

Oracle® Integrated Lights Out Manager (ILOM) 3.0

Supplement for
Sun Blade T6320 Server Modules



Copyright © Copyright© 2009, 2010 Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure the safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Copyright © 2009, 2010, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. UNIX est une marque déposée concédée sous licence par X/Open Company, Ltd.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Adobe PostScript

Contents

Preface ix

Understanding ILOM for the Sun Blade T6320 Server Module 1

ILOM Overview 1

Chassis Monitoring Module Features 2

Updating the System Firmware 2

Resetting the Password to the Factory Default 2

Managing the Host 3

Resetting the Host 4

Managing Host Boot Mode 4

Boot Mode 4

▼ Manage the Host Boot Mode LDOMs Configuration (CLI) 5

▼ Change the Host Boot Mode Behavior at Reset (CLI) 5

▼ Manage the Host Boot Mode Script (CLI) 6

▼ Display Host's Boot Mode Expiration Date (CLI) 7

▼ View or Configure Boot Mode Settings (Web Interface) 7

Viewing and Configuring Host Control Information 8

▼ Display the Host's MAC Address (CLI) 8

▼ Display the Host's OpenBoot Version (CLI) 9

▼ Display the Host's POST Version (CLI) 9

▼ Specify Host Behavior When an Error Is Discovered During
Diagnostics (CLI) 9

- ▼ Specify Host Behavior When the Host Stops Running (CLI) 10
- ▼ View and Configure Host Control Information (Web Interface) 10

Managing Host Diagnostics and POST 12

- ▼ Specify the Level of Diagnostics (CLI) 12
- ▼ Change the Diagnostics Mode (CLI) 13
- ▼ Specify Diagnostic Trigger Conditions (CLI) 13
- ▼ Choose the Amount of Verbosity in Diagnostic Output (CLI) 14
- ▼ Manage Diagnostic Settings (CLI) 15

Managing System User Interactions 16

- ▼ Enable the System to Send a Break Signal or Force a Core Dump (CLI) 16
- ▼ Display Host Status Information (CLI) 16

Managing the Service Processor 19

Storing Customer Information 20

- ▼ Change Customer FRU Data (CLI) 20
- ▼ Change System Identification Information (CLI) 20
- ▼ Change Customer Identification Information (Web Interface) 21

Changing Service Processor Setting to Factory Defaults 22

- ▼ Reset Service Processor Setting to Factory Default Values (CLI) 22
- ▼ Reset Service Processor Setting to Factory Default Values (Web Interface) 22
- ▼ Display Console History (CLI) 23
- ▼ Change Console Escape Characters (CLI) 24

Changing Configuration Policy Settings 24

- ▼ Specify Backup of the User Database (CLI) 25
- ▼ Restore Host Power State at Restart (CLI) 25
- ▼ Specify Host Power State at Restart (CLI) 26
- ▼ Disable or Re-Enable Power-On Delay (CLI) 26
- ▼ Manage Configuration Policy Settings (Web Interface) 27

Managing Power Usage and Monitoring Power Consumption	28
Power Management Interfaces	28
Power Management Terminology	28
▼ View Power Management Properties (CLI)	30
▼ View the Total Power Consumed by the System (CLI)	30
▼ Viewing Total Available Power (CLI)	31
▼ Monitoring Permitted Power Consumption (CLI)	32
Using the Power Consumption Control Interfaces	32
▼ Setting the Power Policy (CLI)	32
▼ Viewing the Power Policy (CLI)	33
▼ Viewing Power Management Properties (Web Interface)	33
Managing Network Access	34
▼ Disable or Re-Enable Network Access to the SP (CLI)	34
▼ Display the DHCP Server's IP Address (CLI)	34
Managing SSH Server Settings	35
▼ Changing the Type of SSH Keys (CLI)	35
▼ Generating a New Set of SSH Keys (CLI)	35
▼ Restarting the SSH Server (CLI)	36
▼ Enable or Disable the SSH Service (CLI)	36
▼ Managing SSH Server Settings (Web Interface)	36
Monitoring Active System Faults	37
▼ Displaying Active System Faults	37
Managing Devices	39
Managing Virtual Keyswitch Settings	39
▼ Specify Host Behavior (CLI)	39
▼ Control the Virtual Keyswitch (Web Interface)	40
IPMI Sensor Reference	41

Sensors on the Sun Blade T6320 Server Module Server 42

Indicators on the Sun Blade T6320 Server Module 42

ALOM CMT Compatibility Shell 45

Limits to Backward Compatibility 45

Adding a Commit Step to Procedures That Configure ILOM Network
Configuration Properties 45

▼ Commit a Change to a Network Configuration Property 46

▼ Commit a Change to a Serial Port Configuration Property 46

▼ Create an ALOM CMT Compatibility Shell 47

▼ Switch Between the ALOM CMT Shell and the Host Console 49

▼ Return to the ILOM From the ILOM CMT Shell 50

ILOM and ALOM CMT Command Comparison 50

ALOM CMT Variables 59

ALOM CMT Variable Comparison 59

Event Messages Available Through the ALOM Compatibility Shell 61

Event Message Overview 61

Event Severity Levels 62

Service Processor Usage Event Messages 63

Environmental Monitoring Event Messages 66

Host Monitoring Event Messages 70

SCC Backup and Restore 73

Information Stored on the SCC 74

Index 77

Preface

This document contains information about the Oracle Integrated Lights Out Manager (ILOM) firmware for the Sun Blade T6320 server module from Oracle. ILOM features are covered in the ILOM 3.0 documentation collection. This document augments that collection, providing information that only pertains to the Sun Blade T6320 server module.

ILOM firmware is used to manage and administer the Sun Blade T6320 Server Module.

You should be an experienced system administrator with a knowledge of UNIX commands.

To fully use the information in this document, you must have thorough knowledge of the topics discussed in these documents.

- Sun Blade T6320 Server Module Product Notes
- Oracle Integrated Lights Out Manager (ILOM) Documentation Collection
- ILOM CMM documentation for your Sun Blade modular system (chassis)

Related Documentation

The documents listed as online are available at:

(<http://docs.sun.com/app/docs/prod/blade.t6340>)

Additional Sun documentation is available at:

(<http://docs.sun.com>)

Application	Title	Part Number	Location
Late-breaking information	<i>Sun Blade T6320 Server Module Product Notes</i>	820-2383	Online
Safety Information	<i>Sun Blade T6320 Server Module Safety and Compliance Manual</i>	820-2387	Online
	Important Safety Information About Sun Hardware	816-7190 or 821-1590	Shipping kit
Installing and Administering the server module	<i>Sun Blade T6320 Server Module Installation Guide</i>	820-2384	Online
Service information	<i>Sun Blade T6320 Server Module Service Manual</i>	820-2386	Online

For more information about how to work with ILOM features that are common to all platforms managed by ILOM, the following documentation provides information.

Task	Title	Part Number	Location
Conceptual information	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Concepts Guide</i>	820-6410	Online
Browser interface information	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Web Interface Procedures Guide</i>	820-6411	Online
CLI procedural information	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 CLI Procedures Guide</i>	820-6412	Online
SNMP and IPMI information	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Management Protocols Reference Guide</i>	820-6413	Online
Installation and configuration information	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Getting Started Guide</i>	820-5523	Online

For more information about how to work with your host server, the following documentation provides information.

Task	Title
Performing diagnostic tests	<i>SunVTS User's Guide</i>
	<i>SunVTS Quick Reference Guide</i>
	<i>SunVTS Test Reference Manual</i>
	<i>Sun Management Center Software User's Guide</i>
System and network administration	<i>Solaris System Administrator Guide</i>
	<i>SPARC: Installing Solaris Software</i>
Working with Logical Domains (LDoms)	Documentation online at: http://docs.sun.com/app/docs/prod/ldoms.mgr
Sun Blade 6000 modular system	Documentation online at: http://docs.sun.com/app/docs/prod/blade.6000mod
Sun Blade 6048 modular system	Documentation online at: http://docs.sun.com/app/docs/prod/blade.6048mod

Documentation, Support, and Training

These web sites provide additional resources:

- Documentation (<http://docs.sun.com>)
- Support (<http://www.sun.com/support>)
- Training (<http://www.sun.com/training>)

Documentation Feedback

Submit comments about this document by clicking the Feedback[+] link at (<http://docs.sun.com>). Include the title and part number of your document with your feedback:

Oracle Integrated Lights Out Manager (ILOM) 3.0 Supplement for the Sun Blade T6320 Server Module, part number 820-7145-11.

Understanding ILOM for the Sun Blade T6320 Server Module

This chapter introduces ILOM for the Sun Blade T6320 Server Module.

This chapter contains the following sections:

- [“ILOM Overview” on page 1](#)
- [“Chassis Monitoring Module Features” on page 2](#)
- [“Updating the System Firmware” on page 2](#)
- [“Resetting the Password to the Factory Default” on page 2](#)

ILOM Overview

Integrated Lights Out Manager (ILOM) is system management firmware that is preinstalled on some SPARC servers. ILOM enables you to actively manage and monitor components installed in your server. ILOM provides a browser-based interface and a command-line interface, for both the Chassis Monitoring Module (CMM) of a Sun Blade modular chassis and for the Sun Blade T6320 Server Module, as well as SNMP and IPMI interfaces. For general information about ILOM, see the *Oracle Integrated Lights Out Manager (ILOM) 3.0 Concepts Guide*.

Note – For information about upgrading, installing, and configuring ILOM on your service processor see the firmware installation instructions in the *Sun Blade T6320 Server Module Installation Guide* and the product notes for your server.

Chassis Monitoring Module Features

The ILOM chassis monitoring module (CMM) manages the Sun Blade modular system chassis. CMM provides management of chassis components, and a method of accessing the service processors in individual server module. The CMM also provides automatic control of the chassis fan speed. For information about using the CMM ILOM with your chassis, refer to the ILOM administration guide for your chassis.

Updating the System Firmware

If an updated version of the system firmware becomes available, you can obtain it from the SunSolve web site in the form of a patch.

Note – You cannot use Sun Update Connection Manager to obtain system firmware.

Resetting the Password to the Factory Default

The procedure for resetting the ILOM root password to the factory default (changeme) requires installation of a jumper on the service processor. The procedure is documented in the *Sun Blade T6320 Server Module Service Manual*.

For information about setting other service processor settings back to the factory defaults, refer to [“Resetting the Variables to the Defaults Using ILOM” on page 44](#).

Managing the Host

This chapter contains information on ILOM features on the Sun Blade T6320 Server Module that augment the array of properties that are common to ILOM on other platforms. In particular, this chapter describes the properties in the /HOST name space. This chapter consists of:

Description	Links
Resetting the Host	“Resetting the Host” on page 4
Managing Host Boot Mode	“Boot Mode” on page 4 “Manage the Host Boot Mode LDom Configuration (CLI)” on page 5 “Change the Host Boot Mode Behavior at Reset (CLI)” on page 5 “Manage the Host Boot Mode Script (CLI)” on page 6 “Display Host’s Boot Mode Expiration Date (CLI)” on page 7 “View or Configure Boot Mode Settings (Web Interface)” on page 7
Viewing and Configuring Host Control Information	“Display the Host’s MAC Address (CLI)” on page 8 “Display the Host’s OpenBoot Version (CLI)” on page 9 “Display the Host’s POST Version (CLI)” on page 9 “Specify Host Behavior When the Host Stops Running (CLI)” on page 10 “Specify Host Behavior When an Error Is Discovered During Diagnostics (CLI)” on page 9 “Specify Host Behavior When an Error Is Discovered During Diagnostics (CLI)” on page 9 “View and Configure Host Control Information (Web Interface)” on page 10
Managing System User Interactions	“Enable the System to Send a Break Signal or Force a Core Dump (CLI)” on page 16 “Display Host Status Information (CLI)” on page 16

Resetting the Host

The reset command generates a graceful or forced hardware reset of the host server. By default, the reset command gracefully resets the host. If a graceful reset is not possible, a forced reset is performed. For a list of available options for the reset command in both the ILOM and ALOM compatibility CLIs, see [TABLE: ALOM CMT Shell Status and Control Commands](#) on page 55.

Managing Host Boot Mode

Use the boot mode properties to specify how ILOM handles boot.

- [“Boot Mode”](#) on page 4
- [“Manage the Host Boot Mode LDOMs Configuration \(CLI\)”](#) on page 5
- [“Manage the Host Boot Mode Script \(CLI\)”](#) on page 6
- [“Change the Host Boot Mode Behavior at Reset \(CLI\)”](#) on page 5
- [“Display Host’s Boot Mode Expiration Date \(CLI\)”](#) on page 7
- [“View or Configure Boot Mode Settings \(Web Interface\)”](#) on page 7

Boot Mode

You can use the boot mode (bootmode) properties to specify how ILOM handles booting. This ability is useful to override particular OpenBoot or LDOMs settings that might be incorrect, to set up OpenBoot variables using a script, or similar tasks.

For example, if the OpenBoot settings have become corrupt, you can set the bootmode state property to reset_nvram then reset the server to its factory default OpenBoot settings.

Service personnel might instruct you to use the bootmode script property for problem resolution. The full extent of script capabilities are not documented and exist primarily for debugging.

Because bootmode is intended to be used to correct problems with the OpenBoot or LDOMs settings, the bootmode takes effect for a single boot only. Additionally, to prevent an administrator from setting a bootmode state property and forgetting about it, a bootmode state property expires if the host is not reset within 10 minutes of the bootmode state property being set.

bootmode properties can be configured using either the ILOM command-line interface (CLI) or the web interface.

▼ Manage the Host Boot Mode LDom Configuration (CLI)

- At the `->` prompt, type:

```
-> set /HOST/bootmode config=confname
```

where the `config` property takes a *confname* value such as a named logical domain configuration downloaded to the SP using the Logical Domains software. For example, if you have created a logical domain configuration called `ldm-set1`:

```
-> set bootmode config=ldm-set1
```

To return the boot mode `config` to the factory default configuration, specify `factory-default`.

For example:

```
-> set bootmode config=factory-default
```

Note – If you set `/HOST/bootmode config=""`, ILOM sets the config to empty.

▼ Change the Host Boot Mode Behavior at Reset (CLI)

The `/HOST/bootmode state` property controls how OpenBoot nonvolatile random access memory (NVRAM) variables are used. Normally the current settings of these variables are retained. Setting `/HOST/bootmode state=reset_nvram` changes the OpenBoot NVRAM variables to their default settings at the next reset.

- At the -> prompt, type:

```
-> set /HOST/bootmode script=value
```

where *value* is one of the following:

- normal – At next reset, retains current NVRAM variable settings.
- reset_nvram – At next reset, returns OpenBoot variables to default settings.

Note – state=reset_nvram will return to normal after the next server reset or 10 minutes (see expires property in “[Display Host’s Boot Mode Expiration Date \(CLI\)](#)” on page 7). config and script properties do not expire and will be cleared upon the next server reset or manually by setting *value* to "".

▼ Manage the Host Boot Mode Script (CLI)

- At the -> prompt, type:

```
-> set /HOST/bootmode script=value
```

where script controls the host server OpenBoot PROM firmware method of booting. script does not affect the current /HOST/bootmode setting. *value* can be up to 64 bytes in length. You can specify a /HOST/bootmode setting and set the script within the same command.

For example:

```
-> set /HOST/bootmode state=reset_nvram script="setenv diag-switch? true"
```

After the server resets and OpenBoot PROM reads the values stored in the script, the OpenBoot PROM sets the OpenBoot PROM variable diag-switch? to the user-requested value of true.

Note – If you set /HOST/bootmode script="", ILOM sets the script to empty.


▼ Display Host's Boot Mode Expiration Date (CLI)

- At the -> prompt, type:

```
-> show /HOST/bootmode expires
Properties:
    expires = Thu Oct 16 18:24:16 2008
```

where expires is the date and time when the current boot mode will expire.

▼ View or Configure Boot Mode Settings (Web Interface)



The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there's a header with 'ABOUT', 'REFRESH', and 'LOG C'. Below this, it displays 'User: root Role: auroc SP Hostname: SUNSP00144F7E834F'. The main title is 'Sun™ Integrated Lights Out Manager'. A navigation bar contains tabs: 'System Information', 'System Monitoring', 'Configuration', 'User Management', 'Remote Control', and 'Maintenance'. Under 'Configuration', there are sub-tabs: 'Remote Power Control', 'Diagnostics', 'Host Control', 'Host Boot Mode', and 'Keyswitch'. The 'Host Boot Mode' sub-tab is selected, showing the 'Host Boot Mode Settings' page. The page instructions say: 'Configure boot mode settings. Select an option for state, either 'Normal' or 'Reset NVRAM'. Enter the boot script and LDOM configuration.' There are four input fields: 'State' (a dropdown menu currently set to 'Normal'), 'Expiration Date', 'Script', and 'LDOM Config'. A 'Save' button is at the bottom left.

You can use the ILOM web interface to view or configure the four aspects of boot mode control:

- State
- Expiration Date
- Script
- LDom Configuration

1. Log in to the ILOM web interface as Administrator (root) to open the web interface.

2. Select Remote Control -> Boot Mode Settings.
3. Select the Boot Mode State, if desired.
4. View the Expiration Date.
5. Specify a boot script, if desired.
6. Specify an LDOMs configuration file, if desired.
7. Click Save.

Viewing and Configuring Host Control Information

Use the host information properties to view system configuration and firmware version information.

- [“Display the Host’s MAC Address \(CLI\)” on page 8](#)
- [“Display the Host’s OpenBoot Version \(CLI\)” on page 9](#)
- [“Display the Host’s POST Version \(CLI\)” on page 9](#)
- [“Specify Host Behavior When the Host Stops Running \(CLI\)” on page 10](#)
- [“Specify Host Behavior When an Error Is Discovered During Diagnostics \(CLI\)” on page 9](#)
- [“View and Configure Host Control Information \(Web Interface\)” on page 10](#)

▼ Display the Host’s MAC Address (CLI)

The `/HOST macaddress` property is automatically configured by the system software, so you cannot set or change the property. The value is read and determined from the server’s removable system configuration card (SCC PROM) and then stored as a property in ILOM.

`/HOST macaddress` is the MAC address for the `net0` port. The MAC addresses for each additional port increments from the `/HOST macaddress`. For example, `net1` is equal to the value of `/HOST macaddress` plus one (1).

- **View the current setting for this property:**

```
-> show /HOST macaddress
```

▼ Display the Host's OpenBoot Version (CLI)

The `/HOST obp_version` property displays information about the version of OpenBoot on the host.

- View the current setting for this property:

```
-> show /HOST obp_version
```

▼ Display the Host's POST Version (CLI)

The `/HOST post_version` property displays information about the version of POST on the host.

- View the current setting for this property:

```
-> show /HOST post_version
```

▼ Specify Host Behavior When an Error Is Discovered During Diagnostics (CLI)

Use the `/HOST autorunonerror` property to specify whether the host should continue to boot after system diagnostics have discovered an error.

- Set this property:

```
-> set /HOST autorunonerror=value
```

where *value* can be:

- `false` – The system stops booting after an error has been discovered (the default).
- `true` – The system attempts to continue booting after an error has been discovered.

The default value is `false`.

▼ Specify Host Behavior When the Host Stops Running (CLI)

Use the `/HOST autorestart` property to specify what ILOM should do when the host leaves the `RUNNING` state.

- **Set this property:**

```
-> set /HOST autorestart=value
```

where *value* can be:

- `none` – ILOM takes no action other than to issue a warning.
- `reset` – ILOM attempts to reset the system when the Solaris watchdog timer expires (the default).
- `dumpcore` – ILOM attempts to force a core dump of the OS when the watchdog timer expires.

The default value is `reset`.

▼ View and Configure Host Control Information (Web Interface)

This procedure describes how to view and configure several kinds of host information.

ABOUT

REFRESH

LOG OUT

User: root Role: auro SP Hostname: SUNSP00144F7E834F

Sun™ Integrated Lights Out Manager

Sun™ Microsystems, Inc.

Java™

System Information

System Monitoring

Configuration

User Management

Remote Control

Maintenance

Remote Power Control

Diagnostics

Host Control

Host Boot Mode

Keyswitch

Host Control

View and configure the host control information. Auto Run on Error determines whether the host should continue to boot in the event of a non-fatal POST error. Auto Restart Policy determines what action the Service Processor should take when it discovers the host is hung. Boot Timeout defines the time out value for boot timer (0 will disable the timer). Boot Restart Policy defines boot timer restart action. Max Boot Fails Allowed defines the number of max boot fails allowed. Boot Fail Recovery defines the timer action upon reaching max boot fails.

MAC Address:

00:14:4f:7e:83:46

Hypervisor Version:

Hypervisor 1.7.0.build_11***PROTOTYPE*** 2008/09/24 17:23

OBP Version:

OBP 4.30.1_nightly_09.23.2008 2008/09/23 00:07

POST Version:

POST 4.30.1_nightly_09.23.2008 2008/09/23 00:30

SysFW Version:

Sun System Firmware : dev build coreilom-re @coreilom-release.east.sun.com (r37557) Tue Sep 30 21:33:20 EDT 2008

Host Status:

Powered on

Auto Run On Error:

False

Auto Restart Policy:

Reset

Boot Timeout:

0

Boot Restart Policy:

None

Max Boot Fails Allowed:

3

Boot Fail Recovery:

Poweroff

Save

ILOM enables you to view or configure several host control features. There are six aspects to host control:

- MAC address
- OpenBoot version
- POST version
- HOST status
- Auto Run On Error
- Auto Restart Policy

1. Log in to the ILOM web interface as Administrator (root) to open the web interface.
2. Select Remote Control -> Host Control.

3. View the MAC address.
 4. View the Hypervisor version.
 5. View the OpenBoot version.
 6. View the POST version.
 7. View the System Firmware version.
 8. View the Host status.
 9. Select a value for Auto Run On Error, if desired.
 10. Select a value for Auto Restart Policy, if desired.
 11. Select a value for Boot Timeout, if desired.
 12. Select a value for Boot Restart Policy, if desired.
 13. Select a value for Maximum Boot Failures Allowed, if desired.
 14. Select a value for Boot Failure Recovery, if desired.
 15. Click on Save.
-

Managing Host Diagnostics and POST

The system user properties enable you to customize the way ILOM identifies and interacts with the host server.

- [“Enable the System to Send a Break Signal or Force a Core Dump \(CLI\)” on page 16](#)
- [“Display Host Status Information \(CLI\)” on page 16](#)

▼ Specify the Level of Diagnostics (CLI)

Use the `/HOST/diag_level` property to control the level of diagnostic testing to be executed when diagnostics are enabled.

- At the -> prompt, type:

```
-> set /HOST/diag level=value
```

where *value* can be:

- min – Run the minimum level of diagnostics to verify the system.
- max – Run the maximum set of diagnostics to fully verify system health.

The default value is max.

▼ Change the Diagnostics Mode (CLI)

Use the /HOST/diag mode property to control whether diagnostics are enabled and to specify which diagnostic mode is enabled.

- At the -> prompt, type:

```
-> show /HOST/diag mode=value
```

where *value* can be:

- off – Do not run any diagnostics.
- normal – Run diagnostics.
- service – Run service-technician diagnostics, equivalent to using the preset values of /HOST/diag trigger=all-resets, /HOSTS/diag verbosity, and /HOST/diag level=max. Setting /HOST/diag mode=service has the same effect as issuing the set /SYS keyswitch_state=diag command.

The default value is normal.

▼ Specify Diagnostic Trigger Conditions (CLI)

Use the /HOST diag trigger property to control the conditions under which POST runs if diagnostics are enabled.

- At the -> prompt, type:

```
-> set /HOST diag trigger=value
```

where *value* is one (or a combination, supplied within quote marks and separated by a space) of the following:

- user-reset - Run diagnostics when the system is reset.

- `error-reset` - Run diagnostics when the system takes a fatal error that requires the system to reset itself to recover.
- `power-on-reset` - Run diagnostics when the system is powered on.
- `all-resets` - Run diagnostics at any server reset.
- `none` - Skip diagnostics.

The default value is the combination of `power-on-reset` `error-reset`.

For example:

```
-> set /HOST/diag trigger="user-reset power-on-reset"
Set 'trigger' to 'user-reset power-on-reset'
-> show /HOST/diag trigger
Properties:
    trigger = user-reset power-on-reset

Commands:
    set
    show
->
```

▼ Choose the Amount of Verbosity in Diagnostic Output (CLI)

Use the `/HOST/diag` verbosity property to specify the verbosity level of the output from POST diagnostics, if diagnostics are enabled.

- At the `->` prompt, type:

```
-> set /HOST/diag verbosity=value
```

where *value* is one of the following:

- `none` - Diagnostics do not print any output on the system console when running, unless a fault is detected.
- `min` - Diagnostics print a limited amount of output on the system console.
- `max` - Diagnostics print full output on the system console, including the name and results of each test being run.
- `normal` - Diagnostics print a moderate amount of output on the system console.

- **debug** - Diagnostics print extensive debugging output on the system console, including devices being tested and debug output of each test.

The default value is normal.

For example:

```
-> show /HOST status
/HOST
  Properties:
    status = Solaris running

  Commands:
    cd
    set
    show
->
```

▼ Manage Diagnostic Settings (CLI)

Use the `show /HOST status` command to display information about the host server's platform ID and status.

- At the `->` prompt, type:

```
-> show /HOST status
```

For example:

```
-> show /HOST status
/HOST
  Properties:
    status = Solaris running

  Commands:
    cd
    set
    show
->
```

Managing System User Interactions

The system user properties enable you to customize the way ILOM identifies and interacts with the host server.

- [“Enable the System to Send a Break Signal or Force a Core Dump \(CLI\)” on page 16](#)
- [“Display Host Status Information \(CLI\)” on page 16](#)

▼ Enable the System to Send a Break Signal or Force a Core Dump (CLI)

Use the `set /HOST send_break_action` command to bring the server to a menu from which you can choose to go to the OpenBoot PROM prompt (ok). If you have configured the `kmdb` debugger, then specifying the `send_break_action=break` command brings the server into debug mode.

Specify `send_break_action=dumpcore` to force a core dump.

- At the `->` prompt, type:

```
-> set send_break_action=value
```

where *value* can be:

- `break` – Sends a break to the host.
- `dumpcore` – Forces a panic core dump of the managed system OS (not supported by all OS versions).

▼ Display Host Status Information (CLI)

Use the `show /HOST status` command to display information about the host server's platform ID and status.

- At the -> prompt, type:

```
-> show /HOST status
```

For example:

```
-> show /HOST status  
/HOST  
  Properties:  
    status = Solaris running  
  
  Commands:  
    cd  
    set  
    show  
->
```


Managing the Service Processor

This chapter contains information on ILOM properties on the Sun Blade T6320 Server Module that augment the array of properties that are common to ILOM on other platforms. In particular, this chapter covers properties in the /SP name space. This chapter consists of:

Description	Links
Storing Customer Information	“Change Customer FRU Data (CLI)” on page 20 “Change System Identification Information (CLI)” on page 20 “Change Customer Identification Information (Web Interface)” on page 21
Change Service Processor Setting to Factory Defaults	
Displaying Console History	“Display Console History (CLI)” on page 23
Modifying Console Escape Characters	“Change Console Escape Characters (CLI)” on page 24
Changing Configuration Policy Settings	“Specify Backup of the User Database (CLI)” on page 25 “Restore Host Power State at Restart (CLI)” on page 25 “Specify Host Power State at Restart (CLI)” on page 26 “Disable or Re-Enable Power-On Delay (CLI)” on page 26 “Manage Configuration Policy Settings (Web Interface)” on page 27
Managing Network Access	“Disable or Re-Enable Network Access to the SP (CLI)” on page 34 “Display the DHCP Server’s IP Address (CLI)” on page 34

Storing Customer Information

This section describes ILOM features that enable you to store information (for purposes such as inventory control or site resource management) on the SP and FRU PROMs.

- [“Change Customer FRU Data \(CLI\)” on page 20](#)
- [“Change System Identification Information \(CLI\)” on page 20](#)
- [“Change Customer Identification Information \(Web Interface\)” on page 21](#)

▼ Change Customer FRU Data (CLI)

Use the `/SP customer_fru_data` property to store information in all FRU PROMs.

- At the `->` prompt, type:

```
-> set /SP customer_fru_data="data"
```

Note – The data string (*data*) must be enclosed in quote marks.

▼ Change System Identification Information (CLI)

Use the `/SP system_identifier` property to store customer identification information.

- At the `->` prompt, type:

```
-> set /SP system_identifier="data"
```

Note – The data string (*data*) must be enclosed in quote marks.

▼ Change Customer Identification Information (Web Interface)

The screenshot shows the Sun Integrated Lights Out Manager (iLOM) web interface. At the top, there is a header bar with 'ABOUT', 'REFRESH', and 'LOG OUT' buttons. Below this, it displays 'User: root Role: auroc SP Hostname: dl94-251' and the title 'Sun™ Integrated Lights Out Manager'. A navigation menu below the header includes 'System Information', 'System Monitoring', 'Configuration', 'User Management', 'Remote Control', and 'Maintenance'. Under 'System Information', there are sub-tabs: 'Versions', 'Session Time-Out', 'Components', 'Fault Management', and 'Identification Information'. The 'Identification Information' tab is active, showing a section titled 'Identification Information' with a description: 'Configure identification information. The setting for Physical Presence Check indicates whether a button press will be required for security related actions such as password recovery.' Below this, there are several input fields: 'Customer FRU Data' (empty), 'SP Hostname' (containing 'SUNSP00144FC64269'), 'SP System Identifier' (empty), 'SP System Contact' (empty), and 'SP System Location' (empty). The 'SP System Description' is displayed as 'Sun Blade T6320 Server Module, iLOM v3.0.2.50.a, r41039'. The 'Physical Presence Check' is set to 'Enabled' with a checked checkbox. A 'Save' button is at the bottom left.

iLOM provides features that enable you to store information on FRUs and the SP.

1. Log in to the iLOM web interface as Administrator (root) to open the web interface.
2. Select System Information -> Identification Information.
3. Edit the Customer FRU data field, if desired.
4. Edit the SP Hostname, if desired.
5. Edit the SP System Identifier field, if desired.
6. Edit the SP System Contact field, if desired.
7. Edit the SP System Location field, if desired.
8. View the SP System Description.
9. Click Save.

Changing Service Processor Setting to Factory Defaults

You can reset the service processor setting to factory defaults using the CLI or the web interface.

▼ Reset Service Processor Setting to Factory Default Values (CLI)

Use the `set reset_to_defaults` command to set all ILOM configuration properties back to their factory default values. The `all` option sets the ILOM configuration and all user information back to the factory default values.

1. At the `->` prompt, type the following command:

```
-> set /SP reset_to_default=value
```

Where *value* can be one of the following:

- none - Make no changes.
- all - Reset (clear) all configuration and users.

2. Reset the service processor so that the new property value can take effect.

▼ Reset Service Processor Setting to Factory Default Values (Web Interface)



1. Log in to the ILOM web interface as Administrator (root) to open the browser interface.
2. Select Maintenance --> Configuration Management.
3. Select a Reset Defaults value:
 - None - Make no changes.
 - All (including users - Reset (clear) all configurations and users.
4. Click Reset Defaults.

▼ Display Console History (CLI)

This section describes displaying the host server console output buffer.

The console buffer can contain up to 1 Mbyte of information. If ILOM senses a host server reset, it writes boot information and initialization data into the console buffer until ILOM is notified by the server that the Solaris OS is up and running.

If ILOM senses a host server reset, it writes boot information and initialization data into the console buffer until ILOM is notified by the server that the Solaris OS is up and running.

Note – You must have Administrator level user permission to use this command.

- At the -> prompt, type:

```
-> set /SP/console/history property=option[...]  
-> show /SP/console/history
```

where *property* can be:

- *line_count* – This option accepts a value within the range of 1 to 2048 lines. Specify "" for an unlimited number of lines. The default is all lines.
- *pause_count* – This option accepts a value of 1 to any valid integer or "" for infinite number of lines. The default is not to pause.
- *start_from* – The options are:
 - *end* – The last line (most recent) in the buffer (the default).
 - *beginning* – The first line in the buffer.

If you type the `show /SP/console/history` command without having set any arguments with the `set` command, ILOM displays all lines of the console log, starting from the end.

Note – Timestamps recorded in the console log reflect server time. These timestamps reflect local time, and the ILOM console log uses UTC (Coordinated Universal Time). The Solaris OS system time is independent of the ILOM time.

▼ Change Console Escape Characters (CLI)

Use the `/SP/console escapechars` property to change the escape character sequence to switch from a system console session back to ILOM.

- At the `->` prompt, type:

```
-> set /SP/console escapechars=xx
```

where `xx` can be any printable characters.

The sequence is limited to two characters. The default value is `#`. (Hash-Period). You can customize the sequence.

Note – Changing the escape character does not take effect in a currently active console session.

Changing Configuration Policy Settings

This section describes managing configuration system policies using ILOM.

- [“Specify Backup of the User Database \(CLI\)” on page 25](#)
- [“Restore Host Power State at Restart \(CLI\)” on page 25](#)
- [“Specify Host Power State at Restart \(CLI\)” on page 26](#)
- [“Disable or Re-Enable Power-On Delay \(CLI\)” on page 26](#)

- “Manage Configuration Policy Settings (Web Interface)” on page 27

▼ Specify Backup of the User Database (CLI)

The `/SP/policy BACKUP_USER_DATA` property specifies whether the local user database on ILOM (that is, user, password, and permission information) should be backed up. When this property is set to enabled, this data is backed up on the removable system configuration card (SCC PROM) on the system.

- At the `->` prompt, type:

```
-> set /SP/policy BACKUP_USER_DATA=value
```

where *value* can be:

- enabled – Backs up the user database to the SCC (This is the default value).
- disabled – No backup.

The default value is enabled.

For example, if you want the local user database on ILOM to be backed up, type:

```
-> set /SP/policy BACKUP_USER_DATA=enabled
```

▼ Restore Host Power State at Restart (CLI)

Use the `/SP/policy HOST_LAST_POWER_STATE` property to control the behavior of the server after an unexpected power outage. When external power is restored, the ILOM service processor starts to run automatically. Normally, the host power is not turned on until you use ILOM to turn it on.

ILOM records the current power state of the server in nonvolatile storage. If the `HOST_LAST_POWER_STATE` policy is enabled, ILOM can restore the host to the previous power state. This policy is useful in the event of a power failure, or if you physically move the server to a different location.

For example, if the host server is running when power is lost and the `/SP/policy HOST_LAST_POWER_STATE` property is set to disabled, the host server remains off when power is restored. If the `/SP/policy HOST_LAST_POWER_STATE` property is set to enabled, the host server restarts when the power is restored.

- At the -> prompt, type:

```
-> set /SP/policy HOST_LAST_POWER_STATE=enabled
```

where *value* can be:

- enabled – When power is restored, returns the server to the state it was in before the power was removed.
- disabled – Keeps the server off when power is applied (the default).

The default value is disabled.

If you enable HOST_LAST_POWER_STATE, you should also configure /SP/policy HOST_POWER_ON_DELAY. For further information, see [“Disable or Re-Enable Power-On Delay \(CLI\)”](#) on page 26.

▼ Specify Host Power State at Restart (CLI)

Use /SP/policy HOST_AUTO_POWER_ON to power on the host automatically when the service processor has been booted. If this policy is set to enabled, the service processor sets HOST_LAST_POWER_STATE to disabled.

- At the -> prompt, type:

```
-> set /SP/policy HOST_AUTO_POWER_ON=value
```

where *value* can be:

- enabled – When power is applied, automatically powers on the host when the SP has been booted.
- disabled – Keeps the host power off when power is applied (the default).

The default value is disabled.

▼ Disable or Re-Enable Power-On Delay (CLI)

Use the /SP/policy HOST_POWER_ON_DELAY property to cause the server to wait for a short time before powering on automatically. The delay is a random interval of one to five seconds. Delaying the server power on helps minimize current surges on the main power source. This power-on delay is important when multiple servers in racks power on after a power outage.

- At the -> prompt, type:


```
-> set /SP/policy HOST_POWER_ON_DELAY=value
```

where *value* can be:

- enabled
- disabled (the default).

The default value is disabled.

▼ Manage Configuration Policy Settings (Web Interface)



1. Log in to the ILOM web interface as Administrator (root) to open the web interface.
2. Select Configuration -> Policy.
3. Click the Policy radio button of the policy you want to change.
4. Select an Action value to apply the Action (enable or disable) you have chosen.

Managing Power Usage and Monitoring Power Consumption

This section describes how to use power management interfaces to manage power usage and to monitor power consumption.

Power Management Interfaces

Power management interfaces enable you to configure and display the power management policy of the system. You use power management policies to manage power usage based on user requirements. Power policies enable you to optimize power usage to match system requirements.

Note – An SNMP MIB (PM-ILOM-MIB) is available to support power management software.

Power Management Terminology

Table 3 -1 defines the terminology used in power management.

TABLE: Power Management Terms

Term	Definition
Actual power	The input power measured in watts. This is the actual power consumed by all the power supplies in the system.

TABLE: Power Management Terms

Term	Definition
Permitted power	The maximum power that the server will permit to be used at any time.
Available power	The input power capacity in watts. For server module, available power is the amount of power available to the server module from the chassis.
Power policy	The setting that governs system power usage at any point in time. Four power policies are supported: Performance, Elastic, Regulated, and Siesta. The characteristics of each policy setting are as follows: <ul style="list-style-type: none">• Performance: The system is allowed to use all the power that is available.• Elastic: The system power usage is adapted to the current utilization level. For example, power up or down just enough system components to keep relative utilization at 70% at all times, even if the workload fluctuates.• Regulated: N/A• Siesta: N/A

▼ View Power Management Properties (CLI)

- At the `_>` prompt, type the following command:

```
-> show /SP/powermgmt
```

For example:

```
-> show /SP/powermgmt

/SP/powermgmt
  Targets:
    history

  Properties
    actual_power = 193
    permitted_power = 320
    available_power = 320

  Commands
    cd
    show

->
```

where

- `actual_power` displays the input power (in watts) consumed by all power supplies in the system.
- `permitted_power` displays the maximum power consumption (in watts) expected.
- `available_power` displays the input power capacity (in watts) that is available to system components.

▼ View the Total Power Consumed by the System (CLI)

The value of `/SYS/VPS` is equivalent to the value of the following command: `show /SYS/powermgmt actual_power`.

The `/SP/powermgmt actual_power` property is the same as `/SYS/VPS` in that `/SYS/VPS` is a sensor that has a threshold and `actual_power` is just the value returned by the sensor.

- At the -> prompt, type the following command:

```
-> show /SYS/VPS
```

for example:

```
-> show /SP/VPS

/SP/VPS
Targets:

Properties
  type = Power Unit
  class = Threshold Sensor
  value = 193.000 Watts
  upper_nonrecov_threshold = N/A
  upper_critical_threshold = N/A
  upper_noncritical_threshold = N/A
  lower_noncritical_threshold = N/A
  lower_critical_threshold = N/A
  upper_nonrecov_threshold = N/A
  alarm_status = cleared

Commands
  cd
  show

->
```

▼ Viewing Total Available Power (CLI)

This interface enables you to view available power.

The system contains one property, `available_power`. The property supports the `show` command and returns the value `<input available power in watts>`.

- Type the `show` command to display the available power:

For example:

```
-> show /SYS/powermgmt available_power
```

▼ Monitoring Permitted Power Consumption (CLI)

This interface enables you to view permitted power consumption. The permitted power consumption is the maximum input power the server guarantees it will consume at any instant. This value cannot be changed directly, but can change based on the power policy and budget, and chassis available power.

The system contains one property, `permitted_power`. The property supports the `show` command and returns the value `<maximum permitted power consumption in watts>`.

- **Type the `show` command to display the permitted power consumption:**

For example:

```
-> show /SYS/powermgmt available_power
```

Using the Power Consumption Control Interfaces

The following section describes how to monitor and control available power and set power consumption configuration parameters.

This interface enables you to set and monitor the power policy of the system. The Power Policy setting is saved across reboots.

The system contains one property, `policy`. This property supports the `show` and `set` commands. Two power policies are supported, `performance` and `elastic`. (Regulated and Siesta policies are not supported currently.) For a description of each of these values, see the definition of Power Policy in TABLE 3-1.

▼ Setting the Power Policy (CLI)

- **Type the `set` command to set the power policy:**

For example, set the power policy to `performance`:

```
-> set /SP/powermgmt policy=performance
```


▼ Viewing the Power Policy (CLI)

- Type the `show` command to display the power policy:

For example:

```
-> show /SP/powermgmt policy
```

▼ Viewing Power Management Properties (Web Interface)



The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a header bar with "ABOUT", "REFRESH", and "LOG OUT" buttons. Below the header, the user role is "Administrator (root)" and the SP Hostname is "SUNSP00144F3AE0AF". The main navigation bar includes "System Information", "System Monitoring", "Configuration", "User Management", "Remote Control", and "Maintenance". The "System Monitoring" tab is selected, and within it, the "Power Management" sub-tab is active. The "Power Management" section displays the following information:

- Actual Power: 242 watts
- Permitted Power: 1000 watts
- Available Power: 1000 watts

Below this, there are configuration options:

- Power Control:
- Power Policy:
- Regulated Budget: watts
- Elastic Budget: watts

A "Save" button is located at the bottom of the configuration section.

1. Log in to the ILOM web interface as Administrator (root) to open the web interface.
2. Select System Monitoring -> Power Management.
3. View the Actual Power consumption.
4. View the Permitted Power consumption.
5. View the Available Power.
6. Select the Power Control.
7. Select the Power Policy.

Note – Elastic and Regulated policy values are not supported currently.

Managing Network Access

This section describes managing network access to the SP using ILOM.

- [“Disable or Re-Enable Network Access to the SP \(CLI\)” on page 34](#)
- [“Display the DHCP Server’s IP Address \(CLI\)” on page 34](#)

▼ Disable or Re-Enable Network Access to the SP (CLI)

Use the `/SP/network state` property to enable or disable the service processor’s network interface.

- At the `->` prompt, type:

```
-> set /SP/network state=value
```

where *value* can be:

- enabled (the default)
- disabled

▼ Display the DHCP Server’s IP Address (CLI)

To display the IP address of the DHCP server that provided the dynamic IP address requested by the service processor, view the `dhcp_server_ip` property. To see the `dhcp_server_ip` property, use the following procedure.

- Type:

```
-> show /SP/network

/SP/network
Targets:

Properties:
  commitpending = (Cannot show property)
  dhcp_server_ip = 10.8.31.5
  ipaddress = 10.8.31.188
  ipdiscovery = dhcp
```

```
ipgateway = 10.8.31.248
ipnetmask = 255.255.252.0
macaddress = 00:14:4F:7E:83:4F
pendingipaddress = 10.8.31.188
pendingipdiscovery = dhcp
pendingipgateway = 10.8.31.248
pendingipnetmask = 255.255.252.0
state = enabled
```

Commands:

```
cd
set
show
```

Managing SSH Server Settings

▼ Changing the Type of SSH Keys (CLI)

Use the `set /SP/services/ssh generate_new_key_type` command to change the type of Secure Shell (SSH) host keys generated on your server. After changing the type, you must use the command `set /SP/services/ssh generate_new_key_action` to generate a new set of keys of the new type.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh generate_new_key_type=value
```

where *value* can be *rsa* or *dsa*.

▼ Generating a New Set of SSH Keys (CLI)

Use the `set /SP/services/ssh generate_new_key_action` command to generate a new set of Secure Shell (SSH) host keys.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh generate_new_key_action=true
```

▼ Restarting the SSH Server (CLI)

Use the `set /SP/services/ssh restart_sshd_action` command to restart the SSH server after you have generated new host keys using the `set /SP/services/ssh generate_new_key_action` command. This reloads the keys into the server's dedicated data structure in memory.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh restart_sshd_action=true
```

▼ Enable or Disable the SSH Service (CLI)

Use the `/SP/services/ssh state` property with the `set` command to enable or disable the SSH service. If the SSH service has been disabled, you can re-enable it through the serial management port (SER MGT) using the ILOM web interface.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh state=value
```

where *value* can be:

- enabled
- disabled

The default value is enabled.

▼ Managing SSH Server Settings (Web Interface)

1. Log in to the ILOM browser interface as Administrator (`root`) to open the web interface.
2. Select Configuration -> SSH Server Settings.
3. Select an action from the SSH Server pull-down menu:
 - Enable the SSH Server
 - Disable the SSH Server
 - Restart the SSH Server

4. Click **Generate RSA Key** or click **Generate DSA Key** to generate a new key type and a new key.

If you have generated a new key, you must restart the SSH server for the new key to take effect.

Note – When the SSH server is restarted or disabled, any CLI sessions running over SSH will be terminated immediately.

Monitoring Active System Faults

▼ Displaying Active System Faults

- At the ILOM CLI prompt (->), type the `show faulty` command.

The `show faulty` command is a shortcut for the following ILOM command string:

```
-> show -o table -level all /SP/faultmgmt
```

The shortcut produces the same output as the longer command string, displaying all active faults in the system in a concise, tabular format. Sample output:

```
-> show faulty
Target          | Property      | Value
-----+-----+-----
/SP/faultmgmt/0 | fru           | /SYS/MB
/SP/faultmgmt/0 | timestamp     | Jan 16 12:53:00
/SP/faultmgmt/0 | sunw-msg-id   | NXGE-8000-0U
faults/0        |               |
/SP/faultmgmt/0 | uuid          | e19f07a5-580e-4ea0-ed6af663aa61
faults/0        |               |
/SP/faultmgmt/0 | timestamp     | Jan 16 12:53:00
faults/0        |               |
```


Managing Devices

This chapter contains information on ILOM properties on Oracle's Sun Blade T6320 Server Module that augment the array of properties that are common to ILOM on other platforms. In particular, this chapter covers properties in the `/SYS` name space.

- [“Managing Virtual Keyswitch Settings” on page 39](#)

Managing Virtual Keyswitch Settings

- [“Specify Host Behavior \(CLI\)” on page 39](#)
- [“Control the Virtual Keyswitch \(Web Interface\)” on page 40](#)

▼ Specify Host Behavior (CLI)

Use the `/SYS keyswitch_state` property to control the position of the virtual keyswitch.

- At the `->` prompt, type:

```
-> set /SYS keyswitch_state=value
```

where *value* can be:

- `normal` – The system can power itself on and start the boot process (the default).
- `standby` – The system cannot power itself on.
- `diag` – The system can power itself on using preset values of diagnostic properties (`/HOST/diag level=max`, `/HOST/diag mode=max`, `/HOST/diag verbosity=max`) to provide thorough fault coverage. This option overrides the values of diagnostic properties that you might have set.

- locked – The system can power itself on, however you are prohibited from updating any of the flash devices or setting
/HOST send_break_action=break.

▼ Control the Virtual Keyswitch (Web Interface)

You can use the web interface to control the virtual keyswitch position of the system.



The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a header bar with 'ABOUT' on the left and 'REFRESH' and 'LOG' on the right. Below the header, the user information is displayed: 'User: root Role: auroc SP Hostname: SUNSP00144F7E834F'. The main title is 'Sun™ Integrated Lights Out Manager'. Below the title is a navigation bar with tabs: 'System Information', 'System Monitoring', 'Configuration', 'User Management', 'Remote Control', and 'Maintenance'. The 'Remote Control' tab is selected, and within it, the 'Keyswitch' sub-tab is active. The 'Keyswitch' section has the title 'Keyswitch' and the instruction 'Configure keyswitch.'. Below this, there is a label 'Keyswitch:' followed by a dropdown menu showing 'Normal'. At the bottom of the section is a 'Save' button.

1. Log in to the ILOM web interface as Administrator (root) to open the web interface
2. Select Remote Control -> Keyswitch.
3. Select the Keyswitch state value.
4. Click Save.

IPMI Sensor Reference

Your server module includes a number of IPMI-compliant sensors and indicators. Sensors measure voltages, temperature ranges, and detection of when components are installed and removed. Indicators, such as light emitting diodes (LEDs), notify you of important server conditions, such as when service is required.

The IPMI interface limits sensor names to 16 characters. Sensor names must sometimes be shortened to fit this character limit. For example, `/SYS` is sometimes removed from the beginning of the path, or `CMP0` might be abbreviated to `P0`.

This chapter contains the following topics:

- [“Sensors on the Sun Blade T6320 Server Module Server” on page 42](#)
- [“Indicators on the Sun Blade T6320 Server Module” on page 42](#)

Sensors on the Sun Blade T6320 Server Module Server

TABLE: Sensors on the Sun Blade T6320 Server Module

IPMI Name	Full Path	Description
V_+V3_STBY	/SYS/MB/V_+V3_STBY	3.3V standby voltage threshold sensor
V+3V3_MAIN	/SYS/MB/V+3V3_MAIN	3.3V main voltage threshold sensor
V_+5V0_STBY	/SYS/MB/V_+5V0_STBYS	5V standby power.
V_+12V0_MAIN	/SYS/MB/V_+12V0_MAIN	12V mail voltage threshold sensor
V_BAT	/SYS/SP/V_BAT	Battery voltage threshold sensor
V_VDDIO	/SYS/MB/V_DDIO	I/O voltage threshold sensor
T_AMB	/SYS/MB/T_AMB	Ambient temperature threshold sensor
V_VCORE	/SYS/MB/V_VCORE	CPU core voltage threshold sensor
V_VMEML	/SYS/MB/V_VMEML	Left branch voltage threshold sensor
V_VMEMR	/SYS/MB/V_VMEMR	Right branch voltage threshold sensor
T_BCORE	/SYS/MB/CMP <i>n</i> /T_BCORE	CPU temperature sensor at the bottom of the chip, in degrees Celsius.
BR <i>n</i> /CH <i>n</i> /D <i>n</i> /T_AMB	/SYS/MB/CMP <i>n</i> /BR <i>n</i> /CH <i>n</i> /D <i>n</i> /T_AMB	DIMM temperature sensor (in degrees Celsius) defined by CMP <i>n</i> (0-1), branch BR <i>n</i> (0-3), channel CH <i>n</i> (0-1), and DIMM D <i>n</i> (0-1).
/HDD <i>n</i> /PRSNT	/SYS/HDD <i>n</i> /PRSNT	Hard disk drive (0-3) presence sensors

Indicators on the Sun Blade T6320 Server

Module

TABLE: Indicators on the Sun Blade T6320 Server Module

Name	Full Path	Description
LOCATE	/SYS/LOCATE	Locate indicator
ACT	/SYS/ACT	System power activity indicator
SERVICE	/SYS/SERVICE	Service indicator
/HDDn/SERVICE	/SYS/HDDn/SERVICE	Hard disk drive (0-3) service indicator
/HDDn/OK2RM	/SYS/HDDn/OK2RM	Hard disk (0-3) OK-to-remove indicator
OK2RM	/SYS/OK2RM	Blade OK-to-remove indicator
SERVICE	/SYS/MB/CMPn/BRn/CHn/Dn/SERVICE	Service indicator for DIMM defined by CMPn (0-1), branch BRn (0-3), channel CHn (0-1), and DIMM Dn (0-1)
VCORE_POK	/SYS/MB/VCORE_POK	CPU core voltage power good
VMEML_POK	/SYS/MB/VMEML_POK	Power to left bank of memory is good
VMEMR_POK	/SYS/MB/VMEMR_POK	Power to right bank of memory is good

ALOM CMT Compatibility Shell

ILOM supports some of the features of the ALOM CMT command-line interface by means of a compatibility shell. There are significant differences between ILOM and ALOM CMT. This chapter describes those differences. This chapter includes the following topics:

- [“Limits to Backward Compatibility” on page 45](#)
- [“Create an ALOM CMT Compatibility Shell” on page 47](#)
- [“ILOM and ALOM CMT Command Comparison” on page 50](#)

Limits to Backward Compatibility

The backward compatibility shell supports some, but not all features of ALOM CMT. Some of the more significant differences between ILOM and ALOM CMT are described in this section or in the product notes for your server.

Adding a Commit Step to Procedures That Configure ILOM Network Configuration Properties

In the original ALOM CMT environment, when changing the values of some ALOM CMT variables (such as network and serial port configuration variables), it was necessary to reset the service processor (called the system controller in ALOM CMT) before the changes took effect. By comparison, in ILOM (and the ALOM CMT compatibility shell) you must commit the changed values rather than resetting the service processor.



Caution – In ILOM, if you change the value of the property and reset the SP without committing the change, the new property setting will not be retained.

▼ Commit a Change to a Network Configuration Property

- 1. Change the value of the target network configuration property.
- 2. Commit the change.

For example, set a static IP address using the ALOM compatibility CLI:

```
SC> setsc netsc_ipaddr xxx.xxx.xxx.xxx
SC> setsc netsc_commit true
```

To set the same property using the ILOM CLI:

```
-> set /SP/network pendingipaddress=xxx.xxx.xxx.xxx
Set 'pendingipaddress' to 'xxx.xxx.xxx.xxx'
-> set /SP/network commitpending=true
Set 'commitpending' to 'true'
```

▼ Commit a Change to a Serial Port Configuration Property

- 1. Change the value of the target serial port configuration property.
- 2. Use either the ALOM CMT command `setsc ser_commit true` or the ILOM command `set /SP/serial/external commitpending=true` to commit the change.

Refer to “[ILOM and ALOM CMT Command Comparison](#)” on page 50 for a list of variables and corresponding properties.

ALOM CMT Variable	Comparable ILOM Property
netsc_commit	/SP/network commitpending
ser_commit	/SP/serial/external commitpending

▼ Create an ALOM CMT Compatibility Shell

Your server is configured to operate under an ILOM shell, by default. You can create an ALOM compatibility shell if you prefer to use commands that resemble ALOM CMT commands to administer your server.

Note – If you have performed an upgrade of the firmware from an earlier version and selected the option to preserve the settings of your earlier version of ILOM, you can continue to use your prior settings (including the username `admin` and password) without recreating the `admin` username, described in this section. If you use the original password for the username `root` supplied with ILOM firmware, ILOM warns you that the password is still set to the factory default.

1. **Log onto the service processor with a username that has been assigned the user management (u) role.**

When powered on, the SP boots to the ILOM login prompt.

```
XXXXXXXXXXXXXXXXXXXX login: username
Password:
Waiting for daemons to initialize...
Daemons ready

Integrated Lights Out Manager

Version 3.0.x.x

Copyright 2008 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

Warning: password is set to factory default.

->
```

2. **Create a user named `admin`, and set the `admin` account roles to `aucro` and the CLI mode to `alom`.**

```
-> create /SP/users/admin
Creating user...
Enter new password: *****
Enter new password again: *****
```

```
Created /SP/users/admin
```

```
-> set /SP/users/admin role=aucro
```

```
Set 'role' to 'aucro'
```

```
->set /SP/users/admin cli_mode=alom
```

```
Set 'cli_mode' to 'alom'
```

Note – The asterisks in the example will not appear when you enter your password.

You can combine the create and set commands on a single line:

```
-> create /SP/users/admin role=aucro cli_mode=alom
```

```
Creating user...
```

```
Enter new password: *****
```

```
Enter new password again: *****
```

```
Created /SP/users/admin
```

3. Log out of the root account after you have finished creating the admin account.

```
-> exit
```

4. Log in to the ALOM CLI shell (indicated by the `sc>` prompt) from the ILOM login prompt.

```
XXXXXXXXXXXXXXXXXXXX login: admin
Password:
Waiting for daemons to initialize...

Daemons ready

Integrated Lights Out Manager

Version 3.0.x.x

Copyright 2008 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

sc>
```

In the ALOM CMT compatibility shell (with a few exceptions) you can use commands that resemble the commands of ALOM CMT. Remember that the ALOM CMT compatibility shell is an ILOM interface. The comparisons between the ILOM CLI and the ALOM CMT compatibility CLI are described in [“ILOM and ALOM CMT Command Comparison” on page 50](#).

▼ Switch Between the ALOM CMT Shell and the Host Console

1. To switch from the ALOM CMT shell to the host console, type:

```
SC> console
host>
```

2. To switch from the console to the ALOM CMT shell, type hash-period:

```
host> #.
sc>
```

▼ Return to the ILOM From the ILOM CMT Shell

1. Log out of the ALOM CMT compatibility shell:

```
sc> logout
```

The ILOM prompt is displayed.

2. Log in to the ILOM CLI as usual, using an account other than the `admin` account (such as `root`).

The `admin` account cannot be used for the ILOM CLI as long as its CLI mode is set to the value `alom`.

In the ALOM CMT compatibility shell (with few exceptions), you can use commands that resemble the commands of ALOM CMT. Remember that the ALOM CMT compatibility shell is an ILOM interface. Refer to the *Sun Blade T6320 Server Module Service Manual* for information about service-related ALOM CMT compatibility shell commands.

ILOM and ALOM CMT Command Comparison

The following table provides a command-by-command comparison between the command sets of ALOM CMT and the default ILOM CLI command set. Only the supported ALOM CMT command options are listed in the tables below. Where there are ALOM CMT command-line arguments that have no corresponding ILOM properties, those ALOM CMT arguments have been omitted. The command set of the ALOM compatibility shell provides a close approximation of the equivalent commands and arguments (where supported) in ALOM CMT.

Note – By default, when displaying information ALOM CMT commands limit their output to a terse format, offering more verbose output if a `-v` flag is supplied with the command. The ILOM `show` commands do not have a terse output format. These commands always provide verbose output.

TABLE: ALOM CMT Shell Configuration Commands

ALOM CMT Command	Summary	Comparable ILOM Command
<code>password</code>	Changes the login password of the current user.	<code>set /SP/users/username password</code>
<code>restartssh</code>	Restarts the SSH server so that new host keys generated by the <code>ssh-keygen</code> command are reloaded.	<code>set /SP/services/ssh restart_sshd_action=true</code>
<code>setdate [[<i>mmdd</i>]<i>HHMM</i> <i>mmddHHMM</i>[<i>cc</i>]<i>yy</i>][<i>.SS</i>]</code>	Sets ALOM CMT date and time.	<code>set /SP/clock datetime=<i>value</i></code>
<code>setdefaults [-a]</code>	Resets all ALOM CMT configuration parameters to their default values. The <code>-a</code> option resets the user information to the default (one admin account only).	<code>set /SP reset_to_defaults=[none factory all]</code>
<code>setkeyswitch [normal stby diag locked]</code>	Sets the status of the virtual keyswitch. Setting the virtual keyswitch to standby (<code>stby</code>) powers off the server. Before powering off the host server, ALOM CMT asks for a confirmation.	<code>set /SYS keyswitch_state=<i>value</i></code>
<code>setsc [<i>param</i>] [<i>value</i>]</code>	Sets the specified ALOM CMT parameter to the assigned value.	<code>set <i>target</i> <i>property</i>=<i>value</i></code>
<code>setupsc</code>	Runs the interactive configuration script. This script configures the ALOM CMT configuration variables.	No equivalent in ILOM

TABLE: ALOM CMT Shell Configuration Commands (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
<code>showplatform [-v]</code>	Displays information about the host system's hardware configuration, and whether the hardware is providing service. The <code>-v</code> option displays verbose information about the displayed components.	<code>show /HOST</code>
<code>showfru</code>	Displays information about the field-replaceable units (FRUs) in a host server.	Use the ILOM <code>show [FRU]</code> command to display static FRU information. (For dynamic FRU information, use the ALOM CMT <code>showfru</code> command.)
<code>showusers -g lines</code>	Displays a list of users currently logged in to ALOM CMT. The display for this command has a similar format to that of the UNIX command <code>who</code> . The <code>-g</code> option pauses the display after the number of lines you specify for <i>lines</i> .	<code>show -level all -o table /SP/sessions</code> No equivalent in ILOM for <code>-g</code> option
<code>showhost version</code>	Displays version information for host-side components. The <i>version</i> option displays the same information as the <code>showhost</code> command with no option.	<code>show /HOST</code>
<code>showkeyswitch</code>	Displays status of virtual keyswitch.	<code>show /SYS keyswitch_state</code>
<code>showsc [param]</code>	Displays the current nonvolatile random access memory (NVRAM) configuration parameters.	<code>show target property</code>
<code>showdate</code>	Displays the ALOM CMT date. ALOM CMT time is expressed in Coordinated Universal Time (UTC) rather than local time. The Solaris OS and ALOM CMT time are not synchronized.	<code>show /SP/clock datetime</code>

TABLE: ALOM CMT Shell Configuration Commands (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
ssh-keygen -l	Generates Secure Shell (SSH) host keys and displays the host key fingerprint on the SC.	show /SP/services/ssh/keys rsa dsa
ssh-keygen -r		set /SP/services/ssh generate_new_key_action=true
ssh-keygen -t {rsa dsa}		set /SP/services/ssh generate_new_key_type={rsa dsa}
usershow [username]	Displays a list of all user accounts and permission levels, and whether passwords are assigned.	show /SP/users
useradd username	Adds a user account to ALOM CMT.	create /SP/users/username
userdel [-y] username	Deletes a user account from ALOM CMT. The -y option enables you to skip the confirmation question.	delete [-script] /SP/users/username
userpassword [username]	Sets or changes a user password.	set /SP/users/username password
userperm [username] [c] [u] [a] [r] [o] [s]	Sets the permission level for a user account.	set /SP/users/username role=permissions [a u c r o s]

TABLE: ALOM CMT Shell Log Commands

ALOM CMT Command	Summary	Comparable ILOM Command
showlogs -p [r p] [-b <i>lines</i> -e <i>lines</i> -v] [-g <i>lines</i>]	Displays the history of all events logged in the event log, or major and critical events in the event log. The -p option selects whether to display only major and critical events from the event log (r) or to display all of the events from the event log (p). -g <i>lines</i> specifies the number of lines to display before pausing. -e <i>lines</i> displays <i>n</i> lines from the end of the buffer. -b <i>lines</i> displays <i>n</i> lines from the beginning of the buffer. -v displays the entire buffer.	show /SP/logs/event/list No equivalent in ILOM
consolehistory [-b <i>lines</i> -e <i>lines</i> -v] [-g <i>lines</i>] [boot run]	Displays the host server console output buffers. -g <i>lines</i> specifies the number of lines to display before pausing. -e <i>lines</i> displays <i>n</i> lines from the end of the buffer. -b <i>lines</i> displays <i>n</i> lines from the beginning of the buffer. -v displays the entire buffer.	set /SP/console/history <i>property=value</i> [set /SP/console/history <i>property=value</i>] [set /SP/console/history <i>property=value</i>] show /SP/console/history where property can be: line_count=[<i>lines</i>] default value is "" (none), meaning there is no limit to the total number of lines retrieved from the buffer. pause_count=[<i>count</i>] default value is "" (none), meaning there is no limit to the count of lines displayed per pause. start_from=[end beginning] default value is end.

TABLE: ALOM CMT Shell Status and Control Commands

ALOM CMT Command	Summary	Comparable ILOM Command
showenvironment	Displays the environmental status of the host server. This information includes system temperatures, power supply status, front panel LED status, hard disk drive status, fan status, voltage, and current sensor status.	show -o table -level all /SYS
showpower [-v]	Displays power metrics for the host server.	show /SP/powermgmt
shownetwork [-v]	Displays the current network configuration information. The -v option shows additional information about your network, including information about your DHCP server.	show /SP/network
console [-f]	Connects to the host system console. The -f option forces the console write lock from one user to another. In ILOM, the -force option terminates the console, permitting you to start a new console.	start [-force] /SP/console
break [-D] [-c]	Drops the host server from running the Solaris OS software into OpenBoot PROM or kmdb depending upon the mode in which the Solaris software was booted.	set /HOST send_break_action=[break dumpcore] [start /SP/console]
bootmode [normal] [reset_nvram] [config= configname] [bootscript = string]	Controls the host server OpenBoot PROM firmware method of booting.	set /HOST/bootmode <i>property=value</i> (where <i>property</i> is state, config, or script)

TABLE: ALOM CMT Shell Status and Control Commands (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
<code>flashupdate -s IPaddr -f pathname [-v] [-y] [-c]</code>	<p>Downloads and updates system firmware (both host firmware and ALOM CMT firmware). For ILOM, <i>ipaddr</i> must be a TFTP server. If you use DHCP, you can replace <i>ipaddr</i> with the name of the TFTP host.</p> <p>The -y option enables you to skip the confirmation question.</p> <p>The -c option enables you to update system firmware on your server without preserving configuration information.</p> <p>After configuration information has been deleted (by having used the -c option or the <code>set /SP reset_to_defaults=factory</code> command), you must use the -c option when replacing system firmware that includes ILOM 3.0 with firmware that includes ILOM 2.0. If you omit the -c option, the <code>flashupdate</code> command attempts to restore preserved configuration information, halting the firmware downgrade because that configuration information is absent.</p>	<pre>load -source tftp: //ipaddr/pathname</pre>
<code>reset [-y] [-f] [-c]</code>	<p>Generates a hardware reset on the host server.</p> <p>The -y option enables you to skip the confirmation question.</p> <p>The -f option forces a hardware reset.</p> <p>The -c option starts the console.</p>	<pre>reset [-script] [-force] /SYS [start /SP/console]</pre>
<code>reset -d [-n] [-y] [-f] [-c]</code>	<p>The -d option gracefully resets the control domain.</p> <p>The -n option sets the <code>auto-boot</code> variable to <code>disable</code> (lasts for one reset).</p> <p>The -y option enables you to skip the confirmation question.</p> <p>The -f option forces a hardware reset.</p> <p>The -c option starts the console.</p>	<pre>[set /HOST/domain/control auto-boot=disable] reset [-script] [-force] /HOST/domain/control [start /SP/console]</pre>
<code>powercycle [-y] [-f]</code>	<p><code>poweroff</code> followed by <code>poweron</code>. The -f option forces an immediate <code>poweroff</code>, otherwise the command attempts a graceful shutdown.</p>	<pre>stop [-script] [-force] /SYS start [-script] [-force] /SYS</pre>

TABLE: ALOM CMT Shell Status and Control Commands (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
poweroff [-y][-f]	Removes the main power from the host server. The -y option enables you to skip the confirmation question. ALOM CMT attempts to shut the server down gracefully. The -f option forces an immediate shutdown.	stop [-script][-force] /SYS
poweron	Applies the main power to the host server or FRU.	start /SYS
setlocator [on/off]	Turns the Locator LED on the server on or off.	set /SYS/LOCATE value= <i>value</i>
showfaults [-v]	Displays current valid system faults.	show /SP/faultmgmt
clearfault <i>UUID</i>	Manually repairs system faults.	set /SYS/ <i>component</i> clear_fault_action=true
showlocator	Displays the current state of the Locator LED as either on or off.	show /SYS/LOCATE
removeblade [-y]	Pauses the service processor tasks and illuminates the blue OK to Remove LED, indicating that it is safe to remove the blade. The -y option enables you to skip the confirmation question.	set /SYS prepare_to_remove_action=true
unremoveblade	Turns off the OK to Remove LED and restores the service processor state.	set /SYS return_to_service_action=true

TABLE: ALOM CMT Shell FRU Commands

ALOM CMT Command	Summary	Comparable ILOM Command
setfru -c <i>data</i>	The -c option enables you to store information (such as inventory codes) on all FRUs in a system.	set /SYS customer_frudata= <i>data</i>
showfru -g lines [-s -d] [<i>FRU</i>]	Displays information about the FRUs in a host server.	show [<i>FRU</i>]
removefru [-y] [<i>FRU</i>]	Prepares a FRU (for example, a power supply) for removal. The -y option enables you to skip the confirmation question.	set /SYS/PS0 prepare_to_remove_action=true

TABLE: ALOM CMT Shell Automatic System Recovery (ASR) Commands

ALOM CMT Command	Summary	Comparable ILOM Command
<code>enablecomponent component</code>	Re-enables a component that has been disabled using the <code>disablecomponent</code> command.	<code>set /SYS/component component_state=enabled</code>
<code>disablecomponent component</code>	Disables a component.	<code>set /SYS/component component_state=disabled</code>
<code>showcomponent component</code>	Displays system components and their test status.	<code>show /SYS/component component_state</code>
<code>clearasrdb</code>	Removes all entries from the list of disabled components.	No equivalent in ILOM

TABLE: ALOM CMT Shell Miscellaneous Commands

ALOM CMT Command	Summary	Comparable ILOM Command
<code>help [command]</code>	Displays a list of all ALOM CMT commands with their syntax and a brief description of how each command works. Specifying a command name as an option enables you to view the help for that command.	<code>help</code>
<code>reset -y</code>	Reboots ALOM CMT. The <code>-y</code> option enables you to skip the confirmation question.	<code>reset [-script] /SP</code>
<code>userclimode username shelltype</code>	Sets the type of shell to <i>shelltype</i> , where <i>shelltype</i> is default or <i>alom</i> .	<code>set /SP/users/username cli_mode=shelltype</code>
<code>logout</code>	Logs out from an ALOM CMT shell session.	<code>exit</code>
<code>setsc sys_ioreconfigure value</code>	Sets the ioreconfiguration parameter to <i>value</i> , where <i>value</i> is <i>true</i> , <i>false</i> , or <i>next-boot</i> .	<code>set /HOST ioreconfigure=value</code>

ALOM CMT Variables

This chapter contains the following topic:

- [“ALOM CMT Variable Comparison” on page 59](#)

ALOM CMT Variable Comparison

TABLE: ALOM CMT Variables and Comparable ILOM Properties

ALOM CMT Variable	Comparable ILOM Properties
diag_level	/HOST/diag level
diag_mode	/HOST/diag mode
diag_trigger	/HOST/diag trigger
diag_verbosity	/HOST/diag verbosity
if_connection	/SP/services/ssh state
if_emailalerts	/SP/clients/smtp state
if_network	/SP/network state
mgt_mailalert	/SP/alertmgmt/rules
mgt_mailhost	/SP/clients/smtp address
netsc_dhcp	/SP/network pendingipdiscovery
netsc_commit	/SP/network commitpending
netsc_enetaddr	/SP/network macaddress
netsc_ipaddr	/SP/network pendingipaddress
netsc_ipgateway	/SP/network pendingipgateway
netsc_ipnetmask	/SP/network pendingipnetmask
sc_backupuserdata	/SP/policy BACKUP_USER_DATA
sc_clieventlevel	N/A

TABLE: ALOM CMT Variables and Comparable ILOM Properties (*Continued*)

ALOM CMT Variable	Comparable ILOM Properties
sc_cliprompt	N/A
sc_clitimeout	N/A
sc_clipasswdecho	N/A
sc_customerinfo	/SP system_identifier
sc_escapechars	/SP/console escapechars
sc_powerondelay	/SP/policy HOST_POWER_ON_DELAY
sc_powerstatememory	/SP/policy HOST_LAST_POWER_STATE
ser_baudrate	/SP/serial/external pendingspeed
ser_data	N/A
sys_autorestart	/SP autorestart
sys_autorunonerror	/SP autorunonerror
sys_boottimeout	/HOST boottimeout
sys_bootrestart	/HOST bootrestart
sys_bootfailrecovery	/HOST bootfailrecovery
sys_eventlevel	N/A
sys_enetaddr	/HOST macaddress

Event Messages Available Through the ALOM Compatibility Shell

This chapter contains information about event messages. Topics include:

- “Event Message Overview” on page 61
- “Event Severity Levels” on page 62
- “Service Processor Usage Event Messages” on page 63
- “Environmental Monitoring Event Messages” on page 66
- “Host Monitoring Event Messages” on page 70

Event Message Overview

The firmware on the service processor (known in ALOM CMT as the SC or system controller) sends event messages to several destinations:

- Messages are sent to all logged-in users, based on the configuration of the `sc_clieventlevelvariable`.
- Messages are recorded in the event log. View logged messages using the ALOM compatibility shell `showlogs` command.
- Messages recorded in the event log can be identified according to the severity of the event. If the severity of the event is major or critical, you can view the messages for those events using the ALOM compatibility shell `showlogs -p r` command. View all messages in the event log using the ALOM compatibility shell `showlogs -p p` command.
- Messages are sent in email messages based on the configuration of the `mgt_mailalert` variable. Individual email addresses can be configured to receive messages of different severities.
- If the event represents a fault, the event message appears in the output of the ALOM compatibility shell `showfaults` command.

- Messages are sent to the managed system operating system for logging into the Solaris syslog facility based on the configuration of the `sys_eventlevel` variable. Not all versions of the Solaris Operating System support this capability.

Event Severity Levels

Each event has a severity level and corresponding number:

- Critical (1)
- Major (2)
- Minor (3)

ALOM compatibility shell configuration parameters use these severity levels to determine which event messages are displayed.

Service Processor Usage Event Messages

The following table displays usage event messages from the service processor (system controller).

TABLE: System Controller Usage Event Messages

Severity	Message	Description
Critical	Host has been powered off	ALOM compatibility shell sends this message whenever the SC requests a host power off, including when a user types the <code>poweroff</code> command.
Critical	Host has been powered off	ALOM compatibility shell sends this message when the SC requires an immediate host power off, including when a user types the <code>poweroff -f</code> command.
Critical	Host has been powered off	ALOM compatibility shell sends this message when the host power has turned off. It is also normal for this event to be sent when the host has reset itself.

TABLE: System Controller Usage Event Messages (*Continued*)

Severity	Message	Description
Major	Host has been powered on	ALOM compatibility shell sends this message when the SC requests a host power on, either because of <code>sc_powerstatememory</code> or when a user types the <code>poweron</code> command.
Critical	Host has been reset	ALOM compatibility shell sends one of these messages when the SC requests a host reset, including when a user types the <code>reset</code> command.
Critical	Host has been powered ff	
Critical	Host has been powered on	
Critical	Host System has Reset.	ALOM compatibility shell sends this message when the SC detects that the host has reset. This message is followed immediately by the Host has been powered off event message because reset is implemented as a powercycle on these systems.
Minor	"root : Set : object = /clock/datetime : value = "datetime": success	ALOM compatibility shell sends this message when a user types the <code>setdate</code> command to modify the SC date or time.
Major	Upgrade succeeded	ALOM compatibility shell sends this message after the SC firmware has been reloaded after operation of the <code>flashupdate</code> command.
Minor	"root : Set : object = /HOST/bootmode/state: value = "bootmode-value": success	ALOM compatibility shell sends this message after a user changes the bootmode to normal using the <code>bootmode normal</code> command.
Minor	"root : Set : object = /HOST/bootmode/state: value = "reset_nvram": success	ALOM compatibility shell sends this message after a user changes the boot mode to <code>reset_nvram</code> with the <code>bootmode</code> command.
Minor	"root : Set : object = /HOST/bootmode/script: value = "text": success	ALOM compatibility shell sends this message after a user changes the boot mode boot script. The boot script = " <code>text</code> " is the text of the boot script provided by the user.
Minor	Keyswitch position has been changed to <i>keyswitch_position</i> .	ALOM compatibility shell sends this message after a user changes the keyswitch position with the <code>setkeyswitch</code> command. The <i>keyswitch_position</i> is the new keyswitch position.

TABLE: System Controller Usage Event Messages (*Continued*)

Severity	Message	Description
Minor	"user" : open session : object = /session/type: value = www/shell: success	ALOM compatibility shell sends this message when users log in. <i>user</i> is the name of the user who just logged in.
Minor	"user" : close session : object = /session/type: value = www/shell: success	ALOM compatibility shell sends this message when users log out. <i>user</i> is the name of the user who just logged out.
Minor	"root : Set: object = /HOST/send_break_action: value = dumpcore : success	ALOM compatibility shell sends this message when an ALOM compatibility shell user sends a request to the host to dump core by typing the <code>break -D</code> command.
Critical	Host Watchdog timeout.	ALOM compatibility shell sends this message when the host watchdog has timed out and the <code>sys_autorestart</code> variable has been set to none. The SC will not perform any corrective measures.
Critical	SP Request to Dump core Host due to Watchdog.	ALOM compatibility shell sends this message when the host watchdog has timed out and the <code>sys_autorestart</code> variable has been set to <code>dumpcore</code> . The SC attempts to perform a core dump of the host to capture error state information. The dump core feature is not supported by all OS versions.
Critical	SP Request to Reset Host due to Watchdog.	ALOM compatibility shell sends this message when the host watchdog has timed out and the <code>sys_autorestart</code> variable has been set to reset. Then the SC attempts to reset the host.

Environmental Monitoring Event Messages

The following table displays environmental monitoring event messages from the service processor (system controller).

TABLE: Environmental Monitoring Event Messages

Severity	Message	Description
Critical	SP detected fault at time <i>time</i> . Chassis cover removed.	ALOM compatibility shell sends this message if the chassis cover has been removed. The platform hardware turns managed system power off immediately as a precautionary measure. The event message System poweron is disabled should accompany this message to prevent the use of the poweron command while the chassis cover is removed.
Major	System poweron is disabled.	ALOM compatibility shell sends this message when the SC refuses to power on the system, either through the user poweron command or by the front panel power button. The SC disables power on because of an accompanying event, such as the event indicated by the message Chassis cover removed. Other possibilities include a device failure or insufficient fan cooling.
Major	System poweron is enabled.	ALOM compatibility shell sends this message after the condition that caused power on to be disabled (indicated by the preceding System poweron is disabled message) has been rectified. For example, by replacing the chassis cover or installing sufficient fans to cool the system.

TABLE: Environmental Monitoring Event Messages (*Continued*)

Severity	Message	Description
Major	SP detected fault at time <i>time</i> "fault_type 'fault' at <i>location</i> asserted"	<p>ALOM compatibility shell sends this message when a failure or a fault is detected. A fault is a lower priority condition that indicates the system is operating in a degraded mode.</p> <p><i>fault_type</i> is the type of failure that has occurred, such as temperature, voltage, current, or power supply.</p> <p>The <i>location</i> is the location and name of the device that has the error condition. The location and name of the device match the output of the ALOM compatibility shell <code>showenvironment</code> command.</p> <p>This fault event message appears in the output of the ALOM compatibility shell <code>showfaults</code> command.</p>
Minor	SP detected fault cleared at <i>time</i> time current fault at <i>device</i> asserted.	<p>ALOM compatibility shell sends this message to indicate that a prior fault or failure has recovered or been repaired. The fields (time and device) are the same as the prior fault or failure event.</p>

TABLE: Environmental Monitoring Event Messages (*Continued*)

Severity	Message	Description
Major	<i>Device_type</i> at <i>location</i> has exceeded low warning threshold.	ALOM compatibility shell sends these messages when analog measurement sensors have exceeded the specified threshold.
Critical	<i>Device_type</i> at <i>location</i> has exceeded low critical shutdown threshold.	The threshold that was exceeded is included in the message.
Critical	<i>Device_type</i> at <i>location</i> has exceeded low nonrecoverable shutdown threshold	<i>Device_type</i> is the type of device that has failed, such as VOLTAGE_SENSOR or TEMP_SENSOR. The <i>location</i> is the location and name of the device that has the error condition. The location and name of the device match the output of the ALOM compatibility shell showenvironment command.
Major	<i>Device_type</i> at <i>location</i> has exceeded high warning threshold	For TEMP_SENSOR events, this message could indicate a problem outside of the server, such as the temperature in the room or blocked airflow in or out of the server. For VOLTAGE_SENSOR events, this message indicates a problem with the platform hardware or possibly with add-on cards installed.
Critical	<i>Device_type</i> at <i>location</i> has exceeded high soft shutdown threshold	These fault event messages appear in the output of the ALOM compatibility shell showfaults command.
Critical	<i>Device_type</i> at <i>location</i> has exceeded high hard shutdown threshold	
Minor	<i>Device_type</i> at <i>location</i> is within normal range.	ALOM compatibility shell sends this message when an analog measurement sensor no longer exceeds any warning or failure thresholds. This message is sent only if the sensor reading recovers sufficiently within the boundaries of the failure parameters. The message might not match the current output of the ALOM compatibility shell showenvironment command.

TABLE: Environmental Monitoring Event Messages (*Continued*)

Severity	Message	Description
Critical	Critical temperature value: host should be shut down	ALOM compatibility shell sends this message to indicate that the SC has started a shutdown because there are not enough working fans necessary to keep the system cooled. The number of fans necessary to maintain system cooling depends on the platform. See your platform documentation for more information.
Critical	Host system failed to power off.	ALOM compatibility shell sends this message if the SC is unable to power off the system. This message indicates a problem with either the platform hardware or the SC hardware. The system should be manually unplugged to prevent damage to the platform hardware. This fault event message appears in the output of the ALOM compatibility shell showfaults command.
Major	<i>FRU_type</i> at <i>location</i> has been removed.	ALOM compatibility shell sends these messages to indicate that a FRU has been removed or inserted. The field <i>FRU_type</i> indicates the type of FRU, such as SYS_FAN, PSU, or HDD. The field <i>location</i> indicates the location and name of the FRU, as shown in the output of the showenvironment command.
Minor	<i>FRU_type</i> at <i>location</i> has been inserted.	
Major	Input power unavailable for PSU at <i>location</i> .	ALOM compatibility shell sends this message to indicate that a power supply is not receiving input power. This message normally indicates that the power supply is not plugged in to AC power. If the power cords are plugged in to an outlet that is provided power, this message indicates a problem with the power supply itself. This fault event message appears in the output of the ALOM compatibility shell showfaults command.

Host Monitoring Event Messages

The following table displays host monitoring event messages from the service processor (system controller).

TABLE: Host Monitoring Event Messages

Severity	Message	Description
Critical	SP detected fault at time <i>time</i> <i>component</i> disabled	ALOM compatibility shell sends this message when a component has been disabled, either automatically by POST discovering a fault or by a user typing the <code>disablecomponent</code> command. <i>component</i> is the disabled component, which will be an entry from the platform <code>showcomponent</code> command. This fault event message appears in the output of the ALOM compatibility shell <code>showfaults</code> command.
Minor	SP detected fault cleared at <i>component</i> reenabled	ALOM compatibility shell sends this message when a component is enabled. A component can be enabled by a user typing the <code>enablecomponent</code> command or by FRU replacement if the component itself is a FRU (such as a DIMM). <i>component</i> is the name of the component shown in the output of the platform <code>showcomponent</code> command.

TABLE: Host Monitoring Event Messages (*Continued*)

Severity	Message	Description
Major	Host detected fault, MSGID: SUNW-MSG-ID	ALOM compatibility shell sends this message when the Solaris PSH software diagnoses a fault. The SUNW-MSG-ID of the fault is an ASCII identifier that can be entered at http://www.sun.com/msg for more information about the nature of the fault and the steps to repair. This fault event message appears in the output of the ALOM compatibility shell <code>showfaults</code> command.
Major	<i>Location</i> has been replaced; faults cleared.	ALOM compatibility shell sends this message after the replacement of a FRU that contained a host-detected fault. <i>Location</i> is the location and name of the FRU that was replaced. This event can be received at SC boot or after FRUs have been swapped and the chassis cover is closed.
Major	Existing faults detected in FRU_PROM at <i>location</i> .	ALOM compatibility shell sends this message to indicate that the SC has detected a new FRU with pre-existing faults logged into its FRU PROM. This event can occur when either a FRU or the SC card is moved from one system to another. The location is the name of the SEEPROM on the replaced FRU, such as MB/SEEPROM. The most recent existing fault will be imported from the FRU PROM onto the <code>showfaults</code> list. The entry on the <code>showfaults</code> list is the fault imported, not this message.

SCC Backup and Restore

SPARC servers store in the SCC (system configuration card) a subset of the information backed up and restored by ILOM 3.0. In case of a server failure in which there is no ILOM backup of SP data, transferring the SCC to the replacement server can provide partial restoration of the failed server's configuration data.

This chapter contains the following topic:

- [“Information Stored on the SCC” on page 74](#)

Information Stored on the SCC

Note – The version of the data on the SCC must match the version of the SCC daemon running on the SP. If the versions differ, the version on the SCC is ignored. After SP reset, the SCC data is overwritten.

TABLE: ILOM Properties Stored on the SCC

Properties	Targets
/SP/users/ <i>username</i> /	name password role cli_mode
/SP/network/	ipaddress ipdiscovery ipgateway ipnetmask state
/HOST/diag/	trigger level verbosity mode
/HOST/	autorunonerror autorestart
/SP/policy/	HOST_LAST_POWER_STATE HOST_POWER_ON_DELAY BACKUP_USER_DATA
/SP/services/ssh/state	N/A
/SP/clients/smtp/	address port state
/SP/alertmgmt/rules/[1-15]/ (if the alert is an email alert)	destination level type
/SP/system_identifier	N/A
/SYS/keyswitch	N/A

TABLE: ALOM CMT Conditional Variables

Variable
sc_clipasswecho
sc_cliprompt
sc_clitimeout
sc_clieventlevel
sc_eschapechars

Index

Symbols

- /HOST autorestart property, 10
- /HOST autorunonerror property, 9
- /HOST macaddress property, 8
- /HOST send_break_action property, 12, 16
- /HOST status property, 15, 16
- /HOST/bootmode config property, 5
- /HOST/bootmode expires property, 7
- /HOST/bootmode script property, 6
- /HOST/bootmode state property, 5
- /SP customer_fru data property, 20
- /SP system_identifier property, 20
- /SP/console escapechars property, 24
- /SP/policy BACKUP_USER_DATA property, 25
- /SP/policy HOST_AUTO_POWER_ON property, 26
- /SP/policy HOST_LAST_POWER_STATE property, 25
- /SP/policy HOST_POWER_ON_DELAY property, 26
- /SYS keyswitch_state property, 39

A

- ALOM CMT commands, comparison with ILOM commands, 50
- ALOM CMT compatibility shell
 - commands, compared with ILOM commands, 50
 - creating, 47
 - limits to backward compatibility, 45
- ALOM CMT variables
 - to commit, 46

B

- backing up user data, 25
- boot mode

- managing configuration, 5
- managing reset, 5
- managing script, 6

C

- commit network configuration properties, 46

H

- host status information, displaying
 - with CLI, 15, 16

I

ILOM commands

- compared with ALOM CMT compatibility shell commands, 50

ILOM properties

- /HOST autorestart, 10
- /HOST autorunonerror, 9
- /HOST macaddress, 8
- /HOST send_break_action, 16
- /HOST status, 15, 16
- /HOST/bootmode config, 5
- /HOST/bootmode expires, 7
- /HOST/bootmode script, 6
- /HOST/bootmode state, 5
- /SP customer_fru data, 20
- /SP system_identifier, 20
- /SP/console escapechars, 24
- /SP/policy BACKUP_USER_DATA, 25
- /SP/policy HOST_AUTO_POWER_ON, 26
- /SP/policy HOST_LAST_POWER_STATE, 25
- /SP/policy HOST_POWER_ON_DELAY, 26
- /SYS keyswitch_state
 - , 39
- < Command>/HOST send_break_action, 12
- /SP/serial/external commitpending, 46
- to commit, 46

IPMI indicators, 43

IPMI sensors, 42

N

network configuration properties, to commit, 46

O

OpenBoot version, displaying
 with CLI, 9
 with web interface, 10

P

platform, showing, 15, 16

POST version, displaying
 with web interface, 10

property
 backup data, 25
 system user, 12, 16

R

remote control settings
 changing with the CLI, 4
 changing with the web interface, 7

S

server, platform information, 15, 16
/SP/serial/external commitpending
 property, 46

T

timer, watchdog, 10

W

watchdog timer, 10