



Netra 150 Server Product Note

A Sun Microsystems, Inc.
Business
901 San Antonio Road
Palo Alto, , CA 94303-4900

Part No: 802-7556-10
Revision A, February 1997

USA 650 960-1300 fax 650 969-9131



Netra 150 Server Product Note

Part No: 802-7556-10
Revision A, February 1997

Copyright 1997 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, California 94303-4900 U.S.A. All rights reserved.

All rights reserved. This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Portions of this product may be derived from the UNIX[®] system, licensed from Novell, Inc., and from the Berkeley 4.3 BSD system, licensed from the University of California. UNIX is a registered trademark in the United States and in other countries and is exclusively licensed by X/Open Company Ltd. Third-party software, including font technology in this product, is protected by copyright and licensed from Sun's suppliers. RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

Sun, Sun Microsystems, the Sun logo, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the United States and in other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the United States and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK[®] and Sun[™] Graphical User Interfaces were developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox Corporation in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a nonexclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

THIS PUBLICATION IS PROVIDED "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR NON-INFRINGEMENT.

Copyright 1997 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, Californie 94303-4900 U.S.A. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie et la décompilation. Aucune partie de ce produit ou de sa documentation associée ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a.

Des parties de ce produit pourront être dérivées du système UNIX[®] licencié par Novell, Inc. et du système Berkeley 4.3 BSD licencié par l'Université de Californie. UNIX est une marque enregistrée aux Etats-Unis et dans d'autres pays, et licenciée exclusivement par X/Open Company Ltd. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Sun, Sun Microsystems, le logo Sun, et Solaris sont des marques déposées ou enregistrées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC, utilisées sous licence, sont des marques déposées ou enregistrées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

Les utilisateurs d'interfaces graphiques OPEN LOOK[®] et Sun[™] ont été développés de Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox Corporation pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique, cette licence couvrant aussi les licenciés de Sun qui mettent en place les utilisateurs d'interfaces graphiques OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" SANS GARANTIE D'AUCUNE SORTE, NI EXPRESSE NI IMPLICITE, Y COMPRIS, ET SANS QUE CETTE LISTE NE SOIT LIMITATIVE, DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DES PRODUITS A REPENDRE A UNE UTILISATION PARTICULIERE OU LE FAIT QU'ILS NE SOIENT PAS CONTREFAISANTS DE PRODUITS DE TIERS.



Contents

1. **Netra 150 Server Product Note** 1
 - Proper Ordering of Bay Disk Drives 1
 - Product Information 2
 - Booting a Netra 150 Server with a Configuration Diskette 2
 - Time Taken for New Disk to Sync 3
 - Devices Can Only be Connected to Serial Port A on the Netra 150 Server 3
 - Powering Off the Netra 150 Server 4
 - Performing a Cold Boot Causes Inherent Delays 5
 - Installing a Netra 150 Server in a Generic (Non-Sun) Cabinet 5

Netra 150 Server Product Note

This document contains the late-breaking news for the Netra 150 server.

Proper Ordering of Bay Disk Drives

In the *Netra 150 Server Service Manual* , the instructions for installing a bay disk drive say to install the disks from top-to-bottom, left-to-right. These instructions are incorrect; the drives should be installed from top-to-bottom, *right-to-left*. Refer to Figure 1-1 for the proper ordering of the drives.




Figure 1-1 Proper Ordering for Bay Disk Drives

Product Information

You can find all the available product information and late-breaking news for the Netra 150 server by accessing the following web site:

<http://netra.sun.com>

Booting a Netra 150 Server with a Configuration Diskette

Whenever you boot your Netra 150 server, it will look for the configuration information for your site in one of two places:

- If you have a diskette with your configuration information inserted in the Netra 150 server diskette drive, the server will automatically boot using the configuration information stored on that diskette.

- If you do not have a diskette inserted in the Netra 150 server diskette drive, the server will boot using the configuration information stored on the Netra 150 server system hard drive instead.

When you boot your Netra 150 server, you should remove the configuration diskette from the diskette drive so that the system will boot using the configuration information stored on the system hard drive. However, if you want to boot your system using the configuration diskette, you must verify that the diskette has the most up-to-date configuration information stored on it or your system will boot using out-of-date configuration information.

Time Taken for New Disk to Sync

It takes approximately one hour for a new disk to sync if there has been a disk failure.

Devices Can Only be Connected to Serial Port A on the Netra 150 Server

You can only connect devices to serial port A on the Netra 150 server; do *not* connect any devices to serial port B on the server. Refer to Figure 1-2 for the location of serial ports A and B on the Netra 150 server.




Figure 1-2 Location of the Serial Ports on the Netra 150 Server

Powering Off the Netra 150 Server

If you shut down the Netra 150 server using the Netra HTML interface (found under System Administration: *Restart and Shutdown*), this does not remove power from the Netra 150 server. To completely power off the server, the power switch located on the back of the Netra 150 server must be used. This is the switch for the server. Turning this switch to the off position will actually turn off the power to the server.

Note - This switch is only to be used to power off the server to allow new hardware to be installed or replaced. Always shutdown the server gracefully before powering off the server.

Performing a Cold Boot Causes Inherent Delays

A cold boot (powering up the system) on a server with 12 disks takes about 5 minutes to boot up. This is because there are inherent delays in powering up each of the disk drives sequentially. This situation should not be misinterpreted as problems with booting.

Installing a Netra 150 Server in a Generic (Non-Sun) Cabinet

It may be possible for you to install a Netra 150 server in a cabinet that you bought from a company other than Sun Microsystems as long as the cabinet is between 30" and 36" in depth. You can use the instructions given in the *Model 150 Server Series Rack-Ready Installation Manual* (802-6742-10) to install a Netra 150 server in a non-Sun cabinet as long as you keep the following things in mind:

1. The Netra 150 server takes up six rack units in a cabinet.
2. The instructions in the sections Powering Off the Expansion Cabinet and Internal Access (pages 2-1 through 2-5) apply to Sun cabinets only; refer to the manual that you received with your generic cabinet for instructions on powering off your cabinet and removing the outer panels.
3. The instructions in steps 17 and 18 on page 2-11 apply to Sun cabinets only. When you get to this point in the instructions, substitute steps 17 and 18 with these steps:
 1. **Measure the distance between the side rails on your rack.**

Figure 1-3 shows the distance measured between the two side rails on a Sun rack, which is 34 inches. Keep in mind that you want to measure from the outer part of the side rails.




Figure 1-3 Positioning the Bracket Assembly in the Rack

2. Slip the long bracket over the end of the short bracket/slide assembly, with the lip on the short bracket/slide assembly facing out (Figure 1-4).




Figure 1-4 Mounting the Long Bracket on the Short Bracket/Slide Assembly

3. Measure the distance between the lip on the long bracket and the end of the short bracket/slide assembly and extend the two brackets until the distance between the ends of the two brackets equals the distance between the side rails on your rack.

- 4. Flip the assembly over and extend the runner as out as far as possible, then use as many nuts and bolts as possible to loosely secure the long bracket to the short bracket/slide assembly.**

You should be able to use 2 to 5 nuts and bolts to loosely secure the brackets together, depending on the distance between the ends of the two brackets. Do not tighten the nuts and bolts at this time.

1. The instructions in the sections Cabling the Model 150 Server, Restoring the Expansion Cabinet and Powering On the Expansion Cabinet (pages 2-16 through 2-22) apply to Sun cabinets only; refer to the manual that you received with your generic cabinet for instructions on cabling, replacing the outer panels and powering on your cabinet.