

Tekelec EAGLE[®] 5 Integrated Signaling System

Release 41.1

Commands Error Recovery Manual

910-5773-001 Revision B

December 2009



Copyright 2009 Tekelec. All Rights Reserved. Printed in USA.
Legal Information can be accessed from the Main Menu of the optical disc or on the
Tekelec Customer Support web site in the *Legal Information* folder of the *Product Support* tab.

Table of Contents

Chapter 1: Introduction.....	4
Overview.....	5
Scope and Audience.....	5
Related Publications.....	5
Documentation Availability, Packaging, and Updates.....	6
Documentation Admonishments.....	6
Customer Care Center.....	7
Emergency Response.....	9
Locate Product Documentation on the Customer Support Site.....	9
Chapter 2: Command Rejected Messages.....	11
Glossary.....	897

List of Tables

Table 1: Admonishments.....	6
Table 2: Conditions that Generate Error Message E2025.....	20
Table 3: Conditions that Generate Error Message E2155.....	56
Table 4: Conditions that Generate Error Message E2165.....	64
Table 5: Conditions that Generate Error Message E2257.....	93
Table 6: Conditions that Generate Error Message E2368.....	129
Table 7: Operations Requiring force=yes Parameter.....	131
Table 8: Required Command and Parameter Combinations.....	134
Table 9: Point Code Requirements	149
Table 10: Conditions that Generate Error Message E2581.....	203
Table 11: Action if X.25 Destination Table is Full.....	231
Table 12: Action if X.25 Route Table is Full.....	238
Table 13: Routesets Feature with Maximum Values.....	294
Table 14: Conditions that Generate Error Message E2903.....	315
Table 15: Valid dev/port Parameter Combinations.....	331
Table 16: Conditions for Command Usage during IMT Tests.....	355
Table 17: Invalid Parameter Combinations.....	357
Table 18: Valid h0/h1 or nh0/nh1 Parameter Combinations.....	397
Table 19: Valid Values for the nsfi Parameter	398
Table 20: Conditions that Generate Error Message E3500.....	467
Table 21: Prepaid SMS Intercept Ph 1 Commands/Parameters	469
Table 22: Conditions that Generate Error Message E3524.....	472
Table 23: Feature/Option Status.....	498
Table 24: TSM and TDM Memory Requirements.....	505
Table 25: Subnet Mask Values.....	525
Table 26: Valid Parameter Combinations for Routing Key Types.....	553
Table 27: Reason that Card Requires a Full Data Download.....	562
Table 28: Conditions that Generate Error Message E3883.....	575
Table 29: G-Port Dependencies.....	601
Table 30: Conditions that Generate an Error Message E4005.....	605
Table 31: PVN Subnet Mask Values.....	608
Table 32: Frame ID Parameter Values.....	751
Table 33: Default Buffer Configuration Sizes.....	769
Table 34: Command Interaction with IMT Rate Change Sequence.....	895

Chapter 1

Introduction

Topics:

- *Overview.....5*
- *Scope and Audience.....5*
- *Related Publications.....5*
- *Documentation Availability, Packaging, and Updates.....6*
- *Documentation Admonishments.....6*
- *Customer Care Center.....7*
- *Emergency Response.....9*
- *Locate Product Documentation on the Customer Support Site.....9*

This chapter contains general information about the organization of this manual, the audience, references to other Tekelec documentation, information on customer assistance, documentation packaging, delivery, and updates, and a list of acronyms and abbreviations used in the document.

Overview

The *Commands Error Recovery Manual* provides a description of the error messages used in the EAGLE 5 Integrated Signaling System (ISS).

Commands are entered at a terminal to perform system operations such as displaying the system status, administering system security, and maintaining the database. The error messages documented in this book are displayed to provide information about problems encountered when you enter commands.

This document is organized into the following chapters.

Chapter 1, Introduction contains general information about the organization of this manual, the audience, references to other Tekelec documentation you might need, information on customer assistance, documentation packaging, delivery, and updates, and a list of acronyms and abbreviations used in the document.

Chapter 2, Command Rejected Messages contains the error messages generated by the commands used on the system. These error messages are presented in alphabetical order. The following items are included in the description of each message:

- The error message generated by the system.
- A list of the commands that can generate the error message. Note that where such a list would be extensive, only a representative sample of commands is provided.
- A brief definition of the error message.
- The actions needed to resolve the error condition or to make sure that the error message does not appear when the command is executed again.

In addition, an index provides an alphabetical listing of error message text and other entries to assist in finding information.

Scope and Audience

This manual is intended for those who maintain the system and those who do database administration for the system. It is assumed that the user is familiar with the SS7 network and its associated protocols. This manual contains an index of all of the Signaling Engineering and Administration System (SEAS) error messages generated by the *system*.

Related Publications

For information about additional publications that are related to this document, refer to the *Related Publications* document. The *Related Publications* document is published as a part of the *Release Documentation* and is also published as a separate document on the Tekelec Customer Support Site.

Documentation Availability, Packaging, and Updates

Tekelec provides documentation with each system and in accordance with contractual agreements. For General Availability (GA) releases, Tekelec publishes a complete EAGLE 5 ISS documentation set. For Limited Availability (LA) releases, Tekelec may publish a documentation subset tailored to specific feature content or hardware requirements. Documentation Bulletins announce a new or updated release.

The Tekelec EAGLE 5 ISS documentation set is released on an optical disc. This format allows for easy searches through all parts of the documentation set.

The electronic file of each manual is also available from the [Tekelec Customer Support](#) site. This site allows for 24-hour access to the most up-to-date documentation, including the latest versions of Feature Notices.

Printed documentation is available for GA releases on request only and with a lead time of six weeks. The printed documentation set includes pocket guides for commands and alarms. Pocket guides may also be ordered separately. Exceptions to printed documentation are:

- Hardware or Installation manuals are printed without the linked attachments found in the electronic version of the manuals.
- The Release Notice is available only on the Customer Support site.

Note: Customers may print a reasonable number of each manual for their own use.

Documentation is updated when significant changes are made that affect system operation. Updates resulting from Severity 1 and 2 PRs are made to existing manuals. Other changes are included in the documentation for the next scheduled release. Updates are made by re-issuing an electronic file to the customer support site. Customers with printed documentation should contact their Sales Representative for an addendum. Occasionally, changes are communicated first with a Documentation Bulletin to provide customers with an advanced notice of the issue until officially released in the documentation. Documentation Bulletins are posted on the Customer Support site and can be viewed per product and release.

Documentation Admonishments

Admonishments are icons and text throughout this manual that alert the reader to assure personal safety, to minimize possible service interruptions, and to warn of the potential for equipment damage.

Table 1: Admonishments

	<p>DANGER: (This icon and text indicate the possibility of <i>personal injury</i>.)</p>
	<p>WARNING: (This icon and text indicate the possibility of <i>equipment damage</i>.)</p>

	CAUTION: (This icon and text indicate the possibility of <i>service interruption</i> .)
---	---

Customer Care Center

The Tekelec Customer Care Center is your initial point of contact for all product support needs. A representative takes your call or email, creates a Customer Service Request (CSR) and directs your requests to the Tekelec Technical Assistance Center (TAC). Each CSR includes an individual tracking number. Together with TAC Engineers, the representative will help you resolve your request.

The Customer Care Center is available 24 hours a day, 7 days a week, 365 days a year, and is linked to TAC Engineers around the globe.

Tekelec TAC Engineers are available to provide solutions to your technical questions and issues 7 days a week, 24 hours a day. After a CSR is issued, the TAC Engineer determines the classification of the trouble. If a critical problem exists, emergency procedures are initiated. If the problem is not critical, normal support procedures apply. A primary Technical Engineer is assigned to work on the CSR and provide a solution to the problem. The CSR is closed when the problem is resolved.

Tekelec Technical Assistance Centers are located around the globe in the following locations:

Tekelec - Global

Email (All Regions): support@tekelec.com

- **USA and Canada**

Phone:

1-888-FOR-TKLC or 1-888-367-8552 (toll-free, within continental USA and Canada)

1-919-460-2150 (outside continental USA and Canada)

TAC Regional Support Office Hours:

8:00 a.m. through 5:00 p.m. (GMT minus 5 hours), Monday through Friday, excluding holidays

- **Central and Latin America (CALA)**

Phone:

USA access code +1-800-658-5454, then 1-888-FOR-TKLC or 1-888-367-8552 (toll-free)

TAC Regional Support Office Hours (except Brazil):

10:00 a.m. through 7:00 p.m. (GMT minus 6 hours), Monday through Friday, excluding holidays

- **Argentina**

Phone:

0-800-555-5246 (toll-free)

- **Brazil**

Phone:

0-800-891-4341 (toll-free)

TAC Regional Support Office Hours:

8:30 a.m. through 6:30 p.m. (GMT minus 3 hours), Monday through Friday, excluding holidays

- **Chile**

Phone:

1230-020-555-5468

- **Columbia**

Phone:

01-800-912-0537

- **Dominican Republic**

Phone:

1-888-367-8552

- **Mexico**

Phone:

001-888-367-8552

- **Peru**

Phone:

0800-53-087

- **Puerto Rico**

Phone:

1-888-367-8552 (1-888-FOR-TKLC)

- **Venezuela**

Phone:

0800-176-6497

- **Europe, Middle East, and Africa**

Regional Office Hours:

8:30 a.m. through 5:00 p.m. (GMT), Monday through Friday, excluding holidays

- **Signaling**

Phone:

+44 1784 467 804 (within UK)

- **Software Solutions**

Phone:

+33 3 89 33 54 00

- **Asia**

- **India**

Phone:

+91 124 436 8552 or +91 124 436 8553

TAC Regional Support Office Hours:

10:00 a.m. through 7:00 p.m. (GMT plus 5 1/2 hours), Monday through Saturday, excluding holidays

- **Singapore**

Phone:

+65 6796 2288

TAC Regional Support Office Hours:

9:00 a.m. through 6:00 p.m. (GMT plus 8 hours), Monday through Friday, excluding holidays

Emergency Response

In the event of a critical service situation, emergency response is offered by the Tekelec Customer Care Center 24 hours a day, 7 days a week. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

A critical situation is defined as a problem with an EAGLE 5 ISS that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical problems affect service and/or system operation resulting in:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with the Tekelec Customer Care Center.

Locate Product Documentation on the Customer Support Site

Access to Tekelec's Customer Support site is restricted to current Tekelec customers only. This section describes how to log into the Tekelec Customer Support site and locate a document. Viewing the document requires Adobe Acrobat Reader, which can be downloaded at www.adobe.com.

1. Log into the [Tekelec Customer Support](#) site.

Note: If you have not registered for this new site, click the **Register Here** link. Have your customer number available. The response time for registration requests is 24 to 48 hours.

2. Click the **Product Support** tab.
3. Use the Search field to locate a document by its part number, release number, document name, or document type. The Search field accepts both full and partial entries.
4. Click a subject folder to browse through a list of related files.
5. To download a file to your location, right-click the file name and select **Save Target As**.

Chapter 2

Command Rejected Messages

This chapter contains the error messages generated by the commands used in the EAGLE 5 Integrated Signaling System (ISS).

Introduction

This chapter contains the command rejected error messages generated by the commands used on the EAGLE 5 ISS. The following items make up each description of the error message:

- The error message generated by the EAGLE 5 ISS.
- A list of the commands that can generate the error message. Note that where such a list would be extensive, only a representative sample of commands is provided.
- A brief definition of the error message.
- The actions needed to resolve the error condition or to make sure that the error message does not appear when the command is executed again.

The commands that generate the error messages in this document are described in the *Commands Manual*.

Message Listing and Description

Command rejected messages are listed below in numerical order.

E2001 Cmd Rej: Undefined msg#

Commands Used: `chg-cmd`, `rtrv-cmd`

The `cmd` parameter value must be a valid system command.

Recovery

Re-enter the command specifying a valid system command.

Refer to the *Commands Manual* for additional information regarding valid format, parameters, and syntax for these commands.

E2002 Cmd Rej: Authority Violation

Commands Used: `all commands`

You cannot enter a command at a system terminal if you have not logged on to the EAGLE 5 ISS, or if your user ID does not have the authorization to access the command class for the command you tried to enter.

Recovery

1. Log on to the EAGLE 5 ISS.
Enter the `logon:uid=<user id>` command and then enter your password.

2. If after logging on, you are still unable to enter the command, contact your site system administrator to obtain user command access privileges to the EAGLE 5 ISS.

E2003 Cmd Rej: Terminal Authority Violation

Commands Used: all commands

You cannot enter a command at a terminal that is not authorized for that EAGLE 5 ISS command class.

Recovery

Perform one of the following:

- Re-enter the command at another terminal that is authorized for that EAGLE 5 ISS command class.
- Contact the system administrator to discuss EAGLE 5 ISS terminal command access privileges for the terminal you used to enter the command originally.
- If you have system administration authority, change the privileges for the terminal.

Enter the `chg-secu-trm` command.

Note:

You cannot issue this command on the target terminal.

E2004 Cmd Rej: Keyboard is locked. Enter UNLOCK command

Commands Used: all commands

The keyboard for the terminal was locked using the `lock` command.

Recovery

Unlock the keyboard. Enter the `unlock` command. Anyone attempting to use the keyboard will be prompted to enter the password of the currently logged-on user.

E2005 Cmd Rej: Argument frame overflow

Commands Used: all commands

You entered a command in which the frame for the argument detected an overflow condition. Re-enter the command specifying the correct format for the command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2006 Cmd Rej: Missing parameter block separator

Commands Used: All commands that have parameters

You specified an incorrect block separator. To separate multiple parameter blocks use a colon (:).

Recovery

Re-enter the command specifying a colon (:) between the input values.

Refer to the *Commands Manual* for additional information regarding the command syntax.

E2007 Cmd Rej: Too many errors in this command

Commands Used: All commands

You entered a command, in which too many errors have been detected to allow continued processing. Re-enter the command specifying the correct format for the command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual..

E2008 Cmd Rej: Missing command identifier

Commands Used: All commands

You entered a command without specifying a keyword. Keywords identify the principal action to be performed by the system and consist of one to three words. In the following example, `dact-slk` is the keyword: `dact-slk:loc=1101:port=a`

Recovery

Re-enter the command specifying a keyword.

Refer to the *Commands Manual* for information regarding the correct keyword.

E2009 Cmd Rej: Missing modifier separator

Commands Used: All commands that have parameters

You specified an incorrect modifier separator. Use a hyphen (-) to separate multiple values within a parameter block.

Recovery

Re-enter the command specifying a hyphen (-) between the input values.

Refer to the *Commands Manual* for additional information regarding command syntax.

E2010 Cmd Rej: Unrecognized command

Commands Used: All commands

The EAGLE 5 ISS does not recognize the command that was entered.

Recovery

1. Verify that the command was typed correctly.
Refer to the *Commands Manual* for additional information regarding the correct keyword.
2. Make any necessary corrections, then re-enter the command.

E2011 Cmd Rej: Missing mandatory parameter - <parm>

Commands Used: all commands

A parameter value that is required for the command is missing.

Recovery

Re-enter the command specifying a valid mandatory command parameter.

Refer to the *Commands Manual* for valid parameter values for this command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2012 Cmd Rej: Cannot specify ALL=YES when command given

Commands Used: all commands

You attempted to run the command specifying the **all=yes** parameter, which is invalid for the command.

Recovery

Re-enter the command that generated this error message specifying an appropriate value for the **all** parameter.

Refer to the *Commands Manual* for detailed information about the use of the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2013 Cmd Rej: Missing argument assignment operator

Commands Used: all commands

The command you entered requires an argument assignment operator. Use an equal sign (=) to assign arguments.

Recovery

Re-enter the command specifying the assignment parameter (=) properly positioned.

Refer to the *Commands Manual* for additional information regarding the proper use of argument assignment operators for the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2014 Cmd Rej: Unrecognized parameter identifier

Commands Used: rtrv-clkopts

No parameters can be specified with this command.

Recovery

1. Re-enter the command without specifying any parameters.
Refer to the *Commands Manual* for information regarding the correct command syntax.
2. If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2015 Cmd Rej: Missing parameter identifier

Commands Used: All commands that have parameters

You specified a parameter without an identifier that the EAGLE 5 ISS requires.

Recovery

1. Verify that you have entered all parameters correctly.
Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

2. Make the necessary corrections and re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2016 Cmd Rej: <parm_desc> is out of range - <parm>

Commands Used: all commands

You entered a parameter value that is out of range for this command.

Note: The `flash-card` command cannot be used to load flash images for HMUX or HIPR cards. Use the `init-flash` command.

Recovery

Re-enter the command specifying a valid value for this command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2017 Cmd Rej: <parm_desc> is out of range, <min>...<max> - <parm>

Commands Used: all commands

The parameter is out of range of the minimum and maximum values allowed for this command parameter.

Note: For the `enable-ctrl-feat` and `chg-ctrl-feat` commands, the value specified for the **partnum** parameter must consist of 9 digits, without any dashes. The first three digits are **893**. The next six values are numeric (**0...9**).

Recovery

Re-enter the command specifying a valid value for the parameter. Refer to the *Commands Manual* and to the Feature Manual for the feature of interest for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2018 Cmd Rej: <parm_desc> is out of range, <min>...<max>, '<char>' - <parm>

Commands Used: all commands

The specified value is outside the range of the allowed minimum and maximum values or valid characters for the command parameter.

Recovery

Re-enter the command and specify a valid value or character for the command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2019 Cmd Rej: <parm_desc> is out of range, <min>...<max>, '<char>', '<char>' - <parm>

Commands Used: all commands

The specified value is outside the range of the allowed minimum and maximum values and characters for the command parameter.

Recovery

Re-enter the command specifying a valid value or character for the command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2020 Cmd Rej: Table copy command already in process

Commands Used: copy-meas

You attempted to enter a command that had already been entered, and was already running.

Recovery

1. Wait for the command to finish running.
2. If the command does not finish running within five minutes, call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Note: Under ideal circumstances with minimum system activity, this command requires at least one minute to run.

E2021 Cmd Rej: Invalid source table

You attempted to run this command specifying an invalid syntax assigned to the source table parameter.

Recovery

Re-enter the command that generated this error message specifying the correct syntax for the source table.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2022 Cmd Rej: Invalid destination table

You attempted to run this command specifying an invalid syntax assigned to the destination table parameter.

Recovery

Re-enter the command that generated this error message specifying the correct syntax for the destination table.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2023 Cmd Rej: Invalid OAM drive

You attempted to run this command specifying an invalid syntax assigned to the Operations, Administration and Maintenance (OAM) parameter.

Recovery

Re-enter the command that generated this error message specifying the correct syntax for the OAM drive.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2024 Cmd Rej: Invalid system

A system error occurred during the execution of a command.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2025 Cmd Rej: Invalid card location

Commands Used: act-lbp, chg-db, dact-lbp, ent-card, ent-trace, rept-stat-rtd, rtrv-data-rtdb, tst-slk

A **loc** parameter was specified that is an invalid type for the command. [Table 2: Conditions that Generate Error Message E2025](#) shows the conditions that cause this error message to be generated for the associated command.

Table 2: Conditions that Generate Error Message E2025

Command	Condition
act-lbp, dact-lbp	The card type must be limds0 , limt1 , or limch (associated with a limt1 card).
chg-db	A value of 1113 or 1115 must be specified for the sloc parameter.
ent-card	A DSM card must be inserted into an odd-numbered card location. The n+1 slot next to the DSM card must be empty, where n is the odd-numbered location (for example, if the DSM is in location 1101, then the 1102 slot must be empty and unprovisioned).
ent-trace	Values 1113 - 1118 cannot be specified for the loc parameter.
rept-stat-rtd	The following card locations are not valid for this command: 1114, 1116, 1117, 1118 (TDM, MDAL cards), and all xy09 and xy10 locations where x is the frame and y is the shelf (HMUX or HIPR cards).
rtrv-data-rtdb	The card location slot must be between 1 and 16 and not 9 or 10. The frame location must be 1xxx, 2xxx, 3xxx, 4xxx, 5xxx, or 6xxx. The shelf location must be 11xx, 12xx, 13xx, 21xx, 22xx, 23xx, 31xx, 32xx, 33xx, 41xx, 42xx, 43xx, 51xx, 52xx, 53xx, or 61xx.
tst-slk	The card type in the specified location must be a TDM or an MDAL.

Recovery

Re-enter the command that generated this error message specifying the correct **loc** parameter value for a location that contains a valid card type for the command.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2026 Cmd Rej: Already logged on

Commands Used: all commands

An attempt was made to log on with a user ID that is already logged on to the system.

Recovery

1. Display the user IDs in the database.
Enter the `rtrv-user` command.
2. Display the users logged on the system.
Enter the `rept-stat-user` command.
3. Re-enter the command specifying a user ID that is shown in the output of step 1 and not shown in the output of step 2.

E2027 Cmd Rej: IP Address requires 4 octets in the range 1 . . . 254 - <parm>

Commands Used: all commands

You have specified an invalid IP address. The specified command parameter has an IP address that does not contain four octets in the required range of 1 through 254.

Recovery

1. Verify the correct IP address containing the allowable range for the four octets.
2. Re-enter the command specifying the correct octet values for the command parameter.
Refer to the *Commands Manual* for the command parameter. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2028 Cmd Rej: Octet 1 is out of range, 1 . . . 223 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 1 of the specified command parameter. The value for the octet must be in the range of 1 through 223.

Recovery

Re-enter the command specifying a first octet value from 1 to 223 for this command parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2029 Cmd Rej: Octet 2 is out of range, 1 . . . 254 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 2 of the specified command parameter. The value for the octet must be in the range of 1 through 254.

Recovery

Re-enter the command specifying a second octet value from 1 to 254 for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2030 Cmd Rej: Octet 3 is out of range, 1 . . . 254 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 3 of the specified command parameter. The value for the octet must be in the range of 1 through 254.

Recovery

Re-enter the command specifying a third octet value from 1 to 254 for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2031 Cmd Rej: Octet 4 is out of range, 1 . . . 254 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 4 of the specified command parameter. The value for the octet must be in the range of 1 through 254.

Recovery

Re-enter the command parameter with a fourth octet value from 1 to 254 for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2032 Cmd Rej: Octet 1 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the first octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the missing first octet.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2033 Cmd Rej: Octet 2 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the second octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address containing the missing second octet.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2034 Cmd Rej: Octet 3 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the third octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the missing third octet.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2035 Cmd Rej: Octet 4 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the fourth octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the missing fourth octet.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2036 Cmd Rej: Too many octets specified, only require 4 - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address that contains more than the required four octets.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the required four octets.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2037 Cmd Rej: Invalid character in IP address - <parm>

Commands Used: all commands

The specified command parameter contains an invalid character in the IP address.

Recovery

1. Verify the correct IP address contains acceptable values for the four octets.

Refer to the *Commands Manual* for additional information regarding valid IP address characters for the specified command parameter.

2. Re-enter the command parameter specifying a valid IP address that contains valid values.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2038 Cmd Rej: <parm_desc> too short, min <min>, max <max>, - <parm>

Commands Used: all commands

You entered a string that is too short and does not contain the minimum number of characters required for this command parameter.

Recovery

Re-enter the command specifying a valid number of characters for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid number of characters for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2039 Cmd Rej: <parm_desc> too long, min <min>, max <max>, - <parm>

Commands Used: all commands

You entered a string that exceeds the maximum number of characters allowed for this command parameter.

For the `chg-gsms-opcode` command, the **opname** parameter value and the **nopname** parameter value must be no more than 8 characters long.

For the `rtrv-stp` command,

- The part number parameter (**partnum**), if specified, may contain no more than 12 characters.
- The GPL type parameter (**gpl**), if specified, may contain no more than 8 characters.

Recovery

Re-enter the command specifying a valid value for this command parameter.

Refer to the *Commands Manual* for detailed information regarding the required number of alphanumeric characters for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2040 Cmd Rej: String pattern nonconformance, alphanumeric - <parm>

Commands Used: all commands

The referenced string pattern is invalid because it does not conform to the required alphanumeric content for the command parameter.

For the `chg-gsms-opcode` command, if the **opname** parameter is specified, the value must be alphanumeric.

Recovery

Re-enter the command specifying a pattern that conforms to the alphanumeric content required for the specified command parameter.

Refer to the *Commands Manual* for detailed information about the use of the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2041 Cmd Rej: String pattern nonconformance, alphabetic - <parm>

Commands Used: all commands

The first character of the translation name must be a letter.

Recovery

Re-enter the command specifying a pattern conforming to the alphabetic content required for the specified command parameter.

Refer to the *Commands Manual* for additional information regarding the detailed information about the use of the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2042 Cmd Rej: String pattern nonconformance, numeric - <parm>

Commands Used: all commands

You entered an invalid referenced string pattern that does not conform to the required numeric content for the command parameter.

Recovery

Re-enter the command specifying a pattern that conforms to the valid numeric characters required for the specified command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2043 Cmd Rej: System error - revert to mandatory in-pattern specification

Commands Used: all commands

An unanticipated system error has been detected. Make a note of this error and the attendant situation.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2044 Cmd Rej: <parm_desc> value is undefined - <parm>

Commands Used: all commands

The entered command is missing a parameter value that is required.

Recovery

Re-enter the command specifying a valid value for each command parameter.

Refer to the *Commands Manual* for additional information regarding valid parameter values for this command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

**E2045 Cmd Rej: <parm_desc> num digits incorrect, min <min> max <max>
- <parm>**

Commands Used: all commands

You entered an invalid number of digits for a parameter value. The values represented by <parm>, <min>, and <max> vary according to the specific command entered. The values represented by <min> and <max> specify the valid minimum and maximum number of digits allowed for the command parameter.

Recovery

Re-enter the command specifying the valid number of digits for this command parameter. Refer to the *Commands Manual* for information on entering the command.

E2046 Cmd Rej: Argument definition error, bad argument type

Commands Used: all commands

An unanticipated system error has been detected. Make a note of this error and the attendant situation.

Recovery

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2047 Cmd Rej: Missing information unit separator

Commands Used: all commands

You failed to specify a required information unit or information unit separator. The correct separator is a hyphen (-) character.

Recovery

Re-enter the command specifying the correct syntax.

Refer to the *Commands Manual* for additional information regarding the valid command syntax that defines the information units and their separators.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2048 Cmd Rej: Unneeded information found

Commands Used: all commands

The command entered contains unnecessary information.

Recovery

Re-enter the command specifying the correct syntax, format and parameters.

Refer to the *Commands Manual* for additional information regarding the correct format, parameters, and syntax for the command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2049 Cmd Rej: Lower bound exceeds upper bound of range - %

Commands Used: all commands

You specified an invalid range because the lower bound value is greater than the upper bound for a range in the cited command parameter.

Recovery

Re-enter the command specifying a valid range for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid range of values for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2050 Cmd Rej: Incorrect information unit, expecting number or range - <parm>

Commands Used: all commands

You supplied an invalid number or range of numbers for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid number or range of numbers.

Refer to the *Commands Manual* for additional information regarding the numbers, or range of numbers, that are valid for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2051 Cmd Rej: Incorrect information unit, expecting number - <parm>

Commands Used: all commands

You supplied an invalid number for a parameter value. The value represented by *<parm>* varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid number.

Refer to the *Commands Manual* for additional information regarding the valid numbers for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2052 Cmd Rej: Incorrect information unit, expecting IP address - *<parm>*

Commands Used: all commands

You supplied an invalid IP address for a parameter value. The value represented by *<parm>* varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid IP address. Refer to the *Commands Manual* for additional information regarding valid IP address values for the command parameter. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2053 Cmd Rej: Incorrect information unit, expecting string - *<parm>*

Commands Used: all commands

You supplied an unrecognized string for a parameter value. The value represented by *<parm>* varies according to the command being entered.

Recovery

Re-enter the command specifying a valid string value.

Refer to the *Commands Manual* for additional information regarding the valid values for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2054 Cmd Rej: Incorrect information unit, expecting mnemonic - *<parm>*

Commands Used: all commands

You supplied an invalid mnemonic for a parameter value. The value represented by *<parm>* varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid parameter value.

Refer to the *Commands Manual* for additional information regarding a valid value for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2055 Cmd Rej: Incorrect information unit, expecting point code - <parm>

Commands Used: all commands

You entered an unrecognized point code for a parameter value. The value represented by <parm> varies according to the command being entered.

Recovery

Re-enter the command specifying a valid point code value.

Refer to the *Commands Manual* for additional information regarding valid values for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2056 Cmd Rej: Incorrect information unit, expecting number or * - <parm>

Commands Used: all commands

You supplied an invalid number or variable for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid number or variable.

Refer to the *Commands Manual* for additional information regarding valid number or variable for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2057 Cmd Rej: Incorrect information unit, translation type - <parm>

Commands Used: all commands

You supplied an incorrect information unit for the translation type. The translation type from <parm> varies according to the specific command entered.

Recovery

1. Press the **F10** key for Help, and see the valid format for the translation type parameter.
2. Re-enter the command specifying a valid translation type format.
Refer to the *Commands Manual* for additional information regarding the translation type format for the command parameter.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2058 Cmd Rej: Incorrect information unit, expecting card location - <parm>

Commands Used: all commands

You supplied an invalid card location for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid card location.

Refer to the *Commands Manual* for additional information regarding the valid card location for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2059 Cmd Rej: <parm_desc> is out of range, <min>...<max> - <parm>

Commands Used: all commands

You entered a value that is out of range of the minimum and maximum values allowed for this command parameter.

Recovery

Re-enter the command specifying a valid value for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid range of values for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2060 Cmd Rej: Lower bound exceeds upper bound of range - <parm>

Commands Used: all commands

You specified an invalid range because the lower bound value is greater than the upper bound for a range in the cited command parameter.

Recovery

Re-enter the command specifying a valid range for this command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2061 Cmd Rej: Incorrect input, expecting number, * or range - <parm>

Commands Used: all commands

You specified an input value that is invalid, because it does not contain a number, variable, or a range of numbers.

Recovery

Re-enter the command specifying valid input values for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid inputs required for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual..

E2062 Cmd Rej: Incorrect information unit, expecting number or none - <parm>

Commands Used: all commands

You specified an information unit that is invalid because it does not contain a number or the string "none" in the command parameter.

Recovery

Re-enter the command specifying information units corrected for this command parameter.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2063 Cmd Rej: Try Double Quoting Parameter with ‘_’

Commands Used: all commands

You specified an underscore character in an unacceptable format.

Recovery

Re-enter the command specifying the underscore character enclosed in double quotes “_”.

Refer to the *Commands Manual* for additional information regarding the correct format for the parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2070 Cmd Rej: IP Address invalid for Address Class

Commands Used: all commands

The specified IP Address is invalid.

Recovery

Re-enter the command specifying a valid IP address.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2071 Cmd Rej: Network Number Invalid

Commands Used: all commands

The specified Network Number is invalid. Valid Network Numbers cannot contain all 0 bits or all 1 bits.

Recovery

Re-enter the command specifying a valid Network Number.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

E2072 Cmd Rej: Host Number Invalid

Commands Used: all commands

The specified Host Number is invalid. Valid Host Numbers cannot contain all 0 bits or all 1 bits.

Recovery

Re-enter the command specifying a valid Host Number.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

E2083 Cmd Rej: GTTSN parameter mustn't be specified

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

If the OBSR feature is enabled or the FLOBR feature is turned on, then the **gttsn** parameter cannot be specified.

Recovery

Re-enter the command without specifying the **gttsn** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2084 Cmd Rej: A-Port or IGM must be turned ON

Commands Used: `ent-srvsel`

The A-Port or IS41 GSM Migration (IGM) feature must be turned on before the **serv=mnps** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. If the A-Port or IGM feature is on, re-enter the `ent-srvsel` command.
3. If neither the A-Port nor the IGM feature is on, one of these features must be enabled and turned on before the **serv=mnps** parameter can be specified in the `ent-srvsel` command.
 - a) Refer to the *Feature Manual - A-Port* for assistance in enabling, turning on, and using the A-Port feature.
 - b) Refer to the *Feature Manual - IS41 GSM Migration* for assistance in enabling, turning on, and using the IGM feature.
 - c) Refer to the *Commands Manual* for a description of the `ent-srvsel` parameters.
4. Re-enter the `ent-srvsel` command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2085 Cmd Rej: A-Port, G-Port or IGM must be turned ON

Commands Used: `chg-srvsel`, `enable-ctrl-feat`, `ent-srvsel`

For the `enable-ctrl-feat` command, the A-Port, G-Port, or IGM feature must be on before the MNP Circular Route Prevention feature can be enabled.

For the `chg-srvsel` and `ent-srvsel` commands, the A-Port or IGM feature must be turned on, or the A-Port or IGM feature must be enabled and the G-Port feature must be turned on before a value of **mnp** can be specified for the **nserv** or **serv** parameter, respectively.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command. If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable or turn on the desired feature. Refer to the *Feature Manual – A-Port* for information on enabling and turning on the A-Port feature. Refer to the *Feature Manual – G-Port* for information on enabling and turning on the G-Port and IGM features.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if the error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2086 Cmd Rej: GTT must be turned ON for A-Port

Commands Used: `enable-ctrl-feat`

The GTT feature must be turned on before the A-Port feature can be turned on.

Note: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off.

Recovery

1. Determine the status of the GTT feature. Enter the `rtrv-feat` command.
2. If necessary turn on the GTT feature bit. Refer to the *Database Administration Manual - Global Title Translation* for assistance. Refer to the *Feature Manual – A-Port* to enable and turn on the A-Port feature.

E2087 Cmd Rej: GTT must be turned ON for G-Port

Commands Used: `enable-ctrl-feat`

The GTT feature must be turned on before the G-Port feature can be turned on.

Recovery

1. Display the status of the GTT feature. Enter the `rtrv-feat` command.

2. Enable and turn on the features as necessary. Refer to the *Database Administration Manual - Global Title Translation* and to the *Feature Manual - G-Port* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Note: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off.

E2088 Cmd Rej: GTT must be turned ON for IGM

Commands Used: `enable-ctrl-feat`

The GTT feature must be turned on before the IS41-GSM Migration (IGM) feature can be enabled.

Recovery

1. Display the status of the GTT feature. Enter the `rtrv-feat` command.
2. Enable and turn on the features as necessary. Refer to the *Database Administration Manual - Global Title Translation* and to the *Feature Manual - IS41 GSM Migration* for assistance.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2100 Cmd Rej: Card location already equipped

Commands Used: `ent-card`

You cannot add a card to the database that already exists in the database. The specified card location cannot already be provisioned in the database.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
2. Re-enter the `ent-card` command specifying a card location not shown in Step 1.
Refer to Appendix A of the *Commands Manual* for detailed information about cards that use the `ent-card` command.

E2101 Cmd Rej: Card location is unequipped

Commands Used: `act-cdl, act-lbp, blk-slk, chg-bip-fld, chg-ip-card, chg-ip-lnk, chg-lbp, chg-x25-slk, dact-cdl, dact-lbp, dact-slk, dbg-ddb, dlt-lbp, disp-bp, disp-bip, disp-mem, dlt-appl-rtkey, dlt-bp, dlt-card, dlt-dlk, dlt-ip-node, dlt-ip-rte, ent-bp, ent-dlk, ent-ip-node, ent-ip-rte, ent-slk, ent-lbp, inh-slk, init-card, rept-meas, rept-stat-cdl, rept-stat-lfs, rept-stat-tst, rept-stat-slk, rtrv-appl-rtkey, rtrv-card,`

rtrv-dlk, rtrv-ip-card, rtrv-ip-lnk, rtrv-ip-node, rtrv-ip-rte, rtrv-lbp, rtrv-slk, rtrv-x25-slk, set-mem, tst-bip, tst-slk, tst-msg, ublk-slk, unhb-slk

The card location specified by the **loc** or the **rlloc** parameter must be equipped.

To enter the command, a card that is valid for the command must be defined previously in the database for the specified card location. The card that contains the specified signaling link must be equipped in the specified card location.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
2. Verify that the correct card location was specified.
3. Verify that a card is defined in the database for the specified card location.
4. Verify that the card in the specified card location is valid for the command.
Refer to the command description in the *Commands Manual*.
5. Re-enter the command that generated this error message. Specify a valid card location as shown in the output of Step 1.

E2102 Cmd Rej: Failed reading the IMT table

Commands Used: `chg-e1`, `chg-t1`, `chg-x25-slk`, `dlt-card`, `dlt-e1`, `dlt-ip-node`, `dlt-t1`, `ent-card`, `ent-dlk`, `ent-e1`, `ent-ip-node`, `ent-slk`, `ent-t1`, `ent-x25-rte`, `rtrv-e1`, `rtrv-ip-node`, `rtrv-slk`, `rtrv-stp`, `rtrv-t1`, `rtrv-x25-slk`

The IMT table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2103 Cmd Rej: Failed reading the link table

Commands Used: `chg-x25-slk`, `chg-ls`, `dbg-ddb`, `dlt-card`, `dlt-dlk`, `dlt-ip-node`, `dlt-slk`, `ent-dlk`, `ent-ip-node`, `ent-slk`, `rtrv-dlk`, `rtrv-ip-node`, `rtrv-slk`, `rtrv-x25-slk`, `rtrv-ls`

The Link table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2104 Cmd Rej: Failed reading shelf table

Commands Used: `chg-x25-slk`, `dlt-card`, `dlt-ip-node`, `ent-card`, `ent-dlk`,
`ent-ip-node`, `ent-slk`, `ent-x25-rte`, `rtrv-ip-node`, `rtrv-slk`, `rtrv-x25-slk`

The Shelf table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2105 Cmd Rej: Invalid card TYPE and APPL load type combination

Commands Used: `act-upgrade`, `ent-card`

The Dual-Slot DCM card is obsolete for IPGW(x) and IPLiM(x) application. For the `act-upgrade` command, this error indicates an unsupported or obsolete card **type** was found in the system.

For the `ent-card` command, the specified card type (**type**) and application (**appl**) combination cannot be used together.

Recovery

For the `act-upgrade` command, replace the unsupported or obsolete card type was found with a TSM card or better.

Note:

For EAGLE 5 ISS 31.6 and later, replace all ASM cards with TSM cards.

For the `ent-card` command, re-enter the `ent-card` command specifying the correct card **type** and **appl** combination.

Refer to Appendix A of the *Commands Manual* for a list of valid Card Types and Application Types for the `ent-card` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2106 Cmd Rej: Link is in test mode

Commands Used: `act-slk`

This command cannot be entered while the `tst-slk` command is in progress.

Recovery

1. Wait for the signal link test to complete.
2. Re-enter the `act-slk` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2107 Cmd Rej: Link assigned to card

Commands Used: `dlt-card`

The specified card location has a signaling link or a TCP/IP data link assigned to it. The card cannot be deleted from the database until the signaling link or the TCP/IP data link is deleted from the database. Use the appropriate recovery procedures listed below to delete the signaling link or the TCP/IP data link from the database.

Recovery - SS7 links

1. Display the signaling links in the database. Enter the `rtrv-slk` command.
2. Delete the signaling link from the database. Enter the `dlt-slk` command specifying the card location that generated this error message along with the port of the signaling link, both shown in the output of Step 1, and with the `force=yes` parameter.
3. Re-enter the `dlt-card` command that generated this error message to delete the card from the database.

Recovery - TCP/IP links

1. Display the TCP/IP data links in the database.
Enter the `rtrv-dlk` command.
2. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
3. From the outputs from Steps 1 and 2, determine if the card location specified has a TCP/IP node and TCP/IP data link assigned to it.
4. Delete the TCP/IP node from the database.
Enter the `dlt-ip-node` command specifying the card location used in Step 3.
5. Delete the TCP/IP data link from the database.
Enter the `dlt-dlk` command specifying the card location used in Step 3.

Note:

An IPLNK entry must be provisioned before an IPHOST entry with `type=local` can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

6. Re-enter the `dlt-card` command that generated this error message, to delete the card from the database.

E2108 Cmd Rej: Shelf location not equipped

Commands Used: `ent-card`

The shelf location, shown in the card address, could not be found in the database. The specified shelf location must be provisioned and present in the frame.

Recovery

1. Display all shelves in the system.
Enter the `rtrv-shlf` command.
2. Re-enter the `ent-card` command specifying a card address that is in one the shelf locations displayed in Step 1.

E2109 Cmd Rej: Database maintenance is required [or] Cmd Rej: Database repair is required

Commands Used: `chg-dstn`, `chg-feat`, `chg-ls`, `chg-rte`, `chg-x25-dstn`, `chg-x25-rte`, `chg-x25-slk`, `dlt-card`, `dlt-dlk`, `dlt-dstn`, `dlt-ip-node`, `dlt-ls`, `dlt-rte`, `dlt-slk`, `dlt-x25-dstn`, `dlt-x25-rte`, `ent-card`, `ent-dlk`, `ent-dstn`, `ent-ip-node`, `ent-ls`, `ent-rte`, `ent-slk`, `ent-x25-dstn`, `ent-x25-rte`, `rtrv-ip-node`

The command failed because the system detects that:

- The database is incoherent (the command requires that the database be coherent).
- The levels of source databases, during a duplex backup or repair, are not identical on the active and standby OAM fixed disks.
- The database is corrupt. An audit has detected a mismatched checksum in a subset.

Recovery

1. Determine the status of the database.
Enter the `rept-stat-db` command.
2. If the status of the database is corrupt, determine which subset is corrupt.
Enter the `aud-data:display=all` command.
3. If the database is either incoherent or corrupt, find the conditions shown in the output of Step 1 in the following list, and execute the appropriate command.
 - a) If the current partition of the fixed disk is coherent and the backup partition of the fixed disk is incoherent, enter the `chg-db:action=backup:dest=fixed` command.
 - b) If the current partition of the fixed disk is coherent and the database on the removable cartridge is incoherent, enter the `chg-db:action=backup:dest=remove` command.
 - c) If the backup partition of the fixed disk is coherent and the current partition of the fixed disk is incoherent.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

- d) If the database on the removable cartridge is coherent and the current partition of the fixed disk is incoherent.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

- e) If the backup and current partitions on the active fixed disk are coherent and the backup and current partitions on the standby fixed disk are incoherent, use the `chg-db:action=repair` command.
4. If you are performing a duplex backup or restore, verify that the level of the source databases residing on both the active and standby OAM fixed disks are identical.

Note:

The error message text is altered for this condition and says "Database repair is required." When you have performed the required repair to make both databases identical, continue with Step 5.

5. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2110 Cmd Rej: Unable to access DB level

Commands Used: `chg-dstn`, `chg-ls`, `chg-rte`, `chg-x25-dstn`, `chg-x25-rte`, `chg-x25-slk`, `dlt-card`, `dlt-dlk`, `dlt-dstn`, `dlt-ip-node`, `dlt-ls`, `dlt-rte`, `dlt-slk`, `dlt-x25-dstn`, `dlt-x25-rte`, `ent-card`, `ent-dlk`, `ent-dstn`, `ent-ip-node`, `ent-ls`, `ent-rte`, `ent-slk`, `ent-x25-dstn`, `ent-x25-rte`, `rtrv-ip-node`

A severe system fault has occurred and the command was rejected.

Recovery

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2111 Cmd Rej: Database consistency violation - maintenance required

Commands Used: `rtrv-rte`

A database inconsistency has been detected.

Recovery

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2112 Cmd Rej: At least one parameter must be changed

Commands Used: `chg-ainpopts`, `chg-gta`, `chg-gtt`, `chg-inpopts`, `chg-map`, `chg-meas`, `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-dpc`, `chg-scr-opc`, `chg-scrset`, `chg-scr-sio`, `chg-scr-tt`

The command was entered without at least one optional parameter specified, or with an invalid optional parameter specified. Some commands require that you specify at least one optional parameter.

Recovery

Re-enter the command specifying at least one valid optional parameter.

Refer to the *Commands Manual* for additional information regarding the command and the required parameters.

E2113 Cmd Rej: CLI cannot be specified without Point Code

Commands Used: `chg-ls`

You cannot invoke the `cli` feature without specifying the point code value.

Parameters `nfeccli` and `nfepc` are optional, but one may not be specified without the other.

Recovery

Re-enter the `chg-ls` command that generated this error message specifying the correct point code.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2114 Cmd Rej: If NDIGITS = 0 then PREFIX parameter is invalid

You do not need to specify the `prefix` parameter if the value specified for the `ndigits` parameter is 0 (`ndigits=0`).

Recovery

Re-enter the command that generated this error message specifying `ndigits=0` and without specifying the `prefix` parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2115 Cmd Rej: NDIGITS parameter mandatory with PREFIX parameter

You cannot specify the `prefix` parameter without specifying the `ndigits` parameter.

Recovery

Re-enter the command that generated this error message specifying both the **prefix** and **ndigits** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2116 Cmd Rej: Number of PREFIX digits cannot exceed NDIGITS parameter

You cannot specify a **prefix** parameter that contains more digits than the **ndigits** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct number of digits for the **ndigits** and **prefix** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2117 Cmd Rej: PREFIX parameter mandatory with NDIGITS parameter

You specified the **ndigits** parameter, but failed to include the **prefix** parameter that is required with it.

Recovery

Re-enter the command that generated this error message specifying the **prefix** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2118 Cmd Rej: Invalid link speed combination within linkset

Commands Used: `ent-slk`

A link cannot be added to a linkset with a transmission rate that is invalid for the linkset.

Low speed links running at 4800 bps, 9600 bps and 19,200 bps must be in a linkset that contains only that transmission rate. All other links running rates other than those three speeds can be mixed within a linkset. Mixing of high speed links and low speed links in a linkset is supported for migration purposes and is not recommended for standard provisioning.

Recovery - For E1/T1 links:

1. Verify the transmission rate of the links in the linkset.

Enter the command `rttrv-ls: lsn=(the linkset the link is being added to)`. The transmission rate of the link is shown in the `BPS` field of the output.

2. Verify that the links in the linkset are running at **56000** bps or **64000** bps.
An E1 link can run at **56000** bps or **64000** bps in a linkset with other links running at **56000** bps and/or **64000** bps. A T1 link can run at **56000** bps in a linkset with other links running at **56000** bps and/or **64000** bps.
3. Re-enter the `ent-slk` command specifying a valid transmission rate for the link that is being added to the linkset.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - For V.35 linksets:

4. Verify the transmission rate of the links in the linkset.
Enter the command `rtrv-ls:lsn=` (the linkset the link is being added to). The transmission rate of the link is shown in the `BPS` field of the output.
5. Re-enter the `ent-slk` command specifying the transmission rate used by the other V.35 links in the linkset, as shown in the output of Step 1.

Note:

If any of the links in the linkset are DS0 or DSCS links, you cannot set the transmission rate for them, and they default to **56000** bps. Therefore, if any of the V.35 links in this linkset are set to **64000** bps, you must first delete those V.35 links with the `dlr-slk` command and re-enter them with the `ent-slk` command specifying a value of `bps=56000`.

E2119 Cmd Rej: BPS must be 56000 or 64000

Commands Used: `ent-slk`

If the card application is `ss7ansi` or `ccs7itu`, then a value of **56000** or **64000**, respectively, must be specified for the `bps` parameter. If SE-HSL or ST-HSL-A cards are used, then a value of **1984000** or **1536000**, respectively, must be specified for the `bps` parameter.

Recovery

Re-enter the `ent-slk` command specifying the card location (`loc`) that generated this error message, and the correct value for the `bps` parameter.

E2120 Cmd Rej: BPS must be 56000 for card type

Commands Used: `ent-slk`

You specified an invalid bits-per-second (`bps`) rate for the card type. If the card type is either `limds0` (includes the multi-port LIM), `limt1`, or `limocu`, specify a `bps` parameter value of **56000**.

Recovery

Re-enter the `ent-slk` command specifying the correct `bps` parameter value to reflect the true bits-per-second rate.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2121 Cmd Rej: PCRN1 and PCRN2 parameters are invalid if ECM=BASIC

Commands Used: `ent-slk`

The `pcrn1` and `pcrn2` parameters cannot be specified if the `ecm` parameter is specified as `basic` (`ecm=basic`). The `pcrn1` and `pcrn2` parameters can be specified `ss7ansi` and `ccs7itu` applications only if the `ecm` parameter is specified as `pcr` (`ecm=pcr`).

Recovery

Perform one of the following:

- Re-enter the `ent-slk` command specifying the `ecm=pcr` parameter, and the `pcrn1` and `pcrn2` parameters.
- Re-enter the `ent-slk` command specifying the `ecm=basic` parameter, without specifying the `pcrn1` and the `pcrn2` parameters.

E2122 Cmd Rej: Failed reading linkset table

Commands Used: `chg-dstn`, `chg-gtttsel`, `chg-ls`, `chg-rte`, `chg-rtx`, `dlt-dstn`, `dlt-ls`, `dlt-rte`, `dlt-rtx`, `dlt-slk`, `ent-gtttsel`, `ent-ls`, `ent-rte`, `ent-rtx`, `ent-slk`, `rtrv-gtwy-acthresh`, `rtrv-gtttsel`, `rtrv-ls`, `rtrv-rte`, `rtrv-rtx`, `rtrv-slk`, `set-gtwy-acthresh`

The Linkset table is corrupt or cannot be found.

Recovery

1. Re-enter the command that generated this error message.
2. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2124 Cmd Rej: All links of LSN must use same error correction method

Commands Used: `ent-slk`

The same value must be specified for the `ecm` parameter for all links in a linkset.

Recovery

1. Verify the error correction method used by the signaling links in the linkset specified by the `lsn` parameter that generated this error message.
Enter the `rtrv-ls:lsn=` command specifying the linkset name that generated this error message. The error correction method of the signaling links is shown in the `ECM` field of the output.

2. Re-enter the `ent-slk` command that generated this error message specifying a value for the **ecm** parameter that is the same as the error correction method shown in the **ECM** field of the `rtrv-ls` command output in Step 1.

E2125 Cmd Rej: Links on specified linkset are in-service

Commands Used: `chg-ls`

If one or more links in a specified linkset are in service, the **rcontext** parameter cannot be specified. You cannot change a linkset that still has signaling links assigned to it.

You cannot specify the **apc/apca/apci/apcn/apcn24** parameters if one or more of the links in the specified linkset are in service.

You cannot specify the **ppc/ppca/ppci/ppcn/ppcn24** parameters if one or more of the links in the specified linkset are in service.

You cannot change the linkset type if links in the linkset are in service.

Recovery

1. Display the current linkset configuration. Enter the `rtrv-ls` command specifying the linkset name.
2. Deactivate all links in the linkset. Enter the `dact-slk` command.
3. Confirm the link status is Out-of-Service-Maintenance-Disabled (OOS-MT-DSBLD). Enter the `rept-stat-ls` command specifying the linkset name.
4. Delete all links in the associated linkset. Enter the `dlr-slk` command.
5. Re-enter the `chg-ls` command that generated this error message.

E2126 Cmd Rej: Invalid linkset type for card

Commands Used: `ent-slk`

The linkset adjacent point code (APC) type must be the same as the card application type (ANSI or ITU).

- IPGS-M2PA linksets cannot contain IPGWx and IPGS-M3UA link types during transition. After the linkset is transitioned to IPGS-M2PA, only IPGS-M2PA and IPLIM links can be added to the linkset.
- IPGS-M3UA linksets cannot contain SS7IPGW, IPGWI, and IPGHC link types during transition. After the linkset is transitioned to IPGS-M3UA, only IPGS-M3UA links can be added to the linkset.

Recovery

1. Verify the card applications.
Enter the `rtrv-card` command.
2. Verify the linksets and their APCs.
Enter the `rtrv-ls` command.

3. Verify the domains of the APCs shown in Step 2.
Enter the `rtrv-dstn` command.
4. Using the outputs of Steps 1, 2, and 3 as a guide, re-enter the `ent-slk` command, specifying a card location whose application matches the domain of the APC assigned to the linkset that is to contain the signaling link.
Refer to the *Commands Manual* for more information about the `ent-slk` command. If this error message occurs again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2127 Cmd Rej: L2 timer not valid for the signaling link type

Commands Used: `ent-slk`

The L2 timer range must be valid for the type of signaling link being provisioned. Refer to the command description in the *Commands Manual* for the valid ranges.

The signaling link type is determined by the APC of the linkset that the signaling link is being added to, and by the application of the card that the signaling link is being assigned to.

Recovery

1. Verify the APC of the specified linkset that generated this error message.
Enter the `rtrv-ls` command. The APC of the linkset is shown in the `APCA`, `APCI`, or `APCN` fields in the `rtrv-ls` command output.
2. Verify the application assigned to the card that generated this error message.
Enter the `rtrv-card:loc=` command, specifying the card location. The card's application is shown in the `APPL` field in the `rtrv-card` command output.
3. Re-enter the command using a valid L2 Timer Range.

E2128 Cmd Rej: Linkset assigned to route must have at least one link

Commands Used: `dlt-slk,ent-rte`

The specified signaling link is the last link in a linkset that is assigned to a route, and the `force=yes` parameter was not specified. The last link in a linkset that is assigned to a route cannot be deleted, unless the `force=yes` parameter is specified. The linkset must be defined with at least one link.

Recovery

Re-enter the `dlt-slk` command specifying the `force=yes` parameter.

E2129 Cmd Rej: CDPNPFX must be specified

Commands Used: `chg-inpopts`

You entered a value for the **ncdnpfx** or **dltprfx** parameter (or both), and did not specify the **cdnpfx** parameter.

Recovery

1. To change a Called Party Number Prefix, re-enter the `chg-inopts` command specifying the existing prefix in the **cdnpfx** parameter and the new prefix in the **ncdnpfx** parameter.
2. To delete a Called Party Number Prefix, re-enter the `chg-inopts` command specifying the existing prefix in the **cdnpfx** parameter and **ncdnpfx=none**.

E2130 Cmd Rej: Maximum number of links are assigned to this linkset

Commands Used: `ent-slk`

Links must be available in the linkset that is specified by the **lsn** parameter. To add the new signaling link, first delete a current signaling link, then add the new one.

Recovery

1. Display the signaling links in the linkset.
Enter the `rtrv-ls` command specifying the linkset name (**lsn**) that generated this error message.
2. Delete an existing signaling link.
Enter the `dlt-slk` command.
3. Re-enter the `ent-slk` command that generated this error message.

E2131 Cmd Rej: Parameters not valid for card type

Commands Used: `chg-clkopts`, `ent-dlk`, `ent-slk`, `inh-alm`, `unh-alm`, `rept-stat-slk`

The parameters specified for the command must be valid for the type of card in the specified card location. Refer to the *Commands Manual* for a list of valid card types for the command.

For the `chg-clkopts` command, the parameters entered are not compatible with the card where the clock resides.

Recovery

1. Verify the card type and card application. Enter the `rtrv-card` command specifying the card location that generated this error message. The card type is shown in the *TYPE* field. The card's application is shown in the *APPL* field.
2. Use the output of Step 1 and the command description in the *Commands Manual* to determine the parameters allowed for each card type and application.
3. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2132 Cmd Rej: The specified SLC is in use

Commands Used: `ent-slk`

The specified signaling link code (SLC) is already being used by another signaling link in the linkset. The SLC must be unique in the linkset.

Recovery

1. Display the signaling links in the linkset that generated this error message.
Enter the `rtrv-ls` command specifying the name of the linkset (`lsn`).
2. Re-enter the `ent-slk` command specifying a value for the SLC that is not displayed in the output of Step 1.

E2133 Cmd Rej: There is a link already assigned to this port

Commands Used: `ent-slk`

A link is already assigned to the specified port.

Recovery

1. Display the cards in the database.
Enter the `rtrv-card` command.
2. Display the signaling links in the database.
Enter the `rtrv-slk` command.
3. Re-enter the `ent-slk` command specifying a card location and port not shown in the output of Step 2, and with a card type shown in the output of Step 1.
The card types are shown in the `TYPE` field in the `rtrv-card` output.

E2136 Cmd Rej: At least one optional parameter is required

Commands Used: `chg-acg-noc`, `chg-assoc`, `chg-atinpopts`, `chg-atm-lps`, `chg-attr-secu-log`, `chg-cmd`, `chg-cmdclass`, `chg-ctrl-feat`, `chg-dstn`, `chg-el`, `chg-eisopts`, `chg-feat`, `chg-ftp-serv`, `chg-gpl`, `chg-gsm-msg`, `chg-gsmmap-scrn`, `chg-gsmopts`, `chg-gsmsmsopts`, `chg-gsms-opcode`, `chg-gta`, `chg-gtt`, `chg-gttset`, `chg-gws-actset`, `chg-gws-redirect`, `chg-ip-card`, `chg-ip-lnk`, `chg-is41-msg`, `chg-is41opts`, `chg-l2t`, `chg-l3t`, `chg-isup-msg`, `chg-lbp`, `chg-lnp-serv`, `chg-loopset`, `chg-ls`, `chg-lsopts`, `chg-m2pa-tset`, `chg-map`, `chg-mrn`, `chg-netopts`, `chg-oap-config`, `chg-ppsopts`, `chg-rte`, `chg-sccp-msg`, `chg-sccp-serv`, `chg-sccpopts`, `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-isup`, `chg-scrset`, `chg-scr-tt`, `chg-scr-opc`, `chg-scr-sio`, `chg-secu-dflt`, `chg-secu-trm`, `chg-sg-opts`, `chg-sid`, `chg-ss7opts`, `chg-stpopts`, `chg-tl`,

chg-tatr-msg, chg-tatropts, chg-tifopts, chg-ttr-msg, chg-user, chk-unref-ent, chg-vflx-cd, chg-vflx-opts, chg-vflx-rn, chg-vflx-vmsid, dlt-lbp, dlt-mrn, dlt-rte, dlt-scr-blkdpc, ent-mrn, ent-scr-blkdpc, ent-scr-blkopc, ent-sid, ent-trace, rtrv-data-rtddb, rtrv-gtwy-acthresh, rtrv-gserv-data, set-gtwy-acthresh, set-uim-acthresh

At least one optional parameter must be specified in the command.

Recovery

Re-enter the command with at least one valid optional parameter specified.

Refer to the *Commands Manual* for descriptions of the valid optional parameters that are available for the command.

E2137 Cmd Rej: Port must be inhibited to change comm. attributes

Commands Used: chg-trm

The terminal port must be inhibited (see the `inh-trm` command) before the **type**, **baud**, **prty**, **sb**, and **fc** parameters can be changed.

The **all**, **traf**, **link**, **sa**, **db**, **sys**, **uimrd**, and **pu** parameters can be changed on any terminal, including the one in use, regardless of the port status (inhibited or allowed).

Recovery

1. Remove the terminal port from service.
Enter the `inh-trm` command.
2. Re-enter the `chg-trm` command, specifying the communication parameters to change.
3. Return the terminal port to service.
Enter the `alw-trm` command.

E2138 Cmd Rej: Failed reading terminal table

Commands Used: chg-trm

The Terminal table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2139 Cmd Rej: Invalid BAUD value specified

Commands Used: `chg-trm`

The value specified for the **baud** parameter was outside the allowed range.

Recovery

Re-enter the `chg-trm` command specifying one of the following values for the **baud** parameter: **2400**, **4800**, **9600**, or **19200**.

E2140 Cmd Rej: Invalid PRTY value specified

Commands Used: `chg-trm`

Only values of **none**, **even**, or **odd** can be specified for the **prty** parameter.

Recovery

Re-enter the `chg-trm` command, specifying a value for the **prty** parameter of **none**, **even**, or **odd**. If the **type=vt320** parameter is specified, then the **none** value cannot be specified.

E2141 Cmd Rej: Invalid FC value specified

Commands Used: `chg-trm`

The valid values for the **fc** parameter are **hw** (hardware), **sw** (software), **both** (hardware and software), and **none** (no flow control).

Recovery

Re-enter the `chg-trm` command, specifying a value for the **fc** parameter that is equal to the flow control value required for the hardware used on the port.

E2142 Cmd Rej: TYPE = VT320 and PRTY=NONE combination not allowed

Commands Used: `chg-trm`

The command attempted to set the **type=vt320** and the **prty=none**. A VT320 terminal does not support seven-bit data bytes and no parity.

Recovery

Perform one of the following:

- Re-enter the `chg-trm` command specifying the **type=vt320** and the **prty=odd** or **even**.

OR

- Re-enter the `chg-trm` command specifying the `type=printer` or `ksr` and the `prty= none, even, or odd`.

E2143 Cmd Rej: The terminal state request was unanswered

Commands Used: `chg-trm`

There is a problem with the OAM card, the TDM card, or the extended bus interface (EBI) between the two. This problem is preventing the system from determining what state the specified terminal or port is in. The terminal or port attributes cannot be changed until the state of the terminal or port can be determined. This error message follows other error messages or system troubles.

Recovery

1. Remove the terminal from service.
Enter the `inh-trm` command.
2. Re-enter the `chg-trm` command.
3. If the `chg-trm` command is rejected, call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
4. If the `chg-trm` command is accepted, return the terminal to service.
Enter the `alw-trm` command.

E2144 Cmd Rej: Location invalid for hardware configuration

Commands Used: `act-lpo`, `act-slk`, `alw-card`, `blk-slk`, `canc-lpo`, `canc-slk`, `copy-fta`, `copy-gpl`, `dact-slk`, `disp-disk-dir`, `disp-tbl`, `ent-card`, `ent-ip-rte`, `inh-card`, `inh-slk`, `pass`, `rept-stat-card`, `rept-stat-db`, `rept-stat-rtd`, `rept-x25-meas`, `rmv-card`, `rtrv-card`, `rst-card`, `rtrv-ip-rte`, `set-tbl`, `tst-slk`, `ublk-slk`, `unhb-slk`

The specified card location is not defined in the database.

The card must be equipped and must be one of the following cards:

- An MDAL card for the 1117 location
- An E5-MCAP card for the 1113 and 1115 locations
- A TDM or E5-TDM card for the 1114 and 1116 locations
- A LIM card running the `ss7ansi` or `ccs7itu` application
- A LIM-ATM card running the `atmansi` application
- An SSEDCCM card or E5-ENET card running the `ss7ipgw`, `ipgwi`, `iplim`, or `iplimi` application
- An E5-ENET card running the `ipsg` application
- An E1/T1 MIM or HC MIM or E5-E1T1 card running the `ss7ansi` or `ccs7itu` application
- An E1-ATM card running the `atmitu` application
- An E5-ATM card running the `atmansi` or `atmitu` application

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
2. Re-enter the command, specifying a valid card location. Refer to the *Commands Manual* for more information about the card requirements for each command.

E2145 Cmd Rej: Failed reading MAS configuration table

Commands Used: `chg-gtw-stp`, `chg-ls`, `chg-sid`, `chg-stpopts`, `dlt-dstn`, `ent-card`, `ent-dstn`, `ent-ls`, `init-oap`, `rtrv-feat`, `rtrv-gtw-stp`, `rtrv-sid`, `rtrv-stpopts`

The MAS Configuration table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2146 Cmd Rej: BPS value not supported

Commands Used: `ent-slk`

The **bps** parameter was specified with a value that is not valid. Refer to the command description in the *Commands Manual* for a list of valid values for the **bps** parameter.

Recovery

1. Verify that the command was entered correctly.
2. Re-enter the `ent-slk` command.
3. If the command was entered correctly,
 - a) Verify the transmission rate of the links in the linkset that you wish to add the link to.
Enter the `rtrv-slk` command.
 - b) Re-enter the `ent-slk` command specifying the **bps** parameter equal to a transmission rate allowed in the linkset that the link is being added to.

E2147 Cmd Rej: X-LIST DPC is not allowed

Commands Used: `rept-stat-dstn`, `rept-stat-rte`

Xlist DPCs cannot be specified.

Recovery

Re-enter the command that generated this error message specifying the correct **dpc** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2148 Cmd Rej: DPC must be a cluster DPC or cluster member

Commands Used: `rept-stat-cluster`

You attempted to use a destination point code that was not relevant to the cluster setting required by this command.

Recovery

Re-enter the `rept-stat-cluster` command that generated this error message specifying the correct **dpc** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2149 Cmd Rej: TYPE = SCCS and PRTY=NONE combination not allowed

Commands Used: `chg-trm`

You specified the **type=sccs** parameter and the **prty=none** parameter together. This parameter combination is not allowed by this command.

Recovery

Re-enter the `chg-trm` command specifying a different value for either the **type** or the **prty** parameter.

E2150 Cmd Rej: Frame ID out of range

Commands Used: `rept-stat-db`

The value you assigned to the **Frame ID** parameter was too large.

Recovery

Re-enter the `rept-stat-db` command that generated this error message specifying the correct **Frame ID** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2152 Cmd Rej: Shelf ID out of range

Commands Used: `dlt-card`, `dlt-shlf`, `ent-card`, `ent-shlf`, `ent-slk`, `rept-stat-db`, `rtrv-shlf`, `rtrv-slk`

The value specified for the **loc** parameter is not valid physically. The first and second digits in the **loc** parameter do not identify a valid shelf.

The frame and shelf portions of the specified card location (**loc**) can be **11** through **13**, **21** through **23**; **31** through **33**; **41** through **43**; **51** through **53**; and **61**.

The format of the address specified by the **loc** parameter is **XYZZ** , where:

X = frame (**1, 2, 3, 4, 5, or 6**)

Y = shelf within the frame (**1, 2, or 3**)

ZZ = slot within the shelf range for control shelf,

X = 1, Y = 1, ZZ = 1-8, 11-12

for **disc-imt**, **ZZ = 1-8, 11-13 and 15**

for **init-card**, **ZZ = 1-8, 11-13, and 16**

for **rept-stat-card**, **ZZ = 1-8, 11-13, and 17**

range for extension shelves (all other shelves) is **1-8, 11-18**

Recovery

Re-enter the command.

Refer to the *Commands Manual* (**ent-card** command) for additional information regarding valid values for the card location.

E2153 Cmd Rej: Card slot location out of range

Commands Used: **act-dlk, canc-dlk, chg-x25-slk, dlt-card, dlt-dlk, dlt-ip-node, dlt-slk, ent-card, ent-dlk, ent-ip-node, ent-slk, ent-x25-rte, rept-stat-db, rept-stat-dlk, rept-x25-meas, rtrv-card, rtrv-dlk, rtrv-ip-node, rtrv-slk, rtrv-x25-rte, rtrv-x25-slk, tst-dlk**

The value specified for the **loc** parameter is physically invalid. The slot portion of the specified card location (**loc**) can be **1** through **8** and **11** through **18**. Slots **09** and **10** cannot be specified. (The card location is **xyss** , where **x** is the frame, **y** is the shelf, and **ss** is the slot.)

Recovery

Re-enter the command specifying a valid value for the **loc** parameter.

Refer to the *Installation Manual* for additional information regarding the values for the card location, and re-enter the command.

Refer to the *Commands Manual* for additional information regarding the correct format of the address specified by the **loc** parameter.

E2154 Cmd Rej: Card slot reserved by system

Commands Used: **chg-e1, chg-t1, chg-x25-slk, dbg-ddb, dlt-card, dlt-dlk, dlt-ip-node, dlt-slk, ent-card, ent-dlk, ent-ip-node, ent-slk, ent-t1,**

ent-x25-rte, rept-stat-db, rtrv-card, rtrv-dlk, rtrv-ip-node, rtrv-slk, rtrv-x25-rte, rtrv-x25-slk

The values of **1113 - 1118** cannot be specified for the **loc** or **rloc** parameters. The following card locations (**loc** parameter) are reserved for system operation and cannot be specified for these commands: **1113** through **1118** (OAM, TDM, MDAL cards), or **xy09** and **xy10** locations (where **x** is the shelf and **y** is the slot (HMUX or HIPR cards)).

Recovery

Re-enter the command specifying a card location that is not for an OAM, TDM, MDAL, or HMUX card. Verify that the card type is valid for the command. Refer to the *Commands Manual* for a valid list of card types for the command.

E2155 Cmd Rej: Invalid parameter combination specified

Commands Used: act-flash, act-upgrade, aud-data, chg-csl, chg-ctrl-feat, chg-db, chg-gta, chg-gtt, chg-gtcnv, chg-ls, chg-secu-dflt, dbg-ddb, dlt-csl, dlt-gta, dlt-map, ent-csl, ent-gta, ent-slk, ent-trace, init-card, init-flash, rept-meas, rept-stat-cluster, rept-stat-dstn, rept-stat-db, rept-stat-ddb, rept-stat-gpl, rept-stat-ls, rept-stat-rte, rept-stat-rtx, rept-stat-slk, rtrv-csl, rtrv-dstn, rtrv-gta, rtrv-ls, rtrv-rte, rtrv-rtx, rtrv-sid, rtrv-stp, rtrv-isupvar-attr, tst-slk

An invalid parameter has been specified.

[Table 3: Conditions that Generate Error Message E2155](#) describes the parameter combinations that generate this error message.

Table 3: Conditions that Generate Error Message E2155

Command	Invalid Parameter Combination Entered
act-flash, init-flash	The loc and sloc / eloc parameters cannot be specified together The loc parameter or the sloc / eloc parameters must be specified The appl parameter must be specified if sloc / eloc are specified The sloc and eloc parameters must be specified together If specified, the sloc parameter cannot be greater than the eloc parameter If the target card is an HMUX, HIPR, or HIPR2 card, then both card locations specified in the sloc and eloc parameters must contain HMUX, HIPR, or HIPR2 cards on the same IMT bus. The bus is implicit based on the specified location. Location <i>xy09</i> specifies an HMUX, HIPR, or HIPR2 A Bus, and location <i>xy10</i> specifies an HMUX, HIPR, or HIPR2 B Bus (<i>x</i> is the frame and <i>y</i> is the shelf). For example, sloc=1109:eloc=6109 specifies all HMUX, HIPR, or HIPR2 cards on the A Bus only; sloc=1110:eloc=6110 specifies all HMUX, HIPR, or

Command	Invalid Parameter Combination Entered
	<p>HIPR2 cards on the B Bus only. HMUX, HIPR, or HIPR2 cards from both the A bus and B bus cannot be flash downloaded simultaneously.</p> <p>If the target is HC Blade, and the if loc parameter is specified, then the gpl parameter must be specified.</p>
act-upgrade	<p>The action=getrel parameter and the release parameter must be specified together in the command.</p>
aud-data	<p>If the ddbqp parameter is specified, then the type=ddb parameter must be specified.</p> <p>If the gplqp parameter is specified, then the tblid, ddbqp, and type=ddb parameters cannot be specified.</p> <p>The display and tblid parameters cannot be specified together in the command.</p>
chg-csl, ent-csl	<p>The pc and ds parameters cannot be specified together in the command.</p>
chg-ctrl-feat	<p>The status and alarm parameters cannot be specified together in the command.</p>
chg-db	<p>The action=restore and the src=server parameters must be specified before the file parameter can be specified. If the src=server parameter is specified, then the file parameter must be specified.</p> <p>The action=restore and the src=remove parameters must be specified before the sloc parameter can be specified.</p>
chg-gta	<p>If the egta parameter is specified, then the ecgssn/ecdssn parameter cannot be specified.</p> <p>If the cgpc parameter is specified, then the egta and ecgssn/ecdssn parameters cannot be specified.</p> <p>If the opc parameter is specified, then the egta and ecgssn/ecdssn parameters cannot be specified.</p> <p>If the cgssn parameter is specified, then the egta parameter cannot be specified. If the xlat parameter has a value of udts or disc, then the egta, cgpc, opc, or cgssn/ecgssn parameters are the only other optional parameters that can be specified. If the cgpc or opc parameter is specified, the egta, ecgssn/ecdssn, and split parameters cannot be specified. If the cgssn/cdssn parameter is specified, the egta and split parameters cannot be specified. If the cgssn parameter is specified, the ecdssn parameter cannot be specified. If the cdssn parameter is specified, the ecgssn parameter cannot be specified. If the opcode parameter is specified, the egta, ecdssn, and ecgssn parameters cannot</p>

Command	Invalid Parameter Combination Entered
	be specified. The acn and family parameters cannot be specified together in the command.
chg-gtcnv	Digit manipulation parameters nsdd and nsds (new suffix digits), npdd and npds (new prefix digits), or RDMOD (reset digit modifiers) cannot be specified together. Digit manipulation parameters nsdd and nsds are mutually exclusive of the npdd and npds parameters. The four values can be added or changed (but not at the same time). However, to specify or delete existing values or to change between suffix and prefix manipulations, RDMOD must be used to reset the current values. RDMOD cannot be specified in a command containing a new suffix or new prefix parameter.
chg-gtt	The nnp , nnai , nsdd , nsds , npdd , and npds parameters cannot be specified with the rmgtt parameter in the command.
chg-ls	If the sapc , matelsn , rcontext or action parameter is specified, those four parameters are the only optional parameters that can be specified. If action is specified, the sapc , rcontext , or matelsn must be specified. If the ipsg parameter is specified, no other optional parameter can be specified.
chg-npp-as , ent-npp-as	The ca and caX , fa and faX , and sa and saX parameters cannot be specified together in the command.
chg-secu-dflt	If the clwrntx=all parameter is specified, then the wrnln and wrntx parameters cannot be specified.
dbg-ddb	<p>The dpc, tidx, lsn, and rloc parameters cannot be specified together in the command.</p> <p>The dpc, tidx, lsn, and link parameters cannot be specified together in the command.</p> <p>The action=disp and tbl=rte parameters must be specified before the dpc parameter can be specified.</p> <p>The action=disp and tbl=ls parameters must be specified before the lsn parameter can be specified.</p> <p>The action=disp and tbl=lnk parameters must be specified before the link parameter can be specified.</p> <p>The action=disp parameter must be specified before the tidx parameter can be specified.</p> <p>The action=aud parameter must be specified before the audtype parameter can be specified.</p>

Command	Invalid Parameter Combination Entered
	<p>The action=disp and tbl=lnk or the action=aud and audtype=uc parameters must be specified before the rloc parameter can be specified.</p> <p>if the action parameter has a value of wwa, stats, or rststat, then the loc parameter is the only other parameter that can be specified.</p>
disp-disk-dir	<p>The loc and src parameters cannot be specified together in the command.</p>
dlt-gta	<p>The acn and family parameters cannot be specified together in the command. If the cgssn parameter is specified, then the cdssn/ecdssn parameters cannot be specified. If the cdssn parameter is specified, the cgssn/ecgssn parameters cannot be specified. If the opcode parameter is specified, then the (e)gta/(e)cgssn/(e)cdssn parameters cannot be specified.</p>
dlt-map	<p>If the mrnset parameter is specified, then the all parameter cannot be specified.</p>
dlt-mrn	<p>If the mapset parameter is specified, then the pc1, pc2, pc3, pc4, and all parameters cannot be specified.</p>
ent-gta	<p>If the cgssn parameter is specified, then the ecdssn and egta parameters cannot be specified. If the cdssn parameter is specified, then the ecgssn and egta parameters cannot be specified. The acn and family parameters cannot be specified together in the command. If the opcode parameter is specified, then the egta, ecdssn, and ecgssn parameters cannot be specified.</p>
ent-slk	<p>The e1loc and t1loc or e1port and t1port parameters cannot be specified together in the command.</p>
ent-trace	<p>The loc and card parameters are mutually exclusive. Only one of the following parameters can be specified in a single MSU trace request: lrn, tn, dn, entityid, imsi, imei, or error.</p>
format-disk	<p>The type=fixed parameter must be specified before the prtnggrp parameter can be specified. If the prtnggrp parameter is specified, then the low=no parameter must be specified.</p>
init-card	<p>The loc parameter must be specified with a value of 1113 or 1115 before the prtnggrp parameter can be specified.</p>
rept-stat-card	<p>If the loc or port parameter is specified, then the stat parameter cannot be specified.</p>

Command	Invalid Parameter Combination Entered
rept-stat-cluster	The stat parameter cannot be specified with the dpc/ dpca parameter in the command.
rept-stat-db	The display and loc parameters, or the db and loc parameters cannot be specified in this command.
rept-stat-ddb	The display , list , and filter parameters cannot be specified together in the command.
rept-stat-dstn	The pst and mode parameters cannot be specified together in the command.
rept-stat-gpl	A combination of the display=all , gpl= , or loc= parameters cannot be specified in this command.
rept-stat-ls	The stat and lsn parameters cannot be specified in this command.
rept-stat-rte	If the clrwrtx=all parameter is specified, then the wrnln and wrtx parameters cannot be specified. The pst and mode parameters cannot be specified together in the command.
rept-stat-slk	The stat parameter and either the loc or port parameter cannot be specified in this command.
rtrv-dstn	<p>The msar=only parameter cannot be specified with any other parameters in this command.</p> <p>OR</p> <p>More than one parameter cannot be specified in this command. The only exception is the prx, pctype, and pcst parameters can be specified together. If the prx parameter is specified, then the PPC feature must be turned on.</p> <p>OR</p> <p>The pctype or pcst parameters cannot be specified with any of the following parameters: aliasa/aliasi/alisan/alisa24, apc, dpc/dpca/dpci/dpcn/dpcn24, clli, ncai, ppc, spc/spca/spci/spcn/spcn24 in this command.</p>
rtrv-gta	<p>The acn and family parameters cannot be specified together in the command. If the cgssn parameter is specified, then the cdssn and ecdssn parameters cannot be specified. If the cdssn parameter is specified, then the cgssn and ecgssn parameters cannot be specified. The cgpc, cgssn, gta, opc, cdssn and opcode parameters cannot be specified together in the command. The specified GTT set must have a set type of opcode (see the ent-gttset command) before the</p>

Command	Invalid Parameter Combination Entered
	opcode/acn/pkgtype or opcode/family/pkgtype parameters can be specified. The specified GTT set must have a set type of cdssn before the cdssn parameter can be specified. The specified GTT set must have a set type of cgssn before the cgssn parameter can be specified. The specified GTT set must have a set type of cdgta or cggta before the gta parameter can be specified. The specified GTT set must have a set type of opc before the opc parameter can be specified. The specified GTT set must have a set type of cgpc before the cgpc parameter can be specified.
rtrv-ls	Only 1 optional parameter can be specified in this command, except for the combination of the slsobit and slsrsb parameters.
rtrv-rte	The pctype and pcst parameters cannot be specified in the same command with the destination point code, alias point code, secondary point code, clli , msar=only , and ncai parameters.
rtrv-rtx	Only one of the following parameters may be specified: cic , ilns , opc or si .
rtrv-sid	The spc parameter cannot be specified with the cpc or cpctype parameter in this command.
rtrv-stp	No two optional parameters can be specified together except the following parameter sets {DISPLAY, FRM} and {GPL,VER}.
tst-slk	If the action=stop parameter is specified, then the loopback , time , and force parameters cannot be specified.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated the error message.

E2156 Cmd Rej: Cannot allow terminal configured as type=none

You cannot specify a value of **none** for the **type** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct **type** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2157 Cmd Rej: Source parameter invalid for upgrade action

Commands Used: `act-upgrade`

If the `src=usb` or `src=server` parameter is specified, then the `action=getrel` parameter must be specified. If the `src=remove` or `src=fixed` parameter is specified, then the `action=getrel` parameter cannot be specified.

Recovery

- Re-enter the `act-upgrade` command, specifying the correct parameter for the **getrel** action.
- If this error appears again, contact your Customer Care Center. Contact the "Customer Care Center" section in Chapter 1 of this manual.

E2158 Cmd Rej: Card location specified must be the standby

You attempted to assign the location of the active card to the `loc` parameter when you ran this command.

Recovery

Re-enter the command that generated this error message specifying the correct `loc` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2160 Cmd Rej: Measurements collect must be off

Commands Used: `act-upgrade`, `copy-disk`, `format-disk`

For the `act-upgrade` command, if measurement collection is enabled, the `act-upgrade:action=convertstp` command automatically inhibits measurement collection during the upgrade. Before returning to full function mode, measurements are turned back on. The following actions require that you manually inhibit measurements: **converttoam**, **oamcomplete**, **convertnet**, and **netcomplete**.

For the `copy-disk` command, OAM measurements collection cannot be in progress when this command is entered. Retry the command after a period of waiting for the measurements collection to complete.

For `format-disk`, measurements collection must be inhibited during execution of the `format-disk` command. If measurements are not inhibited, `format-disk` cannot be executed.

- Do not enter the `chg-measopts:collect=on` command while the `format-disk` command is in progress. This results in read and write errors, because the standby disk is not accessible.
- Do not enter `format-disk` until the 30 minute measurements processing or the midnight measurements processing has completed, because inhibiting measurements during these periods results in the loss of measurement data for the period being processed.

Recovery

1. Follow the instructions listed above for the command. Refer to the *Commands Manual* for more information.
2. After the appropriate waiting period, re-enter the command.
3. Upon command completion, turn OAM measurements on.
4. If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2161 Cmd Rej: Removable cartridge contains Eagle data (use FORCE=YES)

Commands Used: `format-disk`

The removable cartridge to be formatted contains EAGLE 5 ISS data. To format a cartridge already containing EAGLE 5 ISS data, **force=yes** must be specified.

Recovery

1. Make sure that the removable cartridge is in the correct location and the command has been specified correctly.
2. Re-enter the `format-disk` command specifying the **force=yes** parameter.

Note:

Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure completes.

E2163 Cmd Rej: CLI used by STP

Commands Used: `chg-dstn`, `ent-dstn`

The specified CLI is the same as the CLI that is assigned to the EAGLE 5 ISS.

Recovery

1. Enter the `rtrv-sid` command to verify the CLI for the EAGLE 5 ISS.
2. Using the output from Step 1 as a guide, re-enter the command specifying a CLI that is not the same as the CLI for the EAGLE 5 ISS.

E2164 Cmd Rej: Fixed disk contains Eagle data (use FORCE=YES)

Commands Used: `copy-disk`

The media to be formatted contains EAGLE 5 ISS data.

Recovery

1. Ensure that you really want to copy over the EAGLE 5 ISS data on the target disk, and that you have entered the `copy-disk` command correctly.
2. Re-enter the `copy-disk` command specifying the `force=yes` parameter.

E2165 Cmd Rej: Removable drive not inserted

Commands Used: `act-upgrade`, `disp-disk-dir`, `disp-tbl`, `format-disk`, `set-tbl`, `tst-disk`

[Table 4: Conditions that Generate Error Message E2165](#) describes the conditions that generate this error message.

Table 4: Conditions that Generate Error Message E2165

Command	Condition
<code>act-upgrade</code>	If the <code>src=remove</code> parameter is specified, then a removable cartridge must be inserted in the system.
<code>disp-disk-dir</code>	A removable cartridge or drive must be inserted in the slot indicated by the value specified for the <code>loc</code> or <code>source</code> parameter.
<code>disp-tbl</code> , <code>set-tbl</code>	The command was entered with the card location of the MDAL card (1117). To specify the MDAL card with these commands, a removable cartridge must be in the removable cartridge drive.
<code>format-disk</code>	The <code>force=yes</code> parameter must be specified if the cartridge to be formatted is recognized as a system removable cartridge. This parameter is optional if the cartridge is not recognized as a system removable cartridge. Only cartridges that have a <code>dms.cfg</code> file are recognized as system removable cartridges. A removable cartridge must be inserted and made ready before the <code>type=meas</code> or <code>type=system</code> parameter can be specified in the command.
<code>tst-disk</code>	To test the removable cartridge when <code>loc=1117</code> is specified, the disk must be inserted in the removable cartridge drive on the MDAL card.

Recovery

1. Go to the removable cartridge drive on the MDAL card, and visually verify whether there is a removable cartridge is in the removable cartridge drive.
2. If a removable cartridge is in the removable cartridge drive, eject and then insert the removable cartridge.
3. If no removable cartridge is in the removable cartridge drive, insert a removable cartridge in the removable cartridge drive.
For the `act-upgrade` command, make sure the removable cartridge contains the required software for the upgrade.
4. Reseat the MDAL.
5. Re-enter the command.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Note:

Leaving a removable cartridge in the MDAL for a prolonged period of time can cause damage. Remove the cartridge after the command or procedure completes.

E2166 Cmd Rej: Partial point codes are not allowed

Commands Used: `chg-appl-rtkey`, `chg-sid`, `ent-appl-rtkey`, `chg-x25-dstn`, `ent-x25-dstn`, `rtrv-x25-dstn`, `ent-rmt-appl`, `dlt-rmt-appl`

You entered a partial point code, and the system detected that the cluster routing and management diversity (CRMD) feature is turned on. The partial point code is used for CRMD routing. If the CRMD feature is turned on, these commands require that full point codes be entered for the point code parameters. The following Recovery procedures list by command, the remedial action to take for this error message.

Recovery - `chg-sid`

1. Enter the `rtrv-sid` command to verify the site point code and capability point code.
2. Enter `rtrv-dstn` to display the destination point codes in the database.
3. Enter `rtrv-ls` to display the adjacent point codes in the database.
4. Re-enter the command. Specify a full point code for the point code parameters. Use the outputs from Steps 1 through 3 to make sure the specified point code does not match any values not being changed by the `chg-sid` command, and does not match any destination point codes or adjacent point codes.

Recovery - `chg-x25-dstn`, `ent-x25-dstn`, `rtrv-x25-dstn`

1. Enter the `rtrv-dstn` command to display the destination point codes in the database.
2. Re-enter the command, with point code parameters that specify a full point code that is shown in the output of Step 1.

Recovery - `chg-appl-rtkey`, `ent-appl-rtkey`

1. Enter the `rtrv-dstn` command to display the destination point codes in the database.

2. Re-enter the command, with point code parameters that specify a full point code shown in the output of Step 1.

Recovery - ent-rmt-appl, dlt-rmt-appl

1. Enter the `rtrv-rmt-appl` command to verify the format of the point codes in the table.
2. Re-enter the command specifying a full point code in the correct format.

E2167 Cmd Rej: Point code matches a STP capability point code

Commands Used: `chg-ls`, `chg-ppsopts`, `ent-dstn`, `ent-ls`, `ent-rte`

The point code specified (destination point code or an alias point code), is the same as the capability point code of the EAGLE 5 ISS destination point codes. The specified Adjacent Point Code cannot match any of the EAGLE 5 ISS's capability codes as specified in its self-identity.

Alias point codes entered with the `ent-dstn`, `ent-ls`, or `chg-ls` command cannot match the capability point codes of the EAGLE 5 ISS, the site point codes of the EAGLE 5 ISS, or any existing destination point codes and alias point codes.

For the `chg-ppsopts` command, the values specified for the `pc`, `pca`, `pci`, or `pcn` parameter cannot be the same as the STP Capability Point Code.

Recovery - chg-ls, ent-dstn, ent-ls

1. Display the capability point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command. The capability point codes are shown in the `CPCA`, `CPCI`, `CPCN`, and `CPCN 24` fields of the `rtrv-sid` command output. The site point codes of the EAGLE 5 ISS are shown in the `PCA`, `PCI`, `PCN`, and `PCN24` fields of the `rtrv-sid` command output.
2. Display the destination point codes and alias point codes in the database. Enter the `rtrv-dstn` command. Destination point codes are shown in the `DPCA`, `DPCI`, `DPCN`, and `DPCN24` fields of the `rtrv-dstn` command output. Alias point codes are shown in the `ALIASA`, `ALIASI`, `ALIASN`, and `ALIASN24` fields of the `rtrv-dstn` command output.
3. Re-enter the command specifying a point code that is not shown in the outputs of Steps 1 and 2.

Recovery - chg-ppsopts

1. Display the capability point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command.
2. Re-enter the `chg-ppsopts` command, and specify a point code value for the `pc`, `pca`, `pci` or `pcn` parameter that is not the same as the STP Capability Point Code.

E2168 Cmd Rej: Point code matches a STP point code

Commands Used: `chg-ls`, `chg-ppsopts`, `ent-dstn`, `ent-ls`, `ent-rte`

The point code specified (destination point code or an alias point code), is the same as the site point code of the EAGLE 5 ISS destination point code. The specified Adjacent Point Code cannot match the destination point code of the EAGLE 5 ISS as specified in its self-identity.

Alias point codes entered with the `ent-dstn`, `ent-ls`, or `chg-ls` command cannot match the site point codes of the EAGLE 5 ISS, the capability point codes of the EAGLE 5 ISS, or any existing destination point codes and alias point codes.

For the `chg-ppsopts` command, the point code value specified for the `pc`, `pca`, `pci`, or `pcn` parameter cannot be the same as the STP True Point Code.

Recovery - `chg-ls`, `ent-dstn`, `ent-ls`

1. Display site point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command. The site point codes are in the `PCA`, `PCI`, `PCN`, and `PCN24` fields of the `rtrv-sid` command output. The capability point codes of the EAGLE 5 ISS are shown in the `CPCA`, `CPCI`, `CPCN`, and `CPCN24` fields of the `rtrv-sid` command output.
2. Display the destination point codes and alias point codes in the database. Enter the `rtrv-dstn` command. Destination point codes are shown in the `DPCA`, `DPCI`, `DPCN`, and `DPCN24` fields of the `rtrv-dstn` command output. Alias point codes are shown in the `ALIASA`, `ALIASI`, and `ALIASN` fields of the `rtrv-dstn` command output.
3. Re-enter the command, and specify a point code that is not shown in the outputs of Steps 1 and 2.

Recovery - `chg-ppsopts`

Note: The `ppt` parameter must be specified if the `pc`, `pca`, `pci`, `pcn`, `ri`, or `setid` parameter is specified.

1. Display the site point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command.
2. Re-enter the `chg-ppsopts` command, and specify a point code value for the `pc`, `pca`, `pci`, or `pcn` parameter that is not the same as the STP True Point Code.

E2169 Cmd Rej: Point code out of range

Commands Used: `chg-gta`, `chg-gtt`, `chg-loopset`, `chg-ls`, `chg-map`, `chg-mrn`, `chg-sccp-serv`, `chg-sid`, `dlt-gta`, `dlt-map`, `ent-dstn`, `ent-gta`, `ent-gtt`, `ent-ls`, `ent-map`, `ent-mrn`, `ent-rtx`, `ent-sid`, `ent-spc`, `rtrv-gta`, `rtrv-gtt`

The specified point code is outside of the valid range of values for the command parameter.

Recovery

Re-enter the command, and specify a valid point code value.

Refer to the command description in the *Commands Manual* for information on the correct point code values.

E2171 Cmd Rej: Failed reading level 2 timer set table

Commands Used: `chg-l2t`, `rtrv-l2t`

The Level 2 Timer Set table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.

2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2172 Cmd Rej: Command action is out of phase with expected procedure

Commands Used: `act-flash`, `act-upgrade`, `init-flash`

For `act-upgrade`, the database partition must be in the correct functional mode.

OR

The `act-flash` command was entered to activate a flash GPL, and the GPL running on the card is not inactive.

OR

The `init-flash` command was entered to load an inactive flash GPL onto a card, and the card is currently running an inactive flash GPL.

Recovery - `act-upgrade`

1. Enter the `act-upgrade:action=dbstatus` command to verify the phase that the upgrade process is in. The phase of the upgrade process is shown in the header of the command output.
2. If the upgrade process is at Upgrade Phase 0, then enter the `act-upgrade:action=converttoam` command.
3. If the upgrade process is at Upgrade Phase 2, then enter the `act-upgrade:action=oamcomplete` command.

Recovery - `act-flash`

1. Enter the `rept-stat-gpl` command to display the GPLs running on the cards installed in the system.
2. Verify that the GPL you want to activate is inactive on the card. A plus sign (+) in the column between the RUNNING and APPROVED columns indicates an inactive GPL.
3. If the GPL is inactive, re-enter the `act-flash` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - `init-flash`

1. Display the GPLs running on the cards installed in the system.
Enter the `rept-stat-gpl` command.
2. Verify that the card is not already running an inactive flash GPL.
A plus sign (+) in the column between the RUNNING and APPROVED columns indicates an inactive GPL.

3. If the card is not running an inactive GPL, re-enter the `init-flash` command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2173 Cmd Rej: Failed reading level 3 timer set table

Commands Used: `chg-13t`

The Level 3 Timer Set table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2174 Cmd Rej: May not modify both T20 and IT22 timers

Commands Used: `chg-13t`

The command was entered specifying both the `t20` and `it22` timers. These two parameters define the same timer, but the `t20` timer is used with ANSI linksets only, and the `it22` timer is used with ITU linksets. Because these two parameters define the same timer, both parameters cannot be specified in the same command.

Recovery

Re-enter the `chg-13t` command specifying either the `t20` parameter for ANSI linksets only, or the `it22` parameter for ITU linksets, but not both in the same command.

E2175 Cmd Rej: May not modify both T21 and IT23 timers

Commands Used: `chg-13t`

The command was entered specifying both the `t21` and `it23` timers. These two parameters define the same timer, but the `t21` timer is used with ANSI linksets only, and the `it23` timer is used with ITU linksets. Because these two parameters define the same timer, both parameters cannot be specified in the same command.

Recovery

Re-enter the `chg-13t` command specifying either the `t21` or `it23` parameters, but not both in the same command.

E2177 Cmd Rej: Destination parameter not supported

Commands Used: `chg-db`

The command was entered specifying the destination (**dest**) parameter, and the **action=backup** parameter was not specified. If you specify the **dest** parameter, the **action=backup** parameter must also be specified.

Recovery

Re-enter the `chg-db` command specifying both the **dest** and the **action=backup** parameters.

E2178 Cmd Rej: Source parameter not supported

Commands Used: `chg-db`

The command was entered specifying the source (**src**) parameter, and the **action=restore** parameter was not specified. If you specify the **src** parameter, the **action=restore** parameter must be specified.

Recovery

Re-enter the `chg-db` command specifying both the **src** and the **action=restore** parameters.

E2179 Cmd Rej: Current actv OAM db is not supported for this upgrade

Commands Used: `act-upgrade`

The database on the active TDM is not at the proper level for this command.

Recovery

Enter the `act-upgrade:action=dbstatus` command to verify the version of the database on the active TDM. The version of the database is shown in the `VERSION STATUS` field.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2180 Cmd Rej: Current stdbv OAM db is not supported for this upgrade

Commands Used: `act-upgrade`

The database on the standby TDM is not at the proper level for this command.

Recovery

Enter the `act-upgrade:action=dbstatus` command to verify the version of the database on the standby TDM. The version of the database is shown in the `VERSION STATUS` field.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2181 Cmd Rej: ANSI PC is identical to ANSI CPC

Commands Used: `chg-sid`

The specified ANSI point code (`pca`) matches the ANSI capability point code (`cpca`).

Recovery

1. Verify the ANSI capability point code in the system. Enter the `rtrv-sid` command.
The ANSI capability point code is shown in the `CPCA` field of the output.
2. Display the destination point codes in the database. Enter the `rtrv-dstn` command.
The ANSI destination point codes are shown in the `DPCA` field of the output.
3. Display the adjacent point codes in the database. Enter the `rtrv-ls` command.
The ANSI adjacent point codes are shown in the `APCA` field of the output.
4. Re-enter the `chg-sid` command specifying a point code that does not match the capability point code, and does not match any point codes in the destination point codes or adjacent point codes.

E2182 Cmd Rej: Only one of NCPC/A, NCPCI, or NCPCN/N24 may be specified

Commands Used: `chg-sid`

You tried to enter the command specifying more than one of the `ncpc`, `ncpca`, `ncpci`, `ncpcn`, or `ncpcn24` parameters. You can enter only one of these parameters per command.

Recovery

Re-enter the `chg-sid` command specifying a value for only one of the following parameters: `ncpc`, `ncpca`, `ncpci`, `ncpcn`, or `ncpcn24`.

E2183 Cmd Rej: Capability point code is already being used

Commands Used: `chg-sid`

You specified a capability point code (`cpca`, `cpca`, `cpca`, `cpca`) that is already being used to define an STP.

Recovery

1. Verify the site point codes and capability point codes in the system.
Enter the `rtrv-sid` command. The site point codes are shown in the `PCA`, `PCI`, and `PCN` fields of the output. The capability point codes are shown in the `CPCA`, `CPCI`, `CPCN`, `CPCN24` fields of the output.
2. Display the destination point codes in the database.

Enter the `rtrv-dstn` command. The ANSI destination point codes are shown in the `DPCA` , `DPCI` , `DPCN` , and `DPCN24` fields of the output.

3. Re-enter the `chg-sid` command specifying a point code that does not match the site point code or capability point code, and does not match any point codes in the destination point codes.

E2184 Cmd Rej: CLLI is already being used by a route

Commands Used: `chg-dstn`, `ent-dstn`, `ent-ls`, `chg-sid`

The site CLLI code that is specified in the command cannot be the same as an existing route destination CLLI code.

Recovery

1. Display the self-identification parameters. Enter the `rtrv-sid` command.
2. Display all entries in the Route table or SID. Enter the `rtrv-dstn` command.
3. Re-enter the command that generated this error message specifying a CLLI that is not in the Route table.

E2185 Cmd Rej: Capability point code matches STP's own point code

Commands Used: `chg-sid`

The new STP capability point code that is specified in the command cannot be the same as the STP destination point code.

Recovery

1. Enter the `rtrv-sid` command to display the CPC currently specified for the STP.
The capability point code is displayed in either the `CPCA` , `CPCI` , `CPCN` , `CPCN24` , `PC` , `PCI` , `PCN` , or `PCN24` field.
2. Re-enter the command specifying a CPC that is different from the one displayed in Step 1.

E2186 Cmd Rej: Capability point code already defined as a route DPC

Commands Used: `chg-sid`

You entered the command and specified a value for the `cpc` parameter that matches a value already in the database as a route DPC. The capability point code (`cpc`) parameter cannot be already assigned as a route destination point code.

Recovery

1. Display the route DPCs for this EAGLE 5 ISS.
Enter the `rtrv-dstn` command.

2. Re-enter the `chg-sid` command, specifying a value for the `cpc` parameter that differs from all of the DPCs displayed in Step 1.

E2187 Cmd Rej: International PC is identical to international CPC

Commands Used: `chg-sid`

The specified international (ITU-I) point code (`pci`) cannot be the same as the international (ITU-I) capability point code (`cpci`).

Recovery

1. Verify the ITU-I capability point code in the system. Enter the `rtrv-sid` command.
The ITU-I capability point code is shown in the `CPCI` field of the output.
2. Display the destination point codes in the database. Enter the `rtrv-dstn` command.
The ITU-I destination point codes are shown in the `DPCI` field of the output.
3. Re-enter the `chg-sid` command specifying a point code that does not match the capability point code, and does not match any point codes in the destination point codes.

E2188 Cmd Rej: National PC is identical to national CPC

Commands Used: `chg-sid`

The specified national (ITU-N) point code (`pcn`) matches the national capability point code (`cpcn`).

Recovery

1. Verify the ITU-N capability point code in the system.
Enter the `rtrv-sid` command. The ITU-N capability point code is shown in the `CPCN` field of the output.
2. Display the destination point codes in the database.
Enter the `rtrv-dstn` command. The ITU-N destination point codes are shown in the `DPCN` field of the output.
3. Re-enter the `chg-sid` command specifying a point code that does not match the capability point code, and does not match any point codes in the destination point codes.

E2189 Cmd Rej: Site point code is already being used

Commands Used: `chg-sid`, `ent-sid`

The `chg-sid` command was entered with a site point code (`pca`, `pci`, `pcn`, or `pcn24`) that was defined as a route destination point code. The same type of STP Destination point code cannot be assigned if one already exists.

The `chg-sid` or **ent-sid** command was entered with an STP destination point code that was previously defined as a capability point code, or defined as the same type of STP destination point code if one already exists.

Recovery

1. Verify the site point codes and capability point codes in the system.
Enter the `rtrv-sid` command. The site point codes are shown in the `PCA`, `PCI`, `PCN`, and `PCN24` fields of the output. The capability point codes are shown in the `CPCA`, `CPCI`, `CPCN`, and `CPCN24` fields of the output.
2. Display the destination point codes in the database.
Enter the `rtrv-dstn` command. The ANSI destination point codes are shown in the `DPCA`, `DPCI`, `DPCN`, and `DPCN24` fields of the output.
3. Re-enter the command specifying a point code that does not match the site point code or capability point code, and does not match any point codes in the destination point codes.

E2190 Cmd Rej: Cannot delete STP self ID if a DPC of same type is defined

Commands Used: `chg-sid`

The STP destination point code can be deleted by specifying a value of none for the `pc/pca/pci/pcn/pcn24` parameter only if there are no destination point codes in the route table that have the same point code type (pctype) as the STP point code to be deleted.

The EAGLE 5 ISS requires that, if destination point codes of a particular point code type are to be used, the EAGLE 5 ISS's self ID must be defined with a point code of the same point code type.

Recovery

1. Display the self ID of the EAGLE 5 ISS.
Enter the `rtrv-sid` command.
2. Display the DPCs in the database.
Enter the `rtrv-dstn` command.
3. Re-enter the `chg-sid` command that generated the error message specifying a point code parameter whose point code type is not being used by the Destination Point Code table as shown in the output from Step 2.
For example, if the `rtrv-dstn` output contains no `DPCN` or `ALIASN` field, specify the `pcn=none` parameter for the self ID point code that you want to delete.
4. If the output from Step 2 contains fields for all point code types (`DPCA`, `DPCI`, `DPCN`, and `DPCN24`), and you **must** delete the self ID point code, call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2191 Cmd Rej: Failed reading SLTM table

Commands Used: `chg-slt`

The Signaling Link Test Message (SLTM) table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2192 Cmd Rej: Pattern contains invalid characters

Commands Used: `chg-slt`

The specified pattern contains characters that are not allowed. The pattern can contain only the characters 0 – 9 and A – F. The first two characters of the pattern must be the characters A – F.

Recovery

Re-enter the `chg-slt` command specifying a pattern that contains only the characters 0 – 9 and A – F, with the first two characters from the range A – F.

E2193 Cmd Rej: Pattern has odd number of characters

Commands Used: `chg-slt`

The specified pattern contains an odd number of characters. It must have an even number of characters.

Recovery

Re-enter the `chg-slt` command specifying a pattern that contains an even number of characters, but no more than 30 characters.

E2194 Cmd Rej: SLTSET and ENABLED cannot be specified together

Commands Used: `rtrv-slt`

The command was entered with both the `sltset` and `enabled` parameters. This parameter combination is not allowed by this command.

Recovery

Re-enter the `rtrv-slt` command specifying either the `sltset` or `enabled` parameters, but not both.

E2195 Cmd Rej: NCDPNPFX already exists in INPOPTS Table

Commands Used: `chg-inpopts`

You entered a command to change a New Called Party Number Prefix to the prefix specified in the **ncdnpnfx** parameter, and the new Prefix already exists in the INPOPTS table.

Recovery

1. Enter the `rtrv-inpopts` command. The `CDPNPFX` field in the output shows a list of prefixes that are already entered in the INPOPTS table.
2. If the new prefix you entered does not appear in the output, re-enter the `chg-inpopts` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2196 Cmd Rej: Failed reading the user identification table

Commands Used: `chg-pid`, `chg-user`, `dlt-user`, `ent-user`

The User Identification table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2197 Cmd Rej: The specified user identification is already defined

Commands Used: `chg-user`, `ent-user`

The command entered specified a user identification (**nuid** for the `chg-user` command, **uid** for the `ent-user` command) that already exists in the database. The values specified for the **uid** parameter (`ent-user` command) or **nuid** (`chg-user` command) cannot be in the database.

Recovery

1. Display the user IDs in the database.
Enter the `rtrv-user` command.
2. Re-enter the command that generated this error message with a value for the **uid** parameter (`ent-user` command) or **nuid** (`chg-user` command) that is not shown in the output of Step 1.

E2198 Cmd Rej: The maximum number of users is already defined

Commands Used: `ent-user`

The database can contain a maximum of **100** user IDs. An attempt was made to add a user ID to the database, and the database already contains the maximum **100** user IDs. No more users can be added until a current user ID is deleted from the database or a current user ID is changed.

Recovery

1. Display the user IDs in the database.

Enter the `rtrv-user` command.

- a) To change a current user ID, enter the `chg-user` command specifying a user ID (**uid**) shown in the output of Step 1. For the **uid** parameter, specify the user ID used in the command that generated this error message.
- b) To delete a user ID from the database, enter the `dlt-user` command specifying a user ID shown in the output of Step 1.

Enter the `rept-stat-user` command to verify if the user ID to be deleted is currently logged on to the system. If the user is logged on to the system, advise that user to log off the system. If the user is logged on to the system, and you execute the `dlt-user` command, the user will be logged off the system.

2. Re-enter the `ent-user` command that generated this error message.

E2199 Cmd Rej: The specified user identification is not defined

Commands Used: `chg-pid`, `chg-user`, `dlt-user`, `rtrv-secu-user`

The command was entered with a user identification (**uid**) that is not in the database. The value specified for the **uid** parameter must be in the database.

Recovery

1. Display the user IDs in the database.

Enter the `rtrv-user` command.

2. Re-enter the command that generated this error message with a value for the **uid** parameter that is shown in the output of Step 1.

E2200 Cmd Rej: Database maint. in progress - retry later

Commands Used: `chg-dstn`, `chg-ls`, `chg-rte`, `chg-x25-dstn`, `chg-x25-rte`, `chg-x25-slk`, `dlt-card`, `dlt-dlk`, `dlt-dstn`, `dlt-ip-node`, `dlt-ls`, `dlt-rte`, `dlt-slk`, `dlt-x25-dstn`, `dlt-x25-rte`, `ent-card`, `ent-dlk`, `ent-dstn`, `ent-ip-node`, `ent-ls`, `ent-rte`, `ent-slk`, `ent-x25-dstn`, `ent-x25-rte`, `rtrv-card`, `rtrv-feat`, `rtrv-ip-node`, `rtrv-ls`, `rtrv-rte`, `rtrv-slk`, `rtrv-x25-dstn`, `rtrv-x25-rte`, `rtrv-x25-slk`

You entered the command while a database maintenance operation was being executed and was not completed. This command cannot be executed while a database maintenance operation is in progress.

Recovery

Wait for the database maintenance operation to finish, then re-enter the command.

E2201 Cmd Rej: Shelf location 1100 is reserved for the control shelf

Commands Used: `dlt-shlf`, `ent-shlf`

The command was entered with the value **1100** for the `loc` parameter. Shelf **1100** is the control shelf and cannot be deleted from the database.

Recovery

1. Display the shelves in the database.
Enter the `rtrv-shlf` command.
2. Re-enter the command specifying values shown in the `SHELF FRAME` and `DISPLAY SHELF` fields of the `rtrv-shlf` output to determine the value of the `loc` parameter. For example, if the value **3** is shown in the `SHELF FRAME` field and the value **2** is shown in the `DISPLAY SHELF` field, that shelf would be entered in the `dlt-shlf:loc=` command as **3200**.

E2202 Cmd Rej: Shelf location already equipped

Commands Used: `ent-shlf`

The shelf specified by the `loc` parameter already exists in the database. The shelf specified by the `loc` parameter cannot be in the database.

Recovery

1. Display the shelves in the database.
Enter the `rtrv-shlf` command.
2. Re-enter the `ent-shlf` command specifying a shelf location that is not shown in the output of Step 1.

E2203 Cmd Rej: All cards on shelf must be unequipped

Commands Used: `dlt-shlf`

You cannot remove a shelf that has cards assigned to it. Before a shelf can be removed from the database:

- All affected SS7 signaling links and TCP/IP data links must be deactivated.
- All signaling links and their routes assigned to cards in the affected shelf must be removed from the database.
- All cards in the affected shelf must be removed from the database.

Note:

The control shelf (Shelf 1100) cannot be removed from the database.

Refer to the `dlt-shlf` command in the *Commands Manual*.

Recovery

1. Refer to the "Removing a Shelf" procedure in the *Database Administration Manual - System Management*.
2. Re-enter the `dlt-shlf` command specifying the `loc` parameter of the shelf to be removed.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2204 Cmd Rej: Waiting for duplex mode in provisioning subsystem

Commands Used: Any command used to update a database

An attempt was made to update a database immediately following a dual OAM boot, a switchover, or a database repair, and before the detection of an active standby. An active OAM waits for up to five minutes for an available standby before allowing database updates.

Recovery

1. Wait for the message:

```
INFO: Provisioning subsystem is in duplex mode.
```

OR Wait five minutes.

2. Re-enter the command.

E2205 Cmd Rej: Invalid destination application ID

Commands Used: `send-msg`

You specified an invalid `da` parameter value.

Recovery

1. Verify the value specified by the destination application (`da`) parameter.
2. Re-enter the `send-msg` command that generated this error message specifying the correct value for the `da` parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2206 Cmd Rej: Invalid originating application ID

Commands Used: `send-msg`

You specified an invalid `oa` parameter value.

Recovery

1. Verify the value specified by the originating application (**oa**) parameter.
2. Re-enter the `send-msg` command that generated this error message specifying the correct value for the **oa** parameter.
3. Refer to the *Commands Manual* for assistance if necessary.

E2207 Cmd Rej: Location type cannot receive messages

Commands Used: `send-msg`

The destination location is not equipped to receive messages. The destination location must be equipped to receive messages. You may have specified the wrong card location (**loc**) parameter.

Recovery

1. Verify the value specified by the **loc** parameter.
 2. Re-enter the `send-msg` command that generated this error message specifying the correct value for the **loc** parameter.
- Refer to the *Commands Manual* for assistance if necessary.

E2208 Cmd Rej: ALL only qualifier allowed with given card type

Commands Used: `disp-bp`, `disp-mem`, `dlt-bp`, `ent-bp`, `ent-trace`, `set-mem`

You attempted to run this command specifying the card type qualifier (subsystem) set to a value that is not allowed for the card.

Recovery

Re-enter the command that generated this error message specifying the **all** value for the subsystem qualifier.

Refer to the *Commands Manual* if necessary for further assistance.

E2209 Cmd Rej: Both DR and DA parameters cannot be entered

Commands Used: `ent-bp`

The **da** and **dr** parameters cannot be specified together in the command.

Recovery

Perform one of the following actions:

- Re-enter the `ent-bp` command that generated this error message specifying only the **dr** or **da** parameter.

Refer to the *Commands Manual* for further assistance if necessary.

E2210 Cmd Rej: BYTE, WORD or DWORD must be entered

Commands Used: `set-mem`

You tried to run this command without specifying one of the following parameters: **byte**, **word**, or **dword**.

Recovery

Re-enter the `set-mem` command that generated this error message specifying the correct **byte**, **word**, or **dword** parameter value.

Refer to the *Commands Manual* for further assistance.

E2211 Cmd Rej: Maximum number of CDPNPFxs already provisioned

Commands Used: `chg-inpopts`

A maximum of **40** Called Party Number Prefix values is allowed.

Recovery

Verify the number of prefixes in the database. Enter the `rtrv-inpopts` command. View the CDPNPFx column of the output.

- If the number of prefixes is less than **40**, re-enter `chg-inpopts` command that generated this error message.
- If the number of prefixes is **40**, change one of the existing prefixes. Enter the `chg-inpopts` command.

Refer to the *Commands Manual* for further assistance.

E2212 Cmd Rej: Invalid card type for this command

Commands Used: `act-flash`, `dbg-ddb`, `chg-bip-fld`, `chg-bip-rec`, `chg-el`, `chg-ip-card`, `chg-ip-lnk`, `chg-t1`, `disp-bip`, `disp-bp`, `disp-mem`, `dlt-appl-rtkey`, `dlt-bp`, `dlt-el`, `dlt-ip-rte`, `dlt-t1`, `ent-bp`, `ent-card`, `ent-el`, `ent-slk`, `ent-t1`, `ent-trace`, `flash-card`, `init-flash`, `rept-meas`, `rept-stat-rtd`, `rept-x25-meas`, `rtrv-appl-rtkey`, `rtrv-bip`, `rtrv-el`, `rtrv-ip-card`, `rtrv-ip-lnk`, `rtrv-ip-rte`, `rtrv-t1`, `set-mem`, `tst-el`, `tst-slk`, `tst-t1`

The card that is specified cannot be used with this command.

Recovery

1. Display the card's configuration. Enter the `rtrv-card` command specifying the card location that generated this error message. The card's type is shown in the `TYPE` field of the output.

2. Re-enter the command specifying a valid value for the relevant parameter. Refer to the *Commands Manual* for assistance.

E2213 Cmd Rej: Missing parameter - BC

Commands Used: `disp-mem`, `ent-bp`

You ran this command without specifying the **bc** parameter (number of data bytes to display).

Recovery

Re-enter the command that generated this error message specifying the correct **bc** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2214 Cmd Rej: Missing parameter - CARD, LOC or IMT

Commands Used: `disp-bp`, `disp-mem`, `dlt-bp`, `ent-bp`, `set-mem`

You must specify one of the following parameters: **card**, **loc**, or **imt**.

Recovery

Re-enter the command that generated this error message specifying the correct value for one (and only one) of the following parameters: **card**, **loc**, or **imt**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2215 Cmd Rej: Missing parameter - DA or DR

Commands Used: `ent-bp`

You attempted to run this command without specifying either the data register (**dr**) or the memory dump address (**da**) parameters.

Recovery

Perform one of the following:

- Re-enter the `ent-bp` command that generated this error message specifying the correct **dr** parameter value.
- OR
- Re-enter the `ent-bp` command that generated this error message specifying the correct **da** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2216 Cmd Rej: CDPNPFX must not be NONE

Commands Used: `chg-inopts`

The `cdnpfx` parameter cannot have a specified value of `none`.

Recovery

1. View the values for `cdnpfx`.
Enter the `rtrv-inopts` command.
2. To delete an existing prefix (that appears in the output of Step 1), re-enter the `chg-inopts` command specifying the desired prefix in the `cdnpfx` parameter and `ncdnpfx=none`.

E2217 Cmd Rej: More than one of CARD, LOC and IMT specified

Commands Used: `disp-bp`, `disp-mem`, `dlt-bp`, `ent-bp`, `set-mem`

You attempted to run this command while specifying more than one of these parameters: `card`, `loc`, or `imt`.

Recovery

Re-enter the command that generated this error message specifying the correct value for one (and only one) of the following parameters: `card`, `loc`, or `imt`.

Refer to the *Commands Manual* for assistance.

E2218 Cmd Rej: Only one of BYTE, WORD or DWORD may be entered

Commands Used: `set-mem`

You tried to run this command while entering more than one of the following parameters: `byte`, `word`, or `dword`.

Recovery

Re-enter the `set-mem` command that generated this error message specifying the correct `byte`, `word`, or `dword` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2219 Cmd Rej: Specified BC exceeds max allowed (96)

Commands Used: `ent-bp`

You cannot specify a value greater than **96** for the **bc** parameter (number of data bytes to display).

Recovery

Re-enter the `ent -bp` command that generated this error message specifying a **bc** parameter value \leq **96**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2220 Cmd Rej: DLTPFX must not be specified, when NCDPNPFX is NONE

Commands Used: `chg-inopts`

You specified **ncdpnpx=none** and specified the **dlpfx** parameter. You cannot specify the **dlpfx** parameter when you specify the value **none** for the **ncdpnpx** parameter.

Recovery

To delete a prefix, re-enter the `chg-inopts` command specifying the value in the **cdpnpx** parameter for the prefix to be deleted and **ncdpnpx=none**.

E2221 Cmd Rej: File transfer in progress

Commands Used: `act-file-trns`, `copy-fta`, `copy-seculog`, `disp-fta-dir`, `dlt-fta`

You entered the command while another command is already in progress. The EAGLE 5 ISS does not allow this action. Only one file transfer may be active at one time.

Recovery

Wait until the file transfer is complete, then re-enter the command.

E2222 Cmd Rej: CDPNPFX doesn't exist in INPOPTS Table

Commands Used: `chg-inopts`

You entered a command to change or delete a value for the **cdpnpx** parameter that is not in the INPOPTS table.

Recovery

Enter the `rtrv-inopts` command. The CDPNPFX field in the output shows a list of valid names.

- If the value you entered appears in the output, re-enter the `chg-inopts` command.
- If the value you entered does not appear in the output, you cannot change or delete the specified **cdpnpx** value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2223 Cmd Rej: Invalid drive specified

Commands Used: `copy-fta`, `disp-tbl`, `set-lbp`, `set-tbl`

You attempted to run this command while specifying an invalid hard drive.

Recovery

Re-enter the command that generated this error message specifying the correct drive identifier.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2224 Cmd Rej: Only one Source and Destination may be specified

Commands Used: `chg-db`, `copy-fta`

You cannot specify multiple instances of the `src` or `dest` parameters.

Recovery

Re-enter the command that generated this error message specifying the correct `src` and `dest` parameter values.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2225 Cmd Rej: SRC and DEST must be specified

Commands Used: `chg-db`, `copy-fta`

You failed to specify both the source and the destination parameters for this operation.

Recovery

Re-enter the command that generated this error message specifying correct `src` and `dest` parameter values.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2226 Cmd Rej: CDPNNAI doesn't exist in INPOPTS Table

Commands Used: `chg-inpopts`

You specified `snai=none` to delete a `cdpnnai` from the database, and the `cdpnnai` value that you entered does not exist in the database.

Recovery

1. Enter the `rtrv-inpopts` command.
The `CDPNNAI` field in the output shows a list of valid values.
2. If the `cdpnnai` value you entered appears in the output, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the value you entered does not appear in the output, you cannot specify `snai=none` to delete it.

E2227 Cmd Rej: Maximum Number of CDPNNAI already provisioned

Commands Used: `chg-inpopts`

You entered the command to create or change a Called Party Number Nature of Address Indicator, but the database already contains the maximum of 5 values.

Recovery

Verify the number of `cdpnnai` values in the INPOPTS table. Enter the `rtrv-inpopts` command.

- If the number of CDPNNAI listed in the CDPNNAI column of the output is less than 5, re-enter the `chg-inpopts` command that generated this error message.
- If the number of CDPNNAI is 5 or greater, you must delete or change one of the existing CDPNNAI. Enter the `chg-inpopts` command to change the value of an existing `cdpnnai` entry.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2229 Cmd Rej: Use DFILE when specifying STBL

Commands Used: `copy-fta`

You cannot copy information out of a Source table into a destination file without specifying both the (`dfile`) and (`stbl`) parameters. A destination file must be specified when a Source table is specified.

Recovery

Re-enter the `copy-fta` command that generated this error message specifying both the (`dfile`) and (`stbl`) parameters. A Source table must be specified when a destination file is specified.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2230 Cmd Rej: Use DTBL when specifying SFILE

Commands Used: `copy-fta`

You cannot copy information out of a source file into a Destination table without specifying both the **(dtbl)** and **(sfile)** parameters. A Destination table must be specified when a source file is specified.

Recovery

Re-enter the `copy-fts` command that generated this error message specifying both the **(dtbl)** and **(sfile)** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2231 Cmd Rej: Use SFILE when specifying DTBL

Commands Used: `copy-fts`

You cannot copy information out of source file into a Destination table without specifying both the **(dtbl)** and **(sfile)** parameters. A source file must be specified when a Destination table is specified.

Recovery

Re-enter the `copy-fts` command that generated this error message specifying both the **(dtbl)** and **(sfile)** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2232 Cmd Rej: Use STBL when specifying DFILE

Commands Used: `copy-fts`

You cannot copy information out of a Source table into a destination file without specifying both the **(dfile)** and **(stbl)** parameters. A Source table must be specified when a destination file is specified.

Recovery

Re-enter the `copy-fts` command that generated this error message specifying both the **(dfile)** and **(stbl)** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2233 Cmd Rej: May not specify Filename when ALL=YES

Commands Used: `dlt-fts`

You cannot specify the **filename** parameter, if the **all** parameter equals **yes (all=yes)**.

Recovery

Perform one of the following:

- Re-enter the `dlt-fta` command specifying the **all=yes** parameter.
OR
- Re-enter the `dlt-fta` command specifying the **filename** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2234 Cmd Rej: Must specify ALL=YES to delete all files

Commands Used: `dlt-fta`

The **all=yes** parameter must be specified when a specific filename is not supplied.

Recovery

Perform one of the following actions:

- Re-enter the `dlt-fta` command that generated this error message specifying the **all=yes** parameter.
OR
- Re-enter the `dlt-fta` command that generated this error message specifying the filename.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2235 Cmd Rej: Card location must be 1113 or 1115, or APPL=E(OAM)

Commands Used: `init-card`

If you specify the **initclk** and **loc** parameters or the **initclk** and **appl** parameters, then:

- The specified card location (**loc**) must be **1113** or **1115**.
OR
- The specified application (**appl**) must be **oam** or **eoam**.

Recovery

Re-enter the `init-card` command specifying one of the following:

- Specify **initclk** and **loc=1113** or **loc=1115**
OR
- Specify **initclk** and **appl=oam** or **appl=eoam**

E2236 Cmd Rej: Must specify GPL name and version

Commands Used: `chg-gpl`, `rtrv-stp`

For the `chg-gpl` command, if either of the **appl** or **ver** parameters are specified, then both of these parameters must be specified. The one exception to this rule is that the **ver** parameter is not required if **appl=emap** or **appl=oap**.

For the `rtrv-stp` command, the **gpl** parameter is mandatory when the **ver** parameter is specified.

Recovery `chg-gpl`

Re-enter the `chg-gpl` command specifying both the **appl** and **ver** parameters.

Recovery `rtrv-stp`

Re-enter the `rtrv-stp` command specifying both the **gpl** and **ver** parameters.

E2237 Cmd Rej: Card location must be 1114 or 1116

Commands Used: `act-file-trns`

The **loc** parameter must specify a TDM or E5-TDM card.

Recovery

Re-enter the command that generated this error message specifying the correct value for the **loc** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2238 Cmd Rej: The GPL type entered is not currently supported

Commands Used: `act-gpl`, `chg-gpl`, `rept-stat-gpl`, `rtrv-gpl`, `rtrv-stp`

The value specified for the **gpl** parameter must be supported.

Recovery

Re-enter the command specifying a valid value for the **gpl** parameter. Refer to the command definition in the *Commands Manual* for a list of supported GPLs.

E2239 Cmd Rej: Data audit already in progress

Commands Used: `aud-data`

An attempt was made to execute the `aud-data` command while a previously entered `aud-data` command was still executing.

Recovery

If you want to execute the `aud-data` command again, wait for the previously entered `aud-data` command to finish executing. Otherwise, no action is necessary.

E2240 Cmd Rej: Card location must be 1114, 1116, or 1117

Commands Used: `copy-fta`, `disp-fta-dir`, `disp-tbl`, `set-lba`, `set-tbl`

The command was entered with a card location other than the TDMs (1114, 1116), or MDAL (1117).

Recovery

Re-enter the command specifying one of these card locations: 1114, 1116, or 1117. If card location 1117 is specified, make sure a removable cartridge is in the removable cartridge drive.

Note:

Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure completes.

E2241 Cmd Rej: No File Transfer Area on removable cartridge

Commands Used: `copy-fta`, `dlt-fta`

The command was entered with the card location of the source (`sloc`) or the card location of the destination (`dloc`) equal to the removable cartridge disk location, and using a default value for the FTA to be copied (`sfile`) or for the name of the file to be copied into the FTA (`dfile`).

Recovery

Re-enter the `copy-fta` command specifying a value for `sfile` or `dfile`.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2242 Cmd Rej: Destination card invalid

Commands Used: `chg-bip-fld`, `chg-bip-rec`, `disp-bip`, `rtrv-bip`, `tst-bip`

The value specified for the card location (`loc`) is not valid with these commands.

The card location specified in the command cannot be an HMUX, MDAL, fixed disk, or removable cartridge.

Recovery

Re-enter the command specifying a card location that is not an HMUX or MDAL card.

Note:

The MDAL card is in location **1117**. The HMUX cards are in locations **9** and **10** on each shelf.

E2244 Cmd Rej: INIT=YES only valid with BID record

Commands Used: `chg-bip-rec`

You attempted to initialize a Board Identification PROM, but did not include the necessary identification information when you entered this command.

Recovery

Re-enter the `chg-bip-rec` command that generated this error message specifying the correct **data** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2245 Cmd Rej: CDPNNAI and SNAI must be specified together

Commands Used: `chg-inopts`

You specified the **cdpnnai** parameter or the **sna**i parameter but not both. When you specify one of these parameters (**cdpnnai** and **sna**i) in this command, the other parameter must also be specified.

Recovery

Re-enter the `chg-inopts` command specifying both the **cdpnnai** and **sna**i parameters.

E2246 Cmd Rej: Command Class Management feature must be enabled

Commands Used: `chg-cmd`, `chg-cmdclass`, `chg-secu-trm`, `chg-user`, `ent-user`, `rtrv-cmd`, `rtrv-cmdclass`

These commands or a configurable command class name are not allowed until the Command Class Management feature has been enabled.

Recovery

1. Display the status of feature access key controlled features that are purchased and enabled in the system. Enter the `rtrv-ctrl-feat` command. Verify that the Command Class Management feature is enabled.
2. If the Command Class Management feature is enabled, re-enter the command that generated this error message.
3. If necessary, enable the Command Class Management feature. Refer to the `enable-ctrl-feat` command in the Commands Manual for details.

4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2252 Cmd Rej: Day out of range

Commands Used: `rtrv-log`, `rtrv-seculog`, `set-date`

You specified an invalid range value for the day component. The day component must be in the range **01–31**. The day component must accurately reflect the number of days in the month indicated. For example, `sdate=060631` is an invalid parameter value because June has only 30 days.

Recovery

Re-enter the command specifying a valid value for the day within the range **01–31**.

E2253 Cmd Rej: Echo is not set for this terminal

Commands Used: `canc-echo`, `dact-echo`

This command stops the echoing of output from a terminal to one or more terminals. An attempt was made to stop the echoing of the terminal's output when the terminal was not able to echo its output.

Recovery

No action required. If you want to activate the echoing of the terminal's output, enter the `act-echo` command.

E2254 Cmd Rej: Minutes out of range

Commands Used: `act-lbp`, `rtrv-log`, `rtrv-seculog`, `set-time`, `chg-sid`

When the `mtpxlet` parameter is specified, the value for minutes (mm) must be in the range 00-59.

Recovery

Re-enter the command specifying a value for the minutes in the range **00–59**.

E2255 Cmd Rej: Month out of range

Commands Used: `rtrv-log`, `rtrv-seculog`, `set-date`

You specified an invalid range value for the month component. Enter the date in the form of *yy`mm`dd*, where *yy* is the year, *mm* is the month, and *dd* is the day of the month. The month component *mm* must be in the range **01 to 12**.

Recovery

Re-enter the command specifying a value for the month in the range 01 to 12.

E2256 Cmd Rej: Terminal is currently inhibited

Commands Used: `act-echo`

The terminal that the output would be sent to is inhibited. Terminal output cannot be echoed to a terminal that is inhibited.

Recovery

1. Display the status of all the terminals and printers on the system.
Enter the `rept-stat-trm` command.
2. Activate the inhibited terminal.
Enter the `rst-trm` or the `alw-trm` command specifying the number of the inhibited terminal.
3. Re-enter the `act-echo` command.

E2257 Cmd Rej: Terminal is currently out of service

Commands Used: `act-echo`, `inh-trm`, `rmv-trm`

[Table 5: Conditions that Generate Error Message E2257](#) describes the conditions that may have generated the error message.

Table 5: Conditions that Generate Error Message E2257

Command	Condition
<code>act-echo</code>	The terminal that the output would be sent to is currently out of service. Terminal output cannot be echoed to a terminal that is out of service.
<code>inh-trm</code> <code>rmv-trm</code>	An attempt was made to place a terminal out of service and that terminal was already out of service. Only terminals that are in service can be placed out of service.

Recovery

1. Display the status of the terminals.
Enter the `rept-stat-trm` command. The terminals that are in service are shown by the entry IS-NR in the PST field in the `rept-stat-trm` output.
2. Re-enter the command specifying a terminal, from the output of Step 1, that is in service.

E2258 Cmd Rej: NMULTCC and MULTCC parameters must be entered together

Commands Used: `chg-gsmopts`

If you specify the **nmultcc** parameter, you must also specify the **multcc** parameter.

Recovery

Whenever the **nmultcc** parameter is specified to change an existing value, the **multcc** parameter must also be specified.

For example, `chg-gsmopts:multcc=xxx:nmultcc=yyy` changes the value **xxx** to the value **yyy** in the GSM Options MULTCC list.

E2259 Cmd Rej: Terminal already echoing to specified terminal

Commands Used: `act-echo`

An attempt was made to echo the terminal's output to a terminal that is already being used for this purpose.

Recovery

No action is necessary since the terminal's output is being echoed to the specified terminal.

E2260 Cmd Rej: Disk access error - fixed disk

Commands Used: `act-user`, `dact-user`, `login`, `logout`

The command was entered and both TDM cards could not be found.

Recovery

1. Visually verify that both TDM cards are present in card locations **1114** and **1116**.
If they are not, place each TDM card in locations **1114** and **1116** making sure that each TDM is fully seated in the control shelf.
2. Display the status of the TDM cards.
Enter the `rept-stat-db` command. Both the active and the standby TDM cards should be in the IS-NR (in-service normal) state. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2261 Cmd Rej: Illegal attempt to delete yourself

Commands Used: `dlt-user`

The command was entered with the user ID of the user logged on the terminal that this command was issued from. This is not allowed by this command.

Recovery

1. Display the user IDs in the database.
Enter the `rtrv-user` command.
2. If you are not the user logged on to the terminal that issued the command that generated this error message, enter the `rept-stat-user` command to verify the user ID that is logged on to this terminal.
The terminal ID is shown in the system ID region of the terminal display.
3. Re-enter the command that generated this error message with a value for the **uid** parameter that is shown in the output of Step 1, but not the one that is logged on to this terminal, as shown in the output of Step 2.

E2262 Cmd Rej: Password too long, 12 maximum

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

The command was entered with a password that contained more than **12** alphanumeric characters. The password must contain the minimum required in `rtrv-secu-dflt`, and no more than twelve alphanumeric characters. The password is not case sensitive. For security reasons, the password is never displayed on the terminal.

Recovery

Enter the `rtrv-secu-dflt` command to see the default settings for passwords on this system.

minlen = minimum number of characters required.

alpha = minimum number of alpha characters required.

num = minimum number of number characters required.

punc = minimum number of punctuation characters required.

Re-enter the command specifying a password that contains from five to twelve alphanumeric characters.

E2263 Cmd Rej: Password does not contain enough characters

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

The command was entered with a password that contained less than five alphanumeric characters. The password must contain the minimum required in `rtrv-secu-dflt`, and no more than **12**

alphanumeric characters. The password is not case sensitive. For security reasons, the password is never displayed on the terminal.

Recovery

1. Display the default settings for passwords on this system.
Enter the `rtrv-secu-dflt` command. *minlen* = minimum number of characters required. *alpha* = minimum number of alpha characters required *num* = minimum number of number characters required *punc* = minimum number of punctuation characters required.
2. Re-enter the command specifying a password that contains from five-to-twelve alphanumeric characters.

E2264 Cmd Rej: Password verification failed

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

The user ID and password combination that was entered could not be found in the database.

Recovery

1. Verify that the user ID and password combination are correct.
2. Re-enter the command specifying the correct user ID and password combination.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2265 Cmd Rej: User currently logged on

Commands Used: `chg-user`

An attempt was made to change the attributes of a user ID, and that user was logged on the system. No changes can be made to a user ID while that user is logged on the system.

Recovery

1. Display the user IDs in the database.
Enter the `rtrv-user` command.
2. Display the users logged on the system.
Enter the `rept-stat-user` command.
3. Re-enter the command specifying a user ID that is shown in the output from Step 1 and not shown in the output from Step 2.

E2266 Cmd Rej: Class name is not an existing configurable command class

Commands Used: `chg-cmd`, `chg-secu-trm`, `chg-user`, `ent-user`

The arguments specified by the Configurable Command Class names (parameters **CC1** to **CC8**) must be set to **default** or provisioned to configurable command class names.

Recovery

Enter the `rtrv-cmdclass` command to find the list of valid configurable command class names; then re-enter the command specifying corrected names.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2267 Cmd Rej: Init-sys already in progress at another terminal

Commands Used: `init-sys`

You entered the `init-sys` command at your terminal, and someone else has entered the `init-sys` command already at another terminal, and it has started processing. When the `init-sys` command is entered, another `init-sys` command cannot be in progress on another port.

Recovery

Wait until the system is done re-initializing, then re-enter the `init-sys` command that generated this error message.

E2269 Cmd Rej: Unable to communicate with card at location

Commands Used: `disp-disk-dir`, `disp-tbl`, `init-imt-gpl`, `set-lba`, `set-tbl`

The command you keyed in failed to have its desired effect on the card. The reason may be a keyboarding error or a hardware error.

For the `disp-disk-dir` command, the card must be connected to at least one IMT bus.

Recovery

1. Re-enter the command that generated this error message specifying the correct **loc** parameter.
2. If this error message appears again, perform the following:
 - a) Press the **F-11** function key on the terminal, to toggle it to its alternate mode, and re-enter the command.
 - b) Investigate hardware factors including the LAN, the card, and the terminal.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2270 Cmd Rej: Card does not exist or is not an LPE

Commands Used: `init-card`

The card specified by the **loc** parameter cannot be found in the database or is not allowed by this command. All cards except HMUX, TDM, and the MDAL can be initialized by this command.

Recovery

1. Display the cards in the database.
Enter the `rtrv-card` command.
2. Re-enter the `init-card` command specifying a card location that is not an HMUX, TDM, or MDAL card.

E2271 Cmd Rej: Either LOC or APPL (not both) must be specified

Commands Used: `init-card`, `rept-meas`

The **appl** and **loc** parameters cannot be specified in the same command line. Both of these parameters are optional, but either the **loc** or **appl** parameter, but not both parameters, must be specified in the command.

Recovery

Re-enter the command specifying either the **loc** or the **appl** parameters, but not both.

E2272 Cmd Rej: Invalid GPL type for this command

Commands Used: `alw-card`, `init-card`, `init-imt-gpl`, `rst-card`

You specified an invalid **code** parameter or an invalid **appl** parameter. If the **serial** parameter is specified, the value specified for the **appl** parameter must be one of the following: **atmansi**, **ccs7itu**, **gls**, **sccp**, **ss7ansi**, **ss7gx25**, **stplan**, or **all**.

Recovery - `alw-card`, `init-imt-gpl`, `rst-card`

Re-enter the command that generated this error message specifying the correct **code** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - `init-card`

Re-enter the command that generated this error message specifying the correct **appl** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2273 Cmd Rej: Seconds out of range

Commands Used: `act-lbp`, `rtrv-log`, `rtrv-seculog`

You specified an invalid range for the seconds component. The seconds component of must be in the range **00–59**.

Recovery

Re-enter the command specifying the value for the seconds from **00-59**.

E2274 Cmd Rej: TT must be specified when enttype=tt

Commands Used: `rept-meas`

You specified the **enttype=tt** parameter without specifying the **tt** parameter, as required. The value for the **tt** parameter, which specifies the specific translation type to be reported, must be a numeric value from **0** to **255**.

Recovery

Re-enter the command specifying the **tt** parameter.

E2275 Cmd Rej: Day-to-hour measurement data not yet collected

Commands Used: `rept-ftp-meas`, `rept-meas`

The time that the command was entered to specify a measurement report for day-to-hour measurements (**type=avldth** or **type=mtcdth**) was between midnight (00:00) and 59 minutes past midnight (00:59). Day-to-hour measurement collection starts at midnight and are updated on an hourly basis. A day-to-hour measurement report cannot be generated before the first hour of measurements have been collected.

Recovery

Wait until after 1:00 AM (01:00) and re-enter the command that generated this error message.

E2276 Cmd Rej: Day-to-hour measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

Day-to-hour collection and report processing cannot be in progress:

- When report type **mtcd** is specified.
- When report type **mtcdth** is specified

Recovery

Re-enter the command after collection is complete. (The prior period is no longer accessible).

E2277 Cmd Rej: Daily measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

Daily collection and report processing cannot be in progress when report types **mtcd** or **avid** are specified.

Recovery

Re-enter the command specifying either the (**type=avld** or **type=mtcd**) parameter after routine collection is complete.

E2278 Cmd Rej: 30-minute measurement collection in progress

Commands Used: `chg-ctrl-feat`, `chg-measopts`, `rept-ftp-meas`, `rept-meas`

Half-hourly collection and report processing cannot be in progress when report type **comp**, **systot**, **avl**, or **gtwy** is specified.

OR

The `rept-meas` command was entered with either the **type=systot**, **type=comp**, or **type=avl** parameter during routine collection.

OR

The `rept-ftp-meas` command was entered with either the **type=systot**, **type=comp**, **type=gtwy**, or **type=avl** parameter during routine collection.

Recovery

To get a report before routine collection started, do one of the following actions:

- Enter the command specifying the **period=last** parameter.

OR

- Enter the command without specifying the **period** parameter.

OR

- Re-enter the command after the 30-minute measurement collection is complete. (The prior period is no longer accessible).

E2279 Cmd Rej: 5-minute measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

5-minute collection and report processing cannot be in progress when report type **nm** is specified.

Recovery

Re-enter the command after the 15-minute measurement collection is complete. (The prior period is no longer accessible).

E2280 Cmd Rej: Invalid PERIOD for this TYPE

Commands Used: `rept-ftp-meas`, `rept-meas`

For the `stplan-avl` reports (`enttype=stplan` and `type=avl` parameters), if the `appl` parameter is specified, the `period=active` and `period=all` parameters cannot be specified.

Recovery

1. Refer to the descriptions of the `rept-meas` command and the `rept-ftp-meas` command in the *Commands Manual* for valid parameter combinations for the command.
2. Re-enter the command, specifying compatible **type** and **period** parameters.

E2281 Cmd Rej: Invalid ENTTYPE for this TYPE

Commands Used: `rept-ftp-meas`, `rept-meas`

An invalid parameter combination has been entered.

Recovery

1. Refer to the descriptions of the `rept-meas` command and the `rept-ftp-meas` command in the *Commands Manual* for valid parameter combinations for the command.
2. Re-enter the command, specifying compatible **type** and **enttype** parameters.

E2283 Cmd Rej: QH, HH, or DAY cannot be specified when PERIOD=LAST

Commands Used: `rept-ftp-meas`, `rept-meas`

When the `period=last` parameter is specified, the `hh` parameter, the `qh` parameter, or the `day` parameter cannot be specified.

Recovery

Perform one of the following:

- Re-enter the command specifying the **period** parameter with values **last**, **active**, or **all**, without specifying the **hh**, **qh**, or the **day** parameter.

OR

- Re-enter the command specifying the **period=specific** and the **hh**, **qh**, or the **day** parameter.

E2284 Cmd Rej: QH, HH, or DAY cannot be specified when PERIOD=ACTIVE

Commands Used: `rept-ftp-meas`, `rept-meas`

When the **period=active** parameter is specified, the **hh** parameter, the **qh** parameter, and the **day** parameter cannot be specified.

Recovery

Perform one of the following:

- Re-enter the command specifying the **period** parameter with values **last**, **active**, or **all**, without specifying the **hh**, **qh**, or the **day** parameter.

OR

- Re-enter the command specifying the **period=specific** and the **hh**, **qh**, or the **day** parameters.

E2285 Cmd Rej: QH, HH, or DAY cannot be specified when PERIOD=ALL

Commands Used: `rept-meas` You specified the **hh**, **qh**, or the **day** parameter with the **period=all** parameter. If the **period=all** parameter is specified, then the **hh** and **qh** parameters cannot be specified.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **period** parameter with values **last**, **active**, or **all** without specifying the **hh**, **qh**, or the **day** parameter.

OR

- Re-enter the **rept-meas** command specifying the **period=specific** and the **hh**, **qh**, or the **day** parameters.

E2286 Cmd Rej: QH or HH must be specified when PERIOD=SPECIFIC

Commands Used: `rept-ftp-meas`, `rept-meas`

You specified the **period=specific** parameter, and the **hh** or **qh** parameter was not specified.

Recovery

Re-enter the command specifying the **period=specific** parameter, and the **hh** or **qh** parameters.

E2287 Cmd Rej: ACTIVE not available for type-enttype combination

Commands Used: `rept-meas`

The **period=active** parameter cannot be specified when the **enttype=stp** parameter or the **enttype=tt** parameter is specified.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **period=active** parameter with an acceptable parameter combination.

OR

- Re-enter the **rept-meas** command specifying either **last** or **specific** for the **period** parameter.

E2288 Cmd Rej: Either LSN or LOC and LINK must be specified

Commands Used: `rept-meas`

You specified the link entity **type**, and the **lsn** parameter or the **loc** and **port/link** parameters were not specified.

Recovery

Re-enter the **rept-meas** command specifying the **lsn** parameter or the **loc** and **port/link** parameters.

E2289 Cmd Rej: LOC and LINK must be specified when PERIOD=ALL

Commands Used: `rept-meas`

For entity type **avl**, if **period=all** is specified, the **loc** and **port** parameters must be specified.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **period=all** parameter and the **loc** and **port/link** parameters.

OR

- Re-enter the **rept-meas** command specifying the values **last**, **active**, or **specific** for the **period** parameter, with the **loc** and **port/link** parameters optional.

E2290 Cmd Rej: Hourly measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered with either the `type=avldth`, `type=ntcdth`, or `type=mtch` parameter during routine collection. Hourly collection and report processing cannot be in progress when report type `mtch` is specified.

Recovery

Re-enter the command after collection is complete. (The prior period is no longer accessible).

E2291 Cmd Rej: PERIOD must be 1 hour boundary for report type

Commands Used: `rept-ftp-meas`, `rept-meas`

You set the `period` parameter to **specific**, and either the `hh` parameter with final two digits of **30** or the `qh` parameter with final two digits of **15**, **30**, or **45**. The type of report you selected, however, requires that you set the final two digits of the `hh` or `qh` parameter to **00**. Day-to-hour measurement collection starts at midnight and is updated on an hourly basis.

Recovery

Re-enter the command, with the `hh` parameter properly set. Acceptable values range from **0** to **2400**, in increments of **1** hour.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2292 Cmd Rej: Card does not exist or is not a LIM (LOC)

Commands Used: `act-slk`, `alw-slk`, `blk-slk`, `dact-slk`, `ent-slk`, `inh-slk`, `rept-meas`, `rtrv-slk`, `ublk-slk`, `unhb-slk`

The card specified by the `loc` parameter cannot be found in the database, or is not a LIM card.

The `limatm`, `lime1atm`, `lmds0i`, `limocu`, `limv35`, `lime1`, `limt1`, `limch`, and `dcm` card types are the only valid card types for this command.

Recovery

1. Enter the `rtrv-card` command to display the cards in the database.
2. Re-enter the command specifying a card location shown in Step 1 for which the `TYPE` field in the `rtrv-card` command output is `limatm`, `lime1atm`, `lmds0`, `limocu`, `limv35`, `lime1`, `limt1`, `limch`, or `dcm`.

E2293 Cmd Rej: TRM parameter not valid for type-enttype combination

Commands Used: `rept-meas`

When **enttype=lnp**, the **trm** parameter cannot be specified because LNP measurements can be written only to the FTA. To retrieve this data, use the procedure described with the `act-file-trns` command information.

Recovery

Perform one of the following:

- Re-enter the `rept-meas` command that generated this error message, and change either the **enttype** or **type** parameters.

OR

- Re-enter the `rept-meas` command that generated this error message, and omit the **trm** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2294 Cmd Rej: LSN and LOC parms are mutually exclusive

Commands Used: `rept-meas`

The **lsn** and **loc** parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the **lsn** or **loc** parameter.

E2295 Cmd Rej: LSN and LINK parms are mutually exclusive

Commands Used: `rept-meas`

The **lsn** and **link** parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the **lsn** or **link** parameter.

E2296 Cmd Rej: Both LOC and LINK must be specified

Commands Used: `rept-meas`, `rtrv-slk`

If the **link** parameter is specified, the **loc** parameter must be specified. For the `rept-meas` command, the **enttype=link** parameter cannot be specified without specifying both the **loc** and **link** parameters.

For the `rept-meas` command:

If the **link** parameter is specified, the **loc** parameter must be specified.

For the `rtrv-slk` command:

If the **link** parameter is specified the **loc** parameter must be specified. The **loc** parameter can be specified without the **link** parameter. If the **link** parameter is specified the **loc** parameter must be specified. The **loc** parameter can be specified without the **link** parameter.

Recovery

Re-enter the command, if the **link** parameter is specified the **loc** parameter must be specified.

E2297 Cmd Rej: TT parameter valid only when ENTTYPE=TT

Commands Used: `rept-meas`

You attempted to specify the **tt** parameter with a parameter other than **enttype=tt**. The `rept-meas:type=systot:enttype=tt` command is the only valid parameter combination for the **tt** parameter.

The **enttype=tt** parameter must be specified before the **tt** parameter can be specified.

Recovery

Re-enter the `rept-meas` command as follows:

`rept-meas:type=systot:enttype=tt:tt=<0-255>` where **<0-255>** is the specific translation type to be reported.

E2298 Cmd Rej: LOC parameter not valid for this ENTTYPE

Commands Used: `rept-meas`

You specified the **loc** parameter, but the **enttype** specified was not valid. The card in the location specified by the **loc** parameter must match the type of card specified in the **enttype** parameter.

Recovery

1. Review the specified parameters for this ENTTYPE in the *Commands Manual*.
2. Perform one of the following:
 - a) Re-enter the `rept-meas` command specifying the **enttype** from the previous attempt without specifying the **loc** parameter.
OR
 - b) Re-enter the `rept-meas` command specifying **enttype=link** and include the **loc** and **port** parameters.
OR
 - c) Re-enter the `rept-meas` command specifying **enttype=stplan** and include the **loc** parameter.

E2299 Cmd Rej: LINK parameter valid only when ENTTYPE=LINK

Commands Used: `rept-meas`

If the **link** parameter is specified, the **enttype** must be equal to **link**. The **enttype=link** parameter must be specified before the **link** parameter can be specified. If the **enttype=lnp** parameter is specified, then the **link** parameter cannot be specified.

Recovery

Perform one of the following:

- Re-enter the `rept-meas` command specifying the **port/link** parameter and the **enttype=link**.
OR
- Re-enter the `rept-meas` command without specifying the **port/link** parameters.

E2300 Cmd Rej: LSN must be specified

Commands Used: `rept-meas`

If the **type=gtwy:enttype=lnkset, lsdestni, lsorigni, or lsonismt**), only the **lsn** parameter can be specified.

For the `dlt-rtx` command, the **lsn** parameter must be specified if the **all** parameter is not specified.

Recovery

Re-enter the command specifying the **lsn** parameter. Refer to the *Commands Manual* for assistance.

E2301 Cmd Rej: LSN parameter not valid for type-enttype combination

Commands Used: `rept-meas`

The **lsn** parameter cannot be specified with the following parameters:

`enttype=stp/tt/stplan/origni/origninc/lnp/np/mapscrn` or `type=systot`.

The linkset specified by the **lsn** parameter must contain the link specified by the **enttype=link** and **type** parameters. If the **enttype=lnp** parameter is specified, then the **lsn** parameter cannot be specified.

Recovery

Perform one of the following:

- Re-enter the command specifying the **type=systot** parameter, without specifying the **lsn** parameter.
OR
- Re-enter the command specifying any other valid combination of **type** and **enttype** parameters with the **lsn** parameter.

- Refer to the *Commands Manual* for a complete list of valid parameter combinations for this command.

E2302 Cmd Rej: PERIOD must be 1/2 hour boundary

Commands Used: `rept-ftp-meas`, `rept-meas`

A half-hour boundary must be specified for the **hh** parameter, except for report type **mtch**; an hourly boundary must be specified for report type **mtch** (that is, only half hours ending in 00, such as 0100, 0200 or 0300).

Recovery

Re-enter the command specifying the **period=specific** and **hh** parameters, and make sure that the values for the minutes portion of the **hh** parameter are either **00** or **30**.

E2303 Cmd Rej: Unknown LSN

Commands Used: `dbg-ddb`, `rept-meas`, `rept-stat-iptps`

The specified linkset name must exist in the database. For the `dbg-ddb` command, the linkset specified by the **lsn** parameter must already exist in the Linkset table.

Recovery

1. Wait until the in progress on-demand measurements report or audit report is finished printing.
2. Re-enter the command that generated this message. See the *Commands Manual* for more information about the parameters to be used with this command.

E2304 Cmd Rej: Invalid TYPE

Commands Used: `rept-meas`, `rept-stat-lnp`

The following Recovery procedures list the appropriate remedial action to take for each command that generates this error message.

Recovery - `rept-meas`

You entered an invalid combination of the **type** (report type) and **enttype** (entity type) parameters.

Refer to the command in the *Commands Manual* for information on the correct combinations of values and re-enter the `rept-meas` command.

Recovery - `rept-stat-lnp`

You specified a value other than `sccp-all` for the **card** parameter. For the `rept-stat-lnp` command, the only valid value for the **card** parameter is **sccp-all**.

Re-enter the command `rept-stat-lnp:card=sccp-all`.

E2305 Cmd Rej: On demand report currently being printed

Commands Used: `rept-ftp-meas`, `rept-meas`

The system is currently printing the on-demand report that generated this error message. Only one `rept-meas` command can be in progress at any one time.

Recovery

Perform one of the following:

- Re-enter the command specifying another type of on-demand measurements report.
OR
- Wait until the on-demand measurements report that generated this error message has finished printing, then re-enter the command that generated this error message.

E2306 Cmd Rej: NZO is not valid for this TYPE

Commands Used: `rept-meas`

The `nzo` parameter was specified with report type `systot`, `comp`, `mtcd`, `mtcdth`, `mtch`, `mtcs`, `nm`, `gtwy`, or `rbase`. The `nzo` parameter is used only for entity types `avl`, `avld`, and `avldth`.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the report types `avl`, `avld`, or `avldth` and the `nzo` parameter.
OR
- Re-enter the command specifying any of the following the report types: `systot`, `comp`, `mtcd`, `mtcdth`, `mtch`, `mtcs`, `nm`, `gtwy`, or `rbase`, without specifying the `nzo` parameter.

E2307 Cmd Rej: QH or HH is not valid for this TYPE

Commands Used: `rept-ftp-meas`, `rept-meas`

The `hh` parameter and the `qh` parameter cannot be specified when report type `avld`, `mtcd`, `nm`, `rbase`, or `mtcs` is specified.

The `hh` parameter must specify a half-hourly boundary (the end of the requested half-hour for the report) for valid report types (`mtcd` and `nm` are excluded).

The `qh` parameter must specify a quarter-hourly boundary (the end of the requested quarter-hour for the report) for valid report types (`avld`, `mtcd`, `nm`, `rbase`, and `mtcs` are excluded).

Recovery

Re-enter the command without specifying the `hh` or `qh` parameter.

E2309 Cmd Rej: NI required

Commands Used: `rept-meas`

If `nc` is specified for `enttype=originc reports`, `ni` must also be specified.

Recovery

Re-enter the `rept-meas` command that generated this error message specifying the correct `ni` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2310 Cmd Rej: File already exists

You attempted to load a file with a name that matches a file that is already in the database.

Recovery

Re-enter the command that generated this error message specifying the correct file name.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2312 Cmd Rej: Invalid SCSI device syntax

Commands Used: `disp-disk`

You either entered the wrong SCSI syntax, or had a hardware failure.

Recovery

Re-enter the `disp-disk` command that generated this error message specifying the correct SCSI syntax.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2314 Cmd Rej: Invalid filename entered

Commands Used: `chg-db`, `chg-tbl`, `copy-fta`

A command was entered that specified an invalid filename.

For the `chg-db` command, the value specified for the file parameter must have the correct extension.

Recovery

Re-enter the command that generated this error message specifying the correct filename or correct extension.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2316 Cmd Rej: Class name is not an existing command class name

Commands Used: `chg-cmdclass`, `rtrv-cmd`, `rtrv-cmdclass`

The argument specified by the **CLASS** parameter must be a valid configurable or non-configurable command class name.

Recovery

1. Display a list of valid command class names.
Enter the `rtrv-cmdclass` command.
2. Re-enter the command specifying a valid configurable or non-configurable command class name.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2317 Cmd Rej: Invalid table Id

Commands Used: `aud-data`, `chg-tbl`

The value specified for the **id** parameter (`chg-tbl` command) or the **tblid** parameter (`aud-data` command) must already exist.

Recovery

Re-enter the command that generated this error message specifying the correct value.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2318 Cmd Rej: Invalid file length

Commands Used: `chg-tbl`

You entered an invalid value for the **filelength** parameter.

Recovery

Re-enter the `chg-tbl` command that generated this error message specifying the correct **filelength** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2319 Cmd Rej: New class name cannot be the same as an existing class name

Commands Used: `chg-cmdclass`

The new command class name cannot be the duplicate of an existing configurable or non-configurable command class name. You entered this command specifying the same name as an existing command class name. These names cannot be the same.

Recovery

1. Display a list of valid command class names.
Enter the `rtrv-cmdclass` command.
2. Re-enter the `chg-cmdclass` command specifying a valid command class name that is **not** on the list.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2320 Cmd Rej: TYPE can only be set to TELNET, SEAS, EMSALM or NONE

Commands Used: `chg-trm`

For terminals 17 -40, the value of the **type** parameter must be **telnet**, **emsalm**, **seas**, or **none**.

The **type=emsalm** parameter can be specified for terminal numbers from 1 to 16.

Recovery

Re-enter the `chg-trm` command specifying the correct **type** parameter.

E2321 Cmd Rej: Communication Settings are not allowed on TELNET terminals

Commands Used: `chg-trm`

Communications parameters are not valid for non-serial terminals, which are any terminal number 17 or above. Communications settings are not applicable when **type=telnet**. Refer to the *Commands Manual* for the appropriate communication parameters.

Recovery

Re-enter the `chg-trm` command for the appropriate parameter combination:

- If the terminal type is **telnet**, the terminal number must be 17 or above, and you cannot specify communication settings.

OR

- If you intend to use communications settings, you must specify a terminal number in the range from 1 to 16, and cannot specify **type=telnet**.

E2322 Cmd Rej: Alias defined as a destination point code

Commands Used: `chg-dstn`, `ent-dstn`

The value specified for the alias parameter already exists as a destination point code. These commands do not allow an alias point code to be the same as a destination point code.

Recovery

1. Display all the destination point codes and alias point codes in the database.
Enter the `rtrv-dstn` command specifying no parameters. The destination point codes are shown in the `DPCA`, `DPCI`, and `DPCN` fields of the output. The alias point codes are shown in the `ALIASA`, `ALIASI`, and `ALIASN` fields of the output.
2. For the `ent-dstn` and `chg-dstn` commands, enter the `rtrv-sid` command to verify the site point codes and capability point codes in the system.
The site point codes are shown in the `PCA`, `PCI`, and `PCN` fields of the output. The capability point codes are shown in the `CPCA`, `CPCI`, `CPCN` fields of the output.
3. Re-enter the command specifying a point code that does not match the site point code or capability point code, and that does not match any destination point codes or alias point codes.

E2323 Cmd Rej: Terminals 1-16 cannot be set to TYPE=TELNET

Commands Used: `chg-trm`

You cannot specify terminals 1 to 16 as **type=telnet**. Only terminals IDs 17 and above can be telnet terminals.

Recovery

Re-enter the `chg-trm` command for the appropriate parameter combination. If the terminal type must be **telnet**, you must specify a terminal ID number 17 or above. If you are using terminal IDs 1 to 16, the type cannot be **telnet**.

E2324 Cmd Rej: Alias not defined

Commands Used: `dlt-tt`, `rtrv-tt`

The specified alias cannot be found. The following Recovery procedures list by command the remedial action to take.

Recovery `dlt-tt`

1. Display the aliases and translation types. Enter the `rtrv-tt` command.
2. Re-enter the `dlt-tt` command specifying one of the aliases from Step 1.

Note:

To delete an alias, both the alias and the translation type must be specified, and both must already exist in the database for the specified network type.

Recovery - rtrv-tt

Perform one of the following actions:

- Verify that the **alias** has been entered correctly and re-enter the command.
- OR
- Enter the `rtrv-tt` command without specifying any parameters.

E2325 Cmd Rej: Alias type matches DPC type

Commands Used: `chg-dstn`, `ent-dstn`

The alias parameter must be specified with a different point code type than the **dpc** parameter. A specified alias type cannot already be defined as a destination address.

The **aliasa** and **dpca** parameters cannot be specified together in the command. The **aliasi** and **dpci** parameters and the **aliasn** and **dpcn** parameters cannot be specified together in the command if the *prefix* subfields are the same (both are spare or both are non-spare).

Recovery

Re-enter the command specifying the appropriate destination point code and alias point code parameter combinations.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2326 Cmd Rej: APC not defined as destination point code

Commands Used: `chg-ls`, `ent-ls`

The specified adjacent point code could not be found in the Destination Point Code table. For an adjacent point code to be assigned to a linkset, it must be defined in the Destination Point Code table.

Recovery

1. Display all the destination point codes in the Destination Point Code table.
Enter the `rtrv-dstn` command.
2. Re-enter the command specifying a point code from the output in Step 1.
OR
 1. Add the specified point code to the Destination Point Code table. Enter the `ent-dstn` command.

2. Re-enter the command specifying the point code that generated this error message.

E2328 Cmd Rej: CLLI not defined in route table

Commands Used: `rtrv-dstn`, `rtrv-rte`

You cannot specify the `clli` parameter if the value for the `clli` parameter is not defined in the Route table. If the `clli` parameter is specified, it must be defined in the Route table.

Recovery

Re-enter the command specifying no parameters to display all routes (`rtrv-rte`) or all destination point codes (`rtrv-dstn`) and all the CLLI values for these routes and destination point codes in the database.

E2329 Cmd Rej: IPSM card not equipped

Commands Used: `chg-trm`

If the value specified for the `type` parameter is `telnet`, `seas`, or `emsalm`, and a Telnet terminal is used (IDs 17-40), then an **IPSM** card must be equipped in the system. Parameters for a telnet type terminal cannot be changed unless an **IPSM** card is used as the target terminal.

Recovery

1. Display all the terminals. Enter the `rtrv-trm` command.
2. Re-enter the `chg-trm` command for an equipped **IPSM** card. If the **IPSM** card is not equipped, equip it and then enter the `chg-trm` command to continue changing the terminal parameters. Refer to the *Database Administration Manual - Systems Management* manual for assistance.

E2330 Cmd Rej: LSN must be provided with ALL=NO

Commands Used: `dlt-rte`

You specified the `all=no` parameter or you did not specify `all`, and the `lsn` parameter was not entered. If you use the `all=no` parameter, you must enter the `lsn` parameter.

Recovery

Re-enter the `dlt-rte` command specifying the `lsn` parameter.

E2331 Cmd Rej: Cannot specify LSN parameter with ALL=YES

Commands Used: `dlt-rte`

You specified both the **lsn** and **all=yes** parameters. The **lsn** parameter cannot be specified with the **all=yes** parameter. To delete a route, you must use the **lsn** parameter.

Recovery

1. To delete all routes for a given route entry, re-enter the `dlt-rte` command specifying the **all=yes** parameter.
Do not use the **lsn** parameter.
2. To delete a route, re-enter the `dlt-rte` command specifying the **lsn** parameter.
Do not use the **all=yes** parameter.

E2332 Cmd Rej: Point code defined as an alias

Commands Used: `chg-ls`, `ent-dstn`, `ent-ls`

The value specified for the destination point code parameter already exists as an alias point code. An alias point code cannot already be defined as a destination point code.

Recovery

1. Enter the `rtrv-dstn` command specifying no parameters to display all the destination point codes and alias point codes in the database.
The destination point codes are shown in the `DPCA`, `DPCI`, `DPCN`, and `DPCN24` fields of the output. The alias point codes are shown in the `ALIASA`, `ALIASI`, and `ALIASN` fields of the output.
2. Enter the `rtrv-sid` command to verify the site point codes and capability point codes in the system.
The site point codes are shown in the `PCA`, `PCI`, `PCN`, and `PCN24` fields of the output. The capability point codes are shown in the `CPCA`, `CPCI`, `CPCN`, and `CPCN24` fields of the output.
3. Re-enter the command specifying a point code that does not match the site point code or capability point code, and does not match any destination point codes or alias point codes.

E2333 Cmd Rej: DPC is already being used

Commands Used: `ent-dstn`

The specified destination point code already exists in the database. The specified destination address cannot already exist in the Destination entity set.

Recovery

1. Display all destination point codes in the database.
Enter the `rtrv-dstn` command.
2. Display the point code of this EAGLE 5 ISS and its capability point code.
Enter the `rtrv-sid` command.

3. Re-enter the `ent-dstn` command specifying a point code that is not shown in the outputs of Steps 1 and 2.

E2334 Cmd Rej: DPC defined as linkset APC

Commands Used: `dlt-dstn`

The specified destination point code is defined as a linkset adjacent point code in the database. The destination point code to be deleted cannot be defined as a linkset adjacent point code.

Recovery

1. Enter the `rtrv-ls` to display all linkset adjacent point codes in the database and to verify the specified point code is a linkset adjacent point code.
2. Enter the `dlt-ls` command specifying the point code that generated this error message.
3. Re-enter the `dlt-dstn` command that generated this error message.

E2335 Cmd Rej: CLLI is not identical to that of matching Destination

Commands Used: `chg-ls`, `ent-ls`, `rtrv-dstn`

You assigned an invalid value to the `clli` parameter. The `clli` or the destination being entered must match the `clli` of the current site.

Recovery

Re-enter the command that generated this error message specifying the correct `clli` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2336 Cmd Rej: GWSA, GWSM, GWSD are invalid without SCRSET specified

Commands Used: `chg-ls`, `ent-ls`

There is currently no gateway screening screen set assigned to this linkset. If the `gwsa=on`, `gwsm=on`, and `gwsd=on` parameters are specified, the `scrn` parameter must be specified.

Recovery

Re-enter the command specifying the `scrn` parameter to apply a screen set and make the parameters `gwsa`, `gwsm`, or `gwsd` valid.

E2337 Cmd Rej: If GWSA=OFF then GWSD must also be OFF

Commands Used: `chg-ls`, `ent-ls`

The `gwsd=on` parameter can be specified only if the `gwsa=on` parameter is specified. Gateway Screening MSU discard must be turned off (`gwsd=off`) for a linkset, if gateway screening is turned off (`gwsa=off`) for that linkset. If the `gwsd=on` parameter is specified, the `gwsa=on` parameter must be specified.

Recovery

Re-enter the command specifying the `gwsa=off` and `gwsd=off` parameters.

E2338 Cmd Rej: Invalid CLLI

Commands Used: `ent-dstn`, `rtrv-dstn`

You assigned an invalid value to the `clli` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `clli` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2339 Cmd Rej: PC/CLLI does not match current PC/CLLI of the STP

Commands Used: `ent-dstn`, `rtrv-dstn`

You assigned an invalid value to the `clli` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `clli` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2340 Cmd Rej: Invalid point code

Commands Used: `chg-dstn`, `chg-rte`, `chg-sid`, `chg-x25-dstn`, `dlt-dstn`, `dlt-rte`, `ent-dstn`, `ent-rte`, `ent-x25-dstn`, `rtrv-dstn`, `rtrv-rte`, `rtrv-sid`

The specified point code either could not be found in the database or was not in the format required by this command. The point code `0-0-0` is not allowed. The following Recovery procedures list by command the remedial action to take for this error message.

Recovery - `chg-dstn`, `chg-rte`, `chg-x25-dstn`, `dlt-rte`, `ent-rte`, `ent-x25-dstn`, `rtrv-dstn`, `rtrv-rte`

1. Display the Destination Point Code table. Enter the `rtrv-dstn` command specifying no parameters.
2. Re-enter the command specifying a point code shown in the output of Step 1.

Recovery - `chg-sid`

1. Display the Capability Point Code table. Enter the `rtrv-sid` command specifying no parameters.
2. Re-enter the `chg-sid` command specifying a valid point code that is in the Capability Point Code table and, does not match the EAGLE 5 ISS point code and destination point code.

Recovery - `dlt-dstn`

1. Display the point codes in the Destination Point Code table. Enter the `rtrv-dstn` command specifying no parameters.
2. Display the linksets in the database. Enter the `rtrv-ls` command.
3. Re-enter the `dlt-dstn` command specifying a point code that is in the Destination Point Code table (output of Step 1) and that is not shown in the output of Step 2.

Recovery - `ent-dstn`

If the system is configured to use ANSI point codes, the network indicator (**ni**) value of the specified **dpc** parameter must be equal to or greater than 6 when the cluster value (**nc**) is 0.

1. Display the destination point codes in the Destination Point Code table.
Enter the `rtrv-dstn` command specifying no parameters.
2. Display the point code and the capability point code of the EAGLE 5 ISS.
Enter the `rtrv-sid` command.
3. Re-enter the `ent-dstn` command specifying a point code that is not listed in either of the outputs of Step 1 and Step 2.
Refer to the `ent-dstn` command description in the *Commands Manual* for guidelines for specifying point codes.

E2341 Cmd Rej: May not change adjacent point code type

Commands Used: `chg-ls`

The command was entered with an adjacent point code (**apca**, **apci**, or **apcn**) whose point code type was different from the point code type of the adjacent point code currently specified for that linkset. The new adjacent point code must be of the same point code type as the current adjacent point code of the linkset. The point code type for the **spc** paramter can not change.

Recovery

1. Display the linkset that generated this error message.
Enter the `rtrv-ls` command specifying the linkset name (**lsn**) that generated this error message.
 - a) If the adjacent point code is an ANSI point code, the adjacent point code of the linkset is shown in the **APCA** field of the `rtrv-ls` output.
 - b) If the adjacent point code is an ITU-I point code, the adjacent point code of the linkset is shown in the **APCI** field of the `rtrv-ls` output.

- c) If the adjacent point code is an ITU-N point code, the adjacent point code of the linkset is shown in the `APCN` field of the `rtrv-ls` output.
2. Display the point codes in the Destination Point Code table.
Enter the `rtrv-dstn` command. The ANSI destination point codes are shown in the `DPCA` field; the ITU-I destination point codes are shown in the `DPCI` field; the ITU-N destination point codes are shown in the `DPCN` field, and the 24-bit ITU-N destination point codes are shown in the `DPCN24` field of the `rtrv-dstn` output.
3. Re-enter the `chg-ls` command specifying a destination point code, from Step 2, whose point code type matches the point code type of the adjacent point code shown in Step 1.

E2342 Cmd Rej: Links assigned to linkset

Commands Used: `dlt-ls`, `chg-ls`

If the IPSG linkset contains links, then the **adapter** parameter cannot be specified. The linkset can be deleted only after all links associated with the linkset have been deleted.

Recovery

1. Display the current linkset configuration.
Enter the `rtrv-ls` command, specifying the linkset name.
2. Deactivate all links in the linkset.
Enter the `dact-slk` command.
3. Confirm the link status is Out-of-Service - Maintenance Disabled (OOS-MT-DSBLD).
Enter the `rept-stat-ls` command, specifying the linkset name.
4. Delete all links in the associated linkset.
Enter the `dlt-slk` command.
5. Re-enter the `dlt-ls` command that generated this error message.

E2343 Cmd Rej: Linkset APC/SAPC is already being used

Commands Used: `chg-ls`, `ent-ls`

The specified adjacent point code (**apc**) or secondary adjacent point code (**sapc**) is already assigned to another linkset. The specified adjacent point code cannot be assigned to any other linkset. Only one linkset can be assigned to an **apc** or **sapc**.

Recovery

1. Display the linksets in the database. Enter the `rtrv-ls` command.
2. Re-enter the command specifying a value for the **apc** or **sapc** that is not shown in the output of Step 1.

E2345 Cmd Rej: Linkset already defined

Commands Used: `chg-ls`, `ent-ls`

You cannot add a linkset that is already in the database. The specified linkset is already in the database.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command.
2. Re-enter the command specifying a linkset name that is not shown in Step 1.

E2346 Cmd Rej: Linkset not defined

Commands Used: `chg-gtttsel`, `chg-ls`, `chg-rte`, `chg-rtx`, `dlt-gtttsel`, `dlt-ls`, `dlt-rtx`, `ent-appflt`, `ent-gtttsel`, `ent-rte`, `ent-rtx`, `ent-slk`, `rtrv-gtttsel`, `rtrv-gtwy-acthresh`, `rtrv-ls`, `rtrv-rte`, `rtrv-rtx`, `set-gtwy-acthresh`, `tst-msg`

The linkset specified by the `lsn` parameter must already exist. All linksets for the route must be defined, using the `ent-ls` command before this command can be entered.

For the `ent-slk` command, the value that is specified for the `slc` parameter cannot be in use for the specified linkset.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command specifying no parameters.
2. Re-enter the command specifying a linkset name from the output in Step 1.

E2347 Cmd Rej: Linkset table full

Commands Used: `ent-ls`

The Linkset table contains the maximum **1024** linksets and an attempt was made to add another linkset. To add the new linkset, you can either change an existing linkset, or delete an existing linkset and add the new one.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command.
2. To change an existing linkset, enter the `chg-ls` command specifying the new linkset information.
OR
 - a) Delete an existing route. Enter the `dlt-ls` command.

- b) Re-enter the command that generated this error message.

E2348 Cmd Rej: Linkset referenced by route

Commands Used: `dlt-ls`

The linkset being deleted is referenced by the route table (either a point code or routeset) or the rtx table. If the linkset is referenced by the historic routeset of any destination, then this command cannot be entered.

Recovery

1. Display routes using the `rtrv-rte:lsn=(linkset name being deleted)` to show all routes where the lsn is referenced.
Enter the `dlt-rte` command to remove the linkset.
2. For the rtx table enter the `rtrv-rtx:lsn=(linkset name being deleted)` and a `rtrv-rtx:ilsn=(linkset name being deleted)` then using the `dlt-rtx` command remove the linkset.

E2349 Cmd Rej: Linkset Type for Network/Cluster route can't be A or E

Commands Used: `ent-rte`,

If the specified destination address is a network address (`ni-*-*`), or network cluster address (`ni-nc-*`), the linkset type (see the `chg-ls` command) used in the route must be b, c, or d.

Recovery

Re-enter the command specifying a B, C, or D linkset. Refer to the *Commands Manual* for assistance.

E2350 Cmd Rej: At most two linksets can be assigned same cost

Commands Used: `chg-rte`, `ent-rte`

The 6-Way Loadsharing on Routesets feature must be turned on before more than 2 routes can be provisioned with the same relative cost.

Recovery

1. Display the routes and their cost values.
Enter the `rtrv-rte` command.
2. Re-enter the command specifying a value for the `rc` parameter that is not being used or is used by one linkset or less.

E2351 Cmd Rej: Linkset not assigned in routeset

Commands Used: `chg-rte`, `dlt-rte`, `rtrv-rte`

The linkset specified by the `lsn` parameter must exist in the routeset of the destination table entry.

Recovery - `chg-rte`, `dlt-rte`

1. Display the destination's routesets using the `rtrv-rte:dpc=<name of the dpc>` command. Refer to the *Database Administration Manual - SS7* for assistance.
2. Re-enter the command specifying an `lsn` value shown in the output of Step 1.

Recovery - `rtrv-rte`

Re-enter the `rtrv-rte` command without specifying the `lsn` parameter.

E2353 Cmd Rej: Routeset is full

Commands Used: `ent-rte`

The specified routeset already has **six** routes in it. A routeset can contain up to **six** routes.

Recovery

Re-enter the command specifying a different routeset to add the route to.

OR

1. Display the routes using the `rtrv-rte` command. Refer to the *Database Administration Manual - SS7* for assistance.
2. Delete any unnecessary routes or choose a different routset.
3. Re-enter the command that generated this error message.

E2354 Cmd Rej: Routeset must be empty

Commands Used: `dlt-dstn`

You tried to delete the destination point code (DPC) from the database while there were routes in the database assigned to the DPC. A DPC cannot be deleted if there are any routes assigned to it.

Recovery

1. Display the routes assigned to the DPC.
Enter the `rtrv-rte` command specifying the DPC that generated this error message.
2. Remove the routes from the routset using the `dlt-rte` command. Refer to the *Database Administration Manual - SS7* for assistance.
3. Re-enter the `dlt-dstn` command that generated this error message.

E2355 Cmd Rej: Linkset already assigned to route

Commands Used: `ent-rte`

The specified linkset is already in the specified route. A linkset can be entered only once as a route for each destination or for a routeset.

Recovery

1. Display the linksets in the route.
Enter the `rtrv-rte` command specifying the specified route.
2. Display the linksets in the database.
Enter the `rtrv-ls` command.
3. Using the outputs of Steps 1 and 2, re-enter the `ent-rte` command specifying a linkset that is in the database but is not assigned to the specified route.

E2356 Cmd Rej: Last route to DPC in use by GTT

Commands Used: `dlt-rte`, `chg-dstn`

The last route cannot be removed if the destination point codes associated with a historic routeset are referenced by GTT. If a route to a destination in use by a GTT is the last route to that destination, the route cannot be removed until one of the following actions is performed:

Recovery

1. Perform one of the following:
 - a) Delete the GTT referencing the route's destination.
OR
 - b) Change the route used by the GTT to a route using a different destination.
OR
 - c) Add another route using the same destination.
2. Re-enter the command that generated this error message.

E2357 Cmd Rej: Linkset is unequipped

Commands Used: `chg-rte`, `dlt-rte`, `ent-rte`, `rtrv-rte`

The specified linkset could not be found in the database. All linksets that are currently assigned to a route set must be equipped. The `dpc` parameter must be specified in the command.

The `force=yes` parameter must be specified if a linkset is assigned to a route that has no links in it.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command.
2. Re-enter the command specifying a linkset from the output of Step 1.

E2358 Cmd Rej: Routeset is empty

Commands Used: `dlt-rte`

If the `all=yes` parameter is specified, then at least one route must be assigned to the routeset.

Recovery

1. Display the routes in the database. Enter the `rtrv-dstn` command.
2. Re-enter the `dlt-rte` command specifying a destination point code(DPCA,DPCI, DPCN, or DPCN24 fields) shown in the output of Step 1 that has routes assigned to it, along with the `all=yes` parameter.

E2359 Cmd Rej: Route table is full

Commands Used: `ent-dstn`, `chg-dstn`

The Destination Point Code table is full. You must delete a destination point code before another point code can be added to the Destination Point Code table.

Recovery

1. Display the Route table.
Enter the `rtrv-dstn` command.
2. Delete a destination point codes from the Route table.
Enter the `dlt-dstn` command.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2361 Cmd Rej: Screen set name not defined

Commands Used: `chg-ls`, `ent-ls`

The specified screen set name could not be found in the database. The screen set name specified by the `scrn` parameter must be valid and must be in the database.

Recovery

1. Verify that the screen set name was entered correctly and re-enter the command.

2. If the screen set name was entered correctly and this error message appears again, display the screen sets in the database.
Enter the `rtrv-scrset` command specifying no parameters.
3. Re-enter the command specifying a valid screen set name that is in the database.

E2363 Cmd Rej: ITU point codes are not supported when DOMAIN=X25

Commands Used: `chg-dstn`, `ent-dstn`

You attempted to assign an ITU destination point code, but this is valid only in the SS7 domain. You had set the **domain** parameter to `x25`. The following Recovery procedures list by command the remedial action to take.

Recovery - `ent-dstn`

Perform one of the following:

- Re-enter the `ent-dstn` command, but set the **domain** parameter to `ss7`.
OR
- Re-enter the `ent-dstn` command, but omit the **domain** parameter.

Recovery - `chg-dstn`

1. You cannot use the `chg-dstn` command to change the **domain** parameter.
Therefore, delete this destination, using the `dlt-dstn` command.
2. Re-enter the destination using the `ent-dstn` command specifying the **domain** parameter equal to `ss7`.
OR Re-enter the destination using the `ent-dstn` command without specifying the **domain** parameter.

E2364 Cmd Rej: TELNET cannot be specified unless the IPSM card is equipped

Commands Used: `rtrv-trm`

You specified a command that cannot be executed because the IPSM card is not equipped. Before the command you issued can be executed, the supporting IPSM card must be equipped.

Recovery

1. Display the cards that are defined in the database.
Enter the `rtrv-card` command. Verify that the card you specified in the **loc** parameter is the correct IPSM card.
2. If you specified the correct card in the **loc** parameter, go to Step 4.

3. If the desired card is not equipped, equip an IPSM card for use with the `ent-card:apl=ips` command.
Refer to the *Commands Manual* for details.
4. Re-enter the original `rtrv-trm` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2365 Cmd Rej: TELNET Feature must be activated first

Commands Used: `alw-trm`, `inh-trm`, `rmv-trm`, `rst-trm`

You entered a terminal command for a terminal with **type=telnet**. However, the Telnet (IP User Interface) feature must be enabled and turned on before you can use this terminal command.

Note: If you do not have the controlled feature part number or the feature access key for the controlled feature you wish to enable, contact your Tekelec sales representative or account representative. The feature access key determines if the controlled feature is permanently or temporarily enabled.

Recovery

1. Display the terminals and their types to confirm the terminal you want to address. Enter the `rtrv-trm` command.
2. Display the status of the Telnet feature. Enter the command: `rtrv-ctrl-feat:partnum=893005701`.
3. If the Telnet feature is enabled and turned on, re-enter the command that generated this error message.
4. If necessary, enable and turn on the Telnet feature.
Refer to the procedure "Activating Controlled Features" in the *Database Administration Manual-System Management* for additional information.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2366 Cmd Rej: LOC must be specified

Commands Used: `inh-alm`, `rept-stat-card`, `unhb-alm`, `rept-meas`

The following Recovery procedures list by command the condition that generated the error message and the remedial action to take.

For the `rept-stat-card` command, if the **mode** parameter is specified, the **loc** parameter must also be specified.

For the `inh/unhb-alm` command the **loc** parameter must be specified when the `dev=card` parameter is specified.

Recovery - `inh-alm`, `unhb-alm`

You specified the **dev=card** or **dev=dlk** parameter, which both require that you also specify the **loc** parameter.

Perform one of the following:

- Re-enter the command that generated this error message specifying the **loc** parameter.
- OR
- Re-enter the command without specifying the **dev=card** or **dev=dlk** parameter.

Recovery - rept-stat-card

Perform one of the following:

- Re-enter the `rept-stat-card` command specifying both the **mode** and **loc** parameters.
- OR
- Re-enter the `rept-stat-card` command without specifying the **mode** parameter.

Recovery - rept-meas

If the **enttype=sctpcard** parameter is specified, then the **loc** parameter must be specified.

E2367 Cmd Rej: May not specify both LOC and STAT

Commands Used: `rept-stat-card`

The command was entered with a card location (**loc**) and the primary state filter (**stat**) parameters. This command does not allow this parameter combination. Either of these parameters can be entered with this command, but both of these parameters cannot be specified at the same time.

Recovery

Re-enter the `rept-stat-card` command specifying either the **loc** or **stat** parameters, but not both.

E2368 Cmd Rej: System busy - try again later

Commands Used: `act-flash`, `alw-card`, `alw-map-ss`, `alw-trm`, `blk-slk`, `canc-cmd`, `clr-imt-stats`, `dact-slk`, `init-flash`, `inh-alm`, `inh-card`, `inh-map-ss`, `init-imt-gpl`, `init-mux`, `rept-imt-info`, `rept-imt-lvl1`, `rept-imt-lvl2`, `rept-stat-alm`, `rept-stat-card`, `rept-stat-clk`, `rept-stat-eroute`, `rept-stat-imt`, `rept-stat-lfs`, `rept-stat-lnp`, `rept-stat-meas`, `rept-stat-mon`, `rept-stat-mps`, `rept-stat-ndc`, `rept-stat-sccp`, `rept-stat-slan`, `rept-stat-sys`, `rept-stat-trbl`, `rept-x25-meas`, `rmv-card`, `rmv-trm`, `rst-card`, `rst-trm`, `tst-imt`, `ublk-slk`, `unhb-alm`, `unhb-slk`

Table 6: Conditions that Generate Error Message E2368 shows the conditions and recovery procedures for the various commands that can generate this error message.

Table 6: Conditions that Generate Error Message E2368

Commands	Issue and Recovery
<p>canc-cmd:trm=</p>	<p>The command was entered on the same terminal that is running the command to be canceled.</p> <ol style="list-style-type: none"> 1. Verify the user and terminal number that has the command to be canceled. Enter the <code>rept-stat-user</code> command. 2. Perform one of the following: <ul style="list-style-type: none"> • Enter the command from another terminal. <p style="text-align: center;">OR</p> <ul style="list-style-type: none"> • Enter the <code>canc-cmd</code> command without specifying the trm parameter.
<p>rept-stat-trbl or rept-stat-xx</p>	<p>No other <code>rept-stat-xxxx</code> command can be in progress when this command is issued.</p> <p>Wait for all <code>rept-stat-xxxx</code> commands to complete, then re-enter <code>rept-stat-trbl</code> command.</p>
<p>tst-imt</p>	<p>A related IMT command cannot be in progress. Only one Fault Isolation Test can be active at a time.</p> <p>Wait for all of the above commands or tests to complete, then re-enter the <code>tst-imt</code> command.</p>
<p>all other commands using this error</p>	<p>Heavy disk activity (e.g. database maintenance or measurement collection) may prevent access to the system.</p> <p>Action commands (used to change the state of entities within the system) cannot execute because another action command is in progress.</p> <p>For more information on action commands, refer to the <i>Commands Manual</i>.</p> <ol style="list-style-type: none"> 1. Wait for some of the disk activity to subside or for the action command to complete. 2. Re-enter the command that generated this error message.

E2369 Cmd Rej: Partition specified invalid for target disk

Commands Used: `tst-disk`

You entered a command to test a disk partition that does not exist on the target disk. For example, partitions 3 and 4 do not exist on a 4 GB disk; it has only partitions 1 and 2.

OR

You entered a command and specified **partition=1, 2, 3, 4, or all** to test a disk which has been formatted (`format-disk` command) but does not yet contain a DOS directory structure (created with `copy-disk` command).

Note:

The `partition=disk` parameter is accepted in this situation, as this tests the entire disk and does not care about individual partitions. The `partition=disk` parameter is used only by Tekelec for debug purposes.

Recovery

Re-enter the `tst-disk` command specifying a valid **partition** parameter value for the disk being tested.

OR

Re-enter the `tst-disk` command to test the disk.

Enter the `copy-disk` command to create the DOS directory structure of the target disk.

Refer to the *Database Administration Manual - System Management* for information about formatting and copying a TDM disk.

E2370 Cmd Rej: Terminal Id not entered

Commands Used: `rst-trm`

You cannot enter the reset terminal command without specifying the terminal id (**trm**) parameter. You must enter the **trm** parameter for this command to execute.

Recovery

Re-enter the `rst-trm` command specifying the **trm** parameter.

E2371 Cmd Rej: Force parameter required

Commands Used: `chg-db`, `inh-alm`, `inh-card`, `inh-trm`, `init-network`, `rmv-card`, `set-uim-acthresh`

Inhibiting a card would result in the loss of service or the service is not presently active; specify the **force=yes** parameter to perform the command. When the **lvl=crit** parameter is specified, the **force=yes**

parameter must be specified. *Table 7: Operations Requiring force=yes Parameter* describes additional conditions where the **force=yes** parameter must be specified.

Table 7: Operations Requiring force=yes Parameter

Command	Specify the force=yes parameter to...
chg-db	Specify the action=canceled parameter.
inh-alm	Inhibit critical alarms.
inh-card	Inhibit the only remaining MCPM or LIM card.
inh-trm	Inhibit the last OAP port.
init-network	Reset all network cards and override the required four card SS7ANSI or CCS7ITU configuration.
set-uim-acthresh	Set the limit=0 parameter for a given interval. Specifying limit=0 turns off all occurrences of the specified UIM. Use this method of creating thresholds only if you are certain the correct UIM is specified.

Recovery

Contact the Customer Care Center for additional assistance. See the Customer Care Center section in Chapter 1 of this manual.

E2372 Cmd Rej: Terminal is not equipped

Commands Used: `rmv-trm`, `rst-trm`

The specified **trm** number has no terminal assigned to it.

Recovery

1. Enter the `rtrv-trm` command to display all the terminals.
2. With the output from Step 1 as a guide, re-enter the command specifying a **trm** number that has a terminal assigned to it.

E2373 Cmd Rej: Link is unequipped in the database

Commands Used: act-cdl, act-lbp, act-slk, alw-slk, blk-slk, chg-ls, canc-slk, dact-cdl, dact-lbp, dbg-ddb, dlt-slk, inh-alm, inh-slk, rept-meas, rept-stat-cdl, rept-stat-lfs, rept-stat-slk, rept-stat-tstslk, tst-slk, unhb-alm, ublk-slk, unhb-slk

The entity or link specified by the **loc** and **link** parameter must exist in the database, and must already be equipped. For the commands specifying the **dev=slk** or **dev=dlk** parameters, the specified link must exist in the database.

Recovery

1. Display the signaling links in the database.
Enter the `rtrv-slk` command.
2. Re-enter the command specifying a card location and port of a properly provisioned signaling link shown in the output of Step 1.

E2374 Cmd Rej: SCCP not Configured

Commands Used: alw-map-ss, inh-map-ss, rept-stat-mps, rept-stat-sccp, rept-stat-lnp

At least one TSM card running the sccp application, or one Service Module card running the vscpp/ sccphc application must be configured in the system before this command can be entered.

Recovery

1. Display the cards in the system.
Enter the `rtrv-card` command. SCCP cards are shown by the entries TSM in the `TYPE` field and SCCP in the `APPL` field. VSCCP cards are shown by the entries DSM in the `TYPE` field and VSCCP in the `APPL` field.
2. If there are no SCCP or VSCCP cards in the system, no action is necessary.
3. If there are SCCP or VSCCP cards in the system, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2375 Cmd Rej: Unknown command

Commands Used: All commands

The entered command is invalid.

Recovery

Re-enter the command.

If this error message appears again, refer to the specified command in the *Commands Manual*.

E2376 Cmd Rej: Specified LOC is invalid

Commands Used: `act-cdl`, `act-dlk`, `act-flash`, `act-lbp`, `act-lpo`, `act-slk`, `alw-card`, `alw-slk`, `blk-slk`, `canc-dlk`, `canc-lpo`, `canc-slk`, `chg-lbp`, `dact-cdl`, `dact-lbp`, `dact-slk`, `dlt-lbp`, `ent-lbp`, `inh-slk`, `init-flash`, `init-imt-gpl`, `pass`, `rept-stat-cdl`, `rept-stat-dlk`, `rept-stat-lfs`, `rept-stat-mon`, `rept-stat-slk`, `rept-stat-tstslk`, `rept-x25-meas`, `rst-card`, `rtrv-lbp`, `rtrv-obit`, `rtrv-trbl`, `tst-dlk`, `tst-slk`, `ublk-slk`, `unhb-slk`

An invalid card location value was assigned to the **loc** parameter.

The **loc** parameter value must correspond to a card location for:

- An SSEDCCM or E5-ENET card that runs the **ss7ipgw**, **ipgwi**, **iplim**, or **iplimi** application
- An STC card or E5-STC card that runs the **eroute** application
- An IPSM card or E5-IPSM card that runs the **ips** application
- An SSEDCCM card or E5-SLAN card that runs the **stplan** application
- A Service Module card that runs the **vsccp** application
- An E5-TSM card that runs the **gls** application
- An FC-capable card must be provisioned in the system before the **type=fcs** parameter can be specified.
- An STC card must be provisioned in the system before the **type=eroute** parameter can be specified.

Refer to the *Commands Manual* for a detailed description about the use of these commands.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
2. Re-enter the command that generated this error message specifying the correct **loc** parameter value.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2377 Cmd Rej: No test link message is sent

Commands Used: `tst-slk`

You either entered this command while another action command was in progress, or you specified a card that is not a LIM card.

Recovery

1. Allow time for the other action command to complete and then re-enter the `tst-slk` command.
OR
2. Verify the card in the specified location is a LIM card.

Display the cards in the database. Enter the `rtrv-card` command. LIM cards are identified by the terms `limatm`, `limds0`, `limocu`, or `limv35` in the `TYPE` field.

3. Re-enter the `tst-slk` command specifying a valid LIM card location.

E2378 Cmd Rej: The specified card cannot be inhibited

Commands Used: `inh-card`, `rmv-card`

The command specified a card that cannot be inhibited because it is a TDM or MDAL that cannot be inhibited. Any card location other than 1114, 1116, 1117, xx09, and xx10 can be specified.

Recovery

1. Verify the card to be inhibited.
Enter the `rtrv-card` command. The card types are shown in the `TYPE` field in the output.
2. Re-enter the command using a location that is not 1114, 1116, 1117, or a card location that ends in 09 or 10.

E2379 Cmd Rej: Missing parameter

Commands Used: `chg-gta`, `chg-isupvar-attrib`, `dbg-ddb`, `ent-gta`, `ent-slk`, `rept-stat-rte`, `rept-stat-rtx`, `rept-stat-slk`, `rtrv-isupvar-attrib`

A parameter is required or has been entered incorrectly.

[Table 8: Required Command and Parameter Combinations](#) describes the invalid parameter combinations that generate this error message.

Table 8: Required Command and Parameter Combinations

Command	Missing Parameter
chg-gta	<p>If the <code>xlat</code> parameter has a value of <code>udts</code> or <code>disc</code>, then the only other optional parameters that can be specified are the <code>gta/egta</code>, <code>cgpc</code>, <code>opc</code>, <code>cgssn/ecgssn</code>, <code>cdssn/ecdssn</code>, <code>opcode/pkgtype/family</code>, or <code>opcode/pkgtype/acn</code> parameters.</p> <p>If the value of the <code>xlat</code> parameter is changed to <code>dpc</code>, <code>dpcngt</code>, or <code>dpcssn</code>, then the <code>pc/pca/pci/pn/pcn24</code> and <code>ri</code> parameters must be specified.</p> <p>If the value of the <code>xlat</code> parameter is <code>udts</code> or <code>disc</code>, then changing the PC or other fields requires the <code>xlat</code> parameter value to be changed to a value other than <code>udts</code> or <code>disc</code>.</p>

Command	Missing Parameter
dbg-ddb	<p>If the action parameter has a value of disp, aud, stats, or wwa, then the loc parameter must be specified.</p> <p>If the action=aud parameter and the rloc parameter are specified, then the audtype parameter must be specified.</p> <p>If the action parameter has a value of disp or aud, then the tbl parameter must be specified.</p>
ent-gta	<p>If the xlat parameter has a value of dpc, dpcngt, or dpcssn, then the pc/pca/pci/pcn/pcn24 and ri parameters must be specified.</p>
ent-slk	<p>If a card location is specified for a Channel card (card type limch) assigned to an E1 interface, then the e1loc parameter must be specified.</p> <p>If a card location is specified for a Channel card (card type limch) assigned to a T1 interface, then the t1loc parameter must be specified.</p> <p>If a card location is specified for an E1, T1, or Channel card (card type lime1, limt1, or limch), then the ts parameter must be specified for the link.</p>
rept-stat-slk	<p>This command can be entered with the stat parameter or the loc and port/link parameters. The command that generated this error message was entered with either the loc or port/link parameters by themselves.</p> <p>If the stat parameter is specified, it must be specified by itself.</p> <p>If the loc parameter is specified, the port/link parameter must be specified.</p> <p>If the port/link parameter is specified, the loc parameter must be specified.</p> <p>Class criteria cannot be specified without dpc parameter.</p>

Recovery

Re-enter the command specifying a valid set of parameters. Refer to the *Commands Manual* for more information.

E2381 Cmd Rej: Combined total baud rate for all ports cannot exceed 168K

Commands Used: `chg-trm`

The combined total line speed (baud rate in bits-per-second) for all active terminal ports cannot exceed **168,000** bps. When you entered the `chg-trm` command, the value of the combined total line speed for all ports exceeded **168,000** bps.

Recovery

1. Display the status of each port a terminal is attached to.
Enter the `rept-stat-trm` command. The *PST* field displays the primary state of the terminal for each port.
2. Use the information displayed in Step 1 to determine which ports are not being used.
For example, the *PST* field might display `OOS-MT-DSBLD` for a port not in use.
3. Enter the `chg-trm` command specifying the **type=none** parameter for the terminals on the ports not being used (from Step 2).
Specifying (**type=none**) conveys to the terminal processor that a particular port is not connected or is no longer in use, thereby freeing up system resources.
4. Re-enter the `rept-stat-trm` command and verify that the combined total line speed for all ports no longer exceeds **168,000** bps.
5. Re-enter the `chg-trm` command.

E2382 Cmd Rej: Only 4 ports with sys maint. output group ON are allowed

Commands Used: `chg-trm`

You can configure only four terminals to receive system maintenance-related unsolicited messages. You entered the `chg-trm` command specifying the **sys=yes** parameter, and four terminals are already configured to receive system maintenance-related unsolicited messages.

Recovery

1. Verify the number of terminals configured to receive system maintenance-related unsolicited messages.
Enter the `rtrv-trm` command. The *SYS* field should display **yes** for each of the four terminals so configured.
2. Re-enter the original `chg-trm` command without specifying the **sys=no** parameter.
If you must specify a particular port to receive system maintenance-related unsolicited messages, do the following:
3. Using the information displayed in Step 1, select one of the ports already configured, and re-enter the `chg-trm` command specifying that port and the **sys=no** parameter.
4. Verify that only three ports now have **yes** displayed in the *SYS* field.
Enter the `rtrv-trm` command.

5. Re-enter the `chg-trm` command specifying the particular port you need configured to receive system maintenance-related unsolicited messages, specifying the `sys=yes` parameter for that port. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2383 Cmd Rej: MCP card must be IS-ANR Restrict to enable measplatform

Commands Used: `chg-measopts`

You entered the `chg-measopts` command specifying the **platformenable** parameter to enable the Measurements Platform collection function. At least one MCPM card must be in the IS-ANR Restrict state before you can enable the Measurements Platform collection function. The cards usually reach IS-ANR Restrict state within 2 minutes after the feature is turned on.

Recovery

1. Display the state of each MCPM card in the system.
Enter the `rept-stat-card` or `rept-stat-meas` command. The Primary State of each card is shown in the PST column of the command output.
2. If no MCPM cards are in the IS-ANR Restrict state, wait a couple of minutes and enter one of the `rept-stat-` commands again.
3. When at least one MCPM card is in the IS-ANR Restrict state, re-enter the command the Measurements Platform collection function.

E2384 Cmd Rej: Link set is not equipped

Commands Used: `dact-rstst`, `dlt--ls`, `inh-alm`, `rtrv-rte`, `rept-stat-ls`, `unhb-alm`

The linkset specified by the `lsn` parameter must be equipped in the database.

Recovery

1. Display all the linksets configured in the database. Enter the command specifying no parameters. The valid linksets are displayed in the LSN field of the output.
2. Select a valid linkset from the LSN field and re-enter the command specifying a valid linkset value for the `lsn` parameter.

`dact-rstst`

The linkset you specified in the `lsn` parameter must be in the Linkset table and in the DPC's routeset. In this case, it failed to meet either or both conditions.

Recovery

1. Acquire the identifying information for the provisioned clusters.
Enter the command `rept-stat-cluster` command without parameters.
2. Re-enter the command that generated this error message specifying one of the valid linksets displayed in Step 1 as the `lsn` parameter.

E2385 Cmd Rej: May not specify both LSN and PST

Commands Used: `rept-stat-ls`

The command was entered with both the **lsn** and **stat** parameters. The **lsn** parameter identifies the name of the linkset. The **stat** parameter identifies the primary state (PST) of the linksets to report on. The command can be entered with either of these parameters, but not both.

Recovery

Re-enter the `rept-stat-ls` command specifying either the **lsn** parameter, the **stat** parameter, or no parameters.

E2386 Cmd Rej: DPC parameter needed with MODE=FULL

Commands Used: `rept-stat-cluster`, `rept-stat-dstn`, `rep-stat-rte`

The following Recovery procedures list the remedial action to take for each command that generates this error message:

Recovery - `rept-stat-cluster`

When you specify the **mode=full** parameter, you must also specify the **dpc** parameter. When you enter the command specifying no parameters, summary information for all of the defined cluster DPCs is shown. When you enter the command specifying a provisioned cluster member DPC, the report shows status information for the specified DPC plus route information. The destination point code must be in the database.

1. Enter the `rtrv-dstn` command to display all the destination point codes in the database.
2. Re-enter the command specifying the **mode=full** parameter and the **dpc** parameter with a point code from the output of Step 1.

OR

Re-enter the command specifying no parameters for a summary report.

Recovery - `rept-stat-dstn`

You entered the **mode=full** parameter and the destination point code parameter (**dpc**, **dpca**, **dpcn**, **dpcn24**, **dpci**) was not specified, as required. The destination point code must be in the database.

1. Display all the destination point codes in the database.
Enter the `rtrv-dstn` command.
2. Re-enter the `rept-stat-dstn` command, specifying a destination point code that is in the output of Step 1 and the **mode=full** parameter.

E2387 Cmd Rej: Card is not in service

Commands Used: `act-cdl`, `act-ftp-trns`, `act-lbp`, `act-upgrade`, `chg-db`, `dact-cdl`, `dact-lbp`, `dlt-appl-rtkey`, `pass`, `rept-stat-rtd`, `rept-x25-meas`, `rtrv-appl-rtkey`, `tst-slk`

The command was entered with a card location whose card was out of service. The cards specified in these commands must be in service.

E5-IPSM cards must be provisioned before the `chg-db:action=restore:src=server` or `chg-db:action=backup:dest=server` commands can be entered.

For the `act-upgrade` command, an E5-IPSM card must be provisioned before a value of `getrel` or `chkrel` can be specified for the action parameter.

For `act-ftp-trns`, an IPSM card must be in service before this command can be entered.

Recovery

1. Display the status of the cards in the system using the `rept-stat-card` command.
Verify that the card has been provisioned correctly. If the card is in service, the entry IS-NR appears in the `PST` field of the output.
2. Re-enter the command, specifying a card location that is in service.

E2388 Cmd Rej: Point code not equipped

Commands Used: `chg-dstn`, `chg-rte`, `dlt-rte`, `dlt-dstn`, `ent-rte`, `rept-stat-dstn`, `rept-stat-rte`, `rtrv-rte`

The value specified for the `dpc` parameter must exist in the database.

Recovery

1. Use the `ent-dstn` command to make the DSTN table entry in the database. For more information refer to the Database Administration Manual - SS7 for assistance.
2. Re-enter the command that generated this error message.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2389 Cmd Rej: No troubles to Display

Commands Used: `rtrv-trbl`

The command was entered to display an entry from the trouble log, and no troubles were found.

Recovery

No action is necessary since there are no troubles to display.

E2390 Cmd Rej: No obits to display

Commands Used: `rtrv-obit`

The command was entered to display an entry from the obituary log, and none were found.

Recovery

No action is necessary since there are no obituaries to display.

E2391 Cmd Rej: Echo not allowed for telnet terminals

Commands Used: `act-echo`

You specified a telnet port for the `trm` parameter, which is not allowed. You cannot echo FROM or TO a telnet port.

Recovery

1. Enter the `rtrv-trm` command for a list of valid terminal choices.
If the entry in the `TYPE` column is telnet, the terminal is not a valid choice.
2. Re-enter the `act-echo` command specifying a valid (that is, a non-telnet) value in the `trm` parameter.

E2392 Cmd Rej: Received wrong display mode

Commands Used: `aud-data`, `rept-imt-info`, `rept-stat-gpl`

A value that is invalid was assigned to the display mode parameter.

For the `aud-data` command, if the `type=ddb` parameter is specified, then the `except` parameter cannot be specified.

The mode parameter is optional if the `report` parameter equals `err`; otherwise, it is not allowed.

The `display=all` parameter and the `apl` parameter cannot be specified in the same command.

Recovery

Re-enter the command that generated this error message specifying the correct parameter value. Refer to the *Commands Manual* for assistance in the correct parameter values.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2393 Cmd Rej: Terminal is not equipped

Commands Used: `rtrv-trm`

You specified a terminal in the command (`rtrv-trm:trm=x`), the specified terminal must be equipped.

Recovery

1. Display all terminals. Enter the `rtrv-trm` command.
2. Re-enter the `rtrv-trm` command with the **trm** parameter for an equipped terminal, or equip the specified terminal for use and re-enter the `rtrv-trm` command for that terminal.

E2394 Cmd Rej: Number out of range

Commands Used: `chg-assoc`, `ent-assoc`, `rtrv-obit`, `rtrv-trbl`

You assigned a value to a parameter that was either too great or too small.

Recovery

Re-enter the command that generated this error message specifying the correct parameter value. Refer to the *Commands Manual* for assistance with the correct parameter values.

E2395 Cmd Rej: Removable DB levels don't match, must specify **sloc** parameter

Commands Used: `chg-db`

If E5-MASP hardware is used for a restore procedure, and if the active and standby removable drives installed in the latched USB port have different DB levels, then the **sloc** parameter must be specified to indicate the removable drive to be used.

Recovery

1. Verify that the active and standby removable drives are installed in the latched USB port. Enter the `rept-stat-ddb` command.
2. Verify the DB levels for the active and standby removable drives. Refer to the *Commands Manual* and to the *Hardware Manual* for assistance.
3. If the drives are not at the same level, re-enter the command specifying the **sloc** parameter of the DB to be restored.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual

E2398 Cmd Rej: Standby MASP is isolated

Commands Used: `format-disk`, `rtrv-obit`, `rtrv-trbl`

The card location specified in this command was the standby OAM, and the standby OAM could not be found. There is a communication problem with the standby OAM card.

Recovery

1. Reseat the standby OAM card.
2. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2399 Cmd Rej: Removable drive not allowed for upgrade

Commands Used: `act-upgrade`

If an E5-MCAP or E5-MDAL card is used, then the `src=remove` parameter cannot be specified.

Recovery

Re-enter the command without specifying the `src=remove` parameter.

OR

Reference the procedures to perform an upgrade on a different drive.

Note: It is strongly recommended that this command be used only in conjunction with the system Upgrade Procedure for your target release. The Upgrade Procedure provides step-by-step information on performing an upgrade.

E2401 Cmd Rej: GTA range overlaps a current range

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`, `ent-gta`, `ent-gtt`

The range of global title addresses to be changed, as specified by the start and end global title addresses, must match exactly an existing range in the global title translation data for the specified translation type. While an exact match is not required, an overlap with another range cannot be specified. If the range overlaps, an error is generated that displays a list of overlapped global title addresses. An example follows that shows what happens when the user attempts to enter a range (such as 8005550000 to 8005559999) that overlaps an existing range. The overlapping links must match. If they do not, error message E2401 is generated displaying the list of overlapped global title addresses:

The following GTA ranges overlap the input GTA range START GTA END GTA 8005550000 8005551999 8005552000 8005553999 8005554000 8005555999 CHG-GTA: MASP A - Command Aborted. The

overlapping links must match. If they do not, error message E2401 is generated displaying the list of overlapped point codes:

```
The following GTA ranges overlap the input GTA range
START GTA      END GTA
8005550000     8005551999
8005552000     8005553999
8005554000     8005555999
ENT-GTT: MASP A - Command Aborted
```

Recovery

1. Re-enter the command specifying different values for the `gta` and `egta` parameters.
2. To verify the global title address ranges, enter the `rtrv-gtt` or `rtrv-gta` command.

E2402 Cmd Rej: GTA range does not exist

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`

The specified GTA range must exist.

The Global Title Address range, as expressed by the `gta` and `egta` parameters, must already exist in the global title translation.

The following Recovery procedures list by command the remedial action for this error message.

Recovery - `chg-gta`, `dlt-gta`

The specified GTA range must exist for the specified GTT set in the STP active database. Note that an exact match is not required. (See example below).

1. Display the global title addresses in the Global Title Translation table. Enter the `rtrv-gta` command.
2. Re-enter the command specifying one of the global title address values displayed from the output in Step 1.

Recovery - `chg-gtt`, `dlt-gtt`

The global title address must be in the Global Title Translation table.

1. Display the global title addresses in the Global Title Translation table.
Enter the `rtrv-gtt` command.
2. Re-enter the command, with one of the global title address values displayed from the output of the `rtrv-gtt` command.

An example follows that shows what happens when the user attempts to enter a point code range (such as `8005550000` to `8005559999`) that overlaps an existing range. The overlapping links must match. If they do not, error message E2401 is generated displaying the list of overlapped point codes:

```
The following GTA ranges overlap the input GTA range
START GTA      END GTA
8005550000     8005551999
8005552000     8005553999
```

```
8005554000      8005555999
CHG-GTT: MASP A - Command Aborted
```

E2403 Cmd Rej: Length of EGTA must be equal to length of GTA

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`, `ent-gta`, `ent-gtt`, `rtrv-gta`, `rtrv-gtt`

If the **egta** parameter is specified, the **gta** parameter must be specified. The **gta** and **egta** parameters must be the same length, and the value for the **egta** parameter must be greater than the value for the **gta** parameter.

Recovery

Re-enter the command specifying the same number of digits for both the **egta** and the **gta** parameters.

E2404 Cmd Rej: GTA does not match translation type's number of digits

Commands Used: `chg-gtt`, `dlt-gtt`, `ent-gtt`, `rtrv-gtt`

The number of digits in the specified **gta** parameter must be at least the number of digits provisioned for the given translation type. If the VGTT (variable length GTT) feature is turned on, there can be up to 10 GTA lengths per translation type. When the `ent-gtt` command is entered to create entries, the software keeps track of the lengths and allows only ten different lengths.

Recovery

1. Display the translation type information in the Route table.
Enter the `rtrv-tt` command. The number of GTA digits allowed is listed in the NDGT column of the output.
2. Re-enter the command specifying the global title address containing one of the GTA lengths listed in the output of step 1.

E2405 Cmd Rej: GTA does not exist in any range

Commands Used: `rtrv-gta`, `rtrv-gtt`

The command cannot find the global title address specified by the **gta** parameter.

The number of digits in the specified **gta** parameter must be at least the number of digits provisioned for the GTT set specified by the **gttsn** parameter. If the VGTT feature is turned on, then up to 10 GTA lengths can exist per GTT set. If the VGTT with 16 lengths feature is turned on, then up to 16 GTA lengths can exist per GTT set.

Recovery

Perform one of the following:

- Verify that the translation type or GTT set name has been entered correctly and re-enter the command.
- OR
- Enter the `rtrv-gtt` command without specifying any parameters, or enter the `rtrv-gta` command specifying only the mandatory `gttsn` parameter.

E2406 Cmd Rej: ADJ required if MPC/MSSN is given or MULT=DOM or SHR

Commands Used: `chg-map`, `ent-map`

You entered the command without specifying the **adj** parameter and with the mated point code (**mpc**, **mpca**, **mpci**, **mpcn**) and **mssn** parameters, or with the **mult=dom** or **mult=shr** parameters. If any of these parameters are specified in the command, the **adj** parameter must be entered.

Recovery

Re-enter the command specifying the **adj** parameter.

E2407 Cmd Rej: GTA range is already assigned

Commands Used: `ent-gtt`

The range of global title addresses specified is already assigned to this translation type.

Recovery

1. Re-enter the `ent-gtt` command specifying different values for the **gta** and **egta** parameters.
2. To verify which global title addresses have been assigned to translation types, enter the `rtrv-gtt` command.

E2408 Cmd Rej: CSPC broadcast group already exists

Commands Used: `ent-cspc`

You tried to enter a Concerned Signaling Point Code broadcast group name that has already been entered. Entering a CSPC broadcast group with no point code implies that a new CSPC broadcast group is to be created, but the name specified in this command is already in use. The CSPC broadcast group names must be unique.

Recovery

1. Display the CSPC broadcast group names.
Enter the `rtrv-cspc` command.

2. Re-enter the `ent-cspc` command specifying another name for the CSPC broadcast group that is not shown in Step 1.

E2409 Cmd Rej: EGTA cannot be specified without GTA

Commands Used: `chg-gtt`, `ent-gtt`, `rtrv-gtt`, `rtrv-gta`

You cannot specify the **egta** parameter and not specify the **gta** parameter.

Recovery

Re-enter the command that generated this error message specifying both the **egta** and **gta** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2410 Cmd Rej: CSPC broadcast group table is full

Commands Used: `ent-cspc`

The system can contain a maximum of 2550 CSPC broadcast groups. The CSPC broadcast group cannot be entered until another CSPC broadcast group is deleted. This threshold has been reached and this command attempted to enter more than 2550 CSPC broadcast groups.

Recovery

1. Display the CSPC broadcast group information.
Enter the `rtrv-cspc` command specifying no parameters.
2. From the output of the `rtrv-cspc` command entered in Step 1, select a CSPC broadcast group to delete.
3. Delete the CSPC broadcast group selected in Step 2.
Enter the `dlt-cspc` command.
4. Re-enter the `ent-cspc` command specifying the parameters that generated this error message to add the desired CSPC broadcast group.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2411 Cmd Rej: CSPC group does not exist

Commands Used: `chg-map`, `dlt-cspc`, `ent-cspc`, `ent-map`, `rtrv-cspc`

If a concerned point code broadcast list (CSPC) group name is specified, then it must already exist, unless the **none** parameter is specified.

Recovery - `chg-map`, `dlt-cspc`, `ent-cspc`, `rtrv-cspc`

The specified CSPC group could not be found. To change the name of a CSPC group, that CSPC group name must already exist in the CSPC Group Name table.

1. Display the CSPC group names in the CSPC Group Name table. Enter the `rtrv-cspc` command specifying no parameters.
2. Re-enter the command that generated this error message specifying a CSPC group name displayed in the CSPC Group Name table from Step 1.

Recovery - ent-cspc, ent-map

The specified CSPC group does not exist in the CSPC Group Name table. To add a CSPC to a CSPC group, the CSPC group must already exist in the CSPC Group Name table.

1. If the CSPC group name was entered correctly and this error message appears, re-enter the `ent-cspc` command specifying the group parameter only.
2. Re-enter the `ent-cspc` command, this time including the point codes.

E2412 Cmd Rej: Command already in progress

Commands Used: `act-gpl`, `chg-gpl`, `copy-gpl`, `rtrv-gpl`, `rept-stat-gpl`

The command was entered while the system was still executing one of these previously entered commands: `act-gpl`, `chg-gpl`, `copy-gpl`, `rept-stat-gpl`, or `rtrv-gpl`.

No other activate, change, copy, or retrieve GPL command can be in progress when these commands are entered.

Recovery

Wait until the system has completed executing the command in progress. Then re-enter the appropriate `gpl` command that generated this error message.

E2413 Cmd Rej: PC already exists in CSPC group

Commands Used: `ent-cspc`

The specified point code already exists in the concerned signaling point code group. The point code must exist in the Routing Table and cannot already exist in the specified group.

Recovery

1. Verify that the point code was entered correctly and re-enter the `ent-cspc` command.
2. If the point code was entered correctly and this error message appears again, the point code already exists in the concerned signaling point code group.

E2414 Cmd Rej: PC does not exist in CSPC group

Commands Used: `chg-map`, `dlt-cspc`, `ent-map`

The specified point code does not exist in the specified concerned signaling point code group. The PC must already exist in the CPC group.

Recovery

1. Display the point codes currently assigned to the group.
Enter the `rtrv-cspc` command specifying the desired CSPC group name.
2. Re-enter the command specifying a point code that is in the desired CSPC group name.

E2415 Cmd Rej: Concerned node table for this group is full

Commands Used: `ent-cspc`

The specified CSPC group is full. You cannot enter more than 96 point codes into a CSPC group.

Recovery

Note:

The specified point code cannot be added until an existing point code is deleted from the CSPC group.

1. Display the point codes in the CPSC group.
Enter the `rtrv-cspc` command specifying the name of the affected CSPC group. Example:
`rtrv-cspc:grp=grp01`
2. Select and delete an existing point code from the CSPC group.
Enter the `dlt-cspc` command.
3. Re-enter the `ent-cspc` command that generated this error message to add the desired point code to the CSPC group.

E2416 Cmd Rej: Unable to access database. Severe database failure

Commands Used: `chg-gta`, `chg-gtt`, `chg-lnpopts`, `chg-lnp-ttmap`, `chg-mrn`, `chg-sccp-serv`, `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-dpc`, `chg-scr-isup`, `chg-scr-opc`, `chg-scrset`, `chg-scr-sio`, `chg-scr-tt`, `dlt-mrn`, `dlt-sccp-serv`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-dpc`, `ent-scr-isup`, `dlt-scr-opc`, `dlt-scrset`, `dlt-scr-sio`, `dlt-scr-tt`, `ent-gta`, `ent-gtt`, `ent-map`, `ent-mrn`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`, `ent-scr-isup`, `ent-scr-opc`, `ent-scrset`, `ent-scr-sio`, `ent-scr-tt`, `rtrv-sccp-serv`, `rtrv-feat`, `rtrv-lnpopts`, `rtrv-mrn`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`,

rtrv-scr-cgpa, rtrv-scr-dpc, ent-scr-isup, rtrv-scr-opc, rtrv-scrset, rtrv-scr-sio, rtrv-scr-tt

The database cannot be accessed. There is a severe database failure.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2417 Cmd Rej: Point code does not exist in the routing table

Commands Used: chg-ppsopts, chg-gsmmap-scrn, chg-gsms-opcode, chg-gta, chg-rtx, dact-rstst, dbg-ddb, dlt-rtx, ent-cspc, ent-gsmmap-scrn, ent-gsms-opcode, ent-gta, ent-rtx, inh-alm, rept-stat-cluster, rst-dstn, unhb-alm

The value specified for the point code parameter interacts with the Routing tables in different ways, depending on the command. *Table 9: Point Code Requirements* displays the point code requirements for the commands.

Table 9: Point Code Requirements

Command	Requirements
ent/chg-gta	The point code must exist as a destination in the Route table or reside in a cluster that exists as a destination in the Route table (for global routing) unless the point code is the STP's true point code.
chg-ppsopts, inh-alm, unhb-alm	The point code must already exist in the Routing Indicator table.
ent/chg-gsmmap-scrn, ent/chg-gsms-opcode	The point code must exist as a destination in the ordered route entity set or must reside in a cluster (ANSI only) that exists as a destination in the ordered route entity set (for global title routing).
chg-rtx, dlt-rtx	The point code must exist in the Destination table.
dbg-ddb, ent-cspc, ent-rtx	The point code must exist in the Route table.
dact-rstst, rst-dstn	The point code must be provisioned or an X-list entry.
rept-stat-cluster	The point code must already exist.

Recovery

1. Add the point codes to the appropriate tables. Refer to the *Database Administration Manual - GTT* for more information.
2. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2418 Cmd Rej: Mate PC/SSN cannot be given when MULT=SOL

Commands Used: `chg-map`, `ent-map`

The **mult=sol**, **mpc**, and **mssn** parameters were specified in the same command. The **mult=sol** parameter cannot be specified with the **mpc** and **mssn** parameters.

Recovery

Perform one of the following:

- Enter the command specifying the **mpc** and **mssn** parameters, without specifying the **mult=sol** parameter.
- OR
- Enter the command specifying the **mult=sol** parameter, without specifying the **mpc** and **mssn** parameters.

E2419 Cmd Rej: Point code does not exist in the remote point code table

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

The specified point code could not be found in the Remote Point Code/Mated Application (MAP) table.

- For the `chg-gta` command, this error is generated only if the optional point code (**pc/pca/pci/pcn/pcn24**) parameter is not specified.
- For the `chg-gta`, `ent-gta`, and `ent-gtt` commands, you can override this rule by specifying the **force=yes** parameter.

Note:

If the new or existing value of the **xlat** parameter is **dpc**, the new or existing value of the **ri** parameter is **ssn**, and the **pc/pca/pci/pcn** parameter is specified, the new point code must exist in the Remote Point Code/MAP table.

For the `chg-gta`, `ent-gta`, and `ent-gtt` commands, if the specified point code is not in the MAP table; the **force=yes** parameter must be specified to execute the command and instead of error message E2419, the following caution messages are displayed in the scroll area of the terminal:

```
DPC DOES NOT EXIST IN MATED APPLICATION TABLE DPC-SSN DOES NOT EXIST IN MATED APPLICATION TABLE
```

Recovery

1. Display the MAP table.
Enter the `rtrv-map` command specifying no parameters.
2. Perform one of the following:
Re-enter the command specifying a point code (**pc/pca/pci/pcn/pcn24**) parameter that exists in the MAP table. OR For the `chg-gta`, `ent-gta`, and `ent-gtt` commands, if the specified point code is not in the MAP table, re-enter the command specifying the **force=yes** parameter.

E2420 Cmd Rej: EGTA must be greater than or equal to GTA

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`, `ent-gta`, `ent-gtt`, `rtrv-gta`, `rtrv-gtt`

A range of global title addresses cannot be established if the **egta** parameter value is less the **gta** parameter value. If the **egta** parameter is specified, the value must be greater than the value specified for the **gta** parameter.

Recovery

Re-enter the command specifying a value for the **egta** parameter that is greater than or equal to the **gta** value.

E2421 Cmd Rej: ALL=YES must be specified to delete the entire group

Commands Used: `dlt-cspc`

Neither the **pc** nor the **all** parameter was specified; therefore, the command was interpreted as an attempt to delete an entire concerned signaling point code group. To delete an entire concerned signaling point code group, specify the **all=yes** parameter.

Recovery

To delete an entire concerned signaling point code group, re-enter the `dlt-cspc` command specifying the **all=yes** parameter.

E2422 Cmd Rej: ALL=YES must be specified to delete all SSNs for a PC

Commands Used: `dlt-map`

Neither the **ssn** nor the **all** parameter was specified; therefore, the command was interpreted as an attempt to delete all subsystem numbers for a given point code. To delete all subsystem numbers for a given point code, specify the **all=yes** parameter.

Recovery

To delete all subsystem numbers for a given point code, re-enter the `dlt-map` command specifying the **all=yes** parameter. Do not use the **ssn** parameter.

E2423 Cmd Rej: FORCE=YES must be specified for NUM greater than 1000

Commands Used: `rtrv-gta`, `rtrv-gtt`

If the specified **num** parameter value is greater than 1000, the **force=yes** parameter must be specified.

Recovery

Perform one of the following:

- To display more than 1000 entries, re-enter the command specifying **force=yes** and a value greater than 1000 for the **num** parameter.

Note:

The range of values for the num parameter is from 1 to 65535.

OR

- To display 1000 or less entries, re-enter the command specifying **force=no** and a value less than or equal to 1000 for the **num** parameter.

E2424 Cmd Rej: SRM=YES cannot be entered with ITU point code types

Commands Used: chg-map, ent-map

You cannot specify the Control of Subsystem Routing Messages (**srm=yes**) parameter and an ITU point code (**pci**, **pcn**, or **pcn24**). The **srm=yes** parameter can be specified only with an ANSI point code (**pc** or **pca**).

Recovery

Perform one of the following:

- Re-enter the command specifying an ANSI point code and the **srm=yes** parameter, or do not specify the **srm** parameter. The default value for the **srm** parameter for an ANSI point code is **yes**.

OR

- Re-enter the command specifying either an ITU point code and the **srm=no** parameter, or do not specify the **srm** parameter. The default value for the **srm** parameter for an ITU point code is **no**.

E2425 Cmd Rej: Mate PC/SSN cannot be same as PC/SSN

Commands Used: chg-map, ent-map

You cannot specify the same values for the mate point code (**mpc**) and mate subsystem number (**mssn**) pair and the primary point code (**pc**) and subsystem number (**ssn**) pair. The mate PC/SSN cannot be the same as the primary PC/SSN.

- If the mate subsystem number is not equal to the primary subsystem number, the mate point code can be equal to the primary point code.
- If the primary point code is not equal to the mate point code, the subsystem number can be the same as the mate subsystem number.

Recovery

Re-enter the command, specifying values for the primary point code/subsystem pair that are not the same as those for the mate point code/subsystem pair.

E2426 Cmd Rej: Mnemonic argument is undefined

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

You cannot specify a value other than **gt** or **ssn** for the **ri** parameter. You cannot specify **ri=dpc**.

Recovery

Re-enter the command specifying a value of **ri=gt** or **ri=ssn**.

E2427 Cmd Rej: MPC does not exist in routing Table

Commands Used: `chg-map`, `chg-mrn`, `chg-sccp-serv`, `ent-map`, `ent-mrn`

The mate remote point code specified is not in the Route table. If a remote MPC is specified, then the remote MPC must already exist as destination in the Ordered Route entity set, or reside in a cluster destination for which ordered routes are specified.

Recovery

1. Verify that the mate remote point code was entered correctly and re-enter the command.
2. If the mate remote point code was entered correctly and this error message appears again, enter the `rtrv-rte` command to display the Route table.
3. Re-enter the command specifying one of the point code values displayed in the output of the `rtrv-rte` command.

E2428 Cmd Rej: MPC entered, MSSN must also be given

Commands Used: `chg-map`

You cannot specify a mate point code (**mpc**) and not specify a mate subsystem number (**mssn**). If you specify an **mpc**, you must also specify a **mssn**.

Recovery

Re-enter the command specifying values for both the **mpc** and the **mssn** parameters.

E2429 Cmd Rej: MPC network type does not match PC network type

Commands Used: `chg-map`, `ent-map`

The **apca** and **pcn24** parameters cannot be specified for the same MAP set. The **pci** and **pcn** parameters cannot be specified for a MAP set that contains a true point code.

Note:

To mix group and PC network types, the ANSI-ITU-China SCCP Conversion feature must be on.

Recovery

Re-enter the command making sure that the point code and mated point code types match.

Refer to “Point Code Formats and Conversion” in Appendix A of the *Commands Manual* for a detailed description of point code formats, rules for specification, and examples.

E2430 Cmd Rej: Subsystem table for MPC is full

Commands Used: `chg-map`, `ent-map`

You tried to enter more than 10 subsystem numbers. Each mate remote point code can contain only 10 subsystem numbers, and this threshold has been reached. The number of MPC Subsystem entries must not exceed the table capacity.

Recovery

Note:

You cannot enter the subsystem number for the given mate remote point code until another subsystem number is removed.

1. Display the data for this mate remote point code.
Enter the `rtrv-map` command specifying the `pc` parameters.
2. From the output of the `rtrv-map` command entered in Step 1, select a subsystem number to be deleted.
3. Delete the subsystem number selected in Step 2.
Enter the `dlr-map` command.
4. Re-enter the command specifying the parameters that generated this error message, to enter the desired subsystem number.

E2431 Cmd Rej: MPC/MSSN pair already exists

Commands Used: `chg-map`, `ent-map`

The values specified for the mate point code (`mpc`) and mate subsystem number (`mssn`) are already in the MAP table.

If a new mate PC or mate subsystem is specified, then the specified `mpc/mssn` pair must not already exist in the MAP table.

Recovery

1. Display the mate point codes and mate subsystem number pairs in the MAP table.
>Enter the `rtrv-map` command.
2. Re-enter the command specifying values for the `mpc/mssn` pair that do not already exist in the MAP table.

E2432 Cmd Rej: MSSN or MATERC entered, MPC must also be given

Commands Used: `chg-map`, `ent-map`

You specified the mate subsystem number or relative cost, but you did not specify a mate point code. If you specify the mate subsystem number (**mssn**) or relative cost (**rc**) parameters, you must also specify the mate point code (**mpc**) parameter.

Recovery

Re-enter the command specifying a mate point code in addition to the mate subsystem number or relative cost.

E2435 Cmd Rej: New/existing PC does not exist in the remote PC table

Commands Used: `chg-gsmopts`, `chg-gta`, `chg-gtt`

If the new or existing **xlat** parameter value is **dpc**, the new or existing **ri** parameter value is **ssn**, and the **pc/pca/pci/pcn** parameter is not specified, a point code must exist in the Remote Point Code/MAP table. For the `chg-gta` command, you can override this rule by issuing the `force=yes` parameter.

OR

You entered the `chg-gsmopts` command specifying **ssn** as the existing `ppsmsri1` or `ppsmsri2` parameter value, and the `ppsmSpi1`, `ppsmSpi2`, `ppsmSpCn1` or `ppsmSpCn2` parameter value has not been defined in the Mated Application (MAP) table.

Recovery `chg-gsmopts`, `chg-gtt`

1. Enter the `rtrv-map` command specifying no parameters to display the mate applications information.
2. Re-enter the command specifying a point code displayed in Step 1.

Recovery `chg-gta`

Re-enter the `chg-gta` command that generated the error message specifying the `force=yes` override.

E2437 Cmd Rej: New/existing RI must be GT for new/existing XLAT=DPCNGT

Commands Used: `chg-gta`, `chg-gtt`

The translate indicator (**xlat**) was entered with the value of **dpcngt**, and the routing indicator (**ri**) was equal to **ssn**.

Recovery

Perform one of the following:

- Re-enter the command specifying the **xlat=dpcngt** and **ri=gt** parameters.
OR
- Enter the command specifying the **xlat** parameter equal to **dpc** or **dpcssn**.

E2438 Cmd Rej: MPC and MSSN must be defined for new MULT val

Commands Used: `chg-map`

The command was entered with the **mult=dom** or **mult=shr** parameters, to change the multiplicity from solitary to either dominant or load sharing, and without the mated point code (**mpc**, **mpca**, **mpci**, **mpcn**, **mpcn24**) and **mssn** parameters.

If the **mult=dom** or **mult=shr** parameter is specified, the mated point code (**mpc**, **mpca**, **mpci**, **mpcn**, **mpcn24**) and **mssn** parameters must also be specified.

Recovery

Re-enter the `chg-map` command specifying the mated point code (**mpc**, **mpca**, **mpci**, **mpcn**, **mpcn24**), **mssn**, and the **mult=dom** or **mult=shr** parameter.

E2439 Cmd Rej: New PC does not exist in the routing table

Commands Used: `chg-gtt`

To change the point code to the new point code specified in the command, the new point code must be in the routing table.

Recovery

1. Enter the `rtrv-rte` command to display the point codes in the routing table.
2. Re-enter the `chg-gtt` command, with one of the point code values displayed from the output of the `rtrv-rte` command.

E2440 Cmd Rej: Primary PC/SSN pair already exists

Commands Used: `ent-map`

The command attempted to enter a primary point code and a primary subsystem number that has already been entered. The primary point code and primary subsystem number pairs must be unique.

If the **mapset=dflt** parameter is specified, then the specified PC/SSN cannot exist in the default MAP Set.

Recovery

Re-enter the `ent-map` command specifying different values for the primary point code and the primary subsystem number.

E2441 Cmd Rej: NGT must be specified for new values of XLAT/RI

Commands Used: `chg-gtt`

If the new `xlat` parameter value is `dpcngt`, and the current `ngt` parameter value has been removed, a new `ngt` parameter value must be specified

Recovery

Re-enter the command specifying the `xlat=dpcngt`, `ri=gt`, and the `ngt` parameters.

E2442 Cmd Rej: SSN must be specified for new values of XLAT/RI

Commands Used: `chg-gta`, `chg-gtt`

If the new `xlat` parameter value is `dpcssn`, and the current `ssn` parameter value has been removed, a new `ssn` parameter value must be specified.

Recovery

Re-enter the command specifying the `xlat=dpcssn` and `ssn` parameters.

E2443 Cmd Rej: NGT can only be specified when XLAT=DPCNGT

Commands Used: `chg-gtt`, `ent-gtt`

You entered the new global title translation type (`ngt`), and you entered the translate indicator (`xlat`) with the value of `dpc` or `dpcssn`.

Recovery

Note:

If the ANSI-ITU-China SCCP Conversion feature is enabled, this error code will not be generated. When the ANSI-ITU-China SCCP Conversion feature is not on, the current value of the `xlat` parameter is `dpcngt`, and a different value is specified for the `xlat` parameter, then a value for the `ngt` parameter must not be specified, and the current value of the `ngt` parameter is removed.

Perform one of the following:

- Enter the command specifying the `xlat=dpcngt` and `ngt` parameters.
OR
- Enter the command specifying the `xlat` parameter equal to `dpc` or `dpcssn`, and without specifying the `ngt` parameter.

E2444 Cmd Rej: Allow rejected: terminal is not equipped

Commands Used: `alw-trm`, `rst-trm`

If you attempt to allow a terminal number that has not been equipped, the result is a semantic error message.

Recovery

1. Display all the terminals.
Enter the `rtrv-trm` command.
2. Based on the output from Step 1, re-enter the command for an equipped terminal or equip the terminal for use.

E2446 Cmd Rej: SCCPMT must be specified as 9, 10, 17, 18, or *

Commands Used: `chg-scr-cgpa`, `dlt-scr-cgpa`, `ent-scr-cgpa`, `rtrv-scr-cgpa`

You assigned an invalid value to the `sccpmt` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `sccpmt` parameter value. Refer to the *Commands Manual* for assistance in determining the correct `sccpmt` parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2447 Cmd Rej: NUM exceeds maximum table size

Commands Used: `rtrv-gtt`, `rtrv-loopset`

You assigned an invalid value to the `num` parameter.

Recovery

Re-enter `rtrv-gtt` the command that generated this error message specifying the correct `num` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2448 Cmd Rej: ALL=YES cannot be specified with a point code

Commands Used: `dlt-cspc`

You cannot specify both the **pc** and **all** parameters. To delete an entire concerned signaling point code group, specify the **all=yes** parameter. To delete a single point code from a concerned signaling point code group, specify the **pc** parameter.

Recovery

1. To delete an entire concerned signaling point code group, re-enter the `dlt-cspc` command specifying the **all=yes** parameter.
2. To delete a single point code from a concerned signaling point code group, re-enter the `dlt-cspc` command specifying the **pc** parameter.

E2449 Cmd Rej: CSPC group network type does not match PC network type

Commands Used: `chg-map`, `dlt-cspc`, `ent-cspc`, `ent-map`

The command was entered with a concerned signaling point code (CSPC) group name (**grp**) containing point codes whose network type does not match the network type of the specified point code (**pc**, **pca**, **pci**, **pcn**, or **pcn24**). The network type of the point codes in the specified CSPC group name must match the network type of the specified point code.

Note:

Mixing group and point code network types is supported in the `ent-map`, `chg-map`, and `ent-cspc` commands only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

1. Display the CSPC groups.
Enter the `rtrv-cspc` command. The network type of the point codes in each CSPC group is shown in the *NETWORK* field of the output.
2. Re-enter the command specifying the CSPC group name (**grp**) parameter whose network type matches the network type of the specified point code.

E2450 Cmd Rej: PC/SSN does not exist as a mated application

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `ent-gsmmap-scrn`, `ent-gsms-opcode`

If the point code parameters (**pc/pca/pci/pcn/pcn24** or **npc/npca/npci/npcn/npcn24**) or the subsystem number (**ssn** or **nssn**) parameters are specified, then the **force=yes** parameter must be specified, and the new point code and subsystem number must already be populated in the SCCP application entity set (Remote Point Code / Mated Application Table).

Recovery

1. Verify that the SCCP application entity set (Remote Point Code / Mated Application Table) contains the specified point code or subsystem number.
2. Re-enter the command specifying the **force=yes** parameter.
Call your Customer Care Center if this error message appears again.

E2451 Cmd Rej: Primary remote PC does not exist in routing table

Commands Used: `ent-map`

The primary remote point code specified is not in the Route table. The primary remote point code must already exist in the Route table, or as destination in the ordered route entity set, or reside in a cluster destination for which ordered routes are specified.

Recovery

1. Verify that the primary remote point code was entered correctly and re-enter the command.
2. If the primary remote point code was entered correctly and this error message appears again, enter the `rtrv-rte` command to display the Route table.
3. Re-enter the `ent-map` command specifying one of the point code values displayed in the `rtrv-rte` command.

E2452 Cmd Rej: Remote point code does not exist in MAP table

Commands Used: `chg-map`, `chg-ppsopts`, `dlt-map`, `rtrv-map`

The specified remote point code must exist in the MAP table.

For the `chg-ppsopts` command, if the Flexible GTT Load Sharing (FGTTLS) feature is not enabled, and if the `ri=ssn` parameter is specified, then the value specified for the `pc`, `pca`, `pci`, or `pcn` parameter must exist in the default MAP set of the MAP table.

Recovery

1. If necessary, determine if the Flexible GTT Load Sharing feature is enabled. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
2. Display the point codes in the MAP table. Enter the `rtrv-map` command.
3. If the specified point code is not shown, or is not in the correct MAP set, then the code must be added to the MAP table. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
4. Re-enter the command that generated this error message.
5. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2453 Cmd Rej: Subsystem table for primary remote point code is full

Commands Used: `chg-gtt`, `chg-map`, `ent-gtt`, `ent-map`

Each primary remote point code can contain only 12 subsystem numbers. To enter this command, the subsystem table for primary remote point codes cannot be full.

Recovery

The subsystem number for the given primary remote point code cannot be entered until another subsystem number is deleted.

1. Display the data for this primary remote point code. Enter the `rtrv-map` command or the `rtrv-gtt` command specifying point code parameter for the given primary remote point code.
2. From the output of the `rtrv-map` command or `rtrv-gtt` command, select a subsystem number to be deleted.
3. Enter the `dlt-map` command or the `dlt-gtt` command to delete the subsystem number selected in Step 2.
4. Re-enter the command specifying the parameters that generated this error message to enter the desired subsystem number.

E2454 Cmd Rej: Remote point code table is full

Commands Used: `chg-gtt`, `chg-map`, `ent-gtt`, `ent-map`

You cannot enter more than **1024** remote point codes. To enter this command, the Remote Point Code table cannot be full.

A new remote point code cannot be entered until an existing remote point code is deleted.

Recovery

1. Display the MAP table.
Enter the `rtrv-map` command specifying no parameters.
2. Select a remote point code to be deleted from the output of Step 1.
3. Delete the remote point code.
Enter the `dlt-map` command.
4. Enter the desired remote point code.
Re-enter the `ent-map` command specifying the parameters that generated this error message. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2455 Cmd Rej: ALL cannot be specified with a subsystem

Commands Used: `dlt-map`

You cannot specify the **all** and the **ssn** parameters together. This parameter combination is not allowed.

Recovery

Re-enter the `dlt-map` command specifying either the **all** parameter or the **ssn** parameter, but not both.

E2456 Cmd Rej: SSN does not exist for given remote point code

Commands Used: `chg-map`, `dlt-map`, `rtrv-map`

The specified subsystem number (**ssn**) does not exist. The specified **ssn** must exist for the specified remote PC.

Recovery

1. Verify that the subsystem number was entered correctly.
2. Re-enter the command.
3. If the subsystem number was entered correctly and this error message appears again, enter the `rtrv-map` command specifying no parameters to display the mate applications information.
4. Re-enter the command specifying one of the subsystem number values displayed in the `rtrv-map` command.

E2457 Cmd Rej: SSN can only be specified when XLAT=DPCSSN

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

You entered the subsystem number (**ssn**), and the translate indicator (**xlat**) was entered with the value **dpc** or **dpcngt**. If the **xlat=dpcssn** parameter is specified, the **ssn** parameter must be specified. If the **ssn** parameter is specified, a new or existing **xlat=dpcssn** parameter must be specified. If the **xlat** parameter value is changed from **dpcssn** to **dpc** or **dpcngt**, a new **ssn** parameter value cannot be specified, and the current **ssn** parameter value must be removed.

Recovery

Perform one of the following:

- Re-enter the command specifying the **xlat=dpcssn** and the **ssn** parameters.
- OR
- Re-enter the command without specifying the **ssn** parameter.

E2458 Cmd Rej: SSN cannot be specified without a point code

Commands Used: `rtrv-map`

You entered a subsystem number, but you did not enter a point code. If you enter a subsystem number, you also must enter a point code.

Recovery

Re-enter the `rtrv-map` command, with the point code in addition to the subsystem number.

E2459 Cmd Rej: Alias already in use

Commands Used: `chg-dstn`, `ent-dstn`, `ent-tt`

The specified alias value is already being used by an alias for another translation type.

Recovery

1. Enter the `rtrv-dstn` or `rtrv-tt` command to display the translation types and the aliases.
2. Re-enter the command specifying an alias not shown in the output of Step 1.

E2460 Cmd Rej: Alias defined as translation type

Commands Used: `dlt-tt`, `ent-tt`, `rtrv-tt`

The specified alias is defined as a translation type. The alias cannot be specified if it is defined as a translation type.

Recovery

1. Display the translation types and aliases for these translations types.
Enter the `rtrv-tt` command specifying no parameters.
2. Re-enter the command specifying an alias that is not a translation type.

E2461 Cmd Rej: Alias not assigned to translation name

Commands Used: `rtrv-tt`

The association of the specified alias and specified translation name could not be found.

Recovery

Perform one of the following:

- Verify that the translation name and alias have been entered correctly and re-enter the command.
OR
- Enter the `rtrv-tt` command specifying only the translation name.

E2462 Cmd Rej: GTT table is full

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`, `ent-gta`, `ent-gtt`

The GTT table cannot be full. The GTT table can support up to **269,999** entries.

If the XGTT feature is enabled, the GTT table can support up to either **400,000** or **1,000,000** entries, depending on the controlled feature part number that is enabled.

Recovery

1. The GTT table and Translation Type table contains an extremely large amount of information that could take many hours to display.
However, you can use one of the following commands to display a portion of the table or a specific record to determine if there are entries you can delete:
 - a) the `rtrv-gtt` command for GTT
 - b) the `rtrv-gta` command for EGTT(You can use the `canc-cmd` command to abort the `rtrv-gtt` and `rtrv-gta` commands).
2. If you determine that there is an entry you want to delete, delete the entire range (**gta** to **egta**) for the entry.
3. Due to the size of the table (**269,999**, **400,000**, or **1,000,000** possible entries), if you receive this error message, you may want to reexamine your database structure.

E2463 Cmd Rej: Alias not assigned to translation type

Commands Used: `dlt-tt`, `rtrv-tt`

The association of the specified alias and specified translation type could not be found.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the command specifying a translation type and alias combination shown in the output of Step 1.

E2464 Cmd Rej: Translation TYPE already exists

Commands Used: `ent-tt`

The translation type specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the `ent-tt` command specifying a different value for the translation type.

E2465 Cmd Rej: Translation TYPE defined as an alias

Commands Used: `chg-gtt`, `chg-lnp-ttmap`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `ent-tt`, `rtrv-gtt`, `rtrv-lnp-ttmap`, `rtrv-tt`

The specified translation type was defined as an alias for another translation type. A translation type that is already defined as an alias for another translation type cannot be specified.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the command specifying a translation type that is not defined as an alias.

E2466 Cmd Rej: Translation TYPE specified does not exist

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gta`, `ent-gtt`, `ent-tt`, `rtrv-gtt`, `rtrv-tt`

If the translation type is specified, the translation type must already exist.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command specifying no parameters.
2. Re-enter the command specifying a translation type that exists in the Translation Type table.

E2467 Cmd Rej: TTN already in use

Commands Used: `ent-tt`

The translation name specified is used by another translation type. Translation names must be unique.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the `ent-tt` command specifying a different translation name.

E2468 Cmd Rej: TTN specified does not exist

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `rtrv-gtt`, `rtrv-tt`

The translation type name specified must be in the Translation Type table.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the command specifying one of the translation type names values displayed from the output of the `rtrv-tt` command.

E2469 Cmd Rej: NDGT parameter not permitted with ALIAS

Commands Used: `ent-tt`

You cannot specify the **alias** parameter and the **ndgt** parameter.

Recovery

Re-enter the `ent-tt` command specifying the **alias** parameter or the **ndgt** parameter, but not both.

E2470 Cmd Rej: Point Code network type does not match TT network type

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`, `rtrv-gtt`

The network type (ANSI, ITU-I, ITU-N, or 24-bit ITU-N) of the translation type and the translated point code must be the same. The ANSI-ITU-China SCCP Conversion feature must be on before a translated point code and a translation type in different network types can be specified. You cannot have mixed networks.

Recovery**Note:**

If the ANSI-ITU-China SCCP Conversion feature is enabled, this error code will not be generated.

Re-enter the command specifying a point code whose network type matches the specified translation type.

1. If the translation type is an ANSI translation type (**type** or **typea**), the point code must be an ANSI point code (**pc** or **pca**).
2. If the translation type is an ITU-I translation type (**typei**), the point code type must be an ITU-I point code (**pci**).
3. If the translation type is an ITU-N translation type (**typen** or **typen24**), the point code type an ITU-N point code (**pcn** or **pcn24**).

E2471 Cmd Rej: Translation TYPE has an alias

Commands Used: `chg-rtx`, `dlt-tt`

The specified translation type has an alias assigned to it. The translation type cannot be deleted until the alias assigned to it has been deleted.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Delete the alias assigned to the translation type.
Enter the `dlt-tt` command.
3. Delete the translation type.
Re-enter the `dlt-tt` command.

E2472 Cmd Rej: Translation TYPE is referenced by GTT entry

Commands Used: `dlt-tt`

A translation type cannot be deleted if it is referenced by a current global title translation entry.

Recovery

1. Display the GTT table.
Enter the `rtrv-gtt` command.
2. Delete the global title translation entry associated with the translation type to be deleted.
Enter the `dlt-gtt` command.
3. Delete the translation type.
Enter the `dlt-tt:type=` command.

E2473 Cmd Rej: TTN and TYPE do not correspond to each other

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `rtrv-gtt`, `rtrv-tt`

If the `ttn` parameter is specified, the name must correspond to a translation type entry. For this command to be successful, the specified translation type and translation name must be in the translation table.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` (or `rtrv-ttn` or `rtrv-type`) command.
2. Re-enter the command, with the translation type and/or translation name values displayed from the output of the `rtrv-tt` command.

E2474 Cmd Rej: Translation TYPE must be specified

Commands Used: dlt-tt, ent-tt

The command specified an alias without a translation type. The translation type must be specified if an alias is specified.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the command specifying a translation type as well as the alias.

E2475 Cmd Rej: Either TYPE or TTN must be specified

Commands Used: chg-gtt, dlt-gtt, dlt-tt, ent-gtt, rtrv-gtt

The command was entered without either the **type** or **ttn** parameters specified. This command requires either the translation type (**type**) or the translation name (**ttn**) parameters to be specified.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` command.
2. Re-enter the command specifying either the **type** or **ttn** parameters, using one of the values displayed by the `rtrv-tt` command.

E2477 Cmd Rej: This function is not yet supported

You attempted to enter a command that has not yet been developed and enabled. You may have made a clerical error.

Recovery

Re-enter the command that generated this error message.

If this error message appears again, refer to the *Commands Manual* for valid syntax usage.

E2479 Cmd Rej: NGT must be specified when XLAT=DPCNGT

Commands Used: ent-gtt

You entered the translate indicator (**xlat**) specifying the value **dpcngt**, and the **ngt** parameter was not entered.

Recovery

Re-enter the `ent-gtt` command specifying both the `xlat=dpcngt` and the `ngt` parameters.

E2480 Cmd Rej: RI=GT must be specified when XLAT=DPCNGT

Commands Used: `ent-gta`, `ent-gtt`

You entered the translate indicator (`xlat`) parameter specifying the value `dpcngt`, and the routing indicator (`ri`) was entered specifying the value `ssn`.

Recovery

Re-enter the command specifying both the `xlat=dpcngt` and `ri=gt` parameters.

E2481 Cmd Rej: SSN must be specified when XLAT=DPCSSN

Commands Used: `ent-gta`, `ent-gtt`

You entered the translate indicator (`xlat`) specifying the value `dpcssn` and the subsystem number (`ssn`) was not entered.

Recovery

Re-enter the command specifying both the `xlat=dpcssn` and the `ssn` parameters.

E2484 Cmd Rej: SSN must be 1 if NSFI=AFTPC

Commands Used: `ent-scr-cdpa`

You entered the `nsfi=aftpc` parameter, and the `ssn` parameter is not equal to 1. If the `nsfi=aftpc` parameter is entered, the `ssn` parameter must be equal to 1.

Recovery

Perform one of the following:

- Re-enter the `ent-scr-cdpa` command specifying the `nsfi=aftpc` and the `ssn=1` parameters.

OR

- Re-enter the `ent-scr-cdpa` command specifying the `nsfi=stop` parameter and the `ssn=1-255`.

E2485 Cmd Rej: All entered point code elements must be C if any are C

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`

The command was entered with the one of the point code parameters (**ni**, **nc**, **ncm**, **zone**, **area**, **id**, **msa**, **ssa**, **sp**) equal to **c** (for “Continue”) and the other parameters not equal to **c**. If any of the point code parameters are equal to **c**, then all the point code parameters must be equal to **c**.

Whenever **c** for “continue” is entered for the first parameter, the other parameters will default to **c** in the database.

Recovery

Re-enter the command, specifying the value **c** for the point code parameters, and make sure that the specified point code parameters are of the same network type. Point code parameters **ni**, **nc**, and **ncm** are for ANSI point codes. Point code parameters **zone**, **area**, and **id** are for ITU-I point codes. Point code **npc** is for ITU-N point codes. Point code parameters **msa**, **ssa**, and **sp** are for 24-bit ITU-N point codes.

E2486 Cmd Rej: NSFI must be STOP if COPY or REDIRECT are specified

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-dpc`, `chg-scr-opc`, `chg-scrset`, `chg-scr-sio`, `chg-scr-tt`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`, `ent-scr-opc`, `ent-scrset`, `ent-scr-sio`, `ent-scr-tt`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scrset`, `rtrv-scr-sio`, `rtrv-scr-tt`

You specified the **copy=yes**, the **redirect=yes**, or both parameters, and the value for the **nsfi** parameter was not **stop**. If the **copy=-yes**, the **redirect=yes**, or both parameters are specified, then the **nsfi=stop** parameter must also be specified.

Recovery

Perform one of the following:

- Re-enter the command specifying **nsfi=stop** and either or both of the **copy=yes** and **redirect=yes** parameters.
- OR
- Re-enter the command specifying a value for the **nsfi** parameter not equal to **stop** and without the **copy=yes** or the **redirect=yes** parameter.

E2487 Cmd Rej: EPRI cannot be less than PRI

Commands Used: `chg-scr-sio`, `ent-scr-sio`

The specified **epri** value must be greater than or equal to the **pri** parameter.

Recovery

1. Display the **pri**.

Enter the `rtrv-scr-sio` command. The allowed SIO information for the specified screening reference is displayed.

2. Re-enter the command specifying a new value for the **epri** parameter, using the information displayed in Step 1 to make the value of the **epri** greater than or equal to the **pri** value.

E2488 Cmd Rej: H0 and H1 must be specified for given SI

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`

The service indicator (**si**) is less than or equal to 2, and the heading code values **h0** and **h1** were not specified.

Recovery

Re-enter the command specifying the **si** equal to 2 or less and the heading code values **h0** and **h1**.

E2489 Cmd Rej: H0/H1 matches existing H0/H1 in given SR

Commands Used: `ent-scr-sio`

The specified heading code pair **h0/h1** cannot be in the range of any existing wild-carded **h0/h1** pair in the **sr**, **nic**, and **si** parameters combination.

Note:

A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '*".

Recovery

1. Enter the `rtrv-scr-sio` command to display the data for this screening reference.
2. Re-enter the command specifying a value for the heading code **h0** and **h1** parameters that does not appear in the data displayed during Step 1, or within a range of data displayed during Step 1.

E2490 Cmd Rej: H0 and H1 cannot be specified for SI greater than 2

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`, `rtrv-scr-sio`

You cannot specify the **h0** and **h1** parameters if the value of the service indicator (**si**) is greater than 2.

Recovery

1. For service indicator values greater than 2, re-enter the command without specifying the **h0** and **h1** parameters.

2. For service indicator values less than or equal to 2, re-enter the command specifying the **h0** and **h1** parameters.

E2491 Cmd Rej: NH0 and NH1 cannot be specified for NSI greater than 2

Commands Used: `chg-scr-sio`

You cannot specify the **nh0** and **nh1** parameters if the value of the new service indicator (**nsi**) is greater than 2.

Recovery

1. For new service indicator values greater than 2, re-enter the **chg-scr-sio** command without specifying the **nh0** and **nh1** parameters.
2. For new service indicator values less than or equal to 2, re-enter the **chg-scr-sio** command specifying the **nh0** and **nh1** parameters.

E2492 Cmd Rej: The NSFI / RI combination is invalid

Commands Used: `chg-scr-cgpa`, `ent-scr-cgpa`

You specified a combination of values for the **ri** parameter and the **nsfi** parameter that are not allowed.

- If you specify **ri=gt**, you can only specify **nsfi=tt**
- If you specify **ri=dpc**, you can only specify only the **nsfi=cdpa**
- If you specify the **ri=***, you can specify either **nsfi=tt** or **nsfi=cdpa**

Recovery

Perform one of the following:

- Re-enter the command specifying **ri=gt** and **nsfi=tt**
OR
- Re-enter the command specifying **ri=dpc** and **nsfi=cdpa**
OR
- Re-enter the command specifying **ri=*** and either **nsfi=tt** or **nsfi=cdpa**

E2493 Cmd Rej: H1 must be wild card if H0 is wild card

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`, `rtrv-scr-sio`

You cannot specify a wild-card (*) value for the **h0** parameter and not for the **h1** parameter.

Note:

A 'wild card' is a term to describe the asterisk parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '*'".

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the **h0** and **h1** parameters.
OR
- Re-enter the command specifying wild-card (asterisk) values for both the **h0** and **h1** parameters.
OR
- Re-enter the command specifying values for both the **h0** and **h1** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2494 Cmd Rej: The NSFI is invalid for this screen type

Commands Used: chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-dpc, chg-scr-opc, chg-scrset, chg-scr-sio, chg-scr-tt, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-dpc, ent-scr-opc, ent-scrset, ent-scr-sio, ent-scr-tt

You specified a value for the **nsfi** parameter that is not allowed for this command.

Recovery

Re-enter the command specifying the correct value for the **nsfi** parameter. Refer to the *Commands Manual* for the correct parameter values.

E2495 Cmd Rej: Point codes contain invalid wild card combinations

Commands Used: chg-scr-aftpc, chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, dlt-scr-aftpc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-cdpa, dlt-scr-cgpa, dlt-scr-destfld, dlt-scr-dpc, dlt-scr-opc, ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-opc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc

The "wild card" (asterisk *) parameter value can or must be specified only in certain parameter combinations in the gateway screening commands. Refer to the descriptions of the commands in the *Commands Manual* for valid combinations of parameters that allow the use of the wild card parameter value.

Note:

A 'wild card' is a term used to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for all and every entry in the database including the value '*'.

Recovery

Re-enter the command with a valid combination of parameter values and correct use of the wild card value.

E2496 Cmd Rej: NI, ZONE, MSA or NPC cannot be C - more than one exists

Commands Used: `dlt-scr-blkdpc`, `dlt-scr-blkopc`

An attempt was made to delete the point code **c-c-c**, or **npc=c**, from the screening reference, and the screening reference contains more than one entry. The point code **c-c-c**, or **npc=c**, cannot be deleted until all other entries in the screening reference have been deleted.

Recovery

Re-enter the command specifying different values for the **ni**, **nc**, **ncm** parameters for an ANSI point code, **zone**, **area**, **id** parameters for an ITU-I point code, **msa**, **ssa**, **sp** for a 24-bit ITU-N point code, or the **npc** parameter for an ITU-N point code.

E2497 Cmd Rej: NI, ZONE, MSA or NPC cannot be C for existing blocked SR

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`

The point code **c-c-c**, or **npc=c**, was specified for a SR (screening reference) that already exists. The point code **c-c-c**, or **npc=c**, can be specified only for a screening reference that does not exist. If a blocked screen reference exists, then **ni**, **zone**, **msa**, or **npc** cannot equal **c**. Point code **c-c-c** already exists for this blocked SR.

Recovery

Re-enter the command specifying values other than **c** for the point code.

E2498 Cmd Rej: Last entry in given SR is ref'ed by another screen

Commands Used: `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-dpc`, `dlt-scr-isup`, `dlt-scr-opc`, `dlt-scr-sio`, `dlt-scr-tt`

The specified screening reference contains only one entry. If this screening reference is referenced by another screen, it cannot be deleted.

Recovery

1. Find which screen is referencing the specified screening reference; enter one of the following commands with these parameters to display the screen set data:
 - a) `rtrv-scr-aftpc`, for the `dlt-scr-aftpc` command
 - b) `rtrv-scr-blkdpc`, for the `dlt-scr-blkdpc` command
 - c) `rtrv-scr-blkopc`, for the `dlt-scr-blkopc` command
 - d) `rtrv-scr-cdpa`, for the `dlt-scr-cdpa` command
 - e) `rtrv-scr-cgpa`, for the `dlt-scr-cgpa` command
 - f) `rtrv-scr-dpc`, for the `dlt-scr-dpc` command
 - g) `rtrv-scr-opc`, for the `dlt-scr-opc` command
 - h) `rtrv-scrset`, for the `dlt-scrset` command
 - i) `rtrv-scr-sio`, for the `dlt-scr-sio` command
 - j) `rtrv-scr-tt`, for the `dlt-scr-tt` command
2. When the screen is found, change the `nsr` parameter to a value other than the specified screening reference that generated this error message.
Enter one of the following commands:
 - a) `chg-scr-aftpc`, for the `dlt-scr-aftpc` command
 - b) `chg-scr-blkdpc`, for the `dlt-scr-blkdpc` command
 - c) `chg-scr-blkopc`, for the `dlt-scr-blkopc` command
 - d) `chg-scr-cdpa`, for the `dlt-scr-cdpa` command
 - e) `chg-scr-cgpa`, for the `dlt-scr-cgpa` command
 - f) `chg-scr-dpc`, for the `dlt-scr-dpc` command
 - g) `chg-scr-opc`, for the `dlt-scr-opc` command
 - h) `chg-scrset`, for the `dlt-scrset` command
 - i) `chg-scr-sio`, for the `dlt-scr-sio` command
 - j) `chg-scr-tt`, for the `dlt-scr-tt` command
3. Repeat Steps 1 and 2 for any other screens found referencing the screening reference specified that generated this error message.
4. Re-enter the command that generated this error message.

E2499 Cmd Rej: Maximum number of rules exceeded in screen set

Commands Used: `chg-scr-aftpc`, `ent-scr-aftpc`, `chg-scr-blkdpc`, `ent-scr-blkdpc`, `chg-scr-blkopc`, `ent-scr-blkopc`, `chg-scr-cdpa`, `ent-scr-cdpa`, `chg-scr-cgpa`, `ent-scr-cgpa`, `chg-scr-dpc`, `ent-scr-dpc`, `chg-scr-opc`, `ent-scr-opc`, `chg-scrset`, `ent-scrset`, `chg-scr-sio`, `ent-scr-sio`, `chg-scr-tt`, `ent-scr-tt`

You exceeded the available capacity for the screen set. If the screen set reaches 100% capacity (indicated by the "100% full" message), the EAGLE 5 ISS will allow subsequent entries. An error will occur, however, when downloading the screen set to the card. Screen sets should not exceed 100% capacity.

Recovery

Delete screen set entries until the capacity is below 100%, using the appropriate version of the `dlt-scr-` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2500 Cmd Rej: Maximum number of screen sets exceeded

Commands Used: `ent-scrset`

The system can contain up to **63** user-definable screen sets. The attempt to add a screen set exceeds this limit. To add another screen set, one has to be deleted.

Recovery

1. Display the screen sets.
Enter the `rtrv-scrset` command. Select a screen set to be deleted.
2. Display the linksets.
Enter the `rtrv-ls` command.
3. From the linksets that reference a screen set (field `SCRSET`), record the data from the linkset(s) that reference the screen set to be deleted.
4. Change the screen set reference of the linkset(s), from the screen set to be deleted to another screen set.
Enter the `chg-ls` command.
5. Delete the screen set.
Enter the `dlt-scrset` command.
6. Add the new screen set.
Enter the command that generated this error message.

E2501 Cmd Rej: Mixed point code types are not allowed

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`, `ent-scr-blkdpc`, `chg-scr-blkdpc`, `dlt-scr-blkdpc`, `rtrv-scr-blkdpc`, `ent-scr-blkopc`, `chg-scr-blkopc`, `dlt-scr-blkopc`, `rtrv-scr-blkopc`, `ent-scr-dpc`, `chg-scr-dpc`, `dlt-scr-dpc`, `rtrv-scr-dpc`, `ent-scr-opc`, `chg-scr-opc`, `dlt-scr-opc`, `rtrv-scr-opc`, `ent-scr-aftpc`, `chg-scr-aftpc`, `dlt-scr-aftpc`, `rtrv-scr-aftpc`, `ent-scr-cdpa`, `chg-scr-cdpa`, `dlt-scr-cdpa`, `rtrv-scr-cdpa`, `ent-scr-cgpa`, `chg-scr-cgpa`, `dlt-scr-cgpa`, `rtrv-scr-cgpa`, `ent-scr-destfld`, `chg-scr-destfld`, `rtrv-scr-destfld`

The command was entered with a point code that contains different network types. Point codes are specified by the following parameters:

ANSI point code – **ni**, **nc**, **ncm** and for the enter and change commands — **nni**, **nnc**, **nncm**

ITU-I point code – **zone**, **area**, **id** and for the enter and change commands — **nzone**, **narea**, **nid**

ITU-N point code – **npc** and for the enter and change commands — **nnpc**

24-bit ITU-N point code - **msa, ssa, sp** and for the enter and change commands — **nmsa, nssa, nsp**

An example of a point code containing different network types (i.e., mixed types of point codes) is **ni-area-npc**. This is not allowed. If any of the enter and change commands are entered, an existing point code of one network type can be changed to another network type—as long as all the proper parameters are used.

Recovery

Re-enter the command specifying the proper values for point codes.

ANSI point code – **ni, nc, ncm** and for the enter and change commands — **nni, nnc, nncm**

ITU-I point code – **zone, area, id** and for the enter and change commands — **nzone, narea, nid**

ITU-N point code – **npc** and for the enter and change commands — **nnpc**

24-bit ITU-N point code - **msa, ssa, sp** and for the enter and change commands — **nmsa, nssa, nsp**

E2502 Cmd Rej: NSR cannot be specified if COPY or REDIRECT are specified

Commands Used: **chg-scr-blkdpc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-dpc, rtrv-scr-opc, rtrv-scrset, rtrv-scr-sio, rtrv-scr-tt**

You cannot specify the **nsr** parameter if the **copy=yes** and / or the **redirect=yes** parameters are specified.

Recovery

Perform one of the following:

- Re-enter the command specifying the **copy=yes** and / or the **redirect=yes** parameters, without specifying the **nsr** parameter.
- OR
- Re-enter the command specifying the **nsr** parameter, without specifying the **copy=yes** and / or the **redirect=yes** parameters.

E2503 Cmd Rej: NC cannot be zero when NI is less than 6

Commands Used: **chg-scr-aftpc, chg-scr-blkdpc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-dpc, chg-scr-opc, dlt-scr-aftpc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-cdpa, dlt-scr-cgpa, dlt-scr-dpc, dlt-scr-opc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-dpc, ent-scr-opc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-dpc, rtrv-scr-opc**

The network cluster number must be **1-255**, because the network identifier entered is less than or equal to 5.

Recovery

Re-enter the command specifying the proper network cluster number or the proper network identifier. Refer to the *Commands Manual* to find correct values.

E2504 Cmd Rej: New/existing NSFI=AFTPC requires new/existing SSN=1

Commands Used: `chg-scr-cdpa`

You entered the **nsfi=aftpc** parameter and the **ssn** parameter is not equal to 1. If you enter the **nsfi=aftpc** parameter, then **ssn** must be equal to 1.

Recovery

Perform one of the following:

- Re-enter the `chg-scr-cdpa` command specifying the **nsfi=aftpc** and the **ssn=1** parameters.
- OR
- Re-enter the `chg-scr-cdpa` command specifying the **nsfi=stop** parameter and the **ssn** parameter equal to 1-255.

E2505 Cmd Rej: NH0 and NH1 must be specified for given NSI

Commands Used: `chg-scr-sio`

The new service indicator (**nsi**) specified is less than or equal to 2 and the **nh0** and **nh1** parameters have not been specified. If the new service indicator is less than or equal to 2, and the old **si** was greater than 2, the **nh0** and **nh1** parameters must be specified.

Recovery

1. For service indicator values greater than 2, re-enter the command without specifying the **nh0** and **nh1** parameters.
2. For service indicator values less than or equal to 2, re-enter the command specifying the **nh0** and **nh1** parameters.

E2506 Cmd Rej: New H0/H1 matches existing wild carded H0/H1 in given SR

Commands Used: `chg-scr-sio`

Either the **h0** or **h1**, or both, have been specified where they had previously been set (by default) to be wild-carded.

Note:

A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '*'".

Recovery

Change the h0 and/or h1 settings. Enter the `chg-scr-sio` command.

E2507 Cmd Rej: NH0 and NH1 cannot be specified for SI greater than 2

Commands Used: `chg-scr-sio`

You cannot specify a value for the service indicator that is greater than 2, and the **nh0** and **nh1** parameters.

Recovery

Perform one of the following:

- Re-enter the `chg-scr-sio` command specifying a value for the **si** parameter greater than 2, without specifying the **nh0** and **nh1** parameters.
OR
- Re-enter the `chg-scr-sio` command specifying a value for the **si** parameter less than 2 and the **nh0** and **nh1** parameters.

E2508 Cmd Rej: SCMGFID is invalid

Commands Used: `chg-scr-cdpa`, `dlt-scr-cdpa`, `ent-scr-cdpa`, `rtrv-scr-cdpa`

You probably did one of the following:

- Specified the **ssn=1** parameter and failed to specify the **scmgfid** parameter
OR
- Specified the **ssn** parameter with a value other than 1 and specified the **scmgfid** parameter

These combinations are not allowed. You **must** specify the **scmgfid** parameter if you specify the **ssn=1** parameter. You **must not** specify the **scmgfid** parameter if you specify a value other than 1 for the **ssn** value.

Recovery

Perform one of the following:

- Re-enter the command specifying both the **ssn=1** parameter and the **scmgfid** parameter.
OR
- Re-enter the command specifying the **ssn** parameter with a value other than 1, and without specifying the **scmgfid** parameter.

E2509 Cmd Rej: NH1 must be wild card if NH0 is wild card

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`, `rtrv-scr-sio`

You specified a wild-card value for the `nh0` parameter but not the `nh1` parameter.

Note:

A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '**".

Recovery

Perform one of the following:

- Re-enter the command without specifying the **nh0** and **nh1** parameters.
OR
- Re-enter the command specifying the **nh0** and **nh1** parameters both assigned to wild-card (indicated by an asterisk) values.
OR
- Re-enter the command specifying both the **nh0** and **nh1** parameters assigned to specific values.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2510 Cmd Rej: NI is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

You entered a combination of the parameters **ni**, **nc**, and/or **ncm** that is not allowed. Use the following guidelines in determining what combinations of these parameters need to be entered:

- If **ni**, **nc**, or **ncm** is specified, a screening reference must be specified.
- If you specify the **ni** parameter as an asterisk (`ni=*`) or as a range, you must specify the **nc** and **ncm** parameters as an asterisk or as the full range **000-255**.
- If you specify a single value for the **nc** parameter, you also must specify a single value for the **ni** parameter.
- If you specify a range for the **nc** parameter, you must specify a single value for the **ni** parameter, and you must specify the **ncm** parameter as an asterisk (`ncm=*`) or the full range of **000-255**.
- If you specify a single value, or a range other than the full range of **000-255**, for the **ncm** parameter, you must specify the **ni** and the **nc** parameters with a single value.

Recovery

Re-enter the command specifying the appropriate combinations of parameters as outlined in the preceding list.

Refer to “Point Code Formats and Conversion” in Appendix A of the *Commands Manual* for a detailed description of point code formats, rules for specification, and examples.

E2511 Cmd Rej: NC is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`, `rept-meas`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

For the gateway screening commands:

You entered a combination of the parameters **ni**, **nc**, and/or **ncm** that is not allowed. Use the following guidelines in determining what combinations of these parameters you need to enter:

- If **ni**, **nc**, or **ncm** is specified, a screening reference must be specified.
- If you specify the **ni** parameter as an asterisk (**ni**=*) or as a range, you must specify the **nc** and **ncm** parameters as an asterisk or as the full range **000-255**.
- If you specify a single value for the **nc** parameter, you also must specify a single value for the **ni** parameter.
- If you specify a range for the **nc** parameter, you must specify a single value for the **ni** parameter, and you must specify the **ncm** parameter as an asterisk (**ncm**=*) or the full range of **000-255**.
- If you specify a single value, or a range other than the full range of **000-255**, for the **ncm** parameter, you must specify the **ni** and the **nc** parameters with a single value.
- If you specify the **nc** parameter as an asterisk (**nc**=*), you must specify the **ncm** parameter as an asterisk or as the full range **000-255**.

For the `rept-meas` command:

You specified the **origininc** parameter and the **ni** and **nc** parameters, and the measurements data is not available.

Recovery

Re-enter the gateway screening command specifying the appropriate combinations of parameters as outlined in the preceding list.

E2512 Cmd Rej: NCM is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`,

dlt-scr-dpc, dlt-scr-opc, ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-opc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc

You entered a combination of the parameters **ni**, **nc**, and/or **ncm** that is not allowed. Use the following guidelines in determining what combinations of these parameters need to be enter:

- If you specify the **ni** parameter as an asterisk (**ni=***) or as a range, you must specify the **nc** and **ncm** parameters as an asterisk or as the full range **000-255**.
- If you specify a range for the **nc** parameter, you must specify a single value for the **ni** parameter, and you must specify the **ncm** parameter as an asterisk (**ncm=***) or the full range of **000-255**.
- If you specify a single value, or a range other than the full range of **000-255**, for the **ncm** parameter, you must specify the **ni** and the **nc** parameters with a single value.
- If you specify the **nc** parameter as an asterisk (**nc=***), you must specify the **ncm** parameter as an asterisk or as the full range **000-255**.

Recovery

Re-enter the command specifying the appropriate combinations of parameters as outlined in the preceding list.

E2514 Cmd Rej: PC/SSN/RI/SCCPMT already exists in given SR

Commands Used: chg-scr-cgpa, ent-scr-cgpa

While holding the value of the screening reference parameter **sr** constant, you attempted to change the value of one of the other parameters. But, the other parameters already have the value you assigned to them.

Recovery

1. Enter the `rtrv-scr-cgpa` command to acquire the current state of the parameters with the given **sr** parameter.
2. Re-enter the command that generated this error message, using appropriate parameter values acquired in Step 1.

E2515 Cmd Rej: PC/SSN/RI/SCCPMT does not exist in given SR

Commands Used: chg-scr-cdpa, dlt-scr-cdpa, rtrv-scr-cdpa, dlt-scr-cdpa, dlt-scr-cgpa,

You entered this command specifying the **pc**, **ssn**, **ri**, or **sccpmt** parameter set to a value that does not exist in the screening reference. You cannot change, retrieve, or delete an entry that does not exist.

Recovery

1. Enter the `rtrv-scr-cgpa` command without specifying the **pc**, **ssn**, **ri**, or **sccpmt** parameter, to acquire the current state of the parameters.

2. Re-enter the command that generated this error message, using appropriate **pc**, **ssn**, or **scmgfid** parameter values acquired in Step 1.

E2516 Cmd Rej: PC/SSN/SCMG already exists in given SR

Commands Used: `chg-scr-cdpa`, `ent-scr-cdpa`

While holding the value of the screening reference parameter **sr** constant, you attempted to change the value of one of the other parameters. But, the new parameters already exist in the database.

You cannot add a CDPA entry that matches any specific or range or asterisk entry that already exists in the specified screening table.

Recovery

1. Enter the `rtrv-scr-cgpa` command to acquire the current state of the parameters.
2. Re-enter the command that generated this error message using appropriate parameter values acquired in Step 1.

E2517 Cmd Rej: PC/SSN/SCMGFID does not exist in given SR

Commands Used: `chg-scr-cdpa`, `dlt-scr-cdpa`, `ent-scr-cdpa`, `rtrv-scr-cdpa`,
`dlt-scr-cdpa`, `dlt-scr-cgpa`,

You entered this command specifying the **pc**, **ssn**, or **scmgfid** parameter set to a value that does not exist in the screening reference.

Recovery

1. Enter the `rtrv-scr-cgpa` command without specifying the **pc**, **ssn**, or **scmgfid** parameter, to acquire the current state of the parameters.
2. Re-enter the command that generated this error message, specifying the appropriate **pc**, **ssn**, or **scmgfid** parameter values acquired in Step 1.

E2518 Cmd Rej: NNIC, NSI, and NH0/NH1 entry already exists in given SR

Commands Used: `chg-scr-sio`

For the **nnic**, **nsi**, **nh0**, and **nh1** parameters to be changed, the values cannot exist in the specified screening reference.

Recovery

1. Verify that the values for the **nnic**, **nsi**, **nh0**, and **nh1** parameters have been entered correctly and re-enter the `chg-scr-sio` command.

2. If the values for these parameters are entered correctly and this error message appears again, enter the `rtrv-scr-sio:sr=` command to display the allowed SIO information for the specified screening reference.
3. Re-enter the `chg-scr-sio` command specifying different values for the **nnic**, **nsi**, **nh0**, and **nh1** parameters that do not match those displayed in Step 2.

E2519 Cmd Rej: ISUPMT/TUPMT already exists in given SRI

Commands Used: `chg-scr-isup`, `ent-scr-isup`

You attempted to specify an allowed ISUP screening reference in a given `sr` with an existing ISUPMT (ISUP message type) or an allowed ISUP screening reference in a given SR with an existing TUPMT (TUP message type). Duplicate ISUPMTs and TUPMTs are not permitted.

Recovery

1. Verify the values for the **sr** and **isupmt** parameters and the **sr** and **tupmt** parameters have been entered correctly, and re-enter the command.
2. If the value for these parameters have been entered correctly and this error message appears again, enter the `rtrv-scr-isup:sr=` command to display the allowed ISUP information for the specified screening reference.
3. Re-enter the command specifying a different values for the parameters, making certain that the values do not duplicate those displayed in Step 2.

E2520 Cmd Rej: ISUPMT/TUPMT does not exist in given SR

Commands Used: `chg-scr-isup`, `dlt-scr-isup`

You specified an allowed ISUP or TUP screening reference in a given `sr` for an ISUPMT (ISUP message type) or for an TUPMT (TUP message type) that does not exist in the database. A valid **isupmt** or **tupmt** parameter is required for this command.

Recovery

Verify the **isupmt** or **tupmt** parameter, and re-enter the command specifying an existing **isupmt** or **tupmt** parameter.

E2521 Cmd Rej: NIC must be specified for given SI

Commands Used: `rtrv-scr-sio`

The command was entered with a service indicator value (**si**), and the network indicator code value (**nic**) was not specified. The **si** parameter cannot be specified if the **nic** parameter is not specified.

Recovery

1. Display all the network indicator codes and service indicators in the database.

Enter the `rtrv-scr-sio` command specifying no parameters.

2. If you wish to display a particular service indicator entry, enter the `rtrv-scr-sio` command specifying the values for both the **nic** and **si** parameters shown in output of Step 1.

E2522 Cmd Rej: NIC does not exist for given SR

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `rtrv-scr-sio`

The command was entered, and the combination of the screening reference (**sr**) and network indicator code (**nic**) could not be found in the database.

Recovery - `rtrv-scr-sio`

Re-enter the `rtrv-scr-sio` command specifying no parameters.

Recovery - `chg-scr-sio`, `dlt-scr-sio`

1. Display the allowed SIO information in the database.
Enter the `rtrv-scr-sio` command.
2. Re-enter the command specifying a screening reference (**sr**) and network indicator code (**nic**) combination found in the output of Step 1.

E2525 Cmd Rej: NI, ZONE, MSA or NPC must be C when creating new blocked SR

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`

To create a new blocked DPC or OPC screening reference, you must specify **ni**, **zone**, **msa** with the point code **c-c-c** or **npc** with **c**. The first entry in a new screen reference for a blocked DPC or OPC must be the point code **c-c-c**, or **npc=c**.

Recovery

Re-enter the command specifying the point code **c-c-c** for an ANSI, ITU-I, or 24-bit ITU-N point code, or **npc=c** for an ITU-N point code.

E2526 Cmd Rej: All new PC parms must be null if NI, ZONE, MSA or NPC = C

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`

If the **ni**, **zone**, **msa**, or **npc** point codes are set to **c**, all new point code parameters must be null. The point code **c-c-c** cannot be changed to a numbered point code.

Recovery

Re-enter the command specifying new point code parameters as null values if the **ni**, **zone**, **msa**, or **npc** point codes are set to **c**.

E2527 Cmd Rej: C value not allowed

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`, `ent-scr-aftpc`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

You specified a new point code that contained the value **c**. A point code with the value **c** is not allowed when changing a screening entry whose **nsfi** is equal to **fail** for these parameters: **nni-nnc-nncm**, **nzone-narea-nid**, **nmsa-nssa-nsp**, or **nnpc**.

Recovery

Re-enter the command specifying values other than **c** for the new point code.

E2528 Cmd Rej: No match on AREA or SSA parameter during retrieve

Commands Used: `rtrv-scr-sio`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for either the **area** or **ssa** parameter.

Recovery

Re-enter the command specifying the screening reference to show all area values, as well as other values for the screening reference (**sr**).

E2529 Cmd Rej: No match on EPRI parameter during retrieve

Commands Used: `rtrv-scr-sio`

The ending priority (**epri**) was not found.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all ending priorities, as well as other values for the screening reference.

E2530 Cmd Rej: No match on H0 parameter during retrieve

Commands Used: `rtrv-scr-sio`

The h0 heading code (**h0**) was not found.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all **h0** heading codes, as well as other values for the screening reference.

E2531 Cmd Rej: No match on H1 parameter during retrieve

Commands Used: `rtrv-scr-sio`

The h1 heading code (**h1**) was not found.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all h1 heading codes, as well as other values for the screening reference.

E2532 Cmd Rej: No match on ID or SP parameter during retrieve

Commands Used: `rtrv-scr-sio`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the **id** or **sp** parameter.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all ID values, as well as other values for the screening reference.

E2533 Cmd Rej: No match on NC parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match for the network cluster (**nc**) parameter was found.

Recovery

Re-enter the command specifying the screening reference to show all network clusters, as well as other values for the screening reference.

E2534 Cmd Rej: No match on NCM parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`
No match was found for the network cluster member (**ncm**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all network cluster members, as well as other values for the screening reference.

E2535 Cmd Rej: No match on NI parameter during retrieve

Commands Used: `rept-meas`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`
For the gateway screening commands, no match was found for the network identifier (**ni**) parameter.
For the `rept-meas` command, you specified the **origini** parameter and the **ni** parameter, and the measurements data is not available.

Recovery - Gateway Screening commands

Re-enter the command specifying the screening reference, to show all network identifiers as well as other values for the screening reference.

Recovery - `rept-meas`

1. Verify that you entered the correct **origni** and **ni** parameter values in the command.
2. Re-enter the `rept-meas` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2536 Cmd Rej: No match on NIC parameter during retrieve

Commands Used: `rtrv-scr-sio`

The specified network indicator code (**nic**) parameter was not found.

Recovery

Enter the `rtrv-scr-sio:all=yes` command to show all **nic** values as well as other values for the screening reference.

E2537 Cmd Rej: No match on NPC parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the national point code (**npc**) parameter.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all national point codes, as well as other values for the screening reference.

E2538 Cmd Rej: No match on NSFI parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`,
`rtrv-scrset`, `rtrv-scr-sio`, `rtrv-scr-tt`

No match was found for the next screening function identifier (**nsfi**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all next screening function identifiers, as well as other values for the screening reference.

E2539 Cmd Rej: No match on NSR parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`,
`rtrv-scrset`, `rtrv-scr-sio`, `rtrv-scr-tt`

No match was found for the next screen reference (**nsr**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all next screening function identifiers, as well as other values for the screening reference.

E2540 Cmd Rej: No match on PRI parameter during retrieve

Commands Used: `rtrv-scr-sio`

The message priority (**pri**) was not found.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all message priorities, as well as other values for the screening reference.

E2541 Cmd Rej: No match on RI parameter during retrieve

Commands Used: `rtrv-scr-cgpa`

No match was found for the routing indicator (**ri**) parameter.

Recovery

Re-enter the `rtrv-scr-cgpa` command specifying the screening reference to show all routing indicators, as well as other values for the screening reference.

E2542 Cmd Rej: No match on SI parameter during retrieve

Commands Used: `rtrv-scr-sio`

The service indicator (**si**) was not found.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all service indicators, as well as other values for the screening reference.

E2543 Cmd Rej: No match on SSN parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`

No match was found for the subsystem number (**ssn**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all subsystem numbers, as well as other values for the screening reference.

E2544 Cmd Rej: No match on TYPE parameter during retrieve

Commands Used: `rtrv-scr-tt`

No match was found for the translation type (**type**) parameter.

Recovery

Re-enter the `rtrv-scr-tt` command specifying the screening reference to show all translation types, as well as other values for the screening reference.

E2545 Cmd Rej: No match on ZONE or MSA parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`,
`rtrv-scr-sio`

No match was found for the **zone** or **msa** parameter.

Recovery

Re-enter the command specifying the screening reference to show all **zone** values, as well as other values for the screening reference.

E2546 Cmd Rej: NSFI must be specified

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`

You specified the point code equal to **c-c-c** and the **nsfi** parameter was not specified. You must specify the **nsfi** parameter if the point code is **c-c-c**.

Recovery

Re-enter the command along with the **nsfi** parameter.

E2547 Cmd Rej: NSFI must not be FAIL

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `ent-scr-blkdpc`, `ent-scr-blkopc`

You specified the point code equal to **c-c-c** and the **nsfi** parameter equal to **fail**. The **nsfi** parameter cannot be **fail** if the point code is **c-c-c**. If the SR (screen reference) does not exist, you must correct the command parameters; a new BLKPOPC screening table will be created.

Recovery

Re-enter the command specifying:

- The **ni**, **zone**, **msa**, or **npc** parameter equal to **c**
- The **nsfi** parameter equal to any value other than **fail**.

For more information about the command, refer to the *Commands Manual*.

E2548 Cmd Rej: NSFI must be STOP

Commands Used: `chg-scr-aftpc`, `chg-scr-isup`, `ent-scr-aftpc`, `ent-scr-isup`

You specified the **nsfi** parameter specifying a value that is not allowed for this command.

Recovery

Re-enter the command specifying the **nsfi=stop** parameter. The value **stop** is the only value that can be specified for the **nsfi** parameter.

E2549 Cmd Rej: NSFI must be FAIL

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`

You specified the point code not equal to **c-c-c** and the **nsfi** parameter not equal to **fail**. If the point code is not **c-c-c**, the **nsfi** must be **fail**.

Recovery

Re-enter the command specifying the **nsfi** parameter equal to **fail**.

E2550 Cmd Rej: NSFI / NSR cannot be specified

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `rtrv-scr-aftpc`, `rtrv-scr-cgpa`,
`rtrv-scr-opc`, `rtrv-scrset`

You specified the **nsfi** equal to **stop** or **fail**, and the **nsr** parameter was specified. If the **nsfi** is **stop** or **fail**, the **nsr** cannot be specified.

Recovery

Re-enter the command specifying the **nsfi** equal to **stop** or **fail**, without specifying the **nsr** parameter.

E2551 Cmd Rej: NSI must be specified for given NNIC

Commands Used: `chg-scr-sio`

The command was entered with a new network indicator code (**nnic**), and a new service indicator (**nsi**) has not been specified. If a new service indicator is specified, a new network indicator code must be specified.

Recovery

Re-enter the `chg-scr-sio` command specifying either both the **nnic** and **nsi** parameters, or neither the **nnic** and **nsi** parameters.

E2552 Cmd Rej: NSFI and NSR do not reference an existing screen

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`,
`chg-scr-dpc`, `chg-scr-opc`, `chg-scrset`, `chg-scr-sio`, `chg-scr-tt`,

ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-dpc,
ent-scr-opc, ent-scrset, ent-scr-sio, ent-scr-tt

The values specified for thr **nsfi** and **nsr** parameters do not reference an existing screen.

Recovery

1. Verify that the **nsfi** and **nsr** parameters were entered correctly, and re-enter the command.
2. If the **nsfi** and **nsr** were entered correctly and this error message appears again, display the screen set data.

Enter one of the following commands with these parameters:

- a) `rtrv-scr-blkdpc`, for the `chg-scr-blkdpc` command and **nsfi=blkdpc** parameter
 - b) `rtrv-scr-blkopc`, for the `chg-scr-blkopc` command and **nsfi=blkopc** parameter
 - c) `rtrv-scr-cdpa`, for the `chg-scr-cdpa` command and **nsfi=cdpa** parameter
 - d) `rtrv-scr-cgpa`, for the `chg-scr-cgpa` command and **nsfi=cgpa** parameter
 - e) `rtrv-scr-dpc`, for the `chg-scr-dpc` command and **nsfi=dpc** parameter
 - f) `rtrv-scr-opc`, for the `chg-scr-opc` command and **nsfi=opc** parameter
 - g) `rtrv-scrset`, for the `chg-scrset` and `ent-scrset` commands
 - h) `rtrv-scr-sio`, for the `chg-scr-sio` command and **nsfi=sio** parameter
 - i) `rtrv-scr-tt`, for the `chg-scr-tt` command and **nsfi=tt** parameter
3. Re-enter the command specifying the correct **nsfi** and **nsr** parameters displayed in Step 2.

E2553 Cmd Rej: NSR must be specified for given NSFI

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`,
`chg-scr-dpc`, `chg-scr-opc`, `chg-scrset`, `chg-scr-sio`, `chg-scr-tt`,
`ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`,
`ent-scr-opc`, `ent-scrset`, `ent-scr-sio`, `ent-scr-tt`

You specified the **nsfi** parameter equal to a value other than **stop** and the **nsr** parameter was not specified or, for the `chg-scr-blkdpc`, `chg-scr-blkopc`, `ent-scr-blkdpc`, and `ent-scr-blkopc` commands, You specified the **nsfi** parameter equal to a value other than **fail**, and the **nsr** parameter was not specified. The **nsr** parameter must be specified if the value of the **nsfi** parameter is anything other than **stop** or **fail**.

Recovery

Re-enter the command specifying the **nsr** parameter.

E2554 Cmd Rej: NSR cannot be specified when NSFI is STOP or FAIL

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`,
`chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-isup`, `chg-scr-opc`,
`chg-scrset`, `chg-scr-sio`, `chg-scr-tt`, `dlt-scr-cgpa`, `ent-scr-aftpc`,
`ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`,
`ent-scr-dpc`, `ent-scr-isup`, `ent-scr-opc`, `ent-scrset`, `ent-scr-sio`, `ent-scr-tt`,

rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-destfld,
rtrv-scr-dpc, rtrv-scr-isup, rtrv-scr-opc, rtrv-scr-tt

The **nsr** parameter cannot be specified if **nsfi=stop** or **nsfi=fail**.

Recovery

Re-enter the command specifying the **nsfi=stop** or **nsfi=fail**, and without specifying the **nsr** parameter.

E2555 Cmd Rej: Point code does not exist in given SR

Commands Used: chg-scr-blkdpc, chg-scr-blkopc, chg-scr-destfld, chg-scr-dpc,
chg-scr-opc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-destfld, dlt-scr-dpc,
dlt-scr-opc

The point code defined by the **ni**, **nc**, and **ncm** parameters is not defined in the specified screening reference (NPC, the ITU-N standard, or zone area ID, the ITU-I standard). The point code must be in the given screening reference.

Refer to the command in the *Commands Manual* for information on the correct values.

Recovery

1. Verify the point codes for the given screening reference.

Enter one of the following commands with the given screening reference:

- a) `rtrv-scr-blkdpc`, for the `chg-scr-blkdpc` and `dlt-scr-blkdpc` commands
- b) `rtrv-scr-blkopc`, for the `chg-scr-blkopc` and `dlt-scr-blkopc` commands
- c) `rtrv-scr-dpc`, for the `chg-scr-dpc` and `dlt-scr-dpc` commands
- d) `rtrv-scr-opc`, for the `chg-scr-opc` and `dlt-scr-opc` commands

2. Re-enter the command specifying one of the point codes shown in Step 1.

E2556 Cmd Rej: A complete point code must be entered

Commands Used: ent-scr-aftpc, chg-scr-aftpc, dlt-scr-aftpc, ent-scr-blkdpc,
chg-scr-blkdpc, dlt-scr-blkdpc, ent-scr-blkopc, chg-scr-blkopc,
dlt-scr-blkopc, ent-scr-cdpa, chg-scr-cdpa, dlt-scr-cdpa, ent-scr-cgpa,
chg-scr-cgpa, dlt-scr-cgpa, ent-scr-dpc, chg-scr-dpc, dlt-scr-dpc,
ent-scr-opc, chg-scr-opc, dlt-scr-opc, ent-scr-destfld, chg-scr-destfld,
dlt-scr-destfld

The command was entered without all the necessary parameters needed to define a point code. These commands require that a point code be entered, and that the point code must be defined by all the necessary parameters for a point code of a particular network type.

A complete point code must be entered using one and only one of the four point code forms represented as **ni-nc-ncm**, **zone-area-id**, **msa-ssa-sp**, or **npc**. The only exception is the special case of entering **c** for "Continue" in the commands that allow it.

Recovery

Re-enter the command specifying a point code containing the following parameters:

ANSI point codes – **ni**, **nc**, **ncm**

ITU-I point codes – **zone**, **area**, **id**

ITU-N point codes – **npc**

24-bit ITU-N point codes – **msa**, **ssa**, **sp**

E2557 Cmd Rej: GWS/GTT shared table is full

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-dpc`, `ent-scr-opc`, `ent-scr-aftpc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scrset`, `ent-tt`

When you attempted to add a gateway screening screen set, a gateway screening reference name, or a global title translation type to the database, the system determined that the table shared by the gateway screening and global title translation features is full and the database could not be updated.

Either a gateway screening screen set and all of its rules, or a global title translation type (and all global title translation data referencing that translation type) must be deleted from the database.

Recovery - For a Gateway Screening Screen Set

1. Display the gateway screening screen sets in the database. Enter the `rtrv-scrset` command. Select a screen set to delete from the database.
2. Enter these commands to verify the gateway screening entities that reference the gateway screening screen set selected in Step 1.

- `rtrv-scr-aftpc`
- `rtrv-scr-blkdpc`
- `rtrv-scr-blkopc`
- `rtrv-scr-cdpa`
- `rtrv-scr-cgpa`
- `rtrv-scr-dpc`
- `rtrv-scr-destfld`
- `rtrv-scr-opc`
- `rtrv-scr-tt`
- `rtrv-scr-sio`

3. Delete any entries in the gateway screening entities displayed in Step 2 that reference the screen set name selected in Step 1. This includes the screen set itself.

For additional information, refer to the procedures in the *Database Administration Manual - Gateway Screening*.

4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - For a Global Title Translation Type

1. Display the global title translation types in the database.
Enter the `rtrv-tt` command. Select a translation type to delete from the database.
2. Enter the `rtrv-gtt:type=` command, specifying the translation type selected in Step 1, to verify the global title translation data referencing the translation type selected in Step 1.
3. Delete the global title translation data displayed in Step 2.
Enter the `dlt-gtt` command.
4. If the selected translation type has any alias translation types assigned to it, delete them.
Enter the `dlt-tt:type= :alias=` command.
5. Delete the translation type.
Enter the `dlt-tt:type=` command.
6. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2558 Cmd Rej: Point code already exists in given SR

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`

The point code specified already exists in the SR (screening reference). You cannot add a point code to an SR if it is already there. If asterisks or ranges are specified for the point code, nothing that matches the specified range or point codes can already exist in the screening table for the screening reference.

If the SR already exists, the blocked OPC cannot be defined as specified or exist within an existing range of OPCs. The blocked OPC that was intended to be added to the BLKOPC screening table for the blocked OPC SR was specified by one of these parameter sets: **ni-nc-ncm**, **zone-area-id**, **msa-ssa-sp**, or **npc**.

Recovery

1. Enter one of the following commands to verify the point codes in the screening reference:
 - a) `rtrv-scr-blkdpc`, for the `ent-scr-blkdpc` command
 - b) `rtrv-scr-blkopc`, for the `ent-scr-blkopc` command
 - c) `rtrv-scr-dpc`, for the `ent-scr-dpc` command
 - d) `rtrv-scr-opc`, for the `ent-scr-opc` command
2. Re-enter the command specifying a different point code for the screening reference.

E2559 Cmd Rej: PC/SSN does not exist in given SR

Commands Used: `chg-scr-aftpc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `dlt-scr-aftpc`,
`dlt-scr-cdpa`, `dlt-scr-cgpa`

The point code/subsystem number combination (**ni**, **nc**, **ncm**, **ssn**) to be changed does not exist in the screening reference (SR) specified in the command. The point code/subsystem number combination must be in the given screening reference.

OR

The AFTPC or AFTPC range defined by the one of the four point code types represented (**ni-nc-ncm**, **zone-area-id**, **msa-ssa-sp**, or **npc**) must already exist in the screening reference before you can perform this command.

Recovery

1. Verify the point code/subsystem number combinations for the given screening reference.
Enter one of the following commands with the given screening reference:
 - a) `rtrv-scr-aftpc`, for the `chg-scr-aftpc` and `dlt-scr-aftpc` commands
 - b) `rtrv-scr-cdpa`, for the `chg-scr-cdpa` and `dlt-scr-cdpa` commands
 - c) `rtrv-scr-cgpa`, for the `chg-scr-cgpa` and `dlt-scr-cgpa` commands
2. Re-enter the command specifying the appropriate values for the new point code/subsystem number combination shown in Step 1.

E2560 Cmd Rej: Inhibit rejected, target terminal is not equipped

Commands Used: `alw-trm`, `inh-trm`, `rmv-trm`, `rst-trm`

You have attempted to inhibit a terminal number in the allowable range of numbers, but it has not been equipped. This command cannot be completed.

Recovery

1. Display all the terminals.
Enter the `rtrv-trm` command.
2. With the output from Step 1 as a guide, re-enter the command for an equipped terminal, or equip the terminal for use.

E2561 Cmd Rej: PC/SSN already exists in given SR

Commands Used: `chg-scr-aftpc`, `chg-scr-cgpa`, `ent-scr-cdpa`, `ent-scr-cgpa`,
`ent-scr-aftpc`

The specified point code or subsystem (**ni, nc, ncm, msa, ssa, sp, ssn**) is already in the given screening reference. The point code and subsystem number cannot be added if it is already in the screening reference.

Recovery

1. Verify the point code/subsystem number combinations.
Enter the appropriate retrieve command, such as `rtrv-scr-cdpa` command.
2. Re-enter the command specifying the appropriate values for the point code / subsystem number combination, making sure that the values are not in the given screening reference.

E2564 Cmd Rej: Point code out of range

Commands Used: `chg-scr-aftpc, chg-scr-cdpa, chg-scr-cgpa, chg-sid, chg-scr-blkdpc, chg-scr-blkopc, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, dlt-scr-aftpc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-cdpa, dlt-scr-cgpa, dlt-scr-destfld, dlt-scr-dpc, dlt-scr-opc, ent-dstn, ent-ls, ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-opc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc`

The specified point code was not entered with the correct values. The following point codes are **not** allowed:

- ANSI point code value **000-000-000**
- ITU-International point code value **0-000-0**

Refer to the command in the *Commands Manual* for additional information about correct point code values.

Recovery

Re-enter the command specifying the correct point code value.

E2565 Cmd Rej: Gateway screening rules table is full

Commands Used: `ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-isup, ent-scr-opc, ent-scr-sio`

The attempt was made to add a gateway screening entry, but the Gateway Screening Rules table is full. The Gateway Screening Rules table can contain only 362,700 rules. To add another gateway screening entry, an existing gateway screening entry has to be deleted or changed.

Recovery

1. Display the entries in the Gateway Screening table.

Enter one of the following commands: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scr-isup`, `rtrv-scr-sio`, or `rtrv-scr-destfld`.

2. If you wish to delete a current entry in the specified screening entity, enter one of the following commands: `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-dpc`, `dlt-scr-isup`, `dlt-scr-opc`, `dlt-scr-sio`, or `dlt-scr-destfld`.
3. Re-enter the command that generated this error message.
4. If you want to change a current entry in the specified screening entity, enter one of the following commands, with the screening information that you attempted to add within the command that generated this error message.
 - a) `chg-scr-aftpc`, for the `ent-scr-aftpc` command
 - b) `chg-scr-blkdpc`, for the `ent-scr-blkdpc` commands
 - c) `chg-scr-blkopc`, for the `ent-scr-blkopc` command
 - d) `chg-scr-cdpa`, for the `ent-scr-cdpa` command
 - e) `chg-scr-cgpa`, for the `ent-scr-cgpa` command
 - f) `chg-scr-dpc`, for the `ent-scr-dpc` command
 - g) `chg-scr-isup`, for the `ent-scr-isup` command
 - h) `chg-scr-opc`, for the `ent-scr-opc` command
 - i) `chg-scr-destfld`, for the `ent-scr-destfld` command
 - j) `chg-scr-sio`, for the `ent-scr-sio` command

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2567 Cmd Rej: Screen set name already exists

Commands Used: `ent-scrset`

The screen set was not entered because the specified screen set name already exists. The specified screen set name must be unique and cannot be in use by another screen set.

Recovery

1. Display the screen set data.
Enter the `rtrv-scrset` command specifying no parameters.
2. Re-enter the `ent-scrset` command specifying a screen set name that does not match any of the screen set names displayed in Step 1.

E2568 Cmd Rej: Screen set name is referenced by a link set

Commands Used: `dlt-scrset`

A screen set that is assigned to a linkset cannot be deleted. Before a screen set can be removed, it must be removed from all linksets.

Recovery

1. Delete the screen set association from the linkset. Enter the `chg-ls` command.
2. Delete the screen set. Re-enter the `dlt-scrset` command.

E2569 Cmd Rej: SIO does not exist in given SR

Commands Used: `chg-scr-sio`, `dlt-scr-sio`

The entry specified by the **nic**, **si**, **h0**, and **h1** parameters could not be found.

Recovery

1. Display the allowed SIO information for the specified screening reference.
Enter the `rtrv-scr-sio` command.
2. Re-enter the command specifying the appropriate **nic**, **si**, **h0**, and **h1** parameter information from Step 1.

E2570 Cmd Rej: NIC, SI, and H0/H1 entry already exists in given SR

Commands Used: `ent-scr-sio`

The **nic**, **si**, **h0**, and **h1** parameters specified already exist in the screening reference.

Recovery

1. Display the allowed SIO information for the specified screening reference.
Enter the `rtrv-scr-sio` command.
2. Re-enter the `ent-scr-sio` command specifying values for the **nic**, **si**, **h0**, and **h1** parameters that do not match those displayed in Step 1.

E2571 Cmd Rej: SI does not exist for given SR

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `rtrv-scr-sio`

The specified service indicator (**si**) and screening reference (**sr**) combination could not be found in the database. These commands require that the specified screening reference and service indicator combination must be in the database.

Recovery

1. Display the allowed SIO screening references and the associated service indicators in the database.
Enter the `rtrv-scr-sio` command. The screening references are shown in the *SR* field of the `rtrv-scr-sio` command output. The service indicators are shown in the *SI* field of the `rtrv-scr-sio` command output.

2. Re-enter the command specifying a screening reference and service indicator combination shown in the `rtrv-scr-sio` command output in Step 1.

E2572 Cmd Rej: NIC and SI must be specified for given H0 and H1

Commands Used: `rtrv-scr-sio`

The command was entered with the heading codes (**h0** and **h1**) parameters specified, but the service indicator (**si**) and network indicator code (**nic**) parameters were not specified. The **h0** and **h1** parameters cannot be specified if the **nic** and **si** parameters are not specified.

Recovery

1. Display all the network indicator codes (**nic**), service indicators (**si**), and heading codes (**h0** and **h1**) parameters in the database.
Enter the `rtrv-scr-sio` command specifying no parameters.
2. If you wish to view a particular heading code entry, enter the `rtrv-scr-sio` command specifying the values for the **nic**, **si**, **h0**, and **h1** parameters shown in the output of Step 1.

E2573 Cmd Rej: SR or NSR does not reference an existing SR

Commands Used: `chg-scr-aftpc`, `chg-scr-destfld`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `chg-scr-sio`, `chg-scr-tt`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-isup`, `dlt-scr-sio`, `dlt-scr-tt`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-isup`, `rtrv-scr-opc`, `rtrv-scr-sio`

The screening reference specified by the **sr** or **nsr** parameter does not exist.

Recovery

1. Verify the screening references in the entity set.
Enter one of the following commands:
 - a) `rtrv-scr-aftpc`, for the `chg-scr-aftpc` command
 - b) `rtrv-scr-blkdpc`, for the `chg-scr-blkdpc` command
 - c) `rtrv-scr-blkopc`, for the `chg-scr-blkopc` command
 - d) `rtrv-scr-cdpa`, for the `chg-scr-cdpa` and `dlt-scr-cdpa` commands
 - e) `rtrv-scr-cgpa`, for the `chg-scr-cgpa` and `dlt-scr-cgpa` commands
 - f) `rtrv-scr-destfld`, for the `chg-scr-destfld` command
 - g) `rtrv-scr-dpc`, for the `chg-scr-dpc` command
 - h) `rtrv-scr-isup`, for the `chg-scr-isup` and `dlt-scr-isup` commands
 - i) `rtrv-scr-opc`, for the `chg-scr-opc` command
 - j) `rtrv-scr-sio`, for the `chg-scr-sio` and `dlt-scr-sio` commands
 - k) `rtrv-scr-tt`, for the `chg-scr-tt` and `dlt-scr-tt` commands

2. Re-enter the command specifying the screening reference from the output in Step 1.

E2574 Cmd Rej: TYPE does not exist in given SR

Commands Used: `chg-scr-tt`, `dlt-scr-tt`

The specified translation type could not be found.

Recovery

1. View the translation types in the screening reference.
Enter the `rtrv-scr-tt` command.
2. Re-enter the command specifying one of the translation types from the output of Step 1.

E2575 Cmd Rej: TYPE matches existing TYPE in given SR

Commands Used: `chg-scr-tt`

The new type matches a type already in the screening reference.

Recovery

1. Display the data for this screening reference.
Enter the `rtrv-scr-tt` command.
2. Re-enter the `chg-scr-tt` command specifying a new value for the new translation type, that did not appear in the `rtrv` command executed in Step 1.

E2577 Cmd Rej: A specific SSN must be specified in the range (1-255,*)

Commands Used: `chg-scr-aftpc`, `dlt-scr-aftpc`, `dlt-scr-cgpa`

You either failed to include the `ssn` parameter on the command line, or assigned a value to it that was out of range.

Recovery

Re-enter the command that generated this error message specifying the correct `ssn` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2579 Cmd Rej: GWS must be ON if LAN is ON

Commands Used: `chg-feat`

You specified the **lan=on** parameter to turn the STP LAN feature on, and the Gateway Screening feature is off. To use the STP LAN feature, the Gateway Screening feature must be turned on.

Recovery

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Turn on the STP LAN and Gateway Screening features. Enter the command:

```
chg-feat:gws=on:lan=on
```

Refer to the *Database Administration Manual – Features and the Database Administration Manual – Gateway Screening* for details.

E2580 Cmd Rej: A specific NIC must be specified in the range (0-3)

Commands Used: `dlt-scr-sio`

You either failed to include the **nic** parameter on the command line, or assigned a value to it that was out of range.

Recovery

Re-enter the `dlt-scr-sio` command that generated this error message specifying the correct **nic** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2581 Cmd Rej: CRMD feature must be ON

Commands Used: `chg-dstn`, `ent-dstn`, `chg-feat`

The parameters specified require the Cluster Routing and Management Diversity (CRMD) feature turned on.

Table 10: Conditions that Generate Error Message E2581

Command(s)	Condition
<code>chg-dstn ent-dstn</code>	The CRMD feature must be turned on before a cluster destination point code can be entered or changed.
<code>chg-feat</code>	The CRMD feature must be turned on before the Nested Cluster Routing (NCR) feature can be turned on.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the CRMD feature is turned on, re-enter the command.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the CRMD feature is turned off, turn it on. Enter the command: `chg-feat : crmd=on`
4. Re-enter the command that generated this error message.

E2583 Cmd Rej: LAN feature must be ON

Commands Used: `chg-ss7opts`, `ent-card`

For the `chg-ss7opts` command, the STP LAN feature must be turned on (see the `chg-feat` command) before the `slanporgopc` or `slanlsn` parameter can be specified.

For the `ent-card` command, the LAN feature must be turned on to specify the `appl=stplan/vxwslan` parameters.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the LAN or STP LAN feature is turned on, re-enter the command.
3. If the LAN or STP LAN feature is turned off, turn it on. Refer to the *Commands Manual* for more information.
4. Re-enter the command that generated this error message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2584 Cmd Rej: GTT feature must be ON

Commands Used: `chg-ctrl-feat`, `chg-feat`, `chg-loopset`, `dlt-loopset`,
`chg-sccpopts`, `enable-ctrl-feat`, `ent-card`, `ent-loopset`, `rtrv-loopset`

The GTT feature must be turned on before a specific feature can be enabled or card type entered. Features that require the GTT feature to be ON before they can be enabled are listed in the *Commands Manual*.

Recovery

1. Display the status of the GTT feature. Enter the `rtrv-feat` command.
2. Turn on the GTT feature if necessary. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Enable or turn on the desired feature. Refer to the appropriate Feature Manual for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2585 Cmd Rej: GWS feature must be ON

Commands Used: `enable-ctrl-feat`, `ent-card`, `ent-dlk`

The GWS (Gateway Screening) feature must be turned on prior to issuing this command. Specifically:

- For the `enable-ctrl-feat` command, the GWS feature must be turned on before the feature can be enabled.
- For the `ent-card` command, the GWS feature must be turned on before a GLS card can be added to the database (**appl=gl**s).
- For the `ent-dlk` command, the GWS feature and the STPLAN feature must be turned on before the `ent-dlk` command can be entered.

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the GWS feature is turned on, re-enter the command that generated this error message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the GWS feature is turned off (GWS=off), turn on the GWS feature. Enter the command:
`chg-feat:gws=on`
4. If the STPLAN feature is turned off (LAN=off), turn on the STPLAN feature. Enter the command:
`chg-feat:lan=on`
5. Re-enter the command that generated this error message.

E2587 Cmd Rej: Card GPL of link does not match domain of linkset APC

Commands Used: `ent-slk`

The domain of the linkset specified by the `lsn` parameter must match the domain of the link specified by the `link` parameter.

Recovery

1. Verify the card applications of the cards in the system.
Enter the `rtrv-card` command.
2. Display the destination point codes and to verify the domain (SS7) of each destination point code.
Enter the `rtrv-dstn` command. The adjacent point code of the linkset must be in the Destination Point Code table.
3. Using the outputs of Steps 1 and 2 as a guide, re-enter the `ent-slk` command, making sure the card application of the specified signaling link matches the domain of the adjacent point code of the linkset containing the signaling link.

E2591 Cmd Rej: BEI must be YES if APC domain is X.25

Commands Used: `chg-ls`, `ent-ls`

You cannot specify the **bei=no** parameter if the domain of the adjacent point code (APC) of the linkset is in the X.25 domain. If the adjacent point code is in the X.25 domain, the **bei=yes** parameter must be specified, or the **bei** parameter must be omitted from the command.

Recovery

1. Display the point codes in the destination point code table.
Enter the `rtrv-dstn` command. The domain of the point codes is shown in the *DOMAIN* field of the output.
2. Display the linksets in the database.
Enter the `rtrv-ls` command.
3. If you are adding a new linkset (`ent-ls` command), and the selected point code is in the SS7 domain, enter either the **bei=yes** or **bei=no** parameter, or do not enter the **bei** parameter.
The default value for the **bei** parameter is **no**. If the selected point code is in the X.25 domain, enter the **bei=yes** parameter (default is **yes** in the X.25 domain).
4. If you are changing an existing linkset (`chg-ls` command), find the point code of the linkset to be changed in the output of Step 1 to determine the domain of the point code.
If the domain of the point code is **x25**, and the **bei= no** (shown in the *BEI* field in the output of Step 2), enter the **bei=yes** parameter. If the domain of the point code is **SS7**, enter either the **bei=yes** or **bei=no** parameter, or do not enter the **bei** parameter. If the **bei** parameter is not specified, the **bei** value does not change.

E2592 Cmd Rej: Warm Restart capable Feature must be enabled

Commands Used: `alw-card`, `init-card`, `init-sys`

The G-Flex, G-Port, INP, LNP, or V-Flex feature must be turned on, or the ATINP feature must be enabled before the **data** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command and the `rtrv-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2593 Cmd Rej: APC cannot be of a different domain than previous

Commands Used: `chg-ls`

The specified APC was not in the same domain as the previous APC assigned to the linkset. For example, the previous APC was an SS7 APC and the new APC was an X.25 APC. The `chg-ls` command does not allow this.

Recovery

1. Verify all point codes and the domains that they are assigned to.
Enter the `rtrv-dstn` command. The domain of each point code is shown in the *DOMAIN* field in the output.
2. Re-enter the `chg-ls` command, with a point code whose domain matches the domain of the previous APC.
If the domain of the previous APC is `ss7`, select a point code whose domain is `ss7`. If the domain of the previous APC is `x25`, select a point code whose domain is `x25`.

E2594 Cmd Rej: X.25 Destination assigned to non-X.25 linkset

Commands Used: `ent-rte`

If a route is assigned a destination that is marked for the X.25 domain, that destination must be assigned to at least one X.25 destination and the linkset assigned to that route must have an adjacent point code assigned to the X.25 domain. The specified DPC is assigned to the X.25 domain (an X.25 DPC), and the specified linkset (*lsn*) is assigned to an adjacent point code (APC) that is assigned to the SS7 domain (an SS7 linkset). An X.25 DPC must be assigned to an X.25 linkset, and an SS7 DPC must be assigned to an SS7 linkset.

Recovery

1. Display the destination point codes in the database.
Enter the `rtrv-dstn` command.
2. Display the linksets in the database.
Enter the `rtrv-ls` command.
3. Using the outputs from Steps 1 and 2 as a guide, re-enter the `ent-rte` command specifying an X.25 DPC and an X.25 linkset.

E2595 Cmd Rej: SS7 Destination assigned to non-SS7 linkset

Commands Used: `ent-rte`

If the route is assigned a destination that is marked for the SS7 domain, the linkset assigned to that route must have an Adjacent point code assigned to the SS7 domain. The specified DPC is assigned

to the SS7 domain (an SS7 DPC), and the specified linkset (**lsn**) is assigned to an adjacent point code (APC) that is assigned to the X.25 domain (an X.25 linkset). An SS7 DPC must be assigned to an SS7 linkset, and an X.25 DPC must be assigned to an X.25 linkset.

Recovery

1. Display the destination point codes in the database.
Enter the `rtrv-dstn` command.
2. Display the linksets in the database.
Enter the `rtrv-ls` command.
3. Using the outputs from Steps 1 and 2 as a guide, re-enter the `ent-rte` command specifying an SS7 DPC and an SS7 linkset.

E2596 Cmd Rej: DPC must be removed from X.25 route tbl

Commands Used: `dlt-dstn`

The specified destination point code (DPC) is referenced by an X.25 destination. A DPC cannot be deleted from the database if it is referenced by an X.25 destination.

Recovery

1. Display the X.25 destinations in the database.
Enter the `rtrv-x25-dstn` command specifying the DPC that generated this error message.
2. Display any X.25 routes associated with the X.25 destination shown in Step 1, using the `rtrv-x25-rte` command, specifying the X.25 address shown in the *X25 ADDR* field in Step 1.
3. If the output of Step 2 shows any X.25 routes associated with the X.25 address shown in Step 1, delete those X.25 routes from the database using the `dlt-x25-rte` command, specifying the X.25 addresses shown in the *X25 ADDR* and *SS7 ADDR* fields in the output of Step 2.
4. Delete the X.25 destinations associated with the DPC from the database, shown in the *X25 ADDR* field in the output of Step 1, using the `dlt-x25-dstn` command.
5. Re-enter the `dlt-dstn` command that generated this error message.

E2597 Cmd Rej: Cccmmd table must be accessible

Commands Used: `chg-cmd`, `rtrv-cmd`

The `ccmmd` table was not accessible to the command you entered.

Recovery

Re-enter carefully the command that generated this error message specifying correct parameter values.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2598 Cmd Rej: Cccnames table must be accessible

Commands Used: `chg-cmd`, `chg-cmdclass`, `chg-secu-trm`, `chg-user`, `ent-user`,
`rtrv-cmd`, `rtrv-cmdclass`, `rtrv-secu-trm`, `rtrv-secu-user`, `rtrv-user`

The Cccnames table was not accessible to the command you entered.

Recovery

Re-enter carefully the command that generated this error message specifying correct parameter values. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2599 Cmd Rej: Failed reading the extended link table

Commands Used: `chg-x25-slk`, `dlt-ip-node`, `ent-dlk`, `ent-ip-node`, `ent-slk`,
`rtrv-dlk`, `rtrv-x25-slk`, `rtrv-ls`

The Extended Link table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2600 Cmd Rej: Linkset SAPC referenced by route

Commands Used: `chg-ls`

You have been prevented from deleting an **sapc** (Secondary Adjacent Point Code) linkset because it is currently referenced by a route. The command cannot delete an **sapc** when a route exists for a linkset in the SAPC's domain or group code.

Recovery

1. If you did not intend to delete this route, enter the correct linkset name.
2. If you did intend to delete this route:
 - a) Delete the route reference with the `dlt-rte` command specifying the linkset name from the command that generated this error message.
 - b) Re-enter the `chg-ls` command that generated this error message.

E2601 Cmd Rej: Command aborted due to system error

Commands Used: `chg-gtttsel`, `chg-ls`, `chg-ss-appl`, `dlt-dlk`, `dlt-gtttsel`, `dlt-ip-node`, `dlt-ss-appl`, `ent-dlk`, `ent-gtttsel`, `ent-ss-appl`, `rtrv-ss-appl`, `rtrv-ls`

A severe system fault has occurred and the command was rejected.

For the `gttsel` commands, a database error occurred while trying to access the `SSNSELID` table.

Recovery

1. Re-enter the command that generated this error message.
2. If this error message appears again, reinitialize the active MASP.
Enter the `init-card` command, specifying the location of the active OAM.
3. Re-enter the command that generated this error message.
4. If this error message appears again, determine the status of the database.
Enter the `rept-stat-db` command, to identify which OAM is active.
5. If the database is incoherent, find the conditions shown in the output of Step 4 in the following list, and execute the appropriate command.
 - a) If the current partition of the fixed disk is coherent and the backup partition of the fixed disk is incoherent, enter the `chg-db:action=backup:dest=fixed` command.
 - b) If the current partition of the fixed disk is coherent and the database on the removable cartridge is incoherent, use the `chg-db:action=backup:dest=remove` command.
 - c) If the backup partition of the fixed disk is coherent and the current partition of the fixed disk is incoherent, use the `chg-db:action=restore:src=fixed` command.
 - d) If the database on the removable cartridge is coherent and the current partition of the fixed disk is incoherent, enter the `chg-db:action=restore:src=remove` command.
 - e) If the backup and current partitions on the active TDM are coherent and the backup and current partitions on the standby TDM are not coherent, use the `chg-db:action=repair` command.
6. Log into the EAGLE 5 ISS.
Enter the `login` or `act-user` command.
7. Verify that the database is coherent.
Re-enter the `rept-stat-db` command.
8. Re-enter the command that generated this error message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2602 Cmd Rej: Card is not a STPLAN card

Commands Used: `act-dlk`, `canc-dlk`, `ent-dlk`, `rtrv-dlk`, `rtrv-ip-node`

The card location must contain a card that is running the **stplan** application.

Recovery

1. Verify the card types in the database.
Enter the `rtrv-card` command.
2. Re-enter the command specifying a card type that is a STPLAN.

E2603 Cmd Rej: Card must be inhibited before executing this command

Commands Used: `chg-bip-fld`, `chg-ip-card`, `chg-ip-lnk`, `dlt-dlk`, `dlt-ip-node`, `ent-dlk`, `ent-ip-node`, `init-flash`, `tst-bip`

The specified card must be in the OOS-MT-DSBLD (out of service - maintenance disabled) state before any TCP/IP data links or IP nodes can be added or deleted.

Note:

This error message does not apply to HMUX ,HIPR, or HIPR2 cards for the `init-flash` command.

Recovery

1. Display the status of the card specified that generated this error message. Enter the `rept-stat-card` command specifying the card location.
The primary state of the card is shown in the *PST* field.
2. If necessary, enter the `rmv-card` command to make the primary state of the card OOS-MT-DSBLD. Refer to the *Commands Manual* and *Maintenance Manual* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2604 Cmd Rej: Card location not assigned a TCP/IP link

Commands Used: `dlt-dlk`, `dlt-ip-node`, `ent-ip-node`, `rtrv-dlk`, `rtrv-ip-node`

The specified card does not contain a TCP/IP data link.

Recovery

1. Display the TCP/IP data links in the database.
Enter the `rtrv-dlk` command specifying no parameters.
2. Re-enter the command specifying a card location (**loc**) shown in Step 1 that contains a TCP/IP data link.

E2605 Cmd Rej: First octet of IPADDR cannot be 127

Commands Used: ent-dlk

You cannot specify 127 for the first octet of an IP address, since 127 represents loopback. You cannot specify a loopback address with this command.

Recovery

Re-enter the ent-dlk command without specifying 127 as the first octet of the IP address.

E2606 Cmd Rej: Point code must exist within the group

Commands Used: chg-mrn

The command was entered to change the relative costs specified for more than one point code. At least one of the point codes specified does not exist in the group in the Mated Relay Node (MRN) table that is indicated by the point code specified in the **pc** parameter. When the relative costs are entered to change them, all point codes specified must exist in the group indicated by the **pc** parameter point code value.

Recovery

1. Display the point codes in each group in the MRN table.
Enter the `rtvr-mrn` command. Verify that you specified the correct point codes in one group in the table.
2. Re-enter the `chg-mrn` command to change the relative costs, with all specified point codes in the same group in the MRN table
3. If you need to change relative costs for point codes in another group, enter another command for the point codes in that group.

E2607 Cmd Rej: IPADDR assigned to a TCP/IP node

Commands Used: ent-dlk

The specified IP address (**ipaddr**) was already assigned to a TCP/IP node. The **ipaddr** cannot be in the TCP/IP Link table and cannot be a TCP/IP node.

Recovery

1. Verify the TCP/IP nodes in the database.
Enter the `rtvr-ip-node` command.
2. Re-enter the ent-dlk command specifying a value for the **ipaddr** parameter that is not shown in the output of Step 1.

E2608 Cmd Rej: IPADDR not assigned to a TCP/IP link

Commands Used: `dlt-ip-node`, `ent-ip-node`

The specified IP address (**ipaddr**) is the IP address for a TCP/IP data link, not a TCP/IP node. The specified IP address must be the IP address of a TCP/IP node instead of a TCP/IP data link.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
2. Re-enter the command specifying an IP address shown in the output of Step 1.

E2609 Cmd Rej: Only one optional parameter may be specified

Commands Used: `dlt-gserv-data`, `ent-gserv-data`, `rept-stat-eroute`, `rept-stat-lnp`, `rept-stat-mon`, `rept-stat-sccp`, `rtrv-dlk`, `rtrv-gserv-data`, `rtrv-ip-node`, `rtrv-ip-rte`

Only one optional parameter at a time can be specified in the command.

The following Recovery procedures list by command the remedial action for this error message.

Recovery - `ent-gserv-data`, `dlt-gserv-data`

Re-enter the `ent-gserv-data` command using a separate command entry for the **tt**, **opc**, and **gta** parameter data.

Recovery - `rept-stat-lnp`

Enter the `rept-stat-lnp` command specifying either: no parameters, the **loc** parameter, or the **card** parameter.

Recovery - `rept-stat-eroute`, `rept-stat-mon`, `rept-stat-sccp`

Note: As of Release 40.1.0, the `rept-stat-eroute` command is obsolete. Use the `rept-stat-mon` command to display the status of the EROUTE subsystem.

Enter the command specifying either no parameters, only the **perf** parameter, or only the **loc** parameter.

Recovery - `rtrv-dlk`

Enter the `rtrv-dlk` command specifying either: no parameters, the **loc** parameter, or the **ipaddr** parameter. The **loc** and **ipaddr** parameters cannot be specified together in the same command.

Recovery - `rtrv-ip-node`

Enter the `rtrv-ip-node` command specifying either no parameters, the **ipaddr** parameter, the **ipaddr** and **ipport** parameters, the **ipappl** parameter, or the **loc** parameter.

Recovery - `rtrv-ip-rte`

Enter the command specifying either no parameters, only the **loc** parameter, only the **dest** parameter, or only the **gtwy** parameter.

Recovery - rtrv-gserv-data

Enter the command specifying only one of the **display**, **tt**, **opc**, or **gta** parameters.

E2610 Cmd Rej: IPADDR assigned to a TCP/IP link

Commands Used: `ent-dlk`, `ent-ip-node`

You assigned an invalid value to the **ipaddr** parameter. The IP address cannot be in the TCP/IP link table and cannot be a TCP/IP node. The specified TCP/IP data link cannot be in the database.

Recovery

1. Display the current IP addresses.
Enter the `rtrv-dlk` command.
2. Re-enter the command that generated this error message specifying the correct **ipaddr** parameter value.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2611 Cmd Rej: Total Ethernet Capacity is greater than 100% for IP Node

Commands Used: `ent-ip-node`

The value you assigned to the **cap** parameter, when added to the values that were assigned when IP addresses were defined, totaled more than **100**.

Recovery

1. Enter the `rtrv-ip-node` command to acquire the present status of the IP node.
2. Re-enter the `ent-ip-node` command that generated this error message, but set the **cap** parameter to not push the total capacity beyond 100%, when added to the existing capacity as seen in Step 1.

E2612 Cmd Rej: IPPORT already assigned

Commands Used: `ent-ip-node`

You tried to assign a different IP application to an IP port (**ippport**) that, in combination with the IP address used that generated this error message, is already in the database. Once a particular IP address and IP port combination is assigned to an IP application, that IP address and IP port combination must always use that IP application.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.

2. Re-enter the `ent-ip-node` command specifying an IP port (**ipport**), IP address (**ipaddr**), and IP application (**ipappl**) combination that is not shown in the output of Step 1.

E2613 Cmd Rej: IPPORT can only be specified if IPADDR is specified

Commands Used: `rtrv-ip-node`

You cannot specify the **ipport** parameter without specifying the **ipaddr** parameter. If you specify the **ipport** parameter, you must also specify the **ipaddr** parameter.

Recovery

Re-enter the `rtrv-ip-node` command specifying both the **ipaddr** and the **ipport** parameters.

E2614 Cmd Rej: IPADDR w/o IPRTE must match first octet of TCP/IP link

Commands Used: `ent-ip-node`

You specified an IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. No **iprte** parameter (IP address of a TCP/IP router) was assigned. The network portion of the IP address assigned to the TCP/IP data link and the IP address of the IP node must be the same. The IP address is a Class A IP address. This is determined by the first field of the IP address. The first field value of a Class A IP address is 1 to 126. The values 0 and 127 are not allowed for IP addresses. For a Class A IP address, the first field is the network portion of the IP address.

Recovery

1. Display the IP addresses of the TCP/IP data links.
Enter the `rtrv-dlk` command.
2. Display the IP addresses of the TCP/IP nodes.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a Class A IP address not shown in the output of Step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of Step 1).

E2615 Cmd Rej: IPADDR w/o IPRTE must match first 2 octets of TCP/IP link

Commands Used: `ent-ip-node`

You specified an IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. No **iprte** parameter (IP address of a TCP/IP router) was assigned. The network portion of the IP address assigned to the TCP/IP data link and the IP address

of the IP node must be the same. The IP address is a Class B IP address. This is determined by the first field of the IP address. The first field value of a Class B IP address is **128** to **191**. For a Class B IP address, the first two fields are the network portion of the IP address.

Recovery

1. Enter `rtrv-dlk` to display the IP addresses of the TCP/IP data links.
2. Display the IP addresses of the TCP/IP nodes.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a Class B IP address not shown in the output of Step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of Step 1).

E2616 Cmd Rej: IPADDR w/o IPRTE must match first 3 octets of TCP/IP link

Commands Used: `ent-ip-node`

You specified an IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. No `iprte` parameter (IP address of a TCP/IP router) was assigned. The network portion of the IP address assigned to the TCP/IP data link and the IP address of the IP node must be the same. The IP address is a Class C IP address. This is determined by the first field of the IP address. The first field value of a Class C IP address is from **192** to **223**. For a Class C IP address, the first three fields are the network portion of the IP address.

Recovery

1. Display the IP addresses of the TCP/IP data links.
Enter the `rtrv-dlk` command.
2. Display the IP addresses of the TCP/IP nodes.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a Class C IP address not shown in the output of Step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of Step 1).

E2617 Cmd Rej: IPAPPL already assigned to specified LOC

Commands Used: `ent-ip-node`

The specified IP application (`ipappl`) was already assigned to the TCP/IP data link specified by the `loc` parameter. Only one IP node (`ipaddr`, `ipappl`, and `loc` parameter combination) can be assigned to a TCP/IP data link.

Recovery

1. Verify the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
2. Verify the TCP/IP data links in the database.
Enter the `rtrv-dlk` command.
3. Re-enter the `ent-ip-node` command specifying values for the IP node (**ipaddr**, **ipappl**, and **loc** parameter combination) that is not shown in the output of Step 1, but with a value for the **loc** parameter shown in the output of Step 2.

E2619 Cmd Rej: Only one of IPAPPL or IPPORT may be specified

Commands Used: `dlt-ip-node`

You specified both the **ipappl** and **ippport** parameters. This combination is not allowed by this command.

Recovery

Re-enter the `dlt-ip-node` command specifying either the **ipappl** or **ippport** parameters, but not both.

E2620 Cmd Rej: No optional parameters may be specified if FORCE=YES

Commands Used: `dlt-ip-node`

You specified either the **ipappl**, **ippport**, or **loc** parameters, and with the **force=yes** parameter. If you specify the **force=yes** parameter, none of the other optional parameters, **ipappl**, **ippport**, or **loc**, can be specified.

Recovery

Re-enter the `dlt-ip-node` command specifying either the **force=yes** parameter or the **ipappl**, **ippport**, or **loc** parameters.

E2621 Cmd Rej: FORCE=YES must be specified to delete entire node

Commands Used: `dlt-ip-node`

The command was entered with only the **ipaddr** parameter. The system interprets this as an attempt to delete all connections from the specified IP node. To delete all connections from an IP node, the **force=yes** parameter must be specified.

Recovery

Re-enter the `dlt-ip-node` command specifying the **force=yes** parameter, or with either the **ipappl**, **ippport**, or **loc** parameters to delete a specific application or port from the IP node.

E2622 Cmd Rej: IPADDR not assigned to specified LOC

Commands Used: `dlt-ip-node`, `rtrv-ip-node`

The command was entered with the **ipaddr** and **loc** parameters, and the node specified by the **ipaddr** parameter could not be found to be connected to the TCP/IP data link specified by the **loc** parameter. For this command to be successful, the **ipaddr** and **loc** parameter combination must be in the database.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
2. Re-enter the command specifying an IP address (**ipaddr**) and its associated card location (**loc**) shown in the output of Step 1.
OR Re-enter the command specifying no parameters.

E2623 Cmd Rej: IPPORT on node not assigned to specified LOC

Commands Used: `dlt-ip-node`

You specified the **ipport** and the **loc** parameters, and the **ipaddr/ipport** combination could not be found for the specified location. If you enter the command specifying the **ipport** and the **loc** parameters, the **ipaddr/ipport** combination must be assigned to the TCP/IP data link specified by the **loc** parameter.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command specifying no parameters.
2. Re-enter the `dlt-ip-node` command specifying an **ipaddr/ipport** combination and the corresponding card location shown in the output from the `rtrv-ip-node` command.

E2624 Cmd Rej: IPAPPL on node not assigned to specified LOC

Commands Used: `dlt-ip-node`

You specified the **ipappl** and the **loc** parameters, and the **ipaddr/ipappl** combination could not be found for the specified location. If you enter the command specifying the **ipappl** and the **loc** parameters, the **ipaddr/ipappl** combination must be assigned to the TCP/IP data link specified by the **loc** parameter.

Recovery

1. Display the TCP/IP nodes in the database.
Enter `rtrv-ip-node` with no parameters.
2. Re-enter the `dlt-ip-node` command specifying an **ipaddr/ipappl** combination and the corresponding card location shown in the output of Step 1.

E2625 Cmd Rej: IPADDR not assigned to any TCP/IP link

Commands Used: `dlt-ip-node`

The node specified by the **ipaddr** parameter could not be found to be connected to any TCP/IP data link. At least one connection to the specified TCP/IP node must exist for this command to be successful.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
2. Re-enter the `dlt-ip-node` command specifying an IP address shown in the output of Step 1.

E2626 Cmd Rej: IPPORT on Node not connected to any TCP/IP link

Commands Used: `dlt-ip-node`

The specified IP port (**ipappl**) could not be found in the database. To specify an IP port with this command, it must be assigned to a TCP/IP node, and that node must be connected to a TCP/IP data link.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
2. Re-enter the `dlt-ip-node` command specifying an IP port (**ipport**) that is shown in the output of Step 1.

E2627 Cmd Rej: IPAPPL on node not connected to any TCP/IP link

Commands Used: `dlt-ip-node`

The specified IP application (**ipappl**) could not be found in the database. To specify an IP application with this command, it must be assigned to a TCP/IP node, and that node must be connected to a TCP/IP data link.

Recovery

1. Display the TCP/IP nodes in the database.
Enter the `rtrv-ip-node` command.
2. Re-enter the `dlt-ip-node` command specifying an IP application (**ipappl**) that is shown in the output of Step 1.

E2628 Cmd Rej: Only one of IPADDR, IPAPPL, IPRTE, or LOC can be specified

Commands Used: `rtrv-ip-node`

You specified a combination of the `ipaddr`, `ipappl`, `iprte`, or `loc` parameters. You can specify only one of these parameters with this command.

Recovery

Re-enter the `rtrv-ip-node` command specifying either the `ipaddr`, `ipappl`, `iprte`, or the `loc` parameters, but not a combination of these parameters.

E2629 Cmd Rej: Card has IP LNK with IP address assigned

Commands Used: `dlt-card`

The specified card location has an IP link assigned to it. The card cannot be deleted from the database until the IP link is deleted from the database.

Recovery

1. Display the IP links in the database.
Enter the `rtrv-ip-lnk` command.
2. Display the IP hosts in the database.
Enter the `rtrv-ip-host` command.
3. From the outputs of Steps 1 and 2, determine if the card location specified in the command that generated this error message, has an IP link assigned to it.
4. Delete the IPHOST from the database.
Enter the `dlt-ip-host` command specifying the card location used in Step 3.

Note:

An IPLNK entry must be provisioned before an IPHOST entry with **type=local** can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

5. Delete the IP link from the database.
Enter the `chg-ip-lnk` command specifying the card location used in Step 3.
6. Delete the card from the database.
Re-enter the `dlt-card` command that generated this error message.

E2630 Cmd Rej: IPADDR and IPRTE cannot be the same address

Commands Used: `ent-ip-node`

You entered this command specifying the same address for **ipaddr** (the node's IP address) and **iprte** (the default router's IP address). These addresses cannot be the same.

Recovery

1. Verify the values for **ipaddr** and **iprte**.
Enter the `rtrv-ip-node` command.
2. Re-enter the `ent-ip-node` command specifying different addresses for the **ipaddr** and **iprte** parameters.

E2631 Cmd Rej: Link must be cancelled before executing this command

Commands Used: `dlt-dlk`, `inh-card`

The following Recovery procedures list by command the remedial action to take for this error message.

Recovery - `dlt-dlk`

The specified TCP/IP data link was not OOS-MT-DSBLD (out of service - maintenance disabled). To delete a TCP/IP data link from the database, that link must be in an OOS-MT-DSBLD state.

1. To display the status of the TCP/IP data link, use the `rept-stat-dlk` command, specifying the card location.
The primary state (*PST*) field shows the link state.
2. If the primary state displayed in Step 1 is not OOS-MT-DSBLD, enter the `canc-dlk` command to make the primary state of the link OOS-MT-DSBLD.
3. Re-enter the command that generated this error message.
4. If the primary state of the TCP/IP data link displayed in Step 1 is OOS-MT-DSBLD, re-enter the `dlt-dlk` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery `inh-card`

You tried to inhibit a card that has signaling or data links that are in service. Before you can inhibit the card, you must put the links in the OOS-MT-DSBLD (out of service - maintenance disabled) state.

1. To display the status of the signaling link, enter the `rept-stat-slk` command, specifying the card location.
For a data link, use the `rept-stat-dlk` command. The primary state of the link is shown in the *PST* field.
2. If the primary state of the link displayed in Step 1 is not OOS-MT-DSBLD, enter the `inh-slk` command to make the primary state of the link OOS-MT-DSBLD.

Inhibit all signaling links that provide timeslots serviced by E1 interfaces on an E1 card (card type **lime1**) or by T1 interfaces on an E1/T1 MIM used as a T1 card (card type **limt1**). For a data link, use the `cancel-dlk` command. Re-enter the `inh-card` command that generated this error message.

3. If the primary state of the link displayed in Step 1 is OOS-MT-DSBLD, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2632 Cmd Rej: IPRTE address assigned to TCP/IP Link

Commands Used: `ent-ip-node`

The specified router IP address (**iprte**) was already assigned to a TCP/IP link.

Recovery

1. Verify the TCP/IP data links in the database.
Enter the `rtrv-dlk` command.
2. Verify the TCP/IP router addresses in the database.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a router IP address that is different from the address assigned to the TCP/IP link.

E2633 Cmd Rej: IPRTE address must use first octet of Class A TCP/IP Link

Commands Used: `ent-ip-node`

You specified a router IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. The IP address assigned to the TCP/IP router is a Class A IP address. For a Class A IP address, the first field is the network portion of the IP address. The first field value of a Class A IP address is from 1 to 126. The values 0 and 127 are not allowed for IP addresses.

Recovery

1. Display the IP addresses of the TCP/IP data links.
Enter the `rtrv-dlk` command.
2. Display the IP addresses of the TCP/IP routers.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a Class A router IP address not shown in the output of Step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of Step 1).

E2634 Cmd Rej: IPRTE address must use first 2 octets of Class B TCP/IP Link

Commands Used: `ent-ip-node`

You specified a router IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. The IP address assigned to the TCP/IP router is a Class B IP address. For a Class B IP address, the first two fields are the network portion of the IP address. The first field value of a Class B IP address is from **128** to **191**.

Recovery

1. Display the IP addresses of the TCP/IP data links.
Enter the `rtrv-dlk` command.
2. Display the IP addresses of the TCP/IP routers.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a Class B router IP address not shown in the output of Step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of Step 1).

E2635 Cmd Rej: IPRTE address must use first 3 octets of Class C TCP/IP Link

Commands Used: `ent-ip-node`

You specified a router IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. The IP address assigned to the TCP/IP router is a Class C IP address. For a Class C IP address, the first three fields are the network portion of the IP address. The first field value of a Class B IP address is **192** to **223**.

Recovery

1. Display the IP addresses of the TCP/IP data links.
Enter the `rtrv-dlk` command.
2. Display the IP addresses of the TCP/IP routers.
Enter the `rtrv-ip-node` command.
3. Re-enter the `ent-ip-node` command specifying a Class C router IP address not shown in the output of Step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of Step 1).

E2636 Cmd Rej: IPADDR assigned to a TCP/IP router

Commands Used: ent-dlk

The specified IP address (**ipaddr**) was already assigned to a TCP/IP router. The IP Address must not already be assigned to an existing TCP/IP Default Router.

Recovery

1. Verify the TCP/IP router addresses in the database.
Enter the `rtrv-ip-node` command.
2. Re-enter the `ent-dlk` command, with a value for the **ipaddr** parameter that is not shown in the output of Step 1.

E2638 Cmd Rej: IPADDR already assigned to another TCP/IP link

Commands Used: ent-dlk

The specified IP address (**ipaddr**) is already assigned to a TCP/IP data link. The IP Address must not already be assigned to an existing TCP/IP data link.

Recovery

1. Display the TCP/IP data links in the database.
Enter the `rtrv-dlk` command.
2. Re-enter the `ent-dlk` command specifying a value for the **ipaddr** parameter that is not shown in the output of Step 1.

E2639 Cmd Rej: Failed reading redirect table

Commands Used: `chg-gws-redirect`, `chg-sid`, `dlt-rte`, `dlt-gws-redirect`,
`ent-gws-redirect`

The Gateway Screening Redirect Function table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2640 Cmd Rej: Redirect function data has already been entered

Commands Used: `ent-gws-redirect`

The command was entered, but the gateway screening redirect function data has already been entered. Once specific gateway screening redirect function data is entered, the same `ent-gws-redirect` command cannot be entered again.

Recovery

If you wish to change the data for the gateway screening redirect function, either

- Enter the `chg-gws-redirect` command specifying the new information.
OR
- Delete the current gateway screening redirect function information with the `dlt-gws-redirect` command, and re-enter the `ent-gws-redirect` command that generated this error message
OR
- No action is necessary.

E2641 Cmd Rej: Redirect function data has not been entered

Commands Used: `chg-gws-redirect`, `dlt-gws-redirect`

The command was entered, but no gateway screening redirect function data has been changed or deleted. These commands can be entered only if the gateway screening redirect function data has been previously entered with the `ent-gws-redirect` command.

Recovery

No action is necessary.

E2642 Cmd Rej: DPC must have at least one route defined

Commands Used: `chg-gws-redirect`, `ent-gws-redirect`

The command was entered with a value for the destination point code (DPC) parameter that has no route assigned to it. These commands require that the DPC have at least one route assigned to it.

Recovery

1. Display the routes in the database.
Enter the `rtrv-rte` command. The point codes that have routes assigned to them are shown in the *DPCA* field. Only ANSI point codes can be used with the gateway screening redirect function.
2. Re-enter the command that generated this error message, with a point code shown in the *DPCA* field in the output of Step 1.

E2643 Cmd Rej: Cannot delete last route to DPC ref. in MAP table

Commands Used: `dlt-rte`, `chg-dstn`

The last route for the specified DPC being removed cannot be referenced by a mated application or a concerned signaling point code. If this route is removed, and any of these references exist, then those references will not be valid.

Recovery

1. Display information about this route and the DPC it points to. Enter the `rept-stat-rte` command.
2. Display the references that point to this DPC using the `rtrv-map` command.
3. Delete all other references that point to this DPC. Refer to the procedure found in the *Database Administration Manual - SS7* manual for removing the last route to a DPC.
4. Re-enter the `dlt-rte` command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2644 Cmd Rej: Cannot delete last route to DPC ref. by an X.25 route

Commands Used: `dlt-rte`

The route that you attempted to delete was the last route to the DPC, and that DPC was referenced by an X.25 route. You must first delete the X.25 routes to that DPC.

Recovery

1. Display the X.25 destination associated with the DPC used in the command that generated this error message.
Enter the `rtrv-x25-dstn` command.
2. Display the X.25 routes associated with the X.25 address shown in Step 1.
Enter the `rtrv-x25-rte` command.
3. Delete the X.25 routes shown in Step 2.
Enter the `dlt-x25-rte` command.
4. Re-enter the `dlt-rte` command that generated this error message.

E2645 Cmd Rej: Cannot delete last route to DPC ref. by redirect func

Commands Used: `dlt-rte`, `chg-dstn`,

The last route to a destination referenced by the redirect function destination parameter cannot be deleted.

Recovery

1. Display the gateway screening function DPC. Enter the `rtrv-gws-redirect` command.
The entry `rdct` is displayed in the *ACT1* through the *ACT10* fields in any gateway screening stop action sets that have the redirect gateway screening stop action assigned to them.
 - a) To change the gateway screening function DPC, enter the `chg-gws-redirect:dpc=` command.

Refer to the procedure 'Changing the Gateway Screening Redirect Parameters' in the *Database Administration Manual - Features*.

- b) To disable the gateway screening redirect function, enter the `chg-gws-redirect:enabled=off` or `dlt-gws-redirect` command.

Note:

Turning off the gateway screening redirect function also turns off the DTA feature.

Refer to the procedure 'Disabling the Gateway Screening Redirect Function' in the *Database Administration Manual - Features*.

2. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2646 Cmd Rej: APC cannot be ref. by an X.25 route with LC2NM=YES

Commands Used: `chg-ls`, `ent-ls`, `rtrv-x25-rte`

You cannot specify an APC whose associated X.25 address is being used in an X.25 route that has the logical channel to network management mapping function turned on (`lc2nm=yes`). The specified adjacent point code cannot be referenced by an X.25 route that specifies the `lc2nm=yes` parameter.

Recovery

1. Display X.25 routes.
Enter the `rtrv-x25-rte` command.
2. Display the X.25 addresses for their associated point codes.
Enter the `rtrv-x25-dstn` command.
3. Display the DPC table.
Enter the `rtrv-dstn` command.
4. View the linksets.
Enter the `rtrv-ls` command.
5. Re-enter the command specifying a point code shown in Step 3 that is not shown in Step 4 as an adjacent point code.
Also, ensure that the point code has an X.25 address (from Step 2) that does not have an X.25 route with the logical channel to network management mapping function on ("no" is displayed in the `LC2NM` field in Step 1).

E2647 Cmd Rej: Only one of PCN or PCN24 may be specified

Commands Used: `chg-sid`, `ent-sid`

You cannot specify both the `pcn` and `pcn24` parameters in the same command.

Recovery

Re-enter the command specifying either the **pcn** or **pcn24** parameter, but not both.

E2649 Cmd Rej: Failed reading the X.25 destination table

Commands Used: `chg-x25-dstn`, `dlt-x25-dstn`, `ent-x25-rte`, `rtrv-x25-dstn`

The X.25 Destination table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2650 Cmd Rej: Failed reading the X.25 route table

Commands Used: `chg-x25-dstn`, `chg-x25-rte`, `dlt-x25-dstn`, `dlt-x25-rte`,
`ent-x25-rte`

The X.25 Route table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2654 Cmd Rej: Max Packet Size must be 128 when N1 is equal to 1080

Commands Used: `chg-x25-slk`

You cannot specify **n1=1080** if the **mps=256**. If you specify **n1=1080**, the value of the **mps** parameter must be **128**.

Recovery

Perform one of the following:

- Re-enter the `chg-x25-slk` command specifying **n1=1080** and **mps=128**.
OR
- Re-enter the `chg-x25-slk` command, and omit both parameters, to accept the system defaults of a **256** byte maximum packet size, and **2104** maximum number of bits in a frame.

E2655 Cmd Rej: X.25 Address must contain at least four digits

Commands Used: `chg-x25-dstn`, `chg-x25-rte`, `dlt-x25-dstn`, `dlt-x25-rte`,
`ent-x25-dstn`, `ent-x25-rte`, `rtrv-x25-dstn`, `rtrv-x25-rte`

The specified X.25 address (**xaddr**) contained less than four digits. These commands require that each X.25 address must have at least four digits.

Recovery

Re-enter the command specifying an X.25 address parameter (**xaddr**) parameter at least four digits in length.

E2656 Cmd Rej: GTT must be ON before MGTT can be ON

Commands Used: `chg-feat`

You must turn on the Global Title Translation (GTT) feature before you can turn on the Global Title Translation Modifications (MGTT) feature.

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off.

Recovery

1. Verify that the GTT feature is turned off. Enter the `rtrv-feat` command.
2. Turn on the GTT feature. Enter the command: `chg-feat:gtt=on`
3. Turn on the MGTT feature. Enter the command: `chg-feat:mgtt=on`

E2657 Cmd Rej: Point code not defined

Commands Used: `chg-dstn`, `chg-gws-redirect`, `chg-ls`, `dlt-dstn`, `dlt-rmt-appl`,
`ent-gws-redirect`, `ent-ls`, `ent-rmt-appl`, `rtrv-dstn`

A destination point code (DPC) cannot be specified if it is not defined in the Destination Point Code table. To execute the command, the specified destination point code must be defined in the Destination Point Code table.

OR

The specified end node internal point code could not be found in the Destination Point Code table. To execute the command the internal point code must be in the Destination Point Code table.

Recovery - `rtrv-dstn`

Display all the destination point codes in the Destination Point Code table. Re-enter the `rtrv-dstn` command specifying no parameters.

Recovery - `chg-dstn`, `chg-ls`, `dlt-dstn`, `ent-ls`

Verify that the command was entered correctly, and re-enter the command.

OR

1. Display the destination point codes in the Destination Point Code table. Enter the `rtrv-dstn` command.
2. Re-enter the command specifying a destination point code defined in the Destination Point Code table.

Recovery - `chg-gws-redirect`, `ent-gws-redirect`

1. Display the destination point codes in the Destination Point Code table. Enter the `rtrv-dstn` or `rtrv-sid` command, as required.
2. Re-enter the command specifying a destination point code defined in the Destination Point Code table.

Recovery - `dlt/ent-rmt-appl`

1. Display the existing internal point codes in the Destination table. Enter the `rtrv-dstn` command.
2. Re-enter the command specifying an existing internal point code defined in the Destination table.

E2658 Cmd Rej: X.25 address already exists in X.25 destination table

Commands Used: `ent-x25-dstn`

The specified X.25 address (**xaddr**) already exists in the X.25 Destination table. To add an X.25 address entry, it cannot exist in the X.25 Destination table.

Recovery

1. Display the X.25 destinations in the database.
Enter the `rtrv-x25-dstn` command.
2. Re-enter the `ent-x25-dstn` command specifying an X.25 address that is not defined in the X.25 Destination table.

E2659 Cmd Rej: X.25 address cannot be referenced by route

Commands Used: `chg-x25-dstn`, `dlt-x25-dstn`

The specified X.25 address (**xaddr**) is referenced by the X.25 Routing table. To execute these commands, the X.25 address cannot be referenced by any X.25 routes.

Recovery

1. Display the X.25 routes in the X.25 Routing table.
Enter the `rtrv-x25-rte` command.
2. Delete the X.25 routes that reference the specified X.25 address.
Enter the `dlt-x25-rte` command.
3. Re-enter the command that generated this error message.

E2660 Cmd Rej: X.25 address does not exist in X.25 destination table

Commands Used: `chg-x25-dstn`, `dlt-x25-dstn`, `ent-x25-rte`, `rtrv-x25-dstn`

The specified X.25 address (**xaddr**) cannot be found in the X.25 Destination table. These commands require that the X.25 address be in the database.

Recovery

1. Display the X.25 destinations in the database.
Enter the `rtrv-x25-dstn` command.
2. Re-enter the command specifying an X.25 address that is shown in the output of Step 1.

E2661 Cmd Rej: X.25 destination table is full

Commands Used: `ent-x25-dstn`

The X.25 Destination table already contains the maximum number of destinations. If the X.25 feature is turned on, the maximum number is **1024**. If the X.25 and the `x252000` features are turned on, the maximum number is **2000**.

Enter the `rtrv-feat` command to check which features are turned on. If the X.25 feature is on, the output shows `x25g=on`. If the `x252000` feature is on, the output shows both `x25g=on` and `x252000=on`.

Table 11: Action if X.25 Destination Table is Full describes the possible recovery procedures.

Table 11: Action if X.25 Destination Table is Full

To Perform this Action	Follow this Procedure
Change an existing X25 destination.	Display the X.25 destinations in the database. Enter the <code>rtrv-x25-dstn</code> command. Change an existing X.25 destination. Enter the <code>chg-x25-dstn</code> command specifying the new X.25 destination information.
Delete an existing X.25 destination and add the new one.	Delete an existing X.25 destination. Enter the command <code>dlt-x25-dstn</code> Add the new X.25 destination. Re-enter the <code>ent-x25-dstn</code> command that generated this error message.
Turn on the <code>x252000</code> feature to increase the maximum number of X25 destinations up to 2000 .	Turn on the <code>x252000</code> feature. Enter the command: <code>chg-feat : x252000=on</code>

To Perform this Action	Follow this Procedure
	Re-enter the <code>ent-x25-dstn</code> command that generated this error message.

Recovery

1. Verify that the x-list storage is full, or nearly full.
Enter the `rept-stat-xlist` command. This command displays a snapshot of the statistics related to the storage of x-list entries. The percentage of space in the x-list reserved area currently in use is displayed in the Current X-LIST occupancy field. When the x-list storage is full, the percentage of space displayed in this field is 100%.
2. If the percentage of space displayed in Step 1 is less than 100%, re-enter the command.

E2662 Cmd Rej: Maximum SVCAs already defined for link

Commands Used: `chg-x25-rte`, `ent-x25-rte`

You tried to assign an automatic switched virtual circuit (SVCA) to a signaling link (**loc** and **port**) that contains the maximum number of switched virtual circuits (SVC). The maximum number of SVCs for a signaling link is defined by the `chg-x25-slk` command.

Recovery

1. Display the maximum number of SVCs allowed for the signaling link.
Enter the `rtrv-x25-slk` command specifying the card location and port of the signaling link. The maximum number of SVCs defined for the X.25 signaling link is shown in the *SVC* field of the output.
2. Display the X.25 routes in the database.
Enter the `rtrv-x25-rte` command specifying the **type=svca** parameter. The number of SVCs assigned to the specified signaling link should be equal to the number in the *SVC* field in the output of Step 1.
3. If the total of PVCs and SVCs defined for this X.25 signaling link is less than **255**, shown in the *PVC* and *SVC* fields of the output of Step 1, change the number of SVCs.
Enter the `chg-x25-slk` command and a higher value for the **svc** parameter.
4. Re-enter the command that generated this error message.
5. If the total of PVCs and SVCs defined for this X.25 signaling link is **255**, delete an X.25 route with a connection type of SVCA (**type=svca**) assigned to the specified signaling link.
Enter the `dlt-x25-rte` command.
6. Re-enter the command that generated this error message.

E2663 Cmd Rej: Combination of X.25 addresses not in X.25 route table

Commands Used: `chg-x25-rte`, `dlt-x25-rte`

The combinations of X.25 addresses entered cannot be found in the X.25 routing table. These X.25 addresses combinations cannot be changed or deleted if they are not in the X.25 routing table.

Recovery

1. Display the entries in the X.25 routing table.
Enter the `rtrv-x25-rte` command.
2. Re-enter the command specifying X.25 addresses that are shown in the output of Step 1.

E2664 Cmd Rej: LC must be specified when TYPE=PVC

Commands Used: `ent-x25-rte`

You specified the `type=pvc` parameter and without the `lc` parameter. The `lc` parameter is required when the `type=pvc` parameter is specified.

Recovery

Re-enter the `ent-x25-rte` command specifying both the `type=pvc` and the `lc` parameters.

E2665 Cmd Rej: LC can only be specified when TYPE=PVC

Commands Used: `ent-x25-rte`, `rtrv-x25-rte`

You cannot specify the `lc` parameter and the `type=svca` or `type=svcr` parameters. The connection types SVCA (`type=svca`) or SVCR (`type=svcr`) cannot be specified with the `lc` parameter. Only the connection type PVC (`type=pvc`) can be specified with the `lc` parameter.

Recovery

Perform one of the following:

- Re-enter the command specifying the `lc` and `type=pvc` parameters, or
OR
- Re-enter the command specifying either the `type=svca` or `type=svcr` parameters, and without the `lc` parameter.

E2666 Cmd Rej: LOC must be specified when TYPE=PVC or SVCA

Commands Used: `chg-x25-rte`, `ent-x25-rte`

You cannot specify the **type=pvc** or **type=svca** parameters without specifying the **loc** parameter. If the **type=pvc** or **type=svca** parameters are specified, the **loc** parameter must be specified.

Recovery

1. Display the cards in the database.
Enter the `rtrv-card` command.
2. Re-enter the command specifying either the **type=pvc** or **type=svca** parameters and a card location (**loc** parameter) shown in the output of Step 1.
This card location must be either a **limsd0**, **limocu**, or **limv35** card type and must be assigned the **ss7gx25** application. The card types are shown in the *TYPE* field, and the applications are shown in the *APPL* field, of the `rtrv-card` output.

E2667 Cmd Rej: LOC must not be specified when TYPE=SVCR

Commands Used: `rtrv-x25-rte`

You cannot specify the **type=svcr** and the **loc** parameters. If the **type=svcr** parameter is specified, the **loc** parameter cannot be specified.

Recovery

Re-enter the `rtrv-x25-rte` command specifying the **type=svcr** parameter without specifying the **loc** parameter.

E2668 Cmd Rej: PORT must not be specified when TYPE=SVCR

Commands Used: `chg-x25-rte`, `ent-x25-rte`

You cannot specify the **port** parameter if **type=svcr**. You can specify the **port** parameter only with the **loc** parameter. The **loc** parameter cannot be specified with the **type=svcr** parameter.

The **port** parameter can be specified only with the **loc** parameter. Neither the **loc** nor the **port** parameters cannot be specified with the **type=svcr** parameter.

Recovery

Re-enter the command specifying the **type=svcr** parameter without specifying the **port** parameter.

E2669 Cmd Rej: SS7 address does not exist in X.25 destination table

Commands Used: `ent-x25-rte`

The specified SS7 address (**saddr**, the dummy X.25 address assigned to the SS7 destination point code) could not be found in the X.25 destination table. This command requires that the SS7 address be in the X.25 destination table.

Recovery

1. Display the X.25 destinations (**xaddr**) in the database.
Enter the `rtrv-x25-dstn` command.
2. Display the DPCs in the database.
Enter the `rtrv-dstn` command.
3. Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command that generated this error message, with an SS7 address (**saddr**) that is assigned to the SS7 domain and is in the X.25 destination table.

E2670 Cmd Rej: DPC assigned to X25 address does not exist in X25 domain

Commands Used: `ent-x25-rte`

You specified a value for the **xaddr** (X.25 address) parameter whose destination point code is not in the X.25 domain.

Recovery

1. Display the destination point codes in the database.
Enter the `rtrv-dstn` command.
2. Display the X.25 addresses in the X.25 destination table.
Enter the `rtrv-x25-dstn` command.
3. Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying a destination point code that is in the X.25 domain.

E2671 Cmd Rej: DPC assigned to SS7 address does not exist in SS7 domain

Commands Used: `ent-x25-rte`

You specified a value for the SS7 X.25 address (**saddr**) parameter whose destination point code is not in the SS7 domain.

Recovery

1. Display the destination point codes in the database.
Enter the `rtrv-dstn` command.
2. Display the X.25 addresses in the X.25 destination table.
Enter the `rtrv-x25-dstn` command.
3. Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying a destination point code that is in the SS7 domain.

E2672 Cmd Rej: DPC assigned to X.25 address has no SS7 routes

Commands Used: `ent-x25-rte`

The destination point code (DPC) associated with the X.25 address (**xaddr**) does not have any routes assigned to it. For the execution of this command to be successful, the DPC must have at least one route assigned to it.

Recovery

1. Display the X.25 destinations in the database.
Enter the `rtrv-x25-dstn` command.
2. Display the routes in the database.
Enter the `rtrv-rte` command.
3. Perform one of the following:
 - a) Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command, with an X.25 address whose DPC has at least one route assigned to it.
OR
 - b) Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying the **dstn** but not the route.
4. Re-enter the original command.

E2673 Cmd Rej: DPC assigned to SS7 address has no SS7 routes

Commands Used: `ent-x25-rte`

The destination point code (DPC) associated with the SS7 address (**saddr**) does not have any routes assigned to it. For the execution of this command to be successful, the DPC must have at least one route assigned to it.

Recovery

1. Display the X.25 destinations in the database.
Enter the `rtrv-x25-dstn` command.
2. Display the routes in the database.
Enter the `rtrv-rte` command.
3. Perform one of the following:
 - a) Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying an SS7 address whose DPC has at least one route assigned to it.
OR
 - b) Using the output from Steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying the **dstn** but not the route.
4. Re-enter the original command.

E2674 Cmd Rej: Combination of X.25 addresses exists in X.25 route table

Commands Used: `ent-x25-rte`

The X.25 addresses entered already exist in the X.25 Routing table. These X.25 addresses cannot be entered if they are already in the X.25 Routing table.

Recovery

1. Display the entries in the X.25 Routing table.
Enter the `rtrv-x25-rte` command.
2. Display the entries in the X.25 Destination table.
Enter the `rtrv-x25-dstn` command.
3. Re-enter the `ent-x25-rte` command, with X.25 addresses that are shown in the output of Step 2 and that are not in the output of Step 1.
4. If the X.25 addresses you wish to enter are not shown in the output of Step 2, add the X.25 addresses to the X.25 destination table using the `ent-x25-dstn` command, then re-enter the `ent-x25-rte` command specifying those X.25 addresses.

E2675 Cmd Rej: Combination of SS7 PC/SSNs exists in X.25 route table

Commands Used: `ent-x25-rte`

The SS7 point codes and subsystem combinations associated with the X.25 addresses entered, already exist in the X.25 Routing table. These point code and subsystem combinations cannot be entered if they already exist in the X.25 Routing table.

Recovery

1. Display the entries in the X.25 Routing table.
Enter the `rtrv-x25-rte` command.
2. Display the entries in the X.25 Destination table.
Enter the `rtrv-x25-dstn` command.
3. Re-enter the `ent-x25-rte` command specifying X.25 addresses that are shown in the output of Step 2 and that are not in the output of Step 1.
4. If the X.25 addresses you wish to enter are not shown in the output of Step 2, add the X.25 addresses to the X.25 Destination table using the `ent-x25-dstn` command, then re-enter the `ent-x25-rte` command specifying those X.25 addresses.

E2676 Cmd Rej: X.25 route table is full

Commands Used: `ent-x25-rte`, `chg-x25-rte`

The X.25 Route table already contains the maximum of routes. The maximum number allowed depends on the features you have turned on.

- If the X.25 feature is turned on, the maximum number of routes is **1024**.
- If both the X.25 and the x252000 features are turned on, the maximum number of routes is **2000**.

Enter the `rtrv-feat` command to check which features are turned on.

- If the X.25 feature is on, the output shows **x25g=on**.
- If the x252000 feature is on, the output shows both **x25g=on** and **x252000=on**.

Recovery

Table 12: Action if X.25 Route Table is Full describes the possible recovery procedures.

Table 12: Action if X.25 Route Table is Full

To Perform this Action	Follow This Procedure
Change an existing route.	Display the X.25 routes in the database. Enter the command: <code>rtrv-x25-rte</code> To change an existing X.25 route, enter the <code>chg-x25-rte</code> command specifying the new X.25 route information.
Delete an existing X.25 route and add the new one.	Delete an existing X.25 route. Enter the <code>dlt-x25-rte</code> command. Re-enter the command that generated this error message.
Increase the maximum number of routes allowed if the x252000 feature is not yet on.	Enter the command: <code>chg-feat:x252000=on</code> Re-enter the command that generated this error message.

E2677 Cmd Rej: Link not equipped

Commands Used: `ent-x25-rte`

The specified signaling link (**loc** and **port**) could not be found in the database. This command requires that an X.25 signaling link be in the database.

Recovery

1. Display the signaling links in the database.
Enter the `rtrv-slk` command. The X.25 signaling links are shown in the output by dashes in the *L2TSET* field.

2. Re-enter the `ent-x25-rte` command specifying an X.25 signaling link shown in the output of Step 1.

E2678 Cmd Rej: Link not assigned to SS7-X.25 card

Commands Used: `rept-x25-meas`

The card containing the signaling link, specified in this command by the **loc** and **port** parameters, is not a LIM using the **ss7gx25** application. Only signaling links assigned to LIMs using the **ss7gx25** application can be specified with this commands.

Recovery

1. Verify the applications assigned to the cards.
Enter the `rtrv-card` command.
2. Verify that the cards running the **ss7gx25** application, shown in the *APPL* field in the output of Step 1, have signaling links assigned to them.
Enter the `rtrv-slk` command.
3. Using the output from Steps 1 and 2 as a guide, re-enter the `rept-x25-meas` command specifying a card location (**loc**) that is running the **ss7gx25** application that has a signaling link assigned to it, and the corresponding port on that card.

E2679 Cmd Rej: LC greater than maximum PVCs for link

Commands Used: `ent-x25-rte`

The logical channel number specified is greater than the maximum number of permanent virtual circuits (PVCs) allowed for the signaling link. The `ent-x25-rte` command does not allow this.

For example, if the total number of PVCs allowed for the signaling link is **15**, the logical channel number for this signaling link cannot be greater than **15**.

Recovery

1. Display the x25 signal link information.
Enter the `rtrv-x25-slk` command.
2. Re-enter the `ent-x25-rte` command specifying a logical channel number that is less than the number PVCs determined in Step 1.

E2680 Cmd Rej: LC already in use

Commands Used: `ent-x25-rte`

The specified logical channel of the signaling link is assigned to another X.25 route. The logical channel specified in this command cannot be assigned to another X.25 route.

Recovery

1. Display all X.25 routes in the database.
Enter the `rtrv-x25-rte` command.
2. Re-enter the `ent-x25-rte` command specifying the **type=pvc** parameter, and a logical channel for the X.25 route that is not assigned to another X.25 route at this logical channel.

E2681 Cmd Rej: Cannot change if existing connection type is PVC

Commands Used: `chg-x25-rte`

The specified X.25 route has a connection type of PVC (permanent virtual circuit). An X.25 route that has a connection type of PVC cannot be changed with this command. To use this command, the connection type must be SVCA (automatic virtual circuit) or SVCR (remote virtual circuit).

Recovery

1. Display the X.25 routes in the database.
Enter the `rtrv-x25-rte` command. The connection type is shown in the *TYPE* field of the output.
2. Re-enter the `chg-x25-rte` command specifying an X.25 route that has a connection type of either SVCA or SVCR.

E2682 Cmd Rej: New connection type must be different from existing

Commands Used: `chg-x25-rte`

The connection type of the specified X.25 signaling link was not changed by this command. For example, the connection type of the X.25 signaling link is SVCA (automatic switched virtual circuit), and the command was entered with the **type=svca** parameter. When this command is entered, the connection type must be changed.

Recovery

1. Display the X.25 routes in the database.
Enter the `rtrv-x25-rte` command. The connection type of the X.25 signaling links is shown in the *TYPE* field of the output.
2. If the connection type of the specified X.25 signaling link is SVCA, re-enter the command specifying the **type=svcr** parameter.
3. If the connection type of the specified X.25 signaling link is SVCR, re-enter the command specifying the **type=svca** parameter.

E2683 Cmd Rej: Cannot specify LC without LOC

Commands Used: `rtrv-x25-rte`

You cannot specify the **lc** parameter without specifying the **loc** parameter. If the **lc** parameter is specified, the **loc** parameter must be specified.

Recovery

Re-enter the `rtrv-x25-rte` command specifying both the **lc** and **loc** parameters.

E2684 Cmd Rej: N1 must be either 1080 or 2104

Commands Used: `chg-x25-slk`

You specified a value for the **n1** parameter that was not **1080** or **2104**. The only values allowed for this parameter is **1080** or **2104**.

Recovery

Re-enter the command specifying either **1080** or **2104** for the value for the **n1** parameter.

E2685 Cmd Rej: MPS must be either 128 or 256

Commands Used: `chg-x25-slk`

You assigned an invalid value to the maximum packet size (**mps**) parameter. The only valid values are **128** and **256**.

Recovery

Re-enter the `chg-x25-slk` command that generated this error message specifying a value of either **128** or **256** for the **mps** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2686 Cmd Rej: PVC plus SVC must be at least 1

Commands Used: `chg-x25-slk`

You specified the sum of the values for the **pvc** and **svc** parameters being **0** (for example, **pvc=0** and **svc=0**). The sum of the values for the **pvc** and **svc** parameters must be greater than **0**.

Recovery

Re-enter the `chg-x25-slk` command specifying a value greater than **0** for either the **pvc** and/or **svc** parameter.

E2687 Cmd Rej: PVC plus SVC cannot be greater than 255

Commands Used: `chg-x25-slk`

You specified the sum of the values for the **pvc** and **svc** parameters being greater than 255 (for example, **pvc=125** and **svc=150**). The sum of the values for the **pvc** and **svc** parameters cannot exceed 255.

Recovery

Re-enter the `chg-x25-slk` command and make sure that the sum of the values for the **pvc** and **svc** parameters does not exceed 255.

E2688 Cmd Rej: Cannot decrease PVC below a logical channel in use

Commands Used: `chg-x25-slk`

You specified a value for the **pvc** parameter that was less than the number of logical channels assigned to the X.25 signaling link. The number of PVCs cannot be less than the number of logical channels for a particular X.25 signaling link.

Recovery

1. Display the number of PVCs assigned to the X.25 signaling link.
Enter the `rtrv-x25-slk` command, with the card location and port used in the command that generated this error message. The number of PVCs is shown in the *PVC* field of the output.
2. Display the logical channels for the X.25 routes assigned to the X.25 signaling link displayed in Step 1.
Enter the `rtrv-x25-rte` command. The number of logical channels is shown in the *LC* field of the output.
3. Perform one of the following:
 - a) Re-enter the `chg-x25-slk` command specifying a value for the **pvc** parameter that is equal to or greater than the number of logical channels displayed in Step 2.
OR
 - b) Use the `dlt-x25-rte` command to delete a logical channel.
4. Re-enter the `chg-x25-slk` command.

E2689 Cmd Rej: Cannot decrease SVC below number of SVCs already in use

Commands Used: `chg-x25-slk`

The new quantity of SVCs assigned to the specified signaling link is less than the amount used by the X.25 route associated with the X.25 signaling link. The amount of SVCs assigned to an X.25 signaling

link must be equal to or greater than the amount used by the X.25 route associated with the signaling link.

Recovery

1. Display the X.25 routes associated with the specified X.25 signaling link.
Enter the `rtrv-x25-rte` command specifying the card location of the specified X.25 signaling link. The connection type is shown in the *TYPE* field of the output.
2. Count the number of SVCAs in the output of Step 1.
3. Perform one of the following actions:
 - a) Re-enter the `chg-x25-slk` command specifying a value for the `svc` parameter that is equal to greater than the number of SVCAs determined in Step 2.
OR
 - b) Use the `dlr-x25-rte` command to delete an SVC.
4. Re-enter the `chg-x25-slk` command.

E2690 Cmd Rej: LOC not assigned a X.25 signaling link

Commands Used: `chg-x25-slk`

The specified card location was not an X.25 signaling link.

Recovery

1. Display the signaling links in the database.
Enter the `rtrv-x25-slk` command.
2. Re-enter the `chg-x25-slk` command specifying a card location that is an X.25 signaling link as shown in Step 1.

E2691 Cmd Rej: Card is not a SS7GX25 card

Commands Used: `chg-x25-slk`

You specified a card that is not assigned the `ss7gx25` application.

Recovery

1. Display the cards in the database.
Enter the `rtrv-x25-slk` command.
2. Re-enter the `chg-x25-slk` command specifying a `ss7gx25` card location shown in Step 1.

E2692 Cmd Rej: FWORD can only be used with PADDR

Commands Used: `set-mem`

You specified an invalid parameter. You can enter only one of the following parameters, **byte**, **word**, or **dword**.

Recovery

Re-enter the `set-mem` command that generated this error message specifying the correct **byte**, **word**, or **dword** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2693 Cmd Rej: FWORD is not supported at this time

Commands Used: `disp-bp`, `disp-mem`, `ent-bp`, `set-mem`

You specified an invalid parameter. You can enter only one of the following parameters, **byte**, **word**, or **dword**; however, you must enter one of them.

Recovery

Re-enter the command that generated this error message specifying the correct **byte**, **word**, or **dword** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2694 Cmd Rej: Invalid combination of ADDR and PADDR specified

Commands Used: `disp-mem`, `dlt-bp`, `ent-bp`, `set-mem`

You can enter only one of the parameters **addr** or **paddr**.

Recovery

Re-enter the command that generated this error message specifying either the **addr** or **paddr** parameter, but not both.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2695 Cmd Rej: DPADDR cannot be entered with DR/DA

Commands Used: `ent-bp`

The `dpaddr` parameter cannot be entered with the `da` or `dr` parameters.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying the correct `dpaddr`, `da`, or `dr` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2696 Cmd Rej: REP cannot be specified when DUR=PERM

Commands Used: `ent-bp`

You attempted to define a breakpoint that was both permanent, and repeating. You cannot enter the **dur=perm** and the **rep** parameters at the same time.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying the correct **dur** or **rep** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2697 Cmd Rej: IND cannot be greater than 3

Commands Used: `ent-bp`

You cannot enter the `ent-bp` command specifying a value greater than 3 for the **ind** parameter.

Recovery

Re-enter the `ent-bp` command specifying a value less than 3 for the **ind** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2698 Cmd Rej: DUR=PERM can only be specified with a 486 processor

Commands Used: `ent-bp`

You cannot enter the `ent-bp` command specifying the **dur=perm** parameter if the processor is not a 80486 CPU.

Recovery

Perform one of the following:

- Re-enter the `ent-bp` command that generated this error message and omit the **dur** parameter,
OR

- Re-enter the `ent-bp` command that generated this error message and set the `dur` parameter to **temp**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2699 Cmd Rej: DATA can only be specified with P486

Commands Used: `ent-bp`

The value **data** for the breakpoint-type portion of the **type** parameter can only be specified with the value **p486** for the processor-type portion of the **type** parameter.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying the correct value **p486** for the processor-type portion of the **type** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2700 Cmd Rej: ACCESS can only be specified with TYPE=P486-DATA

Commands Used: `ent-bp`

You can specify the **access** parameter only when the value of the processor-type portion of the **type** parameter is **p486**.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying the correct value (**p486**) of the processor type portion of the **type** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2701 Cmd Rej: Meas Platform feature must be ON

Commands Used: `chg-measopts`, `chg-mtc-measopts`, `ent-card`, `rept-ftp-meas`, `rept-stat-meas`, `rtrv-measopts`, `rtrv-mtc-measopts`

The Measurements Platform feature must be turned on before this command can be entered. The Measurements Platform collection option must be turned on (`platformenable=on`) before the CLI-based name option can be turned on (`cllibasedname=on`).

Recovery

1. Verify that the Measurements Platform feature is turned on. Enter the `rtrv-feat` command.

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for more information.

2. If the Measurements Platform feature is off, turn it on. Enter the command:
`chg-feat:measplat=on`
3. When the Measurements Platform feature is turned on, re-enter the command that generated the error message.

E2702 Cmd Rej: At least one MCPM card must be configured in system

Commands Used: `rept-stat-meas`

At least one MCPM card must be configured in the EAGLE 5 ISS for the Measurements Platform feature, before you can enter the `rept-stat-meas` command.

Recovery

1. Enter the `rept-stat-card` command and verify that there is at least one MCPM card configured in the EAGLE 5 ISS for the Measurements Platform.
2. If there are no MCPM cards configured in the system, you cannot use this command.
3. If there is at least one MCPM card configured in the system, re-enter the **`rept-stat-meas`** command that generated the error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2703 Cmd Rej: Missing parameter - DPADDR or DR

Commands Used: `ent-bp`

You attempted to set a break point, but omitted the necessary **`dpaddr`** or **`dr`** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct **`dpaddr`** or **`dr`** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2704 Cmd Rej: Invalid IPADDR

Commands Used: `chg-ftp-serv`, `chg-ip-card`, `chg-ip-lnk`, `dlt-ftp-serv`,
`ent-ftp-serv`, `ent-ip-host`, `rtrv-ftp-serv`, `rtrv-ip-host`, `tst-dlk`, `ent-dlk`

A command was entered for an IP address that does not exist in the database, or a value was specified that does not conform to the naming conventions.

An IP address consists of the system's network number and the machine's unique host number (four numbers separated by dots, with each number in the range of 0-255). An IP address example is **192.9.200.44**, where **192.9.200** is the network number and **44** is the machine's host number. The IP address (**ipaddr**) entered must belong to either CLASS A, CLASS B, or CLASS C.

Recovery - **tst-dlk**

1. Display the IP addresses configured in the database. Enter the **rtrv-dlk** command.
2. Re-enter the **tst-dlk** command specifying an IP address that exists in the database.
OR
3. Add the IP address to the database. Enter the **ent-dlk** command.
4. Re-enter the **tst-dlk** command.

Recovery - **chg-ftp-serv, chg-ip-card, chg-ip-lnk, dlt-ftp-serv, ent-ip-host, ent-ftp-serv, rtrv-ftp-serv, rtrv-ip-host**

Re-enter the command specifying a value for the IP address that conforms to the naming conventions. Refer to the *Commands Manual* and to the *Database Administration Manual-IP7 Secure Gateway* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2705 Cmd Rej: IP Node Address never entered or Card DB corrupt

Commands Used: **dlt-ip-node, ent-ip-node**

If you specify the **loc** and **ipaddr** parameters, the specified IP address must match the IP address of the card location's remote IP node.

Recovery

Re-enter the command that generated this error message specifying the correct **ipaddr** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2706 Cmd Rej: APPL is invalid for report or entity

Commands Used: **rept-meas**

The **enttype=stplan** and the **type=avl** parameters must be specified before the **appl** parameter can be specified. The **appl** parameter is valid only with **enttype=stplan** and **type=avl**. If the **enttype=lnp** parameter is specified, then the **appl** parameter cannot be specified.

The value of the **appl** parameter must apply to the reports specified for the **enttype** and **type** parameters.

Recovery

Re-enter the command specifying the correct combination of parameters.

Refer to the `rept-meas` command description in the *Commands Manual* for valid parameter combinations.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2707 Cmd Rej: LOC is invalid for specified report TYPE

Commands Used: `rept-meas`

The **type=systot** and **loc** parameters cannot be specified in the same command line.

Recovery

Re-enter the `rept-meas` command specifying the **type=systot** parameter, and without the **loc** parameter.

E2708 Cmd Rej: APPL or LOC must be specified

Commands Used: `rept-meas`

The command was entered with both the **appl** and **loc** parameters. Either of these parameters may be entered, but not both.

Recovery

Re-enter the `rept-meas` command specifying either the **appl**, or the **loc** and **port** parameters.

E2709 Cmd Rej: APPL is invalid for specified PERIOD

Commands Used: `rept-meas`

You specified the **appl** parameter, and either the **period=active** or **period=all** parameters. The **appl** parameter can be used only with the **period=last** or the **period=specific** parameters.

Recovery

Re-enter the `rept-meas` command specifying the **appl** parameter, and either the **period=last** or the **period=specific** parameters.

E2710 Cmd Rej: Cannot assign ITU and ANSI LHOST to the same AS

Commands Used: `chg-assoc`, `ent-as`

You entered a `chg-assoc` command to change the **lhost** for a specified association. The current **lhost** and the specified new **lhost** are running different types of applications (ITU or ANSI). This is not allowed.

OR

You entered an `ent-as` command to assign an M3UA/SUA association (adapter type) to an application server (AS). The associations assigned to the specified M3UA/SUA association (adapter type) are assigned to a different type of **lhost** than the **lhost** type for the associations for the M3UA/SUA associations (adapter type) already assigned to the AS (ITU or ANSI). This is not allowed.

Recovery - `chg-assoc`

1. Display the IP address for the current and new association local hosts (**lhost**). Enter the `rtrv-ip-host` command
2. Display the card location for each **lhost** IP address from Step 1. Enter the `rtrv-ip-lnk` command.
3. Display the application that is running on each **lhost** card. Enter the `rtrv-card` command. The **ss7ipgw** and **iplim** applications are ANSI, and the **ipgwi** and **iplimi** applications are ITU.
4. Re-enter the `chg-assoc` command that generated this error message specifying parameters that change the **lhost** for the association to a new **lhost** of the same type.

Recovery - `ent-as`

1. Display the associations with the specified AS.
Enter the `rtrv-as` command.
2. Display the **lhost** assigned to each association for the specified M3UA/SUA association (adapter type).
Enter the `rtrv-assoc` command.
3. Display the **lhost** IP addresses.
Enter the `rtrv-ip-host` command.
4. Display the card location for one **lhost** IP address from Step 3.
Enter the `rtrv-ip-lnk` command.
5. Display the application that is running on that **lhost** card.
Enter the `rtrv-card` command. The **ss7ipgw** and **iplim** applications are ANSI, and the **ipgwi** and **iplimi** applications are ITU.
6. Re-enter the `ent-as` command specifying the correct parameters to assign the M3UA/SUA association (adapter type) to an AS, so that all associations assigned to M3UA/SUA association (adapter type) on the AS have the same type of **lhost**.

E2711 Cmd Rej: Invalid parameter

Commands Used: `chg-gtt`, `chg-tbl`, `ent-gtt`

You specified a parameter that the software did not recognize. You may have made a clerical error, or the system may need maintenance.

For the `chg-gtt` and `chg-egtt` commands, you cannot specify the routing indicator (**ri**) and point code (**pc**) parameters, if the value for the translate indicator **xlat=udts** or **discard** is changed and the **xlat** parameter is not specified.

Recovery

Re-enter the command that generated this error message specifying the correct parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2712 Cmd Rej: RESETCHAR not valid with ACTION=CREATE

Commands Used: `chg-tbl`

If `action=create` is requested, the following parameters must be entered: **name**, **ext**, **filelength**. All other parameters are ignored or defaulted. You attempted to enter the **resetchar** parameter.

Recovery

Re-enter the command that generated this error using only the valid parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2713 Cmd Rej: FILELENGTH not valid with ACTION=RESET

Commands Used: `chg-tbl`

If `action=reset` is requested, the **id** parameter must be entered. All other parameters (including **filelength**) are ignored or defaulted.

Recovery

- Re-enter the command that generated this error message specifying only the valid parameters. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2714 Cmd Rej: NAME not valid with ACTION=RESET

Commands Used: `chg-tbl`

If `action=reset` is requested, the **id** parameter must be entered. All other parameters (including **name**) are ignored or defaulted.

Recovery

- Re-enter the command that generated this error message specifying only the valid parameters. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2715 Cmd Rej: EXT not valid with ACTION=RESET

Commands Used: chg-tbl

If `action=reset` is requested, the `id` parameter must be entered. All other parameters (including `ext`) are ignored or defaulted.

Recovery

- Re-enter the command that generated this error message specifying only the valid parameters. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2716 Cmd Rej: RESETCHAR not valid with ACTION=RENAME

Commands Used: chg-tbl

If `action=rename` is requested, the following parameters must be entered: `id`, `name`, `ext`. All other parameters (including `resetchar`) are ignored or defaulted.

Recovery

Re-enter the `chg-tbl` command that generated this error message specifying only the valid parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2717 Cmd Rej: filelength not valid with ACTION=RENAME

Commands Used: chg-tbl

If `action=rename` is requested, the following parameters must be entered: `id`, `name`, `ext`. All other parameters (including `filelength`) are ignored or defaulted.

Recovery

Re-enter the `chg-tbl` command that generated this error message specifying only the valid parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2718 Cmd Rej: No match on REDIRECT parameter during retrieve

Commands Used: `rtrv-scr-sio`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-dpc`, `rtrv-scr-opc`

The `redirect` parameter was not found. If this is what was being verified, no further action is needed.

Recovery

Re-enter the command without specifying a **redirect** parameter.

E2719 Cmd Rej: REDIRECT can only be specified with ANSI point codes

Commands Used: `chg-gws-redirect`, `ent-gws-redirect`

You specified a value for the destination point code (**dpc**) parameter that was not an ANSI point code (either an ITU-I or ITU-N point code). These commands require that the DPC be an ANSI point code and have at least one route assigned to it.

Recovery

1. Display the routes in the database.
Enter the `rtrv-rte` command. The ANSI point codes that have routes assigned to them are shown in the *DPCA* field.
2. Re-enter the command that generated this error message, with a point code shown in the *DPCA* field in the output of Step 1.

E2720 Cmd Rej: 386/486 register cannot be specified

Commands Used: `ent-bp`

For 80286 processors, you cannot specify **80386** or **80486** registers.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying the correct **ca** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2721 Cmd Rej: Integer value must be less than 65535

Commands Used: `ent-bp`

For 80286 processors, integer values for registers and conditions must be less than **65535**.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying a **ca** parameter value less than **65535**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2722 Cmd Rej: BC should be less than 2000

Commands Used: `disp-mem`, `set-mem`

The value specified for the `bc` parameter must be 2000 or less.

Recovery

Re-enter the command that generated this error message specifying a value for the `bc` parameter of 2000 or less. Refer to the *Commands Manual* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2723 Cmd Rej: Password operations not allowed on a non-secure terminal

Commands Used: `chg-user`, `ent-user`, `login`

Passwords cannot be created or modified from a telnet terminal (terminal IDs 17 to 40) without the OA&M IP Security Enhancements feature turned on. This command will not execute on a telnet terminal until this feature is turned on.

Note:

Once a Permanently On feature that is controlled using a feature access key is turned on, it cannot be turned off. Features with enabled keys that are designated as On/Off features can be turned on and off with the `chg-ctrl-feat` command.

Refer to the *Database Administration Manual-System Management* and the *Commands Manual* for more information about Activating the OA&M IP Security Enhancements feature.

Recovery

Note:

Password operations (such as `login` with expired password) are not supported on a telnet terminal until the OA&M IP Security Enhancement feature is enabled and turned on, thus securing the telnet terminal.

1. Display the status of feature access key controlled features that are purchased and enabled in the system. Enter the `rtrv-ctrl-feat` command.
2. Verify that the OA&M IP Security Enhancements feature has been purchased and installed in your system.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. If you have purchased and installed the OA&M IP Security Enhancements feature, you must use the `enable-ctrl-feat` and `chg-ctrl-feat` commands first to enable and then to turn on the feature.

Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information about enabling features.

4. When the feature is turned on, you can re-enter the command specifying the parameters that generated this error message.

E2725 Cmd Rej: ANSI site id not defined

Commands Used: `act-oap-config`, `chg-dstn`, `ent-dstn`, `chg-ctrl-feat`

The EAGLE 5 ISS must have a configured ANSI point code (SID) before the MT-based IS41 SMS NP feature can be turned on.

Recovery

1. Display all site identification STP point codes and capability point codes.
Enter the `rtrv-sid` command.
2. Re-enter the command that generated this error message, and assign a valid value, acquired in Step 1, to the `pc` or `pca` parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2726 Cmd Rej: ITU-INTL site id not defined

Commands Used: `chg-sid`, `ent-dstn`

You entered this command specifying the `pci` parameter, but the international ITU site ID had not already been provisioned. The ITU-I self-ID destination point code for the STP must be defined before ITU-I destinations can be entered.

Recovery

1. Display all site identification STP point codes and capability point codes.
Enter the `rtrv-sid` command.
2. Re-enter the `chg-sid` command that generated this error message and assign a valid value, acquired in Step 1, to the `pci` parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2728 Cmd Rej: MGTT cannot be ON if any SCCP card less than 586 processor

Commands Used: `chg-feat`

All SCCP cards in the system must have at least 586 processors before you can turn on the Modified Global Title Translation (MGTT) feature.

Recovery

1. Verify that all SCCP cards in the system have at least 586 processors.
2. When all SCCP cards have at least 586 processors, turn on the MGTT feature.

Enter the command: `chg-feat:mgtt=on`

E2729 Cmd Rej: TDM does not support Global Timing Interface

Commands Used: `chg-clkopts`

The `hsclksrc=rs422` parameter must be specified.

The `hsclksrc` parameter values **t1unframed**, **t1framed**, **e1unframed**, and **e1framed** cannot be specified if either TDM is a version that does not support the Global Timing Interface feature (both TDMs must be TDM-15 or later (including E5-TDM), with the Global Timing Interface loaded).

The `hsclkll` parameter cannot be specified if either TDM is a version that does not support the Global Timing Interface feature (both TDMs must be TDM-15 or later (including E5-TDM), with the Global Timing Interface loaded).

Recovery

1. Verify that the correct version of the TDM card is installed. Enter the `rtrv-card` command.
2. Re-enter the `chg-clkopts` command, specifying the parameter values as listed above.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2730 Cmd Rej: SEAS Subsystem has not been provisioned

Commands Used: `rept-stat-seas`

The SEAS subsystem has not been provisioned and is not part of the EAGLE 5 ISS maintenance system.

Recovery

1. Turn on the SEAS feature. Enter the command: `chg-feat:seas=on`

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off.

Refer to the `chg-feat` command in the *Commands Manual* for further information.

2. Ensure that at least one OAP terminal is configured. Enter the command: `chg-trm:type=oap`
3. Re-enter the `rept-stat-seas` command.

E2731 Cmd Rej: FORCE=YES must be given to inhibit last OAP terminal

Commands Used: `inh-trm`

Only one terminal is in the in-service normal (IS-NR) state. If you disable this port, you lose OAP service.

Recovery

1. Verify the status of the OAP subsystem. Enter the `rept-stat-seas` command.
2. When you know the last OAP terminal is disabled, re-enter `inh-trm` command specifying the `force=yes` parameter.

E2732 Cmd Rej: Invalid TRM value for SEAS TDM port

Commands Used: `rmv-trm`

You either entered an invalid value for the `trm` parameter, or tried to inhibit the terminal that you entered this command from.

Recovery

Re-enter the `rmv-trm` command that generated this error message specifying the correct `trm` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2733 Cmd Rej: The T1PORT at the specified location is already equipped

Commands Used: `ent-t1`

You attempted to add a T1 interface in the database using a port on the E1/T1 MIM card (`t1port = 1` or `2`) that already has a T1 interface on the card at the specified location (`t1loc`). The port specified by the `t1port` parameter must not be already equipped with a T1 interface.

Recovery

1. Enter the `rtrv-t1` command to display the port and card location information for each T1 interface defined in the database.
Verify that there is not a T1 interface defined for the port you specified in the `ent-t1` command.
2. Do one of the following:
 - a) If a port is available without a T1 interface at the specified card location, re-enter the `ent-t1` command specifying the available port.OR

- b) If no port is available without a T1 interface at the specified card location, re-enter the `ent-t1` command specifying an available E1/T1 MIM card location and port number.

E2734 Cmd Rej: The Channel card must be on the same shelf as its T1 card

Commands Used: `ent-slk`

If the `loc` parameter is used to specify a Channel card, then the channel card must be installed on the same shelf as the T1 card that is specified by the `t1loc` parameter.

Recovery

Re-enter the `ent-slk` command specifying a T1 card that is on the same shelf with the Channel card.

E2736 Cmd Rej: All signaling links serviced by the T1 must be deactivated

Commands Used: `chg-t1`, `inh-card`

You entered a command that requires all signaling links that are serviced by one or both T1 interfaces on the specified E1/T1 MIM card to be deactivated before the command can execute.

You cannot change the value of one or more of the following parameters before you deactivate all of the signaling links serviced by the specified T1 interface: **framing**, **encode**, **ll**, or **t1tsel**.

You cannot inhibit the E1/T1 MIM card until you deactivate all signaling links that provide timeslots serviced by each T1 interface assigned to that card.

Recovery

1. Deactivate all signaling links with timeslots that are serviced by the specified T1 interface (for the `chg-t1` command), or by each defined T1 interface (for the `inh-card` command).
Enter the `dact-slk` command. Refer to the *Commands Manual* for more information.
2. Re-enter the command to change the specified T1 interface parameter value or inhibit the card.

E2737 Cmd Rej: The T1PORT at the specified location is not equipped

Commands Used: `chg-t1`, `dlt-t1`, `ent-slk`, `rtrv-t1`

The port specified by the `t1port` parameter must have already been configured with a T1 interface on the specified T1 card.

For the `ent-slk` command: The T1 interface on the card at the location specified by the `loc` parameter must be defined (see the `ent-t1` command) before a signaling link can be assigned to the port.

Recovery

1. Display all T1 interface port and card location information.
Enter the `rtrv-t1` command specifying no parameters.

2. Verify that the command specified the correct port in the **t1port** parameter and the correct card in the **loc** parameter for the T1 interface.
 - a) If the specified port or card location was incorrect, re-enter the command specifying the correct port and card location.
 - b) If the specified port and card location were correct, re-enter the command.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2738 Cmd Rej: Can not inhibit IMT bus - alternate bus is in abnormal state

Commands Used: `act-upgrade`

Cards that prevent the IMT buses from being inhibited during the upgrade cannot exist in the system.

Recovery

Note: It is strongly recommended that this command be used only in conjunction with the system Upgrade Procedure for your target release. The Upgrade Procedure provides step-by-step information on performing an upgrade.

1. Display the cards that are defined in the database. Enter the `rtrv-card` command.
2. Remove any cards that are prevent the IMT buses from being inhibited. See the *Commands Manual* for a list of invalid cards.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2739 Cmd Rej: T1 card location is unequipped

Commands Used: `chg-t1`, `dlt-t1`, `ent-slk`, `ent-t1`, `rtrv-t1`

The specified card location (**loc** parameter) must be equipped.

The T1 interface of the T1 card specified by the **t1loc** parameter must already be defined (see the `ent-t1` command) before a signaling link can be assigned to the card.

Recovery

1. Display the cards that are defined in the database.
Enter the `rtrv-card` command. Verify that the card specified in the **loc/ t1loc** parameter is the correct card.
2. If the correct card was specified in the **loc/ t1loc** parameter, re-enter the command.
3. If the **loc/ t1loc** parameter value was incorrect for the card, re-enter the command specifying the correct parameter value. Refer to the *Commands Manual* for more information.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2740 Cmd Rej: The specified LOC only supports SLTC loopbacks

Commands Used: `tst-slk`

For IPSP M2PA signaling links or IPLIMx signaling links having an `iplim2` parameter setting of `m2pa`, only the `loopback=sltc` test is allowed.

The `tst-slk:loopback=sltc` command can only be run on the following card types: `lime1`, `limt1`, or `limch`.

Recovery

Re-enter the `tst-slk` command specifying the SLTC loopback test type (`loopback=sltc`) for the E1/T1 card specified in the `loc` parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2741 Cmd Rej: All links on a channel card must use the same E1LOC or T1LOC

Commands Used: `ent-slk`

The same value must be specified for the `e1loc` or `t1loc` parameter for all provisioned links on an E1 or T1 channel card, respectively.

Recovery

Re-enter the command, specifying the same value for the `e1loc` or `t1loc` parameter for all provisioned links on the channel card. Refer to the *Commands Manual* for more information.

E2742 Cmd Rej: T1 is assigned to card

Commands Used: `dlt-card`

You cannot delete an E1/T1 MIM card used as a T1 card (card type `limt1`) that has at least one T1 interface associated with it. You must delete all T1 interfaces associated with the card before the card can be deleted.

Recovery

1. Display the list of signaling links assigned to the T1 card.
Enter the `rtrv-slk` command.
2. Deactivate all the signaling links assigned to the T1 card.
Enter the `dact-slk` command for each link.
3. Delete all signaling links assigned to the T1 card.
Enter the `dlt-slk` command for each link.

4. Display the T1 interfaces associated with the card.
Enter the `rtrv-t1` command.
5. Delete the T1 interfaces associated with the card.
Enter the `dlt-t1` command. (Refer to the *Commands Manual*).
6. Delete the card.
Re-enter the `dlt-card` command.

E2743 Cmd Rej: Card type of LIMCH does not support T1PORT = 2

Commands Used: `ent-slk`

If an E1/T1 MIM card is used as a T1 channel card, then the **t1port=1** parameter must be specified.

Recovery

Re-enter the `ent-slk` command specifying **t1port=1** for the T1 card.

E2744 Cmd Rej: T1PORT specified by T1LOC is not equipped

Commands Used: `ent-slk`

The T1 interface for the T1 port specified by **t1loc** parameter must already be defined (see the `ent-t1` command) before a signaling link can be assigned to the card.

Recovery

1. Enter the `rtrv-t1` command to display the port and card location information for T1 interfaces already defined.
2. Verify that the T1 interface is defined for the port on the T1 card.
3. If the T1 interface is defined for the specified port on the T1 card at the specified location, re-enter the command specifying the correct T1 card location (**t1loc** parameter) and port (**t1port** parameter).
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
4. If the T1 interface needs to be defined for the specified port on the T1 card at the specified location, perform the following actions:
 - a) Define the T1 interface attributes for the specified port on the T1 card in the location specified by the **t1loc** parameter.
Enter the `ent-t1` command.
 - b) Re-enter the `ent-slk` command specifying the port for the defined T1 interface on the card specified in the **t1loc** parameter.

E2746 Cmd Rej: TS value on the T1 already in use by a signaling link

Commands Used: `ent-slk`

You entered a command to assign a timeslot and signaling link to a T1 interface on an E1/T1 MIM card used as a T1 card. The timeslot that you specified in the command **ts** parameter is already assigned to a signaling link serviced by the T1 interface on the T1 card specified in the **t1loc** and **t1port** parameters.

Recovery

1. Display the T1 interface port, card location, and timeslot information.
Enter the `rtrv-t1` command.
2. Re-enter the `ent-slk` command specifying an available timeslot for the T1 interface on the T1 card specified in the **t1port** and **t1loc** parameters.

E2747 Cmd Rej: FORCE=YES is required when card is allowed

Commands Used: `dlt-ip-rte`

You entered a command to delete a static IP route entry from the Static IP Route table, and the card that has the entry assigned is **allowed**.

Recovery

1. Inhibit the card.
Enter the `inh-card` command.
2. Delete the static IP route entry for the card.
Re-enter the `dlt-ip-rte` command.
OR
Re-enter the command to delete the entry and specifying the **force=yes** parameter to delete the entry while the card is allowed.

E2748 Cmd Rej: T1 TS value must be specified in the range (1-24)

Commands Used: `ent-slk`

You entered a command to assign a signaling link to a T1 interface on an E1/T1 MIM card that is used as a T1 card and specified a timeslot (**ts**) parameter value that is larger than **24** or less than **1** for the signaling link. The timeslot parameter value assigned to a signaling link for a T1 interface cannot be greater than **24** and cannot be **0**.

Recovery

Re-enter the `ent-slk` command to assign the signaling link and timeslot to the T1 interface on the T1 card, specifying a value greater than 0 and less than or equal to 24 for the `ts` parameter.

E2749 Cmd Rej: Could not block link for testing

Commands Used: `act-cdl`, `act-lbp`, `tst-slk`

The command you entered was unsuccessful. This error message may indicate a serious failure and require technical assistance.

Recovery

Wait for a brief period, and re-enter the same command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2750 Cmd Rej: UserID already logged on (or is logging on) another terminal

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because your user ID is already logged in, or is being logged in, to the EAGLE 5 ISS at another terminal.

Recovery

1. Look at the scroll area of the terminal screen you are using for login.
The following message is displayed: **Info: UID is currently logged on (or is logging on) to terminal yy** (where *yy* is in the range 1 - 16).
2. Find the terminal at *yy* and log off your user ID at that work station.
3. Return to your work station and resume login procedures.

E2751 Cmd Rej: UserID has been revoked

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because the systems administrator has revoked your user ID.

Recovery

1. Contact your systems administrator to determine why your user ID has been revoked.
2. If the systems administrator agrees to reinstate your user ID, re-enter the `login` command.

E2752 Cmd Rej: UserID has become obsolete and cannot be used

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because the number of days that have elapsed since you last successfully logged on to the EAGLE 5 ISS with this user ID exceeds the number established for your site.

Recovery

1. Contact your systems administrator to have the last successful login date associated with your user ID reset to today's date.
2. Re-enter the `login` command.

E2753 Cmd Rej: Password does not contain enough alphabetic characters

If you are the systems administrator:

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

The requirements for the password are given in the scroll area of the logon screen. If you fail to adhere to these requirements, this error message will appear after you entered the command and received the password prompt, but entered a password that did not contain the required minimum number of alphabetic characters.

Recovery

1. Review the site password complexity requirements.
2. Display the system wide, security-related defaults. Enter the `rtrv-secu-dflt` command. The minimum number of alphabetic characters allowed is displayed in the *ALPHA* field.
3. Re-enter the command, and at the password prompt, type a new password containing the correct minimum number of alphabetic characters and that meets the other password complexity requirements for your site.

If you are not the systems administrator:

Commands Used: `act-user`, `chg-pid`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of alphabetic characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen.
Make sure that you understand all of your site's password complexity requirements.
2. Re-enter the command, and at the password prompt, type a new password that meets all the password complexity requirements for your site.

E2754 Cmd Rej: Password does not contain enough numeric characters

If you are the systems administrator:

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of numeric characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site password complexity requirements.
2. Display the system wide, security-related defaults. Enter the `rtrv-secu-dflt` command. The minimum number of numeric characters allowed is displayed in the *NUM* field.
3. Re-enter the command, and at the password prompt, type a new password containing the correct minimum number of numeric characters and that meets the other password complexity requirements for your site.

If you are not the systems administrator:

Commands Used: `act-user`, `chg-pid`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of numeric characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site's password complexity requirements.
2. Re-enter the command, and at the password prompt, type a new password that meets all the password complexity requirements for your site.

E2755 Cmd Rej: Password does not contain enough punctuation characters

If you are the system administrator:

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of punctuation characters.

Recovery

- Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site password complexity requirements.
- Display the system wide, security-related defaults. Enter the `rtrv-secu-dflt` command. The minimum number of punctuation characters allowed is displayed in the *PUNC* field.
- Re-enter the command, and at the password prompt, type a new password containing the correct minimum number of punctuation characters and that meets the other password complexity requirements for your site.

If you are not the system administrator:

Commands Used: `act-user`, `chg-pid`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of punctuation characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site's password complexity requirements.
2. Re-enter the command, and at the password prompt, type a new password that meets all the password complexity requirements for your site.

E2756 Cmd Rej: Failed reading the password table

Commands Used: `chg-pid`, `chg-user`, `ent-user`, `login`

The Password table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2757 Cmd Rej: Invalid userID/password combination

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because of one of the following: you either entered a user ID or a password not in the EAGLE 5 ISS database, or you entered a user ID-password combination not in the database. In other words, even though both the user ID and password may be in the database, to pass login verification they must be authorized for use together.

Recovery

1. Contact your systems administrator to verify your correct user ID-password combination.
2. Re-enter the `login` command specifying the user ID and password combination that the systems administrator has assigned to you.

E2758 Cmd Rej: ALPHA+NUM+PUNC must not be greater than 12

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

After you entered the command and received the password prompt, you entered a password whose total of alphabetic, numeric, and punctuation characters exceeds the system allowed maximum of 12.

Note:

Commands `ent-user` and `chg-user` are only available to the system administrator.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen.
Make sure that you understand all of your site password complexity requirements.
2. Re-enter the command, and at the password prompt, type a new password whose total of alphabetic, numeric, and punctuation characters does not exceed the system allowed maximum of 12.

E2759 Cmd Rej: Revocation of security admin userID not allowed

Commands Used: `chg-user`, `ent-user`

The user ID you have attempted to revoke is authorized for the *security administration* category (for example, systems administrator), and the EAGLE 5 ISS does not allow revocation of a user ID in that category. This safeguard ensures that at least one person always has access to the EAGLE 5 ISS.

Recovery

Perform one of the following:

1. Re-enter the command specifying another user ID.
OR
2. Re-enter the command specifying the **revoke=no** parameter.

E2760 Cmd Rej: Failed reading the security defaults table

Commands Used: `chg-pid`, `chg-secu-dflt`, `chg-user`, `ent-user`, `login`,
`rtrv-secu-dflt`

The Security Defaults table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2761 Cmd Rej: Password cannot contain userID

Commands Used: `chg-pid`, `chg-user`, `ent-user`, `login`

You specified a password that contains the user ID that must be used in conjunction with the password. The password cannot contain the string of characters that makes up the user ID to be used in conjunction with it.

Recovery

Re-enter the command specifying a different password.

E2762 Cmd Rej: Terminal temporarily disabled. Excessive LOGIN failures

Commands Used: `act-user`, `login`

You tried to login to the EAGLE 5 ISS at a terminal that is disabled because the login failure threshold level was exceeded. For security reasons, the site administrator has configured the EAGLE 5 ISS to disable terminals for a specified amount of time, when login failures exceeds a specified number.

Recovery

1. Contact the system administrator and request that the port be reset.
2. When the port has been reset, re-enter the `login` command.

E2764 Cmd Rej: Both OAM cards must be of type GPSM-II to enable TSCSYNC

Commands Used: `chg-feat`

You entered a command to turn on the Time Slot Counter synchronization (TSC) feature. The feature requires that both OAM cards must be card type GPSM-II.

Recovery

1. Verify the card type of each OAM card.
Enter the `rtrv-card` command.
2. If the OAM cards are both type GPSM-II, re-enter the command.
3. If one or both OAM cards are not type GPSM-II, you must replace one or both OAM cards with GPSM-II cards before you can turn on the TSC feature.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2765 Cmd Rej: Invalid password. Keyboard is locked. Enter UNLOCK command

Commands Used: `lock`, `unlock`

Your keyboard is locked and when you attempt to unlock it using the `unlock` command, you enter the wrong password. You must enter the password of the logged in user to unlock the keyboard.

Recovery

1. Re-enter the `unlock` command.
2. The following message will appear:
Enter LOGIN Password to unlock keyboard: Enter the correct password. If you enter an incorrect password again, the following message appears: E2765 Cmd Rej: Invalid password. Keyboard is locked.
3. Enter the `unlock` command and return to Step 1.
4. If you continue to enter the wrong password until the number of `unlock` commands entered at your keyboard exceeds the site specified maximum, the the following message appears:
E2770 Cmd Rej: Terminal temporarily disabled due to excessive UNLOCK failures The keyboard remains locked. See the system administrator to have the port reset.
5. If you enter the correct password, the following message appears in the scroll area:
Info: Keyboard unlocked. xxxxx UNLOCK commands were attempted. The keyboard is unlocked and *xxxxx* indicates the number of `unlock` commands entered at your keyboard while it was locked.

E2766 Cmd Rej: Command cannot be executed on an OAP terminal

Commands Used: `lock`

You cannot lock an OAP or SEAS terminal. The specified terminal cannot be an OAP or SEAS terminal.

Recovery

Enter another command.

E2767 Cmd Rej: Keyboard is not locked

Commands Used: `unlock`

You entered the `unlock` command at a terminal the keyboard is not locked, or you entered the `unlock` command at an OAP terminal. OAP terminals cannot be locked. The `unlock` command is valid only if the keyboard is locked.

Recovery

Enter another command.

E2768 Cmd Rej: DURAL must be specified within 0..995959 or 999999

Commands Used: `chg-trm`

You specified an unacceptable `dural` parameter value. The value for `dural` must be specified as either all digits or `999999`.

Recovery

Perform one of the following:

- Re-enter the `chg-trm` command specifying digits in the range of **0-59** for seconds, **0-59** for minutes, or **0-99** for hours.
- OR
- Re-enter the `chg-trm` command specifying the value of **999999**.

E2769 Cmd Rej: Entry already exists for this application at this IP Address

Commands Used: `ent-ftp-serv`

You entered a command for an FTP server with an application/IP address combination that already exists in the FTP Server table. An entry for the specified application ID at the specified IP address cannot already exist.

Recovery

1. Display the information for the FTP servers that are defined in the FTP Server table.
Enter the `rtrv-ftp-serv` command.
2. Re-enter the `ent-ftp-serv` command for the FTP server specifying an application/IP address combination that does not exist in the FTP Server table output from Step 1.

E2770 Cmd Rej: Terminal temporarily disabled. Excessive UNLOCK failures

Commands Used: `unlock`

Your terminal keyboard is locked and temporarily disabled because the number of failed unlock attempts exceeds the site-specified maximum. The port must not be in an unlock disabled state because of excessive successive unlock failures.

Recovery

1. Contact your system administrator to get the terminal reset.

Note:

Locked terminals can also be unlocked by issuing the `inh-trm` command, followed by the `alw-trm` command.

2. Re-enter the `unlock` command.

E2771 Cmd Rej: Both WRNLN and WRNTX must be specified

Commands Used: `chg-secu-dflt`

When you enter the `chg-secu-dflt` command, you must specify both the **warning message line number (wrnlN)** and the **warning message text (wrntX)** parameters.

Recovery

Re-enter the `chg-secu-dflt` command specifying both the `wrnln` and the `wrntx` parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2772 Cmd Rej: Entry already exists for this application at this priority

Commands Used: `chg-ftp-serv`, `ent-ftp-serv`

You entered a command to enter or change an FTP server application and priority parameter combination, and the specified application with the specified priority already exists in the FTP Server table. An entry for the specified application ID at the specified priority cannot already exist.

Recovery

1. Display the information for the FTP servers that are defined in the FTP Server table.
Enter the `rtrv-ftp-serv` command.
2. Re-enter the command for the FTP server, with an application and priority combination that does not exist in the FTP Server table output from Step 1.

E2773 Cmd Rej: FTP Server table must be accessible

Commands Used: `act-ftp-trns`, `chg-ftp-serv`, `dlt-ftp-serv`, `ent-ftp-serv`,
`rtrv-ftp-serv`

The FTP Server table must be accessible.

Recovery

Re-enter the command that generated this error message specifying correct parameter values.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2774 Cmd Rej: FTP Server table entry not found for this APP/IPADDR

Commands Used: `act-ftp-trns`, `act-upgrade`, `chg-db`, `chg-ftp-serv`, `dlt-ftp-serv`

A command was entered to change or delete the entry for an FTP server in the FTP Server table, and the entry to be changed or deleted does not exist in the table.

For the `act-ftp-trns` command, the FTP Server table must contain at least one FTP server entry that specifies the user application.

The DB application server must be provisioned (see the `ent-ftp-serv` command) before the `chg-db:action=backup:dest=server` or `chg-db:action=restore:src=server` command can be entered.

The FTP DIST application must be provisioned before the `act-upgrade` command can be entered.

Recovery

1. Enter the `rtrv-ftp-serv` command to display the current entries in the FTP Server table.
Verify the information for the FTP server entry that you want to change or delete. Verify that the database application server is provisioned correctly.
2. Re-enter the command that generated this error message specifying correct parameter values.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2775 Cmd Rej: Cannot change terminal authority while user is logged on

Commands Used: `chg-secu-trm`

You tried to change the terminal access rights for a terminal while a user is logged on to that terminal. The EAGLE 5 ISS does not allow this action.

Recovery

Re-enter the command when that user ID is logged off.

E2776 Cmd Rej: At least two ports must have security admin authority

Commands Used: `chg-secu-trm`

You entered the command for a security administration terminal, and tried to change the access rights in such a way that only one terminal would remain configured for security administration. The EAGLE 5 ISS requires that at least two terminals be configured as security administration terminals in case one of them has a hardware failure.

Recovery

1. Enter the `rtrv-secu-trm` command to display the access rights for the terminal in question.
2. Perform one of the following:
 - a) Re-enter the command specifying either the **all=yes** or the **sa=yes** parameter.
OR
 - b) Re-enter the command specifying a different port (**port**) parameter for making the original change in security access rights.
This action ensures that the two ports originally configured for security administration remain that way.

E2777 Cmd Rej: Cannot change TYPE as system requires 2 SA enabled terminals

Commands Used: `chg-trm`

You entered the command for a security administration terminal, and tried to change the **type** parameter to a non-terminal value of **printer** or **none**. The EAGLE 5 ISS requires that at least two terminals be configured as security administration terminals in case one of them has a hardware failure.

Recovery

1. Enter the `rtrv-secu-trm` command to display the access rights for the terminal in question.
2. Perform one of the following:
 - a) Re-enter the `chg-trm` command specifying a value other than **printer** or **none** for the **type** parameter,
OR
 - b) Re-enter the `chg-trm` command for a different terminal by specifying a different value for the **terminal** parameter; subsequently configuring another terminal to the non-terminal value of **printer** or **none**.

E2778 Cmd Rej: Max number of entries exist in FTP Server table

Commands Used: `ent-ftp-serv`

The maximum number of FTP servers that can be entered in the FTP Server table is **10**. You entered a command that would have created the 11th entry in the table. You must delete an existing FTP server before you can add a new one.

Recovery

1. Enter the `rtrv-ftp-serv` command to display the FTP servers currently in the FTP Server table.
2. Delete one of the existing FTP servers.
Enter the `dlt-ftp-serv` command specifying the appropriate parameters.
3. Re-enter the `ent-ftp-serv` command to add the new FTP server into the FTP Server table.

E2779 Cmd Rej: Max number of FTPSERV table entries exist for this APP

Commands Used: `ent-ftp-serv`

The FTP Server table can contain entries for a maximum of 10 FTP servers; however, the number of FTP servers supported by an application may be less than 10. Entries that are made for an application cannot be made for more than the maximum number of FTP servers supported by the application.

- The Measurements Platform Application (**app=meas**) supports 3 FTP servers.

- The FTP-based Table Retrieve Application (FTRA) (**app=user**) supports 2 FTP servers.
- The Database (**app=db**) and Software Distribution (**app=dist**) applications each support 1 FTP server.

Refer to the *Commands Manual* for detailed information about the use of the `ent-ftp-serv` command.

Recovery

1. Display the FTP servers currently entered in the FTP Server table.
Enter the `rtrv-ftp-serv` command.
2. Delete an existing FTP server for the application.
Enter the `dlt-ftp-serv` command specifying the appropriate parameters.
3. Re-enter the `ent-ftp-serv` command to add the new FTP server to the FTP Server table.

E2780 Cmd Rej: DFLTACT must be specified as FORWARD, DUPLICATE, or DUPDISC

Commands Used: `ent-gsms-opcode`

If the **mapset**, **ri** or **tt** parameter is specified, then the value specified for the **dftact** parameter must be **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the **ent-gsms-opcode** command containing the parameter **dftact=forward**, **dftact=duplicate**, or **dftact=dupdisc** parameter.

Refer to the *Commands Manual* for detailed information about the use of this command.

E2781 Cmd Rej: NDFLTACT parameter must be FORWARD, DUPLICATE, or DUPDISC

Commands Used: `chg-gsms-opcode`

If the **nmapset**, **nri**, **ntt** and **ndftact** parameters are specified, or if the **ndftact** and **pc** or **ssn** parameters are specified, then the **ndftact** parameter must have a value of **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the `chg-gsms-opcode` command specifying one of the required default action screening parameters.

E2784 Cmd Rej: Current ITU-N site id must be disabled for this assignment

Commands Used: `chg-sid`

If a 14-bit ITU-N site ID currently exists, it must be disabled before a 24-bit ITU-N site ID can be assigned. You must use the `chg-sid` command to delete the existing 14-bit ITU-N site ID before you can enter a 24-bit ITU-N point code site ID.

Recovery

1. Display the current STP site ID.
Enter the `rtrv-sid` command. Refer to the *Database Administration - SS7 Manual* and the `chg-sid` command in the *Commands Manual* for the procedure for replacing an existing site ID with a 24-bit ITU-N site ID.
2. Enter the `chg-sid:pcn=none` command.
3. Enter the `chg-sid` command specifying the 24-bit site ID as the **pcn24** parameter value.

E2785 Cmd Rej: ITU-N 24bit site id not defined

Commands Used: `chg-dstn`, `ent-dstn`

You entered the command to define a 24-bit ITU-N point code destination. The EAGLE 5 ISS site ID is not a 24-bit ITU-N point code. Use the `chg-sid` command to replace the existing site ID with a 24-bit ITU-N point code site ID before you can enter the 24-bit ITU-N point code destination.

Recovery

Display the current STP site ID. Enter the `rtrv-sid` command.

Refer to the *Database Administration - SS7 Manual* and the `chg-sid` command in the *Commands Manual* for the procedure for replacing the existing ITU-N site ID with a 24-bit ITU-N site ID.

When the existing site ID has been replaced, re-enter the command to define a 24-bit ITU-N point code destination.

E2786 Cmd Rej: One PC parameter required with ALL parameter

Commands Used: `dlt-mrn`

If the **all=yes** parameter is specified, the **pc** parameter must be specified and the **pc1/pc2/pc3/pc4** parameters cannot be specified.

Recovery

Perform one of the following steps:

- Re-enter the `dlt-mrn` command specifying the **all=yes** parameter and the **pc** parameter.

```
dlt-mrn:pc=1-1-9:all=yes:mrnset=111
```

OR

- Re-enter the `dlt-mrn` command specifying the **pc** parameter and the **pc1/pc2/pc3/pc4** parameters as applicable, without specifying the **all=yes** parameter.

```
dlt-mrn:pc=1-1-1:pc1=1-1-9:mrnset=111
```

E2787 Cmd Rej: PC network type does not match existing PC network type

Commands Used: `chg-mrn`, `chg-sccp-serv`, `ent-mrn`

A point code was specified that has a parameter value format for a network that is not compatible with the existing point codes in the network. A point code must have a network type compatible with existing point codes.

For the `chg-mrn` and `ent-mrn` commands, the **apca** and **pcn24** parameters cannot be specified for the same MRN set.

For the `chg-sccp-serv` command, the specified point code network type must match an existing point code network type.

Recovery

Re-enter the command specifying a format for the point code parameter value that is correct for the existing network type.

Refer to "Point Code Formats and Conversion" in Appendix A of the *Commands Manual* for a detailed description of point code formats, rules for specification, and examples.

E2788 Cmd Rej: Invalid Loopback selection for LIME1ATM

Commands Used: `tst-slk`

The payload and line values are not valid for the loopback parameter when the card is an E1 ATM.

Recovery

Perform one of the following actions:

- Re-enter the `tst-slk` command specifying a valid **loopback** parameter value for the E1 ATM card.
- OR
- Enter the `tst-slk` command for the **payload** or **line** loopback test for a card that is not an E1 ATM card.

E2789 Cmd Rej: NNP,NNAI,NPDD/S,NSDD/S,NGTI,RMGTT invalid if AMGTT is OFF

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

The AMGTT feature must be turned on before the **rmgtt**, **nnp**, **nnai**, **ngti**, **nsdd**, **nsds**, **npdd**, and **npds** parameters can be specified.

Recovery

1. Verify that the AMGTT feature is turned on in your system. Enter the `rtrv-ctrl-feat` command.
2. If the AMGTT feature is on, re-enter the command that generated this error message.
3. If the AMGTT feature is off, then it must be turned on before the **rmgtt**, **nnp**, **nnai**, **npdd**, **nsdd**, **nsds**, **ngti**, or **npds** parameter can be specified. Refer to the *Database Administration Manual - Global Title Translation* manual for assistance.
4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2793 Cmd Rej: Only parmCODE=0 (EOP) can have MINLEN=0

Commands Used: `chg-isupvar-attrib`

You entered a non-zero **parmcode** with **minlen=0**.

Recovery

Re-enter with non-zero **minlen** or use a different *parmCODE*.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2794 Cmd Rej: MSGCODE and parmCODE must both be DEFINED

Commands Used: `chg-isupvar-attrib`

You entered a command that resulted in either the **msgcode** or the **parmcode** having **attrib=defined** and, the other **parmcode** or **msgcode** with an **attrib** value other than **defined**. Both the **msgcode** and the **parmcode** must have **attrib=defined**.

Recovery

1. Re-enter the `chg-isupvar-attrib` command specifying the **msgcode** and **parmcode** parameter and **attrib=defined**.
2. Re-enter the `chg-isupvar-attrib` command specifying the **parmcode** parameter and **attrib=defined**.

Refer to the **chg-isupvar-attrib** *command in the Commands Manual* for information about using the parameters.

E2795 Cmd Rej: MF or MV parms must be kept in an ordered list starting at 1

Commands Used: `chg-isupvar-attrib`

A parameter cannot be changed to **notsupp** if it is a mandatory fixed (**mf**) or a mandatory variable (**mv**) parameter. Removing it will cause the list of parameters to be non-sequential.

Recovery

Parameters must be deleted from the end of the list and entered at the end of the list only. In other words, if you have parameters (0, 1, 2, 3, 4) and you want to delete parameter 2, you must first delete parameter 4 and then parameter 3.

E2796 Cmd Rej: Max number of DEFINED MSGCODEs per variant is exceeded

Commands Used: `chg-isupvar-attrib`

You entered a command that caused the maximum number (255) of **msgcode** entries per variant with **attrib=defined** to be exceeded.

The ISUP message type code (**msgcode**) parameter is used to identify a specific ISUP message that is going to have its attributes changed.

Recovery

1. Display the attributes of ISUP variant table entries.
Enter the `rtrv-isupvar-attrib` command.
2. Re-enter the **chg-isupvar-attrib** command and change (delete) an existing msgcode entry.
Refer to the **chg-isupvar-attrib** *command in the Commands Manual* and 'Changing ISUP Variant Table Entries' in the *Database Administration Manual - IP7 Secure Gateway* for information on entering **msgcode** entries.

E2797 Cmd Rej: Max number of DEFINED parmCODEs per variant is exceeded

Commands Used: `chg-isupvar-attrib`

You entered a command that caused the maximum number (255) of **parmcode** entries per variant with **attrib=defined** to be exceeded.

The **parmcode** parameter is used to identify a specific ISUP parameter that is going to have its attributes changed. When specified with the **msgcode** parameter, the **parmcode** parameter identifies a parameter within the **msgcode** parameter that is going to have its attributes changed.

Recovery

1. Display the attributes of ISUP variant table entries.
Enter the `rtrv-isupvar-attrib` command.
2. Re-enter the **chg-isupvar-attrib** command and change (delete) the value of an existng ISUP parameter.

Refer to the **chg-isupvar-attrib** command in the *Commands Manual* and 'Changing ISUP Variant Table Entries' in the *Database Administration Manual - IP7 Secure Gateway* for information on entering **parmcode** entries.

E2798 Cmd Rej:parmCODE is supported in a message, cannot be NOTDEFINED

Commands Used: `chg-isupvar-attrib`

You entered a command to change a **parmcode** to **attrib=notdefined**, and the **parmcode** is still supported in a message. The **parmcode** cannot be set to **notdefined** if it occurs in any message as **supp**.

Recovery

1. Re-enter the **chg-isupvar-attrib** command to change the **parmcode** to **attrib=notsupp**.
2. Re-enter the `chg-isupvar-attrib` command to change the **parmcode** to **attrib=notdefined**.

E2810 Cmd Rej: Two OAP terminals are already configured

Commands Used: `chg-trm`

The EAGLE 5 ISS you are configuring has two terminals configured for OAP using the **type=oap** parameter, and you attempted to configure a third OAP terminal. You can configure only two OAP terminals on an EAGLE 5 ISS.

Recovery

1. Display the values of all terminals using the `rtrv-trm` command.
In the output, under the *TYPE* column, OAP is displayed for each terminal configured for OAP.
2. If you must change either one (or both) of the terminals currently configured for OAP, inhibit the terminal you want to change using the `rmv-trm` command specifying the terminal that you want to inhibit.
For example, you might specify `rmv-trm:trm=4` to inhibit the terminal at trm 4.
3. Enter the `rept-stat-trm` command to verify that the terminal you are inhibiting is out of service (OOS-MT-DSBLD).
4. Change the terminal characteristics for the terminal you are reconfiguring using the `chg-trm` command.
For example, you might specify `chg-trm:trm=4:type=oap:all=yes`.
5. Verify the changes made.
Enter the `rtrv-trm` command specifying the trm number of the terminal you reconfigured. For example, you might specify `rtrv-trm:trm=4`.
6. When you have completed the changes to your configuration, activate the terminal that you inhibited in Step 2.

Enter the `rst-trm` command.

E2811 Cmd Rej: Comm. attributes cannot be entered for OAP terminal

Commands Used: `chg-trm`

You entered the command for an OAP terminal (`type=oap`) parameter and specified one or more of the communications attributes parameters: `baud`, `prty`, `sb`, and `fc`. For OAP ports, these parameters must be allowed to default to `baud=19200`, `prty=even`, `sb=1`, and `fc=sw`.

Recovery

Perform one of the following:

- Re-enter the `chg-trm` command but specify none of the communications attributes. For example, you might specify `chg-trm:trm=4:type=oap:all=yes`.

OR

- Re-enter the `chg-trm` command as you originally entered it, but with a value other than `oap` for the `type` parameter.

E2812 Cmd Rej: SEAS feature or LNP feature is not configured

Commands Used: `chg-oap-config`, `chg-trm`

You entered the command without specifying the required SEAS feature or LNP feature turned on. The following Recovery procedures list by command the remedial action to take if you encounter this error message.

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off.

Recovery - `chg-oap-config`

1. Verify that the SEAS feature is turned on. Enter the `rtrv-feat` command.
2. If the SEAS feature is off, turn on the SEAS feature.

Refer to the procedures in the *Database Administration Manual - SEAS* to turn on and use the SEAS feature

3. Re-enter the `chg-oap-config` command that generated this error message. Refer to the Commands Manual for valid SEAS parameter combinations.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - `chg-trm`

1. Verify the SEAS feature is turned on.

Enter the `rtrv-feat` command. Verify the LNP feature is turned on. Enter the `rtrv-ctrl-feat` command. Both features must be on.

2. If the SEAS feature is off, turn on the SEAS feature.
Refer to the procedures in the *Database Administration Manual - SEAS* to turn on and use the SEAS feature.
3. Re-enter the `chg-trm` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2813 Cmd Rej: FORCE=YES must be specified to initialize the last OAP

Commands Used: `init-oap`

You must specify the **force=yes** parameter to reset the last OSS/Application Processor (OAP).

Recovery

Re-enter the `init-oap` command that generated this error message specifying the **force=yes** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2814 Cmd Rej: GPORT invalid if APORT or IGM is enabled

Commands Used: `chg-sccp-serv`, `chg-sid`, `chg-srvsel`, `ent-srvsel`

For the `chg-sccp-serv`, `chg-srvsel`, and `ent-srvsel` commands, if the A-Port feature or the IS41 GSM Migration (IGM) feature is enabled, then a value of **gport** cannot be specified for the **serv** or **nserv** parameter.

For the `chg-sid` command, if the A-Port or IGM feature is enabled, then the **cpctype=gport** parameter cannot be specified.

Recovery

1. Determine the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. If the A-Port or IGM feature is enabled, then re-enter the command without specifying a value of **gport** for the **serv**, **nserv** or **cpctype** parameter. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2815 Cmd Rej: PC and RC must be entered as a pair

Commands Used: `chg-mrn`, `chg-sccp-serv`, `ent-mrn`

Both the point code parameter and relative code parameter must be specified together in the command. When a new point code is specified, its relative cost (**rc**) must be specified; a new point code and its relative cost must be entered together in the command.

Recovery

Re-enter the command that generated this error message specifying parameter values for both the point code and its relative cost.

E2816 Cmd Rej: PC already exists in the MRN entity set

Commands Used: `chg-mrn`, `ent-mrn`

The point code specified already exists in the MRN table. If the **pc** parameter is specified to create a new MRNGROUP, the **pc** cannot already exist in the MRN table.

Recovery

1. Display the MRN table.
Enter the `rtrv-mrn` command.
2. Re-enter the command that generated this error message specifying a point code parameter that is not in the MRN table.

E2817 Cmd Rej: MRN table is full

Commands Used: `chg-mrn`, `ent-mrn`

One or more point codes in the command will exceed the maximum number of point codes that can be entered into the MRN table (3000 if the IGTTLs feature is turned on and 6000 if the IGTTLs and FGTTLS features are turned on).

Recovery

1. Display the MRN table.
Enter the `rtrv-mrn` command.
2. Delete an existing point code from the MRN table.
Enter the `dlt-mrn` command.
3. Re-enter the command to add a point code to the MRN table.

E2818 Cmd Rej: A maximum of 8 PCs are allowed in a group

Commands Used: `chg-mrn`, `ent-mrn`

A command was entered to add one or more point codes to a group in the Mated Relay Node (MRN) table, and the point code group already contains **32** point codes. Each point code group can contain a maximum of **32** point codes.

Recovery

1. Display the MRN table.
Enter the `rtrv-mrn` command.
2. Delete one or more existing point codes from the group.
Enter the `dlt-mrn` command.
3. Re-enter the command to add one or more point codes to the group in the MRN table.

E2819 Cmd Rej: Destination disk is unformatted

Commands Used: `copy-disk`, `copy-gpl`

You entered the command, but the destination disk has not been formatted.

Recovery

1. Enter the `copy-disk` command specifying the **format=yes** parameter to format the destination disk.
2. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2820 Cmd Rej: Source location must specify the active fixed disk

Commands Used: `copy-fta`

You assigned the wrong value to the **sloc** parameter.

Recovery

1. View the active fixed disk.
Enter the `rept-stat-db` command.
2. Re-enter the `copy-fta` command specifying the correct **sloc** parameter value.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2821 Cmd Rej: Could not access removable disk

Commands Used: `act-upgrade`, `copy-disk`

During an upgrade procedure or a `copy-disk` command action, there was an unsuccessful attempt to read a removable disk. A formatted removable cartridge containing the next release is required for the upgrade. Alternatively, you may have a hardware problem with the cartridge or the removable disk.

Recovery

1. Verify the removable cartridge contains the next release.
2. Verify that the removable cartridge is inserted in the MDAL.



warning:

Leaving a removable cartridge (MO) in the MDAL for a prolonged period can damage the cartridge rendering it unreadable. Remove the cartridge from the MDAL after the command or procedure is completed.

3. Verify that the MDAL is seated properly.
4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2822 Cmd Rej: Destination location must specify the standby fixed disk

Commands Used: `copy-fta`

You specified the wrong value for the **dloc** parameter.

Recovery

1. Show the standby fixed disk.
Enter the `rept-stat-db` command.
2. Re-enter the `copy-fta` command specifying the correct **dloc** parameter value.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2823 Cmd Rej: Destination location must specify the standby removable disk

Commands Used: `copy-fta`

You specified the wrong value to the **dloc** parameter.

Recovery

Re-enter the `copy-fta` command specifying the correct **dloc** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2824 Cmd Rej: Could not access standby fixed disk

Commands Used: `copy-fta`, `copy-gpl`, `format-disk`

You may have a hardware problem.

Recovery

1. Verify the status of the standby TDM.
Enter the `rept-stat-db` command.
2. If the status of the standby TDM shows **noaccs**, call your Customer Care Center.
3. If the status of the standby TDM shows **stdby**, re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2825 Cmd Rej: Could not access removable disk

Commands Used: `copy-fta`

You may have a hardware problem. The removable drive is not available.

Recovery

Re-enter the `copy-fta` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2826 Cmd Rej: Could not access active fixed disk

Commands Used: `copy-fta`, `copy-gpl`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2828 Cmd Rej: Source and destination disks not compatible

Commands Used: `copy-fta`, `format-disk`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2829 Cmd Rej: Destination disk capacity equals 0

Commands Used: `copy-disk`, `copy-gpl`, `format-disk`

The system cannot determine the capacity of the disk being formatted.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2830 Cmd Rej: Source drive not coherent

Commands Used: `copy-disk`, `copy-gpl`, `format-disk`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2831 Cmd Rej: Current database not coherent

Commands Used: `chg-db`, `format-disk`

Resolving this issue is beyond the scope of this manual.

Recovery

Refer to the *Database Administration Manual - System Management* for detailed instructions.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2832 Cmd Rej: MTPRSI is only valid if MTPRS or ITUMTPRS feature is ON

Commands Used: `chg-stpopts`

You cannot specify the **mtprsi** parameter, if the ANSI MTP restart (MTPRS) or the ITU MTP restart (ITUMTPRS) feature is off. One or both of these features must be turned on before you can issue the **mtprsi** parameter. The **mtprsi** parameter can be specified only if either the ANSI MTP restart (MTPRS) feature or the ITU MTP restart (ITUMTPRS) feature is turned on.

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the Commands Manual for further information.

Recovery

1. Verify that the MTPRS or the ITUMTPRS features are off (**mtprs=off** or **itumtprs=off**).
Enter the `rtrv-feat` command.
2. Perform one or both of the following:
 - a) Turn on the MTPRS feature. Enter the `chg-feat:mtprs=on` command.
OR
 - b) Turn on the ITUMTPRS feature. Enter the `chg-feat:itumtprs=on` command.
3. Re-enter the `chg-stpopts` command.
OR
Re-enter the `chg-stpopts` command without specifying the **mtprsi** parameter.

E2833 Cmd Rej: MTPRSIT parameter is only valid if MTPRS feature is ON

Commands Used: `chg-stpopts`

You cannot specify the **mtprsit** parameter, if the MTP Restart (MTPRS) feature is off. The **mtprsit** parameter can be specified only if the ANSI MTP restart (MTPRS) feature is turned on.

Recovery

Re-enter the `chg-stpopts` command without specifying the **mtprsit** parameter.

OR

1. Verify that the MTPRS feature is turned on. Enter the `rtrv-feat` command.
2. If the MTPRS feature is off, turn it on. Enter the command `chg-feat:mtprs=on`

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands* Manual for further information.

3. Re-enter the `chg-stpopts` command specifying the `mtprsit` parameter.

E2834 Cmd Rej: MTPRSE parameter is only valid if MTPRS feature is ON

Commands Used: `chg-ls`, `ent-ls`

You cannot specify the `mtprse` parameter, if the ANSI MTP Restart (MTPRS) feature is off. The `mtprse` parameter can be specified only if the MTP restart feature is turned on.

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

Re-enter the command that generated this error without specifying the `mtprse` parameter.

OR

1. Verify that the MTPRS feature is turned on. Enter the `rtrv-feat` command. If the MTPRS feature is off, you must turn it on.
2. Turn on the MTPRS feature. Enter the `chg-feat:mtprs=on` command.
3. Re-enter the command that generated this error message specifying the `mtprse` parameter.

E2836 Cmd Rej: Too many nested cluster dstn entered

Commands Used: `ent-dstn`

You cannot specify the `ncai` parameter, because you have already provisioned **500** nested clusters. If the `ncai` parameter is set to **yes**, the maximum number of provisioned nested clusters is **500**.

Recovery

1. Display a list of provisioned nested clusters.
Enter the `rtrv-dstn:ncai=yes` command.
2. Display the provisioned nested clusters routing information.
Enter the `rtrv-rte` command. Here is an example of system output:

DPCN	ALIASA	ALIASI	CLLI	LSN	RC	APC
40-1-*	-----		-----		-----	ls8 10 45-1-0
40-1-*	-----		-----		-----	ls7 10 45-2-0
40-1-30	-----		-----		-----	ls3 10 45-1-30
40-1-10	-----		-----		-----	ls8 10 45-1-0
40-1-10	-----		-----		-----	ls7 10 45-2-0

The nested member (in this example, `dpc=40-1-30`) has a different routeset than its cluster (`dpc=40-1-*`).

3. Delete a cluster member route.
Enter the `dlt-rte` command specifying the DPC of a cluster member whose route you want to delete. The deletion results in the provisioned member assuming the attributes of its cluster.

4. Change a nested cluster point code to a non-nested cluster point code.
Enter the `chg-dstn` command specifying the `ncai=no` parameter.
5. Re-enter the command that generated this error message.

E2837 Cmd Rej: NCR must be enabled to enter NCAI param

Commands Used: `chg-dstn`, `ent-dstn`

You specified the `ncai` parameter, but the Nested Cluster Routing (NCR) feature is turned off, as required.

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the NCR feature is turned off, turn it on. Enter the command `chg-feat:ncr=on`.
Re-enter the command that generated this error message.
3. If the NCR feature is turned on, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2838 Cmd Rej: Unable to change Network/Cluster dstn NCAI param

Commands Used: `chg-dstn`

You specified the `ncai=no` parameter to change a provisioned nested cluster point code to a non-nested cluster point code. The EAGLE 5 ISS does not allow this action since the previously provisioned members of the cluster have a different route set.

Recovery

1. Enter the `rtrv-rte` command to view routing information for the cluster.

Here is an example of system output:

DPCN	ALIASA	ALIASI	CLLI	LSN	RC	APC
40-1-*	-----	-----	-----	-----	1s8	10 45-1-0
40-1-*	-----	-----	-----	-----	1s7	10 45-2-0
40-1-30	-----	-----	-----	-----	1s3	10 45-1-30
40-1-10	-----	-----	-----	-----	1s8	10 45-1-0
40-1-10	-----	-----	-----	-----	1s7	10 45-2-0

The nested member (in this example, `dpc=40-1-30`) has a different routeset than its cluster (`dpc=40-1-*`).

2. Enter the `dlt-rte` command specifying the DPC of a cluster member whose route you want to delete.
The deletion results in the provisioned member assuming the attributes of its cluster.
3. Enter the `chg-dstn` command specifying the `ncai=no` parameter, to change the nested cluster point code to a non-nested cluster point code.

E2839 Cmd Rej: Invalid parameter for ITU-N 24bit point code

Commands Used: `chg-appl-rtkey`, `chg-dstn`, `ent-dstn`, `ent-ls`

You specified a 24-bit ITU-N point code and a 14-bit ITU-N alias or ANSI alias point code. An ANSI point code cannot have a 24-bit ITU-N alias point code.

OR

You specified a 14-bit ITU-N point code and a 24-bit ITU-N alias or ANSI alias point code. You cannot mix 14- and 24-bit point codes. Specifying mixed point codes and alias point codes in a command is not supported.

OR

You entered the `norm` parameter in the `chg-appl-rtkey` for a 24-bit point code. The `norm` parameter is not valid for 24-bit point codes.

Refer to the *Commands Manual* for valid parameter combinations.

Recovery

Re-enter the command that generated this error message specifying one or more valid optional parameters for a 24-bit point code.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2840 Cmd Rej: Failed reading tt map table

Commands Used: `chg-ttmap`, `dlt-ttmap`, `ent-ttmap`, `rtrv-ttmap`

The TT MAP table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2841 Cmd Rej: tt map table full for LSN specified

Commands Used: `ent-ttmap`

The translation type MAP table was full for the linkset specified on the **lsn** parameter.

Recovery

1. Display a list of the current linksets and their status.
Enter the `rtrv-ttmap` command.
2. Re-enter the command that generated this error message and set the **lsn** parameter to indicate a linkset that has room to spare.
OR
3. Delete a surplus translation type map from the desired linkset.
Enter the `dlt-ttmap` command.
4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2842 Cmd Rej: tt map table is full

Commands Used: `ent-ttmap`

The translation type MAP table was full for the linkset specified on the **lsn** parameter.

Recovery

1. Display a list of the current linksets and their status.
Enter the `rtrv-ttmap` command.
2. Re-enter the command that generated this error message and set the **lsn** parameter to indicate a linkset with room to spare.
OR
3. Delete a surplus translation type map from the desired linkset.
Enter the `dlt-ttmap` command.
4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2843 Cmd Rej: TT Mapping is not provisioned for this link set

Commands Used: `chg-ttmap, dlt-ttmap`

The **lsn** parameter you entered referenced a linkset that was not defined with an accessible Linkset table.

Recovery

Re-enter the command that generated this error message specifying a different **lsn** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2844 Cmd Rej: ETT not defined for LSN and IO specified

Commands Used: `chg-ttmap`, `dlt-ttmap`, `ent-ttmap`, `rtrv-ttmap`

You failed to specify the existing translation type parameter **ett** when entering this command.

Recovery

Re-enter the command that generated this error message specifying the correct **ett** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2845 Cmd Rej: ETT already mapped for LSN and IO specified

Commands Used: `ent-ttmap`

The command you entered duplicates a previous mapping of an existing translation type.

Recovery

1. Display a list of existing translation type maps.
Enter the `rtrv-ttmap` command.
2. Modify the settings that apply to the existing translation type (**ett**) parameter you are working on.
Enter the `chg-ttmap` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2846 Cmd Rej: ETT cannot be mapped to MTT with same value

Commands Used: `ent-ttmap`

You attempted to re-map a translation point back to its existing value.

Recovery

Re-enter the `ent-ttmap` command that generated this error message specifying a different **mtt** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2847 Cmd Rej: IF IO or ETT specified, BOTH opt. parms must be specified

Commands Used: `dlt-ttmap`

If one of these two parameters is specified, the other must also be specified.

Recovery

Perform one of the following:

- Re-enter the command that generated this error message specifying the correct **io** and **ett** parameter values.

OR

- Re-enter the command that generated this error message without specifying both the **io** and the **ett** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2848 Cmd Rej: ASL8 is only valid for ANSI link sets

Commands Used: `chg-ls`, `ent-ls`

You specified the **asl8=yes** parameter with a linkset containing an adjacent point code in the X.25 domain. The **asl8=yes** parameter can only be assigned to an SS7 ANSI linkset (a linkset containing an adjacent point code in the SS7 domain).

Recovery

Re-enter the command specifying **asl8=no**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2849 Cmd Rej: PC must already exist in the MRN table

Commands Used: `chg-mrn`, `dlt-mrn`, `ent-mrn`, `rtrv-mrn`

You specified a point code parameter value that does not already exist in the Mated Relay Node (MRN) table. To change the relative cost for a point code, the point code must already exist in the MRN table.

The specified point code must exist in the MRN table before you can add, change, delete, or retrieve the table information for the point code.

Recovery

1. Display the MRN table.
Enter the `rtrv-mrn` command.

2. Re-enter the command specifying a point code that appears in the MRN table.

E2850 Cmd Rej: MTPXLxx parameters are only valid if CRMD feature is ON

Commands Used: `chg-stpopts`

You specified the `mtpxlq`, `mtpxlet`, and `mtpxlot` parameters, but the Cluster Routing and Management Diversity (CRMD) feature is off. The `mtpxlq`, `mtpxlet`, and `mtpxlot` parameters can be specified only if the Cluster Routing and Management Diversity (CRMD) feature is turned on.

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Verify whether the CRMD feature is turned on. Enter the `rtrv-feat` command. If the CRMD feature is off, turn it on.
2. If the CRMD feature is off, turn it on. Enter the `chg-feat:crmd=on` command.
3. Re-enter the `chg-stpopts` command.

OR

Re-enter the `chg-stpopts` command without specifying any of these suspect parameters.

E2851 Cmd Rej: MTPXLQ cannot exceed available space in the dstn table

Commands Used: `chg-stpopts`

The value specified for `mtpxlq` that exceeds the allowable sum of destinations provisioned as determined by adding the values of the `mtpdpcq` and `mtpxlq` parameters ($mtpdpcq + mtpxlq \leq sum$).

When the number of x-list entries (`mtpxlq`) is specified, the total number of DPCs (`mtpdpcq`) and x-list entries (`mtpxlq`) provisioned cannot exceed the space available in the Route table.

[Table 13: Routesets Feature with Maximum Values](#) shows the maximum values of `mtpdpcq`, `mtpxlq`, and their sums with a particular Routesets feature turned on.

Table 13: Routesets Feature with Maximum Values

Routesets Feature	Maximum values		
	mtpdpcq	mtpxlq	sum
None	2000	2000	2500

5000	5000	5000	5500
6000	6000	6000	6500
7000	7000	6000	7500
8000	8000	6000	8500

Recovery

1. Verify the number of **mtpdpcq** and **mtpxlq** entries currently allocated.
Enter the `rtrv-stpopts` command.
2. Display the DPCs.
Enter the `rtrv-dstn` command.
3. Calculate the maximum value for the **mtpxlq** parameter.
4. Re-enter the command specifying a value for the **mtpxlq** parameter that does not exceed the command requirements.

E2852 Cmd Rej: Failed reading STP Options table

Commands Used: `chg-clkopts`, `chg-gsmopts`, `chg-sccpopts`, `chg-ss7opts`, `chg-stpopts`, `inh-alm`, `rtrv-sccpopts`, `rtrv-stpopts`, `unhb-alm`, `rtrv-ls`, `enable-ctrl-feat`

The STP Options table is corrupt or cannot be found.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2853 Cmd Rej: ELEI is only valid for cluster destinations

Commands Used: `chg-dstn`, `ent-dstn`

You specified the **elei** parameter, and you specified a DPC that is not a cluster destination. If you specify the **elei** parameter, you must also specify a cluster destination for the **dpc/dpca/dpci/dpcn/dpcn24** parameter.

Recovery

1. Display the cluster DPCs.
Enter the `rept-stat-cluster` command.

2. Perform one of the following:
 - a) Re-enter the `chg-dstn` command you originally entered, specifying the `elei` parameter, and a cluster destination point code from the output of Step 1.
OR
 - b) Re-enter the `ent-dstn` command you originally entered, but do not use one of the cluster DPCs from Step 1.
Use the format `x-x-*` to take advantage of the wildcard (a variable value indicated by an asterisk) feature. OR
 - c) Re-enter the command you originally entered without specifying the `elei` parameter.

E2854 Cmd Rej: Alias PCs are not valid for cluster destinations

Commands Used: `chg-dstn`, `ent-dstn`

You cannot specify an alias point code (`aliasa/aliasi/aliasn/aliasn24`) parameter when you specify a cluster destination or a network destination for the (`dpc/dpca/dpci/dpcn/dpcn24`) parameter.

Recovery

1. Perform one of the following:
 - a) Display the cluster DPCs.
Enter the `rept-stat-cluster` command. OR
 - b) Display network destinations.
Enter the `rtrv-dstn` command.
2. Re-enter the command you originally entered specifying the `aliasa/aliasi/aliasn/aliasn24` parameter, and a value for the `dpc/dpca/dpci/dpcn/dpcn24` parameter that is not listed as a cluster or network destination in the output from Step 1.
OR Re-enter the command you originally entered, without specifying the `aliasa/aliasi/aliasn/aliasn24` parameter.

E2855 Cmd Rej: Cluster DPCs are only valid if the CRMD feature is ON

Commands Used: `chg-dstn`, `dlt-dstn`, `ent-dstn`, `rtrv-dstn`

You specified a cluster DPC (`ni-nc-*`), but the Cluster Routing and Management Diversity (CRMD) feature is off.

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the CRMD feature is on, re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. If the CRMD feature is off, turn it on. Enter the command: `chg-feat:crmd=on`
4. Re-enter the command that generated the error message.

E2856 Cmd Rej: ELEI is only valid if the CRMD feature is ON

Commands Used: `chg-dstn`, `ent-dstn`

You specify the exception-list exclusion indicator (**elei**) parameter, if the Cluster Routing and Management Diversity (CRMD) feature is turned off. The CRMD feature must be turned on before the **elei** parameter can be specified.

Note: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the CRMD feature is on, re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. If the CRMD feature is off, turn it on. Enter the command: `chg-feat:crmd=on`
4. Re-enter the command that generated the error message.

E2857 Cmd Rej: DPC is referenced by SCCP's MAP table

Commands Used: `dlt-dstn`

You cannot delete a destination point code that is being referenced in the Mated Application (MAP) table.

Recovery

Perform one of the following:

- Re-enter the `dlt-dstn` command that generated this error message specifying a value for the **dpc** parameter that is not in the MAP table.

OR

- Delete the point code from the MAP table and then re-enter the `dlt-dstn` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2858 Cmd Rej: SLSCI is invalid for X25 link sets

Commands Used: `chg-ls`, `ent-ls`

You cannot specify the `slsci=yes` parameter, if the linkset does not have an ANSI APC. The `slsci` parameter can only be specified for ANSI linksets. The `slsci` parameter is invalid for X25 linksets.

Recovery

Perform one of the following:

1. Re-enter the command specifying the `slsci=no` parameter.
OR
2. To use the `chg-ls` command specifying the `slsci=yes` parameter setting, first enter the `rtrv-ls` command to obtain the ACPA.
OR
3. To use the `ent-ls` command specifying the `slsci=yes` parameter setting, first enter the `rtrv-dstn` command to obtain the DCPA.

E2859 Cmd Rej: Destination address must be a full point code

Commands Used: `chg-dstn`, `chg-gta`, `chg-gtt`, `chg-ls`, `chg-x25-dstn`, `dlt-cspc`, `ent-cspc`, `ent-dstn`, `ent-gta`, `ent-gtt`, `ent-ls`, `ent-x25-dstn`, `rtrv-gta`, `rtrv-gtt`, `rtrv-x25-dstn`

You entered the command and specified a destination point code that is not a full point code. A full point code is specified using numerical values for all three segments of the point code. The adjacent point code must be a full point code.

Recovery

Re-enter the command specifying a point code using the appropriate numerical values for all three segments of the point code.

E2860 Cmd Rej: TFATCABMLQ value exceeds number of links in link set

Commands Used: `chg-ls`, `ent-ls`

You entered the command and specified a value for the TFA/TCA broadcast minimum link quality (`tfatcabmlq`) parameter, that is more than the total number of links assigned to the linkset. This value cannot exceed the total number of links assigned to the linkset.

Recovery

1. Display the linkset information.
Enter the `rtrv-ls` command. The LNKS column lists the total number of links assigned to the linkset.

2. Re-enter the command specifying a value for the **tfatcabmlq** parameter that is less than the number of links found in Step 1, and that is in the parameter's range (0, 1-16).

E2861 Cmd Rej: Site PC, CPCs and NCPCs must be full point codes

Commands Used: `chg-sid`, `ent-sid`, `rtrv-sid`

The STP destination and capability point codes can be specified only as full point codes or none. A full point code is one in which you specify numerical values for all three segments of the point code.

Recovery

Re-enter the command specifying a numerical value for all three segments of the point code.

E2862 Cmd Rej: Network/Cluster DSTNs are not supported in the X.25 domain

Commands Used: `ent-dstn`

You entered the command and specified a cluster destination point code that is in the X.25 domain. This command does not support cluster destination point codes in the X.25 domain.

Recovery

1. Display the DPCs.
Enter the `rtrv-dstn` command.
2. Re-enter the `ent-dstn` command specifying the cluster **dpc** and the **domain=ss7** parameter.
OR Re-enter the command specifying the full **dpc** and the **domain=x25** parameter.

E2863 Cmd Rej: Destination's alias PCs must be full PCs

Commands Used: `chg-dstn`, `ent-dstn`, `rtrv-dstn`

You cannot use an asterisk to designate the network indicator (**ni**), network cluster (**nc**), or network cluster member (**ncm**).

Recovery

Re-enter the command that generated this error message specifying a numerical value for all three segments of the point code using the full point code format.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2864 Cmd Rej: Address (PCx) of primary subsystem must be a full PC

Commands Used: `chg-map`, `dlt-map`, `ent-map`, `rtrv-dstn`, `rtrv-map`

You entered the command but did not specify numerical values for all three segments of the destination point code. The destination point code of the primary subsystem must be a full point code; in other words, you must specify numerical values for all three segments of the point code (*ni-nc-ncm*).

Recovery

Re-enter the command specifying numerical values for all three segments (full point code) of the destination point code for the primary subsystem and the mate subsystem.

E2865 Cmd Rej: Address (MPCx) of mate subsystem must be a full PC

Commands Used: `chg-map`, `chg-mrn`, `chg-sccp-serv`, `dlt-mrn`, `ent-map`, `ent-mrn`

The command was entered with a value for the point code (**pc**, **pc1**, **pc2**, **pc3**, **pc4**) or mate point code (**mpc**, **mpca**, **mpci**, **mpcn**, **mpcn24**) as a cluster point code (*001-011-**). The value for these parameters must be a full point code (*001-011-001*), and the point code must be in the routing table.

Note:

Point codes specified using the **pc**, **pc1**, **pc2**, **pc3** and **pc4** parameters must be full point code values.

Recovery

1. Display the mated applications.
Enter the `rtrv-map` command.
2. Display the routes in the database.
Enter the `rtrv-rte` command.
3. Re-enter the command specifying a full point code for the point code (**pc**, **pc1**, **pc2**, **pc3**, **pc4**) or mate point code (**mpc**, **mpca**, **mpci**, **mpcn**, **mpcn24**) parameters that is displayed in the `rtrv-rte` command output (as displayed in one of the following fields: *DPCA*, *DPCI*, *DPCN*, or *DPCN24*).

E2866 Cmd Rej: TFATCABMLQ is invalid for C-link sets

Commands Used: `chg-ls`

The optional TFA/TCA broadcast minimum link quality (**tfatcabmlq**) parameter cannot be changed for C linksets, because C linksets are the primary route for mated STPs.

Recovery

Re-enter the `chg-ls` command that generated this error message without specifying the **tfatcabmlq** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2867 Cmd Rej: Routes of equal cost cannot exist for X.25 destinations

Commands Used: `chg-rte`, `ent-rte`

Combined linksets are not allowed for X.25 destinations. Routes of equal cost destined for X.25 domains are not allowed.

Recovery

Re-enter the `chg-rte` command that generated this error message specifying the correct `rc` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2868 Cmd Rej: Invalid NCAI parameter has been entered

Commands Used: `chg-dstn`, `ent-dstn`

You specified the `ncai` parameter for a destination address that is not a cluster destination. The EAGLE 5 ISS does not allow this action.

Recovery

Re-enter the command without specifying the `ncai` parameter.

OR

1. View the cluster DPCs and the routeset information for all configured clusters.
Enter the `rept-stat-cluster` command. The cluster DPCs are displayed in the `DPCA` field (for example, `7-7-*` is a cluster destination).
2. Re-enter the command specifying a destination address that is a cluster destination.

E2869 Cmd Rej: NCAI param is only valid if both feat CRMD and NCR are ON

Commands Used: `ent-dstn`

You cannot specify the `ncai` parameter, if the Cluster Routing and Management Diversity (CRMD) and Nested Cluster Routing (NCR) features are turned off. The `ncai` parameter can only be specified for cluster destinations.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.

2. If both the CRMD and NCR features are turned on, re-enter the `ent-dstn` command.

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If both the CRMD or the NCR features are turned off, turn them both on.
Enter the commands: `chg-feat:crmd=on` and `chg-feat:ncr=on`
4. Re-enter the `ent-dstn` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2870 Cmd Rej: LFS feature must be ON

Commands Used: `act-lbp`, `chg-lbp`, `dlt-lbp`, `ent-lbp`, `rept-stat-lfs`, `rtrv-lbp`

The Link Fault Sectionalization (LFS) feature must be turned on to use these commands.

Recovery

1. Verify whether the LFS feature is turned on. Enter the `rtrv-feat` command. If the LFS feature is off, you must turn it on.

Note:

Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

2. Turn on the LFS feature. Enter the `chg-feat:lfs=on` command.
3. Re-enter the command that generated the error message.

E2871 Cmd Rej: NCPCx and CPCx type must match

Commands Used: `chg-sid`

The STP capability point code type (domain) must match the new STP capability point code type (domain).

Recovery

Re-enter the `chg-sid` command specifying the same capability point code type for both the `cpc/cpca/cpci/cpcn/cpcn24` parameter and the `ncpc/ncpca/ncpci/ncpcn/ncpcn24` parameter.

E2872 Cmd Rej: CPCx has not been provisioned

Commands Used: `chg-sid`

When an **npc**, **npc**, **npci**, **npcn**, or **npcn24** parameter is specified, the specified corresponding **cpc**, **cpca**, **cpci**, **cpcn**, or **cpcn24** parameter value must already exist in the database.

This command requires that, if you specify the **npc/npc/npci/npcn/npcn24** parameter, the specified corresponding **cpc/cpca/cpci/cpcn/cpcn24** parameter value must already exist in the database.

Recovery

1. Enter the `rtrv-sid` command specifying the **cpcx** parameter to verify the capability point code's existence.
2. Re-enter the `chg-sid` command without specifying the **npc/npc/npci/npcn/npcn24** parameter.
OR

Re-enter the `chg-sid` command specifying both the **npc/npc/npci/npcn/npcn24** parameter and the **cpc/cpca/cpci/cpcn/cpcn24** parameter, ensuring that you use the same point code type for both.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2873 Cmd Rej: NCPCx cannot be specified without CPCx

Commands Used: `chg-sid`

You specified the new STP capability point code (**npc/npc/npci/npcn/npcn24** parameter), but you did not specify the STP capability point code (**cpc/cpca/cpci/cpcn/cpcn24** parameter). This command requires that if you specify the **npc/npc/npci/npcn/npcn24** parameter, you must specify the **cpc/cpca/cpci/cpcn/cpcn24** parameter.

Recovery

Re-enter the `chg-sid` command specifying both the **npc/npc/npci/npcn/npcn24** parameter and the **cpc/cpca/cpci/cpcn/cpcn24** parameter, ensuring that you use the same point code type for both.

E2874 Cmd Rej: Failed reading site identification table

Commands Used: `chg-dstn`, `chg-gta`, `chg-gtt`, `chg-gws-redirect`, `chg-ls`, `chg-map`, `chg-mrn`, `chg-sccp-serv`, `chg-sid`, `dlt-map`, `ent-gta`, `ent-gtt`, `ent-gws-redirect`, `ent-ls`, `ent-map`, `ent-mrn`, `ent-spc`, `rtrv-dstn`, `rtrv-map`, `rtrv-sid`

The Site Identification table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2875 Cmd Rej: Network/Cluster cannot have alias DPC members

Commands Used: `ent-dstn`

Alias ANSI point codes cannot have the same network identifier (**ni**) and network cluster (**nc**) subfields as a cluster point code that is already defined.

Recovery

Re-enter the `ent-dstn` command that generated this error message and specify the correct **ni** and **nc** subfields.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2876 Cmd Rej: Alias DPCs cannot be a member of a Network or Cluster

Commands Used: `ent-dstn`

Alias ANSI point codes cannot have the same network identifier (**ni**) and network cluster (**nc**) subfields as a cluster point code that is already defined.

Recovery

Re-enter the `ent-dstn` command that generated this error message specifying the correct **ni** and **nc** subfields.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2877 Cmd Rej: NCAI required if cluster members have different route set

Commands Used: `ent-dstn`

You entered a command to provision a cluster point code and did not include **ncai=yes** in the command. When the collection of signaling points sharing the network identifier (**ni**) and network cluster (**nc**) code have different route sets, you must specify **ncai=yes** in the command.

Recovery

Re-enter the `ent-dstn` command that generated this error message and include the **ncai=yes** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2878 Cmd Rej: Ordered routes cannot be assigned to cluster members

Commands Used: `ent-rte`

A route is already provisioned for *ni-nc-xxx* (where *xxx* is *** or *pc*). You cannot enter a route on a linkset different than the one already provisioned, unless the specified destination address's NCAI (nested cluster allowed indicator) is set to **yes**.

Recovery

1. Change the NCAI to **yes**.

Enter the `chg-dstn:dpc=ni-nc-*:ncai=yes` command.

2. Re-enter the `ent-rte` command that generated this error message.

OR

3. Verify that the DPC you specified is a member of a cluster.

Enter the `rept-stat-cluster` command. This command displays routeset information for all configured clusters. The cluster DPCs are displayed in the *DPCA* field. (For example, if *7-7-** exists, then *7-7-3* cannot be assigned to a route because it is a cluster member).

4. Re-enter the `ent-rte` command that generated this error message specifying a DPC that is not a member of a provisioned cluster.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2879 Cmd Rej: Ordered routes cannot be deleted from cluster members

Commands Used: `dlt-rte`

If the specified destination address is a full point code address (*ni-nc-ncm*) and is a member of a provisioned cluster (*ni-nc-**), then whether the ordered routes can be deleted is determined by the destination address's nested cluster allowed indicator. This value is set with the **ncai** parameter of the `ent/chg-dstn` commands:

- If the **ncai=no** parameter is specified, then the ordered route cannot be deleted, and the specified ordered route is deleted for each signaling point code having the same network identifier (NI) and network cluster (NC) codes.
- If the **ncai=yes** parameter is specified, then the destination address is a member of a provisioned nested cluster where the ordered routes of the provisioned members can be deleted. Deletion of the ordered routes of a provisioned member results in the provisioned member assuming the attributes of its cluster. Deletion of the cluster route does not delete the ordered route of the provisioned member.

Recovery

1. Change the NCAI to **yes**. Enter the `chg-dstn:dpc=ni-nc-*:ncai=yes` command.

2. Re-enter the command that generated this error message.

OR

3. Verify that the specified DPC is a member of a cluster. Enter the `rept-stat-cluster` command. The cluster DPCs are displayed in the `DPCA` field.
4. Re-enter the command that generated this error message specifying a DPC that is not a member of a provisioned cluster.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2880 Cmd Rej: MTPDPCQ cannot exceed available space in the dstn table

Commands Used: `chg-stpopts`

The value specified for the `mtpdpcq` parameter exceeds the allowable sum of destinations provisioned as determined by adding the values of the `mtpdpcq` and `mtpxlq` parameters (`mtpdpcq + mtpxlq <= sum`).

When the number of DPCs (`mtpdpcq`) is specified, the total number of DPCs (`mtpdpcq`) and x-list entries (`mtpxlq`) provisioned cannot exceed the space available in the Route table.

[Table 13: Routesets Feature with Maximum Values](#) shows the maximum values of `mtpdpcq`, `mtpxlq`, and their sums with a particular Routesets Feature turned on.

Recovery

1. Display the number of `mtpdpcq` and `mtpxlq` entries currently allocated.
Enter the `rtrv-stpopts` command.
2. Display the DPCs.
Enter the `rtrv-dstn` command.
3. Calculate the maximum value for the `mtpdpcq` parameter.
4. Re-enter the `chg-stpopts` command specifying a value for the `mtpdpcq` parameter that does not exceed the command requirements.

E2881 Cmd Rej: MTPDPCQ cannot be increased while x-list storage is full

Commands Used: `chg-stpopts`

You cannot increase the number of DPCs configured, using the `mtpdpcq` parameter, if space allocated for maintaining x-list entries (`mtpxlq` parameter) becomes full. The values of the `mtpxlq` and `mtpdpcq` parameters are interdependent; that is, if you want to increase the number of DPCs that can be configured, you must decrease the number of x-list entries that the STP is to maintain. Conversely, if you increase the number of x-list entries that the STP maintains, you must decrease the number of DPCs that can be provisioned.

Recovery

Re-enter the `chg-stpopts` command that generated this error message to eliminate the possibility that this error message was generated by a data input error.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2882 Cmd Rej: MSAR=ONLY must be specified exclusively

Commands Used: `rtrv-dstn`

You cannot specify a value of **only** for the Memory Space Accounting Report (**msar=only**) parameter along with other parameters. If the **msar=only** parameter is specified, no other parameters can be specified in the command.

Recovery

Perform one of the following:

- Re-enter the `rtrv-dstn` command specifying the **msar=only** parameter by itself.
OR
- Re-enter the `rtrv-dstn` command specifying a value other than **only** for the **msar** parameter.

E2883 Cmd Rej: Maximum number of CPCs defined (96)

Commands Used: `chg-sid`

The maximum number of capability point codes you can specify is **96**. You specified a capability point code (**cpc**) that would have been the 97th entry in the database. You must first delete an existing CPC before you can add a new one.

Recovery

1. Display the CPCs currently configured in the EAGLE 5 ISS database.
Enter the `rtrv-sid` command.
2. Delete one of the existing CPCs.
Enter the `chg-sid:cpc=xxx-xxx-xxx:ncpc=none` command, where `xxx-xxx-xxx` is a point code you select from the output in Step 1.

E2884 Cmd Rej: PCx, NPCx, CPCx or NCPCx must not be equal

Commands Used: `chg-sid`

If a **pc**, **pca**, **pci**, **pcn**, or **pcn24** parameter, a **cpc**, **cpca**, **cpci**, **cpn**, or **cpn24** parameter, and an **npci**, **npcn**, **npc**, **npca**, **npci**, **npcn**, or **npcn24** parameter are specified, their values must be different.

Recovery

Re-enter the `chg-sid` command specifying a different value for each of the **pc/pca/pci/pcn/pcn24**, **npci/npcn**, **cpc/cpca/cpci/cpn/cpn24**, and **npc/npca/npci/npcn/npcn24** parameters.

E2885 Cmd Rej: Ordered routes cannot be changed for cluster members

Commands Used: `chg-rte`

You specified a destination address that is a full point code address (*ni-nc-ncm*) and is a member of a provisioned cluster (*ni-nc-**), but the specified destination address's Nested Cluster Allowed Indicator (NCAI) is set to **no**.

Whether the attributes of the ordered routes assigned to the cluster can be changed is determined by the destination address's NCAI. The NCAI (**ncai=yes/no**) is set with the **ncai** parameter of the `ent/chg-dstn` commands.

If the NCAI is set to **no**, then the attributes of the ordered routes assigned to the cluster cannot be changed.

If the NCAI is set to **yes**, then the specified destination address is a member of a provisioned nested cluster where the attributes of the ordered routes assigned to the cluster can be changed.

Perform one of the procedures in the following Recovery procedures.

Recovery - Change ordered route attributes for the cluster.

1. Verify that the DPC you specified is a member of a cluster. Enter the `rept-stat-cluster` command.

This command displays routeset information for all configured clusters and the cluster DPCs are displayed in the *DPCA* field.

2. Re-enter the `chg-rte` command specifying the cluster DPC (displayed in the *DPCA* field) of the cluster member point code you entered originally.

Recovery - Change ordered route attributes for a different DPC.

Re-enter the `chg-rte` command specifying a DPC that is not a member of a cluster displayed in the *DPCA* field.

Recovery - Change ordered route attributes for a DPC assigned to the cluster.

Change the **ncai** setting. Enter the `chg-dstn:dpc=ni-nc-*:ncai=yes` command. Re-enter the `chg-rte` command that generated this error message.

E2886 Cmd Rej: DSTN address must be a full, network or cluster PC

Commands Used: `chg-dstn`, `dact-rstst`, `dbg-ddb`, `dlt-dstn`, `ent-dstn`, `rept-stat-cluster`, `rept-stat-dstn`, `rst-dstn`

The value specified for the **dpc** parameter must specify a full point code, a network, or a cluster point code.

Recovery - `rept-stat-dstn`

A point code was specified in the format *ni-nc-*** or *ni-nc-**** and the **mode=full** parameter. The **mode=full** parameter requests detailed status information for a single point code, and specifying point

codes in the format *ni-nc-*** or *ni-nc-**** requests summary status for a range of point codes; therefore, the two are not compatible, and cannot be specified in the same command.

Perform one of the following:

1. Re-enter the `rept-stat-dstn` command without specifying the **mode=full** parameter.
Use a point code in the format *ni-nc-*** or *ni-nc-****. Here is an example:
`rept-stat-dstn:dpc=1-1-**` OR
2. Re-enter the `rept-stat-dstn` command specifying the **mode=full** parameter and a destination point code.
Here is an example: `rept-stat-dstn:dpc=1-1-1:mode=full`

Recovery - `chg-dstn`, `dact-rstst`, `dlt-dstn`, `ent-dstn`

A point code was specified in the format *ni-nc-*** or *ni-nc-****. These formats can only be entered on the `rtrv` or `rept-stat` command to simplify retrieving and reporting ranges of destination point codes.

Re-enter the command specifying a single destination point code.

Example: `chg-dstn:dpc=111-222-111:clli=rlghncxa01a)`

Recovery - `dbg-ddb`, `rept-stat-cluster`, `rst-dstn`

You specified a destination address (**dpc** or **dpca**) that was not a full point code, a cluster point code, a network address, or a permissible asterisk combination.

Re-enter the command specifying a valid destination point code.

Refer to the *Commands Manual* for information regarding valid destination point code formats.

E2887 Cmd Rej: Failed accessing maintenance data

Commands Used: `chg-appl-rtkey`, `chg-stpopts`, `dlt-appl-rtkey`, `rept-stat-rtkey`, `rtrv-appl-rtkey`

The cluster exception-list (x-list) maintenance data is corrupt or cannot be found by the system. The maintenance data must be accessible.

Recovery

Re-enter the command that generated this error message.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2888 Cmd Rej: MTPDPCQ cannot be less than no. of destinations provisioned

Commands Used: `chg-stpopts`, `ent-stpopts`

The value for the **mtpdpcq** parameter cannot be less than the number of DPCs provisioned. This parameter is used to specify the **maximum** number of DPCs that you can configure in the database.

Recovery

1. Display the number of DPCs configured in the EAGLE 5 ISS database.
Enter the `rtrv-dstn` command. If you have the Cluster Routing and Management Diversity (CRMD) feature turned on, the total number of DPCs is displayed in the *TOTAL DPC(s)* field. If you do not have the CRMD feature turned **on**, the number is the first number (in bold for this example) in parentheses as displayed in the following example of output: Destination table is (678 of 2000) 34% full
2. Re-enter the command specifying a value for the **mtpdpcq** parameter that is greater than or equal to, the number of DPCs displayed in the output of Step 1.

E2889 Cmd Rej: No user associated with OAP terminal

Commands Used: `canc-user`, `chg-pid`, `logout`, `rtrv-user`

You specified OAP flow-through, but because OAP requires no login, there is no user to cancel, no password to change, no user privileges to retrieve, no logout necessary. The `logout` command cannot be issued from a SEAS terminal.

Recovery

These commands cannot be entered from a OAP terminal. You must be logged in to an EAGLE 5 ISS terminal to use these commands.

E2890 Cmd Rej: DPC must be specified as wildcard when used with STAT

Commands Used: `rept-stat-dstn`

You specified both the **dpc** and the **stat** parameters, but you did not specify the point code in wild card format (*ni-nc-*** or *ni-nc-****).

A 'wildcard value' is an expression meaning the value is a variable indicated by an asterisk.

Refer to "Point Code Formats and Conversion" in Appendix A of the *Commands Manual* for a detailed description of point code formats, rules for specification, and examples.

Recovery

Perform one of the following:

- Re-enter the `rept-stat-dstn` command specifying either the **dpc** parameter or the **stat** parameter, but not both.

OR

- Re-enter the `rept-stat-dstn` command specifying both the **dpc** and the **stat** parameters, and the point code in wild card format (*ni-nc-*** or *ni-nc-****).

E2891 Cmd Rej: Failed reading Link Fault Sectionalization table

Commands Used: `act-lbp`, `chg-lbp`, `dlt-lbp`, `ent-lbp`, `rtrv-lbp`

The Link Fault Sectionalization table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2892 Cmd Rej: LOC is not LFS capable

Commands Used: `act-lbp`, `chg-lbp`, `dact-lbp`, `dlt-lbp`, `ent-lbp`, `rept-stat-lfs`, `rtrv-lbp`

You entered the command and identified a card location that does not meet the command criteria. The card location (**loc**) must identify a provisioned **limds0**, **limt1**, or **limch** (which is associated with a **limt1**) card configured with either an **ss7ansi** or a **ccs7itu** application.

Recovery

1. Display information about the card in the location you have identified.
Enter the `rtrv-card` command. The output of this command shows the card location, the card type, the application the card is running, the linkset name, and the signaling link code for the LIM cards.
2. Use the output from Step 1 to select a card location that is provisioned as a **limds0**, **limt1**, or **limch** card configured with either an **ss7ansi** or a **ccs7itu** application.
3. Re-enter the command specifying the card location selected in Step 2 as the **loc** parameter value.

E2893 Cmd Rej: REP must be greater than prev. and less than subsequent REP

Commands Used: `chg-lbp`, `ent-lbp`

You entered the command and specified a **rep** parameter value for this remote link element (RLE) that does not meet the command criteria. The **rep** parameter value you specify for an RLE must be **greater** than the **rep** parameter value of any previously defined RLE of the same type and **less** than the **rep** parameter value of any subsequently defined RLE of that type.

Recovery

1. Display all the loopback points on the signaling links for this STP.
Enter the `rtrv-lbp` command. The loopback point IDs for each signaling link are displayed in numerical order in the *LBP* field. The RLEs for each LBP are listed in the *RLE* field, and the repetition

counts for the LBPs are listed in the *REP* field of the output. Refer to the output examples for the *rtrv-lbp* command in the *Commands Manual*.

2. Use the output from Step 1 to determine a value for the **rep** parameter that meets the command criteria.
3. Re-enter the command specifying the **rep** parameter with the value you selected in Step 2.

E2894 Cmd Rej: LBP has already been provisioned

Commands Used: *ent-lbp*

You cannot configure a loopback point ID that was used in a previous configuration. The specified loopback point cannot have been previously defined.

Recovery

1. Display all the loopback points on the signaling links for this STP.
Enter the *rtrv-lbp* command. The loopback point IDs for each signaling link are displayed in numerical order in the *LBP* field. Refer to the output examples for the *rtrv-lbp* command in the *Commands Manual*.
2. Re-enter the *ent-lbp* command specifying for the **lbp** parameter a loopback point ID value that does not appear in the output from Step 1.

E2895 Cmd Rej: REP must be zero if link element to be tested is NEI

Commands Used: *act-lbp*, *chg-lbp*, *ent-lbp*

You entered the command and specified the **rle=nei** parameter, but you did not specify the **rep=0** parameter. If the remote link element (**rle**) parameter to be tested is a network element interface (**nei**) value, you must specify the repetition count (**rep**) parameter as 0.

Recovery

Perform one of the following:

- Re-enter the command as you entered it originally specifying the **rep=0** parameter.
OR
- Re-enter the command specifying the **rep** parameter with a value other than 0, and the **rle** parameter with a range value other than **nei**.

E2896 Cmd Rej: DS0 and NEI link elements do not support non-latching tests

Commands Used: *act-lbp*, *chg-lbp*, *ent-lbp*

You entered the command and specified either the **rle=ds0** or the **rle=nei** parameter, and you specified the **lfst=nl** parameter instead of the **lfst=llt** parameter. The DS0 and NEI link elements cannot be used for non-latching loopback (NLT) tests.

Recovery

Perform one of the following actions:

- Re-enter the command specifying either the **rle=ds0** or the **rle=nei** parameter and the **lfst=llt** parameter.
- OR
- Re-enter the command specifying either **ocu**, **csu**, and **dsu** for the **rle** parameter, and the **lfst=nl** parameter.

E2897 Cmd Rej: REP is only valid if LFST is defined as LLT

Commands Used: `act-lbp`, `chg-lbp`, `ent-lbp`

You entered the command and specified the **rep** parameter, but you did not specify the **lfst=llt** parameter. You can specify the number of link elements to be tested only if you choose the latching loopback test.

Recovery

Perform one of the following:

- Re-enter the command specifying the **rep** parameter and the **lfst=llt** parameter.
- OR
- Re-enter the command without specifying the **rep** parameter.

E2898 Cmd Rej: LBP cannot exceed previously defined NEI LBP value

Commands Used: `ent-lbp`

You cannot specify a value for the **lbp** parameter that exceeds the **lbp** parameter value previously defined for a loopback point with **rle=nei** specified. The Network Element Interface (NEI), specified by the **rle=nei** parameter, identifies the last remote link element on the signaling link; therefore, you cannot define an element whose relative position is beyond that of the NEI.

Recovery

1. Display all the loopback points on the signaling links for this STP.
Enter the `rtv-lbp` command. The loopback point IDs for each signaling link are displayed in numerical order in the *LBP* field. The NEI LBPs are listed last and are identified by NEI in the *RLE* field of the output. Refer to the output examples for the `rtv-lbp` command in the *Commands Manual*.
2. Locate the LBP ID value for the NEI LBP on the signaling link being configured.

3. Re-enter the `ent-lbp` command specifying a value for the **lbp** parameter that is less than than the LBP ID value found in Step 2.

E2899 Cmd Rej: NEI LBP has already been defined for the CCS7 link

Commands Used: `chg-lbp`, `ent-lbp`

You entered the command to configure a Network Element Interface (NEI) Remote Link Element (RLE) on a signaling link that already has an NEI LBP configured.

Recovery

1. Display all the loopback points on the signaling links for this STP.
Enter the `rtrv-lbp` command. Verify that the link has an NEI LBP configured. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. The NEI LBPs are listed last and are identified by NEI in the RLE field of the output. Refer to the output examples for the `rtrv-lbp` command in the *Commands Manual*.
2. Re-enter the command you entered originally specifying a value other than **nei** for the **rle** parameter.

E2900 Cmd Rej: NEI LBP must be defined as the last link element

Commands Used: `chg-lbp`, `ent-lbp`

You entered the command and tried to configure a network element interface (NEI) remote link element (RLE), whose loopback point (LBP) ID does not define the last element on the link. For example, you might have entered `ent-lbp:loc=1101:port=a:lbp=2:rle=nei:lfst=1lt`. If the NEI loopback point 2, at card location **1101 port a**, is not the **last** element on that signaling link, you receive error message E2900.

Recovery

1. Display all the loopback points on the signaling links for this STP.
Enter the `rtrv-lbp` command. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. Refer to the output examples for the `rtrv-lbp` command in the *Commands Manual*.
2. Using the output from Step 1, determine the loopback point ID of the last element on the signaling link in question.
3. Re-enter the command you entered originally specifying a value for the **lbp** parameter that is greater than the last loopback point ID in the output from Step 1.
OR
4. Re-enter the command you entered originally specifying a value other than **nei** for the **rle** parameter.

E2901 Cmd Rej: LBP must have been previously defined in database

Commands Used: act-lbp, chg-lbp, dlt-lbp

You cannot change or delete a loopback point that does not already exist in the database.

Recovery

1. Display the attributes for all the loopback points for SS7 links assigned to the STP.
Enter the `rtrv-lbp` command. The loopback points are listed in the *LBP* field of the output.
2. Using the output from Step 1, select the loopback point you want to change, delete, or activate.
3. Re-enter the command specifying the loopback point you selected in Step 2.

E2902 Cmd Rej: LBP or ALL parameter must be specified exclusively

Commands Used: dlt-lbp

You entered the `dlt-lbp` command and specified both the **lbp** and the **all** parameters. This combination is not allowed. The **all** parameter deletes all loopback points for the specified signaling link, whereas the **lbp** parameter deletes a specific loopback point.

Recovery

Re-enter the `dlt-lbp` command specifying either the **lbp** parameter (with a specific loopback point) or the **all** parameter, but not both.

E2903 Cmd Rej: LOC and PORT parameter combination must be specified

Commands Used: inh-alm, rept-stat-cdl, rept-stat-lfs, rept-stat-tstslk, rtrv-el, rtrv-lbp, rtrv-tl, unhb-alm

[Table 14: Conditions that Generate Error Message E2903](#) describes the conditions that may generate this error message.

Table 14: Conditions that Generate Error Message E2903

Command	Condition
inh-alm, unhb-alm	When the dev=slk parameter is specified, the loc parameter and the link parameter must be specified.
rept-stat-cdl, rept-stat-lfs, rept-stat-tstslk	If the port parameter is specified, then the loc parameter must be specified. Re-enter the

Command	Condition
	command with both loc and port parameters or without the port parameter.
rtrv-lbp	If the lbp parameter is specified, then the loc and port parameters must be specified to display the attributes for a specific loopback point (lbp parameter) that lies along an SS7 signaling link/.
rtrv-el	The loc and e1port parameters must be specified together in the command.
rtrv-t1	The loc and t1port parameters must be specified together in the command.

Recovery

Re-enter the command that generated this error message specifying the **loc** and **port** parameters.

E2904 Cmd Rej: TFATFRPR must be in increments of 100 msec

Commands Used: chg-stpopts

You specified a value for the **tfatfrpr** parameter that is not in increments of 100 ms (milliseconds). A value for the **tfatfrpr** parameter must be specified in increments of 100 milliseconds (0.10 seconds).

Recovery

1. Display the current values of the EAGLE 5 ISS's node-level processing option indicators, maintained in the STP's options table.
Enter the `rtrv-stpopts` command. The TRATFRPR field displays the value you entered for the **tfatfrpr** parameter for the `chg-stpopts` command. The value must be an increment of 100 ms.
2. Re-enter the `chg-stpopts` command specifying a value that is an increment of 100 ms.

E2905 Cmd Rej: LFS command in progress

Commands Used: act-lbp, dact-lbp, tst-slk

A command is already in progress. The previously entered command for a link test must be accepted before another link test command can be entered.

Recovery

1. Display the status of the currently active LFS tests.
Enter the `rept-stat-lfs` command.

2. Re-enter the command that generated this error after the previously issued `act-lbp` or `dact-lbp` or `tst-slk` command is accepted.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2906 Cmd Rej: LFS test is completing, cannot be canceled

Commands Used: `dact-lbp`

A previously issued `act-lbp` command is about to complete. A new `dact-lbp` command cannot be accepted until the `act-lbp` command completes.

Recovery

1. Display the status of the currently active LFS tests.
Enter the `rept-stat-lfs` command.
2. Re-enter the `dact-lbp` command after permitting the currently running test enough time to complete.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2907 Cmd Rej: No active LFS Test on the specified link

Commands Used: `dact-lbp`

There is no active LFS Test on the specified link. A `dact-lbp` command has been issued on a link other than the one for which the test is active.

Recovery

1. Display the status of the currently active LFS tests.
Enter the `rept-stat-lfs` command.
2. Re-enter the `dact-lbp` command, specifying a link with an active LFS test.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2908 Cmd Rej: LOOPBACK param needed for FELINE or FEPAYLOAD exclusively

Commands Used: `tst-tl`

If the `action=stop` parameter is specified, a value of `feline` or `fepayload` must be specified for the `loopback` parameter.

Recovery

Re-enter the command, specifying a value of **feline** or **fepayload** for the **loopback** parameter. Refer to the *Commands Manual* for more information.

E2909 Cmd Rej: LFS data is only valid for OCTET and ALTERNATE patterns

Commands Used: `act-lbp`

You can specify the **data** parameter only if you specify the **pattern=octet** parameter or **pattern=alternate** parameter.

Recovery

Re-enter the `act-lbp` command that generated this error message specifying the correct **pattern** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2910 Cmd Rej: RLE and LFST must be specified when database is not used

Commands Used: `act-lbp`

If you specify any one of the **rle**, **rep**, **lfst**, or **orcli** parameters, the database is not used to look up their values; therefore, you must specify the **lfst** and **rle** parameters.

Recovery

Re-enter the `act-lbp` command specifying the correct **rle** and **lfst** parameter values.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2911 Cmd Rej: OCTET and ALTERNATE are not valid for non-latching test

Commands Used: `act-lbp`

You can specify the **pattern=octet** or **pattern=alternate** parameter only for latching tests.

Recovery

Re-enter the `act-lbp` command that generated this error message without specifying the **pattern** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2912 Cmd Rej: LOC must be LIMDS0 or LIMOCU with SS7ANSI or CCS7ITU

Commands Used: `act-lbp`

The card location (**loc**) parameter must identify a provisioned **limds0** card configured with either an **ss7ansi** or **ccs7itu** application.

Recovery

Re-enter the `act-lbp` command that generated this error message specifying the correct **loc** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2913 Cmd Rej: STOP Loopback type must match active loopback

Commands Used: `tst-t1`

If the **action=stop** parameter is specified, and a value of **feline** or **fepayload** is specified for the **loopback** parameter, then there cannot be an active loopback for the T1 span, or the active loopback must be the one specified in the `tst-t1:action=stop` command.

Recovery

Re-enter the command, and specify the same active loopback as specified in the `tst-t1:action=stop` command.

OR

Re-enter the command and specify different values for the required parameters. Refer to the *Commands Manual* for more information.

E2914 Cmd Rej: REP parameter must be specified

Commands Used: `chg-lbp`, `ent-lbp`

You did not specify the **rep** parameter, accepting instead the default value, and that value is incongruous with **rep** parameter values of previously defined loopback points.

For example, suppose the previously defined values for the **rep** parameter were **1** and **2**. The EAGLE 5 ISS defaults to **2** because no integer exists between **1** and **2**. The sequence of **rep** parameter values would now be **1, 2, 2** but the two same values cause the EAGLE 5 ISS to generate error message E2914.

Recovery

1. Enter the `rtrv-lbp` command and look at the **REP** field values for the **rep** parameter.
2. Select a new **rep** parameter value based on these previously entered values.

3. Re-enter the original command (`chg-lbp` or `ent-lbp`), specifying the new value for the **rep** parameter.

E2915 Cmd Rej: MTPT10ALT cannot be less than level-3 timer T10

Commands Used: `chg-stpopts`

You entered this command specifying the **mtp10alt** parameter set to a value that gave it a priority that was too high, since this timer by definition schedules tests on low-priority routes.

Recovery

1. Acquire the current descriptive parameters.
Enter the `rtrv-stpopts` command.
2. Re-enter the `chg-stpopts` command that generated this error message, and assign a valid value, acquired in Step 1, to the **mtp10alt** parameter.

E2916 Cmd Rej: Link must not be active to execute command

Commands Used: `act-cdl`, `act-lbp`, `dact-cdl`, `dact-lbp`, `tst-slk`

The signaling link that is used for LFS (Link Fault Sectionalization) testing cannot be active.

Recovery

1. Deactivate the signaling link with the `dact-slk` command.
2. Re-enter the original command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2917 Cmd Rej: Link must be SS7 to execute command

Commands Used: `rept-stat-tstslk`, `tst-slk`

The specified signaling link must be an SS7 signaling link.

Recovery

Re-enter the command that generated this error message to rule out the possibility that it was the result of a keying error.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2918 Cmd Rej: Link must be SS7 to display Level 2 stats

Commands Used: `rept-stat-slk`

The signaling link must be an SS7 signaling link to display level 2 statistics.

Recovery

Re-enter the `rept-stat-slk` command that generated this error message without specifying the `l2stats` parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2919 Cmd Rej: LOC and PORT must be specified to display Level2 stats

Commands Used: `rept-stat-slk`

You cannot display Level2 stats without specifying values for both the `loc` and `port` parameters.

Recovery

Re-enter the `rept-stat-slk` command specifying values for both the `loc` and `port` parameters.

E2920 Cmd Rej: Loopback in progress

Commands Used: `act-lbp`

You entered this command while another `act-lbp` command was in progress. Only one loopback test can be performed at a time.

Recovery

1. Wait for the active loopback test to complete.
2. Re-enter the additional `act-lbp` command.

E2921 Cmd Rej: LFS must not be running on requested link

Commands Used: `act-cdl`, `tst-slk`

This command cannot be entered if the LFS test is running on the specified link.

Recovery

Perform one of the following:

- Re-enter the command that generated this error message after giving the link time to complete any activities in progress.

OR

- Re-enter the command that generated this error message but specify a different link.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2922: Cmd Rej: Link must be SAAL to execute command

Commands Used: `act-cdl`, `tst-slk`

You specified a **loopback** parameter valid only for ATM high-speed signaling links.

Recovery

1. Display the card's configuration, using the `rtrv-card` command specifying the card location used in the command that generated this error message.
The card's type is shown in the *TYPE* field of the output.
2. If the card's type is not **limatm** or **lime1atm**, re-enter the command, using a parameter valid for low-speed signaling links.

E2923 Cmd Rej: Maximum number of link tests already in progress

Commands Used: `act-lbp`, `dact-cdl`, `dact-lbp`, `tst-slk`

Maximum number of allowed duration based system tests are in progress. This command cannot be entered if the maximum number of LFS or link tests are already running in the system. At least one active test must complete before the command can be entered again.

`act-lbp`, `tst-slk`

At least one active test must complete before re-issuing another `act-lbp` command.

`dact-cdl`

A command-driven loopback is not found, assumed to be a remote loopback. The maximum number of tests is running; therefore, the `dact-cdl` command is not allowed for the remote loopback. At least one active test must complete before supporting the `dact-cdl` command.

`dact-lbp`

A locally initiated loopback is not found, and is assumed to be a remote loopback. The maximum number of tests is currently running; therefore, the `dact-lbp` command is not allowed for the remote loopback. At least one active test must complete before you re-enter the `dact-lbp` command.

Recovery

- Enter the `rept-stat-lfs` or `rept-stat-tstslk` command to display the status of the currently active tests.

- Re-enter the command that generated this error message after either permitting one of the currently running tests sufficient time to complete, or stopping an active test with the `dact-lbp` or `tst-slk:action=stop` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2924 Cmd Rej: LOC has maximum number of LFS Tests already in progress

Commands Used: `act-lbp`

The maximum number of allowed tests is already in progress on this LOC. At least one active LFS test on this LOC must be completed before another `act-lbp` command can be performed for this card location.

Recovery

1. Enter the `rept-stat-lfs` command to monitor the amount of time until test completion for the LOC.
2. Re-enter the `act-lbp` command that generated this error after permitting the test on the LOC to complete.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2925 Cmd Rej: The Gateway Linkset table is full

Commands Used: `ent-ls`

You exceeded the maximum number of linksets (255) when you entered this command.

Recovery

1. Display the linkset information.
Enter the `rtrv-ls` command.
2. Delete an unneeded linkset.
3. Re-enter the `ent-ls` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2926 Cmd Rej: A problem occurred while trying to access the GWS database

Commands Used: `chg-ls`, `chk-unref-ent`, `ent-ls`

You may have an intermittent system problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2927 Cmd Rej: The linkset is provisioned locally

Commands Used: `ent-slk`

OAP attempted to provision GWS on a linkset that has GWS on it already through an EAGLE 5 ISS terminal.

Recovery

Re-enter the `ent-slk` command that generated this error message specifying the correct `slc` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2928 Cmd Rej: The linkset specified is not a Gateway Linkset

Commands Used: `ent-ls`, `chg-ls`, `rtrv-gtwy-acthresh`, `set-gtwy-acthresh`

You specified the `gwsa`, `gwsm`, or `gwsd` parameters as active, but the linkset does not support these features.

Another possibility is that you used OAP `gtwy-ls` commands on a non-gateway linkset.

Recovery

Perform one of the following:

- Re-enter the command that generated this error message specifying **off** for the `gwsa`, `gwsm`, or `gwsd` parameters.
- OR
- Re-enter the command that generated this error message without specifying the `gwsa`, `gwsm`, and `gwsd` parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2929 Cmd Rej: The linkset specified does not exist in the linkset table

Commands Used: `chg-ls`, `dlt-ls`, `rtrv-ls`

You entered this command specifying an invalid **lsn** parameter value.

Recovery

1. Display a list of valid linkset names.
Enter the `rtrv-ls` command.
2. Re-enter the command that generated this error message specifying the correct **lsn** parameter value.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2930 Cmd Rej: The Gateway Linkset specified already exists

Commands Used: `ent-ls`

The linkset name (**lsn**) parameter value must be unique.

Recovery

1. Display the linkset information.
Enter the `rtrv-ls` command.
2. Re-enter the `ent-ls` command that generated this error message specifying the correct (unique) **lsn** parameter value.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2931 Cmd Rej: SEAS Gateway Screen Set Names cannot be changed locally

Commands Used: `chg-ls`

You entered the command at an EAGLE 5 ISS terminal and tried to change a SEAS gateway linkset. Gateway linksets can be configured only from a OAP terminal and not from an EAGLE 5 ISS terminal.

Recovery

1. Display the linkset information.
Enter the `rtrv-ls` command. The entries displayed as "SEAS" in the *SCRN* field were created at an OAP terminal and cannot be changed at an EAGLE 5 ISS terminal.
2. Perform one of the following:
 - a) Re-enter the `chg-ls` command for a linkset with a name other than "SEAS" in the *SCRN* field of the output from Step 1.
OR
 - b) If a linkset for a SEAS screen set name must be changed, do so at an OAP terminal.

E2932 Cmd Rej: SEAS Gateway Linksets cannot be deleted locally

Commands Used: `dlt-ls`

You entered the command at an EAGLE 5 ISS terminal and tried to delete a SEAS gateway linkset. Gateway linksets can be deleted only from an OAP terminal and not from an EAGLE 5 ISS terminal.

Recovery

1. Display the linkset information.
Enter the `rtrv-ls` command. The entries displayed as "SEAS" in the *SCRN* field were created at an OAP terminal and cannot be deleted from an EAGLE 5 ISS terminal.
2. Perform one of the following:
 - a) Re-enter the `dlt-ls` command for a linkset with a name other than "SEAS" in the *SCRN* field of the output from Step 1.
OR
 - b) If a linkset for a SEAS screen set name must be deleted, do so at an OAP terminal.

E2933 Cmd Rej: A specific SI must be specified in the range (0-15)

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`

You either failed to include the service identifier (**si**) parameter on the command line, or assigned a value to it that was out of range.

Recovery

Re-enter the command that generated this error message specifying the **si** parameter and correct range value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2935 Cmd Rej: If SDATE=EDATE, then ETIME after or same as STIME

Commands Used: `rtrv-log`

You specified the start date (**sdate**) and end date (**edate**) for the same day (that is, **sdate=edate**), but you specified an end time (**etime**) that is before the start time (**stime**). If you specify the same start and end date, you must specify an end time that is the same as or later than the start time.

Recovery

Perform one of the following:

1. Re-enter the command specifying a value for the **etime** parameter that is later than or the same as the value for the **stime** parameter.

For example, you might enter

```
rtrv-log:sdate=961021:edate=961021:stime=130000:etime=140000 OR
```

2. If you meant to enter different dates, re-enter the command specifying the correct values for the **edate** and **sdate** parameters.

E2936 Cmd Rej: SDATE+STIME must be before current date-time

Commands Used: `rtrv-log`

You specified a combination of start date (**sdate**) and start time (**stime**) that is later than the current date-time combination. The EAGLE 5 ISS does not allow you to specify a time in the future to retrieve logs.

Recovery

Re-enter the command specifying values for the **sdate** and **stime** parameters that are before the current date and time. For example, if today's date and time are 11:00 a.m., October 22, 1996, you must enter the `rtrv-log` command specifying a start date and start time combination that is before **sdate=961022** and **stime=110000**.

E2938 Cmd Rej: RTRV-LOG command already in progress

Commands Used: `rtrv-log`

You tried to enter a retrieve log command while another retrieve log command was already in progress. The EAGLE 5 ISS does not allow two retrieve log commands to be in progress at the same time.

Recovery

Wait until the active retrieve log command finishes processing, and re-enter the command.

E2939 Cmd Rej: Unable to read the selected log

Commands Used: `rtrv-log`

The EAGLE 5 ISS was unable to access the selected log.

Recovery

This error message indicates a potentially serious disk error.

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2940 Cmd Rej: Standby MASP is not available

Commands Used: `rtrv-log`

You attempted to download the log of alarms from the standby maintenance and administration subsystem processor, by setting the `slog` parameter to `stb`.

Recovery

1. You are operating without a standby/backup system.
Find out immediately why the standby MASP is not in operation.
2. Bring the standby MASP back into service.
3. If unable to bring the standby MASP back into service, Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E2941 Cmd Rej: Invalid combination - EDATE with STIME

Commands Used: `rtrv-log`

You specified the `stime` parameter and the `edate` parameter. The EAGLE 5 ISS does not allow this combination.

Recovery

Re-enter the `rtrv-log` command specifying another valid combination of the time (`stime/etime`) and date (`sdate/edate`) parameters.

Refer to the *Commands Manual* for valid combinations.

E2942 Cmd Rej: Failed reading/writing Extended Linkset Table

Commands Used: `rtrv-gtwy-acthresh`, `set-gtwy-acthresh`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2943 Cmd Rej: Failed reading/writing Extended STP Options Table

Commands Used: `rtrv-gtwy-prmtrs`, `set-scrrej-prmtrs`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2944 Cmd Rej: Invalid INTRVL value specified

Commands Used: `set-gtwy-acthresh`, `set-scrrej-prmtrs`, `set-uim-acthresh`

You assigned an invalid value to the `intrvl` parameter. Valid values are 5, 10, 15, 20, 25, 30.

Recovery

Re-enter the command that generated this error message specifying a valid `intrvl` parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2945 Cmd Rej: Source database version is not compatible

Commands Used: `act-upgrade`

The specified source drive is not at the correct database version for the upgrade to proceed.

Recovery

CAUTION

CAUTION: It is strongly recommended that this command be used only in conjunction with the system Upgrade Procedure for your target release. The Upgrade Procedure provides step-by-step information on performing an upgrade.

1. Enter the `act-upgrade:action=dbstatus` command to verify the version of the database.
2. If the source drive displays the correct database version, re-enter the `act-upgrade` command.
3. If the drive does not contain the source-release system data, specify a different source drive, or insert the appropriate drive.
4. Re-enter the `act-upgrade` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2946 Cmd Rej: No match on DESTFLD parameter during retrieve

Commands Used: `rtrv-scr-sio`

You set the `nsfi` parameter to the `destfld` value, but no match was found.

Recovery

Re-enter the `rtrv-scr-sio` command that generated this error message specifying a different **destfld** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2947 Cmd Rej: No match on SCCPMT parameter during retrieve

Commands Used: `rtrv-scr-cgpa`

You set the SCCP Message Type parameter **sccpmt** to a value that did not match any of the screening references in the allowed calling party address (CGPA) entity set.

Recovery

Perform one of the following:

- Re-enter the `rtrv-scr-cgpa` command that generated this error message specifying another **sccpmt** parameter value.

OR

- Re-enter the `rtrv-scr-cgpa` command that generated this error message and omit the **sccpmt** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2948 Cmd Rej: No match on SCMGFID parameter during retrieve

Commands Used: `rtrv-scr-cdpa`

You entered this command specifying the SCCP management (SCMG) format ID parameter set to a value that does not exist in the screening reference.

Recovery

1. Enter the `rtrv-scr-cgpa` command without specifying the **scmgid** parameter, to acquire the current state of the parameter.
2. Re-enter the `rtrv-scr-cgpa` command that generated this error message, using the appropriate **scmgid** parameter value acquired in Step 1.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2949 Cmd Rej: SNAME must be specified

Commands Used: inh-alm, unhb-alm

When the **dev=applsock** parameter is specified, the **sname** parameter must be specified.

Recovery

Re-enter the command specifying the **sname** parameter value.

E2950 Cmd Rej: PORT parameter invalid for DEV selected

Commands Used: inh-alm, unhb-alm

The specified **port/link** parameter value was not valid for the device configured with the **dev** parameter.

[Table 15: Valid dev/port Parameter Combinations](#) describes supported parameter combinations.

Table 15: Valid dev/port Parameter Combinations

dev=	port=
dlk	a, b
enet	a, b
lsmsq3	a1, a2, b1, b2
ndclk	a1, a2, b1, b2
seasx25	a1, a2, b1, b2
slk	a, b

Recovery

Re-enter the command that generated this error message specifying the correct **port** parameter value.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2951 Cmd Rej: LSN must be specified

Commands Used: inh-alm, unhb-alm

You failed to enter the required linkset name (**lsn**) parameter when you specified the **dev** parameter with a value of **ls**.

Recovery

Re-enter the command that generated this error message specifying the correct **lsn** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2952 Cmd Rej: PORT must be specified

Commands Used: `inh-alm`, `unhb-alm`

You failed to include the **port** parameter when you specified the **dev** parameter with a value of **seasx25**, **ndclk**, or **lsmconn**. The valid range of values for the **port** parameter is as follows:

a1 – EMDC A to EMAP A link

a2 – EMAP A to NDC OS link

b1 – EMDC B to EMAP B link

b2 – EMAP B to NDC OS link

Recovery

Re-enter the command that generated this error message specifying the correct **port** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2953 Cmd Rej: ID must be specified

Commands Used: `inh-alm`, `unhb-alm`

When the **dev=cdt** parameter is specified, the **id** parameter must be specified.

Recovery

Re-enter the command that generated this error message specifying the correct **id** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2954 Cmd Rej: DEV state does not allow alarms to be inhibited

Commands Used: `inh-alm`

The device you selected was servicing an action command when you entered this command. This command will not execute while the signaling link is running either a Link Fault Sectionalization test

or a Loopback test. An AST of LFS or LPBK must be cleared before signaling link alarms can be inhibited.

Recovery

Wait for the device to finish its action, then re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2955 Cmd Rej: Network Routing is only valid if the NRT feature is ON

Commands Used: `chg-dstn`, `chg-rte`, `dlt-dstn`, `dlt-rte`, `ent-dstn`, `ent-rte`,
`rtrv-dstn`, `rtrv-rte`

You attempted to enter a network destination, but the NRT (network routing) feature has not been turned on.

Network routing is only valid if the NRT feature is on. The NRT feature is turned on with the `chg-feat` command.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the NRT feature is turned on (NRT=on), re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Note:

Once a feature is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information. When using the Network Routing feature, limited network management is provided for point codes not covered by full point code routing, cluster routing, or nested cluster routing.

3. If the NRT feature is turned off (NRT=off from the output of Step 1), turn it on. Enter the command:
`chg-feat:nrt=on`
4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2956 Cmd Rej: NCM must be * when using Network Routing

Commands Used: `chg-dstn`, `chg-rte`, `dlt-dstn`, `dlt-rte`, `ent-dstn`, `ent-rte`,
`rtrv-dstn`, `rtrv-rte`

When using network routing, if the destination point code has a value of * in the nc field, the ncm field must also be * (for example, `dpc=21-*-*`).

Recovery

Re-enter the command, specifying a valid destination point code for network routing.

E2960 Cmd Rej: CHG-PID not allowed while in upgrade mode

Commands Used: chg-pid

You attempted to enter the chg-pid command while the system is in upgrade mode. This action is not allowed.

Recovery

1. Wait until the upgrade has completed.
2. Re-enter the chg-pid command.

E2961 Cmd Rej: <#> (domain) must be between <min> and <max>

Commands Used: all commands

The value specified for the timer must be within the range for that domain.

Recovery

Re-enter the command specifying a valid timer number that is within the minimum-maximum range of permissible timer values.

Refer to the *Commands Manual* for the correct format of the parameter.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2962 Cmd Rej: <device> is <condition>

Commands Used: act-upgrade, chg-db, copy-disk, copy-meas, copy-gpl, format-disk

The removable cartridge or removable drive:

- must be inserted
- must be initialized
- cannot be a measurement removal disk
- must be a system removable disk

A valid upgrade release must reside on the removable cartridge or the inactive partition of the fixed disk.

Recovery - Removable cartridge is not inserted

Insert a system disk for the current system release.

Recovery - Removable cartridge is not initialized

This command requires a removable cartridge formatted for measurements data. A valid system measurements removable cartridge must be inserted in the MDAL removable cartridge drive. See the `format-disk` command for details on how to use the system to format cartridges.

Recovery - Removable cartridge is not a system disk

The removable drive must be accessible and ready and must be formatted as a system removable disk, NOT as a measurement removable disk.

Insert a system disk for the current system release.

Recovery - Removable cartridge is not a MEAS disk

1. Remove the system disk from the MDAL.
2. Insert a MEAS disk for the current system release.

Recovery - Removable cartridge is inaccessible (internal problem)

Remove and re-install the MDAL and cartridge or a spare.

Recovery - Fixed disk is not inserted

Insert a fixed disk for the current system release.

Recovery - Fixed disk is not initialized

1. Enter the command:
`format-disk:type=fixed:loc=1114`
2. Re-issue the `copy-disk` command.

Recovery - Fixed disk is inaccessible (internal problem)

Remove and re-install the MDAL and cartridge or a spare.

E2963 Cmd Rej: Cannot read DB Stat Table (<database>, <disk>, <MASP status>) [or] Cmd Rej: Incorrect DB version (<database>, <disk>, <MASP status>) [or] Cmd Rej: DB status is UPG 1 (<database>, <disk>, <MASP status>) [or] Cmd Rej: DB is incoherent (<database>, <disk>, <MASP status>)

Commands Used: All database commands

A problem has been detected with the designated database:

- DB Stat Table cannot be read
- DB version is incorrect
- DB status is UPG 1
- DB is incoherent

(‘Incoherent’ means that a previous database update was unsuccessful, leaving the coherency indicator unchanged)

For more information on database coherency, refer to the *Database Administration Manual - System Management*.

The designation of the problem database is identified as:

- <database> **Curr DB** or **Bkup DB**
- <disk> **Fxd Disk** or **Rmv Disk**
- <MASP status> **Active MASP** or **Stby MASP**

Recovery

1. Determine the status of your database. Enter the command: `rept-stat-db:display=all`
2. Re-enter the command that generated the error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2964 Cmd Rej: PVN/FCNA/FCNB conflicts with IPRTE or IPLNK network

Commands Used: `act-upgrade`

The destination of a static IP route or the local interface network address of an IP card cannot be the same as the EAGLE 5 ISS PVN, FCNA, or FCNB network address.

Recovery

1. Use the `chg-netopts` command to change the PVN, FCNA and/or FCNB values so that they do not overlap with any networks used for an IPRTE or IPLNK address.
2. Re-enter the `act-upgrade` command.

E2965 Cmd Rej: Too many parameters entered

Commands Used: `chg-ppsopts`, `inh-alm`, `rept-stat-alm`, `unhb-alm`

Too many parameters were specified for the command.

Refer to the command description in the *Commands Manual* for valid parameters for the command.

For the `chg-ppsopts` command, the **gta1**, **gta2**, or **gta3** parameter is specified, then the **ngta** parameter cannot be specified.

Recovery - `inh-alm`, `unhb-alm`

Re-enter the command that generated this error message specifying fewer parameters.

Refer to the `inh-alm` and `unhb-alm` commands in the *Commands Manual* for the valid parameter combinations.

Recovery - `rept-stat-alm`

Re-enter the `rept-stat-alm` command specifying both the **dev** and **display** parameters.

Recovery - chg-ppsopts

Re-enter the `chg-ppsopts` command specifying either the **gta1**, **gta2**, or **gta3** parameter or the **ngta** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2966 Cmd Rej: TRM must be specified

Commands Used: `chg-secu-trm`, `chg-trm`, `rmv-trm`, `inh-alm`, `inh-trm`, `rst-trm`, `unhb-alm`

You entered the command without specifying the mandatory **trm** parameter. For `inh-alm` and `unhb-alm` specifically, it is the **dev=trm** parameter that requires that you also specify the **trm** parameter.

Recovery

Re-enter the command that generated this error message, and include the **trm** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2967 Cmd Rej: Active OAM database is incoherent

Commands Used: all commands

The database was found to be incoherent, which means that a previous database update was unsuccessful, leaving the coherency indicator unchanged. During the subsequent attempted execution of an upgrade procedure, an error was detected when either of the following was issued:
`act-upgrade:action=converttoam` or `act-upgrade:action=convertstp`

Recovery

1. Consult the *Upgrade Procedures* document for the target upgrade.
Refer to the relevant Recovery Procedure section in that document for instructions.
2. Follow the instructions for recovering from the upgrade procedure error.
Those instructions will direct you to back out of the upgrade mode. After returning to full-function mode in the source release, follow instructions in the *Database Administration Manual – System Management* to fix the problem with database incoherence. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2968 Cmd Rej: FORCE=YES is required to isolate card from IMT

Commands Used: `disc-imt`

The command was entered, but was unsuccessful in isolating the card from the specified IMT bus. In a situation where a card is already disconnected from one IMT bus and the command is asking to remove the card from the other bus, the **force** parameter is required.

Recovery

Re-enter the `disc-imt` command specifying the **force=yes** parameter to disconnect a specific card from the IMT bus.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2969 Cmd Rej: Unable to determine current connect status of card <card>

Commands Used: `all commands`

In response to a query, the connect status of the specified card cannot be determined.

Recovery

1. Verify that you typed the command correctly.
2. Make any necessary corrections, and then re-enter the command.

Refer to the *Commands Manual* for information regarding the correct command usage. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2970 Cmd Rej: Action requires ICNP feature to be configured

Commands Used: `rept-meas`

You attempted an action that requires the IntraCarrier Number Portability and IN Triggers (ICNP) feature to be configured.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual-System Management* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the feature access key controlled features that are enabled in the system.
Enter the `rtrv-ctrl-feat` command.

2. If the feature has been purchased and installed in your system verify its status.

Refer to the *Database Administration Manual - System Management* for instructions on enabling and turning on, and configuring the IntraCarrier Number Portability and IN Triggers (ICNP) feature and any prerequisite features that must be turned on.

3. When the feature is turned on in the system, re-enter the `rept-meas` command specifying the parameter that requires the ICNP feature to be on.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2971 Cmd Rej: System busy - Repeat later

Commands Used: all OAP commands

A system-busy error can result from either:

- Heavy disk activity (resulting from database maintenance or measurement collection) is preventing access to the system.

OR

- A conflict between two action commands has occurred. If you enter an action command while another action command is in progress, your command cannot execute.

An action command is a command that changes the state of entities within the EAGLE 5 ISS. For more information, refer to the *Commands Manual*.

Recovery

1. Wait until the disk activity subsides or the action command completes.
2. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E2972 Cmd Rej: Specified Port is not valid for Card and Appl Type

Commands Used: `act-lpo`, `act-slk`, `alw-slk`, `blk-slk`, `canc-lpo`, `canc-slk`, `dact-slk`, `ent-slk`, `inh-slk`, `rept-stat-slk`, `rtrv-slk`, `ublk-slk`

The specified port is not valid for the card and application type. Refer to the command description and to Appendix A in the *Commands Manual* for details on the ports supported for each card and application type.

Recovery

Re-enter the command specifying a valid port for the card type and application.

E2973 Cmd Rej: If specified, BPS must be 56000 for Multi Port LIM

Commands Used: `ent-slk`

You entered a **bps** value that is not valid for a multi-port LIM or an E1/T1 MIM used as a T1 card. Multi-port LIMs and T1 cards support **bps=56000** links only.

Recovery

Re-enter the `ent-slk` command for the multi-port LIM specifying **bps=56000**.

E2974 Cmd Rej: BPS must be 56000 for all ports on Multi Port LIM

Commands Used: `ent-slk`

If a multi-port LIM card is used, then the **bps=56000** parameter must be specified.

Recovery

Re-enter the command for the multi-port LIM specifying **bps=56000**.

E2976 Cmd Rej: Card does not support more than 2 Links

Commands Used: `alw-slk`, `act-lpo`, `act-slk`, `blk-slk`, `canc-lpo`, `canc-slk`, `dact-slk`, `dlt-slk`, `ent-slk`, `inh-alm`, `inh-slk`, `rept-stat-slk`, `rtrv-slk`, `tst-slk`, `ublk-slk`, `unhb-alm`, `unhb-slk`

A signaling link was specified that is not supported on the card that is running. Refer to the command description and to Appendix A in the *Comannds Manual* for details on the links supported on each card type.

Recovery

Re-enter the command, specifying a port that is valid for the card that is running.

E2977 Cmd Rej: Cannot leave a solitary PC in group

Commands Used: `dlt-mrn`

You entered a command that would delete all but one point code in a MRNGROUP. You cannot delete point codes in an MRNGROUP if the deletion leaves only one point code remaining in the MRNGROUP.

Note:

If deleting one or more point codes from the MRNGROUP would result in only one point code remaining, you must delete the entire MRNGROUP by specifying the `all = yes` parameter.

Recovery

1. Display the MRNGROUP that contains the point codes to be deleted.
Enter the `rtrv-mrn` command. If only one point code will remain in the MRNGROUP, delete the entire MRNGROUP.

2. To delete the entire MRNGROUP, re-enter the `dlt-mrn` command specifying the `all=yes` parameter with the `pc` parameter value for one of the point codes in the MRNGROUP.

E2978 Cmd Rej: RC is required if no other optional parameters are provided

Commands Used: `chg-mrn`

You specified only the point code (`pc`) parameter. The relative cost (`rc`) parameter must also be entered if you enter no other optional parameters in the command.

Recovery

Re-enter the `chg-mrn` command specifying the `pc` parameter and its relative cost (`rc`) parameter or other optional parameters.

E2979 Cmd Rej: Cannot enter the same PC more than once

Commands Used: `chg-mrn`, `chg-sccp-serv`, `dlt-mrn`, `dlt-sccp-serv`, `ent-mrn`

The specified point code value already exists in the table. The same point code value cannot be entered more than once in the MRN table.

For the `chg-sccp-serv` command, the same point code value cannot be entered more than once in the SCCP-SERV table.

Recovery - `chg-mrn`, `ent-mrn`

1. Display the point codes currently in the MRN Table. Enter the `rtrv-mrn` command.
2. Re-enter the command specifying a point code parameter value that does not appear in the output from Step 1.

Recovery - `chg-sccp-serv`

1. Display the point codes currently in the SERV Table. Enter the `rtrv-sccp-serv` command.
2. Re-enter the `chg-sccp-serv` command a point code parameter value that does not appear in the output from Step 1.

Recovery - `dlt-mrn`, `dlt-sccp-serv`

Re-enter the command specifying a point code parameter value only once.

E2980 Cmd Rej: Must be in upgrade phase 3 or full function mode

Commands Used: `init-network`

You entered the command and the EAGLE 5 ISS was not in *Upgrade Phase 3* mode or *Full Function* mode. *Upgrade Phase 3* mode means that the MASPs are running GPLs that match the major revision defined for the approved GPLs, but the other network processors are only *prepared* to be upgraded.

Full Function mode means that all MASPs are running GPLs that match the major revision defined for the approved GPLs. *Full Function* mode is the normal operating mode for the MASP.

Recovery

1. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
2. When instructed to do so by the Customer Care Center, re-enter the `init-network` command.

E2981 Cmd Rej: Already in nodal isolation

Commands Used: `init-network`

You entered the command, and the EAGLE 5 ISS detected that there were no in-service active links. The `init-network` command requires that at least one `ss7ansi` or `ccs7itu` card must exist with an in-service active link.

Recovery

1. Return the inhibited signaling link(s) to service.
Enter the `alw-slk` command.
2. Restore the card to IS-NR (in-service normal).
Enter the `rst-card` (or `alw-card`) command.
3. Verify that the card(s) are in service.
Enter the `rept-stat-card` command.
4. Re-enter the `init-network` command.

E2982 Cmd Rej: Database is incoherent

Commands Used: `init-network`

The database is incoherent, which means that a previous database update was unsuccessful, thereby leaving the coherency indicator unchanged.

For more information on database coherency, refer to the *Database Administration Manual – System Management*.

Recovery

Verify the operational status of the EAGLE 5 ISS database. Enter the `rept-stat-db` command.

1. If the current partition of the fixed disk is coherent and the back up partition of the fixed disk is incoherent, create a backup copy of the database on the fixed disk.
Enter the following command: `chg-db:action=backup:dest=fixed`
2. If the current partition of the fixed disk is coherent and the database on the removable cartridge is incoherent, create a backup copy of the database to the removable cartridge.
Enter the following command: `chg-db:action=backup:dest=remove`

3. If the backup partition of the fixed disk is coherent and the current partition of the fixed disk is incoherent, restore the database from the backup partition of the fixed disk.
Enter the following command: `chg-db:action=restore:src=fixed`
4. If the database on the removable cartridge is coherent and the current partition of the fixed disk is incoherent, restore the database from the removable cartridge.
Enter the following command: `chg-db:action=restore:src=remove`
5. If the backup and current partitions on the active TDM are coherent and the backup and current partitions on the standby TDM are incoherent, repair the database.
Enter the following command: `chg-db:action=repair`

E2984 Cmd Rej: SRM or MRC cannot be entered for a solitary entry

Commands Used: `ent-map`

You cannot specify a solitary application and the Control of Subsystem Routing Messages (**srm**) parameter or the Control of Message Routing Under Congestion (**mrc**) parameter. This combination is not allowed. The **srm** or **mrc** parameters cannot be specified for a solitary **pc/ssn** pair entry.

Recovery

Perform one of the following:

- If a solitary application is desired, re-enter the `ent-map` command without specifying the **srm** or **mrc** parameters.
OR
- If a shared application is desired, re-enter the `ent-map` command specifying the **srm** and **mrc** parameters.

E2985 Cmd Rej: Mate Relative Cost (MateRC) required if MPC/MSSN is entered

Commands Used: `ent-map`

If a mate subsystem number (**mssn**) parameter or mate point code (**mpc**) parameter is specified, the mate relative cost (**materc**) parameter must be specified.

Recovery

Re-enter the `ent-map` command specifying the **mpc**, **mssn**, and **materc** parameters.

E2986 Cmd Rej: Relative Cost (RC) is required for PC/SSN and MPC/MSSN

Commands Used: `ent-map`

If the **pc/ssn** and **mpc/mssn** parameter pairs are specified, the **rc** parameter must be specified.

Recovery

Re-enter the **ent-map** command specifying the **pc/ssn** and **mpc/mssn** parameter pairs and the relative cost (**rc**) parameter.

E2987 Cmd Rej: The TPC can be used only when creating a SOL or DOM group

Commands Used: **chg-map**, **ent-map**

For the **chg-map** command, the **pc** parameter value is a true point code, the subsystem must have a lower relative cost (**rc**) than all other mated subsystems in the entity set.

For the **ent-map** command, the new entity set being created must be either solitary or dominant to use the true point code as a point code.

Recovery

Re-enter the command specifying a relative cost (**rc**) parameter value for the true point code that is less than all mated subsystems in the group.

E2988 Cmd Rej: Maximum number of Mated Applications (MAP) exceeded

Commands Used: **chg-map**

A maximum of **32** mated applications is allowed per MAP set.

Recovery

Delete an existing mated application and re-enter the **chg-map** command for the new mated application.

OR

Enter the mated application as a new primary point code.

E2989 Cmd Rej: RC must be specified for PC since MPC is specified

Commands Used: **ent-map**

If the **mpc** parameter is specified, the **rc** parameter must be specified.

Recovery

Re-enter the **ent-map** command specifying the **mpc** and **rc** parameters.

E2990 Cmd Rej: Relative Cost (RC) of true PC must be less than RC of mate

Commands Used: `chg-map`, `ent-map`

You specified the relative cost (`rc`) parameter value for a true point code that is greater than the relative cost of its mate. If the `pc` parameter value is a true point code, the subsystem must have a lower relative cost than all other mated subsystems in the group.

Recovery

Re-enter the command specifying a value for the `rc` parameter for the true point code that is less than the relative cost for its mate.

E2991 Cmd Rej: Relative Cost (RC) of true MPC must be less than RC of mate

Commands Used: `chg-map`, `ent-map`

You specified the mate relative cost (`materc`) parameter value for a true mated point code that is greater than the relative cost of its mate. If the `mpc` parameter value is a true point code, the subsystem must have a lower relative cost than all other mated subsystems in the group.

Recovery

Re-enter the command specifying the `mpc` and `materc` parameter values so that the relative cost of the mated point code is less than the relative cost of its mate.

E2992 Cmd Rej: MSSN and MATERC must be specified since MPC is specified

Commands Used: `chg-map`, `ent-map`

If the `mpc` parameter is specified, the `mssn` and `materc` parameters must be specified.

Recovery

Re-enter the command specifying values for the `mpc`, `mssn`, and `materc` parameters.

E2993 Cmd Rej: True Point Code must remain primary entity

Commands Used: `chg-map`

The true point code in the MAPGROUP must be and remain the primary PC/SSN for that MAPGROUP. The RC value of the `pc` parameter cannot be changed nor can a new point code cannot be added to

the MAPGROUP, that would result in the true point code no longer being the primary PC/SSN of the MAPGROUP.

Recovery

1. Display the entities in the load sharing group.
Enter the `rtrv-map` command.
2. Re-enter the `chg-map` command without changing a routing cost value or specifying a new point code (**mpc**) parameter.

E2994 Cmd Rej: True Point Code may not be routed to self

Commands Used: `chg-map`, `ent-map`

You specified parameters that would route the true point code to itself. A true point code cannot be routed to itself.

Recovery

Re-enter the command specifying different values for the **pc** and **mpc** parameters.

E2995 Cmd Rej: True Point Code can only have one mate

Commands Used: `chg-map`

You entered the command that would result in more than one mate for a true point code. A true point code can have only one mate.

Recovery

If you want to change the mate of the true point code, delete the current mate and re-enter the `chg-map` command to enter the new mate.

E2996 Cmd Rej: Intermed GTT Load sharing feature must be ON

Commands Used: `chg-mrn`, `enable-ctrl-feat`, `ent-mrn`, `rtrv-mrn`

For the `chg-mrn`, `ent-mrn`, and `rtrv-mrn` commands, the Intermediate Global Title Translation Load Sharing (IGTTLS) feature must be turned on before these commands can be entered.

For the `enable-ctrl-feat` command, the Intermediate GTT Load Sharing feature must be turned on before the GTT LS ARI feature can be enabled.

Recovery

1. Display the status of the IGTTLS feature. Enter the command:
`rtrv-ctrl-feat:partnum=893006901`
2. Verify that the IGTTLS feature has been purchased and installed in your system.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. To enable and turn on the IGTTLS feature, refer to the procedures in the *Database Administration Manual - Global Title Translation*.

E2997 Cmd Rej: PC must match NPCFMTI set in CHG-STPOPTS

Commands Used: `chg-gtt`, `chg-ls`, `chg-map`, `chg-mrn`, `dlt-map`, `dlt-mrn`, `dlt-rte`, `ent-rte`, `ent-ls`, `ent-mrn`, `chg-sid`, `chg-rte`, `ent-ls`, `rept-stat-rte`, `rept-stat-rtx`, `rtrv-gtt`

A command was entered to add, change, or delete the entry for a point code or alternate point code in the Mated Relay Node (MRN) table. If the **dpcn** parameter is specified, its format must match the format that was assigned with the **chg-stpopts:npcfmti** parameter. If the **apcn** parameter is specified, its format must match the format that was assigned with the **chg-stpopts:npcfmti** parameter. If the **pcn**, **npcn**, **cpcn**, or **ncpcn** parameter is specified, the format must match the format that was assigned with the **chg-stpopts:npcfmti** parameter.

Refer to the `chg-stpopts` command description in *Commands Manual* for valid **npcfmti** parameter values.

The **apcn** parameter format must match the format that was assigned with the **chg-stpopts:npcfmti** parameter.

Recovery

1. Display the current settings of the STP options in your system.
Enter the `rtrv-stpopts` command. Verify the value for **npcfmti** in the output.
2. Re-enter the command specifying the point code or alternate point code parameter value in the format indicated by the **npcfmti** setting in the output from Step 1.

E2998 Cmd Rej: PC cannot match the SID

Commands Used: `chg-mrn`, `chg-sccp-serv`, `ent-mrn`

You entered a command to add or change a point code entry in the Mated Relay Node table, and the specified point code is the same as the EAGLE 5 ISS site identifier (SID). You cannot specify a point code that has the same value as the EAGLE 5 ISS SID.

Recovery

1. Display the current SID.
Enter the `rtrv-sid` command.
2. Re-enter the command specifying a point code that is not the same as the SID.

E2999 Cmd Rej: Failed reading the MRN table

Commands Used: `chg-gta`, `chg-gtt`, `chg-map`, `chg-mrn`, `chg-ppsopts`, `dlt-mrn`, `ent-gta`, `ent-gtt`, `ent-mrn`, `rtrv-mrn`, `chg-sccp-serv`, `dlt-map`, `dlt-sccp-serv`, `rtrv-sccp-serv`

The Mated Relay Node (MRN) table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3000 Cmd Rej: DPC is referenced by SCCP in MRN table or SCCP Serv table

Commands Used: `dlt-dstn`

You cannot delete a Destination Point Code (DPC) that is referenced by an SCCP as a point code in the Mated Relay Node (MRN) table. The specified destination cannot be referenced by an SCCP as a destination point code in the Mated Relay Node (MRN) table or the SCCP SEV table.

Recovery

1. Display the point codes in the MRN table.
Enter the `rtrv-mrn` command.
2. Before you can delete the DPC from the destination entity, you must delete the point code from the MRN table or the SCCP SEV table.
Enter the `dlt-mrn` command.
3. Verify that the DPC to be deleted is in the MRN table or the SCCP SEV table.
Enter the `rtrv-mrn` command.
4. Delete the DPC from the Destination table.
Re-enter the `dlt-dstn` command.

E3001 Cmd Rej: SDATE must be earlier or equal to EDATE

Commands Used: `rtrv-log`, `rtrv-seculog`

If both the start date (**sdate**) and the end date (**edate**) parameters are specified, the date that is specified for the **sdate** parameter must be earlier than or equal to the date specified for the **edate** parameter.

Recovery

Re-enter the command specifying a new date for the **sdate** parameter (in the form *yyymmdd*, where *yy* is year, *mm* is month, and *dd* is day) that is earlier than the date specified for the **edate** parameter.

E3002 Cmd Rej: STIME must be earlier or equal to ETIME

Commands Used: `rtrv-seculog`

If both the start time (**stime**) and end time (**etime**) parameters are specified, the time you specify for the **stime** parameter must be earlier than or equal to the time specified for the **etime** parameter.

Recovery

Re-enter the `rtrv-seculog` command specifying a new time for the (**stime**) parameter (in the form *hhmmss* — *hh* =hours (00-23), *mm* =minutes (00-59), *ss* =seconds (00-59)) that is earlier than the time specified for the (**etime**) parameter.

E3003 Cmd Rej: Modification of security log not allowed

Commands Used: `copy-fta`, `copy-tbl`

You cannot specify the values (170, 500 or 502) for the Source table (**stbl**) parameter, the Destination table (**dtbl**) parameter, or both.

Recovery

Re-enter the command specifying values other than (170, 500 or 502) for the **stbl** and/or **dtbl** parameters.

E3004 Cmd Rej: Un-uploaded security log entries exist on standby fixed disk

Commands Used: `copy-disk`, `format-disk`

You entered the command to copy the contents of the active fixed disk to the standby fixed disk, and the system determined that the standby fixed disk security log contains un-uploaded entries. The standby fixed disk cannot be initialized while un-uploaded security log entries exist on the standby fixed disk.

Recovery

1. Display pertinent information about the security log on the active and standby fixed disks.
Enter the `rept-stat-seculog` command. The *ENTRIES* field shows the number of un-uploaded commands currently recorded in the log.
2. Copy the log from the standby fixed disk to the active fixed disk's file transfer area (FTA) and reset the *ENTRIES* field to 0 (zero).
Enter the `copy-seculog:slog=stb` command.
3. Re-enter the `copy-disk` command.

E3005 Cmd Rej: Security log command already in progress

Commands Used: `copy-seculog`, `rept-stat-seculog`, `rtrv-seculog`

You cannot enter a security log command while another security log command is already in progress. Two security log commands cannot be in progress at the same time.

Recovery

Wait until the active security log command finishes processing and re-enter the command.

E3006 Cmd Rej: Hex Digit Support for GTT feature must be ON

Commands Used: `chg-gta`, `chg-gtcnv`, `chg-gtt`, `chg-gsmsmsopts`

The Hex Digit Support for GTT feature must be turned on before hexadecimal values can be specified for the `gta`, `egta`, `npds`, `mosmsgta`, or `nsds` parameters.

Recovery

1. Enable and turn on the Hex Digit Support for GTT feature. Refer to the procedure "*Activating the Hex Digit Support for GTT Feature*" in the *Database Administration Manual - Global Title Translation*.
2. Re-enter the command that generated this error message.

E3007 Cmd Rej: Specified UID is reserved for system use

Commands Used: `ent-user`

You cannot specify a user ID that is reserved for system use. The user IDs "`seas`" and "`none`" are both reserved for system use.

Recovery

Re-enter the `ent-user` command specifying a valid user ID other than "`seas`" or "`none`."

E3008 Cmd Rej: Failed reading the security log attributes table

Commands Used: `chg-attr-seculog`

The Security Log Attributes table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3009 Cmd Rej: LNP feature must be ON

Commands Used: `chg-acg-noc`, `chg-feat`, `chg-cmd`, `chg-lnpopts`, `chg-lnp-serv`, `chg-lnp-ttmap`, `chg-map`, `chg-measopts`, `chg-mtc-measopts`, `chg-secu-trm`, `chg-sid`, `chg-ss-appl`, `chg-user`, `dlt-lnp-serv`, `dlt-ss-appl`, `enable-ctrl-feat`, `ent-acg-noc`, `ent-card`, `ent-lnp-serv`, `ent-map`, `ent-ss-appl`, `ent-user`, `rept-ftp-meas`, `rept-meas`, `rept-stat-lnp`, `rst-card`, `rtrv-cmd`, `rtrv-cmdclass`, `rtrv-lnp-serv`, `rtrv-lnpopts`, `rtrv-sid`, `rtrv-ss-appl`

The LNP feature (an LNP ported TNs quantity) must be enabled before the LNP 150,000 LRNs feature or the LNP 300,000 NPANXXs feature can be enabled. The LNP feature must be turned on (refer to the `enable-ctrl-feat` command) before the following actions can be performed:

- Change the LNP database.
 - Enter the `ent-acg-noc` command.
 - Turn on the PCS 1900 Number Portability feature (`chg-feat:plnp=on`).
- Turn on the Wireless Number Portability (WNP) feature (`chg-feat:wnp=on`).
- Retrieve or report on LNP information or measurements.
- Change an EAGLE 5 ISS `cpctype=lnp` and the LNP subsystem.

Recovery

1. Display the features in the database.
Enter the `rtrv-feat` command and `rtrv-ctrl-feat` command.
2. If the LNP feature is turned on, re-enter the command.
3. If the LNP feature is turned off (from the output of Step 1 - the LNP ported TNs entry does not appear in the `rtrv-ctrl-feat` output), turn it on.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.

Refer to the *LNP Feature Activation Guide* and call your Customer Care Center before starting this process. See the "Customer Care Center" section in Chapter 1 of this manual.

4. If required, reset the terminal, terminal command class, and user ID privileges.
Refer to the *Database Administration Manual - System Management* for these procedures.
5. Re-enter the command that generated this error message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3012 Cmd Rej: LNP Subsystem is offline in database

Commands Used: `alw-map-ss`

The LNPQ subsystem must be online in the database before this command can be entered.

Recovery

1. Activate the LNP subsystem.
Enter the `chg-ss-appl:appl=lnp:nstat=online` command.
2. Re-enter the `alw-map-ss` command that generated this error message.

E3014 Cmd Rej: Card location specified must be an SCCP card

Commands Used: `rept-stat-lnp`, `rept-stat-mps`, `rept-stat-sccp`

The specified **loc** parameter is invalid for the card location.

- For the `rept-stat-lnp` command, the card location (**loc** parameter) must identify a configured DSM4G/ E5-SM4G card running the `sccp/ vsccp/ sccphc` application.
- For the `rept-stat-mps` command, the Service Module card must be a VSCCP card.
- For the `rept-stat-sccp` command, the card location (**loc** parameter) must identify a configured Service Module card running the `vsccp` application.

Recovery

1. Display the cards and their identifying information.
Enter the `rtrv-card` command. SCCP cards are shown by the entries TSM in the *TYPE* field and SCCP in the *APPL* field in the `rtrv-card` command output. VCCP cards are shown by the entries DSM in the *TYPE* field and VSCCP in the *APPL* field.
2. Perform one of the following actions:
 - a) Re-enter the command specifying a valid card location obtained in Step 1.
OR
 - b) Re-enter the command without specifying the **loc** parameter.

E3015 Cmd Rej: Cannot delete last route to a DPC referencd by the MRN table

Commands Used: `dlt-rte`, `dlt-dstn`, `chg-dstn`

If any destinations referencing the routset exist in the MRN table, then the last route of the routset cannot be deleted. The last route to a point code that is present in either the MRN table or the SCCPSERV table cannot be deleted.

Recovery

1. Delete the point code from the MRN table or the SCCPSERV table. Enter the `dlt-mrn` command.
2. Re-enter the command to delete the specified route.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3018 Cmd Rej: SSNE should be greater than SSN

Commands Used: `ent-rmt-appl`, `dlt-rmt-appl`

The value specified for the **ssne** parameter is less than or equal to the value of the **ssn** parameter. The **ssne** parameter value must be greater than the **ssn** parameter value.

Recovery

Re-enter the command specifying a value for the **ssne** parameter value that is greater than the **ssn** parameter value. Omit the **ssne** parameter if only one value is desired.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3019 Cmd Rej: Conflicts with existing entry

Commands Used: `dlt-rmt-appl`, `ent-rmt-appl`

The following conditions may cause this error:

- You entered a point code of the same network type (ANSI/ITUI/ITUN) that does not match the point code already in the Remote Application table for that type.
- The point codes match, but the **si** value is already present (except when **si=3**).
- The point code matches, **si=3**, and one or more subsystem numbers **s** already entered overlap the range specified by the **ssn** and **ssne** parameter values.

Recovery

1. Display the entries in the Remote Application table that conflict with the failed command.
Enter the `rtrv-rmt-appl` command.
2. Re-enter the `ent-rmt-appl` command specifying parameter values that do not conflict with existing the entry.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3020 Cmd Rej: Remote Application not found

Commands Used: `dlt-rmt-appl`

To delete a remote application entry, the **ipc**, **si**, and **ssn...ssne** parameter values must all match a values that are in the Destination table.

The command will fail if any of these conditions are not true.

Recovery

Re-enter the `dlt-rmt-appl` command making sure the values specified for the **ipc**, **si**, and **ssn...ssne** parameters all match a value in the Destination table.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3031 Cmd Rej: MULTCC entry cannot be NONE

Commands Used: `chg-gsmopts`

You cannot specify a value of **none** for the **multcc** parameter (**multcc=none**).

Recovery

Perform one of the following:

1. Re-enter the `chg-gsmopts` command specifying a value other than **none** for the **multcc** parameter.
OR
2. Reset the value specified for the **multcc** parameter.

Enter the following command: `chg-gsmopts:multcc=xxx:nmultcc=none`

E3040 Cmd Rej: <string> cannot be used in this command

Commands Used: Any command that has a reserved word

You cannot specify a value for a parameter that is a reserved word for another parameter for the entered command. Reserved words (for example, "none") cannot be used to name a group.

Recovery

Re-enter the command specifying a value that is not a reserved word.

Refer to the *Commands Manual* for information about reserved words for the entered command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3041 Cmd Rej: Timeout

Commands Used: all commands

A timeout occurred while processing the command.

Recovery

Re-enter the command specifying appropriate corrections.

Refer to the *Commands Manual* for the correct command format for the entered command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3042 Cmd Rej: Command Response Timeout, freeing up scroll area

Commands Used: Any command

While in keyboard send/receive (KSR) mode, you entered a command but received no response from the OAM card.

Recovery

1. Re-enter the command that generated this error message.
2. Verify that your terminal settings for peripheral devices such as printers and display terminals match the system terminal settings, as described under "Dependencies" for the `chg-trm` command in the *Commands Manual*.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3043 Cmd Rej: IMT fault test in progress

Commands Used: `alw-imt`, `conn-imt`, `inh-imt`, `init-mux`, `rmv-imt`

If an IMT test is running, then certain commands are affected. [Table 16: Conditions for Command Usage during IMT Tests](#) shows the conditions that govern command usage during IMT tests.

Table 16: Conditions for Command Usage during IMT Tests

Commands	Cannot be used:
<code>alw-imt</code> , <code>conn-imt</code> , <code>inh-imt</code> , <code>rmv-imt</code>	During an IMT Fault Isolation Test
<code>init-mux</code>	During an IMT Fault Isolation Test unless the force=yes parameter is specified

Recovery

Perform one of the following actions:

- Re-enter the command after the test is complete.
- Re-enter the `disc-imt` command specifying the `force=yes` parameter. The `force=yes` parameter allows a card to be disconnected from the IMT bus being tested.

E3044 Cmd Rej: Invalid parameter specified for report type

Commands Used: `rept-imt-info`

If the `report=util` parameter is specified, then the `ebucket`, `erronly`, `mode`, and `sbucket` parameters cannot be specified.

If a value of `hmuxerr`, `hiprerr`, or `hipr2err` is specified for the `report` parameter, then the `erronly` and `mode` parameters cannot be specified.

If a value of `err`, `util`, or `hmuxerr` is specified for the `report` parameter, then the `sslot` and `eslot` parameters cannot be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* for assistance.

E3045 Cmd Rej: Alternate bus must be IS-NR

Commands Used: `tst-imt`

Before you can test the IMT bus using the `tst-imt` command, the state of the alternate IMT bus must be IS-NR state.

Recovery

1. Verify the state of the IMT buses.
Enter the `rept-stat-imt` command.
2. Re-enter the `tst-imt` command specifying the IMT bus that is OOS-MT-DSBLD (out-of-service maintenance-disabled).
This is shown in the *PST* field of the output of Step 1.

E3046 Cmd Rej: Target bus must be inhibited

Commands Used: `tst-imt`

The state of the IMT bus being tested must be OOS-MT-DSBLD (out of service maintenance disabled) before this command can be entered.

Recovery

1. Verify the state of the IMT buses. Enter the `rept-stat-imt` command.
The state of the IMT bus is shown in the *PST* field of the `rept-stat-imt` command output.
2. If the state of one of the IMT buses is OOS-MT-DSBLD, re-enter the `tst-imt` command specifying the IMT bus that is OOS-MT-DSBLD.
3. If the state of both IMT buses is not OOS-MT-DSBLD, place the IMT bus you wish to test out of service with the `rmv-imt` command. Refer to the *Commands Manual* and *Maintenance Manual* for assistance. Re-enter the `tst-imt` command specifying the OOS-MT-DSBLD IMT bus.
4. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3047 Cmd Rej: Parameter combination invalid

Commands Used: `chg-e1`, `chg-t1`, `clr-imt-stats`, `ent-e1`, `ent-t1`, `rept-imt-lvl1`, `rept-imt-lvl2`, `rtrv-gttset`, `tst-imt`

The command was entered with an invalid combination of parameters.

Table 17: Invalid Parameter Combinations

Commands	Recovery
<code>clr-imt-stats</code> , <code>rept-imt-lvl1</code> , <code>rept-imt-lvl2</code>	The s and e or sloc and eloc parameters must be specified.
<code>chg-e1/t1</code> , <code>ent-e1/t1</code>	If the linkclass=unchan parameter is specified, then the chanbrdg=on or cas=on parameters cannot be specified. The linkclass=unchan parameter must be specified before the minsurate parameter can be specified.
<code>rtrv-gttset</code>	If the setidx parameter is specified, then no other parameter can be specified.
<code>tst-imt</code>	If the type=faulttest parameter is specified, then the time and maxerr parameters cannot be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* for assistance.

E3048 Cmd Rej: Starting address/location must be specified

Commands Used: `clr-imt-stats`, `rept-imt-lvl1`

The command was entered without the starting IMT address(es) or starting card location (**sloc**) parameters.

Recovery

Re-enter the command specifying either the **s** or **sloc** parameters.

E3049 Cmd Rej: Ending bucket cannot be less than starting bucket

Commands Used: `rept-imt-info`

The value of the ending bucket (**ebucket**) parameter was less than the value of the starting bucket (**sbucket**) parameter.

Recovery

Re-enter the `rept-imt-info` command specifying a value for the **ebucket** parameter that is greater than the value of the **sbucket** parameter.

E3050 Cmd Rej: L parameter cannot be used in combination with LOC

Commands Used: `rept-imt-lvl2`

The command was entered with both the **l** and **loc** parameters. This combination is not allowed.

Recovery

Re-enter the `rept-imt-lvl2` command specifying either the **l** or **loc** parameter, but not both.

E3051 Cmd Rej: Source address/location must be specified

Commands Used: `rept-imt-lvl2`

The command was entered without specifying the source IMT address (**l**) parameter or the source card location (**loc**) parameter.

Recovery

Re-enter the `rept-imt-lvl2` command specifying either the **l** or **loc** parameter.

E3052 Cmd Rej: IMT statistics collection in progress - Repeat later

Commands Used: `clr-imt-stats`, `init-flash`, `init-imt-gpl`, `init-mux`,
`rept-imt-info`, `rept-imt-lvl1`, `rept-imt-lvl2`, `tst-imt`

The command was entered when the system was collecting the Interprocessor Message Transport (IMT) statistics for the hourly performance monitoring report.

Recovery

Wait for the system to finish collecting the IMT statistics, then re-enter the command.

- If IMT errors are found during the collection process, the hourly performance monitoring report is generated and the collection process has finished. When the hourly performance monitoring report is generated, re-enter the command.
- If no IMT errors are found during the collection process, the hourly performance monitoring report is not generated. In this case, wait five minutes, then re-enter the command.

E3053 Cmd Rej: Failed reading ACG NOC table

Commands Used: `chg-acg-noc`, `dlt-acg-noc`, `ent-acg-noc`, `rtrv-acg-noc`

The Automatic Call Gapping (ACG) Node Overload Control (NOC) table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3054 Cmd Rej: The specified overload level is not defined

Commands Used: `chg-acg-noc`, `dlt-acg-noc`

You attempted to adjust or change an overload level other than those that are currently defined. The specified overload level must be defined.

Recovery

1. Display a list of all currently defined overload levels.
Enter the `rtrv-acg-noc` command.
2. Re-enter the command specifying one of the overload levels from Step 1.

E3055 Cmd Rej: Failed reading ACG MIC table

Commands Used: `ent-acg-mic`

The Automatic Call Gapping (ACG) Manually Initiated Control (MIC) table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3056 Cmd Rej: Parameters ND, INTVL, and AINTVL are required

Commands Used: `ent-acg-mic`

If the manually initiated control applies to all query services (**type=all**), the optional parameters **aintvl**, **intvl**, and **nd** must be specified.

Note:

If the **type=all** parameter is specified, a MIC with **type=all** must exist.

Recovery

Perform one of the following actions:

- Re-enter the `ent-acg-mic` command specifying the **type=all** parameter and the **aintvl**, **intvl**, and **nd** parameters.
- OR
- Re-enter the `ent-acg-mic` command without specifying the **type=sd** parameter (the default is **type=sd**).

E3057 Cmd Rej: Parameters SERV and DGTS are not allowed for TYPE=ALL

Commands Used: `chg-acg-mic`, `dlt-acg-mic`, `ent-acg-mic`, `rtrv-acg-mic`

If the manually initiated control applies to all query services (**type=all**), the **serv** and **dgts** parameters cannot be specified.

Note:

If the **type=all** parameter is specified, a MIC with **type=all** must exist.

Recovery

Perform one of the following actions:

1. Re-enter the command specifying the **type=all** parameter, and the **aintvl**, **intvl**, and **nd** parameters.

OR

2. Re-enter the command without specifying the **type=sd** parameter, and the **serv** and **dgts** parameters.

E3058 Cmd Rej: Parameters SERV and DGTS are required

Commands Used: `chg-acg-mic`, `dlt-acg-mic`, `ent-acg-mic`

If the manually initiated control applies to a specific query service and called party digits (**type=sd**), the **serv** and **dgts** parameters must be specified.

Note:

If the **type=sd** parameter is specified, a MIC with the same service and digits must exist.

Recovery

Re-enter the command specifying the **type=sd** parameter, and the optional parameters **serv** and **dgts**.

E3059 Cmd Rej: Parameter ND is not allowed

Commands Used: `chg-acg-mic`, `ent-acg-mic`

If the manually initiated control applies to a specific query service and called party digits (**type=sd**), the optional number of digits in the global title address (**nd**) parameter cannot be specified.

Note:

If the **type=sd** parameter is specified, a MIC with the same service and digits must exist.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message without specifying the **nd** parameter.
- OR
- Re-enter the command that generated this error message specifying the type of control **type=all** parameter.

Note:

If the **type=all** parameter is specified, a MIC with **type=all** must exist.

E3060 Cmd Rej: Parameter AINTVL is required

Commands Used: `ent-acg-mic`

If the query service specified is the Advanced Intelligent Network (**serv=ain**), the optional AIN interval index **aintvl** parameter must be specified.

Recovery

Perform one of the following actions:

- Re-enter the `ent-acg-mic` command specifying the **serv=ain** parameter and the **aintvl** parameter.
OR
- Re-enter the `ent-acg-mic` command specifying the Intelligent Network query service (**serv=in**) parameter and the **intvl** parameter.

E3061 Cmd Rej: Parameter INTVL is not allowed

Commands Used: `chg-acg-mic`, `ent-acg-mic`

If the query service specified is the Advanced Intelligent Network (**serv=ain**), you cannot specify the Intelligent Network interval index (**intvl**) parameter.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **serv=ain** parameter and the **aintvl** parameter.
OR
- Re-enter the command specifying the **serv=in** parameter and the **intvl** parameter.

E3062 Cmd Rej: Parameter INTVL is required

Commands Used: `ent-acg-mic`

If the query service specified is the Intelligent Network (**serv=in**), the optional IN interval index (**intvl**) parameter must be specified.

Recovery

Perform one of the following actions:

- Re-enter the `ent-acg-mic` command specifying the **serv=in** parameter and the **intvl** parameter.
OR
- Re-enter the `ent-acg-mic` command specifying the **serv=ain** parameter and the **aintvl** parameter.

E3063 Cmd Rej: Parameter AINTVL is not allowed

Commands Used: `chg-acg-mic`, `ent-acg-mic`

If the query service specified is the Intelligent Network (**serv=in**), the AIN interval index (**aintvl**) parameter cannot be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **serv=in** parameter and the **intvl** parameter.
- OR
- Re-enter the command specifying the **serv=ain** parameter and the **aintvl** parameter.

E3064 Cmd Rej: DGTS parameter must be 3 or 6–10

Commands Used: `chg-acg-mic`, `dlt-acg-mic`, `ent-acg-mic`, `rtrv-acg-mic`

You specified an invalid value for the digits of the global title address (**dgts**) parameter. The **dgts** parameter value must be specified as **3** or a number from **6–10**.

Recovery

Re-enter the command specifying a value for the **dgts** parameter as either **3**, or a number from **6–10**.

E3065 Cmd Rej: ND parameter must be 3 or 6-10

Commands Used: `chg-acg-mic`, `ent-acg-mic`

You specified an invalid value for the number of digits in the global title address (**nd**) parameter. The **nd** parameter value must be specified as **3** or a number from **6–10**.

Recovery

Re-enter the command specifying a value for the **nd** parameter as either **3**, or a number from **6–10**.

E3066 Cmd Rej: A MIC of TYPE=ALL already exists

Commands Used: `ent-acg-mic`

If the **type=all** parameter is specified, a manually initiated control (MIC) that applies to all query services (**type=all**) parameter must not already exist.

Recovery

1. Display the values of the current ACG control parameters.
Enter the `rtrv-acg-mic` command.
2. Re-enter the `ent-acg-mic` command that generated this error message specifying a MIC that is not shown in the output generated in Step 1.

E3067 Cmd Rej: A MIC with the same service and digits already exists

Commands Used: `ent-acg-mic`

If the manually initiated control applies to a specific query service and called party digits (**type=sd**), no existing ACG manually initiated control containing the same query service and digits can be in the database.

Recovery

1. Display the values of the current ACG control parameters.
Enter the `rtrv-acg-mic` command.
2. Re-enter the `ent-acg-mic` command that generated this error message with an MIC that is not shown in the output generated in Step 1.

E3068 Cmd Rej: Table full - a maximum of 256 TYPE=SD MICs are allowed

Commands Used: `ent-acg-mic`, `chg-acg-mic`

You entered the command when the LNP database had already reached its maximum capacity of 256 Manually Initiated Controls.

Recovery

1. Display the values of all ACG controls.
Enter the `rtrv-acg-mic` command specifying no parameters.
2. Review ACG controls, to select one or more that is no longer needed.
3. Delete ACG controls that are not needed.
Enter the `dlt-acg-mic` command.
4. Re-enter the command that generated this error message.

E3069 Cmd Rej: Parameter ND, DRTN, INTVL, or AINTVL is required

Commands Used: `chg-acg-mic`

If you enter this command specifying the **type=all** parameter. You must also specify at least one of these optional parameters: **nd**, **drtn**, **intvl**, or **aintvl**.

Recovery

Perform one of the following actions:

- Re-enter the `chg-acg-mic` command specifying the **type=all** parameter, specifying one of the optional parameters.

OR

- Re-enter the `chg-acg-mic` command and omit the **type** parameter (the default is **type=sd**).

E3070 Cmd Rej: Parameter DRTN or AINTVL is required

Commands Used: `chg-acg-mic`

When you enter this command specifying the **serv=ain** parameter, you must specify at least one of these optional parameters: **drtn** or **aintvl**.

Recovery

Perform one of the following actions:

- Re-enter the `chg-acg-mic` command specifying the **serv=ain** parameter, specifying one of the optional parameters.
- OR
- Re-enter the `chg-acg-mic` command without specifying the **serv=ain** parameter.

E3071 Cmd Rej: Parameter DRTN or INTVL is required

Commands Used: `chg-acg-mic`

When you enter this command specifying the **serv=in** parameter, you must specify at least one of these optional parameters: **drtn** or **intvl**.

Recovery

Perform one of the following actions:

- Re-enter the `chg-acg-mic` command specifying the **serv=in** parameter, specifying one of the optional parameters.
- OR
- Re-enter the `chg-acg-mic` command without specifying the **serv=in** parameter.

E3072 Cmd Rej: No MIC of TYPE=ALL exists

Commands Used: `chg-acg-mic`, `dlt-acg-mic`

You specified a Manually Initiated Control (MIC) with the **type** parameter either set to **all**, or completely omitted. Each MIC that already exists in the LNP database has values assigned to the **serv** and **dgts** parameters.

Recovery

1. Enter the `rtrv-acg-mic` command to display the values of ACG controls assigned to certain queries.

2. Re-enter the command that generated this error message specifying an MIC that has its **serv** and **dgts** parameters set to match an MIC shown in the output generated in Step 1.

E3073 Cmd Rej: No MIC with the same service and digits exists

Commands Used: `chg-acg-mic`, `dlt-acg-mic`

You specified a MIC whose service (**serv**) parameter and digits (**dgts**) parameter do not exist in the LNP database.

Recovery

1. Display the values of ACG controls assigned to certain queries.
Enter the `rtrv-acg-mic` command.
2. Re-enter the command that generated this error message specifying a MIC that is shown in the output generated in Step 1.

E3074 Cmd Rej: AND parameter must be 6 or 10

Commands Used: `chg-acg-noc`, `ent-acg-noc`

You specified a value other than **6** or **10** for the AIN number of digits (**and**) parameter. Either **6** or **10** must be specified for the **and** parameter.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying either **and=6** or **and=10**.
OR
- Re-enter the command that generated this error message without specifying the **and** parameter.

E3075 Cmd Rej: IND parameter must be 6 or 10

Commands Used: `chg-acg-noc`, `ent-acg-noc`

You cannot specify a value other than **6** or **10** for the IN number of digits (**ind**) parameter. Either **6** or **10** must be specified for the **ind** parameter.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying either **ind=6** or **ind=10**.
OR
- Re-enter the command that generated this error message without specifying the **ind** parameter.

E3076 Cmd Rej: The specified overload level has already been defined

Commands Used: `ent-acg-noc`

The LNP process can be programmed to take remedial action at ten different levels of overload severity. The controlling variable is the threshold LNP query rates for node overload levels. The response is to adjust the duration of, and intervals between, the automatic call gapping (ACG) function calls as each level is reached.

A command that attempts to re-define one of the levels that has already been defined will trigger this error message. The specified overload level must not already be defined.

Recovery

1. Display a list of all currently defined overload levels.
Enter the `rtrv-acg-noc` command without specifying parameters.
2. Re-enter the `ent-acg-noc` command specifying an overload level other than those from Step 1.
OR Change one of the existing overload levels. Enter the `chg-acg-noc` command.

E3077 Cmd Rej: TT must be specified if PC is specified

Commands Used: `rtrv-lnp-ttmap`

The translation type (**tt**) parameter must be specified if the point code (ANSI) is specified.

Recovery

Perform one of the following actions:

- Re-enter the `rtrv-lnp-ttmap` command specifying both the **tt** and **pc** parameters.
OR
- Re-enter the `rtrv-lnp-ttmap` command specifying only the **tt** parameter.

E3078 Cmd Rej: DPC cannot be defined as a remote application IPC

Commands Used: `dlt-dstn`

You entered a command to delete a **dpc** and specified a remote application Internal Point Code (IPC) for the **dpc** parameter value. This is not allowed.

Recovery

1. Display the list of existing destination point codes.
Enter the `rtrv-dstn` command.
2. Re-enter the `dlt-dstn` command that generated this error message specifying a valid destination point code to be deleted.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3079 Cmd Rej: Command cannot be executed on an MGMT terminal

Commands Used: lock

You cannot lock the keyboard of a terminal that is defined as type **mgmt** for use with Network Surveillance. The **lock** command is not valid for a **mgmt** terminal used for Network Surveillance.

Recovery

Verify that the terminal is type **mgmt**. Enter the `rtv-trl` command.

No other action is required.

E3080 Cmd Rej: ACTION must be specified as FORWARD, DUPLICATE, or DUPDISC

Commands Used: ent-gsmmap-scrn

If the **mapset**, **ri** or **tt** parameter is specified, then the value specified for the **action** parameter must be **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the `ent-gsmmap-scrn` command specifying one of the required default screening action parameters.

E3081 Cmd Rej: NACTION parameter must be FORWARD, DUPLICATE, or DUPDISC

Commands Used: chg-gsmmap-scrn

The **naction** parameter must have a value of **forward**, **duplicate**, or **dupdisc** before the **npc/npca/npci/npcn/npcn24**, **nssn**, **nri**, **ntt** or **naction** parameters can be specified.

If the **naction** parameter has a value of **forward**, **duplicate**, or **dupdisc**, then the **npc/npca/npci/npcn/npcn24** parameter and the **nssn** parameter must be specified.

Recovery

Re-enter the `chg-gsmmap-scrn` command specifying one of the new screening actions for the forbidden parameters **naction=forward**, **naction=duplicate**, or **naction=dupdisc**.

E3082 Cmd Rej: NDFLTACT must be specified (FORWARD, DUPLICATE, or DUPDISC)

Commands Used: `chg-gsms-opcode`

If the `nmapset`, `nri` or `ntt` parameter is specified, and the `ndfltact` parameter is not specified, then the `ndfltact` parameter must have a previously provisioned value of **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the `chg-gsms-opcode` command specifying one of the required default screening action (`ndfltact`) parameters.

E3083 Cmd Rej: NACTION must be specified (FORWARD, DUPLICATE, or DUPDISC)

Commands Used: `chg-gsmmap-scrn`

If the `nmapset`, `nri` or `ntt` parameter is specified, and the `naction` parameter is not specified, then the `action` parameter (see the `ent-gsmmap-scrn` command) must have a value of **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the `chg-gsmmap-scrn` command specifying one of the required new action screening if forbidden parameters: **naction=forward**, **naction=duplicate**, or **naction=duplicate**.

E3084 Cmd Rej: Both OAM cards must be of the same type

Commands Used: Any command used to update a database

A command was entered to update the system database. The database cannot be updated because the OAM is running on two different types of cards (GPSM-II and MCAP). The two cards that run the OAM must be the same type before you can update the database.

Legacy TDM, GPSM-II, and MDAL cards cannot be installed in the same system as E5-TDM, E5-MCAP, and E5-MDAL cards.

Refer to the *Installation Manual* for information about upgrading the MASP cards. Refer to the *Commands Manual* for more information about specific commands and cards that cannot be provisioned at the same time.

Recovery

1. Replace one of the two OAM cards, so that both cards are the same type.
2. Re-enter the command to update the database.

E3085 Cmd Rej: Cannot change the RC parameter with the ENT command

Commands Used: `ent-mrn`

The `ent-mrn` command cannot be used to change the relative cost (**rc**) assigned to a point code; you must use the `chg-mrn` command.

Recovery

1. Display the point code and its existing relative cost parameter values.
Enter the `rtrv-mrn` command.
2. Change the relative cost for the point code.
Enter the `chg-mrn` command specifying the point code (**pc**) and the new relative cost (**rc**) parameters.

E3086 Cmd Rej: New PC and RC must be entered as a pair

Commands Used: `ent-mrn`

You entered a command to add a new point code to the Mated Relay Node (MRN) table, and you did not specify both the new point code (**pc**) parameter value and the new relative cost (**rc**) parameter value for the point code.

To add a new point code to the MRN Table, both the **pc** and **rc** parameters must be specified. If the **pc** parameter is specified to create a new MRNGROUP, the **pc** cannot already exist in the MRN Table.

If the Flexible GTT Loadsharing feature is enabled, and the **mrnset=new** parameter is specified, the **pc** and **rc** parameters must be specified together in the same command.

Recovery

Re-enter the `ent-mrn` command specifying both the new point code (**pc**) parameter value and the relative cost (**rc**) parameter value for the new point code.

E3087 Cmd Rej: Must enter at least one PC/RC pair

Commands Used: `chg-mrn`, `chg-sccp-serv`, `ent-mrn`

You must specify at least one point code (**pc**) and the relative cost (**rc**) parameter value pair.

For the `chg-mrn` and `ent-mrn` commands, when adding point codes, at least one additional point code must be specified.

When using the `chg-sccp-serv` command to add new point codes or modify relative cost values, at least one **pc/rc** pair (e.g. **pc1, rc1**) must be specified.

Note:

When adding point codes, you cannot specify the **wt** parameter.

Recovery

Re-enter the command specifying at least one point code and relative cost parameter pair.

E3088 Cmd Rej: MEAS Platform must be enabled

Commands Used: `chg-ctrl-feat`, `chg-measopts`, `enable-ctrl-feat`, `rept-ftp-meas`

You entered the `chg-ctrl-feat` command to turn on the 15 Minute Measurements feature but the Measurements Platform collection function is not enabled. You must enable the collection function before you can use this command.

OR

You entered the `chg-measopts` command to turn on the Filename with CLI feature but the Measurements Platform collection function is not enabled. You must enable the Measurements Platform collection function before you can use this command.

OR

You entered the `enable-ctrl-feat` command to turn on the MTP MAP Screening feature but the Measurements Platform collection function is not enabled. Enable the Measurements Platform collection function before using this command.

OR

You entered the `rept-ftp-meas` command to manually initiate generation and FTP transfer of a measurements report from the Measurements Platform to the customer's FTP server. The Measurements Platform collection function is not enabled. You must enable the collection function before you can use this command.



CAUTION:

Once the Measurements Platform collection function has been turned on using the `chg-measopts` command, it cannot be disabled using the `chg-measopts` command. Though it is not recommended, measurements collection can be stopped and started by inhibiting and allowing all MCPM cards. All previous measurements data collected can be lost when you inhibit all MCPM cards, if the cards are removed. Refer to the `chg-measopts`, `alw-card`, and `inh-card` commands in the *Commands Manual* for further information.

Recovery

1. Verify that the Measurements Platform collection function is off (**platformenable=off**).
Enter the `rtrv-measopts` command.
2. Turn on the Measurements Platform collection function, enter the `chg-measopts:platformenable=on` command.
3. When the Measurements Platform collection function is on, you can re-enter the original command.

E3089 Cmd Rej: FTP Server password must be 1 - 15 characters in length

Commands Used: `chg-ftp-serv`, `ent-ftp-serv`

You entered a command to enter or change information for a Measurements Platform FTP server. A prompt appeared asking you for the FTP server password. You either pressed the Return key after the prompt without entering the FTP server password, or you entered a password that was more than 15 characters long.

Recovery

1. Re-enter the command to enter or change the FTP server information.
The password prompt appears again.
2. After the prompt, enter the password for the FTP server, and press the Return key.
The password must be at least 1 character and not more than 15 characters long.

Note:

If you enter an invalid password (you press the Return key without entering a password, or you enter more than 15 characters), you must enter the entire command again to cause the password prompt to appear again. The password that you enter is not displayed as you enter it.

E3090 Cmd Rej: Full Point Code must be specified

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`, `dlt-gta`,
`ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gta`, `rtrv-gta`

If a point code was specified, the point code (`pc/pca/pci/pcn/pcn24` or `np/npc/npci/npcn/npcn24`) must be a full point code. A full point code contains numerical values for all segments of the point code.

Recovery

Re-enter the command specifying a full point code.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3091 Cmd Rej: PC/SSN must be given with Action FORWARD, DUPLICATE, DUPDISC

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `ent-gsmmap-scrn`,
`ent-gsms-opcode`

When you issue a command specifying the parameter `dflfact`, `ndflfact`, `action`, or `naction` set to the value `forward`, `duplicate`, or `dupdisc`, along with the point code and subsystem number parameters.

Recovery -gsmmap-scrn commands

1. If you specified `ent-gsmmap-scrn:action=forward, duplicate, or dupdisc`, you must include the **pc/pca/pci/pcn/pcn24** and **ssn** parameters.
2. If you specified `chg-gsmmap-scrn:naction=forward, duplicate, or dupdisc`, you must include the **npc/npca/npci/npcn/npcn24** and **nssn** parameters.

Recovery -gsms-opcode commands

1. If you specified `ent-gsms-opcode:dfltact=forward, duplicate, or dupdisc`, you must include the **pc/pca/pci/pcn/pcn24** and **ssn** parameters.
2. If you specified `chg-gsms-opcode:ndfltact=forward, duplicate, or dupdisc`, you must include the **npc/npca/npci/npcn/npcn24** and **ssn** parameters.

E3092 Cmd Rej: PC/SSN must be specified if FORCE is specified

Commands Used: `chg-gsmmap-scrn, chg-gsms-opcode, ent-gsmmap-scrn, ent-gsms-opcode`

If you specify the **force** parameter, you must also specify the point code and subsystem number parameters.

Recovery

1. Re-enter the command containing the parameter **force**, specifying either **pc/pca/pci/pcn/pcn24** or **npc/npca/npci/npcn/npcn24** parameters and/or subsystem number point code (**ssn** or **nssn**) parameter.
2. If you used the `chg-gsmmap-scrn` command, specify the **force** parameter with the **npc/npca/npci/npcn/npcn24** and **nssn** parameters
Refer to the *Commands Manual* for the additional information.

E3093 Cmd Rej: EROUTE not Configured

Commands Used: `rept-stat-mon`

At least one STC card must be configured before this command can be entered.

Recovery

1. Display the card information. Enter the `rept-stat-card` command.
2. Verify that at least one STC card is configured in the system.
If an STC card is not installed in the system, then the command cannot be used until STC cards are installed and provisioned.
3. If an STC card is in the system, re-enter the command that generated this error message. If the error occurs again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3094 Cmd Rej: Both OAM cards must be of same type to perform upgrade

Commands Used: `act-upgrade`

A prerequisite of the upgrade is that both OAM cards installed in the system must be of the same type.

Recovery

Prior to performing the upgrade, perform the following actions:

1. Verify the hardware baseline configuration requirements are met.
2. Install the same type of OAM cards (both) in the system.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3095 Cmd Rej: LHOST/ALHOST location not found

Commands Used: `chg-assoc`, `ent-assoc`

A card location associated with the IP address for the host name that you entered in the **lhost** parameter for the command was not found in the IP Link table.

OR

The signaling link associated with the local host that you entered in the **lhost** parameter has not been activated.

Recovery

1. Enter the `rtrv-ip-host` command to display the IP addresses for the host names in the IP Host table.
Verify the IP address for the specified local host name.

2. Enter the `rtrv-ip-lnk` command to verify the card location for the local host name IP address.
3. If the card location for the local host IP address is not shown for the local host IP address in the output from Step 2, enter the `chg-ip-lnk` command to define the card location.

4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

OR

5. Enter the `rtrv-ip-host` command to display the IP addresses for the host names in the IP Host table. Verify the IP address for the specified local host name.
6. Enter the `rtrv-ip-lnk` command to display the card location for the local host name IP address.
7. Enter the `rtrv-slk` command for the local host card location to display the signaling links and ports assigned to the card.
8. Enter the `rept-stat-slk` command to verify the status of the signaling links assigned to the local host card.

9. If the link is not In Service, enter the `act-slk` command to activate the signaling link.
10. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3096 Cmd Rej: Invalid socket/association ratio for card type

Commands Used: `chg-assoc`, `ent-assoc`

You entered a command that would create an invalid socket/association ratio for this type of card.

Recovery

Re-enter the command specifying parameter values that do not create an invalid socket/association ratio for the card.

Refer to the *Commands Manual* for information about socket/association ratios.

E3097 Cmd Rej: GPSM-II required to support more than 700 links

Commands Used: `enable-ctrl-feat`, `ent-slk`

If you entered the `enable-ctrl-feat` command to enable the 6000 Routesets Controlled Feature. To enable the 6000 Routesets feature, both OAM cards in locations (1113 and 1115) must be running GPSM-II cards.

OR

If you entered the `ent-slk` command to assign a signaling link that will result in raising the number of links in the system to greater than 700. To assign more than 700 links in the system, both OAM cards in locations (1113 and 1115) must be running GPSM-II cards.

Recovery - `enable-ctrl-feat`

1. Verify that both of the OAM cards are GPSM-II cards and one of them is running the active OAM application. Enter the following commands: `rept-stat-card:loc=1113` and `rept-stat-card:loc=1115`
2. If neither card is a GPSM-II card running the active OAM, you cannot enable the 6000 Routesets controlled feature. To enable this feature, you must replace both MCAP cards in your system with GPSM-II cards.
3. If one of the two GPSM-II cards is running the active OAM application, re-enter the command to enable the 6000 Routesets controlled feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - `ent-slk`

1. Verify that both of the OAM cards are GPSM-II cards and one of them is running the active OAM application.

Enter the following commands: `rept-stat-card:loc=1113` and `rept-stat-card:loc=1115`

2. If one of the two GPSM-II cards is running the active OAM application, re-enter the `ent-slk` command to assign the signaling link.
3. If neither card is a GPSM-II card running the active OAM, you cannot assign more than **700** links in the system.

To add another link, you must first delete an existing link (refer to the `dlc-slk` command in the *Commands Manual*); or replace both MCAP cards in your system with GPSM-II cards. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3098 Cmd Rej: GTA must not be NONE

Commands Used: `chg-ppsopts`

For the `chg-ppsopts` command, you cannot specify a value of none for the **gta**, **gta1**, **gta2**, and **gta3** parameters.

Recovery

Re-enter the `chg-ppsopts` command specifying a valid value for the **gta**, **gta1**, **gta2**, and **gta3** parameters.

E3099 Cmd Rej: GTA must be specified when NGTA is specified

Commands Used: `chg-gsmopts`, `chg-ppsopts`

For the `chg-gsmopts` command, you cannot specify the `nppmsgta` parameter without specifying the `ppmsgta` parameter. The `nppmsgta` parameter cannot be specified by itself.

For the `chg-ppsopts` command, if you specify the `ngta` parameter, you must also specify the `gta` parameter.

Recovery `chg-gsmopts`

Re-enter the `chg-gsmopts` command specifying both the **ppmsgta** parameter and the **nppmsgta** parameter.

Recovery `chg-ppsopts`

Re-enter the `chg-ppsopts` command specifying both the `ngta` parameter and the `gta` parameter.

E3100 Cmd Rej: GTA doesn't exist in PPSOPTS Table

Commands Used: `chg-ppsopts`

For the `chg-ppsopts` command, if you specify the `ngta` parameter, the `gta` parameter value must already exist in the PPSOPTS table.

Recovery

1. Display the gta parameter values currently in the PPSOPTS table. Enter the `rtrv-ppsopts` command.
2. Re-enter the `chg-ppsopts` command specifying the ngta parameter and a value for the gta parameter that appears in the output from Step 1.

E3101 Cmd Rej: Maximum number of GTAs already provisioned

Commands Used: `chg-ppsopts`

You cannot add a gta value to the PPSOPTS table because the PPSOPTS table is full. A maximum of 32 GTA values (for 32 IN platforms) can be defined in the PPSOPTS table.

Recovery

1. Display the gta parameter values currently in the PPSOPTS table. Enter the `rtrv-ppsopts` command.
2. You can enter the new gta value to the table by changing an existing gta value to the new value. Enter the command specifying an existing gta value (in the output from Step 1) for the gta parameter and the new gta value using the ngta parameter.

E3102 Cmd Rej: NGTA already exists in PPSOPTS Table

Commands Used: `chg-ppsopts`

You entered a command to change an existing gta parameter value to a new ngta parameter value. The new value specified for the ngta parameter cannot already exist in the PPSOPTS table.

Recovery

1. Display the gta parameter values currently in the PPSOPTS table. Enter the `rtrv-ppsopts` command.
2. Re-enter the `chg-ppsopts` command specifying a value for the ngta parameter that does not appear in the PPSOPTS table.

E3103 Cmd Rej: GTT must be ON before XGTT can be enabled

Commands Used: `enable-ctrl-feat`

The GTT feature must be turned on before the XGTT Table Expansion feature can be enabled.

Recovery

1. Display the status of controlled features in the database. Enter the `rtrv-feat` command.
2. From the output from Step 1, verify the XGTT Table Expansion feature has been purchased and installed in your system.

3. Refer to the *Database Administration Manual - Global Title Translation* for part number information required for enabling the GTT feature and the XGTT Table Expansion feature.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3104 Cmd Rej: XGTT requires at least a 586 processor for SCCP GPLs

Commands Used: `enable-ctrl-feat`

You entered a command to enable the Expanded Global Title Translation (XGTT) Table Expansion feature, but one or more SCCP cards in the system have less than a 586 processor. All SCCP cards in the system must have at least 586 processors before you can turn on XGTT.

For the XGTT (269,999 to 400,000 entries) feature, all SCCP GPLs must be running on TSM cards that have at least a 586K processor, or DSM cards, or a combination of TSM and DSM cards.

Recovery

1. Verify that all SCCP cards in the system have at least 586 processors. Enter the `rtrv-card` command to locate all SCCP cards in your system.
2. Refer to the procedure in the *Database Administration Manual - Global Title Translation* to enable and use the XGTT feature.

E3105 Cmd Rej: XGTT requires both OAMs running on GPSMII cards

Commands Used: `enable-ctrl-feat`

You cannot enable the Expanded Global Title Translation (XGTT) Table Expansion feature if both OAM cards are not type GPSM-II. Before the XGTT feature can be enabled, both OAM cards must be of type GPSM-II.

Recovery

1. Verify each OAM card type. Enter the `rtrv-card` command.
2. If both OAM cards are type GPSM-II, enable the XGTT feature. Refer to the procedure "Enabling the XGTT Table Expansion Feature" in the *Database Administration Manual - Global Title Translation*.
3. If both OAM cards are not type GPSM-II, replace the non-GPSM-II OAM cards with GPSM-II cards.
4. Enable the XGTT feature. Refer to the procedure "Enabling the XGTT Table Expansion Feature" in the *Database Administration Manual - Global Title Translation*.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3107 Cmd Rej: XMAP requires at least a 586 processor for SCCP GPLs

Commands Used: `enable-ctrl-feat`

You entered a command to enable the Expanded MAP Table (XMAP) feature, but one or more SCCP cards in the system have less than a 586 processor. Before you can turn on the XMAP feature, all SCCP cards in the system must have at least 586 processors.

Recovery

1. Enter the `rtrv-card` command to locate all SCCP cards in your system.
2. Verify that all SCCP cards in the system have at least 586 processors.
3. Refer to the procedure in the *Database Administration Manual - Global Title Translation* to enable and use the XMAP feature.
4. When all SCCP cards have at least 586 processors, re-enter the `enable-ctrl-feat` command to enable the XMAP feature.

E3108 Cmd Rej: XMAP requires both OAMs running on GPSMII cards

Commands Used: `chg-map`, `enable-ctrl-feat`, `ent-map`

Before the XMAP feature can be enabled, both OAM cards must be of type GPSM-II.

Recovery

1. Verify the type of OAM cards. Enter the `rtrv-card` command.
2. If both OAM cards are type GPSM-II, re-enter the command that generated this error message.
3. If either or both OAM cards are not type GPSM-II, replace any non-GPSM-II card with a GPSM-II card.
Refer to the "Card Removal and Replacement" procedures in Appendix A of the *Maintenance Manual* for additional information.
4. Enable the XMAP feature. Refer to the procedure "Enabling the XMAP Table Expansion Feature" in the *Database Administration Manual - Global Title Translation*.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3109 Cmd Rej: Temporary feature key is not allowed for the feature

Commands Used: `enable-ctrl-feat`

A temporary feature access key cannot be used to enable features that do not allow a temporary feature access key. See the *Commands Manual* for a list of the features that allow a temporary feature access key.

Controlled feature access keys may be temporary or permanent. A temporary feature access key enables a specific controlled feature for a limited period of time, after which the controlled feature is automatically disabled by the system. Features that allow a temporary feature access key are listed in the description of the `enable-ctrl-feat` command in the *Commands Manual*. A permanent feature access key enables a controlled feature indefinitely.

Recovery

1. Display the controlled features that are currently enabled. Enter the `rtrv-ctrl-feat` command.
2. Verify that the part number and FAK are correct for the feature that you want to enable with a temporary FAK.
3. Re-enter the `enable-ctrl-feat` command.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3110 Cmd Rej: Loading Mode unstable due to maint. baseline not established

Commands Used: all `ent/dlt/chg` commands and `init-card`

The command was entered while the MASP was re-initializing.

Note:

Loading mode support denies the execution of LNP database change commands when the system is in an unstable loading mode. An unstable loading mode will result in all STP or LNP database update commands being rejected.

Recovery

Wait until the MASP has re-initialized, then re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3111 Cmd Rej: Loading mode unstable. System's LIM service is unavailable

Commands Used: all `ent/dlt/chg` commands and `init-card`

The command was entered, and the system detected that less than 80% of the system's LIM cards and the minimum number of VSCCP or SCCP cards required to support 80% of the LIM cards are not in service or are inhibited (OOS-MT-DSBLD).

Note:

Loading mode support denies the execution of LNP database change commands when the system is in an unstable loading mode. An unstable loading mode will result in all STP or LNP database update commands being rejected.

Recovery

1. Display the state of the signaling links in the database.
Enter the `rept-stat-slk` command. The state of the signaling links should be either in-service normal (IS-NR) or out-of-service maintenance-disabled (OOS-MT-DSBLD). (As shown in the *PST* field of the `rept-stat-slk` command output).
2. Enter the `inh-slk` command to put every SLK whose state is not IS-NR or OOS-MT-DSBLD into an out-of-service disabled state.

3. Enter the `rept-stat-card` command to display the state of the VSCCP, SCCP, and LIM cards in the database.
The state of all these cards should be IS-NR or OOS-MT-DSBLD. (This is shown in the *PST* field of the `rept-stat-card` output.)
4. Enter the `inh-card:loc=xxxx` command to put all the cards whose state is not IS-NR or OOS-MT-DSBLD in an out-of-service disabled state.
5. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3112 Cmd Rej: Loading Mode unstable due to SCCP service is deficient

Commands Used: all ent/dlt/chg commands, `init-card`

The command was entered, and the system detected that LIM cards are being denied SCCP service or the state of any DSM/TSM card is neither in-service normal (IS-NR) or out-of-service maintenance disabled (OOS-MT-DSBLD).

Note:

Loading mode support denies the execution of LNP database change commands when the system is in an unstable loading mode. An unstable loading mode will result in all STP or LNP database update commands being rejected.

Recovery

1. Display the status of the signaling links in the database with the `rept-stat-slk` command.
The state of the signaling links should be IS-NR or OOS-MT-DSBLD. This is shown in the *PST* field of the `rept-stat-slk` command output.
2. Display the status of the DSM/TSMs in the database with the `rept-stat-sccp` command.
The state of the DSM/TSMs should be in-service normal (IS-NR) or out-of-service maintenance-disabled (OOS-MT-DSBLD). This is shown in the *PST* field of the `rept-stat-sccp` command output.
3. Place the cards shown in Steps 1 and 2 whose state is not IS-NR or OOS-MT-DSBLD out of service, with the `rmv-card` command.
4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3117 Cmd Rej: No available primary MCP

Commands Used: `rept-ftp-meas`, `rept-meas`

A primary MCPM card must be available when the Measurements Platform collection option is enabled and this command is entered.

Recovery

1. Verify the status of MCPM cards in the system.
Enter the `rtrv-card:loc=` and `rept-stat-card:loc=` commands.
2. Verify that the Measurements Platform feature is turned on.
Enter the `rtrv-measopts` command.
3. Re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3119 Cmd Rej: Failed Reading GTT TRANS table

Commands Used: `chg-gta`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `rtrv-gta`

The GTT Trans table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3120 Cmd Rej: Failed reading GTT DBMM table

Commands Used: `chg-gta`, `chg-gttset`, `chg-gttset`, `chg-vflx-vmsid`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `ent-gttset`, `ent-gttset`, `rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`, `dlt-vflx-vmsid`, `ent-vflx-vmsid`

The GTT DataBase Memory Manager (DBMM) table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3121 Cmd Rej: Domain indicated by GTIx must match that of existing TT

Commands Used: `ent-gttset`

The domain you specified with the `gti/gtia/gtii/gtin/gtin24=4` parameter does not match the domain of the translation type (tt). The domain is defined as `gti` and `gtia=ansi`, `gtii=ITU international`, `gtin=ITU national`, and `gtin24=24-Bit ITU national`.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttsel` command.
2. Re-enter the `ent-gttsel` command specifying a value for the GTI domain that matches the translation type's domain.

E3122 Cmd Rej: SERV has not been assigned a true TT

Commands Used: `ent-lnp-serv`

You attempted to enter this command specifying an invalid parameter.

Recovery

Re-enter the `ent-lnp-serv` command that generated this error message specifying the correct parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3123 Cmd Rej: Failed Reading LNP TT SERV table

Commands Used: `chg-lnp-serv`, `dlt-lnp-serv`, `ent-lnp-serv`, `rtrv-lnp-serv`

The LNP TT SERV table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3124 Cmd Rej: Failed Reading LNP SS Appl table

Commands Used: `chg-map`, `chg-ss-appl`, `dlt-ss-appl`, `ent-map`, `ent-ss-appl`, `rtrv-ss-appl`

The LNP TT SS-APPL table is corrupt or cannot be found.

Recovery

1. Re-enter the command that generated this error message.
2. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3132 Cmd Rej: LNP SS Appl table is full

Commands Used: `ent-ss-appl`, `chg-ss-appl`

You attempted to reserve an identifying number for an application's subsystem, but the LNP SS Appl table that contains this information had already reached capacity.

Recovery

1. Display the LNP SS Appl table.
Enter the `rtrv-ss-appl` command.
2. Delete one of the existing service types listed.
Enter the `dlt-ss-appl` command.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3134 Cmd Rej: LNP MR table is full

Commands Used: `ent-ss-appl`, `chg-ss-appl`

You attempted to reserve an identifying number for an application's subsystem, but the LNP MR Appl table that contains this information had already reached capacity.

Recovery

1. Display the LNP MR Appl table.
Enter the `rtrv-ss-appl` command.
2. Delete one of the existing service types listed.
Enter the `dlt-ss-appl` command.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3139 Cmd Rej: Translation Type is already in LNP database

Commands Used: `ent-lnp-serv`, `chg-lnp-serv`

You attempted to enter a translation type that duplicated one that was already on record.

Recovery

1. Enter the `rtrv-lnp-serv` command to retrieve a list of all LNP services and translation types.

2. Perform one of the following actions:
 - a) Use the `chg-lnp-serv` command to change the syntax of the service type that is currently assigned to the translation type, to that of the desired service type.
OR
 - b) Use the `dlt-lnp-serv` command to delete the service type, listed in Step 1, that currently is matched to the translation type.
3. Re-enter the command that generated this error message.

E3140 Cmd Rej: Service Type is already in LNP database

Commands Used: `ent-lnp-serv`

You attempted to enter a service type that is already on record.

Recovery

1. Enter the `rtrv-lnp-serv` command to retrieve a list of all LNP services and translation types.
2. Perform one of the following actions:
 - a) Use the `chg-lnp-serv` command to change the syntax of the service type that is currently assigned to the translation type, to that of the desired service type.
OR
 - b) Use the `dlt-lnp-serv` command to delete the service type, listed in Step 1, that currently is matched to the translation type.
3. Re-enter the command that generated this error message.

E3143 Cmd Rej: New Translation Type already in LNP database

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

The specified new translation type (**ntt**) was not added to the LNP database because it already exists in the LNP database. The new translation type (**ntt**) parameter must not already exist in the LNP database.

A maximum of eight unique LNP services can each be assigned one translation type apiece.

Recovery

1. Display a list of all LNP services.
Enter the `rtrv-lnp-serv` command.
2. Re-enter the `chg-lnp-serv` command specifying an **ntt** that is not listed in the output from Step 1.

E3145 Cmd Rej: New Translation Type Name already in LNP database

Commands Used: `chg-lnp-serv`

The specified new translation type name (**nttn**) was not added to the LNP database because it already exists in the LNP database. The new translation type name (**nttn**) parameter must not already exist in the LNP database.

Up to **eight** unique LNP services can each be assigned one translation type apiece.

Recovery

1. Display a list of all LNP services.
Enter the `rtrv-lnp-serv` command.
2. Re-enter the `chg-lnp-serv` command specifying a **nttn** that is not listed in the output from Step 1.

E3146 Cmd Rej: Service type is not in LNP database

Commands Used: `chg-lnp-serv`, `dlt-lnp-serv`

You cannot change or delete a service type that is not in the LNP database.

Recovery

1. Display a list of all LNP services.
Enter the `rtrv-lnp-serv` command.
2. Perform one of the following actions:
 - a) Use the `chg-lnp-serv` command to change the syntax of one of the existing service types to that of the desired service type.
OR
 - b) Use the `dlt-lnp-serv` command to delete one of the existing service types listed in Step 1.

E3147 Cmd Rej: Translation Type referenced in LNP database

Commands Used: `dlt-lnp-serv`

A translation type cannot be deleted if it is referenced by a current LNP database entry.

Recovery

1. Display the GTT table.
Enter the `rtrv-gtt` command.
2. Delete the global title translation entry associated with the translation type to be deleted.

Enter the `dlt-gtt` command.

3. Delete the translation type.

Enter `dlt-tt:type=` OR

4. Change the `tt-service` combination. Enter the `chg-lnp-serv` command.
5. Re-enter the `dlt-lnp-serv` command that generated this error message.
6. If the database needs to be rebuilt, call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3148 Cmd Rej: Translation Type Name is not in the LNP database

Commands Used: `ent-lnp-serv`, `chg-lnp-serv`

The specified LNP service was not entered or changed because the specified translation type name (`ttn`) does not exist in the LNP database.

Recovery

1. Display a list of valid translation types.
Enter the `rtrv-lnp-serv` command.
2. Re-enter the command that generated this error message specifying a valid translation type name (`ttn`) from the output from Step 1.

E3149 Cmd Rej: Maximum number of applications already assigned

Commands Used: `ent-ss-appl`

You attempted to add one more subsystem application than the system was designed to process.

Note:

This error is currently handled by error message E3266. Should you see this error, though, follow the instructions below.

Recovery

1. Enter the `rtrv-ss-appl` command to retrieve a list of all subsystem applications.
2. Use the `dlt-ss-appl` command to delete one of the existing subsystem applications listed in Step 1.
3. Re-enter the `ent-ss-appl` command that generated this error message.

E3150 Cmd Rej: Application already assigned

Commands Used: `ent-ss-appl`

You attempted to add a duplicate subsystem application.

Recovery

1. Display a list of all subsystem applications.
Enter the `rtrv-ss-appl` command.
2. Delete one of the existing subsystem applications listed in Step 1.
Enter the `dlt-ss-appl` command.
3. Re-enter the `ent-ss-appl` command that generated this error message.

E3152 Cmd Rej: Application type not in LNP database

Commands Used: `chg-ss-appl`, `dlt-ss-appl`

You attempted to change or delete a subsystem application with a type that is not listed in the database.

Recovery

1. Display a list of all subsystem applications.
Enter the `rtrv-ss-appl` command.
2. Delete one of the existing subsystem applications listed in Step 1.
Enter the `dlt-ss-appl` command.
3. Re-enter the `ent-ss-appl` command that generated this error message.

E3153 Cmd Rej: Subsystem must be inhibited before it can be OFFLINE

Commands Used: `chg-ss-appl`

This command changes the status of the LNP subsystem application between offline and online. You must inhibit the LNP subsystem before taking it offline.

Recovery

1. Determine the subsystem number (**ssn**) for the LNP subsystem.
Enter the `rtrv-ss-appl` command.
2. Inhibit the LNP subsystem.
Enter the `inh-map-ss` command specifying the **ssn** for the LNP subsystem.
3. Change the status of the LNP subsystem to offline.
Enter the `chg-ss-appl:appl=lnp:nstat=offline` command.

E3154 Cmd Rej: Subsystem must be in opposite state of change

Commands Used: `chg-ss-appl`

The state of the subsystem is already online (or offline).

Recovery

No action required.

E3155 Cmd Rej: Subsystem must be inhibited before it can be deleted

Commands Used: `dlt-ss-appl`

You must inhibit the subsystem before you can delete it.

Recovery

1. Determine the subsystem number (**ssn**) for the LNP subsystem.
Enter the `rtrv-ss-appl` command.
2. Inhibit the LNP subsystem.
Enter the `inh-map-ss` command specifying the **ssn** parameter value for the LNP subsystem.
3. Delete the LNP subsystem.
Enter the `dlt-ss-appl:appl=lnp` command.

E3172 Cmd Rej: Alias is not assigned to SERV

Commands Used: `dlt-lnp-serv`

The alias you entered must be associated with the LNP service you are trying to delete.

Recovery

1. Display a list of the LNP services and their associated aliases.
Enter the `rtrv-lnp-serv` command.
2. Re-enter the `dlt-lnp-serv` command that generated this error message specifying the correct alias parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3177 Cmd Rej: FORCE=YES must be specified if NUM is greater than 50

Commands Used: `rtrv-home-smsc, rtrv-loopset, rtrv-srvsel`

When the specified **num** parameter value is greater than 50, the **force=yes** parameter must also be specified. If the **num** parameter is set to a value greater than 50, the **force=yes** parameter must be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **force=yes** parameter.
- Re-enter the command specifying a value less than **50** for the **num** parameter.
- Re-enter the command without specifying a **num** parameter value.

E3198 Cmd Rej: Failed reading LNP Options table

Commands Used: `chg-lnpopts`, `rtrv-lnpopts`

The LNP Options table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3199 Cmd Rej: To change or delete SERV, it must have no LNP aliases

Commands Used: `dlt-lnp-serv`, `chg-lnp-serv`

You must delete all aliases associated with the LNP service before you can change or delete the service.

Recovery

1. Display a list of the LNP services, and their associated aliases.
Enter the `rtrv-lnp-serv` command.
2. Delete the aliases associated with the LNP service you are trying to change or delete.
3. Delete or change the desired LNP service.
Re-enter the command that generated this error message. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3200 Cmd Rej: TST-DISK command prevented

Commands Used: `tst-disk`

If an E5-MCAP card is installed, then the `tst-disk` command cannot be entered when other database commands are running.

Recovery

Re-enter the `tst-disk` command once the database commands have completed. Refer to the *Commands Manual* for more information about test disk execution times.

E3202 Cmd Rej: TST-DISK not allowed on Active TDM

Commands Used: `tst-disk`

If an E5-TDM card is installed, then the **disk=fixed** parameter cannot be specified.

Recovery

Re-enter the `tst-disk` command, without specifying the **disk=fixed** parameter.

Contact the Customer Care Center if this message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3209 Cmd Rej: CPCTYPE cannot be specified without CPC

Commands Used: `chg-sid`

You specified the **cpctype** parameter, but did not specify a **cpc** parameter. If the **cpctype** parameter is specified, a **cpc**, **cpc**, **cpci**, **cpcn**, or **cpcn24** parameter must be specified in the command.

Recovery

Re-enter the `chg-sid` command specifying both the **cpc** parameter and the **cpctype** parameter.

E3210 Cmd Rej: CPCTYPE cannot be specified with NCPC

Commands Used: `chg-sid`

The **cpctype** and **ncpc** parameters cannot be specified together. If the **cpctype** parameter is specified, an **ncpc**, **ncpca**, **ncpci**, **ncpcn**, or **ncpcn24** parameter cannot be specified in the command.

Recovery

Re-enter the `chg-sid` command specifying either the **cpctype** or the **ncpc** parameter, but not both.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3215 Cmd Rej: Cannot access GSERV table

Commands Used: `dlt/ent/rtrv-gserv-data`

The system is busy or the GSERV table is corrupt.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3216 Cmd Rej: G-Port SRI Query for Prepaid feature is not enabled

Commands Used: `chg-gsmopts`, `dlt-gserv-data`, `ent-gserv-data`, `rtrv-gserv-data`

The G-Port SRI Query for Prepaid feature must be enabled before the `dlt/ent/rtrv-gserv-data` commands can be entered.

For the `chg-gsmopts` command, the feature must be enabled before the `dfltrn` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - G-Port* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3217 Cmd Rej: DUAL OAP configuration is needed for LNP feature

Commands Used: `act-oap-config`

You cannot specify a value of single for the OAP configuration parameter (`cfg=sngl`). The LNP feature requires that a dual OAP configuration (`cfg=dual`) be specified.

Recovery

1. Display the OAP configuration.
Enter the `rtrv-oap-config` command.
2. If the OAP configuration indicates single (`cfg=sngl`), change it to dual.
Enter `chg-oap-config:cfg=dual` command.
3. Verify the OAP configuration changed to dual.
Re-enter the `rtrv-oap-config` command.
4. Re-enter the `act-oap-config` command.

E3220 Cmd Rej: CPCx must be ANSI if CPCTYPE equals LNP

Commands Used: `chg-sid`

When the `cpctype=lnp` parameter is specified, the `cpc` parameter or the `cpca` parameter must be specified with an ANSI point code value.

Recovery

1. Display the necessary information about the current self-identification.
Enter the `rtrv-sid` command.
2. Perform one of the following actions:
 - a) If the output of Step 1 indicates that the `cpctype=stp`, re-enter the `chg-sid` command that generated this error message specifying the correct `cpctype` parameter value.
OR
 - b) If the output of Step 1 indicates that the `cpctype=lnp`, the appropriate capability point code parameter will be either `cpci` or `cpcn`.
Re-enter the `chg-sid` command that generated this error message specifying the correct `cpcx` parameter value.

E3225 Cmd Rej: NONE is a reserved name and cannot be used for a TTN

Commands Used: `ent-lnp-serv`

When you entered this command to reserve an LNP translation type for a unique LNP service, you attempted to assign the only forbidden name (**none**) to the translation type. You can define the translation type by any alphabetic string from 1 to 8 characters long, except for `ttn=none`.

Recovery

Re-enter the `ent-lnp-serv` command specifying the `ttn` parameter as an alphabetic string from 1 to 8 characters long, excluding `ttn=none`.

E3226 Cmd Rej: New digits valid (DV) must not match old DV indication

Commands Used: `chg-lnp-serv`

The value specified for the new digits valid (**ndv**) parameter cannot be the same as the value specified for the old (or current) digits valid indication (**dv**) parameter.

Recovery

Perform one of the following actions:

- Re-enter the `chg-lnp-serv` command without specifying the `ndv` parameter.
OR
- Re-enter the `chg-lnp-serv` command specifying a different value for the `ndv` parameter.

E3233 Cmd Rej: System serial number has not been locked

Commands Used: `enable-ctrl-feat`

The system serial number must be locked in the database before you can enable the specified feature.

Note: Contact your Customer Care Center and refer to the `ent-serial-num` command in the *Commands Manual* before you use the command to lock the Serial Number table. If you inadvertently enter and lock an incorrect serial number in the database, a manual procedure and a system disk are required from Tekelek.

Recovery

1. Enter the `rtrv-serial-num` command to verify that the correct serial number has been entered for your system.
2. If the correct serial number has been entered but not locked, enter the `ent-serial-num` command with the correct serial number and the `lock=yes` parameter.
3. If the serial number has not been entered for your system, contact your system administrator and refer to the `ent-serial-number` command in the *Commands Manual* for the procedure and information to enter and lock the correct serial number.
4. Re-enter the `enable-ctrl-feat` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3239 Cmd Rej: Point Code must be the STP True point code

Commands Used: `ent-map`

You specified the wrong value for the `pc/pca/pci/pcn` parameter. When specifying a MAP entry for LNP subsystems, only the STP's true point code can be entered.

Recovery

1. Display the correct site identification number for this STP.
Enter the `rtrv-sid` command.
2. Re-enter the command that generated this error message specifying the point code value for this STP.

E3243 Cmd Rej: Unknown hardware configuration

Commands Used: `enable-ctrl-feat`

A card with unknown hardware is detected in system (possibly in the process of loading, or a loading error has occurred).

Recovery

Call your Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E3244 Cmd Rej: UIM number does not exist in UIM Threshold table

Commands Used: `dlt-uim-acthresh`

You specified an invalid UIM number. The UIM number must exist in the UIM Threshold Table.

Recovery

1. Verify that you have typed the UIM number correctly.
If necessary, enter the `rtrv-uim-acthresh` command to retrieve a list of valid UIM numbers.
2. Re-enter the `dlt-uim-acthresh` command specifying a valid UIM number.

E3245 Cmd Rej: PLNP feature must be ON

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

You entered a value of `pcs` for the `serv` or `nserv` parameter, which requires that the PLNP (PCS 1900 LNP) Feature be on.

Recovery

Perform one of the following actions:

- Re-enter the command specifying a value other than `pcs` for the `serv` parameter.
OR
- Verify that the PLNP feature is on. Enter the `rtrv-feat` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

- If the PLNP feature is off, turn it on. Enter the `chg-feat:plnp=on` command.
- Re-enter the `ent-lnp-serv` command specifying `serv=pcs`.
OR
- Re-enter the `chg-lnp-serv` command specifying `nserv=pcs`.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3250 Cmd Rej: DV must be SCCP when SERV is a user defined type

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

You entered the command and specified one of the user-defined type values (**udf1-udf6**) for the **serv** parameter, but you did not specify a value of **sccp** for the digits valid (**dv** or **ndv**) parameter. If you specify a user-defined type value for the **serv** parameter, you must specify the **dv/ndv=sccp** parameter.

Recovery

Re-enter the command as you entered it originally with a user defined type value for the **serv** parameter and specifying the **dv/ndv=sccp** parameter.

E3251 Cmd Rej: If specified, (N)DV must be TCAP for specified service

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

If the **lnpqs**, **ain**, **in**, **pcs**, **wnp**, or **lnqt** values are specified for the **serv** parameter, then the **dv=tcap** parameter must be specified.

Recovery

Re-enter the command that generated this message with either **lnpqs**, **ain**, **in**, **pcs**, **wnp**, or **lnqt** as the value for the **serv** parameter, specifying the **dv=tcap** parameter.

If this error message appears again, call the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3252 Cmd Rej: A TTN-reserved service type name only if it matches SERV

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

You specified the **ttn** parameter set to a reserved service type name that did not match the one assigned to the **serv** parameter.

Recovery

Perform one of the following actions:

- Re-enter the command setting the **ttn** parameter to a non-reserved service type name.
- Re-enter the command setting the **ttn** parameter to match the one assigned to the **serv** parameter.

E3260 Cmd Rej: GSERV Table is full

Commands Used: `ent-gserv-data`

A new entry cannot be added to the GSERV table because the GSERV table is full.

Recovery

1. Display all values in the GSERV table.
Enter the `rtrv-gserv-data:display=all` command.

Note:

A maximum of 256 tt values, 50 gta values, and 50 opc values can be provisioned in the GSERV table.

2. Determine which parameter value (**gta**, **opc**, or **tt**) is at the maximum limit as noted above.
3. Delete an existing entry in the GSERV table.
Enter the `dlt-gserv-data` command.
4. Re-enter the **ent-gserv-data** command that generated this error message.
Call your Customer Care Center if this error message appears again.

E3266 Cmd Rej: Only 6 message relay services can be assigned

Commands Used: `ent-lnp-serv`

This service cannot be provisioned as it may prevent future provisioning of the AIN and/or IN service(s).

Recovery

Retrieve a list of defined service types, and verify that six message relay or user-defined services have already been assigned. Enter the `rtrv-lnp-serv` command.

E3269 Cmd Rej: Invalid H0/H1 or NH0/NH1 specified

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`

An invalid combination of **h0** and **h1** parameters and/or **nh0** and **nh1** parameters was specified. [Table 18: Valid h0/h1 or nh0/nh1 Parameter Combinations](#) describes the valid combinations of the parameters.

Table 18: Valid h0/h1 or nh0/nh1 Parameter Combinations

h0 (nh0) parameter	h1 (nh1) parameter
A single value	A single value
A single value	A range
A single value	An asterisk (*) entry
A range	An asterisk (*) entry
An asterisk (*) entry	An asterisk (*) entry

When entering the `chg-scr-sio` command, the values specified for the `nh0` or `nh1` parameters must be valid for the `h0` or `h1` values already in the database.

Recovery

Re-enter the command specifying a valid combination of parameters from the preceding table.

E3271 Cmd Rej: NSFI is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-isup`, `chg-scr-opc`, `chg-scr-sio`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`, `ent-scr-destfld`, `ent-scr-isup`, `ent-scr-opc`, `ent-scr-sio`, `ent-scr-tt`, `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-destfld`, `rtrv-scr-isup`, `rtrv-scr-sio`, `rtrv-scr-tt`

A valid value must be specified for the `nsfi` parameter. [Table 19: Valid Values for the nsfi Parameter](#) lists the supported values.

Table 19: Valid Values for the nsfi Parameter

Commands	Valid Values
<code>chg-scr-aftpc</code> , <code>ent-scr-aftpc</code> , <code>rtrv-scr-aftpc</code>	stop
<code>chg-scr-blkdpc</code> , <code>ent-scr-blkdpc</code>	cgpa , stop , fail , or destfld
<code>chg-scr-blkopc</code> , <code>ent-scr-blkopc</code>	stop , fail , dpc , blkdpc , sio , or cgpa
<code>chg-scr-cdpa</code> , <code>ent-scr-cdpa</code> , <code>rtrv-scr-cdpa</code>	stop or aftpc
<code>chg-scr-cgpa</code> , <code>ent-scr-cgpa</code>	stop , cdpa , or tt
<code>chg-scr-destfld</code> , <code>ent-scr-destfld</code> , <code>rtrv-scr-destfld</code>	stop
<code>chg-scr-dpc</code> , <code>ent-scr-dpc</code>	stop , blkdpc , cgpa , or destfld
<code>chg-scr-opc</code> , <code>ent-scr-opc</code>	stop , sio , dpc , blkopc , blkdpc , or cgpa
<code>chg-scr-sio</code> , <code>ent-scr-sio</code> , <code>rtrv-scr-sio</code>	stop , cdpa , dpc , blkdpc , cgpa , or destfld Specify nsfi=destfld only if si=00 . Specify nsfi=cdpa or nsfi=cgpa only if si=03 .

Commands	Valid Values
	Specify nsfi=isup only if si=05 .
<code>ent-scr-tt, rtrv-scr-tt</code>	stop or cdpa

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a valid **nsfi** parameter.
- OR
- Re-enter the command that generated this error message without specifying the **nsfi** parameter.

E3272 Cmd Rej: PC does not match existing entry in given SR

Commands Used: `chg-scr-blkdpc, chg-scr-blkopc, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-destfld, dlt-scr-dpc, dlt-scr-opc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-dpc`

The values specified for the area, **id**, **msa**, **narea**, **nc**, **ncm**, **ni**, **nid**, **nnpc**, **npc**, **nsp**, **nssa**, **nzone**, **sp**, **ssa**, or **zone** point code parameters do not match the existing entry specified by the screening reference (**sr**) parameter. The blocked OPC or DPC defined must already exist in the screening reference.

Recovery

1. Determine the valid settings for the point code and screening reference parameters.
Enter the `rtrv-scr-blkdpc` command.
2. Re-enter the command specifying the correct point code parameter value.
3. Re-enter the command specifying the correct **sr** parameter value.

E3273 Cmd Rej: NIC, SI, H0/H1,& PRI entry already exist in given SR

Commands Used: `chg-scr-sio, ent-scr-sio`

You entered this command specifying the **h0/h1**, **nic**, **orpri**, **si** parameter set to a value that matches an existing entry specified by the screening reference (**sr**) parameter.

Recovery

1. Determine the valid settings for the screening reference parameter.
Enter the `rtrv-scr-sio` command.
2. Re-enter the command specifying the correct screening reference (**sr**) parameter value.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3276 Cmd Rej: Command not allowed while in upgrade mode

Commands Used: `act-cdl`, `act-lbp`, `aud-data`, `chg-db`, `chg-measopts`, `chg-mtc-measopts`, `dact-cdl`, `dact-lbp`, `inh-alm`, `rept-stat-cdl`, `rept-stat-ddb`, `rept-stat-lfs`, `rept-stat-tstslk`, `rtrv-measopts`, `rtrv-mtc-measopts`, `tst-slk`, `unhb-alm`

If the system is in upgrade mode, then this command cannot be entered.

Recovery

Wait until the system has completed the upgrade that is in progress; then re-enter the command.

E3278 Cmd Rej: RMIN must be less than or equal to RMAX

Commands Used: `chg-assoc`

You cannot specify a value for the **rmin** parameter that is greater than the specified **rmax** value. The value specified for the **rmin** parameter must be less than or equal to the value specified for the **rmax** parameter.

Recovery

Re-enter the `chg-assoc` command specifying a value for the **rmin** parameter that is less than or equal to the value specified for the **rmax** parameter.

E3279 Cmd Rej: CWMIN must be less than or equal to assoc BUFSIZE

Commands Used: `chg-assoc`

You entered a command for an IPGWx association, and specified a value for the **cwmin** parameter that is greater than the value specified for the **bufsize** parameter.

The value specified for the **cwmin** parameter must be less than or equal to the value specified for the **bufsize** parameter.

Recovery

Re-enter the `chg-assoc` command specifying the **cwmin** value less than or equal to the value specified for the **bufsize** parameter.

E3280 Cmd Rej: SLK IPLIML2 requires linkset MTPRSE setting to be no

Commands Used: `chg-ls`, `ent-slk`

The **mtpmse** parameter value must be **no** (`mtpmse=no`) for linksets that contain IPLIMx-M3UA signaling links.

Recovery - chg-ls

1. Verify that the linkset contains IPLIMx M3UA links (the IPLIML2 column says M3UA for the link). Enter the `rtrv-slk` command specifying the `lsn` parameter for the linkset for which you want to change the `mtprse` value.
2. If the linkset contains IPLIMx M3UA links, you cannot change the `mtprse` parameter value to **yes** for the linkset.

Refer to the *Database Administration Manual - SS7* for procedures to define linksets and signaling links.

3. If the linkset does not contain IPLIMx M3UA links, re-enter the `chg-ls` command that generated this error.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - ent-slk

1. Verify that you entered the correct linkset name (`lsn`) in the command.
2. Enter the `rtrv-ls` command specifying the `lsn` parameter for the linkset to which you want to add the link.

Verify the `mtprse` value for the linkset.

3. If the `mtprse` value for the linkset is **yes**, you must either add the link to another linkset that has `mtprse=no`, or change the `mtprse` value to **no** for this linkset.

Refer to the *Database Administration Manual - SS7* for procedures to define linksets and signaling links.

4. Re-enter the `ent-slk` command that generated this error in order to add the link to a linkset that has `mtprse=no`.

E3281 Cmd Rej: IPLIML2 is only valid for IPLIMx SLK

Commands Used: `ent-slk`

The `ipliml2` parameter can be specified only for IPLIM cards.

Recovery

1. If the signaling link is not an IPLIMx signaling link, re-enter the `ent-slk` command without specifying the `ipliml2` parameter.
2. If the signaling link is an IPLIMx signaling link, re-enter the `ent-slk` command specifying the `ipliml2` parameter.

E3282 Cmd Rej: Failed reading the SAPC table

Commands Used: `chg-ls`, `chg-rte`, `dlt-dstn`, `dlt-ls`, `ent-ls`, `ent-rte`

The SAPC table is corrupt or cannot be found.

Recovery

1. Re-enter the command that generated this error message.
2. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3285 Cmd Rej: Cannot change existing STP True PC if in MAP table

Commands Used: `chg-sid`

The existing true point code cannot be changed if it is in the MAP table.

Recovery

1. Display the system's true point code.
Enter the `rtrv-sid` command. The system's true point code is shown in the *PCA* field.
2. Display the mated applications Enter the `rtrv-map` command.
The point codes are shown in the *PCA* field.
3. Delete the system's true point code from the mated applications table.
Enter the `dlt-map` command.
4. Re-enter the `chg-sid` command.
5. Assign the new true point code of the system to the mated applications (MAP) table.
Enter the `ent-map` command.

E3286 Cmd Rej: STP True PC does not exist in MAP table

Commands Used: `ent-ss-appl`

You attempted to reserve an LNP subsystem number (**ssn**) for an application, but no STP true point code exists in the mated applications (MAP) table.

Recovery

1. View a list of (**pc/pca/pci/pcn**) point codes assigned to the EAGLE 5 ISS.
Enter the `rtrv-sid` command.
2. Assign mated application values to the true point code (**pc/pca/pci/pcn**) and subsystem number (**ssn**).
Enter the `ent-map` command.
3. Re-enter the `ent-ss-appl` command specifying the assigned values for the **pc/pca/pci/pcn** and **ssn**.

E3287 Cmd Rej: Map with STP True PC has a local subsystem SS-APPL assigned

Commands Used: `dlt-map`

An STP true point code that is assigned to an INP, LNP, EIR, V-Flex, or ATINPQ subsystem cannot be deleted.

Recovery

1. Display the applications in the database.
Enter the `rtrv-ss-appl` command.
2. Using the output of Step 1, perform the following command(s):
 - a) If an LNP subsystem exists, inhibit the LNPOQS subsystem.
Enter the `inh-map-ss` command specifying the `ssn` parameter value. Then delete the application from the LNP database. Enter the `dlt-ss-appl:appl=lnp` command.
 - b) If an INP subsystem exists, delete the application from the INP database.
Enter the `dlt-ss-appl:appl=inp` command.
 - c) If an EIR subsystem exists, delete the application from the EIR database.
Enter the `dlt-ss-appl:appl=eir` command.
 - d) If a V-Flex subsystem exists, delete the application from the V-Flex database.
Enter the `dlt-ss-appl:appl=vflex` command.
3. Delete the appropriate MAP.
Re-enter the `dlt-map` command specifying values for the `pc/pca` and `ssn` parameters.

E3288 Cmd Rej: STP True PC and LNP SSN do not exist in MAP table

Commands Used: `ent-ss-appl`

To reserve an LNP subsystem number (`ssn`) for an application requires an STP true point code/subsystem number combination to be defined in the Mated Applications (MAP) table.

Recovery

1. View the point codes (`pca`) assigned to the EAGLE 5 ISS.
Enter the `rtrv-sid` command.
2. Assign mated application values for the true point code (`pc/pca`) and subsystem number (`ssn`).
Enter the `ent-map` command.
3. Re-enter the `ent-ss-appl` command specifying the newly assigned values for `pc/pca` and `ssn` parameters.

E3289 Cmd Rej: Must specify NC when NI is specified for ORIGNINC

Commands Used: `rept-meas`

The network cluster (**nc**) parameter must be specified whenever the network indicator (**ni**) parameter is specified.

Recovery

Perform one of the following actions:

- Re-enter the `rept-meas` command specifying the other optional parameter.
- Re-enter the `rept-meas` command but do not specify the **ni** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3290 Cmd Rej: No more subsystem can be provisioned with specified True PC

Commands Used: `chg-map`, `ent-map`

The maximum number of possible entries in the MAP table has been reached for the specified True Point code.

Recovery

Re-enter the command that generated this error message specifying an appropriate true point code. Refer to the *Commands Manual* for assistance if necessary.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3291 Cmd Rej: Card location specified must be an OAM card

Commands Used: `clr-disk-stats`, `disp-disk-stats`, `init-flash`

You attempted to enter this command specifying an invalid **loc** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct **loc** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3292 Cmd Rej: Must specify either: ENTRY or ROW with COLUMN

Commands Used: `disp-tbl`, `set-tbl`

The command was entered specifying an invalid combination of the **entry**, **row**, and **column** parameters. The **row** parameter must be specified with the **column** parameter. The **entry** parameter cannot be specified with either the **row** or **column** parameters.

Recovery

Re-enter the command specifying either the **entry** parameter, or the **column** and **row** parameters.

E3293 Cmd Rej: Invalid offset

Commands Used: `disp-tbl`, `set-lba`, `set-tbl`

The value specified for the **offset** parameter was not valid.

Recovery

Re-enter the command specifying the correct **offset** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3294 Cmd Rej: Security tables may not be altered

Commands Used: `disp-tbl`, `set-lba`, `set-tbl`

The table specified by the **tblid** parameter is either the Security Log, User ID, or Password table. These tables cannot be altered.

Recovery

Re-enter the command specifying the correct **tblid** parameter value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3295 Cmd Rej: DEBUG must be ON

Commands Used: `disp-tbl`, `set-lba`, `set-tbl`

The specified command could not be executed because the debug function is turned off.

Recovery

Contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3296 Cmd Rej: A timeout occurred while processing SCSI Debug Command

Commands Used: `disp-disk-dir`, `disp-lba`, `disp-tbl`, `set-lba`, `set-tbl`, `tst-disk`

A timeout occurred on the SCSI device before or during the processing of this command.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3297 Cmd Rej: Failed reading trouble text table

Commands Used: `set-uim-acthresh`

The Trouble Text Table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3298 Cmd Rej: If specified, BPS must be 2048000 for LIME1ATM Card

Commands Used: `ent-slk`

You specified parameters for a high-speed link on an E1 ATM card (card type `lime1atm`) and but did not specify **2048000** for the `bps` parameter (`bps=2048000`). For an E1 ATM link, the `bps` parameter value must be **2048000**.

Recovery

Re-enter the `ent-slk` command specifying `bps=2048000`.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3299 Cmd Rej: Network Security Enhancements feature must be ON

Commands Used: `chg-stpopts`

The `secmtpmate`, `secmtpsid`, `secmtpsnm` and `secscpcscmg` parameters cannot be specified unless the Network Security Enhancements controlled feature has been enabled and turned on.

Recovery

1. Display the status of features in your system that have feature access keys.
Enter the `rtrv-ctrl-feat` command.
2. Refer to the procedure in the *Database Administration* Manual–System Management to enable and turn on the Network Security Enhancements feature.
Call your Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.
3. Re-enter the `chg-stpopts` command specifying the parameters that generated this error message.

E3300 Cmd Rej: Value <data> not supported for <parm> parameter in this implementation (C<col>)

Commands Used: all OAP commands

The command you entered contains characters (<data>) not supported for the specified parameter (<parm>). (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying a valid value and format for this command parameter.

Refer to the *Commands Manual* for the range of values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3301 Cmd Rej: Value <data> for <parm> parameter not consistent with a previous parameter (C<col>)

Commands Used: all OAP commands

The command you entered contains characters (<data>) inconsistent with a previous parameter specified by <parm>. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying a valid value and format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3302 Cmd Rej: Data missing for <parm> parameter (C<col>)

Commands Used: all OAP commands

The command entered does not contain data essential for the parameter specified by <parm>. (C<col>) indicates the column number of the last character of the data that generated the error message.

Recovery

Re-enter the command specifying an appropriate format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3303 Cmd Rej: Value <data> for <parm> parameter is not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid value (<data>) in the parameter specified by <parm>. (C<col>) indicates the column number of the last character of the data that generated the error message.

Recovery

Re-enter the command specifying a valid value and format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3304 Cmd Rej: Unexpected character(s) <data> after <parm> (C<col>)

Commands Used: all OAP commands

The command you entered contains unexpected characters (<data>) for the specified parameter (<parm>). (C<col>) indicates the column number of the last character of the data that generated the error message.

Recovery

Re-enter the command specifying a valid value and format for this command parameter.

Refer to the *Commands Manual* for the range of values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3305 Cmd Rej: Input syntax: punctuation error (C<col>)

Commands Used: all OAP commands

The command you entered contains a violation of its input syntax, and a punctuation error was detected. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the range of values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3306 Cmd Rej: Value <data> out of range for <parm> parameter (C<col>)

Commands Used: all OAP commands

The command you entered contains an value (<data>) that is out of the allowable range for the parameter specified by <parm>. (C<col>) indicates the column number of the last character of the data that generated the error message.

Recovery

Re-enter the command specifying an in-range value and proper format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3307 Cmd Rej: Too many parameters specified for <parm> block (C<col>)

Commands Used: all OAP commands

The command you entered contains too many parameters for the block specified by <parm>. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct values and proper format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3308 Cmd Rej: Link set argument - not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid linkset argument. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3309 Cmd Rej: Rejection threshold argument - not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid rejection threshold argument. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3310 Cmd Rej: Message threshold argument - not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid message threshold argument. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3311 Cmd Rej: Event interval argument - not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid event interval argument. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3312 Cmd Rej: Occurrence argument - not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid occurrence argument. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3313 Cmd Rej: Minutes argument - not valid (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid minutes argument. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3314 Cmd Rej: <command> command not supported by this implementation (C<col>)

Commands Used: all OAP commands

The command you entered <command> is invalid because it is not supported by the current implementation. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3315 Cmd Rej: <command> command not recognized (C<col>)

Commands Used: all OAP commands

The command you entered <command> is invalid because it cannot be recognized. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command.

Refer to the *Commands Manual* for the correct values and format for this command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3316 Cmd Rej: Input parameter argument - version range error (C<col>)

Commands Used: all OAP commands

The command you entered contains an unacceptable input parameter argument resulting from a version range error. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3317 Cmd Rej: Input parameter argument - range error (C<col>)

Commands Used: all OAP commands

The command you entered contains an unacceptable input parameter argument, resulting from a range error in a sequence-number parameter. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter, specifically for the sequence-number parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3318 Cmd Rej: Input parameter argument - flow-thru command string too long (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid input parameter argument, caused by a flow-thru command string that is too long. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter, specifically for the sequence-number parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3319 Cmd Rej: Input parameter argument - point code range error (C<col>)

Commands Used: all OAP commands

The command you entered contains an invalid input parameter argument caused by a point code range error. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter, specifically for the sequence-number parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3320 Cmd Rej: Input parameter argument - range error (C<col>)

Commands Used: all OAP commands

The command you entered contains an unacceptable input parameter argument, resulting from a range error. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter, specifically for the sequence-number parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3321 Cmd Rej: Quoted string too long (C<col>)

Commands Used: all OAP commands

The command you entered contains a quoted string in error because it is too long. C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter, specifically for the sequence-number parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3322 Cmd Rej: Input parameter '<parm>' - missing (C<col>)

Commands Used: all OAP commands

The command you entered is in error because input parameter <parm> is missing. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying an in-range value and proper format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3323 Cmd Rej: No value expected for '<parm>' parameter (C<col>)

Commands Used: all OAP commands

The command you entered is invalid because the input parameter *<parm>* contains a value when none is expected. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying an in-range value and proper format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3324 Cmd Rej: Input parameter - use of parameter not supported by this implementation (C<col>)

Commands Used: all OAP commands

The command you entered is erroneous because the use of an input parameter is not supported by this implementation. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying an in-range value and proper format for this command parameter.

Refer to the *Commands Manual* for the format and valid values for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3325 Cmd Rej: Input parameter argument - not valid or superfluous (C<col>)

Commands Used: all OAP commands

The command you entered contains an input parameter argument unacceptable because it is invalid or superfluous. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3326 Cmd Rej: System error - software - an attempted buffer overrun has been detected by the SEAS UPL parser (C<col>)

Commands Used: all OAP commands

A system software error has occurred: the SEAS UPL parser has detected an attempted buffer overrun. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3327 Cmd Rej: Eagle can only accept messages of 450 or fewer bytes (C<col>)

Commands Used: all OAP commands

A system software error has occurred: the EAGLE 5 ISS has received a message longer than 450 bytes. (C<col>) indicates the column number of the last character of the data that generated this error message.

Recovery

Re-enter the command specifying the correct syntax and format for this command parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3328 Cmd Rej: GSERV Entry does not exist

Commands Used: dlt-gserv-data

The specified translation type (**tt**), originating point code (**opc/opca/opci/opcn/opcn24**), or global title address (**gta**) parameter does not exist in the GSERV table.

Note:

A maximum of 256 tt values, 50 gta values, and 50 opc values can be provisioned in the GSERV table.

Recovery

1. Display the entries in the GSERV table. Enter the `rtrv-gserv-data` command.
2. Verify the parameter value, and re-enter the `dlt-gserv-data` command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3330 Cmd Rej: APORT or IGM must be enabled

Commands Used: `chg-is41opts`, `chg-sccp-serv`, `chg-sid`, `rtrv-sid`

The command that was entered requires either the A-Port feature or the IS41 GSM Migration (IGM) feature to be enabled.

For the `chg-sid` and `rtrv-sid` commands, the A-Port or the IS41 GSM Migration (IGM) feature must be enabled before the `cpctype=mn` parameter can be specified.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. If the required feature does not appear in the output from Step 1, verify that the feature has been purchased for use in your system. If the feature needs to be enabled in your system:
 - a) Refer to the procedure in the *Feature Manual – IS41 GSM Migration* to enable the IGM feature.
 - b) Refer to the procedure in the *Feature Manual – A-Port* to enable the A-Port feature.
3. Re-enter the command that generated this error.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3331 Cmd Rej: ECGSSN cannot be specified without CGSSN

Commands Used: `rtrv-gta`

You cannot specify the `ecgssn` parameter without specifying the `cgssn` parameter.

Recovery

Perform either one of the following actions:

Re-enter the `rtrv-gta` command specifying the `ecgssn` parameter without specifying the `cgssn` parameter.

OR

Re-enter the `rtrv-gta` command without specifying the `ecgssn` parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3332 Cmd Rej: GTA/CGPC/OPC/CGSSN/CDSSN/OPCODE are mutually exclusive

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

The `cgpc`, `cgssn`, `gta`, `opc`, `cdssn`, and `opcode` parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying a value for each of the parameters individually in separate commands.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3334 Cmd Rej: LNP and specified feature are mutually exclusive

Commands Used: `chg-ctrl-feat`, `enable-ctrl-feat`

Certain features cannot be enabled, and the INP and AINPQ features cannot be turned on if any of the LNP (LNP ported TNs quantity), LNP 150,000 LRNs, or LNP 300,000 NPANXX features are enabled. Refer to the command description in the *Commands Manual* for a list of features that are mutually exclusive with the LNP features.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. Refer to the appropriate feature manuals to enable, turn on, and use LNP features and EPAP-based features. Refer to the *LNP Feature Activation Guide* for information on the LNP features.

E3336 Cmd Rej: IGM must be enabled

Commands Used: `chg-gsmopts`

The IGM feature must be enabled before the `is412gsm`, `gsm2is41`, or `migrpfx` parameter can be specified.

The IS41 Migration (IGM) feature must be enabled before the Server SRI prefix (`serverpfx`) parameter can be specified.

Recovery

1. Refer to the procedures in the *Feature Manual – IS41 GSM Migration* to enable, turn on, and use the IGM feature.
2. Re-enter the `chg-gsmopts` command before specifying the parameter.

Refer to the *Commands Manual* for a detailed description of the `chg-gsmopts` command and parameter syntax.

E3337 Cmd Rej: MNP invalid if GPORT enabled and APORT/IGM not enabled

Commands Used: `chg-sccp-serv`

The Mobile Number Portability (MNP) service is not supported if the G-Port feature is enabled and either the A-Port feature or IS41 Migration (IGM) feature is not enabled.

Recovery

Note: Once a feature that is controlled using a feature access key has been permanently turned on, it cannot be turned off.

Refer to the procedures in the *Feature Manual – IS41 GSM Migration* to enable, turn on, and use the IGM feature.

Refer to the procedures in the *Feature Manual – A-Port* to enable, turn on, and use the A-Port feature.

E3338 Cmd Rej: PC/SETID/SSN does not exist in MAP table

Commands Used: `chg-ppsopts`

If the Flexible GTT Load Sharing (FGTTLS) feature is enabled, and if the `ri=ssn` parameter is specified, then the values specified for the `pc/pca/pci/pcn`, and `ssn` parameters must exist in the MAP table in the MAP set specified by the `setid` parameter, or in the default MAP set if the `setid` parameter is not specified.

Recovery

1. Display the point codes in the MAP table. Enter the `rtrv-map` command.
2. If the specified point codes do not exist in the specified or default MAP set, then they must be entered. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated the error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3339 Cmd Rej: PC/SETID does not exist in MRN table

Commands Used: `chg-ppsopts`

If the `ri=gt` parameter is specified, then the value specified for the `pc`, `pca`, `pci`, or `pcn` parameter must exist in the MRN table.

Recovery

1. Display the point codes in the MRN table. Enter the `rtrv-mrn` command.
2. If the specified point codes do not exist in the MRN table, then they must be entered. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated the error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3340 Cmd Rej: GFLEX, GPORT, INP, PPSMS or VFLEX must be ON or ATINP enbld

Commands Used: `rtrv-data-rtdb`

The G-Flex, G-Port, INP, Prepaid SMS Intercept Ph1, V-Flex, or INP feature must be turned on or the ATINP feature must be enabled before the `dn` parameter can be specified.

Recovery

1. Display the currently used features using the `rtrv-ctrl-feat` command.
2. If the G-Flex, G-Port, INP, PPSMS, or V-Flex feature is on or the ATINP feature is enabled, according to the output of Step 1, re-enter the command. Call your Customer Care Center for assistance if you continue to receive this message.
3. If the G-Flex, G-Port, INP, PPSMS, or V-Flex features are turned off or not present in the output of Step 1, turn at least one feature on or call your Customer Care Center for assistance.

E3341 Cmd Rej: DEFCC/DEFNDC requires relevant feature to be ON/enabled

Commands Used: `chg-stpopts`

The AINPQ, G-Flex, or INP feature must be turned on, or the ATINP, G-Port, MO SMS IS41-to-GSM Migration, MO-based GSM SMS NP, MO-based IS41 SMS NP, Prepaid IDP Relay, Prepaid SMS Intercept Ph1 (PPSMS), or V-Flex feature must be enabled before the `defcc` or `defndc` parameter can be specified.

Recovery

1. Display the current features using the `rtrv-ctrl-feat` command.
2. If the output of Step 1 shows the appropriate feature turned off or disabled, enable/turn on at least one of them. If the output from Step 1 shows any of these features enabled/turned on, re-enter the command that caused this error message to appear.
3. If this error message appears again, call the Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E3342 Cmd Rej: GFLEX/INP/AINPQ/GPORT/PPSMS/VFLEX must be ON or ATINP enbld

Commands Used: `ent-trace`

The G-Flex, G-Port, INP, AINPQ, PPSMS, IDP Relay, or V-Flex feature must be turned on, or the ATINP feature must be enabled before the `dn` parameter can be specified.

The G-Flex, G-Port, INP, or V-Flex feature must be turned on, or the ATINP, IDP Relay or any TIF feature must be enabled before the `entityid` parameter can be specified.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable or turn on the desired feature. Refer to the relevant Feature Manual for assistance:
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3345 Cmd Rej: SRM, MRC or WT specified with RC (use FORCE=YES)

Commands Used: `chg-map`

The `force=yes` parameter must be specified before the `rc` parameter can be specified in the same command with the `srn`, `mrc`, or `wt` parameter.

Recovery

Re-enter the command specifying the `force=yes` parameter.

Refer to the *Commands Manual* for examples of the use of the `chg-map` command.

E3346 Cmd Rej: WT_x specified while modifying RC_x (use FORCE=YES)

Commands Used: `chg-mrn`

The `force=yes` parameter must be specified before the `rc`, `rc1`, `rc2`, `rc3`, or `rc4` parameter can be specified in the same command with the `wt`, `wt1`, `wt2`, `wt3`, or `wt4` parameter.

Recovery

Re-enter the command specifying the `force=yes` parameter.

Refer to the *Commands Manual* for examples of the use of the `chg-mrn` command.

E3347 Cmd Rej: FORCE only with RC and SRM, MRC or WT specified

Commands Used: `chg-map`

The **force** parameter can be used only to specify the **rc** parameter and the **srn**, **mrc**, or **wt** parameter in the same command.

Recovery

Re-enter the command specifying the **force=yes** parameter.

Refer to the *Commands Manual* for examples of the use of the `chg-map` command.

E3348 Cmd Rej: FORCE only with RCx and WTx specified

Commands Used: `chg-mrn`

The **force** parameter can be used only to specify the **rc**, **rc1**, **rc2**, **rc3** or **rc4** parameter and the **wt**, **wt1**, **wt2**, **wt3**, or **wt4** parameter in the same command.

Recovery

Re-enter the command specifying the **force=yes** parameter.

Refer to the *Commands Manual* for examples of the use of the `chg-mrn` command.

E3349 Cmd Rej: INP/AINPQ must be ON or APORT/GPORT/PPSMS/MOSMS feat enbld

Commands Used: `chg-measopts`, `chg-mtc-measopts`

The G-Port, A-Port, IS41 GSM Migration, MO-based GSM SMS NP, MO-based IS41 SMS NP, MO SMS IS41-to-GSM Migration, or Prepaid SMS Intercept Ph1 feature must be enabled, or the INP or AINPQ feature must be turned on before the **mtchnp=on** parameter or the **mtcdnp=on** parameter can be specified.

Recovery

1. Determine if the feature is enabled and turned on.
Enter the `rtrv-ctrl-feat` command.
2. If the feature is on, re-enter the command that generated this error message.

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.

3. If the feature is not on, enable and turn it on.

Refer to the *Commands Manual* and the relevant Feature Manual for details about enabling and activating the feature.

4. Verify the feature is on.
Enter the `rtrv-ctrl-feat` command.
5. Re-enter the command that generated this error message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3352 Cmd Rej: RANDSLS parameter is only valid for ITU Link Sets

Commands Used: `chg-ls`, `ent-ls`

The Random Signaling Link Selection (**randsls**) parameter applies only to ITU SCCP messages for ITU Link Sets.

Note:

Specifying the **randsls** parameter in the `chg-ls` command enables random SLS generation on a per linkset basis only if the **randsls=perls** parameter is specified in the `chg-stpopts` command.

Recovery

Re-enter the command specifying the **randsls** parameter for ITU link sets only.

Note:

If the **randsls=perls** parameter is specified in the `chg-stpopts` command, provision the ITU link sets in a combined linkset with the same **randsls** value to avoid undesired SLS distribution.

Refer to the *Commands Manual* for detailed information about the use of this command parameter.

E3353 Cmd Rej: GFLEX/APORT/IGM/MOSMS must be ON

Commands Used: `enable-ctrl-feat`

The A-Port, G-Flex, IGM, MO SMS ASD, MO-SMS B-Party Routing, MO SMS GRN, MO SMS IS41-to-GSM or MO-based IS41 SMS NP feature must be turned on before the MTP MSGS for SCCP Apps (MTPR) feature can be enabled.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. Enable and turn on the features as necessary. Refer to the *Commands Manual* and to the appropriate Feature Manual for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3354 Cmd Rej: EIR cannot enable if MTPR is turned ON

Commands Used: `enable-ctrl-feat`

If the MTP MSGS for SCCP Apps (MTPR) feature is turned on, the EIR feature cannot be enabled.

Recovery

1. Display the status of the controlled features in the database. Enter the `rtrv-ctrl-feat` command and the `rtrv-feat` command.
2. If the MTPR feature is turned on, turn it on, you cannot enable the EIR Register feature. Refer to the procedures in the *Feature Manual—Equipment Identity Register* for additional information.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3355 Cmd Rej: INP/AINPQ cannot enable if MTPR is turned ON

Commands Used: `enable-ctrl-feat`

If the MTP Msgs for SCCP Apps feature is turned on, the INP and AINP features cannot be enabled.

Recovery

1. Display the controlled features in the database.
Enter the `rtrv-ctrl-feat` command.
2. If the MTPR feature is turned on, turn it off.
Enter the following command: `chg-ctrl-feat:partnum=893017401:status=off`
3. Verify the GTT feature is turned on.
Enter the `rtrv-feat` command.
4. If the GTT feature is off, turn it on.
Enter the command `chg-feat:gtt=on`
5. Verify the GTT feature is turned on.
Enter the `rtrv-feat` command.
6. Enable the INP or AINPQ feature as applicable.
 - a) To enable the INP feature, enter the command:
`enable-ctrl-feat:partnum=893017901:fak=<INP FAK>`
 - b) To enable the AINPQ feature, enter the command:
`enable-ctrl-feat:partnum=893017801:fak=<AINPQ FAK>`

Refer to the procedure "Enabling and Activating the EIR Feature" in the *Feature Manual—Equipment Identity Register* for additional information. Call your Customer Care Center if this error message appears again.

E3356 Cmd Rej: TIF feature is mutually exclusive with LNP

Commands Used: `enable-ctrl-feat`

If the TIF feature (Number Portability/ Additional Subscriber Data / Generic Routing Number) is enabled, then the LNP feature cannot be enabled. If the LNP feature is enabled, then the TIF feature (Number Portability/ Additional Subscriber Data / Generic Routing Number) cannot be enabled.

Recovery

1. Display the enabled controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. If the LNP ELAP Configuration and LNP ported TNs entries do not appear in the output from Step 1, refer to the *LNP Feature Activation Guide* for the procedures to enable the LNP feature.
3. If the TIF feature does not appear in the output from Step 1, refer to the procedures in the *Feature Manual - TIF* to enable the TIF feature.

E3357 Cmd Rej: TIF NP feature must be enabled

Commands Used: `chg-dstn`, `ent-dstn`

The TIF Number Portability feature must be enabled before the **rcause** or **nprst** parameter can be specified.

Recovery

1. Display the enabled controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. If the TIF NP feature does not appear in the output from Step 1, first determine if the feature was purchased for the system.
3. If the TIF NP feature does not appear in the output of Step 1, refer to the procedures in the *Feature Manual - TIF* to enable the feature.
4. When the feature is enabled and turned on, re-enter the command that generated this message.

E3362 Cmd Rej: PC (not equal to none) and RI must be entered as a pair

Commands Used: `chg-ppsopts`

The **pc/pca/pci/pcn** parameter and the **ri** parameter must be specified together in the command, or a value of **none** must be specified for the **pc/pca/pci/pcn** parameter.

Recovery

Re-enter the command, and specify a valid combination of parameters. Refer to the command description in the *Commands Manual* for assistance.

E3363 Cmd Rej: Feature cannot be enabled with DSM less than 4G is present

Commands Used: `enable-ctrl-feat`

The feature cannot be enabled because a DSM card with less than 4 gigabytes of memory is present in the system.

Recovery

1. Upgrade the hardware configuration so that only DSM cards with at least 4 GB of memory are in the system.
Refer to the applicable Card Removal/Replacement procedure in the *Maintenance Manual* for details.
2. Refer to the procedures in the appropriate feature manual to enable, turn on, and use the feature.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3364 Cmd Rej: Transaction Based GTT Load Sharing Feature must be Enabled

Commands Used: `chg-sccpopts`

The Transaction-Based GTT Load-Sharing feature must be enabled before you can specify the `tgtt0`, `tgtt1`, `tgttudtkey`, or `tgtxudkey` parameters.

Recovery

1. Display the status of the Transaction-Based GTT Load-Sharing feature. Enter the `rtrv-ctrl-feat` command.
2. If the Transaction-Based GTT Load-Sharing feature is enabled, re-enter the `chg-sccpopts` command that generated this error message.
3. If the Transaction-Based GTT Load-Sharing feature is not enabled, verify that the feature has been purchased for your system. Call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.
4. Refer to the *Database Administration Manual* - Global Title Translation to enable, turn on, and use the TBGTTLS feature.

E3367 Cmd Rej: DRA with NEC and NEC=NONE combination not allowed

Commands Used: `chg-inpopts`

If the `nec=none` parameter is specified, then values of `asdrnecdn`, `rmasdnecdn`, `rnecdn`, `rngrnecdn`, and `grnrnecdn` cannot be specified for the `dra` parameter.

Recovery

Re-enter the command, specifying a valid combination of parameters. Refer to the *Commands Manual* and the *Feature Manual - INP/AINPQ* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3368 Cmd Rej: PPT can be specified only with PC/PCA/PCI/PCN/RI/SETID/SSN

Commands Used: `chg-ppsopts`

The `pc/pca/pci/pcn`, `ri`, `setid`, and `ssn` parameters must be specified before the `ppt` parameter can be specified.

Recovery

Re-enter the command, and specify a valid combination of parameters. Refer to the command description in the *Commands Manual* for assistance.

E3370 Cmd Rej: Weighted GTT Load-Sharing feature must be ON

Commands Used: `chg-map`, `chg-mrn`, `ent-map`, `ent-mrn`

The Weighted GTT Load-Sharing feature must be on before you can specify the `dfltw`, `eswt`, `grptwt`, `mwt`, `thr` and `wt/wt1/wt2/wt3/wt4` parameters.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Refer to the *Database Administration Manual - Global Title Translation* to enable, turn on, and use the WGTTLS feature and the Intermediate GTT Load Sharing (IGTTL) feature.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3371 Cmd Rej: WTx must have a matching PCx specified

Commands Used: `chg-mrn`, `ent-mrn`

If you specify a weight (`wt`, `wt1`, `wt2`, `wt3` or `wt4`) parameter, a corresponding point code (`pc`, `pc1`, `pc2`, `pc3` or `pc4`) parameter must be specified.

Recovery

Re-enter the command specifying both the point code (`pc`, `pc1`, `pc2`, `pc3` or `pc4`) and a corresponding weight (`wt`, `wt1`, `wt2`, `wt3` or `wt4`) parameter.

E3372 Cmd Rej: All specified RC values must be equal

Commands Used: `ent-map`, `ent-mrn`

If the threshold (`thr`) parameter is specified when adding PCs to an RC group, the values specified for the `rc` parameters (`rc1`, `rc2`, `rc3`, and `rc4`) must be equal.

Recovery

Re-enter the command specifying the same value for the `rc` parameters of a particular RC group.

E3373 Cmd Rej: WT_x or DFLTWT must be specified with THR

Commands Used: `ent-mrn`

The `wt`/`wt1`/`wt2`/`wt3`/`wt4`, or `dfltwt` parameter must be specified if the threshold (`thr`) parameter is specified.

Recovery

Re-enter the `ent-mrn` command specifying values for the `wt`/`wt1`/`wt2`/`wt3`/`wt4`, or `dfltwt` parameter.

E3374 Cmd Rej: WT parameter can't be specified

Commands Used: `chg-mrn`, `ent-mrn`

If the relative cost (`rc`) parameter is not specified, the `wt` parameter cannot be specified.

Recovery

Perform one of the following actions:

Re-enter the command specifying both the `rc` and `wt` parameters.

OR

Re-enter the command without specifying the `rc` and `wt` parameters.

E3375 Cmd Rej: ESWT and GRPWT can't be specified together

Commands Used: `chg-map`, `chg-mrn`

You cannot specify both the Entity Set Weight (`eswt`) and Group Weight (`grpwt`) parameters at the same time in the command.

Use the `eswt` parameter to:

- change a non-weighted load-sharing entity set to a weighted load-sharing entity set where the `eswt` parameter value represents the weight that will be assigned to each entity in the entity set.

- change a weighted load-sharing entity set to a non-weighted load-sharing entity set using **eswt=none**.
- change a weighted load-sharing entity set to a different weight where the **eswt** parameter value represents the weight that will be assigned to each entity in the entity set.

Use the **grpwt** parameter to specify a uniform weight to all entities in an RC group.

Recovery

Re-enter the command specifying either the **eswt** parameter or the **grpwt** parameter, but not both.

E3376 Cmd Rej: THR can't be specified with ESWT=none

Commands Used: `chg-map`, `chg-mrn`

You cannot specify both the threshold (**thr**) parameter and the (**eswt=none**) parameters. If the **eswt=none** parameter is specified, the **thr** parameter cannot be specified

Note:

If the **thr** parameter is not specified, a value of 1% is assigned to each weighted PC.

Recovery

Perform one of the following actions:

- To change an existing weighted entity set to non-weighted, specify the (**eswt=none**) parameter only. Do not specify the **thr** parameter.
OR
- To change the threshold parameter value and not change the weight of all entities in the RC group, specify the **thr** parameter and the **pc/ssn/mapset** parameters.
OR
- To change the threshold parameter value and not change the weight of all entities in the entire weighted entity set, specify both the **eswt** and **thr** parameters together. Specify the existing database weight value for the **eswt** parameter value and only change the **thr** parameter value.

E3377 Cmd Rej: WTx and RCx can't be specified with ESWT, GRPWT and THR

Commands Used: `chg-mrn`

When modifying an individual entity by specifying the **rc**, **rc1**, **rc2**, **rc3**, **rc4** and/or **wt**, **wt1**, **wt2**, **wt3**, **wt4** parameters for the specified PCs, the **eswt**, **grpwt** and **thr** parameters cannot be specified to modify the entity set or RC group. Only the **pc/mrnset** parameters can be specified with the **eswt**, **grpwt** and **thr** parameters.

Recovery

Re-enter the `chg-mrn` command without specifying the **eswt**, **grpwt** and **thr** parameters.

E3378 Cmd Rej: RCx or WTx must be specified

Commands Used: `chg-mrn`

When the WGTTLs feature is enabled and the `chg-mrn` command is used to modify individual entities, the **wt** or **rc** parameter must be specified for each point code.

Recovery

Re-enter the `chg-mrn` command specifying both the weight (**wt**) and routing cost (**rc**) parameters.

E3379 Cmd Rej: Only PC must be specified

Commands Used: `chg-mrn`

You cannot specify alternate point codes (**pcx/pcax/pcix/pcnx/pcn24x**) when modifying an entity set or RC group.

Recovery

Re-enter the command specifying the point code (**pc**) parameter.

E3380 Cmd Rej: WTx required for all specified PCx values

Commands Used: `ent-mrn`

Weighted and non-weighted PCs cannot co-exist in a single MRNGROUP. When creating a new weighted MRNGROUP or adding to an existing weighted MRNGROUP, the **dflwt** parameter must be specified, or an individual weight must be specified for each PC.

Recovery

Re-enter the `ent-mrn` command specifying the **dflwt** parameter or specifying an individual weight (**wt**) for each PC.

E3381 Cmd Rej: Must specify weight for new point codes for weighted groups

Commands Used: `chg-map`, `chg-mrn`, `ent-mrn`

For the `chg-map` command, if adding a new mate point code (**mpc**) to a weighted MAPGROUP, a mate point code weight (**mwt**) must also be specified.

For the `chg-mrn` command, if adding a new point code (**pc1**, **pc2**, **pc3** or **pc4** parameters) to a weighted group, a corresponding weight (**wt1**, **wt2**, **wt3**, or **wt4**) parameter must be specified for each new point code.

For the `ent-mrn` command, if the `pc1`, `pc2`, `pc3` or `pc4` parameter is specified, the `wt1`, `wt2`, `wt3`, `wt4`, or `dflwt` parameter must also be specified.

Recovery

Re-enter the command specifying the new point code parameter and the associated weight parameter.

E3382 Cmd Rej: Can't specify weight for non-weighted groups

Commands Used: `chg-map`, `chg-mrn`, `ent-mrn`

For the `chg-map` command, if adding a new mate point code (`mpc`) to a non-weighted MAPGROUP, the weight (`mwt`) parameter cannot be specified.

If changing an existing point code in a non-weighted entity set, the weight value cannot be modified; only the value of the routing cost (`rc`) parameter can be modified.

For the `chg-mrn` command, if adding a new point code (`pc1`, `pc2`, `pc3` or `pc4`) to a non-weighted group, the weight (`wt1`, `wt2`, `wt3`, or `wt4`) parameter cannot be specified.

For the `ent-mrn` command, if PCs are being added to a non-weighted group, the (`dflwt`, `wt`, `wt1`, `wt2`, `wt3`, and `wt4`) parameters cannot be specified.

Recovery

Re-enter the command without specifying the `wt(x)` parameter.

E3383 Cmd Rej: Can't specify ESWT=none for non-weighted groups

Commands Used: `chg-map`, `chg-mrn`

You cannot specify a value of `none` for the entity set weight parameter (`eswt=none`) for a non-weighted entity set.

The `eswt=none` parameter changes a weighted entity set to a non-weighted entity set.

Recovery

Perform one of the following steps:

Note:

The entity set weight (`eswt`) parameter can only be specified with the `pc/mrnset` and `thr` parameters.

- Re-enter the command specifying a value (1-99) for the `eswt` parameter for a non-weighted entity set.

OR

- Re-enter the command specifying `eswt=none` for an existing weighted entity set.

E3384 Cmd Rej: GRPWT/THR mustn't be specified for non-weighted groups

Commands Used: `chg-map`, `chg-mrn`

You cannot specify the **grpwt** and **thr** parameters for a non-weighted entity set.

Note:

The **thr** parameter cannot be specified when the `chg-mrn` command is used to add new entities or to modify individual entity RC values or weights.

Recovery

Perform one of the following steps:

- Re-enter the command without specifying the **grpwt** parameter. Instead, re-enter the command specifying a value (1-99) for the **eswt** parameter.

OR

- Re-enter the command without specifying the **grpwt** and **thr** parameters.

E3385 Cmd Rej: Weight can't be specified to create SOL or DOM groups

Commands Used: `ent-map`, `ent-mrn`

For the `ent-map` command, if the values specified for both the **rc** and the **materc** parameters are equal, the **rc**, **mpc**, **materc** and **mwt** parameters must be specified.

For the `ent-mrn` command:

- You cannot assign a weights to the PCs of entity sets that are in a dominant mode.
- When creating an entity set, if all of the values specified for the **rc** parameters are unique, the **wt**, **wt1**, **wt2**, **wt3**, **wt4** and **thr** parameters cannot be specified.

Recovery - ent-map

Re-enter the `ent-map` command specifying the **rc**, **mpc**, **materc**, and **mwt** parameters, if the values specified for both the **rc** and the **materc** parameters are equal.

Recovery - ent-mrn

Perform one of the following steps:

- Re-enter the `ent-mrn` command without assigning weights to the PCs of entity sets that are in solitary or dominant load sharing mode.

OR

- Re-enter the `ent-mrn` command specifying unique values for all the **rc** parameters, without specifying the **wt**, **wt1**, **wt2**, **wt3**, **wt4** and **thr** parameters.

E3386 Cmd Rej: WT and MWT must be specified with THR

Commands Used: ent-map

If the threshold (**thr**) parameter is specified, both the **wt** and **mwt** parameters must be specified.

Recovery

Perform one of the following steps:

- Re-enter the ent-map command specifying the **thr**, **wt**, and **mwt** parameters.
- OR
- Re-enter the ent-map command without specifying the **thr** parameter.

E3387 Cmd Rej: WT and MWT must be specified together

Commands Used: ent-map

The **wt** and **mwt** parameters must be specified together in the same command.

Recovery

Re-enter the ent-map command specifying both the **wt** and the **mwt** parameters.

E3388 Cmd Rej: ESWT, GRPWT and THR can't be specified with MPC

Commands Used: chg-map

When adding a new entity to the entity set by specifying the **mpc/mssn** parameters, you cannot specify the **eswt**, **grpwt** and **thr** parameters.

Recovery

Re-enter the chg-map command specifying the **mpc/mssn** parameters and without specifying the **eswt**, **grpwt** and **thr** parameters.

E3389 Cmd Rej: Only PC/SSN can be specified with ESWT, GRPWT and THR params

Commands Used: chg-map

You cannot use the **eswt**, **grpwt** and **thr** parameters to modify an individual entity in an entity set or RC group. The **eswt**, **grpwt** and **thr** parameters are used to modify all the entities in an entity set or RC group. To modify an individual entity in an entity set or RC group, specify the **rc**, **wt**, **mrc**, **srn**,

sso or **grp** parameters. If the **eswt**, **grpwt** and **thr** parameters are specified, the **rc**, **wt**, **mrc**, **srm**, **sso** or **grp** parameters cannot be specified.

Recovery

Perform one of the following actions depending on your objective:

- To modify all the entities in an entity set or RC group, specify the **pc/ssn/mapset** parameters along with the **eswt** or **grpwt** and **thr** parameters.

Note:

You cannot specify both the **eswt** and **grpwt** parameters in the same command. The **mapset** parameter cannot be specified if the Flexible Final GTT Load-Sharing feature is not enabled.

- To modify an individual entity in an entity set or RC group, specify the **rc**, **wt**, **mrc**, **srm**, **sso** or **grp** parameters as applicable.

E3390 Cmd Rej: RCx must be specified

Commands Used: `chg-mrn`

If the Weighted GTT Loadsharing feature is not enabled, and individual PCs are being modified, the routing cost (**rc**) parameter must be specified for each PC.

Recovery

Re-enter the `chg-mrn` command specifying a (**rc**) parameter value for each point code specified.

E3391 Cmd Rej: DFLTWT can't be specified when WTx for each PCx is specified

Commands Used: `ent-mrn`

If the **wt**, **wt1**, **wt2**, **wt3** or **wt4** parameter is specified, the **dfltwt** parameter cannot be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **wt**, **wt1**, **wt2**, **wt3** or **wt4** parameter(s) only.
OR
- Re-enter the command specifying the **dfltwt** parameter only.

E3392 Cmd Rej: ESWT, GRPWT and THR can't be specified for SOL or DOM groups

Commands Used: `chg-map`, `chg-mrn`

The entity set weight (**eswt**), group weight (**grpwt**) and threshold (**thr**) parameters cannot be specified if the entity set is in a solitary or dominant load-sharing mode.

The **eswt** or **grpwt** and **thr** parameters cannot be specified if the entity set is in a solitary or dominant load-sharing mode.

The **eswt** or **grpwt** and **thr** parameters can be specified if the entity set is in a load-sharing or combination load-sharing mode.

Recovery

1. Determine the mode of the entity set. Enter either the `rtrv-map` or `rtrv-mrn` command.
2. Re-enter the command specifying the **eswt** or **grpwt** and **thr** parameters only if the entity set is in a load-sharing or combination load-sharing mode.

E3393 Cmd Rej: Association is not assigned to AS

Commands Used: `rept-meas`

The association specified by the `aname` parameter must be assigned to the application server specified by the `asname` parameter.

Recovery

Assign the association specified in the `aname` parameter to the application server specified in the `asname` parameter. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3397 Cmd Rej: ANAME is invalid for type-enttype combo

Comands Used: `rept-meas`

The `enttype=sctpasoc` or `enttype=ua` parameter must be specified before the `aname` parameter can be specified.

Recovery

- Refer to the *Commands Manual* for the correct parameter combinations for this command.

E3398 Cmd Rej: ASNAME is invalid for type-enttype combo

Comands Used: `rept-meas`

The `enttype=ua` parameter must be specified before the `asname` parameter can be specified.

Recovery

- Refer to the *Commands Manual* for the correct parameter combinations for this command.

E3399 Cmd Rej: Association is not assigned to AS

Commands Used: `rept-meas`, `chg-ctrl-feat`

The association specified by the **aname** parameter must be assigned to the application server specified by the **asname** parameter.

Recovery

- Refer to the *Commands Manual* for the correct parameter combinations for this command.

E3404 Cmd Rej: VCI values 0..4 and 6..31 are reserved

Commands Used: `ent-slk`

You cannot specify the values 0..4 and 6.. 31 for the Virtual Channel Identifier (**vci**) parameter; these values are reserved system values.

Recovery

Re-enter the command specifying a **vci** parameter value of 5 (the default) or a value from 32..65535.

E3405 Cmd Rej: LINK must be A if hardware type is HCAP

Commands Used: `ent-slk`, `rtrv-slk`

If the card application is **atmansi** or **atmitu**, or if the hardware type of an ATM card is **hcap**, then the **link=b** parameter cannot be specified.

Note: For an E5-ATM card, the **link=a** or **b** can be specified.

Recovery

1. Display the card configuration.
Enter the `rtrv-card` command, specifying the card location (**loc**). The card's application is shown in the *APPL* field of the output.
2. If the card application is **atmansi** or **atmitu**, then re-enter the command specifying the **link=a** parameter.

E3406 Cmd Rej: BPS must be 1544000 for LIMATM cards

Commands Used: `ent-slk`

The **bps** parameter value for a **limatm** card must equal 1544000. If the specified card is a **limatm** card, only the **bps=1544000** parameter can be specified. The value of the **bps** parameter must be 1544000 if the card application is **atmansi**.

Recovery

1. Display the card's configuration.
Enter the `rtrv-card` command specifying the card location (**loc**). The card's type is shown in the *TYPE* field of the output.
2. If the specified card is a **limatm**, re-enter the `ent-slk` command specifying the **bps=1544000** parameter.

E3407 Cmd Rej: LSL parameters not valid for card type

Commands Used: `ent-slk`

The parameter values specified for the signaling link (**ecm**, **l2set**, **pcrn1**, and **pcrn2**), are valid only for low-speed signaling links.

Recovery

1. Display the card's configuration. Enter the `rtrv-card` command specifying the card location (**loc**).
The card's type is shown in the *TYPE* field of the output.
2. If the card in the specified location is a low-speed card, not a **atmitu** or **limatm** card, re-enter the `ent-slk` command specifying the parameters for low-speed signaling links.
3. If the card in the specified location is high-speed card (**atmitu** or **limatm**), re-enter the `ent-slk` command specifying the correct parameters.
 - a) For ATM high-speed signaling links: **atmtsel**, **ll**, **lpset**, **vci**, and **vpi**
 - b) For E1 ATM high-speed signaling links: **atmtsel**, **lpset**, **vci**, **vpi**, **e1atmcrc4**, **e1atmsi**, and **e1atmsn**

E3408 Cmd Rej: ATM parameters not valid for card type

Commands Used: `ent-slk`

The parameter values specified for the signaling link are valid only for high-speed links.

When a low-speed link is assigned to a card (card application is not **atmansi** or **atmitu**), the ATM high-speed link and E1 ATM parameters (**atmtsel**, **e1atmcrc4**, **etatmsi**, **e1atmsn**, **ll**, **lpset**, **vci**, and **vpi**) cannot be specified.

Recovery

1. Display the card's configuration. Enter the `rtrv-card` command specifying the card location.
The card's type is shown in the *TYPE* field of the output.
2. If the card in the specified location is a low-speed card, not a **limatm** or **lime1atm** card, re-enter the `ent-slk` command specifying the parameters for low-speed signaling links: **ecm**, **l2set**, **pcrn1**, and **pcrn2**.
3. If the card in the specified location is a high-speed card (**atmitu** or **limatm**), re-enter the `ent-slk` command specifying the correct parameters.

- a) For ATM high-speed signaling links: **atmtsel**, **ll**, **lpset**, **vci**, and **vpi**
- b) For E1 ATM high-speed signaling links: **atmtsel**, **lpset**, **vci**, **vpi**, **e1atmcrc4**, **e1atmsi**, and **e1atmsn**

E3409 Cmd Rej: Max number combined LSLs and HSLs already entered

Commands Used: `ent-slk`

A maximum of 1200, 1500, 2000, or 2800 links is allowed in the system. The maximum depends on the enabled Large System # Links quantity (see the `rtrv-ctrl-feat` command output). A FAK is required to enable support for more than 1200 links. A mixture of high-speed, E1 high-speed, SE-HSL, IP, and low-speed signaling links is supported.

Recovery

1. Enter the `rtrv-slk` command to determine the number of low-speed signaling links and and/or E1 high-speed signaling links the system already contains.
2. If a link needs to be added to the system and the system already contains the maximum number of allowed links, first delete an existing link (use the `dlc-slk` command) and then add the new link to the system.

An alternative is to enable a higher quantity of the Large System # Links feature, if the current quantity is less than 2800. Contact the Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E3410 Cmd Rej: Failed reading the ATM link parameter set table

Commands Used: `chg-atm-lps`

The ATM Parameter Set table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3411 Cmd Rej: Specified LPSET contains default values and not configurable

Commands Used: `chg-atm-lps`

LPSETs 20 and 30 contain system default parameters which can be copied but not changed.

Recovery

To change the parameter value of a **lpset**, re-enter the `chg-atm-lps` command specifying the new value.

E3412 Cmd Rej: SRCLPSET and LPSET cannot be equal

Commands Used: `chg-atm-lps`

You entered this command specifying the same parameter value for both `srclpset`, and `lpset` for an `action=copy`. The `srclpset` parameter provides the value of the source parameter set to be copied. The `lpset` parameter provides the value of the new parameter set.

Recovery

Re-enter the `chg-atm-lps` command specifying a value from **1** to **20** for `srclpset` and a different value from **1** to **19** for `lpset`.

E3413 Cmd Rej: ACTION and SRCLPSET must be specified together

Commands Used: `chg-atm-lps`

The `action` and `srclpset` parameters must both be specified. The `action=copy` parameter indicates that the values for one link parameter set are to be copied to another. The `srclpset` parameter provides the value of the source parameter set to be copied.

Recovery

Re-enter the `chg-atm-lps` command specifying both the `action` and the `srclpset` parameters.

E3414 Cmd Rej: Invalid parameters for ACTION=COPY

Commands Used: `chg-atm-lps`

If the `action=copy` parameter is specified, only the `lpset` and `srclpset` parameters can be specified.

Recovery

Re-enter the `chg-atm-lps` command specifying values for the `lpset` and `srclpset` parameters.

E3415 Cmd Rej: LOC and CLASS cannot be specified together

Commands Used: `rtrv-slk`

The `loc` and `class` parameters cannot be specified together in the same command. The `loc` parameter provides information about a single card at a certain location. The `class` parameter provides information about the class of either low-speed or ATM high-speed signaling links, as specified.

Recovery

Re-enter the `rtrv-slk` command specifying either the `loc` or the `class` parameter, but not both.

E3416 Cmd Rej: NI is invalid for type-enttype combo

Commands Used: `rept-meas`

The **type=gtwy** parameter must be specified, and a value of **lsdestni**, **lsonismt**, **lsoigni**, **origni**, or **originic** must be specified for the **enttype** parameter before the **ni** parameter can be specified. If the **enttype=lnp** parameter is specified, then the **ni** parameter cannot be specified.

Recovery

Re-enter the `rept-meas` command specifying a valid combination of parameters. Refer to the *Commands Manual* and to the *Measurements Manual* for assistance.

E3417 Cmd Rej: NC is invalid for type-enttype combo

Commands Used: `rept-meas`

If the **enttype=lnp** parameter is specified, then the **nc** parameter cannot be specified. The **type=gtwy** parameter and the **enttype=originic** parameter must be specified before the **nc** parameter can be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* and *Measurements Manual* for assistance.

E3418 Cmd Rej: Specified BPS is invalid

Commands Used: `ent-slk`

The value specified for the bits-per-second (**bps**) parameter is invalid.

The card application must be **atmansi** (see the `ent-card` command) before the **bps=1544000** parameter can be specified. The card application must be **atmitu** before the **bps=2048000** parameter can be specified.

Recovery

1. Display the card's configuration.
Enter the `rtrv-card` command specifying the card location (**loc**). The card's type is shown in the *TYPE* field of the output.
2. Re-enter the `ent-slk` command specifying a valid **bps** rate. Refer to the *Commands Manual* for a list of valid transmission rates for the **bps** parameter.

E3419 Cmd Rej: Day is invalid for type-enttype combination

Commands Used: `rept-ftp-meas`, `rept-meas`

For the `rept-ftp-meas` command, the **day** parameter can be specified only with the **type=mtcd** and **enttype= eir, lnp, np, mapscrn**, or **vflex** parameters.

For the `rept-meas` command, the **day** parameter can be specified with only the **type=mtcd** and **enttype= lnp** or **mapscrn** parameters.

Recovery

Re-enter the desired command, and specify a supported combination of parameters.

E3420 Cmd Rej: 'Default' is an invalid ASNAME

Commands Used: `ent-as`

ASNAME cannot be "Default" regardless of case.

Recovery

Change the ASNAME to something other than "Default".

E3421 Cmd Rej: DSTN5000 feature must be enabled

Commands Used: `chg-stpopts`, `enable-ctrl-feat`

The 5000 Routesets feature must be turned on before you can turn on the 6000, 7000 or 8000 Routesets feature can be turned on.

The value specified for the **mtpdpcq** or **mtpxlq** parameter cannot exceed the allowable sum of destinations provisioned as determined by adding the values of the **mtpdpcq** and **mtpxlq** parameters (**mtpdpcq + mtpxlq** <= sum). [Table 13: Routesets Feature with Maximum Values](#) displays the maximum values for the parameters.

Perform one of the following Recovery procedures:

Recovery - Turn Routesets Feature On

- Display the features in the database. Enter the `rtrv-feat` command.
- If the DSTN5000 feature is turned on, re-enter the command.
- If the DSTN5000 feature is turned off, turn it on. Enter `chg-feat :dstn5000=on` command.
- Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - Enter **mtpdpcq** or **mtpxlq** parameter

1. Verify the number of **mtpdpcq** and **mtpxlq** entries currently allocated. Enter the `rtrv-stpopts` command.
2. Re-enter the command specifying a value for the **mtpdpcq** and **mtpxlq** parameters that does not exceed the command requirements.

E3422 Cmd Rej: Echo capability not applicable on originating terminal

Commands Used: `act-echo`, `canc-echo`

You entered your own terminal ID number for the **trm** parameter value. You cannot echo to the terminal from which the command is issued.

Recovery

Re-enter the command specifying a different value for the **trm** parameter.

E3423 Cmd Rej: Day must be specified when PERIOD=SPECIFIC

Commands Used: `rept-ftp-meas`, `rept-meas`

This message appears when the **day** parameter is not specified when using **period=specific**. The **day** parameter must be specified when **period=specific**.

Recovery

Re-enter the command specifying the **day** parameter along with **period=specific**.

E3425 Cmd Rej: Invalid parameter for SS7ANSI, ATMANSI, IPLIM, or SS7IPGW

Commands Used: `ent-trace`

You entered a parameter that is invalid for an ANSI SS7 card running the **ss7ansi**, **atmansi**, **iplim**, or **ss7ipgw** GPL. The invalid parameters are **gt**, **entityid**, **dn**, **imei**, **imsi**, **lrn** and **tn**.

For an ANSI SS7 card, MSUs can be filtered using the following parameters: **ssp/sspa**, **opc/opca**, **dpc/dpca**, and **tlnpisuptype**.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3426 Cmd Rej: ANSI PC parameters are invalid for ITU cards

Commands Used: `ent-trace`

The following ANSI point code parameters are invalid for LIM cards running the `iplimi` GPL: **opc**, **opca**, **dpc**, **dpcn**, **ssp**, and **sspa**.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

E3427 Cmd Rej: ITU PC parameters are invalid for ANSI cards

Commands Used: `ent-trace`

The following ITU point code parameters are invalid for LIM cards running the `ss7ansi`, `atmansi`, `iplim`, or `ss7ipgw` GPLs: **opci**, **opcn**, **opcn24**, **dpci**, **dpcn**, **dpcn24**, **sspi**, **ssp**, and **ssp24**.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3428 Cmd Rej: Invalid parameter for CCS7ITU or IPLIMI

Commands Used: `ent-trace`

The following parameters are invalid for LIM cards running the `atmitu` or `iplimi` GPLs: **gt**, **entityid**, **dn**, **imei**, **imsi**, **lrn**, **tn**, and **tlnpisuptye**.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3429 Cmd Rej: Invalid parameter for VSCCP

Commands Used: `ent-trace`

You specified a parameter (**dpc**, **opc**, or **tlnpisuptye**) that is invalid for a VSCCP card. For VSCCP cards, MSUs can be filtered using one or more of the following parameters: **dn**, **entityid**, **gt**, **imsi**, **lrn**, **ssp/sspa/sspisspn**, and **tn**.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3431 Cmd Rej: SCCPCNV must be ON before TCAPCNV can be ON

Commands Used: `chg-feat`

You cannot enable and turn on the `tcapcnv` feature before the `sccpcnv` feature is enabled and turned on.

Recovery

1. Turn on the SCCPCNV feature.
Enter the `chg-feat:sccpcnv=on` command.
2. Turn on the TCAPCNV feature.
Enter the `chg-feat:tcapcnv=on` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3432 Cmd Rej: Code parameter not supported for OAM locations

Commands Used: `alw-card`

If an OAM card is installed in the location specified by the `loc` parameter, then only a value of `inactiveprtn` is supported for the `code` parameter.

Recovery

If the intent is to load the OAM from the inactive Partition, then re-enter the command specifying a value of `inactiveprtn` for the `code` parameter. Otherwise, re-enter the command specifying either no code parameter or a different location. Refer to the *Commands Manual* for more information.

E3433 Cmd Rej: DPC parameter must be specified

Commands Used: `inh-alm`, `unhb-alm`

When the `dev=route` parameter is specified, a `dpc/dpca/dpci/dpcn/dpcn24` parameter must be specified

Recovery

Re-enter the command specifying the `dev=route` parameter and a value for the `dpc` parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3434 Cmd Rej: The alarms are already inhibited for this device

Commands Used: `inh-alm`

Alarms already inhibited for the specified device.

Recovery

1. Identify any alarms that have been inhibited.
Enter the `rept-stat-trbl` command. The letter *I* after the message reference number (MRN) indicates that the alarm has been inhibited.
2. Re-enter the `inh-alm` command specifying a device that is not already inhibited.

E3435 Cmd Rej: To disable CRITALMINH, critical alarms cannot be inhibited

Commands Used: `chg-stpopts`

To specify the `criticalminh=no` parameter, critical alarms cannot be currently inhibited in the system.

Recovery

1. Enter the `rept-stat-trbl` command to identify the critical alarms that have been inhibited.
The letter *I* after the message reference number (MRN) indicates that the alarm has been inhibited. Critical alarms are identified by *C. Here is an example:

```
5054.0013I*C CARD 1202 SS7ANSI Card is isolated from the system
```
2. Enter the command `unhb-alm: dev=xxxx` where `xxxx` is the device type that is inhibited.
Refer to the *Commands Manual* for valid parameter combinations that may be specified with the `dev` parameter.
3. Re-enter the `chg-stpopts` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3436 Cmd Rej: CRITALMINH not set trying to inhibit critical alarms

Commands Used: `inh-alm`

Before critical alarms can be inhibited, the STP option `criticalminh` must be enabled. The `chg-stpopts:criticalminh=yes` command enables this option.

Recovery

1. Enter the `rtrv-stpopts` command.

The output shows the current setting (**yes** or **no**) for the CRITALMINH option.

2. If the output from Step 1 shows that the option is enabled, re-enter the `inh-alm` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the output from Step 1 shows that the option is disabled, enter the `chg-stpopts: criticalminh=yes` command.
4. Re-enter the `inh-alm` command that generated this error message.

E3437 Cmd Rej: Device alarm inhibit table not accessible

Commands Used: `inh-alm`, `unhb-alm`

The Device Alarm Inhibit table is not accessible and may be corrupt or cannot be found by the system. The Device Alarm Inhibit table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3438 Cmd Rej: Lvl 1 Removable detected during upgrade

Commands Used: `act-upgrade`

The removable cartridge required for the upgrade has upgrade phase indicators. The upgrade command expects the disks to be in certain phases before executing a specific action. This message occurs if you swap out the removable cartridge at some point during the upgrade, so that the disk is no longer in the expected phase.

Recovery

If you have swapped out the removable cartridge, re-insert the removable cartridge that you were using for the upgrade.

OR

1. Determine the status of the removable cartridge.
Enter the `act-upgrade:action=dbstatus` command.
2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.

E3439 Cmd Rej: Standby TDM in unknown upgrade mode

Commands Used: `act-upgrade`

The TDMs have upgrade phase indicators. The upgrade command expects the disks to be in certain phases before executing a specific action. This message appeared because the standby TDM is not in the correct phase.

Recovery

1. Display the current database status.
Enter the `act-upgrade:action=dbstatus` command.
2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.

E3440 Cmd Rej: Active TDM in unknown upgrade mode

Commands Used: `act-upgrade`

The TDMs have upgrade phase indicators. The upgrade command expects the disks to be in certain phases before executing a specific action. This message appeared because the active TDM is not in the correct phase.

Recovery

1. Display the current database status.
Enter the `act-upgrade:action=dbstatus` command.
2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.

E3441 Cmd Rej: Target release source disk in unknown upgrade mode

Commands Used: `act-upgrade`

The disk that contains the upgrade target release is in an unknown upgrade mode.

The upgrade command expects the disk to be in certain phases before executing a specific action.

Recovery

1. Display the current database status.
Enter the `act-upgrade:action=dbstatus` command.
2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3442 Cmd Rej: Removable is from previously aborted upgrade

Commands Used: `act-upgrade`

The upgrade command specifying the **convertstp** action runs from upgrade phase 0 to upgrade phase 3 unless an anomaly occurs that causes the command to terminate.

Recovery

1. Take whatever action is necessary to correct the anomaly.
2. Re-enter the `act-upgrade:action=convertstp` command.

E3443 Cmd Rej: THRES parameter valid only with CONVERTNET/CONVERTSTP

Commands Used: `act-upgrade`

If the **thres** parameter is specified, then the **action=convertnet** and **action=convertstp** parameters must be specified.

Recovery

Perform one of the following actions:

- Re-enter the `act-upgrade` command without specifying the **thres** parameter.
- OR
- Re-enter the `act-upgrade` command, specifying the **thres** parameter, the **action=convertnet** parameter, and the **action=convertstp** parameters.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3444 Cmd Rej: Upgrade prevented due to auto-inhibited card

Commands Used: `act-upgrade`

All cards that are in the auto-inhibited state must be removed before this command can be entered.

Recovery

1. Remove any cards that are in the auto-inhibited state.
2. Re-enter the `act-upgrade` command.

E3445 Cmd Rej: Connection not compatible with SLK IPLIML2 setting

Commands Used: `chg-assoc`, `ent-assoc`

You specified the **lhost** parameter for a local host on an IPLIMx card. The local host connection is not valid for the setting of the **ipliml2** parameter for the signaling link assigned to the specified local host connection.

The signaling link for the local host connection must have the **ipliml2** parameter set to **m2pa** or **m3ua**.

Recovery

1. Enter the `rtrv-ip-host` command to display the IP address for the local host.
2. Enter the `rtrv-ip-lnk` command to display the card location for the local host IP address.
3. Enter the `rtrv-slk` command for the card location, to display the **ipliml2** settings for the links assigned to the signaling link ports on the card.

Refer to the *Database Administration Manual - IP⁷ Secure Gateway* for information on signaling link and socket or association assignments.

- a) If **saaltali** is shown in the IPLIML2 column from Step 3 for the link assigned to the local host signaling link port, you must enter a command that defines a socket connection for the local host.
- b) If **m2pa** or **m3ua** is shown in the IPLIML2 column from Step 3 for the link assigned to the local host signaling link port, you must enter a command that defines an association connection for the local host.

E3446 Cmd Rej: SLK not provisioned for assigned Lhost

Commands Used: `chg-assoc`

A command was entered to change the local host IP address, and the new local host has no signaling link assigned to its associated signaling link port.

Recovery

1. Enter the `rtrv-ip-host` command to display the IP address for the new local host.
2. Enter the `rtrv-ip-lnk` command to display the card location for the new local host IP address.
3. Enter the `rtrv-slk` command for the card location to display the linksets containing links assigned to the signaling link ports for the card.
4. If there is no linkset shown for the local hosts signaling link port, assign a link to the signaling link port for the new local host.

Refer to the procedures in the *Database Administration Manual - IP⁷ Secure Gateway* for assigning links and linksets.

5. Re-enter the command to change the local host IP address.

E3447 Cmd Rej: IPLIMx and IPSG connections cannot be resident in AS

Commands Used: `chg-assoc`, `ent-as`

IPLIMx and IPSG connections cannot reside in an application server (AS). Association can be moved only from a card running the `ss7ipgw` or `ipgwi` application to a card running the `iplim` or `iplimi` application. IPLIMx M3UA/SUA associations cannot be assigned to an AS.

Recovery - `chg-assoc`

1. Display the current local host name.
Enter the `rtrv-assoc` command.
2. Verify that the association is bound to an M3UA/SUA association that is assigned to an AS.
Enter the `rtrv-as` command.
3. Display the card location for the association's current local host and new local host.
Enter the `rtrv-ip-lnk` command.
4. Verify the application that is running on each local host card.
Enter the `rtrv-card` command. If the current host application is `ss7ipgw` or `ipgwi` and the new local host card application is `iplim` or `iplimi`, you cannot move the association to that new local host. Refer to the *Database Administration Manual - IP / Secure Gateway* for the procedures for adding or changing an association.

E3448 Cmd Rej: LHOST has open socket or association

Commands Used: `chg-ip-lnk`, `dlt-slk`

You entered a command to change the local host IP address. The local IP address cannot be changed if the current or new local host has open sockets or associations (the `open` parameter set to `yes` using the `ent-assoc` or `chg-assoc` command).

OR

You entered a command to delete an IPLIMx or IPGWx signaling link assigned to a local host that has a socket or association with connection status `open=yes`. The socket or association connection status must be `open=no` before you can delete the link.

Recovery - `chg-ip-lnk`

1. Display the host name for the current and new local host. Enter the `rtrv-ip-host` command.
2. Display connection status (`open`) for the sockets. Enter the `rtrv-appl-sock` command for the current and new host names.
3. Change the connection status of each open socket to `no` for the current and new local hosts. Enter the `chg-appl-sock` command.
4. Re-enter the `chg-ip-lnk` command to change the local host IP address.

Recovery - `dlt-slk`

1. Display the host name for the local host.
Enter the command `rtrv-ip-host`.
2. Display connection status (**open**) for the associations.
Enter the `rtrv-assoc` command for the local host name.
3. Change the connection status of each open association to **no** for the local host.
Enter the `chg-assoc` command. Example: `chg-assoc:aname=assoc1:open=no`
4. Re-enter the `dlt-slk` command to delete the signaling link.

E3449 Cmd Rej: Command not supported with current IPLIML2 setting

Commands Used: `alw-slk`, `inh-slk`, `tst-slk`, `unhb-slk`

This command cannot be entered for an IPLIMx signaling link that has an **ipliml2** parameter setting of **m3ua**.

If the card in the specified card location is an SSEDCCM card running the **iplim** or **iplimi** application or an E5-ENET card running the **ipsg** application, then the specified link must have an **ipliml2** parameter value of **m2pa** (see the `ent-slk` command).

Recovery

1. Display the IPLIML2 setting for the signaling link. Enter the `rtrv-slk` command.
If the IPLIML2 setting is **m3ua**, then the link cannot be tested, inhibited, allowed, or uninhibited.
2. Use the `ent-slk` command to provision the **ipliml2** parameter with a value of **m2pa**. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3450 Cmd Rej: Invalid Part Number

Commands Used: `chg-ctrl-feat`, `enable-ctrl-feat`

The value specified for the **partnum** parameter must be the correct part number for the purchased feature.

Recovery

Re-enter the command specifying the correct part number for the feature.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3451 Cmd Rej: Controlled Feature is not enabled

Commands Used: `chg-ctrl-feat`, `chg-gta`, `ent-gta`, `chg-trm`, `ent-gttset`

A feature must be enabled or turned on before a parameter can be specified. See the following Recovery sections below for specific command requirements.

The controlled feature specified by the **partnum** parameter must be enabled before this command can be entered.

OR

The IP User Interface (Telnet) feature must be enabled and turned on before the `type=telnet` parameter (IDs 17-40) or the `type=emsalm` parameter (IDs 1-40) can be specified.

Recovery - `chg-ctrl-feat`

Display the status of feature access key controlled features that are purchased and enabled in the system. Enter the `rtrv-ctrl-feat` command.

Recovery - `chg-gta`, `ent-gta`, `ent-gttset`

The OBSR feature must be enabled or the TOBR feature must be turned on before the **optsn** or **settype** parameter can be specified.

Display the status of controlled features that are purchased and enabled in the system. Enter the `rtrv-ctrl-feat` command.

Recovery - `chg-trm`

Either change the **trm=1** value to **16**, for a non-Telnet terminal and re-enter the `chg-trm` command.

OR

1. Enable the IP User Interface (Telnet) feature to support Telnet terminals (**trm= value** or greater).
2. Display the Telnet terminals and their types. Enter the `rtrv-trm` command.
3. Determine the status of the Telnet feature. Enter the `rtrv-ctrl-feat` command with the part number.
 - a) Verify the Telnet feature has been purchased and installed in your system. Contact the Customer Care Center for assistance.
 - b) Verify the Telnet feature is enabled and turn on. If necessary, enable and turn it on.
Refer to the *Database Administration Manual—System Management* for instructions on how to enable and turn on the Telnet feature and any prerequisite features (if any) that must be turned on.
4. When the Telnet feature is turned on in the system, re-enter the `chg-trm` command specifying the parameter that requires the Telnet feature to be on.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3452 Cmd Rej: Invalid Feature Access Key

Commands Used: `enable-ctrl-feat`

The `fk` parameter value that you entered has one of the following conditions:

- Does not meet one of the following naming conventions:
 - Must be a 13-character alphanumeric (A...Z, a...z, or 0...9) symbol.
 - First character must be an alphabet letter.
 - String cannot include any special characters, including space.
- Does not correspond to the `partnum` parameter you entered.
- Does not correspond to the serial number in the database.

Recovery

Re-enter the command ensuring you follow the naming conventions.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3453 Cmd Rej: Database does not contain a serial number

Commands Used: `enable-ctrl-feat`

A valid system serial number must be entered and locked in the database before this command can be entered for the feature.

Recovery

1. Display the system serial number that is in the database. Enter the `rtrv-serial-num` command.
2. If the serial number is not in the database, contact your system administrator and refer to the `ent-serial-num` command in the Commands Manual for the procedure and information to enter and lock the correct serial number for your system.
3. If the serial number is in the database, contact your system administrator to verify that the feature with the part number that was specified in the `enable-ctrl-feat` command is allowed on this system.
4. Re-enter the `enable-ctrl-feat` command for the feature.
5. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3454 Cmd Rej: Routesets Feature Quantity must be increased

Commands Used: `chg-stpopts`

The number of routes being set beyond 5000 is more than the Feature Quantity Key will allow. Before the value of the MTP destination point code quantity (**mtpdpcq**) or the MTP x-list quantity (**mtpxlq**) parameters can be changed, the correct Routesets Feature must be turned on.

The allowable sum of destinations provisioned is determined by adding the values of the **mtpdpcq** and **mtpxlq** parameters (**mtpdpcq + mtpxlq <= sum**). *Table 13: Routesets Feature with Maximum Values* shows the maximum values of **mtpdpcq**, **mtpxlq**, and their sums with a particular Routesets feature turned on.

Note: The values of the **mtpdpcq** and **mtpxlq** parameters are interdependent. To increase the number of DPCs that can be provisioned, the number of x-list entries that the STP is to maintain must be decreased. To increase the number of x-list entries that the STP maintains, the number of DPCs that can be provisioned must be decreased.

Recovery

1. Display the status of features in the system.
Enter the `rtrv-ctrl-feat` command.
2. Verify that a Routesets feature has been purchased and enabled.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If a Routesets feature does not appear in the output from Step 1, refer to the *Commands Manual* and the *Database Administration Manual - SS7* for more information about enabling and using Routesets features.

E3455 Cmd Rej: SCTP Association or SLK provisioned: Card supports 2 links

Commands Used: `ent-slk`

All available links on the specified IPLIM card have already been provisioned.

Recovery

Re-enter the `ent-slk` command and limit the number of signaling links to two for DCMs configured as IPLIM or IPLIMI.

E3456 Cmd Rej: LNP ELAP Configuration feature must be ON

Commands Used: `enable-ctrl-feat`

The LNP ELAP Configuration feature must be enabled and turned on before you can enable the feature access key for any of the following features:

- 24 Million LNP ported TNs or greater
- 300,000 LNP ported NPANXXs
- 150,000 LNP ported LRNs

Note: Once a Permanently On feature that is controlled using a feature access key is turned on, it cannot be turned off. Refer to the Database Administration Manual-System Management and to the Commands Manual for details about enabling features with feature access keys.

Recovery

1. Display the status of the controlled features in the database. Enter the `rtrv-ctrl-feat` command.
2. Refer to the LNP Feature Activation Guide to enable and use the LNP feature (LNP ported TNs), the LNP 300,000 NPANXXs feature, and the LNP 150,000 LRNs feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3457 Cmd Rej: Perm feature key cannot be turned off for the feature

Commands Used: `chg-ctrl-feat`

After a Permanently On feature is turned on, it cannot be turned off with this command.

Refer to the *Database Administration - System Management Manual* and to the command description in the *Commands Manual* for details about turning on and off features with feature access keys. The command description also contains a list of Permanently On features.

Recovery

1. Display the status of the enabled controlled features. Enter the `rtrv-ctrl-feat` command.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Call your Customer Care Center for assistance with turning controlled features on and off. See the "Customer Care Center" section in Chapter 1 of this manual.

E3462 Cmd Rej: LNP ported TNs 24million Qty Feat Require at least DSM2GB

Commands Used: `enable-ctrl-feat`

You cannot enable the LNP Ported TNs 24 Million Quantity Key Feature. Not all DSM cards have at least 2 GB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient (at least 2 GB) memory quantity.
2. Enable the LNP Ported TNs 24 Million Quantity feature. Refer to the *LNP Feature Activation Guide* for details.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3463 Cmd Rej: LNP ported TNs 36million Qty Feat Require at least DSM3GB

Commands Used: `enable-ctrl-feat`

You cannot enable the LNP Ported TNs 36 Million Quantity Key Feature. Not all DSM cards have at least 2 GB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient (at least 2 GB) memory quantity.
2. Enable the LNP Ported TNs 36 Million Quantity feature. Refer to the *LNP Feature Activation Guide* for details.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3464 Cmd Rej: LNP ported TNs 48 to 192 M Qty Feat Req at least DSM4GB

Commands Used: `enable-ctrl-feat`

You cannot enable an LNP Ported TNs feature for a quantity greater than 48 million TNs. Not all DSM cards have at least 4 GB. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient (at least 4 GB) memory quantity.
2. Enable the LNP Ported TNs Quantity feature. Refer to the *LNP Feature Activation Guide* for details.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3466 Cmd Rej: SSO parameter is not compatible with True PC

Commands Used: `chg-map`, `ent-map`

You attempted to specify an **sso** parameter that is incompatible with the True point code. The **sso** parameter cannot be specified with a PC that is the system true PC.

Recovery

Perform one of the following actions:

- Re-enter the command changing the subsystem status option parameter.
- OR
- Re-enter the command altering the primary and/or mate remote point code.

E3467 Cmd Rej: FTP SERV table must contain one entry with application USER

Commands Used: `act-ftp-trns`

You entered a command to activate an FTP transfer on the EAGLE 5 ISS, but the FTP Server table does not have an entry specifying the application USER.

Recovery

1. Enter the `rtrv-ftp-serv` command to display the information for the FTP Servers that are defined in the FTP Server table.
2. Re-enter the `act-ftp-trans` command for the FTP Server, ensuring at least one entry specifies the application USER.

E3468 Cmd Rej: FTP Transfer already in progress

Commands Used: `act-ftp-trns`

An `act-ftp-trns` command cannot be entered if another file transfer is already in progress.

Recovery

The FTP transfer is currently in progress. Re-enter the `act-ftp-trns` command later when the current transfer has completed.

E3469 Cmd Rej: M2PATSET requires M2PA adapter type

Commands Used: `chg-assoc`, `ent-assoc`

If the `m2patset` parameter is specified, then the `adapter` parameter value must be `m2pa`.

For more information, refer to the *Commands Manual*.

Recovery

Re-enter the command that generated this error message, specifying `adapter=m2pa`.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3470 Cmd Rej: SRCTSET and TSET cannot be equal

Commands Used: `chg-m2pa-tset`

You cannot specify the same parameter value for both **srctset** and **tset**. The **srctset** parameter indicates which timer set is to be copied into the timer set specified by the **tset** parameter. The **tset** parameter provides the value of the new parameter set. The timer set specified by **srctset** cannot be the timer specified by **tset**.

Recovery

Re-enter the `chg-m2pa-tset` command specifying a value for **srctset** from 1 to 20 and a different value for **tset** also in the range from 1 to 20.

E3471 Cmd Rej: Application server name must be specified

Commands Used: `rept-meas`

If the **enttype=ua** parameter is specified, then the **asname** parameter must be specified.

Recovery

- Re-enter the command, and specify the **asname** parameter.
- If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3473 Cmd Rej: The last active serial port cannot be inhibited

Commands Used: `inh-trm`

The `inh-trm` command does not permit the user to inhibit all serial ports from a Telnet user. One serial port must remain active and available for login and must be of the terminal type capable of entering commands, such as the VT100, KSR, MGMT, or SCCS.

Recovery

1. Display all the terminals.
Enter the `rtrv-trm` command.
2. With the output from Step 1 as a guide, re-enter the `inh-trm` command for only appropriate terminals.

E3474 Cmd Rej: Prepaid SMS Intercept Ph1 feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The Prepaid SMS Intercept Ph1 feature must be enabled before an AS containing the **pprelay** SA can be specified as a value for the **asn** parameter with the `MOSMSGCDPN` or `MOSMSGCGPN` service.

Recovery

1. Enter the `rtrv-ctrl-feat` command to display the status of features in the system.

2. Refer to the *Feature Manual - MO SMS* to enable the Prepaid SMS Intercept Ph1 feature.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3475 Cmd Rej: Failed reading HOME SMSC ADDRESS table

Commands Used: `dlt-home-smsc`, `ent-home-smsc`, `rtrv-home-smsc`

The Home SMSC Address table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3476 Cmd Rej: HOME SMSC Address to be deleted does not exist in database

Commands Used: `dlt-home-smsc`

The command cannot find the HOME SMSC address specified by the `smsc` parameter. The specified HOME SMSC address must exist in the HOME SMSCADDR table.

Recovery

Perform one of the following actions:

- Verify that the HOME SMSC address was entered correctly, and re-enter the `dlt-home-smsc` command.
- OR
- Verify the HOME SMSC address does not exist. Enter the `rtrv-home-smsc` command specifying the `smsc` parameter.

E3477 Cmd Rej: HOME SMSC Address already exists

Commands Used: `ent-home-smsc`

The specified HOME SMSC address cannot already exist in the HOME SMSCADDR table.

Recovery

Perform one of the following actions:

- Verify that the HOME SMSC address was entered correctly, and re-enter the `ent-home-smsc` command.
OR
- Verify the HOME SMSC address is already present. Enter the `rtrv-home-smsc` command specifying the same **smsc** parameter value.

E3478 Cmd Rej: Home SMSC Table is Full

Commands Used: `ent-home-smsc`

The HOME SMSCADDR table can contain a maximum of **500** entries.

Recovery

1. Display the HOME SMSCADDR table.
Enter the `rtrv-home-smsc` command.
2. Delete an existing entry from the HOME SMSCADDR table.
Enter the `dlt-home-smsc` command.
3. Add the address entry into the HOME SMSCADDR table.
Re-enter the `ent-home-smsc` command.

E3479 Cmd Rej: Port Check for MO SMS feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The Portability Check for MO SMS feature must be enabled before an AS containing the **fraudchk** SA can be specified as a value for the **asn** parameter with the **MOSMSGCGPN** service.

Recovery

1. Display the status of features in your system. Enter the `rtrv-ctrl-feat` command.
2. Refer to the procedures in the *Feature Manual - MO SMS* to enable the Portability Check for Mobile Originated SMS feature.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3480 Cmd Rej: PPT must be specified with PC/PCA/PCI/PCN/RI/SETID/SSN

Commands Used: `chg-ppsopts`

If the **pc**, **ri**, **ssn** or **setid** parameter is specified, then the **ppt** parameter must be specified.

Recovery

Re-enter the `chg-ppsopts` command specifying a valid combination of parameters. Refer to the command description in the *Commands Manual* for assistance.

E3481 Cmd Rej: S/ESLOT cannot be set to 9 or 10

Commands Used: `rept-imt-info`

The HIPR or HIPR2 card slots (**09** and **10**) cannot be specified as values for the `sslot` and `eslot` parameters.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* for assistance.

E3482 Cmd Rej: Link capacity exceeds limit allowed by HSL feature key

Commands Used: `ent-slk`

The link capacity cannot exceed the maximum allowed by the SE-HSL or ST-HSL-A FAK (see the `rtrv-ctrl-feat` command output). Additional signaling links cannot be provisioned until the system capacity is increased.

Recovery

1. Display a list of features controlled by a feature access key in the system.
Enter the `rtrv-ctrl-feat` command.
2. The HC-MIM SLK quantity entry should appear in the output from Step 1. If the SE-HSL or ST-HSL-A SLK Capacity entry appears, the entry indicates the number of links allowed in the system. If the enabled quantity needs to be increased, a larger SLK Capacity quantity must be purchased and enabled in the system.
3. If the SE-HSL or ST-HSL-A SLK Capacity entry does not appear in the output from Step 1, an SE-HSL or ST-HSL-A SLK Capacity quantity must be purchased and enabled in the system before signaling links can be provisioned.
Contact your local Tekelec Sales Representative for assistance with purchasing a SE-HSL or ST-HSL-A SLK Capacity feature.

E3483 Cmd Rej: CAS=ON is not supported on this card

Commands Used: `chg-e1`, `ent-e1`

If a value of **3 - 8** is specified for the `e1port` parameter, or if the `chanbrdg=on` parameter is specified, then the `cas=on` parameter cannot be specified.

Recovery

Re-enter the command without specifying the **cas=on** parameter.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command.

E3484 Cmd Rej: Interface to a channel card is not supported

Commands Used: `chg-e1`, `chg-t1`, `ent-slk`

The card location specified is not supported. For the `ent-slk` command: The **e1loc/t1loc** parameters are not valid for the E5-E1T1 card or the HC-MIM card. The E5-E1T1 card and the HC-MIM card cannot be used as or with a Channel card.

For the `chg-e1`, `chg-t1` commands: If the value specified by the **loc** parameter refers to a Channel card, then the **chanbrdg=on** parameter cannot be specified.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command.

E3485 Cmd Rej: CHANBRDG is not supported on this card

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

The **chanbrdg** parameter can be specified only for HC-MIM cards and E5-E1T1 cards used as E1 or T1 cards. The parameter cannot be specified if the cards are used as SE-HSL or ST-HSL-A cards.

Recovery

1. Display the cards in the system.
Enter the `rtrv-card` command.
2. Based on the output of Step 1, perform one of the following actions:
 - a) remove the card and continue with provisioning.
OR
 - b) replace the card with an HC-MIM (odd card location only) or an E5-E1T1 card.
Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3486 Cmd Ref: CHANBRDG parameter is invalid for even numbered port

Commands Used: `chg-e1`, `chg-t1`, `ent-e1`, `ent-t1`

The **chanbrdg=on** parameter indicates whether an odd-numbered port is to pair with its even-numbered port for non-signaling data pass through. The **chanbrdg=on** parameter cannot be specified for even-numbered E1 ports or T1 ports on HC-MIM and E5-E1T1 cards.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3487 Cmd Rej: Timing Source must be specified if CHANBRDG=ON is specified

Commands Used: chg-e1, chg-t1, ent-e1, ent-t1

The timing source parameter **e1tsel** or **t1tsel** must be specified if **chanbrdg=on** is specified. The timing source is **master** (internal), **slave** (line), or **recovered** from its paired port. The **recovered** option is only valid for a port that is in channel bridging (**chanbrdg=on**) mode.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3488 Cmd Rej: RECOVERED is allowed only in channel bridging mode

Commands Used: chg-e1, chg-t1, ent-e1, ent-t1

The **chanbrdg=on** parameter must be specified for an HC-MIM or E5-E1T1 card before the **e1tsel=recovered** parameter can be specified. If the **e1tsel=recovered** parameter was specified previously, then the **e1tsel=line** parameter must be specified before the **chanbrdg=off** parameter can be specified.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3489 Cmd Rej: Adjacent even numbered port has signaling link assigned

Commands Used: chg-e1, chg-t1, ent-e1, ent-t1

All signaling links assigned to the adjacent even-numbered E1 port must be deleted before an odd-numbered E1 port (**e1port** parameter) on an HC-MIM and E5-E1T1 card can be provisioned into

channel bridging mode using the **chanbrdg=on** parameter. Enter the **dlt-slk** command to delete the signaling links.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3490 Cmd Rej: HIPR must be equipped on the shelf for this card

Commands Used: **chg-e1**, **chg-t1**, **ent-e1**, **ent-slk**, **ent-t1**

The system checks for HIPR cards whenever E1 ports 3 through 8 (**e1port** parameter), **chanbrdg=on**, or **linkclass=unchan** parameter is specified for HC-MIM and E5-E1T1 cards.

HIPR cards must be in card locations **xy09** and **xy10** (*x* is the frame, *y* is the shelf):

- On any shelf that contains one or more HC-MIM or E5-E1T1 cards. When **link** parameter values **a4-a31** and **b4-b31** are specified, the system verifies that HIPR cards are in card locations **xy09** and **xy10** on the same shelf with the specified HC-MIM card.
- On each shelf that contains one or more HC-MIM or E5-E1T1 cards that are used as SE-HSL (**linkclass=unchan**) cards.
- On each shelf that contains one or more HC-MIM or E5-E1T1 cards that are used as E1 cards or T1 cards. The system checks for HIPR cards when HC-MIM E1 or T1 ports 3 through 8 are specified (**e1port** parameter or **t1port** parameter).
- On any shelf that contains one or more HC-MIM or E5-E1T1 cards used in channel bridging mode (**chanbrdg=on** parameter).

Recovery

1. Display the cards on the shelf. Enter the **rtrv-card** command. The card type appears in the *TYPE* column for each card in the system. The card location appears in the *CARD* column; the first two digits of the location are the frame and shelf number where the card is installed.
2. Verify that two HIPR cards are equipped on the same shelf as the HC-MIM or E5-E1T1 card for the port or link to be provisioned.
3. Re-enter the command specifying the correct **loc** parameter that generated this error.

E3491 Cmd Rej: Port is channel bridged with its master port

Commands Used: **chg-e1**, **chg-t1**, **dlt-e1**, **dlt-t1**

Parameter values cannot be changed for the even-numbered E1/T1 port interface (**e1port** or **t1port** parameter) in a channel bridged pair. The values must be changed in the odd-numbered port interface.

A channel bridged slave (even-numbered) port on an HC-MIM card or an E5-E1T1 card cannot be specified in the **e1/t1port** parameter. To delete channel bridged port interfaces, specify the master

(odd-numbered) port in the **e1/t1port** parameter. The slave port interface is automatically deleted when its master port interface is deleted.

Recovery

Re-enter the command specifying a channel bridged master E1/T1 port instead.

E3492 Cmd Rej: ADD/DROP mode provisioned FORCE=YES required

Commands Used: `inh-card`

If channel bridging (Add/Drop mode) is active then **force=yes** is required to inhibit the card. Force removal of the card.

The **force** parameter must be specified if the card is the last card supporting a linkset, SCCP subsystem, Measurement Platform Subsystem, EPAP-to-DSM connection, E1, or GLS. Also if the TDM contains a security log with un-uploaded entries or any other TDM process in progress.

Recovery

Re-enter the `inh-card` command specifying **force=yes**.

E3493 Cmd Rej: MULTCC entry already exists in the GSM Options CC list

Commands Used: `chg-gsmopts`, `chg-stpopts`

You attempted to specify an entry in the GSM Options MULTCC List, but the command failed because the country code already exists there. The attempted entry was either the **defcc** (`chg-stpopts` command) or the **multcc** (`chg-gsmopts` command).

Recovery

1. If the specified value already entered is acceptable, no change is required since that value already exists.
2. To change the **defcc** or **multcc** parameter values, enter one of the following commands:
 - a) To change a **defcc** value,
 - Enter the command `chg-gsmopts:multcc=xxx:nmultcc=none`, which deletes the **multcc** value **xxx**.
 - Enter the command `chg-stpopts:defcc=xxx` to assign a Default Country Code to the GSM Options MULTCC list.
 - b) To change a **multcc** value,
 - Enter the command `chg-gsmopts:multcc=xxx:nmultcc=yyy`, which replaces the value **xxx** with value **yyy** in the GSM Options MULTCC list.

For more information about the Default Country Codes and Multiple Country Codes, refer to the *Commands Manual*.

E3494 Cmd Rej: Link is invalid for card location

Commands Used: dact-slk, dlt-slk, ent-slk, rtrv-slk

An invalid link was entered for the card. Refer to Appendix A of the *Commands Manual* for the valid links for each card type.

Recovery

Re-enter the command specifying a valid card location.

E3495 Cmd Rej: CHANBRDG is invalid for even numbered card location

Commands Used: chg-e1, chg-t1, ent-e1, ent-t1

The **chanbrdg=on** parameter cannot be specified for an HC-MIM card in an even-numbered ($n+1$) card location. An odd-numbered (n) port must be specified.

The **chanbrdg=on** parameter indicates that an odd-numbered port is to pair with its even-numbered port for non-signaling data pass through.

Recovery

Re-enter the command specifying even-numbered ($n+1$) card location.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3496 Cmd Rej: E1/T1 Port greater than 2 unavailable

Commands Used: chg-e1, ent-e1, ent-t1

You must specify an odd-numbered card location (**loc=n**). The **e1port** parameter values 3 through 8 cannot be specified for an even-numbered HC-MIM card location.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for the valid combination of parameters specific to the command that generated this error message.

E3497 Cmd Rej: Either ALIASN or ALIASN24, not both, for destination

Commands Used: chg-dstn, ent-dstn

You cannot enter values for both the **aliasn** and the **aliasn24** parameters in the same command. For ANSI or ITU-I destinations, these parameters are mutually exclusive and must be entered individually in separate commands.

Recovery

Re-enter the command specifying a value for either the **aliasn** or the **aliasn24** parameter, but not both.

E3499 Cmd Rej: GTT Selector does not exist in GTIN24-TT-NP(V)-NAI(V)

Commands Used: `dlt-gttsel`

The specified command does not match an existing **gtin24**, **tt**, **np/nai**, and **npv/naiv** parameter combination as required.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttsel` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3500 Cmd Rej: GFLEX feature must be ON

Commands Used: `chg-sid`, `chg-srvsel`, `chg-stpopts`, `ent-srvsel`, `rtrv-srvsel`, `chg-gsmopts`, `enable-ctrl-feat`

Table 20: Conditions that Generate Error Message E3500 describes the conditions that cause this error.

Table 20: Conditions that Generate Error Message E3500

Command	Condition
<code>chg-srvsel</code> , <code>ent-srvsel</code> , <code>rtrv-srvsel</code>	The G-Flex feature must be turned on before the nserv/serv=gflex parameter can be specified.
<code>chg-gsmopts</code>	The G-Flex feature must be turned on before the parameters defmnc , ccnc , or mccmnc parameter can be specified.
<code>chg-stpopts</code>	The G-Flex feature must be turned on before the ansigflex option can be enabled.
<code>enable-ctrl-feat</code>	The G-Flex feature must be turned on before the G-Flex MAP Layer Routing feature can be enabled.
<code>chg-sid</code>	When CPC is provisioned for G-Flex.

Recovery

1. Display the features in the database. Enter the `rtrv-ctrl-feat` command.
If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature as necessary. Refer to the *Feature Manual - G-Flex* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3501 Cmd Rej: CCNC cannot be NONE

Commands Used: `chg-gsmopts`

You cannot specify a value of **none** for the country code and network code (**ccnc**) parameter.

Recovery

Re-enter the command specifying a valid value (2-8 digits [**0-9, a-f, A-F**]) for the **ccnc** parameter.

E3502 Cmd Rej: The NONE value is not allowed in this case

Commands Used: `chg-prefix, dlt-homern, dlt-subnetid, dlt-vendid, ent-homern, ent-subnetid, ent-trace, ent-vendid, ent-vflx-vmsid`

You cannot specify a value of **none** for one of the following command parameters:

1. One of the following `ent-trace` command parameters: **dn, entityid, gt, imei, or imsi**.
2. The **rn** parameter of an `ent-homern` or `dlt-homern` command.
3. GSM MAP SRI Redirect feature prefix values.
4. The `ent-vflx-vmsid` command using one the command parameters **IDX0** through **IDX9**.

The EAGLE 5 ISS does not allow this action.

Recovery

Re-enter the command specifying a valid parameter value.

E3505 Cmd Rej: Prepaid SMS Intercept Ph1 feature must be ON

Commands Used: `chg-ppsopts, chg-srvsel, ent-srvsel, rtrv-ppsopts`

The Prepaid Short Message Service (PPSMS) Intercept Phase 1, IDP A-Party Routing, or IDP Service Key Routing feature must be enabled and turned on before the `chg-ppsopts` command can be entered.

The PPSMS feature must be turned on before the command and parameter combinations in [Table 21: Prepaid SMS Intercept Ph 1 Commands/Parameters](#) can be specified.

Table 21: Prepaid SMS Intercept Ph 1 Commands/Parameters

Commands	Parameters
chg-ppsopts	ri, pci, pcn, setid, gta, gta1, gta2, gta3, ngta, ppt
chg-srvsel	serv=smsmr or nserv=smsmr
ent-srvsel	serv=smsmr or nserv=smsmr
rtrv-ppsopts	ppt
rtrv-srvsel	serv=smsmr

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* and to the appropriate Feature Manual for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3507 Cmd Rej: Translation TYPEN24 already exists

Commands Used: `ent-tt`

The translation type (**typen24**) specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

1. Determine if the translation type that you want to use already exists in the translation type table.
Enter the `rtrv-tt` command.
2. Re-enter the `ent-tt` command specifying a different translation type.

E3511 Cmd Rej: CCNC and MCCMNC parameters must be entered together

Commands Used: `chg-gsmopts`

If you specify one of the following parameters, you must specify the other as well: **ccnc** and **mccmnc**.

Recovery

Re-enter the command specifying both the **ccnc** and **mccmnc** parameters.

E3512 Cmd Rej: All provisioned shelves must have HIPR cards

Commands Used: `ent-card`

HIPR cards must be installed on all provisioned shelves in the system before the system can contain more than **115** ATM cards.

Recovery

1. Install two HIPR cards on all provisioned shelves in the system.
Refer to the procedure "HIPR/HMUX Card Replacement" in the *Maintenance Manual – EAGLE 5 ISS*.
2. Re-enter the `ent-card` command to add the desired number of LIM ATM cards to the database.
For additional information refer to the section "Cards that use the `ent-card` Command", in Appendix A of the *Commands Manual*.

E3514 Cmd Rej: Maximum of 10 unique CCNCs allowed

Commands Used: `chg-gsmopts`

You specified the **ccnc/mccmnc** parameter combination. You are allowed to have up to ten sets of **ccnc/mccmnc** parameter combinations. The command would have exceeded the ten allowed sets.

Recovery

1. To delete an existing **ccnc/mccmnc** parameter combination, enter the `chg-gsmopts:ccnc=xx:mccmnc=none` command where *xx* (the value of the **ccnc** parameter) specifies the **ccnc/mccmnc** parameter combination to delete.
2. Re-enter the `chg-gsmopts` command that generated this error message.

E3515 Cmd Rej: CCNC already exists

Commands Used: `chg-gsmopts`

You specified either `ccnc=xx:mccmnc=yy` and the **ccnc** already exists, or `ccnc=xx:mccmnc=none` and the **ccnc** does not exist. The **ccnc** must not exist unless **mccmnc=none** is specified.

To add a new **ccnc/mccmnc** parameter combination, enter the `chg-gsmopts:ccnc=xx:mccmnc=yy` command where *xx* (the value of the **ccnc** parameter) and *yy* (the value of the **mccmnc** parameter) specify the **ccnc/mccmnc** parameter combination to add.

To delete an existing **ccnc/mccmnc** parameter combination, enter the `chg-gsmopts:ccnc=xx:mccmnc=none` command where *xx* (the value of the **ccnc** parameter) specifies the **ccnc/mccmnc** parameter combination to delete.

Recovery

Re-enter the `chg-gsmopts` command that generated this error message.

E3517 Cmd Rej: VSCCP cards have insufficient extended memory

Commands Used: `chg-ctrl-feat`

You attempted to turn on the INP or AINPQ feature, but your VSCCP cards do not have sufficient memory. At least one daughterboard on the DSM card is required.

Before the AINPQ feature can be turned on, each provisioned DSM/VSCCP card must have at least 4 GB of memory.

Recovery

1. Upgrade your hardware to a 4 GB DSM cards. Refer to the DSM card replacement procedure in Appendix A of the Maintenance Manual.
2. Re-enter the command.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3518 Cmd Rej: Active OAM must be equipped with E586 hardware

You attempted to bring INP online, but your active Operations, Administration, and Maintenance (OAM) module is not equal to the task. You need to upgrade the hardware.

Recovery

1. Upgrade your OAM hardware.
2. Re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3519 Cmd Rej: Standby OAM must be equipped with E586 hardware

Commands Used: `chg-feat`

You attempted to bring INP online, but your standby Operations, Administration, and Maintenance (OAM) module is not equal to the task. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Re-enter the `chg-feat` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3522 Cmd Rej: Service Selector Table is full

Commands Used: `ent-srvsel`

You cannot add an entry to the Service Selector table because the Service Selector table is full.

Recovery

Perform one of the following actions:

- Delete an entry from the Service Selector table. Enter the `dlt-srvsel` command.
- OR
- Change an entry in the Service Selector table. Enter the `chg-srvsel` command.

E3523 Cmd Rej: At least one parameter must be changed(NSNP, NSNAI, NSERV)

Commands Used: `chg-srvsel`

You must specifying at least one of the following parameters: **nsnp**, **nsnai**, or **nserv**.

Recovery

Re-enter the `chg-srvsel` command specifying at least one of the following parameters: **nsnp**, **nsnai**, or **nserv**.

E3524 Cmd Rej: INP/AINPQ feature(s) must be ON

Commands Used: `chg-inpopts`, `chg-sid`, `chg-srvsel`, `chg-ss-appl`, `dlt-homern`, `dlt-ss-appl`, `ent-homern`, `ent-srvsel`, `ent-ss-appl`, `rtrv-homern`, `rtrv-inpopts`, `rtrv-sid`, `rtrv-srvsel`

Table 22: Conditions that Generate Error Message E3524 describes the conditions that cause this error.

Table 22: Conditions that Generate Error Message E3524

Commands	Condition
<code>chg-inpopts</code> , <code>dlt-homern</code> , <code>ent-homern</code> , <code>rtrv-homern</code> , <code>rtrv-inpopts</code>	The INP or AINPQ feature must be turned on before you can specify these commands.

Commands	Condition
chg-sid, rtrv-sid	The INP feature must be turned on before the cpctype=inp parameter can be specified.
chg-srvsel, ent-srvsel, rtrv-srvsel	The INP or AINPQ feature must be turned on before the serv=inp or serv=inpq parameter can be specified.
chg-ss-appl, dlt-ss-appl, ent-ss-appl	The INP feature must be turned on before the appl=inp parameter can be specified.

Recovery

1. Display the features in the database. Enter the `rtrv-ctrl-feat` command.
2. Refer to the *Feature Manual- INP/AINPQ* to enable, turn on, and use the INP and AINPQ features.
3. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3525 Cmd Rej: Command will cause system clock outage – Use FORCE=YES

Commands Used: `init-card`, `init-flash`

You cannot specify the Initialize TDM Bitfile indicator (**initclk**) parameter if the resulting TDM bitfile reload would cause a system clock outage. To override this restriction and allow the TDM bitfile to reload (resulting in a system clock outage), you must specify the **force=yes** parameter.

The following scenarios will result in a system clock outage.

- Trying to initialize both MASPs at one time. If **initclk=yes** and **appl=eoam** is specified (bitfiles on both TDMs will be initialized).
- A simplex (single TDM) MASP configuration. If **initclk=yes** and the TDM card specified in the **loc** parameter is the only good HS clock source that is currently active.
- A bad clock status on the remaining TDM card.

Note:

Creating a system clock outage will probably result in the loss of traffic on all links.

Recovery

Perform one of the following:

- Re-enter the command without specifying the **initclk** parameter
- OR
- Re-enter the command specifying **force=yes**, which will create a system clock outage and possibly stop the traffic on some or all links.

E3526 Cmd Rej: Invalid TDM configuration for INITCLK

Commands Used: `init-card`, `init-flash`

You can specify the Initialize TDM Bitfile indicator (**initclk**) parameter for only TDM cards that support bitfile reloading, that is, TDMs with part number 870-0774-15 or later, (or 870-0774-18).

Recovery

Perform one of the following:

- Ensure that TDM cards with part number 870-0774-15 or later, (or 870-0774-18), are installed in card locations **1114** and **1116**. If your TDMs are not the correct part number and level, contact your Customer Care Center.

OR

- Re-enter the command without specifying the **initclk** parameter.

E3527 Cmd Rej: NMULTCC entry already exists in the GSM Options MULTCC list

Commands Used: `chg-gsmopts`

You specified an `nmultcc` parameter value for the GSM Options MULTCC List, but that value already exists there. Duplicate `multcc` entries are not supported.

Recovery

1. Display the `multcc` parameter values currently in the MULTCC list.
Enter the `rtrv-gsmopts` command.
2. Re-enter the `chg-gsmopts` command specifying a value for the `nmultcc` parameter that does not appear as a `multcc` value in the output from Step 1.

E3529 Cmd Rej: Application type not in SS-APPL table

Commands Used: `dlt-ss-appl`

The value specified for the **appl** parameter must already exist in the SS-APPL table.

Recovery

- Display the values for the SS-APPL table. Refer to the *Database Administration Manual - Systems Management* for assistance.
- If the value specified for the **appl** parameter is not shown in the output of Step 1, it must be added.
- If the value for the `appl` parameter does exist in the output from Step 1, Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3534 Cmd Rej: E1 Port test command in progress

Commands Used: `tst-e1`

A port test is in progress on this e1port. Only one port test can be performed at a time. Subsequent test requests are rejected until the e1port test is complete.

Recovery

Wait for all tests to complete, then re-enter the `tst-e1` command.

E3535 Cmd Rej: E1 Port test command not in progress

Commands Used: `tst-e1`

There is no active test in progress on this e1port. The parameter **action=stop** cannot be performed if there is no active port test.

Recovery

Re-enter the `tst-e1` command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

E3537 Cmd Rej: Card's A/B interface IP Networks must be unique

Commands Used: `chg-ip-lnk`

The IP network addresses assigned to the A and B interface ports are not unique.

Recovery

1. Display the existing IP addresses for the card.
Enter the `rtrv-ip-card` command.
2. Define a correct IP address for the card.
Enter the `chg-ip-card` command.
3. Verify that the **port** and **ipaddr** parameters in the `chg-ip-lnk` command specify unique addresses for ports A and B.
4. Re-enter the `chg-ip-lnk` command specifying the correct parameters.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3538 Cmd Rej: Linkset SLK requires ITUN APC/SAPC to be 14bit or 24bit only

Commands Used: `chg-ls`, `ent-slk`

For the `chg-ls` command:

- A linkset cannot have both a 14-bit ITU-N and a 24-bit ITU-N APC/SAPC unless it contains only IPGWI links or IPLIM M3UA links. These links support 14-bit ITU-N and 24-bit ITU-N traffic simultaneously.
- A linkset with the `ipgwapc=no` parameter cannot have both a 14-bit ITU-N and a 24-bit ITU-N APC/SAPC if no links are provisioned. The SAPC cannot be a 24-bit ITU-N point code if the linkset contains IPLIM or E1 ATM links, which do not support 24-bit ITU-N traffic.

For the `ent-slk` command:

- Linksets with 14-bit ITU-N and 24-bit ITU-N APCs or SAPCs can contain only IPGWI or IPLIMI M3UA links. These links support 14-bit ITU-N and 24-bit ITU-N traffic simultaneously.
- Linksets containing 24-bit ITU-N APCs or SAPCs cannot contain E1 ATM links. These links do not support 24-bit ITU-N traffic.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

E3541 Cmd Rej: Failed reading GSM Options Table

Commands Used: `chg-gsmopts`, `chg-stpopts`, `rtrv-gsmopts`

The GSM Options table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3542 Cmd Rej: Failed reading GSM SSN Table

Commands Used: `dlt-gsm-ssn`, `ent-gsm-ssn`, `rtrv-gsm-ssn`

The GSM SSN table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.

2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3543 Cmd Rej: Failed reading GTT Selector Table

Commands Used: chg-gtttsel, dlt-gtttsel, dlt-gttset, dlt-ls, ent-gtttsel, rtrv-gtttsel

The GTT Selector table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3544 Cmd Rej: Failed reading GTT Set Table

Commands Used: chg-gsmsmsopts, chg-gtttsel, chg-gta, chg-gttset, chg-is41smsopts, chg-sccpopts, dlt-gta, dlt-gttset, ent-gta, ent-gtttsel, ent-gttset, rtrv-gta, rtrv-gtttsel, rtrv-gttset, rtrv-sccpopts

The GTT Set table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3545 Cmd Rej: Failed reading SERV Selector Table

Commands Used: chg-srvsel, dlt-srvsel, ent-srvsel, rtrv-srvsel

The Service Selector table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3547 Cmd Rej: System serial number entered is invalid

Commands Used: ent-serial-num

The system serial number with the `ent-serial-num` command is unacceptable for one of the following reasons:

- The system serial number entered with the `lock=yes` parameter does not match the contents of the Serial Number table in the database.

OR

- The system serial number entered does not meet all these rules:
 1. The string must be alphanumeric and cannot exceed **15** characters
 2. The first two characters must be alphabetic (referred to as the prefix)
 3. All remaining characters must be numeric
 4. The string cannot contain any special characters (including space)
 5. The format for acceptable characters is: `[A..Z] | [a..z] | [0..9]`

Recovery

Re-enter the `ent-serial-num` command specifying a valid system serial number.

E3548 Cmd Rej: System serial number is already locked in database

Commands Used: `ent-serial-num`

The serial number entered has already been locked in the Serial Number table. Once the table is locked, you cannot enter the serial number again.

Recovery

Contact your Customer Care Center if you need to change the serial number.

E3550 Cmd Rej: GTT must be on before EGTT can be on

Commands Used: `chg-feat`

The Global Title Translation (GTT) feature must be turned on (`gtt=on`) before the Enhanced Global Title Translation (EGTT) feature can be turned on (`egtt=on`). When the EGTT feature is turned on, three new command sets, the GTT Selector (`ent/chg/dlt/rtrv-gttset`), GTT Set (`ent/dlt/rtrv-gttset`), and GTA (`ent/chg/dlt/rtrv-gta`) commands, replace the following Translation Type and Global Title Translation commands: `ent/dlt/rtrv-tt`, and `ent/chg/dlt/rtrv-gtt`. All data previously provisioned with these commands is maintained.

Note:

When the EGTT feature is turned on, three new command sets, the GTT Selector (`ent/chg/dlt/rtrv-gttset`), GTT Set (`ent/dlt/rtrv-gttset`), and GTA (`ent/chg/dlt/rtrv-gta`) commands, replace the following Translation Type and Global Title Translation commands: `ent/dlt/rtrv-tt`, and `ent/chg/dlt/rtrv-gtt`. All data previously provisioned with these commands is maintained.

Note: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3551 Cmd Rej: NP and NPV must not be specified together

Commands Used: `chg-gtttsel`, `chg-sccp-msg`, `chg-srvsel`, `dlt-gtttsel`, `dlt-srvsel`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`, `rtrv-srvsel`

The `np` and `npv` parameters cannot be specified together.

The `cdnp` and `cdnpv` parameters and the `cgnp` and `cgnpv` parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the `np` or the `npv` parameter, but not both.

E3552 Cmd Rej: NAI and NAIV must not be specified together

Commands Used: `chg-gtttsel`, `chg-sccp-msg`, `chg-srvsel`, `dlt-gtttsel`, `dlt-srvsel`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`, `rtrv-srvsel`

The `nai` and `naiv` parameters cannot be specified together.

The `cdnai` and `cdnaiv` parameters and the `cgnai` and `cgnaiv` parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the `nai` or the `naiv` parameter, but not both.

E3553 Cmd Rej: GTI (A)=4, and GTI (X)=1 and 3 are not supported

Commands Used: `chg-gtttsel`, `chg-sccp-msg`, `chg-srvsel`, `dlt-gtttsel`, `dlt-srvsel`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`, `rtrv-srvsel`, `tst-msg`

The `gtia=4`, `gti/gtia/gtii/gtin/gtin24=1`, and `gti/gtia/gtii/gtin/gtin24=3` parameters cannot be specified.

For an ANSI message, the CDPA GTI must be 2 and the CGPA GTI must be 0 or 2 (see the `chg-sccp-msg` command). For an ITU message, the CDPA GTI must be 2 or 4 and the CGPA GTI must be 0, 2, or 4.

For the `chg-sccp-msg` command: The values 1 and 3 cannot be specified for the `cdgti` and `cggti` parameters.

Recovery

Re-enter the command specifying a valid value for the global title indicator. Refer to the *Commands Manual* for more information.

E3554 Cmd Rej: NP(V) and NAI(V) must not be specified for given GTI value

Commands Used: `chg-gtttsel`, `chg-srvsel`, `dlt-gtttsel`, `dlt-srvsel`, `ent-gta`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`, `rtrv-srvsel`

You cannot specify `gtii/gtin/gtin24=2` and the `np/nai` or the `npv/naiv` parameter combinations. If you specify `gtii/gtin/gtin24=2`, the `np/nai` or the `npv/naiv` parameter combinations are invalid.

Recovery

Perform one of the following actions:

- Re-enter the command specifying `gtii/gtin/gtin24=4` and specify either the `np/nai` or the `npv/naiv` parameter combinations.
- OR
- Re-enter the command specifying `gtii/gtin/gtin24=2` without specifying the `np/nai` or the `npv/naiv` parameter combinations.

E3555 Cmd Rej: NP(V) and NAI(V) must be specified for given GTI value

Commands Used: `chg-gtttsel`, `chg-srvsel`, `dlt-gtttsel`, `dlt-srvsel`, `ent-gtttsel`, `ent-srvsel`

If the `gtii/gtin/gtin24=4` parameter is specified, then an `np(v)` and `nai(v)` parameter combination must be specified. These parameters can be specified in any combination: `np` and `naiv`, `npv` and `nai`, `np` and `nai`, or `npv` and `naiv`.

Recovery

Re-enter the command specifying an `np(v)` and `nai(v)` parameter combination. Refer to the *Commands Manual* for more information.

E3556 Cmd Rej: This command is not valid when EGTT is ON

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `ent-tt`, `rtrv-gtt`, `rtrv-tt`

This command is not valid when the EGTT feature is turned on. Once the EGTT feature is turned on:

- A new set of EGTT commands replaces the old GTT or TT commands and,
- The system will no longer accept the old GTT or TT commands.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the EGTT feature is off (from the output of Step 1), re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the EGTT feature is on (from the output of Step 1), the new EGTT command sets replace the old GTT and TT commands:
 - a) GTT Set commands: `ent/dlt/rtrv-gttset`
 - b) GTA commands: `ent/chg/dlt/rtrv-gta`
 - c) GTT Selector commands: `ent/chg/dlt/rtrv-gttset`

E3557 Cmd Rej: EGTT must be ON before this command can be entered

Commands Used: `chg-gsmsmsopts`, `chg-gta`, `chg-gttset`, `chg-gttset`, `dlt-gta`, `dlt-gttset`, `dlt-gttset`, `chg-feat`, `enable-ctrl-feat`, `ent-gta`, `ent-gttset`, `ent-gttset`, `rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`

The Enhanced GTT (EGTT) feature must be turned on before the following features can be enabled:

- Flexible Linkset Optional Based Routing (FLOBR)
- MO SMS B-Party Routing
- Origin-based SCCP Routing (OBSR)

For the `chg-gsmsmsopts` command, the EGTT feature must be turned on before the `is41smcgttsn` parameter can be specified.

Note: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Note: The Global Title Translation (GTT) feature must be turned on before the Enhanced Global Title Translation (EGTT) feature can be turned on. Refer to the *Database Administration Manual - Global Title Translation* for assistance.

Recovery

1. Display the status of the EGTT feature. Enter the `rtrv-feat` command.
2. Turn on the EGTT feature if necessary. Refer to the *Commands Manual* and to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3559 Cmd Rej: GTT Selector specified by GTI-TT-NP(V)-NAI(V) does not exist

Commands Used: `dlt-gttset`

The command specified does not match an existing `gti`, `tt`, `np/ nai`, and `npv/ naiv` parameter combination as required.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttset` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3560 Cmd Rej: GTT Set specified by GTTSN already exists

Commands Used: `ent-gttset`

The value specified for the `gttsn` parameter already exists in the database. This action is not allowed.

Recovery

1. Display the existing GTT set entries.
Enter the `rtrv-gttset` command. In the output, the existing GTT sets are listed in the GTTSN column.
2. Re-enter the `ent-gttset` command specifying a value for the `gttsn` parameter that does not already exist.

E3561 Cmd Rej: GTT Set specified by GTT Set Name/index does not exist

Commands Used: `chg-gsmsmsopts`, `chg-gta`, `chg-gttset`, `chg-is41smsopts`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `rtrv-gta`, `rtrv-gttset`

The value specified for the `gttsn`, `bpartygttsn`, or `is41smcgttsn` parameter must match the name of an existing GTT Set.

Recovery

1. Display the GTT set information. Enter the `rtrv-gttset` command.
The existing GTT sets are listed in the GTTSN column.
2. If necessary, create a new GTT set entry. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message.
4. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3562 Cmd Rej: Network domains of GTI and CdPA GTT Set must match

Commands Used: `chg-gttset`, `ent-gttset`

For `chg-gttset`: The network domain (ANSI or ITU) must match that of the GTT Set entry that is specified by the `cdgttsn`, `cdgtasn`, or `gttsn` parameter.

For `ent-gttset`: The network domain of the specified GTT selector must match the domain of the GTT set that is specified by the `gttsn`, `cdgtasn`, or `cdgttsn` parameter, unless the domain of the GTT set has a value of cross.

Recovery

1. Display the domain of the existing GTTSN.
Enter the `rtrv-gttset` command. The domain is listed in the NETDOM column of the output.
2. Perform one of the following actions:
 - a) Re-enter the command specifying a GTI that matches the network domain of the existing GTT set.
OR
 - b) Re-enter the command specifying an existing GTT set that matches the network domain of the GTI.

E3563 Cmd Rej: NAI entries per TT-NP combination has reached allowed max

Commands Used: `ent-gttset`

If the `gti(x)=4` parameter is specified, then the GTT selector table cannot have more than 5 `nai` entries per `tt/np` combination.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttset` command.
2. Delete an entry from the table.
Enter the `dlt-gttset` command.
3. Re-enter the `ent-gttset` command that generated this error message.

E3564 Cmd Rej: GTT Set table is full

Commands Used: `ent-gttset`

The specified GTT set could not be entered into the GTT Set table because the GTT Set table is full. The GTT Set table cannot contain more than 2000 entries.

Recovery

1. Display the GTT Set table.
Enter the `rtrv-gttset` command. The GTT sets are listed in the GTTSN column.
2. Delete one of the existing entries.
Enter the `dlt-gttset` command. Note that you may first have to delete any GTT selectors (`dlt-gttset`) or GTAs assigned (`dlt-gta`) to the GTT set.
3. Re-enter the `ent-gttset` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3565 Cmd Rej: GTT Set must not be specified as NONE

Commands Used: `chg-gta`, `chg-gttset`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `ent-gttset`, `ent-gttset`, `rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`

A value of **none** cannot be specified for the **gttsn**, **cdgtasn**, **cggtasn**, **cgpcsn**, **cdgttsn**, and **cggttsn** parameters.

Recovery

Re-enter the command specifying a valid value for the GTT Set.

Refer to the *Commands Manual* for more information.

E3566 Cmd Rej: GTT Set specified by GTTSN has GTT Selectors assigned to it

Commands Used: `dlt-gttset`

The specified GTT set cannot have any GTT selectors assigned to it. The value specified for the GTT set name (**gttsn**) parameter is being used by one or more GTT selectors.

Recovery

1. Display a list of the GTT selectors assigned to the GTT set.
Enter the `rtrv-gttset:gttsn=` command.
2. Delete the GTT selectors assigned to the GTT set.
Enter the `dlt-gttset` command.
3. Re-enter the `dlt-gttset` command that generated this error message.

E3567 Cmd Rej: GTT Set must not be used by or assigned to any Translation

Commands Used: `chg-gttset`, `dlt-gttset`

For the `chg-gttset` command, the number of digits (**ndgt**) parameter is invalid if GTAs are assigned to the GTT Set.

For the `dlt-gttset` command: The specified GTT set cannot have the **gta**, **cgpc**, **cgssn**, **opc**, **cdssn** or **opcode** parameters assigned to it and cannot be used by any translation.

Recovery

1. Display the GTAs assigned to the GTT set.
Enter the `rtrv-gta:gttsn=` command.
2. Delete the assigned GTAs from the GTT set.
Enter the `dlt-gta` command.
3. Re-enter the `dlt-gttset` command.

E3568 Cmd Rej: NTT can only be specified when XLAT=DPCNGT

Commands Used: `chg-gta`, `ent-gta`

You cannot specify the **ntt** parameter without specifying the translate indicator **xlat=dpcngt** parameter. If the **ntt** parameter is specified, the **xlat=dpcngt** parameter must be specified.

If the ANSI-ITU-China SCCP Conversion feature is not on, the **ntt** parameter can be specified only when the **xlat=dpcngt** parameter is specified

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **ntt** parameter and **xlat=dpcngt**.
- OR
- Re-enter the command without specifying the **ntt** parameter.

E3569 Cmd Rej: NTT must be specified when XLAT=DPCNGT

Commands Used: `chg-gta`, `ent-gta`, `rtrv-gta`

You cannot specify **xlat=dpcngt** without specifying the **ntt** parameter. If the **xlat=dpcngt** parameter is specified, the **ntt** parameter must also be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying both the **ntt** and **xlat=dpcngt** parameters.
OR
- Re-enter the command without specifying the **xlat=dpcngt** parameter.

E3570 Cmd Rej: Point Code type does not match GTT Set network domain

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

For `chg-gta`, `ent-gta`, the ANSI-ITU-China SCCP Conversion feature must be enabled and turned on before a translated point code that is of a different domain than the GTT set specified by the **gttsn** parameter can be specified.

The point code specified for the network type does not match the network domain of the GTT set name (**gttsn**) parameter. The network type of the specified point code must be the same as the network domain of the GTT set.

- If the specified GTT Set is an ANSI set, the point code must be a valid ANSI point code (**cgpc/cgpc**, **opc/opca**).
- If the specified GTT Set is an ITU set, the point code must be a valid ITU point code (**cgpci/cgpcn/cgpcn24**, **opci/opcn/opcn24**).

Recovery

1. Determine the network domain of the GTT set.
Enter the `rtrv-gttset` command. The network domain is listed in the **NETDOM** column of the output.
2. Re-enter the command specifying a point code whose network type matches the specified **gttsn** parameter.

E3571 Cmd Rej: GTA Length does not match GTT Set number of digits

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

The length of the specified **gta** parameter must match the number of digits provisioned for the specified GTT set when the VGTT feature is turned off. If the VGTT feature is turned on, then up to 10 GTA lengths can exist per GTT set. If the Support for 16 GTT Lengths in VGTT feature is turned on, then up to 16 GTA lengths can exist per GTT set.

Recovery

1. Display the number of digits allocated for the GTT set.
Enter the `rtrv-gttset` command. The number of digits is listed in the **NDGT** column of the output.
2. Re-enter the command specifying a GTA that contains one of the GTA lengths listed in the output of Step 1.

E3572 Cmd Rej: RI must be SSN when CCGT is YES

Commands Used: `chg-gta`, `ent-gta`

If a new or existing `ccgt=yes` parameter is specified, a new or existing `ri=ssn` parameter must be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying `ri=ssn`.
- OR
- Re-enter the command without specifying the `ccgt=yes` parameter.

E3573 Cmd Rej: CCGT must be NO when PC is the STP's PC or CPC

Commands Used: `chg-gta`, `ent-gta`

If the new or existing `pc/pca/pci/pcn/pcn24` parameter is an STP PC or CPC, the `ccgt=no` parameter must be specified.

Recovery

Re-enter the command specifying the `ccgt=no` parameter.

E3574 Cmd Rej: NTT must be specified for new values of XLAT/RI

Commands Used: `chg-gta`

You specified the `xlat=dpcngt` and `ri=gt` parameters, and without the `ntt` parameter. The `ntt` parameter must be specified if you specify the `xlat=dpcngt` and `ri=gt` parameters.

Recovery

Re-enter the `chg-gta` command specifying the `xlat=dpcngt`, `ri=gt`, and the `ntt` parameters.

E3575 Cmd Rej: The sum of the values for NPCFMTI must be equal to 14

Commands Used: `chg-stpopts`

The sum of all the values specified by the `npcfmti` parameter (`m1+m2+m3+m4`) must equal 14. If the ITU national point code format has less than four numbers, the parts of the point code format not being used must be specified as 0. All four parts of the point code format must be specified, no matter

how many numbers the point code format will contain. Some examples follow: **npcfmti=7-7-0-0**, **npcfmti=0-6-8-0**, **npcfmti=0-0-4-10**, **npcfmti=3-8-3-0**, and **npcfmti=14-0-0-0**.

Recovery

Re-enter the `chg-stpopts` command specifying a valid value for the **npcfmti** parameter.

E3578 Cmd Rej: NP and NAI must be specified as DFLT together

Commands Used: `chg-gtttsel`, `dlt-gtttsel`, `rtrv-gtttsel`

A value of **dflt** must be specified for the **np** and **nai** parameters, or neither value can be **dflt**.

Recovery

Re-enter the command specifying both the **np=dflt** and the **nai=dflt** parameters.

E3579 Cmd Rej: NI parameter may not be specified for ITU linksets

Commands Used: `rept-meas`

If the **type=gtwy** parameter is specified, and the value of the **enttype** parameter is **lsorigni**, **lsdestni**, or **lsonismt**, then the **ni** parameter cannot be specified for ITU linksets. The **ni** parameter is allowed only for ANSI linksets.

Recovery

Perform one of the following actions:

- Re-enter the `rept-meas` command but do not specify the **ni** parameter.
- OR
- Re-enter the `rept-meas` command specifying an ANSI linkset for the **lsn** parameter.

E3581 Cmd Rej: SSN value must be the LNP, INP, EIR, VFLEX or ATINPQ SSN

Commands Used: `alw-map-ss`, `inh-map-ss`

The value specified for the **ssn** parameter must be the LNP, INP, EIR, V-Flex or ATINPQ subsystem number.

Recovery

1. Enter the `rtrv-ss-appl` command to obtain the number that correctly identifies the subsystem. The output identifies the subsystem/SSN combination as shown in the following example: APPL SSN STAT LNP 15 online

2. Re-enter the command that generated this error message specifying the correct value for the `ssn` parameter.

E3582 Cmd Rej: INP subsystem is offline in database

Commands Used: `alw-map-ss`

The INP subsystem must be online in the database before this command can be entered.

Recovery

Enter the command `chg-ss-appl:appl=inp:nstat=online` to activate the INP subsystem.

E3583 Cmd Rej: Initial Command Response Timeout

Commands Used: all commands

A response from the entered command has not been received on the OAM/EOAM, within the two-second command response interval.

Recovery

1. Wait for five minutes until the OAM/EOAM return to an operational state.
2. Reconnect to the server and re-enter the original command.

E3584 Cmd Rej: Feature configuration requires DSM card with VSCCP appl

Commands Used: `chg-ctrl-feat`, `enable-ctrl-feat`

A Service Module card running the `vsccp` application must be present in the system before the feature can be enabled. TSM cards cannot be used. Refer to the command descriptions in the *Commands Manual* for a list of features that require Service Module cards running the `vsccp` application.

Recovery

1. Upgrade the hardware configuration so that only Service Module cards running the `vsccp` application are present in system. Refer to the applicable Card Removal/Replacement procedure in the *Maintenance Manual* for assistance.
2. Re-enter the command that generated this error message. Refer to the appropriate feature manual for assistance in enabling and turning on the feature and to the *Maintenance Manual* for assistance in provisioning a card.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3585 Cmd Rej: Dest IP Address is invalid

Commands Used: `dlt-ip-rte`, `ent-ip-rte`, `rtrv-ip-rte`

You specified an invalid destination IP address in the **dest** parameter of the command.

To be valid, the specified destination IP address must:

- consist of four numbers separated by dots, with each number in the range of **0–255**
- not be the default route (**0.0.0.0**)
- not correspond to any loopback address (i.e. **127.X.X.X**)
- be unique per card
- not correspond to an IP address that is local to this card's A or B network

Recovery

Re-enter the command specifying a valid destination IP address as per the conditions listed above.

E3586 Cmd Rej: Dest IP Address already exists for this card

Commands Used: `ent-ip-rte`

The specified destination IP address (**dest**) parameter already exists for the card in the location specified by the **loc** parameter.

Recovery

1. Display the existing destination IP addresses for the card.
Enter the `rtrv-ip-rte` command.
2. Re-enter the `ent-ip-rte` command specifying a destination IP address that is unique and does not already exist for the specified card.

E3587 Cmd Rej: Dest IP Address cannot be local to this cards A, B network

Commands Used: `ent-ip-rte`

You cannot define a destination IP address that is local to the A or B network for the card in the location specified by the **loc** parameter. For this command the destination IP address cannot be local to the A or B network for the card.

Recovery

1. Display the existing destination IP addresses for the card.
Enter the `rtrv-ip-rte` command.

2. Re-enter the `ent-ip-rte` command specifying a destination IP address that is not local to the A or B network for the specified card.

E3588 Cmd Rej: Dest IP Address does not exist for this card

Commands Used: `dlt-ip-rte`

You entered a command to delete a static IP route from the IP route table. The specified destination IP address (**dest**) parameter does not exist in the IP Route table for the specified card.

Recovery

To delete a static IP route entry for the specified card,

1. Display the existing destination IP addresses for the card.
Enter the `rtrv-ip-rte` command specifying the **loc** parameter.
2. Re-enter the `dlt-ip-rte` command specifying a valid destination IP address for the entry you want to delete for the specified card.
OR To delete the entry for the specified destination IP address,
3. Verify that there is a card with an entry containing the specified destination IP address.
Enter the `rtrv-ip-rte` command specifying the **dest** parameter.
4. Re-enter the `dlt-ip-rte` command specifying the correct card location in the **loc** parameter for the card that has the specified destination IP address.

E3589 Cmd Rej: Specified cards A, B interface IP Address must be assigned

Commands Used: `ent-ip-rte`

The A or B interface IP address has not been assigned for the card in the location that you specified in the **loc** parameter for the command.

Recovery

1. Display the existing IP addresses for the card.
Enter the `rtrv-ip-card` command.
2. Define the missing IP addresses for the card.
Enter the `chg-ip-card` command.
3. Re-enter the `ent-ip-rte` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3590 Cmd Rej: Temporary key is un-available

Commands Used: `enable-ctrl-feat`

The temporary access key has expired for the feature that you tried to enable.

Recovery

1. To continue to use the feature, you must purchase the feature from Tekelec. Contact your Customer Care Center.
2. When you have purchased the feature and obtained a permanent feature access key, re-enter the `enable-ctrl-feat` command to enable the feature.

E3591 Cmd Rej: Invalid System serial number

Commands Used: `ent-serial-num`

The serial number that was entered in the command does not meet one of the following naming conventions:

- Up to 15 alphanumeric characters (**A...Z**, **a...z**, or **0...9**). Mixed case is allowed.
- The first two characters (the prefix) must be letters.
- The remaining characters must be numeric.
- No special characters or spaces.

Recovery

Note: Call the Customer Care Center before using the command. Entering a serial number into the Secure Gateway with `lock=yes` is permanent. Correcting an incorrect serial number requires a manual procedure and system disk (MO) from Tekelec.

Re-enter the `ent-serial-num` command specifying the correct system serial number.

E3592 Cmd Rej: System serial number is already locked in database

Commands Used: `ent-serial-num`

You entered a command to enter the system serial number, and the serial number that you entered has already been locked in the Serial Number table. Once the table is locked, you cannot enter the serial number again.

Recovery

If you need to change the serial number, Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3593 Cmd Rej: Part Number does not belong to an On/Off Feature

Commands Used: `chg-ctrl-feat`

The Part Number specified in the command must be for an On/Off feature that is currently on. If a Permanently On feature is turned on with this command, then it cannot be turned off. Refer to the command description in the *Commands Manual* for a list of On/Off features.

Recovery

Determine the status of the feature in the system. Enter the `rtrv-ctrl-feat` command.

Note: If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.

Contact the Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E3595 Cmd Rej: Def Router IP Addr must be local to this cards A, B network

Commands Used: `chg-ip-card`

You specified an IP address in the **defrouter** parameter that is not local to the A or B network for this card. The **defrouter** IP address must be local to this card's A or B network.

Recovery

1. Display the local A and B network IP addresses and the current **defrouter** IP address for this card.
Enter the `rtrv-ip-card` command specifying the **loc** parameter for this card.
2. Re-enter the `chg-ip-card` command specifying a defrouter IP address that is local to the A or B network for this card.

E3596 Cmd Rej: IP Address still referenced by the Def Router

Commands Used: `chg-ip-lnk`

You entered a command to change the **ipaddr** and **subnet** values to addresses that represent a different network. You cannot change to an address on a different network if the **defrouter** address is assigned to this network interface.

Recovery

1. Display the current **defrouter** IP addresses.
Enter the `rtrv-ip-card` command.
2. Display the current **ipaddr** and **submask** addresses.
Enter the `rtrv-ip-lnk` command.

3. Re-enter the `chg-ip-lnk` command specifying **ipaddr** and **submask** values that are on this network.

E3597 Cmd Rej: IP Address still referenced by static IP Routes

Commands Used: `chg-ip-lnk`

You entered a command to change the **ipaddr** and **submask** values to addresses that represent a different network. You cannot change to an address on a different network if the address is referenced by any static IP routes using this network interface.

Recovery

1. Display the current static IP route addresses.
Enter the `rtrv-ip-rte` command.
2. Display the current **ipaddr** and **submask** addresses.
Enter the `rtrv-ip-lnk` command.
3. Re-enter the `chg-ip-lnk` command specifying **ipaddr** and **submask** values that are on this network.

E3598 Cmd Rej: LNP ELAP Configuration and WNP features must be ON

Commands Used: `enable-ctrl-feat`

You entered a command to enable the LNP SMS feature. The LNP ELAP Configuration and Wireless Number Portability (WNP) features must be turned on before you can enable the LNP SMS feature.

Recovery

1. Verify that the GTT, LNP, LNP ELAP Configuration, and WNP features have been purchased and turned on in the system.
 - a) Display a list of features controlled by feature bits and their status in the system. Enter the `rtrv-feat` command.
 - b) Display a list of features in the system controlled by a feature access key. Enter the `rtrv-ctrl-feat` command.Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
2. If necessary, turn on the LNP ELAP Configuration feature. Refer to the procedure "Activating the LNP Feature on the EAGLE 5 ISS" in the LNP Feature Activation Guide.
3. If necessary, turn on the WNP feature. Enter the command: `chg-feat:wnp=on`.
4. Enable the LNP SMS feature. Refer to the procedure "Activating the LNP Short Message Service (SMS) Feature" in the LNP Feature Activation Guide.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3599 Cmd Rej: WSMSC feature must be Activated

Commands Used: `chg-lnp-serv`, `chg-lnpopts`, `ent-lnp-serv`

For the `chg-lnpopts` command, the LNP Short Message Service (LNP SMS) feature must be turned on before you can specify the `wsmc10dig` parameter.

OR

For the `ent-lnp-serv` or `chg-lnp-servsv` commands, the LNP Short Message Service (LNP SMS) feature must be turned on before you can specify the `serv=wsmc` parameter.

Recovery

1. Display those features in the system that are controlled with feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Refer to the LNP Feature Activation Guide for instructions on enabling and turning on the LNP SMS feature and the features that must be turned on before the LNP SMS feature can be turned on.
3. When the LNP SMS feature is turned on in the system, re-enter the command specifying the parameter that requires the LNP SMS feature to be on.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3612 Cmd Rej: SSN must be in SS-APPL table when PC is true point code

Commands Used: `chg-gta`, `ent-gta`

If the `pc/pca/pci/pcn/pcn24` parameter, `ssn` parameter, or both, are specified, and the point code is the STP true point code, then the `ssn` value must exist in the **SS-APPL** table.

Recovery

Re-enter the command without specifying the `ssn` parameter.

OR

1. Display a list of SSNs that exist in the SS-APPL table. Enter the `rtrv-ss-appl` command.
2. Re-enter the command that generated this error message specifying a value for the `ssn` parameter.

E3615 Cmd Rej: T1 Port test command in progress

Commands Used: `tst-t1`

A T1 Port test is in progress. Only one port test is performed at a time. Subsequent test requests are rejected and this error is displayed.

Recovery

Wait for all tests to complete, then re-enter the `tst-t1` command.

E3616 Cmd Rej: APC/SAPC type and group code must match DPC

Commands Used: `chg-rte`, `ent-rte`, `chg-rtx`, `ent-rtx`

The adjacent point code/secondary adjacent point code (APC/SAPC) type and group code in the linkset specified by the `lsn` parameter must match the value specified by the destination point code parameter. The STP ensures that the route destination type and group code match the route Link Set Adjacent PC /Secondary Adjacent PC type and group code.

Recovery

1. Verify the Adjacent Point Code / Secondary Adjacent Point Code(s) of the linkset specified in the command that generated this error. Enter the `rtrv-ls` command.
2. Perform one of the following:
 - a) Re-enter the command specifying a destination (`dpc`, `dpca`, `dpci`, `dpcn`, or `dpcn24`) that matches the point code type and group code of the Adjacent Point Code (`apc`, `apca`, `apci`, `apcn`, or `apcn24`) or one of the Secondary Adjacent Point Codes (`sapcn` or `spci`) of the linkset specified by the `lsn` parameter.
OR
 - b) Provision a Secondary Adjacent Point Code (`sapci`, `sapcn`, or `sapcn24`) that matches the point code type and group code of the destination point code (`dpci`, `dpcn`, or `dpcn24`) specified by the command. Enter the `chg-ls` command.
3. Re-enter the command causing this error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3618 Cmd Rej: LHOST and ALHOST must refer to different IP addresses

Commands Used: `chg-assoc`, `ent-assoc`

In the command that you entered, the `lhost` and `alhost` names refer to the same IP address. The hostnames specified in the `lhost` and `alhost` parameters must refer to different IP addresses.

Recovery

Re-enter the command specifying `lhost` and `alhost` names that do not refer to the same IP address.

E3619 Cmd Rej: LHOST and ALHOST must refer to IP address on the same card

Commands Used: `chg-assoc`, `ent-assoc`

In the command that you entered, the **lhost** and **alhost** names reference IP addresses on different IP cards. The hostnames specified in the **lhost** and **alhost** parameters must refer to IP addresses on the same IP card.

Recovery

Re-enter the command specifying **lhost** and **alhost** names that reference IP addresses on the same IP card.

E3629 Cmd Rej: Turn off EISCOPY before changing PVN and PVNMask

Commands Used: `chg-netopts`

You entered a command to change the Private Virtual Network (PVN) IP address and the PVN subnet mask in the system. The EAGLE 5 Integrated Monitoring Support featurecopy function must be turned off before you can change the PVN and PVN submask addresses in the system. You can turn the copy function back on after the addresses are changed.

Recovery

1. Turn off the EIS copy function. Enter the `chg-eisopts:eiscopy=off` command.
2. Re-enter the `chg-netopts` command to change the PVN and PVN submask.
3. Turn the copy function on. Enter the `chg-eisopts:eiscopy=on` command.

E3630 Cmd Rej: Entry is already defined as the STP Options DefCC

Commands Used: `chg-gsmopts`

A value was entered for the **multcc** or **nmultcc** parameter that was already defined as the STP Options Default Country Code (**defcc**). The EAGLE 5 ISS does not support duplicate use of these entries.

Recovery

1. Enter the `rtrv-stpopts` and `rtrv-gsmopts` commands and examine the **defcc** and **multcc** definitions.
2. Re-enter the `chg-gsmopts` command specifying a value for the **multcc** or **nmultcc** parameter that differs from all the **defcc** and **multcc** values shown in output from Step 1.

E3631 Cmd Rej: Incompatible Feature/Option status

Commands Used: `chg-gsmsmsopts`, `chg-measopts`, `chg-mtc-measopts`, `chg-srvsel`, `chg-stpopts`, `dlt-srvsel`, `ent-srvsel`, `rept-ftp-meas`, `rept-meas`, `rtrv-is41opts`, `rtrv-srvsel`

Using this command requires that the features be in the status shown in [Table 23: Feature/Option Status](#):

Table 23: Feature/Option Status

chg-gsmopts	The G-Flex feature must be turned on or the G-Port or IGM feature must be enabled before the ccnc and mccmnc parameters can be specified.
chg-gsmsmsopts	The Portability Check for MO SMS feature or the MO-based GSM SMS NP feature must be turned on before the mosmsdignat or mosmstcapseg parameter can be specified.
chg-measopts, chg-mtc-measopts	The A-Port, G-Port, IGM, MO SMS IS41-to-GSM Migration, MO-based GSM SMS NP, MO-based IS41 SMS NP, Prepaid SMS Intercept Ph1, TIF ASD, TIF GRN, TIF Number Portability, or TIF Simple Number Substitution feature must be enabled, or the INP feature must be turned on before the mtchnp=on parameter or the mtcdnp=on parameter can be specified.
chg-srvsel, rtrv-srvsel	The PPSMS or Portability Check for MO SMS feature must be turned on, or the MO SMS ASD, MO SMS GRN, MO SMS IS41-to-GSM Migration, MO SMS B-party Routing, MO-based GSM SMS NP, or MO-based IS41 SMS NP feature must be enabled before the nserv=smsmr parameter can be specified.
chg-stpopts	If the TN quantity key is above 228M, or if ELAP version 8.0 or above is provisioned, then the dsmaud=ccc parameter cannot be specified.
ent-srvsel	The PPSMS or Portability Check for MO SMS feature must be turned on, or the MO SMS ASD, MO SMS GRN, MO SMS IS41-to-GSM Migration, MO SMS B-party Routing, MO-based GSM SMS NP, or MO-based IS41 SMS NP feature must be enabled before the serv=smsmr parameter can be specified.
rept-ftp-meas, rept-meas	The A-Port, G-Port, IGM, Prepaid SMS Intercept Ph1, TIF ASD, TIF GRN, TIF Number Portability, or TIF Simple Number Substitution feature must be enabled, or the INP, MO SMS IS41-to-GSM Migration, MO-based GSM SMS NP, or MO-based IS41 SMS NP feature must be turned on before the mtchnp=on parameter or the mtcdnp=on parameter can be specified.
rtrv-is41opts	The APORT or IGM feature must be enabled before this command can be entered.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* and to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3632 Cmd Rej: MULTCC list is full

Commands Used: `chg-gsmopts`

A value was entered for the **multcc**, but the GSM Options MULTCC list has already reached its limit of ten entries. No additional **multcc** entries are allowed.

Recovery

Since the **multcc** entries are limited and filled, either accept the current entries, or delete one to make room for a new entry. In the latter case, use the command `chg-gsmopts:multcc=xxx:nmultcc=yyy` to replace value `xxx` with value `yyy` in the GSM Options MULTCC list.

E3633 Cmd Rej: MULTCC entry does not exist

Commands Used: `chg-gsmopts`

If the **multcc** and **nmultcc** parameters are specified to change the **multcc** value to the **nmultcc** value, then the **multcc** value must already exist in the multiple country code list.

Recovery

1. Determine the **multcc** values. Enter the `rtrv-gsmopts` command.
2. Re-enter the command specifying a valid **multcc** value.

E3634 Cmd Rej: Cannot set DefCC to none if a GSM Options MULTCC is defined

Commands Used: `chg-stpopts`

You cannot specify a Default Country Code of none (**defcc=none**) if a GSM Options MULTCC entry is already defined.

Recovery

If a GSM Options MULTCC is already defined, specifying **defcc=none** is invalid. You can either:

1. Re-enter the command without specifying the **defcc=none** parameter.
OR
2. Delete all GSM Options MULTCC definitions, and then re-enter the `chg-stpopts` command.

For more information about this command refer to the Commands Manual.

E3635 Cmd Rej: UIM number does not exist in STP Trouble Text Table

Commands Used: `set-uim-acthresh`

You specified an invalid UIM number. The UIM number must exist in the system Trouble Text table.

Recovery

1. Verify that the UIM number has been entered correctly.
Refer to the *Unsolicited Alarm and Information Messages Manual* for a complete list of UIM numbers.
2. Re-enter the `set-uim-acthresh` command, specifying a valid UIM number.

E3638 Cmd Rej: Failed Reading SS Appl table

Commands Used: `chg-gta`, `ent-gta`

The SS Appl table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3640 Cmd Rej: Failed reading OAP configuration table

Commands Used: `chg-oap-config`, `act-oap-config`

The OAP configuration table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3641 Cmd Rej: Specified OAP not available

Commands Used: `act-oap-config`

For the `act-oap-config` command to execute, the link from the EAGLE 5 ISS to the specified OAP(s) must be in service.

Recovery

1. Enter the `rtrv-oap-config` command to check whether the entry for `config` is `snl` or `dual`.
2. Enter the `rtrv-trm` command to see which terminals are OAP terminals.
3. Enter the `rept-stat-trm` command to check whether the entry for the specified OAP(s) is IS-NR.
4. Correct any problems, and re-enter the `act-oap-config` command as you entered it previously.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3642 Cmd Rej: The current LSMS and the associated NSAP, PSEL and SSEL required

Commands Used: `act-oap-config`

Before this command can be executed, the database must be configured for Network Service Access Point (NSAP), Presentation Selector (PSEL), and Session Selector (SSEL) for the specified LSMS (main or shadow) for the LNP feature. If the LNP feature is on, the LSMS and associated `nsap`, `p sel` and `s sel` parameters must be specified in order to update specified OAP.

Recovery

1. Display information about your OAP configuration. Enter the `rtrv-oap-config` command.
2. If entries exist in the *LSMS NSAP*, *LSMS SSEL*, and *LSMS PSEL* fields for the specified Active LSMS (main or shadow) for the OAP(s) that you are configuring, re-enter the `act-oap-config` command.
3. If entries are missing from the fields identified in Step 2, enter the `chg-oap-config` command specifying the missing (`nsap`, `p sel` and `s sel`) parameter values.
4. Re-enter the `act-oap-config` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3643 Cmd Rej: If OAP parameter not specified as ALL, FORCE=YES required

Commands Used: `act-oap-config`

The **force=yes** parameter must be specified with the `act-oap-config` command, if you enter the `oap=a`, `oap=b`, or `oap=none` parameter.

Recovery

Re-enter the `act-oap-config` command specifying **force=yes**.

E3644 Cmd Rej: Specified OAP does not exist

Commands Used: `act-oap-config`

You specified the `oap=a`, `oap=b`, or `oap=all` parameter with the `act-oap-config` command. For the command to execute, the specified OAP(s) must be configured, and the link from the EAGLE 5 ISS to the OAP(s) must be in service.

Recovery

1. Verify the primary state (PST) of the OAP(s). Enter the `rept-stat-seas` command.
2. If the entry IS-NR does not appear in the *PST* field for the specified OAP(s), the link is not in service.
3. If the entry IS-NR does appear in the *PST* field for the specified OAP(s), re-enter the `act-oap-config` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3646 Cmd Rej: GWS must be ON before CNCF can be ON

Commands Used: `chg-feat`

The Gateway Screening (GWS) feature must be turned on before you can turn on the CNCF feature.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the Commands Manual for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the GWS feature is on (from the output of Step 1), re-enter the `chg-feat:cncf=on` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the GWS feature is off (from the output of Step 1), turn it on. Enter the `chg-feat:gws=on` command.
4. Turn on the CNCF feature. Enter the `chg-feat:cncf=on` command.

E3647 Cmd Rej: WNP feature must be ON

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

You specified `serv=wnp` or `nserv=wnp`, but the Wireless Number Portability (WNP) feature is turned off.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the WNP feature is turned on (from the output of Step 1), re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the WNP feature is turned off (from the output of Step 1), turn it on. Enter the `chg-feat` command.
4. Re-enter the `ent-lnp-serv` command specifying `serv=wnp`.
OR
5. Re-enter the `chg-lnp-serv` command specifying `nserv=wnp`.

E3648 Cmd Rej: XLAT must be DPCSSN and RI must be SSN if PC is the True PC

Commands Used: `chg-gta`, `ent-gta`

If the `pc/pca/pci/pcn/pcn24` parameter is specified, and the point code is the STP true point code, then the value of the new or existing `xlat` parameter must be `dpcssn`, and the new or existing value of the `ri` parameter must be `ssn`.

Recovery

Perform one of the following actions:

- Re-enter the command specifying `xlat=dpcssn` and `ri=ssn`.
OR
- Re-enter the command specifying a point code that is not a true point code.

E3655 Cmd Rej: Failed reading the GWS Stop Action Set table

Commands Used: all gateway screening and gateway screening stop action set commands

The GWS Stop Action table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3656 Cmd Rej: ACTNAME specified must exist in the GWS Stop Action Set table

Commands Used: all gateway screening commands

You entered a value for the **actname** parameter that is not in the GWS Stop Action Set table.

Recovery

1. Enter the `rtrv-gws-actset` command. The *ACT NAME* field in the output shows a list of valid action names.
2. If the value you entered appears in the output, Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the value you entered does not appear in the output, it can be added to the database via the `chg-gws-actset` command.

E3657 Cmd Rej: NSR cannot be specified if ACTNAME is specified

Commands Used: all gateway screening commands, except gateway screening enter commands

You cannot specify both the **nsr** and the **actname** parameters with this command.

Recovery

Re-enter the command specifying a value for either the **actname** or the **nsr** parameter, but not both.

E3658 Cmd Rej: NSFI must be STOP if ACTNAME is specified

Commands Used: all gateway screening commands, except `ent-scr-aftpc` and `ent-scr-destfld`

To specify the **actname** parameter, specify the value for the Next Screen Function Identifier (**nsfi**) equal to **stop** (**nsfi=stop**).

Recovery

Re-enter the command specifying the **actname** parameter and **nsfi=stop**.

E3661 Cmd Rej: Target drive capacity must be sufficient to perform request

Commands Used: chg-db

The target drive does not have sufficient capacity to hold the required amount of data. Refer to the *Commands Manual* for the disk drive capacity requirements.

Recovery

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3664 Cmd Rej: Capacity of TDM(s) / TSM(s) insufficient to support request

Commands Used: chg-db

Both capacity and memory must be sufficient to support the number of ported telephone numbers allowed by the number of LNP 4DIGIT objects configured in the database (current setting plus the value of the **num** parameter). [Table 24: TSM and TDM Memory Requirements](#) describes the TSM and TDM requirements.

Table 24: TSM and TDM Memory Requirements

Number of LNP 4DIGIT Objects	Number of Ported Numbers Supported	TSM Memory Requirements	Fixed Disk Drive Capacity Requirements
1	2 Million	256 Mbytes	4 Gigabytes
2	4 Million	512 Mbytes	4 Gigabytes
3	6 Million	768 Mbytes	4 Gigabytes
4	8 Million	1024 Mbytes	4 Gigabytes
5	10 Million	1024 Mbytes	4 Gigabytes
6	12 Million	1024 Mbytes	4 Gigabytes

Recovery

Contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3668 Cmd Rej: No other optional parameters may be specified with "ALL"

Commands Used: `chg-gws-actset`

If the **all=none** parameter is specified, then no other optional parameters can be specified.

Recovery

Re-enter the command specifying **all=none** and no other optional parameters.

E3669 Cmd Rej: The CNCF feature must be on if CNCF is specified

Commands Used: `chg-gws-actset`

The Calling Name Conversion Feature (CNCF) must be turned on before a value of **cncf** can be specified for the **act1** through **act10** parameters.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the CNCF and GWS features are on, re-enter the `chg-gws-actset` command.
3. If the CNCF feature is turned off and GWS is on, turn the CNCF feature on. Enter the `chg-feat:cncf=on` command.
4. Re-enter the `chg-gws-actset` command.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3671 Cmd Rej: Duplicate ACTs in different slots are not allowed

Commands Used: `chg-gws-actset`

A specific gateway screening stop action can be specified for one, and only one, gateway screening stop action parameter for each gateway screening stop action set. Stop action values include: **cncf**, **copy**, **none**, **tinp**, **tlnp**, **tif**, **tif2**, **tif3**, or **rdct**.

Recovery

Re-enter the `chg-gws-actset` command without specifying identical values for more than one stop action within a stop action set.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3672 Cmd Rej: ACTNAME already exists in GWS Action Set Table

Commands Used: `chg-gws-actset`

The value you entered for the **actname** parameter is already defined in the database.

Recovery

1. Verify that the value you entered is already in the database. Enter the `rtrv-gws-actset` command.
2. Re-enter the `chg-gws-actset` command specifying a different value for the **actname** parameter.

E3673 Cmd Rej: COPY must be in ACT1

Commands Used: `chg-gws-actset`

You entered the parameter value of **copy** for an action set other than **act1**. The **copy** value can be used only with the **act1** parameter.

Recovery

Re-enter the command specifying **act1=copy**.

E3674 Cmd Rej: RDCT must be in lowest priority action slot

Commands Used: `chg-gws-actset`

You entered the parameter value of **rdct** (redirect) for a step action other than the last step action specified for the command. The **rdct** parameter value can only be specified for the last step action in an action set.

Recovery

Re-enter the command specifying **rdct** for the last step action in the action set.

E3675 Cmd Rej: An ACTNAME must be specified

Commands Used: `chg-gws-actset`

You entered a new gateway screening stop action set in the database, but you did not specify a value for the **actname** parameter. A value for the **actname** parameter is required when an action set is first entered in the database. Afterward, the **actname** parameter is optional.

Recovery

Re-enter the `chg-gws-actset` command specifying a unique value for the **actname** parameter.

E3678 Cmd Rej: ACTNAME and ACTID cannot both be specified

Commands Used: `rtrv-gws-actset`

You cannot enter the `rtrv-gws-actset` command specifying both the **actname** and the **actid** parameters. Specify either the **actname** or the **actid** parameter.

Recovery

Re-enter the `rtrv-gws-actset` command specifying a value for either the **actname** or the **actid**, but not both.

E3679 Cmd Rej: FORCE=YES must be specified to change existing stop action

Commands Used: `chg-gws-actset`

You cannot change an existing stop action within a stop action set without specifying the **force=yes** parameter.

Recovery

Re-enter the `chg-gws-actset` command specifying **force=yes**.

E3680 Cmd Rej: No match on ACTNAME parameter during retrieve

Commands Used: all gateway screening retrieve commands

The entered GWS stop action set name (**actname**) was not found.

Recovery

Enter the command specifying the screening reference to show all action set name identifiers, as well as other values for the screening reference.

E3681 Cmd Rej: Source and destination combination is not allowed

Commands Used: `act-upgrade`, `copy-gpl`

For the `act-upgrade` command, if the **dest=remove** parameter is specified, then the **src=fixed** and **src=usb** parameters cannot be specified.

For the `copy-gpl` command, GPLs can be copied only as follows:

- From the fixed disk on the active TDM to the removable cartridge
- From the removable cartridge to the fixed disk on the standby TDM

- From the active TDM to the standby TDM
- From the standby TDM to the removable cartridge

The active TDM cannot be the destination.

Recovery

Re-enter the command specifying the correct values for the parameters.

Refer to the *Commands Manual* for information about these commands.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3682 Cmd Rej: GWS and LNP must be ON before TLNP can be ON

Commands Used: `chg-feat`

The LNP feature must be turned on **and** the Gateway Screening feature must be turned on before the Triggerless LNP feature can be turned on.

Recovery

1. Display the status of the controlled features in the database. Enter the `rtrv-feat` and the `rtrv-ctrl-feat` command.
2. If both the GWS and LNP features are on (from the output of Step 1), re-enter the `chg-feat` command.

Note: The LNP feature is "turned on" when an LNP ported TNs quantity is shown in the `rtrv-ctrl-feat` command output.

Note: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a Permanently On feature that is controlled using a feature access key is turned on, it cannot be turned off.

3. Refer to the procedures in the *LNP Feature Activation Guide* and in the *Database Administration Manual - Gateway Screening* for using the TLNP feature.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3683 Cmd Rej: TLNP feature must be ON

Commands Used: `chg-gws-actset`, `chg-lnpopts`

You entered the `chg-gws-actset` command and the Triggerless LNP Feature (TLNP) is off.

OR

You entered the `chg-lnpopts` and specified the `jipprv` or `jipdigits` parameter, and the Triggerless LNP Feature (TLNP) is off.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the TLNP feature is turned on (from the output of Step 1), re-enter the command.
3. If the TLNP feature is turned off (from the output of Step 1), turn it on. Enter the `chg-feat:tlnp=on` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3684 Cmd Rej: TLNP and RDCT cannot be in the same action set

Commands Used: `chg-gws-actset`

The `tlnp` and `rdct` stop actions cannot be specified in the same action set.

Recovery

Re-enter the command specifying either the `tlnp` or `rdct` parameter for the action set.

E3685 Cmd Rej: TLNP and CNCF cannot be in the same action set

Commands Used: `chg-gws-actset`

The `tlnp` and `cncf` stop actions cannot be specified in the same action set.

Recovery

Re-enter the command specifying the `tlnp` or `cncf` stop action for the action set.

E3686 Cmd Rej: GTT DBMM table is full

Commands Used: `chg-gttsel`, `ent-gttsel`, `ent-gttset`, `ent-tt`

The GTT DBMM table is an internal table that should never reach full capacity. The GTTDBMM Table cannot contain more than 42,502 entries.

Recovery

Call the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3687 Cmd Rej: Cannot enter MULTCC if STP Options DefCC is NONE

Commands Used: `chg-stpopts`

You cannot specify a GSM Options MULTCC entry when the STP Options Default Country Code is defined as none (`defcc=none`).

Recovery

1. Because the STP Options Default Country Code is **none**, you must specify a value for the default country code (**defcc**) first, as in `chg-stpopts:defcc=xxx`.
2. Re-enter the `chg-stpopts` command specifying the Multiple Country Code (**multcc**) parameter.

E3688 Cmd Rej: 15-minute measurement collection in progress

Commands Used: `chg-measopts`, `rept-ftp-meas`, `rept-meas`, `rept-stat-meas`

Quarter-hourly collection and report processing cannot be in progress when report type **comp**, **systot**, **avl**, or **gtwy** is specified.

OR

The `rept-meas` command was entered with either the **type=systot**, **type=comp**, or **type=avl** parameter during routine collection.

OR

The `rept-ftp-meas` command was entered with either the **type=systot**, **type=comp**, **type=gtwy**, or **type=avl** parameter during routine collection.

Recovery

1. To get a report before routine collection has started, perform one of the following actions:
 - a) Enter the command specifying the **period=last** parameter.
OR
 - b) Enter the command without specifying the **period** parameter.
2. Re-enter the command after collection has completed.
(The prior period is no longer accessible).

E3689 Cmd Rej: Period must be 1/4 hour boundary

Commands Used: `rept-ftp-meas`, `rept-meas`

A quarter-hour boundary must be specified for the **qh** parameter, except for report type **mtch**; an hourly boundary must be specified for report type **mtch** (that is, only quarter hours ending in 00, such as 0100, 0200 or 0300).

Recovery

Re-enter the command specifying the **period=specific** and quarter hour (**qh**) parameters, and the values **00**, **15**, **30**, and **45** for the minutes portion of the **qh** parameter except for report type **mtch**; an hourly boundary must be specified for report type **mtch** .

E3690 Cmd Rej: QH cannot be specified unless 15 min meas is turned ON

Commands Used: `rept-ftp-meas`, `rept-meas`

The 15 Minute Measurements feature must be turned on and the 15 Minute Measurements collection option must be on before the **qh** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
2. Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for information about enabling, turning on, and using the 15 Minute Measurements feature.
3. When the 15 Minute Measurements feature is turned on, re-enter the command that generated this error message.

E3693 Cmd Rej: collect=on cannot be specified with 15 min coll operational

Commands Used: `chg-meas`

The **collect=on** parameter cannot be specified when the 15 Minute Measurements collection is operational. The 15 Minute Measurements collection option provides for only scheduled FTP reports; the 15 Minute Measurements feature does not support any scheduled UI reports. The **collect=on** parameter controls overall measurement collection and scheduled reporting. This message indicates the 15 Minute Measurements collection is already operational and only the supported 15 minute scheduled FTP reports will be available.

Recovery

Because the 15 Minute Measurements collection option (`chg-measopts:collect15min=on`) is already on, you cannot issue the **collect=on** parameter. No scheduled UI reports are available for the 15 Minute Measurements feature.

You can turn off the 15 Minute Measurements collection option to make scheduled UI reports available.

E3694 Cmd Rej: QH and HH cannot be specified together

Commands Used: `rept-ftp-meas`, `rept-meas`

The **hh** and **qh** parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the **qh** or **hh** parameters, but not both.

E3695 Cmd Rej: Command supported only for IPGWx and IPSG linksets

Commands Used: `rept-stat-iptps`

This command cannot be entered for linksets that are not IPGWx or IPSG M3UA linksets. The EAGLE 5 ISS does not support this command for non-IPGWx linksets.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command.
2. Re-enter the `rept-stat-iptps` command specifying one of the linkset names from Step 1.

E3697 Cmd Rej: 15-minute measurement feature must be ON

Commands Used: `chg-measopts`

The 15 Minute Measurements feature must be enabled and turned on before the `collect15min=on` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for details about enabling and turning on the 15 Minute Measurements feature.
3. Re-enter the `chg-measopts` command.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3698 Cmd Rej: At least one MCP card must be IS-NR

Commands Used: `chg-ctrl-feat`

When you entered the command, no Measurements Collection Processor card was IS-NR (in service-normal).

Recovery

1. Enter the `rtrv-card` and `rept-stat-card` commands to verify the status of MCPM cards in the system.

2. Refer to the Commands Manual and the Database Administration Manual - System Management for details about enabling and turning on the 15 Minute Measurements feature.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3699 Cmd Rej: EIR feature must be ON

Commands Used: `chg-gsmopts`, `chg-map`, `chg-measopts`, `chg-mtc-measopts`, `chg-sid`, `chg-srvsel`, `chg-ss-appl`, `ent-map`, `ent-srvsel`, `ent-ss-appl`, `ent-trace`, `rept-fpt-meas`

The Equipment Identity Register (EIR) feature must be turned on before the **dlt-ss-appl:appl=eir** command can be entered or before the following combinations of commands and parameters can be entered:

- `chg-gsmopts`- the **eirimsichk=on**, **eirgrsp=on**, or **eirrsptype=on** parameter can be specified
- `chg-map`- a true point code value for the **mpci** parameter can be specified
- `chg-measopts` or `chg-mtc-measopts`- the **mtcdeir=on** or **mtcheir=on** parameter can be specified
- `chg-sid`- the **cpctype=eir** parameter can be specified
- `chg-srvsel` or `ent-srvsel`- the **serv=eir** or **nserve=eir** parameter can be specified
- `chg-ss-appl` or `ent-ss-appl`- the **appl=eir** parameter can be specified
- `ent-map`- a true point code for the **pci** parameter can be specified
- `ent-trace`- the **imei=** parameter can be specified

Recovery

1. Determine if the EIR feature is enabled and turned on.
Enter the `rtrv-ctrl-feat` command.
2. If the EIR feature is on, re-enter the command that generated this error message.
Note:
Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.
3. If the EIR feature is not on, enable and turn it on.
Refer to the *Commands Manual* and the *Feature Manual – EIR* for details about enabling and activating the EIR feature.
4. Verify the EIR feature is on.
Enter the `rtrv-ctrl-feat` command.
5. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3700 Cmd Rej: SEAC CLI parameter requires SEAS feature

Commands Used: `chg-oap-config`

The SEAS feature must be turned on before the `seaccli` parameter can be specified.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the SEAS feature is on (from the output of Step 1), re-enter the `chg-oap-config` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If the SEAS feature is off (from the output of Step 1), turn it on. Enter the `chg-feat` command.
4. When the SEAS feature is turned on, re-enter the `chg-oap-config` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3701 Cmd Rej: X.25 packet size parameter requires SEAS feature

Commands Used: `chg-oap-config`

The SEAS feature must be turned on before the `x25ps` parameter can be specified.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the SEAS feature is on (from the output of Step 1), re-enter the `chg-oap-config` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If necessary, turn the SEAS feature on. Enter the command: `chg-feat: seas-on`.

E3702 Cmd Rej: X.25 mode parameter requires SEAS feature

Commands Used: `chg-oap-config`

The SEAS feature must be turned on before the `x25mode` parameter can be specified.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.

2. If the SEAS feature is on (from the output of Step 1), re-enter the `chg-oap-config` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If necessary, turn the SEAS feature on. Enter the command: `chg-feat:seas=on`.
4. When the SEAS feature is turned on, re-enter the `chg-oap-config` command that generated this error message.

E3703 Cmd Rej: NSAP parameter requires LNP feature

Commands Used: `chg-oap-config`

The LNP feature must be turned on before the **mnsap** and **snsap** parameters can be specified.

Recovery

1. Display the features in the database.

Enter the `rtrv-ctrl-feat` command. If the LNP feature is on, the LNP ported TNs entry appears in the output with a quantity that is less than or equal to **12,000,000**. Re-enter the `chg-oap-config` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

2. If necessary, enable the LNP feature.

Enter the following command: `enable-ctrl-feat:partnum=893011012:fak=<LNP FAK>`

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the `chg-ctrl-feat` command in the *Commands Manual* for further information.

Refer to the *LNP Feature Activation Guide* for details.

3. Re-enter the `chg-oap-config` command that generated this error message.

E3704 Cmd Rej: SSEL parameter requires LNP feature

Commands Used: `chg-oap-config`

The `spsel` and `sssel` parameters require that the LNP feature be turned on.

Recovery

1. Display the features in the database.

Enter the `rtrv-ctrl-feat` command.

2. If the LNP feature is on, the LNP ported TNs entry appears in the output with a quantity less than or equal to **12,000,000**.

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the `chg-ctrl-feat` command in the *Commands Manual* for further information.

3. If necessary, enable the LNP feature.

Enter the following command: `enable-ctrl-feat:partnum=893011012:fak=<LNP FAK>`
Refer to the *LNP Feature Activation Guide* for details.

4. Re-enter the `chg-oap-config` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3705 Cmd Rej: PSEL parameter requires LNP feature

Commands Used: `chg-oap-config`

The `mtsel` and `spsel` parameters require that the LNP feature be turned on.

Recovery

1. Display the features in the database.

Enter the `rtrv-ctrl-feat` command.

2. If the LNP feature is on, the LNP ported TNs entry appears in the output with a quantity less than or equal to **12,000,000**.
3. If necessary, enable the LNP feature.

Enter the command: `enable-ctrl-feat:partnum=893011012:fak=<LNP FAK>`

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Refer to the *LNP Feature Activation Guide* for details.

4. Re-enter the `chg-oap-config` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3706 Cmd Rej: LSMS parameter requires LNP feature

Commands Used: `chg-oap-config`

The `lsms` parameter requires the LNP feature to be turned on.

Recovery

1. Display the features in the database.

Enter the `rtrv-ctrl-feat` command.

2. If the LNP feature is on, the LNP ported TNs entry appears in the output with a quantity less than or equal to **12,000,000**.

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If necessary, enable the LNP feature.
Enter the command: `enable-ctrl-feat:partnum=893011012:fak=<LNP FAK>` Refer to the *LNP Feature Activation Guide* for details.
4. Re-enter the `chg-oap-config` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3707 Cmd Rej: OAP Hostname required before OAP update

Commands Used: `act-oap-config`

The database must be configured with the Hostname for either the SEAS or LNP feature, before the `act-oap-config` command can be executed. If the SEAS or LNP features are on, the **hostname** parameter must be specified in order to update the specified OAP.

Recovery

1. Display information about your OAP configuration. Enter the `rtrv-oap-config` command.
2. If there is an entry in the *HOSTNAME* field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If there is not an entry in the *HOSTNAME* field of the output, enter names for **aname** (OAP A) and/or **bname** (OAP B).
Enter the `chg-oap-config` command.
4. Re-enter the `act-oap-config` command that generated this error message.

E3708 Cmd Rej: OAP CFG required before OAP update

Commands Used: `act-oap-config`

The database must be configured for single or dual OAP(s) for either the SEAS or LNP feature, before the `act-oap-config` command can be executed. If the SEAS or LNP features are on, the **config** parameter must be specified in order to update the specified OAP.

Recovery

1. View information about your OAP configuration.
Enter the `rtrv-oap-config` command.

2. If an entry exists in the *CONFIG* field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If there is no entry in the *CONFIG* field of the output, specify a `cfg` value, using the `chg-oap-config` command.
4. Re-enter the `act-oap-config` command that generated this error message.

E3710 Cmd Rej: APPL not valid for command

Commands Used: `ent-card`, `init-card`, `rept-meas`, `rept-stat-card`

The value specified for the **appl** parameter is invalid. Refer to the *Commands Manual* for a list of valid values for the **appl** parameter.

Recovery

Re-enter the command specifying a valid value for the **appl** parameter.

Refer to the *Commands Manual* for more information.

E3713 Cmd Rej: OAP IP Address required before OAP update

Commands Used: `act-oap-config`

The database must be configured for Common Language Location Identifier for the LNP feature, before this command can be executed. If LNP feature is on, the IP Address (**aipaddr**) parameter must be specified in order to update specified OAP.

Recovery

1. Display any information about your OAP configuration.
Enter the `rtrv-oap-config` command.
2. If there is an entry in the *IP ADDRESS* field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If there is not an entry in the *IP ADDRESS* field of the output, enter names for **aipaddr** (OAP A) and/or **bipaddr** (OAP B).
Enter the `chg-oap-config` command.
4. Re-enter the `act-oap-config` command that generated this error message.

E3715 Cmd Rej: Insufficient #SCCP cards to support LIM - use FORCE=YES

Commands Used: `ent-card`

You tried to add an SS7 card (LIM card or DCM card containing IP links) to the database; however, the installation of the additional card might push the system's transactions-per-second (TPS) capacity beyond the level that the EAGLE 5 ISS can handle. The EAGLE 5 ISS calculates the current system TPS capacity based on the number and type of provisioned SCCP cards available in the system.

Each SCCP card can handle the following number of transactions-per-second: 850 for a TSM card and 1700 for a DSM card. The system must contain enough SCCP cards to handle the number of SCCP transactions-per-second that the SS7 cards send to the SCCP cards.

An SCCP card can be either

- a TSM card running the `sccp` application, or
- a DSM card running the `vsccp` application.

When you issue the `ent-card` command to add a card that requests service from either an SCCP card or VSCCP card, the EAGLE 5 ISS adds the current TPS level to the estimated TPS level for the new card. The EAGLE 5 ISS uses the following values to derive the TPS estimate: **53** for LSL (cards provisioned as SS7ANSI, CCS7ITU or SS7GX25 cards), **480** for ATM cards, and **1000** for IPLIM cards. The EAGLE 5 ISS then compares the sum to a user-configured threshold set via the `chg-th-alm` command. The purpose of the threshold is to generate an alarm (UAM 0330) if the threshold is exceeded. The SCCP TPS threshold also triggers this error message when you issue the `ent-card` command and the resulting TPS level (the current TPS plus the estimated TPS for the new card) exceeds the threshold level configured.

Recovery

Perform one of the following actions:

1. Enter the `chg-th-alm` command to increase the TPS threshold.
2. Re-enter the command that generated this error message.
OR
3. Re-enter the command that generated this error message specifying the **force=yes** parameter.
4. Add the required number of SCCP cards to the database after you add the SS7 card.
OR
5. Add the required number of SCCP cards to the database.
6. Add the SS7 card to the database.

E3716 Cmd Rej: APPL parameter must be specified with CONVERTNET action

Commands Used: `act-upgrade`

If you specify the **action=convertnet** parameter, you must also specify the **appl** parameter.

Recovery

Re-enter the `act-upgrade` command specifying the `action=convertnet` parameter and the `appl` parameter.

E3717 Cmd Rej: Both LIMIT and INTRVL must be specified for UIM threshold.

Commands Used: `set-uim-acthresh`

Both the `limit` and `intrvl` parameters must be specified to create a new UIM threshold.

Recovery

Re-enter the `set-uim-acthresh` command specifying both the `limit` and `intrvl` parameters.

E3718 Cmd Rej: SEAC CLI required before OAP update

Commands Used: `act-oap-config`

The database must be configured for the SEAC Common Language Location Identifier for the SEAS feature, before this command can be executed. If the SEAS feature is on, the SEAC CLI (`seaccli`) parameter must be specified in order to update the specified OAP.

Recovery

1. Display information about your OAP configuration.
Enter the `rtrv-oap-config` command.
2. If there is an entry in the *SEAC CLI* field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
3. If there is no entry in the *SEAC CLI* field of the output, enter the `chg-oap-config` command, specifying a value for the `seaccli` parameter.
4. Re-enter the `act-oap-config` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3719 Cmd Rej: SEAS X.25 packet size required before OAP update

Commands Used: `act-oap-config`

The database must be configured for X.25 Packet Size for the SEAS feature, before this command can be executed. If the SEAS feature is on, the X.25 packet size (`x25ps`) parameter must be specified in order to update specified OAP.

Recovery

1. Display information about your OAP configuration.
Enter the `rtrv-oap-config` command.
2. If there is an entry of 7 or 8 in the *X.25 PACKET SIZE* field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
3. If there is not an entry in the *X.25 PACKET SIZE* field of the output, specify an **x25ps** value, using the `chg-oap-config` command.
4. Re-enter the `act-oap-config` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3720 Cmd Rej: SEAS X.25 mode required before OAP update

Commands Used: `act-oap-config`

The database must be configured for X.25 mode for the SEAS feature, before this command can be executed. If the SEAS feature is on, the X.25 mode (**x25mode**) parameter must be specified in order to update specified OAP.

Recovery

1. Enter the `rtrv-oap-config` command to view information about your OAP configuration.
2. If there is an entry of DTE or DCE in the *X.25 MODE* field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
3. If there is not an entry of DTE or DCE in the *X.25 MODE* field of the output, enter the `chg-oap-config` command specifying a value for the **x25mode** parameter.
4. Re-enter the `act-oap-config` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3725 Cmd Rej: Removable drive database level is not compatible

Commands Used: `act-upgrade`

The removable cartridge cannot contain an EAGLE 5 ISS backup image.

Recovery



CAUTION

CAUTION: It is strongly recommended that this command be used only in conjunction with the system Upgrade Procedure for your target release. The Upgrade Procedure provides step-by-step information on performing an upgrade.

1. Verify that a backup image exists on the removable cartridge.
Enter the command `act-upgrade:action=dbstatus`.

2. If the backup image is present, follow the procedures in the *Upgrade Procedure* to remove the backup image. Refer to the *Commands Manual* for a list of valid actions to use with the `act-upgrade` command. If the output from Step 1 does not show a backup image, re-enter the `act-upgrade` command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3726 Cmd Rej: Active device state does not permit database change

Commands Used: `dlt-card`, `dlt-slk`, `ent-card`, `ent-slk`

If the link is In-Service, then this command cannot be entered. The card must be in an Out-Of-Service - Maintenance-Disabled (OOS-MT-DSBLD) state.

Recovery

1. Change the state of the card to OOS-MT-DSBLD. Enter the `inh-card` command.

Note:

If the card contains signaling links, all links must be OOS-MT-DSBLD before the card can be inhibited. Refer to the `canc-slk` (`dact-slk`) command in the *Commands Manual*.

2. Re-enter the command that generated this error message.

Recovery - `dlt-slk`

1. Disconnect (deactivate) the signaling link.
Enter the `canc-slk` or `dact-slk` command. The link is placed in the OOS-MT-DSBLD state.
2. Perform one of the following actions:
 - a) If the link to be deleted is the last or only link in a link set that is still used by an ordered route, enter the `dlt-slk` command specifying the **force=yes** parameter.
The `dlt-slk` command deletes the link specified in the **loc** and **port** parameters. OR
 - b) If the link set has more than one link, enter the `dlt-slk` command without specifying the **force** parameter, to delete the link specified in the **loc** and **port** parameters.
To delete the link set after all of its links have been deleted, use the `dlt-ls` command. Refer to the *Commands Manual*.

E3727 Cmd Rej: Max number of cards of application type already exist

Commands Used: `ent-card`

You cannot exceed the maximum number of cards allowed for that application type in the database.

Refer to the `ent-card` command and Appendix A of the *Commands Manual* for additional card information.

Recovery

1. Display the cards and assigned application types in the database.
Enter the `rtrv-card` command.
2. If the number of cards per application type is less than the maximum number allowed, re-enter the `ent-card` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3728 Cmd Rej: Card(s) not in-service normal - FORCE parameter required

Commands Used: `act-upgrade`, `init-card`

You attempted the command without all cards of the specified GPL type being in the in-service normal (IS-NR) state. The **force=yes** parameter must be specified for cards that are not the In-service Normal state.

Recovery

Re-enter the command specifying the **force=yes** parameter.

E3729 Cmd Rej: APPL parameter valid only with CONVERTNET action

Commands Used: `act-upgrade`

If the **appl** parameter is specified, then the **action=convertnet** parameter must be specified. If the **action=convertnet** parameter is specified, then the **appl** parameter must be specified.

Recovery

- Re-enter the `act-upgrade` command specifying the **appl** and **action=convertnet** parameters.
- Contact the Customer Care Center if this message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3731 Cmd Rej: Invalid Hostname

Commands Used: `chg-assoc`, `dlt-ip-host`, `ent-assoc`, `ent-ip-host`, `rept-stat-assoc`, `rept-stat-applsock`, `rtrv-assoc`, `rtrv-ip-host`

The value specified for the **host** parameter must begin with an alphabetic character and can contain **a-z**, **A-Z**, **0-9**, **-**, or **..**. The host name can be up to **60** characters in length.

Recovery

Re-enter the command specifying a valid value for the **host** parameter. Refer to the *Commands Manual* and to the *Database Administration Manual-IP7Secure Gateway* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3732 Cmd Rej: Invalid Subnet Mask

Commands Used: `chg-ip-card`, `chg-ip-lnk`, `ent-ip-rte`, `ent-dlk`

A valid value must be specified for the **bpsubmask** parameter. If the **ipaddr** parameter is specified, the **submask** parameter must be specified and must be valid for the class of the entered IP address. [Table 25: Subnet Mask Values](#) lists supported submask values.

Table 25: Subnet Mask Values

Class A Networks	Class A or B Networks	Class A, B, or C Networks
255.0.0.0	255.255.0.0	255.255.255.0
255.192.0.0	255.255.192.0	255.255.255.192
255.224.0.0	255.255.224.0	255.255.255.224
255.240.0.0	255.255.240.0	255.255.255.240
255.248.0.0	255.255.248.0	255.255.255.248
255.252.0.0	255.255.252.0	255.255.255.252
255.254.0.0	255.255.254.0	
255.255.128.0	255.255.255.128	

Recovery

Re-enter the command specifying a value for the submask parameter.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3733 Cmd Rej: Socket name not found

Commands Used: `dlt-appl-rtkey`

The specified socket name was not found in the associated table. The following Recovery procedures list by command the remedial action to take for this error.

Recovery

1. Determine if the entered socket name is present in the *SNAME* field of the output. Enter the `rtrv-appl-rtkey` command.

2. If the entered name is present, re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3735 Cmd Rej: Hostname must be unique

Commands Used: `ent-ip-host`

The value specified for the **host** parameter cannot already exist in the IP host table.

Recovery

1. Display the host names currently in the IP host table. Enter the `rtrv-ip-host` command specifying no parameters. This information is shown in the *HOST* field of the output.
2. Re-enter the `ent-ip-host` command specifying a host name that does not match any of the names displayed in the *HOST* field in the output of Step 1. Refer to the *Commands Manual* and to the *Database Administration Manual-IP7 Secure Gateway* for more information.

E3736 Cmd Rej: Socket name already exists

Commands Used: `ent-appl-rtkey`

You entered a socket name into the Routing Key table with filter parameters (**dpc/dpca**, **si**, **ssn**, **opc**, **cics**, **cice**), using the `ent-appl-rtkey` command, but an identical socket name with identical filter parameters is already present.

Recovery - `ent-appl-rtkey`

1. Display the socket names and filter parameters in the Routing Key table. Enter the `rtrv-appl-rtkey` command.
2. If the specified socket name and filter parameters are not in the Routing Key table in the output of Step 1, re-enter the `ent-appl-rtkey` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3738 Cmd Rej: Host table is full

Commands Used: `ent-ip-host`

The IP Host table can have a maximum of 2048 entries.

Recovery

1. Display the entries in the IP Host table. Enter the `rtrv-ip-host` command.

2. Delete an existing entry from the IP host table. Enter the `dlt-ip-host` command specifying the **host** parameter for the entry to be deleted.
Refer to the *Commands Manual* and to the *Database Administration Manual-IP7 Secure Gateway* for more information.
3. Add the desired IP host entry to the IP Host table. Re-enter the `ent-ip-host` command specifying the desired value for the **host** parameter.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3739 Cmd Rej: No Entry found

Commands Used: `dlt-ip-host`

The value specified for the **host** parameter must already exist in the IP Host table.

Recovery

1. Verify that the host name is not in the IP Host table. Enter the `rtrv-ip-host` command. Host names are shown in the *HOST* field of the output.
2. If the host name is shown in the *HOST* field of the output, re-enter the `dlt-ip-host` command.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3740 Cmd Rej: If AUTO=yes, then DUPLEX and SPEED are not allowed

Commands Used: `chg-ip-lnk`

If you enter the `chg-ip-lnk` command specifying **auto=yes**, you cannot specify the **duplex** and/or **speed** parameters.

Recovery

Perform one of the following actions:

- Re-enter the `chg-ip-lnk` command specifying **auto=yes** without specifying the **duplex** and/or **speed** parameters.
- OR
- Re-enter the `chg-ip-lnk` command specifying **auto=no** and the **duplex** and/or **speed** parameters.

E3741 Cmd Rej: If TIMER is specified, TVALUE must be specified

Commands Used: `chg-dcmps`

If you enter the `chg-dcmps` command specifying the **timer** parameter, you must also specify the **tvalue** parameter.

Recovery

Re-enter the `chg-dcmps` command specifying both the **timer** and the **tvalue** parameters.

E3742 Cmd Rej: If PARM is specified, PVALUE must be specified

Commands Used: `chg-dcmps`

If you enter the `chg-dcmps` command specifying the **parm** parameter, you must also specify the **pvalue** parameter.

Recovery

Re-enter the `chg-dcmps` command specifying both the **parm** and the **pvalue** parameters.

E3743 Cmd Rej: SSN required if SI is 3

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `dlt-rmt-appl`, `ent-appl-rtkey`, `ent-rmt-appl`

You entered a value of **si=3** (or the string equivalent **si=sccp**) for this command, but you did not specify a value for the **ssn** parameter. If you enter **si=3**, you must also enter a value for the **ssn** parameter.

Recovery

Re-enter the command specifying **si=3** and a value for the **ssn** parameter .

E3745 Cmd Rej: Invalid Domain name

Commands Used: `chg-ip-card`

You entered a domain name that does not conform to the naming convention for this parameter. The naming conventions for the **domain** parameter specify that it must be comprised of (**a-z**, **A-Z**, **0-9**, **-**, **.**), and up to 120 characters in length.

Recovery

Re-enter the **chg-ip-card** command specifying a name for the **domain** parameter that conforms to the specified naming conventions.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3746 Cmd Rej: No other optional parms can be entered with SRCSET

Commands Used: `chg-dcmps`

You entered this command specifying the **srcset** parameter and at least one other optional parameter. If the **srcset** parameter is specified, no additional optional parameters can be specified.

Recovery

Re-enter the `chg-dcmps` command specifying **srcset** as the only optional parameter.

E3747 Cmd Rej: Too many IP connections per card

Commands Used: `chg-assoc`

A maximum of 50 connections (association-to-AS assignments) can be specified per local host on IPGWx cards.

Recovery

- Refer to the *Commands Manual* for the maximum number of connections allowed per card.
- Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E3749 Cmd Rej: If IPADDR is specified SUBMASK is required

Commands Used: `chg-ip-lnk`

When entering the `chg-ip-lnk` command, you specified a value for the **ipaddr** parameter but did not specify a value for the **submask** parameter. If the **ipaddr** parameter is specified, the **submask** parameter is required.

Recovery

Re-enter the `chg-ip-lnk` command specifying a valid value for the **submask** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3751 Cmd Rej: Max sockets per routing key exceeded

Commands Used: `ent-appl-rtkey`

The routing key you entered is already associated with the maximum number of socket names allowed (16). To add the new routing key, first delete a current routing key association, then add the new one.

Recovery

1. Display the routing key assignments for the entered destination point code.
Enter the `rtrv-appl-rtkey:dpc=< destination point code >` command.
2. Delete an existing association.
Enter the `dlt-appl-rtkey` command specifying the **dpc**, **si**, **ssn**, and **sname** parameters for the association you want to delete.
3. Re-enter the `ent-appl-rtkey` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3753 Cmd Rej: Command is not supported for SLK IPLIML2 type

Commands Used: `act-lpo`, `blk-slk`, `tst-slk`, `ublk-slk`

This command can be entered for IPLIMx or IPSP signaling links only when they have an `ipliml2` parameter setting of `m2pa`.

Recovery

1. Verify that this is an IPLIMx or IPSP signaling link and the `ipliml2` parameter setting is `m2pa`.
Refer to the *Database Administration Manual - SS7* for assistance.
2. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3754 Cmd Rej: Command is not supported for IPGW(x) links

Commands Used: `canc-lpo`, `inh-slk`, `unhb-slk`, `alw-slk`

The command you entered is not valid on TCP/IP point-to-multipoint links (SSEDCM cards or E5NET cards equipped with SS7IPGW, IPSP or IPGWI links).

Recovery

1. Verify that the card at the specified location is a DCM card running the SS7IPGW or IPGWI application.
Enter the `rtrv-card` command. This information is shown in the *TYPE* and *APPL* fields of the output.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3757 Cmd Rej: SSN is not allowed unless SI is 3

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `dlt-rmt-appl`, `ent-appl-rtkey`, `ent-rmt-appl`, `rtrv-appl-rtkey`

You specified the **ssn** parameter, but the **si** parameter value is not 3. If the **ssn** parameter is specified, the **si** parameter value must be 3 **si=3** (or the string equivalent **si=sccp**).

Recovery

1. Determine the service indicator value as shown in the SI column of the output.
Enter the `rtrv-appl-rtkey` or `rtrv-rmt-appl` command.
2. Re-enter the command specifying the **ssn** parameter and **si=3**.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3758 Cmd Rej: If Domain name is specified, RSTDMAIN is not valid

Commands Used: `chg-ip-card`

You cannot specify the **rstdomain** parameter if the **domain** parameter is specified.

Recovery

Re-enter the `chg-ip-card` command specifying the **domain** parameter but not the **rstdomain** parameter.

E3760 Cmd Rej: IP address must be unique

Commands Used: `chg-ip-card`, `chg-ip-lnk`, `ent-ip-host`

The IP address specified by the **bpipaddr**, **bpsubmask**, or **ipaddr** parameter must be unique.

Recovery

1. Display the host names and IP addresses currently in the table of interest. Enter the **rtrv-** version of the associated command (`rtrv-ip-card`, `rtrv-ip-lnk`, or `rtrv-ip-host`).
2. Re-enter the command that generated this error message specifying the host name and an IP address that does not match any of the entries in the table.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3761 Cmd Rej: At least one of TIMER, PARM, SRCSET must be entered

Commands Used: `chg-dcmps`

The `chg-dcmps` command requires at least one of the following optional parameters to be specified: **parm**, **srcset** or **timer**.

Recovery

Re-enter the `chg-dcmps` command specifying at least one of the required optional parameters: **parm**, **srcset** or **timer**.

E3762 Cmd Rej: Host table must contain IP Link addresses

Commands Used: `chg-ip-lnk`, `dlt-ip-host`

You tried to enter an IP address (**ipaddr**) into the IP Link table, but the address is not in the IP Host table. An IP address must be in the IP Host table before it can be added to the IP Link table.

OR

You tried to delete an IP host name (**host**) from the IP Host table, and the host name has an IP address in the IP Link table. You must first delete the IP address from the IP Link table before you can delete the IP host name.

Recovery - `chg-ip-lnk`

1. Display the IP Host table. Enter the `rtrv-ip-host` command specifying no parameters. Verify that the address you entered is not in the table. This information is shown in the *IPADDR* field of the output.
2. If the IP address you entered is in the IP Host table, re-enter the `chg-ip-lnk` command.
3. If the IP address you entered is not in the IP Host table, enter the IP address. Enter the `ent-ip-host` command.
4. Re-enter the `chg-ip-lnk` command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - `dlt-ip-host`

1. Display the host names and IP addresses currently in the IP Host table.
Enter the `rtrv-ip-host` command specifying no parameters.
2. Display the IP addresses currently in the IP Link table.
Enter the `rtrv-ip-lnk` command specifying no parameters. Verify that the IP address for the host to be deleted is still in the IP Link table.
3. Delete the IP address from the IP Link table.
Enter the `chg-ip-lnk` command specifying the parameter `ipaddr=0.0.0.0` and the **loc** and **port** parameters that correspond to the host's IP address.

4. Delete the host name from the IP Host table.
Re-enter the `dlt-ip-host` command.

E3763 Cmd Rej: Routing Key table full

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`

The Routing Key table is full (1000 entries per system). You must delete an existing routing key before adding another one to the table.

Recovery

1. Display the entries in the Routing Key table.
Enter the `rtrv-appl-rtkey` command.
2. Enter the `dlt-appl-rtkey` command specifying the **dpc**, **si**, **ssn**, and **sname** parameters for the entry you want to delete.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3764 Cmd Rej: Routing key not found

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`

The specified entry was not found in the Routing Key table.

Recovery

1. Display the Routing Key table.
Enter the `rtrv-appl-rtkey` command.
2. If the routing key you specified is shown in the output from Step 1, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3765 Cmd Rej: Fully specified connection required to change OPEN

Commands Used: `chg-assoc`

Values for all parameters required to fully specify the connection must be specified before the **open** parameter can have a value of **yes**. Refer to the Commands Manual for additional information.

Recovery

1. Enter the command specifying the connection fully specified and without the **open** parameter.

2. Re-enter the command specifying the connection fully and with the **open=yes** parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3767 Cmd Rej: Socket Name not defined

Commands Used: `inh-alm`

You entered a socket name (**sname**) that is not in the database. If the **sname** parameter is specified, the socket name must exist in the IPAPSOCK table.

Recovery

1. View the list of defined sockets.
Enter the `rtrv-appl-sock` command specifying no parameters.
2. If the socket name you entered appears in the *SNAME* field of the output, re-enter the appropriate command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the socket does not appear in the output of Step 1, you can define the socket.

E3768 Cmd Rej: Link B not supported for device

Commands Used: `ent-slk`, `rept-stat-slk`

If the card application is `ss7ipgw` or `ipgwi`, only the **link=a** parameter can be specified.

Recovery

Re-enter the command that generated this error message specifying the **port/link=a** parameter.

E3770 Cmd Rej: SS7 parameters cannot be specified for IP7 link

Commands Used: `ent-slk`

If an IP7 link is assigned to a card (application **iplim**, **iplimi**, **ipgwi**, or **ss7ipgw**), the following SS7 parameters cannot be specified: **atmtsel**, **e1atmcr4**, **e1atmsi**, **e1atmsn**, **ecm**, **lpset**, **l2tset**, **ll**, **pcrn1**, **pcrn2**, **vci** and **vpi**.

Note:

When a link is added to a linkset, the link remains in the state OOS-MT-DSBLD (out of service maintenance disabled) until it is activated.

Recovery

Re-enter the command specifying valid IP7 link parameters. Refer to the *Commands Manual* and to the *Database Administration Manual - IP7 Secure Gateway* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3772 Cmd Rej: Only one SS7IPGW or IPGWI link allowed in mated linkset

Commands Used: `ent-slk`

The mated IPGWx linkset specified already has an assigned signaling link. A mated linkset can have only one signaling link. If the specified linkset has a mate linkset, only 1 SS7IPGW or IPGWI signaling link can be assigned to the specified linkset. The assigned link must be an SS7IPGW or IPGWI link.

Recovery

1. Verify that the card in the specified location is running an IPGWx application.

Enter the `rtrv-card` command.

2. Verify that the correct linkset was specified.

If the correct linkset was specified, perform either of the following:

- a) Delete the pre-existing signaling link from the linkset.

Enter the `dlt-slk` command.

- b) Add the new signaling link.

Enter the `ent-slk` command.

Note:

When a link is added to a linkset, the link remains in the state OOS-MT-DSBLD (out of service maintenance disabled) until it is activated.

OR

- a) Delete the **matelsn** from the linkset.

Enter the `chg-ls:action=delete` command.

- b) Add the new signaling link to the linkset.

Enter the `chg-ls:action=add` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3774 Cmd Rej: Failed reading the UIM Threshold Table

Commands Used: `set-uim-acthresh`

The UIM Threshold table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.

2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3775 Cmd Rej: SERIAL param valid only with APPL param

Commands Used: `init-card`

The **serial** parameter can be used only with the **appl** parameter.

Recovery

Re-enter the `init-card` command specifying both the **appl** and **serial** parameters.

E3776 Cmd Rej: Invalid APPL selection for SERIAL init card command

Commands Used: `init-card`

A valid value must be specified for the **appl** parameter. Refer to the command description in the *Commands Manual* for valid values for the **appl** parameter.

Recovery

Re-enter the `init-card` command, specifying a valid value for the **appl** parameter.

E3777 Cmd Rej: APPL=ALL can only be selected when SERIAL=YES is specified

Commands Used: `init-card`

If you enter the `init-card:appl=all` command, you must specify the **serial=yes** parameter.

Recovery

Re-enter the `init-card:appl=all:serial=yes` command.

E3778 Cmd Rej: Active/Stby GPL versions are not compatible

Commands Used: `copy-disk`, `format-disk`

The OAM GPL version that is running on the active OAM card location differs from the OAM GPL version that is running on the standby OAM card. If the two version numbers are not identical, the command aborts. Note that it is the running GPL versions that must be identical, not the approved or trial GPLs (as shown in the output of the `rept-stat-gpl` command).

You may have encountered this error during an upgrade, when one OAM card may be booted from a removable cartridge and the other from the fixed disk. This action could cause different GPLs to be running on the active and standby OAM cards.

Recovery

Use the following commands, or command combinations, to boot both OAM cards with the same GPL version from the removable cartridge:

- Determine the GPL versions. Enter the `rtrv-gpl` command.
- If the GPL version on the standby OAM card differs from the GPL version on the active OAM card, insert a removable cartridge with the correct GPL version.
- Boot the standby OAM card. Enter the command: `init-card:loc= <xxxx>`
where `xxxx` is the location of the standby OAM card.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3779 Cmd Rej: FORCE=YES must be specified

Commands Used: `chg-db`, `inh-card`

For the `chg-db` command, if the **action=canceled** parameter is specified, then the **force=yes** parameter must be specified.

For the `inh-card` command, if the only in-service EMDCA-DCM or EPAP/ELAP-DSM card is specified or if inhibiting the VSCCP card would cause less than 80% of the in-service normal (IS-NR) LIM cards to have VSCCP service (i.e., cause the system to enter an unstable loading mode), then the **force=yes** parameter must be specified.

Recovery

Re-enter the command specifying the **force=yes** parameter.

E3780 Cmd Rej: Syntax Error Found

Commands Used: Pass-through commands

The command you entered does not conform to the required syntax.

Recovery

Re-enter the command as the rules require.

Refer to the *Commands Manual* for the syntax rules for the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3781 Cmd Rej: MTP restart option invalid for IPGWx and IPSG-M3UA linksets

Commands Used: `chg-ls`, `ent-ls`

If the `ipgwapc=yes` or `ipsg=yes` parameter is specified, then the `mtpmse=yes` parameter cannot be specified.

Recovery

1. Display attributes of the linkset.
Enter the `rtrv-ls` command, specifying the `lsn` parameter. Verify that `mtpmse=no` displays in the output.
2. Re-enter the command and either
 - a) do not specify the `mtpmse` parameter
 - OR
 - b) specify the `mtpmse=no` parameter

E3782 Cmd Rej: Command Not Found

Commands Used: Pass-through commands

The pass-through command you entered was not found.

Recovery

Re-enter the command specifying the correct information.

Refer to the *Commands Manual* for information about the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3783 Cmd Rej: CICS must be less than or equal to CICE

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified a value for the starting circuit identification code (`cics`) that was greater than the value specified for the ending circuit identification code (`cice`). The value entered for the starting circuit identification code must be less than or equal to the value entered for the ending circuit identification code.

Recovery

Re-enter the command specifying a value for the `cics` parameter that is less than or equal to the value for the `cice` parameter.

E3785 Cmd Rej: IPISUP Feature must be on

Commands Used: `ent-appl-rtkey`

You entered this command for a DPC/SI/CIC routing key to route ISUP messages, but the ISUP routing over IP feature is turned off.

Recovery

1. Turn on the ISUP routing over IP feature. Enter the `chg-feat:ipisup=on` command.
2. Re-enter the `ent-appl-rtkey` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3786 Cmd Rej: CIC Range overlaps an existing routing key

Commands Used: `dlt-appl-rtkey`, `ent-appl-rtkey`

You entered a circuit identification code range (**cics** to **cice**) that overlaps an existing routing key.

Recovery

1. Display the conflicting circuit identification code range for the existing routing key.
Enter the `rtrv-appl-rtkey` command specifying the CIC range. This information is shown in the *CICS* and *CICE* fields of the output.
2. Re-enter the command specifying a circuit identification code range (**cics** to **cice**) that does not overlap the range of an existing routing key.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3787 Cmd Rej: SSN not allowed with OPC, CICS, and CICE

Commands Used: `rtrv-appl-rtkey`

You specified the **ssn** parameter along with the **opc**, **cics**, and **cice** parameters. The **opc**, **cics**, and **cice** parameters are used to route ISUP messages and require that **si=5** (or the string equivalent **si=isup**). The **ssn** parameter is not allowed unless **si=3** (or the string equivalent **si=sccp**).

Recovery

Re-enter the `rtrv-appl-rtkey` command without specifying a value for the **ssn** parameter.

E3788 Cmd Rej: OPC, CICS, CICE are required if SI is 4, 5, or 13

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`

You entered the command without specifying the **opc**, **cics**, and **cice** parameters specified. The **opc**, **cics**, and **cice** parameters are used to route ISUP messages and must be specified if **si=4, 5, or 13** (or the string equivalent **si=tup, isup** or **qbicc**) is specified and the routing key **type=full** is specified or defaulted.

Recovery

Re-enter the command specifying values for the **opc**, **cics**, and **cice** parameters for **si=4, 5, or 13** and routing key **type=full**.

E3789 Cmd Rej: OPC, CICS, CICE are not allowed with SI unless SI is 4, 5, or 13

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified the **opc**, **cics**, and **cice** parameters specified, but the **si** parameter value is not **4, 5, or 13**. The **opc**, **cics**, and **cice** parameters are used to route ISUP messages and can be specified only if **si=4, 5, or 13** (or the string equivalent **si=tup, isup** or **qbicc**) is specified.

Recovery

1. Enter the `rtrv-appl-rtkey` command to determine the service indicator value, as shown in the **SI** column of the output.
2. If **si** is **4, 5, or 13** (or **TUP, ISUP, or QBICC**) from the output of step 1, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3791 Cmd Rej: Gtwy IP Address is invalid

Commands Used: `ent-ip-rte`, `rtrv-ip-rte`

You specified an invalid gateway IP address in the **gtwy** parameter of the command. The gateway IP address:

- Must be four numbers separated by dots, with each number in the range of **0–255**
- Must not be the default route (**0.0.0.0**)
- Must not correspond to any loopback address (i.e. **127.X.X.X**)
- Must be unique per card
- Must not correspond to an IP address that is local to this card's A or B network

Recovery

Re-enter the command specifying a valid gateway IP address.

E3792 Cmd Rej: Gtwy IP Address must be local to this cards A, B network

Commands Used: `ent-ip-rte`

For the card in the location specified in the `loc` parameter, you specified a gateway IP address in the `gtwy` parameter of the command that is not local to the A or B network of the card. The gateway IP address must correspond to an IP address that is local to this card's A or B network.

Recovery

Re-enter the `ent-ip-rte` command specifying a gateway IP address that is local to the A or B network for the specified card.

E3793 Cmd Rej: Max IP Route entries already exist for this card

Commands Used: `ent-ip-rte`

You entered a command to define a static IP route for the card in the location specified in the `loc` parameter. The maximum number of **64** static IP routes for this card already exist in the Static IP Route table.

Recovery

1. Display the existing route entries for the card.
Enter the `rtrv-ip-rte` command.
2. To add a route entry for the card, delete an existing route entry.
Enter the `dlt-ip-rte` command.
3. Re-enter the `ent-ip-rte` command to add the new route entry for the card.

E3794 Cmd Rej: IP Route table full

Commands Used: `ent-ip-rte`

You entered a command to define a static IP route for the card in the location specified in the `loc` parameter. The maximum number of **1024** static IP routes already exist in the Static IP Route table.

Recovery

1. Display the existing route entries for the card.
Enter the `rtrv-ip-rte` command.
2. To add another route entry for the card, delete an existing route entry from the table.
Enter the `dlt-ip-rte` command.
3. Re-enter the `ent-ip-rte` command to add the new route entry for the card.

E3795 Cmd Rej: LNP ported NPANXXs 300K Qty Feat Requires at least DSM2GB

Commands Used: `enable-ctrl-feat`

You attempted to enable the LNP ported NPANXX 300K Quantity Keys, but not all DSMs have the required memory, at least a 2 GB DSM card. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Refer to the procedures in the *LNP Feature Activation* Guide to enable the LNP 300,000 NPANXX quantity feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3796 Cmd Rej: LNP ported LRNs 150K Qty Feat Requires at least DSM2GB

Commands Used: `enable-ctrl-feat`

You attempted to enable the LNP ported LRNs 150K Quantity Keys feature, but not all DSMs have the required memory, at least a 2 GB DSM card. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Refer to the procedures in the *LNP Feature Activation* Guide to enable the LNP 150,000 LRNs quantity feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3798 Cmd Rej: Measurement Preparation in progress, Retry later

Commands Used: `chg-db`

Since there is measurement preparation in progress, the upload to the OAM (`finished1`) cannot be started.

Recovery

Wait for the measurement preparation operation to finish, and then re-enter the command.

E3799 Cmd Rej: FORCE=YES must be specified

Commands Used: `act-lbp`, `chg-clkopts`, `chg-db`, `chg-rtx`, `chg-stpopts`, `chg-e1`, `chg-t1`, `ent-e1`, `ent-rtx`, `ent-t1`, `inh-card`, `rept-stat-rtd`, `st-slk`, `tst-slk`

If the `ilsn` and `lsn` parameter have the same value, or if the value specified for the `opc` parameter is the same as the APC of the linkset specified by the `lsn` parameter, then the `force=yes` parameter must be specified.

The `force=yes` parameter must be specified to start a test when 256 or more tests are already running in the system.

If the `hscsrc` and `clock=all` parameters are specified, and the high speed clocks are reporting, then the `force=yes` parameter must be specified.

The `chg-stpopts:hscsrc=xxx` command cannot be entered when the high speed clocks are reporting valid status unless the `force=yes` parameter is specified.

For the `act-lbp` or `tst-slk` commands, the `force=yes` parameter must be specified to activate more than 256 link tests.

For the `e1/t1` commands, if the `chanbrdg=on` parameter is specified for an odd-numbered E1 port on an HC-MIM or an E5-E1T1 card, then the `force=yes` parameter must be specified if the adjacent even-numbered port is already provisioned with an E1 interface.

For the `rept-stat-rtd` command, when the RTD alarm is active and the `reset=yes` parameter is specified, the `force=yes` parameter must be specified to clear the cards statistics and checksum failure indicators.

Recovery

Re-enter the command specifying `force=yes`.

Recovery - `rept-stat-rtd`

For the `rept-stat-rtd` command,

1. to clear/reset MSU validation/Run-Time Diagnostic (RTD) statistics for one card (LIM or SCCP) in the system, specify the `reset=yes` parameter.

Example: `rept-stat-rtd:loc=1107:reset=yes`

2. to clear/reset MSU validation/RTD statistics for all (LIM and SCCP) cards in the system, specify both the `reset=yes` and `force=yes` parameters.

Example: `rept-stat-rtd:reset=yes:force=yes`

E3800 Cmd Rej: BLM/DCM card must be provisioned and IS-NR for bulk download

Commands Used: `chg-db`

You specified the `chg-db:action=begined1` command, but the Bulk Load Module (BLM) and DCM cards do not meet the requirements for a bulk download. The BLM and DCM cards must be provisioned, and their primary state (PST) must be in-service normal (IS-NR).

Recovery

1. Refer to the *LNP Database Synchronization Manual* for instructions on provisioning cards.
2. Display the status of the BLM and DCM cards.
Enter the `rept-stat-card` command.
 - a) If the primary state of one of the BLM or DCM cards displayed in Step 2 is in service, the entry IS-NR appears in the *PST* field of the output.
Re-enter the `chg-db` command that generated this error message.
 - b) If the primary state of one of the BLM or DCM cards displayed in Step 2 is out-of-service maintenance disabled (OOS-MT-DSBLD), change the primary state of the card to IS-NR.
Enter the `alw-card` command. Re-enter the `chg-db` command that generated this error message.
 - c) If the primary state of one of the cards displayed in Step 2 is out of service - maintenance (OOS-MT) or in service - abnormal (IS-ANR), refer to Appendix A of the *Maintenance Manual* for the appropriate card removal and replacement procedures to place the card in service.
3. Re-enter the `chg-db` command that generated this error message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3801 Cmd Rej: BLM/DCM LNP database must be coherent to do a bulk download

Commands Used: `chg-db`

You specified the `chg-db:action=begined1` command. This execute command, the LNP database on the BLM or DCM card must be both coherent, and at the same level as the current LNP database on the active OAM card.

Recovery

1. Determine the status of the database.
Enter the `rept-stat-db:display=all` command.
2. If the BLM or DCM database is not coherent, enter the following command:
`init-card:loc=xxxx` where `xxxx` is the location of the BLM or DCM card.
3. Re-enter the `chg-db:action=begined1` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3802 Cmd Rej: BLM must be provisioned and IS-NR for an upload

Commands Used: chg-db

You specified the `chg-db:action=finished1` command. This action requires that the BLM card be provisioned and its primary state (PST) must be IS-NR.

Recovery

1. Refer to the *LNP Database Synchronization Manual* for instructions on provisioning cards.
2. To display the status of the cards, enter the `rept-stat-card` command.
If the card is in service, the entry IS-NR appears in the *PST* field of the output.
3. Re-enter the `chg-db` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3803 Cmd Rej: Bulk download from LSMS to the BLM card must have completed

Commands Used: chg-db

You specified the `chg-db:action=finished1` command before the download from the LSMS to the BLM card completed.

Recovery

1. Wait until the following message appears:

```
5061.1497  SYSTEM      INFO  LSMS Bulk Download complete
```

2. Re-enter the `chg-db:action=finished1` command.

E3804 Cmd Rej: Database in the BLM card must be coherent for an upload

Commands Used: chg-db

You specified the `chg-db:action=finished1` command. However, the LNP database currently resident in the BLM card is not coherent.

Recovery

1. Determine the status of the database.
Enter the `rept-stat-db:display=all` command.
2. If the BLM database is not coherent, enter the following command:
`init-card:loc=xxxx` where *xxxx* is the location of the BLM card.

3. From the LSMS, restart the bulk download, and then re-enter the `chg-db` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3805 Cmd Rej: Enhanced Bulk Download not in progress

Commands Used: `chg-db`

You specified either the `chg-db:action=finished1` or the `chg-db:action=canceled1` command. Before either of these commands can execute, you must first issue the `chg-db:action=begin1` command.

Recovery

1. Enter the `chg-db:action=begin1` command.
2. Wait until the following message appears:

```
5061.1497  SYSTEM      INFO  LSMS Bulk Download complete
```

E3806 Cmd Rej: Enhanced Bulk Download already in progress

Commands Used: `chg-db`

You specified the `chg-db:action=begin1` command, while a previously issued `chg-db:action=begin1` command is in effect.

Recovery

Perform one of the following actions:

- Wait for the download to complete. At completion, the following message appears:

```
1497 LSMS Bulk Download complete
```

OR

- Wait for LSMS to cancel the download, in which case the following message appears:

```
5061.1498  SYSTEM      INFO  LSMS Bulk Download cancelled at LSMS
```

OR

- Cancel the download. Enter the `chg-db:action=canceled1` command.

E3807 Cmd Rej: Failed reading Secondary Point Code (SPC) table

Commands Used: `chg-sid`, `dlt-spc`, `ent-spc`, `rtrv-spc`, `chg-ls`, `dlt-rtx`

The Secondary Point Code table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3808 Cmd Rej: SPC and NSPC may not be equal

Commands Used: `chg-sid`

When you specify the `spc` and `nspc` parameters, their values must be different.

Recovery

Re-enter the `chg-sid` command and make sure that the values for the `spc` and `nspc` parameters are different.

E3809 Cmd Rej: SPC may not exist in the STP's route table

Commands Used: `ent-spc`

You specified a secondary point code that exists as a destination or an alias in the STP database's Destination table. The system does not allow this action.

Recovery

1. Display the DPCs in the Destination table.
Enter the `rtrv-dstn` command.
2. Re-enter the `ent-spc` command that generated the error message specifying an SPC that does not exist as a destination or an alias in the Destination table, as shown in the output from Step 1.

E3810 Cmd Rej: SPC may not exist as a TPC or CPC in the SID table

Commands Used: `chg-sid`, `ent-spc`

The true point code and capability point codes cannot be the same as existing secondary point codes.

Recovery

1. Display the point codes currently configured in the system database.
Enter the `rtrv-spc` command.
2. Enter the `rtrv-sid` command to display the point codes currently in the SID table.
The EAGLE 5 ISS's true point code is shown in the `PCA` field. Capability point codes are shown in the `CPCA`, `CPCI`, `CPCN`, and `CPCN24` fields.

3. Re-enter the command that generated the error message, but use an SPC that is not referenced in the SID table, as shown in the output from Step 1.

E3811 Cmd Rej: SPC may not exist as a TPC, CPC, or DPC in the route table

Commands Used: `chg-sid`, `ent-spc`

The value of the **spc** parameter cannot already exist in the Destination table as a destination point code, true point code, or concerned point code. You specified a true point code (TPC) that matches an existing/new secondary point code (SPC). The system does not allow this action.

Recovery

1. Display the system's true point code with the `rtrv-sid` command.
The system's true point code is shown in the *PCA* field.
2. Re-enter the `chg-sid` command that generated this error message specifying a value for the **pc/pca** parameter that does not exist as an SPC, as shown in the output from Step 1.

E3812 Cmd Rej: The SPC already exists

Commands Used: `ent-spc`

The specified Secondary Point Code (SPC) entry already exists in the Secondary Point Code table.

Recovery

1. Display the SPCs currently configured in the Secondary Point Code table.
Enter the `rtrv-spc` command.
2. Re-enter the `ent-spc` command that generated the error message specifying a value for the **spc** parameter that does not exist in the Secondary Point Code table.

E3814 Cmd Rej: SPC does not exist

Commands Used: `ent-dstn`, `chg-dstn`, `chg-ls`, `dlt-spc`

You specified the **spc** parameter, but the **spc** is not defined as a Secondary Point Code (SPC) in the database. The exception to this rule is if you specify **spc=none**.

If the point code specified by the **spc** parameter is valid and the linkset type specified by the **lst** parameter is not **prx**, then the **spc** point code must exist in the **spc** table.

Recovery

1. Display the SPCs currently configured. Enter the `rtrv-spc` command.
2. Re-enter the command that generated the error message specifying an SPC that is defined in the database, as shown in the output from Step 1.

E3815 Cmd Rej: The maximum number of SPCs has already been defined

Commands Used: `ent-spc`

The maximum number of Secondary Point Codes (SPCs) you can enter into the database is 40. When you entered the command, you specified a SPC that would have been the 41st entry in the database. You must first delete an existing SPC entry from the database before you can add a new one.

Recovery

1. Display the SPCs currently configured in the system database.
Enter the `rtrv-spc` command.
2. Delete one of the existing SPCs.
Enter the `dlt-spc=xxx-xxx-xxx` command, where `xxx-xxx-xxx` is a point code you select from the output of Step 1.
3. Re-enter the `ent-spc` command.

E3819 Cmd Rej: SPC may not be referenced in the STP's route table

Commands Used: `dlt-spc`

A secondary point code that is referenced in the Destination table cannot be deleted.

Recovery

1. Display the DPCs in the database.
Enter the `rtrv-dstn` command.
2. Re-enter the `dlt-spc` command specifying an SPC that is not referenced in the destination point code table, as shown in the output from Step 1.

E3820 Cmd Rej: Site SPC must be a full point code

Commands Used: `ent-spc`

Specify the `spc` parameter as a full point code. A full point code contains numerical values for all three segments of the point code. The exception to this rule is when you specify a value of **none**.

Recovery

Re-enter the `ent-spc` command specifying a full point code.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3821 Cmd Rej: SPC & DPC must be the same network type

Commands Used: `chg-dstn`, `ent-dstn`, `chg-ls`

You specified the **spc** parameter, but its network type (ANSI, ITU-N, or ITU-I) does not match the network type for the destination point code (DPC). For instance, if you specify the **spci** parameter, you must specify the **dpci** parameter so that both network types are ITU-I. Likewise, **dpci** must be specified with **spca** (ANSI), **dpcn** with **spcn** (ITU-N), and **dpcn24** with **spcn24** (24-bit ITU-N). As long as **spc=none** is not specified, the secondary point code (SPC) must be the same network type as the Adjacent Destination Point Code (APC).

Recovery

Re-enter the command specifying **spc** and **dpc** parameters that are the same network type.

E3822 Cmd Rej: SPC must be a full point code

Commands Used: `chg-dstn`, `ent-dstn`, `rtrv-dstn`, `chg-ls`, `ent-rtx`, `rtrv-ls`

The value of the **spc** parameter must be a full point code or **none**. A full point code contains numerical values for all three segments of the point code.

Recovery

1. Display the secondary point codes in the database. Enter the `rtrv-spc` command.
2. Re-enter the command specifying a full point code, as shown in the output of Step 1.

E3823 Cmd Rej: Domain must be SS7 if SPC is specified

Commands Used: `chg-dstn`, `ent-dstn`

If you specify the **spc** parameter, you must specify **domain=ss7**.

Recovery

Re-enter the command that generated this error message specifying **domain=ss7**.

E3825 Cmd Rej: New CIC range overlaps an existing routing key

Commands Used: `chg-appl-rtkey`

You entered a new circuit identification code range (**ncics-to-ncice**) that overlaps an existing routing key.

Recovery

1. Enter the `rtrv-appl-rtkey` command specifying the new CIC range to see the conflicting circuit identification code range for the existing routing key.
This information is shown in the *CICS* and *CICE* fields of the output.
2. Re-enter the `chg-appl-rtkey` command specifying a new circuit identification code range (**ncics-to-ncice**) that does not overlap the range of an existing routing key.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3826 Cmd Rej: NCICS must be less than or equal to NCICE

Commands Used: `chg-appl-rtkey`

You specified a value for the new starting circuit identification code (**ncics**) that is greater than the value specified for the new ending circuit identification code (**ncice**). The value entered for the starting circuit identification code must be less than or equal to the value entered for the ending circuit identification code.

Recovery

Re-enter the `chg-appl-rtkey` command specifying a value for the **ncics** parameter that is less than or equal to the value for the **ncice** parameter.

E3827 Cmd Rej: No change requested

Commands Used: `chg-appl-rtkey`, `chg-ctrl-feat`, `chg-gttset`, `chg-vflx-cd`, `chg-vflx-rn`, `chg-vflx-vmsid`, `enable-ctrl-feat`

At least one parameter value must be different from the values provisioned for the table entry.

Recovery

1. If this error message appeared after the `chg-appl-rtkey`, `chg-ctrl-feat`, `chg-gttset`, or `enable-ctrl-feat` command was used, skip ahead to the next step. Otherwise, re-enter the command with at least one optional parameter which changes a value provisioned for the table entry.
2. If there is no routing key or controlled feature in the output identical to the entered parameters, then re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If there is a routing key or controlled feature in the output identical to the entered parameters, then re-enter the command specifying different parameters.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3828 Cmd Rej: Card GPL type SS7IPGW requires IPGWAPC=YES

Commands Used: `ent-slk`

When specifying an IP link (**type=ss7ipgw**) with the `ent-slk` command, the **lsn** parameter must reference a linkset that specifies an IP gateway adjacent point code (`ent-ls:ipgwapc=yes`).

Recovery

1. Determine if the **type=ss7ipgw** and **ipgwapc=yes**.
Enter the `rtrv-ls` command specifying the linkset name (**lsn**).
2. If the criteria identified in Step 1 is met, re-enter the `ent-slk` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If **type=ss7ipgw** but **ipgwapc=no**, enter the `ent-ls` command specifying **ipgwapc=yes**.
4. Re-enter the `ent-slk` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3829 Cmd Rej: Link set with IPGWAPC=YES requires SS7IPGW/IPGWI GPL

Commands Used: `ent-slk`

When the specified linkset name (**lsn**) is defined with the **ipgwapc=yes** parameter, the card application must be **ss7ipgw** or **ipgwi**.

Recovery

1. Determine if the **type=ss7ipgw** or **type=ipgwi** and **ipgwapc=yes**.
Enter the `rtrv-ls` command specifying the linkset name (**lsn**).
2. If the criteria identified in Step 1 are met, re-enter the `ent-slk` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3830 Cmd Rej: DPC must not specify a cluster route for IPGWAPC linkset

Commands Used: `chg-rte`, `ent-rte`

If the ITU Duplicate Point Code feature is on, the group code must match for all linksets that are not IPGWx linksets. If the specified destination address is a full point code address (**ni-nc-ncm**) and is a member of a specified cluster (**ni-nc-***), attributes of the ordered routes assigned to it cannot be changed.

Recovery

1. Verify that the link set name (**lsn**) references a destination point code that is a cluster route.
Enter the `rtrv-rte` command for the link set. Cluster routes use a wild card (*) as part of the address.
2. If the referenced destination point code is not a cluster route, re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3831 Cmd Rej: Invalid parameter combination for SI

Commands Used: `chg-appl-rtkey`

A valid combination of parameters must be entered the specified service indicator (**si**) value.

Use only one of the following parameter combinations to specify new values for the routing key:

1. Specify **ncics**, **ncice**, or **ncics** and **ncice** to re-size the CIC range for the routing key
2. Specify **nsname** to override the socket associations for the routing key
3. Specify **split** to split the routing key into 2 entries with adjacent CIC ranges

Table 26: Valid Parameter Combinations for Routing Key Types describes supported parameter combinations for specific actions and service indicator values.

Table 26: Valid Parameter Combinations for Routing Key Types

Action	dpc*	si*	ssn	opc	cics	cice	ncics	ncice	split	type
Split CIC Range	X	X		X	X	X			X	full
Re-size CIC Range	X	X		X	X	X	X	X		full
Socket Name Override (SI=ISUP or 5)	X	X		X	X	X				full
Socket Name Override	X	X	X							full

Action	dpc*	si*	ssn	opc	cics	cice	ncics	ncice	split	type
(SI = SCCP or 3)										
Socket Name Override (SI ≠ 3, 4, 5, or 13)	X	X								full
Socket Name Override (SI = 4, 5, or 13)	X	X								partial
Socket Name Override (SI = 3, 4, 5 or 13)	X	X								partial
Socket Name Override SI-only key		X								partial
Socket Name Override DPC-only key	X									partial
Socket Name Override Default key										default
* Indicates mandatory parameter										

Recovery

Re-enter the `chg-appl-rtkey` command specifying valid parameters for the specified service indicator value.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3832 Cmd Rej: SPLIT must be greater than CICS

Commands Used: `chg-appl-rtkey`

The value specified for the circuit identification code split range (**split**) must be greater than the value entered for the starting circuit identification code (**cics**).

Recovery

Re-enter the **chg-appl-rtkey** command specifying a value for **split** that is greater than the value specified for **cics**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3833 Cmd Rej: SPLIT must be less than or equal to CICE

Commands Used: `chg-appl-rtkey`

The value entered for the circuit identification code split range (**split**) must be less than or equal to the value entered for the ending circuit identification code (**cice**).

Recovery

Re-enter the command specifying a value for **split** that is less than or equal to the value specified for **cice**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3834 Cmd Rej: NCICE unspecified, NCICS must be less than or equal to CICE

Commands Used: `chg-appl-rtkey`

The value entered for the new starting circuit identification code (**ncics**) must be less than or equal to the value entered for the ending circuit identification code (**cice**) when the new ending circuit identification code (**ncice**) is not specified.

Recovery

Re-enter the command specifying a value for **ncics** that is less than or equal to the value specified for **cice**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3835 Cmd Rej: L2STATS not valid for SS7IPGW

Commands Used: `rept-stat-slk`

On TCP/IP point-to-multipoint links (SSEDCM or E5-ENET cards equipped as SS7IPGW or IPGWI links), l2stats output is not available.

Recovery

1. Enter the `rtrv-card` command to verify that the card at the specified location is a DCM card running the SS7IPGW application.
This information is shown in the *TYPE* and *APPL* fields of the output.
2. If the card type is other than DCM or the application type is other than SS7IPGW, re-enter the `rept-stat-slk` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3836 Cmd Rej: Command not valid for IPLIM

Commands Used: `blk-slk`, `ublk-slk`

The command you entered is not valid on TCP/IP point-to-point links (DCM cards equipped as IPLIM links).

Recovery

1. Verify that the card at the specified location is a DCM card running the IPLIM application.
Enter the `rtrv-card` command. This information is shown in the *TYPE* and *APPL* fields of the output.
2. If the card type specified is not a DCM card, or the application type specified is not IPLIM, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3837 Cmd Rej: Command not valid for SS7IPGW

Commands Used: `alw-slk`, `blk-slk`, `ent-rte`, `inh-slk`, `rept-stat-tstslk`, `tst-slk`, `unhb-slk`

All routes with ANSI DPC's must use ANSI linkset APC's. A route with an ITU-I DPC can go over an ITU-N APC and an ITU-I DPC can go over an ITU-N APC. This command is not supported for cards

running the **ss7ipgw** and **ipgwi** applications or cards running **ipsg** application and having IP SG M3UA link configured on specified port (link parameter). This card is not valid for SSED CM cards or E5-ENET cards with **ss7ipgw** or **ipgwi** TCP/IP links.

Recovery

1. Verify that the card at the specified location is a DCM card running the SS7IPGW application. Enter the `rtrv-card` command. This information is shown in the *TYPE* and *APPL* fields of the output.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3838 Cmd Rej: SPLIT, NCICS, NCICE are not allowed with SI unless SI is 4, 5, or 13

Commands Used: `chg-appl-rtkey`

You entered a value for a circuit identification code split range (**split**), a new starting circuit identification code (**ncics**), or a new ending circuit identification code (**ncice**), along with a value for the service indicator (**si**) that is other than **4**, **5**, or **13** (or **tup**, **isup**, or **qbicc**).

Recovery

Re-enter the command specifying an **si** value of **4**, **5**, or **13** (or **tup**, **isup**, or **qbicc**).

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3839 Cmd Rej: SPLIT, RC, NCICS, NCICE or attributes required

Commands Used: `chg-appl-rtkey`

You entered the command to change a routing key but did not specify a value for the **split**, **rc**, **ncics**, or **ncice** parameter. At least one of these values must be specified to change a routing key.

Recovery

Re-enter the command specifying the value(s) for **split**, **rc**, **ncics**, or **ncice** appropriate to the change action you want to make.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3840 Cmd Rej: Attributes required

Commands Used: `chg-appl-rtkey`

You entered the command to change a routing key, but you did not supply attributes required in the command.

Recovery

Re-enter the **chg-appl-rtkey** command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3841 Cmd Rej: SRKQ exceed max allowed rtkey limit

Commands Used: `chg-sg-opts`

On any card that is running the `ss7ipgw` or `ipgwi` application, the total number of **srkq** value cannot exceed: 2500 for SSED CM cards running the `ss7ipgw` or `ipgwi` application.

Note:

The routing key limit is **1000** if any DCM cards configured as SS7IPGW or IPGWI are installed, and is **2500** if no DCM cards configured as SS7IPGW or IPGWI are installed

Recovery

Verify the sum of the value specified for the **srkq** parameter and the highest number of dynamic routing key entries at a location. Enter the `rept-stat-rtkey` command.

Perform one of the following actions:

1. Change the value specified for the **srkq** parameter such that the sum of the value specified for the **srkq** parameter and the highest number of dynamic routing keys at a location does not exceed the maximum allowed routing key limit.

Enter the `chg-sg-opts` command OR

2. Delete dynamic routing key entries at the specified location (**loc**) until the sum of the value specified for the (**srkq** from the output of Step 1) and the highest number of dynamic routing keys at a specific location does not exceed the maximum allowed routing key limit.

Enter the `dlt-appl-rtkey` command.

E3842 Cmd Rej: Entries in static route key table cannot exceed SRKQ

Commands Used: `chg-appl-rtkey`, `chg-sg-opts`, `ent-appl-rtkey`

The **srkq** parameter value in the `chg-sg-opts` command limits the maximum number of static routing keys that can be provisioned using the `ent-appl-rtkey` command. For `ss7ipgw` and `ipgwi` applications running on SSED CM cards (870-2732-xx), or E5-ENET cards (870-2212-xx) there is a limit of 2500 routing keys in the system. See the `chg-sg-opts` command for parameter values that allow 2500 routing keys to be defined in the system.

Recovery

1. Verify the values specified for the static routing key quantity (**srkq**) parameter and the total number of static entries in the Static Routing Key table.
Enter the `rept-stat-rtkey` command.
2. Perform one of the following actions:
 - a) Change the value specified for the **srkq** parameter so that it is greater than or equal to the total number of static entries in the Static Routing Key table.
Enter the `chg-sg-opts` command. OR
 - b) Delete static routing key entries until the desired value for **srkq** (from the output of Step 1) is greater than the total number of static entries in the Static Routing Key table.
Enter the `dlt-appl-rtkey` command.

E3843 Cmd Rej: SRKQ exceed max allowed rtkey limit

Commands Used: `chg-sg-opts`

The total number of **srkq** value must not be greater than:

2500 if all cards running the `ss7ipgw` or `ipgwi` application are SSEDCCM cards (870-2732-xx).

Note:

The routing key limit is **1000** if any DCM cards configured as `SS7IPGW` or `IPGWI` are installed, and **2500** if no DCM cards configured as `SS7IPGW` or `IPGWI` are installed.

Recovery

Re-enter the `chg-sg-opts` command specifying values for **srkq** and **drkq** such that their sum does not exceed the maximum allowed routing key limit.

E3844 Cmd Rej: LOC not allowed with MODE=STATIC

Commands Used: `rtrv-appl-rtkey`

You entered a value for the **loc** parameter, but **mode=static** is also specified. Specifying a card location (**loc**) refers to socket associations for dynamic entries in the Routing Key table (**mode=dynamic**) of the `SS7IPGW/IPGWx` card at the specified card location.

Recovery

Perform one of the following actions:

- Re-enter the `rtrv-appl-rtkey` command without specifying the **loc** parameter
OR

- Re-enter the `rtrv-appl-rtkey` command specifying **mode=dynamic** and the **loc** parameter

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3845 Cmd Rej: DYNRTK feature must be enabled to perform this operation

Commands Used: `chg-sg-opts`

You attempted to change an IP⁷ Secure Gateway option relating to Dynamic Routing keys, but the Dynamic Routing Key feature has not been turned on.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the Dynamic Routing Key feature is turned on (from the output of Step 1 - **dynrtk=on**), re-enter the **chg-sg-opts** command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If the Dynamic Routing Key feature is turned off (from the output of Step 1 - **dynrtk=off**), turn the feature on. Enter the `chg-feat:dynrtk=on` command.
4. Re-enter the **chg-sg-opts** command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3846 Cmd Rej: X25G Feature must be ON before X252000 can be ON

Commands Used: `chg-feat`

You cannot turn on the X252000 (2000 X.25 routes and destinations) feature because the X25G (X.25/SS7 gateway) feature is turned off. You must turn on the X25G feature (`chg-feat:x25g=on`) before you can turn on the **x252000** feature.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the X25G feature is turned on (**X25G=on**), re-enter the `chg-feat` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If the X25G feature is off (**X25G=off**), turn it on. Enter the `chg-feat:x25g=on` command.
4. Turn on the X252000 feature. Enter the command: `chg-feat:x252000=on`.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3847 Cmd Rej: FORCE valid only with APPL, DATA or INITCLK parameters

Commands Used: `init-card`

You specified the **force** parameter with a parameter other than the **appl**, **data**, or **initclk** parameters. This action is not allowed.

Recovery

Perform one of the following actions:

- Re-enter the **init-card** command without specifying the **force** parameter.
- OR
- Re-enter the **init-card** command specifying either the **appl**, **data**, or **initclk** parameter.

E3848 Cmd Rej: FORCE parameter valid only with DATA parameter

Commands Used: `init-sys`

You cannot specify the **force** parameter without specifying the **data** parameter.

Recovery

Perform one of the following actions:

- Re-enter the `init-sys` command without specifying the **force** parameter.
- OR
- Re-enter the `init-sys` command specifying both the **data** and **force** parameters.

E3849 Cmd Rej: Card(s) cannot warm restart - FORCE parameter required

Commands Used: `init-card`, `init-sys`

If the **data=persist** parameter is specified and any SCCP cards present in the system cannot maintain a persistent LNP database over the reset, the **force** parameter must be specified. A full data download may be required. [Table 27: Reason that Card Requires a Full Data Download](#) describes the possible reasons a card may require a full data download:

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **force** parameter.
- OR
- Re-enter the command without specifying the **data=persist** parameter.

Table 27: Reason that Card Requires a Full Data Download

<code>xxxxxxx</code> value	Description
POWER ON	Power on reset
XILINX VERSION	M256 Xilinx version has changed
DB VERSION	LNP Database version has changed
DB LEVEL	Database level is not supported or difference exceeds incremental loading capability
DB STATUS	Database status is incoherent
HW ERR	Hardware error bit checks on the card fail
AUDIT FAILED	Checksum comparisons of the LNP database fail
AUDIT TIMEOUT	LNP initialization audit timed out
NO AUDIT	Unable to perform LNP DB audit. LNP audit not on or excessive number of unknown checksums
USER REQUEST	User initiated <code>init-card</code> or <code>init-sys</code> command reload type cold
UNKNOWN	Unknown
OTHER	Other

E3850 Cmd Rej: Parameters inconsistent on re-entering of command

Commands Used: `init-sys`

Since this command causes a complete system reload, you are required to enter the command twice. This serves as a mechanism to confirm that you really want to execute the command. When you entered the `init-sys` command the second time, the parameters did not match the parameters you entered the first time. The parameters must be the same both times.

Recovery

Re-enter the `init-sys` command specifying the same parameters both times.

E3851 Cmd Rej: MTPRSE parameter is only valid if ITUMTPRS feature is ON

Commands Used: `chg-ls`, `ent-ls`

You specified the **mtpmse** parameter, but the ITU MTP Restart (ITUMTPRS) feature is off.

Recovery

1. Verify that the ITUMTPRS feature is turned on. Enter the `rtrv-feat` command. If the MTPRS feature is off, you must turn it on.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

2. Turn on the MTPRS feature. Enter the `chg-feat:itumtprs=on` command.
3. Perform one of the following actions:
 - a) Re-enter the command that generated this error message.
OR
 - b) Re-enter the command that generated this error message without specifying the **mtpmse** parameter.

E3852 Cmd Rej: Specified APPL or LOC not supported with DATA parameter

Commands Used: `alw-card`, `init-card`, `rst-card`

The **data** parameter can be specified only for SCCP card locations or GPLs. Refer to the *Commands Manual* for more information.

Recovery

Perform one of the following actions:

- Re-enter the command, specifying a valid value for the **appl** or **loc** parameter.
OR
- Re-enter the command without specifying the **data** parameter.

E3853 Cmd Rej: SS7IPGW/IPGWI cards must be inhibited to change SYNC

Commands Used: `chg-sg-opts`

You attempted to perform an action on a card that is not allowed if the card is in a state other than Out-of-Service - Maintenance-Disabled (OOS-MT-DSBLD).

Recovery

1. Enter the `inh-card` command to change the state of the card at the specified location to OOS-MT-DSBLD.

Note:

If the card contains signaling links, all links must be OOS-MT-DSBLD before you can inhibit the card.

2. Re-enter the `chg-sg-opts` command that generated this error message.

E3854 Cmd Rej: NCICS unspecified, NCICE must be greater than or equal to CICS

Commands Used: `chg-appl-rtkey`

The value entered for the new ending circuit identification code (**ncice**) must be greater than or equal to the value entered for the starting circuit identification code (**cics**), when the new starting circuit identification code (**ncics**) is not specified.

Recovery

Re-enter the `chg-appl-rtkey` command specifying a value for **ncice** that is greater than or equal to the value specified for **cics**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3855 Cmd Rej: Command not valid for IPLIMI

Commands Used: `blk-slk`, `tst-slk`, `ublk-slk`

The command you entered is not valid on TCP/IP links (DCM cards equipped with certain IPLIMI links).

Note:

The command is allowable, however, for IPLIM M2PA link types. IPLIM/IPLIMI does support Ports A, B, A1, B1, A2, B2, A3 or B3 for M2PA/SCTP associations on SSEDCCM cards.

Recovery

1. Enter the `rtrv-card` command to verify that the card at the specified location is a DCM card running the IPLIMI application.
This information is shown in the *TYPE* and *APPL* fields of the output.
2. If the card type is other than DCM and the application type is other than IPLIMI, re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3856 Cmd Rej: Processor timeout error

Commands Used: `chg-sg-opts`

There was a processor timeout error during the period when this command was entered.

Recovery

Re-enter the **chg-sg-opts** command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3857 Cmd Rej: Unexpected response message error

Commands Used: `chg-sg-opts`

This command generated an unexpected response message.

Recovery

Re-enter the **chg-sg-opts** command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3858 Cmd Rej: Host Name Still Referenced in IP Link Table

Commands Used: `dlt-ip-host`

You entered the command to delete an entry from the IP Host table which defines local host names for IP addresses, but the entry has not been deleted from the IP Link table.

Recovery

1. Determine the associated IP address for the local host name.
Enter the `rtrv-ip-host` command.
2. Determine the parameter values for **loc** and **port** associated with the IP address from the output of Step 1.
Enter the `rtrv-ip-lnk` command.
3. Change the IP address for the location and port from the output of Step 2 to **0.0.0.0 (ipaddr=0.0.0.0)**.
Enter the `chg-ip-lnk` command. This will delete the IP address for this entry from the IP Link table.

4. Re-enter the `dlt-ip-host` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3860 Cmd Rej: Link not valid for card or application type

Commands Used: `chg-assoc`, `ent-assoc`

Only the **link=a** parameter can be specified on cards running the **ss7ipgw** or **ipgwi** applications.

The link parameter values **a**, **b**, **a1**, **b1**, **a2**, **b2**, **a3**, and **b3** can be specified only if the card is an SSEDCCM card running the **iplim** or **iplimi** application.

The link parameter values **a**, **b**, **a1-a7**, and **b1-b7** can be specified only if the card is an E5-ENET card running the **iplim** or **iplimi** application, or **a**, **b**, **a1-a15**, **b1-b15** for the **ipsg** application.

If the new **lhost** is configured on an IPSP card, then the **link** parameter cannot be specified.

Since associations for IPSP links are configured for each signaling link, the **link** parameter cannot be specified when the **lhost** parameter is configured on IPSP card.

Recovery

Display the card's configuration. Enter the `rtrv-card` command specifying the card location (**loc**) used in the command that generated this error message. The card's application is shown in the *APPL* field of the output.

- If the specified card is running the **ss7ipgw** or **ipgwi** application, re-enter the command specifying the **link=a** parameter.
- If the specified card is running the **iplim** or **iplimi** application, re-enter the command specifying the **link=a** or **link=b** parameter.
- If the specified card is a SSEDCCM card running the **iplim** or **iplimi** application, re-enter the command specifying only link parameter values **a**, **b**, **a1**, **b1**, **a2**, **b2**, **a3**, or **b3**.
- If the specified card is running the **ipsg** application with parameter values of **a**, **b**, **a1-a15**, or **b1-b15**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3861 Cmd Rej: Cannot echo to OAP terminal

Commands Used: `act-echo`

You specified an OAP port for the **trm** parameter, which is not allowed.

Recovery

1. Determine the valid terminals in the system.
Enter the `rtrv-trm` command. If the entry in the *TYPE* column is OAP, the terminal is not a valid choice.

2. Re-enter the `act-echo` command specifying a valid value for the `trm` parameter.

E3862 Cmd Rej: SLSOCBIT parameter is only valid for ITU link sets

Commands Used: `chg-ls`, `ent-ls`

If the linkset associated with the specified routeset is ANSI, then the `slsocbit` and `slrsrb` parameters cannot be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying an ITU link set.
OR
- Re-enter the command without specifying the `slsocbit` or `slrsrb` parameters.

E3863 Cmd Rej: SLSOCBIT parameter not permitted if SLSOCB feature is off

Commands Used: `chg-ls`, `ent-ls`

The `SLSOCB` feature must be turned on before the `slsocbit` parameter can be specified

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
 - a) If the `SLSOCB` feature is turned on, re-enter the command that generated this error message.
Note:
Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.
 - b) If the `SLSOCB` feature is turned off, turn the feature on: Enter the `chg-feat:slsocb=on` command.
2. Re-enter the command that generated this error message specifying the `slsocbit` parameter
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3864 Cmd Rej: SLSRSB parameter is only valid for ITU Link Sets

Commands Used: `chg-ls`, `ent-ls`

The `slrsrb` parameter cannot be specified for a non-ITU link set. The `slrsrb` parameter is only valid for ITU link sets.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **slsrsb** parameter for an ITU link set.
- OR
- Re-enter the command without specifying the **slsrsb** parameter.

E3865 Cmd Rej: Cannot enter MTPRSE with SLSOCBIT, SLSRSB parameters

Commands Used: `rtrv-ls`

You cannot specify the MTP Restart Equipped (**mtprese**) parameter and the Other CIC Bit (**slsobit**) or Rotated SKS Bit (**slsrsb**) parameter.

Recovery

Re-enter the `rtrv-ls` command specifying a valid parameter combination.

If necessary, consult your *Commands Manual*.

E3866 Cmd Rej: Fan feature must be enabled

Commands Used: `chg-e1`, `chg-t1`, `ent-e1`, `ent-slk`, `ent-t1`

The fan feature bit must be on before you can

- specify links **a16... a31**,
- specify links **b16... b31**,
- specify E1 or T1 ports **3** through **8**,
- specify `linkclass=unchan` for an E1 port
- bring an HC-MIM card in an EAGLE 5 ISS shelf into service
- provision a second SE-HSL port.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the fan feature bit is on, re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. To turn on the fan feature bit, enter the `chg-feat:fan=on` command.
4. Verify the fan feature bit is turned on. Enter the `rtrv-feat` command.
5. Re-enter the command that generated this error message.

E3867 Cmd Rej: MPC feature must be enabled

Commands Used: `ent-spc`, `rtrv-spc`, `dlt-spc`

Before you can add a secondary point code (SPC), you must first turn on the Multiple Point Code (MPC) feature.

Note: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the MPC feature is turned on, re-enter the command that generated this error message.
3. Turn the MPC feature on. Enter the command: `chg-feat:mpc=on`. Refer to the *Commands Manual* for further assistance.
4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3870 Cmd Rej: GTT must be ON before VGTT can be ON

Commands Used: `chg-feat`

You cannot turn on the Variable length GTT (VGTT) feature because the Global Title Translation (GTT) feature is turned off. GTT must be turned on before you can turn on VGTT.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

2. If the GTT feature is turned on (GTT = on), re-enter the `chg-feat :vgtt=on` command.
3. Turn on the GTT feature. Enter the command: `chg-feat:gtt=on`.
4. Turn on the VGTT feature.
Enter the `chg-feat :vgtt=on` command.
5. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3871 Cmd Rej: ITUTFR parameter is only valid for ITU link sets

Commands Used: `chg-ls`, `ent-ls`, `rtrv-ls`

You attempted to specify the **itutfr** parameter for a non-ITU national linkset. The **itutfr** parameter is valid only for ITU national (ITU-N) linksets. Consequently, if you specify the **itutfr** parameter, the value specified for the **lsn** parameter must also be an ITU-N linkset.

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the **itutfr** parameter.
- OR
- Re-enter the command specifying the **itutfr** parameter with an ITU national linkset.

E3872 Cmd Rej: FRAMING=ESFPERF not supported

Commands Used: `chg-t1`, `ent-t1`

The ST-HSL-A feature must be turned on before the **framing=esfperf** parameter can be specified.

Recovery

1. Display the feature status in the database.
Enter the `rtrv-ctrl-feat` command.
2. Enable the feature.
Enter the `enable-ctrl-feat` command and the appropriate part number and access key information. Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information.
3. Turn the SE-HSL-A feature on.
Enter the `chg-ctrl-feat` command.
4. When the feature is enabled and turned on, re-enter the command that generated this error.

E3873 Cmd Rej: Card GPL type IPGWI requires a link set with IPGWAPC=YES

Commands Used: `ent-slk`

When entering an IP link (**type=ipgwi**) with the `ent-slk` command, the linkset name (**lsn**) parameter must reference a linkset that specifies an IP gateway adjacent point code (**ipgwapc=yes**).

Recovery

1. Determine if the IP link is **type=ipgwi** and references **ipgwapc=yes**.
Enter the `rtrv-ls` command specifying the linkset name (**lsn**).
 - a) If the criteria identified in Step 1 are met, re-enter the `ent-slk` command.
 - OR
 - b) If the IP link is **type=ipgwi** but **ipgwapc** is not yes, enter the command `ent-ls:ipgwapc=yes`

2. Re-enter the `ent-slk` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3874 Cmd Rej: TUP must use DPC/SI route key if DPC is ANSI

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified `si=4` (for a routing key in an ITU network using TUP) and an ANSI Destination Point Code (`dpc`). When you specify `si=4` and an ANSI DPC:

1. You must specify only the `dpc` and `si` parameters to identify the routing key to be entered, deleted, retrieved, or changed.
2. The `opc/opca/opci/opcn`, `cics`, `cice`, `ncics`, `ncice`, `split`, `pstncat`, `pstnid`, and `norm` parameters are not valid in this case.
3. You can enter just the `sname` and `asname` for a new routing key.
4. You can change only the `sname` (with the `nsname` parameter) and the `asname` (with the `nasname` parameter) of an existing routing key.

Recovery

Re-enter the command specifying only the `dpc` and `si` parameters to identify the routing key. Specify the `sname` or `asname` parameter to enter a new routing key or delete an existing routing key. Specify the `nsname` or `nasname` parameter to change an existing routing key.

E3875 Cmd Rej: Command not valid for IPGWI

Commands Used: `alw-slk`, `blk-slk`, `inh-slk`, `rept-stat-tstslk`, `tst-slk`, `unhb-slk`

The command you entered is not valid on TCP/IP point-to-multipoint links, that is, DCM cards equipped as IPGWI links. The card must be equipped and in service, and must be an SSEDCCM or E5-ENET card running the `iplim` or `iplimi` application with links having `ipliml2=m2pa`.

Recovery

1. Verify that the card at the specified location is a DCM card running the IPGWI application.
Enter the `rtrv-card` command. This information is shown in the `TYPE` and `APPL` fields of the output.
2. If the card type is other than DCM or the application type is other than IPGWI, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3876 Cmd Rej: L2STATS not valid for IPGWI

Commands Used: `rept-stat-slk`

The command that you entered is not valid. Level 2 status (l2stats) output is not available for TCP/IP point-to-multipoint links (DCM cards equipped as IPGWI links).

Recovery

1. Enter the `rtrv-card` command to verify that the card at the specified location is a DCM card running the IPGWI application.
This information is shown in the *TYPE* and *APPL* fields of the output.
2. If the card type is other than DCM card or the application type is other than IPGWI, re-enter the `rept-stat-slk` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3877 Cmd Rej: ANSI/ITU point code type mismatch

Commands Used: `chg-rtx`, `ent-rte`, `ent-rtx`, `chg-dstn`

The network domain of the adjacent point code in the linkset or of the routes in the specified routeset must be the same network domain of the specified destination point code or its alias. A destination point code with ANSI network type cannot use a routeset with ITU network type. A destination point code with ITU network type cannot use a routeset with ANSI network type.

The linkset must be ITU as specified routeset is provisioned with ITU only parameters. SLSRSB and SLSOCB are ITU only parameters of a routeset. The group code must match for all linksets with ITU-N adjacent point code because the ITU Duplicate Point Code feature is on.

The network domain of the APC in the Linkset specified by the linkset name (*lsn*) parameter must be the same network domain of specified the DPC or its alias.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command. The APCs of the linksets are shown in the *APCA*, *APCI*, and *APCN* fields of the output.
2. Enter the `rtrv-dstn` command to display the DPCs in the database.
The DPCs are shown in the *DPCA*, *DPCI*, and *DPCN* fields of the output.
3. Re-enter the command specifying a DPC type that is valid with the linkset APC type.
 - a) ANSI point codes are shown in the *DPCA* and *APCA* fields of the `rtrv-dstn` and `rtrv-ls` command outputs.
 - b) ITU-I point codes are shown in the *DPCI* and *APCI* fields of the `rtrv-dstn` and `rtrv-ls` command outputs.
 - c) ITU-N point codes are shown in the *DPCN* and *APCN* fields of the `rtrv-dstn` and `rtrv-ls` command outputs.

- d) 24-bit ITU-N point codes are shown in the *DPCN24* and *APCN24* fields of the *rtrv-dstn* and *rtrv-ls* command outputs.

E3878 Cmd Rej: CIC outside of valid range for SI

Commands Used: *chg-appl-rtkey*, *dlt-appl-rtkey*, *ent-appl-rtkey*, *rtrv-appl-rtkey*

The values specified for the *cics* and *cice* parameters must be in range for the routing key SI. Refer to the *Commands Manual* for valid CIC and SI parameter values.

For the *ent-appl-rtkey* command, the *si=5* parameter must be specified before the *cics* and *cice* parameters can be specified.

Recovery

1. Verify the *rtrv-appl-rtkey* command to verify the SI and CIC values for the routing key.
2. Re-enter the command that generated this error message, with a valid value for the *cics* or *cice* parameter, or both, for the routing key SI.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3879 Cmd Rej: The MPC feature must be ON before ITUDUPPC can be ON

Commands Used: *chg-feat*

You tried to turn on the ITU National Duplicate Point Code (ITUDUPPC) feature, but the Multiple Point Code (MPC) feature is not on. The MPC feature must be turned on before you can turn on the ITUDUPPC feature.

Recovery

1. Display the features in the database. Enter the *rtrv-feat* command.
2. If the MPC feature is turned on (MPC = on from the output of Step 1), re-enter the command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the *chg-feat* command in the *Commands Manual* for further information.

3. If the MPC feature is off (MPC = off from the output of Step 1), turn it on. Enter the *chg-feat :mpc=on* command.
4. Turn on the ITU National Duplicate Point Code (ITUDUPPC) feature. Enter the command: *chg-feat:ituduppc=on*.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3880 Cmd Rej: Grp Code of dstn & True PC must match if no Secondary PC

Commands Used: `chg-dstn`, `ent-dstn`

If the destination does not use an SPC, the group code of the destination must be the same as the group code of the ITU national true point code. You specified an ITU-N destination that **does not use** a secondary point code (**spc**). In such cases, the group code of the ITU-N destination must match the group code of the ITU-N true point code (**tpc**).

If the destination uses an SPC, then the group code of the destination must match the group code of the SPC.

Recovery

1. Enter the `rtrv-sid` command to display the group code of true point code.
The group code (**aa-zz**) is a two-letter code appended to the last subfield of an ITU-N point code. It appears in the PCN column of the `rtrv-sid` output. Here is an example: **128-15-1-1-si** (**si** is the group code).
2. Re-enter the command that generated this error message specifying an ITU-N destination whose group code matches the group code of the true point code.

E3881 Cmd Rej: Group Code of destination and Secondary PC must match

Commands Used: `chg-dstn`, `ent-dstn`

If the ITUDUPPC feature is on, the group code of the ITU-N destination must match the group code of the secondary point code (SPC). The group code (**aa-zz**) is the two-letter code appended to the last subfield of an ITU-N point code (for example, **si** is the group code in SPC: **128-15-1-1-si**).

If an ITU national destination is being changed and the ITUDUPPC feature is turned on, this applies depending on whether the destination uses an SPC. For example, if the ITU national true point code has a group code of **ee**, then destinations with group codes of **ee** can be added without using an SPC. Destinations with a group code of **ff**, however, must use an SPC with a group code of **ff**.

Recovery

1. Display the SPCs in the SPC table. Enter the `rtrv-spc` command.
2. Re-enter the command that generated this error message specifying an ITU-N destination whose group code matches the group code of the secondary point code.

E3883 Cmd Rej: GSM Map Screening feature must be ON

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-ls`, `chg-measopts`, `chg-mtc-measopts`, `chg-sccpopts`, `chg-stpopts`, `enable-ctrl-feat`,

ent-gsms-opcode, ent-gsmssn-scrn, ent-gsmmap-scrn, ent-ls, rept-ftp-meas, rept-meas, rtrv-ls

The GSM Map Screening feature must be turned on before various actions can occur. [Table 28: Conditions that Generate Error Message E3883](#) describes the conditions that cause this error.

Table 28: Conditions that Generate Error Message E3883

Commands	Condition
chg-gsmmap-scrn, ent-gsmmap-scrn, chg-gsms-opcode, ent-gsms-opcode, ent-gsmssn-scrn	The GSM MAP Screening feature must be enabled and turned on before these commands can be entered.
chg-ls, ent-ls	The GSM Map Screening feature must be enabled and turned on before the gmscrn parameter can be specified.
chg-measopts, chg-mtc-measopts	The GSM MAP Screening feature must be turned on before the mtcdmap=on parameter or the mtchmap=on parameter can be specified.
chg-sccopts	The GSM Map Screening feature must be enabled and turned on before the gmstcapce parameter can be specified.
chg-stpopts	The GSM Map Screening feature must be turned on before the gsmdflt or gsmdecerr parameters can be specified.
enable-ctrl-feat	The GSM MAP Screening feature must be turned on before enabling the EGMS feature.
rept-ftp-meas, rept-meas	The GSM MAP Screening feature must be turned on before the enttype=mapscrn parameter or the mtcdmap=on parameter can be specified.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Verify the GSM MAP Screening feature was purchased and installed in your system.
3. Enable the GSM MAP Screening feature.
Refer to the *Database Administration Manual - Features* for more information.
4. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3884 Cmd Rej: SSN/TYPE combination already exists

Commands Used: `ent-gsmssn-scrn`

You attempted to enter an `ssn/type` parameter combination that already exists in the GSM SSN Screening table. The subsystem number and type pairs must be unique.

Recovery

Re-enter the `ent-gsmssn-scrn` command specifying different values for the `ssn/type` parameter combination.

E3885 Cmd Rej: Failure reading the GSM SSN Screening Table

Commands Used: `ent-gsmssn-scrn`, `dlt-gsms-opcode`, `dlt-gsmssn-scrn`,
`rtrv-gsmssn-scrn`

The GSM SSN Screening table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3886 Cmd Rej: SSN/TYPE combination does not exist

Commands Used: `ent-gsmssn-scrn`, `dlt-gsmssn-scrn`

You specified an `ssn/type` parameter combination that does not already exist in the GSM SSN Screening table as required.

Recovery

1. Display the GSM SSN Screening table. Enter the `rtrv-gsmssn-scrn` command.
2. Re-enter the command specifying an `ssn/type` parameter combination that exists in the GSM SSN Screening table.

E3887 Cmd Rej: OPCODE already exists

Commands Used: `ent-gsms-opcode`

You specified a value for the `opcode` parameter that already exists in the GSM MAP Op-Code table. You must specify a unique value.

Recovery

1. Display the GSM MAP Op-Code table.
Enter the `rtrv-gsms-opcode` command.
2. Re-enter the `ent-gsms-opcode` command specifying a value for the **opcode** parameter that does not already exist in the database.

E3888 Cmd Rej: OPNAME already used

Commands Used: `ent-gsms-opcode`

You specified a value for the **opname** parameter that already exists in the GSM MAP Op-Code table. You must specify a unique value.

Recovery

1. Display the GSM MAP Op-Code table.
Enter the `rtrv-gsms-opcode` command.
2. Re-enter the `ent-gsms-opcode` command specifying a value for the **opname** parameter that does not already exist in the database.

E3889 Cmd Rej: Failure reading the GSM OPCODE Table

Commands Used: `chg-gsms-opcode`, `chg-gsmmap-scrn`, `dlt-gsms-opcode`,
`dlt-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`,
`rtrv-gsms-opcode`

The GSM MAP Op-Code table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3890 Cmd Rej: Failure reading the GSM MAP SCRN Table

Commands Used: `chg-gsmmap-scrn`, `dlt-gsmmap-scrn`, `ent-gsmmap-scrn`,
`rtrv-gsmmap-scrn`

The GSM MAP screening table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3892 Cmd Rej: OPNAME does not exist in the database

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `dlt-gsmmap-scrn`,
`dlt-gsms-opcode`, `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`

You specified a value for the `opname` parameter that does not exist in the GSM MAP Op-Code table. You must specify an existing value.

Recovery

1. Enter the `rtrv-gsms-opcode` command to display the existing entries.
2. Re-enter the original command specifying a value for the `opname` parameter that already exists in the database.

E3893 Cmd Rej: Entry being deleted is referenced by a GSM MAP Screen entry

Commands Used: `dlt-gsms-opcode`

You attempted to delete an entry that is referenced in the GSM MAP screening table. This action is not allowed.

Recovery

1. Delete the entry from the GSM MAP screening table.
Enter the `dlt-gsms-scrn` command.
2. Delete the desired entry.
Re-enter the `dlt-gsms-opcode` command.

E3894 Cmd Rej: SADDR and EADDR must have the same number of digits

Commands Used: `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

The `saddr` parameter does not contain the same number of digits as the `eaddr` parameter. The `saddr` and the `eaddr` parameter must contain the same number of digits.

Recovery

Re-enter the command specifying the same number of digits for the `saddr` and the `eaddr` parameter values.

E3895 Cmd Rej: EADDR must be greater than SADDR

Commands Used: `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

The value specified for the **eaddr** parameter is less than the value specified for the **saddr** parameter.

Recovery

Re-enter the command specifying a value for the **eaddr** parameter that is greater than or equal to the value for the **saddr** parameter.

E3897 Cmd Rej: GSM MAP SCRN entry already exists or overlaps another entry

Commands Used: `ent-gsmmap-scrn`

You specified either a single entry for the CgPA or CdPA (that is, the **eaddr** parameter was not specified) or a range entry for the CgPA or CdPA (that is, the **eaddr** parameter was specified).

- If a single entry is specified for the CgPA or CdPA (that is, **eaddr** is not specified), the combination of **saddr**, **npv**, **naiv** for the specified **opname** must not already exist in the GSM MAP Screening Table.
- If a range entry is specified for the CgPA or CdPA (that is, **eaddr** is specified), the combination of **saddr**, **eaddr**, **npv**, **naiv** for the specified **opname** must not already exist or overlap with another range entry in the GSM MAP Screening Table.

Recovery

1. Display a list of existing entries.
Enter the `rtrv-gsmmap-scrn` command.
2. Re-enter the `ent-gsmmap-scrn` command specifying a single or range entry that does not already exist or that does not overlap any other range entry in the database.

E3898 Cmd Rej: EADDR cannot be specified without SADDR

Commands Used: `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

If you specify the **eaddr** parameter, you must also specify the **saddr** parameter. The **eaddr** parameter alone is not supported.

Recovery

Perform one of the following actions:

1. Re-enter the command without specifying the **eaddr** parameter.
OR

2. Re-enter the command specifying both the `eaddr` and `saddr` parameters.

E3900 Cmd Rej: GSM Map Screening feature must be enabled

Commands Used: `dlt-gsms-opcode`, `dlt-gsmmap-scrn`, `dlt-gsmssn-scrn`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`, `rtrv-gsmssn-scrn`

The command failed because the GSM MAP Screening feature is not enabled.

Recovery

1. Display the status of features in your system that have feature access keys.
Enter the `rtrv-ctrl-feat` command.
2. Refer to the procedures in the Database Administration Manual - Features and to the Commands Manual to enable, turn on, and use the GSM MAP Screening feature.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3901 Cmd Rej: CGPA entry is referred by CDPA entries

Commands Used: `dlt-gsmmap-scrn`

The CgPA entry cannot be deleted because it is referred to by other CdPA entries.

Recovery

1. Display the existing CdPA entries for the CgPA you want to delete.
Enter the `rtrv-gsmmap-scrn` command.
2. Delete all the CdPA entries located in Step 1 for the CgPA you want to delete.
3. Re-enter the `dlt-gsmmap-scrn` command.

E3902 Cmd Rej: FORBID cannot be STATE or LOCATION for the given OPNAME

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

To specify the `nforbid/forbid=state/location` parameter, the operation code referenced by the specified `opname` must have a value of 71. The `nforbid/forbid=state/location` option is only valid for ATI MAP operation codes; `opcode=71` signifies an ATI MAP operation code.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a different value for the **opname** parameter
OR
- Re-enter the command that generated this error message without specifying **nforbid/forbid=state/location**.

E3903 Cmd Rej: Screening action cannot be ATIERR for the given OPNAME

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

To specify the `action=atierr`, or `naction=atierr` parameter, the operation code referenced by the specified `opname` must have a value of 71. The `atierr` option is only valid for ATI MAP operation codes; `opcode=71` signifies an ATI MAP operation code.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying `action/naction=pass/discard`, but do not specify a value of `atierr`.
OR
- Re-enter the command that generated this error message specifying a different value for the `opname` parameter (that is, `opcode=71`).

E3904 Cmd Rej: DFLTACT cannot be ATIERR unless OPCODE=71

Commands Used: `chg-gsms-opcode`, `ent-gsms-opcode`

You specified the `dfltact/ndfltact=atierr` parameter with a value other than 71 for the `opcode` parameter. If you specify the `dfltact/ndfltact=atierr` parameter, you must specify `opcode=71`. The `atierr` option is only valid for ATI MAP operation codes; `opcode=71` signifies an ATI MAP operation code.

Recovery

Re-enter the command specifying the `dfltact=atierr` or `ndfltact=atierr` and `opcode=71` parameter combination.

E3905 Cmd Rej: CGSR doesn't exist for specified OPNAME

Commands Used: `chg-gsmmap-scrn`, `dlt-gsmmap-scrn`, `ent-gsmmap-scrn`,
`rtrv-gsmmap-scrn`

You issued a command that requires a `cgsl` that does not currently exist in the database. The following lists by command remedial actions to perform for this error.

For additional details, refer to the Commands Manual.

Recovery chg-gsmmap-scrn, dlt-gsmmap-scrn

You issued a command that requires an existing **cgsr** (CgPA Screening Reference). This error reports that the specified **opname** does not have a **cgsr**.

1. Enter the `rtrv-gsmmap-scrn` command specifying the **opname** specifying the same as the original message.
2. Re-enter the command specifying the appropriate **opname**, **cgsr**, and optionally the **cdsr** parameter(s).

Recovery ent-gsmmap-scrn, rtrv-gsmmap-scrn

You issued a command that requires an existing **cgsr** (CgPA Screening Reference). This error reports that the specified **opname** does not have a **cgsr**.

1. To create a CgPA entry, enter the `ent-gsmmap-scrn` command specifying the **cgsr** and **opname** parameters.
2. To create a CdPA entry, enter the `ent-gsmmap-scrn` command specifying the **opname**, **cgsr**, and **cdsr** parameters.
3. To display any portion of the EGMS MAP Screen Table, specify the `rtrv-gsmmap-scrn` command and the appropriate **opname**, **cgsr**, and optionally the **cdsr** parameter(s)

E3906 Cmd Rej: The GSM MAP Screening table is full

Commands Used: `ent-gsmmap-scrn`

The GSM MAP Screening table is full. You must delete an entry before another one can be added.

Recovery

1. Display the GSM MAP Screening table.
Enter the `rtrv-gsmmap-scrn` command.
2. Enter the `dlt-gsmmap-scrn` command specifying an entry shown in the output in Step 1.
3. Re-enter the `ent-gsmmap-scrn` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3908 Cmd Rej: Invalid OAM HW config or an HMUX card is out of service

Commands Used: `act-upgrade`

Invalid hardware configuration alarms are set or an HMUX alarm must be addressed.

Recovery

1. Verify that all HMUX cards are in service with the `rept-stat-card` command.
2. Re-enter the `act-upgrade` command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3909 Cmd Rej: XLIST Point codes may not be permanently inhibited

Commands Used: `inh-alm`

This command cannot be used to permanently inhibit XLIST point codes.

Recovery

To permanently inhibit XLIST point codes refer to the *Database Administration Manual - SS7* for assistance.

E3910 Cmd Rej: Translation TYPEN24 specified does not exist

Commands Used: `dlt-tt`, `rtrv-tt`

The translation type specified (**typen24**) must be in the Translation Type table.

Recovery

1. Re-enter the `rtrv-tt` or `rtrv-gtt` command specifying no parameters to display the Translation Type table.
2. Re-enter the command specifying one of the translation type (**tt**) values displayed from the output of Step 1.

E3911 Cmd Rej: Either PLNP or WNP Features must be ON

Commands Used: `chg-lnpopts`

You specified the `wqredrct` parameter, which requires that either the Personal Communication Service 1900 Local Number Portability (PLNP) feature or the Wireless LNP (WNP) feature be turned on.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the PLNP or WNP feature is turned on (`wnp=on` or `plnp=on`), re-enter the command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

3. If both features are turned off (**wnp=off** or **plnp=off**), turn one of them on.
Enter the `chg-feat :wnp=on` or `chg-feat :plnp=on` command.

4. Re-enter the `chg-lnpopts` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3912 Cmd Rej: Translation TYPEN already exists

Commands Used: `ent-tt`

The translation type (`typen`) specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

1. Determine if the translation type you want to use already exists in the translation type table.
Enter the `rtrv-tt` command.
2. Re-enter the `ent-tt` command specifying a different translation type.
To see if the translation type you want to use already exists in the translation type table, enter the `rtrv-tt` command.

E3913 Cmd Rej: Translation TYPEI already exists

Commands Used: `ent-tt`

The translation type (`typei`) specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

Re-enter the `ent-tt` command specifying a different translation type.

To see if the translation type you want to use already exists in the translation type table, enter the `rtrv-tt` command.

E3916 Cmd Rej: GTT Selector does not exist in GTIN-TT-NP(V)-NAI(V)

Commands Used: `dlt-gttsel`

The specified entry does not match an existing `gtin`, `tt`, `np/nai`, and `npv/naiv` parameter combination as required.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttsel` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3917 Cmd Rej: GTT Selector does not exist in GTII-TT-NP(V)-NAI(V)

Commands Used: `dlt-gttsel`

The specified entry does not match an existing `gtii`, `tt`, `np/nai`, and `npv/naiv` parameter combination as required.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttsel` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3918 Cmd Rej: Translation TYPEN specified does not exist

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `rtrv-gtt`, `rtrv-tt`

The translation type specified (`typen`) must be in the Translation Type table.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` or `rtrv-gtt` command specifying no parameters.
2. Re-enter the command specifying one of the translation type values displayed.

E3919 Cmd Rej: Translation TYPEI specified does not exist

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `rtrv-gtt`, `rtrv-tt`

The translation type specified (`tt=typei`) is not in the Translation Type table.

Recovery

1. Display the Translation Type table.
Enter the `rtrv-tt` or `rtrv-gtt` command specifying no parameters.
2. Re-enter the command specifying a Translation Type values that exists in the Translation Type table.

E3921 Cmd Rej: ITU National Point Code must be full point code

Commands Used: all commands that use ITU national point codes except retrieve commands

ANSI point code value 000-000-000 and ITU-International point code value 0-000-0 are not allowed. ITU-National point code must be a full point code. A full point code is one that you specify with a numerical value for the *nnnnn* segment of the point code. If the ITUDUPPC (ITU national duplicate point code) feature is on, the ITU national point code will also contain a group code. The group code is a two-character field from aa to zz that is entered as the last subfield of an ITU-N point code, *nnnnn-gc* (for example, 2112-aa). You can also assign a flexible point code format with the `chg-stpopts:npcfmti` parameter.

Refer to the `chg-stpopts` command in the *Commands Manual* for information on flexible point code formats.

None of the above formatting options allows you to use an asterisk (*) for entering or changing ITU national point codes. The asterisk is allowed only for retrieving ITU national point codes.

Recovery

Re-enter the command specifying a valid value for the ITU national point code.

E3922 Cmd Rej: GTT must be ON before INP/AINPQ can be ON

Commands Used: `chg-ctrl-feat`

You cannot turn on the INAP Number Portability (INP) feature, or the ANSI-41 INP Query (AINPQ) feature, if the Global Title Translation (GTT) feature is turned off. The GTT feature must be turned on before the INP feature, or the ANSI-41 INP Query (AINPQ) feature, can be turned on.

Recovery

1. Display the status of the controlled features in the database. Enter the `rtrv-feat` command and the `rtrv-ctrl-feat` command.

- a) If the GTT feature is turned on, re-enter the command.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

- b) If the GTT feature is off, refer to the procedures in the *Feature Manual - INP/AINPQ* to enable, turn on, and use the INP feature or the AINPQ feature.

2. Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3925 Cmd Rej: HOMERN Table is full

Commands Used: `ent-homern`

The HOMERN table is full. You must delete a routing number before another one can be added. The HOMERN table cannot be full.

Recovery

1. Display the routing numbers in the HOMERN table.
Enter the `rtrv-homern` command.
2. Enter the `dlt-homern` command specifying a routing number shown in the output from Step 1.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3926 Cmd Rej: Failed reading HOMERN Table

Commands Used: `dlt-homern`, `ent-homern`, `rtrv-homern`

The HOMERN table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3927 Cmd Rej: Failed reading INPOPTS Table

Commands Used: `chg-inpopts`, `rtrv-inpopts`

The INPOPTS table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3928 Cmd Rej: STP True PC and INP SSN do not exist in MAP table

Commands Used: `ent-ss-appl`

You attempted to reserve an INP subsystem number (`ssn`) for an application, but the STP true point code/subsystem number combination has not been defined in the mated applications (MAP) table.

Recovery

1. View the point codes assigned to the system.
Enter the `rtrv-sid` command
2. Assign mated application values for the true point code (`pc/pca/pci/pcn`) and the INP subsystem number (`ssn`).
Enter the `ent-map` command.

3. Re-enter the `ent-ss-appl` command specifying the newly assigned values for (`pc/pca/pci/pcn`) and the INP `ssn`.

E3929 Cmd Rej: LNP, INP, EIR, or VFLEX feature must be ON or ATINP must be enabled

Commands Used: `alw-map-ss`, `inh-map-ss`

The LNP, INP, EIR, or V-Flex feature must be turned on, or the ATINP feature must be enabled, before this command can be entered.

Note: Before the LNP feature can be turned on, or before the quantity of LNP telephone numbers can be increased, DSM/VSCCP cards and a sufficient amount of memory must be configured in the EAGLE 5 ISS.

Note: After a Permanently On feature that is controlled by a feature access key is turned on, the feature cannot be turned off.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
Note: The LNP feature is turned on when an LNP ported TNs quantity is shown in the `rtrv-ctrl-feat` command output.
2. Enable and turn on the desired feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. If the error message appears again, call your Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E3930 Cmd Rej: RN already exists in HOMERN Table

Commands Used: `ent-homern`

The specified routing number (**rn**) already exists in the HOMERN table. The **rn** must be unique to the HOMERN table. The routing number must not already exist in the HOMERN table.

Recovery

1. Display the routing numbers in the HOMERN table.
Enter the `rtrv-homern` command.
2. Re-enter the `ent-homern` command that generated this error message specifying a value for **rn** that is not in the output in Step 1.

E3931 Cmd Rej: RN does not exist in HOMERN Table

Commands Used: `dlt-homern`

The specified routing number must already exist in the HOMERN table.

Recovery

1. Display the routing numbers in the HOMERN table.
Enter the `rtrv-homern` command.
2. Re-enter the `dlt-homern` command specifying one of the RN values displayed in the output of Step 1.

E3932 Cmd Rej: GFLEX, INP, GPORT, VFLEX feat must be ON or IDPR/ATINP/TIF enabled

Commands Used: `ent-trace`

The G-Flex, G-Port, INP, or V-Flex feature must be turned on, or the IDPR, ATINP, or any TIF feature must be enabled before the `entityid` parameter can be specified.

Recovery

1. Display the status of the features in the system. Enter the `rtrv-feat` and the `rtrv-ctrl-feat` commands.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the desired feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3934 Cmd Rej: CPCx must not be ANSI if CPCTYPE is INP or EIR

Commands Used: `chg-sid`

You specified the `cpctype=inp` or `cpctype=eir` parameter with an ANSI point code. This action is not allowed.

Recovery

Re-enter the `chg-sid` command that generated this error message, but this time do one of the following actions:

- Specify a value other than `inp` or `eir` for the `cpctype` parameter.

OR

- Specify `cpcn/ncpcn/ncpcn24` or `cpci/ncpci` for the point code.

E3935 Cmd Rej: DRANP and DRANPV must not be specified together

Commands Used: `chg-inpopts`, `chg-vflx-opts`, `rtrv-inpopts`

You cannot specify both the `dranp` and `dranpv` parameters.

Recovery

Re-enter the command specifying either the `dranp` or the `dranpv` parameter, but not both.

E3936 Cmd Rej: DRANAI and DRANAIV must not be specified together

Commands Used: `chg-inpopts`, `chg-vflx-opts`, `rtrv-inpopts`

You cannot specify the `dranai` and `dranaiv` parameters together in the same command.

Recovery

Re-enter the command specifying either the `dranai` or `dranaiv` parameter, but not both.

E3937 Cmd Rej: Entry already exists with specified GTI-TT-NP(V)-NAI(V)-SSN

Commands Used: `ent-srvsel`

You cannot specify a value that matches an existing `gti`, `tt`, `nai(v)`, `np(v)`, and `ssn` parameter combination.

Recovery

1. Display the existing values for the above parameters.
Enter the `rtrv-srvsel` command.
2. Re-enter the `ent-srvsel` command specifying values that do not already exist in the database for the above parameters.

E3938 Cmd Rej: Entry does not exist with specified GTI-TT-NP(V)-NAI(V)-SSN

Commands Used: `chg-srvsel`, `dlt-srvsel`

An entry must already exist that exactly matches the `gti/gtii/gtin/stin24`, `tt`, `ssn`, `np(v)`, and `nai(v)` combination of parameters.

Recovery

1. Display the service selectors.
Enter the `rtrv-srvsel` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3939 Cmd Rej: (N)SNP must be E164 when NSERV=INPMR

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If the value specified for the `nserv` parameter is `inpmr`, `smsmr`, or `gport` the `nsnp=E164` parameter must be specified.

Recovery

Re-enter the command specifying the `nserv=inpmr` parameter and either the `nsnp=e164` or `snp=e164` parameter.

E3940 Cmd Rej: (N)SERV value is invalid for the specified (N)SNAI

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If the value specified for the `snai` parameter is `rnidn`, `rnsdn`, or `rnsdn`, then the value specified for the `serv` parameter must be `inpmr`, `gport`, or `smsmr`.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a valid value for the `nserv/serv` parameter. (Note that the `nsnai/snai` parameter may not be specified if you specify `serv=inpq`).
- OR
- Re-enter the command that generated this error message specifying some other value for the `nsnai/snai` parameter.

E3941 Cmd Rej: GTII must not be specified when (N)SERV = INPQ

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

The `gtii` parameter cannot be specified if the `nserv/serv=inpq` parameter is specified.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying either the `gti`, `gtia`, or `gtin` parameter and the `nserv/serv=inpq` parameter.

OR

- Re-enter the command that generated this error message without specifying the value **inpq** for the **nserv/serv** parameter.

E3942 Cmd Rej: GTI/GTIA is invalid for specified (N)SERV

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If the **nserv** parameter has a value of **inpmr**, **inpq**, **gport**, or **eir**, then the **gtia** and **gti** parameters cannot be specified.

If the MO-based IS41 SMS NP, MO-based GSM SMS NP, or MO SMS IS41-to-GSM Migration feature is enabled, and the **serv=smsmr** parameter is specified, then the **gtia** and **gti** parameters can be specified.

Recovery

1. Re-enter the command, and specify a valid combination of parameters. Refer to the command description in the *Commands Manual* for assistance.
2. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3943 Cmd Rej: SNP/SNAI mustn't be specified for requested service

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If the value specified for the **nserv** or **serv** parameter is **atinp**, **eir**, **idpr**, **inpq**, **ttr**, or **vflex**, then the **snp**, **snai**, **nsnai**, and **nsnp** parameters cannot be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* and to the appropriate Feature Manual for assistance.

E3944 Cmd Rej: SNAI & SNP must be specified for requested service

Commands Used: `chg-srvsel`, `ent-srvsel`

If the value specified for the **serv** parameter is **gflex**, **gport**, **inpmr**, or **smsmr**, then the **snai** and **snp** parameters must be specified.

Recovery

Perform one of the following corrections:

- Re-enter the `ent-srvsel` command specifying the **snp** and **snai** parameters.

OR

- Re-enter the `ent-srvsel` command specifying a valid value for the **serv** parameter.

E3945 Cmd Rej: SERV must not be GFLEX when SNAI = RNIDN/RNNDN/RNSDN

Commands Used: `rtrv-srvsel`

You specified the `serv=gflex` parameter with one of the following values for the `snai` parameter: `rnidn`, `rnndn`, or `rnsdn`. This parameter combination is not allowed.

Recovery

Perform one of the following actions:

- Re-enter the `rtrv-srvsel` command specifying a value other than `gflex` for the `serv` parameter.
OR
- Re-enter the `rtrv-srvsel` command specifying a value other than `rnidn`, `rnndn`, or `rnsdn` for the `snai` parameter.

E3946 Cmd Rej: Entry already exists with specified GTII-TT-NP(V)-NAI(V)-SSN

Commands Used: `ent-srvsel`

You cannot specify an entry that matches an existing `gti`, `gtii`, `gtin`, `gtin24`, `tt`, `np(v)`, `nai(v)` and `ssn` parameter combination.

Recovery

1. Display the existing values for the above parameters.
Enter the `rtrv-srvsel` command.
2. Re-enter the `ent-srvsel` command specifying values that do not already exist in the database for the above parameters.

E3947 Cmd Rej: Entry already exists with specified GTIN-TT-NP(V)-NAI(V)-SSN

Commands Used: `ent-srvsel`

You cannot specify a value for a parameter that matches the value of an existing `gti/gtii/gtin/gtin24`, `tt`, `np(v)`, `nai(v)`, and `ssn` parameter combination.

Recovery

1. Display the service selectors.
Enter the `rtrv-srvsel` command.

2. Re-enter the `ent-srvsel` command specifying values that do not already exist in the database for the above parameters.

E3948 Cmd Rej: Entry does not exist with specified GTII-TT-NP(V)-NAI(V)-SSN

Commands Used: `chg-srvsel`, `dlt-srvsel`

You specified an entry that does not match an existing `gtii`, `tt`, `np(v)` and `nai(v)`, and `ssn` parameter combination as required.

Recovery

1. Display the service selectors.
Enter the `rtrv-srvsel` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3949 Cmd Rej: Specified card cannot be the Active MASP

Commands Used: `act-flash`, `init-flash`, `alw-card`, `rst-card`, `inh-card`, `rmv-card`

You specified the card address for the Active MASP card in the `loc` parameter for the command. The card address in the command cannot be for the Active MASP

Recovery

Re-enter the command specifying a card address in the `loc` parameter that is not the Active MASP.

E3950 Cmd Rej: Standby MASP is inhibited

Commands Used: `chg-db`, Any command used to update a database

A command was entered to update the system database. The database cannot be updated because the standby MASP is inhibited.

For `chg-db`, the standby MASP must be in the Active state before the `chg-db` command can be entered.

Recovery

1. Enter the `alw-card` command to allow the MASP, and wait for the MASP to come to the in-service state.
2. Re-enter the command to update the database.

E3951 Cmd Rej: Entry does not exist with specified GTIN-TT-NP(V)-NAI(V)-SSN

Commands Used: `chg-srvsel`, `dlt-srvsel`

You specified an entry that does not match an existing `gtin`, `tt`, `np(v)` and `nai(v)`, and `ssn` parameter combination as required.

Recovery

1. Display the service selectors.
Enter the `rtrv-srvsel` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E3953 Cmd Rej: NSNAI and NSNP must be specified when NSERV = GFLEX

Commands Used: `chg-srvsel`

If the `nserv=gflex` parameter is specified, then the `nsnai=none` and `nsnp=none` parameters cannot be specified.

Recovery

1. Verify the `nserv=gflex` parameter is specified. Refer to the *Commands Manual* for assistance.
2. If the `nserv=gflex` parameter is specified, the `nsnai` and the `nsnp` parameters must be specified. Refer to the *Commands Manual* for assistance specifying the `nserv`, and `nsnp` parameters.
3. Re-enter the command specifying a parameter combination that exists in the database.

E3954 Cmd Rej: NSNAI must be specified when NSERV = INPMR

Commands Used: `chg-srvsel`

You cannot specify the `nserv=inpmr` parameter without specifying the `nsnai` parameter.

Recovery

Perform one of the following actions:

- Re-enter the `chg-srvsel` command that generated this error message specifying the `nsnai` parameter.
- OR
- Re-enter the `chg-srvsel` command that generated this error message specifying another value for the `nserv` parameter.

E3955 Cmd Rej: Invalid combination of parameters for a partial routing key

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified parameters that do not define a full routing key, and the specified parameter combination is invalid for a partial routing key.

The following types of partial routing keys are supported:

1. DPC-SI-OPC (ignore CIC) can be used as a partial match key for CIC- based traffic.
2. DPC-SI (ignore all other fields) can be used as a partial match key for CIC- based traffic or SCCP traffic.
3. DPC only (ignore all other fields) can be used as a partial match for any type of traffic.
4. SI only (ignore all other fields) can be used as a partial match for any type of traffic.

Recovery

Re-enter the command specifying a valid combination of parameters for a partial routing key, or with parameters for a full routing key.

E3957 Cmd Rej: When type=partial or default, specify attributes

Commands Used: `chg-appl-rtkey`

You specified the routing key **type** specified as **partial** or **default**, and you did not enter the attributes parameters **rcontext**, **pstncat**, **pstnid**, or **norm**.

Recovery

Re-enter the **chg-appl-rtkey** command specifying the routing key **type** of **partial** or **default**, and include the attributes parameters **rcontext**, **pstncat**, **pstnid**, or **norm**.

E3958 Cmd Rej: When type=partial or default, SPLIT/RESIZE are not supported

Commands Used: `chg-appl-rtkey`

You specified the routing key **type** specified as **partial** or **default**, and you specified the **split** parameter in the command. The **split** parameter cannot be specified when **type=partial** or **type=default**.

Recovery

Re-enter the **chg-appl-rtkey** command without specifying the **split** parameter, or re-enter the command without specifying the **type** parameter (the default value is **type=full**) and with parameters for a full routing key.

E3959 Cmd Rej: Invalid combination of parameters for a default routing key

Commands Used: `chg-appl-rtkey`, `rtrv-appl-rtkey`

The routing key type parameter was specified as **default**, and an invalid combination of parameters was entered for a default routing key.

When **type=default** is specified, only the **nsname** parameter or the attributes parameters **pstnid**, **pstncat**, and **norm** can be specified for the `chg-appl-rtkey` command.

Recovery

Re-enter the appropriate command specifying **type=default** and a valid combination of parameters for a default routing key.

E3961 Cmd Rej: PVN and PVNMASK must be specified together

Commands Used: `chg-netopts`

You entered a command without specifying both the **pvn** parameter and the **pvnmask** parameter. Both parameters must be specified together in the command.

Recovery

Re-enter the `chg-netopts` command specifying IP addresses in both the **pvn** and **pvnmask** parameters.

E3962 Cmd Rej: PVN and PVNMASK must not be the same

Commands Used: `chg-netopts`

You entered a command that specified or would result in the same IP address for the Private Virtual Network IP address and the Private Virtual Network submask IP address. The two addresses must not be the same in the system.

Recovery

1. Enter the `rtrv-netopts` command to display the PVN and PVNMASK IP addresses in the system. Verify the PVN and PVNMASK addresses that you specified in the command.
2. Re-enter the `chg-netopts` command specifying two different addresses in the **pvn** and **pvnmask** parameters.

E3964 Cmd Rej: TSCSYNC must be ON before E5IS can be ON

Commands Used: `chg-feat`

You tried to turn on the EAGLE 5 Integrated Monitoring Support feature before the Time Slot Counter Synchronization (TSC) feature has been turned on. The TSC feature must be turned on before the E5IS feature can be turned on (or at the same time the E5IS feature is turned on, in the same command—(chg-feat:e5is=on:tscsync=on).

Recovery

1. Display the features in the database. Enter the command `rtrv-feat`.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

2. If the TSC feature is not **on**, turn it on. Enter the `chg-feat:tscsync=on` command.
3. Re-enter the command `chg-feat:e5is=on` to turn on the E5IS feature.

E3965 Cmd Rej: Invalid PVN

Commands Used: `chg-netopts`

You entered a command that specified an invalid Private Virtual Network IP address in the **pvn** parameter.

Recovery

Re-enter the `chg-netopts` command specifying a valid Class B IP address for the **pvn** parameter.

Refer to the `chg-netopts` command description in the *Commands Manual*.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3966 Cmd Rej: Max number of STC cards per shelf is entered

Commands Used: `ent-card`

You tried to add a Signaling Transport Card (STC) to a shelf for the EAGLE 5 Integrated Monitoring Support feature. However, the specified shelf already contains the maximum three STC cards allowed in the system.

Recovery

1. Display the cards on the shelf.
Enter the `rtrv-card` command. The card type STC appears in the TYPE column for each STC card in the system. The card location appears in the CARD column; the first two digits of the location are the frame and shelf number where the card is installed.
2. If there are already three STC cards on the shelf, you cannot add another one to that shelf unless you remove one of the existing STC cards from the shelf.
3. If there are fewer than three STC cards on the shelf, re-enter the command to add the STC card to the shelf.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3967 Cmd Rej: E5IS must be ON

Commands Used: `chg-eisopts`, `chg-netopts`, `rtrv-eisopts`, `rtrv-netopts`

The EAGLE 5 Integrated Monitoring Support (E5IS) feature bit (see the `chg-feat` command) must be turned on before this command can be entered.

For the `chg-netopts` command, the E5IS feature bit must be turned on before this command can be specified.

Recovery

1. Display the features in the database. Enter the command `rtrv-feat`.
2. If the E5IS feature is off (**E5IS=off**), turn it on. Enter the `chg-feat:e5is=on` command. Refer to the *Commands Manual*.
3. When the E5IS feature is turned on, re-enter the command to enable, disable, or retrieve the current setting for the E5IS copy function.

E3968 Cmd Rej: Invalid hardware for E5IS COPY to be ON

Commands Used: `chg-eisopts`

You entered a command to enable the copy function for the EAGLE 5 Integrated Monitoring Support feature. The required hardware is not in the system for the command. The E5IS feature requires at least two STC cards in IS-NR state to be installed on at least one shelf in the system.

Recovery

1. Display the cards currently installed in the system. Enter the command `rtrv-card`. Locate any STC cards in the output.
2. Enter the `rept-stat-card` command specifying the **loc** parameter for each STC card located in Step 1. Verify that at least two STC cards are running the **eroute** application and are in the IS-NR state.
3. If the required hardware is installed, re-enter the `chg-eisopts` command.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3979 Cmd Rej: Read NETOPTS table failed

Commands Used: `chg-eisopts`, `chg-netopts`, `rtrv-eisopts`, `rtrv-netopts`

The NETOPTS table is corrupt or cannot be found.

The NETOPTS table must be accessible for the command to execute.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3987 Cmd Rej: GTT must be ON before GPORT can be ON

Commands Used: `chg-feat`, `chg-ctrl-feat`

You tried to turn on the GSM Mobile Number Portability (G-Port) feature, but the Global Title Translation (GTT) feature is off. The GTT feature must be turned on before you can turn on the G-Port feature.

Recovery

1. Display the status of the GTT feature.
Enter the `rtrv-feat` command.
2. If the GTT feature is on (**gtt=on** from the output of Step 1), enable and turn on the G-Port feature. Refer to the *G-Port Feature Manual* for instructions to turn on the G-Port feature.
3. If the GTT feature is off (**gtt=off** from the output of Step 1), turn the GTT feature bit on. Refer to the *Database Administration Global Title Translation Manual* for instructions to turn on the GTT feature bit.
4. Enable and turn on the G-Port feature.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3989 Cmd Rej: GPORT feature must be ON when (N)SERV=GPORT

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

The G-Port feature must be turned on before the `nserv=gport` parameter can be specified.

Recovery

1. Display the status of controlled features in the database. Enter the `rtrv-ctrl-feat` command.
If the feature is not displayed in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable and turn on the G-Port feature as necessary. Refer to the *Feature Manual - G-Port* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3990 Cmd Rej: (N)SNP must be E164 when (N)SERV=GPORT/PPSMS/MNPSMS

Commands Used: `chg-srvsel`, `ent-srvsel`

If the value specified for the `serv` parameter is `gport` or `smsmr`, then the `snp=e164` parameter must be specified.

Recovery

Re-enter the command specifying `nsnp/snp=164`.

E3991 Cmd Rej: GPORT feature must be ON

Commands Used: `chg-ctrl-feat`, `chg-gsmopts`, `chg-prefix`, `enable-ctrl-feat`

[Table 29: G-Port Dependencies](#) shows the relationship between the G-Port feature and various other features in the system.

Table 29: G-Port Dependencies

Command	G-Port feature must be turned on...
<code>chg-ctrl-feat</code>	before the MO-based GSM SMS NP or MT-Based GSM SMS NP feature can be turned on
<code>chg-gsmopts</code>	before the <code>migrpfx=multiple</code> parameter can be specified
<code>chg-prefix</code>	to provision a prefix for the GSM MAP SRI Redirect feature
<code>enable-ctrl-feat</code>	before the GSM MAP SRI Redirect for Serving HLR, ISUP NP with EPAP, MNP CRP, or PPSMS features can be enabled

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not displayed, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the G-Port feature as necessary. Refer to the *Feature Manual - G-Port* for assistance.
3. Re-enter the command that generated the error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E3992 Cmd Rej: SRFADDR, SRFNAI & SRFNP parameters must be entered together

Commands Used: `chg-gsmopts`

You entered one or two of the following parameters: `srfaddr`, `srfnai`, or `srfnp`. You must specify all three parameters.

Recovery

Re-enter the command specifying all three parameters: `srfaddr`, `srfnai`, and `srfnp`.

E3993 Cmd Rej: GTIA/GTI is invalid when (N)SERV=GPORT

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If the `serv=gport` parameter is specified, then the `gti/gtia` parameter cannot be specified.

Recovery

Re-enter the command specifying the `gtia` or `gti` parameter and the `nserv=gport` parameter.

E3994 Cmd Rej: (N)SERV must be GPORT/SMSMR when (N)SNAI=CCRNDN

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If the `nsnai=ccrndn` parameter is specified, then the value specified for the `nserv` parameter must be `gport` or `smsmr`.

Recovery

Re-enter the command that generated this error, specifying `gport`, `ppsms`, `mnpsms`, or `eir` for the `nserv/serv` parameter and `ccrndn` for the `nsnai/snai` parameter.

E3995 Cmd Rej: MSRNNAI and MSRNNP parameters must be entered together

Commands Used: `chg-gsmopts`

You entered one of the following parameters: `msrnnai` or `msrnnp`. If you specify one of the above parameters, you must specify both.

Recovery

Re-enter the command specifying both the `msrnnai` and `msrnnp` parameters.

E3997 Cmd Rej: GFLEX must be ON or GPORT/EIR/IGM/VFLEX/MO SMS feat enabled

Commands Used: `rtrv-gsmopts`

The G-Flex feature must be turned on or the EIR, G-Port, IGM, MO SMS ASD, MO SMS B-Party Routing, MO SMS GRN, MO SMS IS41-to-GSM Migration, MO-based GSM SMS NP, Prepaid SMS Intercept Ph1, or V-Flex feature must be enabled before this command can be entered.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-feat` command and the `rtrv-ctrl-feat` command.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled but is not turned on.

2. Enable and turn on the desired feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this message.

E3998 Cmd Rej: NSNAI must not be NONE for requested service

Commands Used: `chg-srvsel`

The `nserv` parameter must have a value of `atinp`, `eir`, `idpr`, `idps`, `inpq`, `ttr`, or `vflex` before the `nsnai=none` parameter can be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* and to the appropriate Feature Manual for assistance.

E3999 Cmd Rej: When type=full, DPC and SI must be specified

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`

If you specify a value of `full` for the routing key `type` parameter (`type=full`), you must also specify either the destination point code (`dpc`) parameter and/or the system indicator (`si`) parameter.

Recovery

Re-enter the command specifying either the `dpc` and/or the `si` parameters.

E4000 Cmd Rej: No data available to display

Commands Used: `rept-stat-ddb`

Audit data is available only if the execution of a periodic or manual DDB audit is complete (see the `aud-data` command).

Recovery

Use the `aud-data` command to start a manual DDB audit or wait for periodic DDB audit start. Refer to the *Commands Manual* for more information.

Re-enter the command that generated this error message.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4001 Cmd Rej: Group Code of DPCN and OPCN must match

Commands Used: `ent-appl-rtkey`

The group codes for the `dpcn` and `opcn` parameter values must match when you specify both parameters in the command.

A two-letter group code is required for ITU-N point codes and spare point codes (DPCN/OPCN) when the ITU Duplicate Point Code feature (ITUDUPPC) is turned on, and not allowed when the feature is turned off.

Recovery

Re-enter the `ent-appl-rtkey` command specifying the same group codes for the `dpcn` and `opcn` parameter values.

E4002 Cmd Rej: PSTNCAT=0 requires PSTNID=0

Commands Used: `chg-appl-rtkey`

You cannot specify a value of `0` for the Public Switched Telephone Network (PSTN) Category (`pstncat=0`) and a value other than `0` for the `pstnid` parameter. The parameter value `pstncat=0` requires the parameter value `pstnid=0`.

Recovery

Re-enter the `chg-appl-rtkey` command specifying both the `pstncat=0` and the `pstnid=0` parameters.

E4003 Cmd Rej: MULTGC=YES requires IPGS-M2PA, IPGWI or IPLIMI links

Commands Used: `chg-ls`, `ent-slk`

If the `multgc=yes` parameter is specified, then all links assigned to the linkset must be of the same type.

Recovery

Re-enter the command specifying **multgc=yes** and a IPSP-M2PA, IPGWI or IPLIMI links.

E4004 Cmd Rej: PSTNCAT=1 requires ITU-I or ITU-N point code

Commands Used: `chg-appl-rtkey`

If you specify a value of **1** for the Public Switched Telephone Network (PSTN) Category parameter (**pstncat=1**), you must specify an ITU-I or ITU-N point code.

The parameter value **pstncat=1** can be used only with routing keys that specify ITU-N or ITU-I point codes. The **pstnid** parameter values used with **pstncat=1** must meet specific SI value criteria.

Refer to the `chg-appl-rtkey` description in the *Commands Manual* for valid parameter values when **pstncat=1** is specified in the command.

Recovery

Re-enter the `chg-appl-rtkey` command specifying the **pstncat=1** parameter and an ITU-I or ITU-N point code.

E4005 Cmd Rej: Either INP/AINPQ/GPORT must be ON or TINP must be enabled

Commands Used: `chg-measopts`, `dlt-homern`, `ent-homern`, `rept-ftp-meas`, `rept-meas`, `rtrv-homern`

The G-Port, INP, A-Port, or IS41 GSM Migration feature must be turned on before the **entity=np** parameter can be specified. [Table 30: Conditions that Generate an Error Message E4005](#) shows the reasons that this error message is generated.

Table 30: Conditions that Generate an Error Message E4005

Commands	Condition
<code>chg-measopts</code>	The INP or G-Port feature must be turned on before the enttype=np:type=mtch parameter can be specified. The INP, AINPQ, G-Port, A-Port, or IGM feature must be turned on before the mtchnp=on or the mtcdnp=on parameter can be specified.
<code>dlt-homern</code> , <code>ent-homern</code> , <code>rtrv-homern</code>	The INP or G-Port feature must be turned on before these commands can be specified.
<code>rept-ftp-meas</code>	The INP, AINPQ, G-Port, A-Port or IGM feature must be turned on before the mtchnp=on ,

Commands	Condition
	mtcdnp=on , or enttype=np parameter can be specified.
rept-meas	The INP, AINPQ, G-Port, A-Port, or IGM feature must be turned on before the entity=np parameter can be specified.

Recovery

1. Display the status of controlled features features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not displayed then the feature is not enabled. If the feature has a status of OFF then the feature is enabled but is not turned on.
2. Enable and turn on the features as necessary. If the INP, G-Port, A-Port, or IGM feature is turned off, turn on the INP, G-Port, A-Port, or IGM feature as applicable. Refer to the Commands Manual and to the feature manual for the feature of interest for assistance.
3. Re-enter the command that generated this message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4007 Cmd Rej: Exceeding max GTA Lengths supported per TT

Commands Used: `ent-gtt`

If the VGTT feature is turned on, then up to 10 GTA lengths can exist per translation type. If the Support for 16 GTT Lengths in VGTT feature is turned on, then up to 16 GTA lengths can exist per translation type.

Recovery

1. Display all GTAs for the specified translation type.
Enter the `rtrv-gtt` command.
2. Delete additional GTAs over the allowed length.
Enter the `dlt-gtt` command.
3. Re-enter the command that generated this error message.

E4008 Cmd Rej: Exceeding max GTA Lengths supported per GTTSET

Commands Used: `ent-gta`

If the VGTT feature is turned on, then up to 10 GTA lengths can exist per GTT set. If the Support for 16 GTT Lengths in VGTT feature is turned on, then up to 16 GTA lengths can exist per GTT set.

You attempted to add an entry that would have exceeded this maximum.

Recovery

1. Display all GTAs for the specified GTT set.
Enter the `rtrv-gta` command.
2. Delete all of the GTAs of a particular length.
Enter the `dlt-gtt` command.
3. Re-enter the `ent-gta` command.

E4009 Cmd Rej: GTA length is not defined for TT

Commands Used: `chg-gtt`, `dlt-gtt`, `rtrv-gtt`

You attempted to change, delete, or retrieve a GTA length that has not been defined for the specified translation type.

Recovery

1. Display all of the GTA lengths for the translation type.
Enter the `rtrv-tt` command.
2. Re-enter the command that generated this error message specifying an existing GTA length.

E4010 Cmd Rej: GTA length is not defined for GTTSET

Commands Used: `chg-gta`, `dlt-gta`, `rtrv-gta`

You cannot change, delete, or retrieve a GTA length that has not been defined for the specified GTT set.

Recovery

1. Display all of the GTA lengths for the translation type.
Enter the `rtrv-gta` command.
2. Re-enter the command that generated this error message specifying an existing GTA length.

E4011 Cmd Rej: NDGT parameter is invalid for VGTT

Commands Used: `chg-gttset`, `ent-gttset`, `ent-tt`

You cannot specify the number of digits (**ndgt**) parameter if the Variable length GTT (VGTT) feature is turned on.

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the **ndgt** parameter.
- OR
- Enter the `ent-gta` or `ent-gtt` command to provision up to **10** different GTA lengths per GTT set.

E4012 Cmd Rej: Invalid PVNMASK

Commands Used: `chg-netopts`

The IP address specified by the Private Virtual Network subnet mask (**pvnmask**) parameter is invalid. The value must be valid for a Class B network IP address. [Table 31: PVN Subnet Mask Values](#) describes valid values for the **pvnmask** parameter.

Table 31: PVN Subnet Mask Values

Valid for Class B Networks	
255.255.0.0	255.255.248.0
255.255.192.0	255.255.252.0
255.255.224.0	255.255.254.0
255.255.240.0	255.255.255.128

Recovery

Re-enter the `chg-netopts` command specifying a valid **pvnmask** parameter value.

E4013 Cmd Rej: T1 Port test command not in progress

Commands Used: `tst-t1`

There is no active test in progress on this t1port. The parameter **action=stop** cannot be performed if there is no active port test.

Recovery

Re-enter the `tst-t1` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `tst-t1` command.

E4014 Cmd Rej: CGSR must be specified when CDSR is specified

Commands Used: `rtrv-gsmmap-scrn`

For the `rtrv-gsmmap-scrn` command, if you specify the `cdsr` parameter, you must also specify the `cgssr` parameter.

Recovery

Re-enter the `rtrv-gsmmap-scrn` command specifying both the `cdsr` and the `cgssr` parameters.

E4015 Cmd Rej: CGSR or CDSR shouldn't be specified when SADDR is specified

Commands Used: `rtrv-gsmmap-scrn`

For the `rtrv-gsmmap-scrn` command, if you specify the `saddr` parameter, the `cgssr` or `cdsr` parameters cannot be specified.

Recovery

Re-enter the `rtrv-gsmmap-scrn` command specifying the `saddr` parameter, without specifying the `cgssr` or `cdsr` parameters.

E4016 Cmd Rej: SADDR, NPV and NAIV must be specified together

Commands Used: `rtrv-gsmmap-scrn`

For the `rtrv-gsmmap-scrn` command, the `saddr`, `npv`, and `naiv` parameters must be specified together.

Recovery

Re-enter the `rtrv-gsmmap-scrn` command specifying the `saddr`, `npv`, and `naiv` parameters together.

E4017 Cmd Rej: ACTION or FORBID parameter shouldn't be specified

Commands Used: `rtrv-gsmmap-scrn`

When any of the `saddr`/`eaddr`/`npv`/`naiv` and `cdsr` parameters are specified, the `forbid` and `action` parameters cannot be specified.

You cannot specify the `action` or `forbid` parameters whenever any of the following are specified:

- The combination of `saddr` (with or without `eaddr`), `npv`, and `naiv` parameters.

OR

- The **cdsr** parameter.

Recovery

Perform one of the following actions:

- Re-enter the **rtrv-gsmmap-scrn** command without specifying the **action** or **forbid** parameters
OR
- Re-enter the **rtrv-gsmmap-scrn** command specifying the **action** or **forbid** parameters, but do not include either the **cdsr** parameter or the combination of **saddr** (with or without **eaddr**), **npv**, and **naiv** parameters.

E4019 Cmd Rej: OPCODE and OPNAME shouldn't be specified together

Commands Used: `rtrv-gsms-opcode`

You cannot specify the MAP Op-code Number (**opcode**) and User-defined Name for Op-code (**opname**) together in this same command. These two parameters are mutually exclusive.

Recovery

Re-enter the `rtrv-gsms-opcode` command specifying either the **opcode** or the **opname** parameter, but not both.

E4024 Cmd Rej: SRCSET and SET cannot be equal

Commands Used: `chg-uaps`

Your attempt to change the UAPS parameter set was unsuccessful because the specified set number and source set parameters were identical. The **set** parameter and the **srcset** parameter cannot be the same value.

Recovery

Review the **set** and **srcset** parameters, and change the specification of the appropriate one. Re-enter the `chg-uaps` command specifying the correct parameter values.

E4026 Cmd Rej: STP options HMUXABUS or HMUXBBUS must be set=yes

Commands Used: `clr-imt-stats`, `rept-imt-info`, `init-mux`

The command you entered cannot be executed due to a possible error in the STP Options table.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4027 Cmd Rej: S/ESHELF parameters are invalid with specified report type

Commands Used: `rept-int-info`

A value of **hmuxerr**, **hiprerr**, or **hipr2err** must be specified for the **report** parameter before the **sshelf** and **eshelf** parameters can be specified.

Recovery

Re-enter the command specifying valid values for the parameters. Refer to the *Commands Manual* for assistance.

E4032 Cmd Rej: Either BUS or Location (not both) must be specified

Commands Used: `init-mux`

The **bus** or **loc** parameter must also be specified.

Recovery

Re-enter the `init-mux` command specifying either the **bus** or **loc** parameter, but not both.

E4033 Cmd Rej: If GTIXLAT is 22, NAI and NP cannot be specified

Commands Used: `ent-gtcnv`

If you specify a value of **22** for the ANSI Global Title Indicator (**gtixlat=22**), the Nature of Address Indicator (**nai**) and Numbering Plan (**np**) parameters cannot be specified.

Recovery

Perform one of the following actions:

- Re-enter the `ent-gtcnv` command specifying the (**nai**) and (**np**) parameters, and a value other than 22 for the (**gtixlat**) parameter.

OR

- Re-enter the `ent-gtcnv` command specifying **gtixlat=22** without specifying the **nai** and **np** parameters.

E4034 Cmd Rej: If GTIXLAT is 24, NAI and NP must be specified

Commands Used: `ent-gtcnv`

If you specify a value of **24** for the ITU Global Title Indicator (**gtixlat=24**), the Nature of Address Indicator (**nai**) and Numbering Plan (**np**) parameters must also be specified.

Recovery

Perform one of the following actions:

- Re-enter the `ent-gtcnv` command specifying **gtixlat=24** and the **nai** and **np** parameters.
OR
- Re-enter the `ent-gtcnv` command specifying a value other than **24** for the (**gtixlat**) parameter.

E4035 Cmd Rej: TTA must be specified for a direction of ATOI

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

If you specify that the direction of conversion is ANSI-to-ITU (**dir=atoi**), the ANSI translation type (**tta**) parameter must be specified.

Recovery

Re-enter the command specifying **dir=atoi** and the **tta** parameter. i.e., `chg-gtcnv:dir=atoi:tta=xxx`

E4036 Cmd Rej: At least TTA, TTI must be specified for a direction of BOTH

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

If you specify that the direction of conversion is BOTH (**dir=both**), the ANSI translation type (**tta**) and the ITU translation type (**tti**) parameters must also be specified.

Recovery

Re-enter the command specifying **dir=both** and the **tta** and **tti** parameters. i.e., `chg-gtcnv:dir=both:tta=xxx:tti=yyy`

E4037 Cmd Rej: Error in FEATCTRL.TBL date, maintenance required

Commands Used: `enable-ctrl-feat`

The contents of the FEATCTRL.TBL is in violation of its stable condition rules. The table content requires maintenance.

Recovery

Perform maintenance on the FEATCTRL database table. Perform a database backup after every successful `enable-ctrl-feat` command.

E4039 Cmd Rej: MULTGC=YES not allowed if ITUDUPPC feature is OFF

Commands Used: `chg-ls`, `ent-ls`

You cannot specify a value of yes for the Multiple Group Codes Allowed (**multgc=yes**) parameter if the International National Duplicate Point Code (ITUDUPPC) feature is turned off. Multiple group codes are not supported if the ITUDUPPC feature is turned off.

Recovery

1. Verify that the ITUDUPPC feature is turned off.
Enter the `rtrv-feat` command.
2. Re-enter the command without specifying a value of **yes** for the multiple group code (**multgc**) parameter.

E4041 Cmd Rej: Cannot change routing key and attribute values

Commands Used: `chg-appl-rtkey`

You entered a command that specified values for both routing key parameters and routing key attribute parameters.

The key attribute parameters (**pstncat**, **pstnid**, and **norm**) are not valid with routing key parameters **ncics**, **ncice**, **split**, **nsname**, or **nasname**.

Recovery

Re-enter the command and specify only valid routing key parameters or only valid key attribute parameters.

E4042 Cmd Rej: ISUP Normalization feature must be enabled to set NORM=YES

Commands Used: `chg-appl-rtkey`

This feature requires the ISUP Normalization ON/OFF controlled feature as well as a separate ON/OFF controlled feature for each ISUP variant that can be normalized.

Recovery

You must first purchase the ISUP Normalization feature, then enable using the `enable-ctrl-feat` command.

E4044 Cmd Rej: Only two E1/T1 ports allowed for Linkclass=Unchan

Commands Used: `chg-e1`, `ent-e1`, `ent-t1`

Only 2 of the 8 ports can be used for T1 interfaces on an HC-MIM card that is used as an ST-HSL-A card.

Only 2 ports can be used for E1 interfaces on an HC-MIM card that is used as an SE-HSL card.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4045 Cmd Rej: Linkset with MULTGC=YES requires IPGWI/IPLIMI/IPSG GPL

Commands Used: `ent-slk`

The card application must be `ipgwi`, `ipsg`, or `iplimi` if the `lsn` parameter references a linkset that specifies `multgc=yes`.

Recovery

Re-enter the `ent-slk` command and reference a link set with a card application of `ipgwi`, `ipsg`, or `iplimi`.

E4046 Cmd Rej: E1 is assigned to card

Commands Used: `dlt-card`

Before you can delete a 2-port E1 card or an E1/T1 MIM card that is being used as an E1 card (card type `lime1` that has an E1 interface associated with it), you must first delete all E1 interfaces associated with the card.

Recovery

1. Display a list of signaling links assigned to the E1 card.
Enter the `rtrv-slk` command.
2. Deactivate all signaling links assigned to the E1 card.
Enter the `dact-slk` command for each link.
3. Delete all signaling links assigned to the E1 card.
Enter the `dlt-slk` command for each link.
4. Display the E1 interfaces associated with the E1 cards.
Enter the `rtrv-e1` command.

5. Delete all E1 interfaces associated with the E1 card.
Enter the `dlt-e1` command.
6. Delete the E1 card.
Re-enter the `dlt-card` command.

E4047 Cmd Rej: Signaling link is not provisioned for the card

Commands Used: `alw-card`

You cannot allow a 2-port E1 card or Channel card or an E1/T1 MIM card used as an E1 card, T1 card, or Channel card (card type `lime1`, `limt1`, or `limch`) that has no signaling links associated with it. At least one signaling link must be associated with the card before the card can be allowed.

Recovery

1. Associate at least one signaling link with the card.
Enter the `ent-slk` command. Refer to the *Commands Manual* for detailed information about the use of the `ent-slk` command.
2. Allow the card.
Re-enter the `alw-card` command.

E4048 Cmd Rej: All signaling links serviced by the E1 must be deactivated

Commands Used: `chg-e1`, `inh-card`, `tst-e1`

If the value specified for the `loc` parameter indicates an E1 card, then all signaling links that are serviced by the card must be deactivated (see the `dlt-slk` command) before the values for the `crc4`, `cas`, `encode`, and `e1tsel` parameters can be changed.

All signaling links that provide timeslots serviced by E1 interfaces on the specified card (`loc` parameter) must be deactivated before this command can be entered. None of the signaling links can be running link diagnostic tests (`tst-slk` and `act-cdl`) when this command is entered.

Recovery

1. Deactivate all signaling links with timeslots that are serviced by the specified E1 card.
Enter the `dact-slk` command.
2. Re-enter the command to change the specified parameter value or inhibit the card.

E4049 Cmd Rej: Card type of LIMCH does not support E1PORT = 2

Commands Used: `ent-slk`

If an E1/T1 MIM card is used as an E1 channel card, then the `e1port=1` parameter must be specified.

Recovery

Re-enter the `ent-slk` command and specify the **e1port=1** parameter.

E4050 Cmd Rej: E1PORT specified by E1LOC is not equipped

Commands Used: `ent-slk`

The E1 interface for the E1 port specified by **e1loc** parameter must already be defined (see the `ent-e1` command) before a signaling link can be assigned to the card.

Recovery

1. Display the E1 port and card location information. Enter the `rtrv-e1` command.
2. Verify that the **e1loc** parameter specifies the correct card location.
 - a) If the E1 interface is defined for the specified **e1port** on the E1 card at the specified location, re-enter the `ent-slk` command specifying the correct card location (**e1loc**) and **e1port** (**e1port**).
 - b) If the E1 interface has not been defined for the specified port on the E1 card at the specified location, perform the following actions:
 - Define the E1 attributes for the specified **e1port** on the E1 card in the location specified by the **e1loc** parameter. Enter the `ent-e1` command.
 - Re-enter the `ent-slk` command and specify the defined **e1port**.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4051 Cmd Rej: TS value on the E1 already in use by a signaling link

Commands Used: `ent-slk`

The value specified for the **ts** parameter cannot already be in use by the E1 card.

Recovery

1. Display the E1 port, card location, and timeslot information.
Enter the `rtrv-e1` command.
2. Re-enter the `ent-slk` command specifying an available timeslot for the E1 card and interface specified in the **e1port** and **e1loc** parameters.

E4052 Cmd Rej: E1 specified by E1LOC/E1PORT is using CAS, TS=16 not allowed

Commands Used: `ent-slk`

You specified a timeslot value of **16** for an E1 interface that has Channel Associated Signaling (CAS) enabled. When CAS is enabled for an E1 interface, you cannot assign timeslot **16** to that E1 interface.

Recovery

1. Display the E1 port, card location, and timeslot information.
Enter the `rtrv-e1` command.
2. Re-enter the `ent-slk` command specifying an available timeslot other than **16** for the E1 interface and card specified by the **e1port** and **e1loc** parameters.

E4054 Cmd Rej: The E1PORT at the specified location is already equipped

Commands Used: `ent-e1`

You cannot add an E1 interface to the database if the **e1port** on the E1 card (**e1port** = 1 or 2) already has an E1 interface defined on that E1 card in the specified location.

Recovery

1. Display the E1 port and card location information.
Enter the `rtrv-e1` command.
2. Perform one of the following actions:
 - a) If an **e1port** is available at the specified location, re-enter the `ent-e1` command specifying the available **e1port**.
OR
 - b) If no **e1port** is available at the specified card location, re-enter the `ent-e1` command specifying an available E1 card location and port number.

E4055 Cmd Rej: The E1PORT at the specified location is not equipped

Commands Used: `chg-e1`, `dlt-e1`, `ent-slk`, `rtrv-e1`

The E1 interface for the card at the location specified by the **loc** parameter must be defined (see the `ent-e1` command) before a signaling link can be assigned to the port.

For `rtrv-e1`, an E1 interface must already be defined on the port specified by the **e1port** parameter before this command can be entered.

Recovery `chg-e1`, `dlt-e1`, `rtrv-e1`

1. Display all **e1port** and **loc** parameter information. Enter the `rtrv-e1` command specifying no parameters.
Verify that you specified the correct **e1port** and **loc** parameters.
2. If the specified **e1port** or **loc** are incorrect, re-enter the command specifying the correct **e1port** and **loc** parameters.
3. If the specified **e1port** or **loc** was correct, re-enter the command.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery ent-slk

1. Display all E1 port and E1 card location information.
Enter the `rtrv-e1` command specifying no parameters. Verify that you specified the correct **e1port** parameter and the correct E1 card location (**loc**) parameter for the command.
2. If the specified E1 card location (**loc**) is correct but not listed, you must equip the specified card location with an appropriate card.
3. Re-enter the `ent-slk` command.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4056 Cmd Rej: Timeslot 16 on the E1 is in use, CAS = ON not allowed

Commands Used: `chg-e1`

You cannot change from Common Channel Signaling (CCS) to Channel Associated Signaling (CAS) multi-framing for the E1 interface on the specified E1 port and card. CAS cannot be enabled because timeslot 16 is being used by the E1 interface.

Recovery

1. Display the E1 port, card location, and timeslot information.
Enter the `rtrv-e1` command.
2. If you need to correct any part of the command information, re-enter the `chg-e1` command specifying the correct information.
3. If you need to change the **cas** parameter value, you must first delete timeslot 16 from the E1 interface before you enter the command again.
 - a) Display the signaling link information for the E1 card, including the timeslot used by each link.
Enter the `rtrv-slk` command.
 - b) Delete the signaling link that has timeslot 16 assigned.
Enter the `dlt-slk` command.
 - c) Add a new signaling link for the E1 interface with a timeslot other than 16.
Enter the `ent-slk` command.
 - d) Re-enter the `chg-e1` command specifying **cas=on**.

E4057 Cmd Rej: All signaling links serviced by this E1/T1 must be deleted

Commands Used: `dlt-e1`, `dlt-t1`

You entered a command to delete an E1 interface or a T1 interface before you deleted all signaling links that are serviced by that E1 interface or T1 interface.

Recovery

1. Display the signaling links assigned to the E1 or T1 interface.
Enter the `rtrv-slk` command.
2. If the links have not already been deactivated, deactivate all of the signaling links assigned to the E1 or T1 interface.
Enter the `dact-slk` command.
3. Delete all of the signaling links assigned to the E1 or T1 interface.
Enter the `dlt-slk` command.
4. Delete the E1 or T1 interface.
Re-enter the `dlt-e1` or `dlt-t1` command.

E4058 Cmd Rej: The Channel card must be on the same shelf as its E1 card

Commands Used: `ent-slk`

If the value specified for the `loc` parameter indicates a Channel card, then the Channel card must be installed on the same shelf as the E1 card that is specified by the `e1loc` parameter.

Recovery

Re-enter the `ent-slk` command specifying an E1 interface on an E1 card that is on the same shelf with the Channel card.

E4059 Cmd Rej: Failed reading the E1/T1 table

Commands Used: `chg-e1`, `chg-t1`, `dlt-card`, `dlt-e1`, `dlt-t1`, `ent-e1`, `ent-slk`, `ent-t1`, `rtrv-e1`, `rtrv-t1`

The E1/T1 table is corrupt or cannot be found.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4060 Cmd Rej: MULTGC=YES requires ITU-N or ITU-I point code

Commands Used: `chg-ls`, `ent-ls`

You must specify an ITU-N or ITU-I point code if `multgc=yes` is specified.

Recovery

Re-enter the command specifying **multgc=yes** and either a ITU-N or ITU-I point code.

E4061 Cmd Rej: Group Code of DPC(s) and APC/SAPC must match when MULTGC=NO

Commands Used: `chg-ls`

The group codes for the DPC(s) and APC/SAPC must match when entering this command specifying **multgc=no**. MULTGC can only be changed to NO if there are no routes with group codes different than the ADJPC's group code. If the ADJPC's group code is changed, MULTGC must be YES or there must be no routes using the linkset.

Recovery

Enter the `chg-ls` command to update **apc/sapc** group code.

E4062 Cmd Rej: Inhibit IPSM card(s) before changing feature status

Commands Used: `chg-ctrl-feat`

You must first inhibit all IPSM cards in the system before the EAGLE OA&M IP Security Enhancements feature can be turned on or off.

Recovery

1. Determine which Telnet terminals are on the IPSM card(s).
Enter the `rtrv-trm` command.
2. Inhibit all Telnet terminals if the Telnet feature is on.
Enter the `inh-trm` command.
3. Inhibit all IPSM cards in the system.
Enter the `inh-card` command.
4. Turn the Eagle OA&M IP Security feature on or off.
Re-enter the `chg-ctrl-feat` command.
5. Allow all IPSM cards in the system.
Enter the `alw-card` command.
6. Allow all Telnet terminals.
Enter the `alw-trm` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4063 Cmd Rej: GTI/GTIA/GTII/GTIN not within specified range of 1 to 4

Commands Used: `chg-gttsel`, `chg-srvsel`, `dlt-gttsel`, `dlt-srvsel`, `ent-gttsel`, `ent-srvsel`, `rtrv-gttsel`, `rtrv-srvsel`

You cannot specify a value for the `gti`, `gtia`, `gtii`, or `gtin` parameter that is outside the range of 1 to 4. Supported values for ANSI are `gti=2` and `gtia=2`. Supported values for ITU are `gtii=2, 4` and `gtin=2, 4`.

Recovery

Re-enter the command specifying a valid value for the `gti`, `gtia`, `gtii`, or `gtin` parameter.

E4064 Cmd Rej: Host Name Referenced by Application Socket or Association

Commands Used: `dlt-ip-host`

Before a local entry can be deleted from the IP Host table, all association references to the host name must be deleted. This rule does not apply to remote host entries.

Recovery

1. Enter the `rtrv-assoc` command specifying the host name to be deleted. Verify the associations that reference the host name.
2. Delete each referenced socket or association. Enter the `dlt-assoc` command.
Refer to the *Commands Manual* and to the *Database Administration Manual-IP7 Secure Gateway* for more information.
3. Delete the host name. Re-enter the `dlt-ip-host` command.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4065 Cmd Rej: Application Sockets on Port B Not Allowed

Commands Used: `chg-ip-lnk`

You cannot assign application socket to DCM card with IP connections on the B interface. The B interface is not supported on DCMs; however, it is supported on SSED CMs.

Recovery

1. Determine the associated IP address for the host name.
Enter the `rtrv-ip-host` command.

2. Determine the parameter values for **loc** and **port** associated with the IP address from the output of Step 1.
Enter the `rtrv-ip-lnk` command.
3. Re-enter the command that generated this message, using the host name associated with the A interface.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4066 Cmd Rej: Matching routing key already entered for AS

Commands Used: `ent-appl-rtkey`

The specified AS name (**asname**) parameter and routing key could not be added to the Routing Key table because an entry that matches the specified AS name and routing key already exists in the Routing Key table.

Recovery

1. Display the AS names and routing keys in the Routing Key table.
Enter the `rtrv-appl-rtkey` command. Verify that the AS name and routing key for your command are correct and unique.
2. Re-enter the `ent-appl-rtkey` command specifying the correct AS name and routing key.

E4067 Cmd Rej: Only ASNAME is allowed for default routing key

Commands Used: `ent-appl-rtkey`

If the **type=default** parameter is specified, then the **rcontext** parameter is the only optional parameter that can be specified.

Recovery

Re-enter the command specifying only the **type=default** parameter and the **rcontext** parameter.

E4068 Cmd Rej: Must specify ASNAME

Commands Used: `inh-alm`, `unhb-alm`

If the **dev=as** parameter is specified, then the **asname** parameter must be specified.

Recovery

Re-enter the command, and specify the **asname** parameter. Refer to the *Commands Manual* for assistance.

E4069 Cmd Rej: Entry already exists with specified GTIN24-TT-NP(V)-NAI(V)-SSN

Commands Used: `ent-srvsel`

You specified an entry that matches an existing `gtin24`, `tt`, `np/nai` or `npv/naiv`, and `ssn` parameter combination, which is not allowed.

Recovery

1. Display the existing values for the above parameters.
Enter the `rtv-srvsel` command.
2. Re-enter the command specifying values for the `gtin24`, `tt`, `np/nai` or `npv/naiv`, and `ssn` parameter combination that do not already exist in the database.

E4070 Cmd Rej: LNP is mutually exclusive with an existing feature

Commands Used: `enable-ctrl-feat`

A feature is enabled or turned on that is mutually exclusive with the LNP (an LNP ported TNs quantity), LNP 150,000 LRNs, or LNP 300,000 NPANXX feature. Refer to the command description in the *Commands Manual* for a list of features that are mutually exclusive with the LNP features.

Recovery

1. Display the status of controlled features in the system. Enter the `rtv-ctrl-feat` command for features that are enabled with a feature access key or the `rtv-feat` command for features that are turned on with a feature bit.
2. If the output from Step 1 does not show any of the mutually exclusive features or if they are **off**, re-enter the command. If the error message appears again call the Customer Care Center for assistance.
3. If the output from Step 1 shows any of the mutually exclusive features turned **on**, you will not be able to use the LNP (an LNP ported TN quantity), LNP 150,000 LRN, or LNP 300,000 NPANXX, or G-Flex features. Call the Customer Care Center for assistance.

E4073 Cmd Rej: AS/socket cannot be deleted while assigned to a routing key

Commands Used: `dlt-assoc`, `dlt-as`

You entered a command to delete an AS from the AS table, and the AS is still associated with a routing key. You must first delete the AS association with the routing key before you can delete the AS.

Recovery

1. Display the current AS and routing key associations.

- Enter the `rtrv-appl-rtkey` command.
2. Delete the AS association with the routing key.
Enter the `dlt-appl-rtkey` command.
 3. Re-enter the command to delete the AS.

E4075 Cmd Rej: Invalid name for adapter type

Commands Used: `chg-assoc`, `dlt-assoc`

The command specified a name that is invalid for the IP connection type. The command was rejected to prevent the erroneous change or deletion of a provisioned IP connection.

Recovery

1. Display the names of the IP connection.
Enter the `rtrv-assoc` command.
2. Re-enter the correct command for the IP connection to be specified.

E4076 Cmd Rej: E1 card location is unequipped

Commands Used: `chg-e1`, `dlt-e1`, `ent-e1`, `ent-slk`, `rtrv-e1`

The card in the location specified by the `loc` parameter must be equipped (defined in the database). The card location specified by the `e1loc` parameter must contain an HC-MIM, E5-E1T1, or E1/T1 MIM card that is used as an E1 card.

Recovery

1. Perform one of the following actions:
 - a) Enter the `rtrv-card` command specifying the location in the `loc` parameter of the E1 card to add the E1 interface.
 - b) Enter the `rtrv-e1` command specifying no parameters to display the card location information for the cards defined in the database.
Verify the card location for the card with the E1 interface to change, delete, or retrieve.
2. Re-enter the command specifying the correct card location in the `loc` parameter for the card on which to add, change, delete, or retrieve the E1 interface.

E4077 Cmd Rej: Parameters incompatible with adapter type

Commands Used: `,alw-slk`, `ent-assoc`, `inh-slk`, `tst-slk`, `unhb-slk`

Only sltc loopback link test type is supported by IPSP-M2PA signaling links.

If an IPSP-M3UA signaling link is used, then the `alw-slk`, `inh-slk`, `tst-slk`, and `unhb-slk` commands cannot be entered. For the `tst-slk` command, if an IPSP-M2PA signaling link is used, then the `loopback=sltc` parameter must be specified.

For the `ent-assoc` command, if the card is running an `iplim` or `iplimi` application, then an association with `adapter=sua` or `m3ua` cannot be assigned as a value for the `lhost` parameter.

Recovery - Signaling Link Commands

1. Determine the type of signaling link used. Enter the `rtrv-slk` command.
2. Refer to the *Commands Manual* for instructions on provisioning an adapter type. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance with provisioning signaling links.

Recovery - ent-assoc command

1. Determine the type of association used. Enter the `rtrv-assoc` command.
2. Refer to the *Commands Manual* for instructions on provisioning an adapter type. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance with provisioning associations.

E4078 Cmd Rej: Conflicting parameters specified

Commands Used: `chg-appl-rtley`, `dlt-appl-rtkey`, `ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified parameters that cannot be entered in the same command.

Recovery

Re-enter the command specifying a valid combination of parameters.

E4079 Cmd Rej: Specified AS name not found

Commands Used: `chg-as,,`, `chg-ctrl-feat`, `dlt-appl-rtkey`, `dlt-as`, `rept-stat-asrept-meas`, `rept-meas`

You entered a command to delete a routing key, delete an application server (AS), or display the status of an AS. The value specified for the AS name parameter (`asname`) does not exist in the AS table. The application server specified by the `asname` parameter must be provisioned in the system.

Recovery

1. Display the AS names that are currently in the AS table. Enter the `rtrv-as` command. Verify the AS name that you specified is in the AS table.
2. Re-enter the command specifying the correct AS name.

E4080 Cmd Rej: INP/AINPQ, GPORT, APORT or VFLEX feature must be on

Commands Used: `dlt-homern`, `ent-homern`

The A-Port, AINPQ, G-Port, INP, or V-Flex feature must be turned on before this command can be entered.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable and turn on least one of the required features. Refer to the *Commands Manual* and to the appropriate Feature Manual for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4081 Cmd Rej: Maximum number of connections already provisioned for AS

Commands Used: `ent-as`

You entered a command to add an M3UA/SUA association to an existing application server (AS). The AS already has the maximum of **16** associations (M3UA/SUA/M2PA IP connections).

Recovery

1. Display the associations with ASs in the AS table.
Enter the `rtrv-as` command.
2. To create another association with the AS, you must first delete an existing association from the AS.
Refer to the *Commands Manual* for detailed information about the use of the `dlr-as` command.
3. If you have deleted an existing association for the AS, re-enter the `ent-as` command to create an association with the AS.

E4083 Cmd Rej: Connection adapter type does not match AS adapter type

Commands Used: `ent-as`

You entered a command to add an M3UA/SUA association to an application server (AS), and the adapter type is not the same as the adapter type of one or more associations that have already been assigned to the AS.

Recovery

1. Enter the `rtrv-as` command to display the associations for the AS.
2. Enter the `rtrv-assoc` command to display the adapter type of the existing associations.

3. Re-enter the `ent-as` command to add an association with the same adapter type as one or more associations already assigned to the AS.

E4087 Cmd Rej: Both NPV and NAIV must be either * or numbers

Commands Used: `ent-gsmmap-scrn`

You specified inconsistent values for the `np` and `naiv` parameters. The values you specify for both of these parameters must be either `*` (wildcard notation) or numbers.

Recovery

Re-enter the `ent-gsmmap-scrn` command that generated this error message specifying either `*` or numbers for the `np` and `naiv` parameters.

E4089 Cmd Rej: Unable to change adapter when assigned to an AS

Commands Used: `chg-assoc`

You entered a command to change the adapter value (M3UA, SUA, or M2PA) for an association. The specified association is bound to an AS. You cannot change the adapter value when the association is bound to an AS.

Recovery

1. Display each AS and its current association.
Enter the `rtrv-as` command.
2. If you want to change the adapter value for the association, first delete the association name for the adapter you want to change.
Enter the `dlt-as` command specifying the association name parameter (`aname=`) of the association to delete.
3. Re-enter the `chg-assoc` command to change the adapter value for the desired association.

E4091 Cmd Rej: Association connection parameters must be unique

Commands Used: `chg-assoc`, `ent-assoc`

You entered a command to change one or more connection parameters for an association or to add an association to the IPAPSOCK table. The new association has exactly the same local host, local port, remote host, and remote port as an existing association in the table. No two associations can have exactly the same `lhost/lport/rhost/rport` parameter combination.

Recovery

1. Display the existing associations and their connection parameters.
Enter the `rtrv-assoc` command.

2. Re-enter the command specifying a connection parameter combination that is not exactly the same as for any existing association.

E4092 Cmd Rej: Too many associations per SLK

Commands Used: `chg-assoc`, `ent-slk`

The M3UA association (specified in `aname` parameter) has already reached its limit of 16 signaling links. Only one signaling link can be assigned to an M2PA association. The specified M2PA association (the `aname` parameter value) already has 1 signaling link assigned to it.

Recovery

1. Display the IP address of the IPLIM or IPLIMI card.
Enter the `rtrv-ip-lnk` command.
2. Display the host name for the card.
Enter the `rtrv-ip-host` command and specify the IP address (`ipaddr` parameter) from Step 1 for the card.
3. Display the associations on the card.
Enter the `rtrv-assoc` command and specify the host name (`lhost` parameter) from Step 2 for the card.
4. Re-enter the `chg-assoc` command specifying an available port to assign an association.

E4093 Cmd Rej: Too many associations per card

Commands Used: `chg-assoc`, `ent-assoc`

A maximum of 32 associations can be provisioned on a card running the `ipsg` application.

Note:

SSEDCM hardware allows **50** associations on an IPGWx card

Recovery

1. Display the associations in the IPAPSOCK table.
Enter the `rtrv-assoc` command.
2. Re-enter the command if the card allows another association.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4094 Cmd Rej: IPSM card has Critical Thermal Alarm

Commands Used: `alw-trm`

If a critical thermal alarm is raised against the E5-IPSM card hosting the terminal, then the specified Telnet terminal cannot be returned to the IS-NR state.

Recovery

1. Wait for the cards thermal temperature to subside below the thermal level, and the IPSM thermal alarm to clear.
2. Use the `alw-trm` command to allow the terminal to resume function. Refer to the *Commands Manual* for assistance using the `alw-trm` command if necessary.

E4096 Cmd Rej: Association name already exists

Commands Used: `ent-assoc`

The association name specified already exists in the IPAPSOCK table.

Recovery

1. Display the existing association names in the IPAPSOCK table.
Enter the `rtrv-assoc` command.
2. Re-enter the `ent-assoc` command specifying an association name that is not already in the IPAPSOCK table.

E4097 Cmd Rej: Cannot assign LHOST/ALHOST to the B interface

Commands Used: `ent-assoc`, `chg-assoc`

You tried to provision socket LHOST or association LHOST/ALHOST with a host name that is associated with the **B** interface. The **B** interface is not supported on DCMs; however, it is supported on SSED CMs.

Recovery

1. Determine the associated IP address for the host name.
Enter the `rtrv-ip-host` command.
2. Determine the parameter values for **loc** and **port** associated with the IP address from the output of Step 1.
Enter the `rtrv-ip-lnk` command.
3. Re-enter the command that generated this message, specifying the host name associated with the **A** interface.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4098 Cmd Rej: OPEN must be NO to change an Association or its AS/Rtkey

Commands Used: `chg-as`, `chg-assoc`, `dlt-appl-rtkey`, `dlt-as`, `dlt-assoc`, `ent-as`

The connection state of an association must be **open=no** before you can change the characteristics (**lhost**, **lport**, **rhost**, **rport**, **adapter**, **ver**, **istrms**, **ostrms**, **rmode**, **rmin**, **rmax**, **rtimes**, and **cwmin**) of an association, or delete the association.

OR

The connection state of the associations bound to the M3UA/SUA associations for the AS must be **open=no** before you can enter, change, or delete the AS.

Recovery - `chg-assoc`, `dlt-assoc`

1. Display the associations and their connection states. Enter the `rtrv-assoc` command. Verify the connection state of the specified association.
2. If the connection state for the specified association is **open=no**, re-enter the `chg-assoc` or `dlt-assoc` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. If the connection state for the specified association is **open=yes**, change the connection status to **open=no**. Perform the following actions:
 - Enter the `chg-assoc` command specifying the association name (**aname**) and the **open=no** parameter.
 - Re-enter the command to change the association characteristics or to delete the association

Recovery - `chg-as`, `dlt-as`, `ent-as`

1. Display the **mode** for the AS you want to change or delete.
Enter the `rtrv-as` command.
2. Display the connection status of the associations bound to each AS.
Enter the `rtrv-assoc` command.
3. For each association that needs to be changed from a connection state of **open=yes** to a connection state of **open=no**, enter the `chg-assoc` command specifying the **open=no** parameter.
4. When all required association connection states are **open=no**, re-enter the command to enter, change, or delete the AS.

E4099 Cmd Rej: Association name not found

Commands Used: `chg-assoc`, `dlt-assoc`, `rept-stat-assoc`, `rept-meas`, `ent-slk`

You entered a command that specified an association name; the name that you specified is not defined in the IPASOCK table. The association specified by the **aname** parameter must be provisioned in the

system. The specified association (**aname** parameter) must be configured in database before assigning it to an IPSPG signaling link.

Recovery

1. Display the association names that currently exist in the IPAPSOCK table. Enter the `rtrv-assoc` command. Verify that you specified an existing association name.
2. Re-enter the command specifying an association name that exists in the IPAPSOCK table.

E4100 Cmd Rej: LNP feature must be ON before LNP ELAP Config can be ON

Commands Used: `chg-ctrl-feat`

The LNP feature must be turned on before the LNP ELAP Configuration feature can be turned on.

Recovery

1. Display the status of controlled features in the database. Enter the `rtrv-ctrl-feat` command. If the feature is not displayed in the output then the feature is not enabled. If the feature has a status of OFF then the feature is enabled but is not turned on.
2. Enable and turn on the feature as necessary. Refer to the *LNP Feature Activation Guide* and contact the Customer Care Center for assistance.

E4102 Cmd Rej: At least one EPAP DB feature/LNP ELAP CFG must be enabled/ON

Commands Used: `rept-stat-db`, `rept-stat-mps`

The G-Flex, INP, AINPQ, G-Port, EIR, LNP ELAP Configuration, Prepaid SMS Intercept Ph1, A-Port, or V-Flex feature must be turned on before the following actions can be performed:

- The **dsmaud** parameter can be specified in the `chg-stpopts` command
- The **db=mps** parameter can be specified in the `rept-stat-db` command
- The `rept-stat-mps` command can be entered

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-feat` command and the `rtrv-ctrl-feat` command.
2. Refer to the relevant feature manual for procedures to enable, turn on, and use the desired feature.
3. Re-enter the command that generated this error message.

E4107 Cmd Rej: AS table is full

Commands Used: `ent-as`

You entered a command to add an application server process to the AS table. The AS table already contains the maximum of 250 AS entries. Before you can add another AS to the table, you must delete an existing AS entry from the table.

Recovery

1. Display the entries the AS table.

Enter the `rtrv-as` command.

Note:

Before an AS can be deleted from the AS table:

- a) The AS cannot be assigned to a routing key.
 - b) The connection state for the associations assigned to the AS must be **open=no**
2. Delete an AS from the AS table.
Enter the `dlt-as` command.
 3. When you have deleted an existing AS from the AS table, re-enter the `ent-as` command to add another AS to the AS table.

E4108 Cmd Rej: Host assignment to IPLIM/IPLIMI card not supported

Commands Used: `chg-assoc`, `ent-assoc`

You entered a command to add an association to the IPAPSOCK table or change the characteristics of an association in the table. You specified a port that is on an IPLIM or IPLIMI card. You cannot assign a local or remote host to an IPLIM or IPLIMI card.

Recovery

1. Display the card TYPE and APPL (application).
Enter the `rtrv-card` command for the card with the specified port. Verify that the card is not an IPLIM or IPLIMI card.
2. If the card is not an IPLIM or IPLIMI card, re-enter the command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the card is an IPLIM or IPLIMI card, re-enter the command specifying a port on the correct card.

E4109 Cmd Rej: Association is still assigned to AS

Commands Used: `dlt-assoc`

You cannot delete an association from the IPAPSOCK table that is assigned to an AS.

Note:

To delete an association from the IPAPSOCK table, the connection state for the associations assigned to the AS must be open=no.

Recovery

1. Display all ASs with that association.
Enter the `rtrv-as:aname=< association_name >` command.
2. Delete the association for each AS.
Enter the `dlt-as` command. Refer to the *Commands Manual* for detailed information about the use of the `dlt-as` command.

E4113 Cmd Rej: Measurement collection in progress, Retry later

Commands Used: `copy-disk`, `format-disk`

The command you entered is not allowed at this time because the OAM measurements collection is in progress. Measurement requirements for disk access are not compatible with the `copy-disk` and `format-disk` commands.

Measurements collection must be turned off before the `copy-disk` command can be executed.

Note:

Do not issue the `chg-meas` command while the `copy-disk` command is in progress. This results in read and write errors, because the standby fixed disk is not accessible and the active fixed disk only allows read-only access.

Recovery

Wait a time for the measurement collection operation to complete, and then re-enter the command.

Note:

Because no user output specifically indicates that measurement collection has begun or ended, re-enter the command until it is accepted. If this error message does not clear up within an hour, call your Customer Care Center for assistance.

E4114 Cmd Rej: TTA cannot be specified for a direction of ITOA

Commands Used: `dlt-gtcnv`

If you specify the direction of conversion is ITU-to-ANSI (`dir=itoa`), you cannot specify the ANSI translation type (`tta`) parameter.

Recovery

Re-enter the `dlt-gtcnv` command specifying `dir=itoa`, without specifying the `tta` parameter.

E4115 Cmd Rej: TTI must be specified for a direction of ITOA

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

If you specify the direction of conversion is ITU-to-ANSI (**dir=itoa**), the ITU translation type (**tti**) parameter must be specified.

Recovery

Re-enter the command specifying **dir=itoa** and the **tti** parameter.

E4116 Cmd Rej: Wildcard/Asterisk invalid for direction of BOTH

Commands Used: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`

The use of wildcards is not allowed if the direction of conversion is **both** (**dir=both**). (A wildcard is an entry specified with the use of asterisks).

Refer to the *Commands Manual* for details about the use of wildcards with these commands.

Recovery

Re-enter the command without specifying wildcards or asterisks if the direction of conversion is BOTH (**dir=both**) parameter is specified.

E4117 Cmd Rej: Wildcard/Asterisk combination invalid for direction

Commands Used: `ent-gtcnv`

The specified command is invalid because the combination of wildcards used is not correct for the specified (**dir**) parameter. The direction of conversion parameter restricts which combination of parameters can use asterisks. (A wildcard is an entry specified with the use of asterisks).

Refer to the *Commands Manual* for detailed information about the use of the `ent-gtcnv` command.

Recovery

Re-enter the `ent-gtcnv` command specifying parameters that do not use wildcards or asterisks.

E4118 Cmd Rej: Wildcard/Asterisk required for TTI, NP, NAI if DIR is ITOA

Commands Used: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`

The command is invalid because wildcards are required for the **tti**, **np**, and **nai** parameters when specifying an ITU-to-ANSI direction of conversion (**dir=itoa**). (A wildcard is an entry specified with the use of asterisks).

Refer to the *Commands Manual* for details about the valid use of wildcards with these command.

Recovery

Re-enter the command specifying the **tti=***, **np=***, and **nai=*** parameters when specifying **dir=itoa**.

E4119 Cmd Rej: Key values: DIR, TTA, TTI, NP, NAI already exist

Commands Used: `ent-gtcnv`

The command is invalid because the key **dir**, **tta**, **tti**, **np**, or **nai** value(s) have already been specified for this Global Title Conversion table entry.

Recovery

Re-enter the `ent-gtcnv` command without the previously specified **dir**, **tta**, **tti**, **np**, or **nai** parameter.

E4120 Cmd Rej: Key values: DIR, TTA, TTI, NP, NAI does not exist

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

The command is invalid because not all key values **dir**, **tta**, **tti**, **np**, and **nai** have been specified.

Recovery

1. Enter the `ent-gtcnv` command specifying all the key values **dir**, **tta**, **tti**, **np**, and **nai**.
2. Once all key values are defined, re-enter the original command.

E4121 Cmd Rej: ENCODE = AMI not currently supported

Commands Used: `chg-e1`, `ent-e1`, `ent-t1`

The **encode=ami** parameter is supported only for the E1/T1 MIM card, HC-MIM card, or E5-E1T1 card used as an E1 card.

Recovery

Re-enter the command specifying a valid value for the **encode** parameter. Refer to the *Commands Manual* for more information.

E4122 Cmd Rej: Both NP and NAI must be specified if either is present

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

If you specify either the **np** or **nai** parameter, you must specify both of these parameters.

Recovery

Re-enter the command specifying both the **np** and **nai** parameters.

E4123 Cmd Rej: SAPC entry not found for the linkset

Commands Used: `chg-ls`

The value specified for the **sapc** parameter does not exist for the linkset.

Recovery

1. Display all the destination point codes in the Destination Point Code table.
Enter the `rtrv-ls:lsn` command for the given linkset.
2. Re-enter the `chg-ls` command specifying a point code from the output in Step 1.

E4124 Cmd Rej: APC/SAPC with specified group code already exists for linkset

Commands Used: `chg-ip-lnk`, `chg-ls`

Only one secondary adjacent point code (**sapc**) or **apc** per domain per linkset is allowed when the specified group code is **multgc=no** for the linkset. Additionally, when the specified group code is **multgc=yes**, only one **sapcn** per group code per link set is allowed.

Recovery

1. Display all **apc/sapc** entries for the specified linkset.
Enter the `rtrv-ls:lsn` command.
2. Delete the **apc/sapc** entry.
Enter the `chg-ls` command specifying `action=delete`, if necessary.

E4125 Cmd Rej: Maximum SAPC entries exceeded

Commands Used: `chg-ls`

No additional secondary adjacent point code (**sapc**) entry can be added.

Recovery

1. Delete an **sapc** entry that is not being used.
Enter the `chg-ls` command specifying `action=delete`, if necessary.
2. Re-enter the `chg-ls` command to add the **sapc** entry.

E4126 Cmd Rej: Only one ITU-N APC/SAPC allowed with MULTGC=NO

Commands Used: `chg-ls`

Only one secondary adjacent point code (**sapc**) or **apc** per ITU-N domain per linkset is allowed when **multgc=no** for the linkset.

Recovery

Display all the destination point codes in the Destination Point Code table. Enter the `rtrv-ls:lsn` command for the given linkset.

E4127 Cmd Rej: Only one ITU-I or 24-bit ITU-N APC/SAPC allowed per linkset

Commands Used: `chg-ls`

Only one secondary adjacent point code (**sapc**) or **apc** is allowed per linkset in an ITU-I or 24-bit ITU-N domain.

Recovery

1. Display all the destination point codes in the Destination Point Code table.
Enter the `rtrv-ls:lsn` command for the given linkset.
2. Re-enter the `chg-ls` command specifying a point code from the output in Step 1.

E4128 Cmd Rej: SAPC entry present for the linkset

Commands Used: `chg-ls`

A secondary adjacent point code (**sapc**) is provisioned for the linkset.

Recovery

Delete a **sapc** entry. Enter the `chg-ls` command specifying `action=delete`.

E4129 Cmd Rej: SAPC allowed for ITU-I or ITU-N linkset only

Commands Used: `chg-ls`

The secondary adjacent point code (**sapc**) value specified is not allowed for this ANSI linkset.

Recovery

Change linkset *apc* type, if needed.

E4131 Cmd Rej: Version parameter not supported for either SUA or M2PA

Commands Used: `chg-assoc`

You entered a command for an SUA or M2PA association, and specified the `ver` parameter. The `ver` parameter is invalid for SUA or M2PA associations.

Recovery

1. Verify that the ADAPTER value is SUA.
Enter the `rtrv-assoc` command for the association.
2. Re-enter the `chg-assoc` command without specifying the `ver` parameter for the SUA association.

E4132 Cmd Rej: Group code not allowed with specified network type

Commands Used: `dlt-na`, `ent-na`

The group code (`gc`) parameter cannot be specified for ANSI, ITUI, and ITUN24 type network appearances.

Recovery

1. For the `dlt-na` command, enter the `rtrv-na` command to display the existing network appearances.
Verify the network appearance that you want to delete.
2. Re-enter the command that generated this message without specifying the `gc` parameter for the network appearance.

E4133 Cmd Rej: Group code required for ITUN when ITUDUPPC feat is ON

Commands Used: `ent-na`

The group code (`gc`) parameter must be specified for ITUN network appearances when the ITUDUPPC feature is turned on.

Recovery

1. Verify that the ITUDUPPC feature is turned on.
Enter the `rtrv-feat` command.
2. Re-enter the `ent-na` command specifying the group code (`gc`) parameter for the ITUN network appearance.

E4134 Cmd Rej: Group code not allowed when ITUDUPPC feat is OFF

Commands Used: `ent-na`

The group code (**gc**) parameter cannot be specified for network appearances if the ITUDUPPC feature is turned off.

Recovery

1. Verify that the ITUDUPPC feature is turned off.
Enter the `rtrv-feat` command.
2. Re-enter the `ent-na` command without specifying the group code (**gc**) parameter for the network appearance.

E4135 Cmd Rej: Group code must be in SID or SPC table

Commands Used: `ent-na`

You specified a group code for a network appearance, and the group code was not found in the SID or SPC table.

Recovery

1. Enter the `rtrv-sid` and `rtrv-spc` commands to verify the group code.
2. Re-enter the `ent-na` command specifying the correct group code (**gc**) parameter for the network appearance.

E4136 Cmd Rej: NA entry already equipped

Commands Used: `ent-na`

You entered a command to define a network appearance that already exists in the Network Appearance table.

Recovery

1. Display the existing network appearances in the Network Appearance table.
Enter the `rtrv-na` command.
2. Re-enter the `ent-na` command to define a network appearance that does not already exist in the Network Appearance table.

E4138 Cmd Rej: NA entry not found

Commands Used: `dlt-na`

You entered a command to delete a network appearance. The specified network appearance was not found in the Network Appearance table.

Recovery

1. Display the existing network appearances in the Network Appearance table.
Enter the `rtrv-na` command. Verify the network appearance that you want to delete is in the Network Appearance table.
2. Delete the network appearance.
Re-enter the `dlt-na` command specifying the network appearance that you want to delete.

E4139 Cmd Rej: RC Already Equipped

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`

You attempted to add or change the routing context value of a routing key without satisfying the following criteria:

- The routing context value in a routing key must be unique (multiple routing keys cannot have identical routing context values).
- The routing context value in a routing key may only be changed if all of the ASPs associated with the routing key are **open=no**. For SPLIT AS routing key changes, the old AS and the new AS must both meet this criteria.
- The routing context value in a routing key may not be changed during the same command as a RESIZE or SPLIT routing key change.
- A routing key containing a routing context may only be deleted if all of the ASPs associated with the routing key are **open=no**.

Recovery

1. Display the routing keys and routing context values.
Enter the `rtrv-appl-rtkey:display=all` command.
2. Following the above criteria, re-enter the command to add or change the routing context value for a routing key.

E4141 Cmd Rej: IPSM card(s) must be inhibited to enable telnet feature

Commands Used: `chg-ctrl-feat`

Before you can change the status of the Telnet feature (either turning on or turning off), you must first inhibit all Internet Protocol Services Module (IPSM) cards. Inhibit all IPSM cards before changing the status of the Telnet feature.

Recovery

1. Inhibit all IPSM cards.
Enter the `inh-card` command.
2. Change the status of the Telnet feature for the IPSM cards you inhibited in Step 1.
Enter the `chg-ctrl-feat` command.
3. Allow all IPSM cards inhibited in Step 1.
Enter the `alw-card` command for each card. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4142 Cmd Rej: VFLEX feature must be ON

Commands Used: `chg-mtc-measopts`, `chg-sid`, `chg-srvsel`, `chg-ss-appl`, `dlt-ss-appl`, `ent-srvsel`, `ent-ss-appl`, `rept-ftp-meas`, `rtrv-sid`, `rtrv-srvsel`

The V-Flex feature must be turned on before the `entype=vflex`, `appl=vflex`, `nserv=vflex`, `serv=vflex`, `mtchvflex=on`, `mtchvflex=on`, or `cpctype=vflex` parameter can be specified.

Recovery

1. Display current features using the `rtrv-ctrl-feat` command.
2. If the V-Flex feature is enabled, but not **on**, in the output from Step 1, turn it on. Refer to the *Feature Manual - V-Flex* for assistance. If the V-Flex feature is turned **on** in the output from Step 1, re-enter the command that caused this error message.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4143 Cmd Rej: GPORT/IGM must be enabled or VFLEX must be ON

Commands Used: `chg-gsmopts`

The G-Port or IGM feature must be enabled or the V-Flex feature must be turned on before the `multcc` and `nmultcc` parameters can be specified.

Recovery

1. Display the status of current features using the `rtrv-ctrl-feat` command.
2. If the feature is disabled (according to the output from Step 1), enable it. If the V-Flex feature is turned off, turn it on. Refer to the appropriate Feature Manual or the *Commands Manual* for assistance.
3. Re-enter the command that caused this error message to appear.

E4146 Cmd Rej: CTX parameter is invalid for this card

Commands Used: ent-bp

You cannot specify the bit-mapped microengine context mask (**ctx**) parameter for a card that is not an IXP-based card with processor **type=IXP**.

Recovery

Re-enter the **ent-bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent-bp** command.

E4147 Cmd Rej: Invalid combination of TYPE, UENG, and CTX parameters

Commands Used: ent-bp

If you specify **type=ixp**, then you must also specify both the microengine number (**ueng**) and the bit-mapped microengine context mask (**ctx**) parameters.

Recovery

Re-enter the **ent-bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent-bp** command.

E4148 Cmd Rej: DATA parameter is invalid for this card

Commands Used: ent-bp

The **data** parameter is only valid on an IXP-based card.

Recovery

Re-enter the **ent-bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent-bp** command.

E4149 Cmd Rej: ARM register must be specified

Commands Used: ent-bp

The **ca**, **cb**, and **drarm** register values must be specified for an IXP-based card with processor **type=arm**.

Recovery

Re-enter the **ent-bp** command specifying a valid combination of parameters. Valid **ca**, **cb**, and **drarm** register values for an IXP-based card ARM processor are **sp**, **lr**, **pc**, and **r0..r15**.

E4150 Cmd Rej: UENG register must be specified

Commands Used: ent-bp

The microengine number (**ueng**) parameter must be specified for a card with processor **type=ixp**. The **ca** and **cb** parameters are not valid with processor **type=ixp**.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of this ent-bp command.

E4151 Cmd Rej: UENG parameter is invalid for this card

Commands Used: disp-bp, dlt-bp, ent-bp

The **ueng** parameter can be specified only for IXP-based cards.

Recovery

Re-enter the command specifying the correct format and parameters, or install IXP-based cards in the system.

Refer to the *Commands Manual* for information on the commands and to the *Maintenance Manual* for card installation procedures.

E4152 Cmd Rej: Invalid combination of TYPE and DATA parameters

Commands Used: ent-bp

The **data** parameter is only valid with breakpoint **type=data**.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4153 Cmd Rej: CA or CB register value is invalid for this card

Commands Used: ent-bp

The **ca**, **cb**, and **drarm** register values must be specified for an IXP-based card with processor **type=arm**.

Recovery

Re-enter the ent-bp command specifying a valid combination of parameters. Valid **ca**, **cb**, and **drarm** register values for an IXP-based card ARM processor are **sp**, **lr**, **pc**, and **r0..r15**.

E4154 Cmd Rej: DRARM parameter is invalid for this processor

Commands Used: ent-bp

The ARM register indirect memory dump (drarm) parameter can only be specified with processor type=arm.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4155 Cmd Rej: DR parameter is invalid for this card

Commands Used: ent-bp

The register indirect memory dump (dr) parameter is not valid on an IXP-based card.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4156 Cmd Rej: DRARM parameter is invalid for this card

Commands Used: ent-bp

The ARM register indirect memory dump (drarm) parameter is only valid on an IXP-based card.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4157 Cmd Rej: DA parameter is invalid for this card

Commands Used: ent-bp

The dump address (da) parameter is not valid on an IXP-based card.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4158 Cmd Rej: ADDR parameter is invalid for this card

Commands Used: ent-bp

The **addr** parameter is valid only for cards with PROM-based COM processors (such as TSMs); that is, when **proc=com** is specified for DS0 cards. A HIPR or IMTPCI card was specified and the ADDR parameter used. The parameter is not valid for use with the HIPR and IMTPCI cards.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4159 Cmd Rej: TYPE parameter value is invalid for this card

Commands Used: ent-bp

Processor types ARM and IXP are only valid on an IXP-based card.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4160 Cmd Rej: ACCESS parameter value is invalid for this card

Commands Used: ent-bp

When using the **access** parameter, **format=any** is only valid on an IXP-based card. The **format** parameter must be set to **any** on IXP-based cards.

Recovery

Re-enter the ent-bp command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the ent-bp command.

E4161 Cmd Rej: Routing Context parameter is required for SUA

Commands Used: chg-appl-rtkey, ent-appl-rtkey, ent-as

Routing context is mandatory for routing keys associated with an AS containing SUA ASPs.

Recovery - chg-appl-rtkey, ent-appl-rtkey

You attempted to add or change a routing key without specifying a routing context value.

Re-enter the command specifying a valid routing context value.

Recovery - ent-as

You attempted to create an AS whose routing key does not have a routing context value.

- Display the routing keys and routing context value. Enter the `rtrv-appl-rtkey:display=all` command.
- Assign a routing context value to the appropriate routing key. Enter the `chg-appl-rtkey` command.
- Create the AS. Re-enter the `ent-as` command.

E4164 Cmd Rej: G-Flex MAP Layer Routing feature must be ON

Commands Used: `chg-gsmopts`

The G-Flex MAP Routing feature must be enabled and turned on before the `gflexmaplayerrtg` parameter can be specified.

Recovery

- Display the G-Flex MAP Routing feature status using the `rtrv-ctrl-feat` command.
- If the feature is disabled or not showing it must be enabled. Refer to the *Database Administration Manual - Systems Management* to enable this feature.
- Re-enter the command to set the `gflexmaplayerrtg` parameter.

E4165 Cmd Rej: Point Code Subtype Prefix not supported

Commands Used: `rtrv-dstn`, `rtrv,rte`

Spare Point Code subtype `s` or `psis` not supported with `pctype=ansi` or `pctype=itun24`.

Recovery

1. Re-enter the command without specifying the `pcst` parameter.
2. Re-enter the command specifying `pcst=p` or `pcst=none`.

E4166 Cmd Rej: Enhanced GSM Map Screening must be ON

Commands Used: `enable-ctrl-feat`

The command to enable the MTP MAP Screening feature was not allowed because the Enhanced GSM MAP (EGMS) feature must be enabled first.

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* about enabling features with access keys.

Recovery

1. Enter the `rtrv-ctrl-feat` command to display the status of features in your system that have feature access keys.
2. Verify the Enhanced GSM MAP Screening (EGMS) feature was purchased and installed in your system.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. Enable the Enhanced GSM MAP Screening feature in your system.
Enter the `enable-ctrl-feat` command and the appropriate part number and access key information. Turn on the feature. Enter the `chg-ctrl-feat` command. Refer to the *Commands Manual* and the *Database Administration Manual - Features* for more information about enabling this feature.
4. Enable the MTP MAP Screening feature.
Re-enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

E4167 Cmd Rej: Cannot add NP and NAI to an entry where GTIXLAT is 22

Commands Used: `chg-gtcnv`

You cannot specify the new numbering plan (**np**) and the new nature of address indicator (**nnai**) parameters, if the value for the **gtixlat** parameter is 22 (**gtixlatt = 22**).

Recovery

Re-enter the `chg-ctcnv` command specifying **gtixlatt = 22** and without specifying the **np** and **nai** parameters.

E4168 Cmd Rej: At least one Non-Key parm that is to be changed is required

Commands Used: `chg-gtcnv`

The command is invalid because it does not specify at least one non-key parameter to be changed.

Recovery

Re-enter the `chg-ctcnv` command specifying at least one of these non-key parameters: **npdd**, **npds**, **nsdd**, **nsds**, or **rdmod**.

E4169 Cmd Rej: GT Conversion table is full

Commands Used: `ent-gtcnv`

The Default Global Title Conversion table is full. You must delete a translation type entry before another translation type entry can be added to the conversion table.

Recovery

1. Display the translation type entries in the Default Global Title Conversion table.
Enter the `rtrv-gtcnv` command.
2. Delete an existing entry from the Default Global Title Conversion table.
Enter the `dlt-gtcnv` command specifying one of the translation type entries shown in the output in Step 1.
3. Re-enter the `ent-gtcnv` command.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4170 Cmd Rej: Prefix & Suffix digit modification parameters can't be mixed

Commands Used: `chg-gta`, `chg-gtcnv`, `chg-gtt`, `ent-gta`, `ent-gtcnv`, `ent-gtt`

The `nsdd` and `nsds` parameters cannot be used in the same command with the `npdd` and `npds` parameters. You cannot mix these parameters in a single command because they are mutually exclusive.

Recovery

Re-enter the command specifying either prefix digit manipulation or suffix digit manipulation parameters, but not both.

E4171 Cmd Rej: SCCP Conversion feature must be enabled

Commands Used: `chg-gta`, `chg-gtcnv`, `chg-gtt`, `chg-gttset`, `chg-sccpopts`, `chg-stpopts`, `dlt-gtcnv`, `ent-gta`, `ent-gtcnv`, `ent-gtt`, `ent-gttset`, `rtrv-gta`, `rtrv-gtcnv`, `rtrv-gttset`

The ANSI/ITU/24 Bit SCCP Conversion feature must be enabled before the `netdom=cross` parameter can be specified.

The ANSI-ITU-China SCCP Conversion feature must be enabled and turned on before the `ngti` parameter can be specified.

The ANSI-ITU-China SCCP Conversion feature must be enabled and turned on before any of the following can be entered:

- Specifying the new GTI code (**ngti**) parameter with either the global title translation commands (`ent-gtt`, `chg-gtt`, `rtrv-gtt`), or with the global title address commands (`ent-gta`, `chg-gta`, `rtrv-gta`).
- Any global translation conversion command: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`, or `rtrv-gtcnv`.
- Command parameters `cnvainat`, `cnvcgda`, `cnvcgdi`, `cnvcgdn`, `cnvcgdn24`, or `gtcnvdfit`.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Verify the ANSI-ITU-China SCCP Conversion feature was purchased and installed in your system.
3. Enable the ANSI-ITU-China SCCP Conversion feature.
Enter the `enable-ctrl-feat` command specifying the appropriate part number and access key information. Refer to the *Commands Manual* and the *Database Administration Manual – Global Title Translation* for more information about enabling this feature.
4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4172 Cmd Rej: Can't switch existing Pfx/Sfx, use RDMOD to reset

Commands Used: `chg-gtcnv`

You cannot switch the prefix and suffix digit modifier parameters in a single command because they are mutually exclusive. To change the values from prefix to suffix or the reverse, first use the **rdmod** parameter to reset the current digit modifier values.

Recovery

1. Reset the digit modifiers.
Enter the `chg-gtcnv:tta=xxx:tti=yyy:rdmod=yes` command.
2. Re-enter the `chg-gtcnv` command specifying either the prefix or suffix digit modifiers.

E4173 Cmd Rej: Not compatible with SCCP Conversion feature

Commands Used: `chg-feat`

You cannot specify either the SCCP Conversion (SCCPCNV feature bit) or TCAP Conversion (TCAPCNV feature bit) features because the ANSI-ITU-China SCCP Conversion feature is already enabled. The ANSI-ITU-China SCCP Conversion feature is mutually exclusive with both of those feature bits.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

Display the features in the database. Enter the `rtrv-feat` command to verify the status of the SCCPCNV and TCAPCNV features and the `rtrv-ctrl-feat` command to verify the status the ANSI-ITU-China SCCP Conversion feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4174 Cmd Rej: NGTI only valid when PC and GTTSN are different domains

Commands Used: `chg-gta`, `ent-gta`

The New GTI Code (**ngti**) parameter is valid only when the translated point code (**pc**) and GTT set name (**gttsn**) are different domains. The **ngti** parameter can be specified only when the translated point code and the translation type are in different domains, or are both in the ITU domain.

Recovery

1. Verify all point codes and the domains that they are assigned to.
Enter the `rtrv-dstn` command. The domain of each point code is shown in the DOMAIN field in the output.
2. Re-enter the original command specifying an **ngti** parameter with a PC (translation point code) whose domain is different from the domain of the GTTSN (GTT set name).

E4175 Cmd Rej: If NGTI is 4, NNP and NNAI must be specified

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

If you specify the New GTI Code is 4 (**ngti=4**), you must specify both the new numbering plan (**nnp**) and the new nature of address indicator (**nnai**) parameters.

Recovery

Re-enter the command specifying both the **nnp** and **nnai** parameters.

E4176 Cmd Rej: If NGTI is 2, NNP and NNAI cannot be specified

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

If you specify the New GTI Code parameter is 2 (**ngti=2**), you cannot specify the new numbering plan (**nnp**) or new nature of address indicator (**nnai**) parameters.

Recovery

Re-enter the command without specifying the **nnp** and **nnai** parameters.

E4177 Cmd Rej: Invalid TPCs are present in the MAP table for specified SSN

Commands Used: `chg-ctrl-feat`, `enable-ctrl-feat`, `ent-ss-appl`

The specified MAP table entry for the subsystem must be a valid point code type for that subsystem. The following point code types are not valid for the indicated subsystems:

- If the subsystem number is configured for the INP subsystem in the SS-APPL table, then the True Point code cannot be an ITU-I or ANSI point code.
- If the subsystem number is configured for the EIR subsystem in the SS-APPL table, then the True Point code cannot be an ANSI point code.
- If the subsystem number is configured for the ATINPQ or VFLEX subsystem in the SS-APPL table, then the True Point code can not be an ITU-N24 point code.

Recovery

1. Display the status of the controlled features in the database. Enter the `rtrv-ctrl-feat` command.

Note:

Once a feature that is controlled using a feature access key has been permanently turned on, it cannot be turned off.

2. Remove any invalid TPCs from the map table. Refer to the appropriate Feature Manual for more information.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4180 Cmd Rej: Wildcard SSN already exists

Commands Used: `ent-srvsel`

You specified a command specifying a **gti/gtia/gtii/gtin**, **tt**, **np(v)**, **nai(v)**, and a specific **ssn** that already has a matching wildcard **ssn** entry. (A wildcard **ssn** entry is specified with the use of asterisks). This duplication of entry is not allowed.

Recovery

1. Display the existing values for the above parameters.
Enter the `rtrv-srvsel` command.

2. Re-enter the `ent-srvsel` command specifying values that do not already exist in the database for the above parameters.

E4181 Cmd Rej: Specific SSN already exists

Commands Used: `ent-srvsel`, `ent-ss-appl`

You specified a command specifying a **gti/gtia/gtii/gtin**, **tt**, **np(v)**, **nai(v)**, and a wildcard **ssn** that already has a matching specific **ssn** entry. (A wildcard **ssn** entry is specified with the use of asterisks). The value specified for the **ssn** parameter cannot already exist in the SS-APPL table.

Recovery

1. Display the existing values for the above parameters.
Enter the `rtrv-srvsel` command.
2. Re-enter the `ent-srvsel` command specifying values that do not already exist in the database for the above parameters.

E4182 Cmd Rej: STP True PC and EIR Subsystem do not exist in MAP table

Commands Used: `ent-ss-appl`

To reserve an EIR subsystem number (**ssn**) for an application, the STP true point code/EIR subsystem number combination must be previously defined in the Mated Applications (MAP) table.

Recovery

1. Enter the `rtrv-sid` command to see the point codes (**pca/pci/pcn**) assigned to the system.
2. Enter the `ent-map` command and assign mated application values for the true point code (**pc/pca/pci/pcn**) and the EIR subsystem number (**ssn**).
3. Re-enter the `ent-ss-appl` command specifying the newly assigned values for **pc/pca/pci/pcn** and the EIR **ssn**.

E4183 Cmd Rej: INP/AINPQ/EIR/VFLEX feature must be ON or ATINP must be enabled

Commands Used: `chg-map`, `ent-map`

The INP, AINPQ, V-Flex, or EIR feature must be turned on or the **ATINP** feature must be enabled before the value specified for the **pcn/ mpcn** parameter can be a true point code.

Note: Once a Permanently On feature that is controlled using a feature key is turned on, it cannot be turned off.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4184 Cmd Rej: EIR Subsystem is offline in database

Commands Used: `alw-map-ss`

The EIR subsystem must be online in the database before this command can be entered.

Recovery

Activate the EIR subsystem. Enter the following command:

```
chg-ss-appl:appl=eir:nstat=online
```

E4185 Cmd Rej: EIR feature must be enabled

Commands Used: `dlt-ss-appl`, `rtrv-sid`

The Equipment Identity Register (EIR) feature is not enabled. You must enable the EIR feature before entering either the `rtrv-sid` command specifying the `cpctype=eir` parameter, or the `dlt-ss-appl` command specifying the `appl=eir` parameter.

Recovery

1. Display the status of features in your system that have feature access keys.
Enter the `rtrv-ctrl-feat` command.
2. Refer to the procedures in the *Feature Manual – EIR* to enable and turn on the EIR feature.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4186 Cmd Rej: At least one EPAP database feature must be enabled/ON

Commands Used: `dlt-srvsel`, `rtrv-srvsel`

At least one EPAP database feature must be enabled or turned on before the command can be entered. Refer to the command description in the *Commands Manual* for a list of EPAP database features.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` and the `rtrv-feat` commands.

If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.

2. Enable and turn on the feature as necessary. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4188 Cmd Rej: LNP/EIR/VFLEX/ATINP must be enabled or INP/AINPQ must be ON

Commands Used: `rtrv-ss-appl`

The LNP, EIR, V-Flex, or ATINP feature must be enabled, or the INP or AINPQ feature must be turned on before the `rtrv-ss-appl` command can be entered.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` command.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled but is not turned on.

2. Enable and turn on the feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4189 Cmd Rej: Invalid PC type for the subsystem associated with SSN value

Commands Used: `chg-map`, `ent-map`

If a subsystem is configured for an SSN value in the SS-APPL table, then the specified MAP table entry for that subsystem must be a valid point code type for that subsystem. The following point code types are not valid for the indicated subsystems:

- If the subsystem number is configured for the INP subsystem in the SS-APPL table, then the True Point code cannot be an **ITU-I** or **ANSI** point code.
- If the subsystem number is configured for the EIR subsystem in the SS-APPL table, then the True Point code cannot be an **ANSI** point code.
- If the subsystem number is configured for the ATINPQ or VFLEX subsystem in the SS-APPL table, then the True Point code can not be an **ITU-N24** point code.

Recovery

Re-enter the command that generated this error message, and specify the correct values for the SSN value. Refer to the *Commands Manual* for assistance.

E4191 Cmd Rej: GFLEX/EIR/VFLEX must be ON or GPORT/IGM/MO SMS feat enabled

Commands Used: `chg-gsmopts`

The G-Port, IGM, MO SMS ASD, MO SMS B-Party Routing, MO SMS GRN, MO SMS IS41-to-GSM Migration, MO-based GSM SMS NP, or Prepaid SMS Intercept Ph1 feature must be enabled, or the G-Flex, EIR, or V-Flex feature must be turned on before this command can be entered.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` and the `rtrv-feat` commands.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled, but it is not turned on.

2. Enable and turn on the feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4192 Cmd Rej: GFLEX or EIR feature must be on

Commands Used: `ent-trace`

The G-Flex or Equipment Identity Register (EIR) feature must be turned on before the `imsi` parameter can be specified.

Note: After a Permanently On feature that is controlled by a feature access key is turned on, the feature cannot be turned off. After a feature that is controlled by a feature bit is turned on, the feature cannot be turned off.

Recovery

1. If the `imsi` parameter is not required in the command, then re-enter the command, and do not specify the `imsi` parameter.
2. If the `imsi` parameter is required, then enter the `rtrv-ctrl-feat` command to display the status of controlled features in the system.

If the entry for the G-Flex feature or the EIR feature does not appear in the command output, then the feature is not enabled in the system.

If the status of the G-Flex feature or the EIR feature is OFF in the command output, then the feature is enabled, but not turned on.

3. Refer to the procedures in the following manuals to enable, turn on and use the required feature.

- *Feature Manual - G-Flex C7 Relay*
 - *Feature Manual - EIR*
4. After the G-Flex feature or the EIR feature is turned on, re-enter the command that generated this error message.
 5. If this message appears again, call your Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4193 Cmd Rej: Spare Point Code Feature must be enabled

Commands Used: `chg-dstn`, `chg-lsopts`, `chg-map`, `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `chg-sid`, `dlt-cspc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`, `dlt-spc`, `ent-cspc`, `ent-dstn`, `ent-map`, `ent-na`, `ent-spc`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`, `ent-sid`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-spc`, `vfy-sid`

The Spare Point Code Support feature must be enabled before a spare point code (prefix s-) can be specified in the command.

Recovery

1. Enter the `rtrv-ctrl-feat` command to display the status of controlled features in the system.
If the entry for the Spare Point Code Support feature does not appear in the command output, then the feature is not enabled in the system.
2. Refer to the *Database Administration Manual - SS7* manual to enable the Spare Point Code feature.
3. After the Spare Point Code Support feature is enabled, re-enter the command that generated this error message.
4. If the message appears again, call your Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4194 Cmd Rej: Cannot delete last route to DPC referenced in PPSOPTS table

Commands Used: `dlt-rte`

The last route to a destination point code that still exists in the Prepaid SMS Options (PPSOPTS) table cannot be deleted until the existing point code is deleted from the PPSOPTS table.

Recovery

1. Enter the `rtrv-rte` command with the point code that was specified in the entered command, to display the routes to that point code.
2. Enter the `rtrv-ppsopts` command to display the point codes assigned to Prepaid SMS options.

3. Refer to the command descriptions in the *Commands Manual* and to the procedures in the *Database Administration Manual - SS7* to delete the route.
4. Use the `chg-ppsopts` command to delete the point code from the PPSOPTS table.
5. Re-enter the command to delete the route.
6. If the message appears again, call your Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual

E4196 Cmd Rej: Spare Point Code Feature not compatible with IPGWI socket

Commands Used: `enable-ctrl-feat`

The Spare Point Code feature cannot be enabled if sockets are provisioned for an IPGWI card.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4197 Cmd Rej: CCGT and NGTI are mutually exclusive

Commands Used: `chg-gta`, `ent-gta`

If the **ccgt** parameter is specified, the **ngti** parameter cannot be specified. If the **ngti** parameter is specified, the **ccgt** parameter cannot be specified.

Recovery

Re-enter the command specifying either the **ccgt** or **ngti** parameter but not both.

E4198 Cmd Rej: Can't switch existing Pfx/Sfx, use RMGTT to reset

Commands Used: `chg-gtt`

You cannot switch the existing prefix or suffix digit manipulation parameters. Neither can you specify both prefix digit manipulation and suffix digit manipulation parameters because they are mutually exclusive. To change the values from prefix to suffix or the reverse, first use the **rmgtt** parameter to reset the Modified Global Title Translation feature (MGTT) fields.

Recovery

1. Reset the MGTT fields.
Enter the `chg-gtt:rmgtt=yes` command.
2. Re-enter the `chg-gtt` command specifying either the prefix digit manipulation or suffix digit manipulation parameters.

E4199 Cmd Rej: NGTI only valid when PC and TYPE are different domains

Commands Used: `chg-gtt`, `ent-gtt`

The **ngti** parameter can be specified only when the translated point code and the translation type are in different domains, or are both in the ITU domain.

Recovery

1. Verify all point codes and the domains that they are assigned to.
Enter the `rtrv-dstn` command. The domain of each point code is shown in the DOMAIN field in the output.
2. Re-enter the original command specifying the **ngti** parameter with a translation point code (**pc**) whose domain does not match the domain of the translation type (**type**).

E4200 Cmd Rej: Cannot use NEXT if preceding RTRV-LOG command used TYPE=ALL

Commands Used: `rtrv-log`

You specified the **next** parameter that followed a `rtrv-log` command specifying the **type=all** parameter. You cannot use the **next** parameter with the **type=all** parameter. This sequence of commands is not supported.

Recovery

Re-enter the `rtrv-log` command without specifying the **next** parameter.

Refer to the *Commands Manual* for detailed information about the use of this command.

E4201 Cmd Rej: SCCPCNV, TCAPCNV must be disabled

Commands Used: `enable-ctrl-feat`

The attempt to enable the ANSI-ITU-China SCCP Conversion feature was unsuccessful. It is mutually exclusive with the SCCPCNV (SCCP Conversion) feature bit and TCAPCNV (TCAP Conversion) feature bit.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

Display the features in the database. Enter the `rtrv-feat` command to verify the status of the SCCPCNV and TCAPCNV features and the `rtrv-ctrl-feat` command to verify the status the ANSI-ITU-China SCCP Conversion feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4202 Cmd Rej: SCCP Conversion feature requires at least TSM Hardware

Commands Used: `enable-ctrl-feat`

You cannot enable the ANSI-ITU-China SCCP Conversion feature because a required TSM card is missing. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware to at least the TSM hardware required for the SCCP Conversion feature.
2. Re-enter the `enable-ctrl-feat` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4203 Cmd Rej: ENUM requires an SNUM as its mate parameter

Commands Used: `rtrv-log`, `rtrv-trbltx`

You specified the **enum** parameter but not with its mate parameter, **snum**. When **enum** is specified, the **snum** parameter is required too.

Recovery

Re-enter the command specifying values for the mate parameters **enum** and **snum**.

E4204 Cmd Rej: ENUM must be greater or equal to mate parameter SNUM

Commands Used: `rtrv-log`, `rtrv-trbltx`

The **enum** value must be equal to or greater than the **snum** value.

Recovery

Re-enter the command specifying the **enum** value equal to or greater than the **snum** value.

E4205 Cmd Rej: ENUM range does not match SNUM: 1-999 or 1000-1499

Commands Used: `rtrv-log`, `rtrv-trbltx`

You specified the **enum** value not in the same range as its mate parameter, **snum**. Both parameters must be in the same range, either **1-999** (for UAMs) or **1000-1499** (For UIMs).

Recovery

Re-enter the command specifying the **enum** value in the same range as its mate parameter, **snum**.

E4206 Cmd Rej: NEXT requires this term issued last valid RTRV-LOG command

Commands Used: `rtrv-log`

Because the **next** parameter extends a previous command, the system requires that the `rtrv-log:next=n` command be entered from the same terminal without any intervening `rtrv-log` commands from this or any other terminal. This **next** option command was either the first `rtrv-log` command from the issuing terminal or another `rtrv-log` command was received from another terminal in the interval between the first and second command from this terminal.

Recovery

Re-enter the `rtrv-log` command without specifying the **next** parameter. To extend the display of UAM or UIM log entries, re-enter the `rtrv-log` command specifying the **next** parameter, while making certain that no other terminal enters an intervening `rtrv-log` command.

E4208 Cmd Rej: No other parameters are permitted with the NEXT parameter

Commands Used: `rtrv-log`

The command entered is invalid because the **next** parameter was specified along with another parameter. When the **next** parameter is specified, no other parameters can be specified.

Recovery

Re-enter the `rtrv-log` command specifying only the **next** parameter.

E4209 Cmd Rej: OUTGRP and SNUM/ENUM combination invalid

Commands Used: `rtrv-trbltx`

You cannot specify both the **outgrp** and **snum/enum** parameters. When the **outgrp** parameter is specified, the **snum** and **enum** parameters cannot be specified.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-trbltx` command.

Recovery

Re-enter the `rtrv-trbltx` command specifying either the **outgrp** parameter or the **snum/enum** parameters.

E4210 Cmd Rej: TYPE and SNUM/ENUM combination invalid

Commands Used: `rtrv-log`, `rtrv-trbltx`

You specified an invalid combination of values for the **type** and **snum/enum** parameters. The values specified for **type** did not agree with the **snum/enum** parameter values.

Recovery

Re-enter the command specifying corresponding values for the **type** and **snum/enum** parameters.

E4211 Cmd Rej: If DIR=BKWD, SDATE/STIME must be > EDATE/ETIME

Commands Used: `rtrv-log`

The command entered is invalid because it specified incorrect **date/time** parameters when **dir=bkwd** (direction is a backward search). For a backward search direction, the specified **sdate/stime** must be greater than the **edate/etime**.

Recovery

Re-enter the `rtrv-log` command specifying **sdate/stime** values greater than the **edate/etime**.

E4212 Cmd Rej: Cannot execute command until table initialization complete

Commands Used: `rtrv-log`

You entered a command that cannot be executed until the table initialization of the ELOG and UIM logs has completed. Please wait until the table has been initialized (that is, the maintenance baseline is established).

Recovery

When the table initialization of the ELOG and UIM logs has completed, you can re-enter the `rtrv-log` command.

E4213 Cmd Rej: Current set of next elog entries have been overwritten

Commands Used: `rtrv-log`

Since the previous entry of a `rtrv-log` command, a number of UAMs and/or UIMs have been logged. Consequently, the pointer to the next log to display has been overwritten by those alarms occurring since the original `rtrv-log` command was entered. Because the pointer was overwritten by system activity, you cannot use the **next** parameter until you enter a new `rtrv-log` command without a **next** parameter.

Recovery

Re-enter the `rtrv-log` command without specifying the **next** parameter.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-log` command.

E4214 Cmd Rej: LOC and E1PORT parameter combination must be specified

Commands Used: `ent-slk`, `inh-alm`, `unhb-alm`, `rtrv-e1`

If the **loc** parameter indicates an SE-HSL card, then the **e1port** parameter must be specified.

When the **dev=e1port** parameter is specified, the **loc** parameter and the **e1port** parameter must be specified.

Recovery

Re-enter the command specifying the **loc** and the **e1port** parameters.

Refer to the *Commands Manual* for detailed information about the use of this command.

E4215 Cmd Rej: LOC and T1PORT parameter combination must be specified

Commands Used: `ent-slk`, `inh-alm`, `unhb-alm`

For `ent-slk`: If the **loc** parameter indicates an ST-HSL-A card, then the **t1port** parameter must be specified.

When the **dev=t1port** parameter is specified, the **loc** parameter and the **t1port** parameter must be specified.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4216 Cmd Rej: Linkset cannot be the mate of another linkset

Commands Used: `chg-ls`, `dlt-ls`

The specified linkset is already the mate of another linkset. A linkset can have only one mate.

Recovery

1. Display the mates of specified linksets with the `rtrv-ls` command.
The output displays mates of other linksets under the **MATELSN** heading.
2. Using the output from Step 1, verify that the correct **matelsn** was specified.
If the **matelsn** was correct, then delete that linkset as a mate from the other linkset that specifies it as a **matelsn**.

3. Re-enter the command that generated this error message specifying a linkset (**lsn=**) that is not the mate of another linkset.

E4217 Cmd Rej: Linkset cannot reference self as mate

Commands Used: `chg-ls`

You cannot specify the linkset itself as the mate. A mate to a linkset must be another unique linkset.

Recovery

Re-enter the `chg-ls` command that generated this error message specifying a linkset (**lsn=**) that is not itself.

E4218 Cmd Rej: A mated linkset cannot have more than one link assigned

Commands Used: `chg-ls`

The command is invalid because the linkset specified as a mate has more than one signaling link assigned to it. A mated linkset can have only one signaling link.

Recovery

1. Display the mates of specified linksets with the `rtvr-ls` command.
The output displays mates of other linksets under the **MATELSN** heading.
2. Based on the output from Step 1, verify that the correct **matelsn** was specified.
If the correct **matelsn** was specified, then the number of signaling links assigned to that linkset must be reduced to one in order to allow the linkset to be referenced as a **matelsn**.

E4219 Cmd Rej: Mated linksets must contain only SS7IPGW or IPGWI links

Commands Used: `chg-ls`

The command is invalid because the **lsn** or **matelsn** parameter refers to a linkset that contains a non-IPGWx signaling link.

Recovery

Re-enter the `chg-ls` command that generated this error message specifying the **matelsn** parameter a mate linkset that is an IPGWx linkset.

E4220 Cmd Rej: Mated linksets must have APCs of same network type

Commands Used: `chg-ls`

The command is invalid because the `apc` parameter and the adjacent point code parameter (**apc**, **apca**, **apci**, **apcn**, **apcn24**) are different network linkset types. Mated linksets must have APCs that share a common network type.

Recovery

Verify that the specified linksets and APC are correct. If they are correct, change the APC of either linkset so that the network types are the same.

E4221 Cmd Rej: Card having link in linkset must first be inhibited

Commands Used: `chg-ls`

The specified card was not OOS-MT-DSBLD (out of service - maintenance disabled). The command is invalid because the card hosting the signaling link in the specified linkset is not inhibited.

Recovery

1. Display the status of the card that generated this message.

Enter the `rept-stat-card` command specifying the card location. The primary state of the card is shown in the PST field.

- a) If the primary state of the card displayed in Step 1 is not OOS-MT-DSBLD, make the primary state of the card OOS-MT-DSBLD.

Enter the `rmv-card` command. Go to Step 2.

Note:

The following card locations are not valid for the `rmv-card` command: 1113, 1114, 1115, 1116, 1117, 1118, and all `xy09` and `xy10` locations (where `x` is the frame and `y` is the shelf).

- b) If the primary state of the card displayed in Step 1 is OOS-MT-DSBLD, go to Step 2.
2. Re-enter the `chg-ls` command that generated this message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4222 Cmd Rej: Card having link in mate linkset must first be inhibited

Commands Used: `chg-ls`

The specified card was not OOS-MT-DSBLD (out of service - maintenance disabled). The command is invalid because the card hosting the signaling link in the specified mate linkset is not inhibited.

Recovery

1. Display the status of the card, specified in the command that generated this message, with the `rept-stat-card` command, specifying the card location.
The primary state of the card is shown in the PST field.
 - a) If the primary state of the card displayed in Step 1 is not OOS-MT-DSBLD, make the primary state of the card OOS-MT-DSBLD.
Enter the `rmv-card` command and go to Step 2.
 - b) If the primary state of the card displayed in Step 1 is OOS-MT-DSBLD, go to Step 2.
2. Re-enter the `chg-ls` command that generated this message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4223 Cmd Rej: Action requires IPSG or MATELSN or RCONTEXT but not together

Commands Used: `chg-ls`

Either an `ipsg`, `rcontext`, or a mate linkset (`matelsn`), can be specified with the `action=delete` parameter.

Recovery

Re-enter the `chg-ls` command that generated this error message specifying the `action=delete` parameter to delete a link that is either a **`ipsg`**, **`rcontext`**, or **`matelsn`**.

E4224 Cmd Rej: Up to 8 SS7IPGW or IPGWx links allowed in un-mated linkset

Commands Used: `ent-slk`

You cannot assign more than eight SS7IPGW or IPGWx signaling links to an unmated linkset. For an unmated linkset, a maximum of eight SS7IPGW or IPGWx signaling links are allowed per linkset.

Recovery

1. Verify that the card in the specified location is running an unmated SS7IPGW or IPGWx application.
Enter the `rtrv-card` command.
2. If the card is not running an unmated SS7IPGW or IPGWx application, re-enter the `ent-slk` command specifying the correct card location.
3. If the unmated linkset already has eight links assigned, you cannot assign another link to it.
You may choose to change current assignments (`chg-slk`) or use a different linkset to make the assignment.

E4225 Cmd Rej: Mate already exists for linkset

Commands Used: `chg-ls`

You cannot assign a mate linkset (**matelsn**) to a linkset that already has an assigned mate linkset. Only one mate linkset per linkset is supported.

Recovery

1. Display the mates of specified linksets.
Enter the `rtrv-ls` command. The **MATELSN** heading displays linkset mates.
2. Using the output of Step 1, verify that the correct **lsn** was specified and that it already has a **matelsn** assigned.
3. You can either:
 - a) Accept the current mate linkset assignment,
OR
 - b) Change the assigned mate linkset by first issuing the `chg-ls:action=delete` command to delete the currently assigned **matelsn** from the linkset.
Then enter `chg-ls:action=add` to assign another **matelsn** to the linkset.

E4234 Cmd Rej: RI must be GT when specifying NGT

Commands Used: `chg-gtt`, `ent-gtt`

If the ANSI-ITU-China SCCP Conversion feature is turned on, and the **ngt** parameter is specified, the **ri=gt** parameter must be specified.

Note:

This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error message specifying both the **ngt** parameter and the **ri=gt** parameter.

E4235 Cmd Rej: NGT can only be specified when XLAT=DPC or DPCNGT

Commands Used: `chg-gtt`, `ent-gtt`

If the ANSI-ITU-China SCCP Conversion feature is on, the **ngt** parameter can be specified only if the **xlat=dpc** parameter or the **xlat=dpcngt** parameter is specified. The **ngt** parameter can only be specified when **xlat=dpc** or **xlat=dpcngt**.

Note:

This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error messages specifying both the **ngt** parameter and either the **xlat=dpc** or **xlat=dpcngt** parameter.

E4236 Cmd Rej: RI must be GT when specifying NTT

Commands Used: `chg-gta`, `ent-gta`

If the ANSI-ITU-China SCCP Conversion feature is on, and the **ntt** parameter is specified, the **ri=gt** parameter must be specified.

Note:

This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error message specifying both the **ntt** parameter and the **ri=gt** parameter.

E4237 Cmd Rej: NTT can only be specified when XLAT=DPC or DPCNGT

Commands Used: `chg-gta`, `ent-gta`

You specified the **ntt** parameter without also specifying the **xlat=dpc** or **xlat=dpcngt** parameter. If the ANSI-ITU-China SCCP Conversion feature is on, the **ntt** parameter can be specified only when the value of the **xlat** parameter is **dpc** or **dpcngt**.

Note:

This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error message specifying both the **ntt** parameter and either the **xlat=dpc** or **xlat=dpcngt** parameter.

E4238 Cmd Rej: Point code matches a STP secondary point code

Commands Used: `ent-dstn`

The Signal Transfer Point (STP) validates the command to ensure that the specified destination address does not correspond to the STP's secondary point code.

Recovery

1. Display the site destination secondary point codes (SPCs) in the system.

Enter the `rtrv-spc` command. The SPCs are shown in the SPC, SPCA, SPCI or SPCN24 outputs.

2. Re-enter the `ent-dstn` command specifying a secondary point code (**spc**) that is not shown in the outputs of Step 1.

E4239 Cmd Rej: At least one other optional parameter is required

Commands Used: `chg-gsmmap-scrn` , `rtrv-data-rtdb`

For the `chg-gsmmap-scrn` command, if the **cdsr** parameter is specified, then at least one additional optional parameter must be specified.

For the `rtrv-data-rtdb` command, if the G-Flex, G-Port, INP, AINPQ, EIR, Prepaid IDP Relay Query, V-Flex, or Prepaid SMS Intercept Ph1 (PPSMS) feature is turned on, or the ATINP feature is enabled, then the **imsi**, **dn**, **entity**, **imei**, or **entitytype** parameter must be specified.

Recovery

Re-enter the command that generated this error message, and specify a supported combination of parameters. Refer to the *Commands Manual* for assistance.

E4240 Cmd Rej: GFLEX, GPORT or VFLEX feature must be ON or ATINP enabled

Commands Used: `rtrv-data-rtdb`

The G-Flex , G-Port, or V-Flex feature must be turned on, or the ATINP feature must be enabled, before the **entity** parameter can be specified.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` and the `rtrv-feat` commands.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled, but it is not turned on.

2. Enable and turn on the feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4241 Cmd Rej: Link test must not be running on requested link

Commands Used: `act-cdl` , `act-lbp` , `dact-lbp`

You entered this command while a `tst-slk` command was running. These tests cannot be performed simultaneously.

Recovery

Perform one of the following actions:

- Wait for the current test to complete. Determine the status of the signaling links currently under test. Enter the `rept-stat-tstslk` command.

OR

- Stop the current test with the `tst-slk:action=stop` command for the appropriate card and link. Then re-enter the original command that prompted this error.

OR

- Re-enter the original command that prompted this error specifying a different card and link.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4242 Cmd Rej: Requested link must not be in command driven loopback

Commands Used: `act-lbp`, `dact-lbp`, `tst-slk`

You cannot enter these commands while a Command Driven Loopback is in progress. These tests cannot be performed simultaneously.

The link cannot be in Command Driven Loopback (CDL) when this command is entered. The link must be removed from CDL before these commands can be entered for the link.

Recovery

Perform one of the following actions:

- Stop the command-driven loopback for the appropriate card and link. Enter the `dact-cdl` command. Re-enter the command that generated this error message.

OR

- Re-enter the command that generated this error message specifying a different card and link.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4243 Cmd Rej: Link test command in progress

Commands Used: `tst-slk`

You entered this command for a specified signaling link that is already performing a link test. All link test commands are rejected until the current test is completed.

Recovery

Perform one of the following actions:

- Wait for the current test to complete. Determine the status of the signaling links currently under test. Enter the `rept-stat-tstslk` command.
OR
- Stop a link test with the `tst-slk:action=stop` command for the appropriate card and link. Then re-enter the `tst-slk` command that generated this error message.
OR
- Re-enter the `tst-slk` command that generated this error message specifying a different card and link.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4244 Cmd Rej: Link test command not in progress

Commands Used: `tst-slk`

A link test is not currently in progress on the specified card and link. The `action=stop` parameter is invalid if a link test is not active.

Recovery

1. Verify that the card location and link are specified correctly.
2. Use the `rept-stat-tstslk` command report to confirm the status of the signaling links currently under test.
3. If you are certain the specified card location and link have a link command in progress and this command continues to fail, call your Customer Care Center for assistance.

E4245 Cmd Rej: Card does not support command driven loopback

Commands Used: `act-cdl`, `rept-stat-cdl`

The card in the specified card location (**loc**) does not support command-driven loopback.

Recovery

1. Enter the `rtrv-card` command to verify the card type and application at the specified location is one of the following:
 - a) An AINF LIM (card type **limds0**, **limocu**, **limv32** and either application **ss7ansi** or **ccs7itu**), or
 - b) A multi-port LIM (card type **limds0** and application **ss7ansi**), or
 - c) An E1/T1 MIM (card type **lime1**, **limt1**, or **limch** and either application **ss7ansi** or **ccs7itu**), or **limatm**, or **lime1atm**
2. Re-enter the command and specify an **loc** that supports command-driven loopback.

E4246 Cmd Rej: Command driven loopback in progress

Commands Used: `act-cdl`

You entered this command for a specified signaling link that is already performing a command-driven loopback test. All command-driven loopback test commands are rejected until the current test is stopped.

Recovery

Perform one of the following actions:

- Stop the command-driven loopback test. Enter the `dact-cdl` command specifying the appropriate card and link. Re-enter the `act-cdl` command that generated this error message.

OR

- Re-enter the `act-cdl` command that generated this error message specifying a different card and link.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4247 Cmd Rej: Command driven loopback not in progress

Commands Used: `dact-cdl`

You attempted to deactivate a command-driven loopback on a signaling link that is not currently in command-driven loopback but is running a link test.

Recovery

1. Determine the status of the signaling links currently in a command-driven loopback.
Enter the `rept-stat-cdl` command.
2. If you are certain the specified card location and link are in the process of a command-driven loopback and this command continues to fail, call your Customer Care Center for assistance.

E4248 Cmd Rej: Card GPL state conflict

Commands Used: `init-flash`

Dependent GPL must be activated. The card cannot support a valid version of BLBIOS and BLCPLD at the same time

Recovery

You must either remove the resident version before activating a new one, or you must activate the resident version before activating a new version.

E4249 Cmd Rej: Mate linkset not defined

Commands Used: `chg-ls`

You specified a mate linkset (**matelsn**) that is not defined. The mate linkset that is successfully assigned to a linkset must be one that is already equipped in the linkset database.

Recovery

1. Display the existing linksets.
Enter the `rtrv-ls` command linksets.
2. Perform one of the following:
 - a) Re-enter the `chg-ls` command and specify another mate linkset from those listed in the output of Step 1 that is suitably equipped as a mate linkset.
OR
 - b) Create a new linkset that is intended to be assigned as the original linkset's mate linkset.
Enter the `ent-ls` command.

E4250 Cmd Rej: Linkset does not reference MATELSN

Commands Used: `dact-cdl` , `chg-ls`

If the **action=delete** parameter is specified to **delete** a mate linkset assignment, the specified mate linkset must be the mate of the specified linkset in the database.

Recovery

Re-enter the `dact-cdl` command specifying both the **lsn** and **matelsn** parameters.

E4251 Cmd Rej: IPTPS required for IPGWx linksets

Commands Used: `chg-ls` , `ent-ls`

The **iptps** parameter must be specified for IPGWx linksets.

Recovery

Re-enter the command that generated this error message specifying the **iptps** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4252 Cmd Rej: IPTPS not allowed for non-IPGWx linksets

Commands Used: ent-ls, chg-ls

The **iptps** parameter cannot be specified for linksets that are not IPGWx. The **ipgwapc=yes** parameter must be specified before the **iptps** parameter can be specified.

Recovery

Re-enter the command that generated this error message without specifying the **iptps** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4253 Cmd Rej: LSUSEALM allowed only for IPGWx and IPSG linksets

Commands Used: chg-ls, ent-ls

You cannot specify the **lsusealm** parameter for non-IPGWx linksets. The **ipgwapc=yes** or **ipsg=yes** parameter must be specified before the **lsusealm** parameter can be specified.

Recovery

Re-enter the command that generated this error message without specifying the **lsusealm** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4254 Cmd Rej: SLKUSEALM allowed only for IPGWx and IPSG linksets

Commands Used: chg-ls, ent-ls

The **slkusealm** parameter cannot be specified for linksets that are not IPGWx or IPSG. The **ipgwapc=yes** or the **ipsg=yes** parameter must be specified before the **slkusealm** parameter can be specified.

Recovery

Re-enter the command that generated this error message without specifying the **slkusealm** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4255 Cmd Rej: Total system TPS limit exceeded

Commands Used: chg-ls, ent-ls, ent-slk

The total of the **iptps** parameter values for all linksets cannot exceed the systems maximum limit of 500,000 TPS. If **slktps** is specified with a larger-than-current value then the total capacity assigned to

any card hosting signaling link assigned to specified linkset must not exceed the total maximum capacity (5000 TPS) of the card .

Recovery

1. Display the System TPS in the database with the `rtrv-ctrl-feat` command.
Then display the IPTPS values for the existing linksets with the `rtrv-ls` command. (The error occurs when the sum of the provisioned System TPS plus the new TPS being defined is greater than the system TPS limit).
2. Perform one of the following solutions:
 - a) Reduce the TPS for other linksets with the `chg-ls` command, or
 - b) Reduce the TPS for the linkset that was being entered or changed, or
 - c) Obtain the key for more System TPS.

Note:

For information about expanding your System TPS limit, call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4256 Cmd Rej: TPS must be divisible by 10

Commands Used: `chg-ls`

The value specified for the `iptps` parameter must be divisible by 10.

Recovery

Re-enter the command, and specify a value for the `iptps` parameter that is divisible by 10. Refer to the *Commands Manual* for assistance.

E4257 Cmd Rej: Entity must be specified when Entity type is specified

Commands Used: `rtrv-data-rtdb`

For the `rtrv-data-rtdb` command, the entity parameter must be specified if the entitytype parameter is specified.

Recovery

Re-enter the `rtrv-data-rtdb` command specifying both the **entitytype** and **entity** parameters.

E4258 Cmd Rej: Target card is not a DSM card with VSCCP appl

Commands Used: `rtrv-data-insrv`, `rtrv-data-rtdb`, `tst-msg`

The card in the location specified by the `loc` parameter must be a Service Module card running the `vsccp` application (a DSM card or an E5-SM4G card).

Recovery

1. Display the cards in the system. Enter the `rtrv-card` command. Service Module cards running the `vsccp` application are identified by the entries DSM in the `TYPE` field and VSCCP in the `APPL` field in the `rtrv-card` command output.
2. Re-enter the command specifying the `loc` parameter of a Service Module card running the `vsccp` application.

E4259 Cmd Rej: Target card is not in Active state

Commands Used: `dbg-ddb`, `rtrv-data-gms`, `rtrv-data-rtdb`, `rtrv-data-insrv`, `tst-msg`

The card at the location specified by the `loc` or `rloc` parameter is not in an Active state. The specified target card must be in the Active state.

Recovery

1. Display the cards in the system. Enter the `rept-stat-card` command. The command output shows ACTIVE status cards in the Secondary State (SST) entries, Service Module cards in the `TYPE` field, and VSCCP applications in the `APPL` field.
2. Re-enter the command specifying a card location (`loc`) for a active Service Module card running the `vsccp` application.

E4260 Cmd Rej: Cluster DPCs can't inherit A or E linkset types

Commands Used: `ent-dstn`

Cluster destination point codes (DPCs) cannot inherit cluster members that have routes with A or E linkset types.

Recovery

Re-enter the `ent-dstn` command specifying a B, C, or D linkset type.

E4261 Cmd Rej: Point code is not configured for the specified Prepaid type

Commands Used: `chg-ppsopts`

The `pc`, `pca`, `pci`, or `pcn` parameter must be provisioned for the prepaid type specified by the `ppt` parameter before the `setid` parameter can be specified.

Recovery

1. Re-enter the command, and specify a valid combination of parameters. Refer to the *Commands Manual* for assistance.

2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4262 Cmd Rej: A specified SI value must be 3 for SUA

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`, `ent-as`

If specified, the service indicator (**si**) parameter must be (**si=3**) for routing keys that are associated with SUA Application Servers.

For SCCP MSU traffic, the routing key service indicator (**si**) value associated with an AS containing SUA ASPs must be 3 (SCCP) for the following key types:

- DPC-SI-SSN key
- DPC-SI key
- SI-only key

Recovery - `chg-appl-rtkey`, `ent-appl-rtkey`

Re-enter the command specifying **si=3**

Recovery - `ent-as`

1. Display the routing keys and **si** values.
Enter the `rtrv-appl-rtkey` command.
2. Assign a valid **si** value to the appropriate routing key.
Enter the `chg-appl-rtkey` command.
3. Re-enter the `ent-as` command to create the AS.

E4264 Cmd Rej: Parameter PCST / NPCST is not allowed with C for blocked SR

Commands Used: `chg/dlt/ent/rtrv-scr-aftpc`, `chg/dlt/ent/rtrv-scr-cdpa`,
`chg/dlt/ent/rtrv-scr-cgpa`, `chg/dlt/ent/rtrv-scr-blkdpc`,
`chg/dlt/ent/rtrv-scr-blkopc`, `chg/dlt/ent/rtrv-scr-destfld`,
`chg/dlt/ent/rtrv-scr-dpc`, `chg/dlt/ent/rtrv-scr-opc`

A command and parameter combination is not allowed:

- The command `ent-scr-blkopc` or `ent-scr-blkdpc` with combination of parameter **pcst** and subparameter **c** is not allowed for a blocked screening reference (SR).
- The command `chg-scr-blkopc` or `chg-scr-blkdpc` with combination of parameter **pcst** or **npcst** and subparameter **c** is not allowed for a blocked screening reference (SR).
- The parameter **pcst** cannot be used with an ANSI point code parameter (**ni**, **nc**, **ncm**) or with an ITU-N24 point code parameter (**sa**, **ssa**, **sp**).

Recovery

Re-enter the command specifying the correct parameter combination.

E4265 Cmd Rej: Network Appearance table full

Commands Used: `ent-na`

The Network Appearance table can contain a maximum of **45** entries.

Recovery

Call your Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4266 Cmd Rej: Channel bridged slave port is invalid for link provisioning

Commands Used: `ent-slk`

A channel bridged slave port (see the `chg-e1` or `chg-t1` command) cannot be specified as a value for the **e1port** or **t1 port** parameter.

Recovery

Re-enter the `ent-slk` command specifying a channel bridged master E1/T1 port. Refer to the *Commands Manual* for more information.

E4267 Cmd Rej: Invalid timing source for channel bridging

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

The **t1tsel=line** parameter cannot be specified for a T1 port (**t1port** parameter) when the **chanbrdg=on** parameter is specified.

The **e1tsel=line** parameter cannot be specified for an E1 port (**e1port** parameter) when the **chanbrdg=on** parameter is specified.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands

E4268 Cmd Rej: Cannot delete last route to DPC ref. in CSPC table

Commands Used: `dlt-rte`, `chg-dstn`

The last route to a destination point code that still exists in the Concerned Secondary Point Code (CSPC) table cannot be deleted until the point code is deleted from the CSPC table. If any of the

destinations referencing the routset exist in the CSPC table, then the last route of the routeset cannot be deleted.

Recovery

1. Display information about this route and the DPC it points to. Enter the `rept-stat-rte` command.
2. Delete the DPC references from the assigned CSPC group(s).
3. Re-enter the `dlt-rte` command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4269 Cmd Rej: No match on PCST parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the point code subtype (`pcst`) parameter.

Recovery

Enter the command specifying the screening reference to show all next screening function identifiers, as well as other values for the screening reference.

E4270 Cmd Rej: Failed reading Application Socket table

Commands Used: `enable-ctrl-feat`

The Application Socket table could not be read.

Recovery

1. Verify that an Application Socket table entry exists with the parameter values you specified.
Enter the `rtrv-appl-sock` command.
2. If an entry in the table does exist, re-enter the `enable-ctrl-feat` command that generated this error message.
3. Re-enter the `enable-ctrl-feat` command specifying different socket connection parameters.
4. Re-enter the `enable-ctrl-feat` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4271 Cmd Rej: TLNP and TINP cannot be in the same action set

Commands Used: `chg-gws-actset`

The `tinp` (Triggerless ISUP Number Portability) gateway screening stop action cannot be specified in the same action set with the `tlnp` (Triggerless LNP) gateway screening stop action.

Recovery

1. Display a list of gateway screening stop action sets and their contents. Enter the `rtrv-gws-actset` command.
2. Re-enter the command specifying the `tinp` stop action in a stop action set that does not contain the `tlnp` stop action, or specifying the `tlnp` stop action in a stop action set that does not contain the `tinp` stop action.

E4272 Cmd Rej: Maximum RContexts per AS exceeded

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`, `ent-as`

The AS is already associated with 4 different routing contexts (or 4 different routing keys with routing context).

Recovery

1. Display the routing keys and routing context values.
Enter the `rtrv-appl-rtkey:display=all` command.
2. Create an AS with new routing keys and routing context.
OR
3. Change the routing key routing context.
 - a) The routing context value in a routing key may only be changed if all of the ASPs associated with the routing key are **open=no**.
For SPLIT AS routing key changes, the old AS and the new AS must both meet this criteria.
 - b) The routing context value in a routing key may not be changed during the same command as a RESIZE or SPLIT routing key change.
 - c) A routing key containing a routing context may only be deleted if all of the ASPs associated with the routing key are **open=no**.

E4273 Cmd Rej: Private PC is only allowed for IPGWx linksets

Commands Used: `chg-ls`, `ent-ls`

Private (**p-**) and private and spare (**ps-**) point codes can only be assigned to IPGW linksets (the `ipgwapc=yes` parameter is specified).

Recovery

Determine the type of route. Enter the `rtrv-rte` command.

- If the route is a non-IPGW route, re-enter the command that generated this error message without specifying the private (**p-**) and private and spare (**ps-**) point codes.

OR

- If the route is an IPGW route. Re-enter the command specifying the correct private (**p-**) and private and spare (**ps-**) point codes.

E4274 Cmd Rej: Cannot mix Unchannelized and Channelized modes on E1/T1 card

Commands Used: `chg-e1`, `ent-e1`, `ent-t1`

Channelized and unchannelized T1 ports (mixed mode) cannot be specified on a single HC-MIM or E5-E1T1 card (the card cannot be used as a T1 card and an ST-HSL-A card at the same time).

Recovery

1. Verify the port setting for the card location in question.
Enter the `rtrv-e1` or `rtrv-t1` command.
2. Re-enter the command specifying the correct format and parameters.
Refer to the *Commands Manual* for detailed information about the use of these commands.

E4275 Cmd Rej: Cannot specify TS when Linkclass=Unchan

Commands Used: `ent-slk`

The **ts** parameter cannot be specified for HC-MIM or E5-E1T1 cards that are used for SE-HSL or ST-HSL-A links (the **linkclass=unchan** parameter is specified in the `ent-e1` or `ent-t1` command).

Recovery

1. Verify the E1PORT setting for the card location in question.
Enter the `rtrv-e1` command and verify the E1PORT setting for the card location in question.
2. Re-enter the **ent-slk** command specifying the correct format and parameters.
Refer to the *Commands Manual* for detailed information about the use of the `ent-slk` command.

E4276 Cmd Rej: BPS value not valid for Linkclass=Unchan

Commands Used: `ent-slk`

The value of the **bps** parameter must be **1984000** or **1536000** if the card is an HC-MIM or E5-E1T1 card used for SE-HSL or ST-HSL-A links (the **linkclass=unchan** parameter is specified in the `ent-e1` or `ent-t1` command) respectively.

Recovery

Re-enter the `ent-slk` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `ent-slk` command.

E4277 Cmd Rej: Linkclass=Unchan is not valid for this card type

Commands Used: `ent-e1`, `ent-t1`

The `linkclass=unchan` parameter can be specified only for HC-MIM and E5-E1T1 cards.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `ent-e1` and `ent-t1` commands.

E4278 Cmd Rej: APCNTYPE parameter is only valid for ITUN/ITUN24 link sets

Commands Used: `ent-ls`, `chg-ls`

You specified an adjacent point code value that is ANSI or ITUI, and specified the `apcntype` parameter. The `apcntype` parameter can be specified only for linksets that have an ITUN or ITUN24 adjacent point code defined for them in the same `ent/chg-ls` command.

The point code parameter must be `apcn` or `apcn24` (not `apc`, `apca`, or `apci`) when the `apcntype` parameter is specified in the same command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4279 Cmd Rej: Only IPGW routes are allowed for private PCs

Commands Used: `ent-rte`, `ent-rtx`, `chg-rte`

You cannot specify a private point code as the destination point code (`dpca`/`dpca`/`dpca`) for a non-IPGW route. A destination point code cannot be a private point code for a link set that is not an IP gateway route. Only IPGW routes are allowed for private point codes.

Recovery

Re-enter the command that generated this error message without specifying a **Private point code prefix**.

OR

Verify the route is an IPGW route. Enter the `rtrv-rte` command.

Re-enter the command specifying the Private point code prefix.

E4280 Cmd Rej: Alias PCs exceed Max allowed for Feature Quantity

Commands Used: `enable-ctrl-feat`

You cannot enable the 7000 Routesets feature and the 8000 Routesets feature because 8000 alias point codes are already assigned in the system.

Recovery

1. Display the number of provisioned aliases.
Enter the `rtrv-dstn` command.
2. If 8000 aliases are provisioned, use either `dlt-dstn` to delete destination point code entries or use `chg-dstn` to delete aliases (`chg-dstn=none`) for destination point codes until the number of provisioned aliases is less than 8000.
3. Verify less than 8000 aliases are provisioned.
Enter the `rtrv-dstn` command.
4. Enable the 7000/8000 Routesets feature.
Enter the `enable-ctrl-feat` command.

E4281 Cmd Rej: Specified link not supported for Linkclass=Unchan

Commands Used: `ent-slk`

If an HC-MIM card is used for SE-HSL or ST-HSL-A links, then only the **link=a** parameter or **link=b** parameter can be specified.

If an E5-E1T1 card is used for SE-HSL or ST-HSL-A links, then only the **link=a** parameter can be specified.

Recovery

1. Verify the E1 port setting for the card location in question.
Enter the `rtrv-e1` command.
2. Re-enter the `ent-slk` command specifying the correct parameter for the un-channelized links.
Refer to the *Commands Manual* for detailed information about the use of this command.

E4282 Cmd Rej: An HSL feature key must be enabled for Linkclass=Unchan

Commands Used: `ent-e1`, `ent-t1`

An SE-HSL feature quantity must be enabled before the **linkclass=unchan** parameter can be specified for an SE-HSL card.

An ST-HSL-A feature quantity (`enable-ctrl-feat` command) must be enabled before the `linkclass=unchan` parameter can be specified for an ST-HSL-A card.

Recovery

1. Display the feature status in the database.
Enter the `rtrv-feat` and the `rtrv-ctrl-feat` commands.
2. Enable the feature.
Enter the `enable-ctrl-feat` command and the appropriate part number and access key information. Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information.
3. Turn the SE-HSL feature on.
Enter the `chg-ctrl-feat` command.
4. When the feature is enabled and turned on, re-enter the command to provision the unchannelized links.

E4283 Cmd Rej: Command cannot be executed on a Telnet terminal

Commands Used: `act-file-trns`, `act-upgrade`, `lock`

The specified command cannot be issued from a Telnet terminal (terminal IDs 17 to 40). You cannot initiate an upgrade conversion from a Telnet terminal. You cannot initiate a transfer of files in the File Transfer Area from a Telnet terminal.

Recovery

1. The `lock` command is invalid and cannot be performed from a Telnet terminal.
2. For the `act-upgrade` command:
 - a) Display a list of valid terminal choices.
Enter the `rtrv-trm` command. If the entry in the TYPE column is telnet, the terminal is not a valid choice.
 - b) Re-enter the `act-upgrade` command specifying a valid (non-Telnet) value for the `trm` parameter.
Refer to the *Commands Manual* for detailed information about the use of the `act-upgrade` command.

E4284 Cmd Rej: CGPA entry can't be provisioned

Commands Used: `ent-gsmmap-scrn`

Your command to provision a CgPA entry was unsuccessful because the CgPA entry cannot be provisioned in the GSMSCRN table when only one entry space is available. Two spaces are required because a default wildcard CdPA entry is also automatically created for each CgPA entry you create.

Recovery

1. Delete at least two entries from the GSMSCRN table.
Enter the `dlt-gsmmap-scrn` command.
2. Re-enter the `ent-gsmmap-scrn` command to add the desired CgPA entry to the GSMSCRN table.

E4285 Cmd Rej: Enhanced GSM Map Screening feature must be ON

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-ls`, `ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-ls`

The Enhanced GSM MAP Screening (EGMS) feature must be on when certain parameters are specified. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* for information about the parameters that require the EGMS feature.

Note:

Once a Permanently On feature that is controlled using a feature access key is turned on, it cannot be turned off.

Recovery

1. Display the status of the EGMS feature in the database. Enter the `rtrv-ctrl-feat` command.
 - If the EGMS feature is enabled and turned on, re-enter the command that generated this message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
 - If the EGMS feature is not enabled, refer to the procedures in the *Database Administration Manual - Features* to enable, turn on, and use the EGMS feature.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
2. When the EGMS feature is on, re-enter the command that generated this message.

E4286 Cmd Rej: EADDR shouldn't be specified when SADDR = *

Commands Used: `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

You specified the `saddr=*` parameter, so the `eaddr` parameter is not needed and not allowed.

Recovery

Re-enter the command without specifying the `eaddr` parameter.

E4287 Cmd Rej: CDSR does not exist in the database

Commands Used: `chg-gsmmap-scrn`, `dlt-gsmmap-scrn`, `rtrv-gsmmap-scrn`

You entered a command containing an OPNAME and CGSR for which a CdPA Screening Reference (**cdsr**) does not exist.

Recovery

1. Enter the `rtrv-gsmmap-scrn` command to display the existing GSM MAP Screening CDSR entries.
2. Re-enter the command, and specify parameters identifying a **cdsr** appearing in the output of Step 1.

E4288 Cmd Rej: NCGSR shouldn't be specified when CDSR is specified

Commands Used: `chg-gsmmap-scrn`

If you specify the **cdsr** parameter, you cannot also specify the **ncgsr** parameter.

Recovery

Re-enter the `chg-gsmmap-scrn` command specifying either the **ncgsr** or the **cdsr** parameter, but not both.

E4289 Cmd Rej: (N)CGSR already exists for specified OPNAME

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`

You specified a CgPA Screening Reference (**cgsr**) or New CgPA Screening Reference (**ncgsr**) that already exists for the opname (user-defined name for Op-Code). The specified **ncgsr** parameter value cannot already exist in the database. If a CgPA entry is being created, the **cgsr** cannot already exist for the specified opname.

Recovery

1. Display the existing GSM MAP Screening CgPA entries.
Enter the `rtrv-gsmmap-scrn` command.
2. Re-enter the command specifying a value for the **cgsr** or **ncgsr** parameters that is not in the output from Step 1.

E4290 Cmd Rej: CDSR must be specified when NCDSR is specified

Commands Used: `chg-gsmmap-scrn`, `enable-ctrl-feat`

You cannot specify the **ncdsr** parameter without specifying the **cdsr** parameter.

Recovery

Re-enter the `chg-gsmmap-scrn` command and specify both the **cdsr** and **ncdsr** parameters.

E4291 Cmd Rej: Enhanced GSM Map Screening feature must be enabled

Commands Used: `dlt-gsmmap-scrn`, `enable-ctrl-feat`, `rtrv-gsmmap-scrn`,
`rtrv-gsms-opcode`

The command you entered requires the Enhanced GSM MAP Screening (EGMS) feature to be enabled.

The EGMS feature must be enabled, when the:

- **opcode** = *
- **cgpa** parameter is specified and is equal to *
- **cgpa** contains hex digits
- **cgds** is specified
- **cdpa** specific parameters are specified

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* for details about enabling features with access keys.

Recovery

1. Review the command and verify the need for the EGMS parameters.
If the EGMS parameters are not required, re-enter the command without them.
2. If the EGMS feature is required, display the status of the installed features with feature access keys.
Enter the `rtrv-ctrl-feat` command.
3. If the EGMS feature is enabled, re-enter the command.
4. If the EGMS feature is not enabled, verify the EGMS feature was purchased and installed in your system.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
5. Enable the EGMS feature.
Enter the `enable-ctrl-feat` command and the appropriate part number and access key information. Refer to the *Commands Manual* and the *Database Administration Manual - Features* for more information about enabling this feature.
6. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4292 Cmd Rej: SADDR must be specified when EGMS feature is OFF

Commands Used: `ent-gsmmap-scrn`, `enable-ctrl-feat`

You must specify the Starting Origination Address (**saddr**) parameter for the `ent-gsmmap-scrn` command when the Enhanced GSM MAP Screening (EGMS) feature is off.

Recovery

1. Display the status of the EGMS feature in the system. Enter the `rtrv-ctrl-feat` command.
2. Perform one of the following actions:
 - If the status of the EGMS feature is Off or the EGMS feature does not appear in the output from Step 1, re-enter the `ent-gsmmap-scrn` command and specify the `saddr` parameter.
 - If the status of the EGMS feature is On, the `saddr` parameter cannot be specified in the `ent-gsmmap-scrn` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4293 Cmd Rej: (N)CDSR already exists for specified CGSR

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`

You specified a CdPA Screening Reference (**cdsr**) or a new CdPA Screening Reference (**ncdsr**) that already exists for the CgPA Screening Reference (**cgsr**). The CdPA entry cannot be created because the specified **cdsr** or **ncdsr** already exists.

Recovery

1. Display the existing GSM MAP Screening CdPA entries.
Enter the `rtrv-gsmmap-scrn` command.
2. Re-enter the command specifying a value for the **cdsr** or the **ncdsr** parameter that is not in the output from Step 1.

E4294 Cmd Rej: Meas for Enh GSM MAP Screening not supported on EOAM

Commands Used: `rept-meas`

When the Enhanced GSM MAP Screening (EGMS) feature is turned on, this command cannot be used to generate EGMS measurements reports.

Recovery

Enter the `rept-ftp-meas` command.

Refer to the *Commands Manual* for detailed information about the use of this command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4295 Cmd Rej: The FEATURE/ANSIGFLEX option combination is invalid

Commands Used: `chg-stpopts`, `enable-ctrl-feat`, `chg-ctrl-feat`

A feature is enabled or turned on that is mutually exclusive with the **ansigflex** system option. For a list of valid parameters, refer to the *Commands Manual*.

Recovery

1. Display the status of the ANSIGFLEX system option. Enter the `rtrv-stpopts` command.
2. Display the status of the enabled features. Enter the `rtrv-ctrl-feat` command.
3. If the ANSIGFLEX system option is enabled (**ansigflex=yes**), verify whether the features from Step 2 are enabled. If any of the features are enabled, then the ANSIGFLEX system option cannot be provisioned.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4296 Cmd Rej: SRVSEL of ITU found, but not allowed with ANSIGFLEX

Commands Used: `chg-stpopts`

The **ansigflex** option cannot be enabled when Service Selector table contains an ITU entry. (See the `chg-srvsel` command.) The ANSI G-Flex at 1700 TPS feature supports only ANSI systems.

Recovery

If the service selector specifies an ITU entry, perform one of the following actions:

- Re-enter the `chg-stpopts` command without specifying the **ansigflex=yes** parameter
- OR
- Delete ITU service selectors from the SRVSEL for the DSM, and then re-enter the `chg-stpopts:ansigflex=yes` command.

E4297 Cmd Rej: ITU entries not allowed when ANSIGFLEX is on

Commands Used: `chg-srvsel`, `ent-srvsel`

You cannot specify any ITU service selector entries if **ansigflex=yes**. The ANSI G-Flex at 1700 TPS feature is mutually exclusive with any ITU entries.

Recovery

You cannot specify an ITU entry if the **ansigflex=yes** parameter has been specified for the system.

1. Disable the **ansigflex** system option.
Enter the `chg-stpopts:ansigflex=no` command.

2. Re-enter the command specifying ITU service selector.

E4298 Cmd Rej: Alias PC table is full

Commands Used: `chg-dstn`, `ent-dstn`

You cannot provision more than **8000** entries in the Alias PC table. If the 8000 Routesets feature key is enabled, a maximum of **8000** alias PCs entries can be provisioned.

Recovery

1. Display the number of provisioned aliases in the Alias PC table.
Enter the `rtrv-dstn` command.
2. If 8000 entries are provisioned, perform one of the following actions:
 - a) Delete destination point code entries until the number of provisioned aliases is less than **8000**.
Enter the `dlt-dstn` command. OR
 - b) Delete aliases for destination point codes until the number of provisioned aliases is less than **8000**.
Enter the `chg-dstn=none` command.
3. Re-enter the command that generated this error message.

E4299 Cmd Rej: Cannot enter a wildcard with XLAT=2, Use XLAT=4 for wildcard

Commands Used: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`

If you specify `gtixlat=22` and `dir=itoa`, you cannot also use a wildcard entry. You can, however, use a wildcard entry and `dir=itoa` if you specify `gtixlat=24`.

Recovery

Re-enter the command specifying a wildcard entry and `dir=itoa`, if you specify `gtixlat=24`.

E4300 Cmd Rej: Conns cannot exist in rtkeys with and without rcontext

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`

An attempt was made to enter or change the routing context value of a routing key value already associated with an AS that is not allowed. An AS cannot be simultaneously assigned to routing keys with routing contexts and to routing keys without routing contexts. All the routing key(s) associated with an AS must either have routing contexts or all the routing key(s) associated with an AS must not have routing contexts.

Recovery `chg-appl-rtkey`, `ent-appl-rtkey`

1. Enter the `rtrv-appl-rtkey:display=all` command to display the routing keys and routing context values.
2. Determine if the routing key you wish to create or change is assigned to an AS.
3. If the routing key is already assigned to an AS, re-enter the command specifying an appropriate routing context value for the routing key.
4. If you wish to assign the routing key to an AS, re-enter the command ensuring that either (1) all the routing key(s) associated with an AS have routing contexts, or (2) all the routing key(s) associated with an AS have no routing contexts.
5. If the routing key is already assigned to an AS and you wish to delete the routing context, you must first delete all routing keys associated with the AS and then re-enter routing keys without routing context values for the AS. The last RTKEY assigned to an AS cannot be deleted unless all associations in the AS provisioned for the RTKEY are OPEN=NO.

Recovery `rtrv-data-gms`

Perform one of the following actions:

- Re-enter the `rtrv-data-gms` command specifying both the `cgds` and `cgpa` parameters.
- OR
- Re-enter the `rtrv-data-gms` command specifying both the `cdds` and `cdpa` parameters.

E4301 Cmd Rej: PCx specified does not exist as a True Point Code

Commands Used: `chg-sid`

The specified point code does not exist as a True Point Code (STP destination point code). The PCI /PCN value specified must already exist as an STP destination point code.

The card specified by the `loc` parameter must either be a DSM card running the VSCCP APPL, or a TSM card running the SCCP APPL.

Recovery `chg-sid`

1. Determine the STP self-identity destination point code, CLLI, and capability point codes associated with the STP in its active database. Enter the `rtrv-sid` command.
2. Verify the PCx value exists. The PCx value must exist to use the `chg-sid` command.
Refer to the specific command and "*Point Code Formats and Conversion*," in the *Commands Manual* for information on the correct values.
3. Re-enter the `chg-sid` command specifying a valid PCx value.

E4302 Cmd Rej: NPCx cannot be specified without PCx

Commands Used: `chg-sid`

For the `chg-sid` command:

- If you specify the **npci** parameter, you must also specify the **pci** parameter.
- If you specify the **npcn** parameter, you must also specify the **pcn** parameter.

Recovery

Re-enter the `chg-sid` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `chg-sid` command.

E4317 Cmd Rej: Failed reading VENDID table

Commands Used: `ent-vendid`, `dlt-vendid`, `rtrv-vendid`

The Vendor ID table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4318 Cmd Rej: VENDID already exists in VENDID table

Commands Used: `ent-vendid`

The specified ID entry is already present in the Vendor ID table. To change vendor information, you must first delete the vendor ID and create a new one.

Recovery

Re-enter the `ent-vendid` command specifying a different ID.

OR

1. Display the entries in the Vendor ID table.
Enter the `rtrv-vendid` command.
2. Delete an entry before creating a new entry.
Enter the `dlt-vendid` command.
3. Create a new entry.
Enter the `ent-vendid` command.

E4319 Cmd Rej: VENDID does not exist in VENDID table

Commands Used: `dlt-vendid`

The specified vendor ID entry does not exist in the Vendor ID table.

Recovery

1. Display the entries in the Vendor ID table.
Enter the `rtrv-vendid` command.
2. Re-enter the `dlt-vendid` command specifying the appropriate vendor ID.

E4320 Cmd Rej: SRI Redirect Feature must be enabled

Commands Used: `chg-prefix`, `ent-vendid`, `rtrv-vendid`

The GSM MAP SRI Redirect feature must be enabled before:

- A GSM MAP SRI Redirect prefix can be defined.
- The `ent-vendid` command and the `rtrv-vendid` command can be entered.

Note: Once a Permanently On feature that is controlled using a feature access key is turned on, it cannot be turned off.

Recovery

1. Display the status of the GSM MAP SRI Redirect feature in the database. Enter the `rtrv-ctrl-feat` commands.
2. If the GSM MAP SRI Redirect feature does not appear in the output of Step 1:
 - a) Refer to the procedure in the Database Administration Manual - Features to enable the GSM MAP SRI Redirect feature.
 - b) Re-enter the command that generated this message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4321 Cmd Rej: All VENDID table entries must be of length VENDIDLEN

Commands Used: `ent-vendid`

All vendor ID entries must be of the specified length value for `VENDIDLEN`. `VENDIDLEN` determines the allowed length for all Vendor ID values and must be entered before any `VEND=Vendor ID` value is allowed.

As long as there are no entries in the VendID list, `VENDIDLEN` may be changed.

Recovery

1. Use `rtrv-vendid` to display the `VENDIDLEN` in the vendor ID table.
2. Re-enter the `ent-vendid` command specifying the appropriate `VENDIDLEN` for the vendor ID.

E4322 Cmd Rej: VENDIDLEN may only be changed if VENDID table is empty

Commands Used: `ent-vendid`

The VENDIDLEN value may only be changed if the Vendor ID list is empty. VENDIDLEN determines the allowed length for all Vendor ID values and must be entered before any VEND=Vendor ID value is allowed.

Recovery

Re-enter the command specifying the appropriate VENDIDLEN.

OR

1. Display the Vendor ID table.
Enter the `rtrv-vendid` command.
2. Delete all Vendor ID table entries.
Enter the `dlt-vendid` command.
3. Create a new VENDIDLEN value, then create a new Vendor ID table entries.
Enter the `ent-vendid` command.

E4323 Cmd Rej: Invalid condition value comparison for CA or CB register.

Commands Used: `ent-bp`

The condition value specified for comparison of the CA or CB registers is invalid.

Recovery

Re-enter the `ent-bp` command specifying a valid set of condition values.

Refer to the *Commands Manual* for detailed information about the use of the `ent-bp` command.

E4325 Cmd Rej: ELAP architecture does not support LNP quantity requested

Commands Used: `enable-ctrl-feat`

You cannot enable 192 Million LNP feature because the ELAP version installed does not support the quantity requested by the feature. To enable the 192 Million LNP feature, the installed ELAP version must be 5.0 or higher.

Recovery

1. Enter the `rept-stat-mps` command to determine the ELAP version installed.
2. If the installed ELAP version is not 5.0 or higher, you must upgrade the software level.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. If the installed ELAP version is 5.0 or higher (or after the software has been upgraded), enter the appropriate ELAP commands to convert the 120 Million database structure to the data compaction structure for 192 Million numbers.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.

4. Re-enter the `enable-ctrl-feat` command specifying the appropriate part number (893011020) and access key information to enable the 192 Million LNP feature.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4326 Cmd Rej: ELAP must be available to verify LNP quantity support

Commands Used: `enable-ctrl-feat`

You cannot enable an LNP feature greater than 96 Million because no ELAP is currently available. To enable LNP quantities above 96 Million, an ELAP must be available to validate its software version.

Recovery

1. Determine if ELAP is installed.
Enter the `rtrv-ctrl-feat` command.
2. If ELAP is not installed, contact your Customer Care Center for assistance.

Note:

The LNP feature cannot be enabled if the GPORT, GFLEX, or INP features are on. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.

3. After ELAP is installed and configured, re-enter the `enable-ctrl-feat` command specifying the appropriate part number and access key information to enable the LNP feature.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4327 Cmd Rej: For VENDNUM specified the prefix is not provisioned

Commands Used: `ent-vendid`

For the vendor number specified, the prefix for feature GSM MAP SRI Redirect is not provisioned.

Recovery

1. Use `chg-prefix` to provision a prefix for the GSM MAP SRI Redirect feature.

2. Re-enter the `ent-vendid` command that generated this message.

E4328 Cmd Rej: IS412GSM must be provisioned before SERVERPFX

Commands Used: `chg-gsmopts`

The IS-41-to-GSM Migration parameter, `chg-gsmopts:is412gsm=x`, must be provisioned before specifying the **serverpfx** parameter.

Recovery

1. Use `chg-gsmopts` to provision `is412gsm`.
2. Re-enter the `chg-gsmopts` command to specifying the **serverpfx** parameter.

E4329 Cmd Rej: Set SERVERPFX to NONE before disabling IS412GSM

Commands Used: `chg-gsmopts`

The **serverpfx** parameter must be set to **none** before you can disable IS-41-to-GSM Migration feature

Recovery

1. Enter the `chg-gsmopts` command to set **serverpfx=none**.
2. Re-enter the `chg-gsmopts` command to disable **is412gsm**.

E4330 Cmd Rej: Network Address conflicts with IP Route Table

Commands Used: `chg-netopts`

The IP Network address specified by the **pvn** and **pvnmask** parameters or the **fcna** and **fcnbn** parameters cannot have an existing route in the IP Route table.

Recovery

1. Display the IP Route Table.
Enter the `rtrv-ip-rte` command.
2. Delete the conflicting IP route.
Enter the `dlt-ip-rte` command.
3. Re-enter the `chg-netopts` command.

E4331 Cmd Rej: Specified network addr assigned to a IP card Ethernet Port

Commands Used: `chg-netopts`

The IP network address specified by the **pvn** and **pvnmask** parameters or the **fcna** and **fcnb** parameters must be different from the IP network addresses assigned to Ethernet interface A or B for the IPGWx, IPLIMx, and FC-capable cards.

Recovery

Re-enter the `chg-netopts` command specifying a different network address.

E4332 Cmd Rej: The specified network address is assigned to PVN/FCNA/FCNB

Commands Used: `chg-ip-lnk`

The IP network address specified by the **ipaddr** and **submask** parameters must be different from the IP and fast copy network address specified by the **pvn** and **pvnmask**, **fcna** and **fcnamask**, and **fcnb** and **fcnbmask** parameters in the NETOPTS table.

Recovery

Re-enter the `chg-ip-lnk` command specifying IP network addresses that are not the same for the PVN, FCNC or FCNB.

E4333 Cmd Rej: The specified IP route is assigned to PVN/FCNA/FCNB

Commands Used: `ent-ip-rte`

The network address specified by the **dest** and **submask** parameters must be different from the network address specified by the **pvn** and **pvnmask**, **fcna** and **fcnamask**, and **fcnb** and **fcnbmask** parameters of the NETOPTS table.

Recovery

Re-enter the `ent-ip-rte` command specifying a different network address. Use the `dlt-ip-rte` or `chg-netopts` command to resolve the conflicting network address.

E4334 Cmd Rej: Requires C-linksets parameter **tfatcabmlq** to be set to 0

Commands Used: `chg-ss7opts`

The TFA/TCA Broadcast Minimum Link Quantity (**tfatcabmlq**) parameter for one or more C-linksets is not set to 0. The linkset restrict (**lsrestrict**) parameter cannot be set to **off** until the **tfatcabmlq** parameter for all C-linksets is set to 0.

You can change the default value of **tfatcabmlq** in C-linksets after the **lsrestrict** is turned **on**. The value of **tfatcabmlq** in any C-linkset it must be set to 0 before the **lsrestrict** option can be turned **off**. You cannot set the **lsrestrict** option to **off** until you set all C linkset **tfatcabmlq** values back to 0.

When the **lsrestrict** option is **on**, the **tfatcabmlq** parameter value for C linksets can be changed to a non-zero value (see the `chg-ls` command). If the **tfatcabmlq** parameter in any C linkset has been

changed to a non-zero value, the **tfatcabmlq** value must be set back to **0** for all C linksets before the **lsrestrict** option can be turned **off**.

Recovery

1. Display all linksets.
Enter the `rtrv-ls` command. C-linksets are identified with a **C** in the LST field.
2. For all C-linksets, set **tfatcabmlq=0**.
Enter the `chg-ls` command.
3. Re-enter the `chg-ss7opts` command to turn off **lsrestrict**.

E4336 Cmd Rej: TINP and CNCF cannot be in the same action set

Commands Used: `chg-gws-actset`

The `tinp` (Triggerless ISUP NP) gateway screening stop action cannot be specified in the same action set with the `cnf` (Calling Name Conversion Facility) gateway screening stop action.

Recovery

- Display a list of gateway screening stop action sets and their contents. Enter the `rtrv-gws-actset` command.
- Re-enter the command specifying the `tinp` stop action in a stop action set that does not contain the `cnf` stop action, or specifying the `cnf` stop action in a stop action set that does not contain the `tinp` stop action.

E4339 Cmd Rej: Common screening list feature invalid

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`, `rtrv-csl`, `rtrv-ctrl-feat`

The common screening list feature specified is not valid. The specified feature name must be valid for a feature that uses a Common Screening List. The feature name must be specified as it appears in the `rtrv-ctrl-feat` command output example. Enough of the name must be specified to make the name unique when two features begin with the same word or acronym.

The following features use a Common Screening List:

- IDP Screening for Prepaid
- Prepaid IDP Query Relay
- VFLEX
- MO-based GSM SMS NP
- MO-based IS41 SMS NP

Recovery

1. Verify how the name appears in the `rtrv-ctrl-feat` output.
2. Re-enter the command specifying the correct name as specified in the output from Step one.
3. Refer to the *Commands Manual* for detailed information about the use of these commands if necessary.

E4340 Cmd Rej: Common screening list key invalid

Commands Used: `chg-csl`, `ent-csl`

The parameter specified for the common screening list key is invalid. Refer to the command descriptions in the *Commands Manual* for a list of valid screening list parameters.

Recovery

1. Display the provisioned screening list values. Enter the `rtrv-csl` command.
2. Re-enter the command specifying valid screening list parameters.

E4342 Cmd Rej: Feature Prefix too short

Commands Used: `chg-prefix`

The feature prefix specified has a length that is less than the minimum prefix-length requirements for that feature-type. The length of the specified feature prefix is too short.

The specified prefix value must contain a number of digits that is equal to or greater than the minimum number of digits required by the specified feature.

Recovery

Re-enter the `chg-prefix` command specifying a feature prefix of the correct length.

E4343 Cmd Rej: Feature Prefix too long

Commands Used: `chg-prefix`

The specified feature prefix length is greater than the maximum prefix-length requirements for that feature-type. The length of the specified feature prefix is too long.

The specified prefix value must contain a number of digits that is equal to or less than the maximum number of digits required by the specified feature.

Recovery

Re-enter the `chg-prefix` command specifying the correct prefix length.

E4344 Cmd Rej: Maximum allowed Prefix values already entered for feature

Commands Used: `chg-prefix`

The maximum number of prefixes are already defined for the feature. Refer to the *Commands Manual* for information on the number of allowed prefixes for a feature.

Recovery

1. Display the provisioned prefix information for all features.
Enter the `rtrv-prefix` command.
2. Delete an entry based on the name of the feature, its Prefix, and PrefixNum value.
Enter the `dlt-prefix` command.
3. Re-enter the `chg-prefix` command to enter a different feature prefix.

E4345 Cmd Rej: Feature Prefix already exists

Commands Used: `chg-prefix`

The specified feature prefix already exists. To add or change a prefix, you must first delete a prefix.

Recovery

Re-enter the `chg-prefix` command specifying a different feature prefix.

OR

1. Display the provisioned prefix information for all features.
Enter the `rtrv-prefix` command to display the provisioned prefix information for all features.
2. Delete an entry based on the name of the feature, its Prefix, and PrefixNum value.
Enter the `dlt-prefix` command.
3. Re-enter the `chg-prefix` command to enter a different feature prefix.

E4346 Cmd Rej: FEATPFX table full

Commands Used: `chg-prefix`

The feature FEATPFX table is full. A maximum of **256** entries is allowed. The FEATPFX table cannot be full when a new entry is added. To add or change a prefix, you must first delete a prefix.

Recovery

1. Display the provisioned prefix information for all features.
Enter the `rtrv-prefix` command.
2. Delete an entry from the FEATPFX table based on the name of the feature, its Prefix, and PrefixNum value.
Enter the `dlt-prefix` command.
3. Re-enter the `chg-prefix` command to enter a different feature prefix.

E4347 Cmd Rej: Feature Name is not valid

Commands Used: `chg-prefix`, `dlt-prefix`, `rtrv-prefix`

The specified feature name must be the name of an enabled controlled feature as it is displayed in the `rtrv-ctrl-feat` command output; The specified feature must be one of the following features that are supported by this command:

- GSM MAP SRI Redirect
- ISUP NP for EPAP

Recovery

Re-enter the command specifying a valid feature name.

E4348 Cmd Rej: Feature Prefix Number invalid

Commands Used: `chg-prefix`

The value specified for the **prefixnum** parameter is not valid. The specified prefix number (**prefixnum**) must be valid for the specified feature.

Recovery

Re-enter the `chg-prefix` command specifying a valid **prefixnum** parameter value.

E4349 Cmd Rej: Feature Prefix still in use

Commands Used: `dlt-prefix`

The prefix is being used by another feature. The prefix value or prefix number is associated with a feature with a different name.

Recovery

Re-enter the `dlt-prefix` command specifying a valid **feature** name.

E4350 Cmd Rej: Feature Prefix not found

Commands Used: `dlt-prefix`

The feature prefix specified is not in the FEATURE_PREFIX table.

Recovery

Re-enter the `dlt-prefix` command specifying a valid feature prefix.

E4351 Cmd Rej: Telnet Feature must be enabled

Commands Used: `enable-ctrl-feat`

The Telnet feature must be enabled before the SEAS Over IP feature can be enabled.

Recovery

1. Display the status of controlled features in the system by entering the `rtrv-ctrl-feat` command
2. If the Telnet feature is not enabled, or not shown in the output from Step 1, refer to the *Database Administration Manual - Systems Management* for assistance in enabling the feature.
3. To enable the SEAS Over IP feature, refer to the *Database Administration Manual - Systems Management* for assistance.

E4352 Cmd Rej: SUBNETID table is full

Commands Used: `ent-subnetid`

The Subnet ID table maximum allowed number of entries is 50. To add a new entry, you must first delete an existing entry.

Recovery

1. Display the Subnet ID table information.
Enter the `rtrv-subnetid` command.
2. Delete a Subnet ID table entry.
Enter the `dlt-subnetid` command.
3. Re-enter the `ent-subnetid` command to enter a different subnet ID.

E4353 Cmd Rej: Failed reading SUBNETID table

Commands Used: `ent-subnetid`, `dlt-subnetid`, `rtrv-subnetid`

The Subnet ID table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4354 Cmd Rej: SUBNETID already exists in SUBNETID table

Commands Used: `ent-subnetid`

The specified Subnet ID entry already exists in the Subnet ID table. To add a new entry you must first delete (or change) an existing Subnet ID table entry.

Note:

Up to 50 Subnet ID entries can be entered into the Subnet ID table.

Recovery

Re-enter the `ent-subnetid` command specifying a different **subnetid** value.

OR

1. Display the Subnet ID table.
Enter the `rtrv-subnetid` command.
2. Change an existing Subnet ID entry.
Enter the `chg-subnetid` command. OR
3. Display the Subnet ID table.
Enter the `rtrv-subnetid` command.
4. Delete an existing Subnet ID entry.
Enter the `dlt-subnetid` command.
5. Add the new Subnet ID entry.
Enter the `ent-subnetid` command.

E4355 Cmd Rej: SUBNETID does not exist in SUBNETID table

Commands Used: `dlt-subnetid`

The specified Subnet ID entry is not in the Subnet ID table.

Recovery

1. Display the Subnet ID table. Enter the `rtrv-subnetid` command.
2. Re-enter the `dlt-subnetid` command specifying a valid Subnet ID entry.

E4356 Cmd Rej: ISUP NP with EPAP feature must be enabled

Commands Used: `chg-prefix`, `ent-subnetid`, `rtrv-subnetid`

The ISUP NP with EPAP feature must be enabled before:

- An ISUP NP with EPAP prefix can be defined.
- The `ent-subnetid` command and the `rtrv-subnetid` command can be entered.

Recovery

1. Display the status of the ISUP NP with EPAP feature in the database. Enter the `rtrv-ctrl-feat` command.
2. If the ISUP NP with EPAP feature does not appear in the output from Step 1, refer to the procedures in the *Feature Manual - G-Port* to enable the ISUP NP with EPAP feature.
3. Re-enter the command that generated this message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4357 Cmd Rej: All SUBNETID table entries must be of length SUBNETIDLEN

Commands Used: `ent-subnetid`

All subnet ID entries must be of the length (number of digits) specified by **subnetidlen** parameter. The **subnetidlen** parameter defines the allowed length for all **subnetid** parameter values, and must be entered first, before the command is entered the second time to enter the Subnet ID and Subnet Number.

If there are no entries in the Subnet ID table, the value of the **subnetidlen** parameter may be changed.

Recovery

1. Determine the value of the **subnetidlen** parameter.
Enter the `rtrv-subnetid` command.
2. Re-enter the `ent-subnetid:subnetidlen=xx` command specifying a value for `xx` from the output of Step 1.
3. Add the Subnet ID and Subnet Number entries to the Subnet ID table.
Re-enter the `ent-subnetid` command specifying the appropriate number of digits for all **subnetid** parameter values, as specified by the **subnetidlen** parameter. Example:
`ent-subnetid:subnetidlen=6 ent-subnetid : subnetid = 886933 : subnet num=`
`1`

E4358 Cmd Rej: SUBNETIDLEN may only be changed if SUBNETID table is empty

Commands Used: `ent-subnetid`

The **subnetidlen** value may only be changed if the Subnet ID table is empty. The **subnetidlen** parameter determines the allowed length (number of digits) for all subnet ID values and must be entered before any subnet ID value can be entered.

Recovery

If the Subnetid table is empty, re-enter the command specifying the appropriate **subnetidlen**.

OR

1. Display the entries in the Subnet ID table.
Enter the `rtrv-subnetid` command.
2. Delete all entries in the Subnet ID table.
Enter the `dlt-subnetid` command.
3. Specify a new **subnetidlen** value.
Enter the `ent-subnet:subnetidlen=xx` command where `xx` is any value from **1-15**.
4. Add the Subnet ID and Subnet Number entries to the Subnet ID table.
Re-enter the `ent-subnetid` command specifying the appropriate number of digits for all **subnetid** parameter values, as specified by the **subnetidlen** parameter. Example:
`ent-subnetid:subnetidlen=9 ent-subnetid : subnetid = 886445933 : subnet num= 1`

E4359 Cmd Rej: For SUBNETNUM specified the prefix is not provisioned

Commands Used: `ent-subnetid`

The specified subnet number is not provisioned for the ISUP NP with EPAP feature prefix number.

For the ISUP NP with EPAP featureThe **subnetnum** parameter value corresponds to a previously defined entry in the Prefix table that matches the **prefixnum** parameter value and provides a reference to the **prefixnum**.

Recovery

1. Provision a prefix for the ISUP NP with EPAP feature.
Enter the `chg-prefix` command.
2. Re-enter the **ent-subnetid** command that generated this message.

E4360 Cmd Rej: VENDIDLEN must be set before Vendor ID may be entered

Commands Used: `ent-vendid`

The **vendidlen** value must be specified before any Vendor ID may be entered. The **vendidlen** parameter determines the allowed length (number of digits) for all Vendor ID values and must be entered before any **vendorid** entries.

Recovery

1. Specify a value for the **vendoridlen** parameter.
Enter the `ent-vendid:vendidlen=x` command where `x` is a value from **1-15** digits.

2. Re-enter the `ent-vendid` command to enter vendor ID values.

E4361 Cmd Rej: Enter param VENIDLEN, or params VENDID, VENDNUM and VENDTYPE

Commands Used: `ent-vendid`

The `ent-vendid` command is used to enter elements into the Vendor ID table, for the GSM MAP SRI Redirect to Serving HLR (aka GSM MAP SRI Redirect) feature.

The **vendidlen** parameter cannot be specified in the same command with the **vendid**, **vendidlen**, and **vendtype** parameters. Either the **vendidlen** parameter, or the **vendid**, **vendidlen**, and **vendtype** parameters can be specified in one command.

Recovery

Perform one of the following actions:

- Re-enter the `ent-vendid` command specifying the **vendidlen** parameter.
- OR
- Re-enter the `ent-vendid` command specifying the **vendid**, **vendidlen**, and **vendtype** parameters.

E4362 Cmd Rej: SUBNETDLEN must be set before Subnet ID may be entered

Commands Used: `ent-subnetid`

The **subnetidlen** value must be specified before any subnet ID may be entered. The **subnetidlen** determines the allowed length (number of digits) for all subnet ID values and must be specified before any **subnetid** value can be specified.

Recovery

1. Specify a value for the **subnetidlen** parameter.
Enter the `ent-subnet:subnetidlen=xx` command where *xx* is any value from 1-15.
2. Re-enter the `ent-subnetid` command to enter subnet ID values.

E4363 Cmd Rej: Enter params SUBNETIDLEN or paramrs SUBNETID and SUBNETNUM

Commands Used: `ent-subnetid`

The **subnetidlen** parameter cannot be specified in the same command with the **subnetid** and **subnetnum** parameters. Either the **subnetidlen** parameter, or the **subnetid** and the **subnetnum** parameters can be specified in one command.

Recovery

Perform one of the following actions:

- Re-enter the `ent-subnetid` command specifying the **subnetidlen** parameter.
- OR
- Re-enter the `ent-subnetid` command specifying the **subnetid** and the **subnetnum** parameters.

E4364 Cmd Rej: Failed reading FEATPFX

Commands Used: `chg-prefix`, `dlt-prefix`, `rtrv-prefix`

The FEATPFX table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4365 Cmd Rej: Either TLNP or ISUP NP with EPAP must be enabled

Commands Used: `chg-gws-actset`

To provision a Gateway Screening TLNP stop action, either the Triggerless LNP (TLNP) feature must be turned on, or the ISUP NP with EPAP feature must be enabled.

Recovery

1. Display the status of controlled features in the database. Enter the `rtrv-feat` and `rtrv-ctrl-feat` commands.
2. If the TLNP feature is turned on, or the ISUP NP with EPAP feature is enabled, re-enter the `chg-gws-actset` command that generated this message.
3. If the TLNP feature is turned off or the ISUP NP with EPAP feature does not appear in the output from Step 1, refer to the procedures in the *Database Administration Manual - Gateway Screening* for provisioning and using the TLNP stop action.
4. Re-enter the `chg-gws-actset` command that generated this message.
5. Re-enter the `chg-gws-actset` command that generated this message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Note: Once a feature that is controlled with a feature bit is turned on, it cannot be turned off. Once a Permanently On feature that is controlled using a feature access key is turned on, it cannot be turned off.

E4366 Cmd Rej: DEV type is not supported by specified location

Commands Used: `inh-alm`, `unhb-alm`

You specified a card location that does not support the device type specified. The `loc` parameter must be specified if the device `dev=card`, `slk`, `dlk`, `e1port`, or `t1port` parameter is specified. The specified device type must be supported by the card in the specified card location.

Refer to the command description in the *Commands Manual* for valid parameter combinations for the `inh-alm` command.

The `dur` and `lvl` parameters are valid with all `dev` parameter values.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4367 Cmd Rej: Cannot change network domain to anything other than CROSS

Commands Used: `chg-gttset`

You cannot specify any other values for the network domain (`netdom`) parameter other than `cross`.

Recovery

Re-enter the `chg-gttset` command specifying `netdom=cross`.

E4368 Cmd Rej: The specified CMD cannot be assigned a configurable class

Commands Used: `chg-cmd`

The specified command cannot be assigned to a configurable class.

The `login` command is rejected as a parameter. The `login` command is available to all users, and cannot be assigned to a configurable class.

Recovery

Re-enter the `chg-cmd` command.

Refer to the *Commands Manual* for detailed information about the use of the `chg-cmd` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4369 Cmd Rej: Cannot assign APC with exception routes to linkset

Commands Used: `ent-rtx`

You cannot provision exception routes for adjacent point codes. Adjacent point codes cannot have exception routes.

Recovery

Re-enter the `ent-rtx` command specifying a point code value that is not an adjacent point code.

E4370 Cmd Rej: Level 1 Alarm Threshold level must be less than Level 2

Commands Used: `chg-th-alm`

You specified an incorrect value for either the Level 1 or Level 2 Threshold Alarms. The setting for the Level 1 alarm threshold must be less than the setting for the corresponding Level 2 alarm threshold.

Note:

HC-MIM cards have a thermal operating limit of 82 degrees C. E5-E1T1 and E5-ENET cards have a thermal operating limit of 99 degrees C. Thermal threshold values represent a percentage of the thermal operating limit of a card.

Recovery

Re-enter the `chg-th-alm` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `chg-th-alm` command.

E4371 Cmd Rej: GPORT must be enabled

Commands Used: `enable-ctrl-feat, chg-gsmopts`

The G-Port feature must be enabled before the following features can be enabled:

- MT-Based GSM SMS NP
- G-Port SRI Query for Prepaid

The G-Port feature must be enabled before the `sriddnotfound` parameter can be specified.

Recovery

1. Display the status of the enabled features. Enter the `rtrv-ctrl-feat` command.
If the G-Port feature is not shown in the output, then the feature is not enabled.
2. Enable the G-Port feature. Refer to the *Feature Manual - G-Port* for assistance.
3. Enable the MO-Based GSM SMS NP or the MT-based GSM SMS NP feature. Refer to the *Feature Manual - MO SMS* or the *Feature Manual - G-Port* for assistance.

E4374 Cmd Rej: Association in maximum allowed application servers

Commands Used: `ent-as`

The maximum number of adapter states (M3U/SUA associations) for a single SS7IPW or IPGWI card is 50. You must either select a different AS or delete or change the association assigned to the desired AS.

Recovery

Re-enter the `ent-as` command specifying a different AS.

Refer to the *Commands Manual* for detailed information about the use of the `ent-as` command.

OR

1. Display the AS and its associations.
Enter `rtrv-as` command.
2. Delete or change the association for the AS.
Enter either the `dlt-assoc` or `chg-assoc` commands.

E4375 Cmd Rej: Route Exception already exists for input parameters

Commands Used: `chg-rtx`, `ent-rtx`

A Route table entry already exists for the specified parameters. An exception route entry cannot already exist with the same input parameter values, other than the relative cost.

Recovery

1. Display the Route table entries.
Enter the `rtrv-rte` command.
2. Re-enter the command specifying a different set of parameters.

E4376 Cmd Rej: Maximum matching Route Exceptions already exist for DPC

Commands Used: `chg-rtx`, `ent-rtx`

The 6-Way Loadsharing on Routesets feature must be turned on before more than 2 routes can be provisioned with the same relative cost for a given exception route criteria.

Recovery

Perform one of the following actions:

- Re-enter the command specifying a different set of exception route parameters.

OR

- Delete one of the existing exception routes. Enter the `dlt-rtx` command.
- Re-enter the command that generated this error message.

E4377 Cmd Rej: Maximum Route Exceptions already exist per DPC and Criteria

Commands Used: `ent-rtx`

A maximum of six exception routes may be associated with the specified DPC and criteria.

Recovery

1. Display the Route table entries.
Enter `rtrv-rte` command.
2. Delete one of the exception route entries from the table that match the **dpc** and criteria.
Enter the `dlt-rtx` command.
3. Re-enter the `ent-rtx` command specifying the **dpc** and criteria to add the exception route.

E4378 Cmd Rej: Maximum Route Exceptions already exist for this STP

Commands Used: `ent-rtx`

The overall number of exception routes and normal routes that may be defined for the EAGLE 5 ISS cannot be over **8000**.

Recovery

1. Display the Route table.
Enter the `rtrv-rte` command.
2. Delete a route exception from the Route table.
Enter the `dlt-rtx` command.
3. Add the route exception to the Route table.
Enter the `ent-rtx` command.

E4379 Cmd Rej: Failed to access Route Table

Commands Used: `chg-dstn`, `chg-rtx`, `dlt-ls`, `dlt-rte`, `dlt-rtx`, `ent-rte`, `ent-rtx`, `rtrv-rte`, `rtrv-rtx`

The Route table is inaccessible. The Route table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4380 Cmd Rej: Route Exception does not exist

Commands Used: `chg-rtx`, `dlt-rtx`

The combination of exception route parameter conditions specified does not exist.

Recovery

1. Display the Route table.
Enter the `rtrv-rtx` command.
2. Re-enter the command specifying a valid combination of exception route parameters.

E4381 Cmd Rej: CIC Range overlaps an existing range

Commands Used: `ent-rtx`

You cannot specify a CIC range that overlaps an existing CIC range.

For example, the following command entry is not allowed because the specified starting and ending CIC ranges are the same:

```
ent-rtx:dpc=ansi pc:cic={0-16383}:ecic={0-16383}
```

Recovery

1. View the Route table.
Enter the `rtrv-rtx` command.
2. Re-enter the `ent-rtx` command specifying a CIC range that does not overlap an existing CIC range.

E4382 Cmd Rej: LSN and NLSN cannot be identical

Commands Used: `chg-rtx`

You cannot specify the same values for the linkset name (`lsn`) parameter and the new linkset name (`nlsn`) parameter.

Recovery

Re-enter the `chg-rtx` command specifying different values for the `lsn` and `nlsn` parameters.

E4383 Cmd Rej: Either NLSN or RC must be specified

Commands Used: `chg-rtx`

For the `chg-rtx` command, either the new linkset name (**nlsn**) parameter or the routing cost (**rc**) parameter must be specified.

Recovery

Re-enter the `chg-rtx` command specifying either the new linkset name (**nlsn**) parameter or the routing cost (**rc**) parameter.

E4384 Cmd Rej: Use type=remote or enter ipaddr in IPLNK table

Commands Used: `ent-ip-host`

If a local host is used (the **type=local** parameter is specified), then the value specified for the **ipaddr** parameter must already exist in the IP Link table.

Note: A remote host resides in a different network or subnetwork. A local host resides within the EAGLE.

Recovery

Perform one of the following actions.

Note: Refer to the *Commands Manual* and to the *Database Administration Manual - IP7 Secure Gateway* for more information.

- Re-enter the `ent-ip-host` command specifying the **type=remote** parameter.
- Re-enter the `ent-ip-host` command specifying an IP address of an existing local host.
- Create a local host entry to configure an IPLNK entry. Enter the `chg-ip-lnk` command.

Note:

An IPLNK entry must be provisioned before an IPHOST entry can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

Re-enter the `ent-ip-host` command specifying the correct format and parameters. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4385 Cmd Rej: Use type=local or remove ipaddr from IPLNK table

Commands Used: `ent-ip-host`

If a remote host is used (the **type=remote** parameter is specified), then the value specified for the **ipaddr** parameter cannot already exist in the IP Link table.

Note: A remote host resides in a different network or subnetwork. A local host resides within the EAGLE.

Recovery

Perform one of the following:

Note: Refer to the *Commands Manual* and to the *Database Administration Manual - IP7 Secure Gateway* for more information.

- Re-enter the command specifying **type=local**.
- Delete the IPHOST from the database. Enter the `dlt-ip-host` command.

Note: An IPLNK entry must be provisioned before an IPHOST entry can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

- Delete the IPLNK entry. Enter the `chg-ip-lnk` command.

Re-enter the `ent-ip-host` command specifying the correct format and parameters. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4386 Cmd Rej: IP Address found in host table

Commands Used: `chg-ip-lnk`

You attempted to change an IP address to a remote host but a corresponding IPHOST entry to that IP address is assigned.

Note:

An IPLNK entry must be provisioned before an IPHOST entry can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

Recovery

1. Display the IP links in the database.
Enter the `rtrv-ip-lnk` command.
2. Display the IP hosts in the database.
Enter the `rtrv-ip-host` command.
3. Using the outputs of Steps 1 and 2, determine the IPHOST assigned to the IP address that generated the error message.
4. Delete the IPHOST from the database.
Enter the `dlt-ip-host` command specifying the information found in Step 3.
5. Re-enter the `chg-ip-lnk` command specifying the correct format and parameters.
Refer to the *Commands Manual* for detailed information about the use of the `chg-ip-lnk` command.

E4387 Cmd Rej: OPC must not be identical to DPC

Commands Used: `chg-rtx`, `ent-rtx`

For the `ent-rtx` command, if `dpc=pointcode1:opc=pointcode2`. The values specified for `pointcode1` and `pointcode2` cannot not be the same.

Recovery

Re-enter the command specifying different values for the `pointcode1` and `pointcode2` parameters.

E4388 Cmd Rej: Exception route cannot be assigned to adjacent point code

The value specified for the `dpc` parameter cannot already be used as an adjacent point code (APC).

Commands Used: `ent-rtx`

Recovery

1. View the status of point codes in the exception route. Enter the `rtrv-rtx` command.
2. Re-enter the `ent-rtx` command specifying a value for the `dpc` parameter that is not an Adjacent Point Code. Refer to the *Database Administration Manual - SS7* for assistance.
3. Re-enter the command that generated this error message. Contact the Customer Care Center if the error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4389 Cmd Rej: BOOT=NO not supported for specified gpl

Commands Used: `init-flash`

The boot parameter cannot be set to NO if the gpl being downloaded is BLCPLD. The HCMIM card must be booted after the BLCPLD is downloaded.

Recovery

Re-enter the `init-flash` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `init-flash` command.

E4391 Cmd Rej: Exception route cannot be assigned to cluster members

Commands Used: `ent-rtx`

An exception route cannot be assigned to cluster members if only the Nested Cluster Routing feature is turned on. However, if the Nested Cluster Routing is also turned on, it is allowed.

This error can occur if Cluster Routing is provisioned and a point code with an asterisk network cluster member sub-field (e.g.: **1-1-***) is in the Route table and there is an attempt to add an exception route and a full point code specified (e.g.: **dpc=1-1-9**).

Recovery

1. Turn on the Nested Cluster Routing feature. Enter the `chg-feat : ncr=on` command.
2. Re-enter the `ent-rtx` command.

E4392 Cmd Rej: Assigned SLKs must be deleted before apcntype can be changed

Commands Used: `chg-ls`, `ent-ls`

You cannot change the value of the **apcntype** parameter for a linkset that still has links assigned to it. The assigned links must first be deleted.

Recovery

1. Display the current linkset configuration.
Enter the `rtrv-ls` command specifying the linkset name (**lsn**) parameter.
2. Delete all links in the linkset.
Enter the `dlt-slk` command.
3. Re-enter the command to change the **apcntype** parameter value for the linkset.
4. When the **apcntype** has been changed, assign links of the correct type (ITUN or ITUN24) to the linkset.

E4393 Cmd Rej: Origin Based SCCP Routing feature must be enabled

Commands Used: `chg-gta`, `chg-gttset`, `chg-ls`, `chg-sccpopts`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `ent-gttset`, `ent-gttset`, `ent-ls`, `rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`

For the `chg-gta` or `ent-gta` commands, the OBSR feature must be enabled before the **opcsn**, **cgpc/cgpc/cgpci/cgpcn/cgpcn24**, **opc/opca/opci/opcn/opcn24** or **(e)cgssn** parameters are specified or before the **xlat** parameter is specified with a value of **udts** or **discard**.

For the `dlt-gta` command, the Origin Based SCCP Routing feature must be enabled whenever the **cgpc/cgpc/cgpci/cgpcn/cgpcn24**, **opc/opca/opci/opcn/opcn24**, or **(e)cgssn** parameters are specified.

For the `chg/ent/rtrv-gttset` commands, the OBSR feature must be enabled before the **cdgtasn**, **cggtasn**, **cgpcsn**, or **cgssn** parameters can be specified.

For the `ent/rtrv-gttset` commands, the Origin Based SCCP Routing feature must be enabled whenever the value specified for the **settype** parameter is either **cggt** or **cgssn** or **opc** or **cgpc**.

For the `chg/ent-ls` commands, the Origin Based SCCP Routing feature must be enabled or turned on before the **gtmode** parameter can have a value of **acdcd**, **cgacdcd**, **acdcdcg**, **acdcdcg**, **cgcd**, **cdcg**, or **cg**.

For the `chg-sccopts` command, the Origin Based SCCP Routing feature must be enabled before the `dfltgttmode` parameter can have a value of `acdcd`, `cgacdcd`, `acdcgdcg`, `cgcd`, `cdcgcg`, or `cg`.

For the `dlt-gttset` command, the OBSR feature must be enabled before the `cgssn` parameter can be specified.

For the `rtrv-gta` command, the OBSR feature must be enabled before the `cgpc/cgpca/cgpci/cgpcn/cgpcn24`, `opc/opca/opci/opcn/opcn24`, `cgssn`, or `ecgssn` parameter can be specified and before a value of `udts` or `discard` can be specified for the `xlat` parameter.

Recovery

1. Verify that the Origin Based SCCP Routing feature is enabled.
Enter the `rtrv-ctrl-feat` command.
2. If the Origin Based SCCP Routing feature is enabled, re-enter the command that generated this error message.
3. If the Origin Based SCCP Routing feature is not enabled (see the output of Step 1), enable the feature.
 - a) Enter the `enable-ctrl-feat` command specifying the appropriate part number and access key information.
Refer to the procedure "Activating the Origin-Based SCCP Routing Feature" in the *Database Administration Manual - Global Title Translation*. Refer to the *Commands Manual* for detailed information about the use of the `enable-ctrl-feat` command.
4. Re-enter the command that generated this message.
Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4397 Cmd Rej: At least one GTT Set Name must be specified

Commands Used: `chg-gttset`, `ent-gttset`

At least one GTT set name parameter must be specified. These parameters include:

- `cdgtasn`, `cggtasn` or `cgpcsn` if the OBSR feature is enabled
- `cdgttsn` or `cggttsn` if the FLOBR feature is turned on
- `gttsn` if the OBSR feature is not enabled and the FLOBR feature is not turned on

Recovery

Re-enter the command specifying at least one GTT set name.

E4398 Cmd Rej: OPTSN and CGSELID/CDSELID are mutually exclusive

Commands Used: `chg-gta`, `ent-gta`

For `chg-gta`: The **cdselid**, **cgselid**, and **optsn** parameters cannot be specified together in the command. If the GTTSN has a set type of **cdgta**, **cdssn**, or **opcode** (see the `ent-gttset` command) then the **optsn** parameter can be specified if one of the other exclusive parameters is specified.

For `ent-gta`: The **cdselid**, **cgselid**, and **optsn** parameters cannot be specified together in the command. If the GTT set has a set type of **cdgta**, **cdssn**, or **opcode**, then the **opcsn** parameter can be specified with one of the above parameters.

Recovery

Re-enter the command specifying either the **cdselid**, **cgselid**, or **optsn** parameter separately, unless the GTT set type follows the exception rule above. Refer to the *Commands Manual* for more information.

E4399 Cmd Rej: Set type of GTT Set Name doesn't match

Commands Used: `chg-gta`, `ent-gta`

The value specified for the GTT set name (**gttsn**) parameter does not match the corresponding set type entry in the GTTSET table. The following GTT set names and matching GTT set types may be specified:

- GTT Set name specified with **cgssnsn** parameter, set type must be **cgssn**
- GTT Set name specified with **cggtasn** parameter, set type must be **cggta**
- GTT Set name specified with **cgpcsn** parameter, set type must be **cgpc**
- GTT Set name specified with **opcsn** parameter, set type must be **opc**

Recovery

1. Determine the GTT Set Name for the GTT set type that is specified in the GTTSET table.
Enter the `rtrv-gttset` command.
2. Re-enter the command specifying the correct value for the **gttsn** parameter.

E4400 Cmd Rej: GTA/CGPC/OPC/CGSSN/CDSSN/OPCODE must be specified

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`

The **cgpc/cgpca/cgpci/cgpcn/cgpcn24**, **opc/opca/opci/opcn/opcn24**, **cgssn**, **gta**, **cdssn**, **opcode/acn/pkgtype**, or **opcode/family/pkgtype** parameter must be specified.

Recovery

Re-enter the command specifying a valid set of parameters as shown above. Refer to the *Commands Manual* for more information.

E4401 Cmd Rej: CGSSNSN cannot be specified with CGGTASN/OPCSN/CGPCSN/SELID

Commands Used: ent-gta

The **cggtasn**, **opcsn**, **cgpcsn**, and **selid** parameters cannot be specified if the **cgssnsn** parameter is specified.

Recovery

Perform one of the following:

Re-enter the command specifying the **cgssnsn** parameter without specifying the **cggtasn**, **opcsn**, **cgpcsn**, and **selid** parameters.

OR

Re-enter the command specifying the **cggtasn**, **opcsn**, **cgpcsn**, and **selid** parameters without specifying the **cgssnsn** parameter.

E4402 Cmd Rej: SETTYPE must be CDGTA when NETDOM=CROSS

Commands Used: chg-gttset, ent-gttset, rtrv-gttset

For the ent-gttset command, the value specified for the GTT set type (**settype**) parameter must be **cdgta**, when the value specified for the network domain (**netdom**) parameter is **cross**.

For the chg-gttset command, the existing GTT set type (**settype**) must be **cdgta**, when the value specified for the network domain (**netdom**) parameter is **cross**.

Note:

For the chg-gttset command, **cross** is the only value that can be specified for the **netdom** parameter.

Recovery

Re-enter the command specifying **settype=cdgta** and **netdom=cross**.

E4403 Cmd Rej: CGSSN cannot be specified with OPTSN/OPCSN/CGSELID

Commands Used: chg-gta, ent-gta

For chg-gta: The FLOBR feature must be turned on before the **cgssn**, **opcsn**, **optsn**, and **cgselid** parameters can be specified in the same command.

For ent-gta: If the **cgssn** parameter is specified, then the **optsn** and **cgselid** parameters cannot be specified.

Recovery

For `chg-gta`: verify the FLOBR feature is turned on. Refer to the *Dabatase Administration Manual - Global Title Translation* for more information.

For `ent-gta`: re-enter the command specifying the `cgssn` parameter, without specifying the `optsn` and `cgselid` parameters.

E4404 Cmd Rej: End value must be greater than or equal to a starting value

Commands Used: `chg-gta`, `chg-rtx`, `dlt-gta`, `dlt-rtx`, `ent-gta`, `ent-rtx`,
`rtrv-gta`, `rtrv-rtx`

For the `ent/chg/dlt/rtrv-gta` commands, If the `ecgssn/ecdssn` parameter is specified, its value must be greater than the value of the `cgssn /cdssn` parameter.

For the `ent/chg/dlt/rtrv-rtx` commands, the value specified for the `ecic` value must be greater than or equal to the value specified for the `cic`.

Recovery

Re-enter the command specifying an end value that is greater than the starting value.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4405 Cmd Rej: OPTSN GTT set type is not compatible with GTTSN set type

Commands Used: `chg-gta`, `ent-gta`

If the GTT set specified by the `gttsn` parameter (GTTSN set) has a set type of `cdgta` (see the `ent-gttset` command), then the `optsn` parameter cannot specify a GTT set (OPTSN set) with a set type of `cgssn`.

If the GTTSN set has a set type of `cdgta`, then the OPTSN set must have a set type of `cggta` or `cgpc`.

The FLOBR feature must be turned on before a GTTSN set with a set type of `cgpc`, `cggta` or `opc` can be specified with an OPTSN with a set type other than `cgssn`.

If the FLOBR feature is turned on, and the GTTSN set has a set type of `cdgta`, then the OPTSN set cannot have a set type of `opc`.

If the TOBR feature is turned on, and the GTTSN set has a set type of `cdgta`, `cdssn`, or `opcode`, then the OPTSN set cannot have a set type of `opc`.

Recovery

Re-enter the command specifying a valid set type. Refer to the *Commands Manual* for more information.

E4406 Cmd Rej: GTA parm must be specified if GTTSN is type of CDGTA/CGGTA

Commands Used: `ent-gta`, `chg-gta`, `dlt-gta`

The `gta` parameter must be specified if the value specified for the GTTSN set type is `cdgta` or `cggta`.

Recovery

Re-enter the command specifying the `gta` parameter, and a value for the GTTSN set type of either `cdgta` or `cggta`.

E4407 Cmd Rej: CGPCx parm must be specified if GTTSN is type of CGPC

Commands Used: `ent-gta`, `chg-gta`, `dlt-gta`

The `cgpc/cgpca/cgpci/cgpcn/cgpcn24` parameter must be specified if the value specified for the GTTSN set type is `cgpc`.

Recovery

Re-enter the command specifying the `cgpc/cgpca/cgpci/cgpcn/cgpcn24` parameter, and a value for the GTTSN set type of `cgpc`.

E4408 Cmd Rej: OPCx parm must be specified if GTTSN is type of OPC

Commands Used: `ent-gta`, `chg-gta`, `dlt-gta`

The `opc/opca/opci/opcn/opcn24` parameter must be specified if the value specified for the GTTSN set type is `opc`. The `opc/opca/opci/opcn/opcn24` parameters can only be specified for an OPC GTTSN set type.

Recovery

Re-enter the command specifying the `opc/opca/opci/opcn/opcn24` parameter and a value for the GTTSN set type of `opc`.

E4409 Cmd Rej: CGSSN parm must be specified if GTTSN is type of CGSSN

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`

The `cgssn` parameter must be specified if the value specified for the GTTSN set type is `cgssn`. The `cgssn` parameter can only be specified for a CGSSN GTTSN set type.

Recovery

Re-enter the command specifying the **cgssn** parameter for the CGSSN GTTSN set type.

E4412 Cmd Rej: CGSSN/CDSSN range cannot overlap an existing range

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`

The range specified by the **cgssn/ecgssn** and **cdssn/ecdssn** parameters cannot overlap a currently existing range for the specified GTT set.

Recovery

Re-enter the command specifying a CGSSN/CDSSN range that does not overlap the existing range for the specified GTT Set.

Refer to the *Commands Manual* or the *System Administration Manual - GTT* for more information about these parameters or GTT sets.

E4414 Cmd Rej: SSNSELID Table is full

Commands Used: `chg-gttssel`, `ent-gttssel`

The specified value could be entered into the SSNSELID table because the table is full. The SSNSELID Table cannot contain more than 100,000 entries.

Recovery

1. Display the SSNSELID table.
Enter the `rtrv-gttssel` command.
2. Change or delete an existing SSNSELID table entry.
Enter the `chg-gttssel` or `dlt-gttssel` command.
3. Re-enter the `ent-gttssel` command to add the entry to the SSNSELID table.

E4415 Cmd Rej: CGSSN/CDSSN range does not exist

Commands Used: `chg-gta`, `dlt-gta`, `rtrv-gta`

The range specified by the **cgssn/ecgssn** and **cdssn/ecdssn** parameters must exist for the specified GTT set. An exact match is not required.

Recovery

Re-enter the command specifying a valid range for the parameter. Refer to the *Commands Manual* for more information about these parameters.

E4416 Cmd Rej: Cannot delete last route to DSTN that has exception routes

Commands Used: `dlt-rte`, `chg-dstn`

The last route to a destination that contains exception routes cannot be deleted.

Recovery

1. Display the Route table. Enter the `rtrv-rte` command.
2. Delete the DPC references from the Route table. Enter the `dlt-rte` command.
3. Delete the desired route. Enter the `dlt-rte` command.
4. Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4418 Cmd Rej: Specified GTT set does not exist

Commands Used: `chg-sccpopts`

The specified GTT set for the Default Calling Party ANSI Point Code Set Name (**`dfltcgpcasn`**), or the Default Calling Party ITU Point Code Set Name (**`dfltcgpcisn`**), must exist in the GTTSET table.

- The **`dfltcgpcasn`** parameter determines the system default of the GTT Calling Party Point Code Set for ANSI when **`gti=0`**
- The **`dfltcgpcisn`** parameter determines the system default of the GTT Calling Party Point Code Set for ITU when **`gti=0`**.

Recovery

1. Display the STP Options table.
Enter the `rtrv-sccpopts` command.
2. Re-enter the `chg-sccpopts` command specifying **`gti=0`** and a default set name (**`dfltcgpcasn`** or **`dfltcgpcisn`**) parameter that exists in the GTTSET table.

E4433 Cmd Rej: APORT must be enabled

Commands Used: `enable-ctrl-feat`

The A-Port feature must be enabled before the MO-based IS41 SMS NP or MT-based IS41 SMS NP feature can be enabled.

Recovery

1. Display the status of the features that are enabled in the system. Enter the `rtrv-ctrl-feat` command.

If the A-Port feature is not shown in the output, then the feature is not enabled.

2. Enable the A-Port feature. Refer to the *Feature Manual - A-Port* for assistance.

E4435 Cmd Rej: OPC/ILSN/CIC/SI is mandatory and mutually exclusive

Commands Used: `chg-rtx`, `dlt-rtx`, `ent-rtx`

Only one of the following optional parameters may be specified for a exception route entry: **cic**, **ilns**, **opc**, or **si**.

Recovery

Re-enter the command specifying only one of the following optional parameters: **cic**, **ilns**, **opc**, or **si**.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4436 Cmd Rej: Entered OPC does not exist in the routing table

Commands Used: `ent-appflt`

The specified origination point code (**opc**) does not exist in Routing table.

Recovery

Re-enter the `ent-appflt` command specifying an **opc** that exists in the Routing table.

Call your Customer Care Center if this error message appears again.

E4441 Cmd Rej: CGGTA and CGPC are mutually exclusive

Commands Used: `rtrv-data-gtt`

You cannot specify the **cggta** and **cgpc** parameters together in the same command.

Recovery

Re-enter the `rtrv-data-gtt` command specifying the **cggta** and the **cgpc** parameters separately.

E4442 Cmd Rej: CDGTA must be specified

Commands Used: `rtrv-data-gtt`

The **cdgta** parameter must be specified if the **opc** parameter is specified.

Recovery

Re-enter the `rtrv-data-gtt` command specifying both the **opc** parameter and the **cdgta** parameter.

E4443 Cmd Rej: CGGTA or CGPC or OPC must be specified

Commands Used: `rtrv-data-gtt`

If the `cgssn` parameter is specified, then either `cggta` or `cgpc` or `opc` parameter must be specified.

Recovery

Re-enter the `rtrv-data-gtt` command specifying the `cgssn` parameter and either the `cggta`, or `cgpc`, or `opc` parameters.

E4444 Cmd Rej: CGGTA or CGPC must be specified

Commands Used: `rtrv-data-gtt`

You must specify either the `cggta` or `cgpc` parameters.

Recovery

Re-enter the `rtrv-data-gtt` command specifying either the `cggta` or `cgpc` parameter.

E4445 Cmd Rej: Target card is not a TSM/DSM with SCCP/VSCCP appl

Commands Used: `rtrv-data-gtt`

The target network card specified by the `loc` parameter must either be a TSM card running the SCCP application or a DSM card running the VSCCP application.

Recovery

Re-enter the `rtrv-data-gtt` command specifying the `loc` parameter for either a TSM card running the SCCP application, or a DSM card running the VSCCP application.

E4446 Cmd Rej: MO-based GSM SMS NP or MO SMS ASD/GRN must be enabled

Commands Used: `chg-gsmsmsopts`

The MO-based GSM SMS NP, MO SMS ASD, or MO SMS GRN feature must be enabled before the `mosmsfwd` or `mosmsgta` parameter can be specified.

Recovery

1. Enable the MO-based GSM SMS NP, MO SMS ASD, or MO SMS GRN feature. See the *Feature Manual - MO SMS* for assistance in how to enable the feature.
2. Re-enter the command that generated this error message.

E4447 Cmd Rej: No links configured

Commands Used: `chg-meas`, `chg-measopts`

If there are no links configured in the system, the `chg-meas:collect=on` parameter and the `chg-measopts:platformenable=on` parameter cannot be specified to start measurements collection.

Recovery

1. Enter the tag or command to verify that there are no links provisioned in the system. Refer to the *Commands Manual* for assistance entering the correct command.
2. If there are no provisioned links shown in the output from Step 1, the commands to start measurements collection cannot be entered until at least one link has been configured.
3. If there are links provisioned in the system, re-enter the command that generated this message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4448 Cmd Rej: Too many IP connection states per card

Commands Used: `chg-assoc`, `ent-as`

There are per card and per system limits on the maximum number of sockets supported: the maximum number of sockets per Local Host on SS7IPGW/IPGWI cards is **50**, the maximum number of sockets per signaling link on IPLIM/IPLIMI cards is **1**, and the maximum number of IP connections per system is **4000**.

Each time an M3UA/SUA association is assigned to an AS, the SS7IPGW or IPGWI card that hosts the association must maintain a state (ASP-Down, ASP-Inactive, ASP-Active) for the association/AS combination.

Recovery

1. Display the connection types in the AS table.
Enter the `rtrv-assoc` or `rtrv-as` command.
2. An existing connection type association must be deleted from the AS before another connection type can be associated with the AS.
Refer to the *Commands Manual* for detailed information about the use of these commands.
3. After deleting an existing connection type association for the AS, re-enter the command to associate the new connection type with the AS.

E4452 Cmd Rej: SOIP feature cant be enabled if the IPUI feature is not ON

Commands Used: `chg-ctrl-feat`

The IP User Interface feature must be turned on before the SEAS Over IP feature can be turned on.

Recovery

1. Display the status of controlled features in the system. Enter the `rtvr-ctrl-feat` command.
If the IP User Interface feature does not appear in the command output, then the feature is not enabled in the system.
If the status of the IP User Interface feature is OFF, then the feature is enabled, but not turned on.
2. Refer to the procedures in the *Database Administration Manual - System Management* to enable, turn on, and use the IP User Interface feature.
3. Re-enter the command that generated this message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4453 Cmd Rej: SOIP feature must be ON

Commands Used: `alw-trm`, `rst-trm`,

The SEAS Over IP feature must be turned on before a SEAS terminal can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtvr-ctrl-feat` command.
If the SEAS Over IP feature does not appear in the output, then the feature is not enabled in the system.
If the status of the SEAS Over IP feature is OFF, then the feature is enabled, but not turned on.
2. Refer to the *Database Administration Manual - Systems Management* for procedures to enable, turn on, and use the feature.
3. Re-enter the command that generated this message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4454 Cmd Rej: Specified GTT Set must be type of CGPC

Commands Used: `chg-sccpopts`

For the `chg-sccpopts` command, the specified GTT set for the `dfltcgpcasn`, `dfltcgpcisn` parameters must be a set type of `cgpc` defined in the GTTSET table.

Recovery

Re-enter the `chg-sccpopts` command specifying a value of `cgpc` for the the GTT set type.

E4456 Cmd Rej: GTT set name must match the network domain

Commands Used: `chg-sccpopts`

The specified GTT Set domain must match the network domain for the specified GTT Set Name.

- For the default CGPCA Set Name (**dfltcgpcasn**), the specified network domain must be an ANSI network domain.
- For the default CGPCI Set Name (**dfltcgpcisn**), the specified network domain must be must be an ITU (including ITU-I, ITU-N, ITU-N24) network domain.

Recovery

Re-enter the `chg-sccpopts` command specifying the correct network domain for the specified GTT Set Name.

E4457 Cmd Rej: CGSELID is valid only if specified GTTSN set type is CDGTA

Commands Used: `chg-gta`, `ent-gta`

The FLOBR feature must be turned on before the **gttsn** parameter can specify a GTT set with a set type other than **cdgta** (see the `ent-gttset` command) in the same command with the **cgselid** parameter.

Recovery

1. Display the status of features in the system. Enter the `rtrv-ctrl-feat` command.
2. If the status of the GTT feature is Off in the output from Step 1, refer to the procedures in the *Database Administration Manual - Global Title Translation* and the *Database Administration Manual - Features* to turn on the FLOBR feature.
3. Re-enter the command that generated this error message.

E4458 Cmd Rej: Common screening list feature is required

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`

An enabled feature that uses a common screening list must be specified using either a valid part number (**pn**) or feature name.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4459 Cmd Rej: Common screening list type is required

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`

The value specified for the **list** parameter is invalid.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4460 Cmd Rej: Common screening list type is invalid

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`, `rtrv-csl`

The value specified for the **list** parameter is invalid for the specified screening feature. Refer to the command descriptions in the *Commands Manual* for the appropriate values for each screening feature.

Recovery

Re-enter the command specifying the correct value and parameters.

E4461 Cmd Rej: Common screening list entry already exists

Commands Used: `ent-csl`

The specified digit string (**ds**) entry already exists for the specified feature and screening list. Duplicate digit string entries are not allowed for any feature and screening list combination.

Recovery

1. Display a list of screening numbers for the specified feature and screening list name.
Enter the `rtrv-csl` command.
2. Re-enter the `ent-csl` command specifying a valid **ds** entry.

E4462 Cmd Rej: Common screening list entry not present

Commands Used: `chg-csl`, `dlt-csl`

The specified entry does not exist for the specified feature part number or feature name and list type.

Recovery

Re-enter the command specifying a valid **ds** entry for the specified feature part number or feature name and list type.

E4464 Cmd Rej: Common screening list invalid parameter combination

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`, `rtrv-csl`

The specified parameter combination is invalid.

Recovery

Re-enter the command, and specify an appropriate parameter combination. Refer to the command descriptions in the *Commands Manual* for assistance.

E4466 Cmd Rej: Common screening list is full

Commands Used: `ent-csl`

The common screening list for the specified feature is full.

Each list table is allowed to contain a maximum number of entries. Refer to the command description in the *Commands Manual* for the maximum number of entries for each list.

Recovery

1. Display a list of screening numbers for the specified feature and screening list name.
Enter the `rtrv-csl` command.
2. Delete the screening numbers for the specified feature and screening list name.
Enter the `dlt-csl` command.
3. Re-enter the `ent-csl` command.
Refer to the *Commands Manual* for detailed information about the use of these commands.

E4467 Cmd Rej: Common screening list read fail

Comands Used: `chg-csl`, `dlt-csl`, `ent-csl`, `rtrv-csl`

The specified screening list cannot be read.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4468 Cmd Rej: Common screening list requested feature must be enabled

Comands Used: `chg-csl`, `dlt-csl`, `ent-csl`

The feature that is specified in the feature parameter must be enabled. Refer to the command description in the *Commands Manual* for a list of features and part numbers.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled, but it is not turned on.

2. Enable and turn on the feature. Refer to the appropriate feature manual and to the *Database Administration Manual - Features* for assistance.
3. Re-enter the command that generated this error message.
4. Call your customer care center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4469 Cmd Rej: Failed reading SSNSELID table

Commands Used: `chg-gtttsel`, `dlt-gtttsel`, `ent-gtttsel`, `rtrv-gtttsel`

The SSNSELID table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4470 Cmd Rej: SSNSELID entry already exists

Commands Used: `chg-gtttsel`, `ent-gtttsel`

The value specified for the `cgssn` and/or `selid` parameter already exists in the SSNSELID table. The specified `cgssn` and/or `selid` is already being used by other selector.

Recovery

Re-enter the command specifying a different value for the `cgssn` and/or `selid` parameter.

E4472 Cmd Rej: The IP Addr of E5-IPSM corresponding to SEAS Trm must be set

Commands Used: `alw-trm`, `chg-ctrl-feat`, `rst-trm`

An E5-IPSM card must be provisioned before a SEAS terminal can be allowed or restored and before the SEAS Over IP feature can be turned on.

Recovery

1. Display the cards in the system using the `rtrv-card` command.
2. If there is no E5-IPSM card listed in the output of Step 1, provision an E5-IPSM card. If an E5-IPSM card is listed, but no IP Address, provision the IP address. Refer to the *Database Administration Manual - Systems Management* for instructions on provisioning the IP address.

E4473 Cmd Rej: CONN parameter required with IPADDR, PORT, LOGIN and HNAME

Commands Used: `chg-seas-config`

The **conn** parameter must be specified before the **port**, **ipaddr**, **login** or **hname** parameters can be specified.

Recovery

1. Specify the **conn** parameter before trying to specify the **port**, **ipaddr**, or **hname** parameters. See the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command that caused this message to appear.

E4474 Cmd Rej: SEASCLLI must be set

Commands Used: `chg-ctrl-feat`

The SEASCLLI value must be set before the SEAS Over IP feature can be turned on.

Recovery

1. Use the `chg-seas-config` command to set the SEASCLLI value. Refer to the *Database Administration Manual - Systems Management* for more information.
2. Re-enter the command that generated this message.

E4475 Cmd Rej: MRNSET must be specified (only) if RI parameter is GT

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

With the Flexible GTT Loadsharing feature enabled, the **mrnset** parameter must be specified if **ri=gt** is specified. If **ri=ssn** is specified, then the **mrnset** parameter cannot be specified

Recovery

Re-enter the command specifying both the **mrnset** and **ri=gt** parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4476 Cmd Rej: Specified PC must exist in MRNSET

Commands Used: `chg-gta`, `chg-gtt`

The specified PC value does not exist in the MRN Set.

Recovery

1. Add the PC to the MRN set.
Enter the `ent-mrn` or `chg-mrn` command. Refer to the *Commands Manual* for detailed information about the use of these commands.
2. Re-enter the command and specified `pc` parameter.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4477 Cmd Rej: Terminal cannot be changed to type SEAS

Commands Used: `chg-trm`

The `type=seas` parameter cannot be specified under the following conditions:

- The value of the `trm` parameter is 1 - 16.
- Specifying the parameter results in more than one SEAS terminal on an E5-IPSM card.
- Specifying the parameter results in more than two SEAS terminals in the EAGLE 5 ISS.
- An E5-IPSM card is not physically present in the corresponding location.
- The SEAS terminal specified by the parameter values does not exist in the SEASCFG table.

Recovery

1. Display the provisioned SEAS terminals by entering the `rtrv-trm` command.
2. Verify that none of the conditions exist in your system that prevent the `type=seas` parameter from being specified. For more information see the *Database Administration Manual - System Management*.
3. Re-enter the command that generated this message with valid parameters to specify the SEAS terminal.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4478 Cmd Rej: Force must be specified to inhibit the last SEAS terminal

Commands Used: `inh-card`, `inh-trm`, `rmv-trm`

If the specified card has the last in-service SEAS Terminal configured, then the `force=yes` parameter must be specified to inhibit the card.

Recovery

1. Display the status of the controlled features using the `rtrv-ctrl-feat` command. Refer to the *Commands Manual* for assistance.
2. Make sure the `force=yes` parameter is set correctly. If not, refer to the *Database Administration Manual - Systems Management* to set this parameter.
3. Re-enter the command that caused this message to appear.

E4479 Cmd Rej: MRNSET must be specified (only) if FGTTLS feature is enabled

Commands Used: `rtrv-gta`, `rtrv-gtt`

The Flexible GTT Load Sharing feature must be enabled before the **mrnset** parameter can be specified.

Recovery

1. Display the current features enabled using the `rtrv-ctrl-feat` command.
2. Verify the Flexible GTT Load Sharing feature is enabled in the output of Step 1. If the Flexible GTT Load sharing feature is not enabled or not listed it must be enabled. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. If the Flexible GTT Load Sharing feature is enabled call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4480 Cmd Rej: Specified MRNSET does not exist

Commands Used: `chg-gta`, `chg-gtt`, `chg-map`, `chg-mrn`, `chg-sccp-serv`, `dlt-mrn`, `dlt-sccp-serv`, `ent-gta`, `ent-gtt`, `ent-mrn`, `rtrv-gta`, `rtrv-mrn`

The value specified for the **mrnset** parameter must already exist in the MRN table.

For the `chg-dccp-serv` and `dlt-sccp-serv` commands, the specified **MRNSET** does not exist in the SCCP-SERV portion of the MRN table.

Recovery

1. Refer to the *Commands Manual* and the procedures in the *Database Administration Manual – Global Title Translation* to provision MRN sets.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4481 Cmd Rej: SOIP Feature is ON

Commands Used: `act-oap-config`, `chg-ctrl-feat`, `chg-oap-config`, `init-oap`, `rtrv-oap-config`

The IPUI feature cannot be turned off, and the OAP related commands cannot be run when the SOIP feature is on.

Recovery

1. Turn off the SOIP feature. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command to turn off the IPUI feature.

E4482 Cmd Rej: Multiple groups are allowed only in default MRNSET

Commands Used: `ent-mrn`

You cannot add a group to an existing MRNSET that is not the default MRNSET. The default MRNSET can have any number of load sharing groups in order to maintain compatibility with existing functionality.

Recovery

Refer to the *Commands Manual* and the procedures in the *Database Administration Manual – Global Title Translation* to provision and use MRN sets.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4483 Cmd Rej: PC does not exist in specified MRNSET

Commands Used: `chg-gta`, `chg-gtt`, `chg-map`, `chg-mrn`, `chg-sccp-serv`, `dlt-sccp-serv`, `ent-gta`, `ent-gtt`, `ent-mrn`, `chg-mrn`, `dlt-mrn`, `rtrv-mrn`

The specified point code does not exist in the MRNSET. If the Flexible GTT Load Sharing feature is enabled, then the specified point code must already exist in the specified MRN set.

For the `chg-sccp-serv` and `dlt-sccp-serv` commands, the specified point code must already exist in the specified MRNSET portion of the SCCP-SERV table.

For the `chg-map` command, the value specified for the `mrnpc` parameter must already exist in the specified MRN Set.

Recovery

1. Display the MRN table. Enter the `rtrv-mrn` command.
2. Refer to the *Commands Manual* and the procedures in the *Database Administration Manual – Global Title Translation* to provision and use MRN sets.
3. Re-enter the command specifying a point code that is in the MRN set.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4484 Cmd Rej: PC reference exists in GTT translation/MAP table

Commands Used: `dlt-mrn`

A specified MRN Set or a PC in an MRN Set cannot be deleted if it is referred to in the GTT2 or MAP table.

Recovery

1. Display the GT Translations.
Enter the `rtrv-gtt` or `rtrv-gta` commands.
2. Delete the specified **pc** from the GTT table.
Enter the `dlt-gtt` or `dlt-gta` commands.
3. Delete the specified **pc** from the MRN table.
Re-enter the `dlt-mrn` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4485 Cmd Rej: PC & MRNSET must be specified together

Commands Used: `rtrv-mrn`

You must specify both the **pc** and the **mrnset** parameters when the Flexible GTT Loadsharing feature is enabled.

Recovery

Re-enter the `rtrv-mrn` command specifying both **pc** and the **mrnset** parameters.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-mrn` command.

E4486 Cmd Rej: CgPA GTT Set does not exist

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The GTT set specified by the **cgttsn**, **cggtasn**, or **cgpcsn** parameter must already exist in the GTT Set table. The GTTSET parameter value must exist in the database before it can be assigned to a GTT selector.

Recovery

1. Display the GTT Set table.
Enter the `rtrv-gttset` command. Refer to the *Commands Manual* for detailed information about the use of these commands.
2. Add the GTT set to the GTT Set table.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4487 Cmd Rej: Network domains of GTI and CgPA GTT Set must match

Commands Used: `chg-gttset`, `ent-gttset`

The network domain of the CgPA GTT Set specified by the **cggttsn**, **cggtasn**, or **cgpcsn** parameter must match the domain indicated by the **gti(x)** parameter.

Recovery

Re-enter the command specifying a network domain for the **cggttsn**, **cggtasn**, or **cgpcsn** parameter that matches the network domain specified by the **gti(x)** parameter.

E4488 Cmd Rej: CGGTASN/CGPCSN set type doesn't match

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The set type of the GTT set specified by the **cggtasn** or **cgpcsn** parameter must match the set type of the corresponding entry in the GTT Set table.

Recovery

Re-enter the command specifying the correct set type parameter value.

E4489 Cmd Rej: Common screening list key must be unique

Commands Used: `chg-csl`, `ent-csl`

The leading digit pattern in the specified digit string (`ds` parameter) must be unique in the specified screening list for the specified feature.

Recovery

Re-enter the command specifying the correct format and parameters.

E4490 Cmd Rej: Card type must be VXWSLAN for a 100Mbit link

Commands Used: `ent-dlk`

If the `speed=100` parameter is specified, the card in the specified location must be a DCM card running the `stplan` application, or an E5-ENET card running the `slanhc` GPL and the `stplan` application. (The `type=dcm` parameter must be specified in the `ent-card` command.)

Recovery

1. List the card types in the database. Enter the `rtrv-card` command. Verify that the card in the location you specified is a DCM card running the `stplan` application, or an E5-ENET card running the `slanhc` GPL and the `stplan` application.
2. Re-enter the `ent-dlk` command specifying a valid card location with the `speed=100` parameter.

E4491 Cmd Rej: Invalid IP database configuration

Commands Used: `act-upgrade`

Unresolved IP references were found in the IP database during the upgrade or health check procedure. This means that the database contains references to IP signaling entities (Application Server, IP Connection, IP Host, etc) that do not exist or configuration parameters that are no longer supported.

Recovery

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4492 Cmd Rej: Common screening list invalid DS parameter value

Commands Used: `chg-csl`, `ent-csl`

The specified digit string (**ds**) parameter contains invalid value(s) for the specified feature screening list.

Recovery

Re-enter the command specifying a valid **ds** parameter value for the specified feature and list type.

E4493 Cmd Rej: Common screening list DS length invalid

Commands Used: `chg-csl`, `ent-csl`

The specified digit string length is invalid for the screening feature and list type. The length of the digit string that is specified for the **ds** parameter must be valid for the screening feature and list type.

Recovery

Re-enter the command specifying a valid digit string length for the screening feature and list type.

E4495 Cmd Rej: Specify a single output method

Commands Used: `rtrv-data-insrv`

You specified multiple methods of output. Only one primary method of output, either trigger type, index, or range, can be specified where a range uses **begin** and/or **end** parameters.

Recovery

Re-enter the `rtrv-data-insrv` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-data-insrv` command.

E4496 Cmd Rej: Range endpoints are reversed

Commands Used: `rtrv-data-insrv`

The **begin** and **end** values for specifying a range are reversed.

Recovery

Re-enter the `rtrv-data-insrv` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-data-insrv` command.

E4497 Cmd Rej: ICNP feature must be activated

Commands Used: `rtrv-data-insrv`

The IntraCarrier Number Portability and IN Triggers (ICNP) feature must be enabled and turned on for the IN Service table to exist for data retrieval.

Recovery

1. Display the features in the system.
Enter the `rtrv-ctrl-feat` command.
2. Verify the IntraCarrier Number Portability and IN Triggers (ICNP) feature has been purchased and installed in your system.

Note:

Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.

Refer to the *Database Administration Manual - System Management* for any prerequisite features that must be turned on before enabling, turning on, and configuring the ICNP feature.

Note:

The ICNP feature requires a 4 GB DSM card to enable the feature. The INP feature must be turned on before the ICNP feature can be enabled.

3. Enable the ICNP feature.
Enter the command `enable-ctrl-feat:partnum=89301XXXX:fak=<ICNP FAK>`
4. Turn on the ICNP feature.
Enter the command: `chg-ctrl-fea:partnum=89301XXXX:status=on`
5. Verify the ICNP feature is enabled and turned on.
Enter the `rtrv-ctrl-feat` command.
6. When the ICNP feature is enabled and turned on in the system, re-enter the `rtrv-data-insrv` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4498 Cmd Rej: The Prepaid IDP Query Relay feature must be enabled

Commands Used: `chg-ttr-msg`, `rtrv-ttr-msg`, `tst-msg`, `chg-tatr-opts`

For the `chg-tatr-opts`, `chg-ttr-msg` and `rtrv-ttr-msg` commands, the Prepaid IDP Query Relay (IDP Relay) feature must be enabled before the command can be entered.

For the `tst-msg` command, the IDP Relay feature must be enabled before the `feat=ttr` parameter can be specified.

Recovery

1. Display the status of the IDP Relay feature. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature if necessary. Refer to the *Commands Manual* and the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4499 Cmd Rej: Common screening list invalid parameter value

Commands Used: `chg-csl`, `ent-csl`

The specified common screening list parameter value must be valid for the specified screening list feature.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4500 Cmd Rej: IDPR must be ON or IAR Base must be enabled when SERV=TTR

Commands Used: `ent-srvsel`, `chg-srvsel`, `rtrv-srvsel`

The Prepaid IDP Query Relay (IDPR) feature must be turned on or the IAR Base feature must be enabled before a value of `ttr` can be specified for the `nserv` or `serv` parameter.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable or enable and turn on the feature as necessary. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for more information.
3. Re-enter the command that generated this message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4501 Cmd Rej: Enabling of IDPR requires VSCCP DSM card

Commands Used: `enable-ctrl-feat`

A DSM card running the VSCCP application must be installed in the system before the Prepaid IDP Query Relay (IDPR) feature can be enabled..

Recovery

1. Display the cards and loads for each. Enter the `rtrv-card` command.
2. Verify that the system contains only DSM cards running the VSCCP application. Upgrade or remove cards as necessary.
3. Refer to the *Feature Manual - IDP and Analyzed Information Features* to enable the IDP Relay feature.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4502 Cmd Rej: GTT must be ON before IDPR can be enabled

Commands Used: `chg-feat`

The GTT feature must be turned on before the Prepaid IDP Query Relay feature can be enabled.

Recovery

1. Display the status of the GTT feature. Enter the `rtrv-feat` command.
If the feature has a status of OFF then the feature is not turned on.
2. Turn on the GTT feature as necessary. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message. Contact the Customer Care Center if the error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4505 Cmd Rej: Service parameters not supported when SERV=IDPR or TTR

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

If a value of `idpr` or `ttr` is specified for the `nserv` or `serv` parameter, then the only valid mandatory service parameters are `gti`, `gtia`, `gtii`, `gtin`, `ssn`, and `tt`, and the only valid optional parameters are `nai` and `np`.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.

E4506 Cmd Rej: Must specify trigger type with an offset

Commands Used: `rtrv-data-insrv`

You specified an **offset** without specifying a trigger type (**tt**). A trigger type must be specified with an offset to determine the IN Service entry to output.

Recovery

Re-enter the `rtrv-data-insrv` command specifying both the **tt** and **offset** parameters.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-data-insrv` command.

E4507 Cmd Rej: DEFCC must be provisioned

Commands Used: `chg-ctrl-feat`

Before the Prepaid IDP Query Relay (IDP Relay, IDPR) feature can be turned on, the default country code (**defcc**) parameter must be provisioned using the `chg-stpopts` command.

Recovery

1. Verify that a default country code has been provisioned. Enter the `rtrv-stpopts` command.
2. If a default country code has not been provisioned, refer to `chg-stpopts` command description in the *Commands Manual* to enter a default country code.
3. Refer to the procedures in the *Feature Manual - IDP and Analyzed Information Features* to turn on the IDP Relay feature.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4508 Cmd Rej: SEAS can only update translations with Default MRNSET

Commands Used: `cht-gta`, `chg-gtt`

You can only use a SEAS command specifying `mrnset=dflt`. SEAS command will not operate on any other MRNSET except the default MRNSET.

Recovery

Re-enter the command.

Refer to the *Commands Manual* for detailed information about the use of these commands.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4509 Cmd Rej: Translation entry already exists

Commands Used: `ent-gta`

The translation entry specified by the `cgpc`, `opcode`, or `opc` parameters cannot already exist.

Recovery

Re-enter the `ent-gta` command specifying a different value for the `cgpc`, `opcode`, or `opc` parameters.

E4510 Cmd Rej: Translation entry does not exist

Commands Used: `chg-gta`, `dlt-gta`

The translation entry for the specified CgPA PC or OPC does not exist.

Recovery

Re-enter the command specifying a different value for the CgPA PC or OPC.

E4511 Cmd Rej: CdPA GTT Set does not exist

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The GTT set specified by the `cdgtasn`, `cdgttsn`, or `gttsn` parameter must already exist in the GTT Set table.

Recovery

1. Display the GTTSEL table. Enter the `rtrv-gttset` command.
2. Re-enter the command specifying a valid value for the `cdgtasn`, `cdgttsn`, or `gttsn` parameter that is provisioned in the database.

E4512 Cmd Rej: CgPA GTT Selector doesn't exist in GTI-TT-NP(V)-NAI(V)

Commands Used: `chg-gttset`

The specified `cggtta gttset/cgpc gttset` parameter is not provisioned in the database.

Recovery

1. Retrieve the GTTSEL table.
Enter the `rtrv-gttset` command.
2. Re-enter the `chg-gttset` command specifying a valid value for the `cggtasn` or `cgpcsn` parameters.

E4513 Cmd Rej: CDGTASN/GTTSN cannot be specified as NONE

Commands Used: `chg-gttset`

You cannot specify a value of **none** for the `cdgtasn` or `gttsn` parameters. If the `chg-gttset` command specifies the only GTTSET associated with that selector, then `cdgtasn=none` cannot be specified.

Recovery

Re-enter the `chg-gttset` command specifying a value other than **none** for the `cdgtasn` or `gttsn` parameters.

E4514 Cmd Rej: CdPA and/or CgPA GTT Set can't be specified as NONE

Commands Used: `chg-gttset`, `rtrv-gttset`

A value of none cannot be specified for the `gttsn`, `cdgtasn`, `cdgttsn`, `cggttsn`, `cggtasn`, or `cgpcsn` parameter.

Recovery

Re-enter the command without specifying **none** for the GTT Set parameter.

E4516 Cmd Rej: CgPA GTT set must not be specified

Commands Used: `rtrv-gttset`

If a full GTT selector key is specified by the `gti(x)`, `tt`, `np/npv`, `nai/naiv`, `cgssn`, `selid`, and `lsn` parameters, then the GTT set specified by the `cgpcsn`, `cggtasn`, or `cggttsn` parameters cannot be specified.

Recovery

Re-enter the command without specifying the `cgpcsn`, `cggtasn`, or `cggttsn` parameters.

Refer to the *Commands Manual* for more information.

E4517 Cmd Rej: CdPA GTT set must not be specified

Commands Used: `rtrv-gttset`

If a full GTT selector key is specified by the `gti(x)`, `tt`, `np/npv`, `nai/naiv`, `selid`, and `lsn` parameters, then the GTT set specified by the `gttsn`, `cdgtasn`, or `cdgttsn` parameters cannot be specified.

Recovery

Re-enter the `rtrv-gttset` command specifying a valid set of parameters. Refer to the *Commands Manual* for more information.

E4518 Cmd Rej: SEAS output group cannot be turned OFF for SEAS terminal

Commands Used: `chg-trm`

If the specified terminal is a SEAS Terminal then the SEAS output group cannot be turned off.

Recovery

1. To turn off the SEAS output group, the specified terminal must be reconfigured to a type other than a SEAS terminal. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command to turn off the SEAS output group.

E4519 Cmd Rej: CdPA GTT Set type must be cdgta

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The GTT Set specified by the `cdgttsn`, `cdgtasn`, or `gttsn` parameter must have a set type of `cdgta` (see the `ent-gttset` command).

Recovery

Re-enter the command specifying the `cdgttsn`, `cdgtasn`, or `gttsn` parameter whose set type is `cdgta`.

E4521Cmd Rej: CGPCSN set domain must be the same as GTTSN set domain

Commands Used: `ent-gta`

The CGPCSN set domain must be the same as the GTTSN set domain; i.e., if the GTTSN set domain is ANSI, then the CGPCSN set domain must also be ANSI; and if GTTSN set domain is ITU, then the CGPCSN set domain must also be ITU.

Recovery

Re-enter the command specifying the same domain (either ANSI or ITU) for both the **cgpcsn** and **gttsn** parameters.

E4522 Cmd Rej: OPCSN set domain must be the same as GTTSN set domain

Commands Used: `chg-gta`, `ent-gta`

The OPCSN set domain must be the same as the GTTSN set domain; i.e., if the GTTSN set domain is ANSI, then the OPCSN set domain must also be ANSI; and if the GTTSN set domain is ITU, then the OPCSN set domain must also be ITU.

Recovery

Re-enter the command specifying the same domain (either ANSI or ITU) for both the **opcsn** and **gttsn** parameters.

E4523 Cmd Rej: MAPSET must be specified (only) if FGTTLS feature is enabled

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`, `chg-gtt`, `chg-map`, `dlt-map`, `ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gta`, `ent-gtt`, `ent-map`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`, `rtrv-gta`, `rtrv-gtt`, `rtrv-map`

The MAPSET ID (mapset parameter) must be specified if the Flexible GTT Load-Sharing (FGTTLS) feature is enabled.

- If the Flexible GTT Load Sharing feature is enabled, then the **mapset** parameter must be specified.
- If the Flexible GTT Load Sharing feature is not enabled, then the **mapset** parameter cannot be specified.

Recovery

1. Display the status of the FGTTLS feature. Enter the `rtrv-ctrl-feat` command.
2. If the FGTTLS feature is enabled, re-enter the command specifying the mapset parameter.
3. If the FGTTLS feature is not enabled, refer to the *Commands Manual* and the procedure in the *Database Administration Manual – Global Title Translation* to enable the FGTTLS feature.
4. Re-enter the command specifying the mapset parameter.
5. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4524 Cmd Rej: Failed Reading MAP table

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`, `chg-gtt`, `chg-map`, `chg-mrn`, `dlt-gsmmap-scrn`, `dlt-gsms-opcode`, `dlt-gta`, `dlt-gtt`, `dlt-map`,

dlt-mrn, ent-gsmmap-scrn, ent-gsms-opcode, ent-gta, ent-gtt, ent-map, rtrv-map

The MAP table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4525 Cmd Rej: Failed Reading RPC3 table

Commands Used: chg-map, ent-map, ent-ss-appl

The RPC3 table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4526 Cmd Rej: MAP table is full

Commands Used: chg-gtt, chg-map, ent-gtt, ent-map

For the chg-map command, the mate point code in the command will exceed the maximum number of entries in the MAP table.

For the ent-map command, one or more point codes in the command will exceed the maximum number of entries in the MAP table.

Recovery

1. Display the contents of the MAP table. Enter the rtrv-map command.
2. Delete an existing MAP table entry. Enter the dlt-map command.
3. Add the new entry to the MAP table. Re-enter the chg-map or ent-map command as applicable. Refer to the *Commands Manual* for detailed information about the use of these commands. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4527 Cmd Rej: Specified MAPSET does not exist

Commands Used: chg-gsmmap-scrn, chg-gsms-opcode, chg-gta, chg-gtt, chg-map, chg-mrn, dlt-map, ent-gsmmap-scrn, ent-gsms-opcode, ent-gta, ent-gtt, rtrv-gsmmap-scrn, rtrv-gsms-opcode, rtrv-gta, rtrv-gtt, rtrv-map

The value specified for the **mapset** parameter must already exist in the MAP table.

Recovery

1. Display the MAP table.
Enter the `rtrv-map` command.
2. Add the MAPSET to the MAP table.
Enter the `ent-map` command. Refer to the *Commands Manual* for detailed information about the use of these commands.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4528 Cmd Rej: PC/SSN doesn't exist in MAPSET

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`, `chg-gtt`, `chg-map`, `dlt-map`, `ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gta`, `ent-gtt`, `rtrv-map`

For the `chg/dlt/rtrv-map` commands, if the **pc/ssn/mapset** parameters are specified, then that **pc/ssn/mapset** combination must already be provisioned in the MAP table.

The specified **pc/ssn** must exist in the MAPSET id the **mapset** parameter is

- not specified as **dflt**.

OR

- specified as **dflt** (**mapset=dflt**) and the **force** parameter is specified as **no** (**force=no**).

Recovery `chg/dlt/rtrv-map` commands

1. Display the **pc/ssn/mapset** entries that are in the MAP table. Enter the `rtrv-map` command.
2. Re-enter the appropriate `chg/dlt/rtrv-map` command specifying a valid **pc/ssn/mapset** parameter combination that exists in the MAP table.

Recovery `chg-gsms-opcode`

1. Display the **pc/ssn** entries that are in the MAP table. Enter the `rtrv-map` command.
2. Re-enter the `chg-gsms-opcode` command specifying a valid **pc/ssn** that exists in the MAP table.

Recovery `ent-gsms-opcode`

1. Display the **pc/ssn** entries that are in the MAP table.
Enter the `rtrv-map` command.
2. Re-enter the `ent-gsms-opcode` command specifying a valid **pc/ssn** that exists in the MAP table.

E4529 Cmd Rej: MAP entry is being referred by other entities

Commands Used: `dlt-map`

If the **mapset** parameter has any value other than **dflt**, then the PC/SSN/MAP set cannot be referenced from the GTT, GSM-MAP Opcode, GSM MAP Screening, or MRN table entry.

Recovery

1. Display the MAP table.
Enter the `rtrv-map` command.
2. From the output of Step 1, determine if the **pc/ssn/mapset** parameters reference a GTT, GSM-MAP Opcode, GSM MAP Screening, or MRN table entry.
3. To delete a MAP, enter the `chg-map` command specifying **mapset=dflt**.

E4530 Cmd Rej: MAPSET must be specified if action is FORWARD/DUP/DUPDISC

Commands Used: `chg-gsms-opcode`, `ent-gsms-opcode`

The **mapset** parameter must be specified if the screening **action** parameter is specified as either **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the command specifying the **action** parameter as either **forward**, **duplicate**, or **dupdisc** and the **mapset** parameter.

E4531 Cmd Rej: NMAPSET must be specified if FORCE is specified

Commands Used: `chg-gsms-opcode`, `chg-gsmmap-scrn`

The **force** parameter may be specified only if the new mapset id (**nmapset**) parameter is specified.

Recovery

Re-enter the command specifying both the **force=yes** and the **nmapset** parameters.

E4532 Cmd Rej: MAPSET must be specified (only) if RI parameter is SSN

Commands Used: `chg-gtt`, `ent-gtt`

The **mapset** parameter can only be specified, if the Flexible GTT Load-Sharing (FGTTLS) feature is enabled and the **ri=ssn**. The **mapset** parameter must be specified when the Flexible GTT Load-Sharing (FGTTLS) feature is enabled and **ri=ssn**. The **mapset** parameter must not be specified if **ri=gt**.

Recovery

Re-enter the command specifying both the **ri=ssn** and the **mapset** parameters

E4534 Cmd Rej: CSPC entry is being referred by other entities

Commands Used: `dlt-cspc`

You cannot delete a Concerned Signaling Point Code group cannot that is still referenced by one or more Mate Application entities. The specified CSPC group cannot be deleted because it is being referenced by other RPC3/MAP table entries.

Note:

Error message E4534 can only be received if the Flexible GTT Load-Sharing feature is enabled. If the Flexible GTT Load-Sharing feature is not enabled, the following caution note will be displayed:

CSPC GROUP MAY BE IN USE BY A MATE APPLICATION

Recovery

1. Display the RPC3/MAP table.
Enter the `rtrv-cspc` command.
2. Reassign the specified **cspc** references in the RPC3/MAP table.
Enter the `chg-cspc` command.
3. Delete the specified **cspc** from the RPC3/MAP table.
Enter the `dlt-cspc` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4535 Cmd Rej: NDGT parameter mustn't be specified

Commands Used: `chg-gttset`, `ent-gttset`

The **ndgt** parameter cannot be specified if the **settype** parameter has a value of **cdssn**, **cgpc**, **cgssn**, **opc**, or **opcode** .

Recovery

Perform one of the following

- Re-enter the command without specifying the **ndgt** parameter.
OR
- Re-enter the command specifying the **ndgt** parameter and change the value for the **settype** parameter. Refer to the *Commands Manual* for more information about GTT set type parameters.

E4536 Cmd Rej: settype parameter must be specified

Commands Used: `ent-gttset`

If the OBSR feature is enabled or the TOBR feature is turned on, then the **settype** parameter must be specified.

Recovery

Re-enter the command, and specify a value for the **settype** parameter.

If this error message occurs again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4537 Cmd Rej: Power Threshold entry already exists in FPT table

Commands Used: `ent-frm-pwr`

The value specified for the **thrshld** parameter is already be provisioned in the Frame Power Threshold table.

Recovery

Enter the `chg-frm-pwr` command specifying a different value (valid range is **30 - 65** amps) for the **thrshld** parameter.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4538 Cmd Rej: Power Threshold entry does not exist in FPT table

Commands Used: `chg-frm-pwr`, `dlt-frm-pwr`

A value for the frame power threshold (**thrshld**) parameter does not exist in the Frame Power Threshold table.

Recovery

Enter the `ent-frm-pwr` command to add the **thrshld** parameter value to the Frame Power Threshold table.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4539 Cmd Rej: Failed reading FPT table

Commands Used: `chg-frm-pwr`, `dlt-frm-pwr`, `dlt-shlf`, `ent-frm-pwr`, `rtrv-frm-pwr`

The Frame Power Threshold table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4540 Cmd Rej: Failed reading Assembly Power table

Commands Used: `rtrv-stp`

The Assembly Power table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4541 Cmd Rej: Entered Frame must be a provisioned frame

Commands Used: `ent-frm-pwr`, `rtrv-frm-pwr`, `rtrv-stp`

The frame specified by the Frame ID parameter (**frm**) must be a provisioned frame (a shelf is provisioned in that frame). [Table 32: Frame ID Parameter Values](#) lists supported Frame ID parameter values.

Table 32: Frame ID Parameter Values

CF00	Control Frame
EF00	First Extension Frame
EF01	Second Extension Frame
EF02	Third Extension Frame
EF03	Fourth Extension Frame
EF04	Fifth Extension Frame

Recovery

1. Determine which shelves are provisioned.
Enter the `rtrv-shlf` command.

2. Re-enter the command specifying a value for the **frm** parameter for a provisioned frame (shelf is provisioned in that frame).

E4542 Cmd Rej: Failed deleting shelf as FPT entry is provisioned

Commands Used: `dlt-shlf`

If the equipped shelf is the only provisioned shelf in the frame, the Frame Power Threshold (FPT) entry cannot be configured for the corresponding frame in the Frame Power Threshold table.

Recovery

1. Delete the frame power value for the specified frame.
Enter the `dlt-frm-pwr` command.
2. Delete the shelf.
Enter the `dlt-shlf` command.

E4543 Cmd Rej: PC/MAPSET does not exist in MAP table

Commands Used: `dlt-map`, `rtrv-map`, `chg-gta`

If new or existing **ri=ssn** and **xlat=dpc** or parameters are specified, and the **pc/pca/pci/pcn/pcn24** parameter is not specified, then the existing **pc** must exist in the Remote Point Code/MAP table, unless the **force=yes** parameter is specified. If new or existing **ri=ssn** and **xlat=dpcsn** parameters are specified, a new or existing **xlat=dpcsn** parameter must exist in the Remote Point Code/MAP table, unless the **force=yes** parameter is specified.

No matching entry for the specified **pc** and **mapset** exists in the MAP Table.

- For the `dlt-map` command, if the **pc** and **mapset** parameters are specified and **all=yes** is specified, then at least one entry for that **pc/mapset** must exist in MAP table.
- For the `rtrv-map` command, if the **pc** and **mapset** parameters are specified and the **ssn** parameter is not specified, then at least one entry for that **pc/mapset** must exist in MAP table.

Recovery

Re-enter the command specifying valid **pc** and **mapset** parameter values.

E4544 Cmd Rej: The IDPS for Prepaid Feature Must be Enabled

Commands Used: `enable-ctrl-feat`

The IDP Screening for Prepaid feature must be enabled before provisioning is allowed.

Note:

Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off using the `chg-ctrl-feat` command.

Refer to the *Commands Manual* for more information about enabling features using access keys.

Recovery

1. Display the features in the database.
Enter the `rtrv-ctrl-feat` command.
2. If the IDP Screening for Prepaid feature is enabled (see the output of Step 1), re-enter the command that generated this message.
3. If the IDP Screening for Prepaid feature is not enabled, enable it.
Enter the `enable-ctrl-feat` command. Refer to the *Commands Manual* for detailed information about the use of the `enable-ctrl-feat` command.
4. Verify that the IDP Screening for Prepaid feature is enabled.
Enter the `rtrv-ctrl-feat` command. Re-enter the command that generated this message. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4545 Cmd Rej: IDP Screening for Prepaid feature must be ON when SERV=IDPS

Commands Used: `chg-ctrl-feat`

The IDP Screening for Prepaid (IDPS) feature must be on before you can specify the `serv=idps` parameter.

Recovery

1. Display the status of the IDP Screening for Prepaid feature in the database. Enter the `rtrv-ctrl-feat` command.
2. If the IDP Screening for Prepaid feature is turned on (see the output from Step 1), re-enter the `chg-ctrl-feat` command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
3. If the IDP Screening for Prepaid feature is turned off or does not appear in the output from Step 1, refer to the Database Administration Manual - Features to enable, turn on, and use the IDP Screening for Prepaid feature.
4. Re-enter the command that generated this error message
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4546 Cmd Rej: GTT must be ON before IDPS can be enabled

Commands Used: `chg-feat`, `enable-ctrl-feat`

The GTT feature must be on before the IDP Screening for Prepaid feature can be enabled.

Recovery

1. Display the status of the controlled features in the database. Enter the `rtrv-feat` command. If the feature has a status of OFF, then the feature is not turned on.
2. Enable the GTT feature as necessary. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4548 Cmd Rej: Requested service parameters not supported when SERV=IDPS

Commands Used: `chg-srvsel`, `ent-srvsel`

If the `nserv=idps` parameter is specified, then the only valid mandatory service parameters are `tt`, `serv`, `ssn`, `gtin`, and `gtii`. The optional service selector parameters supported are: `np` and `nai`.

Recovery

Re-enter the command specifying the correct service selector parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4549 Cmd Rej: EDATE/ETIME must be greater than current system date/time

Commands Used: `inh-alm`

For the `inh-alm` command, the `edate` and `etime` specified must be greater than the current system date and time.

Recovery

Re-enter the `inh-alm` command specifying values for the `edate` and `etime` parameters that are greater than the values for the current system date and time.

E4550 Cmd Rej: Both EDATE and ETIME parameters are required

Commands Used: `inh-alm`

For the `inh-alm` command, both **edate** and **etime** parameters must be specified if the value of the **dur** parameter is specified as **timed** (**dur=timed**).

Recovery

Re-enter the `inh-alm` command specifying **dur=timed** and both the **edate** and the **etime** parameters.

E4551 Cmd Rej: DISPLAY parameter is mandatory with DUR parameter

Commands Used: `rept-stat-alm`

The **display** parameter (**disp**) must be specified if the **dur** parameter is specified.

Recovery

Re-enter the `rept-stat-alm` command specifying both the **dur** parameter and the **disp** parameter.

E4552 Cmd Rej: DUR parameter is mandatory with EDATE parameter

Commands Used: `rept-stat-alm`

For the `rept-stat-alm` command, if you specify the **edate** parameter, you must also specify the **dur** parameter.

Recovery

Re-enter the `rept-stat-alm` command specifying both the **edate** parameter and the **dur** parameter.

E4553 Cmd Rej: EDATE parameter requires DUR = timed

Commands Used: `rept-stat-alm`

For the `rept-stat-alm` command, if the **edate** parameter is specified, the value specified for the **dur** parameter must be **timed**.

Recovery

Perform one of the following actions:

Re-enter the `rept-stat-alm` command specifying the **edate** parameter and **timed** for the **dur** parameter **dur=timed**.

OR

Re-enter the `rept-stat-alm` command without specifying **edate** parameter.

E4554 Cmd Rej: DEV must be either slk, ls, or route if CLI is specified

Commands Used: `rept-stat-alm`

The **device** parameter must be specified as either **slk**, **ls**, or **route**, if the **cli** parameter is specified.

Recovery

Perform one of the following actions:

Re-enter the `rept-stat-alm` command specifying either **slk**, **ls** or **route** for the **device** parameter if the **cli** parameter is specified.

OR

Re-enter the `rept-stat-alm` command without specifying **cli** parameter.

E4555 Cmd Rej: Version parameter not supported for SUA or M3UA

Commands Used: `chg-assoc`

The adapter type specified (SUA or M3UA) is not supported by the **ver** parameter. The **ver** parameter only supports M2PA adapters (**ver=d6**) or (**ver=rfc**).

Recovery

Re-enter the `chg-assoc` command specifying the **ver** parameter only when the adapter is an M2PA Draft 6 (**ver=d6**) or M2PA RFC (**ver=rfc**).

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4556 Cmd Rej: Timer not supported for M2PA Draft 6

Commands Used: `chg-m2pa-tset`

The T2 timer is not supported by M2PA Draft 6. The T2 timer was specified with the **ver=d6** parameter specified. The T2 timer can only be specified when **ver=rfc**.

Recovery

Re-enter the `chg-m2pa-tset` command specifying **ver=rfc** for the T2 timer.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4557 Cmd Rej: Timer value or SRCTSET required

Commands Used: `chg-m2pa-tset`

A timer value or M2PA timer set value (**srctset**) must be specified. If the **srctset** parameter is specified, no other timer values can be specified. Also, the timer set specified here cannot be the timer set specified by the timer set name (**tset**) parameter.

Note:

The **srctset** parameter and the **tset** parameter cannot specify the same timer set name.

Recovery

Re-enter the `chg-m2pa-tset` command specifying an M2PA timer parameter or the **srctset** parameter.

Refer to the *Commands Manual* for detailed information about the use of the `chg-m2pa-tset` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4558 Cmd Rej: Provisioned SCCP cards must not be greater than 25

Commands Used: `ent-card`, `enable-ctrl-feat`

- If any EPAP-based feature is turned on, or the ATINP feature is enabled, then the maximum number of Service Module cards allowed in the system is 25.
- If the system is running only GTT, the maximum number of Service Module cards allowed in the system is 32.

Recovery

1. Determine which features are turned on in the system.
Enter the `rtrv-feat` and `rtrv-ctrl-feat` commands.
2. Determine the total number of VSCCP cards provisioned in the system.
Enter the `rept-stat-sccp` or `rept-stat-sys` command.

E4560 Cmd Rej: CGSSNSN set domain must be the same as GTTSN set domain

Commands Used: `chg-gta`, `ent-gta`

The name specified for the GTT set name (**gttsn**) set domain, and the CGSSN Set Name (**cgssnsn**) set domain, must be the same (either **ansi** or **itu**).

Recovery

Re-enter the command specifying the same name (either **ansi** or **itu**) for both the **cgssnsn** and **gttsn** parameters.

E4561 Cmd Rej: MO-based IS41 SMS NP must be enabled

Commands Used: `chg-is41smsopts`

The MO-based IS41 SMS NP feature must be enabled before the **mosmsnai=unknown** parameter or the **mosmstype** parameter can be specified.

Recovery

1. Display the status of the MO-based IS41 SMS NP feature using the `rtrv-ctrl-feat` command.
2. If the MO-based IS41 SMS NP feature is OFF or not showing, enable the feature. Refer to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that caused this error to appear.

E4563 Cmd Rej: IPGW linksets not supported for proxy destinations

Commands Used: `chg-ls`

If an IPGW linkset is used, then the value specified for the **apc** parameter cannot be associated with a proxy point code.

Recovery

If the **ipgwapc=yes** parameter is specified, then re-enter the command and do not specify the **prx=yes** parameter. Refer to the *Database Administration Manual - System Management* and to the Commands Manual for assistance.

E4464 Cmd Rej: Common screening list invalid parameter combination

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`, `rtrv-csl`

The specified parameter combination is invalid.

Recovery

Re-enter the command, and specify an appropriate parameter combination. Refer to the command descriptions in the *Commands Manual* for assistance.

E4565 Cmd Rej: SCCP Loop Detection Feature is not enabled

Commands Used: `chg-gta`, `chg-gtt`, `chg-loopset`, `dlt-loopset`, `ent-gta`, `ent-gtt`, `ent-loopset`, `rtrv-loopset`

Before you can access the Loopset table, the GTT feature must be turned on and the SCCP Loop Detection feature must be enabled.

Recovery

1. Display the status of features that are controlled by feature bits in the database. Enter the `rtrv-feat` command.
2. If the GTT feature is turned off, turn it on. Enter the command: `chg-ctrl-feat:gtt=on`
3. Enable the SCCP Loop Detection feature. Enter the command:
`enable-ctrl-feat:partnum=893016501:fak=<SCCP Loop Detection FAK>`
4. Re-enter the command to access the Loopset table.
Call your Customer Care Center if this error message appears again.

E4566 Cmd Rej: LoopSet Table is full

Commands Used: `chg-loopset`, `ent-loopset`

The Loopset table is full. You must change or delete an existing loopset entry before another entry can be added to the Loopset table. The Loopset table can hold a maximum of 1000 loopsets. Each loopset can have a maximum of 12 point code entries for a total maximum of 12000 point codes.

Recovery

1. Display all the loopsets in the database. Enter the command: `rtrv-loopset:num=1000:force=yes`.
2. Change or delete an existing loopset entry using the `chg-loopset` or `del-loopset` commands.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4567 Cmd Rej: Cannot access Loop Set table

Commands Used: `chg-gta`, `chg-gtt`, `chg-loopset`, `dlt-loopset`, `ent-gta`, `ent-gtt`, `ent-loopset`, `rtrv-loopset`

The Loopset table is corrupt or cannot be found by the system. The Loopset table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4568 Cmd Rej: Loop Set entry does not exist

Commands Used: `chg-gta`, `chg-gtt`, `chg-loopset`, `dlt-loopset`, `ent-gta`, `ent-gtt`, `rtrv-loopset`

The specified loopset entry does not exist in the Loopset table.

Recovery

1. Display all the loopsets in the database. Enter the command:
`rtrv-loopset:num=1000:force=yes`
2. Re-enter the command specifying a valid entry that exists in the Loopset table.

E4569 Cmd Rej: Cannot delete loopset when in use by GTT

Commands Used: `dlt-loopset`

The specified loop set cannot be deleted because it is being used by the GTT feature. A loopset entry that is being referenced by the GTT feature cannot be deleted.

Recovery

1. Replace all point code entries in the specified loopset with a single point code. Enter the `chg-loopset` command specifying the name, `rpcl` and `force` parameters.

Example: `chg-loopset:name=loopset2:rpcl=3-2-3:force=yes`.

Note: The `rpcl` parameter allows up to 6 comma-delimited entries in the point code list.

Note: If the `force=yes` parameter is specified with the `dlt-loopset` command, only the specified point code is removed from the loopset.

2. Delete the remaining point code from the specified loopset. Enter the `dlt-loopset` command specifying the `force=yes` parameter.

Example: `dlt-loopset:loopset2:pcla=3-2-3:force=yes`

For more information, refer to the procedure "Removing a Loopset" in the Database Administration-Global Title Translation Manual.

OR

3. Use the `chg-loopset` command to change the loopset reference to `NONE` or to another loopset name. For more information, refer to the procedure "Changing the Attributes of a Loopset" in the Database Administration-Global Title Translation Manual.

E4570 Cmd Rej: Point Code in use by GTT Force parameter required

Commands Used: `dlt-loopset`

The point code that you specified to be deleted is in use by GTT. You must specify the `force=yes` parameter to delete a point code entry that is in use by the GTT feature.

Recovery

Re-enter the `dlt-loopset` command specifying the `force=yes` parameter.

For more information, refer to the procedure "Removing a Loopset" in the Database Administration-Global Title Translation Manual.

E4571 Cmd Rej: Addition of these point codes will exceed the pc limit

Commands Used: `chg-loopset`

A maximum of 6 point codes can be added using this command with the `apcl` parameter. The Loopset entry can contain a maximum of 12 point codes.

Recovery

1. Display the contents of the Loopset. Enter the `rtrv-loopset` command specifying the name of the loopset.
2. Delete a single point code entry in the specified loop set using the `dlt-loopset` command.
3. Re-enter the `chg-loopset` command specifying the `apcl` and `rpcl` parameters as necessary, to add the desired point codes to the loopset.

For more information, refer to the procedure “Changing the Attributes of a Loopset” in the Database Administration–Global Title Translation Manual.

E4572 Cmd Rej: Requires force since Loopset is in use by GTT

Commands Used: `chg-loopset`

The `force` parameter must be specified to modify a loopset that is being referenced by the GTT feature.

Recovery

Re-enter the `chg-loopset` command specifying the `force=yes` parameter.

E4573 Cmd Rej: PC2 parameter requires PC1 parameter

Commands Used: `chg-loopset`

If the `pc2` parameter is specified, the `pc1` parameter must be also be specified.

Recovery

Re-enter the `chg-loopset` command specifying values for both `pc1` and `pc2` parameters.

E4574 Cmd Rej: NPC1/NPC2 requires use of PC1/PC2

Commands Used: `chg-loopset`

If the `npc1/npc2` parameters are specified, the `pc1/pc2` parameters must be also be specified. Changing or replacing an existing point code with a new point code.

Recovery

Re-enter the `chg-loopset` command specifying values for both the `pc1/pc2` parameters and the `npc1/npc2` parameters.

E4575 Cmd Rej: Replace and Append Point Code lists are mutually exclusive

Commands Used: `chg-loopset`

You cannot specify the replacing point code list (`rpcl`) parameter and the appending point code list (`apcl`) parameter in the same command.

Recovery

Re-enter the command specifying either the `apcl` or `rpcl` parameters, but not both.

E4576 Cmd Rej: PC1/PC2 cannot be used with either Point Code list

Commands Used: `chg-loopset`

You cannot specify the `pc1/pc2` parameters and the replacing point code list (`rpcl`) parameter, or appending point code list (`apcl`) parameter, in the same command.

Recovery

Re-enter the command specifying either the `pc1/pc2` parameters or the `apcl` parameter or the `rpcl` parameter.

E4577 Cmd Rej: Loop Set entry already exists

Commands Used: `ent-loopset`

The specified loopset name cannot already exist in the database.

Recovery

1. Display the entries in the Loop Set table. Enter the `rtrv-loopset` command.
2. Re-enter the `ent-loopset` command specifying a different set of parameter values.

For more information, refer to the procedure "Adding a Loopset" in the *Database Administration—Global Title Translation Manual*.

E4578 Cmd Rej: Point Code and display of type gtt are mutually exclusive

Commands Used:

If the `type=gtt` parameter is specified, you cannot specify both the point code parameter (`pc`) and display parameter (`disp`) together in the same command.

Recovery

Re-enter the command specifying either the **pc** or the **disp** parameter, but not both.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4579 Cmd Rej:MTPLPRST option must be enabled

Commands Used: `chg-stpopts`, `rtrv-stpopts`

The MTP Low Priority Route Set Test option must be enabled.

The MTP Low Priority Route Set Test option controls route-set-test messaging for routes other than the DPC-only least cost routes. If higher cost routes are used for exception routing, this feature maintains accurate non-adjacent status to ensure that routing occurs properly.

Recovery

Enable the MTP Low Priority Route Set Test option. Enter the `chg-stpopts:mtplprst=yes` command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4580 Cmd Rej: CIC must be specified if ECIC is specified

Commands Used: `chg-rtx`, `dlt-rtx`, `ent-rtx`, `rtrv-rtx`

The start circuit identification code (**cic**) parameter must be specified if the end circuit identification code (**ecic**) parameter is specified.

Recovery

Re-enter the command specifying both the **cic** and the **ecic** parameters.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4581 Cmd Rej: Unsupported Hardware is equipped in the system

Commands Used: `chg-ctrl-feat`, `chg-feat`, `enable-ctrl-feat`

The feature is mutually exclusive with hardware in the system. Refer to the command description in the *Commands Manual* for a list of mutually exclusive features and hardware.

Recovery

1. Upgrade the hardware to ensure that no unsupported cards are on the system.
2. Refer to the appropriate Feature Manual for information on how to enable and turn on the feature.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4582 Cmd Rej: Single rte to APC/SAPC for IPGW LS allowed

Commands Used: `chg-ls`, `chg-rte`, `ent-ls`, `ent-rte`

An APC or SAPC cannot be assigned to an IPGWx linkset that is already assigned to a route involving another linkset.

- For the `chg-rte` and `ent-rte` commands, you cannot assign more than one route to an APC or SAPC for an IPGWx linkset.
- For the `chg-ls` command, you cannot assign an SAPC to an IPGWx linkset that is already assigned to a route involving another linkset.
- For the `ent-ls` command, you cannot assign an APC or SAPC to an IPGWx linkset that is already assigned to a route involving another linkset.

Recovery

Re-enter the `ent/chg-rte` command specifying a different DPC since the selected point code (APC or SAPC of an IPGWx linkset) is already assigned a single route.

E4583 Cmd Rej: DISPLAY parameter is mandatory with FRM parameter

Commands Used: `rtrv-stp`

The display id (**display**) parameter must be specified if the frame id (**frm**) parameter is specified.

Recovery

Re-enter the `rtrv-stp` command specifying both the **display** and **frm** parameters.

E4584 Cmd Rej: MTP Origin Based Routing Feature must be ON

Commands Used: `chg-rtx`, `dlt-rtx`, `ent-rtx`, `rept-stat-rte`, `rtrv-rtx`

The MTP Origin Based Routing feature must be enabled and turned on before you can access a UI option that is unique to the feature.

Recovery

1. Determine the status of the MTP Origin Based Routing feature.
Enter the `rtrv-ctrl-feat` command.
2. Verify that the MTP Origin Based Routing feature has been purchased and installed in the system.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

3. If the MTP Origin Based Routing feature is enabled, go to step 5.
4. If the MTP Origin Based Routing feature is not enabled, enable it.
Enter the `enable-ctrl-feat` command and the appropriate part number and access key information. Verify that the MTP Origin Based Routing feature is enabled. Enter the `rtrv-ctrl-feat` command. Refer to the *Commands Manual* for detailed information about the use of the `enable-ctrl-feat` command.
5. Turn on the MTP Origin Based Routing feature.
Enter the `chg-ctrl-feat` command. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4585 Cmd Rej: Failed Reading SCCP Service Table

Commands Used: `chg-sccp-serv`, `dlt-sccp-serv`, `rtrv-mrn`, `rtrv-sccp-serv`

The SCCP Service table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4586 Cmd Rej: Invalid combination of new and existing point codes

Commands Used: `chg-mrn`, `chg-sccp-serv`, `dlt-mrn`, `ent-mrn`, `rtrv-mrn`

The combination of point codes specified are invalid. You cannot specify both new and existing point codes together in the same command. Either all of the specified PCs, (`pc1`, `pc2`, `pc3` and `pc4` parameters) must already exist or none of the specified PCs can exist.

Note:

When using the `chg-sccp-serv` command to add new point codes, none of the point codes that are specified in one command can already exist in the SCCP-SERV group in the SCCP-SERV table, and all of the point codes must be added to the same SCCP-SERV group.

Recovery

Re-enter the command specifying a valid combination of point codes.

E4587 Cmd Rej: At least one point code must be specified

Commands Used: `dlt-sccp-serv`

You entered this command without specifying at least one point code.

Recovery

Re-enter the `dlt-sccp-serv` command specifying both the point code parameter (**pc**) and its associated relative cost (**rc**) together as a pair.

E4589 Cmd Rej: SCCP-SERV allocation within MRN table is full

Commands Used: `chg-sccp-serv`

The SCCP Service table cannot be full when the command is entered. For each supported service (G-Port and G-Flex), up to 7 point codes can be specified for each network type (ANSI, ITU-I, S-ITU-I, ITU-N, S-ITU-N, and ITU-N24).

Recovery

1. Display the SCCP Service table. Enter the `rtrv-sccp-serv` command.
2. Change one of the existing point codes in the SCCP service group. Enter the `chg-sccp-serv:pc=xxx-xxx-xxx:rc=xxx` command where `xxx-xxx-xxx` is a point code in the SCCP service group from the output in Step 1.

E4590 Cmd Rej: Maximum point codes have been allocated to SCCP-SERV set

Commands Used: `chg-sccp-serv`

The specified SCCP service group (or SCCP Service set) is full. You cannot provision more than seven point codes in a SCCP service group. Before you can add a new point code to the group, you must delete an existing point code from the group.

Recovery

1. Display the SCCP Service table. Enter the `rtrv-sccp-serv` command.
2. Change one of the existing point codes in the SCCP service group. Enter the `chg-sccp-serv:pc=xxx-xxx-xxx:rc=xxx` command where `xxx-xxx-xxx` is a point code in the SCCP service group from the output in Step 1.

E4591 Cmd Rej: PC must already exist in the SCCP-SERV set

Commands Used: `dlt-sccp-serv`

The specified point code does not exist in the specified SCCP service group.

Recovery

1. Display the SCCP Service table. Enter the `rtrv-sccp-serv` command.
2. Re-enter the `dlt-sccp-serv` command specifying a point code that exists in the specified SCCP service group.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4594 Cmd Rej: Feature associated with SERV must be ON or enabled

Commands Used: `chg-feat`, `chg-sccp-serv`, `enable-ctrl-feat`, `rtrv-sccp-serv`

The G-Flex feature must be enabled before the **serv=gflex** parameter can be specified.

The G-Port feature must be enabled before the **serv=gport** parameter can be specified.

The A-Port or IGM feature must be enabled and turned on before the **serv=mnps** parameter can be specified.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` command.
2. If the G-Flex is turned on, or the G-Port or A-Port or IGM feature is on, re-enter the command.
3. If none of the features are on or enabled,
 - a) Refer to the *Feature Manual - G-Flex C7 Relay* to turn on the G-Flex feature.
 - b) Refer to the *Feature Manual - G-Port* to enable and turn on the G-Port feature.
 - c) Refer to the *Feature Manual - EIR* to enable and turn on the EIR feature.
 - d) Refer to the *Feature Manual - IS41 GSM Migration* to enable and turn on the IGM feature.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4595 Cmd Rej: Only one E1/T1 port allowed for Linkclass=Unchan

Commands Used: `ent-e1`, `ent-t1`

Only 1 port can be used for E1 interfaces on an E5-E1T1 card that is used as an SE-HSL card. Any 1 of the 8 ports can be used on the SE-HSL card.

Only 1 of the 8 ports can be used for T1 interfaces on an E5-E1T1 card that is used as an ST-HSL-A card.

Recovery

Re-enter the command specifying only one E1/T1 port on an E5-E1T1 card as **linkclass=unchan**.

E4596 Cmd Rej: Point Code does not exist in Loopset Table

Commands Used: `chg-loopset`, `dlt-loopset`

The value specified for the **pc1** or **pc2** parameter must exist in the Loopset table.

Recovery

1. Display the list of point codes in the Loopset table. Enter the `rtrv-loopset` command.
2. Re-enter the command, specifying a point code from the Loopset table.
Call your Customer Care Center if this error message appears again.

E4597 Cmd Rej: RTKEY DPC cannot be IPGWx APC or SAPC

Commands Used: `ent-appl-rtkey`, `ent-ls`

You cannot specify a DPC for a routing key that is the adjacent node (APC) or Secondary Adjacent Point Code (SAPC) for an IPGW linkset.

- A new IPGW link set cannot be entered if it contains an APC that is already configured in a routing key.
- An SAPC cannot be added to an existing IPGW link set if the new SAPC is already configured in a routing key.

Recovery

1. Display a list of point codes in the linkset. Enter the `rtrv-ls` command.
2. Re-enter the `ent-appl-rtkey` command specifying a DPC that is not an APC or SAPC for an IPGW linkset.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4598 Cmd Rej: Routing Context not configured

Commands Used: `chg-appl-rtkey`

The value of the **nrcontext** parameter cannot be changed for a routing key if the **rcontext** parameter has not been configured for that routing key.

Recovery

1. Provision the **rcontext** parameter for the routing key. Enter the command
`chg-appl-rtkey:rcontext=`
2. Re-enter the **chg-appl-rtkey** command specifying both the **rcontext** parameter and the new value for the **nrcontext** parameter for the routing key.
Example: `chg-appl-rtkey:rcontext=1:nrcontext=2`

E4599 Cmd Rej: GTT Set specified by GTTSN is being referred in SCCOPTS

Commands Used: `dlt-gttset`

You cannot delete a GTT set that is still referenced by the SCCP Options table.

Recovery

1. Display the SCCP Options table. Enter the `rtrv-sccpopts` command.
2. Delete the specified GTT Set name. Enter the `chg-sccpopts` command specifying **gttsn=none**.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4600 Cmd Rej: Must specify ASNAME or RC

Commands Used: `ent-appl-rtkey`

Either the **asname** or **rc** parameter must be specified.

Recovery

Re-enter the `ent-appl-rtkey` command, specifying either the **asname** or the **rc** parameter.

Refer to the *Commands Manual* for detailed information about the use of the `ent-appl-rtkey` command.

E4602 Cmd Rej: Requested Assoc Buffer Space Exceeds Available Buffer Space

Commands Used: `chg-assoc`, `ent-assoc`

The requested associate buffer size exceeds available buffer space for the card type. [Table 33: Default Buffer Configuration Sizes](#) lists the supported card and allowable buffer configuration sizes.

Table 33: Default Buffer Configuration Sizes

Card	Default Buffer Size (KB)	Minimum Buffer Size (KB)	Maximum Buffer Size (KB)
DCM/IPGW	16	8	400
EDCM/IPLIM	200	8	400
EDCM/IPGW	16	8	400
E5-ENET/IPLIM	200	8	400
E5-ENET/IPGW	16	8	400

Recovery

1. Determine the used and total sctp buffer space on the card and the card location. Enter the `rtrv-assoc` command.
2. Re-enter the command specifying a buffer size that is between 8 and 400 KB.
Example: `chg-assoc:aname=xxxxx:open=no chg-assoc:aname=xxxxx:bufsize=345`
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4603 Cmd Rej: CGTT/CGNPV/CGNAIV mustn't be specified when CGGTIx=0

Commands Used: `rtrv-data-gtt`

You cannot specify the `cgtt`, `cgnpv`, or `cgnaiv` parameters when the value specified for the `cggti(x)` parameter is 0 (`cggti(x)=0`).

Recovery

Re-enter the command specifying `cggti(x)=0` without specifying the `cgtt`, `cgnpv`, or `cgnaiv` parameters.

E4604 Cmd Rej: CGPC must be specified

Commands Used: `rtrv-data-gtt`

For the `rtrv-data-gtt` command, you must specify a value for the `cgpc` parameter when `gttmode` contains both `cgpa` mode and `cggti(x)=0`.

Recovery

Re-enter the `rtrv-data-gtt` command specifying the `cgpc` parameter.

E4606 Cmd Rej: Point code type mismatch

Commands Used: `chg-loopset`

When adding point codes using the `apcl` parameter, or changing individual point codes using the `pc1/npc1` or `pc1/npc2` parameters, the new point code type must match the point code type of the loopset entry to which these point codes are being added or changed, respectively.

Recovery

Re-enter the `chg-loopset` command specifying a point code that matches the point code type of the loopset.

E4607 Cmd Rej: Linkset referenced by exception route

Commands Used: `dlt-ls`

The specified linkset is referenced by an exception route. You cannot delete a linkset that is being used by an exception route. If the linkset is referenced by the historic routeset of any exception route destination, then this command cannot be entered.

Recovery

Perform one of the following actions:

Re-enter the `dlt-ls` command specifying a linkset that is not referenced by an exception route.

OR

1. Display the Route table.
Enter the `rtrv-rtx` command.
2. Delete the exception route references to the specified linkset.
Enter the `dlt-rtx` command.
3. Delete the specified linkset.
Enter the `dlt-ls` command.

E4608 Cmd Rej: True Point Code can exist only in Default MAPSET

Commands Used: `chg-map`, `ent-map`

A true PC/SSN can only exist in the default MAP Set.

Recovery

1. Display the site point codes in the system.
Enter the `rtrv-sid` command. The site point codes are shown in the *PCA*, *PCI*, *PCN*, and *PCN24* fields of the `rtrv-sid` command output.
2. Re-enter the command specifying a **pc/ssn** that is not listed in the *PCA*, *PCI*, *PCN*, and *PCN24* fields of the output.

E4613 Cmd Rej: Failed Reading SEASCFG Table

Commands Used: `chg-seas-config`, `rtrv-seas-config`, `rept-stat-seas`, `rmv-trm`

The SEASCFG table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.

2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4614 Cmd Rej: SOIP Must be Enabled

Commands Used: `chg-ctrl-feat`, `chg-seas-config`, `chg-trm`, `rtrv-seas-config`

A terminal cannot be configured as type SEAS if the SEAS Over IP Feature is not enabled. The SEAS Over IP feature must be enabled (see the `enable-ctrl-feat` command) before it can be turned on.

Recovery

1. Enable the SEAS Over IP feature. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Turn on the SEAS Over IP feature. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4615 Cmd Rej: SEAS Terminal Not Inhibited

Commands Used: `chg-seas-config`, `chg-trm`

The SEAS terminal must be inhibited before the `seascli`, `ipaddr`, `port`, `login`, `hname`, `authmode`, or `type=seas` parameters can be specified.

Recovery

1. Inhibit the SEAS terminal. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command that generated this message.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4616 Cmd Rej: SEAS Terminal not configured

Commands Used: `chg-ctrl-feat`

At least one SEAS terminal must be configured (see the `chg-trm` command) before the SEAS Over IP feature can be turned on.

Recovery

1. Display the configured terminals in the system by entering the `rtrv-trm` command.
2. Correctly configure at least one terminal as a SEAS terminal. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4617 Cmd Rej: SEAS terminal is Auto-inhibited

Commands Used: `alw-trm`

The specified terminal cannot be an auto-inhibited SEAS terminal.

Recovery

1. Determine the reason the SEAS terminal is auto-inhibited.
 - Enter the `rtr-ctrl-feat` command to determine if the feature is turned off. If this is the case, turn on the **SEAS Over IP** feature. For assistance in turning this feature on, refer to the *Database Administration Manual - Systems Management*.
 - Enter the `rtr-trm` command to determine if an E5-IPSM or simply an IPSM card is present. Make sure an E5-IPSM card is in place and configured for this terminal. Refer to the *Database Administration Manual - Systems Management* for assistance.
 - Determine if the terminal became auto-inhibited due to a critical thermal alarm. If this is the case, refer to the *Unsolicited Alarm and Information Messages Manual* for procedures to recover from a critical thermal alarm.
2. Re-enter the command to allow the SEAS terminal.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4618 Cmd Rej: STPOPTS DefCC must not be NONE

Commands Used: `chg-ctrl-feat`, `enable-ctrl-feat`

The `defcc` system option (see the `chg-stpopts` command) must be provisioned before the feature can be enabled or enabled and turned on.

Recovery

1. Display the `defcc` system option. Enter the `rtrv-stpopts` command.
2. If the `defcc` option shows as **none**, then it must be set to something other than **none** before turning on the feature. Refer to the *Database Administration Manual - Systems Management* or the appropriate feature manual for assistance in turning on the feature.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4619 Cmd Rej: Failed Reading IPTERM Table

Commands Used: `seas-config`, `chg-trm`

The IPTERM table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4620 Cmd Rej: E5-IPSM Card is not Present

Commands Used: `chg-ctrl-feat`, `chg-trm`

All card locations that correspond to SEAS terminals must be provisioned with E5-IPSM cards before the SEAS Over IP feature can be turned on.

Recovery

1. Install and configure E5-IPSM cards in the appropriate locations. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Display the status of the controlled features in the systems by entering the `rtrv-ctrl-feat` command.
3. Turn on the SEAS Over IP feature. Refer to the *Database Administration Manual - Systems Management* to turn on this feature.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4629 Cmd Rej: RI/SETID must not be specified when PC/PCA/PCI/PCN=none

Commands Used: `chg-ppsopts`

If a value of none is specified for the `pc`, `pca`, `pci`, or `pcn` parameter, then the `ri` or `setid` parameter cannot be specified.

Recovery

1. Display the point code values in the PPSOPTS table. Enter the `rtrv-ppsopts` command.
If necessary, refer to the *Database Administration Manual - Global Title Translation* for assistance in changing the values of the point codes.
2. Re-enter the command, and specify a valid combination of parameters. Refer to the command description in the *Commands Manual* for assistance.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4631 Cmd Rej: Multiple Linksets to Single APC feature must be ON

Commands Used: `chg-ls`

The Multiple Linksets to Single Adjacent PC (MLS) feature must be enabled and turned on in order to specify the **spc** parameter.

Recovery

1. Enable the MLS feature. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command to specify the **spc** parameter.

E4632 Cmd Rej: Max linksets to same APC exceeded

Commands Used: `chg-ls`, `ent-ls`

A maximum of 1 IPGW linkset or maximum of 6 of any other linksets are allowed between any APC and the EAGLE 5 ISS.

Recovery

1. Display the existing linksets using the `rtrv-ls` command to verify the maximum number (6) was reached.
2. If another linkset is necessary, then refer to the *Database Administration Manual - System Management* for further assistance in configuring your system.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4633 Cmd Rej: SPC may not be referenced in the STP's linkset table

Commands Used: `chg-ls`, `dlt-spc`

The point code specified by the **apc** parameter must differ from the APC value stored in the Linkset table for the linkset specified by the **lsn** parameter. A secondary point code that is referenced in the Linkset table cannot be deleted. Secondary point codes can only be referenced in the Linkset table if the Multiple Linksets to a **Single Adjacent PC (MLS)** feature is enabled and turned on.

Recovery

Re-enter the command specifying a valid parameter.

E4634 Cmd Rej: No change in APC actually requested

Commands Used: `chg-ls`

The point code specified by the **apc** parameter must differ from the APC value in the Linkset table for the linkset specified by the **lsn** parameter.

Recovery

Re-enter the command, and specify a valid parameter value. Refer to the *Database Administration Manual - System Management* for assistance.

E4635 Cmd Rej: No change in SPC actually requested

Commands Used: chg-ls, chg-dstn

The point code specified by the **spc** parameter must differ from the SPC value stored in the Linkset table for the linkset specified by the **lsn** parameter.

Recovery

Re-enter the command with a valid parameter. For further assistance refer to the *Database Administration Manual - Systems Management*.

E4636 Cmd Rej: SPC may not exist as an SPC in the route table for the APC

Commands Used: chg-ls

If the valid point code in the SPC parameter is specified, it can not exist as an SPC for the linkset's adjacent destination PC (APC) in the Destination table.

Recovery

1. Display the existing SPC by using the `rtrv-spc` command.
2. Verify the SPC does not also exist as an SPC for the linksets for the linksets adjacent destination (APC) in the Destination table.
3. For further assistance refer to the *Database Administration Manual - Systems Management*.

E4637 Cmd Rej: APC has no assigned linksets

Commands Used: rept-stat-ls

At least one linkset must be associated with the point code specified by the **APC** parameter.

Recovery

1. Display at least one linkset with the point code specified by the **APC** parameter. For further assistance refer to the *Database Administration Manual - System Management*.
2. Re-enter the command that generated this message.

E4639 Cmd Rej: Only 1 IPGWx linkset supported by a single APC

Commands Used: chg-ls, ent-ls

An IPGW linkset cannot be moved to a node that already contains a linkset.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. Refer to the *Database Administration Manual - System Management* for assistance.

E4650 Cmd Rej: MT-based IS41 SMS NP must be enabled

Commands Used: `chg-is41smsopts`

The MT-based IS41 SMS NP feature must be enabled before the `mtsmsdnfmt`, `mtsmstype`, `mtsmsparm`, `mtsmsdltr`, `mtsmsdltrv`, `mtsmsackn`, `mtsmsesn`, `mtsmsssn`, `mtsmsnakerr`, `mtsmsdigtype`, or `mtsmschksrc` parameters can be specified.

Recovery

1. Display the MT-based IS41 SMS NP feature. Enter the `rtrv-ctrl-feat` command.
If the MT-based IS41 SMS NP feature is not shown in the output, then the feature is not enabled.
2. Enable the feature. Refer to the *Feature Manual - A-Port* for assistance.
3. Re-enter the command that generated the error message.

E4651 Cmd Rej: Invalid adapter for specified association

Commands Used: `chg-assoc`

An association with `adapter=sua` or `m3ua` cannot be specified for an `lhost` on a card running the `iplim` or `iplimi` application.

An association with `adapter=m2pa` cannot be specified for an `lhost` on a card running the `ss7ipgw` or `ipgwi` application.

An association with `adapter=sua` cannot be specified for an `lhost` on a card running the `ipsg` application.

Recovery

Re-enter the command that generated this error message, and specify a valid value for the association. Refer to the *Commands Manual* for assistance.

E4655 Cmd Rej: MT-Based GSM MMS NP must be enabled

Commands Used: `chg-gsmsmsopts`

The MT-Based GSM MMS NP feature must be enabled before the `mtmmsgta`, `mtmmstype`, `mtmmsentyn`, `mtmmslen`, or `mtmmsackn` parameter can be specified.

Recovery

1. Display the status of the feature. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. The feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Feature Manual - G-Port* for assistance.
3. Re-enter the command that caused this error message. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4657 Cmd Rej: IPGWAPC and IPSG cannot both be YES

Commands Used: `chg-ls,ent-ls`

The `ipgwapc=yes` and the `ipsg=yes` parameters cannot be specified together in the command.

Recovery

1. Display the linkset information. Enter the `rtrv-ls` command.
2. If IPGWx or IPSG linksets are used, then only one of the `ipgwapc` or `ipsg` parameters can have a value of `yes`.
3. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance in configuring the linksets.

E4658 Cmd Rej: ADAPTER can only be specified when IPSG=YES

Commands Used: `chg-ls,ent-ls`

The `adapter` parameter can be specified only for IPSG linksets (the `ipsg=yes` parameter is specified).

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. If the `ipsg` parameter is `yes`, the `adapter` parameter can be specified.
3. For further assistance in configuring the linksets, refer to the *Database Administration Manual - IP7 Secure Gateway*.

E4659 Cmd Rej: RCONTEXT prohibited unless IPSG=YES and ADAPTER=M3UA

Commands Used: `chg-ls,ent-ls`

The `rcontext` parameter can be specified only for IPSG-M3UA linksets.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. If the `ipsg=yes` and `yes` and the `adapter=m3ua` parameters are specified then the `rcontext` parameter can be specified.

3. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance in provisioning the linksets.

E4660 Cmd Rej: No change in RC actually requested

Commands Used: `chg-rte`

The route cost specified by the `rc` parameter must differ from the existing route cost for the linkset specified by the `lsn` parameter.

Recovery

1. Enter a unique `rc` parameter for each linkset. Refer to the *Database Administration Manual - System Management* for assistance.

E4662 Cmd Rej: GSMOPTS DefMCC must not be NONE

Commands Used: `chg-ctrl-feat`

The `defmcc` GSM option (see the `chg-gsmopts` command) must be provisioned before the MT-Based GSM SMS NP feature can be turned on.

Recovery

1. Display the GSM option setting using the `rtrv-gsmopts` command. The value for the GSM option setting must be something other than NONE.
2. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4666 Cmd Rej: ASNOTIF prohibited unless IPSG=YES and ADAPTER=M3UA

Commands Used: `chg-ls,ent-ls`

The `asnotif` parameter can be specified only for IPSG M3UA linksets (when `ipsg=yes` and `adapter=m3ua` are specified or configured).

Recovery

1. Display the paramters specified using the `rtrv-ls` command. To specify the `asnotif` parameter, make sure the `ipsg=yes` and `adapter=m3ua`. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.

E4667 Cmd Rej: IPSG=YES and ADAPTER=M3UA requires LST=A

Commands Used: `chg-ls,ent-ls`

The linkset type must be A (**lst=a**) for IPSP M3UA linksets (when the parameters **ipsg=yes** and **adapter=m3ua** are specified or configured).

Recovery

1. Display the linkset using the `rtrv-ls` command. If it is an IPSP M3UA linkset type A (**lst=a**), then the **ipsg=yes** and **adapter=mp3a** should be specified. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4669 Cmd Rej: SPC is not supported by IPGWx linksets

Commands Used: `chg-ls`, `ent-ls`, `chg-rte`

If an IPGW linkset is used, then the **spc** parameter cannot be specified.

Recovery

1. Display the linkset information. Enter the `rtrv-ls` command.
2. If an IPGW linkset is used, the **spc** parameter cannot be specified.
3. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance in provisioning the linksets.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4672 Cmd Rej: Login, Password, and Host must be set in SEASCFG

Commands Used: `chg-ctrl-feat`

The **login** and **hname** parameters must be provisioned before the SEAS Over IP feature can be turned on

Recovery

1. Use the `chg-seas-config` command to set the **login** and **hname** parameters. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Turn on the SEAS Over IP feature. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4673 Cmd Rej: CCSMR Server password must be 1-15 characters in length

Commands Used: `chg-seas-config`

The value of the password requested by the **login** parameter must be from 1-15 alphanumeric characters in length.

Recovery

1. Select a CCSMR Server password that is 1-15 alphanumeric characters in length.

E4677 Cmd Rej: PRX allowed only if PPC feature is enabled

Commands Used: `chg-dstn`

The Proxy Point Code feature must be enabled before the **prx** parameter can be specified.

Recovery

1. Display the status of the controlled features using the `rtrv-ctrl-feat` command.
2. Enable the Point Proxy Code feature. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that caused this error to occur.

E4678 Cmd Rej: PPC allowed only if PPC feature is enabled

Commands Used: `ent-dstn`, `rtrv-ls`

The Proxy Point Code feature must be enabled before the **ppc** parameter can be specified.

Recovery

1. Enable the Point Proxy Code feature. Refer to the *Database Administration Manual - System Management* for assistance.
2. Re-enter the command that caused this error to occur.

E4679 Cmd Rej: Domain must be SS7 if Proxy PC is specified

Commands Used: `ent-dstn`

If the **prx=yes** parameter is specified, then the **domain=ss7** parameter must be specified.

Recovery

1. Re-enter the command, and specify the **domain=ss7** parameter. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4680 Cmd Rej: Domain must be SS7 if prx is specified as yes

Commands Used: `ent-dstn`

If the **ppc=yes** parameter is specified, then the **domain=ss7** parameter must be specified.

Recovery

1. Re-enter the command, and specify the domain=ss7 parameter. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4681 Cmd Rej: SPC and PPC are mutually exclusive

Commands Used: ent-dstn

The **SPC** and **PPC** parameters must not be specified together in the command.

Recovery

1. For more information on **SPCs** and **PPCs** refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command that caused this error to occur.

E4682 Cmd Rej: PPC and DPC must be of the same network type

Commands Used: ent-dstn

The **DPC** and **PPC** parameters must be of same network type.

Recovery

1. Make sure the **DPC** and **PPC** parameters are the same network type. Refer to the *Database Administration Manual - System Management* for assistance.
2. Re-enter the command that caused this error to occur.

E4683 Cmd Rej: Group code of PPC and DPC must match

Commands Used: ent-dstn

The **DPC** and **PPC** parameters must be of same group code.

Recovery

1. Make sure the **DPC** and **PPC** parameters are the same group code. See the *Database Administration Manual - System Management* for assistance.
2. Re-enter the command that caused this error to occur.

E4684 Cmd Rej: Allowed Proxy PC capacity exceeded

Commands Used: chg-dstn

The total number of proxy destinations cannot exceed value given by the enabled **PPC** quantity feature.

Recovery

1. To review the parameters for the value enabled in the PPC quantity feature and the appropriate number of proxy destinations, refer to the *Database Administration Manual - Systems Management*.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4685 Cmd Rej: PPC referred by other entities

Commands Used: chg-dstn, dlt-dstn

The **prx** parameter cannot be set to **prx=no** if linksets, or other entries of the route(dstn) table refer to this DPC as PPC.

Recovery

1. Change the **prx** parameter to an appropriate value. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter an appropriate command.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4686 Cmd Rej: PPC not supported for IPGWx DPC

Commands Used: ent-ls, ent-dstn

The **lpgwpc** parameter must not be specified as **yes** if the **ppc** parameter is specified as **yes**.

Recovery

1. Change one of the parameters to **no** in order to use them together.

E4687 Cmd Rej: PRX=YES not supported for IPGWx DPC

Commands Used: ent-dstn

The **lpgwpc** parameter must not be specified as **yes** if the **prx** parameter is specified as **yes**.

Recovery

1. Change one of the parameters to **no** in order to use them together.

E4688 Cmd Rej: LST=PRX if & only if APC uses PPC in route(dstn) table

Commands Used: ent-ls

The value specified for the proxy point code must be defined in the Destination table before the **lst=prx** parameter can be specified.

Recovery

1. Display the defined destinations. Enter the `rtrv-dstn` command.
2. If necessary, define the value specified for the proxy point code in the Destination table. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4689 Cmd Rej: PPC must be specified if and only if linktype is PRX

Commands Used: `ent-srvsel`

The **ppc** parameter must be specified if the **lst=prx** parameter is specified.

Recovery

Re-enter the command, and specify the **ppc** parameter if the **lst=prx** parameter is specified. Refer to the *Database Administration Manual - System Management* for assistance.

E4690 Cmd Rej: Cannot use one PPC for more than 10 linksets

Commands Used: `ent-ls`, `ent-srvsel`

A maximum of 10 linksets may reference one proxy point code.

Recovery

Specify a proxy point code that does not have 10 linksets. Refer to the *Database Administration Manual - System Management* for assistance.

E4691 Cmd Rej: Two point codes must not refer each other as PPC

Commands Used: `ent-ls`

Two adjacent point codes cannot reference each other as proxy point codes.

Recovery

Re-enter the command, and use adjacent point codes that do not reference each other as proxy point codes. Refer to the *Database Administration Manual - System Management* for assistance.

E4692 Cmd Rej: One LS must use PPC assigned to APC in route (dstn) table

Commands Used: `dlt-ls`, `ent-ls`

If multiple linksets and a proxy point code are defined for an APC, then the first linkset defined in the `ent-ls` command must use the proxy point code, and the proxy linkset must be the final linkset that is deleted.

Recovery

1. Display the linksets defined for the APC. Enter the `rtrv-ls` command.
2. Re-enter the command that generated the error message. Refer to the command descriptions in the *Commands Manual* and to the *Database Administration Manual - Systems Management* for assistance.

E4693 Cmd Rej: Command not allowed for proxy links

Commands Used: `act-lpo, blk-slk, canc-lpo, dlt-dstn`

This command is not valid for links belonging to proxy linksets

Recovery

1. Display the linksets. Enter the `rtrv-ls` command.
2. A valid command for use with proxy linksets must be used. For a full list of valid commands refer to the *Commands Manual*.

E4694 Cmd Rej: APC must not use SPC and PPC together

Commands Used: `, ent-srvsel`

A linkset must not use the **SPC** and **PPC** features together.

Recovery

1. Make sure that you are not trying to use the **SPC** and a **PPC** features together in the command. Refer to the *Commands Manual* for further assistance.
2. Re-enter the command that initiated this message.

E4695 Cmd Rej: LST=PRX is valid only if PPC feature is enabled

Commands Used: `ent-ls, rtrv-ls`

The Proxy Point Code feature must be enabled before the `lst=prx` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the Proxy Point Code feature does not appear in the command output, then the feature is not enabled in the system.

2. Enable the Proxy Point Code feature. Refer to the *Database Administration Manual - Systems Management* for further assistance.
3. Re-enter the command that initiated this message.

E4696 Cmd Rej: PPC must be a full point code

Commands Used: act-lpo, blk-slk, canc-lpo, dlt-dstn, ent-ls

The specified ppc must be a full point code.

Recovery

1. Make sure the **PPC** is a full point code. Refer to the *Database Administration Manual - Systems Management* for further assistance.
2. Re-enter the command that initiated this message.

E4697 Cmd Rej: PPC and APC must be of the same network type

Commands Used: act-lpo, blk-slk, canc-lpo, dlt-dstn

The specified **APC** and **PPC** must be of the same network type.

Recovery

1. Make sure the **PPC** and **APC** are of the same network type. Refer to the *Database Administration Manual - Systems Management* for further assistance.
2. Re-enter the command that initiated this message.

E4698 Cmd Rej: Group code of PPC and APC must match

Commands Used: ent-srvsel, ent-ls

The specified **apc** and **ppc** group codes must be of the same network type.

Recovery

1. Make sure the **PPC's** and **APC 's** are of the same network type. Refer to the *Database Administration Manual - Systems Management* for further assistance.
2. Re-enter the command that initiated this message.

E4699 Cmd Rej: Parameter cannot be specified for proxy linksets

Commands Used: chg-ls

The parameters **apc**, **sapc**, **action** and **lst** are not supported for a proxy linkset.

Recovery

Do not specify the parameters **apc**, **sapc**, **action** or **lst** when using a proxy linkset. For a full list of valid parameters refer to the *Database Administration Manual - Systems Management*.

E4700 Cmd Rej: APORT must be ON

Commands Used: `chg-ls, chg-ctrl-feat`

The A-Port feature must be turned on before the MO- or MT-based IS41 SMS NP feature can be turned on.

Note: After a Permanently On feature that is controlled by a feature access key is turned on, the feature cannot be turned off.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the A-Port feature is not shown in the output, then the feature is not enabled.
If the A-Port feature is OFF in the output, then the feature is enabled but turned off.
2. Enable and turn the A-Port feature ON as necessary. Refer to the *Feature Manual - A-Port* for assistance.
3. Re-enter the command that caused this error message to occur.

E4701 Cmd Rej: MT-Based GSM SMS NP must be enabled

Commands Used: `enable-ctrl-feat, chg-gsmsmsopts`

The MT-Based GSM SMS NP feature must be enabled before the **mtsmsimsi**, **mtsmsnni**, **mtsmstype**, **mtsmsackn**, **mtsmsdltr**, **mtsmsdltrv**, **mtsmsnakerr**, or **mtsmschksrc** parameters can be specified.

Recovery

1. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` command.
If the MT-Based GSM SMS NP feature is not shown in the output, then the feature is not enabled.
2. Enable the MT-Based GSM SMS NP feature. Refer to the *Feature Manual - G-Port* for assistance.
3. Re-enter the command that generated this error message.

E4702 Cmd Rej: MNP SMS must be ON or MO/MT SMS feature must be enabled

Commands Used: `ent-home-smsc`

The Portability Check for Mobile Originated SMS (MNPSMS) feature must be turned on or one of the following features must be enabled before this command can be entered:

- MO SMS IS41-to-GSM Migration
- MO-based GSM SMS NP
- MO-based IS41 SMS NP
- MT-Based GSM SMS NP
- MT-Based IS41 SMS NP

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable or turn on the desired feature. Refer to the appropriate feature manual for assistance.
 - *Feature Manual - A-Port* - MT-Based IS41 SMS NP
 - *Feature Manual - G-Port* - MT-Based GSM SMS NP
 - *Feature Manual - MO SMS* - MO-Based IS41 SMS NP, MO-Based GSM SMS NP, Portability Check for Mobile Originated SMS
3. Re-enter the command that caused this error message to occur.

E4703 Cmd Rej: MNP SMS, MO/MT SMS NP or MO SMS IS412GSM Migr must be enbld

Commands Used: `dlt-home-smsc`, `rtrv-home-smsc`

One of the following features must be enabled (see the `enable-ctrl-feat` command) before this command can be entered.

- MO SMS IS41-to-GSM Migration
- MO-based GSM SMS NP
- MO-based IS41 SMS NP
- MT-Based GSM SMS NP
- MT-Based IS41 SMS NP
- Portability Check for Mobile Originated SMS

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. If at least one of the required features is not enabled, enable the feature. Refer to the appropriate feature manual for assistance.
 - *Feature Manual - A-Port* - MT-Based IS41 SMS NP
 - *Feature Manual - G-Port* - MT-Based GSM SMS NP
 - *Feature Manual - MO SMS* - MO-Based IS41 SMS NP, MO-Based GSM SMS NP, Portability Check for Mobile Originated SMS

3. Re-enter the command that caused this error message to occur.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4707 Cmd Rej: PRX using DPC not allowed in GTT, MAP, MRN tables

Commands Used: `chg-gta`, `chg-map`, `chg-mrn`, `chg-ppsopts`, `ent-mrn`, `ent-map`

The value specified for the `pc/pca/pci/pcn` parameter cannot be associated with a proxy point code.

Recovery

1. Make sure no proxy point code is assigned to the specified point code. Refer to the *Database Administration Manual - Systems Management* for further assistance.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4708 Cmd Rej: One route must use PPC assigned in route (dstn) table

Commands Used: `chg-rte`, `dlt-rte`, `ent-rte`

For the `chg-rte` command, if a proxy linkset is used, the `nlsn` parameter cannot be specified.

For the `dlt-rte` command, if multiple routes are assigned to a point code, then the route that uses the proxy linkset must be the final route that is deleted.

For the `ent-rte` command, if multiple routes are defined for the destination point code, and if a proxy point code is assigned to the destination point code, then the first route defined in the `ent-rte` command must use the proxy linkset.

Recovery

1. For more information refer to the *Database Administration Manual - SS7*.

E4709 Cmd Rej: Cannot set DefCC to NONE if MT-Based GSM SMS NP is ON

Commands Used: `chg-stpopts`

If the MT-Based GSM SMS NP feature is turned on, then the `defcc` parameter cannot be specified as `none`.

Recovery

1. Display the MT-Based GSM SMS NP feature using the `rtrv-ctrl-feat` command.
2. If the MT-Based GSM SMS NP feature is on, then the `defcc` parameter cannot be `none`.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4713 Cmd Rej: PRX using DPC not allowed in GSM tables

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `ent-gsmmap-scrn`, `ent-gsms-opcode`

If the **action**, **naction**, **dfltact**, or **ndfltact** parameter has a value of **forward**, **duplicate**, or **dupdisc**, then the value specified for the point code parameter cannot be associated with a proxy point code in the Route table

Recovery

1. Display the parameter values for the relevant command. Enter the `rtrv-gsmmap-scrn` or the `rtrv-gsms-opcode` command.
2. Display the entries in the Route table. Enter the `rtrv-rte` command.
3. Re-enter the command that generated the error message, and specify a supported combination of parameters. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4714 Cmd Rej: PPC not supported for IPGW Linksets

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `ent-gsmmap-scrn`, `ent-ls`, `ent-srvsel`

If an **IPGW** linkset is used, then the **ppc** parameter cannot be specified.

Recovery

- Do not specify the **ipgwapc** parameter as **yes** if the **PPC** parameter is specified. For more information refer to the *Database Administration Manual - IP7 Secure Gateway*

E4716 Cmd Rej: LNP/VFLEX feature must be ON or ATINP must be enabled

Commands Used: `chg-map`, `ent-map`

The LNP or V-Flex feature must be turned on or the ATINP feature must be enabled, before the value specified for the **pca/ mpca** parameter can be a true point code.

Recovery

1. Display the current features using the `rtrv-ctrl-feat` command.
2. If the LNP or V-Flex feature do not show as **ON** (in the output of Step 1), turn at least one of them on. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that caused this error message to appear.

E4717 Cmd Rej: EIR/VFLEX feature must be ON or ATINP must be enabled

Commands Used: `chg-map`, `ent-map`

The EIR or V-Flex feature must be turned on or the ATINP feature must be enabled before the value specified for the **pci/ mpci** parameter can be a true point code.

Recovery

1. Display the current features using the `rtrv-ctrl-feat` command.
2. If the EIR or V-Flex feature do not show as **ON** (in the output of Step 1), turn at least one of them on. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that caused this error message to appear.

E4718 Cmd Rej: DefMCC can't be NONE if MT-Based GSM SMS NP feature is ON

Commands Used: `chg-gsmopts`

If the MT-Based GSM SMS NP feature is turned on, then the **defmcc=none** parameter cannot be specified.

Recovery

1. Display the Mt-Based GSM SMS NP feature status using the `rtrv-ctrl-feat` command.
2. If the feature is turned is on, then the **defmcc** parameter must have a value other than **none**.
3. For more information refer to the *Database Administration Manual - Systems Management*.

E4720 Cmd Rej: MTSMSDLTRV must not be NONE in database

Commands Used: `chg-is41smsopts`, `chg-gsmsmsopts`

The value for the **mtsmsdltrv** parameter must be specified before a value of either **prern** or **postrn** can be used for the **mtsmsdltr** parameter.

Recovery

1. Display the **mtsmsdltrv** value using the `rtrv-is41opts` command.
2. Change the **mtsmsdltrv** value to a valid value other than **none**.

E4723 Cmd Rej: PRX=YES not supported for Private PC

Commands Used: `chg-dstn`, `rtrv-dstn`

The **prx=yes** parameter cannot be specified if the specified destination point code is a private point code.

Recovery

Re-enter the command, and specify the **prx=no** parameter. Refer to the *Database Administration Manual - System Management* for assistance.

E4724 Cmd Rej: Proxy PC not defined in route (dstn) table

Commands Used: chg-dstn, rtrv-ls, rtrv-dstn, ent-srvsel, ent-dstn, ent-ls

The specified PPC must exist in the DSTN table with parameter prx set to yes.

Recovery

1. Set the prx parameter to yes in the PPC in the DSTN table. Refer to the *Database Administration Manual - Systems Management* for further assistance.

E4725 Cmd Rej: LSN for proxy route cannot be changed

Commands Used: chg-dstn, chg-rte

For chg-dstn: If the routeset specified in the command is associated with a proxy point code in the Destination table, then the linkset cannot be changed.

For chg-rte: If the value specified for the dpc parameter refers to a Proxy Point Code in the Destination table, then the nlsn parameter cannot be specified.

Recovery - chg-dstn

This linkset cannot be changed. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Recovery - chg-rte

Re-enter the command, without specifying the nlsn parameter. See the *Commands Manual* for more information.

E4726 Cmd Rej: Linkset Type for Network/Cluster Route can't be PRX

Commands Used: chg-rte, ent-rte, chg-dstn

If the specified destination address is a network cluster address (*ni-nc-**) or network address (*ni-*-**), the linkset type used in the route cannot be a proxy linkset.

Recovery

Use a linkset that is not a proxy linkset. The lst=yes parameter cannot be specified. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4727 Cmd Rej: SPC cannot be assigned to entry that uses PPC

Commands Used: chg-dstn

If the prx=yes parameter is specified, then the spc/spca/spci/spcn/spcn24 parameter cannot be specified.

Recovery

Assign the secondary point code to a destination point code that does not use a proxy point code. Refer to the *Database Administration Manual - System Management* for more information.

E4728 Cmd Rej: PPC has no assigned linksets

Commands Used: rtrv-ls

The specified **ppc** must have a proxy linkset assigned to it.

Recovery

1. To retrieve a linkset using a **ppc** a linkset must be assigned to the **ppc**. Refer to the *Database Administration Manual - Systems Management* for further assistance.

E4729 Cmd Rej: Linkset APC/PPC pair is already being used

Commands Used: rtrv-ls, ent-ls

The values of the **APC** and **PPC** parameters can be assigned to only one linkset.

Recovery

1. The values for the **APC** and **PPC** parameters that were used are already assigned. Use another combination of **APC** and **PPC** parameters for this linkset. Refer to the *Database Administration Manual - Systems Management* for further assistance.

E4730 Cmd Rej: Maximum Proxy PC capacity exceeded

Commands Used: chg-dstn

Total number of proxy destinations cannot exceed the total capacity of Proxy Point Code feature.

Recovery

1. The **PPC** feature has a maximum capacity of 100 proxy destinations.

E4731 Cmd Rej: Cluster DPCs can't inherit PRX linkset type

Commands Used: ent-dstn

Cluster **DPCs** are not allowed to inherit cluster members that have routes with **prx** linkset type.

Recovery

1. For correct configuration refer to the *Database Administration Manual - Systems Management*.

2. Re-enter the command that initiated the error.

E4733 Cmd Rej: Exception route does not support proxy destinations

Commands Used: `ent-rtx`

Recovery

1. Display routes using the `rtrv-rtx` command.
2. Make sure that the routes are not assigned to proxy destinations. Refer to the *Database Administration Manual - SS7* for assistance.
3. Re-enter the command.

E4734 Cmd Rej: IDP A-Party Routing feature must be enabled

Commands Used: `ent-npp-srs`, `chg-npp-srs`

The IDP A-Party Routing feature must be enabled before the `saX=cgpnrtg` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4735 Cmd Rej: Both IDP A-Party & SK Routing features must be enabled

Commands Used: `chg-ttropts`

The IDP A-Party Routing feature and the IDP SK Routing feature must be enabled before the `cgpnskrtg` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the features. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.

3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4736 Cmd Rej: ACCgPN and CCCgPN CAs are mutually exclusive

Commands Used: `ent-npp-srs`, `chg-npp-srs`

The `caX=accgpn` and `caX=cccgpn` parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual*, the *Feature Manual - IDP and Analyzed Information Features*, and the *Numbering Plan Processor Overview* for assistance.

E4737 Cmd Rej: IDP A-Party Blacklist feature must be enabled

Commands Used: `ent-npp-srs`, `chg-npp-srs`

The IDP A-Party Blacklist feature must be enabled before the `saX=blklstqry` or `saX=blklsttrly` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual

E4738 Cmd Rej: IDP A-Party Blacklist Query mutually exclusive with all SAs

Commands Used: `ent-npp-srs`, `chg-npp-srs`

If the `blklstqry` SA is specified, then no other SAs can be specified.

Recovery

Re-enter the command specifying either the **blklstqry** SA or a valid combination of other SAs. Refer to the *Commands Manual*, the *Feature Manual - IDP and Analyzed Information Features*, and the *Numbering Plan Processor Overview* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4739 Cmd Rej: DRAFRMT contains CC so DRANAI must be 4 (INTL)

Commands Used: `chg-ttropts`

If the new or existing value specified for the **drafrrmt** parameter contains a country code (e.g., **ccgrndn**), then only a value of 4 can be specified for the **dranai** parameter. If the **dranai** parameter has a new or existing value that is not equal to 4, then the value that is specified for the **drafrrmt** parameter cannot contain a country code.

1. Retrieve the value entered for the **drafrrmt** parameter. Enter the `rtrv-ttropts` command.
2. If the **drafrrmt** parameter value contains a country code, re-enter the command specifying the **dranai=4** parameter or provisioning the **drafrrmt** parameter with a value that does not contain a country code. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.

Contact your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4740 Cmd Rej: MT-Based GSM SMS NP must be ON

Commands Used: `chg-ctrl-feat`

The MT-Based GSM SMS NP feature must be turned on before the MT-Based GSM MMS NP feature can be turned on.

Recovery

1. Display the MT-Based GSM SMS NP feature status using the `rtrv-ctrl-feat` command.
2. If the status is **off** or not showing, turn it **on** before trying to turn on the MT-Based GSM MMS NP feature.
3. Call your "Customer Care Center" if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4750 Cmd Rej: A cost must be specified with a linkset

Commands Used: `ent-rte`, `ent-rtx`

If the **lsn** parameter is specified, then the **rc** parameter must be specified.

Recovery

Re-enter the command and specify the **lsn** and the **rc** parameter. Refer to the *Database Administration Manual - SS7* for assistance.

E4756 Cmd Rej: GPORT/IGM/MO SMS feature must be enabled

Commands Used: `chg-gsmopts`

The G-Port, IGM, MO SMS ASD, MO SMS B-Party Routing, MO SMS GRN, MO-based GSM SMS NP, or Prepaid SMS Intercept Ph1 feature must be enabled before the **defmapvr** parameter can be specified.

Recovery

1. Enter the `rtrv-ctrl-feat` command to display the status of controlled features in the system.
If the feature does not appear in the command output, then the feature is not enabled in the system.
2. Refer to the procedures in the following manuals to enable the required feature:
 - *Feature Manual - G-Port*
 - *Feature Manual - MO-SMS*
3. After the feature is enabled, re-enter the command that generated this error message, and specify the desired parameter.

E4759 Cmd Rej: Max number of atm links already exists

Commands Used: `ent-slk`

The maximum number of ATM links that can be specified is limited to the maximum number of ATM cards that can be configured in the system.

Recovery

- Remove some of the ATM links, or add additional ATM cards if the systems allows it, to continue adding ATM links.
- Call your "Customer Care Center" if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4760 Cmd Rej: Linkset APC/SPC pair is already being used

Commands Used: `chg-ls`, `ent-ls`

The **apc** and **spc** parameters cannot be changed to values that are assigned to another linkset

Recovery

Make sure the vaules assigned to the **apc** and **sapc** parameters are unique. Refer to the Database Administration Manual - System Management for assistance.

E4761 Cmd Rej: MOSMSGTA must be set

Commands Used: `chg-gsmopts`

The `mosmsgta` parameter must be specified before the `mosmsfwd=yes` parameter can be specified.

Recovery

1. Display the status of the `mosmsgta` parameter by entering `rtrv-gsmopts`.
2. If the output of Step 1 shows the `mosmsgta` parameter is not set, set it. Refer to the *Database Administration Manual - Systems Management* for assistance in setting the `mosmsgta` parameter.
3. Re-enter the command that caused the error message to appear.

E4765 Cmd Rej: Some of the Locations still contain HMUX/HIPR card

Commands Used: `chg-ctrl-feat`

HIPR2 cards must be installed in all MUX locations before the HIPR2 High Rate Mode feature can be turned on.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
2. If any HMUX or HIPR cards are installed, then they must be replaced. Refer to the *Maintenance Manual* for assistance.
3. Re-enter the command that generated this error message. If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4766 Cmd Rej: FCMODE must not be FCOPY

Commands Used: `chg-netopts`

If the `fcmode=fcopy` parameter is specified (see the `chg-eisopts` command), then the `fcna` and `fcnb` parameters cannot be specified.

Recovery

Re-enter the command specifying either the `fcna` or `fcnb` parameter but not both.

E4768 Cmd Rej: Link must be A or B if hardware type is E5ATM

Commands Used: `rtrv-slk`

If the hardware type of an ATM card is E5-ATM, then the value specified for the link parameter must be **a** or **b**.

Recovery

Re-enter the command, and specify **link=a** or **link=b**

E4769 Cmd Rej: GPORT or IGM must be enabled

Commands Used: `chg-gsmopts`

The G-Port or IGM feature must be enabled before the following parameters can be specified: **srfaddr**, **mrsndig**, **mrsnnai**, **sridn**, **msisdntrunc**, **migrpfx**, **gsm2is41**, **serverpfx**.

Recovery

1. Display the controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature as necessary. Refer to the *Feature Manual - G-Port* and the *Feature Manual - A-Port* for assistance.
3. Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4771 Cmd Rej: GFLEX/GPORT must be ON or IGM/MT-Based GSM SMS NP must be enabled

Commands Used: `chg-gsmopts`

The G-Flex or G-Port feature must be turned on or the MT-Based GSM SMS NP or IGM feature must be enabled before the **defmcc** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable or enable and turn on the feature as necessary. Refer to the *Commands Manual* and to the *Feature Manual - G-Port* for more information.
3. Re-enter the command that caused this error message to appear.

Contact the Customer Care Center if the error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4772 Cmd Rej: IPADDR and PORT combination cant be same for both the CCSMRs

Commands Used: `ent-ls`, `chg-seas-config`

The **port** and **ipaddr** parameters must have unique values for each CCS MR

Recovery

Make sure previously assigned values are not used for the **port** and **ipaddr** parameters.

E4774 Cmd Rej: No change in NCAI value requested

Commands Used: `chg-dstn`, `ent-rtx`

The value specified for the **ncai** parameter cannot be same as the nested cluster allowed indicator provisioned for the destination point code.

Recovery

1. Display the value for the **ncai** parameter using the `rtrv-dstn` command.
2. If the value is the same as the nested cluster allowed indicator provisioned for the destination point code, it must be changed. Refer to the *Database Administration Manual - SS7* for assistance.
3. Re-enter the command that generated this message.

E4777 Cmd Rej: Specified route does not exist in the RTX entry

Commands Used: `chg-rtx`

The route associated with the linkset specified by the **lsn** parameter must already exist in the specified exception route.

Recovery

1. Display the routes associated with the linksets using the `rtrv-rte` command.
2. Re-enter the command specifying a route that is shown in the output of Step 1. Refer to the *Database Administration Manual - System Management* for more information.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4779 Cmd Rej: MODE allowed only with DPC and RTX Class

Commands Used: `rept-stat-rte`, `rept-stat-rtx`

The mode parameter can be specified only when both destination and its class criteria are specified.

Recovery

Re-enter the command and specify the destination and its class criteria with the **mode** parameter. Refer to the *Database Administration Manual - SS7* for assistance.

E4784 Cmd Rej: System wide SCTP checksum algorithm already configured

Commands Used: `chg-ip-card`

The `chg-sg-opts:sctpsum=percard` command must be entered before the **sctpsum** parameter can be specified in the `chg-ip-card` command.

Recovery

Re-enter the command and enter the `chg-sg-opts:sctpsum=percard` command before specifying the **sctpsum** parameter. Refer to the *Commands Manual* for assistance.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4785 Cmd Rej: RLOC and LINK parameter combination must be specified

Commands Used: `dbg-ddb`

If the **action=disp** and **tbl=lnk** parameters are specified, then the **rloc** and **link** parameters must be specified together in the command.

Recovery

Re-enter the command specifying a valid set of parameters. Refer to the *Commands Manual* for more information about the `dbg-ddb` command and valid parameters.

E4786 Cmd Rej: Max 25 FPFx single digit wildcard chars '?' per NPP service

Commands Used: `ent-npp-srs`

A single digit wildcard (?) can be specified as a value for the **fpfx** parameter a maximum of 25 times across all of the rules for an NPP service.

Recovery

1. Determine the values specified for the **fpfx** parameter for the NPP service rule sets. Enter the `rtrv-npp-srs` command.
2. If a wildcard value has already been specified 25 times, either re-enter the command specifying a different value for the **fpfx** parameter or delete one of the rules that contains a wildcard value. Refer to the *Commands Manual* and to the *Numbering Plan Processor (NPP) Overview* for assistance.
3. Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4787 Cmd Rej: SPARE ITU-NATL site id not defined

Commands Used: `chg-rtd`, `ent-dstn`

The spare ITU-I self-ID destination point code for the STP must be defined before spare ITU-I destinations can be entered.

Recovery

Define the ITU-I self-ID destination point code. Refer to the *Database Administration Manual - Systems Management* for assistance.

Re-enter the command that caused this error to appear.

E4788 Cmd Rej: SPARE ITU-NATL site id not defined

Commands Used: `chg-rtd`, `ent-dstn`

The spare ITU-N self ID destination point code for the STP must be defined before spare ITU-N destinations can be entered.

Recovery

1. Define the ITU-N self ID destination point code. Refer to the *Database Administration Manual - Systems Management* for assistance.
2. Re-enter the command that caused this message to appear.

E4789 Cmd Rej: Either AMGTT or AMGTT CgPA Upgrade feature must be ON

Commands Used: `chg-gta`, `chg-gtt`, `chg-ls`, `ent-gta`, `ent-gtt`, `ent-ls`, `rtrv-gta`, `rtrv-gtt`, `rtrv-ls`

The AMGTT feature or the AMGTT CgPA Upgrade feature must be turned on before the `cggtmod` parameter can be specified.

Recovery

1. Display the AMGTT or the AMGTT CgPA Upgrade feature using the `rtrv-ctrl-feat` command.
2. If the AMGTT or the AMGTT CgPA Upgrade feature are off or not showing, one of these must be turned on prior to specifying the `cggtmod` parameter. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that generated this message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4790 Cmd Rej: AMGTT CdPA Only feature cannot be enabled

Commands Used: `enable-ctrl-feat`

The AMGTT CdPA Only feature cannot be enabled using the `enable-ctrl-feat` command. This feature is automatically enabled and turned on if the MGTT feature was on before upgrade to EAGLE 5 ISS Release 38.0 occurred.

Recovery

- Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4791 Cmd Rej: AMGTT CdPA Only must be ON

Commands Used: `enable-ctrl-feat`

The AMGTT CdPA Only feature must be turned on before the AMGTT CgPA Upgrade feature can be enabled

Recovery

1. Display the status of the AMGTT CdPA Only feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing turn on the feature. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. If the status is on, re-enter the command to enable the AMGTT CgPA Upgrade feature.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4792 Cmd Rej: AMGTT CdPA Only/AMGTT CgPA Upgrade feature must not be ON

Commands Used: `enable-ctrl-feat`

If the AMGTT CdPA Only feature or the AMGTT CgPA Upgrade feature is turned on, then the AMGTT feature cannot be enabled.

Recovery

1. Display the status of the AMGTT CdPA Only feature and the AMGTT CgPA Upgrade feature using the `rtrv-ctrl-feat` command.
2. Make sure the status is off, or not showing.
3. If the status is on, Refer to the *Database Administration Manual - Systems Management* for assistance.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4793 Cmd Rej: The parameter value can't be changed back to NONE

Commands Used: `chg-gsmsmsopts`

If a digit string value has already been specified for the **mosmsgta** or **mtsmsdltrv** parameter, then a value of **none** cannot be specified subsequently for that parameter.

Recovery

1. Display the specified parameters. Refer to the *Commands Manual* for assistance.
2. Re-enter the command that generated this error message, without specifying a value of **none**.
3. Call your Customer Care Center if this message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4800 Cmd Rej: EISCOPY must be ON

Commands Used: `chg-eisopts`

The **eiscopy=on** parameter must be specified before a value of **stc** or **fcopy** can be specified for the **fcmode** parameter.

Recovery

1. Display the status of EISCOPY using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Commands Manual* for assistance.
3. If the status is on, re-enter the command that generated this message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4801 Cmd Rej: Association is still assigned to a link

Commands Used: `chg-assoc`, `dlt-assoc`

If the **lhost** parameter is configured on the IPSPG card, and the association is referenced by a signaling link, then the **lhost** and **adapter** parameters cannot be changed.

Recovery

The **lhost** or **adapter** parameters must be disassociated from the signaling link. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.

E4802 Cmd Rej: Association ADAPTER type doesn't match linkset ADAPTER type

Commands Used: `ent-slk`

The specified association (**aname** parameter) is configured in the database but has an adapter that differs from that of the specified linkset (**lsn** parameter).

Recovery

- The adapter associated with the **aname** parameter must match the one associated with the **lsn** parameter.
- Refer to the *Database Administration Manual - Systems Management* for assistance.

E4803 Cmd Rej: Association and LOC must reference same card

Commands Used: `ent-slk`

The specified association (**aname** parameter) is configured for a card different from the specified card location (**loc** parameter).

Recovery

- The **aname** parameter must be associated with the same card specified in the **loc** parameter.
- Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.

E4804 Cmd Rej: ANAME is prohibited for a non-IPSG link

Commands Used: `ent-slk`

The **aname** parameter can be specified only for IPSG links.

Recovery

- Display the linkset using the `rttrv-ls` command. If the linkset is an IPSG linkset the **aname** parameter must be specified.
- If the linkset is not an IPSG linkset the **aname** parameter cannot be specified. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4805 Cmd Rej: ANAME is required for an IPSG link

Commands Used: `ent-slk`

If the **loc** specifies an IPSG card location (**ipsg=yes**), then the **aname** parameter must be specified.

Recovery

Display the linkset using the `rtrv-ls` command. If the linkset is an IPSP linkset the **aname** parameter must be specified. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4806 Cmd Rej: Card does not support more than 32 links

Commands Used: `ent-slk`

The IPSP card (specified in **loc** parameter) has already reached its limit of 32 signaling links.

Recovery

Display the linkset using the `rtrv-ls` command. Either delete unnecessary links or assign some links to another card. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4807 Cmd Rej: TPS exceeded for card

Commands Used: `chg-ls,ent-slk`

The value specified for the **iptps** parameter cannot cause the card to exceed the total maximum capacity (5000 TPS) of the card.

Recovery

Display the linkset using the `rtrv-ls` command. If the **iptps** is specified with a larger than current value either another card must be added or signalling links must be deleted.

E4808 Cmd Rej: Service Action(s) require an MPS dependent feature to be ON

Commands Used: `chg-npp-srs,ent-npp-srs`

All of the features that are associated with the SAs in the AS that is specified by the **asn** parameter must be turned on before the AS can be used.

Recovery

1. Display the status of feature access key controlled features. Enter the `rtrv-ctrl-feat` command.
2. If none of the following features have a status of ON, then a feature must be turned on. Refer to the appropriate Feature Manual for assistance.
 - AINPQ
 - A-Port
 - EIR
 - G-Flex
 - G-Port
 - IS41 GSM Migration
3. Re-enter the command that generated this error message.

4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4809 Cmd Rej: GPL type IPSP requires linkset with IPSP=YES

Commands Used: `ent-slk`

When the designated card location (**loc** parameter) is an IPSP application card then the specified linkset must also be an IPSP linkset (**ipsp=yes**).

Recovery

- Display the linkset using the `rtrv-ls` command. If the **ipsp=no**, or is not specified, it must be specified as **yes**.
- Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4810 Cmd Rej: All links must be OOS-MT-DISABLED to modify RCONTEXT

Commands Used: `ent-slk`

When changing the routing context for any link on an IPSP card, all the links in the linkset and all affected associations must be deactivated.

Recovery

- Display the linkset using the `rtrv-ls` command.
- The **rcontext** value must be unique to one linkset specified for that card.
- Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.

E4811 Cmd Rej: SLKTPS is prohibited for non-IPSP linksets

Commands Used: `chg-ls`, `ent-ls`

The **slktps** parameter cannot be specified for linksets that are not ipsp.

Recovery

- Display the linkset using the `rtrv-ls` command.
- Verify the **ipsp=yes** parameter is specified. If the linkset is not an ipsp linkset, the **slktps** parameter cannot be specified.
- Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.

E4812 Cmd Rej: SLKTPS is required for IPSG linksets

Commands Used: `ent-ls`, `chg-ls`

If the `ipsg=yes` parameter is specified, the `slktps` parameter must be specified.

Both the `ipsg=yes` and `adapter=m3ua` parameters must be specified before the `slktps` parameter can be specified.

Recovery

- Display the linkset using the `rtrv-ls` command.
- Specify the `slktps` parameter.
- Refer to the *Database Administration Manual - Systems Management* for assistance.

E4816 Cmd Rej: ATINP feature must be enabled

Commands Used: `chg-atinpopts`, `chg-mtc-measopts`, `chg-sid`, `chg-srvsel`, `chg-ss-appl`, `dlt-ss-appl`, `ent-srvsel`, `ent-ss-appl`, `rtrv-atinpopts`, `rtrv-ftp-meas`, `rtrv-sid`, `rtrv-srvsel`

The ATINP feature must be enabled before a command can be entered, or before specifying a parameter.

Recovery

- Verify the ATINP feature is enabled. Refer to the *Commands Manual* for assistance.
 - Re-enter the command that generated this error message.
 - Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.
1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command and the `rtrv-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
 2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - ATINP* for assistance.
 3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4817 Cmd Rej: E4817 Cmd Rej: ITU TCAP LRN Query (LRNQT) feature must be ON

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

The LRNQT feature must be turned on (see the `chg-ctrl-feat` command) before the **(n)serv=lrnqt** parameter can be specified.

Recovery

- Verify the status of the LRNQT feature, using the `rtrv-ctrl-feat` command.
- If the display output shows the LRNQT feature as on, re-enter the command that generated this error message, specifying the **(n)serv=lrnqt** parameter. If the display output shows the LRNQT feature as off, refer to the *Commands Manual* for more information on commands to turn on feature.
- Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4819 Cmd Rej: Failure reading TSTMSG Table

Commands Used: `chg-isup-msg`, `chg-gsm-msg`, `chg-is41-msg`, `chg-sccp-msg`,
`rtrv-gsm-msg`, `rtrv-is41-msg`, `rtrv-sccp-msg`, `chg-tatr-msg`, `rtrv-tatr-msg`,
`tst-msg`

The TSTMSG table is corrupt or cannot be found.

Recovery

1. Re-enter the command that generated this error message.
2. Contact the Customer Care Center if this message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4820 Cmd Rej: Failure accessing EGLEOPTS Table

Commands Used: `chg-atinpopts`, `chg-gsmopts`, `chg-gsmsmsopts`, `chg-is41opts`,
`chg-is41smsopts`, `chg-tatropts`, `chg-tifopts`, `chg-ttropts`, `dlt-gttset`,
`rtrv-atinpopts`, `rtrv-gsmopts`, `rtrv-gsmsmsopts`, `rtrv-is41smsopts`,
`rtrv-tatropts`, `rtrv-tifopts`

The EGLEOPTS table is corrupt or cannot be found by the system.

Recovery

1. Re-enter the command that generated this error message.
2. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4821 Cmd Rej: CDPNNAI and CGPNNAI must be specified with TCAPTYPE

Commands Used: `chg-ttr-msg`

If the **tcaptype** parameter is specified, then the **cdpnnai** and **cgpnnai** parameters must be specified.

Recovery

Re-enter the command specifying a valid combination of parameters.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual

E4823 Cmd Rej: SAs specified are mutually exclusive

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The SAs in the AS specified by the `asn` parameter cannot violate mutual exclusivity rules defined by the service specified by the `srvn` parameter.

Recovery

- Refer to the *Numbering Plan Processor (NPP) Overview* for assistance to determine which service actions are mutually exclusive. Refer to the Feature Manual for the feature of interest for additional information.
- Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4824 Cmd Rej: No BPIPADDR is provisioned for this card

Commands Used: `chg-ip-card`

The `bpipaddr` parameter must be specified before the `bpsubmask` parameter can be specified.

Recovery

1. Display the current parameters using the `rtrv-ip-card` command.
2. Specify the value for the `bpipaddr` parameter.
3. Re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4825 Cmd Rej: If BPIPADDR is specified BPSUBMASK is required

Commands Used: `chg-ip-card`

If the `bpipaddr` parameter is specified, then the `bpsubmask` parameter must be specified.

Recovery

1. Display the current parameters using the `rtrv-ip-card` command.
2. Verify the `bpipaddr` parameter is specified.
3. Re-enter the command, specifying the `bpsubmask` parameter. Refer to the *Commands Manual* for assistance if necessary.

4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4826 Cmd Rej: MULTGC is prohibited on IPSEG-M3UA linksets

Commands Used: `chg-ls,ent-ls`

Multiple Group Code (**multgc=yes** parameter) is not allowed for IPSEG-M3UA linksets (if **ipsg=yes** and **adapter=m3ua** parameter are specified).

Recovery

- Display the linkset using the `rtrv-ls` parameter.
- If the **ipsg=yes** and the **adapter=m3ua** parameters are specified, the **multgc=yes** parameter cannot be specified.
- Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4827 Cmd Rej: Correct RCONTEXT value is required to delete

Commands Used: `chg-ls`

The correct **rcontext** value must be specified to delete it from the database.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. Verify the correct **rcontext** value. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that generated this message using the correct **rcontext** value.

E4828 Cmd Rej: Unique RCONTEXT required if associations in multiple lsets

Commands Used: `chg-ls,ent-slk`

A unique **rcontext** value is required for linksets to share an association.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. Verify that all instances of the **rcontext** value are unique. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that generated this message.

E4829 Cmd Rej: Multiple links w/in same linkset cannot share an association

Commands Used: `chg-ls`, `ent-slk`

Multiple signaling links in a single linkset cannot share the same association.

For `ent-slk`, the same value cannot be specified for the **aname** parameter for multiple links in the same linkset.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. Verify that multiple signaling links do not share the same association. Refer to the *Database Administration Manual - System Management* for assistance.
3. Re-enter the command that generated this message.

E4830 Cmd Rej: LNP ported TNs (24Million or more) Qty Feature must be ON

Commands Used: `enable-ctrl-feat`

The LNP ported TNs 24 Million Quantity feature or greater must be turned on before the LRNQT feature can be enabled.

Recovery

1. Display the status of the LNP ported TNs Quantity feature using the `rtrv-ctrl-feat` command. The LNP ported TNs quantity must be 24 million or greater to enable the LRNQT feature.
2. If the status is off, or not showing, turn on the feature. Refer to the *LNP Feature Activation Guide* for assistance.
3. If the status is on, but the quantity is less than 24 million ported TNs, contact the Customer Care Center. If the status is on with a quantity of 24 million ported TNs or greater, re-enter the command to enable the LRNQT feature.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4831 Cmd Rej: Cannot set DefCC to NONE if MT-Based IS41 SMS NP is ON

Commands Used: `chg-stopts`

If the MT-based IS41 SMS NP feature is turned ON, then the **defcc** parameter cannot be specified as **none**.

Recovery

- Display the MT-Based IS41 SMS NP feature using the `rtrv-ctrl-feat` command.

- If the MT-Based IS41 SMS NP feature shows as on, you can not set the **defcc** parameter to **none**. set the **defcc** to something other than **none**.
- Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4832 Cmd Rej: CLRWRNTX=YES only valid with WRNLN parameter

Commands Used: `chg-secu-dflt`

If the **clwrntx=yes** parameter is specified, then the **wrnln** parameter must be specified.

Recovery

- Display the specified parameters using the `rtrv-secu-dflt` command.
- Re-enter the `chg-secu-dflt` command, specifying the **wrnln** parameter before specifying the **clwrntx=yes** parameter.

E4835 Cmd Rej: Limit 1 SLK per IPSTG-M2PA association

Commands Used: `ent-slk`

If the **aname=m2pa** parameter is specified, then only one signaling link can be assigned.

Recovery

1. A new IPSTG-M2PA association must be created before another signaling link can be assigned. Refer to the *Commands Manual* for assistance.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4836 Cmd Rej: Limit 16 SLKs per IPSTG-M3UA association

Commands Used: `ent-slk`

If the **aname=m3ua** parameter is specified, a maximum of 16 signaling links can be assigned.

Recovery

1. A new IPSTG-M3UA association must be created before another signaling link can be assigned. Refer to the *Commands Manual* for assistance.
2. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4837 Cmd Rej: MAPSET and MRNSET cannot be specified together

Commands Used: `-rtrv-gta, rtrv-gtt`

The **mapset** parameter and the **mrnset** parameter cannot be specified together in the command.

Recovery

- Display the parameter values using the `rtrv-ctrl-feat` command.
- The **mapset** parameter and the **mrnset** parameter cannot both be specified. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4838 Cmd Rej: GTIN24 must not be specified when (N)SERV = ATINP

Commands Used: `chg-srvsel, ent-srvsel, rtrv-srvsel`

If the **nserv=atinp** parameter is specified, then the **gtin24** parameter cannot be specified.

Recovery

- Display the parameter values using the `rtrv-ctrl-feat` command.
- The **nserv=atinp** parameter and the **gtin24** parameter cannot both be specified. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4840 Cmd Rej: Fast Copy capable card is required

Commands Used: `rept-stat-mon`

At least one FC-capable card must be provisioned in the system before the **type=fcs** parameter can be specified.

Note: A card that can run the Fast Copy interface is referred to as an FC-capable card. Currently, E5-ENET cards running the ipsg application are the only supported FC-capable cards. After the **fcmode=fcopy** parameter is specified (see the `chg-eisopts` command) for an FC-capable card, the card is referred to as an FC-enabled card.

Recovery

1. Display the cards in the system using the `rtrv-card` command.
2. If there is no FC-capable card listed in the output of Step 1, provision an E5-ENET card. Refer to the *Database Administration Manual - Features* for more information.
3. Re-enter the command that generated this error message. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4841 Cmd Rej: Portability Check for MO SMS feature must be ON

Commands Used: `chg-gsmsmsopts`

The Portability Check for MO SMS feature must be turned ON before the `mosmsdigmat` parameter is set to `BESTFIT`.

Recovery

- Display the status of the Portability check for the MO SMS feature using the `rtrv-ctrl-feat` command.
- Verify the Portability Check for MO SMS feature is turned on. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this message.
- Call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4842 Cmd Rej: Cannot set DefCC to NONE, if IDPR ON or IAR Base ENABLED

Commands Used: `chg-stpopts`

If the IDPR feature is turned on or the IAR Base feature is enabled, then the `defcc=none` parameter cannot be specified.

Recovery

Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command. If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of `OFF`, then the feature is enabled but is not turned on.

If the IDPR feature is turned on or the IAR Base feature is enabled, then re-enter the command without specifying the `defcc=none` parameter. Contact the Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual

E4845 Cmd Rej: IGM or MO SMS IS41-to-GSM Migr must be enabled

Commands Used: `chg-gsmopts`

The IGM or MO SMS IS41-to-GSM Migration feature must be enabled before the `is412gsm` parameter can be specified.

Recovery

- Verify the IGM or MO SMS IS41-to-GSM Migration feature is enabled. Refer to the *IS41-GSM-Migration Manual* for assistance.
- Re-enter the command that generated this error message.

- Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4846 Cmd Rej: MOSMSTCAPSEG and/or MOSMSDIGMAT not set to default value

Commands Used: `chg-ctrl-feat`

If the **mosmstcapseg=on** parameter is specified (see the `chg-gsmsmsopts` command), and the MO-based GSM SMS NP feature is not turned on, or if the **mosmsdigmat=bestfit** parameter is specified (see the `chg-gsmsmsopts` command), then the Portability Check for MO SMS feature cannot be turned off.

Recovery

- Verify that the Portability Check for MO SMS feature can be turned off, refer to the *Commands Manual* or the *Feature Manual - MO SMS* for more information on turning this option off.
- Re-enter the command that generated this message.
- Call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4847 Cmd Rej: SAPC is prohibited on IPSG-M3UA linksets

Commands Used: `chg-ls`

If the **ipsg=yes** and **adapter=m3ua** parameters are specified, a linkset cannot have an SAPC.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. Verify there is no SAPC. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Re-enter the command that generated this message.

E4849 Cmd Rej: Linkset must not contain any IPSG type links

Commands Used: `chg-ls`

If the linkset contains any IPSG links, then the **ipsg=no** parameter cannot be specified.

Recovery

1. Display the linksets using the `rtrv-ls` command.
2. Remove any associations to IPSG linksets before attempting to specify the **ipsg=no** parameter. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.
3. Re-enter the command that generated this message.

E4850 Cmd Rej: Maximum number of traces already entered

Commands Used: `ent-trace`

A maximum of 9 traces can be entered.

Recovery

1. Display the current traces using the `rtrv-ctrl-feat` command. Refer to the *Database Administration Manual - Systems Management* for assistance.

E4851 Cmd Rej: Removable cartridge can not be inserted

Commands Used: `act-upgrade, init-card`

For `act-upgrade`, if the **src=fixed** parameter is specified, then a removable cartridge or credit card drive cannot be inserted.

For `init-card`, if a removable cartridge is inserted in the system, then the **prtnggrp=inactive** parameter cannot be specified.

An attempt was made to boot the OAM with the `gpl` on the inactive partition of the disk. This action was rejected due to an MO being inserted. If there is an MO inserted, the OAM will always default to running the `gpl` from the MO. Remove the MO and retry.

Note: When the `init-card` command is issued to the OAM software, there is a 10-second wait before the card is reset. This wait period is intended to ensure that all database updates are complete before the card is reset.

Recovery

- For `act-upgrade`, remove the removable cartridge or credit card drive and re-enter the command specifying the **src=fixed** parameter.
- For `init-card`, remove the MO from the card, re-enter the command that generated this error message and load the cartridge. Refer to the *Database Administration - System Management* manual for more information about this procedure.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4855 Cmd Rej: MO SMS IS41 NP or MO SMS IS41-to-GSM Migr must be enabled

Commands Used: `chg-is41smsopts`

The MO-based IS41 SMS NP or MO SMS IS41-to-GSM Migration feature must be enabled before the **mosmsdigmat** parameter can be specified.

Recovery

- Verify the MO-based IS41 SMS NP or MO SMS IS41-to-GSM Migration feature is enabled. Refer to the *Feature Manual - MO SMS* for assistance.
- Re-enter the command that generated this error message.
- Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4857 Cmd Rej: WRNLN must be specified with WRNTX or CLRWRNTX=yes

Commands Used: `chg-secu-dflt`

If the `wrnl` parameter is specified, then the `wrntx` parameter or the `clrwrntx=yes` parameter must be specified.

Recovery

1. Display the specified parameters using the `rtrv-secu-dflt` command.
2. If the `wrnl` parameter is specified, then the `wrntx` or the `clrwrntx=yes` must be specified. Refer to the *Database Administration Manual - Systems Management* for assistance if necessary.

E4861 Cmd Rej: IDPR FEAT can NOT be activated if IDPRCDPN service is OFF

Commands Used: `chg-ctrl-feat`

The IDPRCDPN NPP service must be turned on before the Prepaid IDP Query Relay feature can be turned on.

Recovery

1. Verify that the IDPRCDPN service is turned on. Enter the `rtrv-npp-serv` command.
2. If the IDPRCDPN service is not turned on, then turn it on using the `chg-npp-serv` command. Refer to the *Feature Manual - IDP and Analyzed Information Features* and the *Commands Manual* for assistance.
3. After the IDPRCDPN service is turned on, re-enter the command that generated this message.
4. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4868 Cmd Rej: action set contains OFNAI value not defined by service

Commands Used: `ent-npp-srs`, `chg-npp-srs`

To use the specified OFNAI class the service should provision the corresponding FNAI class value to something other than **none**.

Recovery

The OFNAI class should be provisioned with a value other than **none**. Refer to the *Commands Manual* for assistance in provisioning FNAI mapping values and the OFNAI class.

E4870 Cmd Rej: NUMSLKPROH must be less than or equal to NUMSLKRSTR

Commands Used: chg-lsopts

The value of the parameter **numslkproh** must not be greater than the value of parameter **numslkrstr**.

Recovery

1. Display the value of the **numslkproh** parameter using the `rtrv-ls:lsn=<xxxx>` command.
2. Make sure the value of the **numslkrstr** parameter is greater than the **numslkproh** parameter. Refer to the *Database Administration Manual - Systems Managemet* for assistance.

E4871 Cmd Rej: NUMSLKRSTR must be less than or equal to NUMSLKALW

Commands Used: chg-lsopts

The value of the parameter **numslkrstr** must not be greater than the value of parameter **numslkalw**.

Recovery

1. Display the value of the **numslkalw** parameter using the `rtrv-ls:lsn=<xxxx>` command.
2. Make sure the value of the **numslkalw** parameter is greater than the **numslkrstr** parameter. Refer to the *Database Administration Manual - Systems Managemet* for assistance.

E4873 Cmd Rej: NUMSLKXXXX thresholds allowed only for IPSP M3UA linksets

Commands Used: chg-lsopts

The parameters **numslkalw**, **numslkproh**, and **numslkrstr** can be specified only for the IPSP M3UA linksets.

Recovery

1. Display the parameter values for the **numslkalw**, **numslkproh**, and **numslkrstr** parameters using the `rtrv-ls:lsn=<xxxx>` command.
2. Make sure the linkset these parameters are assigned to is a IPSP-M3UA linkset. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4874 Cmd Rej: NUMSLK value exceeds number of links in the linkset

Commands Used: `chg-lsopts`

The value of the parameters **numslkalw**, **numslkproh**, and **numslkrstr** cannot be greater than the number of links configured in the IPSP-M3UA linkset.

Recovery

1. Display the parameter values for the **numslkalw**, **numslkproh**, and **numslkrstr** parameters using the `rtrv-ls:lsn=<xxxx>` command.
2. Make sure the values of the **numslkalw**, **numslkproh**, and **numslkrstr** parameters are not greater than the number of links configured in the IPSP-M3UA linkset. Refer to the *Database Administration Manual - Systems Management* for assistance.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4875 Cmd Rej: TFATCABMLQ not allowed for IPSP M3UA linksets

Commands Used: `chg-ls`

The **tfatcabmlq** parameter cannot be specified for IPSP-M3UA linksets.

Recovery

1. Display the parameters specified using the `rtrv-ls` command.
2. If the **tfatcabmlq** parameter is specified, remove it. Refer to the *Database Administration Manual - IP7 Secure Gateway* for assistance.
3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4876 Cmd Rej: STP True PC and ATINPQ Subsystem does not exist in MAP Table

Commands Used: `ent-ss-appl`

For ATINP, the STP true point code and ATINPQ subsystem must exist in the MAP table.

Recovery

- Verify that the STP true point code, and the ATINPQ subsystem exists in the MAP database table. Refer to the *Database Administration Manual - Systems Management* for assistance.
- Call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4877 Cmd Rej: ATINPQ Subsystem is offline in database

Commands Used: `alw-map-ss`

The ATINPQ subsystem must be online in the database before this command can be entered.

Recovery

- Verify that the ATINPQ subsystem is online in the database. Refer to the *Database Administration Manual - Systems Management* for assistance.
- Call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4878 Cmd Rej: Invalid FCNA

Commands Used: `chg-netopts`

The value specified for the `fcna` parameter must be a classless Inter Domain Routing (Supernet) address with a 23-bit network prefix.

Recovery

Re-enter the `chg-netopts` command specifying a different network address. Refer to the *Commands Manual* for more information about this command and the `fcna` parameter.

E4880 Cmd Rej: SSN must not be NONE if RI is SSN

Commands Used: `chg-gsmmap-scrn`, `chg-gsmmap-scrn`, `ent-gsmmap-scrn`, `ent-gsms-opcode`

If the `nri=ssn` parameter is specified, then the `nssn=none` parameter cannot be specified.

Recovery

1. Display the specified parameters. Refer to the *Database Administration Manual - Features* for assistance.
2. If the output of Step 1 shows the `nri=ssn` parameter specified, re-enter the command without the `nssn=none` parameter.

E4881 Cmd Rej: Action Set does not exist

Commands Used: `chg-npp-srs`, `dlt-npp-as`, `ent-npp-srs`, `chg-npp-as`

The Action Set (AS) specified by the `asn` parameter must already exist in the NPP AS table.

Recovery

- Verify that the AS exists in the NPP AS table. Enter the `rtrv-npp-as` command.

- Re-enter the command that generated this message, specifying a valid AS. Refer to the *Commands Manual* and to the *Numbering Plan Processor (NPP) Overview* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4882 Cmd Rej: Rule Contains unsupported Conditioning Actions

Commands Used: chg-npp-srs, ent-npp-srs

The NPP Rule contains a Conditioning Action that is not supported by the NPP Service.

Recovery

- Verify that all NPP Conditioning Actions that are used are supported by the NPP Service. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this message.

E4883 Cmd Rej: Rule contains unsupported Service Actions

Commands Used: chg-npp-srs, ent-npp-srs

The NPP Rule contains a Service Action that is not supported by the NPP Service.

Recovery

- Verify that all the NPP Service Actions used are supported by the NPP Service. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this message.

E4884 Cmd Rej: Rule contains unsupported Formatting Actions

Commands Used: chg-npp-srs, ent-npp-srs

The NPP Rule contains a Formatting Action that is not supported by the NPP service.

Recovery

- Verify that all the NPP Formatting Actions used are supported by the NPP service. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this message.

E4885 Cmd Rej: Rule violates Service Action precedence

Commands Used: chg-npp-srs, ent-npp-srs

The Service Actions specified by the Action Set do not conform to the NPP Service's Service Action precedence order.

Recovery

- Verify the associated Service Action set conforms to the NPP Service Service Action precedence order. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this error message.

E4886 Cmd Rej: Rule conditions too many digits

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The Conditioning Actions specified by the Action Set exceed what the filter will allow.

Recovery

- Verify the NPP Rule's associated Conditioning Action set only conditions the maximum number of allowed digits or less. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this error message.

E4887 Cmd Rej: Rule does not condition a variable length digit string

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The Conditioning Actions specified by the Action Set do not support variable string conditioning.

Recovery

- Verify the NPP Rule's associated Conditioning Action set only contain the Conditioning Actions that support variable string conditioning. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this error message.

E4888 Cmd Rej: System Rule maximum (8192) reached

Commands Used: `ent-npp-srs`

The NPP system-wide rule maximum of 8192 rules was reached.

Recovery

- Remove desired system wide rules in order to add additional rules.
- Refer to the *Commands Manual* for assistance.
- Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4889 Cmd Rej: Service Rule maximum (4096) reached

Commands Used: ent-npp-srs

The NPP service rule maximum of 4096 (4k) was reached.

Recovery

- Refer to the *Commands Manual* for assistance.
- Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4890 Cmd Rej: Rule already exists

Commands Used: ent-npp-srs

The NPP rule already exists within the NPP Rule table.

Recovery

There is no need to enter a rule that already exists in the table. See the "Customer Care" section at the number given in Chapter 1 of this manual for assistance if necessary.

E4891 Cmd Rej: Rule does not exist

Commands Used: chg-npp-srs, dlt-npp-srs

The NPP Rule that is specified by the **fdl**, **fnai**, **fpfx**, and **srvn** parameters must already exist in the NPP Rule table.

Recovery

- Create the NPP rule in the rule table. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance.
- Re-enter the command that generated this error message.

E4892 Cmd Rej: Action Set already exists

Commands Used: ent-npp-as

The Action Set (AS) must not already exist in the NPP AS table.

Recovery

1. Refer to the *Numbering Plan Processor (NPP) Overview* for the correct parameter values to initiate this command.
2. Modify the parameter values and re-enter the command that generated this error.

3. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4893 Cmd Rej: Action Set referenced

Commands Used: `chg-npp-as`, `dlt-npp-as`

If rules are referencing an action set, the action set cannot be changed.

Recovery

- Verify the rules which reference the AS. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance.
- Remove the references. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this message.

E4895 Cmd Rej: CPCx must not be ITUN24 if CPCTYPE is ATINPQ

Commands Used: `chg-sid`

If the `cpctype=atinpq` parameter is specified, then the `cpcn24` parameter cannot be specified.

Recovery

- Re-enter the command, specifying a valid parameter for the code. Refer to the *Commands Manual* for assistance.
- If the issue is not resolved, call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4896 Cmd Rej: LNP must be ON or ATINP must be enabled

Commands Used: `chg-map`, `ent-map`

The LNP feature must be turned on (see the `enable-ctrl-feat` command) or ATINP feature must be enabled before an EAGLE 5 ISS true PC and the respective subsystem can be changed.

Recovery

- Verify the LNP feature is turned on or the ATINP feature is enabled. Refer to the *Commands Manual* for assistance.
- If you continue to have problems call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4897 Cmd Rej: EIR must be ON or ATINP must be enabled

Commands Used: `chg-map`, `ent-map`

The EIR feature must be turned on or ATINP feature must be enabled before the `mpci` parameter value can be a true point code.

Recovery

- Verify the EIR feature is turned on or the ATINP feature is enabled. Refer to the *Commands Manual* for assistance.
- If you continue to have problems call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4898 Cmd Rej: Minimum Number Conditioning Not Met

Commands Used: `chg-npp-as`, `ent-npp-as`

One of the following Conditioning Action combinations must be specified for the Action Set:

- ZNX
- DN*, CC*
- CC*, AC*, SN*

The new or existing Formatting Actions (FAs) within the Action Set must be able to be loaded by the corresponding CAs.

Recovery

1. Verify that the NPP Action Set contains an appropriate combination of CAs. Enter the `rtv-npp-as` command.
2. Re-enter the command, specifying an appropriate combination of CAs. Refer to the *Numbering Plan Processor (NPP) Overview* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" in Chapter 1 of this manual.

E4900 Cmd Rej: Entry does not exist with specified GTIN24-TT-NP(V)-NAI(V)

Commands Used: `chg-srvsel`, `dlt-srvsel`

You specified an entry that does not match an existing `gtin24`, `tt`, `np(v)`, `nai(v)`, and `ssn` parameter combination as required.

Recovery

1. Display the service selectors.

Enter the `rtrv-srvsel` command.

2. Re-enter the command specifying a parameter combination that exists in the database.

E4901 Cmd Rej: TTI, NP, NAI cannot be specified for a direction of ATOI

Commands Used: `dlt-gtcnv`

The following parameter(s) cannot be specified when the direction of conversion is ANSI-to-ITU (`dir=atoi`): ITU translation type (`tti`), numbering plan (`np`), and nature of address indicator (`nai`).

Recovery

Re-enter the `dlt-gtcnv` command specifying `dir=atoi`, but without specifying parameters `tti`, `np`, and `nai`.

E4902 Cmd Rej: CSPC group cannot contain both PCN and PCN24 point codes

Commands Used: `ent-cspc`

The specified concerned signaling point code types are mutually exclusive. A concerned signaling point code group cannot include both `pcn` and `pcn24` point codes (ITUN and ITUN24).

Recovery

1. Determine which type of point code is desired (ITUN or ITUN24).
2. Re-enter the `ent-cspc` command specifying either `pcn` or `pcn24` point codes, but not both.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4903 Cmd Rej: If NGTI is 4, PC cannot be ANSI

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

If the `ngti=4` parameter is specified, the translated point code cannot be ANSI. For ANSI point codes, the GTI value must be 2.

Recovery

Re-enter the command, specifying either:

- `ngti=4` with no ANSI point code specified
- OR
- `ngti=2` for ANSI point codes

E4904 Cmd Rej: ADDTBLCNV and DELTBLCNV cannot be specified together

Commands Used: `chg-upgrade-config`

The specified parameters (`addtblcnv` and `deltblcnv`) are mutually exclusive.

Recovery

Re-enter the `chg-upgrade-config` command specifying either the `addtblcnv` or the `deltblcnv` parameter, but not both.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4911 Cmd Rej: Disk invalid for hardware configuration

Commands Used: `chg-gpl`, `chg-tbl`, `copy-gpl`, `copy-tbl`, `disp-disk-dir`, `format-disk`, `tst-disk`

For `chg-gpl` and `disp-disk-dir`, an E5-MCAP card must be provisioned in the system before the `src=usb` parameter can be specified.

For `chg-tbl` and `tst-disk`, an E5-MCAP card must be installed before the `disk=usb` parameter can be specified.

For `copy-gpl` and `copy-tbl`, an E5-MCAP card must be installed before a value of `usb` can be specified for the `ddriv` or `sdrv` parameter.

For `format-disk`, if the `type=usb` parameter is specified, then a credit card drive must be present in the active MASP.

Recovery

Before entering the `chg-tbl` command or specifying the `usb` value, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4912 Cmd Rej: Disk invalid for specified Location

Commands Used: `copy-gpl`, `copy-tbl`, `format-disk`

For `copy-gpl`, the specified disk type does not match the specified location.

For `copy-tbl`, if a value of `fixed` is specified for the `sdrv` or `ddriv` parameter, then a value of `1114` or `1116` must be specified for the `sloc` or `dloc` parameter, respectively.

For `format-disk`, a value of `1114` or `1116` must be specified for the `loc` parameter, before the `type=fixed` parameter can be specified.

Recovery

- Re-enter the command, specifying the correct disk type or the appropriate values for the parameter. Refer to the *Commands Manual* for more information about these commands.
- Contact the Customer Care Center if this error message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4913 Cmd Rej: Disk parameter required

Commands Used: `disp-disk-dir`

The `src` parameter must be specified.

Recovery

- Re-enter the `disp-disk-dir` command, specifying the `src` parameter.
- Contact the Customer Care Center if this error message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4914 Cmd Rej: Src invalid for hardware configuration

Commands Used: `act-upgrade`, `chg-db`

An E5-MCAP card must be provisioned in the system before the `src=usb` parameter can be specified.

Recovery

For the `act-upgrade` command, use the `rtrv-card` command to display the cards in the system. Provision an E5-MCAP card if necessary. Refer to the *Database Administration Manual - Systems Management* for assistance.

For the `chg-db` command, the `usb` value must be specified by Tekelec personnel only. Contact the Customer Care Center if this error message appears. See the "Customer Care Center" section in Chapter 1 of this manual.

E4915 Cmd Rej: Dest invalid for hardware configuration

Commands Used: `chg-db`

An E5-MCAP card must be installed before the `dest=usb` parameter can be specified.

Recovery

The `usb` value must be specified by Tekelec personnel only. Contact the Customer Care Center if this error message appears. See the "Customer Care Center" section in Chapter 1 of this manual.

E4916 Cmd Rej: Command invalid for hardware configuration

Commands Used: `disp-lba`, `set-lba`

If E5-MCAP, E5-MDAL, or E5-TDM cards are installed, then this command cannot be entered.

Recovery

1. Display the cards in the system using the `rtrv-card` command.
2. If any of the above-listed cards are installed in the system, the Display Logical Block or Set Logical Block commands cannot be used. Refer to the *Commands Manual* for more information about this command or an alternative.

E4918 Cmd Rej: Could not access USB disk

Commands Used: `act-upgrade`, `chg-db`, `chg-gpl`, `copy-gpl`

For `act-upgrade`, if the `src=usb` parameter is selected, then the credit card USB upgrade media must be inserted in the Active OAM's flush mount USB slot.

For `chg-db`, if the `src=usb` or `dest=usb` parameter is specified, then a credit card drive must be inserted into the Active OAM flush-mounted USB port.

For `chg-gpl`, a credit card drive must be inserted in the Active OAM.

For `copy-gpl`, the credit card drive must be accessible in the Active OAM credit card USB port.

Recovery

For the `act-upgrade` command, enter the `rept-stat-db` command to verify that a Credit Card drive is installed. Install the drive if necessary. Refer to the Upgrade Procedures for the target release or the *Database Administration Manual - System Management* for instructions.

For all other commands, the `usb` value must be specified by Tekelec personnel only. Contact the Customer Care Center if this error message appears. See the "Customer Care Center" section in Chapter 1 of this manual.

E4919 Cmd Rej: Could not access RAM disk

Commands Used: `act-upgrade`

The internal ramdisk is not available for the credit card USB upgrade image to be unpackaged.

Recovery



CAUTION

CAUTION: It is strongly recommended that this command be used only in conjunction with the system Upgrade Procedure for your target release. The Upgrade Procedure provides step-by-step information on performing an upgrade.

- The internal ramdisk is not a valid drive for the USB upgrade. Refer to the *Commands Manual* for more information on actions to be specified with the `act-upgrade` command.
- Contact the Customer Care Center if this error message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4920 Cmd Rej: Cannot copy table onto itself

Commands Used: `copy-tbl`

The same value cannot be specified for the **sloc** and **dloc** or the **stbl** and **dtbl** parameters.

Recovery

- Re-enter the command, specifying different values for the **sloc** and **dloc** parameters, or the **stbl** and **dtbl** parameters.
- Contact the Customer Care Center if this error message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4921 Cmd Rej: Type invalid for hardware configuration

Commands Used: `format-disk`

An E5-MCAP card must be installed before the **type=usb** parameter can be specified.

Recovery

The **usb** value must be specified by Tekelec personnel only. Contact the Customer Care Center if this error message appears. See the "Customer Care Center" section in Chapter 1 of this manual.

E4922 Cmd Rej: PCR N1/N2 threshold is out of range for the link type

Commands Used: `ent-slk`

The N1/N2 thresholds for PCR Error Correction Mode (ECM) specified by the **pcrn1** and **pcrn2** parameters must be within the range specified for the link type. Only low speed E1/T1 (LSL) and Unchannelized T1 links support PCR ECM. Refer to the command description in the *Commands Manual* for the range values.

Recovery

Re-enter the `ent-slk` command specifying a threshold within the range for the link type as shown in the table.

E4924 Cmd Rej: Wildcard value is not allowed for ACN

Commands Used: `chg-sccp-msg`

The `tcapacn=*` parameter cannot be specified.

Recovery

Re-enter the command specifying a valid value for the `tcapacn` parameter. Refer to the *Commands Manual* for more information.

E4925 Cmd Rej: OPC must not be identical to APC of linkset

Commands Used: `chg-rtx`, `ent-rtx`

The value specified for the `opc` parameter cannot be the same as the adjacent point code of the linkset specified by the `lsn` parameter.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command specifying no parameters.
2. Re-enter the command specifying a different linkset name for the `opc` parameter.

E4926 Cmd Rej: Service Portability feature must be enabled

Commands Used: `chg-ainpopts`, `chg-atinpopts`, `chg-gsmsmsopts`, `chg-inpopts`, `chg-is41smsopts`, `chg-tifopts`, `chg-ttropts`

The S-Port feature must be enabled before the `sporttype` parameter can be specified.

For the `chg-tifopts` command, the S-Port feature must be enabled before the `sportrelay` or `sportrls` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the appropriate Feature Manual for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4927 Cmd Rej: S-Port feature exclusive of A-Party Blacklist feature

Commands Used: `enable-ctrl-feat`

The S-Port feature and the IDP A-Party Blacklist feature cannot both be enabled in the system.

Recovery

1. Display the status of controlled features in the system. Enter the `rtvr-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Contact the Customer Care Center for assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4928 Cmd Rej: S-Port and G-Port SRI Query for Prepaid features must be enabled

Commands Used: `chg-gsmopts`

The S-Port and G-Port SRI Query for Prepaid features must be enabled before the `sporttype` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtvr-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the features. Refer to the *Commands Manual* and to the *Feature Manual - G-Port* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4929 Cmd Rej: IS41 GSM Migration feature must be turned ON

Commands Used: `chg-gsmsmsopts`

The IS41 GSM Migration feature must be turned on before the `igsmmsrelay`, `is41smcgttsn`, or `defis41smc` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtvr-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.

2. Enable and turn on the feature if necessary. Refer to the *Commands Manual* and to the *Feature Manual–IS41 GSM Migration* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4930 Cmd Rej: IGMSMSRELAY cannot be yes, if DEFIS41SMSC is none

Commands Used: `chg-gsmsmsopts`

If the `defis41smsc=none` parameter is specified, then the `igmsmsrelay=yes` parameter cannot be specified.

Recovery

Re-enter the command specifying an acceptable parameter combination. Refer to the *Commands Manual* and to the *Feature Manual - IS41 GSM Migration* for assistance.

E4931 Cmg Rej: TALI link configured in the system

Commands Used: `act-upgrade`

Upgrade health check requires NO TALI link to be configured in the system.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4932 Cmg Rej: TALI socket configured in the system

Commands Used: `act-upgrade`

Upgrade health check requires NO TALI socket to be configured in the system.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4933 Cmg Rej: ISUP Normalization configuration present in the database

Commands Used: `act-upgrade`

Upgrade health check requires NO ISUP Normalization feature related configuration to be present in the system.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4934 Cmd Rej: Formatting Action Not Loaded

Commands Used: `chg-npp-as, ent-npp-as`

A Formatting Action specified by the Action Set does not have a corresponding Conditioning Action in its Conditioning Action set that is capable of populating the Formatting Action.

Recovery

1. Verify that each Formatting Action has a corresponding Conditioning Action capable of loading the Formatting Action. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance.
2. Re-enter the command that generated this message.

E4935 Cmd Rej: Service Must Have Rules to Turn On

Commands Used: `chg-npp-serv`

The NPP Service must have rules associated with it before its status can be set to ON.

Recovery

- Verify that rules are associated with the NPP Service before attempting to set it to ON. Refer to the *Numbering Plan Processor (NPP) Overview* for more information concerning use of this command. Refer to the *Commands Manual* if more information is necessary for associating rules with this service.
- Re-enter the command that generated this message.

E4936 Cmd Rej: Cannot Modify Service with Rules Provisioned

Commands Used: `chg-npp-serv`

If the service specified by the `srvn` parameter references any NPP rules, then the `intl`, `natl`, `nai1`, `nai2`, and `nai3` parameters cannot have a value of `none`.

Recovery

- Verify the NPP service has rules provisioned. Refer to the *Commands Manual* for more information concerning use of this command.
- Remove all rules before trying to change the parameter. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this message.

E4937 Cmd Rej: Conditioning Actions must be Specified in Sequential Order

Commands Used: `chg-npp-as, ent-npp-as`

If specified, the **caX** parameters must be consecutively numbered, always including **ca1**. The parameters do not have to be entered into the command in sequential order.

Note: To change the value of a single CA within an Action Set (AS), all of the **ca** parameters specified for the AS must be entered. Refer to the *Numbering Plan Processor (NPP) Overview* for additional information.

Recovery

Re-enter the command that caused this error message to occur, and enter the CA parameters using sequential numbers and including **ca1**.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4938 Cmd Rej: Service Actions must be Specified in Sequential Order

Commands Used: `chg-npp-as, ent-npp-as`

If specified, the **saX** parameters must be consecutively numbered, always including **sa1**. The parameters do not have to be entered in sequential order. The SA with the highest precedence must be assigned as the value for **sa1**.

Note: To change the value of a single SA within an Action Set (AS), all of the SA parameters specified for the AS must be entered. Refer to the *Numbering Plan Processor (NPP) Overview* for more information.

Recovery

Re-enter the command specifying the **saX** parameters as sequential numbers and including **sa1**.

Contact the Customer Care Center if this error message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4939 Cmd Rej: Formatting Actions must be Specified in Sequential Order

Commands Used: `chg-npp-as, ent-npp-as`

If specified, the **faX** parameters must be consecutively numbered, always including **fa1**. The parameters do not have to be entered into the command in sequential order.

Note: To change the value of a single FA within an Action Set (AS), all of the **faX** parameters specified for the AS must be entered. Refer to the *Numbering Plan Processor (NPP) Overview* for more information.

Recovery

Re-enter the command that caused this error message to occur, and enter the **faX** parameters using sequential numbers and including **fa1**.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4940 Cmd Rej: Rule with Longer FPFX than FDL Invalid

Commands Used: `ent-npp-srs`

If the NPP Rule's Filter Prefix (FPFX) and the Filter Digit Length (FDL) values are not set as variables (wildcard *), then the FPFX must not have digits greater than the FDL value.

Recovery

- Verify the NPP Rule's Filter Prefix and Filter Digit Length values. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance.
- Make sure the FPFX does not have digits greater than the FDL value, or the FPFX and FDL values are set as variables.

E4941 Cmd Rej: Rule with FPFX=* value cannot have AS with CA(x)=FPFX

Commands Used: `chg-npp-srs`, `ent-npp-srs`

If a rule contains an FPFX with a wildcard value, then the rule cannot also contain an AS where the **fpfx CA** is specified.

Recovery

- Re-enter the command that generated this error message, without specifying the **caX=fpfx** parameter. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance, or the *Commands Manual* for a list of commands and parameter rules.
- If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4943 Cmd Rej: Number of links in the linkset falls below NUMSLK value

Commands Used: `dlt-slk`

If deleting the link causes the provisioned link count to fall below the **numslk** thresholds configured for the corresponding **IPSG-M3UA** linkset (see the `chg-lsopts` command), then the link cannot be deleted. If values of 0 or 1 are specified for all of the **numslk** threshold parameters, then the last link can be deleted.

Recovery

1. Refer to the `chg-lsopts` command description in the *Commands Manual* and to the *Database Administration Manual - SS7* for information about the **numslk** threshold and how to delete a link.

2. Re-enter the command that generated this message.
3. Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4945 Cmd Rej: FPFX value cannot end with a '?'

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The value specified for the `fpfx` parameter cannot contain a `?` as the final character.

Recovery

- Re-enter the value specified for the `fpfx` parameter, and ensure that the final character is not a question mark (`?`). Refer to the *Numbering Plan Processor (NPP) Overview* for assistance with NPP, or the *Commands Manual* for a list of commands and valid parameters.
- If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4946 Cmd Rej: Invalid FCNB

Commands Used: `chg-netopts`

The value specified for the `fcnbn` parameter must be a classless Inter Domain Routing (Supernet) address with a 23-bit network prefix.

Recovery

Re-enter the `chg-netopts` command specifying a different network address. Refer to the *Commands Manual* for more information.

E4948 Cmd Rej: Adjacent PC of the Linkset must be ITUN or ITUI

Commands Used: `chg-lsopts`

Values for the `icnimap` and `ognimap` parameters other than `none` can be specified only for ITU-I and ITU-N APCs of the linkset. The value `none` must be specified for the parameters if the APC is ANSI or ITU-N24.

Recovery

1. Display the APCs assigned to the specified linkset. Enter the `rtrv-ls` command.
2. Verify that the APCs of the specified linkset are either ITU-I or ITU-N (14-bit) point codes. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call your Customer Care Center if the error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4949 Cmd Rej: TEST MSG protocol does not match with the FEAT specified

Commands Used: `tst-msg`

The values specified for the **prot** and **feat** parameters must be compatible. Refer to the command description in the *Commands Manual* for valid combinations.

Recovery

Re-enter the test message using the correct protocol.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4950 Cmg Rej: At least one ITU NP feature must be ON

Commands Used: `enable-ctrl-feat`

At least one of the EPAP-based ITU NP features (G-Flex, G-Port, A-Port, INP, IGM, EIR, V-Flex IDP Relay or IS41 migration) must be enabled before the 1100 TPS/DSM for ITU NP feature can be enabled.

Note:

The 1100 TPS/DSM for ITU NP feature cannot be turned ON if ANSIGFLEX is ON.

Recovery

1. Display the status of the ANSIGFLEX STP option. Enter the `rtrv-stpopts` command.
If the ANSIGFLEX option is shown in the output, then use the `chg-stpopts` command to turn the option off. Refer to the command description in the *Commands Manual* for assistance.
2. Display the status of the controlled features. Enter the `rtrv-ctrl-feat` and the `rtrv-feat` commands.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled, but it is not turned on.
3. If no EPAP-based feature is on, then refer to the appropriate feature manual to enable and turn on the desired feature.
4. Enable and turn on the 1100 TPS/DSM for ITU NP feature. Refer to the `enable-ctrl-feat` command and the `chg-ctrl-feat` command in the *Commands Manual* for assistance.
5. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4952 Cmd Rej: Only message with ACTIVE=YES shall be sent to the Feature

Commands Used: `tst-msg`

If the specified test message is defined with **ACTIVE=YES** (see the `chg-isup-msg` command), then the message is sent to the specified network card for test processing. (Test messages are never sent out to the live network.)

Recovery

- Verify the message specified has a parameter value of **ACTIVE=YES**. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated the error message. If this message occurs again, call the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4953 Cmd Rej: RESET is mutually exclusive with any other parameter

Commands Used: `chg-ttr-msg`, `chg-gsm-msg`, `chg-is41-msg`, `chg-tatr-msg`

If the **reset** parameter is specified, then no other parameters can be specified in the command.

Recovery

- Verify the **reset** parameter is specified. Enter the 'retrieve' version of the relevant command. Refer to the *Commands Manual* for more information. If the **reset** parameter is specified, then no other parameter can be specified in the command.
- Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4956 Cmd Rej: System Action Set maximum (1024) reached

Commands Used: `ent-npp-as`

The NPP System-wide Action Set maximum 1024 (1k) entries was reached.

Recovery

- Reduce the number of System-wide Action Sets used before trying to add additional ones. Refer to the *Commands Manual* for assistance.
- Call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4957 Cmd Rej: MO SMS IS41-to-GSM Migration feature must be enabled

Commands Used: `chg-is41smsopts`, `chg-npp-srs`, `ent-npp-srs`

The MO SMS IS41-to-GSM Migration feature must be enabled before an AS containing the **migrate** SA can be specified as a value for the **asn** parameter with the MOSMSICDPN service.

Recovery

- Verify the MO SMS IS41-to-GSM Migration feature is enabled. Refer to the *Commands Manual* for assistance.
- Re-enter the command that generated this error message.
- Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4960 Cmd Rej: Conditioning Actions condition too many digits

Commands Used: `chg-npp-as`, `ent-npp-as`

The NPP Conditioning Action (CA) set will condition more digits than the filter digit length of the rule.

Recovery

1. Reduce the number of digits conditioned. Refer to the *Commands Manual* for assistance.
2. Call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4961 Cmd Rej: ICNIMAP and OGNIMAP parameters must be specified together

Commands Used: `chg-lsopts`

The **icnimap** and **ognimap** parameters must be specified together in the command.

Recovery

Re-enter the command that generated this error message, and specify the **icnimap** and **ognimap** parameters in the command. Refer to the *Commands Manual* for assistance.

E4962 Cmd Rej: ICNIMAP and OGNIMAP values must be compatible

Commands Used: `chg-lsopts`

The NI mapping for incoming messages in a linkset must be compatible with the NI mapping for the outgoing messages.

Recovery

Re-enter the command that generated this error message, and specify valid parameter values. Refer to the command description in the *Commands Manual* to verify that the parameter values in the command are valid.

E4964 Cmd Rej: Duplicate CAs loading same FA invalid

Commands Used: `chg-npp-as, ent-npp-as`

The NPP Conditioning Action (CA) set can not have duplicate Conditioning Actions that will load or populate the same Formatting Action.

Recovery

- Refer to the *Commands Manual* for assistance in determining which Conditioning Action set should be used for that formatting action.
- Call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4965 Cmd Rej: CAs violate number conditioning

Commands Used: `chg-npp-as, ent-npp-as`

The NPP Conditioning Action set contains Conditioning Actions (CAs) that load or populate invalid combinations of Formatting Action (FAs).

- If the ZNX CA is specified, then the AC* and DNX CAs cannot be specified in the same Action Set.
- Each AC*, CC*, DN*, and SN* CA can be specified only once in the Action Set.

Recovery

Re-enter the command with valid Conditioning Action parameters. Refer to the *Numbering Plan Processor (NPP) Overview* and to the Feature Manual for the feature of interest for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4966 Cmd Rej: Parameter only valid for TELNET terminals

Commands Used: `chg-trm`

The `logintmr` and `logouttmr` parameters can be specified only for terminals with `type=telnet` specified.

Recovery

1. Verify that the specified terminal is a telnet terminal. Enter the `rtrv-trm` command.
2. Re-enter the command that generated this message and specify the `logintmr` and `logouttmr` parameters for a telnet terminal.

E4967 Cmd Rej: Duplicate FA loading invalid

Commands Used: `chg-npp-as, ent-npp-as`

The same value cannot be specified for the **faX** parameters within an Action Set.

Recovery

1. Display the Formatting Actions in the specified Action Set. Enter the `rtrv-npp-as` command.
2. Re-enter the command specifying valid values for the Formatting Action parameters. Refer to the *Numbering Plan Processor (NPP) Overview* and to the Feature Manual for the feature of interest for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4968 Cmd Rej: FAs violates number formatting

Commands Used: `chg-npp-as, ent-npp-as`

The Action Set cannot contain the following combinations of Formatting Actions (FAs):

- If the DN FA is specified, then the AC*, SN*, and ZN FAs cannot be specified.
- If the ZN FA is specified, then the AC*, CC*, SN*, and DN* FAs cannot be specified.
- If the SN FA is specified, then the ZN and DN* FAs cannot be specified.
- If the RNOSPODN, RNOSPOSN, or RNOSPOZN FA is specified, then the RN, SP, SN*, DN* or ZN FAs cannot be specified.
- The RNOSPODN, RNOSPOSN, and RNOSPOZN FAs cannot be specified together.

Recovery

Re-enter the command, specifying a valid combination of parameters. Refer to the *Numbering Plan Processor (NPP) Overview* and to the Feature Manual for the feature of interest for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4969 Cmd Rej: At least one SMS feature must be Enabled

Commands Used: `rtrv-gsmsmsopts, rtrv-IS41smsopts`

At least one of the MO-based or MT-based SMS features must be enabled before this command can be entered. Refer to the command descriptions in the *Commands Manual* for a list of valid features.

Recovery

- Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
- Enable one of the valid features. Refer to the appropriate feature manual for assistance.
- Re-enter the command that generated the error message.
- Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4970 Cmd Rej: FPFX must be first in CA set

Commands Used: `chg-npp-as`, `ent-npp-as`

If specified, the FPFX CA must be the first value (**fpfx**) in the **ca** value list or **caX** parameter sequence.

Recovery

Re-enter the command specifying the **fpfx** value first in the **ca** value list or **caX** parameter sequence. Refer to the *Numbering Plan Processor (NPP) Overview* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4971 Cmd Rej: ZNX/DNX/SNX must be last in CA set

Commands Used: `chg-npp-as`, `ent-npp-as`

The ZNX, SNX, and DNX Conditioning Actions (CAs) must be the final value (**zns**, **snx**, or **dnx**) in the **ca** value list or the **caX** parameter sequence.

Recovery

Re-enter the command that generated this error specifying the CAs in the correct sequence.

If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4972 Cmd Rej: If specified, NSNP/NSNAI must be none for requested service

Commands Used: `chg-srvsel`

If the value specified for the **nserv** parameter is **atinp**, **eir**, **idps**, **inpq**, **idpr**, **ttr**, or **vflex**, then only a value of **none** can be specified for the **nsnai** or **nsnp** parameter.

Recovery

1. Verify the value specified for the **nserv** parameter. Enter the `rtrv-srvsel` command.
2. Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* for assistance.
3. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4973 Cmd Rej: Parameter only valid for TELNET and EMSALM terminals

Commands Used: `chg-trm`

The **pngtimeint** and **pngfailcnt** parameters can be specified only for terminals with terminal type **emsalm** or **telnet**.

Recovery

1. Verify that the specified terminal is a terminal with type **telnet** or **emsalm**. Enter the `rtrv-trm` command.
2. Re-enter the command that generated this message for a telnet or emsalm terminal.

E4974 Cmd Rej: FCNA and FCNAMASK must not be identical

Commands Used: `chg-netopts`

The same value cannot be specified for the **fcna** and **fcnamask** parameters.

Recovery

Re-enter the command specifying different values for the **fcna** and **fcnamask** parameters. Refer to the *Commands Manual* for more information.

E4975 Cmd Rej: Duplicate SAs Specified

Commands Used: `chg-npp-as`, `ent-npp-as`

The same value cannot be specified for the **saX** parameters within an Action Set.

Recovery

1. Display the Service Actions in the specified Action Set. Enter the `rtrv-npp-as` command.
2. Re-enter the command specifying valid values for the Service Action parameters. Refer to the *Numbering Plan Processor (NPP) Overview* and the Feature Manual for the feature of interest for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4976 Cmd Rej: Terminal must be inhibited before changing the parameter

Commands Used: `chg-trm`

The `logintmr`, `logouttmr`, `pngtimeint`, and `pngfailcnt` parameters can be specified only when the terminal is in the Inhibited state.

Recovery

1. Verify the state of the specified terminal. Enter the `rept-stat-trm` command.
2. Verify the terminal is inhibited before attempting to change the parameters. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this message.

E4977 Cmd Rej: At least one TIF feature must be ON

Commands Used: `chg-npp-srs`, `ent-npp-srs`

At least one TIF feature must be turned on before an AS containing the `cdial` SA can be specified as a value for the `asn` parameter.

Recovery

1. Display the status of the TIF feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance.
3. If the status is on, re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4978 Cmd Rej: BPIPADDR only valid for E5-SM4G being equipped but inhibited

Commands Used: `chg-ip-card`

If the card in the location specified by the `loc` parameter is not an E5-SM4G card, or if a DSM card is provisioned in the system, then the `bpipaddr` and `bpsubmask` parameters cannot be specified.

Recovery

- A value of `BPIPADDR` or `BPSUBMASK` was specified improperly. Refer to the *Commands Manual* for correct usage of these values.
- If you continue to have problems call your Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E4979 Cmd Rej: Cannot set DefCC to NONE, if ATINP feature is ON

Commands Used: `chg-stpopts`

If the ATINP feature is turned on, then the `defcc=none` parameter cannot be specified.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command to determine if the ATINP feature is turned on.
2. If the feature has a status of OFF, re-enter the command that generated this error message. If the feature has a status of ON, the `defcc=none` parameter cannot be specified. Refer to the *Database Administration Manual - Systems Management* for more information.
3. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4981 Cmd Rej: TINP feature must be enabled before upgrade to 39.2 or later

Commands Used: `chg-gws-actset`, `chg-tinpopts`

The TINP feature must be enabled before upgrade to 39.2 or later.

The `chg-tinpopts` command cannot be entered unless the TINP feature was enabled before upgrading to Release 39.2 or later.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature cannot be used.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the TINP feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4982 Cmd Rej: At least one TIF feature must be enabled

Commands Used: `chg-gws-actset`, `chg-dstn`, `chg-isup-msg`, `chg-tifopts`, `ent-dstn`, `tst-msg`

For the `chg-gws-actset` command, at least one TIF feature must be enabled before the `tif`, `tif2`, or `tif3` stop action can be specified.

A TIF feature must be enabled before the `splitiam` parameter can be specified for the `chg-dstn` and `ent-dstn` commands.

At least one TIF feature must be enabled prior to running the `chg-isup-msg` or `chg-tifopts` commands. See the *Commands Manual* for a list of features that must be enabled before entering the command.

For the `tst-msg` command, at least one TIF feature must be enabled before a value of **tif**, **tif2**, or **tif3** can be specified for the **feat** parameter.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command and the `rtrv-feat` command.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled but is not turned on.

2. Enable and turn on the feature. Refer to the appropriate feature manual for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4983 Cmd Rej: TIF, TIF2, TIF3, TLNP, TINP, RDCT and SCCP are mutually exclusive

Commands Used: `chg-gws-actset`

Only one of the **tif**, **tif2**, **tif3**, **tlnp**, **tinp**, **rdct**, and **sccp** stop actions can be specified in the command.

Recovery

1. Determine the stop actions contained in the Action Set. Enter the `rtrv-gws-actset` command
2. Delete and re-enter the stop actions as necessary. Refer to the *Commands Manual* and to the *Database Administration Manual - Gateway Screening* for assistance.
3. Re-enter the command that caused this error message. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4984 Cmd Rej: TIF/TIF2/TIF3/TLNP/TINP/RDCT/SCCP must be last stop action

Commands Used: `chg-gws-actset`

If specified, the **tif**, **tif2**, **tif3**, **tlnp**, **tinp**, **rdct** or **sccp** stop action must be the last stop action in the command.

Recovery

1. Display the status of stop actions in the system. Enter the `rtrv-gws-actset` command.
Verify that if any of the stop actions listed above (only one can be specified in the command) appear in the command, that it is the last stop action in the command.

2. Delete and re-enter the stop actions if necessary. Refer to the *Database Administration Manual - Gateway Screening* for assistance.
3. Re-enter the command that generated this error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4985 Cmd Rej: Destination does not support same ITU ntwk alias combination

Commands Used: `chg-dstn`, `ent-dstn`

Two ITUI or two ITUN aliases can be specified for the same destination point code only if the aliases have different prefixes. One alias must be spare and one non-spare.

Note: In this command, only ITU-international and ITU national point codes and aliases support the spare point code subtype prefix (s-). Only ITU-international and ITU national point codes support the private and spare point code subtype prefix (ps-). All of the point code types support the private (internal) point code subtype prefix (p-). Aliases do not support the private (internal) point code prefix.

Recovery

Re-enter the command, specifying a different prefix for each alias within the same destination point code. Refer to the *Commands Manual* for more information on these commands and point code specifications.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E4988 Cmd Rej: TIF SCS Forwarding feature must be ON

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The TIF SCS Forwarding feature must be turned on before an AS containing the `fwdsacs` SA can be specified as a value for the `asn` parameter.

Recovery

1. Display the status of the TIF SCS Forwarding feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Numbering Plan Processor (NPP) Overview* for assistance.
3. If the status is on, re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4989 Cmd Rej: TIF Simple Number Substitution feature must be ON

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The **TIF Simple Number Substitution** feature must be turned on before an AS containing the **snsqgn** SA can be specified as a value for the **asn** parameter.

Recovery

1. Display the status of the **TIF Simple Number Substitution** feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Commands Manual* for assistance.
3. If the status is on, re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4993 Cmd Rej: If Forbid is NONE, Action must be PASS

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`

For the `ent-gsmmap-scrn` command, if the value of the **forbid** parameter is **none**, then the **action** parameter value must be **pass**.

For the `chg-gsmmap-scrn` command, if the value of the **nforbid** parameter is **none**, then the **naction** parameter value must be **pass**.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `ent-gsmmap-scrn` or `chg-gsmmap-scrn` commands.

E4994 Cmd Rej: TIF Number Portability feature must be ON

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The TIF Number Portability feature must be turned on before the **TIF ASD** or **TIF GRN** feature can be turned on.

The TIF Number Portability feature must be turned on before an AS containing the **crp**, **npnrls**, **cgpnprqd**, **nprelay**, or **nprls** SAs can be specified as a value for the **asn** parameter.

Recovery

1. Display the status of the TIF Number Portability feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Commands Manual* for assistance.
3. If the status is on, re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4995 Cmd Rej: GTT Set is being referred in GSM/IS41 SMSOPTS

Commands Used: `dlt-gttset`

A GTT set cannot be deleted if it is referenced by the **bpartygttsn** or **is41smcgttsn** parameter in the `chg-gsmsmsopts` command or by the **bpartygttsn** parameter in the `chg-is41smsopts` command.

Recovery

1. Display the status of the GTT sets. Enter the `rtrv-gsmsmsopts` and `rtrv-is41smsopts` commands.
2. If the GTT set is referenced as a BPARTYGTTSN or IS41SMSCGTTSN, then the reference must be deleted. Refer to the *Feature Manual - G-Port* for assistance with the `chg-gsmsmsopts` command and to the *Feature Manual - A-Port* for assistance with the `chg-is41smsopts` command.
3. Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4996 Cmd Rej: MO-SMS B-Party Routing feature must be Enabled

Commands Used: `chg-gsmsmsopts`, `chg-is41smsopts`

The MO SMS B-Party Routing feature must be enabled before the **bpartygttsn** or **mosmsgttdig** parameter can be specified.

Recovery

1. Determine whether the MO-SMS B-Party Routing feature is enabled. Enter the `rtrv-ctrl-feat` command.

If the MO-SMS B-Party Routing feature does not appear in the output, then the feature is not enabled. If the MO-SMS B-Party Routing feature has a status of OFF, then the feature is enabled but is not turned on.
2. If necessary, enable the MO-SMS B-Party Routing feature. Refer to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4997 Cmd Rej: SETTYPE of specified GTTSET must be CdGTA

Commands Used: `chg-gsmsmsopts`, `chg-is41smsopts`

The GTT set specified by the **bpartygttsn** or **is41smcgttsn** parameter must have a GTT set type of CDGTA.

Recovery

Note: The Origin-based SCCP Routing feature must be turned on before GTT set type information is shown in the output for the `rtrv-gttset` command.

1. Determine whether the Origin-based SCCP Routing feature is enabled and turned on. Enter the `rtrv-ctrl-feat` command.

If the feature does not appear in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.

2. If necessary, enable and turn on the Origin-based SCCP Routing feature. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Display the GTT set information. Enter the `rtrv-gttset` command.
Determine the set type of the appropriate GTT set.
4. If necessary, change the set type of the GTT set to **cdgta**. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
5. Re-enter the command that generated the error message.
6. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E4999 Cmd Rej: Undefined

Commands Used: all commands

Undefined error.

Recovery

Call your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5001 Cmd Rej: Up to two alias PCs are supported per DPC

Commands Used: `chg-dstn`, `ent-dstn`

A maximum of two aliases can be specified per destination point code.

Recovery

Re-enter the command, specifying no more than two aliases per destination point code. Refer to the *Commands Manual* for more information on these commands and point code attributes.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5002 Cmd Rej: MOSMS IS41 features must be enabled

Commands Used: `chg-is41smsopts`, `tst-msg`

For the `tst-msg` command, MO SMS ASD, MO SMS GRN, MO SMS IS41-to-GSM Migration, or MO-based IS1 SMS NP feature must be enabled before the `feat=mosmsnpp` and `prot=is41` parameters can be specified.

For the `chg-is41smsopts` command, the MO-based IS41 SMS NP, MO SMS IS41-to-GSM Migration, MO SMS ASD, or MO SMS GRN feature must be enabled before the `modaparam`, `mosmsnai`, or `mosmsaclen` parameter can be specified. The `modaparam` parameter can also be specified if the MO SMS B-Party Routing feature is enabled.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5003 Cmd Rej: MOSMS GSM features must be enabled

Commands Used: `tst-msg`

The MO SMS ASD, MO SMS GRN, Prepaid SMS Intercept Ph1, MO-based GSM SMS NP, or Portability Check for MO SMS feature must be enabled before the `feat=mosmsnpp` and `prot=gsm` parameters can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5012 Cmd Rej: FCNB and FCNBMASK must not be identical

Commands Used: `chg-netopts`

The same value cannot be specified for the `fcnbn` and `fcnbnmask` parameters.

Recovery

Re-enter the command specifying different values for the `fcnbn` and `fcnbnmask` parameters. Refer to the *Commands Manual* for more information.

E5013 Cmd Rej: PVN, FCNA and FCNB must not be identical

Commands Used: `act-upgrade`, `chg-netopts`

The same value cannot be specified for the `pvn`, `fcna`, and `fcnb` parameters.

The EAGLE 5 ISS PVN address in the source database cannot be identical to the EAGLE 5 ISS FCNA or FCNB network address in the target database.

Recovery

Re-enter the command specifying different values for the `pvn`, and `fcna`, or `fcnb` parameters. Refer to the *Commands Manual* for more information.

E5014 Cmd Rej: EISCOPY must be turned OFF

Commands Used: `chg-netopts`

The `eiscopy=off` parameter must be specified (see the `chg-eisopts` command) before the `pvn` or `pvnmask` parameter can be specified.

Recovery

1. Turn off the EIS copy function. Enter the `chg-eisopts:eiscopy=off` command.
2. Re-enter the `chg-netopts` command to change the PVN and PVN submask.
3. Turn the copy function on. Enter the `chg-eisopts:eiscopy=on` command.

E5015 Cmd Rej: FCMODE must be turned OFF

Commands Used: `chg-eisopts`

The `fcmode=off` parameter must be specified before the `eiscopy=off` parameter can be specified.

The `fcmode=off` parameter must be specified to change the value of the `fcmode` parameter between `stc` and `fcopy`.

Recovery

Re-enter the command, and specify the `fcmode=off` parameter in the command.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5016 Cmd Rej: TYPE parameter is required

Commands Used: `rept-stat-mon`

If the **loc** or **mode** parameters are specified, then the **type** parameter must be specified.

Recovery

Re-enter the `rept-stat-mon` command specifying the **type** parameter with the **loc** or **mode** parameters.

E5017 Cmd Rej: Command Obsolete. Please use rept-stat-mon

Commands Used: `rept-stat-mon`

As of Release 40.1.0, this command is obsolete. To obtain the EROUTE subsystem status, use the `rept-stat-mon` command.

Recovery

- Use command `rept-stat-mon` to get the route status.

E5018 Cmd Rej: MODE can be specified only when TYPE is eroute

Commands Used: `rept-stat-mon`

The **type=eroute** parameter must be specified before the **mode** parameter can be specified.

Recovery

Re-enter the command specifying the **type=eroute** parameter with the **mode** parameter.

Refer to the `rept-stat-mon` command description in the *Commands Manual* for more information.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5019 Cmd Rej: Either LOC or MODE can be specified

Commands Used: `rept-stat-mon`

The **loc** and **mode** parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the **loc** or **mode** parameter but not both.

E5020 Cmd Rej: TIF ASD feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The TIF ASD feature must be enabled before an AS containing the **asdlkup** or **cgpnasdrqd** SAs can be specified as value for the **asn** parameter with the TIF services.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5021 Cmd Rej: TIF GRN feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The TIF GRN feature must be enabled before an AS containing the **grnlkup** or **cgpngrnrqd** SAs can be specified as a value for the **asn** parameter with the TIF services.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the TIF GRN feature is not shown in the output, then the feature is not enabled.
If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the appropriate feature manual or the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5022 Cmd Rej: IDPR ASD feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The IDPR ASD feature must be enabled before an AS containing the **asdlkup** or **cgpnasdrqd** SA can be specified as a value for the **asn** parameter with the IDPRCDPN or IDPRCGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the IDPR ASD feature is not shown in the output, then the feature is not enabled.
2. Enable and turn on the feature. Refer to the appropriate feature manual or the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.

4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5023 Cmd Rej: IDPR GRN feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The IDPR GRN feature must be enabled before an AS containing the **grnlkup** or **cgpngnrqd** SA can be specified as a value for the **asn** parameter with the IDPRCDPN or IDPRCGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the IDPR GRN feature is not shown in the output, then the feature is not enabled.
2. Enable and turn on the feature. Refer to the appropriate feature manual or the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5024 Cmd Rej: Prepaid IDP Query Relay feature must be activated

Commands Used: `chg-ctrl-feat`, `chg-srvsel`, `enable-ctrl-feat`, `ent-srvsel`, `rtrv-srvsel`

The Prepaid IDP Query Relay feature must be turned on before the IDP A-Party Blacklist, IDP A-Party Routing, or IDP Service Key Routing feature can be enabled and before the IDPR ASD or IDPR GRN feature can be turned on.

For the `ent/chg/rtrv-srvsel` commands, the Prepaid IDP Query Relay feature must be turned on before the **serv=idpr** or **nserv=idpr** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5025 Cmd Rej: islsrsb is valid only if ISLSBR Feature is enabled

Commands Used: `chg-ls`, `ent-ls`, `rtrv-ls`

The ISLSBR feature must be enabled before the `islsrsb` parameter can be specified.

Recovery

1. Verify that the ISLSBR feature is enabled. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, the feature is not enabled.
2. Enable the ISLSBR feature. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5026 Cmd Rej: ASDLKUP and CGPNASDRQD SAs are mutually exclusive

Commands Used: `chg-npp-srs`, `ent-npp-srs`

An AS containing the `asdlkup` and `cgpnasdrqd` SAs cannot be specified as a value for the `asn` parameter.

Recovery

Re-enter the `chg-npp-srs` or the `ent-npp-srs` command, specifying either the `saX=asdlkup` or the `saX=cgpnasdrqd` parameter, but not both.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5027 Cmd Rej: GRNLKUP and CGPNGRNRQD SAs are mutually exclusive

Commands Used: `chg-npp-srs`, `ent-npp-srs`

GRNLKUP and CGPNGRNRQD Service Actions are mutually exclusive within the same NPP rule. An AS containing the `grnlkup` and `cgpngrnrqd` SAs cannot be specified as a value for the `asn` parameter.

Recovery

Re-enter the `chg-npp-srs` or the `ent-npp-srs` command, specifying either the `saX=grnlkup` or the `saX=cgpngrnrqd` Service Action, but not both.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5028 Cmd Rej: Eroute or Fast Copy card is required

Commands Used: `rept-stat-mon`

Either an STC card or an FC-capable card must be provisioned in the system.

Recovery

1. Display the cards in the system using the `rtrv-card` command.
2. If there is no STC card or FC-capable card listed in the output of Step 1, provision the card. Refer to the *Database Administration Manual - Features* for more information.
3. Re-enter the command that generated this error message. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5030 Cmd Rej: MO SMS ASD Feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The MO SMS ASD feature must be enabled before an AS containing the **asdlkup** or **cgpnasdrqd** SA can be specified as a value for the **asn** parameter for the MOSMSGCDPN, MOSMSGCGPN, MOSMSICDPN, or MOSMSICGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the MO SMS ASD feature is not shown in the output, then the feature is not enabled.
2. Enable and turn on the feature. Refer to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5031 Cmd Rej: MO SMS GRN Feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The MO SMS GRN feature must be enabled before the an AS containing the **cgpngnrqd** or **grnlkup** SAs can be specified as a value for the **asn** parameter with the MOSMSGCDPN, MOSMSGCGPN, MOSMSICDPN, or MOSMSICGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the MO SMS GRN feature is not shown in the output, then the feature is not enabled.
2. Enable and turn on the feature. Refer to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that generated this error message.

4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5032 Cmd Rej: INP CRP feature must be enabled

Commands Used: `chg-inpopts`

The INP CRP feature must be enabled before the **relcause** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5033 Cmd Rej: INP feature must be ON

Commands Used: `enable-ctrl-feat`, `chg-inpopts`

The INP feature must be turned on before the INP CRP feature can be enabled and before the `chg-inpopts` command can be entered.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5035 Cmd Rej: TIF GRN feature cannot be turned ON unless MATCHSEQ is DN

Commands Used: `chg-ctrl-feat`

The **matchseq=dn** parameter must be specified (see the `chg-tifopts` command) before the TIF GRN feature can be turned on.

Recovery

1. Re-enter the command that generated this message, and specify the **matchseq=dn** parameter before turning on the TIF GRN feature. Refer to the *Commands Manual* for more information about command rules.
2. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5036 Cmd Rej: TIF ASD feature cannot be turned ON unless MATCHSEQ is DN

Commands Used: `chg-ctrl-feat`

The **matchseq=dn** parameter must be specified (see the `chg-tifopts` command) before the TIF ASD feature can be turned on.

Recovery

1. Re-enter the command that generated this message, and specify the **matchseq=dn** parameter before turning on the TIF ASD feature. Refer to the *Commands Manual* for more information about command rules.
2. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5037 Cmd Rej: MATCHSEQ cannot be set to NPTYPE, if TIF GRN Feature is ON

Commands Used: `chg-tifopts`

If the TIF ASD feature is turned on, then the **matchseq=nptype** parameter cannot be specified.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command to determine if the TIF ASD feature is turned on.
2. If the feature has a status of OFF, re-enter the `chg-tifopts` command. If the feature has a status of ON, the **matchseq=nptype** parameter cannot be specified. Refer to the *Commands Manual* for more information about command rules.
3. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5038 Cmd Rej: MATCHSEQ cannot be set to NPTYPE, if TIF GRN Feature is ON

Commands Used: `chg-tifopts`

If the TIF GRN feature is turned on, then the **matchseq=nptype** parameter cannot be specified.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command to determine if the TIF GRN feature is turned on.
2. If the feature has a status of OFF, re-enter the `chg-tifopts` command. If the feature has a status of ON, the **matchseq=nptype** parameter cannot be specified. Refer to the *Commands Manual* for more information.
3. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5039 Cmd Rej: MATCHSEQ cannot be set to NPTYPE unless TIF NP Feature is Enabled

Commands Used: `chg-tifopts`

The TIF Number Portability feature must be enabled before the **matchseq=nptype** parameter can be specified.

Recovery

1. Display the status of the controlled features in the system. Enter the `rtrv-ctrl-feat` command to determine the status of the TIF Number Portability feature.

If the feature is not shown in the output, then the feature is not enabled.

If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* for more information on how to turn on the feature. Once the TIF Number Portability feature is enabled, the **matchseq=nptype** parameter can be specified.
3. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5040 Cmd Rej: Alternate RI Mate PC must be a full PC

Commands Used: `chg-map`, `chg-mrn`, `ent-map`

The value specified for the **mappc**, **mrnpc**, **mrnpca**, **mrnpci**, **mrnpcn**, or **mrnpcn24** parameter must be full point code.

Recovery

Re-enter the command, specifying a full point code for the parameter value. Refer to the *Commands Manual* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5041 Cmd Rej: GTT LS ARI feature must be enabled

Commands Used: `chg-map`, `chg-mrn`, `dlt-map`, `dlt-mrn`

For the `chg-map` and `dlt-map` commands, the GTT LS ARI feature must be enabled before the **mrnset** and **mrnpc** parameters can be specified.

For the `chg-mrn` and `dlt-mrn` commands, the GTT LS ARI feature must be enabled before the **mapset**, **mappc**, or **mapssn** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the GTT LS ARI feature is not shown in the output, then the feature is not enabled.
2. Enable and turn on the feature. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5042 Cmd Rej: PC and Alternate RI Mate PC network types don't match

Commands Used: `chg-map`, `chg-mrn`, `ent-map`, `ent-mrn`

The point codes and alternate RI Mate point codes must have the same network type. Refer to the command description in the *Commands Manual* for supported network types.

Recovery

Re-enter the command that generated this error message, specifying the correct value for the point codes.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5043 Cmd Rej: MRNPC must be specified when MRNSET is specified

Commands Used: `ent-map`

If the **mrnset** parameter is specified, then the **mrnpc** parameter must be specified.

Recovery

Re-enter the command that generated this message and specify the **mrnpc** parameter. Refer to the *Commands Manual* for more information.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5044 Cmd Rej: For ITU link sets, ISLSRSB must be in the range (1-4)

Commands Used: `chg-ls`, `ent-ls`

If an ITU linkset is used, then a value of **1-4** must be specified for the **islsrsb** parameter.

Recovery

Re-enter the command specifying a value of **1-4** for the **islsrsb** parameter. Refer to the *Commands Manual* for more information.

E5045 Cmd Rej: At least one Fast Copy capable card must be IS-NR

Commands Used: `chg-eisopts`

At least one FC-capable card must be installed and in the IS-NR state before the **fcmode=fcopy** parameter can be specified.

Note: A card that can run the Fast Copy interface is referred to as an FC-capable card. Currently, E5-ENET cards running the ipsg application are the only supported FC-capable cards. After the **fcmode=fcopy** parameter is specified, the card is referred to as an FC-enabled card.

Recovery

1. Enter the `rtrv-card` and `rept-stat-card` commands to verify the status of the cards in the system.
2. Verify that the correct card is installed and the status is *in-service normal*. Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for details about card requirements for the Fast Copy feature.
3. Re-enter the command that generated this error.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5046 Cmd Rej: SSN must be specified to update Alternate RI Mate

Commands Used: `dlt-map`

If the **mrnset** and the **mapset=dfilt** parameters are specified, then the **ssn** parameter must be specified.

Recovery

Re-enter the command and specify the **ssn** parameter. Refer to the *Commands Manual* for more information about the **mrnset** and the **mapset=dflt** parameters.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5047 Cmd Rej: Incorrect Alternate RI Mate Set specified

Commands Used: `dlt-map`, `dlt-mrn`

The value specified for the **mrnset** parameter must already be associated with a MAP Set.

Recovery

Note: The GTT LS ARI feature must be enabled before an Alternate RI Mate can be deleted from an MRN Set.

Re-enter the `dlt-map` or `dlt-mrn` command and specify values for the **mrnset** parameter that are associated with a MAP Set.

Refer to the *Commands Manual* for more information.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5051 Cmd Rej: MAPSET/MAPPC does not exist in MAP table

Commands Used: `chg-mrn`

The values specified for the **mappc** and **mapssn** parameters must already exist in the specified MAP Set.

Recovery

1. Display the MAP table.
Enter the `rtrv-map` command.
2. Add the MAPSET/MAPPC to the MAP table.
Enter the `ent-map` command. Refer to the *Commands Manual* for detailed information about the use of these commands.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5052 Cmd Rej: MAPSET/MAPPC does not exist in MAP table

Commands Used: `chg-mrn`

The values specified for the **mapset** and **mappc** parameters must already exist in the MAP table.

Recovery

1. Display the MAP table.
Enter the `rtrv-map` command.
2. Add the **mapset** and **mappc** parameters to the MAP table.
Enter the `ent-map` command. Refer to the *Commands Manual* for detailed information about the use of these commands.
3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5053 Cmd Rej: RSLs8 is only valid for ANSI link sets

Commands Used: `chg-lsopts`

An ANSI linkset must be specified by the **lsn** parameter before the **rsls8=yes** parameter can be specified.

Recovery

Re-enter the command specifying an ANSI linkset in the **lsn** parameter. Refer to the *Commands Manual* for more information.

E5054 Cmd Rej: PKG and PKGV must not be specified together

Commands Used: `chg-sccp-msg`

The **tcappkg** and **tcappkgv** parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the **tcappkg** or the **tcappkgv** parameter, but not both.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5055 Cmd Rej: Flexible GTT Load Sharing feature must be enabled

Commands Used: `enable-ctrl-feat`

The Flexible GTT Load Sharing feature must be enabled before the GTT LS ARI feature can be enabled.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the Flexible GTT Load Sharing feature is not shown in the output, then the feature is not enabled.

2. Enable and turn on the feature. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5056 Cmd Rej: FLOBR must be ON before TOBR can be enabled

Commands Used: `enable-ctrl-feat`

The Flexible Linkset Optional Based Routing (FLOBR) feature must be turned on before the TCAP Opcode Based Routing (TOBR) feature can be enabled.

Recovery

1. Display the status of the FLOBR feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Database Manual - GTT* for assistance.
3. If the status is on, re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5058 Cmd Rej: VGTT must be ON before enabling VGTT with 16 GTT lengths

Commands Used: `enable-ctrl-feat`

The Variable Length GTT (VGTT) feature must be turned on before the Support for 16 GTT Lengths in VGTT feature can be enabled.

Recovery

1. Display the status of the VGTT feature. Enter the `rtrv-feat` command.
If the feature has a status of OFF then the feature is not turned on.
2. Turn on the feature as necessary. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5060 Cmd Rej: Flexible Linkset Optional Based Routing must be ON

Commands Used: `chg-gta`, `chg-gtttsel`, `chg-ls`, `chg-sccp-msg`, `chg-sccpopts`,
`dlt-gtttsel`, `ent-gta`, `ent-gtttsel`, `ent-ls`, `rtrv-gta`, `rtrv-gtttsel`,
`rtrv-sccp-msg`, `tst-msg`

The FLOBR feature must be turned on before the parameter can be specified. See the *Commands Manual* for a list of parameters supported with FLOBR for each command.

Recovery

1. Display the status of the FLOBR feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5061 Cmd Rej: Cannot enter lsn, selid, gttsn or cg* fields if eaglegen=yes

Commands Used: `chg-gttsel`, `dlt-gttsel`, `ent-gttsel`, `rtrv-gttsel`

If the `eaglegen=yes` parameter is specified, then the `lsn`, `selid`, `gttsn`, `cdgtasn`, `cgssn`, `cggtsn`, `cggtasn`, and `cgpcsn` parameters cannot be specified.

Recovery

Re-enter the command without specifying the `lsn`, `selid`, `gttsn`, `cdgtasn`, `cgssn`, `cggtsn`, `cggtasn`, or `cgpcsn` parameters. Refer to the *Commands Manual* for a list of valid parameters.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5062 Cmd Rej: CDGTTSN and/or CGGTTSN must be specified with LSN

Commands Used: `chg-gttsel`, `ent-gttsel`, `rtrv-gttsel`

If the `lsn` parameter is specified, then the `cdgttsn` or `cggtsn` parameter must be specified.

Recovery

Re-enter the command and specify the `cdgttsn` or the `cggtsn` parameter with the `lsn` parameter. Refer to the *Commands Manual* for more information.

If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5063 Cmd Rej: OBSR must be enabled or FLOBR must be ON

Commands Used: `chg-gta`, `chg-gttsel`, `dlt-gttsel`, `ent-gta`, `ent-gttsel`, `rtrv-gttsel`

The OBSR feature must be enabled or the FLOBR feature must be turned on before the `cgselid` parameter can be specified. The OBSR or FLOBR feature must be turned on before the `selid` parameter can be specified.

Recovery

1. Display the status of the controlled features using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, enable or turn on the feature. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5064 Cmd Rej: CDGTASN/CGGTASN/CGPCSN are not valid when FLOBR ON

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

If the FLOBR feature is turned on, then the `cdgtasn`, `cggtasn`, and `cgpcsn` parameters cannot be specified.

Recovery

Re-enter the command without specifying the `cdgtasn`, `cggtasn`, and `cgpcsn` parameters. Refer to the *Commands Manual* for a list of valid parameters.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5072 Cmd Rej: PC has no allowed route

Commands Used: `ent-cspc`

A routeset and link that provides a path to the new CSPC must be configured before the `ent-cspc` command can be entered.

Recovery

1. Verify that the routeset and link path for the new Concerned Signaling Point Code have been configured. Enter the `rtrv-cspc` command.
2. Configure the routeset and link as needed. Refer to the *Point Code Formats and Conversion* section in Appendix A of the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5073 Cmd Rej: Linkset referenced by GTT selector table

Commands Used: `dlt-ls`

If the linkset is referenced by the GTT selector table, then this command cannot be entered.

Recovery

Find the entry referenced by the GTT selector table by entering `rtrv-gttsel:lsn=(linkset name)` and determine whether it is needed.

If it is not needed, follow the procedure for removing a GTT selector entry in the *Database Administration Manual - Global Title Translation* and then re-enter the `dlt-ls` command.

E5074 Cmd Rej: ITU destination does not support ANSI/ITU alias combination

Commands Used: `chg-dstn`, `ent-dstn`

If the **dpci** parameter is specified, then a combination of ITUI and ANSI aliases cannot be specified.
If the **dpcn** parameter is specified, then a combination of ITUN and ANSI aliases cannot be specified.

Recovery

Re-enter the command and specify the **dpci** or **dpcn** parameter without specifying the ANSI/ITU alias combination. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5080 Cmd Rej: OPTSN or CGSELID/CDSELID is not valid

Commands Used: `chg-gta`

A value of **none** must be specified for the **optsn**, **cgselid**, or **cdselid** parameter before the parameter can be changed to another value.

Recovery

Re-enter the command and specify a value of **none** for the **optsn**, **cgselid**, or **cdselid** parameter. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5081 Cmd Rej: IS41SMSCGTTSN can not be none, if DEFIS41SMSC is not none.

Commands Used: `chg-gsmsmsopts`

If the **defis41smsc** parameter has a value other than **none**, then the **is41smscgtsn=none** parameter cannot be specified.

Recovery

Re-enter the command specifying an acceptable parameter combination. Refer to the *Commands Manual* and to the *Feature Manual - IS41 GSM Migration* for assistance.

E5082 Cmd Rej: GTT LS ARI feature must be turned OFF

Commands Used: `chg-ctrl-feat`

The GTT LS ARI feature must be turned off before the IGTTLS feature can be turned off.

Recovery

1. Display the status of the GTT LS ARI feature using the `rtrv-ctrl-feat` command.
2. If the status is on, turn the feature off. Refer to the *Commands Manual* for assistance.
3. If the status is off, or not showing, re-enter the command that generated this error message.
4. Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5083 Cmd Rej: MAPPC can't be TPC or Mate of TPC

Commands Used: `chg-mrn`

The value specified for the **mappc** parameter cannot match an existing STP point code.

Recovery

1. Display the point codes for the **mappc** parameter. Enter the `rtrv-mrn` command. Refer to the *Commands Manual* for a detailed description of point code formats, rules for specification, and examples.
2. Re-enter the command, and specify a point code value that is not shown in the output of Step 1.
3. If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5084 Cmd Rej: To provision Alternate RI Mate, specify MRNPC

Commands Used: `chg-map`

If the **mrnset** parameter is specified, then the **mrnpc**, **mrnpca**, **mrnpci**, **mrnpcn**, or **mrnpc24** parameter must be specified.

Recovery

Re-enter the `chg-map` command and specify one of these parameters: **mrnpc**, **mrnpca**, **mrnpci**, **mrnpcn**, or **mrnpc24**. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5085 Cmd Rej: To provision Alternate RI Mate, specify MAPPC/MAPSSN

Commands Used: `chg-mrn`

The **mappc** and **mapssn** parameters must be specified together in the command.

Recovery

Re-enter the `chg-mrn` command, and specify both the **mappc** and **mapssn** parameters in the command. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5087 Cmd Rej: ESWT, GRPWT and THR can not be specified with ARI Mate PC

Commands Used: `chg-map`

If the **eswt**, **grpwt**, or **thr** parameter is specified, then the **mrnpc** parameter cannot be specified.

Recovery

Perform one of the following actions:

- Re-enter the `chg-map` command, specifying the **eswt**, **grpwt**, or **thr** parameter, and not the **mrnpc** parameter.
- OR
- Re-enter the `chg-map` command, specifying the **mrnpc** parameter, and not the **eswt**, **grpwt**, or **thr** parameters.

E5088 Cmd Rej: ARI Mate can't be provisioned for a MAPSET having TPC

Commands Used: `chg-map`, `ent-map`

The **mrnset** parameter cannot be specified if the MAP Set specified by the **mapset** parameter contains a True Point Code.

Recovery

Re-enter the command that generated this error message, and do not specify the **mrnset** parameter. Refer to the *Commands Manual* for a detailed description of point code formats, rules for specification, and examples.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5089 Cmd Rej: ISLSRSB value must be < 6 when RSLs8 is no

Commands Used: `chg-ls`, `ent-ls`

The `rsls8=yes` parameter (see the `chg-lsopts` command) must be specified for an ANSI linkset before a value greater than 5 can be specified for the `islsrsb` parameter.

Recovery

Re-enter the command specifying the `rsls8=yes` parameter if the value is greater than 5. Refer to the *Commands Manual* for more information.

E5090 Cmd Rej: RSLs8 is valid only if ISLSBR Feature is enabled

Commands Used: `chg-lsopts`

The ISLSBR feature must be enabled before the `rsls8` parameter can be specified.

Recovery

1. Verify that the ISLSBR feature is enabled. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, the feature is not enabled.
2. Enable the ISLSBR feature. Refer to the *Commands Manual* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5091 Cmd Rej: TIF Number Substitution feature must be enabled

Commands Used: `chg-tifopts`, `chg-npp-srs`, `ent-npp-srs`

The TIF Number Substitution feature must be enabled before an AS containing the `nscgpn` or `nscdpn` SA can be specified.

The TIF Number Substitution feature must be enabled before the `nsaddldata` or `nspublic` parameters can be specified.

Recovery

1. Display the status of the enabled features. Enter the `rtrv-ctrl-feat` command.
If the TIF Number Substitution feature is not shown in the output, then the feature is not enabled.
2. Enable the TIF Number Substitution feature. Refer to the *Feature Manual - TIF* for assistance.
3. Re-enter the command. If the error appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5092 Cmd Rej: NSCgPN and SNSCgPN SAs are mutually exclusive

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The AS specified by the `asn` parameter cannot contain both the `nscgpn` and `snschgpn` SAs.

Recovery

Re-enter the command and specify either the `nscgpn` or the `snschgpn` service action, but not both. Refer to the *Commands Manual* for more information.

E5093 Cmd Rej: TIF NS feature cannot be enabled unless MATCHSEQ is DN

Commands Used: `chg-ctrl-feat`

The `matchseq=dn` parameter must be specified (see the `chg-tifopts` command) before the TIF Number Substitution feature can be enabled.

Recovery

1. Use the `chg-tifopts` command to specify the `matchseq=dn` parameter. Refer to the *Commands Manual* if needed.
2. Re-enter the command that generated this error message.

If the error appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5094 Cmd Rej: MATCHSEQ cannot be NPTYPE, if TIF NS Feature is Enabled

Commands Used: `chg-tifopts`

If the TIF Number Substitution feature is enabled, then the `matchseq=nptype` parameter cannot be specified.

Recovery

Re-enter the command and specify a value other than `nptype` for the `matchseq` parameter. Refer to the *Commands Manual* for list of valid values for the parameter.

E5095 Cmd Rej: SCCP and CNCF cannot be in the same action set

Commands Used: `chg-gws-actset`

The `sccp` and `cncf` stop actions cannot exist in the same Action Set.

Recovery

1. Determine the stop actions contained in the Action Set. Enter the `rtrv-gws-actset` command.
2. If the Action Set contains the `sccp` or `cncf` stop action, then that stop action must be deleted before the other stop action can be added to the Action Set, or the stop action must be added to a different Action Set. Refer to the *Database Administration Manual - Gateway Screening* for assistance.
3. Re-enter the command that caused this error message. If the error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5096 Cmd Rej: Origin Based SCCP Routing feature must be ON.

Commands Used: `chg-ls`, `chg-sccpopts`, `ent-ls`

The Origin-based SCCP Routing feature must be turned on before the `gttmode` or `dflgttmode` parameter can have a value of `acdc`, `cgacdc`, `acdcg`, `acdcg`, `cgcd`, `cdcg`, or `cg`.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but is not turned on.
2. Enable and turn on the feature. Refer to the *Database Administration Manual - GTT* for assistance.
3. Re-enter the command that generated this error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5097 Cmd Rej: RNP and RNPV must not be specified together

Commands Used: `chg-ainpopts`

The `rnp` and `rnpv` parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the `rnp` or `rnpv` parameter. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.

E5098 Cmd Rej: RNAI and RNAIV must not be specified together

Commands Used: `chg-ainpopts`

The `rnai` and `rnaiv` parameters cannot be specified together in the command.

Recovery

Re-enter the command specifying either the `rnai` or `rnaiv` parameter. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.

E5099 Cmd Rej: TCAP Opcode Based Routing feature must be turned ON

Commands Used: `chg-gta`, `chg-sccp-msg`, `dlt-gta`, `enable-ctrl-feat`, `ent-gta`, `ent-gttset`, `rtrv-gta`, `rtrv-gttset`

`chg/dlt/ent/rtrv-gta`: The TOBR feature must be turned on before the `cdssn` or `ecdssn` parameter can be specified.

`chg-sccp-msg`: A TOBR quantity feature must be turned on before the `tcapacn`, `tcappkg`, `tcappkgv`, `tcapopcode`, or `tcapfamily` parameter can be specified.

`enable-ctrl-feat`: The TOBR feature must be turned on before any of the TOBR Quantity features can be enabled.

`ent/rtrv-gttset`: The TOBR feature must be turned on before a value of `cdssn` or `opcode` can be specified for the `settype` parameter.

Recovery

1. Display the status of the TOBR feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5100 Cmd Rej: Larger Opcode Quantity FAK should be provided

Commands Used: `enable-ctrl-feat`

A TOBR quantity feature cannot be enabled if a higher quantity level TOBR quantity feature is enabled.

Recovery

1. Determine the quantity level that is already entered into the system. Enter the `rtrv-ctrl-feat` command.
2. Verify the part number and quantity associated with the FAK that was entered. If it is smaller than what is in the system, no further action is necessary.
3. Re-enter the command, specifying the part number associated with a larger quantity. Refer to the *Commands Manual* for more information, or the *Database Administration Manual - Global Title Translation* for assistance with FAKs.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5101 Cmd Rej: Maximum Opcode Quantity FAK already enabled

Commands Used: `enable-ctrl-feat`

If the TOBR quantity feature of maximum quantity level is enabled, then no other TOBR Quantity feature can be enabled.

Recovery

No recovery required. The maximum OPCode quantity is already enabled.

E5102 Cmd Rej: PC/PCA/PCI/PCN must be specified if SSN is specified

Commands Used: `chg-ppsopts`

If the `ssn` parameter is specified, then the `pc/pca/pci/pcn` parameter must be specified.

Recovery

Re-enter the command and specify the `pc/pca/pci/pcn` parameter with the `ssn` parameter. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5103 Cmd Rej: OPTSN set domain must be the same as GTTSN set domain

Commands Used: `chg-gta`, `ent-gta`

The SCCP Conversion feature must be enabled before the GTT set specified by the `optsn` parameter can have a different domain than the GTT set specified by the `gttsn` parameter.

Recovery

Verify the domains of the gttsets being used and either turn on the sccp conversion or use settypes that belong to the same domain. Refer to the *Database Administration Manual - Global Title Translation* for assistance.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5104 Cmd Rej: DIALPFX must be specified

Commands Used: `chg-ainpopts`

If the `ndialpfx` or `dltpfx` parameter is specified, then the `dialpfx` parameter must be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5105 Cmd Rej: One of the TOBR quantity feature must be ON

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

A TOBR quantity feature must be turned on before the **opcode**, **pkgtype**, **acn**, or **family** parameter can be specified.

Recovery

1. Display the status of the TOBR quantity feature using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, turn on the feature. Refer to the *Commands Manual* for assistance.
3. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5106 Cmd Rej: OPCODE,PKGTYPE,ACN/FAMILY must be specified together

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

The **opcode**, **pkgtype**, and **family** parameters must be specified together for ANSI TCAP translations. The **opcode**, **pkgtype**, and **acn** parameters must be specified together for ITU TCAP translations.

Recovery

Re-enter the command that generated this error message, and specify the correct parameters for the ANSI TCAP or ITU TCAP translations. Refer to the *Commands Manual* for assistance.

E5107 Cmd Rej: OPCODE param must be specified if GTTSN settype is OPCODE

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`

If the GTT set specified by the **gttsn** parameter has a set type of **opcode** (see the `ent-gttset` command), then the **opcode/acn/pkgtype** or **opcode/family/pkgtype** parameters must be specified. These parameters cannot be specified for GTT sets of any other set types.

Recovery

Re-enter the command with a valid set of parameters. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5108 Cmd Rej: CDSSN param must be specified if GTTSN settype is CDSSN

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`

If the GTT set specified by the `gttsn` parameter has a set type of `cdssn` (see the `ent-gttset` command), then the `cdssn` parameter must be specified. This parameter cannot be specified for GTT sets with other set types.

Recovery

Re-enter the command and specify the `cdssn` parameter. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5109 Cmd Rej: Exceeding TOBR Quantity feature OPCODE translations limit

Commands Used: `ent-gta`

The maximum number of OPCODE translation entries cannot exceed the value that is set by the associated TOBR quantity feature.

Recovery

- Delete an entry that is not being used,

OR

- enter in a larger TOBR quantity FAK (if available).

Refer to the *Database Administration Manual - Global Title Translation* for more information.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5110 Cmd Rej: OPCSN is invalid when GTTSN set type is `cggtta/cgssn/cgpc`

Commands Used: `chg-gta`

The GTT set specified by the `gttsn` parameter must have a set type of `cdgta`, `opcode`, or `cdssn` (see the `ent-gttset` command) before the `opcsn` parameter can be specified.

Recovery

Re-enter the command and specify the appropriate set type. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5111 Cmd Rej: The GTTSN set type must not be same as OPTSN set type

Commands Used: `chg-gta`, `ent-gta`

The GTT set specified by the **gttsn** parameter cannot have the same set type (see the `ent-gttset` command) as the GTT set specified by the **optsn** parameter.

Recovery

Re-enter the command, specifying a different set type for the **gttsn** parameter. Refer to the *Commands Manual* for assistance.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5115 Cmd Rej: MO-based IS41 SMS NP must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`, `chg-is41smsopts`

The MO-based IS41 SMS NP feature must be enabled before an AS containing the **cdpnp** SA can be specified as a value for the **asn** parameter with the MOSMSICDPN service.

For the `chg-is41smsopts` command, the MO-based IS41 SMS NP feature must be enabled before the **mosmstype**, **defrn**, or **spfill** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but it not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* and to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5116 Cmd Rej: MO-based GSM SMS NP must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`, `chg-gsmsmsopts`

The MO-based GSM SMS NP feature must be enabled before an AS containing the **cdpnp** SA can be specified as a value for the **asn** parameter with the MOSMSGCDPN service.

For the `chg-gsmsmsopts` command, the MO-based GSM SMS NP feature must be enabled before the `mosmstype`, `defrn`, or `spfill` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command and the `rtrv-feat` command
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but it not turned on.
2. Enable and turn on the feature. Refer to the *Commands Manual* and to the *Feature Manual - MO SMS* for assistance
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5117 Cmd Rej: ALW option invalid for IPSG-M3UA associations

Commands Used: `chg-assoc`

If the value specified for the `aname` parameter refers to an M3UA association on an IPSG card, then the `alw` parameter cannot be specified.

Recovery

1. Verify the value specified for the `aname` parameter.
2. Re-enter the `chg-assoc` command without specifying the `alw` parameter. Refer to the *Commands Manual* for more information about parameter inclusion rules.
3. If this error message appears again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5118 Cmd Rej: MO SMS GSM NP, PPSMS or MO SMS ASD/GRN must be enabled

Commands Used: `chg-gsmsmsopts`

The MO SMS ASD, MO SMS GRN, MO-based GSM SMS NP, or Prepaid SMS Intercept Ph feature must be enabled before the `mosmsaclen`, `mosmsnai`, or `mosmssa` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled.
2. Enable and turn on the feature. Refer to the *Feature Manual - MO SMS* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5121 Cmd Rej: CdPA/CgPA GTT Selector already exists

Commands Used: `ent-gttset`

An entry cannot already exist that matches the **eaglegen**, **gti**, **tt**, and **np(v)** and **nai(v)** parameter combination for the specified CdPA and/or CgPA selector.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttset` command specifying the **eaglegen**, **gti**, **tt**, and **np(v)** and **nai(v)** parameter combination.
2. Re-enter the `ent-gttset` command specifying a different range of values for the parameter combination.

E5122 Cmd Rej: CdPA/CgPA GTT Selector does not exist

Commands Used: `chg-gttset`, `dlt-gttset`

The GTT selector specified by the **gti(x)**, **tt**, and **np(v)** and **nai(v)** parameters must already exist.

Recovery

1. Display the GTT Selector table.
Enter the `rtrv-gttset` command.
2. Re-enter the command specifying a parameter combination that exists in the database.

E5123 Cmd Rej: Domain indicated by GTIx must match that of linkset

Commands Used: `chg-gttset`, `ent-gttset`

The domain specified by the **gti(x)** parameter must match the domain of the linkset specified by the **lsn** parameter.

Recovery

1. Display the linksets in the database.
Enter the `rtrv-ls` command specifying no parameters.
2. Re-enter the command using a linkset name that belongs to the same domain as the **gti(x)** parameter.

E5124 Cmd Rej: SCCP Conversion and FLOBR features must be ON

Commands Used: `chg-gta`, `ent-gta`

The SCCP Conversion feature must be enabled and the FLOBR feature must be turned on before the `cgcnvsn` parameter can be specified.

Recovery

1. Display the status of the SCCP Conversion and the FLOBR features using the `rtrv-ctrl-feat` command.
2. If the status is off, or not showing, enable and turn on the feature. Refer to the *Database Administration Manual - Global Title Translation* for assistance.
3. Re-enter the command that generated this error message.
4. Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5125 Cmd Rej: Feature is not supported

Commands Used: `chg-feat`

As of Release 41.0, the X.25/SS7 (X25G) feature is not supported.

Recovery

Support for the X.25 protocol is discontinued. All commands and parameters that support the X.25 protocol are obsolete as of Release 41.0. For more information, refer to the *Commands Manual* for the 41.0 documentation set.

E5127 Cmd Rej: CGCNVSN is invalid when GTTSET type is not cgdta/cdgtta

Commands Used: `chg-gta`, `ent-gta`

The GTT set specified by the `gttsn` parameter must have a set type of `cdgta` or `cgdta` (see the `ent-gttset` command) before the `cgcnvsn` parameter can be specified.

Recovery

Re-enter the command and specify a set type of `cdgta` or `cgdta`. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5128 Cmd Rej: CGGTASN, CGPCSN and CGGTTSN are mutually exclusive

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The `cggtasn`, `cgpcsn`, and `cggtsn` parameters cannot be specified together in the command.

Recovery

Re-enter the command, specifying only one of the above parameters. Refer to the *Commands Manual* for more information.

If this error message occurs again, call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E5129 Cmd Rej: GTTSN, CDGTASN and CDGTTSN are mutually exclusive

Commands Used: `chg-gtttsel`, `ent-gtttsel`, `rtrv-gtttsel`

The **gttsn**, **cdgtasn**, and **cdgttsn** parameters cannot be specified together in the command.

Recovery

Re-enter the command, specifying only one of the above parameters. Refer to the *Commands Manual* for more information.

Call the Customer Care Center if this error message occurs again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5130 Cmd Rej: CGSSN must not be specified with GTTSN, CDGTTSN or CDGTASN

Commands Used: `chg-gtttsel`, `ent-gtttsel`, `rtrv-gtttsel`

If the **gttsn**, **cdgttsn**, or **cdgtasn** parameter is specified, then the **cgssn** parameter cannot be specified. For `chg/ent-gtttsel`, if the **cggtasn**, **cgpcsn** or **cggttsn** parameter is specified, then the **cgssn** parameter must be specified.

Recovery

- Re-enter the command with a valid set of parameters. Refer to the *Commands Manual* for more information.
- If this error message occurs again, call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E5131 Cmd Rej: SELID must not be specified with GTTSN or CDGTASN

Commands Used: `chg-gtttsel`, `ent-gtttsel`, `rtrv-gtttsel`

If the **gttsn** or **cdgtasn** parameter is specified, then the **selid** parameter cannot be specified.

Recovery

- Re-enter the command without specifying the **selid** parameter. Refer to the *Commands Manual* for more information about the **gttsn** and **cdgtasn** parameters.
- If this error message occurs again, call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E5132 Cmd Rej: Invalid parameter(s) specified with NP=DFLT and NAI=DFLT

Commands Used: `chg-gtttsel`, `dlt-gtttsel`, `rtrv-gtttsel`

If the `np=dflt` or `nai=dflt` parameter is specified, then the `cggtasn`, `cggttsn`, `cgpcsn`, `cgssn`, `eaglegen`, `lsn`, and `selid` parameters cannot be specified.

Recovery

- Re-enter the command without specifying the `cggtasn`, `cggttsn`, `cgpcsn`, `cgssn`, `eaglegen`, `lsn`, and `selid` parameters. Refer to the *Commands Manual* for assistance.
- If this error message occurs again, call the Customer Care Center for further assistance. See the "Customer Care Center" section in Chapter 1 of this manual.

E5133 Cmd Rej: Interchanging IPLIMx/IPGWx Assoc to IPSP Assoc not supported

Commands Used: `chg-assoc`

The value specified for the `lhost` parameter cannot change the local host for the association from an IPLIMx or IPGWx card to an IPSP card or from an IPSP card to an IPLIMx or IPGWx card.

Recovery

Re-enter the `chg-assoc` command and specify values for the `lhost` parameter that do not interchange IPLIMx or IPGWx associations to IPSP associations.

Refer to the *Commands Manual* for detailed information about the use of this command and allowed association names.

Call your Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5134 Cmd Rej: DV, NDV, SERV, or NSERV would create invalid SERV and DV

Commands Used: `chg-lnp-serv`

The values of `serv`, `dv`, `nserv`, or `ndv` would create a server with an invalid dv. Check the existing service (`serv`) and dv against the requested `nserv` or `ndv`.

Recovery

Check the existing service and DV against the requested NSERV or NDV. Refer to the *Commands Manual* for more information about this command and associated parameters, and refer to the *LNP Feature Activation Guide* for procedures to change an LNP service.

E5135 Cmd Rej: Primary remote hostname required before alternate

Commands Used: `chg-assoc`

The **rhosttype=primary** parameter must be specified before the **rhosttype=alternate** parameter can be specified.

Recovery

Re-enter the command, specifying the primary remote hostname before the alternate remote hostname. Refer to the *Commands Manual* for assistance.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5136 Cmd Rej: Remote hostname required with rhosttype

Commands Used: `chg-assoc`

If the **rhosttype** parameter is specified, then the **rhost** parameter must be specified.

Recovery

Re-enter the command, and add a value for the **rhost** parameter. Refer to the *Commands Manual* for more information.

E5137 Cmd Rej: Arhost value must not match lhost/alhost/rhost

Commands Used: `chg-assoc`

The value specified for the alternate remote host cannot be the same as the value specified for the **lhost**, **alhost**, or **rhost** parameter in the same association.

Recovery

Re-enter the command, specifying a different value for the alternate remote host. Refer to the *Commands Manual* for assistance.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5138 Cmd Rej: Rhost value must not match lhost/alhost/arhost

Commands Used: `chg-assoc`

The value specified for the **rhost** parameter cannot be the same as the value specified for the alternate remote host or for the **lhost** or **alhost** parameter in the same association.

Recovery

Re-enter the command, specifying a different value for the **rhost** parameter. Refer to the *Commands Manual* for assistance.

Call the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5139 Cmd Rej: CGCNVSN Gttset name cannot be same as GTTSN Gttset name

Commands Used: `chg-gta`, `ent-gta`

The value specified for the **gttsn** parameter cannot be the same as the value specified for the **cgcnvsn** parameter.

Recovery

Re-enter the command, specifying a different value for the **gttsn** parameter.

E5140 Cmd Rej: FAMILY parameter is allowed with ANSI TCAP PKGTYPE

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

If the **family** parameter is specified, then a value of **ansiuni**, **qwp**, **qwop**, **resp**, **cwp**, **cwop**, **ansiabort**, or **any** must be specified for the **pkgtype** parameter.

Recovery

Re-enter the command and specify the appropriate value for the **pkgtype** parameter. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5141 Cmd Rej: ACN parameter is allowed with ITU TCAP PKGTYPE

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

If the **acn** parameter is specified, then a value of **bgn**, **ituabort**, **ituuni**, **any**, **end**, or **cnt** must be specified for the **pkgtype** parameter.

Recovery

Re-enter the command and specify the appropriate value for the **pkgtype** parameter. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5143 Cmd Rej: GTT Set specified by OPTSN/OPCSN/CGCNVSN does not exist

Commands Used: chg-gta, ent-gta

The GTT set name specified in the **optsn**, **opcsn**, or **cgcnvsn** parameters must match an existing GTT set name.

Recovery

1. Display the existing GTT set information. Enter the `rtrv-gttset` command.
2. Re-enter the command and specify a parameter set name that exists in the database.

E5144 Cmd Rej: PKGTYPE abort requires ACN/FAMILY/OPCODE value none

Commands Used: chg-gta, dlt-gta, ent-gta, rtrv-gta

If the **pkgtype=ituabort** parameter is specified, then a value of **none** must be specified for the **acn** and **opcode** parameters.

If the **pkgtype=ansiabort** parameter is specified then a value of **none** must be specified for the **family** and **opcode** parameters.

Recovery

Re-enter the command and specify a value of **none** for the **acn/family** and **opcode** parameters. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5147 Cmd Rej: OPC/CGPC/CDPC Network Domain must match

Commands Used: tst-msg

The network domain of the values specified for the OPC, CGPA PC and CDPA PC must match.

Recovery

1. Verify the point code values for the **msgn** that was used for the test message. Enter `rtrv-sccp-msg`.
2. Change the values to be the same domain as those specified for the OPC, CGPA PC and CDPA PC.

E5148 Cmd Rej: Both FAMILY and OPCODE must be NONE if either is NONE

Commands Used: ent-gta

If the **family** and **opcode** parameters are specified in the command, then either both parameters must have a value of **none** or neither parameter can have a value of **none**.

Recovery

Re-enter the command and specify a value of **none** for both parameter. Refer to the *Commands Manual* for assistance.

If this error message appears again, contact your Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5149 Cmd Rej: Invalid table entry, can not be repaired by conversion code

Commands Used: act-upgrade

The **icdpnunknx** and **icdpnunknX** and the **gcdpnunknx** and **gcdpnunknX** NPP Action Sets cannot co-exist in the source release.

Recovery

1. Determine which NPP Action Sets are necessary. Re-enter the command and specify either the **icdpnunknx** and **icdpnunknX** or the **gcdpnunknx** and **gcdpnunknX** Action Sets, but not both. Refer to the *Commands Manual* for more information.
2. If this error message occurs again, contact the Customer Care Center. See the "Customer Care Center" section in Chapter 1 of this manual.

E5150 Cmd Rej: Info Analyzed Relay Base feature must be enabled

Commands Used: enable-ctrl-feat, chg-tatr-msg, chg-tatropts, tst-msg

The IAR Base feature must be enabled before the **chg-tatr-msg** or **chg-tatropts** command can be entered.

For the **enable-ctrl-feat** command, the feature must be enabled before the IAR ASD, IAR GRN, or IAR NP feature can be enabled.

For the **tst-msg** command, the feature must be enabled before the **feat=iar** parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the **rtrv-ctrl-feat** command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.

2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5152 Cmd Rej: Info Analyzed Relay NP feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The IAR NP feature must be enabled before an AS containing the `cdpnp` or `cgpnp` SA can be specified as a value for the `asn` parameter with the IARCDPN or IARCGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5153 Cmd Rej: Info Analyzed Relay ASD feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The IAR ASD feature must be enabled before an AS containing the `asdlkup` or `cgpnasdrqd` SA can be specified as a value for the `asn` parameter with the IARCDPN or IARCGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5154 Cmd Rej: Info Analyzed Relay GRN feature must be enabled

Commands Used: `chg-npp-srs`, `ent-npp-srs`

The IAR GRN feature must be enabled before an AS containing the `grnlkup` or `cgpngnrnrd` SA can be specified as a value for the `asn` parameter with the IARCDPN or IARCGPN service.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5156 Cmd Rej: IAR NP and Service Portability features must be enabled

Commands Used: `chg-tatropts`

The IAR NP and Service Portability features must be enabled before the `sporttype` parameter can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the features. Refer to the *Commands Manual* and to the *Feature Manual - IDP and Analyzed Information Features* for more information.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5157 Cmd Rej: DIALPFX must not be NONE

Commands Used: `chg-ainpopts`

The `dialpfx=none` parameter cannot be specified.

Recovery

Re-enter the command specifying a value other than **none** for the **dialpfx** parameter. Refer to the *Commands Manual* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5160 Cmd Rej: DIALNAI and SNAI must be specified together

Commands Used: `chg-ainpopts`

The **dialnai** and **snai** parameters must be specified together in the command.

Recovery

Re-enter the command specifying the **dialnai** and **snai** parameters. Refer to the *Commands Manual* for assistance.

E5163 Cmd Rej: RFMT with NEC and NEC=NONE combination not allowed

Commands Used: `chg-ainpopts`

If the **neq=none** parameter is specified, then values of **asdrnecdn**, **masdnecdn**, **rnecdn**, **rngrnecdn**, and **grnrnecdn** cannot be specified for the **rfmt** parameter.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* and the *Feature Manual - INP/AINPQ* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5164 Cmd Rej: NDIALPFX already exists in AINPOPTS Table

Commands Used: `chg-ainpopts`

The value specified for the **ndialpfx** parameter cannot already exist in the AINPOPTS table.

Recovery

1. Verify whether the value specified for the **ndialpfx** parameter already exists. Enter the `rtrv-ainpopts` command.
2. If the value exists, either:
 - Re-enter the command specifying a different value for the **ndialpfx** parameter
 - Change the existing value in the AINPOPTS table. Enter the `chg-ainpopts` command. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.
3. Re-enter the command that generated this error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5165 Cmd Rej: DIALPFX doesn't exist in AINPOPTS Table

Commands Used: `chg-ainpopts`

If the `ndialpfx` and `dialpfx` parameters are specified, then the value specified for the `dialpfx` parameter must already exist in the AINPOPTS table.

Recovery

1. Verify the value for the `dialpfx` parameter. Enter the `rtrv-ainpopts` command.
2. If the value for the `dialpfx` parameter does not exist, then enter the value using the `chg-ainpopts` command. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.
3. After changing the value of the `dialpfx` parameter, or if the `rtrv-ainpopts` command displays the value of interest, re-enter the command that generated the error message.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5166 Cmd Rej: Maximum number of DIALPFXs already provisioned

Commands Used: `chg-ainpopts`

A maximum of 40 Dialed Party Number Prefix values is allowed.

Recovery

Verify the number of prefixes in the database. Enter the `rtrv-ainpopts` command.

- If the number of prefixes is less than 40, then re-enter the command that generated this error message.
- If the number of prefixes is 40, then change one of the existing prefixes. Enter the `chg-ainpopts` command.

Refer to the *Commands Manual* and the *Feature Manual - INP/AINPQ* for more information.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5167 Cmd Rej: DIALNAI doesn't exist in AINPOPTS Table

Commands Used: `chg-ainpopts`

If the `snai=none` parameter is specified, then the value specified for the `dialnai` parameter must already exist in the AINPOPTS table.

Recovery

1. Verify the value for the **dialnai** parameter. Enter the `rtrv-ainpopts` command.
2. If the value for the **dialnai** parameter does not exist, then enter the value. Enter the **chg-ainpopts** command. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.
3. After changing the value of the **dialnai** parameter, or if the `rtrv-ainpopts` command displays the value of interest, re-enter the command that generated the error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5168 Cmd Rej: Maximum number of DIALNAIs already provisioned

Commands Used: `chg-ainpopts`

A maximum of 2 Dialed Party Number Nature of Address values is allowed.

Recovery

Verify the number of Dialed Party Number Nature of Address values in the database. Enter the `rtrv-ainpopts` command.

- If the number of values is less than 2, then re-enter the command that generated this error message.
- If the number of values is 2, then change one of the existing values. Enter the `chg-ainpopts` command.

Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for assistance.

E5169 Cmd Rej: DLTPFX must not be specified, when NDIALPFX is NONE

Commands Used: `chg-ainpopts`

If the **ndialpfx=none** parameter is specified, then the **dltpfx** parameter cannot be specified.

Recovery

Re-enter the command specifying a valid combination of parameters. Refer to the *Commands Manual* for assistance.

Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5171 Cmd Rej: NONE in SPORTRELAY/RLS is compatible w/ NPTYPE in MATCHSEQ

Commands Used: `chg-tifopts`

If the **matchseq=nptype** parameter is specified, then the only value that can be specified for the **sportrelay** or **sportrls** parameter is **none**. If the **sportrelay** or **sportrls** parameter has a value other than **none**, then the **matchseq=nptype** parameter cannot be specified.

Recovery

1. Verify the values for the **matchseq**, **sportrelay**, and **sportrls** parameters. Enter the `rtrv-tifopts` command.
2. Re-enter the command that generated this error message specifying a valid parameter combination. Refer to the *Commands Manual* for assistance.
3. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5174 Cmd Rej: MTP routed GWS Stop Action feature must be enabled

Commands Used: `chg-gws-actset`

The MTP Routed GWS Stop Action feature must be enabled before the **sccp** stop action can be specified.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command. If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Database Administration Manual - Gateway Screening* for assistance.
3. Re-enter the command that generated this error message. Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5184 Cmd Rej: IMT Rate Change sequence is in progress

Commands Used: `alw-imt`, `chg-ctrl-feat`, `disc-imt`, `flash-card`, `inh-imt`, `init-card`, `init-flash`, `init-mux`, `init-sys`, `tst-imt`

If the IMT Rate Change sequence is in progress, then certain commands are affected. [Table 34: Command Interaction with IMT Rate Change Sequence](#) describes the interaction between various commands and the IMT Rate Change Sequence.

Table 34: Command Interaction with IMT Rate Change Sequence

Commands	If the IMT Rate Change Sequence is in Progress:
<code>alw-imt</code> , <code>disc-imt</code> , <code>flash-card</code> , <code>inh-imt</code> , <code>init-card</code> , <code>init-flash</code> , <code>init-mux</code> , <code>init-sys</code>	These commands cannot be entered.

Commands	If the IMT Rate Change Sequence is in Progress:
chg-ctrl-feat	The HIPR2 High Rate Mode feature cannot be turned on or off.

Recovery

Re-enter the command after the IMT Rate Change sequence is complete.

E5194 Cmd Rej: INP feature must be enabled

Commands Used: `chg-inpopts`

The INP feature must be enabled before the `chg-inpopts` command can be entered.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled, but is not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINPQ* for more information.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

E5195 Cmd Rej: AINPQ feature must be enabled

Commands Used: `chg-ainpopts`

The AINPQ feature must be enabled before the `chg-ainpopts` command can be entered.

Recovery

1. Display the status of controlled features in the system. Enter the `rtrv-ctrl-feat` command.
If the feature is not shown in the output, then the feature is not enabled. If the feature has a status of OFF, then the feature is enabled but it not turned on.
2. Enable the feature. Refer to the *Commands Manual* and to the *Feature Manual - INP/AINP Q* for assistance.
3. Re-enter the command that generated this error message.
Contact the Customer Care Center if this error message appears again. See the "Customer Care Center" section in Chapter 1 of this manual.

Glossary

A

ANSI	<p>American National Standards Institute</p> <p>An organization that administers and coordinates the U.S. voluntary standardization and conformity assessment system. ANSI develops and publishes standards. ANSI is a non-commercial, non-government organization which is funded by more than 1000 corporations, professional bodies, and enterprises.</p>
APC	<p>Adjacent Point Code</p> <p>The point code that identifies a node adjacent to the EAGLE 5 ISS. This term is used in link sets and routes.</p>
APCA	<p>Adjacent Point Code ANSI</p>
APCI	<p>Adjacent Point Code International</p>
APCN	<p>Adjacent Point Code National</p>
A-Port	<p>ANSI-41 Mobile Number Portability</p>
ASM	<p>Application Services Module</p> <p>A card in the EAGLE 5 ISS that provides additional memory to store global translation tables and screening data used for applications such as Global Title Translation (GTT) and Gateway Screening (GWS).</p> <p>This card is obsolete as of Release 31.6. The TSM card is used.</p>

B

BLKOPC

Blocked Originating Point Code

The point code that gateway screening uses to keep MSUs coming from a specific point code out of the network where the EAGLE 5 ISS is located. This point code is in the routing label portion of the signaling information field in the MSU.

Messages that do not contain the specified originating point code go on to the next step in the gateway screening process, or are allowed into the network if the gateway screening process stops with this entity.

BPS

Bits per Second

The transmission rate of the signaling links on the EAGLE 5 ISS expressed in bits per second.

C

CLASS

Custom Local Area Signaling Service

Custom Local Area Subscriber Services

CLLI

Common Language Location Identifier

The CLLI uniquely identifies the STP in terms of its physical location. It is usually comprised of a combination of identifiers for the STP's city (or locality), state (or province), building, and traffic unit identity.

The format of the CLLI is:

The first four characters identify the city, town, or locality.

The first character of the CLLI must be an alphabetical character.

The fifth and sixth characters identify state or province.

C

The seventh and eighth characters identify the building.

The last three characters identify the traffic unit.

Cluster Routing and Management Diversity (CRMD)

See CRMD.

Command Class

A set of EAGLE 5 ISS commands that can be assigned to an EAGLE 5 ISS user or to a terminal port of the EAGLE 5 ISS. Command classes are assigned to a user to control the EAGLE 5 ISS commands that user can execute. Command classes are assigned to a terminal port to control the EAGLE 5 ISS commands that can be executed from a particular terminal.

CPC

Capability Point Code

A capability point code used by the SS7 protocol to identify a group of functionally related STPs in the signaling network.

CRMD

Cluster Routing and Management Diversity

A feature in the EAGLE 5 ISS that allows MSUs to be routed to a cluster of point codes and enhances the management of the SS7 traffic to the cluster of point codes.

CSPC

Concerned Signaling Point Code

The point code that receives subsystem allowed and subsystem prohibited status messages about a particular global title translation node. These messages are broadcast from SCCP management.

C

CSPC Group Name The name of the concerned signaling point code group that contains the point codes that should be notified of the subsystem status.

D

Database All data that can be administered by the user, including cards, destination point codes, gateway screening tables, global title translation tables, links, LNP services, LNP service providers, location routing numbers, routes, shelves, subsystem applications, and 10 digit telephone numbers.

Destination The node to which the signaling link traffic is routed. This destination is identified by a point code, either a full point code or a cluster point code.

DPC Destination Point Code
DPC refers to the scheme in SS7 signaling to identify the receiving signaling point. In the SS7 network, the point codes are numeric addresses which uniquely identify each signaling point. This point code can be adjacent to the EAGLE 5 ISS, but does not have to be.

DPCA Destination Point Code ANSI

DPCI Destination Point Code
International

DPCN Destination Point Code National

DS0 Digital Signal Level-0 (64 Kbits/sec
or 56 Kbits/sec)

D

A basic digital signaling rate of 64 Kbits/sec, corresponding to the capacity of one voice-frequency-equivalent channel.

DSM

Database Service Module.

The DSM provides large capacity SCCP/database functionality. The DSM is an application card that supports network specific functions such as EAGLE Provisioning Application Processor (EPAP), Global System for Mobile Communications (GSM), EAGLE Local Number Portability (ELAP), and interface to Local Service Management System (LSMS).

DSCS

Digital Signal Customer Service

E

E1

The European equivalent of T1 that transmits digital data over a telephone network at 2.048 Mbps.

EBI

Extended Bus Interface

A local bus and not connected to the IMT bus. This allows every two card locations to communicate with each other without going over the IMT bus.

ECM

External condition message

Message that is passed on the external condition interface.

EGMS

Enhanced GSM MAP Screening

EGTT

Enhanced Global Title Translation

E

A feature that is designed for the signaling connection control part (SCCP) of the SS7 protocol. The EAGLE 5 ISS uses this feature to determine to which service database to send the query message when a Message Signaling Unit (MSU) enters the system.

EIR

Equipment Identity Register

A network entity used in GSM networks, as defined in the 3GPP Specifications for mobile networks. The entity stores lists of International Mobile Equipment Identity (IMEI) numbers, which correspond to physical handsets (not subscribers). Use of the EIR can prevent the use of stolen handsets because the network operator can enter the IMEI of these handsets into a 'blacklist' and prevent them from being registered on the network, thus making them useless.

F

FGTTLS

Flexible GTT Loadsharing

Flexible GTT Load Sharing (FGTTLS) provides more flexible GTT load sharing arrangements for GTT traffic.

Flexible GTT Load Sharing

See FGTTLS.

FTA

File Transfer Area

A special area that exists on each OAM hard disk, used as a staging area to copy files to and from the EAGLE 5 ISS using the Kermit file-transfer protocol.

G

G

GB	Gigabyte — 1,073,741,824 bytes
G-Flex	<p>GSM Flexible numbering</p> <p>A feature that allows the operator to flexibly assign individual subscribers across multiple HLRs and route signaling messages, based on subscriber numbering, accordingly.</p>
GPL	<p>Generic Program Load</p> <p>Software that allows the various features in the system to work. GPLs and applications are not the same software.</p>
G-Port	<p>GSM Mobile Number Portability</p> <p>A feature that provides mobile subscribers the ability to change the GSM subscription network within a portability cluster, while retaining their original MSISDN(s).</p>
GSM	Global System for Mobile Communications
GTA	Global Title Address
GTT	<p>Global Title Translation</p> <p>A feature of the signaling connection control part (SCCP) of the SS7 protocol that the EAGLE 5 ISS uses to determine which service database to send the query message when an MSU enters the EAGLE 5 ISS and more information is needed to route the MSU. These service databases also verify calling card numbers and credit card numbers. The service databases are identified in the SS7 network by a point code and a subsystem number.</p>

G

GWS

Gateway Screening

Used at gateway STPs to limit access into the network to authorized users. A gateway STP performs inter-network routing and gateway screening functions. GWS controls access to nonhome SS7 networks. Only an MSU that matches predefined criteria in the EAGLE 5 ISS's database is allowed to enter the EAGLE 5 ISS.

H

HMUX

High-Speed Multiplexer

A card that supports the requirements for up to 1500 links, allowing communication on IMT buses between cards, shelves and frames. HMUX cards interface to 16 serial links, creating a ring from a series of point to point links. Each HMUX card provides a bypass multiplexer to maintain the ring's integrity as cards are removed and inserted into an operational shelf.

High-Speed IMT Multiplexer, a replacement card for the IPMX.

I

ID

Identity, identifier

IGM

IS41 GSM Migration

IGTTLS

Intermediate Global Title Translation Load Sharing

IMT

Inter-Module-Transport

The communication software that operates the inter-module-transport bus on all cards except the LIMATM, DCM, DSM, and HMUX.

I

IP	<p>Internet Protocol</p> <p>IP specifies the format of packets, also called datagrams, and the addressing scheme. The network layer for the TCP/IP protocol suite widely used on Ethernet networks, defined in STD 5, RFC 791. IP is a connectionless, best-effort packet switching protocol. It provides packet routing, fragmentation and re-assembly through the data link layer.</p>
IP Address	<p>The location of a device on a TCP/IP network. The IP Address is a number in dotted decimal notation which looks something like [192.168.1.1].</p>
IPSM	<p>IP Services Module</p> <p>A card that provides an IP connection for Telnet and FTP-based Table Retrieve applications. The IPSM is a GPSM-II card with a one Gigabyte (UD1G) expansion memory board in a single-slot assembly running the IPS application.</p>
IS41 GSM Migration	<p>A feature that adds GSM IS-41 migration functions to the existing IS-41 to GSM feature. This enhancement provides flexibility in the encoding and decoding of parameters of LOCREQ messages and responses to number migration from one mobile protocol to another.</p>
IS-ANR	<p>In Service - Abnormal</p> <p>The entity is in service but only able to perform a limited subset of its normal service functions.</p>

I

IS-NR	In Service - Normal
ISS	Integrated Signaling System
ISUP	ISDN User Part
ITU	International Telecommunications Union
ITU-I	ITU International
ITU-N	ITU National
ITUDUPPC	ITU National Duplicate Point Code This feature applies only to 14-bit ITU national point codes. This feature allows an EAGLE 5 ISS mated pair to route traffic for two or more countries that may have overlapping point code values.

L

LAN	Local Area Network A private data network in which serial transmission is used for direct data communication among data stations located in the same proximate location. LAN uses coax cable, twisted pair, or multimode fiber. See also STP LAN.
LFS	Link Fault Sectionalization A feature in the EAGLE 5 ISS that allows the maintenance personnel to perform a series of far end loopback tests, from the EAGLE 5 ISS and identify faulty segments of an SS7 transmission path up to and

L

including the remote network element.

LIM

Link Interface Module

Provides access to remote SS7, IP and other network elements, such as a Signaling Control Point (SCP) through a variety of signaling interfaces (DS0, MPL, E1/T1 MIM, LIM-ATM, E1-ATM, IPLIMx, IPGWx). The LIMs consist of a main assembly and possibly, an interface appliqué board. These appliqués provide level one and some level two functionality on SS7 signaling links.

LNP

Local Number Portability

LSN

Link Set Name

The name of the link set.

M

MAP

Mobile Application Part

MAP Set

A group of entities in the MAP table that are used to distribute final GTT traffic.

MAS

Maintenance and Administration Subsystem

A set of cards located in the Control Shelf, used to provide a central management point for the EAGLE 5 ISS. The MAS provides user interface, maintenance communication, peripheral services, alarm processing, system disk interface, and measurements using the following three subassemblies: GPSM-II, TDM, and MDAL.

M

MASP	<p>Maintenance and Administration Subsystem Processor</p> <p>The Maintenance and Administration Subsystem Processor (MASP) function is a logical pairing of the GPSM-II card and the TDM card. The GPSM-II card is connected to the TDM card by means of an Extended Bus Interface (EBI) local bus.</p> <p>The MDAL card contains the removable cartridge drive and alarm logic. There is only one MDAL card in the Maintenance and Administration Subsystem (MAS) and it is shared between the two MASPs.</p>
Mated Application	<p>The point codes and subsystem numbers of the service databases that messages are routed to for global title translation.</p>
MCPM	<p>Measurement Collection and Polling Module</p> <p>The Measurement Collection and Polling Module (MCPM) provides comma delimited core STP measurement data to a remote server for processing. The MCPM is an EDSM with 2 GB of memory running the MCP application.</p>
MDAL	<p>Maintenance Disk and Alarm</p>
MLS	<p>Multiple Linksets to Single Adjacent PC</p>
MPC	<p>The MPC (Multiple Point Code) feature enables the user to use SPCs (Secondary Point Codes) in addition to the true point codes that the</p>

M

EAGLE 5 ISS uses. The SPCs are used for provisioning and routing as if they were the true point code of the EAGLE 5 ISS. SPCs can be provisioned in any of the three domains (ANSI, ITU-N, and ITU-I). SPCs are supported for any type of link.

N

NPC

National Point Code

O

OAM

Operations, Administration, and Maintenance

The generic load program (application) that operates the Maintenance and Administration Subsystem which controls the operation of the EAGLE 5 ISS.

OOS-MT

Out of Service - Maintenance

The entity is out of service and is not available to perform its normal service function. The maintenance system is actively working to restore the entity to service.

OOS-MT-DSBLD

Out of Service - Maintenance Disabled

The entity is out of service and the maintenance system is preventing the entity from performing its normal service function.

OPC

Originating Point Code

P

PC

Point Code

The identifier of a signaling point or service control point in a network.

P

The format of the point code can be one of the following types:

- ANSI point codes in the format network indicator-network cluster-network cluster member (**ni-nc-ncm**).
- Non-ANSI domestic point codes in the format network indicator-network cluster-network cluster member (**ni-nc-ncm**).
- Cluster point codes in the format network indicator-network cluster-* or network indicator-*-*.
- ITU international point codes in the format **zone-area-id**.
- ITU national point codes in the format of a 5-digit number (**nnnnn**), or 2, 3, or 4 numbers (members) separated by dashes (**m1-m2-m3-m4**) as defined by the Flexible Point Code system option. A group code is required (**m1-m2-m3-m4-gc**) when the ITUDUPPC feature is turned on.
- 24-bit ITU national point codes in the format main signaling area-subsignaling area-service point (**msa-ssa-sp**).

The EAGLE 5 ISS LNP uses only the ANSI point codes and Non-ANSI domestic point codes.

PCA

Point Code ANSI

PCI

Peripheral Component Interface

Point Code International

Protocol Control Information

Peripheral Component
Interconnect

P

PCN	Point Code National Product Change Notice
PLNP	The Personal Communications Service (PCS) 1900 LNP Query (PLNP) feature provides for LNP query/response in a PCS wireless environment using the LRN method to support Service Provider Number Portability.
PPSMS	Prepaid Short Message Service Prepaid Short Message Service Intercept
PST	Primary State A field in the <code>rept-stat</code> command outputs showing the primary state of the specified entity.
PVC	Permanent Virtual Circuit A direct connection to an X.25 node that is configured in the EAGLE 5 ISS's database and can only be changed through database administration.

R

Route	A signaling path from an LSP to an RSP using a specified Link Set
-------	---

S

SAPC	Secondary Adjacent Point Code
SCCP	Signaling Connection Control Part
SCSI	Small Computer System Interface

S

There are two independent Small Computer System Interface (SCSI) buses, one to the fixed disks on TDM cards and the other to the shared administration SCSI bus that runs on the backplane between TDMs and the MDAL card. Each SCSI bus has a block of memory that allows transfers from memory to occur without delaying the application processor.

SEAS

Signaling Engineering and Administration System

An interface defined by Bellcore and used by the Regional Bell Operating Companies (RBOCs), as well as other Bellcore Client Companies (BCCs), to remotely administer and monitor the signaling points in their network from a central location.

Secondary Point Code (SPC)

See SPC.

Signaling Link

The transmission path connecting the EAGLE 5 ISS to other signaling points in the network and providing access to ANSI SS7 and ITU SS7 network elements. The signaling link is connected to the EAGLE 5 ISS at the link interface module (LIM).

SIO

Service Information Octet.

The network indicator code (NIC), priority (PRI), and service indicator (SI) in the SIO field in the message signaling unit (MSU). This information identifies the type of MSU (ISUP, TCAP, and so forth) that is allowed in the network where the EAGLE 5 ISS is located.

S

SLC	Signaling Link Code
SLTM	Signal Link Test Message
SPC	Secondary Point Code The SPC enables the EAGLE 5 ISS to assume more than one point code for SS7 routing. The EAGLE 5 ISS uses the SPC for routing and provisioning as if the SPC were an actual point code of the EAGLE 5 ISS. The EAGLE 5 ISS supports one ANSI true point code and up to seven secondary point codes. Spare Point Code
SR	Screening Reference
SS7	Signaling System #7
SSN	Subsystem Number The subsystem number of a given point code. The subsystem number identifies the SCP application that should receive the message, or the subsystem number of the destination point code to be assigned to the LNP subsystem of the EAGLE 5 ISS. A value of the routing indicator portion of the global title translation data commands indicating that no further global title translation is required for the specified entry.
STP	Signal Transfer Point STPs are ultra-reliable, high speed packet switches at the heart of SS7 networks, which terminate all link types except F-links. STPs are nearly always deployed in mated pairs for

S

reliability reasons. Their primary functions are to provide access to SS7 networks and to provide routing of signaling messages within and among signaling networks.

STP LAN

Signaling Transfer Point Local Area Network.

A feature in the EAGLE 5 ISS that copies MSUs selected through the gateway screening process and sends these MSUs over the Ethernet to an external host computer for further processing.

STPLAN

Signaling Transfer Point Local Area Network

The generic program load and application used by the STPLAN card to support the STP LAN application. This GPL does not support 24-bit ITU-N point codes.

SVC

Switched Virtual Circuit

A temporary virtual circuit that is set up and used only as long as data is being transmitted. Once the communication between the two hosts is complete, the SVC disappears. In contrast, a permanent virtual circuit (PVC) remains available at all times.

SVCA

Automatic Switched Virtual Circuit

A connection to an X.25 node established by the EAGLE 5 ISS as soon as the LIM initializes.

T

T1

Transmission Level 1

A T1 interface terminates or distributes T1 facility signals for the

T

purpose of processing the SS7 signaling links carried by the E1 carrier.

A leased-line connection capable of carrying data at 1,544,000 bits-per-second.

TBGTTLs	Transaction-based GTT Loadsharing
TCP/IP	Transmission Control Protocol/Internet Protocol
TDM	Terminal Disk Module Time Division Multiplexing
TLNP	Triggerless LNP
TO	Timing Output
TSM	Translation Services Module Provides translation capability and Global Title Translation (GTT) implementation for the Local Number Portability (LNP) function and is used for downloading gateway screening tables to link interface modules (LIMs).
TUP	Telephone User Part

U

UIM	Unsolicited Information Message
-----	---------------------------------

V

V.35	ITU Interface Recommendation, V.35 The interface used with the LIMV35 card.
------	--

V

VSCCP	<p>VxWorks Signaling Connection Control Part</p> <p>The application used by the Service Module card to support the G-Flex, G-Port, INP, AINPQ, EIR, A-Port, IGM, V-Flex, and LNP features. If the G-Flex, G-Port, INP, AINPQ, EIR, A-Port, IGM, V-Flex, or LNP feature is not turned on, and a Service Module card is present, the VSCCP GPL processes normal GTT traffic.</p>
-------	--

W

WGTTLS	Weighted GTT Loadsharing
WNP	<p>Wireless Number Portability</p> <p>The Wireless Number Portability feature enhances the Local Number Portability feature to allow wireless service providers to query the LNP database for ported telephone numbers. The query is used to find the location routing number associated with the ported telephone number so the telephone call can be routed to its proper destination. The Wireless Number Portability feature can only be used for ANSI messages not for ITU messages.</p>

X

XGTT	Expanded GTT (GTT Table Expansion).
XMAP	Expanded MAP Table