

Tekelec EAGLE® 5 *Integrated Signaling System*

Release 37.5

Database Administration Manual - IP7 Secure Gateway

910-5051-001 Revision B

November 2007



Copyright 2007 Tekelec
All Rights Reserved.
Printed in U.S.A.

Notice

Information in this documentation is subject to change without notice. Unauthorized use, copying, or translation of this documentation can result in civil or criminal penalties.

Any export of Tekelec products is subject to the export controls of the United States and the other countries where Tekelec has operations.

No part of this documentation may be reproduced, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying or recording, for any purpose without the express written permission of an authorized representative of Tekelec.

Other product names used herein are for identification purposes only, and may be trademarks of their respective companies.

RoHS 5/6 - As of July 1, 2006, all products that comprise new installations shipped to European Union member countries will comply with the EU Directive 2002/95/EC "RoHS" (Restriction of Hazardous Substances). The exemption for lead-based solder described in the Annex will be exercised. RoHS 5/6 compliant components will have unique part numbers as reflected in the associated hardware and installation manuals.

WEEE - All products shipped to European Union member countries comply with the EU Directive 2002/96/EC, Waste Electronic and Electrical Equipment. All components that are WEEE compliant will be appropriately marked. For more information regarding Tekelec's WEEE program, contact your sales representative.

Trademarks

The Tekelec logo, EAGLE, G-Flex, G-Port, IP7, IP7 Edge, IP7 Secure Gateway, and TALI are registered trademarks of Tekelec. TekServer and A-Port are trademarks of Tekelec. All other trademarks are the property of their respective owners.

Patents

This product is covered by one or more of the following U.S. and foreign patents:

U.S. Patent Numbers:

5,732,213; 5,953,404; 6,115,746; 6,167,129; 6,324,183; 6,327,350; 6,456,845; 6,606,379; 6,639,981; 6,647,113; 6,662,017; 6,735,441; 6,745,041; 6,765,990; 6,795,546; 6,819,932; 6,836,477; 6,839,423; 6,885,872; 6,901,262; 6,914,973; 6,940,866; 6,944,184; 6,954,526; 6,954,794; 6,959,076; 6,965,592; 6,967,956; 6,968,048; 6,970,542; 6,987,781; 6,987,849; 6,990,089; 6,990,347; 6,993,038; 7,002,988; 7,020,707; 7,031,340; 7,035,239; 7,035,387; 7,043,000; 7,043,001; 7,043,002; 7,046,667; 7,050,456; 7,050,562; 7,054,422; 7,068,773; 7,072,678; 7,075,331; 7,079,524; 7,088,728; 7,092,505; 7,108,468; 7,110,780; 7,113,581; 7,113,781; 7,117,411; 7,123,710; 7,127,057; 7,133,420; 7,136,477; 7,139,388; 7,145,875; 7,146,181; 7,155,206; 7,155,243; 7,155,505; 7,155,512; 7,181,194; 7,190,702; 7,190,772; 7,190,959; 7,197,036; 7,206,394; 7,215,748; 7,219,264; 7,222,192; 7,227,927; 7,231,024; 7,242,695; 7,254,391

Foreign Patent Numbers:

EP1062792; EP1308054; EP1247378; EP1303994; EP1252788; EP1161819; EP1177660; EP1169829; EP1135905; EP1364520; EP1192758; EP1240772; EP1173969; CA2352246

Ordering Information

To order additional copies of this document, contact your Tekelec Sales Representative.

Table of Contents

Chapter 1. Introduction	1-1
Overview	1-1
Manual Organization	1-1
Related Publications	1-2
Documentation Availability, Packaging, and Updates	1-2
Documentation Admonishments	1-3
Customer Care Center	1-3
Emergency Response	1-4
Maintenance and Administration Subsystem	1-4
EAGLE 5 ISS Database Partitions	1-5
Fixed Disk Drive	1-5
Removable Cartridge	1-6
Locate Product Documentation on the Customer Support Site	1-6
Chapter 2. IP7 Secure Gateway Overview	2-1
Introduction	2-1
Hardware, Applications, and Functions	2-2
IP Connections	2-3
Point-to-Point Connectivity (IPLIM or IPLIMI Application)	2-16
Point-to-Multipoint Connectivity (SS7IPGW and IPGWI)	2-16
SNMP Agent Implementation	2-23
Mixed Networks Using the ANSI/ITUMTP Gateway Feature	2-25
ISUP Normalization	2-29
IETF Adapter Layer Support	2-36
Overview	2-36
Chapter 3. TALI IPLIMx Configuration Procedures	3-1
Adding TALI IPLIMx Components	3-1
Adding an IPLIMx Card	3-2
Adding an IPLIMx Signaling Link	3-7
Enabling the Large System # Links Controlled Feature	3-18
Configuring an IP Link	3-27
Adding an IP Host	3-43
Configuring an IP Card	3-47
Adding an IP Route	3-55
Adding a Socket to an IPLIMx Signaling Link	3-61
Removing TALI IPLIMx Components	3-71
Removing an IPLIMx Card	3-71
Removing an IPLIMx Signaling Link	3-73

Removing an IP Host Assigned to an IPLIMx Card	3-81
Removing an IP Route	3-86
Removing a Socket that is Assigned to an IPLIMx Signaling Link	3-90
Changing TALI IPLIMx Components	3-92
Changing the Attributes of a Socket on an IPLIMx Signaling Link	3-92
Configuring IP Socket Retransmission Parameters	3-105
Configuring a DCM Parameter Set	3-111
Chapter 4. TALI IPGWx Configuration Procedures	4-1
Adding TALI IPGWx Components	4-1
Adding an IPGWx Card	4-3
Configuring an IPGWx Linkset	4-10
Configuring a Mate IPGWx Linkset	4-34
Adding an IPGWx Signaling Link	4-52
Enabling the Large System # Links Controlled Feature	4-66
Configuring an IP Link	4-75
Adding an IP Host	4-91
Configuring an IP Card	4-95
Adding an IP Route	4-103
Adding a Socket to an IPGWx Signaling Link	4-109
Adding a Routing Key Containing a Socket	4-120
Increasing the System-Wide IPGWx Signaling TPS	4-134
Removing TALI IPGWx Components	4-141
Removing an IPGWx Card	4-141
Removing an IPGWx Signaling Link	4-143
Removing an IP Host Assigned to an IPGWx Card	4-150
Removing an IP Route	4-155
Removing a Socket that is Assigned to an IPGWx Signaling Link	4-159
Removing a Routing Key Containing a Socket	4-162
Changing TALI IPGWx Components	4-167
Changing the Attributes of a Socket on an IPGWx Signaling Link	4-168
Configuring IP Socket Retransmission Parameters	4-181
Configuring a DCM Parameter Set	4-187
Changing the CIC Values in an Existing Routing Key Containing a Socket	4-192
Changing the PSTN Presentation and Normalization Attributes in a Routing Key	4-199
Configuring the IP TPS Alarm Threshold	4-211
Chapter 5. IETF M2PA Configuration Procedures	5-1
Adding IETF IPLIMx Components	5-1
Adding an IPLIMx Card	5-3
Adding an IPLIMx Signaling Link	5-7
Enabling the Large System # Links Controlled Feature	5-17
Configuring an IP Link	5-26
Adding an IP Host	5-42
Configuring an IP Card	5-46
Adding an IP Route	5-54
Adding an M2PA Association	5-60
Activating the Large BICC MSU Support for IP Signaling Feature	5-73

Removing IETF M2PA Components	5-80
Removing an IPLIMx Card	5-81
Removing an IPLIMx Signaling Link	5-82
Removing an IP Host Assigned to an IPLIMx Card	5-90
Removing an IP Route	5-95
Removing an M2PA Association	5-99
Changing IETF M2PA Components	5-101
Changing an M2PA Association	5-102
Configuring SCTP Retransmission Control for an M2PA Association	5-123
Changing an M2PA Timer Set	5-129
Changing the SCTP Checksum Algorithm Option for M2PA Associations	5-136
Turning the Large BICC MSU Support for IP Signaling Feature Off	5-143
Chapter 6. IETF M3UA and SUA Configuration Procedures	6-1
Adding IETF M3UA and SUA Components	6-2
Adding an IPGWx Card	6-4
Configuring an IPGWx Linkset	6-12
Configuring a Mate IPGWx Linkset	6-36
Increasing the System-Wide IPGWx Signaling TPS	6-54
Configuring the IP TPS Alarm Threshold	6-61
Adding an IPGWx Signaling Link	6-63
Enabling the Large System # Links Controlled Feature	6-76
Configuring an IP Link	6-85
Adding an IP Host	6-101
Configuring an IP Card	6-105
Adding an IP Route	6-113
Adding an M3UA or SUA Association	6-119
Adding a New Association to a New Application Server	6-128
Adding an Existing Association to a New Application Server	6-134
Adding a New Association to an Existing Application Server	6-144
Adding an Existing Association to an Existing Application Server	6-154
Adding a Routing Key Containing an Application Server	6-166
Adding a Network Appearance	6-185
Activating the Large BICC MSU Support for IP Signaling Feature	6-191
Removing IETF M3UA and SUA Components	6-198
Removing an IPGWx Card	6-199
Removing an IPGWx Signaling Link	6-200
Removing an IP Host Assigned to an IPGWx Card	6-207
Removing an IP Route	6-212
Removing an M3UA or SUA Association	6-216
Removing an Association from an Application Server	6-218
Removing a Routing Key Containing an Application Server	6-223
Removing a Network Appearance	6-231
Changing IETF M3UA and SUA Components	6-233
Changing the IP Protocol Option	6-234
Changing IP Options other than SYNC and SCTPCSUM	6-239
Changing an M3UA or SUA Association	6-244
Configuring SCTP Retransmission Control for an M3UA or SUA Association	6-263

Changing an Application Server	6-269
Changing the CIC Values in an Existing Routing Key Containing an Application Server ...	6-273
Changing the Routing Context Value in an Existing Routing Key	6-282
Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations	6-289
Changing a UA Parameter Set	6-303
Turning the Large BICC MSU Support for IP Signaling Feature Off	6-309
Chapter 7. ISUP Variant Table Provisioning	7-1
Overview	7-1
Adding New ISUP PSTN Presentation Values	7-4
Changing ISUP Presentation Values	7-7
Removing ISUP Presentation Values	7-9
Changing ISUP Variant Table Entries	7-12
Copying ISUP Variant Table Entries	7-19
Chapter 8. End Office Support	8-1
Overview	8-1
Internal Point Code	8-2
New Installation of VXI Behind a EAGLE 5 ISS with End Office Support	8-4
One Node Migrates from PSTN to IP	8-4
A Signaling End Point is Added to a Deployed EAGLE 5 ISS Using End Office	8-5
Two Signaling End Points Move from PSTN to IP Using End Office	8-6
The EAGLE 5 ISS Simultaneously Acts as STP and End Office	8-7
The EAGLE 5 ISS Supports Multiple Network Types and Multiple Hosts as an End Node	8-8
Mated Pair Supports Two End Office Nodes	8-9
End Office Support Configuration	8-10
Adding an End Node Internal Point Code	8-11
Removing an End Node Internal Point Code	8-15
Chapter 9. Activating Controlled Features	9-1
Introduction	9-1
Enabling Controlled Features	9-1
Temporary Feature Keys	9-6
Turning On and Off Controlled Features	9-7
Turning On an Enabled Controlled Feature	9-8
Turning Off an Enabled Controlled Feature	9-10
Glossary	Glossary-1
Index	Index-1

List of Figures

Figure 1-1. EAGLE 5 ISS Database Partitions.....	1-5
Figure 2-1. TCP socket or SCTP Association Database Relationships.....	2-4
Figure 2-2. IP Connections using a Dual-Slot DCM running the IPLIMx Applications.....	2-5
Figure 2-3. IP Connections using a Dual-Slot DCM running the IPGWx Applications.....	2-6
Figure 2-4. IP Connections using an EDCM or E5-ENET Card running the IPGWx Applications.....	2-7
Figure 2-5. Typical SCTP Association and TCP Socket Configuration.....	2-8
Figure 2-6. SCTP Association and TCP Socket on the Same IP Card.....	2-9
Figure 2-7. IP Connections using SSEDICMs running the IPLIMx Applications.....	2-9
Figure 2-8. IP Connections using E5-ENET Cards running the IPLIMx Applications.....	2-10
Figure 2-9. Multi-Homed Associations on EDCMs or E5-ENET Cards running the IPLIMx Applications.....	2-12
Figure 2-10. Multi-Homed Associations on EDCMs or E5-ENET Cards running the IPGWx Applications.....	2-13
Figure 2-11. Multi-Homed Association Database Relationships.....	2-13
Figure 2-12. EAGLE 5 ISS Network (STP Connectivity via MTP-over-IP).....	2-16
Figure 2-13. IP Network (SCP Connectivity via TCAP-over-IP).....	2-17
Figure 2-14. IP Network (SEP connectivity via ISUP, Q.BICC, and TUP-over-IP).....	2-18
Figure 2-15. Complex Network with ANSI, ITU-I, and ITU-N Nodes.....	2-26
Figure 2-16. 8-bit TOS Field.....	2-29
Figure 2-17. DS Field.....	2-29
Figure 2-18. ISUP Normalization Supporting Multiple ISUP Variants.....	2-31
Figure 2-19. Format of PSTN Presentation.....	2-34
Figure 2-20. AS/Association Relationship.....	2-37
Figure 2-21. TCP Socket/SCTP Association Relationship.....	2-38
Figure 2-22. SG/MGC/MG Network Diagram.....	2-38
Figure 2-23. TALI Protocol Stack (IPGWx and IPLIMx).....	2-39
Figure 2-24. IPLIMx Protocol Stack with SCTP as the Transport Layer.....	2-39
Figure 2-25. IPGWx Protocol Stack with SCTP as the Transport Layer.....	2-40
Figure 2-26. M2PA in the IP ⁷ Signaling Gateway.....	2-43
Figure 2-27. SCTP Connectivity.....	2-45
Figure 3-1. Adding an IPLIMx Card.....	3-6
Figure 8-1. An EAGLE 5 ISS with End Office Support and VXI Node.....	8-4
Figure 8-2. Network Before an EAGLE 5 ISS with End Office, Node P is to Migrate.....	8-5
Figure 8-3. Network After an EAGLE 5 ISS with End Office, Node P has Migrated.....	8-5
Figure 8-4. Original Network with Deployed EAGLE 5 ISS.....	8-6
Figure 8-5. New Network with an EAGLE 5 ISS Using End Office and End Node R.....	8-6

Figure 8-6. Network before Two Signaling End Points Migrate from PSTN to IP.....	8-7
Figure 8-7. Network after Two Signaling End Points Migrate from PSTN to IP.....	8-7
Figure 8-8. The EAGLE 5 ISS Simultaneously Acts as STP and End Office.....	8-8
Figure 8-9. Three Multiple-Element End Office Nodes.....	8-9
Figure 8-10. Mated Pair Supports Two End Office Nodes.....	8-10

List of Tables

Table 2-1. Ethernet Interface and Signaling Link Combinations.....	2-4
Table 2-2. Uni-Homed and Multi-Homed Node Combinations.....	2-11
Table 2-3. SS7 Full Routing Keys per IPGWx Functionality.....	2-19
Table 2-4. Example SS7 Routing Key Table.....	2-21
Table 2-5. Routing Key Lookup Hierarchy.....	2-22
Table 2-6. SNMP Object Groups.....	2-23
Table 2-7. Deviations from SNMP Protocols.....	2-24
Table 2-8. Nodes and Point Codes in Complex Network Example.....	2-26
Table 2-9. ISUP Variants Supported by this Feature.....	2-32
Table 2-10. Sample SCTP Endpoints.....	2-46
Table 2-11. Sample SCTP Associations.....	2-47
Table 2-12. Sample SCTP Associations.....	2-47
Table 3-1. IPLIMx Card Types.....	3-3
Table 3-2. TALI IPLIMx Signaling Link Parameter Combinations.....	3-12
Table 3-3. Valid Subnet Mask Parameter Values.....	3-28
Table 3-4. Sample IP Routing Table.....	3-56
Table 3-5. Valid Subnet Mask Parameter Values.....	3-56
Table 3-6. DCMPS Values.....	3-111
Table 4-1. IPGWx Card Types.....	4-3
Table 4-2. Signaling Link Fair Share Example.....	4-12
Table 4-3. Optional Linkset Parameters.....	4-13
Table 4-4. Optional Linkset Parameters.....	4-35
Table 4-5. IPGWx Signaling Link Parameter Combinations.....	4-59
Table 4-6. Valid Subnet Mask Parameter Values.....	4-76
Table 4-7. Sample IP Routing Table.....	4-104
Table 4-8. Valid Subnet Mask Parameter Values.....	4-104
Table 4-9. Examples of IPGWx Card Provisioning Limits.....	4-110
Table 4-10. Service Indicator Text String Values.....	4-121
Table 4-11. Routing Key Parameter Combinations for Adding a Routing Key Containing a Socket.....	4-122
Table 4-12. System-Wide IPGWx Signaling TPS Part Numbers.....	4-135
Table 4-13. Service Indicator Text String Values.....	4-163
Table 4-14. Routing Key Parameter Combinations for Removing Routing Keys.....	4-164
Table 4-15. Examples of IPGWx Card Provisioning Limits.....	4-169
Table 4-16. DCMPS Values.....	4-187
Table 4-17. Service Indicator Text String Values.....	4-192

Table 4-18. Routing Key Parameter Combinations for Changing the Range of CIC Values in an Existing Routing Key	4-193
Table 4-19. Routing Key Parameter Combinations for Splitting the Range of CIC Values in an Existing Routing Key.....	4-194
Table 4-20. Service Indicator Text String Values.....	4-200
Table 5-1. IPLIMx Card Types.....	5-3
Table 5-2. M2PA IPLIMx Signaling Link Parameter Combinations.....	5-12
Table 5-3. Valid Subnet Mask Parameter Values.....	5-27
Table 5-4. Sample IP Routing Table.....	5-55
Table 5-5. Valid Subnet Mask Parameter Values.....	5-55
Table 5-6. M2PA Timers.....	5-130
Table 6-1. IPGWx Card Types.....	6-4
Table 6-2. Signaling Link Fair Share Example.....	6-14
Table 6-3. Optional Linkset Parameters.....	6-15
Table 6-4. Optional Linkset Parameters.....	6-37
Table 6-5. System-Wide IPGWx Signaling TPS Part Numbers.....	6-55
Table 6-6. IPGWx Signaling Link Parameter Combinations.....	6-70
Table 6-7. Valid Subnet Mask Parameter Values.....	6-86
Table 6-8. Sample IP Routing Table.....	6-114
Table 6-9. Valid Subnet Mask Parameter Values.....	6-114
Table 6-10. Examples of IPGWx Card Provisioning Limits.....	6-128
Table 6-11. Examples of IPGWx Card Provisioning Limits.....	6-135
Table 6-12. Examples of IPGWx Card Provisioning Limits.....	6-144
Table 6-13. Examples of IPGWx Card Provisioning Limits.....	6-155
Table 6-14. Service Indicator Text String Values.....	6-166
Table 6-15. Routing Key Parameter Combinations for Adding a Routing Key Containing an Application Server.....	6-167
Table 6-16. Service Indicator Text String Values.....	6-224
Table 6-17. Routing Key Parameter Combinations for Removing Routing Keys.....	6-225
Table 6-18. Examples of IPGWx Card Provisioning Limits.....	6-246
Table 6-19. Service Indicator Text String Values.....	6-274
Table 6-20. Routing Key Parameter Combinations for Changing the Range of CIC Values in an Existing Routing Key	6-275
Table 6-21. Routing Key Parameter Combinations for Splitting the Range of CIC Values in an Existing Routing Key.....	6-276
Table 6-22. Service Indicator Text String Values.....	6-283
Table 6-23. Valid PVALUE Parameter Values if PARM=1.....	6-304
Table 6-24. Valid PVALUE Parameter Values if PARM=2.....	6-305
Table 7-1. ISUP Variants Supported by this Feature.....	7-2
Table 7-2. CHG-ISUPVAR-ATTRIB Parameter Combinations.....	7-14
Table 8-1. Sample IPC Values.....	8-3
Table 9-1. Sample Controlled Feature Part Numbers.....	9-2
Table 9-2. Sample Controlled Feature Part Numbers.....	9-8
Table 9-3. Sample Controlled Feature Part Numbers.....	9-10

List of Flowcharts

Flowchart 1.	Adding an IPLIMx Signaling Link.....	3-15
Flowchart 2.	Enabling the Large System # Links Controlled Feature.....	3-24
Flowchart 3.	Configuring an IP Link.....	3-36
Flowchart 4.	Adding an IP Host.....	3-46
Flowchart 5.	Changing an IP Card.....	3-53
Flowchart 6.	Adding an IP Route.....	3-60
Flowchart 7.	Adding a Socket to an IPLIMx Signaling Link.....	3-68
Flowchart 8.	Removing an IPLIMx Card.....	3-73
Flowchart 9.	Removing an IP Signaling Link.....	3-80
Flowchart 10.	Removing an IP Host Assigned to an IPLIMx Card.....	3-85
Flowchart 11.	Removing an IP Route.....	3-89
Flowchart 12.	Removing an Application Socket.....	3-92
Flowchart 13.	Changing the Attributes of a Socket on an IPLIMx Signaling Link.....	3-100
Flowchart 14.	Configuring IP Socket Retransmission Parameters.....	3-110
Flowchart 15.	Configuring a DCM Parameter Set.....	3-115
Flowchart 16.	Adding an IPGWx Card.....	4-6
Flowchart 17.	Configuring an IPGWx Linkset.....	4-25
Flowchart 18.	Configuring a Mate IPGWx Linkset.....	4-46
Flowchart 19.	Adding an IPGWx Signaling Link.....	4-62
Flowchart 20.	Enabling the Large System # Links Controlled Feature.....	4-72
Flowchart 21.	Configuring an IP Link.....	4-84
Flowchart 22.	Adding an IP Host.....	4-94
Flowchart 23.	Changing an IP Card.....	4-101
Flowchart 24.	Adding an IP Route.....	4-108
Flowchart 25.	Adding a Socket to an IPGWx Signaling Link.....	4-117
Flowchart 26.	Adding a Routing Key Containing a Socket.....	4-130
Flowchart 27.	Increasing the IPGWx Signaling TPS.....	4-139
Flowchart 28.	Removing an IPGWx Card.....	4-143
Flowchart 29.	Removing an IPGWx Signaling Link.....	4-149
Flowchart 30.	Removing an IP Host Assigned to an IPGWx Card.....	4-154
Flowchart 31.	Removing an IP Route.....	4-158
Flowchart 32.	Removing a Socket that is Assigned to an IPGWx Signaling Link.....	4-162
Flowchart 33.	Removing a Routing Key Containing a Socket.....	4-167
Flowchart 34.	Changing the Attributes of a Socket on an IPGWx Signaling Link.....	4-176

Flowchart 35.	Configuring IP Socket Retransmission Parameters.....	4-186
Flowchart 36.	Configuring a DCM Parameter Set.....	4-191
Flowchart 37.	Changing the CIC Values in an Existing Routing Key Containing a Socket.....	4-198
Flowchart 38.	Changing the PSTN Presentation and Normalization Attributes in an Routing Key.....	4-206
Flowchart 39.	Configuring the IP TPS Alarm Threshold.....	4-213
Flowchart 40.	Adding an IP Card.....	5-6
Flowchart 41.	Adding an IPLIMx Signaling Link.....	5-15
Flowchart 42.	Enabling the Large System # Links Controlled Feature.....	5-23
Flowchart 43.	Configuring an IP Link.....	5-35
Flowchart 44.	Adding an IP Host.....	5-45
Flowchart 45.	Changing an IP Card.....	5-52
Flowchart 46.	Adding an IP Route.....	5-59
Flowchart 47.	Adding an M2PA Association.....	5-69
Flowchart 48.	Activating the Large BICC MSU Support for IP Signaling Feature.....	5-78
Flowchart 49.	Removing an IPLIMx Card.....	5-82
Flowchart 50.	Removing an IPLIMx Signaling Link.....	5-89
Flowchart 51.	Removing an IP Host Assigned to an IPLIMx Card.....	5-94
Flowchart 52.	Removing an IP Route.....	5-98
Flowchart 53.	Removing an M2PA Association.....	5-101
Flowchart 54.	Changing an M2PA Association.....	5-115
Flowchart 55.	Configuring an M2PA Association for SCTP Retransmission Control.....	5-128
Flowchart 56.	Changing an M2PA Timer Set.....	5-135
Flowchart 57.	Changing the SCTP Checksum Algorithm Option for M2PA Associations.....	5-141
Flowchart 58.	Turning the Large BICC MSU Support for IP Signaling Feature Off.....	5-144
Flowchart 59.	Adding an IP Card.....	6-7
Flowchart 60.	Configuring an IPGWx Linkset.....	6-27
Flowchart 61.	Configuring a Mate IPGWx Linkset.....	6-48
Flowchart 62.	Increasing the IPGWx Signaling TPS.....	6-59
Flowchart 63.	Configuring the IP TPS Alarm Threshold.....	6-63
Flowchart 64.	Adding an IPGWx Signaling Link.....	6-72
Flowchart 65.	Enabling the Large System # Links Controlled Feature.....	6-82
Flowchart 66.	Configuring an IP Link.....	6-94
Flowchart 67.	Adding an IP Host.....	6-104
Flowchart 68.	Changing an IP Card.....	6-111
Flowchart 69.	Adding an IP Route.....	6-118
Flowchart 70.	Adding an M3UA or SUA Association.....	6-125
Flowchart 71.	Adding a New Association to a New Application Server.....	6-132
Flowchart 72.	Adding an Existing Association to a New Application Server.....	6-141

Flowchart 73. Adding a New Association to an Existing Application Server.....	6-150
Flowchart 74. Adding an Existing Association to an Existing Application Server.....	6-161
Flowchart 75. Adding a Routing Key Containing an Application Server...	6-181
Flowchart 76. Adding a Network Appearance.....	6-189
Flowchart 77. Activating the Large BICC MSU Support for IP Signaling Feature.....	6-196
Flowchart 78. Removing an IPGWx Card.....	6-200
Flowchart 79. Removing an IPGWx Signaling Link.....	6-206
Flowchart 80. Removing an IP Host Assigned to an IPGWx Card.....	6-211
Flowchart 81. Removing an IP Route.....	6-215
Flowchart 82. Removing an M3UA or SUA Association.....	6-218
Flowchart 83. Removing an Association from an Application Server.....	6-222
Flowchart 84. Removing a Routing Key Containing an Application Server.....	6-230
Flowchart 85. Removing a Network Appearance.....	6-233
Flowchart 86. Changing the IP Protocol Option.....	6-238
Flowchart 87. Changing an IP Option That Does Not Require Inhibiting the IP Card.....	6-243
Flowchart 88. Changing an M3UA or SUA Association.....	6-257
Flowchart 89. Configuring an M3UA or SUA Association for SCTP Retransmission Control.....	6-268
Flowchart 90. Changing an Application Server.....	6-272
Flowchart 91. Changing the CIC Values in an Existing Routing Key Containing an Application Server.....	6-281
Flowchart 92. Changing the Routing Context Value in an Existing Routing Key.....	6-288
Flowchart 93. Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations.....	6-299
Flowchart 94. Changing a UA Parameter Set.....	6-309
Flowchart 95. Turning the Large BICC MSU Support for IP Signaling Feature Off.....	6-311
Flowchart 96. Adding ISUP PSTN Presentation Value.....	7-6
Flowchart 97. Changing ISUP PSTN Presentation Value.....	7-9
Flowchart 98. Removing ISUP PSTN Presentation Value.....	7-12
Flowchart 99. Changing ISUP Attribute Values.....	7-18
Flowchart 100. Copying ISUP Attribute Values.....	7-23
Flowchart 101. Adding an End Node Internal Point Code.....	8-14
Flowchart 102. Removing an End Node Internal Point Code.....	8-16
Flowchart 103. Enabling a Permanent or Temporary Key.....	9-5
Flowchart 104. Clearing a Temporary Feature Access Key Alarm.....	9-7
Flowchart 105. Turning On an Enabled Controlled Feature.....	9-9
Flowchart 106. Turning Off an Enabled Controlled Feature.....	9-11

Introduction

Overview	1-1
Manual Organization	1-1
Related Publications	1-2
Documentation Availability, Packaging, and Updates	1-2
Documentation Admonishments	1-3
Customer Care Center	1-3
Emergency Response	1-4
Maintenance and Administration Subsystem	1-4
EAGLE 5 ISS Database Partitions	1-5
Fixed Disk Drive	1-5
Removable Cartridge	1-6
Locate Product Documentation on the Customer Support Site	1-6

Overview

The *Database Administration Manual – IP⁷ Secure Gateway* describes the procedures necessary for database administration personnel or translations personnel to create, modify, display, and maintain the EAGLE 5 ISS database, and to configure the EAGLE 5 ISS to implement the IP⁷ Secure Gateway functionality.

NOTE: Database administration privileges are password restricted. Only those persons with access to the command class “Database Administration” can execute the administrative functions. Other command classes and the commands allowed by those classes are listed in the *Commands Manual*.

Manual Organization

Throughout this document, the terms database and system software are used. Database refers to all data that can be administered by the user, including shelves, cards, links, routes, global title translation tables, and gateway screening tables. System software refers to data that cannot be administered by the user, including generic program loads (GPLs).

This document is organized into these sections:

[Chapter 1 Introduction](#) contains general information about the database and the organization of this manual.

[Chapter 2 IP7 Secure Gateway Overview](#) describes the basics of the IP⁷ Secure Gateway functionality.

[Chapter 3 TALI IPLIMx Configuration Procedures](#) describes the procedures necessary to configure the EAGLE 5 ISS to provide connectivity between SS7 and IP networks, enabling messages to pass between the SS7 network domain and the IP network domain, using TALI sockets and IPLIMx signaling links.

[Chapter 4 TALI IPGWx Configuration Procedures](#) describes the procedures necessary to configure the EAGLE 5 ISS to provide connectivity between SS7 and IP networks, enabling messages to pass between the SS7 network domain and the IP network domain, using TALI sockets and IPGWx signaling links.

[Chapter 5 IETF M2PA Configuration Procedures](#) describes the procedures necessary to configure the EAGLE 5 ISS to provide connectivity between SS7 and IP networks, enabling messages to pass between the SS7 network domain and the IP network domain, using M2PA associations and IPLIMx signaling links.

[Chapter 6 IETF M3UA and SUA Configuration Procedures](#) describes the procedures necessary to configure the EAGLE 5 ISS to provide connectivity between SS7 and IP networks, enabling messages to pass between the SS7 network domain and the IP network domain, using either M3UA or SUA associations and IPGWx signaling links.

[Chapter 7 ISUP Variant Table Provisioning](#) describes the procedures necessary to configure the ISUP Variant Tables.

[Chapter 8 End Office Support](#) describes the procedures necessary to allow the EAGLE 5 ISS to share its true point code (TPC) with an IP-based node without the need for a separate point code for the IP node.

[Chapter 9 Activating Controlled Features](#) explains how to enable controlled features with temporary and permanent feature keys, how to clear the alarms for near to expired and expired temporary keys, and how to turn enabled On/Off features on and off.

Related Publications

For information about additional publications that are related to this document, refer to the *Related Publications* document. The *Related Publications* document is published as a part of the *Release Documentation* and is also published as a separate document on the Tekelec Customer Support Site.

Documentation Availability, Packaging, and Updates

Tekelec provides documentation with each system and in accordance with contractual agreements. For General Availability (GA) releases, Tekelec publishes a complete EAGLE 5 ISS documentation set. For Limited Availability (LA) releases, Tekelec may publish a documentation subset that is tailored to specific feature content or hardware requirements. Documentation Bulletins announce a new or updated release.

The Tekelec EAGLE 5 ISS documentation set is released on a CD-ROM. This format allows for easy searches through all parts of the documentation set.

The electronic file of each manual is also available from the Tekelec Customer Support site. This site allows for 24-hour access to the most up-to-date documentation.

Printed documentation is available for GA releases on request only and with a lead time of 4 weeks. The printed documentation set includes pocket guides for commands and alarms. Pocket guides may also be ordered as a set or individually. Exceptions to printed documentation are:

- Hardware or Installation manuals are printed only without the linked attachments found in the electronic version of the manuals.

- The Release Notice is available only on the Customer Support site.

NOTE: Customers may print a reasonable number of each manual for their own use.

Documentation is updated when significant changes are made that affect system operation. Updates resulting from Severity 1 and 2 PRs are made to existing manuals. Other changes are included in the documentation for the next scheduled release. Updates are made by re-issuing an electronic file to the customer support site. Customers with printed documentation should contact their Sales Representative for an addendum. Occasionally, changes are communicated first with a Documentation Bulletin to provide customers with an advanced notice of the issue until officially released in the documentation. Documentation bulletins are posted on the Customer Support site and can be viewed per product and release.

Content changes are indicated with change bars, the revision of the manual part number is incremented, and the month of publication is updated.

Documentation Admonishments

Admonishments are icons and text throughout this manual that alert the reader to assure personal safety, to minimize possible service interruptions, and to warn of the potential for equipment damage.

	DANGER: (This icon and text indicate the possibility of <i>personal injury</i>.)
	WARNING: (This icon and text indicate the possibility of <i>equipment damage</i>.)
	CAUTION: (This icon and text indicate the possibility of <i>service interruption</i>.)

Customer Care Center

The Tekelec Customer Care Center offers a point of contact for product and service support through highly trained engineers or service personnel. The Tekelec Customer Care Center is available 24 hours a day, 7 days a week at the following locations:

- Tekelec, USA
 Phone:
 +1 888 367 8552 (US and Canada only)
 +1 919 460 2150 (international)
 Email: support@tekelec.com
- Tekelec, Europe
 Phone: +44 1784 467804
 Email: ecsc@tekelec.com

When a call is received, a Customer Service Report (CSR) is issued to record the request for service. Each CSR includes an individual tracking number.

Once a CSR is issued, the Customer Care Center determines the classification of the trouble. If a critical problem exists, emergency procedures are initiated. If the problem is not critical, information regarding the serial number of the system, COMMON Language Location Identifier (CLLI), initial problem symptoms (includes outputs and messages) is recorded. A primary Customer Care Center engineer is also assigned to work on the CSR and provide a solution to the problem. The CSR is closed when the problem is resolved.

Emergency Response

In the event of a critical service situation, emergency response is offered by Tekelec Technical Services twenty-four hours a day, seven days a week. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

A critical situation is defined as a problem with an EAGLE 5 ISS that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical problems affect service and/or system operation resulting in:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with Tekelec Technical Services.

Maintenance and Administration Subsystem

The maintenance and administration subsystem consists of two processors, MASP (maintenance and administration subsystem processor) A and MASP B.

Each MASP is made up of two cards, the GPSM-II card (general purpose service module) and the TDM (terminal disk module).

The GPSM-II card contains the communications processor and applications processor and provides connections to the IMT bus. The GPSM-II controls the maintenance and database administration activity.


The TDM contains the fixed disk drive, the terminal processor for the 16 serial I/O ports and interfaces to the MDAL (maintenance disk and alarm) card which contains the removable cartridge drive and alarm logic. There is only one MDAL card in the maintenance and administration subsystem and it is shared between the two MASPs.

For more information on these cards, go to the *Hardware Manual - EAGLE 5 ISS*.

EAGLE 5 ISS Database Partitions

The data that the EAGLE 5 ISS uses to perform its functions are stored in two separate areas: the fixed disk drives, and the removable cartridge. The following sections describe these areas and data that is stored on them. These areas and their partitions are shown in [Figure 1-1](#).

Figure 1-1. EAGLE 5 ISS Database Partitions



Fixed Disk Drive

There are two fixed disk drives on the EAGLE 5 ISS. The fixed disk drives contain the “master” set of data and programs for the EAGLE 5 ISS. The two fixed disk drives are located on the terminal disk modules (TDMs). Both disks have the same files. The data stored on the fixed disks is partially replicated on the various cards in the EAGLE 5 ISS. Changes made during database administration sessions are sent to the appropriate cards.

The data on the fixed disks can be viewed as four partitions.

- Current partition

- Backup partition
- Measurements partition
- Generic program loads (GPLs) partition

The data which can be administered by users is stored in two partitions on the fixed disk, a current database partition which has the tables which are changed by on-line administration, and a backup database partition which is a user-controlled copy of the current partition.

All of the on-line data administration commands effect the data in the current partition. The purpose of the backup partition is to provide the users with a means of rapidly restoring the database to a known good state if there has been a problem while changing the current partition.

A full set of GPLs is stored on the fixed disk, in the GPL partition. There is an approved GPL and a trial GPL for each type of GPL in this set and a utility GPL, which has only an approved version. Copies of these GPLs are downloaded to the EAGLE 5 ISS cards. The GPL provides each card with its functionality. For example, the **ss7ansi** GPL provides MTP functionality for link interface modules (LIMs).

Measurement tables are organized as a single partition on the fixed disk. These tables are used as holding areas for the measurement counts.

Removable Cartridge

A removable cartridge is used for two purposes.

- To hold an off-line backup copy of the administered data and system GPLs
- To hold a copy of the measurement tables

Because of the size of the data stored on the fixed disk drives on the TDMs, a single removable cartridge cannot store all of the data in the database, GPL and measurements partitions.

To use a removable cartridge to hold the system data, it must be formatted for system data. To use a removable cartridge to hold measurements data, it must be formatted for measurements data. The EAGLE 5 ISS provides the user the ability to format a removable cartridge for either of these purposes. A removable cartridge can be formatted on the EAGLE 5 ISS by using the **format-disk** command. More information on the **format-disk** command can be found in the *Commands Manual*. More information on the removable cartridge drives can be found in the *Hardware Manual - EAGLE 5 ISS*.

The removable cartridge drive is located on the MDAL card in card location 1117.

Additional and preformatted removable cartridges are available from the [Customer Care Center](#).

Locate Product Documentation on the Customer Support Site

To view or download product documentation, log into the Tekelec Customer Support site at:

<https://support.tekelec.com/index.asp>

1. Log in with your user name and password. (Click on "Need an Account?" if you need to register).
2. Select EAGLE from the Product Support menu.

3. Select the release number from the Release menu.
4. Locate the Notices section to view the latest Feature Notice.
5. Locate the Manuals section to view all manuals applicable to this release.

The documentation is listed in alphabetical order by the manual name. Only the first three manuals display. Click **more...** to see the remaining manuals.

6. Locate the latest revision of the manual name.

Confirm the release number and last available revision.

Select the 936-xxxx-x01 part number to download the complete documentation set with all linked files.

NOTE: The electronic file for this part number is quite large.

7. To view a manual, double-click the manual name.
8. To download a manual, right-click and select Save Target As.

NOTE: Customers may print a reasonable number of each manual for their own use.

IP7 Secure Gateway Overview

Introduction	2-1
Hardware, Applications, and Functions	2-2
IP Connections	2-3
Point-to-Point Connectivity (IPLIM or IPLIMI Application)	2-16
Point-to-Multipoint Connectivity (SS7IPGW and IPGWI)	2-16
SNMP Agent Implementation	2-23
Mixed Networks Using the ANSI/ITUMTP Gateway Feature	2-25
ISUP Normalization	2-29
IETF Adapter Layer Support	2-36
Overview	2-36

Introduction

The IP ⁷ Secure Gateway functionality in the EAGLE 5 ISS provides connectivity between SS7 and IP networks, enabling messages to pass between the SS7 network domain and the IP network domain, as follows:

- When an EAGLE 5 ISS receives an SS7 formatted message over an SS7 link, the IP ⁷ Secure Gateway functionality dynamically converts this message into IP format and routes the re-formatted message over an associated IP link to a destination residing within an IP network.

The IP ⁷ Secure Gateway functionality use sockets or associations to access the IP domain. Sockets or associations identify IP sessions.

- Conversely, when the EAGLE 5 ISS receives an IP formatted message over an IP link, the IP ⁷ Secure Gateway functionality dynamically converts this message into SS7 format and routes the re-formatted message over an associated SS7 link to a destination residing within the SS7 signaling network.

Address resolution is not performed in the IP to SS7 direction. It is the responsibility of the sending application to ensure that the appropriate SS7 point code information resides in the IP message to allow a valid SS7 message to be constructed for routing to the SS7 network.

Hardware, Applications, and Functions

The IP⁷ Secure Gateway functionality is provided by applications that run on IP cards, either a Database Communications Module (DCM), a single-slot Enhanced-Performance Database Communications Module (EDCM), or E5-ENER card. IP cards provide interfaces between the IMT bus and two 10/100 Base-T IEEE 802.3/DIX Ethernet interfaces. The IP cards, similar to any other Link Interface Module (LIM), use the Interprocessor Message Transport (IMT) bus to communicate with the other cards in the EAGLE 5 ISS. Like other LIMs, the primary job of an IP card is to send and receive SS7 data on a network (in this case, an IP network), and to route that data to other cards in the EAGLE 5 ISS as appropriate.

The IP card can run on the following applications:

- **iplim** or **iplimi** - Both applications support STP connectivity via MTP-over-IP functionality point-to-point connectivity (for more information, see [Point-to-Point Connectivity \(IPLIM or IPLIMI Application\)](#)).

The **iplim** and **iplimi** applications support these types of connections:

- TALI/TCP/IP (B, C, D links)
- M2PA/SCTP/IP (A, B, C, D, and E links)
- SCP
- SEP
- SCP/SEP

This type of connection is essentially the same as that of a traditional SS7 point-to-point link, except that the traditional MTP2 and 56Kb/s technology is replaced by IP and Ethernet technology.

The **iplim** application supports point-to-point connectivity for ANSI networks. The **iplimi** application supports point-to-point connectivity for ITU networks. With the optional ANSI/ITU MTP Gateway feature and proper configuration, the EAGLE 5 ISS could convert between any of the ANSI, ITU-N, and ITU-I networks, switch traffic between these networks, and perform network management for each of these networks (for more information, see [Mixed Networks Using the ANSI/ITUMTP Gateway Feature](#)).

The EAGLE 5 ISS can support up to 100 cards running the **iplim** and **iplimi** applications.

- **ss7ipgw** and **ipgwi** - These applications support the following types of point-to-multipoint connectivity for networks:
 - SCP connectivity via SCCP/TCAP-over-IP functionality (for more information, see [Connecting to SCPs with SCCP/TCAP Messages Sent Over the IP Network](#))
 - SEP connectivity via ISUP, Q.BICC, and TUP-over-IP functionality (for more information, see [Connecting SEPs Using ISUP, Q.BICC, and TUP Messages Over the IP Network](#))
 - SCP/SEP connectivity via non-ISUP, non-SCCP, non-Q.BICC, and non-TUP-over-IP functionality (for more information, see [Connecting SCPs and SEPs Using Non-ISUP, Non-SCCP, Non-Q.BICC, and Non-TUP Messages Over the IP Network](#))

The **ss7ipgw** application supports point-to-multipoint connectivity for ANSI networks. The **ipgwi** application supports point-to-multipoint connectivity for ITU networks.

The EAGLE 5 ISS can support a maximum of 64 cards running the **ss7ipgw** and **ipgwi** applications.

In addition to running an **iplim**, **iplimi**, **ss7ipgw**, or **ipgwi** application, each IP card supports the following functions:

- A Simple Network Management Protocol (SNMP) agent. For more information, see [SNMP Agent Implementation](#).
- Message Transfer Part (MTP) status. This function is available only on IP cards that support the **ss7ipgw** or **ipgwi** application. For more information, see [Support for MTP Status Functions](#).

IP Connections

IP connections involve the following assignments:


- Transport protocol – The SCTP transport protocol is specified by the **ent-assoc** and **chg-assoc** commands. The TCP transport protocol is specified by the **ent-appl-sock** and **chg-appl-sock** commands.
- Adapter protocol – The M3UA, M2PA, or SUA adapter protocol is specified by the **adapter** parameter of the **ent-assoc** and **chg-assoc** commands. If TCP sockets are provisioned with the **ent-appl-sock** and **chg-appl-sock** commands, the adapter protocol is implicitly defined as TALI.
- One or two near-end (local) hosts – The local host is specified by the **lhost** parameter of the **ent-assoc**, **chg-assoc**, **ent-appl-sock**, and **chg-appl-sock** commands. A second local host can be specified for an association using the **alhost** parameter of the **ent-assoc** and **chg-assoc** commands, allowing the near-end host of the association to be multi-homed. Specifying only one local host for an association allows the association to be uni-homed.
- Far-end (remote) host – The remote host is specified by the **rhost** parameter of the **ent-assoc**, **chg-assoc**, **ent-appl-sock**, and **chg-appl-sock** commands.
- Near-end (local) transport protocol port – The local transport protocol port is specified by the **lport** parameter of the **ent-assoc**, **chg-assoc**, **ent-appl-sock**, and **chg-appl-sock** commands.
- Far-end (remote) transport protocol port – The remote transport protocol port is specified by the **rport** parameter of the **ent-assoc**, **chg-assoc**, **ent-appl-sock**, and **chg-appl-sock** commands.
- SS7 signaling link – specified by the **loc** and **link** parameters of the **ent-slk** command.

The local host is mapped to a particular Ethernet interface on the IP card by linking the local host name of the IP connection to an IP address with the **ent-ip-host** command. The IP address is also assigned to an IP card and to an Ethernet interface on that IP card using the **chg-ip-lnk** command. A signaling link on that card is assigned to the IP connection using the **link** parameter of the **ent-assoc**, **chg-assoc**, **ent-appl-sock**, and **chg-appl-sock** commands and referencing the signaling link on the IP card.

A TCP socket can establish a connection between one local host and one remote host. An SCTP association can establish a connection between one local host and one remote host (a uni-homed association) or between multiple local hosts and a remote host (a multi-homed association). It is possible that the remote host may be multi-homed, but the EAGLE 5 ISS allows only one remote host to be specified for a multi-homed association. If an IP node has multiple IP address associated with it, then an SCTP association originating from this node may take advantage of this added connectivity by establishing an SCTP multi-homed association.

For more information on multi-homed associations, see the [Multi-Homed SCTP Associations](#) section and the [Routing](#) section.

Figure 2-1 shows the components of a TCP socket or SCTP association and how these components interact with each other.

Figure 2-1. TCP socket or SCTP Association Database Relationships

There is no direct correlation between signaling link ports and Ethernet interfaces. A card can be using Ethernet interface A and signaling link B to transmit data to the remote host. Another scenario could have the card using Ethernet interface B and signaling link A to transmit data to the remote host.

The numbers of signaling link ports and Ethernet interfaces on IP cards varies depending on the card type and application running on the card, as shown in [Table 2-1](#). The sections that follow [Table 2-1](#) describe the IP connections supported by each IP card type. The IP connections described in these sections are either TCP sockets or uni-homed SCTP associations.

Table 2-1. Ethernet Interface and Signaling Link Combinations


Card	Application	Ethernet Interface	Signaling Link
Dual-Slot DCM	IPLIMx	A	A and B
	IPGWx	A	A
Single-slot EDCM (SSEDCM)	IPLIMx	A and B	A, B, A1, B1, A2, B2, A3 and B3
	IPGWx	A and B	A

Card	Application	Ethernet Interface	Signaling Link
E5-ENET	IPLIMx	A and B	A - A7, B - B7
	IPGWx	A and B	A

IP Connection on a Dual-Slot DCM Running the IPLIMx Application


Dual-slot DCMs running the IPLIMx applications can have two signaling link ports (A or B) and only one Ethernet interface (A), as shown in [Figure 2-2](#) , resulting in a maximum of two IP connections, one for each signaling link, using Ethernet interface A.

Figure 2-2. IP Connections using a Dual-Slot DCM running the IPLIMx Applications




IP Connection on a Dual-Slot DCM Running the IPGWx Application

Dual-slot DCMs running the IPGWx applications can have only one signaling link (A) and one Ethernet interface (A). With this card able to support up to 50 IP connections, these 50 connections are established over Ethernet interface A, using signaling link A, as shown in [Figure 2-3](#) .


Figure 2-3. IP Connections using a Dual-Slot DCM running the IPGWx Applications**IP Connection on an EDCM or E5-ENET Card Running the IPGWx Application**

Single-slot EDCMs running the IPGWx applications can have only one signaling link (A) and two Ethernet interfaces (A or B). With this card able to support up to 50 IP connections, these 50 connections can be established using both Ethernet interfaces A and B, as shown in [Figure 2-4](#). The number of connections on each Ethernet interface can vary, but the total number connections on both interfaces cannot exceed 50. These 50 connections can also be established using only one Ethernet interface (A or B), if desired. Only signaling link A is used for the signaling link.

Figure 2-4. IP Connections using an EDCM or E5-ENET Card running the IPGWx Applications

The assignment of the transport protocol (TCP or SCTP) port number is made through the local host port (**lport**) and remote host port (**rport**) parameters of the **ent-appl-sock** or **chg-appl-sock** commands (for a TCP socket), or the **ent-assoc** or **chg-assoc** commands (for an SCTP association). An IP card can have both TCP sockets and SCTP associations assigned to it at the same time. The transport protocol port numbers for TCP sockets are TCP ports. The transport protocol port numbers for SCTP associations are SCTP ports. Port numbers for one transport protocol have no relation to port numbers for the other transport protocol.


[Figure 2-5](#) shows typical IP connection data for a uni-homed SCTP association and a TCP socket and how these components interact with each other.

Figure 2-5. Typical SCTP Association and TCP Socket Configuration


Using the data in [Figure 2-5](#), the IP connection defined by the TCP socket is from local host ipnode-1201 (190.50.1.25), TCP port 7005, to remote host remote-node-1 (190.50.1.36), TCP port 5139, using Ethernet interface A on IP card 1201, and signaling link B on IP card 1201.

The IP connection defined by the SCTP association is from local host ipnode-1204 (190.50.1.139), SCTP port 2048, to remote host remote-node-2 (190.50.1.144), SCTP port 3529, using Ethernet interface B on IP card 1204, and signaling link A on IP card 1204.

In another scenario, IP card 1203 could contain a TCP socket and an SCTP association. The connection defined by the TCP socket is from local host ipnode-1203b (190.50.1.69), TCP port 4096, to remote host remote-node-3 (190.50.1.159), TCP port 1657, using Ethernet interface B on IP card 1203, and signaling link A on IP card 1203. The connection defined by the SCTP association is from local host ipnode-1203a (190.50.1.68), SCTP port 4096, to remote host remote-node-4 (190.50.1.199), SCTP port 1657, using Ethernet interface A on IP card 1203, and signaling link B on IP card 1203. This IP connection scenario is shown in [Figure 2-6](#).

Figure 2-6. SCTP Association and TCP Socket on the Same IP Card**IP Connection on a Single-slot EDCM Running the IPLIMx Application**


Single-slot EDCMs (SSEDCMs) running the IPLIMx applications can have 8 signaling links (A, B, A1, B1, A2, B2, A3 or B3) and 2 Ethernet interfaces (A or B) resulting in a maximum of 8 IP connections, one for each signaling link. Each link can use either Ethernet interface A or B. The local host and alternate host assigned to a signaling link must use different Ethernet interfaces; they cannot be assigned to the same Ethernet interface. [Figure 2-7](#) shows some ways the 8 signaling links and the 2 Ethernet interfaces can be used to establish IP connections.

Figure 2-7. IP Connections using SSEDCMs running the IPLIMx Applications

IP Connection on an E5-ENET Card Running the IPLIMx Application

E5-ENET cards running the IPLIMx applications can have 16 signaling links (A, B, A1, B1, A2, B2, A3, B3, A4, B4, A5, B5, A6, B6, A7 or B7) and 2 Ethernet interfaces (A or B) resulting in a maximum of 16 IP connections, one for each signaling link. Each link can use either Ethernet interface A or B. The local host and alternate host assigned to a signaling link must use different Ethernet interfaces; they cannot be assigned to the same Ethernet interface. [Figure 2-8](#) shows some ways the 16 signaling links and the 2 Ethernet interfaces can be used to establish IP connections.

Figure 2-8. IP Connections using E5-ENET Cards running the IPLIMx Applications



Multi-Homed SCTP Associations

If the IP cards are EDCMs or E5-ENET cards, SCTP associations can have two local hosts, and are referred to as multi-homed associations. A multi-homed association uses both Ethernet interfaces on the IP card. Each Ethernet interface is assigned to a local host. Each local host is assigned to a different local network. One of the local hosts is configured with the **lhost** parameter of the **ent-assoc** or **chg-assoc** commands. The second local host, or alternate local host, is configured with the **alhost** parameter of the **ent-assoc** or **chg-assoc** commands. One of the local hosts references one of the Ethernet interfaces on the IP card and the other local host references the other Ethernet interface on the IP card. The multi-homed SCTP association allows the EDCM or E5-ENET card to communicate with another node over two networks. Traffic is passed to and from the remote node on either local interface on the card.

An SCTP association can be uni-homed also. A uni-homed association uses only one Ethernet interface (A or B), which is assigned to only one local host. This local host is configured with the **lhost** parameter of the **ent-assoc** or **chg-assoc** commands. For a uni-homed association, the **alhost** parameter is not be specified with the **ent-assoc** or **chg-assoc** commands. A uni-homed association allows the IP card to communicate to another node on one network only. Traffic is passed to and from the remote node on the local interface on the card defined by the **lhost** parameter.

The remote node can be either uni-homed or multi-homed, and is not dependent on whether or not the local node (containing the local hosts) is uni-homed or multi-homed. For example, Node A can be uni-homed and can be

connected to a multi-homed Node B, or a multi-homed Node A can be connected to a uni-homed Node B. [Table 2-2](#) illustrates the possible combinations.


Table 2-2. Uni-Homed and Multi-Homed Node Combinations

Node A	Node B
Uni-homed	Uni-homed
Uni-homed	Multi-homed
Multi-homed	Uni-homed
Multi-homed	Multi-homed

Multi-Homed Associations on EDCMs or E5-ENET Cards Running the IPLIMx Application

A multi-homed association on an IPLIMx card uses both Ethernet interfaces to reach the remote host, but only one signaling link. An association, either uni-homed or multi-homed, can be assigned to only one signaling link. That signaling link can be either signaling link A or B. The local and alternate local hosts are assigned to each Ethernet interface on the IP card. The IPLIMx cards are limited to one IP connection per signaling link. Since the IPLIMx cards can have eight signaling links on the card, eight multi-homed associations can be assigned to an IPLIMx card.


[Figure 2-9](#) shows the ways a multi-homed IP connection can be established on an IPLIMx card. The remote hosts can be multi-homed, but only one remote host can be specified for each multi-homed association in the EAGLE 5 ISS, so only one remote host is shown in [Figure 2-9](#).

Figure 2-9. Multi-Homed Associations on EDCMs or E5-ENET Cards running the IPLIMx Applications


Multi-Homed Associations on EDCMs or E5-ENET Cards Running the IPGWx Applications

A multi-homed association on an IPGWx card uses both Ethernet interfaces to reach the remote host, but only one signaling link, signaling link A on the IPGWx card. The local and alternate local hosts are assigned to each Ethernet interface on the IP card. The IPGWx cards can have up to 50 connections for each IPGWx card. The IPGWx card can contain both uni-homed and multi-homed IP connections, as long as the total number of connections does not exceed 50.

[Figure 2-10](#) shows the way a multi-homed IP connection can be established on an IPGWx card. The remote hosts can be multi-homed, but only one remote host can be specified for each multi-homed association in the EAGLE 5 ISS, so only one remote host is shown in [Figure 2-10](#).

Figure 2-10. Multi-Homed Associations on EDCMs or E5-ENET Cards running the IPGWx Applications

[Figure 2-11](#) shows the components of the multi-homed SCTP association and how these components interact with each other.

Figure 2-11. Multi-Homed Association Database Relationships

Using the data shown in [Figure 2-11](#), the IP connection is defined as a multi-homed association, connecting to a remote host using local hosts 190.1.5.56 and 189.20.30.137 over SCTP port 3425, using signaling link B on card 1201.

Routing

The IP⁷ Secure Gateway functionality in the EAGLE 5 ISS support two transport protocols – TCP and SCTP. Although both transport protocols are connection oriented, they differ greatly with respect to operation in a multi-homed host environment. The TCP protocol provides for a point-to-point transport connection. The SCTP protocol implements connections with either point to point, point to multi-point, or multi-point to multi-point connectivity capabilities.

A TCP socket connection is defined by an explicit four-tuple – a local IP address, local TCP port, remote IP address and remote TCP port. Once the local IP address is determined for a TCP connection, it binds all subsequent transmissions to this specific IP interface. Once an IP interface is selected for a TCP connection, the TCP connection will fail if the remote host becomes unreachable by this interface. This connection failure occurs on a multi-homed host even if the remote host can still be reached by a different IP interfaces of the multi-homed host.

An SCTP IETF connection – association – has a broader definition than TCP with respect to a multi-homed host. An SCTP IETF association is defined as a four-tuple as follows:

- local host list – one or more of the local host's IP interface addresses
- local SCTP port
- remote host list – one or more of the remote host's IP interface addresses
- remote SCTP port.

Based on this definition for an SCTP IETF connection, and the fact that the IPGWx and IPLIMx applications may utilize both Ethernet interfaces (a multi-homed host), an SCTP IETF association can take advantage of multi-homing and be a multi-homed SCTP endpoint. As a multi-homed endpoint, an SCTP IETF connection remains active and usable as long as at least one of the Ethernet interfaces can be reached by the remote host. Multiple paths through multiple interfaces to the remote host provides a more reliable connection. Thus where a TCP connection would be lost, and if possible, a new one established by the application, the SCTP IETF protocol is designed to make such a network outage transparent to the application.

In previous releases, an SCTP IETF endpoint could only operate as a uni-homed host using only the Ethernet A interface. In this mode, any SCTP transmission received on or transmitted out of the Ethernet B interface are silently discarded. By using the Ethernet B interface, the SCTP protocol running on the IP card can provide SCTP multi-homing endpoint support – that is, when an SCTP IETF association is formed, it may list both the Ethernet A and B IP addresses for the respective interfaces. As a multi-homed association endpoint, SCTP data would be allowed to flow on either of the Ethernet interfaces and thus provide more robust network connectivity.

In order to provide more flexible network connectivity, an association can be configured as follows with respect to the Ethernet interfaces:

- Ethernet A interface only (uni-homed)
- Ethernet B interface only (uni-homed)
- Ethernet A and B interface (multi-homed).

The interface mode is specified by the **lhost** and **alhost** parameters of the **ent -assoc** or **chg -assoc** commands.

In previous releases, the **lhost** parameter of the **ent -assoc** or **chg -assoc** commands is used to define the local IP address of the SCTP IETF association endpoint. The IP address would have to be an IP address associated with an Ethernet A interface. With this release, the IP address may be associated with either the Ethernet A or B

interfaces. If it is an Ethernet A interface IP address, and the **alhost** parameter is not specified, then the association operates as a uni-homed SCTP endpoint on Ethernet interface A. If it is an Ethernet B interface IP address, and the **alhost** parameter is not specified, then the association operates as a uni-homed SCTP endpoint on Ethernet interface B. An association is configured as an SCTP multi-homed endpoint by specifying both the **lhost** and **alhost** parameter values with values corresponding to the Ethernet interface IP address for the IP card. The **lhost** and **alhost** parameter values represent the IP addresses specified by the **chg-ip-lnk** command for the specific IP card. Traffic cannot be passed between the Ethernet interfaces on the IP card containing a multi-homed SCTP association. The IP card cannot act as an IP router between the networks defined by the local host and alternate local hosts of a multi-homed association.

A host that is not on the local network, the network identified by the local host's IP address, can be reached only through a gateway router. A gateway router is a device with more than one physical network connection, and can be connected to multiple networks. Unlike a multi-homed host, a gateway router is permitted to route IP messages between the physical Ethernet interfaces on the IP card. The network portion of the gateway router's IP address must be the same as the network portion of the IP address of one of the IP addresses of the Ethernet interfaces on the IP card. The gateway router is configured using the **defrouter** of the **chg-ip-card** command, or using the **ent-ip-rte** command.

Static entries are added to the IP Routing table using the **ent-ip-rte** command. Static routes are usually assigned to give control over which routers are used, allowing different routers to be selected based upon the destination IP address. There are two types of static routes:

- host static IP routes
- network or subnetwork static IP routes.

The default route entry is a special static route. If there is not a specific host or network address in the IP Routing table that matches the destination IP address of an outbound datagram, then the datagram is sent to the default router (gateway) specified by the default route.

An IP route is configured using the **ent-ip-rte** command with the location of the IP card, the IP address of the gateway router (the **gtwy** parameter), and the IP address and subnet mask of the destination (that is, host or network). The IP address of the gateway router must be a locally attached IP address (that is, the gateway IP address must share the network portion of one of the two Ethernet interfaces).

When an IP packet is to be transmitted the IP routing table must be interrogated to determine where to send the IP datagram. If the destination IP address is local to the node (that is, directly reachable by an Ethernet interface), then the IP datagram is transmitted directly to the node with that associated IP address. If the destination IP address is determined to not be local to the node, then it must be routed (that is, sent to a gateway to reach its destination).

IP routing requires accessing the IP routing table to select a route. The destination IP address of the outbound datagram is used to search the IP routing table for the most specific route match. The order for selection is:

1. Host route
2. Subnetwork route
3. Network route
4. Aggregated route
5. Default route.

Based on this selection order if an IP route is found then the outbound IP datagram will be transmitted to the gateway specified by the route. If no IP route is found (where no default route is specified), then the transmission of the datagram fails due to destination unreachable.

The capability to enter static IP routes provides for flexibility and control with respect to controlling network traffic. An IP card can contain up to 64 IP routes. The EAGLE 5 ISS can contain up to 1024 IP routes.


Point-to-Point Connectivity (IPLIM or IPLIMI Application)

The following sections describe the types of point-to-point connectivity provided, and how routing is accomplished, by the **iplim** or **iplimi** application:

Connecting STPs Over the IP Network

This functionality allows the use of an IP network in place of point-to-point SS7 links to carry SS7 MSUs. [Figure 2-12](#) shows a diagram of this type of network. For example, the C links between the mated pair of STPs or A/B/D links between STPs can be replaced by an IP network. The IP⁷ Secure Gateway functionality is deployed on both ends of the link (point-to-point connection). The EAGLE 5 ISS converts the SS7 MSUs to IP packets on one end of the link, and IP packets to SS7 MSUs on the other end of the link. The IPLIMx applications supports the TALI/TCP/IP sockets over B, C, and D links and M2PA/SCTP/IP associations over A, B, C, D, and E links.

Figure 2-12. EAGLE 5 ISS Network (STP Connectivity via MTP-over-IP)



Point-to-Multipoint Connectivity (SS7IPGW and IPGWI)

The following sections describe the types of point-to-multipoint connectivity, how routing is accomplished, and the MTP status functions provided by the **ss7ipgw** and **ipgwi** applications:


- [Connecting to SCPs with SCCP/TCAP Messages Sent Over the IP Network](#)

- [Connecting SEPs Using ISUP, Q.BICC, and TUP Messages Over the IP Network](#)
- [Connecting SCPs and SEPs Using Non-ISUP, Non-SCCP, Non-Q.BICC, and Non-TUP Messages Over the IP Network](#)
- [Understanding Routing for SS7IPGW and IPGWI Applications](#)
- [Support for MTP Status Functions](#)

Connecting to SCPs with SCCP/TCAP Messages Sent Over the IP Network

This functionality allows SS7 nodes to exchange SCCP/TCAP queries and responses with an SCP residing on an IP network. [Figure 2-13](#) shows a diagram of this type of network.

Figure 2-13. IP Network (SCP Connectivity via TCAP-over-IP)




The EAGLE 5 ISS manages the virtual point codes and subsystem numbers for the IP-SCP. From the SS7 network perspective, the TCAP queries are routed using these virtual point codes/SSNs. The EAGLE 5 ISS maps the virtual point code/SSN to one or more TCP sessions (point-to-multipoint connection), converts the SS7 MSUs to IP packets by embedding the SCCP/TCAP data inside IP packets, and routes them over an IP network. The EAGLE 5 ISS also manages application subsystem status from an IP network's perspective and an SS7 network's perspective.

The following sequence of events illustrates this functionality:

1. Traditional SS7 devices route MSUs (such as TCAP Queries) to the EAGLE 5 ISS.
2. The EAGLE 5 ISS performs a global title translation and forwards the translated MSU to the correct IP device based on Point Code and SCCP Subsystem information in the MSU.
3. The TCAP query is processed at the IP-SCP, and the IP-SCP sends a TCAP reply back to the EAGLE 5 ISS.
4. The EAGLE 5 ISS forwards the TCAP reply back to the sender of the original query.

Connecting SEPs Using ISUP, Q.BICC, and TUP Messages Over the IP Network

This point-to-multipoint functionality allows SS7 nodes to exchange ISUP, Q.BICC, and TUP protocol messages with one or more signaling end points (class 4 switches, class 5 switches, VoIP gateways, Media Gateway Controllers, or Remote Access Servers) residing on an IP network. [Figure 2-14](#) shows an example of this type of network.

Figure 2-14. IP Network (SEP connectivity via ISUP, Q.BICC, and TUP-over-IP)

The EAGLE 5 ISS maps the originating point code, destination point code, and circuit identification code to an IP connection. The SEP is provided the originating and destination point codes in the MTP level 3 routing label as part of the passed protocol.

Connecting SCPs and SEPs Using Non-ISUP, Non-SCCP, Non-Q.BICC, and Non-TUP Messages Over the IP Network

This point-to-multipoint functionality allows SS7 nodes to exchange non-ISUP, non-SCCP, non-Q.BICC, and non-TUP protocol messages with one or more IP-based devices residing on an IP network. The network example is similar to the SCP connectivity via SCCP/TCAP-over-IP functionality example shown in [Figure 2-13](#). The EAGLE 5 ISS maps the destination point code, and service indicator (non-ISUP, non-SCCP, non-Q.BICC, non-TUP) to an IP connection.

Understanding Routing for SS7IPGW and IPGW1 Applications

The **ss7ipgw** and **ipgw1** applications can use a single point code, called a virtual point code. This code is assigned to a set of IP devices that it connects to. The EAGLE 5 ISS distinguishes between the devices within the set by using application routing keys and application sockets or application servers.

Application routing associates SS7 routing keys with sockets or application servers. SS7 routing keys define a filter based on SS7 message data. Application sockets or application servers define the connection between the IP local host/local transport protocol port and IP remote host/remote transport protocol port.

An application server is a logical entity serving a specific routing key. The application server contains a set of one or more unique application server processes, of which one or more is normally actively processing traffic. An application server process is a process instance of an application server and contains an SCTP association. For more information on application servers, application server processes, and SCTP associations, see the [IETF Adapter Layer Support](#) section.

If the routing key filter matches the SS7 message presented for routing to the IP network, the SS7 message is sent to the associated application socket or application server.

There may be up to 16 application sockets or one application server associated with each SS7 routing key. One application server can have up to 16 associations. SS7 messages delivered to the IP network using a routing key are distributed over the available application sockets or application server based on the SLS (signaling link selector) value in the SS7 message.

Routing keys can be fully or partially specified, or specified by default.

Full Routing Keys

For this routing application, all applicable fields in the Message Signaling Unit (MSU) must match the contents of the full routing key. [Table 2-3](#) defines which SS7 message parameters are used to search for a match for full routing keys for each of the functions supported by the **ss7ipgw** and **ipgwi** applications (IPGWx functionality).

Table 2-3. SS7 Full Routing Keys per IPGWx Functionality

IPGWx Functionality (ANSI and ITU)	SS7 Routing Keys
SCP connectivity via TCAP-over-IP	Destination Point Code Service Indicator (=3) Subsystem Number
SEP connectivity via ISUP-over-IP	Destination Point Code Service Indicator (=5) Originating Point Code CIC Range Start CIC Range End
SEP connectivity via Q.BICC-over-IP	Destination Point Code Service Indicator (=13) Originating Point Code CIC Range Start CIC Range End
SEP connectivity via TUP-over-IP (ITU only)	Destination Point Code Service Indicator (=4) Originating Point Code CIC Range Start CIC Range End
SCP/SEP connectivity via non-ISUP, non-SCCP, non-Q.BICC, non-TUP- over-IP	Destination Point Code Service Indicator (any value other than 3, 4*, 5, and 13)
* The service indicator value of 4 can be used in this instance if the DPC is an ANSI point code.	

Partial Routing Keys

Partially specified routing keys are explicitly, but not completely defined. These routing keys ignore some of the contents of the MSU. The parts of the MSU that are ignored are specific. For example, for the 'ignore **cic**' partial-key type, the destination point code (**dpc**), service indicator (**si**), and originating point code (**opc**) must be configured, but the circuit identification code (**cic**) field does not have to be configured. The other types of SS7 partial routing keys are as follows:

- **dpc**, **si**, and **opc** specified (ignore **cic** for CIC-based messages)
- **dpc** and **si** specified (ignore **ssn** for **sccp** messages)
- **dpc** and **si** specified (ignore **opc** and **cic** for CIC-based messages)
- **dpc** specified (ignore all but the **dpc** field)
- **si** specified (ignore all but the **si** field)

Default Routing Keys

Default routing keys do not need any part of the MSU specified. This routing key can be used to carry any SS7 MSU, regardless of the type of MSU or the fields that make up the MSU. The EAGLE 5 ISS can support two default routing keys, one created by administrative commands and one entered by Dynamic Routing Key Registration.

Routing Key Tables

Each IP card has a Routing Key table that maps SS7 routing keys to IP connections, as illustrated by the example in [Table 2-4](#). MSUs that match the parameters in a given row are sent over one of the IP connections shown for that row (up to 16 IP connections can be defined for a single routing key). Multiple IP connections for a given row allow load sharing. In addition, multiple routing keys can be used to send traffic to a single IP connection.

Each IP card's Routing Key table can contain up to 1000 entries (if there are any dual-slot DCM cards) or 2500 entries (if all IP cards are SSED CM cards). Entries in the Routing Key table can be either of the following:

- Static — these entries are defined by the user using the **ent-appl-rtkey** command entered through the OAM, saved on disk, and reloaded to each IP card upon reset. Static entries can be full, partial, or default routing keys. The static entries in one IP card's Routing Key table are identical to the static entries in the other IP card's table. Static entries can be changed by the **chg-appl-rtkey** command or deleted by the **dlt-appl-rtkey** command.
- Dynamic — these entries are added to or deleted from the table when a remote computer sends a message to the EAGLE 5 ISS. Dynamic entries allow an IP connection to automatically direct traffic towards, or away from, itself. A dynamic entry can have the same parameters as a static entry and can be full, partial, or default routing keys. When the **ss7ipgw** or **ipgwi** application transmits an MSU, it looks for a matching dynamic entry before looking for a static entry. When an IP connection fails, all dynamic entries associated with the IP connection are deleted. The dynamic entries in one IP card's Routing Key table may differ from the other IP card's table depending on messages received from other IP nodes. Dynamic entries can be deleted by receipt of a message from the IP connection, by failure of the IP connection, or by the **dlt-appl-rtkey** command.

NOTE: Dynamic routing keys are not created from MSUs containing ITU international or 14-bit ITU national spare point codes.

[Table 2-4](#) shows a sample Routing Key table that has one static entry and one dynamic entry for an SSCP/TCAP-over-IP connection; one static entry each for an ISUP, Q.BICC, and TUP-over-IP connection; and a non-SCCP/non-ISUP/ non-Q.BICC/non-TUP connection.

Table 2-4. Example SS7 Routing Key Table

Location	SS7 DPC Routing Key Parameter	SS7 SI Routing Key Parameter	SS7 SSN Routing Key Parameter	SS7 OPC Routing Key Parameter	CIC START Routing Key Parameter	CIC END Routing Key Parameter	Name of IP Sockets that carry traffic for that Routing Key
DPC-SI-SSN routing key for SSCP/TCAP-over-IP connectivity							
Static	5-5-5	03	6	-	-	-	kchlr11201 kchlr21201 kchlr11203 kchlr21203
1105	5-5-5	03	6	-	-	-	kchlr31205 kchlr41205
ISUP-CIC routing key for ISUP-over-IP connectivity							
Static	5-5-6	05	-	4-4-4	1	100	dnmsc11201 dnmsc21201 dnmsc11203 dnmsc21203
Q.BICC-CIC routing key for Q.BICC-over-IP connectivity							
Static	4363	13	-	5834	48486	48486	lpmsg11204 lpmsg21204 lpmsg31204
TUP-CIC routing key for TUP-over-IP connectivity							
Static	1-44-2	04	-	2-5-1	3948	3948	lpmsg11205 lpmsg21205 lpmsg31205
DPC-SI routing key for non-SCCP/non-ISUP/non-Q.BICC/non-TUP connectivity							
Static	5-5-7	02					sfh1r11204

Routing Key Lookup Hierarchy

To facilitate the delivery of Message Signaling Units (MSUs) that do not match full routing key entries in the Routing Key table, each MSU is processed and delivered according to a specific routing key lookup hierarchy. The hierarchy guarantees that the MSU is delivered to the best possible location based on the MSU's closest match in the Routing Key table, and also prevents MSUs without full routing key matches from being discarded. [Table 2-5](#) defines the routing key lookup hierarchy.

Table 2-5. Routing Key Lookup Hierarchy

Type of MSU	Lookup Order per MSU Type	Segment of MSU that Must Match Routing Key	Routing Key Type
CIC	1	dpc + si+ opc+cic	Full
	2	dpc + si + opc (ignore cic)	Partial
	3	dpc + si (ignore opc & cic)	Partial
	4	dpc (ignore si, opc & cic)	Partial
	5	si (ignore dpc, opc & cic)	Partial
	6	None	Default
SCCP	1	dpc + si + ssn	Full
	2	dpc + si (ignore ssn)	Partial
	3	dpc (ignore si & ssn)	Partial
	4	si (ignore dpc & ssn)	Partial
	5	None	Default
OtherSI	1	dpc + si	Full
	2	dpc (ignore si)	Partial
	2	si (ignore dpc)	Partial
	3	None	Default

When an MSU has an **si** value of **5**, **13**, or **4** (ITU only), it is a CIC message. Messages with an **si** value of **3** are SCCP messages. All other MSUs are considered OtherSI messages. The EAGLE 5 ISS first tries to match each MSU with a full routing key and second with one of the partial keys as numbered in ascending order in the table. Third, if no segment of the routing key matches either full or partial routing keys, the EAGLE 5 ISS assigns the MSU a default routing key.

Support for MTP Status Functions

This feature, available only on IP cards that support the **ss7ipgw** and **ipgwi** applications, allows the Message Transfer Part (MTP) status of point codes in the SS7 networks to be made available to IP-connected media gateway controllers (MGCs) and IP-SCPs. This feature is similar to the MTP3 network management procedures used in an SS7 network.

This feature enables an IP device to:

- Divert traffic from a secure gateway that is not able to access a point code that the mated secure gateway can access
- Audit point code status
- Build up routing tables before sending traffic
- Be warned about network congestion
- Abate congestion (**ss7ipgw** application only)

- Obtain SS7 User Part Unavailability status

SNMP Agent Implementation

This feature implements a Simple Network Management Protocol (SNMP) agent on each IP card that runs the **ss7ipgw**, **ipgwi**, **iplim**, or **iplimi** applications. SNMP is an industry-wide standard protocol used for network management. SNMP agents interact with network management applications called Network Management Systems (NMSs).

Supported Managed Object Groups

The SNMP agent maintains data variables that represent aspects of the IP card. These variables are called managed objects and are stored in a management information base (MIB). The SNMP protocol arranges managed objects into groups. [Table 2-6](#) shows the groups that are supported.

Table 2-6. SNMP Object Groups

Group Name	Description	Contents
<i>system</i>	Text description of agent in printable ASCII characters	System description, object identifier, length of time since reinitialization of agent, other administrative details
<i>interfaces</i>	Information about hardware interfaces on the IP card	Table that contains for each interface, speed, physical address, current operational status, and packet statistics
<i>ip</i>	Information about host and router use of the IP	Scalar objects that provide IP-related datagram statistics, and 3 tables: address table, IP-to-physical address translation table, and IP-forwarding table
<i>icmp</i>	Intranetwork control messages, representing various ICMP operations within the IP card	26 scalar objects that maintain statistics for various Internet Control Message Protocol (ICMP) messages
<i>tcp</i>	Information about TCP operation and connections	14 scalar objects that record TCP parameters and statistics, such as the number of TCP connections supported and the total number of TCP segments transmitted, and a table that contains information about individual TCP connections
<i>udp</i>	Information about UDP operation	4 scalar objects that maintain UDP-related datagram statistics, and a table that contains address and port information
<i>snmp</i>	Details about SNMP objects	30 scalar objects, including SNMP message statistics, number of MIB objects retrieved, and number of SNMP traps sent

Supported SNMP Messages

The SNMP agent interacts with up to two NMSs by:

- Responding to *Get* and *GetNext* commands sent from an NMS for monitoring the IP card.
- Responding to *Set* commands sent from an NMS for maintaining the IP card and changing managed objects as specified.
- Sending *Trap* messages to asynchronously notify an NMS of conditions such as a link going up or down. *Traps* provide a way to alert the NMS in a more timely fashion than waiting for a *Get* or *GetNext* from the NMS. Two hostnames, DCMSNMPTRAPHOST1 and DCMSNMPTRAPHOST2, are utilized to specify the SNMP NMS to which traps are sent. In this release, only the following traps are supported:

- *coldStart*, sent one time only when the IP stack initialization occurs on the IP card as part of boot processing
- *linkUp*, sent when one of the ports on the IP card initially comes up or recovers from a previous failure
- *linkDown*, sent when one of the ports on the IP card fails

When a trap occurs at the IP card agent, the agent sends the trap to each of the SNMP specific host names that can be resolved to an IP address. Resolution is based on configuration data in the **chg-ip-card** command (or default data) which specifies DNS search order and DNS information.

Deviations from SNMP Protocol

[Table 2-7](#) shows how the EAGLE 5 ISS deviates from the standard SNMP protocol definition.

Table 2-7. Deviations from SNMP Protocols

Group	Variable Name	Usage	Deviation
system	<i>sysContact</i>	Text identification of contact information for agent	Cannot be set by <i>Set</i> command; may be set only by chg-sg-opts command.
	<i>sysLocation</i>	Physical location of agent	Cannot be set by <i>Set</i> command; internally set using configuration data already available; set to <CLLI>-<slot of IP card>
	<i>sysName</i>	Administratively assigned name for agent	Cannot be set by <i>Set</i> command; internally set using configuration data already available; set to <CLLI>-<slot of IP card>
interface	<i>ifAdminStatus</i>	Desired state of the interface	Cannot be set by <i>Set</i> command (to ensure that an NMS does not disrupt SS7 traffic by placing an IP interface in a nonoperable state)
ip	<i>ipForwarding</i> <i>ipDefaultTTL</i> <i>ipRoute Dest</i> <i>ipRouteIfIndex</i> <i>ipRouteMetric1-5</i> <i>ipRouteNextHop</i> <i>ipRouteType</i> <i>iprouteAge</i> <i>ipRouteMask</i>	IP route-specific values	Cannot be set by <i>Set</i> command
	<i>ipNetToMediaIfIndex</i> <i>ipNetToMediaPhysAdress</i> <i>ipNetToMediaNetAddress</i> <i>ipNetToMediaType</i>	IP-address specific information	Can be set by <i>Set</i> command, but not saved across IP card reloads

Group	Variable Name	Usage	Deviation
<i>tcp</i>	<i>tcpConnState</i>	State of a TCP connection	Cannot be set by <i>Set</i> command
<i>snmp</i>	<i>snmpEnableAuthenTraps</i>	Indicate whether agent is permitted to generate authentication failure traps	Cannot be set by <i>Set</i> command

Mixed Networks Using the ANSI/ITU MTP Gateway Feature

The optional ANSI/ITU MTP Gateway feature, now also available for IP networks, and the addition of the **iplimi** and **ipgwi** applications enables the EAGLE 5 ISS to act as an interface between nodes that support ANSI, ITU-I, and ITU-N protocols. For more information on the ANSI/ITU MTP Gateway feature, contact your Tekelec Sales Representative.

[Figure 2-15](#) shows an example of a complex network that includes all these types of nodes. [Table 2-8](#) provides more detail about the nodes, network types, and point codes used in this example.

The following SS7 protocol constraints determine how the network must be configured:

- A linkset is a group of links that terminate into the same adjacent point code. All links in the linkset can transport compatible MSU formats. The network type of the linkset is the same as the network type of the adjacent point code assigned to the linkset.
- When nodes in different networks need to communicate, each node must have either a true point code or an alias point code for each of the network types. For example, if Node 1 (in an ANSI network) needs to communicate to Node 7 (in an ITU-N network), Node 1 must have an ANSI true point code and an ITU-N alias point code, while Node 7 must have an ITU-N true point code and an ANSI alias point code.
- The systems are usually deployed as mated pairs. The links connecting the EAGLE 5 ISS to its mate are C links. Each EAGLE 5 ISS must have a C linkset for each network type that the EAGLE 5 ISS connects to. Therefore, in [Figure 2-15](#), Nodes 5 and 6 are connected with three linksets, one each for ANSI traffic, ITU-I traffic, and ITU-N traffic.
- To perform routing, the EAGLE 5 ISS must convert the routing labels in MSUs. To perform this conversion, every destination point code (DPC), originating point code (OPC), and concerned point code must be defined in the Routing table. Even if the EAGLE 5 ISS does not route MSUs to these nodes, they must be provisioned in the Routing table to provision the alias point codes required in the conversion process.

Figure 2-15. Complex Network with ANSI, ITU-I, and ITU-N Nodes




Table 2-8. Nodes and Point Codes in Complex Network Example

Node	Node Type	Network Types Supported	True Point Codes ¹	Alias Point Codes ²
1	SSP	ANSI	A1	N1, I1
2	SSP	ANSI	A2	I2
3	SSP	ANSI	A3	N3, I3
4	SSP	ANSI	A4	N4
5	STP (with IP ⁷ Secure Gateway functionality)	ANSI, ITU-N, ITU-I	A5, N5, I5	
6	STP (with IP ⁷ Secure Gateway functionality)	ANSI, ITU-N, ITU-I	A6, N6, I6	

Node	Node Type	Network Types Supported	True Point Codes ¹	Alias Point Codes ²
7	STP (with IP 7 Secure Gateway functionality)	ITU-N, ITU-I	N7, I7	A7
8	STP (with IP 7 Secure Gateway functionality)	ITU-N, ITU-I	N8, I8	A8
9	STP (with IP 7 Secure Gateway functionality)	ITU-N, ITU-I	N9, I9	A9
10	STP (with IP 7 Secure Gateway functionality)	ITU-N, ITU-I	N10, I10	A10
11	SSP	ITU-N	N11	I11, A11
12	SSP	ITU-I	I12	N12, A12
13	SSP	ITU-I	I13	N13, A13
14	SSP	ITU-N	N14	I14, A14
15	SSP	ITU-I	I15	N15, A15
16	SSP	ITU-I	I16	N16, A16

Notes: 1. A true point code (TPC) defines a destination in the EAGLE 5 ISS's destination point code table. A TPC is a unique identifier of a node in a network. An STP (with IP7 Secure Gateway functionality) must have a TPC for each network type that the EAGLE 5 ISS connects to. An SSP connects to only one type of network, so it has only one TPC.

2. An alias point code is used to allow nodes in other networks to send traffic to and from a EAGLE 5 ISS when that EAGLE 5 ISS does not have a TPC for the same network type.

The configured links and point codes in the complex network shown in [Figure 2-15](#) allows most nodes to communicate with other nodes. However, note that Node 2 cannot communicate with Node 13 or Node 16, or with any node in the ITU-N network because Node 2 does not have an ITU-N alias point code.

Routing and Conversion Within a Single Network Type

The following steps demonstrate how an EAGLE 5 ISS routes and converts when an ITU-N node sends an MSU to another ITU-N node. For example, assume that Node 11 in [Figure 2-15](#) sends an MSU to Node 14. The MSU is routed from Node 11 to Node 7 to Node 5 to Node 9 to Node 14. The following steps describe the actions performed at Node 5 (an STP with IP 7 Secure Gateway functionality):

1. An ITU-N formatted MSU (which has a network identifier=01b and a 14-bit destination point code/originating point code) is received on an **iplimi** card (for this example at location 1103).
2. MSU discrimination is performed with the following substeps:
 - a. Compare the received network identifier (NI) to the list of valid NIs. (Each configured linkset for a receiving link has a defined list of valid NIs.) If the comparison fails, the MSU is discarded and an STP measurement is logged. In this example, the received NI (01b) is valid for an **iplimi** card.
 - b. Extract the NI and destination point code (DPC) from the received MSU.
 - c. Determine whether the destination of the received MSU is this STP. If not (as is the case in this example), the MSU is passed to the STP's routing function.

3. The routing function selects which outgoing link to use by searching a routing table for an entry for the DPC (N14 in this example). The routing table identifies another **iplimi** card (for this example at location 1107) to be used for the outgoing link.
4. Determine whether MSU conversion is required (required when the source network type is not the same as the destination network type). In this example, both Node 11 and Node 14 are ITU-N nodes, so conversion is not required.
5. Forward the MSU across the Interprocessor Message Transport (IMT) bus from location 1103 to location 1107, where the MSU is transmitted out the link towards Node 14.

Routing and Conversion Between Different Network Types

The routing and conversion steps performed by a EAGLE 5 ISS when an ITU-N node sends an MSU to an ITU-I node are the same as the steps shown in the [Routing and Conversion Within a Single Network Type](#) section, except for the conversion step.

For example, assume that Node 11 in [Figure 2-15](#) sends an MSU to Node 16. The MSU is routed from Node 11 to Node 7 to Node 5 to Node 9 to Node 16. The following steps describe the actions performed at Node 5 (an EAGLE 5 ISS with IP⁷ Secure Gateway functionality):

1. Perform step 1 through step 3 as shown in the [Routing and Conversion Within a Single Network Type](#) section. In this example, assume that the routing function determines that the outgoing link is configured on the IP card at location 1203.
2. Determine whether MSU conversion is required (required when the source network type is not the same as the destination network type). In this example, Node 11 is an ITU-N node and Node 16 is an ITU-I node, so conversion is required. Conversion consists of two phases: Message Transfer Part (MTP) conversion and user part conversion.
3. Perform MTP conversion (also known as routing label conversion). The following parts of the MSU can be affected by MTP conversion:
 - Length indicator — for ITU-N to ITU-I conversion, the length of the MSU does not change
 - Service Information Octet (SIO), Priority — for conversion to ITU, the priority is set to 0. For conversion to ANSI, the priority is set to a default of 0, which can later be changed based on user part conversion.
 - Service Information Octet (SIO), Network Indicator — the NI bits are set to the NI value for the destination node. In this example, NI is set to 00b.
 - Routing Label, Destination Point Code (DPC) — the DPC is replaced with the destination's true point code. In this example, N16 is replaced by I16.
 - Routing Label, Originating Point Code (OPC) — the OPC is replaced with the appropriate network type's alias point code for the originating node. In this example, N11 is replaced with I11.
 - Routing Label, Signaling Link Selector (SLS) — no SLS conversion is required between ITU-I and ITU-N nodes. However, if one of the nodes were an ANSI node, conversion would be required between a 5-bit or 8-bit SLS for ANSI nodes and a 4-bit SLS for ITU nodes.
4. Perform user part conversion, if necessary. Currently, only SCCP traffic and only network management messages have the Message Transfer Part (MTP) converted. All other user parts have their data passed through unchanged.
5. Forward the MSU across the Interprocessor Message Transport (IMT) bus from location 1103 to location 1203, where the MSU is transmitted out the link towards Node 16.

Nagle's Algorithm

Nagle's Algorithm is a 1-bit, Boolean socket option that controls message packet transmission timing. Nagle's Algorithm applies only to TALI sockets. Sockets can be set to 1 = Enable or 0 = Disable. Nagle's Algorithm is disabled by default for all sockets, which means that every message is transmitted over the Ethernet as soon as possible. When this socket option is disabled, it minimizes the time it takes for messages to be transmitted but increases the overall number of packets transmitted, which results in increased Central Processing Unit (CPU) utilization and less efficient Local Area Network (LAN) utilization.

Enabling Nagle's Algorithm allows the IP stack to hold on to messages for a period of time in an effort to pack multiple messages into a single TCP packet. Though message latency increases, fewer packets are generated and processed, resulting in lower CPU and better LAN utilization. At high rates of traffic through a socket, message latency is minimal because the threshold packet size is reached (messages fill the packet) very quickly, which causes the stack to transmit the packet.

Administrators can choose to enable or disable Nagle's Algorithm depending on the parameters that work best for the EAGLE 5 ISS. Nagle's Algorithm also can be toggled between being 1) enabled when the amount of messages that are transmitted is higher than the threshold limit and 2) disabled when transmission rates are lower than the threshold.

For more information on how to set up these features by altering the Database Communication Module Parameter Set (DCMPS), see the *Commands Manual*.

Type of Service (TOS)

This 8-bit, Type of Service (TOS) socket option is also used to prioritize the flow of network traffic. Packets can be routed differently according to the TOS value set in the IP header. The TOS field resides within the message's IP header and identifies the network router's priorities. Tekelec does not specify how the TOS bits should be set. The administrator can choose how to set them. [Figure 2-16](#) illustrates a TOS field setup. For more information on how to set up these features by altering the Database Communication Module Parameter Set (DCMPS), see the *Commands Manual*.

Figure 2-16. 8-bit TOS Field

7	6	5	4	3	2	1	0
		Reliability	Throughput	Delay	IP precedence		

For Differentiated Service (DiffServ) the TOS field is referred to as the Differentiated Service (DS) field. The priorities of the DS field in the IP header can also be set through socket options. [Figure 2-17](#) illustrates a DS field setup.

Figure 2-17. DS Field

7	6	5	4	3	2	1	0
CU		DSCP					

ISUP Normalization


This feature allows an EAGLE 5 ISS to deliver ISUP messages that arrive at the EAGLE 5 ISS from the public switched telephone network (PSTN) in a country specific ISUP variant format, to an IP device in a normalized ISUP format. Likewise, it enables traffic received from an IP device in normalized ISUP format to be delivered to a PSTN link in the appropriate country variant format. The normalized ISUP messages are carried in TALI packets. Data is contained in the TALI packet itself to specify what national network (or what country) the ISUP message originated from or is destined to and what ISUP variant the original PSTN message was formatted in.

This feature allows an IP device (for example, an MGC providing Class 4 Tandem functionality) connected to an EAGLE 5 ISS to perform call setup for multiple countries without knowledge of the various countries' ISUP message formats. The MGC needs only to support encode and decode functionality for the normalized format and does not have to support encode and decode functionality for each ISUP variant.

The EAGLE 5 ISS and IP device are able to support these call scenarios:

1. Intra-Country Call
2. Inter-Country Call

This capability is shown in [Figure 2-18](#) .

Figure 2-18. ISUP Normalization Supporting Multiple ISUP Variants

Although [Figure 2-18](#) shows a separate soft-switch (that is, the Media Gateway/Media Gateway Controller pair) per country, this feature does not prevent a single soft-switch, communicating with a single pair of IPGWl cards, from performing call setup for multiple countries.

Referring to [Figure 2-18](#), the 'normalized ISUP traffic' is used in the communication between the EAGLE 5 ISS and the devices on the IP network. The traffic carried over the DS0 links to Country A SSPs and Country B SSPs (on the PSTN side of the EAGLE 5 ISS) continues to be formatted in the ISUP national variant format.

Normalized ISUP refers to the ISUP messages that are passed between the IP card running the IPGWI application (IPGWI card) and the IP device when this feature is used. The Normalized ISUP message is based on ETSI V3 ISUP, but provides a method to pass along variant-specific data that does not map cleanly to ETSI V3. This allows the IP device to support decode/state machine/encode capabilities for Normalized ISUP only, rather than having to support these capabilities for multiple ISUP variants. Note that Normalized ISUP messages only exist in the IP network and are never present in the PSTN.

The variant specific information is retained as part of the ISUP normalized TALI message to guarantee that intra-country calling features which require variant specific messages and parameters can continue to work for those intra-country calls.

The normalization function is performed entirely on the IPGWI card in the EAGLE 5 ISS. Everything presented to the MGCs that are using this feature is in Normalized ISUP format. Everything that is presented to the MTP3 portion of the IPGWI card (to be routed back to a DS0 link towards the PSTN) is in the format for a specific ISUP variant. Each DS0 LIM (or any LIM in the EAGLE 5 ISS other than the IPGWI card) receives MSUs from the PSTN wire and from the IMT in the same ISUP variant format. The DS0 LIMS do not know how to perform ISUP Normalization, and do not even know that it is occurring on the IPGWI cards.

The ISUP Normalization feature supports the normalization of the ISUP variants shown in [Table 2-9](#) :

Table 2-9. ISUP Variants Supported by this Feature

ISUP Variant	Part No.	PSTN Category	PSTN ID
ISUP Normalization	893000201	1	*
ITU Q.767 Normalization	893000501	1	1
ESTI V3 Normalization	893000601	1	2
UK PNO-ISC7 Normalization	893000401	1	3
German ISUP Normalization	893000301	1	4
French ISUP Normalization	893-0007-01	1	5
Sweden ISUP Normalization	893-0008-01	1	6
Belgium ISUP Normalization	893-0009-01	1	7
Netherlands ISUP Normalization	893-0010-01	1	8
Switzerland ISUP Normalization	893-0011-01	1	9
Austria ISUP Normalization	893-0012-01	1	10
Italy ISUP Normalization	893-0013-01	1	11
Ireland ISUP Normalization	893-0014-01	1	12
India ISUP Normalization	893-0015-01	1	13
Malaysia ISUP Normalization	893-0016-01	1	14
Vietnam ISUP Normalization	893-0017-01	1	15
South Africa ISUP Normalization	893-0018-01	1	16
Argentina ISUP Normalization	893-0019-01	1	17

ISUP Variant	Part No.	PSTN Category	PSTN ID
Chile ISUP Normalization	893-0020-01	1	18
Venezuela ISUP Normalization	893-0021-01	1	19
Mexico ISUP Normalization	893-0022-01	1	20
Brazil ISUP Normalization	893-0023-01	1	21
Spain ISUP Normalization	893-0024-01	1	22
Colombia ISUP Normalization	893-0025-01	1	23
Peru ISUP Normalization	893-0026-01	1	24
Hong Kong ISUP Normalization	893-0027-01	1	25
China ISUP Normalization	893-0028-01	1	26
Japan ISUP Normalization	893-0029-01	1	27
Korea ISUP Normalization	893-0030-01	1	28
Taiwan ISUP Normalization	893-0031-01	1	29
Philippines ISUP Normalization	893-0032-01	1	30
Singapore ISUP Normalization	893-0033-01	1	31
Australia ISUP Normalization	893-0034-01	1	32
Reserved for future definition by Tekelec		2 through 4095	
Available for user-defined categories		4095 through 65535	

The Quantity Control feature allows a customer to provision a specified quantity of user-defined variants within the PSTN categories 4096 - 65535. Each Quantity Control Feature is associated with a specific quantity of variants. To provision user-defined variants, it is necessary to purchase the appropriate Feature Access Keys from Tekelec. Variants enabled using the Quantity Control feature do not have associated PSTN Presentation values.

The part number for user-defined variants is 893-0100-nn, where nn is a number ranging from 01 to 20. Use part number 893-0100-01 to order one new variant, 893-0100-05 to order five new variants, and so on.

It is important to understand that for each variant that is supported, only two conversions are needed. For example:

- From ISUP Variant A -> Normalized ISUP
- From Normalized ISUP -> ISUP Variant A

To clarify this, the normalization on the IPGWI card never converts from ISUP Variant A to ISUP Variant B.

However, a call setup scenario could exist where two variants are used. In this case the conversions would go from:
Variant A -> Normalized -> Variant B

But the conversions cannot all occur at once. Two separate conversions occur, possibly on different nodes.

The normalization of ANSI ISUP messages is not supported. The normalization of ISUP MSUs only occur on the cards running the IPGWI application and not the SS7IPGW application.

PSTN Presentation

PSTN presentation is a 32-bit value indicating the format of the MSU Level 3 payload while it exists in the PSTN (see [Figure 2-19](#)). When using this feature, the PSTN presentation is configured in the IP Routing Key table and appears in “XSRV-xnrm” and “XSR-xmtp” packet headers.

The PSTN presentation's primary uses are as follows:

1. To indicate to the IPGWI card how to decode an ISUP MSU received from the PSTN when converting it to Normalized format for transmission over a socket configured for ISUP via XSRV-xmm.
2. To indicate to the IPGWI card how to encode an ISUP MSU for delivery to the PSTN when converting a Normalized ISUP packet received from an IP device.
3. To indicate to an IP device how to decode the Variant Specific portion (Part 2) of a received 'XSRV-xnrm' TALI packet.
4. To indicate to an IP device how to decode the raw MSU payload of a received “XSRV-xmtp” TALI packet (not limited to ISUP messages).

The PSTN Presentation consists of two parts, a PSTN Category and a PSTN ID:

- PSTN Category – provides a way of logically partitioning groups of PSTN IDs
- PSTN ID – provides unique identification of presentations within a given category

Figure 2-19. Format of PSTN Presentation

MSB	LSB
PSTN Category (16 Bits)	PSTN ID (16 Bits)

Some PSTN Categories are reserved for specific vendor's use and definition. For example, EAGLE 5 ISS's reserve category #1 for defining ISUP variants supported by this feature. [Table 2-9](#) lists valid PSTN categories and IDs.

The list of Tekelec-defined and user-defined PSTNs can be displayed by using the **rtrv-psn-pres** command, as illustrated in the following example:

```

PSTNCAT   PSTNID       PSTNDESC
00001     00001        ITU Q.767
00001     00002        ETSI V3
00001     00003        UK PNO-ISC7
00001     00004        GERMAN ISUP
00001     00020        MEXICO
04096     01000        User Defined 4096/1000

```

Note that a PSTN Presentation of 0 (that is, Category = 0 and ID = 0) is defined as unknown and is the default value in routing keys and TALI XSRV headers.

Other PSTN Categories are available for implementation specific definition by the customer. For example, customer X may use category 4096 to define a set of PSTN IDs (that is, BTNUP, French TUP, etc.) that exists in its network and are routed over IPGWI links.

The PSTN Presentation (Category, ID, and description) is provisioned using the **ent-psn-pres** command. This command may be used to define values within the Tekelec-defined range (PSTN Category 0-4095) as long

as there exists an associated ON/OFF Control Feature, and its status is ENABLED. This command may be used to define values within the user-defined range (PSTN Category 4096-65535) as long as there exists an associated ISUP Normalization Quantity Control Feature and its status is ENABLED and its capacity is not going to be exceeded.

This command also creates a new entry in the ISUP Variant table initialized to default values. There must be an available entry in the table or this command will be rejected.

The **chg-pstn-pres** command changes the descriptive text of a previously provisioned PSTN Presentation value.

The **dlt-pstn-pres** command deletes a previously provisioned PSTN Presentation value. The entry in the ISUP Variant table associated with the deleted PSTN will be marked as available. All of the associated ISUP messages and parameters that have been provisioned for the PSTN/Variant with the **chg-isupvar-attrib** command will also be deleted.

The user cannot delete the PSTN for Normalized ISUP (ETSI V3).

Deleting the PSTN Category or ID may cause a loss of traffic if SS7IP routing keys exist using that PSTN value. The user should use caution when performing this action and must enter the **force** parameter with the **dlt-pstn-pres** command.

The **chg-isupvar-attrib** command is used to provision the ISUP message and parameter database for a variant based on the PSTN Presentation value. This command will allow the administrator to:

- Specify/change the defined message-type-codes and parameter-codes for the variant.
- Specify/change the optional parameters that are supported for each message-type.
- Specify/change the mandatory-fixed and mandatory-variable-length parameters that are supported for each message-type.
- Specify/change the minimum valid length for each parameter.
- Specify/change for each message or message/parameter combination, a custom “action”. An “action” parameter for this command will allow the administrator to specify one of the following three actions:
 - NONE - this is the default and it means the standard “normalization” conversion rules apply, i.e. do nothing special.
 - CONVERT - a special conversion routine will be invoked by software when it receives the message or message/parameter. For the Tekelec-defined variants, there may be certain messages or parameters that require special handling. Tekelec will write special conversion software for these cases. This value may be entered for user-defined variants, however software will ignore it.
 - PASSTHRU - If specified with a message, then PASSTHRU means the specified message should be passed through unconverted using the raw MTP3 transfer method. If specified in a message/parameter combination, then PASSTHRU means that parameter, when received in that message, should be passed through to the Normalized section of the message (ignoring the DEFINED/SUPPORTED attributes of the Normalized specification).

The **copy-isupvar-attrib** command copies a “source” variant database to a “destination” variant database. This command provides the user with a quick way to provision a variant by copying a source variant database that has a similar ISUP protocol definition. The user can then use the **chg-isupvar-attrib** command to make the changes for the new protocol.

The PSTN Presentation is used to identify both the source and destination table entries. Both entries must be previously defined PSTN Presentation values, i.e. either a Tekelec-defined PSTN or a user-defined PSTN by the **ent-pstn-pres** command. Use the **rtrv-pstn-pres** command to display the only allowed values for the source and destination PSTNs.

If the source or destination variant is a Tekelec-defined PSTN value, then its associated ON/OFF Control Feature must be ENABLED.

The destination PSTN is not allowed to be Normalized ISUP (ETSI V3).

The **rtrv-isupvar-attrib** command displays the variant database provisioned by the **chg-isupvar-attrib** command. An assortment of displays is possible depending on the filters applied.

The following is an example of a possible output displaying all supported parameters for a specified message in a variant:

PSTNCAT	PSTNID	MSGCODE	ATTRIB	ACTION
00001	00005	04h	DEFINED	CONVERT

MSGCODE	PARMCODE	TYPE	ORDER	ACTION
04h	---	---	-	CONVERT
	10h	MF	1	NONE
	08h	MF	2	NONE
	09h	MV	1	CONVERT
	FEh	MV	2	NONE
	00h	OPT	-	NONE
	01h	OPT	-	NONE

The **chg-appl-rtkey** command accesses the ISUP variant table to determine if the PSTN Presentation value entered is valid. It evaluates both Tekelec-defined and user-defined variant PSTNs.

The [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure shows how to configure the EAGLE 5 ISS for ISUP Normalization feature.

IETF Adapter Layer Support

Overview

The current implementation of the IETF adapter layers in the EAGLE 5 ISS uses three adapter layers: SUA, M3UA, and M2PA. These adapter layers are assigned to SCTP associations which define the connection to the far end. An SCTP association is defined in the EAGLE 5 ISS by the local host name, the local SCTP port, the remote host name, and the remote SCTP port.

The three adapter layers used in the EAGLE 5 ISS are supported depending on the type of IP card being used for the IP connection. The SUA and M3UA adapter layers can be used only on IPGWx cards (cards running either the SS7IPGW or IPGWI applications). The M2PA adapter layer can be used only on IPLIMx cards (cards running either the IPLIM or IPLIMI applications).


SCTP associations on IPGWx cards, like TCP sockets, use routing keys to distinguish between the IP devices being connected to. TCP sockets are assigned directly to routing keys. SCTP associations cannot be assigned directly to routing keys. To get an SCTP association ultimately assigned to a routing key, the IETF adapter layers use the concept of the application server (AS). The SCTP association is assigned to an application server. One or more associations are normally actively processing traffic. A group of associations (up to 16) can be assigned to an application server. An application server, a logical entity serving a specific routing key, is assigned to a routing key. This results in assigning the SCTP association, up to a maximum of 16, to a routing key.

The IETF SUA and M3UA adapter layers are supported on IPGWx cards. These adapter layers support the full implementation of the AS and routing key for the EAGLE 5 ISS. SCTP associations assigned to IPGWx cards can be assigned to application servers and routing keys.

The IETF M2PA adapter layer is supported on IPLIMx cards. The M2PA adapter layer does not support application servers, therefore SCTP associations assigned to M2PA links on IPLIMx cards cannot be assigned to application servers.

[Figure 2-20](#) shows a typical configuration with four connections (SCTP associations) out of the EAGLE 5 ISS using IPGWx cards. Each association is connected to a process on the far end.

Figure 2-20. AS/Association Relationship




Interaction Between TALI and IETF Connections Within a Single EAGLE 5 ISS

The IP cards in the EAGLE 5 ISS can use both TCP sockets (TALI connections) and SCTP associations (IETF connections) to make IP connections to far end devices. An IP connection is defined as either a TCP socket or an SCTP association. The EAGLE 5 ISS may contain all TALI connections, all IETF connections, or a combination of both. [Figure 2-21](#) shows that a single EAGLE 5 ISS can communicate to far end devices using different adapter layers. Each IP card in the EAGLE 5 ISS can support both TCP sockets and application servers. However, on IPGWx cards, only one TCP socket can be assigned to a single routing key. If the routing key has a routing context value assigned to it, only one application server can be assigned to the routing key. If the routing key does not have a routing context value assigned to it, the application server can be assigned to a maximum of 2500 routing keys.

An IPGWx card can contain a maximum of 50 connections. The EAGLE 5 ISS allows a maximum of 64 IPGWx cards, resulting in a maximum of 3200 connections for all IPGWx cards.


An IPLIMx card can have only one connection for each signaling link assigned to the card. The dual-slot DCM can contain only two signaling links, resulting in a maximum of two IP connections on these cards. The single-slot EDCM can contain a maximum of eight signaling links, resulting in a maximum of eight IP connections for this card. The E5-ENET card can contain a maximum of 16 signaling links, resulting in a maximum of 161 IP connections for this card.

The EAGLE 5 ISS can contain a maximum of 4000 IP connections, between IPGWx cards and IPLIMx cards.


Figure 2-21. TCP Socket/SCTP Association Relationship

Feature Components

The EAGLE 5 ISS with IP⁷ Secure Gateway functionality is used as a signaling gateway between the PSTN and IP networks as shown in [Figure 2-22](#). This figure shows that signaling gateways interface with media gateway controllers (MGCs) and MGCs interface with media gateways (MGs).

Figure 2-22. SG/MGC/MG Network Diagram

If a TCP socket is used to make the IP connection to other devices, the EAGLE 5 ISS uses the TALI protocol on top of TCP to communicate to other devices, as shown in [Figure 2-23](#).

Figure 2-23. TALI Protocol Stack (IPGWx and IPLIMx)

To provide a signaling gateway solution that will be able to communicate with a larger number of IP devices, the EAGLE 5 ISS needs to be able to communicate with multiple MGCs which are using SCTP as the transport layer and M3UA, M2PA, or SUA as an adapter layer. On an IPLIMx card, the M2PA adapter layer can be used with SCTP as shown in [Figure 2-24](#) . On an IPGWx card, the M3UA and SUA adapter layers can be used with SCTP as shown in [Figure 2-25](#) .



Figure 2-24. IPLIMx Protocol Stack with SCTP as the Transport Layer

Figure 2-25. IPGWx Protocol Stack with SCTP as the Transport Layer

The EAGLE 5 ISS supports many (mapping & transport) protocol combinations. One connection can be running TALI/TCP while another connection is running M3UA/SCTP, and a third connection is running M2PA/SCTP. These three connections can be on the same card (provided the card is an IPGWx card) and even a part of the same routing key (if the card is an IPGWx card). If the card is an IPLIMx card, only M2PA connections can be assigned to the card.

This mixture allows greater configurability for the user. The EAGLE 5 ISS does not support TALI over SCTP, or IETF adapter layers over TCP.

SUA Layer

The SUA layer, only supported on IP cards running either the SS7IPGW or IPGWI applications (IPGWx cards), was designed to fit the need for the delivery of SCCP-user messages (MAP & CAP over TCAP, RANAP, etc.) and new third generation network protocol messages over IP between two signaling endpoints. Consideration is given for the transport from an SS7 signaling gateway to an IP signaling node (such as an IP-resident database). This protocol can also support transport of SCCP-user messages between two endpoints wholly contained within an IP network. The layer is expected to meet the following criteria:

- Support for transfer of SS7 SCCP-User Part messages (for example, TCAP, RANAP, etc.)
- Support for SCCP connectionless service.
- Support for the seamless operation of SCCP-User protocol peers
- Support for the management of SCTP transport associations between a signaling gateway and one or more IP-based signaling nodes).
- Support for distributed IP-based signaling nodes.
- Support for the asynchronous reporting of status changes to management

Depending upon the SCCP-users supported, the SUA layer supports the four possible SCCP protocol classes transparently. The SCCP protocol classes are defined as follows:

- Protocol class 0 provides unordered transfer of SCCP-user messages in a connectionless manner.
- Protocol class 1 allows the SCCP-user to select the in-sequence delivery of SCCP-user messages in a connectionless manner.
- Protocol class 2 allows the bi-directional transfer of SCCP-user messages by setting up a temporary or permanent signaling connection.
- Protocol class 3 allows the features of protocol class 2 with the inclusion of flow control. Detection of message loss or mis-sequencing is included.

Protocol classes 0 and 1 make up the SCCP connectionless service. Protocol classes 2 and 3 make up the SCCP connection-oriented service.

The SUA layer supports the following SCCP network management functions:

- Coord Request
- Coord Indication
- Coord Response
- Coord Confirm
- State Request
- State Indication
- Pcstate Indication

The SUA layer provides interworking with SCCP management functions at the signaling gateway for seamless inter-operation between the SCN network and the IP network. This means:

- An indication to the SCCP-user at an application server process that a remote SS7 endpoint/peer is unreachable.
- An indication to the SCCP-user at an application server process that a remote SS7 endpoint/peer is reachable.
- Congestion indication to SCCP-user at an application server process.
- The initiation of an audit of remote SS7 endpoints at the signaling gateway.

M3UA Layer

The M3UA layer, supported on only IPGWx cards, was designed to fit the need for signaling protocol delivery from an SS7 signaling gateway to a media gateway controller (MGC) or IP-resident database. The layer is expected to meet the following criteria:

- Support for the transfer of all SS7 MTP3-User Part messages (for example, ISUP, SCCP, TUP, etc.)
- Support for the seamless operation of MTP3-User protocol peers
- Support for the management of SCTP transport associations and traffic between a signaling gateway and one or more MGCs or IP-resident databases
- Support for MGC or IP-resident database process fail-over and load-sharing
- Support for the asynchronous reporting of status changes to management

The M3UA layer at an application server provides a set of primitives at its upper layer to the MTP3-Users that is the equivalent of those provided by the MTP Level 3 to its local users at an SS7 SEP. In this way, the ISUP or SCCP layer at an application server process is unaware that the expected MTP3 services are offered remotely from

an MTP3 Layer at a signaling gateway, and not by a local MTP3 layer. The MTP3 layer at a signaling gateway may also be unaware that its local users are actually remote user parts over the M3UA layer. The M3UA layer extends access to the MTP3 layer services to a remote IP-based application. The M3UA layer does not provide the MTP3 services.

The M3UA layer provides the transport of MTP-TRANSFER primitives across an established SCTP association between a signaling gateway and an application server process and between IPSPs. The MTP-TRANSFER primitives are encoded as MTP3-User messages with attached MTP3 Routing Labels as described in the message format sections of the SCCP and ISUP recommendations. In this way, the SCCP and ISUP messages received from the SS7 network are not re-encoded into a different format for transport to or from the server processes. All the required MTP3 Routing Label information (OPC, DPC, and SIO) is available at the application server process and the IPSP as is expected by the MTP3-User protocol layer.

At the signaling gateway, the M3UA layer also provides inter-working with MTP3 management functions to support seamless operation of the signaling applications in the SS7 and IP domains. This includes:


- Providing an indication to MTP3-Users at an application server process that a remote destination in the SS7 network is not reachable.
- Providing an indication to MTP3-Users at an application server process that a remote destination in the SS7 network is now reachable.
- Providing an indication to MTP3-Users at an application server process that messages to a remote MTP3-User peer in the SS7 network are experiencing SS7 congestion
- Providing an indication to MTP3-Users at an application server process that a remote MTP3-User peer is unavailable.

The M3UA layer at the signaling gateway maintains the availability of all configured remote application server processes, in order to manage the SCTP Associations and the traffic between the signaling gateway and application server processes. As well, the Active/Inactive state of remote application server processes is also maintained - Active application server processes are those currently receiving traffic from the signaling gateway.

M2PA Layer

The M2PA layer, supported only on IPLIMx cards, is a peer-to-peer protocol and provides mappings for all SS7 messages. In a peer-to-peer mode, either side of the IP connection may initiate the connection.

The M2PA layer closely matches the SAAL/TALI/TCP/IP Level 2 protocol stack. This allows it to provide all of the Level 2 features expected by MTP3. The M2PA layer lies below MTP3 in the protocol stack. [Figure 2-26](#) shows the protocol layers in three interconnected nodes involving the M2PA layer.

Figure 2-26. M2PA in the IP⁷ Signaling Gateway

The M2PA layer receives the primitives sent from MTP3 to its lower layer. The M2PA layer processes these primitives or maps them to appropriate primitives at the M2PA/SCTP interface. Likewise, the M2PA layer sends primitives to MTP3 like those used in the MTP3/MTP2 interface.

The M2PA layer provides MTP2 functionality that is not provided by SCTP. This includes:

- Reporting of link status changes to MTP3
- Processor outage procedure
- Link alignment procedure

The M2PA layer allows MTP3 to perform all of its Message Handling and Network Management functions with IPSPs as with other SS7 nodes.

The M2PA layer also supports full retrieval because it assigns sequence numbers to all protocol messages and provides for acknowledgements from the M2PA peer. This means that an M2PA signaling link is able to execute the Change-Over and Change-Back procedures. The M2PA layer makes use of the SS7 Extended Changeover (XCO) and SS7 Extended Changeover Acknowledgement (XCA) messages in order to communicate 24-bit sequence numbers with the peer. This is very similar to what IPLIMx SAALTALI signaling links currently do.

SCTP

SCTP is a protocol designed to operate on top of a non-reliable protocol such as IP, while providing a reliable data delivery to the SCTP user. The SCTP protocol is designed to be a discrete protocol.

Although SCTP is similar in some respects to the Transport Control Protocol (TCP), it differs in several key areas. The two protocols are similar in that they both provide reliable data delivery over a non-reliable network protocol (IP). The SCTP protocol is a more robust and higher performance protocol than TCP.

Broader Definition of Connection Four-Tuple

The TCP protocol defines a connection via a four-tuple – a specific local IP address, local transport protocol port, a specific remote host IP address and remote transport protocol port. The TCP connection is point-to-point and once the session is established the four-tuple can not change. SCTP uses a similar four-tuple concept, but provides for the local and remote IP address values to be a list of IP addresses. SCTP allows a multi-homed host, with multiple network interfaces and more than one way to reach the far-end host, the capability to make use of this additional network connectivity to support the transport of data via the SCTP protocol. Redundancy through the support of multi-homing session end-points is a major SCTP advantage.

Multiple Streams

TCP is a point-to-point byte stream oriented transport protocol. In such a protocol if a single byte is corrupted or lost, then all data that follows must be queued and delayed from delivery to the application until the missing data is retransmitted and received to make the stream valid. With the TCP protocol, all data being transmitted is affected because there is only one path from end-to-end. The SCTP protocol addresses this limitation by providing the capability to specify more than one transport path between the two end-points. In SCTP, the four-tuple – with the multi-homing feature – defines what the SCTP protocol calls an *association*.

The association is composed of one or more uni-directional transport paths called *streams*. The number of inbound and outbound streams is independent of one another and is determined at session initiation time (for example, an association may be composed of three outbound and one inbound stream). In this scheme, a data retransmission only affects a single stream. If an association is defined with multiple streams and a packet is lost on a specific stream, data transmission on the other streams, which form this association, is not blocked. However, this feature is only beneficial if the upper layer application uses it.

In the EAGLE 5 ISS, a maximum of 2 inbound and 2 outbound streams can be defined for an association. Stream 0 in each direction is designated for Link Status messages. Stream 1 is designated for User Data messages. Separating the Link Status and User Data messages onto separate streams allows the adapter layer to prioritize the messages in a manner similar to MTP2. If the peer chooses to configure the association to have only one stream, then the signaling gateway will be able to use only stream 0 for both Link Status messages and User Data messages.

Datagram Stream

While TCP is implemented as a byte-oriented stream protocol, SCTP is based on a datagram-oriented protocol stream. By choosing the datagram as the smallest unit of transport, the SCTP protocol removes the need for the upper layer application to encode the length of a message as part of the message. An SCTP send results in the data being sent as a unit – a datagram – and received at the receiving node as a datagram.

Selective Acknowledgements

TCP acknowledgements are specified as the last consecutive byte in the byte stream that has been received. If a byte is dropped, the TCP protocol on the receiving side cannot pass inbound data to the user until the sender retransmits the lost byte; the stream is blocked. SCTP uses a feature known as *selective acknowledgement* in which each data chunk is identified by a chunk number – the Transmission Sequence Number (TSN) in SCTP terminology – and is explicitly acknowledged at a data chunk granularity. This means that if a data chunk is dropped, only that one data chunk needs to be retransmitted. In SCTP, a dropped data chunk only effects one stream, since ordered transmission of data is only enforced at the stream and not the association level.

Un-order Delivery Capability

The SCTP protocol provides a mechanism for un-ordered datagram delivery. This feature means that a datagram can be transmitted and received independent of datagram sequencing and thus not delayed while awaiting a retransmission. TCP does not provide an equivalent feature of this type.


Enhanced Security

The TCP protocol has a known and easily exploitable vulnerability to denial of service attacks (for example, SYN attacks). This weakness is due to the three-way handshake used by the TCP session-establishment protocol. The TCP session establishment method causes EAGLE 5 ISS resources to be committed prior to actually establishing the session. SCTP uses a four-way handshake where resources are not committed by the host being contacted until the contacting host confirms that it is actually making a contact request to prevent such attacks.

SCTP Connectivity Concepts

The basic connectivity provided by the SCTP protocol is illustrated by [Figure 2-27](#) :

Figure 2-27. SCTP Connectivity



Key elements of the SCTP connection include:

- SCTP Instance
- SCTP Endpoint
- SCTP Association
- SCTP Stream

An SCTP instance is defined by the local SCTP port number. Each local SCTP port number requires its own SCTP instance. An SCTP instance as an entity defines the various SCTP characteristics that will apply to “all” SCTP associations that are created as part of the SCTP instance. These include timeout values, maximum receive windows, and so forth.

In [Figure 2-27](#) there are three hosts: SCTP node A, node B and node C. Node A has two SCTP instances: local SCTP port 2000 and 2100. Both node B and node C have a single SCTP instance, local SCTP port 3000 and 3000 respectively. The fact that both node B and C are using port 3000 does not tie them together in any way.

An SCTP endpoint is defined as the logical sender/receiver of SCTP packets. On a multi-homed host, an SCTP endpoint is represented to its peers as a combination of a set of eligible destination transport addresses to which SCTP packets can be sent and a set of eligible source transport addresses from which SCTP packets can be received. All transport addresses used by an SCTP endpoint must use the same port number, but can use multiple IP addresses. A transport address used by an SCTP endpoint must not be used by another SCTP endpoint. In other words, a transport address is unique to an SCTP endpoint.

The concept of SCTP instance clarifies this definition. In [Figure 2-27](#), IP addresses are not shown, but to illustrate this definition, assume the following:

- Node A is multi-homed having two network interface cards with IP addresses 192.168.110.10 and 192.168.55.10
- Node B has a single network interface card with IP address of 192.168.110.20
- Node C is multi-homed having two network interface cards with IP addresses 192.168.110.30 and 192.168.55.30

Based on these IP addresses from above and the defined port numbers for [Figure 2-27](#), there are four SCTP endpoints ([Table 2-10](#)).

Table 2-10. Sample SCTP Endpoints

Node	Local IP Address	Local SCTP Port
Node-1	192.168.110.10	2000
	192.168.55.10	
Node-1	192.168.110.10	2100
	192.168.55.10	
Node-2	192.168.110.20	3000
Node-3	192.168.110.30	3000
	192.168.55.30	

An SCTP association is defined as a protocol relationship between SCTP endpoints, composed of the two SCTP endpoints and protocol state information including verification tags and the currently active set of Transmission Sequence Numbers (TSNs), etc. An association can be uniquely identified by the transport addresses used by the endpoints in the association. Two SCTP endpoints must not have more than one SCTP association between them at any given time.

Based on this definition, given the endpoints listed above and [Figure 2-27](#), there are three defined SCTP associations.

Table 2-11. Sample SCTP Associations

Association	Local IP Address	Local SCTP Port	Remote IP Address	Remote SCTP Port
Association-1	192.168.110.10 192.168.55.10	2000	192.168.110.20	3000
Association-2	192.168.110.10 192.168.55.10	2000	192.168.110.30 192.168.55.30	3000
Association-3	192.168.110.10 192.168.55.10	2100	192.168.110.30 192.168.55.30	3000

An SCTP stream is defined as a uni-directional logical channel established from one to another associated SCTP endpoint, within which all user messages are delivered in sequence except for those submitted to the unordered delivery service.

NOTE: The relationship between stream numbers in opposite directions is strictly a matter of how the applications use them. It is the responsibility of the SCTP user to create and manage these correlations if they are so desired.

Based on this definition and [Figure 2-27](#) , there are a total of seven streams for the three associations.

Table 2-12. Sample SCTP Associations

Association	Stream Number	Local IP Address	Local SCTP Port	Remote IP Address	Remote SCTP Port
Association-1	Stream 0 Out	192.168.110.10 192.168.55.10	2000	192.168.110.20	3000
Association-1	Stream 0 In	192.168.110.10 192.168.55.10	2000	192.168.110.20	3000
Association-2	Stream 0 Out	192.168.110.10 192.168.55.10	2000	192.168.110.30 192.168.55.30	3000
Association-2	Stream 1 Out	192.168.110.10 192.168.55.10	2000	192.168.110.30 192.168.55.30	3000
Association-2	Stream 0 In	192.168.110.10 192.168.55.10	2000	192.168.110.30 192.168.55.30	3000
Association-3	Stream 0 Out	192.168.110.10 192.168.55.10	2100	192.168.110.30 192.168.55.30	3000
Association-3	Stream 0 In	192.168.110.10 192.168.55.10	2100	192.168.110.30 192.168.55.30	3000

TALI IPLIMx Configuration Procedures

Adding TALI IPLIMx Components	3-1
Adding an IPLIMx Card	3-2
Adding an IPLIMx Signaling Link	3-7
Enabling the Large System # Links Controlled Feature	3-18
Configuring an IP Link	3-27
Adding an IP Host	3-43
Configuring an IP Card	3-47
Adding an IP Route	3-55
Adding a Socket to an IPLIMx Signaling Link	3-61
Removing TALI IPLIMx Components	3-71
Removing an IPLIMx Card	3-71
Removing an IPLIMx Signaling Link	3-73
Removing an IP Host Assigned to an IPLIMx Card	3-81
Removing an IP Route	3-86
Removing a Socket that is Assigned to an IPLIMx Signaling Link	3-90
Changing TALI IPLIMx Components	3-92
Changing the Attributes of a Socket on an IPLIMx Signaling Link	3-92
Configuring IP Socket Retransmission Parameters	3-105
Configuring a DCM Parameter Set	3-111

Adding TALI IPLIMx Components

This section describes how to configure the components necessary to establish IP connections using TALI sockets on IPLIMx signaling links. IPLIMx signaling links are signaling links assigned to cards running either the IPLIM or IPLIMI applications. The IPLIM application supports point-to-point connectivity for ANSI networks. The IPLIMI application supports point-to-point connectivity for ITU networks.

The configuration of these IP connections consists of these items.

1. Configure the IPLIMx card with the [Adding an IPLIMx Card](#) procedure.
2. Configure the required destination point codes - see Chapter 2, "Configuring Destination Tables," in the *Database Administration Manual - SS7*.

3. Configure the required IPLIMx linksets - see Chapter 3, “SS7 Configuration,” in the *Database Administration Manual - SS7*.
4. Configure the IPLIMx signaling links with the [Adding an IPLIMx Signaling Link](#) procedure. The **ipliml2=saaltali** parameter of the **ent-slk** command must be specified for these signaling links. If the addition of these signaling links will exceed the current number of signaling links the EAGLE 5 ISS is allowed to have, the [Enabling the Large System # Links Controlled Feature](#) procedure will have to be performed to increase the quantity of signaling links.
5. Configure the required routes - see Chapter 3, “SS7 Configuration,” in the *Database Administration Manual - SS7*.
6. IP addresses must be assigned to the IPLIMx card configured in step 1 by performing the [Configuring an IP Link](#) procedure. There are other IP link parameters that are assigned to the IPLIMx card when the IPLIMx card is configured. Default values are assigned to these parameters when the IPLIMx card is configured. These values can be displayed by the **rtrv-ip-lnk** command. These values can be changed by performing the [Configuring an IP Link](#) procedure.
7. Local IP hosts, assigned to the IP addresses assigned to step 6, must be configured in the database by performing the [Adding an IP Host](#) procedure. Verify the hosts with the **rtrv-ip-host** command. This establishes a relationship between the IP card related information and the socket related information.
8. When the IP cards are added to the database in step 1, there are IP parameters that control the IP stack that are assigned default values. These parameter values can be displayed by the **rtrv-ip-card** command. These values can be changed by performing the [Configuring an IP Card](#) procedure.
9. Static IP routes provide more flexibility in selecting the path to the remote destination and reduces the dependence on default routers. Static IP routes are provisioned by performing the [Adding an IP Route](#) procedure.
10. Sockets specify a connection between a local host/TCP port and a remote host/TCP port. The socket is configured by performing the [Adding a Socket to an IPLIMx Signaling Link](#) procedure. A number of fields in the socket cannot be configured with the [Adding a Socket to an IPLIMx Signaling Link](#) procedure and are set to default values. The values of these fields can be displayed using the **rtrv-appl-sock** command after the [Adding a Socket to an IPLIMx Signaling Link](#) procedure is performed. These values can be changed by performing the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure. An IPLIMx card can have one socket for each signaling link assigned to the card.
11. When a socket is configured with the [Adding a Socket to an IPLIMx Signaling Link](#) procedure, DCM parameter set 10 is assigned to the socket. The DCM parameter set assignment can be changed by performing the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure. The values assigned to DCM parameter sets can be verified with the **rtrv-dcmps** command. The values assigned to DCM parameter sets can be changed by performing the [Configuring a DCM Parameter Set](#) procedure.
NOTE: Set number 10 is a default parameter set and cannot be changed. To change the DCM parameters set for a socket using set number 10, use the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure to change the DCM parameter set to a different set number, and then use the [Configuring a DCM Parameter Set](#) procedure to modify the new set.

Adding an IPLIMx Card

This procedure is used to add an IPLIMx card to the database using the **ent-card** command. An IPLIMx card is a card that is running either the IPLIM or IPLIMI applications. A maximum of 100 IPLIMx cards can be provisioned in the database. [Table 3-1](#) shows the cards that can be provisioned in this procedure.

Table 3-1. IPLIMx Card Types

Card Type	Part Number
Dual-Slot DCM	870-1945-xx or 870-1984-01 †
Single-Slot EDCM	870-2372-01, 870-2372-08, 870-2372-13

† The dual-slot DCM is not supported if the Origin-Based MTP Routing feature is enabled.

The **ent-card** command uses these parameters.

:loc – The location of the card being added to the database.

:type – The type of card being added to the database. For this procedure, the value of this parameter is **dcm**.

:appl – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is **iplim** for ANSI IP network connections or **iplimi** for ITU IP network connections.

:force – If the global title translation feature is on, the **force=yes** parameter allows the LIM to be added to the database even if the current SCCP transactions-per-second threshold is unable to support the additional SCCP transaction-per-second capacity created by adding the IP card. This parameter is obsolete and is no longer used.

Card Slot Selection

The dual-slot DCM occupies two card slots and can be inserted any card slot in the extension shelf except slots 08 and 18. The dual-slot DCM card requires that the next adjacent slot be empty and not provisioned in the database. For example, if dual-slot DCM cards are inserted into slots 03 and 06, slots 04 and 07 must be empty and not provisioned in the database. Because slots 09 and 10 contain the HMUX cards or HIPR cards, the dual-slot DCM card cannot be inserted into slots 08, 09, or 10. Slot 18 cannot be used because it is the last slot in the shelf. The dual-slot DCM card can be inserted in the control shelf, but only in slots 01 through 07, and 11, following the same rules as the extension shelf. Slots 1113 through 1118 are reserved for MASPs A and B and the MDAL card.

The single-slot EDCM can be inserted into any card slot, except for card slots that must remain empty to accommodate dual-slot cards, slots 09 and 10 in each shelf, and slots 1113 through 1118.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output. Cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM         SCCP
1102   TSM         GLS
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0      SS7ANSI    sp2            A      0      sp1            B      0
1203   LIMDS0      SS7ANSI    sp3            A      0
1204   LIMDS0      SS7ANSI    sp3            A      1
1206   LIMDS0      SS7ANSI    nsp3           A      1      nsp4           B      1
1207   LIMV35      SS7GX25    nsp1           A      0
1208   LIMV35      SS7GX25    nsp1           A      1
1216   ACMENET     STPLAN
1301   LIMDS0      SS7ANSI    sp6            A      1      sp7            B      0
1302   LIMDS0      SS7ANSI    sp7            A      1      sp5            B      1
1303   DCM         IPLIM      ipnode1        A      0      ipnode3        B      1
1305   DCM         IPLIM      ipnode4        A      0
1307   ACMENET     STPLAN
```

If the required unprovisioned card slots (see the Card Slot Selection section) are shown in the **rtrv-card** output, skip steps 2 and 3, and go to step 4.

If the required unprovisioned card slots are not shown in the **rtrv-card** output, step 2 must be performed.

2. Display the shelves in the database by entering the **rtrv-shlf** command. This is an example of the possible output.

```
r1ghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
SHELF DISPLAY
FRAME SHELF      TYPE
  1      1      CONTROL
  1      2      EXTENSION
  1      3      EXTENSION
```

If all the shelves are provisioned in the database, then this procedure cannot be performed. There are no available card slots for the new IPLIMx card.

If all the shelves have not been provisioned in the database, go to step 3.

3. Add the required shelf using the **ent-shlf** command with the location of the shelf and the **type=ext** parameter. The shelf location values are 1200, 1300, 2100, 2200, 2300, 3100, 3200, 3300, 4100, 4200, 4300, 5100, 5200, 5300, and 6100. For this example, enter this command.

ent-shlf:loc=2100:type=ext

When this command has successfully completed, this message should appear.

```
r1ghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
ENT-SHLF: MASP A - COMPLTD
```

4. Verify that the card to be entered has been physically installed into the proper location (see the Card Slot Selection section).



CAUTION: If the version of the BPDCM GPL on the IP card does not match the BPDCM GPL version in the database when the IP card is inserted into the card slot, UAM 0002 is generated indicating that these GPL versions do not match. If UAM 0002 has been generated, perform the alarm clearing procedure for UAM 0002 in the *Maintenance Manual* before proceeding with this procedure.

5. Add the card using the **ent-card** command.

For this example, enter these commands.

ent-card:loc=1311:type=dcn:appl=iplim

ent-card:loc=1313:type=dcn:appl=iplimi

When each of these commands have successfully completed, this message should appear.

```
r1ghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD
```

6. Verify the changes using the **rtrv-card** command with the card location specified in step 5.

For this example, enter these commands.

rtrv-card:loc=1311

This is an example of the possible output.

```
r1ghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE   APPL   LSET NAME   LINK SLC LSET NAME   LINK SLC
1311   DCM       IPLIM
```

rtrv-card:loc=1313

This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1313   DCM        IPLIMI
```


7. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Figure 3-1. Adding an IPLIMx Card





Adding an IPLIMx Signaling Link

This procedure is used to add an IPLIMx signaling link to the database using the **ent-slk** command. The **ent-slk** command uses these parameters.

:loc – The card location of the IP card that the IP signaling link will be assigned to. The cards specified by this parameter are IPcards running the IPLIMor IPLIMI applications.

:link – The signaling link on the card specified in the **loc** parameter.

:lsn – The name of the linkset that will contain the signaling link.

:slc – The signaling link code. The SLC must be unique within the linkset. It must be the same at both the EAGLE 5 ISS location and the distant node.

:ipliml2 – The L2 protocol stack to be assigned to the IP signaling link, either SAALTALI or M2PA (the default value). In this procedure, the **ipliml2** parameter value must be SAALTALI.

The **ent-slk** command also contains these parameters, **l2tset**, **l1mode**, **bps**, **tset**, **ecm**, **pcrn1**, **pcrn2**, **lpset**, **atmtsel**, **vci**, **vpi**, **ll**, **e1atmcr4**, **e1atmsi**, **e1atmsn**, **ts**, **e1port**, **e1loc**,

t1port, and **t1loc**. These parameters are used only for configuring low-speed, ATM high-speed, E1, and T1 signaling links and are not used in this procedure. For more information on configuring these types of signaling links, see the *Database Administration Manual - SS7*.

These items must be configured in the database before an IP signaling link can be added:

- Shelf – perform the "Adding a Shelf" procedure in the *Database Administration Manual - System Management*.
- Card – perform the [Adding an IPLIMx Card](#) procedure
- Destination Point Code – perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7*.
- Linkset – perform the "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

Verify that the link has been physically installed (all cable connections have been made).

To configure the EAGLE 5 ISS to perform circular routing detection test on the signaling links, "Configuring Circular Route Detection" procedure in the *Database Administration Manual - SS7*.

NOTE: Circular route detection is not supported in ITU networks.

To provision a EAGLE 5 ISS with more than 700 signaling links, the EAGLE 5 ISS must have certain levels of hardware installed. See the "Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links" section for more information on these hardware requirements.

The EAGLE 5 ISS can contain a mixture of low-speed, E1, T1, ATM high-speed, and IP signaling links. The "Determining the Number of High-Speed and Low-Speed Signaling Links" section describes how to determine the quantities of the different types of signaling links the EAGLE 5 ISS can have.

Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links

To provision an EAGLE 5 ISS with more than 700 signaling links (currently the EAGLE 5 ISS can have maximum capacities of 1200, or 1500, or 2000 signaling links), the following additional requirements must be met:

- The Measurements Platform feature must be enabled. Perform these procedures in the *Database Administration Manual - System Management* to enable the Measurements Platform Feature:
 - "Adding an MCPM"
 - "Configuring the IP Communications Link for the Measurements Platform Feature"
 - "Adding an FTP Server"
- To provision more than 1200 signaling links, the Large System # Links controlled feature must be enabled for 1500 or 2000 signaling links. For more information on enabling this feature, go to the [Enabling the Large System # Links Controlled Feature](#) procedure.

Determining the Number of High-Speed and Low-Speed Signaling Links

An EAGLE 5 ISS containing either 1200, or 1500, or 2000 signaling links can contain the following quantities of signaling links:

- 180 high-speed ATM signaling links assigned to the ATMANSI application. If there are any high-speed ATM signaling links assigned to the ATMITU application, the maximum number of high-speed ATM signaling links is 115.
- 100 signaling links assigned to either the IPLIM or IPLIMI applications.

- 64 signaling links assigned to either the **ss7ipgw** or **ipgwi** application, or combinations of the **ss7ipgw** and **ipgwi** applications.
- 64 unchannelized E1 signaling links.

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET running either the **iplimi** or **ipgwi** applications.
- E1-ATM running the **atmitu** application.

Canceling the REPT-STAT-SLK, RTRV-LS, and RTRV-SLK Commands

Because the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands used in this procedure can output information for a long period of time, the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered, from another terminal other than the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current signaling link configuration using the **rtrv-slk** command. This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0

LOC LINK LSN          SLC TYPE      L2T  BPS   L1      PCR  PCR
      SET           SET           MODE TSET  ECM  N1   N2
1201 B   lsa1         0  LIMDS0    1    56000  ---  ---  BASIC ---  -----
1203 B   lsa2         0  LIMDS0    1    56000  ---  ---  BASIC ---  -----
1205 A   lsa3         0  LIMV35    3    64000  DCE  ON   BASIC ---  -----
1207 A   lsn1207a     0  LIMDS0    1    56000  ---  ---  BASIC ---  -----
1207 B   lsn1207b     0  LIMDS0    1    56000  ---  ---  BASIC ---  -----
1214 A   lsn1214a     0  LIMV35    2    64000  DTE  ---  PCR   76   3800
1214 B   lsa3         1  LIMV35    3    64000  DCE  ON   BASIC ---  -----

LOC LINK LSN          SLC TYPE      LP      ATM
      SET           SET           SET    TSEL
      BPS           BPS           BPS
      VCI           VPI           LL
```

No Links Set up.

LOC	LINK	LSN	SLC	TYPE	LP SET	BPS	ATM TSEL	VCI	VPI	CRC4	SI	SN
No Links Set up.												

LOC	LINK	LSN	SLC	TYPE	IPLIML2							
No Links Set up.												

LOC	LINK	LSN	SLC	TYPE								
No Links Set up.												

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	E1 LOC	E1 PORT	TS
No Links Set up.												

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	T1 LOC	T1 PORT	TS
No Links Set up.												

SLK table is (7 of 1200) 1% full.

If the **rtrv-sl** output shows that the maximum number of signaling links is 2000, go to step 2.

If the **rtrv-sl** output shows that the maximum number of signaling links is 1200, and the signaling link being added increases the number beyond 1200, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for either 1500 signaling links or 2000 signaling links. Then go to step 2.

If the **rtrv-sl** output shows that the maximum number of signaling links is 1500, and the signaling link being added increases the number beyond 1500, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for 2000 signaling links. Then go to step 2.

If the addition of the new signaling link will not exceed the maximum number of signaling links, go to step 2.

2. Display the current linkset configuration using the **rtrv-ls** command. This is an example of the possible output.

```
r1ghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

LSN	APCA	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
e1e2	001-207-000		none	1	1	no	B	6	off	off	off	no	off
ls1305	000-005-000		none	1	1	no	A	1	off	off	off	no	off
ls1307	000-007-000		none	1	1	no	A	1	off	off	off	no	off
e1m1s1	001-001-001		none	1	1	no	A	7	off	off	off	no	off
e1m1s2	001-001-002		none	1	1	no	A	7	off	off	off	no	off

LSN	APCA	(X25)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
LSN	APCI	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
e1e2i	1-207-0		none	1	1	no	B	4	off	off	off	---	on
ls1315	0-015-0		none	1	1	no	A	1	off	off	off	---	off
ls1317	0-017-0		none	1	1	no	A	1	off	off	off	---	on
e1m2s1	1-011-1		none	1	1	no	A	7	off	off	off	---	off
e1m2s2	1-011-2		none	1	1	no	A	7	off	off	off	---	off

LSN	APCN	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
LSN	APCN24	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS <td>SLSCI</td> <td>NIS</td>	SLSCI	NIS

L3T SET	SLT SET	GWS ACT	GWS MES	GWS DIS
L3T SET	SLT SET	GWS ACT	GWS MES	GWS DIS

```
LSN (CHINA) APCN (SS7) SCRNLST LNKS ACT MES DIS SLSCI NIS
```

```

L3T SLT GWS GWS GWS
LSN (CHINA) APCN24 (SS7) SCRNLST LNKS ACT MES DIS SLSCI NIS

```

Link set table is (10 of 1024) 1% full.

If the required linkset is not in the database, perform the "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7* to add the linkset to the database. After the new linkset has been added, skip step 3 and go to step 4.

If the signaling link will be assigned to the linkset shown in this step, go to step 3.

3. Display the linkset that the signaling link is being assigned to using the **rtrv-ls** command, specifying the name of the linkset that the signaling link is being assigned to.

For this example, enter this command.

rtrv-ls:lsn=lsnipgw

This is an example of the possible output.

```

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
LSN          APCI (SS7) SCRNLST LNKS ACT MES DIS SLSCI NIS
lsnipgw      2968      none 1 1 no A 1 off off off --- off

CLLI          TFATCABMLQ MTPRSE ASL8 SLSRSB MULTGC ITUTFR
----- 1          no    --- 1          yes    off

IPGWAPC MATELSN IPTPS LSUSEALM SLKUSEALM GTTMODE
no      ----- --- ---          CdPA

LOC LINK SLC TYPE L2T BPS L1 MODE TSET ECM PCR N1 PCR N2
LOC LINK SLC TYPE LP BPS ATM TSEL VCI VPI VPI LL
LOC LINK SLC TYPE LP BPS ATM TSEL VCI VPI CRC4 SI SN
LOC LINK SLC TYPE IPLIML2 SAALTALI
LOC LINK SLC TYPE

LOC LINK SLC TYPE L2T BPS ECM PCR N1 PCR N2 E1 LOC E1 PORT TS
LOC LINK SLC TYPE L2T BPS ECM PCR N1 PCR N2 T1 LOC T1 PORT TS

SAPCI
1-10-1

SAPCN
1234-aa
1235-bb
1200-zz

```

Link set table is (13 of 1024) 1% full.

Linksets can contain a mixture of signaling link types unless the card application is SS7IPGW or IPGWI.

A signaling link containing the **ipliml2=saaaltali** parameter cannot be assigned to a linkset containing a 24-bit ITU-N adjacent point code. Either choose another linkset without a 24-bit-ITU-N adjacent point code from the **rtrv-ls** output in step 2, or add a new IPLIMx linkset by performing the "Adding the SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

If you do not wish to assign the signaling link to this linkset, go to the “Adding the SS7 Linkset” procedure in the *Database Administration Manual - SS7* and add the IPLIMx linkset to the database.

4. Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```

r1ghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1102   TSM        GLS
1103   DCM        VXWSLAN
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI   lsa1           B      0
1202   LIMV35     SS7ANSI
1203   LIMDS0     SS7ANSI   lsa2           B      0
1204   LIMDS0     SS7ANSI
1205   LIMV35     SS7ANSI   lsa3           A      0
1206   LIMV35     SS7ANSI
1207   LIMDS0     SS7ANSI   lsn1207a       A      0   lsn1207b       B      0
1208   LIMDS0     SS7ANSI
1212   LIMV35     SS7ANSI
1213   LIMDS0     SS7ANSI
1214   LIMV35     SS7ANSI   lsn1214a       A      0   lsa3           B      1
1215   LIMDS0     SS7ANSI
1301   LIMV35     ATMANSI
1302   LIMATM     ATMANSI
1304   LIMV35     SS7ANSI
1305   LIMATM     ATMANSI
1308   LIMV35     SS7ANSI
1311   LIMDS0     SS7ANSI
1313   LIMDS0     SS7ANSI
1315   LIMV35     CCS7ITU
1317   LIMV35     CCS7ITU
1318   LIMATM     ATMANSI

```

If the required card is not in the database, perform the [Adding an IPLIMx Card](#) procedure and add the IP card to the database.

5. Add the signaling link to the database using the **ent-slk** command.

[Table 3-2](#) shows the parameters and values that can be specified with the **ent-slk** command.

Table 3-2. TALI IPLIMx Signaling Link Parameter Combinations

TALI IPLIMx Signaling Link			
:loc = location of the IP card with one of these applications: IPLIM or IPLIMI; and the DCM card type. ¹			
:link = <see Note 2>			
:lsn = linkset name ^{3, 5}			
:slc = 0 - 15 ⁴			
:ipliml2 = saaltali ^{4, 5}			
Notes:			
1. If the multgc=yes parameter is assigned to the linkset, the card's application must be IPLIMI.			
2. The range of link parameter values is dependent on the type of IPLIMx card that is being provisioned.			
Type of Card	Link Parameter Values	Dual-Slot DCM	A, B Single-Slot EDCM A
- A3, B - B3			
3. If the card's application is IPLIMI, the linkset adjacent point code must be ITU. If the card's application is IPLIM, the linkset adjacent point code must be ANSI. The domain of the linkset adjacent point code must be SS7.			
4. Signaling links provisioned in this procedure can be in a linkset that contains non-IPLIMx signaling links.			

TALI IPLIMx Signaling Link

5. Signaling links containing the **ipliml2=saaltali** parameter value cannot be assigned to linksets containing 24-bit ITU-N APCs (APCN24) or SAPCs (SAPCN24).

For this example, enter these commands.

```
ent-slk:loc=2202:link=a:lsn=lsnlp1:slc=0:ipliml2=saaltali
```

```
ent-slk:loc=2215:link=a:lsn=lsnlp2:slc=1:ipliml2=saaltali
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:29:03 GMT EAGLE5 36.0.0
ENT-SLK: MASP A - COMPLTD
```

6. Verify the changes using the **rtrv-slk** command with the card location and **link** parameter values specified in step 5. For this example, enter this command.

```
rtrv-slk:loc=2202:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN      SLC TYPE      IPLIML2
2202 A   lsnlp1    0  IPLIM      SAALTALI
```

```
rtrv-slk:loc=2215:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN      SLC TYPE      IPLIML2
2215 A   lsnlp2    1  IPLIM      SAALTALI
```

7. If any cards contain the first signaling link on a card, those cards must be brought into service with the **rst-card** command, specifying the location of the card.

For this example, enter these commands.

```
rst-card:loc=2202
```

```
rst-card:loc=2215
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-23 13:05:05 GMT EAGLE5 36.0.0
Card has been allowed.
```

8. Activate all signaling links on the cards using the **act-slk** command, specifying the card location and **link** parameter value of each signaling link.

For this example, enter these commands.

```
act-slk:loc=2202:link=a
```

```
act-slk:loc=2215:link=a
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:31:24 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

9. Check the status of the signaling links added in step 5 using the **rept-stat-slk** command with the card location and link parameter values specified in step 5. The state of each signaling link should be in service

normal (IS-NR) after the link has completed alignment (shown in the PST field). For this example, enter these commands.

```
rept-stat-slk:loc=2202:link=a
```

This is an example of the possible output.

```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2202,A   lsnlp1   ----- IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```

```
rept-stat-slk:loc=2215:link=a
```


This is an example of the possible output.


```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2215,A   lsnlp2   ----- IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```


10. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 3-1. Adding an IPLIMx Signaling Link







Enabling the Large System # Links Controlled Feature

This procedure is used to enable the Large System # Links controlled feature using the feature's part number and a feature access key.

The feature access key for the Large System # Links controlled feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

This feature allows the EAGLE 5 ISS to contain a maximum of either 1500 or 2000 signaling links.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key generated by Tekelec's feature access key generator, and supplied to you when you purchase or temporarily try a controlled feature. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number associated with the signaling link quantity being enabled:

- 893005901 for the 1500 signaling link quantity
- 893005910 for the 2000 signaling link quantity.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent-serial-num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature is enabled with the **enable-ctrl-feat** command, the feature is also activated. The **chg-ctrl-feat** command is not necessary to activate the feature.

This feature cannot be disabled with the **chg-ctrl-feat** command and the **status=off** parameter.

Hardware Supported for Signaling Link Quantities Greater than 1500

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 card running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET card running either the **iplimi** or **ipgwi** applications.
- E1-ATM card running the **atmitu** application.

To increase the signaling link quantity to more than 1500 signaling links, HIPR cards must be installed into card locations 9 and 10 in each shelf in the EAGLE 5 ISS. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the EAGLE 5 ISS shelves.

Procedure

1. Display the status of the Large System # Links controlled feature by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the **rtrv-ctrl-feat** output shows that the controlled feature is enabled for the desired quantity or for a quantity that is greater than the desired quantity, no further action is necessary. This procedure does not need to be performed.

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, skip steps 2 through 5, and go to step 6.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

```
ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Verify that HIPR cards are installed in card locations 9 and 10 in each shelf of the EAGLE 5 ISS.

NOTE: If the 2000 signaling link quantity is not being enabled in this procedure, skip step 6 and go to step 7.

Enter this command.

rept-stat-gpl:gpl=hipr

This is an example of the possible output.

```
rlghncxa03w 06-10-01 11:40:26 GMT EAGLE5 36.0.0
GPL      CARD      RUNNING      APPROVED      TRIAL
HIPR     1109      126-002-000  126-002-000  126-003-000
HIPR     1110      126-002-000  126-002-000  126-003-000
HIPR     1209      126-002-000  126-002-000  126-003-000
HIPR     1210      126-002-000  126-002-000  126-003-000
HIPR     1309      126-002-000  126-002-000  126-003-000
HIPR     1310      126-002-000  126-002-000  126-003-000
HIPR     2109      126-002-000  126-002-000  126-003-000
HIPR     2110      126-002-000  126-002-000  126-003-000
Command Completed
```

If HIPR cards are installed in each the shelf in the EAGLE 5 ISS, go to step 7.

If HIPR cards are not installed on each shelf in the EAGLE 5 ISS, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 7.

NOTE: Before the 2000 signaling link quantity is enabled, make sure the EAGLE 5 ISS is configured with the signaling link hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section.

If signaling hardware other than the hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section is installed and provisioned, contact the Customer Care Center before enabling the 2000 signaling link quantity. Refer to [Customer Care Center](#) for the contact information.

7. Enable the Large System # Links controlled feature for the desired quantity with the **enable-ctrl-feat** command specifying the part number corresponding to the new quantity of signaling links and the feature access key.

To increase the number of signaling links the EAGLE 5 ISS can contain to 1500, enter this command.

enable-ctrl-feat:partnum=893005901:fak=<feature access key>

To increase the number of signaling links the EAGLE 5 ISS can contain to 2000, enter this command.

enable-ctrl-feat:partnum=893005910:fak=<feature access key>

NOTE: A temporary feature access key cannot be specified to enable this feature.

NOTE: The values for the feature access key (the **fak** parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the part number specified in step 7.

If the 1500 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005901

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005901	on	1500

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the 2000 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005910

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```


Feature Name	Partnum	Status	Quantity
Large System # Links	893005910	on	2000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-2. Enabling the Large System # Links Controlled Feature







Configuring an IP Link

This procedure is used to configure the link parameters for IP cards using the **chg-ip-lnk** command. These link parameters are used to configure the Ethernet hardware.

The **chg-ip-lnk** command uses the following parameters.

:loc – The card location of the IP card.

:port – The Ethernet interface on the IP card, A or B.

:ipaddr – IP address assigned to the Ethernet interface on the IP card. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:submask – The subnet mask of the IP interface. A subnet mask is an IP address with a restricted range of values. The bits in the mask must be a string of one’s followed by a string of zero’s. There must be at least two one’s in the mask, and the mask cannot be all one’s. See [Table 3-3](#) to assign the correct parameter values.

:auto – Tells hardware whether to automatically detect the **duplex** and **speed**.

:duplex – This is the mode of operation of the interface.

:speed – This is the bandwidth in megabits per second of the interface.

:mactype – This is the Media Access Control Type of the interface.

:mcast – The multicast control flag. This parameter enables or disables multicast support for the interface.

A zero **ipaddr** parameter value (**0.0.0.0**) indicates the IP card Ethernet interface to IP link association is disabled. The host to the original IP address must be removed before the **ipaddr=0.0.0.0** can be specified.

If the **defrouter** parameter of the **chg-ip-card** command contains an IP address for the card specified in this procedure, the network portion of one of the IP addresses assigned to the card in this procedure must match the network portion of the IP address specified by the defrouter parameter of the **chg-ip-card** command.

The network portion of the IP address is based on the class of the IP address (shown in [Table 3-3](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

If the **auto=yes** parameter is specified, then the **duplex** and **speed** parameters are not allowed.

The **loc** parameter value must be shown in the **rtrv-ip-card** output.

The IP card must be placed out of service.

If either the **ipaddr** or **submask** parameters are specified, then both parameters must be specified. If the **ipaddr** parameter value is zero (**0.0.0.0**), the **submask** parameter is not required.

If the IP card is a single-slot EDCM, the A or B interface can be used. The B interface cannot be used with the DCM.

The IP address and subnet mask values cannot be changed to an address representing a different network if:

- If the network interface specified by the **loc** and **port** parameters has a default router, **dnsa**, or **dsnb** parameter values assigned to it, as shown in the **rtrv-ip-card** output.

- Any IP routes, shown in the **rtrv-ip-rte** output, reference the IP address for the network interface specified by the **loc** and **port** parameters.

The IP link cannot be changed if open sockets or associations reference the IP link being changed.

The network portion of the IP addresses assigned to the IP links on an IP card must be unique. For example, if IP links are assigned to IP card 1103, the network portion of the IP address for Ethernet interface A (**port=a**) must be different from the IP address for Ethernet interface B (**port=b**).

The **submask** parameter value is based upon the **ipaddr** setting. See [Table 3-3](#) for the valid input values for the **submask** and **ipaddr** parameter combinations.

Table 3-3. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0 255.224.0.0 255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.0.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **ipaddr** parameter of the **chg-ip-lnk** command, the subnet address that results from the **ipaddr** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **ipaddr** and **submask**

parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Canceling the RTRV-APPL-SOCK and RTRV-ASSOC Commands

Because the **rtrv-appl-sock** and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10    255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----      -----      HALF    10     DIX      NO    NO
1203  A      192.1.1.12    255.255.255.0   ----    ---    DIX      YES   NO
1203  B      -----      -----      HALF    10     DIX      NO    NO
1205  A      192.1.1.14    255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20    255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22    255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24    255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2205  A      192.1.1.30    255.255.255.0   FULL    100    DIX      NO    NO
2205  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32    255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50    255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52    255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
```

NOTE: If the **ipaddr=0.0.0.0** is not being specified in this procedure, skip step 2 and go to step 3.

2. If IP address information is being added or changed (not deleted) in the link parameters, verify that the IP address is present in the IP host table by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
```

```
REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (11 of 512) 2% full

If the current IP address of the IP link is shown in the **rtrv-ip-host** output, remove the host assigned to the IP address by performing the [Adding an IP Host](#) procedure.

- To change IP link parameters, the signaling link to the IP card and the IP card have to be inhibited. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE   IPLIML2
1201  A   nc001         0  IPLIM  SAALTALI
```

- Retrieve the status of the signaling link assigned to the IP card to be changed using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1201,A nc001    -----  IS-NR
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 5 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 7 to verify the IP card status.

- Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.


```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

6. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001    -----  OOS-MT-DSBLD  AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS: not aligned
UNAVAIL REASON = NA
Command Completed.
```

7. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM  IPLIM  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST      LS      CLLI
A    IS-NR    nc001    -----
```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 8 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 10 to change the IP link parameters.

8. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

9. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM  IPLIM  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
```

```

IMT BUS B          = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----

```

Command Completed.

10. Display the attributes of the IP card assigned to the IP link being changed by entering the **rtrv-ip-card** command and specifying the card location of the IP link.

NOTE: If the `ipaddr` or `submask` parameter values are not being changed, skip steps 10, 11, and 12, and go to step 13.

For this example, enter this command.

rtrv-ip-card:loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN    -----

```

If the **rtrv-ip-card** output shows an IP address for the default router (**DEFROUTER**) whose network portion matches the network portion of the IP address being changed, go to the [Configuring an IP Card](#) procedure and change the IP address of the default router to **0.0.0.0**.

11. Display any IP routes referencing the IP link being changed by entering the **rtrv-ip-rte** command and specifying the card location of the IP link.

For this example, enter this command.

rtrv-ip-rte:loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1201 128.252.10.5   255.255.255.255  140.188.13.33
1201 128.252.0.0    255.255.0.0     140.188.13.34
1201 150.10.1.1     255.255.255.255  140.190.15.3

```

IP Route table is (5 of 1024) 1% full

If the **rtrv-ip-rte** output shows that the card has IP routes assigned to it, go to the [Removing an IP Route](#) procedure and remove the IP routes from the database.

12. The subnet address that results from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

NOTE: If a Class A or C IP address (see [Table 3-3](#)) will be specified for the `ipaddr` parameter in step 15, skip step 12 and go to step 13.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 13.

This is an example of the possible output if the E5IS feature is on.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0
```

Choose **ipaddr** and **submask** parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 13.

13. Display the application sockets referencing the local host name that is associated with the IP link being changed by entering the **rtrv-appl-sock** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

NOTE: If the local host was removed in step 2, skip steps 13 and 14, and go to step 15.

For this example, enter this command.

rtrv-appl-sock: lhost="ipnode1-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
LINK   A
LHOST  ipnode1-1201
RHOST  kc-hlr1
LPORT  7000          RPORT  7000
SERVER YES          DCMPS  1
REXMIT FIXED        RTT    60
OPEN   YES          ALW    NO
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

If no sockets are displayed in this step, go to step 14.

If the **rtrv-appl-sock** output shows that the **open** parameter for any sockets is **yes**, perform one of these procedures to change the value of the **open** parameter of the sockets to **no**.

- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)

14. Display the associations referencing the local host name that is associated with the IP link being changed by entering the **rtrv-assoc** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

For this example, enter this command.

rtrv-assoc: lhost="ipnode1-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
swbel32    1201 A    A    M2PA    1030  2345 YES  YES
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1201

If no associations are displayed in this step, go to step 15.

If the **rtrv-assoc** output shows that the **open** parameter for any associations is **yes**, perform one of these procedures to change the value of the **open** parameter the associations to **no**.

- [Changing an M2PA Association](#)
- [Changing an M3UA or SUA Association](#)

15. Change the link parameters associated with the IP card in the database using the **chg-ip-lnk** command. For this example, enter this command.

```
chg-ip-  
lnk:loc=1201:port=a:ipaddr=192.1.1.10 :submask=255.255.255.0:auto=yes:m  
actype=dix
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0  
CHG-IP-LNK: MASP A - COMPLTD
```

16. Verify the new link parameters associated with the IP card that was changed in step 15 by entering the **rtrv-ip-lnk** command with the card location specified in step 15.

For this example, enter this command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0  
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST  
1201  A      192.1.1.10        255.255.255.128  HALF    10      DIX      YES   NO  
1201  B      -----          -----          HALF    10      DIX      NO    NO
```

17. Allow the IP card that was inhibited in step 8 by using by using the **alw-card** command.

NOTE: If step 8 was not performed, skip steps 17 and 18, and go to step 19.

For example, enter this command.

```
alw-card:loc=1201
```

This message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0  
Card has been allowed.
```

18. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command. For example, enter this command.

```
rept-stat-card:loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0  
CARD  VERSION  TYPE  APPL  PST  SST  AST  
1201  114-000-000  DCM   IPLIM  IS-NR  Active  -----  
ALARM STATUS      = No Alarms.  
BPDCM GPL         = 002-102-000  
IMT BUS A         = Conn  
IMT BUS B         = Conn  
SIGNALING LINK STATUS  
SLK   PST        LS        CLLI  
A     IS-NR      nc001    -----
```

Command Completed.

19. Activate the signaling link from step 5 using the **act-slk** command.

NOTE: If step 5 was not performed, skip steps 19 and 20, and go to step 21.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

20. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command. For example, enter this command.

rept-stat-slk:loc=1201:link=a

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001      ----- IS-NR
Command Completed.
```

21. Perform the [Configuring an IP Link](#) procedure and change the IP address of the default router to a non-zero value, where the network portion of the default router IP address matches the network portion of the IP link's new IP address.

NOTE 1: If the `ipaddr` or `submask` values were not changed, skip steps 21 and 22, and go to step 23.

NOTE: If the IP address of the default router was not changed to 0.0.0.0 in step 10, skip step 21, and go to step 22.

22. Perform the [Adding an IP Route](#) procedure and add the IP routes back into the database.

NOTE: If IP routes were not removed in step 11, skip step 22, and go to step 23.

23. Perform one of these procedures as necessary and change the value of the **open** parameter of either the application socket or the association to **yes**.

NOTE: If the `open` parameter value for either an application socket or an association was not changed in either steps 13 or 14, skip step 23, and go to step 24.


- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)
- [Changing an M2PA Association](#)
- [Changing an M3UA or SUA Association](#)


24. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 3-3. Configuring an IP Link




















Adding an IP Host

This procedure associates hostnames with IP addresses using the **ent-ip-host** command.

The **ent-ip-host** command uses the following parameters.

:host– The host name to be associated with the IP address. This parameter identifies the logical name assigned to the device with the IP address indicated. The host name can contain up to 60 characters (using only these characters: a-z, A-Z, 0-9, -, .) and is not case sensitive. The host name must begin with a letter. Host names containing a dash (-) must be enclosed in double quotes.

:ipaddr – The IP address to be associated with the hostname. The node’s IP address. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:type – Specifies if the host resides on the IP card on the EAGLE 5 ISS (**type=local**, the default value), or if the host resides on equipment that is not in the EAGLE 5 ISS (**type=remote**). This parameter is optional.

The IP address for a local host must be shown in the **rtrv-ip-lnk** output.

The IP address for a remote host must not be shown in the **rtrv-ip-lnk** output.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (10 of 512) 2% full
```

2. Verify that the IP address assigned to the IP links by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10   255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----      -----      HALF    10     DIX      NO    NO
1203  A      192.1.1.12   255.255.255.0   ----    ---     DIX      YES   NO
1203  B      -----      -----      HALF    10     DIX      NO    NO
1205  A      192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
```

If a local host is being configured in this procedure, the IP address assigned to the local host must be shown in the **rtrv-ip-lnk** output. If the IP address is not shown in the **rtrv-ip-lnk** output, add the IP address by performing the [Configuring an IP Link](#) procedure.

If a remote host is being configured in this procedure, the IP address assigned to the remote host cannot be shown in the **rtrv-ip-lnk** output.

3. Add IP host information to the database by entering the **ent-ip-host** command.

If a local host is being configured, enter the **ent-ip-host** command with the IP address from step 2, and the **type=local** parameter or without the **type** parameter. If the **type** parameter is not specified with the **ent-ip-host** command, the **type** parameter value defaults to **local**.

If a remote host is being configured, enter the **ent-ip-host** command with the IP address that is not shown in step 2, and the **type=remote** parameter.

For example, enter this command.

```
ent-ip-host:host="kc-hlr1":ipaddr=192.1.1.30
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
ENT-IP-HOST: MASP A - COMPLTD
```

4. Verify the new IP host information in the database by entering the **rtrv-ip-host** command with the **host** parameter value specified in step 3.

For this example, enter this command.

```
rtrv-ip-host:host="kc-hlr1"
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOCAL IPADDR      LOCAL HOST
192.1.1.30        KC-HLR1
```


```
IP Host table is (11 of 512) 2% full
```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-4. Adding an IP Host



Configuring an IP Card

This procedure is used to change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

The **chg-ip-card** command uses the following parameters.

:loc – The card location of the IP card

:srchordr – Host Table Search Order

:dnrsa – Domain name server A's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:dnrsb – Domain name server B's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:domain – The domain name is used to construct a fully-qualified DNS name consisting of 120 characters or less. For example, a domain name can be **tekelec.com**, the hostname is **john.doe**. The fully-qualified DNS name would be **john.doe@tekelec.com**.

:defrouter – Default router IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:rstdomain – Reset Domain name. The parameter is used to reset the domain to a NULL value.

The IP card must be placed out of service.

The **rstdomain** parameter cannot be specified if the **domain** parameter is specified.

There is only one default router (**defrouter** parameter) for each IP card. The default router is used as the primary route unless a static IP routes is defined for the destination IP address. Static IP routes are assigned using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure.

The network portion of the IP address of the default router must match the network portion of one of the IP addresses assigned to the card.

The network portion of the IP address is based on the class of the IP address (shown in [Table 3-3](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

The default router can be associated with only one IP address assigned to the card if the defrouter parameter is specified. For example, the **dnrsa** value for card 1101 is 150.1.1.10. The **dnrsb** value for card 1101 is 160.25.37.1. A default router is provisioned with the IP address 150.1.1.4. The default router is associated with the Ethernet A IP address (the **dnrsa** parameter value), but not the Ethernet B IP address (the **dnrsb** parameter value).

If the default router is associated with one of the IP card's IP addresses, a second gateway router can be assigned to the other IP address on the IP card by provisioning a static IP route for the IP card using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure. Static IP routes can provide gateway routers associated with the other IP address on the IP card. To provision the gateway router (the **gtwy** parameter of the **ent-ip-rte** command) for the other IP address assigned to the IP card, the network portion of the gateway router's IP address must match the network portion of the other IP address assigned to the IP card.

Specifying the IP address 0.0.0.0 for the **dnrsa** or **dnrsb** parameters, removes the IP address for Ethernet A (**dnrsa**) or Ethernet B (**dnrsb**).

When an IP card is entered into the database with the **ent-card** command, the IP stack parameters associated with this card are initially set with these default values:

- **:srchordr** – SRVR
- **:dnrsa** – No DNSA IP address is specified
- **:dnspb** – No DNSB IP address is specified
- **:domain** – No domain name is specified
- **:defrouter** – No default router IP address is specified
- **:rstdomain** – No

The value of any optional parameter not specified with the **chg-ip-card** command is not changed.

Procedure

1. Display the current IP parameters associated with card in the database by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN    -----

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM
```

To change the parameters of an IP card, the signaling link to the card and the card have to be inhibited.

2. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE  IPLIML2
1201  A    nc001        0  IPLIM  SAALTALI
```

3. Retrieve the status of the signaling link shown in step 2 using the **rept-stat-slk** command specifying the card location and signaling link.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001      ----- IS-NR
        Avail      ----
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 4 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 4 and 5, and go to step 6 to verify the card status.

4. Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

5. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001      ----- OOS-MT-DSBLD AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS:not aligned
UNAVAIL REASON = NA
Command Completed.
```

6. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000 DCM   IPLIM IS-NR Active -----
ALARM STATUS = No Alarms.
BPDCM GPL    =
002-1
02-000
IMT BUS A    = Conn
IMT BUS B    = Conn
SIGNALING LINK STATUS
SLK  PST  LS  CLLI
A    IS-NR nc001 -----
Command Completed.
```

If the IP card to be inhibited is in service-normal (IS-NR), go to step 7 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 7 and 8, and go to step 9.

7. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

8. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE  APPL  PST      SST      AST
1201  114-000-000  DCM   IPLIM  IS-NR      Active    -----
ALARM STATUS      = No Alarms.
BPDCM GPL         =
002-1
02-000
IMT  BUS  A       = Conn
IMT  BUS  B       = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----
```

Command Completed.

NOTE: If the **defrouter** parameter is not specified in step 10, skip step 9 and go to step 10.

9. Verify that the IP address of either Ethernet A or B (the address whose network portion matches the network portion of the **defrouter** parameter value to be used in step 10) is in the IP link table by entering the **rtrv-ip-lnk** command with the card location specified in this procedure.

For this example, enter this command.

rtrv-ip-lnk: loc=1201

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A     192.1.1.10    255.255.255.0  ----   ---   DIX      YES   NO
1201  B     -----      -----      ----   ---   DIX      YES   NO
```

If the network portion of the IP address specified by the **defrouter** value does not match the network portions of either IP address displayed in this step, perform one of these actions:

- Choose another value for the **defrouter** parameter, making sure that the network portion of the new IP address matches the network portion of one of the IP addresses displayed in this step.
- Perform the [Configuring an IP Link](#) procedure and change one of the IP addresses shown in this step so that the network portion of the new IP address changed in the [Configuring an IP Link](#) procedure matches the network portion of the IP address value for the **defrouter** parameter.

10. Change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

For this example, enter this command.

chg-ip-card: loc=1201: srchordr=local: dnsa=192.1.1.40 : domain=nc.tekelec.com

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
CHG-IP-CARD: MASP A - COMPLTD
```

11. Verify the new IP parameters associated with the IP card that was changed in step 10 by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM
```

NOTE: If step 7 was not performed, skip steps 12 and 13, and go to step 14.

12. Allow the IP card that was inhibited in step 7 by using the **alw-card** command.

For example, enter this command.

alw-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

13. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION    TYPE    APPL    PST    SST    AST
1201  114-000-000  DCM     IPLIM   IS-NR   Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
  SLK  PST      LS      CLLI
  A    IS-NR    nc001  -----
```

Command Completed.

NOTE: If step 4 was not performed, skip steps 14 and 15, and go to step 16.

14. Activate the signaling link from step 4 using the **act-slk** command.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a


This message should appear.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----   IS-NR
        Avail     ----
Command Completed.
```


16. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-5. Changing an IP Card





Adding an IP Route

This procedure is used to add an IP route to the database using the **ent-ip-rte** command.

The **ent-ip-rte** command uses these parameters.

:loc – The location of the IP card that the IP route will be assigned to.

:dest – The IP address of the remote host or network.

:submask – The subnet mask of the destination IP address.

:gtwy – The IP address of the gateway or router that will send the IP data to its final destination.

There can be a maximum of 64 IP routes assigned to an IP card.

The EAGLE 5 ISS can contain a maximum of 1024 IP routes.

If the IP card specified by the **loc** parameter is a single-slot EDCM, the card may contain IP addresses for Ethernet A and B. If the IP card specified by the **loc** parameter is a DCM, the card can contain an IP address for Ethernet A only.

The network portion of the IP address value of the **gtwy** parameter must be the same as the network portion of the IP addresses shown for either the A or B interfaces in the **rtrv-ip-card** output.

The value of the **dest** and **gtwy** parameters cannot be 127.x.x.x (the loopback address), 0.0.0.0, or the IP addresses of the A or B interfaces on the IP card, and cannot be assigned to another IP card.

If the **dest** parameter value represents a host IP address, the value for the **submask** parameter must be 255.255.255.255. Otherwise, the **submask** parameter value identifies the network/host ID portions that must be entered when the **dest** parameter value represents a network address.

The submask is applied to the IP address which is being routed to see if it yields a route match. For example, if IP address 192.1.1.2 is being routed and the IP routing table contains these entries.

Table 3-4. Sample IP Routing Table

IP address	Submask	Gateway
191.1.0.0	255.255.0.0	192.168.110.250
192.0.0.0	255.0.0.0	192.168.110.251

IP routing occurs as follows:

1. The subnet mask of route 1 (255.255.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.1.0.0. IP address 192.1.0.0 does not match IP address 191.1.0.0 in the IP routing table, so the next route is chosen.
2. The subnet mask of route 2 (255.0.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.0.0.0 which matches the second route in the IP routing table, so this route is selected for routing this datagram.

See [Table 3-5](#) for the valid input values for the **submask** and **dest** parameter combinations.

Table 3-5. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0

Network Class	IP Network Address Range	Valid Subnet Mask Values
		255.224.0.0 255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.1.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **dest** parameter of the **ent-ip-rte** command, the subnet address that results from the **dest** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1301 128.252.10.5     255.255.255.255 140.188.13.33
1301 128.252.0.0       255.255.0.0      140.188.13.34
1301 150.10.1.1        255.255.255.255 140.190.15.3
1303 192.168.10.1      255.255.255.255 150.190.15.23
1303 192.168.0.0       255.255.255.0    150.190.15.24
```

IP Route table is (5 of 1024) 1% full

2. Display the IP cards in the database with the **rtrv-ip-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1212
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER 150.1.1.100
  DOMAIN    NC. TEKELEC. COM

LOC 1301
  SRCHORDR  SRVRONLY
  DNSA      140.188.13.10
  DNSB      140.190.15.28
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1303
  SRCHORDR  LOCAL
  DNSA      150.190.15.1
  DNSB      -----
  DEFROUTER 150.190.15.25
  DOMAIN    NC. TEKELEC. COM
```

If the required IP card is not shown in the **rtrv-ip-card** output, perform the [Adding an IPLIMx Card](#) procedure to add the card to the database.

Perform the [Configuring an IP Card](#) procedure and make sure that the network portion of the IP addresses assigned for the A or B interfaces of the IP card is the same as the network portion of the IP address that will be assigned to the **gtwy** parameter of the IP route

NOTE: If a Class A or C IP address (see [Table 5-5](#)) will be specified for the **dest parameter in step 4, skip step 3 and go to step 4.**

3. The subnet address that results from the **dest** and **submask** parameter values of the **ent-ip-rte** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 4.

This is an example of the possible output if the E5IS feature is on.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0
```

Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 4.

4. Add the IP route to the database using the **ent-ip-rte** command.

For this example, enter this command.

```
ent-ip-
rte:loc=1212:dest=132.10.175.20:submask=255.255.255.255 :gtwy=150.1.1.5
0
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command with the card location specified with the **ent-ip-rte** command in step 4.

For this example, enter these commands.

rtrv-ip-rte:loc=1212

This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20  255.255.255.255 150.1.1.50
IP Route table is (6 of 1024) 1% full
```


6. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-6. Adding an IP Route





Adding a Socket to an IPLIMx Signaling Link

This procedure is used to add a socket to an IPLIMx signaling link using the **ent-appl-sock** command. The combination of local host, local TCP port, remote host and remote TCP port defines a socket.

The **ent-appl-sock** command uses these parameters.

:sname— The name assigned to the socket. Valid socket names can contain up to 15 alphanumeric characters where the first character is a letter and the remaining characters are alphanumeric characters. The **sname** parameter value is not case-sensitive.

:lhost – Local Hostname. The logical name assigned to the local host device. The local host name must be shown in the **LOCAL HOST** column of the **rtrv-ip-host** output. Local host names that contain dashes (-) must be enclosed in double quotes (“”).

:lport – The TCP port number for the local host.

:rhost – Remote Hostname. The logical name assigned to the remote host device. The remote host name does not have to be shown in the **rtrv-ip-host** output. If remote host name is shown in the **rtrv-ip-host** output, it must be shown in the **REMOTE HOST** column of the **rtrv-ip-host** output. Remote host names that contain dashes (-) must be enclosed in double quotes (“”).

:rport – The TCP port number of the remote host.

:link – The signaling link on the IP card. If a signaling link is not specified for a socket when it is entered, the socket defaults to the signaling link A. If the card’s application is **iplim** or **iplimi**, and the card is a dual-slot

DCM, the values for the **link** parameter can be only **a** or **b**. If the card's application is **iplim** or **iplimi**, and the card is a single-slot EDCM, the values for the **link** parameter can be **a**, **a1**, **a2**, **a3**, **b**, **b1**, **b2**, or **b3**.

NOTE: The port parameter can be used in place of the link parameter to specify the signaling link on the card.

Each IP card can have one socket for each signaling link assigned to the card. Dual-slot DCMs can have a maximum of two sockets. Single-slot EDCMs can have a maximum of 8 sockets.

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

The socket name must be unique (not already used).

The socket table, which contains both the socket and association data, contains fields whose values are not assigned using the **ent-appl-sock** command. When a socket is added to the database, these fields receive their default values. If a different value is desired, the **chg-appl-sock** command must be used. These fields and their default values are:

open=no	dcmps=10
alw=no	rexmit=fixed
server=yes	rtt=60

The value of the **lhost** and **rhost** parameters is a text string of up to 60 characters, with the first character being a letter. The command line on the terminal can contain up to 150 characters. If the host name is too long to fit on the **ent-appl-sock** command line, perform the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure to complete the entry of the host name.

The IP address of the local host (**lhost** parameter) must be shown in the **rtrv-ip-lnk** output.

The **ipliml2** parameter value of the signaling link assigned to the socket must be **saaltali**.

The signaling link being assigned to the socket must be out of service. This state is shown in the **rept-stat-slk** output with the entries **OOS-MT** in the **PST** field and **Unavail** in the **SST** field.

If the socket is being opened in this procedure with the **chg-appl-sock** command and the **open=yes** parameter, the signaling link assigned to the socket must be in the database and the **ipliml2** parameter value of the signaling link assigned to the socket must be **saaltali**.

The B Ethernet interface of the IP card can be used only if the IP card is a single-slot EDCM.

If the socket is being activated in this procedure with the **chg-appl-sock** command, the socket must contain values for the **lhost**, **lport**, **rhost**, and **rport** parameters.

Canceling the RTRV-APPL-SOCK Command

Because the **rtrv-appl-sock** command used in this procedure can output information for a long period of time, the **rtrv-appl-sock** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** command was entered.

- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** command was entered, from another terminal other than the terminal where the **rtrv-appl-sock** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

- Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME kchl11201
LINK   A
LHOST  ipnode1-1201
RHOST  kc-hlr1
LPORT  7000          RPORT  7000
SERVER YES          DCMPS  1
REXMIT FIXED        RTT    60
OPEN   YES          ALW    YES
```

```
SNAME sock1
LINK   A
LHOST  IPNODE2-1205
RHOST  remotehost1
LPORT  1024          RPORT  2048
SERVER YES          DCMPS  10
REXMIT FIXED        RTT    60
OPEN   YES          ALW    YES
```

```
SNAME sock2
LINK   A
LHOST  IPNODE2-1205
RHOST  remotehost2
LPORT  2000          RPORT  2000
SERVER YES          DCMPS  10
REXMIT FIXED        RTT    60
OPEN   YES          ALW    YES
```

IP Appl Sock/Assoc table is (5 of 4000) 1% full

- Display the IP links in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A    192.1.1.10      255.255.255.128  HALF    10     802.3    NO    NO
1201  B    -----          -----          HALF    10     DIX      NO    NO
1203  A    192.1.1.12      255.255.255.0   ----    ---    DIX      YES   NO
1203  B    -----          -----          HALF    10     DIX      NO    NO
1205  A    192.1.1.14      255.255.255.0   FULL    100    DIX      NO    NO
1205  B    -----          -----          HALF    10     DIX      NO    NO
2101  A    192.1.1.20      255.255.255.0   FULL    100    DIX      NO    NO
2101  B    -----          -----          HALF    10     DIX      NO    NO
2103  A    192.1.1.22      255.255.255.0   FULL    100    DIX      NO    NO
2103  B    -----          -----          HALF    10     DIX      NO    NO
2105  A    192.1.1.24      255.255.255.0   FULL    100    DIX      NO    NO
2105  B    -----          -----          HALF    10     DIX      NO    NO
2205  A    192.1.1.30      255.255.255.0   FULL    100    DIX      NO    NO
2205  B    -----          -----          HALF    10     DIX      NO    NO
2207  A    192.1.1.32      255.255.255.0   FULL    100    DIX      NO    NO
```

```

2207 B ----- HALF 10 DIX NO NO
2213 A 192.1.1.50 255.255.255.0 FULL 100 DIX NO NO
2213 B ----- HALF 10 DIX NO NO
2301 A 192.1.1.52 255.255.255.0 FULL 100 DIX NO NO
2301 B ----- HALF 10 DIX NO NO

```

If an IP link containing the required IP address is shown in the **rtrv-ip-lnk** output, go to step 3.

If an IP link containing the required IP address is not shown in the **rtrv-ip-lnk** output, add the IP link using the [Configuring an IP Link](#) procedure. After the IP link is added, perform the [Adding an IP Host](#) procedure to assign this IP address to a local host name. After the local host name has been added, skip step 3 and go to step 4.

3. Verify that the local host name to be assigned to the socket is in the database by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (11 of 512) 2% full

```

If the required hostname is not shown in the **rtrv-ip-host** output, add the IP host name with the IP address shown in step 2 by performing the [Adding an IP Host](#) procedure.

4. Display the application running on the IP card shown in step 2 using the **rept-stat-card** command specifying the location of the IP card.

For this example, enter this command.

rept-stat-card: loc=1203

This is an example of the possible output.

```

rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION    TYPE    APPL    PST    SST    AST
1203  114-000-000  DCM     IPLIM   IS-NR   Active  ----
      ALARM STATUS      = No Alarms.
      BPDCM GPL         = 002-102-000
      IMT BUS A         = Conn
      IMT BUS B         = Conn
      SIGNALING LINK STATUS
      SLK  PST        LS        CLLI
      A    IS-NR      nc001     -----

```

Command Completed.

5. Display the signaling link referenced by the IP link that will be assigned to the socket by entering the **rtrv-sl** command and specifying the card location shown in step 4.

For this example, enter this command.

rtrv-sl: loc=1203

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC   LINK LSN           SLC TYPE   IPLIML2
1203  A    e5e6a         1  IPLIM    SAALTALI
```

The **ipliml2** parameter value for the signaling link assigned to the socket must be **saaltali**. If the **ipliml2** parameter is not **saaltali**, remove the signaling link using the [Removing an IPLIMx Signaling Link](#) procedure. Add the signaling link back into the database with the **ipliml2=saaltali** parameter, and without activating the signaling link, using the [Adding an IPLIMx Signaling Link](#) procedure.

NOTE: If the [Adding an IPLIMx Signaling Link](#) procedure was not performed in this step, skip steps 6, 7, and 8, and go to step 9.

6. Display the status of the signaling link shown in step 5 using the **rept-stat-slk** command specifying the card location and the signaling link that will be assigned to the socket.

For example, enter this command.

rept-stat-slk:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1203,A e5e6a    ----- IS-NR      Avail    ----
Command Completed.
```

NOTE: If the primary state (PST) of the signaling link is **OOS-MT** and the secondary state (SST) is **Unavail**, skip steps 7 and 8, and go to step 9.

7. Deactivate the signaling link from step 6 using the **dact-slk** command.

For example, enter this command.

dact-slk:loc=1203:link=a

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

8. Verify the status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1203,A e5e6a    ----- OOS-MT      Unavail    ----
Command Completed.
```

9. Add the socket to the database by entering the **ent-appl-sock** command with these mandatory parameters:

:sname = the socket name

:lhost = the local host name from step 3

and with at least one of these optional parameters:

:lport = the local port ID, from 1024 to 65535

:rhost = the remote host name

:rport = the remote port ID, from 1024 to 65535

:link = the signaling link value from step 10.

NOTE 1: The port parameter can be used in place of the link parameter to specify the signaling link on the card.

NOTE: See [Flowchart 3-7](#) (Sheet 3) for the rules that apply to the ent-appl-sock command.

For example, enter this command.

```
ent-appl-sock:sname=kchlr11203:lhost="ipnode-1203" :lport=7005:rhost="kc-hlr1":rport=7005:link=a
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-APPL-SOCK: MASP A - COMPLTD
```

NOTE: If the socket added in step 9 is not being activated in this procedure, skip step 10 and go to step 11.

10. Activate the socket added in step 9 by entering the **chg-appl-sock** command with the socket name specified in step 9 and the **open=yes** and **alw=yes** parameters.

For example, enter this command.

```
chg-appl-sock:sname=kchlr11203:open=yes:alw=yes
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

11. Activate the signaling link assigned to the socket using the **act-slk** command.

For example, enter this command.

```
act-slk:loc=1203:link=a
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

12. Verify the status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

```
rept-stat-slk:loc=1203:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1203,A   e5e6a   -----  IS-NR     Avail    ----
Command Completed.
```

13. Verify the new application socket information in the database by entering the **rtrv-appl-sock** command with the socket name specified in step 9.

For this example, enter this command.

rtrv-appl-sock:sname=kchlr11203

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SNAME kchlr11203
LINK A
LHOST ipnode1-1203
RHOST kc-hlr1
LPORT 7005          RPORT 7005
SERVER YES          DCMPS 10
REXMIT FIXED        RTT 60
OPEN YES            ALW YES
```


IP Appl Sock/Assoc table is (3 of 4000) 1% full


14. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-7. Adding a Socket to an IPLIMx Signaling Link





Removing TALI IPLIMx Components

This section describes how to remove the following components from the database.

- An IPLIMx Card – Perform the [Removing an IPLIMx Card](#) procedure
- An IPLIMx Signaling Link – Perform the [Removing an IPLIMx Signaling Link](#) procedure
- An IP Host – Perform the [Removing an IP Host Assigned to an IPLIMx Card](#) procedure
- An IP Route – Perform the [Removing an IP Route](#) procedure
- A Socket – Perform the [Removing a Socket that is Assigned to an IPLIMx Signaling Link](#) procedure

Removing an IPLIMx Card

Use this procedure to remove an IPLIMx card, a card running the **iplim** or **iplimi** applications from the database using the **dlt-card** command.

The card cannot be removed if it does not exist in the database. Prior to removing the card from the database, the signaling links assigned to the card must be removed.



CAUTION: If the IPLIMx card is the last IP card in service, removing this card from the database will cause traffic to be lost.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-15 16:34:56 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101    TSM          SCCP
1102    TSM          GLS
1104    ACMENET      STPLAN
1113    GSPM         EOAM
1114    TDM-A
1115    GSPM         EOAM
1116    TDM-B
1117    MDAL
1201    LIMDS0       SS7ANSI    lsn1           A      0      lsn2           B      1
1202    LIMV35       SS7GX25    lsn2           A      0
1203    LIMV35       SS7ANSI    lsn1           A      0      lsn1           B      1
1204    LIMATM       ATMANSI    atm2gw         A      0
1205    DCM          IPLIM      ipnode1        A      0      ipnode3        B      1
1207    DCM          IPLIM      ipnode2        A      0
1303    DCM          IPLIM      ipnode1        A      0      ipnode3        B      1
1305    DCM          IPLIM      ipnode4        A      0
```

Select a card whose application is either **IPLIM** or **IPLIMI**.

Perform the [Removing an IPLIMx Signaling Link](#) procedure in this chapter to remove all the signaling links assigned to the card, shown in the **LINK** column of the **rtrv-card** output.

The card location is shown in the **CARD** field of the **rtrv-card** command output. No entries in the **LSET NAME**, **LINK**, and **SLC** columns mean that no signaling link is assigned to the card.

2. Remove the card from the database using the **dlt-card** command.

The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter these commands.

dlt-card:loc=1205

dlt-card:loc=1207

When these commands have successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0  
DLT-CARD: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-card** command and specifying the card that was removed in step 2.
For this example, enter these commands.

rtrv-card:loc=1205

rtrv-card:loc=1207


When these commands have successfully completed, this message appears.

```
E2144 Cmd Rej: Location invalid for hardware configuration
```

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.
These messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-8. Removing an IPLIMx Card



Removing an IPLIMx Signaling Link

This procedure is used to remove an IPLIMx signaling link from the database using the **dlt-slk** command. The **dlt-slk** command uses these parameters.

:loc – The card location of the IPLIMx card that the IP signaling link is assigned to.

:link – The signaling link on the card specified in the **loc** parameter.

:force – This parameter must be used to remove the last link in a linkset without having to remove all of the routes that referenced the linkset.

The **tfatcabmlq** parameter (TFA/TCA Broadcast Minimum Link Quantity), assigned to linksets, shows the minimum number of links in the given linkset (or in the combined link set in which it resides) that must be available for traffic. When the number of signaling links in the specified linkset is equal to or greater than the value of the **tfatcabmlq** parameter, the status of the routes that use the specified linkset is set to allowed and can carry traffic. Otherwise, these routes are restricted. The value of the **tfatcabmlq** parameter cannot exceed the total number of signaling links contained in the linkset.

The **dlt-slk** command makes sure that the number of signaling links assigned to a linkset is greater than or equal to the value of the **tfatcabmlq** parameter. If the number of signaling links associated with a linkset drops below the value of the **tfatcabmlq** parameter for that linkset, the **tfatcabmlq** value for that linkset is automatically decremented. The value of the **tfatcabmlq** parameter for a specified linkset can be verified using

the **rtrv-ls:lsn=<linkset name>** command specifying the name of the linkset. The **tfatcabmlq** parameter value is shown in the **tfatcabmlq** field of the **rtrv-ls** command output.

Canceling the RTRV-SLK Command

Because the **rtrv-slk** command used in this procedure can output information for a long period of time, the **rtrv-slk** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-slk** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-slk** command was entered, from another terminal other than the terminal where the **rtrv-slk** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link configuration using the **rtrv-slk** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
```

LOC	LINK	LSN	SLC	TYPE	L2T SET BPS	L1 MODE TSET	ECM	PCR N1	PCR N2
1201	A	ls01	0	LIMDS0	1 56000	---	BASIC	---	---
1201	B	lsa1	0	LIMDS0	1 56000	---	BASIC	---	---
1202	B	ls02	0	LIMV35	2 64000	DTE ---	BASIC	---	---
1203	A	ls03	0	LIMDS0	3 56000	---	BASIC	---	---
1203	B	lsa2	0	LIMDS0	1 56000	---	BASIC	---	---
1204	B	ls01	1	LIMDS0	1 56000	---	BASIC	---	---
1205	A	lsa3	0	LIMV35	4 64000	DCE ON	BASIC	---	---
1206	A	ls02	1	LIMV35	2 64000	DTE ---	BASIC	---	---
1207	A	lsn1207a	0	LIMDS0	1 56000	---	BASIC	---	---
1207	B	lsn1207b	0	LIMDS0	1 56000	---	BASIC	---	---
1208	B	ls03	1	LIMDS0	3 56000	---	BASIC	---	---
1212	A	ls04	0	LIMV35	4 64000	DTE ---	BASIC	---	---
1213	B	ls05	0	LIMDS0	5 56000	---	BASIC	---	---
1214	A	lsn1214a	0	LIMV35	2 64000	DTE ---	PCR	76	3800
1214	B	lsa3	1	LIMV35	4 64000	DCE ON	BASIC	---	---
1215	A	ls05	1	LIMDS0	5 56000	---	BASIC	---	---
1301	B	ls06	0	LIMV35	6 56000	DTE ---	BASIC	---	---
1304	B	ls06	1	LIMV35	6 56000	DTE ---	BASIC	---	---
1308	A	ls06	2	LIMV35	6 56000	DTE ---	BASIC	---	---
1311	A	ls01	2	LIMDS0	1 56000	---	BASIC	---	---
1311	A1	ls05	2	LIMDS0	5 56000	---	BASIC	---	---
1311	B	ls03	2	LIMDS0	3 56000	---	BASIC	---	---
1311	B1	ls07	1	LIMDS0	7 56000	---	BASIC	---	---
1313	A	ls07	0	LIMDS0	7 56000	---	BASIC	---	---
1315	A	lsn5	0	LIMV35	11 64000	DTE OFF	BASIC	---	---
1317	A	lsi7	0	LIMV35	11 64000	DTE OFF	BASIC	---	---

LOC	LINK	LSN	SLC	TYPE	LP SET BPS	ATM TSEL	VCI	VPI	LL
1302	A	atmansio	0	LIMATM	3 1544000	EXTERNAL	35	15	0
1305	A	atmansii	0	LIMATM	4 1544000	INTERNAL	100	20	2
1318	A	atmansio	1	LIMATM	9 1544000	LINE	150	25	4

LP

ATM

E1ATM

LOC	LINK	LSN	SLC	TYPE	SET	BPS	TSEL	VCI	VPI	CRC4	SI	SN
2101	A	atmitu1	0	LIME1ATM	5	2.048M	LINE	150	2	ON	1	20
2105	A	atmitu1	1	LIME1ATM	5	2.048M	LINE	35	15	ON	2	15

LOC	LINK	LSN	SLC	TYPE	IPLIML2
2202	A	lsnlp1	0	IPLIM	SAALTALI
2205	A	lsnip1	1	IPLIM	M2PA
2204	B	lsnlp2	0	IPLIM	M2PA
2213	A	lsnip5	0	IPLIMI	M2PA
2215	A	lsnlp2	1	IPLIM	SAALTALI

LOC	LINK	LSN	SLC	TYPE
2207	A	lsnlp3	0	SS7IPGW
2211	A	lsnlp4	0	IPGWI

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	E1 LOC	E1 PORT	TS

No Links Set Up.

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	T1 LOC	T1 PORT	TS

No Links Set Up.

SLK table is (31 of 1200) 6% full

2. Display the IP link associated with the card that the signaling link being removed the database is assigned to.

Enter the **rtrv-ip-lnk** command with the card location of the signaling link being removed shown in step 1. For this example, enter these commands.

rtrv-ip-lnk:loc=2202

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST
2202  A     192.3.1.10        255.255.255.128  HALF    10     802.3    NO    NO
2202  B     -----            -----            HALF    10     DIX      NO    NO
```

rtrv-ip-lnk:loc=2204

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST
2204  A     192.1.1.10        255.255.255.128  HALF    10     802.3    NO    NO
2204  B     -----            -----            HALF    10     DIX      NO    NO
```

3. Display the IP host information associated with the IP link by entering the **rtrv-ip-host** command with the IP address shown in step 2.

For this example, enter these commands.

rtrv-ip-host:ipaddr=192.001.001.010

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1_2204
```

IP Host table is (11 of 512) 2% full

rtrv-ip-host:ipaddr=192.003.001.010

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR    LOCAL HOST
192.3.1.10      IPNODE1_2202
```

IP Host table is (11 of 512) 2% full

4. Display the socket associated with the local host name shown in step 3 by entering the **rtrv-appl-sock** command.

For this example, enter these commands.

rtrv-appl-sock: lhost=ipnode1_2202

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_2202
LINK   A
LHOST  IPNODE1_2202
RHOST  KC_HLR2
LPORT  7000          RPORT  7001
SERVER YES          DCMPS  1
REXMIT FIXED        RTT    60
OPEN   YES          ALW    YES
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

rtrv-appl-sock: lhost=ipnode1_2215

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

NOTE: If there are no sockets assigned to the specified local host name, the rtrv-appl-sock output shows no socket information as shown above.

5. Change the **open** and **alw** parameter values in the socket shown in step 4 using the **chg-appl-sock** command with the **open=no** and **alw=no** parameters, as necessary.

NOTE: If there is no socket shown in step 4, or the open and alw parameter values of the socket shown in step 4 are no, skip this step and go to step 6.

For example, enter this command.

chg-appl-sock: sname=kc_hlr1_2202: open=no: alw=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

6. Display the association associated with the local host name shown in step 4 that was not assigned to a socket by entering the **rtrv-assoc** command.

For this example, enter this command.

rtrv-assoc: lhost=ipnode1_2215

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME          LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
```

```
assoc1          2215 A      A      M2PA      1030 1030 YES YES
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 2204
```

rt rv-assoc: lhost=ipnode1_2202

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
```

NOTE: If there are no associations assigned to the specified local host name, the rt rv-assoc output shows no association information as shown above.

7. Change the value of the **open** and **alw** parameters to **no** by specifying the **chg-assoc** command with the **open=no** and **alw=no** parameters, as necessary.

NOTE: If there is no association shown in step 6, or the open and alw parameter values of the association shown in step 6 are no, skip this step and go to step 8.

For this example, enter this command.

chg-assoc: aname=assoc1: open=no: alw=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

8. Deactivate the link to be removed using the **dact-slk** command, using the output from step 1 to obtain the card location and **link** parameter value of the signaling link to be removed.

For this example, enter these commands.

dact-slk: loc=2202: link=a

dact-slk: loc=2215: link=a

When each of these command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

9. Verify that the link is out of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-slk** command with the card location and **link** parameter values specified in step 8.

For this example, enter these commands.

rept-stat-slk: loc=2202: link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-23 13:06:25 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
2202,A   lsnlp1    ls05clli  OOS-MT_DSBLD Unavail  ----
ALARM STATUS      = *    0235 REPT-LNK-MGTINH: local inhibited
UNAVAIL REASON    = LI
```

rept-stat-slk: loc=2215: link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-23 13:06:25 GMT EAGLE5 36.0.0
```

```

SLK      LSN      CLLI      PST      SST      AST
2215,A   lsnlp2   ls04clli  OOS-MT   Unavail   ----
  ALARM STATUS   = *    0235 REPT-LNK-MGTINH: local inhibited
  UNAVAIL REASON = LI

```

10. If the signaling link to be removed is the last signaling link on a card, the card must be inhibited before the signaling link is removed.

NOTE: If the signaling link being removed is not the last signaling link on the card, skip steps 10 and 11, and go to step 12.

Before entering the **dlt-slk** command, enter the **rmv-card** command and specify the location of the card to be inhibited. The card location is shown in the output of **rept-stat-slk** command executed in step 9.

In the example used for this procedure, the signaling link is the last signaling link on the card and must be inhibited. Enter these commands.

rmv-card:loc=2202

rmv-card:loc=2215

When each of these command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Card has been inhibited.

```

11. Verify that the card has been inhibited by entering the **rept-stat-card** command with the card location specified in step 10. For this example, enter these commands.

rept-stat-card:loc=2202

This is an example of the possible output.

```

rlghncxa03w 07-05-27 16:43:42 GMT EAGLE5 37.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
2202  114-001-000  DCM      IPLIM      OOS-MT-DSBLD  Isolated  -----
  ALARM STATUS      = **  0013 Card is isolated from the system
  BPDCM GPL         = 002-102-000
  IMT BUS A         = Disc
  IMT BUS B         = Disc
  SIGNALING LINK STATUS
    SLK  PST      LS      CLLI      E5IS
    A    OOS-MT   lsnlp1  -----  INACTIVE

```

Command Completed.

rept-stat-card:loc=2215

This is an example of the possible output.

```

rlghncxa03w 07-05-27 16:43:42 GMT EAGLE5 37.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
2215  114-001-000  DCM      IPLIM      OOS-MT-DSBLD  Isolated  -----
  ALARM STATUS      = **  0013 Card is isolated from the system
  BPDCM GPL         = 002-102-000
  IMT BUS A         = Disc
  IMT BUS B         = Disc
  SIGNALING LINK STATUS
    SLK  PST      LS      CLLI      E5IS
    A    OOS-MT   lsnlp2  -----  INACTIVE

```

Command Completed.

12. Remove the signaling link from the EAGLE 5 ISS using the **dlt-slk** command.

If there is only one signaling link in the linkset, the **force=yes** parameter must be specified to remove the signaling link.

In the example used in this procedure, the signaling link is the last signaling link in the linkset. Enter these commands.

```
dlt-slk:loc=2202:link=a:force=yes
```

```
dlt-slk:loc=2215:link=a:force=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:17 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD
```

13. Verify the changes using the **rtrv-slk** command with the card location and link values specified in step 12. For this example, enter these commands.

```
rtrv-slk:loc=2202:link=a
```

```
rtrv-slk:loc=2215:link=a
```

When the **rtrv-slk** command has completed, the specified signaling link is not shown in the **rtrv-slk** output, as shown in this example.

```
rlghncxa03w 07-05-19 21:16:37 GMT EAGLE5 37.0.0
```

```
LOC  LINK LSN          SLC TYPE      IPLIML2
```


```
No Links Set up.
```


14. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-9. Removing an IP Signaling Link





Removing an IP Host Assigned to an IPLIMx Card

This procedure removes an IP host that is assigned to an IPLIMx card using the **dlt-ip-host** command.

The **dlt-ip-host** command uses the following parameter.

:host— Hostname. The hostname to be removed. This parameter identifies the logical name assigned to a device with an IP address.

No sockets and associations can reference the host name being removed in this procedure.

The sockets referencing the host name can be removed by performing the [Removing a Socket that is Assigned to an IPLIMx Signaling Link](#) procedure in this chapter or the host name in these sockets can be changed by performing the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure. The host name assigned to sockets is displayed in the **rtrv-appl-sock** outputs.

The associations referencing the host name can be removed by performing the [Removing an M2PA Association](#) procedure or the host name in these associations can be changed by performing the [Changing an M2PA Association](#) procedure. The host name assigned to associations is displayed in the **rtrv-assoc** outputs.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

LOCAL IPADDR	LOCAL HOST
192.1.1.10	IPNODE1-1201
192.1.1.12	IPNODE1-1203
192.1.1.14	IPNODE1-1205
192.1.1.20	IPNODE2-1201
192.1.1.22	IPNODE2-1203
192.1.1.24	IPNODE2-1205
192.1.1.30	KC-HLR1
192.1.1.32	KC-HLR2
192.1.1.50	DN-MSC1
192.1.1.52	DN-MSC2
192.3.3.33	GW100. NC. TEKELEC. COM

REMOTE IPADDR	REMOTE HOST
150.1.1.5	NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (12 of 512) 2% full

2. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-link** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
```

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
1303	A	192.1.1.10	255.255.255.128	HALF	10	802.3	NO	NO
1303	B	-----	-----	HALF	10	DIX	NO	NO
1305	A	192.1.1.12	255.255.255.0	----	---	DIX	YES	NO
1305	B	-----	-----	HALF	10	DIX	NO	NO
1313	A	192.1.1.14	255.255.255.0	FULL	100	DIX	NO	NO
1313	B	-----	-----	HALF	10	DIX	NO	NO
2101	A	192.1.1.20	255.255.255.0	FULL	100	DIX	NO	NO
2101	B	-----	-----	HALF	10	DIX	NO	NO
2103	A	192.1.1.22	255.255.255.0	FULL	100	DIX	NO	NO
2103	B	-----	-----	HALF	10	DIX	NO	NO
2105	A	192.1.1.24	255.255.255.0	FULL	100	DIX	NO	NO
2105	B	-----	-----	HALF	10	DIX	NO	NO
2205	A	192.1.1.30	255.255.255.0	FULL	100	DIX	NO	NO
2205	B	-----	-----	HALF	10	DIX	NO	NO
2207	A	192.1.1.32	255.255.255.0	FULL	100	DIX	NO	NO
2207	B	-----	-----	HALF	10	DIX	NO	NO
2213	A	192.1.1.50	255.255.255.0	FULL	100	DIX	NO	NO
2213	B	-----	-----	HALF	10	DIX	NO	NO
2301	A	192.1.1.52	255.255.255.0	FULL	100	DIX	NO	NO
2301	B	-----	-----	HALF	10	DIX	NO	NO

```

2305  A   192.3.3.33      255.255.255.0  FULL   100   DIX    NO    NO
2305  B   -----      -----  HALF   10    DIX    NO    NO

```

3. Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```

rlghncxa03w 07-05-28 09:12:36 GMT EAGLE5 37.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC  LSET NAME      LINK SLC
1101   TSM        SCCP
1102   TSM        GLS
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI  sp2            A    0    sp1            B    0
1203   LIMDS0     SS7ANSI  sp3            A    0
1204   LIMDS0     SS7ANSI  sp3            A    1
1206   LIMDS0     SS7ANSI  nsp3           A    1    nsp4           B    1
1207   LIMV35     SS7GX25  nsp1           A    0
1208   LIMV35     SS7GX25  nsp1           A    1
1216   ACMENET     STPLAN
1301   LIMDS0     SS7ANSI  sp6            A    1    sp7            B    0
1302   LIMDS0     SS7ANSI  sp7            A    1    sp5            B    1
1303   DCM        IPLIM    ipnode1        A    0    ipnode3        B    1
1305   DCM        IPLIM    ipnode4        A    0
1307   ACMENET     STPLAN
1313   DCM        SS7IPGW  ipgtwy1        A    0
2101   DCM        SS7IPGW  ipgtwy2        A    0
2103   DCM        SS7IPGW  ipgtwy3        A    0
2105   DCM        IPLIM    ipnode1        A1   1    ipnode5        B    2
2205   DCM        IPLIM    ipnode3        A2   0    ipnode6        B1   2
2207   DCM        IPLIM    ipnode5        A    0    ipnode4        B3    1
2213   DCM        IPLIM    ipnode5        A3   1    ipnode3        B2    2
2301   DCM        IPLIM    ipnode6        A    0    ipnode1        B    2
2305   DCM        IPLIM    ipnode6        A1   1    ipnode1        B1    3

```

Select an IP host whose IP address is assigned to a card running the IPLIM or IPLIMI application.

4. Display the sockets referencing the host name being removed in this procedure by entering the **rtrv-appl-sock** command.

For this example, enter this command.

rtrv-appl-sock: lhost=gw100.nc.tekelec.com

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_1103
LINK   A
LHOST  GW100. NC. TEKELEC. COM
RHOST  KC_HLR2
LPORT  7000      RPORT  7001
SERVER YES      DCMP5   1
REXMIT FIXED    RTT     60
OPEN   YES      ALW     YES

```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

If no sockets referencing the host name being removed in this procedure are shown in this step, go to step 5.

Any sockets referencing the host name must either be removed or the host name assigned to the socket must be changed. To remove the sockets, perform the [Removing a Socket that is Assigned to an IPLIMx Signaling Link](#) procedure.

Go to step 5 after the sockets have been removed.

To change the host name assigned to the sockets, perform the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure.

Go to step 5 after the host name assigned to the sockets have been changed.

5. Display the associations referencing the host name being removed in this procedure by entering the **rtrv-assoc** command with the local host name.

For this example, enter this command.

rtrv-assoc: lhost=gw100.nc.tekelec.com

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
a2         2305 A    A    M2PA  7205  7001 NO   NO
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (200 KB of 1600 KB) on LOC = 2305

If no associations referencing the host name being removed in this procedure are shown in this step, go to step 6.

Any associations referencing the host name must either be removed or the host name assigned to the association must be changed.

To remove the associations, perform the [Removing an M2PA Association](#) procedure.

Go to step 6 after the associations have been removed.

To change the host name assigned to the associations, perform the [Changing an M2PA Association](#) procedure.

Go to step 6 after the host name assigned to the associations have been changed.

6. Delete IP host information from the database by entering the **dlt-ip-host** command.

For example, enter this command.

dlt-ip-host: host=gw100.nc.tekelec.com

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
DLT-IP-HOST: MASP A - COMPLTD
```

7. Verify the changes by entering the **rtrv-ip-host** command with the host name specified in step 6.

For this example, enter this command.

rtrv-ip-host: host=gw100.nc.tekelec.com

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR    LOCAL HOST
```

IP Host table is (10 of 512) 2% full


8. Back up the new changes using the **chg-db: action=backup: dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
```

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 3-10. Removing an IP Host Assigned to an IPLIMx Card





Removing an IP Route

This procedure is used to remove an IP route from the database using the **dlt-ip-rte** command.

The **dlt-ip-rte** command uses these parameters.

: **loc** – The location of the IP card containing the IP route being removed.

:dest – The IP address of the remote host or network assigned to the IP route being removed.

:force – To remove the IP route, the IP card that the route is assigned to must be out of service, or the **force=yes** parameter must be specified with the **dlt-ip-rte** command. The **force=yes** parameter allows the IP route to be removed if the IP card is in service.



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20   255.255.0.0      150.1.1.50
1301 128.252.10.5     255.255.255.255  140.188.13.33
1301 128.252.0.0      255.255.0.0      140.188.13.34
1301 150.10.1.1       255.255.255.255  140.190.15.3
1303 192.168.10.1     255.255.255.255  150.190.15.23
1303 192.168.0.0      255.255.255.0    150.190.15.24
```

IP Route table is (6 of 1024) 1% full

2. Verify the state of the IP card containing the IP route being removed by entering the **rept-stat-card** command and specifying the card location of the IP card.

The IP card should be in the out-of-service maintenance-disabled (OOS-MT-DSBLD) in order to remove the IP route. If the IP card's state is out-of-service maintenance-disabled, the entry **OOS-MT-DSBLD** is shown in the **PST** column of the **rept-stat-card** output. For this example, enter this command.

rept-stat-card:loc=1301

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST      SST      AST
1301  114-000-000  DCM   IPLIM  IS-NR    Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST      LS      CLLI
A     IS-NR    nc001   -----
```

Command Completed.

NOTE: If the output of step 2 shows that the IP card's state is not OOS-MT-DSBLD, and you do not wish to change the state of the IP card, skip step 3 and go to step 4.

3. Change the IP card's state to OOS-MT-DSBLD using the **inh-card** command and specifying the card location of the IP card.

For this example, enter these commands.

inh-card:loc=1301

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Card has been inhibited.
```

4. Remove the IP route from the database using the **dlt-ip-rte** command.

If the state of the IP card is not OOS-MT-DSBLD, the **force=yes** parameter must be specified with the **dlt-ip-rte** command. For this example, enter this command.

```
dlt-ip-rte:loc=1301:dest=128.252.0.0
```



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212  132.10.175.20    255.255.0.0      150.1.1.50
1301  128.252.10.5     255.255.255.255  140.188.13.33
1301  150.10.1.1       255.255.255.255  140.190.15.3
1303  192.168.10.1     255.255.255.255  150.190.15.23
1303  192.168.0.0      255.255.0.0      150.190.15.24
```

IP Route table is (5 of 1024) 1% full

6. Place the IP card back into service by using the **alw-card** command.

NOTE: If the IP card containing the IP route that was removed from the database does not contain other IP routes, skip step 6 and go to step 7.

For example, enter this command.

```
alw-card:loc=1301
```

This message should appear.


```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

7. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-11. Removing an IP Route



Removing a Socket that is Assigned to an IPLIMx Signaling Link

This procedure is used to remove a socket from the database that is assigned to an IPLIMx signaling link using the **dlt-appl-sock** command.

The **dlt-appl-sock** command has only one parameter, **:sname** – the name of the socket being removed.

The **open** parameter value of the socket must be set to **no** before the socket can be removed. Use the **chg-appl-sock** command to change the value of the **open** parameter.

Canceling the RTRV-APPL-SOCK and RTRV-APPL-RTKEY Commands

Because the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchl11201
LINK A
LHOST ipnode1-1201
RHOST kc-hlr1
LPORT 7000          RPORT 7000
SERVER YES          DCMPS 1
REXMIT FIXED        RTT 60
OPEN YES            ALW NO

SNAME kchl11203
LINK A
LHOST ipnode1-1203
RHOST kc-hlr1
LPORT 7005          RPORT 7005
SERVER YES          DCMPS 10
REXMIT FIXED        RTT 60
OPEN NO             ALW NO
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

2. Change the **open** parameter value in the socket being removed from the database using the **chg-appl-sock** command with the **open=no** parameter.

NOTE 1: If the application socket information shows the value of the **open** parameter in the socket being removed from the database is **no**, skip this step and go to step 3.



CAUTION: Setting the **open** parameter value to **no** could cause traffic to be lost.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:open=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

3. Remove the application socket from the database by entering the **dlt-appl-sock** command with the socket name being removed.

For example, enter this command.

dlt-appl-sock:sname=kchlr11201

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
DLT-APPL-SOCK: MASP A - COMPLTD
```

4. Verify the new application socket information in the database by entering the **rtrv-appl-sock** command with the socket name specified in step 3.

For this example, enter this command.

rtrv-appl-sock:sname=kchlr11201

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
IP Appl Sock/Assoc table is (3 of 4000) 1% full
```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-12. Removing an Application Socket



Changing TALI IPLIMx Components

This section describes how to change the attributes of the following components in the database.

- A Socket – Perform the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure
- The IP socket retransmission parameters – Perform the [Configuring IP Socket Retransmission Parameters](#) procedure
- A DCM parameter set – Perform the [Configuring a DCM Parameter Set](#) procedure

Changing the Attributes of a Socket on an IPLIMx Signaling Link

This procedure is used to change a socket in the database using the **chg-appl-sock** command.

The **chg-appl-sock** command uses these parameters.

:sname— Socket Name.

:lhost — Local Hostname. The logical name assigned to the local host device. The local host name must be shown in the **LOCAL HOST** column of the **rtrv-ip-host** output. Local host names that contain dashes (-) must be enclosed in double quotes ("").

:lport — The TCP port number for the Local host.

:rhost — Remote Hostname. The logical name assigned to the remote host device. The remote host name does not have to be shown in the **rtrv-ip-host** output. If remote host name is shown in the **rtrv-ip-host** output, it must be shown in the **REMOTE HOST** column of the **rtrv-ip-host** output. Remote host names that contain dashes (-) must be enclosed in double quotes ("").

:rport — The TCP port number of the remote host.

:link — The signaling link on the IP card. If the card's application is **iplim** or **iplimi**, and the card is a dual-slot DCM, the values for the **link** parameter can be only **a** or **b**. If the card's application is **iplim** or **iplimi**, and the card is a single-slot EDCM, the values for the **link** parameter can be **a**, **a1**, **a2**, **a3**, **b**, **b1**, **b2**, or **b3**.

NOTE: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

:server — Server Role. The role of the local socket in the Client/Server relationship.

:open — Socket State. Indicates to the connection manager software to open the socket if the socket is operational.

:alw — Connection State. Indicates to the connection manager software if the socket is allowed to carry SS7 traffic.

:dcmps — DCM Parameter Set. The DCM parameter set that will be used by the socket.

:rexmit — Indicates the retransmission mode that the user wants the TCP stack to use for this socket.

:rtt — Indicates the measured or expected round trip time (RTT) of the socket in milliseconds.

For more information on the **rexmit** and **rtt** parameters, go to the [Configuring IP Socket Retransmission Parameters](#) procedure.

The **open** parameter must be set to **no** before changes can be made to **server**, **lhost**, **lport**, **rhost**, **rport**, **rtt**, **rexmit**, and **link** parameters.

The **open** parameter must be changed with a separate **chg-appl-sock** command. The **open** parameter can not be on a command line that has **server**, **lhost**, **lport**, **rhost**, and **rport** parameters.

At least one optional parameter is required.

Each IP card can have one socket for each signaling link assigned to the card. Dual-slot DCMs can have a maximum of two sockets. Single-slot EDCM cards can have a maximum of eight sockets.

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

The value of the **lhost** and **rhost** parameters is a text string of up to 60 characters, with the first character being a letter.

The command input is limited to 150 characters, including the hostname.

To set the **open** parameter value to **yes**, the socket specified by the **sname** parameter must contain values for the **lhost**, **lport**, **rhost**, and **rport** parameters.

The **rtt** parameter cannot be specified with the **rexmit=bsd** parameter.

When the **rexmit=fixed** or **rexmit=mod** parameters are specified, the **rtt** parameter must be specified.

The IP address of the local host (**lhost** parameter) must be shown in the **rtrv-ip-lnk** output.

The **ipliml2** parameter value of the signaling link assigned to the socket must be **saaltali**.

The signaling link being assigned to the socket must be out of service. This state is shown in the **rept-stat-slk** output with the entries **OOS-MT** in the **PST** field and **Unavail** in the **SST** field.

If the socket is being opened in this procedure with the **chg-appl-sock** command and the **open=yes** parameter, the signaling link assigned to the socket must be in the database and the **ipliml2** parameter value of the signaling link assigned to the socket must be **saaltali**.

The B Ethernet interface of the IP card can be used only if the IP card is a single-slot EDCM.

If the socket being changed is a client socket, shown in the **rtrv-appl-sock** output with the entry **NO** in the **SERVER** field, the socket's **lhost** and **lport** values cannot match the values of any open socket.

If the socket being changed is a server socket, shown in the **rtrv-appl-sock** output with the entry **YES** in the **SERVER** field, the socket's **lhost** and **lport** values cannot match the values of any open client socket.

Canceling the RTRV-APPL-SOCK Command

Because the **rtrv-appl-sock** command used in this procedure can output information for a long period of time, the **rtrv-appl-sock** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** command was entered, from another terminal other than the terminal where the **rtrv-appl-sock** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
LINK A
LHOST ipnode1-1201
RHOST kc-hlr1
LPORT 7000 RPORT 7000
```



```

SERVER YES          DCMPS 1
REXMIT FIXED        RTT 60
OPEN YES           ALW NO

SNAME kchlr11203
LINK A
LHOST ipnode1-1203
RHOST kc-hlr1
LPORT 7005          RPORT 7005
SERVER YES          DCMPS 10
REXMIT FIXED        RTT 60
OPEN YES           ALW NO

SNAME sock1
LINK A
LHOST IPNODE2-1205
RHOST remotehost1
LPORT 1024          RPORT 2048
SERVER YES          DCMPS 10
REXMIT FIXED        RTT 60
OPEN YES           ALW YES

SNAME sock2
LINK A
LHOST IPNODE2-1205
RHOST remotehost2
LPORT 2000          RPORT 2000
SERVER YES          DCMPS 10
REXMIT FIXED        RTT 60
OPEN YES           ALW YES

```

IP Appl Sock/Assoc table is (7 of 4000) 1% full

NOTE 1: To change the values of these parameters: **server**, **lhost**, **lport**, **rhost**, **link**, **rtt**, **rexmit**, or **rport**, the value of the **open** parameter must be **no**. If the values of any of these parameters are being changed and the **open** parameter value for the socket being changed is **no**, skip step 2 and go to step 3.

NOTE: If only the values of the **alw**, **open**, or **dcmps** parameters are being changed, skip steps 2 through 11, and go to step 12.

2. Change the value of the **open** parameter to **no** using the **chg-appl-sock** command with the **open=no** parameter.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:open=no

When this command has successfully completed, the following message should appear.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD

```

3. Verify that the local host name to be assigned to the socket is in the database by using the **rtrv-ip-host** command.

NOTE: If the local host name or the **link** value of the socket are not being changed, skip steps 3 through 11, and go to step 12.

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR      LOCAL HOST
192.1.1.10        IPNODE1-1201
192.1.1.12        IPNODE1-1203
192.1.1.14        IPNODE1-1205
192.1.1.20        IPNODE2-1201

```

```
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
```

```
REMOTE IPADDR  REMOTE HOST
150.1.1.5       NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (11 of 512) 2% full

4. Display the IP links in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A     192.1.1.10     255.255.255.128 HALF     10     802.3    NO    NO
1201  B     -----        -----        HALF     10     DIX      NO    NO
1203  A     192.1.1.12     255.255.255.0  ----     ---     DIX      YES   NO
1203  B     -----        -----        HALF     10     DIX      NO    NO
1205  A     192.1.1.14     255.255.255.0  FULL    100     DIX      NO    NO
1205  B     -----        -----        HALF     10     DIX      NO    NO
2101  A     192.1.1.20     255.255.255.0  FULL    100     DIX      NO    NO
2101  B     -----        -----        HALF     10     DIX      NO    NO
2103  A     192.1.1.22     255.255.255.0  FULL    100     DIX      NO    NO
2103  B     -----        -----        HALF     10     DIX      NO    NO
2105  A     192.1.1.24     255.255.255.0  FULL    100     DIX      NO    NO
2105  B     -----        -----        HALF     10     DIX      NO    NO
2205  A     192.1.1.30     255.255.255.0  FULL    100     DIX      NO    NO
2205  B     -----        -----        HALF     10     DIX      NO    NO
2207  A     192.1.1.32     255.255.255.0  FULL    100     DIX      NO    NO
2207  B     -----        -----        HALF     10     DIX      NO    NO
2213  A     192.1.1.50     255.255.255.0  FULL    100     DIX      NO    NO
2213  B     -----        -----        HALF     10     DIX      NO    NO
2301  A     192.1.1.52     255.255.255.0  FULL    100     DIX      NO    NO
2301  B     -----        -----        HALF     10     DIX      NO    NO
```

5. Display the signaling link referenced by the IP link that will be assigned to the socket by entering the **rtrv-slk** command and specifying the location of the IP link.

For this example, enter this command.

rtrv-slk: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK  LSN      SLC  TYPE  IPLIML2
1203  A     e5e6a     1    IPLIM  SAALTALI
```

If the required signaling link is in the database, skip step 6 and go to step 7.

6. Add the IP address of the IP link by performing the [Configuring an IP Link](#) procedure.
 - If the local host name of the socket is not being changed, skip steps 6, 7, 8, and 9, and go to step 10.
 - If the required IP link information is shown in the **rtrv-ip-lnk** output in step 4, skip step 6 and go to step 7.
7. Add the new local host name and IP address from step 6 by performing the [Adding an IP Host](#) procedure.

NOTE: If the new local host name is shown in the rtrv-ip-host output in step 3, skip step 7 and go to step 8.

8. Display the signaling link referenced by the IP link that will be assigned to the socket by entering the **rtrv-slk** command and specifying the card location and signaling link shown in step 5.

For this example, enter this command.

rtrv-slk:loc=1201:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE  IPLIML2
1201  A    e5e6a        1  IPLIM   SAALTALI
```

The **ipliml2** parameter value for the signaling link assigned to the socket must be **saaltali**. If the **ipliml2** parameter is not **saaltali**, remove the signaling link using the [Removing an IPLIMx Signaling Link](#) procedure. Add the signaling link back into the database with the **ipliml2=saaltali** parameter, and without activating the signaling link, using the [Adding an IPLIMx Signaling Link](#) procedure.

NOTE: If the [Adding an IPLIMx Signaling Link](#) procedure was not performed in step 8, skip steps 9, 10, and 11, and go to step 12.

9. Display the status of the signaling link shown in step 8 using the **rept-stat-slk** command specifying the card location and signaling link.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK  LSN          CLLI          PST          SST          AST
1201,A  e5e6a      -----  IS-NR          Avail          ----
Command Completed.
```

NOTE: If the primary state (PST) of the signaling link is 00S-MT and the secondary state (SST) is Unavail, skip steps 10 and 11, and go to step 12.

10. Deactivate the signaling link from step 9 using the **act-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

11. Verify the status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK  LSN          CLLI          PST          SST          AST
1201,A  e5e6a      -----  00S-MT          Unavail          ----
Command Completed.
```

12. Change the application socket by using the **chg-app1-sock** command with this mandatory parameter:

:sname = the socket name

and with at least one of these optional parameters:

:lhost = the local host name from step 3

:lport = the local port ID, from 1024 to 65535

:rhost = the remote host name
:rport = the remote port ID, from 1024 to 65535
:link = the signaling link value from step 11.
:server = yes or no
:alw = yes or no
:dcmps = 1 to 10
:open = yes or no.

NOTE: The **open=yes** parameter cannot be specified in this step if the **lhost**, **lport**, **rhost**, **rport**, **link**, **server**, **rexmit**, and **rtt** parameters are specified.

NOTE 1: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

NOTE: See [Flowchart 3-13](#) (Sheet 6) for the rules that apply to the **chg-appl-sock** command.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:rhost="kc-kc-kc":alw=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

13. Change the **open** parameter value back to **yes** by using the **chg-appl-sock** command.

NOTE: If step 2 was not performed in this procedure, or the **open=yes** parameter was specified in step 12, skip step 13 and go to step 14.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:open=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

14. Activate the signaling link assigned to the socket using the **act-slk** command.

For example, enter this command.

act-slk:loc=1201:link=a

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   e5e6a    -----  IS-NR    Avail    ----
Command Completed.

```

16. Verify the new application socket information in the database by entering the **rtrv-appl-sock** command with the socket name specified in step 16.

For this example, enter this command.

rtrv-appl-sock:sname=kchlr11201

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
LINK   A
LHOST  ipnode1-1201
RHOST  kc-kc-kc
LPORT  7000      RPORT  7000
SERVER YES      DCMPS  1
REXMIT FIXED    RTT    60
OPEN   YES      ALW    YES

```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

17. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


Flowchart 3-13. Changing the Attributes of a Socket on an IPLIMx Signaling Link











Notes:

1. The B Ethernet interface cannot be used with the dual-slot DCM. The B Ethernet interface can be used only with the single-slot EDCM.
2. The EAGLE 5 ISS can contain a maximum of 4000 connections (association – application server assignments plus sockets).
3. IPLIMx cards can have only one connection for each signaling link assigned to the card. If the card is a dual-slot DCM, a maximum of two connections for each card. If the card is a single-slot EDCM, the card may contain a maximum of eight connections.
4. The value of the *lhost* and *rhost* parameters is a text string of up to 60 characters, with the first character being a letter.
5. If the socket is a client socket (*server=no*) and the *open* parameter value is being changed to *yes*, the *lhost/lport* parameter values of this socket cannot match the *lhost/lport* values of any other open sockets.
6. If the socket is a server socket (*server=yes*) and the *open* parameter value is being changed to *yes*, the *lhost/lport* parameter values of this socket cannot match the *lhost/lport* values of any other open client sockets.
7. The *rtt* parameter cannot be specified with the *rexmit=bsd* parameter.
8. When the *rexmit=fixed* or *rexmit=mod* parameters are specified, the *rtt* parameter must be specified.
9. The local host name must be shown in the *rtv-ip-host* output in the *LOCAL HOST* column.
10. The remote host name does not have to be shown in the *rtv-ip-host* output. If the remote host name is shown in the *rtv-ip-host* output, it must be shown in the *REMOTE HOST* column.
11. Host names (local and remote) that contain dashes (-) must be enclosed in double quotes (").
12. The *port* parameter can be used in place of the *link* parameter to specify the signaling link assigned to the socket.
13. If the *open* parameter value is being changed to *yes*, the socket must contain values for the *lhost*, *lport*, *rhost*, and *rport* parameters.

Configuring IP Socket Retransmission Parameters

This procedure is used to configure the retransmission parameters for sockets using the **rexmit** and **rtt** parameters of the **chg-appl-sock** command.

:rexmit – Indicates the retransmission mode that the user wants the TCP stack to use for a socket. The **rexmit** parameter values are **bsd** (standard), **fixed** (Tekelec version), or **mod** (combination of **bsd** and **fixed**). The default value is **fixed**.

:rtt – Indicates the measured or expected round trip time of the socket in milliseconds. Be aware that you are entering the round trip time, not the retransmission timeout that will be used for the socket. The initial retransmission timeout that is actually applied to the socket will be the next 125 millisecond increment above the entered round trip time. The default value is 60.

It is important to set the configured round trip time as accurately as possible. When the round trip time is configured too low, network congestion can occur, thus delaying (or preventing) the delivery of SS7 data, resulting in a negative impact on MSU throughput. If the round trip time is set too high, the TCP protocol layer may act unpredictably, resulting in the SS7 service being degraded. The MSU throughput would be lowered, possibly affecting the client application software. When the round trip time is configured correctly, the TCP network can deliver SS7 data in a timely manner with little or no network congestion.

The [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure is used to change the values of these parameters. In addition to using the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure, these **pass** commands are also used in this procedure.

- **ping** – tests for the presence of hosts on the network.
- **sockrtt** – displays the round trip time data
- **netstat -p tcp** – determines if retransmissions have occurred.

For more information of the **pass** commands, go to the *Commands Manual*.

The **rexmit** and **rtt** parameter values are set using the data collected from the **pass** commands.

The **rtt** parameter cannot be specified with the **rexmit=bsd** parameter.

When the **rexmit=fixed** or **rexmit=mod** parameters are specified, the **rtt** parameter must be specified.

Canceling the RTRV-APPL-SOCK Command

Because the **rtrv-appl-sock** command used in this procedure can output information for a long period of time, the **rtrv-appl-sock** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** command was entered, from another terminal other than the terminal where the **rtrv-appl-sock** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchl11201
  LINK  A
  LHOST ipnode1-1201
  RHOST kc-hlr1
  LPORT 7000          RPORT 7000
  SERVER YES          DCMP5 1
  REXMIT FIXED        RTT   60
  OPEN  YES           ALW   NO

SNAME kchl11203
  LINK  A
  LHOST ipnode1-1203
  RHOST kc-hlr1
  LPORT 7005          RPORT 7005
```

```

SERVER YES          DCMPS 10
REXMIT FIXED        RTT   60
OPEN   YES          ALW   YES

```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

2. Display the IP address assigned to the remote host that will be pinged in step 4 using the **rtrv-ip-host** command with the remote host name shown in step. For this example, enter this command.

```
rtrv-ip-host:host="kc-hlr1"
```

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

```

LOCAL IPADDR      LOCAL HOST
192.1.1.30        KC-HLR1

```

IP Host table is (11 of 512) 2% full

3. Display the IP links assigned to the IP address shown in step 2 by entering the **rtrv-ip-lnk** command. The following is an example of the possible output.

```

rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A     192.1.1.30    255.255.255.128  HALF    10     802.3    NO    NO
1201  B     -----      -----      HALF    10     DIX      NO    NO
1203  A     192.1.1.12    255.255.255.0   ----    ---     DIX      YES   NO
1203  B     -----      -----      HALF    10     DIX      NO    NO
1205  A     192.1.1.14    255.255.255.0   FULL    100    DIX      NO    NO
1205  B     -----      -----      HALF    10     DIX      NO    NO
2101  A     192.1.1.20    255.255.255.0   FULL    100    DIX      NO    NO
2101  B     -----      -----      HALF    10     DIX      NO    NO
2103  A     192.1.1.22    255.255.255.0   FULL    100    DIX      NO    NO
2103  B     -----      -----      HALF    10     DIX      NO    NO
2105  A     192.1.1.24    255.255.255.0   FULL    100    DIX      NO    NO
2105  B     -----      -----      HALF    10     DIX      NO    NO
2207  A     192.1.1.32    255.255.255.0   FULL    100    DIX      NO    NO
2207  B     -----      -----      HALF    10     DIX      NO    NO
2213  A     192.1.1.50    255.255.255.0   FULL    100    DIX      NO    NO
2213  B     -----      -----      HALF    10     DIX      NO    NO
2301  A     192.1.1.52    255.255.255.0   FULL    100    DIX      NO    NO
2301  B     -----      -----      HALF    10     DIX      NO    NO

```

4. Using the outputs of steps 1 through 3 as a guide, enter the **pass:cmd="ping"** command specifying the card and the host name of the remote host. This command is entered several times to obtain the average round trip time. For this example, enter this command.

```
pass:loc=1201:cmd="ping kc-hlr1"
```

The following is an example of the possible output

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

```

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING command in progress

```

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING kc-hlr1 (192.1.1.30): 56 data bytes
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=0. time=5. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=1. time=9. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=2. time=14. ms
----tekral PING Statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 5/9/14

```

PING command complete

5. Perform the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure and change the retransmission parameters (**rtt** and **rexmit**) of the socket based on the results of pinging the remote host in step 4.
6. A TALI monitor (MONI) message is sent to the remote host.
7. Enter the **pass:cmd="sockrtt"** command to display the round trip time data collected during the sending of the TALI monitor acknowledgement (MONA) message. For this example, enter this command.

pass:loc=1201:cmd="sockrtt kc-hlr1"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

SOCKRTT: Socket round-trip time report (in milliseconds)

```
Configured Traffic Round-Trip Time
Retransmission Mode          : MOD
Fixed Round Trip Time        : 250
```

Measured Normal Traffic Round-Trip Times

```
Minimum round-trip time      : 5
Maximum round-trip time      : 195
Weighted Average round-trip time : 10
Last recorded round-trip time : 10
```

Measured Congested Traffic Round-Trip Times

```
Minimum round-trip time      : 0
Maximum round-trip time      : 0
Weighted Average round-trip time : 0
Last recorded round-trip time : 0
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SOCKRTT command complete
```

8. Enter the **pass:cmd="netstat -p tcp"** command to determine if any retransmissions have occurred. For this example, enter this command.

pass:loc=1201:cmd="netstat -p tcp"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
TCP:
```

```
  0 packet sent
    0 data packet (0 byte)
    0 data packet (0 byte) retransmitted
    0 ack-only packet (0 delayed)
    0 URG only packet
    0 window probe packet
    0 window update packet
    0 control packet
  0 packet received
    0 ack (for 0 byte)
    0 duplicate ack
    0 ack for unsent data
    0 packet (0 byte) received in-sequence
```

```

0 completely duplicate packet (0 byte)
0 packet with some dup. data (0 byte duped)
0 out-of-order packet (0 byte)
0 packet (0 byte) of data after window
0 window probe
0 window update packet
0 packet received after close
0 discarded for bad checksum
0 discarded for bad header offset field
0 discarded because packet too short
0 connection request
0 connection accept
0 connection established (including accepts)
0 connection closed (including 0 drop)
0 embryonic connection dropped
0 segment updated rtt (of 0 attempt)
0 retransmit timeout
    0 connection dropped by rexmit timeout
0 persist timeout
0 keepalive timeout
    0 keepalive probe sent
    0 connection dropped by keepalive
0 pcb cache lookup failed


rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
NETSTAT command complete

```

NOTE: If the results of the `pass:cmd="netstat -p tcp"` command show that the retransmission parameters do not need to be adjusted, do not perform this step. This procedure is finished.

9. Go to the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure and adjust the retransmission parameter (**rtt** and **rexmit**) values of the socket based on the results of the `pass:cmd="netstat -p tcp"` command entered in step 8.

Flowchart 3-14. Configuring IP Socket Retransmission Parameters



Configuring a DCM Parameter Set

This procedure is used to configure a Database Communication Module Parameter Set in the database using the **chg-dcmps** command. Parameter sets are sets of generic timers and parameters that can be used by any IP application.

NOTE: For IP, timers one through four correspond to timers T1, T2, T3, T4 in the TALI state machine.

The **chg-dcmps** command uses these parameters.

:set— The set number, 1 to 9.

:timer — The timer number within the set, 1 to 10. Only timers 1 to 4 are used. Timers 5 through 10 are not used.

:tvalue — The value the timer will be set to.

:parm— The parameter number within the timer, 1 to 10. Only parameter numbers 1 through 3 are used. Parameter numbers 4 through 10 are not used.

:pvalue — The numerical value that **pvalue** will be set to if specified.

:srcset — The source set of the copy, 1 - 10.

The values of the **timer**, **tvalue**, **parm**, and **pvalue** parameters is shown in the **rtrv-dcmps** output. The output shows the values for the **tvalue** and **pvalue** in bits. The values for these parameters are entered as a decimal number. [Table 3-6](#) shows the decimal equivalent for the bit values shown in the **rtrv-dcmps** output.

Table 3-6. DCMPS Values

Bit Value	Decimal Number Range
32	0 - 4294967295
8	0 - 255

While the value of the **pvalue** parameter when used with the **parm=3** parameter is 32 bits, or from 0 to 4294967295, only the first 6 bits (bits 0 - 5) are used. Bits 6-31 are reserved. This makes the decimal value of the **pvalue** parameter when used with the **parm=3** parameter from 0 to 63.

The value of the **pvalue** parameter when used with the **parm=2** parameter (enabling or disabling Nagle's Algorithm, TCP socket option) is either 0 (disabling Nagle's Algorithm) or 1 (enabling Nagle's Algorithm).

At least one of these parameters, **timer**, **parm**, or **srcset**, must be entered.

If the **srcset** parameter is specified, no other optional parameters can be entered.

If the **timer** parameter is specified, the **tvalue** parameter must be specified.

If the **parm** parameter is specified, the **pvalue** parameter must be specified.

NOTE: Set number 10 is a default parameter set and cannot be changed. In order to change the DCM parameters set for a socket using set number 10, use the **chg-appl-sock command to change the DCM parameter set to a different set number, and then use the **chg-dcmps** command to modify the new set.**

Canceling the RTRV-DCMPS Command

Because the **rtrv-dcmps** command used in this procedure can output information for a long period of time, the **rtrv-dcmps** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-dcmps** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-dcmps** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-dcmps** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-dcmps** command was entered, from another terminal other than the terminal where the **rtrv-dcmps** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the DCM parameter set being changed in this procedure by entering the **rtrv-dcmps** command with the **set** parameter.

For example, enter this command.

rtrv-dcmps:set=1

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SET  TIMER      TVALUE  PARM      PVALUE
1      1          4000     1          255
1      2          3000     2           1
1      3          3000     3           1
1      4         10000     4           0
1      5           0       5           0
1      6           0       6           0
1      7           0       7           0
1      8           0       8           0
1      9           0       9           0
1     10           0      10           0
```

TIMER 1: TALI T1 Timer, time (mS) between sending of TEST msgs by NE
TVALUE : Valid range = 32-bits

TIMER 2: TALI T2 Timer, time (mS) to wait for response to TEST msg
TVALUE : Valid range = 32-bits

TIMER 3: TALI T3 Timer, time (mS) to continue processing rcv'd service
msgs after NE is prohibited
TVALUE : Valid range = 32-bits

TIMER 4: TALI T4 Timer, time (mS) between sending of MONI msgs by NE
TVALUE: Valid range = 32-bits

PARM 1: Type of Service (TOS), IP header socket option
PVALUE: Valid range = lowest 8-bits

PARM 2: Nagle's Algorithm, TCP socket option
PVALUE: Valid range = lowest bit: 0 = Disable Nagle, 1 = Enable Nagle

PARM 3: Default SORP Flags socket option. Each bit is used as an
enabled/disabled flag for a particular socket option.
PVALUE: Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast Phase MTPP Primitives;	0=Disabled , 1=Enabled

1=Response Method MTPP Primitives;	0=Disabled , 1=Enabled
2=SCCP with MTP;	0=Disabled , 1=Enabled
3=ISUP via MTP;	0=Disabled , 1=Enabled
4=Group Code in MTPP;	0=Disabled , 1=Enabled
5=Use XSRV;	0=Disabled , 1=Enabled
6-31=Reserved	

NOTE: If a parameter set is not being copied to the parameter set being changed, skip step 2 and go to step 3.

2. Display the DCM parameter set that will be copied to the parameter set being changed in this procedure by entering the **rtrv-dcmps** command with the **set** parameter.

For example, enter this command.

rtrv-dcmps:set=5

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SET  TIMER      TVALUE  PARM      PVALUE
1      1          4000     1          255
1      2          1500     2           1
1      3          5000     3           1
1      4         20000     4           0
1      5           0       5           0
1      6           0       6           0
1      7           0       7           0
1      8           0       8           0
1      9           0       9           0
1     10           0      10           0
```

TIMER 1: TALI T1 Timer, time (mS) between sending of TEST msgs by NE
TVALUE : Valid range = 32-bits

TIMER 2: TALI T2 Timer, time (mS) to wait for response to TEST msg
TVALUE : Valid range = 32-bits

TIMER 3: TALI T3 Timer, time (mS) to continue processing rcv'd service
msgs after NE is prohibited
TVALUE : Valid range = 32-bits

TIMER 4: TALI T4 Timer, time (mS) between sending of MONI msgs by NE
TVALUE: Valid range = 32-bits

PARM 1: Type of Service (TOS), IP header socket option
PVALUE: Valid range = lowest 8-bits

PARM 2: Nagle's Algorithm, TCP socket option
PVALUE: Valid range = lowest bit: 0 = Disable Nagle, 1 = Enable Nagle

PARM 3: Default SORP Flags socket option. Each bit is used as an
enabled/disabled flag for a particular socket option.
PVALUE: Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast Phase MTPP Primitives;	0=Disabled , 1=Enabled
1=Response Method MTPP Primitives;	0=Disabled , 1=Enabled
2=SCCP with MTP;	0=Disabled , 1=Enabled
3=ISUP via MTP;	0=Disabled , 1=Enabled
4=Group Code in MTPP;	0=Disabled , 1=Enabled
5=Use XSRV;	0=Disabled , 1=Enabled
6-31=Reserved	

3. Change the DCM parameter set information in the database by using the **chg-dcmps** command.

For example, enter this command.

chg-dcmps:set=1:timer=1:tvalue=500

If a parameter set is being copied to the parameter set changed in this procedure, only the **set** and **srcset** parameters can be specified with the **chg-dcmps** command. The **set** parameter value must be the value specified in step 1. The **scrset** parameter value must be the value specified in step 2.

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-DCMPS: MASP A - COMPLTD
```

4. Verify the new application socket information in the database by entering the **rtrv-dcmps** command. For example, enter this command.

rtrv-dcmps:set=1

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SET  TIMER          TVALUE  PARM          PVALUE
1
1      1      1 500
1      1      255
1      2      3000      2      1
1      3      3000      3      1
1      4      10000     4      0
1      5      0         5      0
1      6      0         6      0
1      7      0         7      0
1      8      0         8      0
1      9      0         9      0
1     10      0        10      0
```

TIMER 1: TALI T1 Timer, time (mS) between sending of TEST msgs by NE
TVALUE : Valid range = 32-bits

TIMER 2: TALI T2 Timer, time (mS) to wait for response to TEST msg
TVALUE : Valid range = 32-bits

TIMER 3: TALI T3 Timer, time (mS) to continue processing rcv'd service
msgs after NE is prohibited
TVALUE : Valid range = 32-bits

TIMER 4: TALI T4 Timer, time (mS) between sending of MONI msgs by NE
TVALUE : Valid range = 32-bits

PARM 1: Type of Service (TOS), IP header socket option
PVALUE : Valid range = lowest 8-bits

PARM 2: Nagle's Algorithm, TCP socket option
PVALUE : Valid range = lowest bit: 0 = Disable Nagle, 1 = Enable Nagle

PARM 3: Default SORP Flags socket option. Each bit is used as an
enabled/disabled flag for a particular socket option.
PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast Phase MTPP Primitives;	0=Disabled , 1=Enabled
1=Response Method MTPP Primitives;	0=Disabled , 1=Enabled
2=SCCP with MTP;	0=Disabled , 1=Enabled
3=ISUP via MTP;	0=Disabled , 1=Enabled
4=Group Code in MTPP;	0=Disabled , 1=Enabled
5=Use XSRV;	0=Disabled , 1=Enabled
6-31=Reserved	


5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
```

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 3-15. Configuring a DCM Parameter Set



Notes:

1. If either the *timer* or *tvalue* parameters are specified, then both the *timer* and *tvalue* parameters must be specified.
2. If either the *parm* or *pvalue* parameters are specified, then both the *parm* and *pvalue* parameters must be specified.
3. If the *parm* parameter value is 1, the *pvalue* parameter is 0 – 255.
 If the *parm* parameter value is 2, the *pvalue* parameter value is either 0 or 1.
 If the *parm* parameter value is 3, the *pvalue* parameter value is 0 – 63. Each bit of the *pvalue* parameter value enables or disables certain functions. See the *rtrv-dcmps* command output for a list of the functions affected by the *parm*=3 parameter.

TALI IPGWx Configuration Procedures

Adding TALI IPGWx Components	4-1
Adding an IPGWx Card	4-3
Configuring an IPGWx Linkset	4-10
Configuring a Mate IPGWx Linkset	4-34
Adding an IPGWx Signaling Link	4-52
Enabling the Large System # Links Controlled Feature	4-66
Configuring an IP Link	4-75
Adding an IP Host	4-91
Configuring an IP Card	4-95
Adding an IP Route	4-103
Adding a Socket to an IPGWx Signaling Link	4-109
Adding a Routing Key Containing a Socket	4-120
Increasing the System-Wide IPGWx Signaling TPS	4-134
Removing TALI IPGWx Components	4-141
Removing an IPGWx Card	4-141
Removing an IPGWx Signaling Link	4-143
Removing an IP Host Assigned to an IPGWx Card	4-150
Removing an IP Route	4-155
Removing a Socket that is Assigned to an IPGWx Signaling Link	4-159
Removing a Routing Key Containing a Socket	4-162
Changing TALI IPGWx Components	4-167
Changing the Attributes of a Socket on an IPGWx Signaling Link	4-168
Configuring IP Socket Retransmission Parameters	4-181
Configuring a DCM Parameter Set	4-187
Changing the CIC Values in an Existing Routing Key Containing a Socket	4-192
Changing the PSTN Presentation and Normalization Attributes in a Routing Key	4-199
Configuring the IP TPS Alarm Threshold	4-211

Adding TALI IPGWx Components

This section describes how to configure the components necessary to establish IP connections using TALI sockets on IPGWx signaling links. IPGWx signaling links are signaling links assigned to cards running either the

SS7IPGW or IPGWI applications. The SS7IPGW application supports point-to-multipoint connectivity for ANSI networks. The IPGWI application supports point-to-multipoint connectivity for ITU networks.

The configuration of these IP connections consists of these items.

1. Configure the IPGWx card with the [Adding an IPGWx Card](#) procedure. Turn the ISUP-over-IP (**ipisup**) feature or the Dynamic Routing Key (**dynrtk**) feature with the **chg-feat** command.
NOTE: Before turning on the ISUP-over-IP feature (ipisup) or the Dynamic Routing Key feature, make sure you have purchased these features. If you are not sure whether you have purchased the ISUP-over-IP feature or the Dynamic Routing Key feature, contact your Tekelec Sales Representative or Account Representative. Once a feature has been turned on with the chg-feat command, the feature cannot be turned off.
2. Configure the required destination point codes - see Chapter 2, "Configuring Destination Tables," in the *Database Administration Manual - SS7*.
3. Configure the required IPGWx linksets with the [Configuring an IPGWx Linkset](#) procedure. A quantity of IP TPS (transactions per second) is assigned to each IPGWx linkset. The total amount of IP TPS for all IPGWx linksets cannot exceed the system-wide IP TPS value shown in the **rept-stat-iptps** output. Perform the [Increasing the System-Wide IPGWx Signaling TPS](#) procedure to change the total amount of IP TPS for all IPGWx linksets. If you wish to configure a mate IPGWx Linkset, perform the [Configuring a Mate IPGWx Linkset](#) procedure.
4. Configure the IPGWx signaling links with the [Adding an IPGWx Signaling Link](#) procedure. If the addition of these signaling links will exceed the current number of signaling links the EAGLE 5 ISS is allowed to have, the [Enabling the Large System # Links Controlled Feature](#) procedure will have to be performed to increase the quantity of signaling links.
5. Configure the required routes - see Chapter 3, "SS7 Configuration," in the *Database Administration Manual - SS7*.
6. IP addresses must be assigned to the IPGWx card configured in step 1 by performing the [Configuring an IP Link](#) procedure. There are other IP link parameters that are assigned to the IPGWx card when the IPGWx card is configured. Default values are assigned to these parameters when the IPGWx card is configured. These values can be displayed by the **rtrv-ip-lnk** command. These values can be changed by performing the [Configuring an IP Link](#) procedure.
7. Local IP hosts, assigned to the IP addresses assigned to step 6, must be configured in the database by performing the [Adding an IP Host](#) procedure. Verify the hosts with the **rtrv-ip-host** command. This establishes a relationship between the IP card related information and the socket related information.
8. When the IP cards are added to the database in step 1, there are IP parameters that control the IP stack that are assigned default values. These parameter values can be displayed by the **rtrv-ip-card** command. These values can be changed by performing the [Configuring an IP Card](#) procedure.
9. Static IP routes provide more flexibility in selecting the path to the remote destination and reduces the dependence on default routers. Static IP routes are provisioned by performing the [Adding an IP Route](#) procedure.
10. Sockets specify a connection between a local host/TCP port and a remote host/TCP port. The socket is configured by performing the [Adding a Socket to an IPGWx Signaling Link](#) procedure. A number of fields in the socket cannot be configured with the [Adding a Socket to an IPGWx Signaling Link](#) procedure and are set to default values. The values of these fields can be displayed using the **rtrv-appl-sock** command after the [Adding a Socket to an IPGWx Signaling Link](#) procedure is performed. These values can be changed by performing the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure. A maximum of 50 sockets can be assigned to an IPGWx card.

11. When a socket is configured with the “Adding a Socket to an IPGWx Signaling Link” procedure, DCM parameter set 10 is assigned to the socket. The DCM parameter set assignment can be changed by performing the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure. The values assigned to DCM parameter sets can be verified with the **rtrv-dcmps** command. The values assigned to DCM parameter sets can be changed by performing the [Configuring a DCM Parameter Set](#) procedure.
NOTE: Set number 10 is a default parameter set and cannot be changed. To change the DCM parameters set for a socket using set number 10, use the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure to change the DCM parameter set to a different set number, and then use the [Configuring a DCM Parameter Set](#) procedure to modify the new set.
12. Routing keys specify MSU filters for the socket. Configure the routing keys with the [Adding a Routing Key Containing a Socket](#) procedure.
13. If the PSTN presentation data and ISUP normalization data will be changed for the routing key, perform the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure. The **ent-pstn-pres** command can be used to define PSTN presentation data, in addition to the values shown in the **rtrv-pstn-pres** output, within either the Tekelec-defined range of PSTN categories, or the user-defined PSTN categories. The ISUP message and parameter database for an ISUP variant, defined by the PSTN presentation data, can be displayed using the **rtrv-isupvar-attrib** command, and changed with the **chg-isupvar-attrib** command. To configure this data, perform the procedures in [Chapter 7 ISUP Variant Table Provisioning](#).

Adding an IPGWx Card

This procedure is used to add an IPGWx card to the database using the **ent-card** command. An IPGWx card is a card that is running either the SS7IPGW or IPGWI applications. [Table 4-1](#) shows the cards that can be provisioned in this procedure.

Table 4-1. IPGWx Card Types

Card Type	Part Number
Dual-Slot DCM	870-1945-xx or 870-1984-01 †
Single-Slot EDCM	870-2372-01, 870-2372-08, 870-2372-13
† The dual-slot DCM is not supported if the Origin-Based MTP Routing feature is enabled.	

The EAGLE 5 ISS may contain a maximum of 64 cards running either the **ss7ipgw** or **ipgwi** application, or combinations of the **ss7ipgw** and **ipgwi** applications.

The **ent-card** command uses these parameters.

: loc – The location of the card being added to the database.

: type – The type of card being added to the database. For this procedure, the value of this parameter is **dcm**.

: appl – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is **ss7ipgw** for ANSI IP network connections or **ipgwi** for ITU IP network connections.

: force – If the global title translation feature is on, the **force=yes** parameter allows the LIM to be added to the database even if the current SCCP transactions-per-second threshold is unable to support the additional SCCP transaction-per-second capacity created by adding the IP card. This parameter is obsolete and is no longer used.

If you have purchased the ISUP-over-IP (**ipisup**) feature or the Dynamic Routing Key (**dynrtk**) feature, verify that the appropriate feature is turned on (**ipisup=on** or **dynrtk=on**) using the **rtrv-feat** command. If the

appropriate feature is off, turn it on with the **chg-feat** command. For more information on these features, refer to section [Understanding Routing for SS7IPGW and IPGWI Applications](#).

NOTE: Before turning on the ISUP-over-IP feature (**ipisup**) or the Dynamic Routing Key feature, make sure you have purchased these features. If you are not sure whether you have purchased the ISUP-over-IP feature or the Dynamic Routing Key feature, contact your Tekelec Sales Representative or Account Representative. Once a feature has been turned on with the **chg-feat** command, the feature cannot be turned off.

Card Slot Selection

The dual-slot DCM occupies two card slots and can be inserted any card slot in the extension shelf except slots 08 and 18. The dual-slot DCM card requires that the next adjacent slot be empty and not provisioned in the database. For example, if dual-slot DCM cards are inserted into slots 03 and 06, slots 04 and 07 must be empty and not provisioned in the database. Because slots 09 and 10 contain the HMUX cards or HIPR cards, the dual-slot DCM card cannot be inserted into slots 08, 09, or 10. Slot 18 cannot be used because it is the last slot in the shelf. The dual-slot DCM card can be inserted in the control shelf, but only in slots 01 through 07, and 11, following the same rules as the extension shelf. Slots 1113 through 1118 are reserved for MASPs A and B and the MDAL card.

The single-slot EDCM card can be inserted into any card slot, except for card slots that must remain empty to accommodate dual-slot cards, slots 09 and 10 in each shelf, and slots 1113 through 1118.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output. Cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM          SCCP
1102   TSM          GLS
1113   GSPM          EOAM
1114   TDM-A
1115   GSPM          EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0       SS7ANSI   sp2             A      0      sp1           B      0
1203   LIMDS0       SS7ANSI   sp3             A      0
1204   LIMDS0       SS7ANSI   sp3             A      1
1206   LIMDS0       SS7ANSI   nsp3            A      1      nsp4          B      1
1207   LIMV35       SS7GX25   nsp1            A      0
1208   LIMV35       SS7GX25   nsp1            A      1
1216   ACMENET       STPLAN
1301   LIMDS0       SS7ANSI   sp6             A      1      sp7           B      0
1302   LIMDS0       SS7ANSI   sp7             A      1      sp5           B      1
1303   DCM           IPLIM     ipnode1         A      0      ipnode3       B      1
1305   DCM           IPLIM     ipnode4         A      0
1307   ACMENET       STPLAN
```

If the required unprovisioned card slots (see the "Card Slot Selection" section) are shown in the **rtrv-card** output, skip steps 2 and 3, and go to step 4.

If the required unprovisioned card slots are not shown in the **rtrv-card** output, step 2 must be performed.

2. Display the shelves in the database by entering the **rtrv-shlf** command. This is an example of the possible output.

```
rlghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
SHELF DISPLAY
FRAME SHELF      TYPE
1      1          CONTROL
1      2          EXTENSION
1      3          EXTENSION
```

If all the shelves are provisioned in the database, then this procedure cannot be performed. There are no available card slots for the new IPGWx card.

If all the shelves have not been provisioned in the database, go to step 3.

3. Add the required shelf using the **ent-shlf** command with the location of the shelf and the **type=ext** parameter. The shelf location values are 1200, 1300, 2100, 2200, 2300, 3100, 3200, 3300, 4100, 4200, 4300, 5100, 5200, 5300, and 6100. For this example, enter this command.

ent-shlf:loc=2100:type=ext

When this command has successfully completed, this message should appear.

```
rlghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
ENT-SHLF: MASP A - COMPLTD
```

4. Verify that the card to be entered has been physically installed into the proper location (see the "Card Slot Selection" section).



CAUTION: If the version of the BPDCM GPL on the IP card does not match the BPDCM GPL version in the database when the IP card is inserted into the card slot, UAM 0002 is generated indicating that these GPL versions do not match. If UAM 0002 has been generated, perform the alarm clearing procedure for UAM 0002 in the *Maintenance Manual* before proceeding with this procedure.

5. If the ISUP-over-IP (**ipisup**) feature or the Dynamic Routing Key (**dynrtk**) feature are to be used, verify that these features are on by entering the **rtrv-feat** command.

If the ISUP-over-IP feature is on, the **ipisup** field is set to **on**. If the Dynamic Routing Key feature is on, the **dynrtk** field is set to **on**.

NOTE 1: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

NOTE: If the features you wish to use are already on, skip step 6 and go to step 7.

6. Turn the ISUP-over-IP or Dynamic Routing Key features by entering one of these commands, depending of which features are already on, and which ones you wish to turn on.

To enable the ISUP-over-IP feature, enter this command.

chg-feat:ipisup=on

To enable the Dynamic Routing Key feature, enter this command.

chg-feat:dynrtk=on

To enable both features, enter this command.

chg-feat:ipisup=on:dynrtk=on

NOTE 1: Once the ISUP-over-IP feature or Dynamic Routing Key features are turned on with the **chg-feat** command, they cannot be turned off.

NOTE: The ISUP-over-IP feature and Dynamic Routing Key features must be purchased before turning them on. If you are not sure whether you have purchased the ISUP-over-IP feature or Dynamic Routing Key features, contact your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

7. Add the card using the **ent-card** command.

For this example, enter these commands.

```
ent-card: loc=1315: type=dcn: appl=ss7ipgw
```

```
ent-card: loc=1317: type=dcn: appl=ipgwi
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD
```

8. Verify the changes using the **rtrv-card** command with the card location specified in step 7.

For this example, enter these commands.

```
rtrv-card: loc=1315
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1315   DCM        SS7IPGW
```

```
rtrv-card: loc=1317
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1317   DCM        IPGWI
```

9. Back up the new changes using the **chg-db: action=backup: dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


10. If you wish to change the quantity of static and dynamic routing keys in the database, perform the [Changing IP Options other than SYNC and SCTPCSUM](#) procedure.


Otherwise, this procedure is finished.


Flowchart 4-1. Adding an IPGWx Card

NOTE: Before executing this procedure, make sure you have purchased the ISUP-over-IP feature and Dynamic Routing Key features. If you are not sure whether you have purchased the ISUP-over-IP feature or Dynamic Routing Key features, contact your Tekelec Sales Representative or Account Representative.









Configuring an IPGWx Linkset

This procedure is used to configure IPGWx linksets in the EAGLE 5 ISS using the **ent - ls** or **chg - ls** commands with these parameters. An IPGWx linkset is a linkset that contains signaling links running either the SS7IPGW or IPGWI applications.

NOTE: This procedure is not used to configure a mate IPGWx linkset, with the **mate lsn** and **action** parameters. To configure a mate IPGWx linkset, perform the [Configuring a Mate IPGWx Linkset](#) procedure.

: lsn – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter. However, the SEAS interface supports only eight characters. If this linkset is displayed on the SEAS interface and the linkset name contains more than eight characters, only the first eight characters in the linkset name are shown. If this linkset name contains more than eight characters, and is specified with the linkset commands on the SEAS interface, only the first eight characters can be specified.

: apc/apca/apci/apcn/apcn24 – Adjacent point code – the point code identifying the node that is next to the EAGLE 5 ISS. The adjacent point code can be one of the following types of point codes:

:apc/apca – ANSI point code, ANSI private point code

:apci – ITU-I point code, ITU-I spare point code, ITU-I private point code, ITU-I private spare point code.

:apcn – 14-bit ITU-N point code, 14-bit ITU-N spare point code, 14-bit ITU-N private point code, 14-bit ITU-N private spare point code.

:apcn24 – 24-bit ITU-N point code, 24-bit ITU-N private point code.

NOTE 2: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

NOTE: The **apc/apca/apci/apcn/apcn24** parameter must be specified with the **ent - ls** command. Specifying this parameter with the **chg - ls** command is required only if the adjacent point code of the linkset is being changed.

: lst – The linkset type of the specified linkset - The **lst** parameter must be specified with the **ent - ls** command. Specifying this parameter with the **chg - ls** command is required only if the linkset type of the linkset is being changed.

: ipgwapc – IP Gateway Adjacent Point Code indicator. Specify the **ipgwapc=yes** parameter to provide SS7 linkset definition compatibility for gateway connections to IP-SCPs. This parameter can be specified only for, and must be specified for, linksets containing signaling links assigned to either the SS7IPGW or IPGWI applications. The default is **ipgwapc=no**.

NOTE: The **ipgwapc** parameter can be specified only with the **ent - ls** command.

To provision ISUP-CIC routing keys, the **ipgwapc=yes** parameter and the IP Gateway ISUP routing feature must be turned on. Verify this with the **rtrv - feat** command. If the IP Gateway ISUP routing feature is turned on, the **ipisup** field should be set to **on**. If the IP Gateway ISUP routing feature is not turned on, enter the **chg - feat:ipisup=on** command.

NOTE 5: Once the IP Gateway ISUP routing feature is turned on with the **chg - feat** command, it cannot be turned off.

NOTE: The IP Gateway ISUP routing feature must be purchased before you turn the feature on with the **chg - feat** command. If you are not sure if you have purchased the IP Gateway ISUP routing feature, contact your Tekelec Sales Representative or Account Representative.

: iptps – The quantity of IPTPS (transactions per second) that is assigned to the IPGWx linkset, from 100 to 112,000. The total amount of IPTPS for all IPGWx linksets cannot exceed the system-wide IPTPS value shown in the **rept - stat - iptps** output. For more information on the system-wide IPTPS value, see the [Increasing the System-Wide IPGWx Signaling TPS](#) procedure.

:lsusealm – The linkset’s IPTPS alarm threshold, from 10 to 100 percent of the linkset’s IPTPS. When this threshold is reached, a major alarm (UAM 0115) is generated. When the linkset’s IPTPS falls below this threshold, UAM 0115 is automatically cleared and UAM 0118 is generated.

:slkusealm – The signaling link IPTPS alarm threshold, from 10 to 100 percent of the signaling link’s fair share of the linkset’s IPTPS or from 10 to 100 percent of the IPGWx card’s capacity (2000 TPS). This threshold is reached when the signaling link’s actual usage exceeds the percentage of the signaling link’s fair share of the linkset’s IPTPS or the percentage of the IPGWx card’s capacity.

A signaling link’s fair share of linkset’s IPTPS is the linkset’s IPTPS divided by the number of in-service links in the linkset. For example, if the linkset IPTPS is 4000 and there are 4 signaling links in the linkset, all in-service, then the signaling link’s fair-share would be 1000 IPTPS ($4000/4=1000$). [Table 4-2](#) shows this calculation for a linkset with 1, 2, 3 and 4 in-service signaling links.

Table 4-2. Signaling Link Fair Share Example

Number of In-Service Signaling Links	Linkset IPTPS	Signaling Link Fair Share of the Linkset IPTPS
4	4000	1000
3	4000	1333
2	4000	2000
1	4000	4000

When this threshold is exceeded, a minor alarm (UAM 0116) is generated. When the amount of traffic on the signaling link falls below this threshold, UAM 0116 is automatically cleared and UAM 0119 is generated.

The signaling link IPTPS alarm shows that the linkset IPTPS is set too low for the linkset or that the IPGWx card’s capacity has been exceeded. Setting the signaling link IPTPS alarm threshold lower than the linkset IPTPS alarm threshold can give the user an earlier indication that the linkset IPTPS is inadequate or that traffic is not balanced across the links in the linkset.

:multgc – specifies whether multiple group codes (for 14-bit ITU-N point codes) are supported for the linkset. When this parameter value is **yes**, secondary adjacent point codes whose group codes are different from the adjacent point code of the linkset can be assigned to the linkset. If the parameter value is **no**, the group code of the secondary adjacent point code must be the same as the group code of the linkset’s adjacent point code. For more information on secondary adjacent point codes, go to the “Configuring an ITU Linkset with a Secondary Adjacent Point Code (SAPC)” procedure in the *Database Administration Manual - SS7*.

This parameter only applies to linksets whose adjacent point codes are either ITU international point codes or ITU national point codes. All the signaling links in this linkset must be assigned to cards running the IPGWI application. For more information on assigning signaling links to cards running the IPGWI application, go to the [Adding an IPGWx Signaling Link](#) procedure.

The ITU duplicate point code feature must be on before this parameter can be specified. Verify this with the **rtrv-feat** command. If the ITU duplicate point code feature is turned on, the **ituduppc** field should be set to **on**. If the ITU duplicate point code feature is not turned on, enter the **chg-feat:ituduppc=on** command.

NOTE: Once the ITU duplicate point code feature is turned on with the **chg-feat** command, it cannot be turned off.

The ITU duplicate point code feature must be purchased before you turn the feature on with the **chg-feat command. If you are not sure if you have purchased the ITU duplicate point code feature, contact your Tekelec Sales Representative or Account Representative.**

The adjacent point code (APC) for the linkset must be defined in the database, must be in the SS7 domain and cannot match the point code or capability point code of the EAGLE 5 ISS. The domain of the point code is shown in the **DOMAIN** field in the output of the **rtrv-dstn** command. The point code of the EAGLE 5 ISS is shown in the **PCA**, **PCN**, **PCN24**, or **PCI** fields and the capability point code of the EAGLE 5 ISS are shown in the **CPCA**, **CPCN**, **CPCN24**, or **CPCI** fields in the output of the **rtrv-sid** command. An ANSI adjacent point code must be a full point code and cannot be a cluster point code or a network routing point code. The adjacent point code of the linkset cannot be a proxy point code, cannot have a proxy point code assigned to it, and cannot be assigned to another linkset.

If the APC is not in the destination point code table, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the APC to the destination point code table.

For IPGWx linksets, more than one device may be attached to the LAN and have IP connections to the IP card running either the SS7IPGW or IPGWI application. Thus each IPGWx linkset is adjacent to all devices on the LAN (or adjacent to no device on the LAN, depending on your point of view). To provide a scheme allowing this point-to-multipoint connection and maintain consistent SS7 linkset definition rules, a virtual APC is required. This virtual APC is a real SS7 point code that is not used anywhere else in the SS7 network. Virtual APCs assigned to SS7IPGW linksets are ANSI point codes. Virtual APCs assigned to IPGWI linksets are either ITU-I or ITU-N point codes (either 14-bit or 24-bit ITU-N point codes). Virtual point codes can be reused on more than one switch. For example, a mated set of switches, each with two related links, could share two virtual point codes instead of requiring four. DPCs and linksets related to the virtual APC must be defined with the **ipgwapc** parameter set to **yes**.

For provisioning of ISUP-CIC routing keys, the **ipgwapc=yes** parameter and the IP Gateway ISUP routing feature must be turned on. Verify this with the **rtrv-feat** command. If the IP Gateway ISUP routing feature is turned on, the **ipisup** field should be set to **on**. If the IP Gateway ISUP routing feature is not turned on, enter the **chg-feat:ipisup=on** command.

NOTE: Once the IP Gateway ISUP routing feature is turned on with the **chg-feat** command, it cannot be turned off.

The IP Gateway ISUP routing feature must be purchased before you turn the feature on with the **chg-feat command. If you are not sure if you have purchased the IP Gateway ISUP routing feature, contact your Tekelec Sales Representative or Account Representative.**

Other Optional Parameters

Other optional parameters, shown in [Table 4-3](#), can be used with the **ent-ls** or **chg-ls** commands but do not need to be used in this procedure. These parameters are discussed in more detail in either the “Adding an SS7 Linkset” or Changing an SS7 Linkset” procedures in the *Database Administration Manual - SS7*. The **matelsn** parameter is discussed in more detail in the [Configuring a Mate IPGWx Linkset](#) procedure.

Table 4-3. Optional Linkset Parameters

ccli	sltset	l3tset	scrn	gwsa
gwsm	gwsd	bei	nis	itutfr
asl8	slsrsb	slsocbit	mtprse*	slsci
tfatcabmlq	gmscrn	sapci	sapcn	sapcn24
action	matelsn	apcntype	gttmode	randsls
spc/spca/spci/spcn/spcn24 *		ppc/ppca/ppci/ppcn/ppcn24 *		
* These parameters cannot be specified for an IPGWx linkset.				

Canceling the RTRV-LS and RTRV-DSTN Commands

Because the **rtrv-ls** and **rtrv-dstn** commands used in this procedure can output information for a long period of time, the **rtrv-ls** and **rtrv-dstn** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-ls** and **rtrv-dstn** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered, from another terminal other than the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the system-wide IPTPS usage report, and the IPGWx linksets, by entering the **rept-stat-iptps** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

IP TPS USAGE REPORT
      THRESH  CONFIG      TPS      PEAK      PEAKTIMESTAMP
-----
SYSTEM
RLGHNCXA03W 100%   30000 TX:    7200    7600 05-02-10 11:40:04
              RCV:    7200    7600 05-02-10 11:40:04
-----
LSN
LSGW1101      80%   10000 TX:    7200    7600 05-02-10 11:40:04
              RCV:    7200    7600 05-02-10 11:40:04
LSGW1103      80%   10000 TX:    6700    7600 05-02-10 11:40:04
              RCV:    6500    7600 05-02-10 11:40:04
LSGW1105      80%   10000 TX:    7300    7450 05-02-10 11:40:04
              RCV:    7300    7450 05-02-10 11:40:04
-----
Command Completed.
```

If the sum of the IPTPSs of all the IPGWx linksets is equal to the configured IPTPS amount shown in this report:

- No new IPGWx linksets can be added
- The linkset IPTPS of any IPGWx existing linkset cannot be increased.

If a new IPGWx linkset is being added in this procedure, and the IPTPS value for this linkset allows the sum of the IPTPS of all the IPGWx linksets to exceed the configured IPTPS amount shown in this report, the new IPGWx linkset cannot be added.

If an existing IPGWx IP TPS value is being changed in this procedure, and the IPTPS value for this linkset allows the sum of the IPTPS of all the IPGWx linksets to exceed the configured IPTPS amount shown in this report, the IPGWx linkset IPTPS value cannot be changed.

To add a new IPGWx linkset or change the IPTPS value of an existing IPGWx linkset when the resulting sum of IPTPS values for all IPGWx linksets will exceed the IPTPS amount shown in this report, the system-

wide IPTPS amount must be increased, or the linkset IPTPS of some or all the IPGWx linksets must be reduced to allow for the new IPTPS value for the linkset configured in this procedure.

To increase the system-wide IPTPS amount, perform the [Increasing the System-Wide IPGWx Signaling TPS](#) procedure. If the system-wide IPTPS amount is 112000, shown in the **CONFIG** column in the **SYSTEM** section of this report, the system-wide IPTPS amount cannot be increased. Skip step 2 and go to step 3.

If the linkset IPTPS values of the IPGWx linksets need to be reduced, perform step 2.

2. Reduce the IPTPS values of some or all the IPGWx linksets by entering the **chg-ls** command with the name of each linkset being changed from step 1, and the new IPTPS value. For this example, enter these commands.

```
chg-ls:lsn=lsgw1101:iptps=6000
```

```
chg-ls:lsn=lsgw1103:iptps=6000
```

When the **chg-ls** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 13 of 1024) 1% full
CHG-LS: MASP A - COMPLTD
```

3. Display the current linksets in the database using the **rtrv-ls** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

LSN	APCA	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS
e1e2	001-207-000		none	1	1	no	B	6		off	off	off	no				off
e1m1s1	001-001-001		none	1	1	no	A	7		off	off	off	no				off
e1m1s2	001-001-002		none	1	1	no	A	7		off	off	off	no				off
ls1305	001-005-000		none	1	1	no	A	1		off	off	off	no				off
ls1307	001-007-000		none	1	1	no	A	1		off	off	off	no				off
lsgw1101	008-012-003		none	1	1	no	A	1		off	off	off	no				off
lsgw1103	003-002-004		none	1	1	no	A	1		off	off	off	no				off
lsgw1105	009-002-003		none	1	1	no	A	1		off	off	off	no				off

LSN	APCA	(X25)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN	APCI	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS
e1e2i	1-207-0		none	1	1	no	B	4		off	off	off	---				on
ls1315	0-015-0		none	1	1	no	A	1		off	off	off	---				off
ls1317	0-017-0		none	1	1	no	A	1		off	off	off	---				on
e1m2s1	1-011-1		none	1	1	no	A	7		off	off	off	---				off
e1m2s2	1-011-2		none	1	1	no	A	7		off	off	off	---				off

LSN	APCN	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN	APCN24	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN (CHINA)	APCN	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN (CHINA)	APCN24	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

Link set table is (13 of 1024) 1% full.

4. To specify the **multgc=yes** parameter with the **ent - ls** or **chg - ls** commands, the ITU Duplicate Point Code feature must be on. For the ITU Duplicate Point Code feature to be on, the Multiple Point Code feature must be on. Enter the **rtrv-feat** command to verify that either of these features are on.

NOTE: If the **multgc** parameter is not being specified for the linkset, skip steps 4, 5, 6, and 7, and go to step 8. If the **multgc** parameter value is being changed to **no**, skip steps 4, and 5, and go to step 6. The **multgc** parameter can be specified only for linksets with either ITU-I or 14-bit ITU-N APCs, and linksets that contain signaling links running the IPGWI application.

The entry **MPC = on** in the **rtrv-feat** command output shows that the Multiple Point Code feature is on. The entry **ITUDUPPC = on** in the **rtrv-feat** command output shows that the ITU Duplicate Point Code feature is on. In this example, both features are off.

NOTE: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

5. Turn the ITU Duplicate Point Code feature on, and the Multiple Point Code feature if necessary, by entering one of these commands.

NOTE: If the ITU Duplicate Point Code feature is on (**ITUDUPPC = on**), skip this step and go to step 6.

To turn the ITU Duplicate Point Code feature on only.

chg-feat:ituduppc=on

To turn both the ITU Duplicate Point Code and Multiple Point Code features on.

chg-feat:mpc=on:ituduppc=on

NOTE: Once the ITU Duplicate Point Code and Multiple Point Code features are turned on with the **chg-feat** command, they cannot be turned off.

The ITU Duplicate Point Code and Multiple Point Code features must be purchased before you turn either of these features on with the **chg-feat** command. If you are not sure if you have purchased these features, contact your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
CHG-FEAT: MASP A - COMPLTD
```

6. If the **multgc** parameter value is changed to **no**, the linkset can contain only one secondary adjacent point code. An ITU international linkset can contain only one 14-bit ITU national secondary adjacent point code. If the ITU international linkset contains more than one 14-bit ITU national secondary adjacent point code, all but one of these 14-bit ITU national secondary adjacent point codes must be removed from the linkset. An ITU national linkset can contain only one ITU international secondary adjacent point code. All 14-bit ITU-N secondary adjacent point codes must be removed from the linkset. All routes to these secondary adjacent point codes must be removed from the database before the secondary adjacent point codes can be removed.

NOTE: If the **multgc** parameter value is not being changed, is being changed to **yes**, or if a new linkset is being added, skip steps 6 and 7, and go to step 8.

Display the routes using the secondary adjacent point code being removed from the linkset with the **rtrv-rte** command, specifying the secondary adjacent point code being removed as the value of the **dpc** parameter.

For this example, enter these commands.

rtrv-rte:dpcn=11213-de

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 37.5.0
DPCN          ALIASA          ALIASI  LSN          RC          APC
11213-de      -----          -----  lsn3          10          11213-de
RTX:No      CLLI=-----
```

rtrv-rte:dpcn=12114-fr

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 37.5.0
DPCN          ALIASA          ALIASI  LSN          RC          APC
12114-fr      -----          -----  lsn3          10          12114-fr
RTX:No      CLLI=-----
```

rtrv-rte:dpcn=12115-uk

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 37.5.0
DPCN          ALIASA          ALIASI  LSN          RC          APC
12115-uk      -----          -----  lsn3          10          12115-uk
RTX:No      CLLI=-----
```

If the secondary adjacent point code is assigned to a route, that route must be removed from the database. Perform the “Removing a Route” procedure in the *Database Administration Manual - SS7* to remove the route from the database.

- Remove the secondary adjacent point codes specified in step 6 from the linkset with the **chg-ls** command with the **sapcn** and the **action=delete** parameters. For this example, enter these commands.

chg-ls:lsn=lsn3:sapcn=11213-de:action=delete

chg-ls:lsn=lsn3:sapcn=12114-fr:action=delete

chg-ls:lsn=lsn3:sapcn=12115-uk:action=delete

When the **chg-ls** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 13 of 255) 5% full
CHG-LS: MASP A - COMPLTD
```

- Display the point code and capability point code of the EAGLE 5 ISS by using the **rtrv-sid** command.

NOTE 1: If an existing linkset is being changed, and the adjacent point code of that linkset is not being changed, skip steps 8 through 15, and go to step 16.

NOTE: If a new linkset is being added, or an existing linkset is being changed and the adjacent point code of that linkset is being changed, continue this procedure with step 8. The new adjacent point code of this linkset cannot be shown in the **rtrv-ls output in step 3.**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
PCA          PCI          PCN          CLLI          PCTYPE
001-001-001  1-200-6          13482          rlghncxa03w  OTHER
```

```

PCPA
002-002-002      002-002-003      002-002-004      002-002-005
002-002-006      002-002-007      002-002-008      002-002-009
004-002-001      004-003-003      144-212-003

PCPA (LNP)
005-005-002      005-005-004      005-005-005

CPCI
1-001-1          1-001-2          1-001-3          1-001-4

CPCN
02091            02092            02094            02097
02191            02192            11177

```

9. Display the destination point codes in the database by entering the **rtrv-dstn** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```

DPCA          CLLI          BEI  ELEI  ALIASI          ALIASN          DOMAIN
001-207-000   -----   no   ---   -----   -----   SS7
001-001-001   -----   no   ---   -----   -----   SS7
001-001-002   -----   no   ---   -----   -----   SS7
001-005-000   -----   no   ---   -----   -----   SS7
001-007-000   -----   no   ---   -----   -----   SS7
008-012-003   -----   no   ---   -----   -----   SS7
003-002-004   -----   no   ---   -----   -----   SS7
009-002-003   -----   no   ---   -----   -----   SS7
010-020-005   -----   no   ---   -----   -----   SS7

DPCI          CLLI          BEI  ELEI  ALIASI          ALIASN          DOMAIN
1-207-0       -----   no   ---   -----   -----   SS7
0-015-0       -----   no   ---   -----   -----   SS7
0-017-0       -----   no   ---   -----   -----   SS7
1-011-1       -----   no   ---   -----   -----   SS7
1-011-2       -----   no   ---   -----   -----   SS7

DPCN          CLLI          BEI  ELEI  ALIASA          ALIASI          DOMAIN
DPCN24        CLLI          BEI  ELEI  ALIASA          ALIASI          DOMAIN

```

```
Destination table is (14 of 2000) 1% full
```

```
Alias table is (0 of 12000) 0% full
```

If the new adjacent point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* to add the required point code. This point code cannot be a proxy point code (the **prx=yes** value assigned to the point code) and a proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code.

10. Display the adjacent point code of the new linkset in the destination point code table by using the **rtrv-dstn** command and specifying the point code. For this example, enter this command.

```
rtrv-dstn:dPCA=010-020-005
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```

DPCA          CLLI          BEI  ELEI  ALIASI          ALIASN          DOMAIN
010-020-005   -----   no   ---   -----   -----   SS7

          SPC          NCAI
          -----

```

```
Destination table is (14 of 2000) 1% full
```

```
Alias table is (0 of 12000) 0% full
```


This point code cannot be a proxy point code (the **prx=yes** value assigned to the point code) and a proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code. If a proxy point code is shown in this step, or if the point code is a proxy point code, choose another point code and repeat this procedure from step 8.

11. The APC of the linkset cannot be the DPC of any exception route. Verify that the adjacent point code of the linkset is not the DPC of any exception route by entering the **rtrv-rtx** command with the **dpc/dpca/dpci/dpcn/dpcn24** parameter. The **dpc/dpca/dpci/dpcn/dpcn24** parameter value is the adjacent point code value that will be specified for the linkset.

NOTE 1: If the adjacent point code was added in step 10, and a new linkset is being added, skip steps 11 and 12, and go to step 13.

NOTE: If the adjacent point code was added in step 10, and an existing linkset is being changed, skip .

For this example, enter this command.

rtrv-rtx:dpca=010-020-005

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
DPCA          RTX-CRITERIA          LSN          RC          APC

010-020-005   OPCA
               007-008-009          ls1305        20        001-005-000
               008-008-008          ls1307        40        001-007-000
```

```
DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s):                  13
EXCEPTION DPC(s):              5
NETWORK DPC(s):                 0
CLUSTER DPC(s):                 1
TOTAL DPC(s):                  19
CAPACITY (% FULL):              1%
ALIASES ALLOCATED:             12000
ALIASES USED:                   0
CAPACITY (% FULL):              0%
X-LIST ENTRIES ALLOCATED:       500
```

If the adjacent point code of the linkset is not the DPC of a route exception table entry, no entries are displayed in the **rtrv-rtx** output, but a summary of the point code quantities is displayed, as shown in the following output example.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s):                  15
EXCEPTION DPC(s):              5
NETWORK DPC(s):                 0
CLUSTER DPC(s):                 1
TOTAL DPC(s):                  21
CAPACITY (% FULL):              1%
ALIASES ALLOCATED:             12000
ALIASES USED:                   0
CAPACITY (% FULL):              0%
X-LIST ENTRIES ALLOCATED:       500
```

If the point code specified in this step is shown in the **DPCA/DPCI/DPCN/ DPCN24** columns in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- Choose another adjacent point code value and repeat steps 8, 9, 10, and 11.

- Remove all the entries displayed in this step by performing the “Removing a Route Exception Entry” procedure in the *Database Administration Manual - SS7*.
12. Display any entries in the route table whose DPC value is also the adjacent point code of the new linkset being added in this procedure, or the new adjacent point code of the existing linkset being changed in this procedure. Enter the **rtrv-rte** command with the **dpc/dpca/dpci/dpcn/dpcn24** parameter. The **dpc/dpca/dpci/dpcn/dpcn24** parameter value is the adjacent point code value that will be specified for the linkset. For this example, enter this command.

rtrv-rte:dpca=010-020-005

This is an example of the possible output.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA	ALIASI	ALIASN/N24	LSN	RC	APCA
010-020-005	-----	-----	lsn1	1	003-003-003
			lsn2	2	003-003-004
			RTX:No	CLLI=-----	

If the adjacent point code of the linkset is not the DPC of a route, the point code entry is displayed in the **rtrv-rte** output, but the LSN, RC, and APC columns contain dashes, as shown in the following output example.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA	ALIASI	ALIASN/N24	LSN	RC	APCA
002-002-002	-----	-----	-----	---	-----
			RTX:No	CLLI=-----	

If the point code specified in this step is shown in the **DPCA/DPCI/DPCN/ DPCN24** columns in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- Choose another adjacent point code value and repeat steps 8 through 12.
 - Remove all the entries displayed in this step by performing the “Removing a Route” procedure in the *Database Administration Manual - SS7*.
13. Verify that the IP Gateway ISUP routing feature is on by entering the **rtrv-feat** command. The entry **IPISUP = on** in the **rtrv-feat** command output shows that the IP Gateway ISUP routing feature is on.

NOTE 1: If you do not wish to use the IP Gateway ISUP routing feature, skip steps 13 and 14, and go to step 15.

NOTE: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

14. Turn the IP Gateway ISUP routing feature on by entering this command.

NOTE: If the IP Gateway ISUP routing feature is on (**IPISUP = on**), skip this step and go to step 15.

chg-feat:ipisup=on

NOTE: Once the IP Gateway ISUP routing feature is turned on with the **chg-feat** command, it cannot be turned off.

The IP Gateway ISUP routing feature must be purchased before you turn the feature on with the **chg-feat** command. If you are not sure if you have purchased the IP Gateway

ISUP routing feature, contact your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
CHG-FEAT: MASP A - COMPLTD
```

15. Add the new linkset to the database using the **ent - ls** command. The new linkset must meet these conditions.

- The name of this linkset cannot be used by another linkset – the linkset configuration is shown in the output of step 3.

The APC of the new linkset must be in the destination point code table, but cannot be either the EAGLE 5 ISS's point code or the EAGLE 5 ISS's capability point code – shown in the outputs of steps 8, 9, and 10. The adjacent point code can be one of the following types of point codes:

:apc/apca – ANSI point code, ANSI private point code

:apci – ITU-I point code, ITU-I spare point code, ITU-I private point code, ITU-I private spare point code.

:apcn – 14-bit ITU-N point code, 14-bit ITU-N spare point code, 14-bit ITU-N private point code, 14-bit ITU-N private spare point code.

:apcn24 – 24-bit ITU-N point code, 24-bit ITU-N private point code.

These parameters and values must also be specified for the IPGWx linkset:

- **ipgwapc=yes**
- **lst=<a, b, c, d, e>**
- **iptps=<100-112000>**

NOTE: The **iptps** parameter value must be divisible by 10. The sum of all the linkset IP TPS values, including the value for this linkset, cannot exceed the system-wide IP TPS value shown in the **rept - stat - iptps** output in step 1.

- The **mtprse=yes** parameter cannot be specified for an IPGWx linkset.
- The optional parameters **lsusealm** (the linkset's IP TPS alarm threshold) and **slkusealm** (the signaling link IP TPS alarm threshold) can be specified with the **ent - ls** command. The default value for the **lsusealm** parameter is 100%, and the default value for the **slkusealm** parameters is 80%.
- The **multgc=yes** parameter can be specified only for IPGWx linksets that will contain signaling links running the IPGWI application.

NOTE: There are other optional parameters that can be specified with the **ent - ls** command, but are not required for an IPGWx linkset. These parameters and their usage are discussed in the [Configuring a Mate IPGWx Linkset](#) procedure and in the "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

For this example, enter this command.

```
ent -
ls: lsn=lsgw1107:apca=010-020-005:lst=a:ipgwapc=yes :iptps=4000:lsusealm
=70:slkusealm=70
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 14 of 1024) 1% full
ENT-LS: MASP A - COMPLTD
```

16. Display the signaling link alarm threshold for the linkset being changed by entering the **rept-stat-iptps** command with the name of the linkset being changed. For this example, enter this command.

NOTE 1: If you do not wish to change an existing IPGWx linkset, skip steps 16 and 17, and go to step 18.

NOTE: If the `slkusealm` parameter for the linkset is not being changed, skip step 16 and go to step 17.

rept-stat-iptps:lsn=lsqw1105

This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
IP TPS USAGE REPORT
-----
THRESH  CONFIG      TPS      PEAK      PEAKTIMESTAMP
-----
LSN
LSGW1105      80%    10000  TX:    7300    7450  05-02-10 11:40:04
                  RCV:    7300    7450  05-02-10 11:40:04
-----
LOC  PORT
1105  A      80%    ----  TX:    7300    7450  05-02-10 11:40:04
                  RCV:    7300    7450  05-02-10 11:40:04
-----
Command Completed.
```

17. Change the existing linkset using the **chg-ls** command with the name of the linkset being changed, shown in the **rept-stat-iptps** output in step 1, and with at least one of these parameters:

- The new adjacent point code of the linkset, if the current adjacent point code of the linkset is being changed.
- **iptps=<100-112000>**
NOTE: The `iptps` parameter value must be divisible by 10. The sum of all the linkset IP TPS values, including the value for this linkset, cannot exceed the system-wide IP TPS value shown in the `rept-stat-iptps` output in step 1.
- The **mtprse=yes** parameter cannot be specified for an IPGWx linkset.
- The optional parameters **lsusealm** (the linkset's IP TPS alarm threshold) and **slkusealm** (the signaling link IP TPS alarm threshold) can be specified with the **chg-ls** command.
- The **multgc=yes** parameter can be specified only for IPGWx linksets that contain signaling links running the IPGWI application.

NOTE: There are other optional parameters that can be specified with the `chg-ls` command, but are not required for an IPGWx linkset. These parameters and their usage are discussed in the [Configuring a Mate IPGWx Linkset](#) procedure and in the "Changing an SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

For this example, enter this command.

chg-ls:lsn=lsqw1105:iptps=14000:lsusealm=70:slkusealm=70

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
```

Link set table is (14 of 1024) 1% full
CHG-LS: MASP A - COMPLTD

18. Verify the changes using the **rtrv-ls** command specifying the linkset name specified in either steps 15 or 17 with the **lsn** parameter. For this example, enter these commands.

rtrv-ls:lsn=lsgw1105

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 37.5.0

LSN	APCA	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
lsgw1105	009-002-003		none	1	1	no	A	1	off	off	off	no	off
CLLI				TFATCABMLQ		MTPRSE		ASL8					
----- 1						no		no					
IPGWAPC				MATELSN		IPTPS		LSUSEALM		SLKUSEALM		GTTMODE	
yes				-----		14000		70		% 70		% CdPA	
LOC	LINK	SLC	TYPE	L2T SET	BPS		L1 MODE	TSET	ECM	PCR N1	PCR N2		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	LL		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	E1ATM CRC4	SI	SN
LOC	LINK	SLC	TYPE	IPLIML2									
LOC	LINK	SLC	TYPE	1105 A 0 SS7IPGW									
LOC	LINK	SLC	TYPE	L2T SET	BPS		ECM	PCR N1	PCR N2	E1 LOC	E1 PORT	TS	
LOC	LINK	SLC	TYPE	L2T SET	BPS		ECM	PCR N1	PCR N2	T1 LOC	T1 PORT	TS	

Link set table is (14 of 1024) 1% full

rtrv-ls:lsn=lsgw1107

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 37.5.0

LSN	APCA	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
lsgw1107	010-020-005		none	1	1	no	A	0	off	off	off	no	off
CLLI				TFATCABMLQ		MTPRSE		ASL8					
----- 1						no		no					
IPGWAPC				MATELSN		IPTPS		LSUSEALM		SLKUSEALM		GTTMODE	
yes				-----		4000		70		% 70		% CdPA	
LOC	LINK	SLC	TYPE	L2T SET	BPS		L1 MODE	TSET	ECM	PCR N1	PCR N2		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	LL		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	E1ATM CRC4	SI	SN
LOC	LINK	SLC	TYPE	IPLIML2									

```

LOC LINK SLC TYPE

LOC LINK SLC TYPE      L2T      PCR PCR E1 E1
                        SET BPS    ECM  N1 N2 LOC PORT TS

LOC LINK SLC TYPE      L2T      PCR PCR T1 T1
                        SET BPS    ECM  N1 N2 LOC PORT TS

```

Link set table is (14 of 1024) 1% full


19. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


Flowchart 4-2. Configuring an IPGWx Linkset


























Configuring a Mate IPGWx Linkset

This procedure is used to configure a mate IPGWx linkset to an existing IPGWx linkset **chg-ls** command with these parameters.

:lsn – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter. However, the SEAS interface supports only eight characters. If this linkset is displayed on the SEAS interface and the linkset name contains more than eight characters, only the first eight characters in the linkset name are shown. If this linkset name contains more than eight characters, and is specified with the linkset commands on the SEAS interface, only the first eight characters can be specified.

:matelsn – The name of the mate IPGWx linkset.

:action – to add (**action=add**) or remove (**action=delete**) the mate IPGWx linkset to the IPGWx linkset specified by the **lsn** parameter.

NOTE: This procedure is not used to configure an IPGWx linkset, with the **ipgwapc**, **iptps**, **lsusealm** and **slkusealm** parameters. To configure an IPGWx linkset with these parameters, perform the [Configuring an IPGWx Linkset](#) procedure.

An IPGWx linkset is a linkset that contains signaling links assigned to IPGWx cards. IPGWx cards are cards running either the SS7IPGW or IPGWI applications.

The EAGLE 5 ISS allows an IPGWx linkset to contain up to 8 IPGWx signaling links, and as a result, 8 IPGWx cards. This increases the amount of traffic that can be delivered to a single IP node compared to the two-card combined IPGWx linkset deployments used in previous releases. An IPGWx linkset containing up to 8 IPGWx signaling links is the preferred method of configuring IPGWx linksets (see the [Configuring an IPGWx Linkset](#) procedure). This method is required if more than two IPGWx signaling links are to be used in the linkset.

To provide backward compatibility with pre-existing two-card combined IPGWx linkset deployments, the EAGLE 5 ISS also provides for a mate IPGWx linkset. A mate IPGWx linkset consists of one IPGWx linkset assigned to another IPGWx linkset using the **mate lsn** parameter of the **chg-ls** command. To assign a mate IPGWx linkset to another IPGWx linkset, both linksets can contain no more than one signaling link. While mate IPGWx linksets can be configured using this procedure, the preferred method of configuring two-card IPGWx deployments is to configure a two-link non-mated linkset using the [Configuring an IPGWx Linkset](#) procedure.

Each linkset in the mated pair must either contain no mate linksets, or can reference the other linkset in the mated pair. For example, to assign linkset **LSN2** to IPGWx linkset **LSN1** as a mate linkset, linkset **LSN1** cannot contain any mate linksets. Linkset **LSN2** can have linkset **LSN1** as a mate, otherwise linkset **LSN2** cannot have any mate linksets assigned to it.

The mate linkset name is displayed in the **rtrv-ls:lsn=<linkset name>** command output. If either linkset contains more than one signaling link, all but one of the signaling links must be removed from these linksets or other linksets must be chosen. Perform the [Removing an IPGWx Signaling Link](#) procedure to remove any signaling links from the linkset. If new linksets must be configured for this procedure, perform the [Configuring an IPGWx Linkset](#) procedure.

Before a mate IPGWx linkset can be added to an IPGWx linkset, the card containing the IPGWx signaling link assigned to the linkset being changed, and the signaling link assigned to that card must be placed out of service.

Before a mate IPGWx linkset can be removed from an IPGWx linkset, the card containing the IPGWx signaling link assigned to the mate linkset, and the signaling link assigned to that card must be placed out of service.

The network type of the adjacent point code of the mate IPGWx linkset must be the same type as the linkset the mate is assigned to. For example, if a mate IPGWx linkset is assigned to an IPGWx linkset with an ITU-I adjacent point code, the mate IPGWx linkset must have an ITU-I adjacent point code.

Other Optional Parameters

Other optional parameters, shown in [Table 4-4](#), can be used with the **chg-ls** command but do not need to be used in this procedure. These parameters are discussed in more detail in the “Changing an SS7 Linkset” procedures in the *Database Administration Manual - SS7*. The **iptps**, **lsusealm**, and **slkusealm** parameters are discussed in more detail in the [Configuring an IPGWx Linkset](#) procedure.

Table 4-4. Optional Linkset Parameters

clli	sltset	l3tset	scrn	gwsa	gwsn
gwsd	bei	nis	itutfr	mtprse*	slsci
asl8	slsrbs	slsocbit	multgc	tfatcabmlq	gsmscrn
sapci	sapcn	sapcn24	iptps	lsusealm	slkusealm

apcntype	gttmode	randsls			
* The mtrprse parameter cannot be specified for an IPGWx linkset.					

Procedure

1. Display the system-wide IP TPS usage report, and the IPGWx linksets, by entering the **rept-stat-iptps** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

IP TPS USAGE REPORT
      THRESH  CONFIG      TPS      PEAK      PEAKTIMESTAMP
-----
SYSTEM
RLGHNCXA03W 100%   30000  TX:   7200   7600  05-02-10 11:40:04
              RCV:   7200   7600  05-02-10 11:40:04
-----
LSN
LSGW1101      80%    6000  TX:   5100   5500  05-02-10 11:40:04
              RCV:   5100   5500  05-02-10 11:40:04
LSGW1103      80%    6000  TX:   5200   5500  05-02-10 11:40:04
              RCV:   5200   5500  05-02-10 11:40:04
LSGW1105      80%   14000  TX:   7300   7450  05-02-10 11:40:04
              RCV:   7300   7450  05-02-10 11:40:04
LSGW1107      70%    4000  TX:   3200   3500  05-02-10 11:40:04
              RCV:   3200   3500  05-02-10 11:40:04
-----
Command Completed.
```

2. Display the linkset that is being changed by entering the **rtrv-ls** command with a linkset name shown in the **rept-stat-iptps** output in step 1. For this example, enter this command.

rtrv-ls:lsn=lsqw1103

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN          APCA  (SS7)  SCRNL3T SLT          GWS GWS GWS
lsqw1103     003-002-004  none  1  1  no  A  1  off off off no  off

CLLI          TFATCABMLQ MTPRSE ASL8
----- 1          no  no

IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
yes      ----- 10000 70    % 70    % CdPA

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR
SET  BPS      MODE TSET  ECM  N1  N2

LOC  LINK SLC TYPE      LP      ATM      VCI  VPI  LL
SET  BPS      TSEL

LOC  LINK SLC TYPE      LP      ATM      VCI  VPI  CRC4 SI SN
SET  BPS      TSEL

LOC  LINK SLC TYPE      IPLIML2

LOC  LINK SLC TYPE
1103 A  0  SS7IPGW

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR  E1  E1
SET  BPS      ECM  N1  N2  LOC  PORT TS

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR  T1  T1
SET  BPS      ECM  N1  N2  LOC  PORT TS
```

Link set table is (14 of 1024) 1% full

If this linkset has a mate linkset assigned to it, the name of the mate linkset is shown in the **MATELSN** field of the **rtrv-ls** output, as shown in the following output.

rtrv-ls:lsn=lsgw1103

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	GWS	GWS	GWS	SLSCI	NIS
lsgw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off
CLLI				TFATCABMLQ		MTPRSE		ASL8					
-----				1		no		no					
IPGWAPC	MATELSN	IPTPS		LSUSEALM	SLKUSEALM	GTTMODE							
yes	lsgw1107	10000		70	% 70	% CdPA							
LOC	LINK	SLC	TYPE	L2T	BPS	L1	MODE	TSET	ECM	PCR	PCR		
				SET						N1	N2		
LOC	LINK	SLC	TYPE	LP	BPS	ATM			VCI	VPI	LL		
				SET		TSEL							
LOC	LINK	SLC	TYPE	LP	BPS	ATM			VCI	VPI	E1ATM		
				SET		TSEL					CRC4	SI	SN
LOC	LINK	SLC	TYPE	IPLIML2									
LOC	LINK	SLC	TYPE										
1103	A	0	SS7IPGW										
LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	E1	E1			
				SET			N1	N2	LOC	PORT	TS		
LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	T1	T1			
				SET			N1	N2	LOC	PORT	TS		

Link set table is (14 of 1024) 1% full

- To assign a mate linkset to this linkset, and the linkset contains more than one signaling link, all but one of these signaling links must be removed from the linkset. Perform the [Removing an IPGWx Signaling Link](#) procedure to remove these signaling links.

NOTE: If the linkset being changed has no signaling links, or only one signaling link assigned to it, or if the mate linkset is being removed from the linkset being changed, skip step 3 and go to step 4.

If you do not wish to change this linkset, either choose another linkset from the **rept-stat-iptps** output in step 1, and repeat step 2, and 3 if necessary, or perform the [Configuring an IPGWx Linkset](#) procedure and add a new linkset. Go to step 4.

- If a mate linkset is being added in this procedure, display the mate linkset from the IPGWx linksets shown in the **rept-stat-iptps** output in step 1.

If a mate linkset is being removed in this procedure, display the mate linkset shown in the **MATELSN** column of the **rtrv-ls** output in step 2.

For this example, enter this command.

rtrv-ls:lsn=lsgw1107

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
```

```

LSN          APCA  (SS7)  SCRNL3T SLT          GWS GWS GWS
lsgw1107     003-002-004  none  SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
                                1  1  no  A   1  off off off no  off

```

```

CLLI          TFATCABMLQ MTPRSE ASL8
----- 1          no      no

```

```

IPGWAPC MATELSN      IPTPS LSUSEALM SLKUSEALM GTTMODE
yes          ----- 10000 70      % 70      % CdPA

```

```

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR
                        SET  BPS    MODE TSET  ECM  N1   N2

LOC  LINK SLC TYPE      LP      ATM      VCI   VPI   LL
                        SET  BPS    TSEL          VPI   LL

LOC  LINK SLC TYPE      LP      ATM      VCI   VPI   CRC4 SI SN
                        SET  BPS    TSEL          VPI   CRC4 SI SN

LOC  LINK SLC TYPE      IPLIML2

LOC  LINK SLC TYPE
1107 A    0    SS7IPGW

```

```

LOC  LINK SLC TYPE      L2T      PCR  PCR  E1  E1
                        SET  BPS    ECM  N1  N2  LOC PORT TS

LOC  LINK SLC TYPE      L2T      PCR  PCR  T1  T1
                        SET  BPS    ECM  N1  N2  LOC PORT TS

```

Link set table is (14 of 1024) 1% full

- To use the linkset shown in step 4 as a mate, the network type of the adjacent point code of the linkset shown in step 4 must be the same as the network type of the linkset shown in step 2. The linkset shown in step 4 must not have more than one signaling link assigned to it.

NOTE: If the mate linkset is being removed from the linkset being changed, skip step 5 and go to step 6.

If the linkset contains more than one signaling link, all but one of these signaling links must be removed from the linkset. Perform the [Removing an IPGWx Signaling Link](#) procedure to remove these signaling links.

If you do not wish to change this linkset, or if the network type of the adjacent point codes of both linksets are not the same, either choose another linkset from the **rept-stat-iptps** output in step 1, and repeat step 4, and 5 if necessary, or perform the [Configuring an IPGWx Linkset](#) procedure and add a new linkset. Go to step 6.

If the network types of the adjacent point codes of both linksets are the same, and the mate linkset contains no more than one signaling link, do not perform the actions in this step. Go to step 6.

- Display the status of the card containing the signaling link assigned to the linkset being changed by entering the **rept-stat-card** command with the card location shown in the **LOC** field in the **rtrv-ls** output in step 2 (for adding a mate linkset) or in the **rtrv-ls** output in step 4 (for removing a mate linkset). For this example, enter one of these commands.

NOTE 1: If the linkset that the mate linkset is being added to has no signaling links (see the **rtrv-ls output in step 2), skip steps 6 through 16, and go to step 17.**

NOTE: If the mate linkset is being removed in this procedure, and has no signaling links (see the **rtrv-ls output in step 4), skip steps 6 through 16, and go to step 17.**

rept-stat-card:loc=1103 (for the adding a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1103  114-000-000   DCM      SS7IPGW   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        lsgw1103   -----
Command Completed.
```

rept-stat-card:loc=1107 (for the removing a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1107  114-000-000   DCM      SS7IPGW   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        lsgw1107   -----
Command Completed.
```

7. Display the status of the signaling link assigned to the card shown in step 6 by entering the **rept-stat-slk** command with the card location used in step 6 and the **link=a** parameter. For this example, enter one of these commands.

NOTE: If the status of the card shown in PST field in the **rept-stat-card** output in step 6 is OOS-MT-DSBLD, skip steps 7 through 16, and go to step 17.

rept-stat-slk:loc=1103:link=a (for the adding a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN          CLLI      PST      SST      AST
1103,A lsgw1103   ----- IS-NR     Avail   -----
ALARM STATUS      = No Alarms.
UNAVAIL REASON    = NA
Command Completed.
```

rept-stat-slk:loc=1107:link=a (for the removing a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN          CLLI      PST      SST      AST
1107,A lsgw1107   ----- IS-NR     Avail   -----
ALARM STATUS      = No Alarms.
UNAVAIL REASON    = NA
Command Completed.
```

8. Any in-service IP connections on the signaling link shown in step 7 must be placed out of service. The recommended method is to have the far end node place these IP connections out of service. Have the far-end node for the signaling link shown in step 7 perform these actions:

NOTE: If the status of the signaling link shown in the PST field of the **rept-stat-slk** output in step 7 is OOS-MT-DSBLD, skip steps 8 through 15, and go to step 16.

- Place the TALI sockets in the NEA-FEP state.
- Place the M3UA or SUA associations in either the ASP-INACTIVE or ASP-DOWN state.

NOTE: If you choose to perform this step, skip steps 9 through 16, and go to step 17.

9. Display the IP link associated with the card that the signaling link shown in step 7 is assigned to by entering the **rtrv-ip-lnk** command with the card location shown in step 7. For this example, enter one of these commands.

rtrv-ip-lnk:loc=1103 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1103  A     192.1.1.10      255.255.255.128  HALF    10     802.3    NO    NO
1103  B     -----          -----          HALF    10     DIX      NO    NO
```

rtrv-ip-lnk:loc=1107 (for the removing a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1107  A     192.3.1.10      255.255.255.128  HALF    10     802.3    NO    NO
1107  B     -----          -----          HALF    10     DIX      NO    NO
```

10. Display the IP host information associated with the IP link by entering the **rtrv-ip-host** command with the IP address shown in step 9. For this example, enter one of these commands.

rtrv-ip-host:ipaddr=192.001.001.010 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR      LOCAL HOST
192.1.1.10        IPNODE1_1103
```

IP Host table is (11 of 512) 2% full

rtrv-ip-host:ipaddr=192.003.001.010 (for the removing a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR      LOCAL HOST
192.3.1.10        IPNODE1_1107
```

IP Host table is (11 of 512) 2% full

11. Display the socket associated with the local host name shown in step 10 by entering the **rtrv-appl-sock** command. For this example, enter one of these commands.

rtrv-appl-sock:lhost=ipnode1_1103 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_1103
LINK   A
LHOST  IPNODE1_1103
```

RHOST	KC_HLR2	RPORT	7001
LPORT	7000	DCMPS	1
SERVER	YES	RTT	60
REXMIT	FIXED	ALW	YES
OPEN	YES		

IP Appl Sock/Assoc table is (4 of 4000) 1% full

rtrv-appl-sock: lhost=ipnode1_1107 (for the removing a mate linkset example)

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

IP Appl Sock/Assoc table is (4 of 4000) 1% full

NOTE: If the specified socket name is not in the database, the rtrv-appl-sock output shows no socket information as shown above.

- Change the **alw** parameter values in the socket shown in step 11 using the **chg-appl-sock** command with the **alw=no** parameters, as necessary.

NOTE: If there is no socket shown in step 11, or the open and alw parameter values of the socket shown in step 11 are no, skip this step and step 13, and go to step 14.

For example, enter this command.

chg-appl-sock: sname=kc_hlr1_1103: alw=no



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

When this command has successfully completed, the following message should appear.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD

Repeat this step for all sockets shown in step 11.

- Change the **open** parameter values in the socket shown in step 11 using the **chg-appl-sock** command with the **open=no** parameters, as necessary.

For example, enter this command.

chg-appl-sock: sname=kc_hlr1_1103: open=no

When this command has successfully completed, the following message should appear.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD

Repeat this step for all sockets shown in step 11.

- Display the association associated with the local host name shown in step 10 by entering the **rtrv-assoc** command.

For this example, enter one of these command.

rtrv-assoc: lhost=ipnode1_1107 (for the removing a mate linkset example)

This is an example of possible output.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

	CARD	IPLNK							
ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW	
assoc1	1107	A	A	M3UA	1030	1030	YES	YES	

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1107
```

rtrv-assoc: lhost=ipnode1_1103 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
```

NOTE: If the specified association name is not in the database, the rtrv-assoc output shows no association information as shown above.

15. Change the **alw** parameter values in the association shown in step 14 using the **chg-assoc** command with the **alw=no** parameters, as necessary.

NOTE: If there is no association shown in step 14, or the open and alw parameter values of the association shown in step 14 are no, skip this step and step 16, and go to step 17.

chg-assoc: aname=assoc1: alw=no



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```

Repeat this step for all associations shown in step 14.

16. Change the **open** parameter values in the association shown in step 14 using the **chg-assoc** command with the **open=no** parameters, as necessary.

chg-assoc: aname=assoc1: open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```

Repeat this step for all associations shown in step 14.

17. Deactivate the signaling link assigned to the IP card using the **dact-slk** command. For example, enter one of these commands:

dact-slk: loc=1103: link=a (for the adding a mate linkset example)

dact-slk: loc=1107: link=a (for the removing a mate linkset example)



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

18. Inhibit the IP card using the **inh-card** command. For example, enter one of these commands.

inh-card: loc=1103 (for the adding a mate linkset example)

inh-card: loc=1107 (for the removing a mate linkset example)

This message should appear.


```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

19. Change the linkset shown in step 2 with the **chg-ls** command. If a mate IPGWx linkset is being added, use the **matelsn** and **action=add** parameters with the **chg-ls** command. If a mate IPGWx linkset is being removed, use the **matelsn** and **action=delete** parameters with the **chg-ls** command.

To add a mate linkset in this example, enter this command.

```
chg-ls: lsn=lsgw1103:matelsn=lsgw1107:action=add
```

To remove a mate linkset in this example, enter this command.

```
chg-ls: lsn=lsgw1103:matelsn=lsgw1107:action=delete
```

NOTE: There are other optional parameters that can be specified with the **chg-ls** command, but are not required for an IPGWx linkset. These parameters and their usage are discussed in the [Configuring an IPGWx Linkset](#) procedure and in the “Changing an SS7 Linkset” procedure in the *Database Administration Manual - SS7*.

When the **chg-ls** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 36.0.0
Link set table is ( 14 of 1024) 1% full
CHG-LS: MASP A - COMPLTD
```

20. Verify the changes using the **rtrv-ls** command specifying the linkset name specified in step 19 with the **lsn** parameter. For this example, enter this command.

```
rtrv-ls: lsn=lsgw1103
```

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
```

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsgw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off

CLLI	TFATCABMLQ	MTPRSE	ASL8
-----	1	no	no

IPGWAPC	MATELSN	IPTPS	LSUSEALM	SLKUSEALM	GTTMODE
yes	lsgw1107	10000	70	% 70	% CdPA

LOC	LINK	SLC	TYPE	L2T	BPS	L1	TSET	ECM	PCR	PCR
				SET		MODE			N1	N2

LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL	VCI	VPI	LL
				SET						

LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL	VCI	VPI	E1ATM
				SET						CRC4 SI SN

LOC	LINK	SLC	TYPE	IPLIML2

LOC	LINK	SLC	TYPE
1103	A	0	SS7IPGW

LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	E1	E1
				SET			N1	N2	LOC	PORT TS

LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	T1	T1
				SET			N1	N2	LOC	PORT TS

```
Link set table is ( 14 of 1024) 1% full
```

If the mate linkset was removed in step 19, the **MATELSN** column of the **rtrv-ls** output should contain dashes, as shown in the following example.

rtrv-ls:lsn=lsqw1103

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN	APCA	(SS7)	SCRN	L3T	SLT	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsqw1103	003-002-004		none	1	1	no	A	1		1	off	off	off	no	off

CLLI	TFATCABMLQ	MTPRSE	ASL8
-----	1	no	no

IPGWAPC	MATELSN	IPTPS	LSUSEALM	SLKUSEALM	GTTMODE
yes	-----	10000	70	% 70	% CdPA

LOC	LINK	SLC	TYPE	L2T	SET	BPS	L1	MODE	TSET	ECM	PCR	PCR
											N1	N2
LOC	LINK	SLC	TYPE	LP	SET	BPS	ATM	TSEL		VCI	VPI	LL
LOC	LINK	SLC	TYPE	LP	SET	BPS	ATM	TSEL		VCI	VPI	E1ATM
LOC	LINK	SLC	TYPE	IPLIML2								
LOC	LINK	SLC	TYPE									
1103	A	0	SS7IPGW									
LOC	LINK	SLC	TYPE	L2T	SET	BPS	ECM	PCR	PCR	E1	E1	
								N1	N2	LOC	PORT	TS
LOC	LINK	SLC	TYPE	L2T	SET	BPS	ECM	PCR	PCR	T1	T1	
								N1	N2	LOC	PORT	TS

Link set table is (14 of 1024) 1% full

21. Allow the IP card that was inhibited in step 18 using the **alw-card** command. For example, enter one of these commands.

NOTE: If the linkset shown in step 20 does not have a signaling link assigned to it, skip steps 21 through 25, and go to step 26.

alw-card:loc=1103 (for the adding a mate linkset example)

alw-card:loc=1107 (for the removing a mate linkset example)

This message should appear.

rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0
Card has been allowed.

22. Activate the signaling link from step 17 using the **act-slk** command. For example, enter one of these commands.

act-slk:loc=1103:link=a (for the adding a mate linkset example)

act-slk:loc=1107:link=a (for the removing a mate linkset example)

The output confirms the activation.

rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card

23. Change the **open** and **alw** parameter values for all the sockets that were changed in steps 12 or 13 using the **chg-appl-sock** command with the **open=yes** and **alw=yes** parameters. For example, enter this command.

NOTE: If steps 12 and 13 were not performed, skip this step and go to step 24.

chg-appl-sock:sname=kc_hlr1_1103:open=yes:alw=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

24. Change the **open** and **alw** parameter values for all the associations changed in steps 15 or 16 using the **chg-assoc** command with the **open=yes** and **alw=yes** parameters.

NOTE: If steps 15 and 16 were not performed, skip this step and go to step 25.

chg-assoc:aname=assoc1:open=yes:alw=yes

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```


25. Have the far-end node for the signaling link shown in step 20 perform these actions to place the IP connections on the signaling link into service:


- Place the TALI sockets in the NEA-FEA state.
- Place the M3UAor SUAassociations in the ASP-ACTIVEstate.


26. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
.
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 4-3. Configuring a Mate IPGWx Linkset

















Adding an IPGWx Signaling Link

This procedure is used to add an IPGWx signaling link to the database using the **ent -slk** command with these parameter:

: loc – The card location of the IP card that the IP signaling link will be assigned to. The cards specified by this parameter are IP cards running the SS7IPGW or IPGWI applications.

: link – The signaling link on the card specified in the **loc** parameter.

: lsn – The name of the linkset that will contain the signaling link.

: slc – The signaling link code. The SLC must be unique within the linkset. It must be the same at both the EAGLE 5 ISS location and the distant node.

The **ent-slk** command also contains these parameters, **l2tset**, **l1mode**, **bps**, **tset**, **ecm**, **pcrn1**, **pcrn2**, **lpset**, **atmtsel**, **vci**, **vpi**, **ll**, **e1atmcrc4**, **e1atmsi**, **e1atmsn**, **ts**, **e1port**, **e1loc**, **t1port**, and **t1loc**. These parameters are used only for configuring low-speed, ATM high-speed, E1, and T1 signaling links and are not used in this procedure. For more information on configuring these types of signaling links, see the *Database Administration Manual - SS7*.

The **ent-slk** command also contains the parameter **ipliml2**. This parameter is used only for configuring IPLIMx signaling links and is not used in this procedure. For more information on configuring IPLIMx signaling links, see the [Adding an IPLIMx Signaling Link](#) procedure in [Chapter 3 TALI IPLIMx Configuration Procedures](#) or the [Adding an IPLIMx Signaling Link](#) procedure in [Chapter 5 IETF M2PA Configuration Procedures](#).

These items must be configured in the database before an IP signaling link can be added:

- Shelf – see "Adding a Shelf" in the *Database Administration Manual - System Management*.
- Card – see [Adding an IPGWx Card](#)
- Destination Point Code – see "Adding a Destination Point Code" in the *Database Administration Manual - SS7*.
- Linkset – see [Configuring an IPGWx Linkset](#).

Verify that the link has been physically installed (all cable connections have been made).

To configure the EAGLE 5 ISS to perform circular routing detection test on the signaling links, "Configuring Circular Route Detection" procedure in the *Database Administration Manual - SS7*.

NOTE: Circular route detection is not supported in ITU networks.

To provision a EAGLE 5 ISS with more than 700 signaling links, the EAGLE 5 ISS must have certain levels of hardware installed. See the "Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links" for more information on these hardware requirements.

The EAGLE 5 ISS can contain a mixture of low-speed, E1, T1, ATM high-speed, and IP signaling links. The "Determining the Number of High-Speed and Low-Speed Signaling Links" on this page describes how to determine the quantities of the different types of signaling links the EAGLE 5 ISS can have.

Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links

To provision a EAGLE 5 ISS with more than 700 signaling links (currently the EAGLE 5 ISS can have maximum capacities of 1200, or 1500, or 2000 signaling links), the following additional requirements must be met:

- The Measurements Platform feature must be enabled. Perform these procedures in the *Database Administration Manual - System Management* to enable the Measurements Platform feature:
 - "Adding an MCPM"
 - "Configuring the IP Communications Link for the Measurements Platform"

— "Adding an FTP Server"

- To provision more than 1200 signaling links, the Large System # Links controlled feature must be enabled for 1500 or 2000 signaling links. For more information on enabling this feature, go to the [Enabling the Large System # Links Controlled Feature](#) procedure.

Determining the Number of High-Speed and Low-Speed Signaling Links

An EAGLE 5 ISS containing either 1200, or 1500, or 2000 signaling links can contain the following quantities of signaling links:

- 180 high-speed ATM signaling links assigned to the ATMANSI application. If there are any high-speed ATM signaling links assigned to the ATMITU application, the maximum number of high-speed ATM signaling links is 115.
- 100 signaling links assigned to either the IPLIM or IPLIMI applications.
- 64 signaling links assigned to either the **ss7ipgw** or **ipgwi** application, or combinations of the **ss7ipgw** and **ipgwi** applications.
- 64 unchannelized E1 signaling links.

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET running either the **iplimi** or **ipgwi** applications.
- E1-ATM running the **atmitu** application.

Canceling the REPT-STAT-SLK, RTRV-LS, and RTRV-SLK Commands

Because the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands used in this procedure can output information for a long period of time, the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered, from another terminal other than the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current signaling link configuration using the **rtrv-slk** command.

This is an example of the possible output.

```

r1ghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0

LOC LINK LSN          SLC TYPE      L2T      L1      PCR PCR
SET BPS      MODE TSET  ECM N1  N2
1201 B   lsa1          0 LIMDS0    1   56000 --- --- BASIC --- -----
1203 B   lsa2          0 LIMDS0    1   56000 --- --- BASIC --- -----
1205 A   lsa3          0 LIMV35    3   64000 DCE  ON  BASIC --- -----
1207 A   lsn1207a      0 LIMDS0    1   56000 --- --- BASIC --- -----
1207 B   lsn1207b      0 LIMDS0    1   56000 --- --- BASIC --- -----
1214 A   lsn1214a      0 LIMV35    2   64000 DTE  --- PCR  76   3800
1214 B   lsa3          1 LIMV35    3   64000 DCE  ON  BASIC --- -----

LOC LINK LSN          SLC TYPE      LP      ATM      VCI      VPI      LL
SET BPS      TSEL
No Links Set up.

LOC LINK LSN          SLC TYPE      LP      ATM      VCI      VPI      E1ATM
SET BPS      TSEL      CRC4 SI SN
No Links Set up.

LOC LINK LSN          SLC TYPE      IPLIML2
No Links Set up.

LOC LINK LSN          SLC TYPE
No Links Set up.

LOC LINK LSN          SLC TYPE      L2T      BPS      ECM      PCR PCR E1 E1
SET BPS      ECM N1  N2  LOC PORT TS
No Links Set up.

LOC LINK LSN          SLC TYPE      L2T      BPS      ECM      PCR PCR T1 T1
SET BPS      ECM N1  N2  LOC PORT TS
No Links Set up.

SLK table is (7 of 1200) 1% full.

```

If the **rtrv-slk** output shows that the maximum number of signaling links is 2000, go to step 2.

If the **rtrv-slk** output shows that the maximum number of signaling links is 1200, and the signaling link being added increases the number beyond 1200, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for either 1500 signaling links or 2000 signaling links. Then go to step 2.

If the **rtrv-slk** output shows that the maximum number of signaling links is 1500, and the signaling link being added increases the number beyond 1500, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for 2000 signaling links. Then go to step 2.

If the addition of the new signaling link will not exceed the maximum number of signaling links, go to step 2.

2. Display the current linkset configuration using the **rtrv-ls** command.

This is an example of the possible output.

```

r1ghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

LSN          APCA      (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS

```

```

e1e2      001-207-000  none  1  1  no  B  6  off off off no  off
ls1305    000-005-000  none  1  1  no  A  1  off off off no  off
ls1307    000-007-000  none  1  1  no  A  1  off off off no  off
e1m1s1    001-001-001  none  1  1  no  A  7  off off off no  off
e1m1s2    001-001-002  none  1  1  no  A  7  off off off no  off

```

```

LSN      APCA  (X25)  SCRNL3T SLT      GWS GWS GWS
      SET SET BEI LST LNKS ACT MES DIS SLSCI NIS

```

```

LSN      APCI  (SS7)  SCRNL3T SLT      GWS GWS GWS
e1e2i    1-207-0      none  1  1  no  B  4  off off off --- on
ls1315   0-015-0      none  1  1  no  A  1  off off off --- off
ls1317   0-017-0      none  1  1  no  A  1  off off off --- on
e1m2s1   1-011-1      none  1  1  no  A  7  off off off --- off
e1m2s2   1-011-2      none  1  1  no  A  7  off off off --- off

```

```

LSN      APCN  (SS7)  SCRNL3T SLT      GWS GWS GWS
      SET SET BEI LST LNKS ACT MES DIS SLSCI NIS

```

```

LSN      APCN24 (SS7)  SCRNL3T SLT      GWS GWS GWS
      SET SET BEI LST LNKS ACT MES DIS SLSCI NIS

```

```

LSN (CHINA) APCN  (SS7)  SCRNL3T SLT      GWS GWS GWS
      SET SET BEI LST LNKS ACT MES DIS SLSCI NIS

```

```

LSN (CHINA) APCN24 (SS7)  SCRNL3T SLT      GWS GWS GWS
      SET SET BEI LST LNKS ACT MES DIS SLSCI NIS

```

Link set table is (10 of 1024) 1% full.

If the required linkset is not in the database, perform the [Configuring an IPGWx Linkset](#) to add the linkset to the database.

If you plan to use a linkset shown in this step, go to step 3.

If a new linkset is being added in this step, skip step 3 and go to step 4.

3. Display the linkset that the signaling link is being assigned to using the **rtrv-ls** command, specifying the name of the linkset that the signaling link is being assigned to.

For this example, enter this command.

rtrv-ls:lsn=lsnipgw

This is an example of the possible output.

```

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

```

```

LSN      APCI  (SS7)  SCRNL3T SLT      GWS GWS GWS
lsnipgw  2968      none  1  1  no  A  1  off off off --- off

```

```

CLLI      TFATCABMLQ  MTPRSE  ASL8  SLRSRB  MULTGC  ITUTFR
-----  1          no      ---  1          yes      off

```

```

IPGWAPC  MATELSN  IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
yes      -----  10000  70      % 70      % CdPA

```

```

LOC  LINK SLC TYPE      L2T  L1      PCR  PCR
      SET BPS      MODE TSET  ECM  N1  N2

LOC  LINK SLC TYPE      LP      ATM
      SET BPS      TSEL      VCI  VPI  LL

LOC  LINK SLC TYPE      LP      ATM      E1ATM
      SET BPS      TSEL      VCI  VPI  CRC4 SI SN

LOC  LINK SLC TYPE      IPLIML2

```

```

LOC LINK SLC TYPE
1317 A 0 IPGWI

L2T PCR PCR E1 E1
SET BPS ECM N1 N2 LOC PORT TS

LOC LINK SLC TYPE L2T BPS ECM PCR PCR T1 T1
SET BPS ECM N1 N2 LOC PORT TS

SAPCI
1-10-1

SAPCN
1234-aa
1235-bb
1200-zz

```

Link set table is (13 of 1024) 1% full.

Linksets containing IPGWx signaling links can contain only IPGWx signaling links.

4. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD TYPE APPL LSET NAME LINK SLC LSET NAME LINK SLC
1102 TSM GLS
1103 DCM VXWLAN
1113 GSPM EOAM
1114 TDM-A
1115 GSPM EOAM
1116 TDM-B
1117 MDAL
1201 LIMDS0 SS7ANSI lsa1 B 0
1202 LIMV35 SS7ANSI
1203 LIMDS0 SS7ANSI lsa2 B 0
1204 LIMDS0 SS7ANSI
1205 LIMV35 SS7ANSI lsa3 A 0
1206 LIMV35 SS7ANSI
1207 LIMDS0 SS7ANSI lsn1207a A 0 lsn1207b B 0
1208 LIMDS0 SS7ANSI
1212 LIMV35 SS7ANSI
1213 LIMDS0 SS7ANSI
1214 LIMV35 SS7ANSI lsn1214a A 0 lsa3 B 1
1215 LIMDS0 SS7ANSI
1301 LIMV35 ATMANSI
1302 LIMATM ATMANSI
1304 LIMV35 SS7ANSI
1305 LIMATM ATMANSI
1308 LIMV35 SS7ANSI
1311 LIMDS0 SS7ANSI
1313 LIMDS0 SS7ANSI
1315 LIMV35 CCS7ITU
1317 LIMV35 CCS7ITU
1318 LIMATM ATMANSI

```

If the required card is not in the database, perform the [Adding an IPGWx Card](#) procedure to add the IP card to the database.

NOTE 1: If the linkset that the signaling link will be added to contains the **multgc=yes** parameter, the application assigned to the card must be IPGWI.

NOTE: If the IPGWx linkset contains any IPGWx signaling links, skip step 5 and go to step 6.

5. If you wish to assign an IPGWx signaling link to a linkset contains no signaling links, but the **IPGWAPC** value is no, perform the “Removing a Linkset Containing SS7 Signaling Links” procedure in the *Database Administration Manual - SS7* and remove the linkset, then perform the [Configuring an IPGWx](#)

[Linkset](#) procedure and re-enter the new linkset with the **ipgwapc=yes** parameter. Skip steps 6 through 8 and go to step 9.

6. If the desired linkset, shown in the **rtrv-ls** output in step 3, has a mate IPGWx linkset assigned, or is the mate to another IPGWx linkset, the desired linkset can contain only one signaling link.

If the desired linkset does not have a mate IPGWx linkset assigned, or is not the mate of another IPGWx linkset, the desired linkset can contain up to 8 IPGWx signaling links. No other signaling link types can be in an IPGWx linkset.

If you wish to assign more than one IPGWx signaling link to an IPGWx linkset that has a mate linkset assigned, the mate to this linkset must be removed. Perform the [Configuring a Mate IPGWx Linkset](#) procedure and remove the mate linkset from the linkset you wish to assign the IPGWx signaling link to. If you do not wish to use this linkset, perform the [Configuring an IPGWx Linkset](#) procedure and add a new IPGWx linkset.

If the desired IPGWx linkset does not have a mate assigned, go to step 8.

If the desired linkset has a mate linkset assigned, and contains an IPGWx signaling link, perform the [Configuring a Mate IPGWx Linkset](#) procedure and add a new IPGWx linkset. Skip steps 7 and 8, and go to step 9.

7. If you wish to assign more than one IPGWx signaling link to an IPGWx linkset that is a mate to another IPGWx linkset, this linkset must be removed from the other linkset as a mate.

To verify if the linkset you wish to use is the mate of another IPGWx linkset, enter the **rept-stat-iptps** command to display the names of all the IPGWx linksets. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

IP TPS USAGE REPORT
```

	THRESH	CONFIG		TPS	PEAK	PEAKTIMESTAMP

SYSTEM						
RLGHNCXA03W	100%	30000	TX:	7200	7600	05-02-10 11:40:04
			RCV:	7200	7600	05-02-10 11:40:04

LSN						
LSGW1101	80%	6000	TX:	5100	5500	05-02-10 11:40:04
			RCV:	5100	5500	05-02-10 11:40:04
LSGW1103	80%	6000	TX:	5200	5500	05-02-10 11:40:04
			RCV:	5200	5500	05-02-10 11:40:04
LSGW1105	80%	14000	TX:	7300	7450	05-02-10 11:40:04
			RCV:	7300	7450	05-02-10 11:40:04
LSGW1107	70%	4000	TX:	3200	3500	05-02-10 11:40:04
			RCV:	3200	3500	05-02-10 11:40:04

Command Completed.						

8. Enter the **rtrv-ls:lsn=<IPGWx linkset name from the rept-stat-iptps output>** to verify if the desired linkset is the mate of another IPGWx linkset.

For this example, enter this command.

rtrv-ls:lsn=lsgw1103

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
```

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS
lsgw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off			


```

CLLI          TFATCABMLQ MTPRSE ASL8
----- 1          no      no

IPGWAPC MATELSN      IPTPS LSUSEALM SLKUSEALM GTTMODE
yes      lsgw1107    10000 70      % 70      % CdPA

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR
      SET  BPS      MODE TSET  ECM   N1   N2

LOC  LINK SLC TYPE      LP      ATM      VCI   VPI   LL
      SET  BPS      TSEL      VCI   VPI   CRC4 SI SN

LOC  LINK SLC TYPE      LP      ATM      VCI   VPI   E1ATM
      SET  BPS      TSEL      VCI   VPI   CRC4 SI SN

LOC  LINK SLC TYPE      IPLIML2

LOC  LINK SLC TYPE
1103 A      0      SS7IPGW

LOC  LINK SLC TYPE      L2T      PCR  PCR  E1  E1
      SET  BPS      ECM   N1   N2   LOC PORT TS

LOC  LINK SLC TYPE      L2T      PCR  PCR  T1  T1
      SET  BPS      ECM   N1   N2   LOC PORT TS

```

Link set table is (14 of 1024) 1% full

If the name of the linkset you wish to use is not shown in the **MATELSN** field of the **rtrv-ls** output, repeat this step until all the IPGWx linksets have been displayed, or until a linkset has been found that has the linkset you wish to use assigned as a mate. If the linkset you wish to use is not the mate of another IPGWx linkset, go to step 9.

If the name of the linkset you wish to use is shown in the **MATELSN** field of the **rtrv-ls** output, perform the [Configuring a Mate IPGWx Linkset](#) procedure to remove this linkset from the other linkset as a mate. Then go to step 9.

If the desired linkset is the mate of another IPGWx linkset, and you do not wish to use this linkset, perform the [Configuring an IPGWx Linkset](#) procedure and add a new IPGWx linkset. Then go to step 9.

9. Add the signaling link to the database using the **ent-slk** command. [Table 4-5](#) shows the parameters and values that can be specified with the **ent-slk** command.

Table 4-5. IPGWx Signaling Link Parameter Combinations

IPGWx Signaling Link
:loc = location of the IP card with one of these applications: SS7IPGW or IPGWI; and the DCM card type. ⁶
:link = A
:lsn = linkset name 1, 2, 3, 4, 5
:slc = 0 - 15 ^{4, 5}
Notes:
1. If the multgc=yes parameter is assigned to the linkset, the card's application must be IPGWI.
2. The ipgwapc=yes parameter must be assigned to the linkset.
3. If the card's application is IPGWI, the linkset adjacent point code must be ITU. If the card's application is SS7IPGW, the linkset adjacent point code must be ANSI. The domain of the linkset adjacent point code must be SS7.
4. A linkset can contain only one signaling link assigned to the SS7IPGW or IPGWI applications if the linkset contains a mate IPGWx linkset, or is the mate of an IPGWx linkset.
5. If the linkset does not have a mate IPGWx linkset assigned to it, or is not the mate of an IPGWx linkset, the linkset can contain up to 8 signaling links assigned to the SS7IPGW or IPGWI applications.

IPGWx Signaling Link

6. If the signaling link is being assigned to a single-slot EDCM, to maximize the performance of the IPGWx cards assigned to the linkset, it is recommended that the all signaling links in the linkset are assigned to single-slot EDCMs with part number 870-2372-xx.

For this example, enter these commands.

ent-slk:loc=2207:link=a:lsn=lsnlp3:slc=0

ent-slk:loc=2211:link=a:lsn=lsnlp4:slc=0

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:29:03 GMT EAGLE5 36.0.0
ENT-SLK: MASP A - COMPLTD
```

10. Verify the changes using the **rtrv-slk** command with the card location and **link** parameter values specified in step 9.

rtrv-slk:loc=2207:link=a

This is an example of the possible output.

```
rlghncxa03w 07-05-19 21:17:04 GMT EAGLE5 37.0.0
LOC LINK LSN          SLC TYPE
2207 A   lsnlp3       0   SS7IPGW
```

rtrv-slk:loc=2211:link=a

This is an example of the possible output.

```
rlghncxa03w 07-05-19 21:17:04 GMT EAGLE5 37.0.0
LOC LINK LSN          SLC TYPE
2211 A   lsnlp4       0   IPGWI
```

11. If any cards contain the first signaling link on a card, those cards must be brought into service with the **rst-card** command, specifying the location of the card.

For this example, enter these commands.

rst-card:loc=2207

rst-card:loc=2211

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-23 13:05:05 GMT EAGLE5 36.0.0
Card has been allowed.
```

12. Activate all signaling links on the cards using the **act-slk** command, specifying the card location and **link** parameter value of each signaling link.

For this example, enter these commands.

act-slk:loc=2207:link=a

act-slk:loc=2211:link=a

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:31:24 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

13. Check the status of the signaling links added in step 9 using the **rept-stat-slk** command with the card location and **link** parameter values specified in step 9. The state of each signaling link should be in service

normal (IS-NR) after the link has completed alignment (shown in the **PST** field). For this example, enter these commands.

rept-stat-slk:loc=2207:link=a

This is an example of the possible output.

```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2207,A   lsnlp3   -----  IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```

rept-stat-slk:loc=2211:link=a


This is an example of the possible output.


```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2211,A   lsnlp4   -----  IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```


14. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-4. Adding an IPGWx Signaling Link









Enabling the Large System # Links Controlled Feature

This procedure is used to enable the Large System # Links controlled feature using the feature's part number and a feature access key.

The feature access key for the Large System # Links controlled feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

This feature allows the EAGLE 5 ISS to contain a maximum of either 1500 or 2000 signaling links.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key generated by Tekelec's feature access key generator, and supplied to you when you purchase or temporarily try a controlled feature. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number associated with the signaling link quantity being enabled:

- 893005901 for the 1500 signaling link quantity
- 893005910 for the 2000 signaling link quantity.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent-serial-num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature is enabled with the **enable-ctrl-feat** command, the feature is also activated. The **chg-ctrl-feat** command is not necessary to activate the feature.

This feature cannot be disabled with the **chg-ctrl-feat** command and the **status=off** parameter.

Hardware Supported for Signaling Link Quantities Greater than 1500

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 card running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET card running either the **iplimi** or **ipgwi** applications.
- E1-ATM card running the **atmitu** application.

To increase the signaling link quantity to more than 1500 signaling links, HIPR cards must be installed into card locations 9 and 10 in each shelf in the EAGLE 5 ISS. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the EAGLE 5 ISS shelves.

Procedure

1. Display the status of the Large System # Links controlled feature by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the **rtrv-ctrl-feat** output shows that the controlled feature is enabled for the desired quantity or for a quantity that is greater than the desired quantity, no further action is necessary. This procedure does not need to be performed.

NOTE: If the **rtrv-ctrl-feat** output in step 1 shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, skip steps 2 through 5, and go to step 6.

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

```
ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Verify that HIPR cards are installed in card locations 9 and 10 in each shelf of the EAGLE 5 ISS.

NOTE: If the 2000 signaling link quantity is not being enabled in this procedure, skip step 6 and go to step 7.

Enter this command.

rept-stat-gpl:gpl=hipr

This is an example of the possible output.

```
rlghncxa03w 06-10-01 11:40:26 GMT EAGLE5 36.0.0
GPL      CARD      RUNNING      APPROVED      TRIAL
HIPR     1109      126-002-000  126-002-000  126-003-000
HIPR     1110      126-002-000  126-002-000  126-003-000
HIPR     1209      126-002-000  126-002-000  126-003-000
HIPR     1210      126-002-000  126-002-000  126-003-000
HIPR     1309      126-002-000  126-002-000  126-003-000
HIPR     1310      126-002-000  126-002-000  126-003-000
HIPR     2109      126-002-000  126-002-000  126-003-000
HIPR     2110      126-002-000  126-002-000  126-003-000
Command Completed
```

If HIPR cards are installed in each the shelf in the EAGLE 5 ISS, go to step 7.

If HIPR cards are not installed on each shelf in the EAGLE 5 ISS, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 7.

NOTE: Before the 2000 signaling link quantity is enabled, make sure the EAGLE 5 ISS is configured with the signaling link hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section.

If signaling hardware other than the hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section is installed and provisioned, contact the Customer Care Center before enabling the 2000 signaling link quantity. Refer to [Customer Care Center](#) for the contact information.

7. Enable the Large System # Links controlled feature for the desired quantity with the **enable-ctrl-feat** command specifying the part number corresponding to the new quantity of signaling links and the feature access key.

To increase the number of signaling links the EAGLE 5 ISS can contain to 1500, enter this command.

enable-ctrl-feat:partnum=893005901:fak=<feature access key>

To increase the number of signaling links the EAGLE 5 ISS can contain to 2000, enter this command.

enable-ctrl-feat:partnum=893005910:fak=<feature access key>

NOTE 1: A temporary feature access key cannot be specified to enable this feature.

NOTE 2: The values for the feature access key (the fak parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the part number specified in step 7.

If the 1500 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005901

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005901	on	1500

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the 2000 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005910

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005910	on	2000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-5. Enabling the Large System # Links Controlled Feature







Configuring an IP Link

This procedure is used to configure the link parameters for IP cards using the **chg-ip-lnk** command. These link parameters are used to configure the Ethernet hardware.

The **chg-ip-lnk** command uses the following parameters.

:loc – The card location of the IP card.

:port – The Ethernet interface on the IP card, A or B.

:ipaddr – IP address assigned to the Ethernet interface on the IP card. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:submask – The subnet mask of the IP interface. A subnet mask is an IP address with a restricted range of values. The bits in the mask must be a string of one’s followed by a string of zero’s. There must be at least two one’s in the mask, and the mask cannot be all one’s. See [Table 4-6](#) to assign the correct parameter values.

:auto – Tells hardware whether to automatically detect the **duplex** and **speed**.

:duplex – This is the mode of operation of the interface.

:speed – This is the bandwidth in megabits per second of the interface.

:mactype – This is the Media Access Control Type of the interface.

:mcast – The multicast control flag. This parameter enables or disables multicast support for the interface.

A zero **ipaddr** parameter value (**0.0.0.0**) indicates the IP card Ethernet interface to IP link association is disabled. The host to the original IP address must be removed before the **ipaddr=0.0.0.0** can be specified.

If the **defrouter** parameter of the **chg-ip-card** command contains an IP address for the card specified in this procedure, the network portion of one of the IP addresses assigned to the card in this procedure must match the network portion of the IP address specified by the defrouter parameter of the **chg-ip-card** command.

The network portion of the IP address is based on the class of the IP address (shown in [Table 4-6](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

If the **auto=yes** parameter is specified, then the **duplex** and **speed** parameters are not allowed.

The **loc** parameter value must be shown in the **rtrv-ip-card** output.

The IP card must be placed out of service.

If either the **ipaddr** or **submask** parameters are specified, then both parameters must be specified. If the **ipaddr** parameter value is zero (**0.0.0.0**), the **submask** parameter is not required.

If the IP card is a single-slot EDCM, the A or B interface can be used. The B interface cannot be used with the DCM.

The IP address and subnet mask values cannot be changed to an address representing a different network if:

- If the network interface specified by the **loc** and **port** parameters has a default router, **dnsa**, or **dsnb** parameter values assigned to it, as shown in the **rtrv-ip-card** output.

- Any IP routes, shown in the **rtrv-ip-rte** output, reference the IP address for the network interface specified by the **loc** and **port** parameters.

The IP link cannot be changed if open sockets or associations reference the IP link being changed.

The network portion of the IP addresses assigned to the IP links on an IP card must be unique. For example, if IP links are assigned to IP card 1103, the network portion of the IP address for Ethernet interface A (**port=a**) must be different from the IP address for Ethernet interface B (**port=b**).

The **submask** parameter value is based upon the **ipaddr** setting. See [Table 4-6](#) for the valid input values for the **submask** and **ipaddr** parameter combinations.

Table 4-6. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0 255.224.0.0 255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.0.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **ipaddr** parameter of the **chg-ip-lnk** command, the subnet address that results from the **ipaddr** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **ipaddr** and **submask**

parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Canceling the RTRV-APPL-SOCK and RTRV-ASSOC Commands

Because the **rtrv-appl-sock** and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10   255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----      -----      HALF    10     DIX      NO    NO
1203  A      192.1.1.12   255.255.255.0   ----    ---     DIX      YES   NO
1203  B      -----      -----      HALF    10     DIX      NO    NO
1205  A      192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2205  A      192.1.1.30   255.255.255.0   FULL    100    DIX      NO    NO
2205  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
```

NOTE: If the **ipaddr=0.0.0.0** is not being specified in this procedure, skip step 2 and go to step 3.

2. If IP address information is being added or changed (not deleted) in the link parameters, verify that the IP address is present in the IP host table by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

LOCAL IPADDR	LOCAL HOST
192.1.1.10	IPNODE1-1201
192.1.1.12	IPNODE1-1203
192.1.1.14	IPNODE1-1205
192.1.1.20	IPNODE2-1201
192.1.1.22	IPNODE2-1203
192.1.1.24	IPNODE2-1205
192.1.1.30	KC-HLR1
192.1.1.32	KC-HLR2
192.1.1.50	DN-MSC1
192.1.1.52	DN-MSC2

REMOTE IPADDR	REMOTE HOST
150.1.1.5	NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (11 of 512) 2% full

If the current IP address of the IP link is shown in the **rtrv-ip-host** output, remove the host assigned to the IP address by performing the [Adding an IP Host](#) procedure.

- To change IP link parameters, the signaling link to the IP card and the IP card have to be inhibited. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE
1201  A    nc001          0  SS7IPGW
```

- Retrieve the status of the signaling link assigned to the IP card to be changed using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1201,A  nc001      -----  IS-NR
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 5 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 7 to verify the IP card status.

- Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

6. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001    -----  OOS-MT-DSBLD  AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS: not aligned
UNAVAIL REASON = NA
Command Completed.
```

7. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM  SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
  SLK  PST      LS      CLLI
  A    IS-NR    nc001    -----
```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 8 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 10 to change the IP link parameters.

8. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card:loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

9. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM  SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
```

```

IMT BUS B          = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----

```

Command Completed.

10. Display the attributes of the IP card assigned to the IP link being changed by entering the **rtrv-ip-card** command and specifying the card location of the IP link.

NOTE: If the `ipaddr` or `submask` parameter values are not being changed, skip steps 10, 11, and 12, and go to step 13.

For this example, enter this command.

rtrv-ip-card:loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN    -----

```

If the **rtrv-ip-card** output shows an IP address for the default router (**DEFROUTER**) whose network portion matches the network portion of the IP address being changed, go to the [Configuring an IP Card](#) procedure and change the IP address of the default router to **0.0.0.0**.

11. Display any IP routes referencing the IP link being changed by entering the **rtrv-ip-rte** command and specifying the card location of the IP link.

For this example, enter this command.

rtrv-ip-rte:loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1201  128.252.10.5  255.255.255.255  140.188.13.33
1201  128.252.0.0   255.255.0.0      140.188.13.34
1201  150.10.1.1     255.255.255.255  140.190.15.3

```

IP Route table is (5 of 1024) 1% full

If the **rtrv-ip-rte** output shows that the card has IP routes assigned to it, go to the [Removing an IP Route](#) procedure and remove the IP routes from the database.

12. The subnet address that results from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

NOTE: If a Class A or C IP address (see [Table 3-3](#)) will be specified for the `ipaddr` parameter in step 15, skip step 12 and go to step 13.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 13.

This is an example of the possible output if the E5IS feature is on.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0
```

Choose **ipaddr** and **submask** parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 13.

13. Display the application sockets referencing the local host name that is associated with the IP link being changed by entering the **rtrv-appl-sock** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

NOTE: If the local host was removed in step 2, skip steps 13 and 14, and go to step 15.

For this example, enter this command.

rtrv-appl-sock: lhost="ipnode1-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
LINK   A
LHOST  ipnode1-1201
RHOST  kc-hlr1
LPORT  7000          RPORT  7000
SERVER YES          DCMPS  1
REXMIT FIXED        RTT    60
OPEN   YES          ALW    NO
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

If no sockets are displayed in this step, go to step 14.

If the **rtrv-appl-sock** output shows that the **open** parameter for any sockets is **yes**, perform one of these procedures to change the value of the **open** parameter of the sockets to **no**.

- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)

14. Display the associations referencing the local host name that is associated with the IP link being changed by entering the **rtrv-assoc** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

For this example, enter this command.

rtrv-assoc: lhost="ipnode1-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
swbel32    1201 A    A    M3UA    1030  2345 YES  YES
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1201

If no associations are displayed in this step, go to step 15.

If the **rtrv-assoc** output shows that the **open** parameter for any associations is **yes**, perform one of these procedures to hange the value of the **open** parameter the associations to **no**.

- [Changing an M2PA Association](#)
- [Changing an M3UA or SUA Association](#)

15. Change the link parameters associated with the IP card in the database using the **chg-ip-lnk** command. For this example, enter this command.

```
chg-ip-  
lnk:loc=1201:port=a:ipaddr=192.1.1.10 :submask=255.255.255.0:auto=yes:m  
actype=dix
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0  
CHG-IP-LNK: MASP A - COMPLTD
```

16. Verify the new link parameters associated with the IP card that was changed in step 15 by entering the **rtrv-ip-lnk** command with the card location specified in step 15.

For this example, enter this command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0  
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST  
1201  A      192.1.1.10        255.255.255.128  HALF    10      DIX      YES   NO  
1201  B      -----          -----          HALF    10      DIX      NO    NO
```

17. Allow the IP card that was inhibited in step 8 by using by using the **alw-card** command.

NOTE: If step 8 was not performed, skip steps 17 and 18, and go to step 19.

For example, enter this command.

```
alw-card:loc=1201
```

This message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0  
Card has been allowed.
```

18. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command. For example, enter this command.

```
rept-stat-card:loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0  
CARD  VERSION  TYPE  APPL  PST  SST  AST  
1201  114-000-000  DCM   SS7IPGW  IS-NR  Active  -----  
ALARM STATUS      = No Alarms.  
BPDCM GPL         = 002-102-000  
IMT BUS A         = Conn  
IMT BUS B         = Conn  
SIGNALING LINK STATUS  
SLK   PST        LS        CLLI  
A     IS-NR      nc001    -----
```

Command Completed.

19. Activate the signaling link from step 5 using the **act-slk** command.

NOTE: If step 5 was not performed, skip steps 19 and 20, and go to step 21.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

20. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command. For example, enter this command.

rept-stat-slk:loc=1201:link=a

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001      ----- IS-NR
Command Completed.
```

21. Perform the [Configuring an IP Card](#) procedure and change the IP address of the default router to a non-zero value, where the network portion of the default router IP address matches the network portion of the IP link's new IP address.

NOTE 1: If the ipaddr or submask values were not changed, skip steps 21 and 22, and go to step 23.

NOTE: If the IP address of the default router was not changed to 0.0.0.0 in step 10, skip step 21, and go to step 22.

22. Perform the [Adding an IP Route](#) procedure and add the IP routes back into the database.

NOTE: If IP routes were not removed in step 11, skip step 22, and go to step 23.

23. Perform one of these procedures as necessary and change the value of the **open** parameter of either the application socket or the association to **yes**.

NOTE: If the open parameter value for either an application socket or an association was not changed in either steps 13 or 14, skip step 23, and go to step 24.


- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)
- [Changing an M2PA Association](#)
- [Changing an M3UA or SUA Association](#)


24. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 4-6. Configuring an IP Link




















Adding an IP Host

This procedure associates hostnames with IP addresses using the **ent-ip-host** command.

The **ent-ip-host** command uses the following parameters.

:host– The host name to be associated with the IP address. This parameter identifies the logical name assigned to the device with the IP address indicated. The host name can contain up to 60 characters (using only these characters: a-z, A-Z, 0-9, -, .) and is not case sensitive. The host name must begin with a letter. Host names containing a dash (-) must be enclosed in double quotes.

:ipaddr – The IP address to be associated with the hostname. The node’s IP address. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:type – Specifies if the host resides on the IP card on the EAGLE 5 ISS (**type=local**, the default value), or if the host resides on equipment that is not in the EAGLE 5 ISS (**type=remote**). This parameter is optional.

The IP address for a local host must be shown in the **rtrv-ip-lnk** output.

The IP address for a remote host must not be shown in the **rtrv-ip-lnk** output.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
```

```
REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (10 of 512) 2% full

2. Verify that the IP address assigned to the IP links by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A    192.1.1.10   255.255.255.128  HALF    10     802.3    NO    NO
1201  B    -----    -----    HALF    10     DIX      NO    NO
1203  A    192.1.1.12   255.255.255.0   ----    ---    DIX      YES   NO
1203  B    -----    -----    HALF    10     DIX      NO    NO
1205  A    192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B    -----    -----    HALF    10     DIX      NO    NO
2101  A    192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B    -----    -----    HALF    10     DIX      NO    NO
2103  A    192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B    -----    -----    HALF    10     DIX      NO    NO
2105  A    192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B    -----    -----    HALF    10     DIX      NO    NO
2207  A    192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B    -----    -----    HALF    10     DIX      NO    NO
2213  A    192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B    -----    -----    HALF    10     DIX      NO    NO
2301  A    192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B    -----    -----    HALF    10     DIX      NO    NO
```

If a local host is being configured in this procedure, the IP address assigned to the local host must be shown in the **rtrv-ip-lnk** output. If the IP address is not shown in the **rtrv-ip-lnk** output, add the IP address by performing the [Configuring an IP Link](#) procedure.

If a remote host is being configured in this procedure, the IP address assigned to the remote host cannot be shown in the **rtrv-ip-lnk** output.

3. Add IP host information to the database by entering the **ent-ip-host** command.

If a local host is being configured, enter the **ent-ip-host** command with the IP address from step 2, and the **type=local** parameter or without the **type** parameter. If the **type** parameter is not specified with the **ent-ip-host** command, the **type** parameter value defaults to **local**.

If a remote host is being configured, enter the **ent-ip-host** command with the IP address that is not shown in step 2, and the **type=remote** parameter.

For example, enter this command.

```
ent-ip-host:host="kc-hlr1":ipaddr=192.1.1.30
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
ENT-IP-HOST: MASP A - COMPLTD
```

4. Verify the new IP host information in the database by entering the **rtrv-ip-host** command with the **host** parameter value specified in step 3.

For this example, enter this command.

```
rtrv-ip-host:host="kc-hlr1"
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOCAL IPADDR      LOCAL HOST
192.1.1.30        KC-HLR1
```


```
IP Host table is (11 of 512) 2% full
```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-7. Adding an IP Host



Configuring an IP Card

This procedure is used to change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

The **chg-ip-card** command uses the following parameters.

:loc – The card location of the IP card

:srchordr – Host Table Search Order

:dnrsa – Domain name server A's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:dnrsb – Domain name server B's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:domain – The domain name is used to construct a fully-qualified DNS name consisting of 120 characters or less. For example, a domain name can be **tekelec.com**, the hostname is **john.doe**. The fully-qualified DNS name would be **john.doe@tekelec.com**.

:defrouter – Default router IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:rstdomain – Reset Domain name. The parameter is used to reset the domain to a NULL value.

The IP card must be placed out of service.

The **rstdomain** parameter cannot be specified if the **domain** parameter is specified.

There is only one default router (**defrouter** parameter) for each IP card. The default router is used as the primary route unless a static IP routes is defined for the destination IP address. Static IP routes are assigned using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure.

The network portion of the IP address of the default router must match the network portion of one of the IP addresses assigned to the card.

The network portion of the IP address is based on the class of the IP address (shown in [Table 4-6](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

The default router can be associated with only one IP address assigned to the card if the defrouter parameter is specified. For example, the **dnrsa** value for card 1101 is 150.1.1.10. The **dnrsb** value for card 1101 is 160.25.37.1. A default router is provisioned with the IP address 150.1.1.4. The default router is associated with the Ethernet A IP address (the **dnrsa** parameter value), but not the Ethernet B IP address (the **dnrsb** parameter value).

If the default router is associated with one of the IP card's IP addresses, a second gateway router can be assigned to the other IP address on the IP card by provisioning a static IP route for the IP card using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure. Static IP routes can provide gateway routers associated with the other IP address on the IP card. To provision the gateway router (the **gtwy** parameter of the **ent-ip-rte** command) for the other IP address assigned to the IP card, the network portion of the gateway router's IP address must match the network portion of the other IP address assigned to the IP card.

Specifying the IP address 0.0.0.0 for the **dnrsa** or **dnrsb** parameters, removes the IP address for Ethernet A (**dnrsa**) or Ethernet B (**dnrsb**).

When an IP card is entered into the database with the **ent-card** command, the IP stack parameters associated with this card are initially set with these default values:

- **:srchordr** – SRVR
- **:dnsc** – No DNSA IP address is specified
- **:dnscb** – No DNSB IP address is specified
- **:domain** – No domain name is specified
- **:defrouter** – No default router IP address is specified
- **:rstdomain** – No

The value of any optional parameter not specified with the **chg-ip-card** command is not changed.

Procedure

1. Display the current IP parameters associated with card in the database by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNCA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN     -----

LOC 1203
  SRCHORDR  LOCAL
  DNCA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNCA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM
```

To change the parameters of an IP card, the signaling link to the card and the card have to be inhibited.

2. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE
1201  A    nc001        0  SS7IPGW
```

3. Retrieve the status of the signaling link shown in step 2 using the **rept-stat-slk** command specifying the card location and signaling link.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----  IS-NR
        Avail     ----
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 4 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 4 and 5, and go to step 6 to verify the card status.

4. Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

5. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----  OOS-MT-DSBLD  AVAIL  ---
ALARM STATUS = * 0236 REPT-LKS:not aligned
UNAVAIL REASON = NA
Command Completed.
```

6. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD VERSION  TYPE  APPL  PST  SST  AST
1201 114-000-000 DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS   = No Alarms.
BPDCM GPL     = 002-102-000
IMT BUS A      = Conn
IMT BUS B      = Conn
SIGNALING LINK STATUS
SLK  PST  LS  CLLI
A    IS-NR  nc001  -----
```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 7 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 7 and 8, and go to step 9.

7. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

8. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE  APPL    PST      SST      AST
1201  114-000-000    DCM   SS7IPGW IS-NR      Active    -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----
```

Command Completed.

NOTE: If the defrouter parameter is not specified in step 10, skip step 9 and go to step 10.

9. Verify that the IP address of either Ethernet A or B (the address whose network portion matches the network portion of the **defrouter** parameter value to be used in step 10) is in the IP link table by entering the **rtrv-ip-lnk** command with the card location specified in this procedure.

For this example, enter this command.

rtrv-ip-lnk: loc=1201

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  PORT IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A    192.1.1.10    255.255.255.0  ----   ---    DIX      YES   NO
1201  B    -----      -----      ----   ---    DIX      YES   NO
```

If the network portion of the IP address specified by the **defrouter** value does not match the network portions of either IP address displayed in this step, perform one of these actions:

- Choose another value for the **defrouter** parameter, making sure that the network portion of the new IP address matches the network portion of one of the IP addresses displayed in this step.
- Perform the [Configuring an IP Link](#) procedure and change one of the IP addresses shown in this step so that the network portion of the new IP address changed in the [Configuring an IP Link](#) procedure matches the network portion of the IP address value for the **defrouter** parameter.

10. Change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

For this example, enter this command.

chg-ip-card: loc=1201:srchordr=local:dnsa=192.1.1.40 :domain=nc.tekelec.com

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
CHG-IP-CARD: MASP A - COMPLTD
```

11. Verify the new IP parameters associated with the IP card that was changed in step 10 by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM
```

NOTE: If step 7 was not performed, skip steps 12 and 13, and go to step 14.

12. Allow the IP card that was inhibited in step 7 by using the **alw-card** command.

For example, enter this command.

alw-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

13. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000 DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST        LS      CLLI
A     IS-NR      nc001    -----
```

Command Completed.

NOTE: If step 4 was not performed, skip steps 14 and 15, and go to step 16.

14. Activate the signaling link from step 4 using the **act-sl** command.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a


This message should appear.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----   IS-NR
          Avail     ----
Command Completed.
```


16. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-8. Changing an IP Card





Adding an IP Route

This procedure is used to add an IP route to the database using the **ent-ip-rte** command.

The **ent-ip-rte** command uses these parameters.

:loc – The location of the IP card that the IP route will be assigned to.

:dest – The IP address of the remote host or network.

:submask – The subnet mask of the destination IP address.

:gtwy – The IP address of the gateway or router that will send the IP data to its final destination.

There can be a maximum of 64 IP routes assigned to an IP card.

The EAGLE 5 ISS can contain a maximum of 1024 IP routes.

If the IP card specified by the **loc** parameter is a single-slot EDCM, the card may contain IP addresses for Ethernet A and B. If the IP card specified by the **loc** parameter is a DCM, the card can contain an IP address for Ethernet A only.

The network portion of the IP address value of the **gtwy** parameter must be the same as the network portion of the IP addresses shown for either the A or B interfaces in the **rtrv-ip-card** output.

The value of the **dest** and **gtwy** parameters cannot be 127.x.x.x (the loopback address), 0.0.0.0, or the IP addresses of the A or B interfaces on the IP card, and cannot be assigned to another IP card.

If the **dest** parameter value represents a host IP address, the value for the **submask** parameter must be 255.255.255.255. Otherwise, the **submask** parameter value identifies the network/host ID portions that must be entered when the **dest** parameter value represents a network address.

The submask is applied to the IP address which is being routed to see if it yields a route match. For example, if IP address 192.1.1.2 is being routed and the IP routing table contains these entries.

Table 4-7. Sample IP Routing Table

IP address	Submask	Gateway
191.1.0.0	255.255.0.0	192.168.110.250
192.0.0.0	255.0.0.0	192.168.110.251

IP routing occurs as follows:

1. The subnet mask of route 1 (255.255.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.1.0.0. IP address 192.1.0.0 does not match IP address 191.1.0.0 in the IP routing table, so the next route is chosen.
2. The subnet mask of route 2 (255.0.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.0.0.0 which matches the second route in the IP routing table, so this route is selected for routing this datagram.

See [Table 4-8](#) for the valid input values for the **submask** and **dest** parameter combinations.

Table 4-8. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0

Network Class	IP Network Address Range	Valid Subnet Mask Values
		255.224.0.0 255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.1.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **dest** parameter of the **ent-ip-rte** command, the subnet address that results from the **dest** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1301 128.252.10.5     255.255.255.255 140.188.13.33
1301 128.252.0.0       255.255.0.0      140.188.13.34
1301 150.10.1.1        255.255.255.255 140.190.15.3
1303 192.168.10.1      255.255.255.255 150.190.15.23
1303 192.168.0.0       255.255.255.0    150.190.15.24
```

IP Route table is (5 of 1024) 1% full

2. Display the IP cards in the database with the **rtrv-ip-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1212
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER 150.1.1.100
  DOMAIN    NC. TEKELEC. COM

LOC 1301
  SRCHORDR  SRVRONLY
  DNSA      140.188.13.10
  DNSB      140.190.15.28
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1303
  SRCHORDR  LOCAL
  DNSA      150.190.15.1
  DNSB      -----
  DEFROUTER 150.190.15.25
  DOMAIN    NC. TEKELEC. COM
```

If the required IP card is not shown in the **rtrv-ip-card** output, perform the [Adding an IPGWx Card](#) procedure to add the card to the database.

Perform the [Configuring an IP Link](#) procedure and make sure that the network portion of the IP addresses assigned for the A or B interfaces of the IP card is the same as the network portion of the IP address that will be assigned to the **gtwy** parameter of the IP route

NOTE: If a Class A or C IP address (see [Table 5-5](#)) will be specified for the **dest parameter in step 4, skip step 3 and go to step 4.**

3. The subnet address that results from the **dest** and **submask** parameter values of the **ent-ip-rte** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 4.

This is an example of the possible output if the E5IS feature is on.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0
```

Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 4.

4. Add the IP route to the database using the **ent-ip-rte** command.

For this example, enter this command.

```
ent-ip-
rte:loc=1212:dest=132.10.175.20:submask=255.255.255.255 :gtwy=150.1.1.5
0
```

When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command with the card location specified with the **ent-ip-rte** command in step 4.

For this example, enter these commands.

rtrv-ip-rte:loc=1212

This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20  255.255.255.255 150.1.1.50
IP Route table is (6 of 1024) 1% full
```


6. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-9. Adding an IP Route





Adding a Socket to an IPGWx Signaling Link

This procedure is used to add a socket to an IPGWx signaling link using the **ent-appl-sock** command. The combination of local host, local TCP port, remote host and remote TCP port defines an application socket.

The **ent-appl-sock** command uses these parameters.

:sname— The name assigned to the socket. Valid socket names can contain up to 15 alphanumeric characters where the first character is a letter and the remaining characters are alphanumeric characters. The **sname** parameter value is not case-sensitive.

:lhost – Local Hostname. The logical name assigned to the local host device. The local host name must be shown in the **LOCAL HOST** column of the **rtrv-ip-host** output. Local host names that contain dashes (-) must be enclosed in double quotes (“”).

:lport – The TCP port number for the local host.

:rhost – Remote Hostname. The logical name assigned to the remote host device. The remote host name does not have to be shown in the **rtrv-ip-host** output. If remote host name is shown in the **rtrv-ip-host** output, it must be shown in the **REMOTE HOST** column of the **rtrv-ip-host** output. Remote host names that contain dashes (-) must be enclosed in double quotes (“”).

:rport – The TCP port number of the remote host.

:link – The signaling link on the IPGWx card. Only the link=a parameter can be specified in this procedure.

NOTE 1: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

NOTE: If the ITU National and International Spare Point Code Support feature is enabled, the socket cannot reference a card running the IPGWI application. Enter the **rtrv-ctrl-feat:partnum=893013601** command to verify whether or not the ITU National and International Spare Point Code Support feature is enabled. If the ITU National and International Spare Point Code Support feature is enabled, and the IP connection is being assigned to a card running the IPGWI application, the IP connection must be an IETF association. Perform the [Adding an M2PA Association](#) or the [Adding an M3UA or SUA Association](#) procedures to add the IP connection to the database.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 22 SCTP association to application server assignments, the maximum number of TALI sockets the IPGWx card can support is 28. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** and **rtrv-as:aname=<association name>** commands.

Table 4-9. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50
25	2	0	50
0	0	50	50
22	1	28	50
11	2	28	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

The socket name must be unique (not already used).

The socket table, which contains both the socket and association data, contains fields whose values are not assigned using the **ent-appl-sock** command. When a socket is added to the database, these fields receive their default values. If a different value is desired, the **chg-appl-sock** command must be used. These fields and their default values are:

open=no	dcmps=10
alw=no	rexmit=fixed
server=yes	rtt=60

The value of the **lhost** and **rhost** parameters is a text string of up to 60 characters, with the first character being a letter. The command line on the terminal can contain up to 150 characters. If the host name is too long to fit on the **ent-appl-sock** command line, go to the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure to complete the entry of the host name.

The IP address of the local host (**lhost** parameter) must be shown in the **rtrv-ip-lnk** output.

The signaling link being assigned to the socket must be in service. This state is shown in the **rept-stat-slk** output with the entries **IS-NR** in the **PST** field and **Avail** in the **SST** field.

The B Ethernet interface of the IP card can be used only if the IP card is a single-slot EDCM.

If the socket is being activated in this procedure with the **chg-appl-sock** command, the socket must contain values for the **lhost**, **lport**, **rhost**, and **rport** parameters.

Canceling the RTRV-APPL-SOCK Command

Because the **rtrv-appl-sock** command used in this procedure can output information for a long period of time, the **rtrv-appl-sock** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** command was entered, from another terminal other than the terminal where the **rtrv-appl-sock** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME kchl11201
  LINK      A
  LHOST     ipnode1-1201
  RHOST     kc-hlr1
  LPORT     7000          RPORT    7000
  SERVER    YES          DCMPS     1
  REXMIT    FIXED        RTT       60
  OPEN      YES          ALW       YES

SNAME sock1
  LINK      A
  LHOST     IPNODE2-1205
  RHOST     remotehost1
  LPORT     1024          RPORT    2048
  SERVER    YES          DCMPS     10
  REXMIT    FIXED        RTT       60
```

```

OPEN      YES      ALW      YES
SNAME sock2
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost2
LPORT     2000      RPORT     2000
SERVER    YES      DCMPS     10
REXMIT    FIXED    RTT       60
OPEN      YES      ALW      YES

```

IP Appl Sock/Assoc table is (5 of 4000) 1% full

2. Display the IP links in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```

rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A    192.1.1.10      255.255.255.128  HALF    10     802.3    NO    NO
1201  B    -----          -----          HALF    10     DIX      NO    NO
1203  A    192.1.1.12      255.255.255.0   ----    ---    DIX      YES   NO
1203  B    -----          -----          HALF    10     DIX      NO    NO
1205  A    192.1.1.14      255.255.255.0   FULL    100    DIX      NO    NO
1205  B    -----          -----          HALF    10     DIX      NO    NO
2101  A    192.1.1.20      255.255.255.0   FULL    100    DIX      NO    NO
2101  B    -----          -----          HALF    10     DIX      NO    NO
2103  A    192.1.1.22      255.255.255.0   FULL    100    DIX      NO    NO
2103  B    -----          -----          HALF    10     DIX      NO    NO
2105  A    192.1.1.24      255.255.255.0   FULL    100    DIX      NO    NO
2105  B    -----          -----          HALF    10     DIX      NO    NO
2205  A    192.1.1.30      255.255.255.0   FULL    100    DIX      NO    NO
2205  B    -----          -----          HALF    10     DIX      NO    NO
2207  A    192.1.1.32      255.255.255.0   FULL    100    DIX      NO    NO
2207  B    -----          -----          HALF    10     DIX      NO    NO
2213  A    192.1.1.50      255.255.255.0   FULL    100    DIX      NO    NO
2213  B    -----          -----          HALF    10     DIX      NO    NO
2301  A    192.1.1.52      255.255.255.0   FULL    100    DIX      NO    NO
2301  B    -----          -----          HALF    10     DIX      NO    NO

```

If an IP link containing the required IP address is shown in the **rtrv-ip-lnk** output, go to step 3.

If an IP link containing the required IP address is not shown in the **rtrv-ip-lnk** output, add the IP link using the [Configuring an IP Link](#) procedure. After the IP link is added, perform the [Adding an IP Host](#) procedure to assign this IP address to a local host name. After the local host name has been added, skip step 3 and go to step 4.

3. Verify that the local host name to be assigned to the socket is in the database by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1-1201
192.1.1.12    IPNODE1-1203
192.1.1.14    IPNODE1-1205
192.1.1.20    IPNODE2-1201
192.1.1.22    IPNODE2-1203
192.1.1.24    IPNODE2-1205
192.1.1.30    KC-HLR1
192.1.1.32    KC-HLR2
192.1.1.50    DN-MS1
192.1.1.52    DN-MS2

REMOTE IPADDR  REMOTE HOST
150.1.1.5      NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

```

IP Host table is (11 of 512) 2% full

If the required hostname is not shown in the **rtrv-ip-host** output, add the IP host name with the IP address shown in step 2 by performing the [Adding an IP Host](#) procedure.

4. Display the application running on the IP card shown in step 2 using the **rept-stat-card** command specifying the location of the IP card.

For this example, enter this command.

rept-stat-card: loc=1203

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      GPL      PST      SST      AST
1203  114-000-000   DCM      SS7IPGW  IS-NR      Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT  BUS A        = Conn
IMT  BUS B        = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----
```

Command Completed.

NOTE: If the local host value being used in this procedure was added in step 3, skip steps 5, 6, and 7, and go to step 8.

5. Display the sockets assigned to the local host that will be assigned to the socket being configured in this procedure by entering the **rtrv-appl-sock** command with the **lhost** parameter.

For this example, enter this command.

rtrv-appl-sock: lhost=IPNODE2-1203

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME sock1
LINK      A
LHOST     IPNODE2-1203
RHOST     remotehost1
LPORT     1024      RPORT     2048
SERVER    YES       DCMPS     10
REXMIT    FIXED     RTT       60
OPEN      YES       ALW       YES

SNAME sock2
LINK      A
LHOST     IPNODE2-1203
RHOST     remotehost2
LPORT     2000      RPORT     2000
SERVER    YES       DCMPS     10
REXMIT    FIXED     RTT       60
OPEN      YES       ALW       YES
```

IP Appl Sock/Assoc table is (5 of 4000) 1% full

6. Display the associations assigned to the local host that will be assigned to the socket being configured in this procedure by entering the **rtrv-assoc** command with the **lhost** parameter.

For this example, enter this command.

rtrv-assoc: lhost=IPNODE2-1203

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
```

ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW
assoc1	1203	A	A	M3UA	2048	2048	YES	YES
assoc2	1203	A	A	SUA	3000	3000	YES	YES

IP Appl Sock/Assoc table is (5 of 4000) 1% full
 Assoc Buffer Space Used (32 KB of 3200 KB) on LOC = 1205

7. Display the application servers that the associations shown in step 6 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 6.

For this example, enter these commands.

rtrv-as:aname=assoc1

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE 2000       assoc1

as4          LOADSHARE 2000       assoc1

as6          LOADSHARE 2000       assoc1
```

AS Table is (6 of 250) 1% full

rtrv-as:aname=assoc2

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as2          LOADSHARE 2000       assoc2

as3          LOADSHARE 2000       assoc2

as5          LOADSHARE 2000       assoc2
```

AS Table is (6 of 250) 2% full

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets and SCTP association to application server assignments is less than 50, go to step 8.

If the number of TALI sockets and SCTP association to application server assignments is 50, the local host value cannot be used in this procedure.

Repeat steps 2 and 3 and select another IP link and IP host to use in this procedure or add a new IP link using the [Configuring an IP Link](#) procedure. After the new IP link is added, perform the [Adding an IP Host](#) procedure address to a new local host name. After the new local host name as been added, go to step 8.

NOTE: If the card's application is SS7IPGW, shown in the application column in the rept-stat-card output in step 4, skip step 8 and go to step 9.

8. Display the status of the ITU National and International Spare Point Code Support feature by entering the **rtrv-ctrl-feat** command with the ITU National and International Spare Point Code Support feature part number.

Enter this command.

rtrv-ctrl-feat:partnum=893013601

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Spare Point Code Support	893013601	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ITU National and International Spare Point Code Support feature is not enabled, go to step 13.

If the ITU National and International Spare Point Code Support feature is enabled, the remainder of this procedure cannot be performed. A socket cannot be added to the database if the application running on the card containing the signaling link is IPGWI and the ITU National and International Spare Point Code Support feature is enabled. Perform the [Adding an M2PA Association](#) or the [Adding an M3UA or SUA Association](#) procedures to add the IP connection to the database.

9. Add the socket to the database by entering the **ent-appl-sock** command with these mandatory parameters:

:sname = the socket name

:lhost = the local host name from step 3

and with at least one of these optional parameters:

:lport = the local port ID, from 1024 to 65535

:rhost = the remote host name

:rport = the remote port ID, from 1024 to 65535

:link = a.

NOTE 1: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

NOTE: See [Flowchart 4-10](#) (Sheet 4) for the rules that apply to the **ent-appl-sock** command.

For example, enter this command.

```
ent-appl-sock:sname=kchlr11203:lhost="ipnode-1203" :lport=7005:rhost="kc-hlr1":rport=7005:link=a
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-APPL-SOCK: MASP A - COMPLTD
```

NOTE: If the socket added in step 9 is not being activated in this procedure, skip step 10 and go to step 11.

10. Activate the socket added in step 9 by entering the **chg-appl-sock** command with the socket name specified in step 9 and the **open=yes** and **alw=yes** parameters.

For example, enter this command.

chg-appl-sock:sname=kchlr11203:open=yes:alw=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

11. Verify the new socket information in the database by entering the **rtrv-appl-sock** command with the socket name specified in step 9.

For this example, enter this command.

rtrv-appl-sock:sname=kchlr11203

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SNAME kchlr11203
LINK A
LHOST ipnode1-1203
RHOST kc-hlr1
LPORT 7005          RPORT 7005
SERVER YES          DCMPS 10
REXMIT FIXED        RTT 60
OPEN YES            ALW YES
```


IP Appl Sock/Assoc table is (3 of 4000) 1% full


12. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-10. Adding a Socket to an IPGWx Signaling Link







Adding a Routing Key Containing a Socket

This procedure is used to add a routing key containing a socket to the database, or add a socket to an existing routing key containing sockets using the **ent-appl-rtkey** command.

A routing key defines a filter that checks the specified values in an incoming SS7 MSU to determine which, if any, socket or association receives the MSU. For more information about static routing keys, see [Understanding Routing for SS7IPGW and IPGWI Applications](#).

The **ent-appl-rtkey** command uses these parameters.

:dpc/dpca/dpci/dpcn/dpcn24 – The destination point code value that is used to filter incoming MSUs. This parameter must not specify a cluster route. The destination point code of the routing key cannot be the APC of an IPGWx linkset or the SAPC assigned to an IPGWx linkset.

:opc/opca/opci/opcn/opcn24 – The originating point code value that is used to filter incoming MSUs. This parameter must not specify a cluster route. This parameter is valid only when the **si** parameter value is set to **4**, **5**, or **13**. This parameter is required if **si=4, 5, or 13** and **type=full**.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value from 0 to 15, or for selected service indicator values, a text string can be used instead of numbers. [Table 4-10](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 4-10. Service Indicator Text String Values

Service Indicator Value	Text String
0	snm
1	regtest
2	spltst
3	sccp
4	tup
5	isup
13	qbicc

:ssn – The subsystem value that is used to filter incoming MSUs. The **ssn** parameter is only valid when the **si** parameter value is set to **3** or **sccp**.

:sname – The name of the socket that will receive the incoming MSU if the filter key values (**dpc**, **si**, **ssn**) match the values in the incoming MSU.

:cics – The starting circuit identification code that is used to filter incoming MSUs. When specified with **cice**, **cics** identifies the start of the range of circuit identification codes. The **cics** parameter is valid only when the **si** parameter value is set to **4**, **5**, or **13**. The **cics** is required if **si=4, 5, or 13** and **type=full**.

:cice – The ending circuit identification code that is used to filter incoming MSUs. When specified with **cics**, **cice** identifies the end of the range of circuit identification codes. The **cice** parameter is valid only when the **si** parameter value is set to **4**, **5**, or **13**. The **cice** is required if **si=4, 5, or 13** and **type=full**.

:type – The routing key type – Identifies the type of routing key that is being entered and used to route message signaling units (MSUs). One of three values, **full/partial/default**, can be specified for the type parameter (see [Table 4-11](#)). If **type** is not explicitly specified, **type = full** is assumed.

The **ent-appl-rtkey** command also contains these parameters which cannot be used in this procedure.

:asname – The application server name

:rcontext – The routing context parameter.

These parameters and their use are discussed in more detail in the [Adding a Routing Key Containing an Application Server](#) procedure.

Socket names are shown in the **rtrv-appl-sock** output.

A routing key can be associated with up to 16 socket names . There is a maximum of 1000 routing keys allowed for each EAGLE 5 ISS (if there are any dual-slot DCM cards), or 2500 routing keys allowed for each EAGLE 5 ISS (if all cards running the **ss7ipgw** or **ipgwi** application are single-slot EDCMs or E5-ENET cards). E5-ENET cards do not support sockets as IP connections.

The number of static routing keys is limited by the **srkq** parameter that was specified on the **chg-sg-opts** command.

Routing keys are associated only with the **ss7ipgw** or **ipgwi** application.

Group codes are required for 14-bit ITU-N point codes (DPCN/OPCN) when the Duplicate Point Code feature is enabled.

The starting circuit identification code must be less than or equal to the ending circuit identification code.

The ISUP routing over IP feature must be on in order to enter a routing key with these parameters: **dpc**, **si**, **opc**, **cics**, and **cice**. The **IPISUP** field in the **rtrv-feat** command output shows whether or not this feature is on.

When a routing key is added to the database, the **pstncat** and **pstnid** parameter values are set to zero and the **norm** parameter is set to **no**. These values cannot be changed with the **ent-appl-rtkey** command. To change these values, go to the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure.

The parameter combinations used by the **ent-appl-rtkey** command are based on the type of routing key and the service indicator value in the routing key. The parameter combinations are shown in [Table 4-11](#) .

Table 4-11. Routing Key Parameter Combinations for Adding a Routing Key Containing a Socket

Full Routing Key - SI=3 (SCCP)	Partial Routing Key - SI=3 (SCCP)	Full Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key - Other SI Values	Partial Routing Key - Other SI Values	Default Routing Key
dpc ^{1, 2}	sname	dpc ^{1, 2}	sname	dpc ^{1, 2}	sname	sname
si=3 ⁴	type=partial	si=4, 5, 13 ⁴	type=partial	si=value other than 3, 4, 5, 13 ⁴	type=partial	type=default
ssn	dpc ^{1, 2, 3}	opc ^{1, 2}	dpc ^{1, 2, 3}	sname	dpc ^{1, 2, 3}	
type=full	si=3 ^{3, 4}	cics ^{5, 6, 7, 8, 9}	si=4, 5, 13 ^{3, 4}	type=full	si=value other than 3, 4, 5, 13 ^{3, 4}	
sname		cice ^{5, 6, 7, 8, 9}	opc ^{1, 2, 3}			
		type=full				
		sname				

Notes:

1. The **dpc** and **opc** parameters can be either an ANSI point code (**dpca**, **opca**), ITU-I point code (**dpci**, **opci**), 14-bit ITU-N point code (**dpcn**, **opcn**), or 24-bit ITU-N point code (**dpcn24**, **opcn24**). If the **dpc** and **opc** parameters are specified, the **dpc** and **opc** must be the same type of point code. For example, if the **dpca** parameter is specified, the OPC is specified with the **opca** parameter. ITU-I and 14-bit ITU-N spare point codes cannot be assigned to a routing key containing a socket.

Full Routing Key - SI=3 (SCCP)	Partial Routing Key - SI=3 (SCCP)	Full Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key - Other SI Values	Partial Routing Key - Other SI Values	Default Routing Key
2. If the ITU National Duplicate Point Code feature is on, the values for the dpcn and opcn parameters must have group codes assigned to them. The field ITUDUPPC in the rtrv-feat command output shows whether or not the ITU National Duplicate Point Code feature is on. If group codes are specified for ITU-N DPC and OPC, the groups codes must be the same. 3. These parameters are optional for partial routing keys, but at least one these parameters must be specified with the ent-appl-rtkey command. 4. Text strings can be used in place of some numerical service indicator values. See Table 4-10 for a list of these text strings. 5. When the service indicator parameter value equals 4 and an ANSI dpc is specified, the opc, cics, and cice parameters cannot be used. If the service indicator parameter value equals 4 and an ITU dpc is specified, the opc, cics, and cice parameters are required. 6. If the service indicator parameter (si) value is 4, the values of the cics and cice parameters is from 0 to 4095. 7. If the service indicator parameter (si) value is 5 and the point code in the routing key is either an ITU-I, 14-bit ITU-N, or 24-bit ITU-N point code, the values of the cics and cice parameters is from 0 to 4095. If the point code in the routing key is an ANSI point code, the values of the cics and cice parameters is from 0 to 16383. 8. If the service indicator parameter value is 13, the values of the cics and cice parameters is from 0 to 4294967295. 9. The CIC range, defined by the cics and cice parameters, cannot overlap the CIC range in an existing routing key.						

Canceling the RTRV-APPL-SOCK and RTRV-APPL-RTKEY Commands

Because the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** or **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** or **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** or **rtrv-appl-rtkey** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

- Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105

```

----- 005-005-001 5 TALI ----- FULL 1105
----- 006-006-001 5 TALI ----- FULL 1107
----- 006-006-001 5 TALI ----- FULL 1107

RCONTEXT DPCI SI ADPTR ASNAME TYPE LOC
----- s-6-006-6 3 TALI ----- FULL STATIC
----- 6-006-7 6 TALI ----- FULL STATIC
----- s-6-006-6 5 TALI ----- FULL STATIC
----- s-6-006-6 5 TALI ----- FULL STATIC

RCONTEXT DPCN SI ADPTR ASNAME TYPE LOC
RCONTEXT DPCN24 SI ADPTR ASNAME TYPE LOC
RCONTEXT DPC SI ADPTR ASNAME TYPE LOC
----- ***** ** TALI ----- DEFAULT STATIC

```

```

STATIC Route Key table is (7 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full

```

```

STATIC Route Key Socket Association table is (7 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full

```

If the routing key will be assigned to a new DPC, skip step 2 and go to step 3.

The database can contain only one default routing key. If the **rtrv-appl-rtkey** output contains a default routing key, a default routing key cannot be added in this procedure. Continue this procedure with step 2 to add either a full or partial routing key with the desired socket. If the **rtrv-appl-rtkey** output in step 1 does not show a default routing key, skip step 2 and go to step 3.

2. Display the specific routing key information for the routing key that the new routing key will be added to by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and the **DPC** value shown in the **rtrv-appl-rtkey** output in step 1.

For this example, enter this command.

rtrv-appl-rtkey:dpc=123-234-123:display=all

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT DPC SI SSN OPC CICS CICE LOC
----- 123-234-123 5 --- 122-124-125 1 1000 STATIC

ADPTR TYPE PSTNCAT PSTNID NORM DUP
TALI FULL 0 0 N N

SNAMES
socket31

RCONTEXT DPC SI SSN OPC CICS CICE LOC
----- 123-234-123 5 --- 100-100-100 1 50 STATIC

ADPTR TYPE PSTNCAT PSTNID NORM DUP
TALI FULL 0 0 N N

SNAMES
socket31

```

```

STATIC Route Key table is (7 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full

```

```

STATIC Route Key Socket Association table is (7 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full

```

If this routing key has an application server assigned to it, another socket cannot be assigned to the routing key. Continue this procedure with step 3 and add a new routing key with a new DPC and the desired socket.

NOTE: If the routing key being added will contain ITU-I or 14-bit ITU-N spare point codes, a socket cannot be assigned to the routing key. Only an application server can be assigned to a routing key that contains ITU-I or 14-bit ITU-N spare point codes. To add a new routing key with a socket, continue with this procedure at step 3 and add a new routing key with a new DPC, but not an ITU-I or 14-bit ITU-N spare point code, and the desired socket. To add a new routing key with an ITU-I or 14-bit ITU-N spare point code, perform the [Adding a Routing Key Containing an Application Server](#) procedure.

3. Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME socket31
  LINK      A
  LHOST     ipnode1-1201
  RHOST     kc-hlr1
  LPORT     7000          RPORT    7000
  SERVER    YES          DCMPS    1
  REXMIT    FIXED        RTT      60
  OPEN      YES          ALW      NO

SNAME kchlr11203
  LINK      A
  LHOST     ipnode1-1203
  RHOST     kc-hlr1
  LPORT     7005          RPORT    7005
  SERVER    YES          DCMPS    10
  REXMIT    FIXED        RTT      60
  OPEN      YES          ALW      YES
```

IP Appl Sock/Assoc table is (2 of 4000) 1% full

If the required socket is shown in the **rtrv-appl-sock** output, and a default routing key is being added, skip steps 4 through 7, and go to step 8.

If the required socket is not shown in the **rtrv-appl-sock** output, and a default routing key is being added, perform the [Adding a Socket to an IPGWx Signaling Link](#) procedure to add the socket. After the socket has been added, skip steps 4 through 7, and go to step 8.

If a partial or full routing key is being added, go to step 4.

4. The DPC of the routing key cannot be the APC of an IPGWx linkset or an SAPC assigned to an IPGWx linkset.

Display the names of the IPGWx linksets by entering the **rept-stat-iptps** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

IP TPS USAGE REPORT
```

	THRESH	CONFIG		TPS	PEAK	PEAKTIMESTAMP

SYSTEM						
RLGHNCXA03W	100%	30000	TX:	7200	7600	05-02-10 11:40:04
			RCV:	7200	7600	05-02-10 11:40:04

LSN						
LSGW1101	80%	10000	TX:	7200	7600	05-02-10 11:40:04
			RCV:	7200	7600	05-02-10 11:40:04
LSGW1103	80%	10000	TX:	6700	7600	05-02-10 11:40:04
			RCV:	6500	7600	05-02-10 11:40:04

```
LSGW1105      80%   10000 TX:   7300   7450 05-02-10 11:40:04
                  RCV:   7300   7450 05-02-10 11:40:04
-----
```

Command Completed.

5. Display the IPGWx linksets shown in the **rept-stat-iptps** output in step 4 using the **rtrv-ls** command and specifying the name of the linkset shown in step 4.

For this example, enter these commands.

rtrv-ls:lsn=lsgw1101

This is an example of the possible output

```
rlghncxa03w 06-10-28 16:31:35 GMT EAGLE5 36.0.0
```

```

LSN          APCA  (SS7)  SCRNL3T SLT          GWS GWS GWS
lsgw1101     240-020-000  scr1 1  1  yes A  1  off off off yes  off
IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
yes      ----- 10000 70    % 70    % CdPA

```

```

LOC LINK SLC TYPE      L2T      L1          PCR PCR
SET BPS  MODE TSET  ECM  N1  N2
LP          ATM
LOC LINK SLC TYPE      SET BPS  TSEL          VCI  VPI  LL
LP          ATM
LOC LINK SLC TYPE      SET BPS  TSEL          VCI  VPI  CRC4 SI SN
LOC LINK SLC TYPE      IPLIML2
LOC LINK SLC TYPE
1101 A      0  SS7IPGW

```

```

LOC LINK SLC TYPE      L2T      L1          PCR PCR  E1  E1
SET BPS  ECM  N1  N2  LOC  PORT TS
LOC LINK SLC TYPE      L2T      L1          PCR PCR  T1  T1
SET BPS  ECM  N1  N2  LOC  PORT TS

```

Link set table is (13 of 1024) 1% full

rtrv-ls:lsn=lsgw1103

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
```

```

LSN          APCN  (SS7)  SCRNL3T SLT          GWS GWS GWS
lsgw1103     2968          none 1  1  no  A  1  off off off ---  off
CLLI          TFATCABMLQ  MTPRSE  ASL8  SLSRSB  MULTGC  ITUTFR
----- 1  ---  ---  1  no  off

```

```

IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
yes      ----- 10000 70    % 70    % CdPA
LOC LINK SLC TYPE      L2T      L1          PCR PCR
SET BPS  MODE TSET  ECM  N1  N2
LP          ATM
LOC LINK SLC TYPE      SET BPS  TSEL          VCI  VPI  LL
LP          ATM
LOC LINK SLC TYPE      SET BPS  TSEL          VCI  VPI  CRC4 SI SN
LOC LINK SLC TYPE      IPLIML2

```

```

LOC LINK SLC TYPE
1103 A 0 IPGWI

LOC LINK SLC TYPE L2T SET BPS ECM PCR N1 PCR N2 E1 LOC E1 PORT TS

LOC LINK SLC TYPE L2T SET BPS ECM PCR N1 PCR N2 T1 LOC T1 PORT TS

SAPCI
1-010-1

```

Link set table is (13 of 1024) 1% full.

rtrv-ls:lsn=lsgw1105

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

```

LSN APCI (SS7) SCRNL3T SLTGWS GWS GWS
lsgw1105 2-154-0 none 1 1 no A 1 LNKS ACT MES DIS SLSCI NIS
off off off --- off

CLLI TFATCABMLQ MTPRSE ASL8 SLSRSB MULTGC ITUTFR
----- 1 --- --- 1 no off

IPGWAPC MATELSN IPTPS LSUSEALM SLKUSEALM GTTMODE
yes ----- 10000 70 % 70 % CdPA

LOC LINK SLC TYPE L2T SET BPS L1 MODE TSET ECM PCR N1 PCR N2

LOC LINK SLC TYPE LP SET BPS ATM TSEL VCI VPI LL

LOC LINK SLC TYPE LP SET BPS ATM TSEL VCI VPI CRC4 SI SN E1ATM

LOC LINK SLC TYPE IPLIML2

LOC LINK SLC TYPE
1105 A 0 IPGWI

LOC LINK SLC TYPE L2T SET BPS ECM PCR N1 PCR N2 E1 LOC E1 PORT TS

LOC LINK SLC TYPE L2T SET BPS ECM PCR N1 PCR N2 T1 LOC T1 PORT TS

SAPCN
5823

```

Link set table is (13 of 1024) 1% full.

If the DPC of the routing key is shown in the **rtrv-ls** outputs in this step, choose another DPC value for the routing key that is not shown in the **rtrv-ls** outputs in this step.

If the required socket is shown in the **rtrv-appl-sock** output in step 3, continue this procedure with step 6.

If the required socket is not shown in the **rtrv-appl-sock** output in step 3, perform the [Adding a Socket to an IPGWx Signaling Link](#) procedure to add the socket. After the socket has been added, continue this procedure with step 6.

If a default routing key is being added to the database, or if the SI value of the routing key being added is a value other than 4, 5, or 13, skip steps 6 and 7, and go to step 8.

6. Verify that the ISUP Routing over IP feature is on, by entering the **rtrv-feat** command.

If the ISUP Routing over IP feature is on, the **IPISUP** field should be set to **on**. For this example, the ISUP Routing over IP feature is off.

NOTE: The **rtrv-feat command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.**

If the ISUP Routing over IP feature is on, skip step 7 and go to step 8.

7. Turn the ISUP Routing over IP feature on by entering this command.

chg-feat:ipisup=on

NOTE: Once the ISUP Routing over IP feature is turned on with the **chg-feat command, it cannot be turned off.**

The ISUP Routing over IP feature must be purchased before you turn this feature on with the **chg-feat command. If you are not sure if you have purchased the ISUP Routing over IP feature, contact your Tekelec Sales Representative or Account Representative.**

When the **chg-feat** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

8. Add a routing key entry to the database by entering the **ent-appl-rtkey** command.

The parameters required for the **ent-appl-rtkey** command are determined by the type of routing key being added and the service indicator value in the routing key. See [Table 4-11](#) for the parameter combinations that can be used for the type of routing key being added to the database.

NOTE: If the DPC and OPC values are ITU-N point codes, these point codes must have group codes assigned to them if the ITU National Duplicate Point Code feature is on. The ITUDUPPC field in the **rtrv-feat command executed in step 6 shows whether or not the ITU National Duplicate Point Code feature is on.**

A socket can be added to an existing routing key if the **DPC** value specified in this procedure must be same as the **DPC** value shown in the existing routing key.

For this example, a full ISUP routing key is being added to the database. Enter this command.

ent-appl-rtkey:dpca=001-002-003:si=5:opca=100-100-100:cics=1 :cice=50:sname=socket5:type=full

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-APPL-RTKEY: MASP A - COMPLTD
```

9. Verify the new routing key information in the database by entering the **rtrv-appl-rtkey** command with the socket name (**sname**) specified in step 8 and the **display=all** parameter.

For this example, enter this command.

rtrv-appl-rtkey:sname=socket5:display=all

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT   DPC           SI SSN OPC           CICS      CICE      LOC
----- 001-002-003    5 --- 100-100-100    1         50      STATIC

      ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
      TALI   FULL           0         0    N    N

      SNAMEs
      socket5

```

```

STATIC Route Key table is ( 8 of 2000) 1% full
1105  Route Key table is ( 2 of 500) 1% full
1107  Route Key table is ( 2 of 500) 1% full

```

```

STATIC Route Key Socket Association table is (8 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full

```

If a socket was assigned to the routing key added in this procedure and you wish to add other sockets to the routing key, repeat this procedure from step 3.

If no other sockets are to be added to the routing key, go to step 10.

10. If you wish to change the PSTN presentation information in the routing key that was added in step 8, go to the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure. Do not perform step 11.

If you do not wish to change the PSTN presentation information in the routing key, skip this step and go to step 11.

11. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


Flowchart 4-11. Adding a Routing Key Containing a Socket











Increasing the System-Wide IPGWx Signaling TPS

This procedure is used with **IPGWx** applications (IP cards running either the **ss7ipgw** or **ipgwi** applications) and increases the system-wide IP transactions per second (TPS), using the **enable-ctrl-feat** command.

The EAGLE 5 ISS is shipped with a default TPS rate of 200 transactions per second.

The **enable-ctrl-feat** command uses these parameters.

:partnum – The Tekelec-issued part number associated with the controlled feature. The part number is a 9-digit number, not including dashes; the first three digits must be 893 (that is, 893xxxxxx, where x is a numeric value). [Table 4-12](#) shows the part numbers that can be used with this procedure.

: fak – The feature access key obtained from the Tekelec. The feature access key contains 13 alphanumeric characters and is not case sensitive.

NOTE 1: The number of system-wide IP transactions per second cannot be enabled with a temporary feature access key.

NOTE: If you do not have the feature access key, you can obtain it from your Tekelec Sales Representative or Account Representative.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent - serial - num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

The TPS rate specified in this procedure must be greater than the current TPS rate.

Table 4-12. System-Wide IPGWx Signaling TPS Part Numbers

Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS
893-0128-01	200		893-0128-21	34,000		893-0128-41	74,000
893-0128-02	400		893-0128-22	36,000		893-0128-42	76,000
893-0128-03	600		893-0128-23	38,000		893-0128-43	78,000
893-0128-04	1,000		893-0128-24	40,000		893-0128-44	80,000
893-0128-05	2,000		893-0128-25	42,000		893-0128-45	82,000
893-0128-06	4,000		893-0128-26	44,000		893-0128-46	84,000
893-0128-07	6,000		893-0128-27	46,000		893-0128-47	86,000
893-0128-08	8,000		893-0128-28	48,000		893-0128-48	88,000
893-0128-09	10,000		893-0128-29	50,000		893-0128-49	90,000
893-0128-10	12,000		893-0128-30	52,000		893-0128-50	92,000
893-0128-11	14,000		893-0128-31	54,000		893-0128-51	94,000
893-0128-12	16,000		893-0128-32	56,000		893-0128-52	96,000

Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS
893-0128-13	18,000		893-0128-33	58,000		893-0128-53	98,000
893-0128-14	20,000		893-0128-34	60,000		893-0128-54	100,000
893-0128-15	22,000		893-0128-35	62,000		893-0128-55	102,000
893-0128-16	24,000		893-0128-36	64,000		893-0128-56	104,000
893-0128-17	26,000		893-0128-37	66,000		893-0128-57	106,000
893-0128-18	28,000		893-0128-38	68,000		893-0128-58	108,000
893-0128-19	30,000		893-0128-39	70,000		893-0128-59	110,000
893-0128-20	32,000		893-0128-40	72,000		893-0128-60	112,000

Procedure

1. Display enabled controlled feature information in the database by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012801	on	200
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the IPGWx Signaling TPS quantity is greater than 200, skip steps 2 through 5, and go to step 6. If the **rtrv-ctrl-feat** output shows only the IPGWx Signaling TPS feature with a quantity of 200 and the HC-MIM SLK Capacity feature with a quantity of 64, steps 2 through 5 must be performed.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Increase the system-wide IP transactions per second (TPS) by entering the **enable-ctrl-feat** command with the part number corresponding to the desired quantity (without the dashes), shown in [Table 4-12](#) , and the feature access key for the desired quantity.

For example, enter this command.

enable-ctrl-feat:partnum=893012814:fak=<feature access key>

NOTE 1: The number of system-wide IP transactions per second cannot be enabled with a temporary feature access key.

NOTE: If you do not have the feature access key, you can obtain it from your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP A - COMPLTD
```

7. Verify the new feature information in the database by entering the **rtrv-ctrl-feat** command with the part number specified in step 6.

For this example, enter this command.

rtrv-ctrl-feat:partnum=893012814

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				


The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 4-12. Increasing the IPGWx Signaling TPS





Removing TALI IPGWx Components

This section describes how to remove the following components from the database.

- An IPGWx Card – Perform the [Removing an IPGWx Card](#) procedure
- An IPGWx Signaling Link – Perform the [Removing an IPGWx Signaling Link](#) procedure
- An IP Host – Perform the [Removing an IP Host Assigned to an IPGWx Card](#) procedure
- An IP Route – Perform the [Removing an IP Route](#) procedure
- A Socket – Perform the [Removing a Socket that is Assigned to an IPGWx Signaling Link](#) procedure
- A Routing Key – Perform the [Removing a Routing Key Containing a Socket](#) procedure

Removing an IPGWx Card

Use this procedure to remove an IP card, a card running one of these applications: **ss7ipgw** or **ipgwi**, from the database using the **dlt-card** command.

The card cannot be removed if it does not exist in the database. Prior to removing the card from the database, the signaling links assigned to the card must be removed.



CAUTION: If the IPLIMx card is the last IP card in service, removing this card from the database will cause traffic to be lost.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-15 16:34:56 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM        SCCP
1102   TSM        GLS
1104   ACMENET    STPLAN
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI   lsn1           A    0    lsn2           B    1
1202   LIMV35     SS7GX25   lsn2           A    0
1203   LIMV35     SS7ANSI   lsn2           A    0    lsn1           B    1
1204   LIMATM     ATMANSI   atm2           A    0
1205   DCM        IPLIM     ipnode1        A    0    ipnode3        B    1
1207   DCM        IPLIM     ipnode2        A    0
1303   DCM        IPLIM     ipnode1        A    0    ipnode3        B    1
1305   DCM        IPLIM     ipnode4        A    0
```

Select a card whose application is either SS7IPGW or IPGWI.

Perform the [Removing an IPGWx Signaling Link](#) procedure to remove all the signaling links assigned to the card, shown in the **LINK** column of the **rtrv-card** output.

The card location is shown in the **CARD** field of the **rtrv-card** command output. No entries in the **LSET NAME**, **LINK**, and **SLC** columns mean that no signaling link is assigned to the card.

2. Remove the card from the database using the **dlt-card** command.

The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter these commands.

```
dlt-card:loc=1205
```

```
dlt-card:loc=1207
```

When these commands have successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-CARD: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-card** command and specifying the card that was removed in step 2.

For this example, enter these commands.

```
rtrv-card:loc=1205
```

```
rtrv-card:loc=1207
```

When these commands have successfully completed, this message appears.


```
E2144 Cmd Rej: Location invalid for hardware configuration
```

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-13. Removing an IPGWx Card



Removing an IPGWx Signaling Link

This procedure is used to remove an IPGWx signaling link from the database using the **dlt-slk** command. The **dlt-slk** command uses these parameters.

:loc – The card location of the IP card that the IP signaling link is assigned to.

:link – The signaling link on the card specified in the **loc** parameter.

:force – This parameter must be used to remove the last link in a linkset without having to remove all of the routes that referenced the linkset.

The **tfatcabmlq** parameter (TFA/TCA Broadcast Minimum Link Quantity), assigned to linksets, shows the minimum number of links in the given linkset (or in the combined link set in which it resides) that must be available for traffic. When the number of signaling links in the specified linkset is equal to or greater than the value of the **tfatcabmlq** parameter, the status of the routes that use the specified linkset is set to allowed and can carry

traffic. Otherwise, these routes are restricted. The value of the **tfatcabmlq** parameter cannot exceed the total number of signaling links contained in the linkset.

The **dlt-slk** command makes sure that the number of signaling links assigned to a linkset is greater than or equal to the value of the **tfatcabmlq** parameter. If the number of signaling links associated with a linkset drops below the value of the **tfatcabmlq** parameter for that linkset, the **tfatcabmlq** value for that linkset is automatically decremented. The value of the **tfatcabmlq** parameter for a specified linkset can be verified using the **rtrv-ls:lsn=<linkset name>** command specifying the name of the linkset. The **tfatcabmlq** parameter value is shown in the **tfatcabmlq** field of the **rtrv-ls** command output.

Canceling the RTRV-SLK Command

Because the **rtrv-slk** command used in this procedure can output information for a long period of time, the **rtrv-slk** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-slk** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-slk** command was entered, from another terminal other than the terminal where the **rtrv-slk** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link configuration using the **rtrv-slk** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
```

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	L1 MODE	TSET	ECM	PCR N1	PCR N2
1201	A	ls01	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1201	B	lsa1	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1202	B	ls02	0	LIMV35	2	64000	DTE	---	BASIC	---	-----
1203	A	ls03	0	LIMDS0	3	56000	---	---	BASIC	---	-----
1203	B	lsa2	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1204	B	ls01	1	LIMDS0	1	56000	---	---	BASIC	---	-----
1205	A	lsa3	0	LIMV35	4	64000	DCE	ON	BASIC	---	-----
1206	A	ls02	1	LIMV35	2	64000	DTE	---	BASIC	---	-----
1207	A	lsn1207a	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1207	B	lsn1207b	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1208	B	ls03	1	LIMDS0	3	56000	---	---	BASIC	---	-----
1212	A	ls04	0	LIMV35	4	64000	DTE	---	BASIC	---	-----
1213	B	ls05	0	LIMDS0	5	56000	---	---	BASIC	---	-----
1214	A	lsn1214a	0	LIMV35	2	64000	DTE	---	PCR	76	3800
1214	B	lsa3	1	LIMV35	4	64000	DCE	ON	BASIC	---	-----
1215	A	ls05	1	LIMDS0	5	56000	---	---	BASIC	---	-----
1301	B	ls06	0	LIMV35	6	56000	DTE	---	BASIC	---	-----
1304	B	ls06	1	LIMV35	6	56000	DTE	---	BASIC	---	-----
1308	A	ls06	2	LIMV35	6	56000	DTE	---	BASIC	---	-----
1311	A	ls01	2	LIMDS0	1	56000	---	---	BASIC	---	-----
1311	A1	ls05	2	LIMDS0	5	56000	---	---	BASIC	---	-----
1311	B	ls03	2	LIMDS0	3	56000	---	---	BASIC	---	-----
1311	B1	ls07	1	LIMDS0	7	56000	---	---	BASIC	---	-----
1313	A	ls07	0	LIMDS0	7	56000	---	---	BASIC	---	-----
1315	A	lsn5	0	LIMV35	11	64000	DTE	OFF	BASIC	---	-----

```

1317 A   lsi7           0 LIMV35 11 64000 DTE OFF BASIC --- -----

LOC LINK LSN          SLC TYPE      LP      ATM
1302 A   atmansi0     0 LIMATM  3 1544000 TSEL      VCI VPI LL
1305 A   atmansi1     0 LIMATM  4 1544000 INTERNAL 100 20  2
1318 A   atmansi0     1 LIMATM  9 1544000 LINE      150 25  4

LOC LINK LSN          SLC TYPE      LP      ATM      E1ATM
2101 A   atmitu1      0 LIME1ATM 5 2.048M TSEL      VCI VPI CRC4 SI SN
2105 A   atmitu1      1 LIME1ATM 5 2.048M LINE      35 15  ON  2 15

LOC LINK LSN          SLC TYPE      IPLIML2
2202 A   lsnlp1       0 IPLIM  SAALTALI
2205 A   lsnlp1       1 IPLIM  M2PA
2204 B   lsnlp2       0 IPLIM  M2PA
2213 A   lsnlp5       0 IPLIMI  M2PA
2215 A   lsnlp2       1 IPLIM  SAALTALI

LOC LINK LSN          SLC TYPE
2207 A   lsnlp3       0 SS7IPGW
2211 A   lsnlp4       0 IPGWI

```

```

LOC LINK LSN          SLC TYPE      L2T      PCR PCR E1 E1
LOC LINK LSN          SLC TYPE      SET BPS ECM N1 N2 LOC PORT TS

```

No Links Set Up.

```

LOC LINK LSN          SLC TYPE      L2T      PCR PCR T1 T1
LOC LINK LSN          SLC TYPE      SET BPS ECM N1 N2 LOC PORT TS

```

No Links Set Up.

SLK table is (31 of 1200) 6% full

- Any in-service IP connections on the signaling link being removed in this procedure must be placed out of service.

Have the far-end node for the signaling link being removed perform these actions:

- Place the TALI sockets in the NEA-FEP state.
- Place the M3UA or SUA associations in either the ASP-INACTIVE or ASP-DOWN state.

- Display the IP link associated with the card that the signaling link being removed the database is assigned to. Enter the **rtrv-ip-lnk** command with the card location of the signaling link being removed shown in step 1. For this example, enter this command.

rtrv-ip-lnk:loc=2207

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC PORT IPADDR      SUBMASK      DUPLEX  SPEED MACTYPE AUTO MCAST
2207 A   192.1.1.10   255.255.255.128 HALF    10    802.3  NO   NO
2207 B   -----

```

- Display the IP host information associated with the IP link by entering the **rtrv-ip-host** command with the IP address shown in step 3. For this example, enter these commands.

rtrv-ip-host:ipaddr=192.001.001.010

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1_2207

```

IP Host table is (11 of 512) 2% full

5. Display the sockets associated with the local host name shown in step 4 by entering the **rtrv-appl-sock** command. For this example, enter this command.

rtrv-appl-sock: lhost=ipnode1_2207

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_2207
LINK      A
LHOST     IPNODE1_2207
RHOST     KC_HLR2
LPORT     7000          RPORT     7001
SERVER    YES          DCMPS     1
REXMIT     FIXED       RTT        60
OPEN      YES          ALW        YES
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

NOTE: If the specified socket name is not in the database, the rtrv-appl-sock output shows no socket information.

6. Change the **open** and **alw** parameter values in the socket shown in step 5 using the **chg-appl-sock** command with the **open=no** and **alw=no** parameters, as necessary. For example, enter this command.

NOTE: If there is no socket shown in step 4, or the open and alw parameter values of the socket shown in step 4 are no, skip this step and go to step 6.

chg-appl-sock: sname=kc_hlr1_2207: open=no: alw=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

7. Display the associations associated with the local host name shown in step 5 by entering the **rtrv-assoc** command. For this example, enter this command.

rtrv-assoc: lhost=ipnode1_2207

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc1     2207 A    A    M3UA  1030  1030 YES  YES
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 2207

8. Change the value of the **open** and **alw** parameters to **no** by specifying the **chg-assoc** command with the **open=no** and **alw=no** parameters, as necessary. For this example, enter this command.

NOTE: If there is no association shown in step 6, or the open and alw parameter values of the association shown in step 6 are no, skip this step and go to step 8.

chg-assoc: aname=assoc1: open=no: alw=no

When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

9. Deactivate the link to be removed using the **dact-slk** command, using the output from step 1 to obtain the card location and **link** parameter value of the signaling link to be removed. For this example, enter these commands.

dact-slk:loc=2207:link=a

When each of these command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

10. Verify that the link is out of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-slk** command with the card location and **link** parameter values specified in step 9. For this example, enter these commands.

rept-stat-slk:loc=2207:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-23 13:06:25 GMT EAGLE5 36.0.0
SLK   LSN       CLLI       PST       SST       AST
2207,A ls04      ls04clli  OOS-MT    Unavail    ----
ALARM STATUS      = *   0235 REPT-LNK-MGTINH: local inhibited
UNAVAIL REASON    = LI
```

11. Place the card that contains the signaling link shown in step 10 out of service by entering the **rmv-card** command specifying the card location shown in step 10. For this example, enter this command.

rmv-card:loc=2207

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Card has been inhibited.
```

12. Verify that the card has been inhibited by entering the **rept-stat-card** command with the card location specified in step 11. For this example, enter this command.

rept-stat-card:loc=2207

This is an example of the possible output.

```
rlghncxa03w 07-05-27 16:43:42 GMT EAGLE5 37.0.0
CARD  VERSION  TYPE    APPL    PST       SST       AST
2207  114-001-000 DCM     SS7IPGW OOS-MT-DSBLD Isolated  -----
ALARM STATUS      = ** 0013 Card is isolated from the system
BPDCM GPL        = 002-102-000
IMT BUS A        = Disc
IMT BUS B        = Disc
SIGNALING LINK STATUS
SLK   PST       LS       CLLI       E5IS
A     OOS-MT    lsnlp1   -----  INACTIVE
```

Command Completed.

13. Remove the signaling link from the EAGLE 5 ISS using the **dlt-slk** command. If there is only one signaling link in the linkset, the **force=yes** parameter must be specified to remove the signaling link.

In the example used in this procedure, the signaling link is the last signaling link in the linkset. Enter this command.

dlt-slk:loc=2207:link=a:force=yes

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:17 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD
```

14. Verify the changes using the **rtrv-slk** command, with the card location and link values specified in step 13. For this example, enter this command.

```
rtrv-slk:loc=2207:link=a
```

When the **rtrv-slk** command has completed, the specified signaling link is not shown in the **rtrv-slk** output, as shown in this example.

```
rlghncxa03w 07-05-19 21:16:37 GMT EAGLE5 37.0.0
```


```
LOC LINK LSN          SLC TYPE
```


```
No Links Set up.
```

15. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-14. Removing an IPGWx Signaling Link





Removing an IP Host Assigned to an IPGWx Card

This procedure removes an IP host that is assigned to an IPGWx card using the **dlt-ip-host** command.

The **dlt-ip-host** command uses the following parameter.

:host—Hostname. The hostname to be removed. This parameter identifies the logical name assigned to a device with an IP address.

No sockets and associations can reference the host name being removed in this procedure.

The sockets referencing the host name can be removed by performing the [Removing a Socket that is Assigned to an IPGWx Signaling Link](#) procedure or the host name in these sockets can be changed by performing the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure in this chapter. The host name assigned to sockets is displayed in the **rtrv-appl-sock** outputs.

The associations referencing the host name can be removed by performing the [Removing an M3UA or SUA Association](#) procedure or the host name in these associations can be changed by performing the [Changing an M3UA or SUA Association](#) procedure. The host name assigned to associations is displayed in the **rtrv-assoc** outputs.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
192.3.3.33      GW100. NC. TEKELEC. COM

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (12 of 512) 2% full
```

2. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-link** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1303  A      192.1.1.10    255.255.255.128  HALF    10     802.3    NO    NO
1303  B      -----      -----      HALF    10     DIX      NO    NO
1305  A      192.1.1.12    255.255.255.0   ----    ---    DIX      YES   NO
1305  B      -----      -----      HALF    10     DIX      NO    NO
1313  A      192.1.1.14    255.255.255.0   FULL    100    DIX      NO    NO
1313  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20    255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22    255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24    255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2205  A      192.1.1.30    255.255.255.0   FULL    100    DIX      NO    NO
2205  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32    255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50    255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52    255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
2305  A      192.3.3.33    255.255.255.0   FULL    100    DIX      NO    NO
2305  B      -----      -----      HALF    10     DIX      NO    NO
```

3. Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```

rlghncxa03w 07-05-28 09:12:36 GMT EAGLE5 37.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101    TSM        SCCP
1102    TSM        GLS
1113    GSPM        EOAM
1114    TDM-A
1115    GSPM        EOAM
1116    TDM-B
1117    MDAL
1201    LIMDS0     SS7ANSI    sp2            A    0    sp1            B    0
1203    LIMDS0     SS7ANSI    sp3            A    0
1204    LIMDS0     SS7ANSI    sp3            A    1
1206    LIMDS0     SS7ANSI    nsp3           A    1    nsp4           B    1
1207    LIMV35     SS7GX25    nsp1           A    0
1208    LIMV35     SS7GX25    nsp1           A    1
1216    ACMENET      STPLAN
1301    LIMDS0     SS7ANSI    sp6            A    1    sp7            B    0
1302    LIMDS0     SS7ANSI    sp7            A    1    sp5            B    1
1303    DCM         IPLIM      ipnode1        A    0    ipnode3        B    1
1305    DCM         IPLIM      ipnode4        A    0
1307    ACMENET      STPLAN
1313    DCM         SS7IPGW    ipgtwy1        A    0
2101    DCM         SS7IPGW    ipgtwy2        A    0
2103    DCM         SS7IPGW    ipgtwy3        A    0
2105    DCM         IPLIM      ipnode1        A1   1    ipnode5        B    2
2205    DCM         IPLIM      ipnode3        A2   0    ipnode6        B1   2
2207    DCM         IPLIM      ipnode5        A    0    ipnode4        B3   1
2213    DCM         IPLIM      ipnode5        A3   1    ipnode3        B2   2
2301    DCM         IPLIM      ipnode6        A    0    ipnode1        B    2
2305    DCM         IPLIM      ipnode6        A1   1    ipnode1        B1   3

```

Select an IP host whose IP address is assigned to a card running the SS7IPGW or IPGWI application.

4. Display the sockets referencing the host name being removed in this procedure by entering the **rtrv-appl-sock** command.

For this example, enter this command.

rtrv-appl-sock: lhost="IPNODE1-1205"

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_1103
LINK      A
LHOST     IPNODE1-1205
RHOST     KC_HLR2
LPORT     7000          RPORT     7001
SERVER    YES          DCMPS     1
REXMIT    FIXED        RTT        60
OPEN      YES          ALW        YES

```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

If no sockets referencing the host name being removed in this procedure are shown in this step, go to step 5.

Any sockets referencing the host name must either be removed or the host name assigned to the socket must be changed. To remove the sockets, perform the [Removing a Socket that is Assigned to an IPGWx Signaling Link](#) procedure.

Go to step 5 after the sockets have been removed.

To change the host name assigned to the sockets, perform the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure.

Go to step 5 after the host name assigned to the sockets have been changed.

5. Display the associations referencing the host name being removed in this procedure by entering the **rtrv-assoc** command with the local host name.

For this example, enter this command.

rtrv-assoc: lhost="IPNODE1-1205"

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
a2         1313 A    A    M3UA   7205  7001  NO   NO
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1203
```

If no associations referencing the host name being removed in this procedure are shown in this step, go to step 6.

Any associations referencing the host name must either be removed or the host name assigned to the association must be changed.

To remove the associations, perform the [Removing an M3UA or SUA Association](#) procedure.

Go to step 6 after the associations have been removed.

To change the host name assigned to the associations, perform the [Changing an M3UA or SUA Association](#) procedure.

Go to step 6 after the host name assigned to the associations have been changed.

6. Delete IP host information from the database by entering the **dlt-ip-host** command.

For example, enter this command.

dlt-ip-host: host="IPNODE1-1205"

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
DLT-IP-HOST: MASP A - COMPLTD
```

7. Verify the changes by entering the **rtrv-ip-host** command with the host name specified in step 6.

For this example, enter this command.

rtrv-ip-host: host="IPNODE1-1205"

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
LOCAL IPADDR  LOCAL HOST
IP Host table is (10 of 512) 2% full
```


8. Back up the new changes using the **chg-db: action=backup: dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-15. Removing an IP Host Assigned to an IPGWx Card





Removing an IP Route

This procedure is used to remove an IP route from the database using the **dlt-ip-rte** command.

The **dlt-ip-rte** command uses these parameters.

:loc – The location of the IP card containing the IP route being removed.

:dest – The IP address of the remote host or network assigned to the IP route being removed.

:force – To remove the IP route, the IP card that the route is assigned to must be out of service, or the **force=yes** parameter must be specified with the **dlt-ip-rte** command. The **force=yes** parameter allows the IP route to be removed if the IP card is in service.



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212  132.10.175.20    255.255.0.0      150.1.1.50
1301  128.252.10.5      255.255.255.255  140.188.13.33
1301  128.252.0.0       255.255.0.0      140.188.13.34
1301  150.10.1.1        255.255.255.255  140.190.15.3
1303  192.168.10.1      255.255.255.255  150.190.15.23
1303  192.168.0.0       255.255.255.0    150.190.15.24
```

IP Route table is (6 of 1024) 1% full

2. Verify the state of the IP card containing the IP route being removed by entering the **rept-stat-card** command and specifying the card location of the IP card.

The IP card should be in the out-of-service maintenance-disabled (OOS-MT-DSBLD) in order to remove the IP route. If the IP card's state is out-of-service maintenance-disabled, the entry **OOS-MT-DSBLD** is shown in the **PST** column of the **rept-stat-card** output. For this example, enter this command.

rept-stat-card:loc=1301

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST      SST      AST
1301  114-000-000  DCM   SS7IPGW  IS-NR    Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST      LS      CLLI
A     IS-NR    nc001   -----
```

Command Completed.

NOTE: If the output of step 2 shows that the IP card's state is not OOS-MT-DSBLD, and you do not wish to change the state of the IP card, skip step 3 and go to step 4.

3. Change the IP card's state to OOS-MT-DSBLD using the **inh-card** command and specifying the card location of the IP card.

For this example, enter these commands.

inh-card:loc=1301

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Card has been inhibited.
```

4. Remove the IP route from the database using the **dlt-ip-rte** command.

If the state of the IP card is not OOS-MT-DSBLD, the **force=yes** parameter must be specified with the **dlt-ip-rte** command. For this example, enter this command.

```
dlt-ip-rte:loc=1301:dest=128.252.0.0
```



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20    255.255.0.0      150.1.1.50
1301 128.252.10.5     255.255.255.255  140.188.13.33
1301 150.10.1.1       255.255.255.255  140.190.15.3
1303 192.168.10.1     255.255.255.255  150.190.15.23
1303 192.168.0.0      255.255.0.0      150.190.15.24
```

IP Route table is (5 of 1024) 1% full

6. Place the IP card back into service by using the **alw-card** command.

NOTE: If the IP card containing the IP route that was removed from the database does not contain other IP routes, skip step 6 and go to step 7.

For example, enter this command.

```
alw-card:loc=1301
```

This message should appear.


```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

7. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-16. Removing an IP Route



Removing a Socket that is Assigned to an IPGWx Signaling Link

This procedure is used to remove a socket from the database that is assigned to an IPGWx signaling link using the **dlt-appl-sock** command.

The **dlt-appl-sock** command has only one parameter, **:sname** – the socket name being removed.

The **open** parameter must be set to **no** before the application socket can be removed. Use the **chg-appl-sock** command to change the value of the **open** parameter.

The socket cannot be removed if it is referenced by any routing keys. This can be verified with the **rtrv-appl-rtkey** command.

Canceling the RTRV-APPL-SOCK and RTRV-APPL-RTKEY Commands

Because the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** and **rtrv-appl-rtkey** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
  LINK      A
  LHOST     ipnode1-1201
  RHOST     kc-hlr1
  LPORT     7000          RPORT    7000
  SERVER    YES          DCMP5     1
  REXMIT    FIXED        RTT       60
  OPEN      YES          ALW       NO

SNAME kchlr11203
  LINK      A
  LHOST     ipnode1-1203
  RHOST     kc-hlr1
  LPORT     7005          RPORT    7005
```

```
SERVER YES      DCMPS 10
REXMIT FIXED    RTT   60
OPEN   NO       ALW   NO
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

2. Change the **open** parameter value in the socket being removed from the database using the **chg-appl-sock** command with the **open=no** parameter.

NOTE 1: If the application socket information shows the value of the **open** parameter in the socket being removed from the database is **no**, skip this step and go to step 3.



CAUTION: Setting the **open** parameter value to **no** could cause traffic to be lost.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:open=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

3. Verify that the socket is not assigned to any routing keys by entering the **rtrv-appl-rtkey** command with the socket name (**sname**) being removed in this procedure and the **display=all** parameter. For this example, enter this command.

rtrv-appl-rtkey:sname=kchlr11201:display=all

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT  DPC          SI SSN OPC          CICS          CICE          LOC
----- 001-002-003    5 --- 100-100-100    1             50           STATIC

      ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
      TALI  FULL          0         0    N    N

      SNAMES
      kchlr11201

STATIC Route Key table is ( 8 of 2000) 1% full
1105  Route Key table is ( 2 of 500) 1% full
1107  Route Key table is ( 2 of 500) 1% full

STATIC Route Key Socket Association table is (8 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

If the socket is assigned to any routing keys, perform the [Removing a Routing Key Containing a Socket](#) procedure and remove the socket from these routing keys.

4. Remove the application socket from the database by entering the **dlt-appl-sock** command with the socket name being removed. For example, enter this command.

dlt-appl-sock:sname=kchlr11201

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
DLT-APPL-SOCK: MASP A - COMPLTD
```

5. Verify the new application socket information in the database by entering the **rtrv-appl-sock** command with the socket name specified in step 4. For this example, enter this command.

rtrv-appl-sock:sname=kchlr11201

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0

IP Appl Sock/Assoc table is (3 of 4000) 1% full


6. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.

BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.

BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 4-17. Removing a Socket that is Assigned to an IPGWx Signaling Link

Removing a Routing Key Containing a Socket

This procedure is used to remove a static or dynamic routing key that contains a socket from the database using the **dlt-appl-rtkey** command. For more information about static and dynamic routing keys, see [Understanding Routing for SS7IPGW and IPGWI Applications](#).

The **dlt-appl-rtkey** command uses these parameters.

:dpc/dpca/dpci/dpcn/dpca24 – The destination point code value that is used to filter incoming MSUs.

:opc/opca/opci/opcn/opcn24 - The originating point code value that is used to filter incoming MSUs. This parameter must not specify a cluster route. This parameter must not specify a cluster route. This parameter is only valid when the **si** parameter value is set to **4**, **5**, or **13**. This parameter is required if **si=4**, **5**, or **13** and **type=full**.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value from 0 to 15, or for selected service indicator values, a text string can be used instead of numbers. [Table 4-13](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 4-13. Service Indicator Text String Values

Service Indicator Value	Text String	Service Indicator Value	Text String
0	snm	4	tup
1	regtest	5	isup
2	spltst	13	qbicc
3	sccp		

:ssn – The subsystem value that is used to filter incoming MSUs. The **ssn** parameter is only valid when the **si** parameter value is set to **3** or **sccp**.

:sname – The name of the socket that will receive the incoming MSU.

:cics - The starting circuit identification code that is used to filter incoming MSUs. Specify with **cice** to delete routing keys with the circuit identification code or range of circuit identification codes. The **cics** parameter is only valid when the **si** parameter value is set to **4**, **5**, or **13**. The **cics** is required if **si=4**, **5**, or **13** and **type=full**.

:cice - The ending circuit identification code that is used to filter incoming MSUs. Specify with **cics** to delete routing keys with the circuit identification code or range of circuit identification codes. The **cice** parameter is only valid when the **si** parameter value is set to **4**, **5**, or **13**. The **cics** is required if **si=4**, **5**, or **13** and **type=full**.

:loc – Card location that indicates from which **ss7ipgw** or **ipgwi** card to delete a dynamic routing key entry. If this parameter is not specified, a static entry is deleted.

:type - Identifies the type of routing key that is being deleted. One of three values, **type = full/partial/default**. If **type** is not explicitly specified, **type = full** is assumed.

The dlt-appl-rtkey command also contains these parameters:

- **:asname** - Application server (AS) name.
- **:rcontext** – The routing context parameter value assigned to the routing key.

These parameters are not used in this procedure. To use these parameters, perform the [Removing a Routing Key Containing an Application Server](#) procedure.

The parameter combinations used by the **dlt-appl-rtkey** command are based on the type of routing key and the service indicator value in the routing key. The parameter combinations are shown in [Table 4-14](#).

Table 4-14. Routing Key Parameter Combinations for Removing Routing Keys

Full Routing Key ¹ - SI = 3 (SCCP)	Partial Routing Key ¹ - SI=3 (SCCP)	Full Routing Key ¹ - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key ¹ - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key ¹ - Other SI Values	Partial Routing Key ¹ - Other SI Values	Default Routing Key
dpc	sname	dpc	sname	dpc	sname	sname
si=3 ¹	type=partial	si=4, 5, 13 ¹	type=partial	si=value other than 3, 4, 5, 13 ¹	type=partial	type=default
ssn	dpc ²	opc	dpc ²	sname	dpc ²	asname
type=full	si=3 ¹ , 2	cics	si=4, 5, 13 ¹ , 2	type=full	si=value other than 3, 4, 5, 13 ¹ , 2	loc ³
sname	asname	cice	opc ²	asname	asname	
asname	loc ³	type=full	asname	loc ³	loc ³	
loc ³		sname	loc ³			
		asname				
		loc ³				

Notes:

1. The values for these parameters must be entered exactly as shown in the **rtrv-appl-rtkey** command output for the routing key being removed. However, text strings can be used in place of some numerical service indicator values. See [Table 4-13](#) for a list of these text strings.

2. These parameters are optional for partial routing keys, but at least one these parameters must be specified with the **dlt-appl-rtkey** command.

3. If the **loc** parameter is not specified, a static entry that matches the other specified parameters is deleted. The **loc** parameter can be specified only for dynamic routing key entries, entries that have a card location in the **LOC** column in the **rtrv-appl-rtkey** output. If the value in the **LOC** column is **STATIC**, the **loc** parameter cannot be used.

Canceling the RTRV-APPL-RTKEY Command

Because the **rtrv-appl-rtkey** command used in this procedure can output information for a long period of time, the **rtrv-appl-rtkey** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-rtkey** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-appl-rtkey** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

RCONTEXT	DPCI	SI	ADPTR	ASNAME	TYPE	LOC
-----	2-100-7	6	M3UA	as4	FULL	STATIC
100	3-137-6	6	SUA	as1	FULL	STATIC
225	4-035-7	5	M3UA	as7	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-7	5	M3UA	as8	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-8	3	M3UA	as3	FULL	STATIC
-----	6-006-8	5	M3UA	as5	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
300	7-008-7	6	SUA	as6	FULL	STATIC

RCONTEXT	DPCN	SI	ADPTR	ASNAME	TYPE	LOC
-----	-----	-----	-----	-----	-----	-----

RCONTEXT	DPCN24	SI	ADPTR	ASNAME	TYPE	LOC
-----	-----	-----	-----	-----	-----	-----

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	*****	**	TALI	-----	DEFAULT	STATIC

STATIC Route Key table is (15 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

If no entries in the **rtrv-appl-rtkey** output contain the entry **TALI** in the **ADPTR** column, there are no routing keys that contain sockets in the database. This procedure cannot be performed. Perform the [Removing a Routing Key Containing an Application Server](#) procedure to remove the routing keys.

2. Select a routing key from the **rtrv-appl-rtkey** output that contains the entry **TALI** in the **ADPTR** column.

Display the specific routing key information for the routing key being removed from the database by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and the **DPC**, **SI**, and **TYPE** values shown in the **rtrv-appl-rtkey** output in step 1 for the routing key being removed. For this example, enter this command.

```
rtrv-appl-rtkey:dpca=006-006-001:si=5:display=all:type=full
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	SSN	OPC	CICS	CICE	LOC
-----	006-006-001	5	---	011-011-001	501	1000	1107

ADPTR	TYPE	PSTNCAT	PSTNID	NORM	DUP
TALI	FULL	0	0	N	N

```

SNAMES
socket31

RCONTEXT  DPC          SI SSN OPC          CICS      CICE      LOC
-----  - 006-006-001  5 --- 012-012-012  1001      1500      1107

```

```

ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
TALI   FULL          0         0    N    N

```

```

SNAMES
socket32

```

```

STATIC Route Key table is (15 of 2000) 1% full
1105   Route Key table is (2 of 500) 1% full
1107   Route Key table is (2 of 500) 1% full

```

```

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105   Route Key Socket Association table is (2 of 8000) 1% full
1107   Route Key Socket Association table is (2 of 8000) 1% full

```

3. Remove the routing key information from the database by entering the **dlt-appl-rtkey** command.

The parameters required for the **dlt-appl-rtkey** command are determined by the type of routing key being added and the service indicator value in the routing key. See [Table 4-14](#) for the parameter combinations that can be used for the type of routing key being added to the database. For example, enter these commands.

```
dlt-appl-rtkey:dpca=006-006-001:loc=1107:si=5:cics=501 :cice=1000:sname=socket31
```

When this command has successfully completed, the following message should appear.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
DLT-APPL-RTKEY: MASP A - COMPLTD

```

4. Verify the changes by entering the **rtrv-appl-rtkey** command with the routing key parameters specified in step 3 (**dpc**, **si**, **opc**, **cics**, **cice**, **ssn**, **sname**, **type**, and **loc**, as applicable).

For this example, enter this command.

```
rtrv-appl-rtkey:dpca=006-006-001:loc=1107:si=5:cics=501 :cice=1000
```

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

STATIC Route Key table is (12 of 2000) 1% full
1105   Route Key table is (2 of 500) 1% full
1107   Route Key table is (1 of 500) 1% full

STATIC Route Key Socket Association table is (12 of 32000) 1% full
1105   Route Key Socket Association table is (2 of 8000) 1% full
1107   Route Key Socket Association table is (1 of 8000) 1% full


```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Flowchart 4-18. Removing a Routing Key Containing a Socket

Changing TALI IPGWx Components

This section describes how to change the attributes of the following components in the database.

- A Socket – Perform the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure

- The IP socket retransmission parameters – Perform the [Configuring IP Socket Retransmission Parameters](#) procedure
- A DCM parameter set – Perform the [Configuring a DCM Parameter Set](#) procedure
- The CIC value in an existing routing key – [Changing the CIC Values in an Existing Routing Key Containing a Socket](#) procedure
- The PSTN presentation and normalization attributes in a routing key – [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure
- The IP TPS alarm threshold – [Configuring the IP TPS Alarm Threshold](#) procedure.

Changing the Attributes of a Socket on an IPGWx Signaling Link

This procedure is used to change an application socket in the database using the **chg-appl-sock** command.

The **chg-appl-sock** command uses these parameters.

:sname– Socket Name.

:lhost – Local Hostname. The logical name assigned to the local host device. The local host name must be shown in the **LOCAL HOST** column of the **rtrv-ip-host** output. Local host names that contain dashes (-) must be enclosed in double quotes (“”).

:lport – The TCP port number for the Local host.

:rhost – Remote Hostname. The logical name assigned to the remote host device. The remote host name does not have to be shown in the **rtrv-ip-host** output. If remote host name is shown in the **rtrv-ip-host** output, it must be shown in the **REMOTE HOST** column of the **rtrv-ip-host** output. Remote host names that contain dashes (-) must be enclosed in double quotes (“”).

:rport – The TCP port number of the remote host.

:link – The signaling link on the IPGWx card. Only the **link=a** parameter can be specified in this procedure.

NOTE: The port parameter can be used in place of the link parameter to specify the signaling link on the card.

:server – Server Role. The role of the local socket in the Client/Server relationship.

:open – Socket State. Indicates to the connection manager software to open the socket if the socket is operational.

:alw – Connection State. Indicates to the connection manager software if the socket is allowed to carry SS7 traffic.

:dcmps – DCM Parameter Set. The DCM parameter set that will be used by the socket.

:rexmit – Indicates the retransmission mode that the user wants the TCP stack to use for this socket.

:rtt – Indicates the measured or expected round trip time (RTT) of the socket in milliseconds.

For more information on the **rexmit** and **rtt** parameters, go to the [Configuring IP Socket Retransmission Parameters](#) procedure.

NOTE: If the ITU National and International Spare Point Code Support feature is enabled, the socket cannot reference a card running the IPGWI application. Enter the **rtrv-ctrl-feat:partnum=893013601** command to verify whether or not the ITU National and International Spare Point Code Support feature is enabled. If the ITU National and International Spare Point Code Support feature is enabled, and the IP connection is being assigned to a card running the IPGWI application, the IP connection must be an IETF association. Perform the [Adding an M2PA Association](#) or the [Adding an M3UA or SUA Association](#) procedures to add the IP connection to the database.

The **open** parameter must be set to **no** before changes can be made to **server**, **lhost**, **lport**, **rhost**, **rport**, **rtt**, **rexmit**, and **link** parameters.

The **open** parameter must be changed with a separate **chg-appl-sock** command. The **open** parameter can not be on a command line that has **server**, **lhost**, **lport**, **rhost**, and **rport** parameters.

At least one optional parameter is required.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 22 SCTP association to application server assignments, the maximum number of TALI sockets the IPGWx card can support is 28. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** and **rtrv-as:aname=<association name>** commands.

Table 4-15. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50
25	2	0	50
0	0	50	50
22	1	28	50
11	2	28	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

The value of the **lhost** and **rhost** parameters is a text string of up to 60 characters, with the first character being a letter.

The command input is limited to 150 characters, including the hostname.

To set the **open** parameter value to **yes**, the socket specified by the **sname** parameter must contain values for the **lhost**, **lport**, **rhost**, and **rport** parameters.

The **rtt** parameter cannot be specified with the **rexmit=bsd** parameter.

When the **rexmit=fixed** or **rexmit=mod** parameters are specified, the **rtt** parameter must be specified.

The IP address of the local host (**lhost** parameter) must be shown in the **rtrv-ip-lnk** output.

The signaling link being assigned to the socket must be in service. This state is shown in the **rept-stat-slk** output with the entries **IS-NR** in the **PST** field and **Avail** in the **SST** field.

The B Ethernet interface of the IP card can be used only if the IP card is a single-slot EDCM.

If the socket being changed is a client socket, shown in the **rtrv-appl-sock** output with the entry **NO** in the **SERVER** field, the socket's **lhost** and **lport** values cannot match the values of any open socket.

If the socket being changed is a server socket, shown in the **rtrv-appl-sock** output with the entry **YES** in the **SERVER** field, the socket's **lhost** and **lport** values cannot match the values of any open client socket.

Canceling the RTRV-APPL-SOCK Command

Because the **rtrv-appl-sock** command used in this procedure can output information for a long period of time, the **rtrv-appl-sock** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** command was entered, from another terminal other than the terminal where the **rtrv-appl-sock** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command.

The following is an example of the possible output.

```
r1ghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
  LINK      A
  LHOST     ipnode1-1201
  RHOST     kc-hlr1
  LPORT     7000          RPORT    7000
  SERVER    YES          DCMPS     1
  REXMIT    FIXED        RTT        60
  OPEN      YES          ALW        NO

SNAME kchlr11203
  LINK      A
  LHOST     ipnode1-1203
  RHOST     kc-hlr1
  LPORT     7005          RPORT    7005
  SERVER    YES          DCMPS     10
  REXMIT    FIXED        RTT        60
  OPEN      YES          ALW        NO

SNAME sock1
```


LINK	A		
LHOST	IPNODE2-1205		
RHOST	remotehost1		
LPORT	1024	RPORT	2048
SERVER	YES	DCMPS	10
REXMIT	FIXED	RTT	60
OPEN	YES	ALW	YES

SNAME	sock2		
LINK	A		
LHOST	IPNODE2-1205		
RHOST	remotehost2		
LPORT	2000	RPORT	2000
SERVER	YES	DCMPS	10
REXMIT	FIXED	RTT	60
OPEN	YES	ALW	YES

IP Appl Sock/Assoc table is (7 of 4000) 1% full

NOTE 1: To change the values of these parameters: **server**, **lhost**, **lport**, **rhost**, **link**, **rtt**, **rexmit**, or **rport**, the value of the **open** parameter must be **no**. If the values of any of these parameters are being changed and the **open** parameter value for the socket being changed is **no**, skip step 2 and go to step 3.

NOTE: If only the values of the **alw**, **open**, or **dcmps** parameters are being changed, skip steps 2 through 11, and go to step 12.

2. Change the value of the **open** parameter to **no** using the **chg-appl-sock** command with the **open=no** parameter. For example, enter this command.

chg-appl-sock:sname=kchlr11201:open=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

NOTE: If the local host name or the **link** value of the socket are not being changed, skip steps 3 through 11, and go to step 12.

3. Verify that the local host name to be assigned to the socket is in the database by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MS1
192.1.1.52      DN-MS2

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (11 of 512) 2% full

4. Display the IP links in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A    192.1.1.10        255.255.255.128  HALF    10     802.3    NO    NO
1201  B    -----            -----            HALF    10     DIX      NO    NO
1203  A    192.1.1.12        255.255.255.0    ---     ---     DIX      YES   NO
1203  B    -----            -----            HALF    10     DIX      NO    NO
1205  A    192.1.1.14        255.255.255.0    FULL    100    DIX      NO    NO
1205  B    -----            -----            HALF    10     DIX      NO    NO
2101  A    192.1.1.20        255.255.255.0    FULL    100    DIX      NO    NO
2101  B    -----            -----            HALF    10     DIX      NO    NO
2103  A    192.1.1.22        255.255.255.0    FULL    100    DIX      NO    NO
2103  B    -----            -----            HALF    10     DIX      NO    NO
2105  A    192.1.1.24        255.255.255.0    FULL    100    DIX      NO    NO
2105  B    -----            -----            HALF    10     DIX      NO    NO
2205  A    192.1.1.30        255.255.255.0    FULL    100    DIX      NO    NO
2205  B    -----            -----            HALF    10     DIX      NO    NO
2207  A    192.1.1.32        255.255.255.0    FULL    100    DIX      NO    NO
2207  B    -----            -----            HALF    10     DIX      NO    NO
2213  A    192.1.1.50        255.255.255.0    FULL    100    DIX      NO    NO
2213  B    -----            -----            HALF    10     DIX      NO    NO
2301  A    192.1.1.52        255.255.255.0    FULL    100    DIX      NO    NO
2301  B    -----            -----            HALF    10     DIX      NO    NO
```

5. Display the signaling link referenced by the IP link that will be assigned to the socket by entering the **rtrv-slk** command and specifying the location of the IP link. For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK  LSN          SLC  TYPE
1201  A    e5e6a        1    SS7IPGW
```

If the required signaling link is in the database, and the card's application (shown in the **TYPE** column) is SS7IPGW, skip step 6 and go to step 7.

If the card's application is IPGWI or if the required signaling link is not in the database, go to step 6.

6. Display the status of the ITU National and International Spare Point Code Support feature by entering the **rtrv-ctrl-feat** command with the ITU National and International Spare Point Code Support feature part number. Enter this command.

rtrv-ctrl-feat:partnum=893013601

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Spare Point Code Support	893013601	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ITU National and International Spare Point Code Support feature is not enabled, and the required signaling link is not in the database, perform the [Adding an IPGWx Signaling Link](#) procedure. After the signaling link has been added, go to step 7.

If the ITU National and International Spare Point Code Support feature is enabled, and the card's application is IPGWI, the IP connection must be assigned to an IETF association, or if the IP connection is to remain assigned to a socket, the socket must be assigned to a card running the SS7IPGW, or application. If the IP connection is to remain a socket, perform the [Adding an IPGWx Signaling Link](#) procedure to add the required signaling link. The signaling link cannot be assigned to a card running the IPGWI applications. After the signaling link has been added, go to step 7.

If the IP connection is to be an association, perform the [Adding an M3UA or SUA Association](#) procedure to add the IP connection to the database. The remainder of this procedure cannot be performed.

NOTE: If the required IP link information is shown in the `rtrv-ip-lnk` output in step 4, skip step 7 and go to step 8.

7. Add the IP address of the IP link by performing the [Configuring an IP Link](#) procedure.

NOTE 1: If the local host name of the socket is not being changed, skip steps 8, 9, 10, and 11, and go to step 12.

NOTE 2: If the new local host name is shown in the `rtrv-ip-host` output in step 3, skip step 8 and go to step 9.

8. Add the new local host name and IP address from step 7 by performing the [Adding an IP Host](#) procedure.
9. Display the sockets assigned to the local host that will be assigned to the socket being configured in this procedure by entering the `rtrv-appl-sock` command with the `lhost` parameter. For this example, enter this command.

`rtrv-appl-sock: lhost="IPNODE2-1205"`

This is an example of the possible output.

r1ghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

```
SNAME sock1
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost1
LPORT     1024          RPORT     2048
SERVER    YES          DCMPS    10
REXMIT    FIXED        RTT        60
OPEN      YES          ALW        YES
```

```
SNAME sock2
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost2
LPORT     2000          RPORT     2000
SERVER    YES          DCMPS    10
REXMIT    FIXED        RTT        60
OPEN      YES          ALW        YES
```

IP Appl Sock/Assoc table is (5 of 4000) 1% full

10. Display the associations assigned to the local host that will be assigned to the socket being configured in this procedure by entering the `rtrv-assoc` command with the `lhost` parameter. For this example, enter this command.

`rtrv-assoc: lhost="IPNODE2-1205"`

This is an example of the possible output.

r1ghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

```
          CARD IPLNK
ANAME     LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc1    1205 A    A    M3UA    2048 2048 YES YES
assoc2    1205 A    A    SUA     3000 3000 YES YES
```

IP Appl Sock/Assoc table is (5 of 4000) 1% full
Assoc Buffer Space Used (32 KB of 3200 KB) on LOC = 1205

11. Display the application servers that the associations shown in step 10 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 10. For this example, enter these commands.

rtrv-as:aname=assoc1

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms    Association Names
as1          LOADSHARE 2000     assoc1

as4          LOADSHARE 2000     assoc1

as6          LOADSHARE 2000     assoc1
```

AS Table is (6 of 250) 1% full

rtrv-as:aname=assoc2

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms    Association Names
as2          LOADSHARE 2000     assoc2

as3          LOADSHARE 2000     assoc2

as5          LOADSHARE 2000     assoc2
```

AS Table is (6 of 250) 2% full

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets and SCTP association to application server assignments is less than 50, go to step 12.

If the number of TALI sockets and SCTP association to application server assignments is 50, the local host value cannot be used in this procedure.

Repeat steps 3 and 4 and select another IP link and IP host to use in this procedure or add a new IP link using the [Configuring an IP Link](#) procedure. After the new IP link is added, perform the [Adding an IP Host](#) procedure to assign this IP address to a new local host name. After the new local host name as been added, go to step 12.

12. Change the application socket by using the **chg-appl-sock** command with this mandatory parameter:

:sname = the socket name

and with at least one of these optional parameters:

:lhost = the local host name from steps 3 or 8

:lport = the local port ID, from 1024 to 65535

:rhost = the remote host name

:rport = the remote port ID, from 1024 to 65535

:link=a

:server = yes or no

:alw = yes or no

:dcmps = 1 to 10

:open = yes or no.

NOTE: The **open=yes** parameter cannot be specified in this step if the **lhost**, **lport**, **rhost**, **rport**, **link**, **server**, **rexmit**, and **rtt** parameters are specified.

NOTE 1: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

NOTE: See [Flowchart 4-19](#) (Sheet 6) for the rules that apply to the **chg-appl-sock** command.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:rhost="kc-kc-kc":alw=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

NOTE: If step 2 was not performed in this procedure, or the **open=yes** parameter was specified in step 12, skip step 13 and go to step 14.

13. Change the **open** parameter value back to **yes** by using the **chg-appl-sock** command.

For example, enter this command.

chg-appl-sock:sname=kchlr11201:open=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

14. Verify the new application socket information in the database by entering the **rtrv-appl-sock** command with the socket name specified in step 12. For this example, enter this command.

rtrv-appl-sock:sname=kchlr11201

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
LINK A
LHOST ipnode1-1201
RHOST kc-kc-kc
LPORT 7000 RPORT 7000
SERVER YES DCMP5 1
REXMIT FIXED RTT 60
OPEN YES ALW YES
```


IP Appl Sock/Assoc table is (3 of 4000) 1% full


15. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


BACKUP (FIXED) : MASP A - Backup starts on active MASP.


BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


Flowchart 4-19. Changing the Attributes of a Socket on an IPGWx Signaling Link











Notes:

1. The B Ethernet interface cannot be used with the dual-slot DCM. The B Ethernet interface can be used only with the single-slot EDCM.
2. The sum of the number of sockets and association – application server assignments on a card running either the *ss7ipgw* or *ipgwi* applications cannot exceed 50.
3. The EAGLE 5 ISS can contain a maximum of 4000 connections (association – application server assignments plus sockets).
4. The value of the *lhost* and *rhost* parameters is a text string of up to 60 characters, with the first character being a letter.
5. If the socket is a client socket (*server=no*) and the *open* parameter value is being changed to yes, the *lhost/lport* parameter values of this socket cannot match the *lhost/lport* values of any other open sockets.
6. If the socket is a server socket (*server=yes*) and the *open* parameter value is being changed to yes, the *lhost/lport* parameter values of this socket cannot match the *lhost/lport* values of any other open client sockets.
7. The *rtt* parameter cannot be specified with the *rexmit=bsd* parameter.
8. When the *rexmit=fixed* or *rexmit=mod* parameters are specified, the *rtt* parameter must be specified.
9. The local host name must be shown in the *rtv-ip-host* output in the *LOCAL HOST* column.
10. The remote host name does not have to be shown in the *rtv-ip-host* output. If the remote host name is shown in the *rtv-ip-host* output, it must be shown in the *REMOTE HOST* column.
11. Host names (local and remote) that contain dashes (-) must be enclosed in double quotes (").
12. The *port* parameter can be used in place of the *link* parameter to specify the signaling link assigned to the socket.
13. If the *open* parameter value is being changed to yes, the socket must contain values for the *lhost*, *lport*, *rhost*, and *rport* parameters.

Configuring IP Socket Retransmission Parameters

This procedure is used to configure the retransmission parameters for sockets using the **rexmit** and **rtt** parameters of the **chg-appl-sock** command.

:rexmit – Indicates the retransmission mode that the user wants the TCP stack to use for a socket. The **rexmit** parameter values are **bsd** (standard), **fixed** (Tekelec version), or **mod** (combination of **bsd** and **fixed**). The default value is **fixed**.

:rtt – Indicates the measured or expected round trip time of the socket in milliseconds. Be aware that you are entering the round trip time, not the retransmission timeout that will be used for the socket. The initial retransmission timeout that is actually applied to the socket will be the next 125 millisecond increment above the entered round trip time. The default value is 60.

It is important to set the configured round trip time as accurately as possible. When the round trip time is configured too low, network congestion can occur, thus delaying (or preventing) the delivery of SS7 data, resulting in a negative impact on MSU throughput. If the round trip time is set too high, the TCP protocol layer may act unpredictably, resulting in the SS7 service being degraded. The MSU throughput would be lowered, possibly affecting the client application software. When the round trip time is configured correctly, the TCP network can deliver SS7 data in a timely manner with little or no network congestion.

The [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure is used to change the values of these parameters. In addition to using the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure, these pass commands are also used in this procedure.

- **ping** – tests for the presence of hosts on the network.
- **sockrtt** – displays the round trip time data
- **netstat -p tcp** – determines if retransmissions have occurred.

For more information of the **pass** commands, go to the *Commands Manual*.

The **rexmit** and **rtt** parameter values are set using the data collected from the **pass** commands.

The **rtt** parameter cannot be specified with the **rexmit=bsd** parameter.

When the **rexmit=fixed** or **rexmit=mod** parameters are specified, the **rtt** parameter must be specified.

Canceling the RTRV-APPL-SOCK Command

Because the **rtrv-appl-sock** command used in this procedure can output information for a long period of time, the **rtrv-appl-sock** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-sock** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** command was entered, from another terminal other than the terminal where the **rtrv-appl-sock** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current application socket information in the database by entering the **rtrv-appl-sock** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
  LINK  A
  LHOST ipnode1-1201
  RHOST kc-hlr1
  LPORT 7000          RPORT 7000
  SERVER YES          DCMPS 1
  REXMIT FIXED        RTT 60
  OPEN  YES           ALW  NO

SNAME kchlr11203
  LINK  A
  LHOST ipnode1-1203
  RHOST kc-hlr1
  LPORT 7005          RPORT 7005
  SERVER YES          DCMPS 10
  REXMIT FIXED        RTT 60
  OPEN  YES           ALW  YES
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

2. Display the IP address assigned to the remote host that will be pinged in step 4 using the **rtrv-ip-host** command with the remote host name shown in step. For this example, enter this command.

```
rtrv-ip-host:host="kc-hlr1"
```

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR    LOCAL HOST
192.1.1.30      KC-HLR1
```

```
IP Host table is (11 of 512) 2% full
```

3. Display the IP links assigned to the IP address shown in step 2 by entering the **rtrv-ip-lnk** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.30   255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----     -----     HALF    10     DIX      NO    NO
1203  A      192.1.1.12   255.255.255.0   ----    ---    DIX      YES   NO
1203  B      -----     -----     HALF    10     DIX      NO    NO
1205  A      192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----     -----     HALF    10     DIX      NO    NO
2101  A      192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----     -----     HALF    10     DIX      NO    NO
2103  A      192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----     -----     HALF    10     DIX      NO    NO
2105  A      192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----     -----     HALF    10     DIX      NO    NO
2207  A      192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----     -----     HALF    10     DIX      NO    NO
2213  A      192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----     -----     HALF    10     DIX      NO    NO
2301  A      192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----     -----     HALF    10     DIX      NO    NO
```

4. Using the outputs of steps 1 through 3 as a guide, enter the **pass:cmd="ping"** command specifying the card and the host name of the remote host. This command is entered several times to obtain the average round trip time. For this example, enter this command.

```
pass:loc=1201:cmd="ping kc-hlr1"
```

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING command in progress
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING kc-hlr1 (192.1.1.30): 56 data bytes
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=0. time=5. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=1. time=9. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=2. time=14. ms
----tekral PING Statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 5/9/14
```

```
PING command complete
```

5. Perform the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure and change the retransmission parameters (**rtt** and **rexmit**) of the socket based on the results of pinging the remote host in step 4.
6. A TALI monitor (MONI) message is sent to the remote host.
7. Enter the **pass:cmd="sockrtt"** command to display the round trip time data collected during the sending of the TALI monitor acknowledgement (MONA) message. For this example, enter this command.

pass:loc=1201:cmd="sockrtt kc-hlr1"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

SOCKRTT: Socket round-trip time report (in milliseconds)

Configured Traffic Round-Trip Time
Retransmission Mode           : MOD
Fixed Round Trip Time         : 250

Measured Normal Traffic Round-Trip Times

    Minimum round-trip time      : 5
    Maximum round-trip time      : 195
    Weighted Average round-trip time : 10
    Last recorded round-trip time : 10

Measured Congested Traffic Round-Trip Times

    Minimum round-trip time      : 0
    Maximum round-trip time      : 0
    Weighted Average round-trip time : 0
    Last recorded round-trip time : 0

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SOCKRTT command complete
```

8. Enter the **pass:cmd="netstat -p tcp"** command to determine if any retransmissions have occurred. For this example, enter this command.

pass:loc=1201:cmd="netstat -p tcp"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
TCP:
    0 packet sent
        0 data packet (0 byte)
        0 data packet (0 byte) retransmitted
        0 ack-only packet (0 delayed)
        0 URG only packet
        0 window probe packet
        0 window update packet
        0 control packet
    0 packet received
        0 ack (for 0 byte)
        0 duplicate ack
        0 ack for unsent data
        0 packet (0 byte) received in-sequence
        0 completely duplicate packet (0 byte)
        0 packet with some dup. data (0 byte duped)
        0 out-of-order packet (0 byte)
        0 packet (0 byte) of data after window
        0 window probe
        0 window update packet
        0 packet received after close
        0 discarded for bad checksum
        0 discarded for bad header offset field
        0 discarded because packet too short
    0 connection request
```


```
0 connection accept
0 connection established (including accepts)
0 connection closed (including 0 drop)
0 embryonic connection dropped
0 segment updated rtt (of 0 attempt)
0 retransmit timeout
    0 connection dropped by rexmit timeout
0 persist timeout
0 keepalive timeout
    0 keepalive probe sent
    0 connection dropped by keepalive
0 pcb cache lookup failed

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
NETSTAT command complete
```

NOTE: If the results of the `pass:cmd="netstat -p tcp"` command show that the retransmission parameters do not need to be adjusted, do not perform this step. This procedure is finished.

9. Go to the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure and adjust the retransmission parameter (**rtt** and **rexmit**) values of the socket based on the results of the `pass:cmd="netstat -p tcp"` command entered in step 8.

Flowchart 4-20. Configuring IP Socket Retransmission Parameters



Configuring a DCM Parameter Set

This procedure is used to configure a Database Communication Module Parameter Set in the database using the **chg-dcmps** command. Parameter sets are sets of generic timers and parameters that can be used by any IP application.

NOTE: For IP, timers one through four correspond to timers T1, T2, T3, T4 in the TALI state machine.

The **chg-dcmps** command uses these parameters.

:set— The set number, 1 to 9.

:timer — The timer number within the set, 1 to 10. Only timers 1 to 4 are used. Timers 5 through 10 are not used.

:tvalue — The value the timer will be set to.

:parm— The parameter number within the timer, 1 to 10. Only parameter numbers 1 through 3 are used. Parameter numbers 4 through 10 are not used.

:pvalue — The numerical value that **pvalue** will be set to if specified.

:srcset — The source set of the copy, 1 - 10.

The values of the **timer**, **tvalue**, **parm**, and **pvalue** parameters is shown in the **rtrv-dcmps** output. The output shows the values for the **tvalue** and **pvalue** in bits. The values for these parameters are entered as a decimal number. [Table 4-16](#) shows the decimal equivalent for the bit values shown in the **rtrv-dcmps** output.

Table 4-16. DCMPS Values

Bit Value	Decimal Number Range
32	0 - 4294967295
8	0 - 255

While the value of the **pvalue** parameter when used with the **parm=3** parameter is 32 bits, or from 0 to 4294967295, only the first 6 bits (bits 0 - 5) are used. Bits 6-31 are reserved. This makes the decimal value of the **pvalue** parameter when used with the **parm=3** parameter from 0 to 63.

The value of the **pvalue** parameter when used with the **parm=2** parameter (enabling or disabling Nagle's Algorithm, TCP socket option) is either 0 (disabling Nagle's Algorithm) or 1 (enabling Nagle's Algorithm).

At least one of these parameters, **timer**, **parm**, or **srcset**, must be entered.

If the **srcset** parameter is specified, no other optional parameters can be entered.

If the **timer** parameter is specified, the **tvalue** parameter must be specified.

If the **parm** parameter is specified, the **pvalue** parameter must be specified.

NOTE: Set number 10 is a default parameter set and cannot be changed. In order to change the DCM parameters set for a socket using set number 10, use the **chg-appl-sock command to change the DCM parameter set to a different set number, and then use the **chg-dcmps** command to modify the new set.**

Canceling the RTRV-DCMPS Command

Because the **rtrv-dcmps** command used in this procedure can output information for a long period of time, the **rtrv-dcmps** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-dcmps** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-dcmps** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-dcmps** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-dcmps** command was entered, from another terminal other than the terminal where the **rtrv-dcmps** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the DCM parameter set being changed in this procedure by entering the **rtrv-dcmps** command with the **set** parameter.

For example, enter this command.

rtrv-dcmps:set=1

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SET  TIMER      TVALUE  PARM      PVALUE
1    1           4000    1          255
1    2           3000    2           1
1    3           3000    3           1
1    4          10000    4           0
1    5            0      5           0
1    6            0      6           0
1    7            0      7           0
1    8            0      8           0
1    9            0      9           0
1   10            0     10           0
```

TIMER 1: TALI T1 Timer, time (mS) between sending of TEST msgs by NE
TVALUE : Valid range = 32-bits

TIMER 2: TALI T2 Timer, time (mS) to wait for response to TEST msg
TVALUE : Valid range = 32-bits

TIMER 3: TALI T3 Timer, time (mS) to continue processing rcv'd service
msgs after NE is prohibited
TVALUE : Valid range = 32-bits

TIMER 4: TALI T4 Timer, time (mS) between sending of MONI msgs by NE
TVALUE: Valid range = 32-bits

PARM 1: Type of Service (TOS), IP header socket option
PVALUE: Valid range = lowest 8-bits

PARM 2: Nagle's Algorithm, TCP socket option
PVALUE: Valid range = lowest bit: 0 = Disable Nagle, 1 = Enable Nagle

PARM 3: Default SORP Flags socket option. Each bit is used as an
enabled/disabled flag for a particular socket option.
PVALUE: Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast Phase MTPP Primitives;	0=Disabled , 1=Enabled

1=Response Method MTPP Primitives;	0=Disabled , 1=Enabled
2=SCCP with MTP;	0=Disabled , 1=Enabled
3=ISUP via MTP;	0=Disabled , 1=Enabled
4=Group Code in MTPP;	0=Disabled , 1=Enabled
5=Use XSRV;	0=Disabled , 1=Enabled
6-31=Reserved	

NOTE: If a parameter set is not being copied to the parameter set being changed, skip step 2 and go to step 3.

2. Display the DCM parameter set that will be copied to the parameter set being changed in this procedure by entering the **rtrv-dcmps** command with the **set** parameter.

For example, enter this command.

rtrv-dcmps:set=5

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SET  TIMER      TVALUE  PARM      PVALUE
1      1          4000     1          255
1      2          1500     2           1
1      3          5000     3           1
1      4         20000     4           0
1      5           0       5           0
1      6           0       6           0
1      7           0       7           0
1      8           0       8           0
1      9           0       9           0
1     10           0      10           0
```

TIMER 1: TALI T1 Timer, time (mS) between sending of TEST msgs by NE
TVALUE : Valid range = 32-bits

TIMER 2: TALI T2 Timer, time (mS) to wait for response to TEST msg
TVALUE : Valid range = 32-bits

TIMER 3: TALI T3 Timer, time (mS) to continue processing rcv'd service
msgs after NE is prohibited
TVALUE : Valid range = 32-bits

TIMER 4: TALI T4 Timer, time (mS) between sending of MONI msgs by NE
TVALUE: Valid range = 32-bits

PARM 1: Type of Service (TOS), IP header socket option
PVALUE: Valid range = lowest 8-bits

PARM 2: Nagle's Algorithm, TCP socket option
PVALUE: Valid range = lowest bit: 0 = Disable Nagle, 1 = Enable Nagle

PARM 3: Default SORP Flags socket option. Each bit is used as an
enabled/disabled flag for a particular socket option.
PVALUE: Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast Phase MTPP Primitives;	0=Disabled , 1=Enabled
1=Response Method MTPP Primitives;	0=Disabled , 1=Enabled
2=SCCP with MTP;	0=Disabled , 1=Enabled
3=ISUP via MTP;	0=Disabled , 1=Enabled
4=Group Code in MTPP;	0=Disabled , 1=Enabled
5=Use XSRV;	0=Disabled , 1=Enabled
6-31=Reserved	

3. Change the DCM parameter set information in the database by using the **chg-dcmps** command.

For example, enter this command.

chg-dcmps:set=1:timer=1:tvalue=500

If a parameter set is being copied to the parameter set changed in this procedure, only the **set** and **srcset** parameters can be specified with the **chg-dcmps** command. The **set** parameter value must be the value specified in step 1. The **scrset** parameter value must be the value specified in step 2.

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-DCMPS: MASP A - COMPLTD
```

4. Verify the new application socket information in the database by entering the **rtrv-dcmps** command. For example, enter this command.

rtrv-dcmps:set=1

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
SET  TIMER          TVALUE  PARM          PVALUE
1
1      1      1 500
1      1      255
1      2      3000      2          1
1      3      3000      3          1
1      4      10000      4          0
1      5          0      5          0
1      6          0      6          0
1      7          0      7          0
1      8          0      8          0
1      9          0      9          0
1     10          0     10          0
```

TIMER 1: TALI T1 Timer, time (mS) between sending of TEST msgs by NE
TVALUE : Valid range = 32-bits

TIMER 2: TALI T2 Timer, time (mS) to wait for response to TEST msg
TVALUE : Valid range = 32-bits

TIMER 3: TALI T3 Timer, time (mS) to continue processing rcv'd service
msgs after NE is prohibited
TVALUE : Valid range = 32-bits

TIMER 4: TALI T4 Timer, time (mS) between sending of MONI msgs by NE
TVALUE : Valid range = 32-bits

PARM 1: Type of Service (TOS), IP header socket option
PVALUE : Valid range = lowest 8-bits

PARM 2: Nagle's Algorithm, TCP socket option
PVALUE : Valid range = lowest bit: 0 = Disable Nagle, 1 = Enable Nagle

PARM 3: Default SORP Flags socket option. Each bit is used as an
enabled/disabled flag for a particular socket option.
PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast Phase MTPP Primitives;	0=Disabled , 1=Enabled
1=Response Method MTPP Primitives;	0=Disabled , 1=Enabled
2=SCCP with MTP;	0=Disabled , 1=Enabled
3=ISUP via MTP;	0=Disabled , 1=Enabled
4=Group Code in MTPP;	0=Disabled , 1=Enabled
5=Use XSRV;	0=Disabled , 1=Enabled
6-31=Reserved	


5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
```

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 4-21. Configuring a DCM Parameter Set



Notes:

1. If either the *timer* or *tvalue* parameters are specified, then both the *timer* and *tvalue* parameters must be specified.
2. If either the *parm* or *pvalue* parameters are specified, then both the *parm* and *pvalue* parameters must be specified.
3. If the *parm* parameter value is 1, the *pvalue* parameter is 0 – 255.
 If the *parm* parameter value is 2, the *pvalue* parameter value is either 0 or 1.
 If the *parm* parameter value is 3, the *pvalue* parameter value is 0 – 63. Each bit of the *pvalue* parameter value enables or disables certain functions. See the *rtrv-dcmps* command output for a list of the functions affected by the *parm*=3 parameter.

Changing the CIC Values in an Existing Routing Key Containing a Socket

This procedure is used to change the CIC values in an existing routing key using the **chg-appl-rtkey** command. These parameters are used in this procedure.

:dpc/dpca/dpci/dpcn/dpcn24 – Destination point code value that is used to filter incoming MSUs.

:opc/opca/opci/opcn/opcn24 - The originating point code value that is used to filter incoming MSUs. This value must not specify a cluster route.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value either 4, 5, or 13, or for selected service indicator values, a text string can be used instead of numbers. [Table 4-17](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 4-17. Service Indicator Text String Values

Service Indicator Value	Text String
4	tup
5	isup
13	qbicc

:cics - Starting circuit identification code that is used to filter incoming MSUs. Specify with **cice** to identify the routing key to be changed.

:cice - Ending circuit identification code that is used to filter incoming MSUs. Specify with **cics** to identify the routing key to be changed.

:ncics - New starting circuit identification code that is used to filter incoming MSUs. Specify the **ncics** parameter and/or the **ncice** parameter to change the range of circuit identification codes assigned to the routing key.

:ncice - New ending circuit identification code that is used to filter incoming MSUs. Specify the **ncice** parameter and/or the **ncics** parameter to change the range of circuit identification codes assigned to the routing key.

:split - The circuit identification code value where the specified range of CIC values for the routing key specified by the **cics** and **cice** values is to be split into two routing keys. The CIC values in one routing key ranges from the **cics** value of the original routing key to a value equal to one less than the **split** value. The CIC values in the other routing key ranges from the **split** value to the **cice** value of the original routing key. All other parameters in both routing keys remain the same as in the original routing key. The range of CIC values cannot be split if the routing key contains a routing context parameter value.

:type - Key type. Identifies the type of routing key that will be changed. One of three values, **type = full/partial/default**. If **type** is not explicitly specified, **type = full** is assumed. Only the **type=full** parameter can be used in this procedure.

The **chg-appl-rtkey** command contains other parameters that are not used in this procedure.

:ssn – The subsystem number value that is used to filter incoming MSUs. See the [Adding a Routing Key Containing a Socket](#) procedure for more information on using the **ssn** parameter with a routing key.

:pstncat – The PSTN category assigned to the routing key.

:pstnid – The PSTN ID assigned to the routing key.

:norm – Specifies whether the ISUP Normalization process is enabled or disabled for MSUs using the routing key.

:rcontext – The routing context parameter value assigned to the routing key.

:nrcontext – The new routing context parameter value.

See the [Changing the Routing Context Value in an Existing Routing Key](#) procedure for changing the routing context parameter value in an existing routing key.

See the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure for changing a routing key using the **pstncat**, **pstnid**, and **norm** parameters.

Rules for Changing the Range of CIC Values in an Existing Routing Key

The parameter combinations used by the **chg-appl-rtkey** command to change the range of CIC values in the routing key are shown in [Table 4-18](#).

Table 4-18. Routing Key Parameter Combinations for Changing the Range of CIC Values in an Existing Routing Key

SI=4 (TUP)	SI=5 (ISUP)		SI=13 (QBICC)
dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca=<the DPC assigned to the routing key> ¹	dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca/dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹
si=4 ¹	si=5 ¹	si=5 ¹	si=13 ¹
opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca=<the OPC assigned to the routing key> ¹	opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca/opci/opcn/opcn24=<the OPC assigned to the routing key> ¹
cics=<the CICS value assigned to the routing key> ^{1, 2}	cics=<the CICS value assigned to the routing key> ^{1, 2}	cics=<the CICS value assigned to the routing key> ^{1, 2}	cics=<the CICS value assigned to the routing key> ^{1, 2}
cice=<the CICE value assigned to the routing key> ^{1, 2}	cice=<the CICE value assigned to the routing key> ^{1, 2}	cice=<the CICE value assigned to the routing key> ^{1, 2}	cice=<the CICE value assigned to the routing key> ^{1, 2}
type=full	type=full	type=full	type=full
ncics=<0 to 4095> ^{2, 3}	ncics=<0 to 16383> ^{2, 3}	ncics=<0 to 4095> ^{2, 3}	ncics=<0 to 4294967295> ^{2, 3}
ncice=<0 to 4095> ^{2, 3}	ncice=<0 to 16383> ^{2, 3}	ncice=<0 to 4095> ^{2, 3}	ncice=<0 to 4294967295> ^{2, 3}
1. The values for these parameters must be entered exactly as shown in the rtrv-appl-rtkey command output for the routing key being changed. However, text strings can be used in place of some numerical service indicator values. See Table 4-17 for a list of these text strings. The text string must correspond to the numerical value shown in the routing key being changed.			

Changing the CIC Values in an Existing Routing Key Database Administration Manual - IP7 Secure Gateway Containing a Socket

SI=4 (TUP)	SI=5 (ISUP)	SI=13 (QBICC)
2. The cics and cice parameters must be specified and either the ncics or ncice parameters, or both, must be specified. If both the ncics and ncice parameters are specified, the value of the ncics parameter must be less than the value of the ncice parameter. If the ncics parameter is not specified, the value of the ncice parameter must be greater than or equal to the cics parameter value. If the ncice parameter is not specified, the value of the ncics parameter must be less than or equal to the cice parameter value. 3. The new CIC range cannot overlap the CIC range in an existing routing key.		

Rules for Splitting the Range of CIC Values in an Existing Routing Key

The parameter combinations used by the **chg-appl-rtkey** command to split the range of CIC values in the routing key are shown in [Table 4-19](#).

Splitting the range of CIC values creates two routing keys. The CIC values in one routing key ranges from the **cics** value of the original routing key to a value equal to one less than the **split** value. The CIC values in the other routing key ranges from the **split** value to the **cice** value of the original routing key. All other parameters in both routing keys remain the same as in the original routing key. The range of CIC values cannot be split if the routing key contains a routing context parameter value.

Table 4-19. Routing Key Parameter Combinations for Splitting the Range of CIC Values in an Existing Routing Key

SI=4 (TUP)	SI=5 (ISUP)		SI=13 (QBICC)
dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca=<the DPC assigned to the routing key> ¹	dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca/dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹
si=4 ¹	si=5 ¹	si=5 ¹	si=13 ¹
opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca=<the OPC assigned to the routing key> ¹	opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca/opci/opcn/opcn24=<the OPC assigned to the routing key> ¹
cics=<the CICS value assigned to the routing key> ¹	cics=<the CICS value assigned to the routing key> ¹	cics=<the CICS value assigned to the routing key> ¹	cics=<the CICS value assigned to the routing key> ¹
cice=<the CICE value assigned to the routing key> ¹	cice=<the CICE value assigned to the routing key> ¹	cice=<the CICE value assigned to the routing key> ¹	cice=<the CICE value assigned to the routing key> ¹
type=full	type=full	type=full	type=full
split=<0 to 4095> ²	split=<0 to 16383> ²	split=<0 to 4095> ²	split=<0 to 4294967295> ²
1. The values for these parameters must be entered exactly as shown in the rtrv-appl-rtkey command output for the routing key being changed. However, text strings can be used in place of some numerical service indicator values. See Table 4-17 for a list of these text strings. The text string must correspond to the numerical value shown in the routing key being changed. 2. The split parameter value must be greater than the cics parameter value and less than the cice parameter value.			

Canceling the RTRV-APPL-RTKEY Command

Because the **rtrv-appl-rtkey** command used in this procedure can output information for a long period of time, the **rtrv-appl-rtkey** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-rtkey** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-rtkey** command was entered.

- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-rtkey** command was entered, from another terminal other than the terminal where the **rtrv-appl-rtkey** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

RCONTEXT	DPCI	SI	ADPTR	ASNAME	TYPE	LOC
-----	2-100-7	6	M3UA	as4	FULL	STATIC
100	3-137-6	6	SUA	as1	FULL	STATIC
225	4-035-7	5	M3UA	as7	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-7	5	M3UA	as8	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-8	3	M3UA	as3	FULL	STATIC
-----	6-006-8	5	M3UA	as5	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
300	7-008-7	6	SUA	as6	FULL	STATIC

RCONTEXT	DPCN	SI	ADPTR	ASNAME	TYPE	LOC
-----	-----	-----	-----	-----	-----	-----

RCONTEXT	DPCN24	SI	ADPTR	ASNAME	TYPE	LOC
-----	-----	-----	-----	-----	-----	-----

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	*****	**	TALI	-----	DEFAULT	STATIC

STATIC Route Key table is (2 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (2 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

If no entries in the **rtrv-appl-rtkey** output contain the entry **TALI** in the **ADPTR** column, there are no routing keys that contain sockets in the database. This procedure cannot be performed. Perform the “Changing the CIC Values in an Existing Routing Key Containing an Application Server” procedure on page 6-300 to change the CIC values in a routing key that contains an application server.

2. Select a routing key from the **rtrv-appl-rtkey** output that contains the entry **TALI** in the **ADPTR** column.

Display the specific routing key information for the routing key being changed by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and the **DPC**, **SI**, and **TYPE** values shown in the

rtrv-appl-rtkey output in step 1 for the routing key being changed. The service indicator value for the routing key to be used in this procedure is either 4, 5, or 13.

For this example, enter these commands.

rtrv-appl-rtkey:dpc=123-234-123:si=5:type=full:display=all

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT    DPC          SI SSN OPC          CICS          CICE          LOC
----- 123-234-123 5 --- 122-124-125 1            1000        STATIC

      ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
      TALI   FULL          0         0    N    N

      SNAMEs
      kchlr11201

STATIC Route Key table is (15 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

3. Change the CIC values of the routing key by entering the **chg-appl-rtkey** command.

The parameters required for the **chg-appl-rtkey** command are determined by the type of change being made to the routing key. Go to one of these sections to determine the required parameter combination.

- Rules for Changing the Range of CIC Values in an Existing Routing Key
- Rules for Splitting the Range of CIC Values in an Existing Routing Key

To change the range of CIC values for this example, enter these commands.

chg-appl-rtkey:dpca=123-234-123:si=5:opca=122-124-125:cics=1 :cice=1000:ncice=2000

To split the range of CIC values for this example, enter this command.

chg-appl-rtkey:dpca=123-234-123:si=5:opca=122-124-125:cics=1 :cice=1000:split=500

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-RTKEY: MASP A - COMPLTD
```

4. Display the new routing key information in the database by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and with the **DPC**, **SI**, **CICS**, and **CICE** parameters and values specified in the **chg-appl-rtkey** command in step 3. If the **ncics** or **ncice** parameters were specified in step 3, the **NCICS** or **NCICE** values specified in step 3 must be specified for the **cics** or **cice** parameters in this step..

For this example, if the range of CIC values was changed, enter this command.

rtrv-appl-rtkey:dpca=123-234-123:si=5:cics=1:cice=2000 :display=all

Database Administration Manual - IP7 Secure Gateway Changing the CIC Values in an Existing Routing Key Containing a Socket

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
RCONTEXT DPC SI SSN OPC CICS CICE LOC
----- 123-234-123 5 --- 122-124-125 1 2000 STATIC
```

```
ADPTR TYPE PSTNCAT PSTNID NORM DUP
TALI FULL 0 0 N N
```

```
SNAMES
socket2
```

```
STATIC Route Key table is (15 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full
```

```
STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

For this example, if the range of CIC values was split, enter this command.

rtrv-appl-rtkey:dpca=123-234-123:si=5:cics=1:cice=1000 :display=all

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
RCONTEXT DPC SI SSN OPC CICS CICE LOC
----- 123-234-123 5 --- 100-100-100 1 499 STATIC
```

```
ADPTR TYPE PSTNCAT PSTNID NORM DUP
TALI FULL 0 0 N N
```

```
SNAMES
socket2
```

```
RCONTEXT DPC SI SSN OPC CICS CICE LOC
----- 123-234-123 5 --- 122-124-125 500 1000 STATIC
```

```
ADPTR TYPE PSTNCAT PSTNID NORM DUP
TALI FULL 0 0 N N
```

```
SNAMES
socket2
```


```
STATIC Route Key table is (16 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full
```


```
STATIC Route Key Socket Association table is (16 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-22. Changing the CIC Values in an Existing Routing Key Containing a Socket





Changing the PSTN Presentation and Normalization Attributes in a Routing Key

This procedure is used for the **ss7ipgw** and **ipgwi** applications to change the PSTN (public switched telephone network) presentation and normalization settings in a routing key using the **chg-appl-rtkey** command with these parameters.

:pstncat – The PSTN category assigned to the routing key.

:pstnid – The PSTN ID assigned to the routing key.

:norm – Specifies whether the ISUP Normalization process is enabled or disabled for MSUs using the routing key.

The PSTN presentation information is a 32-bit value indicating the format of the MTP-3 data portion of a MSU while it exists in a public switched telephone network. It consists of a PSTN category and PSTN ID value which identifies the protocol that is used to encode or decode the data in the MTP-3 portion of MSUs. The PSTN category is used to identify a logical partitioning of groups of PSTN IDs. The PSTN ID uniquely identifies a presentation within a given PSTN category.

The **pstncat**, **pstnid**, and **norm** values are used to identify the PSTN presentation and normalization attributes for the routing key. These values allow the EAGLE 5 ISS to convey the PSTN format information to IP devices and control the normalization process for MSUs using the routing key.

[Table 7-1](#) shows the PSTN presentation information used by these parameters and supported by the EAGLE 5 ISS. The values shown in the PSTN Category and PSTN ID columns in [Table 7-1](#) are used as the values for the **pstncat** and **pstnid** parameters of the **chg-appl-rtkey** command.

The information in [Table 7-1](#) is also shown in the output of the **rtrv-pstn-pres** command. The values in the **PSTNCAT Value(s)** and **Valid PSTNID Value(s) in PSTNCAT** columns in the following output example are the values that can be used by the **pstncat** and **pstnid** parameters of the **chg-appl-rtkey** command.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

PSTNCAT      PSTNID      PSTNDESC
00001        00001      ITU Q.767
00001        00002      ETSI V3
00001        00003      UK PNO-ISC7
00001        00004      GERMAN ISUP
00001        00020      MEXICO
04096        01000      User Defined 4096/1000
```

These parameters are also used by the **chg-appl-rtkey** command to change the PSTN presentation and normalization settings in the routing key.

:dpc/dpca/dpci/dpcn/dpcn24 – Destination point code value that is used to filter incoming MSUs.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value from 0 to 15, or for selected service indicator values, a text string can be used instead of numbers. [Table 4-20](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 4-20. Service Indicator Text String Values

Service Indicator Value	Text String
0	snm
1	regtest
2	spltst
3	sccp
4	tup
5	isup
13	qbicc

:opc/opca/opci/opcn/opcn24 - The originating point code value that is used to filter incoming MSUs. This value must not specify a cluster route.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:cics - Starting circuit identification code that is used to filter incoming MSUs. Specify with **cice** to identify the routing key to be changed.

:cice - Ending circuit identification code that is used to filter incoming MSUs. Specify with **cics** to identify the routing key to be changed.

:type - Key type. Identifies the type of routing key that will be changed. If the **type** parameter is not explicitly specified, **type = full** is assumed.

:ssn – The subsystem number value that is used to filter incoming MSUs.

The **chg-appl-rtkey** command also contains these parameters, but these parameters cannot be used when changing the PSTN presentation information in the routing key. For more information on these parameters, see either the [Changing the CIC Values in an Existing Routing Key Containing a Socket](#) procedure, [Changing the CIC Values in an Existing Routing Key Containing an Application Server](#) procedure, or [Changing the Routing Context Value in an Existing Routing Key](#) procedure.

:nsname – The name of the new socket that will receive the incoming MSU.

:ncics – New starting circuit identification code that is used to filter incoming MSUs.

:ncice – New ending circuit identification code that is used to filter incoming MSUs.

:split – The circuit identification code value where the specified range of the routing key specified by the **cics** and **cice** values is to be split into two entries.

:nasname – The name of the new application server that will receive the incoming MSU.

:rcontext – The routing context value assigned to the routing key.

:nrcontext – The new routing context parameter value.

The **pstnid=0** parameter can be specified only with the **pstncat=0** parameter.

The values 2 through 4095 for the **pstncat** parameter are reserved and cannot be used.

If the value of the **pstncat** parameter is from 4096 to 65536, the value of the **pstnid** parameter can be from 0 to 65535.

The **norm=no** parameter can be specified for all values of the **pstncat** parameter. The **pstncat=1** and the **pstnid=<1,2,3, or 4>** parameters are specified with the **norm=no** parameter, ISUP normalization will not be performed on MSUs using the routing key.

The **pstncat=1** parameter may only be used with 14-bit ITU-N, 24-bit ITU-N, or ITU-I point codes and when the value of the service indicator parameter is 5. The value of the **pstnid** parameter specified with the **pstncat=1** parameter can range from 1 to 32.

The **norm=yes** parameter can be specified only under these conditions:

- The value of the **pstncat** parameter must be 1
- The value of the **pstnid** parameter values can range from 1 to 32.
- The ISUP Normalization controlled feature must be enabled and its status must be on.
- The value of the service indicator parameter in the routing key must be 5.

- The point code in the routing key must be either an ITU-I, 14-bit ITU-N, or 24-bit ITU-N point code.
- The controlled feature associated with the **pstnid** parameter values 1 to 32 must be enabled and its status must be on.

The **rtrv-ctrl-feat** command shows whether or not the controlled features are enabled. If any of the required controlled features are not enabled, enter the **enable-ctrl-feat** command with the feature part number and the feature access key for the required controlled feature. The status of these controlled features is set to **on** with the **chg-ctrl-feat** command.

NOTE: If you do not have the part number or the feature access key for the required controlled feature, contact your Tekelec sales representative or account representative.

[Table 7-1](#) also shows the part numbers of the controlled features used in this procedure. The Quantity Control feature allows a customer to provision a specified quantity of user-defined variants within the PSTN categories 4096 - 65535. Each Quantity Control Feature is associated with a specific quantity of variants. To provision user-defined variants, it is necessary to purchase the appropriate Feature Access Keys from Tekelec. Variants enabled using the Quantity Control feature do not have associated PSTN Presentation values.

The part number for user-defined variants is 893-0100-nn, where nn is a number ranging from 01 to 20. Use part number 893-0100-01 to order one new variant, 893-0100-05 to order five new variants, and so on.

The values of the **dpc**, **opc**, **si**, **cics**, and **cice** parameters specified in this procedure must match the values in the routing key that is being changed in this procedure.

If the ITU National Duplicate Point Code feature is on, the values for the **dpcn** and **opcn** parameters must have group codes assigned to them. The field **ITUDUPPC** in the **rtrv-feat** command output shows whether or not the ITU National Duplicate Point Code feature is on. If group codes are specified for ITU-N DPC and OPC, the groups codes must be the same.

Canceling the RTRV-APPL-RTKEY Command

Because the **rtrv-appl-rtkey** command used in this procedure can output information for a long period of time, the **rtrv-appl-rtkey** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-rtkey** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-rtkey** command was entered, from another terminal other than the terminal where the **rtrv-appl-rtkey** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```


RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

STATIC Route Key table is (2 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (2 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

2. Display the current values of the **pstncat**, **pstnid**, and **norm** parameters of the routing key by entering the **rtrv-appl-rtkey** command with the DPC of the routing key shown in step 1 and the **display=all** parameter. For this example, enter this command.

rtrv-appl-rtkey:dpcn=12323-de:display=all

This is an example of the possible output.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT	DPCN	SI	SSN	OPCN	CICS	CICE	LOC
-----	12323-DE	5	---	12212-DE	1	1000	STATIC

ADPTR	TYPE	PSTNCAT	PSTNID	NORM	DUP
TALI	FULL	0	0	N	N

SNAMES
socket6

STATIC Route Key table is (2 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (2 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

NOTE: If the value of the norm parameter is being set to no, skip steps 3 and 4, and go to step 5.

3. Verify that the ISUP Normalization controlled feature is enabled and activated by entering the **rtrv-crtl-feat** command.

If the ISUP Normalization controlled feature is enabled, the ISUP Normalization controlled feature name should be shown in the **Feature Name** field of the output, and the status of the ISUP Normalization controlled feature, in the **Status** field, should be set to **on**. The following is an example of the possible output

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name Partnum
Zero entries found.

If the ISUP Normalization controlled feature is not enabled and turned on, go to the [Enabling Controlled Features](#) procedure and to [Turning On and Off Controlled Features](#) section to enable and turn on the ISUP Normalization controlled feature.

4. Display the PSTN presentation information supported by the EAGLE 5 ISS by entering the **rtrv-pstn-pres** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
04096 01000 User Defined 4096/1000
```

ISUP Variant table is (6 of 21) 29% full

NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

The output of the **rtrv-pstn-pres** command shows the values in the **PSTNCAT Value(s)** and **Valid PSTNID Value(s) in PSTNCAT** columns that can be used by the **pstncat** and **pstnid** parameters of the **chg-appl-rtkey** command.

If the value of the **norm** parameter is being set to **yes**, and the **rtrv-ctrl-feat** output in step 3 shows that the controlled feature that corresponds to the PSTNID parameter value being specified in this procedure is not enabled and turned on, go to the [Enabling Controlled Features](#) procedure and to [Turning On and Off Controlled Features](#) section to enable and turn on the required controlled feature.

[Table 7-1](#) shows the part numbers of the controlled features and the **ptsnid** parameter values that can be used in this procedure.

NOTE: If 14-bit ITU-N point codes (dpcn, opcn) are not being specified for the routing key, skip step 5 and go to step 6.

5. Verify whether or not the ITU National Duplicate Point Code feature is on, by entering the **rtrv-feat** command.

If the ITU National Duplicate Point Code feature is on, the **ITUDUPPC** field will be set to **on**.

NOTE: The rtrv-feat command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the rtrv-feat command, see the rtrv-feat command description in the Commands Manual.

6. Change PSTN presentation information in the routing key by entering the **chg-appl-rtkey** command with the **pstncat**, **pstnid**, and **norm** parameters.

```
chg-appl-rtkey:dpcn=12323-de:si=5:opc=12212-
de:cics=1 :cice=1000:pstncat=1:pstnid=2:norm=yes
```

NOTE: If the DPC and OPC values are ITU-N point codes, these point codes must have group codes assigned to them if the ITU National Duplicate Point Code feature is on. The ITUDUPPC field in the rtrv-feat command executed in step 5 shows whether or not the ITU National Duplicate Point Code feature is on.

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-RTKEY: MASP A - COMPLTD
```

7. Verify the new values of the **pstncat**, **pstnid**, and **norm** parameters that were changed in step 6 by entering the **rtrv-appl-rtkey** command with the DPC of the routing key specified in step 6 and the **display=all** parameter. For this example, enter this command.

rtrv-appl-rtkey:dpcn=12323-de:display=all

This is an example of the possible output

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT   DPCN           SI SSN OPCN           CICS      CICE      LOC
-----
12323-DE    5 --- 12212-DE    1         1000     STATIC

ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
TALI   FULL          1        2   Y    N

SNAMES
socket6


STATIC Route Key table is (2 of 2000) 1% full
1105   Route Key table is (2 of 500) 1% full
1107   Route Key table is (2 of 500) 1% full


STATIC Route Key Socket Association table is (2 of 32000) 1% full
1105   Route Key Socket Association table is (2 of 8000) 1% full
1107   Route Key Socket Association table is (2 of 8000) 1% full
```

8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 4-23. Changing the PSTN Presentation and Normalization Attributes in an Routing Key








Notes:

1. The *norm=yes* parameter is only required if the ISUP Normalization feature is to be used for the MSUs using the routing key.
2. The values for the DPC, OPC, SI, CICS, and CICE parameters must match the values shown in the routing key being changed.
3. If the Duplicate Point Code feature is on, the DPCN and OPCN values must have a group code assigned to the point code. If both the DPCN and OPCN parameters are specified, the group codes must be the same. The ITUDUPPC field in the *rtrv-feat* command shows whether or not this feature is on.









Configuring the IP TPS Alarm Threshold

The IP TPS alarm threshold is the percentage of the IPGWx signaling TPS at which an alarm is raised. This threshold is set with the **iptpsalmthresh** parameter of the **chg-sg-opts** command. The values for the **iptpsalmthresh** parameter are from 10 to 100 percent, with the system default value of 80 percent. The value of the IP TPS alarm threshold is shown in the **IPTPSALMTHRESH** field of the **rtv-sg-opts** command output.

When this threshold is exceeded, UAM 0114, System IP TPS Threshold exceeded, is generated. UAM 0114 is automatically cleared when the percentage of the IPGWx signaling TPS calculated by the EAGLE 5 ISS falls below the value of the **iptpsalmthresh** parameter value. UAM 0117, System IP TPS normal, is generated when UAM 0114 is cleared.



CAUTION: UAM 0114 is also generated if the IP TPS alarm threshold is set to a percentage that is less than the current percentage of the IPGWx signaling TPS calculated by the EAGLE 5 ISS. If UAM 0114 is not automatically cleared after performing this procedure, perform the alarm clearing procedure for UAM 0114 in the *Maintenance Manual*.

Procedure

1. Display the current IP options in the database by entering the **rtrv-sg-opts** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
IPTPSALMTHRESH: 80
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

2. Change the IP TPS alarm threshold using the **chg-sg-opts** command and the **iptpsalmthresh** parameter. For this example, enter this command.

chg-sg-opts:iptpsalmthresh=90

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
CHG-SG-OPTS: MASP A - COMPLTD
```



CAUTION: UAM 0114 is generated if the IP TPS alarm threshold is set to a percentage that is less than the current percentage of the IPGWx signaling TPS calculated by the EAGLE 5 ISS. If UAM 0114 is not automatically cleared after performing this procedure, perform the alarm clearing procedure for UAM 0114 in the *Maintenance Manual*.


3. Verify the new IP options in the database using the **rtrv-sg-opts** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
IPTPSALMTHRESH: 90
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-24. Configuring the IP TPS Alarm Threshold

IETF M2PA Configuration Procedures

Adding IETF IPLIMx Components	5-1
Adding an IPLIMx Card	5-3
Adding an IPLIMx Signaling Link	5-7
Enabling the Large System # Links Controlled Feature	5-17
Configuring an IP Link	5-26
Adding an IP Host	5-42
Configuring an IP Card	5-46
Adding an IP Route	5-54
Adding an M2PA Association	5-60
Activating the Large BICC MSU Support for IP Signaling Feature	5-73
Removing IETF M2PA Components	5-80
Removing an IPLIMx Card	5-81
Removing an IPLIMx Signaling Link	5-82
Removing an IP Host Assigned to an IPLIMx Card	5-90
Removing an IP Route	5-95
Removing an M2PA Association	5-99
Changing IETF M2PA Components	5-101
Changing an M2PA Association	5-102
Configuring SCTP Retransmission Control for an M2PA Association	5-123
Changing an M2PA Timer Set	5-129
Changing the SCTP Checksum Algorithm Option for M2PA Associations	5-136
Turning the Large BICC MSU Support for IP Signaling Feature Off	5-143

Adding IETF IPLIMx Components

This section describes how to configure the components necessary to establish IP connections using M2PA associations on IPLIMx signaling links. IPLIMx signaling links are signaling links assigned to cards running either the IPLIM or IPLIMI applications. The IPLIM application supports point-to-point connectivity for ANSI networks. The IPLIMI application supports point-to-point connectivity for ITU networks.

The configuration of these IP connections consists of these items.

1. Configure the IPLIMx card with the [Adding an IPLIMx Card](#) procedure.

2. Configure the required destination point codes - see Chapter 2, “Configuring Destination Tables,” in the *Database Administration Manual - SS7*.
3. Configure the required IPLIMx linksets - see Chapter 3, “SS7 Configuration,” in the *Database Administration Manual - SS7*.
4. Configure the IPLIMx signaling links with the [Adding an IPLIMx Signaling Link](#) procedure. The **ipliml2=m2pa** parameter of the **ent-slk** command must be specified for these signaling links. If the addition of these signaling links will exceed the current number of signaling links the EAGLE 5 ISS is allowed to have, the [Enabling the Large System # Links Controlled Feature](#) procedure will have to be performed to increase the quantity of signaling links.
5. Configure the required routes - see Chapter 3, “SS7 Configuration,” in the *Database Administration Manual - SS7*.
6. IP addresses must be assigned to the IPLIMx card configured in step 1 by performing the [Configuring an IP Link](#) procedure. There are other IP link parameters that are assigned to the IPLIMx card when the IPLIMx card is configured. Default values are assigned to these parameters when the IPLIMx card is configured. These values can be displayed by the **rtrv-ip-lnk** command. These values can be changed by performing the [Configuring an IP Link](#) procedure.
7. Local IP hosts, assigned to the IP addresses assigned to step 6, must be configured in the database by performing the [Adding an IP Host](#) procedure. Verify the hosts with the **rtrv-ip-host** command. This establishes a relationship between the IP card related information and the socket related information.
8. When the IP cards are added to the database in step 1, there are IP parameters that control the IP stack that are assigned default values. These parameter values can be displayed by the **rtrv-ip-card** command. These values can be changed by performing the [Configuring an IP Card](#) procedure.
9. Static IP routes provide more flexibility in selecting the path to the remote destination and reduces the dependence on default routers. Static IP routes are provisioned by performing the [Adding an IP Route](#) procedure.
10. Associations specify a connection between a local host/TCP port and a remote host/TCP port. Three types of associations can be provisioned: M2PA, M3UA, and SUA. Associations that are assigned to IPLIMx signaling links must be M2PA associations. The **ipliml2=m2pa** parameter must be assigned to the signaling link that is assigned to an M2PA association. The M2PA association is configured by performing the [Adding an M2PA Association](#) procedure. M3UA and SUA associations are provisioned with the [Adding an M3UA or SUA Association](#) procedure. A number of fields in the association cannot be configured with the [Adding an M2PA Association](#) procedure and are set to default values. The values of these fields can be displayed using the **rtrv-assoc** command after the [Adding an M2PA Association](#) procedure is performed. These values can be changed by performing the [Changing an M2PA Association](#) procedure. An IPLIMx card can have one socket for each signaling link assigned to the card.
11. There are two versions of M2PA associations, RFC and Draft 6, that can be configured in the database. When an M2PA association is added to the database with [Adding an M2PA Association](#) procedure, the association is configured as an RFC M2PA association. The RFC version of M2PA timer set 1 is also assigned to the association when the M2PA association is added to the database.

There are two different versions, RFC and Draft 6, of M2PA timer sets that can be assigned to M2PA associations. Each version of the M2PA timer sets contains 20 timer sets. The values of these timer sets can be changed with the [Changing an M2PA Timer Set](#) procedure.

The version of the M2PA association and the M2PA timer set assigned to the association can be changed with [Changing an M2PA Association](#) procedure. The M2PA version of the association determines the version of the M2PA timer set that is assigned to the association. For example, if M2PA timer set 3 is assigned to the M2PA association, and the association is an RFC M2PA association, the RFC version of M2PA timer

set 3 is used with the association. If M2PA timer set 7 is assigned to the M2PA association, and the association is a Draft 6 M2PA association, the Draft 6 version of M2PA timer set 7 is used with the association.

12. The EAGLE 5 ISS processes messages with a service information field (SIF) that is 272 bytes or smaller. The Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature allows the EAGLE 5 ISS to process BICC messages with a SIF that is larger than 272 bytes. Perform the [Activating the Large BICC MSU Support for IP Signaling Feature](#) procedure to enable and turn on the Large BICC MSU Support for IP Signaling feature.

Adding an IPLIMx Card

This procedure is used to add an IPLIMx card to the database using the **ent-card** command. An IPLIMx card is a card that is running either the IPLIM or IPLIMI applications. A maximum of 100 IPLIMx cards can be provisioned in the database. [Table 5-1](#) shows the cards that can be provisioned in this procedure.

Table 5-1. IPLIMx Card Types

Card Type	Part Number
Single-Slot EDCM	870-2372-01, 870-2372-08, 870-2372-13
E5-ENET	870-2212-xx

The **ent-card** command uses these parameters.

:loc – The location of the card being added to the database.

:type – The type of card being added to the database. For this procedure, the value of this parameter is **dcm**.

:appl – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is **iplim** for ANSI IP network connections or **iplimi** for ITU IP network connections.

:force – If the global title translation feature is on, the **force=yes** parameter allows the LIM to be added to the database even if the current SCCP transactions-per-second threshold is unable to support the additional SCCP transaction-per-second capacity created by adding the IP card. This parameter is obsolete and is no longer used.

Card Slot Selection

The single-slot EDCM and E5-ENET card can be inserted into any card slot, except for card slots that must remain empty to accommodate dual-slot cards, slots 09 and 10 in each shelf, and slots 1113 through 1118.

To provision a E5-ENET card, the shelf containing the E5-ENET card must have HIPR cards installed in slots 9 and 10 in that shelf. If HIPR cards are not installed in the shelf that the E5-ENET card will occupy, the E5-ENET card will be auto-inhibited when the E5-ENET card is inserted into the shelf. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the same shelf as the E5-ENET card being provisioned in this procedure.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output. Cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM          SCCP
1102   TSM          GLS
```

1113	GSPM	EOAM						
1114	TDM-A							
1115	GSPM	EOAM						
1116	TDM-B							
1117	MDAL							
1201	LIMDS0	SS7ANSI	sp2	A	0	sp1	B	0
1203	LIMDS0	SS7ANSI	sp3	A	0			
1204	LIMDS0	SS7ANSI	sp3	A	1			
1206	LIMDS0	SS7ANSI	nsp3	A	1	nsp4	B	1
1207	LIMV35	SS7GX25	nsp1	A	0			
1208	LIMV35	SS7GX25	nsp1	A	1			
1216	ACMENET	STPLAN						
1301	LIMDS0	SS7ANSI	sp6	A	1	sp7	B	0
1302	LIMDS0	SS7ANSI	sp7	A	1	sp5	B	1
1303	DCM	IPLIM	ipnode1	A	0	ipnode3	B	1
1305	DCM	IPLIM	ipnode4	A	0			
1307	ACMENET	STPLAN						

If the required unprovisioned card slots (see the "Card Slot Selection" section) are shown in the **rtrv-card** output, skip steps 2 and 3, and go to step 4.

If the required unprovisioned card slots are not shown in the **rtrv-card** output, step 2 must be performed.

2. Display the shelves in the database by entering the **rtrv-shlf** command. This is an example of the possible output.

```
rlghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
SHELF DISPLAY
FRAME SHELF      TYPE
1      1      CONTROL
1      2      EXTENSION
1      3      EXTENSION
```

If all the shelves are provisioned in the database, then this procedure cannot be performed. There are no available card slots for the new IPLIMx card.

If all the shelves have not been provisioned in the database, go to step 3.

3. Add the required shelf using the **ent-shlf** command with the location of the shelf and the **type=ext** parameter. The shelf location values are 1200, 1300, 2100, 2200, 2300, 3100, 3200, 3300, 4100, 4200, 4300, 5100, 5200, 5300, and 6100. For this example, enter this command.

ent-shlf: loc=2100: type=ext

When this command has successfully completed, this message should appear.

```
rlghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
ENT-SHLF: MASP A - COMPLTD
```

4. Verify that the card to be entered has been physically installed into the proper location (see the "Card Slot Selection" section).



CAUTION: If the version of the BPDCM GPL on the IP card does not match the BPDCM GPL version in the database when the IP card is inserted into the card slot, UAM 0002 is generated indicating that these GPL versions do not match. If UAM 0002 has been generated, perform the alarm clearing procedure for UAM 0002 in the *Maintenance Manual* before proceeding with this procedure.

NOTE: If the card being added in this procedure is not an E5-ENET card, skip step 5 and go to step 6.

5. Verify that HIPR cards are installed in card locations 9 and 10 in the shelf containing the E5-ENET card being added in this procedure. Enter this command.

rept-stat-gpl:gpl=hipr

This is an example of the possible output.


```

rlghncxa03w 06-10-01 11:40:26 GMT EAGLE5 36.0.0
GPL
CARD
RUNNING
APPROVED
TRIAL
HIPR      1109      125-002-000      125-002-000      125-003-000
HIPR      1110      125-002-000      125-002-000      125-003-000
HIPR      1209      125-002-000      125-002-000      125-003-000
HIPR      1210      125-002-000      125-002-000      125-003-000
HIPR      1309      125-002-000      125-002-000      125-003-000
HIPR      1310      125-002-000      125-002-000      125-003-000
HIPR      2109      125-002-000      125-002-000      125-003-000
HIPR      2110      125-002-000      125-002-000      125-003-000
Command Completed

```

If HIPR cards are installed in the shelf containing the E5-ENET card, go to step 6.

If HIPR cards are not installed on the shelf containing the E5-ENET card, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 6.

6. Add the card using the **ent-card** command. For this example, enter these commands.

```
ent-card: loc=1311: type=dc: appl=iplim
```

```
ent-card: loc=1313: type=dc: appl=iplimi
```

When each of these commands have successfully completed, this message should appear.

```

rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD

```

7. Verify the changes using the **rtrv-card** command with the card location specified in step 6. For this example, enter these commands.

```
rtrv-card: loc=1311
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1311  DCM        IPLIM

```

```
rtrv-card: loc=1313
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1313  DCM        IPLIMI

```


8. Back up the new changes using the **chg-db: action=backup: dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Flowchart 5-1. Adding an IP Card





Adding an IPLIMx Signaling Link

This procedure is used to add an IPLIMx signaling link to the database using the **ent-slk** command. The **ent-slk** command uses these parameters.

: loc – The card location of the IP card that the IP signaling link will be assigned to. The cards specified by this parameter are IPcards running the IPLIM or IPLIMI applications.

: link – The signaling link on the card specified in the **loc** parameter.

: lsn – The name of the linkset that will contain the signaling link.

: slc – The signaling link code. The SLC must be unique within the linkset. It must be the same at both the EAGLE 5 ISS location and the distant node.

: ipliml2 – The L2 protocol stack to be assigned to the IP signaling link, M2PA (the default value).

The **ent-slk** command also contains these parameters, **l2tset**, **l1mode**, **bps**, **tset**, **ecm**, **pcrn1**, **pcrn2**, **lpset**, **atmtsel**, **vci**, **vpi**, **ll**, **e1atmcrc4**, **e1atmsi**, **e1atmsn**, **ts**, **e1port**, **e1loc**, **t1port**, and **t1loc**. These parameters are used only for configuring low-speed, ATM high-speed, E1, and T1 signaling links and are not used in this procedure. For more information on configuring these types of signaling links, see the *Database Administration Manual - SS7*.

These items must be configured in the database before an IP signaling link can be added:

- Shelf – perform the "Adding a Shelf" procedure in the *Database Administration Manual - System Management*.
- Card – perform the [Adding an IPLIMx Card](#) procedure
- Destination Point Code – perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7*.
- Linkset – perform the "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

Verify that the link has been physically installed (all cable connections have been made).

To configure the EAGLE 5 ISS to perform circular routing detection test on the signaling links, "Configuring Circular Route Detection" procedure in the *Database Administration Manual - SS7*.

NOTE: Circular route detection is not supported in ITU networks.

To provision a EAGLE 5 ISS with more than 700 signaling links, the EAGLE 5 ISS must have certain levels of hardware installed. See the "Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links" section for more information on these hardware requirements.

The EAGLE 5 ISS can contain a mixture of low-speed, E1, T1, ATM high-speed, and IP signaling links. The "Determining the Number of High-Speed and Low-Speed Signaling Links" section describes how to determine the quantities of the different types of signaling links the EAGLE 5 ISS can have.

Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links

To provision an EAGLE 5 ISS with more than 700 signaling links (currently the EAGLE 5 ISS can have maximum capacities of 1200, or 1500, or 2000 signaling links), the following additional requirements must be met:

- The Measurements Platform feature must be enabled. Perform these procedures in the *Database Administration Manual - System Management* to enable the Measurements Platform Feature:
 - "Adding an MCPM"
 - "Configuring the IP Communications Link for the Measurements Platform Feature"
 - "Adding an FTP Server"

- To provision more than 1200 signaling links, the Large System # Links controlled feature must be enabled for 1500 or 2000 signaling links. For more information on enabling this feature, go to the [Enabling the Large System # Links Controlled Feature](#) procedure.

Determining the Number of High-Speed and Low-Speed Signaling Links

An EAGLE 5 ISS containing either 1200, or 1500, or 2000 signaling links can contain the following quantities of signaling links:

- 180 high-speed ATM signaling links assigned to the ATMANSI application. If there are any high-speed ATM signaling links assigned to the ATMITU application, the maximum number of high-speed ATM signaling links is 115.
- 100 signaling links assigned to either the IPLIM or IPLIMI applications.
- 64 signaling links assigned to either the **ss7ipgw** or **ipgwi** application, or combinations of the **ss7ipgw** and **ipgwi** applications.
- 64 unchannelized E1 signaling links.

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET running either the **iplimi** or **ipgwi** applications.
- E1-ATM running the **atmitu** application.

Canceling the REPT-STAT-SLK, RTRV-LS, and RTRV-SLK Commands

Because the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands used in this procedure can output information for a long period of time, the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered, from another terminal other than the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current signaling link configuration using the **rtrv-sl** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
```

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	L1 MODE	TSET	ECM	PCR N1	PCR N2
1201	B	lsa1	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1203	B	lsa2	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1205	A	lsa3	0	LIMV35	3	64000	DCE	ON	BASIC	---	-----
1207	A	lsn1207a	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1207	B	lsn1207b	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1214	A	lsn1214a	0	LIMV35	2	64000	DTE	---	PCR	76	3800
1214	B	lsa3	1	LIMV35	3	64000	DCE	ON	BASIC	---	-----

LOC	LINK	LSN	SLC	TYPE	LP SET	BPS	ATM TSEL	VCI	VPI	LL
No Links Set up.										

LOC	LINK	LSN	SLC	TYPE	LP SET	BPS	ATM TSEL	VCI	VPI	E1ATM CRC4 SI SN
No Links Set up.										

LOC	LINK	LSN	SLC	TYPE	IPLIML2
No Links Set up.					

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	E1 LOC	E1 PORT TS
No Links Set up.											

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	T1 LOC	T1 PORT TS
No Links Set up.											

SLK table is (7 of 1200) 1% full.

If the **rtrv-sl** output shows that the maximum number of signaling links is 2000, go to step 2.

If the **rtrv-sl** output shows that the maximum number of signaling links is 1200, and the signaling link being added increases the number beyond 1200, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for either 1500 signaling links or 2000 signaling links. Then go to step 2.

If the **rtrv-sl** output shows that the maximum number of signaling links is 1500, and the signaling link being added increases the number beyond 1500, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for 2000 signaling links. Then go to step 2.

If the addition of the new signaling link will not exceed the maximum number of signaling links, go to step 2.

2. Display the current linkset configuration using the **rtrv-ls** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

LSN	APCA	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
e1e2	001-207-000		none	1	1	no	B	6	off	off	off	no	off
ls1305	000-005-000		none	1	1	no	A	1	off	off	off	no	off
ls1307	000-007-000		none	1	1	no	A	1	off	off	off	no	off
e1m1s1	001-001-001		none	1	1	no	A	7	off	off	off	no	off
e1m1s2	001-001-002		none	1	1	no	A	7	off	off	off	no	off

L3T	SLT	GWS	GWS	GWS

```

LSN          APCA   (X25)  SCRNLST LNKS ACT MES DIS SLSCI NIS
          L3T SLT          GWS GWS GWS
LSN          APCI   (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
e1e2i        1-207-0      none 1 1 no B 4 off off off --- on
ls1315       0-015-0      none 1 1 no A 1 off off off --- off
ls1317       0-017-0      none 1 1 no A 1 off off off --- on
e1m2s1       1-011-1      none 1 1 no A 7 off off off --- off
e1m2s2       1-011-2      none 1 1 no A 7 off off off --- off

LSN          APCN   (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
          L3T SLT          GWS GWS GWS
LSN          APCN24 (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
          L3T SLT          GWS GWS GWS
LSN (CHINA)  APCN   (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
          L3T SLT          GWS GWS GWS
LSN (CHINA)  APCN24 (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS

```

Link set table is (10 of 1024) 1% full.

If the required linkset is not in the database, perform the "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7* to add the linkset to the database. After the new linkset has been added, skip step 3 and go to step 4.

If the signaling link will be assigned to the linkset shown in this step, go to step 3.

3. Display the linkset that the signaling link is being assigned to using the **rtrv-ls** command, specifying the name of the linkset that the signaling link is being assigned to.

For this example, enter this command.

rtrv-ls:lsn=lsnipgw

This is an example of the possible output.

```

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
          L3T SLT          GWS GWS GWS
LSN          APCI   (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
lsnipgw      2968      none 1 1 no A 1 off off off --- off

CLLI          TFATCABMLQ MTPRSE ASL8 SLSRSB MULTGC ITUTFR
----- 1          no    --- 1          yes    off

IPGWAPC MATELSN IPTPS LSUSEALM SLKUSEALM GTTMODE
no          ---    ---    ---    CdPA

LOC LINK SLC TYPE          L2T          L1          PCR PCR
SET BPS          MODE TSET ECM N1 N2

LOC LINK SLC TYPE          LP          ATM          VCI VPI LL
SET BPS          TSEL

LOC LINK SLC TYPE          LP          ATM          VCI VPI CRC4 SI SN
SET BPS          TSEL

LOC LINK SLC TYPE          IPLIML2
1317 A          0 IPLIMI SAALTALI

LOC LINK SLC TYPE

LOC LINK SLC TYPE          L2T          PCR PCR E1 E1
SET BPS          ECM N1 N2 LOC PORT TS

LOC LINK SLC TYPE          L2T          PCR PCR T1 T1
SET BPS          ECM N1 N2 LOC PORT TS

SAPCI

```

1-10-1

SAPCN
1234-aa
1235-bb
1200-zz

Link set table is (13 of 1024) 1% full.

Linksets can contain a mixture of signaling link types unless the card application is SS7IPGW or IPGWI.

4. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1102   TSM         GLS
1103   DCM         VXWSLAN
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0      SS7ANSI   lsa1           B      0
1202   LIMV35      SS7ANSI
1203   LIMDS0      SS7ANSI   lsa2           B      0
1204   LIMDS0      SS7ANSI
1205   LIMV35      SS7ANSI   lsa3           A      0
1206   LIMV35      SS7ANSI
1207   LIMDS0      SS7ANSI   lsn1207a       A      0   lsn1207b       B      0
1208   LIMDS0      SS7ANSI
1212   LIMV35      SS7ANSI
1213   LIMDS0      SS7ANSI
1214   LIMV35      SS7ANSI   lsn1214a       A      0   lsa3           B      1
1215   LIMDS0      SS7ANSI
1301   LIMV35      ATMANSI
1302   LIMATM      ATMANSI
1304   LIMV35      SS7ANSI
1305   LIMATM      ATMANSI
1308   LIMV35      SS7ANSI
1311   LIMDS0      SS7ANSI
1313   LIMDS0      SS7ANSI
1315   LIMV35      CCS7ITU
1317   LIMV35      CCS7ITU
1318   LIMATM      ATMANSI
```

If the required card is not in the database, perform the [Adding an IPLIMx Card](#) procedure and add the IP card to the database.

NOTE: If the linkset that the signaling link will be added to contains the `multgc=yes` parameter, the application assigned to the card must be IPLIMI.

5. Add the signaling link to the database using the **ent-slk** command.

[Table 5-2](#) shows the parameters and values that can be specified with the **ent-slk** command.

Table 5-2. M2PA IPLIMx Signaling Link Parameter Combinations

M2PA IPLIMx Signaling Link
Mandatory Parameters
:loc = location of the IP card with one of these applications: IPLIM or IPLIMI; and the DCM card type. ¹
:link = <see Note 2>
:lsn = linkset name ³
:slc = 0 - 15 ⁴
Optional Parameter

M2PA IPLIMx Signaling Link			
:ipliml2 = m2pa, default value = m2pa			
Notes:			
1. If the multgc=yes parameter is assigned to the linkset, the card's application must be IPLIMI.			
2. The range of link parameter values is dependent on the type of IPLIMx card that is being provisioned.			
Type of Card	Link Parameter Values	Single-Slot EDCM	A - A3, B - B3 E5-ENET A - A7, B - B7
3. If the card's application is IPLIMI, the linkset adjacent point code must be ITU. If the card's application is IPLIM, the linkset adjacent point code must be ANSI. The domain of the linkset adjacent point code must be SS7.			
4. Signaling links provisioned in this procedure can be in a linkset that contains non-IPLIMx signaling links.			

For this example, enter these commands.

```
ent-slk:loc=2204:link=b:lsn=lsnlp2:slc=0:ipliml2=m2pa
```

```
ent-slk:loc=2205:link=a:lsn=lsnlp1:slc=1:ipliml2=m2pa
```

```
ent-slk:loc=2213:link=a:lsn=lsnlp5:slc=1:ipliml2=m2pa
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:29:03 GMT EAGLE5 36.0.0
ENT-SLK: MASP A - COMPLTD
```

6. Verify the changes using the **rtrv-slk** command with the card location and **link** parameter values specified in step 5. For this example, enter these commands.

```
rtrv-slk:loc=2204:link=b
```

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN      SLC TYPE    IPLIML2
2204 B   lsnlp2    0  IPLIM    M2PA
```

```
rtrv-slk:loc=2205:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN      SLC TYPE    IPLIML2
2205 A   lsnlp1    1  IPLIM    M2PA
```

```
rtrv-slk:loc=2213:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN      SLC TYPE    IPLIML2
2213 A   lsnlp5    0  IPLIM    M2PA
```

7. If any cards contain the first signaling link on a card, those cards must be brought into service with the **rst-card** command, specifying the location of the card. For this example, enter these commands.

```
rst-card:loc=2204
```

```
rst-card:loc=2205
```

```
rst-card:loc=2213
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-23 13:05:05 GMT EAGLE5 36.0.0
Card has been allowed.
```

8. Activate all signaling links on the cards using the **act-slk** command, specifying the card location and **link** parameter value of each signaling link. For this example, enter these commands.

```
act-slk:loc=2204:link=b
```

```
act-slk:loc=2205:link=a
```

```
act-slk:loc=2213:link=a
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:31:24 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

9. Check the status of the signaling links added in step 5 using the **rept-stat-slk** command with the card location and link parameter values specified in step 5. The state of each signaling link should be in service normal (IS-NR) after the link has completed alignment (shown in the PST field). For this example, enter these commands.

```
rept-stat-slk:loc=2204:link=b
```

This is an example of the possible output.

```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2204,B   lsnlp2   -----  IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```

```
rept-stat-slk:loc=2205:link=a
```

This is an example of the possible output.

```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2205,A   lsnlp1   -----  IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```

```
rept-stat-slk:loc=2213:link=a
```


This is an example of the possible output.


```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2213,A   lsnlp5   -----  IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```


10. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-2. Adding an IPLIMx Signaling Link







Enabling the Large System # Links Controlled Feature

This procedure is used to enable the Large System # Links controlled feature using the feature's part number and a feature access key.

The feature access key for the Large System # Links controlled feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

This feature allows the EAGLE 5 ISS to contain a maximum of either 1500 or 2000 signaling links.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key generated by Tekelec's feature access key generator, and supplied to you when you purchase or temporarily try a controlled feature. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number associated with the signaling link quantity being enabled:

- 893005901 for the 1500 signaling link quantity
- 893005910 for the 2000 signaling link quantity.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent-serial-num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature is enabled with the **enable-ctrl-feat** command, the feature is also activated. The **chg-ctrl-feat** command is not necessary to activate the feature.

This feature cannot be disabled with the **chg-ctrl-feat** command and the **status=off** parameter.

Hardware Supported for Signaling Link Quantities Greater than 1500

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 card running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET card running either the **iplimi** or **ipgwi** applications.
- E1-ATM card running the **atmitu** application.

To increase the signaling link quantity to more than 1500 signaling links, HIPR cards must be installed into card locations 9 and 10 in each shelf in the EAGLE 5 ISS. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the EAGLE 5 ISS shelves.

Procedure

1. Display the status of the Large System # Links controlled feature by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the **rtrv-ctrl-feat** output shows that the controlled feature is enabled for the desired quantity or for a quantity that is greater than the desired quantity, no further action is necessary. This procedure does not need to be performed.

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, skip steps 2 through 5, and go to step 6.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

```
ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>;lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Verify that HIPR cards are installed in card locations 9 and 10 in each shelf of the EAGLE 5 ISS.

NOTE: If the 2000 signaling link quantity is not being enabled in this procedure, skip step 6 and go to step 7.

Enter this command.

rept-stat-gpl:gpl=hipr

This is an example of the possible output.

```
rlghncxa03w 06-10-01 11:40:26 GMT EAGLE5 36.0.0
GPL      CARD      RUNNING      APPROVED      TRIAL
HIPR     1109      126-002-000    126-002-000    126-003-000
HIPR     1110      126-002-000    126-002-000    126-003-000
HIPR     1209      126-002-000    126-002-000    126-003-000
HIPR     1210      126-002-000    126-002-000    126-003-000
HIPR     1309      126-002-000    126-002-000    126-003-000
HIPR     1310      126-002-000    126-002-000    126-003-000
HIPR     2109      126-002-000    126-002-000    126-003-000
HIPR     2110      126-002-000    126-002-000    126-003-000
Command Completed
```

If HIPR cards are installed in each the shelf in the EAGLE 5 ISS, go to step 7.

If HIPR cards are not installed on each shelf in the EAGLE 5 ISS, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 7.

NOTE: Before the 2000 signaling link quantity is enabled, make sure the EAGLE 5 ISS is configured with the signaling link hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section.

If signaling hardware other than the hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section is installed and provisioned, contact the Customer Care Center before enabling the 2000 signaling link quantity. Refer to [Customer Care Center](#) for the contact information.

7. Enable the Large System # Links controlled feature for the desired quantity with the **enable-ctrl-feat** command specifying the part number corresponding to the new quantity of signaling links and the feature access key.

To increase the number of signaling links the EAGLE 5 ISS can contain to 1500, enter this command.

enable-ctrl-feat:partnum=893005901:fak=<feature access key>

To increase the number of signaling links the EAGLE 5 ISS can contain to 2000, enter this command.

enable-ctrl-feat:partnum=893005910:fak=<feature access key>

NOTE 1: A temporary feature access key cannot be specified to enable this feature.

NOTE 2: The values for the feature access key (the fak parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-crtl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the part number specified in step 7.

If the 1500 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005901

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005901	on	1500

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the 2000 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005910

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Enabling the Large System # Links Controlled Feature Database Administration Manual - IP7 Secure Gateway

Feature Name	Partnum	Status	Quantity
Large System # Links	893005910	on	2000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-3. Enabling the Large System # Links Controlled Feature







Configuring an IP Link

This procedure is used to configure the link parameters for IP cards using the **chg-ip-lnk** command. These link parameters are used to configure the Ethernet hardware.

The **chg-ip-lnk** command uses the following parameters.

:loc – The card location of the IP card.

:port – The Ethernet interface on the IP card, A or B.

:ipaddr – IP address assigned to the Ethernet interface on the IP card. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:submask – The subnet mask of the IP interface. A subnet mask is an IP address with a restricted range of values. The bits in the mask must be a string of one’s followed by a string of zero’s. There must be at least two one’s in the mask, and the mask cannot be all one’s. See [Table 5-3](#) to assign the correct parameter values.

:auto – Tells hardware whether to automatically detect the **duplex** and **speed**.

:duplex – This is the mode of operation of the interface.

:speed – This is the bandwidth in megabits per second of the interface.

:mactype – This is the Media Access Control Type of the interface.

:mcast – The multicast control flag. This parameter enables or disables multicast support for the interface.

A zero **ipaddr** parameter value (**0.0.0.0**) indicates the IP card Ethernet interface to IP link association is disabled. The host to the original IP address must be removed before the **ipaddr=0.0.0.0** can be specified.

If the **defrouter** parameter of the **chg-ip-card** command contains an IP address for the card specified in this procedure, the network portion of one of the IP addresses assigned to the card in this procedure must match the network portion of the IP address specified by the **defrouter** parameter of the **chg-ip-card** command.

The network portion of the IP address is based on the class of the IP address (shown in [Table 5-3](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

If the **auto=yes** parameter is specified, then the **duplex** and **speed** parameters are not allowed.

The **loc** parameter value must be shown in the **rtrv-ip-card** output.

The IP card must be placed out of service.

If either the **ipaddr** or **submask** parameters are specified, then both parameters must be specified. If the **ipaddr** parameter value is zero (**0.0.0.0**), the **submask** parameter is not required.

The IP address and subnet mask values cannot be changed to an address representing a different network if:

- If the network interface specified by the **loc** and **port** parameters has a default router, **dnsa**, or **dsnb** parameter values assigned to it, as shown in the **rtrv-ip-card** output.
- Any IP routes, shown in the **rtrv-ip-rte** output, reference the IP address for the network interface specified by the **loc** and **port** parameters.

The IP link cannot be changed if open sockets or associations reference the IP link being changed.

The network portion of the IP addresses assigned to the IP links on an IP card must be unique. For example, if IP links are assigned to IP card 1103, the network portion of the IP address for Ethernet interface A (**port=a**) must be different from the IP address for Ethernet interface B (**port=b**).

The **submask** parameter value is based upon the **ipaddr** setting. See [Table 5-3](#) for the valid input values for the **submask** and **ipaddr** parameter combinations.

Table 5-3. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0 255.224.0.0 255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.0.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **ipaddr** parameter of the **chg-ip-lnk** command, the subnet address that results from the **ipaddr** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **ipaddr** and **submask** parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Canceling the RTRV-APPL-SOCK and RTRV-ASSOC Commands

Because the **rtrv-appl-sock** and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled and the output

to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10   255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----    -----    HALF    10     DIX      NO    NO
1203  A      192.1.1.12   255.255.255.0   ----    ---    DIX      YES   NO
1203  B      -----    -----    HALF    10     DIX      NO    NO
1205  A      192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----    -----    HALF    10     DIX      NO    NO
2101  A      192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----    -----    HALF    10     DIX      NO    NO
2103  A      192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----    -----    HALF    10     DIX      NO    NO
2105  A      192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----    -----    HALF    10     DIX      NO    NO
2205  A      192.1.1.30   255.255.255.0   FULL    100    DIX      NO    NO
2205  B      -----    -----    HALF    10     DIX      NO    NO
2207  A      192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----    -----    HALF    10     DIX      NO    NO
2213  A      192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----    -----    HALF    10     DIX      NO    NO
2301  A      192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----    -----    HALF    10     DIX      NO    NO
```

NOTE: If the `ipaddr=0.0.0.0` is not being specified in this procedure, skip step 2 and go to step 3.

2. If IP address information is being added or changed (not deleted) in the link parameters, verify that the IP address is present in the IP host table by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1-1201
192.1.1.12    IPNODE1-1203
192.1.1.14    IPNODE1-1205
192.1.1.20    IPNODE2-1201
192.1.1.22    IPNODE2-1203
```



```

192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2

```

```

REMOTE IPADDR  REMOTE HOST
150.1.1.5       NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

```

IP Host table is (11 of 512) 2% full

If the current IP address of the IP link is shown in the **rtrv-ip-host** output, remove the host assigned to the IP address by performing the [Adding an IP Host](#) procedure.

- To change IP link parameters, the signaling link to the IP card and the IP card have to be inhibited. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk: loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE  IPLIML2
1201  A   nc001         0  IPLIM  M2PA

```

- Retrieve the status of the signaling link assigned to the IP card to be changed using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output lists the signaling link assigned to this card:

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK  LSN      CLLI      PST      SST      AST
1201,A  nc001  -----  IS-NR
Command Completed.

```

If the signaling link is in service-normal (IS-NR), go to step 5 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 7 to verify the IP card status.

- Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk: loc=1201: link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```

rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.

```

- Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```

rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001    -----  OOS-MT-DSBLD  AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS: not aligned
UNAVAIL REASON = NA
Command Completed.

```

7. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM  IPLIM  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST      LS      CLLI
A    IS-NR    nc001    -----

```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 8 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 10 to change the IP link parameters.

8. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```

rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.

```

9. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM  IPLIM  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST      LS      CLLI
A    IS-NR    nc001    -----

```

Command Completed.

10. Display the attributes of the IP card assigned to the IP link being changed by entering the **rtrv-ip-card** command and specifying the card location of the IP link.

NOTE: If the `ipaddr` or `submask` parameter values are not being changed, skip steps 10, 11, and 12, and go to step 13.

For this example, enter this command.

rtrv-ip-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN    -----
```

If the **rtrv-ip-card** output shows an IP address for the default router (**DEFROUTER**) whose network portion matches the network portion of the IP address being changed, go to the [Configuring an IP Card](#) procedure and change the IP address of the default router to **0.0.0.0**.

11. Display any IP routes referencing the IP link being changed by entering the **rtrv-ip-rte** command and specifying the card location of the IP link.

For this example, enter this command.

rtrv-ip-rte:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1201  128.252.10.5   255.255.255.255  140.188.13.33
1201  128.252.0.0      255.255.0.0      140.188.13.34
1201  150.10.1.1        255.255.255.255  140.190.15.3
```

IP Route table is (5 of 1024) 1% full

If the **rtrv-ip-rte** output shows that the card has IP routes assigned to it, go to the [Removing an IP Route](#) procedure and remove the IP routes from the database.

12. The subnet address that results from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

NOTE: If a Class A or C IP address (see [Table 3-3](#)) will be specified for the **ipaddr** parameter in step 15, skip step 12 and go to step 13.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 13.

This is an example of the possible output if the E5IS feature is on.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0
```

Choose **ipaddr** and **submask** parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 13.

13. Display the application sockets referencing the local host name that is associated with the IP link being changed by entering the **rtrv-appl-sock** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

NOTE: If the local host was removed in step 2, skip steps 13 and 14, and go to step 15.

For this example, enter this command.

rtrv-appl-sock: lhost="ipnode1-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME kchlr11201
LINK A
LHOST ipnode1-1201
RHOST kc-hlr1
LPORT 7000 RPORT 7000
SERVER YES DCMPS 1
REXMIT FIXED RTT 60
OPEN YES ALW NO
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

If no sockets are displayed in this step, go to step 14.

If the **rtrv-appl-sock** output shows that the **open** parameter for any sockets is **yes**, perform one of these procedures to change the value of the **open** parameter of the sockets to **no**.

- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)

14. Display the associations referencing the local host name that is associated with the IP link being changed by entering the **rtrv-assoc** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

For this example, enter this command.

rtrv-assoc: lhost="ipnode-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME LOC PORT LINK ADAPTER LPORT RPORT OPEN ALW
swbel32 1201 A A M2PA 1030 2345 YES YES
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1201

If no associations are displayed in this step, go to step 15.

If the **rtrv-assoc** output shows that the **open** parameter for any associations is **yes**, perform one of these procedures to hange the value of the **open** parameter the associations to **no**.

- [Changing an M2PA Association](#)

- [Changing an M3UA or SUA Association](#)

15. Change the link parameters associated with the IP card in the database using the **chg-ip-lnk** command. For this example, enter this command.

```
chg-ip-  
lnk:loc=1201:port=a:ipaddr=192.1.1.10 :submask=255.255.255.0:auto=yes:m  
actype=dix
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0  
CHG-IP-LNK: MASP A - COMPLTD
```

16. Verify the new link parameters associated with the IP card that was changed in step 15 by entering the **rtrv-ip-lnk** command with the card location specified in step 15.

For this example, enter this command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0  
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST  
1201  A      192.1.1.10      255.255.255.128  HALF    10     DIX      YES  NO  
1201  B      -----          -----          HALF    10     DIX      NO   NO
```

17. Allow the IP card that was inhibited in step 8 by using by using the **alw-card** command.

NOTE: If step 8 was not performed, skip steps 17 and 18, and go to step 19.

For example, enter this command.

```
alw-card:loc=1201
```

This message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0  
Card has been allowed.
```

18. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command.

For example, enter this command.

```
rept-stat-card:loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0  
CARD  VERSION  TYPE  APPL  PST  SST  AST  
1201  114-000-000  DCM  IPLIM  IS-NR  Active  -----  
ALARM STATUS      = No Alarms.  
BPDCM GPL         = 002-102-000  
IMT BUS A         = Conn  
IMT BUS B         = Conn  
SIGNALING LINK STATUS  
SLK  PST  LS  CLLI  
A    IS-NR  nc001  -----
```

Command Completed.

19. Activate the signaling link from step 5 using the **act-slk** command.

NOTE: If step 5 was not performed, skip steps 19 and 20, and go to step 21.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

20. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command. For example, enter this command.

rept-stat-slk:loc=1201:link=a

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----  IS-NR
Command Completed.
```

21. Perform the [Configuring an IP Card](#) procedure and change the IP address of the default router to a non-zero value, where the network portion of the default router IP address matches the network portion of the IP link's new IP address.

NOTE 1: If the `ipaddr` or `submask` values were not changed, skip steps 21 and 22, and go to step 23.

NOTE: If the IP address of the default router was not changed to 0.0.0.0 in step 10, skip step 21, and go to step 22.

22. Perform the [Adding an IP Route](#) procedure and add the IP routes back into the database.

NOTE: If IP routes were not removed in step 11, skip step 22, and go to step 23.

23. Perform one of these procedures as necessary and change the value of the **open** parameter of either the application socket or the association to **yes**.

NOTE: If the `open` parameter value for either an application socket or an association was not changed in either steps 13 or 14, skip step 23, and go to step 24.


- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)
- [Changing an M2PA Association](#)
- [Changing an M3UA or SUA Association](#)


24. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-4. Configuring an IP Link




















Adding an IP Host

This procedure associates hostnames with IP addresses using the **ent-ip-host** command.

The **ent-ip-host** command uses the following parameters.

:host— The host name to be associated with the IP address. This parameter identifies the logical name assigned to the device with the IP address indicated. The host name can contain up to 60 characters (using only these characters: a-z, A-Z, 0-9, -, .) and is not case sensitive. The host name must begin with a letter. Host names containing a dash (-) must be enclosed in double quotes.

:ipaddr – The IP address to be associated with the hostname. The node’s IP address. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:type – Specifies if the host resides on the IP card on the EAGLE 5 ISS (**type=local**, the default value), or if the host resides on equipment that is not in the EAGLE 5 ISS (**type=remote**). This parameter is optional.

The IP address for a local host must be shown in the **rtrv-ip-lnk** output.

The IP address for a remote host must not be shown in the **rtrv-ip-lnk** output.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
```

```
REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (10 of 512) 2% full

2. Verify that the IP address assigned to the IP links by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10   255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----      -----      HALF    10     DIX      NO    NO
1203  A      192.1.1.12   255.255.255.0   ----    ---    DIX      YES   NO
1203  B      -----      -----      HALF    10     DIX      NO    NO
1205  A      192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
```

If a local host is being configured in this procedure, the IP address assigned to the local host must be shown in the **rtrv-ip-lnk** output. If the IP address is not shown in the **rtrv-ip-lnk** output, add the IP address by performing the [Configuring an IP Link](#) procedure.

If a remote host is being configured in this procedure, the IP address assigned to the remote host cannot be shown in the **rtrv-ip-lnk** output.

3. Add IP host information to the database by entering the **ent-ip-host** command.

If a local host is being configured, enter the **ent-ip-host** command with the IP address from step 2, and the **type=local** parameter or without the **type** parameter. If the **type** parameter is not specified with the **ent-ip-host** command, the **type** parameter value defaults to **local**.

If a remote host is being configured, enter the **ent-ip-host** command with the IP address that is not shown in step 2, and the **type=remote** parameter.

For example, enter this command.

ent-ip-host:host="kc-hlr1":ipaddr=192.1.1.30

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
ENT-IP-HOST: MASP A - COMPLTD
```

4. Verify the new IP host information in the database by entering the **rtrv-ip-host** command with the **host** parameter value specified in step 3.

For this example, enter this command.

rtrv-ip-host:host="kc-hlr1"

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOCAL IPADDR      LOCAL HOST
192.1.1.30        KC-HLR1
```


IP Host table is (11 of 512) 2% full

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-5. Adding an IP Host



Configuring an IP Card

This procedure is used to change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

The **chg-ip-card** command uses the following parameters.

:loc – The card location of the IP card

:srchordr – Host Table Search Order

:dnrsa – Domain name server A's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:dnrsb – Domain name server B's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:domain – The domain name is used to construct a fully-qualified DNS name consisting of 120 characters or less. For example, a domain name can be **tekelec.com**, the hostname is **john.doe**. The fully-qualified DNS name would be **john.doe@tekelec.com**.

:defrouter – Default router IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:rstdomain – Reset Domain name. The parameter is used to reset the domain to a NULL value.

The IP card must be placed out of service.

The **rstdomain** parameter cannot be specified if the **domain** parameter is specified.

There is only one default router (**defrouter** parameter) for each IP card. The default router is used as the primary route unless a static IP routes is defined for the destination IP address. Static IP routes are assigned using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure.

The network portion of the IP address of the default router must match the network portion of one of the IP addresses assigned to the card.

The network portion of the IP address is based on the class of the IP address (shown in [Table 5-3](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

The default router can be associated with only one IP address assigned to the card if the defrouter parameter is specified. For example, the **dnrsa** value for card 1101 is 150.1.1.10. The **dnrsb** value for card 1101 is 160.25.37.1. A default router is provisioned with the IP address 150.1.1.4. The default router is associated with the Ethernet A IP address (the **dnrsa** parameter value), but not the Ethernet B IP address (the **dnrsb** parameter value).

If the default router is associated with one of the IP card's IP addresses, a second gateway router can be assigned to the other IP address on the IP card by provisioning a static IP route for the IP card using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure. Static IP routes can provide gateway routers associated with the other IP address on the IP card. To provision the gateway router (the **gtwy** parameter of the **ent-ip-rte** command) for the other IP address assigned to the IP card, the network portion of the gateway router's IP address must match the network portion of the other IP address assigned to the IP card.

Specifying the IP address 0.0.0.0 for the **dnrsa** or **dnrsb** parameters, removes the IP address for Ethernet A (**dnrsa**) or Ethernet B (**dnrsb**).

When an IP card is entered into the database with the **ent-card** command, the IP stack parameters associated with this card are initially set with these default values:

- **:srchordr** – SRVR
- **:dnsc** – No DNS IP address is specified
- **:dnscb** – No DNSB IP address is specified
- **:domain** – No domain name is specified
- **:defrouter** – No default router IP address is specified
- **:rstdomain** – No

The value of any optional parameter not specified with the **chg-ip-card** command is not changed.

Procedure

1. Display the current IP parameters associated with card in the database by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN     -----

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM
```

To change the parameters of an IP card, the signaling link to the card and the card have to be inhibited.

2. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE  IPLIML2
1201  A    nc001        0  IPLIM   M2PA
```

3. Retrieve the status of the signaling link shown in step 2 using the **rept-stat-slk** command specifying the card location and signaling link.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----   IS-NR
        Avail     ----
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 4 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 4 and 5, and go to step 6 to verify the card status.

4. Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

5. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----   OOS-MT-DSBLD  AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS:not aligned
UNAVAIL REASON = NA
Command Completed.
```

6. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000 DCM   IPLIM IS-NR  Active  -----
ALARM STATUS = No Alarms.
BPDCM GPL =
002-1
02-000
IMT BUS A = Conn
IMT BUS B = Conn
SIGNALING LINK STATUS
SLK  PST  LS  CLLI
A    IS-NR  nc001  -----
Command Completed.
```

If the IP card to be inhibited is in service-normal (IS-NR), go to step 7 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 7 and 8, and go to step 9.

7. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

8. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1201  114-000-000    DCM      IPLIM     IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         =
002-1
02-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK      PST      LS      CLI
A        IS-NR     nc001  -----
```

Command Completed.

NOTE: If the defrouter parameter is not specified in step 10, skip step 9 and go to step 10.

9. Verify that the IP address of either Ethernet A or B (the address whose network portion matches the network portion of the **defrouter** parameter value to be used in step 10) is in the IP link table by entering the **rtrv-ip-lnk** command with the card location specified in this procedure.

For this example, enter this command.

rtrv-ip-lnk: loc=1201

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A     192.1.1.10   255.255.255.0  ----   ---   DIX      YES   NO
1201  B     -----     -----     ----   ---   DIX      YES   NO
```

If the network portion of the IP address specified by the **defrouter** value does not match the network portions of either IP address displayed in this step, perform one of these actions:

- Choose another value for the **defrouter** parameter, making sure that the network portion of the new IP address matches the network portion of one of the IP addresses displayed in this step.
- Perform the [Configuring an IP Link](#) procedure and change one of the IP addresses shown in this step so that the network portion of the new IP address changed in the [Configuring an IP Link](#) procedure matches the network portion of the IP address value for the **defrouter** parameter.

10. Change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

For this example, enter this command.

```
chg-ip-  
card:loc=1201:srchordr=local:dnsa=192.1.1.40 :domain=nc.tekelec.com
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0  
CHG-IP-CARD: MASP A - COMPLTD
```

11. Verify the new IP parameters associated with the IP card that was changed in step 10 by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0  
LOC 1201  
  SRCHORDR  LOCAL  
  DNSA      192.1.1.40  
  DNSB      -----  
  DEFROUTER -----  
  DOMAIN    NC. TEKELEC. COM  
  
LOC 1203  
  SRCHORDR  LOCAL  
  DNSA      192.1.1.40  
  DNSB      -----  
  DEFROUTER -----  
  DOMAIN    NC. TEKELEC. COM  
  
LOC 1205  
  SRCHORDR  SRVRONLY  
  DNSA      192.1.1.40  
  DNSB      -----  
  DEFROUTER -----  
  DOMAIN    NC. TEKELEC. COM
```

NOTE: If step 7 was not performed, skip steps 12 and 13, and go to step 14.

12. Allow the IP card that was inhibited in step 7 by using the **alw-card** command.

For example, enter this command.

```
alw-card:loc=1201
```

This message should appear.

```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0  
Card has been allowed.
```

13. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command.

For example, enter this command.

```
rept-stat-card:loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0  
CARD  VERSION  TYPE  APPL  PST  SST  AST  
1201  114-000-000 DCM   IPLIM  IS-NR  Active  -----  
ALARM STATUS      = No Alarms.  
BPDCM GPL         = 002-102-000  
IMT BUS A         = Conn  
IMT BUS B         = Conn  
SIGNALING LINK STATUS  
  SLK  PST  LS  CLLI  
  A    IS-NR  nc001  -----
```

Command Completed.

NOTE: If step 4 was not performed, skip steps 14 and 15, and go to step 16.

14. Activate the signaling link from step 4 using the **act-slk** command.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

This message should appear.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----   IS-NR
        Avail     ----
Command Completed.
```


16. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-6. Changing an IP Card







Adding an IP Route

This procedure is used to add an IP route to the database using the **ent-ip-rte** command.

The **ent-ip-rte** command uses these parameters.

:loc – The location of the IP card that the IP route will be assigned to.

:dest – The IP address of the remote host or network.

:submask – The subnet mask of the destination IP address.

:gtwy – The IP address of the gateway or router that will send the IP data to its final destination.

There can be a maximum of 64 IP routes assigned to an IP card.

The EAGLE 5 ISS can contain a maximum of 1024 IP routes.

Ethernet Interfaces A and B on the IP card specified by the **loc** parameter can be used.

The network portion of the IP address value of the **gtwy** parameter must be the same as the network portion of the IP addresses shown for either the A or B interfaces in the **rtrv-ip-card** output.

The value of the **dest** and **gtwy** parameters cannot be 127.x.x.x (the loopback address), 0.0.0.0, or the IP addresses of the A or B interfaces on the IP card, and cannot be assigned to another IP card.

If the **dest** parameter value represents a host IP address, the value for the **submask** parameter must be 255.255.255.255. Otherwise, the **submask** parameter value identifies the network/host ID portions that must be entered when the dest parameter value represents a network address.

The submask is applied to the IP address which is being routed to see if it yields a route match. For example, if IP address 192.1.1.2 is being routed and the IP routing table contains these entries.

Table 5-4. Sample IP Routing Table

IP address	Submask	Gateway
191.1.0.0	255.255.0.0	192.168.110.250
192.0.0.0	255.0.0.0	192.168.110.251

IP routing occurs as follows:

1. The subnet mask of route 1 (255.255.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.1.0.0. IP address 192.1.0.0 does not match IP address 191.1.0.0 in the IP routing table, so the next route is chosen.
2. The subnet mask of route 2 (255.0.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.0.0.0 which matches the second route in the IP routing table, so this route is selected for routing this datagram.

See [Table 5-5](#) for the valid input values for the **submask** and **dest** parameter combinations.

Table 5-5. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0 255.224.0.0

Network Class	IP Network Address Range	Valid Subnet Mask Values
		255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.1.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **dest** parameter of the **ent-ip-rte** command, the subnet address that results from the **dest** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1301 128.252.10.5     255.255.255.255 140.188.13.33
1301 128.252.0.0       255.255.0.0      140.188.13.34
1301 150.10.1.1        255.255.255.255 140.190.15.3
1303 192.168.10.1      255.255.255.255 150.190.15.23
1303 192.168.0.0       255.255.255.0    150.190.15.24
```

IP Route table is (5 of 1024) 1% full

2. Display the IP cards in the database with the **rtrv-ip-card** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1212
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER 150.1.1.100
  DOMAIN     NC. TEKELEC. COM

LOC 1301
  SRCHORDR  SRVRONLY
  DNSA      140.188.13.10
  DNSB      140.190.15.28
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM

LOC 1303
  SRCHORDR  LOCAL
  DNSA      150.190.15.1
  DNSB      -----
  DEFROUTER 150.190.15.25
  DOMAIN     NC. TEKELEC. COM

```

If the required IP card is not shown in the **rtrv-ip-card** output, perform the [Adding an IPLIMx Card](#) procedure to add the card to the database.

Perform the [Configuring an IP Card](#) procedure and make sure that the network portion of the IP addresses assigned for the A or B interfaces of the IP card is the same as the network portion of the IP address that will be assigned to the **gtwy** parameter of the IP route

NOTE: If a Class A or C IP address (see [Table 5-5](#)) will be specified for the **dest parameter in step 4, skip step 3 and go to step 4.**

3. The subnet address that results from the **dest** and **submask** parameter values of the **ent-ip-rte** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 4.

This is an example of the possible output if the E5IS feature is on.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0

```

Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 4.

4. Add the IP route to the database using the **ent-ip-rte** command.

For this example, enter this command.

```

ent-ip-
rte:loc=1212:dest=132.10.175.20:submask=255.255.255.255 :gtwy=150.1.1.5
0

```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command with the card location specified with the **ent-ip-rte** command in step 4.

For this example, enter these commands.

rtrv-ip-rte:loc=1212

This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20  255.255.255.255 150.1.1.50
IP Route table is (6 of 1024) 1% full
```


6. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-7. Adding an IP Route





Adding an M2PA Association

This procedure is used to configure M2PA associations using the **ent -assoc** command. The combination of a local host, local SCTP port, remote host and remote SCTP port defines an association. M2PA associations are assigned to cards running either the IPLIM or IPLIMI applications (IPLIMx cards).

The **ent -assoc** command uses these parameters:

:aname – The name assigned to the association. Valid association names can contain up to 15 alphanumeric characters where the first character is a letter and the remaining characters are alphanumeric characters. The **aname** parameter value is not case-sensitive.

:lhost – Local Hostname. The logical name assigned to the local host device.

:lport – The SCTP port number for the local host.

:rhost – Remote Hostname. The logical name assigned to the remote host device.

:rport – The SCTP port number for the remote host.

:link – The signaling link on the IP card. If a signaling link is not specified for a association when it is entered, the association defaults to signaling link A. If the card is a single-slot EDCM, the values for the **link** parameter can be **a**, **a1**, **a2**, **a3**, **b**, **b1**, **b2**, or **b3**. If the card is an E5-ENET card, the values for the **link** parameter can be **a**, **a1**, **a2**, **a3**, **a4**, **a5**, **a6**, **a7**, **b**, **b1**, **b2**, **b3**, **b4**, **b5**, **b6**, or **b7**.

NOTE: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

:adapter – The adapter layer for this association, **m2pa**. The **adapter** parameter is optional. The default value for the **adapter** parameter is **m2pa**.

:alhost – The alternate local host name.

:m2patset – The M2PA timer set assigned to the association. The **m2patset** parameter can be specified only with the **adatper=m2pa** parameter. If the **adapter=m2pa** parameter is specified, and the **m2patset** parameter is not specified with the **ent -assoc** command, the default value for the **m2patset** parameter (1 - M2PA timer set 1) is assigned to the association.

The socket table, which contains both the socket and association data, contains fields whose values are not assigned using the **ent -assoc** command. When an association is added to the database, these fields receive their default values. If a different value is desired, the **chg -assoc** command must be used. To change these values perform the [Changing an M2PA Association](#) procedure.

These fields and their default values are:

open=no	rmax=800	cwmin=3000	alw=no	uaps=10
istrms=2	rmode=lin	rtimes=10	ostrms=2	rmin=120
ver=frc	bufsize=200	rtxthr=0		

The size of the buffers on the on the single-slot EDCMs and E5-ENET cards are shown in the following list.

- Single-Slot EDCM - 1600 kB
- E5-ENET Card - 3200 kB

The size of the buffers assigned to each association that is assigned to the IP card cannot exceed the maximum buffer size for the IP card. When a new association is added, the default buffer size for the association is assigned to the association. If adding the new association causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **ent -assoc** command will be rejected. If the you wish to add the association and the maximum buffer size for the IP card will be exceeded, the buffer size of the other associations assigned to the IP card must be decreased by performing the [Changing an M2PA Association](#) procedure. The available size of the buffers on the IP card can be verified by entering this command.

rtrv-assoc:lhost=<local host name assigned to the association being changed>

The **alhost** parameter can also be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card.

The **aname** parameter can be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card and the size of the buffer assigned to the association.

The value of the **lhost**, **rhost**, or **alhost** parameters is a text string of up to 60 characters, with the first character being a letter. The command line on the terminal can contain up to 150 characters. If the host names are too long to fit on the **ent -assoc** command line, go to the [Changing an M2PA Association](#) procedure to complete the entry of the host names.

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

IPLIMx cards can contain one association for each signaling link on the card. The single-slot EDCM can contain a maximum of eight signaling links, resulting in a maximum of eight associations for this card. The E5-ENET card can contain a maximum of 16 signaling links, resulting in a maximum of 16 associations for this card.

The B Ethernet interface of the IP card can be used on the single-slot EDCM or E5-ENET card.

If the association is to be activated in this procedure, with the **chg-assoc** command, the association must contain values for the **lhost**, **lport**, **rhost**, **rport** parameters.

The **ipliml2** parameter value of the signaling link assigned to the association must be **m2pa**. The **adapter** parameter value of the association must be **m2pa**.

The signaling link being assigned to the association must be out of service. This state is shown in the **rept-stat-slk** output with the entries **OOS-MT** in the **PST** field and **Unavail** in the **SST** field.

If the association is being opened in this procedure with the **chg-assoc** command and the **open=yes** parameter, the signaling link assigned to the association must be in the database and the **ipliml2** parameter value of the signaling link assigned to the association must be **m2pa**.

Uni-homed endpoints are associations configured with the **lhost** parameter only. The **lhost** parameter value represents an IP address that corresponds to either the A or B network interface of the IP card. Multi-homed endpoints are associations configured with both the **lhost** and **alhost** parameters. The **lhost** parameter value represents an IP address corresponding to one of the network interfaces (A or B) of the IP card while the **alhost** parameter value represents an IP address corresponding to the other network interface of the same IP card.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command. This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
swbel32    1201 A    A    M3UA   1030  2345  YES  YES
a2         1305 A    A    SUA    1030  2345  YES  YES
a3         1307 A    A    SUA    1030  2346  YES  YES
assoc3     1203 A    A1   M2PA   2048  1030  NO   NO
```

NOTE: If the required IP link is shown in the `rtrv-assoc` output in step 1, skip step 2 and go to step 3.

2. Display the IP links in the database by entering the `rtrv-ip-lnk` command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10    255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----      -----      HALF    10     DIX      NO    NO
1203  A      192.1.1.12    255.255.255.0   ----    ---    DIX      YES   NO
1203  B      -----      -----      HALF    10     DIX      NO    NO
1205  A      192.1.1.14    255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20    255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22    255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24    255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2205  A      192.1.1.30    255.255.255.0   FULL    100    DIX      NO    NO
2205  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32    255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50    255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52    255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
```

If the required IP link is not in the database, add the IP link using the [Configuring an IP Link](#) procedure.

3. Verify that the local host name to be assigned to the association is in the database by using the `rtrv-ip-host` command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (11 of 512) 2% full

The IP address of the IP link should be assigned to the local host name that will be assigned to the association.

If the local host name references a card running either the IPLIM or IPLIMI applications, the `iplim12` parameter value of the signaling link must be `m2pa`.

The values of the `lhost` and `ahost` parameters must be in the **LOCAL HOST** column in the `rtrv-ip-host` output.

If the required hostname is not in the database, add the IP host name using the [Adding an IP Host](#) procedure.

4. Display the application running on the IP card shown in either step 1 or step 2 using the `rept-stat-card` command specifying the location of the IP card. For this example, enter this command.

rept-stat-card:loc=1203

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1203  114-000-000   DCM      IPLIM     IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        e5e6a     -----
```

Command Completed.

NOTE: If a new IP host was added in step 3, skip step 5 and go to step 6.

5. Verify the available buffer size for the IP card that will contain the association being added in this procedure by entering the **rtrv-assoc** command with the local host name assigned to the association being added. For this example, enter this command.

rtrv-assoc: lhost="IPNODE2-1203"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc2     1203 A    A1   M2PA   2048  1030 NO   NO
IP Appl Sock/Assoc table is (8 of 4000) 1% full
Assoc Buffer Space Used (200 KB of 1600 KB) on LOC = 1203
```

If adding the new association causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **ent-assoc** command will be rejected.

The default buffer value for an IPLIMx association is 200.

If the you wish to add the association and the maximum buffer size for the IP card will be exceeded, the buffer size of the other associations assigned to the IP card must be decreased by performing the [Changing an M2PA Association](#) procedure.

6. Display the signaling link referenced by the IP link that will be assigned to the association by entering the **rtrv-slk** command and specifying the card location and signaling link. For this example, enter this command.

rtrv-slk: loc=1203: link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN      SLC TYPE  IPLIML2
1203 A   e5e6a      1  IPLIM   M2PA
```

The **ipliml2** parameter value for the signaling link assigned to the association must be **m2pa**. If the **ipliml2** parameter is not **m2pa**, remove the signaling link using the [Removing an IPGWx Signaling Link](#) procedure. Add the signaling link back into the database with the **ipliml2=m2pa** parameter, and without activating the signaling link, using the [Adding an IPLIMx Signaling Link](#) procedure.

NOTE: If the [Adding an IPLIMx Signaling Link](#) procedure was performed in step 6, skip steps 7, 8, and 9, and go to step 10.

7. Display the status of the signaling link shown in step 6 using the **rept-stat-slk** command specifying the card location and signaling link. For example, enter this command.

rept-stat-slkl:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1203,A   e5e6a      ----- IS-NR      Avail      ----
Command Completed.
```

NOTE: If the primary state (PST) of the signaling link is OOS-MT and the secondary state (SST) is Unavail, skip steps 8 and 9, and go to step 10.

8. Deactivate the signaling link from step 7 using the **dact-slkl** command. For example, enter this command.

dact-slkl:loc=1203:link=a

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

9. Verify the status of the signaling link using the **rept-stat-slkl** command. For example, enter this command.

rept-stat-slkl:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1203,A   e5e6a      ----- OOS-MT      Unavail      ----
Command Completed.
```

10. Verify the values of the M2PA timer set you wish to assign to the association by entering the **rtrv-m2pa-tset** command with the **ver=rfc** parameter.

When an M2PA association is provisioned in this procedure, the RFC M2PA version is assigned to the M2PA association by default.

The M2PA version of the association determines the version of the M2PA timer set that is assigned to the association. For example, if M2PA timer set 3 is assigned to the M2PA association, and the association is an RFC M2PA association, the RFC version of M2PA timer set 3 is used with the association. If M2PA timer set 7 is assigned to the M2PA association, and the association is a Draft 6 M2PA association, the Draft 6 version of M2PA timer set 7 is used with the association.

If you wish to assign the Draft 6 M2PA version to this association and use the Draft 6 M2PA timer sets, perform the [Changing an M2PA Association](#) procedure after this procedure is completed to change the M2PA version of this association.

NOTE: If the m2patset parameter will not be specified with the ent-assoc command, the M2PA timer set 1 will be assigned to the association.

To display the M2PA Draft 6 timer values, enter this command.

rtrv-m2pa-tset:ver=d6

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
M2PA Draft 6 Timers (in msec, T16 in microsec)
```

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	-----	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	-----	1500	2000	500	9000	1250	300	150000	175	600
3	100000	-----	2000	3000	500	4000	1500	500	170000	200	800
4	200000	-----	20000	4000	500	6000	2000	700	480000	225	900
5	250000	-----	30000	30000	500	100	2250	400	400000	400	8000
6	50000	-----	50000	60000	500	500	4500	800	300000	300	7000
7	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
8	80000	-----	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	-----	3850	4859	450	5700	3750	1150	250	375	8750
10	90000	-----	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	-----	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	-----	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	-----	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	-----	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	-----	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	-----	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	-----	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	-----	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	-----	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	-----	1000	1000	400	80	1000	200	100	100	100

To display the M2PA RFC values, enter this command.

rtrv-m2pa-tset:ver=rfc

This is an example of the possible output.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	75000	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	8000	1500	2000	500	9000	1250	300	150000	175	600
3	100000	10000	2000	3000	500	4000	1500	500	170000	200	800
4	200000	6000	20000	4000	500	6000	2000	700	480000	225	900
5	250000	140000	30000	30000	500	100	2250	400	400000	400	8000
6	50000	100000	50000	60000	500	500	4500	800	300000	300	7000
7	300000	20000	2000	10000	500	1000	3000	1200	200000	250	1000
8	80000	130000	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	120000	3850	4859	450	5700	3750	1150	250	375	8750
10	90000	9000	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	60000	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	50000	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	90000	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	45000	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	30000	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	15000	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	150000	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	20000	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	12500	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	5000	1000	1000	400	80	1000	200	100	100	100

If the **ver** parameter is not specified when entering the **rtrv-m2pa-tset** command, both the Draft 6 and RFC values are displayed. This is an example of the possible output.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	-----	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	-----	1500	2000	500	9000	1250	300	150000	175	600
3	100000	-----	2000	3000	500	4000	1500	500	170000	200	800
4	200000	-----	20000	4000	500	6000	2000	700	480000	225	900
5	250000	-----	30000	30000	500	100	2250	400	400000	400	8000
6	50000	-----	50000	60000	500	500	4500	800	300000	300	7000
7	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
8	80000	-----	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	-----	3850	4859	450	5700	3750	1150	250	375	8750

10	90000	-----	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	-----	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	-----	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	-----	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	-----	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	-----	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	-----	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	-----	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	-----	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	-----	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	-----	1000	1000	400	80	1000	200	100	100	100

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	75000	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	8000	1500	2000	500	9000	1250	300	150000	175	600
3	100000	10000	2000	3000	500	4000	1500	500	170000	200	800
4	200000	6000	20000	4000	500	6000	2000	700	480000	225	900
5	250000	140000	30000	30000	500	100	2250	400	400000	400	8000
6	50000	100000	50000	60000	500	500	4500	800	300000	300	7000
7	300000	20000	2000	10000	500	1000	3000	1200	200000	250	1000
8	80000	130000	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	120000	3850	4859	450	5700	3750	1150	250	375	8750
10	90000	9000	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	60000	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	50000	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	90000	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	45000	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	30000	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	15000	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	150000	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	20000	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	12500	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	5000	1000	1000	400	80	1000	200	100	100	100

If the M2PA timer set you wish to assign to the association does not contain the desired values, go to the [Changing an M2PA Timer Set](#) procedure and changed the desired timer values.



CAUTION: Changing an M2PA timer set may affect the performance of any associations using the timer set being changed.

11. Add the associations using the **ent -assoc** command. For this example, enter this command.

```
ent -assoc : aname=assoc2 : lhost=gw107.nc.tekelec.com : lport=2000 :
rhost=gw100.nc.tekelec.com : rport=1030 : adapter=m2pa : link=a
```

NOTE 1: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

NOTE: See [Flowchart 5-8](#) (Sheet 5) for the rules that apply to the **ent -assoc** command.

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-ASSOC: MASP A - COMPLTD
```

NOTE: If the association added in step 6 is not being activated in this procedure, skip step 7 and go to step 8.

12. Activate the association added in step 11 by entering the **chg -assoc** command with the association name specified in step 11 and the **open=yes** and **alw=yes** parameters. For example, enter this command.

```
chg -assoc : aname=assoc2 : open=yes : alw=yes
```

When this command have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```

13. Verify the changes using the **rtrv-assoc** command specifying the association name specified in steps 11 and 12. For this example, enter this command.

rtrv-assoc:aname=assoc2

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc2
  LOC      1203          IPLNK PORT  A          LINK  A
  ADAPTER  M2PA          VER          M2PA RFC
  LHOST    gw105.nc.tekelec.com
  ALHOST    ---
  RHOST    gw100.nc.tekelec.com
  LPORT    1030          RPORT      1030
  ISTRMS    2            OSTRMS     2            BUFSIZE  200
  RMODE     LIN          RMIN        120          RMAX     800
  RTIMES    10           CWMIN       3000         M2PATSET 1
  OPEN      NO           ALW         NO           RTXTHR   0
```

```
IP Appl Sock table is (5 of 4000) 1% full
Assoc Buffer Space Used (400 KB of 1600 KB) on LOC = 1203
```

14. Activate the signaling link assigned to the association using the **act-slk** command.

For example, enter this command.

act-slk:loc=1203:link=a

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the status of the signaling link using the **rept-stat-slk** command. For example, enter this command.

rept-stat-slk:loc=1203:link=a


This is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1203,A    e5e6a    -----  IS-NR      Avail     ----
Command Completed.
```


16. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-8. Adding an M2PA Association









Notes:

1. The B Ethernet interface can be used with single-slot EDCMs or E5-ENET cards.
2. The EAGLE 5 ISS can contain a maximum of 4000 connections (association – application server assignments plus sockets).
3. The *adapter* parameter value for the association must be *m2pa*. The value of the *ipliml2* parameter of the signaling link being assigned to this association must be *m2pa*. The default value for the *adapter* parameter is *m2pa*.
4. IPLIMx cards can have only one connection for each signaling link assigned to the card. If the card is a single-slot EDCM, the card may contain a maximum of eight connections. If the card is an E5-ENET card, the card may contain a maximum of 16 connections.
5. The value of the *lhost*, *rhost*, or *alhost* parameters is a text string of up to 60 characters, with the first character being a letter. The command line on the terminal can contain up to 150 characters. If the host names are too long to fit on the *ent-assoc* command line, go to the "Changing an M2PA Association" procedure in this chapter to complete the entry of the host names.
6. If the new association is to be activated in this procedure with the *chg-assoc* command, the association must contain values for the *lhost*, *rhost*, *lport*, and *rport* parameters.
7. If the *lhost* and *alhost* are specified, the *lhost* parameter value represents the IP address corresponding to one of the network interfaces (A or B) on the IP card while the *alhost* parameter value represents the IP address corresponding to the other network interface of the same IP card.
8. The *m2patset* parameter can be specified only with the *adapter=m2pa* parameter.
9. The *m2patset* parameter value defaults to M2PA timer set 1 (*m2patset=1*) if the *m2patset* parameter is not specified.
10. The *port* parameter can be used in place of the *link* parameter to specify the signaling link assigned to the association.
11. When the *adapter=m2pa* parameter is specified, the RFC M2PA version is assigned to the M2PA association by default. If you wish to assign the Draft 6 M2PA version to this association, perform the "Changing an M2PA Association" procedure in this chapter after this procedure is completed to change the M2PA version of this association.

Activating the Large BICC MSU Support for IP Signaling Feature

This procedure is used to enable and turn on the Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature using the feature's part number and a feature access key.

The feature access key for the Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key provided by Tekelec. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number of the Large BICC MSU Support for IP Signaling feature, 893018401.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial

number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the **ent-serial-num** command must be entered twice, once to add the correct serial number to the database with the **serial** parameter, then again with the **serial** and the **lock=yes** parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature has been enabled, the feature must be turned on with the **chg-ctrl-feat** command. The **chg-ctrl-feat** command uses these parameters:

:partnum – The Tekelec-issued part number of the Large BICC MSU Support for IP Signaling feature, 893018401.

:status=on – used to turn the Large BICC MSU Support for IP Signaling feature on.

Once the Large BICC MSU Support for IP Signaling feature has been turned on, it can be turned off. For more information about turning the Large BICC MSU Support for IP Signaling feature off, go to the [Turning the Large BICC MSU Support for IP Signaling Feature Off](#) procedure.

The status of the features in the EAGLE 5 ISS is shown with the **rtrv-ctrl-feat** command.

The Large BICC MSU Support for IP Signaling feature allows the EAGLE 5 ISS to process BICC messages with a service information field (SIF) that is larger than 272 bytes. The large BICC messages are processed only on single-slot EDCMs and E5-ENET cards. There are certain software components that if enabled or provisioned, that will not process large BICC messages even if the Large BICC MSU Support for IP Signaling feature is enabled and turned on. UIMs are displayed when most of these circumstances occur. These UIMs are:

- UIM 1333 – Displayed when a large BICC message is received on an M3UA association and the Large BICC MSU Support for IP Signaling feature is not enabled or is enabled and turned off. The large BICC message is discarded.
- UIM 1334 – Displayed when a TALI IPGWx socket receives a BICC message with an SIF greater than 272 bytes.
- UIM 1350 – Displayed when a M2PA IP connection receives BICC message with an SIF greater than 272 bytes and the Large BICC MSU Support for IP Signaling feature is not enabled or is enabled and turned off. The large BICC message is discarded.
- UIM 1351 – Displayed when a TALI IPLIMx socket assigned to a single-slot EDCM receives a BICC message with an SIF greater than 272 bytes.
- UIM 1352 – Displayed when a BICC message with an SIF greater than 272 bytes is received; the Large BICC MSU Support for IP Signaling feature is enabled and turned on; there are routes available for the destination point code; but the selected outbound card does not support large BICC messages.
- UIM 1353 – Displayed when a large BICC message passes a gateway screening screenset that redirects messages for the Database Transport Access (DTA) feature. Large BICC messages are not redirected for the DTA feature.

- UIM 1354 – Displayed when a large BICC message passes a gateway screening screenset that copies messages for the STPLAN feature. Large BICC messages are not copied for the STPLAN feature.

For more information on these UIMs, refer to the *Maintenance Manual*.

NOTE: Large BICC messages are not monitored by the EAGLE 5 Integrated Monitoring Support feature and are not sent to the IMF. A UIM is not generated.

Procedure

1. Display the status of the controlled features by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:15:37 GMT EAGLE5 37.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Large System # Links	893005910	on	2000
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the Large BICC MSU Support for IP Signaling feature is enabled and turned on, no further action is necessary. This procedure does not need to be performed.

If the Large BICC MSU Support for IP Signaling feature is enabled and but not turned on, skip steps 2 through 6 and go to step 7.

If the Large BICC MSU Support for IP Signaling feature is not enabled, go to step 2.

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, skip steps 2 through 5, and go to step 6.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the

remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231

System serial number is not locked.

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>;lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Enable the Large BICC MSU Support for IP Signaling feature with the **enable-ctrl-feat** command specifying the part number for the Large BICC MSU Support for IP Signaling feature and the feature access key. Enter this command.

enable-ctrl-feat:partnum=893018401:fak=<Large BICC MSU Support for IP Signaling feature access key>

NOTE 1: A temporary feature access key cannot be specified to enable this feature.

NOTE 2: The values for the feature access key (the **fak** parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```


7. Turn the Large BICC MSU Support for IP Signaling feature on with the **chg-ctrl-feat** command specifying the part number for the Large BICC MSU Support for IP Signaling feature and the **status=on** parameter. Enter this command.

chg-ctrl-feat:partnum=893018401:status=on

When the **chg-crtl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 07-05-28 21:15:37 GMT EAGLE5 37.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the Large BICC MSU Support for IP Signaling feature part number. Enter this command.

rtrv-ctrl-feat:partnum=893018401

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large BICC MSU for IP Sig	893018401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				


The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-9. Activating the Large BICC MSU Support for IP Signaling Feature







Removing IETF M2PA Components

This section describes how to remove the following components from the database.

- An IPLIMx Card – Perform the [Removing an IPLIMx Card](#) procedure
- An IPLIMx Signaling Link – Perform the [Removing an IPLIMx Signaling Link](#) procedure
- An IP Host – Perform the [Removing an IP Host Assigned to an IPLIMx Card](#) procedure
- An IP Route – Perform the [Removing an IP Route](#) procedure
- An M2PA Association – Perform the [Removing an M2PA Association](#) procedure

Removing an IPLIMx Card

Use this procedure to remove an IPLIMx card, a card running the **iplim** or **iplimi** applications from the database using the **dlt-card** command.

The card cannot be removed if it does not exist in the database. Prior to removing the card from the database, the signaling links assigned to the card must be removed.



CAUTION: If the IPLIMx card is the last IP card in service, removing this card from the database will cause traffic to be lost.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-15 16:34:56 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM        SCCP
1102   TSM        GLS
1104   ACMENET    STPLAN
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI   lsn1           A    0    lsn2           B    1
1202   LIMV35     SS7GX25   lsngwy         A    0
1203   LIMV35     SS7ANSI   lsn2           A    0    lsn1           B    1
1204   LIMATM     ATMANSI   atmgy          A    0
1205   DCM        IPLIM     ipnode1        A    0    ipnode3        B    1
1207   DCM        IPLIM     ipnode2        A    0
1303   DCM        IPLIM     ipnode1        A    0    ipnode3        B    1
1305   DCM        IPLIM     ipnode4        A    0
```

Select a card whose application is either **IPLIM** or **IPLIMI**.

Perform the [Removing an IPLIMx Signaling Link](#) procedure in this chapter to remove all the signaling links assigned to the card, shown in the **LINK** column of the **rtrv-card** output.

The card location is shown in the **CARD** field of the **rtrv-card** command output. No entries in the **LSET NAME**, **LINK**, and **SLC** columns mean that no signaling link is assigned to the card.

2. Remove the card from the database using the **dlt-card** command.

The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter these commands.

```
dlt-card: loc=1205
```

```
dlt-card: loc=1207
```

When these commands have successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-CARD: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-card** command and specifying the card that was removed in step 2.

For this example, enter these commands.

```
rtrv-card: loc=1205
```

```
rtrv-card: loc=1207
```

When these commands have successfully completed, this message appears.


E2144 Cmd Rej: Location invalid for hardware configuration

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-10. Removing an IPLIMx Card



Removing an IPLIMx Signaling Link

This procedure is used to remove an IPLIMx signaling link from the database using the **dlt-slk** command. The **dlt-slk** command uses these parameters.

:loc – The card location of the IPLIMx card that the IP signaling link is assigned to.

:link – The signaling link on the card specified in the **loc** parameter.

:force – This parameter must be used to remove the last link in a linkset without having to remove all of the routes that referenced the linkset.

The **tfatcabmlq** parameter (TFA/TCA Broadcast Minimum Link Quantity), assigned to linksets, shows the minimum number of links in the given linkset (or in the combined link set in which it resides) that must be available for traffic. When the number of signaling links in the specified linkset is equal to or greater than the value of the **tfatcabmlq** parameter, the status of the routes that use the specified linkset is set to allowed and can carry traffic. Otherwise, these routes are restricted. The value of the **tfatcabmlq** parameter cannot exceed the total number of signaling links contained in the linkset.

The **dlt-slk** command makes sure that the number of signaling links assigned to a linkset is greater than or equal to the value of the **tfatcabmlq** parameter. If the number of signaling links associated with a linkset drops below the value of the **tfatcabmlq** parameter for that linkset, the **tfatcabmlq** value for that linkset is automatically decremented. The value of the **tfatcabmlq** parameter for a specified linkset can be verified using the **rtrv-ls:lsn=<linkset name>** command specifying the name of the linkset. The **tfatcabmlq** parameter value is shown in the **tfatcabmlq** field of the **rtrv-ls** command output.

Canceling the RTRV-SLK Command

Because the **rtrv-slk** command used in this procedure can output information for a long period of time, the **rtrv-slk** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-slk** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-slk** command was entered, from another terminal other than the terminal where the **rtrv-slk** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link configuration using the **rtrv-slk** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0

LOC  LINK  LSN          SLC TYPE  SET  BPS  MODE  TSET  ECM  N1  N2
1201  A    ls01           0  LIMDS0  1   56000  ---  ---  BASIC  ---  ---
1201  B    lsa1           0  LIMDS0  1   56000  ---  ---  BASIC  ---  ---
1202  B    ls02           0  LIMV35  2   64000  DTE  ---  BASIC  ---  ---
1203  A    ls03           0  LIMDS0  3   56000  ---  ---  BASIC  ---  ---
1203  B    lsa2           0  LIMDS0  1   56000  ---  ---  BASIC  ---  ---
1204  B    ls01           1  LIMDS0  1   56000  ---  ---  BASIC  ---  ---
1205  A    lsa3           0  LIMV35  4   64000  DCE  ON    BASIC  ---  ---
1206  A    ls02           1  LIMV35  2   64000  DTE  ---  BASIC  ---  ---
1207  A    lsn1207a       0  LIMDS0  1   56000  ---  ---  BASIC  ---  ---
1207  B    lsn1207b       0  LIMDS0  1   56000  ---  ---  BASIC  ---  ---
1208  B    ls03           1  LIMDS0  3   56000  ---  ---  BASIC  ---  ---
1212  A    ls04           0  LIMV35  4   64000  DTE  ---  BASIC  ---  ---
1213  B    ls05           0  LIMDS0  5   56000  ---  ---  BASIC  ---  ---
1214  A    lsn1214a       0  LIMV35  2   64000  DTE  ---  PCR    76  3800
1214  B    lsa3           1  LIMV35  4   64000  DCE  ON    BASIC  ---  ---
1215  A    ls05           1  LIMDS0  5   56000  ---  ---  BASIC  ---  ---
1301  B    ls06           0  LIMV35  6   56000  DTE  ---  BASIC  ---  ---
1304  B    ls06           1  LIMV35  6   56000  DTE  ---  BASIC  ---  ---
1308  A    ls06           2  LIMV35  6   56000  DTE  ---  BASIC  ---  ---
```

1311	A	ls01	2	LIMDS0	1	56000	---	---	BASIC	---	----
1311	A1	ls05	2	LIMDS0	5	56000	---	---	BASIC	---	----
1311	B	ls03	2	LIMDS0	3	56000	---	---	BASIC	---	----
1311	B1	ls07	1	LIMDS0	7	56000	---	---	BASIC	---	----
1313	A	ls07	0	LIMDS0	7	56000	---	---	BASIC	---	----
1315	A	lsn5	0	LIMV35	11	64000	DTE	OFF	BASIC	---	----
1317	A	ls17	0	LIMV35	11	64000	DTE	OFF	BASIC	---	----

LOC	LINK	LSN	SLC	TYPE	LP	SET	BPS	ATM	VCI	VPI	LL
1302	A	atmansio	0	LIMATM	3	1544000		TSEL EXTERNAL	35	15	0
1305	A	atmansii	0	LIMATM	4	1544000		INTERNAL	100	20	2
1318	A	atmansio	1	LIMATM	9	1544000		LINE	150	25	4

LOC	LINK	LSN	SLC	TYPE	LP	SET	BPS	ATM	VCI	VPI	CRC4	SI	SN
2101	A	atmitu1	0	LIME1ATM	5	2.048M		LINE	150	2	ON	1	20
2105	A	atmitu1	1	LIME1ATM	5	2.048M		LINE	35	15	ON	2	15

LOC	LINK	LSN	SLC	TYPE	IPLIML2
2202	A	lsnlp1	0	IPLIM	SAALTALI
2205	A	lsnip1	1	IPLIM	M2PA
2204	B	lsnlp2	0	IPLIM	M2PA
2213	A	lsnip5	0	IPLIMI	M2PA
2215	A	lsnlp2	1	IPLIM	SAALTALI

LOC	LINK	LSN	SLC	TYPE
2207	A	lsnlp3	0	SS7IPGW
2211	A	lsnlp4	0	IPGWI

LOC	LINK	LSN	SLC	TYPE	L2T	SET	BPS	ECM	PCR	PCR	E1	E1
									N1	N2	LOC	PORT TS

No Links Set Up.

LOC	LINK	LSN	SLC	TYPE	L2T	SET	BPS	ECM	PCR	PCR	T1	T1
									N1	N2	LOC	PORT TS

No Links Set Up.

SLK table is (31 of 1200) 6% full

2. Display the IP link associated with the card that the signaling link being removed the database is assigned to.

Enter the **rtrv-ip-lnk** command with the card location of the signaling link being removed shown in step 1. For this example, enter these commands.

rtrv-ip-lnk:loc=2205

The following is an example of the possible output.

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
2205	A	192.3.1.10	255.255.255.128	HALF	10	802.3	NO	NO
2205	B	-----	-----	HALF	10	DIX	NO	NO

rtrv-ip-lnk:loc=2204

The following is an example of the possible output.

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
2204	A	192.1.1.10	255.255.255.128	HALF	10	802.3	NO	NO
2204	B	-----	-----	HALF	10	DIX	NO	NO

3. Display the IP host information associated with the IP link by entering the **rtrv-ip-host** command with the IP address shown in step 2.

For this example, enter these commands.

rtrv-ip-host:ipaddr=192.001.001.010

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

LOCAL IPADDR	LOCAL HOST
192.1.1.10	IPNODE1_2204

IP Host table is (11 of 512) 2% full

rtrv-ip-host:ipaddr=192.003.001.010

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

LOCAL IPADDR	LOCAL HOST
192.3.1.10	IPNODE1_2205

IP Host table is (11 of 512) 2% full

4. Display the socket associated with the local host name shown in step 3 by entering the **rtrv-appl-sock** command.

For this example, enter these commands.

rtrv-appl-sock:lhost=ipnode1_2205

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

SNAME KC_HLR1_2202			
LINK	A		
LHOST	IPNODE1_2205		
RHOST	KC_HLR2		
LPORT	7000	RPORT	7001
SERVER	YES	DCMPS	1
REXMIT	FIXED	RTT	60
OPEN	YES	ALW	YES

IP Appl Sock/Assoc table is (4 of 4000) 1% full

rtrv-appl-sock:lhost=ipnode1_2204

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

IP Appl Sock/Assoc table is (4 of 4000) 1% full

NOTE: If there are no sockets assigned to the specified local host name, the rtrv-appl-sock output shows no socket information as shown above.

5. Change the **open** and **alw** parameter values in the socket shown in step 4 using the **chg-appl-sock** command with the **open=no** and **alw=no** parameters, as necessary.

NOTE: If there is no socket shown in step 4, or the open and alw parameter values of the socket shown in step 4 are no, skip this step and go to step 6.

For example, enter this command.

chg-appl-sock:sname=kc_hlr1_2202:open=no:alw=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

6. Display the association associated with the local host name shown in step 4 that was not assigned to a socket by entering the **rtrv-assoc** command.

For this example, enter this command.

```
rtrv-assoc: lhost=ipnode1_2204
```

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc1     2204 A    A    M2PA   1030  1030  YES  YES
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 2204
```

```
rtrv-assoc: lhost=ipnode1_2205
```

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
```

NOTE: If there are no associations assigned to the specified local host name, the **rtrv-assoc output shows no association information as shown above.**

7. Change the value of the **open** and **alw** parameters to **no** by specifying the **chg-assoc** command with the **open=no** and **alw=no** parameters, as necessary.

NOTE: If there is no association shown in step 6, or the **open and **alw** parameter values of the association shown in step 6 are **no**, skip this step and go to step 8.**

For this example, enter this command.

```
chg-assoc: aname=assoc1: open=no: alw=no
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

8. Deactivate the link to be removed using the **dact-slk** command, using the output from step 1 to obtain the card location and **link** parameter value of the signaling link to be removed.

For this example, enter these commands.

```
dact-slk: loc=2205: link=a
```

```
dact-slk: loc=2204: link=a
```

When each of these command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

9. Verify that the link is out of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-slk** command with the card location and **link** parameter values specified in step 8.

For this example, enter these commands.

rept-stat-slkl:loc=2205:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-23 13:06:25 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
2205,A   ls05      ls05clli  OOS-MT_DSBLD Unavail  ----
ALARM STATUS      = *    0235 REPT-LNK-MGTINH: local inhibited
UNAVAIL REASON    = LI
```

rept-stat-slkl:loc=2204:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-23 13:06:25 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
2204,A   ls04      ls04clli  OOS-MT      Unavail  ----
ALARM STATUS      = *    0235 REPT-LNK-MGTINH: local inhibited
UNAVAIL REASON    = LI
```

10. If the signaling link to be removed is the last signaling link on a card, the card must be inhibited before the signaling link is removed.

NOTE: If the signaling link being removed is not the last signaling link on the card, skip steps 10 and 11, and go to step 12.

Before entering the **dlt-slkl** command, enter the **rmv-card** command and specify the location of the card to be inhibited. The card location is shown in the output of **rept-stat-slkl** command executed in step 9.

In the example used for this procedure, the signaling link is the last signaling link on the card and must be inhibited. Enter these commands.

rmv-card:loc=2205

rmv-card:loc=2204

When each of these command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Card has been inhibited.
```

11. Verify that the card has been inhibited by entering the **rept-stat-card** command with the card location specified in step 10. For this example, enter these commands.

rept-stat-card:loc=2205

This is an example of the possible output.

```
rlghncxa03w 07-05-27 16:43:42 GMT EAGLE5 37.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
2205  114-001-000 DCM   IPLIM  OOS-MT-DSBLD Isolated  -----
ALARM STATUS      = **  0013 Card is isolated from the system
BPDCM GPL         = 002-102-000
IMT BUS A         = Disc
IMT BUS B         = Disc
SIGNALING LINK STATUS
SLK  PST  LS      CLLI      E5IS
A    OOS-MT  lsnlp1  -----  INACTIVE
```

Command Completed.

rept-stat-card:loc=2204

This is an example of the possible output.

```

rlghncxa03w 07-05-27 16:43:42 GMT EAGLE5 37.0.0
CARD   VERSION   TYPE      APPL      PST      SST      AST
2204   114-001-000 DCM        IPLIM      00S-MT-DSBLD Isolated -----
ALARM STATUS      = ** 0013 Card is isolated from the system
BPDCM GPL         = 002-102-000
IMT BUS A         = Disc
IMT BUS B         = Disc
SIGNALING LINK STATUS
  SLK   PST      LS      CLLI      E5IS
  A     00S-MT   lsnlp2  ----- INACTIVE

```

Command Completed.

12. Remove the signaling link from the EAGLE 5 ISS using the **dlt-slk** command.

If there is only one signaling link in the linkset, the **force=yes** parameter must be specified to remove the signaling link.

In the example used in this procedure, the signaling link is the last signaling link in the linkset. Enter these commands.

```
dlt-slk:loc=2205:link=a:force=yes
```

```
dlt-slk:loc=2204:link=a:force=yes
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-07 08:41:17 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD

```

13. Verify the changes using the **rtrv-slk** command with the card location and link values specified in step 12. For this example, enter these commands.

```
rtrv-slk:loc=2204:link=a
```

```
rtrv-slk:loc=2204:link=a
```

When the **rtrv-slk** command has completed, the specified signaling link is not shown in the **rtrv-slk** output, as shown in this example.

```

rlghncxa03w 07-05-19 21:16:37 GMT EAGLE5 37.0.0

LOC  LINK LSN      SLC TYPE      IPLIML2

No Links Set up.

```


14. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Flowchart 5-11. Removing an IPLIMx Signaling Link





Removing an IP Host Assigned to an IPLIMx Card

This procedure removes an IP host that is assigned to an IPLIMx card using the **dlt-ip-host** command.

The **dlt-ip-host** command uses the following parameter.

:host—Hostname. The hostname to be removed. This parameter identifies the logical name assigned to a device with an IP address.

No sockets and associations can reference the host name being removed in this procedure.

The sockets referencing the host name can be removed by performing the [Removing a Socket that is Assigned to an IPLIMx Signaling Link](#) procedure or the host name in these sockets can be changed by performing the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure. The host name assigned to sockets is displayed in the **rtrv-appl-sock** outputs.

The associations referencing the host name can be removed by performing the [Removing an M2PA Association](#) procedure or the host name in these associations can be changed by performing the [Changing an M2PA Association](#) procedure. The host name assigned to associations is displayed in the **rtrv-assoc** outputs.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

LOCAL IPADDR	LOCAL HOST
192.1.1.10	IPNODE1-1201
192.1.1.12	IPNODE1-1203
192.1.1.14	IPNODE1-1205
192.1.1.20	IPNODE2-1201
192.1.1.22	IPNODE2-1203
192.1.1.24	IPNODE2-1205
192.1.1.30	KC-HLR1
192.1.1.32	KC-HLR2
192.1.1.50	DN-MSC1
192.1.1.52	DN-MSC2
192.3.3.33	GW100. NC. TEKELEC. COM

REMOTE IPADDR	REMOTE HOST
150.1.1.5	NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (12 of 512) 2% full

2. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-link** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
```

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
1303	A	192.1.1.10	255.255.255.128	HALF	10	802.3	NO	NO
1303	B	-----	-----	HALF	10	DIX	NO	NO
1305	A	192.1.1.12	255.255.255.0	----	---	DIX	YES	NO
1305	B	-----	-----	HALF	10	DIX	NO	NO
1313	A	192.1.1.14	255.255.255.0	FULL	100	DIX	NO	NO
1313	B	-----	-----	HALF	10	DIX	NO	NO
2101	A	192.1.1.20	255.255.255.0	FULL	100	DIX	NO	NO
2101	B	-----	-----	HALF	10	DIX	NO	NO
2103	A	192.1.1.22	255.255.255.0	FULL	100	DIX	NO	NO
2103	B	-----	-----	HALF	10	DIX	NO	NO
2105	A	192.1.1.24	255.255.255.0	FULL	100	DIX	NO	NO
2105	B	-----	-----	HALF	10	DIX	NO	NO
2205	A	192.1.1.30	255.255.255.0	FULL	100	DIX	NO	NO
2205	B	-----	-----	HALF	10	DIX	NO	NO
2207	A	192.1.1.32	255.255.255.0	FULL	100	DIX	NO	NO
2207	B	-----	-----	HALF	10	DIX	NO	NO
2213	A	192.1.1.50	255.255.255.0	FULL	100	DIX	NO	NO
2213	B	-----	-----	HALF	10	DIX	NO	NO
2301	A	192.1.1.52	255.255.255.0	FULL	100	DIX	NO	NO
2301	B	-----	-----	HALF	10	DIX	NO	NO

```

2305 A 192.3.3.33 255.255.255.0 FULL 100 DIX NO NO
2305 B ----- HALF 10 DIX NO NO
    
```

- Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```

rlghncxa03w 07-05-28 09:12:36 GMT EAGLE5 37.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM        SCCP
1102   TSM        GLS
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI  sp2            A    0    sp1            B    0
1203   LIMDS0     SS7ANSI  sp3            A    0
1204   LIMDS0     SS7ANSI  sp3            A    1
1206   LIMDS0     SS7ANSI  nsp3           A    1    nsp4           B    1
1207   LIMV35     SS7GX25  nsp1           A    0
1208   LIMV35     SS7GX25  nsp1           A    1
1216   ACMENET     STPLAN
1301   LIMDS0     SS7ANSI  sp6            A    1    sp7            B    0
1302   LIMDS0     SS7ANSI  sp7            A    1    sp5            B    1
1303   DCM        IPLIM    ipnode1        A    0    ipnode3        B    1
1305   DCM        IPLIM    ipnode4        A    0
1307   ACMENET     STPLAN
1313   DCM        SS7IPGW  ipgtwy1        A    0
2101   DCM        SS7IPGW  ipgtwy2        A    0
2103   DCM        SS7IPGW  ipgtwy3        A    0
2105   DCM        IPLIM    ipnode1        A1   1    ipnode5        B    2
2205   DCM        IPLIM    ipnode3        A2   0    ipnode6        B1   2
2207   DCM        IPLIM    ipnode5        A    0    ipnode4        B3   1
2213   DCM        IPLIM    ipnode5        A3   1    ipnode3        B2   2
2301   DCM        IPLIM    ipnode6        A    0    ipnode1        B    2
2305   DCM        IPLIM    ipnode6        A1   1    ipnode1        B1   3
    
```

Select an IP host whose IP address is assigned to a card running the IPLIM or IPLIMI application.

- Display the sockets referencing the host name being removed in this procedure by entering the **rtrv-appl-sock** command.

For this example, enter this command.

```
rtrv-appl-sock: lhost=gw100.nc.tekelec.com
```

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_1103
LINK   A
LHOST  GW100. NC. TEKELEC. COM
RHOST  KC_HLR2
LPORT  7000      RPORT  7001
SERVER YES      DCMP5   1
REXMIT FIXED    RTT     60
OPEN   YES      ALW     YES
    
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

If no sockets referencing the host name being removed in this procedure are shown in this step, go to step 5.

Any sockets referencing the host name must either be removed or the host name assigned to the socket must be changed. To remove the sockets, perform the [Removing a Socket that is Assigned to an IPLIMx Signaling Link](#) procedure.

Go to step 5 after the sockets have been removed.

To change the host name assigned to the sockets, perform the [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#) procedure.

Go to step 5 after the host name assigned to the sockets have been changed.

5. Display the associations referencing the host name being removed in this procedure by entering the **rtrv-assoc** command with the local host name.

For this example, enter this command.

rtrv-assoc: lhost=gw100.nc.tekelec.com

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
a2         2305 A    A    M2PA   7205  7001  NO   NO
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (200 KB of 1600 KB) on LOC = 2305
```

If no associations referencing the host name being removed in this procedure are shown in this step, go to step 6.

Any associations referencing the host name must either be removed or the host name assigned to the association must be changed.

To remove the associations, perform the [Removing an M2PA Association](#) procedure.

Go to step 6 after the associations have been removed.

To change the host name assigned to the associations, perform the [Changing an M2PA Association](#) procedure.

Go to step 6 after the host name assigned to the associations have been changed.

6. Delete IP host information from the database by entering the **dlt-ip-host** command.

For example, enter this command.

dlt-ip-host: host=gw100.nc.tekelec.com

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
DLT-IP-HOST: MASP A - COMPLTD
```

7. Verify the changes by entering the **rtrv-ip-host** command with the host name specified in step 6.

For this example, enter this command.

rtrv-ip-host: host=gw100.nc.tekelec.com

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR    LOCAL HOST
```

```
IP Host table is (10 of 512) 2% full
```


8. Back up the new changes using the **chg-db: action=backup: dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
```

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 5-12. Removing an IP Host Assigned to an IPLIMx Card





Removing an IP Route

This procedure is used to remove an IP route from the database using the **dlt-ip-rte** command.

The **dlt-ip-rte** command uses these parameters.

: **loc** – The location of the IP card containing the IP route being removed.

:dest – The IP address of the remote host or network assigned to the IP route being removed.

:force – To remove the IP route, the IP card that the route is assigned to must be out of service, or the **force=yes** parameter must be specified with the **dlt-ip-rte** command. The **force=yes** parameter allows the IP route to be removed if the IP card is in service.



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20   255.255.0.0      150.1.1.50
1301 128.252.10.5     255.255.255.255  140.188.13.33
1301 128.252.0.0      255.255.0.0      140.188.13.34
1301 150.10.1.1       255.255.255.255  140.190.15.3
1303 192.168.10.1     255.255.255.255  150.190.15.23
1303 192.168.0.0      255.255.255.0    150.190.15.24
```

IP Route table is (6 of 1024) 1% full

2. Verify the state of the IP card containing the IP route being removed by entering the **rept-stat-card** command and specifying the card location of the IP card.

The IP card should be in the out-of-service maintenance-disabled (OOS-MT-DSBLD) in order to remove the IP route. If the IP card's state is out-of-service maintenance-disabled, the entry **OOS-MT-DSBLD** is shown in the **PST** column of the **rept-stat-card** output. For this example, enter this command.

rept-stat-card:loc=1301

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST      SST      AST
1301  114-000-000  DCM   IPLIM  IS-NR    Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST      LS      CLLI
A     IS-NR    nc001   -----
```

Command Completed.

NOTE: If the output of step 2 shows that the IP card's state is not OOS-MT-DSBLD, and you do not wish to change the state of the IP card, skip step 3 and go to step 4.

3. Change the IP card's state to OOS-MT-DSBLD using the **inh-card** command and specifying the card location of the IP card.

For this example, enter these commands.

inh-card:loc=1301

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Card has been inhibited.
```

4. Remove the IP route from the database using the **dlt-ip-rte** command.

If the state of the IP card is not OOS-MT-DSBLD, the **force=yes** parameter must be specified with the **dlt-ip-rte** command. For this example, enter this command.

dlt-ip-rte:loc=1301:dest=128.252.0.0



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20    255.255.0.0      150.1.1.50
1301 128.252.10.5      255.255.255.255  140.188.13.33
1301 150.10.1.1        255.255.255.255  140.190.15.3
1303 192.168.10.1      255.255.255.255  150.190.15.23
1303 192.168.0.0       255.255.0.0      150.190.15.24
```

IP Route table is (5 of 1024) 1% full

6. Place the IP card back into service by using the **alw-card** command.

NOTE: If the IP card containing the IP route that was removed from the database does not contain other IP routes, skip step 6 and go to step 7.

For example, enter this command.

alw-card:loc=1301

This message should appear.


```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

7. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-13. Removing an IP Route



Removing an M2PA Association

This procedure is used to remove an association from the database using the **dlt-assoc** command.

The **dlt-assoc** command uses one parameter, **aname**, the name of the association being removed from the database. The association being removed must be in the database.

The **open** parameter must be set to **no** before the association can be removed. Use the **chg-assoc** command to change the value of the **open** parameter.

The **adapter** value assigned to the association being removed in this procedure must be **m2pa**.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

ANAME	CARD	IPLNK	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW
swbel32	1201	A	A		M3UA	1030	2345	YES	YES	
a2	1305	A	A		SUA	1030	2345	YES	YES	
a3	1307	A	A		SUA	1030	2346	YES	YES	
assoc1	1203	A	A1		M2PA	2048	1030	NO	NO	

2. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

NOTE: If the value of the **open** parameter for the association being removed from the database (shown in step 1) is **no**, skip this step and go to step 4.

For this example, enter this command.

```
chg-assoc:aname=assoc1:open=no
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

3. Remove the association from the database using the **dlt-assoc** command.

For this example, enter this command.

dlt-assoc:aname=assoc1

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
DLT-ASSOC: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-assoc** command with the name of the association specified in step 4.

For this example, enter this command.


rtrv-assoc:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
IP Appl Sock table is (3 of 4000) 1% full
```

5. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-14. Removing an M2PA Association

Changing IETF M2PA Components

This section describes how to change the attributes of the following components in the database.

- An M2PA Association – Perform the [Changing an M2PA Association](#) procedure
- The SCTP retransmission parameters – Perform the [Changing the SCTP Checksum Algorithm Option for M2PA Associations](#) procedure
- A M2PA timer set – Perform the [Changing an M2PA Timer Set](#) procedure
- The SCTP Checksum Algorithm – Perform the [Changing the SCTP Checksum Algorithm Option for M2PA Associations](#) procedure
- Turn off the Large BICC MSU Support for IP Signaling feature – Perform the [Turning the Large BICC MSU Support for IP Signaling Feature Off](#) procedure.

Changing an M2PA Association

This procedure is used to change the values of the attributes of an M2PA association using the **chg-assoc** command.

The **chg-assoc** command uses these parameters:

:aname – The name assigned to the association. Valid association names can contain up to 15 alphanumeric characters where the first character is a letter and the remaining characters are alphanumeric characters. The **aname** parameter value is not case-sensitive.

:lhost – The host name for the local host, **lhost** can be any string of characters starting with a letter and comprising these characters ['a'..'z', 'A'..'Z', '0'..'9', '-', '.']. Hostnames are not case-sensitive and can contain up to 60 characters. The default value of this optional parameter is empty (null string).

:lport – The SCTP port number for the local host.

:rhost – The host name for the remote host, **rhost** can be any string of characters starting with a letter and comprising these characters ['a'..'z', 'A'..'Z', '0'..'9', '-', '.']. Hostnames are not case-sensitive and can contain up to 60 characters. The default value of this optional parameter is empty (null string).

:rport – The SCTP port number for the remote host.

:link – The signaling link on the IPLIMx card. If the card is a single-slot EDCM, the values for the **link** parameter can be **a, a1, a2, a3, b, b1, b2, or b3**.

If the card is a E5-ENET card, the values for the **link** parameter can be **a, a1, a2, a3, a4, a5, a6, a7, b, b1, b2, b3, b4, b5, b6, or b7**.

NOTE: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

:adapter – The adapter layer for this association, **m2pa**.

:open – The connection state for this association. Valid values are **yes** or **no**. When the **open=yes** parameter is specified, the connection manager opens the association if the association is operational. When the **open=no** parameter is specified, the connection manager will not open the association.

:alw – The connection state for this association. Valid values are **yes** or **no**. When the **alw=yes** parameter is specified, the connection manager allows the association to carry SS7 traffic. When the **alw=no** parameter is specified, the connection manager prohibits the association from carrying SS7 traffic.

:rmode – The retransmission policy used when packet loss is detected. The values are **rfc** or **lin**.

- **rfc** – Standard RFC 2960 algorithm in the retransmission delay doubles after each retransmission. The RFC 2960 standard for congestion control is also used.
- **lin** – Tekelec's linear retransmission policy where each retransmission timeout value is the same as the initial transmission timeout and only the slow start algorithm is used for congestion control.

:rmin – The minimum value of the calculated retransmission timeout in milliseconds, from 10 - 1000.

:rmax – The maximum value of the calculated retransmission timeout in milliseconds, from 10 - 1000.

:rtimes – The number of times a data retransmission will occur before closing the association from 3 - 12.

:cwmmin – The minimum size in bytes of the association's congestion window and the initial size in bytes of the congestion window, from 1500 - 196608.

The **rmode**, **rmin**, **rmax**, **rtimes**, and **cwmin** parameters are used to configure the SCTP retransmission controls for an association, in addition to other commands. Go to the [Configuring SCTP Retransmission Control for an M2PA Association](#) procedure to configure the SCTP retransmission controls for an association.

:istrms – The number of inbound streams (1 or 2) advertised by the SCTP layer for the association.

:ostrms – The number of outbound streams (1 or 2) advertised by the SCTP layer for the association.

:m2patset – The M2PA timer set assigned to the association. The **m2patset** parameter can be specified only with the **adatper=m2pa** parameter, or if the association already has the **adapter=m2pa** parameter assigned and the **adapter** parameter value is not being changed. If the **adapter** parameter value is being changed to **m2pa**, and the **m2patset** parameter is not specified, the default value for the **m2patset** parameter (1 - M2PA timer set 1) is assigned to the association. If the **adapter** parameter value for the association is **m2pa**, is not being changed, and the **m2patset** parameter is not specified with the **chg-assoc** command, the **m2patset** parameter value is not changed.

:ver – The M2PA version assigned to the M2PA association, either the RFC version (**ver=rfc**), or the Draft 6 version (**ver=d6**). The **ver** parameter can be specified only if, when this procedure is completed, the **adapter** parameter value is **m2pa**. If the **adapter** parameter value is being changed to **m2pa**, and the **ver** parameter is not specified, the default M2PA version of RFC is assigned to the association. To change the **ver** parameter value, the **open** parameter value for the association must be **no**.

:bufsize – The size, in kilobytes, of the buffer used by the association. The values for this parameter are 8 kilobytes to 400 kilobytes. The maximum size of the buffers on the single-slot EDCMs and E5-ENET cards are shown in the following list.

- Single-Slot EDCM - 1600 kB
- E5-ENET Card - 3200 kB

The size of the buffers assigned to each association that is assigned to the IP card cannot exceed the maximum buffer size for that card. If the **bufsize** parameter value causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **chg-assoc** command will be rejected. The available size of the buffers on the IP card can be verified by entering this command.

rtrv-assoc:lhost=<local host name assigned to the association being changed>

The **alhost** parameter can also be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card.

The **aname** parameter can be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card and the size of the buffer assigned to the association.

If you wish to increase the buffer size for this association to a value that is greater than available buffer size for the card, the buffer size of the other associations assigned to the card must be decreased.

:rtxthr – The retransmission threshold for the association. The **rtxthr** parameter value indicates the number of retransmissions that can occur on the association that when exceeded will generate UAM 0537, Ethernet Error Threshold Exceeded. The value of this parameter is 0 to 65,535. The value of this parameter is shown in the **RTXTHR** field of the **rtrv-assoc:aname=<association name>** output. The **rtxthr** parameter value can be changed if the **open** parameter value is either **yes** or **no**.

If the value of the **open** parameter is **yes**, only the value of the **alw** parameter can be changed. To change the values of other parameters, the value of the **open** parameter must be **no**.

To set the **open** parameter value to **yes**, the association specified by the **aname** parameter must contain values for the **lhost**, **lport**, **rhost**, and **rport** parameters. The **lhost** parameter value must have a signaling link assigned to it.

At least one optional parameter is required.

The command input is limited to 150 characters, including the hostnames.

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

IPLIMx cards can have one association for each signaling link on the card. The single-slot EDCM can contain a maximum of eight signaling links, resulting in a maximum of eight associations for this card. The E5-ENET card can contain a maximum of 16 signaling links, resulting in a maximum of 16 associations for this card.

The B Ethernet interface of the IP card can be used on single-slot EDCMs and E5-ENET cards..

The value of the **rmin** parameter must be less than or equal to the **rmax** parameter value.

The **ipliml2** parameter value of the signaling link assigned to the association must be **m2pa**. The **adapter** parameter value of the association must match the **ipliml2** parameter value.

The signaling link being assigned to the association must be out of service. This state is shown in the **rept-stat-slk** output with the entries **OOS-MT** in the **PST** field and **Unavail** in the **SST** field.

If the association is being opened in this procedure with the **chg-assoc** command and the **open=yes** parameter, the signaling link assigned to the association must be in the database and the **ipliml2** parameter value of the signaling link assigned to the association must be **m2pa**.

Uni-homed endpoints are associations configured with the **lhost** parameter only. The **lhost** parameter value represents an IP address that corresponds to either the A or B network interface of the IP card. Multi-homed endpoints are associations configured with both the **lhost** and **alhost** parameters. The **lhost** parameter value represents an IP address corresponding to one of the network interfaces (A or B) of the IP card while the **alhost** parameter value represents an IP address corresponding to the other network interface of the same IP card.

The **alhost=none** parameter removes the alternate local host from the specified association, which also removes the multi-homed endpoint capability.

Canceling the RTRV-ASSOC and RTRV-AS Commands

Because the **rtrv-assoc** and **rtrv-as** commands used in this procedure can output information for a long period of time, the **rtrv-assoc** and **rtrv-as** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** and **rtrv-as** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered, from another terminal other than the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

	CARD	IPLNK							
ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW	
swbel32	1201	A	A	M3UA	1030	2345	YES	YES	
a2	1305	A	A	SUA	1030	2345	YES	YES	
a3	1307	A	A	SUA	1030	2346	YES	YES	
assoc1	1201	A	A	M3UA	2000	1030	YES	YES	
assoc2	1205	A	A	M3UA	2048	2048	YES	YES	
assoc3	1205	A	A	M3UA	3000	3000	YES	YES	
assoc5	1205	A	A	M3UA	1500	3000	YES	YES	

NOTE 1: To change the values of these parameters: **lhost**, **lport**, **rhost**, **rport**, **alhost**, **link**, **adapter**, **rmode**, **rmin**, **rmax**, **rtimes**, **cwmin**, **istrms**, **ostrms**, **ver**, **uaps**, or **bufsize**, the value of the **open** parameter must be **no**. If the values of any of these parameters are being changed and the **open** parameter value for the association being changed is **no**, skip step 2 and go to step 3.

NOTE: If only the values of the **alw** or **open** parameters are being changed, skip steps 2 through 19, and go to step 20.

2. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

For this example, enter this command.

chg-assoc:aname=assoc2:open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

3. Display the association being changed by entering the **rtrv-assoc** command with the **aname** parameter specified in step 2.

For this example, enter this command.

rtrv-assoc:aname=assoc2

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
ANAME assoc2
LOC 1205 IPLNK PORT A LINK A
ADAPTER M2PA VER M2PA RFC
LHOST IPNODE2-1205
ALHOST ---
RHOST remotehost1
LPORT 2048 RPORT 2048
ISTRMS 2 OSTRMS 2 BUFSIZE 400
RMODE LIN RMIN 120 RMAX 800
RTIMES 10 CWMIN 3000 M2PATSET 1
OPEN NO ALW YES RTXTHR 2000
```

```
IP Appl Sock/Assoc table is (8 of 4000) 1% full
Assoc Buffer Space Used (1600 KB of 1600 KB) on LOC = 1205
```

NOTE: If the buffer size of the association is not being changed, skip steps 4 through 6, and go to step 7.

4. If the **bufsize** parameter value causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **chg-assoc** command will be rejected.

If you wish to increase the buffer size for this association to a value that is greater than available buffer size for the card, the buffer size of the other associations assigned to the card must be decreased. Perform this step and steps 5 and 6.

If the buffers on the other associations assigned to the card do not need to be changed, skip this step and steps 5 and 6, and go to step 7.

Display the associations assigned to the IP card (and its corresponding local host) by entering the **rtrv-assoc** command with the local host name assigned to the association being changed. For this example, enter this command.

rtrv-assoc:lhost=IPNODE2-1205

This is an example of the possible output.

```
r1ghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME LOC PORT LINK ADAPTER LPORT RPORT OPEN ALW
assoc2 1205 A A M2PA 2048 2048 YES YES
assoc3 1205 A B2 M2PA 3000 3000 YES YES
assoc5 1205 A A3 M2PA 1500 3000 YES YES
```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
Assoc Buffer Space Used (1600 KB of 1600 KB) on LOC = 1205

5. Display each association shown in step 4 by entering the **rtrv-assoc** command with the name of each association shown in step 4.

For this example, enter these commands.

rtrv-assoc:aname=assoc2

This is an example of the possible output.

```
ANAME assoc2
LOC 1205 IPLNK PORT A LINK A
ADAPTER M2PA VER M2PA RFC
LHOST IPNODE2-1205
ALHOST ---
RHOST remotehost1
LPORT 2048 RPORT 2048
ISTRMS 2 OSTRMS 2 BUFSIZE 400
RMODE LIN RMIN 120 RMAX 800
RTIMES 10 CWMIN 3000 M2PATSET 1
OPEN NO ALW YES RTXTHR 2000
```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
Assoc Buffer Space Used (1600 KB of 1600 KB) on LOC = 1205

rtrv-assoc:aname=assoc3

This is an example of the possible output.

```
ANAME assoc3
LOC 1205 IPLNK PORT A LINK A
ADAPTER M2PA VER M2PA RFC
LHOST IPNODE2-1205
ALHOST ---
RHOST remotehost3
LPORT 3000 RPORT 3000
ISTRMS 2 OSTRMS 2 BUFSIZE 800
RMODE LIN RMIN 120 RMAX 800
RTIMES 10 CWMIN 3000 M2PATSET 1
OPEN YES ALW YES RTXTHR 2000
```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (1600 KB of 1600 KB) on LOC = 1205

rtrv-assoc:aname=assoc5

This is an example of the possible output.

ANAME	assoc5						
LOC	1205	IPLNK	PORT	A	LINK	A	
ADAPTER	M2PA	VER		M2PA	RFC		
LHOST	IPNODE2-1205						
ALHOST	---						
RHOST	remotehost3						
LPORT	1500	RPORT	3000				
ISTRMS	2	OSTRMS	2		BUFSIZE	400	
RMODE	LIN	RMIN	120		RMAX	800	
RTIMES	10	CWMIN	3000		M2PATSET	1	
OPEN	YES	ALW	YES		RTXTHR	2000	

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (1600 KB of 1600 KB) on LOC = 1205

- Change the size of the buffers for one or more of the associations displayed in step 3 to allow the buffer of the association displayed in step 3 to be changed.

Enter the **chg-assoc** command with the **bufsize** parameter. For this example, enter this command.

chg-assoc:aname=assoc3:bufsize=400

When this command has successfully completed, this message should appear.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
 CHG-ASSOC: MASP A - COMPLTD;

NOTE: If the local host name assigned to the association is not being changed, skip steps 7 through 12 and go to step 13.

- Verify that the local host name to be assigned to the association is in the database by using the **rtrv-ip-host** command.

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR	LOCAL HOST
192.1.1.10	IPNODE1-1201
192.1.1.12	GW105. NC. TEKELEC. COM
192.1.1.14	IPNODE1-1205
192.1.1.20	IPNODE2-1201
192.1.1.22	IPNODE2-1203
192.1.1.24	IPNODE2-1205
192.1.1.30	KC-HLR1
192.1.1.32	KC-HLR2
192.1.1.50	DN-MS1
192.1.1.52	DN-MS2

REMOTE IPADDR	REMOTE HOST
150.1.1.5	NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (11 of 512) 2% full

- Display the IP links in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
1303	A	192.1.1.10	255.255.255.128	HALF	10	802.3	NO	NO
1303	B	-----	-----	HALF	10	DIX	NO	NO
1305	A	192.1.1.12	255.255.255.0	----	---	DIX	YES	NO

1305	B	-----	-----	HALF	10	DIX	NO	NO
1313	A	192.1.1.14	255.255.255.0	FULL	100	DIX	NO	NO
1313	B	-----	-----	HALF	10	DIX	NO	NO
2101	A	192.1.1.20	255.255.255.0	FULL	100	DIX	NO	NO
2101	B	-----	-----	HALF	10	DIX	NO	NO
2103	A	192.1.1.22	255.255.255.0	FULL	100	DIX	NO	NO
2103	B	-----	-----	HALF	10	DIX	NO	NO
2105	A	192.1.1.24	255.255.255.0	FULL	100	DIX	NO	NO
2105	B	-----	-----	HALF	10	DIX	NO	NO
2205	A	192.1.1.30	255.255.255.0	FULL	100	DIX	NO	NO
2205	B	-----	-----	HALF	10	DIX	NO	NO
2207	A	192.1.1.32	255.255.255.0	FULL	100	DIX	NO	NO
2207	B	-----	-----	HALF	10	DIX	NO	NO
2213	A	192.1.1.50	255.255.255.0	FULL	100	DIX	NO	NO
2213	B	-----	-----	HALF	10	DIX	NO	NO
2301	A	192.1.1.52	255.255.255.0	FULL	100	DIX	NO	NO
2301	B	-----	-----	HALF	10	DIX	NO	NO

If the required IP link, one that contains the desired IP address, is not shown in the **rtrv-ip-lnk** output, add the IP link using the [Configuring an IP Link](#) procedure. After the IP link has been added, assign the IP address of the IP link to the IP host name using the [Adding an IP Host](#) procedure. Then go to step 12.

If the required IP link is shown in the **rtrv-ip-lnk** output, assign the IP address of the IP link to the IP host name using the [Adding an IP Host](#) procedure. Then go to step 13.

If the required IP host was shown in step 7, the required IP link is shown in the **rtrv-ip-lnk** output in this step. Perform step 9 to verify the application running on the card whose IP address is assigned to the IP host.

9. Display the application running on the IP card shown in step 8 whose IP address is assigned to the IP host using the **rept-stat-card** command specifying the location of the IP card.

For this example, enter this command.

rept-stat-card: loc=1205

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE  APPL    PST      SST      AST
1205  114-000-000    DCM   IPLIM   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        e5e6a      -----
A3    IS-NR        e5e6a      -----
B2    IS-NR        e5e6a      -----
```

Command Completed.

10. Display the signaling link associated with the association being changed using the **rtrv-slk** command and specifying the card location shown in step 9, and the new **link** parameter value of the association for the **link** parameter value. The card location should reference the local host assigned to the association. The **rtrv-ip-lnk** output shows the card location associated with the IP address that is associated with the local host in step 9. If the **rtrv-ip-lnk** command was not executed in step 8, execute it now to get the card location and the IP address. To display the signaling link for this example, enter this command.

NOTE: If the link parameter value is not being changed, skip step 10 and go to step 11.

rtrv-slk: loc=1203: link=a

The following is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
```


LOC	LINK	LSN	SLC	TYPE	IPLIML2
1203	A	e5e6a	1	IPLIM	M2PA

If the required signaling link is not in the database, add the signaling link using the [Adding an IPLIMx Signaling Link](#) procedure without activating the signaling link. If the application of the card containing the signaling link is IPLIM or IPLIMI, the **ipliml2=m2pa** parameter must be specified for the signaling link and the **adapter=m2pa** parameter value must be specified for the association.

NOTE: If the adapter parameter value is not being changed from M3UA or SUA to M2PA, skip this step and go to step 12.

11. Display the application servers referencing the association being changed using the **rtrv-as** command with the name of the association being changed in this procedure.

NOTE: If the associations assigned to the IP card were displayed in either step 5 with the rtrv-assoc command and the aname parameter, or step 12 with the rtrv-as command, the rtrv-as command does need to be performed. The application servers assigned to the associations that are assigned to the IP card are displayed in the rtrv-assoc output in step 5 or in the rtrv-as output in step 12.

For this example, enter this command.

rtrv-as:aname=assoc2

This is an example of possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE  2000      assoc2

as4          LOADSHARE  2000      assoc2

as6          LOADSHARE  2000      assoc2

AS Table is (6 of 250) 1% full
```

If the association is assigned to any application servers, go to the [Removing an Association from an Application Server](#) procedure and remove the association from the application servers.

NOTE: If the rept-stat-card command was performed in step 9, skip step 15 and go to step 16.

12. Display the application running on the IP card shown in step 8 using the **rept-stat-card** command specifying the location of the IP card.

For this example, enter this command.

rept-stat-card:loc=1205

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD VERSION      TYPE      APPL      PST      SST      AST
1205 114-000-000  DCM      IPLIM     IS-NR     Active    -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST          LS          CLLI
A    IS-NR        e5e6a      -----
A3   IS-NR        e5e6a      -----
B2   IS-NR        e5e6a      -----
```

Command Completed.

NOTE: If a new signaling link was added in step 10, skip steps 13, 14, 15, and 16, and go to step 17.

13. Display the signaling link that will be assigned to the association by entering the **rtrv-slk** command and specifying the card location and signaling link.

For this example, enter this command.

rtrv-slk:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE   IPLIML2
1203  A    e5e6a        1  IPLIM    M2PA
```

When the IP card's application is either IPLIM or IPLIMI, the **ipliml2** parameter value for the signaling link assigned to the association must be **m2pa**. If the **ipliml2** parameter is not **m2pa**, remove the signaling link using the [Removing an IPLIMx Signaling Link](#) procedure. Add the signaling link back into the database with the **ipliml2=m2pa** parameter, and without activating the signaling link, using the [Adding an IPLIMx Signaling Link](#) procedure.

NOTE: If the [Adding an IPLIMx Signaling Link](#) procedure was not performed in step 13, skip steps 14, 15, and 16, and go to step 17.

14. Display the status of the signaling link shown in step 13 using the **rept-stat-slk** command specifying the card location and signaling link.

For example, enter this command.

rept-stat-slk:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1203,A e5e6a    ----- IS-NR      Avail    ----
Command Completed.
```

NOTE: If the primary state (PST) of the signaling link is OOS-MT and the secondary state (SST) is Unavail, skip steps 15 and 16, and go to step 17.

15. Deactivate the signaling link from step 14 using the **dact-slk** command.

For example, enter this command.

dact-slk:loc=1203:link=a

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

16. Verify the status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1203:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1203,A e5e6a    ----- OOS-MT      Unavail  ----
Command Completed.
```

NOTE: If the current value of the association's adapter parameter is m2pa and the M2PA timer set assigned to the association will not be changed, skip steps 17 and 18, and go to step 19.

17. Verify the values of the M2PA timer set you wish to assign to the association by entering the **rtrv-m2pa-tset** command with the M2PA version (either **ver=rfc** to display the RFC M2PA timer values or **ver=d6** to display the Draft 6 M2PA timer values) of the timer set you wish to assign to the association.

If the **ver** parameter is not specified with the **rtrv-m2pa-tset** command, both the RFC and Draft 6 timer values are displayed.

NOTE: If the m2patset parameter will not be specified with the chg-assoc command, and the adapter parameter value is being changed to m2pa, the RFC version of M2PA timer set 1 will be assigned to the association.

To display the M2PA Draft 6 timer values, enter this command.

rtrv-m2pa-tset:ver=d6

This is an example of the possible output.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	-----	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	-----	1500	2000	500	9000	1250	300	150000	175	600
3	100000	-----	2000	3000	500	4000	1500	500	170000	200	800
4	200000	-----	20000	4000	500	6000	2000	700	480000	225	900
5	250000	-----	30000	30000	500	100	2250	400	400000	400	8000
6	50000	-----	50000	60000	500	500	4500	800	300000	300	7000
7	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
8	80000	-----	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	-----	3850	4859	450	5700	3750	1150	250	375	8750
10	90000	-----	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	-----	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	-----	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	-----	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	-----	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	-----	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	-----	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	-----	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	-----	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	-----	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	-----	1000	1000	400	80	1000	200	100	100	100

To display the M2PA RFC values, enter this command.

rtrv-m2pa-tset:ver=rfc

This is an example of the possible output.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	75000	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	8000	1500	2000	500	9000	1250	300	150000	175	600
3	100000	10000	2000	3000	500	4000	1500	500	170000	200	800
4	200000	6000	20000	4000	500	6000	2000	700	480000	225	900
5	250000	140000	30000	30000	500	100	2250	400	400000	400	8000
6	50000	100000	50000	60000	500	500	4500	800	300000	300	7000
7	300000	20000	2000	10000	500	1000	3000	1200	200000	250	1000
8	80000	130000	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	120000	3850	4859	450	5700	3750	1150	250	375	8750

10	90000	9000	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	60000	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	50000	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	90000	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	45000	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	30000	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	15000	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	150000	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	20000	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	12500	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	5000	1000	1000	400	80	1000	200	100	100	100

If the **ver** parameter is not specified when entering the **rtrv-m2pa-tset** command, both the Draft 6 and RFC values are displayed. This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	-----	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	-----	1500	2000	500	9000	1250	300	150000	175	600
3	100000	-----	2000	3000	500	4000	1500	500	170000	200	800
4	200000	-----	20000	4000	500	6000	2000	700	480000	225	900
5	250000	-----	30000	30000	500	100	2250	400	400000	400	8000
6	50000	-----	50000	60000	500	500	4500	800	300000	300	7000
7	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
8	80000	-----	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	-----	3850	4859	450	5700	3750	1150	250	375	8750
10	90000	-----	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	-----	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	-----	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	-----	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	-----	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	-----	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	-----	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	-----	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	-----	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	-----	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	-----	1000	1000	400	80	1000	200	100	100	100

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	75000	5000	20000	500	5000	4000	1000	100000	150	500
2	7500	8000	1500	2000	500	9000	1250	300	150000	175	600
3	100000	10000	2000	3000	500	4000	1500	500	170000	200	800
4	200000	6000	20000	4000	500	6000	2000	700	480000	225	900
5	250000	140000	30000	30000	500	100	2250	400	400000	400	8000
6	50000	100000	50000	60000	500	500	4500	800	300000	300	7000
7	300000	20000	2000	10000	500	1000	3000	1200	200000	250	1000
8	80000	130000	1500	15000	500	8000	2750	1100	350000	350	5000
9	27500	120000	3850	4859	450	5700	3750	1150	250	375	8750
10	90000	9000	2500	50000	500	7500	5000	1750	440000	450	3000
11	20000	60000	4500	5500	500	6500	5500	1600	250000	475	4500
12	30000	50000	7500	7000	500	750	4250	1800	275000	275	3500
13	40000	90000	35000	9000	500	1250	3500	1900	500	325	9000
14	70000	45000	45000	11000	500	1500	1750	900	1000	125	6000
15	9000	30000	25000	40000	500	2500	3250	600	5000	425	5500
16	75000	15000	15000	25000	500	4500	1600	1400	6000	240	9500
17	350000	150000	60000	70000	600	10000	6000	2000	500000	500	10000
18	150000	20000	55000	35000	500	3500	5750	1500	125000	440	750
19	175000	12500	12500	45000	500	1100	2600	1300	7000	340	850
20	1000	5000	1000	1000	400	80	1000	200	100	100	100

If the M2PA timer set you wish to assign to the association does not contain the desired values, go to the [Changing an M2PA Timer Set](#) procedure and changed the desired timer values.



CAUTION: Changing an M2PA timer set may affect the performance of any associations using the timer set being changed.

18. Change the association using the **chg-assoc** command.

For this example, enter this command.

```
chg-assoc:aname=assoc2:rhost="gw200.nc-
tekelec.com":rport=3000 :bufsize=500:rtxtthr=10000
```

NOTE: See [Flowchart 5-15](#) (Sheet 8) for the rules that apply to the **chg-assoc** command.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

NOTE: If the value of the **open** parameter was not changed in step 2, skip step 17 and go to step 18.

19. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

For this example, enter this command.

```
chg-assoc:aname=assoc2:open=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

20. Verify the changes using the **rtrv-assoc** command specifying the association name specified in steps 22 and 23.

For this example, enter this command.

```
rtrv-assoc:aname=assoc2
```

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc2
  LOC      1205          IPLNK PORT  A          LINK  A
  ADAPTER  M2PA          VER          M2PA RFC
  LHOST    IPNODE2-1205
  ALHOST    ---
  RHOST     gw200.nc-tekelec.com
  LPORT     2048          RPORT      3000
  ISTRMS    2            OSTRMS     2          BUFSIZE  500
  RMODE     LIN          RMIN        120        RMAX      800
  RTIMES    10           CWMIN       3000       M2PATSET  1
  OPEN      YES          ALW         YES        RTXTHR   10000
```

```
IP Appl Sock table is (8 of 4000) 1% full
Assoc Buffer Space Used (1300 KB of 1600 KB) on LOC = 1205
```

21. Activate the signaling link assigned to the association using the **act-slk** command.

For example, enter this command.

```
act-slk:loc=1205:link=a
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

22. Verify the status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1203:link=a

This is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1205,A   e5e6a     -----  IS-NR      Avail     ----
Command Completed.
```


23. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.


These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-15. Changing an M2PA Association















Note: If the *m2patset* parameter will not be specified with the *chg-assoc* command, and the *adapter* parameter value is being changed to *m2pa*, the M2PA timer set 1 will be assigned to the association.

Caution: Changing an M2PA timer set may affect the performance of any associations using the timer set being changed.



Notes:

1. If any optional parameters are not specified with the *chg-assoc* command, those values are not changed.
2. The B Ethernet interface can be used with single-slot EDCMs or E5-ENET cards.
3. The EAGLE 5 ISS can contain a maximum of 4000 connections (associations plus sockets).
4. IPLIMx cards can have only one connection for each signaling link assigned to the card. If the card is a single-slot EDCM, the card may contain a maximum of eight connections. If the card is an E5-ENET card, the card may contain a maximum of 16 connections.
5. The value of the *lhost* and *rhost* parameters is a text string of up to 60 characters, with the first character being a letter. The command input is limited to 150 characters, including the hostnames.
6. The *adapter* parameter value for the association must be *m2pa* and the *ipliml2=m2pa* parameter must be assigned to the signaling link on the *iplim* or *iplimi* card.
7. Specifying the *lhost* parameter only creates a uni-homed endpoint. The network portion of the endpoint's IP address must be the same as the network portion of the IP address assigned to either the A or B network interface of the IP card.
8. Specifying the *lhost* and *alhost* parameters creates a multi-homed endpoint. The network portion of the IP address associated with the *lhost* parameter must be the same as the network portion of the IP address assigned to one of the network interfaces (A or B) of the IP card, and the network portion of the IP address associated with the *alhost* parameter must be the same as the network portion of the IP address assigned to the other network interface on the IP card.
9. The *alhost=none* parameter removes the alternate local host from the specified association, which also removes the multi-homed endpoint capability.
10. If the value of the *open* parameter is *yes*, only the value of the *alw* parameter can be changed. To change the values of other parameters, the value of the *open* parameter must be *no*.
11. The value of the *rmin* parameter must be less than or equal to the *rmax* parameter value.
12. The *m2patset* parameter can be specified only with the *adapter=m2pa* parameter, or if the current *adapter* parameter value for the association is *m2pa*.
13. If the *mp2atset* parameter is not specified with the *chg-assoc* command, and the *adapter* parameter value is being changed to *m2pa*, the *m2patset* parameter value defaults to M2PA timer set 1 (*m2patset=1*).
14. The *port* parameter can be used in place of the *link* parameter to specify the signaling link assigned to the association.
15. The *ver* parameter can be specified only if after the *chg-assoc* command is performed, the *adapter* parameter value is *m2pa*.
16. The M2PA version of the association determines the version of the M2PA timer set that is assigned to the association. For example, if M2PA timer set 3 is assigned to the M2PA association, and the association is an RFC M2PA association, the RFC version of M2PA timer set 3 is used with the association. If M2PA timer set 7 is assigned to the M2PA association, and the association is a Draft 6 M2PA association, the Draft 6 version of M2PA timer set 7 is used with the association.
17. If the *ver* parameter is not specified with the *chg-assoc* command, and the association's *adapter* parameter value is not changing, then the M2PA version of the association is not changed.
18. If the *adapter* parameter value of the association is changed to *m2pa* in this procedure and the *ver* parameter is not specified, the version of the association will be RFC. To make this association a M2PA Draft 6 association, the *ver=d6* parameter must be specified for this association.
19. The new buffer size for this association cannot exceed the available buffer size for the card. If you wish to increase the buffer size for this association to a value that is greater than available buffer size for the card, the buffer size of the other associations assigned to the card must be decreased.
20. If the *open* parameter value is being changed to *yes*, the association must contain values for the *lhost*, *lport*, *rhost*, and *rport* parameters. The *lhost* parameter value must have a signaling link assigned to it.

Configuring SCTP Retransmission Control for an M2PA Association

This procedure is used to gather the information required to configure the retransmission parameters for M2PA associations. If any assistance is needed to configure the retransmission parameters for associations, contact the Customer Care Center. Refer to [Customer Care Center](#) for the contact information.

The retransmission parameters are configured using the **rmode**, **rmin**, **rmax**, **rtimes**, and **cwmin** parameters of the **chg-assoc** command.

:rmode – The retransmission mode used when packet loss is detected. The values are **rfc** or **lin**.

- **rfc** – Standard RFC 2960 algorithm in the retransmission delay doubles after each retransmission. The RFC 2960 standard for congestion control is also used.
- **lin** – Tekelec's linear retransmission mode where each retransmission timeout value is the same as the initial transmission timeout and only the slow start algorithm is used for congestion control.

:rmin – The minimum value of the calculated retransmission timeout in milliseconds.

:rmax – The maximum value of the calculated retransmission timeout in milliseconds.

NOTE: The **rmin** and **rmax** parameter values form a range of retransmission values. The value of the **rmin** parameter must be less than or equal to the **rmax** parameter value.

:rtimes – The number of times a data retransmission occurs before closing the association.

:cwmin – The minimum size in bytes of the association's congestion window and the initial size in bytes of the congestion window.

For associations assigned to the **ss7ipgw** or **ipgwi** applications, the value of the **cwmin** parameter must be less than or equal to 16384.

The [Changing an M2PA Association](#) procedure is used to change the values of these parameters. In addition to using the [Changing an M2PA Association](#) procedure, these pass commands are also used in this procedure.

- **ping** – tests for the presence of hosts on the network.
- **assocrtt** – displays the SCTP round trip times for a specified association. Minimum, maximum, and average times are kept for each open association. The Retransmission Mode (RFC or LIN) and the configured Minimum and Maximum Retransmission Timeout limits are also displayed.
- **sctp** – provides a summary list of all SCTP instances.
- **sctp -a <association name>** – displays the measurements and information for a specific association.

For more information on the **pass** commands, see the *Commands Manual*.

The **chg-assoc** command contains other optional parameters that can be used to configure an association. These parameters are not shown here because they are not necessary for configuring the SCTP retransmission parameters. These parameters are explained in more detail in the [Changing an M2PA Association](#) procedure, or in the **chg-assoc** command description in the *Commands Manual*.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

ANAME	CARD		IPLNK		LPORT	RPORT	OPEN	ALW
	LOC	PORT	LINK	ADAPTER				
swbel32	1201	A	A	M3UA	1030	2345	YES	YES
a2	1305	A	A	SUA	1030	2345	YES	YES
a3	1307	A	A	SUA	1030	2346	YES	YES
assoc1	1201	A	A	M3UA	2000	1030	YES	YES

2. Display the IP address assigned to the IPLINK assigned to the association being changed in this procedure by entering the **rtrv-ip-lnk** command with the card location and IPLINK port shown in step 1.

For this example, enter this command.

```
rtrv-ip-lnk:loc=1201:port=a
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.30      255.255.255.0    ----   ---    DIX      YES   NO
```

3. Display the local host assigned to the IP address displayed in step 2 using the **rtrv-ip-host** command with the IP address shown in step 2.

For this example, enter this command.

```
rtrv-ip-host:ipaddr=192.1.1.30
```

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

LOCAL	IPADDR	LOCAL	HOST
192.1.1.30		GW100.	NC. TEKELEC. COM

```
IP Host table is (11 of 512) 2% full
```

4. Enter the **ping** pass command specifying the card location of the local host, shown in step 3, and the name of the remote host assigned to the association being changed, shown in step 1.

This command is entered several times to obtain the average round trip time. For this example, enter this command.

pass:loc=1201:cmd="ping gw100.nc.tekelec.com"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING command in progress

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING GW100. NC. TEKELEC. COM (192.1.1.30): 56 data bytes
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=0. time=5. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=1. time=9. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=2. time=14. ms
----tekral PING Statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 5/9/14

PING command complete
```

5. Go to the [Changing an M2PA Association](#) procedure and change the retransmission parameters of the association based on the results of pinging the remote host.

NOTE: If the SCTP retransmission parameters are not to be changed, do not perform steps 5 through 9. This procedure is finished.

6. Enter the **assocrtt** pass command to display the round trip time data collected after an association is established when an SCTP INIT message is sent and an acknowledgement is received.

The **assocrtt** command is entered with the card location from step 4 (the card location assigned to the association being changed), and the name of the association being changed. This association must contain the local host name used in step 2. For this example, enter this command.

pass:loc=1201:cmd="assocrtt assoc1"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ASSOCRTT: Association round-trip time report (in milliseconds)

Retransmission Configuration
Retransmission Mode           : LIN
Minimum RT0: 120
Maximum RT0: 800

Traffic Round-Trip Times

Minimum round-trip time       : 5
Maximum round-trip time       : 120
Weighted Average round-trip time : 10
Last recorded round-trip time  : 10

Measured Congested Traffic Round-Trip Times

Minimum round-trip time       : 0
Maximum round-trip time       : 0
Weighted Average round-trip time : 0
Last recorded round-trip time  : 0
;
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ASSOCRTT command complete
```

7. Enter the **sctp -a <association name>** pass command to determine if retransmissions have occurred.

The association name is the association name specified in step 6. Specify the card location used in step 6. For this example, enter this command.

pass:loc=1201:cmd="sctp -a assoc1"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

Aname          Local          Local Remote          Remote
               IP Address    Port  Address         Port
Assoc1         192.168.110.12 2222  192.168.112.4   5555
               192.168.112.12

Configuration                      State
Retransmission Mode = LIN          State = OPEN
Min. Retransmission Timeout = 10   ULP association id = 18
Max. Retransmission Timeout = 800  Number of nets = 2
Max. Number of Retries = 10        Inbound Streams = 1
Min. Congestion Window = 3000      Outbound Streams = 2
Inbound Streams = 2
Outbound Streams = 2

Nets Data

IP Address    192.168.112.4   State  Reachable
Port          7777            Primary YES
MTU           1500            cwnd  16384
sssthresh     16384          RTO   120

IP Address    192.168.113.5   State  Reachable
Port          7777            Primary NO
MTU           1500            cwnd  16384
sssthresh     16384          RTO   120

Last Net Sent To = 192.168.112.4
Last Net Rcvd From = 192.168.112.4
Over All Error Count = 0
Peers Rwnd = 13880
My Rwnd = 16384
Max Window = 16384
Initial Seq Number = 24130
Next Sending Seq Number = 124686
Last Acked Seq Number = 124669
Maximum Outbound Char Count = 16384
Current Outbound Char Count = 2112
Number Unsent Char Count = 0
Outbound Data Chunk Count = 16
Number Unsent = 0
Number To Retransmit = 0

ip datagrams rcvd = 155402
ip datagrams with data chunks rcvd = 120844
data chunks rcvd = 367908
data chunks read = 367900
dup tsns rcvd = 8
sacks rcvd = 38734
gap ack blocks rcvd = 3
heartbeat requests rcvd = 135
heartbeat acks rcvd = 52
heartbeat requests sent = 52
ip datagrams sent = 129254
ip datagrams with data chunks sent = 73084
data chunks sent = 396330
```


```
retransmit data chunks sent = 135
      sacks sent = 64872
      send failed = 0
      retransmit timer count = 0
consecutive retransmit timeouts = 0
RTT between RMIN and RMAX inclusive = 6
      RTT greater than RMAX = 0
      fast retransmit count = 135
      recv timer count = 0
      heartbeat timer count = 244
      none left tosend = 0
      none left rwnd gate = 5
      none left cwnd gate = 8
```


SCTP command complete

8. Perform the [Changing an M2PA Association](#) procedure and change the retransmission parameters of the association based on the results of the outputs of steps 6 and 7.

NOTE: The Weighted Average round-trip time shown in the `assocrtt` pass command output in step 6, and the data retransmission counts shown in the `sctp -a` pass command output in step 7 are used as a guide to determine the appropriate values for the `rmode`, `rmin`, `rmax`, and `rtimes` parameters. If the retransmission parameters do not have to be adjusted, do not perform this step. This procedure is finished.

Flowchart 5-16. Configuring an M2PA Association for SCTP Retransmission Control





Changing an M2PA Timer Set

This procedure is used to change the values of the M2PA timers in an M2PA timer set using the **chg-m2pa-tset** command. The M2PA timers are used to control the behavior of the signaling link assigned to an M2PA association (an association containing the M2PA adapter layer - **adapter=m2pa**) during signaling link alignment and proving, and during times of transmit congestion.

The EAGLE 5 ISS contains 20 M2PA timer sets. One of these timer sets is assigned to an M2PA association using the **m2patset** parameter of either the **ent-assoc** or **chg-assoc** command. If the **m2patset** parameter is not specified with the **ent-assoc** command, or with the **chg-assoc** command if the adapter layer for that association is being changed to M2PA, timer set 1 is automatically assigned to the association.



CAUTION: Changing an M2PA timer set may affect the performance of any associations using the timer set being changed.

The **chg-m2pa-tset** command uses these parameters.

:tset – The M2PA timer set being changed, 1 - 20.

:srctset – The timer values in an existing M2PA timer set can be copied to another M2PA timer set, specified by the **tset** parameter. The **srctset** parameter specifies the timer set that is to be copied. If the **srctset** parameter is specified, no other timer values can be specified. The **srctset** parameter value cannot be the timer set specified by the **tset** parameter.

:ver – The M2PA version, either Draft 6 (**ver=d6**) or RFC (**ver=rfc**).

NOTE: The definitions of timers T1 and T3 for the Draft 6 version are different from the RFC version. The T2 timer applies only to the RFC version. The definitions of timers T4N, T4E, T5, T6, T7, T16, T17 and T18 for are the same for the Draft 6 version and the RFC version.

The timer parameter descriptions and values are shown in [Table 5-6](#) .

Table 5-6. M2PA Timers

Timer	Draft 6 Timer Name	RFC Timer Name	Definition	Value (in milliseconds)	DRAFT 6 System Default Value (in milliseconds)	RFC System Default Value (in milliseconds)
: t1	N/A	Ready Timer	The amount of time after proving the M2PA adapter layer waits to receive a Link Status Ready message from the peer.	1000 - 350000	N/A	300000
: t1	Alignment Timer	N/A	The amount of time the M2PA adapter layer waits to receive a Link Status Alignment message from the peer.	1000 - 350000	10000	N/A
: t2 *	N/A	Not Aligned Timer	The the amount of time the M2PA adapter layer waits to receive a Link Status Alignment/Link Status Proving message after sending a Link Status Alignment message. Timer T2 is not used in M2PA Draft 6 timer sets.	5000 - 150000	N/A	20000
: t3	N/A	Alignment Timer	The amount of time the M2PA layer waits to receive a Link Status Alignment message from the peer.	1000 - 60000	N/A	2000
	Ready Timer	N/A	The amount of time after proving the M2PA adapter layer waits to receive a Link Status Ready message from the peer.	1000 - 60000	10000	N/A
: t4n	Proving Timer (Normal)		The amount of time the M2PA adapter layer generates Link Status Proving messages during normal proving.	1000 - 70000	10000	30000
: t4e	Proving Timer (Emergency)		The amount of time the M2PA adapter layer generates Link Status Proving messages during emergency proving.	400 - 5000	500	500
: t5	Busy Rate Timer		The amount of time between sending Link Status Busy messages while the link is in-service.	80 - 10000	1000	100
: t6	Remote Congestion Timer		The amount of time that a congested link will remain in service.	1000 - 6000	3000	3000

Timer	Draft 6 Timer Name	RFC Timer Name	Definition	Value (in milliseconds)	DRAFT 6 System Default Value (in milliseconds)	RFC System Default Value (in milliseconds)
:t7	Excess Delay in Acknowledgement Timer		The maximum amount of time that may pass between when a user data message is transmitted and an acknowledgement for that message is received from the peer. If this timer expires, the link is taken out of service.	200 - 2000	1200	1200
:t16	Proving Rate Timer		The amount of time between sending Link Status Proving messages while the T4N or T4E timer is running.	100 - 500000 **	200000 **	200000 **
:t17	Ready Rate Timer		The amount of time between sending Link Status Ready messages while the T3 timer is running.	100 - 500	250	250
:t18	Processor Outage Rate Timer		The amount of time between sending Link Status Processor Outage messages while the link is in-service.	100 - 10000	1000	1000
* The T2 Timer can be specified only for the M2PA RFC version. ** The value of the T16 Timer is in microseconds.						

The value of any timer parameter not specified with the **chg-m2pa-tset** command is not changed.

Procedure

1. Display the M2PA timer sets in the database by entering the **rtrv-m2pa-tset** command with the version of the M2PA timer sets you wish to change with the **ver** parameter.

To display the M2PA Draft 6 timer values, enter this command.

rtrv-m2pa-tset:ver=d6

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	-----	5000	20000	500	5000	3000	1000	200000	250	1000
2	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
3	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
4	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
5	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
6	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
7	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
8	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
9	27500	-----	3850	4859	450	5700	3750	1150	250	375	8750
10	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
11	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
12	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
13	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
14	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
15	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
16	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
17	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
18	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000

```

19 10000 ----- 10000 10000 500 1000 3000 1200 200000 250 1000
20 10000 ----- 10000 10000 500 1000 3000 1200 200000 250 1000

```

To display the M2PA RFC timer values, enter this command.

rtrv-m2pa-tset:ver=rfc

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	20000	5000	20000	500	5000	3000	1000	200000	250	1000
1	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
2	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
3	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
4	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
5	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
6	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
7	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
8	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
9	27500	10000	3850	4859	450	5700	3750	1150	250	375	8750
10	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
11	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
12	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
13	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
14	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
15	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
16	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
17	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
18	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
19	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
20	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000

If the **ver** parameter is not specified when entering the **rtrv-m2pa-tset** command, both the Draft 6 and RFC values are displayed. This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	-----	5000	20000	500	5000	3000	1000	200000	250	1000
2	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
3	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
4	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
5	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
6	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
7	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
8	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
9	27500	-----	3850	4859	450	5700	3750	1150	250	375	8750
10	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
11	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
12	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
13	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
14	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
15	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
16	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
17	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
18	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
19	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000
20	10000	-----	10000	10000	500	1000	3000	1200	200000	250	1000

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	6000	20000	5000	20000	500	5000	3000	1000	200000	250	1000
2	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
3	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
4	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000

5	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
6	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
7	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
8	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
9	27500	10000	3850	4859	450	5700	3750	1150	250	375	8750
10	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
11	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
12	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
13	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
14	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
15	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
16	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
17	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
18	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
19	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000
20	300000	20000	2000	30000	500	100	3000	1200	200000	250	1000

2. Change the desired timer set with the **chg-m2pa-tset** command. To change a specific timer set, enter the **chg-m2pa-tset** command with the **tset** and **ver** parameters and the timer parameters you wish to change. For this example, to change the values of the RFC version of timer set 1, enter this command..

chg-m2pa-

tset:tset=1:t1=27500:t2=10000:t3=3850:t4e=450 :t4n=45000:t5=5700:t6=3750:t7=1150:t16=250000:t17=375:t18=8750 :ver=rfc

To change the values of the Draft 6 version of timer set 1, enter this command.

chg-m2pa-

tset:tset=1:t1=27500:t3=3850:t4e=450:t4n=45000 :t5=5700:t6=3750:t7=1150 :t16=250000:t17=375:t18=8750:ver=d6

NOTE: The values for the M2PA timers are shown in [Table 5-6](#) .

To copy an M2PA timer set to another timer set, enter the **chg-m2pa-tset** command with the **tset**, **ver**, and **srctset** parameters. For this example, to copy the RFC version of timer set 9 to timer set 1, enter this command.

chg-m2pa-tset:tset=1:srctset=9:ver=rfc

To copy the Draft 6 version of timer set 9 to timer set 1, enter this command.

chg-m2pa-tset:tset=1:srctset=9:ver=d6

NOTE: The **ver** parameter is optional and does not have to be specified to change the M2PA RFC timer values. The default value for the **ver** parameter is **rfc**. If you wish to change the M2PA Draft 6 timer values, the **ver=d6** parameter must be specified with the **chg-m2pa-tset** command.

When the **chg-m2pa-tset** command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-M2PA-TSET: MASP A - COMPLTD
```

3. Verify the changes by entering the **rtrv-m2pa-tset** command specifying the timer set and version parameter values specified in step 2. For this example, enter one of these commands.

rtrv-m2pa-tset:tset=1:ver=rfc

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	27500	10000	3850	45000	450	5700	3750	1150	250000	375	8750

rtrv-m2pa-tset:tset=1:ver=d6

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
1	27500	-----	3850	45000	450	5700	3750	1150	250000	375	8750

rtrv-m2pa-tset:tset=9:ver=rfc

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA RFC Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
9	27500	10000	3850	45000	450	5700	3750	1150	250000	375	8750

rtrv-m2pa-tset:tset=9:ver=d6

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

M2PA Draft 6 Timers (in msec, T16 in microsec)

TSET	T1	T2	T3	T4N	T4E	T5	T6	T7	T16	T17	T18
9	27500	-----	3850	45000	450	5700	3750	1150	250000	375	8750


4. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Flowchart 5-17. Changing an M2PA Timer Set

**Notes:**

1. Either the timer parameters or the *srctset* parameter must be specified with the *chg-m2pa-tset* command. Both the timer parameters and the *srctset* parameter cannot be specified with the *chg-m2pa-tset* command.
2. If the *ver* parameter is not specified with the *chg-m2pa-tset* command, the RFC values will be changed. To change the Draft 6 values, the *ver=d6* parameter must be specified with the *chg-m2pa-tset* command.

Caution: Changing an M2PA timer set may affect the performance of any associations using the timer set being changed.

Changing the SCTP Checksum Algorithm Option for M2PA Associations

Use this procedure to change the SCTP checksum algorithm, either Adler-32 or CRC-32c, applied to traffic on SCTP associations. The **sctpchecksum** parameter of the **chg-sg-opts** command is used to change this option. This option is a system-wide option that applies to associations assigned to IP cards running the IPLIM or IPLIMI applications.

Once the SCTP checksum option has been changed, the associations on each IP card need to be reset by changing the **open** parameter value for each association to **no**, then back to **yes**. This ensures that the associations on the IP card are using the new SCTP checksum algorithm.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current IP options in the database by entering the **rtrv-sg-opts** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SCTPCSUM:      adler32
```

NOTE: The **rtrv-sg-opts command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.**

2. Display the cards in the EAGLE 5 ISS by entering the **rtrv-card** command. This is an example of the possible output.

```
rlghncxa03w 06-10-15 16:34:56 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC  LSET NAME      LINK SLC
1101   TSM        SCCP
1102   TSM        GLS
1104   ACMENET    STPLAN
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI  lsn1           A      0      lsn2           B      1
```

1202	DCM	IPLIM	ipnode2	A	1			
1203	LIMV35	SS7ANSI	lsn2	A	0	lsn1	B	1
1204	LIMATM	ATMANSI	atmgwy	A	0			
1205	DCM	IPLIM	ipnode1	A	0	ipnode3	B	1
1207	DCM	IPLIM	ipnode2	A	0			
1303	DCM	IPLIM	ipnode3	A	0	ipnode1	B	1
1305	DCM	IPLIM	ipnode4	A	0			
1308	DCM	IPLIM	ipnode3	B	2			
			ipnode1	A1	2	ipnode4	B2	1
1315	DCM	SS7IPGW	ipgtwy1	A				
1317	DCM	IPGWI	ipgtwy2	A				

Record the card location, shown in the **LOC** column, and signaling link, shown in the **LINK** column, information for all cards running the IPLIM or IPLIMI applications.

3. Change the SCTP checksum option in the database using the **chg-sg-opts** command. For this example, enter this command.

chg-sg-opts:sctpcsum=crc32c

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
CHG-SG-OPTS: MASP A - COMPLTD
```

4. Verify that the SCTP checksum algorithm was changed using the **rtrv-sg-opts** command. The SCTP checksum algorithm option value is shown in the **SCTPCSUM** parameter. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SCTPCSUM:      crc32c
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

5. Select one of the IP cards shown in the **rtrv-card** output in step 2 running the IPLIM or IPLIMI applications. Place the signaling links on this card out of service using the **dact-slk** command. For this example, enter these commands.

dact-slk:loc=1308:link=a1

dact-slk:loc=1308:link=b

dact-slk:loc=1308:link=b2

When these commands have successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

6. Display the IP addresses of the IP links in the database by entering the **rtrv-ip-lnk** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1202  A      192.1.1.10   255.255.255.0 HALF    10     DIX      NO    NO
1202  B      -----    -----    HALF    10     DIX      NO    NO
1205  A      192.1.1.12   255.255.255.0 HALF    10     DIX      NO    NO
1205  B      -----    -----    HALF    10     DIX      NO    NO
1207  A      192.1.1.14   255.255.255.0 HALF    10     DIX      NO    NO
1207  B      -----    -----    HALF    10     DIX      NO    NO
1303  A      192.1.1.20   255.255.255.0 HALF    10     DIX      NO    NO
1303  B      -----    -----    HALF    10     DIX      NO    NO
1305  A      192.1.1.22   255.255.255.0 HALF    10     DIX      NO    NO
1305  B      -----    -----    HALF    10     DIX      NO    NO
1308  A      192.1.1.24   255.255.255.0 HALF    10     DIX      NO    NO
```

```

1308 B ----- HALF 10 DIX NO NO
1315 A 192.1.1.50 255.255.255.0 HALF 10 DIX NO NO
1315 B ----- HALF 10 DIX NO NO
1317 A 192.1.1.52 255.255.255.0 HALF 10 DIX NO NO
1317 B ----- HALF 10 DIX NO NO

```

IP-LNK table is (16 of 512) 3% full.

7. Display the current IP host information in the database by entering the **rtrv-ip-host** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1-1201
192.1.1.12    IPNODE1-1203
192.1.1.14    IPNODE1-1205
192.1.1.20    IPNODE2-1201
192.1.1.22    IPNODE2-1203
192.1.1.24    IPNODE2-1205
192.1.1.32    KC-HLR2
192.1.1.50    DN-MS1
192.1.1.52    DN-MS2

```

```

REMOTE IPADDR  REMOTE HOST
150.1.1.5      NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

```

IP Host table is (10 of 512) 2% full

8. Display the associations assigned to the IP card specified in step 5, using the **rtrv-assoc** command with the local host name of the associations assigned to the IP card. To find the local host name of the association, the card location of the IP card is assigned to an IP address in the IP link table (**rtrv-ip-lnk** output). The IP address is assigned to a hostname in the IP host table (**rtrv-ip-host** output).

For this example, the local host name of associations assigned to the IP card 1308 (the card specified in step 5) is IPNODE2-1205. Enter this command.

rtrv-assoc: lhost=ipnode2-1205

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```

CARD IPLNK
ANAME  LOC  PORT  LINK  ADAPTER  LPORT  RPORT  OPEN  ALW
assoc2 1308 A    A1   M2PA   2187   1025   YES   YES
assoc4 1308 A    B    M2PA   3290   1025   YES   YES
assoc5 1308 A    B2   M2PA   1057   1025   YES   YES

```

IP Appl Sock/Assoc table is (9 of 4000) 1% full
Assoc Buffer Space Used (600 KB of 3200 KB) on LOC = 1308

9. Change the value of the **open** parameter of the associations shown in step 8 to **no** by specifying the **chg-assoc** command with the **open=no** parameter. For this example, enter this command.

chg-assoc: aname=assoc2: open=no

chg-assoc: aname=assoc4: open=no

chg-assoc: aname=assoc5: open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

10. Change the value of the **open** parameter of the associations changed in step 9 to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter. For this example, enter this command.

chg-assoc:aname=assoc2:open=yes

chg-assoc:aname=assoc4:open=yes

chg-assoc:aname=assoc5:open=yes

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

11. Put the signaling links that were placed out of service in step 5 back into service using the **act-slk** command. For example, enter this command.

act-slk:loc=1308:link=a1

act-slk:loc=1308:link=b

act-slk:loc=1308:link=b2

When these commands have successfully completed, this message appears.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

12. Verify the in-service normal (IS-NR) status of the signaling link by using the **rept-stat-slk** command and specifying the card location and link values specified in step 11.

For example, enter these commands.

rept-stat-slk:loc=1308:link=a1

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1308,A1  ipnode1  -----  IS-NR      Avail    ----
Command Completed.
```

rept-stat-slk:loc=1308:link=b

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1308,B   ipnode3  -----  IS-NR      Avail    ----
Command Completed.
```

rept-stat-slk:loc=1308:link=b2

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1308,B2  ipnode4  -----  IS-NR      Avail    ----
Command Completed.
```

13. Enter the **netstat -p sctp** pass command with the card location of the IP card to determine if any errors have occurred. For this example, enter this command.

pass:loc=1308:cmd="netstat -p sctp"

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

SCTP:

```
0 ip packets sent
  0 ip packets sent with data chunk
  0 control chunks (excludes retransmissions)
  0 ordered data chunks (excludes retransmissions)
  0 unordered data chunks (excludes retransmissions)
  0 user messages fragmented due to MTU
  0 retransmit data chunks sent
  0 sacks sent
  0 send failed
0 ip packets received
  0 ip packets received with data chunk
  0 control chunks (excludes duplicates)
  0 ordered data chunks (excludes duplicates)
  0 unordered data chunks (excludes duplicates)
  0 user messages reassembled
  0 data chunks read
  0 duplicate tsns received
  0 sacks received
  0 gap ack blocks received
  0 out of the blue
  0 with invalid checksum
0 connections established
  0 by upper layer
  0 by remote endpoint
0 connections terminated
  0 ungracefully
  0 gracefully
0 associations supported
0 associations dropped due to retransmits
0 consecutive retransmit timeouts
0 retransmit timer count
0 fast retransmit count
0 heartbeat requests received
0 heartbeat acks received
0 heartbeat requests sent
0 milliseconds cookie life at 4-way start-up handshake
0 retransmission attempts are allowed at start-up phase
```

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

NETSTAT command complete

If errors are shown in the pass command output, contact the Customer Care Center. Refer to [Customer Care Center](#) for the contact information.

14. Repeat steps 5 through 13 to update the other IP cards in the EAGLE 5 ISS running the IPLIM and IPLIMI applications with the new SCTP checksum algorithm.

If the **rtrv-card** output in step 2 shows cards running the SS7IPGW or IPGWI applications, skip step 15 and go to step 16.


15. Back up the database by entering the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

16. If the **rtrv-card** output in step 2 shows cards running the SS7IPGW or IPGWI applications, perform the [Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations](#) procedure.

If the **rtrv-card** output in step 2 shows that there are no cards running the **SS7IPGW** or **IPGWI** applications, this procedure is finished.

Flowchart 5-18. Changing the SCTP Checksum Algorithm Option for M2PA Associations





Turning the Large BICC MSU Support for IP Signaling Feature Off

This procedure is used to turn off the Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature, using the **chg-ctrl-feat** command.

The **chg-ctrl-feat** command uses these parameters:

:partnum – The part number of the Large BICC MSU Support for IP Signaling feature, 893018401.

:status=off – used to turn off the Large BICC MSU Support for IP Signaling feature.

The status of the Large BICC MSU Support for IP Signaling controlled feature must be on and is shown with the **rtrv-ctrl-feat** command.



CAUTION: If the Large BICC MSU Support for IP Signaling feature is turned off, the EAGLE 5 ISS will not process BICC messages with a signaling information field (SIF) that is larger than 272 bytes.

Procedure

1. Display the status of the Large BICC MSU Support for IP Signaling feature by entering the **rtrv-ctrl-feat:partnum=893018401** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large BICC MSU for IP Sig	893018401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the status of the Large BICC MSU Support for IP Signaling feature is off, or if the Large BICC MSU Support for IP Signaling feature is not enabled, this procedure cannot be performed.

2. Turn off the Large BICC MSU Support for IP Signaling feature by entering the **chg-ctrl-feat** command with the **status=off** parameter. For example, enter this command.

chg-ctrl-feat:partnum=893018401:status=off

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

3. Verify that the Large BICC MSU Support for IP Signaling feature has been turned off by using the **rtrv-ctrl-feat:partnum=893018401** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large BICC MSU for IP Sig	893018401	off	----

Turning the Large BICC MSU Support for IP Signaling Database Administration Manual - IP7 Secure Gateway Feature Off

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				


The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 5-19. Turning the Large BICC MSU Support for IP Signaling Feature Off



IETF M3UA and SUA Configuration Procedures

Adding IETF M3UA and SUA Components	6-2
Adding an IPGWx Card	6-4
Configuring an IPGWx Linkset	6-12
Configuring a Mate IPGWx Linkset	6-36
Increasing the System-Wide IPGWx Signaling TPS	6-54
Configuring the IP TPS Alarm Threshold	6-61
Adding an IPGWx Signaling Link	6-63
Enabling the Large System # Links Controlled Feature	6-76
Configuring an IP Link	6-85
Adding an IP Host	6-101
Configuring an IP Card	6-105
Adding an IP Route	6-113
Adding an M3UA or SUA Association	6-119
Adding a New Association to a New Application Server	6-128
Adding an Existing Association to a New Application Server	6-134
Adding a New Association to an Existing Application Server	6-144
Adding an Existing Association to an Existing Application Server	6-154
Adding a Routing Key Containing an Application Server	6-166
Adding a Network Appearance	6-185
Activating the Large BICC MSU Support for IP Signaling Feature	6-191
Removing IETF M3UA and SUA Components	6-198
Removing an IPGWx Card	6-199
Removing an IPGWx Signaling Link	6-200
Removing an IP Host Assigned to an IPGWx Card	6-207
Removing an IP Route	6-212
Removing an M3UA or SUA Association	6-216
Removing an Association from an Application Server	6-218
Removing a Routing Key Containing an Application Server	6-223
Removing a Network Appearance	6-231
Changing IETF M3UA and SUA Components	6-233
Changing the IP Protocol Option	6-234
Changing IP Options other than SYNC and SCTPCSUM	6-239

Changing an M3UA or SUA Association	6-244
Configuring SCTP Retransmission Control for an M3UA or SUA Association	6-263
Changing an Application Server	6-269
Changing the CIC Values in an Existing Routing Key Containing an Application Server	6-273
Changing the Routing Context Value in an Existing Routing Key	6-282
Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations	6-289
Changing a UA Parameter Set	6-303
Turning the Large BICC MSU Support for IP Signaling Feature Off	6-309

Adding IETF M3UA and SUA Components

This section describes how to configure the components necessary to establish IP connections using M3UA or SUA associations on IPGWx signaling links. IPGWx signaling links are signaling links assigned to cards running either the SS7IPGW or IPGWI applications. The SS7IPGW application supports point-to-multipoint connectivity for ANSI networks. The IPGWI application supports point-to-multipoint connectivity for ITU networks.

The configuration of these IP connections consists of these items.

1. Configure the IPGWx card with the [Adding an IPGWx Card](#) procedure. Turn the ISUP-over-IP (**ipisup**) feature or the Dynamic Routing Key (**dynrtk**) feature with the **chg-feat** command.
NOTE: Before turning on the ISUP-over-IP feature (ipisup) or the Dynamic Routing Key feature, make sure you have purchased these features. If you are not sure whether you have purchased the ISUP-over-IP feature or the Dynamic Routing Key feature, contact your Tekelec Sales Representative or Account Representative. Once a feature has been turned on with the chg-feat command, the feature cannot be turned off.
2. Configure the required destination point codes - see Chapter 2, "Configuring Destination Tables," in the *Database Administration Manual - SS7*.
3. Configure the required IPGWx linksets with the [Configuring an IPGWx Linkset](#) procedure. A quantity of IP TPS (transactions per second) is assigned to each IPGWx linkset. The total amount of IP TPS for all IPGWx linksets cannot exceed the system-wide IP TPS value shown in the **rept-stat-iptps** output. Perform the [Increasing the System-Wide IPGWx Signaling TPS](#) procedure to change the total amount of IP TPS for all IPGWx linksets. If you wish to configure a mate IPGWx Linkset, perform the [Configuring a Mate IPGWx Linkset](#) procedure.
4. Configure the IPGWx signaling links with the [Adding an IPGWx Signaling Link](#) procedure. If the addition of these signaling links will exceed the current number of signaling links the EAGLE 5 ISS is allowed to have, the [Enabling the Large System # Links Controlled Feature](#) procedure will have to be performed to increase the quantity of signaling links.
5. Configure the required routes - see Chapter 3, "SS7 Configuration," in the *Database Administration Manual - SS7*.
6. IP addresses must be assigned to the IPGWx card configured in step 1 by performing the [Configuring an IP Link](#) procedure. There are other IP link parameters that are assigned to the IPGWx card when the IPGWx card is configured. Default values are assigned to these parameters when the IPGWx card is configured. These values can be displayed by the **rtrv-ip-lnk** command. These values can be changed by performing the [Configuring an IP Link](#) procedure.
7. Local IP hosts, assigned to the IP addresses assigned to step 6, must be configured in the database by performing the [Adding an IP Host](#) procedure. Verify the hosts with the **rtrv-ip-host** command. This establishes a relationship between the IP card related information and the socket related information.

8. When the IP cards are added to the database in step 1, there are IP parameters that control the IP stack that are assigned default values. These parameter values can be displayed by the **rtrv-ip-card** command. These values can be changed by performing the [Configuring an IP Card](#) procedure.
9. Static IP routes provide more flexibility in selecting the path to the remote destination and reduces the dependence on default routers. Static IP routes are provisioned by performing the [Adding an IP Route](#) procedure.
10. Associations specify a connection between a local host/TCP port and a remote host/TCP port. Three types of associations can be provisioned: M2PA, M3UA, and SUA. Associations that are assigned to IPGWx signaling links must be either M3UA or SUA associations. The M3UA and SUA associations are configured by performing the [Adding an M3UA or SUA Association](#) procedure. M2PA associations are provisioned with the [Adding an M2PA Association](#) procedure in Chapter 5. A number of fields in the association cannot be configured with the [Adding an M3UA or SUA Association](#) procedure and are set to default values. The values of these fields can be displayed using the **rtrv-assoc** command after the [Adding an M3UA or SUA Association](#) procedure is performed. These values can be changed by performing the [Changing an M3UA or SUA Association](#) procedure. Only one signaling link can be assigned to an IPGWx card. A maximum of 50 IP connections can be assigned to an IPGWx card.
11. When an M3UA or SUA association is added to the database, UA parameter set 10 is assigned to the association. There are 10 UA parameter sets that can be assigned to an association, but the UA parameter set assignment can be changed, using the [Changing an M3UA or SUA Association](#) procedure. The values assigned to each UA parameter set can be changed, except for UA parameter set 10, using the [Changing a UA Parameter Set](#) procedure.
12. The application server contains a set of one to 16 associations, of which one or more is normally actively processing traffic. Application servers are configured by performing one of these procedures:
 - [Adding a New Association to a New Application Server](#)
 - [Adding an Existing Association to a New Application Server](#)
 - [Adding a New Association to an Existing Application Server](#)
 - [Adding an Existing Association to an Existing Application Server](#)

If the associations assigned to application server are M3UA associations, and the **open** parameter value for these associations is **yes**, then the same UA parameter set must be assigned to all of the associations in the application server.
13. Routing keys specify MSU filters for the IP connection. Configure the routing keys with the [Adding a Routing Key Containing an Application Server](#) procedure.
14. An internal point code can be provisioned to provide routing to an IP end office node. Configure the internal point codes by performing the [Adding an End Node Internal Point Code](#) procedure.
15. The network appearance field identifies the SS7 network context for the message, for the purpose of logically separating the signaling traffic between the SGP (signaling gateway process) and the application server over a common SCTP (stream control transmission protocol) association. This field is contained in the DATA, DUNA, DAVA, DRST, DAUD, SCON, and DUPU messages. Network appearances are configured by performing the [Adding a Network Appearance](#) procedure.
16. The EAGLE 5 ISS processes messages with a service information field (SIF) that is 272 bytes or smaller. The Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature allows the EAGLE 5 ISS to process BICC messages with a SIF that is larger than 272 bytes. Perform the [Activating the Large BICC MSU Support for IP Signaling Feature](#) procedure to enable and turn on the Large BICC MSU Support for IP Signaling feature.

Adding an IPGWx Card

This procedure is used to add an IPGWx card to the database using the **ent-card** command. An IPGWx card is a card that is running either the SS7IPGW or IPGWI applications. [Table 6-1](#) shows the cards that can be provisioned in this procedure.

Table 6-1. IPGWx Card Types

Card Type	Part Number
Single-Slot EDCM	870-2372-01, 870-2372-08, 870-2372-13
E5-ENET	870-2212-xx

The EAGLE 5 ISS may contain a maximum of 64 cards running either the **ss7ipgw** or **ipgwi** application, or combinations of the **ss7ipgw** and **ipgwi** applications.

The **ent-card** command uses these parameters.

:loc – The location of the card being added to the database.

:type – The type of card being added to the database. For this procedure, the value of this parameter is **dcm**.

:appl – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is **ss7ipgw** for ANSI IP network connections or **ipgwi** for ITU IP network connections.

:force – If the global title translation feature is on, the **force=yes** parameter allows the LIM to be added to the database even if the current SCCP transactions-per-second threshold is unable to support the additional SCCP transaction-per-second capacity created by adding the IP card. This parameter is obsolete and is no longer used.

If you have purchased the ISUP-over-IP (**ipisup**) feature or the Dynamic Routing Key (**dynrtk**) feature, verify that the appropriate feature is turned on (**ipisup=on** or **dynrtk=on**) using the **rtrv-feat** command. If the appropriate feature is off, turn it on with the **chg-feat** command. For more information on these features, refer to section [Understanding Routing for SS7IPGW and IPGWI Applications](#).

NOTE: Before turning on the ISUP-over-IP feature (ipisup) or the Dynamic Routing Key feature, make sure you have purchased these features. If you are not sure whether you have purchased the ISUP-over-IP feature or the Dynamic Routing Key feature, contact your Tekelec Sales Representative or Account Representative. Once a feature has been turned on with the chg-feat command, the feature cannot be turned off.

Card Slot Selection

The single-slot EDCM and E5-ENET card can be inserted into any card slot, except for card slots that must remain empty to accommodate dual-slot cards, slots 09 and 10 in each shelf, and slots 1113 through 1118.

To provision a E5-ENET card, the shelf containing the E5-ENET card must have HIPR cards installed in slots 9 and 10 in that shelf. If HIPR cards are not installed in the shelf that the E5-ENET card will occupy, the E5-ENET card will be auto-inhibited when the E5-ENET card is inserted into the shelf. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the same shelf as the E5-ENET card being provisioned in this procedure.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output. Cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution.


```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM        SCCP
1102   TSM        GLS
1113   GSPM        EOAM
1114   TDM-A
1115   GSPM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI    sp2           A      0      sp1           B      0
1203   LIMDS0     SS7ANSI    sp3           A      0
1204   LIMDS0     SS7ANSI    sp3           A      1
1206   LIMDS0     SS7ANSI    nsp3          A      1      nsp4          B      1
1207   LIMV35     SS7GX25    nsp1          A      0
1208   LIMV35     SS7GX25    nsp1          A      1
1216   ACMENET     STPLAN
1301   LIMDS0     SS7ANSI    sp6           A      1      sp7           B      0
1302   LIMDS0     SS7ANSI    sp7           A      1      sp5           B      1
1303   DCM         IPLIM      ipnode1       A      0      ipnode3       B      1
1305   DCM         IPLIM      ipnode4       A      0
1307   ACMENET     STPLAN

```

If the required unprovisioned card slots (see the "Card Slot Selection" section) are shown in the **rtrv-card** output, skip steps 2 and 3, and go to step 4.

If the required unprovisioned card slots are not shown in the **rtrv-card** output, step 2 must be performed.

2. Display the shelves in the database by entering the **rtrv-shlf** command. This is an example of the possible output.

```

rlghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
SHELF DISPLAY
FRAME SHELF      TYPE
  1      1      CONTROL
  1      2      EXTENSION
  1      3      EXTENSION

```

If all the shelves are provisioned in the database, then this procedure cannot be performed. There are no available card slots for the new IPGWx card.

If all the shelves have not been provisioned in the database, go to step 3.

3. Add the required shelf using the **ent-shlf** command with the location of the shelf and the **type=ext** parameter. The shelf location values are 1200, 1300, 2100, 2200, 2300, 3100, 3200, 3300, 4100, 4200, 4300, 5100, 5200, 5300, and 6100. For this example, enter this command.

ent-shlf: loc=2100: type=ext

When this command has successfully completed, this message should appear.

```

rlghncxa03w 07-05-01 09:12:36 GMT EAGLE5 37.0.0
ENT-SHLF: MASP A - COMPLTD

```

4. Verify that the card to be entered has been physically installed into the proper location (see the "Card Slot Selection" section).



CAUTION: If the version of the BPDCM GPL on the IP card does not match the BPDCM GPL version in the database when the IP card is inserted into the card slot, UAM 0002 is generated indicating that these GPL versions do not match. If UAM 0002 has been generated, perform the alarm clearing procedure for UAM 0002 in the *Maintenance Manual* before proceeding with this procedure.

NOTE: If the card being added in this procedure is not an E5-ENET card, skip step 5 and go to step 6.

5. Verify that HIPR cards are installed in card locations 9 and 10 in the shelf containing the E5-ENET card being added in this procedure. Enter this command.

rept-stat-gpl:gpl=hipr

This is an example of the possible output.

```
rlghncxa03w 07-05-01 11:40:26 GMT EAGLE5 37.0.0
GPL          CARD      RUNNING      APPROVED      TRIAL
HIPR         1109      125-002-000    125-002-000    125-003-000
HIPR         1110      125-002-000    125-002-000    125-003-000
HIPR         1209      125-002-000    125-002-000    125-003-000
HIPR         1210      125-002-000    125-002-000    125-003-000
HIPR         1309      125-002-000    125-002-000    125-003-000
HIPR         1310      125-002-000    125-002-000    125-003-000
HIPR         2109      125-002-000    125-002-000    125-003-000
HIPR         2110      125-002-000    125-002-000    125-003-000
Command Completed
```

If HIPR cards are installed in the shelf containing the E5-ENET card, go to step 6.

If HIPR cards are not installed on the shelf containing the E5-ENET card, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 6.

6. If the ISUP-over-IP (**ipisup**) feature or the Dynamic Routing Key (**dynrtk**) feature are to be used, verify that these features are on by entering the **rtrv-feat** command.

If the ISUP-over-IP feature is on, the **ipisup** field is set to **on**. If the Dynamic Routing Key feature is on, the **dynrtk** field is set to **on**.

NOTE 1: The **rtrv-feat command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.**

NOTE: If the features you wish to use are already on, skip step 6 and go to step 7.

7. Turn the ISUP-over-IP or Dynamic Routing Key features by entering one of these commands, depending of which features are already on, and which ones you wish to turn on.

To enable the ISUP-over-IP feature, enter this command.

chg-feat:ipisup=on

To enable the Dynamic Routing Key feature, enter this command.

chg-feat:dynrtk=on

To enable both features, enter this command.

chg-feat:ipisup=on:dynrtk=on

NOTE 1: Once the ISUP-over-IP feature or Dynamic Routing Key features are turned on with the **chg-feat command, they cannot be turned off.**

NOTE: The ISUP-over-IP feature and Dynamic Routing Key features must be purchased before turning them on. If you are not sure whether you have purchased the ISUP-over-IP feature or Dynamic Routing Key features, contact your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

8. Add the card using the **ent-card** command.

For this example, enter these commands.

ent-card:loc=1315:type=dcn:appl=ss7ipgw

ent-card:loc=1317:type=dcm:appl=ipgwi

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD
```

9. Verify the changes using the **rtrv-card** command with the card location specified in step 8.

For this example, enter these commands.

rtrv-card:loc=1315

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1315   DCM        SS7IPGW
```

rtrv-card:loc=1317

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1317   DCM        IPGWI
```

10. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


11. If you wish to change the quantity of static and dynamic routing keys in the database, perform the [Changing IP Options other than SYNC and SCTPCSUM](#) procedure.


Otherwise, this procedure is finished.


Flowchart 6-1. Adding an IP Card


NOTE: Before executing this procedure, make sure you have purchased the ISUP-over-IP feature and Dynamic Routing Key features. If you are not sure whether you have purchased the ISUP-over-IP feature or Dynamic Routing Key features, contact your Tekelec Sales Representative or Account Representative.











Configuring an IPGWx Linkset

This procedure is used to configure IPGWx linksets in the EAGLE 5 ISS using the **ent - ls** or **chg - ls** commands with these parameters. An IPGWx linkset is a linkset that contains signaling links running either the SS7IPGW or IPGWI applications.

NOTE: This procedure is not used to configure a mate IPGWx linkset, with the **mate lsn** and **action** parameters. To configure a mate IPGWx linkset, perform the [Configuring a Mate IPGWx Linkset](#) procedure.

: lsn – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter. However, the SEAS interface supports only eight characters. If this linkset is displayed on the SEAS interface and the linkset name contains more than eight characters, only the first eight characters in the linkset name are shown. If this linkset name contains more than eight characters, and is specified with the linkset commands on the SEAS interface, only the first eight characters can be specified.

: apc/apca/apci/apcn/apcn24 – Adjacent point code – the point code identifying the node that is next to the EAGLE 5 ISS. The adjacent point code can be one of the following types of point codes:

:apc/apca – ANSI point code, ANSI private point code

:apci – ITU-I point code, ITU-I spare point code, ITU-I private point code, ITU-I private spare point code.

:apcn – 14-bit ITU-N point code, 14-bit ITU-N spare point code, 14-bit ITU-N private point code, 14-bit ITU-N private spare point code.

:apcn24 – 24-bit ITU-N point code, 24-bit ITU-N private point code.

NOTE 2: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

NOTE: The **apc/apca/apci/apcn/apcn24** parameter must be specified with the **ent - ls** command. Specifying this parameter with the **chg - ls** command is required only if the adjacent point code of the linkset is being changed.

: lst – The linkset type of the specified linkset - The **lst** parameter must be specified with the **ent - ls** command. Specifying this parameter with the **chg - ls** command is required only if the linkset type of the linkset is being changed.

: ipgwapc – IP Gateway Adjacent Point Code indicator. Specify the **ipgwapc=yes** parameter to provide SS7 linkset definition compatibility for gateway connections to IP-SCPs. This parameter can be specified only for, and must be specified for, linksets containing signaling links assigned to either the SS7IPGW or IPGWI applications. The default is **ipgwapc=no**.

NOTE: The **ipgwapc** parameter can be specified only with the **ent - ls** command.

To provision ISUP-CIC routing keys, the **ipgwapc=yes** parameter and the IP Gateway ISUP routing feature must be turned on. Verify this with the **rtrv - feat** command. If the IP Gateway ISUP routing feature is turned on, the **ipisup** field should be set to **on**. If the IP Gateway ISUP routing feature is not turned on, enter the **chg - feat:ipisup=on** command.

NOTE 5: Once the IP Gateway ISUP routing feature is turned on with the **chg - feat** command, it cannot be turned off.

NOTE: The IP Gateway ISUP routing feature must be purchased before you turn the feature on with the **chg - feat** command. If you are not sure if you have purchased the IP Gateway ISUP routing feature, contact your Tekelec Sales Representative or Account Representative.

: iptps – The quantity of IPTPS (transactions per second) that is assigned to the IPGWx linkset, from 100 to 112,000. The total amount of IPTPS for all IPGWx linksets cannot exceed the system-wide IPTPS value shown in the **rept - stat - iptps** output. For more information on the system-wide IPTPS value, see the [Increasing the System-Wide IPGWx Signaling TPS](#) procedure.

:lsusealm – The linkset's IPTPS alarm threshold, from 10 to 100 percent of the linkset's IPTPS. When this threshold is reached, a major alarm (UAM 0115) is generated. When the linkset's IPTPS falls below this threshold, UAM 0115 is automatically cleared and UAM 0118 is generated.

:slkusealm – The signaling link IPTPS alarm threshold, from 10 to 100 percent of the signaling link's fair share of the linkset's IPTPS or from 10 to 100 percent of the IPGWx card's capacity (2000 TPS). This threshold is reached when the signaling link's actual usage exceeds the percentage of the signaling link's fair share of the linkset's IPTPS or the percentage of the IPGWx card's capacity.

A signaling link's fair share of linkset's IPTPS is the linkset's IPTPS divided by the number of in-service links in the linkset. For example, if the linkset IPTPS is 4000 and there are 4 signaling links in the linkset, all in-service, then the signaling link's fair-share would be 1000 IPTPS ($4000/4=1000$). [Table 6-2](#) shows this calculation for a linkset with 1, 2, 3 and 4 in-service signaling links.

Table 6-2. Signaling Link Fair Share Example

Number of In-Service Signaling Links	Linkset IPTPS	Signaling Link Fair Share of the Linkset IPTPS
4	4000	1000
3	4000	1333
2	4000	2000
1	4000	4000

When this threshold is exceeded, a minor alarm (UAM 0116) is generated. When the amount of traffic on the signaling link falls below this threshold, UAM 0116 is automatically cleared and UAM 0119 is generated.

The signaling link IPTPS alarm shows that the linkset IPTPS is set too low for the linkset or that the IPGWx card's capacity has been exceeded. Setting the signaling link IPTPS alarm threshold lower than the linkset IPTPS alarm threshold can give the user an earlier indication that the linkset IPTPS is inadequate or that traffic is not balanced across the links in the linkset.

:multgc – specifies whether multiple group codes (for 14-bit ITU-N point codes) are supported for the linkset. When this parameter value is **yes**, secondary adjacent point codes whose group codes are different from the adjacent point code of the linkset can be assigned to the linkset. If the parameter value is **no**, the group code of the secondary adjacent point code must be the same as the group code of the linkset's adjacent point code. For more information on secondary adjacent point codes, go to the "Configuring an ITU Linkset with a Secondary Adjacent Point Code (SAPC)" procedure in the *Database Administration Manual - SS7*.

This parameter only applies to linksets whose adjacent point codes are either ITU international point codes or ITU national point codes. All the signaling links in this linkset must be assigned to cards running the IPGWI application. For more information on assigning signaling links to cards running the IPGWI application, go to the [Adding an IPGWx Signaling Link](#) procedure.

The ITU duplicate point code feature must be on before this parameter can be specified. Verify this with the **rtrv-feat** command. If the ITU duplicate point code feature is turned on, the **ituduppc** field should be set to **on**. If the ITU duplicate point code feature is not turned on, enter the **chg-feat:ituduppc=on** command.

NOTE: Once the ITU duplicate point code feature is turned on with the **chg-feat** command, it cannot be turned off.

The ITU duplicate point code feature must be purchased before you turn the feature on with the **chg-feat command. If you are not sure if you have purchased the ITU duplicate point code feature, contact your Tekelec Sales Representative or Account Representative.**

The adjacent point code (APC) for the linkset must be defined in the database, must be in the SS7 domain and cannot match the point code or capability point code of the EAGLE 5 ISS. The domain of the point code is shown in the **DOMAIN** field in the output of the **rtrv-dstn** command. The point code of the EAGLE 5 ISS is shown in the **PCA**, **PCN**, **PCN24**, or **PCI** fields and the capability point code of the EAGLE 5 ISS are shown in the **CPCA**, **CPCN**, **CPCN24**, or **CPCI** fields in the output of the **rtrv-sid** command. An ANSI adjacent point code must be a full point code and cannot be a cluster point code or a network routing point code. The adjacent point code of the linkset cannot be a proxy point code, cannot have a proxy point code assigned to it, and cannot be assigned to another linkset.

If the APC is not in the destination point code table, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the APC to the destination point code table.

For IPGWx linksets, more than one device may be attached to the LAN and have IP connections to the IP card running either the SS7IPGW or IPGWI application. Thus each IPGWx linkset is adjacent to all devices on the LAN (or adjacent to no device on the LAN, depending on your point of view). To provide a scheme allowing this point-to-multipoint connection and maintain consistent SS7 linkset definition rules, a virtual APC is required. This virtual APC is a real SS7 point code that is not used anywhere else in the SS7 network. Virtual APCs assigned to SS7IPGW linksets are ANSI point codes. Virtual APCs assigned to IPGWI linksets are either ITU-I or ITU-N point codes (either 14-bit or 24-bit ITU-N point codes). Virtual point codes can be reused on more than one switch. For example, a mated set of switches, each with two related links, could share two virtual point codes instead of requiring four. DPCs and linksets related to the virtual APC must be defined with the **ipgwapc** parameter set to **yes**.

For provisioning of ISUP-CIC routing keys, the **ipgwapc=yes** parameter and the IP Gateway ISUP routing feature must be turned on. Verify this with the **rtrv-feat** command. If the IP Gateway ISUP routing feature is turned on, the **ipisup** field should be set to **on**. If the IP Gateway ISUP routing feature is not turned on, enter the **chg-feat:ipisup=on** command.

NOTE: Once the IP Gateway ISUP routing feature is turned on with the chg-feat command, it cannot be turned off.

The IP Gateway ISUP routing feature must be purchased before you turn the feature on with the chg-feat command. If you are not sure if you have purchased the IP Gateway ISUP routing feature, contact your Tekelec Sales Representative or Account Representative.

Other Optional Parameters

Other optional parameters, shown in [Table 6-3](#), can be used with the **ent-ls** or **chg-ls** commands but do not need to be used in this procedure. These parameters are discussed in more detail in either the “Adding an SS7 Linkset” or Changing an SS7 Linkset” procedures in the *Database Administration Manual - SS7*. The **matelsn** parameter is discussed in more detail in the [Configuring a Mate IPGWx Linkset](#) procedure.

Table 6-3. Optional Linkset Parameters

ccli	sltset	l3tset	scrn	gwsa
gwsm	gwsd	bei	nis	itutfr
asl8	slsrsb	slsocbit	mtprse*	slsci
tfatcabmlq	gmscrn	sapci	sapcn	sapcn24
action	matelsn	apcntype	gttmode	randsls
spc/spca/spci/spcn/spcn24 *		ppc/ppca/ppci/ppcn/ppcn24 *		
* These parameters cannot be specified for an IPGWx linkset.				

Canceling the RTRV-LS and RTRV-DSTN Commands

Because the **rtrv-ls** and **rtrv-dstn** commands used in this procedure can output information for a long period of time, the **rtrv-ls** and **rtrv-dstn** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-ls** and **rtrv-dstn** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered, from another terminal other than the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the system-wide IPTPS usage report, and the IPGWx linksets, by entering the **rept-stat-iptps** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```
IP TPS USAGE REPORT
      THRESH  CONFIG      TPS      PEAK      PEAKTIMESTAMP
-----
SYSTEM
RLGHNCXA03W 100%   30000 TX:    7200    7600 05-02-10 11:40:04
              RCV:    7200    7600 05-02-10 11:40:04
-----
LSN
LSGW1101     80%   10000 TX:    7200    7600 05-02-10 11:40:04
              RCV:    7200    7600 05-02-10 11:40:04
LSGW1103     80%   10000 TX:    6700    7600 05-02-10 11:40:04
              RCV:    6500    7600 05-02-10 11:40:04
LSGW1105     80%   10000 TX:    7300    7450 05-02-10 11:40:04
              RCV:    7300    7450 05-02-10 11:40:04
-----
Command Completed.
```

If the sum of the IPTPSs of all the IPGWx linksets is equal to the configured IPTPS amount shown in this report:

- No new IPGWx linksets can be added
- The linkset IPTPS of any IPGWx existing linkset cannot be increased.

If a new IPGWx linkset is being added in this procedure, and the IPTPS value for this linkset allows the sum of the IPTPS of all the IPGWx linksets to exceed the configured IPTPS amount shown in this report, the new IPGWx linkset cannot be added.

If an existing IPGWx IP TPS value is being changed in this procedure, and the IPTPS value for this linkset allows the sum of the IPTPS of all the IPGWx linksets to exceed the configured IPTPS amount shown in this report, the IPGWx linkset IPTPS value cannot be changed.

To add a new IPGWx linkset or change the IPTPS value of an existing IPGWx linkset when the resulting sum of IPTPS values for all IPGWx linksets will exceed the IPTPS amount shown in this report, the system-

wide IPTPS amount must be increased, or the linkset IPTPS of some or all the IPGWx linksets must be reduced to allow for the new IPTPS value for the linkset configured in this procedure.

To increase the system-wide IPTPS amount, perform the [Increasing the System-Wide IPGWx Signaling TPS](#) procedure. If the system-wide IPTPS amount is 112000, shown in the **CONFIG** column in the **SYSTEM** section of this report, the system-wide IPTPS amount cannot be increased. Skip step 2 and go to step 3.

If the linkset IPTPS values of the IPGWx linksets need to be reduced, perform step 2.

2. Reduce the IPTPS values of some or all the IPGWx linksets by entering the **chg-ls** command with the name of each linkset being changed from step 1, and the new IPTPS value. For this example, enter these commands.

```
chg-ls:lsn=lsgw1101:iptps=6000
```

```
chg-ls:lsn=lsgw1103:iptps=6000
```

When the **chg-ls** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 13 of 1024) 1% full
CHG-LS: MASP A - COMPLTD
```

3. Display the current linksets in the database using the **rtrv-ls** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

LSN	APCA	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS
e1e2	001-207-000		none	1	1	no	B	6		off	off	off	no				off
e1m1s1	001-001-001		none	1	1	no	A	7		off	off	off	no				off
e1m1s2	001-001-002		none	1	1	no	A	7		off	off	off	no				off
ls1305	001-005-000		none	1	1	no	A	1		off	off	off	no				off
ls1307	001-007-000		none	1	1	no	A	1		off	off	off	no				off
lsgw1101	008-012-003		none	1	1	no	A	1		off	off	off	no				off
lsgw1103	003-002-004		none	1	1	no	A	1		off	off	off	no				off
lsgw1105	009-002-003		none	1	1	no	A	1		off	off	off	no				off

LSN	APCA	(X25)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN	APCI	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS
e1e2i	1-207-0		none	1	1	no	B	4		off	off	off	---				on
ls1315	0-015-0		none	1	1	no	A	1		off	off	off	---				off
ls1317	0-017-0		none	1	1	no	A	1		off	off	off	---				on
e1m2s1	1-011-1		none	1	1	no	A	7		off	off	off	---				off
e1m2s2	1-011-2		none	1	1	no	A	7		off	off	off	---				off

LSN	APCN	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN	APCN24	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN (CHINA)	APCN	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

LSN (CHINA)	APCN24	(SS7)	SCRN	L3T	SLT	SET	BEI	LST	LNKS	GWS	GWS	GWS	ACT	MES	DIS	SLSCI	NIS

Link set table is (13 of 1024) 1% full.

4. To specify the **multgc=yes** parameter with the **ent - ls** or **chg - ls** commands, the ITU Duplicate Point Code feature must be on. For the ITU Duplicate Point Code feature to be on, the Multiple Point Code feature must be on. Enter the **rtrv-feat** command to verify that either of these features are on.

NOTE: If the **multgc** parameter is not being specified for the linkset, skip steps 4, 5, 6, and 7, and go to step 8. If the **multgc** parameter value is being changed to **no**, skip steps 4, and 5, and go to step 6. The **multgc** parameter can be specified only for linksets with either ITU-I or 14-bit ITU-N APCs, and linksets that contain signaling links running the IPGWI application.

The entry **MPC = on** in the **rtrv-feat** command output shows that the Multiple Point Code feature is on. The entry **ITUDUPPC = on** in the **rtrv-feat** command output shows that the ITU Duplicate Point Code feature is on. In this example, both features are off.

NOTE: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

5. Turn the ITU Duplicate Point Code feature on, and the Multiple Point Code feature if necessary, by entering one of these commands.

NOTE: If the ITU Duplicate Point Code feature is on (**ITUDUPPC = on**), skip this step and go to step 6.

To turn the ITU Duplicate Point Code feature on only.

chg-feat:ituduppc=on

To turn both the ITU Duplicate Point Code and Multiple Point Code features on.

chg-feat:mpc=on:ituduppc=on

NOTE: Once the ITU Duplicate Point Code and Multiple Point Code features are turned on with the **chg-feat** command, they cannot be turned off.

The ITU Duplicate Point Code and Multiple Point Code features must be purchased before you turn either of these features on with the **chg-feat** command. If you are not sure if you have purchased these features, contact your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
CHG-FEAT: MASP A - COMPLTD
```

6. If the **multgc** parameter value is changed to **no**, the linkset can contain only one secondary adjacent point code. An ITU international linkset can contain only one 14-bit ITU national secondary adjacent point code. If the ITU international linkset contains more than one 14-bit ITU national secondary adjacent point code, all but one of these 14-bit ITU national secondary adjacent point codes must be removed from the linkset. An ITU national linkset can contain only one ITU international secondary adjacent point code. All 14-bit ITU-N secondary adjacent point codes must be removed from the linkset. All routes to these secondary adjacent point codes must be removed from the database before the secondary adjacent point codes can be removed.

NOTE: If the **multgc** parameter value is not being changed, is being changed to **yes**, or if a new linkset is being added, skip steps 6 and 7, and go to step 8.

Display the routes using the secondary adjacent point code being removed from the linkset with the **rtrv-rte** command, specifying the secondary adjacent point code being removed as the value of the **dpc** parameter.

For this example, enter these commands.

rtrv-rte:dpcn=11213-de

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 37.5.0
DPCN          ALIASA          ALIASI  LSN          RC          APC
11213-de      -----          -----  lsn3          10          11213-de
RTX:No      CLLI=-----
```

rtrv-rte:dpcn=12114-fr

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 37.5.0
DPCN          ALIASA          ALIASI  LSN          RC          APC
12114-fr      -----          -----  lsn3          10          12114-fr
RTX:No      CLLI=-----
```

rtrv-rte:dpcn=12115-uk

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 37.5.0
DPCN          ALIASA          ALIASI  LSN          RC          APC
12115-uk      -----          -----  lsn3          10          12115-uk
RTX:No      CLLI=-----
```

If the secondary adjacent point code is assigned to a route, that route must be removed from the database. Perform the “Removing a Route” procedure in the *Database Administration Manual - SS7* to remove the route from the database.

- Remove the secondary adjacent point codes specified in step 6 from the linkset with the **chg-ls** command with the **sapcn** and the **action=delete** parameters. For this example, enter these commands.

chg-ls:lsn=lsn3:sapcn=11213-de:action=delete

chg-ls:lsn=lsn3:sapcn=12114-fr:action=delete

chg-ls:lsn=lsn3:sapcn=12115-uk:action=delete

When the **chg-ls** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 13 of 255) 5% full
CHG-LS: MASP A - COMPLTD
```

- Display the point code and capability point code of the EAGLE 5 ISS by using the **rtrv-sid** command.

NOTE 1: If an existing linkset is being changed, and the adjacent point code of that linkset is not being changed, skip steps 8 through 15, and go to step 16.

NOTE: If a new linkset is being added, or an existing linkset is being changed and the adjacent point code of that linkset is being changed, continue this procedure with step 8. The new adjacent point code of this linkset cannot be shown in the **rtrv-ls output in step 3.**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
PCA          PCI          PCN          CLLI          PCTYPE
001-001-001  1-200-6          13482        rlghncxa03w  OTHER
```

```

PCPA
002-002-002      002-002-003      002-002-004      002-002-005
002-002-006      002-002-007      002-002-008      002-002-009
004-002-001      004-003-003      144-212-003

PCPA (LNP)
005-005-002      005-005-004      005-005-005

CPCI
1-001-1          1-001-2          1-001-3          1-001-4

CPCN
02091            02092            02094            02097
02191            02192            11177

```

9. Display the destination point codes in the database by entering the **rtrv-dstn** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```

DPCA      CLLI      BEI  ELEI  ALIASI      ALIASN      DOMAIN
001-207-000  ----- no  ---  -----  -----  SS7
001-001-001  ----- no  ---  -----  -----  SS7
001-001-002  ----- no  ---  -----  -----  SS7
001-005-000  ----- no  ---  -----  -----  SS7
001-007-000  ----- no  ---  -----  -----  SS7
008-012-003  ----- no  ---  -----  -----  SS7
003-002-004  ----- no  ---  -----  -----  SS7
009-002-003  ----- no  ---  -----  -----  SS7
010-020-005  ----- no  ---  -----  -----  SS7

DPCI      CLLI      BEI  ELEI  ALIASI      ALIASN      DOMAIN
1-207-0      ----- no  ---  -----  -----  SS7
0-015-0      ----- no  ---  -----  -----  SS7
0-017-0      ----- no  ---  -----  -----  SS7
1-011-1      ----- no  ---  -----  -----  SS7
1-011-2      ----- no  ---  -----  -----  SS7

DPCN      CLLI      BEI  ELEI  ALIASA      ALIASI      DOMAIN
DPCN24     CLLI      BEI  ELEI  ALIASA      ALIASI      DOMAIN

```

```
Destination table is (14 of 2000) 1% full
```

```
Alias table is (0 of 12000) 0% full
```

If the new adjacent point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* to add the required point code. This point code cannot be a proxy point code (the **prx=yes** value assigned to the point code) and a proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code.

10. Display the adjacent point code of the new linkset in the destination point code table by using the **rtrv-dstn** command and specifying the point code. For this example, enter this command.

```
rtrv-dstn:dPCA=010-020-005
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```

DPCA      CLLI      BEI  ELEI  ALIASI      ALIASN      DOMAIN
010-020-005  ----- no  ---  -----  -----  SS7

          SPC          NCAI
          -----

```

```
Destination table is (14 of 2000) 1% full
```

```
Alias table is (0 of 12000) 0% full
```


This point code cannot be a proxy point code (the **prx=yes** value assigned to the point code) and a proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code. If a proxy point code is shown in this step, or if the point code is a proxy point code, choose another point code and repeat this procedure from step 8.

11. The APC of the linkset cannot be the DPC of any exception route. Verify that the adjacent point code of the linkset is not the DPC of any exception route by entering the **rtrv-rtx** command with the **dpc/dpca/dpci/dpcn/dpcn24** parameter. The **dpc/dpca/dpci/dpcn/dpcn24** parameter value is the adjacent point code value that will be specified for the linkset.

NOTE 1: If the adjacent point code was added in step 10, and a new linkset is being added, skip steps 11 and 12, and go to step 13.

NOTE: If the adjacent point code was added in step 10, and an existing linkset is being changed, skip .

For this example, enter this command.

rtrv-rtx:dpca=010-020-005

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
DPCA          RTX-CRITERIA          LSN          RC          APC

010-020-005   OPCA
               007-008-009          ls1305        20        001-005-000
               008-008-008          ls1307        40        001-007-000
```

```
DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s):                  13
EXCEPTION DPC(s):             5
NETWORK DPC(s):               0
CLUSTER DPC(s):              1
TOTAL DPC(s):                 19
CAPACITY (% FULL):            1%
ALIASES ALLOCATED:            12000
ALIASES USED:                 0
CAPACITY (% FULL):            0%
X-LIST ENTRIES ALLOCATED:     500
```

If the adjacent point code of the linkset is not the DPC of a route exception table entry, no entries are displayed in the **rtrv-rtx** output, but a summary of the point code quantities is displayed, as shown in the following output example.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s):                  15
EXCEPTION DPC(s):             5
NETWORK DPC(s):               0
CLUSTER DPC(s):              1
TOTAL DPC(s):                 21
CAPACITY (% FULL):            1%
ALIASES ALLOCATED:            12000
ALIASES USED:                 0
CAPACITY (% FULL):            0%
X-LIST ENTRIES ALLOCATED:     500
```

If the point code specified in this step is shown in the **DPCA/DPCI/DPCN/ DPCN24** columns in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- Choose another adjacent point code value and repeat steps 8, 9, 10, and 11.

- Remove all the entries displayed in this step by performing the “Removing a Route Exception Entry” procedure in the *Database Administration Manual - SS7*.
12. Display any entries in the route table whose DPC value is also the adjacent point code of the new linkset being added in this procedure, or the new adjacent point code of the existing linkset being changed in this procedure. Enter the **rtrv-rte** command with the **dpc/dpca/dpci/dpcn/dpcn24** parameter. The **dpc/dpca/dpci/dpcn/dpcn24** parameter value is the adjacent point code value that will be specified for the linkset. For this example, enter this command.

rtrv-rte:dpca=010-020-005

This is an example of the possible output.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA	ALIASI	ALIASN/N24	LSN	RC	APCA
010-020-005	-----	-----	lsn1	1	003-003-003
			lsn2	2	003-003-004
			RTX:No	CLLI=-----	

If the adjacent point code of the linkset is not the DPC of a route, the point code entry is displayed in the **rtrv-rte** output, but the LSN, RC, and APC columns contain dashes, as shown in the following output example.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA	ALIASI	ALIASN/N24	LSN	RC	APCA
002-002-002	-----	-----	-----	---	-----
			RTX:No	CLLI=-----	

If the point code specified in this step is shown in the **DPCA/DPCI/DPCN/ DPCN24** columns in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- Choose another adjacent point code value and repeat steps 8 through 12.
 - Remove all the entries displayed in this step by performing the “Removing a Route” procedure in the *Database Administration Manual - SS7*.
13. Verify that the IP Gateway ISUP routing feature is on by entering the **rtrv-feat** command. The entry **IPISUP = on** in the **rtrv-feat** command output shows that the IP Gateway ISUP routing feature is on.

NOTE 1: If you do not wish to use the IP Gateway ISUP routing feature, skip steps 13 and 14, and go to step 15.

NOTE: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

14. Turn the IP Gateway ISUP routing feature on by entering this command.

NOTE: If the IP Gateway ISUP routing feature is on (**IPISUP = on**), skip this step and go to step 15.

chg-feat:ipisup=on

NOTE: Once the IP Gateway ISUP routing feature is turned on with the **chg-feat** command, it cannot be turned off.

The IP Gateway ISUP routing feature must be purchased before you turn the feature on with the **chg-feat** command. If you are not sure if you have purchased the IP Gateway

ISUP routing feature, contact your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
CHG-FEAT: MASP A - COMPLTD
```

15. Add the new linkset to the database using the **ent - ls** command. The new linkset must meet these conditions.

- The name of this linkset cannot be used by another linkset – the linkset configuration is shown in the output of step 3.

The APC of the new linkset must be in the destination point code table, but cannot be either the EAGLE 5 ISS's point code or the EAGLE 5 ISS's capability point code – shown in the outputs of steps 8, 9, and 10. The adjacent point code can be one of the following types of point codes:

:apc/apca – ANSI point code, ANSI private point code

:apci – ITU-I point code, ITU-I spare point code, ITU-I private point code, ITU-I private spare point code.

:apcn – 14-bit ITU-N point code, 14-bit ITU-N spare point code, 14-bit ITU-N private point code, 14-bit ITU-N private spare point code.

:apcn24 – 24-bit ITU-N point code, 24-bit ITU-N private point code.

These parameters and values must also be specified for the IPGWx linkset:

- **ipgwapc=yes**
- **lst=<a, b, c, d, e>**
- **iptps=<100-112000>**

NOTE: The **iptps** parameter value must be divisible by 10. The sum of all the linkset IP TPS values, including the value for this linkset, cannot exceed the system-wide IP TPS value shown in the **rept - stat - iptps** output in step 1.

- The **mtprse=yes** parameter cannot be specified for an IPGWx linkset.
- The optional parameters **lsusealm** (the linkset's IP TPS alarm threshold) and **slkusealm** (the signaling link IP TPS alarm threshold) can be specified with the **ent - ls** command. The default value for the **lsusealm** parameter is 100%, and the default value for the **slkusealm** parameters is 80%.
- The **multgc=yes** parameter can be specified only for IPGWx linksets that will contain signaling links running the IPGWI application.

NOTE: There are other optional parameters that can be specified with the **ent - ls** command, but are not required for an IPGWx linkset. These parameters and their usage are discussed in the [Configuring a Mate IPGWx Linkset](#) procedure and in the "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

For this example, enter this command.

```
ent -
ls: lsn=lsgw1107:apca=010-020-005:lst=a:ipgwapc=yes :iptps=4000:lsusealm
=70:slkusealm=70
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 14 of 1024) 1% full
ENT-LS: MASP A - COMPLTD
```

16. Display the signaling link alarm threshold for the linkset being changed by entering the **rept-stat-iptps** command with the name of the linkset being changed. For this example, enter this command.

NOTE 1: If you do not wish to change an existing IPGWx linkset, skip steps 16 and 17, and go to step 18.

NOTE: If the `slkusealm` parameter for the linkset is not being changed, skip step 16 and go to step 17.

rept-stat-iptps:lsn=lsqw1105

This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
IP TPS USAGE REPORT
-----
THRESH  CONFIG      TPS      PEAK      PEAKTIMESTAMP
-----
LSN
LSGW1105      80%    10000  TX:    7300    7450  05-02-10 11:40:04
                  RCV:    7300    7450  05-02-10 11:40:04
-----
LOC  PORT
1105  A      80%    ----  TX:    7300    7450  05-02-10 11:40:04
                  RCV:    7300    7450  05-02-10 11:40:04
-----
Command Completed.
```

17. Change the existing linkset using the **chg-ls** command with the name of the linkset being changed, shown in the **rept-stat-iptps** output in step 1, and with at least one of these parameters:

- The new adjacent point code of the linkset, if the current adjacent point code of the linkset is being changed.
- **iptps=<100-112000>**
NOTE: The `iptps` parameter value must be divisible by 10. The sum of all the linkset IP TPS values, including the value for this linkset, cannot exceed the system-wide IP TPS value shown in the `rept-stat-iptps` output in step 1.
- The **mtprse=yes** parameter cannot be specified for an IPGWx linkset.
- The optional parameters **lsusealm** (the linkset's IP TPS alarm threshold) and **slkusealm** (the signaling link IP TPS alarm threshold) can be specified with the **chg-ls** command.
- The **multgc=yes** parameter can be specified only for IPGWx linksets that contain signaling links running the IPGWI application.

NOTE: There are other optional parameters that can be specified with the `chg-ls` command, but are not required for an IPGWx linkset. These parameters and their usage are discussed in the [Configuring a Mate IPGWx Linkset](#) procedure and in the "Changing an SS7 Linkset" procedure in the *Database Administration Manual - SS7*.

For this example, enter this command.

chg-ls:lsn=lsqw1105:iptps=14000:lsusealm=70:slkusealm=70

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 37.5.0
```

Link set table is (14 of 1024) 1% full
CHG-LS: MASP A - COMPLTD

18. Verify the changes using the **rtrv-ls** command specifying the linkset name specified in either steps 15 or 17 with the **lsn** parameter. For this example, enter these commands.

rtrv-ls:lsn=lsgw1105

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 37.5.0

LSN	APCA	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
lsgw1105	009-002-003		none	1	1	no	A	1	off	off	off	no	off
CLLI				TFATCABMLQ		MTPRSE		ASL8					
----- 1						no		no					
IPGWAPC				MATELSN		IPTPS		LSUSEALM		SLKUSEALM		GTTMODE	
yes				-----		14000		70		% 70		% CdPA	
LOC	LINK	SLC	TYPE	L2T SET	BPS		L1 MODE	TSET	ECM	PCR N1	PCR N2		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	LL		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	E1ATM CRC4	SI	SN
LOC	LINK	SLC	TYPE	IPLIML2									
LOC	LINK	SLC	TYPE	1105 A 0 SS7IPGW									
LOC	LINK	SLC	TYPE	L2T SET	BPS		ECM	PCR N1	PCR N2	E1 LOC	E1 PORT	TS	
LOC	LINK	SLC	TYPE	L2T SET	BPS		ECM	PCR N1	PCR N2	T1 LOC	T1 PORT	TS	

Link set table is (14 of 1024) 1% full

rtrv-ls:lsn=lsgw1107

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 37.5.0

LSN	APCA	(SS7)	SCRN	L3T SET	SLT SET	BEI	LST	LNKS	GWS ACT	GWS MES	GWS DIS	SLSCI	NIS
lsgw1107	010-020-005		none	1	1	no	A	0	off	off	off	no	off
CLLI				TFATCABMLQ		MTPRSE		ASL8					
----- 1						no		no					
IPGWAPC				MATELSN		IPTPS		LSUSEALM		SLKUSEALM		GTTMODE	
yes				-----		4000		70		% 70		% CdPA	
LOC	LINK	SLC	TYPE	L2T SET	BPS		L1 MODE	TSET	ECM	PCR N1	PCR N2		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	LL		
LOC	LINK	SLC	TYPE	LP SET	BPS		ATM TSEL		VCI	VPI	E1ATM CRC4	SI	SN
LOC	LINK	SLC	TYPE	IPLIML2									

```

LOC LINK SLC TYPE
LOC LINK SLC TYPE L2T SET BPS ECM PCR N1 PCR N2 E1 LOC E1 PORT TS
LOC LINK SLC TYPE L2T SET BPS ECM PCR N1 PCR N2 T1 LOC T1 PORT TS

```

Link set table is (14 of 1024) 1% full


19. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


Flowchart 6-2. Configuring an IPGWx Linkset


























Configuring a Mate IPGWx Linkset

This procedure is used to configure a mate IPGWx linkset to an existing IPGWx linkset **chg- ls** command with these parameters.

: lsn – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter. However, the SEAS interface supports only eight characters. If this linkset is displayed on the SEAS interface and the linkset name contains more than eight characters, only the first eight characters in the linkset name are shown. If this linkset name contains more than eight characters, and is specified with the linkset commands on the SEAS interface, only the first eight characters can be specified.

:mate lsn – The name of the mate IPGWx linkset.

: action – to add (**action=add**) or remove (**action=delete**) the mate IPGWx linkset to the IPGWx linkset specified by the **lsn** parameter.

NOTE: This procedure is not used to configure an IPGWx linkset, with the **ipgwapc**, **iptps**, **lsusealm** and **slkusealm** parameters. To configure an IPGWx linkset with these parameters, perform the [Configuring an IPGWx Linkset](#) procedure.

An IPGWx linkset is a linkset that contains signaling links assigned to IPGWx cards. IPGWx cards are cards running either the SS7IPGW or IPGWI applications.

The EAGLE 5 ISS allows an IPGWx linkset to contain up to 8 IPGWx signaling links, and as a result, 8 IPGWx cards. This increases the amount of traffic that can be delivered to a single IP node compared to the two-card combined IPGWx linkset deployments used in previous releases. An IPGWx linkset containing up to 8 IPGWx signaling links is the preferred method of configuring IPGWx linksets (see the [Configuring an IPGWx Linkset](#) procedure). This method is required if more than two IPGWx signaling links are to be used in the linkset.

To provide backward compatibility with pre-existing two-card combined IPGWx linkset deployments, the EAGLE 5 ISS also provides for a mate IPGWx linkset. A mate IPGWx linkset consists of one IPGWx linkset assigned to another IPGWx linkset using the **mate lsn** parameter of the **chg-ls** command. To assign a mate IPGWx linkset to another IPGWx linkset, both linksets can contain no more than one signaling link. While mate IPGWx linksets can be configured using this procedure, the preferred method of configuring two-card IPGWx deployments is to configure a two-link non-mated linkset using the [Configuring an IPGWx Linkset](#) procedure.

Each linkset in the mated pair must either contain no mate linksets, or can reference the other linkset in the mated pair. For example, to assign linkset **LSN2** to IPGWx linkset **LSN1** as a mate linkset, linkset **LSN1** cannot contain any mate linksets. Linkset **LSN2** can have linkset **LSN1** as a mate, otherwise linkset **LSN2** cannot have any mate linksets assigned to it.

The mate linkset name is displayed in the **rtrv-ls:lsn=<linkset name>** command output. If either linkset contains more than one signaling link, all but one of the signaling links must be removed from these linksets or other linksets must be chosen. Perform the [Removing an IPGWx Signaling Link](#) procedure to remove any signaling links from the linkset. If new linksets must be configured for this procedure, perform the [Configuring an IPGWx Linkset](#) procedure.

Before a mate IPGWx linkset can be added to an IPGWx linkset, the card containing the IPGWx signaling link assigned to the linkset being changed, and the signaling link assigned to that card must be placed out of service.

Before a mate IPGWx linkset can be removed from an IPGWx linkset, the card containing the IPGWx signaling link assigned to the mate linkset, and the signaling link assigned to that card must be placed out of service.

The network type of the adjacent point code of the mate IPGWx linkset must be the same type as the linkset the mate is assigned to. For example, if a mate IPGWx linkset is assigned to an IPGWx linkset with an ITU-I adjacent point code, the mate IPGWx linkset must have an ITU-I adjacent point code.

Other Optional Parameters

Other optional parameters, shown in [Table 6-4](#), can be used with the **chg-ls** command but do not need to be used in this procedure. These parameters are discussed in more detail in the “Changing an SS7 Linkset” procedures in the *Database Administration Manual - SS7*. The **iptps**, **lsusealm**, and **slkusealm** parameters are discussed in more detail in the [Configuring an IPGWx Linkset](#) procedure.

Table 6-4. Optional Linkset Parameters

clli	sltset	l3tset	scrn	gwsa	gwsn
gwsd	bei	nis	itutfr	mtprse*	slsci
asl8	slsrbs	slsocbit	multgc	tfatcabmlq	gsmscrn
sapci	sapcn	sapcn24	iptps	lsusealm	slkusealm

apcntype	gttmode	randsls			
* The mtrprse parameter cannot be specified for an IPGWx linkset.					

Procedure

1. Display the system-wide IP TPS usage report, and the IPGWx linksets, by entering the **rept-stat-iptps** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

IP TPS USAGE REPORT
      THRESH  CONFIG      TPS      PEAK      PEAKTIMESTAMP
-----
SYSTEM
RLGHNCXA03W 100%   30000  TX:   7200   7600  05-02-10 11:40:04
              RCV:   7200   7600  05-02-10 11:40:04
-----
LSN
LSGW1101      80%    6000  TX:   5100   5500  05-02-10 11:40:04
              RCV:   5100   5500  05-02-10 11:40:04
LSGW1103      80%    6000  TX:   5200   5500  05-02-10 11:40:04
              RCV:   5200   5500  05-02-10 11:40:04
LSGW1105      80%   14000  TX:   7300   7450  05-02-10 11:40:04
              RCV:   7300   7450  05-02-10 11:40:04
LSGW1107      70%    4000  TX:   3200   3500  05-02-10 11:40:04
              RCV:   3200   3500  05-02-10 11:40:04
-----
Command Completed.
```

2. Display the linkset that is being changed by entering the **rtrv-ls** command with a linkset name shown in the **rept-stat-iptps** output in step 1. For this example, enter this command.

rtrv-ls:lsn=lsgw1103

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN          APCA  (SS7)  SCRNL3T SLT          GWS GWS GWS
lsgw1103     003-002-004 none  1  1  no  A  1  ACT MES DIS SLSCI NIS
                                off off off no  off

CLLI          TFATCABMLQ MTPRSE ASL8
----- 1          no  no

IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
yes      ----- 10000 70    % 70    % CdPA

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR
      SET  BPS      MODE TSET  ECM  N1  N2

LOC  LINK SLC TYPE      LP      ATM      VCI  VPI  LL
      SET  BPS      TSEL      VCI  VPI  CRC4 SI SN

LOC  LINK SLC TYPE      LP      ATM      E1ATM
      SET  BPS      TSEL      VCI  VPI  CRC4 SI SN

LOC  LINK SLC TYPE      IPLIML2

LOC  LINK SLC TYPE
1103 A  0  SS7IPGW

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR  E1  E1
      SET  BPS      ECM  N1  N2  LOC  PORT TS

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR  T1  T1
      SET  BPS      ECM  N1  N2  LOC  PORT TS
```

Link set table is (14 of 1024) 1% full

If this linkset has a mate linkset assigned to it, the name of the mate linkset is shown in the **MATELSN** field of the **rtrv-ls** output, as shown in the following output.

rtrv-ls:lsn=lsgw1103

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	GWS	GWS	GWS	SLSCI	NIS
lsgw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off
CLLI				TFATCABMLQ		MTPRSE		ASL8					
-----				1		no		no					
IPGWAPC	MATELSN	IPTPS		LSUSEALM	SLKUSEALM		GTTMODE						
yes	lsgw1107	10000		70	% 70		% CdPA						
LOC	LINK	SLC	TYPE	L2T	BPS	L1	MODE	TSET	ECM	PCR	PCR		
				SET						N1	N2		
LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL		VCI	VPI	LL		
				SET									
LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL		VCI	VPI	E1ATM		
				SET							CRC4	SI	SN
LOC	LINK	SLC	TYPE	IPLIML2									
LOC	LINK	SLC	TYPE										
1103	A	0	SS7IPGW										
LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	E1	E1			
				SET			N1	N2	LOC	PORT	TS		
LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	T1	T1			
				SET			N1	N2	LOC	PORT	TS		

Link set table is (14 of 1024) 1% full

- To assign a mate linkset to this linkset, and the linkset contains more than one signaling link, all but one of these signaling links must be removed from the linkset. Perform the [Removing an IPGWx Signaling Link](#) procedure to remove these signaling links.

NOTE: If the linkset being changed has no signaling links, or only one signaling link assigned to it, or if the mate linkset is being removed from the linkset being changed, skip step 3 and go to step 4.

If you do not wish to change this linkset, either choose another linkset from the **rept-stat-iptps** output in step 1, and repeat step 2, and 3 if necessary, or perform the [Configuring an IPGWx Linkset](#) procedure and add a new linkset. Go to step 4.

- If a mate linkset is being added in this procedure, display the mate linkset from the IPGWx linksets shown in the **rept-stat-iptps** output in step 1.

If a mate linkset is being removed in this procedure, display the mate linkset shown in the **MATELSN** column of the **rtrv-ls** output in step 2.

For this example, enter this command.

rtrv-ls:lsn=lsgw1107

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
```

```

LSN          APCA  (SS7)  SCRNL3T SLT          GWS GWS GWS
lsgw1107      003-002-004  none  1  1  no  A  1  ACT MES DIS SLSCI NIS
                                     off off off no  off

```

```

CLLI          TFATCABMLQ MTPRSE ASL8
----- 1          no      no

```

```

IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
yes      ----- 10000 70      % 70      % CdPA

```

```

LOC  LINK SLC TYPE      L2T      L1      PCR  PCR
SET  BPS      MODE TSET  ECM   N1   N2

LOC  LINK SLC TYPE      LP      ATM      VCI   VPI   LL
SET  BPS      TSEL

LOC  LINK SLC TYPE      LP      ATM      VCI   VPI   E1ATM
SET  BPS      TSEL      CRC4 SI SN

LOC  LINK SLC TYPE      IPLIML2

LOC  LINK SLC TYPE
1107 A      0      SS7IPGW

```

```

LOC  LINK SLC TYPE      L2T      PCR  PCR  E1  E1
SET  BPS      ECM   N1   N2  LOC  PORT TS

LOC  LINK SLC TYPE      L2T      PCR  PCR  T1  T1
SET  BPS      ECM   N1   N2  LOC  PORT TS

```

```
Link set table is ( 14 of 1024) 1% full
```

- To use the linkset shown in step 4 as a mate, the network type of the adjacent point code of the linkset shown in step 4 must be the same as the network type of the linkset shown in step 2. The linkset shown in step 4 must not have more than one signaling link assigned to it.

NOTE: If the mate linkset is being removed from the linkset being changed, skip step 5 and go to step 6.

If the linkset contains more than one signaling link, all but one of these signaling links must be removed from the linkset. Perform the [Removing an IPGWx Signaling Link](#) procedure to remove these signaling links.

If you do not wish to change this linkset, or if the network type of the adjacent point codes of both linksets are not the same, either choose another linkset from the **rept-stat-iptps** output in step 1, and repeat step 4, and 5 if necessary, or perform the [Configuring an IPGWx Linkset](#) procedure and add a new linkset. Go to step 6.

If the network types of the adjacent point codes of both linksets are the same, and the mate linkset contains no more than one signaling link, do not perform the actions in this step. Go to step 6.

- Display the status of the card containing the signaling link assigned to the linkset being changed by entering the **rept-stat-card** command with the card location shown in the **LOC** field in the **rtrv-ls** output in step 2 (for adding a mate linkset) or in the **rtrv-ls** output in step 4 (for removing a mate linkset). For this example, enter one of these commands.

NOTE 1: If the linkset that the mate linkset is being added to has no signaling links (see the **rtrv-ls output in step 2), skip steps 6 through 16, and go to step 17.**

NOTE: If the mate linkset is being removed in this procedure, and has no signaling links (see the **rtrv-ls output in step 4), skip steps 6 through 16, and go to step 17.**

rept-stat-card:loc=1103 (for the adding a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1103  114-000-000   DCM      SS7IPGW   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        lsgw1103   -----
Command Completed.
```

rept-stat-card:loc=1107 (for the removing a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1107  114-000-000   DCM      SS7IPGW   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        lsgw1107   -----
Command Completed.
```

7. Display the status of the signaling link assigned to the card shown in step 6 by entering the **rept-stat-slk** command with the card location used in step 6 and the **link=a** parameter. For this example, enter one of these commands.

NOTE: If the status of the card shown in PST field in the **rept-stat-card** output in step 6 is OOS-MT-DSBLD, skip steps 7 through 16, and go to step 17.

rept-stat-slk:loc=1103:link=a (for the adding a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN          CLLI      PST      SST      AST
1103,A lsgw1103     ----- IS-NR     Avail   -----
ALARM STATUS      = No Alarms.
UNAVAIL REASON    = NA
Command Completed.
```

rept-stat-slk:loc=1107:link=a (for the removing a mate linkset example)

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN          CLLI      PST      SST      AST
1107,A lsgw1107     ----- IS-NR     Avail   -----
ALARM STATUS      = No Alarms.
UNAVAIL REASON    = NA
Command Completed.
```

8. Any in-service IP connections on the signaling link shown in step 7 must be placed out of service. The recommended method is to have the far end node place these IP connections out of service. Have the far-end node for the signaling link shown in step 7 perform these actions:

NOTE: If the status of the signaling link shown in the PST field of the **rept-stat-slk** output in step 7 is OOS-MT-DSBLD, skip steps 8 through 15, and go to step 16.

- Place the TALI sockets in the NEA-FEP state.
- Place the M3UA or SUA associations in either the ASP-INACTIVE or ASP-DOWN state.

NOTE: If you choose to perform this step, skip steps 9 through 16, and go to step 17.

9. Display the IP link associated with the card that the signaling link shown in step 7 is assigned to by entering the **rtrv-ip-lnk** command with the card location shown in step 7. For this example, enter one of these commands.

rtrv-ip-lnk:loc=1103 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1103  A     192.1.1.10      255.255.255.128  HALF    10     802.3    NO    NO
1103  B     -----          -----          HALF    10     DIX      NO    NO
```

rtrv-ip-lnk:loc=1107 (for the removing a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1107  A     192.3.1.10      255.255.255.128  HALF    10     802.3    NO    NO
1107  B     -----          -----          HALF    10     DIX      NO    NO
```

10. Display the IP host information associated with the IP link by entering the **rtrv-ip-host** command with the IP address shown in step 9. For this example, enter one of these commands.

rtrv-ip-host:ipaddr=192.001.001.010 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR      LOCAL HOST
192.1.1.10        IPNODE1_1103
```

IP Host table is (11 of 512) 2% full

rtrv-ip-host:ipaddr=192.003.001.010 (for the removing a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR      LOCAL HOST
192.3.1.10        IPNODE1_1107
```

IP Host table is (11 of 512) 2% full

11. Display the socket associated with the local host name shown in step 10 by entering the **rtrv-appl-sock** command. For this example, enter one of these commands.

rtrv-appl-sock:lhost=ipnode1_1103 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_1103
LINK  A
LHOST IPNODE1_1103
```

RHOST	KC_HLR2	RPORT	7001
LPORT	7000	DCMPS	1
SERVER	YES	RTT	60
REXMIT	FIXED	ALW	YES
OPEN	YES		

IP Appl Sock/Assoc table is (4 of 4000) 1% full

rtrv-appl-sock: lhost=ipnode1_1107 (for the removing a mate linkset example)

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

IP Appl Sock/Assoc table is (4 of 4000) 1% full

NOTE: If the specified socket name is not in the database, the rtrv-appl-sock output shows no socket information as shown above.

- Change the **alw** parameter values in the socket shown in step 11 using the **chg-appl-sock** command with the **alw=no** parameters, as necessary.

NOTE: If there is no socket shown in step 11, or the open and alw parameter values of the socket shown in step 11 are no, skip this step and step 13, and go to step 14.

For example, enter this command.

chg-appl-sock: sname=kc_hlr1_1103: alw=no



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

When this command has successfully completed, the following message should appear.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD

Repeat this step for all sockets shown in step 11.

- Change the **open** parameter values in the socket shown in step 11 using the **chg-appl-sock** command with the **open=no** parameters, as necessary.

For example, enter this command.

chg-appl-sock: sname=kc_hlr1_1103: open=no

When this command has successfully completed, the following message should appear.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD

Repeat this step for all sockets shown in step 11.

- Display the association associated with the local host name shown in step 10 by entering the **rtrv-assoc** command.

For this example, enter one of these command.

rtrv-assoc: lhost=ipnode1_1107 (for the removing a mate linkset example)

This is an example of possible output.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

	CARD	IPLNK							
ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW	
assoc1	1107	A	A	M3UA	1030	1030	YES	YES	

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1107
```

rtrv-assoc: lhost=ipnode1_1103 (for the adding a mate linkset example)

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
```

NOTE: If the specified association name is not in the database, the rtrv-assoc output shows no association information as shown above.

15. Change the **alw** parameter values in the association shown in step 14 using the **chg-assoc** command with the **alw=no** parameters, as necessary.

NOTE: If there is no association shown in step 14, or the open and alw parameter values of the association shown in step 14 are no, skip this step and step 16, and go to step 17.

chg-assoc: aname=assoc1: alw=no



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```

Repeat this step for all associations shown in step 14.

16. Change the **open** parameter values in the association shown in step 14 using the **chg-assoc** command with the **open=no** parameters, as necessary.

chg-assoc: aname=assoc1: open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```

Repeat this step for all associations shown in step 14.

17. Deactivate the signaling link assigned to the IP card using the **dact-slk** command. For example, enter one of these commands:

dact-slk: loc=1103: link=a (for the adding a mate linkset example)

dact-slk: loc=1107: link=a (for the removing a mate linkset example)



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

18. Inhibit the IP card using the **inh-card** command. For example, enter one of these commands.

inh-card: loc=1103 (for the adding a mate linkset example)

inh-card: loc=1107 (for the removing a mate linkset example)

This message should appear.


```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

19. Change the linkset shown in step 2 with the **chg-ls** command. If a mate IPGWx linkset is being added, use the **matelsn** and **action=add** parameters with the **chg-ls** command. If a mate IPGWx linkset is being removed, use the **matelsn** and **action=delete** parameters with the **chg-ls** command.

To add a mate linkset in this example, enter this command.

```
chg-ls: lsn=lsgw1103:matelsn=lsgw1107:action=add
```

To remove a mate linkset in this example, enter this command.

```
chg-ls: lsn=lsgw1103:matelsn=lsgw1107:action=delete
```

NOTE: There are other optional parameters that can be specified with the **chg-ls** command, but are not required for an IPGWx linkset. These parameters and their usage are discussed in the [Configuring an IPGWx Linkset](#) procedure and in the “Changing an SS7 Linkset” procedure in the *Database Administration Manual - SS7*.

When the **chg-ls** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 36.0.0
Link set table is ( 14 of 1024) 1% full
CHG-LS: MASP A - COMPLTD
```

20. Verify the changes using the **rtrv-ls** command specifying the linkset name specified in step 19 with the **lsn** parameter. For this example, enter this command.

```
rtrv-ls: lsn=lsgw1103
```

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
```

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsgw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off

CLLI	TFATCABMLQ	MTPRSE	ASL8
-----	1	no	no

IPGWAPC	MATELSN	IPTPS	LSUSEALM	SLKUSEALM	GTTMODE
yes	lsgw1107	10000	70	% 70	% CdPA

LOC	LINK	SLC	TYPE	L2T	BPS	L1	TSET	ECM	PCR	PCR
				SET		MODE			N1	N2

LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL	VCI	VPI	LL
				SET						

LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL	VCI	VPI	E1ATM
				SET						CRC4 SI SN

LOC	LINK	SLC	TYPE	IPLIML2

LOC	LINK	SLC	TYPE
1103	A	0	SS7IPGW

LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	E1	E1
				SET			N1	N2	LOC	PORT TS

LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	T1	T1
				SET			N1	N2	LOC	PORT TS


```
Link set table is ( 14 of 1024) 1% full
```

If the mate linkset was removed in step 19, the **MATELSN** column of the **rtrv-ls** output should contain dashes, as shown in the following example.

rtrv-ls:lsn=lsqw1103

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsqw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off

CLLI	TFATCABMLQ	MTPRSE	ASL8
-----	1	no	no

IPGWAPC	MATELSN	IPTPS	LSUSEALM	SLKUSEALM	GTTMODE
yes	-----	10000	70	% 70	% CdPA

LOC	LINK	SLC	TYPE	L2T	BPS	L1	TSET	ECM	PCR	PCR
				SET		MODE			N1	N2

LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL	VCI	VPI	LL
				SET						

LOC	LINK	SLC	TYPE	LP	BPS	ATM	TSEL	VCI	VPI	E1ATM
				SET						CRC4 SI SN

LOC	LINK	SLC	TYPE	IPLIML2

LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	E1	E1
				SET			N1	N2	LOC	PORT TS

LOC	LINK	SLC	TYPE	L2T	BPS	ECM	PCR	PCR	T1	T1
				SET			N1	N2	LOC	PORT TS

Link set table is (14 of 1024) 1% full

21. Allow the IP card that was inhibited in step 18 using the **alw-card** command. For example, enter one of these commands.

NOTE: If the linkset shown in step 20 does not have a signaling link assigned to it, skip steps 21 through 25, and go to step 26.

alw-card:loc=1103 (for the adding a mate linkset example)

alw-card:loc=1107 (for the removing a mate linkset example)

This message should appear.

rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0
Card has been allowed.

22. Activate the signaling link from step 17 using the **act-slk** command. For example, enter one of these commands.

act-slk:loc=1103:link=a (for the adding a mate linkset example)

act-slk:loc=1107:link=a (for the removing a mate linkset example)

The output confirms the activation.

rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card

23. Change the **open** and **alw** parameter values for all the sockets that were changed in steps 12 or 13 using the **chg-appl-sock** command with the **open=yes** and **alw=yes** parameters. For example, enter this command.

NOTE: If steps 12 and 13 were not performed, skip this step and go to step 24.

chg-appl-sock:sname=kc_hlr1_1103:open=yes:alw=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-SOCK: MASP A - COMPLTD
```

24. Change the **open** and **alw** parameter values for all the associations changed in steps 15 or 16 using the **chg-assoc** command with the **open=yes** and **alw=yes** parameters.

NOTE: If steps 15 and 16 were not performed, skip this step and go to step 25.

chg-assoc:aname=assoc1:open=yes:alw=yes

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```


25. Have the far-end node for the signaling link shown in step 20 perform these actions to place the IP connections on the signaling link into service:


- Place the TALI sockets in the NEA-FEA state.
- Place the M3UAor SUAassociations in the ASP-ACTIVEstate.


26. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
.
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 6-3. Configuring a Mate IPGWx Linkset

















Increasing the System-Wide IPGWx Signaling TPS

This procedure is used with **IPGWx** applications (IP cards running either the **ss7ipgw** or **ipgwi** applications) and increases the system-wide IP transactions per second (TPS), using the **enable-ctrl-feat** command.

The EAGLE 5 ISS is shipped with a default TPS rate of 200 transactions per second.

The **enable-ctrl-feat** command uses these parameters.

:partnum – The Tekelec-issued part number associated with the controlled feature. The part number is a 9-digit number, not including dashes; the first three digits must be 893 (that is, 893xxxxxx, where x is a numeric value). [Table 6-5](#) shows the part numbers that can be used with this procedure.

:fak – The feature access key obtained from the Tekelec. The feature access key contains 13 alphanumeric characters and is not case sensitive.

NOTE 1: The number of system-wide IP transactions per second cannot be enabled with a temporary feature access key.

NOTE: If you do not have the feature access key, you can obtain it from your Tekelec Sales Representative or Account Representative.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent-serial-num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

The TPS rate specified in this procedure must be greater than the current TPS rate.

Table 6-5. System-Wide IPGWx Signaling TPS Part Numbers

Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS
893-0128-01	200		893-0128-21	34,000		893-0128-41	74,000
893-0128-02	400		893-0128-22	36,000		893-0128-42	76,000
893-0128-03	600		893-0128-23	38,000		893-0128-43	78,000
893-0128-04	1,000		893-0128-24	40,000		893-0128-44	80,000
893-0128-05	2,000		893-0128-25	42,000		893-0128-45	82,000
893-0128-06	4,000		893-0128-26	44,000		893-0128-46	84,000
893-0128-07	6,000		893-0128-27	46,000		893-0128-47	86,000
893-0128-08	8,000		893-0128-28	48,000		893-0128-48	88,000
893-0128-09	10,000		893-0128-29	50,000		893-0128-49	90,000

Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS		Part Number	IPGWx System IP TPS
893-0128-10	12,000		893-0128-30	52,000		893-0128-50	92,000
893-0128-11	14,000		893-0128-31	54,000		893-0128-51	94,000
893-0128-12	16,000		893-0128-32	56,000		893-0128-52	96,000
893-0128-13	18,000		893-0128-33	58,000		893-0128-53	98,000
893-0128-14	20,000		893-0128-34	60,000		893-0128-54	100,000
893-0128-15	22,000		893-0128-35	62,000		893-0128-55	102,000
893-0128-16	24,000		893-0128-36	64,000		893-0128-56	104,000
893-0128-17	26,000		893-0128-37	66,000		893-0128-57	106,000
893-0128-18	28,000		893-0128-38	68,000		893-0128-58	108,000
893-0128-19	30,000		893-0128-39	70,000		893-0128-59	110,000
893-0128-20	32,000		893-0128-40	72,000		893-0128-60	112,000

Procedure

1. Display enabled controlled feature information in the database by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012801	on	200
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the IPGWx Signaling TPS quantity is greater than 200, skip steps 2 through 5, and go to step 6. If the **rtrv-ctrl-feat** output shows only the IPGWx Signaling TPS feature with a quantity of 200 and the HC-MIM SLK Capacity feature with a quantity of 64, steps 2 through 5 must be performed.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Increase the system-wide IP transactions per second (TPS) by entering the **enable-ctrl-feat** command with the part number corresponding to the desired quantity (without the dashes), shown in [Table 6-5](#), and the feature access key for the desired quantity.

For example, enter this command.

enable-ctrl-feat:partnum=893012814:fak=<feature access key>

NOTE 1: The number of system-wide IP transactions per second cannot be enabled with a temporary feature access key.

NOTE: If you do not have the feature access key, you can obtain it from your Tekelec Sales Representative or Account Representative.

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP A - COMPLTD
```

7. Verify the new feature information in the database by entering the **rtrv-ctrl-feat** command with the part number specified in step 6.

For this example, enter this command.

rtrv-ctrl-feat:partnum=893012814

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				


The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-4. Increasing the IPGWx Signaling TPS





Configuring the IP TPS Alarm Threshold

The IP TPS alarm threshold is the percentage of the IPGWx signaling TPS at which an alarm is raised. This threshold is set with the **iptpsalmthresh** parameter of the **chg-sg-opts** command. The values for the **iptpsalmthresh** parameter are from 10 to 100 percent, with the system default value of 80 percent. The value of the IP TPS alarm threshold is shown in the **IPTPSALMTHRESH** field of the **rtrv-sg-opts** command output.

When this threshold is exceeded, UAM 0114, System IP TPS Threshold exceeded, is generated. UAM 0114 is automatically cleared when the percentage of the IPGWx signaling TPS calculated by the EAGLE 5 ISS falls below the value of the **iptpsalmthresh** parameter value. UAM 0117, System IP TPS normal, is generated when UAM 0114 is cleared.



CAUTION: UAM 0114 is also generated if the IP TPS alarm threshold is set to a percentage that is less than the current percentage of the IPGWx signaling TPS calculated by the EAGLE 5 ISS. If UAM 0114 is not automatically cleared after performing this procedure, perform the alarm clearing procedure for UAM 0114 in the *Maintenance Manual*.

Procedure

1. Display the current IP options in the database by entering the **rtrv-sg-opts** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
IPTPSALMTHRESH: 80
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

2. Change the IP TPS alarm threshold using the **chg-sg-opts** command and the **iptpsalmthresh** parameter. For this example, enter this command.

chg-sg-opts:iptpsalmthresh=90

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
CHG-SG-OPTS: MASP A - COMPLTD
```



CAUTION: UAM 0114 is generated if the IP TPS alarm threshold is set to a percentage that is less than the current percentage of the IPGWx signaling TPS calculated by the EAGLE 5 ISS. If UAM 0114 is not automatically cleared after performing this procedure, perform the alarm clearing procedure for UAM 0114 in the *Maintenance Manual*.


3. Verify the new IP options in the database using the **rtrv-sg-opts** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
IPTPSALMTHRESH: 90
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-5. Configuring the IP TPS Alarm Threshold

Adding an IPGWx Signaling Link

This procedure is used to add an IPGWx signaling link to the database using the **ent-slk** command with these parameter:

:loc – The card location of the IP card that the IP signaling link will be assigned to. The cards specified by this parameter are IP cards running the SS7IPGW or IPGWI applications.

:link – The signaling link on the card specified in the **loc** parameter.

:lsn – The name of the linkset that will contain the signaling link.

:slc – The signaling link code. The SLC must be unique within the linkset. It must be the same at both the EAGLE 5 ISS location and the distant node.

The **ent-slk** command also contains these parameters, **l2tset**, **l1mode**, **bps**, **tset**, **ecm**, **pcrn1**, **pcrn2**, **lpset**, **atmtsel**, **vci**, **vpi**, **ll**, **e1atmcrc4**, **e1atmsi**, **e1atmsn**, **ts**, **e1port**, **e1loc**, **t1port**, and **t1loc**. These parameters are used only for configuring low-speed, ATM high-speed, E1, and T1 signaling links and are not used in this procedure. For more information on configuring these types of signaling links, see the *Database Administration Manual - SS7*.

The **ent-slk** command also contains the parameter **ipliml2**. This parameter is used only for configuring IPLIMx signaling links and is not used in this procedure. For more information on configuring IPLIMx signaling links, see the [Adding an IPLIMx Signaling Link](#) procedure in [Chapter 3 TALI IPLIMx Configuration Procedures](#) or the [Adding an IPLIMx Signaling Link](#) procedure in [Chapter 5 IETF M2PA Configuration Procedures](#).

These items must be configured in the database before an IP signaling link can be added:

- Shelf – see "Adding a Shelf" in the *Database Administration Manual - System Management*.
- Card – see [Adding an IPGWx Card](#)

- Destination Point Code – see “Adding a Destination Point Code” in the *Database Administration Manual - SS7*.
- Linkset – see [Configuring an IPGWx Linkset](#).

Verify that the link has been physically installed (all cable connections have been made).

To configure the EAGLE 5 ISS to perform circular routing detection test on the signaling links, “Configuring Circular Route Detection” procedure in the *Database Administration Manual - SS7*.

NOTE: Circular route detection is not supported in ITU networks.

To provision a EAGLE 5 ISS with more than 700 signaling links, the EAGLE 5 ISS must have certain levels of hardware installed. See the "Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links" for more information on these hardware requirements.

The EAGLE 5 ISS can contain a mixture of low-speed, E1, T1, ATM high-speed, and IP signaling links. The "Determining the Number of High-Speed and Low-Speed Signaling Links" on this page describes how to determine the quantities of the different types of signaling links the EAGLE 5 ISS can have.

Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links

To provision an EAGLE 5 ISS with more than 700 signaling links (currently the EAGLE 5 ISS can have maximum capacities of 1200, or 1500, or 2000 signaling links), the following additional requirements must be met:

- The Measurements Platform feature must be enabled. Perform these procedures in the *Database Administration Manual - System Management* to enable the Measurements Platform feature:
 - "Adding an MCPM"
 - "Configuring the IP Communications Link for the Measurements Platform"
 - "Adding an FTP Server"
- To provision more than 1200 signaling links, the Large System # Links controlled feature must be enabled for 1500 or 2000 signaling links. For more information on enabling this feature, go to the [Enabling the Large System # Links Controlled Feature](#) procedure.

Determining the Number of High-Speed and Low-Speed Signaling Links

An EAGLE 5 ISS containing either 1200, or 1500, or 2000 signaling links can contain the following quantities of signaling links:

- 180 high-speed ATM signaling links assigned to the ATMANSI application. If there are any high-speed ATM signaling links assigned to the ATMITU application, the maximum number of high-speed ATM signaling links is 115.
- 100 signaling links assigned to either the IPLIM or IPLIMI applications.
- 64 signaling links assigned to either the **ss7ipgw** or **ipgwi** application, or combinations of the **ss7ipgw** and **ipgwi** applications.
- 64 unchannelized E1 signaling links.

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.

- E5-E1T1 running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET running either the **iplimi** or **ipgwi** applications.
- E1-ATM running the **atmitu** application.

Canceling the REPT-STAT-SLK, RTRV-LS, and RTRV-SLK Commands

Because the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands used in this procedure can output information for a long period of time, the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-slk**, **rtrv-ls**, and **rtrv-slk** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered, from another terminal other than the terminal where the **rept-stat-slk**, **rtrv-ls**, or **rtrv-slk** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current signaling link configuration using the **rtrv-slk** command.

This is an example of the possible output.

rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0											
				L2T		L1				PCR	PCR
LOC	LINK	LSN	SLC	TYPE	SET	BPS	MODE	TSET	ECM	N1	N2
1201	B	lsa1	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1203	B	lsa2	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1205	A	lsa3	0	LIMV35	3	64000	DCE	ON	BASIC	---	-----
1207	A	lsn1207a	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1207	B	lsn1207b	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1214	A	lsn1214a	0	LIMV35	2	64000	DTE	---	PCR	76	3800
1214	B	lsa3	1	LIMV35	3	64000	DCE	ON	BASIC	---	-----
				LP		ATM					
LOC	LINK	LSN	SLC	TYPE	SET	BPS	TSEL		VCI	VPI	LL
No Links Set up.											
				LP		ATM				E1ATM	
LOC	LINK	LSN	SLC	TYPE	SET	BPS	TSEL		VCI	VPI	CRC4 SI SN
No Links Set up.											
				IPLIML2							
No Links Set up.											
No Links Set up.											
						L2T		PCR		PCR	E1 E1

```
LOC LINK LSN          SLC TYPE      SET BPS      ECM  N1  N2      LOC PORT TS
No Links Set up.
```

```
LOC LINK LSN          SLC TYPE      L2T      PCR PCR  T1  T1
SET BPS      ECM  N1  N2      LOC PORT TS
```

No Links Set up.

SLK table is (7 of 1200) 1% full.

If the **rtrv-sl** output shows that the maximum number of signaling links is 2000, go to step 2.

If the **rtrv-sl** output shows that the maximum number of signaling links is 1200, and the signaling link being added increases the number beyond 1200, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for either 1500 signaling links or 2000 signaling links. Then go to step 2.

If the **rtrv-sl** output shows that the maximum number of signaling links is 1500, and the signaling link being added increases the number beyond 1500, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for 2000 signaling links. Then go to step 2.

If the addition of the new signaling link will not exceed the maximum number of signaling links, go to step 2.

2. Display the current linkset configuration using the **rtrv-ls** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

```
LSN          APCA  (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
e1e2         001-207-000  none 1 1 no B 6 off off off no off
ls1305       000-005-000  none 1 1 no A 1 off off off no off
ls1307       000-007-000  none 1 1 no A 1 off off off no off
e1m1s1       001-001-001  none 1 1 no A 7 off off off no off
e1m1s2       001-001-002  none 1 1 no A 7 off off off no off
```

```
LSN          APCA  (X25)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
```

```
LSN          APCI  (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
e1e2i        1-207-0      none 1 1 no B 4 off off off --- on
ls1315       0-015-0      none 1 1 no A 1 off off off --- off
ls1317       0-017-0      none 1 1 no A 1 off off off --- on
e1m2s1       1-011-1      none 1 1 no A 7 off off off --- off
e1m2s2       1-011-2      none 1 1 no A 7 off off off --- off
```

```
LSN          APCN  (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
```

```
LSN          APCN24 (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
```

```
LSN (CHINA)  APCN  (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
```

```
LSN (CHINA)  APCN24 (SS7)  SCRNL3T SLT      GWS GWS GWS
SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
```

Link set table is (10 of 1024) 1% full.

If the required linkset is not in the database, perform the [Configuring an IPGWx Linkset](#) to add the linkset to the database.

If you plan to use a linkset shown in this step, go to step 3.

If a new linkset is being added in this step, skip step 3 and go to step 4.

3. Display the linkset that the signaling link is being assigned to using the **rtrv-ls** command, specifying the name of the linkset that the signaling link is being assigned to.

For this example, enter this command.

rtrv-ls:lsn=lsnipgw

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN	APCI	(SS7)	SCRN	L3T	SLT	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsnipgw	2968		none	1	1	no	A		1		off	off	off	---	off
CLLI		TFATCABMLQ		MTPRSE		ASL8		SLSRSB		MULTGC		ITUTFR			
-----		1		no		---		1		yes		off			
IPGWAPC	MATELSN		IPTPS	LSUSEALM		SLKUSEALM		GTTMODE							
yes	-----	10000	70	%	70	%		CdPA							
LOC	LINK	SLC	TYPE	L2T		L1		PCR		PCR					
				SET	BPS	MODE	TSET	ECM	N1	N2					
LOC	LINK	SLC	TYPE	LP		ATM									
				SET	BPS	TSEL		VCI	VPI	LL					
LOC	LINK	SLC	TYPE	LP		ATM									
				SET	BPS	TSEL		VCI	VPI	E1ATM					
LOC	LINK	SLC	TYPE	IPLIML2											
LOC	LINK	SLC	TYPE												
1317	A	0	IPGWI												
LOC	LINK	SLC	TYPE	L2T		PCR		PCR		E1		E1			
				SET	BPS	ECM	N1	N2		LOC		PORT	TS		
LOC	LINK	SLC	TYPE	L2T		PCR		PCR		T1		T1			
				SET	BPS	ECM	N1	N2		LOC		PORT	TS		
SAPCI															
1-10-1															
SAPCN															
1234-aa															
1235-bb															
1200-zz															

Link set table is (13 of 1024) 1% full.

Linksets containing IPGWx signaling links can contain only IPGWx signaling links.

4. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

CARD	TYPE	APPL	LSET NAME	LINK SLC	LSET NAME	LINK SLC
1102	TSM	GLS				
1103	DCM	VXWSLAN				
1113	GSPM	EOAM				
1114	TDM-A					
1115	GSPM	EOAM				
1116	TDM-B					
1117	MDAL					

1201	LIMDS0	SS7ANSI	lsa1	B	0			
1202	LIMV35	SS7ANSI						
1203	LIMDS0	SS7ANSI	lsa2	B	0			
1204	LIMDS0	SS7ANSI						
1205	LIMV35	SS7ANSI	lsa3	A	0			
1206	LIMV35	SS7ANSI						
1207	LIMDS0	SS7ANSI	lsn1207a	A	0	lsn1207b	B	0
1208	LIMDS0	SS7ANSI						
1212	LIMV35	SS7ANSI						
1213	LIMDS0	SS7ANSI						
1214	LIMV35	SS7ANSI	lsn1214a	A	0	lsa3	B	1
1215	LIMDS0	SS7ANSI						
1301	LIMV35	ATMANSI						
1302	LIMATM	ATMANSI						
1304	LIMV35	SS7ANSI						
1305	LIMATM	ATMANSI						
1308	LIMV35	SS7ANSI						
1311	LIMDS0	SS7ANSI						
1313	LIMDS0	SS7ANSI						
1315	LIMV35	CCS7ITU						
1317	LIMV35	CCS7ITU						
1318	LIMATM	ATMANSI						

If the required card is not in the database, perform the [Adding an IPGWx Card](#) procedure and add the IP card to the database.

NOTE 1: If the linkset that the signaling link will be added to contains the **multgc=yes** parameter, the application assigned to the card must be IPGWI.

NOTE: If the IPGWx linkset contains any IPGWx signaling links, skip step 5 and go to step 6.

- If you wish to assign an IPGWx signaling link to a linkset contains no signaling links, but the **IPGWAPC** value is no, perform the “Removing a Linkset Containing SS7 Signaling Links” procedure in the *Database Administration Manual - SS7* and remove the linkset, then perform the [Configuring an IPGWx Linkset](#) procedure and re-enter the new linkset with the **ipgwapc=yes** parameter. Skip steps 6 through 8 and go to step 9.
- If the desired linkset, shown in the **rtrv-ls** output in step 3, has a mate IPGWx linkset assigned, or is the mate to another IPGWx linkset, the desired linkset can contain only one signaling link.

If the desired linkset does not have a mate IPGWx linkset assigned, or is not the mate of another IPGWx linkset, the desired linkset can contain up to 8 IPGWx signaling links. No other signaling link types can be in an IPGWx linkset.

If you wish to assign more than one IPGWx signaling link to an IPGWx linkset that has a mate linkset assigned, the mate to this linkset must be removed. Perform the [Configuring a Mate IPGWx Linkset](#) procedure and remove the mate linkset from the linkset you wish to assign the IPGWx signaling link to. If you do not wish to use this linkset, perform the [Configuring an IPGWx Linkset](#) procedure and add a new IPGWx linkset.

If the desired IPGWx linkset does not have a mate assigned, go to step 8.

If the desired linkset has a mate linkset assigned, and contains an IPGWx signaling link, perform the [Configuring a Mate IPGWx Linkset](#) procedure and add a new IPGWx linkset. Skip steps 7 and 8, and go to step 9.

- If you wish to assign more than one IPGWx signaling link to an IPGWx linkset that is a mate to another IPGWx linkset, this linkset must be removed from the other linkset as a mate.

To verify if the linkset you wish to use is the mate of another IPGWx linkset, enter the **rept-stat-iptps** command to display the names of all the IPGWx linksets. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```


IP TPS USAGE REPORT

	THRESH	CONFIG		TPS	PEAK	PEAKTIMESTAMP

SYSTEM						
RLGHNCXA03W	100%	30000	TX:	7200	7600	05-02-10 11:40:04
			RCV:	7200	7600	05-02-10 11:40:04

LSN						
LSGW1101	80%	6000	TX:	5100	5500	05-02-10 11:40:04
			RCV:	5100	5500	05-02-10 11:40:04
LSGW1103	80%	6000	TX:	5200	5500	05-02-10 11:40:04
			RCV:	5200	5500	05-02-10 11:40:04
LSGW1105	80%	14000	TX:	7300	7450	05-02-10 11:40:04
			RCV:	7300	7450	05-02-10 11:40:04
LSGW1107	70%	4000	TX:	3200	3500	05-02-10 11:40:04
			RCV:	3200	3500	05-02-10 11:40:04

Command Completed.

8. Enter the **rtrv-ls:lsn=<IPGWx linkset name from the rept-stat-iptps output>** to verify if the desired linkset is the mate of another IPGWx linkset.

For this example, enter this command.

rtrv-ls:lsn=lsgw1103

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

LSN	APCA	(SS7)	SCRN	L3T	SLT	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsgw1103	003-002-004		none	1	1	no	A	1	off	off	off	no	off

CLLI			TFATCABMLQ		MTPRSE		ASL8						
-----			1		no		no						

IPGWAPC			MATELSN		IPTPS		LSUSEALM		SLKUSEALM		GTTMODE		
yes			lsgw1107		10000		70		% 70		% CdPA		

LOC	LINK	SLC	TYPE	L2T	SET	BPS	L1	MODE	TSET	ECM	PCR	PCR	
				SET							N1	N2	

LOC	LINK	SLC	TYPE	LP	SET	BPS	ATM	TSEL		VCI	VPI	LL	
				SET									

LOC	LINK	SLC	TYPE	LP	SET	BPS	ATM	TSEL		VCI	VPI	E1ATM	
				SET								CRC4	SI SN

LOC	LINK	SLC	TYPE	IPLIML2									

LOC	LINK	SLC	TYPE	1103 A 0 SS7IPGW									

LOC	LINK	SLC	TYPE	L2T	SET	BPS	ECM	PCR	PCR	E1	E1		
				SET				N1	N2	LOC	PORT	TS	

LOC	LINK	SLC	TYPE	L2T	SET	BPS	ECM	PCR	PCR	T1	T1		
				SET				N1	N2	LOC	PORT	TS	

Link set table is (14 of 1024) 1% full

If the name of the linkset you wish to use is not shown in the **MATELSN** field of the **rtrv-ls** output, repeat this step until all the IPGWx linksets have been displayed, or until a linkset has been found that has the linkset you wish to use assigned as a mate. If the linkset you wish to use is not the mate of another IPGWx linkset, go to step 9.

If the name of the linkset you wish to use is shown in the **MATELSN** field of the **rtrv-ls** output, perform the [Configuring a Mate IPGWx Linkset](#) procedure to remove this linkset from the other linkset as a mate. Then go to step 9.

If the desired linkset is the mate of another IPGWx linkset, and you do not wish to use this linkset, perform the [Configuring an IPGWx Linkset](#) procedure and add a new IPGWx linkset. Then go to step 9.

9. Add the signaling link to the database using the **ent-slk** command. [Table 6-6](#) shows the parameters and values that can be specified with the **ent-slk** command.

Table 6-6. IPGWx Signaling Link Parameter Combinations

IPGWx Signaling Link
:loc = location of the IP card with one of these applications: SS7IPGW or IPGWI; and the DCM card type. ⁶
:link = A
:lsn = linkset name ^{1, 2, 3, 4, 5}
:slc = 0 - 15 ^{4, 5}
Notes: 1. If the multgc=yes parameter is assigned to the linkset, the card's application must be IPGWI. 2. The ipgwapc=yes parameter must be assigned to the linkset. 3. If the card's application is IPGWI, the linkset adjacent point code must be ITU. If the card's application is SS7IPGW, the linkset adjacent point code must be ANSI. The domain of the linkset adjacent point code must be SS7. 4. A linkset can contain only one signaling link assigned to the SS7IPGW or IPGWI applications if the linkset contains a mate IPGWx linkset, or is the mate of an IPGWx linkset. 5. If the linkset does not have a mate IPGWx linkset assigned to it, or is not the mate of an IPGWx linkset, the linkset can contain up to 8 signaling links assigned to the SS7IPGW or IPGWI applications. 6. If the signaling link is being assigned to a single-slot EDCM, to maximize the performance of the IPGWx cards assigned to the linkset, it is recommended that the all signaling links in the linkset are assigned to single-slot EDCMs with part number 870-2372-xx.

For this example, enter these commands.

```
ent-slk:loc=2207:link=a:lsn=lsnlp3:slc=0
```

```
ent-slk:loc=2211:link=a:lsn=lsnlp4:slc=0
```

When each of these commands have successfully completed, this message should appear.

```
r1ghncxa03w 06-10-07 08:29:03 GMT EAGLE5 36.0.0
ENT-SLK: MASP A - COMPLTD
```

10. Verify the changes using the **rtrv-slk** command with the card location and **link** parameter values specified in step 9.

```
rtrv-slk:loc=2207:link=a
```

This is an example of the possible output.

```
r1ghncxa03w 07-05-19 21:17:04 GMT EAGLE5 37.0.0
LOC LINK LSN          SLC TYPE
2207 A    lsnlp3      0  SS7IPGW
```

```
rtrv-slk:loc=2211:link=a
```

This is an example of the possible output.

```
r1ghncxa03w 07-05-19 21:17:04 GMT EAGLE5 37.0.0
```

```
LOC LINK LSN          SLC TYPE
2211 A   lsnlp4       0   IPGWI
```

11. If any cards contain the first signaling link on a card, those cards must be brought into service with the **rst-card** command, specifying the location of the card.

For this example, enter these commands.

```
rst-card:loc=2207
```

```
rst-card:loc=2211
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-23 13:05:05 GMT EAGLE5 36.0.0
Card has been allowed.
```

12. Activate all signaling links on the cards using the **act-slk** command, specifying the card location and **link** parameter value of each signaling link.

For this example, enter these commands.

```
act-slk:loc=2207:link=a
```

```
act-slk:loc=2211:link=a
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:31:24 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

13. Check the status of the signaling links added in step 9 using the **rept-stat-slk** command with the card location and **link** parameter values specified in step 9. The state of each signaling link should be in service normal (IS-NR) after the link has completed alignment (shown in the **PST** field). For this example, enter these commands.

```
rept-stat-slk:loc=2207:link=a
```

This is an example of the possible output.

```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2207,A   lsnlp3   ----- IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```

```
rept-stat-slk:loc=2211:link=a
```


This is an example of the possible output.


```
rlghncxa03w 07-05-23 13:06:25 GMT EAGLE5 37.0.0
SLK      LSN      CLLI      PST      SST      AST
2211,A   lsnlp4   ----- IS-NR      Avail    ----
  ALARM STATUS      =
  UNAVAIL REASON    =
```


14. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-6. Adding an IPGWx Signaling Link









Enabling the Large System # Links Controlled Feature

This procedure is used to enable the Large System # Links controlled feature using the feature's part number and a feature access key.

The feature access key for the Large System # Links controlled feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

This feature allows the EAGLE 5 ISS to contain a maximum of either 1500 or 2000 signaling links.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key generated by Tekelec's feature access key generator, and supplied to you when you purchase or temporarily try a controlled feature. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number associated with the signaling link quantity being enabled:

- 893005901 for the 1500 signaling link quantity
- 893005910 for the 2000 signaling link quantity.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent-serial-num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature is enabled with the **enable-ctrl-feat** command, the feature is also activated. The **chg-ctrl-feat** command is not necessary to activate the feature.

This feature cannot be disabled with the **chg-ctrl-feat** command and the **status=off** parameter.

Hardware Supported for Signaling Link Quantities Greater than 1500

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 card running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET card running either the **iplimi** or **ipgwi** applications.
- E1-ATM card running the **atmitu** application.

To increase the signaling link quantity to more than 1500 signaling links, HIPR cards must be installed into card locations 9 and 10 in each shelf in the EAGLE 5 ISS. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the EAGLE 5 ISS shelves.

Procedure

1. Display the status of the Large System # Links controlled feature by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the **rtrv-ctrl-feat** output shows that the controlled feature is enabled for the desired quantity or for a quantity that is greater than the desired quantity, no further action is necessary. This procedure does not need to be performed.

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, skip steps 2 through 5, and go to step 6.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

```
ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Verify that HIPR cards are installed in card locations 9 and 10 in each shelf of the EAGLE 5 ISS.

NOTE: If the 2000 signaling link quantity is not being enabled in this procedure, skip step 6 and go to step 7.

Enter this command.

rept-stat-gpl:gpl=hipr

This is an example of the possible output.

```
rlghncxa03w 06-10-01 11:40:26 GMT EAGLE5 36.0.0
GPL      CARD      RUNNING      APPROVED      TRIAL
HIPR     1109      126-002-000  126-002-000  126-003-000
HIPR     1110      126-002-000  126-002-000  126-003-000
HIPR     1209      126-002-000  126-002-000  126-003-000
HIPR     1210      126-002-000  126-002-000  126-003-000
HIPR     1309      126-002-000  126-002-000  126-003-000
HIPR     1310      126-002-000  126-002-000  126-003-000
HIPR     2109      126-002-000  126-002-000  126-003-000
HIPR     2110      126-002-000  126-002-000  126-003-000
Command Completed
```

If HIPR cards are installed in each the shelf in the EAGLE 5 ISS, go to step 7.

If HIPR cards are not installed on each shelf in the EAGLE 5 ISS, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 7.

NOTE: Before the 2000 signaling link quantity is enabled, make sure the EAGLE 5 ISS is configured with the signaling link hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section.

If signaling hardware other than the hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section is installed and provisioned, contact the Customer Care Center before enabling the 2000 signaling link quantity. Refer to [Customer Care Center](#) for the contact information.

7. Enable the Large System # Links controlled feature for the desired quantity with the **enable-ctrl-feat** command specifying the part number corresponding to the new quantity of signaling links and the feature access key.

To increase the number of signaling links the EAGLE 5 ISS can contain to 1500, enter this command.

enable-ctrl-feat:partnum=893005901:fak=<feature access key>

To increase the number of signaling links the EAGLE 5 ISS can contain to 2000, enter this command.

enable-ctrl-feat:partnum=893005910:fak=<feature access key>

NOTE 1: A temporary feature access key cannot be specified to enable this feature.

NOTE 2: The values for the feature access key (the fak parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the part number specified in step 7.

If the 1500 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005901

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005901	on	1500

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the 2000 signaling link quantity was enabled in step 7, enter this command.

rtrv-ctrl-feat:partnum=893005910

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005910	on	2000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-7. Enabling the Large System # Links Controlled Feature







Configuring an IP Link

This procedure is used to configure the link parameters for IP cards using the **chg-ip-lnk** command. These link parameters are used to configure the Ethernet hardware.

The **chg-ip-lnk** command uses the following parameters.

:loc – The card location of the IP card.

:port – The Ethernet interface on the IP card, A or B.

:ipaddr – IP address assigned to the Ethernet interface on the IP card. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:submask – The subnet mask of the IP interface. A subnet mask is an IP address with a restricted range of values. The bits in the mask must be a string of one’s followed by a string of zero’s. There must be at least two one’s in the mask, and the mask cannot be all one’s. See [Table 6-7](#) to assign the correct parameter values.

:auto – Tells hardware whether to automatically detect the **duplex** and **speed**.

:duplex – This is the mode of operation of the interface.

:speed – This is the bandwidth in megabits per second of the interface.

:mactype – This is the Media Access Control Type of the interface.

:mcast – The multicast control flag. This parameter enables or disables multicast support for the interface.

A zero **ipaddr** parameter value (**0.0.0.0**) indicates the IP card Ethernet interface to IP link association is disabled. The host to the original IP address must be removed before the **ipaddr=0.0.0.0** can be specified.

If the **defrouter** parameter of the **chg-ip-card** command contains an IP address for the card specified in this procedure, the network portion of one of the IP addresses assigned to the card in this procedure must match the network portion of the IP address specified by the **defrouter** parameter of the **chg-ip-card** command.

The network portion of the IP address is based on the class of the IP address (shown in [Table 6-7](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

If the **auto=yes** parameter is specified, then the **duplex** and **speed** parameters are not allowed.

The **loc** parameter value must be shown in the **rtrv-ip-card** output.

The IP card must be placed out of service.

If either the **ipaddr** or **submask** parameters are specified, then both parameters must be specified. If the **ipaddr** parameter value is zero (**0.0.0.0**), the **submask** parameter is not required.

The IP address and subnet mask values cannot be changed to an address representing a different network if:

- If the network interface specified by the **loc** and **port** parameters has a default router, **dnsa**, or **dsnb** parameter values assigned to it, as shown in the **rtrv-ip-card** output.
- Any IP routes, shown in the **rtrv-ip-rte** output, reference the IP address for the network interface specified by the **loc** and **port** parameters.

The IP link cannot be changed if open sockets or associations reference the IP link being changed.

The network portion of the IP addresses assigned to the IP links on an IP card must be unique. For example, if IP links are assigned to IP card 1103, the network portion of the IP address for Ethernet interface A (**port=a**) must be different from the IP address for Ethernet interface B (**port=b**).

The **submask** parameter value is based upon the **ipaddr** setting. See [Table 6-7](#) for the valid input values for the **submask** and **ipaddr** parameter combinations.

Table 6-7. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0 255.224.0.0 255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.0.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **ipaddr** parameter of the **chg-ip-lnk** command, the subnet address that results from the **ipaddr** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **ipaddr** and **submask** parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Canceling the RTRV-APPL-SOCK and RTRV-ASSOC Commands

Because the **rtrv-appl-sock** and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled and the output

to the terminal stopped. There are three ways that the **rtrv-appl-sock** and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-appl-sock** or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.10   255.255.255.128  HALF    10     802.3    NO    NO
1201  B      -----      -----      HALF    10     DIX      NO    NO
1203  A      192.1.1.12   255.255.255.0   ----    ---     DIX      YES   NO
1203  B      -----      -----      HALF    10     DIX      NO    NO
1205  A      192.1.1.14   255.255.255.0   FULL    100    DIX      NO    NO
1205  B      -----      -----      HALF    10     DIX      NO    NO
2101  A      192.1.1.20   255.255.255.0   FULL    100    DIX      NO    NO
2101  B      -----      -----      HALF    10     DIX      NO    NO
2103  A      192.1.1.22   255.255.255.0   FULL    100    DIX      NO    NO
2103  B      -----      -----      HALF    10     DIX      NO    NO
2105  A      192.1.1.24   255.255.255.0   FULL    100    DIX      NO    NO
2105  B      -----      -----      HALF    10     DIX      NO    NO
2205  A      192.1.1.30   255.255.255.0   FULL    100    DIX      NO    NO
2205  B      -----      -----      HALF    10     DIX      NO    NO
2207  A      192.1.1.32   255.255.255.0   FULL    100    DIX      NO    NO
2207  B      -----      -----      HALF    10     DIX      NO    NO
2213  A      192.1.1.50   255.255.255.0   FULL    100    DIX      NO    NO
2213  B      -----      -----      HALF    10     DIX      NO    NO
2301  A      192.1.1.52   255.255.255.0   FULL    100    DIX      NO    NO
2301  B      -----      -----      HALF    10     DIX      NO    NO
```

NOTE: If the `ipaddr=0.0.0.0` is not being specified in this procedure, skip step 2 and go to step 3.

2. If IP address information is being added or changed (not deleted) in the link parameters, verify that the IP address is present in the IP host table by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1-1201
192.1.1.12    IPNODE1-1203
192.1.1.14    IPNODE1-1205
192.1.1.20    IPNODE2-1201
192.1.1.22    IPNODE2-1203
```

```

192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2

```

```

REMOTE IPADDR  REMOTE HOST
150.1.1.5       NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

```

IP Host table is (11 of 512) 2% full

If the current IP address of the IP link is shown in the **rtrv-ip-host** output, remove the host assigned to the IP address by performing the [Adding an IP Host](#) procedure.

- To change IP link parameters, the signaling link to the IP card and the IP card have to be inhibited. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk: loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE
1201  A    nc001        0  SS7IPGW

```

- Retrieve the status of the signaling link assigned to the IP card to be changed using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output lists the signaling link assigned to this card:

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK  LSN      CLLI      PST      SST      AST
1201,A  nc001  -----  IS-NR
Command Completed.

```

If the signaling link is in service-normal (IS-NR), go to step 5 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 7 to verify the IP card status.

- Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk: loc=1201: link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```

rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.

```

- Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001    -----  OOS-MT-DSBLD  AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS: not aligned
UNAVAIL REASON = NA
Command Completed.
```

7. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST      LS      CLLI
A    IS-NR    nc001    -----
```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 8 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 10 to change the IP link parameters.

8. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

9. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000  DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST      LS      CLLI
A    IS-NR    nc001    -----
```

Command Completed.

NOTE: If the **ipaddr** or **submask** parameter values are not being changed, skip steps 10, 11, and 12, and go to step 13.

10. Display the attributes of the IP card assigned to the IP link being changed by entering the **rtrv-ip-card** command and specifying the card location of the IP link.

For this example, enter this command.

rtrv-ip-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN    -----
```

If the **rtrv-ip-card** output shows an IP address for the default router (**DEFROUTER**) whose network portion matches the network portion of the IP address being changed, go to the [Configuring an IP Card](#) procedure and change the IP address of the default router to **0.0.0.0**.

11. Display any IP routes referencing the IP link being changed by entering the **rtrv-ip-rte** command and specifying the card location of the IP link.

For this example, enter this command.

rtrv-ip-rte:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1201 128.252.10.5    255.255.255.255 140.188.13.33
1201 128.252.0.0      255.255.0.0     140.188.13.34
1201 150.10.1.1       255.255.255.255 140.190.15.3
```

IP Route table is (5 of 1024) 1% full

If the **rtrv-ip-rte** output shows that the card has IP routes assigned to it, go to the [Removing an IP Route](#) procedure and remove the IP routes from the database.

NOTE: If a Class A or C IP address (see [Table 3-3](#)) will be specified for the **ipaddr** parameter in step 15, skip step 12 and go to step 13.

12. The subnet address that results from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 13.

This is an example of the possible output if the E5IS feature is on.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0
```

Choose **ipaddr** and **submask** parameter values for the IP link whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 13.

13. Display the application sockets referencing the local host name that is associated with the IP link being changed by entering the **rtrv-appl-sock** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

NOTE: If the local host was removed in step 2, skip steps 13 and 14, and go to step 15.

For this example, enter this command.

rtrv-appl-sock: lhost="ipnode1-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME kchlrl1201
LINK A
LHOST ipnode1-1201
RHOST kc-hlr1
LPORT 7000 RPORT 7000
SERVER YES DCMPS 1
REXMIT FIXED RTT 60
OPEN YES ALW NO
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

If no sockets are displayed in this step, go to step 14.

If the **rtrv-appl-sock** output shows that the **open** parameter for any sockets is **yes**, perform one of these procedures to change the value of the **open** parameter of the sockets to **no**.

- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)

14. Display the associations referencing the local host name that is associated with the IP link being changed by entering the **rtrv-assoc** command and specifying the local host name shown in the **rtrv-ip-host** output in step 2.

For this example, enter this command.

rtrv-assoc: lhost="ipnode-1201"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME LOC PORT LINK ADAPTER LPORT RPORT OPEN ALW
swbel32 1201 A A M3UA 1030 2345 YES YES
```

IP Appl Sock/Assoc table is (3 of 4000) 1% full

Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1201

If no associations are displayed in this step, go to step 15.

If the **rtrv-assoc** output shows that the **open** parameter for any associations is **yes**, perform one of these procedures to hange the value of the **open** parameter the associations to **no**.

- [Changing an M2PA Association](#)

- [Changing an M3UA or SUA Association](#)

15. Change the link parameters associated with the IP card in the database using the **chg-ip-lnk** command. For this example, enter this command.

```
chg-ip-  
lnk:loc=1201:port=a:ipaddr=192.1.1.10 :submask=255.255.255.0:auto=yes:m  
actype=dix
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0  
CHG-IP-LNK: MASP A - COMPLTD
```

16. Verify the new link parameters associated with the IP card that was changed in step 15 by entering the **rtrv-ip-lnk** command with the card location specified in step 15.

For this example, enter this command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0  
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST  
1201  A    192.1.1.10      255.255.255.128  HALF    10     DIX      YES  NO  
1201  B    -----          -----          HALF    10     DIX      NO   NO
```

17. Allow the IP card that was inhibited in step 8 by using by using the **alw-card** command.

NOTE: If step 8 was not performed, skip steps 17 and 18, and go to step 19.

For example, enter this command.

```
alw-card:loc=1201
```

This message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0  
Card has been allowed.
```

18. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command. For example, enter this command.

```
rept-stat-card:loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0  
CARD  VERSION  TYPE  APPL  PST  SST  AST  
1201  114-000-000  DCM   SS7IPGW  IS-NR  Active  ----  
ALARM STATUS      = No Alarms.  
BPDCM GPL         = 002-102-000  
IMT BUS A         = Conn  
IMT BUS B         = Conn  
SIGNALING LINK STATUS  
SLK   PST      LS      CLLI  
A     IS-NR    nc001  -----
```

Command Completed.

NOTE: If step 5 was not performed, skip steps 19 and 20, and go to step 21.

19. Activate the signaling link from step 5 using the **act-slk** command.

For example, enter this command.

```
act-slk:loc=1201:link=a
```


The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

20. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command. For example, enter this command.

rept-stat-slk:loc=1201:link=a

This message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----  IS-NR
Command Completed.
```

21. Perform the [Configuring an IP Card](#) procedure and change the IP address of the default router to a non-zero value, where the network portion of the default router IP address matches the network portion of the IP link's new IP address.

NOTE 1: If the `ipaddr` or `submask` values were not changed, skip steps 21 and 22, and go to step 23.

NOTE: If the IP address of the default router was not changed to 0.0.0.0 in step 10, skip step 21, and go to step 22.

22. Perform the [Adding an IP Route](#) procedure and add the IP routes back into the database.

NOTE: If IP routes were not removed in step 11, skip step 22, and go to step 23.

23. Perform one of these procedures as necessary and change the value of the **open** parameter of either the application socket or the association to **yes**.

NOTE: If the `open` parameter value for either an application socket or an association was not changed in either steps 13 or 14, skip step 23, and go to step 24.


- [Changing the Attributes of a Socket on an IPLIMx Signaling Link](#)
- [Changing the Attributes of a Socket on an IPGWx Signaling Link](#)
- [Changing an M2PA Association](#)
- [Changing an M3UA or SUA Association](#)


24. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 6-8. Configuring an IP Link




















Adding an IP Host

This procedure associates hostnames with IP addresses using the **ent-ip-host** command.

The **ent-ip-host** command uses the following parameters.

:host– The host name to be associated with the IP address. This parameter identifies the logical name assigned to the device with the IP address indicated. The host name can contain up to 60 characters (using only these characters: a-z, A-Z, 0-9, -, .) and is not case sensitive. The host name must begin with a letter. Host names containing a dash (-) must be enclosed in double quotes.

:ipaddr – The IP address to be associated with the hostname. The node’s IP address. This is an IP address expressed in standard “dot notation.” IP addresses consist of the system’s network number and the machine’s unique host number.

:type – Specifies if the host resides on the IP card on the EAGLE 5 ISS (**type=local**, the default value), or if the host resides on equipment that is not in the EAGLE 5 ISS (**type=remote**). This parameter is optional.

The IP address for a local host must be shown in the **rtrv-ip-lnk** output.

The IP address for a remote host must not be shown in the **rtrv-ip-lnk** output.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
```

```
REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (10 of 512) 2% full

2. Verify that the IP address assigned to the IP links by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201 A    192.1.1.10  255.255.255.128 HALF    10     802.3    NO    NO
1201 B    -----    -----    HALF    10     DIX      NO    NO
1203 A    192.1.1.12  255.255.255.0   ----    ---    DIX      YES   NO
1203 B    -----    -----    HALF    10     DIX      NO    NO
1205 A    192.1.1.14  255.255.255.0   FULL    100    DIX      NO    NO
1205 B    -----    -----    HALF    10     DIX      NO    NO
2101 A    192.1.1.20  255.255.255.0   FULL    100    DIX      NO    NO
2101 B    -----    -----    HALF    10     DIX      NO    NO
2103 A    192.1.1.22  255.255.255.0   FULL    100    DIX      NO    NO
2103 B    -----    -----    HALF    10     DIX      NO    NO
2105 A    192.1.1.24  255.255.255.0   FULL    100    DIX      NO    NO
2105 B    -----    -----    HALF    10     DIX      NO    NO
2207 A    192.1.1.32  255.255.255.0   FULL    100    DIX      NO    NO
2207 B    -----    -----    HALF    10     DIX      NO    NO
2213 A    192.1.1.50  255.255.255.0   FULL    100    DIX      NO    NO
2213 B    -----    -----    HALF    10     DIX      NO    NO
2301 A    192.1.1.52  255.255.255.0   FULL    100    DIX      NO    NO
2301 B    -----    -----    HALF    10     DIX      NO    NO
```

If a local host is being configured in this procedure, the IP address assigned to the local host must be shown in the **rtrv-ip-lnk** output. If the IP address is not shown in the **rtrv-ip-lnk** output, add the IP address by performing the [Configuring an IP Link](#) procedure.

If a remote host is being configured in this procedure, the IP address assigned to the remote host cannot be shown in the **rtrv-ip-lnk** output.

3. Add IP host information to the database by entering the **ent-ip-host** command.

If a local host is being configured, enter the **ent-ip-host** command with the IP address from step 2, and the **type=local** parameter or without the **type** parameter. If the **type** parameter is not specified with the **ent-ip-host** command, the **type** parameter value defaults to **local**.

If a remote host is being configured, enter the **ent-ip-host** command with the IP address that is not shown in step 2, and the **type=remote** parameter.

For example, enter this command.

```
ent-ip-host:host="kc-hlr1":ipaddr=192.1.1.30
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
ENT-IP-HOST: MASP A - COMPLTD
```

4. Verify the new IP host information in the database by entering the **rtrv-ip-host** command with the **host** parameter value specified in step 3.

For this example, enter this command.

```
rtrv-ip-host:host="kc-hlr1"
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOCAL IPADDR      LOCAL HOST
192.1.1.30        KC-HLR1
```


```
IP Host table is (11 of 512) 2% full
```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-9. Adding an IP Host



Configuring an IP Card

This procedure is used to change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

The **chg-ip-card** command uses the following parameters.

:loc – The card location of the IP card

:srchordr – Host Table Search Order

:dnrsa – Domain name server A's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:dnrsb – Domain name server B's IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:domain – The domain name is used to construct a fully-qualified DNS name consisting of 120 characters or less. For example, a domain name can be **tekelec.com**, the hostname is **john.doe**. The fully-qualified DNS name would be **john.doe@tekelec.com**.

:defrouter – Default router IP address. This is an IP address expressed in standard "dot notation." IP addresses consist of the system's network number and the machine's unique host number.

:rstdomain – Reset Domain name. The parameter is used to reset the domain to a NULL value.

The IP card must be placed out of service.

The **rstdomain** parameter cannot be specified if the **domain** parameter is specified.

There is only one default router (**defrouter** parameter) for each IP card. The default router is used as the primary route unless a static IP routes is defined for the destination IP address. Static IP routes are assigned using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure.

The network portion of the IP address of the default router must match the network portion of one of the IP addresses assigned to the card.

The network portion of the IP address is based on the class of the IP address (shown in [Table 6-7](#)). If the IP address is a Class A IP address, the first field is the network portion of the IP address. If the IP address is a Class B IP address, the first two fields are the network portion of the IP address. If the IP address is a Class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address is 193.5.207.150, a Class C IP address, the network portion of the IP address is 193.5.207.

The default router can be associated with only one IP address assigned to the card if the defrouter parameter is specified. For example, the **dnrsa** value for card 1101 is 150.1.1.10. The **dnrsb** value for card 1101 is 160.25.37.1. A default router is provisioned with the IP address 150.1.1.4. The default router is associated with the Ethernet A IP address (the **dnrsa** parameter value), but not the Ethernet B IP address (the **dnrsb** parameter value).

If the default router is associated with one of the IP card's IP addresses, a second gateway router can be assigned to the other IP address on the IP card by provisioning a static IP route for the IP card using the **ent-ip-rte** command in the [Adding an IP Route](#) procedure. Static IP routes can provide gateway routers associated with the other IP address on the IP card. To provision the gateway router (the **gtwy** parameter of the **ent-ip-rte** command) for the other IP address assigned to the IP card, the network portion of the gateway router's IP address must match the network portion of the other IP address assigned to the IP card.

Specifying the IP address 0.0.0.0 for the **dnrsa** or **dnrsb** parameters, removes the IP address for Ethernet A (**dnrsa**) or Ethernet B (**dnrsb**).

When an IP card is entered into the database with the **ent-card** command, the IP stack parameters associated with this card are initially set with these default values:

- **:srchordr** – SRVR
- **:dnsc** – No DNSA IP address is specified
- **:dnscb** – No DNSB IP address is specified
- **:domain** – No domain name is specified
- **:defrouter** – No default router IP address is specified
- **:rstdomain** – No

The value of any optional parameter not specified with the **chg-ip-card** command is not changed.

Procedure

1. Display the current IP parameters associated with card in the database by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN     -----

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM
```

To change the parameters of an IP card, the signaling link to the card and the card have to be inhibited.

2. Display the signaling link associated with the card shown in step 1 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE
1201  A    nc001        0  SS7IPGW
```

3. Retrieve the status of the signaling link shown in step 2 using the **rept-stat-slk** command specifying the card location and signaling link.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----  IS-NR
        Avail     ----
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 4 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 4 and 5, and go to step 6 to verify the card status.

4. Deactivate the signaling link assigned to the IP card using the **rept-stat-slk** command.

For example, enter this command.

dact-slk:loc=1201:link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

5. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----  OOS-MT-DSBLD  AVAIL  ---
ALARM STATUS = * 0236 REPT-LKS:not aligned
UNAVAIL REASON = NA
Command Completed.
```

6. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card:loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD VERSION  TYPE  APPL  PST  SST  AST
1201 114-000-000 DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS   = No Alarms.
BPDCM GPL      = 002-102-000
IMT BUS A      = Conn
IMT BUS B      = Conn
SIGNALING LINK STATUS
SLK  PST  LS  CLLI
A    IS-NR  nc001  -----
```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 7 to inhibit the card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), skip steps 7 and 8, and go to step 9.

7. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

8. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1201  114-000-000    DCM       SS7IPGW   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----
```

Command Completed.

NOTE: If the defrouter parameter is not specified in step 10, skip step 9 and go to step 10.

9. Verify that the IP address of either Ethernet A or B (the address whose network portion matches the network portion of the **defrouter** parameter value to be used in step 10) is in the IP link table by entering the **rtrv-ip-lnk** command with the card location specified in this procedure.

For this example, enter this command.

rtrv-ip-lnk: loc=1201

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A     192.1.1.10   255.255.255.0  ----   ---   DIX      YES   NO
1201  B     -----      -----      ----   ---   DIX      YES   NO
```

If the network portion of the IP address specified by the **defrouter** value does not match the network portions of either IP address displayed in this step, perform one of these actions:

- Choose another value for the **defrouter** parameter, making sure that the network portion of the new IP address matches the network portion of one of the IP addresses displayed in this step.
- Perform the [Configuring an IP Link](#) procedure and change one of the IP addresses shown in this step so that the network portion of the new IP address changed in the [Configuring an IP Link](#) procedure matches the network portion of the IP address value for the **defrouter** parameter.

10. Change the IP stack parameters associated with an IP card in the database using the **chg-ip-card** command.

For this example, enter this command.

```
chg-ip-card: loc=1201:srchordr=local:dnsa=192.1.1.40 :domain=nc.tekelec.com
```


When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
CHG-IP-CARD: MASP A - COMPLTD
```

11. Verify the new IP parameters associated with the IP card that was changed in step 10 by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN    NC. TEKELEC. COM
```

NOTE: If step 7 was not performed, skip steps 12 and 13, and go to step 14.

12. Allow the IP card that was inhibited in step 7 by using the **alw-card** command.

For example, enter this command.

alw-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

13. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1201  114-000-000 DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK  PST  LS  CLI
A    IS-NR  nc001  -----
```

Command Completed.

NOTE: If step 4 was not performed, skip steps 14 and 15, and go to step 16.

14. Activate the signaling link from step 4 using the **act-sl** command.

For example, enter this command.

act-slk:loc=1201:link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the in-service normal (IS-NR) status of the signaling link using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk:loc=1201:link=a


This message should appear.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1201,A   nc001     -----   IS-NR
          Avail     ----
Command Completed.
```


16. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-10. Changing an IP Card





Adding an IP Route

This procedure is used to add an IP route to the database using the **ent-ip-rte** command.

The **ent-ip-rte** command uses these parameters.

:loc – The location of the IP card that the IP route will be assigned to.

:dest – The IP address of the remote host or network.

:submask – The subnet mask of the destination IP address.

:gtwy – The IP address of the gateway or router that will send the IP data to its final destination.

There can be a maximum of 64 IP routes assigned to an IP card.

The EAGLE 5 ISS can contain a maximum of 1024 IP routes.

Ethernet Interfaces A and B on the IP card specified by the **loc** parameter can be used.

The network portion of the IP address value of the **gtwy** parameter must be the same as the network portion of the IP addresses shown for either the A or B interfaces in the **rtrv-ip-card** output.

The value of the **dest** and **gtwy** parameters cannot be 127.x.x.x (the loopback address), 0.0.0.0, or the IP addresses of the A or B interfaces on the IP card, and cannot be assigned to another IP card.

If the **dest** parameter value represents a host IP address, the value for the **submask** parameter must be 255.255.255.255. Otherwise, the **submask** parameter value identifies the network/host ID portions that must be entered when the dest parameter value represents a network address.

The submask is applied to the IP address which is being routed to see if it yields a route match. For example, if IP address 192.1.1.2 is being routed and the IP routing table contains these entries.

Table 6-8. Sample IP Routing Table

IP address	Submask	Gateway
191.1.0.0	255.255.0.0	192.168.110.250
192.0.0.0	255.0.0.0	192.168.110.251

IP routing occurs as follows:

1. The subnet mask of route 1 (255.255.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.1.0.0. IP address 192.1.0.0 does not match IP address 191.1.0.0 in the IP routing table, so the next route is chosen.
2. The subnet mask of route 2 (255.0.0.0) is applied to the IP address being routed (192.1.1.2) with the resulting IP address of 192.0.0.0 which matches the second route in the IP routing table, so this route is selected for routing this datagram.

See [Table 6-9](#) for the valid input values for the **submask** and **dest** parameter combinations.

Table 6-9. Valid Subnet Mask Parameter Values

Network Class	IP Network Address Range	Valid Subnet Mask Values
A	1.0.0.0 to 127.0.0.0	255.0.0.0 (the default value for a class A IP address) 255.192.0.0 255.224.0.0

Network Class	IP Network Address Range	Valid Subnet Mask Values
		255.240.0.0 255.248.0.0 255.252.0.0 255.254.0.0 255.255.128.1
A+B	128.1.0.0 to 191.255.0.0	255.255.0.0 (the default value for a class B IP address) 255.255.192.0 255.255.224.0 255.255.240.0 255.255.248.0 255.255.252.0 255.255.254.0 255.255.255.128
A+B+C	192.0.0.0 to 223.255.255.0	255.255.255.0 (the default value for a class C IP address) 255.255.255.192 255.255.255.224 255.255.255.240 255.255.255.248 255.255.255.252

If a Class B IP address is specified for the **dest** parameter of the **ent-ip-rte** command, the subnet address that results from the **dest** and **submask** parameter values cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. The **pvn** and **pvnmask** parameter values can be verified by entering the **rtrv-netopts** command. Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1301 128.252.10.5     255.255.255.255 140.188.13.33
1301 128.252.0.0       255.255.0.0      140.188.13.34
1301 150.10.1.1        255.255.255.255 140.190.15.3
1303 192.168.10.1      255.255.255.255 150.190.15.23
1303 192.168.0.0       255.255.255.0    150.190.15.24
```

IP Route table is (5 of 1024) 1% full

2. Display the IP cards in the database with the **rtrv-ip-card** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1212
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER 150.1.1.100
  DOMAIN     NC. TEKELEC. COM

LOC 1301
  SRCHORDR  SRVRONLY
  DNSA      140.188.13.10
  DNSB      140.190.15.28
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM

LOC 1303
  SRCHORDR  LOCAL
  DNSA      150.190.15.1
  DNSB      -----
  DEFROUTER 150.190.15.25
  DOMAIN     NC. TEKELEC. COM

```

If the required IP card is not shown in the **rtrv-ip-card** output, perform the [Adding an IPGWx Card](#) to add the card to the database.

Perform the [Configuring an IP Card](#) and make sure that the network portion of the IP addresses assigned for the A or B interfaces of the IP card is the same as the network portion of the IP address that will be assigned to the **gtwy** parameter of the IP route

NOTE: If a Class A or C IP address (see [Table 5-5](#)) will be specified for the **dest parameter in step 4, skip step 3 and go to step 4.**

3. The subnet address that results from the **dest** and **submask** parameter values of the **ent-ip-rte** command cannot be the same as the subnet address that results from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command.

Display the **pvn** and **pvnmask** parameter values of the **chg-netopts** command by entering the **rtrv-netopts** command.

If error message **E3967 Cmd Rej: E5IS must be on** is displayed after the **rtrv-netopts** command is executed, the **pvn** and **pvnmask** parameters are not configured. Go to step 4.

This is an example of the possible output if the E5IS feature is on.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
NETWORK OPTIONS
-----
PVN      = 128.20.30.40
PVNMASK  = 255.255.192.0

```

Choose **dest** and **submask** parameter values for the IP route whose resulting subnet address is not be the same as the subnet address resulting from the **pvn** and **pvnmask** parameter values of the **chg-netopts** command. Go to step 4.

4. Add the IP route to the database using the **ent-ip-rte** command.

For this example, enter this command.

```

ent-ip-
rte:loc=1212:dest=132.10.175.20:submask=255.255.255.255 :gtwy=150.1.1.5
0

```

When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command with the card location specified with the **ent-ip-rte** command in step 4.

For this example, enter these commands.

rtrv-ip-rte:loc=1212

This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20  255.255.255.255 150.1.1.50
IP Route table is (6 of 1024) 1% full
```


6. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-11. Adding an IP Route





Adding an M3UA or SUA Association

This procedure is used to configure M3UA or SUA associations using the **ent-assoc** command. The combination of a local host, local SCTP port, remote host and remote SCTP port defines an association.

The **ent-assoc** command uses these parameters:

:aname – The name assigned to the association. Valid association names can contain up to 15 alphanumeric characters where the first character is a letter and the remaining characters are alphanumeric characters. The **aname** parameter value is not case-sensitive.

:lhost – Local Hostname. The logical name assigned to the local host device.

:lport – The SCTP port number for the local host.

:rhost – Remote Hostname. The logical name assigned to the remote host device.

:rport – The SCTP port number for the remote host.

:link – The signaling link on the IP card. The value for the link parameter for M3UA or SUA associations is A.

NOTE: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

:adapter – The adapter layer for this association, either **m3ua** or **sua**. The **adapter** parameter is optional. The default value for the **adapter** parameter is **m3ua**.

:alhost – The alternate local host name.

The **adapter=m2pa** and **m2patset** parameters can be used only when configuring M2PA associations. Perform the “Adding an M2PA Association” procedure on page 5-66 to configure M2PA associations.

The socket table, which contains both the socket and association data, contains fields whose values are not assigned using the **ent-assoc** command. When an association is added to the database, these fields receive their default values. If a different value is desired, the **chg-assoc** command must be used. To change these values perform the [Changing an M3UA or SUA Association](#) procedure.

These fields and their default values are:

open=no	rmax=800	cwmin=3000	alw=no	uaps=10
istrms=2	rmode=lin	rtimes=10	ostrms=2	rmin=120
bufsize=16	rtxthr=0			

The **ver** parameter can be used only when configuring M2PA associations. Perform the [Changing an M2PA Association](#) procedure to use the **ver** parameter value.

The size of the buffers on the single-slot EDCMs and E5-ENET cards are shown in the following list.

- Single-Slot EDCM - 800 kB
- E5-ENET Card - 3200 kB

The size of the buffers assigned to each association that is assigned to the IP card cannot exceed the maximum buffer size for the IP card. When a new association is added, the default buffer size for the association is assigned to the association. If adding the new association causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **ent-assoc** command will be rejected. If the you wish to add the association and the maximum buffer size for the IP card will be exceeded, the buffer size of the other associations assigned to the IP card must be decreased by performing the [Changing an M3UA or SUA Association](#) procedure. The available size of the buffers on the IP card can be verified by entering this command.

rtrv-assoc:lhost=<local host name assigned to the association being changed>

The **alhost** parameter can also be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card.

The **aname** parameter can be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card and the size of the buffer assigned to the association.

The value of the **lhost**, **rhost**, or **alhost** parameters is a text string of up to 60 characters, with the first character being a letter. The command line on the terminal can contain up to 150 characters. If the host names are too long to fit on the **ent-assoc** command line, go to the [Changing an M3UA or SUA Association](#) procedure to complete the entry of the host names.

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

The B Ethernet interface of the IP card can be used on the single-slot EDCM or E5-ENET card.

If the association is to be activated in this procedure, with the **chg-assoc** command, the association must contain values for the **lhost**, **lport**, **rhost**, **rport** parameters.

The signaling link being assigned to the association must be in service. This state is shown in the **rept-stat-slk** output with the entries **IS-NR** in the **PST** field and **Avail** in the **SST** field.

Uni-homed endpoints are associations configured with the **lhost** parameter only. The **lhost** parameter value represents an IP address that corresponds to either the A or B network interface of the IP card. Multi-homed

endpoints are associations configured with both the **lhost** and **alhost** parameters. The **lhost** parameter value represents an IP address corresponding to one of the network interfaces (A or B) of the IP card while the **alhost** parameter value represents an IP address corresponding to the other network interface of the same IP card.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command. This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
swbel32    1201 A      A    M3UA  1030  2345 YES YES
a2         1305 A      A    SUA   1030  2345 YES YES
a3         1307 A      A    SUA   1030  2346 YES YES
assoc3     1203 A      A1   M2PA  2048  1030 NO  NO
```

NOTE: If the required IP link is shown in the rtrv-assoc output in step 1, skip step 2 and go to step 3.

2. Display the IP links in the database by entering the **rtrv-ip-lnk** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201 A    192.1.1.10  255.255.255.128 HALF    10     802.3    NO    NO
1201 B    -----  -----  HALF    10     DIX      NO    NO
1203 A    192.1.1.12  255.255.255.0   ----    ---     DIX      YES   NO
1203 B    -----  -----  HALF    10     DIX      NO    NO
1205 A    192.1.1.14  255.255.255.0   FULL    100    DIX      NO    NO
1205 B    -----  -----  HALF    10     DIX      NO    NO
2101 A    192.1.1.20  255.255.255.0   FULL    100    DIX      NO    NO
2101 B    -----  -----  HALF    10     DIX      NO    NO
2103 A    192.1.1.22  255.255.255.0   FULL    100    DIX      NO    NO
2103 B    -----  -----  HALF    10     DIX      NO    NO
2105 A    192.1.1.24  255.255.255.0   FULL    100    DIX      NO    NO
2105 B    -----  -----  HALF    10     DIX      NO    NO
2205 A    192.1.1.30  255.255.255.0   FULL    100    DIX      NO    NO
2205 B    -----  -----  HALF    10     DIX      NO    NO
2207 A    192.1.1.32  255.255.255.0   FULL    100    DIX      NO    NO
2207 B    -----  -----  HALF    10     DIX      NO    NO
2213 A    192.1.1.50  255.255.255.0   FULL    100    DIX      NO    NO
```

```

2213 B ----- HALF 10 DIX NO NO
2301 A 192.1.1.52 255.255.255.0 FULL 100 DIX NO NO
2301 B ----- HALF 10 DIX NO NO

```

If the required IP link is not in the database, add the IP link using the [Configuring an IP Link](#) procedure.

3. Verify that the local host name to be assigned to the association is in the database by using the **rtrv-ip-host** command. The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

```

IP Host table is (11 of 512) 2% full

The IP address of the IP link should be assigned to the local host name that will be assigned to the association.

The values of the **lhost** and **ahost** parameters must be in the **LOCAL HOST** column in the **rtrv-ip-host** output.

If the required hostname is not in the database, add the IP host name using the [Adding an IP Host](#) procedure.

4. Display the application running on the IP card shown in either step 1 or step 2 using the **rept-stat-card** command specifying the location of the IP card. For this example, enter this command.

rept-stat-card:loc=1305

This is an example of the possible output.

```

rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION    TYPE    APPL    PST        SST        AST
1305  114-000-000  DCM     SS7IPGW  IS-NR      Active     -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK    PST        LS        CLLI
A      IS-NR      e5e6a     -----

```

Command Completed.

NOTE: If a new IP host was added in step 3, skip step 5 and go to step 6.

5. Verify the available buffer size for the IP card that will contain the association being added in this procedure by entering the **rtrv-assoc** command with the local host name assigned to the association being added. For this example, enter this command.

rtrv-assoc:lhost="IPNODE2-1305"

This is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD IPLNK

```

ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW
a2	1305	A	A	SUA	1030	2345	YES	YES

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1305

If adding the new association causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **ent -assoc** command will be rejected.

The default buffer value for an M3UA or SUA association is 16.

If the you wish to add the association and the maximum buffer size for the IP card will be exceeded, the buffer size of the other associations assigned to the IP card must be decreased by performing the [Changing an M3UA or SUA Association](#) procedure.

6. Add the associations using the **ent -assoc** command. For this example, enter these commands.

```
ent -assoc : aname=assoc1 : lhost=gw105.nc.tekelec.com : lport=1030 :  
rhost=gw100.nc.tekelec.com : rport=1030 : adapter=m3ua : link=a
```

NOTE 1: The **port** parameter can be used in place of the **link** parameter to specify the signaling link on the card.

NOTE: See [Flowchart 5-47](#) (Sheet 3) for the rules that apply to the **ent -assoc** command.

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
ENT-ASSOC: MASP A - COMPLTD
```

NOTE: If the association added in step 6 is not being activated in this procedure, skip step 7 and go to step 8.

7. Activate the association added in step 6 by entering the **chg -assoc** command with the association name specified in step 6 and the **open=yes** and **alw=yes** parameters. For example, enter this command.

```
chg -assoc : aname=assoc1 : open=yes : alw=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0  
CHG-ASSOC: MASP A - COMPLTD
```

8. Verify the changes using the **rtrv -assoc** command specifying the association name specified in steps 6 and 7. For this example, enter these commands.

```
rtrv -assoc : aname=assoc1
```

This is an example of possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
ANAME assoc1  
LOC 1305 IPLNK PORT A LINK A  
ADAPTER M3UA VER M3UA RFC  
LHOST gw105.nc.tekelec.com  
ALHOST ---  
RHOST gw100.nc.tekelec.com  
LPORT 1030 RPORT 1030  
ISTRMS 2 OSTRMS 2 BUFSIZE 16  
RMODE LIN RMIN 120 RMAX 800  
RTIMES 10 CWMIN 3000 UAPS 10  
OPEN YES ALW YES RTXTHR 0
```


IP Appl Sock table is (5 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1305


9. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-12. Adding an M3UA or SUA Association







Adding a New Association to a New Application Server

This procedure is used to create a new application server and assign a new association to the application server using the **ent-as** command.

The **ent-as** command uses these parameters:

:asname – The name of the new application server. The name of the application server can contain up to 15 alphanumeric characters, with the first character being an alphabetic character. Application server names are not case sensitive.

:aname – The name of the association being assigned to the application server.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 12 TALI sockets, the maximum number of SCTP association to application server assignments that the IPGWx card can support is 38. The SCTP association to application server assignments could be one SCTP association assigned to 38 application servers, two SCTP associations assigned to 19 application servers, or any combination of SCTP associations assigned to application servers that add up to 38. The number of TALI sockets can be verified with the **rtrv-appl-sock:lhost=<local host name>** command. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** and **rtrv-as:aname=<association name>** commands.

Table 6-10. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50
25	2	0	50
0	0	50	50
38	1	12	50
19	2	12	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

The **open** parameter of the association must be set to **no** before the association can be assigned to the application server. This can be verified with the **rtrv-assoc** command.

M2PA associations (**adapter=m2pa**) cannot be assigned to application servers. Only M3UA (**adapter=m3ua**) and SUA (**adapter=sua**) associations can be assigned to application servers. This can be verified in the **ADAPTER** field in the **rtrv-assoc** output.

The application server recovery timer (the **tr** parameter of the **chg-as** command) for the application server is set by default to 10 milliseconds when an application server is added. The traffic mode (the **mode** parameter of the **chg-as** command) for the application server is set by default to **LOADSHARE** when an application server is added. Perform the [Changing an Application Server](#) procedure to change these parameter values.

Canceling the RTRV-AS, RTRV-APPL-SOCK, and RTRV-ASSOC Commands

Because the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the application servers in the database using the **rtrv-as** command. This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name           Mode      Tr ms   Association Names
as1                LOADSHARE 10      a2
                  a3
                  assoc1

as2                OVERRIDE 10      assoc7
as3                OVERRIDE 10      swbel32

AS table is (3 of 250) 1% full.
```

2. Display the associations in the database using the **rtrv-assoc** command. This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

CARD IPLNK
ANAME  LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
swbel32 1201 A    A    M3UA 1030 2345 YES YES
a2      1305 A    A    SUA 2000 2345 YES YES
a3      1307 A    A    SUA 3000 3000 YES YES
assoc1  1305 A    A    SUA 4000 1030 YES YES
assoc7  1311 A    A    SUA 2500 2000 YES YES
```

3. Display the IP host names in the database by using the **rtrv-ip-host** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1-1201
192.1.1.12    GW105. NC. TEKELEC. COM
192.1.1.14    IPNODE1-1205
192.1.1.20    IPNODE2-1201
192.1.1.22    IPNODE2-1203
```

```
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
```

```
REMOTE IPADDR  REMOTE HOST
150.1.1.5       NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (11 of 512) 2% full

If the IP host name for the new association is not shown in the **LOCAL HOST** column of the **rtrv-ip-host** output, add the IP host name by performing the [Adding an IP Host](#) procedure. Then go to step 6.

If the IP host name for the new association is shown in the **LOCAL HOST** column of the **rtrv-ip-host** output, go to step 4.

4. Display the sockets assigned to the local host value that will be assigned to the association being configured in this procedure by entering the **rtrv-appl-sock** command with the **lhost** parameter. For this example, enter this command.

rtrv-appl-sock: lhost="IPNODE2-1205"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME sock1
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost1
LPORT     1024      RPORT     2048
SERVER    YES       DCMPS     10
REXMIT    FIXED     RTT        60
OPEN      YES       ALW        YES

SNAME sock2
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost2
LPORT     2000      RPORT     2000
SERVER    YES       DCMPS     10
REXMIT    FIXED     RTT        60
OPEN      YES       ALW        YES

IP Appl Sock/Assoc table is (8 of 4000) 1% full
```

5. Display the associations assigned to the local host value that will be assigned to the association being configured in this procedure by entering the **rtrv-assoc** command with the **lhost** parameter. For this example, enter this command.

rtrv-assoc: lhost="IPNODE2-1205"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME    LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
a2        1205 A    A    SUA    2000  2048  YES  YES
a3        1205 A    A    SUA    3000  3000  YES  YES

IP Appl Sock/Assoc table is (8 of 4000) 1% full
Assoc Buffer Space Used (32 KB of 3200 KB) on LOC = 1205
```

6. Display the application servers that the associations shown in step 5 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 5. For this example, enter these commands.

rtrv-as: aname=a2

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE  2000      a2
AS Table is (3 of 250) 1% full
```

rtrv-as:aname=a3

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as2          LOADSHARE  2000      a3
AS Table is (3 of 250) 2% full
```

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets and SCTP association to application server assignments is less than 50, go to step 7.

If the number of TALI sockets and SCTP association to application server assignments is 50, the local host value cannot be used in this procedure.

Repeat this procedure from step 3 and select another local IP host from the **rtrv-ip-host** output or perform the [Adding an IP Host](#) procedure to add a new local IP host. After the new local IP host name as been added, go to step 7.

7. Add the new association by performing the [Adding an M3UA or SUA Association](#) procedure.

The **open** parameter value for this association must be set to **no**.

NOTE: See [Flowchart 6-71](#) (Sheet 3) for the rules that apply to the new association and the new application server.

8. Assign the new association to the new application server and add the new application server to the database using the **ent-as** command. For this example, enter this command

ent-as:asname=as4:aname=assoc10

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-AS: MASP A - COMPLTD;
```

9. Verify the changes using the **rtrv-as** command with the application server name and association name specified in step 8. For this example, enter this command.

rtrv-as:asname=as4:aname=assoc10

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as4          LOADSHARE  10        assoc10
```

AS table is (4 of 250) 1% full.

NOTE: If you do not wish to change the open parameter value of the association specified in step 8, skip step 10 and go to step 11.

10. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter. For this example, enter this command.

chg-assoc:aname=assoc10:open=yes

When this command has successfully completed, this message should appear.


```
r1ghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```


11. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.


These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-13. Adding a New Association to a New Application Server







Adding an Existing Association to a New Application Server

This procedure is used create a new application server and assign an existing association to the application server using the **ent-as** command.

The **ent-as** command uses these parameters:

:asname – The name of the new application server. The name of the application server can contain up to 15 alphanumeric characters, with the first character being an alphabetic character. Application server names are not case sensitive.

:aname – The name of the association being assigned to the application server.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 12 TALI sockets, the maximum number of SCTP association to application server assignments that the IPGWx card can support is 38. The SCTP association to application server assignments could be one SCTP association assigned to 38 application servers, two SCTP associations assigned to 19 application servers, or any combination of SCTP associations assigned to application servers that add up to 38. The number of TALI sockets can be verified with the **rtrv-appl-sock:lhost=<local host name>** command. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** and **rtrv-as:aname=<association name>** commands.

Table 6-11. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50
25	2	0	50
0	0	50	50
38	1	12	50
19	2	12	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

The **open** parameter of the association must be set to **no** before the association can be assigned to the application server. This can be verified with the **rtrv-assoc** command.

M2PA associations (**adapter=m2pa**) cannot be assigned to application servers. Only M3UA (**adapter=m3ua**) and SUA (**adapter=sua**) associations can be assigned to application servers. This can be verified in the **ADAPTER** field in the **rtrv-assoc** output.

The application server recovery timer (the **tr** parameter of the **chg-as** command) for the application server is set by default to 10 milliseconds when an application server is added. The traffic mode (the **mode** parameter of the **chg-as** command) for the application server is set by default to **LOADSHARE** when an application server is added. Perform the [Changing an Application Server](#) procedure to change these parameter values.

Canceling the RTRV-AS, RTRV-APPL-SOCK, and RTRV-ASSOC Commands

Because the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the application servers in the database using the **rtrv-as** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE 10         a2
              a3
              assoc1

as2          OVERRIDE 10         assoc7
as3          OVERRIDE 10         swbel32
```

AS table is (3 of 250) 1% full.

NOTE: If the association being added to the application server is not shown in the **rtrv-as output in step 1, skip step 2 and go to step 3.**

2. Display the associations in the database using the **rtrv-assoc** command and specifying the association name shown in the **rtrv-as** output in step 1.

For this example, enter this command.

rtrv-assoc:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc1
LOC      1305      IPLNK PORT  A      LINK  A
ADAPTER  SUA      VER      SUA RFC
LHOST    gw102.nc.tekelec.com
ALHOST    ---
RHOST    gw100.nc.tekelec.com
LPORT    4000      RPORT      1030
ISTRMS    2      OSTRMS      2      BUFSIZE  16
RMODE    LIN      RMIN      120      RMAX      800
RTIMES    10      CWMIN      3000     UAPS      10
OPEN      YES      ALW      YES      RTXTHR   10000

ASNAMES
as1
```

IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1305

If the association does not meet the requirements shown in [Flowchart 6-72](#) (Sheet 4), repeat this step with another association shown in step 1, or go to step 3.

If the association does meet the requirements shown in [Flowchart 6-72](#) (Sheet 4), skip step 3 and go to step 4.

3. Display the associations in the database using the **rtrv-assoc** command with the **display=all** parameter.

This is an example of possible output.

```
rlghncxa03w 06-03-28 09:12:36 GMT EAGLE5 34.3.0
ANAME swbel32
  LOC      1201          IPLNK PORT  A          LINK  A
  ADAPTER  M3UA          VER          M3UA RFC
  LHOST    gw101.nc.tekelec.com
  ALHOST    ---
  RHOST     gw100.ncd-economic-development.southeastern-corridor-ash.gov
  LPORT     1030          RPORT      2345
  ISTRMS    2             OSTRMS    2           BUFSIZE  16
  RMODE     LIN           RMIN       120          RMAX     800
  RTIMES    10            CWMIN     3000         UAPS     10
  OPEN      YES           ALW        YES          RTXTHR  10000
```

```
ASNAMES
as3
```

```
IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1201
```

```
ANAME a2
  LOC      1305          IPLNK PORT  A          LINK  A
  ADAPTER  SUA           VER          SUA RFC
  LHOST     gw102.nc.tekelec.com
  ALHOST     ---
  RHOST     gw100.nc.tekelec.com
  LPORT     2000          RPORT      2345
  ISTRMS    2             OSTRMS    2           BUFSIZE  16
  RMODE     LIN           RMIN       120          RMAX     800
  RTIMES    10            CWMIN     3000         UAPS     10
  OPEN      YES           ALW        YES          RTXTHR  10000
```

```
ASNAMES
as1
```

```
IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1305
```

```
ANAME a3
  LOC      1307          IPLNK PORT  A          LINK  A
  ADAPTER  SUA           VER          SUA RFC
  LHOST     gw103.nc.tekelec.com
  ALHOST     ---
  RHOST     gw106.nc.tekelec.com
  LPORT     3000          RPORT      2346
  ISTRMS    2             OSTRMS    2           BUFSIZE  16
  RMODE     LIN           RMIN       120          RMAX     800
  RTIMES    10            CWMIN     3000         UAPS     10
  OPEN      YES           ALW        YES          RTXTHR  10000
```

```
ASNAMES
as1
```

```
IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1307
```

```
ANAME assoc1
  LOC      1305          IPLNK PORT  A          LINK  A
  ADAPTER  SUA           VER          SUA RFC
```

Adding an Existing Association to a New Application Database Administration Manual - IP7 Secure Gateway Server

```
LHOST gw102.nc.tekelec.com
ALHOST ---
RHOST gw100.nc.tekelec.com
LPORT 4000 RPORT 1030
ISTRMS 2 OSTRMS 2 BUFSIZE 16
RMODE LIN RMIN 120 RMAX 800
RTIMES 10 CWMIN 3000 UAPS 10
OPEN YES ALW YES RTXTHR 10000
```

```
ASNAMES
as1
```

IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1305

```
ANAME assoc7
LOC 1311 IPLNK PORT A LINK A
ADAPTER SUA VER SUA RFC
LHOST gw105.nc.tekelec.com
ALHOST ---
RHOST gw100.nc.tekelec.com
LPORT 2500 RPORT 2000
ISTRMS 2 OSTRMS 2 BUFSIZE 16
RMODE LIN RMIN 120 RMAX 800
RTIMES 10 CWMIN 3000 UAPS 10
OPEN YES ALW YES RTXTHR 10000
```

```
ASNAMES
as2
```

IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1311

If the desired association is shown in the **rtrv-assoc** output, see [Flowchart 6-72](#) (Sheet 4) for the rules that apply to the association and the new application server, go to step 4.

If the desired association is not shown in the **rtrv-assoc** output, perform the [Adding a New Association to a New Application Server](#) procedure to add a new association to a new application server.

4. Display the sockets assigned to the local IP host value shown in either steps 2 or 3 by entering the **rtrv-appl-sock** command with the **lhost** parameter.

For this example, enter this command.

```
rtrv-appl-sock:lhost=gw102.nc.tekelec.com
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME sock1
LINK A
LHOST gw102.nc.tekelec.com
RHOST remotehost1
LPORT 1024 RPORT 2048
SERVER YES DCMPS 10
REXMIT FIXED RTT 60
OPEN YES ALW YES
```

IP Appl Sock/Assoc table is (6 of 4000) 1% full

5. Display the associations assigned to the local IP host value specified in step 4 by entering the **rtrv-assoc** command with the **lhost** parameter.

For this example, enter this command.

```
rtrv-assoc:lhost=gw102.nc.tekelec.com
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
```

	CARD	IPLNK							
ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW	
assoc1	1305	A	A	SUA	4000	1030	YES	YES	

IP Appl Sock/Assoc table is (5 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1305

- Display the application servers that the associations shown in step 5 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 5.

For this example, enter this command.

rtrv-as:aname=assoc1

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms    Association Names
as1          LOADSHARE  10      assoc1
AS Table is (3 of 250) 1% full
```

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets and SCTP association to application server assignments is less than 50, go to step 7.

If the number of TALI sockets and SCTP association to application server assignments is 50, the association shown in either steps 2 or 3 cannot be used in this procedure. Go back to step 1 and choose another association to assign to the new application server.

NOTE: If the value of the open parameter of the association being assigned to the application server in step 5 is no, skip step 7 and go to step 8.

- Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

For this example, enter this command.

chg-assoc:aname=assoc1:open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

- Add the application server to the database with the name of the association shown in either steps 2 or 3 using the **ent-as** command.

For this example, enter this command.

ent-as:asname=as4:aname=assoc1

This is an example of the possible outputs.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-AS: MASP A - COMPLTD;
```

- Verify the changes using the **rtrv-as** command with the application server name specified in step 8.

For this example, enter this command.

rtrv-as:asname=as4

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

AS Name	Mode	Tr ms	Association Names
as4	LOADSHARE	10	assoc1

AS table is (4 of 250) 1% full.

NOTE: If you do not wish to change the open parameter value of the association specified in step 8, skip step 10 and go to step 11.

10. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

For this example, enter this command.

chg-assoc : aname=assoc1 : open=yes

When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```


11. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.


These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 6-14. Adding an Existing Association to a New Application Server







Notes:

1. If the application server is being added in this procedure will be assigned to a routing key containing a *rcontext* parameter value, the *adapter* parameter value for the association assigned to this application server can be either M3UA or SUA.
2. If the application server is being added in this procedure will be assigned to a routing key that does not contain a *rcontext* parameter value, the *adapter* parameter value for the association assigned to this application server must be M3UA.
3. SUA associations and their corresponding application server, can be assigned to only these types of routing keys:
 - Full routing key – DPC/SI=3/SSN
 - Partial routing key – DPC/SI=3
 - Partial routing key – DPC only
 - Partial routing key – SI=3 only
 - Default routing key.

The routing key containing the application server with the SUA associations must have an *rcontext* value assigned to it.

If the new application server will not be assigned to one of these types of routing keys, the *adapter* parameter value of the associations assigned to the application server must be M3UA.
4. M2PA associations cannot be assigned to application servers.

Adding a New Association to an Existing Application Server

This procedure is used assign a new association to an existing application server using the **ent -as** command.

The **ent -as** command uses these parameters:

:asname – The name of the new application server.

:aname – The name of the association being assigned to the application server.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 12 TALI sockets, the maximum number of SCTP association to application server assignments that the IPGWx card can support is 38. The SCTP association to application server assignments could be one SCTP association assigned to 38 application servers, two SCTP associations assigned to 19 application servers, or any combination of SCTP associations assigned to application servers that add up to 38. The number of TALI sockets can be verified with the **rtrv-appl-sock:lhost=<local host name>** command. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** and **rtrv-as:aname=<association name>** commands.

Table 6-12. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
25	2	0	50
0	0	50	50
38	1	12	50
19	2	12	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

A maximum of 16 associations can be assigned to an application server.

The **open** parameter of the association must be set to **no** before the association can be assigned to the application server. This can be verified with the **rtrv-assoc** command.

M2PA associations (**adapter=m2pa**) cannot be assigned to application servers. Only M3UA (**adapter=m3ua**) and SUA (**adapter=sua**) associations can be assigned to application servers. This can be verified in the **ADAPTER** field in the **rtrv-assoc** output.

The application running on the card hosting the association that will be assigned to the application server must be the same as the application running on the cards hosting the other associations assigned to the application server.

Canceling the RTRV-AS, RTRV-APPL-SOCK, and RTRV-ASSOC Commands

Because the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

- Display the application servers in the database using the **rtrv-as** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE 10         assoc1
              assoc2
```

```

                                assoc3
                                assoc5
                                assoc6

as2                OVERRIDE    10    assoc7

```

AS table is (2 of 250) 1% full.

2. Display the application server that the new association will be added to by entering the **rtrv-as** command with the name of the application server.

For this example, enter this command.

rtrv-as:aname=as2

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name      Mode      Tr ms  Association Names
as2          OVERRIDE  10     assoc7

```

AS table is (2 of 250) 1% full.

A maximum of 16 associations can be assigned to an application server. If the application server displayed in this step contains less than 16 associations, go to step 3.

If the application server displayed in this step contains 16 associations, either select another application server to use in this procedure and repeat this step, or perform the [Adding a New Association to a New Application Server](#) procedure to add the new association to a new application server.

3. Display the one of the associations assigned to the application server shown in step 2 using the **rtrv-assoc** command and specifying the association name shown in the **rtrv-as** output from step 2. For this example, enter this command.

rtrv-assoc:aname=assoc7

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc7
  LOC      1203      IPLNK PORT  A      LINK  A
  ADAPTER  SUA      VER      SUA RFC
  LHOST    gw105.nc.tekelec.com
  ALHOST    ---
  RHOST    gw100.nc.tekelec.com
  LPORT    1030      RPORT      1030
  ISTRMS   2          OSTRMS     2          BUFSIZE  16
  RMODE    LIN        RMIN      120        RMAX     800
  RTIMES   10         CWMIN    3000    UAPS     10
  OPEN     YES        ALW        YES       RTXTHR  10000

  ASNAMES
  as2

```

IP Appl Sock table is (7 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

The **adapter** parameter value of all the associations assigned to an application server must be the same. This step identifies the **adapter** value of the associations assigned to the application server. The application running on the card hosting the new association must be the same as the application on the cards hosting the associations assigned to the application server.

4. Display the signaling link assigned to the card, shown in step 3 by entering the **rtrv-slk** command with the card location of the signaling link shown in step 3. For this example, enter this command.

rtrv-slk:loc=1203

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOC LINK LSN          SLC TYPE
1203 A    lsn5        1  SS7IPGW
```

The application running on the card is shown in the **TYPE** column of the **rtrv-slk** output.

For this example, the new association must be assigned to a card running the **SS7IPGW** application.

If the local host value shown in step 3 will be assigned to the new association, skip steps 5, 6, and 7, and go to step 8.

If another local host value will be assigned to the new association, perform step 5.

5. Display the IP host names in the database by using the **rtrv-ip-host** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      GW105. NC. TEKELEC. COM
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MS1
192.1.1.52      DN-MS2

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV
```

IP Host table is (11 of 512) 2% full

If the local IP host name for the new association is not shown in the **LOCAL HOST** column of the **rtrv-ip-host** output, add the new IP host name by performing the [Adding an IP Host](#) procedure. The new local IP host must be assigned to a card running the application shown in step 4.

After the new local IP host has been added, skip steps 6 through 9, and go to step 10.

If the local IP host name for the new association is shown in the **LOCAL HOST** column of the **rtrv-ip-host** output, go to step 8.

6. Display the IP links in the database by entering the **rtrv-ip-lnk** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A     192.1.1.10        255.255.255.128  HALF    10     802.3    NO    NO
1201  B     -----          -----          HALF    10     DIX      NO    NO
1203  A     192.1.1.12        255.255.255.0    ----    ---    DIX      YES   NO
1203  B     -----          -----          HALF    10     DIX      NO    NO
1205  A     192.1.1.14        255.255.255.0    FULL    100    DIX      NO    NO
1205  B     -----          -----          HALF    10     DIX      NO    NO
2101  A     192.1.1.20        255.255.255.0    FULL    100    DIX      NO    NO
2101  B     -----          -----          HALF    10     DIX      NO    NO
2103  A     192.1.1.22        255.255.255.0    FULL    100    DIX      NO    NO
2103  B     -----          -----          HALF    10     DIX      NO    NO
2105  A     192.1.1.24        255.255.255.0    FULL    100    DIX      NO    NO
2105  B     -----          -----          HALF    10     DIX      NO    NO
```

2205	A	192.1.1.30	255.255.255.0	FULL	100	DIX	NO	NO
2205	B	-----	-----	HALF	10	DIX	NO	NO
2207	A	192.1.1.32	255.255.255.0	FULL	100	DIX	NO	NO
2207	B	-----	-----	HALF	10	DIX	NO	NO
2213	A	192.1.1.50	255.255.255.0	FULL	100	DIX	NO	NO
2213	B	-----	-----	HALF	10	DIX	NO	NO
2301	A	192.1.1.52	255.255.255.0	FULL	100	DIX	NO	NO
2301	B	-----	-----	HALF	10	DIX	NO	NO

- Display the signaling link assigned to the card, shown in step 6, whose IP address is assigned to the local host shown in step 5 by entering the **rtrv-sl** command with the card location of the signaling link. For this example, enter this command.

rtrv-sl: loc=1205

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0

LOC LINK LSN          SLC TYPE
1205 A   lsn5          1  SS7IPGW
```

The application running on the card is shown in the **TYPE** column of the **rtrv-sl** output.

For this example, the new association must be assigned to a card running the **SS7IPGW** application.

If the card's application shown in this step and in step 4 are the same, go to step 8.

If the card's application shown in this step and in step 4 are not the same, either repeat this procedure from step 5 with another local IP host, or add the new local IP host name by performing the [Adding an IP Host](#) procedure. The new local IP host must be assigned to a card running the application shown in step 4. After the new local IP host has been added, skip steps 8 and 9, and go to step 10.

- Display the sockets assigned to the local IP host value that will be assigned to the new association by entering the **rtrv-appl-sock** command with the **lhost** parameter. For this example, enter this command.

rtrv-appl-sock: lhost="IPNODE-1205"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME sock1
LINK      A
LHOST     IPNODE-1205
RHOST     remotehost1
LPORT     1024          RPORT     2048
SERVER    YES           DCMP      10
REXMIT    FIXED         RTT       60
OPEN      YES           ALW       YES
IP Appl Sock/Assoc table is (7 of 4000) 1% full
```

- Display the associations assigned to the local IP host value specified in step 8 by entering the **rtrv-assoc** command with the **lhost** parameter. For this example, enter this command.

rtrv-assoc: lhost="IPNODE-1205"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME LOC PORT LINK ADAPTER LPORT RPORT OPEN ALW
assoc1 1205 A   A   M3UA    1030 1030 YES YES

IP Appl Sock/Assoc table is (7 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1205
```


10. Display the application servers that the associations shown in step 9 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 9. For this example, enter this command.

rtrv-as:aname=assoc1

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms    Association Names
as1          LOADSHARE  10      assoc1
AS Table is (2 of 250) 1% full
```

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets and SCTP association to application server assignments is less than 50, go to step 11.

If the number of TALI sockets and SCTP association to application server assignments is 50, either repeat this procedure from step 5 with another local IP host, or add the new local IP host name by performing the [Adding an IP Host](#) procedure. The new local IP host must be assigned to a card running the application shown in steps 4 and 7. After the new local IP host has been added, go to step 11.

11. Add the new association by performing the [Adding an M3UA or SUA Association](#) procedure. The **open** parameter value for this association must be set to **no**. The adapter value for this association must be the same as the adapter value shown in step 3.

NOTE: See [Flowchart 6-73](#) (Sheet 5) for the rules that apply to the new association and the application server.

12. Add the association to the application server using the **ent-as** command with the name of the application server specified in step 2 and the name of the new association. For this example, enter this command.

ent-as:asname=as2:aname=assoc10

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-AS: MASP A - COMPLTD;
```

13. Verify the changes using the **rtrv-as** command with the name of the application server specified in step 12. For this example, enter this command.

rtrv-as:asname=as2

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms    Association Names
as2          OVERRIDE  10      assoc7
                                           assoc10
```

AS table is (2 of 250) 1% full.

NOTE: If you do not wish to change the **open** parameter value of the association specified in step 12, skip step 14 and go to step 15.

14. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter. For this example, enter this command.

chg-assoc:aname=assoc10:open=yes

When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```


15. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.


These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 6-15. Adding a New Association to an Existing Application Server











Adding an Existing Association to an Existing Application Server

This procedure is used assign an existing association to an existing application server using the **ent -as** command.

The **ent -as** command uses these parameters:

:asname – The name of the application server.

:aname – The name of the association being assigned to the application server.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 12 TALI sockets, the maximum number of SCTP association to application server assignments that the IPGWx card can support is 38. The SCTP association to application server assignments could be one SCTP association assigned to 38 application servers, two SCTP associations assigned to 19 application servers, or any combination of SCTP associations assigned to application servers that add up to 38. The number of TALI sockets can be verified with the **rtrv-appl-sock:lhost=<local host name>** command. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** command.

Table 6-13. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50
25	2	0	50
0	0	50	50
38	1	12	50
19	2	12	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

A maximum of 16 associations can be assigned to an application server.

The **open** parameter of the association must be set to **no** before the association can be assigned to the application server. This can be verified with the **rtrv-assoc** command.

M2PA associations (**adapter=m2pa**) cannot be assigned to application servers. Only M3UA (**adapter=m3ua**) and SUA (**adapter=sua**) associations can be assigned to application servers. This can be verified in the **ADAPTER** field in the **rtrv-assoc** output.

The application running on the card hosting the association that will be assigned to the application server must be the same as the application running on the cards hosting the other associations assigned to the application server.

Canceling the RTRV-AS, RTRV-APPL-SOCK, and RTRV-ASSOC Commands

Because the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as**, **rtrv-appl-sock**, and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-as**, **rtrv-appl-sock**, or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the application servers in the database using the **rtrv-as** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE 10         a2
              a3
              assoc1

as2          OVERRIDE 10         assoc7
as3          OVERRIDE 10         swbel32
```

AS table is (3 of 250) 1% full.

2. Display the application server that the new association will be added to by entering the **rtrv-as** command with the name of the application server.

For this example, enter this command.

rtrv-as:asname=as2

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name      Mode      Tr ms      Association Names
as2          OVERRIDE 10         assoc7
```

AS table is (3 of 250) 1% full.

A maximum of 16 associations can be assigned to an application server. If the application server displayed in this step contains less than 16 associations, go to step 3.

If the application server displayed in this step contains 16 associations, either select another application server to use in this procedure and repeat this step, or perform the [Adding an Existing Association to a New Application Server](#) procedure to add the association to a new application server.

NOTE: If the association being added to the application server is shown in the **rtrv-as** output in step 1, skip step 3 and go to step 4.

3. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

	CARD	IPLNK							
ANAME	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW	
swbel32	1201	A	A	M3UA	1030	2345	YES	YES	
a2	1305	A	A	SUA	2000	2345	YES	YES	
a3	1307	A	A	SUA	3000	2346	YES	YES	
assoc1	1305	A	A	SUA	4000	1030	YES	YES	
assoc7	1305	A	A	SUA	4500	1030	YES	YES	

If the association being added to the application server is shown in this step, go to step 4.

If the association being added to the application server is not shown in this step, perform the [Adding a New Association to an Existing Application Server](#) procedure to add a new association to the application server.

- Display one of the associations assigned to the application server shown in step 2 using the **rtrv-
assoc** command and specifying the association name shown in the **rtrv-as** output from step 2 or in the **rtrv-
assoc** output in step 3.

For this example, enter this command.

```
rtrv-  
assoc:aname=assoc7
```

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```
ANAME assoc7
LOC 1203          IPLNK PORT A          LINK A
ADAPTER SUA          VER SUA RFC
LHOST gw105.nc.tekelec.com
ALHOST ---
RHOST gw100.nc.tekelec.com
LPORT 4500          RPORT 1030
ISTRMS 2            OSTRMS 2            BUFSIZE 16
RMODE LIN           RMIN 120            RMAX 800
RTIMES 10           CWMIN 3000          UAPS 10
OPEN YES            ALW YES            RTXTHR 10000

ASNAMES
as2
```

```
IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203
```

The **adapter** parameter value of all the associations assigned to an application server must be the same. This step identifies the **adapter** value of the associations assigned to the application server.

The application running on the card hosting the new association must be the same as the application on the cards hosting the associations assigned to the application server.

- Display the signaling link assigned to the card, shown in step 4 by entering the **rtrv-slk** command with the card location of the signaling link.

For this example, enter this command.

```
rtrv-slk:loc=1205
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
```

LOC	LINK	LSN	SLC	TYPE
1205	A	lsn5	1	SS7IPGW

The application running on the card is shown in the **TYPE** column of the **rtrv-slk** output.

For this example, the new association must be assigned to a card running the **SS7IPGW** application.

6. Display the association being added to the application server using the **rtrv-assoc** command and specifying the name of the association being added.

For this example, enter this command.

rtrv-assoc:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc1
LOC 1203 IPLNK PORT A LINK A
ADAPTER SUA VER SUA RFC
LHOST gw101.nc.tekelec.com
ALHOST ---
RHOST gw100.nc.tekelec.com
LPORT 4000 RPORT 1030
ISTRMS 2 OSTRMS 2 BUFSIZE 16
RMODE LIN RMIN 120 RMAX 800
RTIMES 10 CWMIN 3000 UAPS 10
OPEN YES ALW YES RTXTHR 10000

ASNAMES
as1
```

IP Appl Sock table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

If the local host and **adapter** values shown in this step are the same as the local host and **adapter** values shown in step 4, skip step 7 and go to step 8.

If the **adapter** value shown in this step is not the same as the **adapter** value shown in step 4, repeat this procedure from step 3.

If the local host value shown in this step is not the same as the local host value shown in step 4, but the **adapter** value shown in this step is the same as the **adapter** values shown in step 4, go to step 7.

7. Display the signaling link assigned to the card, shown in step 6 by entering the **rtrv-slk** command with the card location of the signaling link.

For this example, enter this command.

rtrv-slk:loc=1201

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0

LOC LINK LSN SLC TYPE
1201 A lsn1 0 SS7IPGW
```

The application running on the card is shown in the **TYPE** column of the **rtrv-slk** output.

For this example, the association being added to the application server must be assigned to a card running the **SS7IPGW** application.

If the card applications shown in this step and in step 5 are the same, go to step 8.

If the card applications shown in this step and in step 5 are not the same, repeat this procedure from step 3.

8. Display the sockets assigned to the local IP host value of the association that will be assigned to the application server by entering the **rtrv-appl-sock** command with the **lhost** parameter.

For this example, enter this command.

rtrv-appl-sock: lhost=gw101.nc.tekelec.com

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME sock1
  LINK      A
  LHOST     gw101.nc.tekelec.com
  RHOST     remotehost1
  LPORT     1024      RPORT     2048
  SERVER    YES       DCMPS     10
  REXMIT    FIXED     RTT        60
  OPEN      YES       ALW        YES
IP Appl Sock/Assoc table is (6 of 4000) 1% full
```

9. Display the associations assigned to the local IP host value specified in step 8 by entering the **rtrv-assoc** command with the **lhost** parameter.

For this example, enter this command.

rtrv-assoc: lhost=gw101.nc.tekelec.com

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc1     1203 A    A    SUA    4000  1030  YES  YES
IP Appl Sock/Assoc table is (6 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1203
```

10. Display the application servers that the associations shown in step 9 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 9.

For this example, enter this command.

rtrv-as: aname=assoc1

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms  Association Names
as1          LOADSHARE  10     assoc1
AS Table is (3 of 250) 1% full
```

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets and SCTP association to application server assignments is less than 50, go to step 11.

If the number of TALI sockets and SCTP association to application server assignments is 50, either repeat this procedure from step 3, or perform the [Adding a New Association to an Existing Application Server](#) procedure to add a new association to this application server.

NOTE: If the value of the open parameter shown in step 6 is no, skip this step and go to step 12.

11. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

For this example, enter this command.

chg-assoc: aname=assoc1: open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

12. Add the association to the application server using the **ent-as** command.

For this example, enter this command

ent-as:asname=as2:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-AS: MASP A - COMPLTD;
```

13. Verify the changes using the **rtrv-as** command with the application server name specified in step 12.

For this example, enter this command.

rtrv-as:asname=as2

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name           Mode           Tr ms   Association Names
as2                OVERRIDE      10      assoc1
                  assoc7
AS table is (3 of 250) 1% full.
```

NOTE: If you do not wish to change the open parameter value of the association specified in step 12, skip step 14 and go to step 15.

14. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

For this example, enter this command.

chg-assoc:aname=assoc1:open=yes


When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```


15. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.


These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-16. Adding an Existing Association to an Existing Application Server









Adding a Routing Key Containing an Application Server

This procedure is used to add a routing key containing an application server to the database using the **ent-appl-rtkey** command.

A routing key defines a filter that checks the specified values in an incoming SS7 MSU to determine which, if any, socket or association receives the MSU. For more information about static routing keys, see [Understanding Routing for SS7IPGW and IPGWI Applications](#).

The **ent-appl-rtkey** command uses these parameters.

:dpc/dpca/dpci/dpcn/dpcn24 – The destination point code value that is used to filter incoming MSUs. This parameter must not specify a cluster route. The destination point code of the routing key cannot be the APC of an IPGWx linkset or the SAPC assigned to an IPGWx linkset.

:opc/opca/opci/opcn/opcn24 – The originating point code value that is used to filter incoming MSUs. This parameter must not specify a cluster route. This parameter is valid only when the **si** parameter value is set to **4**, **5**, or **13**. This parameter is required if **si=4, 5, or 13** and **type=full**.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value from 0 to 15, or for selected service indicator values, a text string can be used instead of numbers. [Table 6-14](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 6-14. Service Indicator Text String Values

Service Indicator Value	Text String
0	snm
1	regtest
2	spltst
3	sccp
4	tup
5	isup
13	qbicc

:ssn – The subsystem value that is used to filter incoming MSUs. The **ssn** parameter is only valid when the **si** parameter value is set to **3** or **sccp**.

:cics – The starting circuit identification code that is used to filter incoming MSUs. When specified with **cice**, **cics** identifies the start of the range of circuit identification codes. The **cics** parameter is valid only when the **si** parameter value is set to **4**, **5**, or **13**. The **cics** is required if **si=4, 5, or 13** and **type=full**.

:cice – The ending circuit identification code that is used to filter incoming MSUs. When specified with **cics**, **cice** identifies the end of the range of circuit identification codes. The **cice** parameter is valid only when the **si** parameter value is set to **4**, **5**, or **13**. The **cice** is required if **si=4, 5, or 13** and **type=full**.

:type – The routing key type – Identifies the type of routing key that is being entered and used to route message signaling units (MSUs). One of three values, **full/partial/default**, can be specified for the type parameter (see [Table 6-15](#)). If **type** is not explicitly specified, **type = full** is assumed.

:asname – Application server (AS) name.

:rcontext – The routing context parameter, which has two functions:

- Provides an index of the application server traffic that the sending application server is configured or registered to receive.
- Identifies the SS7 network context for the message. The routing context parameter implicitly defines the SS7 point code format used, the SS7 network indicator value, and the SCCP protocol type/variant/version used.

The **ent-appl-rtkey** command also contains the **sname** (socket name) parameters which cannot be used in this procedure. The **sname** parameter and its use is discussed in more detail in the [Adding a Routing Key Containing a Socket](#) procedure.

Application server names are shown in the **rtrv-as** output.

Only one application server can be assigned to a routing key. There is a maximum of 1000 routing keys allowed per EAGLE 5 ISS (if there are any dual-slot DCM cards), or 2500 routing keys allowed per EAGLE 5 ISS (if all cards running the **ss7ipgw** or **ipgwi** application are SSEDCM cards). Each of routing key's socket or application server names must be uniquely named. Dual-slot DCMs do not support associations as IP connections and do not support application servers.

The number of static routing keys is limited by the **srkq** parameter that was specified on the **chg-sg-opts** command.

Routing keys are associated only with the **ss7ipgw** or **ipgwi** application.

Group codes are required for 14-bit ITU-N point codes (DPCN/OPCN) when the Duplicate Point Code feature is enabled.

The starting circuit identification code must be less than or equal to the ending circuit identification code.

The ISUP routing over IP feature must be on in order to enter a routing key with these parameters: **dpc**, **si**, **opc**, **cics**, and **cice**. The **IPISUP** field in the **rtrv-feat** command output shows whether or not this feature is on.

The parameter combinations used by the **ent-appl-rtkey** command are based on the type of routing key and the service indicator value in the routing key. The parameter combinations are shown in [Table 6-15](#) .

Table 6-15. Routing Key Parameter Combinations for Adding a Routing Key Containing an Application Server

Full Routing Key - SI = 3 (SCCP)	Partial Routing Key - SI = 3 (SCCP)	Full Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key - Other SI Values	Partial Routing Key - Other SI Values	Default Routing Key
dpc ^{1, 2, 11}	type=partial	dpc ^{1, 2}	type=partial	dpc ^{1, 2}	type=partial	type=default
si=3 ^{4, 11}	dpc ^{1, 2, 3}	si=4, 5, 13 ⁴	dpc ^{1, 2, 3}	si=value other than 3, 4, 5, 13 ⁴	dpc ^{1, 2, 3}	asname ¹⁰
ssn ¹¹	si=3 ^{3, 4}	opc ^{1, 2}	si=4, 5, 13 ^{3, 4, 10}	type=full	si=value other than 3, 4, 5,	rcontext ¹⁰

Full Routing Key - SI = 3 (SCCP)	Partial Routing Key - SI = 3 (SCCP)	Full Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key - Other SI Values	Partial Routing Key - Other SI Values	Default Routing Key
					13 ³ , 4, 10	
type=full	asname ¹⁰	cics ⁵ , 6, 7, 8, 9	opc ¹ , 2, 3	asname ¹⁰	asname ¹⁰	
asname ¹⁰	rcontext ¹⁰	cice ⁵ , 6, 7, 8, 9	asname ¹⁰	rcontext ¹⁰	rcontext ¹⁰	
rcontext ¹⁰		type=full	rcontext ¹⁰			
		asname ¹⁰				
		rcontext ¹⁰				

Notes:

1. The **dpc** and **opc** parameters can be either an ANSI point code (**dpca**, **opca**), ITU-I point code or ITU-I spare point code (**dpci**, **opci**), 14-bit ITU-N point code or 14-bit ITU-N spare point code (**dpcn**, **opcn**), or 24-bit ITU-N point code (**dpcn24**, **opcn24**). If the **dpc** and **opc** parameters are specified, the **dpc** and **opc** must be the same type of point code. For example, if the **dpca** parameter is specified, the OPC is specified with the **opca** parameter. If either point code value is a spare point code, the other point code value must be a spare point code on the same type. For example, if the **dpc** value is an ITU-I spare point code, the **opc** value must be an ITU-I spare point code.
2. If the ITU National Duplicate Point Code feature is on, the values for the **dpcn** and **opcn** parameters must have group codes assigned to them. The field **ITUDUPPC** in the **rtrv-feat** command output shows whether or not the ITU National Duplicate Point Code feature is on. If group codes are specified for ITU-N DPC and OPC, the groups codes must be the same.
3. These parameters are optional for partial routing keys, but at least one these parameters must be specified with the **ent-appl-rtkey** command.
4. Text strings can be used in place of some numerical service indicator values. See [Table 6-14](#) for a list of these text strings.
5. When the service indicator parameter value equals **4** and an ANSI dpc is specified, the **opc**, **cics**, and **cice** parameters cannot be used. If the service indicator parameter value equals **4** and an ITU dpc is specified, the **opc**, **cics**, and **cice** parameters are required.
6. If the service indicator parameter (**si**) value is **4**, the values of the **cics** and **cice** parameters is from **0** to **4095**.
7. If the service indicator parameter (**si**) value is **5** and the point code in the routing key is either an ITU-I, 14-bit ITU-N, or 24-bit ITU-N point code, the values of the **cics** and **cice** parameters is from **0** to **4095**. If the point code in the routing key is an ANSI point code, the values of the **cics** and **cice** parameters is from **0** to **16383**.
8. If the service indicator parameter value is **13**, the values of the **cics** and **cice** parameters is from **0** to **4294967295**.
9. The CIC range, defined by the **cics** and **cice** parameters, cannot overlap the CIC range in an existing routing key.
10. The following rules apply to using the **rcontext** parameter.
 - The value of the **rcontext** parameter is from **0** to **4294967295**.
 - The **rcontext** parameter is required for a routing key containing an SUA application server.
 - The **rcontext** parameter is optional for a routing key containing an M3UA application server.
 - The **rcontext** parameter value must be unique in the database. Multiple routing keys cannot have the same **rcontext** value assigned.
 - An application server can be assigned to only one routing key containing a routing context value.
 - If the application server being assigned to the new routing key is assigned to other routing keys that do not contain **rcontext** parameter values, the **rcontext** parameter cannot be specified for the new routing key.
 - An application server can be assigned to multiple routing keys if those routing keys do not contain a routing context value.

Full Routing Key - SI = 3 (SCCP)	Partial Routing Key - SI = 3 (SCCP)	Full Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key - SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key - Other SI Values	Partial Routing Key - Other SI Values	Default Routing Key
- An application server can be assigned to either a routing key containing a routing context value, or to routing keys that do not contain a routing context value, but the application server cannot be assigned to both types of routing keys. - In order for an M3UA or SUA association to be assigned to multiple routing keys with a routing context value, the M3UA or SUA association must be assigned to multiple application servers and then each application server must be assigned to a routing key containing a routing context value. 11. To communicate the status changes of remote IP subsystems (defined by the DPC and SSN specified in a full SCCP routing key), the DPC and SSN specified for a full SCCP routing key must be provisioned in the mated application table. Perform one of the mated application procedures in the <i>Database Administration Manual - Global Title Translation</i> to provision a mated application with the DPC and SSN specified for a full SCCP routing key.						

Canceling the RTRV-AS and RTRV-APPL-RTKEY Commands

Because the **rtrv-as** and **rtrv-appl-rtkey** commands used in this procedure can output information for a long period of time, the **rtrv-as** and **rtrv-appl-rtkey** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as** and **rtrv-appl-rtkey** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as** or **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as** or **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as** and **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-as** or **rtrv-appl-rtkey** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

- Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

RCONTEXT	DPCI	SI	ADPTR	ASNAME	TYPE	LOC
-----	2-100-7	6	M3UA	as4	FULL	STATIC
100	3-137-6	6	SUA	as1	FULL	STATIC
225	4-035-7	5	M3UA	as5	FULL	STATIC
-----	6-006-6	5	TALI	-----	FULL	STATIC
-----	6-006-7	6	TALI	-----	FULL	STATIC
-----	6-006-8	3	M3UA	as3	FULL	STATIC
-----	6-006-8	5	M3UA	as2	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC

```

----- 6-024-7 5 M3UA as4 FULL STATIC
300      7-008-7 6 SUA  as6 FULL STATIC

RCONTEXT DPCN SI ADPTR ASNAME TYPE LOC
RCONTEXT DPCN24 SI ADPTR ASNAME TYPE LOC
RCONTEXT DPC SI ADPTR ASNAME TYPE LOC
----- ***** ** TALI ----- DEFAULT STATIC

```

```

STATIC Route Key table is (13 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full

```

```

STATIC Route Key Socket Association table is (13 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full

```

The database can contain only one default routing key. If the **rtrv-appl-rtkey** output contains a default routing key, a default routing key cannot be added in this procedure. Go to step 2 to add either a full or partial routing key with the desired application server.

2. Display the current application server information in the database by entering the **rtrv-as** command. The following is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE 10         assoc1
              LOADSHARE 10         assoc2
              LOADSHARE 10         assoc3
              LOADSHARE 10         assoc5
              LOADSHARE 10         assoc6

as2          OVERRIDE 10         assoc7

as3          LOADSHARE 10         assoc8
              LOADSHARE 10         assoc9

as4          LOADSHARE 10         assoc10
              LOADSHARE 10         assoc11

as5          LOADSHARE 10         assoc12
              LOADSHARE 10         assoc13

AS Table is (5 of 250) 1% full

```

If the required application server is not in the database, perform one of these procedures to add the application server:

- [Adding a New Association to a New Application Server](#)
- [Adding an Existing Association to a New Application Server](#)
- [Adding a New Association to an Existing Application Server](#)
- [Adding an Existing Association to an Existing Application Server](#) .

If the **rcontext** parameter will not be specified for the routing key, make sure that the **adapter** parameter value for the associations assigned to the new application server is **M3UA**.

If the **rcontext** parameter will be specified for the routing key, make sure that the **open** parameter value of the associations is set to **no**. The **adapter** parameter value of these associations can be either **SUA** or **M3UA**.

SUA associations, and their corresponding application server, can be assigned to only these types of routing keys:

- Full routing key – DPC/SI=3/SSN
- Partial routing key – DPC/SI=3
- Partial routing key – DPC only
- Partial routing key – SI=3 only
- Default routing key.

After the new application server is added to the database, go to step 4.

3. Display the routing keys containing the application server being used in this procedure by entering the **rtrv-appl-rtkey** command with the application server name and the **display=all** parameter. For this example, enter these commands.

rtrv-appl-rtkey:asname=as4:display=all

The following is an example of the possible output.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

RCONTEXT	DPCI	SI	SSN	OPCI	CICS	CICE	LOC
-----	6-024-7	5	---	1-057-4	150	175	STATIC

ADPTR	TYPE	ASNAME
M3UA	FULL	as4

ANAMES	
assoc11	assoc12

RCONTEXT	DPCI	SI	SSN	OPCI	CICS	CICE	LOC
-----	2-100-7	6	---	-----	-----	-----	---

ADPTR	TYPE	ASNAME
M3UA	FULL	as4

ANAMES	
assoc11	assoc12

STATIC Route Key table is (7 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (7 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

rtrv-appl-rtkey:asname=as5:display=all

The following is an example of the possible output.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

RCONTEXT	DPCI	SI	SSN	OPCI	CICS	CICE	LOC
225	4-035-7	5	---	3-200-4	200	300	STATIC

ADPTR	TYPE	ASNAME
M3UA	FULL	as5

ANAMES	
assoc15	assoc16

```

STATIC Route Key table is (7 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (7 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full

```

If the application server is not assigned to any routing keys, the **rcontext** parameter can be specified for the new routing key using this application server. Go to step 4.

An application server can be assigned to only one routing key containing a routing context value. If the application server is assigned to other routing keys, the **rcontext** parameter cannot be specified for the new routing key being added in this procedure. If you wish to use the **rcontext** parameter for the new routing key, perform one of these procedures to add the application server:

- [Adding a New Association to a New Application Server](#)
- [Adding an Existing Association to a New Application Server](#)
- [Adding a New Association to an Existing Application Server](#)
- [Adding an Existing Association to an Existing Application Server](#) .

After the new application server is added, go to step 6.

If the application server is assigned to other routing keys, and these routing keys do not contain **rcontext** parameter values, the application server can be assigned to the new routing key in this procedure, but the **rcontext** parameter cannot be specified for the new routing key.

If you do not wish to use the **rcontext** parameter for the new routing key, go to step 6.

4. Display the associations assigned to the application server displayed in step 3, to verify the **open** parameter value of the association, using the **rtrv-assoc** command with the association names shown in step 2.

For this example, enter these commands.

```
rtrv-assoc:aname=assoc11
```

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc11
  LOC      1203          IPLNK PORT  A          LINK  A
  ADAPTER  M3UA          VER        M3UA RFC
  LHOST    gw110.nc.tekelec.com
  ALHOST   ---
  RHOST    gw100.nc.tekelec.com
  LPORT    1030          RPORT      1030
  ISTRMS   2             OSTRMS    2           BUFSIZE  16
  RMODE    LIN           RMIN       120         RMAX     800
  RTIMES   10            CWMIN     3000        UAPS     10
  OPEN     YES           ALW        YES         RTXTHR  10000

  ASNAMES
  as4

```

```

IP Appl Sock table is (10 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

```

```
rtrv-assoc:aname=assoc12
```

This is an example of possible output.


```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc12
  LOC      1204          IPLNK PORT  A          LINK  A
  ADAPTER  M3UA          VER          M3UA RFC
  LHOST    gw200.nc.tekelec.com
  ALHOST    ---
  RHOST    gw100.nc.tekelec.com
  LPORT    2564          RPORT      1030
  ISTRMS   2             OSTRMS    2           BUFSIZE  16
  RMODE    LIN           RMIN       120         RMAX     800
  RTIMES   10            CWMIN      3000        UAPS     10
  OPEN     YES           ALW        YES

```

```

ASNAMES
as4

```

IP Appl Sock table is (10 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1204

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc12
  LOC      1204          IPLNK PORT  A          LINK  A
  ADAPTER  M3UA          VER          M3UA RFC
  LHOST    gw200.nc.tekelec.com
  ALHOST    ---
  RHOST    gw100.nc.tekelec.com
  LPORT    2564          RPORT      1030
  ISTRMS   2             OSTRMS    2           BUFSIZE  16
  RMODE    LIN           RMIN       120         RMAX     800
  RTIMES   10            CWMIN      3000        UAPS     10
  OPEN     YES           ALW        YES          RTXTHR  10000

```

```

ASNAMES
as4

```

IP Appl Sock table is (10 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1204

rtrv-assoc:aname=assoc15

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc15
  LOC      1207          IPLNK PORT  A          LINK  A
  ADAPTER  SUA           VER          SUA RFC
  LHOST    gw150.nc.tekelec.com
  ALHOST    ---
  RHOST    gw100.nc.tekelec.com
  LPORT    1500          RPORT      1030
  ISTRMS   2             OSTRMS    2           BUFSIZE  16
  RMODE    LIN           RMIN       120         RMAX     800
  RTIMES   10            CWMIN      3000        UAPS     10
  OPEN     YES           ALW        YES          RTXTHR  10000

```

```

ASNAMES
as5

```

IP Appl Sock table is (4 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1207

rtrv-assoc:aname=assoc16

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc16
  LOC      1211          IPLNK PORT  A          LINK  A
  ADAPTER  SUA           VER          SUA RFC

```

```

LHOST    gw160.nc.tekelec.com
ALHOST    ---
RHOST    gw100.nc.tekelec.com
LPORT    3571          RPORT    1030
ISTRMS    2            OSTRMS    2          BUFSIZE  16
RMODE    LIN          RMIN     120        RMAX     800
RTIMES    10          CWMIN    3000       UAPS     10
OPEN      YES         ALW      YES        RTXTHR  10000

ASNAMES
as5

```

IP Appl Sock table is (4 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1211

Repeat this step for each association name displayed in step 3 to verify the **open** parameter of each association assigned to the application server.

If a new application server was added in step 2, skip step 5 and go to step 6.

If the **rcontext** parameter is not being specified in this procedure, skip step 5 and go to step 6.

If the **open** parameter value for all the associations assigned to the application server is **no** (shown in this step), skip step 5 and go to step 6.

5. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

For this example, enter this command.

chg-assoc : aname=assoc11 : open=no

chg-assoc : aname=assoc12 : open=no

chg-assoc : aname=assoc15 : open=no

chg-assoc : aname=assoc16 : open=no

chg-assoc : aname=assoc20 : open=no

When each of these commands have successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD

```



CAUTION: The IP connections using the associations specified in this step will not be able to carry any traffic when the **open** parameter is changed to **no**.

Repeat this step for all the associations assigned to the application server that have the **open=yes** parameter value.

If a default routing key with an application server name is being added in this procedure, skip steps 6, 7, 8, 9, and 10, and go to step 11.

If ITU-I or 14-bit ITU-N spare point codes are not being assigned to the routing key, or if ITU-I or 14-bit ITU-N spare point codes are shown in any routing keys shown in the **rtrv-app-rtkey** output in step 1, skip step 6 and go to step 7.

6. Display the status of the ITU National and International Spare Point Code Support feature by entering the **rtrv-ctrl-feat** command with the ITU National and International Spare Point Code Support feature part number.

Enter this command.

rtrv-ctrl-feat : partnum=893013601

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Spare Point Code Support	893013601	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ITU National and International Spare Point Code Support feature is not enabled, perform the “Activating the ITU National and International Spare Point Code Support feature” procedure in the *Database Administration Manual - SS7* and enable and turn on the ITU National and International Spare Point Code Support feature.

- The DPC of the routing key cannot be the APC of an IPGWx linkset or an SAPC assigned to an IPGWx linkset.

Display the names of the IPGWx linksets by entering the **rept-stat-iptps** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

IP TPS USAGE REPORT

THRESH  CONFIG          TPS      PEAK      PEAKTIMESTAMP
-----
SYSTEM
RLGHNCXA03W 100%    50000  TX:    7200    7600  05-02-10 11:40:04
                  RCV:    7200    7600  05-02-10 11:40:04
-----
LSN
LSGW1201      80%    10000  TX:    7200    7600  05-02-10 11:40:04
                  RCV:    7200    7600  05-02-10 11:40:04
LSGW1204      80%    10000  TX:    6700    7600  05-02-10 11:40:04
                  RCV:    6500    7600  05-02-10 11:40:04
LSGW1207      80%    10000  TX:    7300    7450  05-02-10 11:40:04
                  RCV:    7300    7450  05-02-10 11:40:04
LSGW1211      80%    10000  TX:    7400    7450  05-02-10 11:40:04
                  RCV:    7400    7450  05-02-10 11:40:04
-----
Command Completed.
```

- Display the IPGWx linksets shown in the **rept-stat-iptps** output in step 7 using the **rtrv-ls** command and specifying the name of the linkset shown in step 7.

For this example, enter these commands.

rtrv-ls:lsn=lsgw1201

This is an example of the possible output.

```
rlghncxa03w 06-10-28 16:31:35 GMT EAGLE5 36.0.0

LSN          APCA  (SS7)  SCRNL3T  SLT      GWS  GWS  GWS
lsgw1201     240-020-000  scr1  1    1    yes A    1    off off off yes  off

IPGWAPC  MATLSN      IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
yes      -----  10000  70      % 70      % CdPA
```

LOC	LINK	SLC	TYPE	L2T SET	BPS	L1 MODE	TSET	ECM	PCR N1	PCR N2
LOC	LINK	SLC	TYPE	LP SET	BPS	ATM TSEL		VCI	VPI	LL
LOC	LINK	SLC	TYPE	LP SET	BPS	ATM TSEL		VCI	VPI	E1ATM CRC4 SI SN
LOC	LINK	SLC	TYPE	IPLIML2						
LOC	LINK	SLC	TYPE							
1201	A	0	SS7IPGW							
LOC	LINK	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	E1 LOC	E1 PORT TS
LOC	LINK	SLC	TYPE	L2T SET	BPS	ECM	PCR N1	PCR N2	T1 LOC	T1 PORT TS

Link set table is (14 of 1024) 1% full

rtrv-ls:lsn=lsgw1204

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
                                L3T SLT                      GWS GWS GWS
LSN          APCN  (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
lsgw1204      2968      none 1 1 no A 1  off off off --- off

CLLI          TFATCABMLQ  MTPRSE  ASL8  SLSRSB  MULTGC  ITUTFR
-----      1          ---    ---    1      no      off

IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
yes          ----- 10000 70      % 70      % CdPA

LOC LINK SLC TYPE      L2T    L1      PCR  PCR
SET BPS  MODE TSET  ECM  N1    N2

LOC LINK SLC TYPE      LP      ATM      VCI  VPI  LL
SET BPS  TSEL          VCI  VPI  CRC4 SI SN

LOC LINK SLC TYPE      LP      ATM      VCI  VPI  E1ATM
SET BPS  TSEL          VCI  VPI  CRC4 SI SN

LOC LINK SLC TYPE      IPLIML2

LOC LINK SLC TYPE

1204 A    0    IPGWI

LOC LINK SLC TYPE      L2T    L1      PCR  PCR
SET BPS  ECM  N1    N2  LOC  PORT TS

LOC LINK SLC TYPE      L2T    L1      PCR  PCR
SET BPS  ECM  N1    N2  LOC  PORT TS

SAPCI
1-010-1
```

Link set table is (14 of 1024) 1% full.

rtrv-ls:lsn=lsgw1207

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
                                L3T SLT                      GWS GWS GWS
LSN          APCI  (SS7)  SCRNLST LNKS ACT MES DIS SLSCI NIS
lsgw1207      2-154-0      none 1 1 no A 1  off off off --- off
```

```

CLLI          TFATCABMLQ  MTPRSE  ASL8  SLSRSB  MULTGC  ITUTFR
----- 1          ---  ---  1          no      off

IPGWAPC  MATELSN      IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
yes      ----- 10000 70      % 70      % CdPA

LOC  LINK  SLC  TYPE      L2T      L1      PCR  PCR
      SET  BPS      MODE  TSET  ECM  N1  N2

LOC  LINK  SLC  TYPE      LP      ATM
      SET  BPS      TSEL      VCI      VPI  LL

LOC  LINK  SLC  TYPE      LP      ATM
      SET  BPS      TSEL      VCI  VPI  CRC4  SI  SN  E1ATM

LOC  LINK  SLC  TYPE      IPLIML2

LOC  LINK  SLC  TYPE
1207 A      0  IPGWI

LOC  LINK  SLC  TYPE      L2T      PCR  PCR  E1  E1
      SET  BPS      ECM  N1  N2  LOC  PORT  TS

LOC  LINK  SLC  TYPE      L2T      PCR  PCR  T1  T1
      SET  BPS      ECM  N1  N2  LOC  PORT  TS

SAPCN
5823

```

Link set table is (14 of 1024) 1% full.

rtrv-ls:lsn=ls gw1211

This is an example of the possible output.

```

rlghncxa03w 06-10-28 16:31:35 GMT EAGLE5 36.0.0
                                L3T  SLT                                GWS  GWS  GWS
LSN          APCA  (SS7)  SCRNLST  LNKS  ACT  MES  DIS  SLSCI  NIS
ls gw1211    010-130-057  scr1  1  1  yes  A  1  off  off  off  yes  off

IPGWAPC  MATELSN      IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
yes      ----- 10000 70      % 70      % CdPA

LOC  LINK  SLC  TYPE      L2T      L1      PCR  PCR
      SET  BPS      MODE  TSET  ECM  N1  N2

LOC  LINK  SLC  TYPE      LP      ATM
      SET  BPS      TSEL      VCI      VPI  LL

LOC  LINK  SLC  TYPE      LP      ATM
      SET  BPS      TSEL      VCI  VPI  CRC4  SI  SN  E1ATM

LOC  LINK  SLC  TYPE      IPLIML2

LOC  LINK  SLC  TYPE
1211 A      0  SS7IPGW

LOC  LINK  SLC  TYPE      L2T      PCR  PCR  E1  E1
      SET  BPS      ECM  N1  N2  LOC  PORT  TS

LOC  LINK  SLC  TYPE      L2T      PCR  PCR  T1  T1
      SET  BPS      ECM  N1  N2  LOC  PORT  TS

```

Link set table is (14 of 1024) 1% full

If the DPC of the routing key is shown in the **rtrv-ls** outputs in this step, choose another DPC value for the routing key that is not shown in the **rtrv-ls** outputs in this step.

NOTE: If the SI value of the routing key being added is a value other than 4, 5, or 13, skip steps 9 and 10, and go to step 11.

9. Verify that the ISUP Routing over IP feature is on, by entering the **rtrv-feat** command.

If the ISUP Routing over IP feature is on, the **IPISUP** field should be set to **on**. For this example, the ISUP Routing over IP feature is off.

NOTE: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

If the ISUP Routing over IP feature is on, skip step 10 and go to step 11.

10. Turn the ISUP Routing over IP feature on by entering this command.

chg-feat:ipisup=on

NOTE: Once the ISUP Routing over IP feature is turned on with the **chg-feat** command, it cannot be turned off.

The ISUP Routing over IP feature must be purchased before you turn this feature on with the **chg-feat** command. If you are not sure if you have purchased the ISUP Routing over IP feature, contact your Tekelec Sales Representative or Account Representative.

When the **chg-feat** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

11. Add a routing key entry to the database by entering the **ent-appl-rtkey** command.

The parameters required for the **ent-appl-rtkey** command are determined by the type of routing key being added and the service indicator value in the routing key. See [Table 6-15](#) for the parameter combinations that can be used for the type of routing key being added to the database. For this example, enter these commands.

ent-appl-

rtkey:dpci=3-009-3:si=5:opci=4-100-3:cics=100 :cice=500:asname=as3:type=full

ent-appl-

rtkey:dpci=1-050-2:si=5:opci=6-077-7:cics=200 :cice=300:asname=as20:type=full:rcontext=2000

NOTE: A routing key cannot be added with the application server **as4**, displayed in step 3, because application server **as4** is assigned to a routing key containing a routing context value. Only one application server can be assigned to a routing key containing a routing context value.

When each of these commands have successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-APPL-RTKEY: MASP A - COMPLTD
```

12. Verify the new routing key information in the database by entering the **rtrv-appl-rtkey** command with the routing key parameters specified in step 11 (**dpc**, **si**, **opc**, **cics**, **cice**, **ssn**, **asname**, **type**, and **rcontext**, as applicable) with the **display=all** parameter.

For this example, enter these commands.

```
rtrv-appl-
rtkey:dpci=3-009-3:si=5:opci=4-100-3:cics=100 :cice=500:asname=as3:type
=full:display=all
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT  DPCI          SI SSN OPCI          CICS    CICE    LOC
-----  -
          3-009-3      5 ---  4-100-3      100      500     STATIC

      ADPTR  TYPE      ASNAME
      M3UA   FULL      as3

      ANAMES
      assoc11          assoc12

STATIC Route Key table is (12 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (12 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

```
rtrv-appl-
rtkey:dpci=1-050-2:si=5:opci=6-077-7:cics=200 :cice=300:asname=as20:typ
e=full:rcontext=2000:display=all
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT  DPCI          SI SSN OPCI          CICS    CICE    LOC
-----  -
2000      1-050-2      5 ---  6-077-7      200      300     STATIC

      ADPTR  TYPE      ASNAME
      SUA   FULL      as20

      ANAMES
      assoc20

STATIC Route Key table is (12 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (12 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

NOTE: If the open parameter value of the associations assigned to the routing key added in this procedure was not changed (step 5 was not performed), skip step 13 and go to step 14.

13. Change the value of the **open** parameter of the associations that were changed in step 5 to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

For this example, enter these commands.

```
chg-assoc:aname=assoc11:open=yes
```

```
chg-assoc:aname=assoc12:open=yes
```

```
chg-assoc:aname=assoc15:open=yes
```

```
chg-assoc:aname=assoc16:open=yes
```

chg-assoc : aname=assoc20 : open=yes

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
CHG-ASSOC: MASP A - COMPLTD;
```


Repeat this step for all the associations that were changed in step 5.


14. Back up the new changes using the **chg-db : action=backup : dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```



Flowchart 6-17. Adding a Routing Key Containing an Application Server







Notes:

1. If the *adapter* parameter value for the application server is SUA, and a new application server is specified for the routing key, the *rcontext* parameter is required.
2. If the *adapter* parameter value for the application server is M3UA, and a new application server is specified for the routing key, the *rcontext* parameter is optional.
3. If the application server is assigned to other routing keys, the *rcontext* parameter cannot be specified for this routing key. An application server can be assigned to only one routing key that contains an *rcontext* parameter value.







Adding a Network Appearance

The network appearance field identifies the SS7 network context for the message, for the purpose of logically separating the signaling traffic between the SGP (signaling gateway process) and the ASP (application server process) over a common SCTP (stream control transmission protocol) association. This field is contained in the DATA, DUNA, DAVA, DRST, DAUD, SCON, and DUPU messages.

The network appearance is provisioned in the database using the **ent-na** command with these parameters.

:na – the 32-bit value of the network appearance, from 0 to 4294967295.

:type – the network type of the network appearance, **ansi** (ANSI), **itui** (ITU-I), **itun** (14-bit ITU-N), **itun24** (24-bit ITU-N), **ituis** (ITU-I Spare), **ituns** (14-bit ITU-N Spare).

:gc – the specific ITU-N group code associated with the network appearance.

The **gc** parameter can be specified only with the **type=itun** or **type=ituns** parameters.

The **gc** parameter must be specified with the **type=itun** or **type=ituns** parameters if the ITU Duplicate Point Code feature is on. If the ITU Duplicate Point Code feature is off, the **gc** parameter cannot be specified.

The **gc** parameter value must be shown in the **rtrv-spc** or **rtrv-sid** outputs.

The **ituis** or **ituns** parameters can be specified only if the ITU National and International Spare Point Code Support feature is enabled.

Procedure

1. Display the network appearances in the database with the **rtrv-na** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
TYPE  GC          NA
ANSI   --          100
ITUN   FR  4000000000
ITUN   GE  1000000000
```

NOTE: If the gc parameter is not being specified in this procedure, skip step 2 and step 3, and go to step 4.

2. Display the self-identification of the EAGLE 5 ISS using the **rtrv-sid** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
PCA          PCI          PCN          CLLI          PCTYPE
001-001-001  1-200-6          13482          rlghncxa03w    OTHER

CPCA
002-002-002      002-002-003      002-002-004      002-002-005
002-002-006      002-002-007      002-002-008      002-002-009
004-002-001      004-003-003      144-212-003

CPCA (LNP)
005-005-002      005-005-004      005-005-005

CPCI
1-001-1          1-001-2          1-001-3          1-001-4

CPCN
02091            02092            02094            02097
02191            02192            11177
```

If the desired group code is shown in the **rtrv-sid** output, skip step 3 and go to step 4.

3. Display the secondary point codes in the database with the **rtrv-spc** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
SPC (Secondary Point Codes)

SPCA
001-010-010
002-010-010
```

```
003-010-010
```

```
SPC-I
```

```
1-253-5
```

```
2-254-6
```

```
3-255-7
```

```
SPC-N
```

```
10-01-11-1-fr
```

```
13-02-12-0-ge
```

```
13-02-12-0-uk
```

```
SPC-N24
```

```
none
```

Secondary Point Code table is (9 of 40) 23% full

If the desired group code is not shown in the **rtrv-spc** or **rtrv-sid** outputs, go to the “Adding a Secondary Point Code” procedure in the *Database Administration Manual - SS7* to turn the ITU Duplicate Point Code feature on, and add a secondary point code to the database with the desired group code value.

If the **ituis** or **ituns** parameters will not be specified in this procedure, skip step 4 and go to step 5.

If the **ituis** or **ituns** parameters will be specified in this procedure, and ITU-I spare or 14-bit ITU-N spare network appearances are shown in the **rtrv-na** output in step 1, or ITU-I spare or 14-bit ITU-N spare point codes are shown in the **rtrv-sid** output in step 2, skip step 4 and go to step 5.

4. Display the status of the ITU National and International Spare Point Code Support feature by entering the **rtrv-ctrl-feat** command with the ITU National and International Spare Point Code Support feature part number. Enter this command.

```
rtrv-ctrl-feat:partnum=893013601
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Spare Point Code Support	893013601	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ITU National and International Spare Point Code Support feature is not enabled, perform the “Activating the ITU National and International Spare Point Code Support feature” procedure in the *Database Administration Manual - SS7* and enable and turn on the ITU National and International Spare Point Code Support feature.

5. Add the network appearance to the database with the **ent-na** command.

If the **gc** parameter is specified with the **ent-na** command, the **gc** parameter value must be shown in the **rtrv-sid** output in step 2, or assigned to an ITU-N point code (SPC-N) shown in the **rtrv-spc** output in step 3. For this example, enter these commands.

```
ent-na:na=1000:type=itui
```

```
ent-na:na=3:type=itun24
```

```
ent-na:na=150000:type=itun:gc=uk
```

```
ent-na:na=2000:type=ituis
```

```
ent-na:na=5000:type=ituns:gc=sp
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-NA: MASP A - COMPLTD
```


6. Verify the changes using the **rtrv-na** command. This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
TYPE      GC      NA
ANSI      --      100
ITUI      --      1000
ITUN      uk      150000
ITUN      fr      40000000000
ITUN      ge      10000000000
ITUN24    --      3
ITUIS     --      2000
ITUNS     sp      5000
```


7. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 6-18. Adding a Network Appearance





Activating the Large BICC MSU Support for IP Signaling Feature

This procedure is used to enable and turn on the Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature using the feature's part number and a feature access key.

The feature access key for the Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key provided by Tekelec. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number of the Large BICC MSU Support for IP Signaling feature, 893018401.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

: lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the `ent - serial - num` command must be entered twice, once to add the correct serial number to the database with the `serial` parameter, then again with the `serial` and the `lock=yes` parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature has been enabled, the feature must be turned on with the **chg-ctrl-feat** command. The **chg-ctrl-feat** command uses these parameters:

: partnum – The Tekelec-issued part number of the Large BICC MSU Support for IP Signaling feature, 893018401.

: status=on – used to turn the Large BICC MSU Support for IP Signaling feature on.

Once the Large BICC MSU Support for IP Signaling feature has been turned on, it can be turned off. For more information about turning the Large BICC MSU Support for IP Signaling feature off, go to the [Turning the Large BICC MSU Support for IP Signaling Feature Off](#) procedure.

The status of the features in the EAGLE 5 ISS is shown with the **rtrv-ctrl-feat** command.

The Large BICC MSU Support for IP Signaling feature allows the EAGLE 5 ISS to process BICC messages with a service information field (SIF) that is larger than 272 bytes. The large BICC messages are processed only on single-slot EDCMs and E5-ENET cards. There are certain software components that if enabled or provisioned, that will not process large BICC messages even if the Large BICC MSU Support for IP Signaling feature is enabled and turned on. UIMs are displayed when most of these circumstances occur. These UIMs are:

- UIM 1333 – Displayed when a large BICC message is received on an M3UA association and the Large BICC MSU Support for IP Signaling feature is not enabled or is enabled and turned off. The large BICC message is discarded.
- UIM 1334 – Displayed when a TALI IPGWx socket receives a BICC message with an SIF greater than 272 bytes.
- UIM 1350 – Displayed when a M2PA IP connection receives BICC message with an SIF greater than 272 bytes and the Large BICC MSU Support for IP Signaling feature is not enabled or is enabled and turned off. The large BICC message is discarded.
- UIM 1351 – Displayed when a TALI IPLIMx socket assigned to a single-slot EDCM receives a BICC message with an SIF greater than 272 bytes.
- UIM 1352 – Displayed when a BICC message with an SIF greater than 272 bytes is received; the Large BICC MSU Support for IP Signaling feature is enabled and turned on; there are routes available for the destination point code; but the selected outbound card does not support large BICC messages.
- UIM 1353 – Displayed when a large BICC message passes a gateway screening screenset that redirects messages for the Database Transport Access (DTA) feature. Large BICC messages are not redirected for the DTA feature.
- UIM 1354 – Displayed when a large BICC message passes a gateway screening screenset that copies messages for the STPLAN feature. Large BICC messages are not copied for the STPLAN feature.

For more information on these UIMs, refer to the *Maintenance Manual*.

NOTE: Large BICC messages are not monitored by the EAGLE 5 Integrated Monitoring Support feature and are not sent to the IMF. A UIM is not generated.

Procedure

1. Display the status of the controlled features by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:15:37 GMT EAGLE5 37.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Large System # Links	893005910	on	2000
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the Large BICC MSU Support for IP Signaling feature is enabled and turned on, no further action is necessary. This procedure does not need to be performed.

If the Large BICC MSU Support for IP Signaling feature is enabled and but not turned on, skip steps 2 through 6 and go to step 7.

If the Large BICC MSU Support for IP Signaling feature is not enabled, go to step 2.

NOTE: If the **rtrv-ctrl-feat output in step 1 shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, skip steps 2 through 5, and go to step 6.**

2. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 3, 4, and 5, and go to step 6. If the serial number is correct but not locked, skip steps 3 and 4, and go to step 5. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into step 3 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 2, if the serial number shown in step 2 is correct, or with the serial number shown in step 4, if the serial number was changed in step 3, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Enable the Large BICC MSU Support for IP Signaling feature with the **enable-ctrl-feat** command specifying the part number for the Large BICC MSU Support for IP Signaling feature and the feature access key. Enter this command.

enable-ctrl-feat:partnum=893018401:fak=<Large BICC MSU Support for IP Signaling feature access key>

NOTE 1: A temporary feature access key cannot be specified to enable this feature.

NOTE 2: The values for the feature access key (the fak parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

7. Turn the Large BICC MSU Support for IP Signaling feature on with the **chg-ctrl-feat** command specifying the part number for the Large BICC MSU Support for IP Signaling feature and the **status=on** parameter. Enter this command.

chg-ctrl-feat:partnum=893018401:status=on

When the **chg-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 07-05-28 21:15:37 GMT EAGLE5 37.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the Large BICC MSU Support for IP Signaling feature part number. Enter this command.

rtrv-ctrl-feat:partnum=893018401

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large BICC MSU for IP Sig	893018401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				


The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-19. Activating the Large BICC MSU Support for IP Signaling Feature







Removing IETF M3UA and SUA Components

This section describes how to remove the following components from the database.

- An IPGWx Card – Perform the [Removing an IPGWx Card](#) procedure
- An IPGWx Signaling Link – Perform the [Removing an IPGWx Signaling Link](#) procedure
- An IP Host – Perform the [Removing an IP Host Assigned to an IPGWx Card](#) procedure
- An IP Route – Perform the [Removing an IP Route](#) procedure
- An M3UA or SUA Association – Perform the [Removing an M3UA or SUA Association](#) procedure
- An Association from an Application Server – Perform the [Removing an Association from an Application Server](#) procedure
- A Routing Key – Perform the [Removing a Routing Key Containing an Application Server](#) procedure

- A Network Appearance – Perform the [Removing a Network Appearance](#) procedure

Removing an IPGWx Card

Use this procedure to remove an IP card, a card running one of these applications: **ss7ipgw** or **ipgwi**, from the database using the **dlt-card** command.

The card cannot be removed if it does not exist in the database. Prior to removing the card from the database, the signaling links assigned to the card must be removed.



CAUTION: If the IPLIMx card is the last IP card in service, removing this card from the database will cause traffic to be lost.

Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-15 16:34:56 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101    TSM          SCCP
1102    TSM          GLS
1104    ACMENET      STPLAN
1113    GSPM         EOAM
1114    TDM-A
1115    GSPM         EOAM
1116    TDM-B
1117    MDAL
1201    LIMDS0       SS7ANSI    lsn1           A    0    lsn2           B    1
1202    LIMV35       SS7GX25    lsn2           A    0
1203    LIMV35       SS7ANSI    lsn2           A    0    lsn1           B    1
1204    LIMATM       ATMANSI    atm2gw         A    0
1205    DCM          IPLIM      ipnode1        A    0    ipnode3        B    1
1207    DCM          IPLIM      ipnode2        A    0
1303    DCM          IPLIM      ipnode1        A    0    ipnode3        B    1
1305    DCM          IPLIM      ipnode4        A    0
```

Select a card whose application is either SS7IPGW or IPGWI.

Perform the [Removing an IPGWx Signaling Link](#) procedure to remove all the signaling links assigned to the card, shown in the **LINK** column of the **rtrv-card** output.

The card location is shown in the **CARD** field of the **rtrv-card** command output. No entries in the **LSET NAME**, **LINK**, and **SLC** columns mean that no signaling link is assigned to the card.

2. Remove the card from the database using the **dlt-card** command.

The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter these commands.

```
dlt-card:loc=1205
```

```
dlt-card:loc=1207
```

When these commands have successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-CARD: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-card** command and specifying the card that was removed in step 2.

For this example, enter these commands.

rtrv-card:loc=1205

rtrv-card:loc=1207

When these commands have successfully completed, this message appears.


E2144 Cmd Rej: Location invalid for hardware configuration

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
 BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
 BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-20. Removing an IPGWx Card



Removing an IPGWx Signaling Link

This procedure is used to remove an IPGWx signaling link from the database using the **dlt-slk** command. The **dlt-slk** command uses these parameters.

:loc – The card location of the IP card that the IP signaling link is assigned to.

:link – The signaling link on the card specified in the **loc** parameter.

:force – This parameter must be used to remove the last link in a linkset without having to remove all of the routes that referenced the linkset.

The **tfatcabmlq** parameter (TFA/TCA Broadcast Minimum Link Quantity), assigned to linksets, shows the minimum number of links in the given linkset (or in the combined link set in which it resides) that must be available for traffic. When the number of signaling links in the specified linkset is equal to or greater than the value of the **tfatcabmlq** parameter, the status of the routes that use the specified linkset is set to allowed and can carry traffic. Otherwise, these routes are restricted. The value of the **tfatcabmlq** parameter cannot exceed the total number of signaling links contained in the linkset.

The **dlt-slk** command makes sure that the number of signaling links assigned to a linkset is greater than or equal to the value of the **tfatcabmlq** parameter. If the number of signaling links associated with a linkset drops below the value of the **tfatcabmlq** parameter for that linkset, the **tfatcabmlq** value for that linkset is automatically decremented. The value of the **tfatcabmlq** parameter for a specified linkset can be verified using the **rtrv-ls:lsn=<linkset name>** command specifying the name of the linkset. The **tfatcabmlq** parameter value is shown in the **tfatcabmlq** field of the **rtrv-ls** command output.

Canceling the RTRV-SLK Command

Because the **rtrv-slk** command used in this procedure can output information for a long period of time, the **rtrv-slk** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-slk** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-slk** command was entered, from another terminal other than the terminal where the **rtrv-slk** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current link configuration using the **rtrv-slk** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:16:37 GMT EAGLE5 36.0.0
      L2T      L1      PCR      PCR
LOC  LINK  LSN      SLC TYPE  SET  BPS  MODE  TSET  ECM  N1  N2
1201  A    ls01      0  LIMDS0  1  56000  ---  ---  BASIC  ---  -----
1201  B    lsa1      0  LIMDS0  1  56000  ---  ---  BASIC  ---  -----
1202  B    ls02      0  LIMV35  2  64000  DTE  ---  BASIC  ---  -----
1203  A    ls03      0  LIMDS0  3  56000  ---  ---  BASIC  ---  -----
1203  B    lsa2      0  LIMDS0  1  56000  ---  ---  BASIC  ---  -----
1204  B    ls01      1  LIMDS0  1  56000  ---  ---  BASIC  ---  -----
1205  A    lsa3      0  LIMV35  4  64000  DCE  ON    BASIC  ---  -----
1206  A    ls02      1  LIMV35  2  64000  DTE  ---  BASIC  ---  -----
1207  A    lsn1207a    0  LIMDS0  1  56000  ---  ---  BASIC  ---  -----
1207  B    lsn1207b    0  LIMDS0  1  56000  ---  ---  BASIC  ---  -----
1208  B    ls03      1  LIMDS0  3  56000  ---  ---  BASIC  ---  -----
1212  A    ls04      0  LIMV35  4  64000  DTE  ---  BASIC  ---  -----
1213  B    ls05      0  LIMDS0  5  56000  ---  ---  BASIC  ---  -----
1214  A    lsn1214a    0  LIMV35  2  64000  DTE  ---  PCR   76  3800
1214  B    lsa3      1  LIMV35  4  64000  DCE  ON    BASIC  ---  -----
```

1215	A	ls05	1	LIMDS0	5	56000	---	---	BASIC	---	-----
1301	B	ls06	0	LIMV35	6	56000	DTE	---	BASIC	---	-----
1304	B	ls06	1	LIMV35	6	56000	DTE	---	BASIC	---	-----
1308	A	ls06	2	LIMV35	6	56000	DTE	---	BASIC	---	-----
1311	A	ls01	2	LIMDS0	1	56000	---	---	BASIC	---	-----
1311	A1	ls05	2	LIMDS0	5	56000	---	---	BASIC	---	-----
1311	B	ls03	2	LIMDS0	3	56000	---	---	BASIC	---	-----
1311	B1	ls07	1	LIMDS0	7	56000	---	---	BASIC	---	-----
1313	A	ls07	0	LIMDS0	7	56000	---	---	BASIC	---	-----
1315	A	lsn5	0	LIMV35	11	64000	DTE	OFF	BASIC	---	-----
1317	A	ls17	0	LIMV35	11	64000	DTE	OFF	BASIC	---	-----

LOC	LINK	LSN	SLC	TYPE	LP	ATM	VCI	VPI	LL
					SET	TSEL			
1302	A	atmansio	0	LIMATM	3	EXTERNAL	35	15	0
1305	A	atmansii	0	LIMATM	4	INTERNAL	100	20	2
1318	A	atmansio	1	LIMATM	9	LINE	150	25	4

LOC	LINK	LSN	SLC	TYPE	LP	ATM	VCI	VPI	CRC4	SI	SN
					SET	TSEL					
2101	A	atmitu1	0	LIME1ATM	5	LINE	150	2	ON	1	20
2105	A	atmitu1	1	LIME1ATM	5	LINE	35	15	ON	2	15

LOC	LINK	LSN	SLC	TYPE	IPLIML2
2202	A	lsnlp1	0	IPLIM	SAALTALI
2205	A	lsnip1	1	IPLIM	M2PA
2204	B	lsnlp2	0	IPLIM	M2PA
2213	A	lsnip5	0	IPLIMI	M2PA
2215	A	lsnlp2	1	IPLIM	SAALTALI

LOC	LINK	LSN	SLC	TYPE
2207	A	lsnlp3	0	SS7IPGW
2211	A	lsnlp4	0	IPGWI

LOC	LINK	LSN	SLC	TYPE	L2T	PCR	PCR	E1	E1
					SET	N1	N2	LOC	PORT

No Links Set Up.

LOC	LINK	LSN	SLC	TYPE	L2T	PCR	PCR	T1	T1
					SET	N1	N2	LOC	PORT

No Links Set Up.

SLK table is (31 of 1200) 6% full

- Any in-service IP connections on the signaling link being removed in this procedure must be placed out of service.

Have the far-end node for the signaling link being removed perform these actions:

- Place the TALI sockets in the NEA-FEP state.
- Place the M3UA or SUA associations in either the ASP-INACTIVE or ASP-DOWN state.

- Display the IP link associated with the card that the signaling link being removed the database is assigned to. Enter the **rtrv-ip-lnk** command with the card location of the signaling link being removed shown in step 1. For this example, enter this command.

rtrv-ip-lnk:loc=2207

The following is an example of the possible output.

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
2207	A	192.1.1.10	255.255.255.128	HALF	10	802.3	NO	NO
2207	B	-----	-----	HALF	10	DIX	NO	NO

- Display the IP host information associated with the IP link by entering the **rtrv-ip-host** command with the IP address shown in step 3. For this example, enter these commands.

rtrv-ip-host:ipaddr=192.001.001.010

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
```

```
LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1_2207
```

IP Host table is (11 of 512) 2% full

5. Display the sockets associated with the local host name shown in step 4 by entering the **rtrv-appl-sock** command. For this example, enter this command.

rtrv-appl-sock:lhost=ipnode1_2207

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
```

```
SNAME KC_HLR1_2207
```

```
LINK      A
LHOST     IPNODE1_2207
RHOST     KC_HLR2
LPORT     7000          RPORT     7001
SERVER    YES          DCMP      1
REXMIT    FIXED        RTT       60
OPEN      YES          ALW       YES
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

NOTE: If the specified socket name is not in the database, the rtrv-appl-sock output shows no socket information.

6. Change the **open** and **alw** parameter values in the socket shown in step 5 using the **chg-appl-sock** command with the **open=no** and **alw=no** parameters, as necessary. For example, enter this command.

NOTE: If there is no socket shown in step 4, or the open and alw parameter values of the socket shown in step 4 are NO, skip this step and go to step 6.

chg-appl-sock:sname=kc_hlr1_2207:open=no:alw=no

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

```
CHG-APPL-SOCK: MASP A - COMPLTD
```

7. Display the associations associated with the local host name shown in step 5 by entering the **rtrv-assoc** command. For this example, enter this command.

rtrv-assoc:lhost=ipnode1_2207

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```
          CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc1     2207 A    A    M3UA    1030  1030 YES  YES
```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 2207

8. Change the value of the **open** and **alw** parameters to **no** by specifying the **chg-assoc** command with the **open=no** and **alw=no** parameters, as necessary. For this example, enter this command.

NOTE: If there is no association shown in step 6, or the **open** and **alw** parameter values of the association shown in step 6 are **no**, skip this step and go to step 8.

chg-assoc:aname=assoc1:open=no:alw=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

9. Deactivate the link to be removed using the **dact-slk** command, using the output from step 1 to obtain the card location and **link** parameter value of the signaling link to be removed. For this example, enter these commands.

dact-slk:loc=2207:link=a

When each of these command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

10. Verify that the link is out of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-slk** command with the card location and **link** parameter values specified in step 9. For this example, enter these commands.

rept-stat-slk:loc=2207:link=a

This is an example of the possible output.

```
rlghncxa03w 06-10-23 13:06:25 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
2207,A   ls04      ls04clli  OOS-MT   Unavail   ----
  ALARM STATUS      = *    0235 REPT-LNK-MGTINH: local inhibited
  UNAVAIL REASON    = LI
```

11. Place the card that contains the signaling link shown in step 10 out of service by entering the **rmv-card** command specifying the card location shown in step 10. For this example, enter this command.

rmv-card:loc=2207

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:12 GMT EAGLE5 36.0.0
Card has been inhibited.
```

12. Verify that the card has been inhibited by entering the **rept-stat-card** command with the card location specified in step 11. For this example, enter this command.

rept-stat-card:loc=2207

This is an example of the possible output.

```
rlghncxa03w 07-05-27 16:43:42 GMT EAGLE5 37.0.0
CARD  VERSION  TYPE  APPL  PST      SST      AST
2207  114-001-000 DCM   SS7IPGW  OOS-MT-DSBLD  Isolated  -----
  ALARM STATUS      = **    0013 Card is isolated from the system
  BPDCM GPL         = 002-102-000
  IMT BUS A         = Disc
  IMT BUS B         = Disc
  SIGNALING LINK STATUS
    SLK  PST      LS      CLLI      E5IS
    A    OOS-MT   lsnlp1  -----  INACTIVE
```


Command Completed.

13. Remove the signaling link from the EAGLE 5 ISS using the **dlt-slk** command. If there is only one signaling link in the linkset, the **force=yes** parameter must be specified to remove the signaling link.

In the example used in this procedure, the signaling link is the last signaling link in the linkset. Enter this command.

dlt-slk:loc=2207:link=a:force=yes

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 08:41:17 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD
```

14. Verify the changes using the **rtrv-slk** command, with the card location and link values specified in step 13. For this example, enter this command.

rtrv-slk:loc=2207:link=a

When the **rtrv-slk** command has completed, the specified signaling link is not shown in the **rtrv-slk** output, as shown in this example.

```
rlghncxa03w 07-05-19 21:16:37 GMT EAGLE5 37.0.0
```


```
LOC LINK LSN          SLC TYPE
```


No Links Set up.

15. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-21. Removing an IPGWx Signaling Link





Removing an IP Host Assigned to an IPGWx Card

This procedure removes an IP host that is assigned to an IPGWx card using the **dlt-ip-host** command.

The **dlt-ip-host** command uses the following parameter.

:host—Hostname. The hostname to be removed. This parameter identifies the logical name assigned to a device with an IP address.

No sockets and associations can reference the host name being removed in this procedure.

The sockets referencing the host name can be removed by performing the [Removing a Socket that is Assigned to an IPGWx Signaling Link](#) procedure or the host name in these sockets can be changed by performing the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure. The host name assigned to sockets is displayed in the **rtrv-appl-sock** outputs.

The associations referencing the host name can be removed by performing the [Removing an M3UA or SUA Association](#) procedure or the host name in these associations can be changed by performing the [Changing an M3UA or SUA Association](#) procedure. The host name assigned to associations is displayed in the **rtrv-assoc** outputs.

Procedure

1. Display the current IP host information in the database by entering the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0

LOCAL IPADDR    LOCAL HOST
192.1.1.10      IPNODE1-1201
192.1.1.12      IPNODE1-1203
192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.30      KC-HLR1
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
192.3.3.33      GW100. NC. TEKELEC. COM

REMOTE IPADDR    REMOTE HOST
150.1.1.5        NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (12 of 512) 2% full
```

2. Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-link** command. The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1303  A      192.1.1.10    255.255.255.128  HALF    10     802.3    NO    NO
1303  B      -----      -----      HALF    10     DIX       NO    NO
1305  A      192.1.1.12    255.255.255.0   ----    ---    DIX       YES   NO
1305  B      -----      -----      HALF    10     DIX       NO    NO
1313  A      192.1.1.14    255.255.255.0   FULL    100    DIX       NO    NO
1313  B      -----      -----      HALF    10     DIX       NO    NO
2101  A      192.1.1.20    255.255.255.0   FULL    100    DIX       NO    NO
2101  B      -----      -----      HALF    10     DIX       NO    NO
2103  A      192.1.1.22    255.255.255.0   FULL    100    DIX       NO    NO
2103  B      -----      -----      HALF    10     DIX       NO    NO
2105  A      192.1.1.24    255.255.255.0   FULL    100    DIX       NO    NO
2105  B      -----      -----      HALF    10     DIX       NO    NO
2205  A      192.1.1.30    255.255.255.0   FULL    100    DIX       NO    NO
2205  B      -----      -----      HALF    10     DIX       NO    NO
2207  A      192.1.1.32    255.255.255.0   FULL    100    DIX       NO    NO
2207  B      -----      -----      HALF    10     DIX       NO    NO
2213  A      192.1.1.50    255.255.255.0   FULL    100    DIX       NO    NO
2213  B      -----      -----      HALF    10     DIX       NO    NO
2301  A      192.1.1.52    255.255.255.0   FULL    100    DIX       NO    NO
2301  B      -----      -----      HALF    10     DIX       NO    NO
2305  A      192.3.3.33    255.255.255.0   FULL    100    DIX       NO    NO
2305  B      -----      -----      HALF    10     DIX       NO    NO
```

3. Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```

rlghncxa03w 07-05-28 09:12:36 GMT EAGLE5 37.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101    TSM        SCCP
1102    TSM        GLS
1113    GSPM        EOAM
1114    TDM-A
1115    GSPM        EOAM
1116    TDM-B
1117    MDAL
1201    LIMDS0     SS7ANSI    sp2            A    0    sp1            B    0
1203    LIMDS0     SS7ANSI    sp3            A    0
1204    LIMDS0     SS7ANSI    sp3            A    1
1206    LIMDS0     SS7ANSI    nsp3           A    1    nsp4           B    1
1207    LIMV35     SS7GX25    nsp1           A    0
1208    LIMV35     SS7GX25    nsp1           A    1
1216    ACMENET      STPLAN
1301    LIMDS0     SS7ANSI    sp6            A    1    sp7            B    0
1302    LIMDS0     SS7ANSI    sp7            A    1    sp5            B    1
1303    DCM         IPLIM      ipnode1        A    0    ipnode3        B    1
1305    DCM         IPLIM      ipnode4        A    0
1307    ACMENET      STPLAN
1313    DCM         SS7IPGW    ipgtwy1        A    0
2101    DCM         SS7IPGW    ipgtwy2        A    0
2103    DCM         SS7IPGW    ipgtwy3        A    0
2105    DCM         IPLIM      ipnode1        A1   1    ipnode5        B    2
2205    DCM         IPLIM      ipnode3        A2   0    ipnode6        B1   2
2207    DCM         IPLIM      ipnode5        A    0    ipnode4        B3   1
2213    DCM         IPLIM      ipnode5        A3   1    ipnode3        B2   2
2301    DCM         IPLIM      ipnode6        A    0    ipnode1        B    2
2305    DCM         IPLIM      ipnode6        A1   1    ipnode1        B1   3

```

Select an IP host whose IP address is assigned to a card running the SS7IPGW or IPGWI application.

4. Display the sockets referencing the host name being removed in this procedure by entering the **rtrv-appl-sock** command.

For this example, enter this command.

rtrv-appl-sock: lhost="IPNODE1-1205"

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME KC_HLR1_1103
LINK      A
LHOST     IPNODE1-1205
RHOST     KC_HLR2
LPORT     7000          RPORT     7001
SERVER    YES          DCMPS     1
REXMIT    FIXED        RTT        60
OPEN      YES          ALW        YES

```

IP Appl Sock/Assoc table is (4 of 4000) 1% full

If no sockets referencing the host name being removed in this procedure are shown in this step, go to step 5.

Any sockets referencing the host name must either be removed or the host name assigned to the socket must be changed. To remove the sockets, perform the [Removing a Socket that is Assigned to an IPGWx Signaling Link](#) procedure.

Go to step 5 after the sockets have been removed.

To change the host name assigned to the sockets, perform the [Changing the Attributes of a Socket on an IPGWx Signaling Link](#) procedure.

Go to step 5 after the host name assigned to the sockets have been changed.

5. Display the associations referencing the host name being removed in this procedure by entering the **rtrv-assoc** command with the local host name.

For this example, enter this command.

rtrv-assoc: lhost="IPNODE1-1205"

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
a2         1313 A    A    M3UA   7205  7001  NO   NO
```

```
IP Appl Sock/Assoc table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 3200 KB) on LOC = 1203
```

If no associations referencing the host name being removed in this procedure are shown in this step, go to step 6.

Any associations referencing the host name must either be removed or the host name assigned to the association must be changed.

To remove the associations, perform the [Removing an M3UA or SUA Association](#) procedure.

Go to step 6 after the associations have been removed.

To change the host name assigned to the associations, perform the [Changing an M3UA or SUA Association](#) procedure.

Go to step 6 after the host name assigned to the associations have been changed.

6. Delete IP host information from the database by entering the **dlt-ip-host** command.

For example, enter this command.

dlt-ip-host: host="IPNODE1-1205"

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
DLT-IP-HOST: MASP A - COMPLTD
```

7. Verify the changes by entering the **rtrv-ip-host** command with the host name specified in step 6.

For this example, enter this command.

rtrv-ip-host: host="IPNODE1-1205"

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:20:37 GMT EAGLE5 36.0.0
LOCAL IPADDR  LOCAL HOST
IP Host table is (10 of 512) 2% full
```


8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-22. Removing an IP Host Assigned to an IPGWx Card





Removing an IP Route

This procedure is used to remove an IP route from the database using the **dlt-ip-rte** command.

The **dlt-ip-rte** command uses these parameters.

:loc – The location of the IP card containing the IP route being removed.

:dest – The IP address of the remote host or network assigned to the IP route being removed.

:force – To remove the IP route, the IP card that the route is assigned to must be out of service, or the **force=yes** parameter must be specified with the **dlt-ip-rte** command. The **force=yes** parameter allows the IP route to be removed if the IP card is in service.



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

Procedure

1. Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20   255.255.0.0      150.1.1.50
1301 128.252.10.5     255.255.255.255  140.188.13.33
1301 128.252.0.0      255.255.0.0      140.188.13.34
1301 150.10.1.1       255.255.255.255  140.190.15.3
1303 192.168.10.1     255.255.255.255  150.190.15.23
1303 192.168.0.0      255.255.255.0    150.190.15.24
```

IP Route table is (6 of 1024) 1% full

2. Verify the state of the IP card containing the IP route being removed by entering the **rept-stat-card** command and specifying the card location of the IP card.

The IP card should be in the out-of-service maintenance-disabled (OOS-MT-DSBLD) in order to remove the IP route. If the IP card's state is out-of-service maintenance-disabled, the entry **OOS-MT-DSBLD** is shown in the **PST** column of the **rept-stat-card** output. For this example, enter this command.

rept-stat-card:loc=1301

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST      SST      AST
1301  114-000-000  DCM   SS7IPGW  IS-NR    Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST      LS      CLLI
A     IS-NR    nc001   -----
```

Command Completed.

NOTE: If the output of step 2 shows that the IP card's state is not OOS-MT-DSBLD, and you do not wish to change the state of the IP card, skip step 3 and go to step 4.

3. Change the IP card's state to OOS-MT-DSBLD using the **inh-card** command and specifying the card location of the IP card.

For this example, enter these commands.

inh-card:loc=1301

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Card has been inhibited.
```

4. Remove the IP route from the database using the **dlt-ip-rte** command.

If the state of the IP card is not OOS-MT-DSBLD, the **force=yes** parameter must be specified with the **dlt-ip-rte** command. For this example, enter this command.

```
dlt-ip-rte:loc=1301:dest=128.252.0.0
```



CAUTION: Removing an IP route while the IP card is still in service can result in losing the ability to route outbound IP traffic on the IP card. This can cause both TCP and SCTP sessions on the IP card to be lost.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-IP-RTE: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1212 132.10.175.20    255.255.0.0      150.1.1.50
1301 128.252.10.5     255.255.255.255  140.188.13.33
1301 150.10.1.1       255.255.255.255  140.190.15.3
1303 192.168.10.1     255.255.255.255  150.190.15.23
1303 192.168.0.0      255.255.0.0      150.190.15.24
```

IP Route table is (5 of 1024) 1% full

6. Place the IP card back into service by using the **alw-card** command.

NOTE: If the IP card containing the IP route that was removed from the database does not contain other IP routes, skip step 6 and go to step 7.

For example, enter this command.

```
alw-card:loc=1301
```

This message should appear.


```
rlghncxa03w 06-10-28 21:22:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

7. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-23. Removing an IP Route



Removing an M3UA or SUA Association

This procedure is used to remove an association from the database using the **dlt-assoc** command.

The **dlt-assoc** command uses one parameter, **aname**, the name of the association being removed from the database. The association being removed must be in the database.

The **open** parameter must be set to **no** before the association can be removed. Use the **chg-assoc** command to change the value of the **open** parameter.

The association being removed from the database cannot be assigned to an application server. This can be verified with the **rtrv-as** command. If the association is assigned to any application servers, go to the [Removing an Association from an Application Server](#) procedure and remove the association from the application servers.

Canceling the RTRV-ASSOC and RTRV-AS Commands

Because the **rtrv-assoc** and **rtrv-as** commands used in this procedure can output information for a long period of time, the **rtrv-assoc** and **rtrv-as** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** and **rtrv-as** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered, from another terminal other than the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

ANAME	CARD	IPLNK	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW
swbel32	1201	A	A	M3UA	1030	2345	YES	YES		
a2	1305	A	A	SUA	1030	2345	YES	YES		
a3	1307	A	A	SUA	1030	2346	YES	YES		
assoc1	1203	A	A1	M2PA	2048	1030	NO	NO		

2. Display the application servers referencing the association being removed from the database using the **rtrv-as** command with the name of the association being removed in this procedure.

For this example, enter this command.

```
rtrv-as:aname=swbel32
```

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

AS Name	Mode	Tr ms	Association Names
as1	LOADSHARE	2000	swbel32
as2	OVERRIDE	10	swbel32

AS Table is (2 of 250) 1% full

If the association is assigned to any application servers, go to the [Removing an Association from an Application Server](#) procedure and remove the association from the application servers.

3. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

NOTE: If the value of the open parameter for the association being removed from the database (shown in step 1) is no, skip this step and go to step 4.

For this example, enter this command.

chg-assoc : aname=swbel32 : open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

4. Remove the association from the database using the **dlt-assoc** command.

For this example, enter this command.

dlt-assoc : aname=swbel32

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
DLT-ASSOC: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-assoc** command with the name of the association specified in step 4.

For this example, enter this command.

rtrv-assoc : aname=swbel32


This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
IP Appl Sock table is (3 of 4000) 1% full
```

6. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-24. Removing an M3UA or SUA Association



Removing an Association from an Application Server

This procedure is used to remove an association from an application server using the **dlt-as** command.

The **dlt-as** command uses these parameters:

:asname – The application server name containing the association being removed in this procedure.

:aname – The name of the association being removed from the application server.

The association name and application server name combination must be in the database.

The **open** parameter value in the association assigned to the application server specified in the **dlt-as** command must be **no**. This can be verified with the **rtrv-assoc** command. Use the **chg-assoc** command to change the value of the **open** parameter.

If the association is the only association assigned to the application server, the application server is removed from the database. The application server cannot be removed from the database if it is assigned to a routing key. This can be verified with the **rtrv-appl-rtkey** command.

Canceling the RTRV-AS, RTRV-ASSOC, and RTRV-APPL-RTKEY Commands

Because the **rtrv-as**, **rtrv-assoc**, and **rtrv-appl-rtkey** commands used in this procedure can output information for a long period of time, the **rtrv-as**, **rtrv-assoc**, and **rtrv-appl-rtkey** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as**, **rtrv-assoc**, and **rtrv-appl-rtkey** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as**, **rtrv-assoc**, or **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as**, **rtrv-assoc**, or **rtrv-appl-rtkey** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as**, **rtrv-assoc**, or **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-as**, **rtrv-assoc**, or **rtrv-appl-rtkey** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the application servers in the database using the **rtrv-as** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name           Mode      Tr ms   Association Names
as1                LOADSHARE 10      assoc1
                  LOADSHARE 10      assoc2
                  LOADSHARE 10      assoc3
                  LOADSHARE 10      assoc5
                  LOADSHARE 10      assoc6

as2                OVERRIDE 10      assoc7
as3                LOADSHARE 10      assoc4

AS table is (3 of 250) 1% full.
```

2. Display the associations to be removed from the application server using the **rtrv-assoc** command and specifying the association name shown in the **rtrv-as** output in step 1.

For this example, enter this command.

rtrv-assoc:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```

ANAME assoc1
LOC      1203          IPLNK PORT  A          LINK  A
ADAPTER  M3UA          VER        M3UA RFC
LHOST    gw105.nc.tekelec.com
ALHOST    ---
RHOST    gw100.nc.tekelec.com
LPORT    1030          RPORT      1030
ISTRMS   2            OSTRMS     2          BUFSIZE  16
RMODE    LIN          RMIN       120        RMAX     800
RTIMES   10          CWMIN      3000       UAPS     10
OPEN     YES          ALW        YES        RTXTHR  10000

ASNAMES
as1

```

IP Appl Sock table is (4 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

3. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

NOTE: If the value of the open parameter shown in step 3 is no, skip this step and go to step 4.

For this example, enter this command.

chg-assoc : aname=assoc1 : open=no

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;

```

4. If the association is the only association assigned to the application server, the application server is removed from the database.

NOTE: If the application server specified in this procedure contains more than one association, skip this step and go to step 5.

The application server cannot be removed from the database if it is assigned to a routing key. Verify the routing keys that the application server is assigned to by entering the **rtrv-appl-rtkey** command with the application server name that will be specified in step 5 and the **display=all** parameter. For this example, enter this command.

rtrv-appl-rtkey : asname=as1 : display=all

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

```

```

RCONTEXT  DPCI          SI SSN OPCI          CICS      CICE      LOC
-----  -
6-024-7   5 ---  1-057-4   150      175      STATIC

ADPTR  TYPE      ASNAME
M3UA   FULL      as1

ANAMES
assoc1
assoc6

assoc2          assoc3          assoc5

RCONTEXT  DPCI          SI SSN OPCI          CICS      CICE      LOC
-----  -
2-100-7   6 ---  -----   -----   -----   STATIC

ADPTR  TYPE      ASNAME
M3UA   FULL      as1

ANAMES
assoc1
assoc6

assoc2          assoc3          assoc5

```



```

STATIC Route Key table is (7 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (7 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full

```

If the application server is assigned to any routing keys, remove the routing keys referencing the application server by performing the [Removing a Routing Key Containing an Application Server](#) procedure.

5. Remove the association from the application server from the database using the **dlt-as** command.

For this example, enter this command.

```
dlt-as:asname=as1:aname=assoc1
```

NOTE: If the association being removed from the application server is the only association assigned to the application server, the application server is removed from the database.

This is an example of possible inputs and outputs:

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
DLT-AS: MASP A - COMPLTD;

```

6. Verify the changes using the **rtrv-as** command with the application server name specified in step 5.

For this example, enter this command.

```
rtrv-as:asname=as1
```

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name           Mode      Tr ms   Association Names
as1                LOADSHARE 10      assoc2
                  assoc3
                  assoc5
                  assoc6

```

```
AS table is (3 of 250) 1% full.
```

7. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

NOTE: If the value of the open parameter was not changed in step 3, skip this step and go to step 8.

For this example, enter this command.

```
chg-assoc:aname=assoc1:open=yes
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;

```

8. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.

```

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-25. Removing an Association from an Application Server





Removing a Routing Key Containing an Application Server

This procedure is used to remove a static or dynamic routing key from the database using the **dlt-appl-rtkey** command. For more information about static and dynamic routing keys, see [Understanding Routing for SS7IPGW and IPGWI Applications](#).

The **dlt-appl-rtkey** command uses these parameters.

:dpc/dpca/dpci/dpcn/dpca24 – The destination point code value that is used to filter incoming MSUs.

:opc/opca/opci/opcn/opcn24 - The originating point code value that is used to filter incoming MSUs. This parameter must not specify a cluster route. This parameter must not specify a cluster route. This parameter is only valid when the **si** parameter value is set to **4**, **5**, or **13**. This parameter is required if **si=4**, **5**, or **13** and **type=full**.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value from 0 to 15, or for selected service indicator values, a text string can be used instead of numbers. [Table 6-16](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 6-16. Service Indicator Text String Values

Service Indicator Value	Text String	Service Indicator Value	Text String
0	snm	4	tup
1	regtest	5	isup
2	spltst	13	qbicc
3	sccp		

:ssn – The subsystem value that is used to filter incoming MSUs. The **ssn** parameter is only valid when the **si** parameter value is set to **3** or **sccp**.

:sname – The name of the socket that will receive the incoming MSU.

:cics - The starting circuit identification code that is used to filter incoming MSUs. Specify with **cice** to delete routing keys with the circuit identification code or range of circuit identification codes. The **cics** parameter is only valid when the **si** parameter value is set to **4**, **5**, or **13**. The **cics** is required if **si=4**, **5**, or **13** and **type=full**.

:cice - The ending circuit identification code that is used to filter incoming MSUs. Specify with **cics** to delete routing keys with the circuit identification code or range of circuit identification codes. The **cice** parameter is only valid when the **si** parameter value is set to **4**, **5**, or **13**. The **cics** is required if **si=4**, **5**, or **13** and **type=full**.

:loc – Card location that indicates from which **ss7ipgw** or **ipgwi** card to delete a dynamic routing key entry. If this parameter is not specified, a static entry is deleted.

:type - Identifies the type of routing key that is being deleted. One of three values, **type = full/partial/default**. If **type** is not explicitly specified, **type = full** is assumed.

:asname - Application server (AS) name.

:rcontext – The routing context parameter value assigned to the routing key.

The **dlt-appl-rtkey** command contains the **sname** parameter. The **sname** parameter is not used in this procedure. To use the **sname** parameter, perform the [Removing a Routing Key Containing a Socket](#) procedure in Chapter 4.

The parameter combinations used by the **dlt-appl-rtkey** command are based on the type of routing key and the service indicator value in the routing key. The parameter combinations are shown in [Table 6-17](#) .

Table 6-17. Routing Key Parameter Combinations for Removing Routing Keys

Full Routing Key ^{1, 5, 6} SI=3 (SCCP)	Partial Routing Key ^{1, 5, 6} SI=3 (SCCP)	Full Routing Key ^{1, 5, 6} SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Partial Routing Key ^{1, 5, 6} SI=4 (TUP), 5 (ISUP), 13 (QBICC)	Full Routing Key ^{1, 5, 6} Other SI Values	Partial Routing Key ^{1, 5, 6} Other SI Values	Default Routing Key ^{1, 5, 6}
dpc	type=partial	dpc	type=partial	dpc	type=partial	type=default
si=3 ¹	dpc ²	si=4, 5, 13 ¹	dpc ²	si=value other than 3, 4, 5, 13 ¹	dpc ²	asname
ssn	si=3 ^{1, 2}	opc	si=4, 5, 13 ^{1, 2}	type=full	si=value other than 3, 4, 5, 13 ^{1, 2}	loc ³
type=full	asname	cics	opc ²	asname	asname	rcontext ^{4, 5, 6}
asname	loc ³	cice	asname	loc ³	loc ³	
loc ³	rcontext ^{4, 5, 6}	type=full	loc ³	rcontext ^{4, 5, 6}	rcontext ^{4, 5, 6}	
rcontext ^{4, 5, 6}		asname	rcontext ^{4, 5, 6}			
		loc ³				
		rcontext ^{4, 5, 6}				

Notes:

1. The values for these parameters must be entered exactly as shown in the **rtrv-appl-rtkey** command output for the routing key being removed. However, text strings can be used in place of some numerical service indicator values. See [Table 6-16](#) for a list of these text strings.
2. These parameters are optional for partial routing keys, but at least one these parameters must be specified with the **dlt-appl-rtkey** command.
3. If the **loc** parameter is not specified, a static entry that matches the other specified parameters is deleted. The **loc** parameter can be specified only for dynamic routing key entries, entries that have a card location in the **LOC** column in the **rtrv-appl-rtkey** output. If the value in the **LOC** column is **STATIC**, the **loc** parameter cannot be used.
4. The **rcontext** parameter can be specified only for static routing key entries containing a numerical value in the **RCONTEXT** column in the **rtrv-appl-rtkey** output. A static routing key contains the entry **STATIC** in the **LOC** column of the **rtrv-appl-rtkey** output. If the value in the **RCONTEXT** column is dashes, the **rcontext** parameter cannot be used.
5. If the routing key contains a numerical value in the **RCONTEXT** column in the **rtrv-appl-rtkey** output, the **dlt-appl-rtkey** command can be specified with only the **rcontext** parameter and value instead of the **dpc**, **si**, **ssn**, **opc**, **cics**, **cice**, or **type** parameters and values to remove the routing key.
6. If the routing key contains dashes in the **RCONTEXT** column in the **rtrv-appl-rtkey** output, the **dpc**, **si**, **ssn**, **opc**, **cics**, **cice**, or **type** parameters and values must be used with the **dlt-appl-rtkey** command to remove the routing key.

Canceling the RTRV-APPL-RTKEY Command

Because the **rtrv-appl-rtkey** command used in this procedure can output information for a long period of time, the **rtrv-appl-rtkey** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-rtkey** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-rtkey** command was entered.

- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-rtkey** commands were entered, from another terminal other than the terminal where the **rtrv-appl-rtkey** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

RCONTEXT	DPCI	SI	ADPTR	ASNAME	TYPE	LOC
-----	2-100-7	6	M3UA	as4	FULL	STATIC
100	3-137-6	6	SUA	as1	FULL	STATIC
225	4-035-7	5	M3UA	as7	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-7	5	M3UA	as8	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-8	3	M3UA	as3	FULL	STATIC
-----	6-006-8	5	M3UA	as5	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
300	7-008-7	6	SUA	as6	FULL	STATIC

RCONTEXT	DPCN	SI	ADPTR	ASNAME	TYPE	LOC

RCONTEXT	DPCN24	SI	ADPTR	ASNAME	TYPE	LOC

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	*****	**	TALI	-----	DEFAULT	STATIC

STATIC Route Key table is (15 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

If no entries in the **rtrv-appl-rtkey** output contain the entry **M3UA** or **SUA** in the **ADPTR** column, there are no routing keys that contain application servers in the database. This procedure cannot be performed. Perform the [Removing a Routing Key Containing a Socket](#) procedure to remove any of the routing keys.

Select a routing key from the **rtrv-appl-rtkey** output that contains the entry **M3UA** or **SUA** in the **ADPTR** column.

NOTE: If a routing context value is not assigned to the the routing key being removed in this procedure, skip step 2 and go to step 3.

2. Display the specific routing key information for the routing key being removed from the database by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and the **RCONTEXT** values shown in the **rtrv-appl-rtkey** output in step 1 for the routing key being removed.

For this example, enter this command.

rtrv-appl-rtkey:rcontext=225

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT   DPCI          SI SSN OPCI          CICS      CICE      LOC
225         4-035-7       5 --- 2-007-3       2000      3000      STATIC

      ADPTR  TYPE      ASNAME
      M3UA   FULL      as7

      ANAMES
      assoc15

STATIC Route Key table is (15 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

After this step is performed, skip step 3 and go to step 4.

3. Display the specific routing key information for the routing key being removed from the database by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and the **DPC**, **SI**, and **TYPE** values shown in the **rtrv-appl-rtkey** output in step 1 for the routing key being removed. For this example, enter this command.

rtrv-appl-rtkey:dpci=6-006-6:si=3:display=all:type=full

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

RCONTEXT   DPCI          SI SSN OPCI          CICS      CICE      LOC
-----      6-006-6       3 170 -----      -----      STATIC

      ADPTR  TYPE      ASNAME
      M3UA   FULL      as2

      ANAMES
      assoc1

STATIC Route Key table is (15 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

4. Display the associations assigned to the routing key by entering the **rtrv-assoc** parameter with the association name shown in either steps 2 or 3. For this example, enter these commands.

rtrv-assoc:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

```

ANAME assoc1
LOC      1203          IPLNK PORT  A          LINK  A
ADAPTER  M3UA          VER        M3UA RFC
LHOST    gw105.nc.tekelec.com
ALHOST    ---
RHOST    gw100.nc.tekelec.com
LPORT    1030          RPORT      1030
ISTRMS   2            OSTRMS     2          BUFSIZE  16
RMODE    LIN           RMIN       120        RMAX     800
RTIMES   10           CWMIN      3000       UAPS     10
OPEN     YES          ALW        YES        RTXTHR  10000

ASNAMES
as2

```

IP Appl Sock table is (8 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

rtrv-assoc:aname=assoc15

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc15
LOC      1205          IPLNK PORT  A          LINK  A
ADAPTER  M3UA          VER        M3UA RFC
LHOST    gw115.nc.tekelec.com
ALHOST    ---
RHOST    gw100.nc.tekelec.com
LPORT    2000          RPORT      2000
ISTRMS   2            OSTRMS     2          BUFSIZE  16
RMODE    LIN           RMIN       120        RMAX     800
RTIMES   10           CWMIN      3000       UAPS     10
OPEN     YES          ALW        YES        RTXTHR  10000

ASNAMES
as7

```

IP Appl Sock table is (8 of 4000) 1% full
 Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

Repeat this step for all the associations shown in steps 2 or 3.

5. Change the **open** parameter value of the association to **no** by using the **chg-assoc** command.

NOTE: If the open parameter value of all the associations shown in step 4 is no, skip step 5 and go to step 6.

For example, enter these commands.

chg-assoc:aname=assoc1:open=no

chg-assoc:aname=assoc15:open=no

When this command has successfully completed, the following message should appear.

```

rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD

```



CAUTION: The IP connections using the associations specified in this step will not be able to carry any traffic when the open parameter is changed to no.

Repeat this step for all the associations shown in step 4 that contain the **open=yes** parameter value.

6. Remove the routing key information from the database by entering the **dlt-appl-rtkey** command.
 The parameters required for the **dlt-appl-rtkey** command are determined by the type of routing key being added and the service indicator value in the routing key. See [Table 6-17](#) for the parameter

combinations that can be used for the type of routing key being added to the database. For example, enter these commands.

dlt-appl-rtkey:dpci=6-006-6:si=3:ssn=170:asname=as2

dlt-appl-rtkey:rcontext=225

When each of these commands have successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
DLT-APPL-RTKEY: MASP A - COMPLTD
```

7. Verify the changes by entering the **rtrv-appl-rtkey** command with the routing key parameters specified in step 6 (**dpc**, **si**, **opc**, **cics**, **cice**, **ssn**, **asname**, **type**, and **loc**, as applicable). For this example, enter these commands.

rtrv-appl-rtkey:dpci=6-006-6:si=3:ssn=170:asname=as2

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

STATIC Route Key table is (12 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (1 of 500) 1% full

STATIC Route Key Socket Association table is (6 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (1 of 8000) 1% full
```

rtrv-appl-rtkey:rcontext=225

The following is an example of the possible output.

```
STATIC Route Key table is (12 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (1 of 500) 1% full

STATIC Route Key Socket Association table is (12 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (1 of 8000) 1% full
```

NOTE: If step 5 was not performed, skip step 8 and go to step 9.

8. Change the **open** parameter value of the associations that were changed in step 5 to **yes** by using the **chg-assoc** command.

For example, enter these commands.

chg-assoc:aname=assoc1:open=yes

chg-assoc:aname=assoc15:open=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD
```

Repeat this step for all the associations that were changed in step 5.


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
```

BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
 BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-26. Removing a Routing Key Containing an Application Server





Removing a Network Appearance

This procedure removes the network appearance from the database using the **dlt-na** command with these parameters.

:na – the 32-bit value of the network appearance, from 0 to 4294967295.

:type – the network type of the network appearance, **ansi** (ANSI), **itui** (ITU-I), **itun** (14-bit ITU-N), **itun24** (24-bit ITU-N), **ituis** (ITU-I Spare), **ituns** (14-bit ITU-N Spare).

:gc – the specific ITU-N group code associated with the network appearance.

Specifying the **gc** parameter removes the specific network appearance containing the **na** and **gc** parameter values.

Specifying the **type=itun** or **type=ituns** parameter without the **gc** parameter removes all 14-bit ITU-N or 14-bit ITU-N spare network appearances containing the specified **na** parameter value.

Procedure

1. Display the network appearances in the database with the **rtrv-na** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
TYPE      GC      NA
ANSI      --      100
ITUI      --      1000
ITUN      uk      150000
ITUN      fr      4000000000
ITUN      ge      1000000000
ITUN24    --      3
ITUIS     --      2000
ITUNS     sp      5000
```

2. Remove the network appearance from the database with the **dlt-na** command.

For this example, enter these commands.

```
dlt-na:na=100:type=ansi
```

```
dlt-na:na=4000000000:type=itun:gc=fr
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
DLT-NA:  MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-na** command.


This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
TYPE      GC      NA
ITUI      --      1000
ITUN      uk      150000
ITUN      ge      1000000000
ITUN24    --      3
ITUIS     --      2000
ITUNS     sp      5000
```

4. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-27. Removing a Network Appearance

Changing IETF M3UA and SUA Components

This section describes how to change the attributes of the following components in the database.

- IP Protocol Options – Perform the [Changing the IP Protocol Option](#) procedure or the [Changing IP Options other than SYNC and SCTPCSUM](#) procedure
- An M3UA or SUA Association – Perform the [Changing an M3UA or SUA Association](#) procedure
- The SCTP Retransmission Parameters – Perform the [Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations](#) procedure
- An Application Server – Perform the [Changing an Application Server](#) procedure
- CIC Values in a Routing Key – Perform the [Changing the CIC Values in an Existing Routing Key Containing an Application Server](#) procedure

- Routing Context Values in a Routing Key – Perform the [Changing the Routing Context Value in an Existing Routing Key](#) procedure
- The SCTP Checksum Algorithm – Perform the [Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations](#) procedure
- A UA Parameter Set – Perform the [Changing a UA Parameter Set](#) procedure
- Turn off the Large BICC MSU Support for IP Signaling feature – Perform the [Turning the Large BICC MSU Support for IP Signaling Feature Off](#) procedure.

Changing the IP Protocol Option

Use this procedure to change the IP protocol option with the **chg-sg-opts:sync** command.

To change the **:sync** option, which has the values **tali** or **sassi**, the IP cards associated with the **ss7ipgw** or **ipgwi** application must be inhibited, and the signaling links assigned to this card must be deactivated.

Procedure

1. Display the current IP options in the database by entering the **rtrv-sg-opts** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SYNC:          TALI
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

To change the protocol option (synchronization code) for the card, the signaling link to the IP card and the card have to be inhibited.

2. Display the current IP parameters associated with card in the database by entering the **rtrv-ip-card** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC 1201
  SRCHORDR  LOCAL
  DNSA      150.1.1.1
  DNSB      -----
  DEFROUTER -----
  DOMAIN     -----

LOC 1203
  SRCHORDR  LOCAL
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM

LOC 1205
  SRCHORDR  SRVRONLY
  DNSA      192.1.1.40
  DNSB      -----
  DEFROUTER -----
  DOMAIN     NC. TEKELEC. COM
```

3. Display the signaling link associated with the card shown in step 2 using the **rtrv-slk** command specifying the card location.

For this example, enter this command.

rtrv-slk: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-19 21:17:04 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE    IPLIML2
1201  A    nc001        0  IPLIM    SAALTALI
```

4. Verify the status of the signaling link shown in step 3 using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output lists the signaling link assigned to this card:

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK  LSN      CLLI      PST      SST      AST
1201,A  nc001    -----  IS-NR    Avail    ----
Command Completed.
```

If the signaling link is in service-normal (IS-NR), go to step 5 to deactivate the signaling link. If the signaling link is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 7 to verify the card status.

5. Deactivate the signaling link assigned to the IP card using the **dact-slk** command.

For example, enter this command:

dact-slk: loc=1201: link=a



CAUTION: This command impacts network performance and should only be used during periods of low traffic.

After this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

6. Verify the new link status using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

The output displays the link status as OOS-MT-DSBLD and gives off a minor alarm:

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
SLK  LSN      CLLI      PST      SST      AST
1201,A  nc001    -----  OOS-MT-DSBLD  AVAIL    ---
ALARM STATUS = * 0236 REPT-LKS: not aligned
UNAVAIL REASON = NA
```

Command Completed.

7. Verify the status of the IP card to be inhibited using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
```

```

CARD  VERSION      TYPE    APPL      PST          SST          AST
1201  114-000-000  DCM     IPLIM     IS-NR        Active       -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK    PST          LS          CLLI
A      OOS-MT-DSBLD  nc001     -----

```

Command Completed.

If the IP card to be inhibited is in service-normal (IS-NR), go to step 8 to inhibit the IP card. If the IP card is out-of-service-maintenance disabled (OOS-MT-DSBLD), go to step 10 to change the IP options.

8. Inhibit the IP card using the **inh-card** command.

For example, enter this command.

inh-card: loc=1201

This message should appear.

```

rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
Card has been inhibited.

```

9. Display the status of the IP card to verify that it is out-of-service maintenance-disabled (OOS-MT-DSBLD).

Enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```

rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE    APPL      PST          SST          AST
1201  114-000-000  DCM     IPLIM     OOS-MT-DSBLD Manual       -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK    PST          LS          CLLI
A      OOS-MT-DSBLD  nc001     -----

```

Command Completed.

10. Change the IP options in the database using the **chg-sg-opts** command.

For this example, enter this command.

chg-sg-opts: sync=sassi

When this command has successfully completed, the following message should appear.

```

rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
CHG-SG-OPTS: MASP A - COMPLTD

```

11. Verify the new IP options in the database using the **rtrv-sg-opts** command.

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SYNC:          SASSI

```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

If step 8 was not performed, skip steps 12 and 13, and go to step 14.

12. Allow the IP card that was inhibited in step 8 using the **alw-card** command.

For example, enter this command.

alw-card: loc=1201

This message should appear.

```
rlghncxa03w 06-10-28 21:21:37 GMT EAGLE5 36.0.0
Card has been allowed.
```

13. Verify the in-service normal (IS-NR) status of the IP card using the **rept-stat-card** command.

For example, enter this command.

rept-stat-card: loc=1201

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1201  114-000-000  DCM      IPLIM     IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
  SLK   PST          LS          CLLI
  A     IS-NR        nc001      -----
```

Command Completed.

If step 5 was not performed, skip steps 14 and 15, and go to step 16.

14. Activate the signaling link from step 5 using the **act-slk** command.

For example, enter this command.

act-slk: loc=1201: link=a

The link changes its state from OOS-MT-DSBLD (out-of-service maintenance-disabled) to IS-NR (in-service normal).

The output confirms the activation.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

15. Verify the in-service normal (IS-NR) status of the signaling link by using the **rept-stat-slk** command.

For example, enter this command.

rept-stat-slk: loc=1201: link=a

This message should appear.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK   LSN      CLLI      PST      SST      AST
1201,A nc001    -----  IS-NR     Avail    ----
Command Completed.
```


16. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
 BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
 BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-28. Changing the IP Protocol Option





Changing IP Options other than SYNC and SCTPCSUM

Use this procedure to change the IP options defined by these parameters: **drkq**, **getcomm**, **setcomm**, **snmpcont**, **srkq**, **trapcomm**, **inhfepalm**, **ipgwabate**. These parameters do not require the IP card associated with an **ss7ipgw** or **ipgwi** application to be inhibited prior to configuration.

NOTE: The **chg-sg-opts** command also contains the **iptpsalmthresh** parameter, used to configure the IP TPS alarm threshold. This parameter is not used in this procedure. Perform the [Configuring the IP TPS Alarm Threshold](#) procedure to configure the IP TPS alarm threshold with the **iptpsalmthresh** parameter.

:drkq – The dynamic routing key quantity used to specify the maximum number of dynamic routing key entries in the Routing Key table of each **ss7ipgw** and **ipgwi** card.

:getcomm – The community name used to validate SNMP *Get* and *GetNext* requests. This value applies to each IP card SNMP agent.

:setcomm – The community name used to validate SNMP *Set* requests. This value applies to each IP card SNMP agent.

:snmpcont – The system contact information for each IP card SNMP agent, used to define the *sysContact* object in the SNMP MIB II System Group.

:srkq – The static routing key quantity used to specify the maximum number of static routing key entries in the Routing Key table of each **ss7ipgw** and **ipgwi** card.

:trapcomm – The community name used when sending SNMP traps. This value applies to each IP card SNMP agent.

:inhfepalm – This parameter specifies whether or not major alarms for TALI sockets whose secondary state is NEA-FEP will be inhibited (suppressed). This value applies to all IPLIM and SS7IPGW cards in the EAGLE 5 ISS.

When this parameter is set to **no** (default), the NEA-FEP sockets are reported as OOS-MT and a major alarm (UAM 0084 - IP Connection Unavailable) is raised for that connection.

When this parameter is set to **yes**, all TALI sockets with a secondary status of NEA-FEP are reported as IS-NR and no socket alarm is raised. For IPLIM and IPLIMI cards, where each link consists of a single TALI socket, a link alarm will still be raised when the TALI socket's secondary status is NEA-FEP, regardless of the **inhfepalm** parameter value.

:ipgwabate – enables (**ipgwabate=yes**) or disables (**ipgwabate=no**) SS7 congestion abatement procedures for SS7IPGW signaling links (signaling links assigned to cards running the **ss7ipgw** application). The default value for this parameter is **no**.

The sum of the values specified for the **srkq** and **drkq** parameters must not be greater than:

- 1000 if there are any DCM cards (870-1945-xx) running the **ss7ipgw** or **ipgwi** application.
- 2500 if all cards that are running the **ss7ipgw** or **ipgwi** application are SSED CM cards (870-2372-xx) or E5-ENET cards (870-2212-xx).

Replacing an SSED CM or E5-ENET card with a dual-slot DCM card when the sum of the values for the **srkq** and **drkq** parameters is greater than 1000 will result in the DCM card being auto-inhibited.

The value specified for the **srkq** parameter cannot be less than the current number of static entries in the Routing Key table.

The value that can be specified for the **srkq** parameter also depends on how many dynamic routing keys are actively registered. The value specified for the **srkq** parameter cannot exceed the lowest value determined by subtracting the number of dynamic entries on either an **ss7ipgw** or **ipgwi** card from:

- 1000 if there are any dual-slot DCM cards (870-1945-xx) running the **ss7ipgw** or **ipgwi** application
- 2500 if all cards that are running the **ss7ipgw** or **ipgwi** application are SSED CM cards (870-2372-xx) or E5-ENET cards (870-2212-xx)..

For example, if one dual-slot DCM card has 200 dynamic entries and the other card has 300 dynamic entries, the value specified for **srkq** cannot exceed 700 (1000 - 300 = 700; 1000 - 200 = 800; 700 is the lower value).

If **d** is the current maximum number of actual dynamic routing keys on any card that is running the **ss7ipgw** or **ipgwi** application, then the sum of **d** and the **srkq** value cannot exceed:

- 1000 per card if there are any dual-slot DCM cards (870-1945-xx) running the **ss7ipgw** or **ipgwi** application
- 2500 per card if all cards that are running the **ss7ipgw** or **ipgwi** application are SSEDCM cards (870-2372-xx) or E5-ENET cards (870-2212-xx)..

Effectively this means that even if the **drkq** parameter value has been decreased to less than **d**, the **srkq** value cannot be increased until **d** has also decreased.

The Dynamic Routing Key feature must be on in order to enter the **drkq** parameter. If the current value of the **drkq** parameter is greater than 0, then the Dynamic Routing Key feature is on. If the current value of the **drkq** parameter is 0, enter the **rtrv-feat** command. The **DYNRTK** field in the **rtrv-feat** command output shows whether or not this feature is on.

The values of the **snmpcont**, **getcomm**, **setcomm**, and **trapcomm** parameters are a string of up to 32 characters that is not case sensitive. If the character string contains characters other than alphanumeric characters, the character string must be enclosed in single quotes.

Procedure

1. Display the current IP options in the database by entering the **rtrv-sg-opts** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
SYNC:          TALI
SRKQ:          250
DRKQ:          750
SNMPCONT:      john doe 555-123-4567
GETCOMM:       public
SETCOMM:       private
TRAPCOMM:      public
INHFEPALM:     NO
SCTPCSUM:      crc32c
IPGWABATE:     NO
IPTPSALMTHRESH: 80
```

NOTE: If the current value of the **drkq** parameter is 0 and is not being changed, or if the current value of the **drkq** parameter is greater than 0, skip steps 2 and 3, and go to step 4.

2. Verify that the Dynamic Routing Key feature is on, by entering the **rtrv-feat** command.

If the Dynamic Routing Key feature is on, the **DYNRTK** field should be set to **on**. For this example, the Dynamic Routing Key feature is off.

NOTE: The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

If the Dynamic Routing Key feature is on, skip step 3 and go to step 4.

3. Turn the Dynamic Routing Key feature on by entering this command.

chg-feat: dynrtk=on

NOTE: Once the Dynamic Routing Key feature is turned on with the **chg-feat** command, it cannot be turned off. The Dynamic Routing Key feature must be purchased

before you turn this feature on with the `chg-feat` command. If you are not sure if you have purchased the Dynamic Routing Key feature, contact your Tekelec Sales Representative or Account Representative.

When the **`chg-feat`** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

4. Change the IP options in the database using the **`chg-sg-opts`** command.

For this example, enter this command.

`chg-sg-opts:srkq=200:drkq=800`

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:18:37 GMT EAGLE5 36.0.0
CHG-SG-OPTS: MASP A - COMPLTD
```


5. Verify the new IP options in the database by entering the **`rtrv-sg-opts`** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
SYNC:          TALI
SRKQ:          200
DRKQ:          800
SNMPCONT:      john doe 555-123-4567
GETCOMM:       public
SETCOMM:       private
TRAPCOMM:      public
INHFEPALM:     NO
SCTPCSUM:      crc32c
IPGWABATE:     NO
IPLIMABATE:    NO
IPTPSALMTHRESH: 80
```

6. Back up the new changes using the **`chg-db:action=backup:dest=fixed`** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-29. Changing an IP Option That Does Not Require Inhibiting the IP Card

Changing an M3UA or SUA Association

This procedure is used to change the values of the attributes of M3UA or SUA associations in the database using the **chg-assoc** command.

The **chg-assoc** command uses these parameters:

:aname – The name assigned to the association. Valid association names can contain up to 15 alphanumeric characters where the first character is a letter and the remaining characters are alphanumeric characters. The **aname** parameter value is not case-sensitive.

:lhost – The host name for the local host, **lhost** can be any string of characters starting with a letter and comprising these characters ['a'..'z', 'A'..'Z', '0'..'9', '-', '.']. Hostnames are not case-sensitive and can contain up to 60 characters. The default value of this optional parameter is empty (null string).

:lport – The SCTP port number for the local host.

:rhost – The host name for the remote host, **rhost** can be any string of characters starting with a letter and comprising these characters ['a'..'z', 'A'..'Z', '0'..'9', '-', '.']. Hostnames are not case-sensitive and can contain up to 60 characters. The default value of this optional parameter is empty (null string).

:rport – The SCTP port number for the remote host.

:link – The signaling link on the IP card. The value for the **link** parameter for M3UA or SUA associations is A.

NOTE: The port parameter can be used in place of the link parameter to specify the signaling link on the card.

:adapter – The adapter layer for this association, either **m3ua** or **sua**. The **adapter** parameter is optional. The default value for the **adapter** parameter in this procedure is **m3ua**.

:alhost – The alternate local host name.

:open – The connection state for this association. Valid values are **yes** or **no**. When the **open=yes** parameter is specified, the connection manager opens the association if the association is operational. When the **open=no** parameter is specified, the connection manager will not open the association.

:alw – The connection state for this association. Valid values are **yes** or **no**. When the **alw=yes** parameter is specified, the connection manager allows the association to carry SS7 traffic. When the **alw=no** parameter is specified, the connection manager prohibits the association from carrying SS7 traffic.

:rmode – The retransmission policy used when packet loss is detected. The values are **rfc** or **lin**.

- **rfc** – Standard RFC 2960 algorithm in the retransmission delay doubles after each retransmission. The RFC 2960 standard for congestion control is also used.
- **lin** – Tekelec's linear retransmission policy where each retransmission timeout value is the same as the initial transmission timeout and only the slow start algorithm is used for congestion control.

:rmin – The minimum value of the calculated retransmission timeout in milliseconds, from 10 - 1000.

:rmax – The maximum value of the calculated retransmission timeout in milliseconds, from 10 - 1000.

:rtimes – The number of times a data retransmission will occur before closing the association from 3 - 12.

:cwmmin – The minimum size in bytes of the association's congestion window and the initial size in bytes of the congestion window, from 1500 - 196608.

The **rmode**, **rmin**, **rmax**, **rtime**, and **cwmin** parameters are used to configure the SCTP retransmission controls for an association, in addition to other commands. Go to the [Configuring SCTP Retransmission Control for an M3UA or SUA Association](#) procedure to configure the SCTP retransmission controls for an association.

:istrms – The number of inbound streams (1 or 2) advertised by the SCTP layer for the association.

:ostrms – The number of outbound streams (1 or 2) advertised by the SCTP layer for the association.

:uaps – The UA parameter set value being assigned to either an M3UA or SUA association.

:bufsize – The size, in kilobytes, of the buffer used by the association. The values for this parameter are 8 kilobytes to 400 kilobytes. The maximum size of the buffers on the IP cards are shown in the following list:

- Single-Slot EDCM - 800 kB
- E5-ENET Card - 3200 kB.

The size of the buffers assigned to each association that is assigned to the IP card cannot exceed the maximum buffer size for that card. If the **bufsize** parameter value causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **chg-assoc** command will be rejected. The available size of the buffers on the IP card can be verified by entering this command.

rtrv-assoc:lhost=<local host name assigned to the association being changed>

The **alhost** parameter can also be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card.

The **aname** parameter can be used with the **rtrv-assoc** command to display the available size of the buffers on the IP card and the size of the buffer assigned to the association.

If you wish to increase the buffer size for this association to a value that is greater than available buffer size for the card, the buffer size of the other associations assigned to the card must be decreased.

:rtxthr – The retransmission threshold for the association. The **rtxthr** parameter value indicates the number of retransmissions that can occur on the association that when exceeded will generate UAM 0537, Ethernet Error Threshold Exceeded. The value of this parameter is 0 to 65,535. The value of this parameter is shown in the **RTXTHR** field of the **rtrv-assoc:aname=<association name>** output. The **rtxthr** parameter value can be changed if the **open** parameter value is either **yes** or **no**.

The **adapter=m2pa**, **ver**, and **m2patset** parameters can be used only when changing M2PA associations. Perform the [Changing an M2PA Association](#) procedure to change M2PA associations.

If the value of the **open** parameter is **yes**, only the value of the **alw** parameter can be changed. To change the values of other parameters, the value of the **open** parameter must be **no**.

To set the **open** parameter value to **yes**, the association specified by the **aname** parameter must contain values for the **lhost**, **lport**, **rhost**, and **rport** parameters. The **lhost** parameter value must have a signaling link assigned to it.

At least one optional parameter is required.

The command input is limited to 150 characters, including the hostnames.

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50. For example, if the IPGWx card contains 12 TALI sockets, the maximum number of SCTP association to application server assignments that the IPGWx card can support is 38. The SCTP association to application server assignments could be one SCTP association assigned to 38 application servers, two SCTP associations assigned to 19 application servers, or any combination of SCTP associations assigned to application servers that add up to 38. The number

of TALI sockets can be verified with the **rtrv-appl-sock:lhost=<local host name>** command. The SCTP association to application server assignments can be verified with the **rtrv-assoc:lhost=<local host name>** and **rtrv-as:aname=<association name>** commands.

Table 6-18. Examples of IPGWx Card Provisioning Limits

Number of Associations hosted by the IPGWx card	Number of Application Servers each Association is Assigned to *	Number of TALI Sockets Hosted by the IPGWx card	Total Association - Application Server Assignments and TALI Sockets maintained by the IPGWx card
1	50	0	50
50	1	0	50
25	1	25	50
25	2	0	50
0	0	50	50
38	1	12	50
19	2	12	50
* The EAGLE 5 ISS can contain a maximum of 250 application servers.			

The EAGLE 5 ISS can contain a maximum of 4000 connections (association to application server assignments plus sockets).

The B Ethernet interface of the IP card can be used on the single-slot EDCMs or E5-ENET cards.

The **adapter** parameter value cannot be changed if the association is assigned to an application server. This can be verified with the **rtrv-as** command. If the association is assigned to any application servers, go to the [Removing an Association from an Application Server](#) procedure and remove the association from the application servers.

The value of the **rmin** parameter must be less than or equal to the **rmax** parameter value.

For associations assigned to the **ss7ipgw** or **ipgwi** applications, the value of the **cwmin** parameter must be less than or equal to 16384.

If the card's application is either SS7IPGW or IPGWI, the signaling link being assigned to the association must be in service. This state is shown in the **rept-stat-slk** output with the entries **IS-NR** in the **PST** field and **Avail** in the **SST** field.

Uni-homed endpoints are associations configured with the **lhost** parameter only. The **lhost** parameter value represents an IP address that corresponds to either the A or B network interface of the IP card. Multi-homed endpoints are associations configured with both the **lhost** and **alhost** parameters. The **lhost** parameter value represents an IP address corresponding to one of the network interfaces (A or B) of the IP card while the **alhost** parameter value represents an IP address corresponding to the other network interface of the same IP card.

The **alhost=none** parameter removes the alternate local host from the specified association, which also removes the multi-homed endpoint capability.

Canceling the RTRV-ASSOC and RTRV-AS Commands

Because the **rtrv-assoc** and **rtrv-as** commands used in this procedure can output information for a long period of time, the **rtrv-assoc** and **rtrv-as** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** and **rtrv-as** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered, from another terminal other than the terminal where the **rtrv-assoc** or **rtrv-as** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

ANAME	CARD	IPLNK	LOC	PORT	LINK	ADAPTER	LPORT	RPORT	OPEN	ALW
swbel32	1201	A	A		M3UA	1030	2345	YES	YES	
a2	1305	A	A		SUA	1030	2345	YES	YES	
a3	1307	A	A		SUA	1030	2346	YES	YES	
assoc1	1201	A	A		M3UA	2000	1030	YES	YES	
assoc2	1205	A	A		M3UA	2048	2048	YES	YES	
assoc3	1205	A	A		M3UA	3000	3000	YES	YES	
assoc5	1205	A	A		M3UA	1500	3000	YES	YES	

NOTE 1: To change the values of these parameters: **lhost**, **lport**, **rhost**, **rport**, **alhost**, **link**, **adapter**, **rmode**, **rmin**, **rmax**, **rtimes**, **cwmin**, **istrms**, **ostrms**, **ver**, **uaps**, or **bufsize**, the value of the **open** parameter must be **no**. If the values of any of these parameters are being changed and the **open** parameter value for the association being changed is **no**, skip step 2 and go to step 3.

NOTE: If only the values of the **alw** or **open** parameters are being changed, skip steps 2 through 19, and go to step 20.

2. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

For this example, enter this command.

```
chg-assoc:aname=assoc2:open=no
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```

3. Display the association being changed by entering the **rtrv-assoc** command with the **aname** parameter specified in step 2.

For this example, enter this command.

rtrv-assoc:aname=assoc2

This is an example of the possible output.

```

r1ghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
ANAME assoc2
  LOC      1205      IPLNK PORT  A      LINK  A
  ADAPTER  M3UA      VER      M3UA RFC
  LHOST    IPNODE2-1205
  ALHOST    ---
  RHOST    remotehost1
  LPORT    2048      RPORT      2048
  ISTRMS   2      OSTRMS      2      BUFSIZE  200
  RMODE    LIN      RMIN      120      RMAX      800
  RTIMES   10      CWMIN      3000     UAPS      10
  OPEN     No      ALW      YES      RTXTHR   2000

ASNAMES
as1          as4          as6

```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (800 KB of 800 KB) on LOC = 1205

NOTE: If the buffer size of the association is not being changed, skip steps 4 through 6, and go to step 7.

4. If the **bufsize** parameter value causes the total buffer size for all the associations on the IP card to exceed the maximum buffer size for that IP card, the **chg-assoc** command will be rejected.

If you wish to increase the buffer size for this association to a value that is greater than available buffer size for the card, the buffer size of the other associations assigned to the card must be decreased. Perform this step and steps 5 and 6.

If the buffers on the other associations assigned to the card do not need to be changed, skip this step and steps 5 and 6, and go to step 7.

Display the associations assigned to the IP card (and its corresponding local host) by entering the **rtrv-assoc** command with the local host name assigned to the association being changed. For this example, enter this command.

rtrv-assoc:lhost="IPNODE2-1205"

This is an example of the possible output.

```

r1ghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME  LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc2 1205 A    A    M3UA   2048 2048 YES YES
assoc3 1205 A    A    M3UA   3000 3000 YES YES
assoc5 1205 A    A    M3UA   1500 3000 YES YES

```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (800 KB of 3200 KB) on LOC = 1205

5. Display each association shown in step 4 by entering the **rtrv-assoc** command with the name of each association shown in step 4.

For this example, enter these commands.

rtrv-assoc:aname=assoc2

This is an example of the possible output.

```

ANAME assoc2
  LOC      1205      IPLNK PORT  A      LINK  A
  ADAPTER  M3UA      VER      M3UA RFC

```

```

LHOST    IPNODE2-1205
ALHOST    ---
RHOST     remotehost1
LPORT     2048          RPORT      2048
ISTRMS    2            OSTRMS     2          BUFSIZE  200
RMODE     LIN          RMIN       120        RMAX     800
RTIMES    10           CWMIN      3000       UAPS     10
OPEN      YES          ALW        YES        RTXTHR  2000

```

```

ASNAMES
as1          as4          as6

```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (800 KB of 800 KB) on LOC = 1205

rtrv-assoc:aname=assoc3

This is an example of the possible output.

```

ANAME assoc3
LOC      1205          IPLNK PORT  A          LINK  A
ADAPTER  M3UA          VER          M3UA RFC
LHOST    IPNODE2-1205
ALHOST    ---
RHOST     remotehost3
LPORT     3000          RPORT      3000
ISTRMS    2            OSTRMS     2          BUFSIZE  400
RMODE     LIN          RMIN       120        RMAX     800
RTIMES    10           CWMIN      3000       UAPS     10
OPEN      YES          ALW        YES        RTXTHR  10000

ASNAMES
as2          as3          as5

```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (800 KB of 800 KB) on LOC = 1205

rtrv-assoc:aname=assoc5

This is an example of the possible output.

```

ANAME assoc5
LOC      1205          IPLNK PORT  A          LINK  A
ADAPTER  M3UA          VER          M3UA RFC
LHOST    IPNODE2-1205
ALHOST    ---
RHOST     remotehost3
LPORT     1500          RPORT      3000
ISTRMS    2            OSTRMS     2          BUFSIZE  200
RMODE     LIN          RMIN       120        RMAX     800
RTIMES    10           CWMIN      3000       UAPS     10
OPEN      YES          ALW        YES        RTXTHR  10000

ASNAMES
as2          as3          as5

```

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (800 KB of 800 KB) on LOC = 1205

6. Change the size of the buffers for one or more of the associations displayed in step 5 to allow the buffer of the association displayed in step 3 to be changed.

Enter the **chg-assoc** command with the **bufsize** parameter. For this example, enter this command.

chg-assoc:aname=assoc3:bufsize=200

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;

```

NOTE: If the local host name assigned to the association is not being changed, skip steps 7 through 12 and go to step 13.

7. Verify that the local host name to be assigned to the association is in the database by using the **rtrv-ip-host** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

LOCAL IPADDR	LOCAL HOST
192.1.1.10	IPNODE1-1201
192.1.1.12	GW105. NC. TEKELEC. COM
192.1.1.14	IPNODE1-1205
192.1.1.20	IPNODE2-1201
192.1.1.22	IPNODE2-1203
192.1.1.24	IPNODE2-1205
192.1.1.30	KC-HLR1
192.1.1.32	KC-HLR2
192.1.1.50	DN-MSC1
192.1.1.52	DN-MSC2

REMOTE IPADDR	REMOTE HOST
150.1.1.5	NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

IP Host table is (11 of 512) 2% full

8. Display the IP links in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 07-05-28 21:14:37 GMT EAGLE5 37.0.0
```

LOC	PORT	IPADDR	SUBMASK	DUPLEX	SPEED	MACTYPE	AUTO	MCAST
1303	A	192.1.1.10	255.255.255.128	HALF	10	802.3	NO	NO
1303	B	-----	-----	HALF	10	DIX	NO	NO
1305	A	192.1.1.12	255.255.255.0	----	---	DIX	YES	NO
1305	B	-----	-----	HALF	10	DIX	NO	NO
1313	A	192.1.1.14	255.255.255.0	FULL	100	DIX	NO	NO
1313	B	-----	-----	HALF	10	DIX	NO	NO
2101	A	192.1.1.20	255.255.255.0	FULL	100	DIX	NO	NO
2101	B	-----	-----	HALF	10	DIX	NO	NO
2103	A	192.1.1.22	255.255.255.0	FULL	100	DIX	NO	NO
2103	B	-----	-----	HALF	10	DIX	NO	NO
2105	A	192.1.1.24	255.255.255.0	FULL	100	DIX	NO	NO
2105	B	-----	-----	HALF	10	DIX	NO	NO
2205	A	192.1.1.30	255.255.255.0	FULL	100	DIX	NO	NO
2205	B	-----	-----	HALF	10	DIX	NO	NO
2207	A	192.1.1.32	255.255.255.0	FULL	100	DIX	NO	NO
2207	B	-----	-----	HALF	10	DIX	NO	NO
2213	A	192.1.1.50	255.255.255.0	FULL	100	DIX	NO	NO
2213	B	-----	-----	HALF	10	DIX	NO	NO
2301	A	192.1.1.52	255.255.255.0	FULL	100	DIX	NO	NO
2301	B	-----	-----	HALF	10	DIX	NO	NO
2305	A	192.3.3.33	255.255.255.0	FULL	100	DIX	NO	NO
2305	B	-----	-----	HALF	10	DIX	NO	NO

If the required IP link, one that contains the desired IP address, is not shown in the **rtrv-ip-lnk** output, add the IP link using the [Configuring an IP Link](#) procedure. After the IP link has been added, assign the IP address of the IP link to the IP host name using the [Adding an IP Host](#) procedure. Then go to step 12.

If the required IP link is shown in the **rtrv-ip-lnk** output, assign the IP address of the IP link to the IP host name using the [Adding an IP Host](#) procedure. Then go to step 13.

If the required IP host was shown in step 7, the required IP link is shown in the **rtrv-ip-lnk** output in this step. Perform step 9 to verify the application running on the card whose IP address is assigned to the IP host.

9. Display the application running on the IP card shown in step 8 whose IP address is assigned to the IP host using the **rept-stat-card** command specifying the location of the IP card.

For this example, enter this command.

rept-stat-card: loc=1205

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION      TYPE      APPL      PST      SST      AST
1205  114-000-000   DCM       SS7IPGW   IS-NR     Active   -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
SLK   PST          LS          CLLI
A     IS-NR        nc001      -----
```

Command Completed.

NOTE: If the local host value being used in this procedure was configured with the [Adding an IP Host](#) procedure in step 8, skip steps 10, 11, and 12, and go to step 13.

10. Display the sockets assigned to the local host that will be assigned to the socket being configured in this procedure by entering the **rtrv-appl-sock** command with the **lhost** parameter.

For this example, enter this command.

rtrv-appl-sock: lhost="IPNODE2-1205"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
SNAME sock1
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost1
LPORT     1024      RPORT     2048
SERVER    YES       DCMP5     10
REXMIT    FIXED     RTT       60
OPEN      YES       ALW       YES

SNAME sock2
LINK      A
LHOST     IPNODE2-1205
RHOST     remotehost2
LPORT     2000      RPORT     2000
SERVER    YES       DCMP5     10
REXMIT    FIXED     RTT       60
OPEN      YES       ALW       YES
```

IP Appl Sock/Assoc table is (8 of 4000) 1% full

11. If the **rtrv-assoc** command was not performed in step 5, display the associations assigned to the local host that will be assigned to the association being configured in this procedure by entering the **rtrv-assoc** command with the **lhost** parameter.

For this example, enter this command.

rtrv-assoc: lhost="IPNODE2-1205"

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0

CARD IPLNK
ANAME LOC PORT LINK ADAPTER LPORT RPORT OPEN ALW
```

assoc2	1205	A	A	M3UA	2048	2048	YES	YES
assoc3	1205	A	A	M3UA	3000	3000	YES	YES
assoc5	1205	A	A	M3UA	1500	3000	YES	YES

IP Appl Sock/Assoc table is (8 of 4000) 1% full
 Assoc Buffer Space Used (600 KB of 3200 KB) on LOC = 1205

12. Display the application servers that the associations shown in step 11 are assigned to by entering **rtrv-as** command with the names of the associations shown in step 11.

**NOTE: If the associations assigned to the IP card were displayed in step 5 with the **rtrv-
 assoc** command and the **aname** parameter, the **rtrv-as** command does need to be
 performed. The application servers assigned to the associations that are assigned to the
 IP card are displayed in the **rtrv-
 assoc** output in step 5.**

For this example, enter these commands.

rtrv-as:aname=assoc2

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE  2000       assoc2

as4          LOADSHARE  2000       assoc2

as6          LOADSHARE  2000       assoc2
```

AS Table is (6 of 250) 1% full

rtrv-as:aname=assoc3

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as2          LOADSHARE  2000       assoc3

as3          LOADSHARE  2000       assoc3

as5          LOADSHARE  2000       assoc3
```

AS Table is (6 of 250) 2% full

rtrv-as:aname=assoc5

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as2          LOADSHARE  2000       assoc5

as3          LOADSHARE  2000       assoc5

as5          LOADSHARE  2000       assoc5
```

AS Table is (6 of 250) 2% full

The maximum number of TALI sockets and SCTP association to application server assignments that can be hosted by an IPGWx card (referenced by the **lhost** parameter of the socket and association) is 50.

If the number of TALI sockets (shown in step 8) and SCTP association to application server assignments (shown in steps 5 or 12) is less than 50, go to step 11.

If the number of TALI sockets (shown in step 8) and SCTP association to application server assignments (shown in steps 5 or 12) is 50, the local host value cannot be used in this procedure.

Repeat steps 7 and 8 and select another IP link and IP host to use in this procedure or add a new IP link using the [Configuring an IP Link](#) procedure. After the new IP link is added, perform the [Adding an IP Host](#) procedure to assign this IP address to a new local host name. After the new local host name has been added, go to step 13.

13. Display the application servers referencing the association being changed using the **rtrv-as** command with the name of the association being changed in this procedure.

NOTE: If the associations assigned to the IP card were displayed in either step 5 with the **rtrv-assoc command and the **aname** parameter, or step 12 with the **rtrv-as** command, the **rtrv-as** command does need to be performed. The application servers assigned to the associations that are assigned to the IP card are displayed in the **rtrv-assoc** output in step 5 or in the **rtrv-as** output in step 12.**

For this example, enter this command.

rtrv-as:aname=assoc2

This is an example of possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE 2000       assoc2

as4          LOADSHARE 2000       assoc2

as6          LOADSHARE 2000       assoc2

AS Table is (6 of 250) 1% full
```

If the association is assigned to any application servers, go to the [Removing an Association from an Application Server](#) procedure and remove the association from the application servers.

NOTE: If the **rept-stat-card command was performed in step 9, skip step 15 and go to step 16.**

14. Display the application running on the IP card shown in step 8 using the **rept-stat-card** command specifying the location of the IP card.

NOTE: If the **rept-stat-card command was performed in step 9, skip step 14 and go to step 15.**

For this example, enter this command.

rept-stat-card:loc=1205

This is an example of the possible output.

```
rlghncxa03w 06-10-27 17:00:36 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  APPL  PST  SST  AST
1205  114-000-000 DCM   SS7IPGW  IS-NR  Active  -----
ALARM STATUS      = No Alarms.
BPDCM GPL         = 002-102-000
IMT BUS A         = Conn
IMT BUS B         = Conn
SIGNALING LINK STATUS
  SLK  PST      LS      CLLI
  A    IS-NR    nc001    -----
Command Completed.
```

15. Verify the values of the UA parameter set you wish to assign to the association by entering the **rtrv-uaps** command with the desired parameter set.

NOTE: If the uaps parameter will not be specified with the chg-assoc command, and the adapter parameter value is being changed to either m3ua or sua, the UA parameter set 10 will be assigned to the association.

For this example, enter this command.

rtrv-uaps:set=3

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
SET  TIMER      TVALUE  PARM      PVALUE
3      1          10      1          3
3      2         3000     2          0
3      3         10000    3          1
3      4          5000    4          0
3      5           0      5          0
3      6           0      6          0
3      7           0      7          0
3      8           0      8          0
3      9           0      9          0
3     10           0     10          0
```

TIMER 2: False IP Connection Congestion Timer, max time an association can be congested before failing due to false congestion. SS7IPGW and IPGWI applications enforce 0-30000(ms).

TVALUE : Valid range = 32-bits

TIMER 3: UA Heartbeat Period Timer T(beat), time (ms) between sending of BEAT msgs by NE, SS7IPGW and IPGWI applications enforce 100(ms)-60000(ms).

TVALUE : Valid range = 32-bits

TIMER 4: UA Heartbeat Received Timer T(beat ack), timeout period for response BEAT ACK msgs by NE, SS7IPGW and IPGWI applications enforce 100(ms)-10000(ms).

TVALUE : Valid range = 32-bits

PARM 1: ASP SNM options. Each bit is used as an enabled/disabled flag for a particular ASP SNM option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast	0=Disabled , 1=Enabled
1=Response Method	0=Disabled , 1=Enabled
2-5=Reserved	
6=Broadcast Congestion Status Change	0=Disabled , 1=Enabled
7-31=Reserved	

PARM 2: ASP/AS Notification options. Each bit is used as an enabled/disabled flag for a particular ASP/AS Notification option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=ASP Active Notifications	0=Disabled , 1=Enabled
1=ASP Inactive Notifications	0=Disabled , 1=Enabled
2=ASP AS State Query	0=Disabled , 1=Enabled
3-31=Reserved	

PARM 3: UA Serviceability Options. Each bit is used as an enabled/disabled flag for a particular UA serviceability option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=UA Heartbeats	0=Disabled , 1=Enabled
1-31=Reserved	

If the UA parameter set you wish to assign to the association does not contain the desired values, go to the [Changing a UA Parameter Set](#) procedure and changed the desired parameter set values.



CAUTION: Changing a UA parameter set may affect the performance of any associations using the parameter set being changed.

16. Change the association using the **chg-assoc** command.

For this example, enter this command.

```
chg-assoc:aname=assoc2:rhost="gw200.nc-  
tekelec.com":rport=3000 :bufsize=250:rtxtthr=10000
```

NOTE: See [Flowchart 5-54](#) (Sheet 7) for the rules that apply to the **chg-assoc** command.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
CHG-ASSOC: MASP A - COMPLTD;
```

NOTE: If the value of the **open** parameter was not changed in step 2, skip step 17 and go to step 18.

17. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

For this example, enter this command.

```
chg-assoc:aname=assoc2:open=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
CHG-ASSOC: MASP A - COMPLTD;
```

18. Verify the changes using the **rtrv-assoc** command specifying the association name specified in steps 16 and 17.

For this example, enter this command.

```
rtrv-assoc:aname=assoc2
```

This is an example of possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
ANAME assoc2  
LOC 1205 IPLNK PORT A LINK A  
ADAPTER M3UA VER M3UA RFC  
LHOST IPNODE2-1205  
ALHOST ---  
RHOST gw200.nc-tekelec.com  
LPORT 2048 RPORT 3000  
ISTRMS 2 OSTRMS 2 BUFSIZE 250  
RMODE LIN RMIN 120 RMAX 800  
RTIMS 10 CWMIN 3000 UAPS 10  
OPEN YES ALW YES RTXTTHR 10000  
  
ASNAMES  
as1 as4 as6
```


```
IP Appl Sock table is (8 of 4000) 1% full  
Assoc Buffer Space Used (650 KB of 800 KB) on LOC = 1205
```


NOTE: If the [Removing an Association from an Application Server](#) procedure in step 14 was not performed, skip step 19 and go to step 20.


19. Assign the association changed in step 22 to all applicable application servers by performing one of these procedures:
 - [Adding an Existing Association to a New Application Server](#)
 - [Adding an Existing Association to an Existing Application Server](#)
20. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-30. Changing an M3UA or SUA Association










Note: If the *uaps* parameter will not be specified with the *chg-assoc* command, and the *adapter* parameter value is being changed to either *m3ua* or *sua*, the UA parameter set 10 will be assigned to the association.

Caution: Changing an UA parameter set may affect the performance of any associations using the UA parameter set being changed.



Notes:

1. If any optional parameters are not specified with the *chg-assoc* command, those values are not changed.
2. Single-slot EDCMs or E5-ENET cards can use the B Ethernet interface.
3. The sum of the number of sockets and association – application server assignments on an IPGWx card cannot exceed 50.
4. The EAGLE 5 ISS can contain a maximum of 4000 connections (associations plus sockets).
5. The value of the *lhost* and *rhost* parameters is a text string of up to 60 characters, with the first character being a letter. The command input is limited to 150 characters, including the hostnames.
6. Specifying the *lhost* parameter only creates a uni-homed endpoint. The network portion of the endpoint's IP address must be the same as the network portion of the IP address assigned to either the A or B network interface of the IP card.
7. Specifying the *lhost* and *alhost* parameters creates a multi-homed endpoint. The network portion of the IP address associated with the *lhost* parameter must be the same as the network portion of the IP address assigned to one of the network interfaces (A or B) of the IP card, and the network portion of the IP address associated with the *alhost* parameter must be the same as the network portion of the IP address assigned to the other network interface on the IP card.
8. The *alhost=none* parameter removes the alternate local host from the specified association, which also removes the multi-homed endpoint capability.
9. If the value of the *open* parameter is *yes*, only the value of the *alw* parameter can be changed. To change the values of other parameters, the value of the *open* parameter must be *no*.
10. The value of the *rmin* parameter must be less than or equal to the *rmax* parameter value.
11. The value of the *cwmin* parameter must be less than or equal to 16384.
12. If the *uaps* parameter is not specified with the *chg-assoc* command, and the *adapter* parameter value is being changed to either *m3ua* or *sua*, the *uaps* parameter value defaults to UA parameter set 10 (*uaps=10*).
13. The *port* parameter can be used in place of the *link* parameter to specify the signaling link assigned to the association.
14. The new buffer size for this association cannot exceed the available buffer size for the card. If you wish to increase the buffer size for this association to a value that is greater than available buffer size for the card, the buffer size of the other associations assigned to the card must be decreased.
15. If the *open* parameter value is being changed to *yes*, the association must contain values for the *lhost*, *lport*, *rhost*, and *rport* parameters. The *lhost* parameter value must have a signaling link assigned to it.

Configuring SCTP Retransmission Control for an M3UA or SUA Association

This procedure is used to gather the information required to configure the retransmission parameters for M3UA or SUA associations. If any assistance is needed to configure the retransmission parameters for associations, contact the Customer Care Center. Refer to [Customer Care Center](#) for the contact information.

The retransmission parameters are configured using the **rmode**, **rmin**, **rmax**, **rtimes**, and **cwmin** parameters of the **chg-assoc** command.

:rmode – The retransmission mode used when packet loss is detected. The values are **rfc** or **lin**.

- **rfc** – Standard RFC 2960 algorithm in the retransmission delay doubles after each retransmission. The RFC 2960 standard for congestion control is also used.
- **lin** – Tekelec's linear retransmission mode where each retransmission timeout value is the same as the initial transmission timeout and only the slow start algorithm is used for congestion control.

:rmin – The minimum value of the calculated retransmission timeout in milliseconds.

:rmax – The maximum value of the calculated retransmission timeout in milliseconds.

NOTE: The **rmin** and **rmax** parameter values form a range of retransmission values. The value of the **rmin** parameter must be less than or equal to the **rmax** parameter value.

:rtimes – The number of times a data retransmission occurs before closing the association.

:cwmmin – The minimum size in bytes of the association's congestion window and the initial size in bytes of the congestion window.

For associations assigned to the **ss7ipgw** or **ipgwi** applications, the value of the **cwmmin** parameter must be less than or equal to 16384.

The [Changing an M3UA or SUA Association](#) procedure is used to change the values of these parameters. In addition to using the [Changing an M3UA or SUA Association](#) procedure, these pass commands are also used in this procedure.

- **ping** – tests for the presence of hosts on the network.
- **assocrtt** – displays the SCTP round trip times for a specified association. Minimum, maximum, and average times are kept for each open association. The Retransmission Mode (RFC or LIN) and the configured Minimum and Maximum Retransmission Timeout limits are also displayed.
- **sctp** – provides a summary list of all SCTP instances.
- **sctp -a <association name>** – displays the measurements and information for a specific association.

For more information on the **pass** commands, see the *Commands Manual*.

The **chg-assoc** command contains other optional parameters that can be used to configure an association. These parameters are not shown here because they are not necessary for configuring the SCTP retransmission parameters. These parameters are explained in more detail in the [Changing an M3UA or SUA Association](#) procedure, or in the **chg-assoc** command description in the *Commands Manual*.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the associations in the database using the **rtrv-assoc** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

ANAME	CARD		IPLNK		LINK	ADAPTER	LPORT	RPORT	OPEN	ALW
	LOC	PORT								
swbel32	1201	A		A	M3UA	1030	2345	YES	YES	
a2	1305	A		A	SUA	1030	2345	YES	YES	
a3	1307	A		A	SUA	1030	2346	YES	YES	
assoc1	1201	A		A	M3UA	2000	1030	YES	YES	

2. Display the IP address assigned to the IPLINK assigned to the association being changed in this procedure by entering the **rtrv-ip-lnk** command with the card location and IPLINK port shown in step 1.

For this example, enter this command.

rtrv-ip-lnk:loc=1201:port=a

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.30      255.255.255.0  ----   ---    DIX      YES   NO
```

3. Display the local host assigned to the IP address displayed in step 2 using the **rtrv-ip-host** command with the IP address shown in step 2.

For this example, enter this command.

rtrv-ip-host:ipaddr=192.1.1.30

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

LOCAL IPADDR      LOCAL HOST
192.1.1.30      GW100. NC. TEKELEC. COM

IP Host table is (11 of 512) 2% full
```

4. Enter the **ping** pass command specifying the card location of the local host, shown in step 3, and the name of the remote host assigned to the association being changed, shown in step 1.

This command is entered several times to obtain the average round trip time. For this example, enter this command.

pass:loc=1201:cmd="ping gw100.nc.tekelec.com"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING command in progress

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PING GW100. NC. TEKELEC. COM (192.1.1.30): 56 data bytes
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=0. time=5. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=1. time=9. ms
64 bytes from tekral.nc.tekelec.com (192.1.1.30): icmp_seq=2. time=14. ms
----tekral PING Statistics----
3 packets transmitted, 3 packets received, 0% packet loss
round-trip (ms)  min/avg/max = 5/9/14

PING command complete
```

5. Go to the [Changing an M3UA or SUA Association](#) procedure and change the retransmission parameters of the association based on the results of pinging the remote host.

NOTE: If the SCTP retransmission parameters are not to be changed, do not perform steps 5 through 9. This procedure is finished.

6. Enter the **assocrtt** pass command to display the round trip time data collected after an association is established when an SCTP INIT message is sent and an acknowledgement is received.

The **assocrtt** command is entered with the card location from step 4 (the card location assigned to the association being changed), and the name of the association being changed. This association must contain the local host name used in step 2. For this example, enter this command.

pass:loc=1201:cmd="assocrtt assoc1"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

ASSOCRTT: Association round-trip time report (in milliseconds)

Retransmission Configuration
  Retransmission Mode          : LIN
  Minimum RT0: 120
  Maximum RT0: 800

Traffic Round-Trip Times
  Minimum round-trip time      : 5
  Maximum round-trip time      : 120
  Weighted Average round-trip time : 10
  Last recorded round-trip time : 10

Measured Congested Traffic Round-Trip Times
  Minimum round-trip time      : 0
  Maximum round-trip time      : 0
  Weighted Average round-trip time : 0
  Last recorded round-trip time : 0
;
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ASSOCRTT command complete
```

7. Enter the **sctp -a <association name>** pass command to determine if retransmissions have occurred.

The association name is the association name specified in step 6. Specify the card location used in step 6. For this example, enter this command.

pass:loc=1201:cmd="sctp -a assoc1"

The following is an example of the possible output

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0

Aname          Local      Local Remote      Remote
                IP Address  Port  Address      Port
Assoc1         192.168.110.12 2222  192.168.112.4 5555
                192.168.112.12

Configuration                                State
Retransmission Mode = LIN                    State = OPEN
Min. Retransmission Timeout = 10              ULP association id = 18
Max. Retransmission Timeout = 800             Number of nets = 2
Max. Number of Retries = 10                   Inbound Streams = 1
Min. Congestion Window = 3000                 Outbound Streams = 2
Inbound Streams = 2
Outbound Streams = 2
```

```

Nets Data

IP Address 192.168.112.4      State Reachable
Port       7777              Primary YES
MTU        1500              cwnd  16384
sssthresh  16384             RTO   120

IP Address 192.168.113.5      State Reachable
Port       7777              Primary NO
MTU        1500              cwnd  16384
sssthresh  16384             RTO   120

      Last Net Sent To = 192.168.112.4
      Last Net Rcvd From = 192.168.112.4
      Over All Error Count = 0
          Peers Rwnd = 13880
          My Rwnd = 16384
          Max Window = 16384
      Initial Seq Number = 24130
      Next Sending Seq Number = 124686
      Last Acked Seq Number = 124669
      Maximum Outbound Char Count = 16384
      Current Outbound Char Count = 2112
      Number Unsent Char Count = 0
      Outbound Data Chunk Count = 16
      Number Unsent = 0
      Number To Retransmit = 0

      ip datagrams rcvd = 155402
ip datagrams with data chunks rcvd = 120844
      data chunks rcvd = 367908
      data chunks read = 367900
      dup tsns rcvd = 8
      sacks rcvd = 38734
      gap ack blocks rcvd = 3
      heartbeat requests rcvd = 135
      heartbeat acks rcvd = 52
      heartbeat requests sent = 52
      ip datagrams sent = 129254
ip datagrams with data chunks sent = 73084
      data chunks sent = 396330
      retransmit data chunks sent = 135
      sacks sent = 64872
      send failed = 0
      retransmit timer count = 0
      consecutive retransmit timeouts = 0
      RTT between RMIN and RMAX inclusive = 6
      RTT greater than RMAX = 0
      fast retransmit count = 135
      recv timer count = 0
      heartbeat timer count = 244
      none left tosend = 0
      none left rwnd gate = 5
      none left cwnd gate = 8


SCTP command complete


```

8. Go to the [Changing an M3UA or SUA Association](#) procedure and change the retransmission parameters of the association based on the results of the outputs of steps 6 and 7.

NOTE: The **Weighted Average round-trip time** shown in the **assocrtt** pass command output in step 6, and the data retransmission counts shown in the **sctp -a** pass command output in step 7 are used as a guide to determine the appropriate values for the **rmode**, **rmin**, **rmax**, and **rtimes** parameters. If the retransmission parameters do not have to be adjusted, do not perform this step. This procedure is finished.

Flowchart 6-31. Configuring an M3UA or SUA Association for SCTP Retransmission Control





Changing an Application Server

This procedure is used change the characteristics of an existing application server using the **chg-as** command.

The **chg-as** command uses these parameters:

- :asname** – The name of the application server being changed.
- :mode** – The traffic mode assigned to the application server, either **loadshare** or **override**.
- :tr** – The application server recovery timer, 10 - 2000 milliseconds.

The **mode** parameter value cannot be changed unless the **open** parameter value of the all the associations assigned to the application server is set to **no**. This can be verified with the **rtrv-assoc** command.

The association assignments for an application server cannot be changed with this procedure. To change an association assignment for an application server, go to the [Removing an Association from an Application Server](#) procedure and remove the association from the application server, then perform one of these procedures to add another association to the application server:

- [Adding a New Association to an Existing Application Server](#)
- [Adding an Existing Association to an Existing Application Server](#) .

Canceling the RTRV-AS and RTRV-ASSOC Commands

Because the **rtrv-as** and **rtrv-assoc** commands used in this procedure can output information for a long period of time, the **rtrv-as** and **rtrv-assoc** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-as** and **rtrv-assoc** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-as** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-as** or **rtrv-assoc** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-as** or **rtrv-assoc** commands were entered, from another terminal other than the terminal where the **rtrv-as** or **rtrv-assoc** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the application servers in the database using the **rtrv-as** command.

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name      Mode      Tr ms      Association Names
as1          LOADSHARE  10         assoc1
              LOADSHARE  10         assoc2
              LOADSHARE  10         assoc3
              LOADSHARE  10         assoc5
              LOADSHARE  10         assoc6

as2          OVERRIDE   10         assoc7
as3          LOADSHARE  10         assoc4
```

AS table is (2 of 250) 1% full.

NOTE: If the mode parameter will not be specified with the chg-as command in step 5, skip steps 2 through 4 and go to step 5.

2. Display one of the associations assigned to the application server shown in step 1 using the **rtrv-assoc** command and specifying the association name shown in the **rtrv-as** output in step 1.

For this example, enter this command.

rtrv-assoc:aname=assoc1

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc1
LOC      1203      IPLNK PORT  A      LINK  A
ADAPTER  M3UA      VER      M3UA RFC
LHOST    gw105.nc.tekelec.com
ALHOST    ---
RHOST    gw100.ncd-economic-development.southeastern-cooridor-ash.gov
LPORT    1030      RPORT    2345
ISTRMS   2      OSTRMS   2      BUFSIZE  16
RMODE    LIN      RMIN     120      RMAX     800
RTIMES   10      CWMIN    3000    UAPS     10
OPEN     YES      ALW      YES     RTXTHR  10000

ASNAMES
```

as1

IP Appl Sock table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

NOTE: If the value of the open parameter shown in step 2 is no, skip this step and go to step 4.

3. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter.

For this example, enter this command.

chg-assoc:aname=assoc1:open=no

When this command has successfully completed, this message should appear.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD

NOTE: If all the associations assigned to the application server been displayed, skip this step and go to step 5.

4. Repeat steps 2 through 4 for all associations assigned to the application server being changed.
5. Change the application server in the database using the **chg-as** command.

For this example, enter this command

chg-as:asname=as1:mode=override:tr=1000

This is an example of possible inputs and outputs:

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-AS: MASP A - COMPLTD;

6. Verify the changes using the **rtrv-as** command.

This is an example of possible output.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0

AS Name	Mode	Tr ms	Association Names
as1	OVERRIDE	1000	assoc1 assoc2 assoc3 assoc5 assoc6
as2	OVERRIDE	10	assoc7
as3	LOADSHARE	10	assoc4

AS table is (2 of 250) 1% full

NOTE: If the value of the open parameter was not changed in step 3, skip this step and go to step 8.

7. Change the value of the **open** parameter to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter.

For this example, enter this command.

chg-assoc:aname=assoc1:open=yes

When this command has successfully completed, this message should appear.

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD


Repeat this step for all associations that were changed in step 3.


8. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-32. Changing an Application Server





Changing the CIC Values in an Existing Routing Key Containing an Application Server

This procedure is used to change the CIC values in an existing routing key using the **chg-appl-rtkey** command. These parameters are used in this procedure.

:dpc/dpca/dpci/dpcn/dpcn24 – Destination point code value that is used to filter incoming MSUs.

:opc/opca/opci/opcn/opcn24 - The originating point code value that is used to filter incoming MSUs. This value must not specify a cluster route.

NOTE: See the “Point Code Formats” section in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value either 4, 5, or 13, or for selected service indicator values, a text string can be used instead of numbers. [Table 6-19](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 6-19. Service Indicator Text String Values

Service Indicator Value	Text String
4	tup
5	isup
13	qbicc

:cics - Starting circuit identification code that is used to filter incoming MSUs. Specify with **cice** to identify the routing key to be changed.

:cice - Ending circuit identification code that is used to filter incoming MSUs. Specify with **cics** to identify the routing key to be changed.

:ncics - New starting circuit identification code that is used to filter incoming MSUs. Specify the **ncics** parameter and/or the **ncice** parameter to change the range of circuit identification codes assigned to the routing key.

:ncice - New ending circuit identification code that is used to filter incoming MSUs. Specify the **ncice** parameter and/or the **ncics** parameter to change the range of circuit identification codes assigned to the routing key.

:split - The circuit identification code value where the specified range of CIC values for the routing key specified by the **cics** and **cice** values is to be split into two routing keys. The CIC values in one routing key ranges from the **cics** value of the original routing key to a value equal to one less than the **split** value. The CIC values in the other routing key ranges from the **split** value to the **cice** value of the original routing key. All other parameters in both routing keys remain the same as in the original routing key. The range of CIC values cannot be split if the routing key contains a routing context parameter value.

:type - Key type. Identifies the type of routing key that will be changed. One of three values, **type = full/partial/default**. If **type** is not explicitly specified, **type = full** is assumed. Only the **type=full** parameter can be used in this procedure.

:rcontext – The routing context parameter value assigned to the routing key.

The **chg-appl-rtkey** command contains other parameters that are not used in this procedure.

:ssn – The subsystem number value that is used to filter incoming MSUs. See the [Adding a Routing Key Containing a Socket](#) procedure for more information on using the **ssn** parameter with a routing key.

:pstncat – The PSTN category assigned to the routing key.

:pstnid – The PSTN ID assigned to the routing key.

:norm – Specifies whether the ISUP Normalization process is enabled or disabled for MSUs using the routing key.

:nrcontext – The new routing context parameter value.

See the [Changing the Routing Context Value in an Existing Routing Key](#) procedure for changing the routing context parameter value in an existing routing key.

See the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure for changing a routing key using the **pstncat**, **pstnid**, and **norm** parameters.

Rules for Changing the Range of CIC Values in an Existing Routing Key

The parameter combinations used by the **chg-appl-rtkey** command to change the range of CIC values in the routing key are shown in [Table 6-20](#).

Table 6-20. Routing Key Parameter Combinations for Changing the Range of CIC Values in an Existing Routing Key

SI=4 (TUP)	SI=5 (ISUP)		SI=13 (QBICC)
dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca=<the DPC assigned to the routing key> ¹	dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca/dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹
si=4 ¹	si=5 ¹	si=5 ¹	si=13 ¹
opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca=<the OPC assigned to the routing key> ¹	opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca/opci/opcn/opcn24=<the OPC assigned to the routing key> ¹
cics=<the CICS value assigned to the routing key> ^{1, 2}	cics=<the CICS value assigned to the routing key> ^{1, 2}	cics=<the CICS value assigned to the routing key> ^{1, 2}	cics=<the CICS value assigned to the routing key> ^{1, 2}
cice=<the CICE value assigned to the routing key> ^{1, 2}	cice=<the CICE value assigned to the routing key> ^{1, 2}	cice=<the CICE value assigned to the routing key> ^{1, 2}	cice=<the CICE value assigned to the routing key> ^{1, 2}
type=full	type=full	type=full	type=full
ncics=<0 to 4095> ^{2, 3}	ncics=<0 to 16383> ^{2, 3}	ncics=<0 to 4095> ^{2, 3}	ncics=<0 to 4294967295> ^{2, 3}
ncice=<0 to 4095> ^{2, 3}	ncice=<0 to 16383> ^{2, 3}	ncice=<0 to 4095> ^{2, 3}	ncice=<0 to 4294967295> ^{2, 3}
rcontext=<the current routing context value assigned to the routing key> 4, 5, 6	rcontext=<the current routing context value assigned to the routing key> 4, 5, 6	rcontext=<the current routing context value assigned to the routing key> 4, 5, 6	rcontext=<the current routing context value assigned to the routing key> 4, 5, 6
1. The values for these parameters must be entered exactly as shown in the rtrv-appl-rtkey command output for the routing key being changed. However, text strings can be used in place of some numerical service indicator values. See Table 6-19 for a list of these text strings. The text string must correspond to the numerical value shown in the routing key being changed. 2. The cics and cice parameters must be specified and either the ncics or ncice parameters, or both, must be specified. If both the ncics and ncice parameters are specified, the value of the ncics parameter must be less than the value of the ncice parameter. If the ncics parameter is not specified, the value of the ncice parameter must be greater than or equal to the cics parameter value. If the ncice parameter is not specified, the value of the ncics parameter must be less than or equal to the cice parameter value. 3. The new CIC range cannot overlap the CIC range in an existing routing key. 4. The rcontext parameter can be specified only for static routing key entries containing a numerical value in the RCONTEXT column in the rtrv-appl-rtkey output. A static routing key contains the entry STATIC in the LOC column of the rtrv-appl-rtkey output. If the value in the RCONTEXT column is dashes, the rcontext parameter cannot be used. 5. If the routing key contains a numerical value in the RCONTEXT column in the rtrv-appl-rtkey output, the rcontext parameter and value can be used in place of the dpc, si, opc, cics, cice, or type=full parameters and values to identify the routing that is being changed with the chg-appl-rtkey command. However, if only the rcontext parameter is used to identify			

Changing the CIC Values in an Existing Routing Key Database Administration Manual - IP7 Secure Gateway Containing an Application Server

SI=4 (TUP)	SI=5 (ISUP)	SI=13 (QBICC)
the routing key being changed, only one of these parameters, ncics or ncice can be specified with the chg-appl-rtkey parameter. If you wish to specify the ncics and ncice parameters with the chg-appl-rtkey parameter, the dpc , si , opc , cics , cice , or type=full parameters and values must be specified with the chg-appl-rtkey command.		
6. If the routing key contains dashes in the RCONTEXT column in the rtrv-appl-rtkey output, the dpc , si , opc , cics , cice , or type parameters and values must be used with the chg-appl-rtkey command to identify the routing key being changed.		

Rules for Splitting the Range of CIC Values in an Existing Routing Key

The parameter combinations used by the **chg-appl-rtkey** command to split the range of CIC values in the routing key are shown in [Table 6-21](#).

Splitting the range of CIC values creates two routing keys. The CIC values in one routing key ranges from the **cics** value of the original routing key to a value equal to one less than the **split** value. The CIC values in the other routing key ranges from the **split** value to the **cice** value of the original routing key. All other parameters in both routing keys remain the same as in the original routing key. The range of CIC values cannot be split if the routing key contains a routing context parameter value.

Table 6-21. Routing Key Parameter Combinations for Splitting the Range of CIC Values in an Existing Routing Key

SI=4 (TUP)	SI=5 (ISUP)		SI=13 (QBICC)
dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca=<the DPC assigned to the routing key> ¹	dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹	dpc/dpca/dpci/dpcn/dpcn24=<the DPC assigned to the routing key> ¹
si=4 ¹	si=5 ¹	si=5 ¹	si=13 ¹
opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca=<the OPC assigned to the routing key> ¹	opci/opcn/opcn24=<the OPC assigned to the routing key> ¹	opc/opca/opci/opcn/opcn24=<the OPC assigned to the routing key> ¹
cics=<the CICS value assigned to the routing key> ¹	cics=<the CICS value assigned to the routing key> ¹	cics=<the CICS value assigned to the routing key> ¹	cics=<the CICS value assigned to the routing key> ¹
cice=<the CICE value assigned to the routing key> ¹	cice=<the CICE value assigned to the routing key> ¹	cice=<the CICE value assigned to the routing key> ¹	cice=<the CICE value assigned to the routing key> ¹
type=full	type=full	type=full	type=full
split=<0 to 4095> ²	split=<0 to 16383> ²	split=<0 to 4095> ²	split=<0 to 4294967295> ²
1. The values for these parameters must be entered exactly as shown in the rtrv-appl-rtkey command output for the routing key being changed. However, text strings can be used in place of some numerical service indicator values. See Table 6-19 for a list of these text strings. The text string must correspond to the numerical value shown in the routing key being changed. 2. The split parameter value must be greater than the cics parameter value and less than the cice parameter value.			

Canceling the RTRV-APPL-RTKEY Command

Because the **rtrv-appl-rtkey** command used in this procedure can output information for a long period of time, the **rtrv-appl-rtkey** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-rtkey** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-rtkey** command was entered.

- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-rtkey** command was entered, from another terminal other than the terminal where the **rtrv-appl-rtkey** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

RCONTEXT	DPCI	SI	ADPTR	ASNAME	TYPE	LOC
-----	2-100-7	6	M3UA	as4	FULL	STATIC
100	3-137-6	6	SUA	as1	FULL	STATIC
225	4-035-7	5	M3UA	as7	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-7	5	M3UA	as8	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-6	5	M3UA	as2	FULL	STATIC
-----	6-006-8	3	M3UA	as3	FULL	STATIC
-----	6-006-8	5	M3UA	as5	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
300	7-008-7	6	SUA	as6	FULL	STATIC

RCONTEXT	DPCN	SI	ADPTR	ASNAME	TYPE	LOC

RCONTEXT	DPCN24	SI	ADPTR	ASNAME	TYPE	LOC

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	*****	**	TALI	-----	DEFAULT	STATIC

STATIC Route Key table is (2 of 2000) 1% full

1105 Route Key table is (2 of 500) 1% full

1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (2 of 32000) 1% full

1105 Route Key Socket Association table is (2 of 8000) 1% full

1107 Route Key Socket Association table is (2 of 8000) 1% full

2. Select a routing key from the **rtrv-appl-rtkey** output that contains the entry M3UA or SUA in the ADPTR column.

Display the specific routing key information for the routing key being changed by entering the **rtrv-appl-rtkey** command with the **display=all** parameter.

If the routing key being changed contains a routing context value, specify the **rcontext** parameter and value shown in the **rtrv-appl-rtkey** output in step 1 for the routing key being changed.

Changing the CIC Values in an Existing Routing Key Database Administration Manual - IP7 Secure Gateway Containing an Application Server

If the routing key being changed does not contain a routing context value, specify the **DPC**, **SI**, and **TYPE** values shown in the **rtrv-appl-rtkey** output in step 1 for the routing key being changed. The service indicator value for the routing key to be used in this procedure is either 4, 5, or 13.

For this example, enter these commands.

```
rtrv-appl-rtkey:dpc=123-234-123:si=5:type=full:display=all
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT   DPC           SI SSN OPC           CICS          CICE          LOC
----- 123-234-123 5 --- 122-124-125    1           1000        STATIC

      ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
      TALI   FULL           0         0    N    N

      SNAMEs
      kchlr11201

STATIC Route Key table is (15 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full
```

```
STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

```
rtrv-appl-rtkey:rcontext=225:display=all
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT   DPCI           SI SSN OPCI          CICS          CICE          LOC
225         4-035-7        5 --- 2-007-3        2000          3000        STATIC

      ADPTR  TYPE      ASNAME
      M3UA   FULL      as7

      ANAMES
      assoc15

STATIC Route Key table is (15 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

3. Change the CIC values of the routing key by entering the **chg-appl-rtkey** command.

The parameters required for the **chg-appl-rtkey** command are determined by the type of change being made to the routing key. Go to one of these sections to determine the required parameter combination.

- Rules for Changing the Range of CIC Values in an Existing Routing Key
- Rules for Splitting the Range of CIC Values in an Existing Routing Key

To change the range of CIC values for this example, enter these commands.

```
chg-appl-rtkey:dpca=123-234-123:si=5:opca=122-124-125:cics=1 :cice=1000:ncice=2000
```

**chg-appl-
rtkey:dpci=4-035-7:si=5:opci=2-007-3:cics=2000 :cice=3000:ncice=4000**

If a routing context value is assigned to the routing key, the **rcontext** parameter and value assigned to the routing key can be used to identify the routing key being changed instead of the **dpc**, **si**, **opc**, **cics**, and **cice** parameters. If the **rcontext** parameter is specified only one of these parameters, **ncics** or **ncice**, can be specified with the **chg-appl-rtkey** parameter.

For this example, enter this command.

chg-appl-rtkey:rcontext=225:ncice=4000

To split the range of CIC values for this example, enter this command.

**chg-appl-
rtkey:dpca=123-234-123:si=5:opca=122-124-125:cics=1 :cice=1000:split=50
0**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-RTKEY: MASP A - COMPLTD
```

4. Display the new routing key information in the database by entering the **rtrv-appl-rtkey** command with the **display=all** parameter.

If the routing key being changed contains a routing context value, specify the **rcontext** parameter and value specified in the **chg-appl-rtkey** command in step 3. The **DPC**, **SI**, **CICS**, and **CICE** parameters and values used in step 3 can be specified in the **rtrv-appl-rtkey** command for routing keys containing routing context values.

If the routing key being changed does not contain a routing context value, specify the **DPC**, **SI**, **CICS**, and **CICE** parameters and values specified in the **chg-appl-rtkey** command in step 3. If the **ncics** or **ncice** parameters were specified in step 3, the **NCICS** or **NCICE** values specified in step 3 must be specified for the **cics** or **cice** parameters in this step.

For this example, enter these commands.

rtrv-appl-rtkey:dpca=123-234-123:si=5:cics=1:cice=2000 :display=all

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
RCONTEXT  DPC      SI SSN OPC      CICS      CICE      LOC
----- 123-234-123  5 --- 122-124-125  1      2000     STATIC

      ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
      TALI   FULL           0        0    N    N

      SNAMEs
      socket2
```

```
STATIC Route Key table is (15 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full
```

```
STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

rtrv-appl-rtkey:dpci=4-035-7:si=5:cics=2000:cice=4000 :display=all

or

rtrv-appl-rtkey:rcontext=225:display=all

Changing the CIC Values in an Existing Routing Key Database Administration Manual - IP7 Secure Gateway Containing an Application Server

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
RCONTEXT  DPCI          SI SSN OPCI          CICS      CICE      LOC
225        4-035-7      5 --- 2-007-3      2000      4000      STATIC
```

```
ADPTR  TYPE      ASNAME
M3UA   FULL      as7
```

```
ANAMES
assoc15
```

```
STATIC Route Key table is (15 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full
```

```
STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```

rtrv-appl-rtkey:dpca=123-234-123:si=5:cics=1:cice=1000 :display=all

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
RCONTEXT  DPC          SI SSN OPC          CICS      CICE      LOC
----- 123-234-123  5 --- 100-100-100  1         499      STATIC
```

```
ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
TALI   FULL      0         0      N     N
```

```
SNAMEs
socket2
```

```
RCONTEXT  DPC          SI SSN OPC          CICS      CICE      LOC
----- 123-234-123  5 --- 122-124-125  500      1000      STATIC
```

```
ADPTR  TYPE      PSTNCAT  PSTNID  NORM  DUP
TALI   FULL      0         0      N     N
```

```
SNAMEs
socket2
```

```
STATIC Route Key table is (16 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full
```


```
STATIC Route Key Socket Association table is (16 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full
```


5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-33. Changing the CIC Values in an Existing Routing Key Containing an Application Server





Changing the Routing Context Value in an Existing Routing Key

This procedure is used to change the routing context value in an existing routing key using the **chg-appl-rtkey** command.

The routing key being changed in this procedure must contain a number for the routing context value. If the routing context value shown for the routing key contains dashes (-), this routing key cannot be used in this procedure. The dashes shows that the routing key does not have a routing context assigned to it.

To assign a routing context value to an existing M3UA routing key, the routing key must be removed by performing the [Removing a Routing Key Containing an Application Server](#) procedure, then re-enter the routing key with the routing context value by performing the [Adding a Routing Key Containing an Application Server](#) procedure. A routing context value cannot be assigned to a TAL-I routing key. A routing context value must always be assigned to an SUA routing key.

These parameters are used in this procedure.

:rcontext – The current routing context parameter value, which has two functions:

- Provides an index of the application server traffic that the sending ASP is configured or registered to receive.
- Identifies the SS7 network context for the message. The routing context parameter implicitly defines the SS7 point code format used, the SS7 network indicator value, and the SCCP protocol type/variant/version used.

:nrcontext – The new routing context parameter value, from 0 to 4294967295. The new routing context value cannot be assigned to other routing keys.

The **chg-appl-rtkey** command contains other parameters that are not used in this procedure.

:dpc/dpca/dpci/dpcn/dpcn24 – Destination point code value that is used to filter incoming MSUs.

:opc/opca/opci/opcn/opcn24 - The originating point code value that is used to filter incoming MSUs. This value must not specify a cluster route.

:si – The service indicator value that is used to filter incoming MSUs. The range of values for the service indicator parameter (**si**) can be a numerical value from 0 to 15, or for selected service indicator values, a text string can be used instead of numbers. [Table 6-22](#) shows the text strings that can be used in place of numbers for the service indicator values.

Table 6-22. Service Indicator Text String Values

Service Indicator Value	Text String	Service Indicator Value	Text String
0	snm	4	tup
1	regtest	5	isup
2	spltst	13	qbicc
3	sccp		

:ssn – The subsystem number value that is used to filter incoming MSUs.

:cics - Starting circuit identification code that is used to filter incoming MSUs.

:cice - Ending circuit identification code that is used to filter incoming MSUs.

:type - Key type. Identifies the type of routing key that will be changed. One of three values, **type = full/partial/default**. If **type** is not explicitly specified, **type = full** is assumed.

:ncics - New starting circuit identification code that is used to filter incoming MSUs.

:ncice - New ending circuit identification code that is used to filter incoming MSUs.

:split - The circuit identification code value where the specified range of the routing key specified by the **cics** and **cice** values is to be split into two entries.

:pstncat – The PSTN category assigned to the routing key.

:pstnid – The PSTN ID assigned to the routing key.

:norm – Specifies whether the ISUP Normalization process is enabled or disabled for MSUs using the routing key.

See the [Changing the CIC Values in an Existing Routing Key Containing an Application Server](#) procedure for changing a routing key using the **ncics**, **ncice**, and **split** parameters.

See the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure for changing a routing key using the **pstncat**, **pstnid**, and **norm** parameters.

Canceling the RTRV-APPL-RTKEY Command

Because the **rtrv-appl-rtkey** command used in this procedure can output information for a long period of time, the **rtrv-appl-rtkey** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-appl-rtkey** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-appl-rtkey** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-appl-rtkey** command was entered, from another terminal other than the terminal where the **rtrv-appl-rtkey** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current routing key information in the database by entering the **rtrv-appl-rtkey** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

RCONTEXT	DPC	SI	ADPTR	ASNAME	TYPE	LOC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	123-234-123	5	TALI	-----	FULL	STATIC
-----	005-005-001	5	TALI	-----	FULL	1105
-----	005-005-001	5	TALI	-----	FULL	1105
-----	006-006-001	5	TALI	-----	FULL	1107
-----	006-006-001	5	TALI	-----	FULL	1107

RCONTEXT	DPCI	SI	ADPTR	ASNAME	TYPE	LOC
-----	2-100-7	6	M3UA	as4	FULL	STATIC
100	3-137-6	6	SUA	as1	FULL	STATIC
225	4-035-7	5	M3UA	as7	FULL	STATIC
310	6-006-6	5	SUA	as2	FULL	STATIC
-----	6-006-7	5	M3UA	as8	FULL	STATIC
1000	6-006-6	5	SUA	as2	FULL	STATIC
500	6-006-6	5	SUA	as2	FULL	STATIC
-----	6-006-8	3	M3UA	as3	FULL	STATIC
-----	6-006-8	5	M3UA	as5	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
-----	6-024-7	5	M3UA	as4	FULL	STATIC
300	7-008-7	6	SUA	as6	FULL	STATIC

RCONTEXT	DPCN	SI	ADPTR	ASNAME	TYPE	LOC


```

RCONTEXT    DPCN24      SI  ADPTR  ASNAME      TYPE      LOC
RCONTEXT    DPC          SI  ADPTR  ASNAME      TYPE      LOC
-----
*****      **  TALI  -----  DEFAULT  STATIC

```

```

STATIC Route Key table is (15 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full

```

2. Display the specific routing key information for the routing key being changed by entering the **rtrv-appl-rtkey** command with the **display=all** parameter and the **RCONTEXT** value shown in the **rtrv-appl-rtkey** output in step 1 for the routing key being changed. For this example, enter this command.

rtrv-appl-rtkey:rcontext=310:display=all

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

RCONTEXT    DPCI          SI  SSN  OPCI      CICS      CICE      LOC
310         6-006-6      5  ---  1-002-3   75        100      STATIC
      ADPTR  TYPE      ASNAME
      SUA    FULL      as2

      ANAMES
      assoc1

STATIC Route Key table is (15 of 2000) 1% full
1105  Route Key table is (2 of 500) 1% full
1107  Route Key table is (2 of 500) 1% full

```

```

STATIC Route Key Socket Association table is (15 of 32000) 1% full
1105  Route Key Socket Association table is (2 of 8000) 1% full
1107  Route Key Socket Association table is (2 of 8000) 1% full

```

If the routing context value shown for the routing key is dashes (-), this routing key cannot be used in this procedure. The dashes show that the routing key does not have a routing context assigned to it.

To assign a routing context value to a M3UA routing key that does not have a routing context value, the routing key must be removed by performing the [Removing a Routing Key Containing an Application Server](#) procedure. Re-enter the routing key with the routing context value by performing the [Adding a Routing Key Containing an Application Server](#) procedure. If you do not wish to assign a routing context value to this routing key, but you wish to change the routing context value in another routing key, repeat this step with another routing key shown in step 1. If you do not wish to assign a routing context value to this routing key, and do not wish to change the routing context value in another routing key, this procedure cannot be performed.

If the routing key contains a routing context value, go to step 3.

3. Display the association displayed in the **rtrv-appl-rtkey** output in step 2, using the **rtrv-assoc** command with the association name shown in step 2.

rtrv-assoc:aname=assoc1

This is an example of possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ANAME assoc1
LOC      1203      IPLNK PORT  A      LINK  A
ADAPTER  SUA      VER      SUA RFC
LHOST    gw105.nc.tekelec.com
ALHOST   ---
RHOST    gw100.nc.tekelec.com

```

```
LPORT    1030      RPORT    1030
ISTRMS   2         OSTRMS   2         BUFSIZE  16
RMODE    LIN       RMIN     120        RMAX     800
RTIMES   10        CWMIN    3000       UAPS     10
OPEN     YES       ALW      YES        RTXTHR   10000
```

```
ASNAMES
as2
```

IP Appl Sock table is (4 of 4000) 1% full
Assoc Buffer Space Used (16 KB of 800 KB) on LOC = 1203

Repeat this step for each association name displayed in step 2.

NOTE: If the open parameter value for all the associations assigned to the application server is no (shown in step 3), skip step 4 and go to step 5.

4. Change the value of the **open** parameter to **no** by specifying the **chg-assoc** command with the **open=no** parameter. For this example, enter this command.

chg-assoc:aname=assoc1:open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```



CAUTION: The IP connections using the associations specified in this step will not be able to carry any traffic when the open parameter is changed to no.

Repeat this step for all the associations assigned to the application server that have the **open=yes** parameter value.

5. Change the routing key information to the database by entering the **chg-appl-rtkey** command with the current and new routing context values. For this example, enter this command.

chg-appl-rtkey:nrcontext=5280:rcontext=310

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
CHG-APPL-RTKEY: MASP A - COMPLTD
```

6. Display the new routing key information in the database by entering the **rtrv-appl-rtkey** command with the new routing context value specified in step 5 and the **display=all** parameter. For this example, enter this command.

rtrv-appl-rtkey:rcontext=5280:display=all

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
RCONTEXT  DPCI      SI SSN OPCI      CICS      CICE      LOC
5280      6-006-6      5 --- 1-002-3      75        100      STATIC
      ADPTR  TYPE      ASNAME
      SUA   FULL      as2
```

```
ANAMES
assoc1
```

```
STATIC Route Key table is (7 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full
```

STATIC Route Key Socket Association table is (7 of 32000) 1% full

```
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

NOTE: If step 4 was not performed in this procedure, skip step 7 and go to step 8.

7. Change the value of the **open** parameter of the associations that were changed in step 4 to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter. For this example, enter this command.

chg-assoc : aname=assoc1 : open=yes

When this command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-ASSOC: MASP A - COMPLTD;
```


Repeat this step for all the associations that were changed in step 4.

8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-34. Changing the Routing Context Value in an Existing Routing Key





Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations

Use this procedure to change the SCTP checksum algorithm, either Adler-32 or CRC-32c, applied to traffic on SCTP associations. The **sctpchecksum** parameter of the **chg-sg-opts** command is used to change this option. This option is a system-wide option that applies to associations assigned to IP cards running the SS7IPGW and IPGWI applications.

Once the SCTP checksum option has been changed, the associations on each IP card need to be reset by changing the **open** parameter value for each association to **no**, then back to **yes**. This ensures that the associations on the IP card are using the new SCTP checksum algorithm.

Canceling the RTRV-ASSOC Command

Because the **rtrv-assoc** command used in this procedure can output information for a long period of time, the **rtrv-assoc** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-assoc** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-assoc** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-assoc** command was entered, from another terminal other than the terminal where the **rtrv-assoc** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the current IP options in the database by entering the **rtrv-sg-opts** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SCTPCSUM:      adler32
```

NOTE: The **rtrv-sg-opts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sg-opts** command, see the **rtrv-sg-opts** command description in the *Commands Manual*.

2. Display the cards in the EAGLE 5 ISS by entering the **rtrv-card** command. This is an example of the possible output.

```
rlghncxa03w 06-10-15 16:34:56 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC      LSET NAME      LINK SLC
1101    TSM          SCCP
1102    TSM          GLS
1104    ACMENET      STPLAN
1113    GSPM         EOAM
1114    TDM-A
1115    GSPM         EOAM
1116    TDM-B
1117    MDAL
1201    LIMDS0       SS7ANSI      lsn1          A      0      lsn2          B      1
1202    DCM          IPLIM        ipnode2       A      1
1203    LIMV35       SS7ANSI      lsn2          A      0      lsn1          B      1
1204    LIMATM       ATMANSI      atmgwy        A      0
1205    DCM          IPLIM        ipnode1       A      0      ipnode3       B      1
1207    DCM          IPLIM        ipnode2       A      0
1303    DCM          IPLIM        ipnode3       A      0      ipnode1       B      1
1305    DCM          IPLIM        ipnode4       A      0
1308    DCM          IPLIM        ipnode3       B      2
          ipnode1       A1     2      ipnode4       B2     1
1315    DCM          SS7IPGW      ipgtwy1       A
1317    DCM          IPGWI        ipgtwy2       A
```

Record the card location, shown in the **LOC** column, and signaling link, shown in the **LINK** column, information for all cards running the SS7IPGW and IPGWI applications.

3. At the IP near end node, stop all traffic to one of the IP cards running the SS7IPGW or IPGWI applications on the EAGLE 5 ISS.
4. At the EAGLE 5 ISS, enter the **msucount -l** pass command with the card location of the IP card selected in step 3. For this example, enter this command.

pass: loc=1315:cmd="msucount -l"

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
PASS: Command sent to card
```

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
MSUCOUNT: Command In Progress
```

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

```
MSUCOUNT: MSU Count Report
```

```
-----
Link Measurements (Link A)
-----
Transmit Counts                      Receive Counts
-----
rate  msus      bytes                      rate  msus      bytes
-----
2000  4294967295  4294967295  2000  4294967295  4294967295
MTP Primitive (MTPP) counts          Reroute Counts
-----
sent pdus  rcvd pdus  dscrd pdus  sent msus  rcvd msus
-----
4294967295 4294967295 4294967295 4294967295 4294967295
```

END of Report

5. Display the IP addresses of the IP links in the database by entering the **rtrv-ip-lnk** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR      SUBMASK      DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1202 A    192.1.1.10  255.255.255.0 HALF    10     DIX      NO    NO
1202 B    -----    -----    HALF    10     DIX      NO    NO
1205 A    192.1.1.12  255.255.255.0 HALF    10     DIX      NO    NO
1205 B    -----    -----    HALF    10     DIX      NO    NO
1207 A    192.1.1.14  255.255.255.0 HALF    10     DIX      NO    NO
1207 B    -----    -----    HALF    10     DIX      NO    NO
1303 A    192.1.1.20  255.255.255.0 HALF    10     DIX      NO    NO
1303 B    -----    -----    HALF    10     DIX      NO    NO
1305 A    192.1.1.22  255.255.255.0 HALF    10     DIX      NO    NO
1305 B    -----    -----    HALF    10     DIX      NO    NO
1308 A    192.1.1.24  255.255.255.0 HALF    10     DIX      NO    NO
1308 B    -----    -----    HALF    10     DIX      NO    NO
1315 A    192.1.1.50  255.255.255.0 HALF    10     DIX      NO    NO
1315 B    -----    -----    HALF    10     DIX      NO    NO
1317 A    192.1.1.52  255.255.255.0 HALF    10     DIX      NO    NO
1317 B    -----    -----    HALF    10     DIX      NO    NO
```

IP-LNK table is (16 of 512) 3% full.

6. Display the current IP host information in the database by entering the **rtrv-ip-host** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
LOCAL IPADDR  LOCAL HOST
192.1.1.10    IPNODE1-1201
192.1.1.12    IPNODE1-1203
```

Changing the SCTP Checksum Algorithm Option for Database Administration Manual - IP7 Secure Gateway M3UA and SUA Associations

```

192.1.1.14      IPNODE1-1205
192.1.1.20      IPNODE2-1201
192.1.1.22      IPNODE2-1203
192.1.1.24      IPNODE2-1205
192.1.1.32      KC-HLR2
192.1.1.50      DN-MSC1
192.1.1.52      DN-MSC2
REMOTE IPADDR   REMOTE HOST
150.1.1.5       NCDEPTECONOMIC_DEVELOPMENT. SOUTHEASTERN_COORIDOR_ASHVL. GOV

```

IP Host table is (10 of 512) 2% full

7. Display the associations assigned to the IP card specified in step 4, using the **rtrv-assoc** command with the local host name of the associations assigned to the IP card. To find the local host name of the association, the card location of the IP card is assigned to an IP address in the IP link table (**rtrv-ip-lnk** output). The IP address is assigned to a hostname in the IP host table (**rtrv-ip-host** output).

For this example, the local host name of associations assigned to the IP card 1315 (the card specified in step 4) is DN-MSC1. Enter this command.

rtrv-assoc: lhost=dn-msc1

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
CARD IPLNK
ANAME      LOC  PORT  LINK ADAPTER LPORT RPORT OPEN ALW
assoc3     1315 A    A   SUA    2345  1025  YES  YES
assoc6     1315 A    A   SUA    4156  1025  YES  YES

```

IP Appl Sock/Assoc table is (9 of 4000) 1% full

Assoc Buffer Space Used (32 KB of 3200 KB) on LOC = 1315

8. At the EAGLE 5 ISS, enter the **msucount -a** pass command with the card location specified in step 4 and the association names shown in step 7. For this example, enter this command.

pass: loc=1315:cmd="msucount -a assoc3"

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: Command In Progress

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: MSU Count Report

-----
IP Connection Measurements
-----
Receive Counts                      Transmit Counts
-----
msus      bytes                    msus      bytes
-----
4294967295 4294967295                    4294967295 4294967295
Receive Discard Counts              Transmit Discard Counts
-----
reason      count                    reason      count
-----
link state   4294967295                    sccp msg type 4294967295
sccp msg type 4294967295                    sccp class    4294967295
sccp class   4294967295                    normalization error 4294967295
sccp called party 4294967295                    invalid traffic type 4294967295
sccp calling party 4294967295                    M3UA conversion error 4294967295
isup sio     4294967295                    SUA conversion error 4294967295
normalization error 4294967295

```



```

error in XSRV packet 4294967295
M3UA PDU error      4294967295
SUA PDU error       4294967295
invalid rcontext    4294967295
Stored Transmit Discard Data
-----
no stored transmit discard data
Stored Receive Discard Data
-----
53 41 53 49 69 73 6f 74 11 00 87 0a 01 03 01 05
05 00 01 02 03 04 05 06 07 08 09 00 00 00 00 00

```

END of Report

pass:loc=1315:cmd="msucount -a assoc6"

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

```

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: Command In Progress

```

```

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: MSU Count Report

```

IP Connection Measurements

Receive Counts

Transmit Counts

msus bytes

msus bytes

4294967295 4294967295

4294967295 4294967295

Receive Discard Counts

Transmit Discard Counts

reason count

reason count

link state 4294967295

sctp msg type 4294967295

sctp msg type 4294967295

sctp class 4294967295

sctp class 4294967295

normalization error 4294967295

sctp called party 4294967295

invalid traffic type 4294967295

sctp calling party 4294967295

M3UA conversion error 4294967295

isup sio 4294967295

SUA conversion error 4294967295

normalization error 4294967295

error in XSRV packet 4294967295

M3UA PDU error 4294967295

SUA PDU error 4294967295

invalid rcontext 4294967295

Stored Transmit Discard Data

no stored transmit discard data

Stored Receive Discard Data

```

53 41 53 49 69 73 6f 74 11 00 87 0a 01 03 01 05
05 00 01 02 03 04 05 06 07 08 09 00 00 00 00 00

```

END of Report

9. At the IP near end node, disconnect all the associations attached to the IP card specified in step 8.
10. At the EAGLE 5 ISS, place the signaling link on this IP card out of service using the **dact -s lk** command. For this example, enter this command.

dact -s lk:loc=1315:link=a

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0  
Deactivate Link message sent to card
```

11. Change the SCTP checksum option in the database using the **chg-sg-opts** command. For this example, enter this command.

chg-sg-opts:sctpcsum=crc32c

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:19:37 GMT EAGLE5 36.0.0  
CHG-SG-OPTS: MASP A - COMPLTD
```

12. Verify that the SCTP checksum algorithm was changed using the **rtrv-sg-opts** command. The SCTP checksum algorithm option value is shown in the **SCTPCSUM** parameter. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0  
SCTPCSUM:          crc32c
```

NOTE: The rtrv-sg-opts command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the rtrv-sg-opts command, see the rtrv-sg-opts command description in the *Commands Manual*.

13. Change the value of the **open** parameter of the associations shown in step 7 to **no** by specifying the **chg-assoc** command with the **open=no** parameter. For this example, enter this command.

chg-assoc:aname=assoc3:open=no

chg-assoc:aname=assoc6:open=no

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
CHG-ASSOC: MASP A - COMPLTD;
```

14. Change the value of the **open** parameter of the associations changed in step 13 to **yes** by specifying the **chg-assoc** command with the **open=yes** parameter. For this example, enter this command.

chg-assoc:aname=assoc3:open=yes

chg-assoc:aname=assoc6:open=yes

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0  
CHG-ASSOC: MASP A - COMPLTD;
```

15. At the IP near end node, configure all the associations attached to the IP card specified in step 14 to use the SCTP checksum algorithm.
16. Put the signaling link that was placed out of service in step 9 back into service using the **act-slk** command. For example, enter this command.

act-slk:loc=1315:link=a

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-07 11:11:28 GMT EAGLE5 36.0.0  
Activate Link message sent to card
```

17. Verify the in-service normal (IS-NR) status of the signaling link by using the **rept-stat-slk** command and specifying the card location and link value specified in step 16. For example, enter this command.

rept-stat-slk:loc=1315:link=a

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1315,A   ipgtwy1   -----  IS-NR      Avail    ----
Command Completed.
```

18. At the IP near end node, connect one of the associations attached to the IP card specified in step 13.
19. At the EAGLE 5 ISS, enter the **rept-stat-assoc** command specifying the association names specified with the **chg-assoc** command in steps 13 and 14 to verify that the association is established with the IP near end node. For this example, enter this command.

rept-stat-assoc:aname=assoc3

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

          CARD IPLNK
        ANAME  LOC PORT LINK PST      SST      ASPID
        as1    1315 A    A    IS-NR    ESTABLISHED 4294967295

        ASNAME  ANAME      ASP-STATE
        assoc3  as1        ASP-ACTIVE
```

Command Completed.

rept-stat-assoc:aname=assoc6

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

          CARD IPLNK
        ANAME  LOC PORT LINK PST      SST      ASPID
        as6    1315 A    A    IS-NR    ESTABLISHED 4294967295

        ASNAME  ANAME      ASP-STATE
        assoc6  as6        ASP-ACTIVE
```

Command Completed.

20. Enter the **netstat -p sctp** pass command with the card location of the IP card to determine if any errors have occurred. For this example, enter this command. For this example, enter this command.

pass:loc=1315:cmd="netstat -p sctp"

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
SCTP:
  0 ip packets sent
    0 ip packets sent with data chunk
    0 control chunks (excludes retransmissions)
    0 ordered data chunks (excludes retransmissions)
    0 unordered data chunks (excludes retransmissions)
    0 user messages fragmented due to MTU
    0 retransmit data chunks sent
    0 sacks sent
    0 send failed
  0 ip packets received
    0 ip packets received with data chunk
    0 control chunks (excludes duplicates)
    0 ordered data chunks (excludes duplicates)
    0 unordered data chunks (excludes duplicates)
```

```

0 user messages reassembled
0 data chunks read
0 duplicate tsns received
0 sacks received
0 gap ack blocks received
0 out of the blue
0 with invalid checksum
0 connections established
0 by upper layer
0 by remote endpoint
0 connections terminated
0 ungracefully
0 gracefully
0 associations supported
0 associations dropped due to retransmits
0 consecutive retransmit timeouts
0 retransmit timer count
0 fast retransmit count
0 heartbeat requests received
0 heartbeat acks received
0 heartbeat requests sent
0 milliseconds cookie life at 4-way start-up handshake
0 retransmission attempts are allowed at start-up phase

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0

NETSTAT command complete

If errors are shown in the pass command output, contact the Customer Care Center. Refer to [Customer Care Center](#) for the contact information.

21. At the IP near end node, connect all the other associations attached to the IP card specified in step 20.
22. At the IP near end node, activate one of the associations attached to the IP card specified in step 20.
23. At the EAGLE 5 ISS, enter the **msucount -l** pass command with the card location of the IP card specified in step 20. For this example, enter this command.

pass: loc=1315:cmd="msucount -l"

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
MSUCOUNT: Command In Progress

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
MSUCOUNT: MSU Count Report

Link Measurements (Link A)

Transmit Counts			Receive Counts		
rate	msus	bytes	rate	msus	bytes
2000	4294967295	4294967295	2000	4294967295	4294967295

MTP Primitive (MTPP) counts			Reroute Counts	
sent pdus	rcvd pdus	dscrd pdus	sent msus	rcvd msus
4294967295	4294967295	4294967295	4294967295	4294967295

END of Report

24. At the EAGLE 5 ISS, enter the **msucount -a** pass command with the card location specified in step 23 and the association names specified in step 19. For this example, enter this command.

pass:loc=1315:cmd="msucount -a assoc3"

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: Command In Progress

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: MSU Count Report

IP Connection Measurements

Receive Counts		Transmit Counts	
msus	bytes	msus	bytes
4294967295	4294967295	4294967295	4294967295
Receive Discard Counts		Transmit Discard Counts	
reason	count	reason	count
link state	4294967295	sctp msg type	4294967295
sctp msg type	4294967295	sctp class	4294967295
sctp class	4294967295	normalization error	4294967295
sctp called party	4294967295	invalid traffic type	4294967295
sctp calling party	4294967295	M3UA conversion error	4294967295
isup sio	4294967295	SUA conversion error	4294967295
normalization error	4294967295		
error in XSRV packet	4294967295		
M3UA PDU error	4294967295		
SUA PDU error	4294967295		
invalid rcontext	4294967295		

Stored Transmit Discard Data

no stored transmit discard data

Stored Receive Discard Data

53 41 53 49 69 73 6f 74 11 00 87 0a 01 03 01 05
05 00 01 02 03 04 05 06 07 08 09 00 00 00 00 00

END of Report

pass:loc=1315:cmd="msucount -a assoc6"

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PASS: Command sent to card

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: Command In Progress

rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
MSUCOUNT: MSU Count Report

IP Connection Measurements

Receive Counts		Transmit Counts	
msus	bytes	msus	bytes
4294967295	4294967295	4294967295	4294967295
Receive Discard Counts		Transmit Discard Counts	

Changing the SCTP Checksum Algorithm Option for Database Administration Manual - IP7 Secure Gateway M3UA and SUA Associations

```

-----
reason          count      reason          count
-----
link state      4294967295  sctp msg type   4294967295
sctp msg type   4294967295  sctp class      4294967295
sctp class      4294967295  normalization error 4294967295
sctp called party 4294967295  invalid traffic type 4294967295
sctp calling party 4294967295 M3UA conversion error 4294967295
isup sio        4294967295  SUA conversion error 4294967295
normalization error 4294967295
error in XSRV packet 4294967295
M3UA PDU error  4294967295
SUA PDU error    4294967295
invalid rcontext 4294967295
Stored Transmit Discard Data
-----
no stored transmit discard data
Stored Receive Discard Data
-----
53 41 53 49 69 73 6f 74 11 00 87 0a 01 03 01 05
05 00 01 02 03 04 05 06 07 08 09 00 00 00 00 00

```

END of Report

If the outputs of the pass commands in steps 23 and 24 show that traffic is not flowing over the association, contact the Customer Care Center. Refer to [Customer Care Center](#) for the contact information.

25. At the IP near end node, activate all the other associations attached to the IP card specified in step 24.
26. Repeat steps 3 through 25 to update the other IP cards in the EAGLE 5 ISS running the SS7IPGW and IPGWI applications with the new SCTP checksum algorithm.
27. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


28. If the **rtrv-card** output in step 2 shows cards running the IPLIM or IPLIMI applications, perform the [Changing the SCTP Checksum Algorithm Option for M2PA Associations](#) procedure.


If the **rtrv-card** output in step 2 shows that there are no cards running the IPLIM or IPLIMI applications, this procedure is finished.

Flowchart 6-35. Changing the SCTP Checksum Algorithm Option for M3UA and SUA Associations









Changing a UA Parameter Set

Use this procedure to change the values in a UA (user adapter) parameter set using the **chg-uaps** command. The **chg-uaps** command uses these parameters:

:set – the UA parameter set being changed, from 1 - 9

:scrset – the source UA parameter set used to copy the values from one UA parameter set to another, from 1 to 10.

:timer – the timer being changed, from 1 to 10. Currently, there are only three timers defined:

- Timer 2 – The False IP Connection Congestion Timer – the maximum amount of time (in milliseconds) that an association is allowed to remain congested before failing due to false connection congestion.
- Timer 3 – The UA Heartbeat Period Timer – The frequency, in milliseconds, that heartbeat messages are transmitted.
- Timer 4 – The UA Heartbeat Received Timer – The amount of time, in milliseconds, that the EAGLE 5 ISS waits for a response to the heartbeat message that was transmitted. If a response to the heartbeat message is not received in the amount of time defined by Timer 4, the association is torn down

:tvalue – The value of the timer specified by the **timer** parameter.

- The value of timer 2 is from 0 to 30,000 milliseconds. The system default value is 3,000 milliseconds.
- The value of timer 3 is from 0 to 60,000 milliseconds. The system default value is 10,000 milliseconds.
- The value of timer 4 is from 0 to 10,000 milliseconds. The system default value is 5,000 milliseconds.

:parm – the UA parameters, from 1 to 10. Currently, only two UA parameters are defined:

- 1 – Controlling ASP SNM Behavior
- 2 – Controlling ASP/Application Server State Notification Behavior
- 3 – UA Serviceability Options

:pvalue – the value of the UA parameters, which is dependent on the **parm** parameter value. The value of the **pvalue** parameter is a bit-mapped value, requiring a 0 in the specific bit position to disable the item, or a 1 in the specific bit position to enable the item. The value of the **pvalue** parameter is a 32-bit number. Any bits not specified in the following lists are not used.

- If the **parm** value is 1, the bits used by the **pvalue** parameter are:
 - 0 – Broadcast – controls broadcast phase SNM TFPs, TFRs and TFAs that are sent when a destination's status changes. If this flag is set, SNM TFPs/TFRs/TFAs are replicated to all associations/sockets that meet the Multicast SNM Criteria and have this enabled. The default is to enable all broadcast phase messages.
 - 1 – Response Method – controls the sending of an SNM TFC/UPU as a reply to a message received on an association/socket for an unavailable destination. The SNM TFC/UPU is replicated to all associations/sockets that have this capability and meet the Response SNM Criteria. The default is to allow the response to be sent.
 - 6 – Broadcast Congestion Status Change – controls the sending of unsolicited congestion status changes by an ASP. Unsolicited congestion status messages (TFCs generated when a destination's congestion status changes) are replicated to all ASPs who have this capability and meet the Multicast SNM Criteria. The default is to generate no unsolicited congestion status changes.

[Table 6-23](#) shows the values can be entered for the **pvalue** parameter if the **parm** value is 1. The **pvalue** parameter value can be entered as a hexadecimal or a decimal number.

Table 6-23. Valid PVALUE Parameter Values if PARM=1

Bits Enabled	Bits Disabled	Hexadecimal Value	Decimal Value
None	Bit 0 - Broadcast Bit 1 - Response Method Bit 6 - Broadcast Congestion Status Change	h'0	0
Bit 0 - Broadcast	Bit 1 - Response Method Bit 6 - Broadcast Congestion Status Change	h'1	1
Bit 1 - Response Method	Bit 0 - Broadcast Bit 6 - Broadcast Congestion Status Change	h'2	2
Bit 0 - Broadcast Bit 1 - Response Method	Bit 6 - Broadcast Congestion Status Change	h'3*	3*
Bit 6 - Broadcast Congestion Status Change	Bit 0 - Broadcast Bit 1 - Response Method	h'40	64
Bit 6 - Broadcast Congestion Status Change Bit 0 - Broadcast	Bit 1 - Response Method	h'41	65
Bit 6 - Broadcast Congestion Status Change Bit 1 - Response Method	Bit 0 - Broadcast	h'42	66
Bit 0 - Broadcast Bit 1 - Response Method Bit 6 - Broadcast Congestion Status Change	None	h'43	67
* The system default value			

- If the **parm** value is 2, the bits used by the **pvalue** parameter are:
 - 0 – ASP Active Notifications – controls the sending of ASP-Active notifications. If this value is specified, an ASP-Default notification is sent when an ASP transitions to the ASP-ACTIVE state. The default is not to send ASP-Active notifications.
 - 1 – ASP Inactive Notifications – controls the sending of ASP-Inactive notifications. If this value is specified, an ASP-Inactive notification is sent when an ASP transitions to the ASP-INACTIVE state. The default is not to send ASP-Inactive notifications.

NOTE: To see the ASP activations and inactivations, bits 0 and 1 of the pvalue parameter value need to be enabled. See [Table 6-24](#) .

- 2 – ASP AS State Query – controls the sending of ASP/AS State notifications on request by an ASP. If this value is specified, the EAGLE 5 ISS responds with ASP and AS state notifications if the remote ASP sends ASP-UP or ASP-INACTIVE, while the local ASP is in the ASP-INACTIVE state, or the

remote ASP sends an ASP-ACTIVE notification while the local ASP is in the ASP-ACTIVE state. The default is not to send ASP/AS state notifications.

Table 6-24 shows the values can be entered for the **pvalue** parameter if the **parm** value is 2. The **pvalue** parameter value can be entered as a hexadecimal or a decimal number.

Table 6-24. Valid PVALUE Parameter Values if PARM=2

Bits Enabled	Bits Disabled	Hexadecimal Value	Decimal Value
None	Bit 0 - ASP Activate Notifications Bit 1 - ASP Inactivate Notifications Bit 2 - ASP AS State Query	h'0*	0*
Bit 0 - ASP Activate Notifications	Bit 1 - ASP Inactivate Notifications Bit 2 - ASP AS State Query	h'1	1
Bit 1 - ASP Inactivate Notifications	Bit 0 - ASP Activate Notifications Bit 2 - ASP AS State Query	h'2	2
Bit 0 - ASP Activate Notifications Bit 1 - ASP Inactivate Notifications	Bit 2 - ASP AS State Query	h'3	3
Bit 2 - ASP AS State Query	Bit 0 - ASP Activate Notifications Bit 1 - ASP Inactivate Notifications	h'4	4
Bit 0 - ASP Activate Notifications Bit 2 - ASP AS State Query	Bit 1 - ASP Inactivate Notifications	h'5	5
Bit 1 - ASP Inactivate Notifications Bit 2 - ASP AS State Query	Bit 0 - ASP Activate Notifications	h'6	6
Bit 0 - ASP Activate Notifications Bit 1 - ASP Inactivate Notifications Bit 2 - ASP AS State Query	None	h'7	7
* The system default value			

- If the **parm** value is 3, only bit 0 (UA heartbeats) is the only bit used by the **pvalue** parameter. If the value of this bit is 1 (h'1), heartbeat messages are transmitted in the ASP-Down, ASP-Active, and ASP-Inactive states on connections from the Eagle 5 ISS to the far-end node. If the value of this bit is 0, the heartbeat messages are not transmitted.

UA parameter set 10 contains the default values for the UA parameter sets and cannot be changed.

The **set** and **scrset** parameter values cannot be the same.

If the **scrset** parameter is specified, no other optional parameter may be specified.

The **timer** and **tvalue** parameters must be specified together. If one is specified, the other must be specified.

The **parm** and **pvalue** parameters must be specified together. If one is specified, the other must be specified.

Canceling the RTRV-UAPS Command

Because the **rtrv-uaps** command used in this procedure can output information for a long period of time, the **rtrv-uaps** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-uaps** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-uaps** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-uaps** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-uaps** command was entered, from another terminal other than the terminal where the **rtrv-uaps** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

Procedure

1. Display the values in the UA parameter set being changed by entering the **rtrv-uaps** command and specifying the desired UA parameter set number, from 1 to 9. For this example, enter this command.

rtrv-uaps:set=3

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
```

SET	TIMER	TVALUE	PARM	PVALUE
3	1	0	1	3
3	2	3000	2	0
3	3	10000	3	1
3	4	5000	4	0
3	5	0	5	0
3	6	0	6	0
3	7	0	7	0
3	8	0	8	0
3	9	0	9	0
3	10	0	10	0

TIMER 2: False IP Connection Congestion Timer, max time an association can be congested before failing due to false congestion. SS7IPGW and IPGWI applications enforce 0-30000(ms).

TVALUE : Valid range = 32-bits

TIMER 3: UA Heartbeat Period Timer T(beat), time (ms) between sending of BEAT msgs by NE, SS7IPGW and IPGWI applications enforce 100(ms)-60000(ms).

TVALUE : Valid range = 32-bits

TIMER 4: UA Heartbeat Received Timer T(beat ack), timeout period for response BEAT ACK msgs by NE, SS7IPGW and IPGWI applications enforce 100(ms)-10000(ms).

TVALUE : Valid range = 32-bits

PARM 1: ASP SNM options. Each bit is used as an enabled/disabled flag for a particular ASP SNM option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast	0=Disabled , 1=Enabled
1=Response Method	0=Disabled , 1=Enabled
2-5=Reserved	
6=Broadcast Congestion Status Change	0=Disabled , 1=Enabled
7-31=Reserved	

PARM 2: ASP/AS Notification options. Each bit is used as an enabled/disabled flag for a particular ASP/AS Notification option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=ASP Active Notifications	0=Disabled , 1=Enabled
1=ASP Inactive Notifications	0=Disabled , 1=Enabled
2=ASP AS State Query	0=Disabled , 1=Enabled
3-31=Reserved	

PARM 3: UA Serviceability Options. Each bit is used as an enabled/disabled flag for a particular UA serviceability option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=UA Heartbeats	0=Disabled , 1=Enabled
1-31=Reserved	

2. Change the UA parameter set values using the **chg-uaps** command with the UA parameter set value used in step 1. If the **parm** and **pvalue** parameters are being specified, see [Table 6-23](#) , [Table 6-24](#) , or the description of the **parm=3** parameter for the valid values of the **pvalue** parameter. For this example, enter this command.

```
chg-uaps:set=3:timer=2:tvalue=2000:parm=2:pvalue=1
```

The value of the **pvalue** parameter can be entered as either a decimal value or a hexadecimal value. This example shows the **pvalue** parameter value of the **chg-uaps** command being entered as a decimal value. To specify the value of the **pvalue** parameter in the example used in this step as a hexadecimal value, specify the **pvalue=h'1** parameter.

```
chg-uaps:set=3:timer=2:tvalue=2000:parm=2:pvalue=h'1
```

If the values from one UA parameter set are being copied to another UA parameter set, only the **set** and **scrset** parameters can be specified with the **chg-uaps** command. For example, to copy the values from UA parameter set 10 to UA parameter set 5, enter this command.

```
chg-uaps:set=5:scrset=10
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CHG-UAPS: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-uaps** command with the UA parameter set name used in step 2. For this example, enter this command.

```
rtrv-uaps:set=3
```

This is an example of possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
SET  TIMER      TVALUE  PARM      PVALUE
3      1           0        1          3
3      2         2000        2          1
3      3        10000        3          1
3      4         5000        4          0
3      5           0        5          0
3      6           0        6          0
3      7           0        7          0
3      8           0        8          0
3      9           0        9          0
3     10           0       10          0
```

TIMER 2: False IP Connection Congestion Timer, max time an association can be congested before failing due to false congestion. SS7IPGW and IPGWI applications enforce 0-30000(ms).

TVALUE : Valid range = 32-bits

TIMER 3: UA Heartbeat Period Timer T(beat), time (ms) between sending of BEAT msgs by NE, SS7IPGW and IPGWI applications enforce 100(ms)-600000(ms).

TVALUE : Valid range = 32-bits

TIMER 4: UA Heartbeat Received Timer T(beat ack), timeout period for response BEAT ACK msgs by NE, SS7IPGW and IPGWI applications enforce 100(ms)-100000(ms).

TVALUE : Valid range = 32-bits

PARM 1: ASP SNM options. Each bit is used as an enabled/disabled flag for a particular ASP SNM option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=Broadcast	0=Disabled , 1=Enabled
1=Response Method	0=Disabled , 1=Enabled
2-5=Reserved	
6=Broadcast Congestion Status Change	0=Disabled , 1=Enabled
7-31=Reserved	

PARM 2: ASP/AS Notification options. Each bit is used as an enabled/disabled flag for a particular ASP/AS Notification option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=ASP Active Notifications	0=Disabled , 1=Enabled
1=ASP Inactive Notifications	0=Disabled , 1=Enabled
2=ASP AS State Query	0=Disabled , 1=Enabled
3-31=Reserved	

PARM 3: UA Serviceability Options. Each bit is used as an enabled/disabled flag for a particular UA serviceability option.

PVALUE : Valid range = 32-bits

BIT	BIT VALUE
0=UA Heartbeats	0=Disabled , 1=Enabled
1-31=Reserved	

4. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first..


BACKUP (FIXED) : MASP A - Backup starts on active MASP.

BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.

BACKUP (FIXED) : MASP A - Backup starts on standby MASP.

BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-36. Changing a UA Parameter Set



Turning the Large BICC MSU Support for IP Signaling Feature Off

This procedure is used to turn off the Large BICC (Bearer Independent Call Control) MSU Support for IP Signaling feature, using the **chg-ctrl-feat** command.

The **chg-ctrl-feat** command uses these parameters:

:partnum – The part number of the Large BICC MSU Support for IP Signaling feature, 893018401.

:status=off – used to turn off the Large BICC MSU Support for IP Signaling feature.

The status of the Large BICC MSU Support for IP Signaling controlled feature must be on and is shown with the **rtrv-ctrl-feat** command.



CAUTION: If the Large BICC MSU Support for IP Signaling feature is turned off, the EAGLE 5 ISS will not process BICC messages with a signaling information field (SIF) that is larger than 272 bytes.

Procedure

1. Display the status of the Large BICC MSU Support for IP Signaling feature by entering the **rtrv-ctrl-feat:partnum=893018401** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large BICC MSU for IP Sig	893018401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the status of the Large BICC MSU Support for IP Signaling feature is off, or if the Large BICC MSU Support for IP Signaling feature is not enabled, this procedure cannot be performed.

2. Turn off the Large BICC MSU Support for IP Signaling feature by entering the **chg-ctrl-feat** command with the **status=off** parameter. For example, enter this command.

chg-ctrl-feat:partnum=893018401:status=off

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

3. Verify that the Large BICC MSU Support for IP Signaling feature has been turned off by using the **rtrv-ctrl-feat:partnum=893018401** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large BICC MSU for IP Sig	893018401	off	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				


The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
 BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
 BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 6-37. Turning the Large BICC MSU Support for IP Signaling Feature Off



ISUP Variant Table Provisioning

Overview	7-1
Adding New ISUP PSTN Presentation Values	7-4
Changing ISUP Presentation Values	7-7
Removing ISUP Presentation Values	7-9
Changing ISUP Variant Table Entries	7-12
Copying ISUP Variant Table Entries	7-19

Overview

ISUP Normalization is Tekelec's process of converting/translating different customized versions of the ISUP protocol into one standard protocol (Normalized ISUP) for transmission to an IP device. This process also includes the reverse scenario, receiving Normalized ISUP messages from an IP device and denormalizing the message into customized versions.

The EAGLE 5 ISS supports end-user ISUP Normalization Administration. It is now possible to use the EAGLE 5 ISS's commands to achieve the following:

- Define and display new PSTN Presentation values for user-defined variants
- Provision a variant database starting from scratch
- Provision a variant database by copying another variants database
- Define the ISUP message types for a variant
- Define the ISUP parameters for a variant and the minimum length that is valid for each parameter
- Define the optional ISUP parameters supported for each ISUP message type
- Define the mandatory-fixed and mandatory-variable parameters that are supported for each ISUP message type and the order they appear in the message
- Assign a "conversion action" to ISUP messages and message/parameter combinations within a specific variant that require special software treatment
- Display the variant database

Prior implementations of the ISUP Normalization feature kept the ISUP data in hard-coded software tables. Changing ISUP parameters could only be achieved by means of a software revision. The disk-resident ISUP variant table eliminates this problem and increases flexibility and maintainability. This table include an entry in the

variant's ISUP database table for each variant. When the **ent-pstn-pres** command is used to define a PSTN value, the first available entry in the ISUP variant database table is automatically allocated. The table entry is initialized to default values.

The ETSI V3 variant database is treated differently from other variants. It is automatically configured by the EAGLE 5 ISS during an upgrade or new installation. You will not have to enter the **ent-pstn-pres** command to define it. You cannot modify or delete the table entry for this variant, except to change the descriptive text.

The ISUP variant table supports a maximum of 21 entries, one of which is always the ETSI V3 variant. This allows for 20 entries for Tekelec-defined or user-defined ISUP variants.

The normalization process occurs in the following steps:

1. The EAGLE 5 ISS receives a variant ISUP message from a PSTN.
2. The routing key variant database tables are accessed and provide the following information:
 - Indicates the message is to be routed to an IP device
 - Contains the PSTN Presentation value identifying the variant
 - Contains a “normalization flag” indicating the message is to be normalized
3. The software accesses database tables for the variant. The software performs some minor syntax validation on the received message and then constructs a normalized ISUP message.
4. The normalized message is sent in a TALI packet across an IPGWI connection to a far-end IP device.

The normalization function is performed entirely on the IPGWI card in the EAGLE 5 ISS. Everything presented to the MGCs that are using this feature is in normalized ISUP format. Everything that is presented to the MTP3 portion of the IPGWI card (to be routed back to a DS0 link towards the PSTN) is in the format for a specific ISUP variant. Each DS0 LIM (or any LIM in the EAGLE 5 ISS other than the IPGWI) receives MSUs from the PSTN wire and from the IMT in the same ISUP variant format. The DS0 LIMS do not know how to perform ISUP Normalization, and do not even know that it is occurring on the IPGWI cards.

Table 7-1. ISUP Variants Supported by this Feature

ISUP Variant	Part No.	PSTN Category	PSTN ID
ISUP Normalization	893000201	1	*
ITU Q.767 Normalization	893000501	1	1
ESTI V3 Normalization	893000601	1	2
UK PNO-ISC7 Normalization	893000401	1	3
German ISUP Normalization	893000301	1	4
French ISUP Normalization	893-0007-01	1	5
Sweden ISUP Normalization	893-0008-01	1	6
Belgium ISUP Normalization	893-0009-01	1	7
Netherlands ISUP Normalization	893-0010-01	1	8
Switzerland ISUP Normalization	893-0011-01	1	9
Austria ISUP Normalization	893-0012-01	1	10

ISUP Variant	Part No.	PSTN Category	PSTN ID
Italy ISUP Normalization	893-0013-01	1	11
Ireland ISUP Normalization	893-0014-01	1	12
India ISUP Normalization	893-0015-01	1	13
Malaysia ISUP Normalization	893-0016-01	1	14
Vietnam ISUP Normalization	893-0017-01	1	15
South Africa ISUP Normalization	893-0018-01	1	16
Argentina ISUP Normalization	893-0019-01	1	17
Chile ISUP Normalization	893-0020-01	1	18
Venezuela ISUP Normalization	893-0021-01	1	19
Mexico ISUP Normalization	893-0022-01	1	20
Brazil ISUP Normalization	893-0023-01	1	21
Spain ISUP Normalization	893-0024-01	1	22
Colombia ISUP Normalization	893-0025-01	1	23
Peru ISUP Normalization	893-0026-01	1	24
Hong Kong ISUP Normalization	893-0027-01	1	25
China ISUP Normalization	893-0028-01	1	26
Japan ISUP Normalization	893-0029-01	1	27
Korea ISUP Normalization	893-0030-01	1	28
Taiwan ISUP Normalization	893-0031-01	1	29
Philippines ISUP Normalization	893-0032-01	1	30
Singapore ISUP Normalization	893-0033-01	1	31
Australia ISUP Normalization	893-0034-01	1	32
Reserved for future definition by Tekelec		2 through 4095	
Available for user-defined categories		4095 through 65535	

The Quantity Control feature allows a customer to provision a specified quantity of user-defined variants within the PSTN categories 4096 - 65535. Each Quantity Control Feature is associated with a specific quantity of variants. To provision user-defined variants, it is necessary to purchase the appropriate Feature Access Keys from Tekelec. Variants enabled using the Quantity Control feature do not have associated PSTN Presentation values.

The part number for user-defined variants is 893-0100-nn, where nn is a number ranging from 01 to 20. Use part number 893-0100-01 to order one new variant, 893-0100-05 to order five new variants, and so on.

Adding New ISUP PSTN Presentation Values

This procedure is used to add a new ISUP presentation value to the ISUP variant table, using the **ent-pstn-pres** command.

The PSTN Presentation value, consisting of a PSTN Category and PSTN ID, is used by the EAGLE 5 ISS to uniquely define an ISUP variant. The assignment of a new PSTN value also creates a new entry in the ISUP variant table. The new PSTN value must be unique.

This procedure may be used to define values within the Tekelec-defined range (PSTN Category 0-4095) as long as these control features are enabled:

- the controlled feature for the new PSTN category
- ISUP Normalization control feature

This command may be used to define values within the user-defined range (PSTN Category 4096-65535) as long as these control features are enabled:

- the controlled feature for the new PSTN category
- ISUP Normalization control feature
- ISUP Normalization Quantity control feature, to make sure that the quantity of user-defined PSTN categories is not exceeded.

The **ent-pstn-pres** command uses these parameters:

:pstncat - The PSTN Category identifying the new variant being defined is mandatory. Valid values for this parameter range from 0 to 65535.

:pstnid - The PSTN ID identifying the new variant being defined is mandatory. Valid values for this parameter range from 0 to 65535.

:pstndesc - The PSTN Description, a text description of the PSTN Presentation value, is optional. It should be used to describe the variant associated with the PSTN. This field is displayed by the **rtrv-pstn-pres** command and it has no other purpose. This alphanumeric string 0-31 characters in length is delimited with quotation marks.

Valid **pstncat** and **pstnid** parameter values are listed in [Table 7-1](#).

Procedure

1. Display the current value of the ISUP PSTNs using the **rtrv-pstn-pres** command. This is an example of possible output:

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
00001* 00020 Mexico
04096 01000 User Defined 4096/1000

ISUP Variant table is (6 of 21) 29% full
```

NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

2. Display enabled controlled feature information in the database by entering the **rtrv-ctrl-feat** command. The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ISUP Normalization control feature, the controlled feature for the new PSTN category, and if a user-defined PSTN category is being changed, or the ISUP Normalization Quantity control feature have not been enabled and turned on, go to the [Enabling Controlled Features](#) procedure and to [Turning On and Off Controlled Features](#) procedure to enable and turn on these controlled features.

3. Enter the desired new ISUP PSTN using the **ent-pstn-pres** command.

For this example, enter this command.

```
ent-pstn-pres:pstncat=5000:pstnid=1 :pstndesc="Mexican ISUP v1.8"
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
ENT-PSTN-PRES: MASP A - COMPLTD
```

4. Verify that the new ISUP PSTN has been added to the database using the **rtrv-pstn-pres** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
00001* 00020 Mexico
04096 01000 User Defined 4096/1000
05000 00001 Mexican ISUP v1.8
```


ISUP Variant table is (7 of 21) 33% full


NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

5. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 7-1. Adding ISUP PSTN Presentation Value



Changing ISUP Presentation Values

This procedure is used to change the description for a previously defined PSTN presentation value in the ISUP Variant Table, using the **chg-pstn-pres** command. The description of the PSTN presentation value is shown in the **PSTNDESC** column in the **rtrv-pstn-pres** output.

The **chg-pstn-pres** command uses these parameters:

:pstncat - The PSTN Category identifying the variant being changed is mandatory. Valid values for this parameter range from 0 to 65535.

:pstnid - The PSTN ID identifying the variant being changed is mandatory. Valid values for this parameter range from 0 to 65535.

:pstndesc - The PSTN Description, a text description of the PSTN Presentation value, is mandatory. It should be used to describe the variant associated with the PSTN. This field is displayed by the **rtrv-pstn-pres** command and it has no other purpose. This alphanumeric string 0 -31 characters in length is delimited with quotation marks.

Procedure

1. Display the current value of the ISUP PSTNs using the **rtrv-pstn-pres** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
00001* 00020 Mexico
04096 01000 User Defined 4096/1000
05000 00001 Mexican ISUP v1.8
```

ISUP Variant table is (7 of 21) 33% full

NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

2. Change the PSTN descriptive text using the **chg-pstn-pres** command.

For this example, enter this command.

chg-pstn-pres:pstncat=4096:pstnid=1000 :pstndesc="French ISUP v5.7"

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
CHG-PSTN-PRES: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-pstn-pres** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
00001* 00020 Mexico
04096 01000 French ISUP v5.7
05000 00001 Mexican ISUP v1.8
```

ISUP Variant table is (7 of 21) 33% full


NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

4. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
 BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
 BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 7-2. Changing ISUP PSTN Presentation Value



Removing ISUP Presentation Values

This procedure is used to remove a previously defined ISUP presentation value from the ISUP variant table, using the **dlt-pstn-pres** command.

The PSTN Presentation value, consisting of a PSTN Category and PSTN ID, is used by the EAGLE 5 ISS to uniquely define an ISUP variant.

This command will also cause all the ISUP parameters provisioned for the variant with the **chg-isupvar-attrib** command to be deleted.

NOTE 1: Deleting the PSTN Presentation value may cause a loss of traffic if any routing keys are using that PSTN value. Use caution when performing this action. To display the routing keys that are using the PSTN value being removed from the database, enter the **rtrv-appl-rkey** command with the **pstncat** and **pstnid** parameters.

NOTE: You cannot delete the PSTN Present value with Category=1, ID=2 (the ETSI V3 ISUP variant).

The **dlt-pstn-pres** command uses these parameters:

:pstncat - The PSTN Category identifying the variant being deleted is mandatory. Valid values for this parameter range from 0 to 65535.

:pstnid - The PSTN ID identifying the variant being deleted is mandatory. Valid values for this parameter range from 0 to 65535.

:force - You will need to set **force=yes** when deleting the PSTN presentation value.

Procedure

1. Display the current value of the ISUP PSTNs using the **rtrv-pstn-pres** command.

This is an example of possible output:

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
00001* 00020 Mexico
04096 01000 French ISUP v5.7
05000 00001 Mexican ISUP v1.8
```

ISUP Variant table is (7 of 21) 33% full

NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

2. Display any routing keys that are using the PSTN value being removed from the database using the **rtrv-appl-rtkey** command with the **pstncat** and **pstnid** parameter values associated with the PSTN value being removed from the database, and the **display=all** parameter.

For this example, enter this command.

rtrv-appl-rtkey:pstncat=04096:pstnid=01000:display=all

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
KEY:LOC   DPC      SI SSN OPCA      CICS      CICE
        STATIC 12323-DE 5 --- 12212-DE 1          1000
        ATTR:PSTNCAT PSTNID NORM DUP
              4096 1000 Y -
        SNAMES:socket6
```

```
STATIC Route Key table is (2 of 2000) 1% full
1105 Route Key table is (2 of 500) 1% full
1107 Route Key table is (2 of 500) 1% full
```

```
STATIC Route Key Socket Association table is (2 of 32000) 1% full
1105 Route Key Socket Association table is (2 of 8000) 1% full
1107 Route Key Socket Association table is (2 of 8000) 1% full
```

If there is a routing key using the PSTN information being removed from the database, go to the [Changing the PSTN Presentation and Normalization Attributes in a Routing Key](#) procedure and change the routing keys so that they do not reference the PSTN value.

3. Remove the ISUP PSTN value from the database using the **dlt-pstn-pres** command with the **pstncat**, **pstnid**, and **force=yes** parameters.

For this example, enter this command.

dlt-pstn-pres:pstncat=04096:pstnid=01000:force=yes

NOTE: The ISUP variant ETSI V3 (PSTNCAT=1, PSTNID=2) cannot be removed from the database.

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
DLT-PSTN-PRES: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-pstn-pres** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID PSTNDESC
00001 00001 ITU Q.767
00001 00002 ETSI V3
00001 00003 UK PNO-ISC7
00001 00004 GERMAN ISUP
00001* 00020 Mexico
05000 00001 Mexican ISUP v1.8
```


ISUP Variant table is (7 of 21) 33% full

NOTE: An * will be displayed next to the PSTN Category for entries that are no longer usable. These are entries that are disabled because their temporary feature key expired.

5. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 7-3. Removing ISUP PSTN Presentation Value

Changing ISUP Variant Table Entries

This procedure is used to add a new ISUP presentation value to the ISUP variant table, using the **chg-isupvar-attrib** command.

An ISUP variant table entry exists for each variant defined in the EAGLE 5 ISS. Each entry contains ISUP message and parameter data specific to the ISUP protocol used by that variant. A variant is uniquely defined by its PSTN Presentation value, consisting of a PSTN Category and PSTN ID.

The **pstncat** and **pstnid** parameters identify the ISUP variant table entry to be changed. Use the **rtv-pstn-pres** command to display the only allowed values for the PSTN Category and ID. This procedure may be used to change any Tekelec-defined or user-defined variants that are displayed by **rtv-pstn-pres**.

You can make the following changes to ISUP variant table entries.

- All the ISUP messages and parameters for the variant can be provisioned as defined or not defined. All the ISUP messages and parameters default to not defined until set to defined by this command.
- All the ISUP parameters for specific messages in the variant can be provisioned as supported or not supported. All the ISUP parameters default to not supported until set to supported by this command.
- The minimum valid parameter length can be specified for each defined ISUP parameter.
- All the ISUP messages that are provisioned as defined can also have a message conversion action assigned.
- All the ISUP parameters that are provisioned as supported can also have a parameter conversion action assigned.
- All the ISUP parameters that are provisioned as supported, can also be assigned as optional, mandatory-fixed (MF), or mandatory-variable (MV).
- If assigned as MF or MV, the numerical order the parameter appears in the message must be specified.

NOTE: You cannot change the attributes for the ETSI V3 ISUP variant (PSTN Category=1, PSTN ID=2).

The PSTN presentation value, consisting of a PSTN category and PSTN ID, is used by the EAGLE 5 ISS to uniquely define an ISUP variant. The assignment of a new PSTN value also creates a new entry in the ISUP variant table. The new PSTN value must be unique.

This procedure may be used to change values within the Tekelec-defined range (PSTN Category 0-4095) as long as these control features are enabled:

- the controlled feature for the new PSTN category
- ISUP Normalization control feature

This procedure may be used to change values within the user-defined range (PSTN Category 4096-65535) as long as these control features are enabled:

- the controlled feature for the new PSTN category
- ISUP Normalization control feature
- ISUP Normalization Quantity control feature, to make sure that the quantity of user-defined PSTN categories is not exceeded.

The **chg-isupvar-attrib** command uses these parameters:

:pstncat - The PSTN category identifying the new variant being defined. Valid values for this parameter range from 0 to 65535.

:pstnid - The PSTN ID identifying the new variant being defined. Valid values for this parameter range from 0 to 65535.

:msgcode - The ISUP message type code. This parameter is used to identify a specific ISUP message that is going to have its attributes changed. Valid values are 0-255 (h'00 - h'FF).

:parmcode - The ISUP parameter code. This parameter is used to identify a specific ISUP parameter that is going to have its attributes changed. When specified with the **msgcode** parameter, the **parmcode** parameter identifies a parameter within the **msgcode** parameter that is going to have its attributes changed. Valid values are 0-255 (h'00 - h'FF).

:attrib - The attribute being assigned to a message or parameter. This parameter can have values of **defined**, **notdefined**, **supp**, or **notsupp**.

- **defined** – the message or parameter is defined in the variant.
- **notdefined** – the message or parameter is not defined in the variant.
- **supp** – the parameter is supported in the specified message in the variant.
- **notsupp** – the parameter is not supported in the specified message in the variant.

:minlen - The minimum parameter length. This parameter has valid values of 0-255 (h'00 - h'FF). It is used for validating that the length of the received parameter is at least as long as the **minlen** parameter value.

:parmtyp - The type of ISUP parameter, and has valid values of **opt**, **mf**, or **mv**.

- **opt** – The parameter may appear in the Optional part of the ISUP message. This is the default and it does not have to be specified unless the parameter needs to be changed from either **mf** or **mv** to optional.
- **mf** – The parameter must appear in the Mandatory Fixed part of the ISUP message.
- **mv** – The parameter must appear in the Mandatory Variable part of the ISUP message.

:order - The order in which the mandatory parameters appear in the message. Valid values are from 1 to 7.

:action - The message or parameter conversion action the software will follow when a message is received with the specified **msgcode** parameter value or the **msgcode/parmcode** parameter combination. Valid values are **none**, **convert**, and **passthru**.

- **none** – The software will follow its normal conversion rules. No special conversions will occur. This is the default.
- **convert** – The software will invoke a special conversion routine that is available in the EAGLE 5 ISS for the specified **msgcode** parameter value or **msgcode/parmcode** parameter combination.
- **passthru**, for the **msgcode** parameter, – The specified message code should be passed through unconverted using the raw MTP3 transfer method.
- **passthru**, for the **msgcode/parmcode** parameter combination, – The parameter code, when encountered in message code, should be passed through to the normalized section of the message (ignoring the **defined** or **supp** attributes of the normalized specification).

:force – Used to allow the ISUP Message Type Code to be changed to **notdefined**. This parameter has values of **yes** and **no**.

[Table 7-2](#) shows the parameter combinations that can be used with the **chg-isupvar-attrib** command.

Table 7-2. CHG-ISUPVAR-ATTRIB Parameter Combinations

Parameter Combination 1	Parameter Combination 2	Parameter Combination 3	Parameter Combination 4	Parameter Combination 5
pstncat = 0-65535 ¹	pstncat = 0-65535 ¹	pstncat = 0-65535 ¹	pstncat = 0-65535 ¹	pstncat = 0-65535 ¹
pstnid = 0-65535 ¹	pstnid = 0-65535 ¹	pstnid = 0-65535 ¹	pstnid = 0-65535 ¹	pstnid = 0-65535 ¹
msgcode = 0-255	msgcode = 0-255	parmcode = 0-255	parmcode = 0-255	msgcode = 0-255
attrib = defined	attrib = notdefined	attrib = defined	attrib = notdefined	parmcode = 0-255
action = none, convert, passthru ^{6, 7}	force ³	minlen = 0-255 ²		attrib = supp
				action = none, convert, passthru ^{6, 7}

Parameter Combination 6	Parameter Combination 7	Parameter Combination 8	Parameter Combination 9	
pstncat = 0-65535 ¹ pstnid = 0-65535 ¹ msgcode = 0-255 parmcode = 0-255 attrib = supp parmtyp = opt ⁴ action = none, convert, passthru ^{6, 7}	pstncat = 0-65535 ¹ pstnid = 0-65535 ¹ msgcode = 0-255 parmcode = 0-255 attrib = supp parmtyp = mf ⁵ order = 1-7 action = none, convert, passthru ^{6, 7}	pstncat = 0-65535 ¹ pstnid = 0-65535 ¹ msgcode = 0-255 parmcode = 0-255 attrib = supp parmtyp = mv ⁵ order = 1-7 action = none, convert, passthru ^{6, 7}	pstncat = 0-65535 ¹ pstnid = 0-65535 ¹ msgcode = 0-255 parmcode = 0-255 attrib = notsupp	
Notes: 1. The parameter combination pstncat=1 and pstnid=2 cannot be specified with the chg-isupvar-attrib command. 2. The minlen=0 parameter is valid only for the parmcode=0 (EOP) parameter. Otherwise, the values for this parameter are from 1 to 255. 3. Changing an ISUP Message Type Code to notdefined will clear all the associated parameter data. In this case, the force=yes parameter is required. Changing an ISUP Message Type Code to notdefined is destructive and will clear all the associated parameter data for that ISUP Message Type Code. 4. The opt value is the default value for the parmtyp parameter and it does not have to be specified unless the parameter value needs to be changed from mf or mv to opt . 5. The parmtyp parameter may be changed as long as the change does not violate the rules of the order parameter. The mf parameters must be specified in an ordered list starting with 1. The mv parameters must be specified in a different ordered list starting with 1. There can be no gaps in order number. An mf or mv parameter cannot be removed from a list (that is, changing parmtyp parameter value, or changing the attrib parameter value to notsupp) unless all parameters with a higher order number are deleted first. 6. The none value is the only valid value for the action parameter when the parmcode=0 parameter is specified. 7. The action parameter can be specified for user-defined variants, however the EAGLE 5 ISS will ignore the convert value. There will be no supported conversion action.				

Procedure

1. Display the current value of the ISUP supported parameters for all the variants using the **rtrv-isupvar-attrib** command. This is an example of possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
PSTNCAT PSTNID
00001 00001

MSGCODE  PARMCODE  TYPE  ORDER  ACTION
01h      ---      ---   -      NONE
          45h      MF     1      NONE
          00h      OPT    -      NONE
          40h      OPT    -      NONE

MSGCODE  PARMCODE  TYPE  ORDER  ACTION
0Ah      ---      ---   -      CONVERT
          45h      MF     1      NONE
          4Ch      MV     1      NONE
          00h      OPT    -      NONE
          56h      OPT    -      PASSTHRU

MSGCODE  PARMCODE  TYPE  ORDER  ACTION
0Bh      ---      ---   -      NONE

```

```

          45h      MF      1      NONE
          71h      MF      2      NONE
          00h      OPT     -      NONE
          72h      OPT     -      CONVERT

PSTNCAT  PSTNID
00001    00002

MSGCODE  PARMCODE  TYPE  ORDER  ACTION
01h      ---      ---   -      NONE
          45h      MF      1      NONE
          00h      OPT     -      NONE
          40h      OPT     -      NONE
MSGCODE  PARMCODE  TYPE  ORDER  ACTION
0Ah      ---      ---   -      NONE
          45h      MF      1      NONE
          4Ch      MV      1      NONE
          00h      OPT     -      NONE
          10h      OPT     -      NONE
          56h      OPT     -      NONE

PSTNCAT  PSTNID
04097    00001

MSGCODE  PARMCODE  TYPE  ORDER  ACTION
01h      ---      ---   -      NONE
          45h      MF      1      NONE
          00h      OPT     -      NONE
          40h      OPT     -      PASSTHRU

MSGCODE  PARMCODE  TYPE  ORDER  ACTION
0Ah      ---      ---   -      CONVERT
          45h      MF      1      NONE
          4Ch      MV      1      NONE
          00h      OPT     -      NONE
          56h      OPT     -      CONVERT
ISUP Variant table is (5 of 20) 25% full

```

2. Display enabled controlled feature information in the database by entering the **rtrv-ctrl-feat** command. The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:

```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ISUP Normalization control feature, the controlled feature for the new PSTN category, and if a user-defined PSTN category is being changed, or the ISUP Normalization Quantity control feature have not been enabled and turned on, go to the [Enabling Controlled Features](#) procedure and to [Turning On and Off Controlled Features](#) procedure to enable and turn on these controlled features.

3. Enter the desired new values of the ISUP supported parameters using the **chg-isupvar-attrib** command and using one of the parameter combinations shown in [Table 7-2](#). For this example, enter this command.

chg-isupvar-

attrib:pstncat=4097:pstnid=1:msgcode=10 :parmcode=100:attrib=supp:parmtyp=mv:order=1:action=passthru

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
CHG-ISUPVAR-ATTRIB: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-isupvar-attrib** command with the **pstncat** and **pstnid** values used in step 3. For this example, enter this command.

rtrv-isupvar-attrib:pstncat=4097:pstnid=1

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
PSTNCAT PSTNID
04097 00001
```


MSGCODE	PARMCODE	TYPE	ORDER	ACTION
01h	---	---	-	NONE
	45h	MF	1	NONE
	00h	OPT	-	NONE
	40h	OPT	-	PASSTHRU


MSGCODE	PARMCODE	TYPE	ORDER	ACTION
0Ah	---	---	-	CONVERT
	45h	MF	1	NONE
	4Ch	MV	1	NONE
	00h	OPT	-	NONE
	56h	OPT	-	CONVERT
	64h	MV	1	PASSTHRU

ISUP Variant table is (5 of 20) 25% full

5. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.. These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 7-4. Changing ISUP Attribute Values



Copying ISUP Variant Table Entries

The **copy-isupvar-attrb** command is used to copy one ISUP variant table entry to another ISUP variant table entry.

This command provides you with an easy way to provision a new ISUP variant table entry by copying all the data from another entry. You can then change the entry with the **chg-isupvar-attrb** command.

An ISUP variant table entry exists for each variant defined in the EAGLE 5 ISS. Each entry contains ISUP message and parameter data specific to the ISUP protocol used by that variant. A variant is uniquely defined by its PSTN presentation value, consisting of a PSTN category and PSTN ID.

The PSTN presentation is used to identify both the source and destination table entries. Both entries must be previously defined PSTN presentation values, that is, either a Tekelec-defined PSTN or a user-defined PSTN entered into the database by the **ent-pstn-pres** commands. Use the **rtrv-pstn-pres** command to display the only allowed values for the source and destination PSTNs.

Tekelec-defined PSTNs (PSTN Category 0-4095) require that these control features are enabled:

- The controlled feature for the PSTN category
- ISUP Normalization control feature

User-defined PSTNs (PSTN Category 4096-65535) require that these control features are enabled:

- The controlled feature for the PSTN category
- ISUP Normalization control feature
- ISUP Normalization Quantity control feature, to make sure that the quantity of user-defined PSTN categories is not exceeded.

NOTE: The destination PSTN cannot be the ETSI V3 ISUP variant (PSTNCAT=1, PSTNID=2).

The **copy-isupvar-attrib** command uses these parameters:

:pstncat – The source variant table entry being copied. Valid values for this parameter range from 0 to 65535.

:pstnid – The source variant table entry being copied. Valid values for this parameter range from 0 to 65535.

:dpstncat – The destination variant table entry where the source variant table is being copied. Valid values for this parameter range from 0 to 65535.

:dpstnid – The destination variant table entry where the source variant table is being copied. Valid values for this parameter range from 0 to 65535.

Procedure

1. Display the current value of the ISUP supported parameters for all the variants using the **rtrv-isupvar-attrib** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
PSTNCAT PSTNID
00001 00001
```

MSGCODE	PARMCODE	TYPE	ORDER	ACTION
01h	---	---	-	NONE
	45h	MF	1	NONE
	00h	OPT	-	NONE
	40h	OPT	-	NONE
MSGCODE	PARMCODE	TYPE	ORDER	ACTION
0Ah	---	---	-	CONVERT
	45h	MF	1	NONE
	4Ch	MV	1	NONE
	00h	-	-	NONE
	56h	-	-	PASSTHRU
MSGCODE	PARMCODE	TYPE	ORDER	ACTION
0Bh	---	---	-	NONE

	45h	MF	1	NONE
	71h	MF	2	NONE
	00h	OPT	-	NONE
	72h	OPT	-	CONVERT

PSTNCAT PSTNID
00001 00002

MSGCODE	PARMCODE	TYPE	ORDER	ACTION
01h	---	---	-	NONE
	45h	MF	1	NONE
	00h	OPT	-	NONE
	40h	OPT	-	NONE

MSGCODE	PARMCODE	TYPE	ORDER	ACTION
0Ah	---	---	-	NONE
	45h	MF	1	NONE
	4Ch	MV	1	NONE
	00h	OPT	-	NONE
	10h	OPT	-	NONE
	56h	OPT	-	NONE

PSTNCAT PSTNID
04097 00001

MSGCODE	PARMCODE	TYPE	ORDER	ACTION
01h	---	---	-	NONE
	45h	MF	1	NONE
	00h	OPT	-	NONE
	40h	OPT	-	PASSTHRU

MSGCODE	PARMCODE	TYPE	ORDER	ACTION
0Ah	---	---	-	CONVERT
	45h	MF	1	NONE
	4Ch	MV	1	NONE
	00h	OPT	-	NONE
	56h	OPT	-	CONVERT

ISUP Variant table is (5 of 20) 25% full

2. Display enabled controlled feature information in the database by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the ISUP Normalization control feature, the controlled feature for the new PSTN category, and if a user-defined PSTN category is being changed, or the ISUP Normalization Quantity control feature have not been enabled and turned on, go to the [Enabling Controlled Features](#) procedure and to [Turning On and Off Controlled Features](#) procedure to enable and turn on these controlled features.

3. Copy an ISUP PSTN value using the **copy-isupvar-attrib** command.

For this example, enter this command.

copy-isupvar-attrib:pstncat=1:pstnid=2:dpstncat=1:dpstnid=20

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
COPY-ISUPVAR-ATTRIB: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-isupvar-attrib** command with the **pstncat** and **pstnid** parameters.

Use the **dpstncat** and **dpstnid** parameter values used in step 3 for the values of the **pstncat** and **pstnid** parameters.

For this example, enter this command.

rtrv-isupvar-attrib:pstncat=1:pstnid=20

This is an example of the possible output.


```
PSTNCAT  PSTNID
00001    00020


MSGCODE  PARMCODE  TYPE  ORDER  ACTION
01h      ---      ---  -      NONE
          45h      MF    1      NONE
          00h      OPT   -      NONE
          40h      OPT   -      NONE
MSGCODE  PARMCODE  TYPE  ORDER  ACTION
0Ah      ---      ---  -      NONE
          45h      MF    1      NONE
          4Ch      MV    1      NONE
          00h      OPT   -      NONE
          10h      OPT   -      NONE
          56h      OPT   -      NONE
```

5. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 7-5. Copying ISUP Attribute Values



End Office Support

Overview	8-1
Internal Point Code	8-2
New Installation of VXI Behind a EAGLE 5 ISS with End Office Support	8-4
One Node Migrates from PSTN to IP	8-4
A Signaling End Point is Added to a Deployed EAGLE 5 ISS Using End Office	8-5
Two Signaling End Points Move from PSTN to IP Using End Office	8-6
The EAGLE 5 ISS Simultaneously Acts as STP and End Office	8-7
The EAGLE 5 ISS Supports Multiple Network Types and Multiple Hosts as an End Node	8-8
Mated Pair Supports Two End Office Nodes	8-9
End Office Support Configuration	8-10
Adding an End Node Internal Point Code	8-11
Removing an End Node Internal Point Code	8-15

Overview

End Office Support enables the EAGLE 5 ISS to share its true point code (TPC) with an IP-based node without the need for a separate point code for the IP node. When the End Office Support feature is in use, the EAGLE 5 ISS shares a point code for up to three network types with attached IP network elements.

The EAGLE 5 ISS lets you take advantage of next generation network technology by migrating existing signaling end points from the PSTN to the IP network. The fact that the EAGLE 5 ISS is a signaling transfer point and has its own point code, however, can present a significant network management issue. This feature provides the means to perform the migration without obtaining a new point code or reconfiguring the network to interface with both the EAGLE 5 ISS and an IP end office node.

Characteristics of this feature include:

- The EAGLE 5 ISS allows a set of IP network elements to share its true point code.
- The EAGLE 5 ISS allows messages destined to its true point code and having SI $\geq$ 3 to be forwarded to an IP network element.
- The EAGLE 5 ISS enables IP networks elements sharing its true point code to participate in network management.
- The EAGLE 5 ISS supports ANSI, ITU national and international end office nodes.

- The EAGLE 5 ISS implements the MTP procedures required for an end office node.
- The End Office Support feature does not reduce the rated TPS of any EAGLE 5 ISS application.

The Remote Application Table contains fields for assigning each user part to an end office node. The default value is 'not assigned'.

New Remote Application Table commands provide for adding, deleting, and retrieving user-part assignments:

- **ent-rmt-appl**
- **dlt-rmt-appl**
- **rtrv-rmt-appl**

The user parts SI=0, SI=1, and SI=2 cannot be assigned to an end office node. The SNM case is a special case in that UPU's may be forwarded, even though SI=0 cannot be assigned to a remote application. All other SNMs are processed as destined to the EAGLE 5 ISS rather than the end office node. This often results in a multicast throughout the EAGLE 5 ISS that updates the routing tables on all cards. An end office node can receive these messages via replication performed by MTPP.

Each SS7-based application that receives a message destined to a TSPC checks the user-part assignment within the Remote Application Table. If the user-part is assigned and the SI is greater than or equal to 3, then the message is forwarded to the appropriate application, otherwise it is processed as though destined to the EAGLE 5 ISS.

To assign a remote application for the SCCP (SI=3) user part, you must also specify a subsystem number. The Remote Application Table maintains a record of assignments for all possible subsystems (256). Subsystems are either assigned or not assigned.

NOTE: SSN=0 is normally an invalid value. This feature makes use of SSN=0 for the purpose of forwarding certain MSUs to the end office node.

- Received SCCP Messages that indicate route-on-global-title are treated as having SSN=0 for remote application assignment. If a remote application is assigned to SSN=0, then the message is forwarded, otherwise it is distributed to the local SCCP application. In previous releases, this would occur only for mis-configured networks. Messages indicating route-on-global-title and intended for the EAGLE 5 ISS, not the end office node, should be sent to the EAGLE 5 ISS's capability point code.
- Received SCCP Messages that lack a Called Party SS are treated as having SSN=0 for remote application assignment. If a remote application is assigned to SSN=0, then the message is forwarded, otherwise it is distributed to the local SCCP application.
- Received SCCP Messages having a Called Party SS equal to SCMG (SSN=1) are processed and terminated by the EAGLE 5 ISS, and if SSN=1 has a remote application assigned, the MSU is also replicated and forwarded to the end office node.
- Received SCCP Messages having a Called Party SSN not equal to 0 or SCMG (1) and for which a remote application is assigned are forwarded to the end office node. Messages received for unassigned subsystems are distributed to the local SCCP application.
- The end office node cannot share SCCP subsystems (other than SCMG) with the EAGLE 5 ISS. If the end office node assigns a given subsystem, such as LNP, then the subsystem local to the EAGLE 5 ISS cannot receive messages. Remote applications take priority over local applications.

Internal Point Code

To route SS7 messages to the IP address without adding another external point code, the End Office feature uses an internal point code (IPC). This point code is private to the EAGLE 5 ISS, and the PSTN has no awareness of it. Its sole purpose is to allow messages destined to the End Office Node to be routed from the inbound LIM to

the IPGWx card (a card running either the SS7IPGW or IPGWI applications). An IPC must be entered as a destination and must be assigned for each network type having an end office node. This point code is also used internally by the EAGLE 5 ISS in order to route inbound messages to the outbound IPGWx card. The EAGLE 5 ISS can have up to three IPCs, one for ANSI, one for ITU International, and one for ITU National networks.

[Table 8-1](#) displays a sample Remote Application Table. The Network Type and SI are used to index into the table, rather than being stored in the table.

Table 8-1. Sample IPC Values


IPC	Assigned to End Office Node	Assigned SSNs	Network Type	User-Part (SI)	Action taken when MSU is received for the TPC
p-0-1-0	FALSE	n/a	ANSI	0	No application can be assigned for SI=0. Note that TFCs are processed, replicated and sent to an end office node, if an application is assigned to any other user part. UPUs are forwarded if the application specified by the affected SI is assigned.
	FALSE	n/a		1	No application can be assigned for SI=1.
	FALSE	n/a		2	No application can be assigned for SI=2.
	TRUE	3, 7, 100		3	SCCP messages destined to the TSPC and with SSN assigned are forwarded to an end office node. SCCP messages destined to a TSPC and SSN not assigned are distributed to subsystems local to the EAGLE 5 ISS (e.g. LNP).
	FALSE	n/a		4	Terminate with UPU.
	TRUE	n/a		5	ISUP messages destined to a TSPC are forwarded to the end office node.
	FALSE	n/a		6 - 15	Terminate with UPU.
110	FALSE	n/a	ITU-N	0	No application can be assigned for SI=0. TFCs are processed, replicated and sent to an end office node, if an application is assigned to any other user part. UPUs are forwarded if the application specified by the affected SI is assigned.
	FALSE	n/a		1	No application can be assigned for SI=1.
	FALSE	n/a		2	No application can be assigned for SI=2.
	FALSE	NULL		3	Distribute to local SCCP.
	TRUE	n/a		4	TUP messages destined to the TSPC are forwarded to the end office node.
	FALSE	n/a		5 - 12	Terminate with UPU.
	TRUE	n/a		13	QBICC messages destined to the TSPC are forwarded to the end office node.
	FALSE	n/a		14, 15	Terminate with UPU.

IPC	Assigned to End Office Node	Assigned SSNs	Network Type	User-Part (SI)	Action taken when MSU is received for the TPC
0-10-1	FALSE	n/a	ITU-I	0	No application can be assigned for SI=0. TFCs are processed, replicated and sent to an end office node, if an application is assigned to any other user part. UPUs are forwarded if the application specified by the affected SI is assigned.
	FALSE	n/a		1	No application can be assigned for SI=1.
	FALSE	n/a		2	No application can be assigned for SI=2.
	FALSE	NULL		3	Distribute to local SCCP.
	TRUE	n/a		4	TUP messages destined to the TSPC are forwarded to the end office node.
	FALSE	n/a		5 - 15	Terminate with UPU.

New Installation of VXI Behind a EAGLE 5 ISS with End Office Support



[Figure 8-1](#) depicts a network in which a VXI node is deployed behind a EAGLE 5 ISS with End Office Support. Note that the VXI node resides in the IP network and shares the EAGLE 5 ISS's true point code. The PSTN views the EAGLE 5 ISS and VXI as one network element (one point code).

Figure 8-1. An EAGLE 5 ISS with End Office Support and VXI Node



One Node Migrates from PSTN to IP



[Figure 8-2](#) and [Figure 8-3](#) depict the migration of a signaling end point from the PSTN to an IP network using the EAGLE 5 ISS with the End Office Support feature.

Figure 8-2. Network Before an EAGLE 5 ISS with End Office, Node P is to Migrate**Figure 8-3.** Network After an EAGLE 5 ISS with End Office, Node P has Migrated

In [Figure 8-3](#) the EAGLE 5 ISS no longer acts like a signaling transfer point, but rather acts like a signaling end point that has an IP-attached application user-part. The EAGLE 5 ISS and the IP network element share the point code P. All messages received by the EAGLE 5 ISS should be destined to P and all messages sent to the PSTN from the EAGLE 5 ISS have an OPC of P.

A Signaling End Point is Added to a Deployed EAGLE 5 ISS Using End Office



Another possible scenario for the End Office feature is that a customer has a deployed EAGLE 5 ISS with attached IP nodes, and wants to make use of the End Office feature to add a new IP node. Consider the following network diagrams, [Figure 8-4](#) and [Figure 8-5](#) .

Figure 8-4. Original Network with Deployed EAGLE 5 ISS**Figure 8-5.** New Network with an EAGLE 5 ISS Using End Office and End Node R

In [Figure 8-5](#) the customer saves a point code by using the End Office feature and making the new IP network element an end office node. No change is required in the PSTN or at P or Q. Non-network-management and non-test messages destined to R are now forwarded to an IP network element, rather than terminated by the EAGLE 5 ISS.

Two Signaling End Points Move from PSTN to IP Using End Office

A more complex scenario arises when multiple signaling end points are to migrate from the PSTN to an IP network using the End Office feature. Consider [Figure 8-6](#) and [Figure 8-7](#).


Figure 8-6. Network before Two Signaling End Points Migrate from PSTN to IP**Figure 8-7.** Network after Two Signaling End Points Migrate from PSTN to IP

In [Figure 8-7](#), P is an end office node, and so P serves as the adjacent point code for nodes X and Y. The following are key points about this figure:

- Q is not an end office node, and so the EAGLE 5 ISS behaves as an STP for messages originated by and destined to Q.
- Reprovisioning is required in the PSTN, since the Q is now behind P. One example of this is that the linksets between X and Q and between Y and Q must change.
- Traffic between P and Q are no longer routed through X/Y, but are routed within the EAGLE 5 ISS.

The EAGLE 5 ISS Simultaneously Acts as STP and End Office

[Figure 8-8](#) depicts the EAGLE 5 ISS supporting three IP network elements, only one of which use the End Office feature, and two PSTN network elements. In addition, a capability point code is provisioned on the EAGLE 5 ISS, thereby allowing the use of GTT.


Figure 8-8. The EAGLE 5 ISS Simultaneously Acts as STP and End Office

Notes regarding [Figure 8-8](#) :

- P is the end office node, and so the EAGLE 5 ISS TPC=P.
- Assume that end node P has an application assignment for SCCP.
- SCCP traffic destined to P is forwarded to the IP node via the SS7IPGW application.
- SCCP traffic destined to the CPC is distributed to the EAGLE 5 ISS's local SCCP application (e.g. GTT).
- Network elements Q, R, S, and T are not end office nodes, and so the EAGLE 5 ISS generates TFX network management concerning them.
- IP Network element P is an end office node, and so the EAGLE 5 ISS generates only UPU/SSP concerning it.

The EAGLE 5 ISS Supports Multiple Network Types and Multiple Hosts as an End Node

In [Figure 8-9](#) the EAGLE 5 ISS supports an end office node for each of the three network types. Each end office node comprises multiple IP network elements. The IP network elements are distinguished by the remote host and remote port values of the IP network elements (IP address parameters).

Figure 8-9. Three Multiple-Element End Office Nodes

Mated Pair Supports Two End Office Nodes

[Figure 8-10](#) depicts a mated pair of EAGLE 5 ISSs with each EAGLE 5 ISS supporting an End Office Node. Note that EAGLE 5 ISS P lacks IP links to IPNE-Q and EAGLE 5 ISS Q lacks IP links to IPNE-P, since such links would conflict with the C-links of linkset pq.


Figure 8-10. Mated Pair Supports Two End Office Nodes

Figure 8-10 shows that a mated pair of EAGLE 5 ISSs cannot share an End Office Node. Each EAGLE 5 ISS requires its own unique point code and so any attached End Office Nodes share those point codes. It would be possible for a single IP network element to act as both P and Q (have IP connections to both EAGLE 5 ISS P and EAGLE 5 ISS Q). This configuration, however, would not provide true redundancy. Messages destined to P are terminated either at EAGLE 5 ISS P or IPNE-P, and message destined to Q are terminated either at EAGLE 5 ISS Q or IPNE-Q. Should the IP link between EAGLE 5 ISS P and IPNE-P fail, this feature provides no way for EAGLE 5 ISS P to forward messages to the End Office Node using the linkset **pq** (the linkset between systems P and Q).

End Office Support Configuration

In addition to the internal point code provisioned in the database with the [Adding an End Node Internal Point Code](#) procedure, these entities must be configured in the database to support the End Office feature.

- The internal point code must be in the destination point code table - go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7*.
- An SS7 route to the internal point code - go to either the “Adding a Route containing an SS7 DPC” or “Adding a Route Containing an IPGWx Linkset” procedure in the *Database Administration Manual - SS7*.
- Signaling links assigned to the cards running either the SS7IPGW or IPGWI applications:
 - [Adding an IPGWx Signaling Link](#) procedure in Chapter 4.
 - [Adding an IPGWx Signaling Link](#) procedure in Chapter 6.
- Sockets or associations (with the corresponding application servers):
 - [Adding a Socket to an IPGWx Signaling Link](#) procedure in Chapter 4
 - [Adding an M3UA or SUA Association](#) procedure in Chapter 6
 - [Adding a New Association to a New Application Server](#) procedure in Chapter 6
 - [Adding an Existing Association to a New Application Server](#) procedure in Chapter 6
 - [Adding a New Association to an Existing Application Server](#) procedure in Chapter 6
 - [Adding an Existing Association to an Existing Application Server](#) procedure in Chapter 6

- Routing key matching the user part specified in the [Adding an End Node Internal Point Code](#) procedure and with the DPC of the routing key equal to the true point code of the EAGLE 5 ISS (shown in the **rtrv-sid** output) - See either the [Adding a Routing Key Containing a Socket](#) procedure in Chapter 4 or the [Adding a Routing Key Containing an Application Server](#) procedure in Chapter 6.

Adding an End Node Internal Point Code

This procedure is used to assign user parts to an internal point code (IPC), and thereby to an end office node using the **ent-rmt-appl** command. An internal point code is assigned to remote applications.

Only one IPC value for each network type can be configured. If you are adding an IPC value of the same network type as an existing IPC (for example, adding an ANSI IPC when the **rtrv-rmt-appl** output contains an ANSI IPC), the IPC value must be the same as the existing IPC value.

The **ent-rmt-appl** command uses these parameters:

:ipc/ipca/ipci/ipcn/ipcn24 – The end node's internal point code can be an ANSI (**ipc/ipca**), ITU-I or ITU-I spare (**ipci**), 14-bit ITU-N or 14-bit ITU-N spare (**ipcn**), or 24-bit ITU-N (**ipcn24**) point code.

NOTE 1: The point code value can also be either a private (p-) or a private spare (ps-) point code, but does not have to be a private or private spare point code. Any point code can be a private point code. Only ITU-I or 14-bit ITU-N point codes can be private spare point codes. The point code value must be shown in the rtrv-dstn command output.

NOTE: The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both at the same time.

:si – The service indicator value designates which MSU user part is being assigned to a remote application. Valid values range from 3 to 15.

:ssn – The SCCP subsystem number parameter. This parameter is required if the **si=3** parameter is specified and is not valid for any other **si** value. If the **ssne** parameter is also specified, then the **ssn** parameter serves as the starting value of a range. Valid values range from 0 to 255.

:ssne – The SCCP subsystem number range end parameter. The **ssne** value can be specified only if the **si=3** parameter is specified and is not valid for any other **si** value. This parameter serves as an end of a range, and so must be greater than the **ssn** parameter value. Valid values range from 1 to 255.

The specified assignment cannot be an existing assignment, including SSN subsets.

Procedure

1. Display a report listing the remote application assignments using the **rtrv-rmt-appl** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
  IPCA          SI SSN
    003-003-003    3  100, 110-119, 200
                   5

  IPCI          SI SSN
    p-3-003-3      3   5, 50-100, 250
                   5

  IPCN          SI SSN
```

IPCN24

SI SSN

2. Display the current destination point codes, using the **rtrv-dstn** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:02:05 GMT EAGLE5 36.0.0
```

DPCA	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
003-003-003	-----	yes	---	-----	-----	SS7
030-045-*	rlghncbb010	yes	yes	-----	-----	SS7
111-011-*	rlghncbb000	yes	yes	-----	-----	SS7
240-012-004	rlghncbb001	yes	---	1-111-1	2500	SS7
240-012-005	rlghncbb002	yes	---	1-112-2	1357	SS7
240-012-006	rlghncbb003	yes	---	1-112-3	4257	SS7
240-012-008	-----	yes	---	1-113-5	6939	SS7
244-020-004	ls06clli	yes	---	-----	-----	X25
244-020-005	ls07clli	yes	---	-----	-----	X25
244-020-006	ls08clli	yes	---	-----	-----	X25
244-020-007	-----	yes	---	-----	-----	X25
244-020-008	-----	yes	---	-----	-----	X25
p-003-003-003	-----	yes	---	-----	-----	SS7

DPCI	CLLI	BEI	ELEI	ALIASA	ALIASN/N24	DOMAIN
2-131-1	rlghncbb023	no	---	222-210-000	10789	SS7
2-131-2	-----	no	---	222-211-001	1138	SS7
2-131-3	-----	no	---	222-211-002	1298	SS7
p-3-003-3	-----	no	---	-----	-----	SS7

DPCN	CLLI	BEI	ELEI	ALIASA	ALIASI	DOMAIN
7701	rlghncbb013	no	---	222-200-200	2-121-1	SS7
11038	rlghncbb013	no	---	222-200-201	2-121-2	SS7
p-16380	-----	no	---	-----	-----	SS7

DPCN24	CLLI	BEI	ELEI	ALIASA	ALIASI	DOMAIN

```

DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s): 17
EXCEPTION DPC(s): 0
NETWORK DPC(s): 0
CLUSTER DPC(s): 2
TOTAL DPC(s): 19
CAPACITY (% FULL): 1%
ALIASES ALLOCATED: 12000
ALIASES USED: 18
CAPACITY (% FULL): 1%
X-LIST ENTRIES ALLOCATED: 500

```

If the IPC being added to the database is not shown in the **rtrv-dstn** output, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the IPC to the DPC table.

3. Add the remote application assignments using the **ent-rmt-appl** command.

For this example, enter these commands.

```
ent-rmt-appl:ipcn=p-16380:si=3:ssn=250
```

```
ent-rmt-appl:ipcn=p-16380:si=5
```

```
ent-rmt-appl:ipca=003-003-003:si=13
```

```
ent-rmt-appl:ipca=003-003-003:si=3:ssn=50:ssne=75
```

When each of these commands have successfully completed, the following message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
ENT-RMT-APPL: MASP A - COMPLTD;
```

4. Verify the changes using the **rtrv-rmt-appl** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
  IPCA          SI SSN
    003-003-003  3 50-75, 100, 110-119, 200
                  5
                  13

  IPCI          SI SSN
p-3-003-3       3 5, 50-100, 250
                  5


  IPCN          SI SSN
p-16380         3 250
                  5

  IPCN24        SI SSN
```

5. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 8-1. Adding an End Node Internal Point Code**Notes:**

1. If the *ipc* or *ipca* parameter is specified, only a full point code value can be specified.
2. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both at the same time.
3. The point code value can be a non-spare, non-private, spare (s-), private (p-) or a private spare (ps-) point code, but does not have to be a spare, private, or private spare point code. Any point code can be a private point code. Only ITU-I or 14-bit ITU-N point codes can be private spare point codes or spare point codes. The point code value must be shown in the *rtrv-dstn* command output.
4. Only one IPC value for each network type can be configured. If you are adding an IPC value of the same network type as an existing IPC (for example, adding an ANSI IPC when the *rtrv-rmt-appl* output contains an ANSI IPC), the IPC value must be the same as the existing IPC value.
5. The *ssn* parameter value cannot be greater than the *ssne* parameter value.

Removing an End Node Internal Point Code

The **dlt-rmt-appl** command is used to remove remote application assignments from the database.

The **dlt-rmt-appl** command uses these parameters:

:ipc/ipca/ipci/ipcn/ipcn24 – The end node's internal point code can be an ANSI, ANSI private (**ipc/ipca**), ITU-I, ITU-I spare, ITU-I private spare (**ipci**), 14-bit ITU-N, 14-bit ITU-N spare, 14-bit ITU-N private spare (**ipcn**), or 24-bit ITU-N, or 24-bit ITU-N private (**ipcn24**) point code.

:si – The service indicator value designates which MSU user part is being assigned to a remote application. Valid values range from 3 to 15.

:ssn – The SCCP subsystem number parameter. This parameter is required if the **si=3** parameter is specified and is not valid for any other **si** value. If the **ssne** parameter is also specified, then the **ssn** parameter serves as the starting value of a range. Valid values range from 0 to 255.

:ssne – The SCCP subsystem number range end parameter. The **ssne** value can be specified only if the **si=3** parameter is specified and is not valid for any other **si** value. This parameter serves as an end of a range, and so must be greater than the **ssn** parameter value. Valid values range from 1 to 255.

Procedure

1. Display a report listing the remote application assignments using the **rtrv-rmt-appl** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
  IPCA          SI SSN
    003-003-003    3 50-75, 100, 110-119, 200
                  5
                  13

  IPCI          SI SSN
    p-3-003-3      3 5, 50-100, 250
                  5

  IPCN          SI SSN
    p-16380        3 250
                  5

  IPCN24         SI SSN
```

2. Delete remote application assignments using the **dlt-rmt-appl** command.

For this example, enter these commands.

```
dlt-rmt-appl:ipca=003-003-003:si=3:ssn=100
```

```
dlt-rmt-appl:ipca=003-003-003:si=13
```

When each of these commands have successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
DLT-RMT-APPL: MASP A - COMPLTD;
```

3. Verify the changes using the **rtrv-rmt-appl** command.

This is an example of possible output:

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
  IPCA          SI SSN
    003-003-003    3 50-75, 110-119, 200
                  5
```

```

IPCI          SI SSN
p-3-003-3     3 5, 50-100, 250
              5
    
```

```

IPCN          SI SSN
p-16380       3 250
              5
    
```

```

IPCN24        SI SSN
    
```


4. Back up the new changes, using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
    
```

Flowchart 8-2. Removing an End Node Internal Point Code



Activating Controlled Features

Introduction	9-1
Enabling Controlled Features	9-1
Temporary Feature Keys	9-6
Turning On and Off Controlled Features	9-7
Turning On an Enabled Controlled Feature	9-8
Turning Off an Enabled Controlled Feature	9-10

Introduction

Controlled features are features that are activated using a feature access key. These features can be either features that can be turned on or off, or features that operate at a particular performance level.

Enabling Controlled Features

The **enable-ctrl-feat** command is used to enable a controlled feature by entering the controlled feature's access key and the controlled feature's part number with these parameters:

:fak – The feature access key generated by Tekelec's feature access key generator, and supplied to you when you purchase or temporarily try a controlled feature. The feature access key contains 13 alphanumeric characters and is not case sensitive.

:partnum – The Tekelec-issued part number associated with the controlled feature. The part number is a 9-digit number, not including dashes; the first three digits must be 893 (that is, 893xxxxxx, where x is a numeric value).

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

:serial – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

:lock – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

NOTE: To enter and lock the EAGLE 5 ISS's serial number, the **ent -serial-num** command must be entered twice, once to add the correct serial number to the database with the **serial** parameter, then again with the **serial** and the **lock=yes** parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).

Features can be enabled by entering a permanent feature access key. Some features can be tried or tested by entering a temporary feature access key. By requiring a feature access key to enable and activate a controlled feature, unauthorized enabling and activation of a controlled feature can be prevented.

Features enabled with a permanent feature access key remain enabled for as long as the EAGLE 5 ISS remains in service. Once features are permanently enabled, they cannot be disabled.

Enabling a Permanent or Temporary Key

This procedure explains how to enable controlled features in the EAGLE 5 ISS by entering either a permanent feature access key or a temporary feature access key for the controlled features. This procedure uses the **enable-ctrl-feat**, and **ent -serial-num** commands.

If the temporary key is being enabled, it must not be in the *in-use*, *expired*, or *unavailable* state.

The examples in this procedure are used to enable the controlled features in [Table 9-1](#).

Table 9-1. Sample Controlled Feature Part Numbers

Feature Name	Part Number
ISUP Normalization	893000201
ETSI v3 Normalization	893000601

Procedure

1. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

NOTE: If the serial number is correct and locked, skip steps 2, 3, and 4, and go to step 5. If the serial number is correct but not locked, skip steps 2 and 3, and go to step 4. If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

2. Enter the correct serial number into the database using the **ent -serial-num** command with the **serial** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

3. Verify that the serial number entered into step 2 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

System serial number is not locked.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 3 and 4 and re-enter the correct serial number.

4. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 1, if the serial number shown in step 1 is correct, or with the serial number shown in step 3, if the serial number was changed in step 2, and with the **lock=yes** parameter.

For this example, enter this command.

ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

5. Display an update of all of the controlled features that have been purchased and all of the temporary keys that have been issued by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

6. Enable the purchased permanent key or temporary key for controlled features being enabled by entering the **enable-ctrl-feat** command.

For this example, enter this command using the part numbers shown in [Table 9-1](#).

enable-ctrl-feat:partnum=893000201:fak=<feature access key>

enable-ctrl-feat:partnum=893000601:fak=<feature access key>

NOTE: The values for the feature access key (the **fak** parameter) are provided by Tekelec. If you do not have the controlled feature part number or the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

7. Verify the changes by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	off	----
ETSI v3 Normalization	893000601	off	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	


8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

9. If the controlled features enabled in step 4 are On/Off features, the features must be turned on using the **chg-ctrl-feat** command.

Specify the controlled feature part number used in step 4 and the **status=on** parameter. Go to the procedure in the [Turning On and Off Controlled Features](#) section to turn each feature on.

Flowchart 9-1. Enabling a Permanent or Temporary Key

Temporary Feature Keys

Features enabled with a temporary feature access key are enabled for only 30 days. On the twenty-third day, seven days before the temporary key expires, a major alarm (UAM 0367) is generated to inform the user that the one or more temporary feature access keys will expire soon.

```
0367.0181  ** SYSTEM      Temp Key(s) expiring soon.
```

If a temporary feature access key expires, the controlled feature is disabled and a critical alarm (UAM 0368) is generated.

```
0368.0181  *C SYSTEM      Temp Key(s) have expired.
```

Any attempts to enable the controlled feature with the temporary feature access key are rejected. The controlled feature can be enabled only by entering the permanent feature access key for the controlled feature.

To clear the critical alarm (UAM 0368), the user can either enter the **chg-ctrl-feat** command with the **alarm=clear** parameter, or permanently enable the controlled feature by entering the permanent feature access key for the controlled feature.

If the critical alarm is cleared with the **chg-ctrl-feat** command, the controlled feature is disabled and cannot be enabled with the temporary feature access key. The feature can be enabled only by entering the permanent feature access key for the controlled feature.

Clearing a Temporary Feature Access Key Alarm

This procedure is used to clear the EAGLE 5 ISS alarms using the **chg-ctrl-feat** command after a temporary feature access key has expired.

NOTE: The alarm is cleared when no temporary feature access keys are in danger of expiration or in an *expired* state.

The **chg-ctrl-feat** command uses the following parameters:

:partnum - The part number of the controlled feature that was temporarily enabled and is causing the alarm.

:alarm - Clear. Specifying **clear** for this parameter clears the alarm.

The following dependencies apply to this procedure:

The controlled feature part number must be valid. It must match the part number of the temporary controlled feature that is causing the alarm.

The controlled feature must have been temporarily enabled and is now in danger of expiration or in an *expired* state.

1. Display enabled controlled feature information that is causing the EAGLE 5 ISS alarm in the database by entering the **rtrv-ctrl-feat:expired=yes** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:37 GMT EAGLE5 36.0.0
The following features have expired temporary keys:
Feature Name      Partnum
ISUP Normalization 893000201
```

2. Clear the EAGLE 5 ISS alarm in the database by entering the **chg-ctrl-feat** command.

For example, enter this command. **chg-ctrl-feat:partnum=893000201:alarm=clear** When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-30 21:16:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP A - COMPLTD
```

3. Verify that the alarm has cleared in the database by using the **rtrv-ctrl-feat:expired=yes** command.

The following is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
0367.0181 * SYSTEM Temp Key(s) expiration alarm cleared.
```

4. Back up the changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 9-2. Clearing a Temporary Feature Access Key Alarm



Turning On and Off Controlled Features

Some controlled features must be turned on after they are enabled, and can be turned off without disabling them in the EAGLE 5 ISS. The **chg-ctrl-feat** command is used to turn the features on and off, and to clear the critical alarm that occurs when a temporary feature key expires (see the [Temporary Feature Keys](#) section).

The **chg-ctrl-feat** command uses the following parameters:

:partnum – The Tekelec-issued part number associated with the controlled feature. The part number is a 9-digit number, not including dashes; the first three digits must be 893 (that is, 893xxxxxx, where x is a numeric value).

:status – Changes the activation status of the feature (On or Off).

:alarm=clear – Use only to clear the critical alarm that is generated when a temporary feature key expires.

The part number that you enter must be for an On/Off feature that has already been enabled with the **enable-ctrl-feat** command (see the [Enabling Controlled Features](#) procedure).

Turning On an Enabled Controlled Feature

This procedure allows the user to turn on enabled controlled features in the EAGLE 5 ISS, by using the **chg-ctrl-feat** command.

The **chg-ctrl-feat** command uses these parameters:

:partnum – The Tekelec-issued part number associated with the controlled feature. The part number is a 9-digit number, not including dashes. The first three digits must be 893 (that is, 893xxxxxx, where x is a numeric value).

:status – used to activate the controlled features that customer has purchased and enabled.

The examples in this procedure are used to enable and activate the controlled features in [Table 9-2](#).

Table 9-2. Sample Controlled Feature Part Numbers

Feature Name	Part Number
ISUP Normalization	893000201
ETSI v3 Normalization	893000601

Procedure

1. Enter the **rtrv-ctrl-feat** command to display the status of the controlled features in the EAGLE 5 ISS.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	off	----
ETSI v3 Normalization	893000601	off	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

2. The controlled features listed in [Table 9-2](#) must be turned on using the **chg-ctrl-feat** command, specifying the controlled feature part number used to enable the feature and the **status=on** parameter.

For this example, enter these commands.

```
chg-ctrl-feat:partnum=893000201:status=on
```

```
chg-ctrl-feat:partnum=893000601:status=on
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

3. Verify the changes by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 9-3. Turning On an Enabled Controlled Feature



Turning Off an Enabled Controlled Feature

Some controlled features that have been enabled and turned on can be turned off without disabling them in the EAGLE 5 ISS. This procedure allows the user to turn off enabled controlled features in the EAGLE 5 ISS, by using the **chg-ctrl-feat** command.



CAUTION: If the Large BICC MSU Support for IP Signaling feature is turned off, the EAGLE 5 ISS will not process BICC messages with a signaling information field (SIF) that is larger than 272 bytes.

The **chg-ctrl-feat** command uses these parameters:

:partnum – The Tekelec-issued part number associated with the controlled feature. The part number is a 9-digit number, not including dashes. The first three digits must be 893 (that is, 893xxxxxx, where x is a numeric value).

:status – used to activate the controlled features that customer has purchased and enabled.

The examples in this procedure are used to turn off the controlled features shown in [Table 9-3](#).

Table 9-3. Sample Controlled Feature Part Numbers

Feature Name	Part Number
ISUP Normalization	893000201
ETSI v3 Normalization	893000601

Procedure

1. Enter the **rtrv-ctrl-feat** command to display the status of the controlled features in the EAGLE 5 ISS.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	on	----
ETSI v3 Normalization	893000601	on	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

2. The controlled features listed in [Table 9-3](#) are turned off using the **chg-ctrl-feat** command, specifying the controlled feature part number used to enable the feature and the **status=off** parameter. For this example, enter these commands.

```
chg-ctrl-feat:partnum=893000201:status=off
```

```
chg-ctrl-feat:partnum=893000601:status=off
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

3. Verify the changes by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
IPGWx Signaling TPS	893012814	on	20000
ISUP Normalization	893000201	off	----
ETSI v3 Normalization	893000601	off	----
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	

4. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 9-4. Turning Off an Enabled Controlled Feature



Glossary

A

ANSI	American National Standards Institute
APC	Adjacent Point Code
APC	Application Processing Chassis
AS	Application Server
ASP	Application Server Process
ASP	Application Service Part
ASP	Abstract Service Primitive
Association	An association refers to an SCTP association. The association provides the transport for protocol data units and adaptation layer peer messages.
ATM	Asynchronous Transfer Mode
ATMANSI	The application used for high-speed ANSI ATM signaling links.
ATMITU	The application used for high-speed E1 ATM signaling links.

B

BICC	Bearer Independent Call Control
BPDCM	The communication software used in place of the IMT GPL on the Database Communications Module (DCM), Database Services Module (DSM), and General Purpose Services Module (GPSM-II).

C

CAP	Communication & Application Processor
Changeover	A network management event that routes traffic from a failed signaling link to another signaling link that can carry the traffic.
CIC	Carrier Identification Code
	A 4-digit code that controls the routing applied to a message.
CIC	Circuit Identification Code
CICE	Ending Circuit Identification Code
CICS	Starting Circuit Identification Code
CLLI	Common Language Location Identifier
CPC	Capability Point Code
CPU	Central Processing Unit
CRC	CAM Redundancy Controller
CRC	Cyclic Redundancy Check
CSR	Customer Service Request

D

Database	All data that can be administered by the user, including cards, destination point codes, gateway screening tables, global title translation tables, links, LNP services, LNP service providers, location routing numbers, routes, shelves, subsystem applications, and 10 digit telephone numbers.
DCM	Database Communication Module The DCM provides IP connectivity for applications. Connection to a host is achieved through an ethernet LAN using the TCP/IP protocol.
Destination	The node to which the signaling link traffic is routed. This destination is identified by a point code, either a full point code or a cluster point code.
DIX	Digital/Intel/Xerox Digital/Intel/Xerox de facto standard for Ethernet Media Access Control Type.
DN	Directory number A DN can refer to any mobile or wireline subscriber number, and can include MSISDN, MDN, MIN, or the wireline Dialed Number.
Domain	A group of computers and devices on a network that are administered as a unit with common rules and procedures. The network in which the destination entity or node exists, X.25 or SS7.
DPC	Destination Point Code The point code of the signaling point to which the MSU is routed. This point code can be adjacent to the EAGLE 5 ISS, but does not have to be.
DPCN	Destination Point Code National
DS	Differentiated Service
DS0	Digital Signal Level-0 (64 Kbits/sec or 56 Kbits/sec) A basic digital signaling rate of 64 Kbits/sec, corresponding to the capacity of one voice-frequency-equivalent channel.
DTA	Database Transport Access A feature in the EAGLE 5 ISS that encapsulates specific MSUs into the data portion of SCCP within a new SS7 MSU and sends the new MSU to the destination using global title translation. The EAGLE 5 ISS uses gateway screening to determine which MSUs are used by the DTA feature.

E

E1	The European equivalent of T1 that transmits digital data over a telephone network at 2.048 Mbps.
E5-E1T1	EPM-based E1/T1 Multi-Channel Interface Module An EPM-based card that provides E1 and T1 connectivity. The E5 indicates the card is for existing EAGLE 5 control and extension shelves. E1T1 is an abbreviation for the ITU E1 and ANSI T1 interfaces. Thus the nomenclature defines the shelves where the card can be used and the physical interface that it provides.
E5-ENET	EPM-based Ethernet card A high capacity single-slot IP signaling card (EPM card plus Gig Ethernet PMC cards).
E5IS	EAGLE 5 Integrated Monitoring Support The EAGLE 5 Integrated Monitoring Support feature allows the network traffic on the EAGLE 5 ISS's signaling links to be monitored by an ESP (extended services platform) or IMP (integrated message feeder) without additional intrusive cabling. Message Signaling Units (MSUs), alarms, and events are copied to the Sentinel/IMF to provide the network traffic monitoring. The monitored traffic is delivered to the Sentinel/IMF using the

	EAGLE'S STCs (Signaling Transport Cards) which are connected to the ESP/IMF subsystem by Ethernet links. The ESP/IMF subsystem delivers the monitored traffic to the Sentinel/IMF.
EDCM	Enhanced DCM
EDCM	Enhanced Database Communication Module
ENET	Ethernet
ENET	Ethernet. Can refer to a generic hardware type that supports one or more Ethernet interfaces.
ETSI	European Technical Standards Institute

G

GPL	Generic Program Load
GPSM-II	General Purpose Service Module
GTT	Global Title Translation.

H

HC-MIM	High Capacity Multi-Channel Interface Module
HIPR	High-Speed IMT Packet Router
HMUX	High-Speed Multiplexer

I

ICMP	Internet Control Message Protocol
ID	Identity
ID	Identity, identifier
IEEE	Institute of Electrical and Electronic Engineers
IETF	Internet Engineering Task Force
IMF	Integrated Message Feeder
	A data acquisition system similar to Sentinel.
IMT	Inter-Module-Transport
	The communication software that operates the inter-module-transport bus on all cards except the LIMATM, DCM, DSM, and HMUX.
IP	Intelligent Peripheral
IP	Internet Protocol
IP7	Tekelec's Internet Protocol to SS7 Interface
IP Address	The location of a device on a TCP/IP network. The IP Address is a number in dotted decimal notation which looks something like [192.168.1.1].
IPC	Internal Point Code
IPGWI	An application that is used by the DCM/SSEDCM card for IP point-to-multipoint connectivity within an ITU-I or ITU-N network. The system allows a maximum of 64 cards to be assigned the IPGWI application.
IPGWx	Point-to-multipoint MTP-User signaling (e.g. ISUP, TCAP) over IP capability. Typically used for A link connectivity which require routing keys. Far End not required to support MTP3. The IPGWx GPL (IPGWI, SS7IPGW) run on the DCM/SSEDCM hardware.
IPGWx IP TPS	In addition to the IPGWx system IP TPS, there is a configurable per-linkset IP TPS, which must sum across all linksets to no more than the IPGWx system IP TPS.

IPLIM	The application used by the DCM/SSEDCM card for IP point-to-point connectivity for ANSI point codes.
IPLIMI	The application used by the DCM/SSEDCM card for IP point-to-point connectivity for ITU point codes.
IPLIMx	Point-to-point MTP3 and MTP3-User signaling over IP capability. Typically used for B-C-D links but can be used for A links but does not have routing key functionality. Far End required to support MTP3. The IPLIMx GPL (IPLIMI, IPLIM) run on the DCM/SSEDCM hardware.
IPNE	Internet Protocol Network Element
IPSP	IP Server Process
IPSP	IP Server Process
	A process instance of an IP-based application. An IPSP is essentially the same as an ASP, except that it uses MU3A in a peer-to-peer fashion. Conceptually, an IPSP does not use the services of a signaling gateway.
IS-NR	In Service - Normal
ISS	Integrated Signaling System
ISUP	ISDN User Part
ITU	International Telecommunications Union
ITU-N	ITU National

K

Key	For the ICNP feature, a unique DS value used to access a table entry, consisting of a number length and number type.

L

LAN	Local Area Network
	See also STP LAN.
LIM	Link Interface Module
Link	Signaling Link
LNP	Local Number Portability
LSN	Link Set Name

M

M2PA	SS7 MTP2-User Peer-to-Peer Adaptation Layer
M3UA	SS7 MTP3-User Adaptation Layer
MAP	Mated Application Part
MAP	Mobile Application Part
MASP	Maintenance and Administration Subsystem Processor
MDAL	Maintenance Disk and Alarm Card
MF	Miscellaneous Frame
MF	Mediation Function
MF	Multi-Frequency
MGC	Media Gateway Controller
MIB	Management Information Database

MIM	Multi-Channel Interface Module
MSU	Message Signaling Unit
MTP	Message Transfer Part
MTP	Module Test Plan
MTP2	Message Transfer Part, Level 2
MTPP	MTP Primitives
	Messages that the IPGWx application generates to communicate SS7 network management events (SNMs) to IP-attached network elements.

N

NI	Network Indicator
NMS	Network Management System

O

OAM	Operations, Administration, and Maintenance
OOS-MT	Out of Service - Maintenance
OOS-MT-DSBLD	Out of Service - Maintenance Disabled
OPC	Originating Point Code

P

PST	Primary State
PSTN	Public Switched Telephone Network.

R

RC	Relative Cost
RC	Restriction Criteria
RFC	Request for Comment
Route	A path to another signaling point.
Routing Key	A set of SS7 parameter and parameter values that uniquely define the range of signaling traffic to be handled by a particular Application Server. For example, where all traffic directed to an SS7 DPC, OPC and ISUP CIC_range(s) or SCCP SSN is to be sent to a particular Application Server, that SS7 data defines the associated Routing Key.
RTT	Ready to Test
RTT	Round Trip Time
RTT	Round Trip Time

S

SAAL	Signaling ATM Adaptation Layer
SAPC	Secondary Adjacent Point Code
SCCP	Signaling Connection Control Part
SCN	Switched Circuit Network
SCP	Service Control Point.

SCTP	Stream Control Transmission Protocol
SEAS	Signaling Engineering and Administration System An interface defined by Bellcore and used by the Regional Bell Operating Companies (RBOCs), as well as other Bellcore Client Companies (BCCs), to remotely administer and monitor the signaling points in their network from a central location.
SIF	Service Information Field
SI	Service Indicator
SIO	Service Information Octet
SIO	Service Information Octet.
SLC	Signaling Link Code
SLS	Signaling Link Selector
SNM	Signaling Network Management.
SNMP	Simple Network Management Protocol.
SPC	Secondary Point Code Spare Point Code
SPC	Signaling Point Code
SPC	Stored Program Control
SS	Subsystem
SS7	Signaling System #7
SS7IPGW	SS7 IP Gateway An application used by the DCM/SSEDCM card for IP point-to-multipoint capability within an ANSI network.
SSEDCM	Single Slot Enhanced Data Communications Module
SSN	Subsystem Number
SSN	SS7 Subsystem Number
SSP	Subsystem Prohibited network management message. Subsystem Prohibited SCCP (SCMG) management message. (CER) Service Switching Point (SS7 Network)
SST	Secondary State Subsystem Status Test network management message. Subsystem Status Test SCCP (SCMG) management message. (CER)
SST	Subsystem Status Test
STP	Signal Transfer Point.
STPLAN	Signaling Transfer Point Local Area Network The generic program load and application used by the ACM card to support the STP LAN application. This GPL does not support 24-bit ITU-N point codes.
SUA	SS7 SCCP-User Adaptation Layer
SUA	SCCP User Adaptation Layer

T

T1	Transmission Level 1 A T1 interface terminates or distributes T1 facility signals for the purpose of processing the SS7 signaling links carried by the E1 carrier. A leased-line connection capable of carrying data at 1,544,000 bits-per-second.

Database Administration Manual - IP7
Secure Gateway

TALI	Transport Adapter Layer Interface (RFC 3094)
TCA	Transfer Cluster Allowed
TCAP	Transaction Capabilities Application Part
TCP	Transfer-Cluster-Prohibited
TCP	Transfer Control Protocol
TCP	Transmission Control Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
TDM	Terminal Disk Module.
TOS	Type of Service
TPC	True Point Code
TPS	Transactions Per Second
TPC	True Point Code
TSPC	True or Secondary Point Code
TUP	Telephone User Part

U

UA	ETF User Adaptation Layers
UAM	Unsolicited Alarm Message.
UDP	User Datagram Protocol
UIM	Unsolicited Information Message
UPU	User Part Unavailable

Index

1500 Signaling Links 3-18 , 4-66 , 5-17 , 6-76

2000 Signaling Links 3-18 , 4-66 , 5-17 , 6-76

A

activate signaling link, act-slk

IPGWI 3-34 , 3-52 , 3-65 , 3-66 , 3-97 , 3-98 , 4-44 , 4-82 , 4-99 , 5-33 , 5-51 , 5-65 , 5-68 , 5-110 , 5-113 , 6-46 , 6-92 , 6-109 , 6-237

IPLIM 3-34 , 4-44 , 4-82 , 5-33 , 6-46 , 6-92 , 6-237

SS7IPGW 3-34 , 3-52 , 3-65 , 3-66 , 3-97 , 3-98 , 4-44 , 4-82 , 4-99 , 5-33 , 5-51 , 5-65 , 5-68 , 5-110 , 5-113 , 6-46 , 6-92 , 6-109 , 6-237

admonishments, documentation 1-3

alw 3-93 , 4-168

Applications 2-2

C

cice 4-121 , 4-163 , 4-192 , 4-201 , 6-166 , 6-167 , 6-224 , 6-274 , 6-283

cics 4-121 , 4-163 , 4-192 , 4-201 , 6-166 , 6-224 , 6-274 , 6-283

D

dcmps 3-93 , 4-168

Default Routing Keys 2-20

display card status, rept-stat-card

IPGWI 3-31 , 3-50 , 4-79 , 4-98 , 5-30 , 5-49 , 6-89 , 6-108 , 6-236

IPLIM 3-31 , 3-50 , 4-79 , 4-98 , 5-30 , 5-49 , 6-89 , 6-108

SS7IPGW 3-31 , 3-50 , 4-79 , 4-98 , 5-30 , 5-49 , 6-89 , 6-108 , 6-236

display signaling link status, rept-stat-slk

IPGWI 3-30 , 3-35 , 3-48 , 3-52 , 3-65 , 3-97 , 4-78 , 4-83 , 4-96 ,

4-100 , 5-29 , 5-34 , 5-47 , 5-51 , 5-64 , 5-110 , 5-139 , 6-88 , 6-93 , 6-106 , 6-110 , 6-235 , 6-237 , 6-294

IPLIM 3-30 , 3-35 , 3-48 , 4-78 , 4-83 , 4-96 , 5-29 , 5-34 , 5-47 , 5-139 , 6-88 , 6-93 , 6-106 , 6-237 , 6-294

SS7IPGW 3-30 , 3-35 , 3-48 , 3-52 , 3-65 , 3-66 , 3-97 , 3-98 , 4-78 , 4-83 , 4-96 , 4-100 , 5-29 , 5-34 , 5-47 , 5-51 , 5-65 , 5-68 , 5-110 , 5-114 , 5-139 , 6-88 , 6-93 , 6-106 , 6-110 , 6-235 , 6-237 , 6-294

documentation

admonishments 1-3

dpc 4-162 , 6-223

drkq 6-239 , 6-240

F

Full Routing Keys 2-19

G

getcomm 6-239 , 6-240

I

inhfepalm 6-239 , 6-240

ipgwabate 6-239 , 6-240

ipgwi 2-2 , 2-16

activate signaling link, act-slk 3-34 , 3-52 , 3-65 , 3-66 , 3-97 , 3-98 , 4-44 , 4-82 , 4-99 , 5-33 , 5-51 , 5-65 , 5-68 , 5-110 , 5-113 , 6-46 , 6-92 , 6-109 , 6-237

display card status, rept-stat-card 3-31 , 3-50 , 4-79 , 4-98 , 5-30 , 5-49 , 6-89 , 6-108 , 6-236

display signaling link status, rept-stat-slk 3-30 , 3-35 , 3-48 , 3-52 , 3-65 , 3-97 , 4-78 , 4-83 , 4-96 , 4-100 , 5-29 , 5-34 , 5-47 , 5-51 , 5-64 ,

5-110 , 5-139 , 6-88 , 6-93 , 6-106
 , 6-110 , 6-235 , 6-237 , 6-294
iplim 2-2
activate signaling link, act-slk 3-34 , 4-44
 , 4-82 , 5-33 , 6-46 , 6-92 , 6-237
display card status, rept-stat-card 3-31 ,
 3-50 , 4-79 , 4-98 , 5-30 , 5-49 ,
 6-89 , 6-108
display signaling link status, rept-stat-slk
 3-30 , 3-35 , 3-48 , 4-78 , 4-83 ,
 4-96 , 5-29 , 5-34 , 5-47 , 5-139 ,
 6-88 , 6-93 , 6-106 , 6-237 , 6-294
iplimi 2-2
IP options
drkq 6-239 , 6-240
getcomm 6-239 , 6-240
inhfepalm 6-239 , 6-240
ipgwabate 6-239 , 6-240
setcomm 6-239 , 6-240
snmpcont 6-239 , 6-240
srkq 6-239 , 6-240
sync 6-234
trapcomm 6-239 , 6-240
IP protocol option 6-234

N

Nagle's Algorithm 2-28
ncice 4-192 , 4-201 , 6-274 , 6-283
ncics 4-192 , 4-201 , 6-274 , 6-283

O

opc/opca 4-121 , 4-163 , 4-192 , 4-200
 , 6-166 , 6-223 , 6-224 , 6-273 ,
 6-283
open 3-93 , 4-168

P

Partial Routing Keys 2-19

R

Routing Key Lookup Hierarchy 2-21
Routing Key Tables 2-20

S

server 3-93 , 4-168
setcomm 6-239 , 6-240
si 4-163 , 6-224
signaling links, 1500 3-18 , 4-66 , 5-17 ,
 6-76
signaling links, 2000 3-18 , 4-66 , 5-17 ,
 6-76
sname 4-163 , 6-224
snmpcont 6-239 , 6-240
split 4-192 , 4-201 , 6-274 , 6-283
srkq 6-239 , 6-240
ss7ipgw 2-2 , 2-16
activate signaling link, act-slk 3-34 , 3-52
 , 3-52 , 3-65 , 3-66 , 3-97 , 3-98 ,
 4-44 , 4-82 , 4-99 , 5-33 , 5-51 ,
 5-65 , 5-68 , 5-110 , 5-113 , 6-46 ,
 6-92 , 6-109 , 6-237
display card status, rept-stat-card 3-31 ,
 3-50 , 4-79 , 4-98 , 5-30 , 5-49 ,
 6-89 , 6-108 , 6-236
display signaling link status, rept-stat-slk
 3-30 , 3-35 , 3-48 , 3-52 , 3-65 ,
 3-66 , 3-97 , 3-98 , 4-78 , 4-83 ,
 4-96 , 4-100 , 5-29 , 5-34 , 5-47 ,
 5-51 , 5-65 , 5-68 , 5-110 , 5-114 ,
 5-139 , 6-88 , 6-93 , 6-106 , 6-110
 , 6-235 , 6-237 , 6-294
ssn 4-163 , 6-224
sync 6-234

T

trapcomm 6-239 , 6-240
Type of Service 2-29