

AutoVue
Desktop Version 19.3
Installation and Administration Manual

Copyright © 1989, 2008, Oracle and/or its affiliates. All rights reserved.

Portions of this software Copyright 1996-2007 Glyph & Cog, LLC.

Portions of this software Copyright Unisearch Ltd, Australia.

Portions of this software are owned by Siemens PLM © 1986-2008. All rights reserved.

This software uses ACIS® software by Spatial Technology Inc. ACIS® Copyright © 1994-1999 Spatial Technology Inc. All rights reserved.

Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws.

Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this software or related documentation is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS

Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy and other measures to ensure the safe use of this software. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software in dangerous applications.

This software and documentation may provide access to or information on content, products and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third party content, products and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third party content, products or services.

Contents

INTRODUCTION	9
INSTALLATION.....	11
System Requirements	11
Installing AutoVue	11
AutoVue Silent Installation.....	12
Setting up AutoVue for a Silent Installation on Client Machines	13
Uninstalling AutoVue	13
Interactive Uninstallation.....	13
Non-Interactive Uninstallation.....	13
Release Notes	14
HELP FEATURES	15
CHANGING THE LANGUAGE OF AUTOVUE.....	16
VIEWING AND EXPORTING FILE VERSIONS INFORMATION	17
Viewing File Versions	17
Exporting File Versions.....	17
COMMAND LINE OPTIONS	19
Customizing AutoVue Startup.....	19
Syntax.....	20
Commands.....	20
INITIALIZATION FILE CONFIGURATION	23
INI File Configuration	23
Creating an Alternative INI File	23
AutoVueX INI File.....	24
ActiveX INI Options.....	24
Network Configuration	26
INI OPTIONS	27
Acrobat PDF Options	27
Allegro Options	28
AutoCAD Options.....	29
Autodesk DWF Options	31
Autodesk Inventor Options.....	32
Cadence Options	32
Cadkey Options.....	33

CATIA 4 Options	33
CATIA 5 Options	34
CGM Options	35
Excel Options	36
Gerber Options	36
HPGL/HPGL2 Options	38
IFC Options	39
IGES Options	40
JPEG Options	41
JPEG 2000 Options	42
ME10/OneSpace Designer Drafting Options	43
Microsoft Outlook Options	44
MicroStation DGN7/DGN8 Options	45
NC-Drill Options	50
OrCAD Layout Options	51
Pro/ENGINEER Options	51
SolidWorks Options	54
STEP Options	55
Text Options	56
TIFF Options	56
Visio Options	56
Word Options	57
General Options	58
Base Font Options	69
UI Color Options.....	70
AutoVue Mobile Options	71
3D Options	72
3D Color Options	76
3D Measurement Units	77
3D PMI Options	78
EDA Options	83
Markups	87
Markup Options	87
Calibrate	92
Markup Font Options	93
Streaming File Options	93
Applications Options	94

Compare Options	95
Overlay Options	95
Page Size Options in Inches	97
Page Size Options in Millimeters	97
3D Export Options	98
2D Output Options	98
Pen Mapping Options	105
Disable Options	106
OEM Options	108
Thumbnail Options	108
Printing Options	109
Watermark	109
Stamp	110
General Print Options	111
Headers and Footers	114
Printing Batch Pages	115
Margins	116
Notes	116
Markup Measurement Options	117
Area Measurements	117
Arc Measurements	118
Angle Measurements	118
Distance Measurements	119
3D Distance Measurements	119
Calibrate Measurements	120
Watermark in View Mode	121
SCRIPT AND DDE COMMANDS	123
Script Syntax Diagrams	123
Window Commands	124
Child Commands	124
General Commands	126
File Commands	126
Export BOM Commands	128
Printing Commands	128
Print Options	129
Conversion Commands	139
Convert Options	139

View Commands	141
Markup Commands	143
Option Commands	143
INTEGRATION.....	145
Defining Integration.....	145
Integrating with AutoVue	146
DDE Integration	148
DLL Integration	148
OLE Automation.....	150
EDAT: Drawing Information Extraction	153
VCET API.....	153
Markup API	154
AutoVue Command Summary	155
Syntax Summary	156
General Commands.....	156
File Commands	156
View Commands.....	158
Printing Commands.....	160
Print Options	160
Conversion Commands	160
Convert Options	161
Markup Commands.....	163
Option Commands	163
Window Commands.....	164
Child Commands.....	165
EDAT/Drawing Information Commands.....	165
ActiveX Control	166
AutoVueX Control	167
AvMarkupX Control	190
AvPrintX Control	198
AutoVue CompareX Control	202
Integration: AutoVue and "Visual Basic" Applications	207
FORMAT SUPPORT	209
UTILITIES	211
Full Text Extraction.....	211
Using the FullText Extraction Utility	211
Ftype.....	211

CAD Information Extraction..... 212

FEEDBACK213

General Inquiries 213

Sales Inquiries 213

Customer Support..... 213

INDEX.....215

Introduction

Oracle's AutoVue Enterprise Visualization is the industry leading solution for viewing, reviewing, and collaborating on technical documents and information across the enterprise. With support for hundreds of document types, including 2D/3D CAD, EDA, image, and Office, the desktop version allows users within and beyond an organization to instantly and reliably view, markup, print and collaborate on documents, without requiring the original authoring application, and without altering document integrity. Organizations can extend the reach of technical information to a broader set of enterprise users and optimize internal business processes, driving innovation, operational efficiency and business excellence.

Installation

This chapter describes the recommended system requirements and installation procedures for AutoVue.

Note: If you have a network installation of AutoVue Desktop Version (i.e., accessing AutoVue Desktop Version over the network), you must install the Microsoft Visual C++ 2005 SP1 Redistributable Package on each of the machines accessing AutoVue over the network:

<http://www.microsoft.com/downloads/details.aspx?familyid=200b2fd9-ae1a-4a14-984d-389c36f85647&displaylang=en>

System Requirements

- Microsoft Windows 2003 32-bit, Windows XP 32-bit, or Vista 32-bit.
- A hard disk with at least 400 MB of hard disk space.

Note: The memory requirement is dependent on the size and complexity of files you try to view with AutoVue.

Installing AutoVue

If you have an older version of AutoVue installed on your computer, we recommend that you uninstall it before proceeding with the new installation.

Before uninstalling your previous version of AutoVue, make sure to save a backup copy of any specific settings and content that you would like to push forward into your new version. This can include the following:

- AutoVue settings from the "avwin.ini" file (located in the C:\windows directory by default)
- Custom translation .tra files (located in the \avwin directory of your AutoVue installation)
- Custom markup symbol libraries (located in the \avwin\Symbols directory of your AutoVue installation)
- Thumbnails Cache, if any (located in the \avwin\Folders directory of your AutoVue installation)

If you decide to move these settings/content forward to your new installation of AutoVue, they can for the most part be copied to the same relative locations in your new installation. However, for the AutoVue settings in "avwin.ini", it is best

to manually copy the specific settings that you would like to keep, as the newer version of AutoVue may have important new settings.

To install AutoVue, do the following:

- 1 If you downloaded AutoVue from the web site, extract the contents of the zip file and run `avsetup.exe`.
If you have the CD, run `avsetup.exe` from the CD.
- 2 The **InstallShield Wizard** dialog box appears.
- 3 Select the language of AutoVue you want to install, then click **Next**.
Note: You can also change the language of AutoVue after it is installed.
The **AutoVue Welcome** dialog appears.
- 4 Read the dialog, then click **Next**.
The **License Agreement** dialog appears.
- 5 Read the **License Agreement**, then click **Yes** to accept terms.
The **Customer Information** dialog appears.
- 6 Enter your **User Name** and **Company Name**, then click **Next**.
The **Destination Location** dialog appears.
- 7 The default directory where AutoVue will be installed is **C:\Program Files\av**. To accept this location, click **Next** in the **Destination Location** dialog.
Note: If you would like to install AutoVue elsewhere, click **Browse** and select the desired location, then click **Next** in the **Destination Location** dialog.
The **Select Program Folder** dialog appears.
- 8 Enter a **Program Folder** that will contain AutoVue program icons or accept the default folder, then click **Next**.
A dialog box appears indicating the progress of the installation.
- 9 Click **Finish** to complete the installation.

AutoVue Silent Installation

AutoVue can be set up to run in a “silent install” mode. All the parameters needed for the installation are specified in a file which when called upon runs the installation setup without the need for user input.

Setting up AutoVue for a Silent Installation on Client Machines

- 1 Go to the directory where **avsetup.exe** is located.
- 2 At the command prompt, enter **avsetup.exe -a -r**.
The AutoVue setup program is launched.
- 3 Continue the installation setup, answering all the prompts from AutoVue's setup program. See [Installing AutoVue](#).
When the installation setup program is complete, the parameters file called **setup.iss** is stored in the Windows directory. This file contains the user input from the installation. If you wish to modify setup.iss after it is created, you can do so. Below table lists the keys that can be modified.

Where:

szCompany	Name of the company
szDir	Directory where AutoVue is to be installed.
Lang	Default language for AutoVue.

- 4 To run the silent install on the client machine, type the following line at the command prompt:
avsetup.exe -a -s -fIC:\windows\setup.iss
Note: Make sure you enter the number "1" after "f," not the letter L.

Uninstalling AutoVue

Interactive Uninstallation

You can uninstall AutoVue by selecting **Setup > UnInstall AutoVue** from the **AutoVue, Desktop Version** programs shortcut.

Non-Interactive Uninstallation

You can uninstall AutoVue in non-interactive mode. The uninstaller will not prompt the user for input when running in non-interactive mode. However, the

installation progress will be displayed.

To uninstall AutoVue in non-interactive mode, run the following command:

avsetup.exe -csiUninstall -csiSilent

Release Notes

The Release Notes contain last minute information that may not be included in the manuals. You can access this file after running the installation procedure. Just select the Release Notes icon from the AutoVue group.

Help Features

AutoVue provides a **Help** menu that allows you to easily access information on how to use AutoVue.

From the **Help About** dialog box, you can see information about your current installation of AutoVue. Information such as the variation of AutoVue you are using, the version, the build number and the current language that AutoVue is running is displayed. You can also change the language of the AutoVue user interface.

Changing the Language of AutoVue

AutoVue supports different languages for the User Interface. If you wish to switch to a different language, you can do so from the **Help** -> **About** dialog. AutoVue supports the following languages:

- English
- French
- German
- Simplified and Traditional Chinese
- Japanese
- Korean

Note: When you change from one language to another, all toolbar customizations are reset to their default settings.

Take the following steps to switch to a different language:

- 1 Select **Help** > **About** from the AutoVue main menu.
The **About** dialog appears.
- 2 Click **Change Language**.
The **Language Change** dialog appears.




- 3 From the **New Language** drop-down list, select the language you want to change to.
- 4 Click **OK**.
- 5 Click **OK** in the **About** dialog.
- 6 Restart AutoVue for the new language to take effect.

Viewing and Exporting File Versions Information

With AutoVue you can view the version, build number and date of the component .dll files, as well as export the results into a text file.

Viewing File Versions

- 1 Select **Help > About** from the AutoVue main menu.
The **About** dialog appears
- 2 Click **Version Info**.
The **File Versions** dialog appears.



- 3 When you finish viewing, click **OK**.

Exporting File Versions

- 1 Select **Help > About** from the AutoVue main menu.
The **About** dialog appears.
- 2 Click **Version Info**.
The **File Versions** dialog appears.
- 3 Click **Export**.
The **Export** dialog appears.
- 4 Navigate and select the directory you want to export the file to.
- 5 Enter a **File name** with the extension **.txt** or accept the default.

Note: The file can only be exported to text file.

6 Click **Save**.


The export result is exported to the selected directory.

Command Line Options

You may change the behavior of AutoVue on startup with Command Line options. Simply follow the instruction set corresponding to your computer's operating system.

Customizing AutoVue Startup

There are two possibilities:

- 1 Right-click the AutoVue icon  in the Windows group.
- 2 Select **Properties**.
- 3 Click the **Shortcut** tab.
- 4 Enter the Command Line options after the filename and path provided for you in the **Target** text box.
- 5 Click **Apply**.

or

- 1 Select **Run** from the **Start** menu.
- 2 Take one of the following steps:
 - Click **Browse** and browse to the location AutoVue (avwin.exe) is installed.
 - Enter the full path where AutoVue (avwin.exe) is installed.
For example: C:\Program Files\av\avwin.exe
- 3 Click **OK**.

Syntax

Syntax	Description
<angular brackets>	Indicate required entries, but are not included with the entered information.
{curly braces}	Indicate optional entries that may or may not to be included in the command.
[square brackets]	Are required syntactical elements and <i>should</i> be included in the command.
(parentheses)	Are required syntactical elements and <i>should</i> be included in the command.
Bold	Introduces a literal expression and must be entered exactly as shown.
<i>Italics</i>	Indicates a variable that must be replaced by the information you supply.
	Indicates a choice between two selections; this symbol is not entered.
...	Indicates that information may be repeated; this symbol is not entered.

Commands

Command	Description
{file1...}	Lists the files to show on startup: avwin [filename1][filename2] One or more filenames can be specified as startup parameters. These files will automatically be opened and viewed by AutoVue.
{-c cfgfile} or {/c cfgfile}	Specifies the path and configuration file to use: avwin -c inifilename
{-lastfile=fname} or {/lastfile=fname}	Writes the name of the last file viewed into the file name.

{-hide} or {/hide}	Does not display the AutoVue user interface on the desktop.
{-maximizes} or {/maximizes}	Displays a maximized AutoVue user interface on the desktop.
{-minimizes} {/minimizes}	Displays a minimized AutoVue user interface on the desktop.
{-p [nnn-mmm] <i>filename</i> } or {/p [nnn-mmm] <i>filename</i> }	<p>Prints the page range of the specified file from nnn to mmm.</p> <p>avwin -p [pagerange] filename</p> <p>Specifying the -p option makes AutoVue print the filename given with the current default print settings. The file is automatically opened, printed and closed. The pagerange argument is optional. If not specified, all pages are printed by default. The pagerange is in the format: n1 or n2-n3.</p> <p>Example:</p> <p>avwin -p [2-5] myfile.doc would print pages 2 to 5 both inclusive of the file “myfile.doc”.</p>
{-restore} {/restore}	Displays the AutoVue user interface on the desktop at the original size.
{-s <i>scriptfile</i> } or {/s <i>scriptfile</i> }	<p>Specifies a script file to run on startup: Automatically executes the specified script file on startup.</p> <p>Example: avwin -s scriptfile</p>
{-search} {/search}	<p>The /search option automatically initiates a search on the filename given. If the string is found, the text is automatically scrolled to view and the found text is highlighted. Once the text has been found, you can use the F3 function key to find the next search hit within the document. avwin filename -search searchstring</p>

{-f filename}

or

{f filename}

The filename refers to a file that contains a list of files to which AutoVue has access. This file must be in ASCII text and spell out the path of the authorized files at the beginning of each line.

Initialization File Configuration

INI File Configuration

AutoVue stores its runtime settings in a configuration file. This file is by default located in the Windows directory and named **avwin.ini**. The name can be changed with the Command Line options. By presetting AutoVue's INI file, integrators can set up defaults for various operations. Examples include setting up defaults for conversion (output format, output file, etc.), setting up defaults for viewing and printing etc.

After AutoVue is installed and run for the first time on a workstation, this file is created under the Windows directory. The INI file has several sections. Each section heading is enclosed in square brackets. The sections that are listed in this chapter may be changed. Any other sections **must remain unchanged** for AutoVue to operate properly.

Creating an Alternative INI File

- 1 Open the **avwin.ini** file.
- 2 Create and name a copy of the file.
Example: avwin2.ini
Note: This is done so that the original **avwin.ini** file is available as a default file for AutoVue.
- 3 Open the file in any text editor, such as Notepad.
- 4 Locate the section heading corresponding to the changes you want to make.
Example: [Markup Options]
- 5 Modify the command line if it already exists or add the new command line.
Example: INFO_USER=Name of Author
- 6 Save the changes to **avwin2.ini** and close the file.
- 7 Direct AutoVue to use **avwin2.ini** as the configuration file with the command line **-C avwin2.ini**.

AutoVueX INI File

AutoVueX, which is the ActiveX controller for AutoVue, stores its runtime settings in the configuration file, **avx.ini**. This file is by default located in the Windows directory. As with AutoVue's INI file, you can set up new defaults for various operations for AutoVueX's INI file (for example, a different background color). The path to the modified configuration can also be changed. To make these modifications you can do the following:

- 1 Set the windows system environment variable, **AUTOVUEX_INI**, to point to the full path of the modified AutoVueX INI file.

Example: AUTOVUEX_INI=C:\Temp\myavx.ini

- 2 Launch the ActiveX test container or sample.

ActiveX will read from the windows system environmental variable and load the configuration specified in **myavx.ini**.

Note: If the folder containing the modified AutoVueX INI file, **myavx.ini**, is read-only, ActiveX will revert to the default file and location, %WINDIR%\avx.ini.

ActiveX INI Options

Configure ActiveX INI options. The option section header is indicated in brackets [].

[Disable]

Parameter	Description	Default
Layers	Set to 1 to disable ShowLayersDialog method and layer icon from GUI. Set to 0 to enable. Syntax: [Disable] Layers=<0/1>	0

Parameter	Description	Default
Blocks	Set to 1 to disable ShowBlocksDialog method and layer icon from GUI. Set to 0 to enable. Syntax: [Disable] Blocks=<0/1>	0
ZoomOnRMB	Enables or disables the Zoom Fit behavior of the right mouse button (RMB). Set to 1 to enable the Zoom Fit behavior of the RMB. Set to 0 to disable the Zoom Fit behavior of the RMB. Syntax: [Disable] ZoomOnRMB=<0/1>	1

Network Configuration

When AutoVue is installed on a network, each user can specify his or her own configuration file. By default, a user's configuration file is named Avwin.ini and is located in the local Windows directory. The name and path to the configuration file can be changed so that each user has a configuration file. This is specified using the -C Command Line option.

Example:

Assuming that AutoVue is installed on a Network drive named U, two users could have their own settings and configuration files.

- User1 setting where **User1.ini** is the configuration file:

```
U:\AutoVue\avwin\avwin.exe -C C:\AutoVue\user1.ini
```

- User2 setting where **User2.ini** is the configuration file:

```
U:\AutoVue\avwin\avwin.exe -C C:\AutoVue\user2.ini
```

Note: Place paths with spaces between double quotation marks.

INI Options

In the following sections, option section headers are indicated in brackets []. Section headers in the INI file must be specified in brackets. The options for the section are discussed in the table below the section header.

Acrobat PDF Options

Configure Acrobat PDF file options.

[Options]

Parameter	Description	Default
PDFCACHELEVEL = <None Low Medium High>	<p>Customize the level of caching of PDF font glyph bitmaps to improve performance.</p> <p>Specify one of the four caching levels:</p> <p>None - Fonts are not cached (least memory used).</p> <p>Low - Up to 2 fonts cached (up to 3 text sizes per font, up to 200KB of memory).</p> <p>Medium - Up to 4 fonts cached (up to 6 sizes per font, up to 800KB of memory).</p> <p>High - Up to 8 fonts cached (up to 6 sizes per font, up to 1.5MB of memory)</p> <p>The higher the level of caching, the faster the text displays; however memory usage is also higher.</p>	Medium
PDFDPIRESOLUTION = <dpi>	<p>Defines the dpi resolution (dots per inch) for rendering PDF pages on screen. It can be set to any value between 72 and 1224.</p>	360

Allegro Options

Configure options for Allegro files.

[ECAD]

Parameter	Description	Default
ALLEGRO_USETRUETYPEFONTS = <0 1>	Set to 0 to use stroke font. Set to 1 to use true type font instead.	0
ECAD_3D_SHOWHOLES = <0 1>	Set to 1 if you want holes to be drawn in the 3D model. Set to 0 if you do not want holes to be drawn in the 3D model (increases performance). Currently only affects Allegro files.	0

AutoCAD Options

Configure options for ACAD files.

[Options]

Parameter	Description	Default
ACAD_FAST3D = <0 1>	<p>Set to 1 to improve rendering speed of AutoCAD 3D.</p> <p>Note: Setting this option to 1 means that layers will not be listed and AutoVue streams all meshes & extrusions in one body.</p> <p>Set to 0 will mean slower rendering of AutoCAD 3D. However, layer information is listed and each mesh is streamed in its own entity.</p>	1
ACAD_PENSETTINGSAFFECTLI NEWIDTH=<0 1>	<p>Option is for AutoCAD drawings.</p> <p>When set to 0, pen settings do not affect non-zero constant width polylines.</p> <p>When set to 1, pen settings affect non-zero constant width polylines.</p>	0
ACAD2004RGBCOLOR = <0 1>	<p>If 1, use RGB color.</p> <p>If 0, use AIC (AutoCAD Indexed Color).</p> <p>Note: Should be set to 0 to be able to use pen settings for printing.</p> <p>Note: This is for AutoCAD files, version 2004 and later.</p>	1
ACADDEFAULTFONT = fontname	<p>This font is substituted if an 8-bit font is not located for AutoCAD drawings.</p>	

Parameter	Description	Default
ACADDEFAULTBIGFONT = big-fontname	This font is substituted if a 16-bit font is not located	
DRAWORDER = <0 1>	If 1 , draws sorted (ordered) entities from the last save of the DWG file, otherwise, entities are drawn in the order they were first created.	1
FIELDDISPLAY = <0 1>	Specify whether or not field backgrounds display. Set to 1 to display field background. Set to 0 to hide field background. Note: For AutoCAD 2005 and up.	1
LWDEFAULT = [1-100]	Set the default line weight. Specify a value between 1 (which corresponds to 0.01mm) and 100 (which corresponds to 1mm). Default value is 25 (which corresponds to 0.25mm).	25
LWDISPLAYSCALE = [0-100]	This option controls the display scale of line weights in the model space page for AutoCAD files version 14 and above. Set this option to [0-100]. <ul style="list-style-type: none"> • For no line weight scaling, set this option to 25. • For thicker lines, set this option above 25. • For thinner lines, set this option below 25. 	25
SHOWALLLAYERS = <0 1>	If 1 , turns on all the layers in the base and XRef files.	0

Autodesk DWF Options

Configure options for DWF files.

[Options]

Parameter	Description	Default
DWFRGBCOLOR = <0 1>	If 1 , use RGB color. If 0 , use AIC (AutoVue Indexed Color). Note: Should be set to 0 to be able to use pen settings for printing.	1
DWFCOLORTBL	Option is applicable only when DWFRGB-COLOR = 0 . Specify the path and the name to a color table. Specified color table overrides the palette stored in the DWF file. If no external palette is specified, the default palette stored in the DWF file will be used. Below are some of the common colors and their corresponding pen numbers: 0,0,0 /* 0, Black */ 128,128,128 /* 248, Gray */ 255,0,0 /* 190, Red */ 0,255,0 /* 40 Green */ 255,255,0 /* 251, Yellow */ 0,0,255 /* 15, Blue */ 255,0,255 /* 195, Violet */ 0,255,255 /* 45, Cyan */ 255,255,255 /* 225, White */	

Autodesk Inventor Options

Configure options for Autodesk Inventor files.

[Options]

Parameter	Description	Default
AIBACKGROUND = <0 1>	If 1 , the Inventor decoder draws the background sheet. Otherwise, the decoder draws the outline only. This option applies to Autodesk Inventor 2D files.	1
AILOADNATIVE2D = <0 1>	If 1 , forces the 2D Inventor decoder to use native data. Otherwise, the DWF embedded image is used if it exists. If DWF information is not stored in the Inventor 2D file, then native support will be activated automatically. This option applies to Autodesk Inventor 2D files.	1

Cadence Options

Configure options for Cadence HDL files.

[ECAD]

Parameter	Description	Default
CADENCE_CONCEPTHDL ONLY = <0 1>	Set to 1 if you do not want PCB boards displayed.	0
CADENCE_CPMONLY = <0 1>	Set to 1 if you want only files listed in the CPM file displayed.	1

Cadkey Options

Configure options for Cadkey files.

[Options]

Parameter	Description	Default
PRTFONTMAP=fullpath_ to_prffont.map	Specifies the full path to the Cadkey/PRT font map file. This file maps Cadkey/PRT fonts to TrueType fonts.	The file Prtfont.map in the program directory. (avwin)

CATIA 4 Options

Configure options for CATIA 4 files.

[Options]

Parameter	Description	Default
CATIAProjectFile	Specify the full path to the CATIA project file. Note: Option applies to CATIA 4 files only.	
LoadCatiaWires = <0 1>	Set to 0 to disable display of 3D wires for CATIA V4 3D files.	1
CatiaDefaultFont	Specify the default CATIA 4 native font to use if a font is not found.	
CATIAFILTERNONROOT = <0 1>	Set to 0 to display non-root entities for CATIA 4 3D.	1
CATIAFILTERNOSHOWS = <0 1>	Set to 0 to display no-show entities for CATIA 4 3D.	1

Parameter	Description	Default
CATIAIgnoreProjectionLayer = <0 1>	When set to 1 supports projected view visibility through draft view layer settings for CATIA 4 drawings.	0
CATIAProjectFilePath = <file path>	Specify the directory path for the location of project files. If the option is set, it will override the existing INI option CATIAProjectFile. Otherwise if the option is not set or project file(s) cannot be found in the specified directory, the old option (CATIAProjectFile) will be used.	empty

Note: Mapping for CATIA 4 fonts is specified in file CATIAv4.fontmap located in the <install directory>\avwin\fonts. This font map is used to map font name to corresponding font resources so that text strings will be displayed properly with correct characters. A requirement for this font map to work properly is the existence of the CATIA 4 project file.

CATIA 5 Options

Configure options for CATIA 5 files.

[Options]

Parameter	Description	Default
Catia5ShowPMI = <0 1>	Set to 0 to hide PMI entities from display. Set to 1 to display PMI entities.	1
Catia5ShowPMIWithMesh = <0 1>	Specify if you wish to display PMI entities in mesh mode. Catia5ShowPMI should be set to 1 for this option to take effect.	1

Parameter	Description	Default
Catia5BuildInvisibleCGMBodies = <0 1>	Set to 1 if you wish to process and display invisible BREP bodies.	0
CATIA5BuildCGMSETS = <0 1>	Controls the display of Geometrical sets. Set to 1 to show geometrical sets structure in the Model Tree.	1

CGM Options

Configure options for CGM files.

[Options]

Parameter	Description	Default
CGMNOCLIP = <0 1>	Set to 0 to enable clipping. Some files may display as empty when the value is 0. Set to 1 to disable clipping and display the file.	0
SHOWBACKGROUND = <0 1>	If 1 , the background of CGM files is displayed with color. Set option to 0 if you have problems printing CGM files that contain large black or dark backgrounds.	0

Excel Options

Configure options for Excel files.

[Options]

Parameter	Description	Default
DOCVIEW = <0 1>	If 1 , displays an Excel file in print preview mode, otherwise, displays as a regular spreadsheet.	0
DOCVIEWSHOWHEADERS = <0 1>	Set to 1 to display headers when the INI option DOCVIEW = 1 .	0
SSHIDESCROLLBARS = <0 1>	Set to 1 to disable scroll bars for spreadsheet files. Option will work for Excel, Archives and MS Access formats.	0

Gerber Options

Configure options for Gerber files.

[Gerber Format]

Parameter	Description	Default
APERTURE_FORMAT_FILEPATH= <i>file path</i>	Defines the file path for the aperture format file.	
INCREMENTALMODE = <0 1>	Enter 1 if data is in incremental mode.	0
NUMDECIMALS = <i>num</i>	Enter the number of decimals. Specify a value between 1 and 6.	3
NUMDIGITS = <i>num</i>	Enter the number of digits. Specify a value between 1 and 6.	2

Parameter	Description	Default
TOOLFILEPATH = C:\temp\ default.too	Specifies the path to the aperture list file.	<install directory>\avwin\default.too
TOOLFILETYPE = <0 1 2 3 4 5 6 7>	Specifies the type of aperture list file. 0 = CSI 1 = Orcad 2 = ECAM 3 = Protel 4 = Artwork 5 = Allegro 6 = Visula 7 = Autotrax	0
TRAILINGZEROS = <0 1>	Enter 1 if coordinate data is in trailing zeros format.	0
UNITS = <1 2>	Specifies the unit: 1 is for inches; 2 is for mm.	1
TOOL_UNIT	Specify the unit for the tool and aperture file if unit is different from the Gerber file. -1 = Unspecified file unit. Aperture file will adopt the same unit as the Gerber file. 1 = inches 2 = millimeters 12 = mils	-1

HPGL/HPGL2 Options

Configure options for HPGL/HPGL2 files.

[Options]

Parameter	Description	Default
CODEPAGE = <i>num</i>	<p>Forces text display of a specific language. Specify the codepage to use for hpgl files.</p> <p>For example, set CODEPAGE = 932 to display Japanese text in HPGL files.</p> <p>For a full lists of value, refer to the following Web sites: http://www.microsoft.com/globaldev/reference/cphome.msp http://en.wikipedia.org/wiki/Code_page</p>	
HPBACKGROUND = <0 1>	<p>0 = Do not draw page background</p> <p>1 = draw page (applies to HPGL/HPGL2 files)</p>	0
HPGLCOLORTBL = <i>path/hpglcol.tbl</i>	<p>Specifies the path and filename of the color table file for HPGL/HPGL2 files.</p> <p>The color table file specifies the mapping between a pen number and a color.</p> <p>Note: This option is used only if the file does not explicitly specify pen colors with the HPGL PC command.</p>	The file Hpglcol.tbl in the program directory (avwin).

IFC Options

Configure options for IFC 3D files.

[Options]

Parameter	Description	Default										
IFCColors	<p>Specify group element colors for IFC files.</p> <p>Syntax: [Options] IFCCOL- ORS=GROUP_ELEMENT_NAME(r,g,b) or IFCCOL- ORS=GROUP_ELEMENT_NAME(color_name) where GROUP_ELEMENT_NAME is the name of the group element. For example DOORS, WINDOWS, WALLS</p> <p>(r,g,b) is the RGB value for the color color_name is the string representing the color</p> <p>All color definitions should be on the same line and should be separated by spaces. For example: IFCCOLORS = WALLS(WHITE) DOORS(GREEN) WINDOWS(BROWN)</p> <p>Special element name OTHERS is used for all elements that are not in the color definition.</p> <p>Special color NONE is used when you want to use the 3d default element color for a group element.</p> <p>IFC pre-defined color extension is defined as below:</p> <table border="0"> <tr> <td>Color Name</td> <td>(R,G,B)</td> </tr> <tr> <td>LIGHTCYAN</td> <td>(188,255,255)</td> </tr> <tr> <td>BROWN</td> <td>(205,91,69)</td> </tr> <tr> <td>LIGHTYELLOW</td> <td>(255,219,153)</td> </tr> <tr> <td>CADETBLUE</td> <td>(122,197,205)</td> </tr> </table>	Color Name	(R,G,B)	LIGHTCYAN	(188,255,255)	BROWN	(205,91,69)	LIGHTYELLOW	(255,219,153)	CADETBLUE	(122,197,205)	<p>IFCCOLORS= WALLSTAN- DARD- CASES(255,255,255) CURTAIN- WALLS(255,255,255) DOORS(255,219,153) OTH- ERS(0,255,255) SLABS(205,91,69) WALLS(255,255,255) WIN- DOWS(122,197,205)</p>
Color Name	(R,G,B)											
LIGHTCYAN	(188,255,255)											
BROWN	(205,91,69)											
LIGHTYELLOW	(255,219,153)											
CADETBLUE	(122,197,205)											

Parameter	Description	Default
IFCColors_Mode =<0 1 2 3>	Specify the mode of using default element colors. Set to 0 to turn off default element colors. Set to 1 to use default colors. File-defined colors are ignored. Set to 2 to use default colors for elements without file-defined colors. Set to 3 to use default colors for elements without file-defined colors, and to replace elements defined as black.	3
IFCREADProp- erties=<0 1>	Enable or disable loading of attributes for IFC files. Set to 1 to display all supported entity properties for an IFC file. Set to 0 to display only the default entity properties which are Display Mode, Name and Visibility.	1
IFCLoadInvisi- bleSpaces	Enable or disable loading of internal spaces boundary geometry. Set to 1 to enable loading of internal spaces boundary geometry. Set to 0 to disable loading of internal spaces boundary geometry.	1
IFCWINDOW_T RANSPARENCY	Specify the transparency level for windows in IFC files. Value is an integer between 0 (no transparency) and 100 (full transparency).	55

IGES Options

Configure options for IGES files.

[Options]

Parameter	Description	Default
IGESLoadDraftFirst = <0 1>	Set to 1 to display the 2D page first, display of the 3D page as a 2D projection of the 3D model, in IGES files.	0
IGESLoadSubFigureDefinitions = <0 1>	Set to 1 to display sub-figure definitions when sub-figure instances are not found. Option is for IGES 3D files.	0

JPEG Options

Configure options for JPEG files.

Parameter	Description	Default
JPGQUANTIZE = <0 1>	If 1 , JPEG images are quantized to 256 colors for quicker display. If 0 , true colors are used.	1

JPEG 2000 Options

Configure options for JPEG 2000 files.

[Options]

Parameter	Description	Default
J2KRESOLUTION= [DYNAMIC HIGH MEDIUM LOW +num -num]	<p>Set to HIGH to display with a high resolution. This could cause a decrease in performance. Other values: LOW, MEDIUM, and DYNAMIC.</p> <p>You can also set J2KRESOLUTION values to +num or -num, where num is a number between 1 and 100.</p> <p>Setting the value to +num gives the same result as DYNAMIC but increases the resolution by a factor of num where num is a value from 1 to 100 (up to the maximum possible resolution of the image). Note that this will decrease performance.</p> <p>Setting to -num gives the same result as DYNAMIC but decreases the resolution by a factor of num where num is a value from 1 to 100 (down to the lowest possible resolution of the image). Note that this will increase performance.</p>	DYNAM IC

ME10/OneSpace Designer Drafting Options

Configure options for ME10/OneSpace Designer Drafting files.

[Options]

Parameter	Description	Default
ME10CONSTRUCTION GEOM = <0 1>	Set to 1 to toggle on construction entities for ME10 files.	1
ME10MULTIBYTE = <0 1>	This option sets the priority for glyph search in Multibyte/Singlebyte fonts. <ul style="list-style-type: none"> Set this option to 0 if the file does not contain any Multibyte fonts (Far Eastern Languages). Set this option to 1 if the file contains a mixture of Singlebyte/Multibyte fonts. 	0
ME10RGBCOLOR = <0 1>	Determine the mode of colors for ME10 files. If 1 , use RGB colors. If 0 , use AIC (AutoVue Indexed Color). Note: When set to 0 , you can customize the file me10col.tbl to get the desired pen settings.	1
ME10SHOWVERTEX = <0 1>	Set to 1 to toggle on vertices for ME10 files.	0

Parameter	Description	Default
MEFONTMAP = <i>fullpath_to_mefont.map</i>	Specifies the full path to the ME10/OneSpace Designer Drafting font map file. This file maps ME10/OneSpace Designer Drafting fonts to the appropriate native ME10/OneSpace Designer Drafting font files or TrueType fonts. To use native ME10/OneSpace Designer Drafting fonts, you need to provide the appropriate font files. This can be done: <ul style="list-style-type: none"> By specifying the path to them using the INI option XFONTPATH. 	The file mefont.map in the program directory. (avwin)

Microsoft Outlook Options

Configure options for Microsoft Outlook MSG files.

[Options]

Parameter	Description	Default
OUTLOOKLINKFLAG	Enable or disable hyperlinks or attachments in Outlook MSG files. 0 – Hyperlink on, Attachment on 1 – Hyperlink on, Attachment off 2 – Hyperlink off, Attachment on 3 – Hyperlink off, Attachment off	0
DownloadWebResources	Enable or Disable download of images and other web images when viewing Outlook MSG files.	1

MicroStation DGN7/DGN8 Options

Configure options for MicroStation DGN7/DGN8 files.

[AVPrintOptions]

Parameter	Description	Default
ThicknessScale = <i>thickness1</i> , <i>thickness2</i> , ..., <i>thicknessN</i>	Specify the mapping of MicroStation line weights to line thickness on paper. You can get this from the MicroStation config file, attribute <code>weight_strokes</code> . Example: ThicknessScale = 0.250, 0.375, 0.500, 0.625, 0.750, 0.875, 1.000, 1.125, 1.250, 1.375, 1.500, 1.625, 1.750, 1.875, 2.000, 2.125, 2.250, 2.375, 2.500, 2.625, 2.750, 2.875, 3.000, 3.125, 3.250, 3.375, 3.500, 3.625, 3.750, 3.875, 4.000, 4.125	

[Options]

Parameter	Description	Default
DGN_FAST3D	Set to 1 to improve rendering speed of MicroStation 8 files. Note: Setting this option to 1 means that layers will not be listed and AutoVue streams all meshes & extrusions in one body. Set to 0 will mean slower rendering of MicroStation 8 files. However, layer information is listed and each mesh is streamed in its own entity.	1

Parameter	Description	Default
DGN8LSTYLERSC = <i>fullpath_</i> <i>to_style.rsc</i>	Specify the full path to a MicroStation linestyle resource file that will be used to render linestyles and multi-line patterns.	
DGN8LWDISPLAYSCALE = [0.0-1000.0]	Specify a floating point value, larger or equal to 0.0, representing the scaling factor which would be applied to all line-weights in the drawing. For example: Set to 0.0 : Reduces all line-weights to 0 (1 pixel width). Set to 1.0 : Lineweights remain at their default value. Set to 0.5 : Reduces all line-weights by half. Set to 2.0 : Multiplies all line-weights by 2.	1.0

Parameter	Description	Default
DGN8XREFUNITS	<p>Option applies to MicroStation version 8 files with AutoCAD XREFs.</p> <p>Specify the unit to use for AutoCAD XREFs when units information for the XREFs is not stored in the MicroStation drawing. The unit specified should be the same as the unit for the DWG specified in MicroStation. Consult the MicroStation help for a complete list of units. If the unit is not specified or an invalid value is specified, AutoVue reads the units from the AutoCAD XREF and hence, XREFs may not be scaled properly.</p> <p>Example: DGN8XREFUNITS = meters</p>	
DGNARABICFONTS = <0 1>	<p>Support for Arabic fonts for MicroStation.</p> <p>Set to 1 to specify right-to-left drawing.</p>	
DGNCOLORTBL = <i>fullpath_to_color.tbl</i>	<p>Option applies to MicroStation 7 files.</p> <p>Redirects the full path to a MicroStation DGN color table file. This option is used only if the MicroStation file does not have a color-table element in it. If a color-table element exists in the file, it will supersede this option.</p>	

Parameter	Description	Default
DGNDEACTIVATELEV SYMB = <0 1>	Applies to MicroStation 7 and 8 files. When MicroStation's Settings\View settings\Level Symbology flag is set, all graphic entities are displayed using the level (the one the entity belongs to) settings for color, line style, and line width (the entity's symbology). This option was implemented to overwrite the Settings\View settings\Level Symbology flag and display a file using the individual entity's symbology.	0
DGNFONTMAP = <i>fullpath_todgnfont.map</i>	Specify the full path to a MicroStation DGN font to TrueType mapping file. Note that native MicroStation fonts are supported and that this option is used only when the native fonts are unavailable. Note: Applies only to MicroStation 7.	The file dgnfont.map in the program directory.
DGNFONTRSC = <i>fullpath_to_font.rsc;full2. . .</i>	Specify a semi-colon separated list of the full paths to fonts for the MicroStation font RSC files.	
DGNIRASB = <0 1>	If 0 , MicroStation raster hybrid files follow the I/RAS B conventions for raster extents. Use this option if you find that the raster components of MicroStation files appear stretched.	0

Parameter	Description	Default
DGNLSTYLERSC = <i>fullpath</i> _to_style.rsc	Specify the full path to a MicroStation linestyle resource file that will be used to render linestyles and multi-line patterns. Note: Option applies to MicroStation 7 files.	
DGNREFCYCLECHECK = <0 1>	Option applies to MicroStation 8 files and corresponds to MicroStation v8.5 environment variable MS_REF_CYCLECHECK. When set to 1 , the decoder will check for circular references in reference paths. Circular references will not be displayed, except for the case where a given model references itself. When set to 0 , all references will be displayed, as long as nesting depth permits.	1
SHOWZEROLENGTHLINES = <0 1>	Option applies to MicroStation 7 files. If 1 , the MicroStation points (zero length lines) are displayed, otherwise, the points are hidden.	0

NC-Drill Options

Configure options for NC-Drill files.

[ECAD]

Parameter	Description	Default
NCD_UNITS	Option applies to NC-Drill format. Specify units for NC-Drill files. 1 = inches 2 = millimeters	1
NCD_TRAILINGZEROSOMITTED	Option applies to NC-Drill format. 0 = Coordinate data is trailing zero omitted 1 = Coordinate data is leading zero omitted 2 = Coordinate data is all digits present 3 = Coordinate data is explicit decimal point	0
NCD_COMMENTSYMBOL	Option applies to NC-Drill format. Specify the comment symbol.	;
NCD_INCREMENTALMODE	Option applies to NC-Drill format. Set to 1 if data is in incremental mode. 0 = absolute mode 1 = incremental mode	0
NCD_NUMDIGITS	Option applies to NC-Drill format. Specify the number of digits. Specify a value between 0 and 6. Changing this value will affect the x, y coordinate.	2
NCD_NUMDECIMALS	Option applies to NC-Drill format. Specify the number of decimals. Specify a value between 0 and 6. Note: Changing this value will affect the x, y coordinate.	4

Parameter	Description	Default
NCD_APERTURE_FORMAT_FILEPATH	Option applies to NC-Drill format. Complete path for Aperture format file. This file provides information on how to read the tool file	
NCD_TOOLFILEPATH	Complete path for Tool file.	

OrCAD Layout Options

Configure options for OrCAD Layout files.

[ECAD]

Parameter	Description	Default
ORCAD_CUTOOUT_COPPER_POUR = <0 1>	Set to 1 if you wish to display copper pour cutouts for OrCAD Layout files	0

Pro/ENGINEER Options

Configure options for Pro/ENGINEER files.

[Options]

Parameter	Description	Default
ProE2DLoadSavedDisplayLists = <0 1>	<p>If set to 1, the display list will be loaded instead of generating the 2D drawing from the 3D Model.</p> <p>If the display list does not exist, the 2D drawing will be generated from the 3D Model.</p> <p>Note: Option applies to Pro/ENGINEER 2D files.</p>	1

Parameter	Description	Default
ProE2DLoadPicture = <0 1>	Set to 1 to load the preview data for Pro/ENGINEER 2D Drawings. If preview does not exist, the 2D drawing will be generated from the 3D Model.	0
ProELang	Specify the native font to use for Pro/ENGINEER 2D drawings. Possible values are: Korean/Japanese/ Chinese_cn/Chinese_tw/ Hebrew/Russian Example: ProELang = Chinese_cn Font files to use should be defined in the proefont.map file located in the avwin\font subdirectory in the AutoVue installation directory. Refer to proefont.map for more instructions regarding font mapping.	
ProELoadCosmetics = <0 1>	Set to 0 to turn off display of datum cosmetics (coordinate system, datum planes and datum axes and datum points).	1
ProELoadCosmeticWires=<0 1>	Set to 0 to turn off display of cosmetic wires.	1
ProELoadPMIData = <0 1>	Set to 0 to disable display of PMI entities.	1

Parameter	Description	Default
ProEMassPropUseMesh = <0 1>	Set to 1 to compute mass properties (volume, surface area, mass,...) using the mesh model. Default 0 , compute mass properties using the BRep model.	0
ProEPMIDIMTOLDisplay = <0/1>	Set to 1 to display tolerance for dimension entities for Pro/ENGINEER 3D files.	1
ProEShowHiddenLineDashed = <0 1>	This option controls the display and printing of hidden lines contained in Pro/ENGINEER drawings. Set to 1 to display and print hidden lines as dashed lines. Set to 0 to display and print hidden lines as solid lines.	0
ProE2DTanEdgeDefaultStyle = [0-4]	Specify the default line style for tangent edges if it is not saved in the native file. The possible styles are: 0 - Solid [Default] 1 - Disabled 2 - Control 3 - Phantom 4 - Dimmed	0
ProE2DViewDefaultStyle = [HIDDEN WIREFRAME SHADING NO HIDDEN]	Specify a default style to display 3D projected views: <ul style="list-style-type: none"> • HIDDEN • WIREFRAME • SHADING • NO HIDDEN (default) 	NO HIDDEN

SolidWorks Options

Configure options for SolidWorks files.

[Options]

Parameter	Description	Default
SWWIRECOLORVISIBLE	Specify color to use for drawing solidworks wireframe models for Solidworks drawings. Value should be an integer value specifying the RGB color.	0 (Black)

STEP Options

Configure options for STEP files.

[Options]

Parameter	Description	Default
STEPDetailedTree = 0/1	Set to 1 to show detailed tree for STEP files.	0
STEPFacePositiveColor	<p>Option applies to STEP files.</p> <p>When set to 1, AutoVue uses either the color for “.BOTH” sides of the face if it is set or the color of the “positive” face side if it is set.</p> <p>When set to 0, AutoVue uses either the color for “.BOTH” sides of the face if it is set or selects the “positive” or “negative” face side color depending on the face sense.</p> <p>Syntax: [Options] STEPFacePositiveColor=<0/1></p>	0
STEPHideCG	<p>Set to 1 to hide all construction geometry in the STEP file.</p> <p>Syntax: [Options] STEPHideCG=<0/1></p>	0

Text Options

Configure options for text files.

[Options]

Parameter	Description	Default
CODEPAGE = <i>num</i>	<p>Forces text display of a specific language. Specify the codepage to use for TXT files. For example, set CODEPAGE = 932 to display Japanese text in TXT files.</p> <p>For a full lists of value, refer to the following Web sites:</p> <p>http://www.microsoft.com/globaldev/reference/cphome.msp</p> <p>http://en.wikipedia.org/wiki/Code_page</p>	

TIFF Options

Configure options for TIFF files.

[Options]

Parameter	Description	Default
TIFF_ZERO_PIXEL = [BLACK WHITE FILE]	<p>Specify how pixel values are interpreted in black and white TIFF files.</p> <p>Set to BLACK to force zero pixels to display black.</p> <p>Set to WHITE to force zero pixels to display white.</p> <p>Set to FILE to force zero pixels to display as the pixel color specified in the file.</p> <p>Note: This only applies to black and white TIFF images.</p>	FILE

Visio Options

Configure options for Visio files.

[Options]

Parameter	Description	Default
VISIODRAWINGPAGE = <0 1>	Specify if you want to display Visio files in drawing mode or in print mode. Set to 1 to display in print mode.	0
VISIOPAGE = <0 1>	Displays the page outline and background. 0 = Off 1 = On	0
VISIOPAGEBKCOLOR= <i>num</i>	Specify an integer that represents an RGB color (Red + 256 * Green + 65536*Blue). The values for Red, Green, and Blue range from 0 to 255. If set to -1 , there will be no background. Only the outline will be displayed if VISIOPAGE is on (=1).	-1

Word Options

Configure options for Microsoft Word files.

Parameter	Description	Default
CustomDocFontSubstitution	Specify the path of the font mapping file (docfont.map) to use for word documents. Syntax: [Options] CustomDocFontSubstitution=<path> The docfont.map contains font mapping information that identifies what font to use if a font is missing. If you wish to modify font mappings, update docfont.map	docfont.map in avwin\fonts

DOC_SHOWTABLEGRIDLINES = <0 1>	Turn table grid lines on and off. 0 Set to 1 to display table grid lines. Set to 0 to hide table grid lines. Unlike cell borders, gridlines never print.	0
-----------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---

General Options

Configure a variety of general options that apply to parameters such as fonts, performance, color, and a whole lot more.

[Options]

Parameter	Description	Default
2DSELECTION_DIMLEVEL = [0.0 - 1.0]	Specify the dim level. The value corresponds to a percentage. For example 0.3 is 30%. Change takes effect whether you change it manually or through the GUI.	0.5
3DMASSPROP_MESH_BEHAVIOR = [0 1 2]	Specify how to handle mesh when computing mass properties. This option can have of the following values: 0 – Exclude from mass property computation. 1 – Include in mass property computation. 2 – Handle selection: Include in mass property computation only if the selection is made fully with mesh bodies.	1

Parameter	Description	Default
3DMASSPROP_SHEET_BEHAVIOR = [0 1 2]	Specify how to handle sheet when computing mass properties. This option can have of the following values: 0 – Exclude from mass property computation. 1 – Include in mass property computation. 2 – Handle selection: Include in mass property computation only if the selection is made fully with sheet bodies.	2
AntiAlias = <0 1>	If 1 , enhances display of monochrome raster images.	1
ArcResolution = <i>num</i>	Indicates the degree increment used in rendering arcs.	10
Contrast = value	Applies contrast to monochrome raster images. The value can range from -0 (low contrast) to 100 (high contrast).	0
CustomFileFilter	Specifies a custom file filter for opening files with AutoVue.	*.*
DecimalDigits	Specify the number of decimals to display when measuring in AutoVue.	4

Parameter	Description	Default
DefaultDocPageSize	<p>Specify the page size in inches that AutoVue should use in order to properly display text files.</p> <p>Example: DefaultDocPageSize = 11.0,8.5 will force AutoVue to display text files at a page size of 11x8.5 inches.</p> <p>Note: This option is only for Text files and Microsoft Outlook Messenger files.</p>	
DefaultFileUnits	<p>Specify the unit to use if native file does not contain units information.</p> <p>Syntax: [Options] DEFAULTFILEUNITS=<1/2/4/5/7/8/9/10/11/12/13/14/15> where</p> <ul style="list-style-type: none"> 1 - inches 2 - millimeters 4 - twips 5 - centimeters 7 - meters 8 - kilometers 9 - feet 10 - yards 11 - miles 12 - mils 13 - miles/10 14 - microns 15 - microinches 	1

Parameter	Description	Default
DefaultUnits	Specify default unit for AutoVue. 1 - inches 2 - millimeters 5 - centimeters 7 - meters 8 - kilometers 9 - feet 10 - yards 11 - miles 12 - mils 14 - microns 15 - microinches	1
FASTDISPLAY = <0 1>	In 2D files, AutoVue renders the drawing, ignoring some details in order to speedup the rendering. If set to 0 , AutoVue performs a full rendering without any optimization of the drawing of the primitives. If set to 1 , AutoVue performs the following optimizations during the rendering of the files: <ul style="list-style-type: none"> • Draw small text as boxes. • Ignore the line-style for small primitives and draw them with plain style. • Ignore the point style for points and draw them in dot style. 	0

Parameter	Description	Default
FixPrinting=<0 1>	<p>This option allows 3D overlays to be rendered on transparent DIBs when printing. This INI option affects 2D files containing 3D overlays and all 3D files.</p> <p>When set to 1, print preview and printing results are exactly matched to the display. However there will be a decrease in print performance.</p> <p>When set to 0, some overlay parts may not appear in the print results, but will provide better print performance.</p>	0
FLIP = <0 1 2 3>	<p>Specifies the flipping direction:</p> <p>0 = none 1 = horizontal 2 = vertical 3 = both</p>	0
FORCETOBLACK = <0 1>	<p>Set to 1 to force all colors to black when displaying vector documents.</p>	0

Parameter	Description	Default
FullColorPrinterSupport = <0 1>	<p>Enable color printing for some monochrome images.</p> <p>Set to 0: Default AutoVue behavior; where some transparent monochrome images are not printed in color due to some printers that do not fully support transparency.</p> <p>Set to 1: Enables certain monochrome images to be printed in color with color printers. This flag should not be set by default because it has some drawbacks and may cause some problems on some printers.</p> <p>Enabling option 1 could cause a decrease in performance:</p> <ul style="list-style-type: none"> • The spool size is much larger because there is 8 to 24 times more information sent to the printer. • Not all printers fully support image transparency and using them with this option may yield incorrect results. 	0
GpsOutText = <0 1>	<p>Set to 1: When you run out-text.exe, it only reports the first level of Xrefs in the hierarchy with the fully resolved/qualified path to the Xrefs.</p> <p>Set to 0: When you run out-text.exe, all Xref instances are reported and the path to the Xrefs is not fully qualified.</p>	0

Parameter	Description	Default
GUILOOK	<p>Option supports different look and schemes for the AutoVue GUI (toolbars, menus, buttons and icons). Restart AutoVue to implement changes.</p> <p>Syntax: [Options] GUILOOK=<2000/2003/2005/XP></p> <p>For example, when GUILOOK=2000, the look and feel of AutoVue matches the Windows 2000 theme.</p>	2005
INVERT = <0 1>	<p>Set to 1 to display monochrome raster images display inverted.</p>	0
KEEPPORIGINALCOLORS = <0 1>	<p>Set to 1 to preserve the original graphic colors, regardless of the background color.</p> <p>Set to 0 to change the color of graphics to black or white when the original color of the graphics are the same as the background color.</p> <p>Either white or black is chosen depending on which is more visible against the background. For example, yellow graphics on a yellow background change to black, or dark-blue graphics on a dark-blue background change to white.</p>	
NEWCHILD = <0 1>	<p>This option is only used for integrations.</p> <p>If 1, new files are opened in their own window when AutoVue has been launched via the command line with a specified filename. Otherwise, the current window is replaced.</p>	0

Parameter	Description	Default
NOACCELERATION = <0 1>	Set to 1 to disable OpenGL acceleration. We recommend setting this option to 1 in the following cases: <ul style="list-style-type: none"> If 3D files display blank, vector files do not display properly, or if markup entities are not completely visible. If you have a poor graphics card. OpenGL acceleration could slow down performance for big 3D models. 	0
NOLOGO = <0 1>	If 1 , the initial splash screen is not displayed.	0
NOSYMBOLTTF = <0 1>	Set to 1 to override the Charset of Symbol fonts. It will be replaced by the default Charset. This option applies to DWF and DWG files only.	0
NOWINARCS = <0 1>	Set to 1 : AutoVue does not use the Windows GDI functions to draw arcs. Set to 0 : Windows renders the arcs. This option is used for some HP print drivers that do not properly render arcs and circles.	0
OVERLAY_ROTATE_FLIP = <0 1>	Set to 1 to automatically rotate/flip overlay files when overlaying files with AutoVue.	0
RASTERFIT = <0 1>	If 1 , fits the initial display of raster images to the screen. Otherwise, full resolution is shown.	1

Parameter	Description	Default
RASTERMEMLIMIT = <i>n_kbytes</i>	Swaps raster data to disk when the Windows global memory heap falls below <i>n_kbytes</i> .	6000
RASNOFORCETOBLACK = <0 1>	Set to 1 to disable Force to Black for raster overlays and for raster files. Option is applicable only when FORCETOBLACK = 1 .	0
ResetRotateAndFlip=<0 1>	This option allows the user to choose rotation and flip settings when viewing files. Syntax: [Options] ResetRotateAndFlip=<0/1> 1 - render file with no rotation and no flipping. If native file itself is rotated or flipped, native file settings take precedence and file is rendered with saved rotation/flip. 0 - render file with the rotation and flip settings defined in AutoVue GUI or in AutoVue INI file.	1
ResLocateDLL	Set this to the name of the custom resource resolution DLL with which you have defined your own localization callback. Syntax: [Options] ResLocateDLL= ExampleDLL.dll	empty
ROTATE = < <i>degrees</i> >	Specifies the degrees of rotation as 0, 90, 180 or 270.	0
SHOWDIMENSION = <0 1>	If 1 , shows dimension entities. Otherwise, they are not shown.	1

Parameter	Description	Default
SHOWFILL = <0 1>	If 0 , displays only the outlines of filled entities (solids, fat polylines etc.). Otherwise, these entities are shown as filled.	1
SHOWHATCHING = <0 1>	If 1 , the FILLMODE system variable (AutoCad) and the Hatch display are turned off, otherwise, Hatch entities are displayed.	0
SHOWLINESSTYLE = <0 1>	If 1 , shows linestyle patterns If 0 , linestyles are displayed as solid lines.	1
SHOWLINEWEIGHT	If 1 , displays varying line thicknesses. If 0 , displays no line weights for any lines (all lines appear equal).	1
SHOWTEXT = <0 1>	If 1 , text entities are shown.	1
SHOWTREE	If 1 , tree is displayed.	1
SHOWXREFS = <0 1>	If 1 , external reference files are shown.	1
STARTINDIR	If 1 , File Open dialog always defaults to the directory specified in the "start in" option of the AutoVue shortcut. If 0 , sets File Open dialog to the last open path.	0

Parameter	Description	Default
TextBitmapRendering=<0 1>	If set to 1 , render small text glyphs using bitmaps. If set to 0 , text is not rendered using bitmaps. Note: This option may affect most text in PDF, TrueType text in ME10, and PostScript text in CATIA5.	1
TILEMODE = <-1 0 1>	Specifies: 1 - model space 0 - paper space -1 - automatic	-1
TRA_NAME	Specify the name of the translation file to use. AutoVue UI will be launched in specified language. Example: TRA_NAME = fr.tra If fr.tra contains French resource files, AutoVue UI will startup in French.	
VECTORFIT = <0 1>	If 1 , causes Vector files to be "Auto-Fit" once they are loaded.	0
VECTORMEMLIMIT = <i>n_kbytes</i>	Swaps vector data to disk when the Windows global memory heap falls below <i>n_kbytes</i> .	4096
VECTORWINDOWSMETA = <0 1>	If 1 , uses Windows metafiles to store vector display lists, otherwise uses a custom high-performance display list.	0
XFONTPATHS = <i>paths</i>	Specifies a semicolon-delimited list of directories to search for external fonts.	

Parameter	Description	Default
XREFPATHS = <i>paths</i>	Specifies a semicolon-delimited list of directories to search for external references in CAD drawings.	

Base Font Options

The parameters in the following table only apply to text files.

[BaseFont]

Parameter	Description	Default
Face	Specifies the font name.	Arial
Size	Specifies the font size.	10
Weight	Specifies the font weight.	400 (Normal)
IsStrikeOut	If 1 , the text entity has a strikethrough.	0
IsUnderline	If 1 , the text entity is underlined.	0
IsItalic	If 1 , the text entity is italicized.	0

UI Color Options

Configure options to specify background color for different file formats.

Note: For each color option, specify an integer that represents an RGB color (Red + 256 * Green + 65536*Blue). The values for Red, Green, and Blue range from 0 to 255.

[UI Colors]

Parameter	Description	Default
BKCOLORARCHIVE	Specify background color for archive files.	
BKCOLORCOLORRASTER	Specify background color for raster formats.	
BKCOLORDATABASE	Specify background color for database files.	
BKCOLORDOCUMENT	Specify background color for PDF formats.	
BKCOLOREDA	Specify background color for EDA files.	0
BKCOLORMONORASTER	Specify background color for mono-chrome raster formats.	
BKCOLORSPREADSHEET	Specify background color for spreadsheets.	
BKCOLORTHUMBNAILS	Specify background color for thumbnails.	
BKCOLORVECTOR	Specify background color for vector formats.	

AutoVue Mobile Options

Configure the parameters for AutoVue Mobile.

[AutoVueMobile]

Parameter	Description	Default
FileStreamEncryption=[RC4 3DES]	Specify Encryption algorithm for both Markup and Mobile Pack password protection. Syntax: [AutoVueMobile] FileStreamEncryption=<RC4/3DES>	RC4

3D Options

The parameters in the following table apply to 3D files.

[Options]

Parameter	Description	Default
3DPerformancePreference=<0 1>	<p>This option orients the optimization in the product towards speed or memory.</p> <p>If set to 1, the optimization is assigned to the speed performance.</p> <p>If set to 0, the optimization is assigned to memory usage.</p> <p>This option impacts only the loading process of EDA-3D and CATIA 4, CATIA 5, Pro/ENGINEER, Autodesk Inventor, Solid-Designer, Mechanica Desktop, ACIS, IGES and STEP 3D models.</p>	1
AxesSize = <i>value</i>	<p>Enables you to resize the 3D axes.</p> <p>Example:</p> <p>If you set AxesSize=0 the default 3D axes will display. If you assign a value greater than 0, the size of the 3D axes will change accordingly.</p> <p>Suggested value=45.</p>	90

Parameter	Description	Default
BkImages	<p>Displays a list of images in the 3D background. Can include a semi-colon separated list of images.</p> <p>Syntax: BkImages=path1, position1, stretch1; path2, position2, stretch2; ...</p> <p>Path values: May be absolute and relative to the start directory of the application or module directory.</p> <p>Position values: CENTER, TOP, BOTTOM, LEFT, RIGHT, TOP_LEFT, TOP_RIGHT, BOTTOM_LEFT, or BOTTOM_RIGHT.</p> <p>Stretch Values: NONE (no stretching), FILL (fills the screen and does not respect image ratio), UNIFORM (displays full image and respects image ratio), and UNIFORM_TO_FILL (fill the screen and respects image ratio).</p>	
BkType	<p>Specifies the type of 3D background. Three classes of values: <i>radial gradient</i>, <i>directional gradient</i>, and <i>plain color</i> (default value).</p> <p>Radial gradient values: CENTER, TOP, BOTTOM, LEFT, RIGHT, TOP_LEFT, TOP_RIGHT, BOTTOM_LEFT, or BOTTOM_RIGHT.</p> <p>Directional gradient values: An integer value (angle in degrees). Note that 0 is in the “3 o’clock” direction and that the angles rotate CCW.</p>	PLAIN

Parameter	Description	Default
DISPLAYMODE	Specify the default display mode. Display mode values: 1 - Shaded 2 - Wire Polygons 4 - Wireframe 8 - Hidden Line 16 - Silhouette 32 - Shade Wire	1
DYNAMICDISPLAY	Specify render mode for dynamic display.	0
FastPMIRendering=<0 1>	This option affects the rendering of PMI Text. If set to 1 , the rendering time of the PMI Text is decreased. The quality of the small text will be degraded somewhat since it is rendered just as box or line made on the contour of the text. As a result, performance is improved. If set to 0 , the rendering time remains the same.	1
ForcePMIsZOrder = <0 1>	Invalidate the PMI_ATTRIB_RENDERABOV EMODEL generic attribute effect: 3D PMIs are not forced above the model and may be occluded by it, depending on its orientation.	0
LOADFACETEDDATA = <0 1>	Set to 1 if you wish to read Mesh data for 3D files. Set to 0 if you wish to read BRep data for 3D files.	1

Parameter	Description	Default
MESHBUILDTOPOLOGY = <0 1>	<p>Set to 0 if you do not want to build the topology in mesh mode. Applies to the following file formats:</p> <ul style="list-style-type: none"> • Catia 5 • ProEngineer • SolidWorks • Unigraphics • STL • IFC <p>Note: This option replaces the following INI options: SWBUILDMESHTOPOLOGY, Catia5MeshBuildTopology and BUILDMESHTOPOLOGY.</p> <p>Note: This options affects Microstation 8 files.</p>	1
MESHRESOLUTIONDEFAULT = <0 1 2>	<p>Configure default mesh resolution for 3D files:</p> <ul style="list-style-type: none"> 0 - Medium 1 - Low 2 - High 	0
SMOOTHSHADING = <0 1>	If 1 , smooth shading is turned on.	1
PERSPECTIVE = <0 1>	If 1 , enables the Perspective view.	0
PMITEXTRENDERINGSTYLE = <0 1 2>	<p>Specify the text rendering style for PMI entities.</p> <ul style="list-style-type: none"> 0 - Native Setting 1 - 3D 2 - Flat-to-screen 	0
SHOWAXES = <0 1>	If 1 , shows Global Axes.	1

3D Color Options

Configure options to specify color for 3D files.

Note: For each color option, specify an integer that represents an RGB color (Red + 256 * Green + 65536*Blue). The values for Red, Green, and Blue range from **0** to **255**.

[Options]

Parameter	Description	Default
BACKGROUNDCOLOR	Specify color for background.	
ENTITYDEFAULTCOLOR	Specify default color for 3D models.	
HIGHLIGHTCOLOR	Specify color for highlighting.	
DISTANCECOLOR	Specify color for distance measurement.	
EDGECOLOR	Specify color for highlighting edges.	
FACESCOLOR	Specify color for highlighting faces.	
VERTICESCOLOR	Specify color for highlighting vertices.	
SECTIONEDGECOLOR	Specify section edge color.	
MINDISTFIRSTSETCOLOR	Specify color for first set in minimum distance measurement.	
MINDISTSECONDSETCOLOR	Specify color for second set in minimum distance measurement.	

3D Measurement Units

[3D Measurement Units]

Parameter	Description	Default
DisplayMassUnits	Specify display units for mass. Mass units values: 0 - Gram (g.) 1 - Kilogram (kg.) 2 - Milligram (mg.) 3 - Pound (lb.) 4 - Ton (US) 5 - Ton (UK - imperial system) 6 - Ounce (oz.) 7 - Slug	0
DisplayLengthUnits	Specify display units for length. Distance units values: 1 - Inch (in.) 2 - Millimeter (mm.) 5 - Centimeter (cm.) 7 - Meter (m.) 8 - Kilometer (km.) 9 - Feet (ft.) 10 - Yard (yd.) 11 - Mile (mi.) 12 - Thousandth of an inch (mil) 14 - Micron 15 - Microinch	1
DensityMassUnits	Specify density mass units.	0 (Grams)
DensityLengthUnits	Specify density length units.	1 (Inches)
Density	Specify density value	1.0
ApplyDefaultDensity ToAllParts	If 1 , density is to be applied to all parts.	0

Parameter	Description	Default
MassPropsAccuracy	integer 2 = high accuracy Possible values: 0 = LOW 1 = MEDIUM 2 = HIGH 3 = VERY HIGH	2
InertiaTensorPosition	If 1 , computes Tensor of Inertia at Center of Gravity. If 0 , computes Tensor of Inertia at Output Coordinate System Origin.	0

3D PMI Options

Configure the following options to control visibility of PMI entities for 3D files.

[Options]

Parameter	Description	Default
PMI_TREE_COORDINATE SYSTEM	Set to 1 to display datum coordinate system entities in the tree. Set to 0 to hide datum coordinate system entities from the tree.	1
PMI_VIEW_COORDINATE SYSTEM	Set to 2 to set the visibility of datum coordinate system entities to the last saved state in the native application. Set to 1 to display datum coordinate system entities. Set to 0 to hide datum coordinate system entities from the display.	2
PMI_TREE_DATUMFEATURE SYMBOL	Set to 1 to display datum feature symbol entities in the tree. Set to 0 to hide datum feature symbol entities from the tree.	1

Parameter	Description	Default
PMI_VIEW_DATUMFEATURE SYMBOL	Set to 2 to set the visibility of datum feature symbol entities to the last saved state in the native application. Set to 1 to display datum feature symbol entities. Set to 0 to hide datum feature symbol entities from the display.	2
PMI_TREE_DATUMTARGET	Set to 1 to display datum target entities in the tree. Set to 0 to hide datum target entities from the tree.	1
PMI_VIEW_DATUMTARGET	Set to 2 to set the visibility of datum target entities to the last saved state in the native application. Set to 1 to display datum target entities. Set to 0 to hide datum target entities from the display.	2
PMI_TREE_DIMENSION	Set to 1 to display dimension entities in the tree. Set to 0 to hide dimension entities from the tree.	1
PMI_VIEW_DIMENSION	Set to 2 to set the visibility of dimension entities to the last saved state in the native application. Set to 1 to display dimension entities. Set to 0 to hide dimension entities from the display.	2
PMI_TREE_FEATURECONTROL FRAME	Set to 1 to display datum feature control frame entities in the tree. Set to 0 to hide datum feature control frame entities from the tree.	1

Parameter	Description	Default
PMI_VIEW_FEATURECONTROL FRAME	Set to 2 to set the visibility of datum feature control frame entities to the last saved state in the native application. Set to 1 to display datum feature control frame entities. Set to 0 to hide datum feature control frame entities from the display.	2
PMI_TREE_LINEWELD	Set to 1 to display lineweld entities in the tree. Set to 0 to hide lineweld entities from the tree.	1
PMI_VIEW_LINEWELD	Set to 2 to set the visibility of lineweld entities to the last saved state in the native application. Set to 1 to display lineweld entities. Set to 0 to hide lineweld entities from the display.	2
PMI_TREE_LOCATOR	Set to 1 to display locator entities in the tree. Set to 0 to hide locator entities from the tree.	1
PMI_VIEW_LOCATOR	Set to 2 to set the visibility of locator entities to the last saved state in the native application. Set to 1 to display locator entities. Set to 0 to hide locator entities from the display.	2
PMI_TREE_MEASUREMENT POINT	Set to 1 to display point measurement entities in the tree. Set to 0 to hide point measurement entities from the tree.	1

Parameter	Description	Default
PMI_VIEW_MEASUREMENT POINT	Set to 2 to set the visibility of point measurement entities to the last saved state in the native application. Set to 1 to display point measurement entities. Set to 0 to hide point measurement entities from the display.	2
PMI_TREE_NOTE	Set to 1 to display note entities in the tree. Set to 0 to hide note entities from the tree.	1
PMI_VIEW_NOTE	Set to 2 to set the visibility of note entities to the last saved state in the native application. Set to 1 to display note entities. Set to 0 to hide note entities from the display.	2
PMI_TREE_REFERENCE GEOMETRY	Set to 1 to display reference geometry entities in the tree. Set to 0 to hide reference geometry entities from the tree.	1
PMI_VIEW_REFERENCE GEOMETRY	Set to 2 to set the visibility of reference geometry entities to the last saved state in the native application. Set to 1 to display reference geometry entities. Set to 0 to hide reference geometry entities from the display.	2
PMI_TREE_SPOTWELD	Set to 1 to display spotweld entities in the tree. Set to 0 to hide spotweld entities from the tree.	

Parameter	Description	Default
PMI_VIEW_SPOTWELD	Set to 2 to set the visibility of spotweld entities to the last saved state in the native application. Set to 1 to display spotweld entities. Set to 0 to hide spotweld entities from the display.	2
PMI_TREE_SURFACEFINISH	Set to 1 to display surface finish entities in the tree. Set to 0 to hide surface finish entities from the tree.	1
PMI_VIEW_SURFACEFINISH	Set to 2 to set the visibility of surface finish entities to the last saved state in the native application. Set to 1 to display surface finish entities. Set to 0 to hide surface finish entities from the display.	2
PMI_TREE_WIRE	Set to 1 to display wire entities in the tree. Set to 0 to hide wire entities from the tree.	1
PMI_VIEW_WIRE	Set to 2 to set the visibility of wire entities to the last saved state in the native application. Set to 1 to display wire entities. Set to 0 to hide wire entities from the display.	2

EDA Options

Configure a variety of EDA options that apply to parameters for selections, Snap Box, Color.

[ECAD]

Parameter	Description	Default
2DSELECTION_DIMLEVEL = [0.0 - 1.0]	Specify the dim level. The value corresponds to a percentage. For example 0.3 is 30%. Change takes effect whether you change it manually or through the GUI.	0.5
ECAD_3D_BOARDCOLOR	Specify the color of the PCB board in 3D.	25600
ECAD_3D_COMPONENTCOLOR	Specifies the color of the PCB components in 3D.	2631720
ECAD_3D_DEFAULTBOARD THICKNESS = [0-1000]	Specifies the board thickness (in mils) for EDA 3D models. Note: Value cannot represent a thickness greater than 1 foot.	40 (mils)
ECAD_3D_DEFAULTCOMPONENT THICKNESS = [0-1000]	Specifies the component thickness (in mils) for EDA 3D models. Note: Value cannot represent a thickness greater than 1 foot.	40 (mils)

ECAD_3D_DEFAULTHIGHLIGHTSELECTION = <0 1>	<p>Select either Highlight Selected or Dim Unselected as the default behavior when selecting entities.</p> <p>Set to 1 when Dim Unselected is selected.</p> <p>Set to 0 when Highlight Selected is selected.</p> <p>Option takes effect whether you change it manually or through the GUI.</p>	0
ECAD_3D_DEFAULTTHICKNESS UNIT	<p>Specify display units for thickness. Thickness units values:</p> <p>1 - Inch (in.)</p> <p>2 - Millimeter (mm.)</p> <p>5 - Centimeter (cm.)</p> <p>7 - Meter (m.)</p> <p>8 - Kilometer (km.)</p> <p>9 - Feet (ft.)</p> <p>10 - Yard (yd.)</p> <p>11 - Mile (mi.)</p> <p>12 -Thousandth of an inch (mil)</p> <p>14 - Micron</p> <p>15 - Microinch</p>	12
ECAD_3D_DEFAULTMESURE SNAPRADIUS	<p>Specify snap radius for snap box to appear to select entity.</p> <p>Note: The snap radius is configured in pixels.</p>	5

<p>ECAD_CROSSPROBE_AUTOMATIC = <0 1></p>	<p>Specifies whether the Automatic option is enabled or disabled when cross probing EDA files. Set to 1 to enable Automatic mode during an EDA cross probe. Set to 0 to disable Automatic mode during an EDA cross probe.</p>	<p>1</p>
<hr/>		
<p>ECAD_CROSSPROBE_ZOOM = <0 1 2></p>	<p>Specify entity selection behavior when crossprobing EDA files. This option can have one of the following values: 0 - Keep zoom level 1 - Zoom selected 2 - Zoom Fit</p>	<p>1</p>
<hr/>		
<p>ECAD_LAYER_EXPANDCOLLAPSE_PHYSICAL = <0 1></p>	<p>Expand or collapse the Physical Layers pane in the Layers dialog. Set to 0 to expand the Physical Layers pane. Set to 1 to collapse the Physical Layers pane.</p>	<p>0</p>
<hr/>		
<p>ECAD_LAYER_EXPANDCOLLAPSE_LOGICAL = <0 1></p>	<p>Expand or collapse the Logical Layers pane in the Layers dialog. Set to 0 to expand the Logical Layers pane. Set to 1 to collapse the Logical Layers pane.</p>	<p>1</p>

ECAD_LOAD_3D_PAGE=<0 1>	<p>Enable or disable display of 3D models for EDA files.</p> <p>Set to 0 to disable display of 3D model.</p> <p>Set to 1 to enable display of 3D model.</p> <p>Option applies to the following PCB formats:</p> <ul style="list-style-type: none"> • Altium Protel • Cadence Allegro • Cadence Specctra • IDF • Mentor BoardStation • Mentor Expedition • Zuken CADSTAR • OrCAD Layout • ODB++ • Zuken CADIF 	1
EDASCHSCOPE = <0 1>	<p>EDA entity searching scope.</p> <p>Set to 1: the search scope is the entire design.</p> <p>Set to 0: the search scope is current page.</p>	0

Markups

Configure a variety of Markup options that apply to parameters for the **Markup Information** dialog, the Markup file directory, the symbol directory and more.

Markup Options

The parameters in the following table can be configured for Markups.

[Markup Options]

Parameter	Description	Default
ARROW_SIZE	Set to a positive value (greater than 0.1) to create zoomable arrow heads when creating leader and measurement markup entities. If set to a negative value, arrow head is not zoomable.	between -7.2 and 0
ATTACHMENT_MAX_SIZE	Specify the maximum size for attachment markup entities. When creating attachment markup entities, if attachment size exceeds, an error message appears to indicate that attachment size exceeds the limit. Syntax: [Markup Options] ATTACHMENT_MAX_SIZE=<value> value is in MegaBytes.	0 (no limit)
CHILDNORESIZE	Set to 1 if you want to make sure that a child markup entity is not resized when its parent is resized	0
CONSOLIDATE_OPEN ASACTIVE = <0 1>	Set to 1 to toggle-on “Open as Active Markup” option in Markup Consolidation dialog. Set to 0 to turn off this option.	1

Parameter	Description	Default
DEF_COLOR	Specify a Windows RGB color for default markup entity color. Other values: -1 - Assign layer color to markup entity. -2 - Hide markup entity. -3 - Assign line color (option applies to fill color only).	-1 (by layer)
DEF_LSTYLE	Specify the default linestyle for markup entities. Possible values are: 0 - Solid line 1 - Dashed line 2 - Dashed line (smaller dashes) 3 - Dash Dot 6 - Cloud linestyle 7 - Triangle linestyle	0
DEF_LWIDTH	Specify the default line width in pixels for markup entities.	1
DEF_FILLTYPE	Specify the fill type for filled entities. Possible values are: 0 - No Fill 1 - Solid Fill 2 - Transparent Fill	0
DEF_FILLCOLOR	Specify a windows RGB color for default fill color. Other values: -1 - Assign layer color to markup entity -2 - Hide markup entity -3 - Assign line color (option applies to fill color only)	-1

Parameter	Description	Default
EnableOLEEntity=<0 1>	Allows you to re-enable the OLE markup entity. When set to 1 , open a 2D file and enter Markup mode. From the Markup menu, select Add Entity , and then select More . The OLE markup entity is visible. Select OLE to create an OLE markup entity.	0
FACTOR_EXTENSION = factor	Files with the indicated extension use the specified calibration factor when measuring distances in Markup mode.	1.0 Example: FACTOR_TIF = 0.5
INFO_USER = <i>title</i>	Specifies the title of the first field in the Markup Information dialog.	User Name
INFO_DEPT = <i>title</i>	Specifies the title of the second field in the Markup Information dialog.	Department
INFO_COMP = <i>title</i>	Specifies the title of the third field in the Markup Information dialog.	Company
INFO_LOC = <i>title</i>	Specifies the title of the fourth field in the Markup Information dialog.	Location
INFO_TEL = <i>title</i>	Specifies the title of the fifth field in the Markup Information dialog.	Tel#
LINETHICKNESS_ ZOOMABLE	Set to 1 if you want markup entity line thickness to scale according to zoom level.	0
LINestyle_ZOOM- ABLE	Set to 1 if you want to maintain markup entity line style at all zoom levels.	0
NOTENAME_AUTOGE N	Set to 0 to disable automatic numbering of note entities. Set to 1 to enable numbering of note entities.	1

Parameter	Description	Default
REDAUTOPATH = <0 1>	If 0 , the markup will be saved to the directory specified in USERREDLINEPATH. If 1 , markups are saved in the avred sub-directory under the current directory.	1
REDLINEPATH = <i>directory</i>	Specifies the directory to use for Markup files.	The directory avred under the current directory
RESCALEMARKUP = 1	If view extents of base document have changed since creating the Markup, set this option to 1 to scale Markups appropriately.	0
SIGNOFFFILE = <i>path_to_signoffbg</i>	Specify the full name and path for the background image for the Sign Off markup entity.	signoffs-tamp.bmp in the AutoVue installation directory
SYMBOLPATH = <i>directory</i>	Specifies the directory to use for symbol files.	
TRUECOLOR = <0 1>	If 0 , the Markup entity color is inverted when it matches the background color. If 1 , all entities are drawn with their actual color irrespective of the background color. Entities whose color matches or is close to the background color become invisible.	1
USERREDLINEPATH = <i>directory</i>	When specified, this directory takes precedence over the directory specified in REDLINEPATH for the Markup files.	
USERSYMBOLPATH = <i>directory</i>	When specified this directory takes precedence over the directory specified in SYMBOLPATH for the symbol files.	

[Options]

Parameter	Description	Default
EnableOfficeMarkups=<0 1>	<p>Enable/disable creation of markups for office documents.</p> <p>Set to 1 to enable markups for office formats.</p> <p>Set to 0 to disable markups for office formats.</p> <p>Syntax: [Options] EnableOfficeMarkups=1</p>	0
EnableOldMarkupOpen=<0 1>	<p>Set to 1 if you want the Markup Open dialog to appear every time you enter Markup mode.</p>	0

Calibrate

Specify 2D mode measurement units.

[Calibrate]

Parameter	Description	Default
DistanceUnits	<p>Specifies the default units for 2D Markup mode measurements. Distance units values:</p> <ul style="list-style-type: none"> 0 - Pixels 1 - Inches 2 - Millimeters 4 - Twips 5 - Centimeters 7 - Meters 8 - Kilometers 9 - Feet 10 - Yards 11 - Miles 12 - Thousandth of an inch (mils) 13 - Ten Thousandth of an inch (mils/10) 14 - Microns 15 - Microinches 	1
AreaUnits	<p>Specifies the default units for 2D Markup mode area measurements. Area units values:</p> <ul style="list-style-type: none"> 0 - Pixels sq. 1 - Inches sq. 2 - Millimeters sq. 4 - Twips sq. 5 - Centimeters sq. 7 - Meters sq. 8 - Kilometers sq. 9 - Feet sq. 10 - Yards sq. 11 - Miles sq. 12 - Thousandth of an inch (mils sq.) 13 - Ten Thousandth of an inch (mils sq./100) 14 - Microns sq. 15 - Microinches sq. 	1

Markup Font Options

[MrkFont]

Parameter	Description	Default
Face	Specifies the text entity font name.	Arial
Size	Specifies the text entity font size.	10
IsBold	If 1 , the text entity font appears in bold.	0
IsStrikeOut	If 1 , the text entity contains a strikethrough.	0
IsUnderLine	If 1 , the text entity is underlined.	0
IsItalic	If 1 , the text entity appears in italic.	0

Streaming File Options

Configure the streaming file support options.

[Metafiles]

Parameter	Description	Default
Enabled	Set to 1 to enable generation of streaming files. Streaming file format is developed by Oracle AutoVue to improve performance for subsequent loading of files. When enabled, when you open and close a file, AutoVue generates a streaming file. Subsequent rendering of this file reads the streaming file. Syntax: [Metafiles] Enabled=<0/1>	0
Folder	Specify path to the folder where streaming files will be stored. Syntax: [Metafiles] Folder=C:\AutoVue\StreamingFiles	None

Parameter	Description	Default
ControlSize	Specify the size limit for the folder where streaming files will be stored. When set to 0, there is no size limit for the folder. When set to a number, this will be the size limit for the folder in Mega-Bytes. Syntax: [Metafiles] ControlSize=512	0
WriteEnabled	Enable/disable the support for streaming file creation. When set to 1, streaming file writing (creation) and reading is allowed. When set to 0, streaming file writing is disabled and metafile reading is allowed. Syntax: [Metafiles] WriteEnabled=0	1
WriteEnabledPDF	Enable/disable creation of streaming files for PDF format. When set to 0, streaming file will not be generated for PDF. When set to 1, streaming file will be generated for PDF.	0

Applications Options

Configure Applications options that apply to application associations.

[Applications]

Parameter	Description
NUMBER = <i>n</i>	Specifies the number of associations that can be defined by the INI option APPLICATION (see following option).

Parameter	Description
APPLICATION<nnn> = <[extension] [description][command]>	<p>Specify an association between an active file and a related application.</p> <p>Any number of associations can be specified with nnn. Use INI option NUMBER (see previous option) to define the number of associations files can use.</p> <p>Default: No associations. Extension refers to the current active file.</p> <p>Example: APPLICATION001 = [.dwg][Start Acad][c:\ACAD\acad.exe]</p>

Compare Options

Configure Compare mode result display.

[Compare]

Parameter	Description	Default
ViewAdditions	If 1, displays additions.	1
ViewDeletions	If 1, displays deletions.	1
ViewUnchanged	If 1, displays unchanged.	0

Overlay Options

Configure Overlay options that apply to laying files over the current active document.

[Overlay Options]

Parameter	Description	Default
Auto	Automatic overlay. Files with the same name as the base file and the given extensions will be considered for automatic overlay when set to 1.	1 for raster files (tiff, cit, etc.); 0 for all other

Parameter	Description	Default
OneToOne	When set to 1 , avoids scaling and offsetting the overlay file.	0
OverlayText	Specify the list of extensions supported for Auto overlay. Example: OverlayText = drw,dwg,dxf,dgn	drw,dwg,dxf

Page Size Options in Inches

Configure the parameters for the page size in inches.

[PAGESIZEINCH]

Parameter	Description	Default
A = WidthXHeight		8.5 x 11.0
B = WidthXHeight	E.g., To set the Imperial page size to be 11.0" x 17.0", add the following section to the end of the configuration file named avwin.ini : [PageSizeInch] B = 11 x 17	11.0 x 17.0
C = WidthXHeight		17.0 x 22.0
D = WidthXHeight		22.0 x 34.0
E = WidthXHeight		34.0 x 44.0

Page Size Options in Millimeters

Configure the parameters for the page size in millimeters.

[PAGESIZEMM]

Parameter	Description	Default
A4 = WidthXHeight		285 x 198
A3 = WidthXHeight	E.g., To set the metric page size to be 396 mm x 273 mm, add the following section to the end of the configuration file named avwin.ini : [PageSizeMM] A1 = 396X273	396 x 273
A2 = WidthXHeight		570 x 396
A1 = WidthXHeight		817 x 570
A0 = WidthXHeight		165 x 817

3D Export Options

Configure the parameters in the following table for 3D export options
[Export Options]

Parameter	Description	Default
EXPORTTESSEL- LATIONTOL	Control the mesh density when convert- ing to 3D STL. Meshes are more dense if tolerance value is smaller. Syntax: [Export Options] EXPORTTESSELLATIONTOL=val where val can be 0.01, 0.005, 0.001, 0.0001	0
EXPORTREGION	Possible entries for bmp and tiff: “EXTENTS”, “DISPLAY”. Possible entries for STL: “SELECTED”, “ALL”.	EXTENTS for bmp and tiff. ALL for STL
EXPORTTO	STL, BMP, and TIFF	STL

2D Output Options

Configure the output options that apply to parameters for 2D file conversion,
color correction, page size, and many more.

[Output Options]

Parameter	Description	Default
CONVERTTO =	PCRS_TIF is the default for- mat.	
PCRS_TIF	TIFF: This is the default for- mat.	
PCRS_BMP	Windows Bitmap	
PCRS_GP4	CALS GP4	

PCRS_EPS	Encapsulated Postscript (Raster)	
PCRS_PCL	HP Laserjet Printer (PCL)	
PCRS_PCX	PCX Bitmap	
PCRS_RLC	Run Length RLC File	

PenThicknessFname = *fname*

Specify the name of the pen mapping file. The pen mapping file contains a mapping of pen index to width. The unit is preset to pixel.

Note: The pen color mapping is format dependent.

AutoCAD - The pen color mapping uses the AutoCAD color palette. You cannot modify the mapping.

HPGL - The pen color mapping is defined in hpglcol.tbl and can be modified by the user.

ME10 - The pen color mapping is defined in me10col.tbl and can be modified by the user.

DWF - The pen color mapping is defined in dwfcol.tbl and can be modified by the user.

Microstation drawings - The pen color mapping is shipped in a binary file, color.tbl. This mapping file can be modified using Microstation.

The mapping files are located at <AutoVue Installation Directory> \bin.

CONVERTTOSUB =	Subformat	Format
0	Uncompressed	PCRS_TIF
CONVERTTOSUB =	Subformat	Format

1	PackBits	PCRS_TIF
2	Fax III	PCRS_TIF
3	Fax IV	PCRS_TIF
0	75 dpi	PCRS_PCL
1	150 dpi	PCRS_PCL
2	300 dpi	PCRS_PCL

[Options]

Parameter	Description	Default
COLORDEPTH = <i><original\ number></i>	Set the number of bits for the image plane.	ORIGINAL
CONVERTAREA = <i><DISPLAY EXTENTS></i>	Indicates the portion of the drawing to be converted. If CONVERTAREA = EXTENTS , the file extents are printed. If DISPLAY is specified, the area given by the DISPLAY option is used. If the DISPLAY option is not set, the extents are printed.	DISPLAY
OUTPUTPAGESIZE = <i><A B C D E A4 A3 A2 A1 A0 U MAX1 MAX2></i>	Specifies the current page size.	A
DEFAULTHEIGHT = <i>height</i>	Specifies the default height (in pixels) used when converting from vector to raster formats.	480
DEFAULTWIDTH = <i>width</i>	Specifies the default width (in pixels) used when converting from vector to raster formats.	640
FLIPPING = <i><NONE VERTICAL HORIZONTAL BOTH></i>	Specifies the flipping direction(s).	NONE

HEIGHT = <i>height</i>	Specify the height in pixels.	0 (in pixels)
INPUTFILE = <i>fname</i>	Specifies the name and path of the input file.	No default
LAYER< <i>index</i> > = <0 1>	For drawings containing layers, only the layers which are equal to 1 are converted. Example: LAYER1 = 0	1 for all layers
NCOLORS = <i>num</i>	This specifies the number of colors to generate in the output image. The string True Color is used to generate true color images. If the converter does not support the number specified, the closest supported number is used.	The highest number of colors supported for the target format.
NUMLAYERS = <i>num</i>	Specifies the number of layers that exist.	
ORIGIN = <i>unitsX;unitsY</i>	Both X and Y are given in the current UNITS. This specifies the X and Y offset.	X=0 and Y=0
OUTPUTFILE = <i>fname</i>	Specifies the output file name.	No default
OVERLAY< <i>index</i> > = [<i>filename</i>][<i>offsetx</i> . <i>offsety</i> , <i>offsetz</i>] [<i>basex</i> , <i>basesy</i> , <i>basesz</i>] [<i>scalex</i> , <i>scaley</i> , <i>scalez</i>] [<i>dpix</i> , <i>dpiy</i> , <i>dpiz</i>]	Specify a file to overlay. Any number of overlay files can be specified by making multiple entries with different indexes.	No default
OVERRIDE THICKLINES = <0 1>	Set to 1 , AutoVue will print as per pen settings. Set to 0 , AutoVue applies pen settings only to thin lines. Thick lines print with their original thickness. Note: Option only applies if pen settings are defined.	1

PAGES = <0 1 2>	Specifies which page(s) to convert for a multi-page input file. Pages are numbered starting at 1. 0 = All pages 1 = Page range 2 = Current page	1
REDLINEFILE = <i>filename</i>	Specifies a Markup file to overlay.	No default
ROTATION = <0 90 180 270>	Specifies the angle (in degrees) that the drawing is rotated.	0
SCALING = <FIT FACTOR>	Indicates the scaling factor for a drawing.	FIT
SCALINGFACTOR = X;Y	This indicates the scaling factor by specifying that X input units must correspond to Y output units.	X=1 and Y=1
SKIPMODE = <AUTO AND OR SKIP>	Specifies how to delete raster lines when an image's size is reduced. SKIP : suitable for color images. AND : for monochrome images with a light background. OR : for images with a dark background. AUTO : causes AutoVue to determine the best mode based on the image's characteristics.	SKIP
TILESIZE X	Specifies the number of pixels in tile X.	96
TILESIZE Y	Specifies the number of pixels in tile Y.	96
TRUEEXTENTS = X0,Y0;X1,Y1	Specifies the true extents of the input file. Used by the conversion when CONVERTAREA = EXTENTS . If not specified, the conversion evaluates the true extents.	No default
UNITS = <PIXEL INCH MM>	Specifies the units to be used when printing or converting a file.	PIXEL

WIDTH = <i>width</i>	Specify the width in pixels.	0
XResolution YResolution	Specify the resolution of the output device - in this case the output bitmap. They are used when we have thick lines and we need to compute the output line thickness in pixels so it will match the desired line thickness when the bitmap is shown/printed in this resolution. These options will not affect files with no thickness.	Screen resolution is used if no value is specified

[PCRS_BMP]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	72

[PCRS_EPS]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	720

[PCRS_PLC-1]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	75

[PCRS_PLC-2]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	150

[PCRS_PLC-3]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	300

[PCRS_PCX]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	300

[PCRS_RLC]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	200

[PCRS_TIF]

Parameter	Description	Default
STEPSPERINCHX = <i>num</i> STEPSPERINCHY = <i>num</i>	Specifies the conversion factor between device units and inches.	200

Parameter	Description	Default
PREVIEW = <0 1>	Specifies if a preview image should be generated. If PREVIEW = 1 , then a 128x128 preview image is generated as the first page of the destination file.	1
TILING = <0 1>	If 1 , tiles the image; otherwise stripes the image.	1
NSTRIPS = <0 1>	If 1 , defines the number of stripes for an image.	1
TILESIZEX = <i>num</i>	Specifies the number of pixels in tile X.	
TILESIZEY = <i>num</i>	Specifies the number of pixels in tile Y.	

Pen Mapping Options

Configure the pen mapping options that apply to pen color, thickness and speed.

[Pen Mapping]

Parameter	Description
PENS_ <i>starting_pen_number-ending_pen_number</i> = [color, thickness, speed]	Specifies the numerical index for the pen color, thickness (in inches) and speed (in inches per second). The starting pen number must be a multiple of 8; the ending pen number must equal the starting pen number plus 7. Example: PENS16-23 = [16, 0.0100, 36] [17, 0.0100, 36] [18, 0.0100, 36] [19, 0.0100, 36] [20, 0.0100, 36] [21, 0.0100, 36] [22, 0.0100, 36] [23, 0.0100, 36]

Disable Options

Configure the Disable options parameters to disable options such as **Browse**, **Next**, or being able to change print settings.

[Disable]

Parameter	Description	Default
BatchPrint = <0 1>	If 1 , disables batch printing.	0
Browse = <0 1>	If 1 , disables the File menu's Browse , Next , and Previous options.	0
Launch = <0 1>	If 1 , disables the File menu's Launch option.	0
Markup = <0 1>	If 1 , disables Markup mode.	0
Mail = <0 1>	If 1 , disables the Mail option in View mode's File menu. If 1 , also disables the Notify option found in the Save and Save As dialog as in Markup mode.	0
Print = <0 1>	If 1 , disables printing.	0
PrintSettings = <0 1>	If 1 , disables changing listed print settings - margins, watermark, headers/ footers, pen settings and stamps.	0
PrintToFile = <0 1>	If 1 , disables option to print to file.	0
PrintMargins = <0 1>	If 1 , disables changing Print-Margins.	0
PrintHeadersFooters = <0 1>	If 1 , disables changing Print Headers and Footers.	0
PrintWatermarks = <0 1>	If 1 , disables changing the Print-Watermark.	0
PrintStamps = <0 1>	If 1 , disables changing the Print-Stamps.	0
PrintPenSettings = <0 1>	If 1 , disables changing the Print-Pen settings.	0

Parameter	Description	Default
MarkupForceToBlack = <0 1>	If 1 , disables printing Markups in black when the print option AvPrint-Options ForceToBlack is set to 1.	1
Thumbnails = <0 1>	If 1 , disables the creation of Thumbnails.	0
Convert = <0 1>	If 1 , disables converting.	0
Clipboard = <0 1>	If 1 , disables copying to the clipboard.	0
SystemTray = <0 1>	If 1 , disables the AutoVue system tray icon.	0

OEM Options

Configure the OEM options parameters to customize the title of the product.

[OEM]

Parameter	Description	Default
PRODUCT = <Name>	Name of product to appear on title bar.	AutoVue
NICKNAME = <Name>	Short name of product to appear on title bar.	avwin
LONGNAME = <Name>	Long name of product to appear on title bar.	AutoVue, Desktop Version
VERSION = <Version>	Version number of product to appear in the Help menu's About dialog.	19.3
COPYRIGHT = <Name>	Copyright notice to appear in the Help menu's About dialog.	© Oracle 2008

Thumbnail Options

[ThumbNails]

Parameter	Description	Default
ImageSize	Specify the size of the thumbnails image.	64 (64 x 64 pixels)
Spacing = <i>num</i>	Specify the spacing between thumbnails. Value should be between 2 and 20 pixels.	10
Details = <0 1 2>	Specify the details of file display. 0 = None 1 = Partial 2 = Full	1
FOLDERPATH	Specify the folder where the thumbnails info is stored.	

Parameter	Description	Default
FOLDERCONFIG	Specify the name of the configuration file for the thumbnail database.	folders.cfg

Printing Options

Watermark

Set the Watermark parameters used to define how watermarks print on your documents.

[AvPrintWatermark]

Parameter	Description	Default
Facename = <i>font</i>	Specify the font for the printed watermark text.	
Layout = 0	Specify WaterMark Orientation: 0 - Diagonal 1 - Horizontal 2 - Vertical	
LogFont = - 21,0,0,0,400,0,0,0,0,3,2,1,34	Specify the font size, height, style as per the windows logfont structure.	
Text = <i>watermark_text</i>	Specifies the text to be printed as a watermark. Carriage returns are indicated by \n.	
TextColor = 192,192,192	Specifies WaterMark text color.	

Stamp

Each stamp parameter is defined by a number according to the following options. Set the Stamp parameters used to define how a stamp will print with your documents.

[AvPrintStamp]

Parameter	Description	Default
NumberOfStamp = <i>total_number_of_stamps</i>	Specifies the total number of defined stamps.	0
Stamp_entry_Unit_n = <0 1>	Specifies the units used to position stamps. If 1 , millimeters, otherwise, inches. The n represents which stamp is being configured.	0
Stamp_entry_Posx_n	Indicates the position of X in the upper left corner of the stamp file. The n represents which stamp is being configured.	
Stamp_entry_Posy_n	Indicates the position of Y in the upper left corner of the stamp file. The n represents which stamp is being configured.	
Stamp_entry_Sizex_n	Specifies the width of the stamp image. The n represents which stamp is being configured.	
Stamp_entry_Sizey_n	Specifies the height of the stamp image. The n represents which stamp is being configured.	
Stamp_entry_Filename_n = fname	Specifies the name and path of the file printed as a stamp.	

General Print Options

Set the parameters that define various aspects of how your documents print, including pen and pixel thickness, printing notes and orientation.

[AvPrintOptions]

Parameter	Description	Default
AdjustResolution = <0 1>	If 1 , scales the line pixel thickness by the ratio of the printer dpi to the screen dpi. This option produces the same line thickness as when printing with MicroStation.	1
Area = <0 1 2 3>	Specify page area to print: 0 - print file extents 1 - print displayed area 2 - print limits (only for AutoCAD files) 3 - print selected area	0
AutoOrientation = <0 1>	If 1 , Office format document pages are landscape oriented if the page width is greater than the page length.	1
Factor1 = <i>num</i>	When the INI option Scaling = 1 , Factor1 specifies the number of pixels for the scaling factor.	
Factor2 = <i>num</i>	When the INI option Scaling = 1 , Factor2 specifies the number of units to which the specified number of pixels are scaled.	
ForceToBlack = <0 1>	If 1 , the file is printed in black and white. If 0 , in color.	0
FromPage = <i>num</i>	Indicates the starting page number of the print range.	
OneNotePerPage = <0 1>	If 1 , one note per page is printed.	0
Orientation = <1 2>	If 1 , the file is printed as portrait. If 2 , landscape.	1

Parameter	Description	Default
OverrideThickLines = <0 1>	Setting this option to 1 applies the pen-thickness settings when printing files of formats such as DGN and HPGL.	0
Pages = <i>total_num</i>	Indicates whether to print all the pages in a document, the current page, or a range of pages. 0 = All 1 = Current 2 = Range	0
PaperFormname = dmFormname	Specifies the name of the form of paper to use, such as "Letter" or "Legal". Retrieve the list of possible values for a particular printer from the print dialog.	
PaperSize = dmPaperSize	Refer to PRINT-OPTION PAPER-SIZE.	

Parameter	Description	Default
PenThicknessFname = <i>fname</i>	<p>Specify the name of the pen mapping file. The pen mapping file contains a mapping of pen index to width.</p> <p>Note: The pen color mapping is format dependent.</p> <p>AutoCAD - The pen color mapping uses the AutoCAD color palette. You cannot modify the mapping.</p> <p>HPGL - The pen color mapping is defined in hpglcol.tbl and can be modified by the user.</p> <p>ME10 - The pen color mapping is defined in me10col.tbl and can be modified by the user.</p> <p>DWF - The pen color mapping is defined in dwfcol.tbl and can be modified by the user..</p> <p>Calcomp PCI - The pen color mapping is defined in pcicol.tbl and can be modified by the user.</p> <p>Microstation drawings - The pen color mapping is shipped in a binary file, color.tbl. This mapping file can be modified using Microstation. The mapping files are located at <AutoVue Installation Directory>\bin.</p>	
PenThicknessUnits = <0 1>	<p>0 = inches</p> <p>1 = mms</p>	0
PrinterName = PrintName	Name of the Printer device	
PrintNotes = <0 1>	If 1 , notes are printed.	0
PrintOnly1stPrPg = <0 1>	If 1 , limits output to one printer page when the scaling options selected causes a single page to span over several pages.	0
PrintToFile	If 1 , prints to file.	0

Parameter	Description	Default
Scaling = <0 1 2>	Specifies the scaling factor: 0 = fit 1 = scaling factor 2 = scaling percentage	0
ScalingFactor = <i>percentage</i>	When the INI option Scaling = 2 , ScalingFactor specifies the percentage to which the image is scaled.	
SSNoPrintRowHeader = <0 1>	If 1 , row headers are not printed for spreadsheet formats.	0
SSNoPrintColHeader = <0 1>	If 1 , column headers are not printed for spreadsheet formats.	0
THICKNESSSCALEUNIT = <mm inch dot>	Specify the unit to use for the thickness scale. Option only applies to MicroStation files when ThicknessScale is set.	
ToPage = <i>num</i>	Indicates the ending page number of the print range.	
Units = <0 1 2>	Specifies the scaling factor units: 0 = pixels 1 = inches 2 = millimeters	1
WaterMarkOnTop = <0 1>	If 1 , prints the watermark on top of the drawing.	0

Headers and Footers

Set the parameters for document headers and footers used to define how headers/footers print on your documents.

[AvPrintHeadersFooters]

Parameter	Description	Default
Facename = <i>font</i>	Specifies the font used for the printed headers and footers.	

Parameter	Description	Default
LeftHeader = <i>text</i>	Specifies the text for the left header.	
CenterHeader = <i>text</i>	Specifies the text for the center header.	Full path of the current document
RightHeader = <i>text</i>	Specifies the text for the right header.	
LeftFooter = <i>text</i>	Specifies the text for the left footer.	
CenterFooter = <i>text</i>	Specifies the text for the center footer.	
RightFooter = <i>text</i>	Specifies the text for the right footer.	Page X (current page number) of Y (total number of document pages)

Printing Batch Pages

Set the parameters for printing specific pages for file formats defined by AutoVue.

[BatchPrintPages]

Parameter	Description	Default
FORMAT1 = pagerange	Specify the format and the range of pages to print. Note that the format should be the same as identified by AutoVue. Example: Microsoft Excel 95 = 8-10	1

Margins

Set the Margin parameters used to define how margins print on your documents.

[AvPrintMargins]

Parameter	Description	Default
Units	Specify the units: 0 - inches 1 - millimeters	0
Left	Left margin.	0.25
Top	Top margin.	0.25
Right	Right margin.	0.25
Bottom	Bottom margin.	0.25
IgnoreMin	Ignore printer minimum margins. If 1 , the printer minimum margins are merged into the page margins specified by the user. e.g if printer min. margin is 0.25in and the margin set by the user is 1inch, the printout will be 1inch from the edge of the page if the option is true and 1.25 inches if it is false.	0

Notes

Set the Note parameters used to define how notes print on your documents.

[AvPrintNotes]

Parameter	Description	Default
Units	Specify the units: 0 - inches 1 - millimeters	0
Left	Left margin.	0.25
Top	Top margin	0.25
Right	Right margin.	0.25

Parameter	Description	Default
Bottom	Bottom margin.	0.25
OneNotePerPage	If 1, one note per page is printed.	0

Markup Measurement Options

It is possible to configure default units and the default symbol for measurements with AutoVue. Configure below options in **avwin.ini**.

Area Measurements

Configure default symbol and list of symbols for 2D/EDA Area measurements.

[UDE_AREA]

Parameter	Description	Default
DefaultSymbolArea	Specify the default symbol (in unicode) for 2D Markup mode area measurements.	
SymbolList = <i>alphanum</i>	Specifies a comma-separated list of symbols (in unicode) for area measurements. Example: u0398, u2221, u2248.	

Arc Measurements

Configure default symbol and list of symbols for 2D/EDA/3D arc measurements.

[UDE_ARCD]

Parameter	Description	Default
DefaultSymbolArcDiameter	Specify the default symbol (in unicode) for diameter for arc measurements.	
DefaultSymbolArcRadius	Specify the default symbol (in unicode) for radius for arc measurements.	
SymbolList = <i>alphanum</i>	Specifies a comma-separated list of symbols (in unicode) for arc measurements. Example: u0398, u2221, u2248.	

Angle Measurements

Configure default symbol and list of symbols for 2D/EDA/3D angle measurements.

[UDE_ANGD]

Parameter	Description	Default
DefaultSymbolAngle	Specify the default symbol (in unicode) for angle measurements.	
SymbolList = <i>alphanum</i>	Specifies a comma-separated list of symbols (in unicode) for angle measurements. Example: u0398, u2221, u2248.	

Distance Measurements

Configure default symbol and list of symbols for 2D/EDA distance and cumulative distance measurements.

[UDE_DIS] or [UDE_CDIS]

Parameter	Description	Default
DefaultSymbolDist	Specify the default symbol (in unicode) for distance measurements.	
SymbolList = <i>alphanum</i>	Specifies a comma-separated list of symbols (in unicode) for distance measurements. Example: u0398, u2221, u2248.	

3D Distance Measurements

Configure default symbol and list of symbols for 3D distance measurements.

[UDE_LDIM]

Parameter	Description	Default
DefaultSymbolDist	Specify the default symbol (in unicode) for diameter for 3D distance measurements.	
DistanceUnits	Specify the default unit for 3D distance measurements.	1 (inches)
SymbolList = <i>alphanum</i>	Specifies a comma-separated list of symbols (in unicode) for 3D distance measurements. Example: u0398, u2221, u2248.	

Calibrate Measurements

Specify the default units for measurements.

[Calibrate]

Parameter	Description	Default
AreaUnits	Specify the default unit for area measurements.	1 (inches sq.)
DistanceUnits	Specify the default unit for distance measurements.	1 (inches)

The following table lists units and the integer value that represents the unit in the INI file:

Unit	value
pixels	0
inches	1
feet	2
yards	3
miles	4
millimeters	5
centimeters	6
meters	7
kilometers	8
twips	9
microns	10
mils	11
mils/10	12
microinches	13

Watermark in View Mode

With AutoVue it is possible to display watermarks in View mode.

[WATERMARK]

Parameter	Description	Default
TEXT	Specify watermark text. Example , TEXT=AutoVue 19.3.	
FONTNAME	Specify font to be used for the watermark. Example , FONTNAME=Times New Roman.	
FONTSTYLE	Specify the font style for the watermark. 0 – Plain 1 – Bold 2 – Italic 3 – Bold and Italic Example , FONTSTYLE=3.	
FONTSIZE	Specify font size. Example , FONTSIZE=24.	
XFACTOR	Specify watermark x position on the applet window. Value should range from 0 to 1. Example , XFACTOR=0.05.	
YFACTOR	Specify watermark y position on the applet window. Value should range from 0 to 1. Example , YFACTOR=0.90.	
COLOR	Specify a valid color value. Example , COLOR=0xFF.	
ALPHA	Specify the transparency level of the text. Value can range from 0x00 (not visible) to 0xFF (opaque). Example , ALPHA=0x80.	

Note: To disable the watermark you must either remove the whole [WATERMARK] section, remove the TEXT option, or assign an empty string to the TEXT option.

Script and DDE Commands

AutoVue registers itself as a Dynamic Data Exchange (DDE) server under the name **AVWINSERVER**. Commands should be sent using the topic **SYSTEM**. AutoVue can be launched from the command line with the **/s scriptfilename** option to automatically execute the specified script on startup. Below is a full listing and description of the available scripting commands. The scriptfile itself is an ASCII text file, containing scripting commands.

The pound (#) character is used to add comments to the scriptfile. Any text after the pound character to the end of the line is ignored. Also, the backslash (\) character at the end of a line can be used to continue a long line to the next line.

Script Syntax Diagrams

The description of script commands follows certain conventions which may vary from other parts of the Administrator Guide:

Command	Description
<angular brackets>	Indicates required entries but are not to be included in the entered information.
{curly braces}	Indicates optional entries but are not to be included in the entered information.
[square brackets]	Required syntactical elements.
(parentheses)	Required syntactical elements.
bold	Introduces a literal expression which must be entered exactly as shown.
<i>italics</i>	Indicates a variable which must be replaced by information you provide
	Symbol indicates an either-or type of choice.
...	Ellipsis indicates that information may be repeated.

Window Commands

These are the standard Windows messages. They apply to the frame window as a whole.

Message

WINDOW HIDE

WINDOW SHOW

WINDOW POSITION x y width height

WINDOW RESTORE

WINDOW MINIMIZE

WINDOW MAXIMIZE

WINDOW TILE

WINDOW CASCADE

Child Commands

These are the standard Windows MDI child commands.

Command

CHILD CLOSE

CHILD HIDE

CHILD MINIMIZE

CHILD MAXIMIZE

CHILD NEW

CHILD POSITION x y width height

CHILD RESTORE

CHILD SELECT n - Activates the nth child window -- where n is a 1-indexed number
(not zero-indexed).

CHILD SHOW

CHILD SHOWONE - If no child exists, creates a new one.

General Commands

Command	Description
BREAK = <ON OFF>	Controls interruptibility. When set to ON , interruptible.
CHDIR <dirname>	Changes the working directory.
PAUSE <nn>	Pauses for nn milliseconds.
QUIT	Terminates the application.
VIEW <filename>	Open file <filename>.
WRITEPROFILE "section" "entry" "value"	Writes the entry/value under the specified section into AutoVue's INI file.

File Commands

Command	Description
BROWSE	Activates the Browse dialog.
COMPARE <filename>	Compares the file in the active window with "filename".
FILE OPEN {filename}	Same as VIEW , except that if {filename} is not supplied it displays the File Open dialog.
FILE-NEXT	Goes to the next file.
FILE-PREVIOUS	Goes to the previous file.
OVERLAY <filename> {<x, y> {sf}}	Overlays the specified file over the current file (base drawing). The point (x, y) is the offset for the overlaid file expressed in base drawing units. The origin of raster images is in the top left, and for vector images it is in the bottom left. It (sf) is the scaling factor for the overlay. Default values of (0.0, 0.0) and 1.0 are used for the base point and scaling factor.

PROPERTIES	Displays the Properties dialog.
SEARCH = <string to search for>	Finds and highlights the search string.

Export BOM Commands

Command	Description
EXPORT3DBOM FileName	Specify the output file into which to export 3D BOM results.
EXPORTEDABOM Filename ["format=XXX scope=YY attributes=Aaaa,Bbbbb,Ccccc"]	<p>Filename: Specify the file name of the exported BOM.</p> <p>format: Specify whether the export file format is either CVS or PDX. Default value is CVS if nothing is specified.</p> <p>scope: Specify either CP (current page) or ED (entire design). Default is CP if nothing is specified.</p> <p>attributes: Specify the attribute names of Component Instances. Separate attribute names by commas. If no attributes are specified, the default BOM attribute names are used. If there are no default BOM attribute names, the command does nothing.</p> <p>Note: Attributes are case sensitive.</p> <p>Note: The vertical line symbol used in the second parameter (" ") is an actual symbol needed and used as a separator, not the logical symbol used to specify that only one of the parameters can be used.</p>

Printing Commands

Command	Description
PRINT-OPTION <i>option=value</i>	Specify the print option and value.
PRINT	Using the current print options, prints the file in the active window.

Print Options

Command	Description
AREA = <DISPLAY EXTENTS>	Specify print area (extents or display).
CF = <i>string</i>	Center footer text.
CH = <i>string</i>	Center header text.
LF = <i>string</i>	Left footer text.
LH = <i>string</i>	Left header text.
RH = <i>string</i>	Right header text.
RF = <i>string</i>	Right footer text.
COPIES = <number of copies>	Specify number of copies.
PAGERANGE = <from page nnn- to page mmm>	Specify page range.
PAGERANGE CURRENT	Prints current page.
SCALE = <FIT <i>nn.nn</i> <i>n%</i> >	Set <i>n%</i> to the scale value. Example: PRINT-OPTION SCALE = 60% Set <i>nn.nn</i> to a scale factor.
UNITS = <INCH MM PIXEL>	Specify units.
WATERMARK "watermark-text"	Specify watermarking text.
FORCETOBLACK = <0 1>	Specify if you want to force all colors to black
ORIENTATION [L P]	Specify orientation. Set L for landscape or P for portrait.
PRINTDRIVER "drivername"	Specify the print device to use, e.g. "Epson Stylus Color 750."
PENMAPFILE "penmapfilename"	Specify the penmapping file to use.

PAPERSIZE "nPaperSize"

Specify the paper size, where **nPaperSize** is a value from the **nPaperSize** column in the following table. The specified paper size specified must be supported by your printer.

Note: For updated paper size values, refer to *wingdi.h* that is part of the MSDN distribution.

Name	nPaperSize	Description
DMPAPER_LETTER	1	Letter 8 ½ x 11 in
DMPAPER_LETTERSMA LL	2	Letter Small 8 ½ x 11 in
DMPAPER_TABLOID	3	Tabloid 11 x 17 in
DMPAPER_LEDGER	4	Ledger 17 x 11 in
DMPAPER_LEGAL	5	Legal 8 ½ x 14 in
DMPAPER_STATEMENT	6	Statement 5 ½ x 8 ½ in
DMPAPER_EXECUTIVE	7	Executive 7 ¼ x 10 ½ in
DMPAPER_A3	8	A3 297 x 420 mm
DMPAPER_A4	9	A4 210 x 297 mm
DMPAPER_A4SMALL	10	A4 Small 210 x 297 mm
DMPAPER_A5	11	A5 148 x 210 mm
DMPAPER_B4	12	B4 (JIS) 250 x 354
DMPAPER_B5	13	B5 (JIS) 182 X 257
DMPAPER_FOLIO	14	Folio 8 ½ x 13
DMPAPER_QUARTO	15	Quarto 215 x 275 mm
DMPAPER_10X14	16	10 x 14 in
DMPAPER_11X17	17	11 x 17 in
DMPAPER_NOTE	18	Note 8 ½ x 11 in
DMPAPER_ENV_9	19	Envelope #9 3 7/8 x 8 7/8
DMPAPER_ENV_10	20	Envelope #10 4 1/8 x 9 ½
DMPAPER_ENV_11	21	Envelope #11 4 ½ x 10 3/8

DMPAPER_ENV_12	22	Envelope #12 4 276 x 11
DMPAPER_ENV_14	23	Envelope #14 5 x 11 ½
DMPAPER_CSHEET	24	C size sheet
DMPAPER_DSHEET	25	D size sheet
DMPAPER_ESHEET	26	E size sheet
DMPAPER_ENV_DL	27	Envelope DL 110 x 220 mm
DMPAPER_ENV_C5	28	Envelope C5 162 x 229 mm
DMPAPER_ENV_C3	29	Envelope C3 324 x 458 mm
DMPAPER_ENV_C4	30	Envelope C4 229 x 324 mm
DMPAPER_ENV_C6	31	Envelope C6 114 x 162 mm
DMPAPER_ENV_C65	32	Envelope C65 114 x 229 mm
DMPAPER_ENV_B4	33	Envelope B4 250 X 353 mm
DMPAPER_ENV_B5	34	Envelope B5 176 x 250 mm
DMPAPER_ENV_B6	35	Envelope B6 176 x 125 mm
DMPAPER_ENV_ITALY	36	Envelope 110 x 230 mm
DMPAPER_ENV_MONARCH	37	Envelope Monarch 3.875 x 7.5 in
DMPAPER_ENV_PERSONAL	38	6 ¾ Envelope 3 5/8 x 6 ½ in
DMPAPER_ENV_FANFOLD_US	39	US Std Fanfold 8½ x 12 in
DMPAPER_ENV_FANFOLD_STD_GERMAN	40	German Std Fanfold 8½ x 12 in
DMPAPER_ENV_FANFOLD_LGL_GERMAN	41	German Legal Fanfold 8½ x 13
DMPAPER_ISO_B4	42	B4 (ISO) 250 x 353 mm

DMPAPER_JAPANESE_P OSTCARD	43	Japanese Postcard 100 x 148 mm
DMPAPER_9X11	44	9 x 11 in
DMPAPER_10X11	45	10 x 11 in
DMPAPER_15X11	46	15 x 11 in
DMPAPER_ENV_INVITE	47	Envelope Invite 220 x 220 mm
DMPAPER_RESERVED_4 8	48	RESERVED--DO NOTE USE
DMPAPER_RESERVED_4 9	49	RESERVED--DO NOTE USE
DMPAPER_LETTER_EX TRA	50	Letter Extra 9 \275 x 12 in
DMPAPER_LEGAL_EXT RA	51	Legal Extra 9 \275 x 15 in
DMPAPER_TABLOID_E XTRA	52	Tabloid Extra 11.69 x 18 in
DMPAPER_A4_EXTRA	53	A4 Extra 9.27 x 1.69 in
DMPAPER_LETTER_TR ANSVERSE	54	Letter Transverse 8 \275 x 11 in
DMPAPER_A4_TRANSV ERSE	55	A4 Transverse 210 x 297 mm
DMPAPER_LETTER_EX TRA_TRANSVERSE	56	Letter Extra Transverse 9\275 x 12 in
DMPAPER_A_PLUS	57	SuperA/SuperA/A4 227 x 356 mm
DMPAPER_B_PLUS	58	SuperB/SuperB/A3 305 x 487 mm
DMPAPER_LETTER_PLU S	59	Letter Plus 8.5 x 12.69 in
DMPAPER_A4_PLUS	60	A4 Plus 210 x 330 mm
DMPAPER_A5_TRANSV ERSE	61	A5 Transverse 148 x 210 mm

DMPAPER_B5_TRANSVERSE	62	B5 (JIS) Transverse 182 x 257 mm
DMPAPER_A3_EXTRA	63	A3 Extra 322 x 445 mm
DMPAPER_A5_EXTRA	64	A5 Extra 174 x 235 mm
DMPAPER_B5_EXTRA	65	B5 (ISO) Extra 201 x 276 mm
DMPAPER_A2	66	A2 420 x 594 mm
DMPAPER_A3_TRANSVERSE	67	A3 Transverse 297 x 420 mm
DMPAPER_A3_EXTRA_TRANSVERSE	68	A3 Extra Transverse 322 x 445 mm
DMPAPER_DBL_JAPANESE_POSTCARD	69	Japanese Double Postcard 200 x 148 mm
DMPAPER_A6	70	A6 105 x 148 mm
DMPAPER_JENV_KAKU 2	71	Japanese Envelope Kaku #2
DMPAPER_JENV_KAKU 3	72	Japanese Envelope Kaku #3
DMPAPER_JENV_CHOU 3	73	Japanese Envelope Chou #3
DMPAPER_JENV_CHOU 4	74	Japanese Envelope Chou #4
DMPAPER_LETTER_ROTATED	75	Letter Rotated 11 x 8 1/2 11 in
DMPAPER_A3_ROTATED	76	A3 Rotated 420 x 297 mm
DMPAPER_A4_ROTATED	77	A4 Rotated 297 x 210 mm
DMPAPER_A5_ROTATED	78	A5 Rotated 210 x 148 mm
DMPAPER_B4_JIS_ROTATED	79	B4 (JIS) Rotated 364 x 257 mm

DMPAPER_B5_JIS_ROTATED	80	B5 (JIS) Rotated 257 x 182 mm
DMPAPER_JAPANESE_POSTCARD_ROTATED	81	Japanese Postcard Rotated 148 x 100 mm
DMPAPER_DBL_JAPANESE_POSTCARD_ROTATED	82	Double Japanese Postcard Rotated 148 x 200 mm
DMPAPER_A6_ROTATED	83	A6 Rotated 148 x 105 mm
DMPAPER_JENV_KAKU2_ROTATED	84	Japanese Envelope Kaku #2 Rotated
DMPAPER_JENV_KAKU3_ROTATED	85	Japanese Envelope Kaku #3 Rotated
DMPAPER_JENV_CHOU3_ROTATED	86	Japanese Envelope Chou #3 Rotated
DMPAPER_JENV_CHOU4_ROTATED	87	Japanese Envelope Chou #4 Rotated
DMPAPER_B6_JIS	88	B6 (JIS) 128 x 182 mm
DMPAPER_B6_JIS_ROTATED	89	B6 (JIS) Rotated 182 x 128 mm
DMPAPER_12X11	90	12 x 11 in
DMPAPER_JENV_YOU4	91	Japanese Envelope You #4
DMPAPER_JENV_YOU4_ROTATED	92	Japanese Envelope You #4 Rotated
DMPAPER_P16K	93	PRC 16K 146 x 215 mm
DMPAPER_P32K	94	PRC 32K 97 x 151 mm
DMPAPER_P32KBIG	95	PRC 32K(Big) 97 x 151 mm
DMPAPER_PENV_1	96	PRC Envelope #1 102 x 165 mm
DMPAPER_PENV_2	97	PRC Envelope #2 102 x 176 mm
DMPAPER_PENV_3	98	PRC Envelope #3 125 x 176 mm

DMPAPER_PENV_4	99	PRC Envelope #4 110 x 208 mm
DMPAPER_PENV_5	100	PRC Envelope #5 110 x 220 m
DMPAPER_PENV_6	101	PRC Envelope #6 120 x 230 mm
DMPAPER_PENV_7	102	PRC Envelope #7 160 x 230 mm
DMPAPER_PENV_8	103	PRC Envelope #8 120 x 309 mm
DMPAPER_PENV_9	104	PRC Envelope #9 229 x 324 mm
DMPAPER_PENV_10	105	PRC Envelope #10 324 x 458 mm
DMPAPER_P16K_ROTATED	106	PRC 16K Rotated
DMPAPER_P32K_ROTATED	107	PRC 32K Rotated
DMPAPER_P32KBIG_ROTATED	108	PRC 32K(Big) Rotated
DMPAPER_PENV_1_ROTATED	109	PRC Envelope #1 Rotated 165 x 102 mm
DMPAPER_PENV_2_ROTATED	110	PRC Envelope #2 Rotated 176 x 102 mm
DMPAPER_PENV_3_ROTATED	111	PRC Envelope #3 Rotated 176 x 125 mm
DMPAPER_PENV_4_ROTATED	112	PRC Envelope #4 Rotated 208 x 110 mm
DMPAPER_PENV_5_ROTATED	113	PRC Envelope #5 Rotated 220 x 110 mm
DMPAPER_PENV_6_ROTATED	114	PRC Envelope #6 Rotated 230 x 120 mm
DMPAPER_PENV_7_ROTATED	115	PRC Envelope #7 Rotated 230 x 160 mm
DMPAPER_PENV_8_ROTATED	116	PRC Envelope #8 Rotated 309 x 120 mm

DMPAPER_PENV_9_ROTATED	117	PRC Envelope #9 Rotated 324 x 229 mm
DMPAPER_PENV_10_ROTATED	118	PRC Envelope #10 Rotated 458 x 324 mm

PRINT-OPTION PAPERTRAY
"nPaperTray"

Specify the paper tray, where **nPaperTray** is a value from the **nPaperTray** column in the following table. The specified paper tray must be supported by your printer.

Name	nPaperTray
DMBIN_UPPER	1
DMBIN_ONLYONE	1
DMBIN_LOWER	2
DMBIN_MIDDLE	3
DMBIN_MANUAL	4
DMBIN_ENVELOPE	5
DMBIN_ENVMANUAL	6
DMBIN_AUTO	7
DMBIN_TRACTOR	8
DMBIN_SMALLFMT	9
DMBIN_LARGE FMT	10
DMBIN_LARGE CAPACITY	11
DMBIN_CASSETTE	14
DMBIN_FORMSOURCE	15

DMBIN_LAST	DMBIN_FORMSOURCE
DMBIN_USER	256 /* device-specific bins start here

Conversion Commands

Command	Description
CONVERT	Converts the file in the active window using the current convert options.
CONVERT-OPTION <i>option = value</i>	Specify the convert option and value.

Convert Options

Command	Description
AREA = <DISPLAY EXTENTS>	Specify convert area (display or extents).
SCALE = <0 1>	Converts the output file to the set scale. Set to 1 to enable scaling. Set to 0 to disable scaling. Default is 0.
SCALINGFACTOR = <value>	Specify a range from 0% to 100% . Default is 100%. Affects the scaling size when INI option SCALE = 1 (see previous option).
FORMAT = <i>format</i>	Where <i>format</i> specifies an output driver. Available output drivers: <ul style="list-style-type: none"> • PCRS_BMP: windows bitmap • PCRS_EPS: Encapsulated PostScript (raster) • PCRS_GP4: CALG Group IV Type 1 • PCRS_PCL: HP/PCL output • PCRS_PCX: Paintbrush PCX • PCRS_RLC: RLC format • PCRS_TIF: TIFF format • PC3D_STL: 3D format to STL
SUBFORMAT = <i>n</i>	Some of the output drivers support several subformats. The value n specifies which subformat to use.

PCRS_PCL	<p>HP/PCL output.</p> <p>Subformat: 0 - 75 DPI 1 - 150 DPI 2 - 300 DPI</p>
PCRS_TIF	<p>TIFF format.</p> <p>Subformat: 0 - Uncompressed 1 - Packbits compressed 2 - Group III compressed 3 - Group IV compressed</p>
OUTPUT = <i>filename</i>	<p>Specifies output filename. If not specified, the default name is used.</p>
PAGESIZE = <i>pagesize</i>	<p>For certain formats (e.g. plotter formats) the output size is specified as a page size. In this case, page size can be:</p> <p>A B C D E A4 A3 A2 A1 A0</p>
SIZE = <i>width height</i>	<p>Specifies the size of the converted output.</p> <p>See CONVERT OPTION PAGESIZE</p>
STEPSPERINCH = <i>n</i>	<p>Certain formats (e.g. plotter formats) allow a resolution factor to be set.</p>
UNITS = <INCH MM>	<p>Specifies the output units. This option applies only for vector output formats. Raster output units are always assumed to be in pixels.</p>

View Commands

Command	Description
ANTI-ALIAS <ON OFF>	Controls the anti-aliasing (scale-to-grey) for monochrome raster images.
BLOCK { <i>blockname</i> }	Displays the specified block. If no blockname is given, the Blocks dialog appears.
CONTRAST [LIGHT NORMAL DARK DARKEST]	Controls the contrast for monochrome raster images. The default setting is NORMAL.
FLIP <NONE HORZ VERT BOTH>	Flips the image as specified.
LAYER (ALL) <ON OFF>	Turns all layers either on or off.
LAYER < <i>layername1</i> {...} (ON OFF)>	Turns the specified layers on or off.
NAMEDVIEW { <i>viewname</i> }	Sets the view to the specified named view. If no viewname is given, the Named Views dialog appears.
PAGE n	Goes to the specified page.
PAGE-NEXT	Goes to the next page.
PAGE-PREV	Goes to the previous page.
PAN < <i>fromx fromy tox toy</i> >	Pans the image from (fromx, fromy) to (tox, toy), in World Coordinates.
PAN < <i>x-diff y-diff</i> >	Pans the image by the specified amount, in World Coordinates.
REFRESH	Redraws the image.
ROTATE <0 90 180 270>	Rotates the image by the specified amount.
SHELL { <i>command</i> }	Executes the specified command. If no command is given, starts a command shell.

TILEMODE <AUTO OFF ON>	This option only applies to AutoCAD drawings. Sets the tilemode to the value in the drawing file, or to Paperspace or Modelspace, respectively.
VPOINT <i>x y z</i>	Changes the viewpoint of a 3D image.
ZOOM <i>minx miny maxx maxy</i>	Zooms into the box specified by (minx, miny) (maxx, maxy). The values are given in World Coordinates. This command will set view extents without considering file scale and offset.
ZOOM <i>percent</i>	Zooms by the specified percentage.
ZOOM-FIT	Fits the image to the window.
ZOOM-FITHORZ	Fits the image horizontally.
ZOOM-FITVERT	Fits the image vertically.
ZOOM-FULLRES	This option only applies if the image being viewed is a raster file. Displays the image at full resolution.
ZOOM-INWORLD <i>minx miny maxx maxy</i>	Draw a zoom box using world (drawing) coordinates.

Markup Commands

Command	Description
MARKUP { <i>ID</i> }	Selects a Markup file to display over the current file. If no ID is given, displays the Select-Markup dialog.
MARKUPQUIT	Quits Markup mode.
MARKUPSETACTIVE <Extension of Markup to active>	Specify extension of the Markup to be made active. Example: 001, 002

Option Commands

Command	Description
OPTION MENU <ON OFF>	Indicates whether the top menu displays.
OPTION MENU DELETE < <i>N</i> >	Deletes the <i>N</i> th menu item. The menus are numbered from 0 to nMenus-1
OPTION MENUITEM DELETE < <i>N M</i> >	Deletes, disables or enables the <i>M</i> th menu item in the <i>N</i> th menu. Both the menus and menu items are numbered, starting at zero.
OPTION TOOLBAR <ON OFF>	Indicates whether the top toolbar displays.
OPTION STATUSBAR <ON OFF>	Indicates whether the status-bar area displays.
OPTION TEXT <ON OFF>	Indicates whether text displays.
OPTION LINSTYLES <ON OFF>	Indicates whether the linestyles display.
OPTION DIMENSIONS <ON OFF>	Indicates whether dimensions display.
OPTION FILLING <ON OFF>	Indicates whether filling displays.

OPTION XREF <ON OFF>	Indicates whether external references display.
OPTION RASTERDISPLAY <FULL FIT>	Sets the default for the initial display of raster files (at full resolution or fit to the window).
OPTION BASEFONT <i>fontname</i> {normal bold italic bold-italic} <i>pointsize</i>	Sets the default base font for text-and number-based files. This font is used if actual font is not specified in the file itself.
OPTION BGCOLOR { <i>red green blue</i> }	Sets the background color for the view window. Specify the color as an RGB triplet, each index ranging from 0 to 255.


Integration

Extend the functionality of your existing applications by integrating with AutoVue.

The added practicality will result in savings for both you and your organization in terms of time and money. To learn more, continue reading the contents of this chapter.

Defining Integration


Integration is a way of connecting an existing application – the host/server – with applications that have unique areas of expertise thereby enhancing the host application by expanding its abilities.



There are two main benefits of integration:

- **Interoperability:** AutoVue's technology enables you to share data and resources from a vast array of applications since AutoVue displays more than 450 different file formats.
- **A consistent user interface:** The existing software application's graphic interface is always present other than when the AutoVue graphic interface appears to provide the additional viewing capabilities. This minimizes retraining requirements since you only have to learn how to use the new abilities that have been merged with your existing software.

Integration is achieved via scripting, Object Linking and Embedding (OLE) automation, Dynamic Data Exchange (DDE) and Dynamic-Link Library (DLL). In addition, there are interfaces that can be used through Visual Basic and ActiveX technologies.



AutoVue currently allows you to view over 450 file formats including engineering, graphics and desktop file formats. In addition, you can mark up these files to communicate your ideas and observations. Often, to mark up a file it is necessary to recreate a file if you don't have a version of the authoring application. With AutoVue you can immediately mark up the document while preserving the original document since Markups are stored in their own file that is tightly linked to the original document. Another benefit is that external references are clearly visible on the active drawing and they are accessible just as with the original application.

Integrating with AutoVue

There are three ways to integrate AutoVue with various host applications:


- Using Oracle's out-of-the-box integrations available for most major document management systems. These are marketed under the name of VueLink.
- Performing a custom integration. Oracle's products are developed with an open API allowing for ease of custom integration with various host systems.
- Third party value-added integrations are available in several cases between some of the more popular document management systems on the market.

AutoVue integrates with all types of host systems including the following:

- DM (Document Management)

- EDM (Electronic Data Management)
- PDM (Product Data Management)
- TDM (Technical Data Management).
- ASPs (Application Service Providers) and corporate portals
- ERP (Enterprise Resource Planning)
- CMMS (Computerized Maintenance Management Systems)

An Application Integrated with a DMS



When AutoVue is integrated with a DMS, the documents and their associated Markup files are easily accessible for all individuals who have access to the DMS since files are registered in the DMS repository and are accessed through AutoVue's **File** menu. Markup files are returned to the DMS repository with AutoVue's **Save As** option. AutoVue is designed to work under established workflow procedures and its integration with DM, EDM and PDM systems supports access controls and different user privileges. Advanced features such as Master Markups and Consolidated Markups are also provided. Furthermore, AutoVue's Web plug-in enables access to literally thousands of sources of data.

- **Quick Viewing:** AutoVue is integrated with Windows Explorer to allow you to view numerous other file formats than would otherwise be available to you as a Windows user.

There are two types of integration that are immediately available after installing AutoVue on your system: DDE Integration and DLL Integration.

DDE Integration

DDE is a popular mechanism that allows applications to communicate with each other. Using DDE, the same commands that are available through scripting can be transmitted so that AutoVue can be dynamically controlled at runtime by an external application. AutoVue registers itself as a DDE server under the name “**AVWINSERVER.**” Commands should be sent using the topic “**SYSTEM.**”

A sample DDE C++ client application is provided in the AutoVue installation directory under the subdirectory `integrat\dde`.

The DDE Commands should be sent using the “**XTYP_EXECUTE**” method and data sent as text (**CF_TEXT**). The set of commands available is identical in syntax and semantics to those available for scripting and OLE Automation. For a full listing and description of the available scripting commands, see [AutoVue Command Summary](#).

DLL Integration

AutoVue’s API provides a DLL wrapper around its DDE interface. This allows programming languages that do not support DDE but are able to call exported Windows DLL functions to access AutoVue’s DDE functionality. Programmers who do not want to code low-level DDE client/server code can also use the DLL wrapper—the wrapper library handles the details.

The DLL wrapper comprises:

- **avlink.dll**: The wrapper DLL
- **avlink.lib**: The Microsoft-compatible import library for `avlink.dll`
- **avlink.h**: A C/C++ header file for the DLL entry points

The following entry points are defined:

Entry Point	Description
<code>#define PCALLBACK_far_pascal __export _loadds</code>	
<code>BOOL PCALLBACK AVLINK_Start(LPRECT rcPos)</code>	Starts up AutoVue, positioning AutoVue in the rectangle specified by <code>rcPos</code> .
<code>BOOL PCALLBACK AVLINK_End(void)</code>	Terminates AutoVue.

Entry Point	Description
BOOL PCALLBACK AVLINK_TransmitCommand(LPCSTR szCommand)	Sends the command, szCommand, to AutoVue. The same set of commands used in DDE can be used here.
BOOL PCALLBACK AVLINK_Activate(int nChild)	Activates the nth child window of AutoVue. Similar to the CHILD AVTIVATE command.
BOOL PCALLBACK AVLINK_Compare(LPCSTR szFileName)	Initiates a file comparison with the specified file. Similar to the FILE COMPARE command.
BOOL PCALLBACK AVLINK_Markup(LPCSTR szMarkupID)	Initates Markup mode. Similar to the MARKUP command.
BOOL PCALLBACK AVLINK_Overlay(LPCSTR szMarkupID)	Initates Markup mode. Similar to the OVERLAY command.
BOOL PCALLBACK AVLINK_Properties(void)	Displays the File Properties dialog.
BOOL PCALLBACK AVLINK_ShowWindow(BOOL fShow)	Shows/hides the AutoVue application.
BOOL PCALLBACK AVLINK_ShowViewWindow(BOOL fShow)	Shows/hide the active MDI child.
BOOL PCALLBACK AVLINK_View(LPC- STR szFileName)	Opens and views the specified file.

Sample DLL client applications in “C” and Visual Basic are provided in the AutoVue installation directory under the subdirectory **integrat\dlI**.

OLE Automation

OLE Automation is a popular successor to DDE. OLE Automation integration methods are available in a wide variety of products including Visual Basic and the Microsoft Office product line. It is a powerful, yet simple interface. Many developers use it since modules that are developed can be reused by other applications. Again, all the functionality that is available through Scripting and DDE is available through OLE Automation — in fact, the commands available are the same, making the transition from DDE/Scripting to OLE Automation a more straightforward task for programmers.

OLE Automation offers you the opportunity of taking OLE's integration capabilities one step further — you can now automate tasks as you would from a DDE script file, but from within your target or container application, using a simple macro language and pre-existing DDE script commands. OLE embedding, as provided by AutoVue, provides the end user with a great way to compose what is called compound documents using objects from a variety of different types. Still, that method of integration is fairly static, limiting its use to the production of presentation documents.

An OLE Automation client should connect to the object:

- **AutoVue.Application**

AutoVue's OLE Automation exposes two methods:

- **TransmitCommand** (“*command-string*”)
- **Execute** (“*command-string*”)

The methods are synonymous — either one can be used by the client application. The set of commands available is identical in syntax and semantics to that available for scripting and DDE. For a full listing and description of the available scripting commands, see **AutoVue Command Summary**

OLE Automation is ideally suited for the BASIC dialect used to program Microsoft Word or Excel, but is also easy to use with any OLE 2.0-compliant application. Let us look at an example of OLE automation using Microsoft Excel:

OLE Automation Example:

```
; Declare the OLE Automation Object
Dim OleObj As Object
; Function: Create the Ole automation object. Must be called once when your
program starts up.
Sub LoadOleObj()
    ' Create the OLE Automation Object
```

```

    Set OleObj = CreateObject("AutoVue.Application")
End Sub
; Function: Destroy the Ole automation object.
; Must be called once when your program exits. Performs necessary
; cleanups.
Sub UnloadOleObj()
    If (IsObject(OleObj)) Then
        ' Close the window
        OleObj.Execute ("CHILD CLOSE")
    End If
    ' Clean up
    Set OleObj = Nothing
End Sub
; Function: This sample function accessed
; to OLE Automation object and performs several operations.
; You should put in your own code here.
Sub ExecuteOleObj()
    If (IsObject(OleObj)) Then
        ' Copen file
        'OleObj.Execute ("FILE OPEN C:\AV19.1\samples\Desktop-
Office\Word.doc")
        OleObj.Execute ("FILE OPEN ""C:\AV19.1\samples\3d\3D
Compare\Component_V1\Component.SLDASM""")
        OleObj.Execute ("COMPARE ""C:\AV19.1\samples\3d\3D
Compare\Component_V2\Component.SLDASM""")

        ' Display window: The Application is, by default, hidden
        OleObj.Execute ("WINDOW SHOW")
        'OleObj.Execute ("CHILD SHOW")
        ' Display another file
        'OleObj.Execute ("FILE OPEN c:\autoexec.bat")
        ' Print the file
        ' OleObj.Execute ("PRINT")
        OleObj.Execute ("COMPARE ""C:\AV19.1\samples\3d\3D
Compare\Component_V2\Component.SLDASM""")
    End If
End Sub

```

Using this syntax, OLE automation can be achieved in an easy and seamless manner. For more information on the available commands refer to the section [AutoVue Command Summary](#).

Several sample OLE Automation applications are provided in the AutoVue installation directory under the subdirectory **integrat\oleauto**.

EDAT: Drawing Information Extraction

EDAT (Engineering Drawing Access Technology) is an OEM technology available from Oracle Corp. A limited subset of this technology is available through AutoVue allowing users to query CAD drawings (AutoCAD DWG, DXF and MicroStation DGN) and extract entity information (geometry/extended data/attribute tags).

AutoVue's User Interface under the **Analysis** menu contains three **Drawing Information** menu items:

- **Select Single Entity:** Allows the user to select an entity and displays detailed information about the entity in a dialog.
- **List Tags/Attributes:** Allows the user to select an entity and displays detailed information about the entity in a dialog.
- **Entity Information:** Allows the user to select a rectangle, and a dialog displays entity information for all entities contained in the rectangle.

AutoVue allows the user interface to be bypassed, namely the entity selection process and the dialog that appears. Instead the drawing-information query can be performed directly and the resulting data saved in a text file. This text file can later be used by the calling application.

For more information, refer to the topic "EDAT/Drawing Information Commands" in [AutoVue Command Summary](#). It describes three API commands: EDAT ATT, EDAT INFO and EDAT LIST.

VCET API

AutoVue is built using Cimmetry Systems's VCET (Viewing and Conversion Enabling Technology) library. VCET is the engine behind AutoVue that includes the file decoding/parsing technologies (PAFS), the rendering engines, the printing engines and the conversion engines. AutoVue itself is a user interface that sits on top of VCET. The VCET API is a Windows messaging-based API that is open, allowing developers to build custom interfaces (in the programming language of their choice). Further information on the VCET API can be found in the Docs directory of your AutoVue CD. Examples of integrations using the VCET API can be found in the Integrat directory of the AutoVue CD.

Markup API

AutoVue's Markup component is based on CSI's Markup Library Toolkit. Like VCET, it has a message-based API. Using the Markup API, developers can easily Markup-enable their applications. In addition to graphical Markup elements, the API also supports sticky-note objects and powerful hyperlinking features. In addition, the Markup file format used by AutoVue and the Markup Library Toolkit is fully documented, allowing developers to write custom import/export filters and to directly modify Markup elements. Used in conjunction with the VCET API, developers can quickly prototype and develop powerful viewing and Markup solutions that fit specific needs. Further information on the Markup API can be found in the Docs directory of your AutoVue CD. Examples of integrations using the Markup API can be found in the Integrat directory of the AutoVue CD.

AutoVue Command Summary

The description of AutoVue's command syntax follows certain conventions, which may vary from other parts of the Administrator Guide. The command summary that follows applies to AutoVue's Scripting, DDE, DLL and OLE Automation API's. A common scripting language is used for these methods of integration

Syntax Summary

Syntax	Description
<angular brackets>	Indicates required entries but are not to be included in the entered information.
{curly braces}	Indicates optional information.
[square brackets]	Required syntactical elements.
Bold	Introduces a literal expression which must be entered exactly as shown.
<i>Italics</i>	Indicates a variable which you must replace by information you provide.
	Indicates an either-or type of choice.
...	Indicates that information may be repeated.

General Commands

Command	Description
CHDIR { <i>directory_name</i> }	Changes working directory.
PAUSE { <i>nn</i> }	Pauses for <i>nn</i> milliseconds.
QUIT	Terminates application.

File Commands

Command	Description
VIEW { <i>filename</i> }	Displays the specified file. If no <i>filename</i> is supplied it displays the File-Open dialog.
FILE OPEN { <i>filename</i> }	Same as VIEW.

FILE-NEXT	Goes to the next file.
FILE-PREVIOUS	Goes to the previous file.
BROWSE	Activates the Browse dialog.
COMPARE { <i>filename</i> }	Compares the file in the active window with the file-name.
OVERLAY { <i>filename</i> { <i>x</i> , <i>y</i> { <i>scale</i> }}	Overlays the specified file over the current file (base drawing). The point (<i>x</i> , <i>y</i>) is the offset for the overlaid file expressed in base drawing units. The origin of raster images is in the top left, and for vector images it is in the bottom left. Scaling is the scaling factor for the overlay. Default values of (0.0, 0.0) and 1.0 are used for the base point and scaling factor.
PROPERTIES	Displays the Properties dialog.

View Commands

Command	Description
ANTI-ALIAS [ON OFF]	Controls the anti-aliasing (scale-to-gray) for monochrome raster images.
BLOCK { <i>blockname</i> }	Views the specified block. If no blockname is given, display the Blocks dialog.
CONTRAST [LIGHT NORMAL DARK DARKEST]	Controls the contrast for monochrome raster images. The default setting is NORMAL.
FLIP [NONE HORZ VERT BOTH]	Flips the image as specified.
LAYER ALL [ON OFF]	Turns all layers either ON or OFF.
LAYER [<i>layername</i>] { <i>layername2...</i> } [ON OFF]	Turns the specified layers ON or OFF.
NAMEDVIEW { <i>view_name</i> }	Sets the view to the specified named view. If no view-name is given, makes the Named Views dialog appear.
PAGE { <i>n</i> }	Goes the specified page.
PAGE-NEXT	Goes to the next page.
PAGE-PREV	Goes to the previous page.
PAN [<i>from-x from-y to-x to-y</i>]	Pans the image from (from-x, from-y) to (to-x, to-y), in World Coordinates.
PAN { <i>x-delta y-delta</i> }	Pans the image by the specified amount, in World Coordinates.
REFRESH	Redraws the image.
ROTATE [0 90 180 270]	Rotates the image by the specified amount.
SHELL { <i>command</i> }	Executes the specified command. If no command is given, start a command shell.

TILEMODE [AUTO OFF ON]	This option only applies to AutoCAD drawings. Set the tile mode to the value in the drawing file, or to Paperspace, or to Modelspace, respectively.
VPOINT { <i>x y z</i> }	Changes the viewpoint of a 3-D image.
ZOOM [<i>min-x min-y max-x max-y</i>]	Zooms into the box specified by (min-x, min-y) (max-x, max-y). The values are given in World Coordinates.
ZOOM [<i>percent</i>]	Zooms by the specified percent.
ZOOM-FIT	Fits the image to the window.
ZOOM-FITHORZ	Fits the image horizontally.
ZOOM-FITVERT	Fits the image vertically.
ZOOM-FULLRES	This option only applies if the image being viewed is a raster file. Displays the image at full resolution.

Printing Commands

Command	Description
PRINT	Using the current print options, print the file in the active window. See below for available print options.
PRINT-OPTION [<i>option = value</i>]	The next section describes available script options.

Print Options

Command	Description
AREA=[DISPLAY EXTENTS]	Specify print area (extents or display)
SCALE=[FIT <i>scale-factor</i>]	Specify scale factor.
UNITS=[INCH MM PIXEL]	Specify units.
LH=[<i>string</i>]	Left header text.
LH=[<i>string</i>]	Center header text.
RH=[<i>string</i>]	Right header text.
LF=[<i>string</i>]	Left footer text.
CF=[<i>string</i>]	Center footer text.
RF=[<i>string</i>]	Right footer text.

Conversion Commands

Command	Description
CONVERT	Converts the file in the active window using the current convert options. See below for available conversion options.

CONVERT-OPTION [*option* = *value*] The following section describes the available script options.

Convert Options

Command	Description
AREA=<DISPLAY EXTENTS>	Specify convert area (display or extents).
FORMAT=[<i>format</i>]	Where format specifies an output driver.
SUBFORMAT=[<i>n</i>]	Some of the output drivers support several sub-formats. The value n specifies which sub-format to use.
PAGES=<0 1 2>	Specify if you wish to convert All pages (0) (for TIFF only), Current Page (2) or range of pages (1).
ToPage n	Specify the range of pages to convert when PAGES=1.
OUTPUT=[<i>filename</i>]	Specifies output filename. If not specified, the default name is used.
SIZE=[<i>width height</i>]	Where format specifies an output driver. Specifies the size of the converted output.
STEPSPERINCH=[<i>n</i>]	Certain formats (e.g. plotter formats) allow a resolution factor to be set.
PAGESIZE=[<i>page-size</i>]	For certain formats (e.g. plotter formats) the output size is specified as a page size. In this case, page size can be one of: A, B, C, D, E, A4, A3, A2, A1, A0.
UNITS=[INCH MM]	Specifies the output units. This option applies only for vector output formats. Raster-output units are always assumed to be in pixels.

The following table summarizes the available formats and their sub-formats:

Format	Description
Sub-Format	Sub-Format Description
PCRS_BMP	Windows bitmap
PCRS_EPS	Encapsulated PostScript (raster)
PCRS_PCL	HP/PCL output
0	75 DPI
1	150 DPI
2	300 DPI
PCRS_PCX	Paintbrush PCX
PCRS_RLC	RLC Format
PCRS_TIF	TIFF Format
0	Uncompressed
1	Packbits compressed
2	Group III compressed
3	Group IV compressed

Markup Commands

Command	Description
MARKUP { <i>ID</i> }	Selects a Markup file to display over the current file. If no ID is given, displays the Select-Markup dialog.
MARKUPQUIT	Quits Markup mode.

Option Commands

Command	Description
OPTION MENU <ON OFF>	Indicates whether the top menu displays.
OPTION MENU DELETE < <i>N</i> >	Deletes the <i>N</i> th menu item. The menus are numbered from 0 to nMenus-1.
OPTION MENUITEM DELETE < <i>N M</i> >	Deletes, disables or enables the <i>M</i> th menu item in the <i>N</i> th menu. Both the menus and menu items are numbered, starting at zero.
OPTION TOOLBAR <ON OFF>	Indicates whether the top toolbar displays.
OPTION STATUSBAR [ON OFF]	Indicates whether the status-bar area displays.
OPTION TEXT [ON OFF]	Indicates whether text displays.
OPTION LINSTYLES <ON OFF>	Indicates whether the linestyles display.
OPTION DIMENSIONS [ON OFF]	Indicates whether dimensions display.
OPTION FILLING [ON OFF]	Indicates whether filling displays.
OPTION XREF [ON OFF]	Indicates whether external references display.
OPTION RASTERDISPLAY [FULL FIT]	Selects the default for the initial display of raster files (at full resolution or fit to the window).

OPTION BASEFONT <i>fontname</i> {normal bold italic bold-italic} <i>pointsize</i>	Selects the default base font for text- and number-based files. This font is used if the actual font is not specified in the file itself.
OPTION BGCOLOR { <i>red green blue</i> }	Sets the background color for the view window. Specify the color as an RGB triplet, each index ranging from 0 to 255.

Window Commands

These are the standard Windows messages. They apply to the frame window as a whole.

Command	Description
WINDOW HIDE	
WINDOW SHOW	
WINDOW POSITION	[x y {width height}]
WINDOW RESTORE	
WINDOW MINIMIZE	
WINDOW MAXIMIZE	
WINDOW TILE	
WINDOW CASCADE	

Child Commands

These are the standard Windows MDI child commands.

Command	Description
CHILD CLOSE	
CHILD HIDE	
CHILD MINIMIZE	
CHILD MAXIMIZE	
CHILD NEW	
CHILD POSITION [x y {width height}]	
CHILD RESTORE	
CHILD SELECT [n]	Activates the nth child window where n is a 1-indexed number.
CHILD SHOW	

EDAT/Drawing Information Commands

The following commands extract drawing information from CAD files (AutoCAD DWG, DXF and MicroStation DGN) and save the extracted data in a user-specified text file.

Command	Description
EDAT ATT [<i>filename</i> [x, y]]	Extracts Attribute/extended data/attribute tag information from the currently viewed document. If specified, the extracted data is stored in filename; otherwise a dialog displays the information. If the point (x,y) is specified, the entity closest the (x,y) in World Coordinates is queried. Otherwise, the user is prompted to select a point.

EDAT INFO [*filename [x, y]*]

Extracts detailed Entity information from the currently viewed document. If specified, the information is stored in filename, otherwise a dialog will display the information. If the point (x,y) is specified, the entity closest the (x,y) in World Coordinates is queried. Otherwise, the user is prompted to select a point.

EDAT LIST [*filename [x0, y0, x1,y1]*]

Extracts entity information for all entities contained within a bounding box from the viewed document. If specified, the extracted data is stored in filename; otherwise a dialog displays the information. If the bounding box (x0,y0 -> x1,y1) is specified then all entities contained in the bounding box, in World Coordinates are queried. Otherwise, the user is prompted to select a rectangle.

ActiveX Control

This section lists the following ActiveX controls for AutoVue:

- : [AutoVueX Control](#)
- : [AvMarkupX Control](#)
- : [AvPrintX Control](#)
- : [AutoVue CompareX Control](#)

For the most up-to-date information about these controls, refer to **autovuex.htm**.

AutoVueX Control

Properties

Property	Description
<i>BSTR</i> SRC	Source file path.
<i>boolean</i> ShowScrollBars	Flag that indicates whether or not to show Scroll-bars.
<i>boolean</i> ShowMainToolBar	Flag that indicates whether or not to show Main Toolbar.
<i>boolean</i> ShowAuxiiToolBar	Flag that indicates whether or not to show Auxiliary Toolbar.
<i>boolean</i> ShowStatusBar	Flag that indicates whether or not to show Status Bar.
<i>boolean</i> EnablePopupMenu	Flag that indicates whether or not to enable Popup Menu.
<i>boolean</i> MrkMainToolBar	Flag that indicates whether or not to show Markup MainToolBar.
<i>boolean</i> MrkPensToolBar	Flag that indicates whether or not to show Markup PensToolBar.
<i>boolean</i> MrkEntitiesToolBar	Flag that indicates whether or not to show Markup EntitiesToolBar.
<i>boolean</i> MrkColorsToolBar	Flag that indicates whether or not to show Markup ColorsToolBar.
<i>BSTR</i> MrkFileLocation	Directory where Markup files are stored.
<i>OLE_COLOR</i> BgColor	Background color.
<i>short</i> Rotate	Specifies current rotation value. Can be only 0,90, 180, 270.

<i>short</i> Flip	0 - No flipping 1 - Flip horizontal 2 - Flip vertical 3 - Flip both
<i>short</i> Page	Specifies current page.
<i>short</i> Extents	0 - Unchanged 1 - Fit 2 - Fit Width 3 - Custom

The following 4 properties are used to determine the extents:

Property	Description
<i>double</i> ExtMinX	Minimal X coordinate of extents
<i>double</i> ExtMinY	Minimal Y coordinate of extents
<i>double</i> ExtMaxX	Maximal X coordinate of extents
<i>double</i> ExtMaxY	Maximal Y coordinate of extents

Methods

Method	Description
<i>void SetContrast(long contrast Value)</i>	Set the image contrast to be the specific value; this only applies to raster files.
<i>void GetContrast()</i>	Return the image contrast value. The value for the raster file can be one of the following: CONTRAST_LIGHT (-50) CONTRAST_MEDIUM (0) CONTRAST_DARK (66) CONTRAST_DARKER (100)
<i>void SetAntiAlias()</i>	Scale to gray. Enhances the raster file image details that are viewed at less than 100% zoom.
<i>void ShowLayersDlg()</i>	Display the Layers dialog.
<i>void ShowBlocksDlg()</i>	Display the Blocks dialog.
<i>void ShowNamedViewsDlg()</i>	Display the named view dialog.
<i>void ShowXRefDlg()</i>	Display the XReference dialog.
<i>void ZoomFit()</i>	Zoom to fit.
<i>void ZoomPrevious()</i>	Undo last zoom operation.
<i>void ZoomWidth()</i>	Zoom to fit width.
<i>void ZoomHeight()</i>	Zoom to fit height.
<i>void ZoomByFactor(double factor)</i>	Zoom by factor.
Parameters	
factor	Zooming factor.
<i>void ZoomFullResolution()</i>	Displays rasters using full resolution; for other formats same as ZoomFit.
<i>void PrintIt (boolean bPrintDirect</i>	Print current document.
Parameters	

bPrintDirect	Flag indicating whether or not to show a dialog box to user.
<hr/>	
<i>void</i> PrintPreview (boolean bPreviewDirect,boolean bWantFrame)	Preview current document printing
Parameters	
bPreviewDirect	Flag indicating whether or not to show a dialog box to user.
bWantFrame	Flag for indicating whether or not to preview with frame.
<hr/>	
<i>void</i> SetPrintOptions (BSTR sEntry,BSTR sValue)	Set print options, call this method prior to call PrintIt or PrintPreview to set print options
Parameters	
sEntry : Currently the following options are supported:	Specify which print option to set.
PRINT_OPT_ORIENTATION	Set print page orientation.
PRINT_OPT_DISABLE_HEADERSFOOTERS	Disable/enable headers/footers print option.
PRINT_OPT_DISABLE_WATERMARK	Disable/enable watermark print option.
PRINT_OPT_DISABLE_MARGINS	Disable/enable margin print option.
PRINT_OPT_DISABLE_STAMPS	Disable/enable stamp print option
PRINT_OPT_DISABLE_PENSETTINGS	Disable/enable pen setting print option.
PRINT_OPT_DISABLE_PRINTTOFILE	Disable/enable print to file print option.
PRINT_OPT_DISABLE_PRINT	Disable/enable print function.
ALIGNMENT	Printing alignment.
PRINTOFFSETX	x offset when ALIGNMENT is set to "CUSTOM".

PRINTOFFSETY	y offset when ALIGNMENT is set to “CUSTOM”.
PRINTPAGEONLY	Disable/enable print only one page print option.
LH	Specify text for header left.
CH	Specify text for header center.
RH	Specify text for header right.
LF	Specify text for footer left.
CF	Specify text for footer center.
RF	Specify text for footer right.
sValue - Valid values are dependent on each specific print option entry.	Option values.
PRINT_OPT_ORIENTATION	PORTRAIT : Set print page orientation as portrait. LANDSCAPE : Set print page orientation as landscape.
PRINT_OPT_DISABLE_HEADERSFOOTERS	TRUE : Disable headers/footers print option. FALSE : Enable headers/footers print option.
PRINT_OPT_DISABLE_WATERMARKs	TRUE : Disable watermark print option. FALSE : Enable watermark print option.
PRINT_OPT_DISABLE_MARGINS	TRUE : Disable margin print option. FALSE : Enable margin print option.
PRINT_OPT_DISABLE_STAMPS	TRUE : Disable stamp print option. FALSE : Enable stamp print option.
PRINT_OPT_DISABLE_PENSETTINGS	TRUE : Disable pen setting print option. FALSE : Enable pen setting print option.
PRINT_OPT_DISABLE_PRINTTOFILE	TRUE : Disable print to file print option. FALSE : Enable print to file print option.
PRINT_OPT_DISABLE_PRINT	TRUE : Disable print function. FALSE : Enable print function.

ALIGNMENT	One of the following values: <ul style="list-style-type: none"> • CUSTOM • TOPLEFT • TOPCENTER • TOPRIGHT • MIDDLELEFT • CENTER • MIDDLERIGHT • BOTTOMLEFT • BOTTOMCENTER • BOTTOMRIGHT
PRINTOFFSETX	Value in print units.
PRINTOFFSETY	Value in printing units.
PRINTPAGEONLY	Disable/enable print only one page print option. 1 : Enable option 0 : Disable options
LH	Text for header left.
CH	Text for header center.
RH	Text for header right.
LF	Text for footer left.
CF	Text for footer center.
RF	Text for footer right.

<i>long</i> GetVcetHandle()	Return Value: Returns handle of the VCET window.
------------------------------------	---------------------------------------------------------

<i>boolean</i> EnterMarkupMode()	Enter Markup mode. Return Value: TRUE - entered Markup mode successfully FALSE - otherwise
-----------------------------------------	------------------------------------------------------------------------------------------------------------------------------

<i>boolean</i> ExitMarkupMode()	Exit Markup mode. Return Value: TRUE - exited Markup mode successfully FALSE - user canceled operation
----------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------

<i>IDispatch</i> * MrkObj()	Return Value: Returns pointer to AvMarkupX object if in Markup mode otherwise returns NULL
------------------------------------	---------------------------------------------------------------------------------------------------

<i>IDispatch</i> * PrnObj()	Return Value: Returns pointer to AvPrintX object if in Print Preview mode otherwise returns NULL
------------------------------------	---------------------------------------------------------------------------------------------------------

<i>short</i> GetMode()	Return Value: Returns current mode 0 - View mode 1 - Markup mode 2 - Print Preview mode
-------------------------------	----------------------------------------------------------------------------------------------------------------------------------

<i>void</i> PageNext()	Displays next page.
-------------------------------	---------------------

<i>void</i> PagePrevious()	Displays previous page.
-----------------------------------	-------------------------

<i>void</i> PageSelect()	Selects page number.
---------------------------------	----------------------

<i>boolean</i> GetMousePos (double* pPosX, double* pPosY)	Return Value: TRUE if mouse is in the window rectangle; FALSE otherwise
------------------------------------------------------------------	----------------------------------------------------------------------------------------------------

Parameters

*pPosX	X coordinate of mouse position
*pPosY	Y coordinate of mouse position

<i>void</i> ZoomInWorld (double MinX, double MinY, double MaxX, double MaxY)	Zoom box. The box is specified in world coordinate
-------------------------------------------------------------------------------------	----------------------------------------------------

Parameters

MinX	The x-coordinate of the low-left corner of a zoom box.
------	--------------------------------------------------------

MinY	The y-coordinate of the low-left corner of a zoom box.
MaxX	The x-coordinate of the upper-right corner of a zoom box.
MaxY	The y-coordinate of the upper-right corner of a zoom box.

boolean **SetLicenseFilePath** (BSTR sLic Path) Set path environment variable for AutoVueX OCX control.

Return Value:
TRUE if the path environment variable is set
FALSE - otherwise

Parameters

sLicPath The path where the AutoVueX OCX is located

boolean **EnableMarkup**(boolean fEnable) Enable or disable Markup function.

Return Value: The previous Markup status.

Parameters

fEnable Enable Markup if **TRUE**, disable it otherwise.

void **EnablePanMode**(boolean bEnable) Enable or disable Pan Mode

Parameters

bEnable Flag that indicates to turn on Pan Mode or not

long **GetNumCrossProbe Entities()** **Return Value:** Returns number of entities being cross-probed.

BSTR **GetCrossProbeEntityType** (long nIndex) **Return Value:** Returns a string that represents the internal type of the entity being cross-probed.

Parameters

nIndex Index of the entity being cross-probed.

<i>BSTR GetCrossProbeEntity Name</i> (long nindex)	Return Value: Returns a string that represents the internal name of the entity being cross-probed.
<i>void ClearCrossProbeEntities()</i>	Marks all the entities as not used for cross-probing.
<i>void AddCrossProbeEntity</i> (BSTR sType, BSTR sName)	Marks an entity as used for cross-probing.
Parameters	
sType	Internal type of the entity.
sName	Internal name of the entity.
<i>void ZoomSelected()</i>	Zoom fit to the selected entity/entities.
<i>void ShowNetConnectivity()</i>	Highlight all the graphical entities.
<i>long GetNumEcadEntities</i> (LPCTSTR sType)	Return the number of entities of a specified type that are present in the loaded document
Parameters	
sType	Entity type.
<i>BSTR GetEcadEntityName</i> (LPCTSTR sType, long indx)	Return the standard name of the indexed entity of the specified type.
Parameters	
sType	Entity type.
indx	Entity index.
<i>long GetEcadEntityNAttr</i> (LPCTSTR sType, long indx)	Return the number of attributes of the specified entity
Parameters	
sType	Entity type.
indx	Entity index.
<i>BSTR GetEcadEntityAttrName</i> (LPCTSTR sType, long indx, long j)	Return the name of the 'j'th attribute of the specified entity

Parameters

sType	Entity type.
indx	Entity index.
j	Entity's "j"th attribute.

BSTR GetEcadEntityAttrValue (LPCTSTR sType, long index, long j)
Return the value of the 'j'th attribute of the specified entity as a string.

Parameters

sType	Entity type.
indx	Entity index.
j	Entity's "j"th attribute.

long GetNumEcadEntityDefs() Return the number of entity definitions.

BSTR GetEcadEntityDefName(long indx)
Return the name of the indexed entity definition.

Parameters

indx	Entity index.
------	---------------

long GetEcadEntityDefFlags (long indx)
Return the flags of the indexed entity definition.

Parameters

indx	Entity index.
------	---------------

long GetEcadEntityDefNAttr (long indx)
Return the number of attributes of the indexed entity definition.

Parameters

indx	Entity index.
------	---------------

BSTR GetEcadEntityDefAttrName(long indx, long attr)
Return the name of the 'attr'th attribute of the indexed entity definition.

Parameters

indx	Entity index.
------	---------------

<i>attr</i>	“attr” th attribute.
-------------	----------------------

<i>long GetEcadEntityDefAttrFlags</i> (long indx, long attr)	Return the flags of the 'attr'th attribute of the indexed entity definition.
Parameters	
<i>indx</i>	Entity index.
<i>attr</i>	“attr” th attribute.

<i>long GetEcadEntityDefAttrType</i> (long indx, long attr)	Return the type of the 'attr'th attribute of the indexed entity definition.
Parameters	
<i>indx</i>	Entity index.
<i>attr</i>	“attr” th attribute.

<i>void ShowEntityTypeFilterDlg()</i>	Show Entity Type Filter dialog.
---------------------------------------	---------------------------------

<i>void ShowVerifyDesignDlg()</i>	Show Verify Design dialog.
-----------------------------------	----------------------------

<i>void ShowEntityBrowserDlg()</i>	Show Entity Browser dialog.
------------------------------------	-----------------------------

<i>void ShowBillOfMaterialDlg()</i>	Show Bill of Material dialog.
-------------------------------------	-------------------------------

<i>void ShowEntityPropertiesDlg()</i>	Show Entity Properties dialog.
---------------------------------------	--------------------------------

<i>void ShowFileVersionInfoDlg()</i>	Show File Version Information dialog.
--------------------------------------	---------------------------------------

<i>void SetPageByTitle</i> (BSTR sTitle)	Set the page by Title.
Parameters	
<i>sTitle</i>	Title of the page.

<i>void SetNamedView</i> (long lIndex)	Set Named views.
Parameters	
<i>lIndex</i>	Named view index.

<i>void SetNamedViewByName</i> (BSTR sName)	Set Named view by names.
Parameters	

sName	Name of the view.
<i>void ShowImportDesignDlg()</i>	Show Import Design dialog.
<i>void EnableZoomBoxMode</i> (boolean bEnable)	Enable zoom (box) mode.
Parameters	
bEnable	<p>TRUE: For non-3D file format, it will force to exit from pan or magnify mode. Enable zoom mode (zoom mode is default in non-3D file formats). For 3D file formats it will force to enter the zoom mode</p> <p>FALSE: For non-3D file format, it will not perform any action. For 3D file formats, exit zoom mode and enter rotate mode (rotate mode is default for 3D file formats).</p>
<i>void EnableRotateMode</i> (boolean bEnable)	Enable the rotate mode. Works only for 3D file formats
Parameters	
bEnable	<p>TRUE: Enter the rotate mode, will force to exit zoom, pan or spin modes.</p> <p>FALSE: No action.</p>
<i>void ReCenter</i> (short nType)	Applicable to 3D file formats only, re-center the complete drawing or selected entity based on “nType”.
Parameters	
nType	<p>0 - Re-center the complete drawing. 1 - Re-center the selected drawing. 2 - Re-center the entity.</p>
<i>void ShowPMIFilteringDlg()</i>	Applicable to 3D file formats only. Show the PMI Filter dialog.
<i>void ShowLightingDlg()</i>	Applicable to 3D file formats only. Show the lighting dialog.

<i>void ShowDefineSectionDlg()</i>	Applicable to 3D file formats only. Show the Define section dialog
<i>void ShowUserCoordSystems Dlg()</i>	Applicable to 3D file formats only. Show the User coordinate systems dialog
<i>void EnableManipulators</i> (boolean bEnable)	Applicable to 3D file formats only. Enable/Disable the manipulator.
Parameters	
bEnable	TRUE: Enable the manipulator (if already active, then no action). FALSE: Disable the manipulator (if already disabled, then no action).
<i>void ShowPartAlignmentDlg()</i>	Applicable to 3D file formats only. Show the Part Alignment dialog.
<i>void ShowModelTransformDlg()</i>	Applicable to 3D file formats only. Show the Model Transform dialog.
<i>void ResetTransformation()</i>	Applicable to 3D file formats only. Reset transformation.
<i>void ShowInterferenceCheck Dlg()</i>	Applicable to 3D file formats only. Show the Interference Check dialog.
<i>long SelectOverlay()</i>	Opens a dialog that allows a file to be selected and added as an overlay. Returns the overlay ID, if successful, or -1 if the operation was cancelled
<i>long AddOverlay</i> (BSTR sFileName)	Adds sFileName as an overlay. Returns the overlay ID, if successful, or -1 if the operation failed.
<i>boolean RemoveOverlay</i> (long ID)	Removes the overlay with id = ID. Returns "true", if successful, or "false" if the operation failed.
<i>long RemoveOverlays()</i>	Removes all existing overlays.

<i>long</i> LoadOverlay (BSTR sFileName, double x, double y, double scale, boolean positionByUser, boolean sizeByUser)	Adds sFileName as an overlay using the supplied parameters. Returns the overlay ID if successful, or -1 if the operation failed.
Parameters	
x,y	The coordinates of the top-left corner of the new overlay.
scale	The scale of the new overlay.
positionByUser	If true , the user will interactively specify the top-left corner of the overlay (position the overlay).
sizeByUser	If true , the user will interactively specify the scale for the overlay (resize the overlay).

<i>boolean</i> SetOverlayParameters (int ID, double x, double y, double scale, boolean positionByUser, boolean sizeByUser)	Sets overlay parameters for the specified overlay ID. For parameters description see LoadOverlay .
-----------------------------------------------------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------

<i>boolean</i> GetOverlayFileName (int ID)	Returns the filename of the overlay with specified ID.
---------------------------------------------------	--------------------------------------------------------

<i>double</i> GetOverlayPosX (int ID)	Returns the X coordinate of the top-left corner of the overlay with specified ID.
----------------------------------------------	-----------------------------------------------------------------------------------

<i>double</i> GetOverlayPosY (int ID)	Returns the Y coordinate of the top-left corner of the overlay with specified ID.
----------------------------------------------	-----------------------------------------------------------------------------------

<i>double</i> GetOverlayScale (int ID)	Returns the scale of the overlay with specified ID.
-----------------------------------------------	-----------------------------------------------------

<i>BSTR</i> GetOverlayParameters (int ID, double* x, double* y, double* scale)	Returns information about the overlay with specified ID. File name is returned as a result from this function, top-left position and scale are set if pointers to the corresponding variables are passed.
---------------------------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

boolean **DumpModelTree**(BSTR fileName) Exports the data contained in the current model tree to the specified XML file.
Return Value:
 TRUE if the file could be written, FALSE otherwise.

Parameters

fileName	Output filename.
----------	------------------

long **ShowConvertDialog()** Displays Conversion dialog.

void **ConvertIt()** Perform conversion based on the setting previously saved in **avx.ini**.

void **SetConvertOptions**(string sEntry, string sValue1, string2 sValue2) Save conversion settings into **avx.ini**.

Parameters

sEntry	Option name.
sValue1	Option value.
sValue2	Additional option value. It is used just for PAGESIZE. Must be the empty string for all other options.

Options

- AREA <string>
DISPLAY | EXTENTS | ALL |SELECTED
- FORMAT <string>
PCRS_BMP | PCRS_EPN | PCRS_EPS | PCRS_GP4 |
PCRS_IBM | PCRS_PCL | PCRS_PCX | PCRS_RLC |
PCRS_TIF | PC3D_STL
- SUBFORMAT <integer>
- OUTPUT <filename as string>
- SIZE <width as integer> <height as integer>
- STEPSPERINCH <integer>

- PAGESIZE <size as string>
A | B | C | D | E | A4 | A3 | A2 | A1 | A0
- UNITS <unit as string>
INCH | MM
- SCALE <scale as integer>%
- COLORDEPTH
ORIGINAL | <number as integer>
- PAGERANGE
<from_page as integer>-<to_page as integer>
- STL_POSITIVE_TRIANGLES
ON | OFF

boolean **Export3DBom**(BSTR file-Name) Export 3D BOM (Bill of Material) as text file.
Return Value:
TRUE if the file could be written, FALSE otherwise.

Parameters

fileName Output filename.

boolean **ExportEdaBom**(BSTR sFileName, BSTR sFormat, boolean bCurPage, BSTR sAttributes) Export EDA BOM (Bill of Material) as text file.
Return Value:
TRUE if the file could be written, FALSE otherwise.

Parameters

sFileName Output filename.

sFormat Export format, one of two values "PDX" or CSV". If nothing is specified, "CVS" is used.

bCurPage If BOM should be calculated for current page only or for all pages.

sAttributes List of attributes used to calculate the BOM (separated by ","). If nothing is specified, default list of attributes will be used.

<i>void</i> ShowExplodeDialog()	Show 3D Explode dialog. Show the 3D explode dialog. Applicable to 3D file formats only.
<i>void</i> Show3DSearchDialog()	Show 3D Search dialog. Applicable to 3D file formats only.
<i>bool</i> SaveViewStateToFile (BSTR sFileName)	Save the current view state into an external file. Return Value: TRUE if the function succeeds, FALSE - otherwise.
Parameters	
sFileName	Output filename.
<i>bool</i> RestoreViewStateFromFile (BSTR sFileName)	Restore the view state from an external file and apply it. Return Value: TRUE if the function succeeds, FALSE - otherwise.
Parameters	
sFileName	Input filename.
<i>long</i> GetNumPages ()	Obtain number of pages for the currently opened file. Return Value: Number of pages
BSTR GetEcadDesignName (in nPage)	Obtain design name of a page in the EDA document. Return Value: Name of the design of the given page
Parameters	
nPage	'1' based page index.

BSTR GetEcadDesignPage Type (int nPage) Obtain design page type of a page in the EDA document.

Return Value:

Design type of the given page. Can be the following possible values:

- “PCB” – PCB Layout
- “SCH” – Schematic design
- “PCB3D” – PCB 3D View

Parameters

nPage ‘1’ based page index.

BSTR GetEcadDesignPage Name (int nPage) Obtain page name of an EDA document.

Return Value:

Name of the given page

Parameters

nPage ‘1’ based page index.

long **GetNumCrossProbeHits** () Obtain number of Crossprobe “hits” generated by the previous call to AddCrossProbeEntity.

Return Value:

Number of Crossprobe “hits”.

void **ShowCrossProbeHit** (long nIndex) Instruct AutoVueX to display a Crossprobe “hit”.

Parameters

nIndex Index of the Crossprobe “hit”. Has to be between 0 and value returned by GetNumCrossProbeHits,

Events

Event	Descriptions
<p><i>void</i> ModeChanged(short nOldMode, short nNewMode)</p> <p>Parameters</p> <p>nOldMode</p> <p>nNewMode</p>	<p>Fired when modes changes.</p> <p>OldMode value (see GetMode method for values).</p> <p>NewMode value (see GetMode method for values).</p>
<p><i>void</i> StatusChanged(short nNewStatus)</p> <p>Parameters</p> <p>nNewStatus</p>	<p>Fired when status changes.</p> <p>New status value:</p> <ul style="list-style-type: none"> • STATUSIDLE = 0x00 • STATUSPROCESSING = 0x01 • STATUSREADING = 0x02 • STATUSREPFRESHING = 0x04 • STATUSREGENERATING = 0x08 • STATUSREADINGFINISHED = 0x10
<p><i>void</i> HelpString(BSTR szMsg)</p> <p>Parameters</p> <p>szMsg</p>	<p>Help String for status indicator.</p> <p>Help message.</p>
<p><i>void</i> ExtentsChanged(double extMinX, double extMinY, double extMaxX, double extMaxY)</p> <p>Parameters</p> <p>extMinX, extMinY, extMaxX, extMaxY</p>	<p>Fired when extents change internally (not when properties change).</p> <p>New extents' values.</p>
<p><i>void</i> PageChanged(short nNewPage)</p>	<p>Fired when page changes internally.</p>

Event	Descriptions
Parameters	
nNewPage	New page value.
<i>void</i> RotateChanged (short nNewRotate)	Fired when rotate values changes internally.
Parameters	
nNewRotate	New rotate value.
<i>void</i> FlipChanged (short nNewFlip)	Fired when flip value changes internally.
Parameters	
nNewFlip	New flip value.
<i>void</i> OnLMButtonDown (double xPos, double yPos)	Fired when left mouse button is pressed down.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnLMButtonUp (double xPos, double yPos)	Fired when left mouse button is released.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnLMButtonDbClick (double xPos, double yPos)	Fired when left mouse button is double-clicked.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnRMButtonDown (double xPos, double yPos)	Fired when right mouse button is pressed down.

Event	Descriptions
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnRMBButtonUp (double xPos, double yPos)	Fired when right mouse button is released.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnRMBButtonDbIClk (double xPos, double yPos)	Fired when right mouse button is double-clicked.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnMMButtonDown (double xPos, double yPos)	Fired when middle mouse button is pressed down.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnMMButtonUp (double xPos, double yPos)	Fired when middle mouse button is released.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void</i> OnMMButtonDbIClk (double xPos, double yPos)	Fired when middle mouse button is double-clicked.
Parameters	

Event	Descriptions
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void OnMouseMove</i> (double xPos, double yPos)	Fired when mouse gets moved.
Parameters	
xPos	Horizontal mouse position.
yPos	Vertical mouse position.
<i>void OnNewDocument</i> (BSTR szFileName)	Fired when new file is loaded.
Parameters	
szFileName	New filename.
<i>void CrossProbeEvent</i> (shortN-EventType)	Fired when cross-probe event occurred.
Parameters	
nEventType	0 - Change in entity selections 1 - Zoom Selected command being invoked 2 - Show net connectivity command being invoked
<i>void BasefileHperlinkEvent</i> (short-NEventType, short nArg1, BSTR szArg2)	Fired when any of the events in the table below occur due to a hyperlink.

Parameter	nEventType	nArg1 (short)	nArg2 (BSTR)
Set Page	0	Page Index	"" (not used)
Set Page by title	1	0 (not used)	Title

Rotate	2	Degree (possible values: 0, 90, 180, 270)	"" (not used)
Flip	3	Flip setting: 0 - none 1 - Horizontal flip 2 - Vertical flip 3 - Both	"" (not used)
Zoom fit	4	0 (not used)	"" (not used)
Zoom by factor	5	Factor	"" (not used)
Set view	6	View index	"" (not used)
Set view by name	7	0 (not used)	View name

AvMarkupX Control

Properties

Property	Description
<i>long</i> EntityColor	Current EntityColor (COLORREFvalue)
<i>long</i> PenStyle	Current Pen Style
<i>long</i> LineWidth	Current line Width

Methods

Method	Description
<i>void</i> TestMarkup(BSTRsz File-Name)	Load specified file and enter Markup mode (for testing purposes).
Parameters	
szFileName	File to load.
<i>void</i> Open()	Opens Markup file.
<i>boolean</i> OpenMarkup(BSTR sFileName, boolean bCloseAll)	Open specified markup file. Return Value: TRUE - success FALSE - otherwise
Parameters	
szFileName	Markup file name to open bCloseAll. True: Close all existing markup files. False: otherwise
<i>boolean</i> EnterMarkupmode (OLE_HANDLE hVcetControl)	Enter Markup mode. Return Value: TRUE - success FALSE - otherwise
Parameters	

hVcetControl	Handle of the VCET control window.
--------------	------------------------------------

<i>long</i> NotifyProc (<i>long</i> msg, <i>long</i> wParam, <i>long</i> lParam)	Called by VCET control notify procedure. Return Value: Message specific.
------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------

Parameters

msg	Message to process.
wParam	Message WPARAM.
lParam	Message LPARAM.

<i>void</i> Save()	Save current Markup in file.
---------------------------	------------------------------

<i>void</i> SaveAs()	Save current Markup under new name.
-----------------------------	-------------------------------------

<i>void</i> DrawLine()	Draw line entity.
-------------------------------	-------------------

<i>void</i> DrawArc()	Draw arc entity.
------------------------------	------------------

<i>void</i> DrawBox()	Draw box entity.
------------------------------	------------------

<i>void</i> DrawCircle()	Draw Circle entity.
---------------------------------	---------------------

<i>void</i> DrawFilledBox()	Draw filled box entity.
------------------------------------	-------------------------

<i>void</i> DrawFilledCircle()	Draw filled circle entity.
---------------------------------------	----------------------------

<i>void</i> DrawFilledPolygon()	Draw filled polygon entity.
----------------------------------------	-----------------------------

<i>void</i> DrawLeader()	Draw leader entity.
---------------------------------	---------------------

<i>void</i> DrawFreeStyle()	Draw free style entity.
------------------------------------	-------------------------

<i>void</i> DrawCloud()	Draw cloud entity.
--------------------------------	--------------------

<i>void</i> DrawText()	Draw Text entity.
-------------------------------	-------------------

<i>void</i> DrawHighlight()	Draw highlight entity.
------------------------------------	------------------------

<i>void</i> DrawNote()	Draw Note entity.
-------------------------------	-------------------

<i>void</i> DrawSymbol()	Draw Symbol entity.
---------------------------------	---------------------

<i>void</i> DrawOLE()	Draw OLE object entity.
------------------------------	-------------------------

<i>boolean</i> IsCurrentEntity (long nEntId, long nSubType, long nFillType)	Return Value: Returns whether the specified entity is current or not.
Parameters	
nEntId	The entity ID.
nSubType	The sub type of the entity.
nFillType	Entity fill type.
<i>void</i> ModifyLayers ()	Display Modify Markup Layers dialog.
<i>void</i> ModifyFont ()	Display Modify Font dialog.
<i>void</i> Undo ()	Undo last Markup operation.
<i>void</i> Redo ()	Redo last cancelled Markup operation.
<i>boolean</i> IsUndoAvailable ()	Return Value: Returns whether there is an operation to undo or not.
<i>boolean</i> IsRedoAvailable ()	Return Value: Returns whether there is an operation to redo or not.
<i>boolean</i> ExitMarkupMode ()	Exit Markup mode. Return Value: TRUE - exit successful FALSE - user cancelled operation
<i>long</i> GetControlHandle ()	Return Value: Returns handle of the Markup control window.
<i>void</i> MeasureDistance ()	Measure distance between two points.
<i>void</i> MeasureCumDistance ()	Measure cumulative distance.
<i>void</i> MeasureArea ()	Measure area.
<i>void</i> Calibrate ()	Currently unsupported.
<i>void</i> ZoomFit ()	Zoom to fit.
<i>void</i> Rotate (short nDegrees)	Rotate Markups.

Parameters

nDegrees	Rotation value, can be only 0, 90, 180 or 270.
----------	------------------------------------------------

<i>void</i> Flip (short nFlag)	Flip Markups.
---------------------------------------	---------------

Parameters

nFlag	Flipping value.
-------	-----------------

0	No flipping.
---	--------------

1	Flip horizontal.
---	------------------

2	Flip vertical.
---	----------------

3	Flip both.
---	------------

<i>boolean</i> ResetAction()	Reset current action. Return Value: TRUE - if action was reset from adding entity to none FALSE - otherwise
-------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------

<i>void</i> ShowInfo()	Show Markup information.
-------------------------------	--------------------------

<i>void</i> CreateNew()	Open new Markup.
--------------------------------	------------------

<i>void</i> SetFgBgColor (boolean fBackGroundColor, long color)	
------------------------------------------------------------------------	--

Parameters

fBackgroundColor	TRUE/FALSE
------------------	------------

color	RGB color value.
-------	------------------

<i>void</i> DeleteSelEntities()	Delete selected Markup entities.
----------------------------------------	----------------------------------

<i>boolean</i> CopyToClipboard()	Copy selected Markup entities to clipboard. Return Value: TRUE - if action was successful FALSE - otherwise
-----------------------------------------	-------------------------------------------------------------------------------------------------------------------------------------------

<i>boolean</i> PasteFromClipboard()	Paste Markup entities from clipboard into current active Markup. Return Value: TRUE - if action was successful FALSE - otherwise
--------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------

<i>void</i> OnMarkupConsolidate()	Generate consolidated Markup from current loaded Markups.
------------------------------------------	-----------------------------------------------------------

<i>void</i> OnModifyMarkupOnOff()	Toggle - show/hide Markups.
------------------------------------------	-----------------------------

<i>long</i> GetFillStyle()	Get current fill style. Return Value: 0 - No fill 1 - Solid fill 2 - Transparent fill
-----------------------------------	----------------------------------------------------------------------------------------------------------

<i>void</i> SetFillStyle(long nNewValue)	Set current fill style.
Parameters	
nNewValue	0 - No fill 1 - Solid fill 2 - Transparent fill

<i>long</i> GetCtlSnapType()	Get current snap type. Return Value: <ul style="list-style-type: none"> • 0x00000001 - MRK_SNAPTO_NONE • 0x00000002 - MRK_SNAPTO_VERTEX • 0x00000004 - MRK_SNAPTO_EDGE • 0x00000008 - MRK_SNAPTO_MID-EDGE • 0x00000010 - MRK_SNAPTO_ARC-CENTER • 0x00000020 - MRK_SNAPTO_FACE • combination of all above snap types – MRK_SNAPTO_ALL
-------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<i>long</i> SetCtlSnapType(long dwSnapType)	Set current snap type.
Parameters	

`dwSnapType`

Takes one of the following values:

- 0x00000001 - MRK_SNAPTO_NONE
- 0x00000002 - MRK_SNAPTO_VERTEX
- 0x00000004 - MRK_SNAPTO_EDGE
- 0x00000008 - MRK_SNAPTO_MID-EDGE
- 0x00000010 - MRK_SNAPTO_ARC-CENTER
- 0x00000020 - MRK_SNAPTO_FACE
- combination of all above snap types - MRK_SNAPTO_ALL

short **GetAction()**

Get current Markup control action.

Return Value:

- 0 - MRKP_ACTION_NONE
- 1 - MRKP_ACTION_ADD
- 2 - MRKP_ACTION_DEL
- 3 - MRKP_ACTION_COPY
- 4 - MRKP_ACTION_EDIT
- 5 - MRKP_ACTION_MOVE
- 6 - MRKP_ACTION_SEL
- 7 - MRKP_ACTION_HYBRID

void **SetAction(short nAction)**

Set current Markup control action.

Parameters

`nAction`

Takes one of the following values:

- 0 - MRKP_ACTION_NONE
- 1 - MRKP_ACTION_ADD
- 2 - MRKP_ACTION_DEL
- 3 - MRKP_ACTION_COPY
- 4 - MRKP_ACTION_EDIT
- 5 - MRKP_ACTION_MOVE
- 6 - MRKP_ACTION_SEL
- 7 - MRKP_ACTION_HYBRID

void **Draw3DVertexCoord()**

Draw 3d vertex coordinates entity.

void **Draw3DDistance()**

Draw 3D measurement distance entity.

void **Draw3DArc()**

Draw 3D measurement arc entity.

void **Draw3DAngle()**

Drawing 3D measurement angle entity.

<i>void</i> EditText()	Edit a text entity in the currently opened Markups.
<i>void</i> EditNote()	Edit a note entity in the currently opened Markups.
<i>void</i> EditDimensions()	Edit a 3D dimension entity (including distance, arc, angle and vertex coordinates) in the currently opened Markup.
<i>void</i> HideDimensions()	Hide all 3D dimension entities in the currently opened Markups.
<i>void</i> DeleteDimensions()	Delete all 3D dimension entities in the currently opened Markups.
<i>boolean</i> IsThisEntityAvailable (short nEntityID)	Determines if the given entity is available. Return Value: TRUE - if entity is available FALSE - otherwise
Parameters	
nEntityID	The entity ID.
<i>boolean</i> IsThisEntityType Available (short nEntityType)	Determines if any entity of the specified type actually exists in the currently opened Markups. Return Value: TRUE - if there is at least one entity of this type FALSE - otherwise
Parameters	
nEntityType	The entity type.
<i>boolean</i> IsThisEntitySelected (short nEntityType)	Determines if any entity of the specified type is selected in the currently opened Markups. Return Value: TRUE - if at least one entity is selected FALSE - otherwise
Parameters	
nEntityType	The entity type.

boolean **IsEntityType Hidden** (short nEntityType) Determines if any entity of the specified type is hidden in the currently opened Markups.

Return Value:

TRUE - if at least one entity is hidden
 FALSE - otherwise

Parameters

nEntityType The entity type.

long **GetEntityPageIndex**(long handle) Get the page index to which the Markup entity belongs to.

Return Value:

0 based page index.

Parameters

handle The entity handle

boolean **IsEntityEditable**(long handle) Determine if the given entity is editable.

Return Value:

TRUE - if the entity is editable
FALSE - otherwise

Parameters

handle The entity handle.

void **EditEntity**(long handle) Edit the given entity.

Parameters

handle The entity handle.

short **GetEntityLineStyle**(long handle) Get the line style of the given entity.

Return Value:

- 0 - MRK_PENSTYLE_SOLID
- 1 - MRK_PENSTYLE_DASH
- 2 - MRK_PENSTYLE_DOT
- 3 - MRK_PENSTYLE_DASHDOT
- 4 - MRK_PENSTYLE_DASHDOTDOT
- 5 - MRK_PENSTYLE_HOLLOW
- 6 - MRK_PENSTYLE_ARC
- 7 - MRK_PENSTYLE_TRIANGLE

Parameters

handle	The entity handle.
<i>short</i> GetEntityLineWidth (long handle)	Get the line width of the given entity. Return Value: The line width in pixels.
Parameters	
handle	The entity handle.
<i>long</i> GetSelCount ()	Get the number of the selected entities in the currently opened Markups. Return Value: The number of the selected Markup entities.
<i>void</i> RotateRelative (short nDegrees)	Rotate markup control together with base file
Parameters	
nDegrees	Rotation angle in degree, can be only 0, 90, 180, 270.
<i>short</i> IsThisMarkupVisible (long nMrkIndex)	Check if the given markup is visible. Return Value: TRUE if the given markup is visible. FALSE otherwise.
Parameters	
nMrkIndex	The markup index
<i>short</i> ShowThisMarkup (long nMrkIndex, boolean bShow)	Show or hide the given markup.
Parameters	
nMrkIndex	The markup index
bShow	TRUE if show the markup, otherwise FALSE.

AvPrintX Control

Properties

No properties.

Methods

Method	Descriptions
<p><i>void</i> PrintIt (OLE_HANDLE hVcetControl,OLE_HANDLE hMarkupControl, boolean bPrintDirect)</p> <p>Parameters</p> <p>hVcetControl</p> <p>hMarkupControl</p> <p>bPrintDirect</p>	<p>Print file along with Markups.</p> <p>Handle of the VCET control window (must not be NULL)</p> <p>Handle of the Markup control window (can be NULL).</p> <p>Flag that indicates whether to show a dialog to user or not.</p>
<p><i>void</i> PrintFile (BSTR szFileName,boolean bPrintDirect)</p> <p>Parameters</p> <p>szFileName</p> <p>bDirectPrint</p>	<p>Prints specified file.</p> <p>Filename to print.</p> <p>Flag indicating whether or not to show a dialog to user.</p>
<p><i>void</i> PrintPreview (OLE_HANDLE hVcetControl, OLE_HANDLE hMarkupControl, boolean bPreviewDirect, boolean bWantFrame)</p> <p>Parameters</p> <p>hVcetControl</p> <p>hMarkupControl</p>	<p>Enter Print Preview mode.</p> <p>Handle of the VCET control window (must not be NULL).</p> <p>Handle of the Markup control window (must not be NULL).</p>

Method	Descriptions
bPreviewDirect	Flag that indicates whether to show a dialog to user or not bWantFrame - flag for preview with frame or not.
<i>void</i> PrintPreviewFile (BSTR szFileName, boolean bPreviewDirect, boolean bWantFrame)	Enter Print Preview mode for specified file.
Parameters	
szFileName	Filename to preview.
bPreviewDirect	Flag that indicates whether to show a dialog to user.
bWantFrame	Flag for indicating preview with frame.
<i>void</i> PreviewPrint()	In Print Preview window - send Print command.
<i>void</i> PreviewNextPage()	In Print Preview window - go to next page.
<i>void</i> PreviewPrevPage()	In Print Preview window - go to previous page.
<i>void</i> PreviewNumPage()	In Print Preview window - switch between 1 and 2 page display.
<i>void</i> PreviewZoomIn()	In Print Preview window - zoom in.
<i>void</i> PreviewZoomOut()	In Print Preview window - zoom out.
<i>void</i> PreviewClose()	Close Print Preview window.
<i>void</i> SetPrintPageOrientation (boolean bLandscape)	Set page orientation for printing.
Parameters	
bLandscape	True if print as landscape, otherwise as portrait.
<i>void</i> EnablePrintOptions (short nOption, boolean bEnable)	Enable/disable a print option.

Method	Descriptions
Parameters	
nOption	Takes one of the following values: 0 - PRINTOPT_GENERAL 1 - PRINTOPT_HEADERSFOOTS 2 - PRINTOPT_WATERMARK 3 - PRINTOPT_MARGINS 4 - PRINTOPT_STAMPS 5 - PRINTOPT_PENSETTINGS 6 - PRINTOPT_PRINTTOFILE 7 - PRINTOPT_PRINTSETTINGS

Events

Event	Description
<i>void</i> EndPrintPreview()	Fired when user closes Print Preview window.
<i>void</i> EndPrint()	Fired when finished printing.

AutoVue CompareX Control

Properties

Property	Descriptions
<i>BSTR</i> File1	First source filepath.
<i>BSTR</i> File2	Second source filepath.
<i>boolean</i> ShowScrollBar	Flag indicating whether or not to show Scrollbar.
<i>boolean</i> ShowMainToolBar	Flag indicating whether or not to show Main toolbar.
<i>boolean</i> ShowAuxiliaryToolBar	Flag indicating whether or not to show Auxiliary toolbar.
<i>boolean</i> ShowStatusBar	Flag indicating whether or not to show Status bar.
<i>boolean</i> EnablePopupMenu	Flag indicating whether or not to enable Popup menu.
<i>OLE_COLOR</i> CtlBgColor	Background color.
<i>short</i> Rotate	Specifies current rotation value. Can be only 0, 90, 180, 270.
<i>short</i> Flip	0 - No flipping 1 - Flip horizontal 2 - Flip vertical 3 - Flip both

Property	Descriptions
<i>short</i> Page	Specifies current page.
<i>short</i> ZoomType	0 - Zoom fit width 1 - Zoom fit height 2 - Zoom fit both 3 - Zoom fit resolution 4 - Zoom by factor (Default 1) 5 - Zoom custom: The following 4 properties are used to determine the extents
<i>double</i> ExtMinX	Minimal X coordinate of extents.
<i>double</i> ExtMinY	Minimal Y coordinate of extents.
<i>double</i> ExtMaxX	Maximal X coordinate of extents.
<i>double</i> ExtMaxY	Maximal Y coordinate of extents.
<i>boolean</i> ViewAdditions	If TRUE , shows the entities that are in the second file but not in the first file.
<i>boolean</i> ViewDeletion	If TRUE , shows the entities that are in the first file but not in the second file.
<i>boolean</i> ViewUnchanged	If TRUE , shows the entities that are in both files.

Methods

Method	Descriptions
<i>void</i> ZoomFit()	Zoom to fit.
<i>void</i> ZoomPrevious()	Undoes last zoom operation.
<i>void</i> ZoomWidth()	Zooms to fit width.
<i>void</i> ZoomHeight()	Zooms to fit height.
<i>void</i> ZoomByFactor (double factor)	Zooms by factor.
Parameters	
factor	Zooming factor.
<i>void</i> ZoomFullResolution()	Displays rasters using full resolution, for other formats same as ZoomFit
<i>void</i> Print (boolean bDirectPrint)	Prints current document.
Parameters	
bDirectPrint	Flag indicating whether or not to show a dialog to user
<i>void</i> PrintPreview (boolean bDirect-Print)	Previews current document.
Parameters	
bDirectPreview	Flag indicating whether or not to show a dialog to user.
<i>void</i> PageNext()	Displays next page.
<i>void</i> PagePrevious()	Displays previous page.
<i>void</i> PageSelect()	Selects page number.
<i>void</i> SetContrastLight()	Sets the image contrast to be light, this only applies to raster files.

Method	Descriptions
<i>void SetContrastNormal()</i>	Sets the image contrast to be normal, this only applies to raster files.
<i>void SetContrastDark()</i>	Sets the image contrast to be dark, this only applies to raster files.
<i>void SetContrastDarkest()</i>	Sets the image contrast to be darkest, this only applies to raster files.
<i>void GetContrast()</i>	Returns the image contrast value. The value can be one of the following for the raster file: CONTRAST_LIGHT (-50) CONTRAST_MEDIUM (0) CONTRAST_DARK (66) CONTRAST_DARKER (100)
<i>void SetAntiAlias()</i>	Scales to grey, enhances the details of the raster file image that are viewed at less than 100% zoom.
<i>void InvertImage()</i>	Reverses the background and foreground colors of the raster file image.
<i>void ShowLayersDlg()</i>	Displays the Layer dialog.
<i>void ShowBlocksDlg()</i>	Displays the Blocks dialog.
<i>void ShowNamedViewsDlg()</i>	Displays the Named View dialog.
<i>void ShowXRefDlg()</i>	Displays the Xref dialog.

Events

Event	Description
<p><i>void</i> StatusChanged (short nNewStatus)</p> <p>Parameters</p> <p>nNewStatus</p>	<p>Fired when status changes.</p> <p>New status value: STATUSIDLE = 0x00 STATUSPROCESSING = 0x01 STATUSREADING = 0x02 STATUSREFRESHING = 0x04 STATUSREGENERATING = 0x08 STATUSREADINGFINISHED = 0x10</p>
<p><i>void</i> HelpString (BSTR szMsg)</p> <p>Parameters</p> <p>szMsg</p>	<p>Help String for status indicator</p> <p>Help message</p>
<p><i>void</i> ExtentsChanged (double extMinX, double extMinY, double extMaxX, double extMaxY)</p> <p>Parameters</p> <p>extMinX, extMinY, extMaxX, extMaxY</p>	<p>Fired when extents change internally (not when properties change).</p> <p>New extents' values.</p>
<p><i>void</i> PageChanged (short nNewPage)</p> <p>Parameters</p> <p>nNewPage</p>	<p>Fired when page changes internally.</p> <p>New page value.</p>
<p><i>void</i> RotateChanged (short nNewRotate)</p> <p>Parameters</p>	<p>Fired when rotate value changes internally.</p>

nNewRotate	New rotate value.
------------	-------------------

<i>void</i> FlipChanged (short nNewFlip)	Fired when flip value changes internally.
-------------------------------------------------	-------------------------------------------

Parameters

nNewFlip	New flip value.
----------	-----------------

Integration: AutoVue and "Visual Basic" Applications

All the integration methods available through "C" are also available under Visual Basic. Visual Basic provides hooks to call DLL functions and create "C"-like data structures. The easiest way to integrate AutoVue would be through OLE-Automation. This has several advantages, to wit:

- Access to a high level API
- The code that is produced can be used, with little or no modification, in applications that support VBA (Visual Basic for Applications). VBA is a programming language available in most Microsoft Office products (Word, Excel, Access etc.)
- Language is easy to use and extensible

OLE Automation Example:

```

; Declare the OLE Automation Object
Dim OleObj As Object
; Function: Create the Ole automation object. Must be called once when your
program starts up.
Sub LoadOleObj()
    ' Create the OLE Automation Object
    Set OleObj = CreateObject("AutoVue.Application")
End Sub
; Function: Destroy the Ole automation object.
; Must be called once when your program exits. Performs necessary
; cleanups.
Sub UnloadOleObj()
    If (IsObject(OleObj)) Then
        ' Close the window
        OleObj.Execute ("CHILD CLOSE")
    End If

```

```
' Clean up
Set OleObj = Nothing
End Sub
; Function: This sample function accessed
; to OLE Automation object and performs several operations.
; You should put in your own code here.
Sub ExecuteOleObj()
  If (IsObject(OleObj)) Then
    ' Copen file
    'OleObj.Execute ("FILE OPEN C:\AV19.1\samples\Desktop-
Office\Word.doc")
    OleObj.Execute ("FILE OPEN ""C:\AV19.1\samples\3d\3D
Compare\Component_V1\Component.SLDASM""")
    OleObj.Execute ("COMPARE ""C:\AV19.1\samples\3d\3D
Compare\Component_V2\Component.SLDASM""")

    ' Display window: The Application is, by default, hidden
    OleObj.Execute ("WINDOW SHOW")
    'OleObj.Execute ("CHILD SHOW")
    ' Display another file
    'OleObj.Execute ("FILE OPEN c:\autoexec.bat")
    ' Print the file
    ' OleObj.Execute ("PRINT")
    OleObj.Execute ("COMPARE ""C:\AV19.1\samples\3d\3D
Compare\Component_V2\Component.SLDASM""")
  End If
End Sub
```

Format Support

To see the latest list of file formats supported by the AutoVue family of products, please visit our website at: <http://www.oracle.com/applications/autovue/index.html>

. A list of supported file formats is also available in PDF format with your AutoVue installation.

Utilities

In addition to the APIs discussed in the Integration chapter, additional tools are provided with AutoVue. These include:

Full Text Extraction

This utility allows users to extract text information from virtually any type of document, whether it be CAD, vector, text, etc. This utility is perfect for extracting text from a file and providing textual information to a search engine for indexing. It also eliminates duplicates. For example, users can fully text index AutoCAD or MicroStation drawings in a document management system. Further information on this tool can be found in the Docs directory of your AutoVue CD.

Using the FullText Extraction Utility

- 1 From the **Tools** menu in AutoVue, select **Auto Text Extraction**. Alternatively, open the file **Outtext.exe** located in the directory **C:\Program Files\av\avwin**.
The **Automatic Text Extraction** dialog appears.
- 2 In the **From** text box, enter the path and name of the file from which the text is to be extracted.
- 3 In the **To** text box, enter the path and name of the file to which the discovered text is to be copied.
File extensions include **.txt** and **.out**. The default is **text.out** located in the **temp** directory. If the file entered does not exist, it will be created for you.
- 4 Click **Extract**.
Text found in the **From** file are listed under **Contents** in the **Automatic Text Extraction** dialog.

Ftype

This utility provides the file type of a file. For example, provided the filename **doc1.doc**, **Ftype** lets users determine that the file is a Microsoft Word document. This tool is useful for implementing batch check-in of files into a document management system or for providing MIME type information to a web server. Further information on this tool can be found in the Docs directory of your AutoVue CD.

CAD Information Extraction

This utility allows users to extract XRef information from a CAD file. This is useful for batch importing AutoCAD, MicroStation and various other types of CAD files into a document management system. To access this tool, select **CAD/Doc Text Extraction** from the **Tool** menu.

Examples of integrations using these tools and APIs can be found in the Integrat directory of the AutoVue CD.

Feedback

Oracle products are designed according to your needs. We appreciate your feedback, comments or suggestions. Contact us by fax, e-mail or telephone. There is a feedback button on our Web page that activates an easy-to-use feedback form. Let us know what you think.

General Inquiries

Telephone: +1 514-735-3219

Fax: (514) 735-6440

E-mail: info@cimmetry.com

Web Site: <http://www.oracle.com/applications/autovue/index.html>

Sales Inquiries

Telephone: +1 514-735-3219 or 1-800-361-1904

Fax: (514) 735-6440

E-mail: sales@cimmetry.com

Customer Support

Telephone: +1 514-735-9941

Web Site: <http://www.cimmetry.com/support>

Index

Numerics

- 2D Output options 98
- 3D options 72
 - color 76
 - export 98
 - measurement 77
 - pmi 78

A

- Acrobat PDF options 27
- Activex control
 - AutoVue compareX control 202
 - AutoVueX control 167
 - AvMarkupX control 190
- Application options 94
- AutoCAD options 29
- Autodesk DWF options 31
- Autodesk Inventor options 32
- AutoVue commands
 - child 165
 - conversion 160
 - EDAT/drawing information 165
 - file 156
 - general 156
 - markup 163
 - option 163
 - printing 160
 - view 158
 - window 164

C

- CAD Information Extraction 212
- CAD information extraction 212
- Cadence options 32
- Cadkey options 33
- CATIA 4 options 33
- CATIA 5 options 34

- CGM options 35
- Change Locale of AutoVue 16
- Child commands 124
- Command Line Options 19
- Command line options
 - commands 20
 - syntax 20
- Compare options 95
- Conversion commands 139
 - options 139
- Conversion page size 97
- Customize AutoVue Startup 19

D

- DDE commands 123
- Disable options 106
- DLL integration 148

E

- EDA options 83
- EDAT (Engineering Drawing Access Technology) 153
- Excel options 36
- Export BOM 128
- Export BOM commands 128
- Export File Versions 17

F

- File commands 126
- File Versions 17
 - exporting 17
 - view 17
- Format support 209
- Ftype 211
- Full Text Extraction 211

G

- General commands 126
- General options 58
 - base font 69

ui color 70
Gerber options 36

H

Help Features 15
HPGL/HPGL2 options 38

I

IGES options 40
INI file configuration 23
INI File Options

- IFC 39
- Microsoft Outlook 44
- Printing
 - watermark
 - in view mode 121
 - Text 56

INI Options 27

- 2D
 - Output 98
- 3D 72
 - Color 76
 - Export 98
 - Measurement Units 77
 - PMI 78
- Acrobat PDF 27
- Applications 94
- AutoCAD 29
- Autodesk DWF 31
- Autodesk Inventor 32
- Cadence 32
- Cadkey 33
- CATIA 4 33
- CATIA 5 34
- CGM 35
- Compare 95
- Disable 106
- EDA 83
- Excel 36
- General 58

Base Font 69
UI Color 70
Gerber 36
HPGL/HPGL2 38
IGES 40
JPEG 41
JPEG 2000 42
Markup 87

- Font 93

Markup Measurement 117

- 3D Distance 119
- Angle 118
- Arc 118
- Area 117
- Calibrate 120
- Distance 119

Markups

- Calibrate 92

ME10/ME30 43
MicroStation 45
NC-Drill 50
OEM 108
Orcad Layout 51
Overlay 95
page size options

- millimeters 97

Pen mapping 105
Printing 109

- Batch Pages 115
- General 111
- Headers and Footers 114
- Margins 116
- Notes 116
- Stamp 110
- Watermark 109

Pro/ENGINEER 51
SolidWorks 54
STEP 55
Text 56
Thumbnail 108

- Visio 56
- Initialization file
 - applications options 94
 - configuration 23
 - alternative INI file 23
 - general options 58
 - AutoCAD font 58
 - DGN font configuration 48
 - Inventor decoder 32
 - SHOWALLLAYERS 30
 - network configuration 26
 - OEM options 108
 - output options 98
- Installation 11
- Integration 145
 - DDE 148
 - definition 145
 - DLL 148
 - EDAT, Drawing Information Ex- traction 153
 - integrating with Visual Basic ap- plications 207
 - markup API 154
 - OLE automation 150
 - VCET API 153
 - with AutoVue 146
- Inventor decoder 32
- J**
 - JPEG 2000 options 42
 - JPEG options 41
- M**
 - Markup API 154
 - Markup commands 143
 - Markup Measurement options 117
 - 3D distance 119
 - angle 118
 - arc 118
 - area 117
 - calibrate 120
 - distance 119
 - Markup options 87
 - calibrate 92
 - font 93
 - ME10/OneSpace Designer Drafting options 43
 - Microsoft Outlook 44
 - MicroStation options 45
- N**
 - NC-Drill options 50
 - Network configuration 26
- O**
 - OEM options 108
 - OLE Automation 150
 - Option commands 143
 - Orcad Layout options 51
 - Overlay options 95
- P**
 - Page Size options
 - Inches 97
 - inches 97
 - millimeters 97
 - Pen mapping options 105
 - Printing
 - disabling 106
 - Printing commands 128
 - options 129
 - Printing options 109
 - batch pages 115
 - general 111
 - header and footers 114
 - margins 116
 - notes 116
 - stamp 110
 - watermark 109
 - Pro/ENGINEER options 51

S

Scripting 123
 commands
 child 124
 conversion 139
 options 139
 export BOM 128
 file 126
 general 126
 markup 143
 option 143
 printing 128
 options 129
 setup 143
 viewing 141
 window 124
 file
 overlays 126
 syntax 123
 syntax diagrams 123
SolidWorks options 54
STEP options 55
Syntax diagrams 123
System Requirements 11

T

Text options 56
Thumbnail options 108

U

Utilities 211
 CAD Information Extraction 212
 CAD information extraction 212
 Ftype 211
 Full text extraction 211

V

VCET API 153
View commands 141

View File Versions 17
Visio options 56

W

Window commands 124