



Sun™ Enterprise™ 10000 Dynamic
Reconfiguration Reference Manual

Solaris™ 2.6 Hardware: 5/98

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303
U.S.A. 650-960-1300

Part No. 805-3526-10
May 1998, Revision A

Send comments about this document to: smcc-docs@sun.com

Copyright 1997, 1998 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, California 94303 U.S.A. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, SunSoft, SunDocs, SunExpress, Solaris, Solstice, DiskSuite, SunFastEthernet, Ultra Enterprise, Sun Enterprise, AnwserBook, and OpenBoot are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1997, 1998 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, Californie 94303 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, SunSoft, SunDocs, SunExpress, Solaris, Solstice, DiskSuite, SunFastEthernet, Ultra Enterprise, Sun Enterprise, AnwserBook, and OpenBoot sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REPONDRE A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



Please
Recycle



NAME	Intro – Sun™ Enterprise™ 10000 DR administration
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	This section describes commands, scripts, and programs executed in the Enterprise 10000 Dynamic Reconfiguration (DR) environment.
LIST OF COMMANDS	<p>abort_attach(1M) abort DR attach operation</p> <p>abort_detach(1M) abort DR detach operation</p> <p>complete_attach(1M) complete DR attach operation</p> <p>complete_detach(1M) complete DR detach operation</p> <p>dr(1M) initiate dynamic reconfiguration shell</p> <p>dr.service(1M) low-level DR commands for service providers</p> <p>dr_cmd_a_attach(1M) abort DR attach system board operation</p> <p>dr_cmd_a_detach(1M) abort DR detach system board operation</p> <p>dr_cmd_auto_config(1M) run Solaris reconfig sequence on target domain</p> <p>dr_cmd_c_attach(1M) complete DR attach system board operation</p> <p>dr_cmd_c_detach(1M) complete DR detach system board operation</p> <p>dr_cmd_c_f_detach(1M) force completion of DR detach system board operation</p> <p>dr_cmd_cpu_info(1M) show processors on a system board in Tcl encoding</p> <p>dr_cmd_debug(1M) toggle DR library-level debugging</p> <p>dr_cmd_detach_allow(1M) verify a system board can support DR detach</p> <p>dr_cmd_dev_info(1M) show devices on a system board in Tcl encoding</p> <p>dr_cmd_drain(1M) start memory drain on a system board</p> <p>dr_cmd_drain_status(1M) show state of in-progress memory drain</p> <p>dr_cmd_eligible_attach(1M) verify a system board is eligible for DR attach</p> <p>dr_cmd_eligible_detach(1M) verify a system board is eligible for DR detach</p> <p>dr_cmd_init_attach(1M) initiate DR attach system board operation</p> <p>dr_cmd_mem_info(1M) show memory configuration on a system board in Tcl encoding</p> <p>dr_cmd_obp_info(1M) show complete config on a system board in Tcl encoding</p> <p>dr_cmd_print_brd_info(1M) show system board resources in tabular format</p> <p>dr_cmd_print_obp_info(1M) show system board info per OpenBoot™ Prom in tabular format</p> <p>dr_cmd_print_unsafe_info(1M) show a domain's open, unsafe devices in tabular</p>

format

dr_cmd_unsafe_dev_info(1M)	show a domain's open, unsafe devices in TCL encoding
drain(1M)	start memory drain
drshow(1M)	display DR and board resource info
drvview(1M)	DR Graphical User Interface
init_attach(1M)	initiate DR Attach operation
reconfig(1M)	initiate auto-configuration sequence

NAME	abort_attach – abort a DR Attach operation
SYNOPSIS	abort_attach <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Execute this command at the dr(1M) shell prompt to return the specified board to its original condition after completion of an init_attach(1M) operation. abort_attach leaves the board present, powered-on, and in no domain. It instructs the operating system running on the target domain specified by the SUNW_HOSTNAME environment variable to abandon the in-progress attach operation, then removes the board from the domain_config file and resets the Enterprise 10000 centerplane cluster mask registers and board domain mask registers. See domain_config(4) in the <i>Ultra Enterprise 10000 SSP Reference Manual</i>.</p> <p>You should run abort_attach after init_attach(1M) has successfully completed, and instead of the complete_attach(1M) command.</p> <p>If executing abort_attach fails to abort the operation, try repeating the attempt at a later time, or contact your service provider.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board not to be attached.
EXIT STATUS	If successful, abort_attach returns a 0 in the dr_return global variable; if not, it returns a 1, along with one or more diagnostic messages.
EXAMPLE	<pre>dr> abort_attach 5 Aborting attach board 5 to domain ts4. Processors on board 5 reset. Removing board 5 from domain_config file. Board 5 placed into loopback. Abort attach board successful. dr></pre>
DIAGNOSTICS	<p>Failed to abort board attachment</p> <p>Repeat the abort_attach command at a later time, or contact your service provider.</p>
NOTES	If DR detects a usage syntax error, it immediately aborts the dr (1M) command, displays the dr (1M) shell prompt, and leaves dr_return unmodified. See dr (1M).
SEE ALSO	dr (1M), init_attach (1M)

NAME	abort_detach – abort a DR Detach operation
SYNOPSIS	abort_detach <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	Execute this command at the dr(1M) shell prompt to abort an attempt to DR Detach a board. You can execute abort_detach after the board has been asked to drain and before it has been completely detached. After abort_detach has been successfully executed, resources on the designated system board are once again available to the operating system.
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board not to be detached.
EXIT STATUS	If successful, abort_detach returns a 0 in the dr_return global variable; if not, it returns a 1, along with one or more diagnostic messages.
EXAMPLE	<pre>dr> abort_detach 4 Aborting detach board 4 Returning board to domain_config. Adding board 4 to domain_config file. Abort board detach completed successfully.</pre>
DIAGNOSTICS	<p>FAILED to restore domain_config file Retry the ABORT board detach at a later time</p> <p>The attempt to restore the board number to the target domain board list in the domain_config(4) file (in the <i>Ultra Enterprise 10000 SSP Reference Manual</i>) has failed. This may be a temporary condition, so try the abort_detach again at a later time.</p> <p>Failed to abort board detach</p> <p>The operating system on the target domain was unable to restore the board to full operation. This may be a temporary condition, so try the abort_detach again at a later time.</p>
NOTES	If DR detects a usage syntax error, it immediately aborts the dr(1M) command, displays the dr(1M) shell prompt, and leaves dr_return unmodified. See dr(1M) .
SEE ALSO	complete_attach(1M) , dr(1M) , drain(1M)

NAME	complete_attach – complete a DR Attach operation
SYNOPSIS	complete_attach <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	Execute this command at the dr(1M) shell prompt to complete an attempt to DR Attach a board after successful execution of the init_attach(1M) command. complete_attach causes the operating system on the target domain to dynamically add the resources (processors, memory, and I/O devices) from the specified board to the running system. If a problem that prevents attachment of any device present on the board occurs, that problem is logged in the system message buffer of the target domain. To display a list of the devices that were successfully attached, execute the drshow(1M) command to display the current system configuration for the board.
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be attached to the target domain.
EXIT STATUS	If successful, complete_attach returns a 0 in the dr_return global variable; if not, it returns a 1, along with one or more diagnostic messages.
EXAMPLE	<pre>dr> complete_attach 5 Completing attach for board 5 Board attachment completed successfully.</pre>
DIAGNOSTICS	<p>Failed during final state transition The operation failed during the final stage of attachment. Check that the DR daemon is still running on the target domain, and that the network is operational. To recover from the failure, repeat the complete_attach operation or execute an abort_attach(1M).</p> <p>Failed to complete attach board The operating system on the target domain was unable to attach the board. Repeat the complete_attach operation at a later time or execute the abort_attach(1M) command.</p>
NOTES	If DR detects a usage syntax error, it immediately aborts the dr(1M) command, displays the dr(1M) shell prompt, and leaves dr_return unmodified. See dr(1M) .
SEE ALSO	dr(1M) , drshow(1M) , init_attach(1M)

NAME	complete_detach – complete a DR detach operation
SYNOPSIS	complete_detach sb [force]
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Execute this command at the dr(1M) shell prompt to complete an attempt to DR Detach a board. The drain(1M) command must have been previously executed and the drain operation must have completed before complete_detach can proceed. You can use the drshow(1M) command to check the status of the drain operation.</p> <p>A board can be detached only after all use of its devices has ceased. DR automatically terminates the use of memory and network devices and, in almost all cases, processors; but you must terminate use of the board's I/O devices. You can use the drshow(1M) command to list the devices in use on the board.</p> <p>If the detaching board contains non-pageable kernel or OBP memory, the domain is quiesced during the complete_detach operation. The quiesce operation may fail due to <i>forcible</i> conditions. See the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i> for a description of such conditions. You can use the force argument to force the quiesce in such situations.</p>
OPTIONS	<p>sb The board number (0 to 15) of the system board to be detached.</p> <p>force Force the domain quiesce operation. See the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i>. for information about forcing a quiesce.</p>
EXIT STATUS	If successful, complete_detach returns a 0 in the dr_return global variable; if not, it returns a 1, along with one or more diagnostic messages.
EXAMPLE	<pre>dr> complete_detach 5 Completing detach of board 5. Operating System has detached the board. Processors on board 5 reset. Board 5 placed into loopback. Board detachment completed successfully.</pre>
DIAGNOSTICS	<p>Cannot COMPLETE detach until drain completes</p> <p>The drain operation is still in-progress. Use drshow(1M) to monitor the drain. After it has completed, repeat the complete_detach command.</p> <p>Board detachment failed Retry the COMPLETE or ABORT the operation</p> <p>A condition on the target domain's operating system has prevented the detach from completing. Retry the operation at a later time, or use abort_detach(1M) to abort the detach.</p>

NOTES	If DR detects a usage syntax error, it immediately aborts the dr(1M) command, displays the dr(1M) shell prompt, and leaves dr_return unmodified.
SEE ALSO	abort_detach(1M) , dr(1M) , drain(1M) , drshow(1M)

NAME	dr – initiate dynamic reconfiguration shell
SYNOPSIS	dr
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>The dr command initiates the Dynamic Reconfiguration (DR) shell, a Tcl application (see NOTES, below) with DR command extensions. You can use the dr shell to logically attach or detach a system board to or from an Enterprise 10000 domain from the command line or via a script.</p> <p>Note: Whenever possible, use the DR GUI via Hostview to execute Dynamic Reconfiguration operations. Use the dr shell when you cannot run Hostview; for example, if you need to run DR over a dial-up connection. For more information see the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i> and hostview(1M) in the <i>Ultra Enterprise 10000 SSP Reference Manual</i>.</p> <p>When executed on the command line, dr connects to the domain specified by the SUNW_HOSTNAME environment variable. After this connection is established, dr displays the dr> prompt, which accepts the DR commands.</p> <p>Note: To see the list of DR commands while not using AnswerBook, execute man Intro on the SSP while logged in as user ssp.</p> <p>You can quit the dr shell at any time by typing exit or Control-d.</p> <p>Caution: Do not execute any of the DR commands that begin with dr_cmd_; these are low-level commands that are for use only by authorized service personnel under special circumstances, as described in dr.service(1M).</p> <p>To minimize the risk of unintended DR operations, start this shell only when you are ready to execute DR commands and exit it as soon as you are done.</p> <p>The DR commands return error status in the global Tcl variable dr_return. Normally, Tcl commands return both output and status together, which can be confusing and difficult to parse from within scripts. You can, however, execute the DR command set dr_return to display dr_return after executing each DR command, to determine command success or failure. Though, under most circumstances, the diagnostic messages output by the dr shell clearly indicate success or failure.</p> <p>Note: Type help at the dr shell prompt (dr>) to access DR's quick-reference help guide.</p>
EXAMPLE	<p>The following example performs a DR Attach of Board 2 to the domain named 'e100001'. After complete_detach(1M) has successfully completed dr displays the result code stored in dr_return.</p> <pre>e100001-ssp% domain_switch e100001 e100001-ssp% dr</pre>

```
Checking environment...
Initializing SSP SNMP MIB...
Establishing communication with DR daemon...

e100001: System Status - Summary

BOARD #: 2 3 5 6 physically present.
BOARD #: 0 1 4 being used by the system.

dr> init_attach 2
Initiate attaching board 2

phase init_reset: Initial system resets...

phase jtag_integ: JTAG probe and integrity test...
phase mem_probe: Memory dimm probe...
phase jtag_bbsram: JTAG basic test of bootbus sram...
phase proc1: Initial processor module tests...
phase pc/cic_reg: PC and CIC register tests...
phase dtag: CIC DTAG tests...
phase mem: MC register and memory tests...
phase procmem: Processor vs. memory tests...
phase xcall: Interprocessor interrupt tests...
phase io: I/O controller tests...
Skipping phase ecc: Proc ecc vs. memory tests...
phase final_config: Final configuration...
Creating OBP handoff structures...
Configured in 3F with 3 processors, 0 SBUS cards, 1024 MBytes memory.
Boot processor is 4.0 = 8
POST execution time 1:23
hpost is complete.
/opt/SUNWssp/bin/obp_helper
Master cpu is 8
Slave cpus initialization:
Slave cpus initialization OK
board debut utility complete.

Board attachment initiated successfully.

Ready to COMPLETE board attachment.

dr> complete_attach 2
Completing attach for board 2
Board attachment completed successfully.
```

```
dr> set dr_return  
0  
dr> exit  
e100001-ssp%
```

NOTES

Tcl (Tool command language) is a simple scripting language for controlling and extending applications. You do not need Tcl knowledge to use the **dr** shell. However, if you wish to write Tcl scripts or just want more information about Tcl, a good reference is *Tcl and the Tk Toolkit* by John K. Ousterhout, published by Addison-Wesley Publishing Company.

As a Tcl application, **dr** checks for certain types of syntax errors and, if it finds one, aborts without executing the **dr** shell command. For example, if you specify an argument with a command that does not require one, **dr** prints a usage error message and aborts. **dr** updates **dr_return** only upon completion of a **dr** command. If the command does not complete, as in our example above, **dr** does not update **dr_return**.

SEE ALSO

Sun Enterprise 10000 Dynamic Reconfiguration User's Guide
Sun Enterprise Server Alternate Pathing User's Guide
Ultra Enterprise 10000 SSP User's Guide
domain_switch(1M), **hostview(1M)** in the *Ultra Enterprise 10000 SSP Reference Manual*
dr(7) in the *Solaris Reference for SMCC-Specific Software*
add_drv(1M), **drvconfig(1M)**, **devlinks(1M)**, **disks(1M)**, **inetd(1M)**, **ports(1M)**,
prtconf(1M), **tapes(1M)** in *man Pages(1M): System Administration Commands of the SunOS Reference Manual*
syslog(3) in *man Pages(3): Library Routines of the SunOS Reference Manual*

NAME	dr.service – low-level DR commands for service providers
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>The low-level commands described here, which begin with dr_cmd, are available only in the DR shell, and are for use by service providers only. Service providers should use them only when they need a finer level of control to debug failing DR operations, or when they cannot access the DR GUI.</p> <p>Caution: Customers should not use these low-level commands, but should access DR through the DR GUI, as described in the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i>, or via the high-level DR commands (those without the dr cmd prefix) described in this reference manual.</p> <p>The DR shell provides commands that directly map to libdr.so function calls. Executing this command set gives the caller a finer level of control over DR operations, but introduces additional risk of error due to fewer safeguards.</p> <p>Note that DR operations can fail or be denied by the operating system for numerous reasons. Often, specific user action is required to complete a DR sequence. For this reason, Sun cautions against the use of automated DR scripts. The Hostview interface (see hostview(1M) in <i>Ultra Enterprise 10000 SSP Reference Manual</i>) is the preferred method of performing DR operations. Use the dr(1M) shell when the GUI-based Hostview application is unavailable.</p>
SHELL COMMANDS	The low-level shell commands are those that begin with dr_cmd_ . See Intro(1M) .
EXIT STATUS	<p>The DR shell low-level command set generally returns an exit code in the dr_return global variable. Upon return from each of the DR commands, this variable can be tested for success or failure.</p> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>

NAME	dr_cmd_a_attach – abort DR attach system board operation
SYNOPSIS	dr_cmd_a_attach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness. Instead, use abort_attach(1M), which performs the same functions, but with the added security of safeguards and checks.</p> <p>If abort_attach(1M) were unavailable for some reason, you could run dr_cmd_a_attach after a system board has been successfully init attached via dr_cmd_init_attach(1M) and before the board has been completely attached via the dr_cmd_c_attach(1M). dr_cmd_a_attach returns the board to the state it was in prior to the dr_cmd_init_attach(1M) operation; that is, present, powered-on, and in no domain.</p> <p>dr_cmd_a_attach instructs the operating system running on the target domain to abandon the in-progress attach operation, removes the system board from the domain_config file, and resets the Enterprise 10000 server's centerplane shared memory mask registers and board domain mask registers.</p> <p>Some conditions that are transparent to the user may cause an abort failure. Therefore, if dr_cmd_a_attach fails to complete the abort successfully, try executing it again at a later time.</p>
OPTIONS	<i>sb</i> The system board number (0 to 15) for the abort attach operation.
EXIT STATUS	If dr_cmd_a_attach succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on abort_attach(1M) .
SEE ALSO	dr(1M) , dr_cmd_init_attach(1M) , dr_cmd_c_attach(1M)

NAME	dr_cmd_a_detach – abort DR detach system board operation
SYNOPSIS	dr_cmd_a_detach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness. Instead, use abort_detach(1M), which performs the same functions, but with the added security of safeguards and checks.</p> <p>You can run dr_cmd_a_detach after draining a system board via dr_cmd_drain(1M) but before that board has been completely detached.</p>
OPTIONS	<p><i>sb</i> The board number (0 to 15) of the system board whose detach is being aborted.</p>
EXIT STATUS	<p>If dr_cmd_a_detach succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.</p> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS in abort_detach(1M)
SEE ALSO	<p>dr(1M), dr_cmd_drain(1M)</p> <p><i>Ultra Enterprise 10000 SSP User's Guide</i></p>

NAME	dr_cmd_auto_config – run Solaris reconfig sequence on target domain
SYNOPSIS	dr_cmd_auto_config
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command; use reconfig(1M) instead. Only authorized service providers should use dr_cmd_auto_config, which runs in the DR shell, and only when they cannot use reconfig(1M). Performing this operation may cause device files to be remapped and known devices to be renamed.</p> <p>The system administrator would normally run dr_cmd_auto_config after a new system board has been attached to a running domain to make the devices on the boards available immediately. The automatic configuration on Solaris consists of the following SunOS commands, in the order shown:</p> <p style="padding-left: 2em;">drvconfig(1M), devlinks(1M), disks(1M), and tapes(1M).</p>
EXIT STATUS	<p>If dr_cmd_auto_config succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1.</p> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on the reconfig(1M) man page.
SEE ALSO	<p>reconfig(1M) in this Reference Manual</p> <p>dr_daemon (1M) in the <i>Solaris Reference for SMCC-Specific Software</i></p> <p>drvconfig(1M), devlinks(1M), disks(1M), ports(1M), tapes(1M) in <i>man Pages(1M): System Administration Commands</i> of the <i>SunOS Reference Manual</i></p>

NAME	dr_cmd_c_attach – complete DR attach system board operation
SYNOPSIS	dr_cmd_c_attach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness, and is dangerous. Instead, use complete_attach(1M), which performs the same functions, but with the added security of safeguards and checks.</p> <p>dr_cmd_c_attach completes the DR attach board operation started by dr_cmd_init_attach(1M). The designated system board should already have been successfully Init Attached via dr_cmd_init_attach(1M). The complete attach operation causes the operating system on the target domain to dynamically add the resources from this system board (processors, memory, and I/O devices) to the running system. If a problem occurs, preventing attachment of any device present on the board, the problem is logged in the system message buffer of the target domain.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board being attached.
EXIT STATUS	If dr_cmd_c_attach succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on complete_attach(1M) .
SEE ALSO	dr(1M) , dr_cmd_init_attach(1M)

NAME	dr_cmd_c_detach – complete DR detach system board operation
SYNOPSIS	dr_cmd_c_detach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is dangerous and included here only for completeness. Instead, use complete_detach(1M), which performs the same functions, but with the added security of safeguards and checks.</p> <p>dr_cmd_c_detach completes a DR detach board operation. The designated system board should have previously been drained via dr_cmd_drain(1M).</p> <p>You can detach a system board only when none of its devices is in use. DR automatically terminates the use of memory, processors (in almost all cases), and network devices on the board. But the administrator must make certain that all use of the board's I/O devices has ceased. You can use drshow(1M) to list the devices in use on a given system board.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board being detached.
EXIT STATUS	If dr_cmd_c_attach succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on complete_detach(1M) .
SEE ALSO	dr(1M) , dr_cmd_drain(1M) <i>Ultra Enterprise 10000 SSP User's Guide</i>

NAME	dr_cmd_c_f_detach – force completion of DR detach system board operation
SYNOPSIS	dr_cmd_c_f_detach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which is dangerous and runs in the DR shell; it is included here only for completeness. Instead, use complete_detach(1M), which performs the same functions, but with the added security of safeguards and checks.</p> <p>dr_cmd_c_f_detach completes the DR detach board operation, using a forcible domain quiesce. See the Caution, above. Use this command when you need to force the system to complete a detach operation, when the system board to be detached contains unsafe devices that are open, but not in use. See the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i> for more information on system quiesce, and ways to increase the safety of this dangerous command.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be detached.
EXIT STATUS	If dr_cmd_c_f_detach succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on complete_detach(1M) .
SEE ALSO	dr(1M), dr_cmd_drain(1M) <i>Ultra Enterprise 10000 SSP User's Guide</i>

NAME	dr_cmd_cpu_info – show processors on a system board in Tcl encoding
SYNOPSIS	dr_cmd_cpu_info <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: This command, which runs in the DR shell, produces output in a form suitable for the drvview(1M) application, not the interactive user.</p> <p>dr_cmd_cpu_info queries the target domain and produces a list of the processors attached to the specified system board. The list is returned in a Tcl format, and is used by the drvview(1M) application.</p> <p>Since the Tcl list is not readily accessible to an interactive user, you should use drshow(1M) instead to acquire processor information.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the target system board.
EXIT STATUS	If dr_cmd_cpu_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
SEE ALSO	dr(1M) , dr_cmd_mem_info(1M) , dr_cmd_dev_info(1M)

NAME	dr_cmd_debug – toggle DR library-level debugging
SYNOPSIS	dr_cmd_debug
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Only authorized service providers should use this command, which runs in the DR shell.</p> <p>When switched on, dr_cmd_debug provides significantly more detailed information about DR operations performed via dr(1M). dr_cmd_debug is set up as a toggle; execute it once to turn it on, and again to turn it off. Initially, it is set to 0, or off. The service provider may find dr_cmd_debug very useful when diagnosing a DR-related failure. Activate debugging prior to executing any commands related to DR Attach or DR Detach.</p>
EXIT STATUS	dr_cmd_debug always returns a 0 character in the dr_return global Tcl variable.
SEE ALSO	dr(1M)

NAME	dr_cmd_detach_allow – verify a system board can support DR detach
SYNOPSIS	dr_cmd_detach_allow <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Only authorized service providers should use this command, which runs in the DR shell.</p> <p>dr_cmd_detach_allow queries the operating system running on the target domain about any conditions that may prevent the system board from being successfully detached. If the board is not detachable, dr_cmd_detach_allow displays one or more diagnostic messages.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be queried.
EXIT STATUS	If dr_cmd_detach_allow succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
SEE ALSO	dr(1M), <i>Ultra Enterprise 10000 SSP User's Guide</i>

NAME	dr_cmd_dev_info – show devices on a system board in Tcl list encoding
SYNOPSIS	dr_cmd_dev_info <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Note: This command, which runs in the DR shell, produces output in a form suitable for the drvview(1M) application, not the interactive user. Use drshow(1M) instead to view device information.</p> <p>dr_cmd_dev_info checks the target domain for peripheral devices attached to the specified system board and returns the information in a Tcl list encoding, which is used by the drvview(1M) application.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the target system board.
EXIT STATUS	If dr_cmd_dev_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages. <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
SEE ALSO	dr(1M) , dr_cmd_cpu_info(1M) , dr_cmd_mem_info(1M)

NAME	dr_cmd_drain – start memory drain on a system board.
SYNOPSIS	dr_cmd_drain sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: This command, which runs in the DR shell, is dangerous; do not use it. It is included here only for completeness. Instead, use the drain(1M) command, which performs the same functions, but with the added security of safeguards and checks.</p> <p>dr_cmd_drain determines the best way to vacate memory physically located on the designated system board. It may simply flush the memory, or copy it to memory available on another system board in the same domain. If a suitable target memory for the memory copy is not available when the dr_cmd_drain command is invoked, the request is denied. If the unavailability is due to run-time conditions and system load, you should retry the dr_cmd_drain operation at a later time.</p> <p>The dr_cmd_drain operation also removes the system board from the target domain's board list in the domain_config(4) file on the SSP. (See domain_config(4) in the <i>Ultra Enterprise 10000 SSP Reference Manual</i>.)</p> <p>dr_cmd_drain begins execution, then quickly exits. Use drshow(1M) to monitor its progress.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be drained.
EXIT STATUS	If dr_cmd_drain succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on drain(1M) .
SEE ALSO	dr_cmd_mem_info(1M) <i>Ultra Enterprise 10000 SSP User's Guide</i>

NAME	dr_cmd_drain_status – show state of in-progress memory drain
SYNOPSIS	dr_cmd_drain_status <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Only authorized service providers should use this command, which runs in the DR shell.</p> <p>Use dr_cmd_drain_status to monitor a drain-in-progress. It displays a table of current information about the drain. DR cannot complete a detach until all the memory on a system board has been successfully drained.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board being drained.
EXIT STATUS	If dr_cmd_drain_status succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
SEE ALSO	dr(1M)

NAME	dr_cmd_eligible_attach – verify a system board is eligible for DR attach								
SYNOPSIS	dr_cmd_eligible_attach <i>sb</i>								
AVAILABILITY	Sun Enterprise 10000 servers only.								
DESCRIPTION	<p>Caution: Only authorized service providers should use this command, which runs in the DR shell. Service providers: Be sure to run this eligibility check prior to initiating any DR attach activity when using the low-level DR shell command set. Initiating an attach operation on an ineligible board may cause a system failure.</p> <p>Use dr cmd eligible attach to verify that a system board is eligible for an attach operation before using dr cmd init attach(1M) to begin the Init Attach.</p>								
OPTIONS	<i>board</i> The board number (0 to 15) of the system board to be checked.								
EXIT STATUS	<p>dr cmd eligible attach returns one of the following result codes to the dr_return global Tcl variable:</p> <table> <tr> <td>y</td><td>The specified system board is eligible to be attached.</td></tr> <tr> <td>n</td><td>The specified system board is not eligible to be attached.</td></tr> <tr> <td>dr cmd eligible attach</td><td>sends additional information to stdout.</td></tr> <tr> <td>sb</td><td>The specified system board is not eligible to be attached because system board <i>sb</i> (0 to 15), a different system board in the target domain, is in an intermediate DR Attach state. That DR Attach operation must be completed before you can initiate a DR operation on another board (such as the one specified).</td></tr> </table> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>	y	The specified system board is eligible to be attached.	n	The specified system board is not eligible to be attached.	dr cmd eligible attach	sends additional information to stdout.	sb	The specified system board is not eligible to be attached because system board <i>sb</i> (0 to 15), a different system board in the target domain, is in an intermediate DR Attach state. That DR Attach operation must be completed before you can initiate a DR operation on another board (such as the one specified).
y	The specified system board is eligible to be attached.								
n	The specified system board is not eligible to be attached.								
dr cmd eligible attach	sends additional information to stdout.								
sb	The specified system board is not eligible to be attached because system board <i>sb</i> (0 to 15), a different system board in the target domain, is in an intermediate DR Attach state. That DR Attach operation must be completed before you can initiate a DR operation on another board (such as the one specified).								
SEE ALSO	<p>dr(1M) <i>Ultra Enterprise 10000 SSP User's Guide</i></p>								

NAME	dr_cmd_eligible_detach – verify a system board is eligible for DR detach								
SYNOPSIS	dr_cmd_eligible_detach <i>sb</i>								
AVAILABILITY	Sun Enterprise 10000 servers only.								
DESCRIPTION	<p>Caution: Only authorized service providers should use this command, which runs in the DR shell. Service providers: Be sure to run this eligibility check prior to initiating any DR detach activity when using the low-level DR shell command set. Initiating a detach operation on an ineligible board may cause a system failure.</p> <p>Use dr cmd eligible detach to verify that a system board is eligible for a detach operation before using dr cmd drain(1M) to begin a DR drain operation.</p>								
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be checked.								
EXIT STATUS	<p>dr cmd eligible detach returns one of the following result codes to the dr_return global Tcl variable:</p> <table> <tr> <td>y</td> <td>The specified system board is eligible to be detached.</td> </tr> <tr> <td>n</td> <td>The specified system board is not eligible to be detached.</td> </tr> <tr> <td><i>sb_number</i></td> <td>dr cmd eligible detach sends additional information to stdout.</td> </tr> <tr> <td></td> <td>The specified system board is not eligible to be detached because system board <i>sb</i> (0 to 15), a different system board in the target domain, is in an intermediate DR Detach state. That DR Detach operation must be completed before you can initiate a DR operation on another board (such as the one specified).</td> </tr> </table> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>	y	The specified system board is eligible to be detached.	n	The specified system board is not eligible to be detached.	<i>sb_number</i>	dr cmd eligible detach sends additional information to stdout.		The specified system board is not eligible to be detached because system board <i>sb</i> (0 to 15), a different system board in the target domain, is in an intermediate DR Detach state. That DR Detach operation must be completed before you can initiate a DR operation on another board (such as the one specified).
y	The specified system board is eligible to be detached.								
n	The specified system board is not eligible to be detached.								
<i>sb_number</i>	dr cmd eligible detach sends additional information to stdout.								
	The specified system board is not eligible to be detached because system board <i>sb</i> (0 to 15), a different system board in the target domain, is in an intermediate DR Detach state. That DR Detach operation must be completed before you can initiate a DR operation on another board (such as the one specified).								
SEE ALSO	<p>dr(1M)</p> <p><i>Ultra Enterprise 10000 SSP User's Guide</i></p>								

NAME	dr_cmd_init_attach – initiate DR attach system board operation
SYNOPSIS	dr_cmd_init_attach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is dangerous, and is included here only for completeness. Instead, use init_attach(1M), which performs the same functions, but with the added security of safeguards and checks.</p> <p>dr_cmd_init_attach begins a DR attach board operation. DR does not screen the target domain for intermediate system boards as it does with the init_attach(1M) command and through Hostview.</p> <p>dr_cmd_init_attach is a low-level command for use only by trained service personnel for diagnosing DR-related system problems. The designated system board should be present, powered-on, and currently in no domain. dr_cmd_init_attach diagnoses, then debuts the system board to the Enterprise 10000 target domain specified in the SUNW_HOSTNAME environment variable.</p> <p>dr_cmd_init_attach adds the system board to the system board list in the SSP's domain_config file. (See domain_config(4) in <i>Ultra Enterprise 10000 SSP Reference Manual</i>.) DR then prepares the board's resources (processors, memory, and I/O controllers) for attachment by the operating system, and the Enterprise 10000 server's centerplane is reconfigured such that the board is visible to the target domain.</p> <p>After dr_cmd_init_attach completes successfully, you can execute dr_cmd_c_attach(1M) to complete the attach operation, or dr_cmd_a_attach(1M) to abort it.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be attached.
EXIT STATUS	If dr_cmd_init_attach succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
DIAGNOSTICS	See DIAGNOSTICS on init_attach(1M) .
SEE ALSO	<i>Ultra Enterprise 10000 SSP User's Guide</i>

NAME	dr_cmd_mem_info – show memory config on a system board in Tcl encoding
SYNOPSIS	dr_cmd_mem_info <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command. It returns information in Tcl encoding, which is understood by the drvview(1M) application, but is not intended for direct viewing by users. Instead, use the drshow(1M) command.</p> <p>dr_cmd_mem_info queries the target domain for memory attached to this system board, returning the information in a Tcl list encoding, which then is used by the drvview(1M) application.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be checked.
EXIT STATUS	If dr_cmd_mem_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages. <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>
SEE ALSO	dr(1M)

NAME	dr_cmd_obp_info – show complete config of a system board in Tcl encoding
SYNOPSIS	dr_cmd_obp_info <i>sb</i>
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it displays information in Tcl encoding, which is understood by the drvview(1M) application, but is not intended for direct viewing by the interactive user. Instead, use drshow(1M) to view this information.</p> <p>dr_cmd_obp_info displays the complete board configuration, including processors, memory and I/O devices, of a system board that has been Init Attached to a domain (that is, probed by OBP), but is not yet completely attached. See the Caution, above.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the target system board.
EXIT STATUS	If dr_cmd_obp_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>

NAME	dr_cmd_print_brd_info – show board resources in tabular format																		
SYNOPSIS	dr_cmd_print_brd_info <i>sb flags</i>																		
AVAILABILITY	Sun Enterprise 10000 servers only.																		
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness. Instead, use drshow(1M), which presents the information in a more readable format.</p> <p>dr_cmd_print_brd_info obtains configuration information about the specified attached system board. The <i>flags</i> option specifies the information this command is to display, in the form of a bitstring, as follows:</p> <table> <thead> <tr> <th>Flag</th> <th>Value</th> <th>Display</th> </tr> </thead> <tbody> <tr> <td>1</td> <td></td> <td>Processor information</td> </tr> <tr> <td>2</td> <td></td> <td>Controller and peripheral information</td> </tr> <tr> <td>4</td> <td></td> <td>Memory configuration</td> </tr> <tr> <td>8</td> <td></td> <td>Memory cost information</td> </tr> <tr> <td>16</td> <td></td> <td>Memory drain status</td> </tr> </tbody> </table> <p>You can obtain multiple displays by OR'ing (summing) the above decimal values. All displays are in a readable, tabular format.</p>	Flag	Value	Display	1		Processor information	2		Controller and peripheral information	4		Memory configuration	8		Memory cost information	16		Memory drain status
Flag	Value	Display																	
1		Processor information																	
2		Controller and peripheral information																	
4		Memory configuration																	
8		Memory cost information																	
16		Memory drain status																	
EXAMPLES	<p>To display the Processor and Memory configuration:</p> <pre>dr> dr_cmd_print_brd_info 5</pre> <p>To display all configuration information:</p> <pre>dr> dr_cmd_print_brd_info 31</pre>																		
OPTIONS	<p><i>sb</i> The board number (0 to 15) of the target system board.</p> <p><i>flags</i> A bitstring in decimal that represents the desired information.</p>																		
EXIT STATUS	<p>If dr_cmd_print_brd_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.</p> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>																		

NAME	dr_cmd_print_obp_info – show system board info per OpenBoot™ Prom in tabular format
SYNOPSIS	dr_cmd_print_obp_info sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness. Instead, use drshow(1M), which presents the information in a more readable format.</p> <p>dr_cmd_print_brd_info obtains system board configuration information from OpenBoot, then displays that information in a tabular format. Use this command to interrogate a system board that has been Init Attached, but not yet Complete Attached.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the target system board.
EXIT STATUS	If dr_cmd_print_obp succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.
	<p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>

NAME	dr_cmd_print_unsafe_info – show a domain's open, unsafe devices in tabular format
SYNOPSIS	dr_cmd_print_unsafe_info
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness. Instead, use drshow(1M), which displays the information in a more readable format.</p> <p>dr_cmd_print_unsafe_info queries the target domain to determine if any unsafe peripheral devices are open. (See the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i> for more information concerning DR unsafe devices.) If it finds that any such devices are open, it sends that information to stdout.</p> <p>If dr_cmd_print_unsafe_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.</p> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>

NAME	dr_cmd_unsafe_dev_info – show a domain's open, unsafe devices in TCL encoding
SYNOPSIS	dr_cmd_unsafe_dev_info
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Caution: Do not use this command, which runs in the DR shell; it is included here only for completeness. Instead, use drshow(1M), which displays the information in a more readable format.</p> <p>dr_cmd_unsafe_dev_info queries the target domain to determine if any unsafe peripheral devices are open. (See the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i> for more information concerning DR unsafe devices.) If it finds that any such devices are open, it returns that information in a Tcl list encoding, which is used by the drvview(1M) application.</p> <p>If dr_cmd_unsafe_dev_info succeeds it returns a 0 result code in the dr_return global variable. If it fails, it returns a 1 and displays diagnostic messages.</p> <p>Note: Tcl parsing errors prevent DR commands from running which, in turn, leaves dr_return uninitialized. In such cases, the dr_return error code is meaningless. See dr(1M) for more information concerning return codes.</p>

NAME	drain – start memory drain
SYNOPSIS	drain <i>sb</i> [<i>wait</i>]
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>The drain command, which you execute from the dr(1M) prompt, is the first of a two-step procedure for DR detaching a system board. The primary function of the drain command is to determine how the memory physically located on the designated board should be vacated. This memory may be simply flushed, or it may be copied to memory available on another system board in the same domain.</p> <p>If a suitable target memory for the memory copy is not available when the drain command is invoked, the request is denied. If the unavailability is due to run-time conditions and system load, you can retry the drain operation at a later time.</p> <p>The drain command starts the drain operation, and then returns. The drain may take several minutes to complete. You can execute drshow sb DRAIN to monitor its progress; see drshow(1M). Or, you can specify the wait option, and the drain command returns only after the board has been fully drained, or drain detects an error. drain automatically displays the board status once before returning.</p>
OPTIONS	<p>sb The board number (0 to 15) of the system board to be drained.</p> <p>wait Poll the DR daemon every 5 seconds and return to the caller only after the drain completes. This option is useful when the drain is performed by a script. This option is case-insensitive.</p>
EXIT STATUS	Upon successful initiation of the drain, drain returns a 0 in the dr_return global variable; if the initiation fails, it returns a 1. If wait is specified, a 0 in dr_return indicates that the drain (not just initiation of it) has completed successfully, and a 1 indicates that the drain has failed.
EXAMPLE	<pre>ts4-ssp% domain_switch ts4 ts4-ssp% dr Checking environment... Establishing Control Board Server connection... Initializing SSP SNMP MIB... Establishing communication with DR daemon... ts4: System Status - Summary BOARD #: 1 3 4 5 being used by the system. dr> drain 5 Removing board 5 from domain_config file. Start draining board 5.</pre>

Board drain started. Retrieving System Info...

Bound Processes for Board 5

cpu	user	sys	procs
20	0	1	
21	0	1	
22	0	1	
23	0	1	

No active IO devices.

Memory Drain for Board 5 - IN PROGRESS

Reduction = 1024 MBytes

Remaining in System = 2048 MBytes

Percent Complete = 0% (1048576 KBytes remaining)

Drain operation started at Sun Sep 15 22:50:57 1996

Current time Sun Sep 15 22:50:57 1996

Memory Drain is in progress. When Drain has finished,
you may COMPLETE the board detach.

NOTES If DR detects a usage syntax error, it immediately aborts the **dr(1M)** command, displays the **dr(1M)** shell prompt, and leaves **dr_return** unmodified. See **dr(1M)**.

SEE ALSO **dr(1M)** in this reference manual
domain_switch(1M) in the *Ultra Enterprise 10000 SSP Reference Manual*

NAME	drshow – display DR and board resource information
SYNOPSIS	drshow UNSAFE [<i>interval</i> [<i>count</i>]] drshow sb [<i>report_type</i>] [<i>interval</i> [<i>count</i>]] drshow ALL [<i>report_type</i>] [<i>interval</i> [<i>count</i>]]
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	drshow displays board-level and system-level resources and information about DR. It presents the displays in a tabular format. drshow can sample at a specified interval (in seconds), for a given number of times. This polling capability is especially useful to monitor an in-progress drain operation.
OPTIONS	See the SYNOPSIS line for acceptable combinations. UNSAFE Display all unsafe devices that are open throughout the domain. <i>sb</i> The board number (0 to 15) of the target domain. ALL Report the requested information for all active system boards in the domain. You can specify this keyword with one (and only one) of the following report types: CPU , IO , or MEM . <i>report_type</i> The type of information to be displayed. Specify <i>report_type</i> as one of the following keywords. Note that all keyword arguments are case-insensitive. CPU Show processor information for the board (default) DRAIN Show the progress of any active drain operation IO Show the devices attached to this board OBP Display the board configuration as OBP sees it. The OBP display can be used on a board that has been init-attached, and not yet complete-attach'ed. The OBP display may not be as accurate as the CPU/MEM/IO displays for boards in use. MEM Show the memory configuration of this board <i>interval</i> The frequency, in seconds, with which drshow is to repeat the display. <i>count</i> The number of times drshow is to repeat the display.
NOTES	Exercise caution when using repeating displays. The only way to prematurely stop one is by hitting Control-C , which terminates the DR shell.
EXIT STATUS	drshow always returns a character 0 result code in dr_return .

EXAMPLE

```
dr> drshow 1 IO
```

```
I/O Bus Controllers and Devices for Board 1

----- I/O Bus 1 : Slot 0 : esp0 -----

device    opens   name           usage
-----  -----
sd0        0       /dev/dsk/c0t0d0s0
sd1        26      /dev/dsk/c0t1d0s0
                  0       /dev/dsk/c0t1d0s1     swap, /tmp
                  9       /dev/dsk/c0t1d0s3     /var
                  1       /dev/dsk/c0t1d0s5     /opt
                  18      /dev/dsk/c0t1d0s6     /usr
                  1       /dev/dsk/c0t1d0s7     /export
sd2        0       /dev/dsk/c0t2d0s0
sd3        0       /dev/dsk/c0t3d0s1     swap, /tmp
                  0       /dev/dsk/c0t3d0s7     /xfer

----- I/O Bus 1 : Slot 1 : qec0 -----

device    opens   name           usage
-----  -----
qe0        qe0      qe0          ts4 (129.153.49.118)
qe1        qe1      qe1
qe2        qe2      qe2
qe3        qe3      qe3
```

SEE ALSO**dr(1M)***Sun Enterprise 10000 Dynamic Reconfiguration User's Guide*

NAME	drvview – DR Graphical User Interface
SYNOPSIS	drvview
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>drvview is the Graphical User Interface (GUI) for Dynamic Reconfiguration (DR). Do not invoke it directly; it is automatically initiated by Hostview. See hostview(1M) in the <i>Ultra Enterprise 10000 SSP Reference Manual</i>.</p> <p>For more information about Hostview see the <i>Ultra Enterprise 10000 SSP User's Guide</i> and for more information about drvview see the <i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i></p>
SEE ALSO	<p>hostview(1M) in the <i>Ultra Enterprise 10000 SSP Reference Manual</i>.</p> <p><i>Ultra Enterprise 10000 SSP User's Guide</i></p>

NAME	init_attach – initiate a DR attach operation
SYNOPSIS	init_attach sb
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Execute this command at the dr(1M) shell prompt to begin a DR Attach operation. The system board to be attached must be present, powered-on, and currently in no domain. It is diagnosed and debuted to the Enterprise 10000 target domain specified by the SUNW_HOSTNAME environment variable. Upon completion of the init_attach, the board's resources – processors, memory, and I/O controllers – are prepared for attachment by the operating system. The board is added to the board list in the SSP's domain_config(4) file, and the Enterprise 10000 centerplane is reconfigured such that the board is visible to the target domain.</p> <p>Upon successful completion of init_attach you can use complete_attach(1M) to complete the attach operation or abort_attach(1M) to abort it.</p>
OPTIONS	<i>sb</i> The board number (0 to 15) of the system board to be attached.
EXIT STATUS	If successful, init_attach returns a 0 in the dr_return global variable; if not, it returns a 1, along with one or more diagnostic messages.
EXAMPLE	<pre>ts4-ssp% domain_switch ts4 ts4-ssp% dr Checking environment... Establishing Control Board Server connection... Initializing SSP SNMP MIB... Establishing communication with DR daemon... ts4: System Status - Summary BOARD #: 5 physically present. BOARD #: 1 3 4 being used by the system. dr> init_attach 5 Initiate attaching board 5 to domain ts4. Adding board 5 to domain_config file. /opt/SUNWssp/bin/hpost -H20,4 Opening SNMP server library... Reading centerplane asics to obtain bus configuration... Bus configuration established as 3F. phase cplane_isolate: CP domain cluster mask clear... phase init_reset: Initial system resets...</pre>

```

phase jtag_integ: JTAG probe and integrity test...
phase mem_probe: Memory dimm probe...
phase iom_probe: I/O module type probe...
phase jtag_bbsram: JTAG basic test of bootbus sram...
phase procl: Initial processor module tests...
phase pc/cic_reg: PC and CIC register tests...
phase dtag: CIC DTAG tests...
phase mem: MC register and memory tests...
phase io: I/O controller tests...
phase procmem2: Processor vs. memory II tests...
phase lbexit: Centerplane connection tests...
phase final_config: Final configuration...
Configuring in 3F, FOM = 1024.00: 4 procs, 2 SCards, 1024 MBytes.
Creating OBP handoff structures...
Configured in 3F with 4 processors, 2 SBUS cards, 1024 MBytes memory.
Interconnect frequency is 83.273 MHz, from SNMP MIB.
Processor frequency is 166.589 MHz, from SNMP MIB.
Boot processor is 5.0 = 20
POST (level=16, verbose=20, -H4,0020) execution time 3:50
hpost is complete.
obp_helper -H -m20
Board debut complete.
Reconfiguring domain mask registers.
Probing board resources.
Board attachment initiated successfully.

Ready to COMPLETE board attachment.

dr>

```

DIAGNOSTICS

add_board_to_domain returns entry not found

The target domain specified by the SUNW_HOSTNAME environment variable is not properly listed in the **domain_config(4)** file. Check the **domain_config(4)** file, then try the operation again at a later time.

add_board_to_domain returns entry not found

Unable to locate domain *target domain* in **domain_config** file.

DR was unable to locate an entry for the current target domain. Use the **domain_status(1M)** command to verify the contents of the **domain_config(4)** file. See the *Ultra Enterprise 10000 SSP Reference Manual*.

Board debut failed - return = *value*

The debut utility has failed (see **obp_helper(1M)** in *Ultra Enterprise 10000 SSP Reference Manual*). Consult the SSP message files for information regarding the failure.

Board *brd* is a member of a foreign hardware domain.

The board you are trying to attach has been identified as a member of another domain on this platform, which prevents it from being attached to the designated target domain. You must remove this board from the other domain before initiating an attach.

Board *brd* is not eligible for attach

One or more conditions is preventing this board from being attached to the target domain. The board must be physically present, powered on, and not a member of any domain to be eligible for attachment.

Board may be Black or Red listed.

If this board is blacklisted or redlisted, it cannot be attached. Check the **postrc(4)** file for the location of the **blacklist(4)** and **redlist(4)** files.

DR Error: State for board *brd* can't be determined.

During initial domain contact an unexpected board condition was detected by **dr_daemon(1M)**. (See **dr_daemon(1M)** in the *Solaris Reference for SMCC-Specific Software*.) Check the system log on the host for more information.

Error executing *command*

dr(1M) executed the indicated command, but it returned a failure indication. If the error message specifies a specific action you must take, do so, then retry the command. Otherwise, simply retry the **init_attach** operation at a later time. If that attempt fails, call your service provider.

FAD error detected, retrying...

A transient failure occurred during updating of the **domain_config(4)** file has been. **init_attach** will retry the operation. If all retries fail, consult the SSP messages files for more information.

Failed to initiate board attachment

The **init_attach** operation on the target domain has failed.

Unable to execute *command*

dr(1M) could not execute the indicated command. Check that the program file exists and is assigned the appropriate modes.

NOTES If DR detects a usage syntax error, it immediately aborts the **dr(1M)** command, displays the **dr(1M)** shell prompt, and leaves **dr_return** unmodified. See **dr(1M)**.

SEE ALSO **dr(1M)** in this Reference Manual

blacklist(4), **domain_config(4)**, **domain_status(1M)**, **domain_switch(1M)**, **postrc(4)**, **redlist(4)** in Section 4 of the *Ultra Enterprise 10000 SSP Reference Manual*

dr_daemon(1M) in the *Solaris Reference for SMCC-Specific Software*

NAME	reconfig – initiate auto-configuration sequence
SYNOPSIS	reconfig
AVAILABILITY	Sun Enterprise 10000 servers only.
DESCRIPTION	<p>Warning: This command can remap device files and cause the renaming of known devices. Use it with extreme caution.</p> <p>Execute this command at the dr(1M) shell prompt after a new board has been attached to a running domain to make the board's devices immediately available for use.</p> <p>reconfig executes the standard Solaris configuration sequence in the target domain. This sequence consists of the following commands, shown here in the proper order: drvconfig(1M), devlinks(1M), disks(1M), ports(1M), and tapes(1M).</p>
EXIT STATUS	reconfig returns a 0 in the dr_return global variable upon success, or a 1 upon failure.
EXAMPLE	<pre>dr> reconfig Reconfiguration of devices in progress... Reconfiguration completed successfully.</pre>
DIAGNOSTICS	<p>Reconfiguration failed</p> <p>One or more of the Enterprise 10000 domain's reconfiguration commands has failed. Check the /var/adm/messages file on the Enterprise 10000 domain.</p>
NOTES	If DR detects a usage syntax error, it immediately aborts the dr(1M) command, displays the dr(1M) shell prompt, and leaves dr_return unmodified. See dr(1M) .
SEE ALSO	<p>dr(1M) in this Reference Manual</p> <p>drvconfig(1M), devlinks(1M), disks(1M), ports(1M), tapes(1M) in <i>man Pages(1M): System Administration Commands</i> of the <i>SunOS Reference Manual</i>.</p>