



Sun Fire™ V210 and V240 Servers Service Manual

Sun Microsystems, Inc.
www.sun.com

Part No. 819-4207-10
December 2005, Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright 2005 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at <http://www.sun.com/patents> and one or more additional patents or pending patent applications in the U.S. and in other countries.

This document and the product to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of the product or of this document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, Sun Fire, Java, OpenBoot, docs.sun.com, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

U.S. Government Rights—Commercial use. Government users are subject to the Sun Microsystems, Inc. standard license agreement and applicable provisions of the FAR and its supplements.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2005 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, Californie 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. a les droits de propriété intellectuels relatants à la technologie qui est décrit dans ce document. En particulier, et sans la limitation, ces droits de propriété intellectuels peuvent inclure un ou plus des brevets américains énumérés à <http://www.sun.com/patents> et un ou les brevets plus supplémentaires ou les applications de brevet en attente dans les Etats-Unis et dans les autres pays.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a.

Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, Sun Fire, Java, OpenBoot, docs.sun.com, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciées de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ÉTAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.



Contents

Preface ix

- 1. Parts Removal and Installation 1-1**
 - 1.1 Replaceable Components 1-3
 - 1.2 Controlling Server Power 1-3
 - 1.2.1 Powering On the Server 1-3
 - 1.2.2 Powering Off the Server 1-4
 - 1.3 Avoiding Electrostatic Discharge 1-5
 - 1.3.1 Avoiding Electrostatic Discharge While Working on the Back of the Server 1-5
 - 1.3.2 Avoiding Electrostatic Discharge While Working on the Front of the Server 1-6
 - 1.4 Opening the Server 1-7
 - 1.4.1 Removing the Front Section of the Cover Assembly 1-7
 - 1.4.2 Installing the Front Section of the Cover Assembly 1-9
 - 1.4.3 Opening the Back Section of the Cover Assembly 1-9
 - 1.4.4 Closing the Back Section of the Cover Assembly 1-11
 - 1.4.5 Removing the Whole Cover Assembly 1-11
 - 1.5 Location of Components 1-12
 - 1.6 Front Bezel Assembly 1-15
 - 1.6.1 Removing the Bezel Assembly 1-15

- 1.6.2 Installing the Bezel Assembly 1-15
- 1.7 Hard Drives 1-15
 - 1.7.1 Removing a Hard Drive 1-16
 - 1.7.2 Installing a Hard Drive 1-16
- 1.8 System Configuration Card Reader 1-17
 - 1.8.1 Removing the System Configuration Card Reader 1-17
 - 1.8.2 Installing the System Configuration Card Reader 1-19
- 1.9 Power Supply Unit 1-20
 - 1.9.1 Removing the PSU From a Sun Fire V210 Server 1-20
 - 1.9.2 Installing a PSU into a Sun Fire V210 Server 1-20
 - 1.9.3 Removing a PSU From a Sun Fire V240 Server 1-21
 - 1.9.4 Installing a PSU into a Sun Fire V240 Server 1-23
- 1.10 Power Distribution Board 1-24
 - 1.10.1 Removing the Power Distribution Board 1-24
 - 1.10.2 Installing the Power Distribution Board 1-25
- 1.11 Memory 1-26
 - 1.11.1 Memory Configuration Rules 1-26
 - 1.11.2 Installing Memory 1-26
 - 1.11.3 Removing Memory 1-27
- 1.12 Fans 1-28
 - 1.12.1 Removing a Fan 1-28
 - 1.12.2 Replacing a Fan 1-29
- 1.13 CPU, Heat Sink, and System Board Assembly 1-29
 - 1.13.1 Removing the System Board 1-30
 - 1.13.2 Installing a System Board 1-33
- 1.14 Upper and Lower Interface Board Assemblies 1-33
 - 1.14.1 Removing an Upper Interface Board Assembly (Sun Fire V240 Server) 1-33

- 1.14.2 Installing an Upper Interface Board Assembly (Sun Fire V240 Server) 1–35
- 1.14.3 Removing a Lower Interface Board Assembly 1–35
- 1.14.4 Installing a Lower Interface Board Assembly 1–36
- 1.15 PCI Cards 1–37
 - 1.15.1 Adding a PCI Card 1–38
 - 1.15.1.1 Replacing a PCI card 1–39
- 1.16 PCI Riser Card 1–40
 - 1.16.1 Removing the PCI Riser Card Assembly (Sun Fire V240 Only) 1–40
 - 1.16.2 Installing the PCI Riser Card Assembly 1–41
- 1.17 Sun Cryptographic Accelerator 1–41
 - 1.17.1 Removing the Sun Cryptographic Accelerator 1–42
 - 1.17.2 Installing the Sun Cryptographic Accelerator 1–42
- 1.18 Battery 1–43
 - 1.18.1 Replacing the RTC Battery 1–43
- 1.19 Keyswitch Assembly 1–43
 - 1.19.1 Removing the Keyswitch Assembly 1–43
 - 1.19.2 Replacing the Keyswitch Assembly 1–46

Index Index–1

Figures

- [FIGURE 1-1](#) Grounding Point in Back of the Server (Sun Fire V240 Server) 1–6
- [FIGURE 1-2](#) Location of Screws on the Front Section of the Cover 1–8
- [FIGURE 1-3](#) Removing the Front Section of the Cover 1–9
- [FIGURE 1-4](#) Location of Captive Screw and Side Catches on Back Section of the Cover 1–10
- [FIGURE 1-5](#) Location of Catch on Back Section of the Cover 1–11
- [FIGURE 1-6](#) Removing the U-Channel 1–12
- [FIGURE 1-7](#) Location of Major Components in a Sun Fire V210 Server 1–13
- [FIGURE 1-8](#) Location of Major Components in a Sun Fire V240 Server 1–14
- [FIGURE 1-9](#) Removing a Hard Drive 1–16
- [FIGURE 1-10](#) Location of Connectors on the System Configuration Card Reader 1–18
- [FIGURE 1-11](#) Removing the System Configuration Card Reader 1–19
- [FIGURE 1-12](#) Power Supply Unit Lever on a Sun Fire V240 Server 1–22
- [FIGURE 1-13](#) Removing a PSU on a Sun Fire V240 Server 1–23
- [FIGURE 1-14](#) Location of PDB Connectors on the System Board 1–24
- [FIGURE 1-15](#) Removing the Power Distribution Board (Sun Fire V240) 1–25
- [FIGURE 1-16](#) Installing Memory 1–27
- [FIGURE 1-17](#) Disconnecting a Fan Power Cable (Sun Fire V240 Server) 1–28
- [FIGURE 1-18](#) Removing Fans (Sun Fire V240 Server) 1–29
- [FIGURE 1-19](#) Accessing the System Board for Removal 1–31
- [FIGURE 1-20](#) Removing the System Board From the Chassis 1–32

FIGURE 1-21	Removing Cover Assembly and Hard Drives to Access Interface Boards	1-34
FIGURE 1-22	Removing the Interface Boards	1-35
FIGURE 1-23	Lower Interface Board Standoff and Screw Locations	1-37
FIGURE 1-24	Location of PCI Lockdown Screw	1-38
FIGURE 1-25	Removing a PCI Card on a Sun Fire V240 Server	1-39
FIGURE 1-26	Location of PCI Riser Card Screws	1-40
FIGURE 1-27	Removing the PCI Riser Card Assembly	1-41
FIGURE 1-28	Removing the Cryptographic Accelerator	1-42
FIGURE 1-29	Disconnecting the Keypad Wiring Harness	1-44
FIGURE 1-30	Removing the Keypad Locknut	1-45
FIGURE 1-31	Removing the Keypad Assembly	1-45

Preface

The *Sun Fire™ V210 and V240 Servers Service Manual* (819-4207-10) is for use by qualified service personnel only. This manual provides detailed instructions about service procedures for the Sun Fire V210 and V240 servers.

Before You Read This Document

This book does not cover server installation. For detailed information on this topic, refer to the *Sun Fire V210 and V240 Servers Installation Guide* (819-4209). Before following any procedures described in this book, ensure that you have read the *Sun Fire V210 and V240 Servers Compliance and Safety Manual* (817-4827-12).

How This Document Is Organized

Chapter 1 describes the parts removal and installation procedures for the Sun Fire V210 and V240 servers.

Using UNIX Commands

This document does not contain information on basic UNIX® commands and procedures such as shutting down the system, booting the system, and configuring devices.

Refer to one or more of the following documents for this information:

- *Solaris™ 10 Sun Hardware Platform Guide* (817-6337)
- Solaris Operating System documentation, which is at:
<http://docs.sun.com>
- Other software documentation that you received with your system

Shell Prompts

Shell	Prompt
C shell	<i>machine-name%</i>
C shell superuser	<i>machine-name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

Typographic Conventions

Typeface*	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
AaBbCc123	What you type, when contrasted with on-screen computer output	% su Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this. To delete a file, type <code>rm filename</code> .

* The settings on your browser might differ from these settings.

Related Documentation

Application	Title	Part Number
Quick set up	<i>Sun Fire V210 and V240 Servers Getting Started Guide</i>	819-4206
Installation	<i>Sun Fire V210 and V240 Servers Installation Guide</i>	819-4209
Latest information	<i>Sun Fire V210 and V240 Servers Product Notes</i>	819-4205
Administration	<i>Sun Fire V210 and V240 Servers Administration Guide</i>	819-4208
Compliance and safety	<i>Sun Fire V210 and V240 Servers Compliance and Safety Manual</i>	817-4827-12
Lights-Out Management	<i>Advanced Lights Out Manager Software User's Guide</i>	817-5481

Read *Important Safety Information* (816-7190) and the *Sun Fire V210 and V240 Servers Getting Started Guide* (816-4206) before performing any of the procedures documented in this manual. The documents listed above are available online at:

<http://www.sun.com/products-n-solutions/hardware/docs/>

Documentation, Support, and Training

Sun Function	URL
Documentation	http://www.sun.com/documentation/
Support	http://www.sun.com/support/
Training	http://www.sun.com/training/

Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

Sun Fire V210 and V240 Servers Service Manual, part number 819-4207-10

Parts Removal and Installation

This chapter contains procedures for replacing the Sun Fire V210 and V240 servers' internal hardware components.



Caution – The procedures in this section are for qualified service engineers only.



Caution – Read [Section 1.8, “System Configuration Card Reader”](#) on page 1-17, and wear a properly grounded antistatic strap, before you carry out any of the procedures in this document.

The chapter contains the following sections:

- [Section 1.1, “Replaceable Components”](#) on page 1-3
- [Section 1.2, “Controlling Server Power”](#) on page 1-3
- [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5
- [Section 1.4, “Opening the Server”](#) on page 1-7
- [Section 1.5, “Location of Components”](#) on page 1-12
- [Section 1.6, “Front Bezel Assembly”](#) on page 1-15
- [Section 1.7, “Hard Drives”](#) on page 1-15
- [Section 1.8, “System Configuration Card Reader”](#) on page 1-17
- [Section 1.9, “Power Supply Unit”](#) on page 1-20
- [Section 1.10, “Power Distribution Board”](#) on page 1-24
- [Section 1.11, “Memory”](#) on page 1-26
- [Section 1.12, “Fans”](#) on page 1-28
- [Section 1.13, “CPU, Heat Sink, and System Board Assembly”](#) on page 1-29
- [Section 1.14, “Upper and Lower Interface Board Assemblies”](#) on page 1-33
- [Section 1.15, “PCI Cards”](#) on page 1-37

- Section 1.16, “PCI Riser Card” on page 1-40
- Section 1.17, “Sun Cryptographic Accelerator” on page 1-41
- Section 1.18, “Battery” on page 1-43
- Section 1.19, “Keyswitch Assembly” on page 1-43

1.1 Replaceable Components

Replaceable components in the front of the server are:

- Bezel assembly
- Hard drive
- System configuration card reader
- Lower interface board
- Upper interface board (Sun Fire V240 server)
- Keyswitch assembly (Sun Fire V240 server)

The remaining replaceable components are in the back of the server.



Caution – Printed circuit boards and hard drives contain electronic components that are extremely sensitive to static electricity. Ordinary amounts of static from your clothes or the work environment can destroy components. Do not touch the components or any metal parts without taking proper antistatic precautions.

Before you carry out the procedures covered in this document, the server must be powered down. To do this you must remove the power cable. Follow the instructions in [Section 1.2.2, “Powering Off the Server”](#) on page 1-4.

1.2 Controlling Server Power

The On/Standby button does not power off the server, but it toggles the server between on and Standby mode.

1.2.1 Powering On the Server



Caution – Never move the system when the system power is on. Movement can cause catastrophic drive failure. Always power off the system before moving it.

1. Connect the server to an AC power source.

Once connected, the server automatically goes into Standby power mode.

2. **Turn on power to any peripherals and external storage devices you have connected to the server.**
Read the documentation supplied with the device for specific instructions.
3. **Open the bezel.**
4. **Sun Fire V240 server only: Insert the system key into the keyswitch and set it to the Normal or Diagnostics position.**
5. **Press the On/Standby switch.**
6. **Take the following action (Sun Fire V240 server):**
 - a. **Turn the keyswitch to the Locked position.**
This prevents anyone from accidentally powering off the system.
 - b. **Remove the system key from the keyswitch and secure it in the clip inside bezel.**
7. **Close the bezel.**

1.2.2 Powering Off the Server

1. **Notify users that the system will be powered down.**
2. **Back up system files and data.**
3. **Ensure that the keyswitch is in the Normal or Diagnostics position (Sun Fire V240 server).**
4. **Press and release the On/Standby switch behind the bezel.**
The system begins an orderly software system shutdown.

Note – Pressing and releasing the On/Standby switch initiates an orderly software shutdown. Pressing and holding the switch for four seconds causes an immediate hardware shutdown. Whenever possible, initiate an orderly shutdown. Forcing an immediate hardware shutdown can corrupt the hard drive and cause loss of data.

5. **Wait for the front panel green LED to go out.**
6. **Remove the system key from the keyswitch and secure the key in the clip inside the bezel (Sun Fire V240 server).**



Caution – As long as the power cord is connected, potentially hazardous energy is present inside the server.

7. Disconnect the power cable.

This is the only way to remove power from the server. Electrical power is present when the server is in Standby mode.

1.3 Avoiding Electrostatic Discharge

Whenever you work with the server's internal components, follow this procedure to prevent damage caused by static electricity.

You need the following items:

- Antistatic wrist or foot strap
- Antistatic mat

1.3.1 Avoiding Electrostatic Discharge While Working on the Back of the Server

1. Power off the server.

See [Section 1.2, "Controlling Server Power"](#) on page 1-3.

2. Open the back section of the cover.

See [Section 1.4, "Opening the Server"](#) on page 1-7.

3. Attach one end of the antistatic strap to the grounding stud located on the partition inside the server, and the other end to your wrist.




FIGURE 1-1 Grounding Point in Back of the Server (Sun Fire V240 Server)

1.3.2 Avoiding Electrostatic Discharge While Working on the Front of the Server

1. Power off the server.

See [Section 1.2, “Controlling Server Power”](#) on page 1-3.

2. Perform either step a or steps b and c.

a. Attach one end of the antistatic strap to a grounding point on the rack and the other to your wrist.

b. Remove the server from the rack.

c. **Place the server on an antistatic mat or other suitable antistatic surface.**

Suitable antistatic surfaces include:

- Sun electrostatic discharge (ESD) mat, Sun part number 250-1088 (available through your Sun sales representatives)
- The bag or shipping container used to package Sun replacement parts
- Disposable ESD mat, shipped with replacement parts or options

1.4 Opening the Server

The cover of the server is split into two sections, front and back.

- The back section hinges to provide access.
- The front section detaches to provide access.
- The whole cover assembly detaches to provide access to both front and back sections of the server. This is necessary to replace some components.



Caution – Disconnect the power cord before carrying out this procedure. As long as the power cord is connected, potentially hazardous energy is present inside the server.



Caution – After servicing, install and fasten the cover before plugging in the power cords or turning power on.

1.4.1 Removing the Front Section of the Cover Assembly

1. **Open the bezel.**

2. Undo the screws that fasten the front section of the cover to the chassis (FIGURE 1-2).




FIGURE 1-2 Location of Screws on the Front Section of the Cover

3. Slide the front section of the cover towards the front of the server. Use the indentations in the cover to provide grip if necessary.

4. Lift off the front section of the cover (FIGURE 1-3).




FIGURE 1-3 Removing the Front Section of the Cover

1.4.2 Installing the Front Section of the Cover Assembly

1. Align the clips on the bottom of the cover with the corresponding slots in the server chassis.
2. Press the cover down into the slots.
3. Slide the cover towards the back of the server.
4. Replace the screws that fasten the cover to the server.

1.4.3 Opening the Back Section of the Cover Assembly

1. Locate the latches at the back of the server and release them (FIGURE 1-4).
2. Undo the captive Phillips screw in the catch on top of the server (FIGURE 1-4).



FIGURE 1-4 Location of Captive Screw and Side Catches on Back Section of the Cover

- 3. Pull the lever to release the catch and lift the cover up, pulling from the center and one corner of the cover.**

The cover hinges forward to lay flush against the front section of the server.

- 4. (Sun Fire V240 server) Unscrew and remove the green air duct (FIGURE 1-8).**

The air duct is not a part of the cover assembly, but you must remove it to gain access to components in the back section of the server.



FIGURE 1-5 Location of Catch on Back Section of the Cover

1.4.4 Closing the Back Section of the Cover Assembly

1. **(Sun Fire V240 server) Install the green air duct.**
This is essential to ensure correct cooling of the server.
2. **Rotate the cover back to its closed position.**
Ensure that the catch clips the cover into its closed position.
3. **Tighten the captive screw in the catch on the cover.**
4. **Secure the cover using the clips on the outside of the server.**

1.4.5 Removing the Whole Cover Assembly

1. **Remove the front section of the cover assembly.**
See [Section 1.4.1, “Removing the Front Section of the Cover Assembly”](#) on page 1-7.
2. **Open the back section of the cover assembly.**
See [Section 1.4.3, “Opening the Back Section of the Cover Assembly”](#) on page 1-9.

3. Remove the back section of the cover assembly.
4. (Sun Fire V240 server) Unscrew and remove the green air duct.
5. Unclip the U-channel that runs across the server and remove it (FIGURE 1-6).
You must remove this bar to reach the cables that connect the front of the server to the rear.




FIGURE 1-6 Removing the U-Channel

1.5 Location of Components

The internal components of the server are located in [FIGURE 1-7](#) and [FIGURE 1-8](#).




FIGURE 1-7 Location of Major Components in a Sun Fire V210 Server




FIGURE 1-8 Location of Major Components in a Sun Fire V240 Server

1.6 Front Bezel Assembly

The front bezel assembly includes the bezel, the front server status indicators, and hinges. It is replaced as a single unit.

1.6.1 Removing the Bezel Assembly

1. Power off the server.

See [Section 1.2, “Controlling Server Power”](#) on page 1-3.

2. Ensure the server is properly grounded.

See the instructions in [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.

3. Hold the bezel firmly at both ends and rotate it down to its open position.

Grip the bezel at the points marked by the green triangles at each end to open it. Do not attempt to open the bezel using a single gripping point or by holding the middle of the bezel as damage may occur.

4. Disconnect the cable connecting the bezel assembly to the server.

5. Unscrew the bezel hinges and remove them from the server.

1.6.2 Installing the Bezel Assembly

1. Locate the new bezel and hinges onto the server and screw them to the server.

2. Reconnect the bezel cable.

1.7 Hard Drives

For information on removing a hard drive while the operating server is running, see the *Sun Fire V210 and V240 Servers Administration Guide* (819-4208).

1.7.1 Removing a Hard Drive

1. **Ensure that you are properly grounded.**
See [Section 1.3, "Avoiding Electrostatic Discharge"](#) on page 1-5.
2. **Open the front bezel.**
3. **Check that the blue indicator LED is lit on the hard drive.**
The blue LED comes on when the hard drive is ready to remove.
4. **Slide the catch at the front of the hard drive to the right (FIGURE 1-9).**
The handle on the front of the hard drive releases.
5. **Pull the handle and remove the hard drive from the server by sliding the drive out from its bay.**




FIGURE 1-9 Removing a Hard Drive

1.7.2 Installing a Hard Drive

1. **Slide the catch on the front of the hard disk to the right.**
This releases the hard drive. The lever must be open *before* you insert the hard drive into the server. If the lever is closed, the hard drive will not correctly engage.

2. **Slide the hard drive into its bay at the front of the server.**

Push the drive in firmly until the metal lever starts to close. The hard drive has engaged with its connector in the server.

3. **Push the metal lever until the hard drive clicks into place.**
4. **Close the bezel.**

1.8 System Configuration Card Reader

For more information on function of the system configuration card, see the *Sun Fire V210 and V240 Servers Administration Guide* (819-4208).

1.8.1 Removing the System Configuration Card Reader

1. **Power off the server.**

See [Section 1.2, “Controlling Server Power”](#) on page 1-3.

2. **Ensure that the server is properly grounded.**

See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.

3. **Remove the front section of the cover assembly.**

See [Section 1.4, “Opening the Server”](#) on page 1-7.

4. **Remove the system configuration card.**

Place the system configuration aside.

5. **Disconnect the cable leading to the lower interface board from the configuration card reader ([FIGURE 1-10](#)).**




FIGURE 1-10 Location of Connectors on the System Configuration Card Reader

6. (Sun Fire V240 server) Disconnect the keyswitch assembly wiring harness (FIGURE 1-10).
7. Unclip the system configuration card reader (FIGURE 1-11).

Hold the reader board firmly and unclip one corner at a time by pulling up. Take care not to damage the On/Standby switch when you remove the assembly.




FIGURE 1-11 Removing the System Configuration Card Reader

1.8.2 Installing the System Configuration Card Reader

1. Position the new configuration card reader board by lining up the fixing holes with the clips in the top of the DVD drive enclosure.
2. Press the new reader board firmly onto the clips to secure it in place.
3. Reconnect the system configuration card reader power cable.
4. (Sun Fire V240) Reconnect the keyswitch cable.
5. Install the system configuration card.

1.9 Power Supply Unit

1.9.1 Removing the PSU From a Sun Fire V210 Server

1. **Power off the server.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3.
2. **Ensure that the server is properly grounded.**
See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.
3. **Remove the cover assembly.**
See [Section 1.4, “Opening the Server”](#) on page 1-7.
4. **Disconnect the cables leading to the system board and interface board.**
5. **Undo the two screws on the back panel of the server.**
6. **Move the PSU towards the front of the server to release it from the locating tab on the base of the server.**
7. **Lift the PSU out of the chassis.**

1.9.2 Installing a PSU into a Sun Fire V210 Server

1. **Position the new PSU over the location tab and slide it towards the back of the server.**
2. **Install and tighten the two screws on the back panel of the server.**
3. **Connect the power supply wiring harness to the connectors on the system board and interface board.**
4. **Install the cover assembly.**

1.9.3 Removing a PSU From a Sun Fire V240 Server

Note – The Sun Fire V240 server has dual redundant power supplies. You can swap one power supply while the other one is still running. For information on removing a power supply unit while the server is in operation, refer to the *Sun Fire V210 and V240 Servers Administration Guide*.

1. Power off the server.

See [Section 1.2, “Controlling Server Power”](#) on page 1-3.



Caution – Power supply units on the Sun Fire V240 server cannot be removed from the server until the power cable has been disconnected from the PSU you are removing.

2. Disconnect the power cable.

When disconnecting a power cable from a PSU socket, ensure that you are disconnecting the cable from the PSU you intend to remove from the server.

3. Pull down the lever on the back of the power supply unit (FIGURE 1-12).

The PSU disconnects from the power distribution board inside the server.



FIGURE 1-12 Power Supply Unit Lever on a Sun Fire V240 Server

4. Slide the PSU out of the server's chassis by pulling on the PSU lever ([FIGURE 1-13](#)).



FIGURE 1-13 Removing a PSU on a Sun Fire V240 Server

1.9.4 Installing a PSU into a Sun Fire V240 Server

1. **Locate the replacement PSU in the PSU bay.**
2. **Slide the PSU into the server until it attaches (seats) to the power distribution board inside.**

Ensure that the lever does not return to a vertical position until the PSU engages with the power distribution board. If the lever moves, the PSU will not engage correctly.

3. **Press the lever until it clicks.**

Returning the lever to a vertical position engages the PSU with the power distribution board inside the server.

1.10 Power Distribution Board

Note – Only the Sun Fire V240 has a power distribution board (PDB). The power distribution board distributes power to components in the front and back of the Sun Fire V240 server.

1.10.1 Removing the Power Distribution Board

1. **Power off the server.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3.
2. **Ensure that the server is properly grounded.**
See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.
3. **Remove the cover assembly.**
See [Section 1.4, “Opening the Server”](#) on page 1-7.
4. **Disconnect the PDB wiring harness from the three connectors on the system board.**



FIGURE 1-14 Location of PDB Connectors on the System Board

5. **Disconnect the PDB cable from the interface board in the front section of the server.**

6. Withdraw the PSU or PSUs from the chassis far enough to unplug them from the PDB (FIGURE 1-15).
7. Unscrew the retaining screws that hold the PDB assembly in place (FIGURE 1-15).




FIGURE 1-15 Removing the Power Distribution Board (Sun Fire V240)

8. Press the plastic retaining clip holding the wiring harness out of the dividing wall in the server.
9. Remove the PDB assembly.

1.10.2 Installing the Power Distribution Board

1. Locate the replacement PDB in the server's chassis.
2. Replace and tighten the retaining screws.
3. Reconnect all cables.
4. Reconnect the PSU(s).
See [Section 1.9.3, "Removing a PSU From a Sun Fire V240 Server"](#) on page 1-21.
5. Replace the cover.

1.11 Memory

There are four memory module sockets per processor on the server's system board. Memory is supplied by Sun in paired DIMMS. Ensure that you use the DIMM pairs as supplied and do not mix them.

For a list of the available memory options, see the *Sun Fire V210 and V240 Server Administration Guide* (819-4208).

1.11.1 Memory Configuration Rules

Memory is shipped in matched pairs for use on the Sun Fire V210 and V240 servers.

When you install memory into a Sun Fire V210 or V240 server, follow the configuration rules described below:

- A minimum of two matched DIMMs are required for the server. The matched DIMMs must be the same size, manufacturer, and part number.
- DIMMs must be installed in identical pairs with each CPU having separate pairs. Both size and manufacturer must be the same per pair, but you can mix manufacturers and size between pairs.

Note – OpenBoot™ PROM will boot with a vendor (manufacturer) variance in the pair, but will issue a warning message to the console.

Note – OpenBoot PROM 4.16.x and subsequently compatible versions of OpenBoot PROM provide an additional check by comparing DIMM speed and CAS latency to ensure that the DIMM will operate in the server.

1.11.2 Installing Memory

1. **Power down the server and disconnect the power cable.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3
2. **Open the back cover.**
See [Section 1.4.3, “Opening the Back Section of the Cover Assembly”](#) on page 1-9.
3. **Locate the correct DIMM socket.**

4. Ensure that the retaining clips are open ([FIGURE 1-16](#)).
5. Press the memory module in the DIMM socket.
6. Press down until the clips snap into place.




FIGURE 1-16 Installing Memory

1.11.3 Removing Memory

1. **Power down the server and disconnect the power cable.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3.
2. **Open the back cover.**
See [Section 1.4.3, “Opening the Back Section of the Cover Assembly”](#) on page 1-9.
3. **Locate the correct DIMM socket.**
4. **Open the latches at the sides of the socket.**
5. **Remove the module from the DIMM socket.**
6. **Close the rear cover.**

1.12 Fans

The Sun Fire V210 server has four 40 mm fans mounted side by side. Three of these cool the system board, while the fourth cools the PCI card area.

The Sun Fire V240 server uses three 60 mm fans to cool the system board and PCI card areas.

All of these fans plug into the system board individually. The fans can be removed from the server without the use of tools.

1.12.1 Removing a Fan

1. **Open the back section of the cover.**

See [Section 1.4, “Opening the Server”](#) on page 1-7.

2. **Disconnect the fan’s power cable from the system board** ([FIGURE 1-17](#)).




FIGURE 1-17 Disconnecting a Fan Power Cable (Sun Fire V240 Server)

3. **Push back the fan retaining tab.**
4. **Lift the fan out of the chassis** ([FIGURE 1-18](#)).

Pull on the tab on top of the fan assembly.




FIGURE 1-18 Removing Fans (Sun Fire V240 Server)

1.12.2 Replacing a Fan

1. Insert the replacement fan.
2. Connect the fan's power cable to the system board.
3. Install the back section of the cover.

1.13 CPU, Heat Sink, and System Board Assembly

The CPU, heatsink, and system board are replaced as a single assembly.

Tip – To perform the steps in this section, you need a 5 mm wrench to remove and install the SCSI pillars and the DB-9 jackposts.

1.13.1 Removing the System Board

1. Power off the server.

See [Section 1.2, "Controlling Server Power"](#) on page 1-3.

2. Ensure that the server is properly grounded.

See [Section 1.3, "Avoiding Electrostatic Discharge"](#) on page 1-5.

3. Open the back section of the cover.

See [Section 1.4, "Opening the Server"](#) on page 1-7.

4. (Sun Fire V240 server) Remove the air duct.

The air duct clips to the chassis. Unclip the air duct to remove.

5. Disconnect the power supply wiring harness from the system board.

6. Disconnect the interface board SCSI and IDE cables from the system board.

7. If any PCI cards are fitted, remove them.

See [Section 1.15.1, "Adding a PCI Card"](#) on page 1-38.

8. (Sun Fire V240 server) Remove the PCI riser board.

See [Section 1.16, "PCI Riser Card"](#) on page 1-40.

9. Remove the PCI slider assembly.

10. Remove the server fan assembly.

11. Unscrew and remove the DB-9 and SCSI jackposts on the server's back panel.




FIGURE 1-19 Accessing the System Board for Removal

12. Unscrew the system board.

The system board is secured to the chassis by ten screws.

13. Slide the system board towards the front of the chassis so that the SCSI, Ethernet, and serial connectors come free from the chassis.

14. Lift the system board out of the chassis.




FIGURE 1-20 Removing the System Board From the Chassis

1.13.2 Installing a System Board

1. **Insert the new system board and locate it so that the SCSI, Ethernet, and serial connectors are firmly positioned in their slots at the back of the chassis.**
2. **Insert all system board fixing screws loosely.**

Do not put any screws in the holes for the PCI card slide retainer. These holes are identified by a circle printed around their circumference.
3. **Install the PCI riser card assembly.**
4. **Install the PCI slider assembly.**

The arrow embossed on the slider should point to the rear of the server.
5. **Install any PCI cards you removed.**
6. **Reconnect all system board cables and wiring harnesses.**
7. **Install the server's cover and tighten the screws.**

1.14 Upper and Lower Interface Board Assemblies

The interface board assemblies handle the connections between the system board and the components in the front section of the server. The assemblies are positioned in the front section of the server, behind the hard drives and system configuration card reader assembly.

- The Sun Fire V210 server has a lower interface board (LIB) assembly *only*.
- The Sun Fire V240 server has a LIB *and* an upper interface board (UIB) assembly. To gain access to the LIB, you must first remove the UIB.

1.14.1 Removing an Upper Interface Board Assembly (Sun Fire V240 Server)

1. **Power off the server.**

See [Section 1.2, "Controlling Server Power"](#) on page 1-3.
2. **Ensure that the server is properly grounded.**

See [Section 1.3, "Avoiding Electrostatic Discharge"](#) on page 1-5.

3. Remove the cover assembly.

See [Section 1.4, “Opening the Server”](#) on page 1-7.

4. Remove the upper hard drives, if installed.

See [FIGURE 1-21](#).



FIGURE 1-21 Removing Cover Assembly and Hard Drives to Access Interface Boards

5. Disconnect the cable connecting the upper interface board to the lower interface board.

6. Disconnect the PDB cable.

7. Unscrew the seven screws that secure the upper interface board.

8. Lift the UIB out of the server's chassis ([FIGURE 1-22](#)).




FIGURE 1-22 Removing the Interface Boards

1.14.2 Installing an Upper Interface Board Assembly (Sun Fire V240 Server)

1. Locate the new UIB using the two shouldered stand-offs as guides.
2. Screw the UIB into place.
3. Attach the LIB, PDB, and system board connection cables.
4. Install the cover.

1.14.3 Removing a Lower Interface Board Assembly

1. **Power off the server.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3.
2. **Ensure that the server is properly grounded.**
See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.

3. Remove all hard drives.
4. Remove DVD drive, if fitted.
5. Remove the cover assembly.
See [Section 1.4, "Opening the Server"](#) on page 1-7.
6. (Sun Fire V240 server) remove the UIB.
See ["Removing an Upper Interface Board Assembly \(Sun Fire V240 Server\)"](#) on page 33.
7. Disconnect the system board cable.
8. Disconnect the PSU cable.
9. Disconnect the system configuration card reader cable.
10. Unscrew the three screws and five stand-offs that secure the LIB to the server's chassis.
11. Lift the LIB assembly part of the way out of the server chassis.
12. Disconnect the cable from the bezel assembly.
13. Remove the LIB from the server.

1.14.4 Installing a Lower Interface Board Assembly

1. Locate the new LIB assembly using the screw holes at each corner as guides.
The LIB printed circuit board (PCB) pushes onto (blind-mates) its connectors.
2. Screw the LIB into place.

On the Sun Fire V210 server, the LIB is held in place with screws. On the Sun Fire V240 server, the LIB is held in place with a mixture of screws, standoffs, and shouldered

standoffs (FIGURE 1-23).




FIGURE 1-23 Lower Interface Board Standoff and Screw Locations

3. Attach the bezel PCB, PSU, and system board cables.
4. Install the cover assembly.

1.15 PCI Cards

The PCI slot on the Sun Fire V210 server operates at 3.3 Vdc and supports one 64-bit PCI card running at 33 MHz or 66 MHz.

The PCI card riser assembly in the Sun Fire V240 server allows you to stack three PCI cards. The PCI slots on the Sun Fire V240 server:

- Support three 64-bit PCI cards running at 33 MHz or 66 MHz
- Are 3.3 Vdc (PCI 0) and 5 Vdc (PCI 1-2)
- Can support a maximum of 25W per card, but no more than 45W spread over all three slots

Note – The PCI cards are *not* hot-swappable on either server.

Note – Add PCI cards to the Sun Fire V240 server, in the order PCI 0–2. This corresponds to populating the PCI slots from bottom to top.

Note – A 66 MHz PCI card performs at 33 MHz when it is inserted into the PCI-1 or PCI-2 slots.

For information on the PCI cards that are available for the server, see the *Sun Fire V210 and V240 Servers System Administration Guide* (819-4208).

1.15.1 Adding a PCI Card

1. Power off the server.

See [Section 1.2, “Controlling Server Power”](#) on page 1-3.

2. Ensure that the server is properly grounded.

See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.

3. Open the back section of the server.

See [Section 1.4, “Opening the Server”](#) on page 1-7.

4. Unscrew the PCI lockdown screw on the back of the server.




FIGURE 1-24 Location of PCI Lockdown Screw

5. Remove the PCI lockdown bracket on the inside of the server.

6. Slide the PCI card support clear of the PCI card.

Pull up on the riser card support handle to slide it to another position.

7. Disconnect and remove the PCI card.




FIGURE 1-25 Removing a PCI Card on a Sun Fire V240 Server

1.15.1.1 Replacing a PCI card

1. Locate the PCI card in the appropriate slot and press it firmly into the connector.
2. Locate the PCI card support so that it supports the back of the card.
3. Attach the PCI lockdown bracket and tighten the PCI lockdown screw.

1.16 PCI Riser Card

1.16.1 Removing the PCI Riser Card Assembly (Sun Fire V240 Only)

1. **Power off the server.**
See [Section 1.4, “Opening the Server”](#) on page 1-7.
2. **Ensure that the server is properly grounded.**
See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.
3. **Open the back section of the server.**
See [Section 1.4, “Opening the Server”](#) on page 1-7.
4. **Unscrew the two captive screws which secure the PCI riser card to the system board** ([FIGURE 1-26](#)).




FIGURE 1-26 Location of PCI Riser Card Screws

5. **Pull riser card assembly vertically to detach it from the system board** ([FIGURE 1-27](#)).




FIGURE 1-27 Removing the PCI Riser Card Assembly

1.16.2 Installing the PCI Riser Card Assembly



Caution – The PCI riser card must be correctly seated to prevent thermal problems.

1. Locate the replacement riser card and press it into the slot firmly.
2. Screw it in place.

1.17 Sun Cryptographic Accelerator

The hardware cryptographic accelerator clips onto the server's system board. For more information, see the *Sun Crypto Accelerator 1000 Installation and User's Guide* (819-0425).

1.17.1 Removing the Sun Cryptographic Accelerator

1. Locate the clip that secures the cryptographic accelerator onto the system board.
2. Squeeze the clip to compress it.
3. Lift the cryptographic accelerator away from the chassis (FIGURE 1-28).




FIGURE 1-28 Removing the Cryptographic Accelerator

1.17.2 Installing the Sun Cryptographic Accelerator

1. Press the standoff into the motherboard.
2. Place the cryptographic accelerator onto the standoff and connector on the motherboard.
3. Press the accelerator into place.

For information on configuring and using the hardware cryptographic module, see the *Sun Crypto Accelerator 1000 Installation and User's Guide* (819-0425).

1.18 Battery

The battery powers the server's internal real time clock (RTC).

Tip – When replacing the battery, only use an identical replacement part.

1.18.1 Replacing the RTC Battery

- 1. Power off the server.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3.
- 2. Ensure that the server is properly grounded.**
See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.
- 3. Open the back section of the cover.**
See [Section 1.4, “Opening the Server”](#) on page 1-7.
- 4. Unclip the battery from its housing on the system board.**
Push the retaining clip to one side to release the battery.
- 5. Locate the new battery in the housing and press down to secure it in place.**

1.19 Keyswitch Assembly

The keyswitch is a feature of the Sun Fire V240 server.

1.19.1 Removing the Keyswitch Assembly

- 1. Power off the server.**
See [Section 1.2, “Controlling Server Power”](#) on page 1-3.
- 2. Ensure that the server is properly grounded.**
See [Section 1.3, “Avoiding Electrostatic Discharge”](#) on page 1-5.

3. Remove the front section of the cover assembly.
See [Section 1.4, "Opening the Server" on page 1-7](#).
4. Disconnect the wiring harness from the back of the keyswitch assembly ([FIGURE 1-29](#)).
Twist the plastic cradle to disconnect it.




FIGURE 1-29 Disconnecting the Keyswitch Wiring Harness

5. Remove the locknut on the back of the keyswitch assembly ([FIGURE 1-30](#)).




FIGURE 1-30 Removing the Keyswitch Locknut

6. Remove the keyswitch assembly through the server's front panel ([FIGURE 1-31](#)).




FIGURE 1-31 Removing the Keyswitch Assembly

1.19.2 Replacing the Keyswitch Assembly

1. Position the new keyswitch assembly through the server's front panel.
2. Tighten the locknut onto the back of the keyswitch.
3. Reconnect the wiring harness.

Index

A

air duct, 1-10

B

battery, 1-43

bezel assembly, 1-15

C

cooling fans, 1-28

Cover, 1-11

cover, 1-7

cover assembly, removing, 1-7

CPU and system board assembly, 1-29

cryptographic accelerator, 1-42

cryptographic accelerator, 1-42

D

disk drive, caution, 1-3

E

electrostatic discharge (ESD) precautions, 1-5

F

fan, 1-28

fans, 1-28

G

grounding stud, 1-5

H

hard drive, 1-15, 1-16

hard drive, caution, 1-3

I

installation

new system board, 1-33

installing, 1-15, 1-16, 1-19, 1-20, 1-23, 1-25, 1-26, 1-35, 1-36, 1-41, 1-42

interface board assemblies, 1-33

K

keyswitch assembly, 1-43, 1-46

L

LIB assembly, 1-35, 1-36

location of components, V210, 1-12

location of components, V240, 1-14

M

memory, 1-26, 1-27

memory configuration rules, 1-26

moving the system, precautions, 1-3

O

Opening the Server, 1-7

P

PCI cards, 1-37

PCI lockdown screw, 1-38

PCI riser card, 1-41

PCI riser card assembly, 1-40

PCI riser card assembly V240, 1-40

PDB, 1-25

power

- controlling server power, 1-3

- the On/Standby switch, 1-3

power distribution board, 1-24

printed circuit board, caution, 1-3

PSU V210, 1-20

PSU V210 server, 1-20

PSU V240, 1-23

PSU V240 server, 1-21

R

removing, 1-11, 1-15, 1-16, 1-17, 1-20, 1-21, 1-24, 1-27,
1-28, 1-30, 1-33, 1-35, 1-40, 1-42, 1-43

replacing, 1-43, 1-46

S

system board, 1-30

system configuration card reader, 1-17, 1-19

system control switch

- Diagnostics position, 1-4

- Locked position, 1-4

- Normal position, 1-4

U

U-channel, 1-12

UIB assembly V240, 1-33, 1-35

W

whole cover assembly, 1-11