

Sun Fire™ Entry-Level Midrange Systems Firmware 5.18.0 Release Notes

Sun Microsystems, Inc. www.sun.com

Part No. 817-7810-10 October 2004, Revision A Copyright 2004 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Sun Microsystems, Inc. has intellectual property rights relating to technology embodied in the product that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed at http://www.sun.com/patents and one or more additional patents or pending patent applications in the U.S. and in other countries.

This document and the product to which it pertains are distributed under licenses restricting their use, copying, distribution, and decompilation. No part of the product or of this document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any.

Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, docs.sun.com, Java, OpenBoot, Sun Fire, SunStorEdge, and Solaris, are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and SunTM Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

U.S. Government Rights—Commercial use. Government users are subject to the Sun Microsystems, Inc. standard license agreement and applicable provisions of the FAR and its supplements.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2004 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Sun Microsystems, Inc. a les droits de propriété intellectuels relatants à la technologie incorporée dans le produit qui est décrit dans ce document. En particulier, et sans la limitation, ces droits de propriété intellectuels peuvent inclure un ou plus des brevets américains énumérés à http://www.sun.com/patents et un ou les brevets plus supplémentaires ou les applications de brevet en attente dans les Etats-Unis et dans les autres pays.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y ena.

Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, docs.sun.com, Java, OpenBoot, Sun Fire, SunStorEdge, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits protant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et SunTM a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une license non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciées de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.





Contents

reatures introduced in the 5.18.0 Kelease 1			
Secure Shell (SSH) Protocol 1			
SSH-Related Issues 2			
Capacity on Demand 3			
Commands Modified for 5.18.0 3			
DHCP Network Boot Changes 4			
Documentation for Sun Fire Entry-Level Midrange (E2900/V1280/Netra 1280) Systems 6			
General Information 6			
Requirements for Entry-Level Midrange Systems 6			
Firmware Upgrade and Downgrade 7			
Known Limitations for Sun Fire Entry-Level Midrange Systems 7			
Upgrade of Firmware Changes Connection Type (BugID 5060748) 7			
Enabling SNTP on Serengeti SC Disrupts Domain Clock (BugID 4966931) 7			
FRU ID Data Not Updated in Sun Management Center Table (BugID 4834060) 8			
prtdiag and Solaris LOM Report Incorrect or Missing Entries (BugID 4851173) 8			
Firmware Reports RP*/SB*/IB* Boards Unknown or Failed After Use of poweroff Command (BugID 5089726) 9			
prtfru Command Returns IO Error (BugID 5000932) 9			

- Board State Becomes Incorrect After setkeyswitch or testboard Operations (BugID 5066326) 10
- sgcn_output_line(): OBP console blocked; message data lost
 (BugID 4939206) 10
- disablecomponent Fails to Blacklist an I/O Card (BugID 5074564) 10
- Wanboot "panic boot: create_ramdisk: fatal error" on Sun Fire midrange server platforms (BugID 5076076) 11
- ERROR: DomainBufferReader thread error java.lang. NullPointerException(BugID 5088923) 11
- Power Failure May Corrupt SEEPROM Contents (BugID 5093450) 11

Sun Fire Entry-Level Midrange Systems Firmware 5.18.0 Release Notes

This document provides information on new and revised features, as well as late-breaking news, for firmware release 5.18.0 on Sun Fire E2900 Sun Fire V1280, and Netra 1280 systems.

This document contains the following topics:

- Features Introduced in the 5.18.0 Release
- General Information
- Known Limitations for Sun Fire Entry-Level Midrange Systems

Features Introduced in the 5.18.0 Release

This section provides a brief description of the new features in 5.18.0 for Sun Fire entry-level midrange systems.

Secure Shell (SSH) Protocol

The Secure Shell protocol, which provides secure remote access to the system controller, is now available as an alternative to the Telnet protocol on Sun Fire entry-level midrange systems. SSH uses encryption to protect data flowing between the host and client, and also authentication mechanisms to identify both hosts and clients.

The system controller (SC) provides SSHv2 server capability. For further information on SSH and how to configure secure connections, refer to Chapter 8, "Security Guidelines," in the Sun Fire Entry-Level Midrange System Administration Manual.

SSH-Related Issues

■ SSH connections are not supported on Sun Fire V1280 servers equipped with version 1 system controllers (SC V1), or on Netra 1280 servers. SSH is supported only on systems equipped with version 2 system controllers (SC V2). On systems containing the SC V1, the setupnetwork command does not allow you to specify an ssh connection type, allowing you to set the connection type only to none or telnet. (BugID 5091556).

The following SSH support commands are not available on an entry-level midrange system equipped with an SC V1:

- ssh-keygen
- restartssh
- The SSH server creates and uses RSA host keys by default.

If you choose to use the default without creating DSA host keys, you will see the following message when the SSH server is enabled:

```
[0xXXXXXX] Could not load host key: /DsaKey
```

You can ignore this message.

- The SSH server on Sun Fire midrange systems does not support the following features:
 - Remote command-line execution
 - scp command (secure copy program)
 - sftp command (secure file transfer program)
 - Port forwarding
 - Key-based user authentication
 - SSHv1 clients

If you try to use any of the above features, an error message is generated. For example, running the command

ssh SCHOST showboards

generates the following messages:

On the SSH client:

Connection to SCHOST closed by remote host.

■ On the SC console:

```
[0x89d1e0] sshdSessionServerCreate: no server registered for showboards
[0x89d1e0] sshd: Failed to create sshdSession
```

Capacity on Demand

The Capacity on Demand (COD) option provides additional processing resources that you pay for when you use them. Through the COD option, you receive and install unlicensed CPU/Memory boards. These boards, which are identified as COD CPU/Memory boards, contain four CPUs. However, you do not have the right to use the CPUs on COD CPU/Memory boards until you also purchase the COD right-to-use (RTU) licenses for them. The purchase of a COD RTU license entitles you to receive a license key, which enables the appropriate number of COD processors.

Your Sun Fire entry-level midrange system can have any combination of active CPU/Memory boards and COD CPU/Memory boards, up to the maximum capacity allowed for the system. You must have at least one active CPU in your system.

For details on getting started with COD, review the Capacity on Demand chapter in the *Sun Fire Entry-Level Midrange System Administration Manual* (part number 817-7812-10). Contact your Sun sales representative or authorized Sun reseller to purchase COD CPU/Memory boards and the appropriate number of COD RTU licenses. After the COD CPU/Memory boards are installed, refer to the Capacity on Demand chapter and also the *Sun Fire Entry-Level Midrange System Controller Command Reference Manual* (part number 817-7811-10) for information on using certain system controller commands to allocate COD RTU licenses, activate COD CPUs, and monitor the COD CPUs used.

Commands Modified for 5.18.0

The following SC commands were changed in 5.18.0

SSH commands added:

ssh-keygen - Generates SSH host keys and displays host key fingerprint on SC.

restartssh - Restarts SSH server to put new host keys (created using sshkeygen) into effect.

COD commands added:

- addcodlicense Adds a Capacity on Demand (COD) right-to-use (RTU) license key to the COD license database.
- deletecodlicense Removes a COD RTU license key from the COD license database.
- showcodlicense Displays the current COD RTU licenses stored in the COD license database.
- showcodusage Displays the current usage statistics for COD resources.

The following command descriptions were modified in the entry-level command reference manual:

- setupnetwork New SSH value for network enabled parameter
- shownetwork New SSH value for network enabled parameter
- help Supports new commands and updated messages for platform commands
- setescape Adapted to set SSH escape characters
- showescape Adapted to display SSH escape characters
- setupsc Adapted to set up COD parameter:
 - Quantity of instant access CPUs (headroom) to be activated.
 - Quantity of COD RTU licenses to be reserved.
- showsc Displays the parameter values set through the setupsc command, including the following new or modified parameters:
 - Instant Access CPUs (headroom) activated
 - COD RTU licenses reserved for domain
- For details on these commands, refer to their descriptions in the *Sun Fire Entry- Level Midrange System Controller Command Reference Manual*.

DHCP Network Boot Changes

5.18.0 firmware modifies the behavior of the Open Boot PROM when booting off of the network using the DHCP protocol.

During the network boot process, clients use TFTP to download an initial boot binary file (such as inetboot) from a TFTP boot server specified by the DHCP server. If the DHCP server does not tell the client the name of the file to be downloaded, the Open Boot PROM uses a default file name for the TFTP request. In previous firmware releases the default boot file name was the client's IP address expressed as

a string of eight hexadecimal characters (for example, a client whose IP address was 192.168.100.1 would request a file named C0A86401). While this behavior is correct for non-DHCP network boots, it is incorrect for network booting with DHCP.

Starting in this release, the default boot file name used by the Open Boot PROM is constructed from the client's platform type. Unless the DHCP server specifies a different boot file name, midrange platforms request a file named SUNW.Sun-Fire while entry-level midrange platforms request a file named SUNW.Netra-T12. This behavior is consistent with the net boot server setup tools distributed with Solaris software.

With this change, you might (depending upon your network boot configurations) see net boot errors after installing the new firmware. Specifically, if the requested boot file does not exist on the TFTP boot server, the Open Boot PROM issues the following message and fails to boot the OS:

```
ERROR: get_tftp_file: TFTP error 2: Access violation
```

Workarounds: This situation can be corrected in several ways, including (but not limited to):

- Rename the boot file on the TFTP boot server (such as from C0A86401 to SUNW.Sun-Fire)
- Create a symbolic link on the TFTP boot server which points to the actual file (for example, # ln -s COA86401 SUNW.Netra-T12)
- Modify the DHCP macros on the DHCP server to provide an explicit boot file name for clients.

The DHCP network boot process supports configurations in which the DHCP server and the TFTP boot server are different machines. If the DHCP server and other network components are configured correctly, the DHCP and TFTP servers can exist on different IP subnets. However, the Open Boot PROM firmware in previous releases assumes that the DHCP server and the TFTP server are the same machine even if the DHCP server indicates otherwise.

Starting with this release, the Open Boot PROM handles configurations correctly in which the DHCP and TFTP servers are not the same machine, including when they are on different subnets. For cross-subnet TFTP configurations, note that the DHCP server must be configured to provide proper Router and Subnet values to the client.

With this change, if your DHCP servers are improperly configured (providing incorrect Router or Subnet values to clients), you might see net boot errors after installing the new firmware. OpenBoot PROM firmware on the client might issue one or both of the following messages in that situation:

```
ERROR: get_arp_info: Timeout waiting for ARP packet
ERROR: tftp_get_reply: Timeout waiting for TFTP packet
```

Workaround: To eliminate these error messages, verify that the Router and Subnet values sent to the client by the DHCP server are correct.

Documentation for Sun Fire Entry-Level Midrange (E2900/V1280/Netra 1280) Systems

- Sun Fire Entry-Level Midrange System Administration Guide (part number 817-7812-10)
- Sun Fire Entry-Level Midrange System Controller Command Reference Manual (part number 817-7811-10)
- Sun Fire Entry-Level Midrange System Firmware 5.18.0 Release Notes (part number 817-7810-10)

General Information

Requirements for Entry-Level Midrange Systems

The Sun Fire E2900 systems require 5.17.0 firmware or greater and the Solaris 8 2/04 or Solaris 9 4/04 operating environments as the minimum Solaris releases.

TABLE 1 Minimum Firmware and Software Versions Supported on Entry-Level Midrange Systems

Sun Fire E2900 Systems	Sun Fire V1280/Netra 1280 Systems	Solaris 8 OS	Solaris 9 OS
5.17.0 firmware	5.17.0 firmware	Solaris 8 2/04	Solaris 9 4/04
	5.13.001x firmware	Solaris 8 2/02	Solaris 9 4/03

Note – The Sun Fire E2900 systems and systems that contain UltraSPARC IV boards, must run firmware version 5.17.0 or greater. Earlier firmware versions do not support the UltraSPARC IV CPU/Memory boards. Entry-Level midrange systems with SC V2s (but without UltraSPARC IV CPU/Memory boards) can be downgraded from 5.17.0 to 5.13.001x firmware releases, but note that those earlier releases will not support features introduced in 5.17.0 or 5.18.0.

Firmware Upgrade and Downgrade

Instructions for updating firmware (upgrade and downgrade) are provided in the Sun Fire Entry-Level Midrange System Administration Guide.

Sun Fire E2900 systems and Sun Fire V1280 systems that contain UltraSPARC IV CPU/Memory boards must run firmware version 5.17.0 or greater. Earlier firmware versions do not support the UltraSPARC IV CPU/Memory boards.

Entry-level midrange systems with SC V2s can be downgraded from 5.18.0 to earlier firmware releases, but note that those earlier releases will not support bug fixes made in 5.18.0.

Known Limitations for Sun Fire Entry-Level Midrange Systems

This section describes only those bugs with potentially significant impact. The README file lists all bugs, including those seen only internally at Sun.

Upgrade of Firmware Changes Connection Type (BugID 5060748)

If you change the connection type after updating firmware on entry-level midrange systems from 5.17.x or 5.18.x to 5.13.x, then the new connection type (selected in 5.13.x) is not guaranteed once you update firmware back to 5.17.x or 5.18.x. If you subsequently update the firmware to 5.17.x or 5.18.x from 5.13.x, the original connection type that you had in 5.17.x or 5.18.x before the change to 5.13.x will be restored.

Workaround: Set the connection type explicitly (using the setupnetwork command) to ensure system security.

Enabling SNTP on Serengeti SC Disrupts Domain Clock (BugID 4966931)

In the following situation:

- System controller runs 5.18.0 firmware
- System has an SNTP server configured

If you update the SC firmware to a version earlier than 5.18.0, leaving RTOS 40 installed, it is possible to change the scapp NTP server configuration—resulting in RTOS 40 listening to one NTP server and scapp listening to different one.

Workaround: When downgrading scapp, unconfigure the NTP server, and reconfigure it after downgrading. This disables NTP operations until you explicitly re-enable them.

FRU ID Data Not Updated in Sun Management Center Table (BugID 4834060)

If components in an entry-level midrange server are missing or disabled, the FRU ID Info table in Sun Management Center software cannot display the hardware FRU (Field-Replaceable Unit), except for the SSC and BP entries. The remaining entries in the table contain this message: "Reading ..."

The System table's Module Status entry reports FRU ID errors, displaying a critical alarm indicator. The alarm message states: "Data acquisition error" while the software attempts to obtain the Module Status.

Workaround: Use /usr/sbin/prtfru to print out the FRU tree hierarchy and data in a terminal shell.

prtdiag and Solaris LOM Report Incorrect or Missing Entries (BugID 4851173)

If you add a new system board when the system is in Standby mode (that is, having used the lom> poweroff command), once the system has booted to the OS (lom> poweron) prtdiag command output shows incorrect or missing entries for the new board. This problem does not occur when the system has been fully powered off before adding the new board or when the new board has been dynamically reconfigured in a live system.

This problem has been observed only when using 5.13.x firmware on entry-level midrange systems.

Workaround:

In order to get the prtdiag and lom commands to report correctly, reset the system controller after completing the DR operation.

- 1. Reconfigure the new board dynamically:
 - a. # cfgadm -c disconnect N0.SBx
 - b. # cfgadm -c configure N0.SBx
- 2. Reset the SC:
 - a. lom> resetsc

Firmware Reports RP*/SB*/IB* Boards Unknown or Failed After Use of poweroff Command (BugID 5089726)

In rare circumstances, the showboards command displays system boards (SB0, SB2., and so forth) as being in the state, PWR: Unk (power status unknown) and Status: failed (suggesting that the boards have all failed diagnostics). This condition is likely to be a reporting error, and does not necessarily mean that there is anything wrong with the boards.

This situation might be more likely to occur after use of the poweroff command.

Workaround: Use the resetsc command to reset the system controller. The showboards command should then show the system boards in the correct state. This reset does not affect the domain state. However, if resetting the SC does not correct the problem, you can power down the entire system and bring it up again (which resets the domain as well).

prtfru Command Returns IO Error (BugID 5000932)

Use of the prtfru command sometimes results in IO error messages being returned instead of data for many of the Field Replaceable Units (FRUs) in the system. If the Solaris OS waits for the completion of an operation on the System Controller, such as a board test or diagnostic command, uncached FRU information might not be available until that operation completes. The Solaris OS can time out after a few seconds or minutes, resulting in the observed IO error messages. This problem might correct itself when the operation blocking the prtfru command completes. However, depending on the operation, this might take several hours.

Workaround:

If the prtfru command produces IO errors on an entry-level midrange system, reissue the command after waiting for an hour. If the prtfru command continues to fail, it should be considered a permanent condition which cannot be corrected without rebooting the server. Information about the health of the components in the system might be available in other ways, such as by use of the showboards command.

Board State Becomes Incorrect After setkeyswitch or testboard Operations (BugID 5066326)

After a domain panic occurs or when a domain encounters errors, output from a subsequent setkeyswitch or testboard operation will show that the board processors have an Unknown status.

Workaround: Reboot the system controller.

sgcn_output_line(): OBP console blocked; message data lost (BugID 4939206)

A message indicating that there are dropped console messages is displayed when data is being provided by Solaris software or by the OpenBoot PROM faster than the system controller can write it to the console.

Workaround: None

disablecomponent Fails to Blacklist an I/O Card (BugID 5074564)

If you run the disablecomponent or setls command to blacklist an I/O card, the card is not disabled at the OpenBOOT Prom (OBP) level.

Workaround: Perform a setkeyswitch off and then a setkeyswitch on operation after disabling the I/O card.

Wanboot "panic - boot: create_ramdisk: fatal error" on Sun Fire midrange server platforms (BugID 5076076)

If you are using a wanboot server to boot a Sun Fire midrange system (E6900, E4900, E2900, 6800, 4810, 4800, 3800, and V1280), the wanboot server cannot create the ramdisk and is unable to boo the Sun Fire midrange system.

Workaround: None.

ERROR: DomainBufferReader thread error java.lang. NullPointerException (BugID 5088923)

In certain situations, this error message can occur when running reset or shutdown commands from the domain console shell. The error does not affect the availability of the domain. However, the reset or shutdown commands may take an additional 60 seconds to complete.

Workaround: None.

Power Failure May Corrupt SEEPROM Contents (BugID 5093450)

If a power failure and ScApp reboot occurs during an add segment operation, one or more SEEPROM segments may become corrupted upon a reboot. However, even though these error messages display, the availability of the domains is not affected.

Workaround: None.