



# Sun Fire™ E2900/V1280 PCI+ I/O Assembly Installation Guide

---

## Firmware and OS Requirements

---

**Note** – If your system requires a software and firmware upgrade, upgrade the firmware first then upgrade the software. Install new PCI+ I/O assembly only after you have upgraded the firmware and software.

---

---

**Note** – 33MHz PCI adapters with 5V signaling are not supported in the PCI+ assembly (only 3.3V signaling is supported).

---

Sun Fire E2900/V1280 systems with a PCI+ I/O assembly require the following firmware and software versions:

- SCAPP firmware version 5.19.3 or subsequent compatible versions

Sun Fire E2900/V1280 systems with UltraSPARC® IV+ require the following operating systems:

- Releases beginning with Solaris 9 9/05, Solaris 10 3/05 HW1 Operating Systems

Sun Fire E2900/V1280 systems with only UltraSPARC III and/or UltraSPARC IV require the following operating systems:

- Solaris 8 2/04 plus latest KU plus patch, Solaris 9 9/05, Solaris 10 3/05 HW1 Operating Systems

Refer to the SunSolve<sup>SM</sup> patch portal at [sun.com](http://sun.com) for the patch and the latest detail.

## Processor Requirements

PCI+ I/O assemblies are supported in domains with the following processors:

- UltraSPARC III
- UltraSPARC IV+

## Location of I/O Assembly

The I/O assembly (IB6) for these systems is a part of the IB\_SSC assembly, see FIGURE 1.




FIGURE 1 Location of IB\_SSC Assembly

## Removing and Replacing I/O Assembly

The I/O assembly for these systems (IB6) is part of the IB\_SSC assembly. To replace IB6, the IB\_SSC assembly must be replaced. Refer to the service manual for your system for the removal and replacement of the IB\_SSC assembly as well as the removal and replacement of any PCI cards you want to retain from the old assembly. Once you have replaced the assembly and re-installed the I/O cards, restart your system.



**Caution** – Ensure that you remove the plastic covering protecting the connectors on the replacement IB\_SSC assembly before installing or damage to the backplane can occur.

**Note** – Mixing different cards with different speeds within an IB6 leaf (two paired slots) is not recommended since leaf slots run at the lowest speed and the lowest mode for a given set of cards within a leaf. For example, if a 33Mhz PCI card is in slot 0 and a 66Mhz PCI card is in slot 1, then both slots on the leaf will run in the lower 33Mhz PCI mode. IB6 leaves are comprised of paired slots 0 and 1, 2 and 3, and 4 and 5. In addition, all slots will ONLY run in PCI+ mode. Thus, a higher speed card that is plugged in will run at either 33 or 66Mhz (dependent upon the speed of the card in the leaf pair slot).

---

**Note** – This page intentionally left blank.

---

## Accessing Sun Documentation

You can view, print, or purchase a broad selection of Sun documentation, including localized versions, at:

<http://www.sun.com/documentation>

## Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

## Contacting Sun Technical Support

If you have technical questions about this product that are not answered in this document, go to:

<http://www.sun.com/service/contacting>

## Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

*Sun Fire E2900/V1280 PCI+ I/O Assembly Installation Guide*, part number 819-4212-10

Copyright 2005 Sun Microsystems, Inc. All rights reserved. Use is subject to license terms. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers. Portions may be derived from Berkeley BSD systems, licensed from U. of CA. Sun, Sun Microsystems, the Sun logo, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and in other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and in other countries. U.S. Government Rights—Commercial use. Government users are subject to the Sun Microsystems, Inc. standard license agreement and applicable provisions of the FAR and its supplements.

Copyright 2005 Sun Microsystems, Inc. Tous droits réservés. Distribué par des licences qui en restreignent l'utilisation. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun. Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. Sun, Sun Microsystems, le logo Sun, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays.



Sun Microsystems, Inc.  
[www.sun.com](http://www.sun.com)