

# Sun StorEdge™ Fast Write Cache 2.0 Installation Guide

---



THE NETWORK IS THE COMPUTER™

**Sun Microsystems, Inc.**  
901 San Antonio Road  
Palo Alto, CA 94303-4900 USA  
650 960-1300 Fax 650 969-9131

Part No. 806-4405-10  
February 2000, Revision A

Send comments about this document to: [docfeedback@sun.com](mailto:docfeedback@sun.com)

Copyright 2000 Sun Microsystems, Inc., 901 San Antonio Road • Palo Alto, CA 94303-4900 USA. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd. For Netscape Communicator™, the following notice applies: Copyright 1995 Netscape Communications Corporation. All rights reserved.

Sun, Sun Microsystems, the Sun logo, AnswerBook2, docs.sun.com, Sun StorEdge, Instant Image, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

**RESTRICTED RIGHTS:** Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2000 Sun Microsystems, Inc., 901 San Antonio Road • Palo Alto, CA 94303-4900 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd. La notice suivante est applicable à Netscape Communicator™ : Copyright 1995 Netscape Communications Corporation. All rights reserved.

Sun, Sun Microsystems, the Sun logo, AnswerBook2, docs.sun.com, Sun StorEdge, Instant Image, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REpondre A UNE UTILISATION PARTICULIERE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUERAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



# Contents

---

Introduction	1
Document Structure	2
Related Documentation	3
Reading Fast Write Cache man Pages	4
Qualified Platforms	4
Limitations	5
Product Considerations	5
Installation Requirements	7
Configuration Files	8
Installing the Fast Write Cache Software	8
▼ Mount the CD-ROM	9
▼ Install the Fast Write Cache Software	10
Adding Fast Write Cache Volumes to the Storage Volume Driver Configuration File	12
▼ To Add Fast Write Cache Volumes	12
Starting the Sun StorEdge Management Console	13
Reinstalling Fast Write Cache Software	15
▼ To Reinstall the Fast Write Cache Management Services SUNWmscmu and SUNWmscmr	15



# Sun StorEdge Fast Write Cache 2.0 Installation Guide

---

---

## Introduction

The Sun StorEdge™ Fast Write Cache 2.0 Installation Guide describes installation procedures and product considerations for the Sun StorEdge Fast Write Cache software. The Fast Write Cache software is an application host-based write accelerator of disk I/O. It improves performance for transaction processing and delivers faster response times to user requests for data by reducing the frequency of disk I/O accesses. Writes are cached in non-volatile memory and then the cached data is destaged to disk at a later time. Fast Write Cache is installed on Solaris™ servers and consists of NVRAM (non-volatile memory) boards used as cache memory and storage cache management software.

Sun StorEdge Fast Write Cache is implemented as a UNIX device driver, using nonvolatile memory to cache write requests. As the cache fills, older data is written asynchronously to the real disk. Fast Write Cache works as a layer between other disk drivers and the rest of the UNIX kernel. Stubs replace the original driver's entry points in the device switch tables. Whenever Fast Write Cache performs actual I/O (for example, when its cache must be destaged), it uses the real device driver routines.

---

**Note** – Fast Write Cache is implemented using a pair of SBus or PCI NVRAM cards installed on your system.

---

---

# Document Structure

This document contains the following information:

- Introduction
- Related Documentation
- New Feature
- Reading Fast Write Cache man Pages
- Installation Requirements
- Qualified Platforms
- Limitations
- Product Considerations
- Installing the Fast Write Cache Software
- Installing the Fast Write Cache Software
- Adding Fast Write Cache Volumes to the Storage Volume Driver Configuration File
- Starting the Sun StorEdge Management Console
- Reinstalling Fast Write Cache Software

# Related Documentation

**TABLE P-1** Related Documentation

<b>Application</b>	<b>Title</b>	<b>Part Number</b>
man Pages	fwcadm(1FWC) cache_control cache_config cache_health svadm(1SV)	N/A
User	<i>Sun StorEdge Fast Write Cache 2.0 System Administrator's Guide</i>	806-2064
User	<i>Sun StorEdge Fast Write Cache 2.0 Release Notes</i>	806-3165
Configuration	<i>Sun StorEdge Fast Write Cache 2.0 Configuration Guide</i>	806-4383
Installation	<i>Solaris 2.6 Handbook for SMCC Peripherals</i>	802-7295
Installation	<i>Solaris Handbook for SMCC Peripherals</i>	805-7404
Installation	<i>Solaris 2.x Handbook for SMCC Peripherals</i>	801-5488
Options	<i>OpenBoot 3.x Command Reference Manual</i>	802-3242
Diagnostics (Solaris 2.6)	<i>SunVTS 2.1 User's Guide</i>	802-7299
Diagnostics (Solaris 2.6)	<i>SunVTS 2.1.3 Test Reference Manual</i>	805-4163
Diagnostics (Solaris 2.6)	<i>SunVTS 2.1 Quick Reference</i>	802-7301
Diagnostics (Solaris 7)	<i>SunVTS 3.0 User's Guide</i>	805-4442
Diagnostics (Solaris 7)	<i>SunVTS 3.0 Test Reference Manual</i>	805-4443
Diagnostics (Solaris 7)	<i>SunVTS 3.0 Programmer's Guide</i>	805-7338
Diagnostics (Solaris 7)	<i>SunVTS 3.0 Quick Reference</i>	805-4444
Diagnostics (Solaris 7)	<i>SunVTS 3.1 User's Guide</i>	805-7406
Diagnostics (Solaris 7)	<i>SunVTS 3.1 Test Reference Manual</i>	805-7407
Diagnostics (Solaris 7)	<i>SunVTS 3.1 Quick Reference</i>	805-7408
User	<i>Dynamic Reconfiguration User's Guide For Sun Enterprise 3x00/4x00/5x00/6x00 Systems</i>	805-3530
User	<i>Sun Enterprise 6x00, 5x00, 4x00, and 3x00 Systems Dynamic Reconfiguration Guide</i>	806-0280
User	<i>Sun Enterprise 10000 Dynamic Reconfiguration User's Guide</i>	805-7985

---

# Reading Fast Write Cache man Pages

- **Set the MANPATH environment variable to include /usr/opt/SUNWesm/man: for example:**

```
# setenv MANPATH $MANPATH:/usr/opt/SUNWesm/man
```

After the `setenv` command has been executed, you do not have to type the path to the man pages.

- **To read the legacy CLI `fwcadm(1M)` man page, type:**

```
# man -M fwcadm /usr/opt/SUNWesm/SUNWfwc/man fwcadm
```

- **To read any of the Fast Write Cache management service man pages, type:**

```
# man -M /usr/opt/SUNWesm/SUNWfwcmsu/man manpagename
```

where *manpagename* is `fwcadm`, `cache_control(1M)`, `cache_config (1M)`, or `cache_health (1M)`.

---

## Qualified Platforms

The following platforms are qualified for Fast Write Cache:

- Sun Enterprise™ 250
- Sun Enterprise 450
- Sun Enterprise 3000
- Sun Enterprise 3500
- Sun Enterprise 4000
- Sun Enterprise 4500
- Sun Enterprise 5000
- Sun Enterprise 5500
- Sun Enterprise 6000
- Sun Enterprise 6500
- Sun Enterprise 10000

---

## Limitations

Fast Write Cache 2.0 does not support the following:

- Single NVRAM cards
- Multiple NVRAM card pairs
- Clusters

---

## Product Considerations

- Do not cache underlying volume manager devices (for example, VxVM log devices), as this can result in unpredictable behavior.
- The volume manager must always be below the Fast Write Cache:
  - To allow coalescing stripe width size writes for RAID 5
  - The volume manager partitioning of disks does not necessarily map to the Solaris partitions
- Fast Write Cache can cache Volume Manager volumes. The example for configuring the `/etc/opt/SUNWspv/sv.cf` file that is shown in the Sun *StorEdge Fast Write Cache 2.0 System Administrator's Guide* lists linear disks, only. The following example adds a volume manager volume for the Sun Enterprise Volume Manager by including the entry in the `/etc/opt/SUNWspv/sv.cf` file:

```
/dev/vx/rdisk/vol01    cache
```

- Install Fast Write Cache only on systems with clean NVRAM cards. If an unclean shutdown of the system occurred, recover or purge the data before installing Fast Write Cache.
- The file systems must always be above the Fast Write Cache so data and metadata can be destaged to the disk after a crash before `fsck(1M)` is run.
- Do not cache the root (`/`) and `/usr` file systems (or any file systems that come up before Fast Write Cache) because to recover disk data stored in an NVRAM card after a system crash, the data must be restored to disk before file systems are mounted or applications are written to raw volumes.
- Do not cache the swap partition.
- Avoid multiple paths to data. The following are examples of operations that can access data using alternate cached or non-cached paths:
  - `mmap(2)` I/O

- caching overlapping slices
- commands that write to a device using `ioctl(2)`, such as `format(1M)`
- In general, devices must be Storage Volume (SV) disabled using the `fwcadm volume -d` command before doing any operations requiring a device to be quiescent. Some procedures (for example, an A5000 firmware download) will not complete successfully unless the appropriate devices are SV disabled.
- Limit any changes in the default `/etc/sd.cf` file to the following two parameters:
  - `cache_mem` - The `size_in_megabytes` for the `cache_mem` parameter must be greater than 0 and must be at least equal to the amount of memory (in Mbytes) that is available on one board (PCI NVRAM card 64Mbytes or SBus 32Mbytes).
  - `threads` - This parameter must be at least equal to the number of cached volumes.
- If the NVRAM card contains dirty data, do not reconfigure your disks or move the card to another system until the dirty data is destaged to disk.
- Because `SUNWvtsnp` is not a stand-alone package, the appropriate SunVTS must be installed. `SUNWvtsnp` is an enhanced SunVTS test that verifies the SBus NVRAM card for Fast Write Cache.

Solaris Version	SunVTS version
Solaris 2.6	SUNWvts 2.1.3
Solaris 7	SUNWvts 3.0
Solaris 7	SUNWvts 3.1

The Solaris 2.6 version of the `SUNWvtsnp` package contains a 32-bit `nvtest`.

The Solaris 7 versions of the `SUNWvtsnp` package contains both 32-bit and 64-bit `nvtest` binaries. Package dependency is checked during installation, and the `nvtest` binaries are installed in the appropriate directories. The 64-bit `nvtest` is not installed unless the `SUNWvtsx` (64-bit SunVTS) package is already installed.

- If even one of the batteries on an NVRAM card is low, the cache is destaged and a warning message is sent to the console and the message log.

---

# Installation Requirements

- The minimum requirements for installing Fast Write Cache are:
  - Solaris™ 2.6 or Solaris 7 operating environment or a subsequent compatible version
  - Pair of SBus or PCI NVRAM cards
  - CD-ROM drive connected to the host server where Fast Write Cache is to be installed
  - Approximately 40 Mbytes of disk drive space to install the data services, `java/framework/sundae`, and the Fast Write Cache Management service.
    - `root`—50KBytes
    - `/usr`—40MBytes
    - `/var`—136KBytes
    - `SUNWmscmr` and `SUNWmscmu` —283KBytes
- `SUNWvtsnp` is the enhanced SunVTS that verifies the SBus or PCI NVRAM card for Fast Write Cache. `SUNWvtsnp` is not a stand-alone package. It does not run without the corresponding `SUNWvts` package being installed.
- If you are using the Sun Enterprise Volume Manager™, ensure that you have the appropriate patch for your version.
  - Volume Manager 2.5 – patch 107773-01
  - Volume Manager 2.6 – patch 107735-01
  - Volume Manager 3.0.2 - no required patches
- On Sun Enterprise 10000 server -- Solaris 2.6 patch 105181-15

So that the cache software can allocate host memory for optimum performance, set the OpenBoot PROM variable `dr-max-mem` to 2. As superuser, enter:

```
# eeprom dr-max-mem=2
```

Or, at the OK prompt, enter:

```
ok setenv dr-max-mem 2
```

---

# Configuration Files

Fast Write Cache and its related packages include configuration files with a `.cf` suffix. For example, `sv.cf` is in the `/etc/opt/SUNWspsv` directory.

The Fast Write Cache CD contains sample configuration files that are installed in the `/etc/opt/SUNWpackage` directory; however, the packages do not overwrite existing configuration files in this directory.

---

**Note** – Install Fast Write Cache only on systems with clean NVRAM cards. If an unclean shutdown of the system occurred, recover or purge the data before installing Fast Write Cache.

---

Do the following before installing Fast Write Cache:

- Install the NVRAM cards. See the *Sun StorEdge Fast Write Cache 2.0 System Administrator's Guide* for the NVRAM installation instructions.
- Install the `SUNWvts` diagnostic package. Refer to the appropriate SunVTS documentation.

---

# Installing the Fast Write Cache Software

These procedures describe how to perform a clean install of the Fast Write Cache software. The procedures assume you have not previously installed any versions of Fast Write Cache software.

---

**Note** – Before you enable and use Fast Write Cache software, you must add the Fast Write Cache volumes to the Storage Volume driver configuration file and reconfigure the driver. Add the volumes after you install Fast Write Cache software. See “Adding Fast Write Cache Volumes to the Storage Volume Driver Configuration File” on page 12.

---

## ▼ Mount the CD-ROM

---

**Note** – If your CD-ROM is already mounted, go to “Install the Fast Write Cache Software” on page 10.

---

1. **Become superuser (root).**
2. **Insert the Fast Write Cache CD into the CD-ROM drive connected to your system.**
3. **Make sure that Volume Manager is running:**

```
# ps -e | grep vold
```

If the Volume Manager is running, output similar to the following is displayed:

```
239 ? 0:00 vold
```

4. **If Volume Manager is not running, start it by typing:**

```
# /etc/init.d/volmgt start
```

5. **Confirm that the CD-ROM is mounted by typing:**

```
# /etc/mount |grep cdrom
```

Output similar to the following is displayed:

```
/cdrom/sun_ultra_1_series_hw_ab on /vol/dev/dsk/c0t6d0/  
sun_ultra_1_series_hw_ab read only/setuid on Tue Jan 12 15:05:57  
1999
```

6. **Mount the CD-ROM:**

```
# /etc/mount -F hsfs -o ro /dev/dsk/device /mnt
```

where *device* is the CD-ROM drive device name (for example, `c0t6d0s0`).

## ▼ Install the Fast Write Cache Software

1. Become superuser (root).
2. If the Fast Write Cache CD is not already in the CD-ROM, insert it into the CD-ROM drive connected to your system.
3. Start the Fast Write Cache installation.
  - a. To install the package in the Solaris 2.6 operating environment:

```
# cd /cdrom/cdrom0/Products
# ./install_fwc.ksh
```

`install_fwc` installs the data services, `java/framework/sundae` and the Fast Write Cache Management service.

- b. To install the package in the Solaris 7 operating environment:

```
# cd /cdrom/cdrom0/Solaris_7
# ./install_fwc.ksh
```

- c. To install the package in the Solaris 7 8/99 and subsequent compatible operating environments:

```
# cd /cdrom/cdrom0/Solaris_7-899
# ./install_fwc.ksh
```

4. The license agreement is displayed; type `x`:

```
This product provides a graphical interface to the monitoring and
configuring of Fast Write Cache . It is assumed that you agree to
legal terms explained in
http://www.sun.com/share/text/SMICopyright.html
```

```
DO YOU AGREE TO THE ABOVE TERMS AND WISH TO INSTALL THIS ON TO YOUR
SYSTEM?
```

```
Do you agree to the above license terms? [yes or no] Y
```

**5. Type `y` in response to all prompts.**

If a package to be installed currently exists on your server, make sure you install the most recent version.

When the entire installation finishes, the installation script displays:

```
Installation of Sun StorEdge Fast Write Cache was successful.  
  
The System must now be rebooted to complete product installation  
An un-install script has been generated to aid in the removal of  
this software.  
  
The location of the un-install script is:  
/var/tmp/uninstall_fw
```

**6. Reboot your server using `shutdown` and `reboot` commands.**

```
#shutdown -i6 -g0 -y
```

Before enabling and using the Fast Write Cache software, see “Adding Fast Write Cache Volumes to the Storage Volume Driver Configuration File” on page 12.

---

# Adding Fast Write Cache Volumes to the Storage Volume Driver Configuration File

Before you can enable and use the Fast Write Cache software, you must add the Fast Write Cache volumes to the Storage Volume (SV) driver configuration file and reconfigure the driver.

You cannot enable and use the Fast Write Cache software on volumes that are not in the SV driver configuration file and enabled by the SV driver. The SV driver provides a simple layer of volume management for the Fast Write Cache software.

---

**Tip** – If you want to add devices later, repeat the steps in “To Add Fast Write Cache Volumes” on page 12”.

---

## ▼ To Add Fast Write Cache Volumes

1. **Decide which volumes you are going to use with the Fast Write Cache software.**
2. **Using a text editor, add the volumes to the Storage Volume (SV) driver configuration file** `/etc/opt/SUNWspsv/sv.cf`.

This file includes two fields per line for each volume: the resource name field and access mode field. Separate the fields in the file with spaces.

The resource name field contains the name of a raw device for which the SV driver is to be enabled. *It must be the full path to the raw device node and cannot be the block device node.*

The access mode field can be `cache` or `raw`. This field specifies how this device volume is accessed: through the Storage Cache Management module cache.

Solaris Version	SunVTS version
Solaris 2.6	SUNWvts 2.1.3
Solaris 7	SUNWvts 3.0
Solaris 7	SUNWvts 3.1

## Starting the Sun StorEdge Management Console

If you have rebooted your server after fully installing Fast Write Cache software (see Step 6 of “Installing the Fast Write Cache Software” on page 8), start the Sun StorEdge™ Management Console (Management Console).

- 1. On a local system (where the software is not installed) add the server system to the access control list of the current display.**


```
% xhost <hostname>
```

- 2. Become superuser (root) on the server system.**
- 3. Start the Management Console.**

```
# /usr/opt/SUNWesm/bin/esm_gui &
```

- 4. After the initial splash screen, the Management Console is displayed. See FIGURE 1.**
- 5. Double-click Fast Write Cache.**

The GUI tabs are highlighted. The Fast Write Cache software is ready for use.



Operation buttons

FIGURE 1 Fast Write Cache Management Console

---

# Reinstalling Fast Write Cache Software

This section describes how to reinstall Fast Write Cache software and its related packages.

## ▼ To Reinstall the Fast Write Cache Management Services SUNWmscmu and SUNWmscmr

1. **Become superuser (root).**
2. **Disable any currently enabled volumes.**
  - **Using the Management Console**, click the Control tab (FIGURE 1), then click the `Disable` button.
  - **Using the CLI**, type:

```
# /usr/opt/SUNWesm/bin/esm_cli  
> cd cache  
> control -d
```

3. **Before reinstalling the Fast Write Cache software, be sure to deinstall the old version, using the `/var/tmp/uninstall_fw` script created for you on installation. Then you may reinstall the Fast Write Cache software.**
4. **Reinstall the packages according to the steps in “Installing the Fast Write Cache Software” on page 8. Reply yes to all prompts by typing `y`.**
5. **Reboot your server using `shutdown` and `reboot` commands.**

```
#shutdown -i6 -g0 -y
```

