

# Oracle® Integrated Lights Out Manager (ILOM) 2.0

---

Supplement for the Sun Netra T5220 Server



Copyright © 2008, 2010 Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure the safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

---

Copyright © 2008, 2010, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. UNIX est une marque déposée concédée sous licence par X/Open Company, Ltd.



Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



# Contents

---

## **Preface** ix

### **1. Oracle ILOM for the Sun Netra T5220 Server** 1

SPARC Specific ILOM Features 1

ILOM Features Not Supported in SPARC Servers 1

### **2. Managing the Host** 3

Resetting the Host 3

Managing Remote Control 4

Boot Mode 4

▼ To Manage the Host's Boot Mode Configuration Using the CLI 5

▼ To Manage the Host's Boot Mode Script Using the CLI 5

▼ To Change the Host's Boot Mode Behavior at Reset Using the CLI 6

▼ To Display Host's Boot Mode Expiration Date Using the CLI 6

▼ To Change Remote Control Configuration Settings Using the Web Interface 7

Viewing System Information and Setting System Policy Concerning Error Conditions 8

▼ To Display the Host's MAC Address Using the CLI 8

▼ To Display the Host's OpenBoot Version Using the CLI 8

▼ To Display the Host's POST Version Using the CLI 9

- ▼ To Determine Host Behavior When the Watchdog Timer Expires Using the CLI 9
- ▼ To Specify Whether the Host Halts During Diagnostics When an Error Is Discovered Using the CLI 9
- ▼ To View Host Information Using the Web Interface 10

#### Managing Diagnostics 11

- ▼ To Specify the Level of Diagnostics Using the CLI 11
- ▼ To Change the Diagnostics Mode Using the CLI 12
- ▼ To Specify Diagnostic Trigger Conditions Using the CLI 12
- ▼ To Choose the Amount of Verbosity in Diagnostic Output Using the CLI 13
- ▼ To Manage Diagnostics Settings Using the Web Interface 13

#### Managing System User Interactions 15

- ▼ To Choose Host Response Modes to Break Signals Using the CLI 15
- ▼ To Display Host Status Information Using the CLI 15

### 3. Managing the Service Processor 17

#### Storing Customer Information Using the SP 17

- ▼ To Change Customer FRU Data Using the CLI 17
- ▼ To Change System Identification Information Using the CLI 18
- ▼ To Change Customer Identification Information Using the Web Interface 18

#### Changing Service Processor Settings to Factory Defaults 19

- ▼ To Reset the Service Processor Settings to Factory Default Values Using the CLI 19
- ▼ To Reset the Service Processor Settings to Factory Defaults Using the Web Interface 20

#### Modifying Console Escape Characters 20

- ▼ To Change Console Escape Characters Using the CLI 21

#### Changing Configuration Policy Settings 21

- ▼ To Disable or Re-Enable Backup of the User Database Using the CLI 21

- ▼ To Disable or Re-Enable Powering On the Host Server Using the CLI 22
- ▼ To Disable or Re-Enable Power On Delay Using the CLI 23
- ▼ To Manage Configuration Policy Settings Using the Web Interface 23

#### Managing SSH Server Settings 24

- ▼ To Change the Type of SSH Keys Using the CLI 24
- ▼ To Generate a New Set of SSH Keys Using the CLI 24
- ▼ To Restart the SSH Server Using the CLI 25
- ▼ To Specify or Disable the Remote Connection Using the CLI 25
- ▼ To Manage SSH Server Settings Using the Web Interface 26

### 4. Managing Devices 29

#### Managing Virtual Keyswitch Settings 29

- ▼ To Control the Virtual Keyswitch Using the CLI 29
- ▼ To Control the Virtual Keyswitch Using the Web Interface 30

#### A. IPMI Sensor Reference 33

#### B. ALOM CMT Compatibility Shell 47

##### Backward Compatibility Limits 47

- Adding a Commit Step to Procedures That Configure ILOM Network Configuration Properties 48

##### Creating an ALOM CMT Shell 49

- ▼ To Create an ALOM CMT Compatibility Shell 49

##### ILOM and ALOM CMT Command Comparison 51

##### ALOM CMT Variable Comparison 57

#### Index 59



# Preface

---

The *Sun Integrated Lights Out Manager (ILOM) 2.0 Supplement for Sun Netra T5220 Server* contains information about Oracle Integrated Lights Out Manager (ILOM) service processor (SP). The SP enables you to remotely manage and administer your servers. You should be an experienced system administrator with a knowledge of UNIX<sup>®</sup> commands.

---

## How This Book Is Organized

[Chapter 1](#) introduces the Integrated Lights Out Manager (ILOM).

[Chapter 2](#) describes managing SPARC specific features of the host.

[Chapter 3](#) describes managing SPARC specific features of the SP.

[Chapter 4](#) describes managing SPARC specific features of system devices.

[Appendix A](#) identifies IPMI sensor data (the `/SYS` namespace).

[Appendix B](#) lists and describes ALOM CMT equivalents for ILOM commands and properties.

---

# Using UNIX Commands

This document might not contain information on basic UNIX commands and procedures such as shutting down the system, booting the system, and configuring devices. See the following for this information:

- Software documentation that you received with your system
- Oracle Solaris OS documentation, which is at:

<http://docs.sun.com>

---

# Shell Prompts

Shell	Prompt
C shell	<i>machine-name%</i>
C shell superuser	<i>machine-name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#
ILOM service processor	->
OpenBoot PROM firmware	ok

---

# Typographic Conventions

Typeface	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
<b>AaBbCc123</b>	What you type, when contrasted with on-screen computer output	% <b>su</b> Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this. To delete a file, type <code>rm filename</code> .

---

**Note** – Characters display differently depending on browser settings. If characters do not display correctly, change the character encoding in your browser to Unicode UTF-8.

---

---

## Related Documentation

The following table lists the documentation for this product. The online documentation is available at:

<http://docs.sun.com/app/docs/prod/server.nebs>

---

Application	Title	Part Number	Format	Location
Planning	<i>Sun Netra T5220 Server Site Planning Guide</i>	820-3008	PDF, HTML	Online
Installation	<i>Sun Netra T5220 Server Installation Guide</i>	820-3009	PDF, HTML	Online
Administration	<i>Sun Netra T5220 Server Administration Guide</i>	820-3010	PDF, HTML	Online
Issues & Updates	<i>Sun Netra T5220 Server Product Notes</i>	820-3014	PDF, HTML	Online
ILOM Reference	<i>Oracle Integrated Lights Out Manager (ILOM) 2.0 Supplement for the Sun Netra T5220 Server</i>	820-3011	PDF, HTML	Online

---

Application	Title	Part Number	Format	Location
ILOM Reference	<i>Oracle Integrated Lights Out Manager (ILOM) 2.0 Supplement for the Sun Netra T5220 Server</i>	820-6892	PDF, HTML	Online
Service	<i>Sun Netra T5220 Server Service Manual</i>	820-3012	PDF, HTML	Online
Compliance	<i>Sun Netra T5220 Server Safety and Compliance Guide</i>	816-7190	PDF	Online
Overview	<i>Sun Netra T5220 Server Getting Started Guide</i>	820-3016	Printed PDF	Shipping kit & Online

## Documentation, Support, and Training

Sun Function	URL
Documentation	<a href="http://docs.sun.com/">http://docs.sun.com/</a>
Support	<a href="http://www.sun.com/support/">http://www.sun.com/support/</a>
Training	<a href="http://www.sun.com/training/">http://www.sun.com/training/</a>

## Sun Welcomes Your Comments

Submit your comments by clicking the Feedback[+] link at:

<http://docs.sun.com>

Include the title and part number of your document with your feedback:

*Oracle Integrated Lights Out Manager (ILOM) 2.0 Supplement for the Sun Netra T5220 Server*, part number 820-3011-13

# Oracle ILOM for the Sun Netra T5220 Server

---

This chapter introduces ILOM for the Sun Netra T5220 server from Oracle.

This chapter contains the following sections:

- [“SPARC Specific ILOM Features” on page 1](#)
- [“ILOM Features Not Supported in SPARC Servers” on page 1](#)

---

## SPARC Specific ILOM Features

ILOM operates on many platforms, supporting features that are common to all platforms. There are some ILOM features that belong to a subset of platforms and not to all. This document describes features that belong to the Sun Netra T5220, augmenting the set of features described in the *Sun Integrated Lights Out Manager 2.0 User's Guide*.

---

## ILOM Features Not Supported in SPARC Servers

Among the ILOM features supported on other platforms, ILOM does not support the following features on the server:

- ILOM Remote Console
- Chassis Monitoring Module (CMM) features, such as single sign on

The remainder of this document describes the ILOM features that are supported on the server.

## Managing the Host

---

This chapter contains information on ILOM features on the Sun Netra T5220 server that augment the array of properties that are common to ILOM on other platforms. In particular, this chapter describes the properties in the /HOST namespace. This chapter consists of:

- “Resetting the Host” on page 3
- “Managing Remote Control” on page 4
- “Viewing System Information and Setting System Policy Concerning Error Conditions” on page 8
- “Managing Diagnostics” on page 11
- “Managing System User Interactions” on page 15

---

## Resetting the Host

The `reset` command generates a graceful or forced hardware reset of the host server. By default, the `reset` command gracefully resets the host. If a graceful reset is not possible, a forced reset is performed. For a list of available options for the `reset` command in both the ILOM and ALOM compatibility CLIs, see [TABLE B-2](#).

---

# Managing Remote Control

Use the remote control properties to specify how ILOM handles boot.

- [To Manage the Host's Boot Mode Configuration Using the CLI](#)
- [To Manage the Host's Boot Mode Script Using the CLI](#)
- [To Change the Host's Boot Mode Behavior at Reset Using the CLI](#)
- [To Display Host's Boot Mode Expiration Date Using the CLI](#)
- [To Change Remote Control Configuration Settings Using the Web Interface](#)

## Boot Mode

Boot mode (`bootmode`) properties enable you to override the default method the server uses when it boots. This ability is useful to override particular OpenBoot or LDOMs settings that might be incorrect, to set up OpenBoot variables using a script, or similar tasks.

For example, if the OpenBoot settings have become corrupt, you can set the `bootmode state` property to `reset_nvram`, then reset the server with factory default OpenBoot settings.

Service personnel might instruct you to use the `bootmode script` property for problem resolution. The full extent of script capabilities are not documented and exist primarily for debugging.

Because `bootmode` is intended to be used for a single boot only, to correct a problem with the OpenBoot or LDOMs settings, the `bootmode` takes effect for a single boot only. Additionally, to prevent an administrator from setting a `bootmode state` property and forgetting about it, a `bootmode state` property expires if the host is not reset within 10 minutes of the `bootmode state` property being set.

## ▼ To Manage the Host's Boot Mode Configuration Using the CLI

- At the `->` prompt, type the following command:

```
-> set /HOST/bootmode config=value
```

where the `config` property takes a *configname* value such as a named logical domain configuration downloaded to the SP using the Logical Domains software.

For example, if you have created a logical domain configuration called `ldm-set1`:

```
-> bootmode config=ldm-set1
```

To return the boot mode `config` to the factory default configuration, specify `factory-default`.

For example:

```
-> bootmode config=factory-default
```

## ▼ To Manage the Host's Boot Mode Script Using the CLI

- At the `->` prompt, type the following command:

```
-> set /HOST/bootmode script=value
```

where `script` controls the host server OpenBoot PROM firmware method of booting.

The script does not affect the current `/HOST/bootmode` setting. *string* can be up to 64 bytes in length. You can specify a `/HOST/bootmode` setting and set the script within the same command.

For example:

```
-> set /HOST/bootmode state=reset_nvram script="setenv diag-switch? true"
```

After the server resets and OpenBoot PROM reads the values stored in the script, firmware sets the OpenBoot PROM variable `diag-switch?` to the user-requested value of `true`.

---

**Note – Note:** If you set `/HOST/bootmode script=""`, ILOM sets the `script` to empty. If you set `/HOST/bootmode config=""`, ILOM sets the `config` to empty.

---

## ▼ To Change the Host's Boot Mode Behavior at Reset Using the CLI

The `/HOST/bootmode state` property prepares the service processor firmware for reset, retaining the current settings of OpenBoot nonvolatile read-only memory (NVRAM) variables. Setting `/HOST/bootmode state=reset_nvram` changes the OpenBoot NVRAM variables to default settings.

- At the `->` prompt, type the following command:

```
-> set /HOST/bootmode state=value
```

where *value* is one of the following:

- `normal` – At next reset, retains current NVRAM variable settings
- `reset_nvram` – At next reset, returns OpenBoot variables to default settings

---

**Note –** `state=reset_nvram` will return to `normal` after the next server reset (or 10 minutes (see `expires` property in the *Integrated Lights Out Management 2.0 User's Guide*). `config` and `script` properties do not expire and will be cleared upon the next server reset or manually by setting *string* to `" "`.

---

## ▼ To Display Host's Boot Mode Expiration Date Using the CLI

- At the `->` prompt, type the following command:

```
-> show /HOST/bootmode expires
```

where `expires` is the date at which the current `bootmode state` expires.

## ▼ To Change Remote Control Configuration Settings Using the Web Interface

The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a navigation bar with 'ABOUT', 'REFRESH', and 'LOG OUT' buttons. Below this, the user role is 'Administrator (root)' and the SP Hostname is 'SUNSP00144F3F8CAF'. The main title is 'Sun™ Integrated Lights Out Manager'. A secondary navigation bar contains tabs for 'System Information', 'System Monitoring', 'Configuration', 'User Management', 'Remote Control', and 'Maintenance'. Under 'Remote Control', there are sub-tabs for 'Remote Power Control', 'Diagnostics', 'Host Control', 'Boot Mode Settings', and 'Keyswitch'. The 'Boot Mode Settings' tab is active, showing the 'Boot Mode' configuration page. The page instructs the user to 'Configure boot mode settings. Select an option for state, either Normal or Reset\_nvram. Enter the boot script and LDOM configuration.' The form includes a 'State' dropdown menu set to 'Normal', an 'Expiration Date' field showing 'Tue Jan 19 03:14:07 2038', a 'Script' text input field containing 'my script', and an 'LDOM Config' text input field containing 'ldm-set1'. A 'Save' button is located at the bottom left of the form.

ILOM provides several ways to configure the server's firmware environment. There are four aspects to configuring the boot mode:

- State
- Expiration Date
- Script
- LDom Configuration

1. Log into the ILOM web interface as Administrator (`root`) to open the web interface.
2. Select Remote Control -> Boot Mode Settings.
3. Select the Boot Mode State.
4. View the Expiration Date.
5. Specify a boot script.
6. Specify an LDom configuration file.
7. Click Save.

---

# Viewing System Information and Setting System Policy Concerning Error Conditions

Use the system information properties to view system configuration and firmware version information.

- [To Display the Host's MAC Address Using the CLI](#)
- [To Display the Host's OpenBoot Version Using the CLI](#)
- [To Display the Host's POST Version Using the CLI](#)
- [To Determine Host Behavior When the Watchdog Timer Expires Using the CLI](#)
- [To Specify Whether the Host Halts During Diagnostics When an Error Is Discovered Using the CLI](#)
- [To View Host Information Using the Web Interface](#)

## ▼ To Display the Host's MAC Address Using the CLI

The `/HOST macaddress` property is automatically configured by the system software, so you cannot set it or change it. The value is read and determined from the server's MAC address and then stored as a property in ILOM.

`/HOST macaddress` is the MAC address for the `net0` port. The MAC addresses for each additional port increments from the `/HOST macaddress`. For example, `net1` is equal to the value of `/HOST macaddress` plus one (1).

- To view the current setting for this property, type the following command:

```
-> show /HOST macaddress
```

## ▼ To Display the Host's OpenBoot Version Using the CLI

The `/HOST obp_version` property displays information about the version of OpenBoot on the host.

- To view the current setting for this property, type the following command:

```
-> show /HOST obp_version
```

## ▼ To Display the Host's POST Version Using the CLI

The `/HOST post_version` property displays information about the version of POST on the host.

- To view the current setting for this property, type the following command:

```
-> show /HOST post_version
```

## ▼ To Determine Host Behavior When the Watchdog Timer Expires Using the CLI

Use the `/HOST autorestart` property to specify how ILOM should handle expiration of the Oracle Solaris watchdog timer.

- To set this property, type the following command:

```
-> set /HOST autorestart=value
```

where values can be `none`, `reset`, or `dumpcore` (default value: `reset`).

---

**Note** – The default option (`reset`) supports the Oracle Solaris watchdog timer.

---

## ▼ To Specify Whether the Host Halts During Diagnostics When an Error Is Discovered Using the CLI

Use the `/HOST autorunonerror` property to specify whether the host should continue to boot after system diagnostics have discovered an error.

- To set this property, type the following command:

```
-> set /HOST autorunonerror=value
```

Where *values* can be true or false. The default value is false.

## ▼ To View Host Information Using the Web Interface

This procedure describes how to view and configure several kinds of host information.

The screenshot displays the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a navigation bar with 'ABOUT', 'REFRESH', and 'LOG OUT' buttons. Below this, the user role is 'Administrator (root)' and the SP Hostname is 'SUN5P00144F3F8CAF'. The main title is 'Sun™ Integrated Lights Out Manager' with the Sun logo and 'Java' branding. A menu bar contains 'System Information', 'System Monitoring', 'Configuration', 'User Management', 'Remote Control', and 'Maintenance'. Under 'Remote Control', there are sub-menus for 'Remote Power Control', 'Diagnostics', 'Host Control', 'Boot Mode Settings', and 'Keyswitch'. The 'Host Control' sub-menu is selected, showing a page titled 'Host Control'. The page content includes a description: 'View and configure the host control information. Auto Run on Error determines whether the host should continue to boot in the event of a non-fatal POST error. Auto Restart Policy determines what action the Service Processor should take when it discovers the host is hung.' Below this, several fields are listed: 'MAC Address: 00:14:4f:3f:8c:a6', 'OBP Version: OBP \*\*\*n2 build\_100 PROTOTYPE BUILD\*\*\* 2007/05/16 18:19 [stacie obp #0]', 'POST Version: Sun Fire[™] Huron POST 4.x.0.n2.build\_100 2007/05/16 19:23', 'Post Status: OS Running', 'Auto Run On Error: False' (with a dropdown arrow), and 'Auto Restart Policy: Reset' (with a dropdown arrow). A 'Save' button is located at the bottom left of the configuration area.

ILOM provides several ways to view or configure host control features. There are six aspects to host control:

- MAC address
- OpenBoot version
- POST version
- POST status

- Auto Run On Error
  - Auto Restart Policy
1. Log into the ILOM web interface as Administrator (`root`) to open the web interface.
  2. Select Remote Control -> Host Control.
  3. View the MAC address.
  4. View the OpenBoot version.
  5. View the POST version.
  6. Select a value for Auto Run On Error.
  7. Select a value for Auto Restart Policy.
  8. Click on Save.

---

## Managing Diagnostics

Use the diagnostic control properties to specify how ILOM behaves when it encounters an error on the host server.

ILOM uses the following diagnostic system interface property:

- [To Specify the Level of Diagnostics Using the CLI](#)
- [To Change the Diagnostics Mode Using the CLI](#)
- [To Specify Diagnostic Trigger Conditions Using the CLI](#)
- [To Choose the Amount of Verbosity in Diagnostic Output Using the CLI](#)
- [To Manage Diagnostics Settings Using the Web Interface](#)

### ▼ To Specify the Level of Diagnostics Using the CLI

Use the `/HOST/diag level` property to specify the level of diagnostic testing to be executed when diagnostics are enabled.

- At the `->` prompt, type the following command:

```
-> set /HOST/diag level=value
```

where *value* is one of the following:

- `min` – Run the minimum level of diagnostics to verify the system (the default value).
- `max` – Run the maximum set of diagnostics to fully verify system health.

## ▼ To Change the Diagnostics Mode Using the CLI

Use the `/HOST/diag mode` property to control whether diagnostics are enabled and to specify which diagnostic mode is enabled.

- **At the `->` prompt, type the following command:**

```
-> set /HOST/diag mode=value
```

where *value* is one of the following:

- `off` – Run no diagnostics.
- `normal` – Run diagnostics (the default value).
- `service` – Run service-technician diagnostics, equivalent to using the preset values of `/HOST/diag trigger=all-resets`, `/HOST/diag verbosity`, and `/HOST/diag level=max`. Setting `/HOST/diag mode=service` has the same effect as issuing the `set /SYS keyswitch_state=diag` command.

## ▼ To Specify Diagnostic Trigger Conditions Using the CLI

Use the `/HOST/diag trigger` property to control the conditions under which POST runs if diagnostics are enabled.

- **At the `->` prompt, type the following command:**

```
-> set /HOST/diag trigger=value
```

where *value* is one (or a combination, supplied within quote marks) of the following:

- `user-reset` – Run diagnostics when the system is reset.
- `error-reset` – Run diagnostics when the system takes a fatal error that requires the system to reset itself to recover.
- `power-on-reset` – Run diagnostics when the system is powered on.
- `all-resets` – Run all of the diagnostics specified by `user-reset`, `error-reset`, and `power-on-reset` [the default value].

- none – Skip diagnostics.

The default value is the combination of `power-on-reset` `error-reset`.

For example;

```
-> set /HOST/diag trigger="user-reset power-on-reset"  
-> show /HOST/diag trigger  
user-reset power-on-reset
```

## ▼ To Choose the Amount of Verbosity in Diagnostic Output Using the CLI

Use the `/HOST/diag verbosity` property to specify the verbosity level of the output from POST diagnostics, if diagnostics are enabled.

- At the `->` prompt, type the following command:

```
-> set /HOST/diag verbosity=value
```

where *value* is one of the following:

- none – Diagnostics do not print any output on the system console when running, unless a fault is detected.
- min – Diagnostics print a limited amount of output on the system console.
- max – Diagnostics print full output on the system console, including the name and results of each test being run.
- normal – Diagnostics print a moderate amount of output on the system console (the default value).
- debug – Diagnostics print extensive debugging output on the system console, including devices being tested and debug output of each test.

## ▼ To Manage Diagnostics Settings Using the Web Interface

This procedure describes how to view and configure diagnostics settings.

ABOUT REFRESH LOG OUT

Role (User): Administrator (root) SP Hostname : SUNSP00144F3F8CAF

## Sun™ Integrated Lights Out Manager

  
Sun™ Microsystems, Inc.

System Information	System Monitoring	Configuration	User Management	Remote Control	Maintenance
Remote Power Control	Diagnostics	Host Control	Boot Mode Settings	Keyswitch	

### Diagnostics

Select the level of embedded diagnostics to run on the host during start up. The Trigger contains all possible states to cause diagnostics to be run. The Verbosity level will define how much information will be given. The Update Mode contains all the possible OPS modes specified to POST.

Trigger:

Verbosity:

Level:

Current Mode: off

Update Mode:

ILOM provides several ways to view or configure diagnostics. There are four aspects to host control:

- Trigger
- Verbosity
- Level
- Mode

1. **Log into the ILOM web interface as Administrator (root) to open the web interface.**
2. **Select Remote Control -> Diagnostics.**
3. **Select a value for Trigger.**
4. **Select a value for Verbosity.**
5. **Select a value for Level.**
6. **View the Current Mode.**
7. **Select a value for Update Mode.**

---

# Managing System User Interactions

The system user properties enable you to customize the way ILOM identifies and interacts with the host server.

- [To Choose Host Response Modes to Break Signals Using the CLI](#)
- [To Display Host Status Information Using the CLI](#)

## ▼ To Choose Host Response Modes to Break Signals Using the CLI

Use the `set /HOST send_break_action` command to bring the server to a menu from which you can choose to go to the OpenBoot PROM prompt (ok). If you have configured the `kmdb` debugger, then the `break` command brings the server into debug mode.

- At the `->` prompt, type the following command:

```
-> set /HOST send_break_action=value
```

where *value* is one of the following:

- `break` – Sends a break to the host.
- `dumpcore` – Forces a panic core dump of the managed system OS (not supported by all OS versions).

## ▼ To Display Host Status Information Using the CLI

Use the `show /HOST status` command to display information about the host server's platform ID and status.

- At the `->` prompt, type the following command:

```
-> show /HOST status
```

The command returns information similar to the following:

```
-> show /HOST status  
  Properties:  
    status = OS Running  
  
  Commands:  
    show ->
```

## Managing the Service Processor

---

This chapter contains information on ILOM properties on the Sun Netra T5220 server that augment the array of properties that are common to ILOM on other platforms. In particular, this chapter covers properties in the `/SP` namespace. This chapter consists of:

- [“Storing Customer Information Using the SP” on page 17](#)
- [“Changing Service Processor Settings to Factory Defaults” on page 19](#)
- [“Modifying Console Escape Characters” on page 20](#)
- [“This section describes managing configuration system policies using ILOM.” on page 21](#)
- [“Managing SSH Server Settings” on page 24](#)

---

### Storing Customer Information Using the SP

This section describes ILOM features that enable you to store information (for purposes such as inventory control or site resource management) on the SP and FRU PROMs.

- [To Change Customer FRU Data Using the CLI](#)
- [To Change System Identification Information Using the CLI](#)
- [To Change Customer Identification Information Using the Web Interface](#)

#### ▼ To Change Customer FRU Data Using the CLI

Use the `/SP customer_frudata` property to store information in all FRU PROMs.

- At the `->` prompt, type the following command:

```
-> set /SP customer_frudata=data
```

## ▼ To Change System Identification Information Using the CLI

Use the `/SP system_identifier` property to store customer identification information.

- At the `->` prompt, type the following command:

```
-> set /SP system_identifier=data
```

## ▼ To Change Customer Identification Information Using the Web Interface

The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a navigation bar with "ABOUT" on the left and "REFRESH" and "LOG OUT" on the right. Below this, the user role is "Administrator (root)" and the SP hostname is "SUNSP00144F3F8CAF". The main title is "Sun™ Integrated Lights Out Manager" with the Java logo and "Sun™ Microsystems, Inc." on the right. A menu bar contains "System Information", "System Monitoring", "Configuration", "User Management", "Remote Control", and "Maintenance". Under "System Information", there are sub-menus: "Versions", "Session Time-Out", "Components", "Fault Management", and "Identification Information". The "Identification Information" sub-menu is selected, showing the title "Identification Information" and the instruction "Configure identification information." Below this, there are three input fields: "Customer FRU Data:" with the value "my fru data", "SP Hostname:" with the value "SUNSP00144F3F8CAF", and "SP System Identifier:" with the value "my system". A "Save" button is located at the bottom left of the form area.

ILOM provides features that enable you to store information on FRUs and the SP.

1. Log into the ILOM web interface as Administrator (`root`) to open the web interface.

2. Select System Information --> Identification Information.
3. Edit the Customer FRU data field.
4. View the SP Hostname.
5. Edit the SP System Identifier field.
6. Click Save.

---

## Changing Service Processor Settings to Factory Defaults

This section describes how to set service processor settings back to the factory defaults.

- [To Reset the Service Processor Settings to Factory Default Values Using the CLI](#)
- [To Reset the Service Processor Settings to Factory Defaults Using the Web Interface](#)

### ▼ To Reset the Service Processor Settings to Factory Default Values Using the CLI

Use the `reset_to_defaults` property to set all ILOM configuration properties back to their factory default values. The `all` option sets the ILOM configuration and all user information back to the factory default values.

1. At the `->` prompt, type the following command:


```
-> set /SP reset_to_defaults=all
```

where for `reset_to_defaults` can be set to one of the following:

- `none` – Make no changes.
- `configuration` – Preserve the user database.
- `all` – Reset (clear) the user database.

2. Reset the service processor so that the new property value can take effect.

## ▼ To Reset the Service Processor Settings to Factory Defaults Using the Web Interface



The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a header with "ABOUT" on the left and "REFRESH" and "LOG OUT" buttons on the right. Below the header, the user role is "Administrator (root)" and the SP Hostname is "SUNSP00144F3F8CAF". The main title is "Sun™ Integrated Lights Out Manager". On the right side, there is a Java logo and "Sun™ Microsystems, Inc." text. Below the header, there is a navigation menu with tabs: "System Information", "System Monitoring", "Configuration", "User Management", "Remote Control", and "Maintenance". Under the "Configuration" tab, there are sub-tabs: "Firmware Upgrade", "Reset SP", and "Configuration Management". The "Configuration Management" sub-tab is selected. The main content area is titled "Configuration Management" and contains the text: "Manage the system configuration on this page. Clicking *Reset Defaults* will restore the system configuration to factory settings." Below this text, there is a "Reset Defaults:" label followed by a dropdown menu currently showing "None". At the bottom of the form, there is a "Reset Defaults" button.

1. Log into the ILOM web interface as Administrator (`root`) to open the web interface.
2. Select Maintenance --> Configuration Management.
3. Select a Reset Defaults value.
4. Click Save.

---

## Modifying Console Escape Characters

This section describes creating new character combinations for use as escape characters.

- [To Change Console Escape Characters Using the CLI](#)

## ▼ To Change Console Escape Characters Using the CLI

Use the `/SP/console escapechars` property to change the escape character sequence to switch from a system console session back to ILOM.

- At the `->` prompt, type the following command:

```
-> set /SP/console escapechars=x.
```

The sequence is limited to two characters. The second character is always `.` (Period). The default value is `#.` (Hash-Period). The sequence can be customized.

where *x* is any printable character.

---

**Note** – Changing the escape character does not take effect in a currently active console session.

---

---

## Changing Configuration Policy Settings

This section describes managing configuration system policies using ILOM.

- [To Disable or Re-Enable Backup of the User Database Using the CLI](#)
- [To Disable or Re-Enable Powering On the Host Server Using the CLI](#)
- [To Disable or Re-Enable Power On Delay Using the CLI](#)
- [To Manage Configuration Policy Settings Using the Web Interface](#)

## ▼ To Disable or Re-Enable Backup of the User Database Using the CLI

The `/SP/policy BACKUP_USER_DATA` property specifies whether the local user database on ILOM (that is, user, password, and permission information) should be backed up. When this property is set to `enable`, this data is backed up on the removable system configuration card (SCC PROM) on the system.

- At the `->` prompt, type the following command:

```
-> set /SP/policy BACKUP_USER_DATA=value
```

where the *value* can be one of the following:

- enabled – Backs up the user database to the SCC (This is the default value).
- disabled – No backup.

For example, if you want the local user database on ILOM to be backed up, type the following command:

```
-> set /SP/policy BACKUP_USER_DATA=enabled
```

## ▼ To Disable or Re-Enable Powering On the Host Server Using the CLI

ILOM runs as soon as power is applied to the host server, even if the server is powered off. When you first apply power to the host server, ILOM starts to run, but the server does not start up until you power it on.

You can use the `/SP/policy HOST_LAST_POWER_STATE` property to disable the host server (keep the host server off) or re-enable the server (return the server to the state it was in when the power was removed). This property is useful in the event of a power failure, or if you physically move the server to a different location.

For example, if the host server is running when power is lost and the `/SP/policy HOST_LAST_POWER_STATE` property is set to `disabled`, the host server remains off when power is restored. If the `/SP/policy HOST_LAST_POWER_STATE` property is set to `enabled`, the host server restarts when the power is restored.

- At the `->` prompt, type the following command:

```
-> set /SP/policy HOST_LAST_POWER_STATE=enabled
```

where the value for this property can be one of the following:

- enabled – When power is restored, returns the server to the state it was in before the power was removed.
- disabled – Keeps the server off when power is applied.

If you enable this property, you must configure `/SP/policy HOST_POWER_ON_DELAY` as well. For further information, see [“To Disable or Re-Enable Power On Delay Using the CLI” on page 23](#)

## ▼ To Disable or Re-Enable Power On Delay Using the CLI

Use the `/SP/policy HOST_POWER_ON_DELAY` property to cause the server to wait for a short time before powering on automatically. The delay is a random interval of one to five seconds. Delaying the server poweron helps minimize current surges on the main power source. This poweron delay is important when multiple servers in racks power on after a power outage.

This property takes effect only if `/SP/policy HOST_LAST_POWER_STATE` is set to enabled.

- At the `->` prompt, type the following command:

```
-> set /SP/policy HOST_POWER_ON_DELAY=value
```

where *value* can be enabled or disabled.

## ▼ To Manage Configuration Policy Settings Using the Web Interface

The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, there is a navigation bar with 'ABOUT', 'REFRESH', and 'LOG OUT' buttons. Below this, the user role is 'Administrator (root)' and the SP Hostname is 'SUNSP00144F3F8CAF'. The main title is 'Sun™ Integrated Lights Out Manager'. A navigation menu includes 'System Information', 'System Monitoring', 'Configuration', 'User Management', 'Remote Control', and 'Maintenance'. Under 'Configuration', there are sub-menus: 'System Management Access', 'Alert Management', 'Network', 'Serial Port', 'Clock Settings', 'Syslog', 'SMTP Client', and 'Policy'. The 'Policy Configuration' section is active, with instructions: 'Configure system policies from this page. To modify a policy, select the radio button next to that policy, then choose Enable or Disable from the Action drop down list.' Below this is a table titled 'Service Processor Policies' with a dropdown menu for 'Actions' set to 'Actions'. The table has columns for 'Description' and 'Status'.

Description	Status
<input type="radio"/> Auto power-on host on boot (enabling this policy disables Set host power to last power state policy)	Disabled
<input type="radio"/> Set host power to last power state on boot (enabling this policy disables Auto power-on host policy)	Disabled
<input type="radio"/> Set to delay host power on	Disabled
<input type="radio"/> Set to enable backing up of user account info to SCC card	Enabled

1. Log into the ILOM web interface as Administrator (`root`) to open the web interface.
2. Select Configuration --> Policy.
3. Click the Policy radio button of the policy you want to change.
4. Select an Action value to apply the Action (enable or disable) you have chosen.

---

## Managing SSH Server Settings

- [To Change the Type of SSH Keys Using the CLI](#)
- [To Generate a New Set of SSH Keys Using the CLI](#)
- [To Restart the SSH Server Using the CLI](#)
- [To Specify or Disable the Remote Connection Using the CLI](#)
- [To Manage SSH Server Settings Using the Web Interface](#)

### ▼ To Change the Type of SSH Keys Using the CLI

Use the `set /SP/services/ssh generate_new_key_type` command to change the type of Secure Shell (SSH) host keys generated on your server. After changing the type, you must use the `set /SP/services/ssh generate_new_key_action` command to generate a new set of keys of the new type.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh generate_new_key_type=value
```

where *value* can be `rsa` or `dsa`.

### ▼ To Generate a New Set of SSH Keys Using the CLI

Use the `set /SP/services/ssh generate_new_key_action` command to generate a new set of Secure Shell (SSH) host keys.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh generate_new_key_action=true
```

## ▼ To Restart the SSH Server Using the CLI

Use the `set /SP/services/ssh restart_sshd_action` command to restart the SSH server after you have generated new host keys using the `set /SP/services/ssh generate_new_key_action` command. This reloads the keys into the server's dedicated data structure in memory.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh restart_sshd_action=true
```

## ▼ To Specify or Disable the Remote Connection Using the CLI

Use the `/SP/services/ssh state` property with the `set` command to specify or disable the remote connection.

- At the `->` prompt, type the following command:

```
-> set /SP/services/ssh state=value
```

where *value* is enabled or disabled.

## ▼ To Manage SSH Server Settings Using the Web Interface

The screenshot shows the Sun Integrated Lights Out Manager (ILOM) web interface. At the top, it displays the role as Administrator (root) and the SP Hostname as SUNSP00144F3F8CAF. The main navigation bar includes tabs for System Information, System Monitoring, Configuration, User Management, Remote Control, and Maintenance. Under the Configuration tab, there are sub-tabs for System Management Access, Alert Management, Network, Serial Port, Clock Settings, Syslog, SMTP Client, and Policy. The SSH Server sub-tab is selected, showing the SSH Server Settings page.

**SSH Server Settings**

Configure Secure Shell server access and key generation. Newly generated keys are not used until the SSH server is restarted. When the SSH server is restarted or disabled, any CLI sessions running over SSH will be immediately terminated.

**SSH Server:** Enabled

**RSA Key:** Generate RSA Key

**RSA Fingerprint:** e1:92:e7:b2:dc:74:95:e1:7e:f9:18:3a:ab:54:7e:16

**RSA Key Length:** 1024 bits

**RSA Public Key:**

```

AAAAAB3NzaC1yc2EAAAABIwAAAIEAvERT9pFfm3sUg78KI7Qr
+1ws1mbwv15S01/hMTj+++1jw1ebI8+ujvHIn3z1hOROURRJc
V9KymcJnRwE1jWRjmc+UkJWUez29xg7Mi jEIs jqHQbmsH61
6FrSDhpcRV0kHS7L8yDT58HgIITHy6pprakG7Yd9cHek221uO
EzEqUVU=

```

**DSA Key:** Generate DSA Key

**DSA Fingerprint:** d7:03:28:55:cc:cc:4f:c5:06:99:da:7b:ec:4c:77:1a

**DSA Key Length:** 1024 bits

**DSA Public Key:**

```

AAAAAB3NzaC1kc3MAAACBAIbgDF+t1ghTF1L1tvSHN4ELU5ZQ
mX0RuL7EdKWhf0iqTgWqo6fupvBsB1k29UFVJAP2FEnw6ka0
GgFN2UC3y2zr1MtLw4Ufg00blNcZwLoI0Sq8ETZGypLL1H8OPo
xJzGtcjcnKcSALcy+Gwf4WHEB1Qoo4sbknA3AY+jszTIehcnRD
AAAAAPQDAvfDKEm+3/xqh34ThFCq7YhuxHwAAAIb5+aiYIH=0
GgR8SG19HvDDDicC70p0x9irFR/rIVOL1ZCPcoCVJ6663E6q
k+PwHoF8S5J4OpLXhHauLo6uxH6AatLgHK6bR7zrjM1D6wZED
IdFZT4YTyEa8+uoRQiKoorDggkByOq+g71s+uW/A5oEcVKPy
QcKeRpiYQI+6gmKR/QAAAIbzt6knhe1RczyA0dtLw8AP1nHr
L3cu7Zi10Zn1rkpc7IOo21UUPO5JF21MEYHE8Qc/4qxjZvmP
PHOCLmqUj jQMmMizUheZGpMsIe9q2/qhET8UoBSQ9T0VaQ
qQhJr1r5jotcBDxRwHRIH1IFEApTnsQiC+a865P8VY8PPUB
MQ==

```

1. Log into the ILOM web interface as Administrator (root) to open the web interface.
2. Select Configuration --> SSH Server Settings.

3. Select an action from the SSH Server pulldown menu.
4. Click **Generate RSA Key** or **Click Generate DSA Key** to generate a new key type and a new key.

If you have generated a new key, you must restart the SSH server for the new key to take effect.

---

**Note** – When the SSH server is restarted or disabled, any CLI sessions running over SSH will be terminated immediately.

---



## Managing Devices

---

This chapter contains information on ILOM properties on the Sun Netra T5220 server that augment the array of properties that are common to ILOM on other platforms. In particular, this chapter covers properties in the `/SYS` namespace.

- [Managing Virtual Keyswitch Settings](#)

---

## Managing Virtual Keyswitch Settings

- [To Control the Virtual Keyswitch Using the CLI](#)
- [To Control the Virtual Keyswitch Using the Web Interface](#)

### ▼ To Control the Virtual Keyswitch Using the CLI

Use the `/SYS setkeyswitch_state` property to control the virtual keyswitch position of the system.

- At the `->` prompt, type the following command:

```
-> set /SYS keyswitch_state=value
```


where the `setkeyswitch_state` property has the following values:

**TABLE 4-1** `keyswitch_state` Values

Option	Description
normal	The system can power itself on and start the boot process.
stby	The system cannot power itself on.
diag	The system can power itself on using preset values of diagnostic properties ( <code>/HOST/diag level=max</code> , <code>/HOST/diag mode=max</code> , <code>/HOST/diag verbosity=max</code> ) to provide thorough fault coverage. This option overrides the values of diagnostic properties that you might have set.
locked	The system can power itself on, however you are prohibited from updating any of the flash devices or setting <code>/HOST send_break_action=break</code> .

## ▼ To Control the Virtual Keyswitch Using the Web Interface

You can use the web interface to control the virtual keyswitch position of the system.



1. Log into the ILOM web interface as Administrator (`root`) to open the web interface.
2. Select Remote Control --> Keyswitch.

3. Select the Keyswitch state value.
4. Click Save.



## IPMI Sensor Reference

Your server includes a number of IPMI-compliant sensors and indicators that measure things such as voltage and temperature ranges. Sensors include security latches that detect when the components are installed or devices that notify you that service may be required. [TABLE A-1](#) shows the sensors on your server. [TABLE A-2](#) shows the indicators on your server.

**TABLE A-1** Sensors on Sun Netra T5220 Server

Name	Path	Description
V_+3V3_STBY	/SYS/MB/V_+3V3_STBY	3.3V Standby Voltage Threshold Sensor
V_+3V3_MAIN	/SYS/MB/V_+3V3_MAIN	3.3V Main Voltage Threshold Sensor
V_+12V0_MAIN	/SYS/MB/V_+12V0_MAIN	12V Main Voltage Threshold Sensor
V_VBAT	/SYS/MB/V_VBAT	Voltage Threshold Sensor
V_VDDIO	/SYS/MB/V_VDDIO	Voltage Threshold Sensor
T_AMB	/SYS/MB/T_AMB	Ambient Temperature Threshold Sensor
I_USBn	/SYS/MB/I_USBn	USB Port (0-1) Current Sensor
PSn/AC_POK	/SYS/PSn/AC_POK	Power Supply (0-1) Power Within Specification Sensor
V_VCORE	/SYS/MB/V_VCORE	CPU Core Voltage Threshold Sensor
V_VMEML	/SYS/MB/V_VMEML	Left Branch Voltage Threshold Sensor
V_VMEMR	/SYS/MB/V_VMEMR	Right Branch Voltage Threshold Sensor

**TABLE A-1** Sensors on Sun Netra T5220 Server (*Continued*)

<b>Name</b>	<b>Path</b>	<b>Description</b>
VCORE_POK	/SYS/MB/VCORE_POK	Core Power Within Specification Sensor
VMEML_POK	/SYS/MB/VMEML_POK	Left Branch Power Within Specification Sensor
VMEMR_POK	/SYS/MB/VMEMR_POK	Right Branch Power Within Specification Sensor
BRn/CH0/D0/PRSNT	/SYS/MB/CMP0/BRn/CH0/D0/PRSNT	Branch (0-3) Presence Sensor
PSn/VOLT_FAULT	/SYS/PSn/VOLT_FAULT	Power Supply (0-1) Voltage Fault Sensor
PSn/TEMP_FAULT	/SYS/PSn/TEMP_FAULT	Power Supply (0-1) Temperature Fault Sensor
PSn/CUR_FAULT	/SYS/PSn/CUR_FAULT	Power Supply (0-1) Current Fault Sensor
PSn/DC_POK	/SYS/PSn/DC_POK	Power Supply (0-1) DC Power Sensor
PSn/FAN_FAULT	/SYS/PSn/FAN_FAULT	Power Supply (0-1) Fan Fault Sensor
FANBDn/FMn/Fn/TACH	/SYS/FANBDn/FMn/Fn/TACH	Fan Board (0-1) Fan Module (0-1) Fan (0-1) Speed Sensor
T_TCORE	/SYS/MB/CMP0/T_TCORE	Top of Core Temperature Sensor
T_BCORE	/SYS/MB/CMP0/T_BCORE	Bottom of Core Temperature Sensor
PSn/PRSNT	/SYS/PSn/PRSNT	Power Supply (0-1) Presence Sensor
FANBDn/FMn/PRSNT	/SYS/FANBDn/FMn/PRSNT	Fan Board (0-1) Fan Module (0-2) Presence Sensor
BRn/CH0/D0/T_AMB	/SYS/MB/CMP0/BRn/CH0/D0/T_AMB	Branch (0-3) Temperature Sensor
HDDn/PRSNT	/SYS/HDDn/PRSNT	Hard Disk (0-7) Presence Sensor

**TABLE A-2** Indicators on Sun Netra T5220 Server

<b>Name</b>	<b>Path</b>	<b>Description</b>
LOCATE	/SYS/LOCATE	Locate Indicator
ACT	/SYS/ACT	System Power Activity Indicator
SERVICE	/SYS/SERVICE	Service Indicator
BRn/CH0/D0/SERVICE	/SYS/MB/CMP0/BRn/CH0/D0/SERVICE	Branch Service Indicator
PS_FAULT	/SYS/PS_FAULT	Power Supply Fault Indicator
TEMP_FAULT	/SYS/TEMP_FAULT	Temperature Fault Indicator
FAN_FAULT	/SYS/FAN_FAULT	Fan Fault Indicator
FANBDn/FMn/SERVICE	/SYS/FANBDn/FMn/SERVICE	Fan Board (0-1) Fan Module (0-2) Service Indicator
HDDn/SERVICE	/SYS/HDDn/SERVICE	Hard Disk (0-7) Service Indicator
HDDn/OK2RM	/SYS/HDDn/OK2RM	Hard Disk (0-7) Okay to Remove Indicator

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR

Trap Name	Trap OID	Sensors or Components
sunHwTrapVoltageFatalThresholdExceeded	enterprises.42.2.175.103.2.0.1	/MB/V_+3V3_STBY /MB/V_+3V3_MAIN /MB/V_+12V0_MAIN /MB/V_+5V0_VCC /MB/V_VDDIO /MB/V_+1V8_GBE0 /MB/V_+1V8_GBE1 /MB/V_+1V1_VDD /MB/V_+1V0_VDD /MB/V_+1V2_VDD /MB/V_+1V5_VDD /MB/V_VCORE /MB/V_VMEML /MB/V_VMEMR /MB/V_VTFL /MB/V_VTTR
sunHwTrapVoltageFatalThresholdDeasserted	enterprises.42.2.175.103.2.0.2	/MB/V_+3V3_STBY /MB/V_+3V3_MAIN /MB/V_+12V0_MAIN /MB/V_+5V0_VCC /MB/V_VDDIO /MB/V_+1V8_GBE0 /MB/V_+1V8_GBE1 /MB/V_+1V1_VDD /MB/V_+1V0_VDD /MB/V_+1V2_VDD /MB/V_+1V5_VDD /MB/V_VCORE /MB/V_VMEML /MB/V_VMEMR /MB/V_VTFL /MB/V_VTTR

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapVoltageCritThresholdExceeded	enterprises.42.2.175.103.2.0.3	/MB/V_+3V3_STBY /MB/V_+3V3_MAIN /MB/V_+12V0_MAIN /MB/V_+5V0_VCC /MB/V_VDDIO /MB/V_+1V8_GBE0 /MB/V_+1V8_GBE1 /MB/V_+1V0_VDD /MB/V_+1V1_VDD /MB/V_+1V2_VDD /MB/V_+1V5_VDD /MB/V_VCORE /MB/V_VMEML /MB/V_VMEMR /MB/V_VTTL /MB/V_VTTR
sunHwTrapVoltageCritThresholdDeasserted	enterprises.42.2.175.103.2.0.4	/MB/V_+3V3_STBY /MB/V_+3V3_MAIN /MB/V_+12V0_MAIN /MB/V_+5V0_VCC /MB/V_VDDIO /MB/V_+1V8_GBE0 /MB/V_+1V8_GBE1 /MB/V_+1V1_VDD /MB/V_+1V0_VDD /MB/V_+1V2_VDD /MB/V_+1V5_VDD /MB/V_VCORE /MB/V_VMEML /MB/V_VMEMR /MB/V_VTTL /MB/V_VTTR

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapVoltageNonCritThresholdExceeded	enterprises.42.2.175.103.2.0.5	/MB/V_+3V3_STBY /MB/V_+3V3_MAIN /MB/V_+12V0_MAIN /MB/V_+5V0_VCC /MB/V_VDDIO /MB/V_+1V8_GBE0 /MB/V_+1V8_GBE1 /MB/V_+1V1_VDD /MB/V_+1V0_VDD /MB/V_+1V2_VDD /MB/V_+1V5_VDD /MB/V_VCORE /MB/V_VMEML /MB/V_VMEMR /MB/V_VTTL /MB/V_VTTR /MB/V_VBAT
sunHwTrapVoltageOk	enterprises.42.2.175.103.2.0.6	/MB/V_+3V3_STBY /MB/V_+3V3_MAIN /MB/V_+12V0_MAIN /MB/V_+5V0_VCC /MB/V_VDDIO /MB/V_+1V8_GBE0 /MB/V_+1V8_GBE1 /MB/V_+1V1_VDD /MB/V_+1V0_VDD /MB/V_+1V2_VDD /MB/V_+1V5_VDD /MB/V_VCORE /MB/V_VMEML /MB/V_VMEMR /MB/V_VTTL /MB/V_VTTR /MB/V_VBAT

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (*Continued*)

<b>Trap Name</b>	<b>Trap OID</b>	<b>Sensors or Components</b>
sunHwTrapTempCritThresholdExceeded	enterprises.42.2.175.103.2.0.9	/MB/T_AMB /MB/T_BUS_BAR0 /MB/T_BUS_BAR1 /MB/CMP0/T_TCORE /MB/CMP0/T_BCORE /B0/CH0/D0/TEMP /B0/CH1/D0/TEMP /B1/CH0/D0/TEMP /B1/CH1/D0/TEMP /B2/CH0/D0/TEMP /B2/CH1/D0/TEMP /B3/CH0/D0/TEMP /B3/CH1/D0/TEMP
sunHwTrapTempCritThresholdDeasserted	enterprises.42.2.175.103.2.0.10	/MB/T_AMB /MB/T_BUS_BAR0 /MB/T_BUS_BAR1 /MB/CMP0/T_TCORE /MB/CMP0/T_BCORE /B0/CH0/D0/TEMP /B0/CH1/D0/TEMP /B1/CH0/D0/TEMP /B1/CH1/D0/TEMP /B2/CH0/D0/TEMP /B2/CH1/D0/TEMP /B3/CH0/D0/TEMP /B3/CH1/D0/TEMP
sunHwTrapTempNonCritThresholdExceeded	enterprises.42.2.175.103.2.0.11	/MB/T_AMB /MB/T_BUS_BAR0 /MB/T_BUS_BAR1 /MB/CMP0/T_TCORE /MB/CMP0/T_BCORE /B0/CH0/D0/TEMP /B0/CH1/D0/TEMP /B1/CH0/D0/TEMP /B1/CH1/D0/TEMP /B2/CH0/D0/TEMP /B2/CH1/D0/TEMP /B3/CH0/D0/TEMP /B3/CH1/D0/TEMP

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapTempOk	enterprises.42.2.175.103.2.0.12	/MB/T_AMB /MB/T_BUS_BAR0 /MB/T_BUS_BAR1 /MB/CMP0/T_TCORE /MB/CMP0/T_BCORE /B0/CH0/D0/TEMP /B0/CH1/D0/TEMP /B1/CH0/D0/TEMP /B1/CH1/D0/TEMP /B2/CH0/D0/TEMP /B2/CH1/D0/TEMP /B3/CH0/D0/TEMP /B3/CH1/D0/TEMP
sunHwTrapFanSpeedFatalThresholdExceeded	enterprises.42.2.175.103.2.0.19	/FT0/F0/TACH /FT0/F1/TACH /FT0/F2/TACH /FT1/F0/TACH /FT1/F1/TACH /FT2/F0/TACH
sunHwTrapFanSpeedFatalThresholdDeasserted	enterprises.42.2.175.103.2.0.20	/FT0/F0/TACH /FT0/F1/TACH /FT0/F2/TACH /FT1/F0/TACH /FT1/F1/TACH /FT2/F0/TACH
sunHwTrapFanSpeedCritThresholdExceeded	enterprises.42.2.175.103.2.0.21	/FT0/F0/TACH /FT0/F1/TACH /FT0/F2/TACH /FT1/F0/TACH /FT1/F1/TACH /FT2/F0/TACH
sunHwTrapFanSpeedCritThresholdDeasserted	enterprises.42.2.175.103.2.0.22	
sunHwTrapFanSpeedNonCritThresholdExceeded	enterprises.42.2.175.103.2.0.23	

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapFanSpeedOk	enterprises.42.2.175.103.2.0.24	/FT0/F0/TACH /FT0/F1/TACH /FT0/F2/TACH /FT1/F0/TACH /FT1/F1/TACH /FT2/F0/TACH
sunHwTrapSensorFatalThresholdExceeded	enterprises.42.2.175.103.2.0.25	/SYS/VPS
sunHwTrapSensorFatalThresholdDeasserted	enterprises.42.2.175.103.2.0.26	/SYS/VPS
sunHwTrapSensorCritThresholdExceeded	enterprises.42.2.175.103.2.0.27	/SYS/VPS
sunHwTrapSensorCritThresholdDeasserted	enterprises.42.2.175.103.2.0.28	/SYS/VPS
sunHwTrapSensorNonCritThresholdExceede	enterprises.42.2.175.103.2.0.29	/SYS/VPS
sunHwTrapSensorThresholdOk	enterprises.42.2.175.103.2.0.30	/SYS/VPS
sunHwTrapPowerSupplyError	enterprises.42.2.175.103.2.0.32	/PS0/FAIL /PS1/FAIL /PS0/CUR_FAULT /PS0/PWROK /PS0/TEMP_FAULT /PS0/VINOK /PS0/VOLT_FAULT /PS1/CUR_FAULT /PS1/PWROK /PS1/TEMP_FAULT /PS1/VINOK /PS1/VOLT_FAULT
sunHwTrapPowerSupplyOk	enterprises.42.2.175.103.2.0.33	/PS0/FAIL /PS1/FAIL /PS0/CUR_FAULT /PS0/PWROK /PS0/TEMP_FAULT /PS0/VINOK /PS0/VOLT_FAULT /PS1/CUR_FAULT /PS1/PWROK /PS1/TEMP_FAULT /PS1/VINOK /PS1/VOLT_FAULT

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapFanError	enterprises.42.2.175.103.2.0.35	/PS0/FAN_FAULT /PS1/FAN_FAULT
sunHwTrapFanOk	enterprises.42.2.175.103.2.0.36	/PS0/FAN_FAULT /PS1/FAN_FAULT
sunHwTrapComponentError	enterprises.42.2.175.103.2.0.53	MB/P0/CBUS_BIT0 MB/P0/CBUS_BIT1 MB/P0/CBUS_BIT2 MB/P0/CBUS_BIT3 MB/P0/CBUS_BIT4 MB/P0/CBUS_BIT5 MB/P0/CBUS_BIT6 MB/P0/CBUS_BIT7 MB/P0/CBUS_BIT8 MB/P0/CBUS_BIT9 MB/P0/CBUS_BIT10 MB/P0/CBUS_BIT11 /MB/I_USB0 /MB/VCORE_POK /MB/VMEML_POK /MB/VMEMR_POK /MB/I_USB1 /PS0/AC_POK /PS0/DC_POK /PS0/CUR_FAULT /PS0/VOLT_FAULT /PS1/AC_POK /PS1/DC_POK /PS1/CUR_FAULT /PS1/VOLT_FAULT

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapComponentOk	enterprises.42.2.175.103.2.0.54	MB/P0/CBUS_BIT0 MB/P0/CBUS_BIT1 MB/P0/CBUS_BIT2 MB/P0/CBUS_BIT3 MB/P0/CBUS_BIT4 MB/P0/CBUS_BIT5 MB/P0/CBUS_BIT6 MB/P0/CBUS_BIT7 MB/P0/CBUS_BIT8 MB/P0/CBUS_BIT9 MB/P0/CBUS_BIT10 MB/P0/CBUS_BIT11 /MB/I_USB0 /MB/VCORE_POK /MB/VMEML_POK /MB/VMEMR_POK /MB/I_USB1 /PS0/AC_POK /PS0/DC_POK /PS0/CUR_FAULT /PS0/VOLT_FAULT /PS1/AC_POK /PS1/DC_POK /PS1/CUR_FAULT /PS1/VOLT_FAULT

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

<b>Trap Name</b>	<b>Trap OID</b>	<b>Sensors or Components</b>
sunHwTrapFruInserted	enterprises.42.2.175.103.2.0.55	/MB/XAUI0/PRSNT /MB/XAUI1/PRSNT /B0/CH0/D0/PRSNT /B0/CH0/D1/PRSNT /B0/CH1/D0/PRSNT /B0/CH1/D1/PRSNT /B1/CH0/D0/PRSNT /B1/CH0/D1/PRSNT /B1/CH1/D0/PRSNT /B1/CH1/D1/PRSNT /B2/CH0/D0/PRSNT /B2/CH0/D1/PRSNT /B2/CH1/D0/PRSNT /B2/CH1/D1/PRSNT /B3/CH0/D0/PRSNT /B3/CH0/D1/PRSNT /B3/CH1/D0/PRSNT /B3/CH1/D1/PRSNT /SASBP/PRSNT /PS0/PRSNT /PS1/PRSNT

**TABLE A-3** Sun Netra T5220 Server Traps Corresponding to Sensors and Components in SDR (Continued)

Trap Name	Trap OID	Sensors or Components
sunHwTrapFruRemoved	enterprises.42.2.175.103.2.0.56	/MB/XAUI0/PRSNT /MB/XAUI1/PRSNT /B0/CH0/D0/PRSNT /B0/CH0/D1/PRSNT /B0/CH1/D0/PRSNT /B0/CH1/D1/PRSNT /B1/CH0/D0/PRSNT /B1/CH0/D1/PRSNT /B1/CH1/D0/PRSNT /B1/CH1/D1/PRSNT /B2/CH0/D0/PRSNT /B2/CH0/D1/PRSNT /B2/CH1/D0/PRSNT /B2/CH1/D1/PRSNT /B3/CH0/D0/PRSNT /B3/CH0/D1/PRSNT /B3/CH1/D0/PRSNT /B3/CH1/D1/PRSNT /SASBP/PRSNT /PS0/PRSNT /PS1/PRSNT



## ALOM CMT Compatibility Shell

---

ILOM supports some of the features of the ALOM CMT command-line interface by means of a compatibility shell. There are significant differences between ILOM and ALOM CMT. This appendix describes those differences. This appendix includes the following topics:

- [“Backward Compatibility Limits” on page 47](#)
- [“Creating an ALOM CMT Shell” on page 49](#)
- [“ILOM and ALOM CMT Command Comparison” on page 51](#)
- [“ALOM CMT Variable Comparison” on page 57](#)

---

**Note** – The ALOM compatibility CLI has been provided to aid the transition to ILOM. ILOM is a superset of the features available through the ALOM compatibility CLI.

---

---

## Backward Compatibility Limits

The backward compatibility shell supports some, but not all features of ALOM CMT. Some of the more significant differences between ILOM and ALOM CMT are described here or in the product notes for your server.

# Adding a Commit Step to Procedures That Configure ILOM Network Configuration Properties

When changing the values of some ALOM CMT variables (such as network and serial port configuration variables), it was necessary to reset the system controller before the changes took effect. By comparison, in ILOM it is not necessary to reset the service processor after changing the values of comparable properties. In ILOM, if you change the value of the property and then reset the SP, you will lose the new property setting.

Instead, change the network configuration property then *commit* it using `setsc netsc_commit` in the the ALOM compatibility CLI or `set /SP/network commitpending` using the ILOM CLI. To change the serial port configuration property then commit it using `setsc ser_commit` in the the ALOM compatibility CLI or `set /SP/serial/external commitpending` using the ILOM CLI..

For example, set a static IP address using the ALOM compatiblitiy CLI:

```
sc> setsc netsc_ipaddr xxx.xxx.xxx.xxx
sc> setsc netsc_commit
```

To set the same property using the ILOM CLI:

```
-> set /SP/network pendingipaddress=xxx.xxx.xxx.xxx
Set 'pendingipaddress' to 'xxx.xxx.xxx.xxx'
-> set /SP/network commitpending=true
Set 'commitpending' to 'true'
->
```

In summary, you must *commit* the changes before they can take effect.

**TABLE B-1** ALOM CMT *commit* Variables and Comparable ILOM Properties

ALOM CMT Variable	Comparable ILOM Property
<code>netsc_commit</code>	<code>/SP/network commitpending</code>
<code>ser_commit</code>	<code>/SP/serial/external commitpending</code>

---

# Creating an ALOM CMT Shell

Your server is configured to operate under an ILOM shell, by default. You can create an ALOM compatibility shell if you prefer to use commands that resemble ALOM CMT commands to administer your server.

## ▼ To Create an ALOM CMT Compatibility Shell

### 1. Log onto the service processor with the username: `root`.

When powered on, the SP boots to the ILOM login prompt. The factory default password is `changeme`.

```
SUNSPxxxxxxxxxxx login: root
Password:
Waiting for daemons to initialize...

Daemons ready

Sun(TM) Integrated Lights Out Manager

Version 2.0.0.0

Copyright 2007 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

Warning: password is set to factory default.
```

### 2. Create a user named `admin`, and set the `admin` account role to `Administrator` and the CLI mode to `alom`.

```
-> create /SP/users/admin
Creating user...
Enter new password: *****
Enter new password again: *****
Created /SP/users/admin
-> set /SP/users/admin role=Administrator
Set 'role' to 'Administrator'
-> set /SP/users/admin cli_mode=alom
Set 'cli_mode' to 'alom'
```

---

**Note** – The asterisks in the example will not appear when you enter your password.

---

You can combine the `create` and `set` commands on a single line:

```
-> create /SP/users/admin role=Administrator cli_mode=alom
Creating user...
Enter new password: *****
Enter new password again: *****
Created /SP/users/admin
```

**3. Log out of the root account after you have finished creating the admin account.**

```
-> exit
```

**4. Log in to the ALOM CLI shell (indicated by the `sc>` prompt) from the ILOM login prompt.**

```
SUNSPxxxxxxxxxx login: admin
Password:
Waiting for daemons to initialize...

Daemons ready

Sun(TM) Integrated Lights Out Manager

Version 2.0.0.0

Copyright 2007 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

sc>
```

Using the ALOM CMT compatibility shell (with few exceptions) you can use commands that resemble the commands of ALOM CMT. Remember that the ALOM CMT compatibility shell is an ILOM interface. The comparisons between the ILOM CLI and ALOM CMT compatibility CLI are described in [“ILOM and ALOM CMT Command Comparison” on page 51](#).

# ILOM and ALOM CMT Command Comparison

The following table provides a command-by-command comparison between the command sets of ALOM CMT and the default ILOM CLI command set. Only the supported ALOM CMT command options are listed in [TABLE B-2](#). Where there are ALOM CMT command-line arguments that have no corresponding ILOM properties, those ALOM CMT arguments have been omitted. The command set of the ALOM compatibility shell provides a close approximation of the equivalent commands and arguments (where supported) in ALOM CMT.

**TABLE B-2** ALOM CMT Shell Commands by Function

ALOM CMT Command	Summary	Comparable ILOM Command
<b>Configuration Commands</b>		
<code>password</code>	Changes the login password of the current user.	<code>set /SP/users/username password</code>
<code>restartssh</code>	Restarts the SSH server so that new host keys generated by the <code>ssh-keygen</code> command are reloaded.	<code>set /SP/services/ssh restart_sshd_action=true</code>
<code>setalarm critical major minor user on off</code>	Turns the alarm and associated LED on and off.	<code>set /SYS/ALARM/MINOR value=on</code>
<code>setdate [[mddd]HHMM   mdddHHMM[cc]yy][.SS]</code>	Sets ALOM CMT date and time.	<code>set /SP/clock datetime=value</code>
<code>setdefaults [-a]</code>	Resets all ALOM CMT configuration parameters to their default values. The <code>-a</code> option resets the user information to the factory default (one admin account only).	<code>set /SP reset_to_defaults=all</code>

**TABLE B-2** ALOM CMT Shell Commands by Function (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
setkeyswitch [normal stby diag  locked]	Set the status of the virtual keyswitch. Setting the virtual keyswitch to standby ( <i>stby</i> ) powers off the server. Before powering off the host server, ALOM CMT asks for a confirmation.	set /SYS keyswitch_state= <i>value</i>
setsc [ <i>param</i> ] [ <i>value</i> ]	Sets the specified ALOM CMT parameter to the assigned value.	set <i>target property=value</i>
setupsc	Runs the interactive configuration script. This script configures the ALOM CMT configuration variables.	No equivalent in ILOM
showplatform [-v]	Displays information about the host system's hardware configuration, and whether the hardware is providing service. The -v option displays verbose information about the displayed components.	show /HOST
showfru	Displays information about the field-replaceable units (FRUs) in a host server.	No equivalent in ILOM
showusers [-g <i>lines</i> ]	Displays a list of users currently logged in to ALOM CMT. The display for this command has a similar format to that of the UNIX command <i>who</i> . The -g option pauses the display after the number of lines you specify for <i>lines</i> .	show /SP/sessions
showhost [ <i>version</i> ]	Displays version information for host-side components	show /HOST
showkeyswitch	Displays status of virtual keyswitch.	show /SYS keyswitch_state
showsc [ <i>param</i> ]	Displays the current non-volatile read-only memory (NVRAM) configuration parameters.	show <i>target property</i>

**TABLE B-2** ALOM CMT Shell Commands by Function (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
showdate	Displays the ALOM CMT date. ALOM CMT time is expressed in Coordinated Universal Time (UTC) rather than local time. The Oracle Solaris OS and ALOM CMT time are not synchronized.	show /SP/clock datetime
ssh-keygen -l -t (rsa dsa)	Generates Secure Shell (SSH) host keys and displays the host key fingerprint on the SC.	show /SP/services/ssh/keys/dsa show /SP/services/ssh/keys/rsa
usershow [username]	Displays a list of all user accounts, permission levels, and whether passwords are assigned.	show /SP/users
useradd username	Adds a user account to ALOM CMT.	create /SP/users/username
userdel username	Deletes a user account from ALOM CMT. The -y option enables you to skip the confirmation question.	delete /SP/users/username
userdel -y username		delete -script /SP/users/username
userpassword [username]	Sets or changes a user password.	set /SP/users/username password
userperm [username] [c] [u] [a] [r]	Sets the permission level for a user account.	set /SP/users/username role=permissions (where <i>permissions</i> are Administrator or Operator)
<b>Log Commands</b>		
showlogs [-p logtype [p]]	Displays the history of all events logged in the ALOM CMT RAM event log, or major and critical events in the persistent log. The -p option selects whether to display entries only from the RAM event log ( <i>logtype</i> r) or the persistent event log ( <i>logtype</i> p).	show /SP/logs/event/list
consolehistory [-b lines -e lines -v] [-g lines] [boot run]	Displays the host server console output buffers.	No equivalent in ILOM

**TABLE B-2** ALOM CMT Shell Commands by Function (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
<b>Status and Control Commands</b>		
showenvironment	Displays the environmental status of the host server. This information includes system temperatures, power supply status, front panel LED status, hard disk drive status, fan status, voltage, and current sensor status.	show -o table -level all /SYS
shownetwork [-v]	Displays the current network configuration information. The -v option shows additional information about your network, including information about your DHCP server.	show /SP/network
console [-f]	Connects to the host system console. The -f option forces the console write lock from one user to another.	start /SP/console
break [-c]	Drops the host server from running the Oracle Solaris OS software into OpenBoot PROM or kmdb, depending upon the mode in which the Oracle Solaris software was booted.	set /HOST send_break_action=break
break [-D]		set /HOST send_break_action=dumpcore
bootmode [normal] [reset_nvram] [config=configname] [bootscript=string]	Controls the host server OpenBoot PROM firmware method of booting.	set /HOST/bootmode <i>property=value</i> (where <i>property</i> is state, config, or script)
flashupdate -s <i>IPaddr</i> -f <i>pathname</i> [-v]	Downloads and updates system firmware (both host firmware and ALOM CMT firmware). For ILOM, <i>ipaddr</i> must be a TFTP server. If DHCP is used, <i>ipaddr</i> can be replaced by the name of the TFTP host.	load -source tftp:// <i>ipaddr/pathname</i>
reset [-c]	Attempts to gracefully reset the system. If that fails this option forcefully resets the system.	reset /SYS
reset [-y] [-c]		reset -script /SYS
reset -f	Forcefully resets the system	reset -f /SYS

**TABLE B-2** ALOM CMT Shell Commands by Function (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
<code>reset -d</code>	Attempts to gracefully reset the control domain. If that fails, this option forcefully resets the control domain.	<code>reset /HOST/domain/control</code>
<code>reset [-d] [-f]</code>	Forcefully resets the control domain.	<code>reset -f /HOST/domain/control</code>
<code>reset [-d] [-n]</code>	When resetting the control domain, this option may automatically boot, this is default behavior when the <code>auto-boot</code> option is not specified.	<code>set /HOST/domain/control auto-boot=disable</code> <code>reset /HOST/domain/control</code>
<code>reset [-d] [-f] [-n]</code>	When resetting the control domain, this option does not automatically boot and stays at the OpenBoot <code>ok</code> prompt. This option overrides all reboot variables and stops the control domain at the OpenBoot <code>ok</code> prompt after host reset. The <code>auto-boot?</code> option remains unchanged, thus subsequent <code>reset</code> commands automatically reboot host if the <code>auto-boot?</code> option is set to <code>true</code> .	<code>set /HOST/domain/control auto-boot=disable</code> <code>reset -f /HOST/domain/control</code>
<code>powercycle [-y] [-f]</code>	<code>poweroff</code> followed by <code>poweron</code> . The <code>-f</code> option forces an immediate <code>poweroff</code> , otherwise the command attempts a graceful shutdown.	<code>stop /SYS</code> <code>start /SYS</code>
<code>powercycle -y</code>		<code>stop -script /SYS</code>
<code>powercycle -f</code>		<code>start -script /SYS</code> <code>stop -force /SYS</code> <code>start -force /SYS</code>
<code>poweroff</code>	Removes the main power from the host server. The <code>-y</code> option enables you to skip the confirmation question. ALOM CMT attempts to shut the server down gracefully. The <code>-f</code> option forces an immediate shutdown.	<code>stop /SYS</code>
<code>poweroff -y</code>		<code>stop -script /SYS</code>
<code>poweroff -f</code>		<code>stop -force /SYS</code>
<code>poweron</code>	Applies the main power to the host server or FRU.	<code>start /SYS</code>

**TABLE B-2** ALOM CMT Shell Commands by Function (*Continued*)

<b>ALOM CMT Command</b>	<b>Summary</b>	<b>Comparable ILOM Command</b>
setlocator [on/off]	Turns the Locator LED on the server on or off.	set /SYS/LOCATE value= <i>value</i>
showfaults [-v]	Displays current valid system faults.	show /SP/faultmgmt
clearfault <i>UUID</i>	Manually repairs system faults.	set /SYS/ <i>component</i> clear_fault_action=true
showlocator	Displays the current state of the Locator LED as either on or off.	show /SYS/LOCATE
<b>FRU Commands</b>		
setfru -c <i>data</i>	The -c option enables you to store information (such as inventory codes) on all FRUs in a system.	set /SP customer_frudata= <i>data</i>
showfru [-g lines] [-s -d] [ <i>FRU</i> ]	Displays information about the FRUs in a host server.	No equivalent in ILOM
removefru [-y] [ <i>FRU</i> ]	Prepares a FRU (for example, a power supply) for removal. The -y option enables you to skip the confirmation question.	set /SYS/PS0 prepare_to_remove_action=true
<b>Automatic System Recovery (ASR) Commands</b>		
enablecomponent <i>asr-key</i>	Removes a component from the asr-db blacklist.	set /SYS/ <i>component</i> component_state=enabled
disablecomponent <i>asr-key</i>	Adds a component to the asr-db blacklist.	set /SYS/ <i>component</i> component_state=disabled
showcomponent <i>asr-key</i>	Displays system components and their test status (ASR state).	show /SYS/ <i>component</i> component_state
clearasrdb	Removes all entries from the asr-db blacklist.	No equivalent in ILOM
<b>Other Commands</b>		

**TABLE B-2** ALOM CMT Shell Commands by Function (*Continued*)

ALOM CMT Command	Summary	Comparable ILOM Command
help [ <i>command</i> ]	Displays a list of all ALOM CMT commands with their syntax and a brief description of how each command works. Specifying a command name as an option enables you to view the help for that command.	help
resetsc	Reboots ALOM CMT. The <code>-y</code> option enables you to skip the confirmation question.	reset /SP
resetsc -y		reset -script /SP
userclimode	Sets the type of shell to <i>shelltype</i> , where <i>shelltype</i> is default or alom.	set /SP/users/username cli_mode= <i>shelltype</i>
logout	Logs out from an ALOM CMT shell session.	exit

## ALOM CMT Variable Comparison

The following table displays ALOM CMT variables and the ILOM properties to which they can be compared. The comparison does not imply a one-to-one mapping. To understand the ILOM properties it is necessary to view them in their own context, ILOM.

**TABLE B-3** ALOM CMT Variables and Comparable ILOM Properties

ALOM CMT Variable	Comparable ILOM Property
diag_level	/HOST/diag level
diag_mode	/HOST/diag mode
diag_trigger	/HOST/diag trigger
diag_verbosity	/HOST/diag verbosity
if_connection	/SP/services/ssh state
if_emailalerts	/SP/clients/smtp state
if_network	/SP/network state
if_snmp	/SP/services/snmp

**TABLE B-3** ALOM CMT Variables and Comparable ILOM Properties *(Continued)*

<b>ALOM CMT Variable</b>	<b>Comparable ILOM Property</b>
mgt_mailalert	/SP/alertmgmt/rules
mgt_mailhost	/SP/clients/smtp address
mgt_snmptraps	/SP/services/snmp v1 v2c v3
mgt_traphost	/SP/alertmgmt/rules /SP/services/snmp port
netsc_dhcp	/SP/network pendingipdiscovery
netsc_commit	/SP/network commitpending
netsc_enetaddr	/SP/network macaddress
netsc_ipaddr	/SP/network pendingipaddress
netsc_ipgateway	/SP/network pendingipgateway
netsc_ipnetmask	/SP/network pendingipnetmask
sc_backupuserdata	/SP/policy BACKUP_USER_DATA
sc_clieventlevel	N/A
sc_cliprompt	N/A
sc_clitimeout	N/A
sc_clipasswdecho	N/A
sc_customerinfo	/SP system_identifier
sc_escapechars	/SP/console escapechars
sc_powerondelay	/SP/policy HOST_POWER_ON_DELAY
sc_powerstatememory	/SP/policy HOST_LAST_POWER_STATE
ser_baudrate	/SP/serial/external pendingspeed
ser_data	N/A
ser_parity	/SP/serial/external pendingparity
ser_stopbits	/SP/serial/external pendingstopbits
sys_autorestart	/SP autorestart
sys_autorunonerror	/SP autorunonerror
sys_eventlevel	N/A
sys_enetaddr	/HOST macaddress

# Index

---

## Symbols

/HOST autorestart property, 9  
/HOST autorunonerror property, 9  
/HOST macaddress property, 8  
/HOST send\_break\_action property, 15  
/HOST status property, 15  
/HOST/bootmode config property, 5  
/HOST/bootmode expires property, 6  
/HOST/bootmode script property, 5  
/HOST/bootmode state property, 6  
/HOST/diag level property, 11  
/HOST/diag mode property, 12  
/HOST/diag trigger property, 12  
/HOST/diag verbosity property, 13  
/SP customer\_fru data property, 17  
/SP reset\_to\_defaults property, 19  
/SP system\_identifier property, 18  
/SP/console escapechars property, 21  
/SP/policy BACKUP\_USER\_DATA property, 21  
/SP/policy HOST\_LAST\_POWER\_STATE property, 22  
/SP/policy HOST\_POWER\_ON\_DELAY property, 23  
/SP/services/ssh generate\_new\_key\_action property, 24  
/SP/services/ssh generate\_new\_key\_type property, 24  
/SP/services/ssh restart\_sshd\_action property, 25  
/SP/services/ssh state property, 25

/SYS keyswitch\_state property, 29

## A

### ALOM

commands  
setalarm, 51

## B

backing up user data, 21

boot mode

about, 4  
managing configuration, 5  
managing reset, 6  
managing script, 5

## D

defaults, resetting, 19

## F

factory defaults, 19

## I

### ILOM properties

/HOST autorestart, 9  
/HOST autorunonerror, 9  
/HOST macaddress, 8  
/HOST send\_break\_action, 15  
/HOST status, 15  
/HOST/bootmode config, 5  
/HOST/bootmode expires, 6  
/HOST/bootmode script, 5  
/HOST/bootmode state, 6

- /HOST/diag level, 11
- /HOST/diag mode, 12
- /HOST/diag trigger, 12
- /HOST/diag verbosity, 13
- /SP customer\_fru\_data, 17
- /SP reset\_to\_defaults, 19
- /SP system\_identifier, 18
- /SP/console escapechars, 21
- /SP/policy BACKUP\_USER\_DATA, 21
- /SP/policy HOST\_LAST\_POWER\_STATE, 22
- /SP/policy HOST\_POWER\_ON\_DELAY, 23
- /SP/services/ssh
  - generate\_new\_key\_action, 24
- /SP/services/ssh
  - generate\_new\_key\_type, 24
- /SP/services/ssh restart\_sshd\_action, 25
- /SP/services/ssh state, 25
- /SYS keyswitch\_state, 29

## **M**

- memory of power state, 22

## **P**

- platform, showing, 15
- power state, 22
- property
  - backup data, 21
  - memory of power state, 22
  - system user, 15

## **R**

- remote control settings
  - changing with the CLI, 4
  - changing with the web interface, 7

## **S**

- server
  - platform information, 15
- setalarm (ALOM command), 51

## **T**

- timer, watchdog, 9

## **W**

- watchdog timer, 9