



Platform Notes: The Sun GigabitEthernet Device Driver

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, CA 94303-4900 U.S.A.
650-960-1300

Part No. 806-7745-10
April 2001, Revision A

Send comments about this document to: docfeedback@sun.com

Copyright 2001 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, CA 94303-4900 U.S.A. All rights reserved.

This product or document is distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, AnswerBook2, docs.sun.com, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

Federal Acquisitions: Commercial Software—Government Users Subject to Standard License Terms and Conditions.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2001 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, CA 94303-4900 Etats-Unis. Tous droits réservés.

Ce produit ou document est distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, AnswerBook2, docs.sun.com, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.



Adobe PostScript

Contents

- 1. Configuring the `ge` Device Driver 1**
 - Configuring the Driver Parameters 1
 - Setting `ge` Driver Parameters 8
 - Network Configuration 14
 - ▼ To Configure the Host Files 14
 - Installing the Solaris Operating Environment Over a GigabitEthernet Network 16
 - ▼ To Install the Solaris Environment Over a GigabitEthernet Network 17

Preface

These Platform Notes provide instructions for configuring the software used by the Sun GigabitEthernet adapter. They also contain information for configuring the network. Unless otherwise noted, all instructions apply to both the Sun GigabitEthernet/P adapter and the Sun GigabitEthernet/S adapter.

Shell Prompts

Shell	Prompt
C shell	<i>machine_name%</i>
C shell superuser	<i>machine_name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

Typographic Conventions

Typeface or Symbol	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
AaBbCc123	What you type, when contrasted with on-screen computer output	% su Password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this.
	Command-line variable; replace with a real name or value	To delete a file, type <code>rm filename</code> .

Related Documentation

TABLE P-1 Related Documentation

Title	Part Number
Solaris 8 System Administration Guide, Volume 3	806-0916-10
Solaris 8 Sun Hardware Platform Guide	806-2221-10

Ordering Sun Documentation

Fatbrain.com, an Internet professional bookstore, stocks select product documentation from Sun Microsystems, Inc.

For a list of documents and how to order them, visit the Sun Documentation Center on Fatbrain.com at:

<http://www.fatbrain.com/documentation/sun>

Accessing Sun Documentation Online

The docs.sun.comSM web site enables you to access Sun technical documentation on the Web. You can browse the docs.sun.com archive or search for a specific book title or subject at:

<http://docs.sun.com>

Sun Welcomes Your Comments

We are interested in improving our documentation and welcome your comments and suggestions. You can email your comments to us at:

docfeedback@sun.com

Please include the part number (806-7745-10) of your document in the subject line of your email.

Configuring the `ge` Device Driver

These Platform Notes provide instructions for configuring the software used by the Sun GigabitEthernet adapter. They also contain information for configuring the network. Unless otherwise noted, all instructions apply to both the Sun GigabitEthernet/P adapter and the Sun GigabitEthernet/S adapter.

The document contains the following sections:

- Configuring the Driver Parameters
- Setting `ge` Driver Parameters
- Network Configuration

Configuring the Driver Parameters

This section provides an overview of the capabilities of the GigabitEthernet ASIC used in the adapters, lists the available `ge` driver parameters, and describes how to configure these parameters.

The `ge` driver controls the Sun GigabitEthernet adapter devices. The Sun GigabitEthernet device is identified as `network` with the model property `SUNW,sbus-gem` or `SUNW,pci-gem` node. The `ge` driver is attached to the device with the compatible property `pci108e,2bad` for the Sun GigabitEthernet/P adapter or `SUNW,sbus-gem` for the Sun GigabitEthernet/S adapter. You can manually configure the parameters to customize each Sun GigabitEthernet adapter in your system.

GigabitEthernet MAC

The GigabitEthernet MAC (GEM) provides 1000BASE-SX networking interfaces. The driver automatically sets the link speed to 1000 Mbps and conforms to the IEEE 802.3z Ethernet standard. The GEM PCI ASIC provide the PCI interface, Media Access Control (MAC) functions, and Physical Code Sublayer (PCS) functions. The GEM SBus ASIC provides the SBus interface, MAC functions, and PCS functions. The External SERDES, which connects the 1000BASE-SX Compliant SC connector to the ASIC, provides the physical layer functions.

The GEM MAC and PCS are capable of all the operating speeds and modes listed in “Autonegotiation Mode” on page 11. The PCS performs autonegotiation with the remote end of the link (link partner) to select a common mode of operation.

The PCS also supports a forced mode of operation. You can select the speed and mode by creating a `ge.conf` file.

Driver Parameter Values and Definitions

TABLE 1-1 describes the parameters and settings for the `ge` driver.

TABLE 1-1 `ge` Driver Parameters, Status, and Descriptions

Parameter	Status	Description
<code>link_status</code>	Read only	Defines the current status
<code>link_speed</code>	Read only	Defines the current status
<code>link_mode</code>	Read only	Defines the current status
<code>ipg1</code>	Read and write	Interpacket gap parameter
<code>ipg2</code>	Read and write	Interpacket gap parameter
<code>instance</code>	Read and write	Device instance
<code>lance_mode</code>	Read and write	Enable additional delay before transmitting a packet
<code>ipg0</code>	Read and write	Additional delay before transmitting a packet
<code>adv_1000autoneg_cap</code>	Read and write	Operational mode parameter
<code>adv_1000fdx_cap</code>	Read and write	Operational mode parameter
<code>adv_1000hdx_cap</code>	Read and write	Operational mode parameter
<code>adv_pauseTX</code>	Read and write	Operational mode parameter
<code>adv_pauseRX</code>	Read and write	Operational mode parameter

TABLE 1-1 ge Driver Parameters, Status, and Descriptions (Continued)

Parameter	Status	Description
1000autoneg_cap	Read only	PCS autonegotiation capability
1000fdx_cap	Read only	PCS full duplex capability
1000hdx_cap	Read only	PCS half duplex capability
asm_dir_cap	Read only	PCS ASM_DIR capability
pause_cap	Read only	PCS Symmetric PAUSE capability
lp_1000autoneg_cap	Read only	Link partner autonegotiation capability
lp_1000fdx_cap	Read only	Link partner capability
lp_1000hdx_cap	Read only	Link partner capability
lp_asm_dir_cap	Read only	Link partner capability
lp_pause_cap	Read only	Link partner capability

Defining the Current Status

The read-only parameters described in TABLE 1-2 explain the operational mode of the interface. Based on the value of these parameters, you can determine the current status of a link.

TABLE 1-2 Read-Only Parameters Defining the Current Status

Parameter	Values and Description
link_status	Current link status 0 = Link down 1 = Link up
link_speed	Valid only if the link is up 0 = Link is not up 1000 = 1000 Mbps
link_mode	Valid only if the link is up 0 = Half duplex 1 = Full duplex

Flow Control Parameters

The GEM ASIC is capable of sourcing (transmitting) and terminating (receiving) pause frames conforming to IEEE 802.3x Frame Based Link Level Flow Control Protocol. In response to received flow control frames, the GEM can slow down its transmit rate. On the other hand, GEM is capable of sourcing flow control frames, requesting the link partner to slow down, provided that the link partner supports this feature. By default, GEM advertises Receive PAUSE capability during autonegotiation.

TABLE 1-3 Read-Write Flow Control Parameters Values and Descriptions

Parameter	Values and Description
adv_pauseTX	Transmit PAUSE Capable 0=Off (default: not capable) 1=On
adv_pauseRX	Receive PAUSE Capable 0=Off 1=On (default: capable)

For normal operations, GEM doesn't need to source flow control frames. However, if GEM is operating on a slow bus (for instance, a 33-MHz PCI bus slot), and there is a lot of frame reception activity, there could be a performance degradation due to Receive FIFO overflow. If the link partner is capable of terminating PAUSE flow control frames, the performance of GEM could be improved by enabling adv_pauseTX and restarting autonegotiation.

Interpacket Gap Parameters

The GEM ASIC supports the programmable Interpacket Gap (IPG) parameters `ipg1` and `ipg2`. The total IPG is the sum of `ipg1` and `ipg2`: 0.096 microseconds for the link speed of 1000 Mbps.

TABLE 1-4 lists the default values and allowable values for the IPG parameters, `ipg1` and `ipg2`.

TABLE 1-4 Read-Write Interpacket Gap Parameter Values and Descriptions

Parameter	Values (Byte-time)	Description
ipg1	0, 255	ipg1 = 8 (default at initialization)
ipg2	0, 255	ipg2 = 4 (default at initialization)

By default, the driver sets `ipg1` to 8-byte time and `ipg2` to 4-byte time, which are the standard values. (Byte time is the time it takes to transmit one byte on the link, with a link speed of 1000 Mbps.)

If your network has systems that use longer IPG (the sum of `ipg1` and `ipg2`) and if those machines seem to be slow in accessing the network, increase the values of `ipg1` and `ipg2` to match the longer IPGs of other machines.

Defining an Additional Delay Before Transmitting a Packet Using `lance_mode` and `ipg0`

The GEM ASIC supports a programmable mode called `lance_mode`. The `ipg0` parameter is associated with `lance_mode`.

If `lance_mode` is enabled (the default), an additional delay is added by setting the `ipg0` parameter before transmitting the packet. This delay is in addition to the delay set by the `ipg1` and `ipg2` parameters. The additional delay set by `ipg0` helps to reduce collisions. Systems that have `lance_mode` enabled might not have enough transmission time on the network.

If `lance_mode` is disabled, the value of `ipg0` is ignored and no additional delay is set. Only the delays set by `ipg1` and `ipg2` are used. Disable `lance_mode` if other systems keep sending a large number of back-to-back packets.

You can add the additional delay by setting the `ipg0` parameter from 0 to 31, which is the media byte time delay.

TABLE 1-5 defines the `lance_mode` and `ipg0` parameters.

TABLE 1-5 Parameters Defining `lance_mode` and `ipg0`

Parameter	Values and Descriptions
<code>lance_mode</code>	0 = <code>lance_mode</code> disabled 1 = <code>lance_mode</code> enabled (default)
<code>ipg0</code>	0 to 30 = Additional IPG before transmitting a packet (after receiving a packet)

Operational Mode Parameters

TABLE 1-6 describes the operational mode parameters and their default values.

TABLE 1-6 Operational Mode Parameters

Parameter	Values and Description
adv_1000autoneg_cap	Local PCS capability advertised by the hardware 0 = Forced mode 1 = Autonegotiation (default)
adv_1000fdx_cap	Local PCS capability advertised by the hardware 0 = Not 1000 Mbits/sec full duplex capable 1 = 1000 Mbits/sec full duplex capable (default)
adv_1000hdx_cap	Local PCS capability advertised by the hardware 0 = Not 1000 Mbits/sec half duplex capable 1 = 1000 Mbits/sec half duplex capable (default)
adv_pauseTX	Local PCS capability advertised by the hardware 0 = Not Pause TX capable (default) 1 = Pause TX capable
adv_pauseRX	Local PCS capability advertised by the hardware 0 = Not Pause RX capable 1 = Pause RX capable (default)

Reporting Local PCS Capabilities

TABLE 1-7 describes the read-only PCS capabilities that GEM PCS supports. These parameters define the capabilities of the hardware.

TABLE 1-7 Read-Only PCS Capabilities

Parameter	Description (Local PCS Capabilities)
1000autoneg_cap	0 = Not capable of autonegotiation 1 = Autonegotiation capable
1000fdx_cap	Local PCS Full Duplex capability 0 = Not 1000 Mbits/sec full-duplex capable 1 = 1000 Mbits/sec full-duplex capable

TABLE 1-7 Read-Only PCS Capabilities

Parameter	Description (Local PCS Capabilities)
1000hdx_cap	Local PCS Half Duplex capability 0 = Not 1000 Mbits/sec half-duplex capable 1 = 1000 Mbits/sec half-duplex capable
asm_dir_cap	Local PCS Flow Control capability 0 = Not Asymmetric Pause capable 1 = Asymmetric Pause (from Local Device) capable
pause_cap	Local PCS Flow Control capability 0 = Not Symmetric Pause capable 1 = Symmetric Pause capable

Reporting the Link Partner Capabilities

TABLE 1-8 describes the read-only link partner capabilities.

TABLE 1-8 Read-Only Link Partner Capabilities

Parameter	Values and Description
lp_1000autoneg_cap	0 = No autonegotiation 1 = Autonegotiation
lp_1000fdx_cap	0 = No 1000 Mbits/sec full duplex transmission 1 = 1000 Mbits/sec full duplex
lp_1000hdx_cap	0 = No 1000 Mbits/sec half duplex transmission 1 = 1000 Mbits/sec half duplex
lp_asm_dir_cap	0 = Not Asymmetric Pause capable 1 = Asymmetric Pause toward link partner capability
lp_pause_cap	0 = Not Symmetric Pause capable 1 = Symmetric Pause capable

If the link partner is not capable of autonegotiation (when `lp_1000autoneg_cap` is 0), the remaining information described in TABLE 1-8 is not relevant and the parameter value equals 0.

If the link partner is capable of autonegotiation (when `lp_1000autoneg_cap` is 1), the speed and mode information is displayed when you use autonegotiation and get the link partner capabilities.

Setting `ge` Driver Parameters

You can set the `ge` driver parameters in two ways, depending on your needs:

- Using the `ndd` utility
- Using the `ge.conf` file

Use the `ndd` utility to set parameters that are valid until you reboot the system. It is also a good way to test parameter settings.

Use the `ge.conf` file to set parameters so they remain in effect after you reboot the system. Create a `/kernel/drv/ge.conf` file and add parameter values to this file when you need to set a particular parameter for a device in the system.

Setting Parameters Using the `ndd` Utility

Use the `ndd` utility to configure parameters that are valid until you reboot the system. The `ndd` utility supports any networking driver that implements the Data Link Provider Interface (DLPI).

The following sections describe how you can use the `ge` driver and the `ndd` utility to modify (with the `-set` option) or display (without the `-set` option) the parameters for each `ge` device.

▼ To Specify the Device Instance for the `ndd` Utility

Before you use the `ndd` utility to get or set a parameter for a `ge` device, you must specify the device instance for the utility.

1. Check the `/etc/path_to_inst` file to identify the instance associated with a particular device.

For Sun GigabitEthernet/P:

```
# grep ge /etc/path_to_inst
"/pci@4,4000/network@4" 2 "ge"
"/pci@6,2000/network@1" 1 "ge"
"/pci@4,2000/network@1" 0 "ge"
```

In this example, the three GigabitEthernet instances are from the adapters installed in perspective PCI slots.

For Sun GigabitEthernet/S:

```
# grep ge /etc/path_to_inst
"/sbus@b,0/network@2,100000" 0 "ge"
```

In this example, the GigabitEthernet instance is from an adapter installed in a perspective SBus slot.

2. Use the instance number to select the device.

```
# ndd -set /dev/ge instance instance_number
```

The device remains selected until you change the selection.

Non-Interactive and Interactive Modes

You can use the `ndd` utility in two modes:

- Non-interactive
- Interactive

In the non-interactive mode, you invoke the utility to execute a specific command. Once the command is executed, you exit the utility. In the interactive mode, you can use the utility to get or set more than one parameter value. (Refer to the `ndd (1M)` man page for more information.)

▼ To Use the `ndd` Utility in Non-Interactive Mode

This section describes how to modify and to display parameter values.

1. To modify a parameter value, use the `-set` option.

If you invoke the `ndd` utility with the `-set` option, the utility passes *value*, which must be specified down to the named `/dev/ge` driver instance, and assigns it to the parameter:

```
# ndd -set /dev/ge parameter value
```

2. To display the value of a parameter, specify the parameter name (and omit the value).

When you omit the `-set` option, a query operation is assumed and the utility queries the named driver instance, retrieves the value associated with the specified parameter, and prints it:

```
# ndd /dev/ge parameter
```

▼ To Use the `ndd` Utility in Interactive Mode

1. To modify a parameter value in the interactive mode, specify `ndd /dev/ge`, as shown below.

The `ndd` utility then prompts you for the name of the parameter:

```
# ndd /dev/ge
name to get/set? (Enter the parameter name or ? to view all
parameters)
```

▼ To View the `ge` Driver Parameters

After entering the parameter name, the `ndd` utility prompts you for the parameter value (see TABLE 1-1 through TABLE 1-8).

1. To list all the parameters supported by the `ge` driver, type `ndd /dev/ge \?`.
(See TABLE 1-1 through TABLE 1-8 for parameter descriptions.)

```
# ndd /dev/ge \?
?                (read only)
link_status      (read only)
link_speed       (read only)
link_mode        (read only)
ipg1             (read and write)
ipg2             (read and write)
instance         (read and write)
lance_mode       (read and write)
ipg0             (read and write)
adv_1000autoneg_cap (read and write)
adv_1000fdx_cap  (read and write)
adv_1000hdx_cap  (read and write)
adv_pauseTX     (read and write)
adv_pauseRX     (read and write)
1000autoneg_cap (read only)
1000fdx_cap     (read only)
1000hdx_cap     (read only)
asm_dir_cap     (read only)
pause_cap       (read only)
lp_1000autoneg_cap (read only)
lp_1000fdx_cap (read only)
lp_1000hdx_cap (read only)
lp_asm_dir_cap  (read only)
lp_pause_cap    (read only)
#
```

Autonegotiation Mode

By default, autonegotiation is set to `on`. This means that the adapter will communicate with its link partner to determine a compatible network speed, duplex mode, and flow control capability.

If your network equipment does not support autonegotiation, or if you want to specify your network speed, you can set autonegotiation to `off` on the `ge` device.

▼ To Set Autonegotiation to Off (Forced Mode)

1. **Select the following parameters:** `adv_1000fdx_cap`, `adv_1000hdx_cap`, `adv_pauseTX` and `adv_pauseRX`, and set those values according to the user's manual that shipped with your link partner device (for example, switch). See TABLE 1-6 for parameter values.

2. Set `adv_1000autoneg_cap` to 0.

Setting Parameters Using the `ge.conf` File

You can also specify the properties described in this section on a per-device basis by creating a `ge.conf` file in the `/kernel/drv` directory. Use a `ge.conf` file when you need to set a particular parameter for a device in the system. The parameters you set are read and write parameters that are listed in “Driver Parameter Values and Definitions” on page 2.

The man pages for `prtconf (1M)` and `driver.conf (4)` include additional details.

Understanding the `ge.conf` File

1. Obtain the hardware path names for the `ge` devices in the device tree.

Typically the path names and the associated instance numbers will be present in the `/etc/path_to_inst` file.

```
# grep ge /etc/path_to_inst
"/sbus@b,0/network@2,100000" 0 "ge"
```

- where:
 - `"/sbus@b,0/network@2,100000"` specifies the hardware node name in the device tree.
 - `"0"` is the instance number.
 - `"ge"` is the driver name.
- In the device path name, the last component after the last `/` character and before the `@` character (`network`) is the device name.
- The path name before the last component (`sbus@b,0`) is the parent name.

For Sun GigabitEthernet/S:

To identify an SBus device unambiguously in the `ge.conf` file, use the name and parent name of the device. Refer to the `sbus(4)` man page for more information about the SBus device specification.

In the previous example:

- Name = `SUNW,sbus-gem`
- Class = `"sbus"`

Note – The “name” property in the `ge.conf` file should be the same value as the “compatible” property. In this case, the value is `SUNW,sbus-gem`.

For Sun GigabitEthernet/P:

To identify a PCI device unambiguously in the `ge.conf` file, use the name, parent name, and the unit-address for the device. Refer to the `pci(4)` man page for more information about the PCI device specification.

In the first line of the previous example:

- Name = `pci108e,2bad`
- Parent = `/pci@4,4000`
- Unit-address = 4

In the second line in the previous example:

- Name = `pci108e,2bad`
- Parent = `/pci@6,2000`
- Unit-address = 1

In the third line in the previous example:

- Name = `pci108e,2bad`
- Parent = `/pci@4,2000`
- Unit-address = 1

▼ To Set Parameters Using the `ge.conf` File on an SBus adapter

1. **Set the `ipg1` and `ipg2` parameters for the above devices in the `kernel/drv/ge.conf` file.**

```
name = "SUNW,sbus-gem" class = "sbus"
reg=0x2,0x100000,0x14,0x2,0x200000,0x9060 ipg1=20 ipg2=10 ;
```

2. **Save the `ge.conf` file.**
3. **Save and close all files and programs, and exit the windowing system.**
4. **If your system doesn't support DR, reboot by typing the `init 6` command at the superuser prompt.**

▼ To Set Parameters Using the `ge.conf` File on a PCI adapter

1. Set the `ipg1` and `ipg2` parameters for the above devices in the `kernel/drv/ge.conf` file.

```
name="pci108e,2bad" parent="/pci@4,4000" unit-address="4" ipg1=20 ipg2=10;  
name="pci108e,2bad" parent="/pci@6,2000" unit-address="1" ipg1=20 ipg2=10;  
name="pci108e,2bad" parent="/pci@4,2000" unit-address="1" ipg1=20 ipg2=10;
```

2. Save the `ge.conf` file.
3. Save and close all files and programs, and exit the windowing system.
4. Halt and reboot the system by typing the `init 6` command at the superuser prompt.

Network Configuration

This section describes how to configure the driver after it has been installed on your system.

▼ To Configure the Host Files

After installing the Sun GigabitEthernet adapter driver software, you must create a file for the adapter's Ethernet interface. You must also create both an IP address and a host name for the Ethernet interface in the `/etc/hosts` file.

1. **At the command line, use the `grep` command to search the `/etc/path_to_inst` file for `ge` interfaces.**

For Sun GigabitEthernet/P:

The following example shows the device instance from an adapter installed in slot 1.

```
# grep ge /etc/path_to_inst
"/pci@1f,4000/network@1" 0 "ge"
```

For Sun GigabitEthernet/S:

The following example shows the device instance from an adapter installed in slot 0.

```
# grep ge /etc/path_to_inst
"/sbus@1f,0/network@1" 0 "ge"
```

2. **Create an `/etc/hostname.ge<num>` file, where `num` is the instance number of the `ge` interface you plan to use.**

If you wanted to use the adapter's `ge` interface in the Step 1 example, you would need to create a `/etc/hostname.ge0` file, where 0 is the number of the `ge` interface. If the instance number were 1, the file name would be `/etc/hostname.ge1`.

- Do not create an `/etc/hostname.genum` file for a Sun GigabitEthernet adapter interface you plan to leave unused.
- The `/etc/hostname.genum` file must contain the host name for the appropriate `ge` interface.
- The host name should have an IP address and should be entered in the `/etc/hosts` file.
- The host name should be different from any other host name of any other interface: for example, `/etc/hostname.ge0` and `/etc/hostname.ge1` cannot share the same host name.

The following example shows the `/etc/hostname.genum` file required for a system called `zardoz` that has a Sun GigabitEthernet adapter (`zardoz-11`).

```
# cat /etc/hostname.ge0
zardoz
# cat /etc/hostname.ge1
zardoz-11
```

3. Create an appropriate entry in the `/etc/hosts` file for each active `ge` interface.

For example:

```
# cat /etc/hosts
#
# Internet host table
#
127.0.0.1    localhost
129.144.10.57 zardoz    loghost
129.144.11.83 zardoz-11
```

Note – The Internet Protocol, version 6 (IPv6), expands the capabilities of IPv4, which is the current version and the default. The GigabitEthernet device driver included in this release of the Solaris operating environment supports both IPv4 and IPv6. IPv4 uses the `/etc/hosts` configuration file, but IPv6 uses a different configuration file. To transition to, manage, and implement IPv6, refer to the Solaris 8 System Administration Guide, Volume 3.

4. If your system does not support Dynamic Reconfiguration (DR), reboot.

Installing the Solaris Operating Environment Over a GigabitEthernet Network

The *Solaris Advanced Installation Guide* describes the full procedure for installing the Solaris operating environment over the network. The procedure below assumes that you have an install server, which contains the image of the Solaris Operating Environment, and that you have set up the client system to be upgraded over the network.

Before you can install the Solaris operating environment on a client system with a GigabitEthernet adapter, you must first add the GigabitEthernet software packages to the install server. These software packages can be found on Solaris CD.

Note – Refer to the *Solaris Advanced Installation Guide* for more information about installing the Solaris operating environment over the network.

▼ To Install the Solaris Environment Over a GigabitEthernet Network

1. Prepare the install server and client system to install the Solaris operating environment over the network.

The *Solaris Advanced Installation Guide* describes how to create the install server and set up the client systems.

Note – If you want to install the client system over a network that is not part of the same subnet, you must also create a boot server. The *Solaris Advanced Installation Guide* describes how to create a boot server.

2. Find the root directory of the client system.

The client system's root directory can be found in the install server's `/etc/bootparams` file. Use the `grep` command to search this file for the root directory.

```
# grep client_name /etc/bootparams
client_name root=server_name:/netinstall/Solaris_8/Tools/Boot
install=server_name:/netinstall boottype=:in rootopts=:rsize=32768
```

In the example above, the root directory for the client is `/netinstall`.

Note – If the root directory is not found in the `/etc/bootparams` file, refer to the *Solaris Advanced Installation Guide* for configuration instructions.

3. If the client system is not already displaying the OpenBoot (ok) prompt, shut down and halt the client system.

Use the `shutdown(1M)` command to display the OpenBoot (ok) prompt.

```
# shutdown -i0 -g0 -y
. . .
(shutdown command messages omitted)
. . .
ok
```

4. At the `ok` prompt, use the `show-nets` command to find the device path of the GigabitEthernet device.

The `show-nets` command lists the system devices. You should see the full path name of the network device, similar to the examples below.

For Sun GigabitEthernet/P:

```
ok show-nets
a) /pci@1f,0/pci@1/network@3
b) /pci@1f,0/pci@1,1/network@1,1
q) NO SELECTION
Enter Selection, q to quit:
```

For Sun GigabitEthernet/S:

```
ok show-nets
a) /sbus@1f,0/network@1,100000
b) /sbus@1f,0/SUNW,hme@e,8c00000
q) NO SELECTION
Enter Selection, q to quit:
```

5. At the `ok` prompt, boot the client system using the full device path of the GigabitEthernet device.

Use the full device path name of the `network` device, similar to the examples below.

For Sun GigabitEthernet/P:

```
ok boot /pci@1f,0/pci@1/network@3
```

For Sun GigabitEthernet/S:

```
ok boot /sbus@1f,0/network@1,100000
```

6. Proceed with the Solaris operating environment installation.

Refer to the *Solaris Advanced Installation Guide* for more information about installing the Solaris operating environment over the network.

7. Confirm that the network host files have been configured correctly during the Solaris installation.

Although the Solaris software installation creates the client's hosts files, you may need to edit these files to match your specific networking environment. See "To Configure the Host Files" on page 14 for more information about editing these files.

Note – The Internet Protocol, version 6 (IPv6), expands the capabilities of IPv4, which is the current version and the default. The GigabitEthernet device driver included in this release of the Solaris operating environment supports both IPv4 and IPv6. IPv4 uses the `/etc/hosts` configuration file, but IPv6 uses a different configuration file. To transition to, manage, and implement IPv6, refer to the Solaris 8 System Administration Guide, Volume 3.
