



Sun™ Integrated Lights Out Manager 3.0 Supplement for Sun Fire X4540 Server

Sun Microsystems, Inc.
www.sun.com

Part No. 820-5549-12
February 2010, Revision A

Submit comments about this document by clicking the Feedback[+] link at: <http://docs.sun.com>

Copyright © 2010 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

Unpublished - rights reserved under the Copyright Laws of the United States.

THIS PRODUCT CONTAINS CONFIDENTIAL INFORMATION AND TRADE SECRETS OF SUN MICROSYSTEMS, INC. USE, DISCLOSURE OR REPRODUCTION IS PROHIBITED WITHOUT THE PRIOR EXPRESS WRITTEN PERMISSION OF SUN MICROSYSTEMS, INC.

This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo, Java, Solaris, Sun Fire 4500 and Sun Fire 4540 are trademarks or registered trademarks of Sun Microsystems, Inc., or its subsidiaries, in the U.S. and other countries.

AMD Opteron and Opteron are trademarks of Advanced Micro Devices, Inc.. Intel is a registered trademark of Intel Corporation.

This product is covered and controlled by U.S. Export Control laws and may be subject to the export or import laws in other countries. Nuclear, missile, chemical biological weapons or nuclear maritime end uses or end users, whether direct or indirect, are strictly prohibited. Export or reexport to countries subject to U.S. embargo or to entities identified on U.S. export exclusion lists, including, but not limited to, the denied persons and specially designated nationals lists is strictly prohibited.

Use of any spare or replacement CPUs is limited to repair or one-for-one replacement of CPUs in products exported in compliance with U.S. export laws. Use of CPUs as product upgrades unless authorized by the U.S. Government is strictly prohibited.

Copyright © 2010 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Non publiée - droits réservés selon la législation des Etats-Unis sur le droit d'auteur.

CE PRODUIT CONTIENT DES INFORMATIONS CONFIDENTIELLES ET DES SECRETS COMMERCIAUX DE SUN MICROSYSTEMS, INC. SON UTILISATION, SA DIVULGATION ET SA REPRODUCTION SONT INTERDITES SANS L'AUTORISATION EXPRESSE, ECRITE ET PREALABLE DE SUN MICROSYSTEMS, INC.

Cette distribution peut inclure des éléments développés par des tiers.

Sun, Sun Microsystems, le logo Sun, Java, Solaris, et Sun Fire 4540 sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc., et ses filiales, aux Etats-Unis et dans d'autres pays.

AMD Opteron et Opteron sont marques déposées de Advanced Micro Devices, Inc. Intel est une marque déposée de Intel Corporation

Ce produit est soumis à la législation américaine sur le contrôle des exportations et peut être soumis à la réglementation en vigueur dans d'autres pays dans le domaine des exportations et importations. Les utilisations finales, ou utilisateurs finaux, pour des armes nucléaires, des missiles, des armes biologiques et chimiques ou du nucléaire maritime, directement ou indirectement, sont strictement interdites. Les exportations ou reexportations vers les pays sous embargo américain, ou vers des entités figurant sur les listes d'exclusion d'exportation américaines, y compris, mais de manière non exhaustive, la liste de personnes qui font objet d'un ordre de ne pas participer, d'une façon directe ou indirecte, aux exportations des produits ou des services qui sont régis par la législation américaine sur le contrôle des exportations et la liste de ressortissants spécifiquement désignés, sont rigoureusement interdites.

L'utilisation de pièces détachées ou d'unités centrales de remplacement est limitée aux réparations ou à l'échange standard d'unités centrales pour les produits exportés, conformément à la législation américaine en matière d'exportation. Sauf autorisation par les autorités des Etats-Unis, l'utilisation d'unités centrales pour procéder à des mises à jour de produits est rigoureusement interdite.



Adobe PostScript

Contents

Preface v

Sun Fire X4540 Server ILOM 3.0 Supplement 1

ILOM 3.0 Features Not Supported 1

Running ipmitool From the Host Using KCS 2

Power Consumption Management 3

ILOM Firmware Update With Delayed BIOS Update Option 4

▼ To Check the ILOM Firmware Version Using the CLI 5

▼ To Check the ILOM Firmware Version Using Web Interface 5

▼ To Download the ILOM Firmware 5

▼ To Upgrade the ILOM Firmware Using the CLI 6

▼ To Upgrade the ILOM Firmware Using the Web Interface 7

Service Processor Lost Password Recovery Procedure 11

▼ To Recover a Lost Password Using the default User Account 12

Sensors Reference Information 13

Power Supply Sensors 14

Temperature Sensors 14

Voltage Sensors 15

Fan Sensor 16

Presence Sensors 16

Preface

The *Sun Sun Integrated Lights Out Manager 3.0 Supplement for Sun Fire X4540 Server* contains information about ILOM 3.0 that is specific to the Sun Fire X4540 server. For a complete discussion of ILOM 3.0 and its capabilities along with user procedures, see the *Sun Integrated Lights Out Manager 3.0 User's Guide* (820-4597).

Related Documentation

The document set for the Sun Fire X4540 server is described in the *Where To Find Sun Fire X4540 Servers Documentation* sheet that is packed with your system. You can also find the documentation at <http://docs.sun.com>.

- For the Sun Fire X4540:

<http://docs.sun.com/app/docs/prod/sf.x4540~x4540-ops#hic>

Translated versions of some of these documents are available at <http://docs.sun.com>. Select a language from the drop-down list and navigate to the Sun Fire X4540 server document collection using the Product category link. Available translations for the Sun Fire X4540 server include Simplified Chinese, Traditional Chinese, French, Japanese, and Korean.

English documentation is revised more frequently and might be more up-to-date than the translated documentation. For all Sun documentation, go to the following URL:

<http://docs.sun.com>

Documentation, Support, and Training

The following table shows where to find documentation, support, and training.

TABLE P-1 Documentation, Support, and Training

Sun Function	URL	Description
Sun Documentation	http://docs.sun.com	You can navigate to the Sun Fire X4540 Servers document page and then download PDF and view HTML documents.
Support	http://www.sun.com/support/	Obtain technical support and download patches.
Training	http://www.sun.com/training/	Learn about Sun courses.
Warranty	http://www.sun.com/service/support/warranty/index.html	Obtain specific details regarding your warranty.
Feedback	http://www.sun.com/hwdocs/feedback/	Submit your comments.

Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

Sun Sun Integrated Lights Out Manager 3.0 Supplement for Sun Fire X4540 Server, part number 820-5549-12

Sun Fire X4540 Server ILOM 3.0 Supplement

The Sun Fire X4540 server runs ILOM 3.0. However, some ILOM features that are not applicable to these servers are not implemented. Other features are implemented in a platform-specific way.

This supplement describes the differences between the ILOM 3.0 platform-specific user interface provided on the Sun Fire X4540 server and the user interface provided by ILOM 3.0. For a description of all the features and capabilities offered by the ILOM 3.0 firmware, see the *Sun Integrated Lights Out Manager 3.0 User's Guide* (820-4597).

The following topics are covered in this supplement:

- [“ILOM 3.0 Features Not Supported” on page 1](#)
- [“Running ipmitool From the Host Using KCS” on page 2](#)
- [“Power Consumption Management” on page 3](#)
- [“ILOM Firmware Update With Delayed BIOS Update Option” on page 4](#)
- [“Service Processor Lost Password Recovery Procedure” on page 11](#)
- [“Sensors Reference Information” on page 13](#)

ILOM 3.0 Features Not Supported

With the exception of Power Policy Configuration, all ILOM 3.0 firmware features are supported on the Sun Fire X4540 server.

For a complete list of ILOM 3.0 firmware features, see the *Sun Integrated Lights Out Manager 3.0 User's Guide* (820-4597).

TABLE 1 lists the differences between the ILOM 3.0 web interface and the ILOM 3.0 platform-specific web interface on the Sun Fire X4540 server.

TABLE 1 Differences Between the ILOM 3.0 Web Interface and the ILOM 3.0 platform-specific Web Interface on the Sun Fire X4540 Server

Web Interface Features	Supported in ILOM 3.0	Supported by ILOM 3.0 on the Sun Fire X4540 Server
Policy Page on the Configuration Tab	Yes	No
Serial Port Page on the Configuration Tab has a Serial Port Sharing setting. This setting controls whether the external serial port accesses the Host Server or the Service Processor. If set to Host Server, ILOM has no control of the serial port. All serial port settings will be that of the Host Server.	No	Yes
Redirection page on the Remote Control tab has settings for 8-bit or 16-bit redirection. The 16-bit high-quality color redirection is for fast connections. The 8-bit lower-quality color redirection is for slower connections.	Yes	No

Running ipmitool From the Host Using KCS

The Keyboard Controller Style (KCS) interface enables you to use the host operating system to execute `ipmitool` commands on the ILOM service processor (SP). Using `ipmitool` commands you can perform server, initialization, monitoring, and maintenance tasks from the host operating system.

Note – The KCS interface is sometimes referred to as the Baseboard Management Controller (BMC) interface.

The Sun Fire X44540 server supports in-band systems management using IPMI v1.5 or 2.0 with the KCS interface and the IPMI kernel driver. IPMI is an industry-supported standard for performing autonomous platform management functions.

You can run `ipmitool` commands on Solaris, Linux, and Windows Server 2003 R2 Enterprise operating systems. For a description of the `ipmitool` commands and options, see the `ipmitool` manpage on the web at:

<http://ipmitool.sourceforge.net/manpage.html>

The following are a few `ipmitool` commands for the operating systems supported by the server.

- For Solaris and Linux:

```
# ipmitool -I interface sdr list
# ipmitool -I interface sel list
# ipmitool -I interface lan print 1
```

Where *interface* is `bmc` on Solaris systems and `open` on Linux systems.

- For Windows Server 2003 R2 Enterprise:

```
# ipmitool -I ms sdr list
# ipmitool -I ms sel list
# ipmitool -I ms lan print 1
```

If you are using a Solaris or Linux operating system, refer to *Remote Monitoring of Sun X64 Systems Using IPMITOOL and IPMIEVD* (820-1011) for `ipmitool` installation and user instructions. This document is available on the web at:

<http://www.sun.com/blueprints/0107/820-1011.pdf>

If you are using a Windows Server 2003 R2 operating system, install the optional Windows Hardware Management interface driver. For instructions on how to install this driver, refer to *Hardware Management in Microsoft Windows Server 2003 R2 RC0* and perform the procedure “How to Enable the Hardware Management Feature.” It is not necessary to perform any of the other procedures described this document, such as “Configuration and Security.” This document is available on the web at:

<http://www.microsoft.com/technet/scriptcenter/preview/wsm/enable.msp#ECB>

Additional information on IPMI, including the `ipmitool` manpage and detailed specifications, is available on the web at the following locations:

<http://ipmitool.sourceforge.net/manpage.html>

<http://openipmi.sourceforge.net>

<http://www.intel.com/design/servers/ipmi/spec.htm>

Power Consumption Management

The Sun Fire X4540 server supports the power monitoring commands provided by the ILOM 3.0 Power Consumption Management interfaces. You can monitor power using the web interface and the command-line interface (CLI).

The following power properties are supported:

- `actual_power`
- `available_power`
- `permitted_power`

To monitor power using the web interface, open a browser, log in to the web interface, and select the **System Monitoring->Power Management** tab.

To monitor power using the CLI, log in to the CLI and type this command:

```
-> show /SP/powermgmt
```

For more information on power consumption management, see the *Sun Integrated Lights Out Manager 3.0 User's Guide* (820-4597).

ILOM Firmware Update With Delayed BIOS Update Option

The ILOM firmware upgrade process does the following:

- Upgrades the ILOM image.
- Upgrades the BIOS image if the BIOS image currently installed on the server is different from the BIOS image in the firmware upgrade package.

In order to update the BIOS image, the operating system running on the server must be shut down. Because it may be inconvenient or time consuming to shut down the operating system and the server when you complete the firmware upgrade, a new option has been added to the platform-specific ILOM 3.0 that runs on the Sun Fire X4540 server. This option enables you to delay the upgrade to the BIOS image to the next time the server is reset (shutdown and restarted).

The firmware upgrade procedure consists of the following steps:

1. Checking the version of ILOM running on the server.

You should check the version of ILOM running on the server before you download the ILOM firmware to ensure that a newer version of the firmware is available for downloading.

2. Downloading the ILOM firmware.

3. Upgrading the ILOM firmware.

Refer to the following sections for detailed instructions:

- “To Check the ILOM Firmware Version Using the CLI” on page 5
- “To Check the ILOM Firmware Version Using Web Interface” on page 5
- “To Download the ILOM Firmware” on page 5
- “To Upgrade the ILOM Firmware Using the CLI” on page 6
- “To Upgrade the ILOM Firmware Using the Web Interface” on page 7

▼ To Check the ILOM Firmware Version Using the CLI

1. **Log in to any user account that is assigned the Admin (a) role.**

The CLI prompt (->) appears.

2. **To check the firmware version, type `version`.**

The current firmware version information appears.

▼ To Check the ILOM Firmware Version Using Web Interface

1. **Log in to any user account that is assigned the Admin (a) role.**

2. **Select System Information ->Version.**

The Versions page appears displaying the current firmware version information.

▼ To Download the ILOM Firmware

1. **Browse to <http://www.sun.com/download/>**

The Sun Download page appears.

2. **Select the View by Category tab, scroll down the Hardware Drivers section, and click on X64 Servers and Workstations.**

The Sun Downloads x64 Servers & Workstations page appears.

3. **Locate the Sun Fire X4540 server in the left column of the product list and click Download.**

The Sun Fire X4540 Server page appears.

4. In the right column of the table, click **Download**.

The Sun Fire X4540 information page appears.

5. In the **Platform drop-down list**, select **Firmware**.

6. In the **Language drop-down list**, select the desired language.

7. Select the **I agree to the Software License Agreement** check box to accept the license agreement.

8. Enter your user name and password and click **Login and Continue**.

The Download Sun Fire X4540 3.0 for Firmware, English page appears.

Note – If you do not have a user name and password, you can register free of charge by clicking **Register Now**.

9. Follow the on-screen instructions to download the ILOM and BIOS binary. The download file name is similar to this: `ilom.x4540-3.0.1.1_35519e.ima`.

▼ To Upgrade the ILOM Firmware Using the CLI

1. Log in to any user account that is assigned the Admin (a) role.

The CLI prompt (->) appears.

2. Type the following command to upgrade ILOM firmware image:

```
->load -source tftp://ipaddress/firmwaredirectory/filename.ima
```

For example:

```
-> load -source tftp://333.22.22.222/downloads/  
ilom.x4500-3.0.1.1_35519e.ima
```

```
NOTE: An upgrade takes about 6 minutes to complete. ILOM  
will enter a special mode to load new firmware. No  
other tasks can be performed in ILOM until the  
firmware upgrade is complete and ILOM is reset.
```

```
You can choose to postpone the server BIOS upgrade until the  
next server poweroff. If you do not do that, you should  
perform a clean shutdown of the server before continuing.
```

```
Are you sure you want to load the specified file (y/n)? y
```

3. Type `y` to proceed with the upgrade.

The following prompt appears.

```
Do you want to preserve the configuration (y/n)? y
```

4. If you want to preserve the configuration, type `y`; otherwise type `n`.

The following prompt appears.

```
Do you want to force the server off if BIOS needs to be upgraded  
(y/n)? n
```

5. If you want to delay the BIOS firmware upgrade and not force a server shutdown, type `n`; otherwise type `y`.

Note – If you type `n`, the server will not be forced to shut down and the BIOS firmware will be upgraded the next time the server shuts down and restarts.

The upgrade process begins and the following information is displayed when the upgrade is complete.

```
Firmware update is complete.  
ILOM will now be restarted with the new firmware.
```

6. The ILOM 3.0 firmware upgrade is now complete.


▼ To Upgrade the ILOM Firmware Using the Web Interface

1. Log in to any user account that is assigned the Admin (a) role.

2. Select Maintenance --> Firmware Upgrade.

The Firmware Upgrade page appears (see [FIGURE 1](#)).


FIGURE 1 Firmware Upgrade Page



3. Click Enter Upgrade Mode.

The **Firmware Upgrade - Upload** page appears. This page provides the **Specify URL** field for specifying the location of the firmware package (see [FIGURE 2](#)).

FIGURE 2 Firmware Upgrade - Upload Page



4. To specify the location of the firmware package file, do one of the following:
 - a. Click Specify URL and enter the URL for the firmware package file.
 - b. Click Browse and browse to the location of the firmware package file.
5. Click Upload.

The Firmware Upgrade - Start Upgrade page appears (see [FIGURE 3](#)).

FIGURE 3 Firmware Upgrade - Start Upgrade Page

ABOUT REFRESH LOG OUT

Role (User): Administrator (root) SP Hostname: SUNSP00144F8D3894

Sun™ Integrated Lights Out Manager

Sun™ Microsystem, Inc.

Firmware Upgrade

To initiate firmware upgrade select the Start Upgrade button. To cancel the upgrade select Cancel.

Module Name	Existing Version	New Version
Service Processor Firmware <input checked="" type="checkbox"/> Preserve existing configuration	3.0.0.0	3.0.0.0
Service Processor BIOS <input checked="" type="checkbox"/> Delay BIOS upgrade until next server poweroff	26	26

Start Upgrade Cancel

Done

6. If you want to preserve the existing server configuration, select the Preserve existing configuration check box.
7. If you want to delay the BIOS upgrade until the next time the server powers off and reboots, select the Delay BIOS upgrade until next server poweroff check box.




Caution – If the server is running and you do not check the **Delay BIOS upgrade until next server poweroff** check box, the upgrade program forces a shutdown of the operating system and the server, which might result in filesystem corruption. Therefore, if you want to upgrade the BIOS firmware at the same time you upgrade the ILOM firmware, shut down the server prior to performing this upgrade procedure.

8. Click the Start Upgrade button to upgrade the firmware.

When you click the Start Upgrade button, a progress screen appears and indicates that the firmware is being updated. Once the update progress reaches 100%, the Upgrade Complete page appears (see [FIGURE 4](#)) and the SP *automatically* reboots.

FIGURE 4 Firmware Upgrade - Upgrade Complete Page



9. After the SP finishes rebooting, use your browser to reconnect to ILOM.

Service Processor Lost Password Recovery Procedure

In ILOM 3.0, the `root` account—which was used for administrative tasks in ILOM 2.0—has been removed and the `default` user account is used for initial login, creation of user accounts, and server configuration. After those tasks are performed, the `default` user account’s access is limited to the CLI on the SP console. Therefore, all subsequent user account changes (creations and modifications) and configuration changes should be done using specific user accounts. This requirement enables accountability to be traced to individual users who have access to specific accounts.

As mentioned, once you login to the `default` user account, subsequent access to this account is restricted to the CLI on the SP console, which connects through the serial management port. Additionally, by default, the SP requires that a “physical

presence” switch be pressed on the server before the SP console can be used for this purpose. This requirement is there for security reasons as it prevents access to the `default` user account from a remote location, that is, you must have physical access to the server to use this account.

One of the uses of the `default` user account is lost password recovery. It is meant to be used when you cannot access the account for which the password was lost by using a different user account. User accounts assigned the user (`u`) role can be used to change and reset passwords on other user accounts. If there are no user accounts that have the ability to reset passwords, you can use the CLI on the SP console to log in to the `default` user account.

▼ To Recover a Lost Password Using the `default` User Account

1. **Connect a serial cable from the RJ-45 SER MGT port on the server’s back panel to a terminal device.**

For instructions, refer to the *Sun Fire X4500 and X4540 Servers Installation Guide* (820-2394).

2. **Ensure that the server is powered on.**

The `localhost` login prompt appears.


3. **Log in to the `default` user account. Type:**

```
localhost login: default
```

4. **Press the Locator button once.**

This Locator button is on the front of the server (see [FIGURE 5](#)).

FIGURE 5 Sun Fire X4540 Locator Button



5. Press the Enter key on the terminal device.

The SP displays the `Password` prompt.

6. Enter the password for the `default` user account.

The `default` user account password is the product serial number and it cannot be changed. The product serial number is printed on the server hardware or on the product purchase documentation.

Once you have successfully logged in, the SP displays its default CLI command prompt: `->`

7. You can now use the `default` user account to reset the passwords for user accounts for which passwords have been lost.

For instructions on how to use the CLI to reset user passwords, see the *Sun Integrated Lights Out Manager 3.0 User's Guide* (820-4597).

Sensors Reference Information

The server includes a number of sensors that report on hardware conditions. Many of the sensor readings are used to adjust the fan speeds and perform other actions, such as illuminating LEDs and powering off the server.

This sections describes the sensors that ILOM monitors for the Sun Fire X4540 server.

The following types of sensors are described:

- [“Power Supply Sensors” on page 14](#)
- [“Temperature Sensors” on page 14](#)

- “Voltage Sensors” on page 15
- “Fan Sensor” on page 16
- “Presence Sensors” on page 16

Note – To view disk information, use the `ipmitool sdr data` command. The ILOM 3.x Sensor Readings GUI screen does not provide drive information.

Power Supply Sensors

TABLE 2 describes the power supply sensors. In the table, *n* designates the numbers 0-n.

TABLE 2 Power Supply Sensors

Sensor Name	Sensor Type	Description
/SYS/PS <i>n</i> /PWROK	Fault	Power supply DC power out ok
/SYS/PS <i>n</i> /VINOK	Fault	Power supply AC voltage in ok

Temperature Sensors

TABLE 3 describes the temperature sensors. In the table, *n* designates the numbers 0 through *n*.

TABLE 3 Temperature Sensors

Sensor Name	Sensor Type	Description
/SYS/PROC/P <i>n</i> /T_CORE	Temperature	CPU <i>n</i> core temperature
/SYS/DPB/T_AMB	Temperature	Disk backplane ambient temperature
/SYS/IO/FRONT_T_AMB	Temperature	I/O Board Front ambient temperature
/SYS/IO/REAR_T_AMB	Temperature	I/O Board Rear ambient temperature
/SYS/PROC/FRONT_T_AMB	Temperature	Processor Board Front ambient temperature
/SYS/PROC/REAR_T_AMB	Temperature	Processor Board Rear ambient temperature
/SYS/PROC/P <i>n</i> /PROCHOT	Temperature	Processor temperature sensor. Sense if the processor has reached the maximum safe operating temperature.

Voltage Sensors

TABLE 4 describes the voltage sensors. In the table, *n* designates the numbers 0-n.

TABLE 4 Voltage Sensors

Sensor Name	Sensor Type	Description
/SYS/IO/V_+1V2	Voltage	I/O Board +1.2 Volts
/SYS/IO/V_+1V4	Voltage	I/O Board +1.4 Volts
/SYS/IO/V_+1V5	Voltage	I/O Board +1.5 Volts
/SYS/IO/V_+1V8	Voltage	I/O Board +1.8 Volts
/SYS/IO/V_+3V3	Voltage	I/O Board +3.3 Volts
/SYS/IO/V_+3V3STBY	Voltage	I/O Board +3.3 Volts Standby
/SYS/IO/V_+5V_DISK	Voltage	I/O Board +5 Volts Disk
/SYS/IO/V_+12V	Voltage	I/O Board +12 Volts
/SYS/IO/V_BAT	Voltage	Battery Voltage measured on I/O Board
/SYS/PROC/Pn/V_+0V9	Voltage	CPU <i>n</i> +0.9 Volts
/SYS/PROC/Pn/V_+1V8	Voltage	CPU <i>n</i> +1.8 Volts
/SYS/PROC/Pn/V_VDDCORE	Voltage	CPU <i>n</i> Vdd Core Volts
/SYS/V_+12V	Voltage	System +12 Volts
/SYS/V_+1V2HT	Voltage	System +1.2 Volts HT
/SYS/V_+3V3	Voltage	System +3.3 Volts
/SYS/V_+3V3STBY	Voltage	System +3.3 Volts Standby
/SYS/V_BAT	Voltage	Battery voltage

Fan Sensor

TABLE 5 describes the fan sensor. In the table, *n* designates the numbers 0-n.

TABLE 5 Fan Sensor

Sensor Name	Sensor Type	Description
/SYS/FTn/FANn/TACH	Speed	Fan Tray <i>n</i> Fan <i>n</i> Speed

Presence Sensors

TABLE 6 describes the presence sensors. In the table, *n* designates the numbers 0-n.

TABLE 6 Configuration Sensors

Sensor Name	Sensor Type	Description
/SYS/PSn/PRSNT	Entity presence	Power supply unit <i>n</i> present monitor
/SYS/PROC/PRSNT	Entity presence	Processor Mezzanine Board present monitor
/SYS/PROC/Pn/PRSNT	Entity presence	Processor <i>n</i> present monitor
/SYS/FTn/PRSNT	Entity presence	Fan Tray <i>n</i> present monitor