



Do not enter content here

Sun Microsystems, Inc.
901 San Antonio Road
Palo Alto, , CA 94303-4900
U.S.A

Part No: 805-4437
October 1998, Revision A

Copyright 1998 Sun Microsystems, Inc. 901 San Antonio Road, Palo Alto, California 94303-4900 U.S.A. All rights reserved.

This product or document is protected by copyright and distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, OpenBoot, AnswerBook, and Solaris] are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and SunTM Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

RESTRICTED RIGHTS: Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 1998 Sun Microsystems, Inc., 901 San Antonio Road, Palo Alto, Californie 94303 Etats-Unis. Tous droits réservés.

Ce produit ou document est protégé par un copyright et distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, OpenBoot, AnswerBook, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et SunTM a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

CETTE PUBLICATION EST FOURNIE "EN L'ETAT" ET AUCUNE GARANTIE, EXPRESSE OU IMPLICITE, N'EST ACCORDEE, Y COMPRIS DES GARANTIES CONCERNANT LA VALEUR MARCHANDE, L'APTITUDE DE LA PUBLICATION A REPONDRE A UNE UTILISATION PARTICULIÈRE, OU LE FAIT QU'ELLE NE SOIT PAS CONTREFAISANTE DE PRODUIT DE TIERS. CE DENI DE GARANTIE NE S'APPLIQUEAIT PAS, DANS LA MESURE OU IL SERAIT TENU JURIDIQUEMENT NUL ET NON AVENU.



Adobe PostScript



Please
Recycle

Contents

1.	OpenBoot 3.x Quick Reference	1
	Syntax	1
	Numeric Usage and Stack Comments	1
	Help Commands	3
	Device Tree Browsing Commands	3
	Common Options for the boot Command	4
	Emergency Keyboard Commands	5
	Diagnostic Test Commands	5
	Examining and Creating Device Aliases	6
	System Information Display Commands	6
	File Load & Run Commands	7
	SPARC TM Register Commands	7
	SPARC V9 Register Commands	8
	Breakpoint Commands	9
	Miscellaneous Operations	10
	NVRAM Configuration Parameters	11
	Viewing and Changing Configuration Parameters	13
	Commands Affecting NVRAMRC	14
	Editor Commands (for Command Lines and NVRAMRC)	14

Using the NVRAMRC Editor	15
Stack Manipulation Commands	16
Changing the Number Base	17
Basic Number Display	18
Arithmetic Functions	18
Disassembler Commands	20
Memory Access Commands	20
Memory Mapping Commands	22
Defining Words	23
Dictionary Searching Commands	23
Manipulating Text Strings	24
Dictionary Compilation Commands	24
Controlling Text Input	25
Displaying Text Output	26
Redirecting I/O	26
Comparison Commands	27
if-else-then Commands	28
begin (Conditional) Loop Commands	28
do (Counted) Loop Commands	29
case Statement	29
Program Execution Control Commands	30
Alternate Address Space Access Commands	30
Cache Manipulation Commands	31
Multiprocessor Command	31
Program Execution Control Commands	32

OpenBoot 3.x Quick Reference

Syntax

Enter commands at the `ok` prompt. They are executed left-to-right after a carriage-return. Separate all commands by one or more spaces.

Numeric Usage and Stack Comments

- Numeric I/O defaults to hexadecimal.
- Switch to decimal with `decimal`, switch to hexadecimal with `hex`.
- Use `10 .d` to see which base is currently active.

A numeric stack is used for all numeric parameters. Typing any integer puts that value on top of the stack. (Previous values are pushed down.) The right-hand item in a set always indicates the topmost stack item.

- The command `"` removes and displays the top stack value.
- The command `.s` non-destructively shows the entire stack contents.

A stack comment such as `(n1 n2 - n3)` or `(adr len -)` or `(-)` listed after each command name shows the effect on the stack of executing that command. Items *before* the `-` are used by the command and removed from the stack. These items *must* be present on the stack *before* the command can properly execute. Items after the `-` are left on the stack after the command completes execution, and are available for use by subsequent commands.

TABLE 1–1 Numeric Usage and Stack Comments

	Alternate stack results. Example: (input – adr len false result true).
?	Unknown stack items (changed from ???).
???	Unknown stack items.
adr	Memory address (generally a virtual address).
adr16	Memory address, must be 16-bit aligned.
adr32	Memory address, must be 32-bit aligned.
adr64	Memory address, must be 64-bit aligned.
byte bxxx	8-bit value (smallest byte in a 32-bit word).
char	7-bit value (smallest byte), high bit unspecified.
cnt/len/size	Count or length.
flag xxx?	0 = false; any other value = true (usually -1).
long lxxx	32-bit value.
n n1 n2 n3	Normal signed values.
+n u	Unsigned, positive values.
phys	Physical address (actual hardware address).
pstr	Packed string (adr len means unpacked string).
virt	Virtual address (address used by software).
word wxxx	16-bit value.
xt	Execution token.

TABLE 1–1 Numeric Usage and Stack Comments *(continued)*

Help Commands

TABLE 1–2 Help Commands

<code>help</code>	List main help categories.
<code>help <i>category</i></code>	Show help for all commands in the <i>category</i> . Use only the first word of the category description.
<code>help <i>command</i></code>	Show help for individual <i>command</i> (where available).

Device Tree Browsing Commands

TABLE 1–3 Device Tree Browsing Commands

<code>.properties</code>	Display the names and values of the current node's properties.
<code>dev <i>node-name</i></code>	Search for a node with the given name in the subtree below the current node, and choose the first such node found.
<code>dev ..</code>	Choose the device node that is the parent of the current node.
<code>dev /</code>	Choose the root machine node.
<code>device-end</code>	Leave the device tree.
<code>ls</code>	Display the names of the current node's children.

TABLE 1–3 Device Tree Browsing Commands *(continued)*

pwd	Display the device path name that names the current node.
show-devs [<i>device-path</i>]	Display all the devices directly under the specified device in the device tree; without <i>device-path</i> it shows the entire device tree.
words	Display the names of the current node's methods.

Common Options for the boot Command

TABLE 1–4 Common Options for the boot Command

boot [<i>device-specifier</i>] [<i>filename</i>] [<i>options</i>]	
[<i>device-specifier</i>]	The name (full path name or alias) of a device. Examples: cdrom (CD-ROM drive) disk (hard disk) net (Ethernet) tape (SCSI tape)
[<i>filename</i>]	The name of the program to be booted (for example, <code>stand/diag</code>). If specified, <i>filename</i> is relative to the root of the selected device and partition. If not, the boot program uses the value of the <code>boot-file</code> or <code>diag-file</code> based on <code>diag-switch?</code> parameter.
[<i>options</i>]	-a - Prompt interactively for the device and name of the boot file. -h - Halt after loading the program. <i>(OS-specific options may differ from system to system.)</i>

Emergency Keyboard Commands

TABLE 1–5 Emergency Keyboard Commands

Hold down keys during power-on sequence.	
Stop	Bypass POST. This command does not depend on security-mode. (Note: some systems bypass POST as a default; in such cases, use Stop-D to start POST.)
Stop-A	Abort.
Stop-D	Enter diagnostic mode (set diag-switch? to true).
Stop-F	Enter Forth on TTYA instead of probing. Use fexit to continue with the initialization sequence. (Useful if hardware is broken.)
Stop-N	Reset NVRAM contents to default values.

Diagnostic Test Commands

TABLE 1–6 Diagnostic Test Commands

probe-scsi	Identify devices attached to the built-in SCSI bus.
test <i>device-specifier</i>	Execute the specified device's self-test method. For example: <code>test floppy</code> - test the floppy drive, if installed <code>test net</code> - test the network connection
test-all [<i>device-specifier</i>]	Test all devices (that have a built-in self-test method) below the specified node. (If <i>device-specifier</i> is absent, the root node is used.)

TABLE 1–6 Diagnostic Test Commands (*continued*)

watch-clock	Test the clock function.
watch-net	Monitor the network connection.

Examining and Creating Device Aliases

TABLE 1–7 Examining and Creating Device Aliases

devalias	Display all current device aliases.
devalias <i>alias</i>	Display the device path name corresponding to alias.
devalias <i>alias device-path</i>	Define an alias representing the device path. If an alias with the same name already exists, the new value supersedes the old.

System Information Display Commands

TABLE 1–8 System Information Display Commands

banner	Display the power-on banner.
.version	Display the version and date of the boot PROM.
.speed	Display CPU and bus speeds.

File Load & Run Commands

TABLE 1–9 File Load & Run Commands

boot [<i>specifiers</i>] -h	(--)	Load file from specified source.
byte-load	(adr xt--)	Interpret a loaded FCode binary file. xt is usually 1.
dl	(--)	Load a Forth file over a serial line with TIP and interpret. Type: ~C cat <i>filename</i> ^-D
dlbin	(--)	Load a binary file over a serial line with TIP. Type: ~C cat <i>filename</i>
dload <i>filename</i>	(adr --)	Load specified file over Ethernet to given address.
go	(--)	Begin executing a previously-loaded binary program, or resume executing an interrupted program.
init-program	(--)	Initialize to execute a binary file.
load [<i>specifiers</i>]	(--)	Load data from specified device into memory at the address given by load-base. (See boot format.)
load-base	(-- adr)	Address at which load places the data it reads from a device.

SPARCTM Register Commands

TABLE 1–10 SPARC Register Commands

%g0 through %g7	(-- value)	Return the value in the given register.
%i0 through %i7	(-- value)	Return the value in the given register.
%l0 through %l7	(-- value)	Return the value in the given register.
%o0 through %o7	(-- value)	Return the value in the given register.
%pc %npc	(-- value)	Return the value in the given register.
.fregisters	(--)	Display values in %f0 through %f31.
.locals	(--)	Display the values in the i, l and o registers.
.registers	(--)	Display values in %g0 through %g7, plus some processor registers.
.window	(window# --)	Display the desired window.
ctrace	(--)	Display the return stack showing C subroutines.
set-pc	(value --)	Set %pc to the given value, and set %npc to (value+4).
to regname	(value --)	Change the value stored in any of the above registers. Use in the form: <i>value</i> to <i>regname</i> .
w	(window# --)	Set the current window for displaying registers.

SPARC V9 Register Commands

TABLE 1-11 SPARC V9 Register Commands

%fprs %asi %pstate %tl-c %pil %tstate %tt %tba %cwp %cansave %canrestore %otherwin %wstate %cleanwin	(-- value)	Return the value in the specified register.
.pstate	(--)	Formatted display of the processor state register.
.ver	(--)	Formatted display of the version register.
.ccr	(--)	Formatted display of the ccr register.
.trap-registers	(--)	Display trap-related registers.

Breakpoint Commands

TABLE 1-12 Breakpoint Commands

+bp	(adr --)	Add a breakpoint at the given address.
-bp	(adr --)	Remove the breakpoint at the given address.
--bp	(--)	Remove the most-recently-set breakpoint.
.bp	(--)	Display all currently set breakpoints.
.breakpoint	(--)	Perform a specified action when a breakpoint occurs (Example,). ['] .registers to .breakpoint
.instruction	(--)	Display the address, opcode for the last-encountered breakpoint.

TABLE 1–12 Breakpoint Commands (*continued*)

.step	(--)	Perform a specified action when a single step occurs.
bpoff	(--)	Remove all breakpoints.
finish-loop	(--)	Execute until the end of this loop.
go	(--)	Continue from a breakpoint. This can be used to go to an arbitrary address by setting up the processor's program counter before issuing go.
gos	(n --)	Execute go n times.
hop	(--)	(Like the step command.) Treats a subroutine call as a single instruction.
hops	(n --)	Execute hop n times.
return	(--)	Execute until the end of this subroutine.
returnl	(--)	Execute until the end of this leaf subroutine.
skip	(--)	Skip (do not execute) the current instruction.
step	(--)	Single-step one instruction.
steps	(n --)	Execute step n times.
till	(adr --)	Execute until the given address is encountered. Equivalent to +bp go.

Miscellaneous Operations

TABLE 1-13 Miscellaneous Operations

eject-floppy	(--)	Eject the diskette from the drive.
firmware-version	(-- n)	Return major/minor CPU firmware version (that is, 0x00030009 = firmware version 3.9).
ftrace	(--)	Show calling sequence when exception occurred.
get-msecs	(-- ms)	Return the approximate current time in milliseconds.
ms	(n --)	Delay for n milliseconds. Resolution is 1 millisecond.
reset-all	(--)	Reset the entire system (similar to a power cycle).
sync	(--)	Call the operating system to write any pending information to the hard disk.

NVRAM Configuration Parameters

TABLE 1-14 NVRAM Configuration Parameters

Parameter Name	Default	Description
auto-boot?	true	If true, boot automatically after power-on or reset.
boot-command	boot	Executed when auto-boot? is true.
boot-device	disk net	Device from which to boot.
boot-file	empty string	File to boot (an empty string lets secondary booter choose default).
diag-device	net	Diagnostic boot source device.
diag-file	empty string	File from which to boot in diagnostic mode.

TABLE 1-14 NVRAM Configuration Parameters (*continued*)

<code>diag-level</code>	<code>min</code>	Level of diagnostics to run (min or max).
<code>diag-switch?</code>	<code>false</code>	If true, run in diagnostic mode.
<code>fcode-debug?</code>	<code>false</code>	If true, include name fields for plug-in device FCodes.
<code>input-device</code>	<code>keyboard</code>	Power-on input device (usually keyboard, <code>ttya</code> , or <code>ttyb</code>).
<code>keymap</code>	<code>no default</code>	Keymap for custom keyboard.
<code>nvramrc</code>	<code>empty string</code>	NVRAM Startup script.
<code>oem-banner</code>	<code>empty string</code>	Custom OEM banner (enabled by <code>oem-banner? true</code>).
<code>oem-banner?</code>	<code>false</code>	If true, use custom OEM banner.
<code>output-device</code>	<code>screen</code>	Power-on output device (usually <code>screen</code> , <code>ttya</code> , or <code>ttyb</code>).
<code>sbus-probe-list</code>	<code>01</code>	Which SBus slots are probed and in what order.
<code>scsi-initiator-id</code>	<code>7</code>	SCSI bus address of host adapter, range 0-f.
<code>security-mode</code>	<code>none</code>	Firmware security level (none, command, or full).
<code>security-password</code>	<code>no default</code>	Firmware security password (never displayed).
<code>ttya-mode</code>	<code>9600,8,n,1,-</code>	TTYA (baud, #bits, parity, #stop, handshake).
<code>ttyb-mode</code>	<code>9600,8,n,1,-</code>	TTYB (baud, #bits, parity, #stop, handshake).
<code>ttya-ignore-cd</code>	<code>true</code>	If true, OS ignores TTYA carrier-detect.
<code>ttyb-ignore-cd</code>	<code>true</code>	If true, OS ignores TTYB carrier-detect.

TABLE 1-14 NVRAM Configuration Parameters (*continued*)

ttya-rts-dtr-off	false	If true, OS does not assert DTR and RTS on TTYA.
ttyb-rts-dtr-off	false	If true, OS does not assert DTR and RTS on TTYB.
use-nvramrc?	false	If true, execute commands in NVRAMRC during system start-up.
watchdog-reboot?	false	If true, reboot after watchdog reset.

Viewing and Changing Configuration Parameters

TABLE 1-15 Viewing and Changing Configuration Parameters

<code>password</code>	Set <code>security-password</code> .
<code>printenv [parameter]</code>	Display all current parameters and current default values (numbers are usually shown as decimal values). <code>printenv parameter</code> shows the current value of the named parameter.
<code>setenv parameter value</code>	Set the parameter to the given decimal or text value. (Changes are permanent, but usually only take effect after a reset).
<code>set-default parameter</code>	Reset the value of the named parameter to the factory default.
<code>set-defaults</code>	Reset parameter values to the factory defaults.

Commands Affecting NVRAMRC

TABLE 1-16 Commands Affecting NVRAMRC

nvalias <i>alias device-path</i>	Store the command "devalias <i>alias device-path</i> " in NVRAMRC. (The alias persists until the nvunalias or set-defaults commands are executed.) Turns on use-nvramrc?
nvedit	Enter the NVRAMRC editor. If data remains in the temporary buffer from a previous nvedit session, resume editing those previous contents. If not, read the contents of NVRAMRC into the temporary buffer and begin editing it.
nvquit	Discard the contents of the temporary buffer, without writing it to NVRAMRC.
nvrecover	Recover the contents of NVRAMRC if they have been lost as a result of the execution of set-defaults; then enter the editor as with nvedit. nvrecover fails if nvedit is executed between the time that the NVRAMRC contents were lost and the time that nvrecover is executed.
nvstore	Copy the contents of the temporary buffer to NVRAMRC; discard the contents of the temporary buffer.
nvunalias <i>alias</i>	Delete the corresponding alias from NVRAMRC.

Editor Commands (for Command Lines and NVRAMRC)

TABLE 1-17 Editor Commands (for Command Lines and NVRAMRC)

Previous Line	Begin Line	Previous Word	Prev. Char	Next Character	Next Word	End Line	Next Line
Move	^A	escB	^B	^F	escF	^E	^N
Delete	^U	^ W	Del	^D	escD	^K	
Re-type line: ^R							
Show all lines: ^L							
Paste after: ^K ^Y							
Complete command: ^ space							
Show all matches: ^/ or ^?{							

esc = Press and release Escape key first; ^ = Press and hold Control key

Using the NVRAMRC Editor

TABLE 1-18 Using the NVRAMRC Editor

```
ok nvedit
:
(use editor commands)
:
^C           get back to ok prompt
```

TABLE 1-18 Using the NVRAMRC Editor (continued)

ok nvstore	save changes
ok setenv use-nvramrc? true	enable NVRAMRC

Stack Manipulation Commands

TABLE 1-19 Stack Manipulation Commands

-rot	(n1 n2 n3 -- n3 n1 n2)	Inversely rotate three stack items.
>r	(n --)	Move a stack item to the return stack.
?dup	(n -- n n 0)	Duplicate the top stack item if non-zero.
2drop	(n1 n2 --)	Remove top two items from the stack.
2dup	(n1 n2 -- n1 n2 n1 n2)	Duplicate top two stack items.
2over	(n1 n2 n3 n4 -- n1 n2 n3 n4 n1 n2)	Copy second two stack items.
2swap	(n1 n2 n3 n4 -- n3 n4 n1 n2)	Exchange top two pairs of stack items.
clear	(??? --)	Empty the stack.
depth	(??? -- ??? +n)	Return the number of items on the stack.

TABLE 1-19 Stack Manipulation Commands (*continued*)

drop	(n --)	Remove the top item from the stack.
dup	(n -- n n)	Duplicate the top stack item.
over	(n1 n2 -- n1 n2 n1)	Copy the second stack item to the top of the stack.
pick	(nu ... n1 n0 u -- nu ... n1 n0 nu)	Copy u-th stack item (1 pick = over).
r>	(-- n)	Move a return stack item to the stack.
r@	(-- n)	Copy the top of the return stack to the stack.
roll	(nu ... n1 n0 u -- nu-1 ... n1 n0 nu)	Rotate u stack items (2 roll = rot).
rot	(n1 n2 n3 -- n2 n3 n1)	Rotate three stack items.
swap	(n1 n2 -- n2 n1)	Exchange the top two stack items.
tuck	(n1 n2 -- n2 n1 n2)	Copy the top stack item below the second item.

Changing the Number Base

TABLE 1–20 Changing the Number Base

decimal	(--)	Set the number base to 10.
d# <i>number</i>	(-- n)	Interpret the next number in decimal; base is unchanged.
hex	(--)	Set the number base to 16.
h# <i>number</i>	(-- n)	Interpret the next number in hex; base is unchanged.
.d	(n --)	Display n in decimal without changing base.
.h	(n --)	Display n in hex without changing base.

Basic Number Display

TABLE 1–21 Basic Number Display

.	(n --)	Display a number in the current base.
.s	(--)	Display contents of data stack.
showstack	(--)	Execute .s automatically before each ok prompt.

Arithmetic Functions

TABLE 1-22 Arithmetic Functions

*	(n1 n2 -- n3)	Multiply n1 * n2.
+	(n1 n2 -- n3)	Add n1 + n2.
-	(n1 n2 -- n3)	Subtract n1 - n2
/	(n1 n2 -- quot)	Divide n1 / n2; remainder is discarded.
lshift	(n1 +n -- n2)	Left-shift n1 by +n bits.
rshift	(n1 +n -- n2)	Right-shift n1 by +n bits.
>>a	(n1 +n -- n2)	Arithmetic right-shift n1 by +n bits.
abs	(n -- u)	Absolute value.
and	(n1 n2 -- n3)	Bitwise logical AND.
bounds	(n cnt -- n+cnt n)	Prepare arguments for do or ?do loop.
bljoin	(b.low b2 b3 b.hi -- long)	Join four bytes to form a 32-bit value.
bwjoin	(b.low b.hi -- word)	Join two bytes to form a 16-bit value.
lbsplit	(long -- b.low b2 b3 b.hi)	Split a 32-bit value into four bytes.
lwsplit	(long -- w.low w.hi)	Split a 32-bit value into two 16-bit words.
max	(n1 n2 -- n3)	n3 is maximum of n1 and n2.
min	(n1 n2 -- n3)	n3 is minimum of n1 and n2.
mod	(n1 n2 -- rem)	Remainder of n1 / n2.
negate	(n1 -- n2)	Change the sign of n1.

TABLE 1-22 Arithmetic Functions (*continued*)

invert	(n1 -- n2)	Bitwise ones complement.
or	(n1 n2 -- n3)	Bitwise logical OR.
wbsplit	(word -- b.low b.hi)	Split 16-bit value into two bytes.
wljoin	(w.low w.hi -- long)	Join two 16-bit values to form a 32-bit value.
xor	(n1 n2 -- n3)	Bitwise exclusive OR.

Disassembler Commands

TABLE 1-23 Disassembler Commands

+dis	(--)	Continue disassembling where the last disassembly left off.
dis	(adr --)	Begin disassembling at the given address.

Memory Access Commands

TABLE 1-24 Memory Access Commands

!	(n adr --)	Store a number at adr.
+!	(n adr --)	Add n to the number stored at adr.
@	(adr -- n)	Fetch a number from adr.

TABLE 1-24 Memory Access Commands (*continued*)

c!	(n adr --)	Store low byte of n at adr.
c@	(adr -- byte)	Fetch a byte from adr.
cpeek	(adr -- false byte true)	Fetch the byte at adr. Return the data and true if the access was successful. Return false if a read access error occurred. (Also lpeek, wpeek.)
cpoke	(byte adr -- okay?)	Store the byte to adr. Return true if the access was successful. Return false if a write access error occurred. (Also lpoke, wpoke.)
comp	(adr1 adr2 len -- n)	Compare two byte arrays, n = 0 if arrays are identical, n = 1 if first byte that is different is greater in array#1, n = -1 otherwise.
dump	(adr len --)	Display len bytes of memory starting at adr.
fill	(adr size byte --)	Set size bytes of memory to byte.
l!	(n adr32 --)	Store a 32-bit number at adr32.
l@	(adr32 -- long)	Fetch a 32-bit number from adr32.
move	(src dst u --)	Copy u bytes from src to dst, handle overlap properly.
w!	(n adr16 --)	Store a 16-bit number at adr16, must be 16-bit aligned.
w@	(adr16 -- word)	Fetch a 16-bit number from adr16, must be 16-bit aligned.
x!	(o oaddr --)	Store a 64-bit number at oaddr, must be 64-bit aligned.
x@	(oaddr -- o)	Fetch a 64-bit number from oaddr, must be 64-bit aligned.

Memory Mapping Commands

TABLE 1-25 Memory Mapping Commands

alloc-mem	(size -- virt)	Allocate and map size bytes of available memory; return the virtual address. Unmap with free-mem.
free-mem	(virt size --)	Free memory allocated by alloc-mem.
free-virtual	(virt size --)	Undo mappings created with memmap.
map?	(virt --)	Display memory map information for the virtual address.
memmap	(phys space size -- virt)	Map a region of physical addresses; return the allocated virtual address. Unmap with free-virtual.
obio	(-- space)	Specify the device address space for mapping.
obmem	(-- space)	Specify the onboard memory address space for mapping.
pgmap!	(pmentry virt --)	Store a new page map entry for the virtual address.
pgmap?	(virt --)	Display the decoded page map entry corresponding to the virtual address.
pgmap@	(virt -- pmentry)	Return the page map entry for the virtual address.
pagesize	(-- size)	Return the size of a page (often 8K).
sbus	(-- space)	Specify the SBus address space for mapping.

Defining Words

TABLE 1–26 Defining Words

<code>: name</code>	<code>(--)Usage: (??? -- ?)</code>	Start creating a new colon definition.
<code>;</code>	<code>(--)</code>	Finish creating a new colon definition.
<code>buffer: name</code>	<code>(size --)Usage: (-- adr)</code>	Create a named array in temporary storage.
<code>constant name</code>	<code>(n --)Usage: (-- n)</code>	Define a constant (for example, <code>3 constant bar</code>).
<code>create name</code>	<code>(--)Usage: (-- adr)</code>	Generic defining word.
<code>defer name</code>	<code>(--)Usage: (??? -- ?)</code>	Define forward reference or execution vector.
<code>value name</code>	<code>(n --)Usage: (-- n)</code>	Create a changeable, named quantity.
<code>variable name</code>	<code>(--)Usage: (-- adr)</code>	Define a variable.

Dictionary Searching Commands

TABLE 1–27 Dictionary Searching Commands

<code>' name</code>	<code>(-- xt)</code>	Find the named word in the dictionary. (Returns the execution token. Use outside definitions.)
<code>['] name</code>	<code>(-- xt)</code>	Similar to ' <code>but</code> ' is used inside definitions.
<code>.calls</code>	<code>(xt --)</code>	Display a list of all words that call the word whose execution token is <code>xt</code> .

TABLE 1-27 Dictionary Searching Commands (*continued*)

\$find	(adr len -- addr len false xt n)	Find a word. n = 0 if not found, n = 1 if immediate, n = -1 otherwise.
see thisword	(--)	Decompile the named command.
(see)	(xt --)	Decompile the word indicated by the execution token.
sifting ccc	(--)	Display names of all dictionary entries containing the sequence of characters. ccc contains no spaces.
words	(--)	Display visible words in the dictionary.

Manipulating Text Strings

TABLE 1-28 Manipulating Text Strings

" CCC"	(-- adr len)	Collect an input stream string.
. " CCC"	(--)	Compile a string for later display.
bl	(-- char)	ASCII code for the space character; decimal 32.
count	(pstr -- adr +n)	Unpack a packed string.
p " CCC"	(-- pstr)	Collect a string from the input stream; store as a packed string.

Dictionary Compilation Commands

TABLE 1-29 Dictionary Compilation Commands

,	(n --)	Place a number in the dictionary.
c,	(byte --)	Place a byte in the dictionary.
w,	(word --)	Place a 16-bit number in the dictionary.
l,	(long --)	Place a 32-bit number in the dictionary.
allot	(n --)	Allocate n bytes in the dictionary.
forget name	(--)	Remove word from dictionary and all subsequent words.
here	(-- adr)	Address of top of dictionary.
to <i>name</i>	(n --)	Install a new action in a defer word or value.
patch <i>new-word</i> <i>old-word</i> <i>word-to-patch</i>	(--)	Replace <i>old-word</i> with <i>new-word</i> in <i>word-to-patch</i> .
(patch)	(new-n old-n xt --)	Replace old-n with new-n in word indicated by xt.

Controlling Text Input

TABLE 1–30 Controlling Text Input

(<i>ccc</i>)	(--)	Begin a comment.
\ rest-of-line	(--)	Skip the rest of the line.
ascii <i>ccc</i>	(-- <i>char</i>)	Get numerical value of first ASCII character of next word.
key	(-- <i>char</i>)	Read a character from the assigned input device.
key?	(-- <i>flag</i>)	True if a character has been entered from the input device..

Displaying Text Output

TABLE 1–31 Displaying Text Output

cr--)	Terminate a line on the display and go to the next line.
€ndtar --)	Display the character.
t_yadr +n --)	Display n characters.

Redirecting I/O

TABLE 1-32 Redirecting I/O

input	(dev-spec --)	Select device (ttya, ttyb, keyboard, or " <i>dev-spec</i> ") for subsequent input.
io	(dev-spec --)	Select device for subsequent input and output.
output	(dev-spec --)	Select device (ttya, ttyb, screen, or " <i>dev-spec</i> ") for subsequent output.

Comparison Commands

TABLE 1-33 Comparison Commands

<	(n1 n2 -- flag)	True if n1 < n2.
<=	(n1 n2 -- flag)	True if n1 <= n2.
<>	(n1 n2 -- flag)	True if n1 <> n2.
=	(n1 n2 -- flag)	True if n1 = n2.
>	(n1 n2 -- flag)	True if n1 > n2.
>=	(n1 n2 -- flag)	True if n1 >= n2.
between	(n min max -- flag)	True if min <= n <= max.
u<	(u1 u2 -- flag)	True if u1 < u2, unsigned.
u<=	(u1 u2 -- flag)	True if u1 <= u2, unsigned.
u>	(u1 u2 -- flag)	True if u1 > u2, unsigned.

TABLE 1-33 Comparison Commands (*continued*)

u>=	(u1 u2 -- flag)	True if u1 >= u2, unsigned.
within	(n min max -- flag)	True if min <= n < max.

if-else-then Commands

TABLE 1-34 if-else-then Commands

else)	Execute the following code if if failed.
ifflag --)	Execute the following code if flag is true.
then)	Terminate if...else...then.

begin (Conditional) Loop Commands

TABLE 1-35 begin (Conditional) Loop Commands

again	(--)	End a begin...again infinite loop.
begin	(--)	Begin a begin...while...repeat, begin...until, or begin...again loop.
repeat	(--)	End a begin...while...repeat loop.
until	(flag --)	Continue executing a begin...until loop until flag is true.
while	(flag --)	Continue executing a begin...while...repeat loop while flag is true.

TABLE 1-35 begin (Conditional) Loop Commands (*continued*)

do (Counted) Loop Commands

TABLE 1-36 do (Counted) Loop Commands

+loop	(n --)	End a do...+loop construct; add n to loop index and return to do (if n < 0, index goes from start to end inclusive).
?do	(end start --)	Begin ?do...loop to be executed 0 or more times. Index goes from start to end-1 inclusive. If end = start, loop is not executed.
do	(end start --)	Begin a do...loop. Index goes from start to end-1 inclusive. Example: 10 0 do i . loop (prints 0 1 2...d e f).
i	(-- n)	Loop index.
j	(-- n)	Loop index for next enclosing loop.
leave	(--)	Exit from do...loop.
loop	(--)	End of do...loop.

case Statement

```
( value )
case
2 of ." it was two" endof
0 of ." it was zero" endof
." it was " dup . (optional default clause)
endcase
```

Program Execution Control Commands

TABLE 1-37 Program Execution Control Commands

abort	(--)	Abort current execution and interpret keyboard commands.
abort" ccc"	(abort? --)	If flag is true, abort and display message.
eval	(adr len --)	Interpret Forth source from an array.
execute	(xt --)	Execute the word whose execution token is on the stack.
exit	(--)	Return from the current word. (Cannot be used in counted loops.)
quit	(--)	Same as abort, but leave stack intact.

Alternate Address Space Access Commands

TABLE 1-38 Alternate Address Space Access Commands

spacec!	(byte adr asi --)	Store the byte at asi and address.
spacec@	(adr asi -- byte)	Fetch the byte from asi and address.
spaced!	(n1 n2 adr asi --)	Store the two values at asi and address. Order is implementation-dependent.
spaced@	(adr asi -- n1 n2)	Fetch the two values from asi and address. Order is implementation-dependent.

TABLE 1–38 Alternate Address Space Access Commands *(continued)*

spacel!	<code>(long adr asi --)</code>	Store the 32-bit word at asi and address.
spacel@	<code>(adr asi -- long)</code>	Fetch the 32-bit word from asi and address.
spacew!	<code>(word adr asi --)</code>	Store the 16-bit word at asi and address.
spacew@	<code>(adr asi -- word)</code>	Fetch the 16-bit word from asi and address.
spacex!	<code>(x adr asi --)</code>	Store the 64-bit word at asi and address.
spacex@	<code>(adr asi -- x)</code>	Fetch the 64-bit word from asi and address.

Cache Manipulation Commands

TABLE 1–39 Cache Manipulation Commands

clear-cache	<code>(--)</code>	Invalidate all cache entries.
cache-off	<code>(--)</code>	Disable the cache.
cache-on	<code>(--)</code>	Enable the cache.
flush-cache	<code>(--)</code>	Write back any pending data from the cache.

Multiprocessor Command

TABLE 1-40 Multiprocessor Command

switch-cpu	(cpu# --)	Switch to indicated CPU.
------------	-------------	--------------------------

Program Execution Control Commands

TABLE 1-41 Program Execution Control Commands

abort	(--)	Abort current execution and interpret keyboard commands.
abort" ccc"	(abort? --)	If flag is true, abort and display message.
eval	(adr len --)	Interpret Forth source from an array.
execute	(xt --)	Execute the word whose execution token is on the stack.
exit	(--)	Return from the current word. (Cannot be used in counted loops.)
quit	(--)	Same as abort, but leave stack intact.