



System Management Services (SMS) 1.3 Reference Manual

Sun Microsystems, Inc.
4150 Network Circle
Santa Clara, CA 95054 U.S.A.
650-960-1300

Part No. 816-5319-10
January 2003, Revision A

Send comments about this document to: docfeedback@sun.com

Copyright 2003 Sun Microsystems, Inc. 4150 Network Circle, Santa Clara, CA 95054 U.S.A. All rights reserved.

This product or document is distributed under licenses restricting its use, copying, distribution, and decompilation. No part of this product or document may be reproduced in any form by any means without prior written authorization of Sun and its licensors, if any. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, docs.sun.com, Sun Fire, OpenBoot PROM, and Solaris are trademarks, registered trademarks, or service marks of Sun Microsystems, Inc. in the U.S. and other countries. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon an architecture developed by Sun Microsystems, Inc.

The OPEN LOOK and Sun™ Graphical User Interface was developed by Sun Microsystems, Inc. for its users and licensees. Sun acknowledges the pioneering efforts of Xerox in researching and developing the concept of visual or graphical user interfaces for the computer industry. Sun holds a non-exclusive license from Xerox to the Xerox Graphical User Interface, which license also covers Sun's licensees who implement OPEN LOOK GUIs and otherwise comply with Sun's written license agreements.

Federal Acquisitions: Commercial Software—Government Users Subject to Standard License Terms and Conditions.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

Copyright 2003 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, CA 95054 Etats-Unis. Tous droits réservés.

Ce produit ou document est distribué avec des licences qui en restreignent l'utilisation, la copie, la distribution, et la décompilation. Aucune partie de ce produit ou document ne peut être reproduite sous aucune forme, par quelque moyen que ce soit, sans l'autorisation préalable et écrite de Sun et de ses bailleurs de licence, s'il y en a. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, docs.sun.com, Sun Fire, OpenBoot PROM, et Solaris sont des marques de fabrique ou des marques déposées, ou marques de service, de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays. Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'interface d'utilisation graphique OPEN LOOK et Sun™ a été développée par Sun Microsystems, Inc. pour ses utilisateurs et licenciés. Sun reconnaît les efforts de pionniers de Xerox pour la recherche et le développement du concept des interfaces d'utilisation visuelle ou graphique pour l'industrie de l'informatique. Sun détient une licence non exclusive de Xerox sur l'interface d'utilisation graphique Xerox, cette licence couvrant également les licenciés de Sun qui mettent en place l'interface d'utilisation graphique OPEN LOOK et qui en outre se conforment aux licences écrites de Sun.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFAÇON.



Adobe PostScript

Contents

Intro	1
addboard	5
addcodlicense	13
addtag	15
cancelcmdsync	19
codd	25
console	27
dca	31
deleteboard	33
deletcodlicense	39
deletetag	41
disablecomponent	43
dsmd	49

dxs 51

enablecomponent 53

esmd 59

flashupdate 63

fomd 69

frad 71

help 73

hpost 75

kmd 77

hwad 81

initcmdsync 83

mand 89

mld 91

moveboard 93

osd 103

pcd 105

poweroff 107

poweron 111

rcfgadm 115

reset 133

resetsc 135

runcmdsync 137

savecmdsync 139

setbus 145

setdatasync 149

setdate 153

setdefaults 155

setfailover 159

setkeyswitch 161

setobpparams 165

setupplatform 169

showboards 175

showbus 183

showcmdsync 187

showcodlicense 189

showcodusage 191

showcomponent 197

showdatasync 203

showdate 207

showdevices 209

showenvironment 215

showfailover 227

showkeyswitch 231

showlogs 233

showobpparams 237

showplatform 239

showxirstate 249

smsbackup 253

smsconfig 255

smsconnectsc 269

smsinstall 273

smsrestore 277

smsupgrade 279

smsversion 285

ssd 289

tmd 291

wcapp 293

Preface

Both novice users and those familiar with the SunOS operating system can use online man pages to obtain information about the system and its features. A man page is intended to answer concisely the question “What does it do?” In general, man pages comprise a reference manual. They are not intended to be a tutorial.

Overview

The following contains a brief description of the SMS man pages and the information a man page references:

- Section 1M describes, in alphabetical order, commands that are used chiefly for system maintenance and administration purposes.

Below is a generic format for man pages. The man pages of each manual section generally follow this order but include only necessary headings. For example, if there are no notes to report, there is no NOTES section. See the `intro` pages for more information and detail about each section, and `man(1)` for more information about man pages in general.

NAME	This section gives the names of the commands or functions documented, followed by a brief description of what they do.
SYNOPSIS	<p>This section shows the syntax of commands or functions. When a command or file does not exist in the standard path, its full path name is shown. Options and arguments are alphabetized, with single-letter arguments first, and options with arguments next, unless a different argument order is required.</p> <p>The following special characters are used in this section:</p> <ul style="list-style-type: none">[] Brackets. The option or argument enclosed in these brackets is optional. If the brackets are omitted, the argument must be specified.... Ellipses. Several values may be provided for the previous argument, or the previous argument can be specified multiple times, for example <code>"filename..."</code>. Separator. Only one of the arguments separated by this character can be specified at one time.

{ } Braces. The options and/or arguments enclosed within braces are interdependent, such that everything enclosed must be treated as a unit.

DESCRIPTION

This section defines the functionality and behavior of the service. Thus it describes concisely what the command does. It does not discuss OPTIONS or cite EXAMPLES. Interactive commands, subcommands, requests, macros, functions and such, are described under USAGE.

OPTIONS

This lists the command options with a concise summary of what each option does. The options are listed literally and in the order in which they appear in the SYNOPSIS section. Possible arguments to options are discussed under the option, and where appropriate, default values are supplied.

OPERANDS

This section lists the command operands and describes how they affect the actions of the command.

RETURN VALUES

If the man page documents functions that return values, this section lists these values and describes the conditions under which they are returned. If a function can return only constant values, such as 0 or -1, these values are listed in tagged paragraphs. Otherwise, a single paragraph describes the return values of each function. Functions declared void do not return values, so they are not discussed in RETURN VALUES.

ERRORS

On failure, most functions place an error code in the global variable `errno`, indicating why they failed. This section lists alphabetically all error codes, a function can generate and describes the conditions that cause each error. When more than one condition can cause the same error, each condition is described in a separate paragraph under the error code.

USAGE	<p>This section lists special rules, features and commands that require in-depth explanations. The subsections listed below are used to explain built-in functionality:</p> <ul style="list-style-type: none"> Commands Modifiers Variables Expressions Input Grammar
EXAMPLES	<p>This section provides examples of usage, including how to use a command or function. Wherever possible, a complete example, including command line entry and machine response, is shown. Examples are followed by explanations, variable substitution rules, or returned values. Most examples illustrate concepts from the SYNOPSIS, DESCRIPTION, OPTIONS, and USAGE sections.</p>
ENVIRONMENT VARIABLES	<p>This section lists any environment variables that the command or function affects, followed by a brief description of the effect.</p>
EXIT STATUS	<p>This section lists the values the command returns to the calling program or shell and the conditions that cause these values to be returned. Usually, zero is returned for successful completion and values other than zero for various error conditions.</p>
FILES	<p>This section lists all filenames referred to by the man page, files of interest, and files created or required by commands. Each filename is followed by a descriptive summary or explanation.</p>
ATTRIBUTES	<p>This section lists characteristics of commands, utilities, and device drivers by defining the attribute type and its corresponding value. See <code>attributes(5)</code> for more information.</p>
SEE ALSO	<p>This section lists references to other man pages, in-house documentation, and outside publications.</p>

NOTES

This section lists additional information that does not belong anywhere else on the page. It takes the form of an aside to the user, covering points of special interest. Critical information is never covered here.

NAME	Intro - SMS Administration																																										
DESCRIPTION	This section describes the commands executed in the system management software environment.																																										
LIST OF COMMANDS	The following commands are supported:																																										
	<table border="0"> <tr> <td>addboard</td> <td>Assign, connect, and configure a board to a domain.</td> </tr> <tr> <td>addcodlicense</td> <td>Install a Capacity on Demand (COD) license key on the system controller (SC)</td> </tr> <tr> <td>addtag</td> <td>Assign a domain name (tag) to a domain</td> </tr> <tr> <td>cancelcmdsync</td> <td>Command synchronization command</td> </tr> <tr> <td>codd</td> <td>Capacity on Demand daemon</td> </tr> <tr> <td>console</td> <td>Access the domain console.</td> </tr> <tr> <td>dca</td> <td>Domain configuration agent</td> </tr> <tr> <td>deleteboard</td> <td>Unconfigure, disconnect, and unassign a system board from a domain.</td> </tr> <tr> <td>deletecodlicense</td> <td>Remove a Capacity on Demand (COD) license key on the system controller (SC).</td> </tr> <tr> <td>deletetag</td> <td>Remove the domain tag name associated with the domain</td> </tr> <tr> <td>disablecomponent</td> <td>Add the specified component to the specified blacklist file.</td> </tr> <tr> <td>dsmd</td> <td>Domain status monitoring daemon</td> </tr> <tr> <td>dxs</td> <td>Domain X server</td> </tr> <tr> <td>enablecomponent</td> <td>Remove the specified component from the specified blacklist</td> </tr> <tr> <td>esmd</td> <td>Environmental status monitoring daemon</td> </tr> <tr> <td>flashupdate</td> <td>Update the Flash PROMs located on the CPU boards, MaxCPU boards and system controllers (SC).</td> </tr> <tr> <td>fomd</td> <td>Failover management daemon</td> </tr> <tr> <td>frad</td> <td>FRU access daemon</td> </tr> <tr> <td>help</td> <td>Display help information for SMS commands.</td> </tr> <tr> <td>hpost</td> <td>Sun Fire 15K/12K power-on self-test (POST) control application</td> </tr> <tr> <td>hwad</td> <td>Hardware access daemon</td> </tr> </table>	addboard	Assign, connect, and configure a board to a domain.	addcodlicense	Install a Capacity on Demand (COD) license key on the system controller (SC)	addtag	Assign a domain name (tag) to a domain	cancelcmdsync	Command synchronization command	codd	Capacity on Demand daemon	console	Access the domain console.	dca	Domain configuration agent	deleteboard	Unconfigure, disconnect, and unassign a system board from a domain.	deletecodlicense	Remove a Capacity on Demand (COD) license key on the system controller (SC).	deletetag	Remove the domain tag name associated with the domain	disablecomponent	Add the specified component to the specified blacklist file.	dsmd	Domain status monitoring daemon	dxs	Domain X server	enablecomponent	Remove the specified component from the specified blacklist	esmd	Environmental status monitoring daemon	flashupdate	Update the Flash PROMs located on the CPU boards, MaxCPU boards and system controllers (SC).	fomd	Failover management daemon	frad	FRU access daemon	help	Display help information for SMS commands.	hpost	Sun Fire 15K/12K power-on self-test (POST) control application	hwad	Hardware access daemon
addboard	Assign, connect, and configure a board to a domain.																																										
addcodlicense	Install a Capacity on Demand (COD) license key on the system controller (SC)																																										
addtag	Assign a domain name (tag) to a domain																																										
cancelcmdsync	Command synchronization command																																										
codd	Capacity on Demand daemon																																										
console	Access the domain console.																																										
dca	Domain configuration agent																																										
deleteboard	Unconfigure, disconnect, and unassign a system board from a domain.																																										
deletecodlicense	Remove a Capacity on Demand (COD) license key on the system controller (SC).																																										
deletetag	Remove the domain tag name associated with the domain																																										
disablecomponent	Add the specified component to the specified blacklist file.																																										
dsmd	Domain status monitoring daemon																																										
dxs	Domain X server																																										
enablecomponent	Remove the specified component from the specified blacklist																																										
esmd	Environmental status monitoring daemon																																										
flashupdate	Update the Flash PROMs located on the CPU boards, MaxCPU boards and system controllers (SC).																																										
fomd	Failover management daemon																																										
frad	FRU access daemon																																										
help	Display help information for SMS commands.																																										
hpost	Sun Fire 15K/12K power-on self-test (POST) control application																																										
hwad	Hardware access daemon																																										

<code>initcmdsync</code>	Command synchronization command
<code>kmd</code>	SMS key management daemon
<code>mand</code>	Management network daemon
<code>mld</code>	Message-logging daemon
<code>moveboard</code>	Move a board from one domain to another.
<code>osd</code>	OpenBoot PROM server daemon
<code>pcd</code>	Platform configuration database daemon
<code>poweroff</code>	Control power off
<code>poweron</code>	Control power on
<code>rcfgadm</code>	Remote configuration administration
<code>reset</code>	Send reset to all CPU ports of a specified domain.
<code>resetsc</code>	Reset the other system controller (SC).
<code>runcmdsync</code>	Prepare a specified script for recovery after a failover.
<code>savecmdsync</code>	Command synchronization command
<code>setbus</code>	Perform dynamic bus reconfiguration on active expanders in a domain.
<code>setdatasync</code>	Modify the data propagation list used in data synchronization.
<code>setdate</code>	Set the date and time for the system controller (SC) or a domain.
<code>setdefaults</code>	Remove all instances of a previously active domain.
<code>setfailover</code>	Modify the state of the system controller (SC) failover mechanism.
<code>setkeyswitch</code>	Change the position of the virtual keyswitch.
<code>setobpparams</code>	Set up OpenBoot PROM variables for a domain.
<code>setupplatform</code>	Set up the available component list for domains.
<code>showboards</code>	Show the assignment information and status of the boards.
<code>showbus</code>	Display the bus configuration of expanders in active domains.
<code>showcmdsync</code>	Display the current command synchronization list.
<code>showcodlicense</code>	Display the current Capacity on Demand (COD) right-to-use (RTU) licenses stored in the COD license database.

<code>showcodusage</code>	Display the current usage statistics for Capacity on Demand (COD) resources.
<code>showcomponent</code>	Display the blacklist status for a component.
<code>showdatasync</code>	Display the status of system controller (SC) data synchronization for failover.
<code>showdate</code>	Display the date and time for the system controller (SC) or a domain.
<code>showdevices</code>	Display system board devices and resource usage information.
<code>showenvironment</code>	Display the environmental data.
<code>showfailover</code>	Display system controller (SC) failover status or role
<code>showkeyswitch</code>	Display the position of the virtual keyswitch.
<code>showlogs</code>	Display message log files.
<code>showobpparams</code>	Display OpenBoot PROM bring up parameters for a domain.
<code>showplatform</code>	Display the board available component list and domain state for each domain.
<code>showxirstate</code>	Display CPU dump information after sending a reset pulse to the processors.
<code>smsbackup</code>	Back up the SMS environment.
<code>smsconfig</code>	Configure the SMS environment.
<code>smsconnectsc</code>	Access a remote SC console.
<code>smsinstall</code>	Install the SMS environment
<code>smsrestore</code>	Restore the SMS environment
<code>smsupgrade</code>	Upgrade the SMS environment
<code>smsversion</code>	Change the active version of SMS to another co-resident version of the SMS software.
<code>ssd</code>	SMS startup daemon.
<code>tmd</code>	Task management daemon.
<code>wcapp</code>	wPCI application daemon.



NAME	addboard - assign, connect and configure a board to a domain
SYNOPSIS	<p>addboard -d <i>domain_indicator</i> [-c <i>function</i>] [-r <i>retry_count</i> [-t <i>timeout</i>]] [-q] [-f] [-y -n] <i>location</i> ...</p> <p>addboard -h</p>
DESCRIPTION	<p>addboard(1M) assigns, connects, and configures a <i>location</i> to the domain <i>domain_id</i> or <i>domain_tag</i>.</p> <p>The board must be either available or assigned to the domain to which it is being added. The -c option is used to specify the transition of the board from the current configuration state to a new configuration state. Configuration states are assign, connect, and configure. If the -c option is not specified, the default expected configuration state is configure.</p> <p>Note – addboard performs tasks synchronously and does not return control to the user until the command is complete. If the board is not powered on or tested and a -c connect configure option is specified, then the command powers on the board and tests it.</p> <p>Note – If only one board is specified and it is in the automatic system recovery (ASR) blacklist file, addboard displays an error message and exits. If more than one board is specified, addboard displays a message that the board is being skipped, and then goes on to the next board or, after the last board, exits.</p> <p>Note – If the addboard command fails, a board does not return to its original state. A dxs or dca error message is logged to the domain. If the error is recoverable, you can retry the command. If it is unrecoverable, you need to reboot the domain in order to use that board.</p>

OPTIONS

The following options are supported:

`-c` *function*

Valid *function* values are `assign`, `connect`, and `configure`. This option is used to control the configuration state transition. Each successive function builds upon the last. For example, `configure` first assigns and then connects the board before configuring it.

The possible transition states and their meanings are as follows:

`assign` Assigns the board to the logical domain. This is a board state in which the domain has sole access to the board; however, the board is not active. Once assigned, the board can be connected or configured into the domain with the use of either `setkeyswitch on` or the `connect` or `configure` options.

`connect` Assigns the board to the logical domain (if it is not already assigned). Transitions the board into the `connected|unconfigured` state. In this state the system board is assigned to the logical domain and connected (becomes active). This state allows normal system access to hardware resources on the board, but the hardware resources of the board are not represented by the normal Solaris software data structures and thus are not available for use by the Solaris operating environment. Operations allowed on the board are limited to configuration administration operations. This is an intermediate state and does not have any standalone implementation at this time.

`configure` Assigns the board to the logical domain (if it is not already assigned). Transitions the board into the `connected|configured` state. In this state the board is not only assigned, active, and connected to a domain, but also configured into the Solaris operating environment. The hardware resources on the board can be used by Solaris software.

- d** *domain_indicator* Specifies the domain using one of the following:
- domain_id* – ID for a domain. Valid *domain_ids* are A–R and are not case sensitive.
 - domain_tag* – Name assigned to a domain using `addtag(1M)`.
- f** Forces the specified action to occur. Typically, this is a hardware-dependent override of a safety feature. Forcing a state change operation can allow use of the hardware resources of an occupant that is not in the `ok` or `unknown` conditions, at the discretion of any hardware-dependent safety checks.
- h** Help. Displays usage descriptions.
- Note** – Use alone. Any option specified in addition to `-h` is ignored.
- n** Automatically answers no to all prompts. Prompts are displayed unless used with the `-q` option.
- q** Quiet. Suppresses all messages to `stdout` including prompts.
- When used alone `-q` defaults to the `-n` option for all prompts.
- When used with either the `-y` or the `-n` option, `-q` suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen.
- r** *retry_count* These command arguments enable the user to specify retries in case of failures encountered during state transitions. The `-r` *retry_count* option can be used alone and indicates the number of times the configuration state change request should be retried by the domain. The `-t` *timeout* option cannot be used without the `-r` *retry_count* option and specifies the number of seconds that the domain should wait before the next retry is made. If the `-t` *timeout* is not specified, the default *timeout* is zero, meaning that the request is retried immediately.
- t** *timeout*
- y** Automatically answers yes to all prompts. Prompts are displayed unless used with the `-q` option.

OPERANDS

The following operands are supported:

location List of board locations separated by a space. Multiple *location* arguments are permitted.

The following *location* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

Note – Use showboards(1M) to display board type.

EXTENDED DESCRIPTION**Group Privileges Required**

If you have platform administrator privileges, you can perform only the `-c assign` option.

If you have domain administrator or configurator privileges, you can execute this command, but only on your respective domains. If the board(s) are not already assigned to the domain, the board(s) must be in the available component list of the domain.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Assigning Boards to Domain C

To assign four boards to domain C you must have platform privileges or domain privileges and the boards must be in the domain available component list.

```
sc0:sms-user:> addboard -d C -c assign SB0 IO1 SB1 SB2
SB0 assigned to domain: C
IO1 assigned to domain: C
SB1 assigned to domain: C
SB2 assigned to domain: C
sc0:sms-user:>
```

EXAMPLE 2 Assigning a Blacklisted Board to Domain C

To assign four boards to domain C you must have platform privileges or domain privileges and the boards must be in the domain available component list.

```
sc0:sms-user:> addboard -d C -c assign SB0 IO2 SB1 SB2
SB0 assigned to domain: C
IO2 assigned to domain: C
Warning: IO2 is blacklisted.
You will not be able to connect or configure it.
SB1 assigned to domain: C
SB2 assigned to domain: C
sc0:sms-user:>
```

EXAMPLE 3 Connecting Boards to Domain A

This example connects three boards to domain A, setting retries to five and timeout to five seconds. You must have domain privileges for domain A.

```
sc0:sms-user:> addboard -d A -c connect -r 5 -t 5 IO3
IO4 IO5
```

EXAMPLE 4 Connecting Boards Containing an ASR Blacklisted Board to Domain C

You must have domain privileges for domain C. Blacklisted boards are skipped.

```
sc0:sms-user:> addboard -d C -c connect SB0
SB0 is blacklisted. Exiting.
sc0:sms-user:>
```

EXAMPLE 5 Configuring Boards to Domain A

You must have domain privileges for domain A.

```
sc0:sms-user:> addboard -d A -c configure IO3 IO4 IO5
```

EXAMPLE 6 Configuring Boards Containing an ASR Blacklisted Board to Domain A

You must have domain privileges for domain A. Blacklisted boards are skipped.

```
sc0:sms-user:> addboard -d A -c configure IO7 IO8 IO9
Skipping IO8. It is blacklisted.
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
1	No acknowledge.
2	Not supported.

3	Operation not supported.
4	Invalid privileges.
5	Busy.
6	System busy.
7	Data error.
8	Library error.
9	No library.
10	Insufficient condition.
11	Invalid.
12	Error.
13	A PID does not exist.
14	Invalid attribute.
30	Invalid board ID type.
31	Invalid permissions.
32	Assigned to another domain.
33	Unable to get permissions.
34	Unable to get domain board info.
35	Unable to get active board list.
36	Unable to get assigned board list.
38	Solaris not running.
39	Unable to assign/unassign.
40	Unable to get domain permissions.
41	Unable to get platform permissions.
51	Invalid domain.
52	Invalid privileges.
53	Internal error.
54	Library error.
56	DR command syntax error.
57	Location already assigned.
58	Internal error.

- 59 Component blacklisted.
- 60 Unable to get ASR blacklist.
- 61 Unable to get domain blacklist.
- 62 Unable to get platform blacklist.
- 70 DR operation failed.

FILES The following files are used by this command.

<code>/etc/opt/SUNWSMS/config/asr/blacklist</code>	List of components excluded by esmd.
<code>/etc/opt/SUNWSMS/config/platform/blacklist</code>	List of platform components excluded.
<code>/etc/opt/SUNWSMS/config/<i>domain_id</i>/blacklist</code>	List of domain components excluded.

Note – This file is created and used internally and should *not* be edited manually. To remove a component from the ASR blacklist file, use `enablecomponent(1M)`.

ATTRIBUTES See `attributes(5)` for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **addtag(1M)**, **enablecomponent(1M)**, **esmd(1M)**, **showcomponent(1M)**



NAME	addcodlicense - add a Capacity on Demand (COD) right-to-use (RTU) license key to the COD license database
SYNOPSIS	addcodlicense <i>license-signature</i> addcodlicense -h
DESCRIPTION	addcodlicense(1M) adds the COD RTU specified license key to the COD license database on the system controller (SC). Note – Before you run this command, you must obtain a COD license key from the Sun License Center. For details on COD RTU license keys, refer to the <i>System Management Services (SMS) 1.3 Administrator Guide</i> .
OPTIONS	The following option is supported: -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored.
OPERANDS	The following operand is supported: <i>license-signature</i> Specifies the COD RTU license key to be added to the COD license database.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator group privileges to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Adding a COD RTU License Key sc0:sms-user:> addcodlicense \ 01:5014936C37048:01001:0201010302:4:20020430:jWGJdg/ kx78b0wyK2xrqIg
EXIT STATUS	The following exit values are returned: 0 Successful completion. 1 Invalid usage. 2 Invalid group privileges. 3 Duplicate license exists in the COD license database.

- 4 Invalid license key.
- >3 An internal error occurred. For further information, see
/var/opt/SUNWSMS/adm/platform/messages.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

codd(1M), **deletecodlicense**(1M), **showcodlicense**(1M), **showcodusage**(1M)

NAME	addtag - assign a domain name (tag) to a domain
SYNOPSIS	addtag -d <i>domain_indicator</i> [-q] [-y -n] <i>new_tag</i> addtag -h
DESCRIPTION	addtag(1M) adds the specified domain tag name (<i>new_tag</i>) to a domain (<i>domain_id</i> <i>domain_tag</i>). Only one name tag can be assigned to a domain, and it must be unique across all domains. addtag can also be used to change the <i>domain_tag</i> .
OPTIONS	The following options are supported: -d <i>domain_indicator</i> Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain. -h Help. Displays usage descriptions. Note - Use alone. Any option specified in addition to -h is ignored. -n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option. -q Quiet. Suppresses all messages to <code>stdout</code> including prompts. When used alone -q defaults to the -n option for all prompts. When used with either the -y or the -n option, -q suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen. -y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.
OPERANDS	The following operands are supported: <i>new_tag</i> New tag name assigned to a domain. See Extended Description for a description of invalid domain names.

**EXTENDED
DESCRIPTION****Domain Name Tag
Restrictions**

The following restrictions are required on a domain name tag:

- No single character names are permitted.
- All domain name tags must be unique across all domains within a single chassis.
- Tags must adhere to the same restrictions as defined for Solaris software node names. Currently, the size restriction is set to 2 to 64 characters.

**Group Privileges
Required**

You must have platform administrator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Assigning the Tag `eng2` to Domain A With Prompts

```
sc0:sms-user:> addtag -d A eng2
```

If a tag for this domain exists you are prompted.

EXAMPLE 2 Assigning the Tag `eng2` to Domain A Using the `-y` Option

```
sc0:sms-user:> addtag -d A -y eng2
```

Prompts are displayed and are automatically answered yes. This forces the domain tag to be set even if a tag already exists for this domain.

EXAMPLE 3 Assigning the Tag `eng2` to Domain A Using the `-n` Option

```
sc0:sms-user:> addtag -d A -n eng2
```

Prompts are displayed and are automatically answered no. This sets the tag for this domain unless it has already been set.

EXAMPLE 4 Assigning the Tag `eng2` to Domain A Using the `-qy` Options

```
sc0:sms-user:> addtag -d A -qy eng2
```

You are not prompted.

EXAMPLE 5 Assigning the Tag `eng2` to Domain A Using the `-qn` Options

```
sc0:sms-user:> addtag -d A -qn eng2
```

The example assigns the tag `eng2` to Domain A only if it has not already been set. You are not prompted.

EXAMPLE 6 Assigning the Tag `eng2` to Domain A Using the `-q` Option

```
sc0:sms-user:> addtag -d A -q eng2
```

The example assigns the tag `eng2` to Domain A if it is not already set. If it is set, the command does not change it. You are not prompted.

EXIT STATUS The following exit values are returned:

0	Successful completion.
>0	An error occurred.

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **deletetag**(1M)



NAME	cancelcmdsync - command synchronization command
SYNOPSIS	<p>cancelcmdsync <i>cmdsync_descriptor</i></p> <p>initcmdsync <i>script_name</i> [<i>parameters</i>]</p> <p>savecmdsync <i>-M identifier cmdsync_descriptor</i></p> <p>[cancel init save]cmdsync -h</p>
DESCRIPTION	<p>The command synchronization commands work together to control the recovery of user-defined scripts interrupted by a system controller (SC) failover. Insert the following commands in user-defined scripts to enable command synchronization:</p> <p>initcmdsync Creates a command synchronization descriptor that identifies the script to be recovered.</p> <p>This descriptor is placed on a command synchronization list that identifies the scripts and commands to be restarted on the new main SC after a failover.</p> <p>savecmdsync Adds a marker that identifies a location in the script from which processing can be resumed after a failover.</p> <p>cancelcmdsync Removes a command synchronization descriptor from the command synchronization list. This ensures that the script is run only once and not after subsequent failovers.</p> <p>Be sure that all exit paths of a script have a <code>cancelcmdsync</code> sequence to remove the descriptor from the command synchronization list. If you do not remove the descriptor and a failover occurs, the script is rerun on the new main SC.</p> <p>Note – Both an <code>initcmdsync</code> and a <code>cancelcmdsync</code> sequence must be contained within a script to enable command synchronization. The use of the <code>savecmdsync</code> command is optional and marks only specific points in a script from which processing can be resumed. If specific restart points are not necessary, consider using <code>runcmdsync(1M)</code> instead.</p>
OPTIONS	<p>The following options are supported:</p> <p><i>cmdsync_descriptor</i> Specifies the command synchronization descriptor that identifies the user-defined script. This descriptor is the standard output value returned by the <code>initcmdsync</code> command.</p>

- `-h` Help. Displays usage descriptions.
- Note** – Use alone. Any option specified in addition to `-h` is ignored.
- `-M identifier` Marks a location in the script from which the script can be resumed after a failover. The identifier must be a positive integer.
- `parameters` Specifies the options or parameters associated with the user-defined script. These parameters are stored on the spare SC and are used to restart the specified script after a failover.
- `script_name` Identifies the name of the user-defined script to be synchronized. `script_name` must be the absolute path name of an executable command. The command must exist in the same location on both SCs.

**EXTENDED
DESCRIPTION**

The command synchronization commands are inserted at certain logical points within a user-defined script.

For instance, a Korn shell script might be structured as follows:

```
# MAIN CODE STARTS HERE
# Be sure to use a cleanup procedure to handle any
# interrupts.
# Use the cancelcmdsync to remove the script from the
# command synchronization list. Otherwise, the command
# will get restarted on the new main SC.
#
clean_up () {
    cancelcmdsync $desc
    exit
}

# Declare the clean_up function to capture system signals
# and cleanup.
trap "clean_up" INT HUP TERM QUIT PWR URG
goto_label=1
# Process the arguments, capturing the -M marker point
# if provided
#
for arg in $*; do
    case $arg in
        -M )
            goto_label=$arg;;
        .
        .
    esac
done
# Place this script and all its parameters in the command
# synchronization list, which indicates the commands to
# be restarted after an SC failover.
#
# NOTE: The script must be executable by the user defined
# in fowd.cf and reside in the same directory on both the
# main and the spare SC.
```

```

# If the command is not part of the defined PATH for
# the user, the absolute filename must be passed with the
# initcmdsyc command
#
initcmdsyc script_name parameters
# The marker point is stored in the goto_label variable.
# Keep executing this script until all cases have been
# processed or an error is detected.
#
while (( $goto_label != 0 )) ; do
#
# Each case should represent a synchronization point
# in the script.
#
case $goto_label in
#
# Step 1: Do something
#
1 )          do_something
              .
              .
              .

# Execute the savecmdsyc command with the script's
# descriptor and a unique marker to save the position.
# If a failover occurs here, the commands represented in
# the next goto_label (2) will be resumed.
#
          savecmdsyc -M $(( $goto_label + 1 )) $desc
          goto_label=$(( $goto_label + 1 ))
          ;;

#
# Step 2: Do more things
#
2 )          do_more_things
              .
              .
              .
          savecmdsyc -M $(( $goto_label + 1 )) $desc
          goto_label=$(( $goto_label + 1 ))
          ;;

#
# Step 3: Finish the last step and set the goto_label to 0
# so that the script ends.
3 )
          finish_last_step
          .
          .
          .
          goto_label=0
          ;;

        esac
done
# END OF MAIN CODE
# Remember to execute cancelcmdsyc to remove the script from the
# command synchronization list. Otherwise, the command will be restarted
# after the failover.
#
cancelcmdsyc $desc

```

**Group Privileges
Required**

You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXIT STATUS

The following exit values are returned:

0 Successful completion.
>0 An error occurred.

Note – The standard output for `initcmdsync` contains the command synchronization descriptor. Also, when failover is disabled (after a failover or in a single SC environment), scripts that contain synchronization commands generate error messages to the platform log file and return nonzero exit codes. These messages can be ignored.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

runcmdsync(1M), **showcmdsync**(1M)



NAME	codd - Capacity on Demand (COD) daemon																		
SYNOPSIS	codd																		
DESCRIPTION	<p>codd(1M) is a process that runs on the main system controller (SC). This process does the following:</p> <ul style="list-style-type: none"> ■ Monitors the COD resources being used and verifies that the resources used are in agreement with the COD right-to-use (RTU) licenses in the COD license database file. Also logs any warning messages. ■ Provides information on installed licenses, resource use, and board status. ■ Handles the requests to add or delete COD RTU license keys. ■ Configures headroom and COD RTU licenses reserved for domains. <p>This daemon is started automatically by the <code>ssd(1M)</code> daemon. If the <code>codd</code> daemon terminates, it is restarted automatically. Do <i>not</i> manually start this daemon from the command line.</p>																		
EXTENDED DESCRIPTION	<p>The <code>codd</code> daemon releases COD RTU licenses when the following events occur:</p> <ul style="list-style-type: none"> ■ A COD CPU board is powered off or disconnected from a running domain. ■ A domain virtual keyswitch state changes from <code>on/secure</code> to <code>standby/off</code> <p>Clients of the <code>codd</code> daemon include:</p> <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top;"><code>addcodlicense(1M)</code></td> <td>Adds a COD RTU license key to the COD license database on the system controller (SC)</td> </tr> <tr> <td style="vertical-align: top;"><code>dxs(1M)</code></td> <td>Domain X server daemon</td> </tr> <tr> <td style="vertical-align: top;"><code>deletecodlicense(1M)</code></td> <td>Removes a COD RTU license from the SC.</td> </tr> <tr> <td style="vertical-align: top;"><code>hpost(1M)</code></td> <td>Sun Fire 15K/12K power-on self-test (POST) control application</td> </tr> <tr> <td style="vertical-align: top;"><code>setdefaults(1M)</code></td> <td>Remove all instances and reset reserved COD RTUs for a previously active domain.</td> </tr> <tr> <td style="vertical-align: top;"><code>setupplatform(1M)</code></td> <td>Sets up the available component list and reserved COD RTUs for domains and configures platform COD headroom.</td> </tr> <tr> <td style="vertical-align: top;"><code>showcodlicense(1M)</code></td> <td>Shows installed COD RTU licenses.</td> </tr> <tr> <td style="vertical-align: top;"><code>showcodusage(1M)</code></td> <td>Shows current usage statistics for COD resources.</td> </tr> <tr> <td style="vertical-align: top;"><code>showplatform(1M)</code></td> <td>Displays the board available component list, domain state, and reserved COD RTUs for each domain, and platform COD headroom.</td> </tr> </table>	<code>addcodlicense(1M)</code>	Adds a COD RTU license key to the COD license database on the system controller (SC)	<code>dxs(1M)</code>	Domain X server daemon	<code>deletecodlicense(1M)</code>	Removes a COD RTU license from the SC.	<code>hpost(1M)</code>	Sun Fire 15K/12K power-on self-test (POST) control application	<code>setdefaults(1M)</code>	Remove all instances and reset reserved COD RTUs for a previously active domain.	<code>setupplatform(1M)</code>	Sets up the available component list and reserved COD RTUs for domains and configures platform COD headroom.	<code>showcodlicense(1M)</code>	Shows installed COD RTU licenses.	<code>showcodusage(1M)</code>	Shows current usage statistics for COD resources.	<code>showplatform(1M)</code>	Displays the board available component list, domain state, and reserved COD RTUs for each domain, and platform COD headroom.
<code>addcodlicense(1M)</code>	Adds a COD RTU license key to the COD license database on the system controller (SC)																		
<code>dxs(1M)</code>	Domain X server daemon																		
<code>deletecodlicense(1M)</code>	Removes a COD RTU license from the SC.																		
<code>hpost(1M)</code>	Sun Fire 15K/12K power-on self-test (POST) control application																		
<code>setdefaults(1M)</code>	Remove all instances and reset reserved COD RTUs for a previously active domain.																		
<code>setupplatform(1M)</code>	Sets up the available component list and reserved COD RTUs for domains and configures platform COD headroom.																		
<code>showcodlicense(1M)</code>	Shows installed COD RTU licenses.																		
<code>showcodusage(1M)</code>	Shows current usage statistics for COD resources.																		
<code>showplatform(1M)</code>	Displays the board available component list, domain state, and reserved COD RTUs for each domain, and platform COD headroom.																		

The `codd` daemon is a client of

<code>dsmd(1M)</code>	Domain status monitoring daemon
<code>frad(1M)</code>	FRU access daemon
<code>pcd(1M)</code>	Platform configuration database daemon
<code>setkeyswitch(1M)</code>	Virtual keyswitch control command

FILES

The following file is supported:

<code>/var/opt/SUNWSMS/adm/platform/messages</code>	Stores message files.
---	-----------------------

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addcodlicense(1M), **deletecodlicense**(1M), **dsmd**(1M), **dxs**(1M), **frad**(1M), **hpost**(1M), **pcd**(1M), **setdefaults**(1M), **setkeyswitch**(1M), **setupplatform**(1M), **showcodlicense**(1M), **showcodusage**(1M), **showplatform**(1M), **ssd**(1M)

NAME	console - access the domain console
SYNOPSIS	console -d <i>domain_indicator</i> [[-f] [-l] [-g] [-r]] [-e <i>escapeChar</i>] console -h
DESCRIPTION	<p>console(1M) creates a remote connection to the domain virtual console driver, making the window in which the command is executed a console window for the specified domain (<i>domain_id</i> or <i>domain_tag</i>). Many console commands can be attached simultaneously to a domain, but only one console has write permissions; all others have read-only permissions. Write permissions are in either locked or unlocked mode.</p> <p>If console is invoked without any options it comes up in exclusive locked write mode (option -f). An exclusive session forcibly detaches all other sessions from the domain virtual console.</p> <p>Locked write mode is more secure. It can be taken away only if another console is opened using console -f or ~* is entered from another running console window. In both cases the new console session is an exclusive session.</p> <p>Unlocked write permission is not as secure. It can be taken away if another console command is started using console -g, console -l, or console -f, or if ~@, ~&, or ~* is entered from another console window.</p> <p>console can utilize either IOSRAM or the network path for domain console communication. You can manually toggle the communication path by using the ~= (tilde-equal sign) command. Doing so is useful if the network becomes inoperable, in which case the console sessions appears to be hung.</p> <p>Tilde commands are described in EXTENDED DESCRIPTION.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-e <i>escapeChar</i> Set default escape character. Changes the escape character to be <i>escapeCharacter</i>. The default is ~ (tilde).</p> <p style="padding-left: 40px;">Valid escape characters are any <i>except</i> the following:</p> <p style="padding-left: 80px;"># @ ^ & ? * = . </p> <p style="padding-left: 40px;">See the note on rlogin in the Usage section that follows.</p>

- f Force option (the default). Opens a domain console window with locked write permission, terminates all other open sessions, and prevents new ones from being opened. This constitutes an exclusive session. Use it only when you need exclusive use of the console (e.g. for private debugging).
- Note** – To restore multiple-session mode, either release the lock (~^) or terminate the console session (~.).
- g Grab option. Opens a console window with unlocked write permission. If another session has unlocked write permission, that session becomes read-only. If another session has locked permission, this request is denied and the console window opens in read-only mode instead.
- h Help. Displays usage descriptions.
- Note** – Use alone. Any option specified in addition to -h is ignored.
- l Lock option. Opens a console window with locked write permission. If another session has unlocked write permission, that session becomes read-only. If another session has locked permission, the request is denied and the console window opens in read-only mode instead.
- r Opens a console window in read-only mode.

EXTENDED DESCRIPTION

Usage

In a domain console window, a tilde (~) that appears as the first character of a line is interpreted as an escape signal that directs `console` to perform some special action, as follows:

- ~? Status message.
- ~. Disconnect `console` session.
- ~# Break to OpenBoot PROM or `kadb`.
- ~@ Acquire unlocked write permission; see -g.
- ~^ Release write permission.
- ~= Toggle the communication path between the network and IOSRAM interfaces. You can use ~= only in Private mode (see ~*).
- ~& Acquire locked write permission; see -l. You can issue this signal during a read-only or unlocked write session.

`~*` Acquire locked write permission, terminate all other open sessions, and prevent new sessions from being opened; see `-f`. To restore multiple-session mode, either release the lock or terminate this session.

Note – `rlogin` also processes tilde-escape sequences whenever a tilde is entered at the beginning of a new line. If you need to send a tilde sequence at the beginning of a line and you are using `rlogin`, use two tildes (the first escapes the second for `rlogin`). Alternatively, do not enter a tilde at the beginning of a line when running inside of `rlogin`.

Note – If you use a `kill -9` command to terminate a console session, the window or terminal in which the console command was executed goes into raw mode and appears hung. To escape this condition, type `CTRL-j`, then `stty sane`, and then `CTRL-j`.

Group Privileges Required

You must have domain administrator privileges on the domain specified. Users with only platform group privileges are not allowed access to a domain console.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Opening a Console Window in Locked Mode in Domain a

```
sc0:sms-user:> console -d a -l
```

Note – In the domain console window, `vi(1)` runs properly and the escape sequences (tilde commands) work as intended only if the environment variable `TERM` has the same setting as that of the console window. For example:

```
sc0:sms-user:> setenv TERM xterm
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

ATTRIBUTES

See `attributes(5)` for descriptions of the following attributes:

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

`addtag(1M)`, `dxs(1M)`, `kill(1)`, `rlogin(1)`, `set(1)`, `stty(1)`, `vi(1)`, `xterm(1M)`



NAME	dca - domain configuration agent
SYNOPSIS	dca -d <i>domain_indicator</i> [-H <i>hostname</i>] dca -h
DESCRIPTION	<p>dca(1M) provides a communication mechanism between the dca on the system controller and the domain configuration server (dcs) on the specified domain. The dca provides communication services for remote dynamic reconfiguration commands.</p> <p>This agent is automatically started by sscd(1M). Do <i>not</i> start it manually from the command line.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions for the specified <i>hostname</i>.</p> <p style="padding-left: 40px;">Note - Use alone. Any option specified in addition to -h is ignored.</p> <p>-H <i>hostname</i> The Solaris software host name of the domain associated with the dca.</p>
FILES	<p>The following files are used by this command:</p> <pre style="padding-left: 40px;"> /var/opt/SUNWSMS/doors/<domain_id>/dca /var/opt/SUNWSMS/pipes/<domain_id>/scdr0 /var/opt/SUNWSMS/pipes/<domain_id>/scdr1 /var/opt/SUNWSMS/pipes/<domain_id>/scdr2 /var/opt/SUNWSMS/pipes/<domain_id>/scdr3 /var/opt/SUNWSMS/pipes/<domain_id>/scdr4 /var/opt/SUNWSMS/pipes/<domain_id>/scdr5 /var/opt/SUNWSMS/pipes/<domain_id>/scdr6 /var/opt/SUNWSMS/pipes/<domain_id>/scdr7 </pre>

```
/var/opt/SUNWSMS/pipes/<domain_id>/scdr8
```

```
/var/opt/SUNWSMS/pipes/<domain_id>/scdr9
```

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addboard(1M), **deleteboard**(1M), **moveboard**(1M), **rcfgadm**(1M)

NAME	deleteboard - unconfigure, disconnect, and unassign a system board from a domain
SYNOPSIS	deleteboard [-c <i>function</i>] [-r <i>retry_count</i>] [-t <i>timeout</i>] [-q] [-f] [-y] [-n] <i>location</i> ...
DESCRIPTION	<p>deleteboard-h</p> <p>deleteboard(1M) removes a <i>location</i> from the domain it is currently assigned to and possibly active in. The board at that <i>location</i> must be in either the <code>assigned</code> or <code>connected configured</code> states. The <code>-c</code> option is used to specify the transition of the board from the current configuration state to the new configuration state.</p> <p>Configuration states are <code>unconfigure</code>, <code>disconnect</code>, and <code>unassign</code>. If the <code>-c</code> option is not specified, the default expected configuration state is <code>unassign</code>.</p> <p>A domain administrator can unconfigure and disconnect a board but cannot unassign a board from a domain unless the board is in the domain available component list. See <code>setupplatform(1M)</code>. This means the <code>deleteboard location</code> field must appear in the domain available component list list.</p>
OPTIONS	<p>The following options are supported.</p> <p>Note – If the <code>deleteboard</code> command fails, a board does not return to its original state. A <code>dxs</code> or <code>dca</code> error message is logged to the domain. If the error is recoverable, you can retry the command. If it is unrecoverable, you need to reboot the domain in order to use that board.</p> <p><code>-c <i>function</i></code> Valid <i>function</i> values are <code>unconfigure</code>, <code>disconnect</code>, or <code>unassign</code>. The <code>-c</code> option is used to control the configuration state transition. Each successive function builds upon the last. For example, <code>unassign</code> first unconfigures and then disconnects the board before unassigning it.</p>

The possible transition states and their meanings are as follows:

unconfigure	Unconfigures the board from the Solaris operating environment running on the domain. Solaris software stops using any of the hardware resources on the board. Transitions the board into the <code>connected unconfigured</code> state. In this state the system board is assigned to the logical domain and connected (remains in the active state). This state allows normal system access to hardware resources on the board, but the hardware resources of the board are not represented by the normal Solaris software data structures and thus are not available to the Solaris operating environment. Operations allowed on the board are limited to configuration administration operations.
disconnect	Unconfigures the board from the Solaris operating environment running on the domain. See <code>unconfigure</code> . Transitions the board into the <code>disconnected unconfigured</code> state. Removes the board from the physical domain. An UNCLAIM request is sent by the domain to the SC during this step. In this state the system board is assigned to the logical domain and disconnected.
unassign	Unconfigures the board from the Solaris operating environment running on the domain. See <code>unconfigure</code> . Disconnects the board. See <code>disconnect</code> . Moves the board out of the logical domain by changing its state to available.

`-f` Forces the specified action to occur. Typically, this is a hardware-dependent override of a safety feature. Forcing a state change operation can allow use of the hardware resources of an occupant that is not in the `ok` or `unknown` conditions, at the discretion of any hardware-dependent safety checks.

`-h` Help. Displays usage descriptions.

Note – Use alone. Any option specified in addition to `-h` is ignored.

- `-n` Automatically answers no to all prompts. Prompts are displayed unless used with the `-q` option.
- `-q` Quiet. Suppresses all messages to `stdout` including prompts.
- When used alone `-q` defaults to the `-n` option for all prompts.
- When used with either the `-y` or the `-n` option, `-q` suppresses all user prompts, and automatically answers with either 'y' or 'n' based on the option chosen.
- `-r retry_count`
`-t timeout` These command arguments enable the user to specify retries in case of failures encountered during state transitions. The `-r retry_count` option can be used alone and indicates the number of times the configuration state change request should be retried by the domain. The `-t timeout` option cannot be used without the `-r retry_count` option and specifies the number of seconds that the domain should wait before the next retry is made. If the `-t timeout` is not specified, the default *timeout* is zero, meaning that the request is retried immediately.
- `-y` Automatically answers yes to all prompts. Prompts are displayed unless used with the `-q` option.

OPERANDS

The following operands are supported:

location List of board locations separated by a space. Multiple *location* arguments are permitted.

The following *location* forms are accepted:

Sun Fire 15K , Sun Fire 12K

SB(0...17) , SB(0...8)

IO(0...17) , IO(0...8)

Note – Use `showboards(1M)` to display board type.

EXTENDED DESCRIPTION**Group Privileges Required**

Users with platform administrator privileges can perform only the `-c unassign` option if the board(s) are in the `assigned` state (that is, not active in a running domain).

Users with domain administrator or configurator privileges can execute this command but only on their respective domains. To unassign a board, the board must be in the domain available component list.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Unconfiguring Boards From a Domain

To unconfigure four boards from their domain, you must have domain administrator/configurator privileges and the boards must be in the domain available component list.

All boards are in the `configured` state in the example domain.

```
sc0:sms-user:> deleteboard -c unconfigure SB0 IO1 SB1 SB2
```

EXAMPLE 2 Unassigning Boards From a Running Domain

To unassign three active boards from their domain, set retries to five seconds and timeout to three seconds. The boards are unconfigured and disconnected before being unassigned. You must have domain administrator/configurator privileges, and the boards must be in the domain available component list.

```
sc0:sms-user:> deleteboard -r5 -t3 IO3 IO4 IO5
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
1	No acknowledge.
2	Not supported.
3	Operation not supported.
4	Invalid privileges.
5	Busy.
6	System busy.
7	Data error.
8	Library error.
9	No library.
10	Insufficient condition.
11	Invalid.
12	Error.
13	A PID does not exist.

- 14 Invalid attribute.
- 30 Invalid board ID type.
- 31 Invalid permissions.
- 32 Assigned to another domain.
- 33 Unable to get permissions.
- 34 Unable to get domain board info.
- 35 Unable to get active board list.
- 36 Unable to get assigned board list.
- 38 Solaris not running.
- 39 Unable to assign/unassign domain state.
- 40 Unable to get domain permissions.
- 41 Unable to get platform permissions.
- 52 Invalid privileges
- 53 Internal error.
- 54 Library error.
- 56 DR command syntax error.
- 58 Internal error.
- 68 Location not assigned.
- 69 Location not configured.
- 70 DR operation failed.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addboard(1M), **moveboard**(1M)



NAME	deletecodlicense - remove a Capacity on Demand (COD) right-to-use (RTU) license key from the COD license database
SYNOPSIS	deletecodlicense [-f] <i>license-signature</i> deletecodlicense -h
DESCRIPTION	<p>The <code>deletecodlicense(1M)</code> command removes the specified COD RTU license key from the COD license database on the SC. For further information about COD RTU license keys, refer to the <i>SMS 1.3 Administrator Guide</i>.</p> <p>The system checks the number of COD RTU licenses against the number of COD CPUs in use. If the license removal will result in an insufficient number of COD RTU licenses with respect to the CPU in use, the system does not delete the license key from the COD RTU license database. If you still want to delete the COD RTU license key, you must reduce the number of COD CPUs in use. You can either power off the appropriate number of domains or use dynamic reconfiguration (DR) to disconnect the appropriate number of boards.</p> <p>However, you can force the deletion of a COD RTU license by specifying the <code>-f</code> option, even if the license removal will result in a license violation.</p>
OPTIONS	<p>The following options are supported:</p> <p><code>-f</code> Forces the specified COD RTU license key to be deleted from the COD license database.</p> <p><code>-h</code> Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.</p> <p><i>license-signature</i> Specifies the COD RTU license key to be deleted from the COD license database.</p>
Group Privileges Required	<p>You must have platform administrator group privileges to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>
EXAMPLES	<p>EXAMPLE 1 Deleting a COD RTU license key</p> <pre>sc0:sms-user:>deletecodlicense\ 01:5014936C37048:01001:0201010302:4:20020430:jwGJdg/ kx78b0wyK2xrqIg</pre>

EXIT STATUS | The following exit values are returned:

0	Successful completion.
1	Invalid usage
2	Invalid group privileges.
>2	An internal error occurred. For further information, see <code>/var/opt/SUNWSMS/adm/platform/messages</code> .

ATTRIBUTES | See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO | **addcodlicense** (1M), **codd** (1M), **showcodlicense** (1M), **showcodusage** (1M)

NAME	deletetag - remove the domain tag name associated with the domain
SYNOPSIS	deletetag -d <i>domain_indicator</i> [-q] [-y -n] deletetag -h
DESCRIPTION	deletetag(1M) removes the domain tag associated with the domain.
OPTIONS	The following options are supported: -d <i>domain_indicator</i> Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M). -h Help. Displays usage descriptions. Note - Use alone. Any option specified in addition to -h is ignored. -n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option. -q Quiet. Suppresses all messages to stdout including prompts. When used alone, -q defaults to the -n option for all prompts. When used with either the -y or the -n option, -q suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen. -y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator privileges to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Deleting Tag eng2 From the Domain to Which It Was Assigned <pre>sc0:sms-user:> deletetag -d eng2 -qy</pre>

You are not prompted.

EXIT STATUS

The following exit values are returned:

0 Successful completion.
>0 An error occurred.

If the *domain_id* does not have a tag, no error is returned.
deletetag(1M) is treated as successful.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M)

NAME	disablecomponent - add the specified component to the specified blacklist file
SYNOPSIS	disablecomponent [-d <i>domain_indicator</i>] [-i " <i>reason</i> "] <i>location</i> ...
DESCRIPTION	<p>disablecomponent -h</p> <p>disablecomponent(1M) adds a component to the domain or platform blacklist, making it ineligible for booting.</p> <p>The <i>blacklist</i> is an internal file that lists components that POST cannot use at boot time. POST reads the blacklist file(s) before preparing the system for booting, and passes along to OpenBoot PROM a list of only those components that have been successfully tested; those on the blacklist are excluded. SMS supports three blacklists: one for domain boards, one for platform boards, and the internal automatic system recovery (ASR) blacklist.</p> <p>disablecomponent, when used without any option, edits the platform blacklist file.</p> <p>disablecomponent <i>cannot</i> be used on the ASR blacklist file; only enablecomponent(1M) can be used to write to the ASR blacklist file.</p> <p>For more information on the use and editing of platform and domain blacklists refer to Chapter 6, "Domain Control," in the <i>System Management Services (SMS) 1.3 Administrator Guide</i>.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions.</p> <p style="padding-left: 40px;">Note - Use alone. Any option specified in addition to -h is ignored.</p> <p>-i "<i>reason</i>" Short, descriptive explanation for adding a component to the domain blacklist. Must be enclosed in either single or double quotation marks, or be a single word.</p>

OPERANDS

The following operands are supported:

location

List of component locations, separated by forward slashes and comprised of the following:

board_loc/proc/bank/logical_bank

board_loc/proc/bank/all_dimms_on_that_bank

board_loc/proc/all_banks_on_that_proc

board_loc/all_banks_on_that_board

board_loc/proc

board_loc/procs

board_loc/cassette

board_loc/bus

board_loc/paroli_link

Multiple *location* arguments are permitted, separated by a space.

The *location* forms are optional and are used to specify particular components on boards in specific locations.

For example, the *location* SB5/P0/B1/L1 indicates Logical Bank 1 of Bank 1 on Processor 0 at SB5.

The SB0/PP1 *location* indicates Processor Pair 1 at SB0.

The CS0/ABUS *location* indicates address bus 0 on the centerplane.

The EX11/DBUS1 *location* indicates data bus 1 at expander 11.

The following *board_loc* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

CS(0|1), CS(0|1)

EX(0...17), EX(0...8)

Processor locations indicate single processors or processor pairs.

There are four possible processors on a CPU/memory board. Processor pairs on that board are procs 0 and 1, and procs 2 and 3.

Note – If you blacklist a single CPU/mem processor in a processor pair, neither processor is used.

The MaxCPU has two processors, procs 0 and 1, and only one proc pair (PP0). Using PP1 for this board causes `disablecomponent` to exit and display an error message.

The following *proc* forms are accepted:

P(0...3) PP(0|1)

The following *bank* forms are accepted:

B(0|1)

The following *logical_bank* forms are accepted:

L(0|1)

The following *all_dimms_on_that_bank* forms are accepted:

D

The following *all_banks_on_that_proc* forms are accepted:

B

The following *all_banks_on_that_board* forms are accepted:

B

The following *paroli_link* forms are accepted:

PAR(0|1)

The hsPCI assemblies contain hot-swappable cassettes.

The following *hsPCI* forms are accepted:

C(3|5)V(0|1)

The hsPCI+ assemblies contain hot-swappable cassettes.

The following *hsPCI+* forms are accepted:

C3V(0|1|2) and C5V0

There are three bus locations: address, data, and response.

The following *bus* forms are accepted:

```
ABUS|DBUS|RBUS (0|1)
```

EXTENDED DESCRIPTION

Group Privileges Required

You must have platform administrator, domain administrator, or domain configurator privileges to run this command. If you have platform privileges, you can run this command for the platform components only. If you have domain privileges you can run this command only on the domain for which you have privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Adding CSB 0 and Processor 2 on System Board 1 to the Domain A Blacklist

```
sc0:sms-user:> disablecomponent -dA CS0 SB1/P2
```

EXAMPLE 2 Adding the Logical Bank 0 of Bank 0 on Processor 0 on System Board 0 to the Domain A Blacklist

```
sc0:sms-user:> disablecomponent -dA SB0/P0/B0/L0
```

EXAMPLE 3 Adding All DIMMs on Bank 0 of Processor 1 on System Board 3 to the Domain A Blacklist

```
sc0:sms-user:> disablecomponent -dA SB3/P1/B0/D
```

EXAMPLE 4 Adding All Banks on Processor 0 on System Board 1 to the Domain B Blacklist

```
sc0:sms-user:> disablecomponent -dB SB1/P0/B
```

EXAMPLE 5 Adding All Banks on System Board 0 to the Domain D Blacklist

```
sc0:sms-user:> disablecomponent -dD SB0/B
```

EXAMPLE 6 Adding Processor Pair 1 on System Board 3 to the Platform Blacklist

```
sc0:sms-user:> disablecomponent SB3/PP1
```

EXAMPLE 7 Adding the hsPCI Cassette in the 5V slot 0 of IO Board 6 to the Domain A

Blacklist

```
sc0:sms-user:> disablecomponent -dA IO6/C5V0
```

EXAMPLE 8 Adding Paroli Link 0 on wPCi Board 7 to the Platform Blacklist

```
sc0:sms-user:> disablecomponent IO7/PAR0
```

EXAMPLE 9 Adding the Data Bus CS0 on EX9 to the Domain A Blacklist

```
sc0:sms-user:> disablecomponent -dA EX9/DBUS0
```

EXAMPLE 10 Adding CSB 0 and Processor 2 on System Board 1 to the Domain A Blacklist Because It Is Scheduled to Be Upgraded

```
sc0:sms-user:> disablecomponent -dA -i upgrade CS0 SB1/P2
```

EXAMPLE 11 Adding Processor Pair 1 on System Board 3 to the Platform Blacklist Because It Needs Service

```
sc0:sms-user:> disablecomponent -i "Needs service" SB3/PP1
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

FILES

The following file is used by this command.

/etc/opt/SUNWSMS/config/platform/blacklist	List of platform components excluded.
/etc/opt/SUNWSMS/config/ <i>domain_id</i> /blacklist	List of domain components to be excluded.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addboard(1M), **enablecomponent**(1M), **esmd**(1M), **showcomponent**(1M)



NAME	dsmd - domain status monitoring daemon														
SYNOPSIS	dsmd														
DESCRIPTION	<p>dsmd(1M) monitors domain status and operating system (OS) heartbeat for up to 18 domains.</p> <p>dsmd automatically recovers the domain and handles domain-related hardware errors. In the event of a domain hang, dsmd resets the domain, collects CPU registers and hardware configuration dumps, and saves them to two files.</p> <p>All domain state changes are monitored and logged in domain-specific log files if the message level is INFO; otherwise there is no log for a state change.</p> <p>This daemon is started automatically by the sssd(1M) daemon. Do <i>not</i> start it manually from the command line.</p>														
EXTENDED DESCRIPTION	<p>dsmd logs the following events and attempts to recover from them:</p> <ul style="list-style-type: none"> ■ Domain boot failure ■ Error reset ■ Solaris OS hang ■ Domain panic ■ Domain reset/reboot ■ DStop ■ Boot/panic/error_reset_sync timeout <p>dsmd clients include:</p> <table border="0" style="margin-left: 2em;"> <tr> <td>dxs(1M)</td> <td>Domain X server daemon</td> </tr> <tr> <td>efe</td> <td>Sun Management Center daemon</td> </tr> <tr> <td>osd(1M)</td> <td>OpenBoot PROM daemon</td> </tr> <tr> <td>pcd(1M)</td> <td>Platform configuration database daemon</td> </tr> <tr> <td>esmd(1M)</td> <td>Environment status monitoring daemon</td> </tr> </table> <p>dsmd is a client of:</p> <table border="0" style="margin-left: 2em;"> <tr> <td>hwad(1M)</td> <td>Hardware access daemon</td> </tr> <tr> <td>setkeyswitch(1M)</td> <td>Virtual keyswitch control command</td> </tr> </table> <p>For more information refer to the <i>System Management Services (SMS) 1.3 Administrator Guide</i>.</p>	dxs(1M)	Domain X server daemon	efe	Sun Management Center daemon	osd(1M)	OpenBoot PROM daemon	pcd(1M)	Platform configuration database daemon	esmd(1M)	Environment status monitoring daemon	hwad(1M)	Hardware access daemon	setkeyswitch(1M)	Virtual keyswitch control command
dxs(1M)	Domain X server daemon														
efe	Sun Management Center daemon														
osd(1M)	OpenBoot PROM daemon														
pcd(1M)	Platform configuration database daemon														
esmd(1M)	Environment status monitoring daemon														
hwad(1M)	Hardware access daemon														
setkeyswitch(1M)	Virtual keyswitch control command														

FILES | The following files are supported:

<code>/etc/opt/SUNWSMS/startup/ssd_start</code>	Default startup file for <code>ssd</code> .
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/</code>	Stores message files and <code>hpost</code> dump files.
<code>/var/opt/SUNWSMS/SMS/adm/<i>domain_id</i>/post/</code>	Stores the <code>dstop</code> and hardware configuration dump files
<code>/export/home/<i>sms-user</i>/xir_dump/</code>	Stores <code>xir</code> dump files for all domains.

ATTRIBUTES | See `attributes(5)` for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO | `dxs(1M)`, `esmd(1M)`, `hwad(1M)`, `osd(1M)`, `pcd(1M)`, `reset(1M)`, `setkeyswitch(1M)`, `ssd(1M)`

NAME	dxs - domain X server
SYNOPSIS	dxs [-s] -d <i>domain_indicator</i> dxs -h
DESCRIPTION	<p>dxs(1M) provides software support for a domain. This support includes virtual console functionality, dynamic reconfiguration mailbox support, and PCI mailbox support. The mailbox support handles domain driver requests and events. The virtual console functionality enables one or more users running the console program to access the domain's virtual console.</p> <p>When the domain is running Solaris software, dxs acts as a relay between the domain's console driver (cvcd) and the running console windows. When the domain is not running Solaris software, dxs acts as a relay between OpenBoot PROM and the running console windows.</p> <p>A domain X server is automatically started for each active domain by the sdd(1M) daemon. Do <i>not</i> start it manually from the command line. dxs for the domain is terminated when the domain is shut down.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions for the specified <i>hostname</i>.</p> <p style="padding-left: 40px;">Note - Use alone. Any option specified in addition to -h is ignored.</p> <p>-s Disables console output logging. By default, logging is enabled and is written to the /var/opt/SUNWSMS/adm/<i>domain_id/console</i> file.</p>
EXIT STATUS	<p>The following exit values are returned:</p> <p>0 Successful completion.</p> <p>>0 An error occurred.</p>

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **console**(1M), **ssd**(1M)

NAME	enablecomponent - remove the specified component from the specified blacklist
SYNOPSIS	enablecomponent [-a -d <i>domain_indicator</i>] <i>location</i> .. enablecomponent -h
DESCRIPTION	<p>enablecomponent(1M) removes a component from the platform, domain, or ASR blacklist, making it eligible for booting.</p> <p>The <i>blacklist</i> is an internal file that lists components that POST cannot use at boot time. POST reads the blacklist file(s) before preparing the system for booting, and passes along to OpenBoot PROM a list of only those components that have been successfully tested; those on the blacklist are excluded. SMS supports three blacklists: one for domain boards, one for platform boards, and the internal ASR blacklist.</p> <p>The ASR <i>blacklist</i> is an internal file created by <code>esmd</code> when it powers off components due to environmental conditions. The ASR blacklist is also used by the power libraries and SMS commands to prevent turning on a bad component.</p> <p>enablecomponent, when used without any option, edits the platform blacklist.</p> <p>Use showcomponent(1M) to display whether a particular component is currently blacklisted.</p> <p>For more information on the use and editing of platform and domain blacklists refer to Chapter 6, “Domain Control,” in the <i>System Management Services (SMS) 1.3 Administrator Guide</i>.</p>
OPTIONS	<p>The following options are supported:</p> <p>-a Specifies the component to remove from the ASR blacklist.</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case insensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p>

OPERANDS

The following operands are supported:

location

List of component locations, separated by forward slashes and comprised of:

board_loc/proc/bank/logical_bank

board_loc/proc/bank/all_dimms_on_that_bank

board_loc/proc/all_banks_on_that_proc

board_loc/all_banks_on_that_board

board_loc/proc

board_loc/procs

board_loc/cassette

board_loc/bus

board_loc/paroli_link

Multiple *location* arguments are permitted, separated by a space.

The *location* forms are optional and are used to specify particular components on boards in specific locations.

For example, the *location* SB5/P0/B1/L1 indicates Logical Bank 1 of Bank 1 on Processor 0 at SB5.

The SB0/PP1 *location* indicates Processor Pair 1 at SB0.

The CS0/ABUS *location* indicates address bus 0 on the centerplane.

The EX11/DBUS1 *location* indicates data bus 1 at expander 11.

The following *board_loc* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

CS(0|1), CS(0|1)

EX(0...17), EX(0...8)

Processor locations indicate single processors or processor pairs.

There are four possible processors on a CPU/memory board. Processor pairs on that board are: procs 0 and 1, and procs 2 and 3.

The MaxCPU has two processors, procs 0 and 1, and only one proc pair (PP0). Using PP1 for this board causes enablecomponent to exit and display an error message.

The following *proc* forms are accepted:

P(0...3) PP(0|1)

The following *bank* forms are accepted:

B(0|1)

The following *logical_bank* forms are accepted:

L(0|1)

The following *all_dimms_on_that_bank* forms are accepted:

D

The following *all_banks_on_that_proc* forms are accepted:

B

The following *all_banks_on_that_board* forms are accepted:

B

The following *paroli_link* forms are accepted:

PAR(0|1)

The hsPCI assemblies contain hot-swappable cassettes.

The following *hsPCI* forms are accepted:

C(3|5)V(0|1)

The hsPCI+ assemblies contain hot-swappable cassettes.

The following *hsPCI+* forms are accepted:

C3V(0|1|2) and C5V0

There are three bus locations: address, data, and response.

The following *bus* forms are accepted:

```
ABUS|DBUS|RBUS (0|1)
```

EXTENDED DESCRIPTION

Group Privileges Required

You must have platform administrator, domain administrator, or domain configurator privileges to run this command. If you have platform privileges, you can run this command for the platform components only. If you have domain privileges, you can run this command only on the domain for which you have privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Removing CSB0 From the ASR Blacklist

```
sc0:sms-user:> enablecomponent -a CS0
```

EXAMPLE 2 Removing the Logical Bank 0 of Bank 0 on Processor 0 on System Board 0 From the Domain A Blacklist

```
sc0:sms-user:> enablecomponent -dA SB0/P0/B0/L0
```

EXAMPLE 3 Removing All DIMMs on Bank 0 of Processor 1 on System Board 3 From the Domain A Blacklist

```
sc0:sms-user:> enablecomponent -dA SB3/P1/B0/D
```

EXAMPLE 4 Removing All Banks on Processor 0 on System Board 1 From the Domain B Blacklist

```
sc0:sms-user:> enablecomponent -dB SB1/P0/B
```

EXAMPLE 5 Removing All Banks on System Board 0 From the Domain D Blacklist

```
sc0:sms-user:> enablecomponent -dD SB0/B
```

EXAMPLE 6 Removing Processor Pair 0 on I/O Board 7 From the Platform Blacklist

```
sc0:sms-user:> enablecomponent IO7/PP0
```

EXAMPLE 7 Removing Processor 1 on System Board 3 From the Domain A Blacklist

```
sc0:sms-user:> enablecomponent -dA SB3/P1
```

EXAMPLE 8 Removing the hsPCI Cassette in the 3V slot 0 of IO Board 6 From the Domain A Blacklist

```
sc0:sms-user:> enablecomponent -dA IO6/C3V0
```

EXAMPLE 9 Removing the Paroli Link 0 on wPCi Board 5 From the Platform Blacklist

```
sc0:sms-user:> enablecomponent IO5/PAR0
```

EXAMPLE 10 Removing the Address Bus CS0 on EX7 From the Domain A Blacklist

```
sc0:sms-user:> enablecomponent -dA EX7/ABUS0
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

FILES

The following files are used by this command.

<code>/etc/opt/SUNWSMS/config/asr/blacklist</code>	List of components excluded by esmd.
<code>/etc/opt/SUNWSMS/config/platform/blacklist</code>	List of platform components excluded.
<code>/etc/opt/SUNWSMS/config/<i>domain_id</i>/blacklist</code>	List of domain components excluded.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addboard(1M), **disablecomponent**(1M), **esmd**(1M), **showcomponent**(1M)



NAME	esmd - environmental status monitoring daemon													
SYNOPSIS	esmd													
DESCRIPTION	<p>esmd(1M) monitors system cabinet environmental conditions —for example, voltage, temperature, fan tray, and power supply. esmd logs abnormal conditions and takes action, if necessary, to protect the hardware.</p> <p>This daemon is started automatically by the sssd(1M) daemon. Do <i>not</i> start it manually from the command line.</p>													
EXTENDED DESCRIPTION	<p>esmd monitors the following boards for out-of-range conditions:</p> <ul style="list-style-type: none"> ■ CPU board ■ MaxCPU board ■ HPCI board ■ HPCI+ board ■ Expander board ■ Centerplane support board ■ SC control board ■ SC I/O ■ Fan control board ■ Power supplies (bulk) <p>esmd recognizes the following events and alerts the appropriate clients/daemons:</p> <table border="0"> <tr> <td style="vertical-align: top;">Component insertion</td> <td>Notices component presence from one polling cycle to the next. esmd sends notification only if that client (hwad(1M), pcd(1M), dsmd(1M), and so on) has requested it for that particular component type.</td> </tr> <tr> <td style="vertical-align: top;">Component removal</td> <td>Notices component absence from one polling cycle to the next. esmd sends notification only if that client (hwad, pcd, and so on) has requested it for that particular component type.</td> </tr> <tr> <td style="vertical-align: top;">PCI card insertion</td> <td>Notices whenever a PCI card has been inserted into a PCI board.</td> </tr> <tr> <td style="vertical-align: top;">PCI card removal</td> <td>Notices whenever a PCI card has been removed from a PCI board.</td> </tr> <tr> <td style="vertical-align: top;">Board power off</td> <td>Notices whenever a board is powered off or when board power, previously on, is off.</td> </tr> <tr> <td style="vertical-align: top;">Board power on</td> <td>Notices when a board is powered on or when board power, previously off, is on.</td> </tr> </table>		Component insertion	Notices component presence from one polling cycle to the next. esmd sends notification only if that client (hwad(1M), pcd(1M), dsmd(1M), and so on) has requested it for that particular component type.	Component removal	Notices component absence from one polling cycle to the next. esmd sends notification only if that client (hwad, pcd, and so on) has requested it for that particular component type.	PCI card insertion	Notices whenever a PCI card has been inserted into a PCI board.	PCI card removal	Notices whenever a PCI card has been removed from a PCI board.	Board power off	Notices whenever a board is powered off or when board power, previously on, is off.	Board power on	Notices when a board is powered on or when board power, previously off, is on.
Component insertion	Notices component presence from one polling cycle to the next. esmd sends notification only if that client (hwad(1M), pcd(1M), dsmd(1M), and so on) has requested it for that particular component type.													
Component removal	Notices component absence from one polling cycle to the next. esmd sends notification only if that client (hwad, pcd, and so on) has requested it for that particular component type.													
PCI card insertion	Notices whenever a PCI card has been inserted into a PCI board.													
PCI card removal	Notices whenever a PCI card has been removed from a PCI board.													
Board power off	Notices whenever a board is powered off or when board power, previously on, is off.													
Board power on	Notices when a board is powered on or when board power, previously off, is on.													

Board temperature change	Notifies when temperature sensors on a board register a two-degree difference or when a temperature crosses a temperature threshold.
Board voltage change	Notifies if a voltage sensor value has changed so that it is close to being out of range and again if the new value is out of range. In this case <code>esmd</code> removes the board from the domain and powers it off.
Board current change	Notifies whenever any of the monitored board current values change.
CSB state change	Notifies when any of the monitored CSB board properties change.
EXB state change	Notifies when any of the monitored EXB board properties change.
CPU state change	Notifies when any of the monitored CPU board properties change.
Bulk power state change	Notifies when any of the bulk power supply properties change.
Fan tray state change	Notifies when any of the monitored fan tray properties change.
PCI card state change	Notifies when any of the monitored PCI card properties change.

`esmd` clients include:

<code>hwad</code>	Hardware access daemon
<code>pcd</code>	Platform configuration database daemon
<code>dsmd</code>	Domain status monitoring daemon

For more information refer to the *System Management Services (SMS) 1.3 Administrator Guide*.

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

FILES

The following file is supported.

<code>/var/opt/SUNWSMS/adm/platform/messages</code>	Stores message files.
---	-----------------------

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **dsmd**(1M), **hwad**(1M), **pcd**(1M), **ssd**(1M)



NAME	flashupdate - update the flash PROMs located on the CPU boards, MaxCPU boards, and system controllers (SC)
SYNOPSIS	<p>flashupdate -d <i>domain_indicator</i> -f <i>path</i> [-q -v] [-y -n]</p> <p>flashupdate -f <i>path</i> [-q -v] [-y -n] <i>location...</i></p> <p>flashupdate -h</p>
DESCRIPTION	<p>flashupdate(1M) updates the flash PROMs (FPROMs) in the system controllers (SC), and the FPROMs in a domain's CPU and MaxCPU boards, given the board location.</p> <p>To update the FPROMs in the system controller, you must log in to the SC you want to update, and specify the FPROM to be updated. (You cannot update one SC from the other SC.) Each FPROM has a specific image file associated with it. Once you have finished updating the SC FPROMs, you must shut down and reset the SC. See Example 6 in the EXAMPLES section. You do not need to reset the SC after updating CPU FPROMs.</p> <p>Before you can update the CPU FPROMs, SMS must be running and the specified board must be powered on. This is not required for updating the SC FPROMs. If any of the domain's CPU or MaxCPU boards have the virtual keyswitch set to the <i>secure</i> position, the FPROM(s) are not updated.</p> <p>flashupdate displays both the current FPROM and the flash image file information prior to any updates. You are prompted to update the FPROMs.</p> <p>Note – No CLIs should be executed on a system board while flashupdate is running on that board. Wait until flashupdate completes before running any SMS commands involving that system board.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> – ID for a domain. Valid <i>domain_ids</i> are A–R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> – Name assigned to a domain using addtag(1M).</p> <p>-f <i>path</i> Name of the flash image file.</p> <p style="padding-left: 40px;">The <i>path</i> argument specifies the name of the image file that is used to update the FPROM given in the <i>location</i> argument.</p>

- h Help. Displays usage descriptions.
- Note** – Use alone. Any option specified in addition to -h is ignored.
- n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option.
- q Quiet. Suppresses all messages to `stdout` including prompts.
- When used alone, -q defaults to the -n option for all prompts.
- When used with either the -y or the -n option, -q suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen.
- v Verbose. Displays version information about the firmware. The information displayed is intended for internal use by Sun service personnel. Its format is private and subject to change.
- y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.

OPERANDS

The following operands are supported:

- location* FPRM location.
- The FPRM location consists of *board_loc/FPRM_id*, separated by a forward slash.
- The *FPRM_id* is specified only when you want to update a particular FPRM (FP0 or FP1) on a CPU board and the system controller (SC).
- For example, the location, SB4/FP0, indicates the FPRM 0 on the CPU board in slot 4.
- Sun Fire 15K, Sun Fire 12K
- SB(0...17), SB(0...8)
- IO(0...17), IO(0...8)
- SC(0|1), SC(0|1)
- The following *FPRM_id* forms are accepted:
- FP(0|1), FP(0|1)

**EXTENDED
DESCRIPTION****Group Privileges
Required**

You must have platform administrator or domain administrator privileges to run this command. If you have platform administrator privileges, all boards can be updated. For domain administrators, only boards that are active in the administrator's domain or available to the administrator's domain can be updated.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Updating FPROM 0 in the System Controller 0

You must reset the SC after running this command.

```
sc0:sms-user:> flashupdate -f /opt/SUNWSMS/firmware/SCOBPimg.di SC0/  
FP0
```

EXAMPLE 2 Updating FPROM 1 in the System Controller 0

You must reset the SC after running this command.

```
sc0:sms-user:> flashupdate -f /opt/SUNWSMS/firmware/SSCPOST.di SC0/  
FP1
```

EXAMPLE 3 Updating FPROM 0 in the System Controller 1

You must reset the SC after running this command.

```
sc1:sms-user:> flashupdate -f /opt/SUNWSMS/firmware/SCOBPimg.di SC1/  
FP0
```

EXAMPLE 4 Updating Both FPROMs on CPU Board 0

SMS must be running, and the SB0 board must be powered on.

```
sc0:sms-user:> flashupdate -f /opt/SUNWSMS/hostobjs/sgcpu.flash SB0  
Do you wish to update the FPROM (yes/no)? y  
sc0:sms-user:>
```

EXAMPLE 5 Updating FPROMs in Domain A

SMS must be running, and the CPU boards in domain A must be powered on.

```
sc0:sms-user:> flashupdate -d A -f /opt/SUNWSMS/hostobjs/sgcpu.flash
```

EXAMPLE 6 Resetting the SC After Updating the SC FPROMs

Switch to superuser and shut down the SC.

```
sc0: sms-user: > su -

sc0: # shutdown -y -g0 -i0
...[system messages]
ok
```

In order for the new firmware to be enabled on your SC, you must now perform a reset of the SC. Type:

```
ok reset-all
```

If this does not reset the SC, then you must perform a hard reset.

Physically locate your system controller within your Sun Fire 15K/12K cabinet, and depress the Abort button and then the Reset button on the SC board. Once the SC has been reset you should see OpenBoot PROM messages indicating that the new version of the firmware is loading. After the system successfully returns to the `ok` prompt, verify that the flash update worked by typing:

```
ok show-dropins
```

```
Dropins for Flash device: /pci@1f,0/pci@1,1/ebus@1/flashprom@10,40000
-----
Dropin name      Size Checksum Date      Date      Version Vendor
                  created   flashed
-----
SSCOBP-dropins  90      c84e    11/13/2001 11/13/2001 1.2  SUNW,sscobp
....
....
```

Note the version number of the Dropins (1.2).

You can now boot your new installation of the Solaris software. Type:

```
ok boot new disk
```

Log in as a platform administrate and type:

```
sc0:sms-user:> flashupdate -f /opt/SUNWSMS/firmware/SCOBPing.di SC0/
FP0
```

```
Current SC FPROM Information
=====
```

```
SC at SC0, FPROM 0:
Name: SSCOBP-dropins,
Version: 1.2
Size: 144,
Check Sum: 51278
Date Flashed: 11/13/01
Date Created: 11/13/01
```

```
Do you wish to update the SC User FPROM (yes/no)? n
```

```
sc0:sms-user:>
```

Compare version numbers. If they are the same, flashupdate was successful.

EXIT STATUS

The following exit values are returned:

```
0           Successful completion.
>0         An error occurred.
```

FILES

The following files are used by this command:

```
/opt/SUNWSMS/firmware/SCOBPing.di    Used to update the FPROM 0 on
the SC.
/opt/SUNWSMS/firmware/SSCPOST.di     Used to update the FPROM 1 on
the SC.
/opt/SUNWSMS/hostobjs/sgcpu.flash    Used to update the FPROMs on
the CPU and MaxCPU boards.
```

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Interface stability	Evolving
Availability	SUNWSMSop

SEE ALSO

setkeyswitch(1M)



NAME fomd - failover management daemon

SYNOPSIS **fomd**

DESCRIPTION `fomd(1M)` is the core of the system controller (SC) failover mechanism. The `fomd` daemon detects faults on the local and remote SCs and takes the appropriate action (directing a failover/takeover).

The `fomd` daemon ensures that the necessary synchronization data between the two SCs is current. `fomd` runs on both the main and the spare SCs.

This daemon is automatically started by `ssd(1M)`. Do *not* start it manually from the command line.

EXIT STATUS The following exit values are returned:

0 Successful completion.

>0 An error occurred.

FILES The following configuration file is required:

`/etc/opt/SUNWSMS/config/fomd.cf` Failover daemon configuration file

ATTRIBUTES See **attributes(5)** for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **setfailover(1M)**, **showfailover(1M)**

NAME frad - FRU access daemon

SYNOPSIS frad

DESCRIPTION frad(1M) runs on the system controller (SC) and provides the exclusive mechanism by which SMS processes, including daemons, access any FRU SEEPROM within a given Sun Fire 15K/12K system. frad also provides the platform-dependent interface to the Sun Fire 15K/12K SEEPROMs required by the FRU ID software tools.

This daemon is started automatically by the ssd(1M) daemon. Do *not* start it manually from the command line.

EXIT STATUS The following exit values are returned:

0 Successful completion.
>0 An error occurred.

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO ssd(1M)



NAME	help - display help information for SMS commands
SYNOPSIS	help [<i>command_name</i>] help -h
DESCRIPTION	If no argument is included, <code>help(1M)</code> displays a list of valid SMS commands along with their correct syntax. Otherwise, the <i>command_name</i> operand displays that command's man page.
OPTIONS	The following option is supported: -h Help. Displays usage descriptions.
OPERANDS	The following operand is supported: <i>command_name</i> Specific command for which <code>help</code> displays the man page.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator, platform operator, platform service, domain administrator, domain configurator, or superuser privileges to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Using Help Displays all commands. <pre>sc0:sms-user:> help usage: addboard -d <i>domain_indicator</i> [-c <i>function</i>] [-r <i>retry_count</i> [-t <i>timeout</i>]] [-q] [-y -n] <i>location</i>... addboard -h smsversion -h</pre> EXAMPLE 2 Using Help for a Command

Displays man(1M) page.

```
sc0:sms-user:> help addtag
```

```
Maintenance Commands                                addtag(1M)
```

```
NAME
    addtag - assign a domain name (tag) to a domain
```

```
SYNOPSIS
```

```
addtag -d domain_indicator -a new_tag [-q ] [-y | -n]
.....
```

EXIT STATUS The following exit values are returned:

```
0                Successful completion.
>0              An error occurred.
```

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **man**(1M)

NAME hpost - Sun Fire 15K/12K power-on self-test (POST) control application

SYNOPSIS **hpost**

DESCRIPTION hpost(1M) is responsible for probing, testing, and configuring the hardware of a Sun Fire 15K/12K domain, preparing it for use by the OpenBoot PROM and the Solaris operating environment. Alternate modes prepare a single board for `attach` to a running domain using dynamic reconfiguration (DR), create hardware state dump files on the system controller (SC), clear certain nonfatal hardware error states, and perform related Sun Fire 15K/12K hardware operations.

Note – This application is intended to be run only by other SMS applications or daemons. Invoking it directly from the command line can cause failures of running domains and is *not* a supported mode of use.

hpost's clients include:

- dsmd(1M)
- dxs(1M)
- setkeyswitch(1M)

hpost is a client of:

- hwad(1M)
- pcd(1M)

hpost requires and uses flash PROM images and downloadable local POST executables delivered in the `SUNWSMS1p` package.

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSpo

SEE ALSO **dsmd**(1m), **hwad**(1m), **pcd**(1m), **setkeyswitch**(1m), **dxs**(1m)

NAME	kmd - SMS key management daemon								
SYNOPSIS	kmd								
DESCRIPTION	<p>kmd(1M) manages the IPSec security associations (SAs) necessary for securing the communication between the system controller (SC) and servers running on a domain. kmd manages per-socket policies for connections initiated by clients on the SC to servers on a domain. kmd manages shared policies for connections initiated by clients on the domain to servers on the SC.</p> <p>The current default configuration includes authentication policies for the dca(1M) and dxs(1M) clients on the SC, which connect to the dcs(1M) and cvcd(1M) servers on a domain.</p> <p>This daemon is started automatically by the ssd(1M) daemon. Do <i>not</i> start it manually from the command line.</p> <p>Note – kmd must be run as a root process to be permitted to use the pf_key interface to IPSec.</p>								
EXIT STATUS	<p>The following exit values are returned:</p> <p>0 Successful completion.</p> <p>>0 An error occurred.</p>								
FILES	<p>The following file is used to configure kmd:</p> <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top;"><code>/etc/opt/SUNWSMS/config/kmd_policy.cf</code></td> <td style="vertical-align: top;">kmd_policy.cf configures the shared and per-socket policies managed by kmd.</td> </tr> </table> <p>Changes to the policies are made by editing the kmd_policy.cf file on the SC. Corresponding changes must be made on the affected domain(s).</p> <p>The format of kmd_policy.cf is a table of eight fields separated by the pipe () character:</p> <p><i>dir</i> <i>d_port</i> <i>protocol</i> <i>sa_type</i> <i>auth_alg</i> <i>encr_alg</i> <i>domain</i> <i>login</i></p> <p>The fields are defined as follows:</p> <table border="0" style="width: 100%;"> <tr> <td style="vertical-align: top;"><i>dir</i></td> <td style="vertical-align: top;">Direction to connect from.</td> </tr> <tr> <td></td> <td style="vertical-align: top;">Values: sctodom, domtosc</td> </tr> <tr> <td style="vertical-align: top;"><i>d_port</i></td> <td style="vertical-align: top;">Destination port.</td> </tr> </table>	<code>/etc/opt/SUNWSMS/config/kmd_policy.cf</code>	kmd_policy.cf configures the shared and per-socket policies managed by kmd.	<i>dir</i>	Direction to connect from.		Values: sctodom, domtosc	<i>d_port</i>	Destination port.
<code>/etc/opt/SUNWSMS/config/kmd_policy.cf</code>	kmd_policy.cf configures the shared and per-socket policies managed by kmd.								
<i>dir</i>	Direction to connect from.								
	Values: sctodom, domtosc								
<i>d_port</i>	Destination port.								

<i>protocol</i>	Protocol for the socket. Values: tcp, udp
<i>sa_type</i>	Security association type. Values: ah, esp
<i>auth_alg</i>	Authentication algorithm. Values: none, md5, sha1
<i>encr_alg</i>	Encryption algorithm. Values: none, des, 3des
<i>domain</i>	Domain ID. Values: integers 0–17 or a [<i>space</i>]. A space for the domain ID defines a policy that applies to all domains. A policy for a specific domain overrides a policy that applied to all domains.
<i>login</i>	Login name. Values: Any valid login name.

The default policies in the `kmd_policy.cf` file are as follows:

```
sctodom|665|tcp|ah|md5|none| |sms-dca|
sctodom|442|tcp|ah|md5|none| |sms-dxs|
```

The configuration of policies on a domain is the standard IPsec configuration file (`/etc/inet/ipsecconf.init`).

The default policies are shown below.

```
{ dport sun-dr } permit { auth_alg md5 }
{ sport sun-dr } apply { auth_alg md5 sa unique }
{ dport cvc_hostd } permit { auth_alg md5 }
{ sport cvc_hostd } apply { auth_alg md5 sa unique }
```

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSr SUNWSMSop

SEE ALSO **ssd**(1M), **sckmd**(1M), **ipseconf**(1M), **pf_key**(1M), **ipsec**(1M), **dca**(1M), **dxs**(1M), **dcs**(1M), **cvcd**(1M)



NAME	hwad - hardware access daemon				
SYNOPSIS	hwad				
DESCRIPTION	<p>hwad(1M) provides the exclusive mechanism by which SMS processes, including daemons, access, control, monitor, and configure the hardware.</p> <p>hwad runs in either main or spare mode and asks the failover daemon (fomd(1M)) for the role that the system controller (SC) should play when it comes up.</p> <p>At start-up, hwad opens all the drivers (sbbc, echip, gchip, and console bus) and uses the ioctl calls to interface with them. It reads the contents of the device presence register to identify the boards present in the system, and makes them accessible to the clients.</p> <p>IOSRAM and Mbox interfaces are also provided by hwad. This helps communication between the SC and the domain. For dynamic reconfiguration (DR), hwad directs communication to the new IOSRAM (tunnel switch). For darb interrupts, hwad notifies the dsmd(1M) if there is a dstop or rstop. It also notifies related SMS daemon(s), depending on the type of Mbox interrupt that occurs.</p> <p>hwad detects and recovers console bus and jtag errors.</p> <p>This daemon is started automatically by the ssd(1M) daemon. Do <i>not</i> start it manually from the command line.</p>				
ATTRIBUTES	See attributes (5) for descriptions of the following attributes.				
	<table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th style="text-align: center;">Attribute Types</th> <th style="text-align: center;">Attribute Values</th> </tr> </thead> <tbody> <tr> <td>Availability</td> <td>SUNWSMSop</td> </tr> </tbody> </table>	Attribute Types	Attribute Values	Availability	SUNWSMSop
Attribute Types	Attribute Values				
Availability	SUNWSMSop				
SEE ALSO	dsmd (1M), ssd (1M)				

NAME	initcmdsinc - command synchronization command
SYNOPSIS	<p>cancelcmdsinc <i>cmdsinc_descriptor</i></p> <p>initcmdsinc <i>script_name</i> [<i>parameters</i>]</p> <p>savecmdsinc <i>-M identifier cmdsinc_descriptor</i></p> <p>[cancel init save]cmdsinc -h</p>
DESCRIPTION	<p>The command synchronization commands work together to control the recovery of user-defined scripts interrupted by a system controller (SC) failover. Insert the following commands in user-defined scripts to enable command synchronization:</p> <p>initcmdsinc Creates a command synchronization descriptor that identifies the script to be recovered.</p> <p> This descriptor is placed on a command synchronization list that identifies the scripts and commands to be restarted on the new main SC after a failover.</p> <p>savecmdsinc Adds a marker that identifies a location in the script from which processing can be resumed after a failover.</p> <p>cancelcmdsinc Removes a command synchronization descriptor from the command synchronization list. This ensures that the script is run only once and not after subsequent failovers.</p> <p> Be sure that all exit paths of a script have a cancelcmdsinc sequence to remove the descriptor from the command synchronization list. If you do not remove the descriptor and a failover occurs, the script is rerun on the new main SC.</p> <p>Note – Both an initcmdsinc and a cancelcmdsinc sequence must be contained within a script to enable command synchronization. The use of the savecmdsinc command is optional and marks only specific points in a script from which processing can be resumed. If specific restart points are not necessary, consider using runccmdsinc(1M) instead.</p>
OPTIONS	<p>The following options are supported:</p> <p>cmdsinc_descriptor Specifies the command synchronization descriptor that identifies the user-defined script. This descriptor is the standard output value returned by the initcmdsinc command.</p>

<code>-h</code>	Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.
<code>-M <i>identifier</i></code>	Marks a location in the script from which the script can be resumed after a failover. The identifier must be a positive integer.
<code><i>parameters</i></code>	Specifies the options or parameters associated with the user-defined script. These parameters are stored on the spare SC and are used to restart the specified script after a failover.
<code><i>script_name</i></code>	Identifies the name of the user-defined script to be synchronized. <code><i>script_name</i></code> must be the absolute path name of an executable command. The command must exist in the same location on both SCs.

**EXTENDED
DESCRIPTION**

The command synchronization commands are inserted at certain logical points within a user-defined script.

For instance, a Korn shell script might be structured as follows:

```
# MAIN CODE STARTS HERE
# Be sure to use a cleanup procedure to handle any
# interrupts.
# Use the cancelcmdsyc to remove the script from the
# command synchronization list. Otherwise, the command
# will get restarted on the new main SC.
#
clean_up () {
    cancelcmdsyc $desc
    exit
}

# Declare the clean_up function to capture system signals
# and cleanup.
trap "clean_up" INT HUP TERM QUIT PWR URG
goto_label=1
# Process the arguments, capturing the -M marker point
# if provided
#
for arg in $*; do
    case $arg in
        -M )
            goto_label=$arg;;
        .
        .
    esac
done
# Place this script and all its parameters in the command
# synchronization list, which indicates the commands to
# be restarted after an SC failover.
#
# NOTE: The script must be executable by the user defined
# in fowd.cf and reside in the same directory on both the
# main and the spare SC.
```

```

# If the command is not part of the defined PATH for
# the user, the absolute filename must be passed with the
# initcmdsyc command
#
initcmdsyc script_name parameters
# The marker point is stored in the goto_label variable.
# Keep executing this script until all cases have been
# processed or an error is detected.
#
while (( $goto_label != 0 )) ; do
#
# Each case should represent a synchronization point
# in the script.
#
case $goto_label in
#
# Step 1: Do something
#
1 )          do_something
              .
              .
              .

# Execute the savecmdsyc command with the script's
# descriptor and a unique marker to save the position.
# If a failover occurs here, the commands represented in
# the next goto_label (2) will be resumed.
#
          savecmdsyc -M $(( $goto_label + 1 )) $desc
          goto_label=$(( $goto_label + 1 ))
          ;;

#
# Step 2: Do more things
#
2 )          do_more_things
              .
              .
              .
          savecmdsyc -M $(( $goto_label + 1 )) $desc
          goto_label=$(( $goto_label + 1 ))
          ;;

#
# Step 3: Finish the last step and set the goto_label to 0
# so that the script ends.
3 )
          finish_last_step
          .
          .
          .
          goto_label=0
          ;;

        esac
done
# END OF MAIN CODE
# Remember to execute cancelcmdsyc to remove the script from the
# command synchronization list. Otherwise, the command will be restarted
# after the failover.
#
cancelcmdsyc $desc

```

Group Privileges Required

You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXIT STATUS

The following exit values are returned:

0 Successful completion.
>0 An error occurred.

Note – The standard output for `initcmdsync` contains the command synchronization descriptor. Also, when failover is disabled (after a failover or in a single SC environment), scripts that contain synchronization commands generate error messages to the platform log file and return nonzero exit codes. These messages can be ignored.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

runcmdsync(1M), **showcmdsync**(1M)



NAME	mand - management network daemon				
SYNOPSIS	mand				
DESCRIPTION	<p>mand(1M) supports the management network (MAN) drivers and the failover management daemon (fomd(1M)) by providing the required network configuration. This configuration information includes host names, IP addresses, and netmasks. mand is also responsible for initializing and updating these respective fields in the platform configuration database (pcd(1M)) daemon as well as the in MAN driver on the system controller (SC).</p> <p>mand is an SMS daemon running on both the main and spare SCs. Its role is set up by fomd.</p> <p>This daemon is started automatically by the ssd(1M) daemon. Do <i>not</i> start it manually from the command line.</p>				
EXTENDED DESCRIPTION	<p>SC-to-Domain and Domain-to-SC Internal Network (I1) data includes:</p> <ul style="list-style-type: none"> ■ Network mask ■ SC host name ■ SC IP address ■ Domain[A-R] host name ■ Domain[A-R] IP address <p>SC-to-SC Internal Network (I2) data includes:</p> <ul style="list-style-type: none"> ■ Network mask ■ SC 0 host name ■ SC 0 IP address ■ SC 1 host name ■ SC 1 IP address <p>SC External Community (C) data includes:</p> <ul style="list-style-type: none"> ■ Community Failover IP address ■ Community physical interface name 				
EXIT STATUS	<p>The following exit values are returned:</p> <table border="0"> <tr> <td style="padding-right: 20px;">0</td> <td>Successful completion.</td> </tr> <tr> <td>>0</td> <td>An error occurred.</td> </tr> </table>	0	Successful completion.	>0	An error occurred.
0	Successful completion.				
>0	An error occurred.				

FILES | The following configuration file is required:

`/etc/opt/SUNWSMS/config/MAN.cf` This file includes the domain-to-SC, the SC-to-domain, and the SC-to-SC management network data as well as the community data for external access to the SC.

Do *not* manually modify the `MAN.cf` file.

ATTRIBUTES | See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO | **fomd**(1M), **pcd**(1M), **smsconfig**(1M), **ssd**(1M)

NAME	mld - message-logging daemon
SYNOPSIS	mld [-f <i>config_file</i>] [-t]
DESCRIPTION	<p>mld(1M) provides logging services to all SMS daemons and processes. mld is the first SMS daemon started by <code>ssd(1M)</code> in order to capture the output of all other SMS daemons and processes during their startup phases.</p> <ul style="list-style-type: none"> ■ Platform log messages are stored in: <ul style="list-style-type: none"> <code>/var/opt/SUNWSMS/adm/platform/messages</code> in the following format: <pre>time host program [pid]:[msg_id hrttime_t level file_line] message</pre> <p><i>file_line</i> is optional and appears only in verbose mode.</p> For example: <pre>Feb 2 09:16:10 2002 sun15 mld[904]:[209 2345678901 INFO MLDLOGGER.cc 141] Platform messages file created.</pre> ■ Domain log messages are stored in <ul style="list-style-type: none"> <code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/messages</code> in the same format as platform messages, with additional <i>domain_id</i> <i>domain_tag</i> information following the pid: <pre>time host program [pid]<i>domain_id</i> <i>domain_tag</i>: [msg_id hrttime_t level file_line] message</pre> For example: <pre>Feb 2 09:18:55 2002 sun15 mld[904]-B (engB): [314 2345678902 ERR LogManager.cc 424] message queue limit exceeded, messages will be dropped.</pre> ■ Domain syslog messages are stored in <ul style="list-style-type: none"> <code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/syslog</code> in the same format in which they are received.
OPTIONS	<p>The following options are supported:</p> <ul style="list-style-type: none"> -f <i>config_file</i> Provides an absolute path to an alternative remote-message-reception configuration file. -t Disables remote message reception (for example, domain syslog messages).

EXIT STATUS .The following exit values are returned:

0 Successful completion.
>0 An error occurred.

FILES The following file is used by this command:

/var/opt/SUNWSMS/adm/.logger Message logging
 daemon configuration
 file.

This file supports three configuration directives:

FILE Specifies where to send messages. The default is `msgdaemon` and should *not* be changed.

LEVEL Specifies the minimum level necessary for `mld` to log a message. The supported levels are: `debug`, `info`, `notice`, `warning`, `err`, `crit`, `alert`, and `emerg`. The default is `notice`.

MODE Specifies the verbosity of the messages. Two modes are available: `verbose` and `terse`. The default is `verbose`.

Note – All directive arguments are not case sensitive.

ATTRIBUTES See `attributes(5)` for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **ssd(1M)**

NAME	moveboard - move a board from one domain to another
SYNOPSIS	<p>moveboard -d <i>domain_indicator</i> [-c <i>function</i>] [-r <i>retry_count</i> [-t <i>timeout</i>]] [-q] [-f] [-y -n] <i>location</i></p> <p>moveboard -h</p>
DESCRIPTION	<p>moveboard(1M) first attempts to unconfigure, disconnect, and unassign <i>location</i> from the domain it is currently assigned to and possibly active in, and then proceeds to assign, connect, and configure <i>location</i> to the domain <i>domain_id</i> or <i>domain_tag</i>.</p> <p>The -c <i>function</i> command option is used to specify the transition of the board from the current configuration state to a new configuration state. Configuration states are assign, connect, and configure. If the -c option is not specified, the default expected configuration state is configure.</p> <p>Note – moveboard performs tasks synchronously and does not return control to the user until the command is complete. If the board is not powered on or tested and a -c connect configure option is specified, then the command powers on the board and tests it.</p> <p>Note – If the specified board is in the automatic system recovery (ASR) blacklist file, moveboard displays an error message when assigning a board and then continues. When using the connect or configure functions, moveboard displays an error message and then exits.</p> <p>Note – If the moveboard command fails, a board does not return to its original state. A dxs or dca error message is logged to the domain. If the error is recoverable, you can retry the command. If it is unrecoverable, you need to reboot the domain in order to use that board.</p>
OPTIONS	<p>The following options are supported.</p> <p>-c <i>function</i> Valid <i>function</i> values are assign, connect, and configure. One of these values is used to control the configuration state transition.</p>

The possible transition states and their meanings are as follows:

<code>assign</code>	Unconfigures the board from the Solaris operating environment running on the domain. Solaris software stops using any of the hardware resources on the board. (See <code>deleteboard -c unconfigure.</code>) Disconnects the board. Transitions the board into the <code>disconnected unconfigured</code> state. (See <code>deleteboard -c disconnect.</code>) Unassigns the board from the current domain. (See <code>deleteboard -c unassign.</code>) Moves the board out of the logical domain by changing its state to <code>available</code> . Assigns the board to the new logical domain. This is a board state in which the domain has sole access to the board; however, the board is not active. Once assigned, the board can be connected or configured into the domain with the use of either <code>setkeyswitch on</code> or the <code>connect</code> or <code>configure</code> options.
---------------------	--

connect

Unconfigures the board from the Solaris operating environment running on the domain. Solaris software stops using any of the hardware resources on the board. (See `deleteboard -c unconfigure`.) Disconnects the board. Transitions the board into the `disconnected|unconfigured` state. (See `deleteboard -c disconnect`.) Unassigns the board from the current domain. (See `deleteboard -c unassign`.) Moves the board out of the logical domain by changing its state to `available`. Assigns the board to the new logical domain. (See `assign` earlier in this section; see also `addboard(1M) -c assign`.) Transitions the board into the `connected|unconfigured` state. In this state the board is assigned to the logical domain and `connected (active)`. This state allows the normal system access to hardware resources on the board. The hardware resources of the board are not represented by the normal Solaris software data structures, however, and cannot be used by the Solaris operating environment. Allowed operations on the board are limited to configuration administration operations. (See also `addboard -c connect`.) This is an intermediate state and does not have any standalone implementation at this time.

`configure` Unconfigures the board from the Solaris operating environment running on the domain. Solaris software stops using any of the hardware resources on the board. (See `deleteboard -c unconfigure.`) Disconnects the board. Transitions the board into the `disconnected|unconfigured` state. (See `deleteboard -c disconnect.`) Unassigns the board from the current domain. (See `deleteboard -c unassign.`) Moves the board out of the logical domain by changing its state to `available`. Assigns the board to the new logical domain. (See `assign` earlier in this section; see also `addboard -c assign.`) Transitions the board into the `connected|unconfigured` state. In this state, the board is assigned to the logical domain and `connected (active)`. This state allows the normal system access to hardware resources on the board. The hardware resources of the board are not represented by the normal Solaris software data structures, however, and cannot be used by the Solaris operating environment. Allowed operations on the board are limited to configuration administration operations. (See `connect` earlier in this section; see also `addboard -c connect.`) Transitions the board into the `connected|configured` state. In this state, the board is not only assigned and connected to a domain, but also configured into the Solaris operating environment. The hardware resources on the board can be used by Solaris software. (See also `addboard -c configure.`)

`-d domain_indicator` Specifies the domain using one of the following:

domain_id – ID for a domain. Valid *domain_ids* are A–R and are not case sensitive.

domain_tag – Name assigned to a domain using `addtag(1M)`.

This is the domain to which the board is being moved.

-f	Forces the specified action to occur. Typically, this is a hardware-dependent override of a safety feature. Forcing a state change operation can allow use of the hardware resources of an occupant that is not in the <code>ok</code> or <code>unknown</code> conditions, at the discretion of any hardware-dependent safety checks.
-h	Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.
-n	Automatically answers no to all prompts. Prompts are displayed unless used with the <code>-q</code> option.
-q	Quiet. Suppresses all messages to <code>stdout</code> including prompts. When used alone <code>-q</code> defaults to the <code>-n</code> option for all prompts. When used with either the <code>-y</code> or the <code>-n</code> option, <code>-q</code> suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen.
-r <i>retry_count</i>	These command arguments enable the user to specify retries in case of failures encountered during state transitions. The <code>-r <i>retry_count</i></code> option can be used alone and indicates the number of times the configuration state change request should be retried by the domain. The <code>-t <i>timeout</i></code> option cannot be used without the <code>-r <i>retry_count</i></code> option and specifies the number of seconds that the domain should wait before the next retry is made. If the <code>-t <i>timeout</i></code> is not specified, the default <i>timeout</i> is zero, meaning that the request is retried immediately.
-t <i>timeout</i>	
-y	Automatically answers yes to all prompts. Prompts are displayed unless used with the <code>-q</code> option.

OPERANDS

The following operands are supported:

location Board location separated by a space. Multiple *location* arguments are *not* permitted.

The following *location* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

Note – Use `showboards(1M)` to display board type.

EXTENDED DESCRIPTION

Group Privileges Required

Users with platform administrator privileges can perform the `-c assign` option if the board is in the `assigned` state (not active in a running domain) of the domain from which the board is being removed.

Users with domain administrator or configurator privileges can execute this command, but only on their respective domains. You must belong to both domain groups affected, and the board must be in the available component list of both domains.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

For all examples, if the board is currently active in another domain, you must have domain administrator privileges for that domain. In addition, you must have platform administrator privileges or the board must be in the domain available component list in order for it to be unassigned from its current domain.

You must have platform privileges or the board must be in the domain's available component list for you to assign the system board to a new domain. In addition, the user must have domain privileges in the new domain in order to connect or configure the board into the domain.

EXAMPLE 1 Assigning a CPU Board at SB4 to Domain A

```
sc0:sms-user:> moveboard -d A -c assign SB4
SB4 assigned to domain: A
```

EXAMPLE 2 Assigning a Blacklisted CPU Board at SB4 to Domain A

```
sc0:sms-user:> moveboard -d A -c assign SB4
SB4 assigned to domain: A
Warning: SB4 is blacklisted.
You will not be able to connect or configure it.
sc0:sms-user:>
```

EXAMPLE 3 Configuring an IO Board Into Domain A

Note: The default function is set to configure.

```
sc0:sms-user:> moveboard -d A IO2
IO2 unassigned from domain: B
IO2 assigned to domain: A
assign IO2
assign IO2 done
poweron IO2
poweron IO2 done
test IO2
test IO2 done
connect IO2
connect IO2 done
configure IO2
configure IO2 done
notify online /devices/pci@5d,700000
notify online /devices/pci@5d,600000
notify online /devices/pci@5c,700000
notify online /devices/pci@5c,600000
notify add capacity IO2 done
```

EXAMPLE 4 Connecting an IO Board at IO7 to Domain R

You must have platform privileges, or the board must be in the domain available component list.

```
sc0:sms-user:> moveboard -d R -c connect IO7
```

EXAMPLE 5 Connecting a Blacklisted Board to Domain C

```
sc0:sms-user:> moveboard -d C -c connect SB0
SB0 is blacklisted. Exiting.
sc0:sms-user:>
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
1	No acknowledge.
2	Not supported.
3	Operation not supported.
4	Invalid privileges.
5	Busy.
6	System busy.
7	Data error.
8	Library error.

9	No library.
10	Insufficient condition.
11	Invalid.
12	Error.
13	A PID does not exist.
14	Invalid attribute.
30	Invalid board ID type.
31	Invalid permissions.
32	Assigned to another domain.
33	Unable to get permissions.
34	Unable to get domain board info.
35	Unable to get active board list.
36	Unable to get assigned board list.
38	Solaris not running.
39	Unable to assign/unassign domain state.
40	Unable to get domain permissions.
41	Unable to get platform permissions.
51	Invalid domain.
52	Invalid privileges.
55	Library error.
56	DR command syntax error.
58	Internal error.
59	Component blacklisted.
60	Unable to get ASR blacklist.
61	Unable to get domain blacklist.
62	Unable to get platform blacklist.
64	Activity check error.
65	Unassign check error.
66	Unassign, unrestricted check error.
67	Domain permissions check error.

70 DR operation failed.

FILES

The following files are used by this command:

<code>/etc/opt/SUNWSMS/config/asr/blacklist</code>	List of components excluded by esmd.
<code>/etc/opt/SUNWSMS/config/platform/blacklist</code>	List of platform components excluded.
<code>/etc/opt/SUNWSMS/config/<i>domain_id</i>/blacklist</code>	List of domain components excluded.

Note – This file is created and used internally and should *not* be edited manually. To remove a component from the ASR blacklist file, use `enablecomponent(1M)`.

ATTRIBUTES

See **attributes(5)** for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **addboard(1M)**, **deleteboard(1M)**, **enablecomponent(1M)**, **esmd(1M)**, **showcomponent(1M)**

NAME	osd - OpenBoot PROM server daemon				
SYNOPSIS	osd				
DESCRIPTION	<p>osd(1M) provides software support for OpenBoot PROM. It provides an SMS event-based interface to <code>setkeyswitch(1M)</code> for laying out IDPROM and REBOOTARGS information prior to domain bring up.</p> <p>osd also receives mailbox commands from OpenBoot PROM. These mailbox commands are acted upon, and a result is returned to OpenBoot PROM. Commands include <code>get-time-of-day</code>, <code>set-time-of-day</code>, <code>get-idprom</code>, <code>get-nvram-data</code>, <code>set-nvram-data</code>, <code>get-reboot-args</code>, <code>set-reboot-args</code>, and <code>do-tunnel-switch</code>. One instance of <code>osd</code> on the system controller (SC) is shared between all domains.</p> <p>This daemon is automatically started by <code>ssd(1M)</code>. Do <i>not</i> start it manually from the command line.</p>				
EXTENDED DESCRIPTION					
Group Privileges Required	osd is run as the <code>sms-osd</code> user.				
EXIT STATUS	<p>The following exit values are returned:</p> <p>0 Successful completion.</p> <p>>0 An error occurred.</p>				
ATTRIBUTES	See attributes (5) for descriptions of the following attributes.				
	<table border="1"> <thead> <tr> <th style="text-align: center;">Attribute Types</th> <th style="text-align: center;">Attribute Values</th> </tr> </thead> <tbody> <tr> <td>Availability</td> <td>SUNWSMSop</td> </tr> </tbody> </table>	Attribute Types	Attribute Values	Availability	SUNWSMSop
Attribute Types	Attribute Values				
Availability	SUNWSMSop				
SEE ALSO	setkeyswitch (1M)				

NAME	pcd - platform configuration database daemon
SYNOPSIS	pcd
DESCRIPTION	<p>pcd(1M) provides and manages controlled access to platform, domain, and system board configuration data. It is an SMS daemon running on the system controller (SC) and a key component of SMS configuration. All system management applications access the database information through the pcd daemon.</p> <p>In addition to managing platform configuration data, the pcd notifies registered system management applications when pertinent database changes have occurred. These notifications are registered as events and are transparent to the user.</p> <p>This daemon is started automatically by the ssd(1M) daemon. Do <i>not</i> start it manually from the command line.</p>
EXTENDED DESCRIPTION	<p>Platform data includes:</p> <hr/> <pre>Platform type Platform name Rack ID Cacheable Memory Address Slice Map System clock frequency System clock type SC IP address SC0 to SC1 IP address SC1 to SC0 IP address SC to SC IP netmask</pre> <hr/> <p>Domain data includes:</p> <hr/> <pre>Domain ID/Tag OS version (not used) OS type (not used) Available component list Assigned board list Active board list Golden IOSRAM I/O board Virtual keyswitch setting Active Ethernet I/O board Domain creation time Domain dump state Domain bring up priority IP host addressHost name Host netmask Host broadcast address</pre> <hr/>

System board data includes:

Expander Position
 Slot position
 Board type
 Board state
 Domain assignment of the
 board
 Available component list
 state
 Board test status
 Board test level
 Memory cleared state

SIGNALS

SIGHUP Rereads the database files and recaches information.

FILES

Note – *Never* modify these files by hand.

The following files are supported:

<code>/var/opt/SUNWSMS/.pcd/platform_info</code>	Contains platform database information.
<code>/var/opt/SUNWSMS/.pcd/domain_info</code>	Contains domain database information.
<code>/var/opt/SUNWSMS/.pcd/sysboard_info</code>	Contains system board database information

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

ssd(1M)

NAME	poweroff - control power off
SYNOPSIS	poweroff [-q] [-y -n] [<i>location</i>] poweroff -h
DESCRIPTION	<p><code>poweroff(1M)</code> powers off the specified dual 48V power supply, fan tray, or board. If no arguments are specified and you have platform administrator privileges, the entire system, with the exception of the bulk power supplies, the fan trays, and the spare system controller (SC), powers off. If active domains are utilizing the component that is going to be powered off, a listing of those domains and an "Are you sure?" prompt is given by default.</p> <p>Note – When you power off a bulk power supply <code>poweroff</code> trips the circuit breaker. In that case the <code>poweron</code> command alone can not restore power. You must manually flip the breaker back on and then run <code>poweron</code>.</p> <p>If you do not have platform administrator privileges, the [<i>location</i>] command operand <i>must</i> be specified and the board must be assigned to a domain for which you have domain administrator or configurator privileges.</p> <p>Note – This command has no effect on the position of the virtual keyswitch.</p>
OPTIONS	<p>The following options are supported:</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option.</p> <p>-q Quiet. Suppresses all messages to <code>stdout</code> including prompts.</p> <p> When used alone -q defaults to the -n option for all prompts.</p> <p> When used with either the -y or the -n option, -q suppresses all user prompts, and automatically answers with either 'y' or 'n' based on the option chosen.</p> <p>-y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.</p>

OPERANDS

The following operands are supported:

location Component location separated by a space. Multiple *location* forms are *not* permitted.

The following *location* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

CS(0|1), CS(0|1)

FT(0...7), FT(0...7)

PS(0...5), PS(0...5)

EX(0...17), EX (0...8)

SC(0|1), SC(0|1) [Only the spare SC can be powered off.]

EXTENDED DESCRIPTION**Group Privileges Required**

You must have either platform administrator or domain administrator/configurator privileges to run this command.

If you have domain privileges, you must also specify the [*location*] operand, and the [*location*] must be a domain configuration unit (DCU) that is assigned to a domain for which you have domain privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Powering Off a Power Supply

In this example `poweroff` prompts you for a reply.

```
sc0:sms-user:> poweroff ps5
This will trip the breakers on PS at PS5, which must be turned on manually!
Are you sure you want to continue to power off this component? (yes/no)? Y
```

EXAMPLE 2 Powering Off a CPU Board at Expander Position 0

In this example `poweroff` forces the board off by suppressing any `stdout` messages and answering yes to all prompts.

```
sc0:sms-user:> poweroff -qy SB0
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.

>0 An error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

poweron(1M)

NAME	poweron - control power on
SYNOPSIS	poweron [-q] [-y -n] [<i>location</i>] poweron -h
DESCRIPTION	<p>poweron(1M) powers on the specified dual 48V power supply, fan tray, or board. If no arguments are specified and you have platform administrator privileges, the entire system is powered on (provided that no additional 48V power supply modules need to be powered on to support the new power requirements).</p> <p>Note – When you power off a bulk power supply <code>poweroff</code> trips the circuit breaker. In that case the <code>poweron</code> command alone can not restore power. You must manually flip the breaker back on, and then run <code>poweron</code>.</p> <p>If you do not have platform administrator privileges, the <code>location</code> command operand <i>must</i> be specified and the board must be assigned to a domain for which you have domain administrator or configurator privileges. If sufficient power and cooling is not available for the requested board, the <code>poweron</code> operation fails. A minimum of five 48V power supply modules (4 KW modules) are required to power a fully configured system. Thus, with N+1 redundancy, six power supply modules are used. If powering on a component requires another component to be powered on, such as a board requiring a 48V power supply module, the <code>poweron</code> request fails.</p> <p>If a specified component is in the automatic system recovery (ASR) blacklist file, an error message is displayed. If you have platform administrator privileges you are prompted to continue. If you do not, the operation is terminated and an error message is displayed.</p>
OPTIONS	<p>The following options are supported.</p> <p>-h Help. Displays usage descriptions.</p> <p> Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option.</p> <p>-q Quiet. Suppresses all messages to <code>stdout</code> including prompts.</p> <p> When used alone -q defaults to the -n option for all prompts.</p> <p> When used with either the -y or the -n option, -q suppresses all user prompts, and automatically answers with either 'y' or 'n' based on the option chosen.</p> <p>-y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.</p>

OPERANDS

The following operands are supported:

location Component location separated by a space. Multiple *location* forms are *not* permitted.

The following *location* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

CS(0|1), CS(0|1)

FT(0...7), FT(0...7)

PS(0...5), PS(0...5)

EX(0...17), EX (0...8)

EXTENDED DESCRIPTION**Group Privileges Required**

You must have either platform administrator or domain administrator/configurator privileges to run this command.

If you have domain privileges, you must also specify the *location* operand and the *location* must be a domain configuration unit (DCU) that is assigned to a domain for which you have domain privileges.

You must have platform administrator privileges in order to power on a board listed in the ASR blacklist file.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Powering On the Dual 48V Power Supply

The power supply is located on the front side in the 0 bank position.

```
sc0:sms-user:> poweron PS0
```

EXAMPLE 2 Powering On the Dual 48V Power Supply When Both AC Inputs are Bad

When the AC inputs are bad you will receive a warning.

```
sc0:sms-user:> poweron PS0
Both AC inputs to PS0 are bad, did you remember to turn on the breakers?
```

EXAMPLE 3 Powering On a CPU in the ASR Blacklist File

You must have platform administrator privileges. Otherwise, `poweron` terminates and displays an error message.

```
sc0:sms-user:> poweron SB0
Component SB0 is in the ASR blacklist.
Are you sure you want to continue the power ON (yes/no)? Y
```

EXIT STATUS

The following exit values are returned:

```
0           Successful completion.
>0         An error occurred.
```

FILES

The following file is used by this command:

```
/etc/opt/SUNWSMS/config/asr/blacklist           List of components
                                                excluded by esmd.
```

Note – This file is created and used internally and should *not* be edited manually.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

esmd(1M), **poweroff**(1M)



NAME	rcfgadm - remote configuration administration
SYNOPSIS	<pre>rcfgadm -d domain_indicator [-f] [-y -n] [-v] [-o hardware_options] -c function [-r retry_count [-T timeout]] ap_id...</pre> <pre>rcfgadm -d domain_indicator [-f] [-y -n] [-v] [-o hardware_options] -x hardware_function ap_id...</pre> <pre>rcfgadm -d domain_indicator [-v] [-a] [-s listing_options] [-o hardware_options] [-l [ap_id ap_type]...]</pre> <pre>rcfgadm -d domain_indicator [-v] [-o hardware_options] -t ap_id...</pre> <pre>rcfgadm -d domain_indicator [-v] [-o hardware_options] -h [ap_id ap_type]</pre>
DESCRIPTION	<p>rcfgadm(1M) provides remote configuration administration operations on dynamically reconfigurable hardware resources. The rcfgadm command allows configuration administration operations on the specified domain from the system controller. These operations include displaying status (-l), initiating testing (-t), invoking configuration state changes (-c), invoking hardware specific functions (-x), and obtaining configuration administration help messages (-h).</p> <p>rcfgadm performs configuration administration at attachment points, which are places where system software supports dynamic reconfiguration of hardware resources during continued operation of Solaris software.</p> <p>Configuration administration distinguishes between hardware resources that are physically present in the machine and hardware resources that are configured and visible to the Solaris environment. The nature of configuration administration functions are hardware-specific and rcfgadm performs configuration by calling hardware-specific libraries.</p> <p>Configuration administration operates on an attachment point. Hardware resources located at attachment points might or might not be physically replaceable during system operation but are dynamically reconfigurable by way of the configuration administration interfaces.</p> <p>An attachment point defines two unique elements, which are distinct from the hardware resources that exist beyond the attachment point. The two elements of an attachment point are a receptacle and an occupant. Physical insertion or removal of hardware resources occurs at an attachment point and results in a receptacle gaining or losing an occupant. Configuration administration supports the physical insertion and removal operations, as well as other configuration administration functions at an attachment point.</p> <p>Attachment points have associated state and condition information. The configuration administration interfaces provide control for transitioning attachment point states. A receptacle can exist in one of three states: <i>empty</i>, <i>disconnected</i>, or</p>

connected. An occupant can exist in one of two states: `configured` or `unconfigured`.

A receptacle can provide the `empty` state, which is the normal state of a receptacle when the attachment point has no occupants. A receptacle can also provide the `disconnected` state if it has the capability of isolating its occupants from normal system access. Typically this state is used for various hardware-specific testing prior to bringing the occupant's resources into full use by the system, or as a step in preparing an occupant for physical removal or reconfiguration. A receptacle in the `disconnected` state isolates its occupant from the system as much as its hardware allows, but can provide access for testing and setup. A receptacle must provide the `connected` state, which allows normal access to hardware resources contained on any occupants. The `connected` state is the normal state of a receptacle that contains an occupant and that is not currently undergoing configuration administration operations.

The hardware resources contained on an occupant in the `unconfigured` state are not represented by normal Solaris software data structures and are thus not available for use by the Solaris operating environment. Operations allowed on an `unconfigured` occupant are limited to configuration administration operations. The hardware resources of an occupant in the `configured` state are represented by normal Solaris software data structures, and thus some or all of those hardware resources can be in use by the Solaris operating environment. All occupants provide both the `configured` and `unconfigured` states.

An attachment point can be in one of five conditions: `unknown`, `ok`, `failing`, `failed`, or `unusable`. An attachment point can enter the system in any condition, depending upon results of power-on tests and nonvolatile record keeping.

An attachment point with an occupant in the `configured` state is in one of four conditions: `unknown`, `ok`, `failing`, or `failed`. If the condition is not `failing` or `failed`, an attachment point can change to `failing` during the course of operation if a hardware-dependent recoverable error threshold is exceeded. If the condition is not `failed`, an attachment point can change to `failed` during operation as a result of an unrecoverable error.

An attachment point with an occupant in the `unconfigured` state can be in any of the defined conditions. The condition of an attachment point with an `unconfigured` occupant can decay from `ok` to `unknown` after a system-dependent time threshold. Initiating a test function changes the attachment point condition to `ok`, `failing`, or `failed`, depending on the outcome of the test. An attachment point that does not provide a test function can leave the attachment point in the `unknown` condition. If a test is interrupted, the attachment point condition can be set to the previous condition, to `unknown`, or to `failed`. An attachment point in the `unknown`, `ok`, `failing`, or `failed` conditions can be retested.

An attachment point can exist in the `unusable` condition for a variety of reasons, such as inadequate power or cooling for the receptacle, an occupant that is

unidentifiable, unsupported, incorrectly configured, and so on. An attachment point in the `unusable` condition can never be used by the system. It typically remains in this condition until the physical cause is remedied.

An attachment point also maintains `busy` information that indicates when a state change is in progress or the condition is being reevaluated.

Designate attachment points using hardware-specific identifiers (*ap_ids*) that are related to the type and location of the attachment points in the system device hierarchy. An *ap_id* cannot be ambiguous; it must identify a single attachment point. Two types of *ap_id* specifications are supported: physical and logical.

A physical *ap_id* contains a fully specified path name, while a logical *ap_id* contains a shorthand notation that identifies an attachment point in a more user-friendly way.

For example, an attachment point representing system board 6 would have a physical *ap_id* of `/devices/pseudo/dr@0:SB6`, while the logical *ap_id* would be `SB6`.

Attachment points can also be created dynamically. A dynamic attachment point is named relative to a base attachment point that is present in the system. *ap_ids* for dynamic attachment points consist of a base component followed by two colons (`::`) and a dynamic component. The base component is the base attachment point *ap_id*. The dynamic component is hardware-specific and is generated by the corresponding hardware-specific library.

For example, consider a base attachment point, which represents a system board, with the physical *ap_id* `/devices/pseudo/dr@0:SB16` and logical *ap_id* `SB16`.

A CPU attached to this system board could be represented by a dynamic attachment point with logical *ap_id* `SB16::cpu2`, where `SB16` is the base component and `cpu2` is the hardware-specific dynamic component. Similarly, the physical *ap_id* for this dynamic attachment point would be:

```
/devices/pseudo/dr@0:SB16::cpu2.
```

An *ap_type* is a partial form of a logical *ap_id* that can be ambiguous and not specify a particular attachment point. An *ap_type* is a substring of the portion of the logical *ap_id*, up to but not including, the colon (`:`) separator. For example, an *ap_type* of `pci` would show all attachment points whose logical *ap_ids* begin with `pci`.

The use of *ap_types* is discouraged. The new `select` suboption to the `-s` option provides a more general and flexible mechanism for selecting attachment points. See `OPTIONS`.

`rcfgadm` interacts primarily with hardware-dependent functions contained in hardware-specific libraries, and thus its behavior is hardware-dependent.

For each configuration administration operation, a service interruption can be required. If the requested operation requires a noticeable service interruption to interactive users, confirmation is requested before the operation is started.

A prompt is displayed on the standard error output for confirmation on the standard input. Confirmation can be overridden with the `-y` or `-n` option to always answer `yes` or `no`, respectively. Hardware-specific options, such as *test level*, are supplied as suboptions using the `-o` option.

Operations that change the state of the system configuration are audited by the system log daemon `syslogd(1M)`.

The arguments for this command conform to the `getopt(3C)` and `getsubopt(3C)` syntax conventions.

Refer to the *Sun Fire 15K/12K Dynamic Reconfiguration User Guide* for more information.

OPTIONS

The following options are supported.

Note – If the `rcfgadm` command fails, a board does not return to its original state. A `dxs` or `dca` error message is logged to the domain. If the error is recoverable, you can retry the command. If it is unrecoverable, you need to reboot the domain in order to use that board.

- | | |
|---------------------------------|--|
| <code>-a</code> | Specifies that the <code>-l</code> option must also list dynamic attachment points. |
| <code>-c <i>function</i></code> | Performs the state change function on the attachment point specified by <i>ap_id</i> .

Specify function as <code>disconnect</code> , <code>connect</code> , <code>configure</code> , or <code>unconfigure</code> . These functions cause state transitions at the attachment point by calling hardware-specific library routines. |

The possible transition states and their meanings are as follows:

- `disconnect`

Change the receptacle state to disconnected.

If the occupant state is configured, the `disconnect` function first attempts to unconfigure the occupant. The `disconnect` function powers the board off by default. The board is ready to be removed from the slot at that point. The `-o nopoweroff` option specifies skipping the power off step, leaving the board powered on. The board is left assigned to the domain by default. The `-o unassign` option instructs the domain to give up the ownership of the board once the board is disconnected. Once the board has been unassigned, it may no longer be accessible to `cfgadm` because another domain might have assigned the board to itself.

- `connect`

Performs hardware-specific operations to put the receptacle into the `connected` state, which allows an occupant to operate normally through the receptacle.

- `configure`

Performs hardware-specific operations that allow an occupant's hardware resources to be used by Solaris software. Occupants that are configured are part of the system configuration and are available for manipulation by Solaris software device manipulation maintenance commands (for example, `psradm(1M)`, `mount(1M)`, and `ifconfig(1M)`).

- `unconfigure`

Performs hardware-specific operations that logically remove an occupant's hardware resources from the system. The occupant must currently be configured, and its hardware resources must not be in use by the Solaris operating environment.

State transition functions can fail due to the condition of the attachment point or other hardware-dependent considerations. All state change functions in the direction of adding resources (`connect` and `configure`) are passed on to the hardware-specific library when the attachment point is in the `ok` or `unknown` condition. All other conditions require the use of the `force (-f)` option to allow these functions to be passed on to the hardware-specific library. Attachment point condition does not prevent a hardware-specific library being called for the removal (`disconnect` and `unconfigure`) of hardware resources from the system. Hardware-specific libraries can reject state change functions if the attachment point is in the `unknown` condition.

The condition of an attachment point is not necessarily changed by the state change functions; however, errors during state change operations can change the attachment point condition. Specify the `force (-f)` option to override a condition and force a state change that would otherwise fail. Hardware-specific safety and integrity checks can prevent the `force` option from having any effect.

`-d domain_indicator`

Specifies the domain using one of the following:

domain_id – ID for a domain. Valid *domain_ids* are A–R and are not case sensitive.

domain_tag – Name assigned to a domain using `addtag(1M)`.

`-f`

Forces the specified action to occur. Typically, this is a hardware-dependent override of a safety feature. Forcing a state change operation can allow use of the hardware resources of an occupant that is not in the `ok` or `unknown` condition, at the discretion of any hardware-dependent safety checks.

`-h [ap_id | ap_type]`

Prints the help message text. If *ap_id* or *ap_type* is specified, the help routine of the hardware-specific library for the attachment point indicated by the argument is called.

-l [<i>ap_id</i> <i>ap_type</i>]	Lists the state and condition of attachment points specified. Filter attachment points with the <code>-s</code> option and select suboption. Invoking <code>rcfgadm</code> without one of the action options is equivalent to <code>-l</code> without an argument. The format of the list display is controlled by the <code>-v</code> and <code>-s</code> options. When the <code>-a</code> option is specified, attachment points are dynamically expanded.
-n	Automatically answers no to all prompts.
-o <i>hardware_options</i>	Supplies hardware-specific options to the main command option. The following are valid <i>hardware_options</i> : <ul style="list-style-type: none"> ■ <code>parsable</code> Applies only when the <code>-s</code> option is used. The <code>parsable</code> suboption specifies that info is returned for system board and IO assembly only. ■ <code>unassign</code> Applies only when the <code>-c</code> disconnect option is used. The <code>unassign</code> suboption specifies that the domain is to give up ownership of the board. ■ <code>nopoweroff</code> Applies only when the <code>-c</code> disconnect option is used. The <code>nopoweroff</code> suboption specifies that the board is not to be powered off after it is disconnected.
-r <i>retry_count</i>	Specifies the number of times the dynamic reconfiguration (DR) request is retried on the domain. The default is zero.
-s <i>listing_options</i>	Supplies listing options to the list (<code>-l</code>) command. <i>listing_options</i> conforms to the <code>getsubopt(3C)</code> syntax convention. The suboptions are used to specify the attachment point selection criteria (<code>select=select_string</code>), the type of matching desired (<code>match=match_type</code>), the order of listing (<code>sort=field_spec</code>), the data that is displayed (<code>cols=field_spec</code> and <code>cols2=field_spec</code>), the column delimiter (<code>delim=string</code>), and whether to suppress column headings (<code>noheadings</code>).

When the `select` suboption is specified, only attachment points that match the specified criteria are listed. The `select` suboption has the following syntax:

```
rcfgadm -s
select=attr1(value1):attr2(value2)...
```

where an `attr` is one of `ap_id`, `class`, or `type`. `ap_id` refers to the logical `ap_id` field, `class` refers to attachment point class, and `type` refers to the `type` field. `value1`, `value2`, and so on are the corresponding values to be matched. The type of match can be specified by the `match` suboption as follows:

```
rcfgadm -s
match=match_type,select=attr1(value1)...
```

where `match_type` can be either `exact` or `partial`. The default value is `exact`.

Suboptions can contain special characters that can be interpreted in ways other than as part of `rcfgadm` suboptions. For example, a command might contain parentheses, which are acceptable for suboptions but are interpreted as special characters when entered on the command line. Arguments to the `select` suboption can be quoted to protect them from the UNIX C shell interpretation.

A *field_spec* is one or more data-fields concatenated with the use of a colon (:), as in `data-field:data-field:data-field`. A data-field is comprised of `ap_id`, `physid`, `r_state`, `o_state`, `condition`, `type`, `busy`, `status_time`, `status_time_p` and `info`. The `ap_id` field output is the logical name for the attachment point, while the `physid` field contains the physical name. The `r_state` field can be `empty`, `disconnected`, or `connected`. The `o_state` field can be `configured` or `unconfigured`. The `busy` field can be either `y` if the attachment point is `busy`, or `n` if it is not. The `type` and `info` fields are hardware-specific. The `status_time_p` field is a parsable version of the `status_time` field. If an attachment point has an associated class, the `class` field lists the class name.

The order of the fields in *field_spec* is significant. For the *sort* suboption, the first field given is the primary sort key. For the *cols* and *cols2* suboptions, the fields are printed in the order requested. Reverse the order of sorting on a data-field by placing a minus (-) before the data-field name within the *field_spec* for the *sort* suboption. The default value for *sort* is *ap_id*. The default values for *cols* and *cols2* depend on whether the *-v* option is given. Without it, *cols* is

```
ap_id:r_state:o_state:condition and cols2 is not set; with -v, cols is
```

```
ap_id:r_state:o_state:condition:info and cols2 is status_time:type:busy:physid.
```

The default value for *delim* is a single space. The value of *delim* can be a string of arbitrary length. The delimiter cannot include a comma (,) character; see *getsubopt(3C)*. These listing options can be used to create parsable output.

-T timeout

Specifies the time interval, in seconds, between retries. This option cannot be used alone and must be specified with the *-r retry_count* option. The default value is zero, meaning that the DR request is retried immediately.

-t

Performs a test of one or more attachment points. The test function is used to reevaluate the condition of the attachment point.

The results of the test are used to update the condition of the specified occupant to *ok* if no faults are found, *failing* if recoverable faults are found, or *failed* if any unrecoverable faults are found.

If a test is interrupted, the attachment point condition can be restored to its previous value, set to *unknown* if no errors were found, set to *failing* if only recoverable errors were found, or set to *failed* if any unrecoverable errors were found. The attachment point should be set to *ok* only upon normal completion of testing with no errors.

-v

Executes in verbose mode. For the *-c*, *-t*, and *-x* options, displays a message giving the results of each attempted operation. Displays detailed help information for the *-h* option. Displays verbose information for each attachment point for the *-l* option.

- `-x hardware_function` Performs hardware-specific functions.
Lists hardware-specific private functions using `rcfgadm -h ap_id`.
- The following are valid for *hardware_function*:
- `assign ap_id`
Assign a board to a domain.
 - `unassign ap_id`
Unassign a board from a domain.
 - `poweron ap_id`
Power on a board.
 - `poweroff ap_id`
Power off a board.
- `-y` Automatically answers yes to all prompts. Prompts are displayed.

OPERANDS The following operands are supported:

ap_id Refer to attachment points by hardware-specific identifiers (*ap_ids*) that are related to the type and location of the attachment points in the system device hierarchy. An *ap_id* cannot be ambiguous; it must identify a single attachment point. Two types of *ap_id* specifications are supported: physical and logical. A physical *ap_id* contains a fully specified path name, while a logical *ap_id* contains a shorthand notation that identifies an attachment point in a more user-friendly way.

Physical *ap_ids*:

/devices/pseudo/dr@0:IO4

/devices/pseudo/dr@0:IO6

/devices/pseudo/dr@0:IO14

/devices/pseudo/dr@0:SB4

/devices/pseudo/dr@0:SB6

Logical *ap_ids*:

IO4

IO6

IO14

SB4

SB6

ap_type An *ap_type* is a partial form of a logical *ap_id* that can be ambiguous and not specify a particular attachment point. An *ap_type* is a substring of the portion of the logical *ap_id* up to, but not including, the colon (:) separator. For example, an *ap_type* of `pci` would show all attachment points whose logical *ap_ids* begin with `pci`. The two *ap_types* shown here are static and dynamic.

Static *ap_types*:

HPCI

CPU

MCPU

`pci-pci/hp`

Dynamic *ap_types*:

cpu

mem

io

EXTENDED DESCRIPTION

Group Privileges Required

The privileges required for using this command depend on the desired operation. `rcfgadm` can assign or unassign boards that are not connected to a domain. To assign or unassign a board, you must have either platform administrator privileges or domain administrator/configurator privileges for the specified domain *and* the board must be in the domain's available component list. For more information see `setupplatform(1M)` and `showplatform(1M)`.

The `assign` and `unassign` operations are private, hardware-specific operations. Assign a board using `rcfgadm -x assign ap_id`. Unassign a board using `rcfgadm -x unassign ap_id`. The *ap_ids* for `assign` and `unassign` must be logical *ap_ids* specifying a board, such as `SB0` or `IO2`.

Domain administrator or domain configurator privileges are required for `test`, `state change`, `list` or hardware-specific operations.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1 Listing Attachment Points in the Device Tree for Domain A**

The following example lists all attachment points except dynamic attachment points.

```
sc0:sms-user:> rcfgadm -d a
Ap_Id      Type      Receptacle  Occupant    Condition
IO4        PCI       connected   configured  ok
IO6        MCPU     disconnected  unconfigured unknown
IO14       PCI       connected   configured  ok
SB4        CPU      disconnected  unconfigured unknown
SB6        CPU      connected   configured  ok
SB16       CPU      connected   configured  ok
```

EXAMPLE 2 Listing All Configurable Hardware Information for Domain A

The following example lists all current configurable hardware information, including those represented by dynamic attachment points:

```
sc0:sms-user:> rcfgadm -d a -al
Ap_Id      Type      Receptacle  Occupant    Condition
IO4        PCI       connected   configured  ok
IO4::pci0  io        connected   configured  ok
IO4::pci1  io        connected   configured  ok
IO4::pci2  io        connected   configured  ok
IO4::pci3  io        connected   configured  ok
IO6        MCPU     disconnected  unconfigured unknown
IO14       PCI       connected   configured  ok
IO14::pci0 io        connected   configured  ok
IO14::pci1 io        connected   configured  ok
IO14::pci2 io        connected   configured  ok
IO14::pci3 io        connected   configured  ok
SB4        CPU      disconnected  unconfigured unknown
SB6        CPU      connected   configured  ok
SB6::cpu0  cpu      connected   configured  ok
SB6::cpu1  cpu      connected   configured  ok
SB6::cpu2  cpu      connected   configured  ok
SB6::cpu3  cpu      connected   configured  ok
SB6::memory memory   connected   configured  ok
SB16       CPU      connected   configured  ok
SB16::cpu0 cpu      connected   configured  ok
SB16::cpu1 cpu      connected   configured  ok
SB16::cpu2 cpu      connected   configured  ok
SB16::cpu3 cpu      connected   configured  ok
SB16::memory memory   connected   configured  ok
```

EXAMPLE 3 Creating a Selective List Based on Attachment Point Attributes for Domain A

The following example lists all attachment points at *location* SB6 and of *type* cpu. The argument to the `-s` option is quoted to protect it from the shell.

```
sc0:sms-user:> rcfgadm -d a -s match=partial,select="type(cpu)" -
la SB6
Ap_Id          Type      Receptacle  Occupant    Condition
SB6::cpu0     cpu      connected   configured  ok
SB6::cpu1     cpu      connected   configured  ok
SB6::cpu2     cpu      connected   configured  ok
SB6::cpu3     cpu      connected   configured  ok
```

EXAMPLE 4 Listing Current Configurable Hardware Information in Verbose Mode for Domain A

The following example lists current configurable hardware information in verbose mode:

```
sc0:sms-user:> rcfgadm -d a -v -l SB16
Ap_Id  Receptacle  Occupant    Condition  Information
SB16   connected   configured  ok         powered-on, assigned
When   Type        Busy   Phys_Id
Mar 6 13:30 CPU     n      /devices/pseudo/dr@0:SB16
```

EXAMPLE 5 Using the Force Option on Domain A

The following example configures an occupant in the failing state to the system using the force option:

```
sc0:sms-user:> rcfgadm -d a -f -c configure SB6
```

EXAMPLE 6 Unconfiguring an Occupant From the System on Domain A

The following example unconfigures an occupant from the system:

```
sc0:sms-user:> rcfgadm -d a -c unconfigure IO14
```

EXAMPLE 7 Configuring an Occupant at an Attachment Point

The following example configures an occupant:

```
sc0:sms-user:> rcfgadm -d a -c configure SB6
```

EXAMPLE 8 Using the `-o` parsable option:

The following example displays system board and IO assembly information as a set of “name=value” pairs:

```
sc0:sms-user:> rcfgadm -d G -s cols=ap_id:type -o parsable
Ap_Id                                     Type
IO0                                       unknown
IO5                                       HPCI
IO11                                      HPCI
SB0                                       CPU
SB11                                      CPU
```

EXAMPLE 9 Disconnecting But Not Powering Off SB0:

The following example displays domain G giving up ownership of the board.

```
sc0:sms-user:> rcfgadm -d G -c disconnect -o unassign,nopoweroff
SB0
```

**ENVIRONMENT
VARIABLES**

See **environ**(5) for descriptions of the following environment variables that affect the execution of `command_name`: LC_TIME, LC_MESSAGES, TZ.

LC_MESSAGES	Determines how <code>rcfgadm</code> displays column headings and error messages. Listing output data is not affected by the setting of this variable.
LC_TIME	Determines how <code>rcfgadm</code> displays human-readable status changed time (<i>status_time</i>).
TZ	Specifies the time zone used when converting the status changed time. This applies to both the human-readable (<i>status_time</i>) and parsable (<i>status_time_p</i>) formats.

EXIT STATUS

The following exit values are returned:

0	Successful completion.
1	No acknowledge.
2	Not supported.
3	Operation not supported.
4	Invalid privileges.
5	Busy.
6	System busy.
7	Data error.
8	Library error.

9	No library.
10	Insufficient condition.
11	Invalid.
12	Error.
13	A PID does not exist.
14	Invalid attribute.
30	Invalid board ID type.
31	Invalid permissions.
32	Assigned to another domain.
33	Unable to get permissions.
34	Unable to get domain board info.
35	Unable to get active board list.
36	Unable to get assigned board list.
37	Get blacklist failed.
38	Solaris not running.
39	Invalid privileges.
40	Unable to get domain permissions.
41	Unable to get platform permissions.
42	Failed to get domain blacklist.
43	Failed to get platform blacklist.
56	DR command syntax error.
70	DR operation failed.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **cfgadm_sbd**(1M), **setupplatform**(1M), **showplatform**(1M)

DIAGNOSTICS

Diagnostic messages appear on the standard error output. Other than options and usage errors, the following are diagnostic messages produced by this utility:

rcfgadm: Configuration administration not supported on *ap_id*

rcfgadm: No library found for *ap_id*

rcfgadm: *ap_id* is ambiguous

rcfgadm: Operation: Insufficient privileges

rcfgadm: Attachment point is busy, try again

rcfgadm: No attachment points with specified attributes found

rcfgadm: System is busy, try again

rcfgadm: Operation: Operation requires a service interruption

rcfgadm: Operation: Data error: error_text

rcfgadm: Operation: Hardware specific failure: error_text

rcfgadm: Attachment point not found

rcfgadm: Configuration operation succeeded

rcfgadm: Configuration operation canceled

rcfgadm: Configuration operation invalid

rcfgadm: Configuration operation not supported

rcfgadm: Library error

rcfgadm: Insufficient condition

rcfgadm: SCDR/DCA door failure

rcfgadm: DCA/DCS communication error

rcfgadm: DCA internal failure

rcfgadm: PCD event failure

rcfgadm: Callback function failure

rcfgadm: SCDR library internal error

rcfgadm: Board is already assigned to another domain

rcfgadm: Unable to get active or assigned domain info

rcfgadm: Unable to get privileges

rcfgadm: DRCMD library invalid parameter

See `config_admin(3CFGADM)` for additional details regarding error messages.



NAME	reset - send reset to all CPU ports of a specified domain
SYNOPSIS	<pre>reset -d <i>domain_indicator</i> [, <i>domain_indicator</i>]... [-d <i>domain_indicator</i> [, <i>domain_indicator</i>]...] [-q] [-y -n] [-x] reset -h</pre>
DESCRIPTION	<p>reset(1M) enables you to reset one or more domains in one of two ways: reset the hardware to a clean state or send an externally initiated reset (XIR) signal. The default is to reset the hardware to a clean state. You receive an error if the virtual keyswitch is in the <i>secure</i> position. By default, <i>reset</i> gives an optional confirmation prompt. Refer to Chapter 6, “Domain Control,” in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 2em;"><i>domain_id</i> -ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 2em;"><i>domain_tag</i> - Name assigned to a domain using <i>addtag(1M)</i>.</p> <p>Note – Multiple <i>domain_indicators</i> must be separated by a comma.</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option.</p> <p>-q Quiet. Suppresses all messages to <i>stdout</i> including prompts.</p> <p>When used alone -q defaults to the -n option for all prompts.</p> <p>When used with either the -y or the -n option, -q suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen.</p> <p>-x Send an XIR signal to the processors in the specified domain.</p> <p>-y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.</p>

**EXTENDED
DESCRIPTION****Group Privileges
Required**

You must have domain administrator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Resetting Domain C

```
sc0:sms-user:> reset -d C Do you want to send RESET to domain C? [y|n]: y
RESET to port SB4/P0 initiated. RESET to port SB4/P1 initiated.
RESET initiated to all ports for domain: C
```

EXAMPLE 2 XIR Reset of Domain C

```
sc0:sms-user:> reset -d C -x
Do you want to send XIR to domain C? [y|n]:y
XIR to processor SB3/P0 initiated
XIR to processor SB3/P1 initiated
XIR to processor SB3/P2 initiated
XIR to processor SB3/P3 initiated
XIR initiated to all processors for domain: C
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.
>0 An error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M)

NAME	resetsc - reset the <i>other</i> system controller (SC)
SYNOPSIS	resetsc [-q] [-y] [-n] resetsc -h
DESCRIPTION	<code>resetsc(1M)</code> resets the <i>other</i> SC. This might typically be done after failover. This command either runs from the main SC and resets the spare or runs from the spare and resets the main. An SC cannot reset itself. If the SC chosen is not powered on, <code>resetsc</code> prompts the user to power it on. If the chosen SC does not power on, <code>resetsc</code> terminates and returns an error.
OPTIONS	The following options are supported: -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored. -n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option. -q Quiet. Suppresses all messages to <code>stdout</code> including prompts. When used alone -q defaults to the -n option for all prompts. When used with either the -y or the -n option, -q suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen. -y Automatically answers yes to all prompts. Prompts are displayed unless used with the -q option.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator privileges to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Resetting the Other SC Using Prompts <pre>sc0:sms-user:> resetsc About to reset other SC. Are you sure you want to continue? (y or [n])</pre>

EXAMPLE 2 Resetting the Other SC When the Other SC Is Powered Off

```
sc0:sms-user:> resetsc
The other SC is not powered on.
Do you want to try to power it on? (y or [n])
```

EXAMPLE 3 Resetting the Other SC Answering Yes to All Prompts

```
sc0:sms-user:> resetsc -y
About to reset other SC.
Are you sure you want to continue? [y]
```

EXAMPLE 4 Resetting the Other SC Suppressing All Prompts

```
sc0:sms-user:> resetsc -q
```

EXIT STATUS

The following exit values are returned:

- 0 Successful completion.
- 1 The user has invalid permission.
- 2 Memory allocation failed.
- 3 Cannot determine other SC's presence.
- 4 Other SC is not present.
- 5 Cannot determine power state of other SC.
- 6 Unable to power on other SC.
- 7 Unable to reset other SC.
- 8 Flag registration failed.
- 9 Invalid command-line argument.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

NAME	runcmdsync - prepare a specified script for recovery after a failover
SYNOPSIS	runcmdsync <i>script_name</i> [<i>parameters</i>] runcmdsync -h
DESCRIPTION	<p>The <code>runcmdsync(1M)</code> command prepares the specified script for automatic synchronization (recovery) after a failover. <code>runcmdsync</code> creates a command synchronization descriptor that identifies the script to be recovered. This descriptor is added to the command synchronization list that determines the scripts to be restarted after a failover. The <code>runcmdsync</code> command also removes this descriptor from the command synchronization list when the script terminates.</p> <p>To specify restart points in a script, see <code>initcmdsync(1M)</code> and the family of synchronization commands.</p>
OPTIONS	<p>The following options are supported:</p> <p>-h Help. Displays usage descriptions.</p> <p style="padding-left: 100px;">Note – Use alone. Any option specified in addition to -h is ignored.</p> <p><i>script_name</i> Identifies the script to be prepared for command synchronization. <i>script_name</i> must be the absolute path name of an executable command. The command must exist in the same location on both SCs.</p> <p><i>parameters</i> Specifies the options or parameters associated with the specified script. These parameters are stored on the spare system controller (SC) and are used to restart the specified command or script after an automatic failover.</p>
EXTENDED DESCRIPTION	
Group Privileges Required	<p>You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>
EXIT STATUS	<p>The following exit values are returned:</p> <p>0 Successful completion.</p> <p>>0 An error occurred.</p>

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

cancelcmdsync(1M), **initcmdsync**(1M), **savecmdsync**(1M), **showcmdsync**(1M)

NAME	savecmdsnc - command synchronization command
SYNOPSIS	<p>cancelcmdsnc <i>cmdsnc_descriptor</i></p> <p>initcmdsnc <i>script_name</i> [<i>parameters</i>]</p> <p>savecmdsnc <i>-M identifier cmdsnc_descriptor</i></p> <p>[cancel init save]cmdsnc -h</p>
DESCRIPTION	<p>The command synchronization commands work together to control the recovery of user-defined scripts interrupted by a system controller (SC) failover. Insert the following commands in user-defined scripts to enable command synchronization:</p> <p>initcmdsnc Creates a command synchronization descriptor that identifies the script to be recovered.</p> <p> This descriptor is placed on a command synchronization list that identifies the scripts and commands to be restarted on the new main SC after a failover.</p> <p>savecmdsnc Adds a marker that identifies a location in the script from which processing can be resumed after a failover.</p> <p>cancelcmdsnc Removes a command synchronization descriptor from the command synchronization list. This ensures that the script is run only once and not after subsequent failovers.</p> <p> Be sure that all exit paths of a script have a cancelcmdsnc sequence to remove the descriptor from the command synchronization list. If you do not remove the descriptor and a failover occurs, the script is rerun on the new main SC.</p> <p>Note – Both an initcmdsnc and a cancelcmdsnc sequence must be contained within a script to enable command synchronization. The use of the savecmdsnc command is optional, and marks only specific points in a script from which processing can be resumed. If specific restart points are not necessary, consider using runccmdsnc(1M) instead.</p>
OPTIONS	<p>The following options are supported:</p> <p>cmdsnc_descriptor Specifies the command synchronization descriptor that identifies the user-defined script. This descriptor is the standard output value returned by the initcmdsnc command.</p>

<code>-h</code>	Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.
<code>-M <i>identifier</i></code>	Marks a location in the script from which the script can be resumed after a failover. The identifier must be a positive integer.
<code><i>parameters</i></code>	Specifies the options or parameters associated with the user-defined script. These parameters are stored on the spare SC and are used to restart the specified script after a failover.
<code><i>script_name</i></code>	Identifies the name of the user-defined script to be synchronized. <code><i>script_name</i></code> must be the absolute path name of an executable command. The command must exist in the same location on both SCs.

**EXTENDED
DESCRIPTION**

The command synchronization commands are inserted at certain logical points within a user-defined script.

For instance, a Korn shell script might be structured as follows:

```
# MAIN CODE STARTS HERE
# Be sure to use a cleanup procedure to handle any
# interrupts.
# Use the cancelcmdsyc to remove the script from the
# command synchronization list. Otherwise, the command
# will get restarted on the new main SC.
#
clean_up () {
    cancelcmdsyc $desc
    exit
}

# Declare the clean_up function to capture system signals
# and cleanup.
trap "clean_up" INT HUP TERM QUIT PWR URG
goto_label=1
# Process the arguments, capturing the -M marker point
# if provided
#
for arg in $*; do
    case $arg in
        -M )
            goto_label=$arg;;
        .
        .
    esac
done
# Place this script and all its parameters in the command
# synchronization list, which indicates the commands to
# be restarted after an SC failover.
#
# NOTE: The script must be executable by the user defined
# in fowd.cf and reside in the same directory on both the
# main and the spare SC.
```

```

# If the command is not part of the defined PATH for
# the user, the absolute filename must be passed with the
# initcmdsnc command
#
initcmdsnc script_name parameters
# The marker point is stored in the goto_label variable.
# Keep executing this script until all cases have been
# processed or an error is detected.
#
while (( $goto_label != 0 )) ; do
#
# Each case should represent a synchronization point
# in the script.
#
case $goto_label in
#
# Step 1: Do something
#
1 )          do_something
              .
              .
              .

# Execute the savecmdsnc command with the script's
# descriptor and a unique marker to save the position.
# If a failover occurs here, the commands represented in
# the next goto_label (2) will be resumed.
#
          savecmdsnc -M $(( $goto_label + 1 )) $desc
          goto_label=$(( $goto_label + 1 ))
          ;;

#
# Step 2: Do more things
#
2 )          do_more_things
              .
              .
              .
          savecmdsnc -M $(( $goto_label + 1 )) $desc
          goto_label=$(( $goto_label + 1 ))
          ;;

#
# Step 3: Finish the last step and set the goto_label to 0
# so that the script ends.
3 )
          finish_last_step
          .
          .
          .
          goto_label=0
          ;;

        esac
done
# END OF MAIN CODE
# Remember to execute cancelcmdsnc to remove the script from the
# command synchronization list. Otherwise, the command will be restarted
# after the failover.
#
cancelcmdsnc $desc

```

Group Privileges Required

You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

Note – The standard output for `initcmdsync` contains the command synchronization descriptor. Also, when failover is disabled (after a failover or in a single SC environment), scripts that contain synchronization commands generate error messages to the platform log file and return nonzero exit codes. These messages can be ignored.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

runcmdsync(1M), **showcmdsync**(1M)



NAME	setbus - perform dynamic bus reconfiguration on active expanders in a domain								
SYNOPSIS	setbus [-q] [-y -n] -c <i>csb</i> [-b <i>buses</i>] [<i>location</i>]... setbus -h								
DESCRIPTION	<p>setbus(1M) dynamically reconfigures bus traffic on active expanders in a domain to use either one centerplane support board (CSB) or both. Using both CSBs is considered normal mode. Using one CSB is considered degraded mode.</p> <p>This feature enables you to swap out a CSB without having to power off the system.</p>								
OPTIONS	<p>The -y and -n are optional arguments to the setbus(1M) command. If one of these optional arguments is not provided, setbus prompts the user with a confirmation message.</p> <p>If changing the configuration on the chosen expander requires changing the configuration on additional expanders, setbus displays the following message:</p> <hr/> <p style="text-align: center;">The expander board in position <i>location</i> communicates with expanders not already listed, and will be added to the list of boards to reconfigure.</p> <hr/> <p>Additionally, setbus resets any boards that are powered on but not active. Any attach-ready state is lost. To bring the boards back to an attach-ready state refer to the <i>System Management Services (SMS) 1.3 Dynamic Reconfiguration User Guide</i>.</p> <p>Note – If you have degraded all expanders to one CSB you cannot un-degrade a single expander; you must set them all at the same time, otherwise setbus fails.</p> <p>The following options are supported</p> <table border="0" style="margin-left: 20px;"> <tr> <td style="padding-right: 20px;">-b <i>buses</i></td> <td>Specifies which <i>buses</i> to configure. There are three <i>buses</i> to configure. Valid <i>buses</i> are:</td> </tr> <tr> <td style="padding-left: 40px;">a</td> <td>Configures the address bus.</td> </tr> <tr> <td style="padding-left: 40px;">d</td> <td>Configures the data bus.</td> </tr> <tr> <td style="padding-left: 40px;">r</td> <td>Configures the response bus.</td> </tr> </table> <p style="margin-left: 20px;">The default is to configure all three buses.</p>	-b <i>buses</i>	Specifies which <i>buses</i> to configure. There are three <i>buses</i> to configure. Valid <i>buses</i> are:	a	Configures the address bus.	d	Configures the data bus.	r	Configures the response bus.
-b <i>buses</i>	Specifies which <i>buses</i> to configure. There are three <i>buses</i> to configure. Valid <i>buses</i> are:								
a	Configures the address bus.								
d	Configures the data bus.								
r	Configures the response bus.								

<code>-c <i>csb</i></code>	Specifies which CSB(s) to use.
	CS0 Configures the hardware to use CS0 (degraded mode).
	CS1 Configures the hardware to use CS1 (degraded mode).
	CS0 , CS1 Configures the hardware to use both CSBs (normal mode).
<code>-h</code>	Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.
<code>-n</code>	Automatically answers no to all prompts. Prompts are displayed unless used with the <code>-q</code> option.
<code>-q</code>	Quiet. Suppresses all messages to <code>stdout</code> including prompts. When used alone <code>-q</code> defaults to the <code>-n</code> option for all prompts. When used with either the <code>-y</code> or the <code>-n</code> option, <code>-q</code> suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen.
<code>-y</code>	Automatically answers yes to all prompts. Prompts are displayed unless used with the <code>-q</code> option.

OPERANDS

The following operands are supported:

<i>location</i>	Specifies which expander slots to configure. The default is to configure all. Multiple <i>locations</i> are separated by spaces. Valid <i>locations</i> are: Sun Fire 15K, Sun Fire 12K EX(0...17), EX(0...8)
-----------------	--

EXTENDED DESCRIPTION**Group Privileges Required**

You must have platform administrator privileges to reconfigure any set of communicating expanders (SOCX) in the system.

Domain administrators or configurators can reconfigure only the SOCX assigned to the domain(s) in which they have privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Setting All Buses on All Active Domains to Use CS0

The following example displays setbus output when there are inactive boards powered on in one or more of the domains.

```
sc0:sms-user:> setbus -c CS0
The following boards are powered on but are not active in a domain:
SB13
IO9 assigned to domain J
IO16 assigned to domain Q
SB17
These boards will be reset, and any attach-ready state will be lost.
Are you sure you want to continue the reconfiguration? [y|n]:y
```

EXAMPLE 2 Setting All Buses on All Active Domains to Use Both CSBs

```
sc0:sms-user:> setbus -c CS0,CS1
```

EXAMPLE 3 Setting Address Bus on All Domains to Use CS0

```
sc0:sms-user:> setbus -c CS0 -b a
```

EXAMPLE 4 Setting Address and Data Buses on Active EX1 to Use CS1

```
sc0:sms-user:> setbus -c CS1 -b ad EX1
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

showbus(1M)

NAME	setdatasync - modify the data propagation list used in data synchronization
SYNOPSIS	setdatasync [-i interval] schedule <i>filename</i> setdatasync cancel <i>filename</i> setdatasync push <i>filename</i> setdatasync backup setdatasync -h
DESCRIPTION	<p>setdatasync enables you to specify a user-created file to be added to or removed from the data propagation list. This list identifies the files to be copied from the main to the spare system controller (SC) as part of data synchronization for automatic failover. The specified user file and the directory in which it resides must have read and write permissions for the user on both SCs.</p> <p>The data synchronization process checks the user-created files on the main SC for any changes. If the user-created files on the main SC have changed since the last propagation, they are repropagated to the spare SC. By default, the data synchronization process checks a specified file every 60 minutes; however, you can use setdatasync to indicate how often a user file should be checked for modifications.</p> <p>Note – After a file is propagated from the main SC to the spare, the file is repropagated to the spare only when the file on the main SC is updated. If you remove a propagated file from the spare SC, that file is not automatically repropagated until the corresponding file on the main SC has been changed.</p> <p>You can also use setdatasync to do the following:</p> <ul style="list-style-type: none">■ Propagate a specified file to the spare SC without adding the file to the data propagation list.■ Resynchronize the SC configuration files on the main and spare SCs.

OPTIONS

The following options are supported:

backup	<p>Forces re-synchronization after something other than SMS creates undesired changes to SMS files on the spare SC.</p> <p><code>setdatasync backup</code> re-propagates every SMS configuration, data and log file. <code>fomd</code> does this automatically. Using <code>setdatasync backup</code> can slow down automatic <code>fomd</code> file propagation.</p> <p>The time required to execute <code>setdatasync backup</code> is approximately proportional to the number of files being transferred. Other factors that can affect the speed of file transfer include: the average size of files being transferred, the amount of memory available on the SCs, the load (CPU cycles and disk traffic) on the SCs, and whether the I2 network is functioning. For more information refer to Chapter 9, “SC Failover,” of the <i>System Management Services (SMS) 1.3 Administrator Guide</i>.</p> <p>Use <code>setdatasync backup</code> only in the following situations.</p> <ul style="list-style-type: none"> ■ SMS was re-installed on the spare SC while SMS was running on the main SC. <p>Note – SMS users groups must be setup correctly on the spare before running <code>setdatasync backup</code></p> <ul style="list-style-type: none"> ■ SMS files were deleted from the spare SC while SMS was running on the main SC. ■ SMS files were overwritten or corrupted on the spare SC (regardless of whether SMS was running or not).
cancel <i>filename</i>	<p>Removes (cancels) the specified file from the data propagation list, which means the specified file will no longer be propagated to the spare SC. This option does not actually remove the specified file from the spare SC. The file name must contain the absolute path and cannot be a symbolic link to another file.</p>
-h	<p>Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.</p>
-i <i>interval</i>	<p>Indicates how often the specified file should be checked for modifications. The default interval is 60 minutes. The interval can range from 1 to 1440 minutes (24 hours).</p>

`push filename` Propagates (pushes) the specified file to the spare SC without adding it to the data propagation list. The file name must contain the absolute path and cannot be a symbolic link to another file.

`schedule filename` Adds the specified file to the data propagation list. The file name must contain the absolute path and cannot be a symbolic link to another file. During data synchronization, the file is propagated to the same absolute path on the spare SC.

EXTENDED DESCRIPTION

Group Privileges Required

You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Propagating a User File From Main to Spare Every 30 Minutes

The path to the user-specified file must be an absolute path and cannot contain a symbolic link.

```
sc0:sms-user:> setdatasync -i 30 schedule /path/filename
```

EXAMPLE 2 Removing File Name From Data Propagation List

The path to the user-specified file must be an absolute path and cannot contain a symbolic link.

```
sc0:sms-user:> setdatasync cancel /path/filename
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.

>0 An error occurred.

ATTRIBUTES

See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO | **showdatasync**(1M), **smsbackup**(1M)

NAME	setdate - set the date and time for the system controller (SC) or a domain
SYNOPSIS	setdate [-d <i>domain_indicator</i>] [-u] [-q] [<i>mmdd</i>] <i>HHMM</i> / <i>mmddHHMM</i> [<i>cc</i>] <i>yy</i> [<i>.SS</i>] setdate -h
DESCRIPTION	<i>setdate</i> (1M) enables the SC platform administrator to set the SC or optionally set a domain date and time values. Enables domain administrators to set the date and time values for their domains. After the date and time are set <i>setdate</i> (1M) displays the current date and time.
OPTIONS	The following options are supported: -d <i>domain_indicator</i> Specifies the domain using one of the following: <i>domain_id</i> -ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using <i>addtag</i> (1M). Sets the domain time of day (TOD) when the domain keyswitch is in the OFF or STANDBY position. This option is not the primary use of <i>setdate</i> . Normally, <i>setdate</i> is used without this option to set the SC TOD. -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored. -q Does not display current date and time after you set the new value. -u Interprets and displays the time using Greenwich Mean Time (GMT). The default is the local time zone.
OPERANDS	The following operands are supported: <i>[mmdd]HHMM[.SS]</i> Date and time format. <i>mm</i> is the month (1-12), <i>dd</i> is the day of the month (1-31), <i>HH</i> is the hour (0-23), <i>MM</i> is the minute (0-59), and <i>SS</i> is the second (0-59). <i>mmddHHMM[cc]yy[.SS]</i> Date and time format. <i>mm</i> is the month (1-12), <i>dd</i> is the day of the month (1-31), <i>HH</i> is the hour (0-23), <i>MM</i> is the minute (0-59), <i>cc</i> is century minus one, <i>yy</i> is the two-digit year, and <i>SS</i> is the second (0-59).

**EXTENDED
DESCRIPTION****Group Privileges
Required**

You must have platform or domain administrator privileges to run this command. If you have domain administrator privileges you can run this command only for your domain.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Setting the Local Date in Pacific Standard Time

```
sc0:sms-user:> setdate 020210302002.00
System Controller: Sat Feb 2 10:30:00 PST 2002
```

EXAMPLE 2 Setting the Date Using GMT

```
sc0:sms-user:> setdate -u 020218302002.00
System Controller: Sat Feb 2 18:30:00 GMT 2002
```

EXAMPLE 3 Setting the Local Time in Pacific Standard Time for Domain A

```
sc0:sms-user:> setdate -d a 020210302002.00
Domain a: Sat Feb 2 10:30:00 PST 2002
```

EXAMPLE 4 Setting the Date for Domain A Using GMT

```
sc0:sms-user:> setdate -d a -u 020218302002.00
Domain a: Sat Feb 2 18:30:00 GMT 2002
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **setkeyswitch**(1M), **showdate**(1M)

NAME	setdefaults - remove all instances of a previously active domain and reset Capacity on Demand (COD) information
SYNOPSIS	setdefaults [-d <i>domain_indicator</i> [-p]] [-y -n] setdefaults -h
DESCRIPTION	<p>setdefaults(1M) removes all SMS instances of a previously active domain and Capacity on Demand (COD) information. A domain instance includes all <code>pcd</code> entries <i>except</i> network information; all message, console, and syslog log files; and, optionally, all NVRAM and boot parameters. <code>pcd</code> entries and NVRAM and boot parameters are returned to system default settings. IDPROM data is not affected.</p> <p>The COD information that is removed includes instant access CPUs (headroom) and reserved domain COD right-to-use (RTU) licenses. Only the platform administrator can reset the headroom value. The platform or domain administrator can reset reserved domain COD RTU licenses.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> -ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using <code>addtag(1M)</code>.</p> <p>-h Help. Displays usage descriptions.</p> <p style="padding-left: 40px;">Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-n Automatically answers no to all prompts.</p> <p>-p Preserves NVRAM and boot parameter data. By default, you are asked whether or not you want to remove the NVRAM and boot parameter data. If the -p option is used, you are not prompted and the data is preserved.</p> <p>-y Automatically answers yes to all prompts.</p>
EXTENDED DESCRIPTION	<p>If the -d <i>domain_indicator</i> is specified, the <code>setdefaults</code> command resets domain information. The domain cannot be active, and the virtual keyswitch must be set to off. Otherwise, the <code>setdefaults</code> command exits with an error. Platform administrators can reset the access control list (ACL) and the domain COD RTU licenses, but the domain administrator cannot.</p>

If you have platform administrator privileges and you do not specify the `-d domain_indicator`, the `setdefaults` command resets the COD headroom, provided that the reset does not cause any COD RTU license violations.

Group Privileges Required

You must have platform administrator or domain administrator privileges for the specified domain to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Setting Defaults on Domain A With Domain, NVRAM, and Boot Parameter Prompts

```
sc0:sms-user:> setdefaults -d a
Are you sure you want to remove domain info? y
Do you want to remove NVRAM and boot parameter data? y
```

EXAMPLE 2 Setting Defaults on Domain A Without Prompts, Saving NVRAM and Boot Parameter Data

```
sc0:sms-user:> setdefaults -d a -p -y
```

EXAMPLE 3 Setting Defaults on Domain A Without Prompts and Without Saving NVRAM and Boot Parameter Data

```
sc0:sms-user:> setdefaults -d a -y
```

EXIT STATUS

The following exit values are returned:

- | | |
|----|---|
| 0 | Successful completion. |
| 1 | An invalid domain was specified. |
| 2 | An invalid option was entered. |
| 3 | No domain, or more than one domain, was specified. |
| 4 | The user has invalid permission. |
| 5 | The keyswitch is in an invalid position. |
| 6 | The domain is currently active. |
| 7 | An error occurred talking to the <code>pcd</code> . |
| 8 | An error occurred talking to the <code>mld</code> . |
| 9 | An error occurred talking to the <code>osd</code> . |
| 10 | An internal error occurred. |
| 11 | The user canceled the operation. |

12 An error occurred talking to the codd.

FILES

The following files are affected by this command:

<code>/var/opt/SUNWSMS/.pcd/domain_info</code>	Domain pcd information file.
<code>/var/opt/SUNWSMS/.pcd/sysboard_info</code>	Platform pcd information file.
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/console</code>	Domain console log file. Up to ten message files are stored on the system at any one time— <code>console.0</code> through <code>console.9</code> .
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/messages</code>	Domain log file. Up to ten message files are stored on the system at any one time— <code>message.0</code> through <code>message.9</code> .
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/syslog</code>	Domain syslog file. Up to ten message files are stored on the system at any one time— <code>syslog.0</code> through <code>syslog.9</code> .
<code>/var/opt/SUNWSMS/data/<i>domain_id</i>/bootparamdata</code>	Domain boot parameter information file.
<code>/var/opt/SUNWSMS/data/<i>domain_id</i>/nvramdata</code>	Domain nvram information file.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes:

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **mld**(1M), **osd**(1M), **pcd**(1M), **setobpparams**(1M), **showobpparams**(1M)

NAME	setfailover - modify the state of the system controller (SC) failover mechanism
SYNOPSIS	setfailover <i>action</i> setfailover -h
DESCRIPTION	setfailover(1M) provides the ability to modify the state of failover for the SC failover mechanisms.
OPTIONS	The following options are supported: -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored.
OPERANDS	The following operands are supported: <i>action</i> The following are valid actions: <i>force</i> Forces a failover to the spare SC. The spare SC must be available. <i>off</i> Disables the failover mechanism. This prevents a failover until the mechanism is reenabled. <i>on</i> Enables failover for systems that previously had failover disabled due to a failover or an operator request. <i>on</i> instructs the command to attempt to reenale failover only. If failover cannot be reenabled, subsequent use of the <i>showfailover</i> command indicates the current failure that prevented the enable.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator privileges to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	These commands produce no output when successful. An error message appears if the action can not be performed. EXAMPLE 1 Turning Failover On sc0:sms-user:> setfailover on

EXAMPLE 2 Turning Failover Off

```
sc0: sms-user: > setfailover off
```

EXAMPLE 3 Forcing a Failover

```
sc0: sms-user: > setfailover force
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.

>0 An error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

showfailover(1M)

NAME	setkeyswitch - change the position of the virtual keyswitch
SYNOPSIS	<p>setkeyswitch -d <i>domain_indicator</i> [-q] [-y -n] <i>position</i></p> <p>setkeyswitch -h</p>
DESCRIPTION	<p>setkeyswitch(1M) changes the position of the virtual keyswitch to the specified value. setkeyswitch is responsible for powering on or powering off boards and bringing up a domain. See the OPERANDS section for more information.</p> <p>If the domain specified contains a board in the automatic system recovery (ASR) blacklist file, an error message is displayed, setkeyswitch skips power on of that board and setkeyswitch continues.</p> <p>The state of each virtual keyswitch is maintained between power cycles of the system controller (SC) or physical power cycling of the power supplies by the pcd(1M). Use showkeyswitch to display the current position of a virtual keyswitch.</p>
OPTIONS	<p>The following options are supported.</p> <p>Note – The -y and -n are optional arguments to the setkeyswitch(1M) command. If one of these optional arguments is not provided, setkeyswitch prompts you for confirmation when changing from the on, diag, or secure position to the off or standby position.</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> – ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> -- Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-n Automatically answers no to all prompts. Prompts are displayed unless used with the -q option.</p> <p>-q Quiet. Suppresses all messages to stdout including prompts.</p> <p style="padding-left: 40px;">When used alone -q defaults to the -n option for all prompts.</p> <p style="padding-left: 40px;">When used with either the -y or the -n option, -q suppresses all user prompts and automatically answers with either 'y' or 'n' based on the option chosen.</p>

`-y` Automatically answers yes to all prompts. Prompts are displayed unless used with the `-q` option.

OPERANDS

The following operands are supported:

position

Valid *position* operands are:

`on` From the `off` or `standby` position, `on` powers on all boards assigned to the domain (if not already powered on). Then the domain is brought up. From the `diag` position, `on` is nothing more than a position change and does not affect a running domain. From the `secure` position, `on` restores write permission to the domain.

`standby` From the `on`, `diag`, or `secure` position, `standby` optionally displays a confirmation prompt. If you answer 'yes' then it determines if the domain is in a suitable state to be reset and deconfigured (for example, the OS is not running). If the domain is in a suitable state to be reset and deconfigured, then `setkeyswitch` resets and deconfigures all boards assigned to the domain. If not, then prior to the reset and deconfiguration, `setkeyswitch` gracefully shuts down the domain. From the `off` position, `standby` powers on all boards assigned to the domain (if not already powered on).

`off` From the `on`, `diag`, or `secure` position, `off` optionally displays a confirmation prompt. If you answer 'yes' then it determines if the domain is in a suitable state to be powered off (for example, the OS is not running). If the domain is in a suitable state to be powered off, then `setkeyswitch` powers off all boards assigned to the domain. If not, then `setkeyswitch` aborts and logs a message to the domain log. From the `standby` position, `off` powers off all the boards in the domain.

`diag`

From the `off` or `standby` position, `diag` powers on all boards assigned to the domain (if not already powered on). Then the domain is brought up just as in the `on` position, except that `POST` is invoked with verbosity and diagnostic levels set to, at least, their defaults. From the `on` position, `diag` results in nothing more than a position change, but upon automatic system recovery (ASR) of the domain, `POST` is invoked with verbosity and diagnostic levels set to, at least, their defaults. From the `secure` position, `diag` restores write permission to the domain and upon ASR, `post` is invoked with verbosity and diagnostic levels set to, at least, their defaults. For more information on ASR, refer to Chapter 6, "Domain Control," in the *System Management Services (SMS) 1.3 Administrator Guide*.

`secure`

From the `off` or `standby` position, `secure` powers on all boards assigned to the domain (if not already powered on). Then the domain is brought up just as in the `on` position, except that the `secure` position removes write permission to the domain; for example, `flashupdates` and `resets` will not work. From the `on` position, `secure` removes write permission to the domain (as previously described). From the `diag` position, `secure` removes write permission to the domain (as previously described).

EXTENDED DESCRIPTION

Group Privileges Required

You must have domain administrator privileges for the specified domain to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Setting Keyswitch on Domain A On

```
sc0:sms-user:> setkeyswitch -d A on
```

EXAMPLE 2 Using Keyswitch on a Domain Containing a Board in the ASR Blacklist File

```
sc0:sms-user:> setkeyswitch -d A on
SB0 is in the ASR Blacklist.
```

EXIT STATUS

The following exit values are returned:

```
0           Successful completion.
>0         An error occurred.
```

FILES

The following file is used by this command:

```
/etc/opt/SUNWSMS/config/asr/blacklist      List of components
                                           excluded by esmd.
```

Note – This file is created and used internally and should *not* be edited manually.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **esmd**(1M), **flashupdate**(1M), **pcd**(1M), **reset**(1M),
showkeyswitch(1M)

NAME	setobpparams - set up OpenBoot PROM variables for a domain
SYNOPSIS	setobpparams -d <i>domain_indicator</i> <i>param=value...</i> setobpparams -h
DESCRIPTION	<p>setobpparams(1M) enables a domain administrator to set the virtual NVRAM and REBOOT variables passed to OpenBoot PROM by setkeyswitch(1M). The -d option with <i>domain_id</i> or a <i>domain_tag</i> is required. You must reboot the domain in order for any changes to take effect.</p> <p>This command is intended for error recovery and not for routine system administration. For more information refer to Chapter 4, "SMS Configuration," in the <i>System Management Services (SMS) 1.3 Administrator Guide</i>.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions.</p> <p>Note - Use alone. Any option specified in addition to -h is ignored.</p>

OPERANDS

The following operands are supported:

- param=value* NVRAM and REBOOT variable values for OpenBoot PROM. Valid variables are:
- *diag-switch?*
 Default value= false
 When set to false, the default boot device is specified by *boot-device* and the default boot file by *boot-file*.
 When set to true, OpenBoot PROM runs in diagnostic mode and you need to set either *diag-device* or *diag-file* to specify the correct default boot device or file. These default boot device and file settings cannot be set using *setobpparams*. Use *setenv(1)* in OpenBoot PROM.
 - *auto-boot?*
 Default value= false
 When set to true, the domain boots automatically after power-on or *reset-all*. The boot device and boot file used are based on the settings for *diag-switch* (see above). Neither *boot-device* nor *boot file* can be set using *setobpparams*. In the event the OK prompt is unavailable, such as a repeated panic, use *setobpparams* to set *auto-boot?* to false.
 When the *auto-boot?* variable is set to false using *setobpparams*, the reboot variables are invalidated, the system will not boot automatically and will stop in OpenBoot PROM where new NVRAM variables can be set.
 - *fcode-debug?*
 Default value= false
 When set to true, this variable includes name fields for plug-in device FCodes.
 - *use-nvramrc?*
 Default value= false
 When set to true, this variable executes commands in NVRAMRC during system start-up.
 When set to true, this variable executes commands in NVRAMRC during system start-up.
 - *security-mode*
 Default value= none
 Firmware security level.

Valid variable values for all but security mode are:

- true
- false

Valid variable values for security mode are:

- none
- command
- full

where:

none - Means that no password is required (default)

command - Means that all commands except `boot(1M)` and `go` require the password.

full - Means that all commands except for `go` require the password.

Note – It is important to remember your security password and to set the security password before setting the security mode. If you forget this password, you cannot use your system; you must call your vendor's customer support service to make your system bootable again. For more information on `security-mode` and other OpenBoot PROM variables, see the *OpenBoot 4.x Command Reference Manual*.

Note – Most, but not all, shells require single quotes around the variable values to prevent the question mark from being treated as a special character. See Example 1.

EXTENDED DESCRIPTION

Group Privileges Required

Domain administrator or configurator privileges for the specified domain are required.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Setting OpenBoot PROM Variable `diag-switch` to On for Domain A

```
sc0:sms-user:> setobpparams -d a 'diag-switch?=true'
```

EXAMPLE 2 Setting OpenBoot PROM Variable `security-mode` to Full for Domain A

```
sc0:sms-user:> setobpparams -d a security-mode=full
```

EXIT STATUS The following exit values are returned:

0 Successful completion.

>0 An error occurred.

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **addtag**(1M), **setkeyswitch**(1M), **showobpparams**(1M)

NAME	setupplatform - set up the available component list and Capacity on Demand (COD) resources used for domains
SYNOPSIS	<pre>setupplatform -p available [-d <i>domain_indicator</i> [-a -r] <i>location...</i>] setupplatform -p cod [<i>headroom</i> -d <i>domain_indicator</i> <i>domainRTU</i>] setupplatform [-d <i>domain_indicator</i> -] setupplatform -h</pre>
DESCRIPTION	<p>setupplatform(1M) sets up the available component list and COD resources to be used for domains. If a <i>domain_id</i> or <i>domain_tag</i> is specified, a list of boards <i>must</i> be specified. An empty board list can be specified as a dash (-). When no <i>domain_id</i> or <i>domain_tag</i> is specified, current values are displayed in the square brackets ([]) at the command prompt. If no value is specified for a parameter, it retains its current value.</p>
OPTIONS	<p>The following options are supported:</p> <ul style="list-style-type: none"> -a Adds the slot(s) to the available component list for the domain. -d <i>domain_indicator</i> Specifies the domain using one of the following: <ul style="list-style-type: none"> <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M). -h Help. Displays usage descriptions. <p>Note - Use alone. Any option specified in addition to -h is ignored.</p> -p <i>available</i> Modifies the domain available component list. -p <i>cod</i> Assigns COD resources. -r Removes the slots from the available component list for the domain. - Clears the entire available component list.
OPERANDS	<p>The following operands are supported:</p> <ul style="list-style-type: none"> <i>domainRTU</i> Number of COD right-to-use (RTU) licenses to be reserved for a domain. <i>headroom</i> Amount of headroom (processors) to be enabled.

location Board location separated by a space.

The following *location* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

EXTENDED DESCRIPTION

If you run the `setupplatform` command without specifying any options, the command prompts you for platform and COD information. You are asked to specify the available component list for all 18 domains, the amount of COD headroom to be used, and the number of COD RTU licenses to be reserved for your domains. When you are prompted for COD information, the maximum values allowed are displayed within parentheses () and default values are displayed within brackets [].

Use the `-p cod` option with the `setupplatform` command to enable COD headroom (processors to be used on demand). Use the `-d domain_indicator` with the `-p cod` option to specify the number of domain COD RTU licenses to be reserved.

You can reset the domain available component list and COD RTU reservation values by running the `setupplatform` command with a domain indicator and the `'-'` option.

Group Privileges Required

You must have platform administrator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

Use `showplatform(1M)` to display the available component list once you have run `setupplatform`.

EXAMPLE 1 Setting Up Available Component List for All Domains

```

sc0:sms-user:> setupplatform
Available component list for domain domainA [SB3 SB2 SB1 IO5 IO4 IO3]? -r SB1
Are you sure[no]: (yes/no)? Y
Available for domain DomainB [SB6 SB4 SB1 IO3 IO2 ]? -
Are you sure[no]: (yes/no)? Y
Available for domain C [SB7 SB5 IO8 IO7]? -a SB17 SB16
Available for domain D [SB9 SB8 SB4 SB2 IO6 IO5 IO1]?
Available for domain E [SB0 IO0]?
Available for domain F []?
Available for domain G []?
Available for domain H []?
Available for domain I []?
Available for domain J []?
Available for domain K []?
Available for domain L []?
Available for domain M []?
Available for domain N []?
Available for domain O []?
Available for domain P []?
Available for domain Q []?
Available for domain R []?
PROC Headroom Quantiy (0 to disable, 8 MAX) [0]? 4
PROC RTUs reserved for domain A (10 MAX) [0]? 3
PROC RTUs reserved for domain B (7 MAX) [0]? 0
PROC RTUs reserved for domain C (7 MAX) [0]? 0
PROC RTUs reserved for domain D (7 MAX) [0]? 0
PROC RTUs reserved for domain E (7 MAX) [0]? 0
PROC RTUs reserved for domain F (7 MAX) [0]? 0
PROC RTUs reserved for domain G (7 MAX) [0]? 0
PROC RTUs reserved for domain H (7 MAX) [0]? 0
PROC RTUs reserved for domain I (7 MAX) [0]? 0
PROC RTUs reserved for domain J (7 MAX) [0]? 0
PROC RTUs reserved for domain K (7 MAX) [0]? 0
PROC RTUs reserved for domain L (7 MAX) [0]? 0
PROC RTUs reserved for domain M (7 MAX) [0]? 0
PROC RTUs reserved for domain N (7 MAX) [0]? 0
PROC RTUs reserved for domain O (7 MAX) [0]? 0
PROC RTUs reserved for domain P (7 MAX) [0]? 0
PROC RTUs reserved for domain Q (7 MAX) [0]? 0
PROC RTUs reserved for domain R (10 MAX) [3]? 3

```

```
sc0:sms-user:> showplatform -p available
Available for domain DomainA:
  SB3 SB2
  IO0 IO4 IO3
Available for domain DomainB:
  None
  None
Available for domain DomainC:
  SB1 SB6 SB7 SB5
  IO8 IO7
Available for domain D:
  SB9 SB8 SB4
  IO6 IO5 IO1
Available for domain E:
  SB0
  IO0
Available for domain DomainF:
  None
  None
Available for domain DomainG:
  None
  None
Available for domain DomainH:
  None
  None
Available for domain I:
  None
  None
Available for domain J:
  None
  None
Available for domain DomainK:
  None
  None
Available for domain L:
  None
  None
Available for domain M:
  None
  None
Available for domain N:
  None
  None
Available for domain O:
  None
  None
Available for domain P:
  None
  None
Available for domain Q:
  None
  None
Available for domain R:
  None
  None
```

EXAMPLE 2 Setting Up Available Component List for Domain engB to Boards at SB0,

IO1, and IO2

```
sc0:sms-user:> setupplatform -p available -d engB SB0 IO1 IO2
```

EXAMPLE 3 Clearing All Boards in engB Available Component List and Reserved COD RTUs

```
sc0:sms-user:> setupplatform -d engB -
```

EXAMPLE 4 Adding Boards at SB0 and IO2 to engB Available Component List

```
sc0:sms-user:> setupplatform -p available engB -a SB0 IO2
```

EXAMPLE 5 Removing Boards at SB3 and IO3 From engB Available Component List

```
sc0:sms-user:> setupplatform -p available -d engB -r SB3 IO3
```

EXAMPLE 6 Setting COD CPU Headroom Quantity and Reserve Domain COD RTU Licenses

```
sc0:sms-user:> setupplatform -p cod
PROC Headroom Quantity (0 to disable, 8 MAX) [0]? 4
PROC RTUs reserved for domain A (10 MAX) [0]? 3
PROC RTUs reserved for domain B (7 MAX) [0]? 0
PROC RTUs reserved for domain C (9 MAX) [2]? 0
.
.
.
PROC RTUs reserved for domain R (7 MAX) [0]? 0
```

EXAMPLE 7 Set the COD Headroom CPUs to 8

```
sc0:sms-user:> setupplatform -p cod 8
```

EXAMPLE 8 Set the number of COD RTUs for Domain engB to 6

```
sc0:sms-user:> setupplatform -p cod -d engB 6
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An internal error occurred. For further information, see <code>/var/opt/SUNWSMS/adm/platform/messages</code> .

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **showplatform**(1M)

NAME	showboards - show the assignment information and status of the boards
SYNOPSIS	showboards [-d <i>domain_indicator</i>] [-v] showboards -h
DESCRIPTION	<p>showboards(1M) displays board assignments and board status. If <i>domain_id</i> or <i>domain_tag</i> is specified, this command displays which boards are assigned or available to the given domain. The information displayed also indicates whether a board is a Capacity on Demand (COD) board.</p> <p>If the -v option is used, showboards displays all components, including <i>domain configuration units</i> (DCUs) such as CPUs, MCPUs, HPCI, HPCI+s, and WPCI; as well as the system controller (SC), that are not DCUs.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions.</p> <p style="padding-left: 40px;">Note - Use alone. Any option specified in addition to -h is ignored.</p> <p>-v Verbose. Displays all components including DCUs.</p>
EXTENDED DESCRIPTION	
Group Privileges Required	<p>You must have platform administrator, platform operator, platform service privileges or domain administrator, or domain configurator privileges for the specified domain to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p> <p>Platform administrator privileges:</p> <ul style="list-style-type: none"> ■ If no options are specified, showboards displays all components including those DCUs that are assigned or available. ■ If <i>domain_id</i> or <i>domain_tag</i> is specified, showboards displays information on DCUs that are assigned and available to that domain. DCUs assigned to other domains are not displayed.

- If the `-v` option is provided, `showboards` displays information on all assigned or available DCUs. In addition, `showboards` displays information on all other components.
- If `domain_id` or `domain_tag` and the `-v` option are specified, `showboards` displays information on DCUs that are assigned or available to that domain. In addition, `showboards` displays information on all other components. DCUs assigned to other domains are not displayed.

Domain administrator/configurator privileges:

- If no options are specified, `showboards` displays all boards for all domains for which you have privileges, including those DCUs that are assigned or available.
- If `domain_id` or `domain_tag` is specified, `showboards` displays information on DCUs that are assigned or available to that domain. DCUs assigned to other domains are not displayed. Available DCUs are those boards that are in the domain's available component list. See `setupplatform(1M)` and `showplatform(1M)`. You must have domain administrator or configurator privileges for the specified domain.
- The `-v` option is not available to this user.

Status Fields Displayed

This section describes status information displayed in the `showboards` command output.

The Pwr field contains one of five measurements:

On	Full voltage detected.
Off	No voltage detected.
Min	Some voltage detected.
Unk	Unknown. Unable to determine board power on state.
—	The slot is empty so power state is not applicable.

Min does not imply that the board can be used at this point but only that some power was detected on the board. It should not be used until it has been powered on. Conversely, it should not be removed from the system before being powered off.

The Board Status field contains one of four values:

Active	The board is assigned to a domain and has passed POST.
Assigned	The board is assigned to a domain.
Available	The board is available to be assigned to a domain.
—	Domain assignment or activity is not applicable for this board.

The Test status field reflects the recorded entry in the PCD database from the last POST run. The Test Status field contains one of six values:

Passed	The board passed POST.
Degraded	The board is in a degraded mode.
Failed	The board failed POST. Contact your Sun Service representative, who can determine whether or not the board needs to be replaced.
iPOST	The board is in POST.
Unknown	The board has not been tested.
—	The test status for this board is unavailable.

The Domain field contains one of four values:

<i>domain_id</i>	ID for a domain.
<i>domain_tag</i>	Name assigned to a domain using <code>addtag(1M)</code> .
Isolated	The board is not assigned to any domain.
—	Domain assignment is not applicable for this board.

EXAMPLES

EXAMPLE 1 Listing boards for Platform Administrators on a Sun Fire 15K System

```
sc0: sms-user: > showboards
```

Location	Pwr	Type	Board Status	Test Status	Domain
----	---	----	-----	-----	-----
SB0	On	CPU	Active	Passed	domainC
SB1	On	CPU	Active	Passed	A
SB2	On	CPU	Active	Passed	A
SB3	On	CPU	Active	Passed	engB
SB4	On	CPU	Active	Passed	engB
SB5	On	CPU	Active	Passed	engB
SB6	On	CPU	Active	Passed	A
SB7	On	CPU	Active	Passed	domainC
SB8	Off	CPU	Available	Unknown	Isolated
SB9	On	CPU	Active	Passed	dmnJ
SB10	Off	CPU	Available	Unknown	Isolated
SB11	Off	CPU	Available	Unknown	Isolated
SB12	Off	CPU	Assigned	Unknown	engB
SB13	-	Empty Slot	Available	-	Isolated
SB14	Off	CPU	Assigned	Failed	domainC
SB15	On	CPU	Active	Passed	P
SB16	On	CPU	Active	Passed	domainC
SB17	-	Empty Slot	Assigned	-	dmnR
IO0	-	Empty Slot	Available	-	Isolated
IO1	On	HPCI	Active	Passed	A
IO2	On	MCPU	Active	Passed	engB
IO3	On	MCPU	Active	Passed	domainC
IO4	On	HPCI+	Available	Degraded	domainC
IO5	Off	HPCI+	Assigned	Unknown	engB
IO6	On	HPCI	Active	Passed	A
IO7	On	HPCI	Active	Passed	dmnJ
IO8	On	WPCI	Active	Passed	Q
IO9	On	HPCI+	Assigned	iPOST	dmnJ
IO10	Off	HPCI	Assigned	Unknown	engB
IO11	Off	HPCI	Assigned	Failed	engB
IO12	Off	HPCI	Assigned	Unknown	engB
IO13	-	Empty Slot	Available	-	Isolated
IO14	Off	HPCI+	Available	Unknown	Isolated
IO15	On	HPCI	Active	Passed	P
IO16	On	HPCI	Assigned	Unknown	Q
IO17	-	Empty Slot	Assigned	-	dmnR

The following example illustrates `showboards` output if you have platform administrator privileges and specify a domain on a Sun Fire 15K system. The output does not include boards that are assigned to other domains.

EXAMPLE 2 Listing boards for Platform Administrators for Domain B

```
sc0:sms-user:> showboards -d b
```

Location	Pwr	Type	Board Status	Test Status	Domain
SB3	On	CPU	Active	Passed	engB
SB4	On	CPU	Active	Passed	engB
SB5	On	CPU	Active	Passed	engB
SB8	Off	CPU	Available	Unknown	Isolated
SB10	Off	CPU	Available	Unknown	Isolated
SB11	Off	CPU	Available	Unknown	Isolated
SB12	Off	CPU	Assigned	Unknown	engB
SB13	-	Empty Slot	Available	-	Isolated
IO0	-	Empty Slot	Available	-	Isolated
IO2	On	MCPU	Active	Passed	engB
IO5	Off	HPCI+	Assigned	Unknown	engB
IO10	Off	HPCI	Assigned	Unknown	engB
IO11	Off	HPCI	Assigned	Failed	engB
IO12	On	HPCI	Assigned	Unknown	engB
IO13	-	Empty Slot	Available	-	Isolated
IO14	Off	HPCI+	Available	Unknown	Isolated

The following example illustrates `showboards` output if you have platform administrator privileges and use the `-v` option on a Sun Fire 15K system. The command shows all components. If a board is a COD board, it is specified in the Type of Board field.

EXAMPLE 3 Listing boards for Platform Administrators Using the `-v` Option

```
sc0:sms-user:> showboards -v
```

Location	Pwr	Type of Board	Board Status	Test Status	Domain
SC0	On	SC	Main	-	-
SC1	On	SC	Spare	-	-
PS0	On	PS	-	-	-
PS1	On	PS	-	-	-
PS2	On	PS	-	-	-
PS3	On	PS	-	-	-
PS4	Off	PS	-	-	-
PS5	On	PS	-	-	-
FT0	On	FANTRAY	-	-	-
FT1	On	FANTRAY	-	-	-
FT2	On	FANTRAY	-	-	-
FT3	On	FANTRAY	-	-	-
FT4	On	FANTRAY	-	-	-
FT5	On	FANTRAY	-	-	-
FT6	On	FANTRAY	-	-	-
FT7	On	FANTRAY	-	-	-
CS0	On	CSB	-	-	-
CS1	On	CSB	-	-	-
EX0	-	EXB	-	-	-
EX1	-	EXB	-	-	-
EX2	-	EXB	-	-	-

EX3	-	EXB	-	-	-
EX4	On	EXB	-	-	-
EX5	-	EXB	-	-	-
EX6	On	EXB	-	-	-
EX7	-	EXB	-	-	-
EX8	-	EXB	-	-	-
EX9	-	EXB	-	-	-
EX10	-	EXB	-	-	-
EX11	-	EXB	-	-	-
EX12	Off	EXB	-	-	-
EX13	-	EXB	-	-	-
EX14	-	EXB	-	-	-
EX15	-	EXB	-	-	-
EX16	On	EXB	-	-	-
EX17	-	EXB	-	-	-
IO4/C3V0	On	C3V	-	-	domainC
IO4/C5V0	On	C5V	-	-	domainC
IO4/C3V1	On	C3V	-	-	domainC
IO4/C5V1	On	C5V	-	-	domainC
IO6/C3V0	On	C3V	-	-	A
IO6/C5V0	On	C5V	-	-	A
IO6/C3V1	On	C3V	-	-	A
IO6/C5V1	On	C5V	-	-	A
IO9/C3V0	On	C3V	-	-	dmnJ
IO9/C5V0	On	C3V	-	-	dmnJ
IO9/C3V1	On	C3V	-	-	dmnJ
IO9/C3V2	On	C3V	-	-	dmnJ
IO12/C3V0	Off	Unknown	-	-	engB
IO12/C5V0	Off	Unknown	-	-	engB
IO12/C3V1	Off	Unknown	-	-	engB
IO12/C5V1	Off	Unknown	-	-	engB
IO16/C3V0	On	C3V	Assigned	Unknown	Q
IO16/C5V0	On	C5V	Assigned	Unknown	Q
IO16/C3V1	On	C3V	Assigned	Unknown	Q
IO16/C5V1	On	C5V	Assigned	Unknown	Q
SB0	On	CPU	Active	Passed	domainC
SB1	On	CPU	Active	Passed	A
SB2	On	CPU	Active	Passed	A
SB3	On	CPU	Active	Passed	engB
SB4	On	CPU (COD)	Active	Passed	engB
SB5	On	CPU	Active	Passed	engB
SB6	On	CPU (COD)	Active	Passed	A
SB7	On	CPU	Active	Passed	domainC
SB8	Off	CPU	Available	Unknown	Isolated
SB9	On	CPU	Active	Passed	dmnJ
SB10	Off	CPU	Available	Unknown	Isolated
SB11	Off	CPU	Available	Unknown	Isolated
SB12	Off	CPU (COD)	Assigned	Unknown	engB
SB13	-	Empty Slot	Available	-	Isolated
SB14	Off	CPU	Assigned	Failed	domainC
SB15	On	CPU	Active	Passed	P
SB16	On	CPU (COD)	Active	Passed	domainC
SB17	-	Empty Slot	Assigned	-	dmnR
IO0	-	Empty Slot	Available	-	Isolated
IO1	On	HPCI	Active	Passed	A
IO2	On	MCPU	Active	Passed	engB
IO3	On	MCPU	Active	Passed	domainC
IO4	On	HPCI	Available	Degraded	domainC
IO5	Off	HPCI+	Assigned	Unknown	engB
IO6	On	HPCI	Active	Passed	A

IO7	On	HPCI	Active	Passed	dmnJ
IO8	On	wPCI	Active	Passed	Q
IO9	On	HPCI+	Assigned	iPOST	dmnJ
IO10	Off	HPCI	Assigned	Unknown	engB
IO11	Off	HPCI	Assigned	Failed	engB
IO12	Off	HPCI	Assigned	Unknown	engB
IO13	-	Empty Slot	Available	-	Isolated
IO14	Off	HPCI+	Available	Unknown	Isolated
IO15	On	HPCI	Active	Passes	Isolated
IO16	On	HPCI	Assigned	Unknown	Q
IO17	-	Empty Slot	Assigned	-	dmnR

The following example illustrates `showboards` output if you have domain privileges for domains B, J, and R on a Sun Fire 15K system. `showboards` displays information for those boards that are assigned or available to domains B, J, and R. Boards that are assigned to other domains or that do not appear in the available component list for domains B, J, or R are not displayed.

EXAMPLE 4 Listing boards for Domain Admin With Privileges on Domains B, J, and R

```
sc0:sms-user:> showboards
```

Location	Pwr	Type	Board Status	Test Status	Domain
----	---	----	-----	-----	-----
SB3	On	CPU	Active	Passed	engB
SB4	On	CPU	Active	Passed	engB
SB5	On	CPU	Active	Passed	engB
SB8	Off	CPU	Available	Unknown	Isolated
SB9	On	CPU	Active	Passed	dmnJ
SB10	Off	CPU	Available	Unknown	Isolated
SB11	Off	CPU	Available	Unknown	Isolated
SB12	Off	CPU	Assigned	Unknown	engB
SB13	-	Empty Slot	Available	-	Isolated
SB17	-	Empty Slot	Assigned	-	dmnR
IO0	-	Empty Slot	Available	-	Isolated
IO2	On	MCPU	Active	Passed	engB
IO5	Off	HPCI+	Assigned	Unknown	engB
IO7	On	HPCI	Active	Passed	dmnJ
IO9	On	HPCI+	Assigned	iPOST	dmnJ
IO10	Off	HPCI	Assigned	Unknown	engB
IO11	Off	HPCI	Assigned	Failed	engB
IO12	Off	HPCI	Assigned	Unknown	engB
IO13	-	Empty Slot	Available	-	Isolated
IO14	Off	HPCI+	Available	Unknown	Isolated
IO17	-	Empty Slot	Assigned	-	dmnR

In the following example, `showboards` displays output if you have domain privileges on domains B, J, and R on a Sun Fire 15K system. The command shows board information for those DCUs that are assigned or available to the specified domain. DCUs that are assigned to other domains or that do not appear in the specified domain's available component list are not displayed.

EXAMPLE 5 Listing boards for Domain Administrators for Domain B

```
sc0:sms-user:> showboards -d b
```

Location	Pwr	Type	Board Status	Test Status	Domain
----	---	----	-----	-----	-----
SB3	On	CPU	Active	Passed	engB
SB4	On	CPU	Active	Passed	engB
SB5	On	CPU	Active	Passed	engB
SB6	-	Empty Slot	Available	-	Isolated
SB8	Off	CPU	Available	Unknown	Isolated
SB8	Off	CPU	Available	Unknown	Isolated
SB10	Off	CPU	Available	Unknown	Isolated
SB11	Off	CPU	Available	Unknown	Isolated
SB12	Off	CPU	Assigned	Unknown	engB
SB13	-	Empty Slot	Available	-	Isolated
IO0	-	Empty Slot	Available	-	Isolated
IO2	On	MCPU	Active	Passed	engB
IO5	Off	HPCI+	Assigned	Unknown	engB
IO6	-	Empty Slot	Available	-	Isolated
IO10	Off	HPCI	Assigned	Unknown	engB
IO11	Off	HPCI	Assigned	Failed	engB
IO12	Off	HPCI	Assigned	Unknown	engB
IO13	-	Empty Slot	Available	-	Isolated
IO14	Off	HPCI+	Available	Unknown	Isolated

EXIT STATUS

The following exit values are returned:

- | | |
|---|---|
| 0 | Successful completion. |
| 1 | An invalid domain was specified. |
| 2 | An invalid command-line option was specified. |
| 3 | An incorrect number of domains was specified. |
| 4 | The user does not have valid privileges. |
| 5 | An internal error occurred. |
| 6 | An error occurred getting board information. |

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **setupplatform**(1M), **showcodusage**(1M), **showplatform**(1M)

NAME	showbus - display the bus configuration of expanders in active domains
SYNOPSIS	showbus [-v] showbus -h
DESCRIPTION	showbus(1M) displays the bus configuration of expanders in active domains. This information defaults to displaying configuration by slot order EX0-EX17.
OPTIONS	The following options are supported: -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored. -v Verbose. Displays all available command information. In addition to expander configuration, the domain, domain keyswitch position, and slot 0 and slot 1 board assignments are displayed.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator, operator, or service privileges to display all sets of communicating expanders (SOCX) in the system. Domain administrators or configurators can display only the SOCX assigned to the domain(s) in which they have privileges. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.

EXAMPLES**EXAMPLE 1** Display Bus Configuration for All Domains

This display is the default for platform administrators. A domain administrator/configurator must have privileges on all domains in order to obtain this display. Otherwise only those domains for which the user has privileges are displayed.

```
sc0:sms-user:> showbus
```

Location	Data	Address	Response	SOCX
EX0	CS0	CS1	CS0	0x0001
EX1	UNCONF	UNCONF	UNCONF	UNCONF
EX2	UNCONF	UNCONF	UNCONF	UNCONF
EX3	UNCONF	UNCONF	UNCONF	UNCONF
EX4	BOTH	BOTH	BOTH	0x14010
EX5	UNCONF	UNCONF	UNCONF	UNCONF
EX6	UNCONF	UNCONF	UNCONF	UNCONF
EX7	UNCONF	UNCONF	UNCONF	UNCONF
EX8	UNCONF	UNCONF	UNCONF	UNCONF
EX9	UNCONF	UNCONF	UNCONF	UNCONF
EX10	UNCONF	UNCONF	UNCONF	UNCONF
EX11	UNCONF	UNCONF	UNCONF	UNCONF
EX12	UNCONF	UNCONF	UNCONF	UNCONF
EX13	UNCONF	UNCONF	UNCONF	UNCONF
EX14	BOTH	BOTH	BOTH	0x14010
EX15	UNCONF	UNCONF	UNCONF	UNCONF
EX16	BOTH	BOTH	BOTH	0x14010
EX17	UNCONF	UNCONF	UNCONF	UNCONF

EXAMPLE 2 Display Showbus Information for All Domains Using `-v`

```

sc0:sms-user:> showbus -v
-----
SOCX: 0x14010
-----
Data:      BOTH
Address:   BOTH
Response:  BOTH
-----
Domain:A keyswitch: ON
Location:EX4 SB4:active IO4 :active
Location:EX14                IO14:active
Location:EX16                IO16:active
-----
SOCX: 0x00001
-----
Data:      CS0
Address:   CS1
Response:  CS0
-----
Domain:B keyswitch: ON
Location:EX0 SB0:active IO0:active
-----
UNCONFIGURED
-----
Domain: A keyswitch: ON
Location:EX6 SB6:unknown

```

EXIT STATUS The following exit values are returned:

```

0           Successful completion.
>0         An error occurred.

```

ATTRIBUTES See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **setbus** (1M)

NAME	showcmdsyc - display the current command synchronization list
SYNOPSIS	showcmdsyc [-v] showcmdsyc -h
DESCRIPTION	<p>showcmdsyc displays the command synchronization list to be used by the spare system controller (SC) to determine which commands or scripts need to be restarted after an SC failover.</p> <p>The command synchronization list is displayed in the format <i>Descriptor, Identifier, Cmd</i>, where:</p> <p><i>Descriptor</i> Specifies the command synchronization descriptor that represents a particular script.</p> <p><i>Identifier</i> Identifies a marker point in the script from which the script can be resumed on the new main SC after an automatic failover occurs. The identifier -1 indicates that the script does not have any marker points.</p> <p><i>Cmd</i> Indicates the name of the script to be restarted.</p>
OPTIONS	<p>The following options are supported:</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-v Verbose. Displays all available command information.</p>
EXTENDED DESCRIPTION	
Group Privileges Required	<p>You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>
EXAMPLES	<p>EXAMPLE 1 Displaying a Command Synchronization List</p> <pre>sc0:sms-user:> showcmdsyc DESCRIPTOR IDENTIFIER CMD 0 -1 c1 a1 a2</pre>

EXIT STATUS The following exit values are returned:

0 Successful completion.
>0 An error occurred.

ATTRIBUTES See **attributes(5)** for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **cancelcmdsnc(1M)**, **initcmdsnc(1M)**, **runcmdsync(1M)**, **savecmdsnc(1M)**

NAME	showcodlicense - display the current Capacity on Demand (COD) right-to-use (RTU) licenses stored in the COD license database																
SYNOPSIS	<p>showcodlicense [-r] [-v]</p> <p>showcodlicense -h</p>																
DESCRIPTION	showcodlicense(1M) displays COD license information stored in the COD license database.																
OPTIONS	<p>The following options are supported:</p> <p>-h Help. Displays usage descriptions.</p> <p style="padding-left: 150px;">Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-r Displays the license information in the raw <i>license-signature</i> format, as stored in the COD license database.</p> <p>-v Verbose. Displays both the formatted license information and raw <i>license-signature</i> data.</p>																
EXTENDED DESCRIPTION	<p>The showcodlicense command displays the following COD information:</p> <table border="0" style="width: 100%;"> <tr> <td style="width: 30%;">Description</td> <td>Type of resource (processor).</td> </tr> <tr> <td>Lic Ver</td> <td>Version number of the license, which is always set to 01.</td> </tr> <tr> <td>Expiration</td> <td>None.</td> </tr> <tr> <td>Count</td> <td>Number of right-to-use licenses granted for the given resource.</td> </tr> <tr> <td>Status</td> <td>GOOD, which indicates that the given resource is valid, or EXPIRED, which indicates that the resource license is no longer valid.</td> </tr> <tr> <td>Cls</td> <td>Not supported. Tier class value is always set to 1.</td> </tr> <tr> <td>Tier Num</td> <td>Not supported. Tier number value is always set to 1.</td> </tr> <tr> <td>Req</td> <td>Not supported. Required number of lower-tier licenses is always set to 0.</td> </tr> </table>	Description	Type of resource (processor).	Lic Ver	Version number of the license, which is always set to 01.	Expiration	None.	Count	Number of right-to-use licenses granted for the given resource.	Status	GOOD, which indicates that the given resource is valid, or EXPIRED, which indicates that the resource license is no longer valid.	Cls	Not supported. Tier class value is always set to 1.	Tier Num	Not supported. Tier number value is always set to 1.	Req	Not supported. Required number of lower-tier licenses is always set to 0.
Description	Type of resource (processor).																
Lic Ver	Version number of the license, which is always set to 01.																
Expiration	None.																
Count	Number of right-to-use licenses granted for the given resource.																
Status	GOOD, which indicates that the given resource is valid, or EXPIRED, which indicates that the resource license is no longer valid.																
Cls	Not supported. Tier class value is always set to 1.																
Tier Num	Not supported. Tier number value is always set to 1.																
Req	Not supported. Required number of lower-tier licenses is always set to 0.																
Group Privileges Required	<p>You must have platform administrator or platform operator group privileges to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>																

EXAMPLES

The following examples show the COD license information displayed:

EXAMPLE 1 Displaying Formatted License Data

```
sc0:sms-user:> showcodlicense
```

Description	Lic		Count	Status	Cls	Tier	
	Ver	Expiration				Num	Req
PROC	01	NONE	16	GOOD	1	1	0

EXAMPLE 2 Displaying Raw License Data

```
sc0:sms-user:> showcodlicense -r
```

```
01:5014936C37048:03001:0201010100:16:00000000:RKQhd8zKNnTwvxT5DJ1ZNQ
```

EXAMPLE 3 Displaying Formatted and Raw License Data

```
sc0:sms-user:> showcodlicense -v
```

Description	Lic		Count	Status	Cls	Tier	
	Ver	Expiration				Num	Req
PROC	01	NONE	16	GOOD	1	1	0
01:5014936C37048:03001:0201010100:16:00000000:RKQhd8zKNnTwvxT5DJ1ZNQ							

EXIT STATUS

The following exit values are returned:

- 0 Successful completion.
- 1 Invalid usage.
- 2 The user does not have valid privileges.
- >2 An internal error occurred. For further information see /var/opt/SUNWSMS/adm/platform/messages.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addcodlicense(1M), **codd**(1M), **deletcodlicense**(1M), **showcodusage**(1M)

NAME	showcodusage - display the current usage statistics for Capacity on Demand (COD) resources								
SYNOPSIS	showcodusage [-v] [-p resource domains] showcodusage -h								
DESCRIPTION	showcodusage(1M) shows current information about COD right-to-use (RTU) licenses in use. By default, this command displays a summary of COD RTU licenses used and installed, along with the current state of each resource.								
OPTIONS	The following options are supported: <table border="0"> <tr> <td style="padding-right: 20px;">-h</td> <td>Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored.</td> </tr> <tr> <td style="padding-right: 20px;">-p domains</td> <td>Displays the license usage for each domain. The statistics reported include the number of COD RTU licenses used by the domain, resources assigned to the domain, and COD RTU licenses reserved for the domain.</td> </tr> <tr> <td style="padding-right: 20px;">-p resource</td> <td>Displays license usage by resource type.</td> </tr> <tr> <td style="padding-right: 20px;">-v</td> <td>Verbose. Displays all available COD usage information, including COD RTU license use for both the system and its domains.</td> </tr> </table>	-h	Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored.	-p domains	Displays the license usage for each domain. The statistics reported include the number of COD RTU licenses used by the domain, resources assigned to the domain, and COD RTU licenses reserved for the domain.	-p resource	Displays license usage by resource type.	-v	Verbose. Displays all available COD usage information, including COD RTU license use for both the system and its domains.
-h	Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored.								
-p domains	Displays the license usage for each domain. The statistics reported include the number of COD RTU licenses used by the domain, resources assigned to the domain, and COD RTU licenses reserved for the domain.								
-p resource	Displays license usage by resource type.								
-v	Verbose. Displays all available COD usage information, including COD RTU license use for both the system and its domains.								
EXTENDED DESCRIPTION	The showcodusage -p resource command displays the following COD usage information for the system: <table border="0"> <tr> <td style="padding-right: 20px;">Resource</td> <td>Identifies the type of COD resources available (processors).</td> </tr> <tr> <td style="padding-right: 20px;">In Use</td> <td>Specifies the number of COD CPUs currently used in the system.</td> </tr> <tr> <td style="padding-right: 20px;">Installed</td> <td>Specifies the number of COD CPUs installed in the system.</td> </tr> <tr> <td style="padding-right: 20px;">License</td> <td>Specifies the number of COD RTU licenses installed.</td> </tr> </table>	Resource	Identifies the type of COD resources available (processors).	In Use	Specifies the number of COD CPUs currently used in the system.	Installed	Specifies the number of COD CPUs installed in the system.	License	Specifies the number of COD RTU licenses installed.
Resource	Identifies the type of COD resources available (processors).								
In Use	Specifies the number of COD CPUs currently used in the system.								
Installed	Specifies the number of COD CPUs installed in the system.								
License	Specifies the number of COD RTU licenses installed.								

Status	Specifies one of the following COD attributes:	
	OK	Indicates that there are sufficient licenses for the COD CPUs in use. Also specifies the number of remaining COD resources available and the number of any instant access CPUs (headroom) available.
	HEADROOM	The number of instant access COD CPUs in use.
	Violation	Indicates a COD RTU license violation exists. Specifies the number of COD CPUs in use that exceeds the number of COD RTU licenses available. This situation can occur when you force the deletion of a COD RTU license key from the COD RTU license database, but the COD CPU associated with the license key is still in use.

The `showcodusage -p domain` command displays the following COD usage information for each domain:

Domain/Resource	Identifies COD RTU resource (processor) for each domain. An Unused processor is a COD CPU that has not yet been assigned to a domain.	
In Use	Specifies the number of COD CPUs currently used in the domain.	
Installed	Specifies the number of COD CPU resources installed in the domain.	
Reserved	Specifies the number of COD RTU licenses allocated to the domain.	
Status	Contains one of the following when the <code>-v</code> option is specified:	
	Licensed	The domain COD CPU has a COD RTU license and is in use.
	Unlicensed	A COD RTU license for the domain COD CPU could not be obtained and it is not in use.
	Unused	The COD CPU is not in use.

**Group Privileges
Required**

You must have platform administrator, platform operator, or domain administrator group privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

Users with platform administrator privileges can view both resource and domain usage summaries. Users with domain administrator privileges can view only the domain usage summaries for which they have privileges, and a report of unused licenses.

EXAMPLE 1 Displaying COD Usage by Resource

```
sc0:sms-user:> showcodusage -p resource
Resource  In Use  Installed  Licensed  Status
-----
PROC      4       4          16  OK: 12 available
```

EXAMPLE 2 Displaying COD Usage by Domain

```
sc0:sms-user:> showcodusage -p domains
Domain/Resource  In Use  Installed  Reserved
-----
A - PROC          0       0          0
B - PROC          0       0          0
C - PROC          0       0          0
D - PROC          4       4          0
E - PROC          0       0          0
F - PROC          0       0          0
G - PROC          0       0          0
H - PROC          0       0          0
I - PROC          0       0          0
J - PROC          0       0          0
K - PROC          0       0          0
L - PROC          0       0          0
M - PROC          0       0          0
N - PROC          0       0          0
O - PROC          0       0          0
P - PROC          0       0          0
Q - PROC          0       0          0
R - PROC          0       0          0
Unused - PROC    0       0          12
```

EXAMPLE 3 Displaying COD Usage by Resource and Domain

```

sc0:sms-user:> showcodusage -v
Resource  In Use  Installed  Licensed  Status
-----
PROC      4       4          16  OK: 12  available

Domain/Resource  In Use  Installed  Reserved  Status
-----
A - PROC          0         0         0
B - PROC          0         0         0
   SB6 - PROC     0         0
       SB6/P0                Unused
       SB6/P1                Unused
       SB6/P2                Unused
       SB6/P3                Unused
C - PROC          0         0         0
   SB12 - PROC    0         0
       SB12/P0                Unused
       SB12/P1                Unused
       SB12/P2                Unused
       SB12/P3                Unused
D - PROC          4         4         0
   SB4 - PROC     4         4
       SB4/P0                Licensed
       SB4/P1                Licensed
       SB4/P2                Licensed
       SB4/P3                Licensed
   SB16 - PROC    4         4
       SB16/P0                Unused
       SB16/P1                Unused
       SB16/P2                Unused
       SB16/P3                Unused
E - PROC          0         0         0
F - PROC          0         0         0
G - PROC          0         0         0
H - PROC          0         0         0
I - PROC          0         0         0
J - PROC          0         0         0
K - PROC          0         0         0
L - PROC          0         0         0
M - PROC          0         0         0
N - PROC          0         0         0
O - PROC          0         0         0
P - PROC          0         0         0
Q - PROC          0         0         0
R - PROC          0         0         0
Unused - PROC     0         0         12

```

EXIT STATUS

The following exit values are returned:

- 0 Successful completion.
- 1 User cancel.
- 2 Invalid usage.

3 User does not have valid privileges.
>3 An internal error occurred. For further information see
/var/opt/SUNWSMS/adm/platform/messages.

ATTRIBUTES

See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

showcodlicense (1M), **codd** (1M)



NAME	showcomponent - display the blacklist status for a component
SYNOPSIS	showcomponent [-a -d <i>domain_indicator</i>] [-v] [<i>location</i>]... showcomponent -h
DESCRIPTION	<p>showcomponent(1M) indicates whether the specified component is listed in the platform, domain, or ASR blacklist file.</p> <p>If neither the -a nor the -d option is specified, showcomponent displays the platform blacklist. If no <i>location</i> is specified, showcomponent displays all components in the specified blacklist.</p> <p>The <i>blacklist</i> is an internal file that lists components that POST cannot use at boot time. POST reads the blacklist file(s) before preparing the system for booting, and passes along to OpenBoot PROM a list of only those components that have been successfully tested; those on the blacklist are excluded.</p> <p>SMS supports three blacklists: one for domain boards, one for platform boards, and the internal automatic system recovery (ASR) blacklist.</p> <p>For more information on the use and editing of platform and domain blacklists refer to Chapter 6, "Domain Control," in the <i>System Management Services (SMS) 1.3 Administrator Guide</i>.</p>
OPTIONS	<p>The following options are supported:</p> <ul style="list-style-type: none"> -a Specifies the ASR blacklist. -d <i>domain_indicator</i> Specifies the domain using one of the following: <ul style="list-style-type: none"> <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M). -h Help. Displays usage descriptions. <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <ul style="list-style-type: none"> -v Verbose. Displays all available command information.

OPERANDS

The following operands are supported:

location

List of component locations, separated by forward slashes and comprised of:

board_loc/proc/bank/logical_bank

board_loc/proc/bank/all_dimms_on_that_bank

board_loc/proc/all_banks_on_that_proc

board_loc/all_banks_on_that_board

board_loc/proc

board_loc/procs

board_loc/cassette

board_loc/bus

board_loc/paroli_link

Multiple *location* arguments are permitted, separated by a space.

The *location* forms are optional and are used to specify particular components on boards in specific locations.

For example, the *location* SB5/P0/B1/L1 indicates Logical Bank 1 of Bank 1 on Processor 0 at SB5.

The SB0/PP1 *location* indicates Processor Pair 1 at SB0.

The CS0/ABUS1 *location* indicates address bus 1 at CS0.

The following *board_loc* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

CS(0|1), CS(0|1)

EX(0...17), EX(0...8)

Processor locations indicate single processors or processor pairs.

There are four possible processors on a CPU/memory board. Processor pairs on that board are procs 0 and 1, and procs 2 and 3.

The MaxCPU has two processors: procs 0 and 1, and only one proc pair (PP0). Using PP1 for this board causes `disablecomponent` to exit and display an error message.

The following *proc* forms are accepted:

`P(0...3)` `PP(0|1)`

The following *bank* forms are accepted:

`B(0|1)`

The following *logical_bank* forms are accepted:

`L(0|1)`

The following *all_dimms_on_that_bank* forms are accepted:

`D`

The following *all_banks_on_that_proc* forms are accepted:

`B`

The following *all_banks_on_that_board* forms are accepted:

`B`

The following *paroli_link* forms are accepted:

`PAR(0|1)`

The hsPCI assemblies contain hot-swappable cassettes.

The following *hsPCI* forms are accepted:

`C(3|5)V(0|1)`

The hsPCI+ assemblies contain hot-swappable cassettes.

The following *hsPCI+* forms are accepted:

`C3V(0|1|2)` and `C5V0`

There are three bus locations: address, data, and response.

The following *bus* forms are accepted:

```
ABUS|DBUS|RBUS (0|1)
```

EXTENDED DESCRIPTION

Group Privileges Required

You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command. If you have domain privileges you can run this command only on the domain for which you have privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Displaying Whether SB0 is ASR Blacklisted

```
sc0:sms-user:> showcomponent -a SB0
Component SB0 is disabled: #High Voltage
```

EXAMPLE 2 Displaying Whether Four Boards/Components in Domain B Are Blacklisted

```
sc0:sms-user:> showcomponent -dB IO4/PP0 SB5 IO6/C5V0 EX7/ABUS0
Component IO4/PP0 is disabled: #High temp
Component SB5 is disabled: <no reason given>
Component IO6/C5V0 is NOT disabled.
Component EX7/ABUS0 is NOT disabled.
```

EXAMPLE 3 Displaying Whether the Logical Bank on IO7 in Domain B Is Blacklisted

```
sc0:sms-user:> showcomponent -dB IO7/P0/B1/L0
Component IO7/P0/B1/L0 is disabled: <no reason given>
```

EXAMPLE 4 Displaying All Platform-Blacklisted Components

```
sc0:sms-user:> showcomponent
Component SB0 is disabled: #High temp
Component SB3 is disabled:
Component IO2 is disabled. <no reason given>
```

EXAMPLE 5 Displaying All Domain B Blacklisted Components

```
sc0:sms-user:> showcomponent -dB
Component IO4/PP0 is disabled: #High temp
Component SB5 is disabled: <no reason given>
```

EXAMPLE 6 Displaying All ASR-Blacklisted Components

```
sc0:sms-user:> showcomponent -a
Component SB0 is disabled: #High temp
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.
>0 An error occurred.

FILES

The following files are used by this command.

<code>/etc/opt/SUNWSMS/config/asr/blacklist</code>	List of components excluded by esmd.
<code>/etc/opt/SUNWSMS/config/platform/blacklist</code>	List of platform components excluded.
<code>/etc/opt/SUNWSMS/config/<i>domain_id</i>/blacklist</code>	List of domain components excluded.

Note – The ASR blacklist file is created and used internally and should *not* be edited manually.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

enablecomponent(1M), **disablecomponent**(1M), **esmd**(1M)



NAME	showdatasync - display the status of system controller (SC) data synchronization for failover
SYNOPSIS	showdatasync [-l -Q] [-v] showdatasync -h
DESCRIPTION	showdatasync provides the current status of files propagated (copied) from the main SC to its spare. Data propagation synchronizes data on the spare SC with data on the main SC, so that the spare SC is current with the main SC if an SC failover occurs.
OPTIONS	The following options are supported: -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored. -l Lists the files in the current data propagation list. For details on the information displayed see the EXTENDED DESCRIPTION section. -Q Lists the files queued for propagation. Each file name includes the absolute path to the file. -v Verbose. Displays all available command information.
EXTENDED DESCRIPTION	This section describes the information displayed by the showdatasync command. If you do not specify an option with the showdatasync command, the following information is displayed: <pre>File Propagation Status: Active File: Queued files:</pre>

where:

File Propagation Status	Displays the current status of data synchronization:	
	Active	Indicates that the data synchronization process is enabled and functioning normally.
	Disabled	Indicates that the data synchronization process has been disabled because SC failover was disabled.
	Failed	Indicates that the data synchronization process cannot currently propagate files to the spare SC.
Active File	Displays either the absolute path of the file currently being propagated or a dash (-) indicating that the link is idle.	
Queued files	Specifies the number of files to be propagated but not yet processed.	

If you specify the `-l` option with the `showdatasync` command, each entry in the data propagation list is displayed in the format:

```

TIME PROPAGATED          INTERVAL          FILE
time                    interval         filename

```

where:

<i>time</i>	Indicates the last time that the file was propagated from the main SC to the spare.
<i>interval</i>	Specifies the interval, in minutes, between checks for file modification. The default interval is 60 minutes.
<i>filename</i>	Provides the absolute path and name of the propagated file.

Group Privileges Required

You must have platform administrator, platform operator, platform service, domain administrator, or domain configurator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Displaying Data Synchronization Status

```

sc0:sms-user:> showdatasync
File Propagation State: ACTIVE
Active File:           -
Queued files:         0

```

EXAMPLE 2 Displaying Data Synchronization List

```
sc0:sms-user:> showdatasync -l
TIME PROPAGATED      INTERVAL      FILE
Mar 23 16:00:00          60          /tmp/t1
```

EXAMPLE 3 Displaying Data Synchronization Queue

```
sc0:sms-user:> showdatasync -Q
FILE
/tmp/t1
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.
>0 An error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

setdatasync(1M)



NAME	showdate - display the date and time for the system controller (SC) or a domain
SYNOPSIS	showdate [-d <i>domain_indicator</i>] [-u] [-v] showdate -h
DESCRIPTION	showdate (1M) displays the SC's current date and time. Optionally, showdate displays domain time of day.
OPTIONS	The following options are supported: -d <i>domain_indicator</i> Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M). -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored. -u Interprets and displays the time using Greenwich Mean Time (GMT). The default is the local time zone. -v Verbose. Displays all available command information.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator, platform operator, or platform service privileges to display the date on the SC. You must have domain administrator or domain configurator privileges for the specified domain to display the domain date. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Showing the Current Local Date in Pacific Standard Time <pre>sc0:sms-user:> showdate System Controller: Sat Feb 2 15:23:21 PST 2002</pre> EXAMPLE 2 Showing the Current Date Using GMT <pre>sc0:sms-user:> showdate -u System Controller: Sat Feb 2 23:23:21 GMT 2002</pre>

EXAMPLE 3 Showing the Current Local Date on Domain A in Pacific Standard Time

```
sc0:sms-user:> showdate -d a
Domain a: Sat Feb 2 15:33:20 PST 2002
```

EXAMPLE 4 Showing the Current Date on Domain A Using GMT

```
sc0:sms-user:> showdate -d a -u
Domain a: Sat Feb 2 23:33:20 GMT 2002
```

EXIT STATUS

The following exit values are returned:

```
0           Successful completion.
>0         An error occurred.
```

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **setdate**(1M)

NAME	showdevices - display system board devices and resource usage information
SYNOPSIS	<p>showdevices [-v] [-p bydevice byboard query force] <i>location...</i></p> <p>showdevices [-v] [-p bydevice byboard] -d <i>domain_indicator</i></p> <p>showdevices -h</p>
DESCRIPTION	<p>showdevices(1M) displays the configured physical devices on system boards and the resources made available by these devices. Usage information is provided by applications and subsystems that are actively managing system resources. You can perform offline queries of managed resources to display the predicted impact of a system board DR operation. Unmanaged devices are not displayed by default; you must use the -v option.</p> <p>showdevices gathers device information from one or more Sun Fire 15K/12K domains. The command uses dca(1M) as a proxy to gather the information from the domains.</p>
OPTIONS	<p>The following options are supported.</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-h Help. Displays usage descriptions.</p> <p>Note - Use alone. Any option specified in addition to -h is ignored.</p>

`-p` Displays specific reports.

Valid arguments for `-p` are:

<code>bydevice</code>	List output is grouped by device type (CPU, memory, IO). This is the default.
<code>byboard</code>	List output is grouped by system board. Default output is in tabular format grouped by device type (CPU, memory, IO).
<code>query</code>	List output is the result of a query to predict the effect of removing a system board
<code>force</code>	Forced offline query. Resource consumers are requested to apply force semantics in predicting whether they are able to relinquish usage of the system resources. (see <code>cfgadm(1M)</code>).

Note – The `query` and `force` arguments are *not* valid with the `-d` option.

`-v` Displays all I/O devices. Includes both managed and unmanaged I/O devices. Managed devices export actively managed resources. Unmanaged devices are physically configured but do not export actively managed resources. No usage information is available for unmanaged devices.

OPERANDS

The following operands are supported:

location List of board locations, separated by a space. Multiple *location* arguments are permitted.

The following *location* forms are accepted:

Sun Fire 15K, Sun Fire 12K

SB(0...17), SB(0...8)

IO(0...17), IO(0...8)

**EXTENDED
DESCRIPTION**

Showdevices fields:

domain Tag or identifier

board Board identifier

CPU:

id Processor Id

state Processor state

speed CPU frequency in MHz

ecache CPU ecache size in MB

Memory:

board mem Board memory size in MB

perm mem Amount of nonrelocatable memory on board in MB

base address Base physical address of memory on board

domain mem System memory size in MB

board Board identifier

If a memory drain is in progress, the following is available:

target board Target board identifier

deleted Amount of memory already deleted in MB

remaining Amount of memory remaining to be deleted in MB

I/O devices:

device I/O device instance name

resource Managed resource name

usage Description of resource usage instance

query Result of offline query of resources

**Group Privileges
Required**

You must have domain administrator/configurator privileges on all boards specified to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Displaying devices for System Board IO1

```
sc0:sms-user:> showdevices IO1
IO Devices
-----
domain location device resource usage
A IO1 sd3 /dev/dsk/c0t3d0s0 mounted filesystem "/"
A IO1 sd3 /dev/dsk/c0t3s0s1 dump device (swap)
A IO1 sd3 /dev/dsk/c0t3s0s1 swap area
A IO1 sd3 /dev/dsk/c0t3d0s3 mounted filesystem "/var"
A IO1 sd3 /var/run mounted filesystem "/var/run"
```

EXAMPLE 2 Displaying devices for Domain A

```
sc0:sms-user:> showdevices -v -d A
CPU
----
domain location id state speed ecache
A C1 40 online 400 4
A C1 41 online 400 4
A C1 42 online 400 4
A C1 43 online 400 4
A C2 55 online 400 4
A C2 56 online 400 4
A C2 57 online 400 4
A C2 58 online 400 4

Memory
drain in progress:
-----
domain location board perm base domain target deleted remaining
domain location mem MB mem MB address mem MB board mem MB mem MB
A C1 2048 723 0x600000 4096 C2 250 1500
A C2 2048 0 0x200000 4096

IO Devices
-----
domain location device resource usage
A IO1 sd0
A IO1 sd1
A IO1 sd2
A IO1 sd3 /dev/dsk/c0t3d0s0 mounted filesystem "/"
A IO1 sd3 /dev/dsk/c0t3s0s1 dump device (swap)
A IO1 sd3 /dev/dsk/c0t3s0s1 swap area
A IO1 sd3 /dev/dsk/c0t3d0s3 mounted filesystem "/var"
A IO1 sd3 /var/run mounted filesystem "/var/run"
A IO1 sd4
A IO1 sd5
A IO1 sd6
```

EXAMPLE 3 Displaying Offline Query Result for System Board IO1

```
sc0:sms-user:> showdevices -p query IO1

Location IO1 - Domain A
=====
IO Devices
-----
device  resource                query  usage/reason
sd3     /dev/dsk/c0t3d0s0          fail   mounted filesystem "/"
sd3     /dev/dsk/c0t3s0s1          fail   dump device (swap)
sd3     /dev/dsk/c0t3s0s1          fail   swap area
sd3     /dev/dsk/c0t3d0s3          fail   mounted filesystem "/var"
sd3     /var/run                   -      mounted filesystem "/var/run"
```

The query field shows the predicted result of removing the resource. The failure of the mounted file system `/var` to offline prevents the query from reaching the layered mount point `/var/run`.

EXIT STATUS

The following exit values are returned:

- | | |
|---|--|
| 0 | Successful completion. |
| 1 | An invalid domain was specified. |
| 2 | A command line error such as an invalid option was detected. |
| 3 | More than one domain was specified. |
| 4 | An error occurred communicating with <code>pcd</code> . |
| 5 | An error occurred communicating with a domain. |
| 6 | An error occurred handling device information. |
| 7 | An internal error such as failed memory allocation occurred. |

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M), **dca**(1M), **pcd**(1M)



NAME	showenvironment - display the environmental data
SYNOPSIS	<p>showenvironment [-d <i>domain_indicator</i> [, <i>domain_indicator</i>]...]... [-p temps volts currents fans powers [,temps volts currents fans powers]...]... [-v]</p> <p>showenvironment [-d <i>domain_indicator</i>[, <i>domain_indicator</i>]...]... [-p faults] [-v]</p> <p>showenvironment -h</p>
DESCRIPTION	<p>showenvironment(1M) displays the environmental data (temperatures, voltages, and so on). If a domain <i>domain_id</i> or <i>domain_tag</i> is specified, environmental data relating to the domain is displayed, providing that the user has domain privileges for that domain. If a domain is not specified, all domain data permissible to the user is displayed.</p> <p>Note – Only <i>domain configuration units</i> (DCUs) (for example, CPU or I/O) belong to a domain. Displaying environmental data relating to such things as fan trays, bulk power, or other boards (<i>exb</i>, <i>csb</i>) requires platform privileges. You can also specify individual reports for temperatures, voltages, currents, bulk power status, and fan tray status; or faults with the <i>-p</i> option. If the <i>-p</i> option is not present, all reports are shown.</p>
OPTIONS	<p>The following options are supported:</p> <p><i>-d domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> – ID for a domain. Valid <i>domain_ids</i> are A–R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> – Name assigned to a domain using <i>addtag(1M)</i>.</p> <p><i>-h</i> Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to <i>-h</i> is ignored.</p>

- p Display specific reports. Multiple report arguments are separated by commas.
- Valid reports are:
- | | |
|----------|--|
| temps | List output is grouped by temperature. |
| volts | List output is grouped by voltage. |
| currents | List output is grouped by current |
| fans | List output is grouped by fans. |
| powers | List output is grouped by bulk power supplies. |
- p faults List output is of all component readings not within the optimum thresholds.
- Note** – The `faults` argument cannot be used in conjunction with any other report argument.
- v Verbose. Displays all available command information.

EXTENDED DESCRIPTION

The Unit field contains one of three measurements:

C	Degrees Celsius
V	Volts
A	Amperes

The Status field can contain one of 16 states.

Temperature readings:

OVERLIMIT	Over limit.
HIGH_CRIT	High critical.
HIGH_WARN	High warning.
LOW_CRIT	Low critical.
LOW_WARN	Low warning.
OK	Optimum.
INVALID	Reading failure.

Voltage readings:

HIGH_MAX	High maximum.
LOW_MIN	Low minimum.
OK	Acceptable.
INVALID	Reading failure.

Current readings:

OK	The difference between both companion component readings are within tolerance.
BAD	The difference between both companion component readings are out of tolerance.
INVALID	Reading failure.

Miscellaneous:

ON	Power on.
OFF	Power off.
PRESENCE	A HotPlug card is present in slot 1.
FAIL	Failure state.
HIGH	Set to high speed.
NORMAL	Set to normal speed.
INVALID	Reading failure.
AGE	Age of the reading.
UNKNOWN	Unknown power/board type.

Group Privileges Required

Only domain information for which you have domain administrator or configurator privileges for is displayed. Otherwise, you must have platform administrator, operator or service privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Displaying Environmental Data for All Domains on a Sun Fire 15K System.

LOCATION	DEVICE	SENSOR	VALUE	UNIT	AGE	STATUS
SC at SC0	max1617a	RIO Temp	38.00	C	35.5	sec OK
SC at SC0	max1617a	IOA Temp	32.00	C	35.5	sec OK
SC at SC0	pcf8591	PS0 Temp	46.49	C	35.5	sec OK

SC at SC0	pcf8591	PS1 Temp	43.26	C	35.5	sec	OK
SC at SC0	sbbc	SBBC Temp	45.83	C	35.5	sec	OK
SC at SC0	cbh	CBH Temp	50.49	C	35.5	sec	OK
SCPER at SCPER0	max1617a	AMB 0 Temp	26.00	C	35.7	sec	OK
SCPER at SCPER0	max1617a	AMB 1 Temp	25.00	C	35.7	sec	OK
SCPER at SCPER0	max1617a	AMB 2 Temp	25.00	C	35.7	sec	OK
SC at SC0	pcf8591	1.5 VDC	1.48	V	37.1	sec	OK
SC at SC0	pcf8591	3.3 VDC	3.28	V	37.1	sec	OK
SC at SC0	pcf8591	3.3 VDC HK	3.28	V	37.1	sec	OK
SC at SC0	pcf8591	5.0 VDC	4.99	V	37.1	sec	OK
SC at SC0	pcf8591	+12.0 VDC	11.95	V	37.1	sec	OK
SC at SC0	pcf8591	-12.0 VDC	-12.01	V	37.1	sec	OK
SC at SC0	pcf8591	1.5 CVT0 VDC	1.48	V	37.1	sec	OK
SC at SC0	pcf8591	1.5 CVT1 VDC	1.48	V	37.1	sec	OK
SCPER at SCPER0	pcf8591	3.3 VDC HK	3.28	V	37.3	sec	OK
SCPER at SCPER0	pcf8591	5.0 VDC	5.02	V	37.3	sec	OK
SCPER at SCPER0	pcf8591	+12.0 VDC	12.10	V	37.3	sec	OK
SC at SC0	pcf8591	3.3 V_PS0	6.44	A	37.2	sec	OK
SC at SC0	pcf8591	3.3 V_PS1	5.71	A	37.2	sec	OK
SC at SC0	pcf8591	5.0 V_PS0	6.10	A	37.2	sec	OK
SC at SC0	pcf8591	5.0 V_PS1	6.22	A	37.2	sec	OK
SC at SC1	max1617a	RIO Temp	30.00	C	35.5	sec	OK
SC at SC1	max1617a	IOA Temp	25.00	C	35.5	sec	OK
SC at SC1	pcf8591	PS0 Temp	41.65	C	35.5	sec	OK
SC at SC1	pcf8591	PS1 Temp	33.58	C	35.5	sec	OK
SCPER at SCPER1	max1617a	AMB 0 Temp	18.00	C	35.7	sec	OK
SCPER at SCPER1	max1617a	AMB 1 Temp	18.00	C	35.7	sec	OK
SCPER at SCPER1	max1617a	AMB 2 Temp	18.00	C	35.7	sec	OK
SC at SC1	pcf8591	1.5 VDC	1.48	V	37.0	sec	OK
SC at SC1	pcf8591	3.3 VDC	3.28	V	37.0	sec	OK
SC at SC1	pcf8591	3.3 VDC HK	3.28	V	37.0	sec	OK
SC at SC1	pcf8591	5.0 VDC	4.99	V	37.0	sec	OK
SC at SC1	pcf8591	+12.0 VDC	11.95	V	37.0	sec	OK
SC at SC1	pcf8591	-12.0 VDC	-12.01	V	37.0	sec	OK
SC at SC1	pcf8591	1.5 CVT0 VDC	1.88	V	37.0	sec	OK
SC at SC1	pcf8591	1.5 CVT1 VDC	1.87	V	37.0	sec	OK
SCPER at SCPER1	pcf8591	3.3 VDC HK	3.28	V	37.3	sec	OK
SCPER at SCPER1	pcf8591	5.0 VDC	5.02	V	37.3	sec	OK
SCPER at SCPER1	pcf8591	+12.0 VDC	12.03	V	37.3	sec	OK
SC at SC1	pcf8591	3.3 V_PS0	6.15	A	37.0	sec	OK
SC at SC1	pcf8591	3.3 V_PS1	5.85	A	37.0	sec	OK
SC at SC1	pcf8591	5.0 V_PS0	5.98	A	37.0	sec	OK
SC at SC1	pcf8591	5.0 V_PS1	6.22	A	37.0	sec	OK
CSB at CS0	max1617a	AMB Top Temp	30.00	C	29.8	sec	OK
CSB at CS0	max1617a	AMB Bot Temp	31.00	C	29.8	sec	OK
CSB at CS0	sbbc	SBBC Temp	39.16	C	29.8	sec	OK
CSB at CS0	pcf8591	1.5 VDC	1.51	V	36.8	sec	OK
CSB at CS0	pcf8591	3.3 VDC	3.30	V	36.8	sec	OK
CSB at CS0	pcf8591	2.5 VDC	2.54	V	36.8	sec	OK
CSB at CS0	pcf8591	3.3 VDC HK	3.30	V	36.8	sec	OK
CSB at CS1	max1617a	AMB Top Temp	24.00	C	29.6	sec	OK
CSB at CS1	max1617a	AMB Bot Temp	26.00	C	29.6	sec	OK
CSB at CS1	sbbc	SBBC Temp	33.16	C	29.6	sec	OK
CSB at CS1	pcf8591	1.5 VDC	1.51	V	36.7	sec	OK
CSB at CS1	pcf8591	3.3 VDC	3.30	V	36.7	sec	OK
CSB at CS1	pcf8591	2.5 VDC	2.54	V	36.7	sec	OK
CSB at CS1	pcf8591	3.3 VDC HK	3.28	V	36.7	sec	OK
CP at CP0	dmx0	DMX0 Temp	33.91	C	32.3	sec	OK
CP at CP0	dmx1	DMX1 Temp	33.95	C	32.3	sec	OK
CP at CP0	dmx3	DMX3 Temp	29.92	C	32.3	sec	OK
CP at CP0	dmx5	DMX5 Temp	23.98	C	32.3	sec	OK
CP at CP0	amx0	AMX0 Temp	37.32	C	32.3	sec	OK
CP at CP0	amx1	AMX1 Temp	35.43	C	32.3	sec	OK
CP at CP0	rmx	RMX Temp	37.47	C	32.3	sec	OK
CP at CP0	darb	DARB Temp	31.85	C	32.3	sec	OK
CP at CP1	dmx0	DMX0 Temp	37.26	C	30.0	sec	OK
CP at CP1	dmx1	DMX1 Temp	37.26	C	30.0	sec	OK

CP at CP1	dmx3	DMX3 Temp	31.14	C	30.0	sec	OK
CP at CP1	dmx5	DMX5 Temp	29.12	C	30.0	sec	OK
CP at CP1	amx0	AMX0 Temp	36.60	C	30.0	sec	OK
CP at CP1	amx1	AMX1 Temp	38.77	C	30.0	sec	OK
CP at CP1	rmx	RMX Temp	36.73	C	30.0	sec	OK
CP at CP1	darb	DARB Temp	37.16	C	30.0	sec	OK
EXB at EX1	max1617a	AMB Top Temp	38.00	C	43.3	sec	OK
EXB at EX1	max1617	AMB Bot Temp	35.00	C	43.3	sec	OK
EXB at EX1	sbbc	SBBC Temp	50.49	C	43.3	sec	OK
EXB at EX1	axq	AXQ Temp	26.91	C	43.3	sec	OK
EXB at EX1	sdim	SDIM Temp	42.91	C	43.3	sec	OK
EXB at EX1	sdisc	SDISC Temp	48.83	C	43.3	sec	OK
EXB at EX1	sdise	SDISE Temp	38.67	C	43.3	sec	OK
EXB at EX1	pcf8591	1.5 VDC	1.51	V	36.5	sec	OK
EXB at EX1	pcf8591	3.3 VDC	3.30	V	36.5	sec	OK
EXB at EX1	pcf8591	2.5 VDC	2.51	V	36.5	sec	OK
EXB at EX1	pcf8591	3.3 VDC HK	3.30	V	36.5	sec	OK
CPU at SB1	max1617a	PROC 0 Temp	64.00	C	0.7	sec	OK
CPU at SB1	max1617a	PROC 1 Temp	69.00	C	0.7	sec	OK
CPU at SB1	max1617a	PROC 2 Temp	69.00	C	0.7	sec	OK
CPU at SB1	max1617a	PROC 3 Temp	67.00	C	0.7	sec	OK
CPU at SB1	sdco	SDCO Temp	69.82	C	0.7	sec	OK
CPU at SB1	ar0	AR0 Temp	63.16	C	0.7	sec	OK
CPU at SB1	dx0	DX0 Temp	66.49	C	0.7	sec	OK
CPU at SB1	dx1	DX1 Temp	64.49	C	0.7	sec	OK
CPU at SB1	dx2	DX2 Temp	62.49	C	0.7	sec	OK
CPU at SB1	dx3	DX3 Temp	56.49	C	0.7	sec	OK
CPU at SB1	sbbc0	SBBC0 Temp	60.49	C	0.7	sec	OK
CPU at SB1	sbbc1	SBBC1 Temp	69.82	C	0.7	sec	OK
CPU at SB1	pcf8591	1.5 VDC	1.51	V	37.3	sec	OK
CPU at SB1	pcf8591	3.3 VDC	3.30	V	37.3	sec	OK
CPU at SB1	pcf8591	Core 0 Volt	1.64	V	37.3	sec	OK
CPU at SB1	pcf8591	Core 1 Volt	1.65	V	37.3	sec	OK
CPU at SB1	pcf8591	Core 2 Volt	1.64	V	37.3	sec	OK
CPU at SB1	pcf8591	Core 3 Volt	1.64	V	37.3	sec	OK
HPCI at IO1	pcf8591	PS0 Temp	48.10	C	43.9	sec	OK
HPCI at IO1	pcf8591	PS1 Temp	35.19	C	43.9	sec	OK
HPCI at IO1	sdc	SDCO Temp	69.16	C	43.9	sec	OK
HPCI at IO1	ar	AR0 Temp	63.16	C	43.9	sec	OK
HPCI at IO1	dx0	DX0 Temp	62.49	C	43.9	sec	OK
HPCI at IO1	dx1	DX1 Temp	55.83	C	43.9	sec	OK
HPCI at IO1	sbbc	SBBC Temp	41.16	C	43.9	sec	OK
HPCI at IO1	max1617a	IOA0 Temp	53.00	C	43.9	sec	OK
HPCI at IO1	max1617a	IOA1 Temp	53.00	C	43.9	sec	OK
HPCI at IO1	pcf8591	1.5 VDC	1.49	V	37.3	sec	OK
HPCI at IO1	pcf8591	3.3 VDC	3.30	V	37.3	sec	OK
HPCI at IO1	pcf8591	5.0 VDC	4.99	V	37.3	sec	OK
HPCI at IO1	pcf8591	+12.0 VDC	11.95	V	37.3	sec	OK
HPCI at IO1	pcf8591	-12.0 VDC	-11.92	V	37.3	sec	OK
HPCI at IO1	pcf8591	3.3 VDC HK	3.28	V	37.3	sec	OK
HPCI at IO1	pcf8591	1.5 CVT0 VDC	3.28	V	37.3	sec	OK
HPCI at IO1	pcf8591	1.5 CVT1 VDC	1.49	V	37.3	sec	OK
HPCI at IO1	pcf8591	3.3 V_PS0	10.25	A	37.3	sec	OK
HPCI at IO1	pcf8591	3.3 V_PS1	10.25	A	37.3	sec	OK
HPCI at IO1	pcf8591	5.0 V_PS0	3.41	A	37.3	sec	OK
HPCI at IO1	pcf8591	5.0 V_PS1	3.41	A	37.3	sec	OK
Schizo0.0	max1617a	Schizo 0 Slot 0	N/A	N/A	N/A		PRESENCE
Schizo1.0	max1617a	Schizo 1 Slot 0	N/A	N/A	N/A		PRESENCE
Schizo0.1	max1617a	Schizo 0 Slot 1	N/A	N/A	N/A		PRESENCE
Schizo1.1	max1617a	Schizo 1 Slot 1	N/A	N/A	N/A		PRESENCE
EXB at EX3	max1617a	AMB Top Temp	35.00	C	56.1	sec	OK
EXB at EX3	max1617	AMB Bot Temp	34.00	C	56.1	sec	OK
EXB at EX3	sbbc	SBBC Temp	47.83	C	56.1	sec	OK
EXB at EX3	axq	AXQ Temp	26.93	C	56.1	sec	OK
EXB at EX3	sdim	SDIM Temp	42.58	C	56.1	sec	OK
EXB at EX3	sdisc	SDISC Temp	42.52	C	56.1	sec	OK
EXB at EX3	sdise	SDISE Temp	36.69	C	56.1	sec	OK

EXB at EX3	pcf8591	1.5 VDC	1.51	V	37.0	sec	OK
EXB at EX3	pcf8591	3.3 VDC	3.30	V	37.0	sec	OK
EXB at EX3	pcf8591	2.5 VDC	2.51	V	37.0	sec	OK
EXB at EX3	pcf8591	3.3 VDC HK	3.28	V	37.0	sec	OK
CPU at SB3	max1617a	PROC 0 Temp	62.00	C	3.9	sec	OK
CPU at SB3	max1617a	PROC 1 Temp	67.00	C	3.9	sec	OK
CPU at SB3	max1617a	PROC 2 Temp	66.00	C	3.9	sec	OK
CPU at SB3	max1617a	PROC 3 Temp	65.00	C	3.9	sec	OK
CPU at SB3	sdco	SDC0 Temp	74.49	C	3.9	sec	OK
CPU at SB3	ar0	AR0 Temp	60.49	C	3.9	sec	OK
CPU at SB3	dx0	DX0 Temp	65.16	C	3.9	sec	OK
CPU at SB3	dx1	DX1 Temp	55.83	C	3.9	sec	OK
CPU at SB3	dx2	DX2 Temp	61.82	C	3.9	sec	OK
CPU at SB3	dx3	DX3 Temp	55.83	C	3.9	sec	OK
CPU at SB3	sbbc0	SBBC0 Temp	59.83	C	3.9	sec	OK
CPU at SB3	sbbc1	SBBC1 Temp	56.49	C	3.9	sec	OK
CPU at SB3	pcf8591	1.5 VDC	1.51	V	37.6	sec	OK
CPU at SB3	pcf8591	3.3 VDC	3.32	V	37.6	sec	OK
CPU at SB3	pcf8591	Core 0 Volt	1.64	V	37.6	sec	OK
CPU at SB3	pcf8591	Core 1 Volt	1.64	V	37.6	sec	OK
CPU at SB3	pcf8591	Core 2 Volt	1.65	V	37.6	sec	OK
CPU at SB3	pcf8591	Core 3 Volt	1.63	V	37.6	sec	OK
HPCI at IO3	pcf8591	PS0 Temp	43.26	C	56.5	sec	OK
HPCI at IO3	pcf8591	PS1 Temp	38.42	C	56.5	sec	OK
HPCI at IO3	sdco	SDC0 Temp	72.49	C	56.5	sec	OK
HPCI at IO3	ar	AR0 Temp	63.82	C	56.5	sec	OK
HPCI at IO3	dx0	DX0 Temp	63.16	C	56.5	sec	OK
HPCI at IO3	dx1	DX1 Temp	61.16	C	56.5	sec	OK
HPCI at IO3	sbbc	SBBC Temp	43.83	C	56.5	sec	OK
HPCI at IO3	max1617a	IOA0 Temp	52.00	C	56.5	sec	OK
HPCI at IO3	max1617a	IOA1 Temp	51.00	C	56.5	sec	OK
HPCI at IO3	pcf8591	1.5 VDC	1.49	V	37.6	sec	OK
HPCI at IO3	pcf8591	3.3 VDC	3.30	V	37.6	sec	OK
HPCI at IO3	pcf8591	5.0 VDC	4.99	V	37.6	sec	OK
HPCI at IO3	pcf8591	+12.0 VDC	12.03	V	37.6	sec	OK
HPCI at IO3	pcf8591	-12.0 VDC	-12.01	V	37.6	sec	OK
HPCI at IO3	pcf8591	3.3 VDC HK	3.28	V	37.6	sec	OK
HPCI at IO3	pcf8591	1.5 CVT0 VDC	3.28	V	37.6	sec	OK
HPCI at IO3	pcf8591	1.5 CVT1 VDC	1.49	V	37.6	sec	OK
HPCI at IO3	pcf8591	3.3 V_PS0	10.54	A	37.7	sec	OK
HPCI at IO3	pcf8591	3.3 V_PS1	10.54	A	37.7	sec	OK
HPCI at IO3	pcf8591	5.0 V_PS0	3.41	A	37.7	sec	OK
HPCI at IO3	pcf8591	5.0 V_PS1	3.41	A	37.7	sec	OK
Schizo0.0	max1617a	Schizo 0 Slot 0	N/A	N/A	N/A		PRESENCE
Schizo1.0	max1617a	Schizo 1 Slot 0	N/A	N/A	N/A		PRESENCE
Schizo0.1	max1617a	Schizo 0 Slot 1	N/A	N/A	N/A		PRESENCE
Schizo1.1	max1617a	Schizo 1 Slot 1	N/A	N/A	N/A		PRESENCE
EXB at EX5	max1617a	AMB Top Temp	35.00	C	48.0	sec	OK
EXB at EX5	max1617	AMB Bot Temp	33.00	C	48.0	sec	OK
EXB at EX5	sbbc	SBBC Temp	47.16	C	48.0	sec	OK
EXB at EX5	axq	AXQ Temp	26.84	C	48.0	sec	OK
EXB at EX5	sdim	SDIM Temp	30.59	C	48.0	sec	OK
EXB at EX5	sdisc	SDISC Temp	32.42	C	48.0	sec	OK
EXB at EX5	sdise	SDISE Temp	30.52	C	48.0	sec	OK
EXB at EX5	pcf8591	1.5 VDC	1.51	V	34.3	sec	OK
EXB at EX5	pcf8591	3.3 VDC	3.32	V	34.3	sec	OK
EXB at EX5	pcf8591	2.5 VDC	2.51	V	34.3	sec	OK
EXB at EX5	pcf8591	3.3 VDC HK	3.28	V	34.3	sec	OK
CPU at SB5	max1617a	PROC 0 Temp	69.00	C	7.9	sec	OK
CPU at SB5	max1617a	PROC 1 Temp	73.00	C	7.9	sec	OK
CPU at SB5	max1617a	PROC 2 Temp	75.00	C	7.9	sec	OK
CPU at SB5	max1617a	PROC 3 Temp	72.00	C	7.9	sec	OK
CPU at SB5	sdco	SDC0 Temp	63.16	C	7.9	sec	OK
CPU at SB5	ar0	AR0 Temp	60.49	C	7.9	sec	OK
CPU at SB5	dx0	DX0 Temp	59.16	C	7.9	sec	OK
CPU at SB5	dx1	DX1 Temp	58.49	C	7.9	sec	OK
CPU at SB5	dx2	DX2 Temp	60.49	C	7.9	sec	OK

CPU at SB5	dx3	DX3 Temp	53.16	C	7.9	sec	OK
CPU at SB5	sbbc0	SBBC0 Temp	57.16	C	7.9	sec	OK
CPU at SB5	sbbc1	SBBC1 Temp	59.16	C	7.9	sec	OK
CPU at SB5	pcf8591	1.5 VDC	1.51	V	34.8	sec	OK
CPU at SB5	pcf8591	3.3 VDC	3.32	V	34.8	sec	OK
CPU at SB5	pcf8591	Core 0 Volt	1.64	V	34.8	sec	OK
CPU at SB5	pcf8591	Core 1 Volt	1.66	V	34.8	sec	OK
CPU at SB5	pcf8591	Core 2 Volt	1.63	V	34.8	sec	OK
CPU at SB5	pcf8591	Core 3 Volt	1.64	V	34.8	sec	OK
HPCI+ at IO5	pcf8591	D147#0_0	24.00	C	46.2	sec	OK
HPCI+ at IO5	pcf8591	D147#0_1	25.00	C	46.2	sec	OK
HPCI+ at IO5	pcf8591	D147#0_2	24.00	C	46.2	sec	OK
HPCI+ at IO5	pcf8591	D147#1_0	22.00	C	46.2	sec	OK
HPCI+ at IO5	pcf8591	D147#1_1	23.00	C	46.2	sec	OK
HPCI+ at IO5	pcf8591	D147#1_2	25.00	C	46.2	sec	OK
HPCI+ at IO5	max1617a	XMITS0 Temp	34.00	C	46.2	sec	OK
HPCI+ at IO5	max1617a	XMITS1 Temp	27.00	C	46.2	sec	OK
HPCI+ at IO5	sbbc	SBBC Temp	32.50	C	46.2	sec	OK
HPCI+ at IO5	sdsc	SDC0 Temp	48.49	C	46.2	sec	OK
HPCI+ at IO5	ar	AR0 Temp	47.16	C	46.2	sec	OK
HPCI+ at IO5	dx0	DX0 Temp	44.50	C	46.2	sec	OK
HPCI+ at IO5	dx1	DX1 Temp	39.83	C	46.2	sec	OK
HPCI+ at IO5	pcf8591	1.5 VDC1	1.54	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	2.5 VDC1	2.53	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	3.3 VDC1	3.35	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	5.0 VDC1	5.02	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	+12.0 VDC1	12.36	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	-12.0 VDC1	-12.41	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	3.3 VDC HK1	3.33	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	1.5 VDC1	1.54	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	2.5 VDC1	2.53	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	3.3 VDC1	3.35	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	5.0 VDC1	5.02	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	+12.0 VDC1	12.36	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	-12.0 VDC1	-12.41	V	13.0	sec	OK
HPCI+ at IO5	pcf8591	3.3 VDC HK1	3.61	V	13.0	sec	OK
XMITS0.0	max1617a	XMITS 0 Slot 0	N/A	N/A	N/A		PRESENCE
XMITS1.0	max1617a	XMITS 1 Slot 0	N/A	N/A	N/A		PRESENCE
XMITS0.1	max1617a	XMITS 0 Slot 1	N/A	N/A	N/A		PRESENCE
XMITS1.1	max1617a	XMITS 1 Slot 1	N/A	N/A	N/A		PRESENCE
EXB at EX7	max1617a	AMB Top Temp	34.00	C	37.2	sec	OK
EXB at EX7	max1617	AMB Bot Temp	35.00	C	37.2	sec	OK
EXB at EX7	sbbc	SBBC Temp	44.50	C	37.2	sec	OK
EXB at EX7	axq	AXQ Temp	19.18	C	37.2	sec	OK
EXB at EX7	sdim	SDIM Temp	34.42	C	37.2	sec	OK
EXB at EX7	sdisc	SDISC Temp	40.32	C	37.2	sec	OK
EXB at EX7	sdise	SDISE Temp	34.72	C	37.2	sec	OK
EXB at EX7	pcf8591	1.5 VDC	1.51	V	36.3	sec	OK
EXB at EX7	pcf8591	3.3 VDC	3.30	V	36.3	sec	OK
EXB at EX7	pcf8591	2.5 VDC	2.49	V	36.3	sec	OK
EXB at EX7	pcf8591	3.3 VDC HK	3.28	V	36.3	sec	OK
CPU at SB7	max1617a	PROC 0 Temp	41.00	C	8.1	sec	OK
CPU at SB7	max1617a	PROC 1 Temp	40.00	C	8.1	sec	OK
CPU at SB7	max1617a	PROC 2 Temp	52.00	C	8.1	sec	OK
CPU at SB7	max1617a	PROC 3 Temp	50.00	C	8.1	sec	OK
CPU at SB7	sdsc0	SDC0 Temp	61.82	C	8.1	sec	OK
CPU at SB7	ar0	AR0 Temp	55.16	C	8.1	sec	OK
CPU at SB7	dx0	DX0 Temp	58.49	C	8.1	sec	OK
CPU at SB7	dx1	DX1 Temp	59.83	C	8.1	sec	OK
CPU at SB7	dx2	DX2 Temp	56.49	C	8.1	sec	OK
CPU at SB7	dx3	DX3 Temp	59.83	C	8.1	sec	OK
CPU at SB7	sbbc0	SBBC0 Temp	61.82	C	8.1	sec	OK
CPU at SB7	sbbc1	SBBC1 Temp	54.49	C	8.1	sec	OK
CPU at SB7	pcf8591	1.5 VDC	1.51	V	37.2	sec	OK
CPU at SB7	pcf8591	3.3 VDC	3.32	V	37.2	sec	OK
CPU at SB7	pcf8591	Core 0 Volt	1.63	V	37.2	sec	OK
CPU at SB7	pcf8591	Core 1 Volt	1.62	V	37.2	sec	OK

CPU at SB7	pcf8591	Core 2 Volt	1.62	V	37.2	sec	OK
CPU at SB7	pcf8591	Core 3 Volt	1.62	V	37.2	sec	OK
MCPU at IO7	max1617a	PROC 0 Temp	67.00	C	8.3	sec	OK
MCPU at IO7	max1617a	PROC 1 Temp	71.00	C	8.3	sec	OK
MCPU at IO7	sbbc0	SBBC0 Temp	41.83	C	8.3	sec	OK
MCPU at IO7	sdc0	SDC0 Temp	70.49	C	8.3	sec	OK
MCPU at IO7	ar0	AR0 Temp	63.82	C	8.3	sec	OK
MCPU at IO7	dx0	DX0 Temp	61.82	C	8.3	sec	OK
MCPU at IO7	dx1	DX1 Temp	59.83	C	8.3	sec	OK
MCPU at IO7	dx2	DX2 Temp	53.83	C	8.3	sec	OK
MCPU at IO7	dx3	DX3 Temp	49.83	C	8.3	sec	OK
MCPU at IO7	pcf8591	1.5 VDC	1.48	V	36.7	sec	OK
MCPU at IO7	pcf8591	3.3 VDC	3.28	V	36.7	sec	OK
MCPU at IO7	pcf8591	3.3 VDC HK	3.28	V	36.7	sec	OK
MCPU at IO7	pcf8591	Core 0 Volt	1.63	V	36.7	sec	OK
MCPU at IO7	pcf8591	Core 1 Volt	1.63	V	36.7	sec	OK
WPCI at IO8	max1617a	IOA0 Temp	42.00	C	51.8	sec	OK
WPCI at IO8	dx0	DX0 Temp	61.82	C	51.8	sec	OK
WPCI at IO8	dx1	DX1 Temp	55.83	C	51.8	sec	OK
WPCI at IO8	sdc	SDC Temp	62.49	C	51.8	sec	OK
WPCI at IO8	sbbc	SBBC Temp	38.50	C	51.8	sec	OK
WPCI at IO8	ar	AR Temp	65.16	C	51.8	sec	OK
WPCI at IO8	wci	WCI0 Temp	21.11	C	51.8	sec	OK
WPCI at IO8	wci	WCI1 Temp	21.11	C	51.8	sec	OK
WPCI at IO8	pcf8591	+12 VDC	12.03	V	12.6	sec	OK
WPCI at IO8	pcf8591	-12 VDC	-11.92	V	12.6	sec	OK
WPCI at IO8	pcf8591	3.3 HK	3.26	V	12.6	sec	OK
WPCI at IO8	pcf8591	3.3 VDC	3.30	V	12.6	sec	OK
WPCI at IO8	pcf8591	1.5 VDC	1.49	V	12.6	sec	OK
WPCI at IO8	pcf8591	2.5 VDC	2.49	V	12.6	sec	OK
WPCI at IO8	pcf8591	5.0 VDC	5.02	V	12.6	sec	OK
WPCI at IO8	pcf8591	1.5 VDC PAR0	1.52	V	12.6	sec	OK
WPCI at IO8	pcf8591	1.5 VDC PAR1	1.51	V	12.6	sec	OK
WPCI at IO8	pcf8591	3.3 VDC PAR0	3.28	V	12.6	sec	OK
WPCI at IO8	pcf8591	3.3 VDC PAR1	3.28	V	12.6	sec	OK
Schizo0.0	max1617a	Schizo 0 Slot 0	N/A	N/A	N/A	PRESENCE	
Schizo0.1	max1617a	Schizo 0 Slot 1	N/A	N/A	N/A	PRESENCE	
EXB at EX10	max1617a	AMB Top Temp	31.00	C	49.0	sec	OK
EXB at EX10	max1617	AMB Bot Temp	28.00	C	49.0	sec	OK
EXB at EX10	sbbc	SBBC Temp	51.83	C	49.0	sec	OK
EXB at EX10	axq	AXQ Temp	26.87	C	49.0	sec	OK
EXB at EX10	sdim	SDIM Temp	32.56	C	49.0	sec	OK
EXB at EX10	sdisc	SDISC Temp	40.21	C	49.0	sec	OK
EXB at EX10	sdise	SDISE Temp	30.64	C	49.0	sec	OK
EXB at EX10	pcf8591	1.5 VDC	1.51	V	36.3	sec	OK
EXB at EX10	pcf8591	3.3 VDC	3.30	V	36.3	sec	OK
EXB at EX10	pcf8591	2.5 VDC	2.51	V	36.3	sec	OK
EXB at EX10	pcf8591	3.3 VDC HK	3.30	V	36.3	sec	OK
CPU at SB10	max1617a	PROC 0 Temp	37.00	C	6.0	sec	OK
CPU at SB10	max1617a	PROC 1 Temp	40.00	C	6.0	sec	OK
CPU at SB10	max1617a	PROC 2 Temp	40.00	C	6.0	sec	OK
CPU at SB10	max1617a	PROC 3 Temp	38.00	C	6.0	sec	OK
CPU at SB10	sdc0	SDC0 Temp	61.16	C	6.0	sec	OK
CPU at SB10	ar0	AR0 Temp	61.16	C	6.0	sec	OK
CPU at SB10	dx0	DX0 Temp	55.16	C	6.0	sec	OK
CPU at SB10	dx1	DX1 Temp	56.49	C	6.0	sec	OK
CPU at SB10	dx2	DX2 Temp	55.83	C	6.0	sec	OK
CPU at SB10	dx3	DX3 Temp	51.16	C	6.0	sec	OK
CPU at SB10	sbbc0	SBBC0 Temp	53.16	C	6.0	sec	OK
CPU at SB10	sbbc1	SBBC1 Temp	55.16	C	6.0	sec	OK
CPU at SB10	pcf8591	1.5 VDC	1.51	V	36.8	sec	OK
CPU at SB10	pcf8591	3.3 VDC	3.30	V	36.8	sec	OK
CPU at SB10	pcf8591	Core 0 Volt	1.62	V	36.8	sec	OK
CPU at SB10	pcf8591	Core 1 Volt	1.62	V	36.8	sec	OK
CPU at SB10	pcf8591	Core 2 Volt	1.61	V	36.8	sec	OK
CPU at SB10	pcf8591	Core 3 Volt	1.62	V	36.8	sec	OK
HPCI at IO10	pcf8591	PS0 Temp	41.65	C	49.4	sec	OK

HPCI at IO10	pcf8591	PS1 Temp	28.74	C	49.4	sec	OK
HPCI at IO10	sdc	SDC0 Temp	69.16	C	49.4	sec	OK
HPCI at IO10	ar	AR0 Temp	61.82	C	49.4	sec	OK
HPCI at IO10	dx0	DX0 Temp	58.49	C	49.4	sec	OK
HPCI at IO10	dx1	DX1 Temp	47.16	C	49.4	sec	OK
HPCI at IO10	sbbc	SBBC Temp	35.16	C	49.4	sec	OK
HPCI at IO10	max1617a	IOA0 Temp	51.00	C	49.4	sec	OK
HPCI at IO10	max1617a	IOA1 Temp	47.00	C	49.4	sec	OK
HPCI at IO10	pcf8591	1.5 VDC	1.49	V	36.8	sec	OK
HPCI at IO10	pcf8591	3.3 VDC	3.28	V	36.8	sec	OK
HPCI at IO10	pcf8591	5.0 VDC	5.02	V	36.8	sec	OK
HPCI at IO10	pcf8591	+12.0 VDC	12.03	V	36.8	sec	OK
HPCI at IO10	pcf8591	-12.0 VDC	-12.01	V	36.8	sec	OK
HPCI at IO10	pcf8591	3.3 VDC HK	3.28	V	36.8	sec	OK
HPCI at IO10	pcf8591	1.5 CVT0 VDC	3.28	V	36.8	sec	OK
HPCI at IO10	pcf8591	1.5 CVT1 VDC	1.23	V	36.8	sec	OK
HPCI at IO10	pcf8591	3.3 V_PS0	10.40	A	36.9	sec	OK
HPCI at IO10	pcf8591	3.3 V_PS1	10.40	A	36.9	sec	OK
HPCI at IO10	pcf8591	5.0 V_PS0	3.54	A	36.9	sec	OK
HPCI at IO10	pcf8591	5.0 V_PS1	3.54	A	36.9	sec	OK
Schizo0.0	max1617a	Schizo 0 Slot 0	N/A	N/A	N/A		PRESENCE
Schizo1.0	max1617a	Schizo 1 Slot 0	N/A	N/A	N/A		PRESENCE
Schizo0.1	max1617a	Schizo 0 Slot 1	N/A	N/A	N/A		PRESENCE
Schizo1.1	max1617a	Schizo 1 Slot 1	N/A	N/A	N/A		PRESENCE
EXB at EX12	max1617a	AMB Top Temp	28.00	C	61.1	sec	OK
EXB at EX12	max1617	AMB Bot Temp	26.00	C	61.1	sec	OK
EXB at EX12	sbbc	SBBC Temp	55.16	C	61.1	sec	OK
EXB at EX12	axq	AXQ Temp	-4.33	C	61.1	sec	OK
EXB at EX12	sdim	SDIM Temp	21.09	C	61.1	sec	OK
EXB at EX12	sdisc	SDISC Temp	50.86	C	61.1	sec	OK
EXB at EX12	sdise	SDISE Temp	40.83	C	61.1	sec	OK
EXB at EX12	pcf8591	1.5 VDC	1.50	V	36.9	sec	OK
EXB at EX12	pcf8591	3.3 VDC	3.28	V	36.9	sec	OK
EXB at EX12	pcf8591	2.5 VDC	2.51	V	36.9	sec	OK
EXB at EX12	pcf8591	3.3 VDC HK	3.26	V	36.9	sec	OK
CPU at SB12	max1617a	PROC 0 Temp	60.00	C	6.8	sec	OK
CPU at SB12	max1617a	PROC 1 Temp	62.00	C	6.8	sec	OK
CPU at SB12	max1617a	PROC 2 Temp	62.00	C	6.8	sec	OK
CPU at SB12	max1617a	PROC 3 Temp	62.00	C	6.8	sec	OK
CPU at SB12	sdc0	SDC0 Temp	59.83	C	6.8	sec	OK
CPU at SB12	ar0	AR0 Temp	53.83	C	6.8	sec	OK
CPU at SB12	dx0	DX0 Temp	52.49	C	6.8	sec	OK
CPU at SB12	dx1	DX1 Temp	49.83	C	6.8	sec	OK
CPU at SB12	dx2	DX2 Temp	51.16	C	6.8	sec	OK
CPU at SB12	dx3	DX3 Temp	42.50	C	6.8	sec	OK
CPU at SB12	sbbc0	SBBC0 Temp	44.50	C	6.8	sec	OK
CPU at SB12	sbbc1	SBBC1 Temp	61.82	C	6.8	sec	OK
CPU at SB12	pcf8591	1.5 VDC	1.51	V	37.2	sec	OK
CPU at SB12	pcf8591	3.3 VDC	3.34	V	37.2	sec	OK
CPU at SB12	pcf8591	Core 0 Volt	1.65	V	37.2	sec	OK
CPU at SB12	pcf8591	Core 1 Volt	1.65	V	37.2	sec	OK
CPU at SB12	pcf8591	Core 2 Volt	1.63	V	37.2	sec	OK
CPU at SB12	pcf8591	Core 3 Volt	1.64	V	37.2	sec	OK
HPCI at IO12							OFF
EXB at EX16	max1617a	AMB Top Temp	32.00	C	38.0	sec	OK
EXB at EX16	max1617	AMB Bot Temp	32.00	C	38.0	sec	OK
EXB at EX16	sbbc	SBBC Temp	42.50	C	38.0	sec	OK
EXB at EX16	axq	AXQ Temp	13.40	C	38.0	sec	OK
EXB at EX16	sdim	SDIM Temp	34.72	C	38.0	sec	OK
EXB at EX16	sdisc	SDISC Temp	40.54	C	38.0	sec	OK
EXB at EX16	sdise	SDISE Temp	36.65	C	38.0	sec	OK
EXB at EX16	pcf8591	1.5 VDC	1.51	V	36.9	sec	OK
EXB at EX16	pcf8591	3.3 VDC	3.30	V	36.9	sec	OK
EXB at EX16	pcf8591	2.5 VDC	2.51	V	36.9	sec	OK
EXB at EX16	pcf8591	3.3 VDC HK	3.30	V	36.9	sec	OK
CPU at SB16	max1617a	PROC 0 Temp	39.00	C	7.1	sec	OK
CPU at SB16	max1617a	PROC 1 Temp	38.00	C	7.1	sec	OK

CPU at SB16	max1617a	PROC 2 Temp	43.00	C	7.1	sec	OK
CPU at SB16	max1617a	PROC 3 Temp	44.00	C	7.1	sec	OK
CPU at SB16	sdco	SDCO Temp	61.16	C	7.1	sec	OK
CPU at SB16	ar0	AR0 Temp	53.83	C	7.1	sec	OK
CPU at SB16	dx0	DX0 Temp	53.83	C	7.1	sec	OK
CPU at SB16	dx1	DX1 Temp	53.16	C	7.1	sec	OK
CPU at SB16	dx2	DX2 Temp	59.16	C	7.1	sec	OK
CPU at SB16	dx3	DX3 Temp	51.16	C	7.1	sec	OK
CPU at SB16	sbbc0	SBBC0 Temp	53.16	C	7.1	sec	OK
CPU at SB16	sbbc1	SBBC1 Temp	57.83	C	7.1	sec	OK
CPU at SB16	pcf8591	1.5 VDC	1.51	V	37.3	sec	OK
CPU at SB16	pcf8591	3.3 VDC	3.30	V	37.3	sec	OK
CPU at SB16	pcf8591	Core 0 Volt	1.62	V	37.3	sec	OK
CPU at SB16	pcf8591	Core 1 Volt	1.63	V	37.3	sec	OK
CPU at SB16	pcf8591	Core 2 Volt	1.61	V	37.3	sec	OK
CPU at SB16	pcf8591	Core 3 Volt	1.62	V	37.3	sec	OK
MCPU at IO16	max1617a	PROC 0 Temp	36.00	C	7.2	sec	OK
MCPU at IO16	max1617a	PROC 1 Temp	36.00	C	7.2	sec	OK
MCPU at IO16	sbbc0	SBBC0 Temp	33.83	C	7.2	sec	OK
MCPU at IO16	sdco	SDCO Temp	60.49	C	7.2	sec	OK
MCPU at IO16	ar0	AR0 Temp	55.83	C	7.2	sec	OK
MCPU at IO16	dx0	DX0 Temp	50.49	C	7.2	sec	OK
MCPU at IO16	dx1	DX1 Temp	53.83	C	7.2	sec	OK
MCPU at IO16	dx2	DX2 Temp	50.49	C	7.2	sec	OK
MCPU at IO16	dx3	DX3 Temp	43.83	C	7.2	sec	OK
MCPU at IO16	pcf8591	1.5 VDC	1.49	V	37.3	sec	OK
MCPU at IO16	pcf8591	3.3 VDC	3.30	V	37.3	sec	OK
MCPU at IO16	pcf8591	3.3 VDC HK	3.28	V	37.3	sec	OK
MCPU at IO16	pcf8591	Core 0 Volt	1.61	V	37.3	sec	OK
MCPU at IO16	pcf8591	Core 1 Volt	1.61	V	37.3	sec	OK

FANTRAY	POWER	SPEED	FAN0	FAN1	FAN2	FAN3	FAN4	FAN5	FAN6
FT0	ON	HIGH	OK						
FT1	ON	HIGH	OK						
FT2	ON	HIGH	OK						
FT3	ON	HIGH	OK						
FT4	ON	HIGH	OK						
FT6	ON	HIGH	OK						
FT7	ON	HIGH	OK						

POWER	UNIT	AC0	AC1	DC0	DC1	FAN0	FAN1
PS0	FAIL	FAIL	FAIL	ON	ON	OK	OK
PS1	FAIL	OK	OK	ON	ON	OK	OK
PS2	OK	OK	OK	ON	ON	OK	OK
PS4	OK	OK	OK	ON	ON	OK	OK
PS5	OK	OK	OK	ON	ON	OK	OK

POWER	VALUE	UNIT	STATUS
PS0			
Current0	0.39	A	N/A
Current1	0.39	A	N/A
48VDC	0.39	V	N/A
PS1			
Current0	8.36	A	N/A
Current1	5.97	A	N/A
48VDC	48.60	V	N/A
PS2			
Current0	8.36	A	N/A
Current1	6.77	A	N/A
48VDC	48.80	V	N/A
PS4			
Current0	7.57	A	N/A
Current1	7.17	A	N/A
48VDC	50.00	V	N/A

```

PS5
Current0      6.77      A      N/A
Current1      7.17      A      N/A
48VDC         49.40     V      N/A

```

EXAMPLE 2 Reporting Temperature on Domain A

This example assumes that Domain A contains MCPUs at IO7 and IO16.

```

sc0:sms-user:> showenvironment -p temps -d a
LOCATION      DEVICE      SENSOR      VALUE      UNIT      AGE      STATUS
-----
MCPU at IO7 max1617a    PROC 1 Temp  71.00      C        8.0     sec OK
...
MCPU at IO16 max1617a    DX0 Temp    50.49      C        8.0     sec OK
...

```

EXIT STATUS

The following exit values are returned:

- 0 Successful completion.
- 1 An invalid domain used.
- 2 An invalid command-line option used.
- 3 Invalid permission.
- 4 An internal error occurred.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag(1M)



NAME	showfailover - display system controller (SC) failover status or role
SYNOPSIS	showfailover [-r] [-v] showfailover -h
DESCRIPTION	<p>showfailover(1M) enables you to monitor the state of the SC failover mechanism. This command displays the current status of the failover mechanisms. If you do not specify a -r option, then the following information is displayed:</p> <pre>SC Failover Status: state</pre> <p>The failover mechanism can be in one of four states: ACTIVATING, ACTIVE, DISABLED, or FAILED. See the EXTENDED DESCRIPTION section.</p>
OPTIONS	<p>The following options are supported:</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-r Displays the SC's role as either MAIN, SPARE, or UNKNOWN.</p> <p>-v Verbose. Displays all available command information.</p>
EXTENDED DESCRIPTION	<p>The failover mechanism states are as follows:</p> <p>ACTIVATING Indicates that the failover mechanism is preparing to transition to the ACTIVE state. Failover becomes active when all tests have passed and files have been synchronized.</p> <p>ACTIVE Indicates that the failover mechanism is enabled and is functioning normally.</p> <p>DISABLED Indicates that the failover mechanism has been disabled due to a failover or an operator request (for example, <code>setfailover off</code>).</p>

FAILED Indicates that the failover mechanism has detected a failure that prevents a failover.

In addition, if the external network has been configured, `showfailover` displays the state of each of the external network interface links monitored by the failover processes. The display format is as follows:

external community name: [UP | DOWN]

A failure string is returned, describing the failure condition. Each failure string has a code associated with it. The codes and associated failure strings are defined in the following table.

String	Explanation
None	No failure.
S-SC EXT NET	The spare SC external network interface has failed.
S-SC CONSOLE BUS	A fault has been detected on the spare SC's console bus path.
S-SC LOC CLK	The spare SC's local clock has failed.
S-SC DISK FULL	The spare SC's system is full.
S-SC IS DOWN	The spare SC is down and/or unresponsive. If this message results from the I2 network/HASRAMs being down then the spare SC could still be running. Login to the spare SC to verify.
S-SC MEM EXHAUSTED	The spare SC's memory/swap space has been exhausted.
S-SC SMS DAEMON	At least one SMS daemon could not be started/restarted on the spare SC.
S-SC INCOMPATIBLE SMS VERSION	The spare SC is running a different version of SMS software. Both SCs must be running the same version.
I2 NETWORK/HASRAMS DOWN	Both interfaces for communication between the SCs are down. The main cannot tell what version of SMS is running on the spare nor what its state is. It declares the spare SC down and logs a message to that effect. Dependent services, including file propagation, are unavailable.

**Group Privileges
Required**

You must have platform administrator, platform operator, or platform service privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Displaying a Failover Status That Indicates That Everything is OK

```
sc0:sms-user:> showfailover
SC Failover Status: ACTIVE
C1: UP
```

EXAMPLE 2 Displaying a Failover Status That Indicates That the Spare SC System is Full

```
sc0:sms-user:> showfailover
SC Failover Status: FAILED
S-SC DISK FULL
C1: UP
```

EXAMPLE 3 Displaying the SC Role

```
sc0:sms-user:> showfailover -r
SPARE
```

EXIT STATUS

The following exit values are returned:

```
0           Successful completion.
>0         An error occurred.
```

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes:

Attribute Types	Attribute Values
Availability	SUNWSMSop
Interface Stability	Evolving
Command Output	Unstable

SEE ALSO

setfailover(1M)

NAME	showkeyswitch - display the position of the virtual keyswitch
SYNOPSIS	showkeyswitch -d <i>domain_indicator</i> [-v] showkeyswitch -h
DESCRIPTION	showkeyswitch(1M) displays the position of the virtual keyswitch of the specified domain. The state of each virtual keyswitch is maintained between power cycles of the system controller (SC) or physical power cycling of the power supplies by the pcd(1M).
OPTIONS	The following options are supported: -d <i>domain_indicator</i> Specifies the domain using one of the following: <i>domain_id</i> -ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M). -h Help. Displays usage descriptions. Note – Use alone. Any option specified in addition to -h is ignored. -v Verbose. Displays all available command information.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have platform administrator, platform operator, platform service, domain administrator, or configurator privileges for the specified domain to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Displaying the Keyswitch Status for Domain A <pre>sc0:sms-user:> showkeyswitch -d A Virtual keyswitch position: ON</pre>
EXIT STATUS	The following exit values are returned: 0 Successful completion. >0 An error occurred.

ATTRIBUTES

See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag (1M), **setkeyswitch** (1M), **pcd** (1M)

NAME	showlogs - display message log files								
SYNOPSIS	showlogs [-F] [-f <i>filename</i>] [-d <i>domain_indicator</i>] [-p <i>log_type</i>] [-v] showlogs -h								
DESCRIPTION	<code>showlogs(1M)</code> displays platform or domain log files. The default is the platform message log. You must have platform group privileges to run the default; otherwise you receive an error message. Depending on your privileges, you can display the message logs, console logs, or <code>syslog</code> for the platform or a specified domain.								
OPTIONS	The following options are supported: <table border="0"> <tr> <td style="vertical-align: top;">-F</td> <td>Displays only lines that have been appended to the log file since the <code>showlogs</code> command was executed. Similar to the <code>'tail -f'</code> command. Output continues until interrupted by <code>CTRL-C</code>.</td> </tr> <tr> <td style="vertical-align: top;">-d <i>domain_indicator</i></td> <td>Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using <code>addtag(1M)</code>.</td> </tr> <tr> <td style="vertical-align: top;">-f <i>filename</i></td> <td>Places the output of the <code>showlogs</code> command into a specified file.</td> </tr> <tr> <td style="vertical-align: top;">-h</td> <td>Help. Displays usage descriptions.</td> </tr> </table> <p>Note – Use alone. Any option specified in addition to <code>-h</code> is ignored.</p>	-F	Displays only lines that have been appended to the log file since the <code>showlogs</code> command was executed. Similar to the <code>'tail -f'</code> command. Output continues until interrupted by <code>CTRL-C</code> .	-d <i>domain_indicator</i>	Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using <code>addtag(1M)</code> .	-f <i>filename</i>	Places the output of the <code>showlogs</code> command into a specified file.	-h	Help. Displays usage descriptions.
-F	Displays only lines that have been appended to the log file since the <code>showlogs</code> command was executed. Similar to the <code>'tail -f'</code> command. Output continues until interrupted by <code>CTRL-C</code> .								
-d <i>domain_indicator</i>	Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using <code>addtag(1M)</code> .								
-f <i>filename</i>	Places the output of the <code>showlogs</code> command into a specified file.								
-h	Help. Displays usage descriptions.								

<code>-p log_type</code>	Specifies display of the platform message log (m) or domain console log (c) or domain syslog (s).
m	Displaying the platform message log requires platform group privileges. This is the <code>showlogs</code> default.
c	Displaying the domain console log requires the <code>-d</code> option and domain privileges for that domain.
s	Displaying the domain syslog requires domain privileges for that domain. Syslogs forwarded to the system controller (SC) from nondomain systems are stored in <code>/var/opt/SUNWSMS/adm/anonymous</code> .
<code>-v</code>	Verbose. Displays all available command information.

EXTENDED DESCRIPTION

Group Privileges Required

If you have platform administrator, operator, or service privileges, you can display the platform messages log file.

If you have domain administrator/configurator privileges, you can display only those log files for domains for which you have privileges.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Displaying Platform Message Log to Standard Out

```
sc0:sms-user:> showlogs
Aug 24 14:30:53 2000 xc8-sc0 hwad[104609]: [0 5751139758216 ERR SCCSR.cc
1347] getCrt - Client: 104621.14 has locked - 167
Aug 24 14:30:53 2000 xc8-sc0 hwad[104609]: [0 5751170721148 ERR SCCSR.cc
1362] getCrt - Client: 104621.14 about to unlock - 167.....
```

EXAMPLE 2 Displaying Domain A Message Log to Standard Out

```
sc0:sms-user:> showlogs -d A
Aug 15 14:28:05 2000 xc8-sc0 dsmd[106850]-A(): [0 8500962546702 INFO
Observers.cc 125] DOMAIN_UP A event has been sent to SYMON, rc = 0.
Aug 15 14:28:05 2000 xc8-sc0 dsmd[106850]-A(): [0 8500963756755 INFO
DomainMon.cc 183] Start monitoring domain A every 5 second....
```

EXAMPLE 3 Displaying Newly Appended Lines to Domain A Message Log to Standard Out

```
sc0:sms-user:> showlogs -d A -F
Aug 25 14:28:05 2000 xc8-sc0 dsmd[106850]-A(): [0 8500960648900 INFO
Observers.c c 193] DOMAIN_UP A event has been sent to DXS, rc = 0....
```

EXAMPLE 4 Displaying Domain A Console Log to Standard Out

```
sc0:sms-user:> showlogs -d A -p c
** Domain Server Shutting Down - disconnecting
** Domain Server Shutting Down - disconnecting
Sun Fire 15K system, using IOSRAM based Console OpenBoot 4.0, 2048 MB
memory installed, Serial #10000000. Ethernet address 8:0:20:b8:2d:b1,
Host ID: 80a3e446.
```

EXAMPLE 5 Display Domain sms2 Syslog to Standard Out

```
sc0:sms-user:> showlogs -d sms2 -p s
Sep  7 13:51:49 sms2 agent[6629]: [ID 240586 daemon.alert] syslog
Sep  7 13:51:49 agent {received software termination signal}
Sep  7 13:51:49 sms2 agent[6629]: [ID 985882 daemon.alert] syslog
Sep  7 13:51:49 agent *** terminating execution ***
Sep  7 13:51:50 sms2 platform[22481]: [ID 345917 daemon.alert] syslog
Sep  7 13:51:50 platform *** terminating execution ***
Sep  7 14:49:07 sms2 platform[4309]: [ID 745356 daemon.alert] syslog
Sep  7 14:49:07 platform general parsing error
Sep  7 14:49:07 sms2 platform[4309]: [ID 334248 daemon.alert] syslog
Sep  7 14:49:07 platform file://localhost/scmonitor-d.x;flags=ro
Sep  7 14:49:07 sms2 platform[4309]: [ID 449452 daemon.alert] syslog
Sep  7 14:49:07 platform couldn't load file ...
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

FILES

The following files are used:

<code>/var/opt/SUNWSMS/adm/platform/messages</code>	Platform message file
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/messages</code>	Domain message file
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/console</code>	Domain console file
<code>/var/opt/SUNWSMS/adm/<i>domain_id</i>/syslog</code>	Domain syslog file

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

tail(1)

NAME	showobpparams - display OpenBoot PROM bring up parameters for a domain
SYNOPSIS	showobpparams -d <i>domain_indicator</i> [-v] showobpparams -h
DESCRIPTION	showobpparams(1M) enables a domain administrator to display the virtual NVRAM and REBOOT parameters passed to OpenBoot PROM by setkeyswitch(1M). The -d option with <i>domain_id</i> or <i>domain_tag</i> is required.
OPTIONS	The following options are supported: -d <i>domain_indicator</i> Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M). -h Help. Displays usage descriptions. Note - Use alone. Any option specified in addition to -h is ignored. -v Verbose. Displays all available command information.
EXTENDED DESCRIPTION	
Group Privileges Required	You must have domain administrator or domain configurator privileges for the specified domain to run this command. Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.
EXAMPLES	EXAMPLE 1 Displaying OpenBoot PROM Parameters for Domain A sc0:sms-user:> showobpparams -d a auto-boot?=false diag-switch?=true fcode-debug?=false use-nvramrc?=false security-mode=none
EXIT STATUS	The following exit values are returned: 0 Successful completion. >0 An error occurred.

ATTRIBUTES

See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addtag (1M), **setkeyswitch** (1M), **setobpparams** (1M)

NAME	showplatform - display the board available component list, the domain state for each domain, and Capacity on Demand (COD) information.
SYNOPSIS	showplatform [-d <i>domain_indicator</i>] [-p <i>report</i>] [-v] showplatform -h
DESCRIPTION	showplatform(1M) displays the available component list, domain state, and Ethernet address for domains. COD information includes the headroom amount, number of installed COD right-to-use (RTU) licenses, and the number of COD RTU licenses reserved for domains. If a <i>domain_id</i> or <i>domain_tag</i> is specified, only the information for that domain is displayed. If <i>domain_indicator</i> and -p option are not specified, the available component list, domain states, Ethernet addresses, and COD information for all domains for which you have privileges are displayed.
OPTIONS	The following options are supported:
-d <i>domain_indicator</i>	Specifies the domain using one of the following: <i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive. <i>domain_tag</i> - Name assigned to a domain using addtag(1M).
-h	Help. Displays usage descriptions. Note - Use alone. Any option specified in addition to -h is ignored.
-p <i>report</i>	Display specific reports. Valid reports are: domains List output is grouped by domain state. available List output is grouped by domain available component list. ethernet List output is grouped by domain Ethernet addresses. cod Capacity on Demand information is displayed.
-v	Verbose. Displays all available command information.

**EXTENDED
DESCRIPTION**

The domain status is one of the following:

Unknown	The domain state could not be determined, or for Ethernet addresses, it indicates that the domain <code>idprom</code> image file does not exist. You need to contact your Sun service representative.
Powered Off	The domain is powered off.
Keyswitch Standby	The keyswitch for the domain is in STANDBY position.
Running Domain POST	The domain power-on self-test is running.
Loading OBP	The OpenBoot PROM for the domain is being loaded.
Booting OBP	The OpenBoot PROM for the domain is booting.
Running OBP	The OpenBoot PROM for the domain is running.
In OBP Callback	The domain has been halted and has returned to the OpenBoot PROM.
Loading Solaris	The OpenBoot PROM is loading the Solaris software.
Booting Solaris	The domain is booting the Solaris software.
Domain Exited OBP	The domain OpenBoot PROM has exited.
OBP Failed	The domain OpenBoot PROM has failed.
OBP in sync Callback to OS	The OpenBoot PROM is in sync callback to the Solaris software.
Exited OBP	The OpenBoot PROM has exited.
In OBP Error Reset	The domain is in OpenBoot PROM due to an error reset condition.
Solaris Halted, in OBP	Solaris software is halted and the domain is in OpenBoot PROM.
OBP Debugging	The OpenBoot PROM is being used as a debugger.
Environmental Domain Halt	The domain was shut down due to an environmental emergency.
Booting Solaris Failed	OpenBoot PROM is running, but boot attempt has failed.
Loading Solaris Failed	OpenBoot PROM is running, but loading attempt has failed.

Running Solaris	Solaris software is running on the domain.
Solaris Quiesce In-progress	A Solaris software quiesce is in progress.
Solaris Quiesced	Solaris software has quiesced.
Solaris Resume In-progress	A Solaris software resume is in progress.
Solaris Panic	Solaris software has panicked, and panic flow has started.
Solaris Panic Debug	Solaris software has panicked and is entering debugger mode.
Solaris Panic Continue	Solaris software has exited debugger mode, and panic flow continues.
Solaris Panic Dump	Panic dump has started.
Solaris Halt	Solaris software is halted.
Solaris Panic Exit	Solaris software has exited as a result of a panic.
Environmental Emergency	An environmental emergency has been detected.
Debugging Solaris	Debugging Solaris software; this is not a hung condition.
Solaris Exited	Solaris software has exited.
Domain Down	The domain is down and <code>setkeyswitch</code> is in the ON, DIAG, or SECURE position.
In Recovery	The domain is in the midst of an automatic system recovery.

Group Privileges Required

If you have platform administrator, operator, or service privileges, `showplatform` displays the available component list and board state information on all domains. Otherwise, only information for domains, for which you have domain administrator or configurator privileges, is displayed.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

Note – An UNKNOWN state for an Ethernet address as shown in the following example indicates a missing idprom image file for the domain. Contact your Sun service representative.

EXAMPLE 1 Displaying the Available Component List, Domain State, and COD Information for All Domains on a Sun Fire 15K System

The output shown is what you would see if you had platform privileges.

```
sc0:sms-user:> showplatform

COD:
====
Chassis HostID : 5014936C37048
PROC RTUs installed : 8
PROC Headroom Quantity : 0
PROC RTUs reserved for domain A : 4
PROC RTUs reserved for domain B : 0
PROC RTUs reserved for domain C : 0
PROC RTUs reserved for domain D : 0
PROC RTUs reserved for domain E : 0
PROC RTUs reserved for domain F : 0
PROC RTUs reserved for domain G : 0
PROC RTUs reserved for domain H : 0
PROC RTUs reserved for domain I : 0
PROC RTUs reserved for domain J : 0
PROC RTUs reserved for domain K : 0
PROC RTUs reserved for domain L : 0
PROC RTUs reserved for domain M : 0
PROC RTUs reserved for domain N : 0
PROC RTUs reserved for domain O : 0
PROC RTUs reserved for domain P : 0
PROC RTUs reserved for domain Q : 0
PROC RTUs reserved for domain R : 0

Available Component List for Domains:
=====
Available for domain newA:
    SB0 SB1 SB2 SB7
    IO1 IO3 IO6
Available for domain engB:
    No System boards
    No IO boards
Available for domain domainC:
    No System boards
    IO0 IO1 IO2 IO3 IO4
Available for domain eng1:
    No System boards
    No IO boards
Available for domain E:
    No System boards
    No IO boards
Available for domain domainF:
    No System boards
    No IO boards
Available for domain dmnG:
    No System boards
    No IO boards
Available for domain domain H:
    No System boards
    No IO boards
```

```

Available for domain I:
    No System boards
    No IO boards
Available for domain dmnJ:
    No System boards
    No IO boards
Available for domain K:
    No System boards
    No IO boards
Available for domain L:
    No System boards
    No IO boards
Available for domain M:
    No System boards
    No IO boards
Available for domain N:
    No System boards
    No IO boards
Available for domain O:
    No System boards
    No IO boards
Available for domain P:
    No System boards
    No IO boards
Available for domain Q:
    No System boards
    No IO boards
Available for domain dmnR:
    No System boards
    No IO boards

```

Domain Ethernet Addresses:

```

=====
Domain ID   Domain Tag   Ethernet Address
A           newA        8:0:20:b8:79:e4
B           engB        8:0:20:b4:30:8c
C           domainC     8:0:20:b7:30:b0
D           -          8:0:20:b8:2d:b0
E           engl        8:0:20:f1:b7:0
F           domainF    8:0:20:be:f8:a4
G           dmnG       8:0:20:b8:29:c8
H           -          8:0:20:f3:5f:14
I           -          8:0:20:be:f5:d0
J           dmnJ       UNKNOWN
K           -          8:0:20:f1:ae:88
L           -          8:0:20:b7:5d:30
M           -          8:0:20:f1:b8:8
N           -          8:0:20:f3:5f:74
O           -          8:0:20:f1:b8:8
P           -          8:0:20:b8:58:64
Q           -          8:0:20:f1:b7:ec
R           dmnR       8:0:20:f1:b7:10

```

Domain Configurations:

```

=====
DomainID   Domain Tag   Solaris Nodename   Domain Status
A           newA        -                  Powered Off
B           engB        sun15-b            Keyswitch Standby
C           domainC     sun15-c            Running OBP
D           -          sun15-d            Running Solaris
E           engl        sun15-e            Running Solaris
F           domainF    sun15-f            Running Solaris
G           dmnG       sun15-g            Running Solaris
H           -          sun15-g            Solaris Quiesced
I           -          -                  Powered Off

```

J	dmnJ	-	Powered Off
K	-	sun15-k	Booting Solaris
L	-	-	Powered Off
M	-	-	Powered Off
N	-	sun15-n	Keyswitch Standby
O	-	-	Powered Off
P	-	sun15-p	Running Solaris
Q	-	sun15-q	Running Solaris
R	dmnR	sun15-r	Running Solaris

EXAMPLE 2 Showing the Available Component List and Domain State for Domain engB

```
sc0:sms-user:> showplatform -d engB

COD:
====
PROC RTUs reserved for domain B : 0

Available Component List for Domains:
=====
Available for domain engB:
      SB4 SB5 SB6
      IO4 IO5

Domain Ethernet Addresses:
=====
Domain ID   Domain Tag   Ethernet Address
B           engB        8:0:20:b4:30:8c
```

Domain Configurations:

```
=====

DomainID  Domain Tag  Solaris Nodename  Domain Status
B         engB       sun15-b          Keyswitch Standby
```

EXAMPLE 3 Displaying the Platform for Domain Administrators

The following example shows the domain available component list and state information for all domains for which you have domain administrator or configurator privileges; in this case, domains engB, C, and E.

```
sc0:sms-user:> showplatform

COD:
====
PROC RTUs reserved for domain B : 0
PROC RTUs reserved for domain C : 0
PROC RTUs reserved for domain E : 0

Available Component List for Domains:
=====
Available for domain engB:
      SB1 SB2 SB3 SB4 SB5 SB6
      IO1 IO2 IO3 IO4 IO5 IO6 IO7
Available for domain C:
      SB1 SB2 SB3 SB4 SB5 SB6
      IO1 IO2 IO3 IO4 IO5 IO6 IO7
Available for domain E:
      SB1 SB2 SB3 SB4 SB5 SB6
      IO1 IO2 IO3 IO4 IO5 IO6 IO7

Domain Ethernet Addresses:
=====
Domain ID   Domain Tag   Ethernet Address
B           engB        8:0:20:b4:30:8c
C           domainC     8:0:20:b7:30:b0
E           eng1        8:0:20:f1:b7:0

Domain Configurations:
=====
DomainID   Domain Tag   Solaris Nodename   Domain Status
B          engB        sun15-b           Keyswitch Standby
C          domainC    sun15-c           Running OBP
E          eng1        sun15-e           Running Solaris
```

EXAMPLE 4 Showing the Available Component List for Domain engB

```
sc0:sms-user:> showplatform -d engB -p available

Available Component List for Domains:
=====
Available for domain engB:
      SB4 SB5 SB6
      IO4 IO5
```

EXAMPLE 5 Displaying Domain Status for Domain engB

```
sc0:sms-user:> showplatform -d engB -p domains

Domain Configurations:
=====
DomainID   Domain Tag   Solaris Nodename   Domain Status
B          engB        sun15-b           Keyswitch Standby
```

EXAMPLE 6 Show COD Right-to-Use (RTU) License Reservation for Domain engB

```
sc0:sms-user:> showplatform -d engB -p cod
COD:
====
PROC RTUs reserved for domain B : 0
```

EXAMPLE 7 Displaying All COD Information

The output shown is what you would see if you had platform privileges. If the Chassis HostID value is UNKNOWN, power on the centerplane support boards and then run the command `showplatform -p cod` again to display the Chassis HostID. After you power on the centerplane support boards, allow up to one minute for the Chassis HostID information to display in the `showplatform` output.

```
sc0:sms-user:> showplatform -p cod
COD:
====
Chassis HostID : 5014936C37048
PROC RTUs installed : 8
PROC Headroom Quantity : 0
PROC RTUs reserved for domain A : 4
PROC RTUs reserved for domain B : 0
PROC RTUs reserved for domain C : 0
PROC RTUs reserved for domain D : 0
PROC RTUs reserved for domain E : 0
PROC RTUs reserved for domain F : 0
PROC RTUs reserved for domain G : 0
PROC RTUs reserved for domain H : 0
PROC RTUs reserved for domain I : 0
PROC RTUs reserved for domain J : 0
PROC RTUs reserved for domain K : 0
PROC RTUs reserved for domain L : 0
PROC RTUs reserved for domain M : 0
PROC RTUs reserved for domain N : 0
PROC RTUs reserved for domain O : 0
PROC RTUs reserved for domain P : 0
PROC RTUs reserved for domain Q : 0
PROC RTUs reserved for domain R : 0
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.

- 1 An invalid domain was specified.
- 2 An invalid command-line option was specified.
- 3 An incorrect number of domains was specified.
- 4 The user does not have valid privileges.
- 5 An error occurred communicating with the platform configuration daemon (`pcd(1M)`).
- 6 An error occurred communicating with the hardware access daemon (`hwad(1M)`).
- 7 An error occurred communicating with the task management daemon (`tmd(1M)`).
- 8 An internal error occurred.
- 9 An error occurred communicating with the Capacity on Demand daemon (`codd(1M)`).

ATTRIBUTES

See **attributes** (5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

addcodlicense (1M), **addtag** (1M), **hwad** (1M), **pcd** (1M), **setupplatform** (1M), **tmd** (1M)



NAME	showxirstate - display CPU dump information after sending a reset pulse to the processors
SYNOPSIS	<p>showxirstate -d <i>domain_indicator</i> [-v]</p> <p>showxirstate -f <i>filename</i> [-v]</p> <p>showxirstate -h</p>
DESCRIPTION	<p>showxirstate(1M) displays CPU dump information after sending a reset pulse to the processors. This save-state dump can be used to analyze the cause of abnormal domain behavior. showxirstate creates a list of all active processors in that domain and retrieves the save-state information for each processor.</p> <p>If a <i>domain_indicator</i> or <i>filename</i> is not specified, showxirstate returns an error.</p>
OPTIONS	<p>The following options are supported:</p> <p>-d <i>domain_indicator</i> Specifies the domain using one of the following:</p> <p style="padding-left: 40px;"><i>domain_id</i> - ID for a domain. Valid <i>domain_ids</i> are A-R and are not case sensitive.</p> <p style="padding-left: 40px;"><i>domain_tag</i> - Name assigned to a domain using addtag(1M).</p> <p>-f <i>filename</i> Name of the file containing a previously generated xir_dump. The default is /var/opt/SUNWSMS/adm/<i>domain_id</i>/dump and cannot be changed.</p> <p>-h Help. Displays usage descriptions.</p> <p style="padding-left: 40px;">Note - Use alone. Any option specified in addition to -h is ignored.</p> <p>-v Verbose. Displays all available command information.</p>
EXTENDED DESCRIPTION	
Group Privileges Required	<p>You must have domain administrator privileges on the specified domain to run this command. No special privileges are required to read the xir_dump files.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>

EXAMPLES

EXAMPLE 1 Displaying Dump Information for Domain A With 1 CPU

```

sc0:sms-user:> showxirstate -dA

Location: SB4/P0
XIR Magic XIR Version 00415645 Buglevel 00000000

XIR Save Total Size 0x58495253 bytes

ver      : 00000000.00000000
tba      : 00000000.00000000

pil      : 0x0
y        : 00000000.00000000
afsr     : 00000000.00000000  afar      : 00000000.00000000
pcontext: 00000000.00000000  scontext: 00000000.00000000
dcu      : 00000000.00000000
dcr      : 00000000.00000000
pcr      : 00000000.00000000
gsr      : 00000000.00000000
softint  : 0x0000
pa_watch: 00000000.00000000
va_watch: 00000000.00000000
instbp   : 00000000.00000000
tick:    00000000.00000000  tick_cmpr: 00000000.00000000
stick:   00000000.00000000  stick_cmpr: 00000000.00000000
tl: 0

tt      tstate      tpc      tnpc
0x00   0x000000000000  00000000.00000000  00000000.00000000

Globals:
R Normal      Alternate      Interrupt      MMU
0 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
1 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
2 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
3 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
4 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
5 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
6 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000
7 00000000.00000000  00000000.00000000  00000000.00000000
00000000.00000000

wstate: 0x00
cansave: 0 cleanwin: 0
canrestore: 0 otherwin: 0

Register Windows:
Window 0
R Locals      Ins
0 00000000.00000000  00000000.00000000
1 00000000.00000000  00000000.00000000
2 00000000.00000000  00000000.00000000
3 00000000.00000000  00000000.00000000
4 00000000.00000000  00000000.00000000
5 00000000.00000000  00000000.00000000

```

```

6 00000000.00000000 00000000.00000000
7 00000000.00000000 00000000.00000000

```

Window 1

```

R Locals          Ins
0 00000000.00000000 00000000.00000000
1 00000000.00000000 00000000.00000000
2 00000000.00000000 00000000.00000000
3 00000000.00000000 00000000.00000000
4 00000000.00000000 00000000.00000000
5 00000000.00000000 00000000.00000000
6 00000000.00000000 00000000.00000000
7 00000000.00000000 00000000.00000000

```

Window 2

```

R Locals          Ins
0 00000000.00000000 00000000.00000000
1 00000000.00000000 00000000.00000000
2 00000000.00000000 00000000.00000000
3 00000000.00000000 00000000.00000000
4 00000000.00000000 00000000.00000000
5 00000000.00000000 00000000.00000000
6 00000000.00000000 00000000.00000000
7 00000000.00000000 00000000.00000000

```

Window 3

```

R Locals          Ins
0 00000000.00000000 00000000.00000000
1 00000000.00000000 00000000.00000000
2 00000000.00000000 00000000.00000000
3 00000000.00000000 00000000.00000000
4 00000000.00000000 00000000.00000000
5 00000000.00000000 00000000.00000000
6 00000000.00000000 00000000.00000000
7 00000000.00000000 00000000.00000000

```

Window 4

```

R Locals          Ins
0 00000000.00000000 00000000.00000000
1 00000000.00000000 00000000.00000000
2 00000000.00000000 00000000.00000000
3 00000000.00000000 00000000.00000000
4 00000000.00000000 00000000.00000000
5 00000000.00000000 00000000.00000000
6 00000000.00000000 00000000.00000000
7 00000000.00000000 00000000.00000000

```

Window 5

```

R Locals          Ins
0 00000000.00000000 00000000.00000000
1 00000000.00000000 00000000.00000000
2 00000000.00000000 00000000.00000000
3 00000000.00000000 00000000.00000000
4 00000000.00000000 00000000.00000000
5 00000000.00000000 00000000.00000000
6 00000000.00000000 00000000.00000000
7 00000000.00000000 00000000.00000000

```

Window 6

```

R Locals          Ins
0 00000000.00000000 00000000.00000000

```


NAME	smsbackup - back up the SMS environment
SYNOPSIS	<p>smsbackup <i>directory_name</i></p> <p>smsbackup -h</p>
DESCRIPTION	<p>smsbackup(1M) creates a <code>cpio(1)</code> archive of files that maintain the operational environment of SMS. To create a complete and accurate backup, turn off SMS before running <code>smsbackup</code>. For information about manually starting and stopping SMS refer to the <i>System Management Services (SMS) 1.3 Installation Guide</i>.</p> <p>Whenever changes are made to the SMS environment—for example, by shutting down a domain— you must run <code>smsbackup</code> again to maintain a current backup file for the system controller.</p> <p>The name of the backup file is <code>sms_backup.XX.cpio</code>, where <i>XX</i> represents the active version from which the backup was taken.</p> <p>Restore SMS backup files using the <code>smsrestore(1M)</code> command.</p> <p>If any errors occur, <code>smsbackup</code> writes error messages to <code>/var/sadm/system/logs/smsbackup</code> if <code>/var/sadm/system/logs</code> exists and <code>/var/tmp</code> if it does not exist.</p>
OPTIONS	<p>The following option is supported</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p>
OPERANDS	<p>The following operands are supported:</p> <p><i>directory_name</i> Name of the directory in which the backup file is created. This file can reside in any directory on the system, connected network or tape device to which you have read/write privileges. If no <i>directory_name</i> is specified, a backup file is created in <code>/var/tmp</code>. The <i>directory_name</i> does not require the absolute path name for the file.</p> <p>The <i>directory_name</i> specified must be mounted as a UFS file system. Specifying a TMPFS file system, such as <code>/tmp</code>, causes <code>smsbackup</code> to fail. If you are not certain that your <i>directory_name</i> is mounted as a UFS file system, type:</p> <pre style="margin-left: 40px;">/usr/bin/df -F ufs <i>directory_name</i></pre> <p>A UFS file system returns directory information. Any other type of file system returns a warning.</p>

NAME	<code>smsconfig</code> - configures the SMS environment
SYNOPSIS	<p>smsconfig -m</p> <p>smsconfig -m I1 [<i>domain_id</i> <i>sc</i> <i>netmask</i>]</p> <p>smsconfig -m I2 [<i>sc0</i> <i>sc1</i> <i>netmask</i>]</p> <p>smsconfig -m L</p> <p>smsconfig -g</p> <p>smsconfig -a -u <i>username</i> -G <i>platform_role</i> <i>platform</i></p> <p>smsconfig -r -u <i>username</i> -G <i>platform_role</i> <i>platform</i></p> <p>smsconfig -a -u <i>username</i> -G <i>domain_role</i> <i>domain_id</i></p> <p>smsconfig -r -u <i>username</i> -G <i>domain_role</i> <i>domain_id</i></p> <p>smsconfig -l <i>domain_id</i></p> <p>smsconfig -l <i>platform</i></p> <p>smsconfig -s <i>security_option</i></p> <p>smsconfig -v</p> <p>smsconfig -h</p>
DESCRIPTION	<p><code>smsconfig(1M)</code> configures the SMS environment in a three areas: network management, security, and user group privileges.</p> <p><code>smsconfig</code> configures and modifies host name and IP address settings used by the MAN daemon, <code>mand(1M)</code>. For each network, <code>smsconfig</code> can singularly set one or more <i>interface</i> designations within that network. By default, <code>smsconfig</code> steps through the configuration of both internal networks and the external community network.</p> <p>Note – Once you have configured or changed the configuration of the MAN network you <i>must</i> reboot the system controller (SC) in order for the changes to take effect.</p> <p>To configure an individual network, append the <i>net_id</i> to the command line. Management network <i>net_ids</i> are designated I1, I2, and L. Configure a single <i>interface</i> within an enterprise network by specifying both the desired <i>interface</i> and its <i>net_id</i>. Any changes made to the network configuration on one SC using <code>smsconfig -m</code> must be run on the other SC. Network configurations files are not automatically propagated.</p> <p>For security purposes, SMS disables forwarding, broadcast, and multicast by setting the appropriate <code>ndd</code> utility variables upon startup.</p>

The Sunfire 15K/12K system also enables you to further secure the SC allowing you to use `smsconfig -s ssh` as part of the Security Toolkit SC hardening process. To harden the SC, follow the procedures found in the following Sun BluePrints Online articles available at:

<http://www.sun.com/security/blueprints>

- *Securing Sun Fire 12K and 15K System Controller: Updated for SMS 1.3*
- *Securing Sun Fire 12K and 15K Domains: Updated for SMS 1.3*

`smsconfig` configures the UNIX groups used by SMS to describe user privileges. SMS uses a default set of UNIX groups installed locally on each SC. `smsconfig` enables you to customize those groups using the `-g` option. For more information refer to the *System Management Services (SMS) 1.3 Installation Guide*.

`smsconfig` also adds users to SMS groups and configures domain and platform administrative privileges. `smsconfig` sets access control list (ACL) attributes on SMS directories.

Note – Do *not* manually edit the `/etc/group` SMS file entries to add or remove users. Otherwise user access will be compromised.

OPTIONS

The following options are supported:

- a Adds a user to an SMS group and provides read, write, and execute access for a domain or for the platform directories. You must specify a valid *username*, SMS group, and if applicable, a *domain_id*
- G Indicates an SMS group. No group name is case sensitive.
- g Configures the UNIX groups used by SMS to describe user privileges.
- h Help. Displays usage descriptions.
Note – Use alone. Any option specified in addition to `-h` is ignored.
- l Lists all users with access to the specified SMS domain or platform.
- m Configures all interfaces for all enterprise networks and the external community.
- m I1 Configures all interfaces for enterprise network I1. Network designation is not case sensitive. You can exclude a domain from the I1 network configuration by using the word `NONE` as the MAN *hostname*. This applies to the I1 network only.
- m I2 Configures all interfaces for enterprise network I2. Network designation is not case sensitive.

- `-m L` Configures all interfaces for the external community network. Network designation is not case sensitive.
- `-r` Removes a user from an SMS group and denies read, write, and execute access for a domain or for the platform directories. You must specify a valid *username*, SMS group and if applicable, a *domain_id*.
- `-s security_option` This option is used to configure the SMS software to use the security feature. The feature to configure is specified by *security_option*
- The following are valid values for *security_option*:
- `ssh` Instructs SMS to use `ssh`-based commands in place of the default `rsh`-based commands for communicating with the remote SC. All of the `ssh`-based commands must reside in `/usr/bin`. If they are not found in `/usr/bin`, `smsconfig` exits and logs an error.
- NOTE:** Ensure the Secure Shell is configured properly on both SCs before enabling the SMS software to use it. If `ssh` is not configured, `smsconfig` displays and logs an error then exits. Refer to the `ssh` and `scp` man pages for more information.
- `rsh(1)` is the default remote shell in SMS software. When Secure Shell has not been configured properly, SMS attempts to use the default remote shell. Therefore we strongly recommended that you keep `rsh` enabled until `smsconfig -s ssh` successfully configures the SMS software. Once Secure Shell is configured you can disable `rsh` by hardening the SC. Refer to the Online Blueprints documentation and the security section of the *System Management Services (SMS) 1.3 Installation Guide* for more information.
- `rsh` Reconfigures SMS to use `rsh`-based commands.
- `-u username` Indicates user login name.
- `-v` Displays remote shell configuration.

OPERANDS

The following operands are supported:

<i>domain_id</i>	ID for a domain. Valid <i>domain_ids</i> are A–R and are not case sensitive.
<i>domain_role</i>	Valid <i>domain_roles</i> are: adm rcfg
platform	Specifies the Sun Fire 15K/12K platform and platform-specific directories.
<i>platform_role</i>	Valid <i>platform_roles</i> are: adm oper svc
SC0, SC1	Interface designation for the Sun Fire 15K/12K SC. Interface designations are not case sensitive.
netmask	A 32-bit number that masks or screens out the network part of an IP address in a subnet so that only the host computer part of the address remains visible. Commonly displayed in decimal numbers, for example, 255.255.255.0 is a common netmask in a Class C subnet. netmask is not case sensitive.

EXTENDED DESCRIPTION**Group Privileges Required**

You must have superuser privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Setting Up the MAN Network

You must configure all interfaces in the MAN network. This example steps through all the prompts needed to completely set up all three enterprise networks using IPv4. An IPv6 network example differs slightly.

Caution— The IP addresses shown in the following examples are examples only. Refer to your *Sun Fire 15K/12K System Site Planning Guide* for valid IP addresses for your network. Using invalid network IP addresses could, under certain circumstances, make your system unbootable!

There are no prompts for netmasks, and `/etc/ipnodes` are modified in addition to `/etc/hosts`.

IP addresses on the external network for `failover`, `hme0`, and `eril`, on each SC must be unique. The floating IP address is the same on both SCs.

By default, the `I1` network settings are derived from the base network address entered for that network. You can exclude a domain from the `I1` network configuration by using the word `NONE` as the `MAN hostname`. See EXAMPLE 4. For more information refer to the *System Management Services (SMS) 1.3 Installation Guide*.

Once you have configured the MAN network, you *must* reboot the SC.

```
sc0:# smsconfig -m
The platform name identifies the entire host machine to the SMS software.
The platform name occupies a different name space than domain names
(hostnames of bootable systems).

What is the name of the platform this SMS will service? sun15

Configuring the External Network for Community C1

Do you want to define this Community? [y,n] y
Two network interfaces controllers (NICs) are required for IPMP network
failover.
Enter NICs associated with community C1 [hme0 eril]: [Return]

Enter hostname for hme0 [sun15-sc0-hme0]:[Return]
Enter IP address for sun15-sc0-hme0: 10.1.1.52

Enter hostname for eril [sun15-sc0-eril]:[Return]
Enter IP address for sun15-sc0-eril: 10.1.1.53

The Logical/Floating IP hostname and address will "float" over to
whichever system controller (SC0 or SC1) is acting as the main SC.

Enter Logical/Floating IP hostname for community C1 [sun15-sc-C1]:
[Return]
Enter IP address for sun15-sc-C1: 10.1.1.50
Enter Netmask for community C1: 255.255.255.0

Enter hostname for community C1 failover address [sun15-sc0-C1-
failover]:[Return]
Enter IP address for sun15-sc0-C1-failover: 10.1.1.51

Hostname                               IP Address (platform=sun15)
-----
sun15-sc-C1                             10.1.1.50
sun15-sc0-C1-failover                   10.1.1.51
sun15-sc0-hme0                          10.1.1.52
sun15-sc0-eril                          10.1.1.53

Do you want to:
  1) Accept these network settings.
  2) Edit these network settings.
  3) Delete these network settings and go onto the next community? [y,n] y
```

Configuring the External Network for Community C2

Do you want to define this Community? [y,n] **n**

Configuring I1 Management Network - 'I1' is the Domain to SC MAN.

MAN I1 Network Identification

Enter the IP network number (base address) for the I1 network: **10.2.1.0**

Enter the netmask for the I1 MAN network [255.255.255.224]: **[Return]**

Hostname	IP Address	platform=sun15)
-----	-----	
netmask-il	255.255.255.224	
sun15-sc-il	10.2.1.1	
sun15-a	10.2.1.2	
sun15-b	10.2.1.3	
sun15-c	10.2.1.4	
sun15-d	10.2.1.5	
sun15-e	10.2.1.6	
sun15-f	10.2.1.7	
sun15-g	10.2.1.8	
sun15-h	10.2.1.9	
sun15-i	10.2.1.10	
sun15-j	10.2.1.11	
sun15-k	10.2.1.12	
sun15-l	10.2.1.13	
sun15-m	10.2.1.14	
sun15-n	10.2.1.15	
sun15-o	10.2.1.16	
sun15-p	10.2.1.17	
sun15-q	10.2.1.18	
sun15-r	10.2.1.19	

Do you want to accept these network settings? [y,n] **y**

Configuring I2 Management Network - 'I2' is for SC to SC MAN.

MAN I2 Network Identification

Enter the IP network number (base address) for the I2 network: **10.3.1.0**

Enter the netmask for the I2 MAN network [255.255.255.252]: **[Return]**

Hostname	IP Address(platform=sun15)
-----	-----
netmask-i2	255.255.255.252
sun15-sc0-i2	10.3.1.1
sun15-scl-i2	10.3.1.2

Do you want to accept these settings? [y,n] **y**

Creating /.rhosts to facilitate file propagation ... done.

MAN Network configuration modified!

Changes will take effect on next reboot.

The following changes are about to be applied to the "/etc/hosts" hosts file.

```
-----
ADD: 10.2.1.2    sun15-a #smsconfig-entry#
ADD: 10.2.1.3    sun15-b #smsconfig-entry#
ADD: 10.2.1.4    sun15-c #smsconfig-entry#
ADD: 10.2.1.5    sun15-d #smsconfig-entry#
ADD: 10.2.1.6    sun15-e #smsconfig-entry#
ADD: 10.2.1.7    sun15-f #smsconfig-entry#
ADD: 10.2.1.8    sun15-g #smsconfig-entry#
ADD: 10.2.1.9    sun15-h #smsconfig-entry#
ADD: 10.2.1.10   sun15-i #smsconfig-entry#
ADD: 10.2.1.11   sun15-j #smsconfig-entry#
ADD: 10.2.1.12   sun15-k #smsconfig-entry#
ADD: 10.2.1.13   sun15-l #smsconfig-entry#
```

```

ADD: 10.2.1.14 sun15-m #smsconfig-entry#
ADD: 10.2.1.15 sun15-n #smsconfig-entry#
ADD: 10.2.1.16 sun15-o #smsconfig-entry#
ADD: 10.2.1.17 sun15-p #smsconfig-entry#
ADD: 10.2.1.18 sun15-q #smsconfig-entry#
ADD: 10.2.1.19 sun15-r #smsconfig-entry#
ADD: 10.2.1.1 sun15-sc-il #smsconfig-entry#
ADD: 10.1.1.50 sun15-sc-C1 #smsconfig-entry#
ADD: 10.1.1.51 sun15-sc0-C1-failover #smsconfig-entry#
ADD: 10.1.1.52 sun15-sc0-hme0 #smsconfig-entry#
ADD: 10.1.1.53 sun15-sc0-eril #smsconfig-entry#
ADD: 10.3.1.1 sun15-sc0-i2 #smsconfig-entry#
ADD: 10.3.1.2 sun15-sc1-i2 #smsconfig-entry#
-----
Update the hosts file, "/etc/hosts", with these changes? [y,n] y
Hosts file "/etc/hosts" has been updated.

The following information is about to be applied to the "/etc/netmasks"
file.
-----
ADD network: 10.1.1.50, mask: 255.255.255.0
ADD network: 10.2.1.0, mask: 255.255.255.224
ADD network: 10.3.1.0, mask: 255.255.255.252
-----
Update the netmasks file, "/etc/netmasks", with these changes? [y,n] y
Netmasks file "/etc/netmasks" has been updated.
smsconfig complete. Log file is /var/sadm/system/logs/smsconfig
sc#

```

EXAMPLE 2 Configuring the I2 Network

```

sc0: # smsconfig -m I2
Configuring I2 Management Network - 'I2' is for SC to SC MAN
Which System Controller are you configuring [choose 0 or 1]: 0.
Hostname          IP Address (platform=sun15)
-----
netmask-i2        255.255.255.252
sun15-sc0-i2      10.3.1.1
sun15-scl-i2      10.3.1.2
Do you want to accept these network settings? [y,n] n
MAN I2 Network Identification
Enter the IP network number (base address) for the I2 network: 172.16.0.0
Enter the netmask for the I2 MAN network [ 255.255.255.252 ]: [Return]
Hostname          IP Address(platform=sun15)
-----
netmask-i2        255.255.255.252
sun15-sc0-i2      172.16.0.1
sun15-scl-i2      172.16.0.2
Do you want to accept these network settings? [y,n] y
Creating /.rhosts to facilitate file propagation ... done.

MAN Network configuration modified!
Changes will take effect on the next reboot.
The following changes are about to be applied to the "/etc/hosts" hosts
file.
-----
ADD: 172.16.0.1    sun15-sc0-i2 #smsconfig-entry#
ADD: 172.16.0.2    sun15-scl-i2 #smsconfig-entry#
-----
Update the hosts file, "/etc/hosts". with these changes [y,n] y
Hosts file "/etc/hosts" has been updated.

The following information is about to be applied to the "/etc/netmasks"
file.
-----
ADD network: 172.16.0.0, mask: 255.255.255.252
-----
Update the netmasks file, "/etc/netmasks", with these changes? [y,n] y
Netmasks file "/etc/netmasks" has been updated.

sc#

```

EXAMPLE 3 Configuring Internal Host Name and IP Address, SC to Domain B, on the I1 Network

```

sc0: # smsconfig -m I1 B

Enter the MAN hostname for DB-I1 [ sun15-b ]: domainB-il
I could not automatically determine the IP address of domainB-il.

Please enter the IP address of domainB-il: 10.2.1.20

You should make sure that this host/IP address is set up properly in the
/etc/inet/hosts file or in your local name service system.

Network: I1 (DB-I1) Hostname: domainB-il IP Address: 10.2.1.20

Do you want to accept these settings? [y,n] y

Creating /.rhosts to facilitate file propagation ... done.

MAN Network configuration modified!
Changes will take effect on the next reboot.

The following changes are about to be applied to the "/etc/hosts" hosts
file.
-----
ADD: 10.2.1.20    domainB-il #smsconfig-entry#
-----
Update the hosts file, "/etc/hosts", with these changes? [y,n] y
Hosts file "/etc/hosts" has been updated.

sc#

```

EXAMPLE 4 Excluding Domain D From the I1 Network

By excluding a domain, you will no longer be able to perform DR operations (rcfgadm) from the SC on that domain. You can still perform DR operations (cfgadm) on the domain itself. Refer to the *Sun Fire 15K/12K Dynamic Reconfiguration (DR) User Guide* for more information.

```

sc0: # smsconfig -m I1 D

Enter the MAN hostname for DB-I1 [ sun15-b ]: NONE
Network: I1 (DB-I1)
Hostname: NONE IP Address: None

Do you want to accept these settings? [y,n] y

Creating /.rhosts to facilitate file propagation ... done.

sc#

```

EXAMPLE 5 Configuring Non-Default Groups

In this example all domain administrator and domain reconfiguration groups are left as the default groups.

```
sc0: # smsconfig -g
1) Edit current configuration
2) Restore default groups
3) Quit
```

Select one of the above options: 1

NOTE: In order to configure a new group the group must already exist.

The Platform Administrator group has configuration control, a means to get environmental status, the ability to assign boards to domains, power control and other generic service processor functions.

Enter the name of the Platform Administrator group [platadm]? zeus

The Platform Operator group has a subset of the platform privileges, limited generally to platform power control and platform status.

Enter the name of the Platform Operator group [platoper]? poseidon

The Platform Service group possesses platform service command privileges in addition to limited platform control and platform configuration status privileges

Enter the name of the Platform Service group [platsvc]? kronos

The Domain Administrator group possesses domain control and status, and console access privileges (for the respective domain), but does not possess platform wide control or platform resource allocation privileges.

Enter the name of the Domain A Administrator group [dmnaadm]? [Return]

Enter the name of the Domain B Administrator group [dmnbadm]? [Return]

Enter the name of the Domain C Administrator group [dmncadm]? [Return]

Enter the name of the Domain D Administrator group [dmndadm]? [Return]

Enter the name of the Domain E Administrator group [dmneadm]? [Return]

Enter the name of the Domain F Administrator group [dmnfadm]? [Return]

Enter the name of the Domain G Administrator group [dmngadm]? [Return]

Enter the name of the Domain H Administrator group [dmnhadm]? [Return]

Enter the name of the Domain I Administrator group [dmniadm]? [Return]

Enter the name of the Domain J Administrator group [dmnjadm]? [Return]

Enter the name of the Domain K Administrator group [dmnkadm]? [Return]

Enter the name of the Domain L Administrator group [dmnladm]? [Return]

Enter the name of the Domain M Administrator group [dmnmadm]? [Return]

Enter the name of the Domain N Administrator group [dmnnadm]? [Return]

Enter the name of the Domain O Administrator group [dmnoadm]? [Return]

Enter the name of the Domain P Administrator group [dmnpadm]? [Return]

Enter the name of the Domain Q Administrator group [dmnqadm]? [Return]

Enter the name of the Domain R Administrator group [dmnradm]? [Return]

The Domain Reconfiguration group possesses a subset of the Domain Administration group privileges. This group has no domain control other than board power and reconfiguration (for the respective domain).

Enter the name of the Domain A Reconfiguration group [dmnarcfg]? [Return]

Enter the name of the Domain B Reconfiguration group [dmnbrcfg]? [Return]

Enter the name of the Domain C Reconfiguration group [dmncrcfg]? [Return]

Enter the name of the Domain D Reconfiguration group [dmndrcfg]? [Return]

Enter the name of the Domain E Reconfiguration group [dmnercfg]? [Return]

```

Enter the name of the Domain F Reconfiguration group [dmnfrcfg]? [Return]
Enter the name of the Domain G Reconfiguration group [dmngrcfg]? [Return]
Enter the name of the Domain H Reconfiguration group [dmnhrcfg]? [Return]
Enter the name of the Domain I Reconfiguration group [dmnircfg]? [Return]
Enter the name of the Domain J Reconfiguration group [dmnjrcfg]? [Return]
Enter the name of the Domain K Reconfiguration group [dmnkrcfg]? [Return]
Enter the name of the Domain L Reconfiguration group [dmnlrcfg]? [Return]
Enter the name of the Domain M Reconfiguration group [dmnmrcfg]? [Return]
Enter the name of the Domain N Reconfiguration group [dmnncrcfg]? [Return]
Enter the name of the Domain O Reconfiguration group [dmnorcrg]? [Return]
Enter the name of the Domain P Reconfiguration group [dmnprcfg]? [Return]
Enter the name of the Domain Q Reconfiguration group [dmnqrcfg]? [Return]
Enter the name of the Domain R Reconfiguration group [dmnrrcfg]? [Return]

```

Configuration complete.

Select one of the above options:

- 1) Edit current configuration
- 2) Restore default groups
- 3) Quit

Select one of the above options: 3

sc#

EXAMPLE 6 Configuring SMS to Use Secure Shell

Ensure `ssh` is enabled, otherwise when running this command you will receive an error message and `smsconfig` will exit.

```

sc0: # smsconfig -s ssh
Enabling ssh...
Password/passphrase authentication can be ignored.
System will use ssh
Tue Oct 12 13:21:06 PST 2002
smsconfig complete.

```

EXAMPLE 7 Configuring SMS to Use rsh

```

sc0: # smsconfig -s rsh
System will use rsh
Tue Oct 12 13:25:06 PST 2002
smsconfig complete.

```

EXAMPLE 8 Displaying the Remote Shell

```

sc0: # smsconfig -v
Remote Shell
=====
Remote Shell /usr/bin/rsh
Tue Oct 12 13:27:10 PST 2002
smsconfig complete.

```

EXAMPLE 9 Adding a User to the Domain Administrator Group and Configuring Access to the Domain B Directories

You must specify a valid user name and valid SMS group and domain.

```
sc0: # smsconfig -a -u fdjones -G admn B
fdjones has been added to the dmnBadmn group.
All privileges to domain B have been applied.
```

EXAMPLE 10 Adding a User to the Domain Configurator Group and Configuring Access to the Domain C Directories

You must specify a valid user name and valid SMS group and domain.

```
sc0: # smsconfig -a -u fdjones -G rcfg C
fdjones has been added to the dmnCrcfg group.
All privileges to domain C have been applied.
```

EXAMPLE 11 Configuring Access to the Platform Directories

You must specify a valid user name and valid SMS group and the platform.

```
sc0: # smsconfig -a -u jtd -G svc platform
jtd has been added to the platsvc group.
All privileges to the platform have been applied.
```

EXAMPLE 12 Displaying Users With Access to the Domain C Directories

```
sc0: # smsconfig -l C
fdjones
shea
```

EXAMPLE 13 Displaying Users With Access to the Platform Directories

```
sc0: # smsconfig -l platform
fdjones
jtd
```

EXAMPLE 14 Removing User Access to the Domain C Directories

You must specify a valid username and valid SMS group. Any user who belongs to more than one group with access to a domain, must be removed from all groups before directory access is denied.

```
sc0: # smsconfig -r -u fdjones -G rcfg C
fdjones has been removed from the dmnCrcfg group.
fdjones belongs to the dmnCadmn group
Access to domain C remains unchanged.
```

```
sc0: # smsconfig -r -u fdjones -G admn C
fdjones has been removed from the dmnCadmn group.
All access to domain C is now denied.
```

EXAMPLE 15 Configuring Using an Invalid Group name

You must specify a valid SMS group.

```
sc0: # smsconfig -a -u fdjones -G staff D
ERROR: group staff does not exist
ABORTING.
```

EXAMPLE 16 Mixing Groups and Designations

You must specify group names with the correct area designations. The `adm` group works with either designation.

```
sc0: # smsconfig -a -u fdjones -G rcfg platform
ERROR: group rcfg cannot access the platform
ABORTING.
```

```
sc0: # smsconfig -a -u fdjones -G oper D
ERROR: group oper cannot access a domain
ABORTING.
```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

FILES

The following configuration files are required:

<code>/etc/hostname.scman0</code>	MAN Ethernet interface file
<code>/etc/hostname.scman1</code>	MAN Ethernet interface file
<code>/etc/opt/SUNWSMS/config/MAN.cf</code>	MAN daemon configuration file

Note – `MAN.cf` is an internal SMS system file and should *not* be modified except by authorized Sun Microsystems personnel.

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop
Interface Stability	Evolving

SEE ALSO

mand(1M), **ndd**(1M), **rsh**(1), **scp**(1), **ssh**(1)

NAME	smsconnectsc - accesses a remote SC console
SYNOPSIS	smsconnectsc [-y n] smsconnectsc -h
DESCRIPTION	<p>smsconnectsc creates a remote <code>tip</code> console session from a local SC in order to reach a hung remote SC console.</p> <p>smsconnectsc enables the bit that connects the local SC's port B to the remote SC's RS-232 port A when you are logged in to the local SC. The remote SC is the SC that is hanging. Once the <code>tty</code> connection is enabled, smsconnectsc invokes a <code>tip</code> console session to the remote SC. Using the <code>tip</code> console session, you can do whatever needs to be done to the remote SC.</p> <p>smsconnectsc works in the absence of an external connection to the remote SC. If the remote SC has an active external connection to port A, then smsconnectsc fails and the session usually hangs. To exit, type:</p> <p>~.</p> <p>After you finish, there are several ways to end the session, depending on whether you logged in to the local SC using <code>telnet</code> or <code>rlogin</code>. See the EXTENDED DESCRIPTION section.</p>
OPTIONS	<p>The following options are supported.</p> <p>-h Help. Displays usage descriptions.</p> <p> Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-n Automatically answers “no” to all prompts.</p> <p>-y Automatically answers “yes” to all prompts.</p>

**EXTENDED
DESCRIPTION****Usage**

In the `tip` console window established by `smsconnectsc`, a tilde (~) that appears as the first character of a line is interpreted as an escape signal that directs the `tip` console to perform the following action:

`~.` Disconnect the `tip` session.

If you have established a `telnet` session to the local SC this disconnects the `tip` session and you remain logged in to the local SC.

If you have established an `rlogin` session in to the local SC, this disconnects the `tip` session and *also* disconnects your `rlogin` session.

Note – The tilde does not appear on the display until after you have pressed the period.

`~~.` Disconnect `tip` session.

`~~.` Works only with `rlogin`. If you have established a `telnet` session in to the local SC, you receive the following error message:

```
~.: Command not found
```

If you have established an `rlogin` session in to the local SC, this disconnects the `tip` session and you remain logged in to the local SC.

Note – The first tilde does not appear on the display screen. The second tilde does not appear until after you have pressed the period.

`rlogin` also processes tilde-escape sequences whenever a tilde is displayed at the beginning of a new line. If you need to send tilde sequence at the beginning of a line and you are using `rlogin`, use two tildes (the first escapes the second for `rlogin`). Alternatively, do not enter a tilde at the beginning of a line when running inside of `rlogin`. If you use a `kill -9` command to terminate a console session, the window or terminal in which the `smsconnectsc` command was executed goes into raw mode, and appears hung. To escape this condition, type:

```
sc#: sms-user: > CTRL-j
sc#: sms-user: > stty sane
sc#: sms-user: > CTRL-j
```

**Group Privileges
Required**

You must have platform administrator privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Creating a Remote Connection From the Local SC to the Hung Remote SC

In the following example the local SC is shown as `sc1` and the remote SC is shown as `sc0`. Log in to the local SC as a platform administrator.

```
sc1:sms-user:> smsconnectsc
TTY connection is OFF. About to connect to other SC.
Do you want to continue (yes/no)? y
connected
sc0:sms-user:>
```

EXIT STATUS

The following exit values are returned:

```
0           Successful completion.
>0         An error occurred.
```

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

rlogin(1M), **tip**(1M)

NAME	smsinstall - install the SMS environment
SYNOPSIS	<p>smsinstall <i>directory_name</i></p> <p>smsinstall -p</p> <p>smsinstall -h</p>
DESCRIPTION	<p>smsinstall(1M) installs SMS packages on the main or spare SMS system controllers. Refer to the <i>System Management Services (SMS) 1.3 Installation Guide</i> for instructions on how to install SMS using this command.</p> <p>If you are not running <code>smsinstall</code> from the Product directory you must use the absolute path.</p> <p>If any errors occur, <code>smsinstall</code> writes error messages to <code>/var/sadm/system/logs/smsinstall</code>.</p>
OPTIONS	<p>The following option is supported</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-p Performs post-package add actions only. For use after a Web Start installation.</p>
OPERANDS	<p>The following operands are supported:</p> <p><i>directory_name</i> Name of the directory which contains the SMS packages.</p> <p>If you are installing from the Web, the path to the Product directory, <i>directory_name</i>, is: <i>/download_directory/System_Management_Services_1_3/Product</i> where <i>download_directory</i> is the location where you downloaded the files from the Web.</p> <p>If you are installing from CD-ROM, the path to the Product directory, <i>directory_name</i> is <i>/cdrom/cdrom0/System_Management_Services_1_3/Product</i>.</p>
EXTENDED DESCRIPTION	
Group Privileges Required	<p>You must have superuser privileges to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>

EXAMPLES

EXAMPLE 1 Installing SMS From CDROM or Web

```
sc#:sms-user:> smsinstall download_directory
```

```
Installing SMS packages. Please wait. . .
pkgadd -n -d "/cdrom/cdrom0/System_Management_Services_1.3/Product" -a
/tmp/smsinstall.admin.24501 SUNWSMSr SUNWSMSop SUNWSMSdf SUNWSMSjh
SUNWSMSlp
SUNWSMSmn SUNWSMSob SUNWSMSod SUNWSMSpd SUNWSMSpo SUNWSMSpp SUNWSMSsu
SUNWscdvr.u SUNWufrx.u SUNWufu
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
205 blocks
```

```
Installation of <SUNWSMSr> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
61279 blocks
```

```
Installation of <SUNWSMSop> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
32 blocks
```

```
Installation of <SUNWSMSdf> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
2704 blocks
```

```
Installation of <SUNWSMSjh> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
5097 blocks
```

```
Installation of <SUNWSMSlp> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
1696 blocks
```

```
Installation of <SUNWSMSmn> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
576 blocks
```

```
Installation of <SUNWSMSob> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
1025 blocks
```

```
Installation of <SUNWSMSod> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
1025 blocks
```

```
Installation of <SUNWSMSpd> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
14763 blocks
```

```
Installation of <SUNWSMSpo> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
```

```
Installation of <SUNWSMSpp> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
```

```

Use is subject to license terms.
5 blocks

Installation of <SUNWSMSsu> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
479 blocks

Installation of <SUNWscdvr> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
33 blocks

Reboot client to install driver.
type=ddi_pseudo;name=flashprom uflash\N0
Installation of <SUNWufrx> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
13 blocks

Installation of <SUNWufu> was successful.

Verifying that all SMS packages are installed
.....OK
Checking that all installed SMS packages are correct
pkgchk -n SUNWSMSr SUNWSMSop SUNWSMSdf SUNWSMSjh SUNWSMSlp SUNWSMSmn
SUNWSMSob
SUNWSMSod SUNWSMSpd SUNWSMSpo SUNWSMSpp SUNWSMSsu SUNWscdvr SUNWufrx
SUNWufu
OK

Setting up /etc/init.d/sms run control script for SMS 1.3
New SMS version 1.3 is active

Attempting to restart daemon picld
/etc/init.d/picld stop
/etc/init.d/picld start

smsinstall complete. Log file is /var/sadm/system/logs/smsinstall.

```

EXAMPLE 2 Installing SMS After Web Start

```

sc0:~# sms-user:> smsinstall -p download_directory
Verifying that all SMS packages are installed
.....OK
Checking that all installed SMS packages are correct
pkgchk -n SUNWSMSr SUNWSMSop SUNWSMSdf SUNWSMSjh SUNWSMSlp SUNWSMSmn
SUNWSMSob
SUNWSMSod SUNWSMSpd SUNWSMSpo SUNWSMSpp SUNWSMSsu SUNWscdvr SUNWufrx
SUNWufu
OK
Setting up /etc/init.d/sms run control script for SMS 1.3
New SMS version 1.3 is active
Attempting to restart daemon picld
/etc/init.d/picld stop
/etc/init.d/picld start
smsinstall complete. Log file is /var/sadm/system/logs/smsinstall.

```

EXIT STATUS

The following exit values are returned:

0	Successful completion.
>0	An error occurred.

NAME	smsrestore - restore the SMS environment
SYNOPSIS	<p>smsrestore <i>filename</i></p> <p>smsrestore -h</p>
DESCRIPTION	<p>smsrestore(1M) restores the operational environment of the SMS from a backup file created by smsbackup(1M). Use smsrestore to restore the SMS environment after the SMS software has been installed on a new disk.</p> <p>Turn off failover and stop SMS before running smsrestore; start SMS and turn on failover, if you want, afterward. For information about manually starting and stopping SMS refer to the <i>System Management Services (SMS) 1.3 Installation Guide</i>.</p> <p>If any errors occur, smsrestore writes error messages to /var/sadm/system/logs/smsrestore.</p> <p>Note – If the main SMS environment has changed since the backup file was created— for example, by shutting down a domain— you must run smsbackup(1M) again in order to maintain a current backup file for the system controller.</p>
OPTIONS	<p>The following option is supported.</p> <p>-h Help. Displays usage descriptions.</p> <p>Note – Use alone. Any option specified in addition to -h is ignored.</p>
OPERANDS	<p>The following operands are supported:</p> <p><i>filename</i> Name of the backup file that was created by smsbackup(1M). If the specified file is not in the current directory, the <i>filename</i> must contain the full path name for the file. This file can reside anywhere on the system, connected network, or tape device. If no <i>filename</i> is specified, you receive an error message.</p>
EXTENDED DESCRIPTION	
Group Privileges Required	<p>You must have superuser privileges to run this command.</p> <p>Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the <i>System Management Services (SMS) 1.3 Administrator Guide</i> for more information.</p>
EXAMPLES	<p>EXAMPLE 1 Restoring SMS</p> <pre>sc# smsrestore sms_backup.1.0.cpio</pre>

EXAMPLE 2 Restoring SMS From Tape Device 0

```
sc# smsrestore /dev/rmt/0/sms_backup.1.0.cpio
```

EXIT STATUS

The following exit values are returned:

0 Successful completion.

>0 An error occurred.

FILES

The following file is used by this command:

/var/sadm/system/logs/smsrestore smsrestore log file

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

smsbackup(1M)

NAME	smsupgrade - upgrades the SMS software to the current version
SYNOPSIS	<p>smsupgrade [-b] [-r] <i>directory_name</i></p> <p>smsupgrade -p</p> <p>smsupgrade -h</p>
DESCRIPTION	<p>smsupgrade(1M) upgrades SMS software on the main or spare SMS system controllers. Refer to the <i>System Management Services (SMS) 1.3 Installation Guide</i> for instructions on how to upgrade SMS using this command.</p> <p>If you are not running smsupgrade from the Product directory you must use the absolute path.</p> <p>If any errors occur, smsupgrade writes error messages to /var/sadm/system/logs/smsupgrade.</p>
OPTIONS	<p>The following option is supported</p> <p>-b Neither smsbackup(1M) nor smsrestore(1M) are performed. The default is to run smsbackup to directory /var/tmp before upgrading SMS.</p> <p>-h Help. Displays usage descriptions.</p> <p> Note – Use alone. Any option specified in addition to -h is ignored.</p> <p>-p Performs post-package add actions only; it does not perform smsbackup or smsrestore. For use after a Web Start installation.</p> <p>-r smsrestore(1M) is <i>not</i> performed after the upgrade</p> <p> The default is to run smsrestore from directory /var/tmp after upgrading SMS.</p>

OPERANDS

The following operands are supported:

directory_name Name of the directory which contains the SMS packages.

If you are installing from the Web, the path to the Product directory, *directory_name*, is */download_directory/System_Management_Services_1_3/Product*; where *download_directory* is the location where you downloaded the files from the Web.

If you are installing from CD-ROM, the path to the Product directory, *directory_name* is */cdrom/cdrom0/System_Management_Services_1_3/Product*.

EXTENDED DESCRIPTION**Group Privileges Required**

You must have superuser privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES**EXAMPLE 1** Upgrading SMS From CDROM or Web

```
sc0:sms-user:> smsupgrade directory_name

Attempting to stop daemon picld
/etc/init.d/picld stop

Verifying that all SMS packages are installed
.....OK

Backing up SMS to /var/tmp/sms_backup.1.3.cpio before
upgrade. Please wait. . .
smsbackup /var/tmp
smsbackup: Backup configuration file created: /var/tmp/
sms_backup.1.3.cpio
SMS backup complete.

Installing SMS packages. Please wait. . .
pkgadd -n -d "/cdrom/cdrom0/
System_Management_Services_1.3/Product" -a
/tmp/smsinstall.admin.26021 SUNWSMSr SUNWSMSop SUNWSMSdf
SUNWSMSjh SUNWSMSlp
SUNWSMSmn SUNWSMSob SUNWSMSod SUNWSMSpd SUNWSMSpo
SUNWSMSPp SUNWSMSsu
SUNWscdvr.u SUNWufrx.u SUNWufu

Copyright 2002 Sun Microsystems, Inc. All rights
reserved.
Use is subject to license terms.
205 blocks

Installation of <SUNWSMSr> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights
reserved.
Use is subject to license terms.
```

61279 blocks

Installation of <SUNWSMSop> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
32 blocks

Installation of <SUNWSMSdf> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
2704 blocks

Installation of <SUNWSMSjh> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
5097 blocks

Installation of <SUNWSMSlp> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
1696 blocks

Installation of <SUNWSMSmn> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
576 blocks

Installation of <SUNWSMSob> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
1025 blocks

Installation of <SUNWSMSod> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
1025 blocks

Installation of <SUNWSMSpd> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
14763 blocks

Installation of <SUNWSMSpo> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.

Installation of <SUNWSMSpp> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
Use is subject to license terms.
5 blocks

Installation of <SUNWSMSsu> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
479 blocks

Installation of <SUNWscdvr> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
33 blocks

```

Reboot client to install driver.
type=ddi_pseudo;name=flashprom uflash\N0

Installation of <SUNWufrx> was successful.
Copyright 2002 Sun Microsystems, Inc. All rights reserved.
13 blocks

Installation of <SUNWufu> was successful.

Verifying that all SMS packages are installed
.....OK
Checking that all installed SMS packages are correct
pkgchk -n SUNWSMSr SUNWSMSop SUNWSMSdf SUNWSMSjh SUNWSMSlp
SUNWSMSmn SUNWSMSob
SUNWSMSod SUNWSMSpd SUNWSMSpo SUNWSMSpp SUNWSMSsu
SUNWscdvr SUNWufrx SUNWufu
OK
Setting up /etc/init.d/sms run control script for SMS 1.3
New SMS version 1.3 is active
Restoring SMS from /var/tmp/sms_backup.1.3.cpio after
upgrade. Please wait. . .
smsrestore /var/tmp/sms_backup.1.3.cpio

Attempting to start daemon picld
/etc/init.d/picld start

smsupgrade complete. Log file is /var/sadm/system/logs/
smsupgrade.
#

```

EXAMPLE 2 Installing SMS After Web Start

```

sc0:sms-user:> smsupgrade -p directory_name
Verifying that all SMS packages are installed
.....OK
Checking that all installed SMS packages are correct
pkgchk -n SUNWSMSr SUNWSMSop SUNWSMSdf SUNWSMSjh SUNWSMSlp SUNWSMSmn
SUNWSMSob
SUNWSMSod SUNWSMSpd SUNWSMSpo SUNWSMSpp SUNWSMSsu SUNWscdvr SUNWufrx
SUNWufu
OK
Setting up /etc/init.d/sms run control script for SMS 1.3
New SMS version 1.3 is active
Attempting to restart daemon picld
/etc/init.d/picld stop
/etc/init.d/picld start
smsinstall complete. Log file is /var/sadm/system/logs/smsinstall.

```

EXIT STATUS

The following exit values are returned:

```

0           Successful completion.
>0         An error occurred.

```

FILES

The following file is used by this command:

```

/var/sadm/system/logs/smsupgrade           smsupgrade log file

```

/var/temp/sms_backup.1.3.cpio

SMS backup file

ATTRIBUTES

See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO

smsbackup(1M), **smsconfig**(1M), **smsinstall**(1M), **smsrestore**(1M)

System Management Services (SMS) 1.3 Installation Guide

NAME smsversion - change the active version of SMS to another co-resident version of the SMS software

SYNOPSIS **smsversion** *new_version*

smsversion -t

smsversion -h

DESCRIPTION smsversion(1M) can be used to switch between two co-installed (and consecutively released) versions of SMS.

Note – SMS 1.1 and SMS 1.3 are not consecutive releases and you cannot switch from one to the other using `smsversion`. You must do a fresh installation. Refer to the *System Management Services (SMS) 1.3 Installation Guide* for more information.

`smsversion` permits two-way SMS version-switching between sequential co-resident installations on the same operating environment but with the following conditions:

Condition	Explanation
New features	The features supported in the newer version of SMS may not be supported in the older version. Switching to an older version of SMS can result in the lose of those features. Also, the settings for the new features might be erased.
Flash PROM differences	Switching versions of SMS requires reflashing the CPU flash PROMs with the correct files. These files can be found in the <code>/opt/SUNWSMS/<SMS_version>/firmware</code> directory. Use <code>flashupdate(1M)</code> to reflash the PROMs after you have switched versions. Refer to the <code>flashupdate</code> man page, Chapter 11 of the <i>System Management Services (SMS) 1.3 Administrator Guide</i> and the <i>System Management Services (SMS) 1.3 Installation Guide</i> for more information on updating flash PROMs.

`smsversion`, when invoked with no command-line argument, displays the list of all properly installed versions of SMS on the current system controller. You can pick from that list, and `smsversion` stores a copy of the current configuration environment and then switches all necessary software links necessary for activating the new version of the software. `smsversion` can run with an optional command-line argument specifying the target version for switching.

Once `smsversion` completes the switch, the target version becomes the active version. To restore the configuration automatically saved by `smsversion` you must use `smsrestore(1M)`. Your previous configuration is not automatically restored as part of the version switch.

To restore your previous configuration do one of the following:

- Turn off failover and stop SMS. Then run `smsrestore`.

Note – If you changed your network configuration using `smsconfig -m` *after* you created the backup you just restored, you must run `smsconfig -m` and reboot now.

- Start SMS and turn on failover. For information about manually starting and stopping SMS refer to the *System Management Services (SMS) 1.3 Installation Guide*.

If any errors occur, `smsversion` writes error messages to `/var/sadm/system/logs/smsversion`.

OPTIONS

The following options are supported:

`-h` Help. Displays usage descriptions.

Note – Use alone. Any option specified in addition to `-h` is ignored.

`-t` Displays the current active version of SMS and exits.

OPERANDS

The following operands are supported:

`version_number` Release number of the target SMS version

EXTENDED DESCRIPTION

Group Privileges Required

You must have superuser privileges to run this command.

Refer to Chapter 2, "SMS Security Options and Administrative Privileges" in the *System Management Services (SMS) 1.3 Administrator Guide* for more information.

EXAMPLES

EXAMPLE 1 Displaying the Version with One Version of SMS Installed

Displays the active version and exits when only one version of SMS is installed.

```
sc# smsversion -t
1.2
```

EXAMPLE 2 Changing the Active Version of SMS

Displays versions of SMS installed on this system controller. Choose the inactive version and perform a version switch.

You must stop SMS prior to switching versions.

```
sc# smsversion
smsversion: Active SMS version 1.2
smsversion: SMS version 1.2 installed
smsversion: SMS version 1.3 installed
Please select from one of the following installed SMS versions.
1) 1.2
2) 1.3
3) Exit
Select version: 2
You have selected SMS Version 1.3

Is this correct? [y,n] y

smsversion: Upgrading SMS from 1.2> to 1.3>.
To move to a different version of SMS an archive of
critical files will be created. What is the name of
the directory or tape device where the archive will be
stored? [/var/tmp][return]

smsversion: Backup configuration file created: /var/tmp/
sms_backup.1.2.cpio
smsversion: Switching to target version 1.3>.
smsversion: New Version 1.3> Active
smsversion: Active SMS version 1.3 >
To use the previous SMS configuration settings type:
smsrestore /var/tmp/sms_backup.1.2.cpio

NOTE: When switching to another SMS version,
the user must choose (via use of smsrestore) to restore the
configuration settings from the previously active version.
```

EXAMPLE 3 Downgrading SMS Versions

```
sc# smsversion 1.2
smsversion: Active SMS version 1.3 >
You have requested SMS Version 1.2

Is this correct? [y,n] y
smsversion: Downgrading SMS from 1.3> to 1.2>.
smsversion: SMS version 1.2 installed
To move to a different version of SMS an archive of
critical files will be created. What is the name of
the directory or tape device where the archive will be
stored? [/var/tmp][return]

smsversion: Backup configuration file created: /var/tmp/
sms_backup.1.3.cpio
smsversion: Switching to target version 1.2>.
smsversion: New Version 1.2> Active
smsversion: Active SMS version 1.2 >
To restore previous the SMS configuration setting type:
smsrestore /var/tmp/sms_backup.1.3.cpio
```

EXIT STATUS The following exit values are returned:

0 Successful completion.
 >0 An error occurred.

FILES The following file is used by this command:

/var/sadm/system/logs/smsversion smsversion log file

ATTRIBUTES See **attributes(5)** for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **smsbackup(1M)**, **smsrestore(1M)**

- NAME** | `ssd` - SMS startup daemon
- SYNOPSIS** | `ssd [-f startup_file]`
`ssd [-i message]`
- DESCRIPTION** | `ssd(1M)` starts, stops, and monitors all the key daemons and servers of SMS. When executed with no options `ssd` reads from the `ssd_start` file, which lists the daemons and servers that `ssd` starts and monitors.
- Do *not* execute this program manually. `ssd(1M)` is automatically invoked by a Solaris software run-control script and is periodically monitored for restart.
- OPTIONS** | The following options are supported:
- `-f startup_file` Uses this file instead of the default `ssd_start` file.
 - `-i message` Places a notice message in the platform log file. Specified and used exclusively by the `sms` startup script.
- FILES** | The following files are supported:
- `/etc/opt/SUNWSMS/startup/ssd_start` Default startup file for `ssd`
 - `/etc/opt/SUNWSMS/startup/sms` Default startup file for SMS
- ATTRIBUTES** | See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

NAME tmd - task management daemon

SYNOPSIS **tmd** [-t *number*]

DESCRIPTION tmd(1M) provides task management services, such as scheduling for SMS. The purpose of this service is to reduce the number of conflicts that can arise during concurrent invocations of the hardware tests and configuration software.

This daemon is started automatically by `ssd(1M)`. Do *not* start it manually from the command line.

OPTIONS The following option is supported:

-t *number* This option allows the number of concurrent invocations to be throttled. The value must be a positive number, greater than or equal to one.

Caution- Changing the default value can adversely affect system functionality. Do *not* adjust this parameter unless instructed by a Sun service representative to do so.

EXIT STATUS The following exit values are returned:

0 Successful completion.

>0 An error occurred.

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO **ssd**(1M)

NAME wcapp - wPCI application daemon

SYNOPSIS **wcapp**

DESCRIPTION `wcapp(1M)` is responsible for implementing Sun Fire Link clustering functionality—specifically, handling requests from the domain-side drivers and responding to requests for information from the external Sun Fire Link fabric manager server. `wcapp` runs in a Java Virtual Machine (JVM) included with Solaris 8 02/02 operating environment or later.

`wcapp` is responsible for managing Sun Fire Link clustering for all the domains in the Sun Fire 15K/12K system. The Java side of `wcapp` exports a set of Java Remote Method Invocation (RMI) interfaces that can be used by the Sun Fire Link fabric manager to set up and monitor a cluster.

This daemon is automatically started by `ssd(1M)`. Do *not* start it manually from the command line.

EXIT STATUS The following exit values are returned:

0	Successful completion.
>0	An error occurred.

ATTRIBUTES See **attributes**(5) for descriptions of the following attributes.

Attribute Types	Attribute Values
Availability	SUNWSMSop

SEE ALSO `ssd`(1M)

