



# Sun Netra™ CP3060 Blade Server User's Guide

---

Sun Microsystems, Inc.  
[www.sun.com](http://www.sun.com)

Part No. 819-4967-11  
April 2009, Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright © 2009 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

This distribution may include materials developed by third parties.

Parts of the product may be derived from Berkeley BSD systems, licensed from the University of California. UNIX is a registered trademark in the U.S. and in other countries, exclusively licensed through X/Open Company, Ltd.

Sun, Sun Microsystems, the Sun logo, Netra, Sun Ray, the Netra logo and the Solaris logo are trademarks or registered trademarks of Sun Microsystems, Inc., or its subsidiaries, in the U.S. and other countries.

All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. in the U.S. and other countries. Products bearing SPARC trademarks are based upon architecture developed by Sun Microsystems, Inc.

Use of any spare or replacement CPUs is limited to repair or one-for-one replacement of CPUs in products exported in compliance with U.S. export laws. Use of CPUs as product upgrades unless authorized by the U.S. Government is strictly prohibited.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

---

Copyright © 2009 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

Cette distribution peut comprendre des composants développés par des tierces parties.

Des parties de ce produit pourront être dérivées des systèmes Berkeley BSD licenciés par l'Université de Californie. UNIX est une marque déposée aux Etats-Unis et dans d'autres pays et licenciée exclusivement par X/Open Company, Ltd.

Sun, Sun Microsystems, le logo Sun, Netra, Sun Ray, le logo Netra et le logo Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc., ou ses filiales, aux Etats-Unis et dans d'autres pays.

Toutes les marques SPARC sont utilisées sous licence et sont des marques de fabrique ou des marques déposées de SPARC International, Inc. aux Etats-Unis et dans d'autres pays. Les produits portant les marques SPARC sont basés sur une architecture développée par Sun Microsystems, Inc.

L'utilisation de pieces detachees ou d'unités centrales de remplacement est limitee aux reparations ou a l'echange standard d'unités centrales pour les produits exportes, conformément a la legislation americaine en matiere d'exportation. Sauf autorisation par les autorites des Etats-Unis, l'utilisation d'unités centrales pour proceder a des mises a jour de produits est rigoureusement interdite.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFACON.



# Contents

---

## **Preface xi**

### **1. Introduction to the Sun Netra CP3060 Blade Server 1-1**

- 1.1 Overview of the Sun Netra CP3060 Blade Server 1-1
- 1.2 Features of the Sun Netra CP3060 Blade Server 1-2
- 1.3 Sun Netra CP3060 Blade Server System Configurations 1-7
  - 1.3.1 AMC Modules 1-8
  - 1.3.2 Rear Transition Module 1-8
- 1.4 Hot-Swap Support 1-11
- 1.5 System Requirements 1-11
  - 1.5.1 Hardware Requirements 1-12
  - 1.5.2 Software Requirements 1-12
- 1.6 Technical Support and Warranty 1-13
  - 1.6.1 Blade Server Part Number, Serial Number, and Revision Number Identification 1-13

### **2. Hardware Installation 2-1**

- 2.1 Equipment and Operator Safety 2-1
- 2.2 Materials and Tools Required 2-2
- 2.3 Preparing for the Installation 2-3

2.3.1	Checking Power, Thermal, Environmental, and Space Requirements	2-3
2.3.2	Determining Local Network IP Addresses and Host Names	2-4
2.3.3	Installation Procedure Summary	2-4
2.4	Configuring the Blade Server Hardware	2-5
2.4.1	Installation of DDR-2 DIMM Memory Modules	2-5
2.4.1.1	Installing a DDR-2 DIMM Memory Module	2-7
2.4.1.2	Removing a DDR-2 DIMM Memory Module	2-8
2.4.2	Installation of Optional Compact Flash Card	2-9
2.4.3	Configuring Rear Transition Module Hardware	2-11
2.5	Installing the Sun Netra CP3060 Blade Server	2-11
2.5.1	Installing the Sun Netra CP3060 Blade Server With a Rear Transition Module	2-11
2.5.1.1	Installing a Rear Transition Module	2-12
2.5.2	Installing the Sun Netra CP3060 Blade Server	2-15
2.6	Connecting External I/O Cables	2-17
2.7	Installation of Optional AMC Modules	2-18
2.7.0.1	Installing an Optional AMC Module	2-19
<b>3.</b>	<b>Software Installation</b>	<b>3-1</b>
3.1	Operating Systems and Patches	3-1
3.2	Firmware Updates	3-2
3.3	Mandatory <code>/etc/system</code> File Entry	3-2
	▼ To Check and Create the Mandatory <code>/etc/system</code> File Entry	2
3.4	Installing Diskless Clients	3-3
3.4.1	Creating a Boot Server for Diskless Clients	3-3
3.4.2	Adding a Diskless Client	3-5
3.5	Downloading and Installing SunVTS Software	3-7
<b>4.</b>	<b>Firmware and Blade Server Management</b>	<b>4-1</b>

4.1	System Firmware	4-1
4.2	Power-On Self-Test Diagnostics	4-2
4.2.1	POST Test Coverage	4-2
4.2.2	POST Diagnostic and Error Message Format	4-3
4.3	OpenBoot Firmware	4-3
4.3.1	Getting to the ok Prompt	4-4
4.3.2	Auto-Boot Options	4-5
4.3.3	OpenBoot Commands	4-5
4.3.3.1	probe-ide Command	4-6
4.3.3.2	show-devs Command	4-6
4.3.3.3	Checking Network Using watch-net and watch-net-all Commands	4-8
4.3.4	OpenBoot Configuration Variables	4-9
4.3.4.1	Viewing and Setting OpenBoot Configuration Variables	4-12
4.4	Error Handling Summary	4-12
4.5	Automatic System Recovery	4-13
4.5.1	Enabling and Disabling Automatic System Recovery	4-14
4.5.1.1	To Enable Automatic System Recovery	4-14
4.5.1.2	To Disable Automatic System Recovery	4-15
4.6	Hot-Swap Information	4-15
4.6.1	Hot-Swapping the Sun Netra CP3060 Blade Server	4-15
4.6.1.1	Hot-Swap LED	4-16
4.7	Network Device Aliases	4-17
4.8	Retrieving Device Information	4-17
4.9	Mandatory /etc/system File Entry	4-20
▼	To Check and Create the Mandatory /etc/system File Entry	20

## 5. Hardware and Functional Descriptions 5-1

5.1	Hardware Architecture	5-1
-----	-----------------------	-----

5.1.1	UltraSPARC T1 Processor	5-4
5.1.1.1	Overview	5-4
5.1.1.2	Cores and Cache	5-5
5.1.1.3	Memory Controller	5-6
5.1.1.4	Instruction Set	5-6
5.1.1.5	Interrupts	5-6
5.1.1.6	UltraSPARC T1 RAS Features	5-6
5.1.1.7	UltraSPARC T1 Processor Speed	5-6
5.1.2	DDR-2 Memory Subsystem	5-7
5.1.2.1	DIMMs	5-7
5.1.2.2	Memory Subsystem RAS Features	5-8
5.1.2.3	Serial Presence Detect	5-9
5.1.3	System JBus	5-9
5.1.3.1	JBus RAS Features	5-9
5.1.4	I/O Subsystem	5-9
5.1.4.1	JBus-to-PCI-E Bridge	5-10
5.1.4.2	PCI-E Switch	5-11
5.1.4.3	PCI-E to Dual GbE Controller	5-11
5.1.4.4	Ethernet Switch	5-12
5.1.4.5	AMC Slot	5-12
5.1.4.6	Southbridge	5-16
5.1.5	Service Processor MPC885	5-17
5.1.5.1	MPC Bus External Devices	5-18
5.1.5.2	Field-Programmable Gate Array	5-18
5.1.5.3	XBus External devices	5-19
5.1.6	Intelligent Platform Management Controller	5-19
5.1.6.1	Intelligent Platform Management Bus	5-19
5.1.6.2	Interface to the MPC	5-19

5.1.6.3	IPMB-L Interface	5-20
5.1.6.4	ATCA Hot-Swap Latch	5-20
5.1.6.5	LEDs	5-20
5.1.6.6	Power Control	5-20
5.1.6.7	Extended Interface E-keying Control	5-21
5.1.6.8	I <sup>2</sup> C Architecture	5-21
5.1.6.9	I <sup>2</sup> C Device Address Map	5-22
5.1.6.10	System Monitor and Thresholds	5-24
5.2	Power-on Sequence	5-26
5.3	Power	5-27
5.3.1	Power Input	5-27
5.3.2	Fuses	5-27
5.3.3	ATCA Power Module (-48V to 12V)	5-28
5.3.4	On-Board DC/DC Regulators	5-28
5.3.5	TOD Clock Battery	5-28

## **A. Physical Characteristics    A-1**

A.1	Form Factor	A-1
A.2	Layout	A-1
A.3	Front Panel	A-2
A.3.1	Visual Indicators	A-3
A.3.2	Ports	A-3
A.3.3	AMC Slot	A-3
A.4	Connectors and Pinout	A-3
A.4.1	Front Panel Connectors	A-3
A.4.1.1	Ethernet Ports	A-4
A.4.1.2	Serial Port	A-4
A.4.2	AMC Connector	A-5
A.4.3	Compact Flash Connector	A-7

- A.4.4 Midplane Power Connector (Zone 1) A-7
- A.4.5 Data Transport Connector (Zone 2) A-9
- A.4.6 RTM Connector (Zone 3) A-11
- A.4.7 TOD Clock Battery Holder A-14

## **B. Sun OEM IPMI Commands B-1**

- B.1 Get Version Command B-2
- B.2 Get RTM Status Command B-3

## **Index Index-1**



# Figures

---

FIGURE 1-1	Sun Netra CP3060 Blade Server Front Panel	1–4
FIGURE 1-2	Sun Netra CP3060 Blade Server (Top View)	1–4
FIGURE 1-3	Sun Netra CP3060 Blade Server in an ATCA Shelf Enclosure	1–8
FIGURE 1-4	Sun Netra CP3060 Rear Transition Module	1–9
FIGURE 1-5	Relationship of the Sun Netra CP3060 Blade Server, Midplane, and RTM	1–10
FIGURE 1-6	Sun Netra CP3060 Blade Server Barcode Labeling	1–14
FIGURE 2-1	DDR-2 DIMM Memory Locations	2–6
FIGURE 2-2	Installing a DDR-2 DIMM Memory Module	2–8
FIGURE 2-3	Removing a DDR-2 DIMM Memory Module	2–9
FIGURE 2-4	Compact Flash Card Connector	2–10
FIGURE 2-5	Installing the Sun Netra CP3060 Rear Transition Module	2–12
FIGURE 2-6	RTM Injector/Ejector Latch and Locking Screw	2–14
FIGURE 2-7	Installing Node Blade Server Into Chassis Slot	2–16
FIGURE 2-8	Sun Netra CP3060 Blade Server Latches and Locking Screws	2–17
FIGURE 2-9	Removing AMC Slot Filler Panel	2–19
FIGURE 2-10	Inserting AMC Module Into AMC Connector	2–20
FIGURE 4-1	Hot-Swap Latch and Hot-Swap LED	4–16
FIGURE 5-1	Block Diagram	5–3
FIGURE 5-2	UltraSPARC T1 Multicore Processor Block Diagram	5–5
FIGURE 5-3	DDR Memory Diagram	5–8

FIGURE 5-4	AMC Power and Management Infrastructure	5–14
FIGURE 5-5	Clock Synchronization	5–16
FIGURE 5-6	I <sup>2</sup> C Block Diagram	5–22
FIGURE A-1	Sun Netra CP3060 Blade Server Layout	A–2
FIGURE A-2	Ethernet RJ-45 Connector	A–4
FIGURE A-3	Front Panel Serial Port Diagram	A–5
FIGURE A-4	Power Distribution Connector (Zone 1) P10	A–8
FIGURE A-5	Zone 2 Connectors	A–10
FIGURE A-6	Zone 3 Connectors	A–12

# Preface

---

The *Sun Netra CP3060 Blade Server User's Guide* provides information about features, installation, configuration, functional hardware components, and physical properties of this blade server. The *Sun Netra CP3060 Blade Server User's Guide* is written for system integration engineers, field applications and service engineers, and others involved in the integration of these blade servers into systems.

---

## How This Document Is Organized

[Chapter 1](#) provides an overview of the Sun Netra CP3060 blade server.

[Chapter 2](#) provides instructions on hardware installation.

[Chapter 3](#) provides instructions on the software configuration.

[Chapter 4](#) provides information about the Sun Netra CP3060 firmware.

[Chapter 5](#) provides hardware and functional descriptions of the Sun Netra CP3060 blade server.

[Appendix A](#) provides information about the physical characteristics of the Sun Netra CP3060 blade server.

[Appendix B](#) describes the Sun-specific OEM-defined Intelligent Platform Management Interface (IPMI) commands.

---

# Using UNIX Commands

This document might not contain information on basic UNIX® commands and procedures such as shutting down the system, booting the system, and configuring devices. Refer to the following for this information:

- Software documentation that you received with your system
- Solaris™ Operating System documentation, which is at:

<http://docs.sun.com>

---

## Shell Prompts

Shell	Prompt
C shell	<i>machine-name%</i>
C shell superuser	<i>machine-name#</i>
Bourne shell and Korn shell	\$
Bourne shell and Korn shell superuser	#

---

# Typographic Conventions

Typeface*	Meaning	Examples
AaBbCc123	The names of commands, files, and directories; on-screen computer output	Edit your <code>.login</code> file. Use <code>ls -a</code> to list all files. % You have mail.
<b>AaBbCc123</b>	What you type, when contrasted with on-screen computer output	% <b>su</b> password:
<i>AaBbCc123</i>	Book titles, new words or terms, words to be emphasized. Replace command-line variables with real names or values.	Read Chapter 6 in the <i>User's Guide</i> . These are called <i>class</i> options. You <i>must</i> be superuser to do this. To delete a file, type <code>rm filename</code> .

\* The settings on your browser might differ from these settings.

---

## Related Documentation

For additional information about the Sun Netra CP3060 blade server and the Sun Netra CP3060 rear transition module (RTM), refer to the following documents.

Title	Part Number
<i>Sun Netra CP3060 Blade Server Product Notes</i>	819-4966
<i>Sun Netra CP3060 Blade Server Getting Started Guide</i>	819-4971
<i>Sun Netra CP3060 Blade Server Programming Guide</i>	819-4969
<i>Sun Netra CP3060 Rear Transition Module Getting Started Guide</i>	819-6692
<i>Sun Netra CP3060 Rear Transition Module User's Guide</i>	819-6689
<i>Important Safety Information for Sun Hardware Systems</i> (printed version only)	816-7190-10

Except for *Important Safety Information for Sun Hardware Systems*, all the documents listed are available online at:

<http://www.sun.com/documentation>

---

# Documentation, Support, and Training

Sun Function	URL
Documentation	<a href="http://www.sun.com/documentation/">http://www.sun.com/documentation/</a>
Support	<a href="http://www.sun.com/support/">http://www.sun.com/support/</a>
Training	<a href="http://www.sun.com/training/">http://www.sun.com/training/</a>

---

## Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

---

## Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of your document with your feedback:

*Sun Netra CP3060 Blade Server User's Guide*, part number 819-4967-11

# Introduction to the Sun Netra CP3060 Blade Server

---

This chapter contains the following sections:

- [Section 1.2, “Features of the Sun Netra CP3060 Blade Server” on page 1-2](#)
- [Section 1.3, “Sun Netra CP3060 Blade Server System Configurations” on page 1-7](#)
- [Section 1.4, “Hot-Swap Support” on page 1-11](#)
- [Section 1.5, “System Requirements” on page 1-11](#)
- [Section 1.6, “Technical Support and Warranty” on page 1-13](#)

---

## 1.1 Overview of the Sun Netra CP3060 Blade Server

The Sun Netra CP3060 blade server is a high-performance single-blade server computer based on one UltraSPARC® T1 multicore processor and designed for high availability in a switched network computing environment. This blade server is compliant with Advanced Telecom Computing Architecture® (ATCA) specifications (PICMG® 3.0 and PICMG 3.1) and can achieve greater performance levels than compactPCI (cPCI) standards-based products targeted for telco markets.

The PICMG (PCI Industrial Computer Manufacturers Group) standards committee has developed the new ATCA (or PICMG 3.x) standard to address the issues posed by previous standards based on cPCI and cPSB (PICMG 2.x). The PICMG 3.x specification brought the following changes to the existing PICMG 2.x family of products:

- Larger board space (8U high compared to 6U for cPCI), which allows more features and processing power
- On-board power supplies deriving local power from redundant –48V power from the midplane (rather than separate power supplies)

- 6-HP slot width, allowing greater component height
- Advanced Mezzanine card (AMC) support and options
- Elimination of PCI connectivity between the blade servers in the system and reallocation of connectivity to serial interconnects, eliminating single points of failure
- Mandatory use of Intelligent Platform Management Interface (IPMI) management interfaces
- Flexible user I/O
- Power and thermal management guidelines enforced by the management infrastructure
- Separation of control and data traffic by supporting the Base (PICMG 3.0) and Extended (PICMG 3.1) interfaces

The ATCA standard consists of the PICMG 3.0, PICMG 3.1, PICMG 3.2, and PICMG 3.3 specifications. The Sun Netra CP3060 blade server complies with:

- PICMG 3.0, the base specification that defines the mechanical, power distribution, system management, data transport, and regulatory guidelines
- PICMG 3.1, which builds upon the PICMG 3.0 base specification and the IEEE 802.3-2003 standard

---

## 1.2 Features of the Sun Netra CP3060 Blade Server

The Sun Netra CP3060 blade server provides two 1000BASE-T Ethernet interfaces for the Base interface (a requirement of PICMG 3.0) and two serializer, deserializer (SERDES) gigabit Ethernet interfaces (PICMG 3.1) for the Extended interface. The Base interface is used as the control interface and the Extended interface can be used for data traffic. Both Base and Extended interfaces are configured as Dual Star topologies.

Sun Netra CP3060 blade server features include:


- Single-wide ATCA module
  - Compliant with PICMG 3.0/3.1 specification
- UltraSPARC T1 4-core, 6-core, or 8-core, 1.0-GHz processor
- Service processor (MPC885) for CPU reset, boot, partition, and fault management architecture (FMA)
- Memory subsystem
  - Eight standard DDR-2 Very Low Profile (VLP) DIMM sockets



- 200 MHz DIMMs, buffered and registered with error-correcting code (ECC)
- Up to 16 Gbytes of DIMM memory with 2-Gbyte DIMMs
- JBus-to-PCI-E application-specific integrated circuits (ASICs) to bridge processors and the PCI-E I/O subsystem
- Two on-board 1000BASE-T Ethernet interfaces used as ATCA Base Interface
- Two on-board 1000 SERDES Ethernet interfaces used as ATCA Extended Interface
- One AMC slot for x8 PCI-E I/O expansion or compatible disk drive
  - Compliant with PCIMG AMC.0/.1/.3 specifications
- Two 3-Gbps Serial Advanced Technology Attachment (SATA) ports routed to AMC connector
- Two 10/100/1000 BASE-T Ethernet RJ-45 ports on front panel
- One asynchronous serial port on front panel
- Compact Flash socket to support an 8-Gbyte user flash type I/II memory card
- System management support using Pigeon Point Systems Intelligent Platform Management (IPM) controller, providing a redundant IPMI channel to communicate with the ATCA shelf manager
- Rear I/O access using a compatible Sun Netra CP3060 rear transition module (RTM)
- Maximum power consumption: 200 watts (including Sun Netra CP3060 RTM)

FIGURE 1-1 and FIGURE 1-2 show the Sun Netra CP3060 blade server.

**FIGURE 1-1** Sun Netra CP3060 Blade Server Front Panel



- 1 - Top latch
- 2 - AMC Hard Disk Drive (optional)
- 3 - Ethernet port A (RJ-45)
- 4 - Ethernet port B (RJ-45)
- 5 - Serial port (RJ-45, ttya)

- 6 - Out of Service LED (yellow)
- 7 - OK LED (green)
- 8 - Hot-Swap LED (blue)
- 9 - Hot-Swap switch and bottom latch

**FIGURE 1-2** Sun Netra CP3060 Blade Server (Top View)




TABLE 1-1 lists features of the blade server.

**TABLE 1-1** Feature Summary for the Sun Netra CP3060 Blade Server

Feature	Description
CPU	<ul style="list-style-type: none"> <li>• One UltraSPARC T1 processor (4, 6, or 8 core)</li> <li>• CPU core speed: 1.0 GHz</li> </ul>
Memory	<ul style="list-style-type: none"> <li>• Eight DDR-2 240-pin Very Low Profile (VLP) DIMMs, buffered, registered</li> <li>• 1-Gbyte or 2-Gbyte DIMMs, for a total memory of 16 Gbytes</li> <li>• ECC supported</li> </ul>
Power requirement	ATCA 3.0 standard of 200 watts maximum
PICMG compliance	<ul style="list-style-type: none"> <li>• PICMG 3.0 R1.0</li> <li>• PICMG 3.1 R1.0</li> </ul>
Node board support	Functions as a CPU node board with the Solaris software package
Operating system	Solaris 10 6/06 OS and subsequent compatible versions with supported Netra patches
Internal I/O (connections to ATCA midplane)	<ul style="list-style-type: none"> <li>• Dual gigabit Ethernet for Base interface</li> <li>• Dual SERDES interface as Extended interface</li> <li>• Dual IPMI channel connects to the midplane for communicating with the Shelf Management card</li> </ul>
External I/O	<ul style="list-style-type: none"> <li>• Two 10/100/1000 BASE-T Ethernet ports on front panel</li> <li>• One asynchronous serial port for maintenance on front panel</li> <li>• One AMC slot with front panel access for AMC I/O</li> <li>• Rear access support using Sun Netra CP3060 RTM: <ul style="list-style-type: none"> <li>–One 10/100 Mbps Ethernet port</li> <li>–One asynchronous serial port. Access is available in front and rear when RTM is present. Note: Either serial port can be used; but only one of the serial ports can be used at a time.</li> </ul> </li> </ul>
AMC I/O	Provision for adding an independent hardware vendor (IHV)-supplied AMC disk or PCI-E card on front panel
IPMI system management	Uses IPMI communications with baseboard management controller (BMC); performs advanced system monitoring (ASM) on local board interface (for example, temperature sense, FRU ID, and control)
Hot-swap support	<ul style="list-style-type: none"> <li>• Basic, full, and high-availability (HA) hot-swap support for node board</li> <li>• AMC disk/card hot-swap support</li> </ul>

**TABLE 1-1** Feature Summary for the Sun Netra CP3060 Blade Server *(Continued)*


Feature	Description
Front panel access	<ul style="list-style-type: none"><li>• One serial port (RJ-45)</li><li>• Two 10/100/1000BASE-T Ethernet ports (RJ-45)</li><li>• Cutout for installing AMC without removing blade server from system</li></ul>
Building compliance	Network Equipment Building Systems (NEBS) Level 3
Flash update	Supported from downloaded file

**Note** – For EMI compliance of front access ports, use shielded cables on all I/O ports. The shields for all shielded cables must be terminated on both ends.

# 1.3 Sun Netra CP3060 Blade Server System Configurations

Sun Netra CP3060 blade servers can be installed in an ATCA shelf (or chassis), shown in [FIGURE 1-3](#). The blade servers can be deployed in various electrical configurations to suit each end-user requirement. For example, the blade server can be configured to boot from a network as a diskless client with either a front panel or RTM network connection, or from an optional Compact Flash card. Alternatively, industry-standard Advanced Mezzanine Card (AMC) hardware from IHVs can be installed to provide local disk I/O, which can be used optionally as a boot path. The Sun Netra CP3060 blade server has fixed on-blade server memory and connectors for additional memory.

**FIGURE 1-3** Sun Netra CP3060 Blade Server in an ATCA Shelf Enclosure



Diskless client that boots through network from a remote server


## 1.3.1 AMC Modules

The Sun Netra CP3060 blade server has one AMC slot to provide additional I/O to the front panel. The AMC slot supports AMC-compatible SATA disk drives and PCI-E cards. See [Section A.4.2, “AMC Connector ” on page A-5](#) for more information.

## 1.3.2 Rear Transition Module


The optional Sun Netra CP3060 RTM installs into the rear of the ATCA enclosure, opposite the Sun Netra CP3060 blade server (see [FIGURE 1-5](#)). The RTM connects with the host node board’s Zone 3 rear I/O connectors and includes a serial port and 10/100BASE-T Ethernet port, both with RJ-45 connectors (see [FIGURE 1-4](#)).

**FIGURE 1-4** Sun Netra CP3060 Rear Transition Module



**FIGURE 1-5** shows the physical relationship between the blade server, the rear transition module, and the midplane in a typical ATCA system.

**FIGURE 1-5** Relationship of the Sun Netra CP3060 Blade Server, Midplane, and RTM



---

**Note** – When the RTM is used with the Sun Netra CP3060 blade server, shielded cables are required for serial I/O ports. Unshielded cables can be used on Ethernet ports to satisfy EMI compliance standards. The shields for all shielded cables must be terminated on both ends.

---

The customer can order the Sun Netra CP3060 RTM, build a custom card, or buy from an IHV. A minimal set of I/O must provide a boot path for the host board and a path for console I/O to deliver commands and to read board and system status.



Possible boot and console configurations are described in [TABLE 1-2](#). Sun Microsystems provides the Sun Netra CP3060 blade server and a compatible Sun Netra CP3060 RTM. The other configurations require IHV hardware.

**TABLE 1-2** I/O Configurations

I/O	Hardware Required	Description
Ethernet	Sun Netra CP3060 blade server Sun Netra CP3060 RTM (RTM—supplied as an option for rear access)	Default boot path uses the Ethernet port; when the blade server runs in diskless client configuration.
SATA	Through the AMC connector	SATA devices can be used for local booting.
Serial data	Sun Netra CP3060 blade server Sun Netra CP3060 RTM	Serial port on front panel provides a path for a console I/O. The serial port can be used on either the Sun Netra CP3060 blade server or Sun Netra CP3060 RTM, but both ports cannot be used at the same time. If the serial port on Sun Netra CP3060 blade server is used, the serial port on the Sun Netra CP3060 RTM should not be used and vice versa.
Compact Flash	Sun Compact Flash card	The Compact Flash connector can be used to add an optional 8-Gbyte user flash type I/II memory card.

## 1.4 Hot-Swap Support

This section briefly discusses the hot-swap support on the Sun Netra CP3060 blade server.

There are three hot-swap models described in the PICMG ATCA specification: basic hot-swap, full hot-swap, and high-availability (HA) hot-swap. Refer to the PICMG *ATCA Specification*, which provides a detailed description of this subject.

This process uses hardware connection control to connect the hardware in an orderly sequence.

## 1.5 System Requirements

This section contains the system-level hardware and software requirements for the Sun Netra CP3060 blade server.

## 1.5.1 Hardware Requirements

Sun provides the following items for customer order:

- Sun Netra CP3060 node blade server
- Sun Netra CP3060 RTM (optional)

The RTM enables rear system I/O access to the network, to a boot device, and to a console terminal (shown in [FIGURE 1-4](#)). Refer to the *Sun Netra CP3060 Rear Transition Module User's Guide* (819-6689) for more information.

The Sun Netra CP3060 RTM is optional and must be ordered separately.

- Compact Flash card (optional)

An IDE Compact Flash card is optional and must be ordered separately.

Acquire the following components, if needed:

- Serial terminal or terminal emulation for console output.
- Cables for terminal and network connections.
- The Sun Netra CP3060 RTM and the AMC disks and PCI-E cards are optional.

[TABLE 1-3](#) lists ATCA and other minimum requirements met by the Sun Netra CP3060 blade server.

**TABLE 1-3** ATCA and Other Minimum Requirements Met By the Sun Netra CP3060 Blade Server

Requirements	Sun Netra CP3060 Node Blade Server
ATCA system enclosure for 8U boards (includes chassis, midplane, power supply)	Yes
Console output device or serial terminal	Yes
Boot device (such as hard drive, network, or Compact Flash card)	Yes
Peripheral device for network access	Yes
Intelligent Platform Management Controller (IPMC)	Yes

## 1.5.2 Software Requirements

The Sun Netra CP3060 blade server supports the following versions of the Solaris OS:

- Solaris 10 OS and subsequent compatible versions

Refer to the *Sun Netra CP3060 Blade Server Product Notes* (819-4966) for more Solaris OS information, including a list of the required Netra software patches. You can view and download the latest version of this manual at the following web site:

<http://www.sun.com/documentation>

---

## 1.6 Technical Support and Warranty

Should you have any technical questions or support issues that are not addressed in the Sun Netra CP3060 blade server documentation set or on the web site, contact your local Sun Services representative. This hardware carries a one-year return-to-depot warranty. For customers in the US or Canada, call 1-800-USA-4SUN (1-800-872-4786). For customers in the rest of the world, find the World Wide Solution Center nearest you by visiting our web site:

<http://www.sun.com/service/contacting/solution.html>

When you call Sun Services, be sure to indicate if the Sun Netra CP3060 blade server was purchased separately and is not associated with a system. Have the proper blade server identification information ready. Be prepared to give the representative the blade server part number, serial number, and date code (see [FIGURE 1-6](#)).


### 1.6.1 Blade Server Part Number, Serial Number, and Revision Number Identification

The Sun Netra CP3060 blade server part number, serial number, and revision can be found on labels located on the card (see [FIGURE 1-6](#)). The Sun barcode labels provide the following information:

- SunSN – Sun serial number (for example, 1005LCB-0626WM001M)
- SunPN – Sun part number and dash number (for example, 501-7658-01), -01 is the dash number
- Rev – Revision number of the part (for example: Rev 06)

The Media Access Control (MAC) address label contains the MAC address for the blade server in printed and barcode form.

**FIGURE 1-6** Sun Netra CP3060 Blade Server Barcode Labeling



---

**Note** – You might find the labels shown in [FIGURE 1-6](#) on other locations on your blade server. Your particular blade server configuration might also appear different from the illustration.

---

# Hardware Installation

---

This chapter describes the hardware installation procedures for the Sun Netra CP3060 blade server, and contains the following sections:

- [Section 2.1, “Equipment and Operator Safety” on page 2-1](#)
- [Section 2.2, “Materials and Tools Required” on page 2-2](#)
- [Section 2.3, “Preparing for the Installation” on page 2-3](#)
- [Section 2.4, “Configuring the Blade Server Hardware” on page 2-5](#)
- [Section 2.5, “Installing the Sun Netra CP3060 Blade Server” on page 2-11](#)
- [Section 2.6, “Connecting External I/O Cables” on page 2-17](#)

---

## 2.1 Equipment and Operator Safety

Refer to *Important Safety Information for Sun Hardware Systems* (816-7190) for general safety information.

Read the safety statements specific to the Sun Netra CP3060 blade server carefully before you install or remove any part of the system.



---

**Caution** – Depending on the particular chassis design, operations with open equipment enclosures can expose the installer to hazardous voltages with a consequent danger of electric shock. Ensure that line power to the equipment is disconnected during operations that make high voltage conductors accessible.

---

The installer must be familiar with commonly accepted procedures for integrating electronic systems and with the general practice of Sun systems integration and administration. Although parts of these systems are designed for hot-swap

operation, other components must not be subjected to such stresses. Work with power connected to a chassis only when necessary, and follow these installation procedures to avoid equipment damage.

This equipment is sensitive to damage from electrostatic discharge (ESD) from clothing and other materials. Use the following antistatic measures during an installation:

- If possible, disconnect line power from the equipment chassis when servicing a system or installing a hardware upgrade. If the chassis cannot be placed upon a grounded antistatic mat, connect a grounding strap between the facility electrical input ground (usually connected to the equipment chassis) and facility electrical service ground.
- Use an antistatic wrist strap when:
  - Removing a blade server from its antistatic bag
  - Connecting or disconnecting blade servers or peripherals

The other end of the strap lead should be connected to one of the following:

- A ground mat
- Grounded chassis metalwork
- A facility electrical service ground
- Keep blade servers in the antistatic bags until they are needed.
- Place circuit blade servers that are out of their antistatic bags on an antistatic mat if one is available. The mat must be grounded to a facility electrical service ground. Do not place blade servers on top of an antistatic bag unless the outside of the bag also has antistatic protective properties.
- Remove a blade server from its antistatic bag only when wearing a properly connected ground strap.

---

## 2.2 Materials and Tools Required

This section provides information on the materials and tools required to perform installation. The minimum tools required to perform installation are:

- Phillips screwdrivers, No. 1, No. 2 (optional)
- Antistatic wrist strap
- Terminal console

See [Section 1.5.1, “Hardware Requirements” on page 1-12](#) for information on hardware requirements.

---

## 2.3 Preparing for the Installation

Read the following subsections before starting to install these blade servers. In addition, do the following:

1. Become familiar with the contents of the referenced documentation.
2. Verify that all listed hardware and software is available (see [Section 1.5, “System Requirements” on page 1-11](#)).
3. Check power, thermal, environmental, and space requirements (see [Section 2.3.1, “Checking Power, Thermal, Environmental, and Space Requirements” on page 2-3](#)).
4. Verify that local area network (LAN) preparations are completed (see [Section 2.3.2, “Determining Local Network IP Addresses and Host Names” on page 2-4](#)).
5. Ensure that the host names and their network IP addresses are allocated and registered at the site.

### 2.3.1 Checking Power, Thermal, Environmental, and Space Requirements

Verify that you meet the following requirements:

- Your enclosure specifications support the sum of the specified maximum blade server power loads. See [Section 5.3, “Power” on page 5-27](#) for blade server power specifications.
- Facility power loading specifications can support the rack or enclosure requirements.
- Your enclosure specifications support the cooling airflow requirements. The Sun Netra CP3060 blade server fits a standard ATCA shelf or chassis. If your installation requirements are different, contact your field application engineer.

# 2.3.2 Determining Local Network IP Addresses and Host Names

Collect the following information to connect hosts to the local area network (LAN). Ask your network administrator for help, if necessary. You can use [TABLE 2-1](#) to record this information. This information is not needed for a standalone installation.

**TABLE 2-1** Local Network Information

Information Needed	Your Information
IP address* and host name for each Sun Netra CP3060 client	
Domain name	
Type of name service and corresponding name server names and IP addresses—for example, DNS and NIS (or NIS+)	
Subnet mask	
Gateway router IP address	
NFS server names and IP addresses	
Web server URL	

\* Local IP addresses are not needed if they are assigned by a network DHCP server.

You might need the MAC (Ethernet) addresses of the local hosts to make nameserver database entries. The MAC address can be seen in the console output while booting to the ok prompt. It can also be derived from the host ID seen on the barcode label (see [Section 1.6.1, “Blade Server Part Number, Serial Number, and Revision Number Identification” on page 1-13](#)).

# 2.3.3 Installation Procedure Summary

The steps in this section summarize the Sun Netra CP3060 blade server installation at a high level. Be sure to read the details in [Section 2.4, “Configuring the Blade Server Hardware” on page 2-5](#) before installing the blade server.

The procedure to set up and configure a Sun Netra CP3060 blade server in a system includes the following steps:

1. Configure the blade server’s physical hardware. For example, install memory or Compact Flash, as necessary.
2. Configure the rear transition module (RTM), as necessary.



3. Optional - Physically install the Sun Netra CP3060 RTM into the chassis.
4. Physically install the Sun Netra CP3060 blade server into the chassis.
5. Connect the nodes to a local network. Alternatively, the blade server can be run as a standalone system without a network connection.
6. Optional - Install an AMC module on the Sun Netra CP3060 blade server.
7. Install the operating system and patches, as necessary. See [Section 3.1, “Operating Systems and Patches” on page 3-1](#).

---

## 2.4 Configuring the Blade Server Hardware

This section lists hardware installation and settings that might apply to your blade server configuration. Read and perform the procedures, as necessary, before installing the Sun Netra CP3060 blade server into the chassis.

### 2.4.1 Installation of DDR-2 DIMM Memory Modules

The Sun Netra CP3060 blade server supports a total of 8 DIMMs and a maximum memory capacity of 16 Gbytes (using eight 2-Gbyte DIMMs). [FIGURE 2-1](#) shows the location of the DIMMs. In addition to the on-board memory, the Sun Netra CP3060 blade server accommodates the following:

- Eight standard DDR-2 DIMMs, buffered, and registered
- 1-Gbyte and 2-Gbyte DDR-2 modules supported
- DIMMs are installed as shown in [FIGURE 2-1](#)

---

**Note** – You cannot mix 1-Gbyte and 2-Gbyte DIMMs.


---

The Sun Netra CP3060 blade server supports DDR-2 DIMM memory modules that have the following characteristics:

- Each DIMM has a 72-bit-wide data bus (64+8 ECC) and up to 14 address bits.
- Maximum height of the DIMM module is 0.72 inches, Very Low Profile (VLP).
- Supports single-bank or dual-bank SDRAM DIMMs.
- Memory controller supports 128-bit data plus 9-bit error-correcting code (ECC).
- Maximum of 16 Gbytes.

For additional information, see [Section 5.1.2, “DDR-2 Memory Subsystem”](#) on [page 5-7](#). [FIGURE 2-1](#) shows the location of the DIMMs.

**FIGURE 2-1** DDR-2 DIMM Memory Locations



Note: Channels 1 and 2 are used in four DIMM configurations.  
Channels 0 and 3 are only used in eight DIMM configurations.

### 2.4.1.1 Installing a DDR-2 DIMM Memory Module

The following procedure provides a general guide for installing additional memory. However, for directions on the installation process of the memory DDR-2 DIMMs on the Sun Netra CP3060 blade server, refer to the documentation that shipped with the memory module.



---

**Caution** – Do not remove the DDR-2 DIMM from its antistatic container until you are ready to install it on the card. Handle the module only by its edges. Do not touch module components or metal parts. Always wear a grounded antistatic wrist strap when handling modules.

---

**1. Locate the DDR-2 DIMM connectors on the Sun Netra CP3060 blade server.**


Select the connectors where you will install the memory module (see [FIGURE 2-1](#)). If you need to replace an existing memory module with a new module, see [Section 2.4.1.2, “Removing a DDR-2 DIMM Memory Module” on page 2-8](#) for instructions on removing the DDR-2 DIMM module.

**2. Remove the DDR-2 DIMM from its protective packaging, holding the module only by the edges.**

**3. Insert the bottom edge of the DDR-2 DIMM into the bottom of the slot’s hinge-style connector (see [FIGURE 2-2](#)).**

The socket and module are both keyed, which means the module can be installed one way only. With even pressure, push simultaneously on both upper corners of the DDR-2 DIMM until its bottom edge (the edge with the gold fingers) is firmly seated in the connector.

**FIGURE 2-2** Installing a DDR-2 DIMM Memory Module



---

**Caution** – Do not rock the DDR-2 DIMM into place. Ensure that all contacts engage at the same time. You will feel or hear a click when the DDR-2 DIMM properly seats in the connector.

---

4. Press the top edge of the DDR-2 DIMM toward the blade server until the retainer clips click into place (see [FIGURE 2-2](#)).

The small retainer clips on each side of the DDR-2 DIMM slot click into place in the notches on the sides of the DDR-2 DIMM.

### 2.4.1.2

## Removing a DDR-2 DIMM Memory Module

You might need to remove a DDR-2 DIMM module from the Sun Netra CP3060 blade server if you are returning the DDR-2 DIMM module or the blade server for service, or if you are replacing a module with another DDR-2 DIMM module.

---

**Note** – Safely store the original factory-shipped DDR-2 DIMM and related DDR-2 DIMM packaging. You might wish to store any removed DDR-2 DIMM in the new DDR-2 DIMM packaging, or use the packaging for service.

---

To remove a DDR-2 DIMM from the Sun Netra CP3060 blade server, perform the following steps:

1. Take antistatic precautions: attach and electrically ground the wrist strap.




---

**Caution** – Always wear a grounded antistatic wrist strap when handling modules.

---

2. Place the Sun Netra CP3060 blade server on an antistatic mat, or on the blade server's antistatic bag if you do not have a mat available.
3. For the DDR-2 DIMM you wish to remove, simultaneously pull both DDR-2 DIMM retainer clips outward from the slot.
4. Grasp the DDR-2 DIMM by the edges, and carefully pull it out of its connector. Place it in an antistatic bag.

**FIGURE 2-3** Removing a DDR-2 DIMM Memory Module




5. If you are replacing the module you removed with a new DDR-2 DIMM, install it as described in [Section 2.4.1.1, “Installing a DDR-2 DIMM Memory Module”](#) on [page 2-7](#).

## 2.4.2 Installation of Optional Compact Flash Card

An optional IDE Compact Flash card can be installed on the Sun Netra CP3060 blade server. The Compact Flash card is not hot-swappable and there is no access to the card once the blade server is installed in an ATCA chassis.

To install the Compact Flash card, use the arrow on the card's label as a guide and insert the card into the Compact Flash connector (see [FIGURE 2-4](#)).

**FIGURE 2-4** Compact Flash Card Connector



## 2.4.3 Configuring Rear Transition Module Hardware

If you are using the Sun Netra CP3060 RTM, refer to the *Sun Netra CP3060 Rear Transition Module User's Guide* (819-6689). You can also refer to the Sun Netra CP3060 RTM manual for detailed connector pin assignments.

---


## 2.5 Installing the Sun Netra CP3060 Blade Server

If you are installing the Sun Netra CP3060 blade server with the RTM, first install the RTM at the rear of the server. Then install the node card in the front of the server. Even though you will be installing the RTM first, look at the front of the server and locate the slot number where you will be installing the Sun Netra CP3060 blade server. Then go to the back of the server and install the RTM in that particular slot.

### 2.5.1 Installing the Sun Netra CP3060 Blade Server With a Rear Transition Module

A compatible RTM must be used with the Sun Netra CP3060 blade server for rear I/O access. The RTM enables access to the network, to a boot device, and to a console terminal. You can use the Sun Netra CP3060 RTM, or you might design your own rear transition module.

**FIGURE 2-5** Installing the Sun Netra CP3060 Rear Transition Module



### 2.5.1.1 Installing a Rear Transition Module


1. Verify that you have taken the necessary antistatic precautions.
2. Go to the rear of the system and choose an appropriate slot for the RTM.

RTMs must be installed inline behind the accompanying node blade server. For example, if the accompanying node blade server is installed in slot 3, its RTM must be installed at the back of the system in slot 3. See [FIGURE 2-5](#).



3. Remove the slot filler panel from the selected node blade server slot, if necessary.
4. Get the RTM from the shipping kit.
5. Perform any card-specific hardware procedures, if necessary.  
Refer to the documentation that you received with the card for more information.
6. Prepare the card by opening the injector/ejector latches at the top and bottom of the card ([FIGURE 2-6](#)).

**FIGURE 2-6** RTM Injector/Ejector Latch and Locking Screw



7. **Carefully align the edges of the card with the card guides in the appropriate slot.**

It might be helpful to look into the enclosure to verify correct alignment of the rails in the guides.

8. **Taking care to keep the blade server aligned in the guides, slide the card in until the injector/ejector latches engage the card cage.**
9. **Push the blade server into the midplane connectors and close the latches to seat the blade server in the connectors.**
10. **Tighten the locking screws to ensure that the blade server is secured into the shelf.**
11. **Install the Sun Netra CP3060 blade server into the shelf.**

Go to [Section 2.5.2, “Installing the Sun Netra CP3060 Blade Server”](#) on page 2-15 for those instructions.

## 2.5.2 Installing the Sun Netra CP3060 Blade Server

1. **If you have installed a Sun Netra CP3060 RTM, go to the front of the system and locate the card slot where you installed the RTM at the rear of the system.**
2. **Remove the filler panel, if necessary.**


The filler panel is secured to the card cage using two screws, one at the top of the filler panel, the other at the bottom. Store the filler panel in a safe place; you might need to use it again if you have to remove a card for an extended period of time.

3. **Prepare the blade server by opening the injector/ejector latches ([FIGURE 2-6](#)).**
4. **Carefully align the edges of the blade server with the card guides in the appropriate slot ([FIGURE 2-7](#)).**

It might be helpful to look into the enclosure to verify correct alignment of the rails in the guides.

5. **Taking care to keep the blade server aligned in the guides, slide the blade server in until the injector/ejector latches engage the card cage.**


**FIGURE 2-7** Installing Node Blade Server Into Chassis Slot



6. Taking care to keep the blade server aligned in the guides, slide the blade server in until the injector/ejector latches engage the card cage.
7. Push the blade server slightly into the midplane connectors, and then close the latches to seat the blade server in the connectors ([FIGURE 2-8](#)).

When the lower latch is closed, the blue Hot-Swap LED blinks while the blade server is initializing. The blue LED turns off and the green OK LED lights when the blade server is ready.

**FIGURE 2-8** Sun Netra CP3060 Blade Server Latches and Locking Screws



8. Tighten the locking screws to ensure the blade server is secured into the shelf (see [FIGURE 2-6](#)).

---

## 2.6 Connecting External I/O Cables

External I/O cables are connected to the Sun Netra CP3060 blade server, or to the Sun Netra CP3060 RTM when a rear transition module is used. Information on connecting each of these cables follows:

- For Ethernet connections, category 5e or better network cable is required. One end of the Ethernet cable is connected to a suitable 10/100/1000BASE-T switch and the other end to one of the Ethernet ports on the Sun Netra CP3060 blade server. Both Ethernet ports A and B are available on the Sun Netra CP3060 blade server front panel.

**Note** – A single 10/100BASE-T Ethernet port is also available on the Sun Netra CP3060 RTM when installed.) Refer to the *Sun Netra CP3060 Rear Transition Module User's Guide* (819-6689) for more information.

Use the bge device names shown in [TABLE 2-2](#) when configuring the Ethernet ports.

**TABLE 2-2**    bge Device Names

Ethernet Ports	Solaris 10 OS
Ethernet Port A (on front panel) and Ethernet port on the RTM	e1000g0
Ethernet Port B (on front panel)	e1000g1

- An asynchronous serial I/O cable can be attached from serial communication devices to the RJ-45 serial port on the Sun Netra CP3060 blade server's front panel.

**Note** – A serial port is also provided on the Sun Netra CP3060 RTM. Either the serial port on the Sun Netra CP3060 blade server or the serial port on Sun Netra CP3060 RTM can be used, but only one of the ports should be used at one time.

Once a serial cable is connected, use the `tip` utility on the host to establish a full-duplex terminal connection with the Sun Netra CP3060 blade server. At the UNIX prompt in a command tool or shell tool, type:

**TABLE 2-3**

# <code>tip -9600 /dev/ttya</code> (for serial port)
--

## 2.7      Installation of Optional AMC Modules

An Advanced Mezzanine card (AMC) is a card or module that provides additional functionality to the Sun Netra CP3060 blade server. The blade server contains one AMC slot in which you can install an optional AMC device (see [FIGURE 2-1](#) for the location of these slots). The AMC device can be installed and removed via a cutout in the front panel while the Sun Netra CP3060 blade server is installed in the chassis.

## 2.7.0.1

### Installing an Optional AMC Module


---

**Note** – The following procedure provides a general set of instructions for installing AMC modules on the Sun Netra CP3060 blade server. Refer to the AMC module manufacturer's documentation for specific instructions on installing these devices.

---


1. Retrieve the wrist strap from the adapter's shipping kit.
2. Attach the adhesive copper strip of the antistatic wrist strap to the metal chassis. Wrap the other end twice around your wrist, with the adhesive side against your skin.
3. Remove the AMC slot filler panel from the blade server's front panel.  
([FIGURE 2-9](#)).

**FIGURE 2-9** Removing AMC Slot Filler Panel



4. Retrieve the AMC module from its shipping kit and place it on an antistatic surface.
5. Insert the AMC module through the cutout and into the AMC slot ([FIGURE 2-10](#)).

**FIGURE 2-10** Inserting AMC Module Into AMC Connector



**6. Carefully plug the AMC module into the AMC connector (FIGURE 2-10).**

Ensure that the AMC module is seated correctly in the connector.



---

**Caution** – Do not use excessive force when installing the AMC module into the slot. You might damage the AMC connector on the Sun Netra CP3060 blade server, causing permanent damage to the AMC module or the blade server. If the AMC module does not seat properly when you apply even pressure, remove the AMC module and carefully reinstall it.

---

**7. Refer to the AMC module documentation for software and cabling installation instructions.**







## Software Installation

---

This chapter contains the following sections:

- Section 3.1, “Operating Systems and Patches” on page 3-1
- Section 3.2, “Firmware Updates” on page 3-2
- Section 3.3, “Mandatory `/etc/system` File Entry” on page 3-2
- Section 3.4, “Installing Diskless Clients” on page 3-3
- Section 3.5, “Downloading and Installing SunVTS Software” on page 3-7

---

### 3.1 Operating Systems and Patches

The Sun Netra CP3060 blade server supports the Solaris 10 6/06 OS and subsequent compatible versions, with supported Netra patches. The Solaris OS software can be downloaded from the Sun download center at:

<http://www.sun.com/download>

---

**Note** – Refer to the *Sun Netra CP3060 Blade Server Product Notes* (819-4966) for information on the Netra patches at <http://www.sun.com/documentation>.

---

For information on these versions of the Solaris OS, including installation, see the appropriate Solaris Documentation Collection at the Sun Documentation web site at:

<http://www.sun.com/documentation>

---

## 3.2 Firmware Updates

The Sun Netra CP3060 firmware updates can be downloaded from the Sun download center at:

<http://www.sun.com/download>

---

**Note** – For information on firmware updates, refer to the *Sun Netra CP3060 Blade Server Product Notes* (819-4966) which are available online at

<http://www.sun.com/documentation>.

---

---

## 3.3 Mandatory /etc/system File Entry

A mandatory entry must be listed in the `/etc/system` file to ensure the optimal functionality of the blade server.

The following entry must be in the `/etc/system` file:

```
set pcie:pcie_aer_ce_mask=0x1
```

Check that the entry is present before deploying the blade server.

### ▼ To Check and Create the Mandatory /etc/system File Entry

1. Log in as superuser.

2. Check the `/etc/system` file to see if the mandatory line is present.

TABLE 3-1

# more /etc/system	
*ident	"@(#)system 1.18 05/06/27 SMI" /* SVR4 1.5 */
*	
* SYSTEM SPECIFICATION FILE	
.	
.	
.	
set	pcie:pcie_aer_ce_mask=0x1
.	

3. If the entry is not there, add it.

Use an editor to edit the `/etc/system` file and add the entry.

4. Reboot the server.



## 3.4 Installing Diskless Clients

The following procedures describe how to create a boot server for diskless clients and how to add new diskless clients to the patched boot server. For additional instructions on installing diskless clients, refer to the appropriate Solaris Documentation Collection at the Sun Documentation web site at:

<http://www.sun.com/documentation>

You must have a superuser password on your diskless server to perform the following tasks.

### 3.4.1 Creating a Boot Server for Diskless Clients

---

**Note** – This procedure sets up a boot server by starting the operating environment services required for diskless clients. Once you have set up the boot server, see [Section 3.4.2, “Adding a Diskless Client” on page 3-5](#) for instructions on adding diskless clients to the boot server.

---

1. Verify that the IP addresses for all other network interfaces on the boot server have corresponding hostnames in the hosts database.

2. Log in to the network server as superuser and change to the `/usr/sadm/bin` directory.

TABLE 1

```
# cd /usr/sadm/bin
```

3. Use the `smosservice` command to add boot services to the installation server.

---

**Note** – The following command is a single long entry. Do not press the Return key until you have typed the entire text string shown in the following command.

---

TABLE 2

```
# ./smosservice add -u root -p root_password -- -x mediapath=image_directory  
-x platform=sparc.sun4v.Solaris_n -x cluster=SUNWCXall -x locale=locale
```

Where:

- `root_password` is the root password for the installation server
- `image_directory` is the path to the directory where the Solaris install image is stored
- `N` is the Solaris OS version you are using.
- `locale` is the locale that you want to use

Refer to the `smosservice(1M)` man page for more information and options.

For example:

TABLE 3

```
# ./smosservice add -u root -p root_password -- -x mediapath=/export/install  
-x platform=sparc.sun4v.Solaris_10 -x cluster=SUNWCXall -x locale=en_US
```

Where:

- `root_password` = `root_password`
- `image_directory` = `/export/install`
- `locale` = `en_US`
- `n` = 10 (for Solaris 10)

#### 4. Download and install additional patches.

Refer to the *Sun Netra CP3060 Blade Server Product Notes* (819-4966) for the latest information on the patches available for the Sun Netra CP3060 blade server. The document can be downloaded from the following web site:

<http://www.sun.com/documentation>

Follow the instructions in the *Sun Netra CP3060 Blade Server Product Notes* (819-4966) for downloading and applying patches to a diskless clients boot server.

#### 5. After the patches are installed, follow the procedure in [Section 3.4.2, “Adding a Diskless Client”](#) on page 3-5.

## 3.4.2 Adding a Diskless Client

#### 1. Prepare a patched boot server for the diskless clients.

Follow the steps in [Section 3.4.1, “Creating a Boot Server for Diskless Clients”](#) on page 3-3 to create a boot server for the diskless clients.

#### 2. Log in to the patched boot server as superuser.

#### 3. Collect the following information for the diskless client you are adding:

- Client’s IP address
- Client’s Ethernet address
- Client’s host name

#### 4. Change directories to the `/usr/sadm/bin` directory.

TABLE 4

```
# cd /usr/sadm/bin
```

#### 5. Set up the diskless clients.

For each diskless client, type the following command as superuser:

TABLE 5

```
# ./smdiskless add -- -i ip_address -e ethernet_address -n host_name \
-x os=sparc.sun4v.Solaris_n -x root=/export/root/host_name \
-x swap=/export/swap/host_name -x swapsize=swap_size -x tz=time_zone \
-x locale=locale -x ns=name_service -x nameserver=name_server
```

Where:

- `ip_address` is the client’s IP address
- `ethernet_address` is the client’s Ethernet address

- *host\_name* is the client's host name
- *n* is the Solaris OS version you are using, either 10 or 9.
- *swap\_size* is the size of the swap space that you will be using. The default is 24, however your swap space should be the same amount as your memory
- *time\_zone* is the client's time zone
- *locale* is the client's locale
- *name\_service* is the client's nameservice
- *name\_server* is the nameserver's hostname

Refer to the `smdiskless(1M)` man page for more information and options.

For example:

TABLE 6

```
# ./smdiskless add -- -i 129.144.214.999 -e 8:0:20:22:b3:aa -n client_host -x
os=sparc.sun4v.Solaris_10 -x root=/export/root/client_host -x swap=
/export/swap/client_host -x swaptsize=999 -x tz=US/Pacific -x locale=en_US -x
ns=NIS -x nameserver=nameserver_host
```

Where:

- *ip\_address* = 129.144.214.999
- *ethernet\_address* = 8:0:20:22:b3:aa
- *host\_name* = client\_host
- *n* = 10 (for Solaris 10)
- *swap\_size* = 128
- *time\_zone* = US/Pacific
- *locale* = en\_US
- *name\_service* = NIS
- *name\_server* = nameserver\_host

You must type your superuser password again after typing this command. The installation process should take roughly 5 minutes per client and about 15-30 minutes for the operating environment service to install; however, no progress is displayed on screen while the process is running. Do not cancel or kill the process until the process has successfully completed.

You should see messages similar to the following after a few moments, confirming that the command went through successfully the second time:

**TABLE 7**

Login to client_host as user root was successful. Download of com.sun.admin.osservermgr.cli.OsServerMgrCli from client_host was successful.
--

#### **6. Boot the diskless client.**

---

## **3.5 Downloading and Installing SunVTS Software**

SunVTS™ software is a comprehensive suite that tests and validates the Sun Netra CP3060 blade server by verifying the configuration and function of most hardware controllers and devices on the blade server. SunVTS software is used to validate a system during development, production, inspection, troubleshooting, periodic maintenance, and system or subsystem stressing. SunVTS software can be tailored to run on machines ranging from desktops to servers with modifiable test instances and processor affinity features.

You can perform high-level system testing by using the appropriate version of SunVTS software. For detailed information on SunVTS support and downloads, refer to the following web site:

<http://www.sun.com/oem/products/vts/>

Ensure that the SunVTS software version is compatible with the Solaris OS version being used. Information on the version of the SunVTS software installed can be found in the file:

`/opt/SUNWvts/bin/.version`

For the latest version of SunVTS document, go to:

<http://www.sun.com/documentation>



---

**Note** – For security reasons, only a superuser is permitted to run SunVTS software. Installation and starting instructions are included with the software when it is downloaded.

---

# Firmware and Blade Server Management

---

This chapter contains the following sections:

- [Section 4.1, “System Firmware” on page 4-1](#)
- [Section 4.2, “Power-On Self-Test Diagnostics” on page 4-2](#)
- [Section 4.3, “OpenBoot Firmware” on page 4-3](#)
- [Section 4.4, “Error Handling Summary” on page 4-12](#)
- [Section 4.5, “Automatic System Recovery” on page 4-13](#)
- [Section 4.6, “Hot-Swap Information” on page 4-15](#)
- [Section 4.7, “Network Device Aliases” on page 4-17](#)
- [Section 4.8, “Retrieving Device Information” on page 4-17](#)

---

## 4.1 System Firmware

The Sun Netra CP3060 blade server contains a modular firmware architecture that gives you latitude in controlling boot initialization. You can customize the initialization, test the firmware, and even enable the installation of a custom operating system.

This platform also employs the Intelligent Platform Management controller (IPMC)—described in [Section 5.1.6, “Intelligent Platform Management Controller” on page 5-19](#)—which controls the system management, hot-swap control, and some blade server hardware. The IPMC configuration is controlled by separate firmware.

The Sun Netra CP3060 blade server boots from the 4-Mbyte system flash PROM device that includes the power-on self-test (POST) and OpenBoot™ firmware.

---

## 4.2 Power-On Self-Test Diagnostics

Power-on self-test (POST) is a firmware program that helps determine whether a portion of the system has failed. POST verifies the core functionality of the system, including the CPU modules, motherboard, memory, and some on-board I/O devices. The software then generates messages that can be useful in determining the nature of a hardware failure. POST can run even if the system is unable to boot.

If POST detects a faulty component, it is disabled automatically, preventing faulty hardware from potentially harming any software. If the system is capable of running without the disabled component, the system boots when POST is complete. For example, if one of the processor cores is deemed faulty by POST, the core is disabled, and the system boots and runs using the remaining cores.

POST diagnostic and error message reports are displayed on a console.

### 4.2.1 POST Test Coverage

The POST diagnostics include the following tests:

1. UltraSPARC T1 Processor Tests:
    - MMU (Memory Management Unit), all cores
      - DMMU TLBs: tags, data RAM tests
      - IMMU TLBs: tags, data RAM tests
    - Caches, all cores
      - L2 Cache
      - L1 Icache
      - L1 Dcache
    - FPU (Floating Point Unit)
      - Functional
      - Register
    - Interrupts
  2. Memory Tests (up to 2-Gbyte/DIMM):
    - SDRAM data line test
    - SDRAM address line test
    - SDARM cell integrity Test
    - MOVing inversions memory test
  3. POST Image Tests
    - POST PROM checksum test
    - POST memory checksum test
  4. ECC Error Test
-

- 
- 5. XBUS SRAM Test
  - 6. JBus-to-PCIE Bridge Tests:
    - Internal registers test JBus interrupts
    - JBus interrupts
    - PCI-E MSI Interrupts test
    - PLX Interconnect test
    - PCI DMA tests
    - JBus-to-PCI-E loop-back test
  - 7. PCIE Tests:
    - Verify PCI-E Bus configuration
    - Verify VID/DIC registers for all onboard PCI device
    - Verify link status of all onboard PCI-E channel

## 4.2.2 POST Diagnostic and Error Message Format

POST diagnostic and error messages are displayed on a console. The format of the these messages is the following:

```
Core-ID:Strand-ID ERROR: TEST = test-name
Core-ID:Strand-ID H/W under test = description
Core-ID:Strand-ID Repair Instruction
Core-ID:Strand-ID MSG = error-message-body
Core-ID:Strand-ID END_ERROR
```

The following is an example of a POST error message

**TABLE 4-1**

<pre>3:2&gt;ERROR: TEST = L2-Cache Functional 3:2&gt;H/W under test = Core 12 Cache 3:2&gt;Repair Instructions: Replace items in order listed by 'H/W under test' above. 3:2&gt;MSG = No way found to match tag address 00000000.00600000, state 3 3:2&gt;END_ERROR</pre>
---

---

## 4.3 OpenBoot Firmware

The Solaris OS installed operates at different run levels. For a full description of run levels, refer to the Solaris system administration documentation.

Most of the time, the OS operates at run level 2 or run level 3, which are multiuser states with access to full system and network resources. Occasionally, you might operate the system at run level 1, which is a single-user administrative state. However, the lowest operational state is run level 0.

When the OS is at run level 0, the `ok` prompt appears. This prompt indicates that the OpenBoot™ firmware is in control of the system.

There are a number of scenarios under which OpenBoot firmware control can occur.

By default, before the operating system is installed the system comes up under OpenBoot firmware control.

- When the auto-boot? OpenBoot configuration variable is set to false, the system boots to the `ok` prompt.
- When the operating system is halted, the system transitions to run level 0 in an orderly way.
- When the operating system crashes, the system reverts to OpenBoot firmware control.
- During the boot process, when there is a serious hardware problem that prevents the operating system from running, the system reverts to OpenBoot firmware control.
- When a serious hardware problem develops while the system is running, the operating system transitions smoothly to run level 0.
- When the OS is deliberately placed under the OpenBoot firmware control in order to execute firmware-based commands.

## 4.3.1 Getting to the `ok` Prompt

There are different ways of reaching the `ok` prompt. The methods are not equally desirable. See [TABLE 4-2](#) for details.

**TABLE 4-2** Ways of Accessing the `ok` Prompt

Access Method	What to Do
Graceful shutdown of the Solaris OS	From a shell or command tool window, issue an appropriate command (for example, the <code>shutdown</code> or <code>init</code> command) as described in Solaris system administration documentation.
Manual system reset	Setting the OBP <code>auto-boot</code> variable to <code>false</code> causes the system to stop at the <code>ok?</code> prompt the next time the blade server is reset.



---

**Caution** – Obtaining the `ok` prompt suspends all application and operating system software. After you issue firmware commands and run firmware-based tests from the `ok` prompt, the system might not be able to resume where it left off.

---

If possible, back up system data before starting accessing the `ok` prompt. Also exit or stop all applications, and warn users of the impending loss of service. For information about the appropriate backup and shutdown procedures, see Solaris system administration documentation.

## 4.3.2 Auto-Boot Options

The system firmware stores a configuration variable called `auto-boot?`, which controls whether the firmware will automatically boot the operating system after each reset. The default setting for Sun platforms is `true`.

Normally, if a system fails power-on diagnostics, `auto-boot?` is ignored and the system does not boot unless an operator boots the system manually. An automatic boot is generally not acceptable for booting a system in a degraded state. Therefore, the Sun Netra CP3060 server OpenBoot firmware provides a second setting, `auto-boot-on-error?`. This setting controls whether the system will attempt a degraded boot when a subsystem failure is detected. Both the `auto-boot?` and `auto-boot-on-error?` switches must be set to `true` to enable an automatic degraded boot. To set the switches, type:

```
ok setenv auto-boot? true
ok setenv auto-boot-on-error? true
```

---

**Note** – The default setting for `auto-boot-on-error?` is `false`. The system will not attempt a degraded boot unless you change this setting to `true`. In addition, the system will not attempt a degraded boot in response to any fatal nonrecoverable error, even if degraded booting is enabled. For examples of fatal nonrecoverable errors, see [“OpenBoot Configuration Variables” on page 9](#).

---

## 4.3.3 OpenBoot Commands

You type the OpenBoot commands at the `ok` prompt. Two of the OpenBoot commands that can provide useful diagnostic information include:

- `probe-ide`

#### ■ show-devs

For a complete list of OpenBoot commands and more information about the OpenBoot firmware, refer to the *OpenBoot 4.x Command Reference Manual*. An online version of the manual is included with the OpenBoot Collection AnswerBook that ships with Solaris software.

### 4.3.3.1 probe-ide Command

The probe-ide command communicates with all Integrated Drive Electronics (IDE) devices connected to the IDE bus. This is the internal system bus for media devices such as the DVD drive.



---

**Caution** – If you used the halt command or the Stop-A key sequence to reach the ok prompt, issuing the probe-ide command can hang the system.

---

[CODE EXAMPLE 4-2](#) shows sample output from the probe-ide command.

#### **CODE EXAMPLE 4-1** probe-ide Command Output

```
{0} ok probe-ide
Device 0 ( Primary Master )
      ATA Model: FUJITSU MHV2040BH

Device 1 ( Primary Slave )
      ATA Model:

Device 2 ( Secondary Master )
      Not Present

Device 3 ( Secondary Slave )
      Not Present
```

### 4.3.3.2 show-devs Command

The show-devs command lists the hardware device paths for each device in the firmware device tree. [CODE EXAMPLE 4-2](#) shows some sample output.

#### **CODE EXAMPLE 4-2** show-devs Command Output

```
{o} ok show-devs
/pci@7c0
/pci@780
/cpu@17
```

**CODE EXAMPLE 4-2** show-devs Command Output (*Continued*)

```
/cpu@16
/cpu@15
/cpu@14
/cpu@13
/cpu@12
/cpu@11
/cpu@10
/cpu@f
/cpu@e
/cpu@d
/cpu@c
/cpu@b
/cpu@a
/cpu@9
/cpu@8
/cpu@7
/cpu@6
/cpu@5
/cpu@4
/cpu@3
/cpu@2
/cpu@1
/cpu@0
/virtual-devices@100
/virtual-memory
/memory@m0,800000
/aliases
/options
/openprom
/chosen
/packages
/pci@7c0/network@0,1
/pci@7c0/network@0
/pci@780/pci@0
/pci@780/pci@0/pci@9
/pci@780/pci@0/pci@8
/pci@780/pci@0/pci@2
/pci@780/pci@0/pci@1
/pci@780/pci@0/pci@2/network@0,1
/pci@780/pci@0/pci@2/network@0
/pci@780/pci@0/pci@1/pci@0
/pci@780/pci@0/pci@1/pci@0/ide@1f,1
/pci@780/pci@0/pci@1/pci@0/ide@1f
```



**CODE EXAMPLE 4-2** show-devs Command Output (*Continued*)

```
/pci@780/pci@0/pci@1/pci@0/ide@1f,1/cdrom
/pci@780/pci@0/pci@1/pci@0/ide@1f,1/disk
/pci@780/pci@0/pci@1/pci@0/ide@1f/cdrom
/pci@780/pci@0/pci@1/pci@0/ide@1f/disk
/virtual-devices@100/ipmi@f
/virtual-devices@100/flashupdate@e
/virtual-devices@100/led@d
/virtual-devices@100/explorer@c
/virtual-devices@100/sunmc@b
/virtual-devices@100/sunvts@a
/virtual-devices@100/fma@9
/virtual-devices@100/echo@8
/virtual-devices@100/loop@6
/virtual-devices@100/loop@7
/virtual-devices@100/rtc@5
/virtual-devices@100/ncp@4
/virtual-devices@100/console@1
/virtual-devices@100/flashprom@0
/virtual-devices@100/nvram@3
/openprom/client-services
/packages/SUNW,asr
/packages/obp-tftp
/packages/dropins
/packages/terminal-emulator
/packages/disk-label
/packages/deblocker
/packages/SUNW,builtin-drivers
{0} ok
```

### 4.3.3.3 Checking Network Using watch-net and watch-net-all Commands

The watch-net diagnostics test monitors Ethernet packets on the primary network interface. The watch-net-all diagnostics test monitors Ethernet packets on the primary network interface and on any additional network interfaces connected to the system blade server. Good packets received by the system are indicated by a period (.). Errors such as the framing error and the cyclic redundancy check (CRC) error are indicated with an X and an associated error description.

- To start the `watch-net` diagnostic test, type the `watch-net` command at the `ok` prompt.

```
{0} ok watch-net
Internal loopback test -- succeeded.
Link is -- up
Looking for Ethernet Packets.
`.` is a Good Packet. `X` is a Bad Packet.
Type any key to stop.....
```

- To start the `watch-net-all` diagnostic test, type `watch-net-all` at the `ok` prompt.

```
{0} ok watch-net-all
/pci@1f,0/pci@1,1/network@c,1
Internal loopback test -- succeeded.
Link is -- up
Looking for Ethernet Packets.
`.` is a Good Packet. `X` is a Bad Packet.
Type any key to stop.
```

## 4.3.4 OpenBoot Configuration Variables

The OpenBoot configuration variables are stored in the OBP flash PROM and determine how and when OpenBoot tests are performed. This section explains how to access and modify OpenBoot configuration variables. For a list of important OpenBoot configuration variables, see [TABLE 4-3](#).

Changes to OpenBoot configuration variables take effect at the next reboot.

**TABLE 4-3** OpenBoot Configuration Variables

Variable	Possible Values	Default Value	Description
<code>local-mac-address?</code>	<code>true</code> , <code>false</code>	<code>true</code>	If <code>true</code> , network drivers use their own MAC address, not the server MAC address.

**TABLE 4-3** OpenBoot Configuration Variables (Continued)

Variable	Possible Values	Default Value	Description
fcode-debug?	true, false	false	If true, include name fields for plug-in device FCodes.
scsi-initiator-id	0-15	7	SCSI ID of the Serial Attached SCSI controller.
oem-logo?	true, false	false	If true, use custom OEM logo; otherwise, use Sun logo.
oem-banner?	true, false	false	If true, use custom OEM banner.
ansi-terminal?	true, false	true	If true, enable ANSI terminal emulation.
screen-#columns	0-n	80	Sets number of columns on screen.
screen-#rows	0-n	34	Sets number of rows on screen.
ttya-mode	9600,8,n,1,-	9600,8,n,1,-	Serial management port (baud rate, bits, parity, stop, handshake). The serial management port only works at the default values.
output-device	virtual-console, screen	virtual-console	Power-on output device.
input-device	virtual-console, keyboard	virtual-console	Power-on input device.
auto-boot-on-error?	true, false	false	If true, boot automatically after system error.
load-base	0-n	16384	Address.
auto-boot?	true, false	true	If true, boot automatically after power on or reset.
network-boot-arguments	[ <i>protocol</i> , ] [ <i>key=value</i> , ]	none	Arguments to be used by the PROM for network booting. Defaults to an empty string. <i>network-boot-arguments</i> can be used to specify the boot protocol (RARP/DHCP) to be used and a range of system knowledge to be used in the process. For further information, see the <i>eeeprom (1M)</i> man page or your Solaris Reference Manual.
boot-command	<i>variable-name</i>	boot	Action following a boot command.
boot-file	<i>variable-name</i>	none	File from which to boot if <i>diag-switch?</i> is false.
boot-device	<i>variable-name</i>	disk net	Device(s) from which to boot if <i>diag-switch?</i> is false.

**TABLE 4-3** OpenBoot Configuration Variables (*Continued*)

Variable	Possible Values	Default Value	Description
use-nvramrc?	true, false	false	If true, execute commands in NVRAMRC during server startup.
nvramrc	<i>variable-name</i>	none	Command script to execute if use-nvramrc? is true.
security-mode	none, command, full	none	Firmware security level.
security-password	<i>variable-name</i>	none	Firmware security password if security-mode is not none (never displayed). <i>Do not set this directly.</i>
security-#badlogins	<i>variable-name</i>	none	Number of incorrect security password attempts.
verbosity	max, min, none, normal	min	Controls the amount and detail of OpenBoot output. Default is min. <ul style="list-style-type: none"> <li>• none – Only error and fatal messages are displayed on the system console.</li> <li>• min – Notice, error, warning, and fatal messages are displayed on the system console.</li> <li>• normal – Summary progress and operational messages are displayed on the system console in addition to the messages displayed by the min setting.</li> <li>• max – Detailed progress and operational messages are displayed on the system console.</li> </ul>
diag-switch?	true, false	false	If true: <ul style="list-style-type: none"> <li>• After a boot request, boot <i>diag-file</i> from <i>diag-device</i></li> </ul> If false: <ul style="list-style-type: none"> <li>• After a boot request, boot <i>boot-file</i> from <i>boot-device</i></li> </ul>
error-reset-recovery	boot, none, sync	boot	Specifies recovery action after an error reset. Default is boot. <ul style="list-style-type: none"> <li>• none – No recovery action.</li> <li>• boot – System attempts to boot.</li> <li>• sync – Firmware attempts to execute a Solaris sync callback routine.</li> </ul>

### 4.3.4.1 Viewing and Setting OpenBoot Configuration Variables

- **Halt the server to display the `ok` prompt.**
- To display the current values of all OpenBoot configuration variables, use the `printenv` command.

The following example shows a short excerpt of this command's output.

TABLE 4-4

ok <b>printenv</b>		
Variable Name	Value	Default Value
local-mac-address?	true	true
fcode-debug?	false	false
scsi-initiator-id	7	7
oem-logo?	false	false
boot-command	boot	boot
boot-file		
boot-device	disk net	disk net
use-nvramrc?	false	false
nvramrc		

- To set or change the value of an OpenBoot configuration variable, use the `setenv` command:

TABLE 4-5

ok <b>setenv error-reset-recovery none</b>
error-reset-recovery = none

- To set OpenBoot configuration variables that accept multiple keywords, separate keywords with a space.

---

## 4.4 Error Handling Summary

Error handling during the power-on sequence falls into one of the following three cases:

- If no errors are detected by POST or OpenBoot firmware, the system attempts to boot if `auto-boot?` is true.
- If only nonfatal errors are detected by POST or OpenBoot firmware, the system attempts to boot if `auto-boot?` is true and `auto-boot-on-error?` is true. Nonfatal errors include the following:

- SATA subsystem failure. In this case, a working alternate path to the boot disk is required.
- Ethernet interface failure.
- Serial interface failure.
- Memory failure. Given a failed DIMM, the firmware will unconfigure the entire logical bank associated with the failed module. Another nonfailing logical bank must be present in the system for the system to attempt a degraded boot.

---

**Note** – If POST or OpenBoot firmware detects a nonfatal error associated with the normal boot device, the OpenBoot firmware automatically unconfigures the failed device and tries the next-in-line boot device, as specified by the `boot-device` configuration variable.

---

- If a fatal error is detected by POST or OpenBoot firmware, the system does not boot regardless of the settings of `auto-boot?` or `auto-boot-on-error?`. Fatal nonrecoverable errors include the following:
  - Any CPU failed
  - All logical memory banks failed
  - Flash RAM cyclical redundancy check (CRC) failure
  - Critical field-replaceable unit (FRU) PROM configuration data failure
  - Critical application-specific integrated circuit (ASIC) failure

---

## 4.5 Automatic System Recovery

Automatic system recovery (ASR) consists of self-test features and an autoconfiguration capability to detect failed hardware components and unconfigure them. By enabling ASR, the server is able to resume operating after certain nonfatal hardware faults or failures have occurred.

If a component is monitored by ASR and the server is capable of operating without it, the server automatically reboots if that component develops a fault or fails. This capability prevents a faulty hardware component from stopping operation of the entire system or causing the system to fail repeatedly.

If a fault is detected during the power-on sequence, the faulty component is disabled. If the system remains capable of functioning, the boot sequence continues.

To support this degraded boot capability, the OpenBoot firmware uses the 1275 client interface (by means of the device tree) to mark a device as either *failed* or *disabled*, creating an appropriate status property in the device tree node. The Solaris OS does not activate a driver for any subsystem marked in this way.

As long as a failed component is electrically dormant (not causing random bus errors or signal noise, for example), the system reboots automatically and resumes operation while a service call is made.

Once a failed or disabled device is replaced with a new one, the OpenBoot firmware automatically modifies the status of the device upon reboot.

---

**Note** – ASR is not enabled until you activate it (see [Section 4.5.1.1, “To Enable Automatic System Recovery” on page 4-14](#)).

---

## 4.5.1 Enabling and Disabling Automatic System Recovery

The automatic system recovery (ASR) feature is not activated until you enable it. Enabling ASR requires changing configuration variables in ALOM as well as OpenBoot.

### 4.5.1.1 To Enable Automatic System Recovery

1. At the `ok` prompt, type:

```
ok setenv auto-boot true  
ok setenv auto-boot-on-error? true
```

2. To cause the parameter changes to take effect, type:

TABLE 4-6

```
ok reset-all
```

The system permanently stores the parameter changes and boots automatically when the OpenBoot configuration variable `auto-boot?` is set to `true` (its default value).

---

**Note** – To store parameter changes, you can also power cycle the system using the front panel Power button.

---

### 4.5.1.2 To Disable Automatic System Recovery

1. At the `ok` prompt, type:

```
ok setenv auto-boot-on-error? false
```

2. To cause the parameter changes to take effect, type:

TABLE 4-7

```
ok reset-all
```

The system permanently stores the parameter change.

---

**Note** – To store parameter changes, you can also power cycle the system using the front panel Power button.

---

After you disable the automatic system recovery (ASR) feature, it is not activated again until you re-enable it.

---

## 4.6 Hot-Swap Information

The Sun Netra CP3060 blade server supports hot-swapping and includes a blue Hot-Swap LED.

### 4.6.1 Hot-Swapping the Sun Netra CP3060 Blade Server

If the Solaris OS is running on a Sun Netra CP3060 blade server and you open the blade server's latches, you see a message that the operating system will shut down in one minute. When the blue LED on the blade server lights steadily, you can safely remove the blade server.




### 4.6.1.1 Hot-Swap LED

The blue Hot-Swap LED, located on the front panel of the Sun Netra CP3060 blade server (FIGURE 1-1), blinks when a hot-swap is initiated, and lights steadily when the blade server is ready to be removed from the system.

Unlatching the bottom latch on the Sun Netra CP3060 blade server initiates the hot-swap sequence. The LED lights steadily when the blade server can be safely removed from the system. The reverse is true when a Sun Netra CP3060 blade server is installed into the system. Once the Sun Netra CP3060 blade server is installed into the system and the bottom latch is latched, the blue Hot-Swap LED blinks until the blade server is ready and then turns off. The green LED lights steadily when the blade server is ready.

FIGURE 4-1 shows the hot-swap latch and Hot-Swap LED.

**FIGURE 4-1** Hot-Swap Latch and Hot-Swap LED



## 4.7 Network Device Aliases

A device alias is a shorthand representation of a *device path*. The Solaris OS provides some predefined device aliases for the network devices so that you do not need to type the full device path name. [TABLE 4-8](#) lists the network device aliases, the default Solaris OS device names, and associated ports for the Sun Netra CP3060 blade server. The `devalias` command can be used to display the device aliases.

**TABLE 4-8** Network Device Aliases

Device Alias	Default Solaris 10 OS Device Name	Port
net, net0	e1000g0	Base Interface Ethernet A, Management Ethernet A (Ethernet port A on front panel), RTM Ethernet port
net1	e1000g1	Base Interface Ethernet B, Management Ethernet A (Ethernet port A on front panel)
net2	e1000g2	Extended Interface Ethernet A (PICMG 3.1)
net3	e1000g3	Extended Interface Ethernet B (PICMG 3.1)

## 4.8 Retrieving Device Information

You use the Solaris platform information and control library (PICL) framework for obtaining the state and condition of the Sun Netra CP3060 blade server.

The PICL framework provides information about the system configuration that it maintains in the PICL tree. Within this PICL tree is a subtree named *frutree*, which represents the hierarchy of system field-replaceable units (FRUs) with respect to a root node in the tree called *chassis*. The *frutree* represents physical resources of the system. The PICL tree is updated whenever a change occurs in a device's status.

TABLE 4-9 shows the frutree entries and properties that describe the condition of the Sun Netra CP3060 blade server.

**TABLE 4-9** PICL Frutree Entries and Description for the Sun Netra CP3060 Blade Server

Frutree Entry:Property	Entry Description	Example of Condition
CPU (location) :State	State of the receptacle or slot	connected
CPU (fru) :Condition	Condition of the blade server or occupant	ok
CPU (fru) :State	State of the blade server or occupant	configured
CPU (fru) :FRUType	FRU type	bridge/fhs

The `prtpicl -v` command shows the condition of all devices in the PICL tree. Sample output from the `prtpicl` command on the Sun Netra CP3060 blade server is shown in [CODE EXAMPLE 4-3](#).

**CODE EXAMPLE 4-3** `prtpicl` Command Output

```
# prtpicl
/ (picl, 5a00000001)
  platform (sun4v, 5a00000005)
    scsi_vhci (devctl, 5a00000021)
    memory (obp-device, 5a000000cf)
    virtual-devices (virtual-devices, 5a000000e1)
      nvram (nvram, 5a000000f4)
      flashprom (obp-device, 5a000000fc)
      console (serial, 5a00000103)
      ncp (obp-device, 5a00000113)
      rtc (obp-device, 5a00000120)
      loop (obp-device, 5a00000128)
      loop (obp-device, 5a00000138)
      echo (obp-device, 5a00000148)
      fma (obp-device, 5a00000158)
      sunvts (obp-device, 5a00000168)
      sunmc (obp-device, 5a00000178)
      explorer (obp-device, 5a00000188)
      led (obp-device, 5a00000198)
      ipmi (obp-device, 5a000001a8)
    cpu (cpu, 5a000001b8)
    cpu (cpu, 5a000001c6)
    cpu (cpu, 5a000001d4)
    cpu (cpu, 5a000001e2)
    cpu (cpu, 5a000001f0)
    cpu (cpu, 5a000001fe)
```

**CODE EXAMPLE 4-3** prtpicl Command Output (*Continued*)

```
cpu (cpu, 5a0000020c)
cpu (cpu, 5a0000021a)
cpu (cpu, 5a00000228)
cpu (cpu, 5a00000236)
cpu (cpu, 5a00000244)
cpu (cpu, 5a00000252)
cpu (cpu, 5a00000260)
cpu (cpu, 5a0000026e)
cpu (cpu, 5a0000027c)
cpu (cpu, 5a0000028a)
cpu (cpu, 5a00000298)
cpu (cpu, 5a000002a6)
cpu (cpu, 5a000002b4)
cpu (cpu, 5a000002c2)
cpu (cpu, 5a000002d0)
cpu (cpu, 5a000002de)
cpu (cpu, 5a000002ec)
cpu (cpu, 5a000002fa)
pci (pciex, 5a00000308)
  pci (pciex, 5a0000032a)
    pci (pciex, 5a00000347)
      pci (pciex, 5a00000363)
        ide (ide, 5a00000384)
        ide (ide, 5a000003a8)
        dad (block, 5a000003d3)
      pci (pciex, 5a000003ea)
        network (network, 5a00000407)
        network (network, 5a00000438)
      pci (pciex, 5a00000455)
      pci (pciex, 5a0000046f)
    pci (pciex, 5a00000487)
      network (network, 5a000004a7)
      network (network, 5a000004c4)
  pseudo (devctl, 5a000004f6)
obp (picl, 5a0000001e)
ib (ib, 5a00000032)
packages (packages, 5a0000003e)
  SUNW,builtin-drivers (SUNW,builtin-drivers, 5a00000044)
  deblocker (deblocker, 5a0000004a)
  disk-label (disk-label, 5a00000051)
  terminal-emulator (terminal-emulator, 5a00000057)
  dropins (dropins, 5a0000005e)
  obp-tftp (obp-tftp, 5a00000065)
```

**CODE EXAMPLE 4-3** prtpicl Command Output (Continued)

```
SUNW,asr (SUNW,asr, 5a0000006b)
ufs-file-system (ufs-file-system, 5a00000072)
chosen (chosen, 5a00000079)
openprom (openprom, 5a00000086)
client-services (client-services, 5a00000090)
options (options, 5a00000096)
aliases (aliases, 5a000000be)
virtual-memory (virtual-memory, 5a000000d7)
iscsi (iscsi, 5a000004e1)
```

For more information on the PICL framework, refer to the `picld(1M)` man page.

## 4.9 Mandatory `/etc/system` File Entry

A mandatory entry must be listed in the `/etc/system` file to ensure the optimal functionality of the server.

The following entry must be in the `/etc/system` file:

```
set pcie:pcie_aer_ce_mask=0x1
```

Check that the entry is present before deploying the server.

### ▼ To Check and Create the Mandatory `/etc/system` File Entry

1. Log in as superuser.
2. Check the `/etc/system` file to see if the mandatory line is present.

**TABLE 4-10**

```
# more /etc/system
*ident  "@(#)system      1.18 05/06/27 SMI" /* SVR4 1.5 */
*
*  SYSTEM SPECIFICATION FILE
*
*
set pcie:pcie_aer_ce_mask=0x1
.
```

**3. If the entry is not there, add it.**

Use an editor to edit the `/etc/system` file and add the entry.

**4. Reboot the server.**



# Hardware and Functional Descriptions

---

This chapter contains the following sections:

- [Section 5.1, “Hardware Architecture” on page 5-1](#)
- [Section 5.2, “Power-on Sequence” on page 5-26](#)
- [Section 5.3, “Power” on page 5-27](#)

---

## 5.1 Hardware Architecture

The Sun Netra CP3060 blade server is an ATCA node blade server based on the UltraSPARC T1 processor. It is hot-swappable to an ATCA midplane and supports two 1000BASE-T Ethernet interfaces as Base interface and two 1000 SERDES Ethernet interfaces as Extended interface to support redundant Dual Star topology.

The Sun Netra CP3060 blade server supports eight standard DDR-2 Very low profile (VLP) DIMMs, which can support the maximum memory of 16 Gbytes.

The I/O subsystem is designed around the JBus-to-PCI-E ASIC which is the bridge between the processor bus (JBus) and the PCI-E links. The JBus-to-PCI-E bridge has one PCI-E x4 link (Leaf A) and one PCI-E x8 link (Leaf B). Leaf A is wired to a gigabit Ethernet controller which provides the SERDES Extended interface. Leaf B is wired to the PCI-E switch ASIC (PLX8532) and provides the Base interface.

The PCI-E switch ASIC on Leaf B connects to the Southbridge, the AMC slot, the Zone 3 RTM connector, and a gigabit Ethernet controller for the Base interface and maintenance ports.

The Southbridge has a built-in IDE controller that provides support for Compact Flash, and a SATA controller with four 3-Gbps SATA ports, of which two are connected to the AMC connector and the two are connected to the Zone 3 RTM connector.




The BMR-H8S IPM Controller (IPMC) monitors all the critical functions of the blade server and responds to commands from the shelf manager controller (ShMC) and reports events. BMR-H8S uses a serial connection to communicate with the host CPU through the service processor (MPC)/Field-Programmable Gate Array (FPGA).

The ATCA backplane provides redundant –48V power connection and the Sun Netra CP3060 blade server derives the necessary power by using DC-DC converters. Standby power is generated separately from –48V and provided for hardware management circuitry.

The BMR-H8S IPMC subsystem and the FPGA are powered from standby power.

**FIGURE 5-1** is a block diagram of the Sun Netra CP3060 blade server.

**FIGURE 5-1** Block Diagram



## 5.1.1 UltraSPARC T1 Processor

This section provides a brief description of the salient features of the UltraSPARC T1 processor, its package, and its socket.


### 5.1.1.1 Overview

The UltraSPARC T1 multicore processor is the basis of the Sun Netra CP3060 blade server. The UltraSPARC T1 processor is based on chip multithreading (CMT) technology that is optimized for highly threaded transactional processing. The UltraSPARC T1 processor improves throughput while using less power and dissipating less heat than conventional processor designs.

Depending on the model purchased, the processor has four, six, or eight UltraSPARC cores. Each core equates to a 64-bit execution pipeline capable of running four threads. The result is that the 8-core processor handles up to 32 active threads concurrently.

Additional processor components, such as L1 cache, L2 cache, memory access crossbar, DDR2 memory controllers, and a JBus I/O interface have been carefully tuned for optimal performance. See [FIGURE 5-2](#).

The CPU is a high-performance, highly integrated superscaler UltraSPARC T1 processor implementing the 64-bit SPARC-V9 RISC architecture. It contains a 128-Kbyte instruction cache and 64-Kbyte data cache. The chip has an inbuilt 3-Mbyte L2 cache that uses a 32-byte cache line.



**FIGURE 5-2** UltraSPARC T1 Multicore Processor Block Diagram

### 5.1.1.2 Cores and Cache

Each of the 8 SPARC cores has support for 4 threads, for a total of 32 threads. This support consists of a full register file per thread, with most ASI, ASR, and privileged registers replicated per thread. The 4 threads share the instruction cache, data cache, and TLBs. Each TLB is 64 entry.

Each core then has 16 Kbytes of primary Instruction Cache (I-cache) and 8 Kbytes of primary Data Cache (D-cache), each of which is parity protected with redundant rows and columns for repair.

Lastly there is 3-Mbyte unified L2 cache which is 12-way associative, ECC protected along with redundant rows and columns. This cache is shared among the 8 internal cores and is connected through an internal crossbar. The UltraSPARC T1 processor provides no external cache interface.

### 5.1.1.3 Memory Controller

The UltraSPARC T1 processor contains four independent DDR-2 memory controllers and data interfaces. Unlike standard DDR-2 memory interfaces in the PC industry, the UltraSPARC T1 processor uses a 144-bit datapath to main memory. Thus, the DIMMs in a UltraSPARC T1 processor memory subsystem are always accessed two at a time. Because each DIMM provides 64 bits of data (plus ECC), the resulting data width is 128 bits (plus ECC).

The clock speed of the memory subsystem is nominally 200 MHz, which yields a data bit rate of 400 Mbps using the dual data rate signaling inherent to DDR-2 SDRAM technology.

### 5.1.1.4 Instruction Set

The UltraSPARC T1 processor implements the standard SPARC V9 instruction set, along with the standard UltraSPARC III extensions, including the VIS instruction set, Interval Arithmetic support, and a special Prefetch Enhancement.

### 5.1.1.5 Interrupts

The UltraSPARC T1 processor follows the interrupt dispatch mechanisms laid down in the SunV architecture. In this model, interrupts are pushed into the CPU as Mondo Vectors which in UltraSPARC T1 systems take the form of Interrupt packets sent over the JBus interconnect from the JBus-to-PCI-E bridge into UltraSPARC T1 processor.

### 5.1.1.6 UltraSPARC T1 RAS Features

For reliability, availability, and serviceability (RAS), the UltraSPARC T1 processor provides parity protection on its internal cache memories, including tag parity and data parity on the D-cache and I-cache. The internal 3-Mbyte L2 cache has parity protection on the tags, and ECC protection on the data. The memory interface provides a standard Single-bit correct, Double-bit Detect ECC protection across the 128-bits of data, for a total memory width of 144 bits. In addition, the JBus interconnect is parity protected.

### 5.1.1.7 UltraSPARC T1 Processor Speed

The UltraSPARC T1 processor supports a core frequency of 1 GHz. The maximum supported JBus speed is 200 MHz and maximum supported DDR-2 speed is 200 MHz.

The processor's core speed, JBus, and DDR-2 speeds in the Sun Netra CP3060 blade server depend upon total blade server power budget, which shall not exceed 200W as per the PICMG 3.0 R1.0 specification.

## 5.1.2 DDR-2 Memory Subsystem

The Sun Netra CP3060 blade server uses industry-standard DDR-2 VLP (0.72-inch) DIMMs. Each of the four memory controller units (MCUs) inside the UltraSPARC T1 processor can control up to four DIMMs. The Sun Netra CP3060 blade server only supports two DIMMs per MCU. The Sun Netra CP3060 blade server supports up to 2-Gbyte VLP DIMMs, for a total system memory capacity of 16 Gbytes.


Some of the key features of the memory subsystem are:

- Eight 240-pin JEDEC Standard DDR-2 Registered DIMM slots (two DIMM slots per MCU)
- Minimum clock frequency of 200 MHz (400MT/sec)
- Memory controller supports 144 bits (128 bits data, 16 bits ECC)
- 16 Gbytes max (4 Gbytes, 8 Gbytes, 16 Gbytes)
- Peak memory bandwidth of 25.6 Gbytes/sec @ 200MHz.

### 5.1.2.1 DIMMs

The organization of the memory subsystem with regard to the connections between the UltraSPARC T1 processor and the memory DIMMs is shown in [FIGURE 5-3](#). Because the UltraSPARC T1 processor accesses memory with a 128-bit data path (plus ECC), DIMMs must be installed in pairs. The DIMMs are standard DDR-2 Registered VLP DIMMs. Specific vendors' DIMMs are qualified by Sun and supplied as orderable options for system configuration.

**FIGURE 5-3** DDR Memory Diagram



### 5.1.2.2 Memory Subsystem RAS Features

The ECC scheme employed by the UltraSPARC T1 memory controller provides single-bit correct, double-bit detect ECC protection across the 128 bits of data in each bank of memory. Also, each DIMM provides an industry-standard 256-byte Serial Presence Detect (SPD) PROM, of which 128 bytes are available to the system for dynamic FRU data. Plans are being made to use this 128 bytes for dynamic FRU data, such as soft error rate information.

The Sun Netra CP3060 blade server also supports the Chip-kill detect ECC scheme, allowing the detection of up to 4 bits in error, as long as they are not in the same DRAM. This is made possible by limiting the type of DDR-2 memory DIMMs to only include x4 organization.

### 5.1.2.3 Serial Presence Detect

The Sun Netra CP3060 blade server supports autoconfiguration using serial presence detect (SPD). The DIMMs have small EEPROM devices that store their configuration data according to the SPD format. MPC/vBSC reads this data via the I<sup>2</sup>C management bus, and writes the data into the OpenBoot PROM.

A 128-byte region of the SPD EEPROM is available for user data storage, allowing a limited form of FRU information to be implemented for the DIMMs.

## 5.1.3 System JBus

The JBus is the main interconnect for the core of every UltraSPARC T1-based system. The JBus is a memory-coherent interconnect joining the UltraSPARC T1 processor to the JBus-to-PCI-E bridge.

JBus provides a memory-coherent 128-bit shared address/data path between each of the JBus resident devices. The JBus uses the Dynamic Termination Logic (DTL) signaling environment created initially for the UltraSPARC III, and is a globally clocked bus designed to run with a maximum clock frequency of 200 MHz. Memory coherence is maintained through the use of a snooping Modified-Owned-Exclusive-Invalid (MOESI) cache protocol, wherein all JBus agents must snoop their own cache hierarchies on every transaction that goes across the JBus interconnect.

### 5.1.3.1 JBus RAS Features

JBus provides parity protection on all address and data transfers. One set of parity signals provides parity protection over the multiplexed address/data bus, and another provides parity over the control signals. Address and control parity errors cause a fatal reset, while data parity errors are treated on a per-instance basis, depending on the producer and consumer of the data.

## 5.1.4 I/O Subsystem

The I/O subsystem implements the JBus and PCI-E fabrics, including the JBus-to-PCI-E bridge, one PCI-E switch, one AMC slot, two Intel PCI-E dual gigabit Ethernet chips, a PC-E UliM1575 Southbridge chip, and miscellaneous logic.



### 5.1.4.1 JBus-to-PCI-E Bridge

The JBus-to-PCI-E bridge is a low-cost, high-performance JBus-to-dual-PCI-E host bridge, similar to the PC-based Northbridge. On the host bus side, the JBus-to-PCI-E bridge supports a coherent, split-transaction, 128-bit JBus interface. On the I/O side, the JBus-to-PCI-E bridge supports two 8x-lane, industry-standard PCI-E interfaces. In addition, the JBus-to-PCI-E bridge supports the following interfaces/functionality to facilitate a richer system feature set.

#### *JBus Interface*

The JBus unit detects which transactions present on JBus are targeted for the JBus-to-PCI-E bridge, accepts and queues those transactions, and coordinates with the appropriate destination unit within the JBus-to-PCI-E bridge to which the address and data are sent. When the UltraSPARC T1 processor is the target, the converse is true; in this case the JBus unit sends out onto the JBus the transactions initiated from within the JBus-to-PCI-E bridge (such as from one of the PCI units, I/O caches, and so on.), and presents them to the UltraSPARC T1 processor.

#### *PCI-Express*

PCI-Express (PCI-E) is a high-speed, point-to-point dual simplex chip interconnect. It is designed as the next-generation system bus interconnect, replacing the aging PCI bus. PCI-E operates at 2.5 GHz and supports lane widths of x1, x2, x4, x8, x16, and x32.

PCI-E signaling is accomplished through the use of differential pairs per lane of the interface. For a 1x link, four individual lines are needed: TX+, TX-, RX+, and RX-. Electrically, the signaling levels are 1.2 volts.

PCI-E transfers data using packets. Each packet has a header which includes information about the packet and data payload. The data payloads vary in size from 64 bytes to 4 Kbytes. The maximum packet size supported for the JBus-to-PCI-E bridge is 512 bytes.

#### *Leaf A PCI-E Interface*

The Leaf A 4x PCI-E interface on the JBus-to-PCI-E bridge connects to the Extended Fabric NIC. The interface meets the PCI-E 1.0a specification and is completely autonomous from the second PCI-E interface on the JBus-to-PCI-E bridge. (That is, they are not electrically connected).

## *Leaf B PCI-E Interface*

The Leaf B 8x PCI-E interface on the JBus-to-PCI-E bridge connects to the PCI-E Switch chip. The PLX chip then connects up to downstream devices via 1x, 2x, 4x, or 8x links. (See “[PCI-E Switch](#)” on page 11 for a better synopsis of the device).

The interface meets the PCI-E 1.0a specification and is completely autonomous from the first PCI-E interface on the JBus-to-PCI-E bridge. (that is, they are not electrically connected)

## *Interrupts*

The JBus-to-PCI-E bridge employs a newly developed interrupt event queue that was necessitated by PCI-Express being able to generate many more interrupts (2M) than regular PCI, which was limited to four. The JBus-to-PCI-E chip supports 1-K coalesced interrupts.

### 5.1.4.2 PCI-E Switch

The PCI-E switch supports full non-transparent crossbar bridging functionality that allows the system to isolate the I/O memory domains by presenting the processor subsystem as a endpoint rather than another memory system.

The eight ports on the PCI-E switch are highly configurable, allowing for lane widths from x1 up to x16. The Sun Netra CP3060 blade server only uses lane widths of x4 and x8, which are hard coded using strapping resistors on the `port_config` pins.

The signal strengths of SERDES outputs are controlled by software to better optimize power and signal levels. The four levels are off, low, typical, and high. The Sun Netra CP3060 blade server uses the typical setting.

The PCI-E switch provides a PC-Compliant Hot-Plug Controller per port. This is used at the port connected to the AMC modules.

### 5.1.4.3 PCI-E to Dual GbE Controller

This device is a PCI-E based gigabit Ethernet controller with two fully independent Media Access Control (MAC) and physical layer (PHY) ports. The PCI-E interface is fully compliant to the PCI Express Specification., Revision 1.0a.

The Sun Netra CP3060 blade server utilizes two controllers, one for the Base Fabric and one for the Extended Fabric.

Both Ethernet interfaces are compliant to the IEEE 802.3 standard for:

- 1000BASE-T
- 100BASE-TX
- 10BASE-T
- 1000BASE-SX/L SERDES optical fiber

A serial SPI 16-KByte EEPROM is attached off each device to provide it with configuration data (PHY configuration data, MAC address, etc.).

### *10/100/1000BASE-T Ethernet (Base Interface)*

The Sun Netra CP3060 blade server provides two gigabit Ethernet 10/100/1000BASE-T interfaces to meet the Base Interface requirements of ATCA. The Ethernet controller is used to provide dual Base Interfaces and is an integrated MAC and GMII. These controllers are connected to a x4 PCI-E link.

The controllers are coupled to the ATCA backplane for TPE network connection. Each interface supports 10BASE-T, 100BASE-TX, and 1000BASE-T operation, conforming to the IEEE802.3 specification (reference 11). The controllers individually negotiate transfer speeds when their network links are established.

### *1000 SERDES Ethernet for Extended Interface*

The Sun Netra CP3060 blade server provides two gigabit Ethernet SERDES interfaces to meet the Extended Interface requirements of ATCA. This Ethernet controller is used to provide dual Extended Interfaces and includes a MAC and GMII. These controllers are connected to a x4 PCI-E link.

## 5.1.4.4 Ethernet Switch

The Ethernet switch provides Base Interface connectivity to the MPC885.

## 5.1.4.5 AMC Slot

The Sun Netra CP3060 blade server provides one AMC slot, Extended Full Height Single Width Card, used for PCI-E x8 expansion. In addition, a dual SATA channel from the Southbridge are wired to the AMC slot.

The SATA channels are wired to port 2 and port 3 on the AMC connector common options region (an AMC port is equal to a PCI-E lane; that is, two differential pairs).

## AMC Connectivity to RTM

Port 12-20 (8 differential signal pairs - total of 32 signals) on each AMC slot connector is wired to the Zone 3 RTM connector for AMC generated I/O.


## AMC Power and Management

AMC require two power rails:

- 3.3V management power
- 12V payload power, maximum 21W

Power management is handled by the ATCA ShMC. An overview of the power and management signals is shown in [FIGURE 5-4](#).

**FIGURE 5-4** AMC Power and Management Infrastructure



## *IPMB-L Address*

See [TABLE 5-1](#) for the IPMB-L addresses.

**TABLE 5-1** IPMB-L Addresses

Device	IPML_L Address	AMC GA [2:0]
AMC slot	0x72	Gnd, Gnd, NC

## *Reset\_MMC#*

IPMC also provides individual reset (ENABLE# pin on the AMC connector) to the AMC slot by logically AND-ing the Reset\_MMC# with the AMC PS1 input. Reset\_MMC# is driven by the H8S GPIO pins.

## *AMC Module Presence*

The PS1# signal on the AMC connector provides presence indication. This signal is wired to an H8 GPIO pin.

## *AMC Hot-Plug, Module Insertion (PCI-E)*

When an AMC module is installed, the IPMC is signaled and will initially enable management power (3.3V) to the module. The IPMC will then have the ability to communicate with the module through the IPMI interface (IPMB\_L). If the shelf manager controller (ShMC) determines that the module is supported, it signals the IPMC to enable payload power (12V) to the module. The IPMC controller will also assert HP\_PRSENT# and HP\_BUTTON# (ATTN#) inputs to the PCI-E switch hot-plug controller. This assertion will cause the switch to generate a hot-plug interrupt (or Presence detect change) to the processor to indicate that the blade server is hot inserted. This triggers a system event in the Solaris OS which causes an automatic connect/configure operation. When this operation completes, the processor asserts the HW\_PWR\_LED# output pin of the PCI-E switch hot-plug controller. This output is wired to the H8 GPIO pins.

## *AMC Hot-Plug, Module Removal (PCI-E)*


An operator can initiate module removal by opening the module handle, which deactivates the hot-swap switch. When the hot-swap switch on the module is deactivated, the MMC in the module sends a module hot-swap (Module Handle Opened) event to the IPMC. If the ShMC permits blade server removal, the IPMC asserts the HP\_BUTTON# input pin to the PCI-E switch hot-plug controller, which

will generate a hot-plug event to the OS. When the OS has quiesced the driver operating the AMC module, the driver responds by writing to a CSR in the PCI-E switch that causes de-assertion of the HP\_PWR\_LED output pin. This signal is monitored by IPMC. When de-asserted, the IPMC informs the module to light the blue LED, then turns off payload power, and finally turns off management power.

### *Clock Synchronization*

The Sun Netra CP3060 blade server routes the clock synchronization signals from the midplane (CLK1A/1B, CLK2A/2B) to the AMC slot connector CLK1 and CLK2 pins. The control of which clock signal (CLK1A or CLK1B and CLK2A or CLK2B) is routed to the corresponding CLK1 and CLK2 pins is handled by IPMC.

**FIGURE 5-5** Clock Synchronization



#### 5.1.4.6 Southbridge

The PCI-E-based Southbridge, when used in a PC system, implements virtually a complete desktop I/O subsystem, including Ethernet. Although many of the Super I/O functions built into the Southbridge are not used, functional blocks of the device

are essential to the Sun Netra CP3060 blade server's system architecture. Relative to the PCI-E interconnect, the Sun Netra CP3060 blade server uses a 4x link to access the M1575.

The major functional blocks used are listed below and described in the paragraphs which follow:

- UltraDMA IDE controller – The primary port is used to provide the connection to the Compact Flash and it supports speeds of 66/100/133.
- SATA controller with four 3-Gbps SATA ports.

Configuring the internal devices of the Southbridge is very simple. There is a central switching/routing block inside the Southbridge chip that maps the PCI-E incoming data to the intended downstream device. Thus the Southbridge can be viewed as a collection of PCI devices within a single package. The functional units within Southbridge, which appear to firmware as unique PCI devices, are listed in [TABLE 5-2](#). The Southbridge's standard PCI device configuration is used to control the device behavior on the PCI bus and to allocate PCI Memory and I/O space address ranges needed by the device.

**TABLE 5-2** Southbridge PCI Devices

Bus:Device: Function	IDSEL	Function Name	Vendor ID	Device ID
Bus 0: Device 25: Function 0	NA	PCI Bridge	10B9h	5249h

### *PCI IDE Controller*

The IDE controller is resident inside the Southbridge. This is a dual controller but only the primary bus is utilized to connect the Compact Flash drive on the Sun Netra CP3060 blade server. The bus can operate at DMA mode 4 speed.

### *Compact Flash*

The Sun Netra CP3060 blade server provides the option of supporting an IDE Compact Flash card. In order to support higher memory capacity, a Type II CF socket is provided.

The Compact Flash card is not hot-swappable and there is no access to the CF socket once the blade server is installed in an ATCA chassis.

### *SATA controller*

A dual 3-Gbps SATA port is connected to the AMC connector

## 5.1.5 Service Processor MPC885

The Sun Netra CP3060 blade server includes a MPC885 service processor subsystem used for LDOM configuration and Hypervisor interaction, host system reset, and boot support. The Sun Netra CP3060 blade server uses the MPC885 to run the vBSC firmware (on VxWorks). A block diagram of the subsystem is shown in [FIGURE 5-1](#).

The following I/O interfaces provided by MPC885 are used by the Sun Netra CP3060 blade server:

- 100T – Connects to the Base Fabric switch
- I<sup>2</sup>C – Provides interface to I<sup>2</sup>C devices required by vBSC (DIMM SPDs, TOD, NVRAM)
- UART1 – Provides serial interface to IPMC Payload
- UART2 – Provides console interface

### 5.1.5.1 MPC Bus External Devices

There are three MPC external devices:

- SDRAM (64MB) – SDRAM memory for the MPC with ECC.
- Flash – 16-Mbyte flash for the MPC code.
- Disk-On-Chip (64 MB) – Disk-on-Chip (DoC) is used to store FMA logs and LDOM configuration

### 5.1.5.2 Field-Programmable Gate Array

The SSI interface from the UltraSPARC T1 processor connects to a Field-Programmable Gate Array (FPGA) that provides an internal 32-Kbyte SRAM, access to external OpenBoot flash PROM through an XBus, and access to the IPMC and the MPC.

The FPGA serves as a gateway between the UltraSPARC T1 and the MPC subsystem and provides support functionality for the IPMC. It provides the following functionality:

- 32-Kbyte SRAM integrated – used as Mailbox, Data Channel, and scratch pad for POST. The SRAM is accessible both from the UltraSPARC T1 processor through the SSI interface and from H8 through the H8 bus.
- H8 interface providing IPMC support.
- MPC interface.
- SSI Interface (UltraSPARC T1).
- BUS Interface and Arbiter (Round Robin).



- Bus Clock Control
- Power sequence control of DC/DCs on board.
- Interrupts.
- Data Channel/Fast Mailbox Control.

### *Initialization*

The FPGA configuration is performed after an FPGA reset when the configuration is downloaded from the PROM. The PROM can be updated using a cable and the Xilinx programming header (JTAG), or from the MPC.

## 5.1.5.3 XBus External devices

### *Flash PROM for OpenBoot*

The 4-Mbyte flash PROM is used for the OpenBoot and POST firmware.

## 5.1.6 Intelligent Platform Management Controller

The Renesas H8S/2166 provides the IPM controller (IPMC) function on the Sun Netra CP3060 blade server. The IPMC provides PICMG 3.0 board management functionality, and it interfaces to the host CPU through a serial interface. The IPMC subsystem is powered from the standby power.

The IPMC is responsible for the following:

- Dual buffered IPMB interfaces to connect to IPMB-0
- Serial payload interface to the host through MPC
- IPMI\_L interface to the AMC boards
- Power control of the entire Sun Netra CP3060 blade server
- Power and reset control of the AMC board
- Hot-swap latch input and LED control
- Power control
- E-Keying control
- Environmental monitoring
- Access to all environmental I<sup>2</sup>C devices
- Access to all I<sup>2</sup>C devices when MPC is reset

### 5.1.6.1 Intelligent Platform Management Bus

The BMR-H8S provides dual buffered Intelligent Platform Management Bus (IPMB) interfaces to the IPMB-0 bus on the PICMG 3.0 midplane. The I<sup>2</sup>C channels on the H8S are connected the IPMB-A and IPMB-B through the LTC4300A I<sup>2</sup>C buffers. The I<sup>2</sup>C buffers allow the board I<sup>2</sup>C to be isolated from the midplane until the board is fully seated and the I<sup>2</sup>C bus on the midplane is idle.

### 5.1.6.2 Interface to the MPC

The BMR-H8S provides one serial payload interface to the MPC. This interface supports hardware flow control, RTS (Request To Send) and CTS (Clear To Send).

### 5.1.6.3 IPMB-L Interface

The H8S provides a local IPMI interface wired to the AMC slot (IPMB-L). The AMC IPMI interface is isolated through LTC4300A and controlled by H8 GPIO pins.

### 5.1.6.4 ATCA Hot-Swap Latch

Hot-swap is supported by monitoring of the hot-swap handle switch. The handle switch goes directly to one of the GPIO pins on the H8S.

#### *Payload Shutdown in Response to Hot-Swap*

The hardware supports both non-graceful shutdown and graceful shutdown of payload in response to a hot-swap event. In case of non-graceful shutdown, firmware on the IPMC will disable the voltage rails before turning the blue LED on.

In case of graceful shutdown, IPMC writes to the SHUTDOWN\_REQUEST bit in the FPGA, which will cause an interrupt to be sent to the JBus-to-PCI-E bridge and the MPC. When shutdown is complete, MPC signals this to IPMC through a status bit in the FPGA.

### 5.1.6.5 LEDs

The Sun Netra CP3060 blade server supports three LEDs compliant with ATCA specification:

- Green LED – Healthy status
- Amber LED – Fault condition

- Blue LED – Indicates that blade server is safe for removal (hot-swap activity) when on and hot-swap in progress when blinking.

The LEDs are controlled by H8.

#### 5.1.6.6 Power Control

The BMR-H8S is able to control (enable/disable) power rails to the payload.


#### 5.1.6.7 Extended Interface E-keying Control

The BMR-H8S provides E-keying for the Extended interfaces to the midplane. PICMG mandates that the software hooks for E-keying be present, but it does not mandate that anything needs to be done in hardware in response to this. There is no hardware support for E-keying in the base interfaces. E-keying for the Extended interfaces is accomplished by setting the SIG\_DET lines active.

#### 5.1.6.8 I<sup>2</sup>C Architecture

[FIGURE 5-6](#) is a block diagram of the I<sup>2</sup>C architecture. The subsequent subsections contain a description of the I<sup>2</sup>C Devices and Address map. The MPC has default access to the MPC\_RUN\_I2C bus..

**FIGURE 5-6** I<sup>2</sup>C Block Diagram



## 5.1.6.9 I<sup>2</sup>C Device Address Map

TABLE 5-3 shows the complete I<sup>2</sup>C address map for the I<sup>2</sup>C bus.

**TABLE 5-3** I<sup>2</sup>C Address Map

Address	Location	Standby Powered	I <sup>2</sup> C Segment	Accessed by:	Function
0x5C	motherboard (MB)	Yes	IPMC_I2C	H8	Motherboard H/W Monitor
0x98	MB	Yes	IPMC_I2C	H8	JBus-to-PCI-E bridge junction temperature monitor
0xAC	MB	Yes	IPMC_I2C	H8	IPMI FRU
0xAE	DC/DC	Yes	IPMC_I2C	H8	DC/DC FRU ID
0xA6	MB	Yes	IPMC_I2C	H8	SEL EEPROM
0x5E	DC/DC	Yes	IPMC_I2C	H8	DC/DC temp sensor
0xA8	MB	Yes	MCPFID_I2C	MPC when operational, or else H8	Sun FRU ID
0xAE	RTM	Yes	RTM_I2C		RTM FRU ID
0xA4	MB	Yes	MCPFID_I2C		OBP/HV
0xA6	MB	Yes	MCPFID_I2C		SCC MAC
0x50	MB	No	MPCRUN_I2C	MPC	Voltage marginer for UltraSPARC T1 Core power
0xD0	MB	No	MCPFID_I2C	MPC	RTC
0xDC	MB	No	MPCRUN_I2C	MPC	Differential Buffer for PCI-E
0xA0	MB	No	DDRL_I2C	MPC when operational, or else H8	Channel 0 DIMM0
0xA4	MB	No	DDRL_I2C		Channel 0 DIMM1
0xA8	MB	No	DDRL_I2C		Channel 1 DIMM0
0xAC	MB	No	DDRL_I2C		Channel 1 DIMM1
0xA0	MB	No	DDRR_I2C		Channel 2 DIMM0
0xA4	MB	No	DDRR_I2C		Channel 2 DIMM1

**TABLE 5-3** I<sup>2</sup>C Address Map (*Continued*)

Address	Location	Standby Powered	I <sup>2</sup> C Segment	Accessed by:	Function
0xA8	MB	No	DDRR_I2C		Channel 3 DIMM0
0xAC	MB	No	DDRR_I2C		Channel 3 DIMM1
0x72	AMC	No (Yes, AMC management power)	IMPI_L	H8	IPMI bus to AMC module

A few items are worth noting in the I<sup>2</sup>C address map shown above. The Address column indicates the I<sup>2</sup>C address for the associated device. Although the I<sup>2</sup>C address space is only 7 bits, the read/write bit is appended as bit <0>. Thus, the addresses listed here all represent the read form of the given device's address, that is, Addr<0>=0. These devices are solely accessed by the H8 on the motherboard (MB), if not otherwise noted in [TABLE 5-3](#).

Note that a number of addresses are the same. This is possible because they are on different I<sup>2</sup>C segments controlled by the I<sup>2</sup>C MUX.

The Location column indicates the FRU on which the physical device resides. The Standby column indicates whether this device is readable when the system is in standby mode; that is, powered off but receiving its main power source. In other words, a YES in this column indicates that the H8 which is powered from the systems standby power rail, can access this device at all times, whether the system is powered on or off.

### 5.1.6.10 System Monitor and Thresholds

The system monitor (ADM1026) is a highly integrated and highly sophisticated multi-function system monitor, including Analog-to-Digital Conversion (ADC), Digital-to-Analog Conversion (DAC), Temperature Sensing, and GPIO pins.

The Analog Devices ADM1026 is used for system monitoring functions. The ADM1026 is interfaced with the IPMC, and the IPMC firmware is responsible for monitoring these sensors.

#### *Voltage Monitoring*

The ADM1026 measures most of the board voltages. The ADM1026 has one temperature sensor embedded in the device itself and supports two remote sensing channels requiring external diodes for temperature sensing. These remote sensors are used for measuring CPU die temperature.

The ADM1026 measures the voltages listed in [TABLE 5-4](#). The ADM1206 and H8 firmware monitors these voltages. When the voltages are within regulations, the blade server functions with no warnings. When any voltage goes out of regulation beyond approximately  $\pm 7$ percent, a Critical Warning is generated and presented to the shelf manager. When any voltage goes out of regulation beyond approximately  $\pm 10\%$ , the H8 initiates a blade server shutdown.

**TABLE 5-4** Voltage Sensor Thresholds

Sensor	Non-Critical Thresholds		Critical Thresholds		Non-Recoverable Thresholds	
	Lower	Upper	Lower	Upper	Lower	Upper
+12V	11.77V	12.47V	11.47V	12.73V	11.28V	12.92V
+5V VCC	4.86V	5.15V	4.76V	5.25V	4.05V	5.36V
+3V Main	3.24V	3.45V	3.17V	3.50V	3.10V	3.57V
+3V Standby	3.24V	3.45V	3.17V	3.50V	3.10V	3.57V
2.5VBAT	2.38V	2.52V	2.31V	2.57V	2.27V	2.61V
1.0V (1.15V)	1.10V	1.17V	1.07V	1.19V	1.05V	1.21V
1.1V	1.05V	1.12V	1.03V	1.14V	1.00V	1.16V
1.2V	1.15V	1.22V	1.12V	1.24V	1.10V	1.26V
1.5V	1.43V	1.52V	1.40V	1.55V	1.37V	1.58V
0.9V VTTL	0.86V	0.91V	0.84V	.0.93V	0.83V	0.94V
0.9V VTTR	0.86V	0.91V	0.84V	.0.93V	0.83V	0.94V
1.8V DDR2L	1.72V	1.83V	1.69V	1.86V	1.65V	1.90V
1.8V DDR2R	1.72V	1.83V	1.69V	1.86V	1.65V	1.90V
VCCP 2.5V	2.38V	2.54V	2.34V	2.58V	2.29V	2.63V
1.2V Standby	0.96V	1.46V	0.85V	1.50V	0.81V	1.56V
AMC Site 1 - 12V	–	12.69V	–	12.84V	–	13.00V
AMC Site 1 - 3.3V	3.11V	3.35V	3.01V	3.39V	2.91V	3.39V

### *Temperature Monitor*

The ADM1026 also monitors the CPU die (or junction) temperatures of the CPU on the Sun Netra CP3060 blade server. The ADM1206 and H8 firmware reports a minor, major, or critical alarm when the temperature of either CPU goes beyond the

thresholds listed in [TABLE 5-5](#). Also, if the temperature of either CPU goes beyond the Emergency H8 Shutdown value listed in [TABLE 5-5](#), the H8 initiates a blade server shutdown independent of the shelf manager.

**TABLE 5-5** CPU Temperature Alarms

Sensor	Minor Alarm (UNC)	Major Alarm (UC)	Critical Alarm (UNR)	Emergency H8 Shutdown
CPU Temp 1	>80° C	>90° C	> 102° C	> 105° C
CPU Temp 2	>80° C	>90° C	> 102° C	> 105° C
Blade Server Temp	>60° C	>70° C	> 88° C	> 90° C

The H8 temperature alarm equivalents are:

- Minor Alarm = Upper Non Critical (UNC)
- Major Alarm = Upper Critical (UC)
- Critical Alarm = Upper Non Recoverable (UNR)
- Emergency H8 Shutdown = Emergency H8 Shutdown (EMR)



**Caution** – These voltage and temperature thresholds should not be changed under normal operating conditions.

## 5.2 Power-on Sequence

The following list describes the power-on sequence:

1. Sun Netra CP3060 blade server installed into a midplane slot in ATCA shelf
2. Aux power applied to IPMC and the FPGA
3. IPMC enables front-end DC/DC (48V–12V converter)
4. IPMC checks power ok from front-end DC/DC
5. IPMC enables all voltage rails, and proceeds. if DC\_OK
6. MPC boots
7. MPC becomes operational
8. IPMC asserts SYSTEM\_POK\_ENABLE in FPGA CSRs.



9. SYSTEM\_POK to JBus-to-PCI-E bridge F\_PWR\_GOOD is released (causes CPU hard reset), and vBSC commences with host reset sequence.

---

## 5.3 Power

The following list provides an overview of the Sun Netra CP3060 blade server power rails:

- Sun Netra CP3060 blade server derives dual –48V power from the ATCA backplane
- Sun Netra CP3060 blade server has on-board or power converters for the following:
  - –48V to +12V, 3.3V standby, 2.5V standby, 1.2V standby
  - +12V to 5V, 3.3V, 2.5V, 1.8V, 1.5V, 1.2V, 1.1V, 1.0V, 0.9V

### 5.3.1 Power Input

The Sun Netra CP3060 blade server is powered from dual-redundant –48 V power supply inputs from the backplane power connector. It takes redundant –48V as input and derives the other necessary power using DC-DC converters. The design complies to the ATCA power distribution specification such as:

- Inrush current limiting /hot-plug capability
- Input under-voltage, over-voltage, and transient protection
- EMI filtering for conducted emissions
- Isolated Management Power
- External holdup/energy storage capacitors to meet 0V transient for 5msec
- A/B Feed loss alarm

### 5.3.2 Fuses

As required by the PICMG 3.0 R1.0 specification, the Sun Netra CP3060 blade server provides fuses on each of the –48V power feeds and on the return (RTN) connections. The fuses on the return feeds are critical to prevent overcurrent situations when an O-ring diode in the return path fails. There are eight fuses on the blade server connected to –48V\_A, –48V\_B, RET\_A, RET\_B, EARLY\_A, EARLY\_B, ENABLE\_A, and ENABLE\_B inputs. The fuses are one-time blow type fuse and need to be replaced when blown.

### 5.3.3 ATCA Power Module (–48V to 12V)

The Sun Netra CP3060 blade server uses the ATCA power module solution. The power module provides integrated ATCA power solution which supports PCIMG3.0 requirements including dual bus input, DC isolation, hold up, hot-plug, and management power (3.3V standby). It provides 12V intermediate bus as backend power. Some of the salient features of the module are:

- 210W output power
- Input-to-Output Isolation
- 12V with current rating of 17.5A
- 3.3V standby at 1.82A. System Management Controller draws power from IPMI Power (3.3V\_STBY) so that it can be functional even if back end logic is powered down.
- Isolated Remote ON/OFF
- Isolated A and B Bus detect signals
- Operating Input Voltage: –36V to –72V

### 5.3.4 On-Board DC/DC Regulators

The Sun Netra CP3060 blade server uses its own designed DC/DC SIP modules for generating other onboard power. All the voltages are generated from +12V input power.

### 5.3.5 TOD Clock Battery

The TOD clock battery **must** be type CR 1225, with a minimum of 4ma abnormal charging current rating (for example; a Panasonic CR 1225).



---

**Caution** – Risk of explosion if battery is replaced by an incorrect type. Dispose of batteries properly in accordance with manufacturer’s instructions and local regulations.

---



## Physical Characteristics

---

Specifications for the Sun Netra CP3060 blade server are provided in the following sections:

- [Section A.1, “Form Factor” on page A-1](#)
- [Section A.2, “Layout” on page A-1](#)
- [Section A.3, “Front Panel” on page A-2](#)
- [Section A.4, “Connectors and Pinout” on page A-3](#)

---

### A.1 Form Factor

The Sun Netra CP3060 blade server is a standard 8U form factor, a single-slot-wide. It complies with the board mechanical dimensions required by the PICMG 3.0 R1.0 Specification:


- 322.25 mm x 280 mm (length x width)
- 1.2-inch-wide front panel

---

### A.2 Layout

The Sun Netra CP3060 blade server layout is shown in [FIGURE A-1](#).

**FIGURE A-1** Sun Netra CP3060 Blade Server Layout



## A.3 Front Panel

The single-slot-wide, 8U front panel was designed to meet PICMG 3.0 R 1.0 and other specifications.

## A.3.1 Visual Indicators

The Sun Netra CP3060 blade server has the following indicators on the front panel:

- Green LED – Blade Server’s healthy status or user programmable (ACTIVE).
- Amber LED – Blade Server’s fault condition (FAULT).
- Blue LED – Indicates safe removal (hot-swap activity).

The front panel’s Ethernet ports do not have LED indicators.

## A.3.2 Ports

The Sun Netra CP3060 blade server has the following ports on the front panel:

- One serial port (RJ-45)
- Two 10/100/1000BASE-T Ethernet ports (RJ-45)

## A.3.3 AMC Slot

The Netra CP3060 blade server has an AMC I/O full-height, single-width slot that is accessible through the AMC cutout on the front panel.

---

# A.4 Connectors and Pinout

[FIGURE A-1](#) shows all the basic I/O connectors to the front and the rear of the Sun Netra CP3060 blade server.

## A.4.1 Front Panel Connectors


The front panel has the following connectors:

- Two 10/100/1000BASE-T Ethernet ports (RJ-45)
- One serial port (RJ-45)
- AMC connector (via AMC slot)

### A.4.1.1 Ethernet Ports

The Ethernet connectors are RJ-45 connectors. The controller autonegotiates to either 10BASE-T,100BASE-T, or 1000BASE-T. The Ethernet connector pin numbering is shown in [FIGURE A-2](#).

**FIGURE A-2** Ethernet RJ-45 Connector



[TABLE A-1](#) shows the Ethernet connector pin assignments. The 1000BASE-T signal names are in parentheses.


**TABLE A-1** Ethernet Port Connector Pin Assignments

Pin	Signal Name		Pin	Signal Name	
1	TXD+	(BI_DA+)	5	not used	(BI_DC-)
2	TXD-	(BI_DA-)	6	RXD-	(BI_DB-)
3	RXD+	(BI_DB+)	7	not used	(BI_DD+)
4	not used	(BI_DC+)	8	not used	(BI_DD-)

### A.4.1.2 Serial Port

[FIGURE A-3](#) contains the connector pin assignments for the front panel serial port.

**FIGURE A-3** Front Panel Serial Port Diagram



[TABLE A-2](#) shows the serial port connector pin assignments.

**TABLE A-2** Serial Port RJ-45 Connector Pinouts

Pin	Signal Name	Pin	Signal Name
1	RTS	5	DCD
2	DTR	6	RXD
3	TXD	7	DSR
4	GND	8	CTS

## A.4.2 AMC Connector

The Sun Netra CP3060 blade server provides a B+ style 170-pin connector. The pinout of the AMC slot is provided in [TABLE A-3](#).

- The signals denoted RTM are wired to the Zone 3 RTM connector. (These are port 12 through port 20 in the AMC specification, part of the Extended Options Region.)
- The signals denoted PCI-E are connected with an x8 port on the PCI-E switch. (These are port 4 through port 11 in the AMC specification, part of the Fabric I/O Region.)
- The signals denoted SATA are wired to two of the SATA controller ports. (These are port 2 and port 3 in the AMC specification, part of the Common Options Region.)



**TABLE A-3** AMC Connector Pin Assignments

Basic Side		Extended Side		Basic Side		Extended Side	
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
85	Gnd	86	Gnd	42	12V	129	RTM_TX3_N
84	12V	87	PCIE_RX4_N	41	AMC_CONN_ENABLE_L	130	RTM_TX3_P
83	Gnd	88	PCIE_RX4_P	40	Gnd	131	Signal
82	Gnd	89	Gnd	39	SATA1_AMC_TX_N	132	RTM_RX3_N
81	AMCCON_REFCLK_N	90	PCIE_TX4_N	38	SATA1_AMC_TX_P	133	RTM_RX3_P
80	AMCCON_REFCLK_P	91	PCIE_TX4_P	37	Gnd	134	Gnd
79	Gnd	92	Gnd	36	SATA1_AMC_RXX_N	135	RTM_TX4_N
78	CLK2_N	93	PCIE_RX5_N	35	SATA1_AMC_RXX_P	136	RTM_TX4_P
77	CLK2_P	94	PCIE_RX5_P	34	Gnd	137	Gnd
76	Gnd	95	Gnd	33	SATA0_AMC_TX_N	138	RTM_RX4_N
75	CLK1_N	96	PCIE_TX5_N	32	SATA0_AMC_TX_P	139	RTM_RX4_P
74	CLK1_P	97	PCIE_TX5_P	31	Gnd	140	Gnd
73	Gnd	98	Gnd	30	SATA0_AMC_RXX_N	141	RTM_TX5_N
72	12V	99	PCIE_RX6_N	29	SATA0_AMC_RXX_P	142	RTM_TXx5_P
71	I2C_AMCCONN_SDA	100	PCIE_RX6_P	28	Gnd	143	Gnd
70	Gnd	101	Gnd	27	12V	144	RTM_RX5_N
69	PCIE_RX3_N	102	PCIE_TX6_N	26	Gnd	145	RTM_RX5_P
68	PCIE_RX3_P	103	PCIE_TX6_P	25	Gnd	146	Gnd
67	Gnd	104	Gnd	24	n/c	147	RTM_TX6_N
66	PCIE_TX3_N	105	PCIE_RX7_N	23	n/c	148	RTM_TX6_P
65	PCIE_TX3_P	106	PCIE_RX7_P	22	Gnd	149	Gnd
64	Gnd	107	Gnd	21	n/c	150	RTM_RX6_N
63	PCIE_RX2_N	108	PCIE_TX7_N	20	n/c	151	RTM_RX6_P
62	PCIE_RX2_P	109	PCIE_TX7_P	19	Gnd	152	Gnd
61	Gnd	110	Gnd	18	12V	153	RTM_TX7_N
60	PCIE_TX2_N	111	RTM_TX0_N	17	Gnd	154	RTM_TX7_P
59	PCIE_TX2_P	112	RTM_TX0_P	16	Gnd	155	Gnd
58	Gnd	113	Gnd	15	n/c	156	RTM_RX7_N
57	12V	114	RTM_RX0_N	14	n/c	157	RTM_RX7_P
56	I2C_AMCCONN_SCL	115	RTM_RX0_P	13	Gnd	158	Gnd

**TABLE A-3** AMC Connector Pin Assignments (*Continued*)

Basic Side		Extended Side		Basic Side		Extended Side	
Pin	Signal	Pin	Signal	Pin	Signal	Pin	Signal
55	Gnd	116	Gnd	12	n/c	159	RTM_TX8_N
54	PCIE_RX1_N	117	RTM_TX1_N	11	n/c	160	RTM_TX8_P
53	PCIE_RX1_P	118	RTM_TX1_P	10	Gnd	161	Gnd
52	Gnd	19	Gnd	9	12V	162	RTM_RX8_N
51	PCIE_TX1_N	120	RTM_RX1_N	8	nGnd	163	RTM_RX8_P
50	PCIE_TX1_N	121	RTM_RX1_P	7	Gnd	164	Gnd
49	Gnd	122	Gnd	6	Gnd	165	TCLK
48	PCIE_RX0_N	123	RTM_TX2_N	5	n/c	166	TMS
47	PCIE_RX0_P	124	RTM_TX2_P	4	3.3v_AMC	167	TRST
46	Gnd	125	Gnd	3	AMC_PS1_L	168	TDO
45	PCIE_TX0_N	126	RTM_RX2_N	2	12V	169	TDI
44	PCIE_TX0_P	127	RTM_RX2_P	1	Gnd	170	Gnd
43	Gnd	128	Gnd				

### A.4.3 Compact Flash Connector

The Compact Flash connector is a type I/II connector.

### A.4.4 Midplane Power Connector (Zone 1)

The Sun Netra CP3060 blade server uses a Zone 1 power connector. It provides support for the following signals:

- Two –48 volt DC power feeds (four signals each; eight signals total)
- Two IPMB ports (two signals each, four signals total)
- Geographic address (eight signals)

The analog test and ring voltage pins are left unconnected.

FIGURE A-4 shows the pin assignments.

**FIGURE A-4** Power Distribution Connector (Zone 1) P10




TABLE A-4 lists the power connector pin assignments.

**TABLE A-4** Power Distribution Connector Pin Assignments

Pin Number	Name	Description
1	Reserved	Reserved
2	Reserved	Reserved
3	Reserved	Reserved
4	Reserved	Reserved
5	HA0	HA0 Hardware Address Bit 0
6	HA1	HA1 Hardware Address Bit 1
7	HA2	HA2 Hardware Address Bit 2
8	HA3	HA3 Hardware Address Bit 3
9	HA4	HA4 Hardware Address Bit 4
10	HA5	HA5 Hardware Address Bit 5
11	HA6	HA6 Hardware Address Bit 6
12	HA7/P	HA7/P Hardware Address Bit 7(Odd Parity Bit)
13	SCL_A	IPMB Clock, Port A
14	SDA_A	IPMB Data, Port A
15	SCL_B	IPMB Clock, Port B
16	SDA_B	IPMB Data, Port B
17	Unused	
18	Unused	

**TABLE A-4** Power Distribution Connector Pin Assignments (*Continued*)

Pin Number	Name	Description
19	Unused	
20	Unused	
21	Unused	
22	Unused	
23	Unused	
24	Unused	
25	SHELF_GND	Shelf Ground
26	LOGIC_GND	Logic Ground
27	ENABLE_B	Enable B
28	VRTN_A	Voltage Return A
29	VRTN_B	Voltage Return B
30	EARLY_A	–48V Early A
31	EARLY_B	–48V Early B
32	ENABLE_A	Enable A
33	–48V_A	–48V A
34	–48V_B	–48V B

## A.4.5 Data Transport Connector (Zone 2)

The data transport connector consists of one 120-pin HM-Zd connector, labeled P23, with 40 differential pairs. This is called the Zone 2 connector.

The Zone 2 connector provides the following signals:

- Two 1000BASE-T Ethernet Base Fabric channels
- Two 1000 SERDES ports on the Extended Fabric interface
- Synchronization Clock interface supporting CLK1A/B and CLK2A/2B

FIGURE A-5 shows the Zone 2 connectors.

**FIGURE A-5** Zone 2 Connectors




TABLE A-5 gives the Zone 2 J10101 connector pin assignments.

**TABLE A-5** Zone 2 J10101 Connector Pin Assignments

Row	A	B	C	D	E	F	G	H
1	n/c	n/c	P23_F2_ TERM_RX2+	P23_F2_ TERM_RX2-	n/c	/c	P23_F2_ TERM_RX3+	P2_F2_ TERM_RX3+
2	GBE_EXTB_T X0_P	GBE_EXTB_T X0_N	GBE_EXTB_R X0_P	GBE_EXTB_R X0_N	n/c	n/c	P23_F2_ TERM_RX1+	P23_F2_ TERM_RX1+
3	n/c	n/c	P23_F1_ TERM_RX2+	P23-F1_ TERM_RX2+	n/c	n/c	P23_F1_ TERM_RX3+	P23_F1_ TERM_RX3+
4	GBE_EXTB_T X0_P	GBE_EXTB_T X0_N	GBE_EXTB_R X0_P	GBE_EXTB_R X0_N	n/c	n/c	P23_F1_ TERM_RX1+	P23_F1_ TERM_RX1+
5	GBE_BASE_ Z2A_TR0_P	GBE_BASE_ Z2A_TR0_N	GBE_BASE_ Z2A_TR1_P	GBE_BASE_ Z2A_TR1_N	GBE_BASE_ Z2A_TR2_P	GBE_BASE_ Z2A_TR2_N	GBE_BASE_ Z2A_TR3_P	GBE_BASE_ Z2A_TR3_N
6	GBE_BASE_ Z2B_TR0_P	GBE_BASE_ Z2B_TR0_N	GBE_BASE_ Z2B_TR1_P	GBE_BASE_ Z2B_TR1_N	GBE_BASE_ Z2B_TR2_P	GBE_BASE_ Z2B_TR2_N	GBE_BASE_ Z2B_TR3_P	GBE_BASE_ Z2B_TR3_N
7	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
8	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
9	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
10	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c

[TABLE A-6](#) gives the Zone 2 J10001 connector pin assignments.

**TABLE A-6** Zone 2 J10001 Connector Pin Assignments

Row	A	B	C	D	E	F	G	H
1	Clk1A_P	Clk1A_N	Clk1B_P	Clk1B_N	Clk2A_P	Clk2A_N	Clk2B_P	Clk2B_n
2	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
3	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
4	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
5	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
6	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
7	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
8	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
9	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c
10	n/c	n/c	n/c	n/c	n/c	n/c	n/c	n/c

## A.4.6 RTM Connector (Zone 3)

The Sun Netra CP3060 blade server provides all the I/O connections for rear access through the Zone 3 RTM connector. The connector view and the pinouts for the Zone 3 connectors are shown in [FIGURE A-6](#).

**FIGURE A-6** Zone 3 Connectors




TABLE A-7 gives the Zone 3 J10202 connector pin assignments.

**TABLE A-7** Zone 3 J10202 Connector Pin Assignments

Row	A	B	BG	C	D	DG	E	F	FG
1	PCIE_Tx7_p	PCIE_Tx7_n	GND	PCIE_Rx7_p	PCIE_Rx7_n	GND	n/c	n/c	GND
2	PCIE_Tx6_p	PCIE_Tx6_n	GND	PCIE_Rx6_p	PCIE_Rx6_n	GND	n/c	n/c	GND
3	PCIE_Tx5_p	PCIE_Tx5_n	GND	PCIE_Rx5_p	PCIE_Rx5_n	GND	n/c	n/c	GND
4	PCIE_Tx4_p	PCIE_Tx4_n	GND	PCIE_Rx4_p	PCIE_Rx4_n	GND	n/c	n/c	GND
5	PCIE_Tx3_p	PCIE_Tx3_n	GND	PCIE_Rx3_p	PCIE_Rx3_n	GND	n/c	n/c	GND
6	PCIE_Tx2_p	PCIE_Tx2_n	GND	PCIE_Rx2_p	PCIE_Rx2_n	GND	n/c	n/c	GND
7	PCIE_Tx1_p	PCIE_Tx1_n	GND	PCIE_Rx1_p	PCIE_Rx1_n	GND	n/c	n/c	GND
8	PCIE_Tx0_p	PCIE_Tx0_n	GND	PCIE_Rx0_p	PCIE_Rx0_n	GND	n/c	n/c	GND
9	n/c	n/c	GND	n/c	n/c	GND	n/c	n/c	GND
10	n/c	n/c	GND	n/c	n/c	GND	n/c	n/c	GND

TABLE A-8 gives the Zone 3 J10201 connector pin assignments.

**TABLE A-8** Zone 3 J10201 Connector Pin Assignments

Row	A	B	BG	C	D	DG	E	F	FG
1	AMC0_IO1	AMC0_IO2		AMC0_IO3	AMC0_IO4		AMC0_IO5	AMC0_IO6	GND
2	AMC0_IO7	AMC0_IO8		AMC0_IO9	AMC0_IO10		AMC0_IO11	AMC0_IO12	
3	AMC0_IO24	AMC0_IO23		AMC0_IO22	AMC0_IO21		AMC0_IO20	AMC0_IO19	
4	AMC0_IO18	AMC0_IO17		AMC0_IO16	AMC0_IO15	GND	AMC0_IO14	AMC0_IO13	
5	AMC0_IO36	AMC0_IO35	GND	AMC0_IO34	AMC0_IO33		AMC0_IO32	AMC0_IO31	
6	AMC0_IO30	AMC0_IO29		AMC0_IO28	AMC0_IO27		AMC0_IO26	AMC0_IO25	GND
7	n/c	n/c		n/c	n/c		n/c	n/c	
8	n/c	n/c		n/c	n/c		n/c	n/c	
9	n/c	n/c		n/c	n/c		n/c	n/c	
10	n/c	n/c		n/c	n/c		n/c	n/c	

TABLE A-9 gives the Zone 3 J10301 connector pin assignments.

**TABLE A-9** Zone 3 J10301 Connector Pin Assignments

Row	A	B	BG	C	D	DG	E	F	FG
1	n/c	n/c		n/c	n/c		n/c	–12V	
2	n/c	n/c	5V	n/c	n/c	5V	+12V	+12V	5V
3	RTM_SER1_ CTS	RTM_SER1_ DTR	3.3V	RTM_SER1_ DCD	RTM_SER1_ DSR	3.3V	RTM_SER1_ RXD	RTM_SER1_ TXD	3.3V
4	RTM_SER1_ RTS	n/c	3.3V	n/c	n/c	3.3V	n/c	n/c	3.3V
5	n/c	n/c	5V	n/c	n/c	5V	n/c	n/c	5V
6	RTM_SATA1_ RX_P	RTM_SATA1_ RX_N	GND	RTM_ETH_ LED_1	RTM_ETH_ LED_2	GND	RTM_SATA1_ TX_N	RTM_SATA1_ TX_P	GND
7	RTM_PRSENT_ N	3V_STBY	GND	RTM_I2C_ SDA	RTM_I2C_ SCL	GND	3V_STBY	3V_STBY	GND
8	RTM_SATA2_ RX_P	RTM_SATA2_ RX_N	GND	RTM_ETH_ LED3	RTM_ETH_ LED4	GND	RTM_SATA2_ TX_N	RTM_SATA2_ TX_P	GND
9	RTM_ETH_ TRD_3P	RTM_ETH_ TRD_3N	GND	2.5V	2.5V	GND	RTM_ETH_ TRD_2P	RTM_ETH_ TRD_2N	GND
10	RTM_ETH_ TRD_1P	RTM_ETH_ TRD_1N	GND	2.5V	2.5V	GND	RTM_ETH_ TRD_0P	RTM_ETH_ TRD_0N	GND



## A.4.7 TOD Clock Battery Holder

The TOD clock battery holder is located under the AMC enclosure (see [FIGURE A-1](#)).

The TOD battery **must** be type CR 1225, with a minimum of 4ma abnormal charging current rating (for example; a Panasonic CR 1225).



---

**Caution** – Risk of explosion if battery is replaced by an incorrect type.  
Dispose of batteries properly in accordance with manufacturer’s instructions and local regulations.

---

To install the battery, slide the battery into the holder with the side labeled “+ “ facing up.

# Sun OEM IPMI Commands

This appendix contains the following sections:

- [Section B.1, “Get Version Command” on page B-2](#)
- [Section B.2, “Get RTM Status Command” on page B-3](#)

The commands described in this appendix are specific to Sun Netra CP3060 blade server designed by Sun Microsystems. The Internet Assigned Numbers Authority (IANA) number assigned to Sun Microsystems is 42.

Refer to <http://www.iana.org/assignments/enterprise-numbers> for more information about IANA number assignments.

The netfunction (NetFn) used for these commands is 0x2E, which is the OEM netfunction as defined in the IPMI specification. For this netfunction, the first three data bytes in the request packet must be this IANA number and the first three bytes in the response packet following the completion code are the IANA number. For Sun ATCA node blade servers, these three bytes are 00 00 2A.

The Sun OEM IPMI commands are listed in [TABLE B-1](#) and described in the following sections.

**TABLE B-1** Sun OEM IPMI Commands

Command	Opcode	Syntax
Get Version	0x80	#GET_VERSION
Get RTM status	0x88	#GET_RTM_STATUS

# B.1 Get Version Command

Get Version returns the IPM controller (IPMC) firmware version and Standby CPLD version. Bytes 8, 9, and A are reserved for future use.

Command	NetFn	Opcode	Reference
Get Version	0x2E (OEM)	0x80	- -

## Data Bytes

Type	Byte	Data Field
Request data	Byte1	00
	Byte2	00
	Byte3	2A
Response data	Byte1	Completion code: 00 = OK C1 = Command not supported CC = Invalid data in request (Refer to IPMI specification for more completion codes)
	Byte2	00
	Byte3	00
	Byte4	2A
	Byte5	CPLD version
	Byte6	REV1 byte of IPMC firmware
	Byte7	REV2 byte of IPMC firmware
	Byte8	Reserved for future use (ignore)
	Byte9	Reserved for future use (ignore)
	ByteA	Reserved for future use (ignore)

## Example (Terminal Mode):

```
[B8 00 80 00 00 2A] <-----Request
[BC 00 80 00 00 00 2A 02 02 00 00 00 00] <----Response
```

- The IPMC version is read as:

lower nibble of REV1 . high nibble of REV2 . low nibble of REV2

In the preceding example, the IPMC version is 2 . 0 . 0 .

- The CPLD version is read as:

-> lower nibble of CPLD version byte

In the example, the CPLD version is 2 .

---

## B.2 Get RTM Status Command

Get RTM Status can be used to detect the presence of a rear transition module (RTM) in the system.

Command	NetFn	Opcode	Reference
Get RTM Status	0x2E (OEM)	0x88	CPLD Specification

Data Bytes

Type	Byte	Data Field
Request data	Byte1	00
	Byte2	00
	Byte3	2A
Response data	Byte1	Completion code: 00 = OK C1 = Command not supported CC = Invalid data in request
	Byte2	00
	Byte3	00
	Byte4	2A
	Byte5	RTM presence Bits 7 to 1 = 0 Bits 0 = RTM presence (0 = RTM not detected, 1 = RTM detected)

*Example (Terminal Mode):*

```
[B8 00 88 00 00 2A] <-----Request  
[BC 00 88 00 00 00 2A 01] <-----Response
```

# Index

---

## A

### AMC

- devices, 1-8
- installing, 2-18

### AMC I/O, 1-6

### auto-boot (OpenBoot configuration variable), 4-5

### automatic system recovery (ASR)

- disabling, 4-15
- enabling, 4-14

## B

### barcode labels, locating, 1-13

### board layout, A-1

## C

### cabling, 2-17

### collecting network information, 2-4

### compliance

- NEBS, 1-7
- PICMG specifications, 1-6

### components, 1-12

### configurations

- I/O configurations, 1-11

## D

### descriptions<endrange>, 5-28

### descriptions<startrange>, 5-1

### device

- information, retrieving, 4-17

### device paths, hardware, 4-6

### diagnostics

### POST, 4-2

### SunVTS software, 3-7

### DIMM memory module

- described, 2-5
- installing, 2-7
- removing, 2-8
- requirements, 2-5

## E

### electric shock caution, 2-1

### error handling, summary, 4-9

### Ethernet

- RJ-45, A-4

## F

### features, 1-6

- CPU, 1-6
- hot-swap, 1-6
- memory, 1-6
- power requirements, 1-6

### Flash update, 1-7

### form factor, A-1

### front panel, A-2, A-4

- connections, 1-7

### frutree

- entries and properties, 4-18
- hierarchy, 4-17

### fuses, 5-27

## G

### graceful system halt, 4-4

## H

- halt, gracefully, advantages of, 4-4
- hardware, 5-1, 5-28
- hardware architecture, 5-1
- hardware device paths, 4-6
- hardware installation, 2-1 to 2-20
  - AMC device, 2-18
  - collecting network information, 2-4
  - DIMM modules, 2-5
  - preparation, 2-3
  - summary, 2-4
  - tools needed, 2-2
- hot-swap
  - information, 4-15
  - LED indicator, 4-16
  - support, 1-11

## I

- I/O connections
  - front panel, 1-7
- IDE bus, 4-6
- init (Solaris command), 4-4
- installation
  - AMC device, 2-18
  - DIMM modules, 2-7
  - overall procedure, 2-4
  - preparation, 2-3
  - tools needed, 2-2
- installing
  - rear transition modules, 2-12
- integrated drive electronics (IDE)
- Intelligent Platform Management controller (IPMC), 4-1
- Internet Assigned Numbers Authority (IANA), B-1
- IPMC (Intelligent Platform Management controller), 4-1
- IPMI system management, 1-6

## L

- LED
  - hot-swap, 4-16
- LEDs
  - Active, A-3
  - Fault, A-3
  - front panel, A-3
  - hot swap, A-3

## M

- MAC address, 2-4
  - label, 1-13
- manual system reset, 4-4
- memory, 1-6
  - DIMM
    - module, 2-5
- message
  - POST, error, 4-2, 4-3

## N

- netfunction (NetFn), B-1

## O

- ok prompt
  - ways to access, 4-4
- OpenBoot commands
  - probe-ide, 4-6
  - show-devs, 4-6
- OpenBoot configuration variables
  - auto-boot, 4-5

## P

- part number, locating, 1-13
- PICL, 4-17
- pinouts
  - serial port, A-4
- platform information and control library (PICL), 4-17
- POST
  - error messages, 4-2, 4-3
- POST *see also* power-on self-test (POST), 4-2
- power
  - requirements, 1-6
- power module, 5-28
- power-on self-test (POST)
  - see* POST
- power-on sequence, 5-26
- preparation
  - installation, 2-3
- probe-ide command (OpenBoot), 4-6
- PROM contents, 4-1

## R

- rear transition module, features, 1-8

- removing DDR-2 DIMM module, 2-8
- requirements
  - hardware, 1-12
  - safety, 2-1
  - software, 1-6, 1-12
- reset
  - manual system, 4-4
  - scenarios, 4-9
- RJ-45 Ethernet, A-4
- RTM (rear transition module), 1-8

## **S**

- serial
  - number, locating, 1-13
  - port, A-4
- show-devs command, OpenBoot, 4-6
- shutdown (Solaris command), 4-4
- software
  - hot-swap
    - information, 4-15
  - PICL, 4-17
  - requirements, 1-6
- Solaris commands
  - init, 4-4
  - shutdown, 4-4
- Sun OEM IPMI commands, B-1
  - Get RTM Status, B-3
  - Get Version, B-1
- Sun Services, 1-13
- SunVTS software, 3-7
- support, contacting, 1-13
- system reset scenarios, 4-9

## **T**

- TOD clock
  - battery, 5-28, A-14
  - battery holder, A-14
- tools needed, 2-2

## **W**

- warranty, 1-13
- watch-net, 4-8



