

StorageTek Automated Cartridge System Library Software

Installation

Version 8.0.2



Part Number: 316144301
September 2010, Revision AA

Submit comments about this document by clicking the Feedback [+] link at: <http://docs.sun.com>

StorageTek Automated Cartridge System Library Software Installation Guide
Part Number: 316144301

Copyright © 1989, 2010, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure the safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Revision History

Date	Revision	Description
September 2010	AA	Supports StorageTek ACSLS 8.0.2.

Preface

StorageTek Automated Cartridge System Library Software (ACSL) 8.0.2 is Oracle's StorageTek's UNIX server software that controls a StorageTek Automated Cartridge System (ACS). The StorageTek ACS family of products consists of fully automated, tape cartridge-based data storage and retrieval systems. StorageTek ACSL supports network access to different client systems that can range from workstations to mainframes to supercomputers running on a variety of operating systems.

This guide is for the individual responsible for administering StorageTek ACSL. It is expected that you already have a working knowledge of the following:

- UNIX file and directory structure
- How to use UNIX commands and utilities for your platform
- UNIX system files
- How to do typical UNIX system administrator tasks, such as logging on as root and setting up user accesses to a UNIX application

Related Documentation

The following list contains the names and order numbers of publications that provide additional information about *the product*.

The online documentation is available at:

<http://docs.sun.com/app/docs/prod/filename>

Title	Part Number
StorageTek ACSL 8.0.2 Administrator's Guide	316143801
StorageTek ACSL 8.0.2 Messages Guide	316144001
StorageTek ACSL 8.0.2 Installation	316144301

Title	Part Number
StorageTek ACSLS 8.0.2 Product Information	316143901
StorageTek ACSLS 8.0.2 Quick Reference	316144101
StorageTek ACSLS 8.0.2 Release Notes	316144201

Conventions for Reader Usability

Conventions are used to shorten and clarify explanations and examples within this book.

Typographic

Keys

Single keystrokes are represented by double brackets `[[]]` surrounding the key name. For example, press `[[ESC]]` indicates that you should press only the escape key.

Combined keystrokes use double brackets and the plus sign (+). The double brackets surround the key name and the plus sign is used to add the second keystroke. For example, press `[[ALT]]+C` indicates that you should press the alternate key and the C key simultaneously.

Enter Command

The instruction to “press the <Enter> key” is omitted from most examples, definitions, and explanations in this book.

For example, if the instructions asked you to “enter” `Logon pat`, you would type in `Logon pat` and press <Enter>.

However, if the instructions asked you to “type” `Logon pat`, you would type in `Logon pat` and you would *not* press <Enter>.

Symbols

The following symbols are used to highlight text in this book.

Caution – Information necessary to keep you from corrupting your data.

Note – Information that may be of special interest to you. Notes are also used to point out exceptions to rules or procedures.

Documentation Website

Function	URL
Documentation	
Customer:	http://docs.sun.com
Employee:	http://docs.sfbay.sun.com/

Third-Party Web Sites

Oracle is not responsible for the availability of third-party web sites mentioned in this document. Oracle does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Oracle will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

Oracle Welcomes Your Comments

Oracle is interested in improving its documentation and welcomes your comments and suggestions. Submit your comments by clicking the Feedback[+] link at:

<http://docs.sun.com>

Please include the title and part number of your document with your feedback:

ACSL 8.0.2 Installation, part number

Contents

Revision History iii

Preface vii

Contents xi

1. Overview	1
Software Requirements	1
System Requirements	2
Browser Requirements:	2
Co-Hosting	3
2. Installing ACSLS on Solaris	5
Downloading ACSLS Software	5
What's in this Chapter	6
ACSLS 8.0.1 Installation Tasks	6
Exporting the Database	7
Installing Solaris	7
Preparing for ACSLS 8.0.1 Installation	8
Removing any previous version	10
Using pkgadd	11
Installing the 8.0.2 Update	12
Using install.sh	12
Setting the ACSLS User Passwords	14
Installing and Configuring your Library Hardware	15
Importing the Database	15

Verifying ACSLS Installation	15
Auditing the Library	16
Uninstalling ACSLS 8.0.1 (and ACSLS 8.0.2)	16
Uninstalling any SCSI Media Changer Drivers	17
Index	19

Overview

Automated Cartridge System Library Software (ACSL) is Oracle's StorageTek server software that controls StorageTek tape libraries. An Automated Cartridge System (ACS) is a group of tape libraries connected through pass-thru-ports (PTPs). ACSL accesses and manages information stored in one or more ACSs through command processing across a network. The software includes a system administration component and interfaces to client system applications, and library management facilities.

ACSL 8.0.2 uses the relational database PostgreSQL which is included in your Solaris 10 distribution.

Please check the website for any maintenance releases.

ACSL software you download from the Oracle e-delivery website or is ordered and delivered on a CD comes in a zipped ISO image. Refer to the `Download_ISO.txt` file for instructions for unzipping and downloading the ACSL software.

Note – ACSL 8.0.1 must be installed before you apply ACSL 8.0.2 maintenance.

Refer to the instructions provided in the `ACSL_README.txt` file included in 143793-01 or 143783-01 for installing and uninstalling ACSL 8.0.2.

Software Requirements

- ACSL 8.0.2 has been fully tested and verified on Oracle's Sun SPARC and X86 platforms running Solaris-10 (U6 10/2008, U7 05/2009, or U8 10/2009). Other operating systems, including AIX and virtual environments, are not tested or supported.
- Because of special device driver requirements to enable virtual libraries, ACSL 8.0.2 cannot run in a Solaris Zoned environment. However, ACSL 8.0.2 can run in a logical domain on a SPARC system with Chip Multithreading (CMT) technology. ACSL 8.0.2 HA systems must be installed on their own dedicated platform pair.
- The graphical user interface and SMCE service in ACSL 8.0.2 requires Java 1.6 U14 and is included on the ACSL CD for easy installation. You cannot install ACSL unless this requirement is met. Please note that:
 - Should you choose to install Java in a different directory, a soft link must be provided that points to the java binaries located in: `/usr/java/bin/java`

- To verify the version, enter the command: `java -version`.
The system should reply with "java version 1.6.0_14"

System Requirements

- Memory: 2GB minimum
- Swap: Configure swap to be no less than the configured amount of physical memory.
- File systems:
Installation fails if the following filesystems do not exist as separate filesystems.
 - /export/home - 5GB or greater
 - /export/backup - 5GB or greater
- Optional Fibre card.

A Fibre card is optional. However, a contemporary QLogic Fibre HBA (4GB or higher) is required if:

- A dedicated Fibre port is required to operate in target mode for client communication to logical libraries.
- Another port is required to act as an initiator for communication with SCSI-attached libraries, such as the SL500 or SL700.

Note: If neither of these is required, you do not need a Fibre card. However, during normal GUI operations a critical error icon shows up in the Web Console. Ignore this error.

Browser Requirements:

ACSL 8.0.2 has been tested and fully verified on the following browsers:

- Internet Explorer 8.x
- FireFox 2.x, 3.0.x
- Chrome 4.x

There are known issues with the following browsers:

- Internet Explorer 7.x mis-interprets line breaks in drop-down menus as legitimate selections.
- Firefox 3.5.x and 3.6.x are unable to auto refresh the ACSLS Tree menu (left frame). The frame can be manually refreshed as follows: Right-click in the left frame, select This-Frame -> Reload Frame.

This issue can be resolved by installing the FireBug Add-on to FireFox.

Co-Hosting

Co-hosting other applications with ACSLS 8.0.2 is supported on machines that support logical domains (LDOMs). Because ACSLS drivers are attached to hardware devices, ACSLS must be installed in the primary domain. Co-hosting is otherwise not supported with ACSLS.

Installing ACSLS on Solaris

ACSLs 8.0.2 is comprised of both the ACSLS 8.0.1 Base software, as well as the ACSLS 8.0.2 Update.

The instructions in this document walk you through installing or uninstalling the ACSLS 8.0.1 base software. If you already have ACSLS 8.0.1 installed, you need only to download and install the ACSLS 8.0.2 Update. Refer to the platform specific Readme for instructions for installing and uninstalling the ACSLS 8.0.2 Update.

Note – You must install the ACSLS 8.0.1 Base before you can install the ACSLS 8.0.2 Update.

Downloading ACSLS Software

Download ACSLS from the Oracle e-delivery website.

A separate zip file is created for Solaris SPARC and Solaris x86. If you need both platforms, you must download both zip files.

For Solaris SPARC you see the following zip file:

- ACSLS_8.0.2_SPARC.zip. Unzipping this file creates:
 - ACSLS_8.0.1_SPARC_BASE
 - STKacsls
 - STKacsntp
 - java
 - thirdPartySource
 - ACSLS_8.0.2_SPARC_UPDATE
 - 143783-01
 - ACSLS_README.txt
 - README.143783-01
 - STKacsls
 - patchinfo

For Solaris x86 you see the following zip file:

- ACSLS_8.0.2_X86.zip. Unzipping this file creates:

- ACSLS_8.0.1_X86_BASE
 - STKacsls
 - STKacsnmp
 - java
 - thirdPartySource
- ACSLS_8.0.2_X86_UPDATE
 - 143793-01
 - ACSLS_README.txt
 - README.143793-01
 - STKacsls
 - patchinfo

What's in this Chapter

This chapter describes procedures for installing ACSLS 8.0.1. This chapter discusses:

- [“Exporting the Database” on page 7](#)
- [“Installing Solaris” on page 7](#)
- [“Preparing for ACSLS 8.0.1 Installation” on page 8](#)
- [“Using pkgadd” on page 11](#)
- [“Installing the 8.0.2 Update” on page 12](#)
- [“Using install.sh” on page 12](#)
- [“Setting the ACSLS User Passwords” on page 14](#)
- [“Installing and Configuring your Library Hardware” on page 15](#)
- [“Importing the Database” on page 15](#)
- [“Verifying ACSLS Installation” on page 15](#)
- [“Auditing the Library” on page 16](#)
- [“Uninstalling ACSLS 8.0.1 \(and ACSLS 8.0.2\)” on page 16](#)
- [“Uninstalling any SCSI Media Changer Drivers” on page 17](#)

ACSLs 8.0.1 Installation Tasks

The following table provides a summary of the steps you perform for installing ACSLS 8.0.1:

TABLE 2-1 Installation Tasks

Task	Page
1. Export the database if you are upgrading from a previous version of ACSLS This lets you migrate the database and control files to the new version of ACSLS.	7

TABLE 2-1 Installation Tasks

Task	Page
2. Install the Solaris operating system. The latest Solaris patch cluster is recommended.	7
3. Prepare for ACSLS Installation	8
4. Remove any previous version of ACSLS	10
5. Install the ACSLS package through pkgadd	11
6. Initiate the installation shell script	12
7. Set the user passwords	14
8. Install and configure your library hardware	15
9. Import the database if it was exported.	15
10. Verify your installation	15
11. Audit your libraries	16

Exporting the Database

If you are upgrading from a prior release, you need to export the database and control files.

For more information and procedures, refer to Exporting the Database in the "Database Administration" chapter of the *ACSL 8.0.2 Administrator's Guide*.

Installing Solaris

For installation procedures, please refer to the Solaris Installation instructions.

Note – For our ACSLS development and testing, we install Solaris selecting the "Entire Distribution" option. This is the recommended installation environment however, you may prefer a custom installation of Solaris and this may omit some of the packages that ACSLS requires. Since you can create a custom installation and included packages can differ based on the level of Solaris being installed, we cannot provide a list of required packages for ACSLS.

Note – More restrictive Solaris security may result in certain services not being enabled by default. When installing Solaris, choosing the option to "Enable Remote Services" will insure that all services are available. For example, there are services such as NFS and RPC that need to be enabled so the backup software (such as Netbackup) can communicate properly with ACSLS. ACSLS requires several different OS provided services and this could change based on the level of Solaris and ACSLS. We cannot provide a full list of required services.

ACSLs requires the following requirement be met; otherwise the installation fails or ACSLS does not operate properly:

- Two separate file systems must exist and be mounted: `/export/home` and `/export/backup`.
- `/export/home` and `/export/backup` must be mounted to allow SETUID
- Client services must be enabled.
- SUNWcmco must be installed.
- `umask` must be `022`.

Preparing for ACSLS 8.0.1 Installation

Before you install ACSLS, complete the following steps:

1. Verify that the server system hardware is properly configured, connected, powered on, and ready.
2. Connect the LMU to a valid serial or TCP/IP port.
Most contemporary libraries are TCP/IP or SCSI-attached. Legacy StorageTek libraries, such as Cimmaron, Powerhorn, and the L5500 can be Serial-Attached.
If more than one serial port is available on your server, configure two ports to the LMU. An alternate LMU connection provides higher throughput and greater robustness.
3. Multiple serial port connects are necessary if you are configuring the server to a Dual Serial-Attached LMU installation. You can provide redundant connections to each LMU using a multi-port adapter.
4. If your installation includes a SL8500 library or a 9310 library and TCP/IP LMU(s), connect the TCP/IP LMU(s) to the network used for LMU communication.
5. For SCSI-connected libraries, you should use a differential connection where possible. If a single-ended SCSI controller is used, you should limit the cable distance to three meters between the server and the library. With low-voltage differential (LVD), the cable should be no more than 10 meters. High-voltage differential (HVD) SCSI cables can extend up to 20 meters.
6. Make sure that each attached LMU and LSM is fully configured, powered on, and ready.

Note – The configuration utility, `acsss_config`, will fail unless all LMUs and LSMs are fully configured, powered on, and ready.

7. If you will be using logical libraries to support SCSI clients over Fibre Channel, set up the FC connections between any client HBA ports and suitable HBA ports on the ACSLS server.
8. If you have any communication problems refer to “Troubleshooting” chapter in the *ACSLs Administrator’s Guide*.
9. If you intend to use removable media for database backup, have a blank cartridge available for your backup tape device to complete the configuration process.

10. ACSLS requires specific user IDs. If these user IDs are not defined before ACSLS installation, ACSLS creates them.

Note: If Solaris has been installed with more restrictive security, these accounts may be locked by default. You can check to see if an account is locked by using the "passwd" command:

```
# passwd -s acsss
acsss LK
```

If you see "LK" in the output you need to unlock the account. To unlock the account:

```
# passwd -u acsss
passwd: password information changed for acsss
```

Please check all three accounts, acsss, acssa, and acsdb.

When ACSLS installation creates the user IDs, the system assigns the user ID numbers and group ID numbers. To assign specific user ID and group ID numbers, you must define the following groups and users before installing ACSLS:

User	Group
acsss	staff
acssa	staff
acsdb	acsdb

When these user IDs are defined before ACSLS installation, they can either be defined locally (on the ACSLS server) or via remote authentication methods (e.g., NIS or Kerberos). These user IDs must be defined with the following properties:

- The default shell for acsss and acssa is "ksh". The default shell for acsdb is "sh".
- The home directories for the acsss, acssa, and acsdb user IDs must reside under the ACSLS installation directory. The default installation directory for acsss is /export/home/ACSSS (referred to as \$ACS_Home). The home directories for the ACSLS user IDs are:

```
acsss /export/home/ACSSS
acssa /export/home/ACSSA
acsdb /export/home/acsdb
```

If the home directories for the ACSLS user IDs do not match their required locations, please either modify the home directories for these users or delete the user IDs so they are added correctly during the ACSLS installation process.

The following command creates the acsss user on Solaris. (You must be logged in as root.)

```
useradd -d /export/home/ACSSS -g staff -s /bin/ksh -c "ACSLs Control Login" acsss
```

The account information is:

```
acsss-d /export/home/ACSSS-g staff-c "ACSLs Control Login"-s /bin/ksh
acssa-d /export/home/ACSSA-g staff-c "ACSLs SA Login"-s /bin/ksh
acsdb-d /export/home/acsdb-g acsdb-c "ACSLs Database Owner" -s /sbin/sh
```

The following commands modify the `acsss`, `acssa`, and `acsdb` users' home directories. (You must be logged in as `root`.)

```
usermod -d /export/home/ACSSS acsss
usermod -d /export/home/ACSSA acssa
usermod -d /export/home/ascdb acsdb
```

Note – If the `/etc/cron.d/cron.allow` file exists, verify that the ACSLS `acsss` and `acsdb` user IDs exist within the file. If they don't, add them to the `/etc/cron.d/cron.allow` file; otherwise the cron jobs fail.

Removing any previous version

1. Is this a new installation?

YES	Go to "Using pkgadd" on page 11 .
NO	Make sure you exported the database by using the <code>db_export.sh</code> utility command.

2. Shut down ACSLS:

You need to be logged in as `acsss` to do this.

```
acsss disable
```

3. Login as `root` and remove ACSLS, backup and other files:

ACSLs Version	Procedure
ACSLs 6.0 or 6.0.1 If the <code>server_to_server</code> directory exists	<pre>cd /export/home rm -rf ACSSS informix cd /export/backup rm -rf informix misc rm -rf informix misc server_to_server cd / rm -rf INFORMIXTMP nsr</pre>
ACSLs 6.1 to 7.1	<pre>cd /export/home pkgrm STKacsls cd /export/backup rm -rf informix misc server_to_server cd / rm -rf INFORMIXTMP rm -rf /nsr cd /var/tmp rm -rf acsls</pre>

ACSLs Version	Procedure
ACSLs 7.2 or higher	<pre>cd /export/home pkgrm STKacsls rm -rf ACSs ACSSA acsdb cd /export/backup rm -rf * (this removes all contents of the backup directory)</pre>

- Remove files under second disk (if installed).

```
cd /second_disk
```

If you installed the second disk in another directory other than `/second_disk`, cd to that directory.

```
rm -rf data
cd /second_disk/backup
```

If you installed the second disk in another directory other than `/second_disk/backup`, cd to that directory.

For ACSLS 6.0 and later enter:

```
rm -rf informix misc
```

- Verify that no database processes are running before you begin the install. If in doubt, reboot.

Note – If you are removing ACSLS (and not installing a new version), remove the ACSLS user IDs from `/etc/cron.d/cron.allow`.

Using pkgadd

- Log in as root.
- Install using pkgadd:

```
pkgadd -d .
```

Note – Make sure you enter a space and a period after `-d`

pkgadd asks what package you want installed. There are two packages and they must be installed in the following order:

- STKacsls
- STKsnmp (optional)

Note – ACSLS checks for the required Java version. See [“Software Requirements” on page 1](#).

- If you do not have the required Java version, you need to:

- a. Type:

```
cd java
./setup.sh
```
- b. Enter **y** at the Java 6 prompt.
- c. The java setup script installs Java 1.6.xx automatically on your server in the `/usr` directory.
- d. Type `cd /cdrom/cdrom0`.
- e. Re-install ACSLS using `pkgadd` as described in Step 4.
4. When prompted to select a package, select `STKacsls` and press `[[Return]]`.
ACSLS is installed in `/export/home/`.
5. Type **y** to at the prompt to install `setuid/setgid` files.
6. Select to continue at the super-user permission prompt.
7. Type **y** to at the prompt to install `STKacsls`.
User and group IDs are created (unless they already exist). Files being installed are displayed.
If the `acsss`, `acssa`, or `acsdb` user IDs are not defined with their home directories matching the ACSLS installation directory, the installation script displays a warning, for example:

```
***WARNING*** User acsss already exists, but its home directory
does not match the ACSLS installation directory. Please change the
acsss home directory to
/export/home/ACSSS after the installation.
```

If the `acsss`, `acssa`, or `acsdb` user IDs are created during installation, a default password is not created. You need to go into the `admintool` to create a password. These passwords must be maintained or set to never expire.
8. Type `cd /`.

Note – Continue the installation using `install.sh` as described below.

Installing the 8.0.2 Update

Refer to the Readme instructions for installing the ACSLS 8.0.2 Update.

Using `install.sh`

If this is an update only, skip this procedure.

1. Change directories:

```
cd /export/home/ACSSS/install
```

- To initiate the installation shell script, enter

```
./install.sh
```

- Select `/export/backup`.

The progress of the installation displays

- Enter the HBA port you intend to use for Target-Mode operation for your StorageTek SCSI-attached front-end (logical) libraries.

A contemporary QLogic Fibre HBA (4GB or higher) is required.

In order to implement the logical library feature, it is necessary to define one or more fibre ports on the Solaris machine for use as a target-mode device. Normally an HBA is used in initiator mode in order to initiate SCSI transactions with a remote target device such as a disk drive, tape drive, or media changer device.

Once you have an HBA installed, you receive the following prompt:

```
Please select a desired action:
1) Keep the HBA port configuration as it is.
2) Configure an additional target-mode port.
3) Restore a target port to initiator mode.
```

Option 2 lists the ports that are currently operating in initiator mode. When a port shows "Connected to a remote HBA", it's means there is an initiator at the other end, making the local port a potential candidate to become an ACSLS target port. When a port shows "Connected to a target device", there is probably a tape library or disk attached, so that port would be a bad choice for target mode operations.

An example of option 2 is:

```
Please select which local HBA port is to be changed to Target mode:
```

```
Select from the following list:
```

- HBA Port WWN 2100001b32055d85 Not connected.
- HBA Port WWN 2101001b32255d85 Connected to a remote HBA.
- HBA Port WWN 2102001b32055d85 Connected to a target device.
- None of these.

Note: If you have no intention of using the logical library feature select "none of these".

- Optional Step: If you have a SCSI or fibre-attached library.

Respond `y` to the prompt for installing a SCSI device driver for SCSI-attached libraries.

```
Do you want to install the scsi device driver for SCSI libraries?
(y or n):
```

```
Y      Refer to the following example for the prompts you need
       to answer.
```

This is for SCSI-attached back-end StorageTek libraries.

Note: StorageTek libraries attached behind supported Fibre host-bus adapters (HBAs) can be auto-sensed by ACSLS using the capabilities included in supported HBA software. Supported HBAs currently include all contemporary Qlogic and Sun-branded HBAs. The ACSLS SCSI driver installation utility, `install_scsi_sol.sh` can configure multiple mchanger devices easily without the need for explicit user interaction. Libraries behind non-supported HBAs continue to function in the

traditional manner where you declare the target and LUN address for each attached library. The installation utility then displays each library for which an mchanger instance has been created.

Example

```
Installing 64-bit mchanger
Probing for fibre-attached libraries...
One library found:
  STK L180 V-0310   Target 0 LUN 0
Are there additional libraries attached? (y or n): y
Enter the target:LUN pair corresponding to each library.
Separate target:LUN pairs with a space.
example: 4:0 5:0 5:1 5:2
==> 1:0 1:1
Use target 1 LUN 0
Use target 1 LUN 1
Is this correct? (y or n): y
Instances of 'mchanger' in /dev will be
built sequentially starting with mchanger 0.
Building an mchanger instance for each library...
Successfully built the following...
  /dev/mchanger0: STK L180 174-cells 4-drives
  /dev/mchanger1: STK L700 384-cells 8-drives
  /dev/mchanger2: STK SL500 65-cells 2-drives
```

Library driver installation is complete.

Note – You are now ready to set passwords for each user ID.

Setting the ACSLS User Passwords

ACSLS uses three passwords to allow access and protect the library management resources. To prevent a security exposure, these three passwords **must** be maintained or set to never expire.

- `acsss` - Provides system administration access to all commands and utilities.
- `acssa` - Provides operator access to the `cmd_proc` commands.
- `acsdb` - This is an internal ID that manages the ACSLS database.

You must set the passwords the first time you login to these IDs. To set the passwords:

1. Login to each of the user IDs.
2. Enter the password at the prompt.

If the `acsss`, `acssa`, or `acsdb` user IDs were not defined with their home directories matching the ACSLS installation directory, and the installation script displayed a warning, modify these user IDs so that their home directories are under the ACSLS base directory.

The following commands modify the above users' home directories. (You must be logged in as `root`.)

```

usermod -d /export/home/ACSSS acsss
usermod -d /export/home/ACSSA acssa
usermod -d /export/home/ascdb ascdb

```

Note – If the `/etc/cron.d/cron.allow` file exists, verify that the ACSLS `acsss` and `ascdb` user IDs exist within the file. If they don't, add them to the `/etc/cron.d/cron.allow` file; otherwise the cron jobs fail.

Installing and Configuring your Library Hardware

Caution – If you imported data from a previous ACSLS release, you must start ACSLS and ensure all LSMs are online before configuring any new library hardware. This initializes the LSM types and protects your imported database information.

Note – You do not need to run `acsss_config` if you are importing your previous hardware configuration and are not changing your library hardware.

You must run `acsss_config` or `dynamic_config` to configure your libraries if:

- this is a new installation
- you are adding library hardware

Refer to the “Installing and Configuring Your Library Hardware” chapter in the *ACSLS Administrator's Guide*.

Importing the Database

If you have exported the database and control files, you now need to import them.

If you are migrating to ACSLS 8.0.2 from a previous release and have customized your dynamic or static variables, you need to import them. For information on doing this, refer to Importing the Database in the “Database Administration” chapter of the *StorageTek ACSLS 8.0.2 Administrator's Guide*.

Verifying ACSLS Installation

Use the following procedure to verify ACSLS. You should be logged in as `acsss`. This procedure mounts or dismounts a cartridge.

1. Query the server from the `cmd_proc` by entering


```
query server
```

 If messages are displayed indicating that the server is in mode, wait for a message indicating that the server is running.
2. Verify that the following are online. You must have at least one of each online. If not, bring them online with the `vary` command.

```
query port all
query acs all
query lsm all
query drive all
```

3. Do you have at least one cartridge in an LSM?

YES	Continue with the procedure.
NO	Enter a cartridge into an LSM.

4. Mount a volume by entering:

```
mount vol_id drive_id
```

Use the query drive command to get the ID of an available drive and the query volume command to get the ID of a library cartridge. Refer to the “Installing and Configuring Your Library Hardware” chapter in the *ACSLs Administrator’s Guide*.

5. Did you see a message indicating a successful mount?

A successful mount message is:

```
Mount: vol_id mounted on drive_id
```

YES	Procedure is complete.
NO	If an error message appears, run this verification procedure again, ensuring that you specified a valid, available drive and a library cartridge. If the mount/dismount still fails, call StorageTek for assistance.

6. Dismount the cartridge by entering:

```
dismount vol_id drive_id force
```

where *vol_id* is the volume and *drive_id* is the drive you specified in Step 4.

Auditing the Library

The last step of your installation is auditing your libraries. You also need to audit your libraries:

- If this is a new installation.
- If you are adding new libraries to an existing configuration.

Uninstalling ACSLS 8.0.1 (and ACSLS 8.0.2)

Note – Make sure you exported the database by using the `db_export.sh` utility command.

To uninstall ACSLS:

1. Log in as acsss.
2. Enter `acsss disable`.
3. Remove package:
 - Log in as root.
 - Enter `pkgrm STKacsls`
4. Perform a file cleanup for the disk:
 - `cd /export/home`
 - `rm -rf ACSSS ACSSA acsdb`
 - `cd /export/backup`
 - `rm -rf *` (this removes all contents of the backup directory)
5. Reboot.

Uninstalling any SCSI Media Changer Drivers

1. Login as root.
2. Remove the SCSI Media Changer (mchanger) drivers.
`#rem_drv mchanger`
3. Remove mchanger.conf.
`#rm /usr/kernel/drv/mchanger.conf`
4. Remove any mchanger device links.
`#rm /dev/mchanger*`
5. Remove package directories.
`#rm -rf /opt/STKchanger`

Uninstalling any SCSI Media Changer Drivers

Index

A

ACSLs

- de-installing, 16
- removing backup files, 10
- removing previous versions, 11
- SCSI-attached libraries, 13
- uninstalling, 16
- using pkgadd, 11
- verifying installation, 15

E

- Exporting the database, 7

I

- Installing Solaris, 7

M

mchanger

- example, 13
- uninstalling, 17

S

Solaris

- auditing the library, 16
- configuring library hardware, 15
- exporting the database, 7
- importing the database, 15
- install.sh, 12
- installing, 6
- removing previous version, 10

- setting user password, 14
- uninstalling, 16
- using pkgadd, 11
- verifying installation, 15

Solaris 10, 5

U

- Uninstalling ACSLS
 - Solaris 10, 16

V

- verifying ACSLS, 15