

## **Oracle Integrated Lights Out Manager (ILOM) 3.0**

Supplement for the Sun Netra 6000 Modular  
System



Part No. E21625-01  
April 2011

Copyright © , 2010, 2011, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

---

Copyright © 2010, 2011, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. UNIX est une marque déposée concédée sous licence par X/Open Company, Ltd.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Adobe PostScript

# Contents

---

## **Using This Documentation**   vii

## **Understanding Oracle ILOM on the Modular System**   1

Oracle ILOM Overview   1

Oracle ILOM 3.0 Features Specific to the Modular System   2

    Server Module Power Allocation   3

    Fan Speed Control   3

    Modular System Oracle ILOM Targets   3

## **Configuring CMM ILOM**   5

Logging Into and Out of CMM ILOM   5

    Connectivity Choices   6

        ▼ Log Into the CMM Through the SER MGT Port   7

        ▼ Log Into the CMM ILOM Through the CMM NET MGT Port   8

        ▼ Log Out of CMM ILOM   9

Performing Common CMM ILOM Configuration Tasks   10

        ▼ Change the CMM ILOM `root` Account Password   10

        ▼ Display the CMM Firmware Version   11

        ▼ Display Active Oracle ILOM CMM Sessions   11

        ▼ Add a User Account and Assign Privileges   12

    User Account Roles   14

        ▼ Reset the CMM   14

Viewing and Configuring IP and MAC Addresses   15

- ▼ Identify Modular System IP and MAC Addresses 15
- ▼ Configure the CMM NET MGT Port With a Static IP Address 16
- ▼ Configure the Modular System IP Addresses Using Your DHCP Server 17

#### Managing the CMM Clock 19

- ▼ Display the CMM Clock 19
- ▼ Configure the CMM Clock to Use NTP Servers 20
- ▼ Set the CMM Clock Manually 21

### **Administering the Modular System (CMM ILOM) 23**

#### Managing the Chassis Using the CLI 23

- ▼ View Chassis Components 24
- ▼ Display a List of Targets With Descriptions 26
- ▼ Display Component Information 27
- ▼ Display Indicator Information 28
- ▼ Display Sensor Information 28
- ▼ Display the Modular System Event Log 29
- ▼ Clear the Modular System Event Log 30
- ▼ Control the Locate LED 31
- ▼ Shut Down the Chassis 32
- ▼ Restart the Chassis 32

#### Accessing Server Modules (CMM ILOM) 32

- ▼ Access Oracle ILOM on a Server Module SP 33
- ▼ Exit From the Server Module Service Processor 34
- ▼ Change the Server Module Network Configuration 34

### **Interpreting Sensors 37**

#### Sensor Overview 37

- ▼ Display Sensor Readings (CLI) 38

#### Chassis Sensors 40

Fan Sensors	41
Power Supply Sensors	42
NEM Sensors	44
Server Module Sensors	45

**Identifying SNMP Trap and PET Event Messages 47**

SNMP Traps	48
PET Event Messages	51

**Glossary 55**

**Index 61**



# Using This Documentation

---

This supplement describes Oracle Integrated Lights Out Manager (ILOM) 3.0 features that are specific to Oracle's Sun Netra 6000 modular system. This document is written for system administrators, authorized service providers, and users who have experience administering computer systems. This document is available online in the Sun Netra 6000 Modular System Topic Set and as an individual PDF file.

---

**Note** – This guide provides instructions for the AC and DC models of the modular system. Most of the topics apply to both models unless otherwise noted. Illustrations show one model or the other and might not match your equipment exactly.

---

The following topics are covered:

- “Related Documentation” on page vii
- “Documentation, Support, and Training” on page viii

---

## Related Documentation

The modular system documents listed as online are available at:

(<http://www.oracle.com/pls/topic/lookup?ctx=E19945-01&id=homepage>)

Activity	Title	Format	Location
Late-breaking information	<i>Sun Netra 6000 Modular System Product Notes</i>	PDF	Online
Installation	<i>Sun Netra 6000 AC Modular System Getting Started Guide</i>	Printed,	Shipping kit,
	<i>Sun Netra 6000 DC Modular System Getting Started Guide</i>	PDF	Online
	<i>Rack Alignment Template (AC)</i>	Printed,	Shipping kit
	<i>Rack Alignment Template (DC)</i>	PDF	Online

Activity	Title	Format	Location
	<i>Sun Netra 6000 Modular System Installation Guide</i>	Topic set, PDF	Online
Remote management (ILOM)	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Supplement for the Sun Netra 6000 Modular System</i>	Topic set, PDF	Online
Service	<i>Sun Netra 6000 Modular System Service Guide</i>	Topic set, PDF	Online
Safety	<i>Sun Netra 6000 Modular System Safety and Compliance Manual</i>	PDF	Online
	<i>Important Safety Information for Sun Hardware Systems</i>	Printed	Shipping kit

Additional Oracle Integrated Lights Out Manager (ILOM) documentation is available at:

(<http://www.oracle.com/pls/topic/lookup?ctx=E19860-01&id=homepage>)

	Title
General ILOM 3.0 information	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Getting Started Guide</i>
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Concepts Guide</i>
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Web Interface Procedures Guide</i>
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 CLI Procedures Guide</i>
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Feature Updates and Release Notes</i>
	<i>Oracle Integrated Lights Out Manager (ILOM) 3.0 Management Protocols Reference Guide</i>
	<i>Oracle Integrated Lights Out Manager (ILOM) CMM Administration Guide for Sun Blade 6000 and Sun Blade 6048 Modular Systems</i>

## Documentation, Support, and Training

These web sites provide additional resources:

- Documentation:  
(<http://www.oracle.com/technetwork/documentation/index.html>)



- Support: (<http://support.oracle.com>)
- Training: (<http://education.oracle.com>)



# Understanding Oracle ILOM on the Modular System

---

The following topics provide information about the Oracle ILOM 3.0 software and describe the Oracle ILOM features that are specific to the modular system.

---

**Note** – For a complete discussion of Oracle ILOM 3.0 and its capabilities along with user procedures, refer to the Oracle ILOM 3.0 documentation collection at: (<http://www.oracle.com/pls/topic/lookup?ctx=E19860-01&id=homepage>)

---

- “Oracle ILOM Overview” on page 1
- “Oracle ILOM 3.0 Features Specific to the Modular System” on page 2

## Related Information

- *Modular System Product Notes*
- “Configuring CMM ILOM” on page 5
- “Administering the Modular System (CMM ILOM)” on page 23
- “Interpreting Sensors” on page 37

---

## Oracle ILOM Overview

Oracle ILOM is included in firmware that is preinstalled on Oracle systems. Oracle ILOM enables you to remotely manage your servers regardless of the state of the host system.

You interact with Oracle ILOM through the Oracle ILOM browser-based web interface or through the Oracle ILOM CLI. You can also configure Oracle ILOM to integrate with other management tools in your datacenter.

In the modular system, Oracle ILOM is preinstalled on the CMM and on the SP of each server module.

---

**Note** – To distinguish between Oracle ILOM on the CMM from Oracle ILOM on the server module SPs, this supplement uses the terms *CMM ILOM* and *server module SP ILOM*.

---

You can use CMM ILOM to do the following:

- Customize your CMM ILOM configuration by creating users, and LDAP, RADIUS, and SNMP services.
- Display and configure chassis components such as power supplies, fans, and NEMs.
- Display and configure server modules that are installed in the chassis.
- Control the power state of modular components.
- View the status of indicators and sensors.
- Receive alerts about system events.

For a complete discussion of Oracle ILOM 3.0 and its capabilities along with user procedures, refer to the Oracle ILOM 3.0 documentation collection at:

(<http://www.oracle.com/pls/topic/lookup?ctx=E19860-01&id=homepage>)

### Related Information

- [“Oracle ILOM 3.0 Features Specific to the Modular System” on page 2](#)
- [“Configuring CMM ILOM” on page 5](#)
- [“Administering the Modular System \(CMM ILOM\)” on page 23](#)
- [“Interpreting Sensors” on page 37](#)

---

## Oracle ILOM 3.0 Features Specific to the Modular System

The following Oracle ILOM 3.0 features are product-specific to the modular system.

# Server Module Power Allocation

Oracle ILOM 3.0 manages the power allotment to the server and storage modules.

When a server or storage module is powered on, the module requests power from CMM ILOM. CMM ILOM allocates power to the slot, enabling the module to power on. When a module is powered off, the power allotment is returned to CMM ILOM.

If you have a system full of high-powered modules that exceed the permitted power usage, CMM ILOM limits the number of modules that can power on. In such a situation, you can only power on a subset of modules.

## Fan Speed Control

CMM ILOM uses ambient temperature readings from the power supplies to determine the lowest fan speed that will maintain appropriate temperatures and to ensure the lowest acoustic levels are attained in a NEBs-compliant environment.

## Modular System Oracle ILOM Targets

Oracle ILOM *targets* represent all software and hardware components and services managed by Oracle ILOM. You specify targets when you interact with ILOM.

Targets are identified by a hierarchal path similar to the directories and files of a file system.

The modular system has two top-level ILOM CMM targets that are referred to as *name spaces*:

- */CMM* – Represents the CMM ILOM space. Use this target to configure CMM ILOM attributes for such things as alerts, clients, the ILOM clock, network addresses, and users.
- */CH* – Provides component inventory, environmental status, and hardware management at the chassis level. The subtargets under */CH* correspond to names of the installed hardware components. For example, the subtarget */CH/BL0* is the name space for component that is installed in slot BL0.

Each target has a set of properties. Properties are the configurable attributes specific to each target.

### Related Information

- [“Display a List of Targets With Descriptions” on page 26](#)
- [“Administering the Modular System \(CMM ILOM\)” on page 23](#)

- “Interpreting Sensors” on page 37
- “Oracle ILOM Overview” on page 1

# Configuring CMM ILOM

---

The following topics describe some of the common CMM ILOM configuration tasks for the modular system.

- [“Logging Into and Out of CMM ILOM” on page 5](#)
- [“Performing Common CMM ILOM Configuration Tasks” on page 10](#)
- [“Viewing and Configuring IP and MAC Addresses” on page 15](#)
- [“Managing the CMM Clock” on page 19](#)

## **Related Information**

- [“Understanding Oracle ILOM on the Modular System” on page 1](#)
- [“Administering the Modular System \(CMM ILOM\)” on page 23](#)
- [“Interpreting Sensors” on page 37](#)

---

## Logging Into and Out of CMM ILOM

The following topics provide information about connecting to CMM ILOM on the modular system:

- [“Connectivity Choices” on page 6](#)
- [“Log Into the CMM Through the SER MGT Port” on page 7](#)
- [“Log Into the CMM ILOM Through the CMM NET MGT Port” on page 8](#)
- [“Log Out of CMM ILOM” on page 9](#)


## **Related Information**

- [“Performing Common CMM ILOM Configuration Tasks” on page 10](#)
- [“Managing the CMM Clock” on page 19](#)
- [“Viewing and Configuring IP and MAC Addresses” on page 15](#)

# Connectivity Choices

The following illustration and table show some of the ways you can connect to Oracle ILOM to perform administrative tasks.

Instructions for making cable connections are described in the *Modular System Installation Guide*, connecting to and powering on the modular system.



No.	Source	Destination	Description
1	(Ethernet) CMM NET MGT port	Your network	<p>The CMM Net MGT port is connected to your network.</p> <p>From your network, log into Oracle ILOM on the CMM using the IP address of the CMM. Once logged in, you can navigate to an individual server module SP to administer that server module.</p> <p>You can use the Oracle ILOM CLI or the web interface.</p>



No.	Source	Destination	Description
2	(Serial) CMM SER MGT port	Terminal device	<p>A terminal device is connected to the CMM SER MGT port. From the terminal device, log into Oracle ILOM on the CMM. Once logged in, you can navigate to an individual server module SP to administer that server module.</p> <p>You can only use the Oracle ILOM CLI through this connection.</p> <p><b>Note</b> - To meet NEBs requirements, always use a shielded twisted-pair serial cable.</p>
3	(Local KVM connection) Server module SP UCP port (dongle required)	USB keyboard and mouse, and a VGA monitor	<p>A USB keyboard and mouse are connected to a dongle on the server module. A VGA monitor is connected to the 15-pin dongle connector.</p> <p>You can log into Oracle ILOM on the server module SP using the Oracle ILOM CLI or the web interface.</p>
4	(Serial connection) Server module SP UCP port (dongle required)	Terminal device	<p>A terminal device is connected to a dongle that is connected to a server module.</p> <p>You can log into Oracle ILOM on the server module SP using the CLI.</p>

### Related Information

- [Modular System Installation Guide](#), connecting to and powering on the modular system
- [“Identify Modular System IP and MAC Addresses”](#) on page 15
- [“Configure the CMM NET MGT Port With a Static IP Address”](#) on page 16
- [“Configure the Modular System IP Addresses Using Your DHCP Server”](#) on page 17
- [“Log Into the CMM Through the SER MGT Port”](#) on page 7
- [“Log Into the CMM ILOM Through the CMM NET MGT Port”](#) on page 8
- [“Log Out of CMM ILOM”](#) on page 9

## ▼ Log Into the CMM Through the SER MGT Port

Perform this task when you want to perform CMM ILOM tasks through a serial device rather than through your network.

---

**Note** – You can only run Oracle ILOM CLI commands through the SER MGT port. You cannot run the Oracle ILOM web interface through the SER MGT port.

---

**1. Ensure that you have a terminal device connected to the CMM SER MGT port.**

Refer to *Modular System Installation Guide*, cable the CMM SER MGT port.

When a terminal device is connected and the modular system is powered on, a login prompt is displayed.

**2. From your terminal device, log into the CMM SER MGT port specifying a valid Oracle ILOM user account and password.**

The following factory default CMM ILOM account is valid until changed:

- User account – root
- Password – changeme

This default account has administrator privileges.

Once you are logged in, you communicate with the CMM using the CMM ILOM CLI. For additional CLI details, refer to the *Oracle Integrated Lights Out Manager (ILOM) 3.0 CLI Procedures Guide*.

**Related Information**

- *Modular System Installation Guide*, cable the CMM SER MGT port
- [“Performing Common CMM ILOM Configuration Tasks” on page 10](#)
- [“Connectivity Choices” on page 6](#)
- [“Log Into the CMM ILOM Through the CMM NET MGT Port” on page 8](#)
- [“Log Out of CMM ILOM” on page 9](#)
- [“User Account Roles” on page 14](#)

## ▼ Log Into the CMM ILOM Through the CMM NET MGT Port

Perform this task when you want to access the CMM ILOM through your network. You can use the Oracle ILOM web interface or CLI. Topics in this supplement use the CLI. For Oracle ILOM web interface information, refer to the *Oracle Integrated Lights Out Manager (ILOM) 3.0 Web Interface Procedures Guide*.

**1. Ensure that the following conditions are met:**

- The CMM NET MGT is connected to your network.

Refer to the *Modular System Installation Guide*, cable the CMM NET MGT port, and to [“Identify Modular System IP and MAC Addresses” on page 15](#).

- An IP address is assigned to the CMM and you know the address.  
Refer to *Modular System Installation Guide*, CMM IP address configuration, and to [“Viewing and Configuring IP and MAC Addresses” on page 15](#).
- You know a valid CMM ILOM account and password.

---

**Note** – The default login account is `root` and default password is `changeme`.

---

**2. From your network, use the following syntax followed by the password to log into the CMM ILOM CLI:**

```
ssh ilom_user_name@cmm_ip_address
```

Example:

```
$ ssh root@10.7.94.151
Password: CMM_root_password
->
```

Once you are logged in, the Oracle ILOM `->` prompt is displayed. You can perform Oracle ILOM commands that are valid on the CMM. You can also access and administer the modular components.

**Related Information**

- [“Identify Modular System IP and MAC Addresses” on page 15](#)
- [“Performing Common CMM ILOM Configuration Tasks” on page 10](#)
- [“Connectivity Choices” on page 6](#)
- [“Log Into the CMM Through the SER MGT Port” on page 7](#)
- [“Log Out of CMM ILOM” on page 9](#)
- [“User Account Roles” on page 14](#)

## ▼ Log Out of CMM ILOM

- **Type:**

```
-> exit
Connection to 10.6.153.33 closed.
```

You are logged out of CMM ILOM.

**Related Information**

- [“Connectivity Choices” on page 6](#)

- [“Log Into the CMM Through the SER MGT Port” on page 7](#)
- [“Log Into the CMM ILOM Through the CMM NET MGT Port” on page 8](#)
- [“Change the CMM ILOM root Account Password” on page 10](#)

---

## Performing Common CMM ILOM Configuration Tasks

The following topics describe some of the common activities you perform to configure CMM ILOM for your modular system.

- [“Change the CMM ILOM root Account Password” on page 10](#)
- [“Display the CMM Firmware Version” on page 11](#)
- [“Display Active Oracle ILOM CMM Sessions” on page 11](#)
- [“Add a User Account and Assign Privileges” on page 12](#)
- [“User Account Roles” on page 14](#)
- [“Reset the CMM” on page 14](#)

### Related Information

- [“Logging Into and Out of CMM ILOM” on page 5](#)
- [“Viewing and Configuring IP and MAC Addresses” on page 15](#)
- [“Managing the CMM Clock” on page 19](#)

## ▼ Change the CMM ILOM root Account Password

1. **Log into the CMM ILOM root account.**

See [“Logging Into and Out of CMM ILOM” on page 5](#).

2. **Perform the following Oracle ILOM command to change the password:**

```
-> set /CMM/users/root password=new_password
```

For more information about creating new Oracle ILOM user accounts and assigning a role (privileges) to a user account, refer to Oracle ILOM documentation.

### Related Information

- [“Add a User Account and Assign Privileges”](#) on page 12
- [“Display Active Oracle ILOM CMM Sessions”](#) on page 11

## ▼ Display the CMM Firmware Version

This topic describes how to display the version of CMM ILOM firmware that is running on your modular system. For details on how to update the firmware, refer to *Modular System Product Notes*.

### 1. Log into CMM ILOM as any valid user.

[“Logging Into and Out of CMM ILOM”](#) on page 5.

### 2. View the CMM ILOM version information.

```
-> version
CMM firmware 3.0.6.11
CMM firmware build number: 51292
CMM firmware date: Mon Jan 04 11:01:21 PST 2010
CMM filesystem version: 0.1.22
->
```

### Related Information

- *Modular System Product Notes*, firmware updates

## ▼ Display Active Oracle ILOM CMM Sessions

### 1. Log into CMM ILOM as any valid user.

See [“Logging Into and Out of CMM ILOM”](#) on page 5.

### 2. Display active sessions.

```
-> show /CMM/sessions

/CMM/sessions
  Targets:
    5 (current)

  Properties:
```

```
Commands:
  cd
  show
```

### Related Information

- [“Add a User Account and Assign Privileges” on page 12](#)

## ▼ Add a User Account and Assign Privileges

You can either configure local accounts as described in this topic, or you can have Oracle ILOM authenticate accounts against a remote user database, such as Active Directory, LDAP, LDAP/SSL, or RADIUS. With remote authentication, you can use a centralized user database rather than configuring local accounts on each Oracle ILOM instance. Refer to Oracle ILOM documentation for information about creating remote accounts.

### 1. Log into CMM ILOM as `root`.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Create the user account and assign the password.

```
-> create /CMM/users/nightop
Creating user...
Enter new password: *****
Enter new password again: *****
Created /CMM/users/nightop
```

### 3. Display the user accounts:

```
-> show /CMM/users

/CMM/users
Targets:
  root
  nightop
```

#### 4. Assign roles to the user account using the following syntax.

By default, new user accounts are assigned the role of Read only (o). See [“User Account Roles” on page 14](#).

```
set /SP/users/username role=[aucr]
```

Example:

```
-> set /CMM/users/nightop role=ur
Set 'role' to 'ur'

-> show /CMM/users/nightop

/CMM/users/nightop
  Targets:
    ssh

  Properties:
    role = uro
    password = *****
```

#### Related Information

- [“User Account Roles” on page 14](#)
- [“Logging Into and Out of CMM ILOM” on page 5](#)

# User Account Roles

Role	Description
Admin (a)	Authorized to view and change the state of all Oracle ILOM configuration variables.
Console (c)	Authorized to create and delete user accounts, change user passwords, change roles assigned to other users, and enable or disable the physical-access requirement for the default user account. This role also includes authorization to set up LDAP, LDAP/SSL, RADIUS, and Active Directory.
Read Only (o)	Authorized to access the Oracle ILOM Remote Console and the SP console, and to view and change the state of the Oracle ILOM console configuration variables.
User Management (u)	Authorized to operate the system, which includes power control, reset, hot-plug, enabling and disabling components, and fault management.
Reset and Host Control (r)	Authorized to view the state of the Oracle ILOM configuration variables without making any changes. Users assigned this role can also change the password and the Session Time-Out setting for their own user account.

## Related Information

- [“Add a User Account and Assign Privileges” on page 12](#)
- [“Logging Into and Out of CMM ILOM” on page 5](#)
- [“Reset the CMM” on page 14](#)

## ▼ Reset the CMM

### 1. Log into the CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Reset the CMM:

```
-> reset /CMM
```

## Related Information

- [“Administering the Modular System \(CMM ILOM\)” on page 23](#)



---

# Viewing and Configuring IP and MAC Addresses

The following topics describe how to view and set modular system IP and MAC addresses:

- [“Identify Modular System IP and MAC Addresses” on page 15](#)
- [“Configure the CMM NET MGT Port With a Static IP Address” on page 16](#)
- [“Configure the Modular System IP Addresses Using Your DHCP Server” on page 17](#)

## Related Information

- [“Managing the CMM Clock” on page 19](#)
- [“Logging Into and Out of CMM ILOM” on page 5](#)
- [“Performing Common CMM ILOM Configuration Tasks” on page 10](#)

## ▼ Identify Modular System IP and MAC Addresses

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Display the CMM network information:

```
-> show /CMM/network

/CMM/network
  Targets:
    test

  Properties:
    commitpending = (Cannot show property)
    dhcp_server_ip = none
    ipaddress = 10.7.95.153
    ipdiscovery = static
    ipgateway = 10.7.95.254
    ipnetmask = 255.255.255.0
    macaddress = 00:21:28:3E:2B:B6
    pendingipaddress = 10.7.95.153
    pendingipdiscovery = static
```

```
pendingipgateway = 10.7.95.254
pendingipnetmask = 255.255.255.0
state = enabled
switchconf = port0
```

### 3. Display server module SP network information:

```
-> show /CH/BLx/SP/network

/CH/BL0/SP/network
Targets:

Properties:
  type = Network Configuration
  commitpending = (Cannot show property)
  ipaddress = 10.7.95.155
  ipdiscovery = static
  ipgateway = 10.7.95.254
  ipnetmask = 255.255.255.0
  macaddress = 00:21:28:14:F6:5B
  pendingipaddress = 10.7.95.155
  pendingipdiscovery = static
  pendingipgateway = 10.7.95.254
  pendingipnetmask = 255.255.255.0
  state = enabled
```

#### Related Information

- [“Connectivity Choices” on page 6](#)
- [“Configure the CMM NET MGT Port With a Static IP Address” on page 16](#)
- [“Configure the Modular System IP Addresses Using Your DHCP Server” on page 17](#)

## ▼ Configure the CMM NET MGT Port With a Static IP Address

Use this task to assign a static IP address to the CMM NET MGT port. Alternatively, you can use DHCP services to dynamically assign the IP address as described in [“Configure the Modular System IP Addresses Using Your DHCP Server” on page 17](#).

---

**Note** – When the CMM is configured with a static IP address, the CMM no longer broadcasts for a DHCP address.

---

1. Log into the CMM SER MGT port with an account that has administrator privileges.

See [“Log Into the CMM Through the SER MGT Port”](#) on page 7.

2. Access the CMM network directory:

```
-> cd /CMM/network
```

3. Specify the IP, netmask, and gateway addresses for the CMM ILOM:

```
-> set pendingipaddress=static_IP_address  
-> set pendingipnetmask=static_netmask_address  
-> set pendingipgateway=ip_gateway_address  
-> set pendingipdiscovery=static
```

4. Commit the changes:

```
-> set commitpending=true
```

#### Related Information

- [“Connectivity Choices”](#) on page 6
- [“Identify Modular System IP and MAC Addresses”](#) on page 15
- [“Configure the Modular System IP Addresses Using Your DHCP Server”](#) on page 17

## ▼ Configure the Modular System IP Addresses Using Your DHCP Server

This task uses your DHCP server to dynamically assign the CMM NET MGT port IP address. Alternatively, you can assign a static IP address as described in [“Configure the CMM NET MGT Port With a Static IP Address”](#) on page 16.

---

**Note** – Once you configure the modular system with a static IP address, the modular system no longer broadcasts to receive an IP address from a DHCP server.

---

1. Verify that your DHCP server is configured to accept new MAC addresses.
2. Verify that the CMM NET MGT port is cabled to your network.

### 3. Ensure that the CMM is configured to use DHCP services.

By default, the modular system is configured to use DHCP services. If you want to check and set the configuration, perform the following steps.

#### a. Log into the CMM SER MGT port with an account that has administrator privileges.

See [“Log Into the CMM Through the SER MGT Port” on page 7.](#)

#### b. Check the configuration.

View the `ipdiscovery` property. This property must be set to `dhcp` to use DHCP services.

```
-> show /CMM/network

/CMM/network
Targets:
  test

Properties:
  commitpending = (Cannot show property)
  dhcp_server_ip = none
  ipaddress = 10.7.95.153
  ipdiscovery = static
  ipgateway = 10.7.95.254
  ipnetmask = 255.255.255.0
  macaddress = 00:21:28:3E:2B:B6
  pendingipaddress = 10.7.95.153
  pendingipdiscovery = static
  pendingipgateway = 10.7.95.254
  pendingipnetmask = 255.255.255.0
  state = enabled
  switchconf = port0
```

#### c. If the `ipdiscovery` property is not set to `dhcp`, set it.

```
-> cd /CMM/network
-> set pendingipdiscovery=dhcp
-> set commitpending=true
```

### 4. Apply power to the modular system or reset the CMM.

See [“Reset the CMM” on page 14.](#)

The modular system automatically broadcasts to receive an IP address from a DHCP server.

### Related Information

- [“Connectivity Choices” on page 6](#)
- [“Identify Modular System IP and MAC Addresses” on page 15](#)
- [“Configure the CMM NET MGT Port With a Static IP Address” on page 16](#)

---

## Managing the CMM Clock

The following topics describe how to configure the CMM ILOM clock.

- [“Display the CMM Clock” on page 19](#)
- [“Configure the CMM Clock to Use NTP Servers” on page 20](#)
- [“Set the CMM Clock Manually” on page 21](#)

### Related Information

- [“Logging Into and Out of CMM ILOM” on page 5](#)
- [“Performing Common CMM ILOM Configuration Tasks” on page 10](#)

## ▼ Display the CMM Clock

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Display the clock setting:

```
-> show /CMM/clock

/CMM/clock
Targets:

Properties:
  datetime = Wed Jan 27 18:46:27 2010
  timezone = GMT (GMT)
  usntpserver = disabled

Commands:
  cd
  set
  show
```

### Related Information

- [“Configure the CMM Clock to Use NTP Servers” on page 20](#)
- [“Set the CMM Clock Manually” on page 21](#)

## ▼ Configure the CMM Clock to Use NTP Servers

You can configure the CMM to have an NTP server automatically set the CMM clock.

---

**Note** – NTP servers provide UTC time. Therefore, if NTP is enabled on the CMM ILOM, the CMM ILOM clock is set to UTC time.

---

### 1. Log into the CMM ILOM `root` account.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Configure the CMM to obtain its time setting from NTP servers by using the following syntax:

```
set /CMM/clients/ntp/server/n address=ntpserver_IP_address
set /CMM/clock/usentpserver=enabled
```

- *n* is either 1 for the first NTP server or 2 for the second NTP server.
- *ntpserver\_IP\_address* is the IP address of an NTP server on your network.

Example:

```
-> set /CMM/clients/ntp/server/1 address=125.128.84.16
-> set /CMM/clients/ntp/server/2 address=125.128.84.17
-> set /CMM/clock/usentpserver=enabled
```

---

**Note** – After you enable the NTP service, it can take up to five minutes for the clock to synchronize.

---

### Related Information

- [“Display the CMM Clock” on page 19](#)
- [“Set the CMM Clock Manually” on page 21](#)

## ▼ Set the CMM Clock Manually

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM”](#) on page 5.

### 2. Ensure that the CMM clock is configured for manual setting:

```
-> set /CMM/clock/usentpserver=disabled
```

### 3. Set the CMM clock using the following syntax:

```
set /CMM/clock datetime=MMDDhhmmYYYY
```

where:

- *MM* – month
- *DD* – day
- *hh* – hour
- *mm* – minutes
- *YYYY* – year

The following example sets the CMM clock to January 11, 2010, 9:33 am.

```
-> set /CMM/clock datetime=011109332010
```

### Related Information

- [“Display the CMM Clock”](#) on page 19
- [“Configure the CMM Clock to Use NTP Servers”](#) on page 20





# Administering the Modular System (CMM ILOM)

---

The following topics describe common modular system administrative activities that you perform using CMM ILOM.

- [“Managing the Chassis Using the CLI” on page 23](#)
- [“Accessing Server Modules \(CMM ILOM\)” on page 32](#)

## **Related Information**

- [“Understanding Oracle ILOM on the Modular System” on page 1](#)
- [“Configuring CMM ILOM” on page 5](#)
- [“Interpreting Sensors” on page 37](#)

---

## Managing the Chassis Using the CLI

The following topics describe how to use the CMM ILOM CLI to perform common administrative tasks.

- [“View Chassis Components” on page 24](#)
- [“Display a List of Targets With Descriptions” on page 26](#)
- [“Display Component Information” on page 27](#)
- [“Display Indicator Information” on page 28](#)
- [“Display Sensor Information” on page 28](#)
- [“Display the Modular System Event Log” on page 29](#)
- [“Clear the Modular System Event Log” on page 30](#)
- [“Control the Locate LED” on page 31](#)
- [“Shut Down the Chassis” on page 32](#)
- [“Restart the Chassis” on page 32](#)

## Related Information

- [“Accessing Server Modules \(CMM ILOM\)” on page 32](#)

## ▼ View Chassis Components

For the modular system, targets under the /CH space represent the components.

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Access the chassis space and display the modular system components.

The following example shows output of a typical modular system.

```
-> cd /CH
/CH
-> show
/CH
    Targets:
        BL0
        BL1
        BL2
        BL3
        BL4
        BL6
        BL7
        BL8
        BL9
        CMM
        FM0
        FM1
        FM2
        FM3
        FM4
        FM5
        MIDPLANE
        NEM0
        PS0
        PS1
        HOT
        LOCATE
        OK
        SERVICE
        TEMP_FAULT
        T_AMB0
        VPS
```

```

Properties:
  type = Chassis
  ipmi_name = /CH
  chassis_name = SUN NETRA 6000 MODULAR SYSTEM
  chassis_part_number = 541-3789-01
  chassis_serial_number = 0925BD161D
  chassis_manufacturer = SUN MICROSYSTEMS
  product_name = SUN NETRA 6000 MODULAR SYSTEM
  product_part_number = 541-4254-01
  product_serial_number = 0925BD161D
  product_manufacturer = SUN MICROSYSTEMS
  fru_serial_number = 1005LCB-0918YK00PR
  fault_state = OK
  clear_fault_action = (none)
  power_state = On

Commands:
  cd
  set
  show
  start
  stop

```

3. View the items under Properties for information about the target.

4. View information about subtargets.

Either navigate to the subtarget, or specify the subtarget with the show command.

- Navigate to the subtarget.

Example:

```

-> cd NEM0
/CH/NEM0

-> show

/CH/NEM0
  Targets:
    PRSNT

  Properties:
    type = Network Express Module
    ipmi_name = NEM0
    fault_state = OK
    clear_fault_action = (none)

  Commands:

```

```
cd
set
show
```

- Type the show command and specify the subtarget.

Example:

```
-> show NEM0

/CH/NEM0
  Targets:
    PRSNT

  Properties:
    type = Network Express Module
    ipmi_name = NEM0
    fault_state = OK
    clear_fault_action = (none)

  Commands:
    cd
    set
    show
```

### Related Information

- [“Display a List of Targets With Descriptions” on page 26](#)
- *Modular System Installation Guide*, modular system overview

## ▼ Display a List of Targets With Descriptions

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Type:

```
-> help targets
```

Target	Meaning
/	Hierarchy Root
/CH	Sensors, Indicators, and FRU Information
/CMM	Chassis Monitoring Module
/CMM/alertmgmt	Alert rule management
/CMM/alertmgmt/rules	Alert rules

/CMM/check_physical_presence	Require a physical presence check for certain system commands
/CMM/cli	Command line interface
/CMM/clients	Clients that connect to external services
.	
.	
.	< remaining output omitted >

### Related Information

- *Modular System Installation Guide*, modular system overview
- *Modular System Installation Guide*, modular system overview
- [“View Chassis Components” on page 24](#)

## ▼ Display Component Information

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Use the Oracle ILOM `show` command with a target.

The following example displays information about a server module in slot BL4:

```
-> show /CH/BL4

/CH/BL4
Targets:
  ERR
  PRSNT
  STATE
  VPS
  SP
  SYS

Properties:
  type = Blade
  ipmi_name = BL4
  product_name = SUN NETRA X6270 SERVER MODULE
  product_part_number = 000-0000-00
  product_serial_number = 0000000000
  fru_name = ASSY, BLADE, X6270
  fru_part_number = 501-7918-09
  fru_serial_number = 0328MSL-09174Y01GX
  fru_extra_1 = FW 3.0.6.10
  fault_state = OK
  clear_fault_action = (none)
```

### Related Information

- [“View Chassis Components” on page 24](#)
- [“Display Indicator Information” on page 28](#)
- [“Display Sensor Information” on page 28](#)

## ▼ Display Indicator Information

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Use the Oracle ILOM `show` command with a target.

The following example displays information about the Service indicator:

```
-> show SERVICE

/CH/SERVICE
  Targets:

  Properties:
    type = Indicator
    ipmi_name = SERVICE
    value = Off
```

### Related Information

- [“Display Component Information” on page 27](#)
- [“Display Sensor Information” on page 28](#)

## ▼ Display Sensor Information

---

**Note** – For detailed sensor information, see [“Interpreting Sensors” on page 37](#).

---

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

## 2. Use the Oracle ILOM `show` command with a target.

The following example displays information about a temperature sensor (T\_AMB0):

```
-> show /CH/T_AMB0

/CH/T_AMB0
Targets:

Properties:
    type = Temperature
    ipmi_name = T_AMB0
    class = Threshold Sensor
    value = 30.000 degree C
    upper_nonrecov_threshold = N/A
    upper_critical_threshold = N/A
    upper_noncritical_threshold = N/A
    lower_noncritical_threshold = N/A
    lower_critical_threshold = N/A
    lower_nonrecov_threshold = N/A
    alarm_status = cleared
```

### Related Information

- [“Interpreting Sensors” on page 37](#)
- [“View Chassis Components” on page 24](#)
- [“Display Component Information” on page 27](#)
- [“Display Indicator Information” on page 28](#)

## ▼ Display the Modular System Event Log

---

**Note** – The CMM ILOM tags all events or actions with `LocalTime=GMT` (or `UDT`). Browser clients show these events in local time, which can cause apparent discrepancies in the event log.

---

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Display the system event log.

```
-> show /CMM/logs/event/list

/CMM/logs/event/list
```

Targets:

Properties:

Commands:

cd  
show

ID	Date/Time	Class	Type	Severity
808	Wed Jan 6 20:09:21 2010	IPMI	Log	critical
ID = 2df : pre-init timestamp : Module/Board : BL0/STATE : Transition to Running				
807	Wed Jan 6 20:08:51 2010	IPMI	Log	critical
ID = 2de : pre-init timestamp : Module/Board : BL0/STATE : Transition to Power Off				
806	Wed Jan 6 20:05:48 2010	Fault	Repair	minor
Fault fault.chassis.device.fail on component /CH/BL0 cleared				
805	Won Jan 4 20:05:48 2010	IPMI	Log	critical
ID = 2dd : pre-init timestamp : OEM sensor : BL0/ERR : Predictive Failure Deasserted				
804	Wed Jan 6 19:59:10 2010	IPMI	Log	critical
ID = 2dc : pre-init timestamp : Module/Board : BL0/STATE : Transition to Running				
803	Wed Jan 6 19:58:39 2010	IPMI	Log	critical
ID = 2db : pre-init timestamp : Module/Board : BL0/STATE : Transition to Power Off				
802	Wed Jan 6 19:55:21 2010	Fault	Fault	critical
Fault detected at time = Wed Apr 5 19:55:21 1972. The suspect component: /CH/BL0 has fault.chassis.device.fail with probability=100.				

Paused: press any key to continue, or 'q' to quit

### 3. Control the display with the following keys:

- Scroll down – Type any key except q.
- Stop displaying the event log – Type q.

### Related Information

- [“Clear the Modular System Event Log” on page 30](#)

## ▼ Clear the Modular System Event Log

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).



## 2. Clear the event log.

```
-> set clear=true  
Are you sure you want to clear /CMM/logs/event (y/n)? y  
Set 'clear' to 'true'
```

### Related Information

- [“Display the Modular System Event Log” on page 29](#)

## ▼ Control the Locate LED

You can illuminate the white modular system Locate LED to help you find a particular device in a crowded equipment room.

---

**Note** – You can also control the Locate LED by pressing the Locate LED toggle button on the chassis. Typically you turn on the Locate LED from CMM ILOM. When you identify the modular system in your data center, you manually turn off the Locate LED.

---

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Perform one of the following commands:

- Turn on the Locate LED:

```
-> set /CH/LOCATE value=Fast_Blink
```

- Turn off the Locate LED:

```
-> set /CH/LOCATE value=Off
```

### Related Information

- [“Shut Down the Chassis” on page 32](#)
- [“Restart the Chassis” on page 32](#)

## ▼ Shut Down the Chassis



---

**Caution** – Do not shut down the chassis unless all the server modules in the chassis are shut down. Shutting down the chassis when server modules are not shut down can damage chassis components and the server modules.

---

This command shuts down the entire chassis, including fans, power supplies, and all server modules.

**1. Log into CMM ILOM.**

See [“Logging Into and Out of CMM ILOM” on page 5.](#)

**2. Type:**

```
-> stop /CH
```

**Related Information**

- [“Restart the Chassis” on page 32](#)
- [“Reset the CMM” on page 14](#)

## ▼ Restart the Chassis

**1. Log into CMM ILOM.**

See [“Logging Into and Out of CMM ILOM” on page 5.](#)

**2. Type:**

```
-> start /CH
```

**Related Information**

- [“Shut Down the Chassis” on page 32](#)
- [“Reset the CMM” on page 14](#)

---

# Accessing Server Modules (CMM ILOM)

You can access Oracle ILOM running on the server module SPs through CMM ILOM.

The following topics discuss how to access server modules from CMM ILOM. For more comprehensive topics, refer to the Oracle ILOM documentation.

- [“Access Oracle ILOM on a Server Module SP” on page 33](#)
- [“Exit From the Server Module Service Processor” on page 34](#)
- [“Change the Server Module Network Configuration” on page 34](#)

### Related Information

- [“Managing the Chassis Using the CLI” on page 23](#)

## ▼ Access Oracle ILOM on a Server Module SP

You must know the server module SP password to perform this task.

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Navigate to the desired server module SP.

Server modules are identified by their chassis slot ID (0–9). Using the following example, replace the *n* with the number of your server module.

```
-> cd /CH/BLn/SP/cli  
/CH/BL2/SP/cli
```

### 3. Initiate the connection and type the server module SP password.

---

**Note** – The CMM ILOM logs into the server module SP using the user name in the user target under `/CH/BLn/SP/cli` (where *n* is the server module number). The default is `root`.

---

```
-> start  
Are you sure you want to start /CH/BL2/SP/cli (y/n)? y  
Password: server_mod_SP_password  
...  
->
```

You are accessing the Oracle ILOM on the server module SP. Refer to the server module documentation for valid Oracle ILOM commands.

### Related Information

- [“Exit From the Server Module Service Processor” on page 34](#)
- [“Change the Server Module Network Configuration” on page 34](#)

## ▼ Exit From the Server Module Service Processor

- If you are connected to a server module SP, perform this task to exit.

```
-> exit
Connection to 10.6.153.33 closed.

->
```

You are returned to CMM ILOM.

### Related Information

- [“Access Oracle ILOM on a Server Module SP” on page 33](#)

## ▼ Change the Server Module Network Configuration

You can configure the Ethernet addressing of a server module’s SP through CMM ILOM.

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).

### 2. Navigate to the server module SP network space:

```
-> cd /CH/BLn/SP/network
```

Replace *n* with the slot number of the server module.

### 3. Set the server module SP network parameters according to your networking environment.

- Example of setting the server module SP with static IP addressing:

```
-> set pendingipaddress=server_mod_SP_IP_address
```

```
-> set pendingipnetmask=server_mod_SP_netmask_addr  
-> set pendingipgateway=server_mod_SP_gateway_addr  
-> set pendingipdiscovery=static
```

- Example of setting the server module SP to use DHCP:

```
-> set pendingipdiscovery=dhcp
```

#### 4. Commit your changes.

```
-> set commitpending=true
```

#### Related Information

- [“Access Oracle ILOM on a Server Module SP” on page 33](#)
- [“Exit From the Server Module Service Processor” on page 34](#)



# Interpreting Sensors

---

The following topics describe the modular system sensors.

- [“Sensor Overview” on page 37](#)
- [“Display Sensor Readings \(CLI\)” on page 38](#)
- [“Chassis Sensors” on page 40](#)
- [“Fan Sensors” on page 41](#)
- [“Power Supply Sensors” on page 42](#)
- [“NEM Sensors” on page 44](#)
- [“Server Module Sensors” on page 45](#)

## **Related Information**

- [“Understanding Oracle ILOM on the Modular System” on page 1](#)
- [“Configuring CMM ILOM” on page 5](#)
- [“Administering the Modular System \(CMM ILOM\)” on page 23](#)

---

## Sensor Overview

The modular system is equipped with a number of IPMI-compliant sensors that measure voltages, temperatures, fan speeds, and other attributes. Sensors also detect when components are installed and removed.

CMM ILOM regularly polls the sensors and reports any events about sensor state changes or threshold crossings to the Oracle ILOM event log. If sensors detect a condition that indicates that service might be required, Oracle ILOM illuminates modular system LEDs.

You can view sensor readings from the Oracle ILOM web interface or CLI.

There are two types of sensors:

Type	Description	Information Displayed
Discrete	Displays a single value from a set of possible values.	Targets – If applicable, subsensors are listed. Properties: <ul style="list-style-type: none"><li>• Type – Describes the sensor type.</li><li>• Class – Indicates if the sensor is discrete or a threshold sensor.</li><li>• Value – Shows the sensor value.</li></ul>
Threshold	Displays analog readings, such as temperature or voltage levels, and associated thresholds for that reading.	Targets – If applicable, subsensors are listed. Properties: <ul style="list-style-type: none"><li>• Type – Describes the sensor type.</li><li>• Value – A near real-time analog reading from the sensor.</li><li>• Units – Specifies the units for the value.</li><li>• Threshold – A definition of the type of threshold.</li></ul>

### Related Information

- [“Display Sensor Readings \(CLI\)” on page 38](#)
- [“Chassis Sensors” on page 40](#)
- [“Fan Sensors” on page 41](#)
- [“Power Supply Sensors” on page 42](#)
- [“NEM Sensors” on page 44](#)
- [“Server Module Sensors” on page 45](#)

## ▼ Display Sensor Readings (CLI)

### 1. Log into CMM ILOM.

See [“Logging Into and Out of CMM ILOM” on page 5](#).



## 2. Use the following syntax to display sensor data:

`show target`

where *target* is the path to the sensor. All chassis sensors are located in the /CH space.

The properties describing the sensor are displayed.

Example:

```
-> show /CH/FM3/F0/TACH

/CH/FM3/F0/TACH
Targets:

Properties:
    type = Fan
    ipmi_name = FM3/F0/TACH
    class = Threshold Sensor
    value = 3200.000 RPM
    upper_nonrecov_threshold = N/A
    upper_critical_threshold = N/A
    upper_noncritical_threshold = N/A
    lower_noncritical_threshold = N/A
    lower_critical_threshold = N/A
    lower_nonrecov_threshold = N/A
    alarm_status = cleared
```

---

**Note** – Alternatively, you can navigate to the target and type the `show` command without any arguments.

---

### Related Information

- [“Chassis Sensors” on page 40](#)
- [“Fan Sensors” on page 41](#)
- [“Power Supply Sensors” on page 42](#)
- [“NEM Sensors” on page 44](#)
- [“Server Module Sensors” on page 45](#)
- [“Sensor Overview” on page 37](#)

# Chassis Sensors

The following tables list the chassis sensors.

Sensor	Reading	State	Event	Description
/CH/HOT	0x0001	State Deasserted	No	Indicates that monitored temperatures do not require full fan speed.
	0x0002	State Asserted	No	Indicates that monitored temperatures require increased fan speed.

Sensor	Threshold	Description
/CH/T_AMBO	Value	Reports ambient temperature in the chassis midplane.
	Upper nonrecoverable	
	Upper critical	
	Upper noncritical	
	Lower noncritical	
	Lower critical	
	Lower nonrecoverable	
/CH/VPS	Value	Virtual power sensors that report the total power used by the chassis (the sum of PS0 / IN_POWER and PS1 / IN_POWER).
	Upper nonrecoverable	
	Upper critical	
	Upper noncritical	
	Lower noncritical	
	Lower critical	
	Lower nonrecoverable	

## Related Information

- [“Display Sensor Readings \(CLI\)” on page 38](#)

- [“Fan Sensors” on page 41](#)
- [“Power Supply Sensors” on page 42](#)
- [“NEM Sensors” on page 44](#)
- [“Server Module Sensors” on page 45](#)
- [“Sensor Overview” on page 37](#)

# Fan Sensors

The modular system chassis contains six fan modules, numbered FM0 to FM5. Each module contains two fans, numbered F0 to F1.

Sensor	Threshold	Direction	Event	Description
/CH/FM <i>n</i> /F <i>n</i> /TACH	Lower nonrecoverable	Assert	Yes	Fan speed has decreased below lower nonrecoverable threshold. Indicates that the fan has failed or has been removed.
	Lower noncritical	Deassert	Yes	Fan speed has returned to normal from lower nonrecoverable. Indicates that the fan has returned to normal or has been replaced.

Sensor	Reading	State	Event	Description
/CH/FM <i>n</i> /ERR	0x0001	Predictive Failure Deasserted	No	Indicates that the fan module has not failed.
	0x0002	Predictive Failure Asserted	Yes	Indicates that the fan module has failed.

## Related Information

- [“Display Sensor Readings \(CLI\)” on page 38](#)
- [“Chassis Sensors” on page 40](#)
- [“Power Supply Sensors” on page 42](#)
- [“NEM Sensors” on page 44](#)
- [“Server Module Sensors” on page 45](#)
- [“Sensor Overview” on page 37](#)

# Power Supply Sensors

The modular system chassis contains two power supply modules, numbered PS0 and PS1. Each power supply module contains two *sides*, numbered S0 and S1.

**Note** – The power sensors are only accurate when the chassis is drawing a significant amount of power. Under low power conditions, the chassis cannot accurately measure power and reports no reading. Typically, accurate power cannot be reported if the chassis is drawing less than 1500W.

Sensor	Reading	State	Event	Description
/CH/PSn/PRST	0x0001	Device Absent	Yes	Power supply is absent.
	0x0002	Device Present	Yes	Power supply is present.
/CH/PSn/V_3V3_ERR	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply 3_3V fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply 3_3V fault has occurred.
/CH/PSn/TEMP_WRN	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply ambient temperature has not reached the 50°C to 60°C range.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply ambient temperature has reached the 50°C to 60°C range.
/CH/PSn/TEMP_ERR	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply temperature fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply temperature fault has occurred.
/CH/PSn/FAN_ERR	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply fan fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply fan fault has occurred.
/CH/PSn/Sn/V_OUT_OK	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply side fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply side fault has occurred.

Sensor	Reading	State	Event	Description
/CH/PSn/Sn/V_IN_ERR	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply side fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply side fault has occurred.
/CH/PSn/Sn/V_12V_ERR	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply side 12V voltage fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply side 12V voltage fault has occurred.
/CH/PSn/Sn/I_12V_ERR	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply side 12V voltage fault has not occurred.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply side 12V voltage fault has occurred.
/CH/PSn/Sn/I_12V_WRN	0x0001	Predictive Failure Deasserted	No	Indicates that a power supply side 12V current does not exceed 240A for 100 msec.
	0x0002	Predictive Failure Asserted	Yes	Indicates that a power supply side 12V current exceeds 240A for 100 msec.

The following table describes the threshold sensors for power supplies.

Sensor	Description
/CH/PSn/IN_POWER	Threshold sensors that report the input (AC) power to the power supplies in Watts.
/CH/PSn/OUT_POWER	Threshold sensors that report the output (DC) power from the power supplies in Watts.
/CH/PSn/T_AMB	Threshold sensors that report the ambient temperature of the power supply modules.
/CH/PSn/V_12V	Threshold sensors that report the power supply module 12V voltage reading.
/CH/PSn/V_3V3	Threshold sensors that report the power supply module 3.3V voltage reading.
/CH/PSn/I_3V3	Threshold sensors that report the power supply module 3.3V current rating.
/CH/PSn/FANn/TACH	Threshold sensors that report the speed of the two fans in the power supply.
/CH/PSn/Sn/I_12V	Threshold sensors that report the power supply side 12V voltage reading.

### Related Information

- [“Display Sensor Readings \(CLI\)” on page 38](#)
- [“Chassis Sensors” on page 40](#)
- [“Fan Sensors” on page 41](#)
- [“NEM Sensors” on page 44](#)
- [“Server Module Sensors” on page 45](#)
- [“Sensor Overview” on page 37](#)

---

## NEM Sensors

The following table lists possible sensors for NEMs (NEM0 and NEM1).

---

**Note** – Not all NEMs have all sensors.

---

Sensor	Reading	State	Event	Description
NEM <i>n</i> / PRSNT	0x0001	Device Absent	Yes	NEM is absent.
	0x0002	Device Present	Yes	NEM is present.
NEM <i>n</i> / STATE	0x0001	Running	Yes	NEM is running.
	0x0004	Powered Off	Yes	NEM is powered off.
	0x0040	Degraded	Yes	NEM needs to be serviced.
NEM <i>n</i> / ERR	0x0001	Predictive Failure Asserted	Yes	NEM has failed.
	0x0002	Predictive Failure Deasserted	Yes	NEM has not failed.

### Related Information

- [“Display Sensor Readings \(CLI\)” on page 38](#)
- [“Chassis Sensors” on page 40](#)
- [“Fan Sensors” on page 41](#)
- [“Power Supply Sensors” on page 42](#)
- [“Server Module Sensors” on page 45](#)
- [“Sensor Overview” on page 37](#)

# Server Module Sensors

The following tables lists possible sensors for server modules. Not all server modules have all sensors.

Sensor	Reading	State	Event	Description
BLn / PRSNT	0x0001	Device Absent	No	Server module is not present.
	0x0002	State Present	No	Server module is present.
BLn / STATE	0x0001	Running	No	Server module is running.
	0x0004	Power Off	No	Server module is not powered off.
	0x0020	Off Duty	No	Server module is ready to remove.
BLn / ERR	0x0001	Predictive Failure Asserted	Yes	Server module has failed.
	0x0002	Predictive Failure Deasserted	Yes	Server module has not failed.
BLn / VPS	n/a	n/a	n/a	Reports the virtual power for the server modules.

## Related Information

- [“Display Sensor Readings \(CLI\)” on page 38](#)
- [“Chassis Sensors” on page 40](#)
- [“Fan Sensors” on page 41](#)
- [“Power Supply Sensors” on page 42](#)
- [“NEM Sensors” on page 44](#)
- [“Sensor Overview” on page 37](#)





# Identifying SNMP Trap and PET Event Messages

---

These topics describe SNMP trap and PET event messages that are generated by devices that Oracle ILOM monitors.

- [“SNMP Traps” on page 48](#)
- [“PET Event Messages” on page 51](#)

## **Related Information**

- *Oracle Integrated Lights Out Manager (ILOM) 3.0 Management Protocols Reference Guide*

---

# SNMP Traps

SNMP traps are generated by the SNMP agents that are installed on the SNMP devices being managed by Oracle ILOM. Oracle ILOM receives the SNMP traps and converts them into SNMP event messages that appear in the event log.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
event fault.chassis. device.fail	sunHwTrapIOFault	/CH/NEM	Major	A component in the IO subsystem is suspected of causing a fault.
event fault.chassis. device.fail	sunHwTrapIOFaultCleared	/CH/NEM	Informational	An IO subsystem component fault has been cleared.
Upper critical threshold exceeded	sunHwTrapTempCritThreshol dExceeded	/CH/T_AMB /CH/PSx/T_AMB	Major	A temperature sensor has reported that its value has gone above an upper critical threshold setting or below a lower critical threshold setting.
Upper critical threshold no longer exceeded	sunHwTrapTempCritThreshol dDeasserted	/CH/T_AMB /CH/PSx/T_AMB	Informational	A temperature sensor has reported that its value has gone below an upper critical threshold setting or above a lower critical threshold setting.
Upper fatal threshold exceeded	sunHwTrapTempFatalThresho ldExceeded	/CH/T_AMB /CH/PSx/T_AMB	Critical	A temperature sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
Upper fatal threshold no longer exceeded	sunHwTrapTempFatalThresholdDeasserted	/CH/T_AMB /CH/PSx/T_AMB	Informational	A temperature sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting.
Assert	sunHwTrapPowerSupplyError	/CH/P_OVER_WARN	Major	A power supply sensor has detected an error.
Deassert	sunHwTrapPowerSupplyOk	/CH/P_OVER_WARN	Informational	A power supply sensor has returned to its normal state.
Assert	sunHwTrapComponentError	/CH/HOT /CH/PSx/Sx/V_OUT_OK	Major	A sensor has detected an error. This generic <i>component</i> trap is generated when the SNMP agent does not recognize the component type.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
Deassert	sunHwTrapCComponentOk	/CH/HOT /CH/PSx/Sx/V_OUT_OK	Informational	A sensor has returned to its normal state. This generic <i>component</i> trap is generated when the SNMP agent does not recognize the component type.
Lower fatal threshold exceeded	sunHwTrapFanSpeedFatalThresholdExceeded	/CH/PSx/FANx/TACH	Critical	A fan speed sensor has reported that its value has gone above an upper fatal threshold setting or below a lower fatal threshold setting.
Lower fatal threshold no longer exceeded	sunHwTrapFanSpeedFatalThresholdDeasserted	/CH/PSx/FANx/TACH	Informational	A fan speed sensor has reported that its value has gone below an upper fatal threshold setting or above a lower fatal threshold setting.

# PET Event Messages

PET events are generated by systems with ASF or an IPMI baseboard management controller. The PET events provide advance warning of possible system failures.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
Temperature Upper critical threshold has been exceeded	petTrapTemperatureUpperNonCriticalGoingHigh	/CH/T_AMB /CH/PSx/T_AMB	Major	Temperature has increased above upper critical threshold.
Temperature Upper critical threshold no longer exceeded	petTrapTemperatureUpperNonCriticalGoingLowDeassert	/CH/T_AMB /CH/PSx/T_AMB	Warning	Temperature has decreased below upper critical threshold.
Temperature Lower fatal threshold has been exceeded	petTrapTemperatureUpperNonRecoverableGoingHigh	/CH/T_AMB /CH/PSx/T_AMB	Critical	Temperature has increased above upper nonrecoverable threshold.
Temperature Lower fatal threshold no longer exceeded	petTrapTemperatureUpperNonRecoverableGoingLowDeassert	/CH/T_AMB /CH/PSx/T_AMB	Major	Temperature has decreased below upper nonrecoverable threshold.
Temperature sensor ASSERT	petTrapTemperatureStateAssertedAssert	/CH/HOT	Critical	Temperature event occurred. Possible cause: CPU is too hot.
Temperature sensor DEASSERT	petTrapTemperatureStateDeassertedAssert	/CH/HOT	Informational	Temperature event occurred.
Entity Presence Insert	petTrapEntityPresenceDeviceInsertedAssert	/CH/BLx/PRSNT /CH/BLx/HDDx/PRSNT /CH/BLx/FMODx/PRSNT /CH/BLx/ESM/PRSNT /CH/NEMx/PRSNT /CH/PSx/PRSNT	Informational	A device is present or has been inserted.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
Entity Presence Remove	petTrapEntityPresenceDe viceRemovedAssert	/CH/BLx/PRSNT /CH/BLx/HDDx/PRSNT /CH/BLx/FMODx/PRSNT /CH/BLx/ESM/PRSNT /CH/NEMx/PRSNT /CH/PSx/PRSNT	Informational	A device is absent or has been removed.
Module Transition to Running assert	petTrapModuleBoardTrans itionToRunningAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	A device has transitioned to the normal running state. For a blade, this indicates that the host has powered on.
Module Transition to In Test assert	petTrapModuleBoardTrans itionToInTestAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	A device is in a transitional state. (Only used for NEMs.)
Module Transition to Power Off assert	petTrapModuleBoardTrans itionToPowerOffAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	A device has powered off.
Module Transition to On Line assert	petTrapModuleBoardTrans itionToOnLineAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	A device is online and ready to enter the running state. (Only used for NEMs.)
Module Transition to Off Line assert	petTrapModuleBoardTrans itionToOffLineAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	Unused.
Module Transition to Off Duty assert	petTrapModuleBoardTrans itionToOffDutyAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	A device is no longer in use and is ready to be removed.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
Module Transition to Degraded assert	petTrapModuleBoardTransitionToDegradedAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	A device has entered a state of degraded operation, for example, due to a hardware fault or an overtemperature condition that caused the device to shut itself down.
Module Transition to Power Save assert	petTrapModuleBoardTransitionToPowerSaveAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	Unused.
Module Install Error assert	petTrapModuleBoardInstallErrorAssert	/CH/BLx/STATE /CH/NEMx/STATE	Informational	Unused.
OEM Reserved reporting Predictive Failure	petTrapOEMPredictiveFailureAsserted 12583937 QUESTION This number was in the C10 doc. Was it supposed to be there?	/CH/BLx/ERR /CH/BLx/ESM/ERR /CH/NEMx/ERR	Major	OEM predictive failure asserted.
OEM Reserved Return to normal	petTrapOEMPredictiveFailureDeasserted	/CH/BLx/ERR /CH/BLx/ESM/ERR /CH/NEMx/ERR	Informational	OEM predictive failure deasserted.
Fan reporting Predictive Failure	petTrapFanPredictiveFailureAsserted	/CH/FMx/ERR /CH/PSx/FAN_ERR	Major	Fan Predictive Failure detected.
Fan Return to normal	petTrapFanPredictiveFailureDeasserted	/CH/FMx/ERR /CH/PSx/FAN_ERR	Informational	Fan Predictive Failure state has been cleared.
Voltage reporting Predictive Failure	petTrapVoltagePredictiveFailureAssertedAssert	/CH/PSx/V_3V3_ERR /CH/PSx/Sx/V_IN_ERR /CH/PSx/Sx/V_12V_ERR	Major	Voltage Predictive Failure detected.
Voltage Return to normal	petTrapVoltagePredictiveFailureDeassertedAssert	/CH/PSx/V_3V3_ERR /CH/PSx/Sx/V_IN_ERR /CH/PSx/Sx/V_12V_ERR	Informational	Predictive failure state due to voltage event has been cleared.

SNMP Event	SNMP Trap Sent	Sensor Name	Severity	Description
Temperature reporting Predictive Failure	petTrapTemperaturePredictiveFailureAsserted	/CH/PSx/TEMP_WRN /CH/PSx/TEMP_ERR	Major	System is reporting a predictive failure as a result of high temperature.
Temperature Return to normal	petTrapTemperaturePredictiveFailureDeasserted	/CH/PSx/TEMP_WRN /CH/PSx/TEMP_ERR	Informational	Predictive failure state due to high temperature has been cleared.
Fan Lower fatal threshold has been exceeded	petTrapFanLowerNonRecoverableGoingLow	/CH/PSx/FANx/TACH	Critical	Fan speed has decreased below lower nonrecoverable threshold. Fan failed or removed.
Fan Lower fatal threshold no longer exceeded	petTrapFanLowerNonRecoverableGoingHighDeasserted	/CH/PSx/FANx/TACH	Major	Fan speed has increased above lower nonrecoverable threshold.
Voltage sensor ASSERT	petTrapVoltageStateAssertedAssert	/CH/PSx/Sx/V_OUT_OK	Informational	Voltage event occurred.
Voltage sensor DEASSERT	petTrapVoltageStateDeassertedAssert	/CH/PSx/Sx/V_OUT_OK	Informational	Voltage event occurred.
Current reporting Predictive Failure	petTrapCurrentPredictiveFailureAsserted	/CH/PSx/Sx/I_12V_ERR /CH/PSx/Sx/I_12V_WRN	Major	Predictive Failure due to electric current conditions.
Current Return to normal	petTrapCurrentPredictiveFailureDeasserted	/CH/PSx/Sx/I_12V_ERR /CH/PSx/Sx/I_12V_WRN	Informational	Predictive failure caused by electric current conditions.



# Glossary

---

---

## A

**ASF** Alert standard format.

---

## B

**blade** Generic term for server modules and storage modules.

**blade server** Server module.

---

## C

**chassis** Modular system enclosure.

**CMM** Chassis monitoring module. Oracle ILOM runs on the CMM providing lights out management of the components in the chassis. See [Oracle ILOM](#).

**CMM ILOM** Oracle ILOM that runs on the CMM. See [Oracle ILOM](#).

**CRU** Customer-replaceable unit.

---

## D

**disk module or disk blade** Interchangeable terms for storage module.

---

## E

**ESD** Electrostatic discharge.

---

## F

**FEM** Fabric expansion module. FEMs enable server modules to use the 10GbE connections provided by certain NEMs.

**FRU** Field-replaceable unit.

**FIM** Front indicator module.

---

## H

**HBA** Host bus adapter.

---

## I

**ILOM** See [Oracle ILOM](#).

**Installation** Title of the portion of the HTML topic set that corresponds to the PDF book *Sun Netra 6000 Modular System Installation Guide*.

**IPMI** Intelligent platform management interface.

---

## K

**KVM** Keyboard, video, mouse. Refers to using a switch to enable sharing of one keyboard, one display, and one mouse with more than one computer.

---

## L

**L/R** Ratio of inductance to resistance.

---

## M

**MAC or MAC address** Media access controller address.

**MPS** Modular power system.

---

## N

**name space** Top-level ILOM CMM targets.

**NEM** Network express module. NEMs provide 10/100/1000 Ethernet, SAS connectivity to storage modules, and 10GbE Ethernet ports.

**NET MGT port** Network management port. An Ethernet port on the CMM and on server module service processors.

**NTP** Network Time Protocol.

---

## O

### Oracle ILOM

Oracle Integrated Lights Out Manager (ILOM). Oracle ILOM firmware is preinstalled on a variety of Oracle systems. Oracle ILOM enables you to remotely manage your Oracle servers regardless of the state of the host system.

---

## P

### PCI EM

PCIe ExpressModule. Modular components that are based on the PCI Express industry-standard form factor and offer I/O features such as Gigabit Ethernet and Fibre Channel.

### PET

Platform event trap.

### PS

Power supply, as in device and sensor names, such as /CH/PS0/PRST.

### power supply side

Each of the AC power supplies has an A side and a B side. The major 12V power paths of the two sides are independent. The two sides share a common 3.3V stand-by power output, a diagnostics and control section, and a fan module.

---

## R

### REM

RAID expansion module. Sometimes referred to as a host bus adapter (HBA). Supports the creation of RAID volumes on disk drives.

### Remote Management (ILOM)

Title of the portion of the HTML topic set that corresponds to the PDF book *Oracle Integrated Lights Out Manager (ILOM) 3.0 Supplement for the Sun Netra 6000 Modular System*.

---

## S

### SER MGT port

Serial management port. A serial port on the CMM and on server modules service processors.

<b>server module</b>	Modular component that provides the main compute resources (CPU and memory). Server modules might also have onboard storage, and connectors that hold REMs and FEMs.
<b>Service</b>	Title of the portion of the HTML topic set that corresponds to the PDF book <i>Sun Netra 6000 Modular System Service Manual</i> .
<b>SNMP</b>	Simple Network Management Protocol.
<b>SP</b>	Service processor.
<b>storage module</b>	Modular component that provides compute storage to the server modules.

---

## U

<b>UCP</b>	Universal connector port.
------------	---------------------------



# Index

---

## A

- accessing server modules through the CMM, 32, 33
- adding Oracle ILOM user accounts, 12
- Admin (a) role, 14
- administering the modular system, 23

## C

- cd command example, 16, 24
- changing the root password (Remote Management), 10
- chassis
  - restarting, 32
  - sensors, 40
  - shutting down, 32
- chassis components, viewing, 24
- clearing the event log, 30
- clock
  - displaying, 19
  - managing, 19
  - setting manually, 21
  - using NTP to set, 20

## CMM

- accessing server modules, 32, 33
- clock setting, 21
- event log, 29, 30
- logging in and out, 5
- logging in through NET MGT (Remote Management), 8
- logging in through SER MGT (Remote Management), 7
- NET MGT port static IP address, 16
- resetting, 14

CMM ILOM, 1

- CLI, 23
- configuration tasks, 10
- configuring, 5

- connectivity choices, 6
- displaying the version, 11
- logging out, 9
- user account roles, 14

- commitpending example, 16

## components

- displaying, 27
- viewing, 24

- configuration tasks, CMM ILOM, 10

## configuring

- IP addresses with DHCP, 17

- connectivity choices (Remote Management), 6

- Console (c) role, 14

- create command example, 12

## D

- DHCP for IP address configuration (Remote Management), 17

- discrete sensors, 37

## displaying

- CMM clock, 19
- component information, 27
- event log, 29
- indicators, 28
- Oracle ILOM sessions, 11
- sensor readings, 38
- sensors, 28
- target descriptions, 26

## documentation

- related, vii

## E

### event log

- clearing, 30
- displaying, 29

- exit Oracle ILOM command, 9, 34

## F

- fan sensors, 41
- fan speed control, 3
- features, Oracle ILOM, 2
- firmware version, displaying, 11

## H

- help Oracle ILOM command, 26

## I

- identifying IP and MAC addresses, 15
- ILOM
  - targets, 3
- ILOM CMM
  - sessions, displaying, 11
- indicators, displaying, 28
- IP and MAC addresses, 15

## L

- LEDs
  - Locate LED, 31
- Locate LED, controlling, 31
- logging in through
  - NET MGT port (Remote Management), 8
  - SER MGT port (Remote Management), 7
- logging out of CMM ILOM, 9

## M

- MAC and IP addresses, 15
- managing
  - chassis with Oracle ILOM CLI, 23
  - CMM ILOM clock, 19
- modular system
  - administering with CMM ILOM, 23
  - IP and MAC addresses, identifying, 15
  - Oracle ILOM targets overview, 3
  - sensors, overview, 37
  - sensors, understanding, 37
  - targets, 3

## N

- NEMs
  - sensors, 44
- NET MGT port
  - logging in (Remote Management), 8
  - static IP address, 16

- network configuration, 34
- NTP servers, using, 20

## O

- Oracle ILOM
  - CMM ILOM, 1
  - connectivity choices, 6
  - logging out, 9
  - modular system features, 2
  - on the modular system, 1
  - overview, 1
  - SP ILOM, 1
  - targets overview, 3
- Oracle ILOM CMM
  - user accounts and privileges, 12
- Oracle ILOM targets, chassis, 24
- overview
  - Oracle ILOM, 1

## P

- password, root, 10
- PET event messages, 51
- power allocation, 3
- power supply
  - sensors, 42
- privileges, Oracle ILOM, 12
- properties, 24

## R

- Read Only (o) role, 14
- Reset and Host Control (r) role, 14
- reset ILOM command, 14
- resetting the CMM, 14
- restarting the chassis, 32
- roles, user account, 14
- root password, changing, 10

## S

- sensors
  - chassis, 40
  - displaying, 38
  - fan, 41
  - NEM, 44
  - overview, 37
  - power supply, 42
  - server module, 45



- understanding, 37
- SER MGT port
  - logging in (Remote Management), 7
- server modules
  - accessing through CMM, 32, 33
  - change network configuration, 34
  - power allocation, 3
  - sensors, 45
- set command example, 10, 16
- setting the CMM clock manually, 21
- show command example, 11, 15, 27
- shutting down the chassis, 32
- SNMP traps, 48
- SP ILOM, 1
- ssh command, 8
- start Oracle ILOM command, 32
- stop ILOM command, 32
- system event log
  - clearing, 30
  - displaying, 29

## **T**

- target descriptions, displaying, 26
- targets, modular system, 3
- threshold sensors, 37

## **U**

- user account roles, 14
- user accounts, Oracle ILOM, 12
- User Management (u) role, 14

## **V**

- version Oracle ILOM command, 11
- viewing and configuring IP and MAC addresses, 15
- viewing chassis components, 24

