

---


## Memory Riser Assembly Tool

When you replace the memory riser assembly, you must use the supplied torque indicator driver tool, part number 340-6091, to tighten the memory riser assembly thumbscrews to the correct torque.

---

**Caution** – When the torque indicator tool gap closes, and the edges of the tool begin to touch as shown in the illustration below, the proper torque value has been reached. Stop applying force at this point. Do not continue tightening the thumbscrew beyond this point.

---



Copyright 1999 Sun Microsystems, Inc. All rights reserved. Use is subject to license terms. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers.

Sun, Sun Microsystems, the Sun Logo, AnswerBook2, docs.sun.com, Ultra, Sun Enterprise, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

**RESTRICTED RIGHTS:** Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

Copyright 1999 Sun Microsystems, Inc. Tous droits réservés. Distribué par des licences qui en restreignent l'utilisation. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun

Sun, Sun Microsystems, le logo Sun, AnswerBook2, docs.sun.com, Ultra, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.



Please Recycle Sun Microsystems, Inc. • 901 San Antonio Road • Palo Alto, CA 94303-4900  
USA • 650 960-1300 • Fax 650 969-9131



Part Number: 806-2892-11  
September 1999, Revision A



---

## Memory Riser Assembly Damage Caution

This cautionary note applies to the following systems:

- Sun™ Ultra™ 80 workstation
- Sun Enterprise™ 420R server

---

**Caution** – If you remove or replace the memory riser assembly improperly, you may damage the connectors on either the motherboard or the MRA, or both.

These systems will not operate if the memory riser assembly connectors are damaged.

---

Before you remove or replace the memory riser assembly, read the memory riser assembly replacement instruction section in the *Sun™ Ultra™ 80 Product Note*, part number 806-1457-12, which is packed with the Ultra 80 system, or read the instructions in the *Sun Enterprise 420R Server Service Manual*, part number 806-1080-10, which is included on the Sun Enterprise 420R Server AnswerBook2 CD.

---

**Note** – Damage to these connectors is not covered under the system warranty.

---

