

Tekelec EAGLE[®] 5
Integrated Signaling System

ELAP Administration Manual

910-0178-001 Revision F

July 2007



TEKELEC

**Copyright 2005–2007 Tekelec
All Rights Reserved
Printed in U.S.A.**

Notice

Information in this documentation is subject to change without notice. Unauthorized use or copying of this documentation can result in civil or criminal penalties.

Any export of Tekelec products is subject to the export controls of the United States and the other countries where Tekelec has operations.

No part of this documentation may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying or recording, for any purpose without the express written permission of an authorized representative of Tekelec.

Other product names used herein are for identification purposes only, and may be trademarks of their respective companies.

RoHS 5/6 - As of July 1, 2006, all products that comprise new installations shipped to European Union member countries will comply with the EU Directive 2002/95/EC "RoHS" (Restriction of Hazardous Substances). The exemption for lead-based solder described in the Annex will be exercised. RoHS 5/6 compliant components will have unique part numbers as reflected in the associated hardware and installation manuals.

WEEE - All products shipped to European Union member countries comply with the EU Directive 2002/96/EC, Waste Electronic and Electrical Equipment. All components that are WEEE compliant will be appropriately marked. For more information regarding Tekelec's WEEE program, contact your sales representative.

Trademarks

The Tekelec logo, EAGLE, G-Flex, G-Port, IP⁷, IP⁷Edge, IP⁷ Secure Gateway, and TALI are registered trademarks of Tekelec. TekServer is a trademark of Tekelec. All other trademarks are the property of their respective owners.

Patents

This product is covered by one or more of the following U.S. and foreign patents:

U.S. Patent Numbers:

5,008,929, 5,953,404, 6,167,129, 6,324,183, 6,327,350, 6,456,845, 6,606,379, 6,639,981, 6,647,113, 6,662,017, 6,735,441, 6,745,041, 6,765,990, 6,795,546, 6,819,932, 6,836,477, 6,839,423, 6,885,872, 6,901,262, 6,914,973, 6,940,866, 6,944,184, 6,954,526, 6,954,794, 6,959,076, 6,965,592, 6,967,956, 6,968,048, 6,970,542

Ordering Information

For additional copies of this document, contact your sales representative

Table of Contents

Chapter 1. Introduction

Overview	1-1
Scope and Audience	1-2
Manual Organization	1-2
Related Publications	1-3
Documentation Packaging, Delivery, and Updates	1-8
Documentation Admonishments	1-9
Customer Assistance	1-10
Customer Care Center	1-10
Emergency Response	1-10
Acronyms	1-11

Chapter 2. Functional Description

General Description	2-2
Definition of Terms	2-2
Overall Design	2-3
ELAP Switchover	2-5
Network Connections	2-7
LSMS-to-ELAP Connection	2-10
Network Time Protocol (NTP)	2-11
LNP 228 Million Feature	2-13
Network Address Translation on MPS	2-14
ELAP Security Enhancements	2-15
LSMS/ELAP PING Enhancement	2-16
DSM Provisioning	2-17
Incremental Loading	2-17
DSM Reload	2-17
DSM Warm Restart	2-18
ELAP User Interface Menus	2-18
MPS/DSM RTDB Audit Overview	2-19
General Description	2-19
Functional Description	2-19
Status Reporting and Alarms	2-21

Chapter 3. ELAP Graphical User Interface

Overview of the ELAP User Interfaces	3-2
ELAP Graphical User Interface	3-2
Login Screen	3-4
ELAP GUI Main Screen	3-5
ELAP GUI Menus	3-12
Select Mate	3-13
Process Control Menu	3-14
Start ELAP Software	3-14
Stop ELAP Software	3-15
Maintenance Menu	3-16
Force Standby Menu	3-17
Simplex Mode Menu	3-20
Display Release Levels Screen	3-22
Decode EAGLE 5 ISS MPS Alarm Screen	3-23
RTDB Audit Menu	3-24
LSMS High Speed Audit Menu	3-25
LSMS High Speed Bulk Download Menu	3-28
LSMS Connection Menu	3-31
RTDB Menu	3-34
View RTDB Status	3-35
View LNP Qty Features	3-36
Maintenance Menu	3-36
Retrieve Records Menu	3-41
Local Provisioning Menu	3-48
Debug Menu	3-61
View Logs Menu	3-61
View Any File	3-65
List ELAP Software Processes	3-65
Connect to EAGLE 5 ISS MMI Port	3-67
ELAP Log Viewer	3-69
Platform Menu	3-71
Run Health Check Menu	3-72
List All Running Processes	3-74
View System Log	3-75
Eject the CD	3-76
Reboot the MPS	3-77

Table of Contents

Halt the MPS	3-78
SSH to MPS	3-80
User Administration Menu	3-81
Users Menu	3-82
Groups Menu	3-96
Authorized IP Address Menu	3-103
Terminate Active Sessions	3-107
Modify System Defaults	3-108
Change Password	3-110
Logout	3-111
ELAP Messages	3-112
ELAP Error Messages	3-112
ELAP Banner Information Messages	3-115
Chapter 4. Messages, Alarms, and Status Reporting	
MPS and ELAP Status and Alarm Reporting	4-2
Maintenance Blocks	4-2
Alarm Priorities	4-3
Multiple Alarm Conditions	4-4
DSM Status Requests	4-4
System Hardware Verification	4-5
DSM Motherboard Verification	4-6
DSM Daughter board Memory Validation	4-6
Actions Taken When Hardware Determined to be Invalid	4-7
DSM Memory Capacity Status Reporting	4-7
Unstable Loading Mode	4-7
Commands	4-9
rept-stat-db	4-9
rept-stat-mps	4-10
rept-stat-trbl	4-12
rept-stat-alm	4-13
Unsolicited Alarm Messages and Unsolicited Information Messages	4-14
MPS Platform and ELAP Application Alarms	4-14
ELAP-to-DSM Connection Status	4-16
Feature Key Capacity UAMs	4-18
Physical Memory Usage UAMs	4-20

EAGLE DSM Audit UIMs	4-21
Measurement Capacity UIMs	4-21
Chapter 5. ELAP Software Configuration	
Overview of the ELAP User Interfaces	5-2
Setting Up an ELAP Workstation	5-3
Screen Resolution	5-3
Compatible Browsers	5-3
Java	5-3
ELAP Configuration and Initialization	5-8
Required Network Address Information	5-9
Configuration Menu Conventions	5-11
ELAP Configuration Menu	5-13
Overview of ELAP Configuration	5-13
Initial “elapconfig” User Login	5-13
Text-based Configuration Menu	5-15
Display Configuration	5-16
Configure Provisioning Network	5-17
Select Time Zone	5-20
Exchange Secure Shell Keys	5-21
Change Password	5-21
Platform Menu and Options	5-22
Configure NTP Server and Options	5-24
Exit	5-25
ELAP Configuration Procedure	5-26
Configuration Terms and Assumptions	5-26
Configuration Symbols	5-27
Initial Setup and Connecting to MPSs	5-27
Procedure for Configuring ELAPs	5-29
Appendix A. Time Zone File Names	
Appendix B. ELAP Local Provisioning Utility	
Introduction	B-2
LPU Commands	B-2
Update Commands	B-2
Delete Commands	B-13
Retrieve Commands	B-16
Miscellaneous Commands	B-17

Table of Contents

Common Information	B-18
Success message	B-18
Error message format	B-18
Service parameters within error messages	B-18
Missing mandatory parameter	B-18
Communication errors	B-19
Perl errors	B-20
Perl Statements and Functions	B-20

Index

List of Figures

Figure 2-1. ELAP Installation for LNP 228 Million Number Support	2-4
Figure 2-2. NAT on MPS.	2-15
Figure 3-1. Process Architecture View of the ELAP UI	3-3
Figure 3-2. ELAP UI Login Screen	3-4
Figure 3-3. ELAP UI Login Screen	3-4
Figure 3-4. ELAP GUI Main Screen	3-5
Figure 3-5. ELAP Banner Applet	3-6
Figure 3-6. ELAP Area	3-7
Figure 3-7. Alarm View Window	3-8
Figure 3-8. Example of Message History	3-9
Figure 3-9. Example of an ELAP Menu	3-10
Figure 3-10. Example of Workspace Format	3-10
Figure 3-11. ELAP Menu	3-12
Figure 3-12. Select Mate Screen	3-13
Figure 3-13. Process Control Menu	3-14
Figure 3-14. Start ELAP Software Screen	3-14
Figure 3-15. Successful Start of ELAP Software Screen	3-14
Figure 3-16. Stop ELAP Software Screen	3-15
Figure 3-17. Successful Stop ELAP Software Screen	3-15
Figure 3-18. Maintenance Menu	3-16
Figure 3-19. Force Standby Menu	3-17
Figure 3-20. View Forced Standby Status Screen	3-17
Figure 3-21. Change Forced Standby Status Screen	3-18
Figure 3-22. Successfully Changing Forced Standby Status	3-18
Figure 3-23. Removing Changing Forced Standby Status	3-19
Figure 3-24. Removing Changing Forced Standby Status	3-19
Figure 3-25. Simplex Mode Menu	3-20
Figure 3-26. View Simplex Mode Screen	3-20
Figure 3-27. Change Simplex Mode Screen	3-21
Figure 3-28. Maintenance / Display Release Levels Screen	3-22
Figure 3-29. Decode EAGLE 5 ISS MPS Alarm Screen	3-23

List of Figures

Figure 3-30. RTBD Audit	3-24
Figure 3-31. View the RTDB Status Screen	3-24
Figure 3-32. Change the RTDB Audit Enabled Screen	3-25
Figure 3-33. LSMS High Speed Audit	3-25
Figure 3-34. LSMS HS Audit View Enabled Screen	3-26
Figure 3-35. LSMS HS Audit Change Enabled Screen	3-26
Figure 3-36. Successfully Disabling LSMS HS Audit	3-27
Figure 3-37. Restoring LSMS HS Audit Enabled	3-27
Figure 3-38. Confirming LSMS HS Audit Enabled	3-27
Figure 3-39. LSMS High Speed Bulk Download	3-28
Figure 3-40. LSMS HS Bulk Download View Enabled Screen	3-28
Figure 3-41. LSMS Bulk Download Change Enabled Screen	3-29
Figure 3-42. Successfully Disabling LSMS HS Bulk Download	3-29
Figure 3-43. Restoring LSMS HS Bulk Download Enabled	3-30
Figure 3-44. Confirming LSMS HS Bulk Download Enabled	3-30
Figure 3-45. LSMS Connection	3-31
Figure 3-46. LSMS Connection View Allowed Screen	3-31
Figure 3-47. Change LSMS Connection Allowed Enabled	3-32
Figure 3-48. Successfully Disabling LSMS HS Bulk Download	3-32
Figure 3-49. Restoring LSMS Connection Allowed Enabled	3-33
Figure 3-50. Confirming LSMS Connection Allowed Enabled	3-33
Figure 3-51. RTDB Menu	3-34
Figure 3-52. View RTDB Status Screen	3-35
Figure 3-53. LNP QTY Features Screen	3-36
Figure 3-54. Maintenance Menu	3-36
Figure 3-55. Reload RTDB from Remote Screen	3-37
Figure 3-56. Error in Reloading RTDB from Remote Screen	3-37
Figure 3-57. Backup the RTDB Screen	3-38
Figure 3-58. Confirming the Backup the RTDB Screen	3-38
Figure 3-59. Successfully Starting the Backup the RTDB Screen	3-39
Figure 3-60. Restore the RTDB	3-39
Figure 3-61. Confirming the Restoration of the RTDB	3-40
Figure 3-62. Successfully Starting the RTDB Restoration	3-40
Figure 3-63. Retrieve Records Menu	3-41
Figure 3-64. Retrieve Subscriptions Screen	3-41
Figure 3-65. Sample of Retrieve Subscriptions Output	3-42
Figure 3-66. Retrieve Default GTT from RTDB	3-43

Figure 3-67. Sample of Retrieve Default GTT Output	3-43
Figure 3-68. Retrieve Override GTT Screen	3-44
Figure 3-69. Sample of Retrieve Override GTT Output	3-45
Figure 3-70. Retrieve NPA NXX Split Screen	3-46
Figure 3-71. Sample of Retrieve NPA NXX Split Output	3-46
Figure 3-72. Retrieve Service Providers Screen	3-47
Figure 3-73. Sample of Retrieve Service Providers Output	3-47
Figure 3-74. Local Provisioning Menu	3-48
Figure 3-75. Local Provisioning / Subscriptions Menu	3-49
Figure 3-76. Update LNP Subscriptions Records	3-50
Figure 3-77. Sample of Updating LNP Subscription Records Output	3-50
Figure 3-78. Delete LNP Subscribing	3-51
Figure 3-79. Sample of Delete Subscription Output	3-51
Figure 3-80. Retrieve LNP Subscribing	3-52
Figure 3-81. Sample of Retrieve Subscription Output	3-52
Figure 3-82. RTDB / Local Provisioning / NPA NXX Menu	3-53
Figure 3-83. Update NPA NXX Records	3-53
Figure 3-84. Samples of Update NPA NXX Records Output	3-54
Figure 3-85. Delete NPA NXX Records	3-54
Figure 3-86. Samples of Delete NPA NXX Records Output	3-55
Figure 3-87. RTDB / Local Provisioning / Override GTT Menu ...	3-55
Figure 3-88. Update Override GTT Records	3-56
Figure 3-89. Samples of Update Override GTT Record Output	3-56
Figure 3-90. Delete Override GTT Record	3-57
Figure 3-91. Samples of Delete Override GTT Record Output	3-57
Figure 3-92. RTDB / Local Provisioning / NPA NXX Split Menu	3-58
Figure 3-93. Update NPA NXX Split Records	3-58
Figure 3-94. Samples of Update NPA NXX Split Record Output ...	3-59
Figure 3-95. Delete NPA NXX Split Record	3-59
Figure 3-96. Samples of Delete NPA NXX Split Record Output	3-60
Figure 3-97. RTDB / Local Provisioning / Batch Mode Screen	3-60
Figure 3-98. Debug Menu	3-61
Figure 3-99. View Logs Menu	3-61
Figure 3-100. View Maintenance Log Screen	3-62
Figure 3-101. Capture Log Files	3-63

List of Figures

Figure 3-102. Example of Successfully Capturing Log Files	3-63
Figure 3-103. Manage Log Files	3-64
Figure 3-104. Example of Successfully Deleting a Log File	3-64
Figure 3-105. View Any File Screen	3-65
Figure 3-106. View Any File Screen	3-66
Figure 3-107. Connect to MMI Port Screen	3-67
Figure 3-108. SSH User Authentication Screen	3-67
Figure 3-109. MMI Connection Window	3-68
Figure 3-110. Error in Connecting to MMI Port from ELAP A	3-69
Figure 3-111. Typical Log Viewer Request Screen	3-69
Figure 3-112. Log Viewer Window Example	3-70
Figure 3-113. Closing the Log Viewer Window	3-71
Figure 3-114. Platform Menu	3-71
Figure 3-115. Run Health Check Screen	3-72
Figure 3-116. Normal Health Check Output	3-73
Figure 3-117. Portion of Verbose Health Check Output	3-73
Figure 3-118. List All Running Processes Screen	3-74
Figure 3-119. View the System Log Screen	3-75
Figure 3-120. View System Log Format Example	3-75
Figure 3-121. Eject the CD Screen	3-76
Figure 3-122. Eject CD Screen Error Message	3-76
Figure 3-123. Reboot the MPS Screen	3-77
Figure 3-124. Caution about Rebooting the MPS	3-77
Figure 3-125. Rebooting the MPS in Process	3-78
Figure 3-126. Halt the MPS Screen	3-78
Figure 3-127. Caution about Halting the MPS	3-79
Figure 3-128. Rebooting the MPS in Process	3-79
Figure 3-129. SSH to MPS Screen	3-80
Figure 3-130. Example of a SSH Window	3-80
Figure 3-131. User Administration Menu	3-81
Figure 3-132. User Menu	3-82
Figure 3-133. Add User Screen	3-84
Figure 3-134. Success in Adding UI User	3-84
Figure 3-135. Select a User for Modification Screen	3-85
Figure 3-136. Specify the Modify UI User Screen	3-86
Figure 3-137. Confirming Modify UI User Profile Changes	3-86
Figure 3-138. Modify UI User's Group Membership	3-87

Figure 3-139. Confirming Modify UI User Group Membership Changes	3-87
Figure 3-140. Modify UI User's Specific Actions	3-88
Figure 3-141. Continuing Modify UI User's Specific Actions	3-89
Figure 3-142. Confirming Modify UI User Specific Actions Changes	3-90
Figure 3-143. Delete UI User Screen	3-91
Figure 3-144. Requesting Confirmation of User Deletion	3-91
Figure 3-145. Confirming Deletion of the User	3-92
Figure 3-146. Select a User to Retrieve Screen	3-92
Figure 3-147. Retrieval of UI User Information Screen	3-93
Figure 3-148. Viewing the User's Group Membership Screen	3-93
Figure 3-149. Viewing User Privileges	3-94
Figure 3-150. Continue Viewing User Privileges	3-95
Figure 3-151. Reset User Password Screen	3-95
Figure 3-152. Confirming the Reset User Password	3-96
Figure 3-153. User Administration / Groups Menu	3-96
Figure 3-154. Add UI Group Screen	3-97
Figure 3-155. Confirming a New Group	3-98
Figure 3-156. Modify UI Group Screen	3-98
Figure 3-157. Viewing a Group for Modification	3-99
Figure 3-158. Continuing to View a Group for Modification	3-99
Figure 3-159. Confirming Modify UI Group Action Privileges ...	3-100
Figure 3-160. Select a Group for Deletion Screen	3-100
Figure 3-161. Confirming the Delete Group	3-101
Figure 3-162. Success in Delete UI Group	3-101
Figure 3-163. Retrieve UI Group Screen	3-102
Figure 3-164. Retrieval of UI User Information Screen	3-102
Figure 3-165. Authorized IP Address Menu	3-103
Figure 3-166. Add Authorized UI IP Screen	3-103
Figure 3-167. Successfully Adding an Authorized UI IP Address	3-104
Figure 3-168. Remove Authorized UI IP Screen	3-104
Figure 3-169. Successfully Removing an Authorized UI IP Address	3-105
Figure 3-170. List All Authorized UI IP Addresses Screen	3-105
Figure 3-171. Change UI IP Authorization Status Screen	3-106
Figure 3-172. Toggling the UI IP Authorization Status	3-106

List of Figures

Figure 3-173. Terminate Active Sessions Screen	3-107
Figure 3-174. Confirmation of Session Termination	3-107
Figure 3-175. Modify System Defaults Screen	3-108
Figure 3-176. Confirming Modify System Defaults Screen	3-109
Figure 3-177. Change Password Screen	3-110
Figure 3-178. Logout Screen	3-111
Figure 4-1. Obit Message for Abort of Card Loading	4-9
Figure 4-2. rept-stat-db Command Report Example	4-10
Figure 4-3. rept-stat-mps Command Report Examples	4-11
Figure 4-4. rept-stat-trbl Command Output Example	4-12
Figure 4-5. repr-stat-alm Command Report Example	4-13
Figure 4-6. Alarm Output Example	4-15
Figure 4-7. MPS Available Alarm	4-15
Figure 5-1. Security Warning Window	5-4
Figure 5-2. Unpacking Java Runtime	5-5
Figure 5-3. Software Licensing Agreement	5-5
Figure 5-4. Choosing a Destination Location	5-6
Figure 5-5. Storing the Java Program	5-6
Figure 5-6. Successfully Completing the Installation	5-7
Figure 5-7. Configuration Menu Header Format	5-11
Figure 5-8. Initial Configuration Text Screen	5-13
Figure 5-9. Initial Configuration Continues	5-13
Figure 5-10. Entering the elapdev Password	5-14
Figure 5-11. ELAP Configuration Menu	5-15
Figure 5-12. Example of Display Configuration Output	5-16
Figure 5-13. Configure Network Interfaces Menu	5-17
Figure 5-14. Configure Provisioning Network Output	5-18
Figure 5-15. Configure Sync Network	5-19
Figure 5-16. Configure DSM Network	5-19
Figure 5-17. Configuring NAT Addresses Prompt	5-20
Figure 5-18. Select Time Zone Menu	5-20
Figure 5-19. Exchange Secure Shell Keys Output	5-21
Figure 5-20. Change Password	5-21
Figure 5-21. Platform Menu Output	5-22
Figure 5-22. Configure NTP Server Output	5-24

List of Tables

Table 2-1. ELAP Switchover Matrix	2-6
Table 2-2. Sample Network IP Addresses Configured from UI	2-7
Table 2-3. IP Addresses on the DSM Network	2-8
Table 2-4. ELAP Initial Connection to LSMS	2-10
Table 2-5. Existing ELAP-to-LSMS Connection	2-11
Table 2-6. Inconsistent DSM Card Alarm	2-19
Table 2-7. Corrupted RTDB Database Alarm	2-20
Table 2-8. Effect of Corrupted record received from MPS	2-21
Table 3-1. Log Viewer Navigation Commands	3-70
Table 3-2. ELAP UI Logins	3-83
Table 3-3. ELAP Error Messages	3-112
Table 3-4. ELAP Informational Banner Messages	3-115
Table 3-5. ELAP Alarm Related Banner Messages	3-116
Table 4-1. EAGLE 5 ISS MPS Application and Platforms UAM Alarms	4-3
Table 4-2. MPS Platform and ELAP Alarm Category UAMs	4-15
Table 5-1. Information for MPS at EAGLE 5 ISS A	5-9
Table 5-2. Information for MPS at EAGLE 5 ISS B	5-10
Table 5-3. Sample IP Addresses Used in Configuration	5-17
Table B-1. Mapping EAGLE 5 ISS to upd_lnp_npanxx LPU Command	B-8
Table B-2. Mapping EAGLE 5 ISS to upd_lnp_lrn LPU Command	B-12

Introduction

Overview	1-1
Scope and Audience	1-2
Manual Organization	1-2
Related Publications	1-3
Documentation Packaging, Delivery, and Updates	1-8
Documentation Admonishments	1-9
Customer Assistance	1-10
Customer Care Center	1-10
Emergency Response	1-10
Acronyms	1-11

Overview

This manual describes how to administer the EAGLE LNP Application Processor (ELAP), and how to use the ELAP user interface menus to perform configuration, maintenance, debug, and platform operations.

The Local Number Portability (LNP) 228 Million Numbers feature supports a maximum of 228 Million provisionable telephone numbers (TNs).

NOTE: Refer to the *LNP Feature Activation Guide* for the available configurations.

The MPS hardware platform supports high speed provisioning of large databases for the Tekelec EAGLE 5 Integrated Signaling System (ISS). The MPS is composed of hardware and software components that interact to create a secure and reliable platform.

MPS running ELAP supports provisioning from the Local Service Management System (LSMS) to the EAGLE 5 ISS Database Services Module (DSM) cards, using the LNP 228 Million Number feature for North American LNP.

Scope and Audience

This manual is intended for anyone responsible for ELAP administration and using the ELAP user interface in the EAGLE 5 ISS. Users of this manual and the others in the EAGLE 5 ISS family of documents must have a working knowledge of telecommunications and network installations.

Manual Organization

This document is organized into the following chapters:

- Chapter 1, "*Introduction*," contains general information about the ELAP user interface documentation, the organization of this manual, and how to get technical assistance.
- Chapter 2, "*Functional Description*," provides a description of ELAP overall design and operation.
- Chapter 3, "*ELAP Graphical User Interface*," describes how to log into the ELAP user interface and how to use the ELAP user interface menus.
- Chapter 4, "*Messages, Alarms, and Status Reporting*," describes ELAP status reporting, alarms, and error messages.
- Chapter 5, "*ELAP Software Configuration*," describes the text-based user interface that performs ELAP configuration and initialization.
- Appendix A, "*Time Zone File Names*", lists the valid UNIX file names for setting the time zone in ELAP software configuration.
- Appendix B, "*ELAP Local Provisioning Utility*", provides user guide information for the ELAP Local Provisioning Utility (LPU) batch command language.

Related Publications

The *ELAP Administration Manual* is part of the EAGLE 5 ISS documentation and may refer to one or more of the following manuals:

- The *Commands Manual* contains procedures for logging into or out of the EAGLE 5 ISS, a general description of the terminals, printers, the disk drive used on the system, and a description of all the commands used in the system.
- The *Commands Pocket Guide* is an abridged version of the *Commands Manual*. It contains all commands and parameters, and it shows the command-parameter syntax.
- The *Commands Quick Reference Guide* contains an alphabetical listing of the commands and parameters. The guide is sized to fit a shirt-pocket.
- The *Commands Error Recovery Manual* contains the procedures to resolve error message conditions generated by the commands in the *Commands Manual*. These error messages are presented in numerical order.
- The *Database Administration Manual – Features* contains procedural information required to configure the EAGLE 5 ISS to implement these features:
 - X.25 Gateway
 - STPLAN
 - Database Transport Access
 - GSM MAP Screening
 - EAGLE 5 ISS Integrated Monitoring Support.
- The *Database Administration Manual - Gateway Screening* contains a description of the Gateway Screening (GWS) feature and the procedures necessary to configure the EAGLE 5 ISS to implement this feature.
- The *Database Administration Manual – Global Title Translation* contains procedural information required to configure an EAGLE 5 ISS to implement these features:
 - Global Title Translation
 - Enhanced Global Title Translation
 - Variable Length Global Title Translation
 - Global Title Translation Modification
 - Intermediate GTT Load Sharing
 - ANSI-ITU-China SCCP Conversion

- Flexible GTT Load Sharing
 - Origin-Based SCCP Routing
 - Hex Digit Support for GTT
 - Weighted GTT Load Sharing
 - Transaction-Based GTT Load Sharing.
- The *Database Administration Manual - IP7 Secure Gateway* contains procedural information required to configure the EAGLE 5 ISS to implement the SS7-IP Gateway.
 - The *Database Administration Manual - SEAS* contains the EAGLE 5 ISS configuration procedures that can be performed from the Signaling Engineering and Administration Center (SEAC) or a Signaling Network Control Center (SNCC). Each procedure includes a brief description of the procedure, a flowchart showing the steps required, a list of any EAGLE 5 ISS commands that may be required for the procedure but that are not supported by SEAS, and a reference to optional procedure-related information, which can be found in one of these manuals:
 - *Database Administration Manual - Gateway Screening*
 - *Database Administration Manual - Global Title Translation*
 - *Database Administration Manual - SS7*
 - The *Database Administration Manual - SS7* contains procedural information required to configure an EAGLE 5 ISS to implement the SS7 protocol.
 - The *Database Administration Manual - System Management* contains procedural information required to manage the EAGLE 5 ISS database and GPLs, and to configure basic system requirements such as user names and passwords, system-wide security requirements, and terminal configurations.
 - The *Dimensioning Guide for EPAP Advanced DB Features* is used to provide EPAP planning and dimensioning information. This manual is used by Tekelec personnel and EAGLE 5 ISS customers to aid in the sale, planning, implementation, deployment, and upgrade of EAGLE 5 ISS systems equipped with one of the EAGLE 5 ISS EPAP Advanced Database (EADB) Features.
 - The *ELAP Administration Manual* defines the user interface to the EAGLE 5 ISS LNP Application Processor on the MPS/ELAP platform. The manual defines the methods for accessing the user interface, menus, screens available to the user and describes their impact. It provides the syntax and semantics of user input, and defines the output the user receives, including information and error messages, alarms, and status.

Introduction

- The *EPAP Administration Manual* describes how to administer the EAGLE 5 ISS Provisioning Application Processor on the MPS/EPAP platform. The manual defines the methods for accessing the user interface, menus, and screens available to the user and describes their impact. It provides the syntax and semantics of user input and defines the output the user receives, including messages, alarms, and status.
- The *Feature Manual - A-Port* provides an overview of a feature providing the capability for IS41 mobile subscribers to change service provider while retaining their original Mobile Directory Number (MDN). This manual gives the instructions and information on how to install, use, and maintain the A-Port feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.
- The *Feature Manual - ECAP* provides instructions and information on how to install, use, and maintain the Integrated Accounting Feature Application feature on the Eagle Collector Application Processor (ECAP). This feature collects raw MSU data from the EAGLE 5 ISS, categorizes the data into groups, and feeds those groups to another system for accounting activities. Additional features will be added to this manual at a later date.
- The *Feature Manual - EIR* provides instructions and information on how to install, use, and maintain the EIR feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS. The feature provides network operators with the capability to prevent stolen or disallowed GSM mobile handsets from accessing the network.
- The *Feature Manual - G-Flex C7 Relay* provides an overview of a feature supporting the efficient management of Home Location Registers in various networks. This manual gives the instructions and information on how to install, use, and maintain G-Flex features on the MPS/EPAP platform of the EAGLE 5 ISS.
- The *Feature Manual - G-Port* provides an overview of a feature providing the capability for mobile subscribers to change the GSM subscription network within a portability cluster while retaining their original MSISDNs. This manual gives the instructions and information on how to install, use, and maintain G-Port features on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.
- The *Feature Manual - INP/AINPQ* provides the user with information and instructions on how to implement, utilize, and maintain either the INAP-based Number Portability (INP) feature or the ANSI-41 INP Query (AINPQ) feature or both features on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.

- The *Feature Manual - Migration* provides an overview of a feature providing the capability for IS41 subscribers to migrate to a GSM network and GSM mobile subscribers to migrate to an IS41 network. This manual gives the instructions and information on how to install, use, and maintain the Migration feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.
- The *FTP-Based Table Retrieve Application (FTRA) User Guide* describes how to set up and use a PC to serve as the offline application for the EAGLE 5 ISS FTP Retrieve and Replace feature.
- The *Hardware Manual - EAGLE 5 ISS* provides an overview of each system and its subsystems, details of standard and optional hardware components in each system, and basic site engineering. These include the EAGLE 5 ISS, OEM-based products such as the ASi 4000 Service Control Point (SCP), and the Netra-based Multi-Purpose Server (MPS).
- The *Hardware Manual - Tekelec 1000 Application Server* provides general specifications and a description of the Tekelec 1000 Application Server (T1000 AS). This manual also includes site preparation, environmental and other requirements, procedures to physically install the T1000 AS, and troubleshooting and repair of Field Replaceable Units (FRUs).
- The *Hardware Manual - Tekelec 1100 Application Server* provides general specifications and a description of the Tekelec 1100 Application Server (T1100 AS). This manual also includes site preparation, environmental and other requirements, procedures to physically install the T1100 AS, and troubleshooting and repair of Field Replaceable Units (FRUs).
- The *Installation Manual - EAGLE 5 ISS* contains cabling requirements, schematics, and procedures for installing the EAGLE 5 ISS along with LEDs, connectors, cables, and power cords to peripherals. Refer to this manual to install components or the complete systems.
- The *LNP Database Synchronization Manual - LSMS with EAGLE 5 ISS* describes how to keep the LNP databases at the LSMS and at the network element (the EAGLE 5 ISS is a network element) synchronized through the use of resynchronization, audits and reconciles, and bulk loads. This manual is contained in both the LSMS documentation set and in the EAGLE 5 ISS documentation set.
- The *LNP Feature Activation Guide* contains procedural information required to configure the EAGLE 5 ISS for the LNP feature and to implement these parts of the LNP feature on the EAGLE 5 ISS:
 - LNP services
 - LNP options
 - LNP subsystem application
 - Automatic call gapping

Introduction

- Triggerless LNP feature
- Increasing the LRN and NPANXX Quantities on the EAGLE 5 ISS
- Activating and Deactivating the LNP Short Message Service (SMS) feature
- The *Maintenance Manual* contains procedural information required for maintaining the EAGLE 5 ISS and the card removal and replacement procedures. The *Maintenance Manual* provides preventive and corrective maintenance procedures used in maintaining the different systems.
- The *Maintenance Pocket Guide* is an abridged version of the Maintenance Manual and contains all the corrective maintenance procedures used in maintaining the EAGLE 5 ISS.
- The *Maintenance Emergency Recovery Pocket Guide* is an abridged version of the Maintenance Manual and contains the corrective maintenance procedures for critical and major alarms generated on the EAGLE 5 ISS.
- The *MPS Platform Software and Maintenance Manual - EAGLE 5 ISS with Tekelec 1000 Application Server* describes the platform software for the Multi-Purpose Server (MPS) based on the Tekelec 1000 Application Server (T1000 AS) and describes how to perform preventive and corrective maintenance for the T1000 AS-based MPS. This manual should be used with the EPAP-based applications (EIR, G-Port, G-Flex, A-Port, Migration, AINPQ, and INP).
- The *MPS Platform Software and Maintenance Manual - EAGLE 5 ISS with Tekelec 1100 Application Server* describes the platform software for the Multi-Purpose Server (MPS) based on the Tekelec 1100 Application Server (T1100 AS) and describes how to perform preventive and corrective maintenance for the T1100 AS-based MPS. This manual should be used with the ELAP-based application (LNP).
- The *Provisioning Database Interface Manual* defines the programming interface that populates the Provisioning Database (PDB) for the EAGLE 5 ISS features supported on the MPS/EPAP platform. The manual defines the provisioning messages, usage rules, and informational and error messages of the interface. The customer uses the PDBI interface information to write his own client application to communicate with the MPS/EPAP platform.
- The *Previously Released Features Manual* summarizes the features of previous EAGLE, EAGLE 5 ISS, and IP⁷ Secure Gateway releases, and it identifies the release number of their introduction.

- The *Release Documentation* contains the following documents for a specific release of the system:
 - *Feature Notice* - Describes the features contained in the specified release. The Feature Notice also provides the hardware baseline for the specified release, describes the customer documentation set, provides information about customer training, and explains how to access the Customer Support website.
 - *Release Notice* - Describes the changes made to the system during the lifecycle of a release. The Release Notice includes Generic Program Loads (GPLs), a list of PRs resolved in a build, and all known PRs.
NOTE: The *Release Notice* is maintained solely on Tekelec's Customer Support site to provide you with instant access to the most up-to-date release information.
 - *System Overview* - Provides high-level information on SS7, the IP⁷ Secure Gateway, system architecture, LNP, and EOAP.
 - *Master Glossary* - Contains an alphabetical listing of terms, acronyms, and abbreviations relevant to the system.
 - *Master Index* - Lists all index entries used throughout the documentation set.
- The *SEAS Commands Error Messages Manual* lists the error messages generated by the EAGLE 5 ISS that are specific to the Signaling Engineering and Administration System (SEAS). It includes the SEAS commands that trigger the error messages, the equivalent system error messages and commands, and the explanatory text.
- The *SS7-over-IP Networks Using SIGTRAN* manual examines the reasons for transitioning to an SS7-over-IP network, the considerations that go into planning and dimensioning, and helpful information for implementing the network using EAGLE 5 ISS.
- The *System Manual – EOAP* describes the Embedded Operations Support System Application Processor (EOAP) and provides the user with procedures on how to implement the EOAP, replace EOAP-related hardware, device testing, and basic troubleshooting information.

Documentation Packaging, Delivery, and Updates

Customer documentation is provided with each system in accordance with the contract agreements. It is updated whenever significant changes that affect system operation or configuration are made. Updates may be issued as an addendum, or a reissue of the affected documentation.

Introduction

The document part number appears on the title page along with the current revision of the document, the date of publication, and the software release that the document covers. The bottom of each page contains the document part number and date of publication.

Two types of releases are major software releases and maintenance releases. Maintenance releases are issued as addenda with a title page and change bars. On changed pages, the date and document part number are changed; on unchanged pages that accompany the changed pages, the date and document part number are unchanged.

When the software release has a minimum affect on documentation, an addendum is provided. The addendum contains an instruction page, a new title page, a change history page, and replacement chapters with the date of publication, the document part number, and change bars.

If a new release has a major impact on documentation, such as a new feature, the entire documentation set is reissued with a new part number and a new release number.

Documentation Admonishments

Admonishments are icons and text throughout this manual that alert the reader to assure personal safety, to minimize possible service interruptions, and to warn of the potential for equipment damage. This manual has three admonishments, listed in descending order of priority.

	DANGER: (This icon and text indicate the possibility of <i>personal injury</i> .)
	WARNING: (This icon and text indicate the possibility of <i>equipment damage</i> .)
	CAUTION: (This icon and text indicate the possibility of <i>service interruption</i> .)

Customer Assistance

The Tekelec Customer Care Center offers a point of contact through which customers can receive support for problems. The Tekelec Customer Care Center is staffed with highly-trained engineers to provide solutions to technical questions and issues seven days a week, twenty-four hours a day. A variety of service programs are available through the Tekelec Customer Care Center to maximize the performance of Tekelec products that meet and exceed customer needs.

Customer Care Center

To receive technical assistance, call the Tekelec Customer Care Center at one of the following locations by one of the following methods:

- Tekelec, UK

Phone: +44 1784 467 804

Fax: +44 1784 477 120

Email: *ecsc@tekelec.com*

- Tekelec, USA

Phone (within continental US): 1-888-FOR-TKLC

1-888-367-8552

(outside continental US): +1 919-460-2150

Email: *support@tekelec.com*

When the call is received, a Customer Service Report (CSR) is issued to record the request for service. Each CSR includes an individual tracking number.

Once a CSR is issued, Technical Services determines the classification of the trouble. If a critical problem exists, emergency procedures are initiated. If the problem is not critical, information regarding the serial number of the system, COMMON Language Location Identifier (CLLI), initial problem symptoms (includes outputs and messages) is recorded. A primary Technical Services engineer is also assigned to work on the CSR and provide a solution to the problem. The CSR is closed when the problem is resolved.

Emergency Response

In the event of a critical service situation, emergency response is offered by Tekelec Technical Services twenty-four hours a day, seven days a week. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

Introduction

A critical situation is defined as a problem with an EAGLE 5 ISS that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical problems affect service and/or system operation resulting in:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with Tekelec Technical Services.

Acronyms

ACK	Acknowledgment message
AIN	Advanced Intelligent Network
ANSI	American National Standards Institute
ASCII	American Standard Code for Information Interchange
AST	Associated State of the specified entity
CD-ROM	Compact Disk Read Only Memory
CGI.....	Common Gateway Interface
DB.....	Database
DCM	Data Communications Module
DN.....	Mobile Directory Number (also called MSISDN)
DSM	Database Services Module
EBDA.....	Enhanced Bulk Download and Audit
ELAP.....	EAGLE LNP Application Processor
EPAP	EAGLE Provisioning Application Processor

GPL.....	Generic Program Load
GSM.....	Global System for Mobile Telecommunications
GTT	Global Title Translation
GUI	Graphical User Interface
HTML	Hypertext Markup Language
HTTP.....	Hypertext Transfer Protocol
ID	Identifier
IMSI.....	International Mobile Subscriber Identity
IN.....	Intelligent Network
IP.....	Internet Protocol
IS-ANR.....	In Service - Abnormal
ISDN.....	Integrated Services Digital Network
IS-NR.....	In Service - Normal
JRS.....	Job Routing Server
KB	Kilobyte
LAN.....	Local Area Network
LIM	Link Interface Module
LNP	Local Number Portability
LNP SMS	LNP Short Message Service
LPU.....	Local Provisioning Utility
LRN	Location Routing Number
LSMS	Local Service Management System
MAP	Mobile Application Part or Mated Application
MB	Megabyte
MMI.....	Man-Machine Interface
MPS	Multi-Purpose Server
MR	Message Relay
MR Group.....	Message Relay Group
MSISDN	Mobile Subscriber ISDN Number (also referred to as Mobile Subscriber Directory Number)

Introduction

MSU	Message Signal Unit
MTS.....	Message Transfer System
MTSU.....	Message Transfer System Utilities
MTT	Mapped Translation Type
NAK.....	Negative Acknowledgment message
NE	Network Entity
NLA	Non-Local Advanced Intelligent Network
NLI.....	Non-Local Advanced Intelligent Network
NPA NXX.....	Number Plan Area and Number Exchange
NPAC.....	Number Portability Administration Center
NTP.....	Network Time Protocol
OAM.....	Operation Administration & Maintenance
OAP	Operation System Support/Application Processor
OOS-MT-DSBLD.....	Out of Service - Maintenance Disabled
PC.....	Point Code
PDB.....	Provisioning Database
PDBA	Provisioning Database Application
PDBI.....	Provisioning Database Interface
PID	Process Identifier
PMCT.....	Peripheral Maintenance Application
PPP	Point-to-Point Protocol
PST	Primary State of the specified entity
RFC	Request for Comment document
RI.....	Routing Indicator
RMTP.....	Reliable Multicast Transport Protocol (GlobalCast Communications, Inc.)
RTDB.....	Real-Time Database
SCCP	Signaling Connection Control Part
SMS	Short Message Service
SP.....	(1) Service Provider (2) Signalling Point

SPID.....	Service Provider Identifier
SS7	Signaling System #7
SSN	Subsystem Number
SSP	Subsystem Prohibited network management message or Subsystem Prohibited SCCP (SCMG) management message
SST	Secondary State of the specified entity
STP.....	Signaling Transfer Point
TCP	Transmission Control Protocol
TKLC.....	Tekelec
TN.....	Telephone Number (10-digit subscription)
TTT	Translation Type
UAM.....	Unsolicited Alarm Message
UDP	User Datagram Protocol
UIM	Unsolicited Information Message
UTC	Universal Time Coordinated
VSCCP.....	VxWorks Signaling Connection Control Part
WSMSC.....	Wireless Short Message Service Center

Functional Description

General Description.....	2-2
Overall Design	2-3
Definition of Terms	2-2
ELAP Switchover	2-5
Network Connections.....	2-7
LSMS-to-ELAP Connection	2-10
Network Time Protocol (NTP)	2-11
LNP 228 Million Feature	2-13
Network Address Translation on MPS.....	2-14
ELAP Security Enhancements.....	2-15
LSMS/ELAP PING Enhancement.....	2-16
DSM Provisioning	2-17
Incremental Loading.....	2-17
DSM Reload	2-17
ELAP User Interface Menus.....	2-18
Status Reporting and Alarms.....	2-21

General Description

The Local Number Portability (LNP) 228 Million Numbers feature supports up to 228 Million provisionable telephone numbers (TNs).

The LNP 228 Million Numbers feature utilizes the “master” or “golden” real-time LNP database on the Multi-Purpose Server (MPS).

The MPS hardware platform supports high speed provisioning of large databases for the Tekelec EAGLE 5 ISS. The MPS system is composed of hardware and software components that interact to create a secure and reliable platform.

MPS running the EAGLE LNP Application Processor (ELAP) software supports provisioning from the Local Service Management System (LSMS) to EAGLE 5 ISS Database Services Module (DSM) cards. ELAP now supports up to 228 Million ported numbers for North American LNP.

Definition of Terms

The following terms are used throughout this manual:

MPS

One Tekelec 1100 Application Server (T1100 AS) is referred to as an *MPS server*.

The two MPS servers installed at one EAGLE 5 ISS location are installed in one frame or rack. The two MPS servers that are located at one EAGLE 5 ISS location are “mate servers”—from one MPS server, the other MPS server in the rack can be referred to as its mate. The two servers are also referred to as “server A” and “server B.”

One “MPS system” consists of two MPS servers and associated hardware that are located at one EAGLE 5 ISS location.

Usually, a minimum of two MPS systems are deployed in the customer network (one at each mated EAGLE 5 ISS). These two MPS systems are considered “mate MPS systems” on mated EAGLE 5 ISSs.

ELAP

The EAGLE LNP Application Processor (ELAP) software that is supported by MPS includes support for the 228 Million Number LNP feature.

An MPS server that is hosting ELAP is referred to as an MPS running ELAP. One MPS server running ELAP is also referred to as ELAP A, while the mate MPS server running ELAP is referred to as ELAP B.

The two MPS servers running ELAP at each EAGLE 5 ISS site have exactly the same software installed.

SP (or SPID) refers to the Service Provider ID. These are (4) alphanumeric characters assigned to each carrier. The ELAP can store up to 32,700 SP entries in the RTDB.

Functional Description

MR (Message Relay) is another name for service (CNAM, CLASS, LIDB, ISVM, WSMSC). Each Message Relay entry contains ri (routing indicator) and ngt (new gtt translation) data. The ELAP is capable of storing up to 65,500 MR entries in the RTDB.

MR Groups (Message Relay Groups) is a group of one or more MR entries that are grouped or assigned to a particular TN. The ELAP supports up to 2 million MR groups.

Overall Design

The Multi Purpose Server (MPS) hardware platform supports high speed provisioning of large databases for the EAGLE 5 ISS. MPS running ELAP supports the LNP 228 Million Numbers feature. Figure 2-1 on page 2-4 illustrates an ELAP with LNP 228 Million Numbers installation.


The main functions of ELAP are the following:

- Accept and store data provisioned by the customer from LSMS over the provisioning network
- Update and reload provisioning data to the EAGLE 5 ISS DSM cards.

During normal operation information flows through the ELAP with no intervention.

ELAP provides a direct user interface for performing configuration, maintenance, debugging, and platform operations. Chapter 3, "*ELAP Graphical User Interface*," describes the ELAP user interface menus and operations.

Figure 2-1. ELAP Installation for LNP 228 Million Number Support



An MPS system consists of two mated Tekelec 1100 AS processors (MPS Server A and MPS Server B) installed as part of an EAGLE 5 ISS. Each server runs ELAP—ELAP A on MPS Server A and ELAP B on MPS Server B.

Two Ethernet networks, referred to as the main and backup DSM networks, connect the DSMs and the ELAPs. Another Ethernet network connects the two ELAPs; it is referred to as the ELAP Sync network. (See “Network Connections” on page 2-7.)

Figure 2-1 on page 2-4 shows the network layout. Table 2-2 on page 2-7 shows examples of typical IP addresses of the network elements.

Functional Description

The ELAPs connect to the LSMS at ELAP initialization and receive provisioning data from the LSMS. The ELAPs store the provisioning data in redundant copies of the real-time database (RTDB), and use the data to provision the EAGLE 5 ISS DSM cards. The set of DSMs, which each hold a copy of the RTDB, is part of the EAGLE 5 ISS.

One ELAP runs as the Active ELAP and the other as the Standby ELAP. In normal operation, the DSM database is provisioned through the main DSM network by the Active ELAP. In case of failure of the Active ELAP, the Standby ELAP takes over the role of Active ELAP and continues to provision the DSM databases.

In the case where the main DSM network fails the Active ELAP switches to the backup DSM network to continue provisioning the DSMs. At any given time there is only one Active ELAP using one DSM network per MPS system.

ELAP Switchover

ELAPs assume an Active or a Standby role through negotiation and algorithm. This role impacts the way the ELAP handles its various external interfaces. External provisioning is allowed only through the Active ELAP. Only the Active ELAP can provide maintenance information to EAGLE 5 ISS.

An ELAP can switch from an Active to a Standby role under the following circumstances:

1. The ELAP maintenance component becomes isolated from the maintenance component on the mate ELAP and from EAGLE 5 ISS.

This implies that the maintenance subsystem has attempted and failed to establish communication with each of the following:

- The mate ELAP maintenance task across the Sync network
 - The mate ELAP maintenance task across the main DSM network
 - Any DSM card on any DSM network
2. The RTDB becomes corrupt.
 3. All of the RMTP channels have failed
 4. A fatal software error occurred.
 5. The ELAP is forced to Standby by the user interface Force to Become Standby operation.

If the Active ELAP has one or more of the five switchover conditions and the Standby ELAP does not, a switchover occurs. Table 2-1 lists the possibilities:

Table 2-1. ELAP Switchover Matrix

Active state	Standby state	Event	Switchover?
No switchover conditions	No switchover conditions	Condition occurs on Active	Yes
Switchover conditions exist	Switchover conditions exist	Conditions clear on Standby; switches to Active	Yes
No switchover conditions	Switchover conditions exist	Condition occurs on Active	No
Switchover conditions exist	Switchover conditions exist	Condition occurs on Active	No
Switchover conditions exist	Switchover conditions exist	Condition occurs on Standby	No
Switchover conditions exist	Switchover conditions exist	Conditions clear on Active	No

The following are exceptions to the switchover matrix:

1. If the mate maintenance component cannot be contacted and the mate ELAP is not visible on the DSM networks, the ELAP assumes an Active role if *any* DSMs are visible on the DSM networks.
2. If the ELAP user interface menu item is used to force an ELAP to Standby role, no condition causes it to become Active until the user removes the interface restriction with another menu item. (See “Force Standby Menu” on page 3-17 and “Change Status Screen” on page 3-18.)

If none of the Standby conditions exist for either ELAP, the MPS servers negotiate an Active and a Standby. The mate is considered unreachable after two seconds of attempted negotiation.

Functional Description

Network Connections

Each MPS system is equipped with four network connections. This section describes the four networks and the IP address assignment for the networks that require them.

Table 2-2. Sample Network IP Addresses Configured from UI

Network Connection	Sample MPS A Value	Sample MPS B Value
Hostname	MPSA-000000	MPSB-000001
Provisioning Network IP Address	10.25.50.45	10.25.50.46
Provisioning Network Netmask	255.255.255.0	255.255.255.0
Provisioning Network Default Router	10.25.50.250	10.25.50.250
Sync Network IP Address	192.168.3.100	192.168.3.200
Main DSM Network IP Address	192.168.1.100	192.168.1.200
Backup DSM Network IP Address	192.168.2.100	192.168.2.200

NOTE: These values are not the correct values for your network! The values that you enter while configuring the ELAPs will be unique to your network configuration. The *Signaling Products Hardware Manual* describes how to determine the actual values for your network.

DSM Networks

The main DSM network carries provisioning data from the RTDBs on the ELAP to the RTDBs on the DSMs, and carries reload and maintenance traffic to the DSMs. The 100BASE-T main DSM network runs half-duplex at 100 Mbps. The 10BASE-T backup DSM network carries only connection maintenance traffic unless the main network is not operational; if the main network fails, the backup network carries all of the traffic normally carried by the main network. The backup DSM network runs half-duplex at 10 Mbps. Each network connects ELAP A and ELAP B to each DSM on a single EAGLE 5 ISS.

The first two octets of the ELAP network addresses for this network are 192.168. These are the first two octets for private class C networks as defined in RFC 1597.

The third octet for each DSM network is configured, usually to the default value .120 for the main network and the default value .121 for the backup network. These are not visible to any external networks, and should not need to be changed.

The fourth octet of the address is selected as follows:

- If the ELAP is configured as ELAP A, the fourth octet has a value of 100.
- If the ELAP is configured as ELAP B, the fourth octet has a value of 200.

Table 2-3 summarizes the derivation of each octet.

The configuration menu of the ELAP user interface contains menu items for configuring the ELAP network addresses. (See “ELAP Configuration and Initialization” on page 5-8).

Table 2-3. IP Addresses on the DSM Network

Octet	Derivation
1	192
2	168
3	Usually already configured as: 120 for DSM main network 121 for DSM backup network
4	100 for ELAP A 200 for ELAP B 1 - 25 for DSMs on the networks

ELAP Sync Network

The ELAP Sync network is a point-to-point network between ELAP A and ELAP B on a single MPS system. This network provides a high-bandwidth dedicated communication channel for MPS data synchronization. This network is a single Ethernet crossover cable, uses 100Base-T protocol, and runs at full-duplex 100 Mbps.

The ELAP Sync network carries RTDB and maintenance application traffic between the Active ELAP and the Standby ELAP on the MPS platform.

The first two octets of the ELAP IP addresses for the Sync network are 192.168. These are the first two octets for private class C networks as defined in RFC 1597.

The third octet for each ELAP Sync network address is set to .2 as the default. It can be changed if necessary. It is important to perform the instructions to “Configure Sync Network” on page 5-18 if you change this octet value.

The fourth octet of the Sync network IP address is .100 for ELAP A, and .200 for ELAP B.

Functional Description

Dialup PPP Network

The Dialup Point-To-Point Protocol (PPP) Network (not shown in Figure 2-1) allows multiple user interface sessions to be established to the ELAP from a remote workstation over a dialup connection.

The MPS servers are configured for the use of a modem on port a001 on the serial expansion board. The modem connection supports PPP (TCP/IP). With this capability, multiple networked applications can be run across the PPP link at the same time.

PPP also requires two IP addresses to be registered, one to the serial port on the server, and one to the client dialing into the server. These IP addresses are allocated on the Sync network.

If the IP address of the Sync network is changed using an ELAP user interface configuration menu item, the PPP IP addresses are updated by the user interface operation at the same time.

The remote dial-in serial port is configured as follows:

- Hardware flow control (RTS/CTS)
- 38400 bps port speed
- 8-bit data
- No parity

Contact the Customer Care Center for assistance in configuring the Dialup PPP Network; see “Customer Assistance” on page 1-10.

If the remote dial-in serial port is not functional at one EAGLE 5 ISS site, dialing into the remote EAGLE 5 ISS site and connecting back to the functional MPS at the failed EAGLE 5 ISS site allow remote recovery.

Provisioning Network

The provisioning network is the only network attached directly to the customer’s network. All provisioning information from the customer’s provisioning system travels over this network. In addition, all traffic required to keep remote MPS systems synchronized also travels across this network.

The provisioning (customer) network carries ELAP user interface traffic and traffic between ELAP and the LSMS.

The port is a 10BASE-T/100BASE-T auto-sensing device; it automatically runs as fast as the customer’s equipment allows. A dedicated network is recommended, but it is possible that unrelated customer traffic could also use this network.

LSMS-to-ELAP Connection

All normal LNP provisioning is conducted through the LSMS. (Localized retrievals of data can be accomplished through the ELAP user interface.)

The LSMS communicates with each ELAP in the MPS system using the LSMS High Speed Operation Protocol (HSOP. The LSMS connects to both ELAPs at initialization.

Two types of ELAP states are relevant to LSMS communication. The first is the existing Active or Standby role. The second is the ability of an ELAP to apply LNP updates to the RTDB. These two states affect LSMS connectivity as follows:

- A connection is established to each ELAP that is able to apply LNP data.
- Data is sent to only one of the ELAPs. If one ELAP is Active, data is sent to it.

The connection that the LSMS uses to send data to one of the ELAPs is called the LSMS primary connection. This is usually the connection to the Active ELAP. In the event that both sides are Standby or that only one side is available, the LSMS primary connection might not be to an Active ELAP (see Table 2-4 and Table 2-5). An “Unable” or “Down” ELAP does not accept a connection from the LSMS. The following definitions apply:

- Active/Able:** The ELAP is the **Active** ELAP, and it is **able** to accept LNP updates and apply them to the RTDB.
- Standby/Able:** The ELAP is the **Standby** ELAP, and it is **able** to accept LNP updates and apply them to the RTDB.
- Standby/Unable:** The ELAP is the **Standby** ELAP, and it is **unable** to accept LNP updates and apply them to the RTDB.
- Down:** The ELAP is unreachable.

Based on the Active/Standby status returned to the LSMS on connection, the LSMS begins to provision LNP data to the Active ELAP across a TCP/IP connection in the customer network.

Table 2-4. ELAP Initial Connection to LSMS

Elap Status	Mate Status	Result
Active/Able	Standby/Able	Connection is established to both ELAPs. The LSMS chooses first ELAP for the LSMS primary connection.
Active/Able	Standby/Unable	Connection is established to first ELAP only. The LSMS chooses first ELAP for the LSMS primary connection.
Active/Able	Down	Connection is established to first ELAP only. The LSMS chooses first ELAP for the LSMS primary connection.
Standby/Able	Down	Connection is established to first ELAP only. The LSMS chooses first ELAP for the LSMS primary connection.

Functional Description

Table 2-4. ELAP Initial Connection to LSMS (Continued)

Elap Status	Mate Status	Result
Standby/Able	Standby/Able	Connection is established to both ELAPs. LSMS chooses one of the ELAP for the LSMS primary connection.
Standby/Able	Standby/Unable	Connection is established to first ELAP only. The LSMS chooses first ELAP for the LSMS primary connection.
Standby/Unable	Standby/Unable	No connection is allowed.

Table 2-5. Existing ELAP-to-LSMS Connection

ELAP Status	Change	Result
Active/Able	Active → Standby	The ELAP closes the connection. LSMS chooses the other ELAP for the LSMS primary connection if it is Active. The ELAP immediately allows another LSMS connection. This switchover mechanism is used because the HSOP does not allow for ELAP status reporting to the LSMS.
Able	Able → Unable	The ELAP closes the connection. LSMS sends data to the other ELAP if it is able to apply LNP updates. The ELAP does not allow another LSMS connection until it is able to apply LNP updates to the real-time database.

Data is collected at the LSMS from the Number Portability Administration Center (NPAC) (for subscription data) and from local provisioning on the LSMS (for default NPANXX, split NPANXX and other types of LNP records). This data is sent to the Job Routing Server (JRS) at the Active ELAP, which performs minimal parsing and validation before updating its real-time database (RTDB) and replicating the data to the mate ELAP RTDB. The ELAP with the LSMS primary connection ensures that the RTDBs on both ELAPs receive the provisioning data.

Network Time Protocol (NTP)

The Network Time Protocol (NTP) is a Internet protocol that synchronizes clocks of computers to Universal Time Coordinated (UTC) as a time reference. NTP reads a time server's clock and transmits the reading to one or more clients; each client adjusts its clock as required. NTP assures accurate local timekeeping with regard to radio, atomic, or other clocks located on the Internet. This protocol is capable of synchronizing distributed clocks within milliseconds over extended time periods.

If left unchecked, the system time of Internet servers will drift out of synchronization with each other.

The MPS A server of each mated MPS pair is configured, by default, as a “free-running” NTP server that communicates with the mate MPS servers on the provisioning network. (“Free-running” refers to a system that is not synchronized to UTC; it runs off of its own clocking source.) This allows mated MPS servers to synchronize their time.

All MPS servers running the ELAP application have the option to be configured to communicate and synchronize time with an LSMS server or with a customer-defined NTP time server. The `prefer` keyword prevents “clock-hopping” when additional MPS or NTP servers (for example, LSMS servers) are defined.

If this optional feature uses an LSMS, the LSMS must be configured as an NTP server. Refer to the *LSMS Configuration Manual* for configuration instructions. When the LSMS has been configured, you can configure the MPS servers to synchronize with the LSMS. Refer to Chapter 5, *ELAP Software Configuration* for instructions on configuring the MPS servers through the application user interface.

Understanding Universal Time Coordinated (UTC)

Universal Time Coordinated (UTC) is an official standard for determining current time. The UTC is based on the quantum resonance of the cesium atom. UTC is more accurate than Greenwich Mean Time (GMT), which is based on solar time.

The term ‘universal’ in UTC means that this time can be used anywhere in the world; it is independent of time zones. To convert UTC to your local time, add or subtract the same number of hours as is done to convert GMT to local time. The term coordinated in UTC means that several institutions contribute their estimate of the current time, and the UTC is calculated by combining these estimates.

UTC is disseminated by various means, including radio and satellite navigation systems, telephone modems, and portable clocks. Special-purpose receivers are available for many time-dissemination services, including the Global Position System (GPS) and other services operated by various national governments.

Generally, it is too costly and inconvenient to equip every computer with a UTC receiver. However, it is possible to equip a subset of computers with receivers; these computers relay the time to a number of clients connected by a common network. Some of those clients can disseminate the time, in which case they become lower stratum servers. The industry-standard Network Time Protocol is one time dissemination implementation.

Understanding Network Time Protocol

NTP is an Internet protocol used to synchronize clocks of computers using UTC as a time reference. NTP primary servers provide their clients time that is accurate within a millisecond on a LAN and within a few tens of milliseconds on a WAN. This first level of accuracy is called stratum-1. At each stratum, the client can also operate as a server for the next stratum.

Functional Description

A hierarchy of NTP servers is defined with several strata to indicate how many servers exist between the current server and the original time source external to the NTP network, as follows:

- A stratum-1 server has access to an external time source that directly provides a standard time service, such as a UTC receiver.
- A stratum-2 server receives its time from a stratum-1 server.
- A stratum-3 server receives its time from a stratum-2 server.
- This NTP network hierarchy supports up to stratum-15.

Normally, client workstations do not operate as NTP servers. NTP servers with a relatively small number of clients do not receive their time from a stratum-1 server. At each stratum, it is usually necessary to use redundant NTP servers and diverse network paths to protect against broken software, hardware, or network links. NTP works in one or more of these association modes:

- Client/server mode, in which a client receives synchronization from one or more servers, but does not provide synchronization to the servers
- Symmetric mode, in which either of two peer servers can synchronize to the other, in order to provide mutual backup
- Broadcast mode, in which many clients synchronize to one or a few servers, reducing traffic in networks that contain a large number of clients. IP multicast can be used when the NTP subnet spans multiple networks.

The Tekelec MPS servers are configured to use the symmetric mode to share their time with their mate MPS servers. For an ELAP system, customers using the application user interface have the option to configure the MPS system to receive NTP from LSMS or a customer-provided NTP server.

LNP 228 Million Feature

The LNP 228 Million feature uses Feature Keys to enforce quantity limits. Feature keys also enforce the ON only philosophy. There is one general feature key to indicate the existence of the ELAP device. Three additional feature keys: LNP TN QTY, LNP NPANXX QTY and LNP LRN QTY regulate the maximum capacity allowed within the LNP DB System and contains a finite increment of the quantity field.

The LNP 228 Million feature auto-inhibits any SCCP application card that does not meet the minimum hardware requirements based upon feature key capacities and ELAP-Configuration Feature Keys. Refer to the *LNP Feature Activation Guide* for more information on minimum requirements.

Measurement collection is capped at 150,000 NPANXXs and 100,000 LRNs when collection is performed via the OAM. This limitation does not inhibit the provisioning of additional LRNs and NPANXXs, but further entries are not collected or reported. The reduced capacity LNP reports are generated to the FTA

area of the fixed disk on request, and are available for downloading to the local terminal via Kermit. If the number of provisioned LRNs exceeds 100,000 or the number of provisioned NPANXXs exceeds 150,000, the Measurements Subsystem generates a UIM at each hourly collection interval. The UIM is a warning that measurements data have been discarded. The UIM output can be suppressed by setting the UIM threshold limit to zero.

When measurements are being collected by the Measurement-Platform the collection is capped at 300,000 NPANXXs and 150,000 LRNs. When the Measurements Platform is installed, the Measurements Subsystem collects measurements data for all provisioned LRNs and NPANXXs, up to 150,000 LRNs and 300,000 NPANXXs. Full LNP reports are available via FTP on demand or by enabling the schedule option. LNP measurement reports are still available via FTA, but are limited to 100,000 LRNs and 150,000 NPANXXs.

Network Address Translation on MPS

The MPS supports 2 types of network address translation (NAT), Port Forwarding and Static Address Mapping. In both cases, the MPS will have private IP addresses that are not available outside of the firewall protected internal network. The firewall will translate particular addresses and port numbers to the internal addresses for the MPS.

The addresses in the following figure are examples. Addresses are not restricted to particular classes/ranges.

Port Forwarding

Port forwarding allows a single external address to be used for multiple internal systems. The port forwarding firewall maintains a list of services (basically port numbers) and corresponding internal addresses.


Although the MPS has two individual internal IP addresses, external clients are only allowed to reach the internal network using one external address. The MPS servers must use different port numbers for each externally available service in order to distinguish MPS A from MPS B to external clients.

The MPS uses 3 ports for the Web UI and another 2 ports for the LSMS and EBDA connections. At a minimum, one MPS side must be configured with 3 Web UI ports different from the default values. The firewall must be configured to forward 3 Web UI ports to MPS A and 3 different Web UI ports to MPS B. See [4] for a list of the default port numbers used by the MPS.

The LSMS does not currently allow configuration of alternate LSMS and EBDA ports. Until this changes, the LSMS is required to be on the internal network of a port forwarding firewall. Do not change the default values for these ports.

Functional Description

Figure 2-2. NAT on MPS.



Static Address Mapping

Static address mapping makes systems that are behind the firewall appear to have public addresses on the external network. A one-to-one mapping exists between internal and external addresses.

An external address must be assigned to the NAT firewall for each MPS side. The external addresses must be entered into the MPS database in order for the Web UI to be fully functional.

ELAP Security Enhancements

The ELAP Security Enhancements feature controls access to an ELAP GUI to specific IP addresses. The specified allowed IP addresses are kept in an ELAP list and can be added to, deleted from, and retrieved only by an authorized user. This feature also allows an authorized user to toggle IP authorization checking on and off through the GUI.

The administrator or user with IP action privileges can add, delete and retrieve IP addresses. Deleting an IP would result in that IP address no longer residing in the IP table, hence preventing that IP address from being able to connect to an ELAP.

NOTE: While each of the IP action privileges can be assigned to any individual user, the IP action privileges of add and delete should be granted only to users who are knowledgeable about the customer network.

The ability to add, delete, and retrieve client IP addresses and to toggle IP authorization checking is assignable by function. This is accessible through the ELAP GUI (refer to “Authorized IP Address Menu” on page 3-103). The IP mechanism implemented in this feature provides the user a means of further enhancing ELAP privilege control.

The ELAP Security Enhancements feature is available through the ELAP GUI and is available initially to only the administrator. The ability to view IP addresses on the customer's network is a security consideration and should be restricted to users with administration group privileges. In addition, privileged users can prepare a custom message to replace the standard 403 Forbidden site error message.

NOTE: IP access and range constraints provided by the web server and the ELAP Security Enhancement feature cannot protect against IP spoofing. (The term ‘spoofing’ refers to the creation of TCP/IP packets using another's IP address; it is IP impersonation or misrepresentation). The customer must rely on the security of the customer's intranet network to protect against spoofing.

ELAP maintains a list of the IP addresses that are authorized to access the graphical user interface. Only requests from IP addresses on the authorized list can connect to the ELAP GUI. Attempts from any unauthorized address are rejected.

NOTE: No IP addresses are restricted from accessing the ELAP GUI until the administrator toggles IP authorization to ‘enabled’. When IP authorization checking is enabled, any IP address not present in the IP authorization list will be refused access to the ELAP GUI.

ELAP Security Enhancement also provides the means to enable/disable the IP address list once it is provisioned. If the list is disabled, the provisioned addresses are retained in the database, but access is not blocked from IP addresses not on the list. The ELAP GUI restricts permission to enable/disable the IP address list to specific user names and passwords.

The IP actions for adding, deleting, retrieving authorized IP Addresses and for toggling authorized IP checking are available only from the ELAP GUI (described in Chapter 3), but not from the ELAP text-based UI (described in Chapter 5).

LSMS/ELAP PING Enhancement

Depending on customer network architecture, the LSMS and ELAP may be on different internal networks. To increase security, as few ports as necessary should be required to be open inbound to the ELAP network. Currently the LSMS/ELAP interface supports a UDP PING function to monitor the connectivity between the two systems. This feature will move the monitoring function within the HSOP interface, such that the UDP PING port is no longer required.

Functional Description

Because this feature requires changes to both the ELAP and LSMS in order to function, the LSMS will continue to support the existing UDP PING method to address operation with ELAPs that have not been upgraded, as well as continued UDP PING operation in conjunction with the HSOP keep alive.

The procedures to set-up this feature are done on the LSMS.

DSM Provisioning

One of the core functions of the ELAP is to provision the DSM cards with database updates.

The ELAP provides real-time database loading and provisioning functions for the EAGLE 5 ISS DSM cards using the main (and backup if necessary) DSM network between the MPS system and the EAGLE 5 ISS DSM cards. Real-time updates are sent to the EAGLE 5 ISS DSMs in parallel using RMTP multicast technology.

The SCCP application executing on the DSM conducts all database communications between the Active ELAP and each of the 25 VSCCP cards.

Incremental Loading

Incremental loading occurs when a DSM has missed some updates, but does not need a complete reload.

The ELAP can broadcast a stream of current updates to all DSMs at a rate of 25 updates per second. When the ELAP detects that a DSM is back-level from the current provisioning stream, the ELAP attempts to start a new stream at that level.

NOTE: Incremental loading and normal provisioning are done in parallel. The DSM provisioning task supports up to five incremental loading streams in addition to the normal provisioning stream.

Incremental reload streams are terminated when the database level contained in that stream matches that of another stream. This is expected to happen most often when the incremental stream “catches up to” the current provisioning stream. DSM cards accept *any* stream with the “next” sequential database level for that card.

DSM Reload

DSM cards might require a complete database reload in the event of reboot or loss of connectivity for a significant amount of time. The ELAP provides a mechanism to quickly load a number of DSM cards with the current database. The database on the ELAP is large and may be updated constantly. The database sent to the DSM card or cards is likely to be missing some updates, making it corrupt as well as back level. The upload process is divided in to two stages, one to sequentially send the raw database records and another to send all of the updates missed since the beginning of the first stage.

The DSM reload stream uses a separate RMTP channel from the provisioning and incremental update streams. This allows DSM multicast hardware to filter out the high volume of reload traffic from DSM cards that do not require it.

Continuous Reload

The ELAP handles reloading of multiple DSMs from different starting points. Reload begins when the first DSM requires it. Records are read sequentially from the real-time database from an arbitrary starting point, wrapping back to the beginning. If another DSM requires reloading at this time, it uses the existing record stream and notifies the DSM provisioning task of the first record it read. This continues until all DSMs are satisfied.

DSM Warm Restart

When a DSM is rebooted with a warm restart and there were no database updates transmitted during the reboot, the existing database is retained. If updates were transmitted from the ELAP RTDB during the reboot, the DSM database is reloaded when the reboot is complete.

ELAP User Interface Menus

The ELAP user interface consists of several menus of items that provide functions for configuration, maintenance, debugging, and platform operations. When a menu item is chosen, the ELAP performs the requested action.

Chapter 3, "*ELAP Graphical User Interface*," describes how to log into the interface and how to use the menu items. The descriptions include the following information:

- Login user names that can access the user interface menus
- The menu presented to each user for each login name
- Basic function provided by each menu item
- Response syntax expected by any prompts presented to the user by each menu item
- Output that can be displayed for each menu item operation
- Error responses that can be expected

Functional Description

MPS/DSM RTDB Audit Overview

General Description

The fact that the ELAP advanced services use several databases, creates the need for an audit that validates the contents of the different databases against each other. The audit runs on both MPS platforms to validate the contents of the Real-time DSM databases (RTDB). The active ELAP machine validates the database levels for each of the DSM cards.

Functional Description

MPS RTDB Audit

This audit maintains the the integrity of the RTDB Database on the MPS. This audit cycles through the entire RTDB within a 24-hour period and reports any anomalies in the form of an alarm. Once the RTDB is determined to be corrupt, provisioning is stopped and a data reload is required.

The Audit is controlled through the MPS GUI Menu field Maintenance:RTDB Audit. The state of the audit can be viewed and Enabled or Disabled through this control (“Maintenance Menu” on page 3-16).

When this Audit is enabled, the RTDB validates the CRC32 values per record entry within all tables. If corruption is encountered, an alarm is set on the MPS scrolling banner. All provisioning from the LSMS is halted until the condition is corrected via RTDB Reload

ELAP-to-DSM Network Card DB Level

Each DSM card validates its own database level against the received ELAP database level. An inconsistent alarm is generated at the EAGLE 5 ISS for every inconsistent DSM card. The command `rept-stat-db` displays the LNP database on the DSM card as *Diff* level. See Table 2-6.

Table 2-6. Inconsistent DSM Card Alarm

UAM#	Severity	Message Text	Output Group (UI Output Direction)
444	Minor	RTDB database is inconsistent	card

EAGLE 5 ISS DSM Audit of MPS Databases

This audit is responsible for maintaining the integrity of the RTDB on the VSCCP-DSM Card. This audit cycles though the entire RTDB within a 24 hour period, reporting any anomalies in the form of alarms and possibly (attempts to repair any found corrupted records with those from a mate VSCCP-DSM card.

The STP Options (`chg-stpopts`) command is used to set this audit. This is done with the aid of the `DSMAUD` parameter which has three states, OFF, ON and CCC. When the `DSMAUD` parameter is set to OFF the auditing capabilities on each of the VSCCP-DSM cards is disabled from auditing the RTDB Databases. Setting the `DSMAUD` parameter to ON enables the auditing capabilities producing corruption alarms when corruption is detected. Setting the `DSMAUD` parameter to CCC enables the cross correction capabilities, providing a method for repairing corruption as it is encountered.

When corruption is encountered several events occur.

1. The RTDB DB is set to Corrupt Status
2. A UAM (Table 2-7) is sent to the OAM
3. The Corruption is logged and stored in a memory array and contains:
 - a. Table Id
 - b. Record Number
 - c. Table High-water-mark
 - d. Old CRC32 value
 - e. New CRC32 value
 - f. Record Address in memory
 - g. Record entry Contents

Table 2-7. Corrupted RTDB Database Alarm

UAM#	Severity	Message Text	Output Group (UI Output Direction)
443	Minor	RTDB database is corrupted	card

A maximum of 250 Log entries are permitted within an audit cycle. When this maximum is exceeded the first 25 corrected records are output to the DB output group and the card initiates a Full Re-Load.

VSCCP-DSM cards in the corrupted state continue to receive updates from the MPS and continue to service MSU traffic.

Functional Description

All records received from the MPS are validated through the CRC32 routines prior to being written to memory. If a corrupted record is encountered, data is collected and depending upon the loading phase state, events will differ:

Table 2-8. Effect of Corrupted record received from MPS

MPS Loading Phase	Effect of Corrupted Record Received
Phase I - Loading	Booting of Card and Full Reload Requested
Phase II - Resynchronization	Booting of Card and Full Reload Requested
Load Complete	Alarm Incoherent and Reload Required

Corruption Cross Correction

If a record within the RTDB database on any card should become corrupted, a mate VSCCP-DSM card can supply the corrected data. Corruption Cross Correction occurs across the IMT and for each corrupted record encountered a single broadcast message is sent from the affected VSCCP-DSM card to all mate VSCCP-DSM cards. When a VSCCP-DSM card receives a request for corruption correction, the current DB Level and requested record is evaluated for consistency. If the request is validated, a response is sent to the original card. Otherwise the request is simply discarded. This would occupy at most 26 messages on the IMT bus for each corrupted record encountered. When a Corruption Correction Response is received, it is evaluated for correctness and applied once passed. Any subsequent messages received for the same correction is simply discarded.

Status Reporting and Alarms

The MPS systems and ELAPs have no direct means of displaying output messages on EAGLE 5 ISS terminals. Maintenance, measurements, status, and alarm information must be routed from the Active ELAP to an arbitrarily selected DSM card, known as the primary DSM. Static information is exchanged across this interface at initialization and dynamic information is exchanged on occurrence.

All the alarms are reported in a common message format. The Active ELAP generates and sends Maintenance Blocks to the primary DSM. One Maintenance Block is sent when the IP link is established between the Active ELAP and the primary DSM. Additional Maintenance Blocks are sent whenever the ELAP needs to report any change in status or error conditions. The information returned in Maintenance Blocks is included in the status reports produced by the `rept-stat-mps` command (see "Commands" on page 4-9).

The alarm reporting mechanism and various alarm messages are described in Chapter 4, "*Messages, Alarms, and Status Reporting.*"

Functional Description

3

ELAP Graphical User Interface

Overview of the ELAP User Interfaces.....	3-2
ELAP Graphical User Interface	3-2
ELAP GUI Menus	3-12
Select Mate	3-13
Process Control Menu	3-14
Maintenance Menu	3-16
RTDB Menu.....	3-34
Debug Menu	3-61
Platform Menu.....	3-71
User Administration Menu	3-81
Change Password.....	3-110
Logout.....	3-111
ELAP Messages.....	3-112

Overview of the ELAP User Interfaces

The EAGLE LNP Application Processor (ELAP) User Interface, consists of two user interfaces:

- The Graphical User Interface provides GUI menus that maintain, debug, and operate the platform; it and its associated error messages are described in this chapter.
- The text-based User Interface has a Configuration menu that performs the ELAP configuration and initialization; it is described in Chapter 5, *"ELAP Software Configuration"*.

The GUI provides the user with menus and screens to perform routine operations. The text-based user interface provides the ELAP Configuration menu to perform the initial configuration.

To communicate with the ELAP graphical user interface, you use a PC with a network connection and a network browser. For information about using the ELAP GUI, see "ELAP Graphical User Interface" on page 3-2

To configure ELAP, you use the ELAP text-based user interface. For information about configuring the ELAP and how to set up its PC workstation, refer to Chapter 5, *"ELAP Software Configuration"*.

ELAP Graphical User Interface

ELAP employs a web-based user interface. It uses the typical client-server paradigm. The front end appears on an Internet browser. The back end operates on the MPS platform. The front end is officially supported on Microsoft's Internet Explorer, version 5.0 or later, and on Mozilla's Firefox, version 1.0.2 or later. When using Firefox, you will encounter the following message when logging into the ELAP GUI:

CAUTION: The User Interface may not function correctly with the browser you are using.

Microsoft Internet Explorer, version 5 and later, has been certified for this application

The graphical user interface pages have three different sections.

- A banner header section for displaying the real-time status of the MPS servers
- A menu section for selecting desired actions
- A work area section for filling out requested information and displaying results.


ELAP Graphical User Interface

The banner header sections are a Java applet that communicates directly with the GUI Server process on the MPS. The menu and work area sections primarily consist of HTML and JavaScript generated by CGI (Common Gateway Interface) scripts on the back end.

An http web server starts the process of handling requests from browsers. It receives the requests and loads the requested document. If the document is a simple HTML file, the http web server just returns the document to the browser. The ELAP software may also connect with the GUI server to request that actions be performed. HTML output from the script is returned to the browser and displayed.

Figure 3-1 shows the process architecture view of the ELAP user interface.

Figure 3-1. Process Architecture View of the ELAP UI




This section describes the various screens, screen structure and layouts, and input prompts of the ELAP graphical user interface (GUI). It describes the login screen and the contents of the main screen. It explains the three frames comprising the browser window in the ELAP user interface.

Login Screen


The first screen in the ELAP Internet interface is the login screen. Two fields are prompted for on this screen: **Username** and **Password**. To log in, enter a valid user name and password, and click the Login button. These fields provide the user identification and verification. See Figure 3-2.

Figure 3-2. ELAP UI Login Screen



When a user logs in successfully, the screen workspace indicates the user is logged in, as shown in Figure 3-3.

Figure 3-3. ELAP UI Login Screen



When a user logs into the ELAP UI, he does not need to log in again so long as the web browser session remains. This is due to the fact that subsequent user authentication is handled with “cookies,” which are stored in the user's browser and remain there throughout the duration of the browser's operation.

ELAP Graphical User Interface


The user uses the Logout menu option to terminate the session and invalidate the cookie. Alternatively, the user can be logged out by session inactivity (defined by User Administration), terminated by the administrator, and by selecting another window on another independent browser.

ELAP GUI Main Screen

The ELAP graphical user interface main screen is composed of three “frames” or window sections. One window section, called the banner, is the topmost frame. It extends the entire width of the browser window.

The remainder of the browser window is divided vertically into two sections of unequal width. The smaller left section is known as the menu section. The larger right section is known as the workspace section. See Figure 3-4 for a view of the ELAP GUI main screen.

Figure 3-4. ELAP GUI Main Screen



Details describing the three sections of the ELAP GUI window are next.


- “Banner Section” on page 3-6
- “Menu Section” on page 3-9
- “Workspace Section” on page 3-10

Banner Section

In order to display real time status information, the banner section (the top area of the UI screen shown in Figure 3-4) has a Java applet that remains in constant communication with the ELAP program. The banner applet displays current status of the ELAP, state of the alarms, etc.

The banner applet contains the ELAP A and B areas, and the busy icon. See Figure 3-5.

Figure 3-5. ELAP Banner Applet



Busy Icon


The Tekelec company logo is located at the top left of the banner applet and performs as the busy icon. Its purpose is to serve as an indicator of activity in progress. When an action is being performed, the Tekelec icon moves; when the action ends, the icon is at rest.

ELAP Areas

The ELAP A and ELAP B areas contain information and displays to inform the user about the status and operation of the servers. See Figure 3-6.

ELAP Graphical User Interface

Figure 3-6. ELAP Area



ELAP A and ELAP B each have their own sections in the applet, but are structured similarly. The ELAP areas are described:

- **ELAP Server** - This indicator simply shows which ELAP server (A or B) is represented in this area. There is no action available via click or mouse-over for this field.
- **Name** - The Name field displays the name of the ELAP represented by this area.
- **Status** - The Status field displays the current status of the ELAP. The following values can be displayed:
 - **NONE**: No established connection exists to the ELAP GUI Server. This can result because of connectivity problems or because the ELAP GUI server is not running.
 - **DOWN**: The maintenance task is not running. The box may be running or not.
 - **UP**: The maintenance task is running (UP), but the box is experiencing some problem that prevents it from becoming ACTIVE or STANDBY. This condition can result from a hardware, software, or database problem.
 - **STANDBY**: This ELAP is capable of being the active ELAP but is not for some reason. Valid reasons are either its mate ELAP is active, or there are no DSMs to provision. In the latter case, both ELAPs are STANDBY.
 - **FORCED STANDBY**: This ELAP has been forced into the standby state by the user.
 - **ACTIVE**: This ELAP is actively responsible for provisioning the DSM cards with data. It is also the machine that has the connection to the primary DSM for the passage of maintenance and alarm information.
 - **VIOL**: This is not a valid ELAP state. This indicator on the browser indicates that the client browser's Java policy file is incorrect. For details, refer to "Installing Java Policy File" on page 5-7.

- LSMS Connection - The LSMS Connection field displays the connectivity status of the ELAP to the LSMS. If the LSMS is not connected, the label displays an icon indicating no connectivity. If the LSMS is connected, the icon displays an icon indicating a valid connection. When the LSMS is connected, a mouse-over of the label and icon displays the LSMS IP address and the JRS state.
- Alarm LEDs - The three Alarm LEDs show alarm conditions. The left LED indicates Critical alarms; it turns red when a Critical alarm occurs. The middle LED indicates Major alarms, and turns orange when a Major alarm occurs. The right LED indicates Minor alarms, and turns yellow when a Minor alarm occurs. Within each LED is a count of how many alarms of that type are currently active.

Clicking on any LED or any count field brings up another window that gives more detail on the actual alarms present. See Figure 3-7.

Figure 3-7. Alarm View Window



The Alarm View window has the details about what alarms are present. The alarms are subdivided into six categories by alarm type and severity. Each category displays its alarm bit mask for comparing to the EAGLE 5 ISS MPS alarm output. Each alarm category also displays the actual text value and alarm number for each of its active alarms.

For more information about these six alarm categories, refer to “Decode EAGLE 5 ISS MPS Alarm Screen” on page 3-23.

- Message Box - The message box has a horizontal scroll box that displays text messages for the user. Banner information messages, sometimes referred to as “scroll by” messages, indicate the status of the ELAP machine.

ELAP Graphical User Interface

Here are some messages that are scrolled in the message box.


- Backup file system successful
- Restore RTDB in progress
- RTDB synchronization in progress

See “ELAP Banner Information Messages” on page 3-115 for the complete list.

- Message History - The Message History icon links to a Java applet that displays in a separate window a history of the alarms and information messages for that server. Messages that scroll by are recorded in the message history box. It serves as a sort of visual log of error events.

Entries are color-coded to match the severity of its Alarm LED. Messages are coded in the following manner: red are critical, orange are major, yellow are minor, and white are information messages. Optionally, you can suppress messages from appearing in the Message Box by clicking its entry in the ‘Hide’ box in the Message History Box, a useful tool when you want to temporarily hide a recurrent messages. Figure 3-8 has a sample Message History box.

Figure 3-8. Example of Message History




Time Added	Time Cleared	Message	Hide
2/6/02 5:43:10 PM		Platform Error	<input type="checkbox"/>
2/6/02 5:43:10 PM		Platform Process Failure	<input type="checkbox"/>
2/6/02 5:43:10 PM		Mate PDBA Unreachable	<input type="checkbox"/>
2/6/02 5:43:10 PM		Hardware Configuration Error	<input type="checkbox"/>

Menu Section

The ELAP graphical user interface menu is located in the left frame of ELAP browser interface. At the top of the frame is the software system title, ELAP, and a letter designation of the selected MPS machine, either A or B. One or more submenus appear below the title, depending on the access privilege of the user who views the menu. An icon accompanies the name of each submenu.

By clicking on the name or folder icon of a directory, the user may expand and contract the listing of the submenu's contents in the typical “tree-menu” fashion. Directory contents may be either menu actions or more submenus. When you click the Menu actions, the output is displayed in the workspace section, which is the right frame of ELAP browser interface. An example of a menu in the menu section is shown in Figure 3-9.


Figure 3-9. Example of an ELAP Menu



Workspace Section

The results of from menu actions are displayed in the workspace section. The content of the workspace section can be various things such as prompts or status reports. Every menu action that writes to the workspace uses a standard format. See the example of the workspace format in Figure 3-10.

Figure 3-10. Example of Workspace Format



The format for the workspace is a page header and footer, and page margins on either side. In the header two data fields are displayed. The left-justified letter A or B designates which MPS server this menu action affects. The other data field has the right-justified menu action title. The footer consists of a bar and text with the time when the page was generated. At the bottom of the footer, a Tekelec copyright notice appears.

Workspace Syntax Checking


The web browser user interface uses layers of syntax checking to validate user input for text-entry fields.

- Mouse-over syntax check: For many of the entry fields, you can move the mouse over the field, causing a list of syntax hints for that field to appear.
- Pop-up syntax checking: When you click the **Submit** button, syntax is verified on the client side by code running on the user's browser. Incorrect syntax appears in a pop-up window, which contains a description of the syntax error. When the window is dismissed, you can correct the error and submit the input again.
- Back-end syntax checking: When you have clicked **Submit** button and the client side syntax checking has found no errors, back-end syntax checking is performed. If back-end syntax checking detects an error, it is displayed in the work space with an associated error code.

ELAP GUI Menus

The ELAP menu is the main menu of the ELAP application. It provides the functions of the ELAP User Interface. Figure 3-11 shows the ELAP main menu.

Figure 3-11. ELAP Menu



The ELAP menu provides three actions common to all users, Select Mate, Change Password, and Logout. All the remaining actions are options assignable by the system administrator to groups and individual users.


- “Select Mate” on page 3-13
- “Process Control Menu” on page 3-14
- “Maintenance Menu” on page 3-16
- “RTDB Menu” on page 3-34
- “Debug Menu” on page 3-61
- “Platform Menu” on page 3-71
- “User Administration Menu” on page 3-81
- “Change Password” on page 3-110
- “Logout” on page 3-111

Select Mate

The Select Mate menu selection changes the menus and workspace areas to point to the ELAP mate. This selection exchanges the status of the active and standby ELAPs. This basic action is available to all users and is accessible from the main menu (Figure 3-11, on page 3-12).

If you using ELAP A at the main menu, and you want to switch to ELAP B, you click the Select Mate button on the main menu. The initial sign-on screen for the alternate server now appears, as shown in Figure 3-12.

Figure 3-12. Select Mate Screen




When you perform the Select Mate action, the contents of the banner do not change. However, the side (server) changes in the workspace and at the top of the menu area to indicate the active ELAP.

Process Control Menu

The Process Control menu allows the user to start and stop the ELAP software processes. See the Process Control menu in Figure 3-13.

Figure 3-13. Process Control Menu



The Process Control menu provides the start and stop software actions.

- “Start ELAP Software” on page 3-14
- “Stop ELAP Software” on page 3-15

Start ELAP Software

The Process Control / Start ELAP Software menu option lets you start the ELAP software processes. The screen contains only a button to confirm that you do want to start the software processes. See Figure 3-14 for the Start ELAP Software screen, Figure 3-15 for a successful start of the ELAP software.

Figure 3-14. Start ELAP Software Screen





Figure 3-15. Successful Start of ELAP Software Screen



Stop ELAP Software

The Process Control / Stop ELAP Software screen lets the user stop the ELAP software processes. The screen contains a button to confirm that the user does want to stop the software processes. It also lets you choose whether the software is to restart automatically when the server reboots. See Figure 3-16 for the Stop ELAP Software screen, Figure 3-17 for a successful stop.

Figure 3-16. Stop ELAP Software Screen





Figure 3-17. Successful Stop ELAP Software Screen



Maintenance Menu

The Maintenance Menu lets you perform various ELAP platform tasks shown in Figure 3-18.

Figure 3-18. Maintenance Menu



The Maintenance menu provides the following actions:

- “Force Standby Menu” on page 3-17
- “Simplex Mode Menu” on page 3-20
- “Display Release Levels Screen” on page 3-22
- “Decode EAGLE 5 ISS MPS Alarm Screen” on page 3-23
- “RTDB Audit Menu” on page 3-24
- “LSMS High Speed Audit Menu” on page 3-25
- “LSMS High Speed Bulk Download Menu” on page 3-28
- “LSMS Connection Menu” on page 3-31

Force Standby Menu

The Maintenance / Force Standby menu lets you view the ELAP state and change it by toggling into and out of forced standby state. See Figure 3-19.

Figure 3-19. Force Standby Menu



The Force Standby menu provides the following actions:

- “View Status Screen” on page 3-17
- “Change Status Screen” on page 3-18

View Status Screen

This Maintenance / Force Standby / View Status screen displays whether or not ELAP is currently in a forced standby state. See Figure 3-20.

Figure 3-20. View Forced Standby Status Screen




Change Status Screen

The Maintenance / Force Standby / Change Forced Standby Status screen selection toggles the forced standby restriction on the selected ELAP. The current state of the selected ELAP is determined before the output of this screen. If the ELAP is not currently in forced standby mode, this screen lets the user force it into standby mode.

If the ELAP is currently in forced standby mode, the user can remove the standby restriction on the selected ELAP. See Figure 3-21.

Figure 3-21. Change Forced Standby Status Screen




To put the current ELAP in forced standby mode, click the Activate STANDBY Restriction button. See Figure 3-22 for the screen showing successful change of status.

Figure 3-22. Successfully Changing Forced Standby Status



To remove the forced standby mode, click the Change Status button and see the screen that initiates the removal of the forced standby state, shown by Figure 3-23.

Figure 3-23. Removing Changing Forced Standby Status



To finish removing the forced standby status, click the Remove STANDBY Restriction button. See Figure 3-24 for the screen showing a successful change of status.


Figure 3-24. Removing Changing Forced Standby Status



Simplex Mode Menu

The Maintenance /Simplex Mode Menu provides the functionality to view as well as change (i.e toggle) whether or not the ELAP is in the simplex mode. See Figure 3-25 for this menu.

Figure 3-25. Simplex Mode Menu



The Simplex Mode Menu provides the following functions:

- “View Simplex Mode” on page 3-20
- “Change Simplex Mode” on page 3-21

View Simplex Mode

The Maintenance /Simplex Mode Menu/View Simplex Mode screen displays whether or not the ELAP is in the simplex mode state. See Figure 3-26 for this menu.


Figure 3-26. View Simplex Mode Screen



Change Simplex Mode

The Maintenance /Simplex Mode Menu/Change Simplex Mode screen is used to activate or deactivate the simplex mode on the selected ELAP. The current state of the selected ELAP is shown on this screen. If the ELAP is currently in the duplex mode, this screen will enable the user to change it to the simplex mode. If the ELAP is currently in simplex mode, this screen will enable the user to remove the simplex mode condition on the selected ELAP. See Figure 3-27 for this menu.


Figure 3-27. Change Simplex Mode Screen



Display Release Levels Screen

The Maintenance / Display Release Levels screen displays release information, as shown in Figure 3-28.

Figure 3-28. Maintenance / Display Release Levels Screen



Decode EAGLE 5 ISS MPS Alarm Screen


The Maintenance / Decode EAGLE 5 ISS MPS Alarm menu selection lets the user decode the EAGLE 5 ISS output of MPS alarms. The user enters the 16-character hexadecimal string from the EAGLE 5 ISS `rept-stat-mps` command. The strings are encoded from one of the following six categories, which are reported by UAM alarm data strings:

- Critical Platform Alarm (UAM #0370, alarm data h'1000 . . .')
- Critical Application Alarm (UAM #0371, alarm data h'2000 . . .')
- Major Platform Alarm (UAM #0372, alarm data h'3000 . . .')
- Major Application Alarm (UAM #0373, alarm data h'4000 . . .')
- Minor Platform Alarm (UAM #0374, alarm data h'5000 . . .')
- Minor Application Alarm (UAM #0375, alarm data h'6000 . . .')

The string included in the alarm messages is decoded into a category and a list of each MPS alarm that the hexadecimal string represents. The user should compare the decoded category with the source of the hex string as a sanity check. More details about the messages is in "System Health Check" *Tekelec 1100 AS MPS Platform Software and Maintenance Manual*.

The text for the alarms indicated by the alarm hex string is described in "MPS Platform and ELAP Application Alarms" on page 4-14. See Figure 3-29 for the Decode EAGLE 5 ISS MPS Alarm screen.


Figure 3-29. Decode EAGLE 5 ISS MPS Alarm Screen



RTDB Audit Menu

The Maintenance / RTDB Audit menu lets the user view and change the auditing of the selected ELAP. See Figure 3-30 for the Maintenance / RTDB Audit menu.

Figure 3-30. RTBD Audit




The RTDB Audit menu provides these RTDB Audit tasks:

- “View Enabled” on page 3-24
- “Change Enabled” on page 3-25

View Enabled

The Maintenance / RTDB Audit / View Enabled menu selection lets the user view the status of RTDB audit enabled, as shown in Figure 3-31.


Figure 3-31. View the RTDB Status Screen



Change Enabled

The Maintenance / RTDB Audit / Change Enabled screen turns auditing on and off for the RTDB that is on the selected ELAP. The user interface detects whether RTDB audit is enabled or disabled, and provides the associated screen to toggle the state. In Figure 3-32, the RTDB Audit is shown as Enabled.


Figure 3-32. Change the RTDB Audit Enabled Screen



LSMS High Speed Audit Menu

The Maintenance / LSMS HS Audit menu lets the user view and change the auditing of the selected ELAP. See Figure 3-33 for the Maintenance / High Speed Audit menu.

Figure 3-33. LSMS High Speed Audit




The LSMS High Speed Audit menu provides these actions.

- “View Enabled” on page 3-26
- “Change Enabled” on page 3-26

View Enabled

The Maintenance / LSMS HS Audit / View Enabled menu selection reports whether LSMS high speed auditing is enabled or disabled, as shown in Figure 3-34.

Figure 3-34. LSMS HS Audit View Enabled Screen




Change Enabled

The Maintenance / LSMS HS Audit / Change Enabled menu selection lets the user change the state of LSMS HS Auditing. The user interface detects the whether LSMS HS audit is engaged or disengaged, and provides the associated screen to toggle (that is, to alternate) the state.

In Figure 3-35, the LSMS HS Audit is shown as engaged.

Figure 3-35. LSMS HS Audit Change Enabled Screen




To put the change the status of the LSMS High Speed audit to Disabled, click the Disable LSMS HS Audit button. See Figure 3-36 for the screen showing successful change of status.

Figure 3-36. Successfully Disabling LSMS HS Audit




To restore the LSMS HS Audit to Enabled status, click the Change Enabled button on the menu. The new state is displayed in Figure 3-37.

Figure 3-37. Restoring LSMS HS Audit Enabled



To confirm the restoring of LSMS HS Audit to Enabled state, click the Enable LSMS HS Audit button, shown in Figure 3-38.


Figure 3-38. Confirming LSMS HS Audit Enabled



LSMS High Speed Bulk Download Menu

The Maintenance / LSMS HS Bulk Download menu lets the user view and change the state of high speed bulk downloading of the selected ELAP. See Figure 3-39 for the Maintenance / High Speed Bulk Download menu.

Figure 3-39. LSMS High Speed Bulk Download




The LSMS High Speed Bulk Download menu provides these actions.

- “View Enabled” on page 3-28
- “Change Enabled” on page 3-29

View Enabled

The Maintenance / LSMS HS Bulk Download / View Enabled menu selection displays the state of the LSMS High Speed Bulk Download / LSMS High Speed Resync. The LSMS Bulk Download/LSMS HS Resync status is enabled, as shown in Figure 3-40.

Figure 3-40. LSMS HS Bulk Download View Enabled Screen




Change Enabled

The Maintenance / LSMS HS Bulk Download / Change Enabled menu selection lets the user enable and disable the LSMS Bulk Download/LSMS HS Resync state. The user interface detects whether LSMS Bulk Download/LSMS HS Resync is enabled or disabled, and provides the associated screen to toggle the state.


In Figure 3-41, the LSMS Bulk Download/LSMS HS Resync is shown as Enabled.

Figure 3-41. LSMS Bulk Download Change Enabled Screen




To change the status of the LSMS High Speed Bulk Download to Disabled, click the Disable LSMS Bulk Download for this ELAP button. See Figure 3-42 for the screen showing successful change of status.

Figure 3-42. Successfully Disabling LSMS HS Bulk Download




To restore the LSMS HS Bulk Download to Enabled status, click the Change Enabled button on the menu. The new state is displayed in Figure 3-43.

Figure 3-43. Restoring LSMS HS Bulk Download Enabled



To confirm the restoring of LSMS HS Bulk Download to Enabled state, click the Enable LSMS Bulk Download for this ELAP button, shown in Figure 3-43. When LSMS Bulk Download for the ELAP is successfully enabled, the screen in Figure 3-44 confirms it is Enabled.


Figure 3-44. Confirming LSMS HS Bulk Download Enabled



LSMS Connection Menu

The Maintenance / LSMS Connection menu lets you view and change the state of the LSMS connection. See Figure 3-45 for the LSMS Connection menu.

Figure 3-45. LSMS Connection




The LSMS Connection menu provides these actions.

- “View Allowed” on page 3-31
- “Change Allowed” on page 3-32

View Allowed

The Maintenance / LSMS Connection / View Allowed menu selection displays the state of the LSMS connection. The LSMS connection status is enabled, as shown in Figure 3-46.

Figure 3-46. LSMS Connection View Allowed Screen




Change Allowed

The Maintenance / LSMS Connection / Change Allowed menu selection lets the user enable and disable the LSMS connection. The user interface detects the whether LSMS Connection is enabled or disabled, and provides the associated screen to toggle between (that is, to alternate) the states.


In Figure 3-47, the LSMS Connection Allowed is shown as enabled.

Figure 3-47. Change LSMS Connection Allowed Enabled




To disable the LSMS connection, click the Disable LSMS Connection button. See Figure 3-48 for the screen showing successfully disabling the LSMS connection.

Figure 3-48. Successfully Disabling LSMS HS Bulk Download



To restore the LSMS HS Bulk Download to Allowed status, click the Change Allowed button on the menu. See the screen that shows the state is Disabled and that lets you restore the Allowed state. See Figure 3-49.

Figure 3-49. Restoring LSMS Connection Allowed Enabled



To confirm the restoring of LSMS connection to Enabled state, click the Enable LSMS Connection button. See Figure 3-50 for the screen showing the LSMS Connection successfully Enabled.


Figure 3-50. Confirming LSMS Connection Allowed Enabled



RTDB Menu

The RTDB (Real-Time Database) Menu allows the user to interact with the RTDB for status, reloading, and updating. See the RTDB Menu in Figure 3-51.

Figure 3-51. RTDB Menu



The RTDB menu supports various ELAP tasks, including:

- “View RTDB Status” on page 3-35
- “View LNP Qty Features” on page 3-36
- “Maintenance Menu” on page 3-36
- “Retrieve Records Menu” on page 3-41
- “Local Provisioning Menu” on page 3-48

ELAP Graphical User Interface

View RTDB Status

The RTDB / View RTDB Status screen displays the current level and birthday of the ELAP RTDBs. This selection displays the RTDB status information for both the selected ELAP and its mate. The status information reports the DB level and the DB birthday (date and time of the creation of the database). See Figure 3-52.

Figure 3-52. View RTDB Status Screen

The screenshot shows a web interface titled "View RTDB Status". It is divided into three main sections: "Local RTDB Status", "Mate RTDB Status", and "Refresh Options".

Local RTDB Status:

DB Status:	Coherent	Audit Enabled:	Yes
RTDB Level:	47	RTDB Birthday:	09/23/2005 20:21:14 GMT
Counts:	TNs=192000000, NPANXXs=273117, LRNs=149261, SPs=9402, MRs=17109, MRGroups=963718		
Reload:	None		

Mate RTDB Status:

DB Status:	Coherent	Audit Enabled:	Yes
RTDB Level:	47	RTDB Birthday:	09/23/2005 20:21:14 GMT
Counts:	TNs=192000000, NPANXXs=273117, LRNs=149261, SPs=9402, MRs=17109, MRGroups=963718		
Reload:	None		

Refresh Options:

View RTDB Status refresh time (seconds):

Tue September 27 2005 18:23:19 EDT


2003 © Tekelec, Inc., All Rights Reserved.

View LNP Qty Features

The RTDB /View LNP QTY screen displays the enabled LNP quantity features and quantity enabled as provisioned on the EAGLE 5 ISS. See Figure 3-53.

This ELAP version only menu item selection displays the enabled LNP quantity features as provisioned on the EAGLE 5 ISS. User requires "View LNP Qty Features" action privilege to view this menu selection.

Figure 3-53. LNP QTY Features Screen



LNP Quantity Feature	Quantity Enabled
LNP ported TNs	12000000
LNP ported NPANXXs	0
LNP ported LRNs	100000

Wed March 26 2003 15:12:26 EST
2003 © Tekelec, Inc., All Rights Reserved.

Maintenance Menu

The RTDB / Maintenance menu lets the user perform RTDB maintenance. See Figure 3-54 for the RTDB / Maintenance menu.

Figure 3-54. Maintenance Menu




The Maintenance menu provides these actions:

- “Reload from Remote” on page 3-37
- “Backup RTDB” on page 3-38
- “Restore RTDB” on page 3-39

Reload from Remote


The RTDB / Maintenance / Reload RTDB from Remote screen copies the RTDB to the local machine from the mate or remote machine. See Figure 3-55.

Figure 3-55. Reload RTDB from Remote Screen



To reload the local RTDB, choose which source you want to reload, and click the Begin RTDB Reload from Remote button. If you attempt to do this while the ELAP is running, you receive the error message in Figure 3-56.


Figure 3-56. Error in Reloading RTDB from Remote Screen



Backup RTDB


The RTDB / Maintenance / Backup the RTDB screen allows the user to backup the RTDB to a file. This file should then be transferred by Secure File Transfer Protocol (`sftp`) to a remote, safe location. The software must be down for the backup to be allowed to ensure that no updates are occurring. See Figure 3-57.

Figure 3-57. Backup the RTDB Screen




When you are ready to backup the RTDB, stop the selected ELAP software. Click the Backup RTDB button. You are shown a screen to confirm your backup choice in Figure 3-58.

Figure 3-58. Confirming the Backup the RTDB Screen



Confirm that you want to perform the backup by clicking the Confirm RTDB Backup button. Figure 3-59 shows the successful startup of the RTDB backup.


Figure 3-59. Successfully Starting the Backup the RTDB Screen



Restore RTDB


The RTDB / Maintenance / Restore the RTDB screen allows the user to restore the RTDB from an RTDB backup file. The software must be down for the backup to be allowed to ensure that no updates are occurring. Follow the procedure in the *Tekelec 1100 AS MPS Platform Software and Maintenance Manual* to restore the RTDB from a backup file. See Figure 3-60.

Figure 3-60. Restore the RTDB




When you are ready to restore the RTDB, prepare the backup media and stop the selected ELAP software. Select the appropriate file and click the Restore RTDB from the Selected File button. You are shown a screen to confirm your restoration choice in Figure 3-61.

Figure 3-61. Confirming the Restoration of the RTDB



Confirm that you want to perform the backup by clicking the Confirm RTDB Restore button. Figure 3-62 shows the successful restoration of the RTDB.


Figure 3-62. Successfully Starting the RTDB Restoration



Retrieve Records Menu

The RTDB / Retrieve Records menu allows the user to retrieve a single subscription record, a single default GTT record, a single override GTT record, a single NPA NXX record, and a service provider record or list all service providers. See Figure 3-63 for an example of the Retrieve Records menu.

Figure 3-63. Retrieve Records Menu



The RTDB / Retrieve Records menu provides these actions:

- “Subscriptions” on page 3-41
- “Default GTT” on page 3-43
- “Override GTT” on page 3-44
- “NPA NXX Split” on page 3-46
- “Service Providers” on page 3-47

Subscriptions

The RTDB / Retrieve Records / Subscriptions menu option lets the user retrieve a single subscription record using a 10-digit subscription as the key. See Figure 3-64 for the Retrieve Subscription screen.

Figure 3-64. Retrieve Subscriptions Screen

A screenshot of a web-based form titled "Retrieve Subscriptions Records from RTDB". The form has a header with a large "A" on the left and the title on the right. Below the header, there are two input fields: "Start TN:" followed by a text box, and "End TN:" followed by a text box and the word "(optional)". Below these fields is a "Retrieve" button. At the bottom of the form, there is a blue bar containing the text "Thu March 06 2003 15:32:41 EST" and "2003 © Tekelec, Inc., All Rights Reserved."

Enter the single ten-digit subscription number in the TN field, and click the Retrieve button.

See Figure 3-65 for a sample response from the Retrieve Subscription screen.

Figure 3-65. Sample of Retrieve Subscriptions Output

A Retrieve Subscriptions Records from RTDB

TN	LRN	SPID	TYPE	Service	DPC	SSN	RI	NEWTT
9194601368	1234567890	44	NONE	CLASS	010-011-012	055	D	---
				LIDB	020-021-022	055	D	---
				ISVM	030-031-032	055	D	---
				CNAM	040-041-042	055	D	---
				WSMSC	050-051-052	055	D	---

Mon April 15 2002 13:27:34 EDT

2001 © Tekelec, Inc., All Rights Reserved.

Output Field Descriptions		
Field	Description	Range
TN	Telephone Number (10 character subscription)	0000000000 - 9999999999 or 0000000*** - 9999999***
LRN	Location Routing Number	0000000000 - 9999999999
SPID	Service Provider ID	4 character alphanumeric
TYPE	LNP Type	NONE, POOL
Service	LNP Service	CLASS, LIDB, ISVM, CNAM, WSMSC
DPC	Destination Point Code	xxx-yyy-zzz where: xxx: 000 - 254 yyy: 000 - 254 zzz: 000 - 254
SSN	Subsystem Number	000 - 254
RI	Routing Indicator	G, D
NEWTT	New Translation Type	000 - 254

Default GTT

The RTDB / Retrieve Records / Retrieve Default GTT Records from RTDB screen lets you retrieve a single default GTT record using a six-digit NPA NXX number as the key. See Figure 3-66 for the Retrieve Default GTT Records from GTT screen.

Figure 3-66. Retrieve Default GTT from RTDB

Enter the single NPA NXX number in the Default GTT NPANXX field, and click the Retrieve button.

See Figure 3-67 for a sample response from the Retrieve Default GTT screen.

Figure 3-67. Sample of Retrieve Default GTT Output


NPANXX	AIN	IN	Service	DPC	SSN	RI	NEWT
919460	YES	YES	CLASS	010-011-012	055	G	000
			LIDB	020-021-022	055	G	000
			ISVM	030-031-032	055	G	000
			CNAM	040-041-042	055	D	---
			WSMSC	050-051-052	055	D	---

Output Field Descriptions		
Field	Description	Range
NPANXX	6-digit default GTT	000000 - 999999
AIN	Use Local AIN	YES, NO
IN	Use Local IN	YES, NO
Service	LNP Service	CLASS, LIDB, ISVM, CNAM, WSMSC
DPC	Destination Point Code	xxx-yyy-zzz where: xxx: 000 - 254 yyy: 000 - 254 zzz: 000 - 254
SSN	Subsystem Number	000 - 254
RI	Routing Indicator	G, D
NEWTT	New Translation Type	000 - 254

Override GTT

The RTDB / Retrieve Records / Override GTT screen lets the user retrieve a single override GTT record using a 10-digit LRN number as the key. See Figure 3-68 for the Retrieve Override GTT from RTDB screen.

Figure 3-68. Retrieve Override GTT Screen



Enter the single Location Routing Number in the LRN field, and click the Retrieve button.

See Figure 3-69 for a sample response from the Retrieve Override GTT screen.

Figure 3-69. Sample of Retrieve Override GTT Output

A Retrieve Override GTT Records from RTDB

LRN	SPID	Service	DPC	SSN	RI	NEWTT	RGTA
9194601368	66	CLASS	001-002-003	055	G	---	YES
		LIDB	002-003-004	055	G	---	NO
		ISVM	003-004-005	055	G	---	YES
		CNAM	004-005-006	055	D	---	NO
		WSMSC	005-006-007	055	D	---	YES

Mon April 15 2002 13:41:39 EDT
2001 © Tekelec, Inc., All Rights Reserved.

Output Field Descriptions		
Field	Description	Range
LRN	Location Routing Number	0000000000 - 9999999999
SPID	Service Provider ID	4 character alphanumeric
Service	LNP Service	CLASS, LIDB, ISVM, CNAM, WSMSC
DPC	Destination Point Code	xxx-yyy-zzz where: xxx: 000 - 254 yyy: 000 - 254 zzz: 000 - 254
SSN	Subsystem Number	000 - 254
RI	Routing Indicator	G, D
NEWTT	New Translation Type	000 - 254
RGTA	Replace Global Title Address with LRN	YES, NO

NPA NXX Split

The RTDB / Retrieve Records / NPA NXX Split screen lets the user retrieve a single split NPA NXX record using a 6-digit NPA NXX number as the key. See Figure 3-70 for the Retrieve NPA NXX Split Records from RTDB screen.

Figure 3-70. Retrieve NPA NXX Split Screen

Enter the single NPA NXX split record number in the Old NPANXX field, and click the Retrieve button.

See Figure 3-71 for a sample response from the Retrieve NPA NXX Split screen.

Figure 3-71. Sample of Retrieve NPA NXX Split Output

Output Field Descriptions		
Field	Description	Range
Old NPA NXX	6-digit default GTT	000000 - 999999
New NPA NXX	6-digit default GTT	000000 - 999999

Service Providers


The RTDB / Retrieve Records / Service Providers from RTDB screen lets you retrieve a single service provider record or list all the service providers in the database. See Figure 3-72 for the Retrieve Service Providers Records from RTDB screen.

Figure 3-72. Retrieve Service Providers Screen



Enter the number in the Service Provider ID field, and click the Retrieve button. See Figure 3-73 for a sample response from the Retrieve Service Provider Records from RTDB screen.

Figure 3-73. Sample of Retrieve Service Providers Output




Output Field Descriptions		
Field	Description	Range
SP	Service Provider	4 character alphanumeric

Local Provisioning Menu

The RTDB / Local Provisioning menu contains options that let the user provision LNP data directly to the RTDB. This menu contains options for Subscriptions, NPA NXX, Override GTT, and NPA NXX Split. See Figure 3-74 for the Local Provisioning screen.

Figure 3-74. Local Provisioning Menu



Local Provisioning Utility

The Local Provisioning Utility (LPU) handles customer data received locally. The LPU processes Local Provisioning commands (page 3-48).

If an equipment or communications failure causes the LSMS to be unable to connect to either the local or remote JRS through the JRS's LPU port, the LPU masquerades as an LSMS. This masquerade results in the LPU processing commands in the absence of an LSMS connection. When such a failure happens, the LPU takes control of both JRS LSMS ports and sends a timestamp request to the local side, which allows LPU to connect to the local JRS's LPU port. It controls both ports to eliminate the possibility of LSMS reconnecting to the other port and causing synchronization problems.

The Retrieve Records and Local Provisioning commands have a checkbox option:

`Process command even if connection to remote LSMS port not possible
(use option with care).`

The user checks this option to allow the LPU to masquerade by connecting to only the local JRS's LSMS port.

NOTE: Use the checkbox option only when the remote JRS is known to be corrupted or not operational.


The RTDB / Local Provisioning menu provides these actions:

- “Subscriptions” on page 3-49
- “NPA NXX Menu” on page 3-53
- “Override GTT Menu” on page 3-55
- “NPA NXX Split Menu” on page 3-58
- “Batch Mode” on page 3-60

Subscriptions

The RTDB / Local Provisioning / Subscriptions menu options lets you update, delete, and retrieve LNP data directly to the RTDB. See Figure 3-75 for the Local Provisioning /Subscriptions menu.

Figure 3-75. Local Provisioning / Subscriptions Menu




The RTDB / Local Provisioning /Subscriptions menu provides these actions:

- “Subscriptions / Update” on page 3-49
- “Subscriptions / Delete” on page 3-51
- “Subscriptions / Retrieve” on page 3-52

Subscriptions / Update

The RTDB / Local Provisioning /Subscriptions / Update LNP Subscription Records screen lets the user update values for a specific subscription using a 10-digit subscription number as a key. See Figure 3-76 for the RTDB / Local Provisioning / Subscriptions / Update LNP Subscription Records screen.

Figure 3-76. Update LNP Subscriptions Records



A Update LNP Subscription Records

TN:

LRN:

Service Provider ID:

Service	DPC	SSN
CLASS	<input type="text"/>	<input type="text"/>
LIDE	<input type="text"/>	<input type="text"/>
ISVM	<input type="text"/>	<input type="text"/>
CNAM	<input type="text"/>	<input type="text"/>
WSMSC	<input type="text"/>	<input type="text"/>

Process command even if connection to remote LSMS port not possible (use this option with care)

Fri April 12 2002 09:50:20 EDT

2001 © Tekelec, Inc., All Rights Reserved.

Enter the required information in the fields shown, and click the Update button.

NOTE: Do not check the ‘Process command even if connection to remote LSMS port not possible’ button unless you thoroughly understand the material in “Local Provisioning Utility” on page 3-48.

See Figure 3-77 for a list of sample responses from the Update Subscriptions option screen.

Figure 3-77. Sample of Updating LNP Subscription Records Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N] :
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N] :

Subscriptions / Delete

The RTDB / Local Provisioning / Subscriptions / Delete LNP Subscription Records screen lets the user delete a specific subscription record using a 10-digit subscription number as a key. See Figure 3-78 for the RTDB / Local Provisioning / Subscriptions / Delete LNP Subscription Records screen.

Figure 3-78. Delete LNP Subscribing

Enter the single ten-digit subscription number in the TN field, and click the Retrieve button.

NOTE: Do not check the 'Process command even if connection to remote LSMS port not possible' button unless you thoroughly understand the material in "Local Provisioning Utility" on page 3-48.

See Figure 3-79 for a list of sample responses from the Delete Subscriptions option screen.


Figure 3-79. Sample of Delete Subscription Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N] :
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N] :

Subscriptions / Retrieve

The RTDB / Local Provisioning / Subscriptions / Retrieve LNP Subscription Records screen lets the user retrieve a specific subscription record using a 10-digit subscription number as a key. See Figure 3-80 for the Local Provisioning / Subscriptions / Retrieve LNP Subscription Records screen.

Figure 3-80. Retrieve LNP Subscribing



A Retrieve LNP Subscription Records

Start TN:

End TN: (optional)

Process command even if connection to remote LSMS port not possible (use this option with care)

Retrieve

Thu March 06 2003 13:57:54 EST
2003 © Tekelec, Inc., All Rights Reserved.

Enter the single ten-digit subscription number in the TN field, and click the Retrieve button.

NOTE: Do not check the ‘Process command even if connection to remote LSMS port not possible’ button unless you thoroughly understand the material in “Local Provisioning Utility” on page 3-48.

See Figure 3-81 for a list of sample responses from the Retrieve Subscriptions option screen.


Figure 3-81. Sample of Retrieve Subscription Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N]:
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N]:

NPA NXX Menu

The RTDB / Local Provisioning / NPA NXX menu lets you update and delete a single NPA NXX record directly to the RTDB. See Figure 3-82 for the RTDB / Local Provisioning / NPA NXX screen.

Figure 3-82. RTDB / Local Provisioning / NPA NXX Menu



The RTDB / Local Provisioning / NPA NXX menu provides these actions:

- “NPA NXX / Update” on page 3-53
- “NPA NXX / Delete” on page 3-54

NPA NXX / Update

The RTDB / Local Provisioning / NPA NXX / Update NPA NXX Records screen lets you update values for a specific NPA NXX record using a 6-digit subscription number as a key. See Figure 3-83 for the Local Provisioning / Subscriptions / Update NPA NXX Records screen.

Figure 3-83. Update NPA NXX Records

A
Update NPA NXX Records

Default GTT NPANXX:	<input type="text"/>
AIN Local?:	<input type="button" value="Yes"/>
IN Local?:	<input type="button" value="Yes"/>

Service	DPC	RI	SSN	New TT
CLASS	<input type="text"/>	<input type="button" value="None"/>	<input type="text"/>	<input type="text"/>
LIDB	<input type="text"/>	<input type="button" value="None"/>	<input type="text"/>	<input type="text"/>
ISVM	<input type="text"/>	<input type="button" value="None"/>	<input type="text"/>	<input type="text"/>
CNAM	<input type="text"/>	<input type="button" value="None"/>	<input type="text"/>	<input type="text"/>
WSMSC	<input type="text"/>	<input type="button" value="None"/>	<input type="text"/>	<input type="text"/>

Process command even if connection to remote LSMS port not possible (use this option with care)

Content Generated: Fri Apr 12 10:03:12 EDT 2002

2001 © Tekelec, Inc., All Rights Reserved.

Enter the required information in the fields shown, and click the Update button.

NOTE: Do not check the ‘Process command even if connection to remote LSMS port not possible’ button unless you thoroughly understand the material in “Local Provisioning Utility” on page 3-48.

See Figure 3-84 for a list of sample responses from the Update NPA NXX Records option screen.

Figure 3-84. Samples of Update NPA NXX Records Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N] :
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N] :

NPA NXX / Delete

The RTDB / Local Provisioning / NPA NXX / Delete NPA NXX Records screen lets you delete values for a specific NPA NXX record using a 6-digit subscription number as a key. See Figure 3-85 for the RTDB / Local Provisioning / NPA NXX / Delete NPA NXX Records screen.

Figure 3-85. Delete NPA NXX Records

ELAP Graphical User Interface

Enter the single NPA NXX number in the Default GTT NPANXX field, and click the Delete button.

NOTE: Do not check the ‘Process command even if connection to remote LSMS port not possible’ button unless you thoroughly understand the material in “Local Provisioning Utility” on page 3-48.

See Figure 3-86 for a list of sample responses from the Update NPA NXX Records option screen.


Figure 3-86. Samples of Delete NPA NXX Records Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N] :
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N] :

Override GTT Menu

The RTDB / Local Provisioning / Override GTT menu lets you update and delete a single LRN (Location Routing Number) record directly to the RTDB. See Figure 3-87 for the RTDB / Local Provisioning / Override GTT menu.

Figure 3-87. RTDB / Local Provisioning / Override GTT Menu




The RTDB / Local Provisioning / Override GTT menu provides these actions:

- “Override GTT / Update” on page 3-55
- “Override GTT / Delete” on page 3-57

Override GTT / Update

The RTDB / Local Provisioning / Override GTT / Update Override GTT Records screen lets the user update values for a specific LRN record using a 10-digit LRN number as a key. See Figure 3-88 for the Local Provisioning / Override GTT / Update Override GTT Records screen.

Figure 3-88. Update Override GTT Records



A Update Override GTT Records

LRN:

Service Provider ID:

Service	DPC	RI	SSN	New TT	Replace GTA
CLASS	<input type="text"/>	None ▾	<input type="checkbox"/>	<input type="checkbox"/>	None ▾
LIDB	<input type="text"/>	None ▾	<input type="checkbox"/>	<input type="checkbox"/>	None ▾
ISVM	<input type="text"/>	None ▾	<input type="checkbox"/>	<input type="checkbox"/>	None ▾
CNAM	<input type="text"/>	None ▾	<input type="checkbox"/>	<input type="checkbox"/>	None ▾
WSMSC	<input type="text"/>	None ▾	<input type="checkbox"/>	<input type="checkbox"/>	None ▾

Process command even if connection to remote LSMS port not possible (use this option with care)

Fri April 12 2002 10:16:42 EDT

2001 © Tekelec, Inc., All Rights Reserved.

Enter the required information in the fields shown, and click the Update button.

NOTE: Do not check the ‘Process command even if connection to remote LSMS port not possible’ button unless you thoroughly understand the material in “Local Provisioning Utility” on page 3-48.

See Figure 3-89 for a list of sample responses from the Update Override GTT Records option screen.

Figure 3-89. Samples of Update Override GTT Record Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N]:
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N]:

Override GTT / Delete

The RTDB / Local Provisioning / Override GTT / Delete Override GTT Records screen lets you delete a specific LRN record using a 10-digit LRN number as a key. See Figure 3-90 for the Local Provisioning / Subscriptions / Delete Override GTT Records screen.

Figure 3-90. Delete Override GTT Record

Enter the specific Location Routing Number in the LRN field, and click the Delete button.

NOTE: Do not check the 'Process command even if connection to remote LSMS port not possible' button unless you thoroughly understand the material in "Local Provisioning Utility" on page 3-48.

See Figure 3-91 for a list of sample responses from the Delete Override GTT Record option screen.


Figure 3-91. Samples of Delete Override GTT Record Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N] :
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N] :

NPA NXX Split Menu

The RTDB / Local Provisioning / NPA NXX Split menu lets you update and delete a single Split NPA NXX record directly to the RTDB. See Figure 3-92 for the RTDB / Local Provisioning / Subscriptions / NPA NXX screen.

Figure 3-92. RTDB / Local Provisioning / NPA NXX Split Menu



The RTDB / Local Provisioning / NPA NXX Split menu provides these actions:

- “NPA NXX Split / Update” on page 3-58
- “NPA NXX Split / Delete” on page 3-59

NPA NXX Split / Update

The RTDB / Local Provisioning / NPA NXX Split / Update NPA NXX Split Records screen lets you update values for a single Split NPA NXX record using a 6-digit NPA NXX number as a key. See Figure 3-93 for the Local Provisioning / NPA NXX / Update NPA NXX Split Records screen.

Figure 3-93. Update NPA NXX Split Records

 A screenshot of a web form titled "Update NPA NXX Split Records". The form has a header "A" on the left and the title on the right. Below the title, there are two input fields: "Old NPANXX:" and "New NPANXX:". Below these fields is a checkbox with the text "Process command even if connection to remote LSMS port not possible (use this option with care)". At the bottom of the form is an "Update" button. A blue status bar at the bottom of the form displays "Mon November 12 2001 18:03:50 EST" and "2001 © Tekelec, Inc., All Rights Reserved."

Enter the required information in the fields shown, and click the Update button.

NOTE: Do not check the ‘Process command even if connection to remote LSMS port not possible’ button unless you thoroughly understand the material in “Local Provisioning Utility” on page 3-48.

See Figure 3-94 for a list of sample responses from the Update NPA NXX Split Records option screen.

Figure 3-94. Samples of Update NPA NXX Split Record Output

- Success - New NPA NXX: 910345
- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N] :
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N] :

NPA NXX Split / Delete

The RTDB / Local Provisioning / NPA NXX Split / Delete screen lets the user delete a single Split NPA NXX record using a 6-digit NPA NXX number as a key. See Figure 3-95 for the Local Provisioning / NPA NXX / Update screen.

Figure 3-95. Delete NPA NXX Split Record

Enter the single Split NPA NXX record using a 6-digit NPA NXX number in the Old or New NPANX field, and click the Update button.

NOTE: Do not check the 'Process command even if connection to remote LSMS port not possible' button unless you thoroughly understand the material in "Local Provisioning Utility" on page 3-48.

See Figure 3-96 for a list of sample responses from the Delete NPA NXX Split Records option screen.

Figure 3-96. Samples of Delete NPA NXX Split Record Output

- Connected to local LSMS port on X.X.X.X
- Connected to remote LSMS port on Y.Y.Y.Y
- Connected to LPU port on Z.Z.Z.Z
- Could not connect to LPU port. Do you wish to connect and try to send the command again? [N]:
- Could not connect to local LSMS port
- Could not connect to remote LSMS port. Do you wish to connect and try to send the command again? [N]:

Batch Mode

The RTDB / Local Provisioning / Batch Mode screen lets you upload an LPU batch file for local provisioning. See Figure 3-97 for the RTDB / Local Provisioning / Batch Mode screen.

Figure 3-97. RTDB / Local Provisioning / Batch Mode Screen




The RTDB / Local Provisioning / LPU Batch Mode screen lets you name an LPU file to be uploaded. Browse for and/or enter the filename, and click the Upload and Execute button to perform the action.

Debug Menu

The Debug Menu allows the user to view logs, list running processes, and access the EAGLE 5 ISS MMI port. See the Debug Menu in Figure 3-98.

Figure 3-98. Debug Menu




The Debug menu provides the following actions:

- “View Logs Menu” on page 3-61
- “Capture Log Files” on page 3-63
- “Manage Log Files” on page 3-64
- “View Any File” on page 3-65
- “List ELAP Software Processes” on page 3-65
- “Connect to EAGLE 5 ISS MMI Port” on page 3-67

View Logs Menu

The Debug / View Logs menu allows the user to view such logs as the Maintenance, RTDB, Provisioning, RTDB audit, and UI logs. See the View Logs menu in Figure 3-99.

Figure 3-99. View Logs Menu




The View Logs menu provides the following actions:

- “Maintenance Log” on page 3-62
- “RTDB, Provisioning, RTDB Audit, JRS, Transaction Log API, CGI and GS Logs” on page 3-62

Maintenance Log

When you click Debug / View Logs / Maintenance in Figure 3-99, you see the View Maintenance Log screen, shown in Figure 3-100. Press the Open View Window button to activate the View Window viewer and see the Maintenance Log.

Figure 3-100. View Maintenance Log Screen



Selecting the Maintenance Log in this window displays the requested log in the log viewer window. For details about using this utility, see “ELAP Log Viewer” on page 3-69.

RTDB, Provisioning, RTDB Audit, JRS, Transaction Log API, CGI and GS Logs


When you choose to view any of the Debug / View Logs files, the process is the same as for the Maintenance Log described previously. The selection you choose causes a screen similar to the View Maintenance Log screen in Figure 3-100. Press the Open View Window button to activate the View Window viewer for the log file you have selected in the View Logs menu.

Opening any log in this window displays the requested log in the log viewer window. All log files are viewed with the same file viewing utility. For details about this utility, see “ELAP Log Viewer” on page 3-69.

Capture Log Files


The Debug / Capture Log Files screen allows the user to make a copy of the logs for the current MPS. Optionally, you can capture files with the logs. See Figure 3-101 for the Capture Log Files screen.

Figure 3-101. Capture Log Files



When you click the Capture Logs button, the copy of the log files occurs, and a successful completion displays the message in Figure 3-102.


Figure 3-102. Example of Successfully Capturing Log Files



Manage Log Files

The Debug / Manage Log Files screen displays the captured log files and allows the user to delete the copies no longer wanted. See Figure 3-103 for the Manage Log Files screen.

Figure 3-103. Manage Log Files



In the Manage Log Files screen, you can remove a log file by clicking the appropriate file under the Selete column and then the Delete Selected File(s) button. A successful removal message appears in Figure 3-104.


Figure 3-104. Example of Successfully Deleting a Log File



View Any File

The Debug / View Any File screen allows the user to view any file on the system using the Log Viewer. When the user enters a file, the Log Viewer is invoked. See the View Any File screen in Figure 3-105.

Figure 3-105. View Any File Screen



Opening any file in this window displays the requested file in the file viewer window. All files are viewed with the same file viewing utility. For details about this utility, see “ELAP Log Viewer” on page 3-69.

List ELAP Software Processes

The Debug / List ELAP Software Processes screen shows the ELAP processes started when the ELAP boots or with the “Start ELAP software” prompt. The `/usr/ucb/ps -auxw` command generates this list. (The operating system's manual page for the `ps` command thoroughly defines the output for this command.) Figure 3-106 shows an example of the format of the process list.

Figure 3-106. View Any File Screen

The screenshot shows a window titled "List ELAP Software Processes" with a scrollable list of processes. The processes are grouped into several categories, each with a header line indicating the number of processes in that group. The data is presented in a table-like format with columns for USER, PID, %CPU, %MEM, SZ, RSS, TT, S, START, TIME, and COMMAND.


GROUP	USER	PID	%CPU	%MEM	SZ	RSS	TT	S	START	TIME	COMMAND
topnode (2 of 2)	elapdev	2169	0.0	2.7	5240	3192	?	S	14:59:54	0:01	/opt/TKLCelap/bin.
	elapdev	2171	0.0	2.7	5240	3224	?	S	14:59:54	0:02	/opt/TKLCelap/bin.
maint (1 of 1)	elapdev	2177	0.1	2.2	4440	2648	?	S	14:59:59	0:17	/opt/TKLCelap/bin.
provRMTMP (4 of 4)	elapdev	2239	0.0	2.4	4896	2912	?	S	15:00:03	0:01	/opt/TKLCelap/bin.
	elapdev	2245	0.0	2.4	4896	2904	?	S	15:00:03	0:00	/opt/TKLCelap/bin.
	elapdev	2256	0.0	2.4	4896	2904	?	S	15:00:03	0:01	/opt/TKLCelap/bin.
	elapdev	2262	0.0	2.4	4896	2912	?	S	15:00:04	0:01	/opt/TKLCelap/bin.
gs (1 of 1)	elapdev	2916	0.1	2.1	4728	2544	?	S	Nov 08	2:58	/opt/TKLCappl/bin.
rtdb (1 of 1)	elapdev	2201	0.0	48.637344859008	?	?	?	S	15:00:01	0:06	/opt/TKLCelap/bi:
provRcvr (4 of 4)	elapdev	2285	0.0	2.4	5400	2896	?	S	15:00:04	0:01	/opt/TKLCelap/bin.
	elapdev	2287	0.0	2.4	5400	2888	?	S	15:00:05	0:01	/opt/TKLCelap/bin.
	elapdev	2293	0.0	2.4	5400	2888	?	S	15:00:05	0:01	/opt/TKLCelap/bin.

When you have finished with this screen, you can click the Back button on the browser or select another menu item to perform.

Connect to EAGLE 5 ISS MMI Port

The Debug / Connect to EAGLE 5 ISS MMI Port screen lets the user interact with the EAGLE 5 ISS through the MMI port only from ELAP B. See the *Commands Manual* for a detailed listing of EAGLE 5 ISS commands and the input and output from the EAGLE 5 ISS MMI port. Figure 3-107 shows the Connect to MMI Port screen.

Figure 3-107. Connect to MMI Port Screen




Press the Start MMI Connection button, and the SSH User Authentication window appears. Enter the User name (elapdev) and password to connect. Figure 3-109 has an example of the SSH User Authentication screen.

Figure 3-108. SSH User Authentication Screen



After a successful login, a new window appears with the MMI connection. Refer to the *Commands Manual* for details about the `chg-trm` and `rtrv-trm` commands. Figure 3-109 has an example of the MMI window.

Figure 3-109. MMI Connection Window



The window starts a `ssh` session during which you can issue EAGLE 5 ISS commands. You can close the session by:

- Using the tilde character and the period (for example: `~.`) or
- Closing the window under the File menu, or
- Clicking on the X icon in the upper right corner of the window.

NOTE: Remember that the MMI port is on only ELAP B, and you can connect to the port only when you are on ELAP B. If you were to forget and attempt to perform this command from ELAP A, you see the error screen in Figure 3-110.


Figure 3-110. Error in Connecting to MMI Port from ELAP A



ELAP Log Viewer


Viewing any log file involves using the Log Viewer. Menu options using the log viewer first display a request screen in the workspace, shown in Figure 3-111.

Figure 3-111. Typical Log Viewer Request Screen



Invoke the log viewer by pressing the Open View Window button. This opens the SSH User Authentication window. A user name and Password word are required to login. Then the log viewer appears in its own window so you can continue using the user interface while viewing the selected file. See Figure 3-112 for a sample Log Viewer window.

Figure 3-112. Log Viewer Window Example




Use the commands in Table 3-1 to navigate through the file displayed by the log viewer:

Table 3-1. Log Viewer Navigation Commands

Command	Action
<return>	Scroll down 1 line
<space>	Scroll down 1 page
b	Scroll up 1 page
G	Go to bottom of file
/{ <i>pattern</i> }	Search for <i>pattern</i> from current position in file
n	Repeat search
q	Exit log viewer

When you have finished viewing a log file, close the Log Viewer window by clicking the Close View Window button, shown in Figure 3-113.


Figure 3-113. Closing the Log Viewer Window



Platform Menu

The Platform Menu allows the user to perform various platform-related functions, including running health checks, back ups, upgrades, shut downs, etc., shown in Figure 3-114.

Figure 3-114. Platform Menu



The Platform menu provides these actions:


- “Run Health Check Menu” on page 3-72
- “List All Running Processes” on page 3-74
- “View System Log” on page 3-75
- “Eject the CD” on page 3-76
- “Reboot the MPS” on page 3-77
- “Halt the MPS” on page 3-78
- “SSH to MPS” on page 3-80

Run Health Check Menu

The Platform / Run Health Check screen allows the user to execute the health check routine on the selected ELAP. The *Tekelec 1100 AS MPS Platform Software and Maintenance Manual* describes the health check (also called system health check and syscheck) in detail.

The first screen presented in the workspace frame lets the user select the “normal” or “verbose” mode of output detail. Figure 3-115 shows the Run Health Check screen that begins the execution of this diagnostic tool.

Figure 3-115. Run Health Check Screen



The ELAP system health check utility performs multiple tests of the server. For each test, check and balances verify the health of the MPS server and platform software. Refer to the *Tekelec 1100 AS MPS Platform Software and Maintenance Manual*, for the functions performed and how to interpret the results of the normal outputs (Figure 3-116) and verbose outputs (Figure 3-117).

Figure 3-116. Normal Health Check Output





Figure 3-117. Portion of Verbose Health Check Output



List All Running Processes

The Platform / List All Running Processes screen lists all processes running on the selected ELAP. The `/usr/ucb/ps -auxw` command generates this list. The operating system's manual page for the `ps` command thoroughly defines the output for this command. Figure 3-118 shows an example of the process list.

Figure 3-118. List All Running Processes Screen


USER	PID	%CPU	%MEM	SZ	RSS	TT	S	START	TIME	COMMAND
nobody	8574	4.5	5.2	6736	6336	?	S	10:00:54	0:00	/opt/TKLCplat/bin.
root	1	0.2	0.2	752	144	?	S	Nov 08	6:57	/etc/init -
root	8587	0.2	1.1	1528	1272	?	O	10:00:55	0:00	/usr/ucb/ps -auxw
nobody	1432	0.1	1.3	2704	1560	?	S	Nov 08	0:00	/opt/TKLCplat/apau
elapdev	2916	0.1	2.0	4904	2392	?	S	Nov 08	3:24	/opt/TKLCappl/bin.
root	3	0.1	0.0	0	0	?	S	Nov 08	4:32	fsflush
elapdev	4904	0.0	2.2	4432	2632	?	S	09:51:48	0:00	/opt/TKLCelap/bin.
root	0	0.0	0.0	0	0	?	T	Nov 08	0:01	sched
root	2	0.0	0.0	0	0	?	S	Nov 08	0:03	pageout
root	75	0.0	0.2	1264	144	?	S	Nov 08	0:00	/usr/lib/devfsadm.
root	77	0.0	0.0	2264	?	?	S	Nov 08	0:00	/usr/lib/devfsadm.
root	141	0.0	0.0	1800	?	?	S	Nov 08	0:00	/etc/opt/SUNWconn.
root	156	0.0	0.0	1744	?	?	S	Nov 08	0:00	/usr/sbin/aspppd
root	176	0.0	0.4	2152	504	?	S	Nov 08	0:00	/usr/sbin/rpcbind
root	178	0.0	0.8	2352	896	?	S	Nov 08	0:00	/usr/sbin/keyserv
root	208	0.0	0.0	1992	?	?	S	Nov 08	0:00	/usr/sbin/inetd -
daemon	210	0.0	0.9	2416	1072	?	S	Nov 08	0:00	/usr/lib/nfs/stat
root	211	0.0	0.0	1808	?	?	S	Nov 08	0:00	/usr/lib/nfs/lock
root	222	0.0	1.2	2480	1400	?	S	Nov 08	0:00	/usr/lib/autofs/a
root	234	0.0	1.2	2976	1464	?	S	Nov 08	0:00	/usr/sbin/syslogd
root	240	0.0	0.0	1784	?	?	S	Nov 08	0:00	/usr/sbin/cron

NOTE: The exact processes shown will not be the same on your ELAP servers. The output from this command is unique for each ELAP, depending on the ELAP software processes, the number of active ELAP user interface processes, and other operational conditions.

View System Log

The Platform / View System Log screen allows the user to display the System Log. Each time a system maintenance activity occurs, an entry is made in the System Log. When the user chooses this menu selection, the View the System Log screen appears, as shown in Figure 3-119.

Figure 3-119. View the System Log Screen



When the user clicks the Open View Window button, the system shows the System Log in the Log Viewer window. (The use of the Log Viewer is described “ELAP Log Viewer” on page 3-69.) See Figure 3-120 for an example of the System Log output.

Figure 3-120. View System Log Format Example

```
May 6 15:39:08 mate unix: WARNING: interrupt level 4 not serviced
May 7 10:13:00 mate unix: WARNING: interrupt level 4 not serviced
```

Eject the CD

The Platform / Eject the CD screen allows the user to eject the CD on the selected CD device on the selected ELAP server. Figure 3-121 shows the Eject CD screen.

Figure 3-121. Eject the CD Screen





Figure 3-122 shows an example of an error reporting that CD media is missing.


Figure 3-122. Eject CD Screen Error Message



Reboot the MPS


The Platform / Reboot the MPS screen allows the user to reboot the selected ELAP. All ELAP software processes running on the selected ELAP are shut down normally. Figure 3-123 shows the Reboot the MPS screen.

Figure 3-123. Reboot the MPS Screen




When you click the Reboot MPS button, a cautionary message appears, informing the user that this action causes ELAP to stop all activity and to prevent the RTDB from being updated with new subscriber data. See Figure 3-124.

Figure 3-124. Caution about Rebooting the MPS



When you are certain that you want to reboot, click the Continue button. Another screen informs you that MPS is being rebooted and that the User Interface will be reconnected when the reboot is completed, as shown in Figure 3-125.


Figure 3-125. Rebooting the MPS in Process



Halt the MPS


The Platform / Halt the MPS screen allows the user to halt the selected ELAP. All ELAP software processes running on the selected ELAP are shut down normally. Figure 3-126 shows the Halt the MPS screen.

Figure 3-126. Halt the MPS Screen




To perform this action, click the halt_MPS button. Next a cautionary message appears, informing the user that this action causes ELAP to stop all activity and to prevent the RTDB from being updated with new subscriber data. See Figure 3-127.

Figure 3-127. Caution about Halting the MPS



When you are certain that you want to halt the MPS, click the Continue button. Another screen informs you that MPS is being halted and that the process may require up to 50 seconds. See Figure 3-128.

Figure 3-128. Rebooting the MPS in Process



SSH to MPS


The Platform / SSH to MPS screen allows the user to have a `SSH` window to the user interface user. Clicking on the Connect button, shown in Figure 3-129, opens the SSH User Authentication window. A user name and Password word are required to login.

Figure 3-129. SSH to MPS Screen



Press the Connect button, and see the `SSH` window with which you can perform `SSH` communications, as shown in Figure 3-130.

Figure 3-130. Example of a SSH Window




User Administration Menu

The User Administration menu allows the user to perform various platform tasks, including administering users and groups, terminating active sessions, and modifying system defaults. The user interface allows for many users with multiple and varied configurations of permissions. It is designed for convenience and ease of use while supporting complex user set-ups where required.

See the User Administration menu in Figure 3-131.

Figure 3-131. User Administration Menu



When a user successfully logs into the UI, he is considered to have a session open. These rules apply to session management and security.

- **Idle Port Logout:** If no messages are exchanged with the UI client session for a configurable amount of time, the session is automatically closed on the server side. The default length of the timeout is a system-wide value, configurable by the administrator. The administrator can also set a different timeout length for an individual user, if desired.
- **Multiple Sessions per User:** The administrator can turn off multiple sessions allowed per user on a global system-wide basis.
- **Revoke/Restore User:** The administrator can revoke a userid. A revoked userid remains in the database but can no longer log in. Likewise, the administrator can restore a userid that was previously revoked.

- **Manage Unused UserIDs:** The ELAP UI automatically revokes userids that are not accessed within a specified number of days. The number of days is a system-wide value that is definable by the administrator.
- **Login Tracking:** When a user successfully logs in, the UI displays the time of the last successful login and the number of failed login attempts for that userid.
- **Intrusion Alert:** When the number of successive failed login attempts from a specific IP address reaches 5 (five), the ELAP automatically writes a message to the UI security log and displays a message on the banner applet to inform any administrator logged in at that time.
- **Revoke Failed User:** The UI automatically revokes any user who has N successive login failures within 24 hours. N is a system-wide configurable number, with a default of 3 (three). This restriction is turned off if N is set to 0 by the administrator.


The User Administration menu performs administration functions for users and groups, and handles terminating active sessions and modifying system defaults. See these topics discussed:

- “Users Menu” on page 3-82
- “Groups Menu” on page 3-96
- “Authorized IP Address Menu” on page 3-103
- “Terminate Active Sessions” on page 3-107
- “Modify System Defaults” on page 3-108

Users Menu

The User Administration / Users menu allows the system administrator to administer users functions such as add, modify, delete, retrieve, and reset user password. See the Users menu in Figure 3-132.

Figure 3-132. User Menu



ELAP Graphical User Interface

A user is someone who has been given permission with system administrator authority to log in to the user interface. The administrator creates these user accounts and associates them with the groups to which they belong. A user automatically has access to all actions allowed to the groups he is a member. In addition to the user's groups, the administrator can set other user-specific permissions or restrictions to any user's set of individual permissions.

The ELAP user interface comes pre-defined with user interface users in order to provide a seamless transition to the user interface. This is done by duplicating the Unix user logins and permissions that exist on the text-based UI. In addition, The default password for a new `uiadmin` is `uiadmin`. See Table 3-2 for login names.

Table 3-2. ELAP UI Logins

Login Name	Access Granted
elapmaint	Maintenance menu and all submenus
elapdatabase	Database menu and all submenus
elapdebug	Debug menu and all submenus
elapplatform	Platform menu and all submenus
uiadmin	User Administration menu
elapall	All of the above menus
elapconfig	Configuration menu and all submenus (text-based UI)

The Users menu performs the following actions:

- “Add User” on page 3-84
- “Modify User” on page 3-85
- “Delete User” on page 3-91
- “Retrieve User” on page 3-92
- “Reset User Password” on page 3-95

Add User

The User Administration / Users / Add User screen lets you add a new user interface user name and a default password. Figure 3-133 shows the Add UI User screen.

Figure 3-133. Add User Screen


See Figure 3-134 for the screen confirmation of the newly added user.

Figure 3-134. Success in Adding UI User

Modify User

The User Administration / Users / Modify User screen lets you change a user permission profile. The administrator must first select a user name from the list of current users, as shown in Figure 3-135.

Figure 3-135. Select a User for Modification Screen



After you select a User Name in the screen above, the screen to specify the user permissions appears, as shown in Figure 3-136. In that screen, you can view and specify the permissions allowed to the user.

You can directly specify the number of concurrent log-ins, an inactivity time limit, and a password age limit. In addition, you can modify group membership data and specific actions that the user is permitted. See Figure 3-136 to see how to specify user modifications.

Figure 3-136. Specify the Modify UI User Screen

The screenshot shows a web browser window titled "Modify UI User". The page content includes the following fields and options:

- User Name: ric-test
- User ID: 7
- Administrator:
- Debug User:
- Reset Password:
- User Revoked:
- Maximum Concurrent Logins: System Default (1) Infinite User Specific
- Session Inactivity Limit: System Default (10) Infinite User Specific in minutes
- Maximum Password Age: System Default (Infinite) Infinite User Specific in days

At the bottom of the form area, there are three buttons: "Submit Profile Changes", "Modify Group Membership", and "Modify Specific Actions". The status bar at the bottom of the browser window shows the date and time: "Tue October 23 2001 13:36:06 EDT".

When you modify any of the direct entries, such as concurrent logins or inactivity, and click the Submit Profile Changes, you see the screen confirming the changes, as in Figure 3-137.

Figure 3-137. Confirming Modify UI User Profile Changes

The screenshot shows the "Modify UI User" screen after a successful update. It features two message boxes:

- A yellow warning triangle icon followed by the text: "CAUTION: Changes to user profile will not affect current user sessions."
- A green checkmark icon followed by the text: "SUCCESS: All modified groups were successfully changed."

The status bar at the bottom of the browser window shows the date and time: "Tue February 05 2002 14:36:34 EST". Below the status bar, the copyright notice "2001 © Tekelec, Inc., All Rights Reserved." is visible.

When you click Modify Group Membership in Figure 3-136, the screen displays the group membership choices available for the user. See Figure 3-138.

Figure 3-138. Modify UI User's Group Membership

The screenshot shows a web interface titled "Modify UI User" with a sub-header "User ric-test Groups". Below this, there is a table of group membership options. Each option consists of a text label, a checkbox, and a corresponding label. The groups listed are: maint (checked), debug (checked), readonly (checked), database (checked), pdba (unchecked), platform (checked), and admin (checked). Below the table is a button labeled "Submit Group Membership Changes". At the bottom of the page, there is a blue status bar with the text "Tue October 23 2001 13:48:07 EDT" and "2001 © Tekelec, Inc., All Rights Reserved."

User ric-test Groups		
maint	<input checked="" type="checkbox"/>	
debug	<input checked="" type="checkbox"/>	
readonly	<input checked="" type="checkbox"/>	
database	<input checked="" type="checkbox"/>	
pdba	<input type="checkbox"/>	
platform	<input checked="" type="checkbox"/>	
admin	<input checked="" type="checkbox"/>	

Submit Group Membership Changes

Tue October 23 2001 13:48:07 EDT
2001 © Tekelec, Inc., All Rights Reserved.

When you submit the changes for group membership, Figure 3-139 illustrates the confirmation screen.

Figure 3-139. Confirming Modify UI User Group Membership Changes


The screenshot shows the same "Modify UI User" interface, but now with a success message. A green checkmark icon is followed by the text "SUCCESS: All modified groups were successfully changed." Below this message is a blue status bar with the text "Tue November 13 2001 12:10:27 EST" and "2001 © Tekelec, Inc., All Rights Reserved."

✓ SUCCESS: All modified groups were successfully changed.

Tue November 13 2001 12:10:27 EST
2001 © Tekelec, Inc., All Rights Reserved.


When you click Modify Specific Actions in Figure 3-136, the screen displays Action Privileges you can specify for the user you are modifying. See Figure 3-140.

Figure 3-140. Modify UI User’s Specific Actions



This screen contains many selections from which to choose. Figure 3-141 shows the continuation of the screen and the Submit button to press when you are done.

Figure 3-141. Continuing Modify UI User’s Specific Actions




The bottom of the Modify UI User’s Special Actions screen contains these explanatory notes:

- ^A - Permission for this action has been explicitly added for this user.
- ^R - Permission for this action has been explicitly removed for this user.

These notes indicate the privileges specifically added or removed for an individual user from the groups to which he/she is a member. This allows discrete refinement of user privileges even though he/she may be a member of groups.

When you submit the changes for specific actions, Figure 3-142 shows the system accepting your change in action privileges for the specified user.


Figure 3-142. Confirming Modify UI User Specific Actions Changes



Delete User


The User Administration / Users / Delete User screen lets an administrator remove a user name from the list of user interface names. First you select the user name to be deleted and click the Delete User button, shown in Figure 3-143.

Figure 3-143. Delete UI User Screen




Next a confirmation screen appears, as shown in Figure 3-144.

Figure 3-144. Requesting Confirmation of User Deletion



Finally, the screen shows the user has been successfully removed, as shown in Figure 3-145.


Figure 3-145. Confirming Deletion of the User



Retrieve User

The User Administration / Users / Retrieve User screen lets you display the user name permission profiles from the user interface information. First select a user name to be retrieved, and click the Select User button, as shown in Figure 3-146.

Figure 3-146. Select a User to Retrieve Screen



ELAP Graphical User Interface

After you select a User Name in the screen above, the screen to view the user permissions appears, as shown in Figure 3-147. There you can view the permissions allowed to this user.

You can directly see certain information such as the maximum allowed number of concurrent log-ins and the inactivity time limit. In addition, you can go on to view the user's group membership data and specific actions (privileges). Figure 3-147 shows the user's permissions and privileges.

Figure 3-147. Retrieval of UI User Information Screen

The screenshot shows a web interface titled "Retrieve UI User". It displays the following information:

User Name:	elapall	User ID:	7
Administrator:	No		
Reset Password:	No	User Revoked:	No
Maximum Concurrent Logins:	System Default (99)		
Session Inactivity Limit:	System Default (Infinite)		
Maximum Password Age:	System Default (Infinite)		

Below the table are two buttons: "View Group Membership" and "View Specific Actions". At the bottom, there is a blue status bar with the text "Tue September 27 2005 18:35:11 EDT" and "2003 © Tekelec, Inc., All Rights Reserved."

After you examine this screen, you can also continue to view the group membership by clicking the View Group Membership button. You see the user's memberships in Figure 3-148.

Figure 3-148. Viewing the User's Group Membership Screen

The screenshot shows a web interface titled "Retrieve UI User". It displays the following information:


User **ric-test** Groups

maint	database	platform	pdba	admin
readonly				

At the bottom, there is a blue status bar with the text "Wed October 24 2001 10:37:18 EDT" and "2001 © Tekelec, Inc., All Rights Reserved."

When you click the View Specific Actions in the Retrieve UI User screen in Figure 3-147, you see the user privileges shown in Figure 3-149. This screen contains many privileges to display. Figure 3-150 shows the continuation of the screen.

Figure 3-149. Viewing User Privileges




The bottom of Figure 3-150 also can also have explanatory notes:

- **A** - Permission for this action has been explicitly added for this user.
- **R** - Permission for this action has been explicitly removed for this user.

These notes indicate the privileges specifically added or removed for an individual user from the group to which he/she is a member. These permissions allow individual variations to user privileges even though the user is a member of a group. See Figure 3-150.


Figure 3-150. Continue Viewing User Privileges



Reset User Password


The User Administration / Users / Reset User Password screen lets you select a user name and change the password. See Figure 3-151.

Figure 3-151. Reset User Password Screen



Next, a confirmation screen appears when you correctly update the user's password, shown in Figure 3-152.

Figure 3-152. Confirming the Reset User Password



Groups Menu

The User Administration / Groups menu allows the user to administer action groups functions such as add, modify, delete, and retrieve. See the Groups menu in Figure 3-153.

Figure 3-153. User Administration / Groups Menu



For your convenience, actions can be grouped together. These groups can be used when assigning permissions to users. The groups can consist of whatever combinations of actions that system administrators deem reasonable. Group permissions allow any given action to be employed by more than one group.

Groups can be added, modified, deleted, and viewed through the menu items in the User Administration / Groups menu.

NOTE: The ELAP User Interface concept of groups should not be confused with the Unix concept of groups. The two are not related.

ELAP Graphical User Interface

The ELAP user interface comes with pre-defined groups with the same names and action permissions used in the text-based (ELAP version 1.0) user interface:

- `maint`
- `database`
- `platform`
- `debug`
- `admin`

One additional pre-defined group used is new to ELAP version 3.0. This group is called `readonly`. The `readonly` group contains only actions that view status and information. The `readonly` group is the default group for new users.


The Groups menu performs the following actions:

- “Add Group” on page 3-97
- “Modify Group” on page 3-98
- “Delete Group” on page 3-100
- “Retrieve Group” on page 3-102

Add Group

The User Administration / Groups / Add Group screen lets you enter a new user interface group and assign action privileges with the new group. See Figure 3-154 for the Add UI Group screen.

Figure 3-154. Add UI Group Screen



The screenshot shows a web-based form titled "Add UI Group". At the top left is a large letter "A". Below the title, a message states: "This screen will create a new group. The resulting group will initially contain no actions." There is a text input field labeled "Group Name:" containing the text "rictest-group". Below the input field is a "Submit Group" button. At the bottom of the screen, a blue status bar displays the date and time: "Wed October 24 2001 14:39:48 EDT". Below the status bar, the copyright notice "2001 © Tekelec, Inc., All Rights Reserved." is visible.

Figure 3-155 shows the screen confirmation of the newly added user interface group.

Figure 3-155. Confirming a New Group




When you receive the successful group added message, you should proceed to the “Modify Group” on page 3-98 and assign the Action Privileges for the new group.

Modify Group

The User Administration / Group / Modify Group screen lets you administer user interface group permission profiles. Select the Group Name, and click the Select Group button. Figure 3-156 shows a sample Modify UI Group screen.

Figure 3-156. Modify UI Group Screen



When you have selected the group, the Modify Group Permission Profiles screen shows the current action privileges assigned to the user interface group. See Figure 3-157 and Figure 3-158 for the beginning and end of the Action Privileges.

Figure 3-157. Viewing a Group for Modification





Figure 3-158. Continuing to View a Group for Modification



When you specify the Action Privileges you want to assign to this user interface group and click the Submit Specific Action Changes, you see the screen confirming the changes, as in Figure 3-159.


Figure 3-159. Confirming Modify UI Group Action Privileges



Delete Group


The User Administration / Group / Delete UI Group screen lets you remove a user interface group from the user interface information. The administrator must first select the user interface group name for deletion, as shown in Figure 3-160.

Figure 3-160. Select a Group for Deletion Screen



When you click the Select Group button, a confirmation banner and button appear, as shown in Figure 3-161.

Figure 3-161. Confirming the Delete Group



Finally, select the Confirm Delete Group button to delete the user interface group name and its permissions. See Figure 3-162.


Figure 3-162. Success in Delete UI Group



Retrieve Group


The User Administration / Users / Retrieve Group screen lets you display the permission profiles for user interface groups from the user interface information. First select a user interface group name to be retrieved, and click the Select Group button, as shown in Figure 3-163.

Figure 3-163. Retrieve UI Group Screen



After you select a Group Name in the screen above, the screen to view the group permissions appears, as shown in Figure 3-164. There you can view the permissions allowed to this user interface group. All you see is the actions supported for the group, as illustrated in Figure 3-164.


Figure 3-164. Retrieval of UI User Information Screen



Authorized IP Address Menu

The User Administration / Authorized IP menu lets you add, remove, and list all authorized UI IP addresses and also change the UI IP address authorization status. Figure 3-165 shows the Authorized IP menu.

Figure 3-165. Authorized IP Address Menu




The PDBA / Authorized IP menu provides these actions:

- “Add Authorized UI IP Address Screen” on page 3-103
- “Remove Authorized UI IP Address Screen” on page 3-104
- “List All Authorized UI IP Addresses” on page 3-105
- “Change UI IP Authorization Status” on page 3-106

Add Authorized UI IP Address Screen

The User Administration / Authorized IP / Add Authorized UI IP screen lets you add a new IP address to the list of authorized IP addresses. Note that a pop-up syntax box appears when the cursor is positioned over the input field. See Figure 3-166 for the Add Authorized UI IP screen.

Figure 3-166. Add Authorized UI IP Screen



Enter the IP address you want authorized and press the Allow IP button. When an authorized IP address is accepted, you see the message indicating a successful acceptance of the address in Figure 3-167.

Figure 3-167. Successfully Adding an Authorized UI IP Address



An error notification screen appears when a duplicate IP address is entered (the address already exists), when an attempt to add more than the maximum allowable number of addresses (i.e., more than 1,000), or when any internal failure is detected.

Remove Authorized UI IP Address Screen

The User Administration / Authorized IP / Remove Authorized UI IP screen lets you remove an IP address from the list of authorized IP addresses. You must enter the individual IP address or Classless Interdomain Routing Format (CIDR) IP format in the 'IP to Remove' input field. A pop-up syntax box appears when the cursor is positioned over that input field. See Figure 3-168 for an example of the Remove Authorized UI IP screen.

Figure 3-168. Remove Authorized UI IP Screen



When the authorized IP address is deleted, you see the message confirming the removal of the specified address, as shown in Figure 3-169.


Figure 3-169. Successfully Removing an Authorized UI IP Address



List All Authorized UI IP Addresses

The User Administration / Authorized IP / List All Authorized UI IPs screen retrieves and displays all authorized IP addresses. The screen also shows whether the authorization list is Enabled or Disabled. See Figure 3-170 for an example of the List All Authorized UI IP address screen.

Figure 3-170. List All Authorized UI IP Addresses Screen




For information about enabling and disabling the authorization list, see “Change UI IP Authorization Status” on page 3-106.

Change UI IP Authorization Status

The User Administration / Authorized IP / Change UI IP Authorization Status screen permits toggling (that is, alternating) the state of authorization list between 'enabled' and 'not enabled.'


When this menu option is chosen, the current authorization state is displayed in the INFO field. See Figure 3-171 for an example of the Change UI IP Authorization Status screen.

Figure 3-171. Change UI IP Authorization Status Screen



In the example above, the figure shows the authorization state is 'NOT Enabled.' To toggle the state to Enabled, click the Enable IP Checking button. See Figure 3-172 for an example of the authorization status having been successfully toggled to the opposite state, now 'Enabled.'

Figure 3-172. Toggling the UI IP Authorization Status




The enforcement of the checking for authorization status is immediate. The IP address of every message of every IP device using the GUI is checked as soon as the authorization status is enabled. The checking for authorized IPs does not occur only when devices log in.

Terminate Active Sessions

The User Administration / Terminate Active Sessions screen allows the administrator to selectively terminate individual active user interface sessions. See the Terminate Active Sessions screen in Figure 3-173.

Figure 3-173. Terminate Active Sessions Screen



The administrator selects a user interface session for termination, by clicking a Session in its **Delete?** column. A successful termination is shown in Figure 3-174.

Figure 3-174. Confirmation of Session Termination



Modify System Defaults

The User Administration / Modify System Defaults screen allows the administrator to manage the systems defaults from this screen. See the start of the Modify System Defaults screen in Figure 3-175.

Figure 3-175. Modify System Defaults Screen

A Modify System Defaults

Enforce password complexity checking:

When password complexity checking is turned on, all new passwords must adhere to several complexity rules before they are accepted. When checking is turned off, all new passwords are accepted.

Maximum Failed User Logins:

This field represents the number of consecutive failed logins for a specific user before that user's account is revoked.

Password Reuse Limit:

This field represents the number of passwords for user that must be used before a previous password is allowed to be reused.

The system defaults that you can modify are the following.

- **Enforce password complexity checking**: When password complexity checking is enforced, all new passwords must adhere to several complexity rules before they are accepted. When checking is not enforced, all new passwords are accepted.
- **Maximum Failed User Logins**: This field specifies the number of consecutive failed logins allowed for a specific user before that user's account is revoked.
- **Password Reuse Limit**: This field requires a specified number of unique passwords that a user must use before accepting a previous password.
- **Maximum Account Inactivity**: This field specifies the maximum number of days that a user account can be idle before the account is automatically revoked.
- **Session Idle Timeout**: This field limits the number of minutes that an open session can remain idle before the server automatically closes the session.
- **Maximum Password Age**: This field limits the number of days that a user can have the same password before requiring him/her to change it.


ELAP Graphical User Interface

- Maximum Concurrent User Logins: This field limits the number of concurrent login sessions that each user can have. This limitation does not apply to users with Administrative privileges.
- Maximum Concurrent Logins: This field limits the number of concurrent login sessions that can exist on the ELAP pair. Users with Administrative privileges are excluded from this total session count.
- Login Message Text: This field contains the text message displayed in the initial work area at login. The field is limited to 255 characters. The default text is:

`NOTICE: This is a private computer system. Unauthorized access or use may lead to prosecution.`
- New User Default Groups: This field contains a list of group names (comma-delimited) with which newly created users are automatically assigned. The default group name is `readonly`.

When you complete the changes to the Modify System Defaults, click the Submit Defaults button. A successful change is shown in Figure 3-176. This screen confirms your changes.

Figure 3-176. Confirming Modify System Defaults Screen




Change Password

The Change Password menu selection provides you, the ELAP user, with a screen to change your password. This basic action is available to all users and is accessible from the main menu (Figure 3-11, on page 3-12).

To change the password, you must enter the current password, enter the new password, and retype the new password. Click the Set Password button, as shown in Figure 3-177.

Figure 3-177. Change Password Screen



With the ability to support many users comes the need for tighter security. The user interface addresses security concerns with various restrictions and controls. In many cases, the frequency or severity of these checks is configurable by the administrator at both a user specific and system-wide level.

Users are required to use a password to log in to the UI. The following rules govern passwords.

- **Complexity:** Tekelec recommends that the password consist of at least five alphanumeric characters. It must include at least one alphabetic, one numeric, and one special (that is, punctuation) character. The password can contain a maximum of eight characters. It cannot include the `userid`.
Note: The default value for this password complexity rule is not required.
- **Aging:** Users can be forced to change their passwords after a certain number of days. The administrator can set a maximum password age as a default for the system. The administrator can also specify a different maximum password age for any individual user, if that is desired.
- **Force Change on Initial Login:** Users can be forced to change their password the first time that they log in. The administrator can assign a password to a user, either when the user is first created or when the password of an existing user is reset, and the user must change the password the first time that he/she logs in.

ELAP Graphical User Interface


- **Password Reuse:** Users cannot reuse their last N passwords. N is a system-wide configurable number, with the default of 5 (five). The administrator can turn off this restriction by setting N to 0 (zero).

Logout

The Logout menu selection allows you to confirm logging out of the current session. This basic action is available to all users and is accessible from the main menu (Figure 3-11, on page 3-12).

To logout, you are notified by the screen that this terminates your current session, and gives you the opportunity to continue or not. Click the Continue button to complete the logout, shown in Figure 3-178.

Figure 3-178. Logout Screen



When you have continued with the logout, the screen returns to the screen showing the Tekelec ELAP UI Login screen (see Figure 3-2, on page 3-4).

ELAP Messages

ELAP Error Messages

Table 3-3 lists all of the possible error codes and associated text that the ELAP user interface can generate. The <> fields indicate values that are different for each error; they are filled in at run time.

Table 3-3. ELAP Error Messages

E1000	Unknown error <error number>. No error text is available.
E1001	Invalid menu selection: <menu selection>
E1002	Invalid syntax: <input>
E1003	Mate ELAPs may not have the same designation.
E1004	ELAP software is running. You must stop the ELAP software before performing this operation.
E1005	ELAP software is not running. You must start the ELAP software before performing this operation.
E1006	Mate ELAP not available
E1007	Could not eject media: <device>
E1008	Could not read file: <file name>
E1009	Active PDBA is not available.
E1010	This host is not an ELAP.
E1011	Cannot find ELAP <A/B> (host name <host name>)
E1012	Subscription (SP= <subscription number>) does not exist.
E1013	Subscription (SP= <subscription number>) already exists.
E1014	SP <identifier> does not exist.
E1015	IMSI <identifier> does not exist.
E1016	DN <identifier> does not exist.
E1017	PDBI error: <error text>
E1018	DN <identifier> already associated with IMSI <identifier>.
E1019	Device <device> unavailable.
E1020	Remote PDB unavailable.
E1021	IP address <address> is not authorized for PDB access.
E1022	RN <identifier> does not exist.
E1023	Invalid value for <prompt >: <value>. Valid values are <range>. Hit the Escape key to abort the command.
E1024	MTSU error: <error text>
E1025	File lock failed: <file name>

Table 3-3. ELAP Error Messages (Continued)

E1026	Environment variable <variable name> not defined.
E1027	ssh error: <error text>
E1028	IP address <IP address> is already authorized for PDBI access.
E1029	IP address <IP address> is not authorized for PDBI access.
E1030	Operation timed out waiting for a response from the PDBA.
E1031	Operation timed out waiting for a response from the RTDB.
E1032	Operation aborted by user.
E1033	Unexpected response received from the PDBA: id=<txid>, return code=<return code>
E1034	Unexpected response received from the RTDB: id=<txid>, return code=<return code>
E1035	Script <script name> failed: status=<status>
E1036	ELAP configuration failed. Please use the configuration menu to manually configure the ELAP sync and DSM networks.
E1037	One or more ELAP software processes did not start
E1038	One or more ELAP software processes did not stop
E1039	Transaction log query failed: <error text>
E1040	Transaction log response file was not created.
E1041	Transaction log response file could not be parsed.
E1042	Transaction log export failed: <error text>
E1043	The specified ELAP was not available.
E1044	Remote ELAP software is running. You must stop the remote ELAP software before performing this operation.
E1045	RTDB copy operation failed.
E1046	Improperly encoded alarm string. Re-check source.
E1047	RTDB did not respond to query.
E1048	Invalid response received from RTDB.
E1049	Could not connect to <device or process>: <error text>
E1050	Secure shell daemon is not running on mate ELAP. Config files could not be synchronized !!!
E1051	No feature(s) specified.
E1052	Both ELAP and EPAP features specified.
E1053	This action may only be performed on the local ELAP.
E1054	Another user is currently performing this same action.
E1055	Missing mandatory parameter: <parameter>
E1056	Unexpected parameter was provided: <parameter>

Table 3-3. ELAP Error Messages (Continued)

E1057	The ELAP must be in Forced Standby mode for this operation.
E1058	An internal error in the <i><parameter></i> occurred: <i><error text></i>
E1059	The passwords did not match.
E1060	The provisioning addresses for MPS A and B must be different.
E1061	The provisioning addresses for MPS A and B must be on the same network.
E1062	The default router must be on the same network as MPS A and MPS B.
E1063	The local and remote PDB addresses must be different.
E1064	This action may only be performed on ELAP A.
E1065	<i><device or process></i> must be configured.
E1066	The requested user <i><user></i> was not found.
E1067	The requested group <i><group></i> was not found.
E1068	The password entered was not correct.
E1069	The new password has been used too recently.
E1070	The provided password does not meet the security requirements. Reason: <i><reason text></i>
E1071	The specified group already exists.
E1072	This action may only be performed on ELAP B.
E1073	The file you have attempted to upload is larger than the <i><number></i> bytes of allocated storage space.
E1074	LPU batch failure: <i><error text></i>
E1075	This action must be done on the Active PDBA.
E1076	This action may only be performed while the LSMS connection is disabled.
E1077	File system violation: <i><error text></i>
E1078	File ' <i><file name></i> ' was empty
E1079	There are no PDBI connections available. Try again later.
E1080	The provisioning addresses for the main and backup networks must be different.
E1081	The specified IP already exists.
E1082	The specified IP does not exist.
E1083	The maximum number of authorized UI IPs has been reached.
E1084	This action may only performed on a provisionable MPS.
E1085	The specified address is local to this MPS.

ELAP Banner Information Messages

Table 3-4 lists the banner information messages that appear on the UI browser screen in the Message Box described on page 3-8. These messages, sometimes referred to as ‘scroll by’ messages, indicate the status of the ELAP machines.

Table 3-4. ELAP Informational Banner Messages

Attempt to correct MySQL replication failed
Backup Filesystem Failed
Backup filesystem in progress
Backup filesystem successful
Backup filesystem was aborted manually
Backup RTDB completed successfully
Backup RTDB failed
Backup RTDB in progress
Failure within filesystem backup utility. View backup_fs.fail log.
JRS Simplex Mode Enabled
MPS Reboot in Progress
MPS Resynchronization in Progress
MySQL Data replication error detected; Attempting to restore
MySQL Data replication restored: <reason>
MySQL Data Replication from <source> is Failing
Reload RTDB from <source> completed successfully
Reload RTDB from <source> failed
Reload RTDB from <source> in progress
Restore RTDB completed successfully
Restore RTDB failed
Restore RTDB in progress
Transaction log export failed: <reason>
Transaction log export in progress
Transaction log successfully exported to file: <file>

Table 3-5 lists the alarm related banner information messages that appear on the UI browser screen in the Message Box described on page 3-8. If any of the following alarm related messages appear, refer to the *Tekelec 1100 AS MPS Platform Software and Maintenance Manual* for the related corrective procedure.

Table 3-5. ELAP Alarm Related Banner Messages

Uncorrectable ECC Memory Error
LSMS DB Maintenance Required
Server Fan Failure
Server Internal Disk Error
Server RAID Disk Error
Server Platform Error
Server File System Error
Server Platform Process Error
Server RAM Shortage Failure
Server Swap Space Shortage Failure
Server Provisioning Network Error
Server Eagle Network A Error
Server Eagle Network B Error
Server Sync Network Error
Server Disk Space Shortage Error
Server Default Route Network Error
Server Temperature Error
Server Mainboard Voltage Error
Server Power Feed Unavailable
Server Disk Health Test Error
Server Disk Unavailable Error
Correctable ECC Memory Error
Server Power Supply 1 Error
Server Power Supply 2 Error
Breaker Panel Feed Error
Breaker Panel Breaker Error
Breaker Panel Monitoring Error
Mate ELAP Unavailable
RTDB Mate Unavailable
Congestion

Table 3-5. ELAP Alarm Related Banner Messages (Continued)

File System Full
Log Failure
RMTP Channels Down
Fatal Software Error
RTDB Corrupt
RTDB Inconsistent
RTDB Incoherent
JRS to RTDB Connection Down
Transaction Log Full
RTDB 100% Full
RTDB Resynchronization in Progress
RTDB Reload Is Required
Mate PDBA Unreachable
PDBA Connection Failure
PDBA Replication Failure
RTDB DMS Over-Allocation
RTDB Maximum Depth Reached
Server Disk Space Shortage Warning
Server Application Process Error
Server Hardware Configuration Error
Server RAM Shortage Warning
Server Software Configuration Error
Server Swap Space Shortage Warning
Server Default Router Not Defined
Server Temperature Warning
Server Core File Detected
Server NTP Daemon Not Synchronized
Server CMOS Battery Voltage Low
Server Disk Self Test Warning
Server Reboot Watchdog Initiated
RMTP Channel A Down
RMTP Channel B Down
RTDB 80% Full
Standby PDBA Falling Behind

Table 3-5. ELAP Alarm Related Banner Messages (Continued)

RTDB Tree Error

4

Messages, Alarms, and Status Reporting

MPS and ELAP Status and Alarm Reporting.....	4-2
Maintenance Blocks	4-2
Alarm Priorities	4-3
Multiple Alarm Conditions	4-4
DSM Status Requests.....	4-4
System Hardware Verification.....	4-5
DSM Motherboard Verification.....	4-6
DSM Daughter board Memory Validation.....	4-6
Actions Taken When Hardware Determined to be Invalid	4-7
DSM Memory Capacity Status Reporting.....	4-7
Unstable Loading Mode.....	4-7
Commands.....	4-9
rept-stat-db.....	4-9
rept-stat-mps.....	4-10
rept-stat-trbl	4-12
rept-stat-alm.....	4-13
Unsolicited Alarm Messages and Unsolicited Information Messages ..	4-14
MPS Platform and ELAP Application Alarms	4-14
ELAP-to-DSM Connection Status.....	4-16

Feature Key Capacity UAMs.....	4-18
Physical Memory Usage UAMs.....	4-20
Measurement Capacity UIMs.....	4-21

MPS and ELAP Status and Alarm Reporting

The System Health Check (syscheck) utility runs automatically at least every five minutes, and can be run manually, to test for error conditions in each MPS Server and in each ELAP. See “Run Health Check Menu” on page 3-72 and refer to the *Tekelec 1100 AS MPS Platform Software and Maintenance Manual* for more information about executing and viewing results from the System Health Check.

Alarms of minor, major, and critical levels of severity are reported for error conditions detected for the MPS hardware platform and for the ELAP application.

On the MPS, a critical alarm lights the Fault LED, a major alarm lights the Alarm 1 LED, and a minor alarm lights the Alarm 2 LED. If more than one alarm level is active, all applicable LED lights are illuminated (not just the most severe) until all alarms in that level are cleared.

Maintenance Blocks

MPS and ELAP have no direct means of accepting user input from or displaying output messages on EAGLE 5 ISS terminals. Maintenance, measurements, error, and status information are routed to the EAGLE 5 ISS through the primary DSM.

The Active ELAP generates and sends Maintenance Blocks to the primary DSM. One Maintenance Block is sent as soon as the IP link is established between the Active ELAP and the primary DSM. Additional Maintenance Blocks are sent whenever the ELAP needs to report any change in status or error conditions. The information returned in Maintenance Blocks is also included in the output of the `rept-stat-mps` command.

It is possible for the ELAP to be at a provisioning congestion threshold, and to be entering and exiting congested mode at a very high rate of speed. To minimize this “thrashing” effect, the ELAP is restricted to sending no more than one ELAP Maintenance Block per second.

ELAP Maintenance Block Contents

The ELAP sends Maintenance Blocks that contain (at a minimum) the following information. The actual states are defined in the description of the `rept-stat-mps` command in the *Commands Manual*.

- MPS major, minor, and dot software versions
- MPS Status (down/up)

Messages, Alarms, and Status Reporting

- MPS Status (Active/Standby)

If the ELAP needs to report one or more alarm conditions, it inserts the appropriate alarm data string for the indicated alarm category into the Maintenance Block.

EAGLE 5 ISS Alarm Reporting

A 16-character hexadecimal alarm data string reports any errors found during the last System Health Check and the level of severity for each error. The first character (four bits) uniquely identifies the alarm severity for the alarm data. The remaining 15 characters (60 bits) uniquely identify up to 60 individual failure cases for the alarm category.

The System Health Check (syscheck) is responsible for forwarding platform errors to the application. The application combines the platform alarms with the application alarms and forwards all of this information to EAGLE 5 ISS. The information that is transferred is described in the *Tekelec 1100 AS MPS Platform Software and Maintenance Manual*.

Table 4-1 defines the application and platform alarms that are forwarded to the EAGLE 5 ISS. The EAGLE 5 ISS receives the alarm number, alarm text, and alarm data string recovered from the MPS/ELAP.

Table 4-1. EAGLE 5 ISS MPS Application and Platforms UAM Alarms

Alarm Number	Level	Device	Error Description
370	Critical	MPS A or B	Critical Platform Failure
371	Critical	MPS A or B	Critical Application Failure
372	Major	MPS A or B	Major Platform Failure
373	Major	MPS A or B	Major Application Failure
374	Minor	MPS A or B	Minor Platform Failure
375	Minor	MPS A or B	Minor Application Failure
250	Clearing	MPS A or B	MPS Available

Alarm Priorities

The ELAP sends the maintenance information, including the alarm data strings, to the EAGLE 5 ISS for interpretation. Alarm priorities determine which alarm category is displayed at the EAGLE 5 ISS terminal when multiple alarm levels exist simultaneously. EAGLE 5 ISS prioritizes the data and displays only the alarm category with the highest severity level and priority for each MPS.

If an alarm category of lower priority is sent from the MPS, the lower priority alarm category is not displayed on the EAGLE 5 ISS terminal until any higher priority alarms are cleared.

Multiple Alarm Conditions

Critical, major and minor alarms appear repeatedly in each alarm delivery to the EAGLE 5 ISS until the alarm condition clears.

If multiple alarms exist, the highest priority alarm category is the Active Alarm. The Active Alarm is shown in the output from the `rept-stat-trbl` command and the `rept-stat-mps` command, and the alarm count associated with this alarm is included in the `rept-stat-alm` command output.

Though only the highest priority alarm is displayed at the EAGLE 5 ISS terminal when multiple alarms are reported, you can use the EAGLE 5 ISS `rept-stat-mps` command to list the alarm data strings for all of the alarm categories with existing alarms. Then you can use the ELAP user interface maintenance menu item Decode EAGLE 5 ISS Output of MPS Alarms to convert the hexadecimal alarm data string to text. The output text shows the alarm category represented by the string and the alarm text for each alarm encoded in the string.

DSM Status Requests

When the ELAP needs to know the status of a DSM, it can send a DSM Status Request to that DSM. Because status messages are sent over UDP, the ELAP broadcasts the DSM Status Request and all DSMs return their status.

DSM Status Reporting to the ELAP

The ELAP needs to know the current status of various aspects of the DSMs. Accordingly, the DSM sends a DSM status message to the ELAP when the following events occur:

- When the DSM is booted
- When the DSM receives a DSM Status Request message from the ELAP
- When the DSM determines that it needs to download the entire database

For example, the database could become totally corrupted, or a user could initialize the card.

- When the DSM starts receiving DB downloads or DB updates.

When a DSM card starts downloading the RTDB, or if the DSM starts accepting database updates, it needs to send a status message informing the ELAP of the first record received. This helps the ELAP keep track of downloads in progress.

DSM Status Message Fields

The DSM status message provides the following information to the ELAP:

- DSM Memory Size

When the DSM is initialized, it determines the amount of applique memory present. The ELAP uses this value to determine if the DSM has enough memory to hold the RTDB.

- Load Mode Status

This flag indicates whether or not 80% of the IS-NR LIMs have access to SCCP services.

- Database Level Number

The ELAP maintains a level number for the RTDB. Each time the database is updated, the level number will be incremented. When the database is sent to the DSM, the DSM keeps track of the database level number. The database level number will be included in all Status messages sent from the DSM. A level number of 0 signifies that no database has been loaded into the DSM (this can be done any time the DSM wants to request a full database download).

- Database Download Starting Record Number

When the DSM starts downloading either the entire RTDB or updates to the database, it will identify the starting record number. This allows the ELAP to know when to wrap around the end of the file, and when the DSM has finished receiving the file or updates.

System Hardware Verification

DSM card loading verifies the validity of the hardware configuration for the DSM cards. The verification of the hardware includes:

- Validity of the DSM motherboard
- Verification of daughterboard memory size

System hardware verification includes checks for the appropriate LNP capable hardware when the feature bit is on. If the hardware is not capable, the feature bit cannot be turned on and the provisioning mode is set to LNP Degraded. If capacity on the ELAP has exceeded the supplied feature keys, the Major MPS alarm will be set and the DSM cards will NOT load.

DSM Motherboard Verification

An AMD-K6 (or better) motherboard is required to support the LNP ELAP feature VSCCP application on the DSM card. EAGLE 5 ISS maintenance stores the validity status of the VSCCP card's motherboard configuration. The system does not allow the LNP ELAP feature to be enabled if the hardware configuration is invalid.

When the VSCCP application is initializing, it determines the motherboard type. If the motherboard is determined to be invalid for the LNP ELAP application, loading of the VSCCP card is automatically inhibited and the card is booted through PMTC. Booting the card in this manner suppresses any obituary.

DSM Daughter board Memory Validation

The VSCCP application performs two types of memory validation to determine whether or not a DSM has sufficient memory to run the LNP ELAP VSCCP application: Local Memory validation and Continual Memory validation.

The report from the `rept-stat-sccp` command includes the daughterboard memory both allocated and physically present on each VSCCP card. (See the *Commands Manual* for a description of the `rept-stat-sccp` command output.)

Local Memory Validation

Any time the LNP ELAP feature is enabled and a DSM is initializing, VSCCP checks to see if the DSM has at least one D1G daughterboard. After this is successful, VSCCP application requests the RTDB size from the MPS and determine if the DSM contains sufficient daughterboards to download the RTDB. These two checks occur before starting the data loading operation from the MPS.

Real-Time Memory Validation

Once communications between the DSM and ELAP have been established, and the DSM has joined the RMTP Tree, the ELAP starts downloading the RTDB to the DSM. After the DSM has downloaded the RTDB, it continues to receive database updates as necessary. The ELAP includes the size of the current RTDB in all records sent to the DSM. The DSM compares the size required to the amount of memory installed, and issues a minor alarm whenever the database exceeds 80% of the DSM memory. If the database completely fills the DSM memory, a major alarm is issued and the DSM status changes to IS-ANR/Restricted.

Messages, Alarms, and Status Reporting

Actions Taken When Hardware Determined to be Invalid

When the hardware configuration for a DSM card is determined to be invalid for the LNP ELAP application, SCM automatically inhibits loading for that specific DSM card. A major alarm is generated indicating that card loading for that DSM card has failed and has been automatically inhibited (i.e., prevented from reloading again). When card loading has been inhibited, the primary state of the card is set to OOS-MT-DSBLD and the secondary state of the card is set to MEA (Mismatch of Equipment and Attributes).

The following actions apply to a DSM card determined to be invalid:

- The DSM will not download the EAGLE 5 ISS databases.
- The DSM will not download the RTDB from the ELAP.
- The DSM will not accept RTDB updates (additions, changes, and deletes) from the ELAP.

Refer to the *Tekelec 1100 AS MPS Platform Software and Maintenance Manual* to determine the appropriate corrective actions.

DSM Memory Capacity Status Reporting

The DSM sends a message to the ELAP containing the amount of memory on the DSM board. The ELAP determines whether the DSM has enough memory to store the RTDB and sends an ACK or NAK back to the DSM indicating whether or not the DSM has an adequate amount of memory.

When the ELAP sends database updates to the DSMs, the update messages includes a field that contains the new database memory requirements. Each DSM monitors the DB size requirements and issues a minor alarm if the size of the DB exceeds 80% of its memory. If a database increases to the point that it occupies 100% of the DSM memory, a major alarm is issued.

The `rept-stat-mps:loc=xxxx` command shows the amount of memory used by the RTDB as a percent of available DSM memory (see “rept-stat-mps” on page 4-10).

Unstable Loading Mode

At some point, having a number of invalid DSM cards will result in some of the LIMs being denied SCCP services. There is a threshold that needs to be monitored: if the number of valid DSMs is insufficient to provide service to at least 80% of the IS-NR LIMs, the system is said to be in an unstable Loading Mode.

The system interrupts and aborts card loading upon execution of an STP database change command. Loading Mode support denies the execution of STP database change commands when the system is in an unstable loading mode.

An unstable loading mode exists when any of the following conditions are true:

- The system's maintenance baseline has not been established.
- Less than 80% of the number of LIMs provisioned are IS-NR or OOS-MT-DSBLD.

The conditions that an insufficient number of VSCCP cards are IS-NR or OOS-MT-DSBLD relative to 80% of the number of provisioned LIMs is called a failure to provide adequate SCCP capacity.

- The number of IS-NR and OOS-MT-DSBLD SCCP cards is insufficient to service at least 80% of all provisioned LIMs.

Loading Mode is based on the ability of the system to provide SCCP service to at least 80% of the LIMs. No more than 16 LIMs can be serviced by each SCCP (or VSCCP) card.

- There is insufficient SCCP service, which occurs if an insufficient number of IS-NR VSCCP cards are available to service at least 80% of the number of IS-NR LIMs.

It is possible for LIMs or VSCCP cards to be inhibited or to have problems that prevent them from operating normally. If enough VSCCP cards are out of service, it may not be possible for the remaining IS-NR VSCCP cards to service at least 80% of the number of IS-NR LIMs. This is called "insufficient SCCP service." When this occurs, some of the LIMs will be denied SCCP service. It is possible to use the `inh-card` command to inhibit LIMs to bring the ratio back to 16:1 or better (see "Actions Taken When the System is in an Unstable Loading Mode" on page 4-8).

- If LIM cards are being denied SCCP service *and* any VSCCP cards are in an abnormal state (OOS-MT, IS-ANR)

Actions Taken When the System is in an Unstable Loading Mode

- Unstable loading mode has no impact on RTDB downloads or the stream of RTDB updates.
- When the loading mode is unstable, the `rept-stat-sys` command will report the existence of the unstable loading mode and the specific trigger that caused it.
- When in an unstable Loading Mode, the EAGLE 5 ISS will not accept STP database updates. When updates are rejected, the reason will be given as "E3112 Cmd Rej: Loading Mode unstable due to SCCP service is deficient."

Messages, Alarms, and Status Reporting

The `inh-card` and `alw-card` commands can be used to alter SCCP service levels to achieve the 80% threshold. This can be repeated for each card until the system is able to supply SCCP services to at least 80% of the IS-NR LIMs. The remaining 20% LIM or supporting VSCCP cards may remain out of service until the stream of STP database updates ceases. This stream of updates can be temporarily interrupted to allow the remaining 20% of the system to come in service.

Once an STP database has been loaded, that database can be updated (as long as the system is not in an unstable Loading Mode). However, if an STP update comes in during STP database loading, the DSM will abort the current loading, issue a class 01D7 obit message (Figure 4-1), and reboot.

Figure 4-1. Obit Message for Abort of Card Loading

```
tekelecstp 97-04-08 12:29:04 EST EAGLE 35.0-31.8.0
-----
STH: Received a BOOT Appl-obituary reply for restart
Card 1317  Module RADB_MGR.C  Line 337  Class 01d7
Register Dump :
  EFL=00000246  CS =0058  EIP=0000808d  SS =0060
  EAX=000a6ff3  ECX=000a0005  EDX=00000000  EBX=000a6fa0
  ESP=00108828  EBP=0010882c  ESI=001f1e10  EDI=00000000
  DS =0060  ES =0060  FS =0060  GS =0060

Stack Dump :
[SP+1E]=001f  [SP+16]=0000  [SP+0E]=000a  [SP+06]=0010
[SP+1C]=1e10  [SP+14]=0004  [SP+0C]=6fa0  [SP+04]=8850
[SP+1A]=0010  [SP+12]=001f  [SP+0A]=0004  [SP+02]=0001
[SP+18]=886c  [SP+10]=4928  [SP+08]=7ec3  [SP+00]=504b

User Data Dump :
14 02 fa ed 01 01 1d 01 5a 01 00  . . . . .Z..

Report Date:02-08-08  Time:12:29:04
```

- If executing the `ent-card` or `inh-card` command would cause the system to enter an unstable Loading Mode, it will be necessary to use the “Force” parameter on the command.

Commands

The commands described in this section report status information for the provisioning system.

`rept-stat-db`

The `rept-stat-db` command report includes the RTDB birthdate, level, and status. This information is used to help determine the need for and method to use for an RTDB resynchronization, audit and reconcile, reload from another RTDB, or bulk load from LSMS.

Figure 4-2. rept-stat-db Command Report Example

```
rept-stat-db:display=all:db=mps

                ELAP A ( ACTV )
                C BIRTHDATE                LEVEL                EXCEPTION
                - - - - -
RTDB            Y 02-01-29 08:20:04        12345                -
RTDB-EAGLE     02-01-29 08:20:04        12345                -

                ELAP B ( STDBY )
                C BIRTHDATE                LEVEL                EXCEPTION
                - - - - -
RTDB            Y 02-01-29 08:20:04        12345                -
RTDB-EAGLE     02-01-29 08:20:04        12345                -

                EAGLE RTDB REPORT
CARD/APPL  LOC  C BIRTHDATE                LEVEL                EXCEPTION
-----  ---  - - - - -
VSCCP      1201 Y 02-01-29 08:20:04        12345                -
VSCCP      1203 Y 02-01-29 08:20:04        12345                -
VSCCP      1105 Y 02-01-29 08:20:04        12345                -

;
```

rept-stat-mps

The `rept-stat-mps` command reports the status of the provisioning system, including MPS platform status and ELAP status.

There are two possible variants of this command:

- `rept-stat-mps` - This produces a summary report showing the overall status of the provisioning system and a moderate level of information for each DSM card.
- `rept-stat-mps:loc=xxxx` - This produces a more detailed report showing the status of a specific DSM card.

When the ELAP sends database updates to the DSMs, the update messages include a field that contains the new database memory requirements. This version of the `rept-stat-mps` command displays the amount of memory used by the RTDB as a percent of available DSM memory.

Each DSM monitors the database size requirements, and issue a minor alarm if the size of the database exceeds 80% of its memory. If a database increases to the point that it occupies 100% of the DSM memory, a major alarm is issued.

Messages, Alarms, and Status Reporting

Samples of the reports produced by these commands are shown in Figure 4-3:

Figure 4-3. `rept-stat-mps` Command Report Examples

```
0          1          2          3          4          5          6          7
01234567890123456789012345678901234567890123456789012345678901234567890123456789

rept-stat-mps
  Command entered at terminal #4.
;

Integrat40 00-06-24 10:37:22 EST EAGLE 35.0.0-35.10.0

          VERSION      PST          SST          AST
ELAP A          027-015-000  OOS-MT      Fault      -----
  CRITICAL PLATFORM  ALARM DATA = No Alarms
  MAJOR   PLATFORM  ALARM DATA = h'0123456789ABCDEF
  MINOR   PLATFORM  ALARM DATA = h'0123456789ABCDEF
  CRITICAL APPLICATION ALARM DATA = No Alarms
  MAJOR   APPLICATION ALARM DATA = h'0123456789ABCDEF
  MINOR   APPLICATION ALARM DATA = No Alarms
          ALARM STATUS = ** 0371 Major Platform Failure(s)

          VERSION      PST          SST          AST
ELAP B          027-015-000  OOS-MT      Fault      -----
  CRITICAL PLATFORM  ALARM DATA = No Alarms
  MAJOR   PLATFORM  ALARM DATA = No Alarms
  MINOR   PLATFORM  ALARM DATA = No Alarms
  CRITICAL APPLICATION ALARM DATA = h'0123456789ABCDEF
  MAJOR   APPLICATION ALARM DATA = h'0123456789ABCDEF
  MINOR   APPLICATION ALARM DATA = No Alarms
          ALARM STATUS = *C 0373 Critical Application Failure(s)

CARD  PST          SST          LNP STAT
1106 P IS-NR      Active      ACT
1201  IS-ANR      Active      SWDL
1205  OOS-MT-DSBLD Manual      -----
1302  OOS-MT      Fault      -----
1310  IS-ANR      Standby    SWDL

CARD 1106 ALARM STATUS = No Alarms
CARD 1201 ALARM STATUS = No Alarms
CARD 1205 ALARM STATUS = No Alarms
CARD 1302 ALARM STATUS = ** 0013 Card is isolated from the system
CARD 1310 ALARM STATUS = No Alarms

Command Completed.
```

rept-stat-trbl

This command includes the DSM/ELAP IP link alarms.

Figure 4-4. `rept-stat-trbl` Command Output Example

```
> rept-stat-trbl
Command Accepted - Processing
  eagle10605 99-06-24 14:34:08 EST EAGLE 35.0.0
  rept-stat-trbl
  Command entered at terminal #10.
;
  eagle10605 99-06-24 14:34:08 EST EAGLE 35.0.0
  Searching devices for alarms...
;
  eagle10605 99-06-24 14:34:09 EST EAGLE 35.0.0
  SEQN UAM AL DEVICE ELEMENT TROUBLE TEXT
  0002.0143 * CARD 1113 OAM System release GPL(s) not approved
  0011.0176 * SECULOG 1116 Stdby security log -- upload required
  3540.0203 ** SLK 1201,A lsn1 REPT-LKF: lost data
  3541.0203 ** SLK 1201,B lsn4 REPT-LKF: lost data
  3542.0203 ** SLK 1202,A lsn2 REPT-LKF: lost data
  3544.0202 ** SLK 1203,A lsn3 REPT-LKF: HWP - too many link interrupts
  0021.0318 ** LSN lsn1 REPT-LKSTO: link set prohibited
  0022.0318 ** LSN lsn2 REPT-LKSTO: link set prohibited
  0023.0318 ** LSN lsn3 REPT-LKSTO: link set prohibited
  0010.0318 ** LSN lsn4 REPT-LKSTO: link set prohibited
  3537.0084 ** DSM A 1215 IP Connection Unavailable
  3536.0372 ** MPS A Major Platform Failure(s)
  0003.0313 *C DPC 010-010-003 DPC is prohibited
  0004.0313 *C DPC 010-010-004 DPC is prohibited
  0005.0313 *C DPC 010-010-005 DPC is prohibited
  0028.0313 *C DPC 252-010-001 DPC is prohibited
  0006.0313 *C DPC 252-010-003 DPC is prohibited
  0008.0313 *C DPC 252-010-004 DPC is prohibited
  0009.0313 *C DPC 252-011-* DPC is prohibited
  0029.0308 *C SYSTEM Node isolated due to SLK failures
Command Completed.
```

Messages, Alarms, and Status Reporting

rept-stat-alm

This command includes the alarm totals for the DSM/ELAP IP links.

Figure 4-5. `repr-stat-alm` Command Report Example

```
> rept-stat-alm

Command Accepted - Processing

eagle10605 99-06-24 23:59:39 EST EAGLE 35.0.0
rept-stat-alm
Command entered at terminal #10.
;

eagle10605 99-06-24 23:59:39 EST EAGLE 35.0.0
ALARM TRANSFER= RMC
ALARM MODE          CRIT= AUDIBLE      MAJR= AUDIBLE      MINR= AUDIBLE
ALARM FRAME 1      CRIT= 9          MAJR= 12          MINR= 2
ALARM FRAME 2      CRIT= 0          MAJR= 0           MINR= 0
ALARM FRAME 3      CRIT= 0          MAJR= 0           MINR= 0
ALARM FRAME 4      CRIT= 0          MAJR= 0           MINR= 0
ALARM FRAME 5      CRIT= 0          MAJR= 0           MINR= 0
ALARM FRAME 6      CRIT= 0          MAJR= 0           MINR= 0
ALARM FRAME GPF    CRIT= 1          MAJR= 2           MINR= 1
PERM. INH. ALARMS CRIT= 0          MAJR= 0           MINR= 0
TEMP. INH. ALARMS CRIT= 0          MAJR= 0           MINR= 0
ACTIVE ALARMS     CRIT= 10         MAJR= 14          MINR= 3
TOTAL ALARMS      CRIT= 10         MAJR= 14          MINR= 3
Command Completed.
;
```

Unsolicited Alarm Messages and Unsolicited Information Messages

The following sections describe MPS and ELAP Unsolicited Alarm Messages (UAMs) and Unsolicited Information Messages (UIMs), as well as those related to the LNP ELAP.

The EAGLE 5 ISS outputs two types of unsolicited messages:

- **Unsolicited Alarm Messages (UAMs)** - Denotes persistent problems with a device or object that needs the attention of a craftsman.
- **Unsolicited Informational Messages (UIMs)** - Indicates transient events that have occurred.

Unsolicited Alarm Messages are generated by the maintenance system as trouble notification for the OS. The maintenance system is able to determine the status of the system through polling and periodic audits. Troubles are detected through analysis of system status and notifications from various subsystems in the EAGLE 5 ISS. The EAGLE 5 ISS controls and generates the alarm number, associated text, and formatting for alarms sent to EAGLE 5 ISS through the Maintenance Block mechanism for the LNP ELAP.

The *Maintenance Manual* describes all EAGLE 5 ISS UAMs and the appropriate recovery actions.

MPS Platform and ELAP Application Alarms

MPS platform and ELAP application alarms are reported in six categories of alarms. The categories are:

- **Critical Platform Alarm**—This is a 16-character hexadecimal string in which each bit represents a unique critical platform failure and alarm. An alarm in this category results in the associated MPS state being set to OOS-MT// Fault.
- **Major Platform Alarm**—This is a 16-character hexadecimal string in which each bit represents a unique major platform failure and alarm. An alarm in this category results in the associated MPS state being set to OOS-MT// Fault.
- **Minor Platform Alarm**—This is a 16-character hexadecimal string in which each bit represents a unique minor platform failure and alarm. An alarm in this category results in the associated MPS state being set to IS-ANR// Restricted.
- **Critical Application Alarm**—This is a 16-character hexadecimal string in which each bit represents a unique critical application failure/alarm. An alarm in this category results in the associated MPS state being set to OOS-MT//Fault.
- **Major Application Alarm**—This is a 16-character hexadecimal string in which each bit represents a unique major application failure/alarm. An alarm in this category results in the associated MPS state being set to OOS-MT// Fault.

Messages, Alarms, and Status Reporting

- **Minor Application Alarm**—This is a 16-character hexadecimal string in which each bit represents a unique minor application failure and alarm. An alarm in this category results in the associated MPS state being set to IS-ANR/Restricted.

The alarm categories, shown in Table 4-2, are forwarded to the EAGLE 5 ISS when MPS and ELAP failures or errors are detected. Each alarm category is sent with a hexadecimal alarm data string that encodes all alarms detected in that category (see “MPS and ELAP Status and Alarm Reporting” on page 4-2). The clearing alarm for all of the MPS Platform and Application alarms is UAM 0250, MPS Available

NOTE: The recovery actions for the platform and application alarms are defined in *Tekelec 1100 AS MPS Platform Software and Maintenance Manual*.

Table 4-2. MPS Platform and ELAP Alarm Category UAMs

UAM #	Severity	Message Text
370	Critical	Critical Platform Failure(s)
371	Critical	Critical Application Failure(s)
372	Major	Major Platform Failure(s)
373	Major	Major Application Failure(s)
374	Minor	Minor Platform Failure(s)
375	Minor	Minor Application Failure(s)

Figure 4-6. Alarm Output Example

```

1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 00-09-30 16:28:08 EST EAGLE 35.0.0-35.10.0
*C 0259.0370 *C MPS   B           Critical Platform Failure(s)
      ALARM DATA = h'0123456789ABCDEF

```

Figure 4-7. MPS Available Alarm

```

1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 00-09-30 16:28:08 EST EAGLE 35.0.0-35.10.0
0259.0250   MPS   B           MPS Available

```

The clearing alarm is generated after existing alarms have been cleared. The clearing alarm sets the MPS primary status to IS-NR.

ELAP-to-DSM Connection Status

The ELAP and the DSM are connected over one 100BASE-T Ethernet network that runs at 100 Mbps and one 10BASE-T Ethernet network that runs at 10 Mbps, and use TCP/IP. In the event connection is inoperative, the DSM is responsible for generating an appropriate UAM. Loss of connectivity or inability of the ELAP to communicate (from hardware or software failure, for example) is detected and reported within 30 seconds.

ELAP-DSM UAMs

Maintenance Blocks sent from the ELAP have a field to identify error message requests. (See “Maintenance Blocks” on page 4-2). The DSM processes incoming Maintenance Blocks and generates the requested UAM. The DSM acts only as a delivery agent. The recovery actions for the ELAP-DSM UAMs are defined in "Corrective Maintenance" Chapter in the *Maintenance Manual*.

DSM-ELAP Link Status Alarms

Two alarms indicate the DSM-to-MPS link status:

- 0084 “IP Connection Unavailable” (Major)
- 0085 “IP Connection Available” (Normal/Clearing)

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
  station1234 00-09-30 16:28:08 EST EAGLE 35.0.0-35.10.0
** 3582.0084 ** DSM B 1217 IP Connection Unavailable
  
```

RTDB Audit Alarms

During an audit of the DSM cards and the ELAPs, the status of each real-time database (RTDB) is examined and the following alarms can be raised. The recovery actions for the RTDB Audit Alarms are defined in "Corrective Maintenance" Chapter in the *Maintenance Manual*.

1. When an RTDB has become corrupted, the following minor alarm is raised.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
  station1234 00-04-30 16:28:08 EST EAGLE 35.0.0-31.7.0
* 0012.0443 * CARD 1108 VSCCP RTDB Database is corrupted
  
```

Messages, Alarms, and Status Reporting

2. When a card's RTDB is inconsistent (its contents are not identical to the current RTDB on the Active ELAP fixed disks), the following minor alarm is raised.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 00-04-30 16:28:08 EST EAGLE 35.0.0-31.7.0
* 0012.0444 * CARD 1108 VSCCP           RTDB Database is inconsistent
```

3. When an inconsistent, incoherent, or corrupted RTDB has been fixed and the card or ELAP is in an IS-NR condition, the following alarm is raised.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 00-04-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0012.0445 CARD 1108 VSCCP           RTDB Database has been corrected
```

4. While the RTDB is being downloaded or an update has failed, it is in an incoherent state. The following minor alarm is raised.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
* 0012.0448 * CARD 1108 VSCCP           RTDB Database is incoherent
```

5. When a DSM card detects that its RTDB needs to be resynchronized and has started the resync operation, the following major alarm is raised.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
** 0012.0449** CARD 1108 VSCCP           RTDB resynchronization in progress
```

6. After a DSM card completes its RTDB resync operation, the following clearing alarm is raised.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0012.0450 CARD 1108 VSCCP           RTDB resynchronization complete
```

- When a DSM card detects that its RTDB needs to be reloaded because the resync log does not contain all of the required updates, the following major alarm is raised.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
** 0012.0451 ** CARD 1108 VSCCP           RTDB reload required
    
```

- After a DSM card completes its RTDB reload operation, the following clearing alarm is raised.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0012.0452   CARD 1108 VSCCP           RTDB reload complete
    
```

Feature Key Capacity UAMs

The following alarms are issued when the DSM detects the capacity has been exceeded. The recovery actions for the Feature Key Capacity Alarms are defined in "Corrective Maintenance" Chapter in the *Maintenance Manual*.

- This UAM appears when the NPANXX totals on the DSM VSCCP cards has reached 90% of the total NPANXX capacity that is currently configured for the EAGLE 5 ISS.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
** 0012.0283 ** LNP SYSTEM           LNP Ported NPAs exceeds Feat. Capacity
    
```

- The following example is a clearing message that appears when a previous fault with the number of LNP ported NPAs is greater than the capacity this feature supports has been corrected.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0012.0284   LNP SYSTEM           LNP Ported NPAs Capacity Normal
    
```

Messages, Alarms, and Status Reporting

3. This UAM appears when the LRN totals on the DSM VSCCP cards has reached 90% of the total LRN capacity that is currently configured for the EAGLE 5 ISS.

Example:

```
      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
** 0012.0285 ** LNP SYSTEM                    LNP Ported LRNs exceeds Feat. Capacity
```

4. The following example is a clearing message that appears when a previous fault with the number of LNP ported LRNs is greater than the capacity this feature supports has been corrected.

Example:

```
      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0012.0286      LNP SYSTEM                    LNP Ported LRNs Capacity Normal
```

5. This critical UAM is output to warn that the total TN's in the LNP database has reached the configurable percentage (default value is 95%) of the allowed Feature Access Key (FAK) capacity currently configured for the EAGLE 5 ISS.

Example:

```
      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
*C 0056.0287 *C LNP SYSTEM                    RTDB Table Level 2 FAK Cap exceeded
                                TABLE: TN      Threshold Value: 95%
                                Exceeds 91200000 of 96000000
```

6. This major UAM is output to warn that the total TN's in the LNP database has reached the configurable percentage (default value is 80%) of the allowed Feature key capacity currently configured for the EAGLE 5 ISS. The configured threshold value for UAM 0288 must be less than the configured threshold value for UAM 0287.

Example:

```
      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
** 0056.0288 ** LNP SYSTEM                    RTDB Table Level 1 FAK Cap exceeded
                                TABLE: TN      Threshold Value: 80%
                                Exceeds 76800000 of 96000000
```

- The following example is a clearing message that appears when a previous LNP FAK alarm condition no longer exists.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0058.0289    LNP SYSTEM                      RTDB Table FAK Capacity Normal
    
```

Physical Memory Usage UAMs

The following alarms are issued when the DSM detects the RTDB memory capacity is not adequate for the ELAP feature. The recovery actions for the Physical Memory Usage Alarms are defined in "Corrective Maintenance" Chapter in the *Maintenance Manual*.

- This critical UAM is displayed when the RTDB physical memory usage threshold exceeds 95% for the specified number of TNs, LRNs, or NPAs.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
*C 0012.0442 *C CARD 1108 VSCCP              RTDB database capacity is 95% full
    
```

- This major UAM is displayed when the RTDB physical memory usage threshold exceeds 80% for the specified number of TNs, LRNs, or NPAs.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
** 0012.0446 ** CARD 1108 VSCCP             RTDB database capacity is 80% full
    
```

- The following example is a clearing message that appears when a previous RTDB physical memory usage alarm condition no longer exists.

Example:

```

      1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0012.0447    CARD 1108 VSCCP                RTDB database capacity alarm cleared
    
```

EAGLE DSM Audit UIMs

The DSM performs data validation checks prior to applying updates and changes to the RTDB. This consist of comparing the checksum in the data about to be overwritten with the old checksum (new data element) in the update about to be applied.

1. This UIM is output when validation failure occurs because the target-cell checksums do not match the source-cell checksums. The updates are not applied and the database is marked incoherent.

Measurement Capacity UIMs

When the Measurements Platform is not installed, the OAM-based Measurements Subsystem will collect up to 100,000 LRNs and 150,000 NPANXXs from the SCCP cards. If the number of provisioned LRNs exceeds 100,000 or the number of provisioned NPANXXs exceeds 150,000, the Measurements Subsystem will generate a UIM at each hourly collection interval. The UIM is a warning that measurements data have been discarded. The UIM output may be suppressed by setting the UIM threshold limit to zero. More information on the Measurement Capacity UIMs are defined in "Corrective Maintenance" Chapter in the *Maintenance Manual*.

1. The following UIM is issued if the Measurements Platform is not enabled and the number of provisioned LRNs exceeds 100,000. This UIM is notification that the LNP LRN measurements report will be truncated, and additional LRN measurements will not be collected or reported.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0002.1310   CARD 1201   INFO       Sytem Meas. Limit exceeded for LRN
```

2. The following UIM is issued if the Measurements Platform is not enabled and the number of provisioned NPANXXs exceeds 150,000. This UIM is notification that the LNP NPANXXs measurements report will be truncated, and additional NPANXX measurements will not be collected or reported.

Example:

```
1           2           3           4           5           6           7           8
1234567890123456789012345678901234567890123456789012345678901234567890
station1234 99-09-30 16:28:08 EST EAGLE 35.0.0-31.7.0
0002.1311   CARD 1201   INFO       Sytem Meas. Limit exceeded for NPANXX
```

Messages, Alarms, and Status Reporting

5

ELAP Software Configuration

Overview of the ELAP User Interfaces.....	5-2
Setting Up an ELAP Workstation.....	5-3
Screen Resolution	5-3
Compatible Browsers.....	5-3
Java	5-3
ELAP Configuration and Initialization	5-8
Required Network Address Information	5-9
Configuration Menu Conventions	5-11
ELAP Configuration Menu	5-13
Overview of ELAP Configuration.....	5-13
Initial “elapconfig” User Login.....	5-13
Text-based Configuration Menu	5-15
Display Configuration.....	5-16
Configure Provisioning Network.....	5-17
Select Time Zone	5-20
Exchange Secure Shell Keys	5-21
Change Password	5-21
Platform Menu and Options	5-22
Configure NTP Server and Options.....	5-24
Exit	5-25

ELAP Configuration Procedure 5-26

 Configuration Terms and Assumptions..... 5-26

 Configuration Symbols..... 5-27

 Initial Setup and Connecting to MPSs..... 5-27

 Procedure for Configuring ELAPs..... 5-29

Overview of the ELAP User Interfaces

The EAGLE LNP Application Processor (ELAP) User Interface, provides two user interfaces:

- The Graphical User Interface provides GUI menus that maintain, debug, and operate the platform; it and its associated error messages are described in Chapter 3, "ELAP Graphical User Interface"
- The text-based User Interface has a Configuration menu that performs the ELAP configuration and initialization; it is described in this chapter.

The GUI provides the user with menus and screens to perform routine operations. The text-based user interface provides the ELAP Configuration menu to perform the initial configuration.

To communicate with the ELAP graphical user interface, you use a PC with a network connection and a network browser. For information about using the ELAP GUI, see "ELAP Graphical User Interface" on page 3-2.

To configure ELAP, you use the ELAP text-based user interface. For information about configuring the ELAP and how to set up its PC workstation, continue with this chapter.

Setting Up an ELAP Workstation

The customer workstation serving as a client PC (shown in Figure 3-1 on page 3-3) must meet certain criteria, which are described next.

Screen Resolution

For optimum usability, the workstation must have a minimum resolution of 800x600 pixels and a minimum color depth of 16 thousand colors per pixel.

Compatible Browsers

The ELAP user interface was designed and written to perform with Microsoft Internet Explorer 5.0 or later. The ELAP user interface is also compatible with Mozilla Firefox 1.0.2 or later. Do not use other browsers with the ELAP user interface. When using Firefox, you will encounter the following message when logging into the ELAP GUI:

CAUTION: The User Interface may not function correctly with the browser you are using.

Microsoft Internet Explorer, version 5 and later, has been certified for this application

Java

The ELAP GUI uses a Java “banner” applet to display real-time updates and status for both A and B sides of the MPS. A Java virtual machine version 1.2 or later is required.

The Java installation must be performed in the sequence shown:

- “Installing Java Plug-In” on page 5-4
- “Installing Java Policy File” on page 5-7
- “Adding Security Parameters to an Existing Java Policy File” on page 5-7 or “Creating a New Java Policy File” on page 5-8

Installing Java Plug-In

Because the Java applet is required for the ELAP GUI to operate, perform the following procedure to install the Java plug-in. You will perform this after completing the ELAP configuration described in “ELAP Configuration and Initialization” on page 5-8.

NOTE: The selected browser must be the only browser open on your PC when you modify or create the Java policy file, or else the change does not take effect.

1. Using the selected browser (Internet Explorer 5.0 or later or Mozilla Firefox 1.0.2 or later), enter the IP address for your ELAP A machine. You will see the login screen. See Figure 3-2 on page 3-4.
2. Attempt to log in to the ELAP User Interface screen.
When using Firefox, you will encounter the following message when logging into the ELAP GUI:

CAUTION: The User Interface may not function correctly with the browser you are using.

Microsoft Internet Explorer, version 5 and later, has been certified for this application

When you have successfully entered the Username and Password, the login process checks for the required Java plug-in. When it finds the Java plug-in not present, the system displays a ‘Security Warning’ window, shown in Figure 5-1.

Figure 5-1. Security Warning Window




3. Click the **Yes** button to begin the process of loading the Java plug-in.

ELAP Software Configuration


4. The loading and unpacking of the Java runtime environment begins, as shown in Figure 5-2.

Figure 5-2. Unpacking Java Runtime



5. Next, the Java installation presents a Software Licensing Agreement screen shown in Figure 5-3.


Figure 5-3. Software Licensing Agreement



6. Click the **Yes** button to accept the Sun Microsystems agreement.


- 7. Next, you must specify a destination location for the Java folder, as shown in Figure 5-4.

Figure 5-4. Choosing a Destination Location



- 8. Since we prefer to use the specified default location, simply click the **Next** button to accept the Destination Folder. The process begins to load the program and shows the progress in a screen like Figure 5-5.

Figure 5-5. Storing the Java Program



9. As this loading process continues, several screens appear in succession marking the progress of the installation and the creation of Java JAR files. Finally, another momentary message indicates the successful completion, shown in Figure 5-6.

Figure 5-6. Successfully Completing the Installation



10. When screen above appears and then disappears, the installation of the Java plug-in is finished. You return to the browser screen containing the login screen in Figure 3-2 on page 3-4.

Installing Java Policy File

The banner applet makes a network connection to each MPS side. A Java policy file must be modified or created for the banner applet to connect properly. If the Java policy file is not present, you will receive a Violation status (VIOL) for the machine; for more information, see “VIOL” on page 3-7.

NOTE: The selected browser must be the only browser open on your PC when you modify or create the Java policy file, or else the change does not take effect.

Adding Security Parameters to an Existing Java Policy File

To check to see if a Java policy file is already in place, perform the following actions:

- Select Settings -> Control Panel from the Windows “Start” menu. If in the Category View, switch to the Classic View.
- Double click on the Java Plug-in icon
- Under the “Advanced” tab, the path to a policy file is specified as follows:

```
-Djava.security.policy={full_path_to_file}
```

Open the specified file, and insert the following text:

```
grant {  
    permission java.net.SocketPermission "*:8473", "connect";  
};
```

Creating a New Java Policy File

To create a Java policy file, insert the following text into a file accessible by the workstation:

```
grant {
  permission java.net.SocketPermission "*:8473", "connect";
};
```

To install the new Java policy file, perform the following actions:

- Select Settings -> Control Panel from the Windows “Start” menu. If in the Category View, switch to the Classic View.
- Double click on the Java Plug-in icon
- Under the “Advanced” tab, type in the path to the policy file you created above:

```
-Djava.security.policy={full_path_to_file}
```

You have now completed the Java installation procedure.

ELAP Configuration and Initialization

Before you can use the ELAP GUI, you must initialize and configure the ELAP software. The ELAP configuration and initialization is performed through the ELAP text-based user interface.

You will connect a local (optional) terminal connected to port 0 of the 8 -port connector box on the MPS frame at each EAGLE 5 ISS. (Refer to the *Installation Manual* - EAGLE 5 ISS.) To begin the initialization, you will log into ELAP A the first time as the “elapconfig” user. An automatic configuration is performed on both mated ELAPs.

NOTE: All network connections and the mate ELAP must be present and verified to allow the initial configuration to complete successfully.

No other user is able to log in to an ELAP until the configuration step is completed for that system.

Errors and Other Messages

The following rules are applicable to configuring the ELAP:

1. Mate MPS servers (MPS A and MPS B) must be powered on.
2. “Initial Platform Manufacture” for the mate MPS servers must be complete.
3. The Sync Network between the mate MPS servers must be operational.

ELAP Software Configuration

4. You must have the correct password for the `elapdev` user on the mate MPS server.

Required Network Address Information

The following information is needed to configure the MPSs at EAGLE 5 ISS A (Table 5-1) and EAGLE 5 ISS B (Table 5-2). Fill in the following tables for reference during the installation procedure.

Table 5-1. Information for MPS at EAGLE 5 ISS A

Common Information	
MPS A Provisioning Network Address	. . .
MPS B Provisioning Network Address	. . .
Netmask	. . .
Default Router	. . .
Port Forwarding and Static NAT Information (optional)	
MPS A Forwarded HTTP Port	
MPS B Forwarded HTTP Port	
MPS A Forwarded SuExec Port	
MPS B Forwarded SuExec Port	
MPS A Forwarded LSMS Port	7483*
MPS A Forwarded LSMS Port	7483*
MPS A Forwarded Banner Port	
MPS B Forwarded Banner Port	
MPS A Forwarded EBDA Port	1030*
MPS B Forwarded EBDA Port	1030*
MPS A Provisioning Static NAT Addr.	. . .
MPS B Provisioning Static NAT Addr.	. . .

* Do not change the default values for these ports

..

Table 5-2. Information for MPS at EAGLE 5 ISS B

Common Information	
MPS A Provisioning Network Address	. . .
MPS B Provisioning Network Address	. . .
Netmask	. . .
Default Router	. . .
Port Forwarding and Static NAT Information (optional)	
MPS A Forwarded HTTP Port	
MPS B Forwarded HTTP Port	
MPS A Forwarded SuExec Port	
MPS B Forwarded SuExec Port	
MPS A Forwarded LSMS Port	7483*
MPS A Forwarded LSMS Port	7483*
MPS A Forwarded Banner Port	
MPS B Forwarded Banner Port	
MPS A Forwarded EBDA Port	1030*
MPS B Forwarded EBDA Port	1030*
MPS A Provisioning Static NAT Addr.	. . .
MPS B Provisioning Static NAT Addr.	. . .

* Do not change the default values for these ports

Configuration Menu Conventions

After you have logged into the ELAP user interface with the `elapconfig` user name, the menu appears that corresponds to that user login name. Before going into the details about the Configuration Menu, you need to know a few things about the Menu Format, Prompts and Default Values, and Error Message Format, which are covered next.

Menu Format

The configuration menu has a header format displaying specific information. On the first line, it indicates the MPS Side A or B, with which you are active. On the same line, you are shown the `hostname` and `hostid`. The second and third lines show the `Platform Version`, followed by the `Software Version`. The last line displays the date and time. See a sample configuration header format in Figure 5-7.

Figure 5-7. Configuration Menu Header Format

```
MPS Side A:  hostname: mps-t1100-a  hostid: fd0a4767
             Platform Version: 2.0.2-4.0.0_50.26.0
             Software Version: ELAP 1.0.1-4.0.0_50.37.0
             Mon Sep 26 10:57:57 EDT 2005
```

When you are shown a menu, you choose a menu item by entering the number of the item (or “e” for Exit) in response to the `Enter Choice` prompt that follows the menu, and press Return.

When you choose a menu item, the user interface performs the requested operation. The operation and any associated output for each menu item are described in detail later in this section.

If you enter an invalid choice (such as a letter or a number that is not available for that menu), an error appears. Perform the corrective action described for that error.

Prompts and Default Values

Depending on the menu item that you choose, you might be prompted for data (such as IP addresses) that is required to complete the selected operation. Optional fields are indicated by the text “(optional)” at the end of the prompt. To bypass an optional field without entering a value, press Return.

Default values are indicated by a value enclosed in square brackets at the end of the prompt text: `[default value]`. Example default values are shown in this chapter; they might not be the same as the default values that appear for your system. To accept the default value for a prompt instead of entering a response, press Return.

You can press the Escape key to exit any operation without entering a value for the prompt. The operation is aborted, and you are returned to the menu.

Error Message Format

Invalid menu selections, invalid user input, and failed user interface operations generate error messages on the screen. The error message remains on the screen until you press Return.

All error messages have a unique four-digit error number and associated text. The numbers and text for all error messages generated by the ELAP user interface are listed in “ELAP Messages” on page 3-112. The possible error messages that can occur for each ELAP user interface menu item are listed in the description of the menu item in this chapter.

Error messages have the following format, where **XXXX** is the unique four-digit error number for the error and *Error text* is the corresponding error text:

```
XXXX: Error text  
Press return to continue
```

Whenever the software must be stopped to perform an operation, you are prompted to stop the software:

```
ELAP software is running. Stop it? [N]: Y
```

However, you must remember that while the ELAP software is stopped, no provisioning updates can be processed by the ELAP.

ELAP Configuration Menu

Overview of ELAP Configuration

When you log into an ELAP with user name “`elapconfig`” after the first initialization of the ELAP, the configuration process begins. (See the details in “Procedure for Configuring ELAPs” on page 5-29.) The configuration process lets you change IP addresses, time zone, and the password for “`elapconfig`”. You can display the host ID and exchange secure shell keys. This section describes each of these items in configuration menu.

Initial “`elapconfig`” User Login

The first time the `elapconfig` user logs in to the system, the text screen is displayed as shown in Figure 5-8.

Figure 5-8. Initial Configuration Text Screen

Caution: This is the first login of the text user interface. Please review the following checklist before continuing. Failure to enter complete and accurate information at this time will have unpredictable results.

1. The mate MPS servers (MPS A and MPS B) must be powered on.
2. "Initial Platform Manufacture" for the mate MPS servers must be complete.
3. The sync network between the mate MPS servers must be operational.
4. You must have the correct password for the ELAPdev user on the mate MPS server.

Press return to continue...

If all four criteria above are not met, the configuration cannot proceed. Ensuring that the MPS servers are powered on requires a visual check. If the “Initial Platform Manufacture” is not complete, the configuration cannot proceed; furthermore, if the sync network is not operational, the user is notified.

When the four criteria are met, press Return and the process resumes. Figure 5-9 shows the continuation of the screen information. The installer enters `y` if the installation is to continue.

Figure 5-9. Initial Configuration Continues

Are you sure you wish to continue? [N]: y

NOTE: Review the information required for the following section in “Required Network Address Information” on page 5-9. Make certain all required information is obtained and recorded in the tables provided.

Next, the installer is prompted for the `elapdev` user password on the mate MPS server. Figure 5-10 shows sample output that is generated after the correct password is entered.

Figure 5-10. Entering the elapdev Password

```
Password for ELAPdev@mate:

Keys exchanged.
Verifying that ssh works correctly.
ssh is working correctly.
Building the initial database on slave.
Building the initial database on master.
There was no elap.cfg file. Using default configuration.
Allowing access from slave.
Stopping mysql on master.
Stopping mysql on slave.
Setting up master config file.
Setting up slave config file.
Copying database to slave.
Starting MySQL on master.
Starting MySQL on slave.
```

At this point, the first appearance of the Configuration Menu occurs, and is discussed next.

ELAP Software Configuration

Text-based Configuration Menu

Following the report appearing in Figure 5-10, the ELAP Configuration Menu is displayed as shown in Figure 5-11. The `elapconfig` user can now begin configuring the MPS local and remote servers.

Figure 5-11. ELAP Configuration Menu

```
MPS Side A:  hostname: mps-t1100-a  hostid: fd0a4767
              Platform Version: 2.0.2-4.0.0_50.26.0
              Software Version: ELAP 1.0.1-4.0.0_50.37.0
              Mon Sep 26 10:57:57 EDT 2005
```

```
/-----ELAP Configuration Menu-----\
/-----\
| 1 | Display Configuration              |
|-----|
| 2 | Configure Network Interfaces Menu |
|-----|
| 3 | Set Time Zone                     |
|-----|
| 4 | Exchange Secure Shell Keys       |
|-----|
| 5 | Change Password                  |
|-----|
| 6 | Platform Menu                    |
|-----|
| 7 | Configure NTP Server              |
|-----|
| e | Exit                              |
\-----/
```

Enter Choice:

To choose a menu item, enter the number or letter of the menu item in response to the **Enter Choice** prompt that follows the menu item list, and press Return.

Next the use of each of the menu options is explained.

Display Configuration

The Display Configuration menu option 1 displays network address information and the time zone. See an example in Figure 5-12.

Figure 5-12. Example of Display Configuration Output

```
MPS Side A:  hostname: mps-t1100-a  hostid: fd0a4767
              Platform Version: 2.0.2-4.0.0_50.26.0
              Software Version: ELAP 1.0.1-4.0.0_50.37.0
              Mon Sep 26 10:57:57 EDT 2005

ELAP A Provisioning Network IP Address = 192.168.61.90
ELAP B Provisioning Network IP Address = 192.168.61.91
Provisioning Network Netmask           = 255.255.255.0
Provisioning Network Default Router    = 192.168.61.250
ELAP A Backup Prov Network IP Address = Not configured
ELAP B Backup Prov Network IP Address = Not configured
Backup Prov Network Netmask           = Not configured
Backup Prov Network Default Router    = Not configured
ELAP A Sync Network Address           = 192.168.2.100
ELAP B Sync Network Address           = 192.168.2.200
ELAP A Main DSM Network Address       = 192.168.128.100
ELAP B Main DSM Network Address       = 192.168.128.200
ELAP A Backup DSM Network Address     = 192.168.129.100
ELAP B Backup DSM Network Address     = 192.168.129.200
ELAP A HTTP Port                      = 8888
ELAP B HTTP Port                      = 80
ELAP A HTTP SuExec Port               = 8001
ELAP B HTTP SuExec Port               = 8001
ELAP A Banner Connection Port         = 8473
ELAP B Banner Connection Port         = 8473
ELAP A Static NAT Address              = 10.25.50.10
ELAP B Static NAT Address              = 10.25.50.11
ELAP A LSMS Connection Port           = 7402
ELAP B LSMS Connection Port           = 7403
ELAP A EBDA Connection Port           = 1030
ELAP B EBDA Connection Port           = 1030
Time Zone                             = US/Eastern

Press return to continue...
```

Addresses that you choose should not conflict with your internal network addresses. The class C networks you choose should not conflict with the class C network used in your network scheme. Table 5-3 shows an example of IP addresses used in the configuration process.

Table 5-3. Sample IP Addresses Used in Configuration

Provisioning Network Information	MPS A (Local) IP Addresses	MPS B (Local) IP Addresses
ELAP A Provisioning Network IP Address (MPS A)	192.168.61.90	192.168.61.119
ELAP B Provisioning Network IP Address (MPS B)	192.168.61.91	192.168.61.120
Network Net Mask	255.255.255.0	255.255.255.0
Default Router	192.168.61.250	192.168.61.250

Configure Provisioning Network

The Configure Network Interfaces Menu option 2 of the Configuration Menu displays the submenu shown in Figure 5-13. It supports the configuration of all the network interfaces for the ELAP.

NOTE: The Configure Backup Provisioning Network option 4 of the Configure Network Interfaces Menu is not operational in this release.

Figure 5-13. Configure Network Interfaces Menu

```

/-----Configure Network Interfaces Menu-----\
/-----\
| 1 | Configure Provisioning Network |
|---|-----\
| 2 | Configure Sync Network |
|---|-----\
| 3 | Configure DSM Network |
|---|-----\
| 4 | Configure Backup Provisioning Network |
|---|-----\
| 5 | Configure Forwarded Ports |
|---|-----\
| 6 | Configure Static NAT Addresses |
|---|-----\
| e | Exit |
\-----/

```

Enter choice:

Configure Provisioning Network

The Configure Provisioning Network option 1 of the Configure Network Interfaces Menu configures the ELAP provisioning network. These include the provisioning network's IP address, netmask, and default router IP address. This information allows the ELAP to communicate with an existing customer network.

NOTE: You must configure these IP addresses. Obtain the values for the IP address, netmask, and default router from the customer's Information Services department. Record the values in the two tables in "Required Network Address Information" on page 5-9.

In response to each prompt, you can enter a dotted decimal IP address or press Return to leave the current value unchanged (the current value is shown in brackets after the prompt text). See Figure 5-14 for the option 1 output.

Figure 5-14. Configure Provisioning Network Output

```
Verifying connectivity with mate ...
Enter the ELAP A provisioning network IP Address [192.168.61.90]:
Enter the ELAP B provisioning network IP Address [192.168.61.91]:
Enter the ELAP provisioning network netmask [255.255.255.0]:
Enter the ELAP provisioning network default router IP Address: 192.168.54.250

Press return to continue ...
```

NOTE: Take care in configuring the IP information. Incorrect information can prevent the ELAP from accepting provisioning data and establishing remote ELAP user interface connections over the customer network.

Configure Sync Network

The Configure Sync Network option 2 of the Configure Network Interfaces Menu lets you specify the Sync network IP address of the selected ELAP. Sync network IP addresses are configured to default values during ELAP initialization. The third octet of the address can be changed after ELAP initialization is complete.

NOTE: Unless there is a known network address conflict, the installer can bypass option 2. If these IP addresses are changed in this procedure, obtain the values for the IP address, netmask, and default router from the customer's Information Services department. Record the values in the two tables in "Required Network Address Information" on page 5-9 and 5-10.

See Figure 5-15 for the option 2 output.

Figure 5-15. Configure Sync Network

```
Verifying connectivity with mate...  
Enter the first 3 octets for the ELAP MPS sync Network [192.168.4]:
```



CAUTION: Take care in entering the prompt responses. Entering incorrect information or rebooting at the wrong time may result in improper operation of the ELAP.

If you reboot at the wrong time, you need to contact the Customer Care Center for assistance in resolving this situation.

Configure DSM Network

The Configure DSM Network option 3 of the Configure Network Interfaces Menu prompts you for the ELAP DSM network IP addresses. This information allows the ELAP to communicate with the main and backup DSM networks.

NOTE: Unless there is a known network address conflict, the installer can bypass option 3.

In response to each prompt, you can enter a dotted decimal IP address or press Return to leave the current value unchanged (the current value is shown in brackets after the prompt text).

See Figure 5-16 for the option 3 output.

Figure 5-16. Configure DSM Network

```
Verifying connectivity with mate ...  
Enter the first 3 octets for the ELAP main DSM network [192.168.128]:  
Enter the first 3 octets for the ELAP backup DSM network [192.168.129]:
```

NOTE: Take care in configuring the IP information. Incorrect information will prevent the ELAP from communicating with the EAGLE 5 ISS.

Configure Forwarded Ports

The Configure Forwarded Ports option 5 of the Configure Network Interfaces Menu provides the functionality to configure ELAP ports for the Web UI.



CAUTION: Do not change the default values, the LSMS is not capable of changing the LSMS/EBDA ports it can connect to on the MPS.

Each numbered item of the Configure Forwarded Ports menu allows the user to specify a port number used for remote access to the MPS.

This information should be received from the customer for the MPS and recorded in Tables 5-1 and 5-2.

Configure Static NAT Addresses

The Configure Static NAT Addresses option 6 from the Configure Network Interfaces Menu provides the functionality to configure the static NAT addresses of the ELAP.

Each numbered item of the Configure Static NAT Addresses menu allows the user to specify an IP Address used outside of the firewall for remote access to the MPS. The following Figure 5-17 shows an example of a resulting prompt.

Figure 5-17. Configuring NAT Addresses Prompt

```
ELAP A Static NAT Address:
```

Select Time Zone

NOTE: Do not perform the Select the Time Zone function on a running system. Contact the Customer Care Center for assistance.

The Select Time Zone option 3 prompts you for the time zone to be used by the ELAP. The time zone can be the zone where the ELAP is located, Greenwich Mean Time, or another zone that is selected by the customer to meet the needs of the system.

NOTE: The value for the time zone should be obtained from the customer's Information Services department. The default value for the time zone is "US/Eastern".

To select a file in one of the subdirectories, enter a relative path name (such as "US/Eastern") in response to the prompt. See Figure 5-18 for the option 3 output.

Figure 5-18. Select Time Zone Menu

```
Press return to continue...
Verifying connectivity with mate...
Are you sure you wish to change the timezone for MPS A and B? [N]: y
Enter a time zone:
```

You must enter a valid UNIX time zone file name. Alternatively, to display a complete list of the valid time zones, simply press Return in response to the prompt, and all valid time zone names are displayed. See Appendix A for the list that appears when you press the Return key or enter invalid time zone file name.

The time zone change does not take effect until the next time the MPS is rebooted. The Reboot MPS screen is described in "Reboot the MPS" on page 3-77.

ELAP Software Configuration

Exchange Secure Shell Keys

The Exchange Secure Shell Keys option 4 from the ELAP Configuration Menu, enables connections between local and remote ELAPs. The ELAPs exchange encryption keys, which are required to run the secure shell.

The exchange normally occurs automatically during ELAP initialization. Use this menu item only if the exchange must be performed manually.

The `elapconfig` user must know the password for the `ELAPdev@mate`.

The exchange normally occurs automatically during ELAP initialization. Use this menu item only if the exchange must be performed manually.

See Figure 5-19 for the option 4 output.

Figure 5-19. Exchange Secure Shell Keys Output

```
Are you sure you wish to exchange keys? [N]: y
```

Change Password

The Change Password option 5 from the ELAP Configuration Menu, changes the text-based user interface password for the `elapconfig` login name for both MPS A and B.

See Figure 5-20 for the option 5 output.

Figure 5-20. Change Password

```
Verifying connectivity with mate...
Are you sure you wish to change the text UI password on MPS A and B? [N]: y
Enter new password for text UI user:
Re-enter new password:

Press return to continue...
```

Platform Menu and Options

The ELAP Platform Menu option 6, from the ELAP Configuration Menu, accesses the Platform menu so that the elapconfig user can access and manage platform functions shown next. See Figure 5-21 for the option 8 output.

Figure 5-21. Platform Menu Output

MPS Side A: hostname: mps-t1100-a hostid: fd0a4767
Platform Version: 2.0.2-4.0.0_50.26.0
Software Version: ELAP 1.0.1-4.0.0_50.37.0
Mon Sep 26 10:57:57 EDT 2005

```
/-----ELAP Platform Menu-\
/-----\
| 1 | Initiate Upgrade |
|-----|
| 2 | Eject CD |
|-----|
| 3 | Reboot MPS |
|-----|
| 4 | Halt MPS |
|-----|
| 5 | MySQL Backup |
|-----|
| 6 | RTDB Backup |
|-----|
| e | Exit |
\-----/
```

Enter choice:

Initiate Upgrade

The Initiate Upgrade menu option 1 initiates an upgrade on the selected ELAP. For upgrade procedures, contact the Customer Care Center; refer to "Customer Assistance" on page 1-10.

Eject CD

The Eject CD menu option 2 initiates an ejection of the CD media on the selected ELAP. The default, as shown next, is 'BOTH'.

Eject CD tray of MPS A, MPS B or BOTH? [BOTH]:

Reboot MPS

The Reboot MPS menu option 3 initiates a reboot of either MPS or both. The default, as shown below, is BOTH.

NOTE: The `elapconfig` user can abort rebooting the MPS by pressing the Escape key at the displayed prompt.

```
Reboot MPS A, MPS B or [BOTH]:
```



CAUTION: Rebooting the MPS stops all ELAP processes, and databases cannot be updated until MPS is fully booted.

Halt MPS

The Halt MPS menu option 4 initiates a halt of one MPS or both. The default, as shown below, is BOTH.



CAUTION: Halting an MPS stops all ELAP processes. Selecting the default to halt both MPS A and MPS B requires a person to be physically present in order to reboot MPS to allow for further access!

```
Halt MPS A, MPS B or [BOTH]: y
```

NOTE: The `elapconfig` user can abort halting the MPS by pressing the Escape key at the displayed prompt.

MySQL Backup

The MySQL Backup menu option 5 backs up the MySQL database. The output is shown below.

NOTE: ELAP software must be stopped or MySQL backup will abort and return to the ELAP Platform Menu.

```
Are you sure you want to back up the MySQL database on MPS A? [N]: y
Connecting to local MySQL server...
Getting read lock...
Tarring the NPDB...
Disconnecting from local MySQL server...
```

RTDB Backup

The RTDB Backup menu option 6 backs up the RTDB database. The output is shown below.

NOTE: ELAP software must be stopped or RTDB backup will abort and return to the ELAP Platform Menu.

```
Are you sure you want to back up the RTDB database on MPS A to
"/var/TKLC/appl/free/rtdbBackup_mps-t1100-a_20050926110224.tar"? [N] : y
```

ELAP Platform Menu Exit

The Exit menu option e exits from the ELAP Platform Menu and returns to the ELAP Configuration Menu.

Configure NTP Server and Options

The Configure NTP Server option 7 allows for the display, addition, and removal of an external NTP server. See Figure 5-22 for the option 7 output.

Figure 5-22. Configure NTP Server Output

```
/-----ELAP Configure NTP Server Menu-----\
/-----\
| 1 | Display External NTP Server |
|-----|
| 2 | Add External NTP Server |
|-----|
| 3 | Remove External NTP Server |
|-----|
| e | Exit |
\-----/
```

Enter Choice:

Display External NTP Server

The Display External NTP Server menu option 1 displays External NTP Server information. If a server is present, the server name and IP address are displayed. If an NTP Server is not present, the following is displayed.

```
There are no External NTP Servers.
Press return to continue...
```

ELAP Software Configuration

Add External NTP Server

The Add External NTP Server menu option 2 adds an External NTP Server. The output below is an example of the addition of an External NTP Server.

NOTE: The IP address must be a valid address for an External NTP Server.

```
Are you sure you wish to add new NTP Server? [N]: y
Enter the ELAP NTP Server IP Address: 192.168.61.69

Verifying NTP Server. It might take up to 1 minute.

External NTP Server [server 192.168.61.69 prefer]
has been added.

Press return to continue...

Verifying NTP Server. It might take up to 1 minute.
External NTP Server [server 192.102.61.91 prefer] has been added.
```

Remove External NTP Server

The Remove External NTP Server menu option 3 removes an External NTP Server. If a server is present, selecting the Remove External NTP Server removes the server. If an NTP Server is not present, the following appears.

```
There are no External NTP Servers.
Press return to continue...
```

ELAP Configure NTP Server Menu Exit

The ELAP Configure NTP Server Menu Exit menu option e exits the ELAP Configure NTP Server Menu, and returns to the ELAP Configuration Menu.

Exit

The Exit menu option e exits the ELAP Configuration menu.

ELAP Configuration Procedure

Initialization and configuration are provided through a text-based user interface (UI) described in this chapter. The user accesses the text-based configuration procedure by means of the product UI.

The first time user `elapconfig` logs into MPS A, the system performs an auto-configuration on both MPS ELAP pairs. The sync network and main and backup DSM networks are initialized to their default values, described in “Network Connections” on page 2-7 and defined in the *Installation Manual - EAGLE 5 ISS*. Various internal configuration parameters are also set to their default values. The installer must perform initial configuration on MPS A on EAGLE 5 ISS A and MPS A on EAGLE 5 ISS B.

Configuration Terms and Assumptions

- The initial configuration steps assume that each MPS has previously undergone successful Initial Platform Manufacture (IPM).
- The network paths must be present and verified before the MPS servers are ready for ELAP configuration.
- Initial configuration can be implemented on only the MPS A side of EAGLE 5 ISS A and MPS A side of EAGLE 5 ISS B. Attempting to perform initial configuration on MPS B of EAGLE 5 ISS A is not allowed, and the `elapconfig` user will be notified. The attempted configuration will be aborted with no impact on either MPS A or B.

After the initial configuration of MPS A on EAGLE 5 ISS A and MPS A on EAGLE 5 ISS B, both ELAPs should be operational unless the system failed to successfully initialize during reboot or the configured values for the Sync and/or DSM networks conflict with other equipment in the network. Tekelec recommends that you do not change the default network values.

- The provisioning values displayed for the following initialization and configuration steps are example values only.
- Default values can be accepted just by pressing the Return key at the prompt; default values are shown enclosed in brackets [].
- It is the customer's decision about the timing and frequency of performing a back-up of his databases. Of course, databases should be backed up when they are initially populated with data; however, the priority that the customer assigns to data and time lost in restoring it will dictate the frequency of database back-up.
- Adding an NTP server is optional. Additionally, only one NTP server is needed to provide time synchronization for all the MPS servers on both EAGLE 5 ISS pairs.

ELAP Software Configuration

- The ELAP terms 'local' and 'remote' are relative with respect to the ELAP configuration software. In other words, if the installer is running the configuration software on the physical MPS (that is, the MPS that the installer is physically on-site and has his terminal connected to), the configuration software refers to that MPS as 'local'. However if the installer connects through the network into the MPS A on EAGLE 5 ISS B, the configuration software executing at EAGLE 5 ISS B sees itself as 'local', referring to MPS that the installer is physically connected to as the 'remote'.

Remember that the 'local' MPS is whichever MPS A that the configuration software is being executed on, regardless of where the user is physically located.

The MPS of EAGLE 5 ISS A is the first MPS to which the installer physically connects and on which initial configuration of the ELAPs is always begun.

To avoid confusion of these relative terms, the MPS A on EAGLE 5 ISS A is considered to be the on-site MPS to which the installer has the physical connection. This document refers to the MPS to which the installer does not have the physical connection as MPS A on EAGLE 5 ISS B.

Configuration Symbols

During the Configuration Procedure, the installer will initialize and configure the MPSs to perform various functions. Special instructions are required occasionally for an MPS on EAGLE 5 ISS A, an MPS on EAGLE 5 ISS B. To assist the installer, this manual uses these symbols to indicate individual instructions to be performed for those specific MPSs.

MPS Symbol

Symbol Description



This symbol indicates installation instructions to be performed specifically for the MPSs (MPS A and MPS B) on EAGLE 5 ISS A.



This symbol indicates installation instructions to be performed specifically for the MPSs (MPS A and MPS B) on EAGLE 5 ISS B.

Initial Setup and Connecting to MPSs

Installation personnel may choose to employ various methods for connecting to an MPS. The ELAP software requires that an MPS be configured from side A. This procedure describes a likely method for connecting to EAGLE 5 ISS A and then EAGLE 5 ISS B. Installers require that all console output be captured.

Connecting to EAGLE 5 ISS A

To prepare for the configuration of the MPS on EAGLE 5 ISS A, the installer connects directly to the MPS at EAGLE 5 ISS A. Use the following method to connect to MPS B of EAGLE 5 ISS A.

1. Use the `ppp` utility to connect the modem located in the OOBM card in server A. (For information about setting up the `ppp` utility, refer to the “Dialup PPP Network” on page 2-9.
2. When the prompt appears, enter the following command to start a secure shell session with an ELAP server:

```
ssh elapconfig<server_IP_address>
```

where `<server_IP_address>` is the IP address of the MPS B at EAGLE 5 ISS A.

3. This will access the ELAP text interface. The `elapconfig` username and a password provided by your system administrator are required to continue.

Connecting to EAGLE 5 ISS B

To prepare for the configuration of the MPS on EAGLE 5 ISS B, the installer must first complete the connection to and configuration of the MPS on EAGLE 5 ISS A. The installer is then able to use a secure shell session to MPS at EAGLE 5 ISS B to configure it.

1. The installer can now use a secure shell session from the system prompt to the MPS A on EAGLE 5 ISS B, using the IP address shown in Table 5-2 on page 5-10.

```
ssh 192.168.61.119
Trying 192.168.61.119...
Connected to 192.168.61.119.
Escape character is '^]'.
```

```
SunOS 5.7
```

Procedure for Configuring ELAPs

Perform the configuration procedure by following these steps in the text-based user interface. After you have connected to an MPS (as described in “Initial Setup and Connecting to MPSs” on page 5-27), you can perform this procedure to configure the ELAPs in your network.

NOTE: Initial configuration cannot be performed through the GUI because the IP addresses required for browser connectivity are not defined until the initial configuration, using the text-based UI, is completed.

Using the set up and connection described previously, the installer connects to an MPS to perform configuration. In a typical installation, the installer connects directly to the MPS at EAGLE 5 ISS A to configure it, then uses `ssh` to connect to the MPS at EAGLE 5 ISS B and configure it.

1. After connecting to the MPS on EAGLE 5 ISS A, the installer is prompted to login. The installer must login as `elapconfig`. A note of caution appears, and the installer must evaluate them. When all the conditions of the Caution notice are satisfied, the installer presses the Return key to continue.

```
SunOS 5.7
```

```
mpsa-f0c7c3 console login: elapconfig  
Password:
```

```
Caution: This is the first login of the text user interface. Please  
review the following checklist before continuing. Failure  
to enter complete and accurate information at this time will  
have unpredictable results.
```

1. The mate MPS servers (MPS A and MPS B) must be powered on.
2. "Initial Platform Manufacture" for the mate MPS servers must be complete.
3. The sync network between the mate MPS servers must be operational.
4. You must have the correct password for the ELAPdev user on the mate MPS server.

```
Press return to continue...
```

-
2. Upon pressing Return key to continue, the installer can now abort or proceed with the initial configuration. (Note that pressing the Return key would accept the default value `n`.) To continue with the configuration, enter `y`.

```
Are you sure you wish to continue? [N]: y
```



MPS on Eagle B:

The configuration software is now being executed on the MPSs on EAGLE 5 ISS B. While the MPSs on EAGLE 5 ISS B were formerly referred to as 'remote', remember that the configuration software now considers the same MPS pair now to be 'local' (for more information, refer to the “Configuration Terms and Assumptions” section on page 5-26).

- 3. Next, the installer is prompted for the `elapdev` user password on the mate MPS server in order to confirm the secure shell keys are successfully exchanged. The example shows the output generated when the correct password is entered, the secure shell keys are successfully exchanged, and the UI database is set up on MPS A and MPS B at this site.

```

Password for ELAPdev@mate:

Keys exchanged.
Verifying that ssh works correctly.
ssh is working correctly.
Building the initial database on slave.
Building the initial database on master.
There was no elap.cfg file. Using default configuration.
Allowing access from slave.
Stopping mysql on master.
Stopping mysql on slave.
Setting up master config file.
Setting up slave config file.
Copying database to slave.
Starting MySQL on master.
Starting MySQL on slave.

```

- 4. A successful configuration file setup results in the display (for the first time) of the ELAP Configuration Menu and its associated header information. The server designation of MPS A at this site is displayed as well as `hostname`, `hostid`, `Platform Version`, `Software Version`, and the date.

```

MPS Side A:  hostname: mps-t1100-a  hostid: fd0a4767
              Platform Version: 2.0.2-4.0.0_50.26.0
              Software Version: ELAP 1.0.1-4.0.0_50.37.0
              Mon Sep 26 10:57:57 EDT 2005

```

```

/-----ELAP Configuration Menu-----\
|-----|
| 1 | Display Configuration |
|-----|
| 2 | Configure Network Interfaces Menu |
|-----|
| 3 | Set Time Zone |
|-----|
| 4 | Exchange Secure Shell Keys |
|-----|
| 5 | Change Password |
|-----|
| 6 | Platform Menu |
|-----|
| 7 | Configure NTP Server Menu |
|-----|
| e | Exit |
|-----|
\-----/

```

Enter Choice:

ELAP Software Configuration

5. Choose option 1 for Display Configuration, which provides a means of verifying ELAP A and ELAP B Provisioning Network IP addresses, the Time Zone, and other provisioning values for the MPS on EAGLE 5 ISS A.

```
MPS Side A:  hostname: mps-t1100-a  hostid: fd0a4767
              Platform Version: 2.0.2-4.0.0_50.26.0
              Software Version: ELAP 1.0.1-4.0.0_50.37.0
              Mon Sep 26 10:57:57 EDT 2005
```

```
ELAP A Provisioning Network IP Address = 192.168.61.90
ELAP B Provisioning Network IP Address = 192.168.61.91
Provisioning Network Netmask          = 255.255.255.0
Provisioning Network Default Router    = 192.168.61.250
ELAP A Backup Prov Network IP Address = Not configured
ELAP B Backup Prov Network IP Address = Not configured
Backup Prov Network Netmask           = Not configured
Backup Prov Network Default Router     = Not configured
ELAP A Sync Network Address           = 192.168.2.100
ELAP B Sync Network Address           = 192.168.2.200
ELAP A Main DSM Network Address        = 192.168.128.100
ELAP B Main DSM Network Address        = 192.168.128.200
ELAP A Backup DSM Network Address      = 192.168.129.100
ELAP B Backup DSM Network Address      = 192.168.129.200
ELAP A HTTP Port                      = 8888
ELAP B HTTP Port                      = 80
ELAP A HTTP SuExec Port                = 8001
ELAP B HTTP SuExec Port                = 8001
ELAP A Banner Connection Port          = 8473
ELAP B Banner Connection Port          = 8473
ELAP A Static NAT Address              = 10.25.50.10
ELAP B Static NAT Address              = 10.25.50.11
ELAP A LSMS Connection Port            = 7402
ELAP B LSMS Connection Port            = 7403
ELAP A EBDA Connection Port            = 1030
ELAP B EBDA Connection Port            = 1030
Time Zone                              = US/Eastern
```

Press return to continue...

-
6. Press Return to return to the ELAP Configuration Menu.
-

7. Choose option 2, Configure Network Interfaces Menu from the ELAP Configuration Menu.

```
/-----ELAP Configuration Menu-----\  
\  
1 | Display Configuration  
-----  
2 | Configure Network Interfaces Menu  
-----  
3 | Set Time Zone  
-----  
4 | Exchange Secure Shell Keys  
-----  
5 | Change Password  
-----  
6 | Platform Menu  
-----  
7 | Configure NTP Server Menu  
-----  
e | Exit  
\  
\  
/
```

Enter Choice: 2

8. Choose option 1, Configure Provisioning Network form the Configure Network Interfaces Menu.

```
/-----Configure Network Interfaces Menu----\  
\  
1 | Configure Provisioning Network  
-----  
2 | Configure Sync Network  
-----  
3 | Configure DSM Network  
-----  
4 | Configure Backup Provisioning Network  
-----  
5 | Configure Forwarded Ports  
-----  
6 | Configure Static NAT Addresses  
-----  
e | Exit  
\  
\  
/
```

Enter choice: 1

9. The Configure Provisioning Network lets the installer accept the default IP address values presented by the configuration software for ELAP A and ELAP B provisioning network and network netmask, or to enter specific IP values previously received from the customer for the MPS. Refer to the information recorded in Table 5-1 and Table 5-2 for the correct addresses.

NOTE: No default value is provided for the ELAP provisioning network default router. This value must be received from the customer.

The display for the submenu for configuring communications networks and other information shown next.

```
Verifying connectivity with mate...
Enter the ELAP A provisioning network IP Address [192.168.61.90]:
Enter the ELAP B provisioning network IP Address [192.168.61.91]:
Enter the ELAP provisioning network netmask [255.255.255.0]:
Enter the ELAP provisioning network default router IP Address:
192.168.54.250
```

Press return to continue...

10. Press the Return key, to return to the Configure Network Interfaces Menu.
-

NOTE: Note: Unless there is a known network address conflict, the installer should skip all steps related to option 2, Configure Sync Network and continue with step 15.

11. Enter option 2, Configure Sync Network from the Configure Network Interfaces Menu.

```
/-----Configure Network Interfaces Menu-----\
/-----\
| 1 | Configure Provisioning Network |
|---|-----|
| 2 | Configure Sync Network |
|---|-----|
| 3 | Configure DSM Network |
|---|-----|
| 4 | Configure Backup Provisioning Network |
|---|-----|
| 5 | Configure Forwarded Ports |
|---|-----|
| 6 | Configure Static NAT Addresses |
|---|-----|
| e | Exit |
\-----/
```

Enter choice: 2

12. A sample output follows:

```
Verifying connectivity with mate...
Enter the first 3 octets for the ELAP MPS sync Network [192.168.4]
Press return to continue...
```

13. The Installer is now able to accept or change the default values default Sync Network IP address octet values presented by the configuration software. The installer can press the Return key or, if there is a known conflict, can enter the customer-specified IP address octet values.

14. After accepting the default value or entering a specific ELAP Sync IP address octet value, the installer returns to the Configure Network Interfaces Menu.

NOTE: Unless there is a known network address conflict, the installer should skip all steps (Step 15 through Step 17) related to option 3, Configure DSM Network.

15. Choose option 3, Configure DSM Network from the Configure Network Interfaces Menu.

```

/-----Configure Network Interfaces Menu-----\
/-----\
| 1 | Configure Provisioning Network |
| 2 | Configure Sync Network |
| 3 | Configure DSM Network |
| 4 | Configure Backup Provisioning Network |
| 5 | Configure Forwarded Ports |
| 6 | Configure Static NAT Addresses |
| e | Exit |
\-----/

```

Enter choice: 3

16. The Configure DSM Network choice automatically adds the DSM network IP address to the list of known hosts. The installer should then accept default IP address octets for the ELAP main DSM network and the ELAP backup DSM network presented by the configuration software unless a known network conflict exists.

```

Verifying connectivity with mate...
Enter the first 3 octets for the ELAP main DSM network [192.168.136]:
Enter the first 3 octets for the ELAP backup DSM network [192.168.137]:

```

17. After accepting the default value or entering a specific ELAP backup DSM network octet IP address value, the installer returns to the Configure Network Interfaces Menu.

NOTE: Unless the MPS is separated from GUI workstations and provisioning systems by a port forwarding firewall, the installer should skip all steps related to option 5. Proceed to step 22.

18. Choose option 5, Configure Forwarded Ports from the Configure Network Interfaces Menu.

```
/-----Configure Forwarded Ports Menu-----\  
/-----\  
 1 | Change ELAP A HTTP Port  
-----  
 2 | Change ELAP B HTTP Port  
-----  
 3 | Change ELAP A HTTP SuExec Port  
-----  
 4 | Change ELAP B HTTP SuExec Port  
-----  
 5 | Change ELAP A Banner Connection Port  
-----  
 6 | Change ELAP B Banner Connection Port  
-----  
 7 | Change ELAP A LSMS Connection Port  
-----  
 8 | Change ELAP B LSMS Connection Port  
-----  
 9 | Change ELAP A EBDA Connection Port  
-----  
10 | Change ELAP B EBDA Connection Port  
-----  
 e | Exit  
-----\  
Enter choice: 5
```

19. Enter the correct option number for the port information to be entered. Refer to the information recorded in Table 5-1 and Table 5-2 for the correct information.

NOTE: The LSMS is not capable of changing the LSMS/EBDA ports it can connect to on the MPS. Therefore, the default values for options 7 through 10 on the Configure Forwarded Ports Menu should not be changed.

```
ELAP A HTTP Port [80]:
```

20. Enter the appropriate information. Press return once to return to the Configure Forwarded Ports Menu.

21. Enter the option number or enter e to return to the Configure Network Interfaces Menu.

22. The installer returns to the Configure Network Interfaces Menu.

23. Choose option **6**, Configure Static NAT Addresses from the Configure Network Interfaces Menu.

```
/-----Configure Network Interfaces Menu-----\  
/-----\  
1 | Configure Provisioning Network  
-----  
2 | Configure Sync Network  
-----  
3 | Configure DSM Network  
-----  
4 | Configure Backup Provisioning Network  
-----  
5 | Configure Forwarded Ports  
-----  
6 | Configure Static NAT Addresses  
-----  
e | Exit  
-----\  
\-----\  
/-----
```

Enter choice: 6

24. Enter option **1** or **2** Configure Static NAT Addresses Menu. Each numbered item of the Configure Static NAT Addresses Menu allows the user to specify an IP Address used outside of the firewall for remote access to the MPS. The following table shows an example of a resulting prompt.

```
/-----Configure Static NAT Addresses Menu-----\  
/-----\  
1 | Change ELAP A Static NAT Address  
-----  
2 | Change ELAP B Static NAT Address  
-----  
e | Exit  
-----\  
\-----\  
/-----
```

25. Enter a valid NAT IP address from Table 5-1 or Table 5-2.

ELAP A Static NAT Address:

26. Choose option **e** on the Configure Static NAT Addresses Menu to return to the Configure Network Interfaces Menu.

27. Choose option **e**, Exit from the Configure Network Interfaces Menu to return to the ELAP Configuration Menu.

ELAP Software Configuration

NOTE: Obtain the value for the time zone from the customer's Information Services department. The default value for the time zone is "US/Eastern". If the time zone was correct for this installation, as shown in the output of the Display Configuration (step 5), the installer can skip this menu option 3. Proceed to Step 31.

28. Choose option 3, Set Time Zone on the ELAP Configuration Menu.

```

/-----ELAP Configuration Menu-----\
| 1 | Display Configuration              |
|---|-----|
| 2 | Configure Network Interfaces Menu |
|---|-----|
| 3 | Set Time Zone                     |
|---|-----|
| 4 | Exchange Secure Shell Keys       |
|---|-----|
| 5 | Change Password                   |
|---|-----|
| 6 | Platform Menu                    |
|---|-----|
| 7 | Configure NTP Server Menu         |
|---|-----|
| e | Exit                              |
\-----|

```

Enter Choice: 3

29. An important Caution statement is displayed. After noting the caution, press the Return key to continue.

```

Caution: This action requires a reboot of the affected MPS servers to
          activate the change. Operation of the ELAP software before
          the MPS servers are rebooted may have unpredictable
          consequences.

```

Press return to continue...

30. The installer is prompted for confirmation on setting the time zone for MPS A and MPS B at his site. The installer enters **y** to confirm the change. (Pressing the Return key accepts the default of 'N' (or no) and the action is aborted. In this case, the installer returns to the ELAP Configuration Menu.)

```

Are you sure you wish to change the timezone for MPS A and B? [N]: y

```

When the affirmative response **y** is given to change the time zone, the following prompt is displayed. The time zone can be the zone where the ELAP is located, Greenwich Mean Time, or another zone that is selected by the customer to meet the needs of the system. If the time zone is known, it can be entered at the prompt. If the exact time zone value is not known, just press the Return key, and a list of the valid names is displayed.

```

Enter a time zone file (relative to /usr/share/lib/zoneinfo):

```

(This list of valid time zones is also in Appendix A, Time Zone File Names.)

If an incorrect time zone is entered or if only the Return key is pressed, a list of all available time zone values is displayed. The installer can select a value from this table.

The time zone change does not take effect until the next time the MPS is rebooted.

31. After setting the time zone successfully, the installer is returned to the ELAP Configuration Menu.

NOTE: Option 4, Exchange Secure Shell Keys, is successfully performed automatically by the configuration software at the start of configuration. (The configuration software would not have proceeded to this point if the exchange had not been successful.)

Therefore, the installer may normally skip this step and continue with the next configuration option; proceed to step 36.

32. Enter option 4, Exchange Secure Shell Keys, from the ELAP Configuration Menu.

```

/-----ELAP Configuration Menu-----\
/-----\
 1 | Display Configuration
 2 | Configure Network Interfaces Menu
 3 | Set Time Zone
 4 | Exchange Secure Shell Keys
 5 | Change Password
 6 | Platform Menu
 7 | Configure NTP Server Menu
  e | Exit
\-----/

```

Enter Choice: 4

33. The following is output.

Are you sure you wish to exchange keys? [N]: y

34. The following is output. The installer is notified that secure shell keys have already been exchanged.

```

Verifying connectivity with mate...

Caution: Secure shell keys have already been exchanged between this MPS
          server and its mate. Secure shell is working properly.

Press return to continue...

```

35. Pressing the Return key brings up a prompt requiring confirmation to continue with the exchange. Pressing the Return key at this confirmation prompt defaults to 'N' or 'no', and the exchange action is aborted. Entering **y** confirms the exchange, and the installer is prompted for the password of the mate. (Contact the Customer Care Center for the password; refer to “Customer Assistance” on page 1-10.)

After entering the appropriate password, a verification of the exchange is displayed. The installer is returned to the ELAP Configuration Menu.

```
Are you sure you wish to exchange keys with the mate? [N]: y
Password for ELAPdev@mate:
Keys exchanged.
Verifying that ssh works correctly.

ssh is working correctly.
```

NOTE: If required by the customer to change the text-based UI password for the MPSs at this site, the installer selects option 5, Change Password. Otherwise, this step can be skipped, and the installer can proceed to step 39.

36. Enter option 5, Change Password, from the ELAP Configuration Menu to change the text-based user interface password for the `elapconfig` login name for both MPS A and B at this site.

```
/{-----ELAP Configuration Menu-----}\
| 1 | Display Configuration                |
|-----|
| 2 | Configure Network Interfaces Menu    |
|-----|
| 3 | Set Time Zone                       |
|-----|
| 4 | Exchange Secure Shell Keys         |
|-----|
| 5 | Change Password                    |
|-----|
| 6 | Platform Menu                     |
|-----|
| 7 | Configure NTP Server Menu          |
|-----|
| e | Exit                               |
|-----|
```

```
Enter Choice: 5
```

37. The installer is prompted to confirm the action of changing the password for both the MPS A and MSP B servers at this site. Pressing the Return key accepts the default of 'N' or 'no,' and aborts the action to the change the password.

Entering **y** invokes a prompt for the new password, followed by the re-entry of the password to confirm the entry.

```
Verifying connectivity with mate...
Are you sure you wish to change the text UI password on MPS A and B? [N]: y
Enter new password for text UI user:
Re-enter new password:

Press return to continue ...
```

38. Successful entry of the new password returns the installer to the ELAP Configuration Menu.

NOTE: If an NTP server does not need to be added at this time, the installer can skip all steps related to option 7 Configure NTP Server Menu, and proceed to step 44.

39. Enter option 7, Configure NTP Server Menu, from the ELAP Configuration Menu to add an NTP Server.

```

/-----ELAP Configuration Menu-----\
| 1 | Display Configuration              |
| 2 | Configure Network Interfaces Menu |
| 3 | Set Time Zone                    |
| 4 | Exchange Secure Shell Keys      |
| 5 | Change Password                 |
| 6 | Platform Menu                   |
| 7 | Configure NTP Server Menu       |
| e | Exit                             |
\-----\

```

Enter Choice: 7

40. Enter option 2, Add External NTP Server from the ELAP Configure NTP Server Menu.

```

/-----ELAP Configure NTP Server Menu-----\
| 1 | Display External NTP Server      |
| 2 | Add External NTP Server         |
| 3 | Remove External NTP Server     |
| e | Exit                             |
\-----\

```

Enter Choice: 2

41. Now the installer is prompted to confirm the action of adding a new NTP Server. (Pressing Return would accept the default of 'N' or 'no', and would abort the action to add an external NTP server.) Instead, the installer enters y, which invokes a prompt where the IP address of the NTP server is added, as shown below.



MPS on Eagle B:

The installer should now enter the same IP address for the NTP server that was previously added to the MPS A and B servers on EAGLE 5 ISS A. This action allows the one NTP server to keep all MPS servers in synchronization.

ELAP Software Configuration

```
Are you sure you wish to add new NTP Server? [N]: y
Enter the ELAP NTP Server IP Address: 192.168.61.69

Verifying NTP Server. It might take up to 1 minute.

External NTP Server [server 192.168.61.69 prefer]
has been added.

Press return to continue...

Verifying NTP Server. It might take up to 1 minute.
External NTP Server [server 192.102.61.91 prefer] has been added.

Press return to continue...
```

NOTE: All NTP Server IP addresses shown are only examples.

The display shows the server verification occurring. The installer receives a confirmation of a successful addition of the NTP server. The installer presses the Return key and returns to the ELAP Configure NTP Server Menu.

42. Enter option 1, Display External NTP Server from the ELAP Configure NTP Server Menu, to confirm successful addition of the NTP server.

```
/-----ELAP Configure NTP Server Menu-----\
| 1 | Display External NTP Server                |
| 2 | Add External NTP Server                    |
| 3 | Remove External NTP Server                |
| e | Exit                                        |
\-----/
```

Enter Choice: 1

43. The following output is displayed. Verify that the External NTP Server IP address is correct.

```
External NTP Server [server 192.168.61.69 prefer ]
Press return to continue...
```

44. Press the Return key to return to the ELAP Configure NTP Server Menu.

45. Enter option **e** to exit the ELAP Configure NTP Server Menu and return to the ELAP Configuration Menu.

```
/-----ELAP Configure NTP Server Menu-----\  
\  
1 | Display External NTP Server  
-----  
2 | Add External NTP Server  
-----  
3 | Remove External NTP Server  
-----  
e | Exit  
\  
-----
```

Enter Choice: e

46. The installer is returned to the ELAP Configuration Menu, as shown below.

NOTE: During configuration fo MPSs on EAGLE 5 ISS B, if the time zone was not changed (step 28) and if the Backup Provisioning Network (step 18) was not configured on either MPS, the ELAP initial configuration of MPSs on EAGLE 5 ISS B is now complete.

Otherwise the installer must continue with this step because both MPS pairs on EAGLE 5 ISS A and on EAGLE 5 ISS B must now be rebooted.

47. Enter option **6**, Platform Menu from the ELAP Configuration Menu.

```
/-----ELAP Configuration Menu-----\  
\  
1 | Display Configuration  
-----  
2 | Configure Network Interfaces Menu  
-----  
3 | Set Time Zone  
-----  
4 | Exchange Secure Shell Keys  
-----  
5 | Change Password  
-----  
6 | Platform Menu  
-----  
7 | Configure NTP Server Menu  
-----  
e | Exit  
\  
-----
```

Enter Choice: 6

48. Enter option 3, Reboot MPS, from the ELAP Platform Menu.

```
/-----ELAP Platform Menu-\  
/-----\  
| 1 | Initiate Upgrade |  
|---|-----|  
| 2 | Eject CD |  
|---|-----|  
| 3 | Reboot MPS |  
|---|-----|  
| 4 | Halt MPS |  
|---|-----|  
| 5 | MySQL Backup |  
|---|-----|  
| 6 | RTDB Backup |  
|---|-----|  
| e | Exit |  
|---|-----|  
\-----\  
  
Enter Choice: 3
```

49. The installer is prompted on whether MPS A, MPS B or BOTH sides are to be rebooted. The correct response is to select the default value of **BOTH**. Use the Return key to select both MPS A and MPS B.

```
Reboot MPS A, MPS B or [BOTH]:
```

50. When the rebooting of the present MPS server pair on EAGLE 5 ISS B ends, the Platform Menu may re-appear; however, the connection to the MPS server will be closed, and the installer is returned to the system prompt.

51. The console logon appears at the system prompt signifying the ELAP initial configuration is complete.

NOTE: The console logon will be preceded by many lines of reboot output.



MPS on Eagle B:

The initial configuration of MPSs on EAGLE 5 ISS B is now complete. Both MPSs on EAGLE 5 ISS A and MPSs on B are now configured and rebooted.

A

Time Zone File Names

This appendix lists the valid UNIX file names, from the `/usr/share/lib/zoneinfo` directory, for setting the time zone in ELAP software configuration. The initial default value for the time zone is “US/Eastern”.

africa	EET	Etc/GMT-9
asia	Egypt	etcetera
australasia	Eire	europa
Australia/ACT	EST	factory
Australia/Broken_Hill	EST5EDT	Factory
Australia/LHI	Etc/GMT	GB
Australia/North	Etc/GMT+0	GB-Eire
Australia/NSW	Etc/GMT+1	GMT
Australia/Queensland	Etc/GMT+10	GMT+0
Australia/South	Etc/GMT+11	GMT+1
Australia/Tasmania	Etc/GMT+12	GMT+10
Australia/Victoria	Etc/GMT+2	GMT+11
Australia/West	Etc/GMT+3	GMT+12
Australia/Yancowinna	Etc/GMT+4	GMT+13
backward	Etc/GMT+5	GMT+2
Brazil/Acre	Etc/GMT+6	GMT+3
Brazil/DeNoronha	Etc/GMT+7	GMT+4
Brazil/East	Etc/GMT+8	GMT+5
Brazil/West	Etc/GMT+9	GMT+6
Canada/Atlantic	Etc/GMT-0	GMT+7
Canada/Central	Etc/GMT-1	GMT+8
Canada/Eastern	Etc/GMT-10	GMT+9

Time Zone File Names

Canada/East-Saskatchewan	Etc/GMT-11	GMT-0
Canada/Mountain	Etc/GMT-12	GMT-1
Canada/Newfoundland	Etc/GMT-13	GMT-10
Canada/Pacific	Etc/GMT-2	GMT-11
Canada/Yukon	Etc/GMT-3	GMT-12
CET	Etc/GMT-4	GMT-2
Chile/Continental	Etc/GMT-5	GMT-3
Chile/EasterIsland	Etc/GMT-6	GMT-4
CST6CDT	Etc/GMT-7	GMT-5
Cuba	Etc/GMT-8	GMT-6
GMT-7	Mideast/Riyadh89	Turkey
GMT-8	MST	UCT
GMT-9	MST7MDT	Universal
Greenwich	Navajo	US/Alaska
Hongkong	northamerica	US/Aleutian
HST	NZ	US/Arizona
Iceland	NZ-CHAT	US/Central
Iran	pacificnew	US/Eastern
Israel	Poland	US/East-Indiana
Jamaica	Portugal	US/Hawaii
Japan	PRC	US/Michigan
Kwajalein	PST8PDT	US/Mountain
Libya	ROC	US/Pacific
MET	ROK	US/Pacific-New
Mexico/BajaNorte	Singapore	US/Samoa
Mexico/BajaSur	solar87	UTC
Mexico/General	solar88	WET
Mideast/Riyadh87	solar89	W-SU
Mideast/Riyadh88	southamerica	Zulu

B

ELAP Local Provisioning Utility

Introduction.....	B-2
LPU Commands	B-2
Update Commands.....	B-2
upd_inp_sub	B-2
upd_inp_npanxx	B-5
upd_inp_lrn	B-8
upd_split_npa	B-12
Delete Commands.....	B-13
dlt_inp_sub	B-13
dlt_inp_npanxx.....	B-14
dlt_inp_lrn	B-15
dlt_split_npa	B-15
Retrieve Commands	B-16
rtrv_inp_sub	B-16
Miscellaneous Commands.....	B-17
set_echo.....	B-17
set_cont_wo_remote.....	B-18
Common Information	B-18
Success message	B-18
Error message format	B-18

Service parameters within error messages	B-18
Missing mandatory parameter	B-18
Communication errors.....	B-19
Perl errors	B-20
Perl Statements and Functions	B-20
#	B-20
foreach	B-20
print.....	B-21
scalar localtime	B-21
eval	B-21

Introduction

This chapter provides user guide information for the ELAP Local Provisioning Utility (LPU) batch command language.

LPU Commands

For each command listed in this section, the following information is given:

- A description of the command
- The command syntax
- A description of the command parameters
- An example of the command usage
- Rules, dependencies, and notes relevant to the command
- A list of related commands

Update Commands

upd_lnp_sub

Update LNP 10-Digit Subscription

Use this command to enter or change LNP 10-digit telephone number (TN) subscription or pooled TN's along with related services in the database.

ELAP Local Provisioning Utility

Related services refer to message relay global title information. If the TN already exists, then the newly input data replaces the existing data. This command automatically creates the NPANXX for a TN-LRN record if the NPANXX does not already exist. It also creates an SP for a specified SP that does not already exist. The command updates data normally administered from the NPAC. Pooled TN's are allocated on an even 1000-block boundary. Specific ported TN's may overlap a pooled block and contain different routing.

Keyword

upd_lnp_sub

Parameters

TN=> (mandatory)

The telephone number.

Range = To specify a single TN subscription: 10 decimal digits

To pool a block of 1000 TNs: 7 digits with 3 asterisks (***) appended

SP=> (mandatory)

Service provider ID.

Range = 1-4 alphanumeric characters

LRN=> (mandatory)

The new location routing number.

Range = 10 decimal digits

CLASS_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for CLASS MR GTT.

Range = ni 001-255

nc 001-255 (if ni = 001-005)

000-255 (if ni = 006-255)

ncm 000-255

Default = Null

CLASS_SSN=> (optional)

Subsystem number for CLASS MR GTT

Range = 0, 2-255

Default = Null

LIDB_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for LIDB MR GTT.

Range = ni 001-255

nc 001-255 (if ni = 001-005)

000-255 (if ni = 006-255)

ncm 000-255

Default = Null

LIDB_SSN=> (optional)

Subsystem number for LIDB MR GTT

Range = 0, 2-255**Default = Null****ISVM_DPC=> (optional)**ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for ISVM MR GTT.**Range = ni 001-255****nc 001-255 (if ni = 001-005)****000-255 (if ni = 006-255)****ncm 000-255****Default = Null****ISVM_SSN=> (optional)**

Subsystem number for ISVM MR GTT

Range = 0, 2-255**Default = Null****CNAM_DPC=> (optional)**ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for CNAM MR GTT.**Range = ni 001-255****nc 001-255 (if ni = 001-005)****000-255 (if ni = 006-255)****ncm 000-255****Default = Null****CNAM_SSN=> (optional)**

Subsystem number for CNAM MR GTT

Range = 0, 2-255**Default = Null****Examples**

Individual TN:

```
upd_inp_sub (TN => '1234567890', SP => 'A123', LRN => '1234567890',
CLASS_DPC => '233-233-233', CLASS_SSN => '0');
```

TN Pool

```
upd_inp_sub (TN => '1234567***', SP => 'A123', LRN => '1234567890',
CLASS_DPC => '233-233-233', CLASS_SSN => '2');
```

Command Rules

The TN parameter must be 10 decimal digits or 7 decimal digits followed by 3 *s.

SP parameter must be 1-4 numbers/letters.

LRN parameter must be 10 decimal digits.

ELAP Local Provisioning Utility

xxxxx_DPC parameter must be a valid ANSI DPC.

A service's **DPC** and **SSN** parameters must be specified together or not at all.

If the **LRN** parameter already exists, the **SP** parameter must be the same as the existing one for the **LRN** parameter.

Related Commands

dlt_lnp_sub, rtrv_lnp_sub

upd_lnp_npanxx

Update LNP NPANXX

Use this command to enter or change an existing LNP NPANXX record, including an LNP query or message relay default global title translation in the database.

The upd_lnp_npanxx command allows the user to enter or to change an LNP NPANXX and its associated LNP default global title translations in(to) the database. If the NPANXX already exists, then the newly input data replaces the existing data.

Keyword

upd_lnp_npanxx

Parameters

NPANXX=> (mandatory)

Block of 10,000 numbers.

Range = 6 digits

AIN=> (mandatory)

Local Advanced Intelligent Network (AIN) indicator.

Range = Y, N

IN=> (mandatory)

Local Intelligent Network (IN) indicator.

Range = Y, N

CLASS_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for CLASS Default GTT.

Range = ni 001-255

nc 001-255 (if ni = 001-005)

000-255 (if ni = 006-255)

ncm 000-255

Default = Null

CLASS_SSN=> (optional)

Subsystem number for CLASS Default GTT.

Range = 0, 2-255

Default = Null

CLASS_RI=> (optional)

Routing Indicator for CLASS Default GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

CLASS_NEWTT=> (optional)

New Translation Type for CLASS Default GTT.

Range = 0-255

Default = Null

LIDB_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for LIDB Default GTT.

Range = ni 001-255

nc 001-255 (if *ni = 001-005*)

000-255 (if *ni = 006-255*)

ncm 000-255

Default = Null

LIDB_SSN=> (optional)

Subsystem number for LIDB Default GTT

Range = 0, 2-255

Default = Null

LIDB_RI=> (optional)

Routing Indicator for LIDB Default GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

LIDB_NEWTT=> (optional)

New Translation Type for LIDB Default GTT.

Range = 0-255

Default = Null

ISVM_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for ISVM Default GTT.

Range = ni 001-255

nc 001-255 (if *ni = 001-005*)

000-255 (if *ni = 006-255*)

ncm 000-255

Default = Null

ELAP Local Provisioning Utility

ISVM_SSN=> (optional)

Subsystem number for ISVM Default GTT

Range = 0, 2-255

Default = Null

ISVM_RI=> (optional)

Routing Indicator for ISVM Default GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

ISVM_NEWTT=> (optional)

New Translation Type for ISVM Default GTT.

Range = 0-255

Default = Null

CNAM_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for CNAM Default GTT.

Range = ni 001-255

nc 001-255 (if ni = 001-005)

000-255 (if ni = 006-255)

ncm 000-255

Default = Null

CNAM_SSN=> (optional)

Subsystem number for CNAM Default GTT

Range = 0, 2-255

Default = Null

CNAM_RI=> (optional)

Routing Indicator for CNAM Default GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

CNAM_NEWTT=> (optional)

New Translation Type for CNAM Default GTT.

Range = 0-255

Default = Null

Example

```
upd_lnp_npanxx (NPANXX => '123456', AIN => 'Y', IN => 'Y', CLASS_DPC =>
'233-233-233', CLASS_SSN => '0', CLASS_RI => 'G', CLASS_NEWTT => '71');
```

```
upd_lnp_npanxx (NPANXX => '234567', AIN => 'N', IN => 'N', CLASS_DPC =>
'33-23-33', CLASS_SSN => '72', CLASS_RI => 'D', CLASS_NEWTT => '0');
```

Command Rules

NPANXX parameter must be 6 decimal digits.

AIN parameter must be **Y** (for Yes) or **N** (for No).

IN parameter must be **Y** (for Yes) or **N** (for No).

xxxxx_DPC parameter must be a valid ANSI DPC.

A service's **DPC**, **SSN**, **RI**, and **NEWTT** parameters must be specified together or not at all.

xxxxx_RI parameter must be **G** (for GT) or **D** (for DPC/SSN).

xxxxx_NEWTT parameter must be 0-255, inclusive.

A service's **NEWTT** parameter must be 0 unless its **RI** parameter is **G** and its **SSN** parameter is **0**.

Notes

XXXX_RI => G is for an outgoing CDPA routing indicator of Route on Global Title.

XXXX_RI => D is for an outgoing CDPA routing indicator of Route on DPC/SSN.

Table B-1. Mapping EAGLE 5 ISS to upd_lnp_npanxx LPU Command

EAGLE 5 ISS XLAT	EAGLE 5 ISS RI	EAGLE 5 ISS SSN	EAGLE 5 ISS NGT	LPU RI	LPU SSN	LPU NEWTT
DPC	GT	-	-	G	0	0
DPC	SSN	-	-	D	0	0
DPCSSN	GT	0-255	-	G	2-255	0
DPCSSN	SSN	0-255	-	D	2-255	0
DPCNGT	GT	-	0-255	G	0	1-255

Related Commands

dlt_lnp_npanxx

upd_lnp_lrn

Update LNP Location Routing Number

Use this command to enter or change existing location routing number (LRN) specific information in the database.

This command allows the user to enter or to change an LNP Location Routing Number and its associated LNP message relay override global title translations in(to) the database. If the LRN already exists, then the newly input data replaces the existing data.

Keyword

upd_lnp_lrn

Parameters

LRN=> (mandatory)

The location routing number.

Range = 10 decimal digits

SP=> (mandatory)

Service provider ID.

Range = 1-4 alphanumeric characters

CLASS_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for CLASS MR Override GTT.

Range = *ni* **001-255**

nc **001-255 (if ni = 001-005)**

000-255 (if ni = 006-255)

ncm **000-255**

Default = Null

CLASS_SSN=> (optional)

Subsystem number for CLASS MR Override GTT.

Range = **0, 2-255**

Default = Null

CLASS_RI=> (optional)

Routing Indicator for CLASS MR Override GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

 D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

CLASS_NEWTT=> (optional)

New Translation Type for CLASS MR Override GTT.

Range = 0-255

Default = Null

CLASS_RGTA=> (optional)

Replace Global Title Address (TN) with LRN for CLASS MR Override GTT.

Range = Y, N

Default = Null

LIDB_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for LIDB MR Override GTT.

Range = *ni* **001-255**

nc **001-255 (if ni = 001-005)**

000-255 (if ni = 006-255)

ncm **000-255**

Default = Null

LIDB_SSN=> (optional)

Subsystem number for LIDB MR Override GTT

Range = 0, 2-255

Default = Null

LIDB_RI=> (optional)

Routing Indicator for LIDB MR Override GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

LIDB_NEWTT=> (optional)

New Translation Type for LIDB MR Override GTT.

Range = 0-255

Default = Null

LIDB_RGTA=> (optional)

Replace Global Title Address (TN) with LRN for LIDB MR Override GTT.

Range = Y, N

Default = Null

ISVM_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for ISVM MR Override GTT.

Range = ni 001-255

nc 001-255 (if *ni = 001-005*)

000-255 (if *ni = 006-255*)

ncm 000-255

Default = Null

ISVM_SSN=> (optional)

Subsystem number for ISVM MR Override GTT

Range = 0, 2-255

Default = Null

ISVM_RI=> (optional)

Routing Indicator for ISVM MR Override GTT.

Range = G (the outgoing CDPA routing indicator of Route on Global Title)

D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

ISVM_NEWTT=> (optional)

New Translation Type for ISVM MR Override GTT.

Range = 0-255

Default = Null

ISVM_RGTA=> (optional)

Replace Global Title Address (TN) with LRN for ISVM MR Override GTT.

Range = Y, N

Default = Null

ELAP Local Provisioning Utility

CNAM_DPC=> (optional)

ANSI destination point code in the form of *network indicator-network cluster-network cluster member (ni-nc-ncm)* for CNAM MR Override GTT.

Range = *ni* **001-255**
 nc **001-255** (if *ni* = **001-005**)
 000-255 (if *ni* = **006-255**)
 ncm **000-255**

Default = Null

CNAM_SSN=> (optional)

Subsystem number for CNAM MR Override GTT

Range = **0, 2-255**

Default = Null

CNAM_RI=> (optional)

Routing Indicator for CNAM MR Override GTT.

Range = **G** (the outgoing CDPA routing indicator of Route on Global Title)
 D (the outgoing CDPA routing indicator of Route on DPC/SSN)

Default = Null

CNAM_NEWTT=> (optional)

New Translation Type for CNAM MR Override GTT.

Range = **0-255**

Default = Null

CNAM_RGTA=> (optional)

Replace Global Title Address (TN) with LRN for CNAM MR Override GTT.

Range = **Y, N**

Default = Null

Example

```
upd_inp_lrn (LRN => '1234567890', SP => 'A123', CLASS_DPC => '233-233-233',  
CLASS_SSN => '0', CLASS_RI => 'G', CLASS_NEWTT => '71', CLASS_RGTA  
=> 'Y');
```

```
upd_inp_lrn (LRN => '1234567890', SP => 'A123', CLASS_DPC => '33-23-33',  
CLASS_SSN => '72', CLASS_RI => 'D', CLASS_NEWTT => '0', CLASS_RGTA  
=> 'Y');
```

Command Rules

The **LRN** parameter must be 10 decimal digits.

The **SP** parameter must be 1-4 numbers/letters.

The **xxxxx_DPC** parameter must be a valid ANSI DPC.

The **xxxxx_RI** parameter must be **G** (for GT) or **D** (for DPC/SSN).

The **xxxxx_NEWTT** parameter must be 0-255, inclusive.

The **xxxx_RGTA** parameter must be **Y** (for Yes) or **N** (for No).

A service's **DPC**, **SSN**, **RI**, **NEWTT**, and **RGTA** parameters must be specified together or not at all.

A service's **NEWTT** parameter must be 0 unless its **RI** parameter is **G** and its **SSN** parameter is **0**.

At least one service must be specified

If the **LRN** parameter already exists, the **SP** parameter must be the same as the existing one for the **LRN** parameter.

Notes

XXXX_RI => G is for an outgoing CDPA routing indicator of Route on Global Title.

XXXX_RI => D is for an outgoing CDPA routing indicator of Route on DPC/SSN.

Table B-2. Mapping EAGLE 5 ISS to upd_lnp_lrn LPU Command

EAGLE 5 ISS XLAT	EAGLE 5 ISS RI	EAGLE 5 ISS SSN	EAGLE 5 ISS NGT	LPU RI	LPU SSN	LPU NEWTT
DPC	GT	-	-	G	0	0
DPC	SSN	-	-	D	0	0
DPCSSN	GT	0-255	-	G	2-255	0
DPCSSN	SSN	0-255	-	D	2-255	0
DPCNGT	GT	-	0-255	G	0	1-255

RGTA is not in the Table because it maps directly and is independent of the other parameters.

Related Commands

dlt_lnp_lrn

upd_split_npa

Update Split NPANXX

Use this command to force two different NPANXXs to reference the same last 4-digit telephone number (TN) in the database. During this time, updates to either NPANXX will update the same last 4-digit entry of a 10-digit ported TN. All existing NPANXX data is copied automatically to the new NPANXX for the split. It does not matter if the old block is specified as NNPANXX and the new is specified as NPANXX (i.e. the parameters are switched); they will still point to the same set of last 4 digits.

Keyword

upd_split_npa

Parameters

NPANXX=> (mandatory)

Block of 10,000 numbers.

Range = 6 digits

NNPANXX=> (mandatory)

New NPANXX.

Range = 6 digits

Example

upd_split_npa (NPANXX => '123456', NNPANXX => '234567');

Command Rules

NPANXX parameter must be 6 decimal digits.

NNPANXX parameter must be 6 decimal digits.

The NPANXX parameter must not already be split.

The new block cannot have any existing TNs.

The new block cannot be the same as the old.

The new block cannot have non-null service data that does not match the service data for the old block.

Related Commands

dlt_split_npa

Delete Commands

dlt_lnp_sub

Delete LNP 10-Digit Telephone Number Subscription

This command is used to remove an LNP 10-digit ported telephone number (TN) or a Pooled Block of 1000 TN's along with its related services from the database. Related services refer to message relay global title information. This command deletes data normally administered from the NPAC.

Keyword

dlt_lnp_sub

Parameters

TN=> (mandatory)

The telephone number.

Range = To specify a single TN subscription: 10 decimal digits

To pool a block of 1000 TNs: 7 digits with 3 asterisks (***) appended

Examples

Individual TN:

```
dlt_lnp_sub (TN => '1234567890');
```

TN Pool

```
dlt_lnp_sub (TN => '1234567***');
```

Command Rules

The TN parameter must be 10 decimal digits or 7 decimal digits followed by 3 *s.

Notes

No error message when the TN parameter does not exist.

Related Commands

upd_lnp_sub, rtrv_lnp_sub

dlt_lnp_npanxx**Delete LNP Numbering Plan and Exchange**

This command is used to delete an LNP numbering plan area and exchange (NPANXX) and its associated LNP query or message relay default global title translations from the database.

Keyword

dlt_lnp_npanxx

Parameters

NPANXX=> (mandatory)

Block of 10,000 numbers.

Range = 6 digits

Example

```
dlt_lnp_npanxx (NPANXX => '123456');
```

Command Rules

The NPANXX parameter must be 6 decimal digits.

The NPANXX parameter cannot be part of a NPA split.

The NPANXX parameter cannot be part of a ported TN.

Notes

No error message when the NPANXX parameter does not exist.

Related Commands

upd_lnp_npanxx

dlt_inp_lrn

Delete LNP Location Routing Number

Use this command to delete an existing location routing number (LRN) and its corresponding final overriding message relay global title translations from the database. The LRN can only be deleted if it is not referenced by a 10-digit telephone number.

Keyword

dlt_inp_lrn

Parameters

LRN=> (mandatory)

The location routing number.

Range = 10 decimal digits

Example

```
dlt_inp_lrn (LRN => '1234567890');
```

Command Rules

The LRN parameter must be 10 decimal digits.

Notes

No error message when LRN parameter does not exist.

Related Commands

upd_inp_lrn

dlt_split_npa

Delete Split NPANXX

Use this command to remove the NPANXX from the database. This command allows the user to remove 1 of the 2 different NPANXXs referencing the same last 4 digits of TN in the database.

Keyword

dlt_split_npa

Parameters

NPANXX=> (mandatory)

Block of 10,000 numbers.

Range = 6 digits

Example

```
dlt_split_npa (NPANXX => '123456');
```

Command Rules

The NPANXX parameter must be 6 decimal digits.

The NPANXX parameter must be part of NPA split.

Notes

None

Related Commands

upd_split_npa

Retrieve Commands**rtrv_lnp_sub****Retrieve LNP 10-digit Subscription**

Use this command to retrieve LNP 10 digit ported TN or a single Pooled Block of 1000 TN's along with related services from the database. Related services refer to message relay global title information. The command retrieves data normally administered from the NPAC.

Keyword

rtrv_lnp_sub

Parameters

TN=> (mandatory)

The telephone number.

Range = To specify a single TN subscription: 10 decimal digits

To pool a block of 1000 TNs: 7 digits with 3 asterisks (***) appended

Example

Individual TN:

```
rtrv_lnp_sub (TN => '1234567890');
```

TN Pool:

```
rtrv_lnp_sub (TN => '1234567***');
```

Command Rules

The TN parameter must be 10 decimal digits or 7 decimal digits followed by 3 *s.

Notes

None

Related Commands

upd_lnp_sub, dlt_lnp_sub

ELAP Local Provisioning Utility

Output

Found:

```
TN = 2345678000
LRN = 0123456789
SP = oc1
```

Service	TT	DPC	SSN	RI	NEWT
CLASS	3	001-001-001	0	G	0
ISVM	6	001-002-003	4	D	---

```
TN = 2345000***
LRN = 0123456789
SP = oc1
```

Service	TT	DPC	SSN	RI	NEWT
CLASS	3	001-001-001	0	G	0
ISVM	6	001-002-003	4	D	---

Not Found:

```
TN 9195551234 not found.
```

Miscellaneous Commands

set_echo

This command is used to Turn on or off the output of calls to commands.

Example

```
set_echo(1);
dlt_lnp_sub(TN => '9195551234');
set_echo(0);
dlt_lnp_sub(TN => '9195554321');
```

Outputs

```
Processing dlt_lnp_sub (
  TN => '9195551234',
)
Done.
```

set_cont_wo_remote

This command is used to turn on or off the ability to continue to execute commands in the face of no connection to the remote LSMS port.

Example

```
set_cont_wo_remote(1);
```

Common Information

The following sub-sections highlight messages, formats, templates, and errors that are not specific to particular batch commands.

Success message

The following message is output when a batch file is successfully executed:

```
SUCCESS: The LPU batch file has been successfully executed.
```

Error message format

All command errors will follow the following format:

```
E1074: LPU batch failure: Batch Error: Message text at
/export/home/elapall/LPU_batch line x
```

Message text will be replaced with the message text associated with the rule as provided in the command details.

x will be replaced with the line number within the batch file where the error occurred.

Service parameters within error messages

When a service parameter is specified in the error message texts, a template is used to avoid repeating the message text for each possible service.

The templates are as follows:

- xxxx_DPC
- xxxx_SSN
- xxxx_RI
- xxxx_NEWTT
- xxxx_RGTA

xxxx will be replaced with the appropriate service's mnemonic (e.g. CLASS, LIDB, ISVM, or CNAM)

Missing mandatory parameter

For all commands, the message text for a missing mandatory parameter is the following:

ELAP Local Provisioning Utility

Missing mandatory argument x

x will be replaced with the parameter's mnemonic (e.g. TN, SP, LRN, AIN, IN, or NPANXX).

Communication errors

The following are connection errors that may occur when processing batch commands. They are listed from most common to least common. The most likely corrective action for each are included:

- 1 Could not connect to local LSMS port
 - Check the LSMS Connection Allowed state. If the LSMS Connection is currently Disabled, then Enable the LSMS Connection.
 - Check the LSMS HS Bulk Download Enabled state. If the LSMS Bulk Download for this ELAP is currently Enabled, then Disable the LSMS Bulk Download for this ELAP.
 - Check the state of the software on both ELAP sides. If the software is stopped (side is down), then start the software.
 - Possibly, the LSMS was in the middle of connecting to the ELAPs. Try again.
- 2 No connection to remote LSMS port
 - Probably, the LSMS was in the middle of connecting to the ELAPs. Try again.
- 3 Could not connect to local LPU port
 - Probably, a user on the mate started a batch at the same time which grabbed the port before the local user's batch could. Try again.
- 4 Connection to LPU port closed by another instance
 - Probably, the local user's batch grabbed the port just before or just after the mate user's batch. Try again.

The following are send and receive errors that may occur when processing batch commands. They are listed in no particular order. They should very rarely happen:

- 1 Could not send message
- 2 Receive header timed out
- 3 Could not receive header
- 4 Receive data timed out
- 5 Could not receive data

Perl errors

The following are Perl-related errors that may occur along with their probable causes:

- 1 Unable to create sub named "`*Safe::Root0::x`"
— Probably misspelled command or function name

Perl Statements and Functions

The batch language is actually a subset of the Perl language with the addition of the functions/commands specified under “**LPU Commands**” on page B-2. For more information on Perl, see reference [1].

The following subsections highlight some of the more useful Perl statements and functions for batch processing.

#

If not quoted, comments out rest of line.

foreach

Iterates through a list, assigning the current element to a variable. For example, the following will retrieve TNs 919-555-0000 through 919-555-9999:

```
foreach $extension ('0000'..'9999')
{
    rtrv_lnp_sub(TN => "919555$extension");
}
```

print

Outputs string(s). For example, the following will output the TNs being deleted

```
foreach $tn ('9195550000'..'9195559999')
{
print ("Deleting TN $tn \n");
dlt_lnp_sub (TN => $tn);
}
```

scalar localtime

Returns the current time for the current locale in UNIX date command form. For example, the following:

```
print scalar localtime, "\n";
```

Output the following

```
Wed Apr 24 15:45:27 2002
```

eval

Allows user to catch an error without stopping execution of the batch. On error, the error message is put into the special variable \$@ and execution continues at the next line after the eval block.

For example without an eval, the following:

```
set_echo(1);
upd_lnp_sub (TN=>'9194601234', LRN=>'3456789012', SP=>'tklc',
CLASS_SSN=>2);
upd_lnp_sub (TN=>'9194602341', LRN=>'3456789012', SP=>'tklc');
rtrv_lnp_sub(TN=>'9194601234');
```

Produces:

```
Processing upd_lnp_sub (
  CLASS_SSN => '2',
  LRN => '3456789012',
  SP => 'tklc',
  TN => '9194601234',
)
```

```
ERROR: An error occurred while attempting the requested operation.
E1074: LPU batch failure: Batch Error: CLASS_DPC and CLASS_SSN must be
specified together at /export/home/elapall/LPU_batch line 3
```

However, if one puts the updates in an eval, the error can be caught and dealt with instead of exiting the batch execution. For example:

```
set_echo(1);
eval
{
    upd_lnp_sub (TN=>'9194601234', LRN=>'3456789012', SP=>'tklc',
CLASS_SSN=>2);
    upd_lnp_sub (TN=>'9194602341', LRN=>'3456789012', SP=>'tklc');
};
print $@ if $@;
rtrv_lnp_sub(TN=>'9194601234');
rtrv_lnp_sub(TN=>'9194602341');
```

Produces:

```
Processing upd_lnp_sub (
  CLASS_SSN => '2',
  LRN => '3456789012',
  SP => 'tklc',
  TN => '9194601234',
)
CLASS_DPC and CLASS_SSN must be specified together at
/export/home/elapall/LPU_batch line 5
Processing rtrv_lnp_sub (
  TN => '9194601234',
)

TN 9194601234 not found.

Processing rtrv_lnp_sub (
  TN => '9194602341',
)

TN 9194602341 not found.

Done.

SUCCESS: The LPU batch file has been successfully executed.
```

Index

Symbols

#, B-20

Numerics

100BASE-T Ethernet network
 ELAP Sync, 2-8
 main DSM, 2-7
10BASE-T Ethernet network
 backup DSM, 2-7
18911
 Heading 2
 LSMS/ELAP PING
 Enhancement, 2-16
228 Million Numbers feature, LNP, 2-2

A

Able/Unable states, ELAP, 2-10
access
 configuration menu, 5-13
Account Inactivity, 3-108
ACTIVE, 3-7
Active/Standby
 ELAP relation to LSMS
 connection, 2-10
 ELAP roles, 2-5
 ELAP switchover, 2-5
Add Authorized PDDBA Client IP, 3-103
Add External NTP Server, 5-25
Add Group screen, 3-97
Add User screen, 3-84
Adding Security Parameters, 5-7
address
 default router, 5-18
 netmask, 5-18
addresses, IP
 see IP addresses
admonishments, documentation, 1-9
Aging, 3-110
alarm data strings
 contents, 4-3
 list using rept-stat-mps command, 4-11
Alarm LEDs, 3-8
Alarm View Window, 3-8

alarms

alarm priorities, 4-3
categories, 4-14
clearing alarm, 4-15
DSM/ ELAP rept-stat-trbreport, 4-12
DSM-ELAP Link status, 4-16
ELAP application, 4-14
ELAP-DSM UAMs, 4-16
IP Connection
 Available/ Unavailable, 4-16
MPS Available alarm, 4-15
MPS platform, 4-14
MPS platform and ELAP
 application, 4-15
multiple alarm conditions, 4-4
rept-stat-mps command to list data
 strings, 4-11
RTDB Audit, 4-16
 totals in rept-stat-alm report, 4-4, 4-13
application alarms, ELAP, 4-14
Audit, RTDB
 alarms, 4-16
Authorized IP menu, 3-103, 3-104, 3-105,
 3-106
Authorized IPs, 3-103
auto-configuration, 5-26

B

back-end check, 3-11
backup DSM network, 2-7
Backup RTDB, 3-38
banner header section, 3-2
Banner Information Messages, 3-115
banner section, 3-6
Batch Mode, 3-60
browser connectivity, 5-29
browser window, 3-5
browsers, 5-3
busy icon, 3-6

C

capacity status reporting, DSM
 memory, 4-7

- Capture Log Files, 3-63
 - categories, alarm, 4-14
 - Change Allowed menu, 3-32
 - Change Enabled, 3-29
 - Change Enabled menu, 3-25, 3-26
 - Change Password, 5-21
 - Change Password menu, 3-110, 5-21
 - Change Simplex Mode, 3-21
 - Change Status, 3-18
 - clearing alarm, 4-15
 - commands
 - ELAP log viewer navigation, 3-70
 - rept-stat-alm, 4-4, 4-13
 - rept-stat-db, 4-9
 - rept-stat-mps
 - description, 4-10
 - report multiple alarm
 - conditions, 4-4
 - rept-stat-trbl, 4-4, 4-12
 - Communication errors, B-19
 - Complexity, 3-110
 - complexity checking, 3-108
 - Concurrent Logins, 3-109
 - Concurrent User Logins, 3-109
 - conditions, multiple alarm, 4-4
 - Configuration and Initialization, 5-8
 - Configuration Menu, 5-13
 - configuration menu
 - Change Password, 5-21
 - Configure DSM Networks, 5-19
 - Configure ELAP Sync Network, 5-18
 - Configure Provisioning Network, 5-18
 - description, 5-13
 - elapconfig login name, 5-13
 - Exchange Secure Shell Keys, 5-21
 - Select Time Zone, 5-20
 - Configuration Menu Conventions, 5-11
 - Configuration Procedure, 5-26
 - configuration procedure, 5-29
 - configure
 - customer (provisioning) network IP
 - addresses, 5-18
 - customer (provisioning) network
 - netmask, 5-18
 - customer network default router
 - address, 5-18
 - DSM network IP addresses, 5-19
 - ELAP Sync network IP addresses, 5-18
 - remote dial-in serial port, 2-9
 - Configure DSM Network menu, 5-17, 5-19
 - Configure DSM Networks, 5-19
 - Configure ELAP Sync Network, 5-18
 - Configure NTP Server, 5-24
 - Configure Provisioning Network, 5-18
 - Configure Provisioning Network
 - menu, 5-17
 - Configure Sync Network menu, 5-18
 - Connect to MMI Port, 3-67
 - connection
 - DSM to ELAP, 2-7
 - ELAP Sync network, 2-4, 2-8
 - ELAP to DSM, 2-4
 - existing ELAP to LSMS, 2-11
 - initial ELAP to LSMS, 2-10
 - LSMS to ELAP, 2-5, 2-10
 - primary LSMS to ELAP, 2-10
 - provisioning (customer) network, 2-9
 - remote Dialup PPP, 2-9
 - status, ELAP-to-DSM, 4-16
 - connectivity, 5-29
 - continual memory validation, DSM
 - daughterboard, 4-6
 - continuous reload, DSM, 2-18
 - Corrupted RTDB Database Alarm, 2-20
 - Corruption Cross Correction, 2-21
 - Creating New Java Policy File, 5-8
 - customer (provisioning) network
 - configure IP addresses, 5-18
 - description, 2-9
 - Customer Care Center, 1-10
- ## D
- data strings, alarm
 - see alarm data strings, 4-3
 - database back-up, 5-26
 - database, DSM
 - see DSM
 - daughterboard, DSM
 - continual memory validation, 4-6
 - db=mps, 4-10
 - Debug Menu, 3-61
 - Decode Eagle MPS Alarm, 3-23
 - default
 - DMS network IP addresses, 2-7
 - ELAP Sync network IP addresses, 2-8

Index

- router IP address, 5-18
 - values for ELAP user interface
 - prompts, 5-11
- Default GTT, 3-43
- default network values, 5-26
- default values, 5-26
- Delete Group Profile, 3-100
- Delete LNP 10-Digit Telephone Number
 - Subscription, B-13, B-14
- Delete LNP Location Routing
 - Number, B-15
- Delete LNP Subscription, 3-51
- Delete NPA-NXX Records, 3-54
- Delete Override GTT Records, 3-57
- Delete Split NPANXX, B-15
- Delete User screen, 3-91
- design, ELAP overall, 2-4
- Dialup PPP network
 - description, 2-9
 - IP addresses, 2-9
 - modem, 2-9
 - remote dial-in port, 2-9
- Display Configuration menu, 5-16
- Display External NTP Server, 5-24
- Display Release Levels, 3-22
- documentation
 - admonishments, 1-9
 - packaging, 1-9
 - part numbers, 1-9
 - updates, 1-8
- DSM
 - connection to ELAP, 2-7
 - continuous reload, 2-18
 - database level, 4-5
 - daughterboard continual memory
 - validation, 4-6
 - DSM-ELAP Link status alarms, 4-16
 - incremental loading model, 2-17
 - memory capacity status reporting, 4-7
 - primary, 2-21, 4-2
 - provisioning description, 2-17
 - reload, 2-17
 - status of connection to ELAP, 4-16
 - Status Requests, 4-4
 - system hardware verification, 4-5
 - UAMs, 4-16
 - unstable loading mode, 4-7
 - warm restart, 2-18

- DSM networks
 - configure IP addresses, 5-19
 - description, 2-4, 2-7
 - IP addresses, 2-7

E

- Eagle DSM Audit of MPS Databases, 2-19
- Eagle LNP Application Processor
 - see* ELAP
- Effect of Corrupted record received from MPS, 2-21
- Eject CD menu, 3-76, 5-22
- ELAP
 - Able/Unable states for provisioning, 2-10
 - Active/Standby
 - relation to LSMS connection, 2-10
 - roles, 2-5
 - switchover, 2-5
 - alarms
 - see also* alarms
 - application, 4-14
 - DSM-ELAP Link status, 4-16
 - in rept-stat-mps report, 4-11
 - RTDB Audit, 4-16
 - UAMs, 4-14
 - change login name passwords, 5-21
 - connection to DSMs, 2-4, 2-7
 - definition, 2-2
 - DSM UAMs, 4-16
 - existing connection to LSMS, 2-11
 - general description, 2-3
 - initial connection to LSMS, 2-10
 - initialization, 5-8
 - log viewer navigation commands, 3-70
 - LSMS connection, 2-5
 - Maintenance Blocks, 4-2
 - overall design, 2-4
 - status of connection to DSM, 4-16
 - Sync network
 - configure IP addresses, 5-18
 - description, 2-4, 2-8
 - IP addresses, 2-8
 - time zone, 5-20
 - user interface
 - error message format, 5-12
 - list of error messages, 3-112

- user interface menus
 - configuration, 5-13
 - default values for prompts, 5-11
 - Escape key to exit operations, 5-11
 - responding to prompts, 5-11
- user login names
 - access configuration menu, 5-13
 - elapconfig
 - for ELAP initialization, 5-8
- ELAP Areas, 3-6
- ELAP Error Messages, 3-112
- ELAP menu, 3-12
- ELAP User Interfaces, 3-2
- elapconfig, 5-13
- elapconfig login name
 - access configuration menu, 5-13
 - for ELAP initialization, 5-8
- encryption keys for secure shell, 5-21
- Enforce password complexity
 - checking, 3-108
- EPAP Audit, 2-19
- epapconfig, 5-26, 5-29
- error codes, 3-112
- Error Message Format, 5-12
- Error message format, B-18
- Error Messages, 3-112
- error messages, ELAP
 - format, 5-12
 - list of user interface, 3-112
- Escape key to exit ELAP user interface
 - operations, 5-11
- Ethernet network
 - 100BASE-T, 2-7, 2-8
 - 10BASE-T, 2-7
 - DSM networks, 2-4, 2-7
 - ELAP Sync, 2-4, 2-8
- eval, B-21
- Exchange Secure Shell Keys, 5-21
- Exchange Secure Shell Keys menu, 5-21
- existing ELAP connection to LSMS, 2-11
- Exit menu, 5-25
- exit user interface operations with Escape
 - key, 5-11

F

- Failed User Logins, 3-108
- feature, LNP 228 Million Numbers, 2-2

- files
 - UNIX time zone, 1-2, 5-20, A-1
- Force Change on Initial Login, 3-110
- Force Standby menu, 3-17
- FORCED STANDBY, 3-7
- foreach, B-20
- format
 - ELAP error messages, 5-12
- Functional Description, 2-19

G

- GPL, 1-12
- Graphical User Interface, 3-2
- Groups menu, 3-96
- GTT, 1-12
- GUI, 1-12, 3-2
- GUI Main Screen, 3-5

H

- Halt MPS menu, 5-23
- Halt MPS screen, 3-78
- hardware
 - platform, MPS, 2-3
 - verification, DSM system, 4-5
- header format, 5-11
- Health Check, System
 - status and alarm reporting, 4-2
- HTML output, 3-3
- http web server, 3-3

I

- Idle Port Logout, 3-81
- Idle Timeout, 3-108
- Inconsistent DSM Card Alarm, 2-19
- incremental loading, DSM, 2-17
- information messages, 3-115, 3-116
- initial configuration steps, 5-26
- initial ELAP-LSMS connection, 2-10
- Initial Platform Manufacture, 5-26
- Initialization, 5-8
- initialization
 - ELAP, 5-8
- Initiate Upgrade, 5-22
- Installing Java Policy File, 5-7
- Internet Explorer, 5-3

Index

Intrusion Alert, 3-82
IP addresses
 configure customer (provisioning)
 network, 5-18
 configure DSM network, 5-19
 configure ELAP Sync network, 5-18
 default for DSM networks, 2-7
 default for ELAP Sync network, 2-8
 default router, 5-18
 Dialup PPP network, 2-9
 DSM networks, 2-7
 ELAP Sync network, 2-8
 provisioning (customer) network
 netmask, 5-18
 sample network, 2-7
IP Connection Available/ Unavailable
 alarms, 4-16
IPM, 5-26

J

Java, 5-3
Java Plug-In, 5-4
Java Policy File, 5-7
Job Routing Server (JRS)
 description, 2-11

K

keys, secure shell encryption, 5-21

L

level
 DSM database, 4-5
Link Status alarms, DSM-ELAP, 4-16
list alarms data strings, 4-11
List All Running Processes, 3-74
List ELAP Software Processes, 3-65
LNP
 provisioning, 2-10
 provisioning data collection
 sources, 2-11
LNP Service, 3-42, 3-44, 3-45
loading
 DSM incremental, 2-17
 mode, DSM unstable loading, 4-7
local ELAP, 5-27

Local Number Portability (LNP 228 Million
 Numbers feature, 2-2
Local Provisioning menu, 3-48
Local Provisioning Utility, 3-48
Log Viewer, 3-69
log viewer navigation commands, 3-70
Login Message Text, 3-109
login names
 change passwords for, 5-21
login screen, 3-4
Login Tracking, 3-82
Logout menu, 3-111
logs
 log viewer navigation commands, 3-70
LPU, 3-48
LPU Commands, B-2
LSMS
 connection to ELAP for
 provisioning, 2-5, 2-10, 2-11
 ELAP connection for provisioning, 2-10
 existing connection to ELAP, 2-11
 initial ELAP connection to, 2-10
 primary connection to ELAP, 2-10
LSMS Connection, 3-8
LSMS Connection menu, 3-31
LSMS HS Audit menu, 3-25
LSMS HS Bulk Download, 3-28

M

main DSM network, 2-7
Maintenance Blocks, ELAP
 contents of, 4-2
 description, 4-2
Maintenance Log, 3-62
Maintenance Menu, 3-16
maintenance task, 3-7
Manage Log Files, 3-64
Manage Unused UserIDs, 3-82
Maximum Account Inactivity, 3-108
Maximum Concurrent Logins, 3-109
Maximum Concurrent User Logins, 3-109
Maximum Failed User Logins, 3-108
Maximum Password Age, 3-108
memory, DSM
 capacity status reporting, 4-7
 daughterboard continual
 validation, 4-6

Menu Format, 5-11
 menu section, 3-2, 3-9
 menus, ELAP user interface
 configuration, 5-13
 see also configuration menu
 default values for prompts, 5-11
 Escape key to exit operations, 5-11
 responding to prompts, 5-11
 message box, 3-8
 Message History, 3-9
 messages, 3-115, 3-116
 messages, ELAP user interface error
 format, 5-12
 list of, 3-112
 Miscellenous Commands, B-17
 Missing mandatory parameter, B-18
 mode
 DSM unstable loading, 4-7
 modem for PPP connection, 2-9
 Modify Group menu, 3-98
 Modify System Defaults menu, 3-108
 Modify User screen, 3-85
 mouse-over check, 3-11
 MPS
 definition, 2-2
 hardware platform, 2-3
 platform alarms, 4-14
 MPS Available alarm, 4-15
 MPS RTDB Audit, 2-19
 MPS-to-DSM Data Validation, 2-19
 multiple alarm conditions, 4-4
 Multiple Sessions per User, 3-81
 MySQL Backup menu, 5-23

N

Name field, 3-7
 navigation commands, ELAP log
 viewer, 3-70
 netmask IP address, 5-18
 network values, 5-26
 network, customer (provisioning)
 configure IP addresses, 5-18
 description, 2-9
 network, Dialup PPP
 description, 2-9
 IP addresses, 2-9
 modem for, 2-9

 remote dial-in serial port
 configuration, 2-9
 network, ELAP Sync
 configure IP addresses, 5-18
 description, 2-4, 2-8
 IP addresses, 2-8
 network, Ethernet
 100BASE-T, 2-7, 2-8
 10BASE-T, 2-7
 DSM networks, 2-4, 2-7
 ELAP Sync network, 2-8
 networks
 RFC 1587 standard, 2-7
 sample IP addresses for, 2-7
 networks, DSM
 configure IP addresses, 5-19
 description, 2-4, 2-7
 IP addresses, 2-7
 New User Default Groups, 3-109
 NPA-NXX Split / Delete, 3-59
 NPA-NXX Split menu, 3-58
 NPA-NXX Split screen, 3-46
 NTP server, 5-26
 Number Portability Administration Center
 (NPAC), 2-11

O

octets
 changing ELAP Sync network IP address
 third, 5-18
 DSM network IP address, 2-7
 ELAP Sync network IP address, 2-8
 on-site MPS, 5-27
 operations, Escape key to exit user
 interface, 5-11
 Override GTT, 3-44
 Override GTT menu, 3-55
 Overview of ELAP UI, 5-2

P

packaging, documentation, 1-9
 part numbers, documentation, 1-9
 Password Age, 3-108
 password complexity checking, 3-108
 Password Reuse, 3-111
 Password Reuse Limit, 3-108

Index

- passwords
 - change for ELAP login names, 5-21
- Perl errors, B-20
- Perl Statements and Functions, B-20
- platform
 - alarms, MPS, 4-14
 - MPS hardware, 2-3
- Platform Menu, 3-71, 5-22
- Platform Menu Exit, 5-24
- Point-to-Point Protocol (PPP)
 - for Dialup PPP network, 2-9
 - modem for, 2-9
- Policy File, 5-7
- pop-up check, 3-11
- port, remote dial-in, 2-9
- primary
 - DSM, 2-21, 4-2
 - LSMS to ELAP connection, 2-10
- print, B-21
- priorities, alarm, 4-3
- Process Control menu, 3-14
- prompts
 - default value format, 5-11
 - ELAP user interface menus, 5-11
 - Escape key to exit operations, 5-11
- Prompts and Default Values, 5-11
- Protocol, Point-to-Point (PPP), 2-9
- provisioning
 - ELAP Able/Unable status, 2-10
 - ELAP-to-DSM description, 2-17
 - LNP, 2-10
 - LSMS-ELAP connection, 2-5, 2-10
 - NPAC and local data collection at LSMS, 2-11
- provisioning values, 5-26

R

- Reboot MPS menu, 3-77, 5-23
- reload
 - DSM, 2-17
 - DSM continuous, 2-18
- Reload RTDB from Remote, 3-37
- remote dial-in port, 2-9
- remote ELAP, 5-27
- Remove External NTP Server, 5-25
- reporting
 - DSM memory capacity status, 4-7

- DSM/ ELAP IP link alarm totals, 4-13
- DSM/ ELAP link alarms, 4-12
- RTDB level and status, 4-9
- rept-stat-alm command, 4-4, 4-13
- rept-stat-db command, 4-9
- rept-stat-mps command
 - description, 4-10
 - DSM memory capacity status reporting, 4-7
 - list alarm categories and data strings, 4-11
 - list multiple alarm conditions, 4-4
- rept-stat-trbl command, 4-4, 4-12
- Required Network Address Information, 5-9
- Reset User Password, 3-95
- restart, DSM warm, 2-18
- Restore RTDB, 3-39
- Retrieve Group screen, 3-102
- Retrieve LNP 10-digit Subscription, B-16
- Retrieve LNP Subscription, 3-52
- Retrieve RTDB Records, 3-41
- Retrieve User screen, 3-92
- Return key, 5-26
- Reuse Limit, 3-108
- Revoke Failed User, 3-82
- Revoke/Restore User, 3-81
- RFC 1587 network standard, 2-7
- roles, ELAP
 - Active/Standby, 2-5
 - Active/Standby switchover, 2-5
- router IP address, default, 5-18
- RTDB
 - Audit alarms, 4-16
 - rept-stat-db command to view database level and status, 4-9
- RTDB / Maintenance menu, 3-36
- RTDB Audit menu, 3-24
- RTDB Backup menu, 5-24
- RTDB Menu, 3-34
- Run Health Check menu, 3-72

S

- scalar localtime, B-21
- Screen Resolution, 5-3
- screen workspace, 3-4
- scroll by messages, 3-115

secure shell encryption key exchange, 5-21
 Select Mate menu, 3-13
 Select Time Zone, 5-20
 Select Time Zone menu, 5-20
 Service parameters within error messages, B-18
 Service Providers, 3-47
 Session Idle Timeout, 3-108
 session inactivity, 3-5
 Setting Up an ELAP Workstation, 5-3
 Setting Up Workstation, 5-3
 Simplex Mode Menu, 3-20
 Software Configuration, 5-1
 standard, RFC 1587 network, 2-7
 STANDBY, 3-7
 Standby ELAP
 see Active/Standby
 Start ELAP Software, 3-14
 status
 DSM memory capacity, 4-7
 DSM Status Requests, 4-4
 DSM-ELAP Link alarms, 4-16
 ELAP Able/Unable, 2-10
 ELAP-to-DSM connection, 4-16
 Status field, 3-7
 Stop ELAP Software, 3-15
 Subscriptions menu, 3-41, 3-49
 Success message, B-18
 switchover, ELAP
 Active/Standby, 2-5
 Sync network, ELAP
 configure IP addresses, 5-18
 description, 2-4, 2-8
 IP addresses, 2-8
 syntax checking, 3-11
 system hardware verification, DSM, 4-5
 System Health Check
 status and alarm reporting, 4-2

T

Telnet to MPS, 3-80
 Terminate Active Sessions, 3-107
 text-based configuration, 5-26
 text-based UI, 3-2, 5-26
 time zone
 select for ELAP, 5-20
 UNIX files, 1-2, 5-20, A-1

U

UAMs
 alarm categories, 4-15
 clearing alarm, 4-15
 ELAP application, 4-15
 ELAP-DSM, 4-16
 MPS platform, 4-15
 RTDB Audit, 4-16
 UNIX
 time zone files, 1-2, 5-20, A-1
 Unsolicited Information Messages, 4-14
 unstable loading mode, DSM, 4-7
 Update Commands, B-2
 Update LNP 10-Digit Subscription, B-2
 Update LNP Location Routing
 Number, B-8
 Update LNP NPANXX, B-5
 Update LNP Subscription, 3-49
 Update NPA-NXX Records, 3-53
 Update NPA-NXX Split Records, 3-58
 Update Override GTT Records, 3-55
 Update Split NPANXX, B-12
 updates, documentation, 1-8
 User Administration menu, 3-81
 User Default Groups, 3-109
 user interface, ELAP
 error message format, 5-12
 Escape key to exit operations, 5-11
 list of error messages, 3-112
 User Interfaces, 3-2
 User Login, 5-13
 User Logins, 3-109
 Users menu, 3-82

V

validation
 DSM daughterboard continual
 memory, 4-6
 verification, DSM system hardware, 4-5
 View Allowed menu, 3-31
 View Any File menu, 3-65
 View Enabled, 3-28
 View Enabled menu, 3-24, 3-26
 View LNP QTY, 3-36
 view logs files, 3-62
 View Logs menu, 3-61
 View RTDB Status, 3-35

Index

View Simplex Mode, 3-20
View Status screen, 3-17
View System Log, 3-75
View Window viewer, 3-62
VIOL, 3-7

W

warm restart, DSM, 2-18
web-based user interface, 3-2
work area section, 3-2
workspace section, 3-10

