

# *Tekelec EAGLE<sup>®</sup> 5 Integrated Signaling System*

Release 38.0

## **Database Administration Manual - Features**

910-5256-001 Revision C

July 2008



**Copyright 2008 Tekelec  
All Rights Reserved.  
Printed in U.S.A.**

### *Notice*

Information in this documentation is subject to change without notice. Unauthorized use, copying, or translation of this documentation can result in civil or criminal penalties.

Any export of Tekelec products is subject to the export controls of the United States and the other countries where Tekelec has operations.

No part of this documentation may be reproduced, translated, or transmitted in any form or by any means, electronic or mechanical, including photocopying or recording, for any purpose without the express written permission of an authorized representative of Tekelec.

Other product names used herein are for identification purposes only, and may be trademarks of their respective companies.

RoHS 5/6 - As of July 1, 2006, all products that comprise new installations shipped to European Union member countries will comply with the EU Directive 2002/95/EC "RoHS" (Restriction of Hazardous Substances). The exemption for lead-based solder described in the Annex will be exercised. RoHS 5/6 compliant components will have unique part numbers as reflected in the associated hardware and installation manuals.

WEEE - All products shipped to European Union member countries comply with the EU Directive 2002/96/EC, Waste Electronic and Electrical Equipment. All components that are WEEE compliant will be appropriately marked. For more information regarding Tekelec's WEEE program, contact your sales representative.

### *Trademarks*

The Tekelec logo, EAGLE, G-Flex, G-Port, IP7, IP7 Edge, and IP7 Secure Gateway are registered trademarks of Tekelec. TekServer, A-Port, and V-FLEX are trademarks of Tekelec. All other trademarks are the property of their respective owners.

### *Patents*

This product is covered by one or more of the following U.S. and foreign patents:

#### U.S. Patent Numbers:

5,732,213; 5,953,404; 6,115,746; 6,167,129; 6,324,183; 6,327,350; 6,456,845; 6,606,379; 6,639,981; 6,647,113; 6,662,017; 6,735,441; 6,745,041; 6,765,990; 6,795,546; 6,819,932; 6,836,477; 6,839,423; 6,885,872; 6,901,262; 6,914,973; 6,940,866; 6,944,184; 6,954,526; 6,954,794; 6,959,076; 6,965,592; 6,967,956; 6,968,048; 6,970,542; 6,987,781; 6,987,849; 6,990,089; 6,990,347; 6,993,038; 7,002,988; 7,020,707; 7,031,340; 7,035,239; 7,035,387; 7,043,000; 7,043,001; 7,043,002; 7,046,667; 7,050,456; 7,050,562; 7,054,422; 7,068,773; 7,072,678; 7,075,331; 7,079,524; 7,088,728; 7,092,505; 7,108,468; 7,110,780; 7,113,581; 7,113,781; 7,117,411; 7,123,710; 7,127,057; 7,133,420; 7,136,477; 7,139,388; 7,145,875; 7,146,181; 7,155,206; 7,155,243; 7,155,505; 7,155,512; 7,181,194; 7,190,702; 7,190,772; 7,190,959; 7,197,036; 7,206,394; 7,215,748; 7,219,264; 7,222,192; 7,227,927; 7,231,024; 7,242,695; 7,254,391; 7,260,086; 7,260,207; 7,283,969; 7,286,516; 7,286,647; 7,286,839; 7,295,579; 7,299,050; 7,301,910; 7,304,957; 7,318,091; 7,319,857; 7,327,670

#### Foreign Patent Numbers:

EP1062792; EP1308054; EP1247378; EP1303994; EP1252788; EP1161819; EP1177660; EP1169829; EP1135905; EP1364520; EP1192758; EP1240772; EP1173969; CA2352246

### *Ordering Information*

To order additional copies of this document, contact your Tekelec Sales Representative.

# Table of Contents

<b>Chapter 1. Introduction</b> .....	1-1
Feature Overview .....	1-1
X.25 Gateway .....	1-2
STPLAN .....	1-2
Database Transport Access .....	1-2
GSM MAP Screening .....	1-2
EAGLE 5 Integrated Monitoring Support .....	1-3
Manual Organization .....	1-3
Related Publications .....	1-3
Documentation Availability, Packaging, and Updates .....	1-3
Documentation Admonishments .....	1-4
Customer Care Center .....	1-4
Emergency Response .....	1-5
Maintenance and Administration Subsystem .....	1-5
EAGLE 5 ISS Database Partitions .....	1-6
Fixed Disk Drive .....	1-7
Removable Cartridge .....	1-7
Locate Product Documentation on the Customer Support Site .....	1-8
<b>Chapter 2. X.25 Gateway Configuration</b> .....	2-1
The X.25 Gateway .....	2-1
Connectivity to the X.25 Node .....	2-2
Message Conversion .....	2-2
Address Mapping .....	2-3
X.25 Gateway Description .....	2-3
X.25 Gateway Routing .....	2-3
Connection Determination .....	2-4
X.25 Connection Control .....	2-5
Same Link Management .....	2-6
Logical Channel to Network Management Mapping .....	2-6
X. 25 Gateway Routing on Mated STPs .....	2-7
X.25 Gateway Configuration Procedures .....	2-7
Adding an X.25 LIM .....	2-10
Removing an X.25 LIM .....	2-14
Adding an X.25 Gateway Destination .....	2-20
Removing an X.25 Gateway Destination .....	2-26
Changing an X.25 Gateway Destination .....	2-28
Adding an X.25 Linkset .....	2-32
Removing a Linkset Containing X.25 Signaling Links .....	2-51

Changing an X.25 Linkset .....	2-58
Adding an X.25 Signaling Link .....	2-82
Removing an X.25 Signaling Link .....	2-93
Adding an X.25 Route .....	2-97
Removing an X.25 Route .....	2-112
Changing an X.25 Route .....	2-114
Changing the X.25 Signaling Link Parameters .....	2-127
Enabling the Large System # Links Controlled Feature .....	2-131
<b>Chapter 3. STPLAN Configuration .....</b>	<b>3-1</b>
STPLAN Feature Overview .....	3-1
Message Sequencing .....	3-2
Message Format .....	3-2
TCP/IP Router .....	3-4
Hardware Requirements .....	3-7
Node Requirements .....	3-7
Gateway Screening .....	3-8
Congestion Management .....	3-9
STPLAN Provisioning .....	3-9
ACM-based or Mixed ACM- and DCM-Based Systems .....	3-10
Pure DCM-Based Systems .....	3-10
Understanding Firewall and Router Filtering .....	3-11
IP Addresses .....	3-11
Network Configuration Procedures .....	3-13
Adding an STPLAN Card .....	3-17
Removing an STPLAN Card .....	3-25
Adding a TCP/IP Data Link .....	3-29
Removing a TCP/IP Data Link .....	3-36
Adding a TCP/IP Node .....	3-39
Removing a TCP/IP Node .....	3-43
<b>Chapter 4. Database Transport Access (DTA) Configuration .....</b>	<b>4-1</b>
DTA Feature Overview .....	4-1
Functional Description .....	4-3
Discarding MSUs .....	4-4
Measurements .....	4-6
Summary of the Gateway Screening Redirect Table Commands .....	4-6
X.25/SS7 Gateway Description .....	4-6
X.25/SS7 Gateway Routing .....	4-7
Routing Management Mapping .....	4-8
SCCP Subsystem Management .....	4-9
EAGLE 5 ISS Requirements .....	4-10
Configuring the EAGLE 5 ISS for the DTA Feature .....	4-11
Changing the Gateway Screening Redirect Parameters .....	4-32
Disabling the Gateway Screening Redirect Function .....	4-41
<b>Chapter 5. GSM MAP Screening Configuration .....</b>	<b>5-1</b>
Introduction .....	5-1
GSM MAP Screening Overview .....	5-2

GSM MAP Screening Details ..... 5-5

GSM MAP Screening Example ..... 5-17

GSM MAP Screening Procedures ..... 5-18

Activating the GSM MAP Screening Feature ..... 5-22

Configuring the MTP MAP Screening Feature ..... 5-34

Configuring a Linkset for the GSM MAP Screening Feature ..... 5-39

Changing the System-Wide GSM MAP Screening Options ..... 5-49

Adding a GSM Subsystem Number Screening Entry ..... 5-52

Removing a GSM Subsystem Number Screening Entry ..... 5-55

Adding a GSM MAP Screening Operation Code ..... 5-57

Removing a GSM MAP Screening Operation Code ..... 5-75

Changing a GSM MAP Screening Operation Code ..... 5-78

Adding a GSM MAP Screening Entry ..... 5-92

Removing a GSM MAP Screening Entry ..... 5-119

Changing a GSM MAP Screening Entry ..... 5-128

Changing the GSM MAP Screening TCAP Continue and End Message Processing  
Option ..... 5-146

**Chapter 6. EAGLE 5 Integrated Monitoring Support Configuration ..... 6-1**

    Introduction ..... 6-1

    TCP/IP Link Provisioning ..... 6-4

    Time Stamping ..... 6-5

    EAGLE 5 ISS Provisioning ..... 6-5

    Network Considerations ..... 6-7

        IP Address Provisioning ..... 6-8

        Route Configuration ..... 6-8

        Network Limitations ..... 6-8

    Enabling the Time Slot Counter Synchronization (TSCSYNC) and EAGLE 5 Integrated  
    Monitoring Support (E5IS) Features ..... 6-8

    Configuring the EAGLE 5 Integrated Monitoring Support Options ..... 6-11

    Adding a Signaling Transport Card (STC) ..... 6-19

    Removing a Signaling Transport Card (STC) ..... 6-24

**Glossary ..... Glossary-1**

**Index ..... Index-1**



# List of Figures

- Figure 1-1.** EAGLE 5 ISS Database Partitions..... 1-6
- Figure 2-1.** X.25 Gateway Network..... 2-2
- Figure 2-2.** X.25 Gateway Connection Determination..... 2-4
- Figure 2-3.** X.25 Gateway Database Relationships..... 2-8
- Figure 2-4.** Typical X.25/SS7 Gateway Configuration ..... 2-10
- Figure 3-1.** STPLAN Messages Embedded in TCP/IP Packets..... 3-4
- Figure 3-2.** STPLAN Network with a TCP/IP Router..... 3-5
- Figure 3-3.** STPLAN in a Large Network..... 3-6
- Figure 3-4.** STPLAN Network with Subnet Routing..... 3-6
- Figure 3-5.** IP Address Bit Categorization..... 3-12
- Figure 3-6.** STPLAN Database Relationships..... 3-14
- Figure 3-7.** STPLAN Configuration Example..... 3-17
- Figure 4-1.** Example of Configuration for the DTA Feature..... 4-2
- Figure 4-2.** DTA Encapsulation..... 4-4
- Figure 4-3.** X.25 Routing to a CPC..... 4-8
- Figure 4-4.** Configuration of GTT for Routing Management..... 4-10
- Figure 5-1.** GSM MAP Screening Overview..... 5-4
- Figure 5-2.** GSM MAP Screening Details ..... 5-8
- Figure 5-3.** GSM MAP Screening Database Relationships..... 5-20
- Figure 6-1.** Monitoring via Hardware Connection..... 6-2
- Figure 6-2.** EAGLE 5 Integrated Monitoring Support Network Connectivity..... 6-3
- Figure 6-3.** ESP/IMF/EAGLE 5 ISS Network..... 6-4
- Figure 6-4.** Ethernet Link Establishment - EMP Link Data..... 6-5



# List of Tables

<b>Table 1-1.</b> Admonishments.....	1-4
<b>Table 2-1.</b> Card Address Field Action.....	2-5
<b>Table 2-2.</b> Connection Action.....	2-5
<b>Table 2-3.</b> Typical X.25/SS7 Gateway Routing Table.....	2-10
<b>Table 2-4.</b> X.25 LIM Card Type Combinations.....	2-11
<b>Table 2-5.</b> X.25 Linkset Configuration Table.....	2-34
<b>Table 2-6.</b> X.25 Signaling Link Configuration Table.....	2-83
<b>Table 2-7.</b> X.25/SS7 Gateway Route Configuration.....	2-98
<b>Table 3-1.</b> Gateway Screening Action.....	3-8
<b>Table 3-2.</b> VXWSLAN External Ports and Their Use.....	3-11
<b>Table 3-3.</b> Values of IP Addresses.....	3-12
<b>Table 3-4.</b> Invalid IP Address Error Codes.....	3-13
<b>Table 3-5.</b> STPLAN Configuration Example Database.....	3-16
<b>Table 3-6.</b> STPLAN Card Part Numbers.....	3-18
<b>Table 3-7.</b> DCM Card Locations.....	3-18
<b>Table 4-1.</b> Maximum Encapsulation Length per DTA DPC Type.....	4-5
<b>Table 4-2.</b> Commands for the Gateway Screening Redirect Table.....	4-6
<b>Table 4-3.</b> Cards Required in Specific Situations.....	4-10
<b>Table 4-4.</b> Translation Type Parameters.....	4-18
<b>Table 4-5.</b> Translation Type Parameters.....	4-35
<b>Table 5-1.</b> Example GSM MAP Screening Table.....	5-17
<b>Table 5-2.</b> System-Wide Screening Table.....	5-18
<b>Table 5-3.</b> GSM MAP Screening Linkset Configuration Table.....	5-40
<b>Table 5-4.</b> Example GSM MAP Screening SSN Configuration Table.....	5-53
<b>Table 5-5.</b> Example GSM MAP Screening Operation Code Configuration Table.....	5-60
<b>Table 5-6.</b> Add GSM MAP Screening Entry Parameter Combinations.....	5-94
<b>Table 5-7.</b> Example CGPA GSM MAP Screening Configuration Table.....	5-97
<b>Table 5-8.</b> Example CDPA GSM MAP Screening Configuration Table.....	5-97
<b>Table 5-9.</b> Change GSM MAP Screening Entry Parameter Combinations.....	5-129
<b>Table 6-1.</b> Monitored Card Types.....	6-6
<b>Table 6-2.</b> STC Part Numbers.....	6-19
<b>Table 6-3.</b> Dual-Slot STC Locations.....	6-19



# List of Flowcharts

<b>Flowchart 1.</b>	Adding an X.25 LIM to the Database.....	2-14
<b>Flowchart 2.</b>	Removing an X.25 LIM.....	2-19
<b>Flowchart 3.</b>	Adding an X.25 Gateway Destination.....	2-25
<b>Flowchart 4.</b>	Removing an X.25 Gateway Destination.....	2-28
<b>Flowchart 5.</b>	Changing an X.25 Gateway Destination.....	2-32
<b>Flowchart 6.</b>	Adding an X.25 Linkset.....	2-44
<b>Flowchart 7.</b>	Removing a Linkset Containing X.25 Signaling Links.....	2-57
<b>Flowchart 8.</b>	Changing an X.25 Linkset.....	2-73
<b>Flowchart 9.</b>	Adding an X.25 Signaling Link.....	2-90
<b>Flowchart 10.</b>	Removing an X.25 Signaling Link.....	2-97
<b>Flowchart 11.</b>	Adding an X.25 Route.....	2-102
<b>Flowchart 12.</b>	Removing an X.25 Route.....	2-114
<b>Flowchart 13.</b>	Changing an X.25 Route.....	2-117
<b>Flowchart 14.</b>	Changing the X.25 Signaling Link Parameters.....	2-131
<b>Flowchart 15.</b>	Enabling the Large System # Links Controlled Feature.....	2-137
<b>Flowchart 16.</b>	Adding an STPLAN Card.....	3-22
<b>Flowchart 17.</b>	Removing an STPLAN Card.....	3-28
<b>Flowchart 18.</b>	Adding a TCP/IP Data Link.....	3-35
<b>Flowchart 19.</b>	Removing a TCP/IP Data Link.....	3-39
<b>Flowchart 20.</b>	Adding a TCP/IP Node.....	3-43
<b>Flowchart 21.</b>	Removing a TCP/IP Node.....	3-48
<b>Flowchart 22.</b>	Configuring for the DTA Feature.....	4-21
<b>Flowchart 23.</b>	Changing the Gateway Screening Redirect Parameters .....	4-38
<b>Flowchart 24.</b>	Disabling the Gateway Screening Redirect Function.....	4-45
<b>Flowchart 25.</b>	Activating the GSM MAP Screening Feature.....	5-29
<b>Flowchart 26.</b>	Configuring the MTP MAP Screening Feature.....	5-37
<b>Flowchart 27.</b>	Configuring a Linkset for the GSM MAP Screening Feature.....	5-46
<b>Flowchart 28.</b>	Changing the System-Wide GSM MAP Screening Options.....	5-52
<b>Flowchart 29.</b>	Adding a GSM Subsystem Number Screening Entry.....	5-55
<b>Flowchart 30.</b>	Removing a GSM Subsystem Number Screening Entry.....	5-57
<b>Flowchart 31.</b>	Adding a GSM MAP Screening Operation Code.....	5-69
<b>Flowchart 32.</b>	Removing a GSM MAP Screening Operation Code.....	5-78
<b>Flowchart 33.</b>	Changing a GSM MAP Screening Operation Code.....	5-86
<b>Flowchart 34.</b>	Adding a GSM MAP Screening Entry.....	5-113
<b>Flowchart 35.</b>	Removing a GSM MAP Screening Entry.....	5-126

**Flowchart 36.** Changing a GSM MAP Screening Entry..... 5-141

**Flowchart 37.** Changing the GSM MAP Screening TCAP Continue  
and End Message Processing Option..... 5-148

**Flowchart 38.** Enabling the TSCSYNC and E5IS Features..... 6-10

**Flowchart 39.** Configuring the EAGLE 5 Integrated Monitoring  
Support Options..... 6-16

**Flowchart 40.** Adding a Signaling Transport Card (STC)..... 6-23

**Flowchart 41.** Removing a Signaling Transport Card (STC)..... 6-27

## Introduction

Feature Overview .....	1-1
X.25 Gateway .....	1-2
STPLAN .....	1-2
Database Transport Access .....	1-2
GSM MAP Screening .....	1-2
EAGLE 5 Integrated Monitoring Support .....	1-3
Manual Organization .....	1-3
Related Publications .....	1-3
Documentation Availability, Packaging, and Updates .....	1-3
Documentation Admonishments .....	1-4
Customer Care Center .....	1-4
Emergency Response .....	1-5
Maintenance and Administration Subsystem .....	1-5
EAGLE 5 ISS Database Partitions .....	1-6
Fixed Disk Drive .....	1-7
Removable Cartridge .....	1-7
Locate Product Documentation on the Customer Support Site .....	1-8

## Feature Overview

The *Database Administration Manual – Features* describes the procedures necessary for database administration personnel or translations personnel to configure the EAGLE 5 ISS and its database to implement these features:

- X.25 Gateway
- STPLAN
- Database Transport Access
- GSM MAP Screening
- Eagle 5 Integrated Monitoring Support

**NOTE:** Previous editions of this manual contained the procedures for provisioning the Global Title Translation and Enhanced Global Title Translation features. These procedures have been removed from this manual and are now located in the *Database Administration Manual - Global Title Translation*.

**NOTE:** Before enabling any one of these features, make sure you have purchased the feature to be turned on. If you are not sure whether you have purchased the feature to be turned on, contact your Tekelec Sales Representative or Account Representative.

**NOTE:** Database administration privileges are password restricted. Only those persons with access to the command class "Database Administration" can execute the administrative functions. Refer to the *Commands Manual* for more information on command classes and commands allowed by those classes.

It is possible for two or more users to make changes to the same database element at any time during their database administration sessions. It is strongly recommended that only one user at a time make any changes to the database.

## X.25 Gateway

The X.25 Gateway feature provides connectivity between SS7 and X.25 networks. This feature enables cellular (IS.41) applications using different transport services to connect. The gateway is physically positioned between the SS7 network and the X.25 network and transports IS.41 messages from one network to the other using the SS7 Transaction Capability Application Part (TCAP) protocol.

## STPLAN

The STPLAN feature provides a TCP/IP connection from any interface shelf to support external applications. Message signaling units (MSUs) that are processed by the EAGLE 5 ISS can be copied and directed through the LAN interface to an external server or microcomputer application such as a usage measurements system. The gateway screening feature must be available on the STP in order to use the STPLAN feature.

The feature requires an STPLAN card, either the Application Communications Module (ACM) running the `stplan` application, or the Database Communications Module (DCM) running the `vxwslan` application.

## Database Transport Access

The Database Transport Access (DTA) feature provides a mechanism for the redirection of specific Message signaling units (MSUs) to a customized database. The EAGLE 5 ISS uses gateway screening to qualify incoming MSUs for redirection. Once gateway screening is passed, the original MSU is encapsulated into a new MSU and routed to its new destination.

## GSM MAP Screening

The GSM MAP Screening feature examines the Mobile Application Part (MAP) level of incoming SCCP messages to against predefined criteria in the system database to determine whether or not to allow an external server to interrogate an HLR and obtain information about the location and/or state of a GSM subscriber. This feature also allows the user to control which external entities can request this information, and what information they can request before allowing the message to pass through to the HLR.

## EAGLE 5 Integrated Monitoring Support

The EAGLE 5 Integrated Monitoring Support feature allows the network traffic on the EAGLE 5 ISS's signaling links to be monitored by an ESP (extended services platform)/ IMF (integrated message feeder) without additional intrusive cabling. Message Signaling Units (MSUs), alarms, and events are copied to the Sentinel/IMF to provide the network traffic monitoring. The monitored traffic is delivered to the Sentinel/IMF using the EAGLE 5 ISS's STCs (Signaling Transport Cards) which are connected to the ESP/IMF subsystem by Ethernet links. The ESP/IMF subsystem delivers the monitored traffic to the Sentinel/IMF.

## Manual Organization

Throughout this document, the terms database and system software are used. Database refers to all data that can be administered by the user, including shelves, cards, links, routes, global title translation tables, and gateway screening tables. System software refers to data that cannot be administered by the user, including generic program loads (GPLs).

This document is organized into the following sections.

[Chapter 1 Introduction](#) contains an overview of the features described in this manual, general information about the database, and the organization of this manual.

[Chapter 2 X.25 Gateway Configuration](#) describes the X.25 Gateway feature and the procedures necessary to configure the EAGLE 5 ISS to support this feature.

[Chapter 3 STPLAN Configuration](#) describes the STPLAN feature and the procedures necessary to configure the EAGLE 5 ISS to support this feature.

[Chapter 4 Database Transport Access \(DTA\) Configuration](#) describes the Database Transport Access (DTA) feature and the procedures necessary to configure the EAGLE 5 ISS to support this feature.

[Chapter 5 GSM MAP Screening Configuration](#) describes the GSM MAP Screening feature and the procedures necessary to configure the EAGLE 5 ISS to support this feature.

[Chapter 6 EAGLE 5 Integrated Monitoring Support Configuration](#) describes the Eagle 5 Integrated Monitoring Support feature and the procedures necessary to configure the EAGLE 5 ISS to support this feature.

## Related Publications

For information about additional publications that are related to this document, refer to the *Related Publications* document. The *Related Publications* document is published as a part of the *Release Documentation* and is also published as a separate document on the Tekelec Customer Support Site.

## Documentation Availability, Packaging, and Updates

Tekelec provides documentation with each system and in accordance with contractual agreements. For General Availability (GA) releases, Tekelec publishes a complete EAGLE 5 ISS documentation set. For Limited Availability (LA) releases, Tekelec may publish a documentation subset tailored to specific feature content or hardware requirements. Documentation Bulletins announce a new or updated release.

The Tekelec EAGLE 5 ISS documentation set is released on an optical disc. This format allows for easy searches through all parts of the documentation set.

The electronic file of each manual is also available from the Tekelec Customer Support site. This site allows for 24-hour access to the most up-to-date documentation.

Printed documentation is available for GA releases on request only and with a lead time of four weeks. The printed documentation set includes pocket guides for commands and alarms. Pocket guides may also be ordered as a set or individually. Exceptions to printed documentation are:

- Hardware or Installation manuals are printed only without the linked attachments found in the electronic version of the manuals.
- The Release Notice is available only on the Customer Support site.

**NOTE: Customers may print a reasonable number of each manual for their own use.**

Documentation is updated when significant changes are made that affect system operation. Updates resulting from Severity 1 and 2 PRs are made to existing manuals. Other changes are included in the documentation for the next scheduled release. Updates are made by re-issuing an electronic file to the customer support site. Customers with printed documentation should contact their Sales Representative for an addendum. Occasionally, changes are communicated first with a Documentation Bulletin to provide customers with an advanced notice of the issue until officially released in the documentation. Documentation bulletins are posted on the Customer Support site and can be viewed per product and release.

Content changes are indicated with change bars, the revision of the manual part number is incremented, and the month of publication is updated.

## Documentation Admonishments

Admonishments are icons and text throughout this manual that alert the reader to assure personal safety, to minimize possible service interruptions, and to warn of the potential for equipment damage.

**Table 1-1. Admonishments**

	<b>DANGER:</b> (This icon and text indicate the possibility of <i>personal injury</i> .)
	<b>WARNING:</b> (This icon and text indicate the possibility of <i>equipment damage</i> .)
	<b>CAUTION:</b> (This icon and text indicate the possibility of <i>service interruption</i> .)

## Customer Care Center

The Tekelec Customer Care Center offers a point of contact for product and service support through highly trained engineers or service personnel. The Tekelec Customer Care Center is available 24 hours a day, 7 days a week at the following locations:

- Tekelec, USA  
Phone:  
+1 888 367 8552 (US and Canada only)

+1 919 460 2150 (international)

Email: *support@tekelec.com*

- Tekelec, Europe

Phone: +44 1784 467804

Email: *ecsc@tekelec.com*

When a call is received, a Customer Service Report (CSR) is issued to record the request for service. Each CSR includes an individual tracking number.

After a CSR is issued, the Customer Care Center determines the classification of the trouble. If a critical problem exists, emergency procedures are initiated. If the problem is not critical, information regarding the serial number of the system, COMMON Language Location Identifier (CLLI), initial problem symptoms (includes outputs and messages) is recorded. A primary Customer Care Center engineer is also assigned to work on the CSR and provide a solution to the problem. The CSR is closed when the problem is resolved.

## Emergency Response

In the event of a critical service situation, emergency response is offered by the Tekelec Customer Care Center 24 hours a day, 7 days a week. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

A critical situation is defined as a problem with an EAGLE 5 ISS that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical problems affect service and/or system operation resulting in:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with the Tekelec Customer Care Center.

## Maintenance and Administration Subsystem

The maintenance and administration subsystem consists of two processors, MASP (maintenance and administration subsystem processor) A and MASP B.

Each MASP is made up of two cards, the GPSM-II card (general purpose service module) and the TDM (terminal disk module).

The GPSM-II card contains the communications processor and applications processor and provides connections to the IMT bus. The GPSM-II controls the maintenance and database administration activity.


The TDM contains the fixed disk drive, the terminal processor for the 16 serial I/O ports and interfaces to the MDAL (maintenance disk and alarm) card which contains the removable cartridge drive and alarm logic. There is only one MDAL card in the maintenance and administration subsystem and it is shared between the two MASPs.

For more information on these cards, go to the *Hardware Manual - EAGLE 5 ISS* .

## EAGLE 5 ISS Database Partitions

The data that the EAGLE 5 ISS uses to perform its functions are stored in two separate areas: the fixed disk drives, and the removable cartridge. The following sections describe these areas and data that is stored on them. These areas and their partitions are shown in [Figure 1-1](#) .

**Figure 1-1.** EAGLE 5 ISS Database Partitions



## Fixed Disk Drive

There are two fixed disk drives on the EAGLE 5 ISS. The fixed disk drives contain the “master” set of data and programs for the EAGLE 5 ISS. The two fixed disk drives are located on the terminal disk modules (TDMs). Both disks have the same files. The data stored on the fixed disks is partially replicated on the various cards in the EAGLE 5 ISS. Changes made during database administration sessions are sent to the appropriate cards.

The data on the fixed disks can be viewed as four partitions.

- Current partition
- Backup partition
- Measurements partition
- Generic program loads (GPLs) partition

The data which can be administered by users is stored in two partitions on the fixed disk, a current database partition which has the tables which are changed by on-line administration, and a backup database partition which is a user-controlled copy of the current partition.

All of the on-line data administration commands effect the data in the current partition. The purpose of the backup partition is to provide the users with a means of rapidly restoring the database to a known good state if there has been a problem while changing the current partition.

A full set of GPLs is stored on the fixed disk, in the GPL partition. There is an approved GPL and a trial GPL for each type of GPL in this set and a utility GPL, which has only an approved version. Copies of these GPLs are downloaded to the EAGLE 5 ISS cards. The GPL provides each card with its functionality. For example, the **ss7ansi** GPL provides MTP functionality for link interface modules (LIMs).

Measurement tables are organized as a single partition on the fixed disk. These tables are used as holding areas for the measurement counts.

## Removable Cartridge

A removable cartridge is used for two purposes.

- To hold an off-line backup copy of the administered data and system GPLs
- To hold a copy of the measurement tables

Because of the size of the data stored on the fixed disk drives on the TDMs, a single removable cartridge cannot store all of the data in the database, GPL and measurements partitions.

To use a removable cartridge to hold the system data, it must be formatted for system data. To use a removable cartridge to hold measurements data, it must be formatted for measurements data. The EAGLE 5 ISS provides the user the ability to format a removable cartridge for either of these purposes. A removable cartridge can be formatted on the EAGLE 5 ISS by using the **format-disk** command. More information on the **format-disk** command can be found in the *Commands Manual*. More information on the removable cartridge drives can be found in the *Hardware Manual - EAGLE 5 ISS*.

The removable cartridge drive is located on the MDAL card in card location 1117.

Additional and preformatted removable cartridges are available from the [Customer Care Center](#) .

## Locate Product Documentation on the Customer Support Site

To view or download product documentation, log into the Tekelec Customer Support site at:

<https://support.tekelec.com/index.asp>

1. Log in with your user name and password. (Click on **Need an Account?** if you need to register).
2. Select **EAGLE** from the Product Support menu.
3. Select the release number from the Release menu.
4. Locate the Notices section to view the latest Feature Notice.
5. Locate the Manuals section to view all manuals applicable to this release.

The documentation is listed in alphabetical order by the manual name. Only the first three manuals display. Click **more...** to see the remaining manuals.

6. Locate the latest revision of the manual name.

Confirm the release number and last available revision.

Select the 936-xxxx-x01 part number to download the complete documentation set with all linked files.

**NOTE: The electronic file for this part number is quite large.**

7. To view a manual, double-click the manual name.
8. To download a manual, right-click and select **Save Target As**.

**NOTE: Customers may print a reasonable number of each manual for their own use.**

## X.25 Gateway Configuration


The X.25 Gateway .....	2-1
Connectivity to the X.25 Node .....	2-2
Message Conversion .....	2-2
Address Mapping .....	2-3
X.25 Gateway Description .....	2-3
X.25 Gateway Routing .....	2-3
Connection Determination .....	2-4
X.25 Connection Control .....	2-5
Same Link Management .....	2-6
Logical Channel to Network Management Mapping .....	2-6
X.25 Gateway Routing on Mated STPs .....	2-7
X.25 Gateway Configuration Procedures .....	2-7
Adding an X.25 LIM .....	2-10
Removing an X.25 LIM .....	2-14
Adding an X.25 Gateway Destination .....	2-20
Removing an X.25 Gateway Destination .....	2-26
Changing an X.25 Gateway Destination .....	2-28
Adding an X.25 Linkset .....	2-32
Removing a Linkset Containing X.25 Signaling Links .....	2-51
Changing an X.25 Linkset .....	2-58
Adding an X.25 Signaling Link .....	2-82
Removing an X.25 Signaling Link .....	2-93
Adding an X.25 Route .....	2-97
Removing an X.25 Route .....	2-112
Changing an X.25 Route .....	2-114
Changing the X.25 Signaling Link Parameters .....	2-127
Enabling the Large System # Links Controlled Feature .....	2-131

### The X.25 Gateway

The EAGLE 5 ISS X.25/SS7 gateway feature provides connectivity between SS7 and X.25 networks. This enables cellular (IS.41) applications using different transport services to connect. The gateway is physically positioned

between the SS7 network and X.25 network. See [Figure 2-1](#). The gateway transports IS.41 messages from one network to the other using the SS7 Transaction Capability Application Part (TCAP) protocol.

**Figure 2-1.** X.25 Gateway Network



The X.25 gateway requires a new communications capability between SS7 and X.25 networks. The gateway uses a LIM card running the **ss7gx25** application. The LIM supports the DS0A, OCU, or V.35 interfaces at lines speeds of 4800, 9600, 19,200, 56,000, and 64,000 bps.

The card looks and operates like any other LIM card. The card is labeled as a LIM-DS0, LIM-V35, and so forth. It can perform gateway screening. It must also provide three distinct functional components: MTP (Level 3) processing, IS.41 gateway and X.25 conversion.

The MTP Level 3 processing is similar to the operation on SS7 LIM cards. The IS.41 gateway function converts the MTP portion of the packet to X.25 protocol. The X.25 function controls the X.25 protocol and the X.25 link status.

### Connectivity to the X.25 Node

The gateway supports these two types of connectivity to the X.25 node:

- direct connectivity
- connectivity through a public or private data network

If the gateway has a direct link to the X.25 node, the gateway appears as a DCE to the X.25 node. The gateway can also connect to the X.25 node through a public data network where it appears as a DTE to the X.25 network.

### Message Conversion

The gateway performs the message conversion for all TCAP traffic in both directions. The message conversion removes and adds protocol envelopes used by the X.25 and SS7 networks. The TCAP portion of the data is not changed. The MTP/SCCP of SS7 is converted to X.25 and reverse, depending upon the traffic direction. TCAP is passed through the gateway unchanged. IS.41 uses TCAP as the “carrier.”

## Address Mapping

In order to route traffic between networks, the gateway performs address mapping between the X.25 domain and the SS7 domain. The X.25 application entities and the SS7 application entities must have addresses not only in their domain but also in the opposite network domain. For example, the X.25 application entity is addressed by the SS7 network using a pseudo point code and pseudo subsystem number (XPC and XSSN). Conversely, the SS7 application entity must be addressed by the X.25 network using a pseudo X.25 network address (SADDR).

## X.25 Gateway Description

X.25 requires that any data that is transmitted must be sent on a connection. A connection represents a route between two application entities (one in the X.25 domain and one in the SS7 domain). It must exist before any messages can be transferred. The connection can be one of three types:

- PVC (permanent virtual circuit): A fixed connection that can only be altered through administration.
- SVCA (switched virtual circuit-automatic): A connection established by the STP as soon as the X.25 gateway card initializes.
- SVCR (switched virtual circuit-remote): A connection established by the X.25-user end when necessary.

For these connections, a route must be defined through administration. Every application entity that can be connected through the gateway must be defined. The association between the application entities must also be defined.

An X.25 link appears to the STP as though it is an SS7 link. Adjacent point codes are either the originating point code of the X.25 distant end (if the connection is direct), or a virtual point code (if the connection is through a network). This is equivalent to routing through an adjacent STP to the signaling points connected to it. See [Figure 2-1](#).

As messages travel from the X.25 network to the SS7 network, the gateway determines the destination point code (DPC) and adds the SS7 SCCP and MTP envelopes to the TCAP message. The gateway determines the virtual circuit and removes the SCCP and MTP envelopes on messages transmitted from the SS7 network side to an X.25 destination.

Other attributes of the gateway are as follows:

- Each X.25 link supports up to 255 logical channels as SVCs or PVCs or a combination.
- The EAGLE 5 ISS supports up to 1024 X.25 logical connections. If the 2000 X.25 routes feature is turned on, shown by the entry **x252000 = on** in the **rtrv-feat** command output, the EAGLE 5 ISS supports up to 2000 X.25 logical connections.
- All X.25 network-initiated calls are accepted when the calling X.25 node is correctly defined in the STP.
- Gateway screening is supported from the X.25 to the SS7 network.
- Routing does not occur through the X.25 gateway between two X.25 points.
- X.25 networks that do not supply the calling address in the call request are not supported for network-initiated connections.

## X.25 Gateway Routing

Gateway routing is performed through four different functions:


- Connection Determination
- X.25 Connection Control
- Same-Link Management
- Logical Channel to Network Management Mapping

### Connection Determination

The destination address for X.25 is defined as a destination element (X.25 DE). An X.25 DE is an object on the X.25 network to which a connection can be made and has a point code assigned to it. An X.25 link can be either point-to-point (direct) or through an intermediary network. A destination for SS7 is a point code, plus an optional subsystem number (SSN).

A destination for X.25 is dependent upon whether a connection is established. A connection is defined as a pair of destinations that are exchanging messages. The destination for X.25 is an X.25 address before connection, and a logical channel (LC) after connection. One of the destinations must be in the X.25 domain and the other in the SS7 domain. See [Figure 2-2](#).

**Figure 2-2.** X.25 Gateway Connection Determination



The connection is determined using the gateway routing table (GRT). This process can be divided by whether the message arrives from the X.25 side (inbound) or the SS7/MTP side (outbound):

- Inbound messages:  
If the logical channel on which the message arrives is in the connected state, it already points to an entry in the gateway routing table. The destination point code (DPC) is the value in the SS7 point code field. The origination point code (OPC) is the value in the X.25 point code field.  
For an incoming SVC (SVCR), the X.25 user must first establish the connection.
- Outbound messages:  
The DPC is used to locate the connection on which to send the message. The order of the lookup in the GRT is as follows:
  1. The STP locates an entry in the X.25 point code field that matches the DPC. If no entry is found for that point code, the gateway produces MRN #1140 and the MSU is discarded.

**NOTE: If no entry is found, or an SVCA defined, the connection cannot be established.**

2. The STP verifies that the OPC matches the SS7 point code field. If there is no match, the gateway produces MRN #1134 and the MSU is discarded.
3. Once the connection entry is found in the Gateway Routing Table (GRT), the STP examines the card address field and proceeds as follows:

**Table 2-1. Card Address Field Action**

If...	then...
the card address is the same as the card that receives the MSU,	the routing is complete and the message passes to format conversion.
the card address is not the same card that receives the MSU,	the STP passes the MSU to "single link" management for the card defined in the card address field.

### X.25 Connection Control

There is an additional routing requirement, connection routing and control, that is different from SS7 routing.

A connection must be established before any message can be transferred between the STP and an X.25 DE. A connection is established depending upon when and where the connection is made.

A fixed connection route is defined through administration and can be either PVC (permanent virtual circuit), SVCA (switched virtual circuit-automatic) or SVCR (switched virtual circuit - remote). If the connection type field is PVC, the PVC is already established when the link is initialized through provisioning in the public data network (PDN) and STP. The PVC remains in effect while the link is operational.

If the connection type field is SVCA, the connection is established by the designated LIM card (defined in the location field) immediately after the link becomes initialized. It is possible that the remote end becomes available during this cycle, and makes the connection from the remote end. The remote end could make the connection to any card. The connection remains in effect while the link is operational or until the remote end fails or clears the connection.

If the connection type field is SVCR, the connection can only be made by the X.25 DE as follows:

If an X.25 DE wants to send a message to an SS7 node, and the STP has not established a connection to that node, the X.25 DE attempts to establish one before sending the message. The X.25 DE establishes the connection by sending a call request to the STP with identification in the calling address field, and the SS7 node in the called address field.

When the STP receives the incoming call, the STP verifies both the calling and called addresses using the X.25 address and SS7 address fields. If the STP finds an entry for the X.25 address pair, it checks to see if a connection is active.

**Table 2-2. Connection Action**

If...	then...
the connection is active,	the STP clears the incoming call.
the connection is not active, and the SS7 point code is accessible from the STP,	it is set as active. Otherwise, the STP clears the incoming call.

If...	then...
an entry for the X.25 address pair is not found,	the STP checks the X.25 destination table to see if the designated X.25 addresses are present.
both addresses are present (the caller is in the X.25 domain and the called address is in the SS7 domain),	the connection is established and a temporary entry is added to the database.

### Same Link Management

X.25 requires that if there is a set of links into a PDN (or directly to an X.25 DE), a response to a request must be returned on the same link and logical channel as the request was received. Because MTP routing does not use a particular link on a linkset, it is likely that a response would go to a non-originating LIM. Same link management assures that the message is sent out on the same link. This is achieved by each LIM informing all others LIMs when the state of a connection changes.

### Logical Channel to Network Management Mapping

The EAGLE 5 ISS X.25/SS7 gateway also provides management procedures for failed X.25 logical channels. This feature allows traffic destined for failed logical channels to be rerouted to an alternate route.

When configuring logical channel to network management mapping (LC2NM), you must determine if the X.25 entity is expecting associated queries and responses to use the same logical channel, or if they may be assigned to different logical channels. If associated queries and responses can be received over different logical channels, load balancing and failure recovery through alternate routing is supported.

If logical channel to network management mapping is enabled, and the X.25 entity can receive associated queries and responses on different logical channels, data destined to a failed logical channel is diverted by forced rerouting procedures in the EAGLE 5 ISS to the alternate route. All other associated traffic is diverted, and the logical channels to which associated traffic is assigned are made unavailable.

If the X.25 entity expects all associated queries and responses to be received on the same logical channel, traffic is still diverted to the alternate route if the logical channel fails. Forced rerouting procedures are not needed in this case.

If the alternate route is not available, the EAGLE 5 ISS uses level three network management procedures. For example, an X.25 link interface module (LIM) determines a logical channel has failed. Network management diverts traffic away from the failed logical channel to a defined terminate route.

No network management messages are sent outside the EAGLE 5 ISS, and therefore should have no adverse effects on the SS7 network. The EAGLE 5 ISS uses SS7 network management procedures in software to divert traffic from the failed X.25 signaling link to another X.25 signaling link.

If route management mapping is not enabled on the X.25 linkset, there is no indication of logical channel failures. An unsolicited alarm message (UAM) output is created, which provides a textual message to indicate failure of an X.25 logical channel. All traffic destined to the failed logical channel is discarded.

If X.25 level 2 should fail within the X.25 LIM, all X.25 routes associated with the LIM are considered unavailable and forced rerouting procedures are used.

In either of the above cases, when the logical channel is restored to service, network management will divert traffic back to the newly restored logical channel.

## X.25 Gateway Routing on Mated STPs

If the network uses two STPs as gateways between an X.25 network (or set of X.25 networks) and the SS7 network, there are special routing considerations.

To use the mated STPs, you must define two connections between each pair of nodes that communicate through the mated pair. The view is different for the X.25 node and the SS7 node. To the SS7 node, there is one destination for the messages. To the X.25 node, there are two X.25 address pairs that represent this same logical connection.

The X.25 application on one MSC sees two connection paths to another MSC – one is primary the other secondary.

## X.25 Gateway Configuration Procedures

For the EAGLE 5 ISS to implement the X.25/SS7 gateway feature, the EAGLE 5 ISS must be configured to support the X.25 network. These items must be configured to support the X.25 network.


- X.25 LIMs
- X.25 gateway destinations
- X.25 linksets
- X.25 signaling links
- X.25 routes
- X.25 signaling link parameters – if the default X.25 signaling link parameters need to be changed

The procedures shown in this chapter use a variety of commands. If more information on these commands is needed, go to the *Commands Manual* to find the required information.

In addition to the X.25 gateway destinations, X.25 linksets, X.25 signaling links, X.25 routes, and X.25 signaling link parameters, other entities must be provisioned in the database to support the X.25 network. The entities that are required for the particular X.25 entity are listed with the particular procedure. They are also shown here to give an overview of what is required to configure the EAGLE 5 ISS to support the X.25 network. These entities must also be provisioned in the order that they are shown.

[Figure 2-3](#) shows the relationships of the database elements that are configured in these procedures.

Figure 2-3. X.25 Gateway Database Relationships



1. The X.25/SS7 gateway feature must be turned on with the **chg-feat:x25g=on** command. If the database is to contain more than 1024 X.25 destinations and routes, the 2000 X.25 routes feature must be turned on with the **chg-feat:x252000=on** command. The **rtrv-feat** command is used to verify whether these features are on or off.

**NOTE: Once the X.25 gateway feature and the 2000 X.25 routes features are turned on with the chg-feat command, they cannot be turned off.**

2. Make sure that the required shelf is in the database with the **rtrv-shlf** command. If it is not in the database, add it with the **ent-shlf** command.
3. Make sure the cards that the X.25 signaling links will be assigned to are in the database with the **rtrv-card** command. These cards must be LIMs (card types **limds0**, **limocu**, or **limv35**) and must have the **ss7gx25** application assigned to them. If these cards are not in the database, add them with the

**ent-card** command, specifying a LIM (:type=limds0, :type=limocu, or :type=limv35) and the **ss7gx25** application ( :appl=ss7gx25).

4. The X.25 network configuration for the EAGLE 5 ISS requires linksets, routes, and X.25 destinations. These entities use point codes and these point codes must be defined in the database. Verify that the necessary point codes are in the database with the **rtrv-dstn** command. If they are not in the database, add them with the **ent-dstn** command. The point codes must also be assigned to the X.25 domain.

**NOTE: No database entity used for the X.25/SS7 gateway feature can contain ITU international and ITU national point codes. The ent-dstn command does not allow an ITU international or ITU national point code to be assigned to the X.25 domain.**

5. The X.25 destination, used to assign an X.25 address to a point code, must be in the database. Verify this with the **rtrv-x25-dstn** command. If it is not in the database, add it with the **ent-x25-dstn** command, specifying a point code in the X.25 domain.
6. The linksets that will contain the X.25 signaling links must be in the database. These linksets must be assigned an adjacent point code (APC) that is in the X.25 domain. Verify this with the **rtrv-ls** command. If the APC is in the X.25 domain, the entry **x25** is shown in the **DOMAIN** field of the output. If the necessary linksets are not in the database, add them with the **ent-ls** command, specifying an APC that is in the database and in the X.25 domain, added in step 4.
7. The X.25 signaling links must be in the database. Verify this with the **rtrv-slk** command. The X.25 signaling links are assigned to linksets in the X.25 domain, from step 6 and to LIMs with the **ss7gx25** application, from step 3. They also have dashes in the **L2TSET** field in the **rtrv-slk** command. If the necessary X.25 signaling links are not in the database, add them with the **ent-slk** command. These signaling links must be assigned to LIMs with the **ss7gx25** application and to linksets whose APC is in the X.25 domain.
8. When the X.25 signaling links are added to the database, there are parameters that control the behavior of these signaling links that are not configured with the **ent-slk** command and are assigned default values. These values can be changed with the **chg-x25-slk** command. If you wish to change the values for these parameters, display the current values with the **rtrv-x25-slk** command. Change these values with the **chg-x25-slk** command.
9. The point codes assigned to each of the X.25 destinations must also be assigned to a route. A route must also be assigned to the linksets containing the X.25 APCs. Verify this with the **rtrv-rte** command. If the necessary routes are not in the database, add them to the database with the **ent-rte** command, specifying a point code assigned to an X.25 destination, from step 5, and a linkset with an X.25 APC, from step 6.
10. The X.25 routes, containing the X.25 addresses from step 5, and the X.25 signaling links from step 7, must be in the database. The connection type assigned to each X.25 route must conform to the number of connection types allowed for X.25 signaling link assigned to the X.25 route. This is shown in output of the **rtrv-x25-slk** command, from step 8, in the **PVC** and **SVC** fields. Verify this with the **rtrv-x25-rte** command. If the X.25 routes are not in the database, add them with the **ent-x25-rte** command.

[Figure 2-4](#) shows a typical network configuration and [Table 2-3](#) shows the information in the gateway routing table (GRT) after the typical network is provisioned.

Figure 2-4. Typical X.25/SS7 Gateway Configuration




Table 2-3. Typical X.25/SS7 Gateway Routing Table

Conn #	X.25 Address	SS7 Address	X.25 Point Code/SSN	SS7 Point Code/SSN	Connection Type	Location	Port	Logical Channel
1	11101	44401	1-1-1/5	4-4-4/5	PVC	1205	A	1
2	11102	55501	1-1-1/5	5-5-5/5	PVC	1206	A	2
3	22201	44401	2-2-2/5	4-4-4/5	PVC	1205	A	2
4	22202	55501	2-2-2/10	5-5-5/10	PVC	1206	A	1
5	33301	44401	3-3-3/6	4-4-4/6	Auto-SVC	1207	A	--
6	33302	55501	3-3-3/7	5-5-5/7	Auto-SVC	1207	A	--

## Adding an X.25 LIM

This procedure is used to add an X.25 LIM to the database using the **ent-card** command. The **ent-card** command uses these parameters.

**:loc** – The location of the card being added to the database.

**:type** – The type of card being added to the database. The X.25 LIM can be assigned to one of three card types: **limds0**, **limocu**, or **limv35**. [Table 2-4](#) shows the names and part numbers of the cards that can be configured as X.25 LIMs in the database. This can be used to verify that the card being entered into the database matches the card physically installed in the EAGLE 5 ISS.

**Table 2-4. X.25 LIM Card Type Combinations**

Card Name	Part Number	Card Type (:type)
LIM or LIM-AINF	870-1014-XX 870-1488-XX	limds0, limocu, limv35
EILA	870-2049-XX	limds0, limocu, limv35
LIM-DS0	870-1009-XX 870-1485-XX	limds0
LIM-OCU	870-1010-XX 870-1486-XX	limocu
LIM-V.35	870-1012-XX 870-1487-XX	limv35
The LIM, LIM-AINF, or EILA is a link interface module using the AINF interface and can be installed in place of the LIM-DS0, LIM-OCU, or LIM-V.35. It is configured in the database as either a LIM-DS0, LIM-OCU, or LIM-V.35 card.		

**:appl** – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is **ss7gx25**.

**:force** – If the global title translation feature is on, the **force=yes** parameter allows the LIM to be added to the database even if the current SCCP transactions-per-second threshold is unable to support the additional SCCP transaction-per-second capacity created by adding the LIM. This parameter is obsolete and is no longer used.

The shelf to which the card is to be added, must already be in the database. This can be verified with the **rtrv-shlf** command. If the shelf is not in the database, see the Adding a Shelf procedure in the *Database Administration Manual – System Management*.

The card cannot be added to the database if the specified card location already has a card assigned to it.

Before an X.25 LIM can be configured in the database, the X.25 gateway feature must be turned on with the **chg-feat** command. The **rtrv-feat** command can verify that the X.25 gateway feature is on.

**NOTE: Once the X.25 gateway feature is turned on with the chg-feat command, it cannot be turned off.**

The examples in this procedure are used to configure an X.25 LIM on a LIM-V.35 card in card slot 1202 in the database.

**Procedure**

1. Display the cards in the EAGLE 5 ISS using the **rtrv-card** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE   APPL   LSET NAME   LINK SLC LSET NAME   LINK SLC
1101   TSM     SCCP
1102   TSM     GLS
1113   GPSM    EOAM
1114   TDM-A
1115   GPSM    EOAM
1116   TDM-B
    
```

1117	MDAL								
1117	MDAL								
1201	LIMDS0	SS7ANSI	sp2	A	0	sp1	B	0	
1203	LIMDS0	SS7ANSI	sp3	A	0				
1204	LIMDS0	SS7ANSI	sp3	A	1				
1206	LIMDS0	SS7ANSI	nsp3	A	1	nsp4	B	1	
1207	LIMV35	SS7GX25	nsp1	A	0				
1208	LIMV35	SS7GX25	nsp1	A	1				
1216	ACMENET	STPLAN							
1301	TSM	SCCP							
1308	LIMDS0	SS7ANSI	sp6	A	1	sp7	B	0	
1314	LIMDS0	SS7ANSI	sp7	A	1	sp5	B	1	
1317	ACMENET	STPLAN							

The cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution. If the **APPL** field of the **rtrv-card** command output shows cards assigned to the **ss7gx25** GPL, skip steps 2, and 3, and go to step 4.

2. Verify that the X.25 gateway and global title translation features are on, by entering the **rtrv-feat** command.

If the X.25 gateway feature is on, the **X25G** field should be set to **on**. For this example, the X.25 gateway feature is off.

If the global title translation feature is on, shown by the entry **GTT = on** in the **rtrv-feat** output, then the EAGLE 5 ISS must contain the proper number of SCCP cards to support the X.25 LIM being added.

**NOTE: The rtrv-feat command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the rtrv-feat command, see the rtrv-feat command description in the Commands Manual.**

If the X.25 gateway feature is on and the global title translation feature is off, skip steps 3, 4, and 5, and go to step 6.

If the X.25 gateway and global title translation features are on, skip steps 3, and 4 and go to step 5.

3. If the X.25 gateway feature is not on, shown by the **X25G = off** entry in the **rtrv-feat** command output in step 2, turn the X.25 gateway feature on by entering this command.

**chg-feat:x25g=on**

**NOTE: Once the X.25 gateway feature is turned on with the chg-feat command, it cannot be turned off.**

When the **chg-feat** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 00:57:31 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

4. Using [Table 2-4](#) as a reference, verify that the card has been physically installed into the proper location.
5. Add the card using the **ent-card** command.

For this example, enter this command.

**ent-card:loc=1202:type=limv35:appl=ss7gx25**

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD
```

6. Verify the changes using the **rtrv-card** command with the card location specified.

For this example, enter this command.

**rtrv-card:loc=1202**

This is an example of the possible output.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1202   LIMV35     SS7GX25
```

7. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-1. Adding an X.25 LIM to the Database



## Removing an X.25 LIM

This procedure is used to remove an X.25 LIM from the database using the **dlt-card** command.

The card being removed must exist in the database.



**CAUTION:** If the X.25 LIM is the last X.25 LIM in service, removing this card from the database will cause X.25 traffic to be lost.

The examples in this procedure are used to remove the X.25 LIM in card location 1202.

### Canceling the **REPT-STAT-CARD** Command

Because the **rept-stat-card** command used in this procedure can output information for a long period of time, the **rept-stat-card** command can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-card** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-card** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-card** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-card** command was entered, from another terminal other than the terminal where the **rept-stat-card** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the cards in the database using the **rtrv-card** command. The X.25 LIMs are shown by the entry **SS7GX25** in the **APPL** field. This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM         SCCP
1102   TSM         GLS
1113   GPSM       EOAM
1114   TDM-A
1115   GPSM       EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI   sp2             A    0    sp1            B    0
1202   LIMV35     SS7GX25
1203   LIMDS0     SS7ANSI   sp3             A    0
1204   LIMDS0     SS7ANSI   sp3             A    1
1206   LIMDS0     SS7ANSI   nsp3            A    1    nsp4           B    1
1207   LIMV35     SS7GX25   nsp1            A    0
1208   LIMV35     SS7GX25   nsp1            A    1
1216   ACMENET    STPLAN
1301   TSM         SCCP
1308   LIMDS0     SS7ANSI   sp6             A    1    sp7            B    0
1314   LIMDS0     SS7ANSI   sp7             A    1    sp5            B    1
1317   ACMENET    STPLAN
```

2. Display the current configuration of the X.25 routes in the database by entering the **rtrv-x25-rte** command. This is an example of the possible output.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE LOC  PORT  LC  RT  LC2NM
2510010011234567 342342341234567 pvc 1202 a    02  xpc  no
251001002      234234231    pvc 1202 a    04  pc   no
51200105      34223422845  svca 1202 a    --  pc   no
2510103      232330       pvc 1206 a    06  xpc  yes
2510103      232330       svcr ---- -    --  pc   no
2516019002    24247235     svca 1206 a    --  pc   no
```

```
345454          4545434          svca 1206 a    -- pc no
X.25 ROUTE TABLE IS 30 % FULL
```

- Remove the X.25 route assigned to the card that you wish to remove (in this example, 1202) by entering the **dlt-x25-rte** command. For this example, enter these commands.

```
dlt-x25-rte:xaddr=2510010011234567:saddr=342342341234567
```

```
dlt-x25-rte:xaddr=251001002:saddr=234234231
```

```
dlt-x25-rte:xaddr=51200105:saddr=34223422845
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-X25-RTE: MASP A - X.25 Route table 45% full
DLT-X25-RTE: MASP A - COMPLTD
```

- Display the status of the X.25 signaling link assigned to the card by entering the **rept-stat-slk** command, specifying the card location and the signaling link. For this example, enter this command.

```
rept-stat-slk:loc=1202:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1202,A   lsngwy   -----  IS-NR    Avail    ----
        ALARM STATUS      = No Alarms.
        UNAVAIL REASON   = --
Command Completed.
```

- If the X.25 signaling link is not in an OOS-MT-DSBLD state, deactivate the X.25 signaling link using the **dact-slk** command. For this example, enter this command.

```
dact-slk:loc=1202:link=a
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

- Display the cards that are in service with the **rept-stat-card:stat=nr** command.

```
rept-stat-card:stat=nr
```

This is an example of the possible output.

```
rlghncxa03w 06-10-27 16:43:42 GMT EAGLE5 36.0.0
CARD  VERSION  TYPE  GPL  PST  SST  AST
1101  113-003-000  TSM  SCCP  IS-NR  Active  ---
1102  113-003-000  TSM  GLS  IS-NR  Active  ---
1109  113-003-000  HMUX  BPHMUX  IS-NR  Active  ---
1110  113-003-000  HMUX  BPHMUX  IS-NR  Active  ---
1201  113-003-000  LIMDS0  SS7ANSI  IS-NR  Active  ---
1202  113-003-000  LIMV35  SS7GX25  IS-NR  Active  ---
1203  113-003-000  LIMDS0  SS7ANSI  IS-NR  Active  ---
1204  113-003-000  LIMDS0  SS7ANSI  IS-NR  Active  ---
1206  113-003-000  LIMDS0  SS7ANSI  IS-NR  Active  ---
1207  113-003-000  LIMV35  SS7GX25  IS-NR  Active  ---
1208  113-003-000  LIMV35  SS7GX25  IS-NR  Active  ---
1209  113-003-000  HMUX  BPHMUX  IS-NR  Active  ---
1210  113-003-000  HMUX  BPHMUX  IS-NR  Active  ---
1216  113-003-000  ACMENET  STPLAN  IS-NR  Active  ---
1301  113-003-000  TSM  SCCP  IS-NR  Active  ---
```

1308	113-003-000	LIMDS0	SS7ANSI	IS-NR	Active	---
1309	113-003-000	HMUX	BPHMUX	IS-NR	Active	---
1310	113-003-000	HMUX	BPHMUX	IS-NR	Active	---
1314	113-003-000	LIMDS0	SS7ANSI	IS-NR	Active	---
1317	113-003-000	ACMENET	STPLAN	IS-NR	Active	---

7. If the signaling link on the card to be removed from the database is the last signaling link in a linkset, the **force=yes** parameter must be used with the **dlt-slk** command. To verify this, enter the **rtrv-ls** command with the linkset name shown in step 1 (**LSET NAME** field). For this example, enter this command.

```
rtrv-ls:lsn=lsngwy
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 16:31:35 GMT EAGLE5 36.0.0

                                L3T SLT                    GWS GWS GWS
LSN          APCA  (X25)  SCR1  SET SET BEI  LST LNKS ACT MES DIS SLSCI NIS
lsngwy       240-020-000  scr1  1  1  yes A  1  off off off yes  off

CLLI          TFATCABMLQ MTPRSE ASL8
-----      -
IPGWAPC MATELSN  IPTPS LSUSEALM SLKUSEALM GTTMODE
no          -----
PCR PCR
LOC LINK SLC TYPE  L2T      L1          ECM  N1  N2
1202 A  0  LIMV35  1  56000  ---  ---  BASIC  ---  -----

Link set table is ( 10 of 1024) 1% full
```

8. Inhibit the card using the **rmv-card** command, specifying the card location. If the LIM to be inhibited contains the only signaling link in the linkset that is in service, the **force=yes** parameter must also be specified. For this example, enter this command.

```
rmv-card:loc=1202:force=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
Card has been inhibited.
```

9. Remove the signaling link on the specified card by using the **dlt-slk** command. If the output of step 7 shows that the signaling link being removed is the last signaling link in a linkset, the **force=yes** parameter must be used. For this example, enter this command.

```
dlt-slk:loc=1202:link=a:force=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD
```

10. Remove the card using the **dlt-card** command with the card location of the card to be removed. The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter this command.

```
dlt-card:loc=1202
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0  
DLT-CARD: MASP A - COMPLTD
```

11. Verify the changes using the **rtrv-card** command specifying the card that was removed in step 11. For this example, enter this command.

```
rtrv-card:loc=1202
```


When this command has successfully completed, this message should appear.


```
E2144 Cmd Rej: Location invalid for hardware configuration
```

12. Backup the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-2. Removing an X.25 LIM





## Adding an X.25 Gateway Destination

This procedure is used to add an X.25 destination to the database using the **ent-x25-dstn** command.

The **ent-x25-dstn** command uses these parameters.

**:xaddr** – The X.25 network address of the X.25 destination entity or the SS7 node.

**:dpc** – The real SS7 point code assigned to a real SS7 node or the dummy point code for an X.25 destination entity. The value for this parameter is an ANSI point code.

**:ssn** – The subsystem number of the destination point code to be assigned to the X.25 address.

The examples in this procedure are based on the example network shown in [Figure 2-4](#) and [Table 2-3](#).

A destination point code (DPC) in the X.25 domain – see the "Adding a Destination Point Code" procedure in the *Database Administration Manual – SS7*.

**NOTE: The point code assigned to the X.25 address in the X.25 destination cannot be an ITU international or ITU national point code. The ent-dstn command does not allow an ITU international or ITU national point code to be assigned to the X.25 domain.**

The destination point code specified with the **ent-x25-dstn** command must be a full point code. Cluster point codes and network routing point codes cannot be specified for X.25 destinations. For more information on cluster point codes, go to the "Cluster Routing and Management Diversity" section in the *Database Administration Manual – SS7*. For more information on network routing point codes, go to the "Network Routing" section in the *Database Administration Manual – SS7*.

The X.25 gateway destination to be added cannot already be in the database. This can be verified in step 2.

The X.25/SS7 gateway feature must be turned on. Verify this by entering the **rtrv-feat** command. If the X.25/SS7 gateway feature is off, shown by the entry **X25G = off** in the output of the **rtrv-feat** command, it can be turned on by entering the **chg-feat:x25g=on** command.

If the database is to contain more than 1024 X.25 destinations and routes, The 2000 X.25 routes feature must be turned on. Verify this by entering the **rtrv-feat** command. If the 2000 X.25 routes feature is off, shown by the entry **X252000 = off** in the output of the **rtrv-feat** command, it can be turned on by entering the **chg-feat:x252000=on** command.

**NOTE: Once the X.25 gateway feature and the 2000 X.25 routes features are turned on with the chg-feat command, they cannot be turned off.**

### Canceling the RTRV-DSTN Command

Because the **rtrv-dstn** command used in this procedure can output information for a long period of time, the **rtrv-dstn** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-dstn** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-dstn** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-dstn** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-dstn** command was entered, from another terminal other than the terminal where the **rtrv-dstn** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

### Procedure

1. Verify that the X.25 gateway feature is on, by entering the **rtrv-feat** command.

If the X.25 gateway feature is on, the **X25G** field should be set to **on**. For this example, the X.25 gateway feature is off.

**NOTE: The `rtrv-feat` command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the `rtrv-feat` command, see the `rtrv-feat` command description in the *Commands Manual*.**

If the X.25 gateway feature is on, skip step 2 and go to step 3.

If the X.25 gateway feature is not on, go to step 2.

2. If the X.25 gateway feature is not on, shown by the **X25G = off** entry in the `rtrv-feat` command output in step 1, turn the X.25 gateway feature on by entering this command.

**chg-feat:x25g=on**

**NOTE: Once the X.25 gateway feature is turned on with the `chg-feat` command, it cannot be turned off.**

When the `chg-feat` has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 00:57:31 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

3. Display the DPCs in the database by entering the `rtrv-dstn` command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 16:02:05 GMT EAGLE5 36.0.0
DPCA      CLLI      BEI  ELEI  ALIASI  ALIASN  DOMAIN
020-002-*  rlghncbb000  yes  yes  -----  -----  SS7
004-004-004 -----  yes  ---  -----  -----  SS7
005-005-005 -----  yes  ---  -----  -----  SS7
240-012-004 rlghncbb001  yes  ---  1-111-1  11111  SS7
240-012-005 rlghncbb002  yes  ---  1-112-2  11112  SS7
240-012-006 rlghncbb003  yes  ---  1-112-3  11113  SS7
240-012-008 -----  yes  ---  1-113-5  11114  SS7
001-001-001 -----  yes  ---  -----  -----  X25
002-002-002 -----  yes  ---  -----  -----  X25
003-003-003 -----  yes  ---  -----  -----  X25

DPCI      CLLI      BEI  ELEI  ALIASA  ALIASN  DOMAIN
2-131-1   rlghncbb023  no  ---  222-210-000  12001  SS7
2-131-2   -----  no  ---  222-211-001  12002  SS7
2-131-3   -----  no  ---  222-211-002  12003  SS7

DPCN      CLLI      BEI  ELEI  ALIASA  ALIASI  DOMAIN
11211    rlghncbb013  no  ---  222-200-200  2-121-1  SS7
11212    rlghncbb013  no  ---  222-200-201  2-121-2  SS7

DESTINATION ENTRIES ALLOCATED: 2000
  FULL DPC(s): 14
  EXCEPTION DPC(s): 0
  NETWORK DPC(s): 0
  CLUSTER DPC(s): 1
  TOTAL DPC(s): 15
  CAPACITY (% FULL): 1%
ALIASES ALLOCATED: 8000
  ALIASES USED: 18
  CAPACITY (% FULL): 1%
X-LIST ENTRIES ALLOCATED: 500
RTRV-DSTN: MASP A - COMPLTD
```

If the required DPC is not in the database, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the DPC to the database.

4. Display the X.25 destinations in the database by entering the **rtrv-x25-dstn** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 DPC          SSN
220525586456772  240-012-004  002
234234231         240-012-005  113
23423422834      244-010-006  235
2342342325       244-010-006  236
23423423         244-010-007  112
423423045656767  244-010-008  112
9342              244-010-006  234
X.25 DSTN TABLE IS 30 % FULL
```

If the database is to contain more than 1024 X.25 destinations and routes, the X.25 gateway feature and the 2000 X.25 routes feature must be turned on. If the 2000 X.25 routes feature is on, the **x252000** field in the **rtrv-feat** command output in step 1 should be set to **on**.

If the database is to contain 1024 X.25 destinations and routes or less, skip step 5 and go to step 6.

If the 2000 X.25 routes feature is on, skip step 5 and go to step 6.

If the 2000 X.25 routes feature is off, and the database is to contain more than 1024 X.25 destinations and routes, go to step 5.

5. If the 2000 X.25 routes feature is not on, shown by the **x252000 = off** entry in the **rtrv-feat** command output in step 1, turn the 2000 X.25 routes feature on by entering this command.

```
chg-feat:x252000=on
```

**NOTE: Once the 2000 X.25 routes feature is turned on with the chg-feat command, it cannot be turned off.**

When the **chg-feat** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 00:57:31 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

6. Add the X.25 destination to the database using the **ent-x25-dstn** command.

For this example, enter these commands.

```
ent-x25-dstn:xaddr=11101:dpc=001-001-001:ssn=5
ent-x25-dstn:xaddr=11102:dpc=001-001-001:ssn=5
ent-x25-dstn:xaddr=22201:dpc=002-002-002:ssn=5
ent-x25-dstn:xaddr=22202:dpc=002-002-002:ssn=10
ent-x25-dstn:xaddr=33301:dpc=003-003-003:ssn=6
ent-x25-dstn:xaddr=33302:dpc=003-003-003:ssn=7
ent-x25-dstn:xaddr=44401:dpc=004-004-004
ent-x25-dstn:xaddr=55501:dpc=005-005-005
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:38:53 GMT EAGLE5 36.0.0
X.25 DSTN TABLE 33 % FULL
ENT-X25-DSTN: MASP A - COMPLTD
```

7. Verify the changes using the **rtrv-x25-dstn** command.

This is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 DPC          SSN
11101             001-001-001    005
11102             001-001-001    005
22201             002-002-002    005
22202             002-002-002    010
220525586456772 240-012-004    002
234234231         240-012-005    113
23423422834      244-010-006    235
2342342325       244-010-006    236
23423423         244-010-007    112
33301             003-003-003    006
33302             003-003-003    007
3450912          244-010-005    114
423423045656767 244-010-008    112
44401             004-004-004    005
55501             005-005-005    005
9342             244-010-006    234
X.25 DSTN TABLE IS 30 % FULL
```

8. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-3. Adding an X.25 Gateway Destination



## Removing an X.25 Gateway Destination

This procedure is used to remove an X.25 destination from the database using the `dlt-x25-dstn` command.

The `dlt-x25-dstn` command has only one parameter, `xaddr`, which is the X.25 network address of the X.25 destination entity or the SS7 node.

The examples in this procedure are used to remove the X.25 destination `33301` from the database.

The X.25 gateway destination to be removed must be in the database. This can be verified in step 1.

The X.25 gateway destination to be removed cannot have any X.25 routes assigned to it. This can be verified in step 2.

### Procedure

1. Display the X.25 destinations in the database by entering the `rtrv-x25-dstn` command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 DPC      SSN
11101             001-001-001 005
11102             001-001-001 005
22201             002-002-002 005
22202             002-002-002 010
220525586456772  240-012-004 002
234234231         240-012-005 113
23423422834      244-010-006 235
2342342325       244-010-006 236
23423423         244-010-007 112
33301             003-003-003 006
33302             003-003-003 007
3450912           244-010-005 114
423423045656767  244-010-008 112
44401             004-004-004 005
55501             005-005-005 005
9342              244-010-006 234
X.25 DSTN TABLE IS 30 % FULL
```

2. Verify that there are no X.25 routes assigned to the X.25 destination to be removed by entering the `rtrv-x25-rte` command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 ADDR      TYPE LOC PORT LC RT LC2NM
11101             44401         pvc  1205 a   01 xpc no
11102             55501         pvc  1206 a   02 pc  no
22201             44401         pvc  1205 a   02 pc  no
22202             55501         pvc  1206 a   01 xpc yes
33301             44401         svca 1207 a   -- pc  no
33302             55501         svca 1207 a   -- pc  no
X.25 ROUTE TABLE IS 30 % FULL
```

3. If the X.25 destination to be removed, shown in the `X25 ADDR` column in the output of step 1, is shown in either the `X25 ADDR` or `SS7 ADDR` columns in the output of step 2, then the X.25 destination has an X.25 route assigned to it.

Remove these X.25 routes by using the `dlt-x25-rte` command. For this example, enter this command.

```
dlt-x25-rte:xaddr=33301:saddr=44401
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
```

```
DLT-X25-RTE: MASP A - X.25 Route table 45% full
DLT-X25-RTE: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE  LOC  PORT  LC  RT  LC2NM
11101         44401         pvc   1205 a    01  xpc no
11102         55501         pvc   1206 a    02  pc  no
22201         44401         pvc   1205 a    02  pc  no
22202         55501         pvc   1206 a    01  xpc yes
33302         55501         svca  1207 a    --  pc  no
X.25 ROUTE TABLE IS 30 % FULL
```

5. Remove the X.25 destination from the database using the **dlt-x25-dstn** command.

For this example, enter this command.

```
dlt-x25-dstn:xaddr=33301
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:38:53 GMT EAGLE5 36.0.0
X.25 DSTN TABLE 33 % FULL
DLT-X25-DSTN: MASP A - COMPLTD
```

6. Verify the changes using the **rtrv-x25-dstn** command.

This is an example of the possible output.


```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 DPC      SSN
11101         001-001-001 005
11102         001-001-001 005
22201         002-002-002 005
22202         002-002-002 010
220525586456772 240-012-004 002
234234231     240-012-005 113
23423422834  244-010-006 235
2342342325   244-010-006 236
23423423     244-010-007 112
33302         003-003-003 007
3450912      244-010-005 114
423423045656767 244-010-008 112
44401         004-004-004 005
55501         005-005-005 005
9342         244-010-006 234
X.25 DSTN TABLE IS 30 % FULL
```

7. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-4. Removing an X.25 Gateway Destination



## Changing an X.25 Gateway Destination

This procedure is used to change the attributes of an X.25 destination in the database using the **chg-x25-dstn** command.

The **chg-x25-dstn** command uses these parameters.

**:xaddr** – The X.25 network address of the X.25 destination entity or the SS7 node.

**:dpc** – The real SS7 point code assigned to a real SS7 node or the dummy point code for an X.25 destination entity. The value for this parameter is an ANSI point code.

**:ssn** – The subsystem number of the destination that is assigned to the X.25 address.

The examples in this procedure are used to change the DPC and SSN of the X.25 destination **33301** in the database to the DPC 011-011-011 and the SSN 230.

The X.25 gateway destination to be changed must be in the database and cannot have any X.25 routes assigned to it. This can be verified in steps 1 and 2.

If the destination point code (DPC) is changed, the new DPC must be in the database. This can be verified in step 5 with the **rtrv-dstn** command. If the new DPC is not in the database, go to the "Adding a Destination Point Code" procedure in the *Database Administration Manual – SS7*.

**NOTE: The point code assigned to the X.25 address in the X.25 destination cannot be an ITU international or ITU national point code. The ent-dstn command does not allow an ITU international or ITU national point code to be assigned to the X.25 domain.**

The destination point code specified with the **chg-x25-dstn** command must be a full point code. Cluster point codes and network routing point codes cannot be specified for X.25 destinations. For more information on cluster point codes, go to the "Cluster Routing and Management Diversity" section in the *Database Administration Manual – SS7*. For more information on network routing point codes, go to the "Network Routing" section in the *Database Administration Manual – SS7*.

### Canceling the RTRV-DSTN Command

Because the **rtrv-dstn** command used in this procedure can output information for a long period of time, the **rtrv-dstn** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-dstn** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-dstn** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-dstn** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-dstn** command was entered, from another terminal other than the terminal where the **rtrv-dstn** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

### Procedure

1. Display the X.25 destinations in the database by entering the **rtrv-x25-dstn** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 DPC      SSN
11101         001-001-001 005
11102         001-001-001 005
22201         002-002-002 005
22202         002-002-002 010
220525586456772 240-012-004 002
234234231    240-012-005 113
23423422834  244-010-006 235
2342342325   244-010-006 236
234234223    244-010-007 112
33301         003-003-003 006
33302         003-003-003 007
3450912      244-010-005 114
423423045656767 244-010-008 112
44401         004-004-004 005
55501         005-005-005 005
9342         244-010-006 234
X.25 DSTN TABLE IS 30 % FULL
```

2. Verify that there are no X.25 routes assigned to the X.25 destination to be changed by entering the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE LOC  PORT  LC  RT   LC2NM
11101         44401         pvc 1205  a    01  xpc  no
11102         55501         pvc 1206  a    02  pc   no
22201         44401         pvc 1205  a    02  pc   no
22202         55501         pvc 1206  a    01  xpc  yes
33301         44401         svca 1207  a    --  pc   no
33302         55501         svca 1207  a    --  pc   no
X.25 ROUTE TABLE IS 30 % FULL
```

3. If the X.25 destination to be removed, shown in the **X25 ADDR** column in the output of step 1, is shown in either the **X25 ADDR** or **SS7 ADDR** columns in the output of step 2, then the X.25 destination has an X.25 route assigned to it.

Remove these X.25 routes by using the **dlt-x25-rte** command. For this example, enter this command.

**dlt-x25-rte:xaddr=33301:saddr=44401**

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
DLT-X25-RTE: MASP A - X.25 Route table 45% full
DLT-X25-RTE: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE LOC  PORT  LC  RT   LC2NM
11101         44401         pvc 1205  a    01  xpc  no
11102         55501         pvc 1206  a    02  pc   no
22201         44401         pvc 1205  a    02  pc   no
22202         55501         pvc 1206  a    01  xpc  yes
33302         55501         svca 1207  a    --  pc   no
X.25 ROUTE TABLE IS 30 % FULL
```

5. If the DPC is being changed, display the DPCs in the database by entering the **rtrv-dstn** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 16:02:05 GMT EAGLE5 36.0.0
DPCA  CLLI      BEI ELEI  ALIASI  ALIASN  DOMAIN
020-002-*  rlghncbb000 yes yes  -----  -----  SS7
004-004-004 -----  yes ---  -----  -----  SS7
005-005-005 -----  yes ---  -----  -----  SS7
240-012-004 rlghncbb001 yes ---  1-111-1  11111  SS7
240-012-005 rlghncbb002 yes ---  1-112-2  11112  SS7
240-012-006 rlghncbb003 yes ---  1-112-3  11113  SS7
240-012-008 -----  yes ---  1-113-5  11114  SS7
001-001-001 -----  yes ---  -----  -----  X25
002-002-002 -----  yes ---  -----  -----  X25
003-003-003 -----  yes ---  -----  -----  X25
011-011-011 -----  yes ---  -----  -----  X25

DPCI  CLLI      BEI ELEI  ALIASA  ALIASN  DOMAIN
2-131-1  rlghncbb023 no ---  222-210-000 12001  SS7
2-131-2  -----  no ---  222-211-001 12002  SS7
2-131-3  -----  no ---  222-211-002 12003  SS7

DPCN  CLLI      BEI ELEI  ALIASA  ALIASI  DOMAIN
11211  rlghncbb013 no ---  222-200-200 2-121-1  SS7
11212  rlghncbb013 no ---  222-200-201 2-121-2  SS7

DESTINATION ENTRIES ALLOCATED: 2000
```

```

FULL DPC(s):                15
EXCEPTION DPC(s):          0
NETWORK DPC(s):            0
CLUSTER DPC(s):            1
TOTAL DPC(s):              16
CAPACITY (% FULL):         1%
ALIASES ALLOCATED:         8000
  ALIASES USED:             18
  CAPACITY (% FULL):        1%
X-LIST ENTRIES ALLOCATED:  500
RTRV-DSTN: MASP A - COMPLTD

```

If the required DPC is not in the database, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the DPC to the database.

6. Change the attributes of the X.25 destination using the **chg-x25-dstn** command.

For this example, enter this command.

```
chg-x25-dstn:xaddr=33301:dpc=011-011-011:ssn=230
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 08:38:53 GMT EAGLE5 36.0.0
X.25 DSTN TABLE 33 % FULL
CHG-X25-DSTN: MASP A - COMPLTD

```

7. Verify the changes using the **rtrv-x25-dstn** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 DPC      SSN
11101         001-001-001 005
11102         001-001-001 005
22201         002-002-002 005
22202         002-002-002 010
220525586456772 240-012-004 002
234234231     240-012-005 113
23423422834   244-010-006 235
2342342325    244-010-006 236
23423423      244-010-007 112
33301         011-011-011 230
33302         003-003-003 007
3450912       244-010-005 114
423423045656767 244-010-008 112
44401         004-004-004 005
55501         005-005-005 005
9342          244-010-006 234
X.25 DSTN TABLE IS 30 % FULL

```

8. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Flowchart 2-5. Changing an X.25 Gateway Destination



## Adding an X.25 Linkset

This procedure is used to add X.25 linksets to the EAGLE 5 ISS using the **ent-1s** command. To add SS7 linksets, go to the "Adding an SS7 Linkset" procedure in the *Database Administration Manual – SS7*.

The **ent-1s** command uses these parameters.

**:lsn** – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter. However, the SEAS interface supports only eight characters. If this linkset is displayed on the SEAS interface and the linkset name contains more than eight characters, only the first eight characters in the linkset name are shown. If this linkset name contains more than eight characters, and is specified with the linkset commands on the SEAS interface, only the first eight characters can be specified.

**:apc/apca** – Adjacent point code – the point code identifying the node that is next to the EAGLE 5 ISS.

**:spc/spca** – The secondary point code assigned to the linkset. Secondary point codes are used for multiple linksets that have the same APC. Secondary point codes can be used only if the Multiple Linksets to Single Adjacent PC feature is enabled and turned on (shown in the **rtrv-ctrl-feat** output).

**NOTE:** See Chapter 2, "Configuring Destination Tables," in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS.

**:lst** – The linkset type of the specified linkset - A, B, C, D, or E.

**:clli** – The Common Language Location Identifier assigned to this point code. The value of the **clli** parameter is only displayed in the **rtrv-ls** command output when a specific linkset is being displayed with the **rtrv-ls:lsn=<linkset name>** command.

**:sltset** – The signaling link test message record to be associated with the linkset.

**:l3tset** – The level 3 timer set table. This parameter identifies which level three timer set is to be assigned to this linkset.

**:scrn** – The name of the screenset to be assigned to this linkset if gateway screening is to be used.

**:gwsa** – Gateway screening action determines whether gateway screening (GWS) is on or off for the specified link set.

**:gwsmsg** – Gateway screening messaging is used to turn on or off the display of messages generated for each screened message. When an MSU is rejected by gateway screening, a message is output to alert personnel of the event.

**:gwsd** – Gateway screening MSU discard is used to turn on or off the discarding of MSUs that bypass the gateway screening function due to load-shedding. Also use this parameter with the redirect function; MSUs that cannot be screened are discarded if you specify **gwsd=on**.

**:bei** – The broadcast exception indicator. This parameter indicates whether TFP (transfer prohibited) messages are allowed to be broadcast on the linkset. The **yes** parameter means TFPs are not broadcast. The **no** parameter means TFPs are broadcast. The **bei=yes** parameter must be specified, or the **bei** parameter must be omitted.

**:gttmode** – The GTT mode/hierarchy identifying the types of global title translation that will be performed on the messages arriving on the specified linkset. The values for this parameter are:

- **sysdf1t** – the value of the **df1tgttmode** parameter shown in the **rtrv-sccopts** command output.
- **cd** - CdPA GTT only
- **cg** - CgPA GTT only
- **acdcd** - Advanced CdPA GTT, CdPA GTT
- **acdcgcd** - Advanced CdPA GTT, CgPA GTT, CdPA GTT
- **acdcdcg** - Advanced CdPA GTT, CdPA GTT, CgPA GTT
- **cgacdcd** - CgPA GTT, Advanced CdPA GTT, CdPA GTT
- **cgcd** - CgPA GTT, CdPA GTT

- **cdcg** - CdPA GTT, CgPA GTT

The default value for the **gttmode** parameter is **sysdf1t**.

For more information on using the **gttmode** parameter, see the Origin Based SCCP Routing Feature section in the *Database Administration Manual - Global Title Translation*.

**:cggtmod** - The calling party GT modification indicator. This parameter specifies whether or not calling party global title modification is required. The values for this parameter are **yes** (calling party global title modification is required) or **no** (calling party global title modification is not required). The default value for the **cggtmod** parameter is **no**. This parameter can be specified only if the AMGTT or AMGTT CgPA Upgrade feature is enabled. Enter the **rtrv-ctrl-feat** command to verify that either the AMGTT or AMGTT CgPA Upgrade feature is enabled. If the AMGTT or AMGTT CgPA Upgrade feature is not enabled, perform the "Activating the Advanced GT Modification Feature" procedure in the *Database Administration Manual - Global Title Translation* procedure to enable the required feature. For more information about the Advanced GT Modification feature, refer to the "Advanced GT Modification Feature" section in the *Database Administration Manual - Global Title Translation*.

The examples in this procedure are based on the example network shown in [Figure 2-4](#) and [Table 2-5](#) and are used to add X.25 linksets **1s03** and **1s04** to the database.

**Table 2-5. X.25 Linkset Configuration Table**

Linksets	Linkset APC	# LINKS	LST	GWSA	GWSD	SCRN
1s03	007-007-007	2	A	ON	OFF	SCR0
1s04	003-003-003	1	A	ON	ON	SCR2

The EAGLE 5 ISS can contain 1024 linksets, with a maximum of 255 of these linksets being gateway linksets. A gateway linkset is a linkset that contains routes to a different network.

The linkset to be added cannot be in the database. This can be verified in step 1 of this procedure.

The adjacent point code (APC) must be defined in the database. This can be verified in step 2 of this procedure. The domain of the point code is shown in the **DOMAIN** field in the output of the **rtrv-dstn** command (step 2). The adjacent point code must be a full point code and cannot be a cluster point code.

If the APC is not in the destination point code table, go to the "Adding a Destination Point Code" procedure in the *Database Administration Manual – SS7*. and add the point code to the destination point code table.

**NOTE: The adjacent point code for the X.25 linkset cannot be an ITU international or ITU national point code. An ITU international or ITU national point code cannot be assigned to the X.25 domain.**

An X.25 APC cannot be referenced by an X.25 route that has the logical channel to network management function turned on (**lc2nm=yes**). Enter the **rtrv-x25-dstn** command to show the association of the point codes to X.25 addresses. Enter the **rtrv-x25-rte** command to show which X.25 routes have the logical channel to network management function turned on. This is shown by the entry **no** in the **LC2NM** field in the output of the **rtrv-x25-rte** command. The APC cannot be associated with an X.25 address that is assigned to an X.25 route that has the logical channel to network management function turned on (**lc2nm=yes**).

The **gwsa**, **gwsn**, and **gwsd** parameters can only be specified if the **scrn** parameter is defined. Enter the **rtrv-ls** command to verify that the **scrn** parameter is defined for the specified linkset. If the **scrn** parameter is defined, a gateway screening screen set name is shown in the **SCRN** field of the output. This gateway screening screen set name must also be defined as a gateway screening screen set entity. This can be verified with the **rtrv-scrset** command.

The **gwsd** parameter allows the discarding of messages that should have gone through the gateway screening process, but did not. The **gwsd** parameter is only intended to be used with the Database Transport Access (DTA) feature. If you are not using the DTA feature, the **gwsd** parameter should not be specified or should be set to no (**gwsd=no**).



**CAUTION: When Gateway Screening is in the screen test mode, as defined by the linkset parameters **gwsa=off** and **gwsn=on**, the gateway screening action in the gateway screening stop action set specified by the **actname** parameter of the gateway screening screen set at the end of the gateway screening process will be performed.**

If the **clli** parameter is specified with the **ent-ls** command, the value of the **clli** parameter must match the CLLI value of the adjacent point code of the linkset. The CLLI value of the adjacent point code is shown in the **CLLI** field of the **rtrv-dstn** command.

To provision more than one linkset with the same APC, the Multiple Linksets to Single Adjacent PC feature must be enabled and turned on. The database can contain a maximum of six linksets that have the same APC. A secondary point code (shown in the **rtrv-spc** output) must be specified with the linkset. The network type and format of the secondary point code must be the same as the APC of the linkset. Secondary point codes cannot be assigned to the APC of the linkset when the point code is provisioned in the database with the **ent-dstn** or **chg-dstn** commands.

### Other Optional Parameters

The **ent-ls** command contains other optional parameters that are not used to configure an X.25 linkset. These parameters are discussed in more detail in the *Commands Manual* or in these sections.

- The [Configuring a Linkset for the GSM MAP Screening Feature](#) procedure
- The "Adding an SS7 Linkset" procedure in the *Database Administration Manual - SS7*
- These procedures in the *Database Administration Manual - IP7 Secure Gateway*
  - Configuring an IPGWx Linkset
  - Adding a Mate IPGWx Linkset to another IPGWx Linkset
  - Removing a Mate IPGWx Linkset from another IPGWx Linkset
  - Adding an IPSG M3UA Linkset
  - Adding an IPSG M2PA Linkset

### Canceling the REPT-STAT-LS, RTRV-LS, and RTRV-DSTN Commands

Because the **rept-stat-ls**, **rtrv-ls**, and **rtrv-dstn** commands used in this procedure can output information for a long period of time, the **rept-stat-ls**, **rtrv-ls**, and **rtrv-dstn** commands can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-ls**, **rtrv-ls**, and **rtrv-dstn** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-ls**, **rtrv-ls**, or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-ls**, **rtrv-ls**, or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-ls**, **rtrv-ls**, or **rtrv-dstn** commands were entered, from another terminal other than the terminal where the **rept-stat-ls**, **rtrv-ls**, or **rtrv-dstn** commands were entered. To enter the **canc-cmd:trm=<xx>**

command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current linkset configuration using the **rtrv-ls** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 37.5.0

      L3T SLT
LSN      APCA  (SS7)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsa1     240-020-000 scr1  1  1  yes a  1  off off off no  off
lsa2     240-030-000 scr2  1  2  no  c  3  on  on  on  yes  off
lsa3     240-040-000 scr3  1  3  yes c  5  off off off yes  off
ls01     006-006-006 scr1  1  1  yes a  1  on  off off no  off
ls02     008-008-008 scr1  1  1  yes a  1  on  off off yes  off

      L3T SLT
LSN      APCA  (X25)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
ls6      244-010-004 scr4  1  4  no  a  6  off off off ---  off
ls7      244-012-005 scr5  1  5  no  c  3  on  on  on  ---  off
ls8      244-012-006 scr6  1  6  no  c  8  off off off ---  off

      L3T SLT
LSN      APCI  (SS7)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsi1     1-111-1      scr1  1  1  yes a  1  off off off ---  ---
lsi2     1-111-2      scr2  1  2  no  c  3  on  on  on  ---  ---
lsi3     1-111-3      scr3  1  3  yes c  5  off off off ---  ---

      L3T SLT
LSN      APCN  (SS7)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsn1     11111      scr1  1  1  yes a  1  off off off ---  off
lsn2     11112      scr2  1  2  no  c  3  on  on  on  ---  off
lsn3     11113      scr3  1  3  yes c  5  off off off ---  off

Link set table is ( 14 of 1024) 1% full
```

If the APC of the linkset is being assigned to more than one linkset, and multiple linksets with the same APC are shown in the **rtrv-ls** output in this step, continue the procedure with [Step 3](#).

If the APC of the linkset is being assigned to more than one linkset, and multiple linksets with the same APC are not shown in the **rtrv-ls** output in this step, continue the procedure with [Step 2](#).

2. Verify whether or not the Multiple Linksets to Single Adjacent PC feature is enabled and turned on by entering this command.

```
rtrv-ctrl-feat:partnum=893017901
```

This is an example of the possible output.

```
rlghncxa03w 07-08-21 15:48:20 EST 37.5.0
The following features have been permanently enabled:

Feature Name          Partnum  Status Quantity
Multiple Linkset to APC 893019701 on      ----
```

The following features have been temporarily enabled:

```
Feature Name          Partnum  Status Quantity  Trial Period Left
Zero entries found.
```

The following features have expired temporary keys:

```
Feature Name          Partnum
Zero entries found.
```

If the Multiple Linksets to Single Adjacent PC feature is not enabled or turned on, perform the "Activating the Multiple Linksets to Single Adjacent PC (MLS) Feature" procedure in this chapter to enable and turn on this feature. After this feature has been enabled and turned on, continue the procedure with [Step 3](#).

If the Multiple Linksets to Single Adjacent PC feature is enabled and turned on, continue the procedure with [Step 3](#).

3. Display the linksets that contain the APC for the new linkset by entering the **rtrv-ls** command with the APC of the linkset. For this example, enter this command.

```
rtrv-ls:apca=001-001-002
```

This is an example of the possible output.

```
rlghncxa03w 07-08-22 08:09:26 EST 37.5.0
```

```
APCA = 001-001-002
```

```

                L3T SLT                GWS GWS GWS
LSN          SPCA          SCRN SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
elm1s2      020-020-021  none 1  1  no  A  7  off off off no  off
```

```
Link set table is (10 of 1024) 1% full.
```

The maximum number of linksets that can use the same APC is six. If six linksets are shown in this step, the specified APC cannot be used in this procedure. Select another APC from the **rtrv-ls** output in [Step 1](#) and repeat this step.

If one to five linksets are shown in this step, continue the procedure with [Step 4](#).

4. Display the secondary point codes by entering the **rtrv-spc** command. This is an example of the possible output.

```
rlghncxa03w 07-08-22 09:39:30 EST 37.5.0
SPC (Secondary Point Codes)
```

```
SPCA
020-020-020
020-020-021
021-021-021
022-022-022
026-026-026
026-026-027
026-026-028
026-026-029
200-010-000
```

```
SPC-I
```

```
none
```

```
SPC-N
00002
```

```
SPC-N24
```

```
none
```

```
Secondary Point Code table is (10 of 40) 25% full.
```

If the desired secondary point code is shown in this step, continue the procedure with [Step 7](#).

If the desired secondary point code is not shown in this step, perform the "Adding a Secondary Point Code" procedure in the *Database Administration Manual - SS7* to add the desired secondary point code. The network

type of the new secondary point code must be the same as the APC of the linkset. After the secondary point code has been added, continue the procedure with [Step 7](#) .

5. Display the point codes in the destination point code table by using the **rtrv-dstn** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 16:02:05 GMT EAGLE5 37.5.0
DPCA          CLLI          BEI  ELEI  ALIASI  ALIASN  DOMAIN
004-004-004  -----  yes  ---  -----  -----  SS7
005-005-005  -----  yes  ---  -----  -----  SS7
006-006-006  -----  no   ---  -----  -----  SS7
008-008-008  -----  no   ---  -----  -----  SS7
240-012-004  rlghncbb001 yes  ---  1-111-1  11111  SS7
240-012-005  rlghncbb002 yes  ---  1-112-2  11112  SS7
240-012-006  rlghncbb003 yes  ---  1-112-3  11113  SS7
240-012-008  -----  yes  ---  1-113-5  11114  SS7
001-001-001  -----  yes  ---  -----  -----  X25
002-002-002  -----  yes  ---  -----  -----  X25
003-003-003  -----  yes  ---  -----  -----  X25
007-007-007  -----  yes  ---  -----  -----  X25
244-010-004  ls06clli   no   ---  -----  -----  X25
244-012-005  ls07clli   no   ---  -----  -----  X25
244-012-006  ls08clli   no   ---  -----  -----  X25
244-012-007  -----  no   ---  -----  -----  X25
244-012-008  -----  no   ---  -----  -----  X25

DPCI          CLLI          BEI  ELEI  ALIASA  ALIASN  DOMAIN
2-131-1      rlghncbb023 no   ---  222-210-000 12001  SS7
2-131-2      -----  no   ---  222-211-001 12002  SS7
2-131-3      -----  no   ---  222-211-002 12003  SS7

DPCN          CLLI          BEI  ELEI  ALIASA  ALIASI  DOMAIN
11211        rlghncbb013 no   ---  222-200-200 2-121-1  SS7
11212        rlghncbb013 no   ---  222-200-201 2-121-2  SS7
```

Destination table is (22 of 2000) 1% full

If the required DPC is not in the database, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the DPC to the database. After the adjacent point code has been added, continue the procedure with [Step 7](#) .

6. The adjacent point code of the linkset cannot be the DPC of any exception route. Verify that the adjacent point code of the new linkset is not the DPC of any exception route by entering the **rtrv-rtx** command with the **dpc/dpca** parameter. The **dpc/dpca** parameter value is the adjacent point code value that will be specified for the linkset. For this example, enter this command.

```
rtrv-rtx:dpca=010-020-005
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
DPCA          RTX-CRITERIA          LSN          RC          APC
010-020-005  OPCA
007-008-009          1s01          20          006-006-006
008-008-100          1s02          40          008-008-008

DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s): 13
EXCEPTION DPC(s): 5
NETWORK DPC(s): 0
CLUSTER DPC(s): 1
TOTAL DPC(s): 19
CAPACITY (% FULL): 1%
ALIASES ALLOCATED: 12000
ALIASES USED: 0
```

```

CAPACITY (% FULL):          0%
X-LIST ENTRIES ALLOCATED:   500

```

If the adjacent point code of the linkset is not the DPC of a route exception table entry, no entries are displayed in the **rtrv-rtx** output, but a summary of the point code quantities is displayed, as shown in the following output example.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```

DESTINATION ENTRIES ALLOCATED:  2000
FULL DPC(s):                    15
EXCEPTION DPC(s):               5
NETWORK DPC(s):                 0
CLUSTER DPC(s):                 1
TOTAL DPC(s):                   21
CAPACITY (% FULL):              1%
ALIASES ALLOCATED:              12000
ALIASES USED:                   0
CAPACITY (% FULL):              0%
X-LIST ENTRIES ALLOCATED:       500

```

If the point code specified in this step is shown in the **DPCA** column in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- a. Choose another adjacent point code value and repeat [Step 5](#) and [Step 6](#).
  - b. Remove all the entries displayed in this step by performing the “Removing a Route Exception Entry” procedure in the *Database Administration Manual - SS7*.
7. Verify that the gateway screening screen set that is to be assigned to the linkset is in the database by entering the **rtrv-scrset** command. This is an example of the possible output.

**NOTE: If the screen set assigned to the linkset is not being changed, or if the screen set that you wish to assign to the linkset is assigned to other linksets (shown in the **SCRN** field of the **rtrv-ls** command output in [Step 1](#)), continue the procedure with [Step 8](#).**

```

rlghncxa03w 06-10-28 16:37:05 GMT EAGLE5 37.5.0
ENTIRE GWS DATABASE IS 1% FULL
CDPA + AFTPC TABLES ARE 1% FULL
THERE ARE 243 SCREEN SETS AVAILABLE

```

```

THE FOLLOWING ARE OVER 80% FULL:
SCRN  NSFI    NSR/ACT  FULL  RULES  TABLES  DESTFLD
-----
SCRN  NSFI    NSR/ACT  FULL  RULES  TABLES  DESTFLD
fld1  OPC      gws4     1%    5      4        NO
gws1  OPC      gws4     1%    9      7        NO
gws2  BLKOPC   gws5     1%    5      4        NO
ls01  SIO      ls02     1%    3      3        YES
scr1  OPC      opc1     1%    37     10       YES
scr2  OPC      opc2     2%    75     22       YES
scr3  OPC      opc3     2%    75     22       YES
scr4  OPC      opc1     51%   2075   22       NO
scr5  OPC      opc1     51%   2075   22       YES
scr6  OPC      opc1     51%   2075   22       NO
ss28  OPC      opc1     51%   2075   22       YES
wrld1 SIO      iec      1%    6      5        YES

```

If you wish to examine the contents of a particular screen set, enter the **rtrv-scrset:scrn=<screen set name>** command specifying a screen set name shown in the **SCRN** field of either the **rtrv-scrset** command executed in this step or the **rtrv-ls** command executed in step 1.

For this example, enter the **rtrv-scrset:scrn=scr1** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-14 16:39:04 GMT EAGLE5 37.5.0
```

SCRN	NSFI	NSR/ACT	RULES	DESTFLD
scr1	OPC	opc1	3	Y
	BLKDPC	bkd2	2	
	CGPA	cgp1	3	
	TT	tt1	3	
	TT	tt2	3	
	TT	tt3	4	
	CDPA	cdp1	3	
	CDPA	cdp2	3	
	CDPA	cdp3	4	
	AFTPC	end1	9	

The output of this command shows the screens that make up the screen set. These screens can be examined by entering the gateway screening retrieve command corresponding to the value in the **NSFI** field and specifying the screening reference name shown in the **NSR/ACT** field. For this example, you enter these commands to examine the screens in the screen set.

- **rtrv-scr-opc:sr=opc1**
- **rtrv-scr-blkdpc:sr=bkd2**
- **rtrv-scr-cgpa:sr=cgp1**
- **rtrv-scr-tt:sr=tt1**
- **rtrv-scr-tt:sr=tt2**
- **rtrv-scr-tt:sr=tt3**
- **rtrv-scr-cdpa:sr=cdp1**
- **rtrv-scr-cdpa:sr=cdp2**
- **rtrv-scr-cdpa:sr=cdp3**
- **rtrv-scr-aftpc:sr=end1**

If the screen set that you wish to assign to the linkset is not in the database, go to the "Adding a Screen Set" procedure in the *Database Administration Manual - Gateway Screening* and add the screen set to the database.

8. Display the X.25 destinations in the database by entering the **rtrv-x25-dstn** command with the point code to be assigned to the linkset, shown in the **rtrv-dstn** output in [Step 5](#).

**NOTE:** If a new X.25 point code was added in [Step 5](#), continue the procedure with [Step 10](#).

```
rtrv-x25-dstn:dpc=244-012-008
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 37.5.0
X25 ADDR          SS7 DPC          SSN
234234231         244-012-008     113
234234231         244-012-008     113
X.25 DSTN TABLE IS 30 % FULL
```

If the new APC of the linkset is not shown in the **rtrv-x25-dstn** output, continue the procedure with [Step 10](#). If the new APC of the linkset is shown in the **rtrv-x25-dstn** output, continue the procedure with [Step 10](#).

9. Display the X.25 routes by entering the **rtrv-x25-rte** command with the **xaddr** parameter value shown in [Step 8](#). For this example, enter this command.

```
rtrv-x25-rte:xaddr=234234231
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 37.5.0
X25 ADDR          SS7 ADDR          TYPE LOC  PORT  LC  RT   LC2NM
234234231         44401                pvc 1205  a    01  xpc  no
X.25 ROUTE TABLE IS 30 % FULL

```

If the LC2NM value in the X.25 route is no, continue the procedure with [Step 10](#) .

If the LC2NM value in the X.25 route is yes, the new linkset APC cannot be used in the X.25 linkset. To use the new linkset APC in the X.25 linkset, the LC2NM value of the X.25 route associated with the new linkset APC must be no. The LC2NM value must be changed to no, or another X.25 point code must be chosen.

To chose another X.25 point code, repeat this procedure from [Step 5](#) .

To change the LC2NM value, perform the [Changing an X.25 Route](#) procedure. Then continue the procedure with [Step 10](#) .

10. The **gttmode** parameter can be specified with the values **acdcd**, **cgacdcd**, **acdcgcd**, **acdcdcg**, **cgcd**, **cdcg**, or **cg** only if the Origin Based SCCP Routing feature is enabled. Enter the **rtrv-ctrl-feat** command with the part number of the Origin Based SCCP Routing feature to verify whether or not the Origin Based SCCP Routing feature is enabled. Enter this command.

**NOTE: If the **gttmode** parameter is not being specified for the linkset, or if the **gttmode** parameter is being specified for the linkset with either the **sysdf1t** or **cd** values, continue the procedure with [Step 11](#) .**

```
rtrv-ctrl-feat:partnum=893014301
```

This is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
The following features have been permanently enabled:

Feature Name          Partnum  Status Quantity
Origin Based SCCP Routing 893014301 on      ----

The following features have been temporarily enabled:

Feature Name          Partnum  Status Quantity  Trial Period Left
Zero entries found.

The following features have expired temporary keys:

Feature Name          Partnum
Zero entries found.

```

If the Origin Based SCCP routing feature is enabled, continue the procedure with [Step 11](#) .

If the Origin Based SCCP routing feature is not enabled, perform the “Activating the Origin Based SCCP Routing Feature” procedure in the *Database Administration Manual - Global Title Translation* to enabled the Origin Based SCCP Routing feature. After the Origin Based SCCP Routing feature is enabled, continue the procedure with [Step 11](#) .

11. The **cggtmod** parameter cannot be specified with the **ent-1s** command unless the AMGTT or AMGTT CgPA Upgrade features are enabled. If the **cggtmod** parameter will be specified with the linkset, enter the **rtrv-ctrl-feat** command to verify the status of the AMGTT or AMGTT CgPA Upgrade features.

**NOTE: If the **cggtmod** parameter will not be specified with the **ent-1s** command, this step does need to be performed. Continue the procedure with [Step 12](#) .**

This is an example of the possible output.

```

rlghncxa03w 07-08-22 10:58:06 EST 37.0.0
The following features have been permanently enabled:

```

Feature Name	Partnum	Status	Quantity
HC-MIM SLK Capacity	893012707	on	64
Origin-Based MTP Routing	893014201	on	----
Multiple Linkset to APC	893019701	on	----
Proxy Point Code	893018702	on	20
AMGTT CdPA Only	893021802	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the AMGTT feature (shown by the entry **AMGTT** with the part number 893021801) or the AMGTT CgPA Upgrade feature (shown by the entry **AMGTT CgPA Upgrade** with the part number 893021803) is enabled, continue the procedure with [Step 12](#) .

If the AMGTT or the AMGTT CgPA Upgrade features are not enabled, or if the AMGTT CdPA Only feature is enabled, perform the "Activating the Advanced GT Modification Feature" procedure in the *Database Administration Manual - Global Title Translation* procedure to enable the required feature. After the AMGTT or the AMGTT CgPA Upgrade feature is enabled, continue the procedure with [Step 12](#) .

12. Using the outputs from [Step 1](#) through [Step 11](#) as a guide, add the new linkset using the **ent-ls** command. The new linkset must meet these conditions.
  - a. The new linkset cannot already be in the database – the linkset configuration is shown in the output of [Step 1](#) .
  - b. The APC of the new linkset must be in the destination point code table, shown in the output of [Step 5](#) . The adjacent point code for the X.25 linkset must be an ANSI point code in the X.25 domain.
  - c. The new linkset cannot use an APC assigned to an X.25 address that is assigned to an X.25 route that has the logical channel to network management function turned on (shown by the entry **yes** in the **LC2NM** field in the output of [Step 9](#) ). The output of [Step 8](#) shows which X.25 addresses are assigned to the point codes that can be used as APCs for linksets. The output of [Step 9](#) shows the X.25 addresses used by the X.25 routes.

For this example, enter these commands.

```
ent-ls:lsn=ls03:apca=007-007-007:lst=a:gwsa=on:scrn=scr1
```

```
ent-
```

```
ls:lsn=ls04:apca=003-003-003:lst=a:gwsa=on:scrn=scr2:gttmode=cgacdcd
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 16:23:21 GMT EAGLE5 37.5.0
Link set table is ( 16 of 1024) 2% full
ENT-LS: MASP A - COMPLTD
```

13. Verify the changes using the **rtrv-ls** command with the linkset name that was specified in [Step 12](#) . For this example, enter these commands.

```
rtrv-ls:lsn=ls03
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 37.5.0
```

```

LSN          APCA  (X25)  SCRNL3T SLT          GWS GWS GWS
ls03         007-007-007  scr1  1  1  yes a  0  on  off  off  ---  off
          CLLI          TFATCABMLQ MTPRSE ASL8
          -----
          IPGWAPC MATELSN      IPTPS LSUSEALM SLKUSEALM GTTMODE
          no          -----

```

Link set table is ( 16 of 1024) 2% full

**rtrv-ls:lsn=ls04**

This is an example of the possible output.

rlghncxa03w 06-10-28 08:40:38 GMT EAGLE5 37.5.0

```

LSN          APCA  (X25)  SCRNL3T SLT          GWS GWS GWS
ls04         003-003-003  scr2  1  1  yes a  0  on  off  off  ---  off
          CLLI          TFATCABMLQ MTPRSE ASL8
          -----
          IPGWAPC MATELSN      IPTPS LSUSEALM SLKUSEALM GTTMODE
          no          -----

```

Link set table is ( 16 of 1024) 2% full


- Backup the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


Flowchart 2-6. Adding an X.25 Linkset




















## Removing a Linkset Containing X.25 Signaling Links

This procedure is used to remove a linkset with X.25 signaling links from the database using the **dlt-ls** command. To remove linksets with SS7 signaling links, go to the "Removing a Linkset Containing SS7 Signaling Links" procedure in the *Database Administration Manual – SS7*.

The **dlt-ls** command has only one parameter, **lsn**, which is the name of the linkset to be removed from the database.

The examples in this procedure are used to remove linkset **ls04** from the database.

The linkset to be removed must exist in the database. This can be verified in step 1.

To remove a linkset, all links associated with the linkset must be removed. This can be verified in step 2.

All X.25 routes associated with the X.25 signaling links in the linkset must be removed. This can be verified in step 3.

The linkset to be removed cannot be referenced by a routeset. This can be verified in step 5.

**Canceling the REPT-STAT-LS and RTRV-LS Commands**

Because the **rept-stat-ls** and **rtrv-ls** commands used in this procedure can output information for a long period of time, the **rept-stat-ls** and **rtrv-ls** commands can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-ls** and **rtrv-ls** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rept-stat-ls** or **rtrv-ls** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-ls** or **rtrv-ls** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-ls** or **rtrv-ls** commands were entered, from another terminal other than the terminal where the **rept-stat-ls** or **rtrv-ls** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current linkset configuration using the **rtrv-ls** command. This is an example of the possible output.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0

      L3T SLT                      GWS GWS GWS
LSN      APCA  (SS7)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsa1     240-020-000  scr1  1  1  yes a  1  off off off no  off
lsa2     240-030-000  scr2  1  2  no  c  3  on  on  on  yes  off
lsa3     240-040-000  scr3  1  3  yes c  5  off off off yes  off
ls01     006-006-006  scr1  1  1  yes a  1  on  off off no  off
ls02     008-008-008  scr1  1  1  yes a  1  on  off off yes  off

      L3T SLT                      GWS GWS GWS
LSN      APCA  (X25)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
ls03     007-007-007  scr1  1  1  yes a  3  on  off off ---  off
ls04     003-003-003  scr2  1  1  yes a  1  on  off off ---  off
ls6      244-010-004  scr4  1  4  no  a  6  off off off ---  off
ls7      244-012-005  scr5  1  5  no  c  3  on  on  on  ---  off
ls8      244-012-006  scr6  1  6  no  c  8  off off off ---  off

      L3T SLT                      GWS GWS GWS
LSN      APCI  (SS7)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsi1     1-111-1      scr1  1  1  yes a  1  off off off ---  ---
lsi2     1-111-2      scr2  1  2  no  c  3  on  on  on  ---  ---
lsi3     1-111-3      scr3  1  3  yes c  5  off off off ---  ---

      L3T SLT                      GWS GWS GWS
LSN      APCN  (SS7)  SCRNL SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsn1     11111        scr1  1  1  yes a  1  off off off ---  off
lsn2     11112        scr2  1  2  no  c  3  on  on  on  ---  off
lsn3     11113        scr3  1  3  yes c  5  off off off ---  off
    
```

```
Link set table is ( 16 of 1024) 2% full
```

2. Select a linkset whose APC is shown in the output of step 1 and is assigned to the X.25 domain. Display the signaling links in that linkset using the **rtrv-ls** command, specifying the linkset name of the linkset you wish to remove from the database. For this example, enter this command.

```
rtrv-ls:lsn=ls04
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0

LSN          APCA   (X25)  SCRN  L3T SLT          GWS GWS GWS
ls04         003-003-003  scr2  1   1  yes a   1   on off off --- off

          CLLI          TFATCABMLQ MTPRSE ASL8
          rlghncwd40z ---          ---    ---

          IPGWAPC MATELSN          IPTPS LSUSEALM SLKUSEALM GTTMODE
          no          ----- ---    ---    ---          CdPA

          LOC LINK SLC TYPE          L2T          L1          PCR PCR
          1207 a   0   LIMV35  1   56000 DTE --- BASIC --- -----
```

```
Link set table is ( 16 of 1024) 2% full
```

3. Display the X.25 routes in the database by entering the **rtrv-x25-rte** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR          TYPE LOC PORT LC RT LC2NM
11101         44401             pvc 1205 a 01 xpc no
11102         55501             pvc 1206 a 02 pc no
22201         44401             pvc 1205 a 02 pc no
22202         55501             pvc 1206 a 01 xpc yes
33301         44401             svca 1207 a -- pc no
33302         55501             svca 1207 a -- pc no
X.25 ROUTE TABLE IS 30 % FULL
```

4. If any X.25 routes shown in the output of step 3 are assigned to the X.25 signaling links shown in the output of step 2, remove those X.25 routes by using the **dlt-x25-rte** command. For this example, enter these commands.

```
dlt-x25-rte:xaddr=33301:saddr=44401
```

```
dlt-x25-rte:xaddr=33302:saddr=55501
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:45:17 GMT EAGLE5 36.0.0
DLT-X25-RTE: MASP A - X.25 Route table is 4
DLT-X25-RTE: MASP A - COMPLTD
```

5. Display the routes in the database by using the **rtrv-rte** command, specifying the name of the linkset you wish to remove. For this example, enter this command.

```
rtrv-rte:lsn=ls04
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
LSN          DPC          RC
ls04         004-004-004  10
```

If the X.25 linkset is shown in the **rtrv-rte** output, perform to the “Removing a Route” procedure in the *Database Administration Manual - SS7* and remove the routes shown in this step from the database.

- Deactivate the X.25 signaling links in the linkset using the **dact-slk** command. For this example, enter this command.

**dact-slk:loc=1207:link=a**

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

- Verify that the signaling link status is out of service maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-ls** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 08:40:38 GMT EAGLE5 36.0.0
LSN      APCA      PST      SST      AST
lsa1     240-020-000 IS-NR    Allowed  -----
lsa2     240-030-000 IS-NR    Allowed  GWS
lsa3     240-040-000 IS-NR    Allowed  -----
ls01     006-006-006 IS-NR    Allowed  GWS
ls02     008-008-008 IS-NR    Allowed  GWS
ls03     007-007-007 IS-NR    Allowed  GWS
ls04     003-003-003 OOS-MT-DSBLD Prohibit GWS

LSN      APCI      PST      SST      AST
lsi1     1-111-1   IS-NR    Allowed  -----
lsi2     1-111-2   IS-NR    Allowed  -----
lsi3     1-111-3   IS-NR    Allowed  -----

LSN      APCN      PST      SST      AST
lsn1     11111    IS-NR    Allowed  -----
lsn2     11112    IS-NR    Allowed  -----
lsn3     11113    IS-NR    Allowed  -----
Command Completed.
```

- If any signaling links in the linkset are the last signaling link on a card, the card must be placed out of service before that signaling link can be removed. Verify this by entering the **rtrv-slk** command and specifying each of the card locations shown in the output of step 2. Do not specify the **link** parameter. For this example, enter this command.

**rtrv-slk:loc=1207**

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:17:04 GMT EAGLE5 36.0.0
LOC LINK LSN      SLC TYPE SET BPS  MODE TSET ECM  N1  N2
1207 A  LS04      0  LIMV35  1  56000 DTE  ---  BASIC ---  -----
```

- If the output of step 9 shows that any of the signaling links in the specified linkset are the last signaling links on the card, place that card out of service by using the **rmv-card** command, specifying the card location to be taken out of service. For this example, enter this command.

**rmv-card:loc=1207**

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:11:28 GMT EAGLE5 36.0.0
Card has been inhibited.
```

- Remove all X.25 signaling links in the linkset using the **dlt-slk** command. For this example, enter this command.

```
dlt-slk:loc=1207:link=a
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:41:17 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD
```

11. Display any entries in the route exception table whose linkset name is the name of the linkset being removed in this procedure. Enter the **rtrv-rtx** command with the **lsn** parameter. For this example, enter this command.

```
rtrv-rtx:lsn=ls04
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

      DPCA          RTX-CRITERIA          LSN          RC          APC
      004-004-004   OPCA
                        008-008-008          ls04          40          003-003-003

DESTINATION ENTRIES ALLOCATED:    2000
  FULL DPC(s):                    15
  EXCEPTION DPC(s):                5
  NETWORK DPC(s):                  0
  CLUSTER DPC(s):                  1
  TOTAL DPC(s):                    21
  CAPACITY (% FULL):               1%
ALIASES ALLOCATED:                12000
  ALIASES USED:                    0
  CAPACITY (% FULL):               0%
X-LIST ENTRIES ALLOCATED:         500
```

If the linkset being removed in this procedure is not assigned to a route exception table entry, no entries are displayed in the **rtrv-rtx** output, but a summary of the point code quantities is displayed.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

DESTINATION ENTRIES ALLOCATED:    2000
  FULL DPC(s):                    15
  EXCEPTION DPC(s):                5
  NETWORK DPC(s):                  0
  CLUSTER DPC(s):                  1
  TOTAL DPC(s):                    21
  CAPACITY (% FULL):               1%
ALIASES ALLOCATED:                12000
  ALIASES USED:                    0
  CAPACITY (% FULL):               0%
X-LIST ENTRIES ALLOCATED:         500
```

If the name of the linkset being removed in this procedure shown in the **LSN** column in this step, perform one of these procedures:

- a. Change the name of the linkset in the entries displayed in this step by performing the “Changing a Route Exception Entry” procedure in the *Database Administration Manual - SS7*.
  - b. Remove all the entries displayed in this step by performing the “Removing a Route Exception Entry” procedure in the *Database Administration Manual - SS7*.
12. Remove the linkset using the **dlt-ls** command with the name of the linkset being removed. For this example, enter this command.

```
dlt-ls:lsn=ls04
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 16:03:12 GMT EAGLE5 36.0.0
Link set table is ( 15 of 1024) 1% full
DLT-LS: PSM A - COMPLTD
```

13. Verify the changes using the **rtrv-ls** command and specifying the name of the linkset specified in step 12. For this example, enter this command.

```
rtrv-ls:lsn=ls04
```


The following message should appear indicating that the linkset is not in the database.


```
E2346 Cmd Rej: Linkset not defined
```

14. Backup the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-7. Removing a Linkset Containing X.25 Signaling Links





## Changing an X.25 Linkset

This procedure is used to change the definition of linksets that contain X.25 signaling links using the **chg-ls** command. To change SS7 linksets, go to the "Changing an SS7 Linkset" procedure in the *Database Administration Manual – SS7*. The **chg-ls** command uses these parameters.

**:lsn** – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter. However, the SEAS interface supports only eight characters. If this linkset is displayed on the SEAS interface and the linkset name contains more than eight characters, only the first eight characters in the linkset name are shown. If this linkset name contains more than eight characters, and is specified with the linkset commands on the SEAS interface, only the first eight characters can be specified.

**:apc/apca** – ANSI adjacent point code – the point code identifying the node that is next to the EAGLE 5 ISS. ITU point codes cannot be used for an X.25 linkset.

**:spc/spca** – The secondary point code assigned to the linkset. Secondary point codes are used for multiple linksets that have the same APC. Secondary point codes can be used only if the Multiple Linksets to Single Adjacent PC feature is enabled and turned on (shown in the **rtrv-ctrl-feat** output).

**NOTE:** See Chapter 2, "Configuring Destination tables," in the *Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS.

**:lst** – The linkset type of the specified linkset - A, B, C, D, or E.

**:clli** – The Common Language Location Identifier assigned to this point code. The value of the **clli** parameter is only displayed in the **rtrv-ls** command output when a specific linkset is being displayed with the **rtrv-ls:lsn=<linkset name>** command.

**:sltset** – The signaling link test message record to be associated with the linkset.

**:l3tset** – The level 3 timer set table. This parameter identifies which level three timer set is to be assigned to this linkset. Currently, only one is supported.

**:scrn** – The name of the screenset to be assigned to this linkset if gateway screening is to be used.

**:gwsa** – Gateway screening action determines whether gateway screening (GWS) is on or off for the specified link set.

**:gwsmsg** – Gateway screening messaging is used to turn on or off the display of messages generated for each screened message. When an MSU is rejected by gateway screening, a message is output to alert personnel of the event.

**:gwsd** – Gateway screening MSU discard is used to turn on or off the discarding of MSUs that bypass the gateway screening function due to load-shedding. Also use this parameter with the redirect function; MSUs that cannot be screened are discarded if you specify **gwsd=on**.

**:bei** – The broadcast exception indicator. This parameter indicates whether TFP (transfer prohibited) messages are allowed to be broadcast on the linkset. The **yes** parameter means TFPs are not broadcast. The **no** parameter means TFPs are broadcast. For an X.25 linkset, the **bei=yes** parameter must be specified, or the **bei** parameter must be omitted.

**:nlsn** – The new name of the linkset

**:gttmode** – The GTT mode/hierarchy identifying the types of global title translation that will be performed on the messages arriving on the specified linkset. The values for this parameter are:

- **sysdf1t** – the value of the **df1tgttmode** parameter shown in the **rtrv-sccopts** command output.
- **cd** - CdPA GTT only
- **cg** - CgPA GTT only
- **acdcd** - Advanced CdPA GTT, CdPA GTT

- **acdcgcd** - Advanced CdPA GTT, CgPA GTT, CdPA GTT
- **acdcdcg** - Advanced CdPA GTT, CdPA GTT, CgPA GTT
- **cgacdcd** - CgPA GTT, Advanced CdPA GTT, CdPA GTT
- **cgcd** - CgPA GTT, CdPA GTT
- **cdcg** - CdPA GTT, CgPA GTT

For more information on using the **gttmode** parameter, see the Origin Based SCCP Routing Feature section in the *Database Administration Manual - Global Title Translation* .

**:cggtmod** - The calling party GT modification indicator. This parameter specifies whether or not calling party global title modification is required. The values for this parameter are **yes** (calling party global title modification is required) or **no** (calling party global title modification is not required). The default value for the **cggtmod** parameter is **no**. This parameter can be specified only if the AMGTT or AMGTT CgPA Upgrade feature is enabled. Enter the **rtrv-ctrl-feat** command to verify that either the AMGTT or AMGTT CgPA Upgrade feature is enabled. If the AMGTT or AMGTT CgPA Upgrade feature is not enabled, perform the "Activating the Advanced GT Modification Feature" procedure in the *Database Administration Manual - Global Title Translation* procedure to enable the required feature. For more information about the Advanced GT Modification feature, refer to the "Advanced GT Modification Feature" section in the *Database Administration Manual - Global Title Translation*.

The linkset to be changed must exist in the database.

If the adjacent point code (APC) is changed, the new APC must be in the destination point code table and must be defined as a true point code in the destination point code table and cannot be an alias point code. The domain of the new APC must be the same as the APC being changed. The new APC of the linkset cannot match the self ID of the EAGLE 5 ISS. The new APC must be a full point code and cannot be a cluster point code.

The signaling link configuration of the linkset can be verified by entering the **rtrv-ls:lsn=<linkset name>** command specifying the linkset name as shown in [Step 15](#) .

Use the **rtrv-dstn** command to verify that the new APC is in the destination point code table and to verify the domain of the new APC. If the new APC is not shown in the **rtrv-dstn** command output, go to the "Adding a Destination Point Code" in the *Database Administration Manual – SS7* and add the new APC to the destination point code table.

To change the APC of a linkset, all signaling links in the linkset must be in the OOS-MT-DSBLD state.

The domain of the linkset's APC cannot be changed using the **chg-ls** command. For example, if the current domain of the APC is X.25, the new APC must also be in the X.25 domain. To change the domain of the linkset's APC, the linkset must be removed from the database using the **dlt-ls** command and re-entered with the new APC in the different domain using the **ent-ls** command. To remove the X.25 linkset, go to the [Removing a Linkset Containing X.25 Signaling Links](#) procedure. To add the X.25 linkset, go to the [Adding an X.25 Linkset](#) procedure. To add an SS7 linkset, go to the "Adding an SS7 Linkset" procedure in the *Database Administration Manual – SS7* .

The **gwsa**, **gwsn**, and **gwsd** parameters can only be specified if the **scrn** parameter is defined. Enter the **rtrv-ls** command to verify that the **scrn** parameter is defined for the specified linkset. If the **scrn** parameter is defined, a gateway screening screen set name is shown in the **SCRN** field of the output. This gateway screening screen set name must also be defined as a gateway screening screen set entity. This can be verified with the **rtrv-scrset** command.

The **gwsd** parameter allows the discarding of messages that should have gone through the gateway screening process, but could not. The **gwsd** parameter is only intended to be used with the database transport access (DTA) feature. If you are not using the DTA feature, the **gwsd** parameter should not be specified or should be set to off (**gwsd=off**).

If the **gwsa=off** parameter is specified, then the **gwsd=off** parameter must be specified.



**CAUTION:** When Gateway Screening is in the screen test mode, as defined by the linkset parameters **gwsa=off** and **gwsd=on**, the gateway screening action in the gateway screening stop action set specified by the **actname** parameter of the gateway screening screen set at the end of the gateway screening process will be performed.

An X.25 APC cannot be referenced by an X.25 route that has the logical channel to network management function turned on (**lc2nm=yes**). Use the **rtrv-x25-dstn** command to verify which point codes are assigned to each X.25 address. Use the **rtrv-x25-rte** to verify which X.25 address is assigned to each X.25 route and to verify which X.25 route has the logical channel to network management function turned on, shown by the entry **yes** in the **LC2NM** field.

The word **SEAS** cannot be used as a value for the **scrn** parameter of the **chg-ls** command. The word **SEAS** is used in the **rtrv-ls** command output, in the **SCRN** field, to show gateway linksets created on the SEAS interface. A gateway linkset combines the functions of a gateway screening screen set and an SS7 linkset specifying the **gwsa=on** and **scrn** parameters. Like an EAGLE 5 ISS gateway screening screen set, a gateway linkset defines the screening references that are to be used to screen the messages on the linkset. It also defines the linkset whose messages are to be screened. A gateway linkset can only be configured from a SEAS terminal and not from an EAGLE 5 ISS terminal.

If the **clli** parameter is specified with the **chg-ls** command, the value of the **clli** parameter must match the CLLI value of the adjacent point code of the linkset. The CLLI value of the adjacent point code is shown in the **CLLI** field of the **rtrv-dstn** command.

To provision more than one linkset with the same APC, the Multiple Linksets to Single Adjacent PC feature must be enabled and turned on. The database can contain a maximum of six linksets that have the same APC. A secondary point code (shown in the **rtrv-spc** output) must be specified with the linkset. The network type and format of the secondary point code must be the same as the APC of the linkset. Secondary point codes cannot be assigned to the APC of the linkset when the point code is provisioned in the database with the **ent-dstn** or **chg-dstn** commands. When these linksets are assigned to routes

The secondary point code that is assigned to a linkset can be removed from the linkset by specifying the value **none** for the **spc/spca** parameter. A secondary point code can be removed from only one of the linksets in a group of linksets that have the same APC.

In this procedure, the examples are used to change the definition of a linkset named **ls7**. The attributes of linkset **ls7** that are changed in this example are the APC, the gateway screening screen set name, and to change the linkset type to A. For any optional parameters not specified with the **chg-ls** command, the values for those parameters are not changed.

### Other Optional Parameters

The **chg-ls** command contains other optional parameters that are not used to configure an X.25 linkset. These parameters are discussed in more detail in the *Commands Manual* or in these sections.

- The [Configuring a Linkset for the GSM MAP Screening Feature](#) procedure
- These procedures in the *Database Administration Manual - SS7*
  - Adding an SS7 Linkset

- Changing an SS7 Linkset
- These procedures in the *Database Administration Manual - IP7 Secure Gateway*
  - Configuring an IPGWx Linkset
  - Adding a Mate IPGWx Linkset to another IPGWx Linkset
  - Removing a Mate IPGWx Linkset from another IPGWx Linkset
  - Changing an IPSG M3UA Linkset
  - Changing an IPSG M2PA Linkset

**Canceling the RTRV-DSTN and RTRV-LS Commands**

Because the **rtrv-dstn** and **rtrv-ls** commands used in this procedure can output information for a long period of time, the **rtrv-dstn** and **rtrv-ls** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-dstn** and **rtrv-ls** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-dstn** or **rtrv-ls** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-dstn** or **rtrv-ls** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-dstn** or **rtrv-ls** commands were entered, from another terminal other than the terminal where the **rtrv-dstn** or **rtrv-ls** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current linkset configuration using the **rtrv-ls** command. This is an example of the possible output.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 37.5.0

```

LSN	APCA	(SS7)	SCRN	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsa1	240-020-000	scr1	1	1	yes	a	1	1	off	off	off	no	off
lsa2	240-030-000	scr2	1	2	no	c	3	3	on	on	on	yes	off
lsa3	240-040-000	scr3	1	3	yes	c	5	5	off	off	off	yes	off
ls1	240-012-004	scr1	1	1	yes	a	4	4	off	off	off	yes	off
ls2	240-012-005	scr2	1	2	yes	c	2	2	on	on	on	yes	off
ls3	240-012-006	scr3	1	3	yes	c	5	5	off	off	off	no	off
ls01	002-002-002	scr1	1	1	no	c	0	0	on	off	off	yes	off
ls02	004-004-004	scr1	1	1	no	b	0	0	on	off	off	no	off
ls03	003-003-003	scr1	1	1	no	d	0	0	on	off	off	no	off
ls04	001-002-003	scr2	1	1	no	a	0	0	on	off	on	yes	off
ls06	002-007-008	scr4	1	1	no	a	0	0	on	off	off	yes	off

LSN	APCA	(X25)	SCRN	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
ls6	244-010-004	scr4	1	4	no	a	6	6	off	off	off	---	off
ls7	244-012-005	scr5	1	5	no	c	3	3	on	on	on	---	off
ls8	244-012-006	scr6	1	6	no	c	8	8	off	off	off	---	off

LSN	APCI	(SS7)	SCRN	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
-----	------	-------	------	-----	-----	-----	-----	------	-----	-----	-----	-------	-----

lsi1	1-111-1	scr1	1	1	yes	a	1	off	off	off	---	---
lsi2	1-111-2	scr2	1	2	no	c	3	on	on	on	---	---
lsi3	1-111-3	scr3	1	3	yes	c	5	off	off	off	---	---
lsi7	3-150-4	scr1	1	1	no	a	0	on	off	off	---	---

LSN	APCN	(SS7)	SCRN	L3T		SLT	BEI	LST	LNKS	GWS			SLSCI	NIS
				SET	SET					ACT	MES	DIS		
lsn1	11111		scr1	1	1	yes	a	1	off	off	off	---	off	
lsn2	11112		scr2	1	2	no	c	3	on	on	on	---	off	
lsn3	11113		scr3	1	3	yes	c	5	off	off	off	---	off	
lsn5	10685		scr3	1	1	no	a	0	on	off	off	---	off	

Link set table is ( 22 of 1024) 2% full

If you wish to change the APC of a linkset to an APC that is assigned to another linkset and multiple linksets with the same APC are shown in the **rtrv-ls** output, continue the procedure with [Step 3](#) . If multiple linksets with the same APC are not shown in the **rtrv-ls** output, continue the procedure with [Step 2](#) .

If you wish to change the secondary point code that is assigned to a linkset and multiple linksets with the same APC are shown in the **rtrv-ls** output, continue the procedure with [Step 3](#) . If multiple linksets with the same APC are not shown in the **rtrv-ls** output, continue the procedure with [Step 2](#) .

If you wish to change the APC of a linkset to an APC that is not assigned to another linkset or do not wish to change the secondary point code that is assigned to a linkset, continue the procedure with [Step 10](#) .

If neither the APC of the linkset nor the secondary point code that is assigned to the linkset is being changed, continue the procedure with [Step 12](#) .

2. Verify whether or not the Multiple Linksets to Single Adjacent PC feature is enabled and turned on by entering this command.

**rtrv-ctrl-feat:partnum=893017901**

This is an example of the possible output.

rlghncxa03w 07-08-21 15:48:20 EST 37.5.0  
The following features have been permanently enabled:

Feature Name	Partnum	Status	Quantity
Multiple Linkset to APC	893019701	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the Multiple Linksets to Single Adjacent PC feature is not enabled or turned on, perform the "Activating the Multiple Linksets to Single Adjacent PC (MLS) Feature" procedure in the *Database Administration Manual - SS7* to enable and turn on this feature. After this feature has been enabled and turned on, and the APC of the linkset is being changed, continue the procedure with [Step 3](#) . If only the secondary point code that is assigned to the linkset is being changed, continue the procedure with [Step 4](#) .

If the Multiple Linksets to Single Adjacent PC feature is enabled and turned on, and the APC of the linkset is being changed, continue the procedure with [Step 3](#) . If only the secondary point code that is assigned to the linkset is being changed, continue the procedure with [Step 4](#) .

3. A maximum of six linksets can be assigned to an APC. Verify the number of linksets that are assigned to the new APC of the linkset that is being changed by entering the **rtrv-ls** command with the new APC of the linkset. For this example, enter this command.

**rtrv-ls:apca=002-002-002**

This is an example of the possible output.

```
r1ghncxa03w 07-08-22 08:09:26 EST 37.5.0
APCA = 002-002-002

LSN          SPCA          SCRN SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
lsn2         001-001-002    none 1 1 no A 2 off off off no off
lsn40        020-020-021    none 1 1 no A 2 off off off no off
lsn41        021-021-021    none 1 1 no A 2 off off off no off
lsn42        022-022-022    none 1 1 no A 3 off off off no off
```

Link set table is (29 of 1024) 3% full.

If six linksets are shown in this step, choose another APC for the linkset from the **rtrv-ls** output and repeat this step.

If one to five linksets are shown in this step, continue this procedure with [Step 4](#).

4. Display the linkset that is being changed by entering the **rtrv-ls** command with the name of the linkset. For this example, enter this command.

**rtrv-ls:lsn=ls04**

This is an example of the possible output.

```
r1ghncxa03w 06-10-17 11:43:04 GMT EAGLE5 37.5.0
LSN          APCA (SS7) SCRN SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
ls04         001-002-003 scr2 1 1 no a 4 off off off yes off

          SPCA          CLLI          TFATCABMLQ MTPRSE ASL8
          -----          -----          2          ---          no

IPGWAPC MATELSN IPTPS LSUSEALM SLKUSEALM GTTMODE
no          -----          ---          ---          ---          CdPA

          L2T          L1          PCR          PCR
          SET BPS          MODE TSET          ECM          N1          N2
1205 b 0 LIMDS0 1 56000 --- --- BASIC --- ---
1213 b 1 LIMOCU 1 56000 --- --- BASIC --- ---
1211 a 2 LIMDS0 1 56000 --- --- BASIC --- ---
1207 b 3 LIMV35 1 64000 DCE OFF BASIC --- ---
```

Link set table is ( 24 of 1024) 2% full

### Changing the APC of the Linkset

If the APC of the linkset is being changed:

- To use the APC displayed in [Step 3](#), the secondary point code assigned to the linkset shown in this step cannot be shown in [Step 3](#), unless the secondary point code that is assigned to the linkset shown in this step is changed.
  - If you wish to change the secondary point code assigned to the linkset shown in this step, refer to the [Changing the Secondary Point Code of the Linkset](#) section in this step.
  - If you do not wish to change the secondary point code assigned to the linkset shown in this step, choose another APC for the linkset from the **rtrv-ls** output in [Step 1](#) and repeat this procedure from [Step 2](#).

- If the secondary point code assigned to the linkset shown in this step is not shown in [Step 3](#) , the APC displayed in [Step 3](#) can be used as the APC of the linkset that is being changed. The secondary point code that is assigned to the linkset can be changed along with the APC of the linkset.
  - If you wish to change the secondary point code that is assigned to the linkset, refer to the [Changing the Secondary Point Code of the Linkset](#) section in this step.
  - If you only wish to change the APC of the linkset, continue the procedure with [Step 10](#) .

### Changing the Secondary Point Code of the Linkset

If the secondary point code assigned to the linkset shown in this step is being changed:

- and a secondary point code is not assigned to the linkset, continue the procedure with [Step 8](#) .
  - and a secondary point code is assigned to the linkset, the secondary point code can be changed to another secondary point code value or can be removed from the linkset.
    - If you wish to change the secondary point code to another secondary point code value, continue the procedure with [Step 8](#) .
    - If you wish to remove the secondary point code value from the linkset, continue the procedure with [Step 7](#) .
5. Only one linkset can be assigned to an APC that does not have a secondary point code. Verify the secondary point codes of the linksets that are assigned to the APC shown in [Step 4](#) by entering the **rtrv-ls** command with the APC of the linkset shown in [Step 4](#) . For this example, enter this command.

```
rtrv-ls:apca=001-002-003
```

This is an example of the possible output.

```
rlghncxa03w 07-08-22 08:09:26 EST 37.5.0
```

```
APCA = 001-002-003
```

LSN	SPCA	SCRN	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
ls04	-----	scr2	1	1	no	a	4	off	off	off	yes	off

```
Link set table is (29 of 1024) 3% full.
```

If one linkset is shown in this step that does not have a secondary point code, then no secondary point codes can be removed from any of the linksets shown in this step.

- The secondary point code value can be changed to another secondary point code value. If you wish to change the secondary point code value to another secondary point code value, continue the procedure with [Step 6](#) .
- If the secondary point code value will not be changed to another secondary point code value and the APC of the linkset is being changed, [Step 3](#) and [Step 4](#) were performed, skip continue the procedure with [Step 10](#) . If the APC of the linkset is not being changed, continue the procedure with [Step 12](#) .

If all the linksets shown in this step have a secondary point code, then the secondary point code from one of these linksets can be removed. If the APC of the linkset is also being changed, [Step 3](#) and [Step 4](#) were performed, continue the procedure with [Step 10](#) . If the APC of the linkset is not being changed, continue the procedure with [Step 12](#) .

6. Display the secondary point codes by entering the **rtrv-spc** command. This is an example of the possible output.

```
rlghncxa03w 07-08-22 09:39:30 EST 37.5.0
SPC (Secondary Point Codes)
```

```
SPCA
020-020-020
020-020-021
021-021-021
022-022-022
026-026-026
026-026-027
026-026-028
026-026-029
200-010-000
```

SPC-I

none

```
SPC-N
00002
```

SPC-N24

none

Secondary Point Code table is (10 of 40) 25% full.

If the desired secondary point code is shown in this step, continue the procedure with [Step 7](#) .

If the desired secondary point code is not shown in this step, perform the "Adding a Secondary Point Code" procedure in the *Database Administration Manual - SS7* to add the desired secondary point code. The network type of the new secondary point code must be the same as the APC of the linkset. If the APC of the linkset is being changed, after the secondary point code has been added, continue the procedure with [Step 10](#) . If the APC of the linkset is not being changed, after the secondary point code has been added, continue the procedure with [Step 12](#) .

7. Verify the secondary point codes of the linksets that are assigned to the APC shown in [Step 4](#) by entering the **rtrv-ls** command with the APC of the linkset shown in [Step 4](#) . For this example, enter this command.

**NOTE: If [Step 5](#) was performed, displaying the linksets that are assigned to the APC shown in [Step 4](#) does not have to be performed.**

**rtrv-ls:apca=001-002-003**

This is an example of the possible output.

```
rlghncxa03w 07-08-22 08:09:26 EST 37.5.0
```

```
APCA = 001-002-003
```

LSN	SPCA	SCRN	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
ls04	-----	scr2	1	1	no	a	4	off	off	off	yes	off

Link set table is (29 of 1024) 3% full.

The secondary point code value that will be assigned to the linkset that is being changed cannot be assigned to any of the linksets shown in this step or in [Step 5](#) . Choose another secondary point code by repeating [Step 6](#) and [Step 7](#) .

The secondary point code value that will be assigned to the linkset that is being changed is not assigned to any of the linksets shown in this step or in [Step 5](#) , continue the procedure with either [Step 10](#) or [Step 12](#) . If the APC of the linkset is also being changed, [Step 3](#) and [Step 4](#) were performed, continue the procedure with [Step 10](#) . If the APC of the linkset is not being changed, continue the procedure with [Step 12](#) .

8. Display the point codes in the destination point code table by using the **rtrv-dstn** command. This is an example of the possible output.

```

rlghncxa03w 06-10-28 16:02:05 GMT EAGLE5 37.5.0
DPCA      CLLI      BEI  ELEI  ALIASI  ALIASN  DOMAIN
004-004-004 ----- yes --- ----- SS7
005-005-005 ----- yes --- ----- SS7
006-006-006 ----- no  --- ----- SS7
008-008-008 ----- no  --- ----- SS7
240-012-004 rlghncbb001 yes --- 1-111-1 11111  SS7
240-012-005 rlghncbb002 yes --- 1-112-2 11112  SS7
240-012-006 rlghncbb003 yes --- 1-112-3 11113  SS7
240-012-008 ----- yes --- 1-113-5 11114  SS7
001-001-001 ----- yes --- ----- X25
002-002-002 ----- yes --- ----- X25
003-003-003 ----- yes --- ----- X25
007-007-007 ----- yes --- ----- X25
244-010-004 ls06clli no  --- ----- X25
244-012-005 ls07clli no  --- ----- X25
244-012-006 ls08clli no  --- ----- X25
244-012-007 ----- no  --- ----- X25
244-012-008 ----- no  --- ----- X25

DPCI      CLLI      BEI  ELEI  ALIASA  ALIASN  DOMAIN
2-131-1   rlghncbb023 no  --- 222-210-000 12001  SS7
2-131-2   ----- no  --- 222-211-001 12002  SS7
2-131-3   ----- no  --- 222-211-002 12003  SS7

DPCN      CLLI      BEI  ELEI  ALIASA  ALIASI  DOMAIN
11211    rlghncbb013 no  --- 222-200-200 2-121-1  SS7
11212    rlghncbb013 no  --- 222-200-201 2-121-2  SS7
    
```

Destination table is (22 of 2000) 1% full

If the new APC of the linkset is not shown in the **rtrv-dstn** output, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the point code to the database. Continue the procedure with [Step 11](#) .

If the new APC of the linkset is shown in the **rtrv-dstn** output, continue the procedure with [Step 9](#) .

9. The adjacent point code of the linkset cannot be the DPC of any exception route. Verify that the adjacent point code of the new linkset is not the DPC of any exception route by entering the **rtrv-rtx** command with the **dpc/dpca** parameter. The **dpc/dpca** parameter value is the adjacent point code value that will be specified for the linkset. For this example, enter this command.

**NOTE: If the adjacent point code was added in [Step 8](#) , continue the procedure with [Step 10](#) .**

**rtrv-rtx:dpca=244-012-008**

This is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
DPCA      RTX-CRITERIA      LSN      RC      APC

244-012-008  OPCA
                007-008-009      1s01      20      002-002-002
                008-008-100     1s02      40      004-004-004

DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s): 13
EXCEPTION DPC(s): 5
NETWORK DPC(s): 0
CLUSTER DPC(s): 1
TOTAL DPC(s): 19
CAPACITY (% FULL): 1%
ALIASES ALLOCATED: 12000
ALIASES USED: 0
CAPACITY (% FULL): 0%
X-LIST ENTRIES ALLOCATED: 500
    
```

If the adjacent point code of the linkset is not the DPC of a route exception table entry, no entries are displayed in the **rtrv-rtx** output, but a summary of the point code quantities is displayed, as shown in the following output example.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

```

DESTINATION ENTRIES ALLOCATED: 2000
FULL DPC(s): 15
EXCEPTION DPC(s): 5
NETWORK DPC(s): 0
CLUSTER DPC(s): 1
TOTAL DPC(s): 21
CAPACITY (% FULL): 1%
ALIASES ALLOCATED: 12000
ALIASES USED: 0
CAPACITY (% FULL): 0%
X-LIST ENTRIES ALLOCATED: 500

```

If the point code specified in this step is shown in the **DPCA** column in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- a. Choose another adjacent point code value and repeat this procedure from [Step 1](#) .
  - b. Remove all the entries displayed in this step by performing the “Removing a Route Exception Entry” procedure in the *Database Administration Manual - SS7* .
10. Display the X.25 destinations in the database by entering the **rtrv-x25-dstn** command with the point code shown in the **rtrv-dstn** output in [Step 8](#) .

```
rtrv-x25-dstn:dpca=244-012-008
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 37.5.0
X25 ADDR      SS7 DPC      SSN
234234231     244-012-008 113
X.25 DSTN TABLE IS 30 % FULL

```

If the new APC of the linkset is not shown in the **rtrv-x25-dstn** output, continue the procedure with [Step 12](#) .

If the new APC of the linkset is shown in the **rtrv-x25-dstn** output, continue the procedure with [Step 11](#) .

11. Display the X.25 routes by entering the **rtrv-x25-rte** command with the **xaddr** parameter value shown in [Step 10](#) . For this example, enter this command.

```
rtrv-x25-rte:xaddr=234234231
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 37.5.0
X25 ADDR      SS7 ADDR      TYPE LOC  PORT  LC  RT  LC2NM
234234231     44401         pvc 1205  a    01  xpc  no
X.25 ROUTE TABLE IS 30 % FULL

```

If the LC2NM value in the X.25 route is no, continue the procedure with [Step 12](#) .

If the LC2NM value in the X.25 route is yes, the new linkset APC cannot be used in the X.25 linkset. To use the new linkset APC in the X.25 linkset, the LC2NM value of the X.25 route associated with the new linkset APC must be no. The LC2NM value must be changed to no, or another X.25 point code must be chosen.

To chose another X.25 point code, repeat this procedure from [Step 1](#) .

To change the LC2NM value, perform the [Changing an X.25 Route](#) procedure. Then continue the procedure with [Step 12](#) .

12. Verify that the gateway screening screen set that is to be assigned to the linkset is in the database by entering the **rtrv-scrset** command.

**NOTE: If the screen set assigned to the linkset is not being changed, or if the screen set that you wish to assign to the linkset is assigned to other linksets (shown in the **SCRN** field of the **rtrv-ls** command output in [Step 1](#) ), continue the procedure with [Step 13](#) .**

This is an example of the possible output.

```
rlghncxa03w 06-10-28 16:37:05 GMT EAGLE5 37.5.0
ENTIRE GWS DATABASE IS 1% FULL
CDPA + AFTPC TABLES ARE 1% FULL
THERE ARE 243 SCREEN SETS AVAILABLE
```

```
THE FOLLOWING ARE OVER 80% FULL:
SCRN  NSFI    NSR/ACT  FULL  RULES  TABLES  DESTFLD

SCRN  NSFI    NSR/ACT  FULL  RULES  TABLES  DESTFLD
fld1  OPC     fld2     1%    5      4        NO
gws1  OPC     gws4     1%    9      7        NO
gws2  BLKOPC  gws5     1%    5      4        NO
ls01  SIO     ls02     1%    3      3        YES
scr1  OPC     opc1     1%    37     10       YES
scr2  OPC     opc2     2%    75     22       YES
scr3  OPC     opc3     2%    75     22       YES
scr4  OPC     opc1     51%   2075   22       NO
scr5  OPC     opc1     51%   2075   22       YES
scr6  OPC     opc1     51%   2075   22       NO
ss28  OPC     opc1     51%   2075   22       YES
wrld1 SIO     iec      1%    6      5        YES
```

If you wish to examine the contents of a particular screen set, enter the **rtrv-scrset:scrn=<screen set name>** command specifying a screen set name shown in the **SCRN** field of either the **rtrv-scrset** command executed in this step or the **rtrv-ls** command executed in [Step 1](#) .

For this example, enter the **rtrv-scrset:scrn=scr1** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-14 16:39:04 GMT EAGLE5 37.5.0
SCRN  NSFI    NSR/ACT  RULES  DESTFLD
scr1  OPC     opc1     3      Y
      BLKDPC  bkd2     2
      CGPA   cgpl     3
      TT    tt1     3
      TT    tt2     3
      TT    tt3     4
      CDPA  cdp1     3
      CDPA  cdp2     3
      CDPA  cdp3     4
      AFTPC  end1     9
```

The output of this command shows the screens that make up the screen set. These screens can be examined by entering the gateway screening retrieve command corresponding the to the value in the **NSFI** field and specifying the screening reference name shown in the **NSR/ACT** field. For this example, you enter these commands to examine the screens in the screen set.

```
rtrv-scr-opc:sr=opc1
```

```
rtrv-scr-blkdpc:sr=bkd2
```

```

rtrv-scr-cgpa:sr=cgp1
rtrv-scr-tt:sr=tt1
rtrv-scr-tt:sr=tt2
rtrv-scr-tt:sr=tt3
rtrv-scr-cdpa:sr=cdp1
rtrv-scr-cdpa:sr=cdp2
rtrv-scr-cdpa:sr=cdp3
rtrv-scr-aftpc:sr=end1

```

If the screen set that you wish to assign to the linkset is not in the database, go to the "Adding a Screen Set" procedure in the *Database Administration Manual - Gateway Screening* and add the screen set to the database.

- Remove the current screen set assigned to this linkset by entering the **chg-ls** command with the **scrn=none** parameter. For this example, enter this command.

**NOTE: If the linkset being changed does not have a screen set assigned to it (the SCRN value for the linkset is NONE), continue the procedure with [Step 14](#) .**

```
chg-ls:lsn=ls7:scrn=none
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-07 08:38:45 GMT EAGLE5 37.5.0
Link set table is ( 24 of 1024) 2% full
CHG-LS: MASP A - COMPLTD

```

- The **gttmode** parameter can be specified with the values **acdcd**, **cgacdcd**, **acdgcgd**, **acdcdcg**, **cgcd**, **cdcg**, or **cg** only if the Origin Based SCCP Routing feature is enabled. Enter the **rtrv-ctrl-feat** command with the part number of the Origin Based SCCP Routing feature to verify whether or not the Origin Based SCCP Routing feature is enabled. Enter this command.

**NOTE: If the gttmode parameter is not being specified for the linkset, continue the procedure with [Step 15](#) .**

**NOTE: If the gttmode parameter is being specified for the linkset with either the **sysdf1t** or **cd** values, continue the procedure with [Step 15](#) .**

```
rtrv-ctrl-feat:partnum=893014301
```

This is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
The following features have been permanently enabled:

Feature Name          Partnum   Status Quantity
Origin Based SCCP Routing 893014301 on      ----

The following features have been temporarily enabled:

Feature Name          Partnum   Status Quantity   Trial Period Left
Zero entries found.

The following features have expired temporary keys:

Feature Name          Partnum
Zero entries found.

```

If the Origin Based SCCP routing feature is enabled, continue the procedure with [Step 15](#) .

If the Origin Based SCCP routing feature is not enabled, perform the “Activating the Origin Based SCCP Routing Feature” procedure in the *Database Administration Manual - Global Title Translation* to enable the Origin Based SCCP Routing feature. After the Origin Based SCCP Routing feature is enabled, continue the procedure with [Step 15](#) .

15. Display the current linkset configuration of the linkset to be changed using the **rtrv-ls** command with the linkset name. For this example, enter this command.

```
rtrv-ls:lsn=ls7
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 37.5.0
                                L3T SLT                                GWS GWS GWS
LSN          APCA  (X25)  SCRN  SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
ls7          244-012-005  scr5  1   5  no  c   3   on  on  on  ---  off

                                CLLI          TFATCABMLQ MTPRSE ASL8
ls07c11i    ---          ---          ---

IPGWAPC MATELSN          IPTPS LSUSEALM SLKUSEALM GTTMODE
no          -----  ---          ---          ---          CdPA

                                L2T          L1          PCR  PCR
                                SET  BPS      MODE TSET   ECM   N1   N2
1205 A          0  LIMV35  -   56000  DTE  --   BASIC ---  ---
1206 A          1  LIMV35  -   56000  DTE  --   BASIC ---  ---
1207 A          2  LIMV35  -   64000  DTE  --   BASIC ---  ---
```

Link set table is ( 22 of 1024) 2% full

16. The **cggtmod** parameter cannot be specified with the **chg-ls** command unless the AMGTT or AMGTT CgPA Upgrade feature is enabled. If the **CGGTMOD** column is shown in the **rtrv-ls** output, the AMGTT or AMGTT CgPA Upgrade feature is enabled.
  - If the **cggtmod** parameter will not be specified with the **chg-ls** command, continue the procedure with [Step 17](#) .
  - If the **CGGTMOD** column is shown in the **rtrv-ls** output in [Step 15](#) , and you wish to specify the **cggtmod** parameter with the **chg-ls** command, continue the procedure with [Step 17](#) .
  - If the **CGGTMOD** column is not shown in the **rtrv-ls** output in [Step 15](#) , and you wish to specify the **cggtmod** parameter with the **chg-ls** command, perform the "Activating the Advanced GT Modification Feature" procedure in the *Database Administration Manual - Global Title Translation* procedure to enable the required feature. After the AMGTT or AMGTT CgPA Upgrade feature is enabled, continue the procedure with [Step 17](#) .
17. Deactivate the signaling links in the linkset using the **dact-slk** command. For this example, enter these commands.

```
dact-slk:loc=1205:link=a
```

```
dact-slk:loc=1206:link=a
```

```
dact-slk:loc=1207:link=a
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 37.5.0
Deactivate Link message sent to card
```

18. Change the linkset configuration using the **chg-ls** command. For this example, enter this command.

```
chg-ls:lsn=ls7:apca=244-012-008:scrn=scr7:lst=a :gttmode=cgacdcd
```

This command example changes the APC of the linkset to **244-012-008**, changes the gateway screening screen set name to **scr7**, changes the linkset type to A, and changes the GTT mode to CgPA GTT, Advanced CdPA GTT, CdPA GTT.

.When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:38:45 GMT EAGLE5 37.5.0
Link set table is ( 22 of 1024) 2% full
CHG-LS: MASP A - COMPLTD
```

19. Verify the changes using the **rtrv-ls** command, specifying the linkset name that was changed in [Step 18](#) . For this example, enter this command.

```
rtrv-ls:lsn=ls7
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 37.5.0
                                L3T SLT                                GWS GWS GWS
LSN          APCA  (X25)  SCRNL  SET SET BEI  LST LNKS ACT MES DIS SLSCI NIS
ls7          244-012-008  scr7  1  5  no  a   3   on on on  ---  off

          CLLI          TFATCABMLQ MTPRSE ASL8
          -----          ---          ---          ---

          IPGWAPC MATELSN          IPTPS LSUSEALM SLKUSEALM GTTMODE
          no          -----          ---          ---          ---          CgPA, AdvCdPA, CdPA

          LOC  LINK  SLC  TYPE          L2T          L1          PCR  PCR
          1205 A    0    LIMV35  -    56000  DTE  --    BASIC  ---  -----
          1206 A    1    LIMV35  -    56000  DTE  --    BASIC  ---  -----
          1207 A    2    LIMV35  -    64000  DTE  --    BASIC  ---  -----
```

```
Link set table is ( 22 of 1024) 2% full
```

20. Activate the signaling links that were deactivated in [Step 17](#) using the **act-slk** command. For this example, enter these commands.

```
act-slk:loc=1205:link=a
```

```
act-slk:loc=1206:link=a
```

```
act-slk:loc=1207:link=a
```


When each of these commands have successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 37.5.0
Activate Link message sent to card
```


21. Backup the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 2-8. Changing an X.25 Linkset


























## Adding an X.25 Signaling Link

This procedure is used to add an X.25 signaling link to the database using the **ent-slk** command. To add SS7 signaling links to the database, go to the “Adding an SS7 Signaling Link” procedure in the *Database Administration Manual – SS7*.

The **ent-slk** command uses these parameters to configure an X.25 signaling link.

**:loc** – The card location of the LIM that the X.25 signaling link will be assigned to.

**:link** – The signaling link on the card specified in the **loc** parameter. For an X.25 signaling link, this parameter value is A.

**:lsn** – The name of the linkset that will contain the signaling link.

**:slc** – The signaling link code. The SLC must be unique within the linkset. It must be the same at both the EAGLE 5 ISS location and the distant node.

**:llmode** – The mode of operation used to select the link clocking source at layer 1. One end of a V.35 link must be DTE and the other end must be DCE.

**:bps** – The transmission rate for the link in bits per second.

**:tset** – Transmitter signal element timing.

**:ecm** – Error correction method.

**:pcrn1** – The threshold of the number of MSUs available for retransmission. If the error correction method being used is PCR, and this threshold is reached, no new MSUs or FISUs are sent. The retransmission cycle is continued up to the last MSU entered into the retransmission buffer in the order in which they were originally transmitted.

**:pcrn2** – The threshold of the number of MSU octets available for retransmission. If the error correction method being used is PCR, and this threshold is reached, no new MSUs or FISUs are sent. The retransmission cycle is continued up to the last MSU entered into the retransmission buffer in the order in which they were originally transmitted.

The **ent-slk** command contains other optional parameters that are not used to configure an X.25 signaling link. These parameters are discussed in more detail in the *Commands Manual* or in these sections.

- These procedures in the *Database Administration Manual - SS7*
  - Adding an SS7 Signaling Link
  - Adding an E1 Signaling Link
  - Adding a T1 Signaling Link
  - Adding an ATM High-Speed Signaling Link
- These procedures in the *Database Administration Manual - IP<sup>7</sup> Secure Gateway*
  - Adding an IPGWx Signaling Link
  - Adding an IPLIMx Signaling Link
  - Adding an IPSG M3UA Signaling Link
  - Adding an IPSG M2PA Signaling Link

The examples in this procedure are based on the example network shown in [Figure 2-4](#) and [Table 2-6](#) and are used to add X.25 signaling links to cards 1205, 1206, and 1207.

**Table 2-6. X.25 Signaling Link Configuration Table**

SLK LOC	SLK LINK	LSN	SLC	TYPE	BPS
1205	A	LS03	0	LIMV35	56000
1206	A	LS03	1	LIMV35	56000
1207	A	LS04	0	LIMV35	64000

These items must be provisioned in the database before an X.25 signaling link can be added:

- A shelf – see the "Adding a Shelf" procedure in the *Database Administration Manual – System Management*.
- An LIM (card type **limocu**, **limds0**, or **limv35**) assigned to the **ss7gx25** application – see [Adding an X.25 LIM](#) .
- A destination point code (DPC) assigned to the X.25 domain – see the “Adding a ANSI Destination Point Code” procedure in the *Database Administration Manual – SS7* .
- A linkset whose adjacent point code (APC) is in the X.25 domain – see [Adding an X.25 Linkset](#)

Verify that the X.25 signaling link has been physically installed (all cable connections have been made).

If the **l1mode** or **tset** parameters are specified, the card type must be **limv35**.

The **tset** parameter can only be specified with the **l1mode=dce** parameter. When **l1mode=dce** is specified and the **tset** parameter is not specified, the value of the **tset** parameter is set to **off**, and dashes are shown in the **TSET** column in the **rtrv-slk** output. The default value for the **l1mode** parameter is **dte**.

The transmission rate of the X.25 signaling link can be either 4800 (**bps=4800**), 9600 (**bps=9600**), 19200 (**bps=19200**), 56000 (**bps=56000**), or 64000 (**bps=64000**) bits per second. If the card type is either **limds0** or **limocu**, the transmission rate of the X.25 signaling link can be either 56000 or 64000. The transmission rates 4800, 9600, or 19200 can be specified only if the card type is **limv35**. The default value for the X.25 signaling link transmission rate is 56000.

The **l2tset** parameter cannot be specified for an X.25 signaling link, but its value is defaulted to **11** and is shown in the **L2TSET** column in the **rtrv-slk** output.

The linkset must be in the database. The number of signaling links in a linkset cannot exceed 16. The number of signaling links in the linkset is shown in the **LNKS** column of the **rtrv-ls** command output.

The APC of the linkset assigned to the signaling link must be in the X.25 domain. Use the **rtrv-dstn** command to verify the domain of the APC of the linkset.

### Requirements for EAGLE 5 ISSs Containing more than 700 Signaling Links

To provision an EAGLE 5 ISS with more than 700 signaling links (currently the EAGLE 5 ISS can have maximum capacities of 1200, 1500, or 2000 signaling links), the following additional requirements must be met:

- The Measurements Platform feature must be enabled. Perform these procedures in the *Database Administration Manual - System Management* to enable the Measurements Platform feature:
  - "Adding an MCPM"
  - "Configuring the IP Communications Link for the Measurements Platform"
  - "Adding an FTP Server"
- To provision more than 1200 signaling links, the Large System # Links controlled feature must be enabled for 1500 or 2000 signaling links. For more information on enabling this feature, go to [Enabling the Large System # Links Controlled Feature](#) .

**NOTE: An X.25 signaling link cannot be assigned to a Multiport LIM.**

For more information on these hardware components, go to the *Installation Manual - EAGLE 5 ISS* .

### Determining the Number of High-Speed and Low-Speed Signaling Links

An EAGLE 5 ISS containing either 1200, 1500, or 2000 signaling links can contain the following quantities of signaling links:

- 180 high-speed ATM signaling links assigned to the ATMANSI application. If there are any high-speed ATM signaling links assigned to the ATMITU application, the maximum number of high-speed ATM signaling links is 115.
- 100 signaling links assigned to either the IPLIM or IPLIMI applications.
- 64 signaling links assigned to either the SS7IPGW or IPGWI application, or combinations of the SS7IPGW and IPGWI applications.
- 64 unchannelized E1 signaling links.

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the `ccs7itu` application.
- HC-MIM running the `ccs7itu` application.
- E5-E1T1 running the `ccs7itu` application.
- Single-slot EDCM running either the `iplimi` or `ipgwi` applications.
- E5-ENET running either the `iplimi` or `ipgwi` applications.
- ATM high-speed LIM running the `atmitu` application.

### Canceling the REPT-STAT-SLK and RTRV-SLK Commands

Because the `rept-stat-slk` and `rtrv-slk` commands used in this procedure can output information for a long period of time, the `rept-stat-slk` and `rtrv-slk` commands can be canceled and the output to the terminal stopped.

There are three ways that the `rept-stat-slk` and `rtrv-slk` commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the `rept-stat-slk` or `rtrv-slk` commands were entered.
- Enter the `canc-cmd` without the `trm` parameter at the terminal where the `rept-stat-slk` or `rtrv-slk` commands were entered.
- Enter the `canc-cmd:trm=<xx>`, where `<xx>` is the terminal where the `rept-stat-slk` or `rtrv-slk` commands were entered, from another terminal other than the terminal where the `rept-stat-slk` or `rtrv-slk` commands were entered. To enter the `canc-cmd:trm=<xx>` command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the `rtrv-secu-trm` command. The user's permissions can be verified with the `rtrv-user` or `rtrv-secu-user` commands.

For more information about the `canc-cmd` command, go to the *Commands Manual*.

1. Display the cards in the database using the `rtrv-card` command.

The X.25 LIMs are shown by the entry **SS7GX25** in the **APPL** field. This is an example of the possible output.

```

rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM          SCCP
1113   GPMS        EOAM
1114   TDM-A
1115   GPMS        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0     SS7ANSI   sp2            A    0    sp1            B    0
1202   LIMV35     SS7GX25
1203   LIMDS0     SS7ANSI   sp3            A    0
1204   LIMDS0     SS7ANSI   sp3            A    1
1206   LIMDS0     SS7ANSI   nsp3           A    1    nsp4           B    1
1207   LIMV35     SS7GX25   nsp1           A    0
1208   LIMV35     SS7GX25   nsp1           A    1
1216   ACMENET    STPLAN
1301   TSM          SCCP
1308   LIMDS0     SS7ANSI   sp6            A    1    sp7            B    0
1314   LIMDS0     SS7ANSI   sp7            A    1    sp5            B    1
1317   ACMENET    STPLAN
    
```

If the required card is not in the database, go to [Adding an X.25 LIM](#) and add the card to the database.

2. Display the current linkset configuration using the **rtrv-ls** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0

LSN          APCA (SS7)  SCRNL3T SLT          GWS GWS GWS
lsa1         240-020-000scr1 1 1  yes a 1  off off off no  off
lsa2         240-030-000scr2 1 2  no  c 3  on  on  on yes  off
lsa3         240-040-000scr3 1 3  yes c 5  off off off yes  off
ls01         006-006-006scr1 1 1  yes a 1  on  off off no  off
ls02         008-008-008scr1 1 1  yes a 1  on  off off yes  off

LSN          APCA (X25)  SCRNL3T SLT          GWS GWS GWS
ls6          244-010-004scr4 1 4  no  a 6  off off off --- off
ls7          244-012-005scr5 1 5  no  c 3  on  on  on --- off
ls8          244-012-006scr6 1 6  no  c 8  off off off --- off

LSN          APCI (SS7)  SCRNL3T SLT          GWS GWS GWS
lsi1         1-111-1     scr1 1 1  yes a 1  off off off --- ---
lsi2         1-111-2     scr2 1 2  no  c 3  on  on  on --- ---
lsi3         1-111-3     scr3 1 3  yes c 5  off off off --- ---

LSN          APCN (SS7)  SCRNL3T SLT          GWS GWS GWS
lsn1         11111       scr1 1 1  yes a 1  off off off --- off
lsn2         11112       scr2 1 2  no  c 3  on  on  on --- off
lsn3         11113       scr3 1 3  yes c 5  off off off --- off
    
```

Link set table is ( 14 of 1024) 1% full

If the required linkset is not in the database, go to [Adding an X.25 Linkset](#) and add the linkset to the database.

3. Display the current signaling link configuration using the **rtrv-slk** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC  LINK LSN          SLC TYPE      L2T          L1          PCR PCR
      SET BPS      MODE TSET  ECM      N1  N2
    
```

```

1201 A   lsn1201a   0 LIMDS0   1   56000 --- --- BASIC --- -----
1201 B   lsn1201b   0 LIMDS0   1   56000 --- --- PCR   76   3800
1202 A   lsn1202a   0 LIMV35   -   64000 DTE --- BASIC --- -----
1202 B   lsn1202b   1 LIMV35   3   64000 DCE ON  BASIC --- -----
1203 A   lsn1203a   0 LIMV35   1   56000 DCE ON  BASIC  76   3800
1203 B   lsn1203b   0 LIMV35   1   56000 DCE OFF PCR   120  5034
1204 A   lsn1204a   1 LIMV35   3   64000 DCE ON  PCR   76   3800
1204 B   lsn1204b   1 LIMV35   3   64000 DCE ON  PCR   76   3800
1301 A   lsn1301a   0 LIMDS0   -   56000 --- -- BASIC --- -----

```

```

LOC LINK LSN          SLC TYPE      LP          ATM
SET BPS      TSEL          VCI    VPI    LL
1302 A   atmansi0    0 LIMATM     3  1544000 INTERNAL 35    15    0
1305 A   atmansi1    0 LIMATM     4  1544000 INTERNAL 100   20    2
1318 A   atmansi0    1 LIMATM     9  1544000 LINE    150   25    4

```

SLK table is (12 of 1200) 1% full.

If the **rtrv-slk** output shows that the maximum number of signaling links is 2000, go to step 4.

If the **rtrv-slk** output shows that the maximum number of signaling links is 1200, and the signaling link being added increases the number beyond 1200, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for either 1500 signaling links or 2000 signaling links. Then go to step 4.

If the **rtrv-slk** output shows that the maximum number of signaling links is 1500, and the signaling link being added increases the number beyond 1500, perform the [Enabling the Large System # Links Controlled Feature](#) procedure and enable the Large System # Links controlled feature for 2000 signaling links. Then go to step 4.

If the addition of the new signaling link will not exceed the maximum number of signaling links, go to step 4.

4. Add the X.25 signaling link using the **ent-slk** command. For this example, enter these commands.

```

ent-slk:loc=1205:link=a:lsn=ls03:slc=0
ent-slk:loc=1206:link=a:lsn=ls03:slc=1
ent-slk:loc=1207:link=a:lsn=ls04:slc=0:bps=64000

```

When each of these commands have successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 08:29:03 GMT EAGLE5 36.0.0
ENT-SLK: MASP A - COMPLTD

```

5. Verify the changes using the **rtrv-slk** command with the card location specified in step 5. For this example, enter these commands.

```
rtrv-slk:loc=1205
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN          SLC TYPE      LP          ATM
SET BPS      MODE TSET          ECM    N1    N2
1205 A   ls03          0 LIMV35     11  56000 DTE --- BASIC --- -----

```

```
rtrv-slk:loc=1206
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC LINK LSN          SLC TYPE      LP          ATM
SET BPS      MODE TSET          ECM    N1    N2
1206 A   ls03          1 LIMV35     11  56000 DTE --- BASIC --- -----

```

```

LOC LINK LSN          SLC TYPE      SET BPS      MODE TSET  ECM  N1  N2
1206 A   1s03          1  LIMV35     11  56000    DTE  ---  BASIC ---  -----

```

```
rtrv-slk:loc=1207
```

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
                                L2T          L1          PCR  PCR
LOC LINK LSN          SLC TYPE      SET BPS      MODE TSET  ECM  N1  N2
1207 A   1s04          0  LIMV35     11  64000    DTE  ---  BASIC ---  -----

```

**NOTE: If the X.25 signaling link parameters for the newly added X.25 signaling link are not being changed, skip steps 6 through 8 and go to step 9.**

6. Display the values of the X.25 signaling link you wish to change using the **rtrv-x25-slk** command. This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC  PORT  T1  N1   N2  K  L3MODE  PVC  SVC  WIN  MPS
1202 A    9   1080 13  6  DTE    255  0   2   128
1205 A    5   2104 10  7  DTE     0   1   3   256
1206 A    5   2104 10  7  DTE     0   1   3   256
1207 A    5   2104 10  7  DTE     0   1   3   256
1301 A    5   1080 10  7  DTE     0  255  3   128

```

7. Change the X.25 signaling link parameter values using the **chg-x25-slk** command. For this example, enter these commands.

```
chg-x25-
slk:loc=1205:port=a:t1=2:n1=1080:n2=5:k=1:l3mode=dte :pvc=2:svc=0:win=6
:mps=128
```

```
chg-x25-
slk:loc=1206:port=a:t1=4:n1=2104:n2=12:k=3:l3mode=dce :pvc=2:svc=0:win=
3:mps=256
```

```
chg-x25-
slk:loc=1207:port=a:t1=8:n1=2104:n2=7:k=6:l3mode=dce :pvc=0:svc=2:win=2
:mps=256
```

When each of these commands have successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
CHG-X25-SLK: MASP A - COMPLTD

```

8. Verify the changes using the **rtrv-x25-slk** command. This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC  PORT  T1  N1   N2  K  L3MODE  PVC  SVC  WIN  MPS
1202 A    9   1080 13  6  DTE    255  0   2   128
1205 A    2   1080  5  1  DTE     2   0   6   128
1206 A    4   2104 12  3  DCE     2   0   3   256
1207 A    8   2104  7  6  DCE     0   2   2   256
1301 A    5   1080 10  7  DTE     0  255  3   128

```

9. Put the X.25 LIMs in service using the **rst-card** command with the card location specified in step 5. For this example, enter these commands.

```
rst-card:loc=1205
```

```
rst-card:loc=1206
```

```
rst-card:loc=1207
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:21:07 GMT EAGLE5 36.0.0
Card has been allowed.
```

10. Activate the X.25 signaling links using the **act-slk** command with the card location and the signaling link specified in step 5. For this example, enter these commands.

```
act-slk:loc=1205:link=a
```

```
act-slk:loc=1206:link=a
```

```
act-slk:loc=1207:link=a
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:31:24 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

11. Check the status of the X.25 signaling link using the **rept-stat-slk** command with the card location and the signaling link specified in step 5 for each X.25 signaling link added in step 5. The state of the X.25 signaling link should be in service normal (IS-NR) after the link has completed alignment (shown in the **PST** field). For this example, enter these commands.

```
rept-stat-slk:loc=1205:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN   CLLI   PST   SST   AST
1205,A 1s03   ----- IS-NR   Avail  ----
      ALARM STATUS      = No alarm
      UNAVAIL REASON    =
Command Completed.
```

```
rept-stat-slk:loc=1206:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN   CLLI   PST   SST   AST
1206,A 1s03   ----- IS-NR   Avail  ----
      ALARM STATUS      = No alarm
      UNAVAIL REASON    =
Command Completed.
```

```
rept-stat-slk:loc=12075:link=a
```

This is an example of the possible output.


```
rlghncxa03w 06-10-28 17:00:36 GMT EAGLE5 36.0.0
SLK   LSN   CLLI   PST   SST   AST
1207,A 1s04   ----- IS-NR   Avail  ----
      ALARM STATUS      = No alarm
      UNAVAIL REASON    =
Command Completed.
```


12. Backup the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
```


BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 2-9. Adding an X.25 Signaling Link









## Removing an X.25 Signaling Link

This procedure is used to remove an X.25 signaling link from the database using the **dlt-slk** command. To remove SS7 signaling links from the database, go to the "Removing an SS7 Signaling Link" procedure in the *Database Administration Manual – SS7*.

The **dlt-slk** command uses these parameters.

**:loc** – The card location of the LIM that the X.25 signaling link is assigned to.

**:link** – The signaling link on the card location specified in the **loc** parameter. For an X.25 signaling link, this parameter value is A.

**:force** – This parameter must be used to remove the last link in a linkset without having to remove all of the routes that referenced the linkset.

The examples in this procedure are used to remove the X.25 signaling link assigned to card 1207 from the database.

The X.25 signaling link to be removed must exist in the database.

All X.25 routes associated with this link must be removed before the X.25 signaling link can be removed. See the [Removing an X.25 Route](#) procedure.

### Canceling the RTRV-SLK Command

Because the **rtrv-slk** command used in this procedure can output information for a long period of time, the **rtrv-slk** command can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-slk** command can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-slk** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-slk** command was entered, from another terminal other than the terminal where the **rtrv-slk** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current link configuration using the **rtrv-slk** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

LOC	LINK	LSN	SLC	TYPE	L2T SET	BPS	L1 MODE	TSET	ECM	PCR N1	PCR N2
1201	A	lsn1201a	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1201	B	lsn1201b	0	LIMDS0	1	56000	---	---	PCR	76	3800
1202	A	lsn1202a	0	LIMV35	-	64000	DTE	---	BASIC	---	-----
1202	B	lsn1202b	1	LIMV35	3	64000	DCE	ON	BASIC	---	-----
1203	A	lsn1203a	0	LIMV35	1	56000	DCE	ON	BASIC	76	3800
1203	B	lsn1203b	0	LIMV35	1	56000	DCE	OFF	PCR	120	5034
1204	A	lsn1204a	1	LIMV35	3	64000	DCE	ON	PCR	76	3800
1204	B	lsn1204b	1	LIMV35	3	64000	DCE	ON	PCR	76	3800
1205	A	ls03	0	LIMV35	-	56000	DTE	--	BASIC	---	-----
1206	A	ls03	1	LIMV35	-	56000	DTE	--	BASIC	---	-----
1207	A	ls04	0	LIMV35	-	64000	DTE	--	BASIC	---	-----
1301	A	lsn1301a	0	LIMDS0	-	56000	---	--	BASIC	---	-----

LOC	LINK	LSN	SLC	TYPE	LP SET	BPS	ATM TSEL	VCI	VPI	LL
1302	A	atmansio	0	LIMATM	3	1544000	INTERNAL	35	15	0
1305	A	atmansil	0	LIMATM	4	1544000	INTERNAL	100	20	2
1318	A	atmansio	1	LIMATM	9	1544000	LINE	150	25	4

SLK table is (15 of 1200) 1% full.

2. Deactivate the X.25 signaling link to be removed using the **dact-slk** command, using the output from step 1 to obtain the card location and the signaling link to be removed. For this example, enter this command.

```
dact-slk:loc=1207:link=a
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 36.0.0
Deactivate Link message sent to card
```

3. Verify that the X.25 signaling link is out of service - maintenance (OOS-MT) using the **rept-stat-slk** command, using the card location and the signaling link. For this example, enter this command.

```
rept-stat-slk:loc=1207:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 17:00:36 GMT EAGLE5 36.0.0
```

```

SLK      LSN      CLLI      PST      SST      AST
1207,A  ls04      -----  OOS-MT   Unavail  ----
  ALARM STATUS      = * 0221 REPT-LKF: X25 link unavailable
  UNAVAIL REASON    = X25FL
Command Completed.

```

- Before the X.25 signaling link can be removed from the database, any X.25 routes associated with the X.25 signaling link must be removed from the database. Enter the **rtrv-x25-rte** command to display the X.25 routes in the database. This is an example if the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE  LOC  PORT  LC  RT  LC2NM
11101         44401         pvc   1205 a    01  xpc no
11102         55501         pvc   1206 a    02  pc  no
22201         44401         pvc   1205 a    02  pc  no
22202         55501         pvc   1206 a    01  xpc yes
33301         44401         svca  1207 a    --  pc  no
33302         55501         svca  1207 a    --  pc  no
X.25 ROUTE TABLE IS 30 % FULL

```

- If any X.25 routes shown in the output of step 5 are assigned to the X.25 signaling links shown in the output of step 4, remove those X.25 routes by using the **dlt-x25-rte** command. For this example, enter these commands.

```
dlt-x25-rte:xaddr=33301:saddr=44401
```

```
dlt-x25-rte:xaddr=33302:saddr=55501
```

When each of these commands have successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
DLT-X25-RTE: MASP A - X.25 Route table 30% full
DLT-X25-RTE: MASP A - COMPLTD

```

- Verify the changes using the **rtrv-x25-rte** command. This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE  LOC  PORT  LC  RT  LC2NM
11101         44401         pvc   1205 a    01  xpc no
11102         55501         pvc   1206 a    02  pc  no
22201         44401         pvc   1205 a    02  pc  no
22202         55501         pvc   1206 a    01  xpc yes
X.25 ROUTE TABLE IS 30 % FULL

```

- Because there can only be one X.25 signaling link assigned to a LIM, that card must be inhibited. Enter the **rmv-card** command and specify the location of the card to be inhibited. The card location is shown in the output of **rept-stat-slk** command executed in step 4. For this example, enter this command.

```
rmv-card:loc=1207
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 36.0.0
Card has been inhibited.

```

- Remove the X.25 signaling link from the database using the **dlt-slk** command. If this X.25 signaling link is the last link in a linkset, the **force=yes** parameter must be specified. For this example, enter this command.

```
dlt-slk:loc=1207:link=a:force=yes
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:41:17 GMT EAGLE5 36.0.0
DLT-SLK: MASP A - COMPLTD
```

- Verify the changes using the **rtrv-slk** command. This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
```

LOC	LINK	LSN	SLC	TYPE	L2T		L1		ECM	PCR	
					SET	BPS	MODE	TSET		N1	N2
1201	A	lsn1201a	0	LIMDS0	1	56000	---	---	BASIC	---	-----
1201	B	lsn1201b	0	LIMDS0	1	56000	---	---	PCR	76	3800
1202	A	lsn1202a	0	LIMV35	-	64000	DTE	---	BASIC	---	-----
1202	B	lsn1202b	1	LIMV35	3	64000	DCE	ON	BASIC	---	-----
1203	A	lsn1203a	0	LIMV35	1	56000	DCE	ON	BASIC	76	3800
1203	B	lsn1203b	0	LIMV35	1	56000	DCE	OFF	PCR	120	5034
1204	A	lsn1204a	1	LIMV35	3	64000	DCE	ON	PCR	76	3800
1204	B	lsn1204b	1	LIMV35	3	64000	DCE	ON	PCR	76	3800
1205	A	ls03	0	LIMV35	-	56000	DTE	--	BASIC	---	-----
1206	A	ls03	1	LIMV35	-	56000	DTE	--	BASIC	---	-----
1301	A	lsn1301a	0	LIMDS0	-	56000	---	---	BASIC	---	-----


LOC	LINK	LSN	SLC	TYPE	LP		ATM			
					SET	BPS	TSEL	VCI	VPI	LL
1302	A	atmansio	0	LIMATM	3	1544000	INTERNAL	35	15	0
1305	A	atmansil	0	LIMATM	4	1544000	INTERNAL	100	20	2
1318	A	atmansio	1	LIMATM	9	1544000	LINE	150	25	4

SLK table is (15 of 1200) 1% full.

- Backup the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-10. Removing an X.25 Signaling Link



## Adding an X.25 Route

This procedure is used to add an X.25 route to the database using the **ent-x25-rte** command.

The **ent-x25-rte** command uses these parameters.

- :xaddr** – The X.25 address assigned to the X.25 destination entity on the X.25 side of the circuit.
- :saddr** – The dummy X.25 address assigned to the SS7 destination entity on the SS7 side of the circuit.
- :type** – The type of X.25 connection that the link is expected to maintain.
- :loc** – The card location of the LIM containing the X.25 signaling link that will maintain the connection. For an automatic virtual circuit, this link is the link on which the EAGLE 5 ISS initially attempts the connection. However, if this attempt fails, the connection may be established by the X.25 destination entity on any other link in this link's linkset.

**:port** – The signaling link on the card specified in the **loc** parameter. For an X.25 signaling link, this parameter value is A.

**:lc** – The number of the logical channel on the X.25 signaling link to which the PVC connection is assigned. This parameter is mandatory if the **type=pvc** parameter is specified. If the **type=svca** or **type=svcr** parameters are specified, the logical channel number is arbitrary and cannot be specified.

**:rt** – The type of routing to perform for messages originating in the SS7 domain and destined for the X.25 domain. Two types of routing are available: (1) Route on X.25 destination point code (XPC) and (2) Route using X.25 origination and destination point code combinations (PC).

**:lc2nm** – Invokes network management for failures and recoveries of logical channels. When the logical channel being used to carry data fails, network management reroutes traffic to an alternate route. The logical channel to network management mapping (LC2NM) feature handles this process.

The examples in this procedure are based on the example network shown in [Figure 2-4](#) and [Table 2-7](#) and are used to add X.25 signaling links to cards 1205, 1206, and 1207.

**Table 2-7. X.25/SS7 Gateway Route Configuration**

Conn #	X.25 Address	SS7 Address	X.25 Point Code/ SSN	SS7 Point Code/ SSN	Connection Type	Location	Port	Logical Channel
1	11101	44401	1-1-1/5	4-4-4/5	PVC	1205	A	1
2	11102	55501	1-1-1/5	5-5-5/5	PVC	1206	A	2
3	22201	44401	2-2-2/5	4-4-4/5	PVC	1205	A	2
4	22202	55501	2-2-2/10	5-5-5/10	PVC	1206	A	1
5	33301	44401	3-3-3/6	4-4-4/6	Auto-SVC	1207	A	--
6	33302	55501	3-3-3/7	5-5-5/7	Auto-SVC	1207	A	--

These items must be provisioned in the database before an X.25 route can be added:

- A LIM assigned to the **ss7gx25** application – see [Adding an X.25 LIM](#) .
- An destination point code (DPC) assigned to the X.25 domain and a DPC assigned to the SS7 domain – see the "Adding a Destination Point Code" procedure in the *Database Administration Manual – SS7* .

**NOTE:** ITU international or ITU national point codes cannot be assigned to the X.25 domain.

- An X.25 destination – see [Adding an X.25 Gateway Destination](#)
- A linkset whose adjacent point code (APC) is in the X.25 domain – see [Adding an X.25 Linkset](#) procedure
- A signaling link assigned to a linkset containing an X.25 APC – see [Adding an X.25 Signaling Link](#)
- A route assigned to the linkset containing the X.25 APC – see the "Adding a Route Containing an X.25 DPC" procedure in the *Database Administration Manual – SS7* .

The X.25 gateway route to be added cannot already be in the database. The combination of the two X.25 addresses must be unique in the X.25 route table. The combination of point code/SSNs assigned to the two X.25 addresses must be unique in the X.25 route table. This can be verified with the **rtrv-x25-rte** command.

The point codes assigned to each of the X.25 destinations must also be assigned to a route. This can be verified with the **rtrv-rte** command.

The point codes assigned to each of the X.25 destinations must be a full point code. Cluster point codes and network routing point codes cannot be specified for X.25 destinations. For more information on cluster point codes, go to the "Cluster Routing and Management Diversity" section in the *Database Administration Manual – SS7*. For more information on network routing point codes, go to the "Network Routing" section in the *Database Administration Manual – SS7*.

Two new parameters have been added to the **ent-x25-rte** command, **rt** and **lc2nm**. The **rt** parameter defines the type of routing to perform on messages originating in the SS7 domain and destined for the X.25 domain. This parameter has two values, **xpc** and **pc**. The **rt=xpc** parameter routes the message based on the X.25 destination point code. The **rt=pc** parameter routes the message based on the X.25 origination and destination point code combination.

If the **rt=xpc** parameter is specified, the point code associated with the X.25 address used for this X.25 route cannot be in the X.25 route table. This can be verified with the **rtrv-x25-rte** command.

The X.25 network is connection oriented. All traffic from one node to another node uses one and only one logical channel. Once a logical channel is mapped to a pair of nodes, it cannot be used by any other pair of nodes.

When a logical channel on a particular X.25 route can no longer carry traffic between two nodes, the traffic between those two nodes can be rerouted to alternate routes with the logical channel to network management function and is specified by the **lc2nm** parameter. This function maps logical channel failures and recoveries to SS7 network management messages so that the alternate routing for the X.25 routes can be managed.

If the **lc2nm=yes** parameter is specified, then network management for logical channel failures and recoveries is performed. If the **lc2nm=no** parameter is specified, there is no network management for logical channel failures and recoveries.

If the X.25 route has the **lc2nm** parameter set to **yes**, and this X.25 route contains an X.25 destination whose X.25 destination point code is a member of a cluster, make sure that the **bei** parameter of the cluster containing the X.25 destination point code is set to **no**. Enter the **rtrv-x25-dstn** command to verify the destination point code that is assigned to the X.25 destination. Enter the **rtrv-dstn** command to verify that the X.25 destination point code is a member of a cluster and to verify the value of the **bei** parameter of the cluster. If the X.25 destination point code is not a member of a cluster, and you wish to use the **lc2nm=yes** parameter with the X.25 route, enter the **rtrv-dstn** command to verify that the value of the **bei** parameter for that X.25 destination point code is set to **no**. To change the existing value the **bei** parameter, go to the "Changing a Destination Point Code procedure in the *Database Administration Manual – SS7*. For more information on the interaction of X.25 destination point codes and clusters, go to the "Adding a Destination Point Code" procedure in the *Database Administration Manual – SS7*.

To specify the **lc2nm=yes** parameter, the **rt=xpc** parameter must be specified, and the point code that the message is to be routed on (**xpc**) cannot be an adjacent point code. This can be verified by first entering the **rtrv-x25-dstn** command to find the point code and X.25 address association, then the **rtrv-ls** command to display the linksets and the adjacent point codes they are assigned to. Any X.25 address that is associated with an adjacent point code, comparing the outputs of the **rtrv-x25-dstn** and **rtrv-ls** commands, cannot be used if the **ent-x25-rte** command specifies the **lc2nm=yes** parameter.

If the **lc2nm=yes** parameter is specified for the X.25 route in the linkset and the linkset has gateway screening associated with it, gateway screening must be configured to allow TFA and TFP network management messages

on this linkset to pass through the EAGLE 5 ISS. Go to the *Database Administration Manual - Gateway Screening* for details on how to create a screen that allows network management messages.

To allow TFA messages to pass through the EAGLE 5 ISS on this linkset, the allowed SIO screen must contain these parameters: si=0, h0=4, h1=5. To allow TFP messages to pass through the EAGLE 5 ISS on this linkset, the allowed SIO screen must contain these parameters: si=0, h0=4, h1=1. This can be verified with the **rtrv-scr-sio** command. If the allowed SIO screen that allows TFA and TFP messages is not in the database, go to the “Adding an Allowed SIO Screen” procedure in the *Database Administration Manual - Gateway Screening* to add the allowed SIO screen with these parameters. If the required allowed SIO screen does not contain the parameters to allow the TFA and TFP messages, go to the “Changing an Allowed SIO Screen” procedure in the *Database Administration Manual - Gateway Screening* to change the parameters of this allowed SIO screen.

## Procedure

1. Display the current X.25 route configuration using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 ADDR          TYPE LOC  PORT  LC  RT   LC2NM
2510010011234567 342342341234567  pvc 1201  a    02  xpc  yes
251001002         234234231        pvc 1201  a    04  pc   no
51200105         34223422845      svca 1202  a    --  pc   no
2510103          232330           pvc 1201  a    06  xpc  yes
2510103          232330           svcr ----  -    --  pc   no
2516019002       24247235         svca 3205  a    --  pc   no
345454           4545434         svca 1201  a    --  pc   no
X.25 ROUTE TABLE IS 30 % FULL
```

2. Add the X.25 route using the **ent-x25-rte** command.

For this example, enter these commands.

```
ent-x25-rte:xaddr=11101:saddr=44401:type=pvc:loc=1205:port=a:lc=1
```

```
ent-x25-rte:xaddr=11102:saddr=55501:type=pvc:loc=1206:port=a:lc=2
```

```
ent-x25-rte:xaddr=22201:saddr=44401:type=pvc:loc=1205:port=a:lc=2
```

```
ent-x25-rte:xaddr=22201:saddr=55501:type=pvc:loc=1206:port=a:lc=1
```

```
ent-x25-rte:xaddr=33301:saddr=44401:type=svca:loc=1207:port=a
```

```
ent-x25-rte:xaddr=33302:saddr=55502:type=svca:loc=1207:port=a
```

When each of these commands have successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
ENT-X25-RTE: MASP A - X.25 Route table 32% full
ENT-X25-RTE: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 ADDR          TYPE LOC  PORT  LC  RT   LC2NM
11101             44401             pvc 1205  a    01  pc   no
11102             55501             pvc 1206  a    02  pc   no
22201             44401             pvc 1205  a    02  pc   no
22202             55501             pvc 1206  a    01  pc   no
2510010011234567 342342341234567  pvc 1201  a    02  xpc  yes
251001002         234234231        pvc 1201  a    04  pc   no
2510103          232330           pvc 1201  a    06  xpc  yes
2510103          232330           svcr ----  -    --  pc   no
2516019002       24247235         svca 3205  a    --  pc   no
33301             44401             svca 1207  a    --  pc   no
```


```
33302          55501          svca 1207 a    -- pc  no
345454         4545434         svca 1201 a    -- pc  no
51200105      34223422845     svca 1202 a    -- pc  no
6389012       57982           pvc  1301 a    01 xpc yes
X.25 ROUTE TABLE IS 30 % FULL
```


4. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 2-11. Adding an X.25 Route





























## Removing an X.25 Route

This procedure is used to remove an X.25 route from the database using the **dlt-x25-rte** command.

The **dlt-x25-rte** command uses these parameters.

**:xaddr** – The X.25 address assigned to the X.25 destination entity on the X.25 side of the circuit.

**:saddr** – The dummy X.25 address assigned to the SS7 destination entity on the SS7 side of the circuit.

The examples in this procedure are used to remove the X.25 route with the X.25 address (**xaddr**) of 22202 and an SS7 address (**saddr**) of 55501.

The X.25 route to be removed must be in the database. This can be verified in step 1.

## Procedure

1. Display the current X.25 route configuration using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 ADDR          TYPE LOC  PORT  LC  RT   LC2NM
11101             44401             pvc 1205  a    01  pc   no
11102             55501             pvc 1206  a    02  pc   no
22201             44401             pvc 1205  a    02  pc   no
22202             55501             pvc 1206  a    01  pc   no
2510010011234567 342342341234567  pvc 1201  a    02  xpc  yes
251001002         234234231         pvc 1201  a    04  pc   no
2510103           232330            pvc 1201  a    06  xpc  yes
2510103           232330            svcr ----  -    --  pc   no
2516019002       24247235          svca 3205  a    --  pc   no
33301             44401             svca 1207  a    --  pc   no
33302             55501             svca 1207  a    --  pc   no
345454            4545434          svca 1201  a    --  pc   no
51200105         34223422845      svca 1202  a    --  pc   no
6389012          57982             pvc 1301  a    01  xpc  yes
X.25 ROUTE TABLE IS 30 % FULL
```

2. Remove the X.25 route using the **dlt-x25-rte** command.

For this example, enter this command.

```
dlt-x25-rte:xaddr=22202:saddr=55501
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
DLT-X25-RTE: MASP A - X.25 Route table 30% full
DLT-X25-RTE: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 ADDR          TYPE LOC  PORT  LC  RT   LC2NM
11101             44401             pvc 1205  a    01  pc   no
11102             55501             pvc 1206  a    02  pc   no
22201             44401             pvc 1205  a    02  pc   no
2510010011234567 342342341234567  pvc 1201  a    02  xpc  yes
251001002         234234231         pvc 1201  a    04  pc   no
2510103           232330            pvc 1201  a    06  xpc  yes
2510103           232330            svcr ----  -    --  pc   no
2516019002       24247235          svca 3205  a    --  pc   no
33301             44401             svca 1207  a    --  pc   no
33302             55501             svca 1207  a    --  pc   no
345454            4545434          svca 1201  a    --  pc   no
51200105         34223422845      svca 1202  a    --  pc   no
6389012          57982             pvc 1301  a    01  xpc  yes
X.25 ROUTE TABLE IS 30 % FULL
```

4. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

**Flowchart 2-12.** Removing an X.25 Route



## Changing an X.25 Route

This procedure is used to change the attributes of an X.25 route in the database using the **chg-x25-rte** command.

The **chg-x25-rte** command uses these parameters.

- :xaddr** – The X.25 address assigned to the X.25 destination entity on the X.25 side of the circuit.
- :saddr** – The alias X.25 address assigned to the SS7 destination entity on the SS7 side of the circuit.
- :type** – The type of X.25 connection that the link is expected to maintain.
- :loc** – The card location of the LIM containing the X.25 signaling link that maintains the connection.
- :port** – The signaling link on the card specified in the *loc* parameter. For an X.25 signaling link, this parameter value is A.
- :rt** – The type of routing to perform for messages originating in the SS7 domain and destined for the X.25 domain. Two types of routing are available: (1) route on X.25 destination point code (XPC) and (2) route using X.25 origination and destination point code combinations (PC).
- :lc2nm** – Invokes SS7 MTP network management for failures and recoveries of logical channels.

The examples in this procedure are used to change the attributes of the X.25 route with the X.25 address (**xaddr**) of 11102 and an SS7 address (**saddr**) of 55501. The new configuration of this X.25 route has a connection type of **svca**, no logical channel assignment, and is assigned to the X.25 signaling link on card 1215.

The X.25 route to be changed must be in the database. This can be verified in step 1.

The card location assigned to the X.25 route must be an X.25 card (card type **ss7x25g**). This can be verified with the **rtrv-card** command.

The signaling link assigned to the X.25 route must be in the database and must be assigned to a linkset. The linkset must be assigned to a route associated with an X.25 destination and must contain an APC in the X.25 domain. This can be verified by entering these commands:

- **rtrv-slk** – to display the signaling links
- **rtrv-ls** – to display the linksets
- **rtrv-rte** – to display the routes
- **rtrv-x25-dstn** – to display the X.25 destinations
- **rtrv-dstn** – to display the destination point codes.

If the **lc2nm=yes** parameter is specified with the **chg-x25-rte** command, the SS7 point code assigned to the X.25 address used by the **xaddr** parameter must be unique in the X.25 routing table.

The **rt=xpc** parameter must be specified with the **chg-x25-rte** command if the **lc2nm=yes** is specified.

If the X.25 destination is an adjacent entity, the **lc2nm=no** parameter must be specified with the **chg-x25-rte** command.

If the X.25 route has the **lc2nm** parameter set to **yes**, and this X.25 route contains an X.25 destination whose X.25 destination point code is a member of a cluster, make sure that the **bei** parameter of the cluster containing the X.25 destination point code is set to **no**. Enter the **rtrv-x25-dstn** command to verify the destination point code that is assigned to the X.25 destination. Enter the **rtrv-dstn** command to verify that the X.25 destination point code is a member of a cluster and to verify the value of the **bei** parameter of the cluster. If the X.25 destination point code is not a member of a cluster, and you wish to use the **lc2nm=yes** parameter with the X.25 route, enter the **rtrv-dstn** command to verify that the value of the **bei** parameter for that X.25 destination point code is set to **no**. To change the existing value the **bei** parameter, go to the "Changing a Destination Point Code" procedure in the *Database Administration Manual – SS7*. For more information on the interaction of X.25 destination point codes and clusters, go to the Adding a Destination Point Code procedure in the *Database Administration Manual – SS7*.

If the **lc2nm=yes** parameter is specified for the X.25 route in the linkset and the linkset has gateway screening associated with it, gateway screening must be configured to allow TFA and TFP network management messages on this linkset to pass through the EAGLE 5 ISS. Refer to the *Database Administration Manual - Gateway Screening* for details on how to create a screen that allows network management messages.

To allow TFA messages to pass through the EAGLE 5 ISS on this linkset, the allowed SIO screen must contain these parameters: si=0, h0=4, h1=5. To allow TFP messages to pass through the EAGLE 5 ISS on this linkset, the allowed SIO screen must contain these parameters: si=0, h0=4, h1=1. This can be verified with the **rtrv-scr-sio** command. If the allowed SIO screen that allows TFA and TFP messages is not in the database, go to the "Adding an Allowed SIO Screen" procedure in the *Database Administration Manual - Gateway Screening* to add the allowed SIO screen with these parameters. If the required allowed SIO screen does not contain the parameters to allow the TFA and TFP messages, go to the "Changing an Allowed SIO Screen" procedure in the *Database Administration Manual - Gateway Screening* to change the parameters of this allowed SIO screen.

## Procedure

1. Display the current X.25 route configuration using the **rtrv-x25-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR          SS7 ADDR          TYPE  LOC  PORT  LC  RT  LC2NM
```

```

11101          44401          pvc  1205  a    01  pc  no
11102          55501          pvc  1206  a    02  pc  no
22201          44401          pvc  1205  a    02  pc  no
22202          55501          pvc  1206  a    01  pc  no
2510010011234567 342342341234567 pvc  1201  a    02  xpc yes
251001002          234234231    pvc  1201  a    04  pc  no
2510103          232330          pvc  1201  a    06  xpc yes
2510103          232330          svcr  ----  -    --  pc  no
2516019002       24247235          svca  3205  a    --  pc  no
33301          44401          svca  1207  a    --  pc  no
33302          55501          svca  1207  a    --  pc  no
345454          4545434          svca  1201  a    --  pc  no
51200105          34223422845          svca  1202  a    --  pc  no
6389012          57982          pvc  1301  a    01  xpc yes
X.25 ROUTE TABLE IS 30 % FULL

```

2. Change the attributes of the X.25 route using the **chg-x25-rte** command.

For this example, enter this command.

```
chg-x25-rte:xaddr=11102:saddr=55501:type=svca:loc=1215:port=a
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
CHG-X25-RTE: MASP A - X.25 Route table 30% full
CHG-X25-RTE: MASP A - COMPLTD

```

3. Verify the changes using the **rtrv-x25-rte** command.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
X25 ADDR      SS7 ADDR      TYPE LOC  PORT  LC  RT  LC2NM
11101          44401          pvc  1205  a    01  pc  no
11102          55501          svca  1215  a    --  pc  no
22201          44401          pvc  1205  a    02  pc  no
22202          55501          pvc  1206  a    01  pc  no
2510010011234567 342342341234567 pvc  1201  a    02  xpc yes
251001002          234234231    pvc  1201  a    04  pc  no
2510103          232330          pvc  1201  a    06  xpc yes
2510103          232330          svcr  ----  -    --  pc  no
2516019002       24247235          svca  3205  a    --  pc  no
33301          44401          svca  1207  a    --  pc  no
33302          55501          svca  1207  a    --  pc  no
345454          4545434          svca  1201  a    --  pc  no
51200105          34223422845          svca  1202  a    --  pc  no
6389012          57982          pvc  1301  a    01  xpc yes
X.25 ROUTE TABLE IS 30 % FULL

```

4. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```


Flowchart 2-13. Changing an X.25 Route





























## Changing the X.25 Signaling Link Parameters

This procedure is used to change any of the X.25 signaling link parameters using the **chg-x25-slk** command.

The **chg-x25-slk** command uses these parameters.

**:loc** – The card location of the LIM containing the X.25 signaling link

- :port** – The signaling link on the card specified in the **loc** parameter. For an X.25 signaling link, this parameter value is A.
- :t1** – The amount of time to wait before retransmitting a frame.
- :n1** – The maximum number of bits in a frame.
- :n2** – The maximum number of retransmission attempts to complete a transmission.
- :k** – The maximum number of outstanding I frames.
- :l3mode** – The logical layer 3 address of the connection
- :pvc** – The total number of the permanent virtual circuits (PVCs) available on this X.25 signaling link.
- :svc** – The total number of the switched virtual circuits (SVCs) available on this X.25 signaling link.
- :win** – The number of packets allowed for a window on this X.25 signaling link.
- :mps** – The maximum packet size (in bytes) allowed on this X.25 signaling link.

The examples in this procedure are used to change the attributes of the X.25 signaling link assigned to card 1204.

The X.25 signaling link whose parameters are being changed must be in the database. This can be verified by entering the **rtrv-slk** command. The X.25 signaling links are shown by the dashes in the **L2TSET** column in the output.

### Procedure

1. Display the values of the X.25 signaling link you wish to change using the **rtrv-x25-slk** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC  PORT  T1  N1   N2  K  L3MODE  PVC  SVC  WIN  MPS
1201  A      10  2104 15  7  DCE     25  205  1   256
1202  A      9   2104 13  6  DTE    255  0   2   256
1203  A      8   1080 11  5  DCE     10  10  3   128
1204  A      7   1080 9   4  DTE     0   255  4   128
1205  A      6   2104 7   3  DCE    100  0   5   256
1206  A      5   2104 5   2  DTE     0   100  6   256
1207  A      4   1080 3   1  DCE    100  100  7   128
1208  A      5   2104 10  7  DTE     0   255  3   256
```

2. Deactivate the X.25 signaling link using the **dact-slk** command, using the card location and the signaling link.

For this example, enter this command.

```
dact-slk:loc=1204:link=a
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 36.0.0
Deactivate SLK message sent to card
```

3. Verify that the X.25 signaling link is out of service - maintenance (OOS-MT) using the **rept-stat-slk** command, using the card location and the signaling link.

For this example, enter this command.

```
rept-stat-slk:loc=1204:link=a
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 17:00:36 GMT EAGLE5 36.0.0
```

```

SLK      LSN      CLLI      PST      SST      AST
1204,A  nsp1     -----  OOS-MT   Unavail  ----
  ALARM STATUS      = * 0221 REPT-LKF: X25 link unavailable
  UNAVAIL REASON    = X25FL
Command Completed.

```

- Place the card assigned to the X.25 signaling link out of service using the **rmv-card** command, specifying the location of the card.

For this example, enter this command.

```
rmv-card:loc=1204
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 36.0.0
Card has been inhibited.

```

- Change the X.25 signaling link parameter values using the **chg-x25-slk** command.

For this example, enter this command.

```
chg-x25-
slk:loc=1204:port=a:t1=10:n1=2104:n2=4:k=7:l3mode=dce :pvc=5:svc=10:win
=2:mps=256
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 11:43:04 GMT EAGLE5 36.0.0
CHG-X25-SLK: MASP A - COMPLTD

```

- Verify the changes using the **rtrv-x25-slk** command, specifying the card location.

This is an example of the possible output.

```

rlghncxa03w 06-10-28 21:16:37 GMT EAGLE5 36.0.0
LOC  PORT  T1  N1    N2  K  L3MODE  PVC  SVC  WIN  MPS
1201  A      10  2104  15  7  DCE     25  205  1   256
1202  A      9   2104  13  6  DTE     255  0   2   256
1203  A      8   1080  11  5  DCE     10  10  3   128
1204  A      10  2104  4   7  DCE     5   10  2   256
1205  A      6   2104  7   3  DCE     100  0   5   256
1206  A      5   2104  5   2  DTE     0   100  6   256
1207  A      4   1080  3   1  DCE     100  100  7   128
1208  A      3   1080  5   2  DTE     1   1   6   128

```

- Place the card back into service using the **rst-card** command, specifying the location of the card.

For this example, enter this command.

```
rst-card:loc=1204
```

When this command has successfully completed, this message should appear.

```

rlghncxa03w 06-10-28 08:41:12 GMT EAGLE5 36.0.0
Card has been allowed.

```

- Activate the X.25 signaling link using the **act-slk** command, specifying the card location and the signaling link.

For this example, enter this command.

```
act-slk:loc=1204:link=a
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 08:31:24 GMT EAGLE5 36.0.0
Activate SLK message sent to card
```

9. Check the status of the X.25 signaling link using the **rept-stat-slk** command, specifying the card location and the signaling link.

The state of the X.25 signaling link should be in service normal (IS-NR) after the link has completed alignment (shown in the **PST** field). For this example, enter this command.

```
rept-stat-slk:loc=1204:link=a
```


This is an example of the possible output.

```
rlghncxa03w 06-10-28 17:00:36 GMT EAGLE5 36.0.0
SLK      LSN      CLLI      PST      SST      AST
1204,A  nsp1      -----  IS-NR    Avail    ----
  ALARM STATUS      = No alarm
  UNAVAIL REASON:
Command Completed.
```

10. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

**Flowchart 2-14.** Changing the X.25 Signaling Link Parameters

## Enabling the Large System # Links Controlled Feature

This procedure is used to enable the Large System # Links controlled feature using the feature's part number and a feature access key.

The feature access key for the Large System # Links controlled feature is based on the feature's part number and the serial number of the EAGLE 5 ISS, making the feature access key site-specific.

This feature allows the EAGLE 5 ISS to contain a maximum of either 1500 or 2000 signaling links.

The **enable-ctrl-feat** command enables the controlled feature by inputting the controlled feature's access key and the controlled feature's part number with these parameters:

**:fak** – The feature access key generated by Tekelec's feature access key generator, and supplied to you when you purchase or temporarily try a controlled feature. The feature access key contains 13 alphanumeric characters and is not case sensitive.

**:partnum** – The Tekelec-issued part number associated with the signaling link quantity being enabled:

- 893005901 for the 1500 signaling link quantity
- 893005910 for the 2000 signaling link quantity.

The **enable-ctrl-feat** command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the **rtrv-serial-num** command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, by using the **ent-serial-num** command. The **ent-serial-num** command uses these parameters.

**:serial** – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

**:lock** – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

**NOTE: To enter and lock the EAGLE 5 ISS's serial number, the ent-serial-num command must be entered twice, once to add the correct serial number to the database with the serial parameter, then again with the serial and the lock=yes parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).**

This feature cannot be temporarily enabled (with the temporary feature access key).

Once this feature is enabled with the **enable-ctrl-feat** command, the feature is also activated. The **chg-ctrl-feat** command is not necessary to activate the feature.

This feature cannot be disabled with the **chg-ctrl-feat** command and the **status=off** parameter.

#### Hardware Supported for Signaling Link Quantities Greater than 1500

The following hardware and applications are the only signaling link hardware and applications supported for an EAGLE 5 ISS containing more than 1500 signaling links.

- E1/T1 MIM running the **ccs7itu** application.
- HC-MIM running the **ccs7itu** application.
- E5-E1T1 card running the **ccs7itu** application.
- Single-slot EDCM running either the **iplimi** or **ipgwi** applications.
- E5-ENET card running either the **iplimi** or **ipgwi** applications.
- ATM high-speed LIM card running the **atmitu** application.

To increase the signaling link quantity to more than 1500 signaling links, HIPR cards must be installed into card locations 9 and 10 in each shelf in the EAGLE 5 ISS. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not HIPR cards are installed in the EAGLE 5 ISS shelves.

**Procedure**

1. Display the status of the Large System # Links controlled feature by entering the `rtrv-ctrl-feat` command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the `rtrv-ctrl-feat` output shows that the controlled feature is enabled for the desired quantity or for a quantity that is greater than the desired quantity, no further action is necessary. This procedure does not need to be performed.

**NOTE:** If the `rtrv-ctrl-feat` output in [Step 1](#) shows any controlled features, or if the Large System # Links controlled feature is enabled for a quantity that is less than the desired quantity, continue the procedure with [Step 6](#) . If the `rtrv-ctrl-feat` output shows only the HC-MIM SLK Capacity feature with a quantity of 64, [Step 2](#) through [Step 5](#) must be performed.

2. Display the serial number in the database with the `rtrv-serial-num` command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231
```

```
System serial number is not locked.
```

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

**NOTE:** If the serial number is correct and locked, continue the procedure with [Step 6](#) . If the serial number is correct but not locked, continue the procedure with [Step 5](#) . If the serial number is not correct, but is locked, this feature cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).

3. Enter the correct serial number into the database using the `ent-serial-num` command with the `serial` parameter.

For this example, enter this command.

**ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

4. Verify that the serial number entered into [Step 3](#) was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231

System serial number is not locked.

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat [Step 3](#) and [Step 4](#) and re-enter the correct serial number.

5. Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in [Step 2](#), if the serial number shown in [Step 2](#) is correct, or with the serial number shown in [Step 4](#), if the serial number was changed in [Step 3](#), and with the **lock=yes** parameter.

For this example, enter this command.

**ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

6. Verify that HIPR cards are installed in card locations 9 and 10 in each shelf of the EAGLE 5 ISS.

**NOTE: If the 2000 signaling link quantity is not being enabled in this procedure, continue the procedure with [Step 7](#).**

Enter this command.

**rept-stat-gpl:gpl=hipr**

This is an example of the possible output.

```
rlghncxa03w 06-10-01 11:40:26 GMT EAGLE5 36.0.0
GPL      CARD      RUNNING      APPROVED      TRIAL
HIPR     1109      126-002-000  126-002-000  126-003-000
HIPR     1110      126-002-000  126-002-000  126-003-000
HIPR     1209      126-002-000  126-002-000  126-003-000
HIPR     1210      126-002-000  126-002-000  126-003-000
HIPR     1309      126-002-000  126-002-000  126-003-000
HIPR     1310      126-002-000  126-002-000  126-003-000
HIPR     2109      126-002-000  126-002-000  126-003-000
HIPR     2110      126-002-000  126-002-000  126-003-000
Command Completed
```

If HIPR cards are installed in each the shelf in the EAGLE 5 ISS, continue the procedure with [Step 7](#).

If HIPR cards are not installed on each shelf in the EAGLE 5 ISS, go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, continue the procedure with [Step 7](#).

**NOTE:** Before the 2000 signaling link quantity is enabled, make sure the EAGLE 5 ISS is configured with the signaling link hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section.

If signaling hardware other than the hardware shown in the [“Hardware Supported for Signaling Link Quantities Greater than 1500”](#) section is installed and provisioned, contact the Customer Care Center before enabling the 2000 signaling link quantity. Refer to [Customer Care Center](#) for the contact information.

7. Enable the Large System # Links controlled feature for the desired quantity with the **enable-ctrl-feat** command specifying the part number corresponding to the new quantity of signaling links and the feature access key.

To increase the number of signaling links the EAGLE 5 ISS can contain to 1500, enter this command.

```
enable-ctrl-feat:partnum=893005901:fak=<feature access key>
```

To increase the number of signaling links the EAGLE 5 ISS can contain to 2000, enter this command.

```
enable-ctrl-feat:partnum=893005910:fak=<feature access key>
```

**NOTE:** A temporary feature access key cannot be specified to enable this feature.

**NOTE:** The values for the feature access key (the **fak** parameter) are provided by Tekelec. If you do not have the feature access key for the feature you wish to enable, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

8. Verify the changes by entering the **rtrv-ctrl-feat** command with the part number specified in [Step 7](#).

If the 1500 signaling link quantity was enabled in [Step 7](#), enter this command.

```
rtrv-ctrl-feat:partnum=893005901
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Large System # Links	893005901	on	1500

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the 2000 signaling link quantity was enabled in [Step 7](#), enter this command.

```
rtrv-ctrl-feat:partnum=893005910
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

The following features have been permanently enabled:

Feature Name	Partnum	Status	Quantity
Large System # Links	893005910	on	2000

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:


Feature Name	Partnum
Zero entries found.	


9. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 2-15. Enabling the Large System # Links Controlled Feature









## STPLAN Configuration

STPLAN Feature Overview .....	3-1
Message Sequencing .....	3-2
Message Format .....	3-2
TCP/IP Router .....	3-4
Hardware Requirements .....	3-7
Node Requirements .....	3-7
Gateway Screening .....	3-8
Congestion Management .....	3-9
STPLAN Provisioning .....	3-9
ACM-based or Mixed ACM- and DCM-Based Systems .....	3-10
Pure DCM-Based Systems .....	3-10
Understanding Firewall and Router Filtering .....	3-11
IP Addresses .....	3-11
Network Configuration Procedures .....	3-13
Adding an STPLAN Card .....	3-17
Removing an STPLAN Card .....	3-25
Adding a TCP/IP Data Link .....	3-29
Removing a TCP/IP Data Link .....	3-36
Adding a TCP/IP Node .....	3-39
Removing a TCP/IP Node .....	3-43

### STPLAN Feature Overview

The STPLAN feature provides a TCP/IP connection from any interface shelf to support external applications. Message signal units (MSUs) that are processed by the EAGLE 5 ISS can be copied and directed through the LAN interface to an external server or microcomputer application such as a usage measurements EAGLE 5 ISS. The gateway screening feature must be available on the STP in order to use the STPLAN feature.

The feature requires an STPLAN card, either the application communications module (ACM) running the **stplan** application, or database communications module (DCM) running the **stplan** application, or E5-SLAN card running the **stplan** application, which provides an ethernet interface at the backplane, as well as the processing power required to support TCP/IP message encapsulation.

The STPLAN card receives SS7 MSUs from the Interprocessor Message Transport (IMT) bus and copies the MSUs into memory resident on the STPLAN card. The EAGLE 5 ISS encapsulates the copied MSU into TCP/IP packets and sends the encapsulated message over the ethernet to the host computer or to a TCP/IP router. The host computer is responsible for assembling and processing the packets it receives. The TCP/IP router routes the messages to a host computer on another network.

Each STPLAN card has one ethernet port. The Transmission Control Protocol (TCP) and User Datagram Protocol (UDP) are supported at the transport layer. Internet Protocol (IP), Internet Control Message Protocol (ICMP) and Address Resolution Protocol (ARP) are supported at the network layer.

If the ACM is used as the STPLAN card, the EAGLE 5 ISS uses a special cable assembly for the ethernet connection, which is connected to an external media access unit (MAU). From the MAU, the customer can attach any compatible host EAGLE 5 ISS. The host system must be using TCP/IP as the higher layer protocol, and must support either 10base2 ethernet or 10baseT ethernet as the transmission method. The ACM's capacity is 435 transactions per second (TPS).

If the DCM is used as the STPLAN card, either 10baseT ethernet or 100baseT ethernet is supported by the EAGLE 5 ISS. The ethernet connection is made directly to the EAGLE 5 ISS backplane and no external media access unit (MAU) is used. The MAU is incorporated in the DCM. The DCM's capacity is 1200 TPS when configured to run on a 10baseT network, and 2500 TPS when configured for a 100baseT network.

If the E5-SLAN card is used as the STPLAN card, 10/100Mbps port data transfer rate is supported by the EAGLE 5 ISS. The E5-SLAN card has two ethernet interfaces. Each interface independently supports 10/100 Mbps data rates, full/half duplex, fixed/auto-negotiate, DIX/802.3 MAC header modes. The capacity of the E5-SLAN card is 1200 TPS when configured to run on a 10baseT network, or on a 100baseT network at half duplex, and 12000 TPS when configured for a 100baseT network at full duplex.

This implementation does not support standard TCP/IP protocols such as TELNET and FTP. However, it supports EAGLE 5 ISS applications that are built on TCP/IP using the Socket Application Programming Interface (API). The protocol stack is not biased toward any particular application.

## Message Sequencing

The STPLAN card adds a time stamp to the message before sending it to the LAN. The time stamp maintains a one second granularity and is synchronized with the host computer. This synchronization requires the host computer to be capable of responding to the time and date queries on the UDP port 37. The receiver can use the time stamp to provide sequencing within an application. The STPLAN application does not use sequence numbers for messages.

## Message Format


Because TCP/IP is a stream-oriented protocol, the host computer can receive multiple messages in a single packet, or the message can be divided among different packets. [Figure 3-1](#) shows an example of both. There are multiple MSUs in the first packet with one of the MSUs divided between the first packet and the second packet.

This list describes the fields used in these packets:

- STP/LAN Protocol Version (a 1-byte value) – The type of EAGLE 5 ISS message being carried from the LIMs to the STPLAN card. The only valid value for this field is 1.
- Time Stamp Type (a 1-byte value) – The type of timestamp that is being used in the message. The only valid value for this field is 1, indicating that the supported timestamp type is the UNIX style timestamp (a 32-bit number containing the time elapsed since 00:00:00 hour, January 1, 1970).

- MSU Count (a 1-byte value) – How many MSUs are actually contained in the packet.
- Total Length (a 2-byte value) – The total length, in bytes, of the data plus the MSU headers embedded inside the packet. This length should not be greater than 485 bytes.
- Port ID (a 2-byte value) – The ID of the port on the LIM which copied the data to the STPLAN card. The valid range for this field is 0–511.
- Timestamp (a 4-byte value) – The actual timestamp at which the message is sent out to the host.
- MSU Length (a 2-byte value) – The length of the actual MSU in bytes. The sum of the MSU lengths of all the MSUs in the packet plus the sum of the sizes of the single MSU headers should be equal to the number contained in the Total Length field.
- MSU – The MSU that is contained in the packet.


Figure 3-1. STPLAN Messages Embedded in TCP/IP Packets



## TCP/IP Router

A TCP/IP router is used to route STPLAN messages from the EAGLE 5 ISS to a remote host in another network or subnetwork. [Figure 3-2](#) shows an example of the STPLAN feature using a TCP/IP router.

Figure 3-2. STPLAN Network with a TCP/IP Router




**NOTE:** The term “STPLAN Card” used in [Figure 3-2](#) refers to either an ACM, DCM, or E5-SLAN card running the `stplan` application.

In this example, STPLAN cards 1 and 2, with IP addresses 193.4.202.50 and 193.4.202.57, need to route their traffic to the remote host at IP address 200.11.202.44. The STPLAN cards and the remote host are in two different networks; the network ID of the STPLAN cards is 193.4.202.67 and the network ID of the remote host is 200.11.202.44. The EAGLE 5 ISS can connect only to TCP/IP nodes that are in the same network as the EAGLE 5 ISS. To permit communication between the STPLAN cards and an external network, a TCP/IP router is placed in between the EAGLE 5 ISS and the remote host. The TCP/IP router is located in the same network as the EAGLE 5 ISS, with the IP address of 193.4.202.87. The messages can now be sent to the remote host through the TCP/IP router.

A TCP/IP default router must be entered into the database when the class and network ID of the data link’s IP address and host’s IP address do not match or when subnet routing is used. The TCP/IP router is entered into the database with the `ent-ip-node` command. The EAGLE 5 ISS cannot distinguish between a large network and the use of subnet routing, and cannot detect the omission of a TCP/IP router. In a large network, no TCP/IP routers are required because all the nodes are directly connected to a single ethernet. See [Figure 3-3](#) .


**Figure 3-3.** STPLAN in a Large Network



**NOTE:** The term “STPLAN Card” used in [Figure 3-3](#) refers to either an ACM, DCM, or E5-SLAN card running the `stp1an` application.

If a user is using subnet routing and as a result, multiple ethernets, TCP/IP routers are required and must be configured in the EAGLE 5 ISS. See [Figure 3-4](#) .

**Figure 3-4.** STPLAN Network with Subnet Routing



**NOTE:** The term “STPLAN Card” used in [Figure 3-4](#) refers to either an ACM, DCM, or E5-SLAN card running the `stp1an` application.

For the examples shown in [Figure 3-3](#) and [Figure 3-4](#) , the IP addresses of the TCP/IP data links and the remote node are the same. In [Figure 3-3](#) , the remote node is in the same network as the TCP/IP data links, so no TCP/IP router is needed. In [Figure 3-4](#) , the user is using subnet routing. The remote node is in one subnetwork, and the TCP/IP data links are in another subnetwork. Even though the network portion of the IP addresses of the TCP/IP data links and the remote node are the same (93, a class A IP address), a TCP/IP router is required because the user is using subnet routing.

If, when configuring STPLAN according to the network in [Figure 3-4](#) , the TCP/IP router is not configured with the `ent-ip-node` command, the EAGLE 5 ISS does not detect that the TCP/IP router has been omitted, and no warnings are given in this case. The EAGLE 5 ISS sees the remote node as a TCP/IP node in the same network as the TCP/IP data links, because of the class of the IP addresses, and does not require the user to specify the `iprte` parameter of the `ent-ip-node` command.

## Hardware Requirements

The hardware requirements and configuration include these items:

- The EAGLE 5 ISS supports up to 32 ACMs, DCMs, or E5-SLAN cards.
- Multiple ACM, DCM, or E5-SLAN cards can connect to each host on different ports. The assignment of the LIMs is done automatically by the EAGLE 5 ISS.
- The TSM and multiple LIM cards can also be used.
- For the ACM, the ethernet cable from the node terminates to an adapter (part number 830-0425-01) and a media access unit (P/N 804-0059-01 for 10base2 ethernet or P/N 804-0144-01 for 10baseT ethernet). Only the A port (the top port) of the ACM is used.
- For the DCM, one of two cables can be used to connect the DCM to the node, a straight-thru cable (P/N 830-0704-XX) or a transmit/receive cross-over cable (P/N 830-0728-XX). The cable from the node terminates directly to the backplane and does not use any adapters. The cable connects to port A (the top port) on the DCM.
- For the E5-SLAN card, one of the two cables can be used to connect the E5-SLAN card to the node, an existing cable used by SSEDCCM cards or a standard CAT-5 ethernet cable. The cable used by SSEDCCM cards requires a backplane cable adaptor (P/N 830-1103-02) to connect to the E5-SLAN card to the node. The CAT-5 ethernet cable requires a backplane cable adaptor (P/N 830-1102-02) to connect the E5-SLAN card to the node. The cable connects to port A0 on the PMC A ethernet card within the E5-SLAN card.

Refer to the *Hardware Manual - EAGLE 5 ISS* for more information about the ACM, DCM, or E5-SLAN card.

## Node Requirements

In order for a node to communicate with the ACM, DCM, or E5-SLAN card, you must configure the node system to perform or include these items:

- The node system must include an ethernet driver, TCP/IP protocol interface, and application software to process the incoming messages.
- The node TCP/IP protocol must be able to accept connections and supply an accurate time/date stamp over UDP port 37. (See RFC 868.)
- If multiple nodes are receiving data, the node application must be able to correlate related messages that are received on different nodes. Because of the load-balancing feature, the EAGLE 5 ISS cannot guarantee a constant LIM-to-node path.

## Gateway Screening

Gateway screening tables can be configured to screen messages for certain attributes. The screening process results in a message being accepted or rejected into the network. The criteria for message screening depends on the type of message received by the EAGLE 5 ISS, and the contents of the gateway screening tables.

You can send a copy of the message that has passed all of the screening criteria to a node. To stop the screening process and, at the same time, send a copy of the message to the STPLAN application, the next screening function identifier (**NSFI**) of the screen where the gateway screening process stops must be set to **stop**, and a gateway screening stop action set containing the **copy** gateway screening stop action must be assigned to that screen. The linkset containing the SS7 messages copied to the STPLAN application must have a gateway screening screenset assigned to it and the **gwsa** or **gwsn** parameter must be set to **on**.



**CAUTION:** When Gateway Screening is in the screen test mode, as defined by the linkset parameters **gwsa=off** and **gwsn=on**, the gateway screening action in the gateway screening stop action set specified by the **actname** parameter of the gateway screening screen set at the end of the gateway screening process will be performed.

Gateway screening functions are defined using screening tables or screensets which contain a set of rules. Each screenset is uniquely identified by a screenset name. A screenset is a collection of screening references or rules, each assigned a unique screening reference name. Each screening reference belongs to a specific category, which indicates the criteria that is used to either accept or reject an incoming MSU. For example, the category “blkopc” rejects all MSUs with the OPCs specified in the screening reference.

The screening parameters (point codes, routing indicator, subsystem number, and so forth) are used to match information in the SS7 message.

Each group of screening references is referred to as a screen set and is identified by a particular screen set name (**SCRN**). The screen set can then be applied to a particular linkset. This allows, for example, for specific OPCs with particular SIOs and DPCs to be allowed into the network.

There are two basic functions, allow and block. In an allowed screen (for example, allowed DPC), if a match is found and the next screening function identifier (**nsfi**) is equal to anything but **stop**, the next screening reference (**nsr**) is identified and the screening process continues. If the next screening function identifier is **stop**, the message is processed and no further screening takes place. If no match is found, the message is rejected. If the next screening function identifier is **stop** and a gateway screening stop action set that contains the **copy** gateway screening stop action is assigned to the screen, the EAGLE 5 ISS sends a copy of the message to the STPLAN application.

In a blocked screen (for example, blocked DPC):

**Table 3-1. Gateway Screening Action**

If...	then...
a match is found and the next screening function identifier is <b>fail</b> ,	the message is rejected and no further screening takes place.
no match is found and the next screening function identifier is equal to anything but <b>stop</b> ,	the next screening reference is identified and the screening process continues.
the next screening function identifier is equal to <b>stop</b> ,	the message is processed and no further screening takes place.
the next screening function identifier is equal to <b>stop</b> and a gateway screening stop action containing	the message is processed and the EAGLE 5 ISS sends a copy of the message to the STPLAN application.

If...	then...
the copy gateway screening stop action is assigned to the screen	

The allowed OPC and DPC screens are useful in the gateway screening process when specifying particular sets of point codes that are allowed to send or receive messages to or from another network. The blocked OPC and DPC screens are useful in the gateway screening process to specify particular sets of point codes that are not allowed to send or receive messages to or from another network.

### Congestion Management

If a message reaches the outbound “stop and copy” phase of the gateway screening process, and the LIM that is designated to transmit a copy of the message to the node is congested, the copy of the message is not transmitted to the node. The STP disables the application only on the particular LIM that is experiencing congestion.

Conversely, a message may arrive on an inbound LIM that is in danger of congestion while the outbound LIM is not in danger of congestion. As the message was not screened on the inbound LIM, it is not marked to be copied to the STPLAN card.

Go to the *Database Administration Manual - Gateway Screening* for information on configuring gateway screening entities.

## STPLAN Provisioning

The STPLAN application allows the user to selectively copy outbound messages to a remote node for further processing. The messages that are copied to the remote node are actually selected for copying on the inbound linkset by the Gateway Screening feature. The messages that pass the screening criteria set for that linkset are processed by the EAGLE 5 ISS, and are copied prior to being transmitted on the outbound link.

The external connection to the remote node consists of several ACMs or DCMs equipped with Ethernet interfaces using the TCP/IP protocol to communicate to an external processing device running software that receives and processes the messages. Each ACM or DCM card (or STPLAN card) supports a single remote destination node. Each STPLAN card may also support a single default router.

On the EAGLE 5 ISS, the LAN interface is implemented through a pool of STPLAN cards. For reliability, STPLAN cards are provisioned on an “N+1” redundancy basis so that in case of failure of one such card, performance can be maintained during the time required to replace it. Furthermore, the calculations assume that a typical LIM card carries 0.8 Erlang worth of traffic, which would be the case if cards normally carry 0.4 Erlang and a failover situation occurs. Thus, the equations yield a number of STPLAN cards calculated to accommodate worst case traffic situations.

STPLAN cards are provisioned per site based on the total number of cards in the EAGLE 5 ISS which require STPLAN service.

ACM cards and a DCM card are capable of supporting different traffic loads. Systems which are ACM-based, or which contain both ACM- and DCM-based STPLAN cards, must use the first set of provisioning rules. Systems which are purely DCM-based must use the second set of provisioning rules.

To determine the number of STPLAN cards required in a particular site, the following quantities must be determined first.

- LSL = the number of low-speed links in the system

- HSL = the number of high-speed LIM ATMs links in the system
- SE-HSL = the number of high-speed SE-HSL LIM links in the system
- KTPS = the number of thousands of packets per second that IPLIM/IPGWY cards will handle, e.g.: 2 for 2,000 TPS, 4 for 4,000 TPS, etc.
- The estimated average size of MSUs flowing though the system ( such as 80 octets per MSU).

### ACM-based or Mixed ACM- and DCM-Based Systems

When the average MSU size is 80 octets or less, use this equation:

$$N = \text{roundup}(\text{LSL}/28 + \text{HSL}/3 + \text{KTPS}/2 + \text{SE-HSL} + 1)$$

When the average MSU size is 140 octets, use this equation:

$$N = \text{roundup}(\text{LSL}/28 + \text{HSL}/3 + \text{KTPS}/1.5 + \text{SE-HSL} + 1)$$

When the average MSU size is 272 octets, use this equation:

$$N = \text{roundup}(\text{LSL}/18 + \text{HSL}/2 + \text{KTPS}/0.4 + \text{SE-HSL}/0.6 + 1)$$

For example, if an EAGLE 5 ISS were equipped with 200 low-speed LIMs, 13 high-speed ATM LIMs or DCMs, and the average MSU size is 140 octets, the following calculations would be used to determine N+1.

$$(200 \text{ LSL}/28 + 13 \text{ HSL}/3 + 0 \text{ KTPS}/1.5 + 0 \text{ SE-HSL} + 1) = 12.5$$

This would be rounded up to 13 STPLAN cards.

This EAGLE 5 ISS would require 13 STPLAN cards.

If the rate of low-speed LIM traffic per second to be transferred to the STPLAN application is some value other than .4 Erlang, then that portion of the equation may be scaled accordingly.

For example, one card's worth of traffic @ 0.4 Erlang equals the capacity of two cards worth of traffic @ 0.2 Erlang and the number of STPLAN cards could be halved.

### Pure DCM-Based Systems

The equations below assume a 100baseT ethernet network which allows for a DCM capacity of 2,500 TPS or SLAN packets per second.

When the average MSU size is 80 octets or less, use this equation:

$$N = \text{roundup}(\text{LSL}/165 + \text{HSL}/18 + \text{KTPS}/12 + \text{SE-HSL}/6 + 1)$$

When the average MSU size is 140 octets, use this equation:

$$N = \text{roundup}(\text{LSL}/165 + \text{HSL}/19 + \text{KTPS}/7 + \text{SE-HSL}/5 + 1)$$

When the average MSU size is 272 octets, use this equation:

$$N = \text{roundup}(\text{LSL}/110 + \text{HSL}/12 + \text{KTPS}/2 + \text{SE-HSL}/4 + 1)$$

For example, if an EAGLE 5 ISS were equipped with 200 low-speed LIMs, 13 high-speed ATM LIMs, and the average MSU size is 140 octets, the following calculations would be used to determine N+1.

$$(200 \text{ LSL}/165 + 13 \text{ HSL}/19 + 0 \text{ KTPS}/7 + 0 \text{ SE-HSL}/5 + 1) = 2.9$$

This would be rounded up to 3 STPLAN cards.

This EAGLE 5 ISS would require 3 STPLAN cards.

If the rate of low-speed LIM traffic per second to be transferred to the STPLAN application is some value other than .4 Erlang, then that portion of the equation may be scaled accordingly.

For example, one card's worth of traffic @ 0.4 Erlang equals the capacity of two cards worth of traffic @ 0.2 Erlang and the number of STPLAN cards could be halved.

## Understanding Firewall and Router Filtering

Firewall protocol filtering for the interface between the EAGLE 5 ISS's DCM or E5-SLAN card and the host computer is defined in [Table 3-2](#).

**Table 3-2. VXWSLAN External Ports and Their Use**

Interface	TCP/IP Port	Use	Inbound	Outbound
10BASE-TX or 100BASE-TX	1024 to 5000 <sup>1</sup>	STPLAN Traffic	Yes	Yes
	7	UDP Echo (ping)	Yes	Yes
	37	Time/Date	Yes	Yes
	N/A	ARP (Address Resolution Protocol) <sup>2</sup>	Yes	Yes

1. The TCP/IP port is the port number configured with the **ipport** parameter of the **ent-ip-node** command. The value of the **ipport** parameter is shown in the **IPPORT** field of the **rtv-ip-node** command output. The values for this parameter are in the range 1024–5000.

2. ARP is used to provide TCP communication. The customer network will provide this information as appropriate.

The VXWSLAN application requires a data pipe of 10 or 100 Mb. The actual percentage of SLAN transactions that is used (the maximum) is defined by the **cap** parameter of the **ent-ip-node** command. There can be more than one connection from the EAGLE 5 ISS to the node defined by the **ipaddr** (the node's IP address) parameter of the **ent-ip-node** command.

## IP Addresses

An IP address contains 32 bits grouped into four segments or octets. Each octet contains eight bits. The range of values for an octet is from 0 (all bits in the octet are 0) to 255 (all bits in the octet are 1). The four octets of an IP address are grouped into three different identifiers: the class ID, the network number and the host number. The value in the class ID determines how the rest of the bits in the ip address are categorized, mainly into the network number and the host number. The value of the class ID are in the first octet. If the first bit in the first octet is 0, the IP address is a class A IP address. If the first two bits in the first octet are 1 and 0, the IP address is a class B IP address. If the first three bits in the first octet are 1, 1, and 0, the IP address is a class C IP address. There are class D and E IP addresses, but these classes of IP addresses are not supported by the EAGLE 5 ISS. The loopback IP addresses (127.\*.\*) are not supported by ACM cards in the EAGLE 5 ISS. Loopback, however, is supported by DCM and E5-SLAN cards..

The network number of the IP address is the part of an IP address that identify the network that the host belongs to. The octets that make up the network number depend on the class of the IP address. For class A IP addresses, the network number is the bits in the first octet minus the class ID bits (the first bit of the first octet). For class B IP addresses, the network number is the bits in the first octet minus the class ID bits (the first two bits of the first

octet) plus the bits in the second octet. For class C IP addresses, the network number is the bits in the first octet minus the class ID bits (the first three bits in the first octet) plus the bits in the second and third octets.

The host number of an IP address is the part of an IP address that identify a specific host on a network. The host number contains all the bits that do not belong to the class ID or the network number. For class A IP addresses, the host number contains all the bits in the second, third and fourth octets. For class B IP addresses, the host number contains all the bits in the third and fourth octets. For class C IP addresses, the host number contains all the bits in the fourth octet.


[Table 3-3](#) summarizes the IP address values for the classes of IP addresses. [Figure 3-5](#) illustrates the different parts of the IP addresses in each class of IP addresses.

**Table 3-3. Values of IP Addresses**

IP Address Class	IP Address Format	Class ID Bits	Range of IP Address Values
A	N.H.H.H	0	1.0.0.1 to 126.255.255.254
B	N.N.H.H	1, 0	128.1.0.1 to 191.254.255.254
C	N.N.N.H	1, 1, 0	192.0.1.1 to 223.255.254.254

N = Network Number, H = Host Number

**Figure 3-5. IP Address Bit Categorization**



The EAGLE 5 ISS does not allow IP addresses to be entered that contain an invalid class ID, network number or host number. Valid class ID values are shown in [Table 3-3](#). Valid network numbers and host numbers cannot contain all 0 bits or all 1 bits. For example, the class A IP address 10.0.0.0 is invalid because it contains a host number of '0.0.0'. A class B IP address of 128.0.10.5 is also invalid because the network number is '0.0' (remember the network number for a class B address is the bits in the first octet minus the class ID bits). The class C IP address of 192.0.1.255 is also invalid because it contains a host number of '255' (all ones). One of the error codes shown in [Table 3-4](#) will be generated when an invalid IP address is entered.

**Table 3-4. Invalid IP Address Error Codes**

Error Code	Error Message
E2028	Octet 1 is out of range, 1..223
E2071	Network Number Invalid
E2072	Host Number Invalid
E2070	IP Address invalid for Address Class


## Network Configuration Procedures

To support the STPLAN feature, you must configure these database elements that are specific to the STPLAN feature.

- ACM, DCM, or E5-SLAN card
- TCP/IP Data Link
- IP Node

When the EAGLE 5 ISS is booted, each module gets the configuration information from the database. [Figure 3-6](#) shows the database elements that must be configured, and the order in which they should be configured.

Figure 3-6. STPLAN Database Relationships



These procedures use a variety of commands. If you need more information on these commands, refer to the *Commands Manual* to find the required information.

This list describes the database entities (shown in [Figure 3-6](#)) that must be configured for the STPLAN feature.

1. The STPLAN and gateway screening features must be turned on. Verify that these features are turned on with the **rtrv-feat** command. If either of these features are not on, shown with the entries **GWS = off** (if the gateway screening feature is off), and **LAN = off** (if the STPLAN feature is off), in the **rtrv-feat** command output, enter the **chg-feat:gws=on** command to turn on the gateway screening feature, and the **chg-feat:lan=on** command to turn on the STPLAN feature.

**NOTE: Once the gateway screening and STPLAN features are turned on with the chg-feat command, they cannot be turned off.**

2. Make sure that the required shelf is in the database with the **rtrv-shlf** command. If it is not in the database, add it with the **ent-shlf** command.
3. Make sure the cards that the TCP/IP data links will be assigned to are in the database with the **rtrv-card** command. These cards can be either ACMs (card type **acmenet**) or DCMs (card type **dcn**), or E5-SLAN card (card type **dcn**). The ACM, DCM, or E5-SLAN card must have the **stplan** application

assigned to it. If these cards are not in the database, add them with the **ent-card** command, specifying an ACM with the **type=acmenet** and **appl=stplan** parameters, or a DCM or E5-SLAN card with the **type=dcm** and **appl=stplan** parameters.

4. The TCP/IP data links needed by the STPLAN feature must be in the database. Verify this by entering the **rtrv-dlk** command. If the necessary TCP/IP data links are not in the database, add them with the **ent-dlk** command. Make sure that the card location specified in the **ent-dlk** command is an ACM, DCM, or E5-SLAN card shown in step 3. If the card is a DCM, you must also select the speed of 10 (default) or 100. If the card is an E5-SLAN card, you must also select the speed of 10 (default) or 100.
5. The TCP/IP nodes used by the STPLAN feature must be in the database. Verify this by entering the **rtrv-ip-node** command. If the necessary TCP/IP nodes are not in the database, add them with the **ent-ip-node** command with a card location assigned to a TCP/IP data link shown in step 4.
6. The GLS card must be provisioned and installed to be able to load cards' screen-set
7. The STPLAN feature uses gateway screening to select the messages that are copied and sent to the STPLAN application on an ACM, DCM, or E5-SLAN card. A gateway screening stop action set containing the **COPY** gateway screening stop action must be assigned to the gateway screening entity where the gateway screening process stops (the NSFI of the screen is STOP). Enter the **rtrv-gws-actset** command to display the gateway screening stop action sets in the database. The database contains at least two gateway screening stop actions sets that contain the **COPY** gateway screening stop action as shown in bold in the example output. These gateway screening stop actions are always in the database and cannot be changed or removed.

```
rlghncxa03w 06-10-20 21:16:37 GMT EAGLE5 36.0.0
ACT  ACT      ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT
ID   NAME     1    2    3    4    5    6    7    8    9    10
--   -
1    copy     copy
2    rdct     rdct
3    cr       copy rdct
GWS action set table is (3 of 16) 19% full
```

8. Verify that the necessary gateway screening entities have been configured with the required gateway screening stop action set, by entering the appropriate gateway screening retrieve command specifying the **actname** parameter with the gateway screening stop action name shown in the **rtrv-gws-actset** command output.

```
rtrv-scrset:actname=copy
```

```
rtrv-scr-opc:actname=copy
```

```
rtrv-scr-blkopc:actname=copy
```

```
rtrv-scr-sio:actname=copy
```

```
rtrv-scr-dpc:actname=copy
```

```
rtrv-scr-blkdpc:actname=copy
```

```
rtrv-scr-destfld:actname=copy
```

```
rtrv-scr-cgpa:actname=copy
```

```
rtrv-scr-tt:actname=copy
```

```
rtrv-scr-cdpa:actname=copy
```

```
rtrv-scr-aftpc:actname=copy
```

```
rtrv-scr-isup:actname=copy
```

If a gateway screening entity is configured to copy messages to an STPLAN application, the entry **STOP** appears in the **NSFI** field and the **NSR/ACT** field contains the name of the gateway screening stop action set specified in the gateway screening retrieve command (see the following example).

```
rlghncxa03w 06-10-20 21:17:37 GMT EAGLE5 36.0.0
SCREEN = ALLOWED OPC
SR   NI       NC       NCM       NSFI       NSR/ACT
opc1 010       010       010       STOP       COPY
opc1 010       010       012       STOP       COPY
```

If the desired gateway screening entity is not configured to copy messages to the STPLAN application, configure these entities to copy messages to the STPLAN application. Go to the *Database Administration Manual - Gateway Screening* for information on configuring gateway screening entities.

9. The linkset containing the messages copied for the STPLAN application must have a gateway screening assigned to it. Either the **gwsa** or **gwsn** parameters of the linkset must be set to **on**. Verify this with the **rtrv-ls** command. If the desired linkset does not have a gateway screening assigned to it, shown in the **SCRN** field of the **rtrv-ls** output, or the **GWSA** or **GWSM** field is set to **off**, refer to either [Changing an X.25 Linkset](#) or to the Changing an SS7 Linkset procedure in the *Database Administration Manual - SS7* and change the **scrn**, **gwsa**, and **gwsn** parameters of the desired linkset.




**CAUTION:** When Gateway Screening is in the screen test mode, as defined by the linkset parameters **gwsa=off** and **gwsn=on**, the gateway screening action in the gateway screening stop action set specified by the **actname** parameter of the gateway screening screen set at the end of the gateway screening process will be performed.

The STPLAN configuration procedures in this chapter use the sample network information shown in [Table 3-5](#) . [Figure 3-7](#) shows a diagram of this sample network.

**Table 3-5. STPLAN Configuration Example Database**

Card Location	Interface Address	TCP/IP Router Address	STPLAN Node Address	STPLAN Port ID
1103	193.4.201.34	—	193.4.201.70	1024
1104	193.4.201.35	—	193.4.201.71	1024
1201	193.4.201.30	—	193.4.201.50	1024
1203	193.4.201.31	—	193.4.201.51	1024
1204	193.4.202.39	193.4.202.30	200.50.100.47	2000
1205	193.4.202.32	—	193.4.201.50	3000
1206	197.4.217.39	197.4.217.47	203.14.212.30	4000
1207	194.5.198.74	—	194.5.198.34	4000

Figure 3-7. STPLAN Configuration Example



## Adding an STPLAN Card

This procedure is used to add a card supporting the STPLAN feature, either a DCM, ACM, or E5-SLAN card running the `stplan` to the database using the `ent-card` command. The `ent-card` command uses these parameters:

**:loc** – The location of the card being added to the database.

**:type** – The type of card being added to the database. For this procedure, the value of this parameter is either `dcm` (for the dual-slot DCM or single-slot EDCM) or `acmenet` (for the ACM).

**:appl** – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is `vxslan` (for the GPL assigned to the dual-slot DCM or single-slot EDCM) or `stplan` (for the GPL assigned to the ACM).

**:force** – Allow the LIM to be added to the database even if there are not enough cards running the SCCP or VSCCP GPLs to support the number of LIMs. This parameter is obsolete and is no longer used.

The STPLAN card part numbers are shown in [Table 3-6](#) .

**Table 3-6. STPLAN Card Part Numbers**

Card Type	Card Name (as shown on the card label)	TYPE Parameter Value	Part Number
ACM	ACM-ENET	acmenet	870-1008-XX
Dual-Slot DCM	DCM	dcm	870-1945-XX 870-1984-01
Single-Slot EDCM	DCM	dcm	870-2372-01
	EDCM-A	dcm	870-2508-XX
E5-SLAN Card	E5-ENET	dcm	870-2212-02

The dual-slot DCM can be inserted only in the odd numbered card slots of the extension shelf. Slot 09 of each shelf contains the HMUX card or HIPR card, thus the DCM cannot be inserted in slot 09. The dual-slot DCM can be inserted in the control shelf, but only in slots 01, 03, 05, and 07. The dual-slot DCM occupies two card slots, so the even numbered card slot adjacent to the odd numbered slot where the dual-slot DCM has been inserted must be empty, as shown in [Table 3-7](#) . The dual-slot DCM is connected to the network through the odd numbered card slot connector.

**Table 3-7. DCM Card Locations**

Location of the DCM	Empty Card Location	Location of the DCM	Empty Card Location
Slot 01	Slot 02	Slot 11	Slot 12
Slot 03	Slot 04	Slot 13	Slot 14
Slot 05	Slot 06	Slot 15	Slot 16
Slot 07	Slot 08	Slot 17	Slot 18

Before the card can be configured in the database for the STPLAN feature, the STPLAN and gateway screening features must be turned on with the **chg-feat** command. The gateway screening feature must be on before the STPLAN feature can be turned on. The **rtrv-feat** command can verify that the STPLAN, and gateway screening features are on.

**NOTE: Once the Gateway Screening and STPLAN features are turned on with the chg-feat command, they cannot be turned off.**

**NOTE: Verify the temperature threshold settings for the E5-SLAN card by performing the “Changing the High-Capacity Card Temperature Alarm Thresholds” procedure in the Database Administration Manual-SS7.**

The shelf to which the card is to be added must already be in the database. This can be verified with the **rtrv-shlf** command. If the shelf is not in the database, see the "Adding a Shelf" procedure in the *Database Administration Manual – System Management*.

The card cannot be added to the database if the specified card location already has a card assigned to it.

### STPLAN Card Provisioning

The following rules apply to provisioning STPLAN cards:

- A minimum of two STPLAN cards must be provisioned in an EAGLE 5 ISS.
- A maximum of 32 STPLAN cards can be provisioned in an EAGLE 5 ISS.
- For shelves containing HMUX cards, the following rules apply to provisioning STPLAN cards.
  - If the shelf containing the STPLAN cards (only ACMs or DCMs, but not E5-SLAN cards) has HMUX cards installed in card slots 9 and 10, the shelf can contain a maximum of three STPLAN cards.
  - The STPLAN cards should be provisioned in shelves adjacent to the shelf containing the cards being monitored - half of the STPLAN cards should be provisioned in the next shelf and the other half of the STPLAN cards should be provisioned in the previous shelf. For example, if the shelf generating the STPLAN traffic is shelf 2100, half of the STPLAN cards should be provisioned in shelf 1300 and the other half of the STPLAN cards should be provisioned in shelf 2200.
- For shelves containing HIPR cards, the STPLAN cards should be provisioned in the same shelves that contain HIPR cards. There is no limit on the number of STPLAN cards that can be provisioned on shelves containing HIPR cards.
- The E5-SLAN card requires that HIPR cards are installed in the card locations 9 and 10 in the shelf that will contain the E5-SLAN card. If HIPR cards are not installed in the shelf that the E5-SLAN card will occupy, the E5-SLAN card will be auto-inhibited when the E5-SLAN card is inserted into the shelf. Enter the **rept-stat-gpl:gpl=hipr** command to verify whether or not **HIPR** cards are installed in the same shelf as the **E5-SLAN** card being provisioned in this procedure.

**NOTE: Contact your Tekelec Sales Representative or Account Representative to determine the number of STPLAN cards that must be provisioned in your EAGLE 5 ISS, and to determine where in the EAGLE 5 ISS these STPLAN cards must be provisioned before performing this procedure.**

The examples in this procedure are used to add a DCM in card slot 1201 and an ACM in card slot 1204 to the database, and an E5-SLAN card in card slot 1207.

## Procedure

1. Display the cards in the EAGLE 5 ISS using the **rtrv-card** command.

Cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution. This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:58:31 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101  TSM           SCCP
1102  TSM           GLS
1103  ACMENET      STPLAN
1104  ACMENET      STPLAN
1113  GPSM         EOAM
1114  TDM-A
1115  GPSM         EOAM
1116  TDM-B
1117  MDAL
1203  ACMENET      STPLAN
1205  ACMENET      STPLAN
1206  ACMENET      STPLAN
1211  LIMDS0       SS7ANSI   lsn1           A      0      lsn2           B      1
1212  LIMV35       SS7GX25   lsn1           A      0
1213  LIMV35       SS7ANSI   lsn2           A      0      lsn1           B      1
1216  LIMDS0       SS7ANSI   sp2            A      0      sp1            B      0
1303  LIMDS0       SS7ANSI   sp3            A      0
```

1304	LIMDS0	SS7ANSI	sp3	A	1			
1306	LIMDS0	SS7ANSI	nsp3	A	1	nsp4	B	1
1307	LIMV35	SS7GX25	nsp1	A	0			
1308	LIMV35	SS7GX25	nsp1	A	1			

If the **APPL** field of the **rtrv-card** command output shows cards assigned to the **STPLAN** application, skip steps 2, 3, and 4, and go to step 5.

- Verify that the STPLAN and the gateway screening features are on, by entering the **rtrv-feat** command. If the STPLAN feature is on, the **LAN** field should be set to **on**. If the gateway screening feature is on, the **GWS** field should be set to **on**. For this example, the STPLAN and gateway screening features are off.

**NOTE: The rtrv-feat command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the rtrv-feat command, see the rtrv-feat command description in the Commands Manual.**

If the gateway screening and STPLAN features are on, skip steps 3 and 4 and go to step 5. If the gateway screening feature is not on, go to step 3. If the gateway screening feature is on, but the STPLAN feature is off, skip step 3 and go to step 4.

- If the gateway screening feature is not on, shown by the **GWS = off** entry in the **rtrv-feat** command output in step 2, turn the gateway screening feature on by entering this command.

**chg-feat:gws=on**

**NOTE: Once the gateway screening feature is turned on with the chg-feat command, it cannot be turned off.**

When the **chg-feat** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

- Turn the STPLAN feature on by entering this command.

**chg-feat:lan=on**

**NOTE: Once the STPLAN feature is turned on with the chg-feat command, it cannot be turned off.**

When the **chg-feat** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:19:37 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

- Verify that the card has been physically installed into the proper location.



**CAUTION: If the versions of the flash GPLs on the STPLAN card does not match the flash GPL versions in the database when the STPLAN is inserted into the card slot, UAM 0002 is generated indicating that these GPL versions do not match. If UAM 0002 has been generated, perform the alarm clearing procedure for UAM 0002 in the Maintenance Manual before proceeding with this procedure.**

**NOTE: Skip step 6 and go to step 7 if you do not want to enter an E5-SLAN card.**

- Verify whether HIPR cards are installed in the same shelf as the E5-SLAN card to be provisioned using the **rept-stat-gpl:gpl=hipr** command.

```
rlghncxa03w 07-02-01 11:40:26 GMT EAGLE5 37.0.0
GPL      CARD      RUNNING      APPROVED      TRIAL
HIPR     1109     126-002-000 126-002-000 126-003-000
HIPR     1110     126-002-000 126-002-000 126-003-000
HIPR     1209     126-002-000 126-002-000 126-003-000
HIPR     1210     126-002-000 126-002-000 126-003-000
```

```

HIPR 1309 126-002-000 126-002-000 126-003-000
HIPR 1310 126-002-000 126-002-000 126-003-000
HIPR 2109 126-002-000 126-002-000 126-003-000
HIPR 2110 126-002-000 126-002-000 126-003-000
Command Completed

```

If HIPR cards are installed in the shelf containing the E5-SLAN card, go to step 7.

If HIPR cards are not installed at the card locations 9 and 10 on the shelf where the E5-SLAN card is to be installed, refer to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 7.

7. Add the card to the database using the **ent-card** command.

For this example, enter these commands.

```
ent-card:loc=1201:type=dcm:appl=vwxslan
```

```
ent-card:loc=1204:type=acmenet:appl=stplan
```

```
ent-card:loc=1207:type=dcm:appl=stplan
```

When each of these commands has successfully completed, this message should appear.

```

rlghncxa03w 06-10-20 21:21:37 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD

```

8. Verify the changes using the **rtrv-card** command with the card location specified.

For this example, enter these commands.

```
rtrv-card:loc=1201
```

This is an example of the possible output.

```

rlghncxa03w 06-10-20 21:22:37 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1201  DCM          VWXSLAN

```

```
rtrv-card:loc=1204
```

This is an example of the possible output.

```

rlghncxa03w 06-10-20 21:23:37 GMT EAGLE5 36.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1204  ACMENET      STPLAN

```

```
rtrv-card:loc=1207
```

```

rlghncxa03w 06-08-20 21:22:37 GMT EAGLE5 37.0.0
CARD  TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1207  DCM          STPLAN

```

9. Backup the new changes, using the **chg-db:action=backup:dest=fixed** command.


These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Flowchart 3-1. Adding an STPLAN Card







## Removing an STPLAN Card

This procedure is used to remove a card supporting the STPLAN feature, either an ACM, DCM, or E5-SLAN card running the **stplan** application, from the database using the **dlt-card** command.

The card cannot be removed if it does not exist in the database.

No TCP/IP data links can be assigned to the card you wish to remove from the database.



**CAUTION:** If the card being removed from the database is the last in-service card supporting the STPLAN feature (either ACM, DCM, or E5-SLAN card), removing this card from the database will disable the STPLAN feature.

The examples in this procedure are used to remove the DCM in card location 1201 from the database.

### Procedure

1. Display the cards in the database using the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:58:31 GMT EAGLE5 36.0.0
CARD   TYPE     APPL      LSET NAME   LINK SLC LSET NAME   LINK SLC
1101   TSM       SCCP
1102   TSM       GLS
1103   ACMENET   STPLAN
1104   ACMENET   STPLAN
1113   GPSM      EOAM
1114   TDM-A
1115   GPSM      EOAM
1116   TDM-B
1117   MDAL
1201   DCM       STPLAN
1203   DCM       STPLAN
1204   ACMENET   STPLAN
1205   DCM       STPLAN
1206   DCM       STPLAN
1207   DCM       STPLAN
1211   LIMDS0    SS7ANSI   lsn1        A    0    lsn2        B    1
1212   LIMV35    SS7GX25   lsn2        A    0
1213   LIMV35    SS7ANSI   lsn2        A    0    lsn1        B    1
1216   LIMDS0    SS7ANSI   sp2         A    0    sp1         B    0
1303   LIMDS0    SS7ANSI   sp3         A    0
1304   LIMDS0    SS7ANSI   sp3         A    1
1306   LIMDS0    SS7ANSI   nsp3        A    1    nsp4        B    1
1307   LIMV35    SS7GX25   nsp1        A    0
1308   LIMV35    SS7GX25   nsp1        A    1
```

If no STPLAN cards are shown in the **rtrv-card** output, this procedure cannot be performed. STPLAN cards are shown by the entry **STPLAN** in the **APPL** field.

2. Display the status of the TCP/IP data link assigned to the card you wish to remove by entering the **rept-stat-dlk** command with the card location of the STPLAN card being removed. For this example, enter this command.

```
rept-stat-dlk:loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:17:37 GMT EAGLE5 36.0.0
DLK    PST      SST      AST
1201   IS-NR    Avail    ---
```

```
ALARM STATUS      = No Alarms.
Command Completed.
```

3. If the TCP/IP data link is not in an OOS-MT-DSBLD state, deactivate the TCP/IP data link assigned to the card using the **canc-dlk** command with the card location specified in step 2.

For this example, enter this command.

```
canc-dlk:loc=1201
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

4. Inhibit the card using the **rmv-card** command, specifying the card location specified in step 3.

For this example, enter this command.

```
rmv-card:loc=1201
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:19:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

5. Display the TCP/IP nodes in the database by entering the **rtrv-ip-node** command with the card location specified in step 4. For this example, enter this command.

```
rtrv-ip-node=loc=1201
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:20:37 GMT EAGLE5 36.0.0
IPADDR      IPPORT  IPAPPL  LOC   CAP  IPRTE
193.4.201.50  1024   stplan 1201  10%  --
```

6. Remove the TCP/IP node assigned to the card location containing the TCP/IP data link to be removed from the database using the **dlt-ip-node** command with the card location specified in step 5.

For this example, enter this command.

```
dlt-ip-node:ipaddr=193.4.201.50:loc=1201
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:21:37 GMT EAGLE5 36.0.0
DLT-IP-NODE: MASP A - COMPLTD
```

7. Remove the data link from the specified card by using the **dlt-dlk** command with the card location specified in step 6.

For this example, enter this command.

```
dlt-dlk:loc=1201
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:22:37 GMT EAGLE5 36.0.0
DLT-DLK: MASP A - COMPLTD
```

8. Remove the card using the **dlt-card** command with the card location of the card to be removed.

The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter this command.

```
dlt-card:loc=1201
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:23:37 GMT EAGLE5 36.0.0  
DLT-CARD: MASP A - COMPLTD
```

9. Verify the changes using the **rtrv-card** command specifying the card that was removed in step 8.

For this example, enter this command.

```
rtrv-card:loc=1201
```

When this command has successfully completed, this message should appear.


```
E2144 Cmd Rej: Location invalid for hardware configuration
```


10. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-2. Removing an STPLAN Card





## Adding a TCP/IP Data Link

This procedure is used to add a TCP/IP data link to the database using the **ent-dlk** command.

The **ent-dlk** command uses these parameters:

**:loc** – The card location of the ACM, DCM, or E5-SLAN card that the TCP/IP data link will be assigned to.

**:ipaddr** – The TCP/IP data link's IP address

**:duplex** – The mode of operation of the interface. This parameter is valid only for DCMs or E5-SLAN cards running the **STPLAN** application. The value for this parameter is **half** or **full**. The default value is **half**. The

value **half** indicates that the mode of operation of the interface is half duplex. The value **full** indicates that the mode of operation of the interface is full duplex.

**:speed** – The transmission rate of the TCP/IP data link, either 10 Mb/s (**speed=10**) or 100 Mb/s (**speed=100**). The default value for this optional parameter is 10. The **speed=100** parameter can be specified only if the application running on the STPLAN card is VXWSLAN. The application running on the card is shown in the **APPL** field of the **rtrv-card** command output.

**:auto** – This parameter specifies whether the hardware automatically determines duplex and speed. This parameter is valid only for DCMs or E5-SLAN cards running the **STPLAN** application. The value for this parameter is **yes** or **no**. The value **yes** indicates that the parameters duplex and speed are automatically determined. Dashes are displayed in the **LINK SPEED** and **DUPLEX** columns in the **rtrv-dlk** output if the **auto** parameter value is **yes**. The value **no** indicates that the parameters **duplex** and **speed** are not determined automatically.

The default value for the **auto** parameter is **yes**, if the **speed** and **duplex** parameters are not specified.

The **speed** and **duplex** parameters can be specified with the **auto** parameter only if the **auto** parameter value is **no**.

If the **speed** and **duplex** parameters are specified and the **auto** parameter is not specified, the default value for the **auto** parameter is **no**.

If either the **duplex** or **speed** parameters are specified, then both the **duplex** and **speed** parameters must be specified.

**NOTE: If the STPLAN card is an ACM (shown in the rtrv-card output with the entry ACMENET in the TYPE column), only the loc and ipaddr parameters can be specified in this procedure. The following values are also displayed in the rtrv-dlk output if the STPLAN card is an ACM.**

AUTO – NO LINK

SPEED – 10Mbit

DUPLEX – HALF

This examples used in this procedure are based on the example network shown in [Figure 3-7](#) and [Table 3-5](#).

The STPLAN and gateway screening features must be turned on. Verify this by entering the **rtrv-feat** command. If either the STPLAN feature or gateway screening feature is off, they can be turned on by entering the **chg-feat:lan=on** command for the STPLAN feature and the **chg-feat:gws=on** command for the gateway screening feature.

**NOTE: Once the gateway screening and STPLAN features are turned on with the chg-feat command, they cannot be turned off.**

The card that the TCP/IP data link is assigned to must be an ACM running the **stplan** application or a DCM or E5-SLAN card running the **stplan** application. This can be verified in step 2 with the **rtrv-card** command. The ACM is shown by the entries **ACMENET** in the **TYPE** field and **STPLAN** in the **APPL** field of the **rtrv-card** command output. The DCM or E5-SLAN card is shown by the entries **DCM** in the **TYPE** field and **STPLAN** in the **APPL** field of the **rtrv-card** command output. If the STPLAN card is not shown in the **rtrv-card** command output, go to [Adding an STPLAN Card](#) and add the required card to the database.

The specified card cannot have a TCP/IP data link assigned to it, nor can the TCP/IP data link be in the database. This can be verified in step 1.

The IP address to be assigned to the TCP/IP data link cannot be assigned to a TCP/IP node or to a TCP/IP router. Enter the **rtrv-ip-node** command to display the IP addresses of the TCP/IP nodes and the TCP/IP routers. This can be verified in step 2.

### Procedure

1. Display the data links in the database by entering the **rtrv-dlk** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:16:37 GMT EAGLE5 36.0.0
LOC  IPADDR          LINK SPEED
1103 193.4.201.34     10Mbit
1104 193.4.201.35     10Mbit
```

2. Display the TCP/IP nodes and TCP/IP routers by entering the **rtrv-ip-node** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:17:37 GMT EAGLE5 36.0.0
IPADDR  IPPORT  IPAPPL  LOC  CAP  IPRTE
193.4.201.70  1024  stplan  1103  10%  --
193.4.201.71  1024  stplan  1104  10%  --
```

If the IP address being assigned to the TCP/IP data link in this procedure matches any IP address values shown in steps 1 or 2, choose an IP address value that is not shown in steps 1 or 2 and go to step 3.

3. Display the cards in the database by entering the **rtrv-card** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:58:31 GMT EAGLE5 36.0.0
CARD  TYPE  APPL  LSET NAME  LINK SLC  LSET NAME  LINK SLC
1101  TSM  SCCP
1102  TSM  GLS
1103  ACMENET  STPLAN
1104  ACMENET  STPLAN
1113  GPSM  EOAM
1114  TDM-A
1115  GPSM  EOAM
1116  TDM-B
1117  MDAL
1201  DCM  STPLAN
1203  DCM  STPLAN
1204  ACMENET  STPLAN
1205  DCM  STPLAN
1206  DCM  STPLAN
1207  DCM  STPLAN
1211  LIMDS0  SS7ANSI  lsn1  A  0  lsn2  B  1
1212  LIMV35  SS7GX25  lsngwy  A  0
1213  LIMV35  SS7ANSI  lsn2  A  0  lsn1  B  1
1216  LIMDS0  SS7ANSI  sp2  A  0  sp1  B  0
1303  LIMDS0  SS7ANSI  sp3  A  0
1304  LIMDS0  SS7ANSI  sp3  A  1
1306  LIMDS0  SS7ANSI  nsp3  A  1  nsp4  B  1
1307  LIMV35  SS7GX25  nsp1  A  0
1308  LIMV35  SS7GX25  nsp1  A  1
```

The STPLAN card that will be specified in step 4 must be shown in the **rtrv-card** output in this step, but cannot be shown in the **loc** column of the **rtrv-dlk** output in step 1.

If the required STPLAN card is not shown in the **rtrv-card** output, perform [Adding an STPLAN Card](#) and add the STPLAN card to the database.

If the STPLAN card is shown in the **rtrv-dlk** output, either select an STPLAN card that is shown in the **rtrv-card** output, but not shown in the **rtrv-dlk** output, or perform [Adding an STPLAN Card](#) and add the STPLAN card to the database.

The **speed**, **duplex**, and **auto** parameters can be specified with the **ent-dlk** command only if the STPLAN card is a DCM or an E5-SLAN card.

4. Add the data link to the database by entering the **ent-dlk** command.

For this example, enter these commands.

```
ent-dlk:loc=1201:ipaddr=193.4.201.50:speed=100:auto=no
```

```
ent-dlk:loc=1203:ipaddr=193.4.201.51
```

```
ent-dlk:loc=1204:ipaddr=200.50.100.47
```

```
ent-dlk:loc=1205:ipaddr=193.4.201.50
```

```
ent-dlk:loc=1206:ipaddr=203.14.212.30
```

```
ent-dlk:loc=1207:ipaddr=203.14.212.39
```

When each of these commands has successfully completed, this message should appear.

```
r1ghncxa03w 06-10-20 21:19:37 GMT EAGLE5 36.0.0
ENT-DLK: MASP A - COMPLTD
```

The **ent-dlk** command assigns the IP address (**ipaddr**) to the STPLAN card. If the network is a private network (not on the Internet), you can assign any unique address. If the STPLAN card is on the Internet, you must obtain an IP address from the Internet Network Information Center (NIC). Refer to [IP Addresses](#) for information on the IP address values used in the **ent-dlk** command.

The default value for the **auto** parameter is **yes**, if the **speed** and **duplex** parameters are not specified.

The **speed** and **duplex** parameters can be specified with the **auto** parameter only if the **auto** parameter value is **no**.

If the **speed** and **duplex** parameters are specified and the **auto** parameter is not specified, the default value for the **auto** parameter is **no**.

If either the **duplex** or **speed** parameters are specified, then both the **duplex** and **speed** parameters must be specified.

**NOTE: If the STPLAN card is an ACM (shown in the **rtrv-card** output with the entry **ACMENET** in the **TYPE** column), only the **loc** and **ipaddr** parameters can be specified in this procedure. The following values are also displayed in the **rtrv-dlk** output if the STPLAN card is an ACM.**

**AUTO – NO ; LINK SPEED – 10Mbit; DUPLEX – HALF**

5. Verify the changes using the **rtrv-dlk** command with the card location specified in step 4.

For this example, enter these commands.

```
rtrv-dlk:loc=1201
```

This is an example of the possible output.

```
r1ghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC      IPADDR          LINK SPEED  DUPLEX  AUTO
1201    193.4.201.50    100Mbit    HALF    NO
```

```
rtrv-dlk:loc=1203
```

This is an example of the possible output.

```
r1ghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
```

```

LOC      IPADDR      LINK SPEED  DUPLEX  AUTO
1203    193.4.201.51  -----  -----  YES

```

**rtrv-dlk:loc=1204**

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC      IPADDR      LINK SPEED  DUPLEX  AUTO
1204    200.50.100.47  10Mbit     HALF    NO

```

**rtrv-dlk:loc=1205**

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC      IPADDR      LINK SPEED  DUPLEX  AUTO
1205    193.4.201.50  -----  -----  YES

```

**rtrv-dlk:loc=1206**

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC      IPADDR      LINK SPEED  DUPLEX  AUTO
1206    203.14.212.30  -----  -----  YES

```

**rtrv-dlk:loc=1207**

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC      IPADDR      LINK SPEED  DUPLEX  AUTO
1207    202.14.212.39  -----  -----  YES

```

- Place the cards into service by entering the **rst-card** command with the card location specified in step 4.

For this example, enter these commands.

**rst-card:loc=1201**

**rst-card:loc=1203**

**rst-card:loc=1204**

**rst-card:loc=1205**

**rst-card:loc=1206**

**rst-card:loc=1207**

This message should appear when each command has successfully completed.

```

rlghncxa03w 06-10-20 21:21:37 GMT EAGLE5 36.0.0
Card has been allowed.

```

- Place the data links into service by entering the **act-dlk** command with the card location specified in step 4.

For this example, enter these commands.

**act-dlk:loc=1201**

**act-dlk:loc=1203**

**act-dlk:loc=1204**

```
act-dlk:loc=1205
```

```
act-dlk:loc=1206
```

```
act-dlk:loc=1207
```

This message should appear when each command has successfully completed.


```
rlghncxa03w 06-10-20 21:22:37 GMT EAGLE5 36.0.0  
Activate Link message sent to card
```


8. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-3. Adding a TCP/IP Data Link





## Removing a TCP/IP Data Link

This procedure is used to remove a TCP/IP data link from the database using the **dlt-dlk** command.

The examples used in this procedure are used to remove the TCP/IP data link on card 1204 from the database.

The card that the TCP/IP data link is assigned to must be an ACM running the **stplan** application or a DCM/E5-SLAN card running the **stplan** application. This can be verified with the **rtrv-card** command. The

ACM is shown by the entries **ACMENET** in the **TYPE** field and **STPLAN** in the **APPL** field of the **rtrv-card** command output. The DCM or E5-SLAN card is shown by the entries **DCM** in the **TYPE** field and **STPLAN** in the **APPL** field of the **rtrv-card** command output.

The specified card must have a TCP/IP data link assigned to it and the TCP/IP data link must be in the database. This can be verified in step 1.

### Procedure

1. Display the data links in the database by entering the **rtrv-dlk** command.

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC  IPADDR      LINK SPEED  DUPLEX  AUTO
1103 193.4.201.70   10Mbit   HALF    NO
1104 193.4.201.71   10Mbit   HALF    NO
1201 193.4.201.50   100Mbit  HALF    NO
1203 193.4.201.51   -----  ----    YES
1204 200.50.100.47   10Mbit   HALF    NO
1205 193.4.201.50   -----  ----    YES
1206 203.14.212.30  -----  ----    YES
1207 202.14.212.39  -----  ----    YES
```

2. Place the TCP/IP data link to be removed out of service using the **canc-dlk** command, using the output from step 1 to obtain the card location of the TCP/IP data link to be removed.

For this example, the TCP/IP data link to be removed is assigned to card 1204. Enter this command.

```
canc-dlk:loc=1204
```

When the command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:17:37 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

3. Verify that the TCP/IP data link is out of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-dlk** command.

For this example, enter this command.

```
rept-stat-dlk:loc=1204
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
DLK  PST      SST      AST
1204 OOS-MT-DSBLD Unavail  ---
      ALARM STATUS =
Command Completed.
```

4. Place the card specified in step 3 out of service by using the **rmv-card** command.

For this example, enter this command.

```
rmv-card:loc=1204
```

This message should appear.

```
rlghncxa03w 06-10-20 21:19:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

5. Display the TCP/IP nodes in the database by entering the **rtrv-ip-node** command with the card location specified in step 4. For this example enter this command

```
rtrv-ip-node:loc=1204
```

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:20:37 GMT EAGLE5 37.0.0
IPADDR          IPPORT  IPAPPL  LOC   CAP  IP RTE
200.50.100.47   1024   stplan 1204  10%  --
```

6. Remove the TCP/IP node assigned to the card location containing the TCP/IP data link to be removed from the database using the **dlt-ip-node** command with the card location specified in step 5.

For this example, enter this command.

```
dlt-ip-node:ipaddr=200.50.100.47:loc=1204
```

This message should appear.

```
rlghncxa03w 06-10-20 21:21:37 GMT EAGLE5 36.0.0
DLT-IP-NODE: MASP A - COMPLTD
```

7. Remove the data link from the database using the **dlt-dlk** command.

The **dlt-dlk** command has only one parameter, **loc**, which is the location of the STPLAN card containing the TCP/IP data link. For this example, enter this command.

```
dlt-dlk:loc=1204
```

This message should appear.

```
rlghncxa03w 06-10-20 21:22:37 GMT EAGLE5 36.0.0
DLT-DLK: MASP A - COMPLTD
```

8. Verify the changes using the **rtrv-dlk** command with the card location specified in step 7.

```
rtrv-slk:loc=1204
```

When this command has successfully completed, this message should appear.


```
E2604 Cmd Rej: Card location not assigned a TCP/IP link
```

9. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-4. Removing a TCP/IP Data Link



## Adding a TCP/IP Node

This procedure is used to add a TCP/IP node to the database using the **ent-ip-node** command.

The **ent-ip-node** command uses these parameters:

- :ipaddr** – The node's IP address.
- :ipappl** – The IP application supported by the node.
- :ipport** – The logical IP port to address the application on the node.
- :loc** – The card location of the STPLAN card that contains the TCP/IP link that will be directly connected to the node.

**:cap** – The maximum percentage of SLAN TPS capacity for this node connection

**:iprte** – The IP address of the TCP/IP router.

This examples used in this procedure are based on the example network shown in [Figure 3-7](#) and [Table 3-5](#).

The TCP/IP node cannot already be in the database. This can be verified in step 1.

The specified card must have a TCP/IP data link assigned to it. This can be verified in step 2.

The IP address assigned to the TCP/IP node cannot be assigned to any other TCP/IP nodes, TCP/IP routers, or TCP/IP data links.

The class of the IP address (**ipaddr**) must match the class of the assigned TCP/IP data link's IP address only if the **iprte** parameter is not specified with the **ent-ip-node** command. The EAGLE 5 ISS supports three classes of IP addresses, class A, class B, and class C. Class A IP addresses can contain only the values 1 to 126 in the first field of the IP address. Class B IP addresses can contain only the values 128 to 191 in the first field of the IP address. Class C IP addresses can contain only the values 192 to 223 in the first field of the IP address. No IP address can contain the value 127 in the first field of the IP address. These IP addresses are reserved for loopback.

The network portion of the IP address (**ipaddr**) must match the network portion of the IP address assigned to the TCP/IP data link only if the **iprte** parameter is not specified with the **ent-ip-node** command. The network portion of the IP address is based on the class of the IP address. If the IP address is a class A IP address, the first field is the network portion of the IP address. If the IP address is a class B IP address, the first two fields are the network portion of the IP address. If the IP address is a class C IP address, the first three fields are the network portion of the IP address. For example, if the IP address of the TCP/IP data link is 193.5.207.150, a class C IP address, the network portion of the IP address for the TCP/IP node must be 193.5.207.

Refer to the [TCP/IP Router](#) section for more information of the TCP/IP router.

If the **iprte** parameter is specified with the **ent-ip-node** command, the class and network portion of the TCP/IP router's IP address must match the class and network portion of the TCP/IP data link and cannot match the IP address of the TCP/IP node being added to the database. If subnet routing is being used, the **iprte** parameter must be specified with the **ent-ip-node** command. Refer to the [TCP/IP Router](#) section on for more information of the TCP/IP router.

The capacity of all connections to the IP address cannot be greater than 100%. This is shown in the **CAP** field of the **rtrv-ip-node** command output.

## Procedure

1. Display the TCP/IP nodes in the database by entering the **rtrv-ip-node** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:16:37 GMT EAGLE5 36.0.0
IPADDR      IPPORT  IPAPPL  LOC   CAP  IP RTE
193.4.201.70 1024    stplan 1103 10%  --
193.4.201.71 1024    stplan 1104 10%  --
```

2. Display the TCP/IP data links in the database by entering the **rtrv-dlk** command.

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC  IPADDR      LINK SPEED  DUPLEX  AUTO
1103 193.4.201.70 10Mbit  HALF    NO
1104 193.4.201.71 10Mbit  HALF    NO
1201 193.4.201.50 100Mbit HALF    NO
1203 193.4.201.51 ----- ----    YES
1204 200.50.100.47 10Mbit  HALF    NO
```

```

1205  193.4.201.50      -----  ----  YES
1206  203.14.212.30     -----  ----  YES
1207  202.14.212.39     -----  ----  YES

```

If the required TCP/IP data link is not shown in the **rtrv-dlk** output, perform the “Adding a TCP/IP Data Link” procedure on page 3-33 and add the required TCP/IP data link to the database.

3. Add the TCP/IP nodes to the database by entering the **ent-ip-node** command.

For this example, enter these commands.

```

ent-ip-
node:loc=1201:ipaddr=193.4.201.65:ipappl=stplan:ippport=1024:cap=10

ent-ip-
node:loc=1203:ipaddr=193.4.201.78:ipappl=stplan:ippport=1024:cap=10

ent-ip-
node:loc=1204:ipaddr=200.50.115.101:ipappl=stplan:ippport=2000:cap=40:ip
prte=193.4.202.30

ent-ip-
node:loc=1205:ipaddr=193.4.201.56:ipappl=stplan:ippport=3000:cap=40

ent-ip-
node:loc=1206:ipaddr=203.24.212.30:ipappl=stplan:ippport=4000:cap=40:ip
rte=197.4.217.47

ent-ip-
node:loc=1207:ipaddr=205.37.12.63:ipappl=stplan:ippport=3963:cap=40:ipr
te=198.10.186.53

```

When each of these commands has successfully completed, this message should appear.

```

rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
ENT-IP-NODE: MASP A - COMPLTD

```

4. Verify the changes using the **rtrv-ip-node** command with the IP address specified in step 3. For this example, enter these commands.

```
rtrv-ip-node:ipaddr=193.4.201.65
```

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
IPADDR      IPPORT  IPAPPL  LOC    CAP  IPRTE
193.4.201.65  1024   stplan  1201  10%  --
193.4.201.65  3000   stplan  1205  40%  --

```

```
rtrv-ip-node:ipaddr=193.4.201.78
```

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
IPADDR      IPPORT  IPAPPL  LOC    CAP  IPRTE
193.4.201.78  1024   stplan  1203  10%  --

```

```
rtrv-ip-node:ipaddr=200.50.115.101
```

This is an example of the possible output.

```

rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
IPADDR      IPPORT  IPAPPL  LOC    CAP  IPRTE
200.50.115.101  2000   stplan  1204  40%  193.4.202.30

```

```
rtrv-ip-node:ipaddr=203.24.212.30
```

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
IPADDR          IPPORT  IPAPPL  LOC   CAP  IPRTE
203.24.212.30   1024   stplan  1206  40%  197.4.217.47
```

**rtrv-ip-node:ipaddr=205.37.12.63**

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
IPADDR          IPPORT  IPAPPL  LOC   CAP  IPRTE
205.37.12.63    3963   stplan  1207  40%  198.10.186.53
```

- Place the data links into service by entering the **act-dlk** command with the card location shown in step 4.

For this example, enter these commands.

**act-dlk:loc=1201**

**act-dlk:loc=1203**

**act-dlk:loc=1204**

**act-dlk:loc=1205**

**act-dlk:loc=1206**

**act-dlk:loc=1207**

This message should appear when each command has successfully completed.

```
rlghncxa03w 06-10-20 21:20:37 GMT EAGLE5 36.0.0
Activate Link message sent to card
```

- Check the status of the data links using the **rept-stat-dlk** command, specifying the card locations of the data links entered in step 5.

The link should be in service-normal (IS-NR) after the link has been activated. This is an example of the possible output.


```
rlghncxa03w 06-10-20 21:21:37 GMT EAGLE5 36.0.0
DLK          PST          SST          AST
1103         IS-NR         Avail        ----
1104         IS-NR         Avail        ----
1201         IS-NR         Avail        ----
1203         IS-NR         Avail        ----
1204         IS-NR         Avail        ----
1205         IS-NR         Avail        ----
1206         IS-NR         Avail        ----
1207         IS-NR         Avail        ----
Command Completed.
```

- Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-5. Adding a TCP/IP Node



## Removing a TCP/IP Node

This procedure is used to remove a TCP/IP node from the database using the **dlt-ip-node** command.

The **dlt-ip-node** command uses these parameters:

- :ipaddr** – The node’s IP address.
- :ipappl** – The IP application supported by the node.
- :ipport** – The logical IP port that addresses the application on the node.
- :loc** – The card location of the STPLAN card that contains the TCP/IP link that is directly connected to the node.
- :force** – Whether or not to remove all applications associated with the node, thus removing the entire node from the database.

The examples used in this procedure are used to remove the TCP/IP node with the IP address 193.4.201.71 from the database.

The TCP/IP node must be in the database. This can be verified in step 1.

The specified card must have a TCP/IP data link assigned to it. This can be verified in step 2.

The card that the TCP/IP data link is assigned to must be an ACM running the **stplan** application or a DCM or E5-SLAN card running the **stplan** application. This can be verified with the **rtrv-card** command. The ACM is shown by the entries **ACMENET** in the **TYPE** field and **STPLAN** in the **APPL** field of the **rtrv-card** command output. The DCM or E5-SLAN card is shown by the entries **DCM** in the **TYPE** field and **STPLAN** in the **APPL** field of the **rtrv-card** command output.

If only the **ipaddr** parameter is specified with the **dlt-ip-node** command, all the connections to a TCP/IP node will be removed from the database. To remove all the connections to a TCP/IP node, the **force=yes** parameter must be specified with the **ipaddr** parameter.

The **ipappl** or **ipport** parameters can be specified with the **dlt-ip-node** command, but both parameters cannot be specified with the **dlt-ip-node** command at the same time.

**Procedure**

---

1. Display the TCP/IP nodes in the database by entering the **rtrv-ip-node** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:16:37 GMT EAGLE5 36.0.0
IPADDR      IPPORT  IPAPPL  LOC    CAP  IPRTE
193.4.201.15 1024    stplan  1103  10%  --
193.4.201.23 1024    stplan  1104  10%  --
193.4.201.65 1024    stplan  1201  10%  --
193.4.201.65 3000    stplan  1205  40%  --
193.4.201.78 1024    stplan  1203  10%  --
200.50.115.101 2000    stplan  1204  40%  193.4.202.30
203.24.212.30 4000    stplan  1206  40%  197.4.217.47
205.37.12.63 3963    stplan  1207  40%  198.10.186.53
```

2. Display the TCP/IP data links in the database by entering the **rtrv-dlk** command.

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:16:37 GMT EAGLE5 37.0.0
LOC  IPADDR      LINK SPEED  DUPLEX  AUTO
1103 193.4.201.70 10Mbit  HALF    NO
1104 193.4.201.71 10Mbit  HALF    NO
1201 193.4.201.50 100Mbit HALF    NO
1203 193.4.201.51 ----- ----    YES
1204 200.50.100.47 10Mbit  HALF    NO
1205 193.4.201.50 ----- ----    YES
```

```
1206 203.14.212.30 ----- ---- YES
1207 202.14.212.39 ----- ---- YES
```

3. Verify the current state of the TCP/IP data link assigned to the TCP/IP node to be removed from the database using the **rept-stat-dlk** command. For this example, the TCP/IP data link to be placed out of service is assigned to card 1104. For this example, enter this command.

**rept-stat-dlk:loc=1104**

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:21:37 GMT EAGLE5 37.0.0
DLK          PST          SST          AST
1104         IS-NR        Avail       ----
Command Completed.
```

**NOTE: Skip step 4 and step 5 and go to step 6 if the status of the TCP/IP data link shown in the output of step 3 is OOS-MT-DSBLD.**

4. Place the TCP/IP data link using the **canc-dlk** command, using the outputs from steps 1 and 2 to obtain the card location (shown in the **LOC** field of both outputs) of the TCP/IP data link to be placed out of service. For this example, the TCP/IP data link to be placed out of service is assigned to card 1104. Enter this command.

**canc-dlk:loc=1104**

When the command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
Deactivate Link message sent to card.
```

5. Verify that the TCP/IP data link is out of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-dlk** command.

For this example, enter this command.

**rept-stat-dlk:loc=1104**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 21:19:37 GMT EAGLE5 36.0.0
DLK  PST          SST          AST
1104 OOS-MT-DSBLD Unavail    ---
ALARM STATUS =
Command Completed.
```

6. Verify the current state of the card assigned to the TCP/IP data link to be removed using the **rept-stat-card** command. For this example, enter this command.

**rept-stat-card:loc=1104**

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
CARD  VERSION    TYPE    GPL    PST          SST          AST
1104  126-003-002  DCM     VXWSLAN  IS-NR        Active       -----
ALARM STATUS = No Alarms.
BPDCM GPL version = 126-002-000
IMT BUS A = Conn
IMT BUS B = Conn
DLK A  PST = OOS-MT-DSBLD    SST = Unavail    AST = -----
SLAN % EAGLE CAPACITY = 0%
SLAN % HOST CAPACITY = 0%
Command Completed.
```

**NOTE: Skip steps 7 and 8 and go to step 9 if the status of the card shown in the output of step 6 is OOS-MT-DSBLD.**

- Place the card assigned to the TCP/IP node to be removed out of service by using the **rmv-card** command, specifying the card location used in step 3.

For this example, enter this command.

```
rmv-card:loc=1104
```

This message should appear.

```
rlghncxa03w 06-10-20 21:20:37 GMT EAGLE5 36.0.0
Card has been inhibited.
```

- Verify that the card is out-of service - maintenance disabled (OOS-MT-DSBLD) using the **rept-stat-card** command. For this example, enter this command.

```
rept-stat-card:loc=1104
```

This is an example of the possible output.

```
rlghncxa03w 07-02-20 21:19:37 GMT EAGLE5 37.0.0
CARD  VERSION      TYPE      GPL      PST      SST      AST
1104  126-003-002  DCM      VXWSLAN  OOS-MT-DSBLD  Manual  -----
ALARM STATUS      = ** 0013 Card is isolated from the system
  BPDCM GPL version = 126-002-000
  IMT BUS A         = Conn
  IMT BUS B         = Conn
  DLK A PST         = OOS-MT-DSBLD   SST = Unavail   AST = -----
  SLAN % EAGLE CAPACITY = 0%
  SLAN % HOST CAPACITY  = 0%
```

Command Completed.

- Remove the TCP/IP node to the database using the **dlt-ip-node** command. For this example, enter this command.

```
dlt-ip-node:ipaddr=193.4.201.71:ipport=1024 :loc=1104
```

This message should appear.

```
rlghncxa03w 06-10-20 21:21:37 GMT EAGLE5 36.0.0
DLT-IP-NODE: MASP A - COMPLTD
```

If you wish to remove all the connections to a TCP/IP node, for example, all the connections to the node at IP address 193.4.201.65, enter the **dlt-ip-node** command with the IP address of the node and the **force=yes** parameter, or enter the **dlt-ip-node** command with the IP address of the node and the **ipappl=stplan** parameter. For this example, enter one of these commands.

```
dlt-ip-node:ipaddr=193.4.201.65:force=yes
```

```
dlt-ip-node:ipaddr=193.4.201.65:ipappl=stplan
```

- Verify the changes using the **rtrv-ip-node** command.

If a single connection to a TCP/IP node was removed in step 9, enter the **rtrv-ip-node** command with the card location specified in step 9. For this example, enter this command.

```
rtrv-ip-node:loc=1104
```

The following message is displayed.

```
rlghncxa03w 07-02-20 21:22:37 GMT EAGLE5 37.0.0
E2622 Cmd Rej: IPADDR not assigned to specified LOC
```

If all the connections to a TCP/IP node were removed in step 9, enter the **rtrv-ip-node** command with the IP address specified in step 9. For this example, enter this command

```
rtrv-ip-node:ipaddr=193.4.201.65
```

The following message is displayed.


```
rlghncxa03w 07-02-20 21:22:37 GMT EAGLE5 37.0.0
IPADDR          IPPORT  IPAPPL  LOC   CAP   IP RTE
IPADDR not connected to any TCP/IP Link.
```


11. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 3-6. Removing a TCP/IP Node







# Database Transport Access (DTA) Configuration

DTA Feature Overview .....	4-1
Functional Description .....	4-3
Discarding MSUs .....	4-4
Measurements .....	4-6
Summary of the Gateway Screening Redirect Table Commands .....	4-6
X.25/SS7 Gateway Description .....	4-6
X.25/SS7 Gateway Routing .....	4-7
Routing Management Mapping .....	4-8
SCCP Subsystem Management .....	4-9
EAGLE 5 ISS Requirements .....	4-10
Configuring the EAGLE 5 ISS for the DTA Feature .....	4-11
Changing the Gateway Screening Redirect Parameters .....	4-32
Disabling the Gateway Screening Redirect Function .....	4-41

## DTA Feature Overview


This feature allows data to be routed through the SS7 network using the SCCP protocol without relying on TCAP as the upper level protocol.

In the case of specialized applications, MSUs containing SCCP and proprietary data must be sent through the network to customer-specific databases. However, these MSUs may need additional processing before being routed to their final destination.

The DTA feature provides a mechanism for the redirection of specific MSUs to a customized database. The EAGLE 5 ISS uses gateway screening to qualify incoming MSUs for redirection.

Once gateway screening is passed, the original MSU is encapsulated into a new MSU and routed to its new destination.

[Figure 4-1](#) shows a typical configuration for the DTA feature.

**Figure 4-1.** Example of Configuration for the DTA Feature

The new routing is specified by a redirection table that specifies the destination point code (DPC) and a new called party address. The routing indicator and the subsystem number are defined within the called party address.

The MSU is then passed to the SCP on the specified linkset where the application data is processed for a customized application.

Once the SCP has processed the user data, the SCP sends the MSU back to the EAGLE 5 ISS. At the EAGLE 5 ISS, the MSU is routed to its final destination either in the SS7 network or in the X.25 network. The SCP determines the routing for the MSU, providing it in the routing label of the MTP portion of the MSU and in the SCCP called party address.

The SCP also provides new calling party address information to support billing applications. The SCP is considered as the originator (OPC) and the calling party.

If the original destination is located within an X.25 network, the EAGLE 5 ISS uses its X.25 gateway feature to route the MSU to the X.25 network. The EAGLE 5 ISS selects a logical channel according to an X.25 routing table and sends the MSU on that logical channel.

If the selected logical channel fails, the EAGLE 5 ISS uses enhanced network management to reroute the MSU to a new X.25 logical channel. There are up to 1024 logical channels supported on the X.25/SS7 gateway.

As an optional feature, MSUs that are redirected to an SCP can also be copied using the STPLAN feature. This provides a copy of the redirected MSU to be routed over a TCP/IP interface to an adjunct processor. The copied MSU can then be processed for a variety of applications such as usage measurements.

The EAGLE 5 ISS does not provide any conversion of the copied MSU; it merely provides a copy of the redirected MSU after encapsulation of the original MSU. The copy is conducted by the LIM transmitting the redirected MSU.

If this feature is used, either the Applications Communications Module (ACM), running the STPLAN application, or the Database Communications Module (DCM), running the VXWSLAN application, is required. These cards provide an ethernet interface supporting TCP/IP applications. For more information regarding the STPLAN feature, see [Chapter 3 STPLAN Configuration](#) .


## Functional Description

The principal function within the EAGLE 5 ISS for this feature is gateway screening. This feature allows the EAGLE 5 ISS to examine all incoming MSUs and determine whether or not they should be allowed into the network. Gateway screening looks at the routing label of the incoming MSU and matches this information with the EAGLE 5 ISS's gateway screening tables.

To support the DTA feature, a gateway screening stop action set containing the **rdct** (redirect) gateway screening stop action is assigned to the last screen in the screening process. The redirect gateway screening stop action selects the MSU that is redirected for the DTA feature. The screening table for the DTA feature examines the routing label (OPC, DPC) and the SIO fields of the MSU.

Once the MSU has been qualified for redirection by the gateway screening function, the original MSU is encapsulated into the data portion of SCCP within a new SS7 MSU, including all level two and level three headers. A redirect routing table identifies the DPC to be inserted into the routing label of the redirected MSU. In addition, the called party address in the SCCP portion of the MSU is modified according to the parameters set in the redirect routing table. [Figure 4-2](#) illustrates the encapsulation process.

Figure 4-2. DTA Encapsulation



The global title function is used to determine which of the SCPs the MSU is routed to. In the event of subsystem failures, SCCP subsystem management determines which of the SCPs is available. The global title function provides the routing information and routes the MSU to the available SCP.

The global title function requires either the Translation Services Module (TSM) or Database Services Module (DSM) which contains the global title translation tables.

Once the MSU has received its routing information, the MSU can be sent to the appropriate SCP (specified by the EAGLE 5 ISS's redirection table and global title). The SCP then processes the user data contained within the encapsulated MSU. Once processing has been completed, the MSU is sent back to the EAGLE 5 ISS for final routing.

The DTA feature will redirect MSUs to either ANSI or ITU nodes, depending on the value of the DPC in the redirect routing table, but the redirect routing table can contain only one DPC value. If the incoming message type is not the same as the DPC in the redirect routing table, the message is tunneled to the redirect DPC.

The subsystem number in the called party address determines whether the MSU is processed as an ANSI MSU or an ITU MSU. If the subsystem number is 0, the MSU is an ANSI MSU. If the subsystem number is 250, the MSU is an ITU MSU (an MSU containing either a ITU-I point code, 14-bit ITU-N point code, ITU-I Spare point code, or 14-bit ITU-N Spare point code). If the subsystem number is 251, the MSU is an ITU-N24 MSU (an MSU containing a 24-bit ITU-N point code).

Tunneling uses an MTP2/MTP3/SCCP header based on the network type of the DTA DPC to allow any incoming message to be routed to the DTA DPC. A wrapper is placed around the message (an ANSI wrapper around an ITU message, or an ITU wrapper around an ANSI message), and sends the message to the DTA DPC. The destination removes the wrapper and processes the original information.

## Discarding MSUs

MSUs can be discarded for these reasons:

- Gateway screening is not available or the MSU does not pass gateway screening.
- The gateway screening redirect function is disabled.
- The MSU is too large to be encapsulated
- The DPC for the gateway screening redirect function is prohibited or congested.
- The EAGLE 5 ISS's SCCP subsystem is prohibited.

The discarding of MSUs is controlled by **gwsd** linkset parameter. If the **gwsd=on** parameter is specified for the linkset, and one or more of the conditions in the previous list are encountered, MSUs on the linkset are discarded. If the **gwsd=off** parameter is specified for the linkset, and one or more of the conditions in the previous list are encountered, MSUs on the linkset are routed to its original destination. Each of the MSU discard conditions are discussed in the following paragraphs.

If gateway screening is not available or the MSU does not pass gateway screening, the MSU is discarded. An unsolicited alarm message (UAM) is not generated. This condition is not dependent on the linkset **gwsd** parameter value. The MSGWSDSLIM measurement is pegged.

If the redirect mode is set to 'off' in the redirect function, either with the **chg-gws-redirect:enabled=off** or **dlt-gws-redirect** commands, and the linkset **gwsd=on** parameter is specified for the linkset, the MSU is discarded, MRN 1084 is generated, and the DTAMSULOST measurement is pegged. If the linkset **gwsd=off** parameter is specified for the linkset, the MSU is routed to its original destination, MRN 1084 is not generated, and the DTAMSULOST measurement is not pegged.

If an MSU is too large to be encapsulated, the MSU may be discarded, depending on the linkset's **gwsd** parameter value. The maximum length of the MSU is dependent on the number of digits contained in the global title address and on the network type of the DPC in the MSU, as shown in [Table 4-1](#) .

**Table 4-1. Maximum Encapsulation Length per DTA DPC Type**

MSU DPC Type	GTA Length - 1 Digit	GTA Length - 21 Digits
ANSI	250 bytes	240 bytes
ITU-I	253 bytes	243 bytes
ITU-I Spare	253 bytes	243 bytes
ITU-N	253 bytes	243 bytes
ITU-N Spare	253 bytes	243 bytes
ITU-N24	250 bytes	240 bytes

MSUs that are too long are discarded based on the linkset **gwsd** parameter value. If the linkset **gwsd=on** parameter is specified for the linkset, the MSU is discarded, MRN 1084 is generated, and the DTAMSULOST measurement is pegged. If the linkset **gwsd=off** parameter is specified for the linkset, the MSU is routed to its original destination, MRN 1085 is generated, but the DTAMSULOST measurement is not pegged.

If the DPC of the gateway screening redirect function is the DPC of an external node, and if the route to this DPC is prohibited, or if this DPC is available, but the congestion level is above the priority of the MSU (for DTA, this priority is always 0), the MSU will not be encapsulated and will be discarded or routed according to the linkset's **gwsd** parameter value. If the linkset's **gwsd** value is **on**, the MSU is discarded, MRN 1084 is generated, and the DTAMSULOST measurement is pegged. If the linkset's **gwsd** value is **off**, the MSU is routed to its original destination, MRN 1084 is not generated, and the DTAMSULOST measurement is not pegged.

If the DPC for the gateway screening redirect function is the EAGLE 5 ISS's point code, the MSU is sent to the EAGLE 5 ISS's SCCP subsystem for GTT processing. If the EAGLE 5 ISS's SCCP subsystem is prohibited, the MSU will not be encapsulated and will be discarded or routed according to the linkset's **gwsd** parameter value.

If the linkset's **gwsd** value is **on**, the MSU is discarded, MRN 1084 is generated, and the DTAMSULOST measurement is pegged. If the linkset's **gwsd** value is **off**, the MSU is routed to its original destination, MRN 1084 is not generated, and the DTAMSULOST measurement is not pegged.

MRNs 1084 and 1085 are discussed in greater detail in the *Maintenance Manual*.

### Measurements

Two measurements are provided to indicate the number of MSUs discarded: DTAMSULOST and MSGWSDSLIM.

The DTAMSULOST measurement counts the number of MSUs discarded because gateway screening is not available. This can be caused by a number of events, including congestion in the EAGLE 5 ISS.

The MSGWSDSLIM counts the number of MSUs discarded because the received MSU was too large to be encapsulated or because the redirect function was disabled.

DTAMSULOST and MSGWSDSLIM are explained in greater detail in the *Maintenance Manual*.

## Summary of the Gateway Screening Redirect Table Commands

The following set of commands is used to administer the gateway screening redirect table.

**Table 4-2. Commands for the Gateway Screening Redirect Table**

Command	Explanation and action
<b>ent-gws-redirect</b>	The <b>ent-gws-redirect</b> command is used to enter the routing table for redirected MSUs.
<b>chg-gws-redirect</b>	The <b>chg-gws-redirect</b> command is used to modify the existing redirect routing table.
<b>dlt-gws-redirect</b>	The <b>dlt-gws-redirect</b> command is used to delete the redirect table from the database.
<b>rtrv-gws-redirect</b>	The <b>rtrv-gws-redirect</b> command is used to display the parameters of an existing redirect routing table.

## X.25/SS7 Gateway Description

The X.25/SS7 gateway feature allows SCCP traffic to be routed over X.25 networks. X.25 protocol data units (PDUs) received over X.25 links are converted to SS7 MSUs for routing over the SS7 networks.

This protocol conversion does not affect the level four data. SCCP remains intact, with no conversion. This feature can be used for a variety of applications using the SCCP protocol over X.25 networks.

In addition to protocol conversion, the EAGLE 5 ISS also provides route management of X.25 logical channels. Traffic destined to a failed logical channel is diverted to an alternate route without loss of data. The EAGLE 5 ISS uses SS7 network management procedures to divert traffic and maintain data integrity.

The EAGLE 5 ISS supports 1024 logical channels. All X.25 entities are assigned an SS7 point code and SCCP subsystem number. The individual X.25 connections are assigned X.25 addresses, as well as alias point codes.

These are then mapped in the routing table to logical channels. This allows X.25 messages (which use connection-oriented procedures) to be routed and maintained in the SS7 network (which uses connectionless procedures).

Messages originating from the SS7 network destined for the X.25 network can be routed by the DPC assigned to the X.25 entity in the X.25 routing table (called Xpc). This allows SS7 entities to address the X.25 network without knowing X.25 addresses.

The X.25 routing table provides the X.25 address of each X.25 entity, an SS7 point code for each of the X.25 entities, the connection type used by the X.25 route, a subsystem number for SCCP routing, the method of routing to be used (Xpc or normal SS7 routing) and the logical channel to be used between each of the specified X.25 entities and the SS7 entities.

Routing by the X.25 point code assignment allows many SS7 entities to communicate to one X.25 entity without each SS7 entity having to know the X.25 address, and allows all SS7 entities to connect to the X.25 entity over one logical channel.

This provides for easier routing table administration. Without this capability, every possible connection between X.25 and SS7 entities would have to be defined in the X.25 routing table.

For more information on the X.25/SS7 gateway feature, see [Chapter 2 X.25 Gateway Configuration](#) .

## X.25/SS7 Gateway Routing

To support the gateway function, the entities within the X.25 network must be assigned an SS7 point code. This point code is assigned in the X.25 routing table using administration commands.

The routing table specifies the X.25 address, the SS7 point code assigned to both the X.25 entities and any SS7 entities that need to connect to X.25, a subsystem number for the X.25 entities, and the logical channel to be used on the X.25 link for connections between the specified entities.

Each EAGLE 5 ISS connection to the X.25 network is assigned an X.25 address as well. This allows routing of data from the X.25 network to the SS7 network. An SCCP subsystem number is assigned to the X.25 destination to enable global title translation to the X.25 entity.

Logical channels are also assigned in the X.25 routing table. Each X.25 entity must be assigned an SS7 destination to allow logical channel assignments to be made for the connection.


If there are to be several SS7 entities connecting to the X.25 entity over the same logical channel, a 'wild card' entry can be made in the routing table. This allows any SS7 entity to establish a connection over the specified logical channel, but only one connection can be made at any one time.

When data arrives on a LC destined for a node in the SS7 domain, the current X.25 gateway layer checks to see if the node is isolated. If so, the data is discarded.

This is shown in [Figure 4-3](#) . This figure also shows that it is possible to connect an Xpc to an SS7 point code (SS7pc) through an LC, where the SS7pc is a capability point code (CPC). This technique provides a higher availability of service to the Xpc.

**NOTE: A CPC is a group of individual nodes, where each node is identified by an individual point code. Collectively, when these nodes are grouped by point codes into a CPC, this group of nodes provides a capability. In this case, the capability is global titling.**

Figure 4-3. X.25 Routing to a CPC



## Routing Management Mapping

The X.25/SS7 gateway also provides management procedures for failed X.25 logical channels. This feature allows traffic destined for failed logical channels to be rerouted to an alternate route.

When configuring route management mapping, called logical channel to network management mapping, or LC2NM, it must be determined if the X.25 entity will be expecting associated queries and responses to use the same logical channel or if they may be assigned to different logical channels.

If associated queries and responses can be received over different logical channels, then failure recovery through alternate routing can be supported.

If route management mapping is enabled, and the X.25 entity can receive associated queries and responses on different logical channels, data destined to a failed logical channel is diverted by forced rerouting procedures in the EAGLE 5 ISS to the alternate route. All other associated traffic is diverted as well, and the logical channels to which associated traffic is assigned are made unavailable.

If the X.25 entity expects all associated queries and responses to be received on the same logical channel, traffic is still diverted to the alternate route if the logical channel fails. Forced rerouting procedures are not needed in this case.

If the alternate route is not available, the EAGLE 5 ISS uses level three network management procedures. For example, an X.25 Link Interface Module (LIM) determines a logical channel has failed. Network management diverts traffic away from the failed logical channel to a defined terminate route.

No network management messages are sent outside the EAGLE 5 ISS, and therefore should have no adverse effects on the SS7 network. The EAGLE 5 ISS uses SS7 network management procedures in software to divert traffic from the failed X.25 signaling link to another X.25 signaling link.

If route management mapping is not enabled on the X.25 linkset, there is no indication of logical channel failures. An unsolicited alarm message (UAM) output is created, which provides a textual message to indicate failure of an X.25 logical channel. All traffic destined to the failed logical channel is discarded.

If X.25 level 2 should fail within the X.25 LIM, all X.25 routes associated with the LIM are considered unavailable and forced rerouting procedures are used.

In either of the above cases, when the logical channel is restored to service, network management will divert traffic back to the newly restored logical channel.

## SCCP Subsystem Management

The EAGLE 5 ISS provides SCCP subsystem management for all transactions sent to an SCP. In the case of the DTA feature, subsystem management is provided for the customized SCP. The customized SCP is deployed in a quad configuration adjacent to the EAGLE 5 ISS. The links connecting the EAGLE 5 ISS and the SCP must be configured in such a way to support SCCP subsystem management. The application supported by the dual SCPs is duplicated in both entities. The applications can be configured in one of the following two modes: dominant or load-shared.


When configured as dominant, one SCP is configured to receive all queries. This assignment is made in EAGLE 5 ISS routing tables. In the event the dominant SCP fails, traffic is diverted by SCCP subsystem management to the mate application.

If load sharing is configured, both SCPs will receive queries. SCCP ensures that all associated transactions are sent to the same SCP. Load sharing allows traffic to be distributed to both SCPs evenly, preventing congestion at one SCP.

If there is a failure in a load sharing configuration, all traffic is diverted by SCCP subsystem management to the mate SCP. When the failed SCP is restored, the EAGLE 5 ISS resumes load sharing.

[Figure 4-4](#) shows an EAGLE 5 ISS configured with primary and backup SCPs.

Figure 4-4. Configuration of GTT for Routing Management



## EAGLE 5 ISS Requirements

There are no specific hardware requirements to support the DTA feature. However, if the following specific situations exist, the following cards are required.

Table 4-3. Cards Required in Specific Situations

If	Required Card
Interworking with an X.25 network with the OCU interface	LIM-OCU*
Interworking with an X.25 network with the DSOA interface	LIM-DS0*
Interworking with an X.25 network with the V.35 interface	LIM-V.35*
STPLAN feature is used	Application Communication Module
	DCM
Subsystem management is used	Application Service Module
	TSM-256
	TSM-512
	TSM-768

If	Required Card
	TSM-1024
	DSM
* A Link Interface Module with the AINF interface (labeled as either LIM or EILA) can also be used. The AINF interface can be configured as either an OCU, DS0, or V.35 interface.	

## Configuring the EAGLE 5 ISS for the DTA Feature

This procedure is used to add all the items to the EAGLE 5 ISS's database that are necessary to implement the DTA feature.

The following features must be turned on:

Gateway screening

Global title translation

X.25/SS7 gateway feature

Verify that these features are turned on by entering the **rtrv-feat** command. If any of these features are turned off, they can be turned on by entering one of the following commands:

**chg-feat:gws=on** – if the gateway screening feature is off (**GWS = off** in the **rtrv-feat** command output)

**chg-feat:gtt=on** – if the global title translation feature is off (**GTT = off** in the **rtrv-feat** command output)

**chg-feat:x25g=on** – if the X.25 gateway feature is off (**X25G = off** in the **rtrv-feat** command output)

**NOTE: Once the gateway screening, X.25 gateway, and global title translation features are turned on with the chg-feat command, they cannot be turned off.**

The following items must be provisioned in the database before the EAGLE 5 ISS can be provisioned for the DTA feature:

- LIMs assigned to the **ss7gx25** application and LIMs assigned to the **ss7ansi** application that are necessary to implement the DTA feature – [Adding an X.25 LIM](#) and "Adding an SS7 LIM" procedure in the *Database Administration Manual – System Management*. The LIMs can be verified by entering the **rtrv-card** command.
- SCCP cards assigned to either the **sccp** or **vsccp** applications that are necessary to implement the DTA feature - Adding an SCCP Card procedure in the *Database Administration Manual – Global Title Translation*. The SCCP cards can be verified by entering the **rtrv-card** command.
- If you wish to redirect MSUs on IP cards (cards running the **iplim**, **iplimi**, **ss7ipgw**, **ipgwi**, or **ipsg** applications), then IP cards assigned to the **iplim**, **iplimi**, **ss7ipgw**, **ipgwi**, or **ipsg** applications must be in the database - see the Adding an IPLIMx Card, Adding an IPGWx Card, or Adding an IPSP Card procedures in the *Database Administration Manual - IP<sup>7</sup> Secure Gateway*. The IP cards can be verified by entering the **rtrv-card** command. If MSUs on IP cards are being redirected, the IP cards must be assigned to SCTP associations, and routing keys, if applicable, according to the application assigned to the IP card. The IP configuration can be verified by entering these commands, as appropriate: **rtrv-**

**appl-rtkey, rtrv-as, rtrv-assoc, rtrv-ip-lnk, rtrv-ls, rtrv-slk.** Perform the procedures in the *Database Administration Manual - IP<sup>7</sup> Secure Gateway* to update the IP<sup>7</sup> Secure Gateway configuration as necessary.

- X.25 destination point codes (DPCs) and SS7 DPCs that are necessary to implement the DTA feature - "Adding a Destination Point Code" procedure in the *Database Administration Manual – SS7* . The DPCs can be verified by entering the **rtrv-dstn** command. The SS7 DPCs can be either ANSI, ITU-I, ITU-N, ITU-I Spare, ITU-N Spare, or ITU-N24 point codes. X.25 DPCs must be ANSI point codes.
- X.25 destinations that are necessary to implement the DTA feature – see the [Adding an X.25 Gateway Destination](#) procedure. The X.25 destinations can be verified by entering the **rtrv-x25-dstn** command.
- Linksets whose adjacent point codes (APCs) are in the X.25 domain and linksets whose APCs are in the SS7 domain that are necessary to implement the DTA feature – see one of these procedures: "Adding an SS7 Linkset" procedure in the *Database Administration Manual – SS7* , [Adding an X.25 Linkset](#) , "Adding an SS7 Linkset" procedure in the *Database Administration Manual – SS7* , or [Changing an X.25 Linkset](#) . The APCs of SS7 linksets can be either ANSI, ITU-I, ITU-N, ITU-I Spare, ITU-N Spare, or ITU-N24 point codes. The APCs of X.25 linksets must be ANSI point codes. The linksets can be verified by entering the **rtrv-ls** command. The linksets whose traffic is to be redirected by the DTA feature, must have gateway screening allowed (specify the **gwsa=on** parameter) and must reference a gateway screening screen set. The name of the screen set is shown in the **SCRN** field of the **rtrv-ls** command output. The name of the screen set is specified by the **scrn** parameter in either the **ent-ls** or **chg-ls** commands. The screen set referenced by the linkset must be in the database. All gateway screening entities must be in the database before the necessary linkset can be added to the database or changed to reference the necessary screen set. See the "Gateway Screening Configuration" section to make sure that the necessary gateway screening entities are in the database for this feature. To enhance the reliability of the DTA feature, the gateway screening message discard function should be turned on with the **gwsd=on** parameter.
- Signaling links assigned to linksets containing X.25 APCs and signaling links assigned to linksets containing SS7 APCs that are necessary to implement the DTA feature – "Adding an SS7 Signaling Link" procedure in the *Database Administration Manual – SS7* and [Adding an X.25 Signaling Link](#) . The APCs of SS7 linksets can be either ANSI, ITU-I, ITU-N, ITU-I Spare, ITU-N Spare, or ITU-N24 point codes. The APCs of X.25 linksets must be ANSI point codes. The signaling links can be verified by entering the **rtrv-slk** command.
- Routes assigned to linksets containing X.25 APCs and routes assigned to linksets containing SS7 APCs that are necessary to implement the DTA feature - "Adding a Route Containing an SS7 DPC" and "Adding a Route Containing an X.25 DPC" procedures in the *Database Administration Manual – SS7* . The DPCs of SS7 routes and APCs of SS7 linksets can be either ANSI, ITU-I, ITU-N, ITU-I Spare, ITU-N Spare, or ITU-N24 point codes. The DPCs of X.25 routes and APCs of X.25 linksets must be ANSI point codes. The routes can be verified by entering the **rtrv-rte** command.
- X.25 routes that are necessary to implement the DTA feature – see [Adding an X.25 Route](#) . The X.25 routes can be verified by entering the **rtrv-x25-rte** command.

### Gateway Screening Configuration

The DTA feature uses gateway screening to select the messages that are redirected. A gateway screening stop action set containing the **rdct** (redirect) gateway screening stop action must be assigned to one of these gateway screening entities where the gateway screening process stops (the NSFI of the screen is STOP).

- Allowed OPC
- Blocked OPC
- Allowed SIO
- Allowed DPC

- Blocked DPC
- Allowed Destination Field
- Allowed ISUP Message Type

Enter the **rtrv-gws-actset** command to display the gateway screening stop action sets in the database. The database contains one gateway screening stop action set that contain the **rdct** gateway screening stop action as shown in bold in the example output. This gateway screening stop action is always in the database and cannot be changed or removed.

```
rlghncxa03w 06-10-07 00:17:31 GMT EAGLE5 36.0.0
ACT  ACT   ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT
ID   NAME   1    2    3    4    5    6    7    8    9    10
--   ---   -
1    copy   copy
2    rdct   rdct
3    cr     copy rdct
```

GWS action set table is (3 of 16) 19% full

For more information on configuring gateway screening stop action sets, see the “Configuring Gateway Screening Stop Action Sets” procedure in the *Database Administration Manual - Gateway Screening*.



**CAUTION: Redirecting SLTA/SLTM messages prevents SLTA/SLTM messages from being returned to the EAGLE 5 ISS. The signaling link carrying these messages will fail if these messages are not returned to the EAGLE 5 ISS. To prevent SLTA/SLTM messages from being redirected, gateway screening stop action sets containing the redirect stop action should not be assigned to the following screens:**

- Allowed OPC screens containing the adjacent point code of a linkset
- Allowed SIO screens containing the service indicator values 1 (SI=1) or 2 (SI=2)
- Allowed DPC screens containing the EAGLE 5 ISS’s point code.

To verify that the screen set being used with the gateway screening redirect function, enter the **rtrv-scrset:scrn=<screen set name assigned to the linkset being used>** command. If the last screen in the screen set is OPC, BLKOPC, SIO, DPC, BLKDPC, DESTFLD, or ISUP, enter the gateway screening retrieve command corresponding to the last screen in the screen set, with the screening reference name shown in the **rtrv-scrset** output. For example, if the last screen in the screen set is ISUP, enter the **rtrv-scr-isup** command with the **sr** parameter. If the NSR/ACT value shown in the retrieve output is a gateway screening stop action set name that contains the **rdct** stop action, shown in the **rtrv-gws-actset** output, this screen set can be used for the gateway screening redirect function. If you wish to use this screen set, but the **rdct** gateway screening stop action is not assigned to the last screen in the screen set, go to the *Database Administration Manual - Gateway Screening* and perform one of these procedures, as appropriate, to assign the **rdct** gateway screening stop action to the last screen in the screen set.

- “Changing an Allowed ISUP Message Type Screen”
- “Changing an Allowed Affected Destination Field Screen”
- “Changing a Blocked DPC Screen”
- “Changing an Allowed DPC Screen”
- “Changing an Allowed SIO Screen”
- “Changing a Blocked OPC Screen”
- “Changing an Allowed OPC Screen”

If the last screen in the screen set is CGPA, TT, CDPA, or AFTPC, it is recommended that either this screen set is changed so that the last screen in the screen set is OPC, BLKOPC, SIO, DPC, BLKDPC, DESTFLD, or ISUP with the **rdct** gateway screening stop action, or that another screen set with OPC, BLKOPC, SIO, DPC, BLKDPC, DESTFLD, or ISUP as the last screen in the screen set with the **rdct** gateway screening stop action be used. To find another screen set, enter the **rtrv-scrset** command, then enter the **rtrv-scrset** command again with one of the screen set names shown in the first **rtrv-scrset** output. If the last screen in the screen set is OPC, BLKOPC, SIO, DPC, BLKDPC, DESTFLD, or ISUP, enter the gateway screening retrieve command corresponding to the last screen in the screen set, with the screening reference name shown in the **rtrv-scrset** output. Repeat this entering the **rtrv-scrset** commands until a desirable screen set is found. If a desirable screen set cannot be found, either add a new screen set, or change the existing screen set. To add a new screen set, go to the *Database Administration Manual - Gateway Screening* and perform one of these procedures, as appropriate, and assign the **rdct** gateway screening stop action to the last screen in the screen set.

- “Adding an Allowed ISUP Message Type Screen”
- “Adding an Allowed Affected Destination Field Screen”
- “Adding a Blocked DPC Screen”
- “Adding an Allowed DPC Screen”
- “Adding an Allowed SIO Screen”
- “Adding a Blocked OPC Screen”
- “Adding an Allowed OPC Screen”

If you wish to change the existing screen set, go to the *Database Administration Manual - Gateway Screening* and perform one of these procedures, as appropriate. Make sure the last screen in the screen set has the **rdct** gateway screening stop action assigned.

- “Changing an Allowed ISUP Message Type Screen”
- “Changing an Allowed Affected Destination Field Screen”
- “Changing a Blocked DPC Screen”
- “Changing an Allowed DPC Screen”
- “Changing an Allowed SIO Screen”
- “Changing a Blocked OPC Screen”
- “Changing an Allowed OPC Screen”

Verify that the necessary gateway screening entities have been configured with the required gateway screening stop action set, by entering the appropriate gateway screening retrieve command specifying the **actname** parameter with the gateway screening stop action name shown in the **rtrv-gws-actset** command output.

- **rtrv-scr-opc:actname=rdct** – to display the allowed OPC screens
- **rtrv-scr-blkopc:actname=rdct** – to display the blocked OPC screens
- **rtrv-scr-sio:actname=rdct** – to display the allowed SIO screens
- **rtrv-scr-dpc:actname=rdct** – to display the allowed DPC screens
- **rtrv-scr-blkdpc:actname=rdct** – to display the blocked DPC screens
- **rtrv-scr-destfld:actname=rdct** – to display the allowed destination field screens
- **rtrv-scr-isup:actname=rdct** – to display the allowed ISUP message type screens

If a gateway screening entity is configured to redirect, the entry **STOP** appears in the **NSFI** field, the **NSR/ACT** field contains the name of the gateway screening stop action set specified in the gateway screening retrieve command (see the following example).

```
rlghncxa03w 06-10-07 00:17:31 GMT EAGLE5 36.0.0
SCREEN = ALLOWED OPC
SR   NI       NC       NCM       NSFI       NSR/ACT
opc1 010       010       010       STOP       RDCT
opc1 010       010       012       STOP       RDCT
```

If the necessary gateway screening entities are not in the database, add them to the database using one of these procedures in the *Database Administration Manual - Gateway Screening*.

- “Adding an Allowed ISUP Message Type Screen”
- “Adding an Allowed Affected Destination Field Screen”
- “Adding a Blocked DPC Screen”
- “Adding an Allowed DPC Screen”
- “Adding an Allowed SIO Screen”
- “Adding a Blocked OPC Screen”
- “Adding an Allowed OPC Screen”

If the necessary gateway screening entities are in the database, use one these procedures in the *Database Administration Manual - Gateway Screening* to assign the redirect gateway screening stop action to them.

- “Changing an Allowed ISUP Message Type Screen”
- “Changing an Allowed Affected Destination Field Screen”
- “Changing a Blocked DPC Screen”
- “Changing an Allowed DPC Screen”
- “Changing an Allowed SIO Screen”
- “Changing a Blocked OPC Screen”
- “Changing an Allowed OPC Screen”



**CAUTION:** When Gateway Screening is in the screen test mode, as defined by the linkset parameters **gwsa=off** and **gwsn=on**, the gateway screening action in the gateway screening stop action set specified by the **actname** parameter of the gateway screening screen set at the end of the gateway screening process will be performed.

A screen set is required to start the screening process. Enter the **rtrv-scrset** command to verify that the necessary screen set is in the database. If the necessary screen set is not in the database, use the “Adding a Screen Set” in the in the *Database Administration Manual - Gateway Screening* and add the necessary screen set to the database. If the necessary screen set is in the database and the next screening function identifier (NSFI) needs to be changed, use the “Changing a Screen Set” in the in the *Database Administration Manual - Gateway Screening* to change the NSFI of the screen set.

### Canceling the **RTRV-GTT** and **RTRV-GTA** Commands

Because the **rtrv-gtt** and **rtrv-gta** commands used in this procedure can output information for a long period of time, the **rtrv-gtt** and **rtrv-gta** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-gtt** and **rtrv-gta** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-gtt** or **rtrv-gta** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-gtt** or **rtrv-gta** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-gtt** or **rtrv-gta** commands were entered, from another terminal other than the terminal where the **rtrv-gtt** or **rtrv-gta** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

### Procedure

1. Verify that the gateway screening redirect function is disabled by entering the **rtrv-gws-redirect** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:17:31 GMT EAGLE5 36.0.0
```

```
ENABLED DPCA          RI  SSN  TT    GTA
```

```
Redirect function data is not provisioned.
```

If the gateway screening redirect function is enabled, the **ent-gws-redirect** command in [Step 2](#) cannot be executed.

2. Provision the gateway screening redirect function by entering the following command.

This example is using the destination point code (**dpc**) 009-002-001, the routing indicator (**ri**) GT, the subsystem number (**ssn**) 15, the global title translation type (**tt**) 225, the global title address (**gta**) 9105551212, and the **enabled** parameter is equal to **on**.

**ent-gws-**

**redirect:dpc=009-002-001:ri=gt:ssn=15:tt=225 :gta=9105551212:enabled=on**

- **:dpc/dpca/dpci/dpcn/dpcn24** – The destination point code, either an ANSI, ITU-I, ITU-N, ITU-I Spare, ITU-N Spare, or ITU-N24 point code, that the message is being redirected to. The point code used for this parameter must be in the database as a destination point code of a route, shown in the **rtrv-rte** output, or must be the STP's site point code, shown in the **rtrv-sid** output.

**:dpc/dpca** – an ANSI point code

**:dpci** – an ITU-I or ITU-I Spare point code

**:dpcn** – a 14-bit ITU-N or 14-bit ITU-N Spare point code

**:dpcn24** – a 24-bit ITU-N point code

If you wish to use a destination point code as a value for this parameter, verify that the destination point code has a route assigned to it by entering the **rtrv-rte** command with the point code value being assigned to the gateway screening redirect function. The **dpc** parameter specified with the **rtrv-rte** command must correspond to the parameter value being specified as shown in the list preceding this paragraph.

For this example, enter the **rtrv-rte:dpca=009-002-001** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:19:31 GMT EAGLE5 36.0.0
DPCA          ALIASI          ALIASN/N24      LSN          RC          APCA
009-002-001  -----  -----  1s02        0          009-002-001
                                     RTX:No  CLLI=dtac11i
```

If you wish to use the STP's point code for the dpc parameter, enter the rtrv-sid command to find the STP's point code. The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:20:31 GMT EAGLE5 36.0.0
PCA          PCI          PCN          CLLI          PCTYPE
144-201-001  0-123-1          11211       rlghncxa03w  ANSI
                s-0-123-1          s-11211

CPCA
002-002-002  002-002-003      002-002-004  002-002-005
002-002-006  002-002-007      002-002-008  002-002-009
004-002-001  004-003-003      144-212-003

CPCA (LNP)
005-005-002  005-005-004      005-005-005

CPCI
1-001-1      1-001-2          1-001-3      1-001-4
1-002-1      1-002-2          1-002-3      1-002-4
2-001-1      7-222-7

CPCN
02091        02092            02094        02097
02191        02192            11177
```

The EAGLE 5 ISS's point code is shown in either the PCA, PCI, PCN, or PCN24 fields of the rtrv-sid command output. The rtrv-sid command will show either the PCN or PCN24 fields along with the PCA and PCI fields.

- :ri – The routing indicator for the redirected message.  
If the routing indicator is ssn, the DPC and SSN shown in the output of the rtrv-gws-redirect command, is the final destination of the redirected message. If the routing indicator is gt, additional global title translation is required to determine the final destination of the redirected message.
- :ssn – The CDPA subsystem to which the redirected message is bound for
- :tt – The CDPA translation type of the global title translation
- :gta – The CDPA global title translation address. Hexadecimal digits cannot be specified for the gta parameter. Only decimal digits can be specified for the gta parameter,
- :enabled – Whether the messages that have passed GWS are to be redirected (on) or discarded based on the linkset's gwsd parameter value (off). If the enabled parameter is off and the linkset's gwsd value is on, the MSU is discarded, MRN 1084 is generated, and the DTAMSULOST measurement is pegged. If the enabled parameter is off and the linkset's gwsd value is off, the MSU is routed to its original destination, MRN 1084 is not generated, and the DTAMSULOST measurement is not pegged.

When the command has been completed successfully, the following message should appear.

```
rlghncxa03w 06-10-07 00:21:31 GMT EAGLE5 36.0.0
ENT-GWS-REDIRECT: MASP A - COMPLTD
```

### 3. Verify the changes by entering the **rtrv-gws-redirect** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:22:31 GMT EAGLE5 36.0.0
```

```
ENABLED DPCA      RI  SSN  TT      GTA
on          009-002-001 GT  15   225   9105551212
```

- Verify if the enhanced global title translation feature is on or off by entering the **rtrv-feat** command. If the enhanced global title translation feature is on, the **EGTT** field should be set to **on**.

**NOTE: The rtrv-feat command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the rtrv-feat command, see the rtrv-feat command description in the *Commands Manual*.**

If the enhanced global title translation feature is on, the **rtrv-tt**, **ent-tt**, **rtrv-gtt**, and **ent-gtt** commands cannot be executed. Instead, the **rtrv-gttset**, **ent-gttset**, **rtrv-gttset**, **ent-gttset**, **rtrv-gta**, and **ent-gta** are used to verify and configure the global title translation data.

**NOTE: If the enhanced global title translation is on, skip [Step 5](#) , and [Step 6](#) , and go to [Step 7](#) .**

- Verify the global title translation data in the database for the translation type specified in the output of [Step 3](#) by entering the **rtrv-gtt** command with the **type** and **gta** parameters, specifying the values shown in [Step 3](#) in the **TT** and **GTA** fields of the **rtrv-gws-redirect** command output.

For this example, enter this command.

```
rtrv-gtt:type=225:gta=9105551212
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:24:31 GMT EAGLE5 36.0.0
TYPEA TTN      NDGT
225    DTA7    10
GTT TABLE IS 10% FULL.      (27000 of 269999)

START GTA      END GTA      XLAT  RI  PCA      SSN  NGT
9105551212    DPCSSN GT  009-002-001  15  ---
```

If the global title translation data is shown in the **rtrv-gtt** command output, no further action is necessary. Go to [Step 9](#) .

- Verify that the global title translation type shown in the output of [Step 3](#) , in the **TT** field, is in the database by entering the **rtrv-tt** command with the **type** parameter corresponding to the point code type shown in the **rtrv-gws-redirect** output and shown in [Table 4-4](#) .

**Table 4-4. Translation Type Parameters**

Point Code Type	DPC Parameter shown in the rtrv-gws-redirect output	Translation Type Parameter
ANSI	DPC/DPCA	typea
ITU-I or ITU-I Spare	DPCI	typei
ITU-N or ITU-N Spare	DPCN	typen
ITU-N24	DPCN24	typen24

In this example, the global title translation type is **225** and the DPC value is an ANSI point code. The **typea** parameter should be specified with the **rtrv-tt** command. The translation type is shown in the **TYPEA** field. For this example, enter this command.

```
rtrv-tt:typea=225
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:25:31 GMT EAGLE5 36.0.0
TYPEA  TTN      NDGT
225    DTA7     10
```

If the translation type is shown in the **rtrv-tt** output, perform the “Adding a Global Title Translation” procedure in the *Database Administration Manual - Global Title Translation* and configure a global title translation entry that contains the values shown in the **rtrv-gws-redirect** output in [Step 3](#) . This procedure is finished.

If the translation type is not shown in the **rtrv-tt** output, perform the “Adding a Translation Type” and “Adding a Global Title Translation” procedures in the *Database Administration Manual - Global Title Translation* and configure a global title translation entry that contains the values shown in the **rtrv-gws-redirect** output in [Step 3](#) . This procedure is finished.

**NOTE: If the enhanced global title translation is off, do not perform [Step 7](#) , [Step 8](#) , and [Step 9](#) . This procedure is finished.**

7. Verify that the global title translation type specified in the output of [Step 3](#) , in the **TT** field, is in the database by entering the **rtrv-gttset** command with the **tt** parameter.

For this example, enter the **rtrv-gttset:tt=225** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:27:31 GMT EAGLE5 36.0.0
GTIA  TT  NP      NAI  GTTSN
2     225  --      ---  dta7
```

If the translation type is not in the database, this message is displayed in the scroll area of the terminal display.

```
No GTT Selectors matching the specified criteria were found.
```

If the translation type is shown in the **rtrv-gttset** command output, go to [Step 8](#) and verify that the global title address data is in the database.

If the translation type is not shown in the **rtrv-gttset** command output, perform the “Adding a GTT Set,” “Adding a GTT Selector,” and “Adding Global Title Address Information” procedures in the *Database Administration Manual - Global Title Translation* and configure a global title address entry that contains the values shown in the **rtrv-gws-redirect** output in [Step 3](#) . This procedure is finished.

8. The new global title address data must be in the database.

Verify the global title translation data in the database for the translation type specified in the output of [Step 7](#) by entering the **rtrv-gta** command with the **GTTSN** value shown in the output of [Step 7](#) , and with the **GTA**, **SSN**, and **DPC** values shown in the output of [Step 3](#) . For this example, enter this command.

```
rtrv-gta:gttsn=dta7:gta=9195551212:ssn=15:pca=009-002-001
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
GTTSN      NETDOM  NDGT
dta7      ansi     10
GTA TABLE IS 1 % FULL (17 of 269999)

START GTA  END GTA  XLAT  RI  PCA          SSN CCGT NTT
```

If the required global title translation data is shown in the **rtrv-gta** command output, no further action is necessary. Go to [Step 9](#) .


If the required global title translation data is not shown in the **rtrv-gta** command output, perform the “Adding Global Title Address Information” procedure in the *Database Administration Manual - Global Title Translation* and configure a global title address entry that contains the values shown in the **rtrv-gws-redirect** output in [Step 3](#) . This procedure is finished.


9. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


The following messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 4-1. Configuring for the DTA Feature
































## Changing the Gateway Screening Redirect Parameters

To change the configuration to support the DTA feature, one or more of the gateway screening redirect function's attributes can be changed using the `chg-gws-redirect` command. This procedure shows the steps necessary to change these attributes.

The gateway screening redirect function's data must be in the database and the gateway screening redirect function must be enabled, shown by the entry `on` in the `enabled` field of the `rtrv-gws-redirect` command output.

Any of the gateway screening redirect function's attributes can be changed. The new attributes, and any database entities required to support these attributes, must be in the database.

### Canceling the RTRV-GTT and RTRV-GTA Commands

Because the `rtrv-gtt` and `rtrv-gta` commands used in this procedure can output information for a long period of time, the `rtrv-gtt` and `rtrv-gta` commands can be canceled and the output to the terminal stopped. There are three ways that the `rtrv-gtt` and `rtrv-gta` commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the `rtrv-gtt` or `rtrv-gta` commands were entered.
- Enter the `canc-cmd` without the `trm` parameter at the terminal where the `rtrv-gtt` or `rtrv-gta` commands were entered.
- Enter the `canc-cmd:trm=<xx>`, where `<xx>` is the terminal where the `rtrv-gtt` or `rtrv-gta` commands were entered, from another terminal other than the terminal where the `rtrv-gtt` or `rtrv-gta` commands were entered. To enter the `canc-cmd:trm=<xx>` command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the `rtrv-secu-trm` command. The user's permissions can be verified with the `rtrv-user` or `rtrv-secu-user` commands.

For more information about the `canc-cmd` command, go to the *Commands Manual*.

The examples in this procedure are used to change the gateway screening redirect function's attributes to these values. The routing indicator is not being changed.

- `:dpc` – 009-003-001
- `:ssn` – 45
- `:tt` – 175
- `:gta` – 3365841342

### Procedure

1. Verify the gateway screening redirect function attributes by entering the `rtrv-gws-redirect` command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:17:31 GMT EAGLE5 36.0.0
ENABLED DPCA          RI  SSN  TT    GTA
on          003-175-010 GT  15   225   9105551212
```

If the DPC, shown in the **DPC** field, is not being changed, skip, [Step 2](#), and [Step 3](#), and go to [Step 4](#).

2. Verify that the new DPC is in the database and has a route assigned to it.

**NOTE:** If the DPC is being changed to the EAGLE 5 ISS's point code, skip step 2 and go to step 3.

Verify this by entering the `rtrv-rte` command with the new DPC, in this example, 009-003-001.

```
rlghncxa03w 06-10-07 00:19:31 GMT EAGLE5 36.0.0
DPCA          ALIASI          ALIASN/N24   LSN          RC          APCA
009-003-001  -----  -----  1s02         0          009-001-001
RTX:No      CLLI=dtaccli
```

If the required route to the DPC is not shown in the **rtrv-rte** command output, go to the “Adding a Route Containing an X.25 DPC” or “Adding a Route Containing an SS7 DPC” procedures in the *Database Administration Manual - SS7* and add the route to the DPC to the database.

3. Display the EAGLE 5 ISS's point code by entering the **rtrv-sid** command.

**NOTE: If the DPC is being changed to a point code in the routing table, shown in the output of step 2, skip step 3 and go to [Step 4](#) .**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:20:31 GMT EAGLE5 36.0.0
PCA          PCI          PCN          CLLI          PCTYPE
144-201-001  0-123-1          11211       rlghncxa03w  ANSI
              s-0-123-1       s-11211

CPCA
002-002-002      002-002-003      002-002-004      002-002-005
002-002-006      002-002-007      002-002-008      002-002-009
004-002-001      004-003-003      144-212-003

CPCA (LNP)
005-005-002      005-005-004      005-005-005

CPCI
1-001-1          1-001-2          1-001-3          1-001-4
1-002-1          1-002-2          1-002-3          1-002-4
2-001-1          7-222-7

CPCN
02091            02092            02094            02097
02191            02192            11177
```

The EAGLE 5 ISS's point code is shown in either the **PCA**, **PCI**, **PCN**, or **PCN24** fields of the **rtrv-sid** command output. The **rtrv-sid** command will show either the **PCN** or **PCN24** fields along with the **PCA** and **PCI** fields.

4. Change the parameters for the gateway screening redirect function by entering the **chg-gws-redirect** command with any of these parameters:

- 

For this example, enter this command. In this example, the **ri** parameter is not being changed.

```
chg-gws-redirect:dpc=009-003-001:ssn=45:tt=175:gta=3365841342
```

When the command has been completed successfully, the following message should appear.

```
rlghncxa03w 06-10-07 00:21:31 GMT EAGLE5 36.0.0
CHG-GWS-REDIRECT: MASP A - COMPLTD
```

5. Verify the changes by entering the **rtrv-gws-redirect** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:22:31 GMT EAGLE5 36.0.0
ENABLED DPCA      RI  SSN  TT      GTA
on           009-003-001  GT  45   175    3365841342
```

If only the DPC parameter was changed in [Step 4](#) , skip [steps 6](#) through 10, go to [step 11](#) .

6. Verify if the enhanced global title translation feature is on or off by entering the **rtrv-feat** command.

If the enhanced global title translation feature is on, the **EGTT** field should be set to **on**.

For this example, the enhanced global title translation feature is on.

**NOTE:** The `rtrv-feat` command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the `rtrv-feat` command, see the `rtrv-feat` command description in the *Commands Manual*.

If the enhanced global title translation feature is on, the `rtrv-tt`, `ent-tt`, `rtrv-gtt`, and `ent-gtt` commands cannot be executed. Instead, the `rtrv-gttset`, `ent-gttset`, `rtrv-gttsetl`, `ent-gttsetl`, `rtrv-gta`, and `ent-gta` are used to verify and configure the global title translation data.

- The new global title address data must be in the database.

**NOTE:** If the enhanced global title translation is on, skip [steps 7](#) and [8](#), and go to [step 9](#).

Verify the global title translation data in the database for the translation type specified in the output of [step 5](#) by entering the `rtrv-gtt` command with the `type` and `gta` parameters. For this example, enter this command.

```
rtrv-gtt:type=175:gta=3365841342
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:24:31 GMT EAGLE5 36.0.0
TYPEA TTN          NDGT
175   DTA7         10
GTT TABLE IS 10% FULL.      (27000 of 269999)

START GTA          END GTA          XLAT  RI  PCA          SSN  NGT
3365841342        -----          DPCSSN GT  009-003-001  45  ---
```

If the global title translation data is shown in the `rtrv-gtt` command output, no further action is necessary. Go to [step 11](#).

- The new translation type must be in the database.

Verify that the global title translation type specified in the `rtrv-gws-redirect` output in [step 5](#) in the `TT` field, is in the database by entering the `rtrv-tt` command with the `type` parameter corresponding to the point code type shown in the `rtrv-gws-redirect` output in [step 5](#) and [Table 4-5](#).

**Table 4-5. Translation Type Parameters**

Point Code Type	DPC Parameter shown in the <code>rtrv-gws-redirect</code> output	Translation Type Parameter
ANSI	DPC/DPCA	typea
ITU-I or ITU-I Spare	DPCI	typei
ITU-N or ITU-N Spare	DPCN	typen
ITU-N24	DPCN24	typen24

In this example, the new global title translation type is 175. The `typea` parameter should be specified with the `rtrv-tt` command. The translation type is shown in the `TYPEA` field. For this example, enter this command.

```
rtrv-tt:typea=175
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:25:31 GMT EAGLE5 36.0.0
TYPEA TTN      NDGT
175   DTA7     10
```

If the translation type is shown in the **rtrv-tt** output, perform the “Adding a Global Title Translation” procedure in the *Database Administration Manual - Global Title Translation* and configure a global title translation entry that contains the values shown in the **rtrv-gws-redirect** output in [step 5](#). This procedure is finished. If the translation type is not shown in the **rtrv-tt** output, perform the “Adding a Translation Type” and “Adding a Global Title Translation” procedures in the *Database Administration Manual - Global Title Translation* and configure a global title translation entry that contains the values shown in the **rtrv-gws-redirect** output in [step 5](#). This procedure is finished.

9. Verify that the global title translation type specified in the output of [step 5](#), in the **TT** field, is in the database by entering the **rtrv-gttset** command with the **tt** parameter.

**NOTE: If the enhanced global title translation is off, do not perform steps 9, 10, and 11. This procedure is finished.**

For this example, enter the **rtrv-gttset:tt=175** command. The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:27:31 GMT EAGLE5 36.0.0
GTIA TT NP      NAI   GTTSN
2    175 --      ---   dta7
```

If the translation type is not in the database, this message is displayed in the scroll area of the terminal display.

```
No GTT Selectors matching the specified criteria were found.
```

If the translation type is shown in the **rtrv-gttset** command output, go to [step 10](#) and verify that the global title address data is in the database.

If the translation type is not shown in the **rtrv-gttset** command output, perform the “Adding a GTT Set,” “Adding a GTT Selector,” and “Adding Global Title Address Information” procedures in the *Database Administration Manual - Global Title Translation* and configure a global title address entry that contains the values shown in the **rtrv-gws-redirect** output in step 3. This procedure is finished.

10. The new global title address must be in the database.

Verify the global title translation data in the database for the translation type specified in the output of [step 5](#) by entering the **rtrv-gta** command with the **GTTSN** value shown in the output of [step 9](#) and with the **GTA**, **SSN**, and **DPC** values shown in the output of [step 5](#). For this example, enter this command.

```
rtrv-gta:gttsn=dta7:gta=3365841342:pca=009-003-001:ssn=45
```

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
GTTSN      NETDOM NDGT
t800      ansi    10
GTA TABLE IS 1 % FULL (17 of 269999)

START GTA  END GTA   XLAT  RI  PCA          SSN CCGT NTT
```

If the required global title translation data is shown in the **rtrv-gta** command output, no further action is necessary. Go to [step 11](#).

If the required global title translation data is not shown in the **rtrv-gta** command output, perform the “Adding Global Title Address Information” procedure in the *Database Administration Manual - Global*


*Title Translation* and configure a global title address entry that contains the values shown in the **rtrv-gws-redirect** output in [step 5](#). This procedure is finished.


11. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


The following messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 4-2. Changing the Gateway Screening Redirect Parameters









## Disabling the Gateway Screening Redirect Function

This procedure is used to turn off the gateway screening redirect function using either the `dlt-gws-redirect` or `chg-gws-redirect` commands. Turning off the gateway screening redirect function also turns off the DTA feature.

### Procedure

1. Verify that the gateway screening redirect function is enabled by entering the `rtrv-gws-redirect` command.

The following is an example of the possible output.

```
r1ghncxa03w 06-10-07 00:17:31 GMT EAGLE5 36.0.0
```

```
ENABLED DPCA      RI  SSN  TT      GTA
on          009-002-001 GT  15   225   9105551212
```

2. Disable the gateway screening redirect function by entering the **dlt-gws-redirect** command or the **chg-gws-redirect:enabled=off** command.

When the **dlt-gws-redirect** command has been completed successfully, the following message should appear.

```
rlghncxa03w 06-10-07 00:18:31 GMT EAGLE5 36.0.0
DLT-GWS-REDIRECT: MASP A - COMPLTD
```

When the **chg-gws-redirect** command has been completed successfully, the following message should appear.

```
rlghncxa03w 06-10-07 00:19:31 GMT EAGLE5 36.0.0
CHG-GWS-REDIRECT: MASP A - COMPLTD
```

3. Display the gateway screening stop action sets in the database by entering the **rtrv-gws-actset** command.

The entry **rdct** is displayed in the **ACT1** through the **ACT10** fields in any gateway screening stop action sets that have the redirect gateway screening stop action assigned to them. The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:20:31 GMT EAGLE5 36.0.0
ACT ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT  ACT
ID  NAME  1    2    3    4    5    6    7    8    9    10
--  ----  ---  ---  ---  ---  ---  ---  ---  ---  ---  ---
1   copy  copy
2   rdct  rdct
3   cr    copy rdct
GWS action set table is (3 of 16) 19% full
```

4. All gateway screening entities that have been assigned the redirect function must have the redirect function turned off.

Check the gateway screening entities for any screening references that have the redirect gateway screening stop action assigned to them.

Enter each of the following commands with the **actname** parameter specifying the name of the gateway screening stop action set shown in step 3 that contains the redirect gateway screening stop action. If a redirect gateway screening stop action has been assigned to a gateway screening entity, the name of the gateway screening stop action appears after the **NSR/ACT** field.

If a redirect gateway screening stop action has not been assigned to a gateway screening entity, the command is rejected with this message.

```
E3680 Cmd Rej: No match on ACTNAME parameter during retrieve
```

**rtrv-scr-opc:actname=rdct**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:21:31 GMT EAGLE5 36.0.0
SCREEN = ALLOWED OPC
SR  NI      NC      NCM      NSF1     NSR/ACT
DTA1 240     001     010     STOP     RDCT
```

**rtrv-scr-blkopc:actname=rdct**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:22:31 GMT EAGLE5 36.0.0
```

```
SCREEN = BLOCKED OPC
SR      NI      NC      NCM      NSF1      NSR/ACT
DTA2   C        C        C        STOP     RDCT
```

**rtrv-scr-sio:actname=rdct**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:23:31 GMT EAGLE5 36.0.0
SCREEN = ALLOWED SIO
SR      NIC     PRI     SI     H0      H1      NSF1      NSR/ACT
DTA3   1       3       4     --     --     STOP     RDCT
```

**rtrv-scr-dpc:actname=rdct**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:24:31 GMT EAGLE5 36.0.0
SCREEN = ALLOWED DPC
SR      NI      NC      NCM      NSF1      NSR/ACT
DTA4   243     015     001     STOP     RDCT
```

**rtrv-scr-blkdpc:actname=rdct**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:25:31 GMT EAGLE5 36.0.0
SCREEN = BLOCKED DPC
SR      NI      NC      NCM      NSF1      NSR/ACT
DTA5   C        C        C        STOP     RDCT
```

**rtrv-scr-destfld:actname=rdct**

The following is an example of the possible output.

```
rlghncxa03w 06-10-07 00:26:31 GMT EAGLE5 36.0.0
SCREEN = ALLOWED DESTFLD
SR      NI      NC      NCM      NSF1      NSR/ACT
DTA6   240     001     010     STOP     RDCT
```

5. If any of the necessary gateway screening entities displayed in step 4 have been assigned a gateway screening stop action containing the redirect gateway screening stop action, change the gateway screening stop action for these entities to a gateway screening stop action displayed in step 3 that does not have the redirect gateway screening stop action assigned to it, or to have no gateway screening stop action set assigned to the gateway screening entity with the **actname=none** parameter.

These command examples are based on the example outputs shown in step 4.

**chg-scr-opc:sr=dta1:ni=240:nc=001:ncm=010:actname=none**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 00:27:31 GMT EAGLE5 36.0.0
CHG-SCR-OPC: SCREEN SET AFFECTED - DTA1 55% FULL
CHG-SCR-OPC: MASP A - COMPLTD
```

**chg-scr-blkdpc:sr=dta2:nc=c:ni=c:ncm=c:actname=none**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
CHG-SCR-BLKOPC: SCREEN SET AFFECTED - DTA2 55% FULL
CHG-SCR-OPC: MASP A - COMPLTD
```

**chg-scr-sio:sr=dta3:nic=1:pri=3:si=4:actname=none**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 00:29:31 GMT EAGLE5 36.0.0
CHG-SCR-SIO: SCREEN SET AFFECTED - DTA3 55% FULL
CHG-SCR-SIO: MASP A - COMPLTD
```

**chg-scr-dpc:sr=dta4:ni=243:nc=015:ncm=001:actname=none**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 00:30:31 GMT EAGLE5 36.0.0
CHG-SCR-DPC: SCREEN SET AFFECTED - DTA4 55% FULL
CHG-SCR-DPC: MASP A - COMPLTD
```

**chg-scr-blkdpc:sr=dta5:nc=c:ni=c:ncm=c:actname=none**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 00:31:31 GMT EAGLE5 36.0.0
CHG-SCR-BLKDPC: SCREEN SET AFFECTED - DTA5 55% FULL
CHG-SCR-BLKDPC: MASP A - COMPLTD
```

**chg-scr-destfld:sr=dta6:ni=240:nc=001:ncm=010:actname=none**

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-07 00:32:31 GMT EAGLE5 36.0.0
CHG-SCR-DESTFLD: SCREEN SET AFFECTED - DTA6 55% FULL
CHG-SCR-DESTFLD: MASP A - COMPLTD
```

- Verify that the changes have been made by entering any of the following commands with the **actname** parameter and the name of the gateway screening stop action set used in step 4.

**rtrv-scr-opc:actname=rdct**

**rtrv-scr-blkopc:actname=rdct**

**rtrv-scr-sio:actname=rdct**

**rtrv-scr-dpc:actname=rdct**

**rtrv-scr-blkdpc:actname=rdct**

**rtrv-scr-destfld:actname=rdct**

None of the screens should contain any entries assigned to the gateway screening redirect function. When each these commands are executed, this message should appear.


```
E3680 Cmd Rej: No match on ACTNAME parameter during retrieve
```


- Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


The following messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 4-3. Disabling the Gateway Screening Redirect Function



















# GSM MAP Screening Configuration

Introduction .....	5-1
GSM MAP Screening Overview .....	5-2
GSM MAP Screening Details .....	5-5
GSM MAP Screening Example .....	5-17
GSM MAP Screening Procedures .....	5-18
Activating the GSM MAP Screening Feature .....	5-22
Configuring the MTP MAP Screening Feature .....	5-34
Configuring a Linkset for the GSM MAP Screening Feature .....	5-39
Changing the System-Wide GSM MAP Screening Options .....	5-49
Adding a GSM Subsystem Number Screening Entry .....	5-52
Removing a GSM Subsystem Number Screening Entry .....	5-55
Adding a GSM MAP Screening Operation Code .....	5-57
Removing a GSM MAP Screening Operation Code .....	5-75
Changing a GSM MAP Screening Operation Code .....	5-78
Adding a GSM MAP Screening Entry .....	5-92
Removing a GSM MAP Screening Entry .....	5-119
Changing a GSM MAP Screening Entry .....	5-128
Changing the GSM MAP Screening TCAP Continue and End Message Processing Option .....	5-146

## Introduction

Traditionally, STP message screening has been limited to the MTP and SCCP levels; this has been sufficient to meet operators' needs. However, GSM mobile operators have an increasing need for screening at the Mobile Application Part (MAP) level. This need is driven by advanced network capabilities and proliferating roaming agreements.

New features that require this enhanced screening capability are Inter-operator Short Message Service (SMS) and Any Time Interrogation (ATI). The GSM MAP Screening feature focuses on solving the screening needs associated with ATI, which is defined in MAP version 3. An ATI message allows an external server to interrogate an HLR and obtain information about the location and/or state of a GSM subscriber. It may be desirable to control which external entities can request this information, and what information they can request before allowing the message to pass through to the HLR.

This feature allow the user to provision which MAP SSNs are affected, which MAP operations codes to screen, which origination points are allowed, and which error messages to use.

**NOTE:** GSM MAP Screening can be used with linksets containing ITU international or ITU national adjacent point codes whether or not the Enhanced GSM MAP Screening feature is enabled and on. GSM MAP Screening can be used with linksets containing ANSI adjacent point codes only if the Enhanced GSM MAP screening feature is enabled and on.

## GSM MAP Screening Overview

An SCCP MSU arrives at the EAGLE 5 ISS on a linkset with the **gsmscrn** parameter value set to **on**. If the DPC of the MSU is the EAGLE 5 ISS's point code, the MSU is processed by Global Title Translation and Gateway Screening on the called party address (CDPA). Any applicable SCCP/MTP conversions are also performed on the MSU. The MSU is passed on to GSM MAP Screening. GSM MAP screening is then performed on the MSU before forwarding it to the destination. If the **gsmscrn** parameter of the linkset is set to **off**, GSM MAP Screening is not performed on the MSU.

If the DPC of the MSU is not the EAGLE 5 ISS's point code, the message is routed to its destination using MTP routing. GSM MAP Screening is not performed on the MSU.

If the MTP MAP Screening feature is enabled and turned on, and the DPC of the MSU is not the EAGLE 5 ISS's point code, the MSU (SCCP message types 9 - UDT, or 10 - UDTS only) is sent to GSM MAP Screening without being processed by Global Title Translation and Gateway Screening on the called party address. GSM MAP screening is then performed on the MSU before forwarding the MSU to its destination.

When GSM MAP Screening on the message has completed, the EAGLE 5 ISS performs one of the following actions:

- Route the message to destination
- Discard the message
- Forward the message to a new destination
- Duplicate the message. Send the original message to the original destination, and send the duplicate message to a new destination.
- Duplicate the message and send the duplicate message to a new destination. Discard the original message.
- Return an error message to the originator.

GSM MAP screening first checks to see whether the calling party SSN and called party SSN are present and targeted to be screened or not.

If both SSNs are targeted, it then checks for the MAP operations code of the message to know whether it is targeted to be screened or not. If the MAP operations code is not targeted to be screened, then the EAGLE 5 ISS either discards or routes the message, defined by the **GSMDFLT** parameter of the **chg-stpopts** command. If the MAP operations code is targeted to be screened, GSM MAP screening checks the calling party address of the message to know whether it is targeted for screening or not.

If the CGPA (calling party address) of the message is not targeted for GSM MAP Screening, then the screening action defined in the MAP operations code table by the **dfltact** parameter of the **ent-gsms-opcode** command is performed on the message.


If the CGPA of the message is targeted for screening and the Enhanced GSM MAP Screening feature is enabled and on, GSM MAP Screening checks the CDPA (called party address) of the message to know whether or not it is targeted for screening. If the CDPA of the message is targeted for screening, GSM MAP screening checks to see if the ATI request contains the forbidden parameter value provisioned for the CDPA. If there is no forbidden parameter in the ATI request, the message is not an ATI request, or the provisioned forbidden parameter value for the CDPA is **none**, the message is routed to the destination. If the message is an ATI request and contains the forbidden parameter value provisioned for the CDPA, or the provisioned forbidden parameter value is **all**, GSM MAP screening performs the screening action defined in the CDPA screening table by the **action** parameter of the **ent-gsmmap-scrn** command.


If the CDPA of the message is not targeted for screening, GSM MAP screening checks to see if the ATI request contains the forbidden parameter value provisioned for the CGPA. If there is no forbidden parameter in the ATI request, the message is not an ATI request, or the provisioned forbidden parameter value for the CGPA is **none**, the message is routed to the destination. If the message is an ATI request and contains the forbidden parameter value provisioned for the CGPA, or the provisioned forbidden parameter value is **all**, GSM MAP screening performs the screening action defined in the CGPA screening table by the **action** parameter of the **ent-gsmmap-scrn** command.

If the CGPA of the message is targeted for screening and the Enhanced GSM MAP Screening feature is not enabled and off, GSM MAP Screening checks the CGPA (calling party address) of the message to know whether or not it is targeted for screening. If the CGPA of the message is targeted for screening, GSM MAP screening checks to see if the ATI request contains the forbidden parameter value provisioned for the CGPA. If there is no forbidden parameter in the ATI request, the message is not an ATI request, or the provisioned forbidden parameter value for the CGPA is **none**, the message is routed to the destination. If the message is an ATI request and contains the forbidden parameter value provisioned for the CGPA, or the provisioned forbidden parameter value is **all**, GSM MAP screening performs the screening action defined in the CGPA screening table by the **action** parameter of the **ent-gsmmap-scrn** command.

[Figure 5-1](#) shows overview of GSM MAP screening functionality.

Figure 5-1. GSM MAP Screening Overview





## GSM MAP Screening Details

GSM MAP screening verifies the MAP message format and performs screening before the message is routed to the destination. The following database tables are used in performing GSM MAP screening:

- SSN table
- MAP operations code table
- STP option table

- MAP screening table

GSM MAP Screening is performed in the following stages.

1. The following fields from SCCP message are decoded:
  - The SSN from the calling party address
  - The SSN from the called party address
  - The global title address from the calling party address
  - The global title address from the called party address (only if the Enhanced GSM MAP Screening feature is enabled and turned on).

**NOTE: If the MTP MAP Screening is enabled and turned on, the MSU (SCCP message types 9 - UDT, or 10 - UDTS only) is sent to GSM MAP Screening even if the MSU does not require GTT and is MTP routed.**

2. GSM MAP Screening performs a lookup in the origination SSN table for an entry with the SSN of calling party address. If an entry is not found, GSM MAP screening is stopped and the message is routed to its destination using global title translation.
3. GSM MAP Screening performs a lookup in the destination SSN table for an entry with the SSN of called party address. If an entry is not found, GSM MAP screening is stopped and the message is routed to its destination using global title translation.
4. GSM MAP Screening checks to see if the CGPA and CDPA GTI values are supported in the EAGLE 5 ISS. The EAGLE 5 ISS supports only these GTI values: for an ANSI message - GTI value of 2; for an ITU message - GTI values of 2 or 4. If the CGPA and CDPA GTI values are supported, the GTA values are decoded. If the GTI values are not supported in the EAGLE 5 ISS, the GTA, NAI, and NP values for the CGPA or CDPA are set to asterisk (\*). The asterisk (\*) values for the GTA, NAI, and NP parameters allows the action of the provisioned wildcard entries for the CGPA/CDPA MAP screening tables to be performed, or the action for the OPCODE table to be performed (if no wildcard entries are provisioned for the CGPA or CDPA in the GSM MAP screening table).
5. The MAP operations code and parameters are extracted from the MAP message. If the TCAP Package Type of the message is ITU TC-BEGIN, GSM MAP Screening continues.

If the **GMSTCAPCE** SCCP option is set to on and the TCAP Package Type is either ITU TC-CONTINUE or ITU TC-END, GSM MAP Screening continues. In order for GSM MAP Screening to be performed on these messages, the messages must meet the following requirements:

- ITU TC-CONTINUE messages must have an Invoke component type.
- ITU TC-END messages must have a Return-Result (Test) type.

If the TCAP Package Type of the message is not ITU TC-BEGIN, GSM MAP Screening is stopped and the message is routed to its destination using global title translation, as if the message passed GSM MAP screening.

If the **GMSTCAPCE** SCCP option is set to **on**, and the TCAP Package Type of the message is not ITU TC-CONTINUE or ITU TC-END, GSM MAP Screening is stopped and the message is routed to its destination using global title translation, as if the message passed GSM MAP screening.

If the TCAP portion is not in a valid format, the action defined by the GSM MAP screening decode error action from the STP option table (pass or discard) is performed and a UIM is generated indicating that an Invalid TCAP message received.


6. GSM MAP Screening performs a lookup in the MAP screening table for an entry with the MAP operations code of the MAP message. If an entry is not found, the default action from the STP option table is performed. If the default action parameter value is **pass**, the message is routed to its destination. If the default action parameter value is **discard**, the message is discarded.
7. GSM MAP Screening performs a lookup in the GSM MAP screening table for an entry containing the global title address of the calling party address. If an entry is not found in the GSM MAP screening table, the screening action defined in the GSM MAP operations code table by the **dfltact** parameter of the **ent-gsms-opcode** command is performed.
8. If the Enhanced GSM MAP Screening feature is enabled and turned on, GSM MAP Screening performs a lookup for an entry for the called party address in the GSM MAP screening table.
9. If an entry is found in the MAP screening table, the forbidden parameter from the GSM MAP screening table is checked. If the forbidden parameter value is **none**, the message is routed to its destination. If the forbidden parameter value is **all**, the screening action defined in the GSM MAP screening table by the **action** parameter of the **ent-gsmmap-scrn** command is performed. For any other forbidden parameter, the parameter list of the message is examined. If the message is an ATI request and the forbidden parameter is found in the parameter list, then the screening action defined in the GSM MAP screening table by the **action** parameter of the **ent-gsmmap-scrn** command is performed.


The screening actions defined by the **dfltact** parameter of the **ent-gsms-opcode** command and the **action** parameter of the **ent-gsmmap-scrn** command are:


- **DISCARD** – do not route the MSU. The MSU is discarded (thrown away) and the appropriate UIM is issued. This is the default action value.
- **PASS** – route the message as normal to the destination and the appropriate UIM is issued.
- **ATIERR** – do not route the MSU and send a rejection message back to the originator.
- **ROUTE** – route the message as normal to the original destination node, defined by global title translation.
- **FORWARD** – route the original message to the forward node. The original message is not sent to the original node. If, however, the forwarded node is not available for routing then the MSU is routed to the original node, defined by global title translation.
- **DUPLICATE** – route the message as normal to the original destination, defined by global title translation, and route a copy of the original message to the duplicate node. If the MSU fails to route to the duplicate node, then a UIM is generated indicating the duplicate routing failure.
- **DUPLICATE AND DISCARD** – route the original message to the duplicate node. The original message is not sent to the original node. If, however, the duplicate node is not available for routing then the MSU is discarded.


[Figure 5-2](#) shows how GSM MAP screening is performed.


Figure 5-2. GSM MAP Screening Details


























## GSM MAP Screening Example

[Table 5-1](#) shows an example of the GSM MAP screening table.

**Table 5-1. Example GSM MAP Screening Table**

Authorized Origination Point (E.164 address)	Numbering Plan	Nature of Address Indicator	MAP Operations Code	Forbidden Parameters	Screening Action
6611273888	1	4	ATI_Request	All	Discard
6611273444	1	4	SRI_for_SM	All	Discard

6611273444	1	4	ATI_Request	Subscriber state	ATI-error
5431111888	1	4	FW_SM	None	----
5431111777	1	4	ATI_Request	All	Pass

In this example,

- Any ATI\_Request message from 6611273888 containing the numbering plan value of 1 and nature of address indicator value of 4 would be discarded.
- Any SRI\_for\_SM from 6611273444 containing the numbering plan value of 1 and nature of address indicator value of 4 would be discarded.
- An ATI\_Request message from 6611273444 containing the numbering plan value of 1 and nature of address indicator value of 4 requesting the Location only would be routed. An ATI\_Request message from 6611273444 requesting both the Location and Subscriber state would result in an ATI-error message being sent back to the originator. An ATI\_Request message from 6611273444 requesting the Subscriber state only would result in an ATI-error message being sent back to the originator.
- A FW\_SM message from 5431111888 containing the numbering plan value of 1 and nature of address indicator value of 4 would be routed successfully, because no parameters are forbidden.
- Any ATI\_Request from 5431111777 containing the numbering plan value of 1 and nature of address indicator value of 4 would be routed successfully because of the “Pass” screening action. This could be used for testing purposes prior to screening.

[Table 5-2](#) shows an example of the system-wide screening table. It specifies the action to be taken in the event that a MAP operations code was defined for MAP screening, but no specific entry was found in the MAP screening table.

**Table 5-2. System-Wide Screening Table**

MAP Operations Code	Operations Code Specific Screening Action
ATI	ATI-error
SRI_for_SM	Discard

## GSM MAP Screening Procedures

The following procedures describe the steps needed to add, remove, or change GSM MAP Screening data in the database.

The items administered in this section are:

- Linkset with GSM MAP Screening enabled
- STP options for GSM MAP Screening
- GSM SSN
- GSM Opcodes
- GSM MAP Screening entries

- An option to enable or disable the processing of GSM MAP Screening TCAP Continue and TCAP End messages.

The procedures shown in this chapter use a variety of commands. For more information on these commands, refer to the *Commands Manual*.

[Figure 5-3](#) shows the relationships of the database elements that are configured in these procedures.

The following is a brief description of the GSM MAP Screening entities. These entities must be configured in the order that they are shown.

1. The Global Title Translation (GTT) feature must be turned on with the **chg-feat** command using the **gtt=on** parameter. The global title translation feature must be on before the GSM MAP Screening feature can be enabled and turned on. Verify that the GTT feature is on using the **rtrv-feat** command.


**NOTE: Once the Global Title Translation (GTT) feature is turned on with the chg-feat command, it cannot be turned off.**


**The GTT feature must be purchased before turning on the GTT feature. If you are not sure whether you have purchased the GTT feature, contact your Tekelec Sales Representative or Account Representative.**

2. The GSM MAP Screening feature must be enabled with the **enable-ctrl-feat** command, and turned on with the **chg-ctrl-feat** command. Verify the status of the GSM MAP Screening feature with the **rtrv-ctrl-feat** command.

**NOTE: Once the GSM MAP Screening feature is enabled and turned on, it cannot be disabled or turned off.**

Figure 5-3. GSM MAP Screening Database Relationships





3. GSM MAP Screening can process TCAP Continue and TCAP End messages in addition to TCAP Begin messages by setting the SCCP option parameter **GMSTCAPCE** to **on** with the **chg-sccpopts** command. Setting the SCCP option parameter **GMSTCAPCE** to **off** disables the processing of the TCAP Continue and TCAP End messages. The current value of the **GMSTCAPCE** parameter is shown in the **rtrv-sccpopts** output. For more information on setting the SCCP option parameter **GMSTCAPCE**, see the [Changing the GSM MAP Screening TCAP Continue and End Message Processing Option](#) procedure.
4. To use GSM MAP Screening on all types of linksets including ANSI linksets, or to provision CDPA entries in the GSM MAP Screening table, the Enhanced GSM MAP Screening feature must be enabled with the **enable-ctrl-feat** command, and turned on with the **chg-ctrl-feat** command. Verify the status of the Enhanced GSM MAP Screening features with the **rtrv-ctrl-feat** command.

**NOTE: Once the Enhanced GSM MAP Screening feature is enabled and turned on, it cannot be disabled or turned off.**
5. MSUs that do not require global title translation and are MTP routed can be sent to GSM MAP Screening only if the MTP MAP Screening feature is enabled with the **enable-ctrl-feat** command, and turned on with the **chg-ctrl-feat** command. The Enhanced GSM MAP Screening feature must be enabled and turned on to enable and turn on the MTP MAP Screening feature.
6. Linksets containing the **gsmscrn=on** parameter must be in the database. The **gsmscrn=on** parameter allows the messages on these linksets to be screened by the GSM MAP Screening feature. Verify this with the **rtrv-ls** command. If the necessary linksets are not in the database, add them with the **ent-ls** command, specifying the **gsmscrn=on** parameter. If the necessary linksets are in the database, but do not contain the **gsmscrn=on** parameter, change these linksets with the **chg-ls** command, specifying the **gsmscrn=on** parameter. If the Enhanced GSM MAP screening feature is enabled and on, the adjacent

point code of the linkset can be any type. If the Enhanced GSM MAP screening feature is not enabled and off, the adjacent point code of the linkset can be either an ITU international, ITU international spare, or 14 bit ITU national, 14-bit ITU national spare, or 24-bit ITU national point code. The EAGLE 5 ISS can contain either 14 bit or 24-bit ITU national point codes, but not both at the same time.

7. The GSM MAP screening options, **gsmdflt** (GSM MAP screening default action) and **gsmdecerr** (GSM MAP screening decode error action), can be changed with the **chg-stpopts** command. The current values for these options can be verified with the **rtrv-stpopts** command. The **GSMDFLT** parameter allows the user to specify the default screening action (PASS or DISCARD) that occurs when a MAP operations code contained in the MSU is not found in the GSM MAP operations code table. The **gsmdecerr** parameter allows the user to specify the default screening action (PASS or DISCARD) that occurs when an error is detected in the TCAP layer of the MSU being screened. Such errors included an invalid value for a parameter, length error, missing data, and so on.
8. The origination and destination subsystem numbers that are being screened using the GSM MAP screening feature need to be provisioned in the database. These subsystem numbers are shown in the **rtrv-gsmssn-scrn** command and provisioned using the **ent-gsmssn-scrn** command.
9. The concerned GSM MAP screening operation codes and the default screening action for the operation code need to be provisioned in the database. These operation codes are shown in the **rtrv-gsms-opcode** command and provisioned using the **ent-gsms-opcode** command. The **ent-gsms-opcode** allows the user to provision a list of all operation codes that the EAGLE 5 ISS uses in performing GSM screening. If a point code and subsystem number is provisioned for the GSM MAP screening operation code, the point code and subsystem number must be shown in the **rtrv-map** output. If the flexible GTT Load Sharing feature is enabled, a MAP set containing the point code and subsystem number must be assigned to the GSM MAP screening operation code. For more information on provisioning GSM MAP screening operation codes, see the [Adding a GSM MAP Screening Operation Code](#) procedure.
10. The GSM MAP screening entries that filter or allow TCAP messages for certain MAP operation codes need to be provisioned in the database. The GSM MAP screening entries are shown in the **rtrv-gsmmap-scrn** command and provisioned using the **ent-gsmmap-scrn** command. The messages are filtered or allowed based on the origination addresses (**saddr/eaddr**), numbering plan value (**npv**), nature of address indicator value (**naiv**), MAP opnames (**opname**), and forbidden (**forbid**) parameters. If the Enhanced GSM MAP Screening feature is enabled and on, the CGPA and CDPA of the messages are checked by the GSM MAP Screening table. If the Enhanced GSM MAP Screening feature is not enabled and off, only the CGPA of the messages are checked by the GSM MAP Screening table. If a point code and subsystem number is provisioned for the GSM MAP screening entry, the point code and subsystem number must be shown in the **rtrv-map** output. If the Flexible GTT Load Sharing feature is enabled, a MAP set containing the point code and subsystem number must be assigned to the GSM MAP screening entry. For more information on provisioning GSM MAP screening operation entries, see the [Adding a GSM MAP Screening Entry](#) procedure.

## Activating the GSM MAP Screening Feature

The GSM MAP screening feature is activated by enabling the GSM MAP Screening feature with the **enable-ctrl-feat** command, then by turning the feature on with the **chg-ctrl-feat** command. The status of the GSM MAP Screening feature can be verified with the **rtrv-ctrl-feat** command. Before the GSM MAP Screening feature is activated, the global title translation feature must be on. This can be verified with the **rtrv-feat** command.

**NOTE:** Once the global title translation feature is turned on with the **chg-feat** command, it cannot be turned off.

**The global title translation feature must be purchased before you turn the feature on with the `chg-feat` command. If you are not sure if you have purchased the global title translation feature, contact your Tekelec Sales Representative or Account Representative.**

This procedure can also be used to enable and turn on the Enhanced GSM MAP Screening feature. The `enable-ctrl-feat` and `chg-ctrl-feat` commands are used to enable and turn on the Enhanced GSM MAP Screening feature. The GSM MAP Screening feature must be enabled and turned on before the Enhanced GSM MAP Screening feature is enabled and turned on.

The `enable-ctrl-feat` command enables the feature by inputting the feature's access key and the feature's part number with these parameters:

**: `fak`** – The feature access key supplied by Tekelec. The feature access key contains 13 alphanumeric characters and is not case sensitive.

**: `partnum`** – The Tekelec-issued part number of the GSM MAP Screening and Enhanced GSM MAP Screening features.

- The GSM MAP Screening feature, 893013201
- The Enhanced GSM MAP Screening feature, 893012401

The `enable-ctrl-feat` command requires that the database contain a valid serial number for the EAGLE 5 ISS, and that this serial number is locked. This can be verified with the `rtrv-serial-num` command. The EAGLE 5 ISS is shipped with a serial number in the database, but the serial number is not locked. The serial number can be changed, if necessary, and locked once the EAGLE 5 ISS is on-site, with the `ent-serial-num` command. The `ent-serial-num` command uses these parameters.

**: `serial`** – The serial number assigned to the EAGLE 5 ISS. The serial number is not case sensitive.

**: `lock`** – Specifies whether or not the serial number is locked. This parameter has only one value, **yes**, which locks the serial number. Once the serial number is locked, it cannot be changed.

**NOTE: To enter and lock the EAGLE 5 ISS's serial number, the `ent-serial-num` command must be entered twice, once to add the correct serial number to the database with the `serial` parameter, then again with the `serial` and the `lock=yes` parameters to lock the serial number. You should verify that the serial number in the database is correct before locking the serial number. The serial number can be found on a label affixed to the control shelf (shelf 1100).**

The GSM MAP Screening and Enhanced GSM MAP Screening features cannot be temporarily enabled (with the temporary feature access key).

Once these features have been enabled, the features must be activated with the `chg-ctrl-feat` command. The `chg-ctrl-feat` command uses these parameters:

**: `partnum`** – The Tekelec-issued part number of the GSM MAP Screening and Enhanced GSM MAP Screening features.

- The GSM MAP Screening feature, 893013201
  - The Enhanced GSM MAP Screening feature, 893012401
- : `status=on`** – used to activate the features that customer has purchased and enabled.

**NOTE: Once the GSM MAP Screening and Enhanced GSM MAP Screening features are turned on, they cannot be turned off.**

The status of the features in the EAGLE 5 ISS is shown with the `rtrv-ctrl-feat` command.

The GSM MAP Screening feature requires that either TSMs or DSMs are installed and provisioned in the EAGLE 5 ISS. The Enhanced GSM MAP Screening feature require that DSMs are installed and provisioned in the EAGLE 5 ISS. TSMs are shown by the entry **TSM** in the **TYPE** column of the **rtrv-card** output and **SCCP** in the **APPL** column of the **rtrv-card** output. DSMs are shown by the entry **DSM** in the **TYPE** column of the **rtrv-card** output and **SCCP** in the **APPL** column of the **rtrv-card** output.

If the Enhanced GSM MAP Screening feature is being enabled and turned on, any cards with the TSM card type running the SCCP application in the EAGLE 5 ISS must be replaced by DSMs . Contact the Customer Care Center before replacing any SCCP cards. Refer to [Customer Care Center](#) for the contact information.

**Procedure**

1. Display the status of the controlled features by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Large System # Links	893005910	on	2000
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the GSM MAP Screening feature (shown in the **rtrv-ctrl-feat** output as **GSM Map Screening (GMS)**) is enabled and on, no further action is necessary. This procedure does not need to be performed.

If you wish to use the Enhanced GSM MAP Screening feature, and the Enhanced GSM MAP Screening feature (shown in the **rtrv-ctrl-feat** output as **Enhanced GMS (EGMS)**) is enabled and on, no further action is necessary. This procedure does not need to be performed.

If the GSM MAP Screening feature is enabled and off, skip steps 2 through 7 and go to step 8.

If the Enhanced GSM MAP Screening feature is enabled and off, skip steps 2 through 10 and go to step 11.

2. Display the cards in the EAGLE 5 ISS using the **rtrv-card** command.

The GSM MAP Screening feature requires that TSMs or DSMs are in the database. The Enhanced GSM MAP Screening feature requires that DSMs are in the database. This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:58:31 GMT EAGLE5 36.0.0
```

CARD	TYPE	APPL	LSET NAME	LINK SLC	LSET NAME	LINK SLC
1113	GPSM	EOAM				
1114	TDM-A					
1115	GPSM	EOAM				
1116	TDM-B					
1117	MDAL					
1201	LIMDS0	SS7ANSI	sp2	A 0	sp1	B 0
1203	LIMDS0	SS7ANSI	sp3	A 0		
1204	LIMDS0	SS7ANSI	sp3	A 1		

1206	LIMDS0	SS7ANSI	nsp3	A	1	nsp4	B	1
1207	LIMV35	SS7GX25	nsp1	A	0			
1208	LIMV35	SS7GX25	nsp1	A	1			
1216	ACMENET	STPLAN						
1308	LIMDS0	SS7ANSI	sp6	A	1	sp7	B	0
1314	LIMDS0	SS7ANSI	sp7	A	1	sp5	B	1
1317	ACMENET	STPLAN						

TSMs are shown by the entry **TSM** in the **TYPE** column and **SCCP** in the **APPL** column of the **rtrv-card** output. DSMs are shown by the entry **DSM** in the **TYPE** column and **SCCP** in the **APPL** column of the **rtrv-card** output. If the Enhanced GSM MAP Screening feature is being enabled and turned on, and the **rtrv-card** output shows TSM card types in the EAGLE 5 ISS, these cards must be replaced by DSMs. Contact the Customer Care Center before replacing any SCCP cards. Refer to [Customer Care Center](#) for the contact information.

If no SCCP cards are shown in the **rtrv-card** output, perform the “Adding an SCCP Card” procedure in the *Database Administration Manual - Global Title Translation* and add the required SCCP cards to the database.

If DSMs are in the EAGLE 5 ISS, go to step 3.

**NOTE: If the `rtrv-ctrl-feat` output in step 1 shows any controlled features, skip steps 3 through 6, and go to step 7. If the `rtrv-ctrl-feat` output shows only the HC-MIM SLK Capacity feature with a quantity of 64, steps 3 through 6 must be performed.**

3. Display the serial number in the database with the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
System serial number = nt00001231

System serial number is not locked.

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

**NOTE: If the serial number is correct and locked, skip steps 4, 5, and 6, and go to step 7. If the serial number is correct but not locked, skip steps 4 and 5, and go to step 6. If the serial number is not correct, but is locked, the GSM MAP Screening and Enhanced GSM MAP Screening features cannot be enabled and the remainder of this procedure cannot be performed. Contact the Customer Care Center to get an incorrect and locked serial number changed. Refer to [Customer Care Center](#) for the contact information. The serial number can be found on a label affixed to the control shelf (shelf 1100).**

4. Enter the correct serial number into the database using the **ent-serial-num** command with the **serial** parameter.

For this example, enter this command.

```
ent-serial-num:serial=<EAGLE 5 ISS's correct serial number>
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

5. Verify that the serial number entered into step 4 was entered correctly using the **rtrv-serial-num** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

```
System serial number = nt00001231
System serial number is not locked.
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
Command Completed
```

If the serial number was not entered correctly, repeat steps 4 and 5 and re-enter the correct serial number.

- Lock the serial number in the database by entering the **ent-serial-num** command with the serial number shown in step 3, if the serial number shown in step 3 is correct, or with the serial number shown in step 5, if the serial number was changed in step 4, and with the **lock=yes** parameter.

For this example, enter this command.

```
ent-serial-num:serial=<EAGLE 5 ISS's serial number>:lock=yes
```

When this command has successfully completed, the following message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENT-SERIAL-NUM: MASP A - COMPLTD
```

- Enable the GSM MAP Screening feature with the **enable-ctrl-feat** command specifying the part number for the GSM MAP Screening feature and the feature access key.

Enter this command.

```
enable-ctrl-feat:partnum=893013201:fak=<GSM MAP Screening feature access key>
```

**NOTE: A temporary feature access key cannot be specified to enable this feature.**

**NOTE: The values for the feature access key (the fak parameter) are provided by Tekelec. If you do not have the feature access key for the GSM MAP Screening feature, contact your Tekelec Sales Representative or Account Representative.**

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

- Turn the GSM MAP Screening feature on with the **chg-ctrl-feat** command specifying the part number for the GSM MAP Screening feature and the **status=on** parameter.

Enter this command.

```
chg-ctrl-feat:partnum=893013201:status=on
```

**NOTE: Once the GSM MAP Screening feature is turned on, it cannot be turned off.**

When the **chg-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

- Verify the changes by entering the **rtrv-ctrl-feat** command with the GSM MAP Screening feature part number.

Enter this command.

```
rtrv-ctrl-feat:partnum=893013201
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

The following features have been permanently enabled:

Feature Name	Partnum	Status	Quantity
GSM Map Screening (GMS)	893013201	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

10. Enable the Enhanced GSM MAP Screening feature with the **enable-ctrl-feat** command specifying the part number for the Enhanced GSM MAP Screening feature and the feature access key.

**NOTE: If you do not wish to enable and turn on the Enhanced GSM MAP Screening feature, skip steps 10, 11, and 12, and go to step 13.**

Enter this command: **enable-ctrl-feat:partnum=893012401:fak=<Enhanced GSM MAP Screening feature access key>**

**NOTE: A temporary feature access key cannot be specified to enable this feature.**

**NOTE: The values for the feature access key (the fak parameter) are provided by Tekelec. If you do not have the feature access key for the Enhanced GSM MAP Screening feature, contact your Tekelec Sales Representative or Account Representative.**

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

11. Turn the Enhanced GSM MAP Screening feature on with the **chg-ctrl-feat** command specifying the part number for the Enhanced GSM MAP Screening feature and the **status=on** parameter.

Enter this command.

**chg-ctrl-feat:partnum=893012401:status=on**

**NOTE: Once the Enhanced GSM MAP Screening feature is turned on, it cannot be turned off.**

When the **chg-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

12. Verify the changes by entering the **rtrv-ctrl-feat** command with the Enhanced GSM MAP Screening feature part number.

Enter this command.

**rtrv-ctrl-feat:partnum=893012401**

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Enhanced GMS (EGMS)	893012401	on	----

The following features have been temporarily enabled:

```
Feature Name      Partnum  Status  Quantity  Trial Period Left
Zero entries found.
```

The following features have expired temporary keys:


```
Feature Name      Partnum
Zero entries found.
```


13. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-1. Activating the GSM MAP Screening Feature











## Configuring the MTP MAP Screening Feature

The MTP MAP screening feature is enabled with the **enable-ctrl-feat** command. Once enabled, the feature can be turned on or off with the **chg-ctrl-feat** command. If the feature is already on, it can only be turned off. If the feature is off, it can only be turned on.

Before the MTP MAP Screening feature is enabled and turned on, the Enhanced GSM MAP Screening feature must be enabled and on. The Measurements Platform must also be enabled.

The status of the MTP MAP Screening and Enhanced GSM MAP Screening features can be verified with the **rtrv-ctrl-feat** command. The **rtrv-measopts** command shows whether the Measurements Platform is enabled or not.

The **enable-ctrl-feat** command enables the feature by inputting the feature's access key and the feature's part number with these parameters:

**:fak** – The feature access key supplied by Tekelec. The feature access key contains 13 alphanumeric characters and is not case sensitive.

**:partnum** – The Tekelec-issued part number of the MTP MAP Screening feature, 893013501

The MTP MAP Screening feature cannot be temporarily enabled (with a temporary feature access key).

The **chg-ctrl-feat** command uses these parameters:

**:partnum** – The Tekelec-issued part number of the MTP MAP Screening feature, 893013501.

**:status=on** – used to turn the MTP MAP Screening feature on.

**:status=off** – used to turn the MTP MAP Screening feature off.

**NOTE: Turning the MTP MAP Screening feature on allows GSM MAP Screening to be performed on all SCCP messages, even if these messages do not require Global Title Translation and are MTP routed. The value of the GSMSCRN parameter of the linkset carrying these SCCP messages must be YES.**

**NOTE: Turning the MTP MAP Screening feature off allows GSM MAP Screening to be performed only on those SCCP messages, on linksets with the GSMSCRN=YES value, that have passed Global Title Translation and Gateway Screening.**

### Procedure

1. Display the status of the controlled features by entering the **rtrv-ctrl-feat** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Command Class Management	893005801	on	----
LNP Short Message Service	893006601	on	----
Intermed GTT Load Sharing	893006901	on	----
XGTT Table Expansion	893006101	on	400000
XMAP Table Expansion	893007710	off	----
Large System # Links	893005910	on	2000
Routesets	893006401	on	6000
HC-MIM SLK Capacity	893012707	on	64

```
The following features have been temporarily enabled:
```

```
Feature Name      Partnum  Status  Quantity  Trial Period Left
Zero entries found.
```

The following features have expired temporary keys:

```
Feature Name      Partnum
Zero entries found.
```

If the MTP MAP Screening feature (shown in the **rtrv-ctrl-feat** output as **MTP Map Screening**) is enabled and on, and you do not wish to turn the feature off, no further action is necessary. If you wish to turn this feature off, skip steps 2 through 4, and go to step 5.

If the MTP MAP Screening feature is enabled and off, skip steps 2 through 4 and go to step 5 to turn the feature on.

2. If the **rtrv-ctrl-feat** in step 1 shows that the Enhanced GSM MAP Screening feature is enabled and on, skip this step and go to step 3.

If the **rtrv-ctrl-feat** in step 1 shows that the Enhanced GSM MAP Screening feature is not enabled or off, perform the [Activating the GSM MAP Screening Feature](#) to enable and turn on the Enhanced GSM MAP Screening feature.

3. Verify whether or not the Measurements Platform option is enabled (**PLATFORMENABLE = on**) using the **rtrv-measopts** command.

```
rlghncxa03w 06-10-01 16:02:05 GMT EAGLE5 36.0.0
```

```
PLATFORMENABLE = on
COLLECT15MIN    = off
CLLIBASEDNAME   = off
-----
SYSTOTSTP      = off
SYSTOTTT       = off
```

**NOTE:** The **rtrv-measopts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-measopts** command, see the **rtrv-measopts** command description in the *Commands Manual*.

If the Measurements Platform is not enabled, perform the “Configuring the Measurements Platform Feature” procedure in the *Database Administration Manual - System Management* to enable the Measurements Platform.

4. Enable the MTP MAP Screening feature with the **enable-ctrl-feat** command specifying the part number for the MTP MAP Screening feature and the feature access key.

Enter this command.

```
enable-ctrl-feat:partnum=893013501:fak=<MTP MAP Screening feature
access key>
```

**NOTE:** A temporary feature access key cannot be specified to enable this feature.

**NOTE:** The values for the feature access key (the **fak** parameter) are provided by Tekelec. If you do not have the feature access key for the Enhanced GSM MAP Screening feature, contact your Tekelec Sales Representative or Account Representative.

When the **enable-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
ENABLE-CTRL-FEAT: MASP B - COMPLTD
```

- Turn the MTP MAP Screening feature on or off with the **chg-ctrl-feat** command specifying the part number for the Enhanced GSM MAP Screening feature and either the **status=on** or **status=off** parameter.

To turn the MTP MAP Screening feature on, enter this command.

```
chg-ctrl-feat:partnum=893013501:status=on
```

To turn the MTP MAP Screening feature off, enter this command.

```
chg-ctrl-feat:partnum=893013501:status=off
```

When the **chg-ctrl-feat** command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
CHG-CTRL-FEAT: MASP B - COMPLTD
```

- Verify the changes by entering the **rtrv-ctrl-feat** command with the MTP MAP Screening feature part number.

Enter this command.

```
rtrv-ctrl-feat:partnum=893013501
```

The following is an example of the possible output if the feature was turned on in step 5.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
MTP MAP Screening	893013501	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

The following is an example of the possible output if the feature was turned off in step 5.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
MTP MAP Screening	893013501	off	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	


- Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
```

BACKUP (FIXED): MASP A - Backup starts on standby MASP.  
 BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 5-2. Configuring the MTP MAP Screening Feature





## Configuring a Linkset for the GSM MAP Screening Feature

This procedure is used to configure SS7 linksets for the GSM MAP Screening feature using the **gsmscrn** parameter of either the **ent-ls** or **chg-ls** command.

The **gsmscrn** parameter specifies whether or not GSM MAP screening is applied to messages arriving on the linkset. This parameter can be applied to all linksets, but this parameter can be specified for linksets with ANSI adjacent point codes only if the Enhanced GSM MAP Screening feature is enabled and on. The values for this parameter are **on** (GSM MAP screening is applied to the linkset) or **off** (GSM MAP screening is not applied to the linkset). GSM MAP screening is used to screen GSM MAP messages to control which external entities can request information about a GSM subscriber and the specific information these entities can request before allowing the GSM MAP message to pass through to the HLR.

Before the **gsmscrn** parameter can be specified for a specific linkset, the GSM MAP screening feature must be enabled and on. The status of the GSM MAP Screening feature, and if applicable the Enhanced GSM MAP screening feature, is shown in the **rtrv-ctrl-feat** command output with the entries **GSM Map Screening (GMS)** (for the GSM MAP Screening feature) and **Enhanced GMS (EGMS)** (for the Enhanced GSM MAP Screening feature). Perform the [Activating the GSM MAP Screening Feature](#) procedure to enable and turn on either of these features as required.

The value of the **gsmscrn** parameter is only displayed in the **rtrv-ls** command output when a specific linkset is being displayed with the **rtrv-ls:lsn=<linkset name>** command.

To configure a linkset for the GSM MAP Screening feature, the **ent-ls** or **chg-ls** commands uses these mandatory parameters in addition to the **gsmscrn** parameter.

**:lsn** – The name of the linkset. The linkset name can contain up to 10 characters, with the first character being a letter.

**:apc/apca/apci/apcn/apcn24** – Adjacent point code – the point code identifying the node that is next to the EAGLE 5 ISS. This parameter is only mandatory for the **ent-ls** command.

**NOTE:** See Chapter 2, *Configuring Destination Tables in the Database Administration Manual - SS7* for a definition of the point code types that are used on the EAGLE 5 ISS and for a definition of the different formats that can be used for ITU national point codes.

**NOTE:** The EAGLE 5 ISS can contain a 14-bit ITU-N point code (**apcn**) or a 24-bit ITU-N point code (**apcn24**), but not both at the same time.

**:lst** – The linkset type of the specified linkset This parameter is only mandatory for the **ent-ls** command.

The **ent-ls** and **chg-ls** commands contain other optional parameters that can be used to configure a linkset. These parameters are not shown here because they are not necessary for configuring a linkset for the GSM MAP Screening feature. These parameters are explained in more detail in the Adding an SS7 Linkset procedure or in the Changing an SS7 Linkset procedure in the *Database Administration Manual - SS7*, or in the **ent-ls** and **chg-ls** command descriptions in the *Commands Manual*.

The EAGLE 5 ISS can contain 1024 linksets, with a maximum of 255 of these linksets being gateway linksets. A gateway linkset is a linkset that contains routes to a different network.

This examples used in this procedure are based on the examples shown in [Table 5-3](#) .

Table 5-3. GSM MAP Screening Linkset Configuration Table

Linkset Names	Linkset APC	LST	GSMSCRN
New Linksets Being Added			
lsn5	10685	a	on
lsi7	3-150-4	a	on
Existing Linkset Being Changed			
lsn4	N/A	N/A	on

The linkset to be added cannot be in the database. This can be verified in step 1 of this procedure.

**Canceling the RTRV-LS and RTRV-DSTN Commands**

Because the **rtrv-ls** and **rtrv-dstn** commands used in this procedure can output information for a long period of time, the **rtrv-ls** and **rtrv-dstn** commands can be canceled and the output to the terminal stopped. There are three ways that the **rtrv-ls** and **rtrv-dstn** commands can be canceled.

- Press the **F9** function key on the keyboard at the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered, from another terminal other than the terminal where the **rtrv-ls** or **rtrv-dstn** commands were entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the current linkset configuration using the **rtrv-ls** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

LSN          APCA  (SS7)  SCR1  SET  SET  BEI  LST  LNKS  ACT  MES  DIS  SLSCI  NIS
lsa1         240-020-000 scr1   1   1   yes  a   1   off  off  off  no   off
lsa2         240-030-000 scr2   1   2   no   c   3   on   on   on   yes  off
lsa3         240-040-000 scr3   1   3   yes  c   5   off  off  off  yes  off
ls04         001-002-003 scr2   1   1   no   a   4   on   off  on   yes  off

LSN          APCA  (X25)  SCR4  SET  SET  BEI  LST  LNKS  ACT  MES  DIS  SLSCI  NIS
ls6          244-010-004 scr4   1   4   no   a   6   off  off  off  ---  off
ls7          244-012-005 scr5   1   5   no   c   3   on   on   on   ---  off
ls8          244-012-006 scr6   1   6   no   c   8   off  off  off  ---  off

LSN          APCI  (SS7)  SCR1  SET  SET  BEI  LST  LNKS  ACT  MES  DIS  SLSCI  NIS
lsi1         1-111-1   scr1   1   1   yes  a   1   off  off  off  ---  ---
lsi2         1-111-2   scr2   1   2   no   c   3   on   on   on   ---  ---
lsi3         1-111-3   scr3   1   3   yes  c   5   off  off  off  ---  ---

L3T  SLT          GWS  GWS  GWS
```

LSN	APCN	(SS7)	SCRN	SET	SET	BEI	LST	LNKS	ACT	MES	DIS	SLSCI	NIS
lsn1	11111		scr1	1	1	yes	a	1	on	off	off	---	off
lsn2	11112		scr2	1	2	no	c	3	on	on	on	---	off
lsn3	11113		scr3	1	3	yes	c	5	on	off	off	---	off
lsn5	10685		scr1	1	3	yes	a	4	on	off	off	---	off

Link set table is ( 13 of 1024) 1% full

2. Display the point code and capability point code of the EAGLE 5 ISS by using the **rtrv-sid** command.

**NOTE: If the APC of an existing linkset is not being changed, skip steps 2, 3, and 4, and go to step 5.**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
PCA          PCI          PCN          CLLI          PCTYPE
001-001-001  3-150-4          13482        rlghncxa03w  OTHER
                s-3-150-4        s-13482
CPCA
002-002-002  002-002-003     002-002-004  002-002-005
002-002-006  002-002-007     002-002-008  002-002-009
004-002-001  004-003-003     144-212-003
CPCA (LNP)
005-005-002  005-005-004     005-005-005
CPCI
1-001-1      1-001-2          1-001-3      1-001-4
CPCN
02091        02092            02094        02097
02191        02192            11177
```

If you wish to use ITU-I or ITU-N spare point codes with GSM MAP Screening, and the **rtrv-sid** output does not show any ITU-I or ITU-N spare point codes, add ITU-I and ITU-N spare point codes, as necessary, to the self identification of the EAGLE 5 ISS by performing the “Changing the Self-Identification of the EAGLE 5 ISS” procedure in the *Database Administration Manual - SS7*.

3. Display the point codes in the destination point code table by using the **rtrv-dstn** command with the linkset’s adjacent point code.

For this example, enter these commands.

```
rtrv-dstn:dpci=3-150-4
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
DPCI          CLLI          BEI ELEI  ALIASA          ALIASN/N24  DOMAIN
3-150-4      lsi7c1li     yes ---  -----  -----  SS7
                SPC          NCAI
                -----  ----
```

```
rtrv-dstn:dpcn=10685
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
DPCN          CLLI          BEI ELEI  ALIASA          ALIASI          DOMAIN
10685        lsn5c1li     yes ---  -----  -----  SS7
                SPC          NCAI
                -----  ----
```

If the point code specified in the **rtrv-dstn** command in this step is not in the database, the following message is displayed.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
DPCA          CLLI          BEI ELEI  ALIASI          ALIASN/N24  DOMAIN
```

No destinations meeting the requested criteria were found

Destination table is (28 of 2000) 1% full

If a linkset is being added to the database, or the adjacent point code of the linkset is being changed, and the adjacent point code is not shown in the **rtrv-dstn** command output, go to the “Adding a Destination Point Code” procedure in the *Database Administration Manual - SS7* and add the adjacent point code to the destination point code table.

**NOTE: An ANSI point code can be used as the APC of a linkset for GSM MAP Screening only if the Enhanced GSM MAP Screening feature is enabled and on.**

4. The adjacent point code of the linkset cannot be the DPC of any exception route.

**NOTE: If the adjacent point code was added in step 3, skip step 4 and go to step 5.**

Verify that the adjacent point code of the new linkset is not the DPC of any exception route by entering the **rtrv-rtx** command with the **dpc/dpca/dpci/dpcn/dpcn24** parameter. The **dpc/dpca/dpci/dpcn/dpcn24** parameter value is the adjacent point code value that will be specified for the new linkset. For this example, enter this command.

**rtrv-rtx:dpci=3-150-4**

This is an example of the possible output.

```

r1ghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
  DPCI          RTX-CRITERIA          LSN          RC          APC
  3-150-4          OPCI
                    4-050-1                    lsi2          20          1-111-2
DESTINATION ENTRIES ALLOCATED:    2000
  FULL DPC(s):                    13
  EXCEPTION DPC(s):                5
  NETWORK DPC(s):                  0
  CLUSTER DPC(s):                  1
  TOTAL DPC(s):                    19
  CAPACITY (% FULL):               1%
ALIASES ALLOCATED:                12000
  ALIASES USED:                    0
  CAPACITY (% FULL):               0%
X-LIST ENTRIES ALLOCATED:         500
    
```

If the adjacent point code of the linkset is not the DPC of a route exception table entry, no entries are displayed in the **rtrv-rtx** output, but a summary of the point code quantities is displayed, as shown in the following output example.

```

r1ghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
  DESTINATION ENTRIES ALLOCATED:    2000
  FULL DPC(s):                    15
  EXCEPTION DPC(s):                5
  NETWORK DPC(s):                  0
  CLUSTER DPC(s):                  1
  TOTAL DPC(s):                    21
  CAPACITY (% FULL):               1%
ALIASES ALLOCATED:                12000
  ALIASES USED:                    0
  CAPACITY (% FULL):               0%
X-LIST ENTRIES ALLOCATED:         500
    
```

If the point code specified in this step is shown in the **DPCA/DPCI/DPCN/DPCN24** columns in this step, the point code value cannot be used as an adjacent point code unless one of two actions are taken:

- Choose another adjacent point code value and repeat steps 2, 3, and 4.
- Remove all the entries displayed in this step by performing the “Removing a Route Exception Entry” procedure in the *Database Administration Manual - SS7*.

5. Verify that the GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893013201
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
GSM Map Screening (GMS)	893013201	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) procedure to enable and turn on the GSM MAP screening feature.

- Verify that the Enhanced GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the Enhanced GSM MAP Screening feature.

**NOTE: If ANSI point codes are not being used, skip step 6 and go to step 7.**

Enter this command.

```
rtrv-ctrl-feat:partnum=893012401
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Enhanced GMS (EGMS)	893012401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the Enhanced GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) procedure to enable and turn on the Enhanced GSM MAP screening feature.

- Display the current linkset configuration of the linkset to be changed using the **rtrv-ls** command with the linkset name.

**NOTE: If no existing linksets are being changed, skip step 7 and go to step 8.**

For this example, enter this command.

```
rtrv-ls:lsn=lsn4
```

This is an example of the possible output.

```
rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0
LSN          APCN   (SS7)  SCRN  SET SET BEI LST LNKS ACT MES DIS SLSCI NIS
```

```

lsn4          09786          scr3 1 2 no a 4 on off off no on

CLLI          TFATCABMLQ MTPRSE ASL8 SLRSRB ITUTFR GSMSCRN
lsn4clli     1          --- --- 1 on on

IPGWAPC MATELSN IPTPS LSUSEALM SLKUSEALM GTTMODE
no          ----- --- --- --- CdPA

          L2T          L1          PCR PCR
          SET BPS MODE TSET ECM N1 N2
1205 b 0 LIMDS0 1 56000 --- --- BASIC --- -----
1213 b 1 LIMOCU 1 56000 --- --- BASIC --- -----
1211 a 2 LIMDS0 1 56000 --- --- BASIC --- -----
1207 b 3 LIMV35 1 64000 DCE OFF BASIC --- -----

```

Link set table is ( 21 of 1024) 2% full

8. Add the new linkset to the database using the **ent-ls** command.

**NOTE: If you are not adding a new linkset to the database, skip step 8 and go to step 9.**

For this example, enter these commands.

```
ent-ls:lsn=lsn5:apcn=10685:lst=a:gsmscrn=on
```

```
ent-ls:lsn=lsi7:apci=3-150-4:lst=a:gsmscrn=on
```

**NOTE: An ANSI point code can be used as the APC of a linkset for GSM MAP Screening only if the Enhanced GSM MAP Screening feature is enabled and on.**

**The apci parameter value can be either an ITU-I point code or an ITU-I spare point code.**

**The apcn parameter value can be either an ITU-N point code or an ITU-N spare point code.**

When each of these commands have successfully completed, this message should appear.

```

rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 36.0.0
Link set table is ( 21 of 1024) 2% full
ENT-LS: MASP A - COMPLTD

```

9. Change the **gsmscrn** parameter value in the existing linkset in the database using the **chg-ls** command.

**NOTE: If you are not changing an existing linkset in the database, skip step 9 and go to step 10.**

For this example, enter this command.

```
chg-ls:lsn=lsn4:gsmscrn=on
```

**NOTE: The gsmscrn parameter can be specified for a linkset with an ANSI APC only if the Enhanced GSM MAP Screening feature is enabled and on.**

When this commands has successfully completed, this message should appear.

```

rlghncxa03w 06-10-17 16:23:21 GMT EAGLE5 36.0.0
Link set table is ( 21 of 1024) 2% full
CHG-LS: MASP A - COMPLTD

```

10. Verify the changes using the **rtrv-ls** command specifying the linkset name specified in either steps 8 or 9 with the **lsn** parameter.

For this example, enter these commands.

```
rtrv-ls:lsn=lsn4
```

This is an example of the possible output.

```

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

          L3T SLT          GWS GWS GWS

```

```

LSN          APCN  (SS7)  SCRN  SET  SET  BEI  LST  LNKS  ACT  MES  DIS  SLSCI  NIS
lsn4        09786          scr3  1   2   no  a   4   on  off  off  no   on

          CLLI          TFATCABMLQ  MTPRSE  ASL8  SLRSRB  ITUTFR  GSMSCRN
lsn4c11i    1          ---      ---   1      on      on

IPGWAPC  MATELSN          IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
no        -----  ---   ---      ---      CdPA

          L2T          L1          PCR  PCR
          SET  BPS  MODE  TSET  ECM  N1  N2
1205  b   0  LIMDS0  1   56000  ---  ---  BASIC  ---  -----
1213  b   1  LIMOCU  1   56000  ---  ---  BASIC  ---  -----
1211  a   2  LIMDS0  1   56000  ---  ---  BASIC  ---  -----
1207  b   3  LIMV35  1   64000  DCE  OFF  BASIC  ---  -----

```

Link set table is ( 21 of 1024) 2% full

### **rtrv-ls:lsn=lsn5**

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

```

          L3T  SLT          GWS  GWS  GWS
LSN          APCN  (SS7)  SCRN  SET  SET  BEI  LST  LNKS  ACT  MES  DIS  SLSCI  NIS
lsn5        10685          none  1   2   no  a   0   off  off  off  no   off

          CLLI          TFATCABMLQ  MTPRSE  ASL8  SLRSRB  ITUTFR  GSMSCRN
lsn5c11i    1          ---      ---   1      on      on

IPGWAPC  MATELSN          IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
no        -----  ---   ---      ---      CdPA

```

Link set table is ( 21 of 1024) 2% full

### **rtrv-ls:lsn=lsi7**

This is an example of the possible output.

rlghncxa03w 06-10-17 11:43:04 GMT EAGLE5 36.0.0

```

          L3T  SLT          GWS  GWS  GWS
LSN          APCI  (SS7)  SCRN  SET  SET  BEI  LST  LNKS  ACT  MES  DIS  SLSCI  NIS
lsi7        3-150-4          none  1   2   no  a   0   off  off  off  no   off

          CLLI          TFATCABMLQ  MTPRSE  ASL8  SLRSRB  ITUTFR  GSMSCRN
lsn7c11i    1          ---      ---   1      off     on

IPGWAPC  MATELSN          IPTPS  LSUSEALM  SLKUSEALM  GTTMODE
no        -----  ---   ---      ---      CdPA

```

Link set table is ( 21 of 1024) 2% full


## **11. Back up the new changes using the `chg-db:action=backup:dest=fixed` command.**


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


```

Flowchart 5-3. Configuring a Linkset for the GSM MAP Screening Feature









## Changing the System-Wide GSM MAP Screening Options

The GSM MAP screening options can be changed with the **chg-stpopts** command after the GSM MAP screening feature has been activated. The **chg-stpopts** command contains two options for GSM MAP screening.

- **GSMDFLT** – GSM MAP screening default action – Allows the user to specify the default screening action (PASS or DISCARD) that occurs when a MAP operations code contained in the MSU is not found in the GSM MAP operations code table.
- **gsmdecerr** – GSM MAP screening decode error action – Allows the user to specify the default screening action (PASS or DISCARD) that occurs when an error is detected in the TCAP layer of the MSU being screened. Such errors included an invalid value for a parameter, length error, missing data, and so on.

The GSM MAP Screening feature must be enabled and on before performing this procedure. Use the **rtrv-ctrl1-feat** command to verify the status of the GSM MAP Screening feature. If the GSM MAP Screening feature is not enabled and off, go to the [Activating the GSM MAP Screening Feature](#) procedure to enable and turn on the GSM MAP screening feature.

When the GSM MAP screening feature is activated, the values for the **gsmdflt** and **gsmdecerr** parameters are set to **pass**. The current values for these options can be verified with the **rtrv-stpopts** command.

**Procedure**

1. Verify that the GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the GSM MAP Screening feature.

Enter this command.

**rtrv-ctrl-feat:partnum=893013201**

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
GSM Map Screening (GMS)	893013201	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) procedure to enable and turn on the GSM MAP screening feature.

2. Display the existing values for the **gsmdflt** and **gsmdecerr** parameters by entering the **rtrv-stpopts** command.

The value for the **gsmdflt** parameter is shown in the **GSMSDFLT** field. The value for the **gsmdecerr** parameter is shown in the **GSMDECERR** field. This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:02:05 GMT EAGLE5 36.0.0
STP OPTIONS
-----
GSMDFLT          PASS
GSMDECERR       PASS
```

**NOTE:** The **rtrv-stpopts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-stpopts** command, see the **rtrv-stpopts** command description in the *Commands Manual*.

3. Change either the GSM MAP screening default action (**gsmdflt**) and GSM MAP screening decode error action (**gsmdecerr**) options using the **chg-stpopts** command.

If you wish to change both options, enter the **chg-stpopts** command with the **gsmdflt** and **gsmdecerr** parameters as shown in this example.

**chg-stpopts:gsmdflt=discard:gsmdecerr=discard**

If you wish to change only one option, enter the **chg-stpopts** command with either the **gsmdflt** and **gsmdecerr** parameters as shown in these examples.

**chg-stpopts:gsmdflt=discard**

**chg-stpopts:gsmdecerr=discard**

For this example, the GSM MAP screening error code action is being changed.

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 00:22:57 GMT EAGLE5 36.0.0
CHG-STPOPTS: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-stpopts** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:02:05 GMT EAGLE5 36.0.0
STP OPTIONS
-----
GSMDFLT          PASS
GSMDECERR        DISCARD
```


**NOTE:** The **rtrv-stpopts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-stpopts** command, see the **rtrv-stpopts** command description in the *Commands Manual*.

5. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-4. Changing the System-Wide GSM MAP Screening Options



## Adding a GSM Subsystem Number Screening Entry

Use this procedure to provision the origination and destination SSNs (subsystem numbers) to be screened with the GSM MAP screening feature using the **ent-gsmssn-scrn** command.

The **ent-gsmssn-scrn** command uses these parameters.

**:ssn** – The subsystem number contained in either the calling party address (CGPA) or the called party address (CDPA) contained in the MAP message.

**:type** – The type of SSN, either an origination SSN (**orig**) or a destination SSN (**dest**). The origination SSN is found in the calling party address of the message. The destination SSN is found in the called party address of the message.

The GSM MAP Screening feature must be enabled and on before performing this procedure. Use the **rtrv-ctrl-feat** command to verify the status of the GSM MAP Screening feature. If the GSM MAP Screening feature is not enabled and off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the GSM MAP screening feature.

You cannot specify an **ssn** and **type** parameter combination that already exists in the database.

This examples used in this procedure are based on the examples shown in [Table 5-4](#) .

**Table 5-4. Example GSM MAP Screening SSN Configuration Table**

SSN	TYPE
250	orig
251	dest

### Procedure

1. Verify that the GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893013201
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

```
Feature Name          Partnum    Status  Quantity
GSM Map Screening (GMS) 893013201 on      ----
```

The following features have been temporarily enabled:

```
Feature Name          Partnum    Status  Quantity  Trial Period Left
Zero entries found.
```

The following features have expired temporary keys:

```
Feature Name          Partnum
Zero entries found.
```

If the GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the GSM MAP screening feature.

2. Display the GSM MAP Screening subsystem numbers in the database using the **rtrv-gsmssn-scrn** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
SSN  ORIG  DEST
  2   Yes   No
 10   Yes   Yes
GSM Map Screening table is (2 of 512) 1% full
RTRV-GSMSSN-SCRN: MASP A - COMPLTD
```

3. Add the new subsystem numbers to be screened to the database with the **ent-gsmssn-scrn** command.

For this example, enter these commands:

```
ent-gsmssn-scrn:ssn=250:type=orig
```

```
ent-gsmssn-scrn:ssn=251:type=dest
```

When each of these commands has successfully completed, this message appears.

```
rlghncxa03w 06-10-07 00:29:31 GMT EAGLE5 36.0.0
ENT-GSMSSN-SCRN: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-gsmssn-scrn** command.


This is an example of the possible output.

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
SSN  ORIG  DEST
   2  Yes   No
  10  Yes   Yes
 250  Yes   No
 251  No    Yes
GSM Map Screening table is (4 of 512) 1% full
RTRV-GSMSSN-SCRN: MASP A - COMPLTD
```

5. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

**Flowchart 5-5.** Adding a GSM Subsystem Number Screening Entry

## Removing a GSM Subsystem Number Screening Entry

Use this procedure to remove an SSN (subsystem number) from the GSM MAP SSN screening table using the **dlt-gsmssn-scrn** command.

The **dlt-gsmssn-scrn** command uses these parameters.

**:ssn** – The subsystem number contained in either the calling party address (CGPA) or the called party address (CDPA) contained in the MAP message.

**:type** – The type of SSN, either an origination SSN (**orig**) or a destination SSN (**dest**). The origination SSN is found in the calling party address of the message. The destination SSN is found in the called party address of the message.

The **ssn** and **type** parameter combination specified in the **dlt-gsmssn-scrn** command must be in the database.

## Procedure

---

1. Display the GSM MAP Screening subsystem numbers in the database using the **rtrv-gsmssn-scrn** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
SSN  ORIG  DEST
   2   Yes  No
  10   Yes  Yes
 250   Yes  No
 251   No   Yes
GSM Map Screening table is (4 of 512) 1% full
RTRV-GSMSSN-SCRN: MASP A - COMPLTD
```

2. Remove the subsystem number from the database with the **dlt-gsmssn-scrn** command.

For this example, enter this command.

```
dlt-gsmssn-scrn:ssn=010:type=orig
```

```
dlt-gsmssn-scrn:ssn=251:type=dest
```

When each of these commands has successfully completed, this message appears.

```
rlghncxa03w 06-10-07 00:29:31 GMT EAGLE5 36.0.0
DLT-GSMSSN-SCRN: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-gsmssn-scrn** command.


This is an example of the possible output.

```
rlghncxa03w 06-10-07 00:28:31 GMT EAGLE5 36.0.0
SSN  ORIG  DEST
   2   Yes  No
  10   No   Yes
 250   Yes  No
GSM Map Screening table is (3 of 512) 1% full
RTRV-GSMSSN-SCRN: MASP A - COMPLTD
```

4. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

**Flowchart 5-6.** Removing a GSM Subsystem Number Screening Entry

## Adding a GSM MAP Screening Operation Code

Use this procedure to provision the concerned GSM MAP screening operation codes and the default screening action for the operation code in the database using the **ent-gsms-opcode** command. This procedure allows the user to provision a list of all operation codes that the EAGLE 5 ISS uses in performing GSM screening.

The **ent-gsms-opcode** command uses these parameters.

**:opcode** – The MAP operation code. This parameter refers to the actual decimal value of the MAP operation codes from the TCAP layer of GSM MAP messages.

**:opname** – The name of operation code. This parameter lets the user give a meaningful name to the MAP operation code (**opcode**) entered. This name is then used by subsequent commands such as **dlt-/chg-gsms-opcode** and **ent-/chg-/dlt-/rtrv-gsmmap-scrn**.

**:dfltact** – The default screening action. This parameter lets the user define a default screening action for the MAP operation code (**opcode**) entered. The default screening action is used when a matching CGPA (calling party) address is not found in the GSM MAP screening table or when a CGPA address is found but does not have the correct **npv** and **naiv** parameters as defined by the **ent-gsmmap-scrn** command. One of these actions can be assigned.

- **pass** – Route the message as normal to the destination.
- **discard** – The MSU is to be discarded.
- **atierr** – An ATI (Any Time Interrogation) reject message is generated. This option is only valid for ATI MAP operation codes.
- **route** – Route the message as normal to the original destination node.

- **forward** – Route the original message to the forward node. The original message is not sent to the original node. If, however, the forwarded node is not available for routing then the MSU is routed to the original node.
- **duplicate** – Route the message as normal to the original destination and route a copy of the original message to the duplicate node.
- **dupdisc** – Duplicate and discard – Route the original message to the duplicate node. The original message is not sent to the original node.

**:pc/pca/pci/pcn/pcn24** – The ANSI point code (**pc/pca**), ITU-I point code or ITU-I spare point code (**pci**), 14-bit ITU-N point code or 14-bit ITU-N spare point code (**pcn**), or 24-bit ITU-N point code (**pcn24**) of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both. To specify the **pc/pca** parameters, the Enhanced GSM MAP Screening feature must be enabled and on.

**:ssn** – The subsystem number of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions

**:force** – The mated application override. Is the GSM MAP screening operation code to be entered without a mated application in the database (**yes** or **no**)?

**:mapset** – The MAP set ID, shown in the **rtrv-map** command. This parameter can be specified only if the Flexible GTT Load Sharing feature is enabled. The status of the Flexible GTT Load Sharing feature is shown in the **rtrv-ctrl-feat** output. To enable the Flexible GTT Load Sharing feature, perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation* .

If the Flexible GTT Load Sharing feature is not enabled:

- The **mapset** parameter cannot be used.
- The **pc/pca/pci/pcn/pcn24** and **ssn** values must be shown in the **rtrv-map** output, or else the **force=yes** parameter must be specified.

If the Flexible GTT Load Sharing feature is enabled:

- The **mapset** parameter can be specified only for GSM OPCODE entries that contain point code and subsystem entries. The **dfltact** parameter value for these GSM OPCODE entries can be either **forward**, **duplicate**, or **dupdisc**.
- If the **dfltact** parameter value for the GSM OPCODE entry will be **forward**, **duplicate**, or **dupdisc**, and the **pc/pca/pci/pcn/pcn24** and **ssn** parameters will be specified for the GSM OPCODE entry, the **mapset** parameter must be specified.
- The **force=yes** parameter can be used only if the MAP set assigned to the GSM OPCODE entry is the default MAP set.
- If the MAP set assigned to the GSM OPCODE entry is a MAP set other than the default MAP set, the **force=yes** parameter cannot be used. The point code and subsystem contained in the GSM OPCODE entry must be in the MAP set assigned to the GSM OPCODE entry.

- If the default MAP set is assigned to the GSM OPCODE entry and the **force=yes** parameter is not specified, the point code and subsystem contained in the GSM OPCODE entry must be in the default MAP set.

The GSM MAP Screening feature must be enabled and on before performing this procedure. Use the **rtrv-ctrl-feat** command to verify the status of the GSM MAP Screening feature. If the GSM MAP Screening feature is not enabled and off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the GSM MAP screening feature.

The **opcode** parameter value must be a number between 0 and 255 or an asterisk (\*). The **opcode=\*** parameter can be specified only if the Enhanced GSM MAP Screening feature is enabled and on. Use the **rtrv-ctrl-feat** command to verify the status of the Enhanced GSM MAP Screening feature. If the Enhanced GSM MAP Screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the Enhanced GSM MAP screening feature.

The **opname** parameter value must be no more than 8 alphanumeric characters.

The word **none** cannot be used as a value for the **opname** parameter.

The **dfltact=atierr** parameter cannot be specified unless the value of the operation code (**opcode**) referenced by the **opname** parameter value is 71. The **atierr** option is only valid for ATI MAP operation codes; **opcode=71** signifies an ATI MAP operation code.

The value specified for the **opcode** parameter cannot already exist in the GSM MAP operation code table.

The value specified for the **opname** parameter cannot already be used in the GSM MAP operation code table.

The **pc/pca/pci/pcn/pcn24** and **ssn** values must be shown in the **rtrv-map** output, or else the **force=yes** parameter must be specified. If the **pc/pca/pci/pcn/pcn24** and **ssn** values are not shown in the **rtrv-map** output, and a new mated application is to be added, perform one of the “Provisioning a Mated Application” procedures in the *Database Administration Manual - Global Title Translation* and add the required mated application with the **pc/pca/pci/pcn/pcn24** and **ssn** values:

The **force=yes** parameter can be specified only with the **pc/pca/pci/pcn/pcn24** and **ssn** parameters.

The **dfltact=forward**, **dfltact=duplicate**, or **dfltact=dupdisc** parameters can be specified only with the **pc/pca/pci/pcn/pcn24** and **ssn** parameters. If the **pc/pca/pci/pcn/pcn24** and **ssn** parameters are specified, the **dfltact=forward**, **dfltact=duplicate**, or **dfltact=dupdisc** parameters must be specified.

The **pc/pca/pci/pcn/pcn24** and **ssn** parameters must be specified together.

The **pc/pca/pci/pcn/pcn24** parameter values must be the DPC of a route and a proxy point code cannot be assigned to the point code. The **pc/pca** parameter value must be a full point code. The **pc/pca** parameter value can be a member of a cluster point code when that cluster point code is the DPC of a route. This can be verified with the **rtrv-rte** command. If the **pc/pca/pci/pcn/pcn24** value is not shown in the **rtrv-rte** as the DPC of a route, go to the “Adding a Route Containing an SS7 DPC” procedure in the *Database Administration Manual - SS7* and add a new route containing the **pc/pca/pci/pcn/pcn24** value. To verify whether or not a proxy point code is assigned to the **pc/pca/pci/pcn/pcn24** value, enter the **rtrv-dstn** command with the point code value. If a proxy point code is assigned to the point code, choose another point code.

This examples used in this procedure are based on the examples shown in [Table 5-5](#).

**Table 5-5. Example GSM MAP Screening Operation Code Configuration Table**

OPCODE	OPNAME	DFLTACT	PC/PCA/PCI/PCN/PCN24	SSN	MAPSET
100	pass100	pass	N/A	N/A	N/A
150	discard1	discard	N/A	N/A	N/A
71	ati	atierr	N/A	N/A	N/A
25	route25	route	N/A	N/A	N/A
139	fwd139	forward	3-159-7	128	dflt
187	dup187	duplicate	11519	79	10
93	dd93	dupdisc	5-25-3	200	20
36	for1	forward	002-002-002	10	25
*	star	pass	N/A	N/A	N/A

**Procedure**

1. Verify that the GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893013201
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

```
Feature Name          Partnum    Status    Quantity
GSM Map Screening (GMS) 893013201 on        ----
```

The following features have been temporarily enabled:

```
Feature Name          Partnum    Status    Quantity    Trial Period Left
Zero entries found.
```

The following features have expired temporary keys:

```
Feature Name          Partnum
Zero entries found.
```

If the GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the GSM MAP screening feature.

**NOTE: If the opcode=\* or the pc/pca parameters are not being used in this procedure, skip step 2, and go to step 3.**

2. Verify that the Enhanced GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the Enhanced GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893012401
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
```

The following features have been permanently enabled:

Feature Name	Partnum	Status	Quantity
Enhanced GSM (EGMS)	893012401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the Enhanced GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the Enhanced GSM MAP screening feature.

3. Display the GSM MAP screening operation codes in the database using the **rtrv-gsms-opcode** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

OPCODE	OPNAME	DFLTACT	PCA	SSN
OPCODE	OPNAME	DFLTACT	PCI	SSN
OPCODE	OPNAME	DFLTACT	PCN	SSN
OPCODE	OPNAME	DFLTACT	PCN24	SSN
OPCODE	OPNAME	DFLTACT		
22	sri	disc		
50	pass50	pass		

GSMMS OPCODE Table (2 of 257) is 1% full

If the Flexible GTT Load Sharing feature is enabled, the **MAPSET** field is shown in the **rtrv-gsms-opcode** output. This is an example of the possible output

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

OPCODE	OPNAME	DFLTACT	PCA	SSN	MAPSET
OPCODE	OPNAME	DFLTACT	PCI	SSN	MAPSET
OPCODE	OPNAME	DFLTACT	PCN	SSN	MAPSET
OPCODE	OPNAME	DFLTACT	PCN24	SSN	MAPSET
OPCODE	OPNAME	DFLTACT			
22	sri	disc			
50	pass50	pass			

GSMMS OPCODE Table (2 of 257) is 1% full

4. Perform one of these actions.

- If the **dfltact** parameter value will be either **pass**, **discard**, **route**, or **atierr**, skip steps 4 through 8, and continue the procedure with step 9.
- If the **dfltact** parameter value will be either **forward**, **duplicate**, or **dupdisc**, perform one of these actions.
  - To use a point code and a MAP set from the mated application table, and MAP sets are not shown in the **rtrv-gsms-opcode** output in step 3, the Flexible GTT Load Sharing Feature must be

enabled. Perform the "Activating the Flexible GTT Load Sharing Feature" procedure in the *Database Administration Manual - Global Title Translation* and enable the Flexible GTT Load Sharing feature. After enabling the Flexible GTT Load Sharing feature, skip steps 5 and 6 and continue the procedure with step 7.

- To use a point code and a MAP set from the mated application table, and MAP sets are shown in the **rtrv-gsms-opcode** output in step 3, skip steps 5 and 6 and continue the procedure with step 7.
- To use a point code in the mated application table, but without using a MAP set, and MAP sets are not shown in the **rtrv-gsms-opcode** output in step 3, skip steps 5 and 6 and continue the procedure with step 7.
- To use a point code that is not in the mated application table, the **force=yes** parameter must be specified with the **ent-gsms-opcode** command. A proxy point code cannot be assigned to this point code. If the Flexible GTT Load Sharing feature is enabled, the **force=yes** parameter can be used only if the default MAP set is assigned to the GSM OPCODE entry. Continue the procedure with step 5.

5. Display the destination point codes in the database by entering the **rtrv-dstn** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

DPCA	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
001-207-000	-----	no	---	-----	-----	SS7
001-001-001	-----	no	---	-----	-----	SS7
001-001-002	-----	no	---	-----	-----	SS7
001-005-000	-----	no	---	-----	-----	SS7
001-007-000	-----	no	---	-----	-----	SS7
008-012-003	-----	no	---	-----	-----	SS7
003-002-004	-----	no	---	-----	-----	SS7
009-002-003	-----	no	---	-----	-----	SS7
010-020-005	-----	no	---	-----	-----	SS7

DPCI	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
1-207-0	-----	no	---	-----	-----	SS7
0-015-0	-----	no	---	-----	-----	SS7
0-017-0	-----	no	---	-----	-----	SS7
1-011-1	-----	no	---	-----	-----	SS7
1-011-2	-----	no	---	-----	-----	SS7

DPCN	CLLI	BEI	ELEI	ALIASA	ALIASI	DOMAIN
DPCN24	CLLI	BEI	ELEI	ALIASA	ALIASI	DOMAIN

```
Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full
```

If the required point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* to add the required point code. A proxy point code cannot be assigned to the point code.

After the new point code has been added, skip steps 6 through 8 and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 9.

6. Display the point code that will be assigned to the mated application by using the **rtrv-dstn** command and specifying the point code. For this example, enter this command.

```
rtrv-dstn:dpca=010-020-005
```

This is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA          CLLI          BEI ELEI  ALIASI          ALIASN          DOMAIN
010-020-005  ----- no --- -----
                                     -----
                                     SS7

PPC           NCAI           PRX
009-002-003  ----          no

```

```

Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full

```

If the adjacent point code is not shown in the **rtrv-dstn** command output, the following output is displayed.

```

DPCA          CLLI          BEI ELEI  ALIASI          ALIASN/N24      DOMAIN

No destinations meeting the requested criteria were found

Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full

```

A proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code. If a proxy point code is shown in this step, choose another point code from the **rtrv-dstn** output in the previous step and repeat this step.

If the point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* and add the adjacent point code to the destination point code table.

After the new point code has been added, skip steps 7 and 8 and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 9.

- The point code and subsystem number being assigned to the GSM OPCODE must be in the mated application table.

Enter the **rtrv-map** command with the **pc/pca/pci/pcn/pcn24** and **ssn** values that will be specified with the **ent-gsms-opcode** command in step 9.

If the Flexible GTT Load Sharing feature is not enabled, for this example, enter these commands.

```
rtrv-map:pci=3-159-7:ssn=128
```

This is an example of the possible output.

```

rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0

MAP TABLE IS  2 % FULL      (20 of 1024)

PCI           Mate PCI       SSN RC MULT SRM MRC GRP NAME SSO
3-159-7              128 10  SOL  --- --- GRP01  OFF

```

```
rtrv-map:pcn=11519:ssn=79
```

This is an example of the possible output.

```

rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0

MAP TABLE IS  2 % FULL      (20 of 1024)

PCN           Mate PCN       SSN RC MULT SRM MRC GRP NAME SSO
11519              79 10  SOL  --- --- GRP01  ON

```

**rtrv-map:pci=5-25-3:ssn=200**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCI          Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
5-25-3              200 10  SOL --- --- GRP01  ON
```

**rtrv-map:pca=002-002-002:ssn=10**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
E2452 Cmd Rej: Remote point code does not exist in MAP table
```

If the Flexible GTT Load Sharing feature is enabled:

- The **mapset** parameter must be specified with the **ent-gsms-opcode** command in step 9.
- The point code and subsystem contained in the GSM OPCODE entry must be in the MAP set assigned to the GSM OPCODE entry.

For this example, enter these commands.

**rtrv-map:pci=3-159-7:ssn=128**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCI          Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
MAPSET ID=DFLT
3-159-7              128 10  SOL --- --- GRP01  OFF
```

**rtrv-map:pcn=11519:ssn=79**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCN          Mate PCN      SSN RC MULT SRM MRC GRP NAME SSO
MAPSET ID=10
11519              79 10  SOL --- --- GRP01  ON
```

**rtrv-map:pci=5-25-3:ssn=200**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCI          Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
MAPSET ID=20
5-25-3              200 10  SOL --- --- GRP01  ON
```

**rtrv-map:pca=002-002-002:ssn=10**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
E2452 Cmd Rej: Remote point code does not exist in MAP table
```

If the point code and subsystem number is not shown in the **rtrv-map** output, perform one of the “Provisioning a Mated Application” procedures in the *Database Administration Manual - Global Title Translation* and add the required point code and subsystem number to the mated application table.

8. The point code specified with the **ent-gsms-opcode** command must be the DPC of a route.

If the point code specified with the **ent-gsms-opcode** command is an ANSI point code, the point code can be a member of a cluster point code when that cluster point code is the DPC of a route.

Enter the **rtrv-rte** command with the **dpc** parameter specifying the point code to be used with the **ent-gsms-opcode** command to verify whether or not the point code is the DPC of a route. For this example, enter these commands.

```
rtrv-rte:dpci=3-159-7
```

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
DPCI      ALIASN/N24      ALIASA      LSN          RC          APC
3-159-7   12111                240-111-111 ls100001     10          1-234-5
                                     ls100002     10          1-234-6
                                     ls100003     20          1-234-7
                                     ls100004     30          1-234-1
                                     ls100005     40          1-234-2
                                     ls100006     50          1-234-3
RTX:No    CLLI=idp1
```

```
rtrv-rte:dpcn=11519
```

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
DPCN      ALIASA      ALIASI      LSN          RC          APC
11519     011-222-111 0-001-1     ls200001     10          11111
                                     ls200002     10          11112
                                     ls200003     20          11113
                                     ls200004     30          11114
                                     ls200005     40          11115
                                     ls200006     50          11116
RTX:No    CLLI=ndp1
```

```
rtrv-rte:dpci=5-25-3
```

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
DPCI      ALIASN/N24      ALIASA      LSN          RC          APC
5-25-3    07659           240-039-150 ls100001     10          5-25-3
                                     ls100002     10          3-250-6
                                     ls100003     20          7-34-7
                                     ls100004     30          6-98-1
                                     ls100005     40          3-142-2
                                     ls100006     50          1-178-3
RTX:No    CLLI=idp1
```

```
rtrv-rte:dpca=002-002-002
```

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
DPKA      ALIASI      ALIASN/N24      LSN          RC          APCA
```

```
002-002-002 ----- lsn1      10      002-002-002
                    RTX:No  CLLI=-----
```

If the point code is not shown in the **rtrv-rte** output, or, if the point code is an ANSI point code, the point code is not a member of a cluster point code when that cluster point code is the DPC of a route, go to the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database.

9. Add the new GSM MAP screening operation codes to the database with the **ent-gsms-opcode** command. For this example, enter these commands:

```
ent-gsms-opcode:opcode=100:opname=pass100:dfltact=pass
```

```
ent-gsms-opcode:opcode=150:opname=discard1:dfltact=discard
```

```
ent-gsms-opcode:opcode=71:opname=ati:dfltact=atierr
```

```
ent-gsms-opcode:opcode=25:opname=route25:dfltact=route
```

```
ent-gsms-
```

```
opcode:opcode=139:opname=fwd139:dfltact=forward :pci=3-159-7:ssn=128:ma
pset=df1t
```

```
ent-gsms-
```

```
opcode:opcode=187:opname=dup187:dfltact=duplicate :pcn=11519:ssn=79:map
set=10
```

```
ent-gsms-
```

```
opcode:opcode=93:opname=dd93:dfltact=dupdisc :pci=5-25-3:ssn=200:mapset
=20
```

```
ent-gsms-
```

```
opcode:opcode=36:opname=for1:dfltact=forward :pca=002-002-002:ssn=10:ma
pset=25
```

```
ent-gsms-opcode:opcode=*:opname=star1:dfltact=pass
```

When each of these commands has successfully completed, this message appears.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
ENT-GSMS-OPCODE: MASP A - COMPLTD
```

**NOTE:** See [Flowchart 5-7](#) ( Sheet 7) for the rules that apply to the **ent-gsms-opcode** command.

10. Verify the changes using the **rtrv-gsms-opcode** command and specifying the **opcode** parameter value used in step 9.

For this example, enter these commands.

```
rtrv-gsms-opcode:opcode=025
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME  DFLTACT
 25     route25  route
```

```
GSMMS OPCODE Table (11 of 257) is 4% full
```

```
rtrv-gsms-opcode:opcode=071
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT
 71     ati     atiterr
```

GSMMS OPCODE Table (11 of 257) is 4% full

**rtrv-gsms-opcode:opcode=093**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT PCI SSN MAPSET
 93     dd93   dupdc    5-25-3  200  20
```

GSMMS OPCODE Table (11 of 257) is 4% full

**rtrv-gsms-opcode:opcode=100**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT
 100    pass100 pass
```

GSMMS OPCODE Table (11 of 257) is 4% full

**rtrv-gsms-opcode:opcode=139**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT PCI SSN MAPSET
 139    fwd139 fwd      3-159-7  128  DFLT
```

GSMMS OPCODE Table (11 of 257) is 4% full

**rtrv-gsms-opcode:opcode=150**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT
 150    discard1 disc
```

GSMMS OPCODE Table (11 of 257) is 4% full

**rtrv-gsms-opcode:opcode=187**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT PCN SSN MAPSET
 187    dup187 dupl     11519   79   10
```

GSMMS OPCODE Table (11 of 257) is 4% full

**rtrv-gsms-opcode:opcode=36**

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT PCA SSN MAPSET
 36     for1   fwd      002-002-002  10  25
```

GSMMS OPCODE Table (11 of 257) is 4% full

```
rtrv-gsms-opcode:opcode=*
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE  OPNAME      DFLTACT
*        star        pass
```


```
GSMSMS OPCODE Table (11 of 257) is 4% full
```


11. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-7. Adding a GSM MAP Screening Operation Code














Notes:

1. The word "none" cannot be used as a value for the *opname* parameter.
2. The *pc/pca/pci/pcn/pcn24* value must be shown in the *rtrv-rte* output on Sheets 4 or 5 as the DPC of a route. The *pc/pca* value must be a full point code value. The *pc/pca* value can be a member of a cluster point code when that cluster point code is the DPC of a route. A proxy point code cannot be assigned to the point code.
3. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both.
4. To specify the *opcode=\* or pc/pca* parameters, the Enhanced GSM MAP Screening feature must be enabled and on.
5. If the Flexible GTT Load Sharing feature is not enabled, shown on Sheet 3:
  - The *mapset* parameter cannot be used.
  - The *pc/pca/pci/pcn/pcn24* and *ssn* values must be shown in the *rtrv-map* output on Sheet 4, otherwise, the *force=yes* parameter must be specified.
6. If the Flexible GTT Load Sharing feature is enabled, shown on Sheet 3:
  - The *mapset* parameter must be used.
  - The *force=yes* parameter can be used only if the MAP set assigned to the GSM OPCODE entry is the default MAP set.
  - If the MAP set assigned to the GSM OPCODE entry is a MAP set other than the default MAP set, the *force=yes* parameter cannot be used. The point code and subsystem contained in the GSM OPCODE entry must be in the MAP set assigned to the GSM OPCODE entry.
  - If the default MAP set is assigned to the GSM OPCODE entry and the *force=yes* parameter is not specified, the point code and subsystem contained in the GSM OPCODE entry must be in the default MAP set.

## Removing a GSM MAP Screening Operation Code

Use this procedure to remove GSM MAP screening operation codes and the default screening action for that operation code using the `dlt-gsms-opcode` command.

The `dlt-gsms-opcode` command uses only one parameter, **opname**. The value for the **opname** parameter is the user-defined name for the operation code shown in the `rtrv-gsms-opcode` command output.

The **opname** value being removed cannot be referenced by any GSM MAP screening entries (shown in the `rtrv-gsmmap-scrn` command output). Use the [Removing a GSM MAP Screening Entry](#) procedure to remove any GSM MAP screening entries that reference the **opname** name value being removed from the database.

### Procedure

1. Display the GSM MAP screening opcodes in the database using the `rtrv-gsms-opcode` command. This is an example of the possible output.

```
r1ghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

OPCODE	OPNAME	DFLTACT	PCA	SSN
36	for1	fwd	002-002-002	10

OPCODE	OPNAME	DFLTACT	PCI	SSN
93	dd93	dupdc	5-25-3	200
139	fwd139	fwd	3-159-7	128

OPCODE	OPNAME	DFLTACT	PCN	SSN
187	dup187	dup1	11519	79

OPCODE	OPNAME	DFLTACT	PCN24	SSN
--------	--------	---------	-------	-----

OPCODE	OPNAME	DFLTACT
22	sri	disc
25	route25	route
50	pass50	pass
71	ati	atierr
100	pass100	pass
150	discard1	disc
*	star	pass

GSMMS OPCODE Table (11 of 257) is 4% full

2. Display the GSM MAP screening entries that reference the **opname** value being removed from the database using the **rtrv-gsmmap-scrn** command specifying the **opname** parameter with the **opname** value being removed from the database. For this example, enter this command.

**rtrv-gsmmap-scrn:opname=sri**

This is an example of the possible output if the **rtrv-gsmmap-scrn** output contains no entries that reference the **opname** value being removed.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: sri

```
-----
```

SADDR	NP NAI FORBD ACT	PCA	SSN CGSR
SADDR	NP NAI FORBD ACT	PCI	SSN CGSR
SADDR	NP NAI FORBD ACT	PCN	SSN CGSR
SADDR	NP NAI FORBD ACT	PCN24	SSN CGSR
SADDR	NP NAI FORBD ACT	CGSR	

Range CgPA Entries for OPNAME: sri

```
-----
```

SADDR	EADDR	NP NAI FORBD ACT	PCA	SSN CGSR
SADDR	EADDR	NP NAI FORBD ACT	PCI	SSN CGSR
SADDR	EADDR	NP NAI FORBD ACT	PCN	SSN CGSR
SADDR	EADDR	NP NAI FORBD ACT	PCN24	SSN CGSR
SADDR	EADDR	NP NAI FORBD ACT	CGSR	

GSM Map Screening table is (1500 of 4000) 38% full

This is an example of the possible output if the **rtrv-gsmmap-scrn** output contains entries that reference the **opname** value being removed.

**rtrv-gsmmap-scrn:opname=sri**

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: sri

```
-----
```

SADDR	NP NAI FORBD ACT	PCA	SSN CGSR
SADDR	NP NAI FORBD ACT	PCI	SSN CGSR
SADDR	NP NAI FORBD ACT	PCN	SSN CGSR
SADDR	NP NAI FORBD ACT	PCN24	SSN CGSR
SADDR	NP NAI FORBD ACT	CGSR	

919462000000005 1 0 none pass sri1

Range CgPA Entries for OPNAME: sri

```

-----
SADDR          EADDR          NP NAI FORBD ACT    PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN24        SSN CGSR

SADDR          EADDR          NP NAI FORBD ACT    CGSR
91946188888888 9194619000000000 4 1 all pass sri2
91946200000000 9194630000000000 * * all disc sri3

```

GSM Map Screening table is (1500 of 4000) 38% full

If the GSM MAP screening entry in this step contains any CGPA entries, go to the [Removing a GSM MAP Screening Entry](#) procedure to remove the CGPA entries shown in this step.

3. Remove the GSM MAP opname value from the database using the **dlt-gsms-opcode** command.

For this example, enter this command.

```
dlt-gsms-opcode:opname=sri
```

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-07 00:29:31 GMT EAGLE5 36.0.0
DLT-GSMS-OPCODE: MASP A - COMPLTD
```

4. Verify the changes using the **rtrv-gsms-opcode** command with the **opname** parameter value specified in step 3. For this example, enter this command.

```
rtrv-gsms-opcode:opname=sri
```

This is an example of the possible output.


```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
E3892 Cmd Rej: OPNAME does not exist in the database
```

5. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 5-8. Removing a GSM MAP Screening Operation Code



## Changing a GSM MAP Screening Operation Code

Use this procedure to change the attributes of the GSM MAP screening operation codes using the **chg-gsms-opcode** command. The procedure allows you to change the default screening action and the operation-code name for a specific operation code. The **chg-gsms-opcode** command uses these parameters.

**:opname** – The user-defined name for the operation code shown in the **rtrv-gsms-opcode** command output.

**:nopname** – The new user-defined name for the operation code.

**:ndfltact** – The new default screening action.

- **pass** – Route the message as normal to the destination.
- **discard** – The MSU is to be discarded.

- **atierr** – An ATI (Any Time Interrogation) reject message is generated. This option is only valid for ATI MAP operation codes.
- **route** – Route the message as normal to the original destination node.
- **forward** – Route the original message to the forward node. The original message is not sent to the original node. If, however, the forwarded node is not available for routing then the MSU is routed to the original node.
- **duplicate** – Route the message as normal to the original destination and route a copy of the original message to the duplicate node.
- **dupdisc** – Duplicate and discard – Route the original message to the duplicate node. The original message is not sent to the original node.

**:npc/npca/npci/npcn/npcn24** – The new ANSI point code (**npc/npca**), new ITU-I point code or ITU-I spare point code (**npci**), new 14-bit ITU-N point code or 14-bit ITU-N spare point code (**npcn**), or new 24-bit ITU-N point code (**npcn24**) of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both. The **npc/npca** parameters can be specified only if the Enhanced GSM MAP Screening feature is enabled and on.

**:nssn** – The new subsystem number of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions

**:force** – The mated application override. Is the GSM MAP screening operation code to be entered without a mated application in the database (**yes** or **no**)?

**:nmapset** – The new MAP set ID, shown in the **rtrv-map** command. This parameter can be specified only if the Flexible GTT Load Sharing feature is enabled. The status of the Flexible GTT Load Sharing feature is shown in the **rtrv-ctrl-feat** output. To enable the Flexible GTT Load Sharing feature, perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation*.

If the Flexible GTT Load Sharing feature is not enabled:

- The **nmapset** parameter cannot be used.
- The **npc/npca/npci/npcn/npcn24** and **nssn** values must be shown in the **rtrv-map** output, or else the **force=yes** parameter must be specified.

If the Flexible GTT Load Sharing feature is enabled:

- If the current **dflfact** parameter value is either **pass**, **route**, **discard**, or **atierr**, and the **dflfact** parameter value is changed to either **forward**, **duplicate**, or **dupdisc**, the GSM OPCODE entry must be assigned to a MAP set with the **nmapset=dflt** parameter (to assign the GSM OPCODE entry to the default MAP set), or with the **nmapset=<numbered MAP set ID>** parameter (to assign the GSM OPCODE entry to a MAP set other the default MAP set).
- If the default MAP set will be assigned to the GSM OPCODE entry, the **npc/npca/npci/npcn/npcn24** and **nssn** values must be shown in the default MAP set in the **rtrv-map** output. If the **npc/**

**npc**/**npca**/**npci**/**npcn** /**npcn24** or **nssn** values are not shown in the default MAP set in the **rtrv-map** output, the **force=yes** parameter must be specified.

- If a MAP set other than the default MAP set will be assigned to the GSM OPCODE entry, the **npc/npca/npci/npcn/npcn24** and **nssn** values must be shown in that MAP set in the **rtrv-map** output. The **force=yes** parameter cannot be specified with the **chg-gsms-opcode** command.
- If the point code and subsystem values are not being changed, the **nmapset** parameter does not have to be specified unless the MAP set ID assigned to the GSM OPCODE entry is being changed. The new MAP set must contain the point code and subsystem values in the GSM OPCODE entry.

The **nopname** parameter value must be no more than 8 alphanumeric characters.

The reserved word **none** cannot be used as a value for the **nopname** parameter.

The **ndflctact=atierr** parameter cannot be specified unless the value of the operation code (**opcode**) referenced by the **opname** parameter value is **71**. The **atierr** option is only valid for ATI MAP operation codes; **opcode=71** signifies an ATI MAP operation code.

The **npc/npca/npci/npcn/npcn24** and **nssn** values must be shown in the **rtrv-map** output, or else the **force=yes** parameter must be specified. If the **npc/npca/npci/npcn/npcn24** and **nssn** values are not shown in the **rtrv-map** output, and a new mated application is to be added, perform one of the “Provisioning a Mated Application” procedures in the *Database Administration Manual - Global Title Translation* and add the required mated application with the **npc/npca/npci/npcn/npcn24** and **nssn** values.

The **force=yes** parameter can be specified only with the **npc/npca/npci/npcn/npcn24** and **nssn** parameters.

The **ndflctact=forward**, **ndflctact=duplicate**, or **ndflctact=dupdisc** parameters can be specified only with the **npc/npca/npci/npcn/npcn24** and **nssn** parameters. If the **npc/npca/npci/npcn/npcn24** and **nssn** parameters are specified, the **ndflctact=forward**, **ndflctact=duplicate**, or **ndflctact=dupdisc** parameters must be specified.

The **npc/npca/npci/npcn/npcn24** and **nssn** parameters must be specified together.

The **npc/npca/npci/npcn/npcn24** parameter values must be the DPC of a route or a member of a cluster route, and a proxy point code cannot be assigned to the point code. This can be verified with the **rtrv-rte** command. If the **npc/npca/npci/npcn/npcn24** value is not shown in the **rtrv-rte** as the DPC of a route, go to the “Adding a Route Containing an SS7 DPC” procedure in the *Database Administration Manual - SS7* and add a new route containing the **npc/npca/npci/npcn/npcn24** value. To verify whether or not a proxy point code is assigned to the **npc/npca/npci/npcn/npcn24** value, enter the **rtrv-dstn** command with the point code value. If a proxy point code is assigned to the point code, choose another point code.

## Procedure

1. Display the GSM MAP screening operation codes in the database using the **rtrv-gsms-opcode** command.

If the Flexible GTT Load Sharing feature is not enabled, this is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

OPCODE  OPNAME    DFLTACT   PCA        SSN
  36     for1      fwd       002-002-002  10

OPCODE  OPNAME    DFLTACT   PCI        SSN
  93     dd93     dupdc     5-025-3    200
```

```

139 fwd139 fwd 3-159-7 128
OPCODE OPNAME DFLTACT PCN SSN
187 dup187 dupl 11519 79
OPCODE OPNAME DFLTACT PCN24 SSN
OPCODE OPNAME DFLTACT
22 sri disc
25 route25 route
50 pass50 pass
71 ati atierr
150 discard1 disc
* star pass
    
```

GSMSMS OPCODE Table (10 of 257) is 4% full

If the Flexible GTT Load Sharing feature is enabled, this is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE OPNAME DFLTACT PCA SSN MAPSET
36 for1 fwd 002-002-002 10 25
OPCODE OPNAME DFLTACT PCI SSN MAPSET
93 dd93 dupdc 5-025-3 200 20
139 fwd139 fwd 3-159-7 128 DFLT
OPCODE OPNAME DFLTACT PCN SSN MAPSET
187 dup187 dupl 11519 79 10
OPCODE OPNAME DFLTACT PCN24 SSN MAPSET
OPCODE OPNAME DFLTACT
22 sri disc
25 route25 route
50 pass50 pass
71 ati atierr
150 discard1 disc
* star pass
    
```

GSMSMS OPCODE Table (10 of 257) is 4% full

**NOTE:** If the default action parameter value will be changed to either `pass`, `discard`, `route`, or `atierr`, or the `npc/npca/npci/npcn/npcn24` and `nssn` parameters are not to be specified, skip steps 2 through 7, and go to step 8.

**NOTE:** If the `npc/npca` parameters are not being used in this procedure, or if the `rtrv-gsms-opcode` output in step 1 shows ANSI point code values (`pc/pca` parameter values) or the `opcode=*` parameter value, skip step 2, and go to step 3.

2. Verify that the Enhanced GSM MAP Screening feature is enabled and on by entering the `rtrv-ctrl-feat` command with the part number of the Enhanced GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893012401
```

The following is an example of the possible output.

```

rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
    
```

Feature Name	Partnum	Status	Quantity
Enhanced GMS (EGMS)	893012401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
--------------	---------	--------	----------	-------------------

Zero entries found.

The following features have expired temporary keys:

```
Feature Name          Partnum
Zero entries found.
```

If the Enhanced GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the Enhanced GSM MAP screening feature.

3. Perform one of these actions.

- If the **ndfltact** parameter value will be either **pass**, **discard**, **route**, or **atierr**, skip steps 4 through 7, and continue the procedure with step 8.
- If the point code is not being changed, skip steps 4 through 7, and continue the procedure with step 8. If the point code and subsystem values are not being changed, and the Flexible GTT Load Sharing feature is enabled, the **nmapset** parameter does not have to be specified unless the MAP set ID assigned to the GSM OPCODE entry is being changed. The new MAP set must contain the point code and subsystem values in the GSM OPCODE entry.
- If the **ndfltact** parameter value will be either **forward**, **duplicate**, or **dupdisc**, perform one of these actions.
  - To use a point code and a MAP set from the mated application table, and MAP sets are not shown in the **rtrv-gsms-opcode** output in step 1, the Flexible GTT Load Sharing Feature must be enabled. Perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation* and enable the Flexible GTT Load Sharing feature. After enabling the Flexible GTT Load Sharing feature, skip steps 4 and 5 and continue the procedure with step 6.
  - To use a point code and a MAP set from the mated application table, and MAP sets are shown in the **rtrv-gsms-opcode** output in step 1, skip steps 4 and 5 and continue the procedure with step 6.
  - To use a point code in the mated application table, but without using a MAP set, and MAP sets are not shown in the **rtrv-gsms-opcode** output in step 1, skip steps 4 and 5 and continue the procedure with step 6.
  - To use a point code that is not in the mated application table, the **force=yes** parameter must be specified with the **chg-gsms-opcode** command. A proxy point code cannot be assigned to this point code. If the Flexible GTT Load Sharing feature is enabled, the **force=yes** parameter can be used only if the default MAP set is assigned to the GSM OPCODE entry. Continue the procedure with step 4.

4. Display the destination point codes in the database by entering the **rtrv-dstn** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0
```

DPCA	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
001-207-000	-----	no	---	-----	-----	SS7
001-001-001	-----	no	---	-----	-----	SS7
001-001-002	-----	no	---	-----	-----	SS7
001-005-000	-----	no	---	-----	-----	SS7
001-007-000	-----	no	---	-----	-----	SS7
008-012-003	-----	no	---	-----	-----	SS7
003-002-004	-----	no	---	-----	-----	SS7
009-002-003	-----	no	---	-----	-----	SS7
010-020-005	-----	no	---	-----	-----	SS7
DPCI	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
1-207-0	-----	no	---	-----	-----	SS7

```

0-015-0      ----- no  ---  -----  -----  SS7
0-017-0      ----- no  ---  -----  -----  SS7
1-011-1      ----- no  ---  -----  -----  SS7
1-011-2      ----- no  ---  -----  -----  SS7

DPCN        CLLI        BEI ELEI  ALIASA        ALIASI        DOMAIN
DPCN24      CLLI        BEI ELEI  ALIASA        ALIASI        DOMAIN

```

```

Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full

```

If the required point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* to add the required point code. A proxy point code cannot be assigned to the point code.

After the new point code has been added, skip steps 5 through 7 and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 8.

5. Display the point code that will be assigned to the mated application by using the **rtrv-dstn** command and specifying the point code. For this example, enter this command.

```
rtrv-dstn:dpca=010-020-005
```

This is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA        CLLI        BEI ELEI  ALIASI        ALIASN        DOMAIN
010-020-005 ----- no  ---  -----  -----  SS7

PPC         NCAI         PRX
009-002-003 ----          no

Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full

```

If the adjacent point code is not shown in the **rtrv-dstn** command output, the following output is displayed.

```

DPCA        CLLI        BEI ELEI  ALIASI        ALIASN/N24    DOMAIN

No destinations meeting the requested criteria were found

Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full

```

A proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code. If a proxy point code is shown in this step, choose another point code from the **rtrv-dstn** output in the previous step and repeat this step.

If the point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* and add the adjacent point code to the destination point code table.

After the new point code has been added, skip steps 6 and 7, and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 8.

6. The point code and subsystem number being assigned to the GSM operations code must be in the mated application table.

Enter the **rtrv-map** command with the **npc/npca/npci/npcn/npcn24** and **nssn** values that will be specified with the **chg-gsms-opcode** command in step 8.

If the Flexible GTT Load Sharing feature is not enabled, for this example, enter these commands.

For this example, enter this command.

```
rtrv-map:pci=4-038-1:ssn=50
```

This is an example of the possible output.

```
r1ghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCI Mate PCI SSN RC MULT SRM MRC GRP NAME SSO
4-038-1 50 10 SOL --- --- GRP01 ON
```

**NOTE: If the point code and subsystem number is not shown in the rtrv-map output, and is not added to the database in one of these procedures, the force=yes parameter must be specified with the chg-gsms-opcode command in step 5.**

If the Flexible GTT Load Sharing feature is enabled and the current **dfltact** parameter value is either **pass**, **route**, **discard**, or **atierr**, and the **dfltact** parameter value is changed to either **forward**, **duplicate**, or **dupdisc**, the GSM OPCODE entry must be assigned to a MAP set with the **nmapset=dflt** parameter (to assign the GSM OPCODE entry to the default MAP set), or with the **nmapset=<numbered MAP set ID>** parameter (to assign the GSM OPCODE entry to a MAP set other the default MAP set).

- The point code specified with the **chg-gsms-opcode** command must be the DPC of a route.

If the point code specified with the **chg-gsms-opcode** command is an ANSI point code, the point code can be a member of a cluster point code when that cluster point code is the DPC of a route.

Enter the **rtrv-rte** command with the **dpc** parameter specifying the point code to be used with the **chg-gsms-opcode** command to verify whether or not the point code is the DPC of a route. For this example, enter these commands.

```
rtrv-rte:dpci=4-038-1
```

This is an example of the possible output.

```
r1ghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
DPCI ALIASN/N24 ALIASA LSN RC APC
4-038-1 12111 240-111-111 1s300001 10 4-038-1
1s300002 10 2-066-7
1s300003 20 5-087-4
RTX:No CLLI=idp1
```

If the point code is not shown in the **rtrv-rte** output, if the point code is an ANSI point code, the point code is not a member of a cluster point code when that cluster point code is the DPC of a route, go to the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database.

- Change the attributes of GSM MAP screening operation codes in the database with the **chg-gsms-opcode** command.

For this example, enter these commands:

```
chg-gsms-opcode:opname=pass100:ndfltact=discard
```

```
chg-gsms-opcode:opname=discard1:nopname=pass1:ndfltact=pass
```

```
chg-gsms-opcode:opname=sri:nopname=irs
```

```
chg-gsms-
```

```
opcode:opname=fwd139:nopname=fwd1000:npci=4-038-1:nssn=50:nmapset=18
```

When each of these commands has successfully completed, this message appears.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
GSM Map Op-Code Table is (8 of 256) 3% full
CHG-GSMS-OPCODE: MASP A - COMPLTD
```

**NOTE:** See [Flowchart 5-9](#) ( Sheet 7) for the rules that apply to the **chg-gsms-opcode** command.

9. Verify the changes using the **rtrv-gsms-opcode** command with the **opname** parameter value specified in step 8.

If the **opname** parameter value was changed in step 8, the new **opname** parameter value should be specified with the **rtrv-gsms-opcode** command. For this example, enter these commands.

```
rtrv-gsms-opcode:opanme=pass100
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE  OPNAME      DFLTACT
100     pass100    discard
```

```
GSMSMS OPCODE Table (10 of 257) is 4% full
```

```
rtrv-gsms-opcode:opname=pass1
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE  OPNAME      DFLTACT
150     pass1       pass
```

```
GSMSMS OPCODE Table (10 of 257) is 4% full
```

```
rtrv-gsms-opcode:opname=irs
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE  OPNAME      DFLTACT
22      irs         disc
```

```
GSMSMS OPCODE Table (10 of 257) is 4% full
```

```
rtrv-gsms-opcode:opname=fwd1000
```

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
OPCODE  OPNAME      DFLTACT  PCI      SSN  MAPSET
139     fwd1000    fwd      4-38-1   50   18
```

```
GSMSMS OPCODE Table (10 of 257) is 4% full
```


10. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
```


BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
 BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
 BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.


Flowchart 5-9. Changing a GSM MAP Screening Operation Code














## Notes:

1. The word "none" cannot be used as a value for the *opname* or *nopname* parameters.
2. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both.
3. If the point code and subsystem number values are not being changed, the *npc/npcal/npci/npcn/npcn24* and *nssn* parameters must be specified with the current values for these parameters.
4. The *npc/npcal/npci/npcn/npcn24* value must be shown in the *rtrv-rte* output on Sheets 4 or 5 as the DPC of a route. The *npc/npca* value must be a full point code value. The *npc/npca* value can be a member of a cluster point code when that cluster point code is the DPC of a route. A proxy point code cannot be assigned to the point code.
5. If the Flexible GTT Load Sharing feature is not enabled, shown on Sheet 3, the *npc/npcal/npci/npcn/npcn24* and *nssn* values must be shown in the *rtrv-map* output on Sheet 4. If the *npc/npcal/npci/npcn/npcn24* or *nssn* values are not shown in the *rtrv-map* output, the *force=yes* parameter must be specified.
6. If the Flexible GTT Load Sharing feature is enabled, shown on Sheet 3, and the current *dfltact* parameter value is either *pass*, *route*, *discard*, or *atierr*, and the *dfltact* parameter value is changed to either *forward*, *duplicate*, or *dupdisc*, the GSM OPCODE entry must be assigned to a MAP set with the *nmapset=dflt* parameter (to assign the GSM OPCODE entry to the default MAP set), or with the *nmapset=<numbered MAP set ID>* parameter (to assign the GSM OPCODE entry to a MAP set other the default MAP set).
7. If the Flexible GTT Load Sharing feature is enabled, shown on Sheet 3, and the default MAP set will be assigned to the GSM OPCODE entry, the *npc/npcal/npci/npcn/npcn24* and *nssn* values must be shown in the default MAP set in the *rtrv-map* output on Sheet 4. If the *npc/npcal/npci/npcn/npcn24* or *nssn* values are not shown in the default MAP set in the *rtrv-map* output, the *force=yes* parameter must be specified.
8. If the Flexible GTT Load Sharing feature is enabled, shown on Sheet 3, and a MAP set other than the default MAP set will be assigned to the GSM OPCODE entry, the *npc/npcal/npci/npcn/npcn24* and *nssn* values must be shown in that MAP set in the *rtrv-map* output on Sheet 4.
9. To specify the *npc/npca* parameters, the Enhanced GSM MAP Screening feature must be enabled and turned on.
10. If only the point code or subsystem number value is being changed, the point code or subsystem number value being changed must be specified with the new value for the parameter being changed. The current value for the point code or subsystem number parameter not being changed must be specified. The *ndfltact* parameter does not have to be specified. For example, if the current point code is *pca=002-002-002* and the subsystem number is 50, and the point code is being changed to *pca=003-003-003* and the substem number is not changing, the *npca* parameter value would be the new point code value (003-003-003) and the *nssn* parameter value would be the current value (50).
11. If the Flexible GTT Load Sharing feature is enabled, shown on Sheet 3, and the point code and subsystem values are not being changed, the *nmapset* parameter does not have to be specified unless the MAP set ID assigned to the GSM OPCODE entry is being changed. The new MAP set must contain the point code and subsystem values in the GSM OPCODE entry.

## Adding a GSM MAP Screening Entry

Use this procedure to provision the GSM MAP screening entries that filter or allow TCAP messages for certain MAP operation codes in the database using the **ent-gsmmap-scrn** command. The messages are filtered or allowed based on the origination addresses (**saddr/eaddr**), numbering plan value (**npv**), nature of address indicator value (**naiv**), MAP opnames (**opname**), and forbidden (**forbid**) parameters.

The **ent-gsmmap-scrn** command uses these parameters.

**:saddr** – The origination address (1 - 15 decimal digits, 1 - 15 hex digits, or \*) for a single entry or the starting origination address for a range of entries of the CGPA/CDPA entry to be screened.

**:eaddr** – The ending origination address (1 - 15 decimal digits or 1 - 15 hex digits) for a range of entries of the CGPA/CDPA entry to be screened.

**:action** – The screening action to take if a message is forbidden as defined by the **forbid** parameter. One of these actions can be assigned.

- **pass** – Route the message as normal to the destination.
- **discard** – The MSU is to be discarded.
- **atierr** – An ATI (Any Time Interrogation) reject message is generated. This option is only valid for ATI MAP operation codes.
- **route** – Route the message as normal to the original destination node.
- **forward** – Route the original message to the forward node. The original message is not sent to the original node. If, however, the forwarded node is not available for routing then the MSU is routed to the original node.
- **duplicate** – Route the message as normal to the original destination and route a copy of the original message to the duplicate node.
- **dupdisc** – Duplicate and discard – Route the original message to the duplicate node. The original message is not sent to the original node.

**:pc/pca/pci/pcn/pcn24** – The ANSI point code (**pc/pca**), ITU-I point code or ITU-I spare point code (**pci**), 14-bit ITU-N point code or 14-bit ITU-N spare point code (**pcn**), or 24-bit ITU-N point code (**pcn24**) of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both. To specify the **pc/pca** parameters, the Enhanced GSM MAP Screening feature must be enabled and on.

**:ssn** – The subsystem number of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions

**:force** – The mated application override. Is the GSM MAP screening operation code to be entered without a mated application in the database (**yes** or **no**)?

**:forbid** – The forbidden parameter value. If a forbidden parameter is detected, the message is rejected by the action defined by the **action** parameter. One of four forbidden parameter values can be specified.

- **all** – All parameters are forbidden. Take the specified screening action defined by the **action** parameter for incoming messages that contain the entered address and operation code combination.
- **none** – No parameters are forbidden. Take the specified screening action defined by the **action** parameter for incoming messages that contain the entered address and operation code combination.
- **state** – Take the specified screening action defined by the **action** parameter for incoming messages that contain **state** as the forbidden parameter for the entered address and operation code combination.
- **location** – Take the specified screening action defined by the **action** parameter for incoming messages that contain **location** as the forbidden parameter for the entered address and operation code combination.

**NOTE: The state and location values are valid only for GSM ATI messages.**

**:naiv** – The nature of address value (0 - 15 or \*).

**:npv** – The numbering plan value (0 - 127 or \*).

**:opname** – The user-defined name for the operation code. The **opname** value references the operation code (**opcode**) shown in the **rtrv-gsms-opcode** command. GSM MAP screening is performed on the specified address or addresses for the referenced operation code.

**:cgssr** – The CGPA screening reference name consisting of 1 alphabetic character and 3 optional alphanumeric characters.

**:cdsr** – The CDPA screening reference name consisting of 1 alphabetic character and 3 optional alphanumeric characters.

**:mapset** – The MAP set ID, shown in the **rtrv-map** command. This parameter can be specified only if the Flexible GTT Load Sharing feature is enabled. The status of the Flexible GTT Load Sharing feature is shown in the **rtrv-ctrl-feat** output. To enable the Flexible GTT Load Sharing feature, perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation*.

[Table 5-6](#) shows the parameter combinations that can be used in this procedure.

**Table 5-6. Add GSM MAP Screening Entry Parameter Combinations**

Entry Containing a Point Code and SSN <sup>1</sup>	Entry Without a Point Code and SSN <sup>1</sup>	Entry containing the Action ATIERR <sup>1</sup>	Entry Containing a Point Code and SSN <sup>1</sup>	Entry Without a Point Code and SSN <sup>1</sup>	Entry containing the Action ATIERR <sup>1</sup>
Enhanced GSM MAP Screening Feature Enabled and On	Enhanced GSM MAP Screening Feature Enabled and On	Enhanced GSM MAP Screening Feature Enabled and On	GSM MAP Screening Feature Enabled and On Only	GSM MAP Screening Feature Enabled and On Only	GSM MAP Screening Feature Enabled and On Only
<b>Mandatory Parameters</b>					
:opname = opname value <sup>2</sup>	:opname = opname value <sup>2</sup>	:opname = opname value containing opcode=71 <sup>2</sup>	:opname = opname value <sup>2</sup>	:opname = opname value <sup>2</sup>	:opname = opname value containing opcode=71 <sup>2</sup>
:cgssr = CGSR name <sup>3</sup>	:cgssr = CGSR name <sup>3</sup>	:cgssr = CGSR name <sup>3</sup>	:cgssr = CGSR name <sup>3</sup>	:cgssr = CGSR name <sup>3</sup>	:cgssr = CGSR name <sup>3</sup>
			saddr = 0 - 15 decimal digits <sup>4, 5, 6</sup>	saddr = 0 - 15 decimal digits <sup>4, 5, 6</sup>	saddr = 0 - 15 decimal digits <sup>4, 5, 6</sup>
<b>Optional Parameters</b>					
:saddr = 0 - 15 hex digits, or * <sup>4, 5, 6</sup>	:saddr = 0 - 15 hex digits, or * <sup>4, 5, 6</sup>	:saddr = 0 - 15 hex digits, or * <sup>4, 5, 6</sup>	:eaddr = 0 - 15 decimal digits <sup>4, 5, 6</sup>	:eaddr = 0 - 15 decimal digits <sup>4, 5, 6</sup>	:eaddr = 0 - 15 decimal digits <sup>4, 5, 6</sup>
:eaddr = 0 - 15 hex digits <sup>4, 5, 6, 7</sup>	:eaddr = 0 - 15 hex digits <sup>4, 5, 6, 7</sup>	:eaddr = 0 - 15 hex digits <sup>4, 5, 6, 7</sup>	:forbid = all	:forbid = all, none <sup>15</sup>	:forbid = state, location
:cdsr = CDSR name <sup>3</sup>	:cdsr = CDSR name <sup>3</sup>	:cdsr = CDSR name <sup>3</sup>	:action = forward, duplicate, dupdisc <sup>9</sup>	:action = pass, discard, route <sup>15</sup>	:action = atiterr
:forbid = all	:forbid = all, none <sup>15</sup>	:forbid = state, location	:npv = 0 - 15, or * <sup>8</sup>	:npv = 0 - 15, or * <sup>8</sup>	:npv = 0 - 15, or * <sup>8</sup>

Entry Containing a Point Code and SSN <sup>1</sup>  Enhanced GSM MAP Screening Feature Enabled and On	Entry Without a Point Code and SSN <sup>1</sup>  Enhanced GSM MAP Screening Feature Enabled and On	Entry containing the Action ATIERR <sup>1</sup>  Enhanced GSM MAP Screening Feature Enabled and On	Entry Containing a Point Code and SSN <sup>1</sup>  GSM MAP Screening Feature Enabled and On Only	Entry Without a Point Code and SSN <sup>1</sup>  GSM MAP Screening Feature Enabled and On Only	Entry containing the Action ATIERR <sup>1</sup>  GSM MAP Screening Feature Enabled and On Only
:action = forward, duplicate, dupdisc <sup>9</sup>	:action = pass, discard, route <sup>15</sup>	:action = atiterr	:naiv = 0 - 127, or * 8	:naiv = 0 - 127, or * 8	:naiv = 0 - 127, or * 8
:npv = 0 - 15, or * 8	:npv = 0 - 15, or * 8	:npv = 0 - 15, or * 8	:pci/pcn/pcn24 = point code value <sup>10, 11, 12, 13, 14</sup>		
:naiv = 0 - 127, or * 8	:naiv = 0 - 127, or * 8	:naiv = 0 - 127, or * 8	ssn = SSN value <sup>13, 14</sup>		
:pc/pca/pci/pcn/ pcn24 = point code value <sup>10, 11, 12, 13, 14</sup>			:force=yes <sup>13, 14</sup>		
:ssn = SSN value <sup>13, 14</sup>			:mapset= dflt or numbered MAP set ID <sup>13, 14</sup>		
:force=yes <sup>13, 14</sup>					
:mapset = dflt or numbered MAP set ID <sup>13, 14</sup>					

Notes:

- When a CGPA entry (**cgpr** parameter is specified without the **cdsr** parameter) is added to the GSM MAP Screening table, a default wild card entry is created for the CGPA entry, thus adding two entries to the GSM MAP Screening table. The default wild card CDPA entry is not shown in the **rtrv-gsmmap-scrn** output. As a result, the GSM MAP Screening table must have at least two free entries in order to provision a CGPA entry in the GSM MAP Screening table. When the first provisioned wildcard (\*) CDPA entry is added to a CGPA entry, the number of entries in the GSM MAP Screening table, shown in the GSM MAP Screening command outputs, does not change.
- The **opname** parameter value must be shown in either the **rtrv-gsms-opcode** or **rtrv-gsmmap-scrn** output.
- The **cgpr** and **cdsr** parameter values consist of 1 alphabetic character and up to 3 optional alphanumeric characters. If the **cdsr** parameter is not specified, a CGPA entry with a default wild card CDPA entry is created in the GSM MAP Screening table (see Note 1). If the **cdsr** parameter is specified, a CDPA entry is created in the GSM MAP Screening table.
- If a single entry is specified for the CGPA/CDPA (that is, the **eaddr** parameter is not specified) then the **saddr/npv/naiv/opname** parameter combination cannot exist in the GSM MAP Screening table.
- If a range of entries is specified for the CGPA/CDPA (that is, the **eaddr** parameter is specified) then the **saddr/eaddr/npv/naiv/opname** parameter combination cannot exist in the GSM MAP Screening table or overlap with another range entry in the GSM MAP Screening table.
- The **eaddr** parameter value must contain the same number of digits as the **saddr** parameter value. The **eaddr** parameter value must be greater than the **saddr** parameter value. The **saddr** parameter must be specified with the **eaddr** parameter.
- The **eaddr** parameter cannot be specified with the **saddr=\*** parameter.
- If the Enhanced GSM MAP Screening feature is not enabled or off, and either the **npv** or **naiv** parameters are specified, both the **npv** and **naiv** parameters must be specified. If the asterisk (\*) is specified for either the **npv** or **naiv** parameters, the asterisk must

Entry Containing a Point Code and SSN <sup>1</sup>	Entry Without a Point Code and SSN <sup>1</sup>	Entry containing the Action ATIERR <sup>1</sup>	Entry Containing a Point Code and SSN <sup>1</sup>	Entry Without a Point Code and SSN <sup>1</sup>	Entry containing the Action ATIERR <sup>1</sup>
Enhanced GSM MAP Screening Feature Enabled and On	Enhanced GSM MAP Screening Feature Enabled and On	Enhanced GSM MAP Screening Feature Enabled and On	GSM MAP Screening Feature Enabled and On Only	GSM MAP Screening Feature Enabled and On Only	GSM MAP Screening Feature Enabled and On Only

be specified for both the **npv** and **naiv** parameters. If numbers are specified for either the **npv** or **naiv** parameters, numbers must be specified for both the **npv** and **naiv** parameters.

9. If the **action** parameter values are either **forward**, **duplicate**, or **dupdisc**, the point code and **ssn** parameters must be specified with the **ent-gsmmap-scrn** command. A proxy point code cannot be assigned to this point code.

10. The point code value must be the DPC of a route or a member of a cluster route. The **pc/pca** value must be a full point code, The **pc/pca** value can be a member of a cluster point code when that cluster point code is the DPC of a route. This can be verified with the **rtrv-rte** command. If the point code value is not shown in the **rtrv-rte** output as the DPC of a route, go to the “Adding a Route Containing an SS7 DPC” procedure in the *Database Administration Manual - SS7* and add a new route containing the point code value.

11. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both at the same time.

12. If either the point code or **ssn** parameters are specified, then both the point code and **ssn** parameters must be specified.

13. If the Flexible GTT Load Sharing feature is not enabled:

- The **mapset** parameter cannot be specified.
- The point code and subsystem number values specified with the **ent-gsmmap-scrn** command must be shown in the **rtrv-map** output, or else the **force=yes** parameter must be specified. If the point code and subsystem number values are not shown in the **rtrv-map** output, and a new mated application is to be added, perform one of the “Provisioning a Mated Application” procedures in the *Database Administration Manual - Global Title Translation* and add the required mated application with the point code and subsystem number values.

14. If the Flexible GTT Load Sharing feature is enabled:

- The **mapset** parameter must be specified.
- The **force=yes** parameter can be used only if the default MAP set assigned to the GSM MAP screening entry.
- If the MAP set assigned to the GSM MAP screening entry is a MAP set other than the default MAP set, the **force=yes** parameter cannot be used. The point code and subsystem contained in the GSM MAP screening entry must be in the MAP set assigned to the GSM MAP screening entry.
- If the default MAP set is assigned to the GSM MAP screening entry and the **force=yes** parameter is not specified, the point code and subsystem contained in the GSM MAP screening entry must be in the default MAP set.

15. If the **forbid=none** parameter is specified, then the **action=pass** parameter must be specified.

GSM screening entries can either be single entries or range entries. Single entries have precedence in screening over range entries. Thus the single entry table is searched first and if a match is found, the range table is never searched. Range entries may overlap single entries.

If a message is screened and does not contain matching GTA, NPV, and NAIV values, the message is rejected. The message is rejected with the default action defined by the **ent-gsms-opcode** command for the operation code (**opcode**) parameter entry referenced by the operation name (**opname**) parameter.

This examples used in this procedure are based on the examples shown in [Table 5-7](#) and [Table 5-8](#) .

**Table 5-7. Example CGPA GSM MAP Screening Configuration Table**

CGSR	SADDR	EADDR	NPV	NAIV	OPNAME	FORBID
cg01	9194600000	---	5	75	pass50	none
cg02	252555100000	252700000000	12	37	discard1	all
cg03	8284540000	8284600000	---	---	ati	state
cg04	2416546464	---	0	127	route25	none
cg05	854000000	857000000	3	99	dd93	all
cg06	154363000000	155000000000	8	86	sri	all
cg07	368900000	369000000	9	111	dup187	none
CGSR	ACTION	PC/PCA/PCI/PCN/PCN24	SSN	MAPSET		
cg01	pass	N/A	N/A	N/A		
cg02	discard	N/A	N/A	N/A		
cg03	atierr	N/A	N/A	N/A		
cg04	route	N/A	N/A	N/A		
cg05	forward	3-201-7	100	DFLT		
cg06	duplicate	9384	30	10		
cg07	dupdisc	4-102-6	150	20		

**Table 5-8. Example CDPA GSM MAP Screening Configuration Table**

CGSR	CDSR	SADDR	EADDR	OPNAME	NPV	NAIV	FORBID
cg01	cd01	---	---	pass50	6	15	all
cg02	cd15	---	---	discard1	10	15	all
cg07	cd10	---	---	dup187	11	57	all
CGSR	CDSR	ACTION	PC/PCA/PCI/PCN/PCN24	SSN	MAPSET		
cg01	cd01	pass	N/A	N/A	N/A		
cg02	cd15	discard	N/A	N/A	N/A		
cg07	cd10	dupdisc	5-97-2	135	30		

**Procedure**

1. Display the GSM MAP screening operation codes in the database using the `rtrv-gsms-opcode` command.

If the Flexible GTT Load Sharing feature is not enabled, this is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0
```

```

OPCODE  OPNAME  DFLTACT  PCA      SSN
  36     for1    fwd      002-002-002  10

OPCODE  OPNAME  DFLTACT  PCI      SSN
  93     dd93    dupdc    5-25-3   200
  139    fwd139  fwd      3-159-7   128

OPCODE  OPNAME  DFLTACT  PCN      SSN
  187    dup187  dupl     11519    79

OPCODE  OPNAME  DFLTACT  PCN24    SSN

OPCODE  OPNAME  DFLTACT
  22     sri     disc
  25     route25  route
  50     pass50  pass
  71     ati     atierr
  150    discard1  disc
  *      star   pass
    
```

GSMSMS OPCODE Table (10 of 257) is 4% full

If the Flexible GTT Load Sharing feature is enabled, this is an example of the possible output.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

```

OPCODE  OPNAME  DFLTACT  PCA      SSN  MAPSET
  36     for1    fwd      002-002-002  10  25

OPCODE  OPNAME  DFLTACT  PCI      SSN  MAPSET
  93     dd93    dupdc    5-025-3   200  20
  139    fwd139  fwd      3-159-7   128  DFLT

OPCODE  OPNAME  DFLTACT  PCN      SSN  MAPSET
  187    dup187  dupl     11519    79  10

OPCODE  OPNAME  DFLTACT  PCN24    SSN  MAPSET

OPCODE  OPNAME  DFLTACT
  22     sri     disc
  25     route25  route
  50     pass50  pass
  71     ati     atierr
  150    discard1  disc
  *      star   pass
    
```

GSMSMS OPCODE Table (10 of 257) is 4% full

**NOTE:** If the desired GSM MAP screening operation code entry is not shown in the `rtrv-gsms-opcode` output, go to the [Adding a GSM MAP Screening Operation Code](#) and add the required entry. Skip step 2 and go to step 3.

If either the `forbid=state`, `forbid=location`, or `action=atierr` parameters are to be assigned to the GSM MAP screening entry, the GSM MAP screening operation code table must contain an entry containing the operation code value 71.

2. Enter the `rtrv-gsmmap-scrn` command with an `opname` value shown in the `rtrv-gsms-opcode` command output in step 1 to display the GSM MAP screening entries in the database.

For this example, enter these commands.

```
rtrv-gsmmap-scrn:opname=pass50
```

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: pass50

```
-----
SADDR      NP NAI FORBD ACT    PCA      SSN CGSR
SADDR      NP NAI FORBD ACT    PCI      SSN CGSR
SADDR      NP NAI FORBD ACT    PCN      SSN CGSR
SADDR      NP NAI FORBD ACT    PCN24    SSN CGSR
SADDR      NP NAI FORBD ACT  CGSR
```

Range CgPA Entries for OPNAME: pass50

```
-----
SADDR      EADDR      NP NAI FORBD ACT    PCA
SSN CGSR

SADDR      EADDR      NP NAI FORBD ACT    PCI      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT    PCN      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT    PCN24    SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT  CGSR
```

GSM Map Screening table is (1500 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=discard1**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: discard1

```
-----
SADDR      NP NAI FORBD ACT    PCA      SSN CGSR
SADDR      NP NAI FORBD ACT    PCI      SSN CGSR
SADDR      NP NAI FORBD ACT    PCN      SSN CGSR
SADDR      NP NAI FORBD ACT    PCN24    SSN CGSR
SADDR      NP NAI FORBD ACT  CGSR
```

Range CgPA Entries for OPNAME: discard1

```
-----
SADDR      EADDR      NP NAI FORBD ACT    PCA
SSN CGSR

SADDR      EADDR      NP NAI FORBD ACT    PCI      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT    PCN      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT    PCN24    SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT  CGSR
```

GSM Map Screening table is (1500 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=ati**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: ati

```
-----
SADDR      NP NAI FORBD ACT    PCA      SSN CGSR
SADDR      NP NAI FORBD ACT    PCI      SSN CGSR
```

```
SADDR      NP NAI FORBD ACT      PCN      SSN CGSR
SADDR      NP NAI FORBD ACT      PCN24     SSN CGSR

SADDR      NP NAI FORBD ACT  CGSR
919462000000005 1 0  locat atier atil
```

Range CgPA Entries for OPNAME: ati

```
-----
SADDR      EADDR      NP NAI FORBD ACT      PCA      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT      PCI      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT      PCN      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT      PCN24     SSN CGSR

SADDR      EADDR      NP NAI FORBD ACT  CGSR
919461888888888 919461900000000 4 1  locat atier ati2
919462000000000 919463000000000 * *  locat atier ati3
```

GSM Map Screening table is (1500 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=route25**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: route25

```
-----
SADDR      NP NAI FORBD ACT      PCA      SSN CGSR
SADDR      NP NAI FORBD ACT      PCI      SSN CGSR
SADDR      NP NAI FORBD ACT      PCN      SSN CGSR
SADDR      NP NAI FORBD ACT      PCN24     SSN CGSR

SADDR      NP NAI FORBD ACT  CGSR
```

Range CgPA Entries for OPNAME: route25

```
-----
SADDR      EADDR      NP NAI FORBD ACT      PCA      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT      PCI      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT      PCN
SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT      PCN24     SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT  CGSR
```

GSM Map Screening table is (1500 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=dd93**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: dd93

```
-----
SADDR      NP NAI FORBD ACT      PCA      SSN CGSR
SADDR      NP NAI FORBD ACT      PCI      SSN CGSR
SADDR      NP NAI FORBD ACT      PCN      SSN CGSR
```

```

SADDR          NP NAI FORBD ACT      PCN24          SSN CGSR
SADDR          NP NAI FORBD ACT    CGSR
Range CgPA Entries for OPNAME: dd93
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI
SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    CGSR
    
```

GSM Map Screening table is (1500 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=sri**

This is an example of the possible output.

```

rlghncxa03w 06-10-20 09:07:58 GMT  EAGLE5 36.0.0
Single CgPA Entries for OPNAME: sri
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          NP NAI FORBD ACT    CGSR
    
```

```

Range CgPA Entries for OPNAME: sri
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    CGSR
    
```

GSM Map Screening table is (1500 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=dup187**

This is an example of the possible output.

```

rlghncxa03w 06-10-20 09:07:58 GMT  EAGLE5 36.0.0
Single CgPA Entries for OPNAME: dup187
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          NP NAI FORBD ACT    CGSR
    
```

```
Range CgPA Entries for OPNAME: dup187
```

```
-----
SADDR          EADDR          NP NAI FORBD ACT    PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    CGSR
```

```
GSM Map Screening table is (1500 of 4000) 38% full
```

If the Flexible GTT Load Sharing feature is enabled, the **MAPSET** field is shown in the **rtrv-gsmmap-scrn** output as shown in the following output example.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
```

```
Single CgPA Entries for OPNAME: dup187
```

```
-----
SADDR          NP NAI FORBD ACT    PCA          SSN CGSR MAPSET
SADDR          NP NAI FORBD ACT    PCI          SSN CGSR MAPSET
SADDR          NP NAI FORBD ACT    PCN          SSN CGSR MAPSET
SADDR          NP NAI FORBD ACT    PCN24        SSN CGSR MAPSET
SADDR          NP NAI FORBD ACT    CGSR
```

```
Range CgPA Entries for OPNAME: dup187
```

```
-----
SADDR          EADDR          NP NAI FORBD ACT    PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCI SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN24 SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    CGSR
```

```
GSM Map Screening table is (1500 of 4000) 38% full
```

**NOTE: If any of the following parameters or values are not being used in this procedure, skip step 3 and go to step 4.**

- **saddr=\***
- **cdsr**
- **pc/pca**
- **The saddr or eaddr parameter values containing hex digits.**

**If the rtrv-gsmmap-scrn output in this step shows any of the parameters or values listed above, skip step 3, and go to step 4.**

3. Verify that the Enhanced GSM MAP Screening feature is enabled and on by entering the **rtrv-ctrl-feat** command with the part number of the Enhanced GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893012401
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Enhanced GSM (EGMS)	893012401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

If the Enhanced GSM MAP screening feature is not enabled or off, go to the [Activating the GSM MAP Screening Feature](#) to enable and turn on the Enhanced GSM MAP screening feature.

#### 4. Perform one of these actions.

- If the **action** parameter value will be either **pass**, **discard**, **route**, or **atierr**, skip steps 4 through 8, and continue the procedure with step 9.
- If the **action** parameter value will be either **forward**, **duplicate**, or **dupdisc**, perform one of these actions.
  - To use a point code and a MAP set from the mated application table, and MAP sets are not shown in the **rtrv-gsmmap-scrn** output in step 2, the Flexible GTT Load Sharing Feature must be enabled. Perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation* and enable the Flexible GTT Load Sharing feature. After enabling the Flexible GTT Load Sharing feature, skip steps 5 and 6 and continue the procedure with step 7.
  - To use a point code and a MAP set from the mated application table, and MAP sets are shown in the **rtrv-gsmmap-scrn** output in step 2, skip steps 5 and 6 and continue the procedure with step 7.
  - To use a point code in the mated application table, but without using a MAP set, and MAP sets are not shown in the **rtrv-gsmmap-scrn** output in step 2, skip steps 5 and 6 and continue the procedure with step 7.
  - To use a point code that is not in the mated application table, the **force=yes** parameter must be specified with the **ent-gsmmap-scrn** command. A proxy point code cannot be assigned to this point code. If the Flexible GTT Load Sharing feature is enabled, the **force=yes** parameter can be used only if the default MAP set is assigned to the GSM MAP screening entry. Continue the procedure with step 5.

#### 5. Display the destination point codes in the database by entering the **rtrv-dstn** command. This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA          CLLI          BEI  ELEI  ALIASI          ALIASN          DOMAIN
001-207-000   -----   no   ---   -----   -----   SS7
001-001-001   -----   no   ---   -----   -----   SS7
001-001-002   -----   no   ---   -----   -----   SS7
001-005-000   -----   no   ---   -----   -----   SS7
001-007-000   -----   no   ---   -----   -----   SS7
008-012-003   -----   no   ---   -----   -----   SS7
003-002-004   -----   no   ---   -----   -----   SS7
```

```

009-002-003 ----- no --- -----
010-020-005 ----- no --- -----

DPCI          CLLI          BEI ELEI  ALIASI      ALIASN      DOMAIN
1-207-0       ----- no --- -----
0-015-0       ----- no --- -----
0-017-0       ----- no --- -----
1-011-1       ----- no --- -----
1-011-2       ----- no --- -----

DPCN          CLLI          BEI ELEI  ALIASA      ALIASI      DOMAIN
DPCN24        CLLI          BEI ELEI  ALIASA      ALIASI      DOMAIN
    
```

Destination table is (14 of 2000) 1% full  
 Alias table is (0 of 12000) 0% full  
 PPC table is (1 of 20) 5% full

If the required point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* to add the required point code. A proxy point code cannot be assigned to the point code.

After the new point code has been added, skip steps 6 through 8 and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 9.

6. Display the point code that will be assigned to the mated application by using the **rtrv-dstn** command and specifying the point code. For this example, enter this command.

**rtrv-dstn:dpca=010-020-005**

This is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA          CLLI          BEI ELEI  ALIASI      ALIASN      DOMAIN
010-020-005   ----- no --- -----

PPC           NCAI          PRX
009-002-003   ----         no
    
```

Destination table is (14 of 2000) 1% full  
 Alias table is (0 of 12000) 0% full  
 PPC table is (1 of 20) 5% full

If the adjacent point code is not shown in the **rtrv-dstn** command output, the following output is displayed.

```

DPCA          CLLI          BEI ELEI  ALIASI      ALIASN/N24  DOMAIN
No destinations meeting the requested criteria were found

Destination table is (14 of 2000) 1% full
Alias table is (0 of 12000) 0% full
PPC table is (1 of 20) 5% full
    
```

A proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code. If a proxy point code is shown in this step, choose another point code from the **rtrv-dstn** output in the previous step and repeat this step.

If the point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* and add the adjacent point code to the destination point code table.

After the new point code has been added, skip steps 7 and 8 and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 9.

- The point code and subsystem number being assigned to the GSM MAP screening entry must be in the mated application table.

Enter the **rtrv-map** command with the **pci/pcn/pcn24** and **ssn** values that will be specified with the **ent-gsmmap-scrn** command in step 9.

If the Flexible GTT Load Sharing feature is not enabled, for this example, enter these commands.

```
rtrv-map:pci=3-201-7:ssn=100
```

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)

PCI          Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
3-201-5      100 10 SOL --- --- GRP01  ON
```

```
rtrv-map:pcn=9384:ssn=30
```

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)

PCN          Mate PCN      SSN RC MULT SRM MRC GRP NAME SSO
9384         30 10 SOL --- --- GRP01  ON
```

```
rtrv-map:pci=4-102-6:ssn=150
```

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)

PCI          Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
4-102-6      150 10 SOL --- --- GRP01  ON
```

If the Flexible GTT Load Sharing feature is enabled:

- The **mapset** parameter must be specified with the **ent-gsmmap-scrn** command in step 9.
- The point code and subsystem contained in the GSM MAP screening entry must be in the MAP set assigned to the GSM MAP screening entry.

For this example, enter these commands.

```
rtrv-map:pci=3-201-7:ssn=100
```

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)

PCI          Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
```

```
MAPSET ID=DFLT
3-201-7                100 10 SOL --- --- GRP01    ON
```

**rtrv-map:pcn=9384:ssn=30**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS  2 % FULL    (20 of 1024)

PCN           Mate PCN      SSN RC MULT SRM MRC GRP NAME SSO
MAPSET ID=10
9384                30 10 SOL --- --- GRP01    ON
```

**rtrv-map:pci=4-102-6:ssn=150**

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS  2 % FULL    (20 of 1024)

PCI           Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
MAPSET ID=20
4-102-6                150 10 SOL --- --- GRP01    ON
```

If the point code and subsystem number is not shown in the **rtrv-map** output, perform one of the “Provisioning a Mated Application” procedures in the *Database Administration Manual - Global Title Translation* and add the required point code and subsystem number to the mated application table.

- The point code specified with the **ent-gsmmap-scrn** command must be the DPC of a route.

If the point code specified with the **ent-gsmmap-scrn** command is an ANSI point code, the point code can be a member of a cluster point code when that cluster point code is the DPC of a route. Enter the **rtrv-rte** command with the **dpc** parameter specifying the point code to be used with the **ent-gsmmap-scrn** command to verify whether or not the point code is the DPC of a route. For this example, enter these commands.

**rtrv-rte:dpci=3-201-7**

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
DPCI          ALIASA/N24      ALIASA    LSN          RC    APC
3-201-7       12111                240-111-111 1s100001    10    1-234-5
                                     1s100002    10    1-234-6
                                     1s100003    20    1-234-7
                                     1s100004    30    1-234-1
                                     1s100005    40    1-234-2
                                     1s100006    50    1-234-3
RTX:No      CLLI=idp1
```

**rtrv-rte:dpcn=9384**

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
DPCN          ALIASA          ALIASI    LSN          RC    APC
9384          011-222-111    0-001-1 1s200001    10    11111
                                     1s200002    10    11112
                                     1s200003    20    11113
                                     1s200004    30    11114
                                     1s200005    40    11115
                                     1s200006    50    11116
RTX:No      CLLI=ndp1
```

```
rtrv-rte:dpci=4-102-6
```

This is an example of the possible output.

DPCI	ALIASN/N24	ALIASA	LSN	RC	APC
4-102-6	7659	240-039-150	ls100001	10	5-25-3
			ls100002	10	3-250-6
			ls100003	20	7-34-7
			ls100004	30	6-98-1
			ls100005	40	3-142-2
			ls100006	50	1-178-3
			RTX:No	CLLI=idp1	

If the point code is not shown in the **rtrv-rte** output, if the point code is an ANSI point code, the point code is not a member of a cluster point code when that cluster point code is the DPC of a route, go to the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database.

9. Add the new CGPA GSM MAP screening entries to the database with the **ent-gsmmap-scrn** command.

**NOTE: If a CDPA entry is being added to an existing CGPA entry, skip steps 9 and 10, and go to step 11.**

See [Table 5-6](#) for the parameter combinations that can be used with the **ent-gsmmap-scrn** command.

For this example, enter these commands:

```
ent-gsmmap-
scrn:saddr=9194600000:npv=5:naiv=75:opname=pass50 :forbid=none:action=p
ass:cgsr=cg01
```

```
ent-gsmmap-
scrn:saddr=252555100000:eaddr=252700000000:npv=12 :naiv=37:opname=disca
rd1:forbid=all:action=discard :cgsr=cg02
```

```
ent-gsmmap-
scrn:saddr=8284540000:eaddr=8284600000:opname=ati :forbid=state:action=
atierr:cgsr=cg03
```

```
ent-gsmmap-
scrn:saddr=2416546464:opname=route25 :forbid=all:action=route:npv=0:naiv=
127:cgsr=cg04
```

```
ent-gsmmap-
scrn:saddr=854000000:eaddr=857000000:opname=dd93 :forbid=all:action=for
ward:npv=3:naiv=99:pci=3-201-7 :ssn=100:cgsr=cg05:mapset=df1t
```

```
ent-gsmmap-
scrn:saddr=154363000000:eaddr=155000000000 :opname=sri:forbid=all:actio
n=duplicate:npv=8:naiv=86 :pcn=9384:ssn=30:cgsr=cg06:mapset=10
```

```
ent-gsmmap-
scrn:saddr=368900000:eaddr=369000000:opname=dup187 :forbid=all:action=d
updisc:npv=9:naiv=111:pci=4-102-6 :ssn=150:cgsr=cg07:mapset=20
```

When each of these commands has successfully completed, this message appears.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
GSM Map Screening table is (1512 of 4000) 38% full
ENT-GSMMAP-SCRN: MASP A - COMPLTD
```

- Verify the changes using the **rtrv-gsmmap-scrn** command and specifying the **opname** and **cgsr** parameter values specified in step 9.

For this example, enter these commands:

**rtrv-gsmmap-scrn:opname=pass50**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
Single CgPA Entries for OPNAME: pass50
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24       SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT  CGSR
9194600000    5 75 none pass cg01

Range CgPA Entries for OPNAME: pass50
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24       SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT  CGSR

GSM Map Screening table is (1512 of 4000) 38% full
```

**rtrv-gsmmap-scrn:opname=discard1**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
Single CgPA Entries for OPNAME: discard1
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24       SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT  CGSR

Range CgPA Entries for OPNAME: discard1
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24       SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT  CGSR
252555100000 252700000000    12 37 all disc cg02
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=ati**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: ati

```
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      CGSR
```

Range CgPA Entries for OPNAME: ati

```
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
```

8284540000 8284600000 \* \* state atier cg03

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=route25**

This is an example of the possible output.

rlghncxa03w 08-06-20 09:07:58 GMT EAGLE5 39.0.0

Single CgPA Entries for OPNAME: route25

```
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      CGSR
```

2416546464 0 127 all route cg04

Range CgPA Entries for OPNAME: ati

```
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=dd93**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: dd93

```
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      CGSR
```

Range CgPA Entries for OPNAME: dd93

```
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
854000000      857000000      3 99 all fwd          3-201-7      100 cg05
MAPSET = DFLT
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=sri**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: sri

```
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      CGSR
```

Range CgPA Entries for OPNAME: sri

```
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
1534363000000  1550000000000  8 86 all dupl          9384          30 cg06
MAPSET = 10
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=dup187**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: dup187
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT  CGSR

Range CgPA Entries for OPNAME: dup187
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
368900000      369000000      9 111 all  dupdc      4-102-6      150 cg07
MAPSET = 20

SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR

GSM Map Screening table is (1512 of 4000) 38% full
```

11. Add the new CDPA GSM MAP screening entries to the database with the **ent-gsmmap-scrn** command.

**NOTE: If a CDPA entry is not being added, or if the Enhanced GSM MAP Screening feature is not enabled or off (see the `rtrv-ctrl-feat` output in step 3), skip steps 11 and 12, and go to step 13.**

See [Table 5-6](#) for the parameter combinations that can be used with the **ent-gsmmap-scrn** command.

For this example, enter these commands:

```
ent-gsmmap-
scrn:opname=pass50:npv=6:naiv=15:forbid=all :action=pass:cgsr=cg01:cdsr
=cd01
```

```
ent-gsmmap-
scrn:opname=discard1:npv=10:naiv=15:forbid=all :action=discard:cgsr=cg0
2:cdsr=cd15
```

```
ent-gsmmap-
scrn:opname=dup187:npv=11:naiv=57:forbid=all :pci=5-97-2:ssn=135:action
=dupdisc:cgsr=cg07:cdsr=cd10 :mapset=30
```

When each of these commands has successfully completed, this message appears.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
GSM Map Screening table is (1512 of 4000) 38% full
ENT-GSMMAP-SCRN: MASP A - COMPLTD
```

12. Verify the changes using the **rtrv-gsmmap-scrn** command and specifying the **opname**, **cgsr**, and **cdsr** parameter values specified in step 11.

For this example, enter these commands:

```
rtrv-gsmmap-scrn:opname=pass50:cgsr=cg01:cdsr=cd01
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

SADDR          NP NAI FORBD ACT   CDSR
*              6  15  all  pass  cd01

GSM Map Screening table is (1512 of 4000) 38% full
```

```
rtrv-gsmmap-scrn:opname=discard1:cgsr=cg02:cdsr=cd15
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

SADDR          NP NAI FORBD ACT   CDSR
*              10 15  all  disc  cd15

GSM Map Screening table is (1512 of 4000) 38% full
```

```
rtrv-gsmmap-scrn:opname=dup187:cgsr=cg07:cdsr=cd10
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

SADDR          NP NAI FORBD ACT   PCI          SSN CDSR  MAPSET
*              11 57  all  dupdc  5-97-2      135 cd10  30


GSM Map Screening table is (1512 of 4000) 38% full
```


13. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


Flowchart 5-10. Adding a GSM MAP Screening Entry

















## Removing a GSM MAP Screening Entry

Use this procedure to remove the GSM MAP screening entries that filter or allow TCAP messages containing MAP operation codes, origination addresses, and forbidden parameters using the `dlt-gsmmap-scrn` command. The `dlt-gsmmap-scrn` command uses these parameters:

- :opname** – The user-defined name for the operation code. The **opname** value references the operation code (**opcode**) shown in the `rtv-gsms-opcode` command output.
- :cgsr** – The CGPA screening reference name
- :cdsr** – The CDPA screening reference name

If the GSM MAP Screening entry contains CDPA entries, the individual CDPA entries can be removed without removing the CGPA entry. However, if you wish to remove the CGPA entry, all CDPA entries assigned to the CGPA entry must be removed before the CGPA entry can be removed.

To remove CDPA entries, the **opname**, **cgstr**, and **cdsr** parameters must be specified with the **dlt-gsmmap-scrn** command. To remove CGPA entries, the **opname** and **cgstr** parameters must be specified with the **dlt-gsmmap-scrn** command.

Unlike GTT (Global Title Translation) entries, the GSM MAP screening commands do not support splits of ranges during removing or changing entries.

**Procedure**

1. Display the GSM MAP screening operation codes in the database using the **rtrv-gsms-opcode** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

OPCODE  OPNAME  DFLTACT  PCA          SSN
  36     for1    fwd      002-002-002  10

OPCODE  OPNAME  DFLTACT  PCI          SSN
  93     dd93    dupdc    5-25-3       200
  139    fwd139  fwd      3-159-7      128

OPCODE  OPNAME  DFLTACT  PCN          SSN
  187    dup187  dupl     11519        79

OPCODE  OPNAME  DFLTACT  PCN24        SSN

OPCODE  OPNAME  DFLTACT
  22     sri     disc
  25     route25 route
  50     pass50  pass
  71     ati     atiterr
  150    discard1 disc
  *      star   pass
```

GSMMS OPCODE Table (10 of 257) is 4% full

2. Enter the **rtrv-gsmmap-scrn** command with an **opname** value shown in the **rtrv-gsms-opcode** command output in step 1 to display the CGPA GSM MAP screening entries. For this example, enter these commands.

**rtrv-gsmmap-scrn:opname=pass50**

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: pass50
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR

SADDR          NP NAI FORBD ACT  CGSR
9194600000    5 75 none pass  cg01

Range CgPA Entries for OPNAME: pass50
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
```

```

SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
    
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=ati**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: ati

```

-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR

SADDR          NP NAI FORBD ACT      CGSR
919462000000005 1 0  locat atier atil
    
```

Range CgPA Entries for OPNAME: ati

```

-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI
SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN
SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR

SADDR          EADDR          NP NAI FORBD ACT      CGSR
8284540000      8284600000      * *  state atier cg03
919461888888888 919461900000000 4 1  locat atier ati2
919462000000000 919463000000000 * *  locat atier ati3
    
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=sri**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: sri

```

-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR

SADDR          NP NAI FORBD ACT      CGSR
    
```

Range CgPA Entries for OPNAME: sri

```

-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
    
```

```

SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
1534363000000  1550000000000      8 86 all dupl        9384         30 cg06
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
    
```

GSM Map Screening table is (1512 of 4000) 38% full

**NOTE: The `rtrv-gsmmap-scrn` output in step 2 shows only the CGPA entries in the MAP screening table for the specified OPNAME. The CGPA entries in step 2 could contain CDPA entries that would have to be removed before the CGPA entry could be removed. CDPA entries can be in the MAP screening table only if the Enhanced GSM MAP Screening feature is enabled and on.**

**If any of the following parameters or values are shown in the `rtrv-gsmmap-scrn` output in step 2, the Enhanced GSM MAP Screening feature is enabled and on. Skip step 3 and go to step 4.**

- `saddr=*`
- `pc/pca`
- The `saddr` or `eaddr` parameter values containing hex digits.

**If the `rtrv-gsmmap-scrn` output in step 2 does not show any of these parameters or values, it is possible that the Enhanced GSM MAP Screening feature is enabled and on. Perform step 3 to verify the status of the Enhanced GSM MAP Screening feature.**

3. Enter the `rtrv-ctrl-feat` command with the part number of the Enhanced GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893012401
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Enhanced GMS (EGMS)	893012401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

**NOTE: If step 3 shows that the Enhanced GSM MAP Screening feature is not enabled or off, CDPA entries cannot be in the MAP screening table. Skip step 4 and go to step 5.**

4. To display the CDPA entries assigned to the CGPA entry shown in step 2, enter the `rtrv-gsmmap-scrn` command with the `opname` and `cgsr` parameter values specified shown in step 2.

For this example, enter these commands.

```
rtrv-gsmmap-scrn:opname=pass50:cgsr=cg01
```

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CdPA Entries for OPNAME: pass50 and CGSR: cg01

```
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          NP NAI FORBD ACT      CDSR
*              6 15 all pass cd01
```

Range CdPA Entries for OPNAME: pass50 and CGSR: cg01

```
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      CDSR
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=ati:cgsr=cg03**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CdPA Entries for OPNAME: ati and CGSR: cg03

```
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          NP NAI FORBD ACT      CDSR
919461000000130 2 16 locat atier ati5
```

Range CdPA Entries for OPNAME: ati and CGSR: cg03

```
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      CDSR
4329290000      5450000000      * * state atier cd15
9194630000000000 9194640000000000 11 95 locat atier ati7
8035490000000000 8036500000000000 * * locat atier ati9
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=sri:cgsr=cg06**

This is an example of the possible output.

```

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: sri and CGSR: cg06
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          NP NAI FORBD ACT      CDSR

Range CgPA Entries for OPNAME: sri and CGSR: cg06
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      CDSR

GSM Map Screening table is (1512 of 4000) 38% full

```

- Remove the GSM MAP screening entries from the database with the **dlt-gsmmap-scrn** command.

If CDPA entries are being removed, these parameters must be specified with the **dlt-gsmmap-scrn** command: **opname**, **cgsr**, and **cdsr**.

If the GSM MAP Screening entry contains CDPA entries, the individual CDPA entries can be removed without removing the CGPA entry. However, if you wish to remove the CGPA entry, all CDPA entries assigned to the CGPA entry must be removed before the CGPA entry can be removed.

To remove a CGPA entry, enter the **dlt-gsmmap-scrn** command with the **opname**, and **cgsr** parameter values.

For this example, enter these commands:

```
dlt-gsmmap-scrn:opname=pass50:cgsr=cg01:cdsr=cd01
```

```
dlt-gsmmap-scrn:opname=ati:cgsr=cg03:cdsr=cd15
```

```
dlt-gsmmap-scrn:opname=sri:cgsr=cg06
```

To remove the CGPA entry **cg01** from the opname **pass50** (now that CGPA entry **cg01** has no CDPA entries assigned), enter this command:

```
dlt-gsmmap-scrn:opname=pass50:cgsr=cg01
```

When each of these commands has successfully completed, this message appears.

```

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
GSM Map Screening table is (1508 of 4000) 38% full
DLT-GSMMAP-SCRN: MASP A - COMPLTD

```

- Verify the changes using the **rtrv-gsmmap-scrn** command with the **opname** parameter value used in step 5.

If CDPA entries were removed from CGPA entries without removing the CGPA entry, specify the **opname** and **cgsr** parameter values used in step 5 with the **rtrv-gsmmap-scrn** command.

For this example, enter these commands:

**rtrv-gsmmap-scrn:opname=pass50**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: pass50
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          NP NAI FORBD ACT      CGSR

Range CgPA Entries for OPNAME: pass50
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR

GSM Map Screening table is (1508 of 4000) 38% full
```

**rtrv-gsmmap-scrn:opname=ati:cgsr=cg03**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CdPA Entries for OPNAME: ati and CGSR: cg03
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          NP NAI FORBD ACT      CDSR
919461000000130 2 16 locat atier ati5

Range CdPA Entries for OPNAME: ati and CGSR: cg03
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      CDSR
919463000000000 919464000000000 11 95 locat atier ati7
803549000000000 803650000000000 * * locat atier ati9

GSM Map Screening table is (1508 of 4000) 38% full
```


7. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
    
```

**Flowchart 5-11.** Removing a GSM MAP Screening Entry





## Changing a GSM MAP Screening Entry

Use this command to change the attributes of the GSM MAP screening entries that filter or allow TCAP messages for certain MAP operation codes using the **chg-gsmmap-scrn** command. The SCCP messages contain MAP operation codes, origination addresses, numbering plan values, nature of address indicator values, and forbidden parameters.

The **chg-gsmmap-scrn** command uses these parameters.

**:opname** – The user-defined name for the operation code. The **opname** value references the operation code (**opcode**) defined with the **ent-gsms-opcode** command. GSM MAP screening is performed on the specified address or addresses for the referenced operation code.

**:naction** – The new screening action to take if a message is forbidden as defined by the **forbid** parameter value. One of these actions can be assigned.

- **pass** – Route the message as normal to the destination.
- **discard** – The MSU is to be discarded.
- **atierr** – An ATI (Any Time Interrogation) reject message is generated. This option is only valid for ATI MAP operation codes.
- **route** – Route the message as normal to the original destination node.
- **forward** – Route the original message to the forward node. The original message is not sent to the original node. If, however, the forwarded node is not available for routing then the MSU is routed to the original node.
- **duplicate** – Route the message as normal to the original destination and route a copy of the original message to the duplicate node.
- **dupdisc** – Duplicate and discard – Route the original message to the duplicate node. The original message is not sent to the original node.

**:npc/npca/npci/npcn/npcn24** – The new ANSI point code (**npc/npca**), new ITU-I point code or ITU-I spare point code (**npci**), new 14-bit ITU-N point code or 14-bit ITU-N spare point code (**npcn**), or new 24-bit ITU-N point code (**npcn24**) of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions. The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both.

**:nssn** – The new subsystem number of the node that the MSU is routed to by the **forward**, **duplicate**, or **dupdisc** screening actions

**:force** – The mated application override. Is the GSM MAP screening operation code to be entered without a mated application in the database (**yes** or **no**)?

**:nforbid** – The new forbidden parameter value. If a forbidden parameter is detected, the message is rejected by the action defined by the **action** parameter value. One of four forbidden parameter values can be specified.

- **all** – All parameters are forbidden. Take the specified screening action defined by the **naction** parameter for incoming messages that contain the entered address and operation code combination.
- **none** – No parameters are forbidden. Take the specified screening action defined by the **naction** parameter for incoming messages that contain the entered address and operation code combination.
- **state** – Take the specified screening action defined by the **naction** parameter for incoming messages that contain **state** as the forbidden parameter for the entered address and operation code combination.

- **location** – Take the specified screening action defined by the **naction** parameter for incoming messages that contain **location** as the forbidden parameter for the entered address and operation code combination.

**:cgshr** – The current CGPA screening reference name.

**:cdsr** – The current CDPA screening reference name.

**:ncgshr** – The new CGPA screening reference name consisting of 1 alphabetic character and 3 optional alphanumeric characters.

**:ncdsr** – The new CDPA screening reference name consisting of 1 alphabetic character and 3 optional alphanumeric characters.

**:nmapset** – The new MAP set ID, shown in the **rtrv-map** command. This parameter can be specified only if the Flexible GTT Load Sharing feature is enabled. The status of the Flexible GTT Load Sharing feature is shown in the **rtrv-ctrl-feat** output. To enable the Flexible GTT Load Sharing feature, perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation* .

If a message is screened and does not contain matching **npv** and **naiv** values, the message is rejected. The message is rejected with the default action defined by the **chg-gsms-opcode** command for the operation code (**opcode**) parameter entry referenced by the operation name (**opname**) parameter.

[Table 5-9](#) shows the parameter combinations that can be used in this procedure.

**Table 5-9. Change GSM MAP Screening Entry Parameter Combinations**

Entry Containing a Point Code and SSN  Enhanced GSM MAP Screening Feature Enabled and On	Entry Without a Point Code and SSN  Enhanced GSM MAP Screening Feature Enabled and On	Entry containing the Action ATIERR  Enhanced GSM MAP Screening Feature Enabled and On	Entry Containing a Point Code and SSN  GSM MAP Screening Feature Enabled and On Only	Entry Without a Point Code and SSN  GSM MAP Screening Feature Enabled and On Only	Entry containing the Action ATIERR  GSM MAP Screening Feature Enabled and On Only
<b>Mandatory Parameters</b>					
:opname = current opname value <sup>2</sup>	:opname = current opname value <sup>2</sup>	:opname = current opname value containing opcode=71 <sup>2</sup>	:opname = current opname value <sup>2</sup>	:opname = current opname value <sup>2</sup>	:opname = current opname value containing opcode=71 <sup>2</sup>
:cgshr = current CGSR value	:cgshr = current CGSR value	:cgshr = current CGSR value	:cgshr = current CGSR value	:cgshr = current CGSR value	:cgshr = current CGSR value
<b>Optional Parameters<sup>1</sup></b>					
:cdsr = current CDSR value <sup>3, 4</sup>	:cdsr = current CDSR value <sup>3, 4</sup>	:cdsr = current CDSR value <sup>3, 4</sup>	:nforbid = all	:nforbid = all, none <sup>13</sup>	:nforbid = state, location
:nforbid = all	:nforbid = all, none <sup>13</sup>	:nforbid = state, location	:naction = forward, duplicate, dupdisc <sup>6</sup>	:naction = pass, discard, route <sup>13</sup>	:naction = atierr
:naction = forward, duplicate, dupdisc <sup>6</sup>	:naction = pass, discard, route <sup>13</sup>	:naction = atierr	:ncgshr = new CGSR value	:ncgshr = new CGSR value	:ncgshr = new CGSR value

Entry Containing a Point Code and SSN  Enhanced GSM MAP Screening Feature Enabled and On	Entry Without a Point Code and SSN  Enhanced GSM MAP Screening Feature Enabled and On	Entry containing the Action ATIERR  Enhanced GSM MAP Screening Feature Enabled and On	Entry Containing a Point Code and SSN  GSM MAP Screening Feature Enabled and On Only	Entry Without a Point Code and SSN  GSM MAP Screening Feature Enabled and On Only	Entry containing the Action ATIERR  GSM MAP Screening Feature Enabled and On Only
:ncgsr = new CGSR value 4, 5	:ncgsr = new CGSR value 4, 5	:ncgsr = new CGSR value 4, 5	:npci/npcn/npcn24 =point  code value 7, 8, 9, 10, 11, 12		
:ncdsr = new CDSR value 3, 5	:ncdsr = new CDSR value 3, 5	:ncdsr = new CDSR value 3, 5	nssn = SSN value 7, 8, 9, 10, 11, 12		
:npc/npca/npci/npcn/npcn24 = point code  value 7, 8, 9, 10, 11, 12			:force=yes 11, 12  :nmapset = dflt or numbered MAP set ID 11, 12		
:nssn = SSN value 7, 8, 9, 10, 11, 12					
:force=yes 11, 12					
:nmapset = dflt or numbered MAP set ID 11, 12					
<p>Notes:</p> <ol style="list-style-type: none"> <li>At least one optional parameter must be specified with the <b>chg-gsmmap-scrn</b> command. If the <b>cdsr</b> parameter is specified, at least one other optional parameter must be specified with the <b>chg-gsmmap-scrn</b> command.</li> <li>The <b>opname</b> parameter value must be shown in the <b>rtrv-gsms-opcode</b> output.</li> <li>The <b>cdsr</b> parameter must be specified when the <b>ncdsr</b> parameter is specified.</li> <li>The <b>ncgsr</b> parameter should not be specified when the <b>cdsr</b> parameter is specified.</li> <li>The <b>ncgsr</b> and <b>ncdsr</b> parameters cannot be specified together.</li> <li>The point code value must be the DPC of a route or a member of a cluster route. The <b>npc/npca</b> value must be a full point code, The <b>npc/npca</b> value can be a member of a cluster point code when that cluster point code is the DPC of a route. This can be verified with the <b>rtrv-rte</b> command. If the point code value is not shown in the <b>rtrv-rte</b> output as the DPC of a route, go to the "Adding a Route Containing an SS7 DPC" procedure in the <i>Database Administration Manual - SS7</i> and add a new route containing the point code value. A proxy point code cannot be assigned to the point code.</li> <li>The EAGLE 5 ISS can contain 14-bit ITU-N point codes or 24-bit ITU-N point codes, but not both at the same time.</li> <li>If the new or current (if unchanged) <b>action</b> parameter values are either <b>forward</b>, <b>duplicate</b>, or <b>dupdisc</b>, the point code and <b>nssn</b> parameters must be specified with the <b>chg-gsmmap-scrn</b> command. If the point code or subsystem number values are not being changed, the point code and subsystem number parameters must be specified with the current values for these parameters.</li> <li>If only the point code or subsystem number value is being changed, the point code or subsystem number value being changed must be specified with the new value for the parameter being changed. The current value for the point code or subsystem number parameter not being changed must be specified. The <b>naction</b> parameter does not have to be specified. For example, if the current point code is <b>pca=002-002-002</b> and the subsystem number is 50, and the point code is being changed to <b>pca=003-003-003</b> and the subsystem number is not changing, the <b>npca</b> parameter value would be the new point code value (003-003-003) and the <b>nssn</b> parameter value would be the current value (50).</li> </ol>					

Entry Containing a Point Code and SSN	Entry Without a Point Code and SSN	Entry containing the Action ATIERR	Entry Containing a Point Code and SSN	Entry Without a Point Code and SSN	Entry containing the Action ATIERR
Enhanced GSM MAP Screening Feature Enabled and On	Enhanced GSM MAP Screening Feature Enabled and On	Enhanced GSM MAP Screening Feature Enabled and On	GSM MAP Screening Feature Enabled and On Only	GSM MAP Screening Feature Enabled and On Only	GSM MAP Screening Feature Enabled and On Only

10. To specify the npc/npca parameters, the Enhanced GSM MAP Screening feature must be enabled and turned on.

11. If the Flexible GTT Load Sharing feature is not enabled:

- The **nmapset** parameter cannot be specified.
- The point code and subsystem number values specified with the **chg-gsmmap-scrn** command must be shown in the **rtrv-map** output, or else the **force=yes** parameter must be specified. If the point code and subsystem number values are not shown in the **rtrv-map** output, and a new mated application is to be added, perform one of the "Provisioning a Mated Application" procedures in the *Database Administration Manual - Global Title Translation* and add the required mated application with the point code and subsystem number values.

12. If the Flexible GTT Load Sharing feature is enabled:

- If the current **action** parameter value is either **pass**, **route**, **discard**, or **atierr**, and the **action** parameter value is changed to either **forward**, **duplicate**, or **dupdisc**, the GSM MAP screening entry must be assigned to a MAP set with the **nmapset=dflt** parameter (to assign the GSM MAP screening entry to the default MAP set), or with the **nmapset=<numbered MAP set ID>** parameter (to assign the GSM MAP screening entry to a MAP set other the default MAP set).
- If the default MAP set will be assigned to the GSM MAP screening entry, the **npc/npca/npci/npcn/npcn24** and **nssn** values must be shown in the default MAP set in the **rtrv-map** output. If the **npc/npca/npci/npcn/npcn24** or **nssn** values are not shown in the default MAP set in the **rtrv-map** output, the **force=yes** parameter must be specified.
- If a MAP set other than the default MAP set will be assigned to the GSM MAP screening entry, the **npc/npca/npci/npcn/npcn24** and **nssn** values must be shown in that MAP set in the **rtrv-map** output.
- If the point code and subsystem values are not being changed, the **nmapset** parameter does not have to be specified unless the MAP set ID assigned to the GSM MAP screening entry is being changed. The new MAP set must contain the point code and subsystem values in the GSM MAP screening entry.

13. If the value of the **forbid** parameter is being changed to **none**, and the current value of the **action** parameter is not **pass**, the **naction=pass** parameter must be specified. If the current value of the **forbid** parameter is **none** and will not be changed, the value of the **action** parameter must be **pass** and cannot be changed.

**Procedure**

1. Display the GSM MAP screening operation codes in the database using the **rtrv-gsms-opcode** command.

If the Flexible GTT Load Sharing feature is not enabled, this is an example of the possible output.

```
rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

OPCODE  OPNAME    DFLTACT   PCA      SSN
  36     for1      fwd       002-002-002  10

OPCODE  OPNAME    DFLTACT   PCI      SSN
  93     dd93     dupdc     5-25-3   200
 139     fwd139   fwd       3-159-7  128

OPCODE  OPNAME    DFLTACT   PCN      SSN
 187     dup187   dupl     11519    79
```

```

OPCODE  OPNAME    DFLTACT  PCN24      SSN
OPCODE  OPNAME    DFLTACT
 22     sri       disc
 25     route25  route
 50     pass50   pass
 71     ati      atierr
 150    discard1 disc
 *     star    pass
    
```

GSMSMS OPCODE Table (10 of 257) is 4% full

If the Flexible GTT Load Sharing feature is enabled, this is an example of the possible output.

```

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 36.0.0

OPCODE  OPNAME    DFLTACT  PCA         SSN  MAPSET
 36     for1     fwd      002-002-002 10   25

OPCODE  OPNAME    DFLTACT  PCI         SSN  MAPSET
 93     dd93     dupdc    5-025-3    200  20
 139    fwd139   fwd      3-159-7    128  DFLT

OPCODE  OPNAME    DFLTACT  PCN         SSN  MAPSET
 187    dup187   dupl     11519      79   10

OPCODE  OPNAME    DFLTACT  PCN24      SSN  MAPSET

OPCODE  OPNAME    DFLTACT
 22     sri       disc
 25     route25  route
 50     pass50   pass
 71     ati      atierr
 150    discard1 disc
 *     star    pass
    
```

GSMSMS OPCODE Table (10 of 257) is 4% full

If the default action for the GSM MAP screening entry will be **atierr**, or the **forbid** parameter value will be **location** or **state**, the **opname** value must contain an **opcode** value of 71.

2. Enter the **rtrv-gsmmap-scrn** command with an **opname** value shown in the **rtrv-gsms-opcode** command output in step 1 to display the CGPA GSM MAP screening entries to change.

For this example, enter this command.

**rtrv-gsmmap-scrn:opname=ati**

This is an example of the possible output.

```

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: ati
-----
SADDR          NP NAI FORBD ACT      PCA         SSN CGSR
SADDR          NP NAI FORBD ACT      PCI         SSN CGSR
SADDR          NP NAI FORBD ACT      PCN         SSN CGSR
SADDR          NP NAI FORBD ACT      PCN24      SSN CGSR

SADDR          NP NAI FORBD ACT  CGSR
91946200000005 1 0  locat atier atil

Range CgPA Entries for OPNAME: ati
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA
SSN CGSR
    
```

```

SADDR          EADDR          NP NAI FORBD ACT    PCI          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    CGSR
8284540000     8284600000     * * state atier cg03
91946188888888 919461900000000 4 1 locat atier ati2
919462000000000 919463000000000 * * locat atier ati3
    
```

GSM Map Screening table is (1512 of 4000) 38% full

**rtrv-gsmmap-scrn:opname=dd93**

This is an example of the possible output.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: dd93

```

-----
SADDR          NP NAI FORBD ACT    PCA          SSN CGSR
SADDR          NP NAI FORBD ACT    PCI          SSN CGSR
SADDR          NP NAI FORBD ACT    PCN          SSN CGSR
SADDR          NP NAI FORBD ACT    PCN24        SSN CGSR
SADDR          NP NAI FORBD ACT    CGSR
    
```

Range CgPA Entries for OPNAME: dd93

```

-----
SADDR          EADDR          NP NAI FORBD ACT    PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCI          SSN CGSR
854000000     857000000     3 99 all fwd      3-201-7     100 cg05
SADDR          EADDR          NP NAI FORBD ACT    PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    CGSR
    
```

GSM Map Screening table is (1512 of 4000) 38% full

If the Flexible GTT Load Sharing feature is enabled, the **MAPSET** field is shown in the **rtrv-gsmmap-scrn** output as shown in the following output example.

rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: dd93

```

-----
SADDR          NP NAI FORBD ACT    PCA          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT    PCI          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT    PCN          SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT    PCN24        SSN CGSR  MAPSET
SADDR          NP NAI FORBD ACT    CGSR
    
```

Range CgPA Entries for OPNAME: dd93

```

-----
SADDR          EADDR          NP NAI FORBD ACT    PCA          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT    PCI
SSN CGSR
    
```

```

854000000      857000000      3 99 all fwd      3-201-7      100 cg05
MAPSET = DFLT

SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CGSR
SADDR          EADDR          NP NAI FORBD ACT      CGSR
    
```

GSM Map Screening table is (1512 of 4000) 38% full

**NOTE: If the `npc/npca` or `ncdsr` parameters are being specified in this procedure, the Enhanced GSM MAP Screening feature must be enabled and on. If these parameters are not being specified in this procedure, skip step 3 and go to step 4.**

**If any of the following parameters or values are shown in the `rtrv-gsmmap-scrn` output in this step, the Enhanced GSM MAP Screening feature is enabled and on. Skip step 3 and go to step 4.**

- `saddr=*`
- `pc/pca`
- The `saddr` or `eaddr` parameter values containing hex digits.

**If the `rtrv-gsmmap-scrn` output in this step does not show any of these parameters or values, it is possible that the Enhanced GSM MAP Screening feature is enabled and on. If you wish to use the `npc/npca` or `ncdsr` parameters, perform step 3 to verify the status of the Enhanced GSM MAP Screening feature.**

3. Verify that the Enhanced GSM MAP Screening feature is enabled and on by entering the `rtrv-ctrl-feat` command with the part number of the Enhanced GSM MAP Screening feature.

Enter this command.

```
rtrv-ctrl-feat:partnum=893012401
```

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:15:37 GMT EAGLE5 36.0.0
The following features have been permanently enabled:
```

Feature Name	Partnum	Status	Quantity
Enhanced GSM (EGMS)	893012401	on	----

The following features have been temporarily enabled:

Feature Name	Partnum	Status	Quantity	Trial Period Left
Zero entries found.				

The following features have expired temporary keys:

Feature Name	Partnum
Zero entries found.	

- If the Enhanced GSM MAP screening feature is not enabled or is turned off, and you wish to use the `npc/npca` or `ncdsr` parameters, perform the [Activating the GSM MAP Screening Feature](#) procedure to enable and turn on the Enhanced GSM MAP Screening feature. After the Enhanced GSM MAP Screening feature has been enabled and turned on, continue the procedure with step 4.
- Skip step 4 and continue the procedure with step 5 if:
  - The Enhanced GSM MAP Screening feature will not be enabled and turned on in this step.

- The **npc**/**npca** or **ncdsr** parameters will not be specified in this procedure and the Enhanced GSM MAP Screening feature is enabled and turned on.

4. Enter the **rtrv-gsmmap-scrn** command with an **opname** and **cgsr** values shown in the **rtrv-gsmmap-scrn** command output in step 2 to display the CDPA GSM MAP screening entries to change. For this example, enter this command.

**rtrv-gsmmap-scrn:opname=ati:cgsr=cg03**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
Single CdPA Entries for OPNAME: ati and CGSR: cg03
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          NP NAI FORBD ACT      CDSR
919461000000130 2 16 locat atier ati5
Range CdPA Entries for OPNAME: ati and CGSR: cg03
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      CDSR
4329290000    5450000000    * * state atier cd15
9194630000000000 9194640000000000 11 95 locat atier ati7
8035490000000000 8036500000000000 * * locat atier ati9
GSM Map Screening table is (1512 of 4000) 38% full
```

**rtrv-gsmmap-scrn:opname=dd93:cgsr=cg05**

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
Single CdPA Entries for OPNAME: dd93 and CGSR: cg05
-----
SADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          NP NAI FORBD ACT      PCI          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN          SSN CDSR
SADDR          NP NAI FORBD ACT      PCN24        SSN CDSR
SADDR          NP NAI FORBD ACT      CDSR
Range CgPA Entries for OPNAME: dd93 and CGSR: cg05
-----
SADDR          EADDR          NP NAI FORBD ACT      PCA          SSN CDSR
SADDR          EADDR          NP NAI FORBD ACT      PCI          SSN CDSR
```

```

SADDR      EADDR      NP NAI FORBD ACT      PCN      SSN CDSR
SADDR      EADDR      NP NAI FORBD ACT      PCN24    SSN CDSR
SADDR      EADDR      NP NAI FORBD ACT      CDSR
    
```

GSM Map Screening table is (1512 of 4000) 38% full

**NOTE: If the Flexible GTT Load Sharing feature is enabled, the MAPSET field is shown in the `rtrv-gsmmap-scrn` output if the action parameter value for the GSM MAP screening entry is either `forward`, `duplicate`, or `dupdisc`.**

5. Perform one of these actions.

- If the **naction** parameter value will be either **pass**, **discard**, **route**, or **atierr**, skip steps 6 through 9, and continue the procedure with step 10.
- If the point code is not being changed, skip steps 6 through 9, and continue the procedure with step 10. If the point code and subsystem values are not being changed, and the Flexible GTT Load Sharing feature is enabled, the **nmapset** parameter does not have to be specified unless the MAP set ID assigned to the GSM MAP screening entry is being changed. The new MAP set must contain the point code and subsystem values in the GSM MAP screening entry.
- If the **naction** parameter value will be either **forward**, **duplicate**, or **dupdisc**, perform one of these actions.
  - To use a point code and a MAP set from the mated application table, and MAP sets are not shown in the **rtrv-gsmmap-scrn** output in step 4, the Flexible GTT Load Sharing Feature must be enabled. Perform the “Activating the Flexible GTT Load Sharing Feature” procedure in the *Database Administration Manual - Global Title Translation* and enable the Flexible GTT Load Sharing feature. After enabling the Flexible GTT Load Sharing feature, skip steps 6 and 7 and continue the procedure with step 8.
  - To use a point code and a MAP set from the mated application table, and MAP sets are shown in the **rtrv-gsmmap-scrn** output in step 4, skip steps 6 and 7 and continue the procedure with step 8.
  - To use a point code in the mated application table, but without using a MAP set, and MAP sets are not shown in the **rtrv-gsmmap-scrn** output in step 4, skip steps 6 and 7 and continue the procedure with step 8.
  - To use a point code that is not in the mated application table, the **force=yes** parameter must be specified with the **chg-gsmmap-scrn** command. A proxy point code cannot be assigned to this point code. If the Flexible GTT Load Sharing feature is enabled, the **force=yes** parameter can be used only if the default MAP set is assigned to the GSM OPCODE entry. Continue the procedure with step 6.

6. Display the destination point codes in the database by entering the **rtrv-dstn** command. This is an example of the possible output.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

```

DPCA      CLLI      BEI  ELEI  ALIASI      ALIASN      DOMAIN
001-207-000  ----- no  ---  -----  -----  SS7
001-001-001  ----- no  ---  -----  -----  SS7
001-001-002  ----- no  ---  -----  -----  SS7
001-005-000  ----- no  ---  -----  -----  SS7
001-007-000  ----- no  ---  -----  -----  SS7
008-012-003  ----- no  ---  -----  -----  SS7
003-002-004  ----- no  ---  -----  -----  SS7
009-002-003  ----- no  ---  -----  -----  SS7
010-020-005  ----- no  ---  -----  -----  SS7
    
```

DPCI	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
1-207-0	-----	no	---	-----	-----	SS7
0-015-0	-----	no	---	-----	-----	SS7
0-017-0	-----	no	---	-----	-----	SS7
1-011-1	-----	no	---	-----	-----	SS7
1-011-2	-----	no	---	-----	-----	SS7
DPCN	CLLI	BEI	ELEI	ALIASA	ALIASI	DOMAIN
DPCN24	CLLI	BEI	ELEI	ALIASA	ALIASI	DOMAIN

Destination table is (14 of 2000) 1% full  
 Alias table is (0 of 12000) 0% full  
 PPC table is (1 of 20) 5% full

If the required point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* to add the required point code. A proxy point code cannot be assigned to the point code.

After the new point code has been added, skip steps 7 through 9 and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 10.

7. Display the point code that will be assigned to the mated application by using the **rtrv-dstn** command and specifying the point code. For this example, enter this command.

**rtrv-dstn:dpca=010-020-005**

This is an example of the possible output.

rlghncxa03w 06-10-10 11:43:04 GMT EAGLE5 37.5.0

DPCA	CLLI	BEI	ELEI	ALIASI	ALIASN	DOMAIN
010-020-005	-----	no	---	-----	-----	SS7
PPC	NCAI		PRX			
009-002-003	----		no			

Destination table is (14 of 2000) 1% full  
 Alias table is (0 of 12000) 0% full  
 PPC table is (1 of 20) 5% full

If the adjacent point code is not shown in the **rtrv-dstn** command output, the following output is displayed.

DPCA	CLLI	BEI	ELEI	ALIASI	ALIASN/N24	DOMAIN
------	------	-----	------	--------	------------	--------

No destinations meeting the requested criteria were found

Destination table is (14 of 2000) 1% full  
 Alias table is (0 of 12000) 0% full  
 PPC table is (1 of 20) 5% full

A proxy point code (a point code value is shown in the **PPC** column) cannot be assigned to the point code. If a proxy point code is shown in this step, choose another point code from the **rtrv-dstn** output in the previous step and repeat this step.

If the point code is not shown in the **rtrv-dstn** output, perform the "Adding a Destination Point Code" procedure in the *Database Administration Manual - SS7* and add the adjacent point code to the destination point code table.

After the new point code has been added, skip steps 8 and 9, and perform the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database. After the route has been added, continue the procedure with step 10.

8. The point code and subsystem number being assigned to the GSM MAP screening entry must be in the mated application table.

Enter the **rtrv-map** command with the **npc/npca/npci/npcn/npcn24** and **nssn** values that will be specified with the **chg-gsmmap-scrn** command in step 10.

If the Flexible GTT Load Sharing feature is not enabled, for this example, enter these commands.

```
rtrv-map:pci=5-79-2:ssn=89
```

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCI           Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
5-79-2                89 10 SOL --- --- GRP01  ON
```

**NOTE: If the point code and subsystem number is not shown in the rtrv-map output, and is not added to the database in one of these procedures, the force=yes parameter must be specified with the chg-gsmmap-scrn command in step 10.**

If the Flexible GTT Load Sharing feature is enabled and the current **action** parameter value is either **pass**, **route**, **discard**, or **atierr**, and the **action** parameter value is changed to either **forward**, **duplicate**, or **dupdisc**, the GSM MAP screening entry must be assigned to a MAP set with the **nmapset=dflt** parameter (to assign the GSM MAP screening entry to the default MAP set), or with the **nmapset=<numbered MAP set ID>** parameter (to assign the GSM MAP screening entry to a MAP set other the default MAP set).

For this example, enter these commands.

```
rtrv-map:pci=5-79-2:ssn=89
```

This is an example of the possible output.

```
rlghncxa03w 06-10-25 09:42:31 GMT EAGLE5 36.0.0
MAP TABLE IS 2 % FULL (20 of 1024)
PCI           Mate PCI      SSN RC MULT SRM MRC GRP NAME SSO
MAPSET ID=20
5-79-2                89 10 SOL --- --- GRP01  ON
```

If the point code and subsystem number is not shown in the **rtrv-map** output, perform one of the "Provisioning a Mated Application" procedures in the *Database Administration Manual - Global Title Translation* and add the required point code and subsystem number to the mated application table.

9. The point code specified with the **chg-gsmmap-scrn** command must be the DPC of a route. Enter the **rtrv-rte** command with the **dpc** parameter specifying the point code to be used with the **chg-gsmmap-scrn** command to verify whether or not the point code is the DPC of a route. For this example, enter these commands.

```
rtrv-rte:dpci=5-79-2
```

This is an example of the possible output.

```
rlghncxa03w 06-10-07 11:43:04 GMT EAGLE5 36.0.0
```

DPCI	ALIASN/N24	ALIASA	LSN	RC	APC
5-79-2	1501	230-101-191	ls100001	10	1-234-5
			ls100002	10	3-65-4
			RTX:No	CLLI=idp9	

If the point code is not shown in the **rtrv-rte** output, go to the "Adding a Route Containing an SS7 DPC" procedure in the *Database Administration Manual - SS7* and add the required route to the database.

- Change the GSM MAP screening entry with the **chg-gsmmap-scrn** command.

[Table 5-9](#) shows the parameter combinations that can be used with the **chg-gsmmap-scrn** command.

For this example, the Enhanced GSM MAP Screening feature is enabled and on. Enter these commands:

```
chg-gsmmap-
scrn:opname=ati:cgsr=cg03:cdsr=cd15:nforbid=none :naction=pass

chg-gsmmap-
scrn:opname=dd93:cgsr=cg05:nforbid=none:naction=pass:npci=5-79-2 :nssn=
89:nmapset=20
```

When this command has successfully completed, this message appears.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0
GSM Map Screening table is (1512 of 4000) 38% full
CHG-GSM MAP-SCRN: MASP A - COMPLTD
```

- Verify the changes using the **rtrv-gsmmap-scrn** command, specifying the **opname** parameter value used in step 10.

If the **cdsr** parameter was specified in step 10, specify the **cgsr**, and **cdsr** parameter values used in step 10 with the **opname** parameter value. For this example, the Enhanced GSM MAP Screening feature is enabled and on. Enter these commands:

```
rtrv-gsmmap-scrn:opname=ati:cgsr=cg03:cdsr=cd15
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

SADDR          EADDR          NP NAI FORBD ACT  CDSR
8284540000     8284600000     * * none pass    cd15
```

GSM Map Screening table is (1512 of 4000) 38% full

```
rtrv-gsmmap-scrn:opname=dd93
```

This is an example of the possible output.

```
rlghncxa03w 06-10-20 09:07:58 GMT EAGLE5 36.0.0

Single CgPA Entries for OPNAME: dd93
-----
SADDR          NP NAI FORBD ACT  PCA          SSN CGSR
SADDR          NP NAI FORBD ACT  PCI          SSN CGSR
SADDR          NP NAI FORBD ACT  PCN          SSN CGSR
SADDR          NP NAI FORBD ACT  PCN24        SSN CGSR
SADDR          NP NAI FORBD ACT  CGSR

Range CgPA Entries for OPNAME: dd93
-----
SADDR          EADDR          NP NAI FORBD ACT  PCA          SSN CGSR
```

```

SADDR      EADDR      NP NAI FORBD ACT   PCI      SSN CGSR
854000000  860000000  3 99 none pass    5-79-2   89 cg05
MAPSET = 20

SADDR      EADDR      NP NAI FORBD ACT   PCN      SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT   PCN24    SSN CGSR
SADDR      EADDR      NP NAI FORBD ACT   CGSR

GSM Map Screening table is (1512 of 4000) 38% full
    
```


12. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```


BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
    
```


Flowchart 5-12. Changing a GSM MAP Screening Entry














## Changing the GSM MAP Screening TCAP Continue and End Message Processing Option

The option for enabling or disabling the processing of GSM MAP screening TCAP Continue and TCAP End messages can be changed with the **chg-sccpopts** command and with the following parameter:

**:gmstcapce** – This parameter has two values:

- **on** – enables the processing of TCAP Continue and TCAP End messages.
- **off** – disables the processing of TCAP Continue and TCAP End messages.

The system default value for this parameter is **off**.

The value of the **gmstcapce** parameter is shown in the **GMSTCAPCE** field of the **rtrv-sccpopts** output. The **GMSTCAPCE** field of the **rtrv-sccpopts** output is shown only when the GSM MAP Screening feature is

enabled and turned on. If the **GSMTCAPCE** field is not shown in the **rtrv-sccpopts** output, perform the [Activating the GSM MAP Screening Feature](#) to enable and turn on the GSM MAP screening feature.

### Procedure

1. Display the existing value for the **gsmtcapce** parameter by entering the **rtrv-sccpopts** command. The value for the **gsmtcapce** parameter is shown in the **GSMTCAPCE** field. This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:02:05 GMT EAGLE5 36.0.0

SCCP OPTIONS
-----
GSMTCAPCE                off
```

**NOTE:** The **rtrv-sccpopts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sccpopts** command, see the **rtrv-sccpopts** command description in the *Commands Manual*.

If the **GSMTCAPCE** field is not shown in the **rtrv-sccpopts** output, perform the [Activating the GSM MAP Screening Feature](#) to enable and turn on the GSM MAP screening feature. After the GSM MAP Screening feature is enabled and turned on, go to step 2.

If the **GSMTCAPCE** field is shown in the **rtrv-sccpopts** output, go to step 2.

2. Change the **gsmtcapce** parameter value by entering one of the following commands.

If the current value of the **gsmtcapce** parameter is **off**, or if the GSM MAP Screening feature was enabled and turned on in step 1, enter the following command to enable the processing of TCAP Continue and TCAP End messages.

```
chg-sccpopts:gsmtcapce=on
```

If the current value of the **gsmtcapce** parameter is **on**, enter the following command to disable the processing of TCAP Continue and TCAP End messages.

```
chg-sccpopts:gsmtcapce=off
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-07 00:22:57 GMT EAGLE5 36.0.0
CHG-SCCPOPTS: MASP A - COMPLTD
```

3. Verify the changes using the **rtrv-sccpopts** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-17 16:02:05 GMT EAGLE5 36.0.0

SCCP OPTIONS
-----
GSMTCAPCE                on
```

**NOTE:** The **rtrv-sccpopts** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-sccpopts** command, see the **rtrv-sccpopts** command description in the *Commands Manual*.


4. Backup the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
```

BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.  
 BACKUP (FIXED): MASP A - Backup starts on standby MASP.  
 BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.

Flowchart 5-13. Changing the GSM MAP Screening TCAP Continue and End Message Processing Option



# EAGLE 5 Integrated Monitoring Support Configuration


Introduction .....	6-1
TCP/IP Link Provisioning .....	6-4
Time Stamping .....	6-5
EAGLE 5 ISS Provisioning .....	6-5
Network Considerations .....	6-7
IP Address Provisioning .....	6-8
Route Configuration .....	6-8
Network Limitations .....	6-8
Enabling the Time Slot Counter Synchronization (TSCSYNC) and EAGLE 5 Integrated Monitoring Support (E5IS) Features .....	6-8
Configuring the EAGLE 5 Integrated Monitoring Support Options .....	6-11
Adding a Signaling Transport Card (STC) .....	6-19
Removing a Signaling Transport Card (STC) .....	6-24

## Introduction

The EAGLE 5 Integrated Monitoring Support feature allows the network traffic on the EAGLE 5 ISS's signaling links to be monitored by an ESP (extended services platform) or IMF (integrated message feeder) without additional intrusive cabling.


To monitor the network traffic on the EAGLE 5 ISS's signaling links without this feature requires physical, clamp-on connections to the EAGLE 5 ISS's SS7 signaling links (see [Figure 6-1](#)). This monitoring method involves costs for cable installation and maintenance for each SS7 link that is to be monitored.

Figure 6-1. Monitoring via Hardware Connection




This feature eliminates the need to have intrusive hardware for each link that is to be monitored. The monitoring is performed by an Ethernet connection from an STC ( Signaling Transport Card) to the ESP/IMF (see [Figure 6-2](#) ). Message Signaling Units (MSUs), alarms, and events may be copied to the ESP/IMF subsystem over the Ethernet link to provide the network traffic monitoring.

Figure 6-2. EAGLE 5 Integrated Monitoring Support Network Connectivity



As can be seen in [Figure 6-2](#) , this new method of connectivity removes the cabling and clamps from each monitored SS7 link. By incorporating a TCP/IP stack on each LIM and having the STCs serve as IP routers, the ESP/IMF subsystem may communicate directly with the SS7 LIMs. [Figure 6-3](#) shows the logical communications pathway.

Figure 6-3. ESP/IMF/EAGLE 5 ISS Network




The STC communicates to the LIM by the IMT bus; the IP messages are simply encapsulated in an IMT wrapper between the cards. The STCs are provisioned in an  $n+1$  configuration for redundancy. Each STC Ethernet port has a separate connection path to each Ethernet switch in order to provide an alternate path in the event of an Ethernet link failure. Note that the figure depicts a redundant network; this assures that a single network failure will not halt EAGLE 5 ISS or ESP/IMF operations. As shown in [Figure 6-3](#), one or more ESP/IMF may be connected to a single Ethernet switch. The number of STCs required corresponds to the number of SS7 links that are to be associated with the EAGLE 5 Integrated Monitoring Support feature, plus an additional STC for redundancy.

The LIMs are assigned private network addresses. The IP message origination address specified is that of the LIM. The IP message destination address is that of the VIP (virtual IP address) contained within the ESP/IMF server. The STC serves as a router from the LIM to the ESP/IMF servers.

## TCP/IP Link Provisioning

The IP communications link, used to transmit copied MSUs between the EAGLE 5 ISS and the ESP/IMF subsystem, is dynamically configured by the Sentinel/IMF. This is performed automatically as part of the operations for coming into service. A special function, part of the card's application software, is to establish communications with the ESP/IMF subsystem by sending a service request message (see [Figure 6-4](#)).

**Figure 6-4.** Ethernet Link Establishment - EMP Link Data



*Diagram depicts example of normal link data message flow.*

The LIM receiving the service accept response then opens a new socket using the specified IP address and port as the destination using standard TCP/IP socket messaging. The ESP/IMF server configured to service the port responds to the connect request and the socket is now available for normal operations. MSUs are copied from the LIM through the STC to the ESP/IMF server, then to the Sentinel/IMF.

If the LIM is unsuccessful with its initial link service request, it will reattempt link establishment with the ESP/IMF subsystem after delaying for a short period (that is, approximately 15 seconds). The LIM continuously repeats the link establishment procedure until it is successful. If the LIM ever loses its IP connection to the ESP server, the LIM will automatically begin reestablishment operations.

The STCs use DHCP ( Dynamic Host Configuration Protocol) to provision themselves with IP addresses. The ESP/IMF subsystem contains a DHCP server and a DHCP client resides on the STC. The STC receives its IP address from the DHCP server in accordance with the DHCP standard.

A custom routing protocol, TRP (Tekelec Routing Protocol) manages the multiple redundant links and provides a faster network convergence than is possible with standard routing protocols.

## Time Stamping

The MSU information will be delivered to the ESP/IMF subsystem with an accurate time stamp ( $\pm 5$  milliseconds). This allows the Sentinel/IMF to correlate a call's messages for CDR (Call Detail Record) operations.

## EAGLE 5 ISS Provisioning

To provision this feature, these items are required:

- STCs are installed in the EAGLE 5 ISS

- The TSC (Time Slot Counter) Synchronization feature is enabled in the EAGLE 5 ISS. TSC synchronization is supplied by the GPSM-II cards in card locations 1113 and 1115.
- A timing source for the low-speed signaling links and for the TSC (Time Slot Counter) synchronization feature  
If the EAGLE 5 ISS does not contain LIMDS0 cards, but contains TDM part numbers 870-0774-15 or later, the clock source for any low-speed links and for the TSC (Time Slot Counter) synchronization feature used by the Sentinel/IMF can be generated from the high-speed master clock source. An external BITS clock is not required.  
  
If an external BITS clock is connected to an EAGLE 5 ISS without LIMDS0 cards, but with TDM part numbers 870-0774-15 or later, the external BITS clock must be used as the clock source for any low-speed links and for the TSC (Time Slot Counter) synchronization feature.  
  
If LIMDS0 cards are present in the EAGLE 5 ISS, the external BITS clock is required for timing of the DS0 signaling links and for TSC (Time Slot Counter) synchronization used by the Sentinel/IMF. If the EAGLE 5 ISS also contains TDM part numbers 870-0774-15 or later along with the LIMDS0 cards, this procedure can be used to select the source of the high-speed master clock for the high-speed links using external timing. The high-speed master clock source cannot be used to generate the clock source for any low-speed links and for the TSC (Time Slot Counter) synchronization feature.
- A Network Time Protocol (NTP) timing source from the ESP/IMF server
- The EAGLE 5 ISS shelves can contain HMUX or HIPR cards. Shelves containing IPLIMx or IPGWx cards that are being monitored must contain HIPR cards.

An “n + 1” STC configuration is required to provide redundancy for this feature.

The connection from the EAGLE 5 ISS to the ESP is an Ethernet connection with a minimum bandwidth of 10 Mbps. The dual-slot STC contains two 10 Mbps Ethernet ports. The single-slot STC contains two 100 Mbps Ethernet ports.

Refer to the *Hardware Manual - EAGLE 5 ISS* for more information about the GPSM-II and STCs.

The *n+1* STC configuration requires that a minimum of two STCs must be provisioned in the database. If single-slot STCs are being provisioned in the database, a minimum of two single-slot STCs must be provisioned.

[Table 6-1](#) shows the signaling links on these cards can be monitored by this feature.

**Table 6-1. Monitored Card Types**

Card Application (APPL Value Used by the ent-card Command)	Card Type (TYPE Value Used by the ent-card Command)	Card Name
SS7ANSI, CCS7ITU	LIMDS0	LIM-DS0, EILA, ILA, MPL
	LIMOCU	LIM-OCU, EILA, ILA, MPL
	LIMV35	LIM-V.35, EILA, ILA, MPL
	LIME1	E1/T1 MIM, LIM-E1, HC MIM, E5-E1T1 card
	LIMT1	E1/T1 MIM, HC MIM, E5-E1T1 card
	LIMCH	E1/T1 MIM, LIM-E1
ATMANSI	LIMATM	LIM-ATM , E5-ATM

Card Application (APPL Value Used by the ent-card Command)	Card Type (TYPE Value Used by the ent-card Command)	Card Name
ATMITU	LIME1ATM	E1-ATM , E5-ATM
IPLIM	DCM	Single-Slot EDCM, E5-ENET card
IPLIMI	DCM	Single-Slot EDCM, E5-ENET card
SS7IPGW	DCM	Single-Slot EDCM, E5-ENET card
IPGWI	DCM	Single-Slot EDCM, E5-ENET card
<p>Notes:</p> <p>Only signaling links assigned to M2PA associations can be monitored on the cards running the IPLIM and IPLIMI applications. This can be verified by entering the <code>rtrv-assoc:adapter=m2pa</code> command.</p> <p>Only signaling links assigned to M3UA associations can be monitored on the cards running the SS7IPGW and IPGWI applications. This can be verified by entering the <code>rtrv-assoc:adapter=m3ua</code> command.</p> <p>Monitoring can be performed on single-slot EDCMs, E5-E1T1 cards, and E5-ENET cards using only the IMF.</p> <p>Monitoring can be performed on E1 signaling links (assigned to the LIME1 card type) only for channelized E1 signaling links. A channelized E1 signaling link is a signaling link that is assigned to a channelized E1 port, shown by the entry <b>CHAN</b> in the <b>LINKCLASS</b> field in the <code>rtrv-e1</code> output.</p>		

The signaling links assigned to the cards running either the `ss7ansi` or `ccs7itu` applications are low-speed signaling links transmitting at either 56 kbps or 64 kbps. Signaling links assigned to the `atmansi` and `atmitu` applications are high-speed signaling links transmitting at 1.544 Mbps (`atmansi`) or 2.048 Mbps (`atmitu`). Signaling links assigned to the `iplim`, `iplimi`, `ss7ipgw`, and `ipgwi` applications are IP signaling links.

Because the performance of a single-slot STC is higher than a dual-slot STC, a dual-slot STC cannot replace a single-slot STC. If a single-slot STC replaces a dual-slot STC, and it is the only single-slot STC in the EAGLE 5 ISS, another single-slot STC must be added to the EAGLE 5 ISS. To add the additional single-slot STC, go to [Adding a Signaling Transport Card \(STC\)](#) .

In order to perform the necessary IP routing within the EAGLE 5 ISS switch, a private virtual network (PVN) is incorporated; the PVN represents the internal IP addressing scheme for every card within the EAGLE 5 ISS switch. Each card has an auto-assigned, default, Class B private IP address (for example, 172.28.60.16).

**NOTE: The EAGLE 5 ISS uses a default value of 172.20.48.0 for the PVN address. You may change the default value by specifying a new network portion of an IP address and a network mask; the host portion is auto-configured. The EAGLE 5 ISS requires use of the lower 10 bits of address space for auto-configuration of internal networking schemes. The entered mask value may be up to 255.255.252.0**

## Network Considerations

There are three networks used to connect the EAGLE 5 ISS to the ESP/IMF subsystem (see [Figure 6-3](#) :

- The EAGLE 5 ISS containing the STCs
- The two Ethernet switches
- The ESP/IMF servers

The monitored information is sent from the EAGLE 5 ISS to the ESP/IMF servers through the Ethernet switches, then forwarded to the Sentine/IMF by the isolation routers. Each router will have one Ethernet port designated as the physical demarcation point between the customer network and the ESP/IMF subsystem.

## IP Address Provisioning

The ESP/IMF subsystem requires IP addresses for these items:

- ESP/IMF external network:
  - Three IP addresses on the customer network for the ESP/IMF isolation routers, one IP address for HSRP, one IP address for each router (two total)
  - One netmask
  - One IP address for the default router.
- ESP/IMF internal network – Contiguous IP block routed within their network (last octet range 1-67 for 17 servers). The Sentinel/IMF considers each ESP/IMF server a separate processing element, therefore each ESP/IMF server needs its own IP address.
- Routes to their network to route to the VIP network already defined within ESP/IMF subsystem.



**CAUTION:** These IP addresses can be changed, as well as the PVN IP address in the EAGLE 5 ISS, contact the Customer Care Center (refer to [Customer Care Center](#) for the contact information) before changing these IP addresses.

## Route Configuration

No explicit routing tables are provisioned in the ESP/IMF subsystem. Use of the single customer provided default router address is assumed for outgoing traffic. All incoming traffic will use the HSRP address provided by the isolation routers.

## Network Limitations

The maximum length of the network cables between the ESP/IMF server frame and the STC cards is limited to 328 feet (100 meters). This limitation is the maximum length that any 10/100BaseT cable can be run.

# Enabling the Time Slot Counter Synchronization (TSCSYNC) and EAGLE 5 Integrated Monitoring Support (E5IS) Features

The EAGLE 5 Integrated Monitoring Support feature requires that the Time Slot Counter Synchronization (TSCSYNC) and EAGLE 5 Integrated Monitoring Support (E5IS) features are enabled with the **chg-feat** command using the **tscsync** and **e5is** parameters. This procedure is used to enable these features.

**NOTE:** Once the Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features are turned on with the **chg-feat** command, they cannot be turned off.

**The Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features must be purchased before turning on these features. If you are not sure whether you**

have purchased the Time Slot Counter Synchronization or EAGLE 5 Integrated Monitoring Support features, contact your Tekelec Sales Representative or Account Representative.

### Procedure

---

1. Verify that the EAGLE 5 Integrated Monitoring Support feature and Time Slot Counter Synchronization features are on, by entering the `rtrv-feat` command.

If the EAGLE 5 Integrated Monitoring Support feature is on, the `E5IS` field should be set to `on`. If the Time Slot Counter Synchronization feature is on, the `TSCSYNC` field should be set to `on`.

**NOTE:** The `rtrv-feat` command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the `rtrv-feat` command, see the `rtrv-feat` command description in the *Commands Manual*.

**NOTE:** If both the EAGLE 5 Integrated Monitoring Support feature and Time Slot Counter Synchronization features are on, then no further action is necessary. If you wish to change the `EISCOPY` or `PVN` IP address options, go to [Configuring the EAGLE 5 Integrated Monitoring Support Options](#) procedure. If you wish to add STCs to the database, go to [Adding a Signaling Transport Card \(STC\)](#) .

**NOTE:** If the Time Slot Counter Synchronization feature is on, go to step 2.

2. Turn the Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features on by entering one of these commands, depending on whether or not the `rtrv-feat` output in step 1 shows that the Time Slot Counter Synchronization feature is on.

If the Time Slot Counter Synchronization feature is not on, enter this command.

```
chg-feat:tscsync=on:e5is=on
```

If the Time Slot Counter Synchronization feature is on, enter this command.

```
chg-feat:e5is=on
```

**NOTE:** Once the Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features are turned on with the `chg-feat` command, they cannot be turned off.

The Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features must be purchased before turning on these features. If you are not sure whether you have purchased the Time Slot Counter Synchronization or EAGLE 5 Integrated Monitoring Support features, contact your Tekelec Sales Representative or Account Representative.

When the `chg-feat` has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
CHG-FEAT: MASP A - COMPLTD
```

3. Back up the new changes using the `chg-db:action=backup:dest=fixed` command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

4. If the `EISCOPY` or `PVN` IP address options are to be changed, go to [Configuring the EAGLE 5 Integrated Monitoring Support Options](#) .

If STCs are to be added to the database, Go to [Adding a Signaling Transport Card \(STC\)](#) to provision the EAGLE 5 ISS with the required number of STCs.

Flowchart 6-1. Enabling the TSCSYNC and E5IS Features

**Note:** Before executing this procedure, make sure you have purchased the Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features. If you are not sure whether you have purchased the Time Slot Counter Synchronization and EAGLE 5 Integrated Monitoring Support features, contact your Tekelec Sales Representative or Account Representative.



## Configuring the EAGLE 5 Integrated Monitoring Support Options

This procedure is used to configure the EISCOPY option and the PVN IP address options for the EAGLE 5 Integrated Monitoring Support feature.

To set the EISCOPY function for the EAGLE 5 Integrated Monitoring Support feature, the **eiscopy** parameter is specified with the **chg-eisopts** command. The **eiscopy=on** parameter enables the EISCOPY function for the EAGLE 5 Integrated Monitoring Support feature. The **eiscopy=off** parameter turns off the EISCOPY function for the EAGLE 5 Integrated Monitoring Support feature. The EISCOPY function allows the EAGLE 5 ISS to copy MSUs to the ESP/IMF subsystem. The default value for the **eiscopy** parameter is **off**.

The IP communications link, used to transmit copied MSUs between the EAGLE 5 ISS and the ESP/IMF subsystem, is dynamically configured by the Sentinel/IMF. The LIMs are assigned Class B private network IP addresses (for example, 172.28.60.16), creating a PVN). The IP message origination address is the address of the LIM. The IP message destination address is that of the VIP (virtual IP address) contained within the ESP/IMF server. private virtual network (

The EAGLE 5 ISS uses a default value of 172.20.48.0 for the PVN address (**pvn** parameter). The default value may be changed by specifying a new network portion of an IP address and a network mask. The host portion of these PVN addresses are configured automatically. The default value for the **pvnmask** parameter is 255.255.252.0.

To change the network portion of the PVN address and the PVN submask used by the PVN addresses within the EAGLE 5 ISS, enter the **chg-netopts** command with the **pvn** and **pvnmask** parameters. The EISCOPY function must be disabled (**eiscopy=off**) in order to make these changes.

The subnet address that results from the **pvn** and **pvnmask** parameter values cannot be the same as the subnet address resulting from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command, or the **dest** and **submask** parameter values of the **ent-ip-rte** command. This interaction applies only if the **ipaddr** or **dest** parameter values are Class B IP addresses. The **ipaddr**, **dest**, and **submask** parameter values can be verified by entering the **rtrv-ip-lnk** and **rtrv-ip-rte** commands. Choose **pvn** and **pvnmask** parameter values whose resulting subnet address is not be the same as the subnet address resulting from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command, or the **dest** and **submask** parameter values of the **ent-ip-rte** command.

To change either the EISCOPY option or the PVN IP address options, the EAGLE 5 Integrated Monitoring Support feature (**E5IS**) must be enabled.



**CAUTION:** Contact the Customer Care Center (refer to [Customer Care Center](#) for the contact information) before performing this procedure.

1. Verify that the EAGLE 5 Integrated Monitoring Support feature is on, by entering the **rtrv-feat** command.

If the EAGLE 5 Integrated Monitoring Support feature is on, the **E5IS** field should be set to **on**.

**NOTE:** The **rtrv-feat** command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the **rtrv-feat** command, see the **rtrv-feat** command description in the *Commands Manual*.

**NOTE:** If the EAGLE 5 Integrated Monitoring Support feature is not on, go to the and enable the EAGLE 5 Integrated Monitoring Support feature.

2. Display the EISCOPY option by entering the **rtrv-eisopts** command.

**NOTE:** If the PVN IP address of the EAGLE 5 ISS and the PVN subnet mask are not being changed, skip steps 2 through 10, and go to step 11.

**NOTE: If the PVN IP address of the EAGLE 5 ISS, PVN subnet mask, or EISCOPY option are not being changed, this procedure cannot be performed.**

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
EIS OPTIONS
-----
EISCOPY = ON
```

- To change the PVN IP address of the EAGLE 5 ISS and the PVN subnet mask, the EISCOPY option must be OFF.

**NOTE: If the EISCOPY option value shown in step 2 is OFF, skip step 3 and go to step 4.**

Turn the EISCOPY option off by entering this command.

**chg-eisopts:eiscopy=off**



**CAUTION: The EAGLE 5 Integrated Monitoring Support feature will be disabled if the EISCOPY option is turned off.**

When the **chg-eisopts** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
CHG-EISOPTS: MASP A - COMPLTD
```

- Display the PVN IP address of the EAGLE 5 ISS and the PVN subnet mask by entering the **rtrv-netopts** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
NET OPTIONS          STATUS
-----
PVN                  172.20.50.0
PVNMASK              255.255.252.0
```

- Display the current link parameters associated with the IP card in the database by entering the **rtrv-ip-lnk** command.

The following is an example of the possible output.

```
rlghncxa03w 06-10-28 21:14:37 GMT EAGLE5 36.0.0
LOC  PORT  IPADDR          SUBMASK          DUPLEX  SPEED  MACTYPE  AUTO  MCAST
1201  A      192.1.1.1       255.255.255.128  HALF    10     802.3    NO    NO
1203  A      192.1.1.12     255.255.255.0   ----    ---    DIX      YES   NO
1205  A      192.1.1.14     255.255.255.0   FULL    100    DIX      NO    NO
```

- Display the IP routes in the database with the **rtrv-ip-rte** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
LOC  DEST          SUBMASK          GTWY
1301  128.252.10.5   255.255.255.255  140.188.13.33
1301  128.252.0.0    255.255.0.0      140.188.13.34
1301  150.10.1.1     255.255.255.255  140.190.15.3
1303  192.168.10.1   255.255.255.255  150.190.15.23
1303  192.168.0.0    255.255.255.0    150.190.15.24

IP Route table is (5 of 1024) 1% full
```

- The subnet address that results from the **pvn** and **pvnmask** parameter values cannot be the same as the subnet address resulting from the **ipaddr** and **submask** parameter values of the **chg-ip-lnk** command, or the **dest** and **submask** parameter values of the **ent-ip-rte** command.

This interaction applies only if the **ipaddr** or **dest** parameter values are Class B IP addresses. The **ipaddr**, **dest**, and **submask** parameter values can be verified by entering the **rtrv-ip-lnk** and **rtrv-ip-rte** commands. If no Class B IP addresses are not shown in **rtrv-ip-lnk** and **rtrv-ip-rte** outputs in steps 5 and 6, go to step 8. If no Class B IP addresses are shown in **rtrv-ip-lnk** and **rtrv-ip-rte** outputs in steps 5 and 6, choose **pvn** and **pvnmask** parameter values for the **chg-netopts** command whose resulting subnet address is not be the same as the subnet address resulting from the **ipaddr** and **submask** values shown in the **rtrv-ip-lnk** command in step 5, or the **dest** and **submask** values of the **rtrv-ip-rte** command in step 6. Go to step 8.

- Change the PVN IP address of the EAGLE 5 ISS and the PVN subnet mask by entering the **chg-netopts** command with the **pvn** and **pvnmask** parameters.

For this example, enter this command. **chg-netopts:pvn=158.30.75.133:pvnmask=255.255.252.0** When the **chg-netopts** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
CHG-NETOPTS: MASP A - COMPLTD
```

- Verify the changes using the **rtrv-netopts** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
NET OPTIONS          STATUS
-----
PVN                  158.30.75.133
PVNMASK              255.255.252.0
```

- Back up the new changes using the **chg-db:action=backup:dest=fixed** command.

These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

- Display the EISCOPY option by entering the **rtrv-eisopts** command.

**NOTE: If the EISCOPY option value is not being changed, skip steps 11 through 16, and go to step 17.**

**NOTE: If the EISCOPY option value was changed in step 3, skips step 11 through 13, and go to step 14.**

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
EIS OPTIONS
-----
EISCOPY = OFF
```

- Display the STC cards in the database using the **rept-stat-eroute** command.

**NOTE: If the EISCOPY option value shown in step 11 is ON, skip steps 12 and 13, and go to step 14.**

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
EROUTE SUBSYSTEM REPORT IS-NR      Busy      -----
STC Cards Configured= 8  Cards IS-NR= 8
EISCOPY BIT = ON
System Threshold = 80% Total Capacity
System Peak EROUTE Load:      8000 Buffers/Sec
System Total EROUTE Capacity:  9600 Buffers/Sec
SYSTEM ALARM STATUS = No Alarms
```

CARD	VERSION	PST	SST	AST	TVG USAGE	CPU USAGE
1205	126-002-000	IS-NR	Active	-----	22%	33%
1211	126-002-000	IS-NR	Active	-----	22%	33%
1303	126-002-000	IS-NR	Active	-----	22%	33%
1311	126-002-000	IS-NR	Active	-----	22%	33%
1313	126-002-000	IS-NR	Active	-----	22%	33%
2211	126-002-000	IS-NR	Active	-----	22%	33%
2213	126-002-000	IS-NR	Active	-----	22%	33%
1105	126-002-000	IS-NR	Active	-----	22%	33%

```
EROUTE Service Average TVG Capacity = 22% Average CPU Capacity = 33%
Command Completed.
```

At least two STCs must be shown in the **rept-stat-eroute** output. The primary state (**PST** value) of at least two STCs must be **IS-NR**. If two or more STCs are shown in the **rept-stat-eroute** output and the primary state of at least two of these STCs is **IS-NR**, skip step 13 and go to step 14. If only one STC, or no STCs are shown in the **rept-stat-eroute** output, add the necessary STCs by perform the [Adding a Signaling Transport Card \(STC\)](#) procedure. After the STCs have been added, skip step 13 and go to step 14. If two or more STCs are shown in the **rept-stat-eroute** output and the primary state of only one STC, or no STCs is **IS-NR**, go to step 13.

- Put at least one or two STCs, as required in step 12, shown in step 12 whose primary state is not IS-NR into service using the **rst-card** command specifying the card location shown in step 12.

For this example, enter this command.**rst-card:loc=1205 rst-card:loc=1211**When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
Card has been allowed.
```

- Change the EISCOPY option by entering one of these commands.

To turn the EISCOPY option on, enter this command.**chg-eisopts:eiscopy=on**To turn the EISCOPY option off, enter this command.**chg-eisopts:eiscopy=off**.



**CAUTION: The EAGLE 5 Integrated Monitoring Support feature will be disabled if the EISCOPY option is turned off.**

When the **chg-eisopts** has successfully completed, this message should appear.

```
rlghncxa03w 06-10-20 21:18:37 GMT EAGLE5 36.0.0
CHG-EISOPTS: MASP A - COMPLTD
```

- Verify the changes to the EISCOPY option by entering the **rtrv-eisopts** command.

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
EIS OPTIONS
```

```
-----  
EISCOPY = ON
```

16. Back up the new changes using the **chg-db:action=backup:dest=fixed** command.


These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.


```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.  
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.  
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.  
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```


17. If more STCs are not being added to the database, this procedure is finished.

If more STCs are to be added to the database, go to [Adding a Signaling Transport Card \(STC\)](#) to provision the EAGLE 5 ISS with the increased number of STCs.

Flowchart 6-2. Configuring the EAGLE 5 Integrated Monitoring Support Options







## Adding a Signaling Transport Card (STC)

This procedure is used to add an STC (Signaling Transport Card) to the database using the **ent-card** command. The STC provides an interface between the EAGLE 5 ISS and the ESP (EAGLE 5 Integrated Monitoring Support) feature. The STC allows the ESP subsystem to monitor the EAGLE 5 ISS's signaling links without additional intrusive cabling.

The **ent-card** command uses these parameters.

**:loc** – The location of the card being added to the database.

**:type** – The type of card being added to the database. For this procedure, the value of this parameter is **stc**.

**:appl** – The application software or GPL that is assigned to the card. For this procedure, the value of this parameter is **eroute**.

**:force** – Allow the LIM to be added to the database even if there are not enough SCCP cards to support the number of LIMs in the EAGLE 5 ISS. This parameter is obsolete and is no longer used.

The STC can be either a single-slot STC, a dual-slot STC, or an E5-STC card as shown in [Table 6-2](#).

**Table 6-2. STC Part Numbers**

Card Type	Card Name (as shown on the card Label)	Part Number
Dual-Slot STC	DCM	870-1945-XX
		870-1984-01
Single-Slot STC	DCM	870-2372-01
	EDCM-A	870-2508-XX
E5-STC	E5-ENET	870-2212-02

The dual-slot STC can be inserted only in the odd numbered card slots of the extension shelf. Slot 9 of each shelf contains the HMUX card or HIPR card, thus the dual-slot STC cannot be inserted in slot 09. The dual-slot STC can be inserted in the control shelf, but only in slots 1101, 1103, 1105, 1107, and 1111. Slots 1113, 1115 and 1117 are reserved for MASPs A and B and the MDAL card. The dual-slot STC occupies two card slots, so the even numbered card slot must be empty and not provisioned in the database, as shown in [Table 6-3](#). The dual-slot STC is connected to the network through the odd numbered card slot connector.

**Table 6-3. Dual-Slot STC Locations**

Location of the STC	Empty Card Location	Location of the STC	Empty Card Location
Slot 01	Slot 02	Slot 11	Slot 12
Slot 03	Slot 04	Slot 13	Slot 14
Slot 05	Slot 06	Slot 15	Slot 16
Slot 07	Slot 08	Slot 17	Slot 18

The single-slot STC can be inserted into any card slot, except an even numbered card slot adjacent to a dual-slot card, shown in [Table 6-3](#), slots 9 and 10 in each shelf, and slots 1113 through 1118.

The shelf to which the card is to be added, must already be in the database. This can be verified with the **rtrv-shlf** command. If the shelf is not in the database, see the “Adding a Shelf” procedure in the *Database Administration Manual - System Management*.

In order to enable the EISCOPY option, with the **chg-eisopts** command, and to comply with the  $n+1$  STC configuration requirement, a minimum of two STCs must be provisioned in the database. A minimum of two STCs must be provisioned.

The number of SS7 signaling links that can be monitored by an STC varies depending the following criteria:

- Whether the STC is a dual-slot STC or single-slot STC
- The type of signaling link (defined by the application running on the card the signaling link is assigned to)
- The amount of traffic and the size of the MSUs being handled by the EAGLE 5 ISS

**NOTE: Verify the temperature threshold settings for the E5-STC card by performing the “Changing the High-Capacity Card Temperature Alarm Thresholds” procedure in the *Database Administration Manual-SS7*.**

### STC Provisioning

The following rules apply to provisioning STCs:

- A minimum of two STCs must be provisioned in an EAGLE 5 ISS.
- The maximum number of STCs that can be provisioned in an EAGLE 5 ISS is 32.
- For shelves containing HMUX cards, the following rules apply to provisioning STCs.
  - If the shelf containing the STCs (only single/double slot STCs but not E5-STC) has HMUX cards installed in card slots 9 and 10, the shelf can contain a maximum of three STCs.
  - The STCs should be provisioned in shelves adjacent to the shelf containing the cards being monitored - half of the STCs should be provisioned in the next shelf and the other half of the STCs should be provisioned in the previous shelf. For example, if the shelf containing the cards being monitored is shelf 2100, half of the STCs monitoring shelf 2100 should be provisioned in shelf 1300 and the other half of the STCs monitoring shelf 2100 should be provisioned in shelf 2200.
- STCs should be provisioned in the same shelf containing the cards being monitored if that shelf has HIPR cards installed in card slots 9 and 10.
- If the shelf being monitored has HIPR cards installed in card slots 9 and 10, more than three STCs can be provisioned in the shelf, depending on the number of empty card slots that shelf has.
- If the IP signaling links assigned to single-slot EDCMs or E5-ENET cards are being monitored, HIPR cards must be installed in card slots 9 and 10 of the shelf containing the single-slot EDCMs or E5-ENET cards.
- If E1 or T1 signaling links assigned to HC MIMs or E5-E1T1 cards are being monitored, HIPR cards must be installed in card locations 9 and 10 of the shelf that the HC MIM or E5-E1T1 will occupy.
- If IP signaling links are being monitored, the EAGLE 5 ISS can have only single-slot STCs provisioned and installed. Dual-slot STCs cannot be installed or provisioned.
- The E5-STC requires that HIPR cards are installed in the card locations 9 and 10 in the shelf that will contain the E5-STC. There is no limit on the number of E5-STCs that can be provisioned on shelves containing HIPR cards.

**NOTE: Contact your Tekelec Sales Representative or Account Representative to determine the number of STCs that must be provisioned in your EAGLE 5 ISS, and to determine where in the EAGLE 5 ISS these STCs must be provisioned before performing this procedure.**

The examples in this procedure are used to add an STC in these card locations: 1303, 2101, and 2102.

### Procedure

1. Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```
r1ghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
```

1102	TSM	GLS							
1113	GPSM	EOAM							
1114	TDM-A								
1115	GPSM	EOAM							
1116	TDM-B								
1117	MDAL								
1201	LIMDS0	SS7ANSI	sp2	A	0	sp1	B	0	
1203	LIMDS0	SS7ANSI	sp3	A	0				
1204	LIMDS0	SS7ANSI	sp3	A	1				
1206	LIMDS0	SS7ANSI	nsp3	A	1	nsp4	B	1	
1207	LIMV35	SS7GX25	nsp1	A	0				
1208	LIMV35	SS7GX25	nsp1	A	1				
1216	ACMENET	STPLAN							
1301	TSM	SCCP							
1308	LIMDS0	SS7ANSI	sp6	A	1	sp7	B	0	
1314	LIMDS0	SS7ANSI	sp7	A	1	sp5	B	1	
1317	ACMENET	STPLAN							

The cards should be distributed throughout the EAGLE 5 ISS for proper power distribution. Refer to the *Installation Manual - EAGLE 5 ISS* for the shelf power distribution.

- Verify that the EAGLE 5 Integrated Monitoring Support feature is on, by entering the `rtrv-feat` command. If the EAGLE 5 Integrated Monitoring Support feature is on, the **ESIS** field should be set to **on**.

**NOTE:** The `rtrv-feat` command output contains other fields that are not used by this procedure. If you wish to see all the fields displayed by the `rtrv-feat` command, see the `rtrv-feat` command description in the *Commands Manual*.

**NOTE:** If the EAGLE 5 Integrated Monitoring Support feature is not on, go to the [Enabling the Time Slot Counter Synchronization \(TSCSYNC\) and EAGLE 5 Integrated Monitoring Support \(ESIS\) Features](#) procedure and enable the EAGLE 5 Integrated Monitoring Support feature.

**NOTE:** If HIPR cards are not required for provisioning STC cards, refer to the “STC Provisioning” section, skip step 3 and go to step 4.

- Verify that the HIPR cards are installed in card locations 9 and 10 in the shelf before adding the STCs cards in this procedure. Enter this command.

```
rept-stat-gpl:gpl=hipr
```

This is an example of the possible output.

```
r1ghncxa03w 07-02-01 11:40:26 GMT EAGLE5 37.0.0
GPL          CARD          RUNNING          APPROVED          TRIAL
HIPR         1109         126-002-000     126-002-000     126-003-000
HIPR         1110         126-002-000     126-002-000     126-003-000
HIPR         1209         126-002-000     126-002-000     126-003-000
HIPR         1210         126-002-000     126-002-000     126-003-000
HIPR         1309         126-002-000     126-002-000     126-003-000
HIPR         1310         126-002-000     126-002-000     126-003-000
HIPR         2109         126-002-000     126-002-000     126-003-000
HIPR         2110         126-002-000     126-002-000     126-003-000
Command Completed
```

If HIPR cards are installed in the shelf containing STC cards go to step 4.

If HIPR cards are not installed on the shelf containing the STC cards go to the *Installation Manual - EAGLE 5 ISS* and install the HIPR cards. Once the HIPR cards have been installed, go to step 4.

- Add the STC using the `ent-card` command. Refer to the “STC Provisioning” section for the rules for provisioning STC cards. A dual-slot STC can be inserted only in an odd numbered slot and the adjacent even card slot must be empty, as shown in [Table 6-3](#). A single-slot STC can be inserted into any card slot except an even numbered card slot adjacent to a dual-slot card, slots 09 and 10 in each shelf, and slots 1113 through 1118. For this example, enter these commands.

```
ent-card:loc=1303:type=stc:appl=eroute
```

```
ent-card:loc=2101:type=stc:appl=eroute
```

```
ent-card:loc=2102:type=stc:appl=eroute
```

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-10-12 09:12:36 GMT EAGLE5 36.0.0
ENT-CARD: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-card** command with the card location specified in step 4. For this example, enter these commands.

```
rtrv-card:loc=1303
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1303   STC         EROUTE
```

```
rtrv-card:loc=2101
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
2101   STC         EROUTE
```

```
rtrv-card:loc=2102
```

This is an example of the possible output.

```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
2102   STC         EROUTE
```

6. Verify that the card to be entered has been physically installed into the card location specified in step 4.



**CAUTION:** If the version of the flash GPLs on the STC does not match the flash GPL versions in the database when the STC is inserted into the card slot, UAM 0002 is generated indicating that these GPL versions do not match. If UAM 0002 has been generated, perform the alarm clearing procedure for UAM 0002 in the *Maintenance Manual* before proceeding with this procedure.

7. Put the STC added in step 4 into service using the **alw-card** command specifying the card location specified in step 4. For this example, enter these commands.

```
alw-card:loc=1303
```

```
alw-card:loc=2101
```

```
alw-card:loc=2102
```


When the **alw-card** command has successfully completed, this message should appear.


```
rlghncxa03w 06-10-28 09:12:36 GMT EAGLE5 36.0.0
Card has been allowed.
```

8. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-3. Adding a Signaling Transport Card (STC)





## Removing a Signaling Transport Card (STC)

This procedure is used to remove an STC from the database using the **dlt-card** command.



**CAUTION:** If the STC is the last STC in service, removing this card from the database will disable the EAGLE 5 Integrated Monitoring Support feature.



**CAUTION:** If removing the STC reduces the quantity of STCs in the EAGLE 5 ISS below number of STCs required by the ESP subsystem, the performance of the EAGLE 5 Integrated Monitoring Support feature will be degraded.

The examples in this procedure are used to remove the STC in card location 1303.

### Canceling the REPT-STAT-CARD Command

Because the **rept-stat-card** command used in this procedure can output information for a long period of time, the **rept-stat-card** command can be canceled and the output to the terminal stopped. There are three ways that the **rept-stat-card** command can be canceled.

- Press the F9 function key on the keyboard at the terminal where the **rept-stat-card** command was entered.
- Enter the **canc-cmd** without the **trm** parameter at the terminal where the **rept-stat-card** command was entered.
- Enter the **canc-cmd:trm=<xx>**, where **<xx>** is the terminal where the **rept-stat-card** command was entered, from another terminal other than the terminal where the **rept-stat-card** command was entered. To enter the **canc-cmd:trm=<xx>** command, the terminal must allow Security Administration commands to be entered from it and the user must be allowed to enter Security Administration commands. The terminal's permissions can be verified with the **rtrv-secu-trm** command. The user's permissions can be verified with the **rtrv-user** or **rtrv-secu-user** commands.

For more information about the **canc-cmd** command, go to the *Commands Manual*.

1. Display the cards in the database using the **rtrv-card** command. This is an example of the possible output.

```

r1ghncxa03w 06-08-28 09:12:36 GMT EAGLE5 37.0.0
CARD   TYPE      APPL      LSET NAME      LINK SLC LSET NAME      LINK SLC
1101   TSM          SCCP
1103   DCM          STPLAN
1113   GPSM        EOAM
1114   TDM-A
1115   GPSM        EOAM
1116   TDM-B
1117   MDAL
1201   LIMDS0      SS7ANSI    sp2             A    0    sp1           B    0
1202   LIMDS0      SS7ANSI    sp2             A    1    nsp3          B    0
1202   LIMV35      SS7GX25    lsnngwy        A    0
1203   LIMDS0      SS7ANSI    sp3             A    0
1204   LIMDS0      SS7ANSI    sp3             A    1
1205   LIMOCU      CCS7ITU    itu1            A    0
1206   LIMDS0      SS7ANSI    nsp3            A    1    nsp4          B    0
1207   LIMV35      SS7GX25    nsp1            A    0
1208   LIMV35      SS7GX25    nsp1            A    1
1212   TSM          SCCP
1214   TSM          GLS
1215   DCM          STPLAN
1301   LIMATM      ATMANSI    lsnatm1        A    0
1303   STC         EROUTE
1305   DCM          STPLAN
1308   LIMDS0      SS7ANSI    sp6             A    0    sp7           B    0
1311   LIMDS0      SS7ANSI    sp2             A    2    sp1           B    1
          sp7             A1   1    sp3           B1   2
1315   LIMDS0      SS7ANSI    sp7             A    2    sp5           B    0
1318   LIMATM      ATMANSI    lsnatm1        A    1
2101   STC         EROUTE
2102   STC         EROUTE
2105   STC         EROUTE

```

An STC is identified by the entries **STC** in the **TYPE** field and **EROUTE** in the **APPL** field.

2. Display the status of the STC being removed with the **rept-stat-card** command with the location of the STC. For this example, enter this command.

**rept-stat-card:loc=1303**

This is an example of the possible output.

```
rlghncxa03w 06-08-27 16:43:42 GMT EAGLE5 37.0.0
CARD  VERSION      TYPE      GPL      PST      SST      AST
1303  113-003-000    STC      EROUTE   IS-NR    Active   -----
ALARM STATUS      = No Alarms.
BP GPL version = 002-108-000
IMT BUS A         = Conn
IMT BUS B         = Conn
EROUTE % OCCUP    = 50%
NTP broadcast = VALID

STC IP PORT A:           IS-NR      Active   -----
ALARM STATUS = No Alarms.
STC IP PORT B:           IS-NR      Active   -----
ALARM STATUS = No Alarms.
Command Completed.
```

3. Inhibit the card using the **rmv-card** command, specifying the card location. For this example, enter this command.

**rmv-card:loc=1303**

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-08-12 09:12:36 GMT EAGLE5 37.0.0
Card has been inhibited.
```

4. Remove the card using the **dlt-card** command. The **dlt-card** command has only one parameter, **loc**, which is the location of the card. For this example, enter this command.

**dlt-card:loc=1303**

When this command has successfully completed, this message should appear.

```
rlghncxa03w 06-08-12 09:12:36 GMT EAGLE5 37.0.0
DLT-CARD: MASP A - COMPLTD
```

5. Verify the changes using the **rtrv-card** command specifying the card that was removed in step 4. For this example, enter this command.

**rtrv-card:loc=1303**


When this command has successfully completed, this message should appear.

```
E2144 Cmd Rej: Location invalid for hardware configuration
```

6. Back up the new changes using the **chg-db:action=backup:dest=fixed** command. These messages should appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Flowchart 6-4. Removing a Signaling Transport Card (STC)





# Glossary

## A

ACM	Address Complete Message <i>Application Communications Module</i>
ACT	Activate
AFTPC	Affected Point Code
AINF	Application Interface Appliqué
Allowed Affected Destination Field	The gateway screening entity that identifies the point code in the affected destination field (the concerned signaling point code) of incoming MTP network management messages from another network that are allowed into the EAGLE 5 ISS. Messages containing the specified point code are allowed into the network.
Allowed DPC	The gateway screening entity that identifies the destination point codes that are allowed to receive SS7 messages from the EAGLE 5 ISS. Messages containing the specified destination point codes go on to the next step in the gateway screening process, or are allowed into the network if the gateway screening process stops with this entity.
Allowed ISUP	The gateway screening entity that identifies the ISUP or TUP message types that are allowed into the network.
Allowed OPC	The gateway screening entity that identifies the originating point codes that are allowed to send SS7 messages into the network. Messages containing the specified originating point codes go on to the next step in the gateway screening process, or are allowed into the network if the gateway screening process stops with this entity.
Allowed SIO	The gateway screening entity that identifies the type of MSUs (ISUP, TUP, TCAP, and so forth) that are allowed into the network. The message type is determined by the network indicator code (NIC), priority (PRI), and service indicator (SI) fields of the signaling information octet (SIO) field in the MSU, and the H0 and H1 heading codes of the signaling information field of the MSU. Messages containing the specified message type go on to the next step in the gateway screening process, or are allowed into the network if the gateway screening process stops with this entity.
AND	AIN Number of Digits (in GTT address for AIN query)
ANSI	American National Standards Institute
APC	Adjacent Point Code Application Processing Chassis
API	Application Interface Application Programming Interface
ARP	Address Resolution Protocol
ATI	Any Time Interrogation
ATM	Asynchronous Transfer Mode
ATMANSI	The application used for high-speed ANSI ATM signaling links.
ATMITU	The application used for high-speed E1 ATM signaling links.

## B

BITS	Building Integrated Timing System
BLKDPC	Blocked Destination Point Code
BLKOPC	Blocked Originating Point Code
BPS	Bits per Second

## C

CCS7ITU	The generic program load and application for the ITU SS7 signaling links that is used with card types <b>limds0</b> , <b>limch</b> , <b>limocu</b> , <b>limv35</b> , <b>lime1</b> , and <b>limt1</b> .
CdPA	Called Party Address
CDR	Call Detail Record
CgPA	Calling Party Address
CLLI	Common Language Location Identifier
Cluster	A group of signaling points whose point codes have identical values for the network and cluster fields of the point codes. A cluster entry in the routing table is shown as an asterisk (*) in the member field of the point code, for example, 111-011-*. Cluster entries can be provisioned only as ANSI destination point codes.
CPC	Capability Point Code
CSR	Customer Service Request

## D

Database	All data that can be administered by the user, including cards, destination point codes, gateway screening tables, global title translation tables, links, LNP services, LNP service providers, location routing numbers, routes, shelves, subsystem applications, and 10 digit telephone numbers.
DCE	Data Communication Equipment The data communication equipment associated with the transmission of data from one device to another. Examples of data communication equipment are modems, remote terminals, and communications processors.
DCM	Database Communication Module The DCM provides IP connectivity for applications. Connection to a host is achieved through an ethernet LAN using the TCP/IP protocol.
DESTFLD	The point code in the affected destination field (the concerned signaling point code) of incoming MTP network management messages from another network that are allowed into the EAGLE 5 ISS.
Destination	The node to which the signaling link traffic is routed. This destination is identified by a point code, either a full point code or a cluster point code.
DHCP	Dynamic Host Configuration Protocol
DPC	Destination Point Code The point code of the signaling point to which the MSU is routed. This point code can be adjacent to the EAGLE 5 ISS, but does not have to be.
DPCA	Destination Point Code ANSI
DPCI	Destination Point Code International
DPCN	Destination Point Code National
DS0	Digital Signal Level-0 (64 Kbits/sec or 56 Kbits/sec)

## Database Administration Manual - Features

	A basic digital signaling rate of 64 Kbits/sec, corresponding to the capacity of one voice-frequency-equivalent channel.
DS0A	Digital Signal Level - 0
DSM	Database Service Module.
DTA	Database Transport Access
	A feature in the EAGLE 5 ISS that encapsulates specific MSUs into the data portion of SCCP within a new SS7 MSU and sends the new MSU to the destination using global title translation. The EAGLE 5 ISS uses gateway screening to determine which MSUs are used by the DTA feature.
DTE	Data Terminal Equipment
	The equipment associated with the entering and retrieving data from a computer system or a data communications system. A video display terminal is an example of data terminal equipment.

### E

E1	The European equivalent of T1 that transmits digital data over a telephone network at 2.048 Mbps.
E5-E1T1	EPM-based E1/T1 Multi-Channel Interface Module
	An EPM-based card that provides E1 and T1 connectivity. The E5 indicates the card is for existing EAGLE 5 control and extension shelves. E1T1 is an abbreviation for the ITU E1 and ANSI T1 interfaces. Thus the nomenclature defines the shelves where the card can be used and the physical interface that it provides.
E5-ENET	EPM-based Ethernet card
	A high capacity single-slot IP signaling card (EPM card plus Gig Ethernet PMC cards).
E5IS	EAGLE 5 Integrated Monitoring Support
	The EAGLE 5 Integrated Monitoring Support feature allows the network traffic on the EAGLE 5 ISS's signaling links to be monitored by an ESP (extended services platform) or IMP (integrated message feeder) without additional intrusive cabling. Message Signaling Units (MSUs), alarms, and events are copied to the Sentinel/IMF to provide the network traffic monitoring. The monitored traffic is delivered to the Sentinel/IMF using the EAGLE'S STCs (Signaling Transport Cards) which are connected to the ESP/IMF subsystem by Ethernet links. The ESP/IMF subsystem delivers the monitored traffic to the Sentinel/IMF.
EDCM	Enhanced DCM
	Enhanced Database Communication Module
EILA	Enhanced Integrated LIM Appliqué
ENET	Ethernet
	Can refer to a generic hardware type that supports one or more Ethernet interfaces.
Enhanced Global Title Translation	A feature that is designed for the signaling connection control part (SCCP) of the SS7 protocol. The EAGLE 5 ISS uses this feature to determine to which service database to send the query message when a Message Signaling Unit (MSU) enters the system.
ESP	Expanded Services Platform

### F

FTP	Feature Test Plan
	File Transfer Protocol.

**G**

GLS	Generic Loading Services An application that is used by the TSM cards for downloading gateway screening to LIM cards.
GPL	Generic Program Load
GPSM-II	General Purpose Service Module
GRT	Gateway Routing Table
GSM	Global System for Mobile Communications
GSMSCRN	GSM MAP Screening. A feature that allows the user to provision which MAP subsystem numbers are affected, which MAP operations codes to screen, which origination points are allowed, and which error messages to use.
GT	Global Title Routing Indicator
GTA	Global Title Address
GTI	Global Title Indicator
GTT	Global Title Translation.
GWS	Gateway Screening.
GWSA	Gateway Screening Action Gateway Screening Application
GWSD	Gateway Screening Message Discard

**H**

HC-MIM	High Capacity Multi-Channel Interface Module
HIPR	High-Speed IMT Packet Router
HLR	Home Location Register
HMUX	High-Speed Multiplexer
HSL	High-Speed Links

**I**

ICMP	Internet Control Message Protocol
ID	Identity, identifier
ILA	Integrated LIM Appliqué
IMF	Integrated Message Feeder A data acquisition system similar to Sentinel.
IMT	Inter-Module-Transport The communication software that operates the inter-module-transport bus on all cards except the LIMATM, DCM, DSM, and HMUX.
IP	Intelligent Peripheral Internet Protocol
IP <sup>7</sup>	Tekelec's Internet Protocol to SS7 Interface
IP Address	The location of a device on a TCP/IP network. The IP Address is a number in dotted decimal notation which looks something like [192.168.1.1].

## Database Administration Manual - Features

IPGWI	An application that is used by the SSEDCEM/E5-ENET card for IP point-to-multi-point connectivity within an ITU-I or ITU-N network. The system allows a maximum of 64 cards to be assigned the IPGWI application.
IPGWx	Point-to-multipoint MTP-User signaling (e.g. ISUP, TCAP) over IP capability. Typically used for A link connectivity which require routing keys. Far End not required to support MTP3. The IPGWx GPL (IPGWI, SS7IPGW) run on the SSEDCEM/E5-ENET hardware.
IPLIM	The application used by the SSEDCEM/E5-ENET card for IP point-to-point connectivity for ANSI point codes.
IPLIMI	The application used by the SSEDCEM/E5-ENET card for IP point-to-point connectivity for ITU point codes.
IPLIMx	Point-to-point MTP3 and MTP3-User signaling over IP capability. Typically used for B-C-D links but can be used for A links but does not have routing key functionality. Far End required to support MTP3. The IPLIMx GPL (IPLIMI, IPLIM) run on the SSEDCEM/E5-ENET hardware.
IS	Information Services
IS-NR	In Service - Normal
ISS	Integrated Signaling System
ISUP	ISDN User Part
ITU	International Telecommunications Union

## L

LAN	Local Area Network See also STP LAN.
LC	Logical Channel
LC2NM	Logical Channel to Network Management
LIM	Link Interface Module
LIM-AINF	A link interface module (LIM) with the AINF interface.
LIM-DS0	A link interface module (LIM) with the DS0A Appliqué.
LIM-OCU	A link interface module (LIM) with the OCU Appliqué.
LIM-OCU	LIM-Office Channel Unit Applique
Link	Signaling Link
Load Sharing	A type of routing used by global title translation to route MSUs This type of routing is used when a second point code and subsystem is defined for the primary point code and subsystem. Traffic is shared equally between the replicated point codes and subsystems.
LSL	Low-speed Link
LSN	Link Set Name
LST	Link Set Type

## M

M2PA	SS7 MTP2-User Peer-to-Peer Adaptation Layer
M3UA	SS7 MTP3-User Adaptation Layer
MAP	Mated Application Part Mobile Application Part
MASP	Maintenance and Administration Subsystem Processor

Mated Application	The point codes and subsystem numbers of the service databases that messages are routed to for global title translation.
MAU	Media Access Unit
MDAL	Maintenance Disk and Alarm Card
MIM	Multi-Channel Interface Module
MPL	Multi-port LIM
MRN	Message Reference Number Mated Relay Node
MSC	Mobile Switching Center
MSU	Message Signaling Unit
MTP	Message Transfer Part Module Test Plan
MTP2	Message Transfer Part, Level 2

**N**

NAI	Nature of Address Indicator
NAIV	NAI Value
NIC	Network Identifier Code Network Information Center
NP	Number Plan Numbering Plan Number Portability
NPV	Numbering Plan Value
NSR	Next Screening Reference
NTP	Network Time Protocol

**O**

OCU	Office Channel Unit
OOS-MT	Out of Service - Maintenance
OOS-MT-DSBLD	Out of Service - Maintenance Disabled
OPC	Originating Point Code

**P**

PC	Point Code.
PCA	Point Code ANSI
PCI	Peripheral Component Interface Point Code International Protocol Control Information
PCN	Point Code National Product Change Notice
PCR	Preventive Cyclic Retransmission
PDN	Packet Data Network

## Database Administration Manual - Features

	Public Data Network
PVC	Permanent Virtual Circuit Permanent Virtual Connection
PVN	Private Virtual Network

### R

RFC	Request for Comment
Route	A path to another signaling point.

### S

SCCP	Signaling Connection Control Part
SCP	Service Control Point.
Screen Set	A gateway screening table containing a list of rules, or screening references. The screening references indicate the screening action that is to be performed on a message in a specific linkset.
SCRN	Screen Set Name
SE-HSL	Synchronous E1 High Speed Link
SEAS	Signaling Engineering and Administration System An interface defined by Bellcore and used by the Regional Bell Operating Companies (RBOCs), as well as other Bellcore Client Companies (BCCs), to remotely administer and monitor the signaling points in their network from a central location.
SI	Service Indicator
Signaling Link	The transmission path connecting the EAGLE 5 ISS to other signaling points in the network and providing access to ANSI SS7, ITU SS7, and X.25 network elements. The signaling link is connected to the EAGLE 5 ISS at the link interface module (LIM). A generic program load application that is loaded on the LIM to allow the LIM to access a particular network element.
SIO	Service Information Octet
SIO	Service Information Octet.
SLAN	STP LAN Signaling Transfer Point Local Area Network.
SLC	Signaling Link Code
SLTA	Signaling Link Test Acknowledgment
SLTM	Signal Link Test Message
SMS	Short Message Service
SRI	Send Routing Information Send_Route_Information Message
SS7	Signaling System #7
SS7ANSI	SS7 ANSI An application used by the LIM cards and the E1/T1 MIM card for the MTP functionality.
SS7IPGW	SS7 IP Gateway An application used by the DCM/SSEDCM card for IP point-to-multipoint capability within an ANSI network.
SSEDCM	Single Slot Enhanced Data Communications Module

SSN	SS7 Subsystem Number Subsystem Number
STC	Sentinel Transport Card Signaling Transport Card
STP	Signal Transfer Point
STPLAN	Signaling Transfer Point Local Area Network The generic program load and application used by the ACM card to support the STP LAN application. This GPL does not support 24-bit ITU-N point codes.
SVC	Switched Virtual Circuit A temporary virtual circuit that is set up and used only as long as data is being transmitted. Once the communication between the two hosts is complete, the SVC disappears. In contrast, a permanent virtual circuit (PVC) remains available at all times.
SVCA	Automatic Switched Virtual Circuit
SVCR	Remote Switched Virtual Circuit

**T**

T1	Transmission Level 1 A T1 interface terminates or distributes T1 facility signals for the purpose of processing the SS7 signaling links carried by the E1 carrier. A leased-line connection capable of carrying data at 1,544,000 bits-per-second.
TC	Table Copy Transaction Capabilities
TCAP	Transaction Capabilities Application Part
TCP	Transfer-Cluster-Prohibited Transfer Control Protocol Transmission Control Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol
TDM	Terminal Disk Module. Time Division Multiplexing.
TFA	TransFer Allowed (Msg)
TFP	TransFer Prohibited (Msg)
TPS	Transactions Per Second A method of measuring how quickly a network can transmit and receive data. Capacities listed with “TPS” units involve the maximum of the receive rate and the transmit rate, and the worst-case assumption is that the transmit and receive rates are the same. Under the TU model, transaction units per second are calculated with the total transaction unit value and the advertised card capacity.
TSC	Time Slot Counter
TSCSYNC	Time Slot Counter Synchronization The Time Slot Counter (TSC) Synchronization feature allows the system’s A (Active) and B (Standby) internal clocks to be synchronized by the standby OAM GPSM-II card.
TSM	Translation Services Module
TT	Translation Type.
TX	Transmit

## Database Administration Manual - Features

### U

UAM	Unsolicited Alarm Message.
UDP	User Datagram Protocol
UDT	Unit Data Transfer
UDTS	Unit Data Transfer Service
UIM	Unsolicited Information Message

### V

V.35	ITU Interface Recommendation, V.35 The interface used with the LIMV35 card.
VSCCP	VxWorks Signaling Connection Control Part The application used by the DSM card to support the G-Flex, G-Port, INP, AINPQ, EIR, A-Port, IGM, V-Flex, and LNP features. If the G-Flex, G-Port, INP, AINPQ, EIR, A-Port, IGM, V-Flex, or LNP feature is not turned on, and a DSM card is present, the VSCCP GPL processes normal GTT traffic.
VXWSLAN	An application used by the DCM card to support the STP LAN application. This GPL does not support 24-bit ITU-N point codes.



# Index

1500 Signaling Links 2-131

2000 Signaling Links 2-131

## A

admonishments, documentation 1-4

appl 2-9

ATMANSI 6-6

ATMITU 6-7

## C

CCS7ITU 6-6

Connection

definition 2-4

## D

Destination element

definition 2-4

DHCP 6-5

documentation

admonishments 1-4

dpc 2-21

dual-slot STC 6-6 , 6-7 , 6-19 , 6-21

Dynamic Host Configuration Protocol 6-5

## E

E1/T1 MIM 6-6

E1-ATM 6-7

EAGLE 5 Integrated Monitoring Support 1-3  
, 6-4 , 6-9 , 6-11 , 6-19 , 6-24 ,  
6-25

EILA 6-6

ESP 1-3 , 6-1 , 6-3 , 6-6 , 6-19

Ethernet 6-6

extended services platform 6-1 , 6-19

## F

feature

X.25 Gateway 1-2

Fixed connection 2-5

Flexible GTT Load Sharing 5-62 , 5-82 ,  
5-103 , 5-136

## G

Gateway routing 2-3

Global Title Translation 5-22

## H

HMUX 6-6 , 6-19

HMUXTVG option 6-6

## I

ILA 6-6

IMF 1-3

Integrated Monitoring

Eagle 5 Support 1-3

## L

LIMATM 6-6

LIM-ATM 6-6

LIMCH 6-6

limds0 2-8 , 6-6

LIM-DS0 6-6

LIME1 6-6

LIME1ATM 6-7

limocu 2-8 , 6-6

LIM-OCU 6-6

LIMT1 6-6

LIM-V.35 6-6

limv35 2-8 , 6-6

## M

Measurements Platform 5-35

Measurements Platform option 5-35

MIM

E1T1 6-6

MPL 6-6

MTP envelopes 2-3

## P

private virtual network 6-7 , 6-11  
PVC 2-3  
PVN 6-7 , 6-11 , 6-12 , 6-13  
PVN subnet mask 6-11 , 6-12 , 6-13

## S

SCCP envelopes 2-3  
signaling links, 1500 2-131  
signaling links, 2000 2-131  
Signaling Transport Card 6-2 , 6-3 , 6-4 ,  
6-5 , 6-6 , 6-7 , 6-8 , 6-9 , 6-10 ,  
6-15 , 6-19 , 6-21 , 6-22  
dual-slot 6-6 , 6-7 , 6-19 , 6-21  
single-slot 6-6 , 6-7 , 6-19 , 6-21  
single-slot STC 6-6 , 6-7 , 6-19 , 6-21  
SS7ANSI 6-6  
ss7gx25 2-9  
ssn 2-21  
STC 6-2 , 6-3 , 6-4 , 6-5 , 6-6 , 6-7 ,  
6-8 , 6-9 , 6-10 , 6-15 , 6-19 ,  
6-21 , 6-22 , 6-24  
dual-slot 6-6 , 6-7 , 6-19 , 6-21  
single-slot 6-6 , 6-7 , 6-19 , 6-21  
SVC-Automatic 2-3  
SVC-Incoming 2-3

## T

T1 MIM 6-6  
TCAP 1-2 , 2-2  
Time Slot Counter 6-6  
Time Slot Counter Synchronization 6-6 ,  
6-9  
TSC 6-6

## U

UDP echo 3-11

## X

X.25/SS7 IS41 Rev. A Gateway  
Overview 2-1  
X.25  
Connectivity 2-2  
X.25 Gateway Destinations 2-7  
X.25 Gateway feature 1-2  
X.25 LIMs 2-7  
X.25 linksets 2-7  
X.25 Routes 2-7  
X.25 Signaling Link Parameters 2-7  
X.25 signaling links 2-7  
X252000 2-21  
X25G 2-21  
xaddr 2-20