

# Oracle FS1-2 Flash Storage System

## Customer Service Guide



FLASH STORAGE  
SYSTEMS

Part Number E41587-04  
Oracle FS1-2 Flash Storage System release 6.1.0  
2015 April

Copyright © 2005, 2015, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

This software or hardware and documentation may provide access to or information on content, products and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Copyright © 2005, 2015, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT RIGHTS. Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.

# Contents

- List of Figures ..... 11
- List of Tables ..... 20
- Oracle FS1-2 Flash Storage System Customer Service Guide ..... 22
- Related Documentation ..... 23
- Oracle Resources ..... 24
- Chapter 1: Introduction to Oracle FS1-2 System Service Procedures ..... 25**
  - Oracle FS System Service Procedures ..... 25
    - Controller Components ..... 25
    - Drive Enclosure Components ..... 29
    - Pilot Components ..... 32
    - Warnings and Cautions ..... 35
      - Electrostatic Discharge Precautions ..... 35
      - Key Identity Properties (KIP) Automated Update ..... 35
    - Required Tools ..... 36
  - Guided Maintenance ..... 36
    - Guided Maintenance Overview ..... 36
    - Guided Maintenance Replaceable Components ..... 38
    - Access Guided Maintenance ..... 39
      - Access to Replace a Controller Component (1) ..... 39
      - Access to Replace a Controller Component (2) ..... 40
      - Access to Replace a Drive Enclosure Component ..... 41
      - Access to Replace a Pilot Component ..... 41
- Chapter 2: Oracle FS1–2 Global Procedures and Rail Kit Installation ..... 42**
  - Component Placement ..... 42
  - Component Numbering ..... 44
  - Oracle FS System Rack Hardware Specifications ..... 46
  - Prepare the Rack ..... 48
    - Remove the Doors From a Rack ..... 49
    - Remove a Side Panel From a Rack ..... 49
    - Rack Installation Safety Precautions ..... 50
  - System-Wide Procedures ..... 50
    - Data Backups ..... 50
    - Power Cycling ..... 51
  - Controller Rails ..... 51
    - Controller Rail Kits ..... 52
    - Install the Rack Rails for the Controller ..... 53
    - Install the Slide Rails for the Controller ..... 56
    - Install the Controller CMA ..... 61
    - Insert the Controller Into a Rack ..... 64
    - Verify Operation of the Slide Rails and the CMA ..... 65

---

Drive Enclosure Rails .....	67
Drive Enclosure Rail Kits .....	70
Install Drive Enclosure Rails .....	72
Install Rails for DE2-24P Drive Enclosures .....	72
Install Rails in Threaded Racks .....	72
Install Rails in Square or Round Hole Racks .....	75
Install Rails for DE2-24C Drive Enclosures .....	78
Insert a DE2-24P Drive Enclosure Into a Rack .....	82
Insert a DE2-24C Drive Enclosure Into a Rack .....	85
Pilot Rails .....	88
Pilot Rail Kits .....	88
Install the Rack Rails for the Pilot .....	89
Install the Slide Rails for the Pilot .....	92
Install the Pilot CMA .....	93
Insert the Pilot into a Rack .....	94
Verify Operation of the Slide Rails and the CMA .....	96
<b>Chapter 3: Controller Replacement Procedures .....</b>	<b>98</b>
Controller Overview .....	98
Key Identity Properties (KIP) Automated Update .....	98
Use SSH to Access Pilot (For PS-0 Replacement) .....	99
Replace Controller Air Filter .....	100
Remove an Air Filter .....	101
Insert an Air Filter .....	102
Replace a Controller Fan Module .....	103
Prepare the Component for Replacement .....	105
Remove the Controller Power Supply Cords .....	106
Slide Controller to Service Position .....	107
Open the Controller Top Cover .....	107
Remove a Fan Module .....	108
Insert a Fan Module .....	109
Close the Controller Top Cover .....	110
Complete the Component Replacement .....	111
Verify Controller Component Status .....	111
Replace a Controller Power Supply .....	112
Prepare the Component for Replacement .....	114
Remove the Power Cord .....	114
Remove a Power Supply .....	115
Insert a Power Supply .....	116
Insert the Power Cord .....	117
Verify Controller Component Status .....	117
Replace a Controller Energy Storage Module (ESM) .....	117
Prepare the Component for Replacement .....	119
Remove an Air Filter .....	120
Remove a Controller Energy Storage Module (ESM) .....	121
Insert an Energy Storage Module .....	122
Power On the Controller .....	124

---

---

Insert an Air Filter .....	124
Verify Controller Component Status .....	124
Replace a Controller Riser .....	125
Prepare the Component for Replacement .....	126
Remove the Controller Power Supply Cords .....	127
Slide Controller to Service Position .....	128
Disconnect Controller Cabling .....	129
Open the Controller Top Cover .....	129
Remove a Riser .....	129
Insert a Riser .....	132
Close the Controller Top Cover .....	134
Reconnect Controller Cabling .....	134
Complete the Component Replacement .....	135
Verify Controller Component Status .....	135
Replace a Controller HBA .....	135
Prepare the Component for Replacement .....	137
Remove the Controller Power Supply Cords .....	138
Slide Controller to Service Position .....	138
Disconnect Controller Cabling .....	139
Open the Controller Top Cover .....	140
Remove a Riser .....	140
Remove an HBA .....	143
Insert an HBA .....	144
Insert a Riser .....	146
Close the Controller Top Cover .....	148
Reconnect Controller Cabling .....	148
Complete the Component Replacement .....	149
Verify Controller Component Status .....	149
Replace a Controller DIMM .....	149
Prepare the Component for Replacement .....	152
Remove the Controller Power Supply Cords .....	153
Slide Controller to Service Position .....	153
Open the Controller Top Cover .....	154
Remove an Air Filter .....	155
Raise the Drive Compartment to Service Position .....	156
Remove an Air Duct .....	159
Remove a DIMM .....	160
Insert a DIMM .....	161
Lower the Drive Compartment .....	162
Insert an Air Duct .....	163
Insert an Air Filter .....	163
Close the Controller Top Cover .....	164
Complete the Component Replacement .....	165
Verify Controller Component Status .....	165
<b>Chapter 4: Drive Enclosure Replacement Procedures .....</b>	<b>166</b>
Drive Enclosure Overview .....	166

---

---

Drive Enclosure Drive Replacement .....	168
Replace a Drive Enclosure Drive .....	170
Prepare a Drive Enclosure for Component Replacement .....	170
Remove a Drive .....	171
Insert a Drive .....	173
Verify the Status of a Drive Enclosure Component .....	175
Replace an I/O Module .....	175
Prepare a Drive Enclosure for Component Replacement .....	177
Remove an I/O Module .....	177
Insert an I/O Module .....	178
Verify the Status of a Drive Enclosure Component .....	180
Replace a Power Cooling Module .....	180
Prepare a Drive Enclosure for Component Replacement .....	181
Remove a Power Cooling Module .....	182
Insert a Power Cooling Module .....	183
Verify the Status of a Drive Enclosure Component .....	185
<b>Chapter 5: Pilot Replacement Procedures .....</b>	<b>187</b>
Pilot Overview .....	187
Replace a Pilot Battery .....	187
Prepare a Pilot for Component Replacement .....	189
Power Off the Pilot .....	190
Slide Pilot to Service Position .....	190
Open Pilot Fan Door .....	191
Open Pilot Top Cover .....	192
Remove a Battery .....	193
Insert a Battery .....	193
Close Pilot Top Cover .....	194
Close Pilot Fan Door .....	195
Slide Pilot to Rack Position .....	195
Connect Power Cords On the Pilot .....	196
Verify Component Replacement on the Standby Pilot .....	196
Verify Component Replacement on the Active Pilot .....	197
Replace a Pilot SAS HBA .....	197
Prepare a Pilot for Component Replacement .....	199
Power Off the Pilot .....	199
Slide Pilot to Service Position .....	200
Open Pilot Fan Door .....	201
Open Pilot Top Cover .....	202
Remove a SAS HBA .....	203
Insert a SAS HBA .....	203
Close Pilot Top Cover .....	204
Close Pilot Fan Door .....	204
Slide Pilot to Rack Position .....	205
Connect Power Cords On the Pilot .....	205
Verify Component Replacement on the Standby Pilot .....	206
Verify Component Replacement on the Active Pilot .....	206

---

---

Replace a Pilot Riser .....	206
Prepare a Pilot for Component Replacement.....	208
Power Off the Pilot.....	209
Slide Pilot to Service Position.....	209
Open Pilot Fan Door.....	210
Open Pilot Top Cover .....	211
Remove a Riser.....	212
Insert a Riser .....	213
Close Pilot Top Cover.....	214
Close Pilot Fan Door .....	215
Slide Pilot to Rack Position.....	215
Connect Power Cords On the Pilot.....	216
Verify Component Replacement on the Standby Pilot .....	216
Verify Component Replacement on the Active Pilot.....	217
Replace a Pilot Power Supply .....	217
Prepare a Pilot for Component Replacement.....	218
Remove a Power Supply .....	219
Insert a Power Supply .....	220
Verify Power Supply Replacement on a Pilot .....	220
Replace a Pilot Fan Module .....	221
Prepare a Pilot for Component Replacement.....	222
Slide Pilot to Service Position.....	223
Open Pilot Fan Door.....	224
Remove a Fan Module .....	225
Insert a Fan Module.....	226
Close Pilot Fan Door .....	226
Slide Pilot to Rack Position.....	227
Verify Component Replacement on the Standby Pilot .....	227
Verify Component Replacement on the Active Pilot.....	227
Replace a Pilot DIMM .....	228
Prepare a Pilot for Component Replacement.....	229
Power Off the Pilot.....	230
Slide Pilot to Service Position.....	230
Open Pilot Fan Door.....	232
Open Pilot Top Cover .....	233
Remove a Pilot DIMM.....	234
Insert a Pilot DIMM .....	234
Close Pilot Top Cover.....	235
Close Pilot Fan Door .....	236
Slide Pilot to Rack Position.....	236
Connect Power Cords On the Pilot.....	237
Verify Component Replacement on the Standby Pilot .....	237
Verify Component Replacement on the Active Pilot.....	237
Replace a Pilot Chassis .....	238
Prepare a Pilot for Component Replacement.....	239
Power Off the Pilot.....	240
Disconnect Pilot Cabling.....	240

---

---

Slide Pilot to Service Position .....	241
Remove Pilot Chassis From Rack .....	243
Open Pilot Fan Door .....	244
Open Pilot Top Cover .....	244
Remove Components From the Pilot .....	245
Remove a Power Supply .....	245
Remove a Fan Module .....	246
Remove a Pilot DIMM .....	247
Remove a Heat Sink .....	248
Remove a Pilot CPU .....	249
Remove a Riser .....	251
Remove a SAS HDD .....	252
Remove a Disk Backplane .....	253
Insert Components on the Pilot .....	256
Insert a Disk Backplane .....	256
Insert a SAS HDD .....	258
Insert a Riser .....	259
Insert a Pilot CPU .....	259
Insert a Heat Sink .....	260
Insert a Pilot DIMM .....	261
Insert a Fan Module .....	261
Close Pilot Top Cover .....	262
Close Pilot Fan Door .....	263
Insert the Pilot Onto the Rack .....	263
Insert Pilot Chassis Into Rack .....	264
Slide Pilot to Rack Position .....	264
Re-connect Pilot Cabling .....	265
Connect Power Cords On the Pilot .....	266
Verify Component Replacement on the Standby Pilot .....	266
Verify Component Replacement on the Active Pilot .....	266
<b>Appendix A: Oracle FS System Hardware Specifications .....</b>	<b>267</b>
Oracle FS System Hardware Specifications .....	267
Component Chassis Hardware Specifications .....	268
PDU Hardware Specifications .....	271
System Power Requirements .....	275
System Packaging and Transportation .....	275
System Environmentals .....	275
<b>Appendix B: Oracle FS System LED Status .....</b>	<b>277</b>
Oracle FS System LEDs .....	277
Controller LED Indicators .....	277
Controller Power Supply LED Indicators .....	284
Controller Fan LED Indicators .....	284
Controller ESM LED Indicators .....	285
Drive Enclosure LED Indicators .....	286
Power Cooling Module LED Indicators .....	288
I/O Module LED Indicators .....	289

---

---

Drive LED Indicators.....	290
Pilot LED Indicators .....	292
Pilot Drive LED Indicators.....	295
Pilot Fan LED Indicators .....	296
Pilot Port LED Indicators .....	296
Pilot Motherboard LED Indicators.....	297
Pilot Power Supply LED Indicators .....	298
<b>Index.....</b>	<b>300</b>

# List of Figures

- Figure 1: Controller back view.....26
- Figure 2: Controller front view with the air filter.....27
- Figure 3: Controller front view without the air filter.....27
- Figure 4: Exploded view of Controller replaceable components.....28
- Figure 5: DE2-24P Drive Enclosure CRUs.....29
- Figure 6: DE2-24C Drive Enclosure CRUs.....30
- Figure 7: Pilot back view.....32
- Figure 8: Pilot front view.....33
- Figure 9: Exploded view of Pilot replaceable components.....34
- Figure 10: Component numbering in Oracle FS Systems.....45
- Figure 11: Maximum tilt angles for stationary Oracle FS System racks.....48
- Figure 12: Rack door removal.....49
- Figure 13: Examples of supported rack holes.....51
- Figure 14: Controller rack mount location.....54
- Figure 15: Left rail secured to the front of the rack.....55
- Figure 16: Left rail adjusted at the back of the rack .....56
- Figure 17: Slide rail assembly unlocked.....57
- Figure 18: Mounting bracket release button .....57
- Figure 19: Slide rail middle section unlocked.....58
- Figure 20: Mounting bracket attached to the chassis.....58
- Figure 21: Slide rail mounted on the rack post.....59
- Figure 22: Slide rail spacing tool .....60
- Figure 23: Controller chassis mounted on the slide rails .....61
- Figure 24: CMA rail extension inserted into the back of the left slide rail .....62
- Figure 25: Inner CMA connector mounted.....63
- Figure 26: Outer CMA connector attached.....63

---

Figure 27: Left side of the slide rail mounted.....	64
Figure 28: Controller slide rails unlocked.....	66
Figure 29: Mounting bracket release button.....	66
Figure 30: Slide rail release button.....	67
Figure 31: Examples of supported rack holes.....	68
Figure 32: Rails for the DE2-24P Drive Enclosure.....	69
Figure 33: Rails for the DE2-24C Drive Enclosure.....	70
Figure 34: 10mm wrench and adaptor pins .....	73
Figure 35: Rack flange, rail flange, and rail label (front).....	74
Figure 36: Back-mounting screw.....	75
Figure 37: Front of the rack and rail-location pegs.....	76
Figure 38: A Phillips 13mm head hex flange screw and the front of a rack.....	77
Figure 39: Extended rail to the back of the rack.....	77
Figure 40: A Phillips 13mm head hex flange screw and the back of a rack.....	78
Figure 41: Cage nut installed in a square-hole rack.....	79
Figure 42: Rail-location pegs from inside of the rail flange and the clip nut.....	79
Figure 43: Rail-location pegs and a square-hole rack.....	80
Figure 44: Rail extended to holes in the back of the rack.....	81
Figure 45: The locking screws and side of the rail.....	81
Figure 46: DE2-24P Drive Enclosure (left) and DE2-24C Drive Enclosure (right).....	82
Figure 47: Left rail channel.....	82
Figure 48: Back of the Drive Enclosure and Rail secured.....	84
Figure 49: Left front-side cap and Phillips 13mm head hex flange screw.....	85
Figure 50: DE2-24P Drive Enclosure (left) and DE2-24C Drive Enclosure (right).....	86
Figure 51: The rail ledge for the DE2-24C Drive Enclosure.....	86
Figure 52: Phillips Number 2 pan head screw with patch lock.....	87
Figure 53: Left front-side cap and Phillips 13mm head hex flange screw.....	87
Figure 54: Pilot rail kit parts.....	89

---

---

Figure 55: Rack-mount installation card template.....	90
Figure 56: Slide rails oriented with the ball bearing track.....	91
Figure 57: Slide rail assembly aligned with the rack.....	91
Figure 58: Mounting bracket aligned with the Pilot chassis.....	92
Figure 59: CMA slide rail connector inserted into the back of the right slide rail.....	93
Figure 60: CMA slide rail connector inserted into the back of the left slide rail.....	94
Figure 61: Pilot with mounting brackets inserted into the slide rails.....	95
Figure 62: Pilot inserted into the rack.....	96
Figure 63: Oracle FS System Controller.....	98
Figure 64: Controller air filter.....	100
Figure 65: Air filter release tabs.....	101
Figure 66: Remove air filter.....	102
Figure 67: Insert air filter.....	102
Figure 68: Fan module .....	103
Figure 69: Fan module location.....	104
Figure 70: Remove power supply cords .....	106
Figure 71: Slide the Controller to service position.....	107
Figure 72: Captive thumb screws to remove the top cover.....	108
Figure 73: Remove fan module .....	109
Figure 74: Insert fan module .....	110
Figure 75: Close Controller top cover.....	111
Figure 76: Power supply location.....	112
Figure 77: Disconnect the power cord .....	115
Figure 78: Controller power supply latch.....	115
Figure 79: Remove power supply.....	116
Figure 80: Insert power supply .....	117
Figure 81: ESM .....	118
Figure 82: Air filter release tabs.....	120

---

---

Figure 83: Remove air filter.....	121
Figure 84: Open ESM latch.....	121
Figure 85: Remove ESM .....	122
Figure 86: Insert ESM.....	123
Figure 87: Secure ESM into drive slot.....	123
Figure 88: Insert air filter.....	124
Figure 89: Riser locations .....	125
Figure 90: Remove power supply cords .....	127
Figure 91: Slide the Controller to service position.....	128
Figure 92: Captive thumb screws to remove the top cover.....	129
Figure 93: Captive screws to secure the risers.....	130
Figure 94: Unlock Riser 3 latch .....	131
Figure 95: Remove riser.....	131
Figure 96: Insert riser.....	132
Figure 97: Captive screws to secure risers to the motherboard.....	133
Figure 98: Riser 3 latch locked.....	133
Figure 99: Close Controller top cover.....	134
Figure 100: Remove power supply cords .....	138
Figure 101: Slide the Controller to service position.....	139
Figure 102: Captive thumb screws to remove the top cover.....	140
Figure 103: Captive screws to secure the risers.....	141
Figure 104: Unlock Riser 3 latch .....	142
Figure 105: Remove riser.....	142
Figure 106: Unlock riser retainer latch to release HBA.....	143
Figure 107: Remove HBA from riser slots.....	144
Figure 108: Insert HBA into riser slot.....	145
Figure 109: HBA retainer latch.....	145
Figure 110: Insert riser.....	146

---

---

Figure 111: Captive screws to secure risers to the motherboard.....	147
Figure 112: Riser 3 latch locked.....	147
Figure 113: Close Controller top cover.....	148
Figure 114: DIMM memory module.....	150
Figure 115: DIMMs in DIMM slots.....	151
Figure 116: Remove power supply cords .....	153
Figure 117: Slide the Controller to service position.....	154
Figure 118: Captive thumb screws to remove the top cover.....	155
Figure 119: Air filter release tabs.....	155
Figure 120: Remove air filter.....	156
Figure 121: Cables connected to the backplane.....	157
Figure 122: Disengaging the backplane.....	158
Figure 123: Drive compartment raised.....	158
Figure 124: Remove air duct.....	159
Figure 125: Air duct.....	160
Figure 126: Remove DIMMs .....	160
Figure 127: Insert Controller DIMM.....	161
Figure 128: DIMM alignment over DIMM slots.....	162
Figure 129: Reconnect cables to the backplane.....	163
Figure 130: Insert air filter.....	164
Figure 131: Close Controller top cover.....	165
Figure 132: DE2-24P Drive Enclosure (front view).....	166
Figure 133: DE2-24C Drive Enclosure (front view).....	167
Figure 134: DE2-24P Drive Enclosure (back view).....	168
Figure 135: DE2-24C Drive Enclosure (back view).....	168
Figure 136: DE2-24P Drive Enclosure drives.....	169
Figure 137: DE2-24C Drive Enclosure drives.....	169
Figure 138: A DE2-24P Drive Enclosure drive and drive carrier latch.....	171

---

---

Figure 139: A DE2-24C Drive Enclosure drive and drive carrier latch.....	172
Figure 140: Failed drive removed from a DE2-24C Drive Enclosure.....	172
Figure 141: Failed drive removed from a DE2-24P Drive Enclosure.....	173
Figure 142: Extended drive carrier handles.....	173
Figure 143: DE2-24C Drive Enclosure and inserted replacement drive.....	174
Figure 144: DE2-24P Drive Enclosure and inserted replacement drive.....	174
Figure 145: I/O modules on DE2-24P and DE2-24C Drive Enclosure types.....	176
Figure 146: I/O module SAS connector ports.....	178
Figure 147: Remove the I/O module.....	178
Figure 148: Insert the I/O module.....	179
Figure 149: I/O module SAS connector ports.....	179
Figure 150: Power cooling modules (DE2-24P and DE2-24C Drive Enclosures).....	181
Figure 151: Attachment lever and latch on the power cooling module.....	183
Figure 152: Power cooling module orientation.....	184
Figure 153: Replacement power cooling module with a fully open attachment lever.....	184
Figure 154: Replacement power cooling module (right side).....	185
Figure 155: Pilot.....	187
Figure 156: Pilot battery.....	188
Figure 157: Pilot position during component replacement.....	190
Figure 158: Pilot slide lockout release tabs.....	191
Figure 159: Pilot with fan door open.....	192
Figure 160: Pilot top cover removal.....	192
Figure 161: Pilot battery removal.....	193
Figure 162: Battery insertion.....	194
Figure 163: Pilot top cover installed.....	195
Figure 164: Location of the Pilot release tabs.....	196
Figure 165: SAS HBA.....	198
Figure 166: Pilot position during component replacement.....	200

---

---

Figure 167: Pilot slide lockout release tabs.....	201
Figure 168: Pilot with fan door open.....	202
Figure 169: Pilot top cover removal.....	202
Figure 170: SAS HBA insertion into the riser.....	203
Figure 171: Pilot top cover installed.....	204
Figure 172: Location of the Pilot release tabs.....	205
Figure 173: Riser locations.....	207
Figure 174: Pilot position during component replacement.....	209
Figure 175: Pilot slide lockout release tabs.....	210
Figure 176: Pilot with fan door open.....	211
Figure 177: Pilot top cover removal.....	211
Figure 178: Riser board assembly removal.....	212
Figure 179: Disconnect SAS cable bundle.....	213
Figure 180: Pilot riser insertion.....	214
Figure 181: Pilot top cover installed.....	215
Figure 182: Location of the Pilot release tabs.....	216
Figure 183: Location of the Pilot power supplies.....	217
Figure 184: Power supply removal.....	219
Figure 185: Power supply insertion.....	220
Figure 186: Fan module location .....	221
Figure 187: Pilot position during component replacement.....	223
Figure 188: Pilot slide lockout release tabs.....	224
Figure 189: Pilot with fan door open.....	225
Figure 190: Pilot fan module removal.....	225
Figure 191: Fan module insertion.....	226
Figure 192: Location of the Pilot release tabs.....	227
Figure 193: Location of the DIMMs on the Pilot motherboard.....	228
Figure 194: Pilot position during component replacement.....	231

---

---

Figure 195: Pilot slide lockout release tabs.....	232
Figure 196: Pilot with fan door open.....	233
Figure 197: Pilot top cover removal.....	233
Figure 198: Pilot DIMM removal.....	234
Figure 199: Pilot top cover installed.....	236
Figure 200: Location of the Pilot release tabs.....	236
Figure 201: CMA release tabs.....	241
Figure 202: Pilot position during component replacement.....	242
Figure 203: Pilot slide lockout release tabs.....	243
Figure 204: Pilot with fan door open.....	244
Figure 205: Pilot top cover removal.....	245
Figure 206: Power supply removal.....	246
Figure 207: Pilot fan module removal.....	247
Figure 208: Pilot DIMM removal.....	248
Figure 209: Loosen four screws to remove heat sink.....	249
Figure 210: CPU socket disengaged.....	249
Figure 211: CPU removal tool.....	250
Figure 212: CPU removal.....	250
Figure 213: Riser board assembly removal.....	251
Figure 214: Disconnect SAS cable bundle.....	252
Figure 215: SAS HDD removal.....	253
Figure 216: Disk backplane cables disconnected.....	254
Figure 217: Captive thumb screws to remove disk backplane.....	255
Figure 218: Pilot disk backplane removal.....	255
Figure 219: Pilot disk backplane positioned over standoffs.....	256
Figure 220: Captive thumb screws to secure disk backplane.....	257
Figure 221: Disk backplane cables connected.....	257
Figure 222: SAS HDD insertion.....	258

---

---

Figure 223: Pilot riser insertion.....	259
Figure 224: CPU insertion.....	260
Figure 225: Heat sink insertion.....	260
Figure 226: Fan module insertion.....	262
Figure 227: Pilot top cover installed.....	263
Figure 228: Lift Pilot chassis onto rack.....	264
Figure 229: Location of the Pilot release tabs.....	265
Figure 230: LED alarm assembly front display.....	278
Figure 231: Controller back LEDs.....	280
Figure 232: Controller drive LEDs.....	285
Figure 233: Operator panel LEDs (DE2-24P Drive Enclosure).....	287
Figure 234: Operator panel LEDs (DE2-24C Drive Enclosure).....	287
Figure 235: Power cooling module LEDs.....	288
Figure 236: I/O module LEDs.....	290
Figure 237: Drive LEDs (DE2-24P Drive Enclosure).....	291
Figure 238: Drive LEDs (DE2-24C Drive Enclosure).....	291
Figure 239: LEDs at the front of the Pilot.....	292
Figure 240: LEDs at the back of the Pilot.....	293

# List of Tables

Table 1: Oracle resources.....24

Table 2: Controller components and descriptions.....25

Table 3: Drive Enclosure component descriptions.....31

Table 4: Release 6.1 supported drives.....31

Table 5: Pilot components and descriptions.....32

Table 6: Required tools.....36

Table 7: Hot-serviceable components.....38

Table 8: Pilot replaceable components.....39

Table 9: Default component placement in racks.....42

Table 10: Component placement with one Replication Engine.....42

Table 11: Component placement with two Replication Engines.....43

Table 12: Component placement with three Replication Engines.....43

Table 13: Component placement with four Replication Engines.....44

Table 14: Rack specifications for an Oracle FS System.....46

Table 15: Controller rail kit mounting screws.....52

Table 16: Drive Enclosure rail kits.....71

Table 17: Basic components of an Oracle Flash Storage System.....267

Table 18: Maximum physical dimensions of an Oracle Flash Storage System.....268

Table 19: Pilot dimensions and weight .....268

Table 20: Controller dimensions and weight.....269

Table 21: DE2-24P Drive Enclosure dimensions and weight.....269

Table 22: DE2-24C Drive Enclosure dimensions and weight.....269

Table 23: Pilot power characteristics.....270

Table 24: Controller power characteristics .....270

Table 25: Drive Enclosure power characteristics.....271

Table 26: Low voltage dual phase PDU for Oracle Flash Storage Systems.....272

---

Table 27: Low voltage three-phase PDU for Oracle Flash Storage Systems.....	272
Table 28: High voltage single phase PDU for Oracle Flash Storage Systems.....	273
Table 29: High voltage three-phase PDU for Oracle Flash Storage Systems.....	274
Table 30: System altitude specifications.....	275
Table 31: System temperature and humidity specifications.....	276
Table 32: Controller LED status and description (front panel).....	278
Table 33: Controller LED status and description (back panel).....	281
Table 34: Controller power supply LED status and description .....	284
Table 35: Controller fan LED status and description .....	284
Table 36: Controller ESM LED status and description .....	286
Table 37: Drive Enclosure LED status and description (operator panel).....	288
Table 38: Drive Enclosure LED status and description (power cooling module).....	289
Table 39: Drive Enclosure LED status and description (I/O module).....	290
Table 40: Drive Enclosure LED status and description (drives).....	291
Table 41: Pilot LED status and description .....	293
Table 42: Pilot drive LED status and description .....	295
Table 43: Pilot fan LED status and description .....	296
Table 44: Network management port LED status and description .....	296
Table 45: Ethernet port LED status and description .....	297
Table 46: Motherboard LED status and description .....	297
Table 47: Pilot Drive LED status and description .....	298

# Oracle FS1-2 Flash Storage System Customer Service Guide

Part Number E41587-04

Oracle Flash Storage System Release 6.1

2015 April



---

FLASH STORAGE  
SYSTEMS

## Related Documentation

- *Oracle Flash Storage System Glossary*
- *Oracle FS1-2 Flash Storage System Installation Guide (Racked)*
- *Oracle FS1-2 Flash Storage System Installation Guide (Not-Racked)*
- *Oracle Flash Storage System Administrator's Guide*
- *Oracle Flash Storage System CLI Reference*
- *Oracle FS1-2 Flash Storage System Release Notes*

# Oracle Resources

Table 1: Oracle resources

For help with...	Contact...
Support	<a href="http://www.oracle.com/support">http://www.oracle.com/support</a> (www.oracle.com/support)
Training	<a href="https://education.oracle.com">https://education.oracle.com</a> (https://education.oracle.com)
Documentation	<ul style="list-style-type: none"><li>• <b>Oracle Help Center:</b> (<a href="http://www.oracle.com/goto/FSStorage/docs">http://www.oracle.com/goto/FSStorage/docs</a>)</li><li>• From Oracle FS System Manager (GUI): Help &gt; Documentation</li><li>• From Oracle FS System HTTP access: (<a href="http://system-name-ip/documentation.php">http://system-name-ip/documentation.php</a> where system-name-ip is the name or the public IP address of your system)</li></ul>
Documentation feedback	<a href="http://www.oracle.com/goto/docfeedback">http://www.oracle.com/goto/docfeedback</a> ( <a href="http://www.oracle.com/goto/docfeedback">http://www.oracle.com/goto/docfeedback</a> )
Contact Oracle	<a href="http://www.oracle.com/us/corporate/contact/index.html">http://www.oracle.com/us/corporate/contact/index.html</a> ( <a href="http://www.oracle.com/us/corporate/contact/index.html">http://www.oracle.com/us/corporate/contact/index.html</a> )

# Introduction to Oracle FS1-2 System Service Procedures

## Oracle FS System Service Procedures

### Controller Components

When replacing a component, you must know its part number and whether it is hot serviceable. Having that information helps you to order the correct replacement component and to determine whether you can replace the component yourself. To locate part numbers, open [Oracle System Handbook](https://support.oracle.com/handbook_private/index.html) ([https://support.oracle.com/handbook\\_private/index.html](https://support.oracle.com/handbook_private/index.html)). The part numbers are listed in the Oracle FS1 Flash Storage System components list.

The Controller is a two rack-unit (2U) server and consists of several replaceable components. Many Controller components are customer replaceable (CRUs), while others are field replaceable units (FRUs) that require Oracle Customer Support to perform the replacement. Also, some components are hot-serviceable, meaning that they can be replaced, while the Controller is powered on. Some of the Controller component replacement procedures require the Controller to be powered off and/or removed from the rack. The following table provides a summary of the Controller FRUs and CRUs.


**Table 2: Controller components and descriptions**

Controller component	Type	Hot serviceable
4 GB NVDIMM	FRU	No
16 GB DIMM module	CRU	No
Air filter	CRU	Yes
Central processing unit (CPU)	FRU	No
Disk backplane	FRU	No
Energy storage module (ESM)	CRU	No
Fan module	CRU	No
Controller identification display (CUID)	FRU	No
HBA [Sun Storage: 16 Gb/s Fibre Channel (FC) PCI-e]	CRU	No
HBA [Sun Storage: 16 Gb/s FC optics]	CRU	No

**Table 2: Controller components and descriptions (continued)**

Controller component	Type	Hot serviceable
HBA [Sun Storage: 10 Gb/s FCoE optics][iSCSI]	CRU	No
HBA [dual-port 10 GbE PCIe 2.0 Copper and Fiber SFP+]	CRU	No
HBA [8 Gb/s Dual-Port FC PCI-e]	CRU	No
Heat sink	FRU	No
LED alarm board assembly	FRU	No
Motherboard cable kit	FRU	No
Power distribution board (PDB)	FRU	No
Power supply	CRU	Yes
Rail kit assembly	CRU	No
Riser board assembly	CRU	No
SAS HBA (PCIe-3, 6 Gb/s, 4x4 port)	CRU	No

Some FRUs and CRUs can be accessed from the front or back of the Controller. For replacing other FRUs and CRUs, you must open the top cover of the Controller. The following figure shows the components located at the back of the Controller.

**Figure 1: Controller back view**


Legend 1 Power supplies

6 Network port to opposite  
Controller

2 HBA slots	7 Network port to Pilot PMI
3 Server management port	8 Network port to opposite Controller PMI
4 Network management port	9 Ports for NAS host connection
5 Serial link port to opposite Controller	

The following figure shows the front of the Controller with the air filter.


**Figure 2: Controller front view with the air filter**



Legend 1 LED alarm board assembly	3 Controller identification display
2 Air filter	4 Controller RFID tag

The following figure shows the front of the Controller without the air filter.


**Figure 3: Controller front view without the air filter**



Legend 1 ESM modules (0,1,2,3)
2 Filler panels
3 Controller Unit Identification Display (CUID)

The following figure shows all the replaceable components of the Controller.

**Figure 4: Exploded view of Controller replaceable components**



Legend	1 Top cover (with service label)	9 DIMMs	17 Riser
	2 LED assembly	10 Fan compartment	18 Battery
	3 Fan modules	11 PDB Risers	19 NV-DIMM
	4 CUID	12 ESM backplane boards	20 Heat sink
	5 Energy storage modules (ESMs)	13 Power supply	21 CPU
	6 Air filter	14 PDB Duct	22 PDB cover
	7 Motherboard cable kit	15 Air duct	
	8 Filler panels for DIMM slots	16 HBA	

## Related Links

[Replace Controller Air Filter](#)

[Replace a Controller DIMM](#)

[Replace a Controller Energy Storage Module \(ESM\)](#)

[Replace a Controller Fan Module](#)

[Replace a Controller HBA](#)

[Replace a Controller HDD](#)

[Replace a Controller NV-DIMM](#)

[Replace a Controller Power Supply](#)

[Replace a Controller Riser](#)

## Drive Enclosure Components


When replacing a component, you must know its part number and whether it is hot serviceable. Having that information helps you to order the correct replacement component and to determine whether you can replace the component yourself. To locate part numbers, open [Oracle System Handbook](https://support.oracle.com/handbook_private/index.html) ([https://support.oracle.com/handbook\\_private/index.html](https://support.oracle.com/handbook_private/index.html)). The part numbers are listed in the Oracle FS1 Flash Storage System components list.

The Drive Enclosure chassis is a field replaceable unit (FRU). The remaining components of both Drive Enclosure types are customer replaceable units (CRU). Drive Enclosure CRUs are hot serviceable.

**WARNING:** Do not power-cycle a Drive Enclosure. Power-cycling a Drive Enclosure impacts the primary and secondary data paths in the Drive Enclosure and puts user data at risk.

The following figure shows the CRUs in the DE2-24P Drive Enclosure.

**Figure 5: DE2-24P Drive Enclosure CRUs**




Legend	1 Drives	4 I/O module 0
	2 Power cooling module 0	5 I/O module 1

## 3 Power cooling module 1

The following figure shows the CRUs in the DE2-24C Drive Enclosure.

**Figure 6: DE2-24C Drive Enclosure CRUs**



Legend	1 Drives	4 I/O module 0
	2 Power cooling module 1	5 I/O module 1
	3 Power cooling module 2	

The following table provides a summary of the Drive Enclosure components.

**Table 3: Drive Enclosure component descriptions**

Drive Enclosure component	Component Type	Hot serviceable
Chassis for the DE2-24P Drive Enclosure	FRU	No
Chassis for the DE2-24C Drive Enclosure	FRU	No
Two I/O modules (EBOD modules)	CRU	Yes
Two power cooling modules	CRU	Yes

Drive Enclosure drives are customer replaceable and hot serviceable. The Oracle FS System release 6.1 supports the following drives:

**Note:** The list of supported drives can change. Refer to the release notes for your release of the Oracle FS System for the corresponding list of supported drives.

**Table 4: Release 6.1 supported drives**

Drives and configurations	Drive Enclosure type
<ul style="list-style-type: none"> <li>2.5-inch (6.35-cm) SAS-2 small form factor (SFF) HDDs, 300 GB</li> <li>24 drives in a DE2-24P Drive Enclosure</li> </ul>	DE2-24P Drive Enclosure
<ul style="list-style-type: none"> <li>2.5-inch (6.35-cm) SAS-2 SFF HDDs, 900 GB</li> <li>24 drives in a DE2-24P Drive Enclosure</li> </ul>	DE2-24P Drive Enclosure
<ul style="list-style-type: none"> <li>SSDs, 400 GB</li> <li>Seven or 13 drives in a DE2-24P Drive Enclosure</li> </ul>	DE2-24P Drive Enclosure
<ul style="list-style-type: none"> <li>SSDs, 1.6 TB</li> <li>Seven, 13, or 19 drives in a DE2-24P Drive Enclosure</li> </ul>	DE2-24P Drive Enclosure
<ul style="list-style-type: none"> <li>3.5-inch (8.89-cm) SAS-2 large form factor (LFF) HDDs, 4 TB</li> <li>24 drives in a DE2-24C Drive Enclosure</li> </ul>	DE2-24C Drive Enclosure

## Pilot Components

When replacing a component, you must know its part number and whether it is hot serviceable. Having that information helps you to order the correct replacement component and to determine whether you can replace the component yourself. To locate a part number for the Pilot, open [Oracle System Handbook](https://support.oracle.com/handbook_private/index.html) ([https://support.oracle.com/handbook\\_private/index.html](https://support.oracle.com/handbook_private/index.html)) and go to the Oracle FS1 Flash Storage System components list. Part numbers are listed in the components list.


The Pilot is a one rack-unit (1U) server and consists of several replaceable components. Many Pilot components are customer replaceable (CRUs), while others are field replaceable units (FRUs) that require Oracle Customer Support to perform the replacement. Also, some components are hot-serviceable, meaning that they can be replaced, while the Pilot is powered on. The following table provides a summary of the Pilot FRUs and CRUs.

**Table 5: Pilot components and descriptions**

Pilot component	Type	Hot-serviceable
Battery	CRU	No
Disk backplane	FRU	No
8 GB DIMM module	CRU	No
Cable kit	FRU	No
CPU	FRU	No
300 GB SAS HDD	FRU	No
Fan module	CRU	No <b>Note:</b> GM support is required to ensure that failover has occurred.
SAS HBA [6 Gb/s]	CRU	No
Heat sink	FRU	No
Power supply	CRU	Yes

The following figure shows the components located at the back of the Pilot.

**Figure 7: Pilot back view**



Legend	1 Power supplies	7 Ethernet port (ETH-0) labeled as NET-3
	2 PCIe card slot 1	8 Ethernet port (ETH-1) labeled as NET-2
	3 PCIe card slot 2	9 Ethernet port (ETH-2) labeled as NET-1
	4 PCIe card slot 3	10 Ethernet port (ETH-3) labeled as NET-0
	5 ILOM SP network management port (also labeled as NET MGT port)	11 USB connectors
	6 Serial management port (also labeled as SRMGT port)	12 Video connector

The following figure shows the components located at the front of the Pilot.


**Figure 8: Pilot front view**



Legend	1 Product serial number RFID tag	3 Front indicator module (FIM)
	2 Power button	4 Pilot boot drive

The following figure shows an exploded view of the Pilot.

Figure 9: Exploded view of Pilot replaceable components



Legend	1 CPU	7 Battery
	2 Motherboard	8 DIMMs
	3 Fan modules	9 Heat sinks
	4 Fan modules	10 Power supplies
	5 HBA	11 Disk backplane boards
	6 Risers	

### Related Links

[Replace a Battery](#)

[Replace a Chassis](#)

[Replace a DIMM](#)

[Replace a Fan Module](#)

[Replace a Power Supply](#)

[Replace a SAS HBA](#)

[Replace a SAS HDD](#)

[Replace a Riser](#)

## Warnings and Cautions

Hazard signal words conform to the American National Standards Institute (ANSI) Z535.4-2002 meanings.

**CAUTION:** Indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury.

**DANGER:** Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.

**Tip:** To indicate best practices for a process.

**Important:** To emphasize a point, to remind you of something, or to indicate potential problems in the outcome of the in-process task.

## Electrostatic Discharge Precautions

**CAUTION:** Before you handle a component, make sure that you have taken electrostatic discharge (ESD) precautions:

- The minimum requirement is an anti-static wrist strap connected to a hard ground. Remove components from their packaging and place them on an ESD-qualified table that is equipped with ground points for wrist straps.
- Static charges can build up rapidly on rolling carts. If you transport a hardware component by cart, ground the cart with a drag chain on an ESD floor. If there is no ESD cart available or ESD floor, ground yourself before you touch a component that has been transported on a cart.

## Key Identity Properties (KIP) Automated Update

Oracle ILOM includes a Key Identity Properties (KIP) auto-update feature that ensures product information that is used for service entitlement and warranty coverage is accurately maintained by the Pilots and Controllers at all times, even during hardware replacement service activities.

The KIP includes the component product name, product part number (PPN), and product serial number (PSN). The KIP information is stored in the replaceable unit identifiers container of the three replaceable units that are designated as the quorum members for the component.

The Pilot quorum members include:

- Disk backplane (DBP), designated as the primary quorum member
- Motherboard (MB), designated as a backup quorum member
- Power supply-0 (PS-0) designated as a backup quorum member

The Controller quorum members include:

- Disk backplane (DBP), designated as the primary quorum member
- Motherboard (MB), designated as a backup quorum member
- Power Distribution Board (PDB) designated as a backup quorum member

When a Pilot or Controller replaceable unit that contains the KIP is removed and a replacement component is installed, the KIP of the replacement component is programmed by the Oracle Integrated Lights Out Manager (ILOM) to contain the same KIP as the other two components.

**Note:** Do not change more than one of the quorum devices for either Pilot or Controller at the same time. The ILOM must perform the system initialization after any change in any quorum device. Automated updates can only be completed when two of the three quorum members contain matching key identity properties.

After a quorum device is replaced, you can reset the ILOM either by using an improvised tool like an unbent paper clip or using secure shell (SSH) into the Pilot.

## Required Tools

Before starting the installation of a Oracle Flash Storage System, be sure you have the needed equipment and tools available.

**Table 6: Required tools**

Tool	Purpose	Illustration
#1 and #2 Phillips-head screwdrivers	Remove and secure Oracle Flash Storage System hardware components.	
Offset box wrench, 13/32 inches (10 millimeters)	Work with adjustable mounting rail assemblies.	
Torx® T20 screwdriver	Attach rail assemblies to the vertical channels and secure hardware components to the rails.	
Torx® T30 screwdriver	Connect two racks.	
Wire cutters	Cut tie wraps.	

**Note:** These tools are not included with the Oracle Flash Storage System.

## Guided Maintenance

### Guided Maintenance Overview

As a feature of Oracle FS System Manager (GUI), Guided Maintenance presents you with a sequence of dialogs that guides you through the process of replacing

field replaceable units (FRUs) and customer replaceable units (CRUs). Prompt replacement of failed FRUs and CRUs helps maintain system reliability.

Guided Maintenance supports the identification and replacement of FRUs and CRUs for Controllers and Drive Enclosures. Guided Maintenance performs the following functions to help you replace FRUs and CRUs:

- Determines the status of the hardware based on events and diagnostics to accurately reflect the state of the system.
- Identifies the affected Controller or Drive Enclosure. During the identify process, Guided Maintenance issues a command to light the LEDs on the affected chassis.

If you are replacing a component on a Drive Enclosure, the following LEDs flash:

Drive	Flashes the Locate LED on the Drive Enclosure chassis and the Fault LED on the selected drive.
Power cooling module	Flashes the Locate LED on the Drive Enclosure chassis and the Fan Fail LED on the selected power cooling module.
I/O module	Flashes the Locate LED on the Drive Enclosure chassis and the Fault/Locate LED on the selected I/O module.

If you are replacing a component on the Controller, the following LEDs flash:

Energy Storage Module (ESM)	Flashes the Locate LED on the front of the Controller chassis, the Status LED on the back of the Controller chassis, and the Ready to Remove LED on the ESM.
All of the remaining Controller components	Flashes the Locate LED on the Controller chassis and the Status LED on the back of the Controller chassis.

During reverse identify, Guided Maintenance issues a command to light the LEDs on all of the chassis except for the affected chassis.

- Prepares the Oracle FS System for component replacement. For FRUs and CRUs that require you to bring the chassis offline, Guided Maintenance issues commands to redirect activity from a failed component to a redundant component and then brings the chassis offline.
- Displays replacement procedures for the failed FRU or CRU. For hot-serviceable FRUs and CRUs, Guided Maintenance presents a sequence of dialogs with the replacement steps. For FRUs or CRUs that require you to bring the chassis offline, Guided Maintenance provides a link to documentation containing the replacement steps.

**Note:** Only administrator accounts set up with support role privileges can access Guided Maintenance to replace FRUs.

Providing accurate system status and replacing FRUs and CRUs are complex operations that involve many lower level components within the system. The Oracle FS System is designed to be maintained without requiring support from Oracle Customer Support.

Each FRU and CRU has its own diagnostics, which are called by the Pilot to verify that a FRU or CRU is accessible and functioning properly. The diagnostics are primarily used to verify FRUs and CRUs that have been added or replaced. The system also tracks parts that have failed and have been removed to prevent re-insertion of failed components. Diagnostics run automatically when you replace a FRU or CRU.

## Guided Maintenance Replaceable Components

Depending upon the type of component being replaced, Guided Maintenance provides different interfaces to help guide you through the replacement process.

### Controller and Drive Enclosure Replaceable Components

For hot-serviceable Controller and Drive Enclosure components, Guided Maintenance presents a sequence of dialogs with the component replacement instructions. Follow the instructions in Guided Maintenance to replace the following hot-serviceable Controller and Drive Enclosure components:

**Table 7: Hot-serviceable components**

Controller components	Drive Enclosure components
Power supply	<ul style="list-style-type: none"> <li>• Drives</li> <li>• I/O modules</li> <li>• Power cooling modules</li> </ul>

For components that require you to initiate failover and bring the Controller offline, Guided Maintenance provides a link to HTML pages containing the replacement instructions. Follow the instructions in the HTML pages to replace the following components:

- Controller Identification Display
- CPU
- DIMMs
- Energy storage module (ESM)
- ESM backplane
- Fan modules
- HBAs
- Heat sink
- LED Alarm assembly

- Motherboard assembly
- Motherboard cables
- NVDIMMs
- Power distribution board
- Riser

### Pilot Components

Replacing Pilot components requires assistance from Oracle Customer Support. Oracle Customer Support identifies the failed component for you. You then use Guided Maintenance to prepare the Pilots for component replacement. Guided Maintenance provides a link to *Pilot Repair Procedures*. Follow the instructions in *Pilot Repair Procedures* to replace the following Pilot components:

**Table 8: Pilot replaceable components**

Hot serviceable Pilot components	Pilot components that require powering down the Pilot
<ul style="list-style-type: none"> <li>• Fan module</li> <li>• Power supply</li> </ul>	<ul style="list-style-type: none"> <li>• Battery</li> <li>• CPU</li> <li>• DIMMs</li> <li>• Heat sink</li> <li>• Motherboard</li> <li>• Pilot chassis</li> <li>• Pilot disk backplane</li> <li>• Riser</li> <li>• SAS HDD</li> </ul>

### Access Guided Maintenance

Use Oracle FS System Manager (GUI) to access Guided Maintenance.

**Prerequisites:** If you plan to replace a Controller field replaceable unit (FRU), you must sign into the GUI with an administrator account set up with Support role privileges.

#### *Access to Replace a Controller Component (1)*

For the following Controller components, access Guided Maintenance through System > Hardware.

- CPUs
- DIMMs

- Energy Storage Modules (ESMs)
  - Fan modules
  - Motherboard
  - NVDIMMs
  - Power supplies
- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware.
  - 2 Select Controllers.  
The GUI displays the Controllers Overview page. The Controllers Overview pages displays the status of the Controller components.
  - 3 Select the Controller containing the component that is to be replaced.
  - 4 Select Actions > View.  
The View Controller dialog displays the list of replaceable Controller components in the Replaceable Unit list.
  - 5 From the Replaceable Unit list, select the component that you want to replace and click Replace Component.  
Guided Maintenance displays the Introduction page and guides you through the steps to replace the Controller component.

#### *Access to Replace a Controller Component (2)*

For the following Controller components, access Guided Maintenance through Support > System Trouble.

- Customer identification display
  - ESM backplane
  - Heat sink
  - LED alarm assembly
  - Motherboard cables
  - Power distribution board
  - PCIe Riser
- 1 From Oracle FS System Manager (GUI), navigate to Support > System Trouble.
  - 2 Select the Controller that contains the component that is to be replaced.
  - 3 Select Actions > Replace Component.  
Guided Maintenance displays the list of replaceable components for the Controller.  
  
**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.
  - 4 Select a component from the list.

Guided Maintenance displays the Introduction page and guides you through the steps to replace the Controller component.

#### *Access to Replace a Drive Enclosure Component*

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware.
- 2 Select Drive Enclosures.  
The GUI displays the Drive Enclosures Overview page. The Drive Enclosures Overview page displays the status of the Drive Enclosure components.
- 3 Select the Drive Enclosure containing the component that you want to replace.
- 4 Select Actions > View.  
The View Drive Enclosure dialog displays the list of replaceable Drive Enclosure components in the Replaceable Unit list.
- 5 From the Replaceable Unit list, select the component that you want to replace and click Replace Component.  
Guided Maintenance displays the Introduction page, and guides you through the steps to replace the Drive Enclosure component.

#### *Access to Replace a Pilot Component*

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware.
- 2 Select Pilots.  
The GUI displays the Pilots Overview page.
- 3 Select a Pilot.
- 4 Select Actions > Repair Pilot.  
Guided Maintenance displays the Pilot Repair page and guides you through the steps to replace a Pilot component.

# Oracle FS1–2 Global Procedures and Rail Kit Installation

## Component Placement

Oracle recommends the following rack unit (RU) locations for installing the components in the rack:

**Table 9: Default component placement in racks**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 18
Drive Enclosures	RU 1 to RU 20	RU 1 to RU 18
Pilot-1	RU 21	RU 19
Pilot-2	RU 22	RU 20
Controller-1	RU 23, RU 24	RU 21, RU 22
Controller-2	RU 25, RU 26	RU 23, RU 24
Remaining Drive Enclosures	RU 27 to RU 42	RU 25 to RU 28 (next DE2-24C DE) RU 29 to RU 42

If the Oracle FS System includes one Replication Engine, then follow the placement shown in the following table:

**Table 10: Component placement with one Replication Engine**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 16
Drive Enclosures	RU 1 to RU 18	RU 1 to RU 16
Replication Engine-1	RU 19, RU 20	RU 17, RU 18
Pilot-0	RU 21	RU19
Pilot-1	RU 22	RU20
Controller-1	RU 23, RU 24	RU 21, RU22

**Table 10: Component placement with one Replication Engine (continued)**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 16
Controller-2	RU 25, RU 26	RU 23, RU 24
Remaining Drive Enclosures	RU 27 to RU 42	RU 25 to RU 28 (next DE2-24C DE) RU 29 to RU 42

If the Oracle FS System includes two Replication Engines, then follow the placement shown in the following table:

**Table 11: Component placement with two Replication Engines**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 14
Drive Enclosures	RU 1 to RU 16	RU1 to RU14
Replication Engine-2	RU 17, RU18	RU 15, RU 16
Replication Engine-1	RU 19, RU 20	RU 17, RU18
Pilot-0	RU 21	RU 19
Pilot-1	RU 22	RU 20
Controller-1	RU 23, RU 24	RU 21, RU 22
Controller-2	RU 25, RU 26	RU 23, RU 24
Remaining Drive Enclosures	RU 27 to RU 42	RU 25 to RU 28 (next DE2-24C DE) RU 29 to RU 42

If the Oracle FS System includes three Replication Engines, then follow the placement shown in the following table:

**Table 12: Component placement with three Replication Engines**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 12
Drive Enclosures	RU 1 to RU 14	RU 1 to RU 12
Replication Engine-3	RU 15, RU 16	RU 13, RU14
Replication Engine-2	RU 17, RU 18	RU 15, RU 16
Replication Engine-1	RU 19, RU 20	RU 17, RU 18
Pilot-0	RU 21	RU 19
Pilot-1	RU 22	RU 20
Controller-1	RU 23, RU 24	RU 21, RU 22

**Table 12: Component placement with three Replication Engines (continued)**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 12
Controller-2	RU 25, RU 26	RU 23, RU 24
Remaining Drive Enclosures	RU 27 to RU 42	RU 25 to RU 28 (next DE2-24C DE) RU 29 to RU 42

If the Oracle FS System includes four Replication Engines, then follow the placement shown in the following table:

**Table 13: Component placement with four Replication Engines**

Component type	RU space for installation	RU space if a DE2-24C DE follows RU 10
Drive Enclosures	RU 1 to RU 12	RU1 to RU10
Replication Engine-4	RU 13, RU 14	RU 11, RU 12
Replication Engine-3	RU 15, RU 16	RU 13, RU 14
Replication Engine-2	RU 17, RU 18	RU 15, RU 16
Replication Engine-1	RU 19, RU 20	RU 17, RU 18
Pilot-0	RU 21	RU 19
Pilot-1	RU 22	RU 20
Controller-1	RU 23, RU 24	RU 21, RU 22
Controller-2	RU 25, RU 26	RU 23, RU 24
Remaining Drive Enclosures	RU 27 to RU 42	RU 25 to RU 28 (next DE2-24C DE) RU 29 to RU 42

## Component Numbering

Oracle FS Systems support two Pilots (Pilot-1 and Pilot-2). Additionally, Oracle FS Systems support two Controllers (Controller-1 and Controller-2) and 1 to 30 Drive Enclosures (DE-1 to DE-30).

The chassis ID number of the Drive Enclosure is based on the order by which the Controller identifies the Drive Enclosures. Drive Enclosures are also assigned a chassis ID number in the Oracle FS System Manager GUI that is labeled Enclosure Chassis ID. The chassis ID number can be changed using the GUI. The chassis ID number displayed on the chassis must always match the Enclosure Chassis ID displayed on the GUI.

**Tip:** The Drive Enclosure sticker on the back of the chassis must be removed once the Drive Enclosure is installed in the rack because the seven segment display is now the preferred method to identify the Drive Enclosure.

**Tip:** The chassis ID in the Drive Enclosure identification display always matches the ID shown in the GUI. Drive Enclosures are identified by the serial number and the World Wide Name (WWN). Sometimes, the physical order in which the Drive Enclosures are stacked and cabled in might differ from the cabling order recommended in this document. If the Drive Enclosures appear out of order (not, 1 through 30 in sequence bottom up), then the customer can change it through the GUI. But the GUI and the identification display on the chassis must always match.

The Pilots, Controllers, and the Replication Engines must also be numbered sequentially from the bottom to the top of the rack. Refer to the following example for more information on component numbering of the rack-ready Oracle FS Systems.

The chassis ID numbers on the Controllers can also be manually changed from the GUI.

**Figure 10: Component numbering in Oracle FS Systems**

RU	Component	RU	Component
42		42	
41	4U DE (12)	41	4U DE (14)
40			
39			
38			
37	4U DE (11)	37	4U DE (13)
36			
35			
34			
33	4U DE (10)	33	4U DE (12)
32			
31			
30			
29	4U DE (09)	29	4U DE (11)
28			
27			
26			
25	Controller Node 2	26	Controller Node 2
24	Controller Node 1	25	Controller Node 1
23			
22	Pilot Node 2	24	Pilot Node 2
21	Pilot Node 1	23	Pilot Node 1
20	Replication Appliance 2	22	Replication Appliance 2
19			
18	Replication Appliance 1	21	Replication Appliance 1
17			
16	2U DE (08)	20	2U DE (10)
15	2U DE (07)	19	2U DE (09)
14			
13	2U DE (06)	18	2U DE (08)
12			
11	2U DE (05)	17	2U DE (07)
10			
9	2U DE (04)	16	2U DE (06)
8			
7	2U DE (03)	15	2U DE (05)
6			
5	2U DE (02)	14	2U DE (04)
4			
3	2U DE (01)	13	2U DE (03)
2			
1		12	2U DE (02)
		11	
		10	2U DE (01)
		9	
		8	
		7	
		6	
		5	
		4	
		3	
		2	
		1	

**Note:** The above example shows eight DE2–24P Drive Enclosures (2 RU), four DE2–24C Drive Enclosures (4 RU), and two Replication Engines.

## Oracle FS System Rack Hardware Specifications

An Oracle FS System can contain a combination of:

- Two Pilot nodes; each node is a 1U Oracle server.
- Two Controllers
- One to 30 Drive Enclosures.
- Two power distribution units (PDUs) built into the rack.
- Replication Engines (optional)

**Note:** Two racks are required to install 30 Drive Enclosures

Customer supplied racks into which you install the Oracle FS1 Flash Storage System components must meet the requirements listed in the following table:

**Table 14: Rack specifications for an Oracle FS System**

Item	Requirement
Structure	<p>Four-post rack (mounting at both front and rear).</p> <p>Supported rack types:</p> <ul style="list-style-type: none"> <li>• square hole (9.5 mm)</li> <li>• round hole (M6 or 1/4-20 threaded only)</li> </ul> <p><b>Note:</b> Two-post racks are not compatible.</p>
Rack horizontal opening and unit vertical pitch	Conforms to ANSI/EIA 310-D-1992 or IEC 60927 standards.
Distance between front and rear mounting planes	<ul style="list-style-type: none"> <li>• Minimum 24 in (610 mm)</li> <li>• Maximum 36 in (915 mm)</li> </ul>
Clearance depth in front of front mounting plane	<p>Minimum distance to rear cabinet door:</p> <ul style="list-style-type: none"> <li>• 35.43 in (900 mm) with the CMA</li> <li>• 31.49 in (800 mm) without the CMA</li> </ul> <p><b>Note:</b> CMAs are required for Pilots, Controllers, and Replication Engines.</p>

**Table 14: Rack specifications for an Oracle FS System (continued)**


Item	Requirement
Clearance width between front and rear mounting planes	Minimum distance between structural supports and cable troughs is 18 in (456 mm).
Minimum clearance for service access	Clearance (front): 48.5 in (123.2 cm) Clearance (back): 36 in (91 cm)
Front door	<ul style="list-style-type: none"> <li>• Vented</li> <li>• 1.5 in (3.81 cm) deep</li> <li>• Lockable</li> <li>• Open left to right</li> <li>• 1 in (2.54 cm) clearance between front vertical channel and inside of frame</li> </ul>
Rear door	<ul style="list-style-type: none"> <li>• Vented</li> <li>• Lockable</li> <li>• Open left to right</li> </ul>
Sides	<ul style="list-style-type: none"> <li>• Solid</li> <li>• Removable</li> <li>• Lockable</li> <li>• 1 inches (2.54 centimeters) between side and frame</li> </ul>
Vertical channels	<ul style="list-style-type: none"> <li>• 19 in side to side</li> <li>• 26 in front rail to back rail</li> </ul>
Vents	<ul style="list-style-type: none"> <li>• Front and back doors</li> <li>• Top</li> </ul>
PDU	<ul style="list-style-type: none"> <li>• 2 PDUs</li> <li>• 90–240VAC, 50–60Hz</li> <li>• 10kVA for single-phase PDUs; 15 kVA for three-phase PDUs</li> <li>• 42 outlets (six groups of seven outlets each)</li> <li>• Vertical mount</li> </ul>

**Table 14: Rack specifications for an Oracle FS System (continued)**

Item	Requirement
Heat dissipation	<ul style="list-style-type: none"> <li>Oracle FS System: 28,500 BTU/hr</li> </ul>
Loaded weight	<ul style="list-style-type: none"> <li>Oracle FS System: 1535.7 lb (696.6 kg)</li> </ul>

The center of gravity of a populated Oracle FS System rack is toward the front. The threshold tilt angle depends on whether the front or back of the rack faces down the slope:

- Front faces downward: 12° maximum slope.
- Back faces downward: 24° maximum slope.

**Figure 11: Maximum tilt angles for stationary Oracle FS System racks**

Legend 1 42U rack

2 Oracle FS system components

3 Cabling aperture

4 Ramp

## Prepare the Rack

Not-racked systems require preparation of the rack prior to component installation and cabling into the rack. Refer to the vendor's rack documentation for detailed information on unpacking the rack, positioning the rack, and stabilizing the rack.


To create a bay of racks, first remove the adjacent (inner) side panels from each rack and move the racks into position. You must route the cables directly from one rack to the other through the open sides of the racks because the cables are not long enough to route through a raised floor.

## Remove the Doors From a Rack

Remove the rack doors to make the placement of the components easier.

- 1 If locked, unlock the front and back doors of the rack.
- 2 Release all door hinges, as well as any grounding straps.

**Figure 12: Rack door removal**



Legend	1 Ground strap
	2 Rack door hinge

**Note:** This is an example of removing the doors from a rack. Your rack may differ from the illustration. Consult the rack vendor's documentation for details on removing doors and ground straps.

- 3 Remove the doors and set them aside.

**Note:** Use care to place the doors where they cannot fall on people or slide and cause injury.

**Important:** After installing an Oracle FS System, shut all the doors, re-attach the ground straps to maintain compliance with applicable emissions requirements.

## Remove a Side Panel From a Rack

You might be required to remove the rack side panels to have sufficient space to perform service actions such as replace components or cable Drive Enclosures. Consult the rack vendor's documentation for details on how to remove the side panels.

**Important:** Be sure not to pinch any cables that might have strayed from their proper location.

## Rack Installation Safety Precautions

Follow these safety precautions when installing the components in the rack.

**CAUTION:** If non-Oracle FS System equipment must be installed in the rack, additional care must be taken to ensure that this equipment does not cause overheating of the Oracle FS System components or block air flow. All Oracle FS System components meet these requirements, but **ONLY** if the installation and rack position guidelines are carefully followed.

**CAUTION:** Always load components into a rack from the bottom to the top so that the rack does not become top-heavy and tip over.

**CAUTION:** Avoid elevated operating ambient temperature. If the component is installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment might be greater than room ambient temperature. Therefore, make sure that the environment is compatible with the maximum ambient temperature (TMA) specified for the component.

**CAUTION:** Make sure that there is sufficient amount of airflow required for safe operation of each component.

**CAUTION:** Mounting of a component in the rack should be such that a hazardous condition is not created due to uneven mechanical loading.

**CAUTION:** Consideration should be given to the connection of a component to the supply circuit and the effect that overloading of the circuits might have on over-current protection and supply wiring. Appropriate consideration of component nameplate power ratings should be used when addressing this concern.

**CAUTION:** Reliable grounding of rack-mounted equipment should be maintained. Particular attention should be given to supply connections other than direct connections to the branch circuit (for example, use of power strips).

**CAUTION:** Do not use slide-rail mounted equipment as a shelf.

## System-Wide Procedures

### Data Backups

Regular backups are prudent IT practice. When you service hardware components that directly affect user data paths, we highly recommend that you first back up all user data to external media.

**Important:** Extraordinary system hardware changes (such as replacing a Controller) and software configuration changes (such as resetting the system to a factory-fresh state) and all other modifications not specifically mentioned in this document should only be attempted after consultation with Oracle Customer Support. A backup of data should always be done prior to all but routine maintenance actions.

Full system backups to external media must be performed when you want to perform any of the following actions:

- Remove a Drive Enclosure permanently from the Oracle FS System.

**Note:** You need not always perform a complete data backup to remove Drive Enclosures from an Oracle FS System. However, prior to removal make sure that all necessary resources have been migrated from the Drive Enclosure and the system configuration is not located on the Drive Enclosure. For more information, contact Oracle Customer Support.

- Clear the system configuration. This action removes all user and system data.

**CAUTION:** Before you clear the system configuration, consult with Oracle Customer Support to avoid the risk of losing system configuration data.

To back up the system, refer to the documentation for your backup application.

## Power Cycling

Contact Oracle Customer Support before power cycling an Oracle FS System except in the event of an emergency, in which case, drop all power and then contact Oracle Customer Support.

Contact Oracle Customer Support before touching any power cables or switches. There are some situations where not power cycling the entire system is the correct action.

For failure testing, do not power cycle individual components without first contacting Oracle Customer Support.


## Controller Rails

Adding Controllers in the rack requires you to install rack rails in the rack and slide rails on the chassis for each Controller that you plan to add.

Controller rail kits can be installed in the Sun™ Rack 900, the Sun Rack 1000, and third-party ANSI/EIA 310-D-1992 or IEC 60927 compliant racks with the following types of holes:

- Square
- Round
- Threaded

**Figure 13: Examples of supported rack holes**



Legend	1 Square holes
	2 Round holes
	3 Threaded holes

**CAUTION:** Oracle recommends that you install each Controller after you install the rail kit before installing the next combination of rail kit and Controller. Installing all of the rail kits and then inserting the Controllers is not always possible because of potential space limitations at some data centers. Also, you run the risk of not placing the Controllers in the correct rack position and causing possible cabling issues.

**Note:** Controller rails are packaged within the Pilot shipping carton (not the Controller shipping carton). Ensure that the Controller rails are not misplaced during unpacking.

### Related Links

[Controller Rail Kits](#)

## Controller Rail Kits

The Controller rail kit contains the following items:

- One slide rail that attaches to the rack posts
- One mounting bracket that attaches to the Controller chassis
- CMA with six pre-installed cable clips
- Package of mounting screws and nuts in assorted sizes to fit various types of racks and cabinets
- Manufacturer's instruction sheet for the CMA

The following table summarizes the mounting hardware packaged with the Controller rail kits.

**Table 15: Controller rail kit mounting screws**

Contents of the mounting screw packet	Quantity	Usage
10-32 pan head screw	8	Assemble main and extender sections of left and right rails (Typically, left and right rails are shipped pre-assembled)
8-32 pan head screw	4	Mount left and right rails to front of cabinet rails

**Table 15: Controller rail kit mounting screws (continued)**

Contents of the mounting screw packet	Quantity	Usage
Metric M6 pan head screw	8	<ul style="list-style-type: none"> <li>Mount left and right rails to back of cabinet rails</li> <li>Secure front of chassis to left and right cabinet rails</li> </ul>
6–32 flat head screw	2	Secure back of chassis to left and right side rails

**Tip:** Ensure that you have all of the parts in the Controller rail kit before you begin the installation of the Controller rails on the rack and the Controller chassis.

**Note:** To locate part numbers for the rail kits, open [Oracle System Handbook](https://support.oracle.com/handbook_private/index.html) ([https://support.oracle.com/handbook\\_private/index.html](https://support.oracle.com/handbook_private/index.html)) and go to the Oracle FS1 Flash Storage System components list. Part numbers are listed in the components list.

### Related Links

[Controller Rails](#)


## Install the Rack Rails for the Controller

Prior to adding Controllers, install rails into the rack for each Controller that you plan to add.

- Prerequisites:
- Ensure that you have adequate room to work around the rack while installing the rails and the Controller.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
  - If you are installing the rails in a rack with threaded holes, make sure you have a Torx Number 20 screwdriver.

- Mark the rack mount hole where you plan to mount the Controller. The Controller requires two standard rack units (2U) of vertical space.
- Remove the rails from the packaging.
- Position the front of the left rail behind the left front rack rail.

Figure 14: Controller rack mount location




Legend	1 Rack mount holes
	2 Left rail

- 4 Use a Phillips Number 2 screwdriver to insert and tighten two 8-32 panhead screws to secure the left rail to the front of the rack.

**Note:** Each Controller requires two standard mounting units (2U) of vertical space in the rack. Each standard mounting unit (U) has three mounting holes in the left and right rack rails.

**Note:** Insert the screws into the lowest holes in the top two mounting units of the 2U slot in which the chassis is to be mounted. These screws pass through the rack rail holes and screw into threaded holes in the left rail.

**Figure 15: Left rail secured to the front of the rack**


Legend 1 Rack

2 8-32 screws to secure left rail to rack

3 Left rail

- 5 Repeat the above two steps for the right rail.
- 6 At the back of the rack, adjust the length of the left rail as needed to fit the rack, and position the rail flange over the face of the rack rail.

Figure 16: Left rail adjusted at the back of the rack




Legend	1 Back of the rack
	2 Left rail

- 7 Align the rail flange so that the mounting holes correspond to those at the front of the rack.
- 8 Use a Phillips screwdriver to insert and tighten four metric M6 screws (two on each side) at the back of the rail.
- 9 Repeat the above three steps for the right rail.
- 10 Using a Phillips Number 2 screwdriver, tighten the eight 10-32 panhead adjustment screws (four on each side) toward the back of each rail.

### Install the Slide Rails for the Controller

- 1 Extend the mounting brackets completely out of their respective slide rails.


**Tip:** To extend the mounting brackets out of the slide rails, simultaneously press and hold the upper and lower lock buttons of the slide rail lock. Then, pull the mounting bracket out until it locks in the extended position.

**Figure 17: Slide rail assembly unlocked**

Legend 1 Slide rail assembly

2 Slide rail lock button


- 2 Slide the mounting bracket release button, and then slide the mounting bracket out of the slide rail.

**Figure 18: Mounting bracket release button**

Legend 1 Slide rail

2 Mounting bracket release button


3 Mounting bracket
--------------------

**Figure 19: Slide rail middle section unlocked**

Legend	1 Slide rail
	2 Metal lever

**Tip:** Press the metal lever on the middle section of the slide rail to unlock the slide rail, and then push the middle section back into the rack.

- 3 Attach a mounting bracket to the right side of the Controller chassis.

**Figure 20: Mounting bracket attached to the chassis**

Legend	1 Mounting bracket
	2 Controller chassis

**Tip:** Position the mounting bracket against the Controller chassis so that the mounting bracket are aligned with screw holes and then install the screws.

- 4 Attach the second mounting bracket to the left side of the Controller chassis.
- 5 Determine which rack hole numbers to use when attaching the slide rails to the rack posts.


**Note:** The Controller is two rack units tall (2U). The slide rails will occupy the lower half of the 2U space.

- 6 Determine which screws you will use to mount the slide rails.

**Tip:** If your rack has threaded mounting holes in the rack posts, determine whether the threads are metric or standard. Select the appropriate screws from the package included in the mounting kit. If your rack does not have threaded mounting holes, the mounting screws are secured with a caged nut.

- 7 Attach a slide rail to the right front rack post.

**Figure 21: Slide rail mounted on the rack post**



Legend	1 Rack post
	2 Slide rail


**Tip:** Loosely attach the front of a slide rail to the right front rack post using two screws but do not tighten the screws yet. Adjust the length of the slide rail by sliding the back mounting flange to reach the outside edge of the back rack post. Loosely attach the back of the slide rail to the back rack post with two screws.

- 8 Attach the second slide rail to the left rack posts in a similar manner.

**Tip:** Do not tighten the screws.

- 9 Use the slide rail spacing tool to adjust the distance between the slide rails.

**Figure 22: Slide rail spacing tool**



Legend	1 Spacing tool
	2 Slide rails


**Tip:** At the front of the rack, plug the left side of the tool into slots at the end of the left rail. Insert the right side of the tool into the front end of the right rail, while sliding the end of the rail to the right or left as needed to allow the ends of the tool to enter the ends of both rails. The distance between the rails is now equal to the width of the Controller with mounting brackets.

- 10 Tighten the screws to lock the front ends of the rails in place.  
 11 Repeat the steps for the back ends of the rails.  
 12 Deploy the anti-tilt mechanism on the rack, if any.

**CAUTION:** The weight of the Controller on extended slide rails can be enough to overturn a rack.

- 13 Insert the ends of the mounting brackets into the sliding rails.

Figure 23: Controller chassis mounted on the slide rails



Legend	1 Slide rails
	2 Controller chassis
	3 Mounting brackets

**CAUTION:** Work with a partner or use a mechanical lift for assistance. The Controller weighs approximately 70 lbs (31.75 kg). Two people are required to carry the chassis.

- 14 Simultaneously release the rail locks on each side of the sliding rails, and guide the Controller chassis into the rack.

**CAUTION:** Verify that the Controller is securely mounted in the rack, and that the slide rails are locked to the mounting brackets, before continuing.


## Install the Controller CMA

The cable management arm (CMA) clips into the ends of the left and right Controller slide rail assemblies. No screws are necessary for mounting the CMA. The right sides of the two CMA arms have hinged extensions. On the manufacturer's instruction sheet, the smaller extension is called the CMA Connector for Inner Member. It attaches to the right mounting bracket. The larger extension is called the CMA Connector for Outer Member, and attaches to the right sliding rail.

**Note:** The CMA shown in the graphics might vary slightly from the CMA shipped with your product.

- 1 At the back of the rack, plug the CMA rail extension into the end of the left slide rail assembly.

Figure 24: CMA rail extension inserted into the back of the left slide rail




Legend 1 CMA rail extension

2 Slide rail


**CAUTION:** Support the CMA during this installation. Do not allow the assembly to hang by its own weight until it is secured by all three attachment points.

- 2 Insert the smaller extension into the clip located at the end of the mounting bracket.

**Figure 25: Inner CMA connector mounted**

Legend	1 Slide rail
	2 Inner CMA connector
	3 Clip

- 3 Insert the outer CMA connector into the end of the right sliding rail.


**Figure 26: Outer CMA connector attached**

Legend	1 Outer CMA connector
--------	-----------------------

2 Slide rail
--------------

- 4 Fully insert the hinged plastic connector at the left side of the CMA into the CMA rail extension.

**Figure 27: Left side of the slide rail mounted**



Legend	1 Plastic tab on CMA rail extension
	2 Slide rail

## Insert the Controller Into a Rack

**Prerequisites:** Ensure that you have a magnetic-tipped Phillips Number 2 screwdriver with at least a four-inch shank.

**CAUTION:** Do not power on the Controller until all components have been installed and all internal private management interface (PMI) and private interconnect (PI) cables have been connected.

**CAUTION:** Work with a partner or use a mechanical lift for assistance. The Controller weighs approximately 41 lbs (18.59 kg). Two people are required to unmount and carry the chassis.

**CAUTION:** Deploy any rack anti-tilt mechanisms before installing the Controller into the rack to prevent the rack from tipping over during component installation.

**CAUTION:** Always load equipment into a rack from the bottom up so that the rack will not become top-heavy and tip over.

**CAUTION:** Slide-rail-mounted components are not to be used as a shelf or a work space.

**CAUTION:** Elevated operating ambient temperature: If the Controller is installed in a closed or multi-unit rack assembly, the operating ambient temperature of the rack environment might be greater than room ambient temperature. Therefore, consideration should be given to installing the components in an environment compatible with the maximum ambient temperature (TMA) specified for the Controller.

- 1 Using two people, one at each side of the Controller, carefully lift and position the Controller on the bottom ledge of the left and right rails.

**CAUTION:** Do not use the power supply handles to lift the chassis. Using the power supply handles to lift the chassis can damage the power supplies and disrupt electrical power to the Controller.

- 2 Carefully slide the Controller into the rack until the front flanges of the Controller touch the vertical face of the rack.
- 3 Use a Phillips screwdriver to install and tighten the four M6 panhead screws (two on each side) to secure the chassis to the front of the rack.
- 4 Install and tighten two 6-32 screws (one on each side) at the back of the chassis, to secure the back of the chassis to the rack.


## Verify Operation of the Slide Rails and the CMA

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Two people are needed to verify the operation of the slide rails and the cable management arm (CMA): one to move the Controller in and out of the rack and one to observe the cables and CMA.
  - To reduce the risk of personal injury, stabilize the expansion rack cabinet and extend all anti-tilt devices before extending the Controller from the rack.

**CAUTION:** Work with a partner or use a mechanical lift for assistance. The Controller weighs approximately 41 lbs (18.59 kg). Two people are required to unmount and carry the chassis.

- 1 Unlock the slide lock buttons at the right and left sides of the Controller chassis, and slowly pull the Controller out of the rack until the slide rails reach their stops.


Figure 28: Controller slide rails unlocked



Legend	1 Slide rail assembly
	2 Slide rail lock button

- 2 Inspect the attached cables for any binding or kinks.
- 3 Verify that the CMA extends fully and does not bind in the slide rails.
- 4 When the Controller is fully extended out, release the mounting bracket release button.

Figure 29: Mounting bracket release button




Legend	1 Slide rail
--------	--------------

2 Mounting bracket release button
3 Mounting bracket

- 5 Slide the Controller back into the rack.
- 6 Simultaneously unlock both slide rail release buttons, and push the Controller completely into the rack.

**Figure 30: Slide rail release button**



Legend	1 Slide rail release button
	2 Slide rail

**Note:** The Controller should stop after approximately 15 inches (40 cm) of travel.

- 7 Verify that the cables and the CMA retracted without binding.
- 8 Adjust the cable hangers and CMA as required.

## Drive Enclosure Rails

To prepare a rack for adding Drive Enclosures to the Oracle Flash Storage System, you must install rails in the rack for each Drive Enclosure that you plan to add. Oracle includes rail kits in the Drive Enclosure packaging.

Use one of the following racks for the Drive Enclosure:


- Sun Rack II 1042/1242 rack
- Any 19-inch wide, four-post, EIA-compatible rack with a front-to-back depth between vertical cabinet rails of 24 inches to 36 inches (61 cm to 91 cm)

Drive Enclosures rail kits can be installed in racks with the following types of holes:

- Square
- Round
- Threaded (must be M6 or 10-32 racks)

The following figure shows examples of supported rack holes.


**Figure 31: Examples of supported rack holes**



Legend	1 Square holes	3 Threaded holes
	2 Round holes	

The following figures show the rails for both Drive Enclosure types.


Figure 32: Rails for the DE2-24P Drive Enclosure



Legend 1 Left-side rail for square-hole and round-hole racks

2 Adaptor pins for threaded-hole racks

Figure 33: Rails for the DE2-24C Drive Enclosure



Legend	1 Left-side rail for square-hole racks	3 Round-hole racks
	2 Threaded-hole racks	

#### Related Links

[Install Drive Enclosure Rails](#)

[Drive Enclosure Rail Kits](#)

#### Drive Enclosure Rail Kits

The following table summarizes the contents of the Drive Enclosure rail kits.

**Table 16: Drive Enclosure rail kits**

Type of Drive Enclosure	Contents
DE2-24P Drive Enclosure	2 Phillips Number 2 pan head screws with patch lock 2 Phillips hex flange head screws (11mm) 1 Left-hand rail assembly 1 Right-hand rail assembly 4 Phillips Number 2 ACR hex flange screws 1 10mm wrench 8 Threaded rack adaptor pegs 1 Threaded rack adaptor kit label 4 Phillips hex flange screws (13mm)
DE2-24C Drive Enclosure	2 Phillips Number 2 pan head screws with patch lock (M5 x 16) 1 Left-hand rail assembly 2 Phillips hex flange head screws (11mm) 1 Right-hand rail assembly 2 Cage nuts 4 Orange service screw labels 2 Clip nuts 8 Special screws for round hole rack 1 Tardis rail kit user label 2 Phillips Number 2 pan head screws with patch lock (M5 x 6) 4 Phillips hex flange head screws (13mm) 4 Phillips Number 2 ACR hex flange head screws

To locate part numbers for the rail kits, open [Oracle System Handbook](https://support.oracle.com/handbook_private/index.html) (https://support.oracle.com/handbook\_private/index.html) and go to the Oracle FS1 Flash Storage System components list. Part numbers are listed in the components list.

### Related Links

[Drive Enclosure Rails](#)

[Install Drive Enclosure Rails](#)

## Install Drive Enclosure Rails

Prior to adding Drive Enclosures, install rails into the rack for each Drive Enclosure that you plan to add.

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
  - If you are installing the rails in a rack with threaded holes, make sure you have a Torx Number 20 screwdriver.
  - Ensure that you have a flashlight to use when verifying that the Drive Enclosure is seated in the rack.

### Related Links

[Drive Enclosure Rail Kits](#)

## Install Rails for DE2-24P Drive Enclosures

The rails for the DE2-24P Drive Enclosure are preassembled with rail-location pegs on the front and back for installation in a square hole rack and a round hole rack. If you install the rails in a threaded, universal 19-inch rack, you must replace the rail-location pegs with adaptor pins before installing the rails in the rack.


**Note:** To simplify the following procedures, install the left-side rail assembly first and then the right-side rail assembly.

### *Install Rails in Threaded Racks*

- 1 Use a Torx Number 20 screwdriver to remove the rail-location pegs from the front and back of the rails.
- 2 Use a 10mm wrench to insert the adaptor pins into the ends of the rails where you removed the rail-location pegs.

A 10mm wrench and adaptor pins are included in the rail kit packaging.


Figure 34: 10mm wrench and adaptor pins



Legend	1 10mm wrench	2 Adaptor pins
--------	---------------	----------------


- 3 Position the front of the rails inside of the rack, with the rail flange inside of the rack flange.  
The rail label faces the inside of the rack. The pins should be fully located within the rack holes.

Figure 35: Rack flange, rail flange, and rail label (front)



Legend 1 Rack flange	2 Rail flange and label
----------------------	-------------------------

- 4 Insert and loosely tighten one screw through the front of the rack and into the top hole in the rails.
- 5 Adjust the rail lengths and locate the back pins inside the corresponding back rack holes.
- 6 Insert and loosely tighten one screw through the back of the rack and into the back of the rails.


**Figure 36: Back-mounting screw**

### *Install Rails in Square or Round Hole Racks*

- 1 Locate the appropriate rack unit (RU) height.  
The DE2-24P Drive Enclosure requires two standard mounting units (2U) of vertical space in the rack.
- 2 Remove the rails from the Drive Enclosure packaging.
- 3 Position the front rail-location pegs fully inside the holes in the front rack posts where you plan to add a Drive Enclosure.

Make sure the rail label faces the inside of the rack. Align the rail flange inside of the rack flange. Position the rail-location pegs fully within the rack holes.


Figure 37: Front of the rack and rail-location pegs



Legend	1 Rail-location pegs	2 Front rack post
--------	----------------------	-------------------

- 4 Insert and tighten one Phillips 13mm head hex flange screw through the front rack hole and into the top hole of the rail.

Figure 38: A Phillips 13mm head hex flange screw and the front of a rack




Legend	1 Phillips 13mm head hex flange screw	2 Rail-location pegs
--------	---------------------------------------	----------------------

- From the back of the rack, position the pegs fully into the corresponding rack holes.

To position the pegs, extend the length of the rail to the back of the rack and position the pegs through the appropriate rack holes.


Figure 39: Extended rail to the back of the rack



Legend	1 Back of the rack
--------	--------------------

- 6 Insert and tighten one Phillips 13mm head hex flange screw into the back of the rack and into the rail.

**Figure 40: A Phillips 13mm head hex flange screw and the back of a rack**



- 7 Repeat steps 1-6 to install the right-hand rail assembly.


### Install Rails for DE2-24C Drive Enclosures

- 1 Locate the appropriate rack unit (RU) height.  
The DE2-24C Drive Enclosure requires four standard rack units (4U) of vertical space.
- 2 Remove the rails from the Drive Enclosure packaging.
- 3 If you are installing rails in a square-hole rack, snap one cage nut into the eighth rack hole on both sides of the rack.

To locate the eighth rack hole, count eight holes upward from the bottom rail location peg.

The following figure shows a cage nut installed in a square-hole rack.

Figure 41: Cage nut installed in a square-hole rack



Legend	1 Rail-location pegs	2 Cage nut
--------	----------------------	------------


4 Prepare the screws in each rail end.

Square-hole racks No preparation is required.

Round-hole racks Remove the two rail-location pegs from each rail end and replace them with the special screws from the rail kit. The special screws are part number 0093340-02.

Threaded-hole rack Remove the two rail-location pegs from each rail end and replace them in the opposite direction from inside of the rail flange. Remove and discard the clip nut from the front rail.

Figure 42: Rail-location pegs from inside of the rail flange and the clip nut



Legend	1 Rail location pegs from inside of the rail flange	2 Clip nut
--------	---	------------

5 Position the front of the rails inside of the rack.

Make sure the rail flange aligns with the inside of the rack flange and the rail label faces the inside of the rack.


Square-hole racks The rail-location pegs fit inside of the rack holes.

Round-hole rack The special screws fit inside of the rack holes.

Threaded-hole rack The rail-location pegs fit inside of the rack holes.


The following figure shows an example of the rail-location pegs inserted into a square-hole rack.

**Figure 43: Rail-location pegs and a square-hole rack**




Legend	1 Rail-location pegs	2 Cage nut
--------	----------------------	------------

6 Extend the rail length towards the back of the rack and into the rail holes at the back of the rack.

**Figure 44: Rail extended to holes in the back of the rack**

- 7 Insert and fully tighten one Phillips 13mm head hex flange screw through the back of the rack and into the rail.
- 8 Tighten the two locking screws in the side of the rail.

**Figure 45: The locking screws and side of the rail**

- 9 Repeat steps 1 - 8 to install the right-hand rail assembly.

## Insert a DE2-24P Drive Enclosure Into a Rack

- 1 With the help of a partner or mechanical lift, carefully lift the Drive Enclosure to the location of the prepared slot and rest the Drive Enclosure on the bottom ledge of the left and right rails.

**CAUTION:** The Drive Enclosures are heavy. Work with a partner or use a mechanical lift for assistance. The DE2-24C Drive Enclosure weighs approximately 102 lbs (46 kg) and the DE2-24P Drive Enclosure weighs approximately 53 lbs (24 kg). Be careful not to drop a Drive Enclosure. Dropping a Drive Enclosure can cause damage and can reduce the life of the drives.


**CAUTION:** Do not use the power supply handles to lift the chassis. Using the power supply handles to lift the chassis can damage the power cooling modules and disrupt electrical power to the Drive Enclosure.

Figure 46: DE2-24P Drive Enclosure (left) and DE2-24C Drive Enclosure (right)



- 2 Angle the Drive Enclosure slightly to the left and align the Drive Enclosure's left side slider so that it engages with the left rail channel.

Figure 47: Left rail channel



---


Legend 1 Left rail channel

- 3 Slightly tug the Drive Enclosure to the right and align the Drive Enclosure's right side slider so that it engages with the right rail channel.
- 4 Apply even pressure to both sides of the Drive Enclosure and carefully slide the Drive Enclosure into the rails.

**Important:** The Drive Enclosure must be fully seated in the rack. To verify that the Drive Enclosure is fully seated, check for the following:

- Using a flashlight, visually check to see that the sliders on both sides of the Drive Enclosure are in the rail channels on both sides of the rack. If the Drive Enclosure side sliders are not in the rail channels, then the Drive Enclosure is not seated. You must reinsert the Drive Enclosure.
  - Ensure that the Drive Enclosure slides smoothly into the rack and out of the rack. If the Drive Enclosure does not slide smoothly in and out of the rack, then the Drive Enclosure is not seated. You must reinsert the Drive Enclosure.
  - Ensure that the screw hole at the back of the Drive Enclosure aligns with the screw hole on the rail. Do not secure the screw, yet. If the screw hole at the back of the Drive Enclosure does not align with the screw hole on the rail, then the Drive Enclosure is not seated. You must reinsert the Drive Enclosure.
- 5 On both sides of the Drive Enclosure, insert a Phillips Number 2 pan head screw with patch lock through the hole at the back of the Drive Enclosure and secure it into the screw hole on the rail.

Figure 48: Back of the Drive Enclosure and Rail secured




Legend	1 Phillips Number 2 pan head screw with patch lock	2 Back of the Drive Enclosure
--------	--	-------------------------------

**Important:** If you insert the screw through the hole at the back of the Drive Enclosure and the screw does not align with the screw hole on the rail, then the Drive Enclosure is not seated. You must reinstall the Drive Enclosure.

- 6 Remove the front-side caps on both sides of the Drive Enclosure and secure a Phillips 13mm head hex flange screw.

**Note:** The front-side cap on the right side of the Drive Enclosure contains the RFID tag, which uniquely identifies the Drive Enclosure. Take care not to mix up the right front-side caps among Drive Enclosures.

Figure 49: Left front-side cap and Phillips 13mm head hex flange screw



Legend	1 Phillips 13mm head hex flange screw	2 Left front-side cap
--------	---------------------------------------	-----------------------

After you have secured the Drive Enclosure to the rails, attach the front-side caps to the Drive Enclosure.

- 7 Insert the I/O modules, the power cooling modules, and all of the drives into their corresponding slots in the chassis.

### Insert a DE2-24C Drive Enclosure Into a Rack

- 1 With the help of a partner or mechanical lift, carefully lift the Drive Enclosure to the location of the prepared slot and rest the Drive Enclosure on the bottom ledge of the left and right rails.

**CAUTION:** The Drive Enclosures are heavy. Work with a partner or use a mechanical lift for assistance. The DE2-24C Drive Enclosure weighs approximately 102 lbs (46 kg) and the DE2-24P Drive Enclosure weighs approximately 53 lbs (24 kg). Be careful not to drop a Drive Enclosure. Dropping a Drive Enclosure can cause damage and can reduce the life of the drives.

**CAUTION:** Do not use the power supply handles to lift the chassis. Using the power supply handles to lift the chassis can damage the power cooling modules and disrupt electrical power to the Drive Enclosure.


**Figure 50: DE2-24P Drive Enclosure (left) and DE2-24C Drive Enclosure (right)**



- 2 Carefully slide the Drive Enclosure into the rack.


The DE2-24C Drive Enclosure rails have a ledge along the bottom of the rail to allow you to slide the Drive Enclosure into the rack. To verify that the Drive Enclosure is seated correctly in the rails, ensure that the bottom edges on both sides of the Drive Enclosure slide along the left and right rail ledges.

**Figure 51: The rail ledge for the DE2-24C Drive Enclosure**



- 3 At the back of the chassis, insert and fully tighten a Phillips Number 2 pan head screw with patch lock into the side of the rail.

Figure 52: Phillips Number 2 pan head screw with patch lock




Legend	1 Phillips Number 2 pan head screw with patch lock
--------	--

- 4 Remove the front-side caps on both sides of the Drive Enclosure and secure a Phillips 13mm head hex flange screw.

**Note:** The front-side cap on the right side of the Drive Enclosure contains the RFID tag, which uniquely identifies the Drive Enclosure. Take care not to mix up the right front-side caps among Drive Enclosures.

Figure 53: Left front-side cap and Phillips 13mm head hex flange screw



Legend	1 Phillips 13mm head hex flange screw	2 Left front-side cap
--------	---------------------------------------	-----------------------

After you have secured the Drive Enclosure to the rails, attach the front-side caps to the Drive Enclosure.

- 5 Insert the I/O modules, the power cooling modules, and all of the drives into their corresponding slots in the chassis.

## Pilot Rails

Adding Pilots in the rack requires you to install rack rails in the rack and slide rails on the chassis for each Pilot that you plan to add.

Pilot rail kits can be installed in the Sun trademark Rack 900, the Sun Rack 1000, and third-party ANSI/EIA 310-D-1992 or IEC 60927 compliant racks with the following types of holes:

- Square (9.5 mm)
- Round (M6 or 1/4-20 threaded only)

**CAUTION:** We recommend that you install each Pilot after you install the rail kit before installing the next combination of rail kit and Pilot. Installing all of the rail kits and then inserting the Pilots is not always possible because of potential space limitations in some data centers. Also, you run the risk of not placing the Pilot in the correct rack position and causing possible cabling issues.

## Pilot Rail Kits

The Pilot rail kit contains the following items:


- One slide rail that attaches to the rack posts
- One mounting bracket that attaches to the Pilot chassis
- CMA with six pre-installed cable clips
- Four M4 x 5 fine-pitch mounting bracket securing screws (optional)
- Manufacturer's instruction sheet

**Tip:** Ensure that you have all of the parts in the Pilot rail kit before you begin the installation of the Pilot rails on the rack and the Pilot chassis.

**Note:** To locate part numbers for the rail kits, open [Oracle System Handbook](https://support.oracle.com/handbook_private/index.html) ([https://support.oracle.com/handbook\\_private/index.html](https://support.oracle.com/handbook_private/index.html)) and go to the Oracle FS1 Flash Storage System components list. Part numbers are listed in the components list.

The following figure shows the parts in the Pilot rail kit.

Figure 54: Pilot rail kit parts



Legend	1 Slide rails
	2 Mounting brackets
	3 Four M4 x 5 fine pitch mounting bracket securing screws (optional)
	4 Installation card

### Related Links

[Install the Rack Rails for the Pilot](#)


### Install the Rack Rails for the Pilot

Install the rack rails on the rack prior to installing the Pilot.

Prerequisite: • Ensure that you have adequate room to work around the rack while installing the rails and the Pilot.

- 1 Place the rack-mount installation card against the front rails to identify the correct mounting holes for the slide rails.

Figure 55: Rack-mount installation card template




Legend	1 Installation card
	2 Rack mount hole
	3 Pilot chassis
	4 Front rack post

**Note:** The Pilot requires one standard rack units (1U) of vertical space.


**Tip:** The bottom edge of the installation card must correspond to the bottom edge of the Pilot. Measure up from the bottom of the installation card.

- 2 Mark the mounting holes for the front slide rails.
- 3 Mark the mounting holes for the back slide rails.
- 4 Remove the rails from the packaging.
- 5 Orient the slide-rail assembly so that the ball bearing track is forward and locked in place.

**Figure 56: Slide rails oriented with the ball bearing track**

Legend	1 Slide rail
	2 Ball bearing track
	3 Locking mechanism

- 6 Starting with either the left or right side of the rack, align the rear of the slide-rail assembly against the inside of the rear rack rail, and push until the assembly locks into place with an audible click.

**Figure 57: Slide rail assembly aligned with the rack**

Legend	1 Back of the rack
	2 Slide rail

- 7 Align the front of the slide-rail assembly against the outside of the front rack rail, and push until the assembly locks into place with an audible click.
- 8 Repeat steps to attach the slide-rail assembly to the other side of the rack.

### Related Links


[Pilot Rail Kits](#)

## Install the Slide Rails for the Pilot

Install the slide rails with mounting brackets on to the Pilot chassis before inserting it into the rack.

- 1 Position a mounting bracket against the Pilot chassis so that the slide rail lock is at the Pilot front, and the five keyhole openings on the mounting bracket are aligned with the five locating pins on the side of the Pilot chassis.

**Figure 58: Mounting bracket aligned with the Pilot chassis**



Legend	1 Pilot chassis front
	2 Slide rail lock
	3 Mounting bracket
	4 Mounting bracket clip

- 2 With the heads of the five chassis locating pins protruding through the five keyhole openings in the mounting bracket, pull the mounting bracket toward the front of the Pilot chassis until the mounting bracket clip locks into place with an audible click.
- 3 Verify that the rear locating pin has engaged the mounting bracket clip.
- 4 Repeat steps to install the remaining slide rail mounting bracket on the other side of the Pilot chassis.

## Install the Pilot CMA


Install the cable management arm (CMA) so that you can route the Pilot cables into the rack.

The CMA clips into the ends of the left and right Pilot slide rail assemblies. No screws are necessary for mounting the CMA. The right sides of the two CMA arms have hinged extensions.

**Note:** The CMA shown in the graphics might vary slightly from the CMA shipped with your product.

- 1 Unpack the CMA parts.
- 2 Take the CMA to the back of the rack, and ensure that you have adequate room to work around the back of the Pilot.
- 3 Remove the tape to separate the parts of the CMA.
- 4 Insert the CMA's mounting bracket connector into the back of the right slide rail until the connector locks into place with an audible click.
- 5 Insert the right CMA slide rail connector into the back of the right slide rail assembly until the connector locks into place with an audible click.

**Figure 59: CMA slide rail connector inserted into the back of the right slide rail**




Legend	1 CMA slide rail connector
	2 Right slide rail

**Note:** The CMA in the graphic is for representation only. The CMA shipped with your Pilot might be slightly different.

- 6 Insert the left CMA slide-rail connector into the back of the left slide rail assembly until the connector locks into place with an audible click.

**Figure 60: CMA slide rail connector inserted into the back of the left slide rail**



Legend 1 CMA slide rail connector

2 Left slide rail

**Note:** The CMA in the graphic is for representation only. The CMA shipped with your Pilot might be slightly different.

- 7 Install and route cables to the Pilot, as required.

### Insert the Pilot into a Rack

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and ensure that you have an ESD mat. Stand on the ESD mat while replacing components

**CAUTION:** Do not connect the PDUs to any external power source until all components and internal cables have been installed.

**CAUTION:** Turn off all the PDUs or do not connect component power cords to PDUs until all components have been installed and all internal private management interface (PMI) and private interconnect (PI) cables have been connected.

**CAUTION:** Work with a partner or use a mechanical lift for assistance. The Pilot weighs approximately 39.9 lbs (18.1 kg). Two people are required to carry the chassis.


**CAUTION:** Deploy any rack anti-tilt mechanisms before installing the Pilot into the rack to prevent the rack from tipping over during component installation.

**CAUTION:** Always load equipment into a rack from the bottom up so that the rack will not become top-heavy and tip over.

**CAUTION:** Slide rail mounted components are not to be used as a shelf or a work space.

- 1 Push the slide rails as far as possible into the slide rail assemblies in the rack.
- 2 Using two people, one at each side of the Pilot, position the Pilot so that the back ends of the mounting brackets are aligned with the slide rail assemblies that are mounted in the rack.
- 3 Insert the mounting brackets into the slide rails, and then push the Pilot into the rack until the mounting brackets encounter the slide rail stops (approximately 30 cm, or 12 inches).


**Figure 61: Pilot with mounting brackets inserted into the slide rails**



Legend	1 Mounting brackets inserted into the slide rail
	2 Slide rail release button
	3 Slide rail lock

- 4 Simultaneously push and hold the slide rail release buttons on each mounting bracket while you push the Pilot into the rack. Continue pushing the Pilot into the rack until the slide rail locks (on the front of the mounting brackets) engage the slide rail assemblies until you hear an audible click.

Figure 62: Pilot inserted into the rack



Legend	1 Slide rail button
	2 Mounting bracket

**CAUTION:** Verify that the Pilot is securely mounted in the rack and that the slide rail locks are engaged with the mounting brackets before you install the cable management arm.

### Verify Operation of the Slide Rails and the CMA

- Prerequisites:
- Two people are needed to verify the operation of the slide rails and the cable management arm (CMA): one to move the Pilot in and out of the rack and one to observe the cables and CMA.
  - To reduce the risk of personal injury, stabilize the expansion rack cabinet and extend all anti-tilt devices before extending the Pilot from the rack.

**CAUTION:** Work with a partner or use a mechanical lift for assistance. The Pilot weighs approximately 18.1 kilograms (39.9 pounds). Two people are required to carry the chassis.

- 1 Slowly pull the Pilot out of the rack until the slide rails reach their stops.
- 2 Verify that the CMA extends fully from the slide rails.
- 3 Push the Pilot back into the rack.

When the Pilot is fully extended, you must release two sets of slide rail stops to return the Pilot to the rack:

- The first set of stops are levers, located on the inside of each slide rail, just behind the back panel of the Pilot. These levers are labeled “PUSH.” Push in both levers simultaneously, and slide the Pilot toward the rack. The chassis slides in approximately 46 cm (18

inches) and stops. Verify that the cables and the CMA retract without binding before you continue.

- The second set of stops are the slide rail release buttons, located near the front of each mounting bracket. Simultaneously push both of the green slide-rail release buttons, and push the Pilot completely into the rack until both slide-rail locks engage.
- 4 Adjust the cable straps and CMA, as required.


# Controller Replacement Procedures

## Controller Overview

Controllers provide I/O access to the customer LAN or SAN and provide an internal SAS interface that is used to interconnect all Drive Enclosures and other Controllers. The Oracle FS System supports two storage Controllers.

The following figure shows an Oracle FS System Controller.

**Figure 63: Oracle FS System Controller**



## Key Identity Properties (KIP) Automated Update

Oracle ILOM includes a Key Identity Properties (KIP) auto-update feature that ensures product information that is used for service entitlement and warranty coverage is accurately maintained by the Pilots and Controllers at all times, even during hardware replacement service activities.

The KIP includes the component product name, product part number (PPN), and product serial number (PSN). The KIP information is stored in the replaceable unit identifiers container of the three replaceable units that are designated as the quorum members for the component.

The Pilot quorum members include:

- Disk backplane (DBP), designated as the primary quorum member
- Motherboard (MB), designated as a backup quorum member
- Power supply-0 (PS-0) designated as a backup quorum member

The Controller quorum members include:

- Disk backplane (DBP), designated as the primary quorum member
- Motherboard (MB), designated as a backup quorum member
- Power Distribution Board (PDB) designated as a backup quorum member

When a Pilot or Controller replaceable unit that contains the KIP is removed and a replacement component is installed, the KIP of the replacement component is programmed by the Oracle Integrated Lights Out Manager (ILOM) to contain the same KIP as the other two components.

**Note:** Do not change more than one of the quorum devices for either Pilot or Controller at the same time. The ILOM must perform the system initialization after any change in any quorum device. Automated updates can only be completed when two of the three quorum members contain matching key identity properties.

After a quorum device is replaced, you can reset the ILOM either by using an improvised tool like an unbent paper clip or using secure shell (SSH) into the Pilot.

## Use SSH to Access Pilot (For PS-0 Replacement)

Use secure shell (SSH) to access the Pilot on which power supply 0 (PS-0) is being replaced to verify that the Product Serial Number Containers (PSNCs) of the quorum devices are synchronized.

**Note:** This procedure applies only to the replacement of power supply 0 (PS-0).

**Note:** If replacing power supply 0 (PS-0), confirm that the PSNCs of the quorum devices are synchronized with the Pilot. The PSNC of at least two quorum devices must be synchronized, otherwise the Pilot will not boot. Do not replace the quorum devices, if the PSNCs are not synchronized.

- 1 Enable SSH to access the Pilot using the following `fscli` command:  
`# fscli system -modify enablessh 30`
- 2 Use PuTTY or similar software to log in to the Pilot on which PS-0 must be replaced.

```
# ssh <IP address>
```

Where, the IP address refers to the Pilot with the failed PS-0.

- 3 Access the Pilot ILOM port using SSH.  
`[root@pilot2 ~]# ssh 169.254.2.5`  
`Password: changeme`

**Note:** To access the buddy Pilot ILOM, use the IP address: 169.254.2.9.

**Note:** The default password is `changeme` and the IP address 169.254.2.5 connects to the local Pilot ILOM.

- 4 Enter restricted session mode and run the `showpsnc` command.  
`set SESSION mode=restricted`

```
[restricted_shell] ORACLESP-1307FML0VY:~]# showpsnc
```

**Note:** The Restricted Shell account is provided to allow services to perform diagnostic tasks.

```
Primary: fruID:///SYS/DBP0Backup 1: fruID:///SYS/MBBackup 2:
fruID:///SYS/PS0
Element | Primary| Backup1| Backup2
-----+-----+-----+-----
PPN      7056044  7056044  7056044
PSN      1307FML0VY 1307FML0VY 1307FML0VY
<Product Serial Numbers must match. Product Name SUN
FIRE X4170 M3 SUN FIRE X4170 M3 SUN FIRE X4170 M3
```

**Note:**

- If all three PSNCs match, exit and proceed to prepare the system for the replacement procedure.
- If the disk backplane 0 (DBP-0) and the motherboard (MB) have the same PSNC, but the power supply 0 (PS-0) has a different PSNC, proceed to prepare system for the replacement procedure.
- If any other condition exists, contact Oracle Customer Support before proceeding to replace the failed power supply (PS-0).

5 Type `exit` twice to terminate the ssh sessions.


## Replace Controller Air Filter

Air filters are designed to maintain proper airflow within the Controller by keeping the air circulating inside the chassis clear and free of dust.

Each Controller has an air filter covering the front of the chassis. Air filters are customer replaceable units (CRUs). Replacing the air filter does not require you to bring the Controller offline. The following figure shows the Controller air filter.

**Tip:** Wait two minutes before re-seating the air filter to allow the energy storage modules (ESMs) to drain. Otherwise, potential damage might occur if the ESMs are not completely discharged.

**Figure 64: Controller air filter**



### Procedure Overview

- 1 [Remove an Air Filter](#)
- 2 [Insert an Air Filter](#)


## Related Links

[Controller Components](#)

### Remove an Air Filter

- 1 At the front of the Controller chassis, locate the air filter release tabs.
- 2 Press the release tabs inwards at the same time to unlock the tabs and disengage the air filter.

**Figure 65: Air filter release tabs**



Legend 1 Release tabs

2 Air filter

- 3 Carefully rotate the top of the air filter outwards and as the release tabs disengage, lift out the filter.

**Figure 66: Remove air filter**

- 4 Set the air filter aside.

### Insert an Air Filter

- 1 Tilt the top of the air filter slightly towards you and insert the bottom two hooks into the mounting tabs.

**Figure 67: Insert air filter**

**Important:** Ensure that nothing interferes with the edges of the air filter and that the air filter seats properly.

- 2 Press the top corners of the air filter to engage the top two air filter hooks with the top rail tabs.
- 3 Press both air filter release tabs until they lock in place.

## Replace a Controller Fan Module

If a fan module fails, the system issues critical alerts. Replace failed fan modules as soon as possible.

- Prerequisites:
- Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
  - Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Controller chassis.
  - Fail over the Controller before replacing the component using Guided Maintenance.

**Note:** The Controller must be failed over to prevent data loss or data corruption during the component replacement process.

- Initiate Guided Maintenance only when you are able to replace the fan module immediately.

Each Controller has five fan modules that are located side-by-side at the center inside the Controller chassis. A fan module is a customer replaceable unit (CRU). Replacing a fan module requires you to bring the Controller offline. The following figure shows a Controller fan module.

**Figure 68: Fan module**





Figure 69: Fan module location



Legend	1 Fan module-0
	2 Fan module-1
	3 Fan module-2
	4 Fan module-3
	5 Fan module-4

**Note:** The fan modules can be accessed only after removing the top cover over the Controller chassis.

**Note:** To replace a fan module, you do not need to remove the Controller from the rack but extend it along the Controller rails using the cable management arm (CMA).

**Note:** Ensure that all power is removed from the Controller before replacing the fan module. Disconnect the power cables before performing the fan module replacement procedure.

**Note:** For fan replacement, the Replaceable Unit list displays the names of each fan. Each power supply contains one fan, and each fan module contains two fans. If a fan fails in a power supply, replace the power supply. If a fan fails in a fan module, replace the fan module. The following list identifies the names of the fans and the corresponding customer replaceable unit (CRU).

If the following fan fails	Replace the following CRU
Fan 0	Power supply 0
Fan 1	Power supply 1
Fans 2, 3	Fan module 0
Fans 4, 5	Fan module 1

---

If the following fan fails	Replace the following CRU
Fans 6, 7	Fan module 2
Fans 8, 9	Fan module 3
Fans 10, 11	Fan module 4

#### Procedure Overview

- 1 [Prepare the Component for Replacement](#)
- 2 [Remove the Controller Power Supply Cords](#)
- 3 [Slide Controller to Service Position](#)
- 4 [Open the Controller Top Cover](#)
- 5 [Remove a Fan Module](#)
- 6 [Insert a Fan Module](#)
- 7 [Close the Controller Top Cover](#)
- 8 [Complete the Component Replacement](#)
- 9 [Verify Controller Component Status](#)

#### Related Links

[Controller Components](#)

### Prepare the Component for Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware > Controllers and then select the Controller that contains the component that is to be replaced.
- 2 Select Actions > View.  
The View dialog displays the components in the Replaceable Unit list. The Status column lists the status of each component. A status of Normal requires no action.  
**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.
- 3 Select a component from the list and click Replace Component.  
Guided Maintenance displays an image of the chassis.
- 4 Click Next.  
Guided Maintenance displays the Identify Hardware dialog.
- 5 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.  
You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.

6 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.

7 Click Next.


For components that are not hot-serviceable, Guided Maintenance sends a request to bring the Controller offline and automatically initiate failover. Guided Maintenance also displays an HTML link that you use to access the instructions for component replacement.

For hot-serviceable components, Guided Maintenance completes the process of preparing the system for component replacement and displays the Replace Hardware dialog. The Replace Hardware dialog instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, navigate to System > Alerts and Events > System Alerts.

## Remove the Controller Power Supply Cords

Disconnect the power cords from both power supplies.

**Figure 70: Remove power supply cords**



Legend 1 Power supply cords


2 Power supply handle

**Tip:** Always notify affected users that the Controller will be powered off.

## Slide Controller to Service Position

Squeeze the release buttons on either side of the Controller front panel at the same time and slide the Controller chassis forward until the slide rails lock into position. You might have to remove screws locking the front panel to the rack before the Controller slides forward.

**Figure 71: Slide the Controller to service position**



Legend	1 Rack
	2 Controller chassis
	3 Release buttons


**Important:** Before you slide the Controller chassis out, ensure that the cables do not interfere with the movement of the Controller chassis. Although the cable management arm (CMA) is hinged so that you can extend the Controller chassis, all cables and cords must be out of the way when you service the Controller components.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Controller chassis.

## Open the Controller Top Cover

- 1 Fully loosen the two captive thumb screws at the back of the top cover using the Phillips number 2 screwdriver, if necessary.

**Figure 72: Captive thumb screws to remove the top cover**




Legend	1 Controller top cover
	2 Captive screws

- 2 Slide the top cover backwards 0.5 inches (13 mm) and lift the top cover straight up and off the Controller chassis.

## Remove a Fan Module

- 1 Using your thumb and forefinger, grasp the removal tab and gently lift the fan module from the fan compartment.

Figure 73: Remove fan module



Legend	1 Controller chassis
	2 Fan compartment
	3 Removal tab
	4 Fan module

**Note:** Pulling the green tab from the middle releases the locking tab for each individual fan.

**Note:** When removing a fan module, do not rock it back and forth. Rocking the fan module can cause damage to the motherboard connectors.


- 2 Set the fan module aside.

**Note:** The fan compartment might come out when the last fan module is removed.

## Insert a Fan Module

Insert the replacement fan module into the Controller.

Figure 74: Insert fan module



Legend	1 Controller chassis
	2 Fan compartment
	3 Fan module


**Note:** Press down on the fan module and apply firm pressure to fully seat the fan module into the fan compartment. The fan modules are notched to ensure that they are installed in the correct orientation.

**Note:** Repeat for each additional fan module.

### Close the Controller Top Cover

Place the top cover of the Controller and tighten the two thumb screws at the back of the Controller that secure the top cover.

Figure 75: Close Controller top cover



Legend	1 Thumb screws
	2 Controller top cover
	3 Controller

## Complete the Component Replacement

- 1 Slide the Controller back into rack position.
- 2 Connect the AC power cords to power on the Controller.

**Note:** The Controller automatically powers up when the power cords are plugged in.

## Verify Controller Component Status

- 1 From Guided Maintenance, verify that the status is Normal.  
You can also verify the status by navigating to System > Hardware and then selecting a chassis. The Overview page for the selected chassis lists the status of each component.  
**Note:** The Controller status will be visible several minutes after being powered on.
- 2 Review the status of the LEDs to confirm a status of Normal.

## Replace a Controller Power Supply

Power supplies, which exist in pairs, provide DC power to all of the Controller components. If one power supply fails, the other supply carries the full load. This situation creates a risk of Controller failure should the other power supply also fail.


A failed Controller can cause data paths to drop.

**Prerequisites:**

- Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Controller.
- Before handling a component, touch a grounded surface to discharge any static electricity.
- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- Make sure you have a similar replacement power supply available before you start the replacement procedure.
- Initiate Guided Maintenance only when you are able to replace the power supplies immediately.

Each Controller has a pair of power supplies that are located at the back of the Controller. Power supplies are customer replaceable units (CRUs). Replacing a power supply does not require you to bring the Controller offline, provided that the other power supply is online and working. The following figure identifies the location of the Controller power supplies.

**Figure 76: Power supply location**



Legend 1 Power supply-0 (PS-0)

2 Power supply-1 (PS-1)

**Note:** To replace a power supply, you can access the faulted power supply from the back of the Controller module. To access the power supply located in the

bottom slot (PS-1), the CMA clip must be disconnected to enable the power supply to clear the support arm.

**Note:** Replacing the power supply does not require you to slide the Controller into the extended rack position and can be performed while the Controller is in the rack position.

**Note:** Ensure that the power strain relief strap on the power supply is positioned correctly such that there is proper clearance and the power supplies can be re-inserted into the power supply compartment without interference.

**Note:** Ensure that the power cable is routed correctly and there is no interference with the Controller chassis.

**Important:** Do not remove the failed power supply until you have a replacement power supply to ensure proper airflow in the Controller.

**Note:** For fan replacement, the Replaceable Unit list displays the names of each fan. Each power supply contains one fan, and each fan module contains two fans. If a fan fails in a power supply, replace the power supply. If a fan fails in a fan module, replace the fan module. The following list identifies the names of the fans and the corresponding customer replaceable unit (CRU).

If the following fan fails	Replace the following CRU
Fan 0	Power supply 0
Fan 1	Power supply 1
Fans 2, 3	Fan module 0
Fans 4, 5	Fan module 1
Fans 6, 7	Fan module 2
Fans 8, 9	Fan module 3
Fans 10, 11	Fan module 4

#### Procedure Overview

- 1 [Prepare the Component for Replacement](#)
- 2 [Remove the Power Cord](#)
- 3 [Remove a Power Supply](#)
- 4 [Insert a Power Supply](#)
- 5 [Insert the Power Cord](#)
- 6 [Verify Controller Component Status](#)

#### Related Links

[Controller Components](#)

## Prepare the Component for Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware > Controllers and then select the Controller that contains the component that is to be replaced.

- 2 Select Actions > View.

The View dialog displays the components in the Replaceable Unit list. The Status column lists the status of each component. A status of Normal requires no action.

**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.

- 3 Select a component from the list and click Replace Component.

Guided Maintenance displays an image of the chassis.

- 4 Click Next.

Guided Maintenance displays the Identify Hardware dialog.

- 5 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
----------	---

Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.
------------------	---

- 6 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.

- 7 Click Next.


For components that are not hot-serviceable, Guided Maintenance sends a request to bring the Controller offline and automatically initiate failover. Guided Maintenance also displays an HTML link that you use to access the instructions for component replacement.

For hot-serviceable components, Guided Maintenance completes the process of preparing the system for component replacement and displays the Replace Hardware dialog. The Replace Hardware dialog instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, navigate to System > Alerts and Events > System Alerts.

## Remove the Power Cord

Disconnect the power cord from the power supply.

Figure 77: Disconnect the power cord



Legend	1 Power supply cord
--------	---------------------

	2 Power supply handle
--	-----------------------


**Note:** Ensure that the power cord has been disconnected from the faulted power supply.

**Tip:** Always notify affected users that the Controller will be powered off.

## Remove a Power Supply

- 1 Remove the power supply by grasping the power supply handle and pushing the power supply latch to the left.

Figure 78: Controller power supply latch




Legend	1 Power supply handle
--------	-----------------------

	3 Power supply
--	----------------

2 Power supply latch

4 Controller back

Figure 79: Remove power supply



Legend 1 Power supply

2 Power supply compartment

3 Controller

- 2 If both power supplies must be removed, label the power supplies with the slot numbers from which they are removed.

**Note:** Removing both power supplies will result in the immediate powering off of the Controller. Do not pull both power supplies from an active and running Controller.


**Note:** The power supplies must be re-installed into the same slots from which they were removed.

- 3 Pull the power supply out of the chassis and place it on an antistatic mat.

## Insert a Power Supply

- 1 Slide the replacement power supply into the power supply compartment at the back of the Controller until it is fully seated.

Figure 80: Insert power supply



Legend	1 Power supply
	2 Power supply compartment
	3 Controller chassis

- 2 Listen for an audible click or feel the power supply engage to confirm that the power supply is properly seated.

**Note:** Repeat for each power supply. Also, replace the power supplies only into the slots from which they had been removed.

## Insert the Power Cord

Connect the power cord to the power supply.

## Verify Controller Component Status

- 1 From Guided Maintenance, verify that the status is Normal.  
You can also verify the status by navigating to System > Hardware and then selecting a chassis. The Overview page for the selected chassis lists the status of each component.  
**Note:** The Controller status will be visible several minutes after being powered on.
- 2 Review the status of the LEDs to confirm a status of Normal.

## Replace a Controller Energy Storage Module (ESM)


If a failed energy storage module (ESM) is not replaced, you run the risk of losing the data that is temporarily stored in the flash memory. If the external power to

the Controller is lost as well, the potential for data loss rises dramatically. In case of an ESM failure, the Controller should go into write-through (conservative) mode so there is no data loss. Nevertheless, a failed ESM must be replaced as soon as possible to avoid the risk of data loss and to restore system performance.

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Ensure that a replacement ESM or a filler panel available to replace the ESM that you will be removing.

Each Controller has one ESM for every NVDIMM. ESMs are located inside the Controller's ESM drive compartment. An Oracle Flash Storage System with a basic configuration contains two ESMs and two NVDIMMs. An Oracle FS System configured for performance contains four ESMs and four NVDIMMs. ESMs are customer replaceable units (CRUs). The following figure shows the location of the ESM modules.

**Figure 81: ESM**



Legend 1 ESM 0

2 ESM1

3 ESM 2

## 4 ESM 3

**Important:** Do not mix ESM and NVDIMM types. ESM type must match the NVDIMM type. For example, an ESM labeled A (ESM-A) must be paired with an NVDIMM labeled A (NVDIMM-A); The NVDIMM type is printed on a small label near the end of the NVDIMM cable.

**Note:** To replace an ESM, you do not need to remove the Controller from the rack or even extend it along the Controller rails.

**Note:** Make a note of the ESM slot where the failed ESM was located so that the replacement ESM can be placed in the same slot to avoid the risk of mis-configuration. Alternatively, replace the ESMs only one at a time, so that there is only one empty ESM slot at any point in time.

### Procedure Overview

- 1 [Prepare the Component for Replacement](#)
- 2 [Remove an Air Filter](#)
- 3 [Remove a Controller Energy Storage Module \(ESM\)](#)
- 4 [Insert an Energy Storage Module](#)
- 5 [Insert an Air Filter](#)
- 6 [Verify Controller Component Status](#)

### Related Links

[Controller Components](#)

## Prepare the Component for Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware > Controllers and then select the Controller that contains the component that is to be replaced.
- 2 Select Actions > View.  
The View dialog displays the components in the Replaceable Unit list. The Status column lists the status of each component. A status of Normal requires no action.  
**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.
- 3 Select a component from the list and click Replace Component.  
Guided Maintenance displays an image of the chassis.
- 4 Click Next.  
Guided Maintenance displays the Identify Hardware dialog.
- 5 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.

6 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.

7 Click Next.


For components that are not hot-serviceable, Guided Maintenance sends a request to bring the Controller offline and automatically initiate failover. Guided Maintenance also displays an HTML link that you use to access the instructions for component replacement.

For hot-serviceable components, Guided Maintenance completes the process of preparing the system for component replacement and displays the Replace Hardware dialog. The Replace Hardware dialog instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, navigate to System > Alerts and Events > System Alerts.

## Remove an Air Filter

- 1 At the front of the Controller chassis, locate the air filter release tabs.
- 2 Press the release tabs inwards at the same time to unlock the tabs and disengage the air filter.

**Figure 82: Air filter release tabs**



Legend 1 Release tabs

2 Air filter

- Carefully rotate the top of the air filter outwards and as the release tabs disengage, lift out the filter.

**Figure 83: Remove air filter**




- Set the air filter aside.

## Remove a Controller Energy Storage Module (ESM)

- Remove the Controller ESM from the drive compartment by pushing the latch release button to open the latch.

**Figure 84: Open ESM latch**




Legend	1 ESM
	2 Latch release button
	3 Controller front

**Important:** Do not bend the latch too far to the right. Bending the latch can damage the latch.

**Important:** When you remove an ESM, be sure to replace it immediately with another ESM or a filler panel. Otherwise, the Controller might overheat because of improper airflow.

- 2 Grasp the latch and pull the ESM out of the Controller drive compartment.

**Figure 85: Remove ESM**



Legend	1 ESM
	2 Controller drive compartment
	3 Controller front

- 3 Set the failed component aside.


## Insert an Energy Storage Module

- 1 Insert the ESM into the correct slot.

**Note:** The Controller might have filler panels covering the empty slots in the ESM drive compartment.

- 2 Slide the replacement ESM into the drive compartment until the ESM is fully seated into the slot.

Figure 86: Insert ESM




Legend	1 ESM
	2 Controller drive compartment
	3 Controller front

**Note:** Be sure to install the replacement ESM in the same slot from which the ESM was removed.

- 3 Close the drive carrier latch to lock the ESM in place.

Figure 87: Secure ESM into drive slot



Legend	1 ESM
	2 Controller drive compartment
	3 Controller front

**Note:** Do not force the drive carrier latch. You can damage the drive carrier latch if you apply too much force.

## Power On the Controller

Power on the Controller using the power button and the ILOM web interface.

**Note:** As soon as the power cords are connected to the Controller, standby power is applied. In standby power mode, the Power/OK LED on the Controller front panel blinks every five seconds or so. However, to apply main power to the Controller, you must use the power button and the web interface. When main power is applied to the Controller, the green Power/OK LED on the front panel of the Controller blinks steadily. When the Controller BIOS has completed booting, the OK LED remains lit.

## Insert an Air Filter

- 1 Tilt the top of the air filter slightly towards you and insert the bottom two hooks into the mounting tabs.

**Figure 88: Insert air filter**



**Important:** Ensure that nothing interferes with the edges of the air filter and that the air filter seats properly.

- 2 Press the top corners of the air filter to engage the top two air filter hooks with the top rail tabs.
- 3 Press both air filter release tabs until they lock in place.

## Verify Controller Component Status

- 1 From Guided Maintenance, verify that the status is Normal.

You can also verify the status by navigating to System > Hardware and then selecting a chassis. The Overview page for the selected chassis lists the status of each component.

**Note:** The Controller status will be visible several minutes after being powered on.

- 2 Review the status of the LEDs to confirm a status of Normal.

## Replace a Controller Riser


A riser board assembly provides network and data-path connections for network or read and write operations. If the assembly fails, read and write operations carried by the HBAs will fail as well.

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Disconnect any cables connected to the PCIe cards in the riser that must be replaced.

Each Controller contains three PCI-express (PCIe) risers that are located side by side at the back of the Controller. The three risers, though similar, are not interchangeable. Each riser hosts two PCIe3 slots and can accommodate two PCIe3 host bus adapters (HBAs). The risers are customer replaceable units (CRUs). Replacing a riser assembly requires you to bring the Controller offline. The following figure shows the location of the three risers.

**Note:** By design, the risers are mechanically dependent upon each other. Even if there are no PCIe3 HBAs installed, all risers must be installed.

**Figure 89:** Riser locations



Legend	1 Riser 1
	2 Riser 2
	3 Riser 3 with latch

**Note:** The risers can be accessed only after removing the top cover over the Controller chassis.

**Note:** To replace a riser, you do not need to remove the Controller from the rack but extend it along the Controller rails using the cable management arm (CMA).

**Note:** Ensure that all power is removed from the Controller before replacing the riser. Disconnect the power cords before performing the riser replacement procedure.

#### Procedure Overview

- 1 *Prepare the Component for Replacement*
- 2 *Remove the Controller Power Supply Cords*
- 3 *Slide Controller to Service Position*
- 4 *Disconnect Controller Cabling*
- 5 *Open the Controller Top Cover*
- 6 *Remove a Riser*
- 7 *Insert a Riser*
- 8 *Close the Controller Top Cover*
- 9 *Reconnect Controller Cabling*
- 10 *Complete the Component Replacement*
- 11 *Verify Controller Component Status*

#### Related Links

[Controller Components](#)

### Prepare the Component for Replacement

- 1 From Oracle FS System Manager (GUI), navigate to Support > System Trouble.
- 2 Select the Controller that contains the component that is to be replaced.
- 3 Select Actions > Replace Component.  
Guided Maintenance displays the list of replaceable components for the Controller.

**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.

- 4 Select a component from the list.

## 5 Click Next.

Guided Maintenance displays the Identify Hardware dialog.

## 6 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.

## 7 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.


## 8 Click Next.

Guided Maintenance sends a request to shut down the software running on the Controller and automatically initiates failover. Guided Maintenance also displays an HTML link that you use to access the instructions for component replacement.

## Remove the Controller Power Supply Cords

Disconnect the power cords from both power supplies.

**Figure 90: Remove power supply cords**




Legend	1 Power supply cords
	2 Power supply handle

**Tip:** Always notify affected users that the Controller will be powered off.

## Slide Controller to Service Position

Squeeze the release buttons on either side of the Controller front panel at the same time and slide the Controller chassis forward until the slide rails lock into position. You might have to remove screws locking the front panel to the rack before the Controller slides forward.

**Figure 91: Slide the Controller to service position**



Legend 1 Rack

2 Controller chassis

3 Release buttons

**Important:** Before you slide the Controller chassis out, ensure that the cables do not interfere with the movement of the Controller chassis. Although the cable management arm (CMA) is hinged so that you can extend the Controller chassis, all cables and cords must be out of the way when you service the Controller components.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Controller chassis.

## Disconnect Controller Cabling

Disconnect all data cables from the Controller.

**Note:** All cables must be dis-connected from the Controller and labelled such that they can be reconnected accurately to the Controller after the replacement procedure is complete. Reconnecting cables to the incorrect position might impact the performance of the Controller or result in a complete loss of functionality.


**Note:** Service the Controller components from the front of the Controller while the Controller is in service position.

**Note:** Do not lean on or place any weight on the Controller while the Controller is in the service position.

## Open the Controller Top Cover

- 1 Fully loosen the two captive thumb screws at the back of the top cover using the Phillips number 2 screwdriver, if necessary.

**Figure 92: Captive thumb screws to remove the top cover**



Legend	1 Controller top cover
	2 Captive screws

- 2 Slide the top cover backwards 0.5 inches (13 mm) and lift the top cover straight up and off the Controller chassis.

## Remove a Riser

- 1 Disconnect any external cables that remain connected to the HBAs in the risers.

**Note:** Also disconnect any internal cables attached to the HBAs, if that will ease removing the HBA.

**Tip:** Make a note of the positions of all existing cable connections before removing any cables. Replacing HBAs or their cables into the incorrect position in the riser may result in a loss of performance or functionality.


- 2 Note the position of the HBAs installed on the riser.

**Tip:** Make a note of the slot numbers of all existing HBAs before removing any HBAs.

- 3 Using a Phillips Number 2 screwdriver, loosen the two Phillips Number 2 captive screws on either side of the riser that hold the riser to the Controller motherboard.

**Note:** The riser on the opposite end of the power supply has a latch that must be disengaged to remove the riser from the Controller chassis


**Figure 93: Captive screws to secure the risers**



Legend	1 Riser 3 with latch	3 Riser 1
	2 Riser 2	4 Captive screws that secure riser

To remove riser 3, unlock the latch to release the riser from the Controller motherboard.


Figure 94: Unlock Riser 3 latch



Legend	1 Riser 3 latch	3 HBA
	2 Riser 3	

- Carefully pull the riser straight up and place it aside.

Figure 95: Remove riser



Legend	1 Riser
	2 Controller motherboard


**Important:** Ensure that any HBAs that must be removed from the failed riser and placed onto the replacement rise are inserted into the same slots on the replacement riser.

## Insert a Riser

- 1 Lower the riser onto the Controller motherboard and press the riser edge connector securely into the socket.

**Important:** Ensure that any HBAs that must be removed from the failed riser and placed onto the replacement rise are inserted into the same slots on the replacement riser.

**Figure 96: Insert riser**




Legend 1 Riser

2 Controller motherboard

- 2 After the riser is seated properly inside the Controller, tighten the two captive Phillips screws on both sides of the riser to secure the riser on the Controller motherboard.


Figure 97: Captive screws to secure risers to the motherboard



Legend	1 Riser 3 with latch	3 Riser 1
	2 Riser 2	4 Captive screws

To install riser 3, lock the latch to secure the riser to the ControllerReplication Engine motherboard.

Figure 98: Riser 3 latch locked




Legend	1 Riser 3 latch	3 HBA
	2 Riser 3	

- 3 Reconnect any previously removed internal or external cables to any HBAs installed in the riser.
- 4 Repeat the above steps for any additional risers that you are installing.

## Close the Controller Top Cover

Place the top cover of the Controller and tighten the two thumb screws at the back of the Controller that secure the top cover.

**Figure 99: Close Controller top cover**



Legend	1 Thumb screws
	2 Controller top cover
	3 Controller

## Reconnect Controller Cabling

- 1 Reconnect all the data cables on the Controller.

**Note:** Oracle Customer Support recommends labeling all cables connected to the Controller so that the cables can be reconnected accurately to the Controller after the replacement procedure is complete.

- 2 Reconnect the CMA to the Controller by attaching the release tab on the left and right side of the CMA.

## Complete the Component Replacement

- 1 Slide the Controller back into rack position.
- 2 Connect the AC power cords to power on the Controller.

**Note:** The Controller automatically powers up when the power cords are plugged in.

## Verify Controller Component Status

- 1 From Guided Maintenance, verify that the status is Normal.

You can also verify the status by navigating to System > Hardware and then selecting a chassis. The Overview page for the selected chassis lists the status of each component.

**Note:** The Controller status will be visible several minutes after being powered on.

- 2 Review the status of the LEDs to confirm a status of Normal.

## Replace a Controller HBA

An HBA is a circuit board installed inside the Controller riser board assembly.

A failed HBA might cause a Controller failure that could result in the remaining Controllers to shoulder the load. Therefore, if failed, an HBA must be replaced immediately. Additional HBAs can also be added to existing configurations.

- Prerequisites:
- Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
  - Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Keep filler panels available in case you only remove the HBA and do not plan to replace the HBA immediately.

**Note:** Filler panels ensure proper airflow inside the Controller.

- Use only the filler panels provided with the Controller to maintain proper airflow and EMI conformance for empty slots inside the Controller.
- Fail over the Controller before replacing the component using Guided Maintenance.

**Note:** The Controller must be failed over to prevent data loss or data corruption during the component replacement process.

- Label all cables connected to the Controller so that they can be reconnected accurately to the Controller after the replacement procedure is complete.

**Note:** Replacing an HBA might require changes to the port's world wide name (WWN).

Each Oracle Flash Storage System supports two types of HBA connectivity SAN (FC or iSCSI HBA 16Gb, optical only) and NAS (10 GbE HBA). The placement of the HBA inside the riser slot is based on the Oracle FS System configuration option selected. All HBAs supported in the Oracle FS System are customer replaceable units (CRUs). Replacement of an HBA requires you to bring the Controller offline. HBAs connecting to host servers must be placed into slots 1, 4, and 5 on the risers. HBAs connecting to Drive Enclosures must be placed into slots 2, 3, and 6 on the risers. You must install all HBAs according to the slot numbers listed in the following table.

HBA	System type	Slot number
16 Gb/s Fibre Channel (FC) or 10GbE iSCSI universal HBA, QLogic	SAN	1, 4, 5
10 Gb/s Ethernet dual port or fibre SFP+	NAS	1, 4, 5
6 Gb/s SAS PCIe-3, 4x4 port	ALL	3,6,2

**Note:** Replacement of the HBA will result in a change to the world wide port name (WWPN) of the HBA

**Note:** If both Ethernet and FC HBA are used, insert the Ethernet HBA in the first slot of the riser.

#### Procedure Overview

- 1 [Prepare the Component for Replacement](#)
- 2 [Remove the Controller Power Supply Cords](#)
- 3 [Slide Controller to Service Position](#)
- 4 [Disconnect Controller Cabling](#)
- 5 [Open the Controller Top Cover](#)

- 6 [Remove a Riser](#)
- 7 [Remove an HBA](#)
- 8 [Insert an HBA](#)
- 9 [Insert a Riser](#)
- 10 [Close the Controller Top Cover](#)
- 11 [Reconnect Controller Cabling](#)
- 12 [Complete the Component Replacement](#)
- 13 [Verify Controller Component Status](#)

## Related Links

[Controller Components](#)

## Prepare the Component for Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware > Controllers and then select the Controller that contains the component that is to be replaced.
- 2 Select Actions > View.

The View dialog displays the components in the Replaceable Unit list. The Status column lists the status of each component. A status of Normal requires no action.

**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.

- 3 Select a component from the list and click Replace Component.

Guided Maintenance displays an image of the chassis.

- 4 Click Next.

Guided Maintenance displays the Identify Hardware dialog.

- 5 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
----------	---

Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.
------------------	---

- 6 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.

- 7 Click Next.

For components that are not hot-serviceable, Guided Maintenance sends a request to bring the Controller offline and automatically initiate failover.


Guided Maintenance also displays an HTML link that you use to access the instructions for component replacement.

For hot-serviceable components, Guided Maintenance completes the process of preparing the system for component replacement and displays the Replace Hardware dialog. The Replace Hardware dialog instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, navigate to System > Alerts and Events > System Alerts.

## Remove the Controller Power Supply Cords

Disconnect the power cords from both power supplies.

**Figure 100: Remove power supply cords**




Legend	1 Power supply cords
	2 Power supply handle

**Tip:** Always notify affected users that the Controller will be powered off.

## Slide Controller to Service Position

Squeeze the release buttons on either side of the Controller front panel at the same time and slide the Controller chassis forward until the slide rails lock into position. You might have to remove screws locking the front panel to the rack before the Controller slides forward.

Figure 101: Slide the Controller to service position



Legend	1 Rack
	2 Controller chassis
	3 Release buttons

**Important:** Before you slide the Controller chassis out, ensure that the cables do not interfere with the movement of the Controller chassis. Although the cable management arm (CMA) is hinged so that you can extend the Controller chassis, all cables and cords must be out of the way when you service the Controller components.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Controller chassis.

## Disconnect Controller Cabling

Disconnect all data cables from the Controller.

**Note:** All cables must be dis-connected from the Controller and labelled such that they can be reconnected accurately to the Controller after the replacement procedure is complete. Reconnecting cables to the incorrect

position might impact the performance of the Controller or result in a complete loss of functionality.


**Note:** Service the Controller components from the front of the Controller while the Controller is in service position.

**Note:** Do not lean on or place any weight on the Controller while the Controller is in the service position.

## Open the Controller Top Cover

- 1 Fully loosen the two captive thumb screws at the back of the top cover using the Phillips number 2 screwdriver, if necessary.

**Figure 102: Captive thumb screws to remove the top cover**



Legend	1 Controller top cover
	2 Captive screws

- 2 Slide the top cover backwards 0.5 inches (13 mm) and lift the top cover straight up and off the Controller chassis.

## Remove a Riser

- 1 Disconnect any external cables that remain connected to the HBAs in the risers.

**Note:** Also disconnect any internal cables attached to the HBAs, if that will ease removing the HBA.

**Tip:** Make a note of the positions of all existing cable connections before removing any cables. Replacing HBAs or their cables into the incorrect position in the riser may result in a loss of performance or functionality.


- 2 Note the position of the HBAs installed on the riser.

**Tip:** Make a note of the slot numbers of all existing HBAs before removing any HBAs.

- 3 Using a Phillips Number 2 screwdriver, loosen the two Phillips Number 2 captive screws on either side of the riser that hold the riser to the Controller motherboard.

**Note:** The riser on the opposite end of the power supply has a latch that must be disengaged to remove the riser from the Controller chassis


**Figure 103: Captive screws to secure the risers**



Legend	1 Riser 3 with latch	3 Riser 1
	2 Riser 2	4 Captive screws that secure riser

To remove riser 3, unlock the latch to release the riser from the Controller motherboard.


Figure 104: Unlock Riser 3 latch



Legend	1 Riser 3 latch	3 HBA
	2 Riser 3	

- 4 Carefully pull the riser straight up and place it aside.

Figure 105: Remove riser




Legend	1 Riser
	2 Controller motherboard

**Important:** Ensure that any HBAs that must be removed from the failed riser and placed onto the replacement riser are inserted into the same slots on the replacement riser.

## Remove an HBA

- 1 Disconnect any cables that are connected to the HBAs inside the riser. If you have not done so already, note the ports from which the cables are disconnected in the HBA, so that the cables can be reconnected to their original ports when the HBA is replaced.
- 2 Swing the riser retainer latch (for riser 3) to its fully open (180 degrees) position.


**Figure 106: Unlock riser retainer latch to release HBA**



Legend	1 Riser retainer latch
	2 HBA
	3 Riser

- 3 Lift the HBA off of the alignment pin of the riser slot.

Figure 107: Remove HBA from riser slots



Legend	1 Riser
	2 Riser slots
	3 HBA

**Note:** If you cannot replace the HBA immediately, insert a filler panel in the vacant slot. The filler panel ensures proper airflow in the Controller.

## Insert an HBA

- 1 When all HBAs have been installed in this riser, swing the riser retainer latch and unscrew the filler panels on the riser (if any), so that the HBAs can be inserted into the PCIe slots of the replacement riser.


**Note:** If you are replacing an HBA from the riser with the retainer latch, swing the retainer latch to its fully open (180 degrees) position.

- 2 Orient the HBA so that the brackets of the HBA align with the alignment pin in the PCIe slot of the riser.

**Important:** Hold the HBA by the edges. Do not touch the metal contacts on the bottom of the card.

- 3 Push the connectors on the edge of the HBA into the PCIe slot by pushing firmly to seat the card.

Figure 108: Insert HBA into riser slot




Legend	1 Riser
	2 Riser slots
	3 HBA

- 4 Apply firm pressure on each end of the HBA alternately until it clicks into place in the riser socket.

**CAUTION:** Support the HBA and the riser as necessary to prevent excessive flexure. Otherwise, the HBA or the riser card might be damaged.

- 5 When all HBAs have been installed in this riser, swing the retainer latch to its fully closed position. If there is resistance, check the alignment of the HBA and try again.

Figure 109: HBA retainer latch



Legend	1 Riser retainer latch
	2 HBA
	3 Riser

- 6 Repeat the procedure for any additional PCIe3 HBAs that might be installed in the other risers.
- 7 Reconnect any cables that had been disconnected from the HBAs.


**Note:** Make sure that disconnected cables from the HBAs are connected to their original ports.

## Insert a Riser

- 1 Lower the riser onto the Controller motherboard and press the riser edge connector securely into the socket.

**Important:** Ensure that any HBAs that must be removed from the failed riser and placed onto the replacement rise are inserted into the same slots on the replacement riser.

**Figure 110: Insert riser**




Legend 1 Riser

2 Controller motherboard

- 2 After the riser is seated properly inside the Controller, tighten the two captive Phillips screws on both sides of the riser to secure the riser on the Controller motherboard.


Figure 111: Captive screws to secure risers to the motherboard



Legend	1 Riser 3 with latch	3 Riser 1
	2 Riser 2	4 Captive screws

To install riser 3, lock the latch to secure the riser to the ControllerReplication Engine motherboard.

Figure 112: Riser 3 latch locked




Legend	1 Riser 3 latch	3 HBA
	2 Riser 3	

- 3 Reconnect any previously removed internal or external cables to any HBAs installed in the riser.
- 4 Repeat the above steps for any additional risers that you are installing.

## Close the Controller Top Cover

Place the top cover of the Controller and tighten the two thumb screws at the back of the Controller that secure the top cover.

**Figure 113: Close Controller top cover**



Legend	1 Thumb screws
	2 Controller top cover
	3 Controller

## Reconnect Controller Cabling

- 1 Reconnect all the data cables on the Controller.

**Note:** Oracle Customer Support recommends labeling all cables connected to the Controller so that the cables can be reconnected accurately to the Controller after the replacement procedure is complete.

- 2 Reconnect the CMA to the Controller by attaching the release tab on the left and right side of the CMA.

## Complete the Component Replacement

- 1 Slide the Controller back into rack position.
- 2 Connect the AC power cords to power on the Controller.  
**Note:** The Controller automatically powers up when the power cords are plugged in.

## Verify Controller Component Status

- 1 From Guided Maintenance, verify that the status is Normal.  
You can also verify the status by navigating to System > Hardware and then selecting a chassis. The Overview page for the selected chassis lists the status of each component.  
**Note:** The Controller status will be visible several minutes after being powered on.
- 2 Review the status of the LEDs to confirm a status of Normal.

## Replace a Controller DIMM

Dual in-line memory modules (DIMMs) provide random access memory (RAM) for the central processing units (CPUs) configured in the Controller. DIMMs are connected to the DIMM slots located on both sides of the central processing unit (CPUs) and heat sinks on the Controller motherboard. A failed DIMM might cause the Controller to be brought offline and must be replaced as soon as possible.

- Prerequisites:
- Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
  - Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Fail over the Controller before replacing the component using Guided Maintenance.


**Note:** The Controller must be failed over to prevent data loss or data corruption during the component replacement process.

- Ensure that all DIMM slots are filled with either filler panels or DIMMs to ensure proper airflow.

A basic Oracle FS1 Flash Storage System has two standard DIMMs and a performance Oracle FS1 Flash Storage System has 12 standard DIMMs. The DIMMs in the Oracle FS1 Flash Storage System have 16 GB memory.


DIMMs are customer replaceable units (CRUs). Replacing a DIMM requires you to bring the Controller offline. The following figure depicts a DIMM memory module.

**Figure 114: DIMM memory module**



The following diagram indicates the location of the DIMMs in the DIMM slots.

Figure 115: DIMMs in DIMM slots



**Note:** The DIMMs can be accessed only after removing the cover over the Controller chassis.

**Note:** To replace a DIMM, you do not need to remove the Controller from the rack but extend it along the Controller rails using the cable management arm (CMA).

**Note:** All DIMM fault LEDs are located next to the DIMM slots along with the DIMM slot number.

**CAUTION:** Ensure that all power is removed from the Controller before removing or installing the DIMM.

#### Procedure Overview

- 1 *Prepare the Component for Replacement*
- 2 *Remove the Controller Power Supply Cords*
- 3 *Slide Controller to Service Position*
- 4 *Open the Controller Top Cover*
- 5 *Remove an Air Filter*
- 6 *Raise the Drive Compartment to Service Position*
- 7 *Remove an Air Duct*
- 8 *Remove a DIMM*
- 9 *Insert a DIMM*
- 10 *Lower the Drive Compartment*

- 11 [Insert an Air Duct](#)
- 12 [Insert an Air Filter](#)
- 13 [Close the Controller Top Cover](#)
- 14 [Complete the Component Replacement](#)
- 15 [Verify Controller Component Status](#)

## Related Links

[Controller Components](#)

## Prepare the Component for Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware > Controllers and then select the Controller that contains the component that is to be replaced.

- 2 Select Actions > View.

The View dialog displays the components in the Replaceable Unit list. The Status column lists the status of each component. A status of Normal requires no action.

**Note:** Field replaceable units (FRUs) can only be replaced by field technicians with support role privileges.

- 3 Select a component from the list and click Replace Component.

Guided Maintenance displays an image of the chassis.

- 4 Click Next.

Guided Maintenance displays the Identify Hardware dialog.

- 5 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
----------	---

Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.
------------------	---

- 6 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.

- 7 Click Next.


For components that are not hot-serviceable, Guided Maintenance sends a request to bring the Controller offline and automatically initiate failover. Guided Maintenance also displays an HTML link that you use to access the instructions for component replacement.

For hot-serviceable components, Guided Maintenance completes the process of preparing the system for component replacement and displays the Replace Hardware dialog. The Replace Hardware dialog instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, navigate to System > Alerts and Events > System Alerts.

## Remove the Controller Power Supply Cords

Disconnect the power cords from both power supplies.

**Figure 116: Remove power supply cords**



Legend 1 Power supply cords


2 Power supply handle

**Tip:** Always notify affected users that the Controller will be powered off.

## Slide Controller to Service Position

Squeeze the release buttons on either side of the Controller front panel at the same time and slide the Controller chassis forward until the slide rails lock into position. You might have to remove screws locking the front panel to the rack before the Controller slides forward.

Figure 117: Slide the Controller to service position




Legend	1 Rack
	2 Controller chassis
	3 Release buttons

**Important:** Before you slide the Controller chassis out, ensure that the cables do not interfere with the movement of the Controller chassis. Although the cable management arm (CMA) is hinged so that you can extend the Controller chassis, all cables and cords must be out of the way when you service the Controller components.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Controller chassis.

## Open the Controller Top Cover

- 1 Fully loosen the two captive thumb screws at the back of the top cover using the Phillips number 2 screwdriver, if necessary.

**Figure 118: Captive thumb screws to remove the top cover**


Legend 1 Controller top cover

2 Captive screws

- 2 Slide the top cover backwards 0.5 inches (13 mm) and lift the top cover straight up and off the Controller chassis.

### Remove an Air Filter

- 1 At the front of the Controller chassis, locate the air filter release tabs.
- 2 Press the release tabs inwards at the same time to unlock the tabs and disengage the air filter.

**Figure 119: Air filter release tabs**

Legend 1 Release tabs

---

2 Air filter
--------------

- Carefully rotate the top of the air filter outwards and as the release tabs disengage, lift out the filter.

**Figure 120: Remove air filter**




- Set the air filter aside.

### **Raise the Drive Compartment to Service Position**

- Disconnect the cables attached to the backplane.  
Cables that must be disconnected include:
  - SATA or drive cable
  - NV-DIMM cable
  - Motherboard to HDD backplane cable
  - USB board cable

Figure 121: Cables connected to the backplane



Legend	1 SATA or drive cable
	2 NV-DIMM cables
	3 Drive compartment
	4 Backplane boards
	5 Motherboard to HDD backplane cable

**Note:** The USB board cable is connected to the Controller display panel.


**Note:** All cables attached to the backplane must be disconnected before raising the drive compartment. Otherwise, the cables might get damaged or tear due to unnecessary flexure or pull.

**Note:** Note the location of all the cable connections to the backplane for later re-connection of the cables after the replacement procedure is completed.

**Tip:** Refer to the service label for more information on rotating the drive compartment.

- 2 Disengage the backplane by loosening the four Phillips Number 2 thumb screws on the four sides of the backplane using a Phillips Number 2 screwdriver and rotate the backplane at a 90 degrees angle.

Figure 122: Disengaging the backplane




- |        |  |
|--------|--|
| Legend | 1 Thumb screws that secure the backplane |
|        | 2 Backplane                              |

**Note:** Use the screwdriver very carefully to avoid damaging the electrical circuitry inside the Controller.

- 3 Raise the backplane and drive compartment to the vertical position.

Figure 123: Drive compartment raised




Legend	1 Backplane
	2 Drive compartment
	3 Controller motherboard

## Remove an Air Duct

- 1 Replace and secure the air duct for removal by loosening the two brackets and the Phillips Number 2 thumb screws on both sides of the air duct.

**Figure 124: Remove air duct**




Legend	1 Screws that secure air duct
	2 Air duct

**Note:** The brackets that secure the air duct are labeled L (left) and R (right). The left bracket slides forward and the right bracket slides back when facing the Controller in the service position.

- 2 Lift up the air duct from the Controller chassis and set it aside. The following figure shows a Controller air duct:


Figure 125: Air duct



## Remove a DIMM

- 1 Remove the DIMMs by pressing down on the tabs on both sides of the DIMM to unlock it from the slot.

Figure 126: Remove DIMMs



Legend	1 Tabs to release DIMMs
	2 DIMM
	3 DIMM slot

**Note:** Pressing on the fault remind button on the motherboard lights up the fault LED. The fault remind button helps to identify the faulted DIMMs. However, press the fault remind button only when necessary, because the

capacitor powering up the fault remind button can be sustained only for 60 seconds.

**Note:** While inserting or removing DIMMs, ensure that there is no interference with the cables. Pulling or pressing down on the cables might cause damage to the cables during the replacement procedure.

- 2 Lift out the DIMM and set aside on an antistatic mat.


**Note:** Visually inspect the slots and the memory for physical damage by checking for cracked or broken plastic in the slot.

**Note:** Sometimes memory might fault because of dust or improper alignment or damaged slots. Use only compressed air to dust the memory.

## Insert a DIMM


Press the DIMM fully into the DIMM slot and ensure that the tabs on both sides of the DIMM are locked.

**Figure 127: Insert Controller DIMM**



Legend	1 DIMM
	2 Tabs to secure DIMMs
	3 DIMM notch aligns with the DIMM slots

**Note:** While inserting DIMMs, ensure that there is no interference with the cables. Pulling or pressing down on the cables might cause damage to the cables during the replacement procedure.

**Figure 128: DIMM alignment over DIMM slots**

**Important:** Ensure that the notch in the DIMM lines up with the key in the slot.

**Note:** Replace only one DIMM at a time to make sure that they are inserted into the correct slots. Attempting to insert multiple DIMMs into the slots might damage the DIMMs due to excessive flexure.

**Note:** Never leave a DIMM slot unpopulated. Insert fillers into empty slots to ensure proper air flow inside the Controller.


## Lower the Drive Compartment

- 1 Rotate the drive compartment and backplane back into position inside the Controller and ensure that the alignment pins engage.  
**Note:** To confirm that the backplane is locked into position, listen for an audible click or feel the backplane engage with the Controller.
- 2 Secure the backplane inside the Controller by inserting the four Phillips Number 2 thumb screws on the four sides of the backplane and tightening them using a Phillips Number 2 screwdriver.
- 3 Reconnect all the cables that had been previously disconnected from the backplane.

Cables that must be reconnected include:

- SATA or drive cable
- NV-DIMM cable
- Motherboard to HDD backplane cable

Figure 129: Reconnect cables to the backplane



Legend	1 SATA or drive cable
	2 NV-DIMM cable
	3 Drive compartment
	4 Backplane boards
	5 Motherboard to HDD backplane cable


## Insert an Air Duct

Secure the air duct inside the Controller by tightening the two Phillips Number 2 screws into position.

**Note:** The brackets that secure the air duct are labeled L (left) and R (right). The left bracket slides forward, the right bracket slides back when facing the Controller in the service position.

## Insert an Air Filter

- 1 Tilt the top of the air filter slightly towards you and insert the bottom two hooks into the mounting tabs.

**Figure 130: Insert air filter**


**Important:** Ensure that nothing interferes with the edges of the air filter and that the air filter seats properly.

- 2 Press the top corners of the air filter to engage the top two air filter hooks with the top rail tabs.
- 3 Press both air filter release tabs until they lock in place.

### Close the Controller Top Cover

Place the top cover of the Controller and tighten the two thumb screws at the back of the Controller that secure the top cover.

Figure 131: Close Controller top cover



Legend	1 Thumb screws
	2 Controller top cover
	3 Controller

## Complete the Component Replacement

- 1 Slide the Controller back into rack position.
- 2 Connect the AC power cords to power on the Controller.

**Note:** The Controller automatically powers up when the power cords are plugged in.

## Verify Controller Component Status

- 1 From Guided Maintenance, verify that the status is Normal.  
You can also verify the status by navigating to System > Hardware and then selecting a chassis. The Overview page for the selected chassis lists the status of each component.  
**Note:** The Controller status will be visible several minutes after being powered on.
- 2 Review the status of the LEDs to confirm a status of Normal.

# Drive Enclosure Replacement Procedures


## Drive Enclosure Overview


Drive Enclosures are used as back-end storage for the Oracle Flash Storage System. The Oracle FS System can be configured for as many as 30 Drive Enclosures. The two types of Drive Enclosure are the DE2-24P Drive Enclosure and the DE2-24C Drive Enclosure. Both Drive Enclosure types can co-exist in the same system.

Drive Enclosure are high-availability, serial-attached SCSI (SAS-2) storage enclosures. The DE2-24P Drive Enclosure has a 2U chassis that supports 24 small form factor (SFF), 2.5-inch (6.35-cm) hard disk drives (HDDs). The DE2-24P Drive Enclosure also supports configurations with seven, 13, or 19 solid state drives (SSDs). The DE2-24C Drive Enclosure has a 4U chassis that supports 24 large form factor (LFF), 3.5-inch (8.89-cm) HDDs.

The following figures show the front of the DE2-24P Drive Enclosure and the DE2-24C Drive Enclosure.

**Figure 132: DE2-24P Drive Enclosure (front view)**





**Figure 133: DE2-24C Drive Enclosure (front view)**

Both types of Drive Enclosures have the following physical configuration:

- Two hot-serviceable I/O modules with two interface slots that comply with the Storage Bridge Bay (SBB) standard
- Two hot-serviceable 580W power cooling modules with dual load-sharing power supplies and integrated fans
- 19-inch rack-compatible enclosure
- Front access to all drives
- Back access to the I/O modules and the power cooling modules
- LEDs with status information for the I/O modules, the drives, and the power cooling modules

The following figures show the back of the DE2-24P Drive Enclosure and the DE2-24C Drive Enclosure.

**Figure 134: DE2-24P Drive Enclosure (back view)****Figure 135: DE2-24C Drive Enclosure (back view)**

## Drive Enclosure Drive Replacement

Each Drive Enclosure has drives located on the front of the chassis. Drives are customer replaceable units (CRUs). Replacing a drive is a hot-serviceable process.

The DE2-24P Drive Enclosure supports the following drive configuration options:

- 300GB hard disk drives (HDDs) fully populated with 24 drives
- 900GB HDDs fully populated with 24 drives
- 400GB solid state drives (SSDs) in the following configurations:
  - Six drives and one spare

- 12 drives and one spare
- Six drive upgrade to the current configuration
- 1.6TB SSDs with the following configurations:
  - Six drives and one spare
  - 12 drives and one spare
  - 18 drives and one spare
  - Six drive upgrade to the current configuration

**Important:** The Oracle FS System accepts only Oracle-supplied drives. The capacity and the type of a replacement drive must be same as the other drives in the Drive Enclosure.

The 24 drive locations are numbered 0 to 23 from left to right. The following figure shows the location of the drives on the DE2-24P Drive Enclosure.

**Figure 136: DE2-24P Drive Enclosure drives**



The DE2-24C Drive Enclosure can only be configured with 24, 4TB HDDs.

The 24 drive locations are numbered 0 to 23 from the lower left of the Drive Enclosure to the upper right of the Drive Enclosure. The following figure shows the location of the drives on the DE2-24C Drive Enclosure.

**Figure 137: DE2-24C Drive Enclosure drives**



**CAUTION:** Make sure you can replace the FRU or CRU within 10 minutes of removing the FRU or CRU. Do not remove a FRU or CRU if you cannot replace it within 10 minutes with a FRU or CRU or with a filler panel. If a FRU or CRU slot is left empty, the system can overheat due to improper airflow.

**Important:** Make sure that you remove the correct drive. Removing a drive other than the failed drive can disrupt data access and possibly corrupt data.

The system generates an alert to notify you of a failed drive. The system also notifies you when it detects that a drive might fail soon.

## Replace a Drive Enclosure Drive

A failed Drive Enclosure drive degrades data throughput. Additionally, if more than one drive begins to fail, data loss can occur. Replace a failed drive with a drive of the same type and capacity as soon as possible.

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Make sure that the replacement drive has the same capacity and same type as the drive to be replaced.

**Important:** After you initiate Guided Maintenance to prepare the system for replacing a drive, you must complete the procedure. Do not cancel the replacement process after the replacement process has started. Canceling the replacement process can result in loss of data.

### Procedure Overview

- 1 [Prepare a Drive Enclosure for Component Replacement](#)
- 2 [Remove a Drive](#)
- 3 [Insert a Drive](#)
- 4 [Verify the Status of a Drive Enclosure Component](#)

## Prepare a Drive Enclosure for Component Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware.
- 2 Select Drive Enclosures.  
The GUI displays the Drive Enclosures Overview page. The Drive Enclosures Overview page displays the status of the Drive Enclosure components.
- 3 Select the Drive Enclosure containing the component that you want to replace.
- 4 Select Actions > View.  
The View Drive Enclosure dialog displays the list of replaceable Drive Enclosure components in the Replaceable Unit list.
- 5 From the Replaceable Unit list, select the component that you want to replace and click Replace Component.

Guided Maintenance displays the Introduction page, and guides you through the steps to replace the Drive Enclosure component.

- 6 Click Next.

Guided Maintenance displays the Identify Hardware dialog.

- 7 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

**Identify** Flashes the LEDs on the chassis that contains the failed component.

**Reverse Identify** Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.

- 8 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.


- 9 Click Next.

Guided Maintenance completes the process of preparing the system for Drive Enclosure replacement. After Guided Maintenance prepares the Drive Enclosure for replacing a component, it displays the Replace Hardware dialog box. The Replace Hardware dialog box instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, select System > Alerts and Events > System Alerts.

## Remove a Drive


- 1 On the failed drive, press the drive carrier latch to disengage the drive.

**Figure 138: A DE2-24P Drive Enclosure drive and drive carrier latch**



Legend	1 A drive	2 Drive carrier latch (closeup)
--------	-----------	---------------------------------

Figure 139: A DE2-24C Drive Enclosure drive and drive carrier latch




Legend	1 A drive	2 Drive carrier latch (closeup)
--------	-----------	---------------------------------


- 2 On the failed drive, pull the drive carrier handle fully open to unlock and partially eject the drive from the Drive Enclosure chassis.

**CAUTION:** Do not force open the drive carrier handle. You can damage the drive carrier handle if you apply too much force.

Figure 140: Failed drive removed from a DE2-24C Drive Enclosure



Legend	1 Drive carrier handle	2 Removing the drive
--------	------------------------	----------------------


**Figure 141: Failed drive removed from a DE2-24P Drive Enclosure**

Legend	1 Drive carrier handle	2 Removing the drive
--------	------------------------	----------------------

- 3 On the failed drive, grasp the middle of the drive body and pull the failed drive completely out of the Drive Enclosure chassis.  
Place the failed drive into an antistatic bag.

### Insert a Drive

- 1 Make sure that the drive carrier handle on the replacement drive is in the fully extended position.

**Figure 142: Extended drive carrier handles**


---

Legend	1 Drive carrier handle DE2-24C Drive Enclosure	2 Drive carrier handle DE2-24P Drive Enclosure
--------	---	---


---

- 2 Slide the replacement drive all the way into the Drive Enclosure chassis slot.

**Figure 143: DE2-24C Drive Enclosure and inserted replacement drive**



**Figure 144: DE2-24P Drive Enclosure and inserted replacement drive**



- 3 Press the drive carrier handle closed until it locks into place.  
The green LED should flash green for up to one minute and become steady.  
Return to Guided Maintenance to accept the drive.

## Verify the Status of a Drive Enclosure Component

- 1 From Guided Maintenance, verify that the status of the component is Normal.

Guided Maintenance displays a message stating the component status. A status of Normal requires no action.

- 2 Close Guided Maintenance.

You can also verify component status by navigating to System > Hardware > Drive Enclosures. The Drive Enclosure overview page lists the status of each component.

## Replace an I/O Module

I/O modules provide the input and output transfer of data. While a single I/O module failure does not impact data availability, two I/O module failures degrade data traffic and connectivity. Replace a failed I/O module as soon as possible.


- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.

Each Drive Enclosure has two I/O modules located at the back of the Drive Enclosure. I/O modules are customer replaceable units (CRUs). You can replace a failed I/O module without powering down the Drive Enclosure only if the other I/O module is operational with a status of Normal.

The following figure shows the I/O modules on the back of the DE2-24P and DE2-24C Drive Enclosure types.

**Note:** Notice that I/O module 0 in the DE2-24P Drive Enclosure is inverted.

Figure 145: I/O modules on DE2-24P and DE2-24C Drive Enclosure types



Legend	1 I/O module 0 (DE2-24P Drive Enclosure)	3 I/O module 0 (DE2-24C Drive Enclosure)
	2 I/O module 1 (DE2-24P Drive Enclosure)	4 I/O module 1 (DE2-24C Drive Enclosure)

**CAUTION:** Make sure you can replace the FRU or CRU within 10 minutes of removing the FRU or CRU. Do not remove a FRU or CRU if you cannot replace it within 10 minutes with a FRU or CRU or with a filler panel. If a FRU or CRU slot is left empty, the system can overheat due to improper airflow.

**Note:** Prior to replacement, ensure that only one I/O module has failed and that the other I/O module shows a status of Normal.

Procedure Overview

- 1 [Prepare a Drive Enclosure for Component Replacement](#)
- 2 [Remove an I/O Module](#)
- 3 [Insert an I/O Module](#)
- 4 [Verify the Status of a Drive Enclosure Component](#)

---

## Prepare a Drive Enclosure for Component Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware.
- 2 Select Drive Enclosures.  
The GUI displays the Drive Enclosures Overview page. The Drive Enclosures Overview page displays the status of the Drive Enclosure components.
- 3 Select the Drive Enclosure containing the component that you want to replace.
- 4 Select Actions > View.  
The View Drive Enclosure dialog displays the list of replaceable Drive Enclosure components in the Replaceable Unit list.
- 5 From the Replaceable Unit list, select the component that you want to replace and click Replace Component.  
Guided Maintenance displays the Introduction page, and guides you through the steps to replace the Drive Enclosure component.
- 6 Click Next.  
Guided Maintenance displays the Identify Hardware dialog.
- 7 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.  
You can select one of the following methods to identify the chassis:


Identify	Flashes the LEDs on the chassis that contains the failed component.
Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.
- 8 Click Next.  
Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.
- 9 Click Next.  
Guided Maintenance completes the process of preparing the system for Drive Enclosure replacement. After Guided Maintenance prepares the Drive Enclosure for replacing a component, it displays the Replace Hardware dialog box. The Replace Hardware dialog box instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, select System > Alerts and Events > System Alerts.

## Remove an I/O Module

- 1 When Guided Maintenance prompts you to remove the component, label and disconnect the SAS interface cables that are attached to the I/O module.

After replacing the I/O module, you will be required to restore the SAS interface connectors to the same configuration as prior to replacement.


**Figure 146: I/O module SAS connector ports**



Legend	1 SAS connector ports
--------	-----------------------

- Using your thumb and forefinger, squeeze the release button toward the lever hole to release the lever.

**Figure 147: Remove the I/O module**



Legend	1 Release button
--------	------------------

2 Lever
---------

- Pull the lever and remove the I/O module from the Drive Enclosure.

**Note:** Be careful not to damage the connector pins.

### Insert an I/O Module

- With the lever of the replacement I/O module in the open position, slide the I/O module into the Drive Enclosure chassis.


**Note:** Be careful not to damage the connector pins.

**Note:** Notice that I/O module 0 in the DE2-24P Drive Enclosure is inverted.

- As the replacement I/O module contacts the chassis midplane, close the lever and reattach the release button.

To confirm that the replacement I/O module is properly closed, listen for an audible click or feel the replacement I/O module engage with the chassis midplane.

**Figure 148: Insert the I/O module**




Legend 1 Lever

2 Release button

- 3 Reconnect the SAS interface cables to the SAS connector ports on the I/O module.

Make sure to connect the SAS interface cables in the exact same configuration as prior to replacement.

**Figure 149: I/O module SAS connector ports**



Legend 1 SAS connector ports

- 4 Wait approximately 60 seconds for the I/O module to restart. When the startup process completes, the following indicators should be present:
  - The Power LED emits a steady green light.
  - The Fault LED is off.

- All four Activity LEDs emit a green light for each SAS-2 port that has an SAS interface cable connected to it.

### Verify the Status of a Drive Enclosure Component

- 1 From Guided Maintenance, verify that the status of the component is Normal.

Guided Maintenance displays a message stating the component status. A status of Normal requires no action.

- 2 Close Guided Maintenance.

You can also verify component status by navigating to System > Hardware > Drive Enclosures. The Drive Enclosure overview page lists the status of each component.

### Replace a Power Cooling Module

The power cooling modules provide redundant power control and cooling of the system. If one power cooling module fails, the other power cooling module maintains the power supply and cooling while you replace the failed power cooling module. Electrical overload, inadequate internal and external airflow, dirt and dust, incorrect input voltage, or a short circuit can damage a power cooling module. Replace a failed power cooling module immediately; otherwise, damage from overheating and data loss can occur.


- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.

**WARNING:** Do not remove covers from the power cooling modules. Power cooling modules produce a high-energy hazard.

Each Drive Enclosure has two power cooling modules located at the back of the Drive Enclosure. Power cooling modules are customer replaceable units (CRUs). You can replace a failed power cooling module without powering down the Drive Enclosure only if the other power cooling module is operational with a status of Normal.

The following figure shows the power cooling modules on the DE2-24P Drive Enclosure and the DE2-24C Drive Enclosure.

Figure 150: Power cooling modules (DE2-24P and DE2-24C Drive Enclosures)



Legend	1 Power cooling module 0 (DE2-24P Drive Enclosure)	3 Power cooling module 0 (DE2-24C Drive Enclosure)
	2 Power cooling module 1 (DE2-24P Drive Enclosure)	4 Power cooling module 1 (DE2-24C Drive Enclosure)

**CAUTION:** Make sure you can replace the FRU or CRU within 10 minutes of removing the FRU or CRU. Do not remove a FRU or CRU if you cannot replace it within 10 minutes with a FRU or CRU or with a filler panel. If a FRU or CRU slot is left empty, the system can overheat due to improper airflow.

#### Procedure Overview

- 1 [Prepare a Drive Enclosure for Component Replacement](#)
- 2 [Remove a Power Cooling Module](#)
- 3 [Insert a Power Cooling Module](#)
- 4 [Verify the Status of a Drive Enclosure Component](#)

#### Prepare a Drive Enclosure for Component Replacement

- 1 From Oracle FS System Manager (GUI), navigate to System > Hardware.
- 2 Select Drive Enclosures.

The GUI displays the Drive Enclosures Overview page. The Drive Enclosures Overview page displays the status of the Drive Enclosure components.

- 3 Select the Drive Enclosure containing the component that you want to replace.

- 4 Select Actions > View.

The View Drive Enclosure dialog displays the list of replaceable Drive Enclosure components in the Replaceable Unit list.

- 5 From the Replaceable Unit list, select the component that you want to replace and click Replace Component.

Guided Maintenance displays the Introduction page, and guides you through the steps to replace the Drive Enclosure component.

- 6 Click Next.

Guided Maintenance displays the Identify Hardware dialog.

- 7 From the Identify Hardware dialog, specify how you want to identify the chassis so that you can locate it in the data center.

You can select one of the following methods to identify the chassis:

Identify	Flashes the LEDs on the chassis that contains the failed component.
----------	---

Reverse Identify	Flashes the LEDs on all of the chassis in the system except for the chassis that contains the failed component.
------------------	---

- 8 Click Next.

Based on the method you selected to identify the chassis, the corresponding LEDs flash to help you locate the chassis in the data center.

- 9 Click Next.

Guided Maintenance completes the process of preparing the system for Drive Enclosure replacement. After Guided Maintenance prepares the Drive Enclosure for replacing a component, it displays the Replace Hardware dialog box. The Replace Hardware dialog box instructs you to replace the component. You also receive a System Alert informing you that the component is ready for removal. To review System Alerts, select System > Alerts and Events > System Alerts.

## Remove a Power Cooling Module

- 1 When Guided Maintenance prompts you to remove the component, power off the failed power cooling module.


**Note:** Do not power off the healthy power cooling module.

- 2 Disconnect the power cord tie strap from the faulted power cooling module.
- 3 Unplug the power cord from the failed power cooling module.

- 4 Release the attachment lever.

To release the attachment lever, squeeze together the latch and the opposite side of the failed power cooling module.

**Figure 151: Attachment lever and latch on the power cooling module**



Legend	1 Power cooling module	3 Attachment lever
	2 Latch	

- 5 Gently pull the failed power cooling module out of the Drive Enclosure chassis.


**Note:** Be careful not to damage the connector pins.

### Insert a Power Cooling Module

Before sliding a power cooling into the Drive Enclosure, ensure that the power cooling module is oriented correctly. To ensure correct orientation, align the latch on the power cooling module with the inner area of the Drive Enclosure.

**CAUTION:** Inserting a power cooling module that is not oriented correctly into a Drive Enclosure can damage the power cooling module and the Drive Enclosure.

Figure 152: Power cooling module orientation




Legend 1 Latch on the left power cooling module

2 Latch on the right power cooling module

- 1 With the attachment lever fully open, orient the power cooling module so that the latch aligns with the inner area of the Drive Enclosure and slide the power cooling module into the chassis slot.

Figure 153: Replacement power cooling module with a fully open attachment lever




Legend	1 Power cooling module	2 Opened attachment lever
--------	------------------------	---------------------------

- As the replacement power cooling module contacts the Drive Enclosure chassis midplane, close the attachment lever.

To confirm that the replacement power cooling module is properly closed, listen for an audible click or feel the part engage with the Drive Enclosure chassis midplane.

**Figure 154: Replacement power cooling module (right side)**



Legend	1 Slide replacement power cooling module into Drive Enclosure chassis slot	2 Close the attachment lever
--------	--	------------------------------

- On the replacement power cooling module, make sure that the power switch is off.
- Plug the power cord into the replacement power cooling module.
- Attach the power cord tie strap to the power cord.
- Power on the replacement power cooling module.

When the power-on process completes, the following indicators should be present:

- The Power status LED emits a steady green light.
- All other LEDs are off.

### Verify the Status of a Drive Enclosure Component

- From Guided Maintenance, verify that the status of the component is Normal.

Guided Maintenance displays a message stating the component status. A status of Normal requires no action.

- Close Guided Maintenance.

You can also verify component status by navigating to System > Hardware > Drive Enclosures. The Drive Enclosure overview page lists the status of each component.

# Pilot Replacement Procedures

## Pilot Overview

The Pilot is an out-of-band management controller that directs and manages all system activity.


Each Oracle FS System has one active Pilot and one standby Pilot.

The Pilot provides access to the following:

- All management functions for the Oracle FS System
- System monitoring, alerts, log collection, and automatic log transmission
- Management for restarting, replacing, updating, and recovering Controller and Drive Enclosure resources

The following figure shows the front of the Pilot.

**Figure 155: Pilot**



## Replace a Pilot Battery

The lithium coin-cell battery in the Pilot maintains system time when the Pilot is powered off and a time server is unavailable. The battery also powers the CMOS BIOS system settings of the Oracle FS System. Replace the battery if the Pilot fails to maintain proper time or the battery gets discharged due to wear and tear.


Prerequisites:

- Before handling a component, touch a grounded surface to discharge any static electricity.

- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- Ensure you have a screwdriver or any kind of sharp pointed object.

Each Pilot has a battery located on the Pilot motherboard. Batteries are customer replaceable units (CRUs) and are not hot-serviceable. Replacing the battery requires you to power off the Pilot. The following figure identifies the location of the battery inside the Pilot motherboard.

**Figure 156: Pilot battery**



Legend	1 Pilot battery
	2 Pilot motherboard

**Note:** The battery can be accessed only after removing the cover over the Pilot chassis.

**Note:** Ensure that all power is removed from the Pilot before removing or installing the battery. You must disconnect the power cords from the Pilot before performing these procedures.

#### Procedure Overview

- 1 [Prepare a Pilot for Component Replacement](#)
- 2 [Power Off the Pilot](#)
- 3 [Slide Pilot to Service Position](#)
- 4 [Open Pilot Fan Door](#)
- 5 [Open Pilot Top Cover](#)
- 6 [Remove a Battery](#)
- 7 [Insert a Battery](#)
- 8 [Close Pilot Top Cover](#)

- 9 [Close Pilot Fan Door](#)
- 10 [Slide Pilot to Rack Position](#)
- 11 [Connect Power Cords On the Pilot](#)
- 12 [Verify Component Replacement on the Standby Pilot](#)
- 13 [Verify Component Replacement on the Active Pilot](#)

## Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot.  
Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next.  
Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.
- 6 Click Next.  
Guided Maintenance displays a link to *Pilot Repair Procedures*.
- 7 Click the *Pilot Repair Procedures* link to open and print the procedures.
- 8 Click Next.
  - If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.
  - If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.
  - If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

## Power Off the Pilot


**Note:** Do not power off the Pilot host without ensuring that SSH is enabled on the Oracle FS System. Otherwise, the replacement procedure might fail.

- 1 Notify affected users that the Pilot will be powered off.
- 2 Ensure that the host of the Pilot on which the replacement procedure must be performed is powered off.

## Slide Pilot to Service Position

- 1 Slide the Pilot chassis fully forward until the slide rails lock into position.


**Figure 157: Pilot position during component replacement**



Legend	1 Rack
	2 Pilot chassis
	3 Pilot rails

- 2 When Guided Maintenance prompts you to remove the component, pull the flip handles at front of the Pilot and start sliding the Pilot out of the rack.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Pilot.

**Figure 158: Pilot slide lockout release tabs**

Legend	1 Slide rail lock
	2 Slide lockout release tab


**Note:** The slide-rail locks are located behind the flip-down handles on the front of the Pilot chassis. The slide-rail locks are released when the flip-down handles are pulled down. The slide lockout release tab must be released to push the Pilot chassis back into the rack.

## Open Pilot Fan Door

Press the two fan door release tabs simultaneously forward and swing the Pilot fan door to the open position.

**Note:** Servicing the Pilot fan modules and other components located in the front of the Pilot, such as the front indication module (FIM) and the disk backplanes, require that the fan door be opened. It is also easier to remove the Pilot's top cover if you open the fan door first.

Figure 159: Pilot with fan door open



Legend	1 Fan door release tabs
	2 Pilot fan door in open position


## Open Pilot Top Cover

- 1 Press down on the push button on the Pilot top cover to release the top cover and use the recessed areas to slide the top cover toward the back of the Pilot about 0.5 inches (12.7 mm).

**CAUTION:** Before removing the top cover of the Pilot, power off the Pilot using Guided Maintenance. Removing the Pilot top cover before powering off the Pilot might cause damage to the software image on the Pilot.

**Tip:** Slide out the Pilot top cover by pressing down on the grooves located on both sides of the cover.

Figure 160: Pilot top cover removal




Legend	1 Push button to release top cover
	2 Grooves to slide out top cover

- 2 Lift the cover off the Pilot chassis and set it aside.

## Remove a Battery

- 1 Remove the battery by placing your finger or a pointed tool like a screwdriver under the battery on the side nearest to the back of the Pilot and gently lifting the battery out of the retainer.

**Figure 161: Pilot battery removal**



Legend	1 Pilot battery
	2 Battery socket

- 2 Place the battery on an antistatic mat.


**Note:** Replacing a battery usually resets the CMOS settings to a default value.

## Insert a Battery

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Press the replacement battery into the battery retainer with the positive side (+) facing upwards.

**Figure 162: Battery insertion**

Legend	1 Pilot battery
	2 Battery socket

If the Pilot is configured to synchronize with a network time server using the Network Time Protocol (NTP), the Oracle ILOM clock is reset as soon as the Pilot is powered on and connected to the network. Otherwise, proceed to the next step.

- 3 If the Pilot is not configured to use NTP, reset the Oracle ILOM clock using the Oracle ILOM CLI or the web interface. You can also reprogram the BIOS Setup utility to reprogram the host clock.

For instructions, on setting the Oracle ILOM clock, see the Oracle Integrated Lights Out Manager (ILOM) 3.1 Documentation Library.

## Close Pilot Top Cover

- 1 Place the top cover of the Pilot onto the chassis.

**Tip:** Place the top cover down so that it hangs over the back of the Pilot by about 13 mm (0.5 inches) [1] and the side latches align with the slots in the sides of the Pilot chassis.

**Note:** There are three latching tabs on the sides of the Pilot top cover, two on the right side and one on the left side when viewing the Pilot from the front. There is also a latch on the underside of the top cover in the front left corner near the release button.


- 2 Check both sides of the Pilot chassis to ensure that the four corners of the top cover are fully down and flush with the chassis.

**Note:** If the cover corners are not flush with the Pilot chassis, slide the cover towards the back of the chassis until you can position the cover correctly.

**Note:** If the top cover is not correctly positioned before attempting to slide the cover forward, the internal latch that is on the underside of the cover might be damaged.

- 3 Gently slide the top cover along the grooves of the Pilot by pressing down on either side of the top cover until it locks into place and you hear an audible click.

**Figure 163: Pilot top cover installed**



Legend	1 Top cover
	2 Grooves to slide the top cover
	3 Fan door


## Close Pilot Fan Door

Close the Pilot fan door by pressing the two release tabs on both sides of the fan door until it locks into place.

## Slide Pilot to Rack Position

- 1 Simultaneously pull and hold the two release tabs, one on each side of the Pilot, toward the front of the Pilot while you push the Pilot into the rack.

Figure 164: Location of the Pilot release tabs



**Note:** As you push the Pilot into the rack, verify that the cable management arm (CMA) retracts without binding.

**Note:** To pull the Pilot release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 Continue pushing the Pilot into the rack until the slide-rail locks on the front of the Pilot engage the slide-rail assemblies.

**Note:** The Pilot locks into the rack position with an audible click.

## Connect Power Cords On the Pilot

Reconnect the power cords to the Pilot.

**Note:** After the power cords are connected, the green SP LED and the OK LED both start to blink.

**Note:** Do not turn on the power to the Pilot host immediately. The power on the Pilot host is turned on only after updating the Pilot BIOS. Turning on the power to the Pilot host early can prevent the Pilot from booting after the Pilot BIOS is updated.

## Verify Component Replacement on the Standby Pilot

If you replaced a component on the standby Pilot, complete the following steps to verify the status of the Pilot:

- 1 Return to Guided Maintenance and click Finish.  
Guided Maintenance closes and the GUI displays the Pilot Overview page.
- 2 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Verify Component Replacement on the Active Pilot

If you replaced a component on the active Pilot, complete the following steps to verify the status of the Pilot:

- 1 Restart Oracle FS System Manager (GUI).
- 2 Navigate to System > Hardware > Pilots.  
The GUI displays the Pilot Overview page.
- 3 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Replace a Pilot SAS HBA

A serial attached SCSI (SAS) host bus adapter (HBA) provides access to the SAS hard disk drive (HDD) in the Pilot. A damaged SAS HBA can result in losing access to the SAS HDD to which the SAS HBA connects using the SAS cable bundle and must be replaced as soon as possible.


### Prerequisites:

- Before handling a component, touch a grounded surface to discharge any static electricity.
- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
- Use only the filler panels provided with the Pilot to maintain proper airflow and EMI conformance for empty slots inside the Pilot.
- Fail over the Pilot before replacing the component using Guided Maintenance

**Note:** The Pilot must be failed over to prevent data loss or data corruption during the component replacement process.

Each Pilot supports a single 6 Gb/s SAS HBA on the PCIe slot of its riser. To service a SAS HBA, the PCIe risers inside the Pilot and the filler panels inside the riser must be removed. The SAS HBA is a customer replaceable unit (CRU) and is not hot-serviceable. However, replacing a SAS HBA will require failing over all operations to the other Pilot. The following figure shows the location of the SAS HBA inside a riser board assembly.

Figure 165: SAS HBA



Legend	1 Riser board assembly
	2 SAS HBA

**Note:** The SAS HBA can be accessed only after removing the cover over the Pilot chassis.

**Note:** To replace a SAS HBA, you do not need to remove the Pilot from the rack but extend it along the Pilot rails using the cable management arm (CMA).

**Note:** The riser that contains the failed SAS HBA must be removed before servicing the HBA.

#### Procedure Overview

- 1 *Prepare a Pilot for Component Replacement*
- 2 *Power Off the Pilot*
- 3 *Slide Pilot to Service Position*
- 4 *Open Pilot Fan Door*
- 5 *Open Pilot Top Cover*
- 6 *Remove a SAS HBA*
- 7 *Insert a SAS HBA*
- 8 *Close Pilot Top Cover*
- 9 *Close Pilot Fan Door*
- 10 *Slide Pilot to Rack Position*
- 11 *Connect Power Cords On the Pilot*
- 12 *Verify Component Replacement on the Standby Pilot*
- 13 *Verify Component Replacement on the Active Pilot*

---

## Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot.  
Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next.  
Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.
- 6 Click Next.  
Guided Maintenance displays a link to *Pilot Repair Procedures*.
- 7 Click the *Pilot Repair Procedures* link to open and print the procedures.
- 8 Click Next.
  - If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.
  - If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.
  - If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

## Power Off the Pilot

**Note:** Do not power off the Pilot host without ensuring that SSH is enabled on the Oracle FS System. Otherwise, the replacement procedure might fail.


- 1 Notify affected users that the Pilot will be powered off.

- 2 Ensure that the host of the Pilot on which the replacement procedure must be performed is powered off.

## Slide Pilot to Service Position

- 1 Slide the Pilot chassis fully forward until the slide rails lock into position.


Figure 166: Pilot position during component replacement



Legend	1 Rack
	2 Pilot chassis
	3 Pilot rails

- 2 When Guided Maintenance prompts you to remove the component, pull the flip handles at front of the Pilot and start sliding the Pilot out of the rack.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Pilot.

**Figure 167: Pilot slide lockout release tabs**

Legend	1 Slide rail lock
	2 Slide lockout release tab


**Note:** The slide-rail locks are located behind the flip-down handles on the front of the Pilot chassis. The slide-rail locks are released when the flip-down handles are pulled down. The slide lockout release tab must be released to push the Pilot chassis back into the rack.

## Open Pilot Fan Door

Press the two fan door release tabs simultaneously forward and swing the Pilot fan door to the open position.

**Note:** Servicing the Pilot fan modules and other components located in the front of the Pilot, such as the front indication module (FIM) and the disk backplanes, require that the fan door be opened. It is also easier to remove the Pilot's top cover if you open the fan door first.

Figure 168: Pilot with fan door open



Legend	1 Fan door release tabs
	2 Pilot fan door in open position


## Open Pilot Top Cover

- 1 Press down on the push button on the Pilot top cover to release the top cover and use the recessed areas to slide the top cover toward the back of the Pilot about 0.5 inches (12.7 mm).

**CAUTION:** Before removing the top cover of the Pilot, power off the Pilot using Guided Maintenance. Removing the Pilot top cover before powering off the Pilot might cause damage to the software image on the Pilot.

**Tip:** Slide out the Pilot top cover by pressing down on the grooves located on both sides of the cover.

Figure 169: Pilot top cover removal



Legend	1 Push button to release top cover
	2 Grooves to slide out top cover

- 2 Lift the cover off the Pilot chassis and set it aside.

## Remove a SAS HBA

Identify the riser in which the failed SAS HBA is located.

**Note:** There are three riser board assemblies inside the Pilot chassis.


## Insert a SAS HBA

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Reconnect the SAS cable bundle into the HBA inside the riser.
- 3 Orient the SAS HBA so that the brackets of the HBA align with the alignment pin in the PCIe slot of the riser.

**Figure 170: SAS HBA insertion into the riser**



Legend	1 Riser board
	2 SAS HBA

**Important:** Hold the SAS HBA by the edges. Do not touch the metal contacts on the bottom of the card.

- 4 Push the connectors on the edge of the SAS HBA into the PCIe slot by pushing firmly to seat the card.
- 5 Apply firm pressure on each end of the SAS HBA alternately until it clicks into place in the riser socket.

**CAUTION:** Support the SAS HBA and the riser as necessary to prevent excessive flexure. Otherwise, the SAS HBA or the riser card might break.

- 6 Insert the riser into the black slot on the Pilot motherboard and slide the release tab backward to secure the riser in position.

## Close Pilot Top Cover

- 1 Place the top cover of the Pilot onto the chassis.

**Tip:** Place the top cover down so that it hangs over the back of the Pilot by about 13 mm (0.5 inches) [1] and the side latches align with the slots in the sides of the Pilot chassis.

**Note:** There are three latching tabs on the sides of the Pilot top cover, two on the right side and one on the left side when viewing the Pilot from the front. There is also a latch on the underside of the top cover in the front left corner near the release button.


- 2 Check both sides of the Pilot chassis to ensure that the four corners of the top cover are fully down and flush with the chassis.

**Note:** If the cover corners are not flush with the Pilot chassis, slide the cover towards the back of the chassis until you can position the cover correctly.

**Note:** If the top cover is not correctly positioned before attempting to slide the cover forward, the internal latch that is on the underside of the cover might be damaged.

- 3 Gently slide the top cover along the grooves of the Pilot by pressing down on either side of the top cover until it locks into place and you hear an audible click.

**Figure 171: Pilot top cover installed**



Legend	1 Top cover
	2 Grooves to slide the top cover
	3 Fan door


## Close Pilot Fan Door

Close the Pilot fan door by pressing the two release tabs on both sides of the fan door until it locks into place.

## Slide Pilot to Rack Position

- 1 Simultaneously pull and hold the two release tabs, one on each side of the Pilot, toward the front of the Pilot while you push the Pilot into the rack.

**Figure 172: Location of the Pilot release tabs**



**Note:** As you push the Pilot into the rack, verify that the cable management arm (CMA) retracts without binding.

**Note:** To pull the Pilot release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 Continue pushing the Pilot into the rack until the slide-rail locks on the front of the Pilot engage the slide-rail assemblies.

**Note:** The Pilot locks into the rack position with an audible click.

## Connect Power Cords On the Pilot

Reconnect the power cords to the Pilot.

**Note:** After the power cords are connected, the green SP LED and the OK LED both start to blink.

**Note:** Do not turn on the power to the Pilot host immediately. The power on the Pilot host is turned on only after updating the Pilot BIOS. Turning on the power to the Pilot host early can prevent the Pilot from booting after the Pilot BIOS is updated.

---

## Verify Component Replacement on the Standby Pilot

If you replaced a component on the standby Pilot, complete the following steps to verify the status of the Pilot:

- 1 Return to Guided Maintenance and click Finish.

Guided Maintenance closes and the GUI displays the Pilot Overview page.

- 2 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Verify Component Replacement on the Active Pilot

If you replaced a component on the active Pilot, complete the following steps to verify the status of the Pilot:

- 1 Restart Oracle FS System Manager (GUI).

- 2 Navigate to System > Hardware > Pilots.

The GUI displays the Pilot Overview page.

- 3 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Replace a Pilot Riser

Riser board assemblies include printed circuit boards and PCIe slots in which HBAs can be inserted based on system type and configuration. A failed riser board assembly can cause read and write errors because the HBAs will not be able to function properly. Replace a failed riser board as soon as possible.


### Prerequisites:

- Before handling a component, touch a grounded surface to discharge any static electricity.
- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
- Fail over the Pilot before replacing the component using Guided Maintenance.

**Note:** The Pilot must be failed over to prevent data loss or data corruption during the component replacement process.

Each Pilot contains three riser board assemblies (R1 to R3 – left to right) located side-by-side at the back of the Pilot next to the power supplies. Risers are customer replaceable units (CRUs). The SAS HBA is the only HBA that is inserted into the Pilot riser. Replacing a riser requires you to power off the Pilot. The following figure shows the location of the riser board assemblies on the Pilot motherboard.

Figure 173: Riser locations



Legend	1 Pilot motherboard
	2 Risers

**Note:** The risers can be accessed only after removing the cover over the Pilot chassis.

**Important:** Disconnect any cables connected to the HBAs in the riser that must be replaced.

**Note:** To replace a riser, you do not need to remove the Pilot from the rack but extend the Pilot along the Pilot rails using the cable management arm (CMA).

#### Procedure Overview

- 1 *Prepare a Pilot for Component Replacement*
- 2 *Power Off the Pilot*
- 3 *Slide Pilot to Service Position*
- 4 *Open Pilot Fan Door*
- 5 *Open Pilot Top Cover*
- 6 *Remove a Riser*
- 7 *Insert a Riser*
- 8 *Close Pilot Top Cover*

- 9 [Close Pilot Fan Door](#)
- 10 [Slide Pilot to Rack Position](#)
- 11 [Connect Power Cords On the Pilot](#)
- 12 [Verify Component Replacement on the Standby Pilot](#)
- 13 [Verify Component Replacement on the Active Pilot](#)

## Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot.  
Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next.  
Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.
- 6 Click Next.  
Guided Maintenance displays a link to *Pilot Repair Procedures*.
- 7 Click the *Pilot Repair Procedures* link to open and print the procedures.
- 8 Click Next.
  - If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.
  - If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.
  - If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

## Power Off the Pilot


**Note:** Do not power off the Pilot host without ensuring that SSH is enabled on the Oracle FS System. Otherwise, the replacement procedure might fail.

- 1 Notify affected users that the Pilot will be powered off.
- 2 Ensure that the host of the Pilot on which the replacement procedure must be performed is powered off.

## Slide Pilot to Service Position

- 1 Slide the Pilot chassis fully forward until the slide rails lock into position.


**Figure 174: Pilot position during component replacement**



Legend	1 Rack
	2 Pilot chassis
	3 Pilot rails

- 2 When Guided Maintenance prompts you to remove the component, pull the flip handles at front of the Pilot and start sliding the Pilot out of the rack.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Pilot.

**Figure 175: Pilot slide lockout release tabs**

Legend	1 Slide rail lock
	2 Slide lockout release tab


**Note:** The slide-rail locks are located behind the flip-down handles on the front of the Pilot chassis. The slide-rail locks are released when the flip-down handles are pulled down. The slide lockout release tab must be released to push the Pilot chassis back into the rack.

## Open Pilot Fan Door

Press the two fan door release tabs simultaneously forward and swing the Pilot fan door to the open position.

**Note:** Servicing the Pilot fan modules and other components located in the front of the Pilot, such as the front indication module (FIM) and the disk backplanes, require that the fan door be opened. It is also easier to remove the Pilot's top cover if you open the fan door first.

Figure 176: Pilot with fan door open



Legend	1 Fan door release tabs
	2 Pilot fan door in open position


## Open Pilot Top Cover

- 1 Press down on the push button on the Pilot top cover to release the top cover and use the recessed areas to slide the top cover toward the back of the Pilot about 0.5 inches (12.7 mm).

**CAUTION:** Before removing the top cover of the Pilot, power off the Pilot using Guided Maintenance. Removing the Pilot top cover before powering off the Pilot might cause damage to the software image on the Pilot.

**Tip:** Slide out the Pilot top cover by pressing down on the grooves located on both sides of the cover.

Figure 177: Pilot top cover removal




Legend	1 Push button to release top cover
	2 Grooves to slide out top cover

- 2 Lift the cover off the Pilot chassis and set it aside.

## Remove a Riser

- 1 Press on the release tab of the riser to release the riser from the Pilot motherboard.
- 2 Carefully pull up the release tab on the riser to release the filler panel or HBA card (if any) and pull the riser straight up.

**Figure 178: Riser board assembly removal**




Legend	1 Release tab on the riser
	2 Riser
	3 HBA
	4 Motherboard

**Note:** Remove any host bus adapter (HBA) cables or HBAs that are on the failed riser assemblies using the appropriate procedure. Make a note of the riser slot in which the HBAs are installed and the SAS cables that are connected to the HBAs.

- 3 Disconnect the SAS cable bundle that connects the SAS HBA and the Pilot disk backplane and set aside.

Figure 179: Disconnect SAS cable bundle



Legend	1 Riser
	2 HBA
	3 SAS cable bundle

- Remove any HBA cards (usually the SAS card) that are inserted into the PCI-express (PCI-e) slots of the riser and place the riser and the HBA cards on an antistatic mat.


**Note:** Retain the HBA cards because they will be placed inside the replacement riser board assembly.

## Insert a Riser

- Unpack the component from its shipping carton.
 

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.
- Insert the HBA cards that were placed aside and insert them in the same PCIe slots as before within the replacement riser.
- Reconnect the SAS cable bundle into the HBA inside the riser.
- Insert the riser into the black slot on the Pilot motherboard and slide the release tab backward to secure the riser in position.

Figure 180: Pilot riser insertion



Legend	1 Release tab
	2 Riser
	3 HBA
	4 Pilot motherboard

- 5 Insert the filler panels, if any, inside the riser.

## Close Pilot Top Cover

- 1 Place the top cover of the Pilot onto the chassis.

**Tip:** Place the top cover down so that it hangs over the back of the Pilot by about 13 mm (0.5 inches) [1] and the side latches align with the slots in the sides of the Pilot chassis.

**Note:** There are three latching tabs on the sides of the Pilot top cover, two on the right side and one on the left side when viewing the Pilot from the front. There is also a latch on the underside of the top cover in the front left corner near the release button.


- 2 Check both sides of the Pilot chassis to ensure that the four corners of the top cover are fully down and flush with the chassis.

**Note:** If the cover corners are not flush with the Pilot chassis, slide the cover towards the back of the chassis until you can position the cover correctly.

**Note:** If the top cover is not correctly positioned before attempting to slide the cover forward, the internal latch that is on the underside of the cover might be damaged.

- 3 Gently slide the top cover along the grooves of the Pilot by pressing down on either side of the top cover until it locks into place and you hear an audible click.

**Figure 181: Pilot top cover installed**



Legend	1 Top cover
	2 Grooves to slide the top cover
	3 Fan door


## Close Pilot Fan Door

Close the Pilot fan door by pressing the two release tabs on both sides of the fan door until it locks into place.

## Slide Pilot to Rack Position

- 1 Simultaneously pull and hold the two release tabs, one on each side of the Pilot, toward the front of the Pilot while you push the Pilot into the rack.

Figure 182: Location of the Pilot release tabs



**Note:** As you push the Pilot into the rack, verify that the cable management arm (CMA) retracts without binding.

**Note:** To pull the Pilot release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 Continue pushing the Pilot into the rack until the slide-rail locks on the front of the Pilot engage the slide-rail assemblies.

**Note:** The Pilot locks into the rack position with an audible click.

## Connect Power Cords On the Pilot

Reconnect the power cords to the Pilot.

**Note:** After the power cords are connected, the green SP LED and the OK LED both start to blink.

**Note:** Do not turn on the power to the Pilot host immediately. The power on the Pilot host is turned on only after updating the Pilot BIOS. Turning on the power to the Pilot host early can prevent the Pilot from booting after the Pilot BIOS is updated.

## Verify Component Replacement on the Standby Pilot

If you replaced a component on the standby Pilot, complete the following steps to verify the status of the Pilot:

- 1 Return to Guided Maintenance and click Finish.  
Guided Maintenance closes and the GUI displays the Pilot Overview page.
- 2 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Verify Component Replacement on the Active Pilot

If you replaced a component on the active Pilot, complete the following steps to verify the status of the Pilot:

- 1 Restart Oracle FS System Manager (GUI).
- 2 Navigate to System > Hardware > Pilots.  
The GUI displays the Pilot Overview page.
- 3 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.


## Replace a Pilot Power Supply

Power supplies, which exist in pairs, provide DC to all of the Pilot components. If one power supply fails, the other supply carries the full load. This situation creates a risk of Pilot failure should the other power supply also fail.

- Prerequisites:
- Before handling a component, touch a grounded surface to discharge any static electricity.
  - Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
  - Ensure that you have a similar replacement power supply available before you start the replacement procedure.
  - Initiate Guided Maintenance only when you are able to replace the power supplies immediately.

Each Pilot has a pair of power supplies that are located at the back of the Pilot. Power supplies are customer replaceable units (CRUs). Replacing a failed power supply does not require you to bring the Pilot offline, provided that the other power supply is online and working. The following figure shows the location of the Pilot power supplies.

**Figure 183: Location of the Pilot power supplies**



Legend 1 Power supplies (PS-0 on left) and (PS-1 on right)

---

**Note:** To replace a power supply, the left side of the CMA must be disengaged from the end of the slide before the power supply can be pulled out. Disengaging the CMA reduces the risk of damaging the cables.

**Important:** Do not remove the failed power supply until you have a replacement power supply to ensure proper airflow in the Pilot.

#### Procedure Overview

- 1 [Prepare a Pilot for Component Replacement](#)
- 2 [Remove a Power Supply](#)
- 3 [Insert a Power Supply](#)
- 4 [Verify Power Supply Replacement on a Pilot](#)

### Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot.  
Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next.  
Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.
- 6 Click Next.  
Guided Maintenance displays a link to *Pilot Repair Procedures*.
- 7 Click the *Pilot Repair Procedures* link to open and print the procedures.
- 8 Click Next.
  - If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.
  - If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.

- If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

## Remove a Power Supply


- 1 Proceed to step 3 if you have already removed the power cords. Otherwise, from the back of the Pilot, remove the velcro that holds the power cord from the failed power supply.

**Note:** You might need to swing the cable management arm (CMA) out of the way to access the power supplies. If the CMA is still in the way, extend the Pilot approximately 20 cm (8 inches) out of the front of the rack.

**Note:** The fans of a failed power supply may still be spinning when the system is powered on. You can remove a power supply while the fans are still spinning.

- 2 Disconnect the power cord from the failed power supply.
- 3 While holding the power supply handle with one hand, use the other hand to push the power supply latch to the left.

**Figure 184: Power supply removal**



Legend	1 Power supplies (PS0 and PS1)
	2 Power supply handle
	3 Power supply compartment

- 4 Pull the power supply out of the chassis and place the power supply on an antistatic mat.

**CAUTION:** Whenever you remove a power supply, you should replace it with another power supply; otherwise, the Pilot might overheat due to improper airflow.


## Insert a Power Supply

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Align the replacement power supply with the empty power supply compartment.
- 3 Slide the power supply into the bay until it is fully seated.

**Figure 185: Power supply insertion**



Legend	1 Power supplies (PS0 and PS1)
	2 Power supply handle
	3 Power supply compartment

**Note:** Listen for an audible click or feel the power supply engage to confirm that the power supply is properly seated.

- 4 Re-connect the power cord into the replacement power supply.
- 5 Attach the power cord velcro to the power supply.

**Note:** If you pulled the Pilot out of the rack to make it easier to remove the power supply, push the Pilot into the rack until the slide-rail locks at the front of the Pilot engage the slide-rail assemblies.

## Verify Power Supply Replacement on a Pilot

- 1 Return to Guided Maintenance and click Finish.

Guided Maintenance closes and the GUI displays the Pilot Overview page.

2 From the Pilot Overview page, review the status of the Pilot.

A status of Normal requires no action.

## Replace a Pilot Fan Module


If a fan module fails, the Pilot internal temperature rises quickly. If the temperature exceeds normal thresholds, the system issues critical alerts. Replace fan modules as soon as possible to prevent high-temperature buildup.

Prerequisites:

- Before handling a component, touch a grounded surface to discharge any static electricity.
- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- If you need to replace multiple fan module, replace only one fan module at a time and within five minutes.
- Initiate Guided Maintenance only when you are able to replace the fan module immediately.

Each Pilot has four fan modules that are located side-by-side at the center inside the Pilot chassis. A fan module is a customer replaceable unit (CRU) and is hot-serviceable. Replacing a fan module does not require you to bring the Pilot offline. The following figure shows the location of the Pilot fan modules.

**Figure 186: Fan module location**



Legend 1 Fan module

2 Fan compartment

3 Fan door

---

4 Pilot
---------

**Note:** The fan module can be accessed only after removing the cover over the Pilot chassis.

**Note:** To replace a fan module, you do not need to remove the Pilot from the rack but extend it along the Pilot rails using the cable management arm (CMA).

#### Procedure Overview

- 1 [Prepare a Pilot for Component Replacement](#)
- 2 [Slide Pilot to Service Position](#)
- 3 [Open Pilot Fan Door](#)
- 4 [Remove a Fan Module](#)
- 5 [Insert a Fan Module](#)
- 6 [Close Pilot Fan Door](#)
- 7 [Slide Pilot to Rack Position](#)
- 8 [Verify Component Replacement on the Standby Pilot](#)
- 9 [Verify Component Replacement on the Active Pilot](#)

#### Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot. Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next. Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.
- 6 Click Next. Guided Maintenance displays a link to *Pilot Repair Procedures*.
- 7 Click the *Pilot Repair Procedures* link to open and print the procedures.
- 8 Click Next.
  - If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can

safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.


- If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.
- If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

### Slide Pilot to Service Position

- 1 Slide the Pilot chassis fully forward until the slide rails lock into position.

**Figure 187: Pilot position during component replacement**



Legend 1 Rack


2 Pilot chassis

3 Pilot rails

- When Guided Maintenance prompts you to remove the component, pull the flip handles at front of the Pilot and start sliding the Pilot out of the rack.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Pilot.

**Figure 188: Pilot slide lockout release tabs**



Legend	1 Slide rail lock
	2 Slide lockout release tab


**Note:** The slide-rail locks are located behind the flip-down handles on the front of the Pilot chassis. The slide-rail locks are released when the flip-down handles are pulled down. The slide lockout release tab must be released to push the Pilot chassis back into the rack.

## Open Pilot Fan Door

Press the two fan door release tabs simultaneously forward and swing the Pilot fan door to the open position.

**Note:** Servicing the Pilot fan modules and other components located in the front of the Pilot, such as the front indication module (FIM) and the disk backplanes, require that the fan door be opened. It is also easier to remove the Pilot's top cover if you open the fan door first.

Figure 189: Pilot with fan door open




Legend	1 Fan door release tabs
	2 Pilot fan door in open position

## Remove a Fan Module

- 1 Using your thumb and forefinger on both sides of the fan module tab, gently lift the fan module from the fan compartment.

Figure 190: Pilot fan module removal



Legend	1 Fan module tab
	2 Fan modules
	3 Fan door

**Note:** When removing a fan module, do not rock it back and forth. Rocking the fan module can cause damage to the motherboard connectors.

- 2 Set the fan module aside on an antistatic mat.

**Note:** When replacing a fan module, do not service any other components unless the system is powered off and the power cords are removed.


## Insert a Fan Module

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Grasp the fan module tabs and press the fan down firmly into the fan module compartment.

**Figure 191: Fan module insertion**



Legend	1 Fan module tab
	2 Fan modules
	3 Fan door

**Note:** Apply firm pressure to fully seat the fan module into the fan compartment. The fan modules are notched to ensure that they are installed in the correct orientation.

- 3 Press down on the fan module and apply firm pressure to fully seat the fan module.


## Close Pilot Fan Door

Close the Pilot fan door by pressing the two release tabs on both sides of the fan door until it locks into place.

## Slide Pilot to Rack Position

- 1 Simultaneously pull and hold the two release tabs, one on each side of the Pilot, toward the front of the Pilot while you push the Pilot into the rack.

**Figure 192: Location of the Pilot release tabs**



**Note:** As you push the Pilot into the rack, verify that the cable management arm (CMA) retracts without binding.

**Note:** To pull the Pilot release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 Continue pushing the Pilot into the rack until the slide-rail locks on the front of the Pilot engage the slide-rail assemblies.

**Note:** The Pilot locks into the rack position with an audible click.

## Verify Component Replacement on the Standby Pilot

If you replaced a component on the standby Pilot, complete the following steps to verify the status of the Pilot:

- 1 Return to Guided Maintenance and click Finish.  
Guided Maintenance closes and the GUI displays the Pilot Overview page.
- 2 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Verify Component Replacement on the Active Pilot

If you replaced a component on the active Pilot, complete the following steps to verify the status of the Pilot:

- 1 Restart Oracle FS System Manager (GUI).
- 2 Navigate to System > Hardware > Pilots.  
The GUI displays the Pilot Overview page.
- 3 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Replace a Pilot DIMM

Dual in-line memory modules (DIMMs) provide random access memory (RAM) for the central processing units (CPUs) in the Pilot. A failed DIMM would cause the Pilot to fail and must be replaced as soon as possible.


### Prerequisites:

- Before handling a component, touch a grounded surface to discharge any static electricity.
- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- Ensure that all DIMM slots are filled with either filler panels or DIMMs to ensure proper airflow.
- Fail over the Pilot before replacing the component using Guided Maintenance.

**Note:** The Pilot must be failed over to prevent data loss or data corruption during the component replacement process.

Each Pilot has two standard DIMMs with an 8 GB memory. DIMMs are connected to the DIMM slots located on both sides of the central processing unit (CPUs) and heatsinks on the Pilot motherboard. DIMMs are customer replaceable units (CRUs) but are not hot-swappable. Replacing a DIMM requires you to power off the Pilot. The following figure shows the location of the DIMMs on the Pilot motherboard and DIMM LEDs.

**Figure 193: Location of the DIMMs on the Pilot motherboard**



Legend	1 DIMMs
	2 Motherboard
	3 DIMM LED

**Note:** The DIMMs can be accessed only after removing the cover over the Pilot chassis.

**Note:** To replace a DIMM, you do not need to remove the Pilot from the rack but extend it along the Pilot rails using the cable management arm (CMA).

#### Procedure Overview

- 1 *Prepare a Pilot for Component Replacement*
- 2 *Power Off the Pilot*
- 3 *Slide Pilot to Service Position*
- 4 *Open Pilot Fan Door*
- 5 *Open Pilot Top Cover*
- 6 *Remove a Pilot DIMM*
- 7 *Insert a Pilot DIMM*
- 8 *Close Pilot Top Cover*
- 9 *Close Pilot Fan Door*
- 10 *Slide Pilot to Rack Position*
- 11 *Connect Power Cords On the Pilot*
- 12 *Verify Component Replacement on the Standby Pilot*
- 13 *Verify Component Replacement on the Active Pilot*

#### Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot.  
Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next.  
Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.

6 Click Next.

Guided Maintenance displays a link to *Pilot Repair Procedures*.

7 Click the *Pilot Repair Procedures* link to open and print the procedures.

8 Click Next.

- If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.
- If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.
- If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

## Power Off the Pilot


**Note:** Do not power off the Pilot host without ensuring that SSH is enabled on the Oracle FS System. Otherwise, the replacement procedure might fail.

- 1 Notify affected users that the Pilot will be powered off.
- 2 Ensure that the host of the Pilot on which the replacement procedure must be performed is powered off.

## Slide Pilot to Service Position

- 1 Slide the Pilot chassis fully forward until the slide rails lock into position.


Figure 194: Pilot position during component replacement



Legend	1 Rack
	2 Pilot chassis
	3 Pilot rails

- 2 When Guided Maintenance prompts you to remove the component, pull the flip handles at front of the Pilot and start sliding the Pilot out of the rack.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Pilot.

**Figure 195: Pilot slide lockout release tabs**

Legend	1 Slide rail lock
	2 Slide lockout release tab


**Note:** The slide-rail locks are located behind the flip-down handles on the front of the Pilot chassis. The slide-rail locks are released when the flip-down handles are pulled down. The slide lockout release tab must be released to push the Pilot chassis back into the rack.

## Open Pilot Fan Door

Press the two fan door release tabs simultaneously forward and swing the Pilot fan door to the open position.

**Note:** Servicing the Pilot fan modules and other components located in the front of the Pilot, such as the front indication module (FIM) and the disk backplanes, require that the fan door be opened. It is also easier to remove the Pilot's top cover if you open the fan door first.

Figure 196: Pilot with fan door open



Legend	1 Fan door release tabs
	2 Pilot fan door in open position


## Open Pilot Top Cover

- 1 Press down on the push button on the Pilot top cover to release the top cover and use the recessed areas to slide the top cover toward the back of the Pilot about 0.5 inches (12.7 mm).

**CAUTION:** Before removing the top cover of the Pilot, power off the Pilot using Guided Maintenance. Removing the Pilot top cover before powering off the Pilot might cause damage to the software image on the Pilot.

**Tip:** Slide out the Pilot top cover by pressing down on the grooves located on both sides of the cover.

Figure 197: Pilot top cover removal




Legend	1 Push button to release top cover
	2 Grooves to slide out top cover

- 2 Lift the cover off the Pilot chassis and set it aside.

## Remove a Pilot DIMM

- 1 Remove the DIMM by pressing down on the tabs on both sides of the DIMM to unlock it from the slot.

**Figure 198: Pilot DIMM removal**



Legend 1 DIMM

2 DIMM slot

3 DIMM tab

**Note:** While inserting or removing DIMMs, ensure that there is no interference with the cables. Pulling or pressing down on the cables might cause damage to the cables during the replacement procedure.

- 2 Lift out the DIMM and set aside on an antistatic mat.

**Note:** Visually inspect the DIMM slots, and the DIMM, for physical damage by checking for cracked or broken plastic in the slot.

**Note:** Sometimes DIMMs might fault because of dust or improper alignment or damaged slots. Use only compressed air to dust DIMMs.

## Insert a Pilot DIMM

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Press the DIMM fully into the DIMM slot and ensure that the tabs on both sides of the DIMM are locked.

**Important:** Ensure that the notch in the DIMM lines up with the key in the slot.

**Note:** Replace only one DIMM at a time to make sure that they are inserted into the correct slots. Attempting to insert multiple DIMMs into the slots might damage the DIMMs due to excessive flexure.

**Note:** Never leave a DIMM slot unpopulated. Insert filler panels into empty DIMM slots to ensure proper air flow inside the Pilot.

## Close Pilot Top Cover

- 1 Place the top cover of the Pilot onto the chassis.

**Tip:** Place the top cover down so that it hangs over the back of the Pilot by about 13 mm (0.5 inches) [1] and the side latches align with the slots in the sides of the Pilot chassis.

**Note:** There are three latching tabs on the sides of the Pilot top cover, two on the right side and one on the left side when viewing the Pilot from the front. There is also a latch on the underside of the top cover in the front left corner near the release button.


- 2 Check both sides of the Pilot chassis to ensure that the four corners of the top cover are fully down and flush with the chassis.

**Note:** If the cover corners are not flush with the Pilot chassis, slide the cover towards the back of the chassis until you can position the cover correctly.

**Note:** If the top cover is not correctly positioned before attempting to slide the cover forward, the internal latch that is on the underside of the cover might be damaged.

- 3 Gently slide the top cover along the grooves of the Pilot by pressing down on either side of the top cover until it locks into place and you hear an audible click.

Figure 199: Pilot top cover installed



Legend	1 Top cover
	2 Grooves to slide the top cover
	3 Fan door


## Close Pilot Fan Door

Close the Pilot fan door by pressing the two release tabs on both sides of the fan door until it locks into place.

## Slide Pilot to Rack Position

- 1 Simultaneously pull and hold the two release tabs, one on each side of the Pilot, toward the front of the Pilot while you push the Pilot into the rack.

Figure 200: Location of the Pilot release tabs



**Note:** As you push the Pilot into the rack, verify that the cable management arm (CMA) retracts without binding.

**Note:** To pull the Pilot release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 Continue pushing the Pilot into the rack until the slide-rail locks on the front of the Pilot engage the slide-rail assemblies.

**Note:** The Pilot locks into the rack position with an audible click.

## Connect Power Cords On the Pilot

Reconnect the power cords to the Pilot.

**Note:** After the power cords are connected, the green SP LED and the OK LED both start to blink.

**Note:** Do not turn on the power to the Pilot host immediately. The power on the Pilot host is turned on only after updating the Pilot BIOS. Turning on the power to the Pilot host early can prevent the Pilot from booting after the Pilot BIOS is updated.

## Verify Component Replacement on the Standby Pilot

If you replaced a component on the standby Pilot, complete the following steps to verify the status of the Pilot:

- 1 Return to Guided Maintenance and click Finish.  
Guided Maintenance closes and the GUI displays the Pilot Overview page.
- 2 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

## Verify Component Replacement on the Active Pilot

If you replaced a component on the active Pilot, complete the following steps to verify the status of the Pilot:

- 1 Restart Oracle FS System Manager (GUI).
- 2 Navigate to System > Hardware > Pilots.  
The GUI displays the Pilot Overview page.
- 3 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

---

## Replace a Pilot Chassis

If an integrated riveted component of a Pilot chassis is damaged, the chassis must be replaced as soon as possible.

**Prerequisites:**

- Ensure that you have a Phillips Number 2 screwdriver with at least a 4-inch shaft.
- Before handling a component, touch a grounded surface to discharge any static electricity.
- Attach an electrostatic discharge (ESD) wrist strap to your wrist, and stand on an ESD mat while replacing components.
- Ensure that you have the correct green color coded CPU removal tool that is used for removing smaller core processors. The CPU tool is shipped with replacement motherboards and replacement CPUs.
- Ensure that there is a workbench available to place the Pilot chassis once it is removed from the rack for servicing.
- Fail over the Pilot before replacing the component using Guided Maintenance.

**Note:** The Pilot must be failed over to prevent data loss or data corruption during the component replacement process.

Each Oracle Flash Storage System has two Pilots installed in the rack. The Pilot chassis is a customer replaceable unit (CRU). Replacing a Pilot chassis requires you to bring the failed Pilot offline and fail over operations to the standby Pilot using Guided Maintenance.

**CAUTION:** The Pilot weighs approximately 18.1 kilograms (39.9 pounds). Two people are required to carry the Pilot chassis and install it into the rack.

**CAUTION:** Deploy any rack anti-tilt mechanisms before installing the Pilot into the rack.

**Important:** The replacement Pilot ships as a metal chassis without any pre-existing components inside it. Replacement of the Pilot chassis requires assistance from Oracle Customer Support because it involves removing all FRUs and CRUs from the failed chassis and reinstalling them into the replacement chassis.

**CAUTION:** Ensure that all power is removed from the failed Pilot before removing the Pilot chassis. You must disconnect the power cords before performing this procedure.

**Note:** To replace a Pilot chassis, you must remove the failed Pilot from the rack.

---

**Note:** Using Guided Maintenance ensures that none of the re-used components have failed in case the replacement Pilot is re-using pre-existing components (CRUs and FRUs) from the failed Pilot.

### Procedure Overview

- 1 [\*Prepare a Pilot for Component Replacement\*](#)
- 2 [\*Power Off the Pilot\*](#)
- 3 [\*Disconnect Pilot Cabling\*](#)
- 4 [\*Slide Pilot to Service Position\*](#)
- 5 [\*Remove Pilot Chassis From Rack\*](#)
- 6 [\*Open Pilot Fan Door\*](#)
- 7 [\*Open Pilot Top Cover\*](#)
- 8 [\*Remove Components From the Pilot\*](#)
- 9 [\*Insert Components on the Pilot\*](#)
- 10 [\*Close Pilot Top Cover\*](#)
- 11 [\*Close Pilot Fan Door\*](#)
- 12 [\*Insert the Pilot Onto the Rack\*](#)

### Prepare a Pilot for Component Replacement

- 1 Contact Oracle Customer Support prior to replacing a Pilot component. Oracle Customer Support identifies the failed component on the Pilot for you.
- 2 From Oracle FS System Manager (GUI), navigate to System > Hardware > Pilots and select the Pilot that contains the component that you want to replace.
- 3 Select Actions > Repair Pilot.  
Guided Maintenance displays the list of Pilot components.
- 4 Based on the information from your Oracle Customer Support representative, select the correct component from the list.
- 5 Click Next.  
Guided Maintenance sends a request to flash the white locate LED on the Pilot to help you identify the Pilot in the data center.
- 6 Click Next.  
Guided Maintenance displays a link to *Pilot Repair Procedures*.
- 7 Click the *Pilot Repair Procedures* link to open and print the procedures.
- 8 Click Next.
  - If you are replacing a component located on the active Pilot, Guided Maintenance brings the active Pilot offline and fails over to the standby Pilot. After the active Pilot is offline, the GUI closes. You can

safely disconnect the power cords and data cables. When the failover is complete, you can log back into the GUI.

- If you are replacing a component located on the standby Pilot, Guided Maintenance brings the standby Pilot offline. After the standby Pilot is offline, you can safely disconnect the power cords and data cables. When servicing the standby Pilot, failover is not required.
- If you are replacing a power supply or a fan module, you are not required to bring the Pilot offline. The power supplies and fan modules are hot-serviceable.

**Note:** You can replace one power supply without bringing the Pilot offline, as long as the second power supply remains online and operational.

## Power Off the Pilot

**Note:** Do not power off the Pilot host without ensuring that SSH is enabled on the Oracle FS System. Otherwise, the replacement procedure might fail.

- 1 Notify affected users that the Pilot will be powered off.
- 2 Ensure that the host of the Pilot on which the replacement procedure must be performed is powered off.

## Disconnect Pilot Cabling

- 1 Disconnect all power and data cables from the Pilot.  
These include:
  - Ethernet cables connected to the network ports
  - Rollover cable connected to the serial port
  - Power cables connected to the power supplies of the Pilot

**Note:** Oracle Customer Support recommends labeling all cables connected to the Pilot so that they can be re-connected accurately to the Pilot after the replacement procedure is complete.


**Important:** Ensure that the Pilot is offline before removing the power cords.

**CAUTION:** When the Pilot is offline, power is still directed to the power supply fans in the Pilot. To completely power off the Pilot, you must disconnect the power cords from the back of the power supplies.

- 2 Disconnect the cable management arm (CMA) by pulling the release tabs on the left and right side of the CMA.

**Note:** Do not disconnect the cables attached to the CMA.

Figure 201: CMA release tabs




Legend	1 CMA	2 Release tab to disconnect the CMA
	3 Pilot	

**Important:** Before sliding out the Pilot, ensure that the cables do not interfere with the movement of the Pilot. Although the cable management arm (CMA) is hinged to accommodate extending the Pilot, ensure that all cables and cords are capable of being extended.

### Slide Pilot to Service Position

- 1 Slide the Pilot chassis fully forward until the slide rails lock into position.

Figure 202: Pilot position during component replacement



Legend 1 Rack


2 Pilot chassis

3 Pilot rails

- 2 When Guided Maintenance prompts you to remove the component, pull the flip handles at front of the Pilot and start sliding the Pilot out of the rack.

**CAUTION:** Deploy any rack anti-tilt mechanism before releasing the release buttons and extending the Pilot.

Figure 203: Pilot slide lockout release tabs



Legend	1 Slide rail lock
	2 Slide lockout release tab

**Note:** The slide-rail locks are located behind the flip-down handles on the front of the Pilot chassis. The slide-rail locks are released when the flip-down handles are pulled down. The slide lockout release tab must be released to push the Pilot chassis back into the rack.

## Remove Pilot Chassis From Rack

- 1 From the front of the Pilot, pull the slide-rail release tabs toward the front of the Pilot and pull the Pilot out of the rack until it is free of the rack rails.

**Note:** A slide-rail release tab is located on each slide-rail. To pull the slide-rail release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 With the help of a partner or a mechanical lift, place the Pilot on an antistatic surface or ESD qualified mat or workbench.

**CAUTION:** Deploy any rack anti-tilt mechanisms before removing or installing the Pilot into the rack.

**CAUTION:** The Pilot weighs approximately 39.9 pounds (18.1 kilograms). Two people are required to dismount and carry the chassis.


**CAUTION:** Do not use the power supply handles to lift the chassis. Using the power supply handles to lift the chassis can damage the power supplies and disrupt electrical power to the Pilot.

## Open Pilot Fan Door

Press the two fan door release tabs simultaneously forward and swing the Pilot fan door to the open position.

**Note:** Servicing the Pilot fan modules and other components located in the front of the Pilot, such as the front indication module (FIM) and the disk backplanes, require that the fan door be opened. It is also easier to remove the Pilot's top cover if you open the fan door first.

**Figure 204: Pilot with fan door open**



Legend	1 Fan door release tabs
	2 Pilot fan door in open position


## Open Pilot Top Cover

- 1 Press down on the push button on the Pilot top cover to release the top cover and use the recessed areas to slide the top cover toward the back of the Pilot about 0.5 inches (12.7 mm).

**CAUTION:** Before removing the top cover of the Pilot, power off the Pilot using Guided Maintenance. Removing the Pilot top cover before powering off the Pilot might cause damage to the software image on the Pilot.

**Tip:** Slide out the Pilot top cover by pressing down on the grooves located on both sides of the cover.

Figure 205: Pilot top cover removal



Legend	1 Push button to release top cover
	2 Grooves to slide out top cover

- 2 Lift the cover off the Pilot chassis and set it aside.

## Remove Components From the Pilot

Remove the necessary components on the Pilot following the procedures outlined below.

**Note:** All components that are removed from the Pilot must be placed on an antistatic surface or ESD qualified mat.

### *Remove a Power Supply*


- 1 Proceed to step 3 if you have already removed the power cords. Otherwise, from the back of the Pilot, remove the velcro that holds the power cord from the failed power supply.

**Note:** You might need to swing the cable management arm (CMA) out of the way to access the power supplies. If the CMA is still in the way, extend the Pilot approximately 20 cm (8 inches) out of the front of the rack.

**Note:** The fans of a failed power supply may still be spinning when the system is powered on. You can remove a power supply while the fans are still spinning.

- 2 Disconnect the power cord from the failed power supply.
- 3 While holding the power supply handle with one hand, use the other hand to push the power supply latch to the left.

Figure 206: Power supply removal



Legend	1 Power supplies (PS0 and PS1)
	2 Power supply handle
	3 Power supply compartment


- 4 Pull the power supply out of the chassis and place the power supply on an antistatic mat.

**CAUTION:** Whenever you remove a power supply, you should replace it with another power supply; otherwise, the Pilot might overheat due to improper airflow.

### *Remove a Fan Module*

- 1 Using your thumb and forefinger on both sides of the fan module tab, gently lift the fan module from the fan compartment.

Figure 207: Pilot fan module removal



Legend	1 Fan module tab
	2 Fan modules
	3 Fan door

**Note:** When removing a fan module, do not rock it back and forth. Rocking the fan module can cause damage to the motherboard connectors.


- 2 Set the fan module aside on an antistatic mat.

**Note:** When replacing a fan module, do not service any other components unless the system is powered off and the power cords are removed.

### *Remove a Pilot DIMM*

- 1 Remove the DIMM by pressing down on the tabs on both sides of the DIMM to unlock it from the slot.

Figure 208: Pilot DIMM removal



Legend	1 DIMM
	2 DIMM slot
	3 DIMM tab

**Note:** While inserting or removing DIMMs, ensure that there is no interference with the cables. Pulling or pressing down on the cables might cause damage to the cables during the replacement procedure.

- Lift out the DIMM and set aside on an antistatic mat.

**Note:** Visually inspect the DIMM slots, and the DIMM, for physical damage by checking for cracked or broken plastic in the slot.

**Note:** Sometimes DIMMs might fault because of dust or improper alignment or damaged slots. Use only compressed air to dust DIMMs.


### *Remove a Heat Sink*

- Tip:** A portion of the air duct over CPU-1 must be removed to access CPU-1 and Heat sink-1.

Loosen the four Phillips screws on the four sides of the heat sink in a diagonal pattern using a Phillips Number 2 screwdriver.

The four Phillips screws on the four sides of the heat sink secure the heat sink to the Pilot chassis.

Figure 209: Loosen four screws to remove heat sink



Legend	1 Heat sink
	2 Phillips screws that secure the heat sink


- Lift up the heat sink and set aside the failed heat sink on an antistatic mat.

**Note:** Visually inspect the failed heat sink to verify if the thermal grease has dried out. After cleaning the heat sink with an alcohol pad, apply thermal grease to the heat sink, if necessary.

### Remove a Pilot CPU

- Press gently on the lever at the side of the CPU socket to disengage the CPU socket.

Figure 210: CPU socket disengaged



Legend	1 CPU socket lever
	2 CPU socket
	3 CPU


This exposes the CPU inside the CPU socket.

**CAUTION:** The correct CPU removal or replacement tool must be used to remove and replace a CPU. Otherwise, the CPU or the CPU socket might

be damaged. The correct CPU removal/replacement tool is included in the box with the replacement CPU. Additionally, both removal or replacement tools ship with replacement motherboards.

The model for the CPUs in the Oracle FS System Pilot is E5-2609 V2 (4 core processor) and requires a CPU removal tool that is color coded green.


**Figure 211: CPU removal tool**



Legend	1 CPU removal tool color coded green
--------	--------------------------------------

- 2 Gently disengage the CPU pins on the underside to lift up the CPU from the CPU socket and set aside the failed CPU on an antistatic mat.

**Figure 212: CPU removal**



Legend	1 CPU socket lever
--------	--------------------

	2 CPU socket
--	--------------

	3 CPU
--	-------


Use the syringe to apply approximately 0.1 ml of thermal grease to the top center of the CPU.

**Note:** Do not distribute the thermal grease. The spring pressure of the heat sink will evenly distribute the compound.

### Remove a Riser

- 1 Press on the release tab of the riser to release the riser from the Pilot motherboard.
- 2 Carefully pull up the release tab on the riser to release the filler panel or HBA card (if any) and pull the riser straight up.

**Figure 213: Riser board assembly removal**



Legend 1 Release tab on the riser

2 Riser


3 HBA

4 Motherboard

**Note:** Remove any host bus adapter (HBA) cables or HBAs that are on the failed riser assemblies using the appropriate procedure. Make a note of the riser slot in which the HBAs are installed and the SAS cables that are connected to the HBAs.

- 3 Disconnect the SAS cable bundle that connects the SAS HBA and the Pilot disk backplane and set aside.

Figure 214: Disconnect SAS cable bundle



Legend	1 Riser
	2 HBA
	3 SAS cable bundle


- 4 Remove any HBA cards (usually the SAS card) that are inserted into the PCI-express (PCI-e) slots of the riser and place the riser and the HBA cards on an antistatic mat.

**Note:** Retain the HBA cards because they will be placed inside the replacement riser board assembly.

### *Remove a SAS HDD*

- 1 On the Pilot with the failed SAS HDD, press the drive carrier latch to disengage the SAS HDD.

Figure 215: SAS HDD removal



Legend	1 Pilot front
	2 SAS HDD
	3 Drive carrier latch

**Important:** The drive carrier latch is not an ejector. Do not bend the latch too far to the right. Bending the latch can damage the latch.

**Important:** When you remove a failed SAS HDD, be sure to replace it immediately with another SAS HDD or a filler panel.

- 2 Grasp the drive carrier latch and pull the SAS HDD out of the Pilot drive compartment.
- 3 Place the failed SAS HDD on an antistatic mat.

### *Remove a Disk Backplane*

- 1 Pull out all the storage drives or filler panels from the drive compartment far enough to disengage it from the disk backplane.


**Note:** It is not necessary to completely remove the storage drives from the Pilot. However, you must pull them out far enough to disengage them from the disk backplane. If you remove the storage drives from the Pilot, make a note of their locations so that you can reinstall the storage drives in the same locations.

- 2 If replacing both disk backplane boards, disconnect the SAS cable bundle starting with the top board of the disk backplane.

If you are going to remove and replace both disk backplane boards, make a note of which cables connect to the top disk backplane and which cables

connect to the bottom disk backplane. Do this before disconnecting any backplane cables.

**Figure 216: Disk backplane cables disconnected**




Legend 1 Disk backplane power cable

2 LED cable

3 SAS cable bundle

- 3 Disconnect the disk backplane LED cable (1U system controller cable) and the disk backplane power cord from the disk backplane.
- 4 Using your thumb and fingers, loosen the two captive thumb screws that secure the disk backplane to the Pilot chassis.


Figure 217: Captive thumb screws to remove disk backplane



Legend	1 Captive thumb screws
	2 Disk backplane

- 5 Slide the disk backplane forward toward the front of the Pilot to release it from the three standoffs and lift it out of the chassis.

Figure 218: Pilot disk backplane removal



Legend	1 Disk backplane
	2 Standoffs

- 6 Place the disk backplane on an antistatic mat.  
If replacing both disk backplane boards, repeat the steps for the second board.

## Insert Components on the Pilot

Insert the necessary components on the Pilot following the procedures outlined below.

Some components had to be removed from the Pilot as a prerequisite while replacing the failed component. These components must be reinstalled after completing the replacement.


### *Insert a Disk Backplane*

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Lower the disk backplane into the Pilot and position it to engage the three standoffs.

**Figure 219: Pilot disk backplane positioned over standoffs**




Legend 1 Disk backplane

2 Standoffs

**Note:** If replacing two disk backplane boards, start by installing the bottom disk backplane board.

- 3 Using just your thumb and fingers, tighten the two captive thumb screws to secure the disk backplane to the Pilot chassis.


Figure 220: Captive thumb screws to secure disk backplane



Legend	1 Disk backplane
	2 Captive thumb screws

- 4 Reconnect the disk backplane LED cable (1U system controller cable) and the disk backplane power cord to the disk backplane.
- 5 Reconnect the SAS cable bundle to the disk backplane.

Figure 221: Disk backplane cables connected



Legend	1 SAS cable bundle
	2 LED cable

3 Disk backplane power cable
------------------------------

**Note:** After replacing the disk backplane, you must manually program the product serial number (PSN) into the replacement disk backplane. Programming the PSN on the disk backplane is important for service entitlement.

- 6 Reinstall all of the storage drives into the drive compartment.


### *Insert a SAS HDD*

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Insert and slide the replacement SAS HDD into the drive slot until the SAS HDD is fully seated into the slot.

**Figure 222: SAS HDD insertion**



Legend	1 Pilot front
	2 SAS HDD
	3 Drive carrier latch


- 3 Close the drive carrier latch to lock the SAS HDD in place.

**Note:** Do not force open the drive carrier latch. You can damage the drive carrier latch if you apply too much force.

## Insert a Riser

- 1 Unpack the component from its shipping carton.  
**Note:** Place the component on an antistatic mat if it must be set aside for any reason.
- 2 Insert the HBA cards that were placed aside and insert them in the same PCIe slots as before within the replacement riser.
- 3 Reconnect the SAS cable bundle into the HBA inside the riser.
- 4 Insert the riser into the black slot on the Pilot motherboard and slide the release tab backward to secure the riser in position.

Figure 223: Pilot riser insertion



Legend	1 Release tab
	2 Riser
	3 HBA
	4 Pilot motherboard

- 5 Insert the filler panels, if any, inside the riser.


## Insert a Pilot CPU

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Gently align the pins on the underside of the CPU to the CPU socket and push down to secure the CPU in the socket.

**Figure 224: CPU insertion**



Legend	1 CPU socket lever
	2 CPU socket
	3 CPU


- 3 Push down on the lever of the CPU socket to secure the CPU inside.

### *Insert a Heat Sink*

Secure the heat sink over the CPU to the Pilot motherboard by inserting the four screws on the four sides of the heat sink and tightening them using a Phillips Number 2 screwdriver.

**Tip:** Ensure that you have thermal grease and syringe available to clean the CPU and heat sink.

**Figure 225: Heat sink insertion**



Legend	1 Heat sink
--------	-------------

---

2 Phillips screws that secure the heat sink
---

**Important:** Ensure that the heat sink and the screws are aligned so that the airflow marker on the heat sink faces the back of the Pilot and the system front marker on the heat sink faces the front of the Pilot. Also, ensure that the screws on opposite ends of the heat sink are tightened first. A slight force must be applied to push down the screwdriver while tightening the screws to overcome the tension generated.

**Note:** Install the chassis mid-wall and ensure that the cables are running through the opening in the center of the mid-wall. Position the mid-wall with the cables in front of the motherboard so that it engages the mushroom-shaped standoffs that are located on the chassis sidewall (one for each side of the mid-wall).

### *Insert a Pilot DIMM*

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Press the DIMM fully into the DIMM slot and ensure that the tabs on both sides of the DIMM are locked.

**Important:** Ensure that the notch in the DIMM lines up with the key in the slot.

**Note:** Replace only one DIMM at a time to make sure that they are inserted into the correct slots. Attempting to insert multiple DIMMs into the slots might damage the DIMMs due to excessive flexure.

**Note:** Never leave a DIMM slot unpopulated. Insert filler panels into empty DIMM slots to ensure proper air flow inside the Pilot.


### *Insert a Fan Module*

- 1 Unpack the component from its shipping carton.

**Note:** Place the component on an antistatic mat if it must be set aside for any reason.

- 2 Grasp the fan module tabs and press the fan down firmly into the fan module compartment.

Figure 226: Fan module insertion



Legend	1 Fan module tab
	2 Fan modules
	3 Fan door

**Note:** Apply firm pressure to fully seat the fan module into the fan compartment. The fan modules are notched to ensure that they are installed in the correct orientation.

- 3 Press down on the fan module and apply firm pressure to fully seat the fan module.

## Close Pilot Top Cover

- 1 Place the top cover of the Pilot onto the chassis.

**Tip:** Place the top cover down so that it hangs over the back of the Pilot by about 13 mm (0.5 inches) [1] and the side latches align with the slots in the sides of the Pilot chassis.

**Note:** There are three latching tabs on the sides of the Pilot top cover, two on the right side and one on the left side when viewing the Pilot from the front. There is also a latch on the underside of the top cover in the front left corner near the release button.


- 2 Check both sides of the Pilot chassis to ensure that the four corners of the top cover are fully down and flush with the chassis.

**Note:** If the cover corners are not flush with the Pilot chassis, slide the cover towards the back of the chassis until you can position the cover correctly.

**Note:** If the top cover is not correctly positioned before attempting to slide the cover forward, the internal latch that is on the underside of the cover might be damaged.

- 3 Gently slide the top cover along the grooves of the Pilot by pressing down on either side of the top cover until it locks into place and you hear an audible click.

**Figure 227: Pilot top cover installed**



Legend	1 Top cover
	2 Grooves to slide the top cover
	3 Fan door

## Close Pilot Fan Door

Close the Pilot fan door by pressing the two release tabs on both sides of the fan door until it locks into place.

## Insert the Pilot Onto the Rack


Inserting the Pilot onto the rack includes the following tasks:

- 1 Re-connect the Pilot cabling and the cable management arm (CMA).
- 2 Connect the power cords onto the Pilot.
- 3 Update the Pilot BIOS.
- 4 Install the Top Cover
- 5 Slide the Pilot into rack position.
- 6 Push power button on the Pilot.
- 7 Verify the Pilot component status.

## Insert Pilot Chassis Into Rack

- 1 With the help of a partner or a mechanical lift, raise the Pilot so that the back ends of the mounting brackets are aligned with the slide-rail assemblies that are mounted in the rack.

**Figure 228: Lift Pilot chassis onto rack**



Legend	1 Inserting mounting brackets into slide-rails
	2 Slide-rail release button
	3 Slide-rail lock

**CAUTION:** Deploy any rack anti-tilt mechanisms before installing the Pilot into the rack.

**CAUTION:** The Pilot weighs approximately 18.1 kg (39.9 lb). Two people are required to carry the chassis and install it into the rack.

**CAUTION:** Do not use the power supply handles to lift the chassis. Using the power supply handles to lift the chassis can damage the power supplies and disrupt electrical power to the Pilot.


- 2 Insert the mounting brackets into the slide-rails, then push the Pilot into the rack until the mounting brackets encounter the slide-rail stops at approximately 12 inches (30 cm).

The Pilot is now in the extended maintenance position.

## Slide Pilot to Rack Position

- 1 Simultaneously pull and hold the two release tabs, one on each side of the Pilot, toward the front of the Pilot while you push the Pilot into the rack.

**Figure 229: Location of the Pilot release tabs**



**Note:** As you push the Pilot into the rack, verify that the cable management arm (CMA) retracts without binding.

**Note:** To pull the Pilot release tab, place your finger in the center of the tab, not on the end, and apply pressure as you pull the tab toward the front of the Pilot.

- 2 Continue pushing the Pilot into the rack until the slide-rail locks on the front of the Pilot engage the slide-rail assemblies.

**Note:** The Pilot locks into the rack position with an audible click.

### *Re-connect Pilot Cabling*

- 1 Reconnect the following cables that had been disconnected from the Pilot.
  - Ethernet cables connected to the network ports
  - Rollover cable connected to the serial port

**Note:** If the cable management arm (CMA) is in the way, extend the Pilot approximately 13 cm (5 inches) out of the front of the rack. Once the cables are connected to the ports, the Pilot can be pushed back into the rack position.

- 2 Reconnect the power cords to the power supplies and secure them with the velcro straps.
- 3 If necessary, reinstall the cables into the cable management arm (CMA) and secure them with cable straps.
- 4 Reconnect the CMA to the Pilot chassis by reattaching the release tabs on both sides of the CMA.

### *Connect Power Cords On the Pilot*

Reconnect the power cords to the Pilot.

**Note:** After the power cords are connected, the green SP LED and the OK LED both start to blink.

**Note:** Do not turn on the power to the Pilot host immediately. The power on the Pilot host is turned on only after updating the Pilot BIOS. Turning on the power to the Pilot host early can prevent the Pilot from booting after the Pilot BIOS is updated.

### *Verify Component Replacement on the Standby Pilot*

If you replaced a component on the standby Pilot, complete the following steps to verify the status of the Pilot:

- 1 Return to Guided Maintenance and click Finish.  
Guided Maintenance closes and the GUI displays the Pilot Overview page.
- 2 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

### *Verify Component Replacement on the Active Pilot*

If you replaced a component on the active Pilot, complete the following steps to verify the status of the Pilot:

- 1 Restart Oracle FS System Manager (GUI).
- 2 Navigate to System > Hardware > Pilots.  
The GUI displays the Pilot Overview page.
- 3 From the Pilot Overview page, review the status of the Pilot.  
A status of Normal requires no action.

# Oracle FS System Hardware Specifications

## Oracle FS System Hardware Specifications

An Oracle Flash Storage System is an assembly of Pilots, Controllers, Drive Enclosures, power distribution units (PDUs), racks, and cables. Replication Engines are an optional component of the Oracle FS System.

The following table indicates the basic components that constitute an Oracle Flash Storage System.

**Table 17: Basic components of an Oracle Flash Storage System**

Component	Oracle Flash Storage System
Pilot	<ul style="list-style-type: none"> <li>• Two Pilots for failover and failback</li> <li>• Management commands flow from the active Pilot to the Controllers</li> </ul>
Controller	<ul style="list-style-type: none"> <li>• Two Controllers for failover and failback</li> <li>• Provide network I/O access to customer facilities and provides a storage fabric interface between all Drive Enclosures and other Controllers.</li> </ul>
Drive Enclosure	<ul style="list-style-type: none"> <li>• 1 to 30. The two types of Drive Enclosure are the DE2-24P Drive Enclosure and the DE2-24C Drive Enclosure.</li> <li>• Used as back-end storage for the Oracle FS Systems.</li> </ul>
PDU	<ul style="list-style-type: none"> <li>• Two PDUs are required in each rack that is used for the installation of rack-ready Oracle FS Systems.</li> <li>• PDUs are built-in to the Oracle racks.</li> </ul>
Rack	<ul style="list-style-type: none"> <li>• At least one rack.</li> </ul> <p><b>Note:</b> The number of racks is based on the number of Drive Enclosures and whether there are any Replication Engines included in the system.</p> <p>The number of racks depends on the number and the distribution of the hardware components.</p>

The following table provides the maximum dimensions of an Oracle Flash Storage System that is fully integrated at the factory in the supported Oracle rack with Oracle PDUs.

**Table 18: Maximum physical dimensions of an Oracle Flash Storage System**

Component	Oracle Flash Storage System
Height	42U or 1998 mm (78.7 in)
Width	600 mm (23.6 in)
Depth (front door handle to back door handle)	1200 mm (47.2 in)
Depth (doors removed)	1112 mm (43.8 in)
Maximum weight	696.6 kg (1535.7 lb)

**Note:** The weight of an Oracle Flash Storage System depends on the distribution of Drive Enclosures in the rack and whether any Replication Engines are included, as well as the Pilots and Controllers.

### Related Links

[Component Chassis Hardware Specifications](#)

[PDU Hardware Specifications](#)

[System Power Requirements](#)

[System Packaging and Transportation](#)

[System Environmentals](#)

## Component Chassis Hardware Specifications

The following tables provide information on the hardware specifications and the power characteristics of the Pilot, Controller, and Drive Enclosures.

### Dimensions and Weight

**Table 19: Pilot dimensions and weight**

Attribute	Value
Height	1.68 in (4.26 cm)
Width	Server chassis (not including ears): 17.19 in (43.65 cm) Server chassis (with bezel): 18.9 in (48.24 cm)
Depth (not including power supply handles)	29.0 in (73.7 cm)
Weight	40 lb (18.1437 kg): Weight of one Pilot.

**Table 20: Controller dimensions and weight**

Attribute	Value
Height	3.45 in (8.76 cm)
Width	17.52 in (44.55 cm)
Depth	20.25 in (51.435 cm)
Weight	41 lb (18.59 kg)

**Table 21: DE2-24P Drive Enclosure dimensions and weight**

Attribute	Value
Height	3.46 in (8.79 cm); 2U
Weight (with drives)	55 lb (24.9 kg)
Width	Width across mounting flange: 19 in (48.26 cm) Width across body of enclosure: 17.44 in (44.29 cm)
Depth	24.8 in (62.99 cm)

**Table 22: DE2-24C Drive Enclosure dimensions and weight**

Attribute	Value
Height	6.92 in (17.57 cm); 4U
Weight (with drives)	110 lb (49.89 kg)
Width	Width across mounting flange: 19 in (48.26 cm) Width across body of enclosure: 17.44 in (44.29 cm)
Depth	24.8 in (62.99 cm)

## Power Characteristics

**Table 23: Pilot power characteristics**

<b>Power characteristic</b>	<b>Value</b>
Frequency	50–60Hz
AC voltage	100–240V
Maximum power consumption for both nodes	314 VA
Current draw for both nodes	1.42A, 208V
Maximum heat dissipation	1102 BTU/hr
AC receptacle type	IEC 60320 C14 inlet

**Table 24: Controller power characteristics**

<b>Power characteristic</b>	<b>Value</b>
Frequency (nominal)	50–60 Hz (47–63 Hz range)
Voltage (nominal)	100 to 127/200 to 240 Volts AC
Input current (maximum) for both nodes	13.6 A at 100–120 Volts AC (approximately) 8 A at 200–240 Volts AC (approximately)
Maximum power consumption for both nodes	874 VA (power at maximum FS1 Controller configuration)
Maximum heat dissipation	2830 BTU/hr
AC receptacle type	IEC 60320 C14 inlet

**Table 25: Drive Enclosure power characteristics**

Power characteristic	Value
Maximum output power	<p>Maximum power consumption depends on the type of Drive Enclosure (DE2-24P or DE2-24C), its size (2U/4U), and configuration.</p> <ul style="list-style-type: none"> <li>• 4U HDD= 376VA (4TB HDD)</li> <li>• 2U SFF = 260VA (900GB SFF HDD)</li> <li>• 2U SSD = 307VA (19 x 1.6TB SSD)</li> </ul>
Frequency	50–60 Hz
Voltage range	100–240 Volts AC rated
Maximum range selection	47–63 Hz
Maximum inrush current	20A
Power factor correction	95% or less at nominal input voltage
Harmonics	Meets EN61000-3-2
Operating temperature	5° –40° Celsius (41° —104° Fahrenheit)

## PDU Hardware Specifications

The PDUs used in a not-racked Oracle FS System installation must provide redundancy for both external AC power source and internal AC power distribution to the components. The PDUs must provide sufficient current to meet the sum of the requirements for the Oracle FS System components.

Oracle PDUs might be purchased for use with non-Oracle racks. The Oracle FS System component power cords have been designed to work with vertical style Oracle or third party PDUs. Non-Oracle PDUs must be compatible with Oracle component power cord lengths and plug types. Non-Oracle PDUs must be mounted in a manner such that the power cords provided by Oracle might be used and the PDUs do not obstruct the ability to replace field replaceable units (FRUs) and customer serviceable units (CRUs).

While planning rack-space, ensure that adequate space is also allocated for the PDUs, if using non-Oracle PDUs.

The following tables provide information on the various PDUs for the Oracle FS Systems, with the assumption that there are two PDUs in each rack.

**Note:** The term “Ph” stands for “phase” in the above tables.

**Table 26: Low voltage dual phase PDU for Oracle Flash Storage Systems**

<b>Low Voltage</b>	<b>2Ph (2W + ground)</b>
kVA size	10 kVA
Marketing part number	7104982
Manufacturing part number	7051798
Phase	1 Phase No grounded neutral conductors are provided in the two input cords.
Voltage input	2x [2Ph (2W+ground)], 208Vac, 50/60 Hz, maximum. 24A per phase Can be connected to input sources in the range of 200V – 240V AC (nominal)
Number of input cords and plug type	2x NEMA L6-30P
Number of data center receptacles and type	2x NEMA L6-30R
Maximum input current for each cord	24A
Outlet receptacles (number/type)	42/C13 (seven for each outlet group) 6/C19 (one for each outlet group)
Outlet groups for each PDU	6
PDU power cord length	2 meters (6.6 feet) PDU power cords are 4 m (13 ft) long, but only 2 m (6.6 ft) are usable outside of the cabinet.

**Table 27: Low voltage three-phase PDU for Oracle Flash Storage Systems**

<b>Low Voltage</b>	<b>3Ph (3W + ground)</b>
kVA size	15 kVA
Marketing part number	7104979
Manufacturing part number	7051909

**Table 27: Low voltage three-phase PDU for Oracle Flash Storage Systems (continued)**

<b>Low Voltage</b>	<b>3Ph (3W + ground)</b>
Phase	3 No grounded neutral conductors are provided in the input cords.
Voltage input	3Ph [(3W+ground)] 208Vac, 50/60 Hz, maximum. 40A per phase Can be connected to Ph-Ph input sources in the range of 190V – 220V AC (nominal)
Number of input cords and plug type	1x IEC 309, 60A (Hubbell C460P9W or equivalent)
Number of data center receptacles and type	1x IEC 309, 60A (Hubbell 460R9S or equivalent)
Maximum input current for each cord	40A
Outlet receptacles (number/type)	42/C13 (seven for each outlet group) 6/C19 (one for each outlet group)
Outlet groups for each PDU	6
PDU power cord length	2 meters (6.6 feet) PDU power cords are 4 meters (13 feet) long, but sections are connected for internal routing in the rack.

**Table 28: High voltage single phase PDU for Oracle Flash Storage Systems**

<b>High Voltage</b>	<b>1Ph (2W + ground)</b>
kVA size	10 kVA
Marketing part number	7104983
Manufacturing part number	7051801
Phase	1
Voltage input	2x [2Ph. (2W+ground)] 230Vac, 50 Hz, maximum. 25A per phase Can be connected to Ph-N input sources in the range of 220V – 240V AC (nominal)

**Table 28: High voltage single phase PDU for Oracle Flash Storage Systems (continued)**

<b>High Voltage</b>	<b>1Ph (2W + ground)</b>
Number of input cords and plug type	2x IEC 309, 32A (Hubbell 332P6S or equivalent)
Number of data center receptacles and type	2x IEC 309, 32A (Hubbell 332R6S or equivalent)
Maximum input current for each cord	25A
Outlet receptacles (number/type)	42/C13 (seven for each outlet group) 6/C19 (one for each outlet group)
Outlet groups for each PDU	6
PDU power cord length	2 meters (6.6 feet)  PDU power cords are 4 meters (13 feet) long, but sections are connected for internal routing in the rack.

**Table 29: High voltage three-phase PDU for Oracle Flash Storage Systems**

<b>High Voltage</b>	<b>3Ph (5W + ground)</b>
kVA size	15 kVA
Marketing part number	7104980
Manufacturing part number	7051915
Phase	3
Voltage input	[3Ph. (4W+ground)] 230/400Vac, 50/60 Hz, maximum. 25A per phase  Can be connected to Ph-N input sources in the range of 220V – 240V AC (nominal)
Number of input cords and plug type	1x IEC 309, 32A (Hubbell 532P6S or equivalent)
Number of data center receptacles and type	1x IEC 309, 32A (Hubbell 532R6S or equivalent)
Maximum input current for each cord	25A

**Table 29: High voltage three-phase PDU for Oracle Flash Storage Systems (continued)**

<b>High Voltage</b>	<b>3Ph (5W + ground)</b>
Outlet receptacles (number/type)	42/C13 (seven for each outlet group) 6/C19 (one for each outlet group)
Outlet groups for each PDU	6
PDU power cord length	2 meters (6.6 feet)  PDU power cords are 4 meters (13 feet) long, but sections are connected for internal routing in the rack.

## System Power Requirements

The total power consumed by the Oracle FS1 Flash Storage System is dependent on the configuration of the system. To determine the system electrical input ratings for Oracle Flash Storage Systems that use the Oracle supported PDUs, refer to the PDU information provided for Oracle Flash Storage Systems.

Oracle Flash Storage Systems require redundant input power feeds for proper fault tolerant operation.

**Note:** Ensure that you have the exact power load and current requirements for your specific Oracle FS System at hand.

If non-Oracle PDUs are used, you must determine the electrical input ratings of the Oracle FS System configuration.

## System Packaging and Transportation

All packaging and transportation are tested in accordance with Oracle Shipping Package Test, Doc. No. 950-1291-01.

## System Environmentals

**Table 30: System altitude specifications**

<b>Mode</b>	<b>Elevation</b>
Operational	-196 to 10498.7 feet (-60 to 3,200 meters)
Non-operational	-196 to 40026.2 feet (-60 to 12,200 meters)

**Table 31: System temperature and humidity specifications**

<b>Mode</b>	<b>Ambient temperature</b>	<b>Non-condensing humidity</b>	<b>Max wet bulb temperature</b>	<b>Gradient</b>
Operational	Up to 7000-foot elevation: +41 to 104°F (+5 to 40°C)  Up to 10,000-foot elevation: +41 to 95°F (+5 to 35°C)	10–85%  10%/hr gradient	86°F (30°C)	36°F/hr (20°C/hr)
Non-operational	-45.4 to 154.4 °F (-43 °C to 68 °C)	5–95%  10%/hr gradient	104°F (40°C)	54°F/hr (30°C/hr)

# Oracle FS System LED Status

## Oracle FS System LEDs

An Oracle FS System includes LEDs to indicate the status of the hardware components. To restore reliability to the Oracle FS System, locate the specific failed component so that you can replace it. Hardware LED configuration helps you identify the failed component.

**Important:** If you cannot locate the hardware component that must be replaced, contact Oracle Customer Support.

The Guided Maintenance feature of the Oracle FS System Manager triggers the chassis with the failed component to blink, or it triggers all of the other chassis to blink, except for the one with the failed component. This blinking pattern helps you to identify component status.

**Note:** LED interpretations in this appendix apply to a system after it has been powered on.

### Related Links

[Controller LED Indicators](#)

[Drive Enclosure LED Indicators](#)

[Pilot LED Indicators](#)

[Pilot Drive LED Indicators](#)

[Pilot Fan LED Indicators](#)

[Pilot Port LED Indicators](#)

[Pilot Motherboard LED Indicators](#)


[Pilot Power Supply LED Indicators](#)

## Controller LED Indicators

The LED alarm assembly is a high-level status indicator of the Controller and Controller components. Use these diagnostic LEDs to determine if a component has failed in the Controller. The LED alarm assembly also includes a power button to power on the Controller. Besides, the LED alarm assembly there is the Controller Identification Display (CID) that identifies the Controller by its numeric identifier.

The following figure shows the front display panel of the LED alarm assembly on the Controller:

Figure 230: LED alarm assembly front display



Legend	1 Chassis identification LED or Locator LED	5 Service processor LEDs
	2 Service Action Required LED or Caution or Fault LED	6 Back power supply LED
	3 Motherboard or Power or OK LED	7 Fault or Alarm LEDs (Critical, Major, Minor)
	4 Power switch	8 User Alarm LED

The following table provides status information on the LEDs on the front display panel of the LED alarm assembly on the Controller:

Table 32: Controller LED status and description (front panel)

No.	LED	LED color	Status
1	Chassis identification LED or Locator LED button	White	The Locator LED can be turned on to identify a particular system. When on, the LED blinks rapidly. Pressing and holding the Locator button for 5 seconds initiates a test of all LEDs in the LED assembly.
2	Service Action Required LED	Amber	Indicates that service is required. Under some fault conditions, individual component fault LEDs are turned on in addition to the Service Required LED.

Table 32: Controller LED status and description (front panel) (continued)


No.	LED	LED color	Status
3	Power or OK LED	Green	<p>Indicates these conditions:</p> <ul style="list-style-type: none"> <li>• Off – Indicates that the system is not running in its normal state. System power might be off. The SP might be running.</li> <li>• Steady on – Indicates that the system is powered on and is running in its normal operating state. No service actions are required.</li> <li>• Fast blink: Indicates that the system is running in standby mode and can be quickly returned to full function.</li> <li>• Slow blink: Indicates that a normal but transitory activity is taking place. Slow blinking might indicate that system diagnostics are running or that the system is booting.</li> </ul>
5	Service processor LED	Green	<p>Indicates the state of the service processor:</p> <ul style="list-style-type: none"> <li>• Flashing: Indicates the SP is booting.</li> <li>• Steady: Indicates a steady state, no service action is required.</li> </ul>
6	Back power supply LED	Amber	<p>Indicates the state of the power supplies:</p> <ul style="list-style-type: none"> <li>• Off – Indicates a steady state, no service action is required.</li> <li>• On – Indicates a fault with one of the power supplies.</li> </ul>

Table 32: Controller LED status and description (front panel) (continued)

No.	LED	LED color	Status
7	Fault or Alarm LEDs (Critical, Major, Minor)	<ul style="list-style-type: none"> <li>Critical Alarm LED : Red</li> <li>Major Alarm LED: Red</li> <li>Minor Alarm LED: Amber</li> </ul>	<b>Note:</b> The alarm indicators appear on the front panel of the Controller but are not applicable for the Oracle FS System.
8	User Alarm LED	Amber	Indicates a user alarm condition.  <b>Note:</b> The alarm indicators appear on the front panel of the Controller but are not applicable for the Oracle FS System.

The following figure shows the LEDs at the back of the Controller:

Figure 231: Controller back LEDs



Legend 1 Power supply status LEDs

2 Chassis Status LEDs

3 Network management LED

4 Net0 to Net3 status LEDs

The following table provides information on the LEDs at the back of the Controller:

Table 33: Controller LED status and description (back panel)

No.	LED	LED color	Status
1	Power supply status LEDs:	<ul style="list-style-type: none"> <li>• (Top) Output Power OK LED: Green</li> <li>• (Middle) Service Action Required LED: Amber</li> <li>• (Bottom) AC or DC Input Power OK LED: Green</li> </ul>	<ul style="list-style-type: none"> <li>• Output Power OK LED: Indicates that output power is without fault.</li> <li>• Service Action Required LED: Indicates that service for the power supply is required.</li> <li>• AC or DC Input Power OK LED: Indicates that input power is without fault.</li> </ul>
2	Chassis Status LEDs	<ul style="list-style-type: none"> <li>• (Left) Locator LED and button: White</li> <li>• (Center) Service Action Required LED: Amber</li> <li>• (Right) Main Power OK LED: Green</li> </ul>	<ul style="list-style-type: none"> <li>• Locator LED and button: The Locator LED can be turned on to identify a particular system.</li> <li>• Service Action Required LED: Indicates that service is required. Under some fault conditions, individual component fault LEDs are turned on in addition to the Service Required LED.</li> <li>• Main Power OK LED: Indicates these conditions: <ul style="list-style-type: none"> <li>• Off – System is not running in its normal state. System power might be off. The SP might be running.</li> <li>• Steady on – System is powered on and is running in its normal operating state. No service actions are required.</li> <li>• Fast blink – System is running in standby mode</li> </ul> </li> </ul>

Table 33: Controller LED status and description (back panel) (continued)

No.	LED	LED color	Status
			<p>and can be quickly returned to full function.</p> <ul style="list-style-type: none"><li>• Slow blink – A normal but transitory activity is taking place. Slow blinking might indicate that system diagnostics are running or that the system is booting.</li></ul>

Table 33: Controller LED status and description (back panel) (continued)

No.	LED	LED color	Status
3	Network management LED	<ul style="list-style-type: none"> <li>• (Left) Link and Activity LED: Green</li> <li>• (Right) Speed LED: Green, amber, or OFF</li> </ul>	<p>Indicates these conditions:</p> <ul style="list-style-type: none"> <li>• Link and Activity LED: <ul style="list-style-type: none"> <li>• On or blinking – A link is established.</li> <li>• Off – No link is established.</li> </ul> </li> <li>• Speed LED: <ul style="list-style-type: none"> <li>• On or blinking – The link is operating as a 100-Mbps connection.</li> <li>• Off – The link is operating as a 10-Mbps connection.</li> </ul> </li> </ul>
4	Net0 to Net3 status LEDs	<ul style="list-style-type: none"> <li>• (Left) Link and Activity LED: Green</li> <li>• (Right) Speed LED: Amber</li> </ul>	<p>Indicates the state of the service processor:</p> <ul style="list-style-type: none"> <li>• Link and Activity LED: <ul style="list-style-type: none"> <li>• On or blinking – A link is established.</li> <li>• Off – No link is established.</li> </ul> </li> <li>• Speed LED: <ul style="list-style-type: none"> <li>• Amber – The link is operating as a Gigabit connection (1000-Mbps).</li> <li>• Green – The link is operating as a 100-Mbps connection.</li> <li>• Off – The link is operating as a 10-Mbps connection or there is no link.</li> </ul> </li> </ul>

**Related Links**

[Oracle FS System LEDs](#)

## Controller Power Supply LED Indicators

The LED indicators on the power supplies are at the left of the fan of each power supply and provide power activity status.

**Table 34: Controller power supply LED status and description**

Icon	Location	Name	Color	Status and meaning
	Top	OK	Green	<ul style="list-style-type: none"> <li>On – Power supply is functional without fault.</li> <li>Off – Power supply is off or initializing.</li> <li>Flashing – No function.</li> </ul>
	Middle	Attention Service Required	Amber	<ul style="list-style-type: none"> <li>On – Normal fault detected.</li> <li>Off – No faults detected.</li> <li>Flashing – No function.</li> </ul>
	Bottom	AC or DC	Green	<ul style="list-style-type: none"> <li>On – Input power present and good.</li> <li>Off – Input power not present.</li> <li>Flashing – No function.</li> </ul>

## Controller Fan LED Indicators

A single bi-color LED represents the status of each fan module. The LEDs are on the motherboard near each fan module, and are visible from the back panel of the Controller when you look through the grill below the risers.

**Table 35: Controller fan LED status and description**


Color	Status and meaning
Green	The fan module is functional without fault.
Amber	The fan module has experienced a fault.

**Note:** There are two LEDs near the status LED for the third fan module. Do not confuse the FPGA Good and FPGA Diagnostic LEDs with the status LED for the third fan module.

## Controller ESM LED Indicators

Three LEDs represent the status of each energy storage module (ESM). The LEDs are above the release button of each drive.

**Figure 232: Controller drive LEDs**



Legend	1 Ready to Remove LED
	2 Attention Service Required LED
	3 OK/Activity LED
	4 Power switch

This following table describes the functionality of the ESM LEDs:

Table 36: Controller ESM LED status and description


Icon	Location	Name	Color	Status and meaning
	Top	Ready to Remove	Blue	<ul style="list-style-type: none"> <li>On – ESM can be removed as a hot-swap operation.</li> <li>Off – Do not remove the ESM.</li> <li>Flashing – ESM is initializing.</li> </ul>
	Middle	Attention Service Required	Amber	<ul style="list-style-type: none"> <li>On – Normal fault is detected.</li> <li>Off – No faults are detected.</li> <li>Flashing – No function.</li> </ul>
	Bottom	OK/Activity	Green	<ul style="list-style-type: none"> <li>On – ESM is functional without fault.</li> <li>Off – ESM is off or initializing.</li> <li>Flashing – ESM read and write activity.</li> </ul>

## Drive Enclosure LED Indicators

The LED indicators on the operator panel of the Drive Enclosures provide system status. The LED display identifies the Drive Enclosure by its numeric identifier.


The following figures show the operator panel LEDs for both types of Drive Enclosure.

Figure 233: Operator panel LEDs (DE2-24P Drive Enclosure)



Legend 1 System power indicator	3 Locate indicator and logical fault indicator
2 Module fault indicator	4 Chassis ID

Figure 234: Operator panel LEDs (DE2-24C Drive Enclosure)



Legend 1 System power indicator	3 Locate indicator and logical fault indicator
2 Module fault indicator	4 Chassis ID

The following table provides status information on the operator panel LEDs.

**Table 37: Drive Enclosure LED status and description (operator panel)**

LED	LED color	Status
System power indicator	Green	The status is normal.
Module fault indicator	Amber	A module fault is present.
Locate indicator	White	The DE is located.
LED display	Green number between 01 and 30	The numeric identifier of a DE is displayed.


**Related Links**

[Oracle FS System LEDs](#)

**Power Cooling Module LED Indicators**

The LED indicators on the power cooling modules provide power activity status, fan and temperature fault conditions, and firmware upgrade status.

The following figure shows the power cooling module LEDs.

**Figure 235: Power cooling module LEDs**

Legend	1 Status indicator	3 Fan fail indicator
	2 AC fail indicator	4 DC output fail indicator

The following table provides status information on the power cooling module LEDs.

**Table 38: Drive Enclosure LED status and description (power cooling module)**


Status	Status indicator (green)	Fan fail indicator (amber)	AC fail indicator (amber)	DC fail indicator (amber)
AC power is not available on either power cooling module.	Off	Off	Off	Off
AC power is not available on this power cooling module.	Off	Off	On	On
AC power is present, and the status of the power cooling module is normal.	On	Off	Off	Off
The power cooling module fan is outside of acceptable limits.	Off	On	Off	Off
The power cooling module fan failed.	Off	On	Off	Off
A fault is present (over temperature, over volts, over current).	Off	On	On	On
The power cooling module is in standby mode.	Flashing	Off	Off	Off
The power cooling module is downloading firmware.	Off	Flashing	Flashing	Flashing

### I/O Module LED Indicators

The LED indicators on the I/O modules provide power activity status, locate indicators, fault conditions, and host port activity.

The following figure shows the I/O module LEDs.

Figure 236: I/O module LEDs



Legend	1 Fault and locate indicator	3 Host port activity indicator
	2 Power and OK indicator	

The following table provides status information on the I/O module LEDs.

Table 39: Drive Enclosure LED status and description (I/O module)


Status	Fault and locate indicator (amber)	Power and OK indicator (green)	Host port activity (green)
The status is normal.	Off	On	Not applicable
An I/O module fault is present.	On	Off	Not applicable
The I/O module is located.	Flash	On	Not applicable
A vital product data (VPD) error is present.	Not applicable	Flash	Not applicable
The host port is not connected.	Not applicable	Not applicable	Off
The host port is not active.	Not applicable	Not applicable	On
The host port activity is normal.	Not applicable	Not applicable	Flashing

### Drive LED Indicators

The LED indicators on the Drive Enclosure drives provide power activity status, locate indicators, and fault conditions of each drive.


The following figures show the drive LEDs for both types of Drive Enclosure.

Figure 237: Drive LEDs (DE2-24P Drive Enclosure)



Legend	1 Power and activity indicator	2 Drive fault indicator
--------	--------------------------------	-------------------------

Figure 238: Drive LEDs (DE2-24C Drive Enclosure)



Legend	1 Power and activity indicator	2 Drive fault indicator
--------	--------------------------------	-------------------------

The following table provides status information on the drive LEDs.

Table 40: Drive Enclosure LED status and description (drives)

Status	Power/Activity Indicator (green)	Drive Fault indicator (amber)
Drive is installed and operational.	On and blinking with startup or activity	Off
The drive is located.	On	Flash one second on and one second off
A drive fault is present.	On	On In addition to the continuous amber light on the Drive Fault LED, the Locate LED on the operator panel is also a continuous amber light.

Table 40: Drive Enclosure LED status and description (drives) (continued)


Status	Power/Activity Indicator (green)	Drive Fault indicator (amber)
A failure occurred in the power control circuit.	Off	On In addition to the continuous amber light on the Drive Fault LED, the Module Fault LED on the operator panel is also a continuous amber light.
A failure occurred in the disk array.	On	Flash three seconds on and one second off. In addition to the flashing amber light on the Drive Fault LED, the Locate LED on the operator panel is also a continuous amber light.

## Pilot LED Indicators

The Pilot LEDs are on the front panel of the Pilot. Use these diagnostic LEDs to determine if a component has failed in the Pilot.

The following figure shows the LEDs at the front of the Pilot:


Figure 239: LEDs at the front of the Pilot



Legend	1 Locator LED / Locator button: white	5 Power button
	2 Service Action Required LED or Caution or Fault LED: Amber	6 Fan fault LED: amber
	3 OK LED: green	7 Power supply fault LED: amber
	4 Service processor LED: green	

The following figure shows the LEDs at the back of the Pilot:

Figure 240: LEDs at the back of the Pilot



Legend	1 Poser supply 0 (PS0)	5 Locator LED: white
	2 Power supply LEDs: Service Required LED (amber) and AC OK LED (green)	6 Service Required LED: amber
	3 Power supply 1 (PS1)	7 Power or OK LED: green
	4 Power supply LEDs: Service Required LED (amber) and AC OK LED (green)	

There are six, system-level status indicators (LEDs), that are on the Pilot front panel and the Pilot back panel. The following table provides status information on these Pilot LEDs:

Table 41: Pilot LED status and description

LED	Icon	LED color	Status
Locator LED button		White	<ul style="list-style-type: none"> <li>OFF – Pilot is operating normally</li> <li>FAST BLINK – To locate a particular system quickly and easily.</li> <li>Pressing the Locate button toggles the LED fast blink on or off.</li> </ul>
Service Action Required LED		Amber	<ul style="list-style-type: none"> <li>OFF – Normal operation</li> <li>STEADY ON – Fault present on the Pilot. This LED lights whenever a fault indicator lights for a Pilot replaceable component.</li> </ul> <p><b>Note:</b> When this indicator lights up, there is a system console message that includes a recommended service action.</p>

Table 41: Pilot LED status and description (continued)

LED	Icon	LED color	Status
Power or OK LED		Green	<p>Indicates the operational state of the chassis. This indicator can be in the following states:</p> <ul style="list-style-type: none"> <li>• OFF – AC power is not present.</li> <li>• STEADY BLINK – Standby power is on, but the chassis power is off.</li> <li>• SLOW BLINK – Startup sequence has been initiated on the host. This pattern begins soon after you power on the Pilot. This status indicates either: (1) POST code checkpoint tests are running on the Pilot host system, or (2) the host is transitioning from the powered-on state to the standby state on shutdown.</li> <li>• STEADY ON – The Pilot is powered on, and all host POST code checkpoint tests are complete. The Pilot is in one of the following states: <ul style="list-style-type: none"> <li>• 1) The Pilot host is booting the operating system (OS).</li> <li>• 2) The Pilot host is running the OS.</li> </ul> </li> </ul>
Service Processor LED		Green	<ul style="list-style-type: none"> <li>• OFF – Service processor (SP) is not running.</li> <li>• SLOW BLINK – SP is booting.</li> <li>• STEADY ON – SP is fully operational.</li> </ul>
Top Fan, Processor, Memory Failure LED	TOP	Amber	<p>Indicates that one or more of the internal fan modules, processors, or memory DIMMs have failed.</p> <ul style="list-style-type: none"> <li>• OFF – Indicates steady state; no service is required.</li> <li>• STEADY ON – Indicates service required; service the fan modules, processors, or memory DIMMs.</li> </ul>

Table 41: Pilot LED status and description (continued)

LED	Icon	LED color	Status
Rear Power Supply Failure LED	REAR	Amber	<p>Indicates that one of the Pilot power supplies has failed.</p> <ul style="list-style-type: none"> <li>• OFF – Indicates steady state; no service is required.</li> <li>• STEADY ON – Indicates service required; service the power supply.</li> </ul>
Over Temperature Warning LED		Amber	<ul style="list-style-type: none"> <li>• OFF – Normal operation; no service is required.</li> <li>• STEADY ON – The system is experiencing an over-temperature warning condition.</li> </ul> <p><b>Note:</b> This is a warning indication, not a fatal over temperature. Might result in the system overheating and shutting down unexpectedly.</p>

**Related Links**

[Oracle FS System LEDs](#)

**Pilot Drive LED Indicators**

There are three LEDs on each Pilot drive. There is only one drive in each Pilot.

Table 42: Pilot drive LED status and description

LED	Icon	LED color	Status
OK to Remove		Blue	The storage drive can be removed safely during a hot-swap operation.
Service Required		Amber	<ul style="list-style-type: none"> <li>• OFF – Normal operation.</li> <li>• STEADY ON – The system has detected a fault with the storage drive.</li> </ul>
OK/Activity		Green	<ul style="list-style-type: none"> <li>• OFF – Power is off or the system does not recognize the installed drive.</li> <li>• STEADY ON – The drive is engaged and is receiving power.</li> <li>• STEADY BLINK – There is disk activity. Indicator blinks on and off to indicate activity</li> </ul>

**Related Links**[Oracle FS System LEDs](#)**Pilot Fan LED Indicators**

Each Pilot fan module has one bicolored LED. These LEDs are on the Pilot side wall next to the fan modules and are visible when the top cover fan door is open.

**Table 43: Pilot fan LED status and description**

LED	Icon	LED color	Status
Fan Status LED	NONE	Bicolored: Amber/ Green	<ul style="list-style-type: none"> <li>Amber – There is a fan fault.</li> <li>Green – Fan is properly installed and operating correctly. No fan errors detected.</li> </ul>

**Related Links**[Oracle FS System LEDs](#)**Pilot Port LED Indicators**

The Pilot has LED indicators for Network Management ports and the Ethernet ports.

**Network Management Port Status LEDs**

The Pilot has one 10/100BASE-T Ethernet management domain interface, labeled NET MGT. There are two LEDs on this port. These indicators are visible from the back of the Pilot.

**Table 44: Network management port LED status and description**

LED	Location	LED color	Status
Link speed	Top left	Amber or Green	<ul style="list-style-type: none"> <li>Amber on - 10BASE-T link</li> <li>Green on - 100BASE-T link</li> <li>Off - No link or link down</li> <li>Flashing - No function</li> </ul>
Activity	Top right	Green	<ul style="list-style-type: none"> <li>On - No function</li> <li>Off - No activity</li> <li>Flashing - Packet activity</li> </ul>

**Ethernet Port Status LEDs**

The Pilot has four Ethernet ports (NET 3, NET 2, NET 1, NET 0). There are two LEDs on each port. These LEDs are visible from the back of the Pilot.

**Table 45: Ethernet port LED status and description**

LED	Location	LED color	Status
Link speed	Top left	Green	<ul style="list-style-type: none"> <li>• On - No function.</li> <li>• Off - No activity</li> <li>• Flashing - Packet activity</li> </ul>
Activity	Top right	Amber or Green	<ul style="list-style-type: none"> <li>• Amber on - 100BASE-T link</li> <li>• Green on - 1000/10GBBASE-T link</li> <li>• Off - No link or link down</li> <li>• Flashing - No function</li> </ul>

**Related Links**

[Oracle FS System LEDs](#)

**Pilot Motherboard LED Indicators**

The Pilot motherboard and modules that are installed on the motherboard contain several LEDs.

**Table 46: Motherboard LED status and description**

LED	Description
DDR3 DIMM Fault LED	Each of the 16 DDR3 DIMM slots on the motherboard has an amber fault LED associated with it. If a DIMM is faulty, pressing the Fault Remind button on the motherboard signals the service processor to light the fault LEDs associated with the faulted DIMMs.
Processor Fault LED	<p>The motherboard includes a fault status indicator (LED) next to each of the two processor (CPU) sockets.</p> <p>These LEDs indicate when a processor is faulty. For example, if on reboot the BIOS detects that there are uncorrectable processor errors recorded in the machine check architecture (MCA) registers apparently left over from the previous boot, then the BIOS records and diagnoses these errors.</p> <p>If it is determined that a processor is faulty, pressing the Fault Remind button on the motherboard signals the service processor to light the fault LED associated with the faulted processor.</p>

**Table 46: Motherboard LED status and description (continued)**

LED	Description
Fault Remind Power LED	This LED is located next to the Fault Remind button and is powered from the super capacitor that powers the fault LEDs on the motherboard. This LED lights to indicate that the fault remind circuitry is working properly in cases where no components have failed and, as a result, none of the component fault LEDs illuminate.
Standby Power Good LED	<p>The service instructions for all internal components require that all AC power is removed from the power supplies before the top cover of the Pilot is removed.</p> <p>This green LED is labeled STBY PWRGD and is located on the back of the Pilot near PCIe slot 2.</p> <p>This LED lights to inform a service technician that the motherboard is receiving standby power from at least one of the power supplies. This LED is provided to help prevent service actions on the Pilot's internal components while the AC power cords are installed and power is being supplied to the Pilot.</p>

**Related Links**

[Oracle FS System LEDs](#)

**Pilot Power Supply LED Indicators**

There are two LEDs on each power supply. These LEDs are visible from the back of the Pilot.

**Table 47: Pilot Drive LED status and description**

LED	Icon	LED color	Status
AC OK/ DC OK		Green	<ul style="list-style-type: none"> <li>• OFF – No AC power is present.</li> <li>• SLOW BLINK – Normal operation. Input power is within specification. DC output voltage is not enabled.</li> <li>• STEADY ON – Normal operation. Input AC power and DC output voltage are within specification.</li> </ul>
Service Required		Amber	<ul style="list-style-type: none"> <li>• OFF – Normal operation; no service required.</li> <li>• STEADY ON – The power supply (PS) has detected a PS fan failure, PS over-temperature, PS over current, or PS over or under voltage.</li> </ul>

**Related Links**

[\*Oracle FS System LEDs\*](#)

# Index

## A

- additional resources [23](#)
- air filter
  - how to
    - replace [100](#)
  - service procedures [100](#)
- altitude specifications [275](#)

## B

- backups
  - procedure for backing up data [50](#)
  - when to do [50](#)
- battery
  - how to
    - replace [187](#)
  - service procedures [187](#)

## C

- Caution signal words [35](#)
- component numbering location [44](#)
- component numbering order [44](#)
- component placement location [42](#)
- components, Oracle FS system
  - technical specifications [267](#)
- contact information [24](#)
- contacts, Oracle [24](#)
- Controller
  - how to
    - insert [64](#)
    - install CMA [61](#)
    - install rack rails [53](#)
    - install slide rails [56](#)
    - verify rails [65](#)
  - installing rails [51](#)
- Controller components
  - part numbers [25](#)
  - parts list [25](#)
- Controller hardware components
  - CRU list [25](#)
  - FRU list [25](#)
  - replacement concepts
    - energy storage module (ESM) [117](#)
- Controller rail kits [52](#)
- Controllers
  - how to
    - access Guided Maintenance [39](#)
  - overview [98](#)
- CRUs
  - Drive Enclosure components [29](#)
  - Guided Maintenance [38, 39](#)

- part numbers (*continued*)
  - part numbers
    - Drive Enclosures [29](#)
- customer replaceable units, *see* CRUs
- customer supplied materials [36](#)
- customer support [24](#)

## D

- Danger signal words [35](#)
- DE2-24C Drive Enclosure
  - part numbers [29](#)
- DE2-24C Drive Enclosures
  - physical configuration [166](#)
  - type of Drive Enclosure [166](#)
- DE2-24P Drive Enclosure
  - part numbers [29](#)
- DE2-24P Drive Enclosures
  - physical configuration [166](#)
  - type of Drive Enclosure [166](#)
- DIMM (s)
  - how to
    - replace [149, 228](#)
    - service procedures [149, 228](#)
- documentation
  - conventions
    - Caution, Warning, and Danger signal words [35](#)
  - feedback [24](#)
  - related to service procedures [23](#)
- doors, rack
  - how to
    - remove [49](#)
- Drive Enclosure hardware components
  - backups for [50](#)
  - how to
    - insert a drive [170](#)
    - insert a power cooling module [180](#)
    - insert an I/O module [175](#)
    - remove a drive [170](#)
    - remove a power cooling module [180](#)
    - remove an I/O module [175](#)
    - replace a drive [170](#)
    - replace a power cooling module [180](#)
    - replace an I/O module [175](#)
  - replacement concepts
    - drives [168](#)
- Drive Enclosure rail kits [70](#)
- Drive Enclosures
  - components list [29](#)
  - CRU list [29](#)
  - FRU list [29](#)
  - how to
    - access Guided Maintenance [39](#)

types of (*continued*)  
 how to (*continued*)  
   install rails 72  
   replace drives 168, 170  
   replace I/O modules 175  
   replace power cooling modules 180  
 installing rails 67  
 logical names 44  
 part numbers 29  
 physical configuration 166  
 physical names 44  
 types of  
   DE2-24C Drive Enclosure 166  
   DE2-24P Drive Enclosure 166

drives  
 Drive Enclosures  
   HDDs 166  
   large form factor (LFF) 166  
   small form factor drives (SFF) 166  
   SSDs 166  
 how to  
   insert 170  
   remove 170  
   replace 170  
 part numbers 29  
 service procedures 170

## E

education programs 24  
 electrostatic discharge (ESD)  
   precautions 35  
 energy storage module (ESM)  
   how to  
     replace 117  
   service procedures 117  
 environment, data center  
   Oracle FS system requirements 275

## F

fan modules  
   how to  
     replace 103, 221  
   service procedures 103, 221  
 feedback, documentation 24  
 field replaceable units, *see* FRUs  
 FRUs  
   Drive Enclosure components 29  
   Guided Maintenance 38, 39  
   part numbers  
     Drive Enclosures 29

## G

ground straps  
   personal ESD 35

Guided Maintenance  
 CRUs 38, 39  
 FRUs 38, 39  
 how to  
   access Guided Maintenance 39  
   replace a CRU 39  
   replace a FRU 39  
 overview 36

## H

hardware components  
 CRUs  
   Drive Enclosures 29  
 Drive Enclosure parts list 29  
 FRUs  
   Drive Enclosures 29  
 how to  
   replace a drive 170  
   replace a power cooling module 180  
   replace an I/O module 175  
 replacement concepts  
   air filter 100  
   DIMM (s) 149  
   fan modules 103  
   HBA 135  
   power supplies 112  
   riser board assembly 125  
 types of Drive Enclosures  
   DE2-24C 166  
   DE2-24P 166  
 hardware problems  
   how to  
     perform emergency back up 50  
     replace battery 187  
     replace drives 168  
 hardware specifications  
   altitude 275  
   humidity 275  
   PDU 271  
   temperature 275  
 hazard signal words  
   in English 35  
 HBA  
   how to  
     replace 135  
   service procedures 135  
 HDDs  
*see also* hard disk drives (HDDs)  
   how to  
     replace a drive 170  
     replace drives 168  
   *see also* hard disk drives (HDDs)  
 how to  
   insert 100, 103, 112, 117, 125, 135, 149, 197, 206,  
   217, 221, 228, 238

how to (*continued*)  
 remove [100](#), [103](#), [112](#), [117](#), [125](#), [135](#), [149](#), [197](#), [206](#),  
[217](#), [221](#), [228](#), [238](#)  
 humidity specifications [275](#)

## I

### I/O modules

how to  
 insert [175](#)  
 remove [175](#)  
 replace [175](#)  
 part numbers [29](#)  
 service procedures [175](#)

### insert

air filter [100](#)  
 DIMM (s) [149](#), [228](#)  
 drives [170](#)  
 energy storage module (ESM) [117](#)  
 fan module [103](#), [221](#)  
 HBA [135](#)  
 I/O modules [175](#)  
 Pilot chassis [238](#)  
 power cooling modules [180](#)  
 power supplies [112](#), [217](#)  
 riser board assembly [125](#), [206](#)  
 SAS HBA [197](#)

### installation procedures

tools, required [36](#)

## K

Key Identity Properties (KIP) [35](#), [98](#)

## L

large form factor (LFF) drives, *see* drives

LED status [277](#)

## N

notice conventions, safety [35](#)

## O

online help [24](#)

Oracle documentation [24](#)

### Oracle FS system

component numbering  
 location [44](#)  
 order [44](#)  
 component placement  
 location [42](#)  
 hardware specifications [267](#)

### Oracle FS System

Drive Enclosures  
 replace a drive [170](#)  
 replace a power cooling module [180](#)

how to (*continued*)

Drive Enclosures (*continued*)

replace an I/O module [175](#)

how to

back up data [51](#)

prepare the rack [48](#)

LED status indicators [277](#)

power cycling [51](#)

Oracle FS System Manager

Guided Maintenance [36](#)

Oracle FS Systems

Controllers

overview [98](#)

Pilots, overview [187](#)

Oracle Help Center (OHC) [24](#)

Oracle racks

how to

remove rack doors [49](#)

## P

panels, rack

how to

remove [49](#)

part numbers

Controller components [25](#)

DE2-24C Drive Enclosure chassis [29](#)

DE2-24P Drive Enclosure chassis [29](#)

drives [29](#)

I/O modules [29](#)

Pilot components [32](#)

power cooling modules [29](#)

parts list

Controller components [25](#)

Pilot components [32](#)

PDUs

hardware specifications [271](#)

Pilot

how to

insert [94](#)

install CMA [93](#)

install rack rails [89](#)

install slide rails [92](#)

verify rails [96](#)

Pilot chassis

how to

replace [238](#)

service procedures [238](#)

Pilot components

part numbers [32](#)

parts list [32](#)

Pilot hardware components

CRU list [32](#)

FRU list [32](#)

replacement concepts

battery [187](#)

DIMM (s) [228](#)

---

 replacement concepts (continued)

- fan modules 221
- Pilot chassis 238
- power supplies 217
- riser board assembly 206
- SAS HBA 197

## Pilot rail kits 88

## Pilots

- how to
  - access Guided Maintenance 39
- installing rails 88
- overview 187

## power

- feed requirements of the system 275

## power cooling modules

- how to
  - insert 180
  - remove 180
  - replace 180
- part numbers 29
- service procedures 180

## power cycling, system 51

## power supplies

- how to
  - replace 112, 217
  - service procedures 112, 217

## prepare racks 48

## product support 24

## Q

## quorum devices 35, 98

## R

## rack

- how to
  - install Drive Enclosures 72
  - verify rail installation 65, 96
- safety precautions 50

## rack-ready 52, 88

## racks

- how to
  - remove doors 49
  - remove panels 49

## rail kits 52, 70, 88

## rails

- how to
  - install Drive Enclosures rails 72
  - verify 65, 96

## related books 23

## remove

- air filter 100
- DIMM (s) 149, 228
- drives 170
- energy storage module (ESM) 117
- fan module 103, 221

## rack (continued)

- HBA 135
- I/O modules 175
- Pilot chassis 238
- power cooling modules 180
- power supplies 112, 217
- rack
  - doors 49
  - panels 49
- riser board assembly 125, 206
- SAS HBA 197

## replace

- air filter 100
- battery 187
- DIMM (s) 149, 228
- drives 170
- energy storage module (ESM) 117
- fan module 103, 221
- HBA 135
- I/O modules 175
- Pilot chassis 238
- power cooling modules 180
- power supplies 112, 217
- riser board assembly 125, 206
- SAS HBA 197

## replaceable components

- Guided Maintenance 38, 39
- how to
  - access Guided Maintenance 39

## replacement concepts

- Drive Enclosure
  - drives 168
- Pilot
  - battery 187

## riser board assembly

- how to
  - replace 125, 206
- service procedures 125, 206

## S

## safety

- notice conventions 35

## safety precautions 50

## sales information 24

## SAS HBA

- how to
  - replace 197
  - service procedures 197

## service procedures

- air filter 100
- back up data 50
- battery 187
- CRUs 38, 39
- DIMM (s) 149, 228
- energy storage module (ESM) 117
- fan modules 103, 221

---

how to (*continued*)

FRUs [38, 39](#)

Guided Maintenance [36, 38, 39](#)

HBA [135](#)

how to

access Guided Maintenance [39](#)

remove rack doors [49](#)

remove rack panels [49](#)

replace drives [168](#)

Pilot chassis [238](#)

power supplies [112, 217](#)

replace drives [170](#)

replace I/O modules [175](#)

replace power cooling modules [180](#)

riser board assembly [125, 206](#)

SAS HBA [197](#)

signal words [35](#)

small form factor (SFF) drives, *see* drives

SSDs

*see also* solid state drives (SSDs)

how to

replace a drive [170](#)

replace drives [168](#)

*see also* solid state drives (SSDs)

storage enclosures, *see* Drive Enclosures

Support portal [24](#)

## T

temperature specifications [275](#)

tools, required [36](#)

training programs [24](#)

## W

Warning signal words [35](#)