

Oracle Database Appliance Service Manual

ORACLE

Part No: E75625-02
June 2016

Part No: E75625-02

Copyright © 2016, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable:

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

Référence: E75625-02

Copyright © 2016, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf stipulation expresse de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique:

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. UNIX est une marque déposée d'The Open Group.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers, sauf mention contraire stipulée dans un contrat entre vous et Oracle. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation, sauf mention contraire stipulée dans un contrat entre vous et Oracle.

Contents

Preface	9
1 Overview of System Status Indicators and LEDs	11
Oracle Database Appliance X6-2 Series Status Indicators	11
Oracle Database Appliance X6-2S/X6-2M Status Indicators	11
Oracle Database Appliance X5-2 Status Indicators	12
Server Node Status Indicators	12
Storage Shelf Status Indicators	12
Oracle Database Appliance X3-2/X4-2 Status Indicators	15
Server Node Status Indicators	15
Storage Shelf Status Indicators	15
Oracle Database Appliance (Original Version) Status Indicators	17
Server Node Status Indicators	18
Server Node Fan Indicators	20
Storage and Boot Drive Status Indicators	21
Power Supply Status Indicators	22
Rear Server Node Status Indicators	23
Server Node Internal LEDs	24
Ethernet Port Indicators	25
2 Preparing Oracle Database Appliance for Service	27
Preparing Oracle Database Appliance X6-2 Series for Service	27
Preparing Oracle Database Appliance X3-2/X4-2/X5-2 for Service	28
Preparing Oracle Database Appliance (Original Version) for Service	29
Component Replacement Policy (CRUs and FRUs)	29
Safety Information	31
Required Tools	31
Obtaining the Chassis Serial Number	31
Shutting Down a Server Node and Powering Off the System	32
Performing Electrostatic Discharge and Antistatic Prevention Measures	35

Removing Server Nodes From the System Chassis	35
Removing the Server Node Top Cover	36
Removing the Middle Section of the System Top Cover	37
3 Servicing CRUs That Do Not Require System Power Off	39
Oracle Database Appliance X6-2 Series Server Node Hot-Pluggable Components	39
Servicing NVMe Storage Drives (CRU)	40
Oracle Database Appliance X3-2/X4-2/X5-2 Server Node Hot-Pluggable Components	43
Oracle Database Appliance Storage Shelf Hot-Pluggable Components	43
Replacement Procedures	44
Oracle Database Appliance (Original Version) Hot-Pluggable Components	52
Servicing Storage Drives and Boot Drives (CRU)	53
Servicing Fan Modules (CRU)	58
Servicing Power Supplies (CRU)	61
4 Servicing CRUs That Require Server Node Power Off	65
Servicing Oracle Database Appliance X6-2 Series CRUs	65
Servicing Oracle Database Appliance X3-2/X4-2/X5-2 CRUs	66
Servicing Oracle Database Appliance (Original Version) CRUs	67
Server Node CRU Component Locations	67
Servicing Memory Modules (DIMMs) (CRU)	68
Servicing PCIe Risers (CRU)	77
Servicing PCIe Cards (CRU)	80
Servicing the Server Node Battery (CRU)	88
5 Servicing FRUs	91
Servicing Oracle Database Appliance X6-2 Series FRUs	91
Servicing Oracle Database Appliance X3-2/X4-2/X5-2 FRUs	92
Managing System Faults and FRU ID Information on Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 Series	93
Component Fault Management	93
Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane	94
Servicing Oracle Database Appliance (Original Version) FRUs	99
Removing and Installing the Air Duct (FRU)	100
Servicing Processors (CPUs) (FRU)	102
Servicing the Boot Disk Backplane (FRU)	109
Servicing the Power Distribution Board (FRU)	111

Servicing the Disk Midplane Module (FRU)	115
Servicing the Disk Midplane Module HDD Cable (FRU)	121
Servicing the Front Indicator Panels (FRU)	123
Servicing Server Node Cables	128
Servicing the Motherboard Assembly (FRU)	138
6 Returning Oracle Database Appliance to Operation	143
Returning Oracle Database Appliance X6-2 Series to Operation	143
Returning Oracle Database Appliance X3-2/X4-2/X5-2 to Operation	144
Powering On an Oracle Database Appliance That Includes a Storage Shelf	144
▼ Power On Procedure	145
Returning Oracle Database Appliance (Original Version) to Operation	146
Installing the Server Node Top Cover	146
Installing a Server Node Into the System Chassis	147
Powering On Oracle Database Appliance (Original Version)	149
7 Server Node Diagnostic Tools and Resetting the Service Processor	153
Server Node Diagnostic Tools	153
Resetting the Service Processor	155
8 Server Node Basic Input/Output System (BIOS)	157
Oracle Database Appliance X6-2 Series BIOS Utility	157
Setting Up BIOS Configuration Parameters	158
BIOS Setup Utility Menu Options	158
Oracle Database Appliance X3-2/X4-2/X5-2 BIOS Utility	158
Setting Up BIOS Configuration Parameters	159
BIOS Setup Utility Menu Options	159
Oracle Database Appliance (Original Version) BIOS Utility	160
BIOS Booting and Setup	160
Ethernet Port Naming and Boot Order	167
Configuring Support for TPM	167
Configuring SP LAN Settings	173
Configuring Option ROM Settings in BIOS	175
BIOS Setup Utility Hot Keys	176
Accessing the BIOS Setup Utility Menus	176
BIOS Setup Utility Screens	179
Index	187

Preface

This preface provides the following information:

- “Documentation and Feedback” on page 9
- “Documentation Accessibility” on page 9
- “Change History” on page 10

Documentation and Feedback

Documentation	Link
All Oracle products	http://docs.oracle.com
Oracle Database Appliance	http://www.oracle.com/goto/oda/docs
Oracle Integrated Lights Out Manager (Oracle ILOM) 3.X	http://www.oracle.com/goto/ILOM/docs

Provide feedback on this documentation:

<http://www.oracle.com/goto/docfeedback>

Documentation Accessibility

For information about Oracle's commitment to accessibility, visit the Oracle Accessibility Program website at <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=docacc>.

Access to Oracle Support

Oracle customers have access to electronic support through My Oracle Support. For information, visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.

Change History

The following lists the release history of this documentation set:

- May 2016. Initial publication.
- June 2016. Addition of Oracle Database Appliance X6-2 series.

◆◆◆ CHAPTER 1

Overview of System Status Indicators and LEDs

This manual provides instructions for servicing Oracle Database Appliance hardware. Oracle Database Appliance comes in the following versions:

- Oracle Database Appliance X6-2S/X6-2M
- Oracle Database Appliance X5-2
- Oracle Database Appliance X4-2
- Oracle Database Appliance X3-2
- Oracle Database Appliance original version (also referred to as "version 1" or "V1")

The following sections in this chapter describe system status indicators and LEDs:

- [“Oracle Database Appliance X6-2 Series Status Indicators” on page 11](#)
- [“Oracle Database Appliance X5-2 Status Indicators” on page 12](#)
- [“Oracle Database Appliance X3-2/X4-2 Status Indicators” on page 15](#)
- [“Oracle Database Appliance \(Original Version\) Status Indicators” on page 17](#)

For information about system features and racking, refer to the *Oracle Database Appliance Owner's Guide*. For information about cabling, Oracle ILOM initial setup, and appliance software setup, refer to the *Oracle Database Appliance Getting Started Guide*.

Oracle Database Appliance X6-2 Series Status Indicators

This section describes the status indicators for Oracle Database Appliance X6-2 series.

- [“Oracle Database Appliance X6-2S/X6-2M Status Indicators” on page 11](#)

Oracle Database Appliance X6-2S/X6-2M Status Indicators

These topics describe Oracle Database Appliance X6-2S/X6-2M server node status indicators (LEDs).

Note - The links below take you to topics *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Server Node General Status Indicators	Server Node General Status Indicators
Server Node Fan Status Indicators	Server Node Fan Status Indicators
Server Node Storage Drive Status Indicators	Server Node Storage Drive Status Indicators
Server Node Power Supply Status Indicators	Server Node Power Supply Status Indicators
Server Node Motherboard Status Indicators	Server Node Motherboard Status Indicators

Oracle Database Appliance X5-2 Status Indicators

This section describes the status indicators for Oracle Database Appliance X5-2.

- [“Server Node Status Indicators” on page 15](#)
- [“Storage Shelf Status Indicators” on page 15](#)

Server Node Status Indicators

These topics describe Oracle Database Appliance X5-2 server node status indicators (LEDs).

Note - The links below take you to topics *outside* of the Oracle Database Appliance library to the Oracle Server X5-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.


- [Server Node General Status Indicators](#)
- [Server Node Fan Status Indicators](#)
- [Server Node Storage Drive Status Indicators](#)
- [Server Node Power Supply Status Indicators](#)
- [Server Node Motherboard Status Indicators](#)

Storage Shelf Status Indicators

Storage shelves are supported with Oracle Database Appliance X5-2. They include controls and indicators on the front panel, hard drives, SSD drives, power supplies, and SAS I/O modules.

Storage Shelf Front Panel and Drive Indicators


The following figure shows the controls and indicators on the storage shelf front panel and drives.



Callout	Indicator/LED: Color	State Meaning
1	OK: green	<ul style="list-style-type: none"> ■ On – The storage shelf is powered on and operating normally. ■ Off – The storage shelf is unplugged or turned off.
2	Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault is present in the storage shelf.
3	Locate: white	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Fast blink – This LED blinks to help locate the system. Operators can turn this indicator on and off remotely using Oracle ILOM. ■ Pressing this button toggles the fast blink on or off.
4	Drive Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault is present in the disk drive.
5	Power/Activity: green	<ul style="list-style-type: none"> ■ On – The drive is installed and recognized by the system but there is no drive activity. ■ Blink – The LED blinks randomly in response to data being written to or read from the drive. ■ Off – The drive is powered off or the installed drive is not recognized by the system.

Storage Shelf Back Panel Indicators

The following figure shows the controls and indicators on the storage shelf back panel and drives.



Callout	Indicator/LED: Color	State Meaning
1	AC power fault indicator: amber	<ul style="list-style-type: none"> ■ On – Indicates an AC power fault. ■ Off – Normal operation.
2	Power supply status indicator: green	<ul style="list-style-type: none"> ■ On – The power supply is operating normally. ■ Off – The power supply is unplugged or turned off.
3	Fan fail indicator: amber	<ul style="list-style-type: none"> ■ On – The fan is faulty. ■ Off – Normal operation.
4	DC power fail indicator: amber	<ul style="list-style-type: none"> ■ On – The power supply is faulty. ■ Off – Normal operation.
5	SAS I/O Module status indicators: green or amber	<ul style="list-style-type: none"> ■ OK – Lights green to indicate normal operation. ■ Service Required – Lights amber to indicate a fault with the I/O module (top module is 0; bottom module is 1).
6	Reserved	This port is reserved for Oracle Service.
7	Network port (reserved)	This port is reserved for Oracle Service.
8	Host SAS port activity indicators (x4 per port): green	Lights green to indicate host SAS link activity.

Oracle Database Appliance X3-2/X4-2 Status Indicators

This section describes the status indicators for Oracle Database Appliance X3-2 and Oracle Database Appliance X4-2.

- [“Server Node Status Indicators” on page 15](#)
- [“Storage Shelf Status Indicators” on page 15](#)

Server Node Status Indicators

These topics describe Oracle Database Appliance X3-2 and Oracle Database Appliance X4-2 server node status indicators (LEDs).

Note - The links in the following table take you to topics *outside* of the Oracle Database Appliance library to the Sun Server X3-2 and Sun Server X4-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.


Oracle Database Appliance X3-2	Oracle Database Appliance X4-2
Server Node General Status Indicators	Server Node General Status Indicators
Server Node Fan Status Indicators	Server Node Fan Status Indicators
Server Node Storage Drive Status Indicators	Server Node Storage Drive Status Indicators
Server Node Power Supply Status Indicators	Server Node Power Supply Status Indicators
Server Node Motherboard Status Indicators	Server Node Motherboard Status Indicators

Storage Shelf Status Indicators

Storage shelves are supported with Oracle Database Appliance X3-2/X4-2. They include controls and indicators on the front panel, hard drives, SSD drives, power supplies, and SAS I/O modules.

Storage Shelf Front Panel and Drive Indicators


The following figure shows the controls and indicators on the storage shelf front panel and drives.



Callout	Indicator/LED: Color	State Meaning
1	OK: green	<ul style="list-style-type: none"> ■ On – The storage shelf is powered on and operating normally. ■ Off – The storage shelf is unplugged or turned off.
2	Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault is present in the storage shelf.
3	Locate: white	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Fast blink – This LED blinks to help locate the system. Operators can turn this indicator on and off remotely using Oracle ILOM. ■ Pressing this button toggles the fast blink on or off.
4	Status Code Display	Not used for this product.
5	Drive Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault is present in the disk drive.
6	Power/Activity: green	<ul style="list-style-type: none"> ■ On – The drive is installed and recognized by the system but there is no drive activity. ■ Blink – The LED blinks randomly in response to data being written to or read from the drive. ■ Off – The drive is powered off or the installed drive is not recognized by the system.

Storage Shelf Back Panel Indicators

The following figure shows the controls and indicators on the storage shelf back panel and drives.



Callout	Indicator/LED: Color	State Meaning
1	AC power fault indicator: amber	<ul style="list-style-type: none"> ■ On – Indicates an AC power fault. ■ Off – Normal operation.
2	Power supply status indicator: green	<ul style="list-style-type: none"> ■ On – The power supply is operating normally. ■ Off – The power supply is unplugged or turned off.
3	Fan fail indicator: amber	<ul style="list-style-type: none"> ■ On – The fan is faulty. ■ Off – Normal operation.
4	DC power fail indicator: amber	<ul style="list-style-type: none"> ■ On – The power supply is faulty. ■ Off – Normal operation.
5	SAS I/O Module status indicators: green or amber	<ul style="list-style-type: none"> ■ OK – Lights green to indicate normal operation. ■ Service Required – Lights amber to indicate a fault with the I/O module (top module is 0; bottom module is 1).
6	Reserved	This port is reserved for Oracle Service.
7	Network port (reserved)	This port is reserved for Oracle Service.
8	Host SAS port activity indicators (x4 per port): green	Lights green to indicate host SAS link activity.

Oracle Database Appliance (Original Version) Status Indicators


This section describes the status indicators for the original version Oracle Database Appliance.

- [“Server Node Status Indicators” on page 18](#)
- [“Server Node Fan Indicators” on page 20](#)

- “Storage and Boot Drive Status Indicators” on page 21
- “Power Supply Status Indicators” on page 22
- “Rear Server Node Status Indicators” on page 23
- “Server Node Internal LEDs” on page 24
- “Ethernet Port Indicators” on page 25

Server Node Status Indicators

The following table lists and describes the general status indicators on the front and rear panel of each Oracle Database Appliance (original version) server node.



Callout	Indicator/LED: Color	State Meaning
1	Locate button/LED: white	■ Off – Normal operation.


Callout	Indicator/LED: Color	State Meaning
		<ul style="list-style-type: none"> ■ Fast blink – This LED blinks to help locate the system. Operators can turn this indicator on and off remotely using Oracle ILOM. ■ Pressing this button toggles the fast blink on or off. It is also used to prove physical presence. ■ Indicator Test Mode – Push and hold the Locate button for 5 seconds to activate the push to test feature, which causes all LEDs except disk activity and power supply LEDs to light for 15 seconds.
2	SP OK/Fault: bi-color	<ul style="list-style-type: none"> ■ Off – No power is supplied to the SP or it is not functional. ■ Amber – When lit indicates an SP fault. ■ Green – When steady on indicates that Oracle ILOM is fully functional. If blinking, POST diagnostics are running, Oracle ILOM is booting, or firmware is updating. <p>Note - The amber LED indicates the status of the watchdog timer. The watchdog timer runs continuously, but it times out if it is not reset by Oracle ILOM. If it times out, the amber LED is lit and the green LED is extinguished.</p>
3	Ready to Remove: blue	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Fast Blink – The system is preparing a customer-replaceable unit (CRU) (disk drive, fan module, or power supply) for safe removal but it is not ready yet. ■ Steady on – The CRU can be safely removed.
4	Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault is present in system or a subsystem within the chassis.
5	Power/OK: green	<p>This LED indicates the operational state of the chassis. This LED can be in the following states:</p> <ul style="list-style-type: none"> ■ Off – AC power is not present or the Oracle ILOM boot has not completed. ■ Standby blink – Standby power is on and Oracle ILOM can be accessed, but full chassis power is off. The LED blinks at a 10 percent duty cycle (0.1 second on, 2.9 seconds off), that is, the light is on for a very short period of time. ■ Slow blink – The startup sequence has been initiated on the host. The LED blinks at a 50 percent duty cycle, which is noticeably longer than the STANDBY BLINK. This pattern should begin immediately following powering on the system. This status indicates either 1) power-on self-test (POST) diagnostics running on system host or 2) the host is transitioning from the powered-on state to the standby state on shutdown. ■ Steady on – The system is powered on and all host POST tests passed. The system is one of the following states: 1) the system host is ready to boot, or 2) the system host is booting the operating system (OS), or 3) the system host is running the OS.
6	Over temperature: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – The system is experiencing an over-temperature warning condition.

Callout	Indicator/LED: Color	State Meaning
7	Rear Component Failure: amber	<p>Note - This is a warning indication, not a fatal over temperature. Failure to correct this can result in the system over heating and shutting down.</p> <ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – The system has detected a power supply fault, a fan fault, or a rear 2.5-inch disk drive fault. <p>This fault condition is associated with chassis components located in the rear of the chassis. This fault might be caused by:</p> <ul style="list-style-type: none"> ■ Power supply failure (AC fault, 12V/3.3Vaux fault, or power supply fan fault) ■ Rear fan failure ■ Rear 2.5-inch disk failure

Server Node Fan Indicators

Each fan module for Oracle Database Appliance (original version) has a single bi-colored LED indicating both fan OK and fan fault conditions. The LED lights green to indicate that the fan module is properly plugged into the system and operating within the expected RPM range for a given power management setting. The LED lights amber to indicate a fan fault.

Note - The LEDs on the fan modules are not lit amber on initial system power-on. The fan amber LED only lights if Oracle ILOM detects a failure that indicates a faulty fan module or a missing fan that should be installed.



Indicator/LED: Color	State Meaning
OK: green	<ul style="list-style-type: none"> ■ Steady on – The fan is functioning normally. ■ Off – Chassis 3.3V_Standby power is off or there is a fan fault.
Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault has been detected with the fan. <p>Note - The front and rear panel Service Required LEDs are also lit if the system detects a fan module fault.</p>

Storage and Boot Drive Status Indicators


Each storage drive for Oracle Database Appliance (original version) includes three LEDs. They are the same on the front storage drives and the rear-mounted boot drives. See the following table.



Callout	Indicator/LED: Color	State Meaning
1	Ready to Remove: blue	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Fast blink – The system is preparing a disk drive for safe removal but it is not ready yet. ■ Steady on – The disk drive can be safely removed.
2	Service Required: amber	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Steady on – A fault is present in the disk drive.
3	OK/Activity: green	<ul style="list-style-type: none"> ■ On – The drive is installed and recognized by the system but there is no drive activity. ■ Blink – The LED blinks randomly in response to data being written to or read from the drive. ■ Off – The drive is powered off or the installed drive is not recognized by the system.

Power Supply Status Indicators

There are three status LEDs on each power supply for Oracle Database Appliance (original version), as shown in the following table.




Callout	Indicator/LED: Color	State Meaning
1	OK: green	<ul style="list-style-type: none"> ■ On – The power supply is operating normally. ■ Off – The power supply is unplugged or turned off.

Callout	Indicator/LED: Color	State Meaning
2	Service Required: amber	<ul style="list-style-type: none"> ■ On – The power supply is faulty. The front REAR PS LED and the front and rear panel Service Required LEDs are also lit if the system detects a power supply fault. ■ Off – Normal operation.
3	AC Present: green	<ul style="list-style-type: none"> ■ On – The power supply is plugged in and AC power is available, regardless of system power state. ■ Off – The power supply is unplugged or turned off.

Rear Server Node Status Indicators

Each server node in Oracle Database Appliance (original version) has four summary status LEDs that are located on its back panel, as shown in the following table.



Callout	Indicator/LED: Color	State Meaning
1	Locate: white	<ul style="list-style-type: none"> ■ Off – Normal operation. ■ Fast blink – This LED blinks to help locate the system. Operators can turn this indicator on and off remotely using Oracle ILOM. ■ Pressing this button toggles the fast blink on or off. ■ Indicator Test Mode – Push and hold the Locate button for 5 seconds to activate the push to test feature, which causes all LEDs except disk activity and power supply LEDs to light for 15 seconds.
2	Ready to Remove: blue	<ul style="list-style-type: none"> ■ Off – Normal operation.

Callout	Indicator/LED: Color	State Meaning
3	Service Required: amber	<ul style="list-style-type: none"> ■ Fast Blink – The system is preparing a customer-replaceable unit (CRU) (disk drive, fan module, or power supply) for safe removal but it is not ready yet. ■ Steady on – The CRU can be safely removed. ■ Off – Normal operation. ■ Steady on – A fault is present in system or a subsystem within the chassis.
4	Power/OK: green	<p>This LED indicates the operational state of the chassis. This LED can be in the following states:</p> <ul style="list-style-type: none"> ■ Off – AC power is not present or the Oracle ILOM boot has not completed. ■ Standby blink – Standby power is on and Oracle ILOM can be accessed, but full chassis power is off. The LED blinks at a 10 percent duty cycle (0.1 second on, 2.9 seconds off), that is, the light is on for a very short period of time. ■ Slow blink – The startup sequence has been initiated on the host. The LED blinks at a 50 percent duty cycle, which is noticeably longer than the STANDBY BLINK. This pattern should begin immediately following powering on the system. This status indicates either 1) power-on self-test (POST) diagnostics running on system host or 2) the host is transitioning from the powered-on state to the standby state on shutdown. ■ Steady on – The system is powered on and all host POST tests passed. The system is one of the following states: 1) the system host is ready to boot, or 2) the system host is booting the operating system (OS), or 3) the system host is running the OS.

Server Node Internal LEDs

The following section describes the internal LEDs for Oracle Database Appliance (original version). Each server node contains the following internal LEDs:

Note - A super capacitor (located on the motherboard) provides power to light the server node fault LEDs for up to 15 minutes after the server node is removed from a powered-on system chassis. After approximately 15 minutes, the capacitor discharges enough so that it cannot light the fault LEDs.

- **Fault Remind Power Good LED.**
 This green LED lights each time the Fault Remind button is pressed, if the capacitor has enough of a charge to light the fault LEDs. This LED is located next to the Fault Remind button.
 For the location of Fault Remind button and the Fault Remind Power Good LED, see [“Remove Faulty DIMMs” on page 70](#).
- **Memory DIMM Fault LEDs**

Each DIMM slot has an adjacent DIMM fault LED. If a DIMM fails, the adjacent LED lights when the Fault Remind button is pressed.

For the location of Fault Remind button and the DIMM fault LEDs, see [“Remove Faulty DIMMs” on page 70](#).

- CPU Fault LEDs

Both CPUs have an associated CPU fault LED. If a CPU fails, the associated LED lights when the Fault Remind button is pressed.


For the location of CPU fault LEDs, see [“Remove Processor \(CPU\)” on page 102](#).

- Ethernet Port LEDs

Each server node has two host Ethernet ports (NET0 and NET1) and an SP network management port (NET MGT). Each of these has two LEDs that indicate link activity and port speed. See [“Ethernet Port Indicators” on page 25](#).

Ethernet Port Indicators

Each server node in Oracle Database Appliance (original version) has two host Ethernet ports (NET0 and NET1) and an SP network management port (NET MGT). Each of these has two LEDs that indicate link activity and port speed.



Callout	Indicator/LED: Color	State Meaning
1	Link Activity: green	Lights to indicate link activity.
2	Link Speed: bi-colored	Green – Link established at fastest speed. Amber – Link established at next fastest speed or slower speeds. Off – Link at slowest speed, which is 10 Mbps.

Preparing Oracle Database Appliance for Service

This chapter describes how to prepare Oracle Database Appliance for servicing.

It includes the following topics:

- [“Preparing Oracle Database Appliance X6-2 Series for Service” on page 27](#)
- [“Preparing Oracle Database Appliance X3-2/X4-2/X5-2 for Service” on page 28](#)
- [“Preparing Oracle Database Appliance \(Original Version\) for Service” on page 29](#)

Preparing Oracle Database Appliance X6-2 Series for Service

This section describes preparing Oracle Database Appliance X6-2 series for service. If you have Oracle Database X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Preparing Oracle Database Appliance X3-2/X4-2/X5-2 for Service” on page 28](#). If you have Oracle Database Appliance (original version), go to [“Preparing Oracle Database Appliance \(Original Version\) for Service” on page 29](#).

Most service procedures are performed on a single appliance component. Before powering off any component for service, refer to the *Getting Started Guide* or *Administration and Reference Guide* for any special instructions or commands that must be performed on the appliance to prepare it for service.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Safety Precautions	Safety Precautions
Safety Symbols	Safety Symbols

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Electrostatic Discharge Safety	Electrostatic Discharge Safety
Required Tools	Required Tools
Powering Down the Server	Powering Down the Server
Disconnect Cables From the Server	Disconnect Cables From the Server
Extend the Server to the Maintenance Position	Extend the Server to the Maintenance Position
Remove the Server From the Rack	Remove the Server From the Rack
Take Antistatic Measures	Take Antistatic Measures
Remove the Server Top Cover	Remove the Server Top Cover

Preparing Oracle Database Appliance X3-2/X4-2/X5-2 for Service

This section describes preparing Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, and Oracle Database Appliance X5-2 for service. If you have Oracle Database Appliance X6-2 series, go to [“Preparing Oracle Database Appliance X6-2 Series for Service” on page 27](#). If you have Oracle Database Appliance (original version), go to [“Preparing Oracle Database Appliance \(Original Version\) for Service” on page 29](#).

Most service procedures are performed on a single appliance component. Service procedures that require a single server node to be powered off can be performed without shutting down the entire appliance. Before powering off any component for service, refer to the *Getting Started Guide* or *Administration and Reference Guide* for any special instructions or commands that must be performed on the appliance to prepare it for service.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2, and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
Safety Precautions	Safety Precautions	Safety Precautions
Safety Symbols	Safety Symbols	Safety Symbols
Electrostatic Discharge Safety	Electrostatic Discharge Safety	Electrostatic Discharge Safety
Required Tools	Required Tools	Required Tools
Powering Down the Server	Powering Down the Server	Powering Down the Server
Disconnect Cables From the Server	Disconnect Cables From the Server	Disconnect Cables From the Server
Extend the Server to the Maintenance Position	Extend the Server to the Maintenance Position	Extend the Server to the Maintenance Position

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
Remove the Server From the Rack	Remove the Server From the Rack	Remove the Server From the Rack
Take Antistatic Measures	Take Antistatic Measures	Take Antistatic Measures
Remove the Server Top Cover	Remove the Server Top Cover	Remove the Server Top Cover

Preparing Oracle Database Appliance (Original Version) for Service

This chapter describes how to prepare Oracle Database Appliance (original version) for servicing. If you have Oracle Database X6-2 series, go to [“Preparing Oracle Database Appliance X6-2 Series for Service” on page 27](#). If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Preparing Oracle Database Appliance X3-2/X4-2/X5-2 for Service” on page 28](#).

- [“Component Replacement Policy \(CRUs and FRUs\)” on page 29](#)
- [“Safety Information” on page 31](#)
- [“Required Tools ” on page 31](#)
- [“Obtaining the Chassis Serial Number” on page 31](#)
- [“Shutting Down a Server Node and Powering Off the System” on page 32](#)
- [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#)
- [“Removing Server Nodes From the System Chassis” on page 35](#)
- [“Removing the Server Node Top Cover” on page 36](#)
- [“Removing the Middle Section of the System Top Cover” on page 37](#)

Component Replacement Policy (CRUs and FRUs)

The replaceable components in your Oracle Database Appliance (original version) are designated as either field-replaceable units (FRUs) or customer-replaceable units (CRUs). Some can be replaced with the power on, some require the powering off of a server node, and some require the powering off of the entire system chassis.

- A part designated as a FRU must be replaced by Oracle-qualified service technician.
- A part designated as a CRU can be replaced by a person who is not an Oracle-qualified service technician.

The following table lists replaceable components, their service designation (CRU or FRU), and the system power policy related to servicing the component.

Component	Policy
Storage drives and boot drives (CRU)	Hot-pluggable – Can be removed and replaced when the system is powered on.
Fan modules (CRU)	Hot-pluggable – Can be removed and replaced when the system is powered on.
Power supplies (CRU)	Hot-pluggable – Can be removed and replaced when the system is powered on.
Air duct (FRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
DIMMs (CRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
PCIe risers (CRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
PCIe cards (CRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Boot disk backplane (FRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Server node battery (CRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Processors (CPUs) (FRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Motherboard (FRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Server node internal cables (FRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Power distribution board (FRU)	Cold service, system chassis – Servicing this component requires that the power be completely removed from the system chassis (both server nodes powered off).
Disk midplane module (FRU)	Cold service, system chassis – Servicing this component requires that the power be completely removed from the system chassis (both server nodes powered off).
Disk midplane module HDD cable (FRU)	Cold service, server node – Can only be removed and replaced when the server node is powered off. The other server node and the system chassis can remain on.
Front indicator panels (FRU)	Cold service, system chassis – Servicing this component requires that the power be completely removed from the system chassis (both server nodes powered off).

Safety Information

This section provides important safety information. Read it before servicing Oracle Database Appliance.



Caution - Hazardous voltage present. Never run the system with the top cover removed.



Caution - Equipment damage. Install the system top cover properly before starting the system.

For your protection, observe the following safety precautions when setting up your equipment:

- Follow all cautions, warnings, and instructions marked on the equipment and described in *Important Safety Information for Oracle's Hardware Systems* and *Oracle Database Appliance Safety and Compliance Guide*.
- Ensure that the voltage and frequency of your power source match the voltage and frequency inscribed on the equipment's electrical rating label.
- Follow the electrostatic discharge safety practices as described in this chapter.

Required Tools

Oracle Database Appliance can be serviced with the following tools:

- Antistatic wrist strap
- Antistatic mat
- No. 2 10-inch Phillips screwdriver (magnetic tip recommended)
- Flat blade screwdriver
- Stylus or pencil (to press the Clear CMOS button)

Obtaining the Chassis Serial Number

To obtain support for Oracle Database Appliance (original version), you need to report your product serial number. The product serial number is located on an RFID tag on the front of the system and on the Customer Information Sheet that is included with the system.

Shutting Down a Server Node and Powering Off the System

You can shut down either Oracle Database Appliance (original version) server node using the front panel power button, or Oracle ILOM. Each method provides a *graceful shutdown* and an *emergency shutdown* option.



Caution - Data loss. To avoid data loss and file system corruption, always use a graceful shutdown unless it is an emergency.

Note - To use Oracle ILOM to shut down a server node, ensure that you have performed its initial configuration as described in "Connecting and Configuring Oracle ILOM" in the *Oracle Database Appliance Getting Started Guide*.

After you have shut down the server nodes, you can power off the system.

See the following topics in this section to shut down a server node and power off the system chassis:

- [“Shut Down a Server Node” on page 32](#)
- [“Power Off the System” on page 34](#)

▼ Shut Down a Server Node

You must shut down the server node before you remove it from the system chassis.


1. To shut down a server node using the Power button, perform one of the following:

- **Graceful shutdown:** Press and release the recessed Power button on the lower left-hand corner of the server node's front panel (see the following figure [1]). This causes Advanced Configuration and Power Interface (ACPI) to perform an orderly shutdown of the system.
- **Emergency shutdown:** Press and hold the recessed Power button on the lower left-hand corner of the server node's front panel for at least five seconds until the main power is off and the server node enters standby power mode (see the following figure [1]).



Caution - Data loss. To avoid data loss and file system corruption, always use a graceful shutdown unless it is an emergency.

When the server node is shut down, the Power/OK LED [2] on the server node's front panel flashes, indicating that the server node is in standby power mode.



2. To shut down a server node using the Oracle ILOM, perform one of the following:
 - Using the Oracle ILOM web interface:
 - a. Open a browser and enter the server node's service processor IP address in the browser's address field.
 - b. At the log in page, type a user name (the account must have Reset and Host Control (r) privileges) and password, and click the Log In button.
 - c. Go to Remote Power Control and do one of the following:
 - Select **Graceful Shutdown and Power Off** from the Select Action list box and then click Save and OK.
The server node shuts down gracefully.
 - Select **Immediate Power Off** from the Select Action list box and then click Save and OK.
The server node shuts down immediately.



Caution - Data loss. To avoid data loss and file system corruption, use graceful shutdown unless it is an emergency.

■ **Using the Oracle ILOM CLI:**

a. **Log in to Oracle ILOM using an ssh client. Type:**

```
$ssh username@sp_ip_address
```

Where *username* is a user account name with Reset and Host Control (r) privileges and *sp_ip_address* is the IP address of the server node service processor.

b. **When prompted, enter the user account password.**

c. **Enter the command to shut down the server node:**

- For a graceful shutdown, type:

```
-> stop /SYS
```

The server node shuts down gracefully.

- For an emergency shutdown, type:

```
-> stop -f /SYS
```

The server node shuts down immediately.



Caution - Data loss. To avoid data loss and file system corruption, use graceful shutdown unless it is an emergency.

▼ **Power Off the System**

The appliance database must be shut down before powering off the system chassis.

1. **Shut down both server nodes.**

Shutting down both server nodes places the system in standby power mode.

See [“Shut Down a Server Node” on page 32](#).

2. **Disconnect the AC power cords from the system.**

Disconnecting the power cords from the system removes all power from the system.

Performing Electrostatic Discharge and Antistatic Prevention Measures

Electrostatic discharge (ESD) sensitive devices, such as the motherboards, PCIe cards, storage drives, and memory cards, require special handling.



Caution - Equipment damage. Follow antistatic precautions and do not touch the components along their connector edges.

When handling components such as storage drive assemblies, circuit boards, or PCIe cards:

- Attach an *antistatic strap* to your wrist and then to a metal area on the chassis. Following this practice equalizes the electrical potential between you and the system.

Note - An antistatic wrist strap is not included in the system Accessory Kit. However, antistatic wrist straps are included with some options and components.

- Place ESD-sensitive components on an *antistatic mat*. The following items can be used as an antistatic mat:
 - Antistatic bag used to wrap a replacement part
 - ESD mat
 - Disposable ESD mat (shipped with some replacement parts or optional system components)

Removing Server Nodes From the System Chassis

You must remove the Oracle Database Appliance (original version) server node from the chassis to remove or replace internal server node components.

▼ Remove a Server Node From the System Chassis

The removal procedure is the same for both server nodes. Note that you do not need to remove the entire system chassis from the rack to perform service procedures on a server node.

Note - Replacing a server node FRU with a new server node is a service activity that must be performed by an Oracle-qualified service technician. The customer may remove the server node to service other CRU components in the server node.

1. **Shut down the server node.**


See [“Shut Down a Server Node” on page 32.](#)



Caution - Data loss. To avoid data loss and file system corruption, always use a graceful shutdown unless it is an emergency.

2. **To unseat the server node from the system chassis, pull the two latches on the rear of the server node down [1].**

The latches are marked by green tabs. Pull the latches down and away from the rear to the system.



3. **Slide the server node to the rear and lift it out of the system [2].**

Removing the Server Node Top Cover


To gain access to a most of Oracle Database Appliance (original version) server node's internal components, you must remove the server node's top cover.

▼ Remove the Server Node Top Cover

1. **Remove the server node from the system chassis.**

See [“Shut Down a Server Node” on page 32.](#)

2. Remove the top cover.
 - a. To unlatch the server node top cover, press and hold the green release button on the top of the server node cover [1].
 - b. Using the indented area near the green release button, slide the cover toward the front of the server node about 0.5 inches (12.7 mm) [1].
 - c. Lift the cover up and remove it [2].



Removing the Middle Section of the System Top Cover

To gain access to the Oracle Database Appliance (original version) power distribution board and the disk midplane board you must remove the middle section of the system's top cover.

▼ Remove the Middle Section of System Top Cover

1. Power down the server nodes and remove the power cords from the power supplies.

For instructions, see [“Shut Down a Server Node” on page 32](#).



Caution - System fault. Do not remove the middle section of the system cover while the AC power cords are connected. Otherwise the fault LEDs light and a system fault is logged.

2. Remove the middle section of the system top cover.


To remove the middle section of the system's top cover, remove the captive Phillips screws that secure it to the system.



Caution - Hazardous voltage present. Never run the system with the middle section of the system top cover removed.



Caution - Equipment damage. Install the system top cover properly before starting the system.



Servicing CRUs That Do Not Require System Power Off

This chapter describes how to remove and replace the hot-pluggable components in Oracle Database Appliance. Hot-pluggable means that these components can be replaced with the system powered on.

Note - Hot-pluggable components can also be replaced with the system powered off. If you choose this method, first power off the system as described in [Chapter 2, “Preparing Oracle Database Appliance for Service”](#).

The following topics are covered:

- [“Oracle Database Appliance X6-2 Series Server Node Hot-Pluggable Components” on page 39](#)
- [“Oracle Database Appliance X3-2/X4-2/X5-2 Server Node Hot-Pluggable Components” on page 43](#)
- [“Oracle Database Appliance Storage Shelf Hot-Pluggable Components” on page 43](#)
- [“Oracle Database Appliance \(Original Version\) Hot-Pluggable Components” on page 52](#)

Oracle Database Appliance X6-2 Series Server Node Hot-Pluggable Components

This section describes replacing hot-pluggable components for the Oracle Database Appliance X6-2 series server node. If you have the Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Oracle Database Appliance X3-2/X4-2/X5-2 Server Node Hot-Pluggable Components” on page 43](#). If you have Oracle Database Appliance (original version), go to [“Oracle Database Appliance \(Original Version\) Hot-Pluggable Components” on page 52](#).

Hot-pluggable components are those that can be removed and installed while the system and the server nodes are running. These are designated as Customer Replaceable Units (CRUs).

Refer to the following table for hot-plug component instructions for your appliance.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Servicing Non-NVMe Storage Drives (CRU) Caution - NVMe disks are not hot-swappable. If you remove an NVMe drive without first powering it off, you can crash the operating system. Oracle Database Appliance uses special commands to add or remove NVMe storage, see the link below. “Servicing NVMe Storage Drives (CRU)” on page 40 Servicing Fan Modules (CRU) Servicing Power Supplies (CRU)	Servicing Non-NVMe Storage Drives (CRU) Caution - NVMe disks are not hot-swappable. If you remove an NVMe drive without first powering it off, you can crash the operating system. Oracle Database Appliance uses special commands to add or remove NVMe storage, see the link below. “Servicing NVMe Storage Drives (CRU)” on page 40 Servicing Fan Modules (CRU) Servicing Power Supplies (CRU)

Servicing NVMe Storage Drives (CRU)

This section describes servicing NVMe drives in an Oracle Database Appliance X6-2 series system.

- [“Replacing an NVMe Storage Drive” on page 40](#)
- [“Adding NVMe Expansion Storage” on page 42](#)

▼ Replacing an NVMe Storage Drive

NVMe solid state drives are not hot-swappable. Before removing a drive it must be powered off. After installing a drive it must be powered on. Failed drives are automatically powered off after 5 minutes.



Caution - If you remove an NVMe drive without first powering it off, you can crash the operating system. Oracle Database Appliance uses special commands to add or remove NVMe storage.

These instructions describe how to replace an NVMe drive using the `odaamcli power on/off` commands for an Oracle Database X6-2 series system.

1. **Identify the NVMe drive to be replaced. Type the following command at the host:**

```
# odaamcli show disk
```

For example, the drive names `pd_00` and `pd_01` seen by the host, correspond to drive slot labels NMe0 and NVMe1, respectively.

2. Unmount and power off the drive to be replaced. Do one of the following:

- **If you are replacing a failed drive, check to see if its blue ready-to-remove light is lit.**

If a drive has failed, it should power off automatically and light its blue ready-to-remove indicator after 5 minutes.

- **If the drive being replaced doesn't already have its blue ready-to-remove indicator lit, type the following command from the host to unmount and turn off power to the drive:**

```
# odaadmcli power disk off pd_xx
```

Where `pd_xx` is the name of the disk to be replaced as described in step 1.

Before proceeding to the next step confirm that the blue ready-to-remove indicator on the drive is lit.

3. Push the latch release button on the front of the drive to open the drive latch, grasp the latch, and pull the drive out of the drive slot.

4. Align the replacement drive with the drive slot.

The drive is physically addressed according to the slot in which it is installed. It is important to install a replacement drive in the same slot as the drive that was removed.

5. Slide the drive into the slot until the drive is fully seated. Then close the drive latch to lock the drive in place.

6. Power on and remount the replacement drive. Type the following command from the host:

```
# odaadmcli power disk on pd_xx
```

Where `pd_xx` is the name of the disk being replaced as described in step 1.

It can take a few minutes for the power-on operation to complete. Once complete, the drive's green OK indicator will light.

7. To check the status of the replacement disk, type the following command from the host:

```
# odaadmcli show disk
```

For additional information, refer to the *Deployment and User's Guide*.

▼ Adding NVMe Expansion Storage

Before You Begin The Oracle Database Appliance X6-2S/X6-2M includes two expansion slots for NVMe drives (slots labeled NVMe2 and NVMe3 as seen from the front of the system). When adding NVMe storage, you must populate both of these slots.

If you have the default configuration of only two NVMe drives (seen as `pd_00` and `pd_01` from the host), then you can expand storage by adding two (2) NVMe drives.

Note - If you expand storage, then you must add two (2) disks and expand storage on both disks at the same time. Once you expand storage to four (4) NVMe drives, you cannot revert to the default configuration of two (2) NVMe drives.

1. Insert the new NVMe drives into the expansion disk slots.

The name for these drives to the host will be `pd_02` and `pd_03`, matching the numbering of their respective drive slots.

2. Slide the drive into the slot until the drive is fully seated. Then close the drive latch to lock the drive in place. Repeat for the second drive.

3. Power on both drives by typing the following commands from the host:

```
$ odaadmcli power disk on pd_02
```

```
$ odaadmcli power disk on pd_03
```

It can take a few minutes for the power-on operation to complete. Once complete, the green OK indicator will light for both drives.

Note - Do not run attempt to power on and expand storage on one disk and then power on and expand storage on the second disk. Before you expand storage, both disks must be powered on with their green OK indicator lit.

4. Expand the system storage to include the new drives. Type the following command from the host:

```
$ odaadmcli expand storage
```

For additional information, refer to the Oracle Database Appliance *Deployment and User's Guide*.

Oracle Database Appliance X3-2/X4-2/X5-2 Server Node Hot-Pluggable Components

This section describes replacing hot-pluggable components for the Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2. If you have Oracle Database Appliance X6-2 series, go to [“Oracle Database Appliance X6-2 Series Server Node Hot-Pluggable Components” on page 39](#). If you have Oracle Database Appliance (original version), go to [“Oracle Database Appliance \(Original Version\) Hot-Pluggable Components” on page 52](#).

Hot-pluggable components are those that can be removed and installed while the system and the server nodes are running. These are designated as Customer Replaceable Units (CRUs).

Note - For Oracle Database Appliance X3-2 and Oracle Database Appliance X4-2 bare metal installations, you must run the `oakcli add disk -local` command after replacing a failed disk. Refer to the *Administration and Reference Guide* for details.

Refer to the following table for hot-plug component instructions for your appliance.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2, and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
Servicing Storage Drives (CRU)	Servicing Storage Drives (CRU)	Servicing Storage Drives (CRU)
Servicing Fan Modules (CRU)	Servicing Fan Modules (CRU)	Servicing Fan Modules (CRU)
Servicing Power Supplies (CRU)	Servicing Power Supplies (CRU)	Servicing Power Supplies (CRU)

Oracle Database Appliance Storage Shelf Hot-Pluggable Components

This section describes replacing hot-pluggable components for the Oracle Database Appliance storage shelf. Only certain versions of Oracle Database Appliance support a storage shelf. If you have Oracle Database Appliance (original version), go to [“Oracle Database Appliance \(Original Version\) Hot-Pluggable Components” on page 52](#).

A storage shelf, or expansion storage shelf, are only supported with the following Oracle Database Appliance products:

- Oracle Database Appliance X5-2 supports the DE2-24C shelf.
- Oracle Database Appliance X3-2 and X4-2 support the DE2-24P shelf.

Hot-pluggable components are those that can be removed and installed while the system and the server nodes are running. These are designated as Customer Replaceable Units (CRUs).



Caution - Data loss. Do not remove power from both power supplies of the storage shelf or storage expansion shelf (if equipped) while the database is running. If you must power off the storage shelf or expansion storage shelf, stop the database first.

Note - After a physical insertion or removal action of a storage shelf component (such as a disk or SAS cable), you should wait before performing the next action to allow the system software to fully process the event. This could take up to 3 minutes to complete.

Replacement Procedures

Oracle Database Appliance X3-2/X4-2 (DE2-24P) and Oracle Database Appliance X5-2 (DE2-24C) storage shelf components can all be replaced while the storage shelf is powered-on and running. They include:

- [“Replace a Storage Shelf HDD or SSD \(CRU\)” on page 44](#)
- [“Replace a Storage Shelf Power Supply \(CRU\)” on page 46](#)
- [“Replace a Storage Shelf I/O Module \(CRU\)” on page 49](#)


▼ Replace a Storage Shelf HDD or SSD (CRU)

1. **Locate the failed drive on the front of the chassis.**




Caution - Equipment damage. Do not remove a drive unless you have an immediate replacement.

2. **Remove the drive:**
 - For the DE2-24C, press the button to release the drive lever, rotate the lever open and, grasping the drive body, slide the drive out of the chassis.




- For the DE2-24P, press the button to release the drive lever, rotate the lever open and, grasping the drive body, slide the drive out of the chassis.




3. Install the replacement drive:

- For the DE2-24C, open the drive lever on the replacement drive and slide the replacement drive as far into the drive slot as possible and then close the lever to lock it into place. Check that the drive is locked in place and flush with the other drives.



- For the DE2-24P, open the drive lever on the replacement drive and slide the replacement drive as far into the drive slot as possible and then close the lever to lock it into place. Check that the drive is locked in place and flush with the other drives.




▼ Replace a Storage Shelf Power Supply (CRU)

The storage shelf and the storage expansion shelf each have two power supplies. Indicators (LEDs) on the power supplies indicate their operation state.

The power supplies are redundant and one can be replaced while the appliance is running.


Example showing a DE2-24C or DE2-24P power supply:




Callout	Description
1	AC power fail indicator
2	Fan fail indicator
3	Power supply status indicator
4	DC power fail indicator
5	Release lever
6	AC connector
7	On/Off switch

If any of the indicators are amber, or if the power supply status indicator does not light, replace the power supply.

1. **Ensure the power supply on/off switch is in the "O" off position.**
2. **Disconnect the power cord tie strap from the power cord, and unplug the power cord from the power supply.**
3. **Remove the power supply unit:**
 - For the DE2-24C, push the ejector release button [1], grasp the power supply ejector handle and rotate it to the open position [2]. Slide the power supply out of the chassis.



- For the DE2-24P power supply, push the ejector release button [1], grasp the power supply ejector handle and rotate it to the open position [2]. Slide the power supply out of the chassis.



4. **Open the lever/ejection arms on the replacement power supply.**
5. **Slide the replacement power supply module into the chassis.**
Be careful to not bend the pins.
6. **Close the lever/ejection arms.**
Push the lever fully closed until you hear or feel a click.


▼ **Replace a Storage Shelf I/O Module (CRU)**

Storage Shelf SAS I/O modules are fully redundant and can be replaced while the appliance is running.


1. **Disconnect the cables from the I/O module.**

Be sure to mark the cables so you can return them to their proper connectors.

Example showing the DE2-24C:




Example showing the DE2-24P:




Callout	Description
1	I/O module locking levers
2	I/O module 1 (top)
3	I/O module 0 (bottom)

2. Remove the I/O module:

- For the DE2-24C, using your thumb and forefinger, squeeze the release button [1] toward the locking lever hole to release the lever [2]. Grasp the lever and remove the I/O module from the chassis.



- For the DE2-24P, using your thumb and forefinger, squeeze the release button [1] toward the lever hole to release the locking lever [2]. Grasp the lever and remove the I/O module from the chassis.



Caution - Equipment damage. Be careful not to damage the connector pins at the back of the I/O module.

3. **Open the lever in the new I/O module if it is not already open.**
4. **Slide the new I/O module into the disk shelf and close the locking lever.**
5. **Reconnect the cables.**
6. **Verify that the new I/O module is working correctly.**
 - After approximately 60 seconds, the power LED should be solid green and the Fault/Locate LED should be off.
 - For each port that has a cable connected, all four activity LEDs should be solid green.

Oracle Database Appliance (Original Version) Hot-Pluggable Components

This section describes replacing hot-pluggable components for the Oracle Database Appliance (original version). If you have Oracle Database Appliance X6-2 series, go to [“Oracle Database Appliance X6-2 Series Server Node Hot-Pluggable Components” on page 39](#). If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Oracle Database Appliance X3-2/X4-2/X5-2 Server Node Hot-Pluggable Components” on page 43](#) or [“Oracle Database Appliance Storage Shelf Hot-Pluggable Components” on page 43](#).

Hot-pluggable components are those that can be removed and installed while the system and the server nodes are running. These are designated as Customer Replaceable Units (CRUs).

In Oracle Database Appliance (original version), the following devices are hot-pluggable:

- Storage and Boot Drives. See [“Servicing Storage Drives and Boot Drives \(CRU\)” on page 53](#).
- Fan modules. See [“Servicing Fan Modules \(CRU\)” on page 58](#).
- Power supplies. See [“Servicing Power Supplies \(CRU\)” on page 61](#).

Note - After a physical insertion or removal action of a storage component (such as a disk or SAS cable), you should wait before performing the next action to allow the system software to fully process the event. This could take up to 3 minutes to complete.

Note - For the Oracle Database Appliance (original version), you must run the `oakcli add disk -local` command after replacing a failed disk. Refer to the *Administration and Reference Guide* for details.

Servicing Storage Drives and Boot Drives (CRU)

Oracle Database Appliance (original version) has 24 storage drives, located in the front of the chassis, and each server node has 2 boot drives, located in the rear. All storage drives and boot drives are hot-pluggable.

See [“Storage and Boot Drive Status Indicators” on page 21](#) for specific information about drive status LEDs.

This section includes:

- [“Storage and Boot Drive Locations” on page 53](#)
- [“Remove a Storage Drive” on page 54](#)
- [“Install Storage Drive” on page 55](#)
- [“Remove a Boot Drive” on page 56](#)
- [“Install a Boot Drive” on page 57](#)

Storage and Boot Drive Locations

Appliance storage drives. Appliance storage drives are installed at the front of Oracle Database Appliance (original version). Drive numbering is listed on the drive label on the right side of the appliance [1].



The following table shows slot numbering and the type of the storage drive supported in each slot.

Note - The appliance might include both mechanical hard disk (HDD) and solid state (SSD) drives. Both use the same 2.5 inch disk drive bracket. An SSD has a smaller footprint inside of the bracket than an HDD.

If a drive has failed, its amber Service Required LED will be lit. For information on drive status LEDs, see [“Storage and Boot Drive Status Indicators” on page 21](#). For specific drive locations, see [“Storage and Boot Drive Locations” on page 53](#).

2. Remove a storage drive.

- a. On the drive you plan to remove, push the storage drive release button to open the latch [1].
- b. Grasp the latch and open it to a 45 degree angle [2].
- c. Using the latch, slowly pull the drive straight out of the drive slot, not sideways or vertically.


Do not use much force on the latch when removing the drive.



Caution - Equipment damage. Do not use the latch as an ejector. Do not bend it too far to the right.



Caution - Equipment damage. Always replace a drive with another drive to maintain proper airflow.




▼ Install Storage Drive

1. Determine the drive slot location for the replacement drive.

Drives are physically addressed according to the slot in which they are installed. See [“Storage and Boot Drive Locations” on page 53](#) for drive locations.

2. **Slide the drive into the drive slot until it is fully seated.**



3. **Close the latch to lock the drive in place.**
4. **Run the `fwupdate` command and verify that it lists all the disks under the DISKS section.**

▼ **Remove a Boot Drive**

1. **Identify the boot drive that you want to remove.**
The amber Service Required LED might be lit. For specific drive locations, see [“Storage and Boot Drive Locations”](#) on page 53.
2. **Remove the boot drive.**
 - a. **To open the drive door, slide the latch to the left.**

- b. Pull the door open [2].
- c. On the drive you plan to remove, push the storage drive release button to open the latch [2].
- d. Grasp the latch and open it to a 45 degree angle [2].
- e. Using the latch, slowly pull the drive straight out of the drive slot, not sideways or vertically [2].


Do not use much force on the latch when removing the drive.



Caution - Equipment damage. Do not use the latch as an ejector. Do not bend it too far to the right.



Caution - Equipment damage. Close the door after removing a boot drive to prevent overheating due to improper airflow.




▼ Install a Boot Drive

1. Determine the drive slot location for the replacement drive.

Drives are physically addressed according to the slot in which they are installed. See [“Storage and Boot Drive Locations” on page 53](#) for drive locations.

2. **Pull open the rear drive door.**
3. **Slide the drive into the drive slot until it is fully seated [1].**



4. **Close the drive latch to lock the drive in place.**
5. **Close the drive door and ensure that the door latch engages [2].**



Caution - Equipment damage. Close the door after removing a boot drive to prevent overheating due to improper airflow.

6. **Run the following command to ensure that the OS sees the replacement disk.**

```
# ls SCSI -v | grep ATA
[0:0:0:0] disk ATA SEAGATE ST95001N n/a /dev/sda
[1:0:0:0] disk ATA SEAGATE ST95001N n/a /dev/sdb
```

Servicing Fan Modules (CRU)

Each Oracle Database Appliance (original version) server node contains two fan modules. Each fan module contains a single, dual-motor, 80 mm, counter-rotating fan assembly that contains two fans. Each fan module is hot-pluggable. For specific information about fan status LEDs, see [“Server Node Fan Indicators” on page 20](#).

When a server node is removed from the system, the fans provide sufficient cooling for all 24 front disks and the server node. A door automatically closes off the vacant server node slot to

ensure proper cooling. When the server node is replaced, its two fans also cool the 24 front disks and provide cooling to the second server node.



Caution - Equipment damage. If a fan module fails, replace it as soon as possible.

The following topics are covered in this section:

- [“Detecting a Fan Module Failure” on page 59](#)
- [“Remove a Fan Module” on page 59](#)
- [“Install a Fan Module” on page 60](#)

Detecting a Fan Module Failure

The following LEDs are lit when a fan module fault is detected:

- Front and rear Service Required LEDs located on each server node
- REAR HDD/PS/FAN LED located on the front of each server node
- Fan Fault Status LED located on the faulty fan module

The system over-temperature LED for a server node might light if a fan fault causes an increase in server node operating temperature. See [“Server Node Status Indicators” on page 18](#) for more information about server node LEDs.


▼ Remove a Fan Module



Caution - Equipment damage. When removing a fan module from a powered on system, it must be replaced within two minutes of removal.

1. **Identify the faulty fan module with its amber LED.**
When a fan fails, the Service Required LED lights amber. For information about fan status LEDs, see [“Server Node Fan Indicators” on page 20](#).
2. **To remove the faulty fan module, press down on the fan release lever [1].**
3. **While holding the release lever down, use the handle on the fan module to pull it out of the server node [2].**

The fan door swings shut to ensure proper cooling.




▼ Install a Fan Module

1. **Align the fan module in the fan door and slide it into the server node.**

The extender on the side of the fan module pushes the fan door open, allowing the fan module to enter.

2. **Apply firm pressure to fully seat the fan module.**

The fan release lever engages when the fan is fully seated.



3. Verify that the Fan Fault Status LED on the replacement fan module is lit green.
4. Verify that the following fault LEDs on the applicable server node are off.
 - Front and rear Service Required LEDs located on the applicable server node
 - REAR HDD/PS/FAN LED located on the front of the applicable server node

See [“Server Node Status Indicators”](#) on page 18 for more information about system LEDs.

Servicing Power Supplies (CRU)

Oracle Database Appliance (original version) is equipped with two hot pluggable power supplies. They are redundant, meaning that the system can operate with a single power supply. This allows you to remove and replace a power supply without shutting the system down.

If a power supply fails and you do not have a replacement available, to ensure proper airflow, leave the failed power supply installed in the system.

For information about power supply status LEDs, see [“Power Supply Status Indicators” on page 22](#).

This section includes:

- [“Detecting a Power Supply Failure” on page 62](#)
- [“Remove a Power Supply” on page 62](#)
- [“Install a Power Supply” on page 63](#)

Detecting a Power Supply Failure

The following LEDs light up when the system detects a power supply fault:

- Front and rear Service Required LEDs located on each server node
- REAR HDD/PS/FAN LED located on the front of each server node
- Service Required LED located on the faulty power supply

See [“Server Node Status Indicators” on page 18](#) on page 1-6 for information about these LEDs.

▼ Remove a Power Supply



Caution - Hazardous voltages. To reduce the risk of electric shock and danger to personal health, follow the instructions.


1. Identify which power supply (0 or 1) requires replacement.

A lit Service Required LED on a power supply indicates that a failure was detected. For information about power supply status LEDs, see [“Power Supply Status Indicators” on page 22](#).

2. Disconnect the power cord from the faulty power supply.

3. Grasp the power supply handle and press the release latch [1]).


4. Pull the power supply out of the chassis [2].



▼ Install a Power Supply

1. Align the replacement power supply with the empty power supply chassis bay.
2. Slide the power supply into the bay until it is fully seated.

The release latch engages when the power supply is fully seated.



3. Reconnect the power cord to the power supply and verify the following:

- The power supply AC Present LED is lit
- The power supply Service Required LED is off.

4. Verify that the following LEDs are off:

- Service Required LEDs located on the front of both server nodes
- REAR HDD/PS/FAN LED located on the front of both server nodes

See [“Storage and Boot Drive Locations”](#) on page 53 for more information about system LEDs.

◆◆◆ CHAPTER 4

Servicing CRUs That Require Server Node Power Off

These sections describe how to service customer-replaceable units (CRUs) for the Oracle Database Appliance that require you to power off the server node. All of these CRUs are located on the server nodes.

Note - The servicing of hot-plug components such as the HDDs, SDDs, power supplies, and fans is described in [Chapter 3, “Servicing CRUs That Do Not Require System Power Off”](#).

- [“Servicing Oracle Database Appliance X6-2 Series CRUs” on page 65](#)
- [“Servicing Oracle Database Appliance X3-2/X4-2/X5-2 CRUs” on page 66](#)
- [“Servicing Oracle Database Appliance \(Original Version\) CRUs” on page 67](#)

Servicing Oracle Database Appliance X6-2 Series CRUs

This section describes how to service customer-replaceable units (CRUs) for Oracle Database Appliance X6-2 series. If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Servicing Oracle Database Appliance X3-2/X4-2/X5-2 CRUs” on page 66](#). If you have Oracle Database Appliance (original version), go to [“Servicing Oracle Database Appliance \(Original Version\) CRUs” on page 67](#).

This section describes how to service customer-replaceable units (CRUs) that require you to power off the server.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
---------------------------------	---------------------------------

CRU List	CRU List
--------------------------	--------------------------

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Servicing DIMMs (CRU)	Servicing DIMMs (CRU)
Servicing PCIe Risers (CRU)	Servicing PCIe Risers (CRU)
Servicing PCIe Cards (CRU)	Servicing PCIe Cards (CRU)
Servicing Internal USB Flash Drives (CRU)	Servicing Internal USB Flash Drives (CRU)
Servicing the Battery (CRU)	Servicing the Battery (CRU)

Servicing Oracle Database Appliance X3-2/X4-2/X5-2 CRUs

This section describes how to service customer-replaceable units (CRUs) for Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2. If you have Oracle Database Appliance X6-2 series, go to [“Servicing Oracle Database Appliance X6-2 Series CRUs” on page 65](#). If you have Oracle Database Appliance (original version), go to [“Servicing Oracle Database Appliance \(Original Version\) CRUs” on page 67](#).

This section describes how to service customer-replaceable units (CRUs) that require you to power off the server.

Note - All of the CRUs on the storage shelf and the storage expansion shelf can be replaced while the power is on. See [“Oracle Database Appliance Storage Shelf Hot-Pluggable Components” on page 43](#) for storage shelf component replacement procedures.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2, and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
CRU Locations	CRU Locations	CRU List
Servicing DIMMs (CRU)	Servicing DIMMs (CRU)	Servicing DIMMs (CRU)
Servicing PCIe Risers (CRU)	Servicing PCIe Risers (CRU)	Servicing PCIe Risers (CRU)
Servicing PCIe Cards (CRU)	Servicing PCIe Cards (CRU)	Servicing PCIe Cards (CRU)
Servicing a DVD Drive (CRU)	Servicing a DVD Drive (CRU)	An optional DVD drive for this system is considered a FRU. See “Servicing Oracle Database Appliance X3-2/X4-2/X5-2 FRUs” on page 92 .
This system does not include an internal USB flash drive.	Servicing the Internal USB Flash Drives (CRU) Note - A factory installed flash drive is reserved for future use.	Servicing the Internal USB Flash Drives (CRU) Note - A factory installed flash drive is reserved for future use.
Servicing the Battery (CRU)	Servicing the Battery (CRU)	Servicing the Battery (CRU)

Servicing Oracle Database Appliance (Original Version) CRUs


This section describes how to service customer-replaceable units (CRUs) for Oracle Database Appliance (original version). If you have Oracle Database Appliance X6-2 series, go to [“Servicing Oracle Database Appliance X6-2 Series CRUs” on page 65](#). If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Servicing Oracle Database Appliance X3-2/X4-2/X5-2 CRUs” on page 66](#).

This section includes information on how to service the following Oracle Database Appliance (original version) CRUs:

- [“Server Node CRU Component Locations” on page 67](#)
- [“Servicing Memory Modules \(DIMMs\) \(CRU\)” on page 68](#)
- [“Servicing PCIe Risers \(CRU\)” on page 77](#)
- [“Servicing PCIe Cards \(CRU\)” on page 80](#)
- [“Servicing the Server Node Battery \(CRU\)” on page 88](#)

Server Node CRU Component Locations

Each server node (also called a system controller) in Oracle Database Appliance (original version) includes the following replaceable components.



Callout	Description
1	DDR3 Memory DIMMs (12)
2	PCIe Cards Mounted on PCIe Riser
3	PCIe Riser
4	Internal HBA PCIe Card
5	Battery

Servicing Memory Modules (DIMMs) (CRU)

Each server node in Oracle Database Appliance (original version) is provisioned with twelve 1333 MHz or 1600 MHz DDR3, 8GB dual rank DIMMs, for a total of 96GB.

The server node supports a maximum memory speed of 1333 MHz, even if 1600 MHz DIMMs are installed.

Before replacing a DIMM see the following:

- DIMM and CPU physical layout.
For details, see [“DIMM and CPU Physical Layout” on page 69](#).
- Instructions for removing a faulty DIMM.
For details, see [“Remove Faulty DIMMs” on page 70](#).
- Instructions for installing a DIMM.
For details, see [“Install DIMMs” on page 73](#).
- Memory Error Correction and Parity
For details, see [“Error Correction and Parity Protection” on page 76](#).



Caution - These procedures require you to handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#).

DIMM and CPU Physical Layout


Each processor in Oracle Database Appliance (original version) has six DIMM slots numbered D0 through D5. D0 is the closest to the processor and D5 is the farthest.

Each slot should contain a 1333 MHz or 1600 MHz DDR3, 8GB dual rank DIMM. No other configurations are supported.

The server node supports a maximum memory speed of 1333 MHz, even if it is configured with 1600 MHz DIMMs.

If the system contains a mixture of 1333 MHz and 1600 MHz DIMMs, then P0 and P1 should be configured the same, so that both sides are symmetrical. For example, if you install only two 1600 MHz DIMMs, they should go into P0, D0 and P1, D0.

The following picture shows the physical layout of the DIMMs and CPUs. When viewing the server node from the front, CPU0 (P0) is on the right.



Each processor socket supports three independent memory channels labeled channel A, B, and C, where channel A is closest to the processor socket. Each channel supports two DIMM slots, is controlled by an independent memory controller, and operates independent of the other channels.

▼ Remove Faulty DIMMs

Note - The DDR3 memory modules (DIMMs) are customer-replaceable units (CRUs) and do not require an Oracle-qualified service person for replacement.

1. Prepare the server node for service.

a. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

b. Remove the server node from the system.

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.


c. Remove the server node top cover.

See [“Removing the Server Node Top Cover”](#) on page 36.

2. Identify the faulty DIMM(s).

- a. To identify the location of a faulty DIMMs, press the Fault Remind button on the motherboard.


Note - When the Fault Remind button is pressed, the Fault Remind Power Good LED lights green to indicate that there is sufficient voltage present in the fault remind circuit to light the fault LEDs. If this LED fails to light when you press the Fault Remind button, the capacitor powering the fault remind circuit has lost its charge. This can happen if the Fault Remind button is pressed for a long time with fault LEDs lit or if the server node has been out of the chassis for more than 15 minutes.



Callout	Description
1	Fault Remind Button
2	Fault Remind Power Good LED (green)


- b. Note the location of faulty DIMMs.

The amber DIMM fault LEDs light if the adjacent DIMM is faulty.



- If the DIMM fault LED is off, the DIMM is operating properly.
 - If the DIMM fault Required LED is on (amber), the DIMM is faulty and should be replaced.
3. To remove the faulty DIMM(s), do the following:
- a. Rotate both DIMM slot ejectors outward as far as they go.
The ejectors push the DIMM partially up.

- b. Carefully lift the DIMM straight up to remove it from the socket.



Callout	Description
1	DIMM connector slot
2	DIMM connector key
3	DIMM ejector lever

4. Replace each faulty DIMM with either another DIMM of the same rank size.

For DIMM replacement instructions, see [“Install DIMMs” on page 73](#).



Caution - Do not operate the system with an empty DIMM slot. If you remove a DIMM, you must replace it before starting the server.

▼ Install DIMMs

1. **Unpack the replacement DIMMs and place them on an antistatic mat.**
2. **Ensure that the replacement DIMMs match the system requirements.**


The system supports only 1333 MHz or 1600 MHz DDR3, 8GB, dual rank DIMMs obtained from Oracle.

For the best performance, if you combine 1333 MHz and 1600 MHz DIMMs in a single system, they should be configured so that P0 and P1 have the same mixture, in the same DIMM slots. For example, in a 1333 MHz system, if you replace P0, D0 with a 1600 MHz DIMM, you should also replace P1, D0 with a 1600 MHz DIMM.

The server node supports a maximum memory speed of 1333 MHz, even if 1600 MHz DIMMs are installed.

- 3. Ensure that the ejector tabs are in the open position.**
- 4. Align the replacement DIMM with the connector.**

Align the notch in the DIMM with the key in the connector. The notch ensures that the DIMM is oriented correctly.



5. **Push the DIMM into the connector until the ejector tabs lock the DIMM in place.**
If the DIMM does not easily seat into the connector, verify that the notch in the DIMM is aligned with the key in the connector as shown above. If the notch is not aligned, damage to the DIMM might occur.
6. **Repeat Step 3 through Step 5 until all replacement DIMMs are installed.**
7. **Return the server node to operation.**

- a. **Install the server node top cover.**
See [“Installing the Server Node Top Cover”](#) on page 146.
 - b. **Install the server node into the system.**
See [“Installing a Server Node Into the System Chassis”](#) on page 147.
 - c. **Power on the server node.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.
8. **Clear the DIMM faults.**

- a. **Log in to the server node Oracle ILOM CLI as root.**
- b. **To view server node faults, type the following command:**

```
-> show /SP/faultmgmt
```

Oracle ILOM lists all known faults. For example:

```
SP/faultmgmt
Targets:
0 (/SYS/MB/P0/D2)
Properties:
Commands:
cd
show
```

- c. **To clear the DIMM fault, type the following command:**

```
-> set /SYS/MB/Px/Dn clear_fault_action=true
```

For example, to clear a fault on the DIMM in location D2 on CPU0:

```
-> set /SYS/MB/P0/D2 clear_fault_action=true
Are you sure you want to clear /SYS/MB/P0 (y/n)? y
Set 'clear_fault_action' to 'true'
```

Error Correction and Parity Protection

The server node's processor provides parity protection on its internal cache memories, and error-correcting code (ECC) protection of the data. The server node detects and posts the following errors to the Oracle ILOM event log:

- Correctable and uncorrectable memory ECC errors
- Uncorrectable CPU internal errors

Advanced ECC corrects up to 4 bits in error on nibble boundaries, as long as they are all in the same DRAM. If a DRAM fails, the DIMM continues to function.

To clear a fault once the faulty DIMM has been replaced, type the following in the Oracle ILOM CLI:

```
-> set clear_fault_action=true
```

For more information on clearing DIMM faults, see the *Oracle Integrated Lights Out Manager (Oracle ILOM) 3.0 Documentation Collection*: <http://www.oracle.com/goto/ILOM/docs>.

Servicing PCIe Risers (CRU)

PCIe cards in Oracle Database Appliance (original version) are installed on a vertical riser. You must remove the riser to remove and replace a PCIe card. Also, you must remove the PCIe riser when replacing the motherboard.

This section includes:

- “Remove PCIe Riser From Server Nodes” on page 77
- “Install PCIe Riser in Server Nodes” on page 79



Caution - These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in “Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35.

▼ Remove PCIe Riser From Server Nodes

1. **Prepare the server node for service.**
 - a. **Attach an antistatic wrist strap.**

See “Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35.
 - b. **Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See “Removing Server Nodes From the System Chassis” on page 35.
 - c. **Remove the server node top cover.**

See “Removing the Server Node Top Cover” on page 36.

2. **If you are servicing a PCIe card, locate its position on the riser.**
3. **Disconnect any data cables connected to the cards on the PCIe riser being removed.**

To disconnect a cable from a PCIe card, press the latch, push in toward the connector, and then pull out to remove the cable.


Note the location of all cables for reinstallation later.

4. **Ensure that the latch adjacent to the location where PCIe riser is installed is in the open (down) position [1].**

If the latch is in the closed position, it prevents you from removing the PCIe riser.

5. **Loosen the three green captive Phillips screws that secure the PCIe riser to the server node [1].**


Access these screws from the rear of the server node.



6. **Loosen the green captive Phillips screw that secures the PCIe riser to the motherboard [2].**
7. **To lift the PCIe riser out of the server node, grasp the front-most side plastic tab with one hand and the rear of the riser with the other hand, and lift it straight up and out of the server node [2].**
8. **Place the PCIe riser and any cards attached to it on an antistatic mat.**

▼ Install PCIe Riser in Server Nodes

1. Before installing the PCIe riser, ensure that the latch adjacent to the location where PCIe riser is to be installed is in the open (down) position [2].
2. Install the PCIe riser.
 - a. Ensure that any PCIe cards installed in the PCIe riser are properly seated, and that the card's locking bracket is flush with the recess in the riser and is engaging the locking tab.
For instructions for installing a PCIe card into a PCIe riser, see [“Install PCIe Card in PCIe Riser” on page 82](#).
 - b. Lower the PCIe riser and any cards attached to it, into the server node [1].
 - c. Push the PCIe riser down until its connector is seated into the connector on the motherboard.
 - d. Tighten the green captive Phillips screw that secures the riser to the motherboard [1].



- e. Tighten the three green captive Phillips screws that secure the PCIe riser to the chassis [2].

Access these screws from the rear of the server node.

3. **Return the server node to operation.**
 - a. **Install the server node top cover.**
See [“Installing the Server Node Top Cover”](#) on page 146.
 - b. **Install the server node into the system.**
See [“Installing a Server Node Into the System Chassis”](#) on page 147.
 - c. **Reconnect any data cables to the PCIe card connectors on the system rear panel.**
 - d. **Power on the server node.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

4. **Clear PCIe riser faults.**

- a. **Log in to the Oracle ILOM CLI as root.**

- b. **Type:**

```
-> show /SP/faultmgmt
```

Oracle ILOM lists all known faults. For example:

```
SP/faultmgmt
Targets:
0 (/SYS/MB/RISER)
Properties:
Commands:
cd
show
```

- c. **To clear PCIe riser faults, use the set command. For example:**

```
-> set /SYS/MB/RISER clear_fault_action=true
Are you sure you want to clear /SYS/MB/RISER (y/n)? y
Set 'clear_fault_action' to 'true'
```

Servicing PCIe Cards (CRU)

This section describes servicing PCIe cards in Oracle Database Appliance (original version).

- [“PCIe Card Configuration”](#) on page 81
- [“Remove PCIe Card From PCIe Riser”](#) on page 81
- [“Install PCIe Card in PCIe Riser”](#) on page 82

- [“Remove Primary HBA PCIe Card From Motherboard” on page 85](#)
- [“Install Primary HBA PCIe Card in Motherboard” on page 86](#)

PCIe Card Configuration

The Oracle Database Appliance (original version) PCIe expansion system includes one standalone low-profile slot on the motherboard and a PCIe riser with three slots. These are provisioned as follows:

- Motherboard slot – A low-profile, dual-port SAS-2 HBA used internally
- PCIe slot 2 – Dual-port SAS-2 HBA used internally
- PCIe slot 1 – Quad-port 1-Gb Ethernet NIC
- PCIe slot 0 – Dual-port 10-Gb Ethernet NIC



Caution - If you replace a PCIe card, ensure the replacement is identical to the card you are replacing.

▼ Remove PCIe Card From PCIe Riser

- 1. Prepare the server node for service.**
 - a. Attach an antistatic wrist strap.**

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#).
 - b. Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis” on page 35](#).
 - c. Remove the server node top cover.**

See [“Removing the Server Node Top Cover” on page 36](#).
- 2. Locate the PCIe card in the PCIe riser that you want to remove.**

See the "Oracle Database Appliance (Original Version) Back Panel" section of the *Oracle Database Owner's Guide* for the location of the PCIe slots.
- 3. If necessary, make a note of where the PCIe cards are installed.**
- 4. Disconnect all data cables from the PCIe card.**

To disconnect a cable from the PCIe card, press the latch, push in toward the connector, and then pull out to remove the cable.


Note the location of all cables for reinstallation later.

5. Remove the PCIe riser.

See [“Remove PCIe Riser From Server Nodes” on page 77](#).

6. Remove the PCIe card from the riser.

- a. Carefully disconnect the PCIe card from the riser connector and remove it from the riser board connector.




- b. Place the PCIe card on an antistatic mat.

▼ Install PCIe Card in PCIe Riser

1. **Unpack the replacement PCIe card and place it on an antistatic mat.**

2. **Locate the proper PCIe slot for the card you are replacing.**
3. **Remove the PCIe riser.**
See [“Remove PCIe Riser From Server Nodes”](#) on page 77.
4. **Insert the PCIe card into the correct slot on the riser.**
 - a. **Press the PCIe card until the locking bracket on the PCIe card is flush with the recessed area on the PCIe riser.**
 - b. **Slide the locking bracket down until it engages the PCIe riser locking tab.**



Callout	Description
1	Recessed area on the PCIe riser
2	PCIe riser locking tab
3	PCIe card locking bracket

5. **Install the PCIe riser.**

See [“Install PCIe Riser in Server Nodes”](#) on page 79.

6. **Reconnect any cables to the PCIe card that you unplugged during the removal procedure.**
7. **Return the server node to operation.**
 - a. **Install the server node top cover.**

See [“Install Server Node Top Cover”](#) on page 146.
 - b. **Install the server node into the system.**

See [“Install Server Node Into System Chassis”](#) on page 147.
 - c. **Reconnect any data cables to the PCIe card connectors on the system rear panel.**
 - d. **Power on the server node.**

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.
8. **Clear the PCIe card fault.**
 - a. **Log in to the server node as root using the Oracle ILOM CLI.**
 - b. **To view server node faults, type the following command to list all known faults on the system:**

```
-> show /SP/faultmgmt
```

Oracle ILOM lists all known faults, for example:

```
SP/faultmgmt
Targets:
0 (/SYS/MB/RISER/PCIE2)
Properties:
Commands:
cd
show
```
 - c. **To clear PCIe riser faults, use the set command. For example:**

```
-> set /SYS/MB/RISER clear_fault_action=true
Are you sure you want to clear /SYS/MB/RISER (y/n)? y
Set 'clear_fault_action' to 'true'
```
 - d. **To clear a PCIe card fault, use the set command. For example, to clear a fault on PCIe 2:**

```
-> set /SYS/MB/RISER/PCIE2 clear_fault_action=true
Are you sure you want to clear /SYS/MB/RISER/PCIE2 (y/n)? y
Set 'clear_fault_action' to 'true'
```

▼ Remove Primary HBA PCIe Card From Motherboard

1. Prepare the server node for service.

a. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

b. Remove the server node from the system.

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.


c. Remove the server node top cover.

See [“Removing the Server Node Top Cover”](#) on page 36.

2. Remove the primary PCIe card.

a. Locate the internal PCIe card [1].

The internal PCIe card is located next to the rear-mounted disk drives.



b. Disconnect the data cables from the PCIe card [1].

There are two data cables that connect the PCIe card to the server node connector that connects to disk drive backplane.

Note the location of all cables for reinstallation later.


To disconnect the cables from the internal PCIe card, press the latch, push in toward the connector, and then pull out to remove the cable.

- c. **Grasp the PCIe card and lift it up and out of the server node [2].**
- d. **Place the PCIe card on an antistatic mat.**

▼ Install Primary HBA PCIe Card in Motherboard

- 1. **Unpack the replacement PCIe card and place it on an antistatic mat.**
- 2. **Install the internal PCIe card.**
 - a. **Locate the connector for the internal PCIe card [1].**

The internal PCIe connector is located next to the rear-mounted disk drives.



- b. **Align the notch on the PCIe card with the key on the motherboard connector [1].**

- c. **Align the rear of the PCIe card with the support bracket located on the rear of the server node [1].**
- d. **Press down on the PCIe to seat it into the connector [1].**



Caution - If the notch and key are not aligned, damage to the PCIe card might occur.

Note - To install the primary HBA into the HBA slot on the motherboard, a special PCI metal bracket is required. The standard low-profile metal bracket or full-height metal bracket must be removed from the PCIe card and replaced with the unique metal bracket that is provided with the system.

- e. **Reconnect the cables to the PCIe card that you disconnected during the removal procedure [2].**
3. **Return the server node to operation.**
 - a. **Install the server node top cover.**
See [“Install Server Node Top Cover”](#) on page 146.
 - b. **Install the server node into the system.**
See [“Install Server Node Into System Chassis”](#) on page 147.
 - c. **Power on the server node.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.
 4. **Clear the primary HBA card fault.**
 - a. **Log in to the server node as root using the Oracle ILOM CLI.**
 - b. **To view server node faults, type the following command to list all known faults on the server node:**

```
-> show /SP/faultmgmt
```

Oracle ILOM lists all known faults, for example:

```
SP/faultmgmt
Targets:
0 (/SYS/MB/HBA)
Properties:
Commands:
cd
show
```

- c. To clear the internal PCIe card fault, use the set command. For example:

```
-> set /SYS/MB/HBA clear_fault_action=true
Are you sure you want to clear /SYS/MB/HBA (y/n)? y
Set 'clear_fault_action' to 'true'
```

Servicing the Server Node Battery (CRU)

The Oracle Database Appliance (original version) battery maintains the date and time for the Oracle ILOM service processor when the server node is removed from the system and, therefore, is powered off. If the server node fails to maintain the proper time when powered off, replace the battery.



Caution - These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

▼ Remove Battery

1. **Prepare the server node for service.**
 - a. **Attach an antistatic wrist strap.**

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.
 - b. **Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.
 - c. **Remove the server node top cover.**

See [“Removing the Server Node Top Cover”](#) on page 36.
2. **Remove the battery.**
 - a. **Place you finger between the battery and the server node side wall and push the battery away from the side wall.**

See [“Install Server Node Top Cover”](#) on page 146.

b. Install the server node into the system.

See [“Install Server Node Into System Chassis”](#) on page 147.

c. Power on the server node.

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing FRUs

The following topics describe how to service field-replaceable units (FRUs) for the Oracle Database Appliance. You must power down the system and disconnect the AC power cords from the server before servicing any of these components.

Only Oracle authorized service personnel should service FRU components.

- [“Servicing Oracle Database Appliance X6-2 Series FRUs” on page 91](#)
- [“Servicing Oracle Database Appliance X3-2/X4-2/X5-2 FRUs” on page 92](#)
- [“Managing System Faults and FRU ID Information on Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 Series” on page 93](#)
- [“Servicing Oracle Database Appliance \(Original Version\) FRUs” on page 99](#)

Servicing Oracle Database Appliance X6-2 Series FRUs

This section describes how to service server node FRUs for Oracle Database Appliance X6-2 series. If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Preparing Oracle Database Appliance X3-2/X4-2/X5-2 for Service” on page 28](#). If you have Oracle Database Appliance (original version), go to [“Servicing Oracle Database Appliance \(Original Version\) FRUs” on page 99](#).

Only Oracle authorized service personnel should service FRU components.

Note - Most of the links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
FRU List	FRU List
Servicing Processors (FRU)	Servicing Processors (FRU)
Servicing the Oracle PCIe NVMe Switch Card (FRU)	Servicing the Oracle PCIe NVMe Switch Card (FRU)

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Note - The NVMe Switch Card is located in Slot 2 for the Oracle Database Appliance X6-2S/X6-2M.	Note - The NVMe Switch Card is located in Slot 2 for the Oracle Database Appliance X6-2S/X6-2M.
Servicing the internal host bus adapter (HBA) (FRU)	Servicing the internal host bus adapter (HBA) (FRU)
Servicing the Disk Backplane (FRU)	Servicing the Disk Backplane (FRU)
Servicing the DVD Drive (FRU)	Servicing the DVD Drive (FRU)
Servicing the Front Indicator Module (FRU)	Servicing the Front Indicator Module (FRU)
Servicing the Motherboard (FRU)	Servicing the Motherboard (FRU)
Servicing the SAS Cables (FRU)	Servicing the SAS Cables (FRU)
Servicing the NVMe Cables (FRU)	Servicing the NVMe Cables (FRU)
Note - The NVMe Switch Card is located in Slot 2 for the Oracle Database Appliance X6-2S/X6-2M.	Note - The NVMe Switch Card is located in Slot 2 for the Oracle Database Appliance X6-2S/X6-2M.
Servicing the Power, FIM, Disk Backplane Data, and DVD Cables (FRU)	Servicing the Power, FIM, Disk Backplane Data, and DVD Cables (FRU)
“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane” on page 94	“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane” on page 94
“Component Fault Management” on page 93	“Component Fault Management” on page 93

Servicing Oracle Database Appliance X3-2/X4-2/X5-2 FRUs

This section describes how to service server node FRUs for Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2. If you have Oracle Database Appliance X6-2 series, go to [“Servicing Oracle Database Appliance X6-2 Series FRUs” on page 91](#). If you have Oracle Database Appliance (original version), go to [“Servicing Oracle Database Appliance \(Original Version\) FRUs” on page 99](#).

Only Oracle authorized service personnel should service FRU components.

Note - Most of the links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2, and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
FRU Locations	FRU Locations	FRU List
Servicing Processors (FRU)	Servicing Processors (FRU)	Servicing Processors (FRU)
Servicing the Disk Backplane (FRU)	Servicing the Disk Backplane (FRU)	Servicing the Disk Backplane (FRU)
An optional DVD drive for this system is considered a CRU. See “Servicing Oracle Database	An optional DVD drive for this system is considered a CRU. See “Servicing Oracle Database	Servicing a DVD Drive (FRU)

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
Appliance X3-2/X4-2/X5-2 CRUs” on page 66.	Appliance X3-2/X4-2/X5-2 CRUs” on page 66.	
Servicing the Front Indicator Module (FRU)	Servicing the Front Indicator Module (FRU)	Servicing the Front Indicator Module (FRU)
Servicing the Motherboard (FRU)	Servicing the Motherboard (FRU)	Servicing the Motherboard (FRU)
Servicing the SAS Cables (FRU)	Servicing the SAS Cables (FRU)	Servicing the SAS Cables (FRU)
“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane” on page 94	“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane” on page 94	“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane” on page 94
“Component Fault Management” on page 93	“Component Fault Management” on page 93	“Component Fault Management” on page 93

Managing System Faults and FRU ID Information on Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 Series

This section describes how to manage system faults and system FRU ID information when servicing Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, Oracle Database Appliance X5-2 or Oracle Database Appliance X6-2 series. If you have Oracle Database Appliance (original version), go to [“Servicing Oracle Database Appliance \(Original Version\) FRUs” on page 99.](#)

- [“Component Fault Management” on page 93](#)
- [“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane” on page 94](#)

Component Fault Management

Typically, when a faulty component is replaced and the server is returned to service, the fault state of the component in Oracle ILOM is automatically cleared and the component Service Required indicator will turn off. This is the default behavior for all components that have an embedded FRU serial number in the component firmware.

For replaced components that do not have an embedded FRU serial number, or do not automatically clear their fault state after the component has been repaired and the server is returned to service, you can use Oracle ILOM command line interface to manually clear the fault state. Use the following syntax:

```
set /path_to_target clear_fault_action=true
```

Where *path_to_target* is the path to the component (such as a DIMM) that had the fault.

In addition, the Fault Management shell can also be used. Use of the Fault Management shell is reserved for Oracle Service. For more information on component fault management:

- For systems with Oracle ILOM 3.1, see [Using fmadm to Administer Active Hardware Faults](http://docs.oracle.com/cd/E24707_01/html/E24528/z400390c1426287.html#scrolltoc) (http://docs.oracle.com/cd/E24707_01/html/E24528/z400390c1426287.html#scrolltoc) in the Oracle Integrated Lights Out Manager Documentation Library.
- For systems with Oracle ILOM 3.2, see [Using fmadm to Administer Active Hardware Faults](http://docs.oracle.com/cd/E37444_01/html/E37447/z400390c1426287.html#scrolltoc) (http://docs.oracle.com/cd/E37444_01/html/E37447/z400390c1426287.html#scrolltoc) in the Oracle Integrated Lights Out Manager Documentation Library.

Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane

This section is for Oracle field service personnel who replace FRU components, such as the motherboard and disk backplane, that contain special FRU ID information. This FRU ID information includes the System_Identifier and Top Level Identifier (TLI). Maintaining the correct System_Identifier and TLI information in the system is important for the correct operation of the Oracle Database Appliance software and for warranty service.

System_Identifier:

This is an Oracle ILOM setting maintained in the service processor. By logging in to the Oracle ILOM CLI as root, you can reset this value after replacing a server node's motherboard.

FRU ID information:

There are two levels of FRU ID information in Oracle Database Appliance:

- Oracle Database Appliance TLI product and serial number
- The component server node product number and serial number

The FRU ID information is maintained in the motherboard (MB), disk backplane (DBP0) and power supply (PS0).

An Oracle Database Appliance assembled at the factory has the same appliance TLI product and TLI serial number for each bundled component (server nodes, storage shelves). Components added later, such as the optional storage expansion shelf, might have a different TLI.

Additionally, each server node has its own component-level product number and serial number maintained in the FRU ID.

The appliance TLI and server component numbers can be found on labels attached to the top of each appliance server node near the front and look similar to the following illustration:



Callout	Description
1	Server serial label
2	Oracle Database Appliance TLI label

If the appliance is in a rack where you cannot see the labels, slide a server node partway out on its rails, just far enough to see the information. Refer to [Chapter 2, “Preparing Oracle Database Appliance for Service”](#).

Note - You only need to extend the server node a couple of inches on its slide rails to see the TLI. You do not need to release any cables, or slide it to the extended maintenance position.

Choose a task to perform:

- [“Update System_Identifier Information” on page 95](#)
- [“Update Disk Backplane or System FRU TLI Information” on page 97](#)

▼ Update System_Identifier Information

Perform the following steps to update the System_Identifier information after replacing a motherboard in an Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series.

1. **Log in as root to the service processor of the new motherboard using the Oracle ILOM command line interface.**
2. **Set the system_identifier. For example, if you have a Oracle Database Appliance X3-2, enter the following command:**

```
set /SP system_identifier="Oracle Database Appliance X3-2 TLI serial number"
```

Where *TLI serial number* is the Oracle Database Appliance TLI serial number. If you have a dual node appliance, this is the serial number used in common for both nodes of the appliance. Information stored in the `system_identifier` is used by the appliance software. For a dual node appliance, it is required to confirm the server nodes are a matched pair. You can find the TLI serial number on the top of the server (left front). See [“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane”](#) on page 94 for label location.

3. Confirm that the information has been successfully updated by viewing the `system_identifier` field. Enter the following command:

```
show /System
```

The system information is displayed. For example, for Oracle Database Appliance X3-2 you might see:

```
/System
```

```
Targets:
```

```
Open_Problems (0)
Processors
Memory
Power
Cooling
Storage
Networking
PCI_Devices
Firmware
BIOS
```

```
Properties:
```

```
health = OK
health_details = -
open_problems_count = 0
type = Rack Mount
model = Oracle Database Appliance X3-2
part_number = 12341003+2+1
serial_number = 5678FM0001
component_model = SUN FIRE X4170 M3
component_part_number = 7064195
component_serial_number = 1150FML00J
system_identifier = Oracle Database Appliance X3-2 5678FM0001
system_fw_version = 3.1.2.10.a
```

4. Confirm that the FRU TLI information is also correct for the system, as follows:

- `model`: should list the appliance model.
- `part_number`: should list the appliance TLI part number.

- serial_number: should list the appliance TLI serial number.
 - component_model: should list the server node model.
 - component_part_number: should list the server node part number.
 - component_serial_number: should list the server node serial number.
5. **If the information is correct, you are done and can log out. If the information is not correct, proceed to “[Update Disk Backplane or System FRU TLI Information](#)” on page 97.**

▼ Update Disk Backplane or System FRU TLI Information

Perform the following steps to confirm or update the Oracle Database Appliance TLI and server FRU ID information. This procedure must be performed when replacing the disk backplane board or when TLI or FRU ID information on the motherboard is not automatically updated after replacement.

1. **Log in using the sunservice account (enabled through Escalation mode) to the service processor using the Oracle ILOM command line interface.**

Upon successful log in, the Service Mode prompt is displayed:

```
#
```

2. **Check the Oracle Database Appliance TLI information, enter the following command:**

```
setsvcid
```

The setsvcid command obtains backup TLI information stored in the system and displays it for confirmation.

For example, for Oracle Database Appliance X3-2 you might see:

```
Reading fruId:///SYS/DBP0...
Top Level Product Name ['Oracle Database Appliance X3-2']:
Top Level PPN ['12341003+2+1']:
Top Level PSN ['5678FM0001']:

Top Level Product Name:    Oracle Database Appliance X3-2
Top Level PPN:             12341003+2+1
Top Level PSN:             5678FM0001
Is the above correct? (y/n) [n]:
```

3. **If the information displayed is correct, type `y` and press Enter. If the information is not correct, type `n` and enter the correct information found on the Oracle Database Appliance TLI label on the top left of the server (see “[Updating System Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane](#)” on page 94).**

The following message is displayed:

```
Writing fruId:///SYS/DBP0... You will need to reboot the SP for these changes to take full effect.
```

4. Check the component server FRU information, enter the following command:

```
setpsnc
```

The setpsnc command obtains backup component server FRU information stored in the system and displays it for confirmation.

For example, for Oracle Database Appliance X3-2 that contains two Sun Server X3-2 (formerly known as Sun Fire X4170 M3) nodes you might see:

```
Reading fruId:///SYS/DBP0...
PPN ['7064195']:
PSN ['1150FML00J']:
Product Name ['SUN FIRE X4170 M3']:
```

```
PPN:          7064195
PSN:          1150FML00J
Product Name: SUN FIRE X4170 M3
Is the above correct? (y|n) [n]:
```

5. If the information displayed is correct, type `y` and press Enter. If the information is not correct, type `n` and enter the correct information found on the server serial label on the top left of the server (see [“Updating System_Identifier and/or FRU ID Information for a Replacement Motherboard or Disk Backplane”](#) on page 94).

The following message is displayed:

```
Writing fruId:///SYS/DBP0... You will need to reboot the SP for these changes to take full effect.
```

6. Reboot the SP using the following command:

```
reboot
```

Rebooting the SP will automatically log you off.

7. After the service processor reboots, log back in to sunservice account using the command line interface.

Upon successful log in, the Service Mode prompt is displayed:

```
#
```

8. Confirm that the Oracle Database Appliance TLI information is correct. Enter the following command:

```
showsvcid
```

The system information is displayed.

For example, for Oracle Database Appliance X3-2 you might see:

Top Level Product Manufacturer: Oracle Corporation

Top Level Product Name: Oracle Database Appliance X3-2

Top Level PPN: 12341003+2+1

Top Level PSN: 5678FM0001

9. **Confirm that the component server FRU information is correct. Enter the following command:**

showpsnc

The system information is displayed. For example, for Oracle Database Appliance X3-2:

Primary: fruid:///SYS/DBP0

Backup 1: fruid:///SYS/MB

Backup 2: fruid:///SYS/PS0

Element	Primary	Backup1	Backup2
PPN	7064195	7064195	7064195
PSN	1150FML00J	1150FML00J	1150FML00J
Product Name	SUN FIRE X4170 M3	SUN FIRE X4170 M3	SUN FIRE X4170 M3

10. **If the information is correct, log out. If the information is not correct (does not match the information on the Oracle Database Appliance TLI or server serial labels), repeat the process for information that is missing or incorrect.**

Servicing Oracle Database Appliance (Original Version) FRUs

This section describes how to service server node FRUs for Oracle Database Appliance (original version). If you have Oracle Database Appliance X6-2 series, go to [“Servicing Oracle Database Appliance X6-2 Series FRUs” on page 91](#). If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Servicing Oracle Database Appliance X3-2/X4-2/X5-2 FRUs” on page 92](#).

Note - Only Oracle authorized service personnel should service FRU components.

- [“Removing and Installing the Air Duct \(FRU\)” on page 100](#)
- [“Servicing Processors \(CPUs\) \(FRU\)” on page 102](#)
- [“Servicing the Boot Disk Backplane \(FRU\)” on page 109](#)
- [“Servicing the Power Distribution Board \(FRU\)” on page 111](#)
- [“Servicing the Disk Midplane Module \(FRU\)” on page 115](#)

- [“Servicing the Disk Midplane Module HDD Cable \(FRU\)” on page 121](#)
- [“Servicing the Front Indicator Panels \(FRU\)” on page 123](#)
- [“Servicing Server Node Cables” on page 128](#)
- [“Servicing the Motherboard Assembly \(FRU\)” on page 138](#)

Removing and Installing the Air Duct (FRU)

The air duct for the Oracle Database Appliance (original version) must be removed to service the CPUs.

The air duct is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment overheating. Ensure that the air duct is installed correctly before powering on the server.

This section includes the following topics:

- [“Remove Air Duct” on page 100](#)
- [“Install Air Duct” on page 101](#)

▼ Remove Air Duct

1. Prepare the server node for service.

a. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#).

b. Remove the server node from the system.

See [“Removing Server Nodes From the System Chassis” on page 35](#).

Power is removed from the server node when you remove it from the system.

c. Remove the server node top cover.


See [“Removing the Server Node Top Cover” on page 36](#).

2. Remove the air duct.

a. From the rear of the server node, grasp the middle/rear of the air duct with your right hand and lift it up to a 45 degree angle [1].

The air duct swings up and away from the rear of the system.

- b. Grasp the left end of the plastic air duct with your left hand to hold it at a 45 degree angle, and with your right hand press gently down on the middle of the air duct until it bends enough to disengage its left hinge from its socket [2].
- c. Remove the air duct's right hinge from its socket and set the air duct aside [2].



▼ Install Air Duct



Caution - Equipment overheating. Ensure that the air duct is installed correctly before powering on the server.

1. Install the air duct into the chassis.
 - a. From the rear of the server node, insert the air duct's right hinge into the right-side socket [2], and place the left hinge on top of the left-side socket.
 - b. Grasp the left end of the air duct with your left hand to hold it at a 45 degree angle, and, with your right hand, press gently down on the middle of the air duct until it bends enough to insert the left hinge into the left-side socket [2].
 - c. Carefully lower the air duct to its closed position, with particular attention given to the SAS cables [1].

Ensure that the openings on each side of the air duct fit around the cables and not on top of them.



Caution - Equipment overheating. Verify that the air duct is fully closed.

2. Return the server node to operation.

a. Install the server node top cover.

See [“Installing the Server Node Top Cover”](#) on page 146.

b. Install the server node into the system.

See [“Installing a Server Node Into the System Chassis”](#) on page 147.

c. Power on the server node.

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing Processors (CPUs) (FRU)

This section includes information on servicing CPUs in Oracle Database Appliance (original version).

The CPU is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

This section includes the following topics:

- [“Remove Processor \(CPU\)”](#) on page 102
- [“Install Processor \(CPU\)”](#) on page 106

▼ Remove Processor (CPU)

1. Prepare the server node for service.

a. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

b. Remove the server node from the system.

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.

c. Remove the server node top cover.

See [“Removing the Server Node Top Cover”](#) on page 36.

d. Remove the air duct.

See [“Remove Air Duct”](#) on page 100.

2. Remove the CPU.


a. Identify which CPU to remove.

b. To identify the location of the faulty CPU, press the Fault Remind button on the motherboard.

Note - When the Fault Remind button is pressed, the Fault Remind Power Good indicator (LED) lights green to indicate that there is sufficient voltage present in the fault remind circuit to light the fault indicators. If this indicator fails to light when you press the Fault Remind button, the capacitor powering the fault remind circuit has lost its charge. This can happen if the Fault Remind button is pressed for a long time with fault indicators lit or if the server node has been out of the chassis for more than 15 minutes.

c. The fault LED for the faulty CPU lights.

The fault LED is located next to the CPU.



- If CPU fault LED is off: CPU is operating properly.
- If CPU fault LED is on (amber): CPU is faulty and should be replaced.

Viewing the server node from the front, CPU0 (P0) is on the right side of the server node.

- d. Using a Phillips screwdriver, turn one captive screw on the heatsink counterclockwise two full turns, then turn the other screw two full turns, and keep alternating between the two screws until they are removed [2].
- e. Twist the heatsink slightly to break the grease seal, then lift it off and place it upside down on a flat surface to prevent the thermal grease from contaminating other components.
- f. Using the wipes supplied with the replacement CPU, carefully clean the thermal grease from both the bottom of the heatsink and the top of the CPU.



Caution - Equipment damage. When cleaning the top of the CPU, be careful not to get the thermal grease on the CPU socket and associated components.




Caution - Equipment damage. Failure to clean the heatsink and CPU prior to removing the CPU could result in the accidental contamination of the CPU socket or other components. Also, be careful not to get the grease on your fingers as this could result in contamination of components.

- g. Disengage the CPU release lever by pushing down and moving it to the side away from the CPU, and then rotating the lever upward [3].**
- h. Raise the pressure frame on the CPU to the open position [3].**
- i. Use your index finger to carefully lift up the edge of the CPU or protective cap that is farthest from the socket alignment slots [4], then firmly grasp both sides of the CPU or protective cap with your thumb and index finger on your other hand [4], and carefully lift the CPU or protective cap up and out of the socket [5].**




Caution - Equipment overheating. Whenever you remove a heatsink, you should replace it or install a CPU filler before you return the server to operation; otherwise, the system might overheat due to improper airflow.



▼ Install Processor (CPU)

1. **Attach an antistatic wrist strap.**
See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.
2. **Unpack the replacement CPU.**
The CPU replacement kit includes a new CPU, wipes, and a tube of thermal grease.
3. **Install the CPU.**
 - a. **Grasp the sides of the CPU firmly with your thumb and index finger, tilt it at a 45 degree angle, orient it with the socket alignment tabs [2], carefully lower the end of the CPU with the alignment tabs into the socket [3], support the**

raised end of the CPU with the index finger on your other hand, and lower the CPU into the socket [3].



- b. **Lower the pressure frame to the closed position [4].**
Ensure that the pressure frame sits flat around the periphery of the CPU.
- c. **Engage the release lever by rotating it downward and slipping it under the catch [4].**
- d. **Ensure that there is no debris on the top of the CPU die.**
- e. **Use the syringe (supplied with the new or replacement CPU) to apply approximately 0.1 ml of thermal grease to the center of the top of the CPU. Do not distribute the grease.**
- f. **Orient the heatsink so that the DIMM SIDE label on the top of the heatsink is facing the memory modules (DIMMs) and the two captive Phillips screws align with the mounting studs.**

Set 'clear_fault_action' to 'true'

Servicing the Boot Disk Backplane (FRU)

The Oracle Database Appliance (original version) boot disk backplane (BDB) serves as an interface between the motherboard and the rear-mounted disk drives.

The boot disk backplane is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

This section includes:

- [“Remove Boot Disk Backplane”](#) on page 109
- [“Install Boot Disk Backplane”](#) on page 110

▼ Remove Boot Disk Backplane

1. **Prepare the server node for service.**
 - a. **Attach an antistatic wrist strap.**


See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.
 - b. **Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.
 - c. **Remove the server node top cover.**

See [“Removing the Server Node Top Cover”](#) on page 36.
2. **Unseat the boot disk drives.**

See [“Remove a Boot Drive”](#) on page 56.
3. **Remove the boot disk backplane.**

- a. **Disconnect the power and data cables [1].**



- b. **Remove the four Phillips screws that secure the boot disk backplane to the rear-mounted disk drives assembly and remove the backplane [2].**

4. **Place the boot disk backplane on an antistatic mat.**

▼ Install Boot Disk Backplane

1. **Install the boot disk backplane.**
 - a. **Position the boot disk backplane on the rear-mounted disk drives assembly and install and tighten the four Phillips screws to secure the backplane [2].**
 - b. **Reconnect the power cable and the data cables [1].**
2. **Return the server node to operation.**
 - a. **Re-seat the boot disk drives.**
See [“Install a Boot Drive” on page 57](#).
 - b. **Install the server node top cover.**
See [“Install Server Node Top Cover” on page 146](#).

c. **Install the server node into the system.**

See [“Install Server Node Into System Chassis”](#) on page 147.

d. **Power on the server node.**

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing the Power Distribution Board (FRU)

The Oracle Database Appliance (original version) power distribution board (PDB) distributes power from the power supplies to all system components.

The power distribution board is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. Follow antistatic precautions as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35. Do not touch the components along their connector edges.



Caution - Equipment damage. Remove all power from the system before removing or installing the power distribution board. Power down both server nodes (also called system controllers) and disconnect the power cords from the system before performing these procedures. For instructions, see [“Shutting Down a Server Node and Powering Off the System”](#) on page 32.

This section includes:

- [“Remove Power Distribution Board”](#) on page 111
- [“Install Power Distribution Board”](#) on page 113

▼ Remove Power Distribution Board


1. **Prepare the system for service.**

a. **Power off the system.**

See [“Shutting Down a Server Node and Powering Off the System”](#) on page 32.

b. **Disconnect the power cords from the system.**


- d. Lift the power distribution board out of the system chassis [4] and place it on the antistatic mat.



▼ Install Power Distribution Board

1. Install the power distribution board into the system chassis.
 - a. Lower the power distribution board partially into the system [1].

- b. Reconnect the chassis interlock switch cable [2].



- c. Align the power distribution board with the two power connectors on the disk midplane module and slide the power distribution board forward until the connectors seat.
 - d. To secure the power distribution board to the system, use the holes in the system side wall to access and tighten the two Phillips screws [3].
 - e. Reconnect the power distribution board ribbon cable [4].
2. Return the system to operation.
- a. Install both server nodes into the system.

See [“Installing a Server Node Into the System Chassis”](#) on page 147.

- b. Install the middle section of the top cover.**
Install and tighten the Phillips screws that secure the middle section of the top cover to the system chassis.
- c. Install both power supplies into the system.**
See [“Install a Power Supply”](#) on page 63.
- d. If the system was installed in a rack, reinstall it into the rack.**
See the *Oracle Database Appliance Owner's Guide* for instructions.
- e. Reconnect the power cords to the system and power on the system.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing the Disk Midplane Module (FRU)

The Oracle Database Appliance (original version) disk midplane interconnects the front disk drives to the server nodes, the front indicator modules, and the power distribution board (PDB).

The disk midplane board is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. Follow antistatic precautions as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35. Do not touch the components along their connector edges.



Caution - Equipment damage. Remove all power from the system before removing or installing the disk midplane board. Power down both server nodes (also called system controllers) and disconnect the power cords from the system before performing these procedures. For instructions, see [“Shutting Down a Server Node and Powering Off the System”](#) on page 32.

This section includes:


- [“Remove Disk Midplane Module”](#) on page 115
- [“Install Disk Midplane Module”](#) on page 119

▼ Remove Disk Midplane Module

1. **Prepare the system for service.**

- a. **Power off the system.**
See [“Shutting Down a Server Node and Powering Off the System”](#) on page 32.
 - b. **Disconnect the power cords from the system.**
 - c. **If the system is installed in a rack, remove it.**
See the *Oracle Database Appliance Owner's Guide* for information on racking the system chassis.
 - d. **Remove both power supplies from the system.**
See [“Remove a Power Supply”](#) on page 62.
 - e. **Attach an antistatic wrist strap.**
See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.
2. **Remove all of the front storage drives.**
See [“Remove a Storage Drive”](#) on page 54.
 3. **Remove both server nodes from the system.**
See [“Removing Server Nodes From the System Chassis”](#) on page 35.
 4. **Remove the middle section of the system top cover.**
See [“Removing the Middle Section of the System Top Cover”](#) on page 37.
 5. **Loosen the two captive Phillips screws that secure the side-wall cover to the chassis and remove the cover.**


The side-wall cover is positioned under the middle section of the system top cover. Before you can remove the side-wall cover, you must remove the middle section of the system top cover.



6. **Remove the power distribution board.**
See [“Remove Power Distribution Board”](#) on page 111.
7. **Remove the disk midplane module.**
 - a. **Before disconnecting the two front indicator module (FIM) cable connectors from the disk midplane module, label them [1].**

The lower connector on the disk midplane is for SN0 and the upper connector is for SN1.

- b. **Disconnect the two FIM cable connectors from the disk midplane module [1].**



- c. **Remove the Phillips screw that secures the disk midplane module to the disk drive cage [2].**
- d. **To remove the disk midplane module from the system chassis, lift the board up about 0.25 inches (6.35 mm) to clear the standoffs that hold it in place [3].**

To remove the board, you might need to move the bottom of the board away from the disk drive cage to disengage the standoff located at the top left corner of the board. Then, you should be able to lift the board up and out of the system.


There are four columns of standoffs, four in the left-most column and three in each of the remaining columns.

- e. Lift the disk midplane module up and out of the system [4].
- f. Place the board on an antistatic mat.

▼ Install Disk Midplane Module

1. Install the disk midplane module.
 - a. Move the front indicator module (FIM) cable connectors toward the rear of the system so that the disk midplane module is not installed over them.
 - b. Lower the disk midplane module in the system chassis [1].
 - c. Position the disk midplane module against the disk drive cage, tilting the top slightly forward so that it fits over the top-most standoff on the left side and then position board so that it fits over the remaining 12 standoffs, then push downward on the board to engage the standoffs [2].
 - d. To secure the disk midplane module to the disk drive cage, install the Phillips screw [3].
 - e. Reconnect the two FIM cable connectors to the receptacles on the disk midplane module [4].

Ensure that the FIM connectors are properly connected. The lower connector on the disk midplane is for SN0 and the upper connector is for SN1.



- 2. Install the power distribution board into the system.**
See [“Install Power Distribution Board” on page 113.](#)
- 3. Position the side-wall cover into the chassis and tighten the two captive Phillips screws to secure the side-wall cover to the chassis.**
- 4. Install the middle section of the system's top cover.**
Install and tighten the Phillips screws that secure the middle section of the top cover to the system chassis.
- 5. Reinstall all of the front storage drives.**
See [“Install Storage Drive” on page 55.](#)

6. **Reinstall both server nodes into the system.**
See [“Installing a Server Node Into the System Chassis”](#) on page 147.
7. **Return the system to operation.**
 - a. **Install both power supplies into the system.**
See [“Install a Power Supply”](#) on page 63.
 - b. **If the system was installed in a rack, reinstall it into the rack.**
See the *Oracle Database Appliance Owner's Guide* for instructions.
 - c. **Reconnect the power cords to the system and power on the system.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing the Disk Midplane Module HDD Cable (FRU)

The Oracle Database Appliance (original version) HDD cable connects the power distribution board to the disk midplane module.

The disk midplane module HDD cable is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. Remove all power from the system before removing or installing the disk midplane module HDD cable. Power down both server nodes (also called system controllers) and disconnect the power cords from the system before performing these procedures. For instructions, see [“Shutting Down a Server Node and Powering Off the System”](#) on page 32.

The following topics are covered in this section:

- [“Remove Disk Midplane Module HDD Cable”](#) on page 121
- [“Install Disk Midplane Module HDD Cable”](#) on page 122

▼ Remove Disk Midplane Module HDD Cable

1. **Prepare the system for service.**
 - a. **Power off the system.**

See “[Shutting Down a Server Node and Powering Off the System](#)” on page 32.

b. Disconnect the power cords from the system.

c. If the system is installed in a rack, remove it.

See the *Oracle Database Appliance Owner's Guide* for instructions.

d. Attach an antistatic wrist strap.


See “[Performing Electrostatic Discharge and Antistatic Prevention Measures](#)” on page 35.

2. Remove the middle section of the system top cover.

See “[Removing the Middle Section of the System Top Cover](#)” on page 37.

3. Disconnect the HDD ribbon cable connector located on the power distribution board [1]).

4. Disconnect the HDD ribbon cable connector located on the disk midplane module [2].



▼ Install Disk Midplane Module HDD Cable

1. Reconnect the HDD ribbon cable connector located on the disk midplane module [2]).

2. **Reconnect the HDD ribbon cable connector located on the power distribution board [1].**
3. **Return the system to operation.**
 - a. **Install the middle section of the system top cover.**

Install and tighten the Phillips screws that secure the middle section of the top cover to the system chassis.
 - b. **If the system was installed in a rack, reinstall it into the rack.**

See the *Oracle Database Appliance Owner's Guide* for instructions.
 - c. **Reconnect the power cords to the system and power on the system.**

See [“Powering On Oracle Database Appliance \(Original Version\)” on page 149](#).

Servicing the Front Indicator Panels (FRU)

The Oracle Database Appliance (original version) front indicator panels contain the LEDs and indicators on the front of the system. Each server node has its own front indicator panel, which sits behind the ears on the system chassis.

The front indicator panels are FRUs and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. Remove all power from the system before removing or installing the front indicator panels. Power down both server nodes (also called system controllers) and disconnect the power cords from the system before performing these procedures. For instructions, see [“Shutting Down a Server Node and Powering Off the System” on page 32](#).

The following topics are covered in this section:

- [“Remove Front Indicator Panel” on page 123](#)
- [“Install Front Indicator Panel” on page 126](#)

▼ Remove Front Indicator Panel

1. **Prepare the system for service.**
 - a. **Power off the system (both server nodes).**

See [“Shutting Down a Server Node and Powering Off the System”](#) on page 32.

b. Disconnect the power cords from the system.

c. If the system is installed in a rack, remove it.

See the *Oracle Database Appliance Owner's Guide* for information on racking the system chassis.

d. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

2. Remove the adjacent disk drives [1].

Be sure to mark them so that you can return them to the correct drive bays later.


3. Unscrew the three Phillips screws from the back of the ear bezel [2].

4. Remove four more Phillips screws from the inside of the drive bays [3].

5. Remove the ear bezel [4].

The ear bezel and indicator panels remain connected to the ribbon cables.

6. Disconnect the ribbon cables from the indicator panel you wish to change [5].




7. Remove the screw that holds the indicator panel to the ear bezel [6].

Make sure you remove the correct indicator panel. There are two indicator panels on the ear bezel.

▼ Install Front Indicator Panel

1. Use the Phillips screw to attach the new indicator panel to the ear bezel [1].
2. Connect the ribbon cable to the indicator panel [2].
3. Place the ear bezel on the chassis [3].
4. Fasten the four Phillips screws inside the drive bays [4].
5. Fasten the three Phillips screws on the back of the ear bezel [5].
6. Replace the disk drives in the drive bays [6].

Use the marks to ensure that you return each drive to its original bay.



7. Return the system to operation.

a. Reinstall the system into the rack.

See the *Oracle Database Appliance Owner's Guide* for instructions.

- b. Reconnect the power cords to the system and power on the system.**

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing Server Node Cables

This section includes information on servicing cables in Oracle Database Appliance (original version).

The internal server node cables are FRUs and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

The following topics are covered in this section:

- [“Servicing the Fan Power Cables \(FRU\)”](#) on page 128
- [“Servicing the PCIe Card Cables \(FRU\)”](#) on page 130
- [“Servicing the SAS Expander Cable \(FRU\)”](#) on page 134
- [“Servicing the Boot Disk Backplane Cables \(FRU\)”](#) on page 136

Servicing the Fan Power Cables (FRU)

Each Oracle Database Appliance (original version) server node has two fans and each fan has a separate power cable.

▼ Remove Fan Power Cables

- 1. Prepare the server node for service.**
 - a. Attach an antistatic wrist strap.**


See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.
 - b. Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.

c. Remove the server node top cover.

See [“Removing the Server Node Top Cover”](#) on page 36.

2. Disconnect the fan power cables and remove them from the server node.



▼ **Install Fan Power Cables**

1. Reconnect the fan power cables.

2. Return the server node to operation.

a. Install the server node top cover.

See [“Installing the Server Node Top Cover”](#) on page 146.

b. Install the server node into the system.

See [“Installing a Server Node Into the System Chassis”](#) on page 147.

c. Power on the server node.

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing the PCIe Card Cables (FRU)

The Oracle Database Appliance (original version) PCIe card cables are used to connect the internal PCIe card, the primary HBA and a riser-mounted PCIe card, and the secondary HBA to the motherboard. See the following sections for instructions.

The PCIe card cables are FRUs and can only be replaced by an Oracle-qualified service technician.

- [“Remove PCIe Card Cables From Primary HBA PCIe Card” on page 130](#)
- [“Install PCIe Card Cables for Primary HBA PCIe Card” on page 131](#)
- [“Remove PCIe Card Cables From Secondary HBA PCIe Card” on page 132](#)
- [“Install PCIe Card Cables for Secondary HBA PCIe Card” on page 133](#)

▼ Remove PCIe Card Cables From Primary HBA PCIe Card


1. **Prepare the server node for service.**
 - a. **Attach an antistatic wrist strap.**

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#).
 - b. **Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis” on page 35](#).
 - c. **Remove the server node top cover.**

See [“Removing the Server Node Top Cover” on page 36](#).
2. **Disconnect the primary HBA PCIe card cables and remove them from the server node.**
 - a. **Loosen the three green, captive Phillips screws that secure the server node's front cover and remove the cover [1].**
 - b. **Disconnect the two cables from the primary HBA PCIe card and remove the cables [2].**

To remove each cable connector, push the connector inward, press down on the connector to release it, and pull the connector out.



▼ Install PCIe Card Cables for Primary HBA PCIe Card

1. **Reconnect the PCIe card cables.**
 - a. **Reconnect the two PCIe card cables to the primary HBA PCIe card and the connectors on the motherboard [2].**
Notice that there are two sets of connectors on the motherboard. Be sure to connect the cables to the connector on the right in each set (looking at the connectors from the rear of the server node).
 - b. **Position the server node's front cover onto the server node and tighten the three green, captive Phillips screws that secure the server node's front cover to the motherboard [1].**
2. **Return the server node to operation.**
 - a. **Install the server node top cover.**
See [“Installing the Server Node Top Cover”](#) on page 146.
 - b. **Install the server node into the system.**
See [“Installing a Server Node Into the System Chassis”](#) on page 147.

c. Power on the server node.

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

▼ **Remove PCIe Card Cables From Secondary HBA PCIe Card**

1. Prepare the server node for service.

a. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

b. Remove the server node from the system.

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.

c. Remove the server node top cover.

See [“Removing the Server Node Top Cover”](#) on page 36.


2. Disconnect the PCIe card cables and remove them from the server node.

The Secondary HBA PCIe Card sits in the top slot on the PCIe riser (PCIe slot 2)

a. Loosen the three green, captive Phillips screws that secure the server node's front cover and remove the cover [1].

b. Disconnect the two secondary HBA PCIe card cables and remove the cables [2].

To remove each cable connector, push the connector inward, press down on the connector to release it, and pull the connector out.



▼ Install PCIe Card Cables for Secondary HBA PCIe Card

1. **Reconnect the PCIe card cables.**
 - a. **Reconnect the two PCIe card cables between to the secondary PCIe card and the connectors on the motherboard [2].**
 The Secondary HBA PCIe Card sits in the top slot on the PCIe riser (PCIe slot 2)
 Notice that there are two sets of connectors on the motherboard. Be sure to connect the cables to connector on the left in each set (looking at the connectors from the rear of the server node).
 - b. **Position the server node's front cover onto the server node and tighten the three green, captive Phillips screws that secure the server node's front cover to the motherboard [1].**
2. **Return the server node to operation.**
 - a. **Install the server node top cover.**
 See [“Installing the Server Node Top Cover”](#) on page 146.

- b. Install the server node into the system.**
See [“Installing a Server Node Into the System Chassis”](#) on page 147.
- c. Power on the server node.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing the SAS Expander Cable (FRU)

The Oracle Database Appliance (original version) SAS expander cable runs from a connector on the front of the motherboard to a connector near the rear of the motherboard. See the following sections for instructions.

The SAS expander cable is a FRU and can only be replaced by an Oracle-qualified service technician.

The following topics are covered in this section:


- [“Remove SAS Expander Cable”](#) on page 134
- [“Install SAS Expander Cable”](#) on page 135

▼ Remove SAS Expander Cable

- 1. Prepare the server node for service.**
 - a. Attach an antistatic wrist strap.**
See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.
 - b. Remove the server node from the system.**
Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.
 - c. Remove the server node top cover.**
See [“Removing the Server Node Top Cover”](#) on page 36.
 - d. Remove the PCIe riser.**
See [“Remove PCIe Riser From Server Nodes”](#) on page 77.
- 2. Disconnect the SAS expander cable and remove it from the server node.**
 - a. Loosen the three green, captive Phillips screws that secure the server node's front cover and remove the cover [1].**

- b. **Disconnect both cable connectors from the motherboard and remove the cable [2].**

Push the connector inward, press down on the connector to release it, and pull the connector out.



▼ Install SAS Expander Cable

1. **Reconnect the SAS expander cable.**
 - a. **Reconnect the SAS expander cable connectors to the motherboard [2].**
 - b. **Position the server node's front cover onto the server node and tighten the three green, captive Phillips screws that secure the server node's front cover to the motherboard [1].**
2. **Return the server node to operation.**
 - a. **Install the PCIe riser.**
See [“Install PCIe Riser in Server Nodes”](#) on page 79.
 - b. **Install the server node top cover.**
See [“Installing the Server Node Top Cover”](#) on page 146.

c. Install the server node into the system.

See [“Installing a Server Node Into the System Chassis”](#) on page 147.

d. Power on the server node.

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Servicing the Boot Disk Backplane Cables (FRU)

The Oracle Database Appliance (original version) boot disk backplane cables connect the boot disk backplane to the motherboard.

The boot disk backplane cables are FRUs and can only be replaced by an Oracle-qualified service technician.

The following topics are covered in this section:

- [“Remove Boot Disk Backplane Cables”](#) on page 136
- [“Install Boot Disk Backplane Cables”](#) on page 137

▼ Remove Boot Disk Backplane Cables

1. Prepare the server node for service.

a. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

b. Remove the server node from the system.

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis”](#) on page 35.

c. Remove the server node top cover.

See [“Removing the Server Node Top Cover”](#) on page 36.

2. Disconnect the power cable and hard disk drive (HDD) cables and remove them from the server node.

a. Disconnect the power cable and HDD cables from the motherboard [1].

Servicing the Motherboard Assembly (FRU)


Each Oracle Database Appliance (original version) server node has a motherboard assembly. The service strategy for the motherboard is to remove the replaceable components from the server node and then return the server node with the motherboard in place to Oracle for repair or replacement.

The motherboard assembly is a FRU and can only be replaced by an Oracle-qualified service technician.



Caution - Equipment damage. These procedures require that you handle components that are sensitive to static discharge. This sensitivity can cause the component to fail. To avoid damage, ensure that you follow antistatic practices as described in [“Performing Electrostatic Discharge and Antistatic Prevention Measures”](#) on page 35.

The following figure shows the components that must be removed from the server node.



Callout	Description	Callout	Description
1	CPUs and Heatsinks	6	Internally Mounted PCIe Card
2	Memory modules (DIMMs)	7	Boot Disk Drives (2)
3	PCIe Cards mounted on the PCIe Riser	8	Boot Disk Drive Backplane
4	PCIe Riser	9	Battery
5	Fan Modules (2)		

The following topics are covered in this section:

- [“Remove Replaceable Components From Motherboard Assembly” on page 139](#)
- [“Install Replaceable Components in Motherboard Assembly” on page 140](#)

▼ Remove Replaceable Components From Motherboard Assembly

1. **Prepare the server node for service.**
 - a. **Attach an antistatic wrist strap.**
See [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#).
 - b. **Remove the server node from the system.**
Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis” on page 35](#).
 - c. **Remove the server node top cover.**
See [“Removing the Server Node Top Cover” on page 36](#).
2. **With the exception the SAS expander cable, disconnect and remove all internal cables from the server node.**

Note - To identify the SAS expander cable, see [“Install SAS Expander Cable” on page 135](#).

The cables for the fans, the primary and secondary HBA PCIe cards, and the boot disk backplane must be removed.

- Fan power cables
See Remove [“Remove Fan Power Cables” on page 128](#).
- Primary HBA PCIe card data cables
See [“Remove PCIe Card Cables From Primary HBA PCIe Card” on page 130](#).
- Secondary HBA PCIe card data cables
See [“Remove PCIe Card Cables From Secondary HBA PCIe Card” on page 132](#).



Caution - Equipment damage. The HBA data cables are delicate. Ensure that they are removed and safely out of the way when servicing the motherboard.

- Boot disk board cables.
See [“Remove Boot Disk Backplane Cables” on page 136.](#)

3. Remove the following components from the server node.

- Fan modules
[“Remove a Fan Module” on page 59.](#)
- Boot disk drives
[“Remove a Boot Drive” on page 56.](#)
- Boot disk drive backplane
[“Remove Boot Disk Backplane” on page 109.](#)
- Memory modules (DIMMS)
[“Remove Faulty DIMMs” on page 70.](#)
- PCIe riser and attached PCIe cards
[“Remove PCIe Riser From Server Nodes” on page 77.](#)
- CPUs
[“Remove Processor \(CPU\)” on page 102.](#)
- Internal primary HBA PCIe card
[“Remove Primary HBA PCIe Card From Motherboard” on page 85.](#)
- Battery
[“Remove Battery” on page 88.](#)

▼ Install Replaceable Components in Motherboard Assembly

1. Attach an antistatic wrist strap.

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35.](#)

2. Install the following components into the server node.

- Fan modules
See [“Install a Fan Module” on page 60.](#)
- Boot disk drives
See [“Install a Boot Drive” on page 57.](#)
- Memory modules (DIMMS)
See [“Install DIMMs” on page 73.](#)

- PCIe riser and attached PCIe cards
See [“Install PCIe Riser in Server Nodes”](#) on page 79.
- CPUs
See [“Install Processor \(CPU\)”](#) on page 106.
- Internal primary HBA PCIe card
See [“Install Primary HBA PCIe Card in Motherboard”](#) on page 86.

3. Reconnect and install the following cables.

- Fan module power cables.
See [“Servicing the Fan Power Cables \(FRU\)”](#) on page 128.
- Internal PCIe card data cables.
See [“Servicing the PCIe Card Cables \(FRU\)”](#) on page 130.



Caution - Equipment damage. The disk drive data cables are delicate. Handle them carefully.

- Boot disk backplane cables.
See [“Servicing the Boot Disk Backplane Cables \(FRU\)”](#) on page 136.

4. Return the server node to operation.

- a. **Install the server node top cover.**
See [“Installing the Server Node Top Cover”](#) on page 146.
- b. **Install the server node into the system.**
See [“Installing a Server Node Into the System Chassis”](#) on page 147.
- c. **Reconnect all external data cables from the PCIe card(s) that are installed in the PCIe riser.**
- d. **Power on the server node.**
See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

Returning Oracle Database Appliance to Operation

This chapter describes how to return Oracle Database Appliance to operation after you have performed service procedures. It includes:

- [“Returning Oracle Database Appliance X6-2 Series to Operation” on page 143](#)
- [“Returning Oracle Database Appliance X3-2/X4-2/X5-2 to Operation” on page 144](#)
- [“Powering On an Oracle Database Appliance That Includes a Storage Shelf” on page 144](#)
- [“Returning Oracle Database Appliance \(Original Version\) to Operation” on page 146](#)

Returning Oracle Database Appliance X6-2 Series to Operation

This section describes returning Oracle Database Appliance X6-2S/X6-2M to operation after servicing. If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Returning Oracle Database Appliance X3-2/X4-2/X5-2 to Operation” on page 144](#). If you have Oracle Database Appliance (original version), go to [“Returning Oracle Database Appliance \(Original Version\) to Operation” on page 146](#).

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Install the Top Cover	Install the Top Cover
Remove Antistatic Measures	Remove Antistatic Measures
Reinstall the Server Chassis Into the Rack	Reinstall the Server Chassis Into the Rack
Return the Server to the Normal Rack Position	Return the Server to the Normal Rack Position

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Reconnect Data Cables and Power Cords	Reconnect Data Cables and Power Cords
Powering On Oracle Database Appliance X6-2S/X6-2M	Powering On Oracle Database Appliance X6-2S/X6-2M

Returning Oracle Database Appliance X3-2/X4-2/X5-2 to Operation

This section describes returning Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2 to operation after servicing. If you have Oracle Database Appliance X6-2 series, go to [“Returning Oracle Database Appliance X6-2 Series to Operation” on page 143](#). If you have Oracle Database Appliance (original version), go to [“Returning Oracle Database Appliance \(Original Version\) to Operation” on page 146](#).

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2 and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
Install the Top Cover	Install the Top Cover	Install the Top Cover
Remove Antistatic Measures	Remove Antistatic Measures	Remove Antistatic Measures
Reinstall the Server Chassis Into the Rack	Reinstall the Server Chassis Into the Rack	Reinstall the Server Chassis Into the Rack
Return the Server to the Normal Rack Position	Return the Server to the Normal Rack Position	Return the Server to the Normal Rack Position
Reconnect Data Cables and Power Cords	Reconnect Data Cables and Power Cords	Reconnect Data Cables and Power Cords
“Powering On an Oracle Database Appliance That Includes a Storage Shelf” on page 144	“Powering On an Oracle Database Appliance That Includes a Storage Shelf” on page 144	“Powering On an Oracle Database Appliance That Includes a Storage Shelf” on page 144

Powering On an Oracle Database Appliance That Includes a Storage Shelf

This section describes how to restore power after servicing an Oracle Database Appliance that includes at least one storage shelf (DE2-24P, DE2-24C). If you have an Oracle Database Appliance X6-2S/X6-2M or Oracle Database Appliance (original version), your system does not support a storage shelf and you should skip this section.

If you haven't already, return the Oracle Database Appliance to operational status. If you have Oracle Database X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Returning Oracle Database Appliance X3-2/X4-2/X5-2 to Operation” on page 144](#).

When powering on the system, each server node is powered on separately.

▼ Power On Procedure

Perform the following procedure to power on the Oracle Database Appliance.

1. **If you powered off and disconnected the power cords from a storage shelf (and storage expansion shelf if one is present), reconnect the power cords now.**
2. **Power on the storage shelf (and storage expansion shelf if one is present) by switching the power supply On/Off button on each power supply to the On position.**

The disks begin to initialize and the power supply LEDs light green. This can take several minutes.

Note - Do not power on the server nodes until the disks on the storage shelf and storage expansion shelf have initialized.

3. **If you powered off a server node, reconnect any unplugged power cords.**
4. **Power on a server node on using one of the following methods:**
 - Press the recessed Power button on the server node front panel.
 - Log in to the Oracle ILOM web interface, click Host Management > Power Control, and select **Power On** from the Select Action list box.
 - Log in to the Oracle ILOM command-line interface (CLI), and type the following command at the Oracle ILOM CLI prompt.

```
-> start /SYS
```

When the server is powered on and the power-on self-test (POST) code checkpoint tests have completed, the green Power/OK status indicator on the server node front panel lights and remains lit.

Note - If you powered off both server nodes prior to servicing, repeat steps 3 and 4 to power on the second server node.

5. **Refer to the *Getting Started Guide* and *Administration and Reference Guide* for any instructions or commands required to return the appliance to service.**

Returning Oracle Database Appliance (Original Version) to Operation

This section describes returning Oracle Database Appliance (original version) to operation after servicing. If you have Oracle Database Appliance X6-2 series, go to [“Returning Oracle Database Appliance X6-2 Series to Operation” on page 143](#). If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Returning Oracle Database Appliance X3-2/X4-2/X5-2 to Operation” on page 144](#).

- [“Installing the Server Node Top Cover” on page 146](#)
- [“Installing a Server Node Into the System Chassis” on page 147](#)
- [“Powering On Oracle Database Appliance \(Original Version\)” on page 149](#)

Installing the Server Node Top Cover

If you removed the top cover from an Oracle Database Appliance (original version) server node, perform the following procedure to replace it.



Caution - Hazardous voltage present. Do not run the system with the top cover removed.




Caution - Equipment damage. Install the top cover properly before starting the system.

▼ Install Server Node Top Cover

1. Place the top cover down on the server node so that it hangs over the front of the chassis by 0.5 inches (12.7 mm).
2. Ensure that all six of the standoffs on the underside of the cover (three on each side) fit into the slots on the top of the chassis side walls.

When the top cover is positioned (as described in previous step), the six standoffs on the underside of the cover fit into the slots in the top of the chassis sidewalls.



3. Slide the top cover toward the rear of the server node until it seats [2].


Installing a Server Node Into the System Chassis

If you removed a Oracle Database Appliance (original version) server node from the chassis, perform the following procedure to reinstall it.

▼ Install Server Node Into System Chassis

Note - Replacing a server node FRU with a new server node is a service activity that must be performed by an Oracle-qualified service technician. The customer may remove the server node to service other customer serviceable components in the server node.

1. **Before inserting the server node into the system chassis, ensure that both release latches on the rear of the server node are in the open position.**



2. **Slide the server node into the rear of the system chassis until the bottom lips of the release latches touch the chassis [2].**
3. **To re-seat the server node in the system chassis, grasp both release latches, one on each side of the server node, and push them upward simultaneously to the closed position [3].**



Caution - Equipment damage. Always use the release latches to re-seat the server node into the system chassis as described in this procedure. Failure to do so might damage the connectors on the front of the server node and/or the connectors on the disk midplane module.

4. **Reinstall the system chassis into the rack.**
Follow the instructions listed in the "Inserting Oracle Database Appliance (Original Version) Into a Rack" section in the *Oracle Database Appliance Owner's Guide*.

Powering On Oracle Database Appliance (Original Version)

To power on Oracle Database Appliance (original version), follow this procedure.

Each server node is powered on separately.

Note - To use Oracle ILOM to power on a server node, ensure that you have performed its initial configuration as described in "Connecting and Configuring Oracle ILOM" in the *Oracle Database Appliance Getting Started Guide*.

▼ Power On Oracle Database Appliance (Original Version)

1. **Ensure that the power cord (or cords) are connected to the power supplies on the rear of the server node that was serviced.**

Once plugged in, the server node goes into the standby power state. The SP status LED on the front panel of the server node lights green and goes from slow blink to steady on. The Power/OK LED on the front panel of the server node lights green and goes to standby blink. It might take about five minutes for the LED to reach standby blink after the power cord is inserted.


For the location of the SP status LED and Power/OK LED, see [“Server Node Status Indicators” on page 18](#).

Standby power state indicates that the server node's service processor is active, but the server node host is powered off.

2. **Power on a server node by performing *one of the following*:**

If you powered off a single server node without shutting down the appliance, perform this step only for that server node. If you shut down the appliance completely, then perform this step for both server nodes.

- **Using the server node's Power button: Momentarily press and release the recessed Power button on the front panel [1].**



On the server node, the green Power/OK LED [2] blinks while the server node is booting, and remains steady on when the server node is operational.

- **Using the Oracle ILOM web interface:**
 - Open a browser and enter the server node's service processor IP address in the browser's address field.**
 - At the log in page, type a user name (the account must have Reset and Host Control (r) privileges) and password, and click the Log In button.**
 - Go to Remote Power Control and select Power On from the Select Action list box and then click Save and OK.**

On the server node, the green Power/OK LED [2] blinks while the server node is booting, and remains steady on when the server node is operational.

- **Using the Oracle ILOM CLI:**
 - Log in to Oracle ILOM using an ssh client. Type:**

```
$ssh username@sp_ip_address
```

Where *username* is a user account name with Reset and Host Control (r) privileges and *sp_ip_address* is the IP address of the server node service processor.

b. When prompted, enter the user account password.

c. Enter the command to power on the server node:

```
-> start /SYS
```

On the server node, the green Power/OK LED [2] blinks while the server node is booting, and remains steady on when the server node is operational.

Server Node Diagnostic Tools and Resetting the Service Processor

This chapter introduces the diagnostic tools available to troubleshoot or monitor the performance of your server nodes (also called system controllers). It also includes instructions to reset the service processor (SP) in the event that it hangs or becomes inaccessible.

Note - Most of the tools and procedures described in this chapter are reserved and should not be run on the appliance unless directed to do so by Oracle Service personnel.

- [“Server Node Diagnostic Tools” on page 153](#)
- [“Resetting the Service Processor” on page 155](#)

Server Node Diagnostic Tools

Oracle provides a wide selection of diagnostic tools for use with your server node. These tools include lights out management of the system, service processor recovery, power-on self-test (POST), U-Boot tests, UEFI or Pc-Check diagnostics, as well as hardware LEDs that indicate the status of system components.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library. Use your browser's Back button to return to the Oracle Database Appliance library.

Diagnostic Tool	What It Does	Where to Find Information
Oracle Integrated Lights Out Manager (ILOM)	Monitors server status, environmental conditions, generates alerts (SNMP traps, IPMI PEs, remote syslog), performs fault isolation, provides remote console access. Note - All patching/updating of Oracle Database Appliance is done with the regular Oracle Database Appliance Patch Set Bundle. This includes BIOS and SP firmware. This ensures that all software and	Refer to the appropriate Oracle Integrated Lights Out Manager (ILOM) Documentation Library based on your appliance's supported version of Oracle ILOM. http://www.oracle.com/goto/ILOM/docs

Diagnostic Tool	What It Does	Where to Find Information
	firmware component versions are supported to work together. Patches are available through My Oracle Support.	
Oracle ILOM Preboot Menu	The Oracle ILOM preboot menu is a utility that can be used to fix problems with Oracle ILOM that cannot be fixed while it is running. It allows you to interrupt the Oracle ILOM boot process, configure settings, then continue booting Oracle ILOM. Among other things, it allows you to reset the Oracle ILOM root password to factory defaults, restore Oracle ILOM access to the serial port.	Refer to the appropriate <i>Oracle x86 Servers Diagnostics Guide</i> based on your appliance's supported version of Oracle ILOM. http://www.oracle.com/goto/x86AdminDiag/docs
System indicators and LEDs	Provides at-a-glance status of the system and its components.	<ul style="list-style-type: none"> ■ Chapter 1, “Overview of System Status Indicators and LEDs” ■ You can also use Oracle ILOM to check server node indicator status. Refer to the appropriate Oracle Integrated Lights Out Manager (ILOM) Documentation Library based on your appliance's supported version of Oracle ILOM. http://www.oracle.com/goto/ILOM/docs
Power-On Self-Test (POST)	Tests core components of system: CPUs, memory, and motherboard I/O bridge integrated circuits.	For Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, refer to the appropriate <i>Oracle x86 Servers Diagnostics Guide</i> based on your appliance's supported version of Oracle ILOM. http://www.oracle.com/goto/x86AdminDiag/docs For the Oracle Database Appliance original version, see: <ul style="list-style-type: none"> ■ “Default BIOS Power-On Self-Test (POST) Events” on page 161 ■ “BIOS POST F1 and F2 Errors” on page 162
U-Boot	Initializes and test aspects of the SP prior to booting Oracle ILOM. Tests SP memory, SP, network devices and I/O devices.	Refer to the appropriate <i>Oracle x86 Servers Diagnostics Guide</i> based on your appliance's supported version of Oracle ILOM. http://www.oracle.com/goto/x86AdminDiag/docs
UEFI Diagnostics (for Oracle Database Appliance X4-2/X5-2 and X6 series)	UEFI-based utility that tests and detect problems on all processor, memory, disk drives, and network ports. It is used on newer Oracle systems.	Refer to the appropriate <i>Oracle x86 Servers Diagnostics Guide</i> based on your appliance's supported version of Oracle ILOM. http://www.oracle.com/goto/x86AdminDiag/docs
Pc-Check (for Oracle Database Appliance X3-2 and Oracle	DOS-based utility that tests all motherboard components (CPU, memory, and I/O), ports, and slots.	Refer to the appropriate <i>Oracle x86 Servers Diagnostics Guide</i> based on your appliance's supported version of Oracle ILOM.

Diagnostic Tool	What It Does	Where to Find Information
Database Appliance (original version)		http://www.oracle.com/goto/x86AdminDiag/docs

Resetting the Service Processor

There are times when you might need to reset the service processor (such as after a firmware update). You can reset the server node SP using Oracle ILOM without affecting the host OS. However, this action disconnects your current Oracle ILOM session and will not allow any new sessions to be initiated until the reset has completed.

To reset the SP using the Oracle ILOM web interface or the CLI, see *Oracle Integrated Lights Out Manager (ILOM) Documentation Library*:

<http://www.oracle.com/goto/ILOM/docs>

Note - Be sure to refer to the documentation that applies to the version of Oracle ILOM supported with your appliance. See the "Supported Components and Capabilities" section in the *Oracle Database Appliance Owner's Guide*.

If you are unable to reset the SP using the Oracle ILOM web interface or the CLI (for example, if the SP hangs), then use the SP reset button as described in the following tables.

Note - The links in the following tables take you to instructions *outside* of the Oracle Database Appliance library. Use your browser's Back button to return to the Oracle Database Appliance library.

For Oracle Database Appliance X6-2 series:

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Reset the Service Processor From the Server Back Panel	Reset the Service Processor From the Server Back Panel

For Oracle Database Appliance X3-2X4-2/X5-2 and Oracle Database Appliance (original version):

Oracle Database Appliance (Original Version)	Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
1. Find the SP reset button on the rear of the system, next to the power supply and the Locate button/LED.	Reset the Service Processor From the Server Back Panel	Reset the Service Processor From the Server Back Panel	Reset the Service Processor From the Server Back Panel

Oracle Database Appliance (Original Version)	Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
<p>See the "Oracle Database Appliance (Original Version) Back Panel" section in the <i>Oracle Database Appliance Owner's Guide</i>.</p> <p>2. Insert a small stylus or non-conductive object into the opening and press the recessed push button switch.</p> <p>The SP resets.</p>			

Server Node Basic Input/Output System (BIOS)

The Basic Input/Output System (BIOS) has a Setup Utility stored in the BIOS flash memory. The Setup Utility reports system information and can be used to configure the BIOS settings. The configurable data is provided with context-sensitive help and is stored in the system's battery-backed CMOS RAM. If the configuration stored in the CMOS RAM is invalid, the BIOS settings return to their default optimal values.

Note - The BIOS menus shown in this chapter are examples. The BIOS version numbers, menu information, and menu selections are subject to change over the life of the product. You should not change the factory settings unless prompted to do so by Oracle Service personnel.

- [“Oracle Database Appliance X6-2 Series BIOS Utility” on page 157](#)
- [“Oracle Database Appliance X3-2/X4-2/X5-2 BIOS Utility” on page 158](#)
- [“Oracle Database Appliance \(Original Version\) BIOS Utility” on page 160](#)

Oracle Database Appliance X6-2 Series BIOS Utility

This section describes the Oracle Database Appliance X6-2 series BIOS utility. If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Oracle Database Appliance X3-2/X4-2/X5-2 BIOS Utility” on page 158](#). If you have Oracle Database Appliance (original version), go to [“Oracle Database Appliance \(Original Version\) BIOS Utility” on page 160](#).

All settings are set to the optimal defaults at startup.



Caution - You should not configure system BIOS settings. Oracle Database Appliance patch software will do this for you. The only time you might need to configure BIOS settings would be if requested to do so by Oracle Service.

The following topics are included:

- [“Setting Up BIOS Configuration Parameters” on page 158](#)
- [“BIOS Setup Utility Menu Options” on page 158](#)

Setting Up BIOS Configuration Parameters

This section describes the BIOS configuration parameters for Oracle Database Appliance X6-2 series.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
Managing the BIOS Configuration	Managing the BIOS Configuration
Accessing the BIOS Setup Utility	Accessing the BIOS Setup Utility
Using Legacy or UEFI BIOS	Using Legacy or UEFI BIOS
Using BIOS for Resource Allocation	Using BIOS for Resource Allocation
Common BIOS Setup Utility Tasks	Common BIOS Setup Utility Tasks

BIOS Setup Utility Menu Options

This section describes the BIOS utility menu options for Oracle Database Appliance X6-2 series.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Oracle Server X6-2 documentation library. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X6-2S	Oracle Database Appliance X6-2M
BIOS Main Menu Selections	BIOS Main Menu Selections
BIOS Advanced Menu Selections	BIOS Advanced Menu Selections
BIOS IO Menu Selections	BIOS IO Menu Selections
BIOS Boot Menu Selections	BIOS Boot Menu Selections
BIOS Save and Exit Menu Selections	BIOS Save and Exit Menu Selections

Oracle Database Appliance X3-2/X4-2/X5-2 BIOS Utility

This section describes the Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2 BIOS utility. If you have Oracle Database Appliance X6-2 series, go to [“Oracle Database Appliance X6-2 Series BIOS Utility” on page 157](#). If you

have Oracle Database Appliance (original version), go to [“Oracle Database Appliance \(Original Version\) BIOS Utility”](#) on page 160.

All settings are set to the optimal defaults at startup.



Caution - You should not configure system BIOS settings. Oracle Database Appliance patch software will do this for you. The only time you might need to configure BIOS settings would be if requested to do so by Oracle Service.

The following topics are included:

- [“Setting Up BIOS Configuration Parameters”](#) on page 159
- [“BIOS Setup Utility Menu Options”](#) on page 159

Setting Up BIOS Configuration Parameters

This section describes the BIOS configuration parameters for Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, and Oracle Database Appliance X5-2.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2, and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
Managing the BIOS Configuration	Managing the BIOS Configuration	Managing the BIOS Configuration
Accessing the BIOS Setup Utility	Accessing the BIOS Setup Utility	Accessing the BIOS Setup Utility
Using Legacy or UEFI BIOS	Using Legacy or UEFI BIOS	Using Legacy or UEFI BIOS
Using BIOS for Resource Allocation	Using BIOS for Resource Allocation	Using BIOS for Resource Allocation
Common BIOS Setup Utility Tasks	Common BIOS Setup Utility Tasks	Common BIOS Setup Utility Tasks

BIOS Setup Utility Menu Options

This section describes the BIOS utility menu options for Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, and Oracle Database Appliance X5-2.

Note - The links in the following table take you to instructions *outside* of the Oracle Database Appliance library to the Sun Server X3-2, Sun Server X4-2, and Oracle Server X5-2 documentation libraries. Use your browser's Back button to return to the Oracle Database Appliance library.

Oracle Database Appliance X3-2	Oracle Database Appliance X4-2	Oracle Database Appliance X5-2
BIOS Main Menu Selections	BIOS Main Menu Selections	BIOS Main Menu Selections
BIOS Advanced Menu Selections	BIOS Advanced Menu Selections	BIOS Advanced Menu Selections
BIOS IO Menu Selections	BIOS IO Menu Selections	BIOS IO Menu Selections
BIOS Boot Menu Selections	BIOS Boot Menu Selections	BIOS Boot Menu Selections
UEFI Driver Control Menu Selections	UEFI Driver Control Menu Selections	<i>See the Advanced Menu for driver settings.</i>
BIOS Save and Exit Menu Selections	BIOS Save and Exit Menu Selections	BIOS Save and Exit Menu Selections

Oracle Database Appliance (Original Version) BIOS Utility

This section describes the Oracle Database Appliance (original version) BIOS utility. If you have Oracle Database Appliance X6-2 series, go to [“Oracle Database Appliance X6-2 Series BIOS Utility” on page 157](#). If you have Oracle Database Appliance X3-2, Oracle Database Appliance X4-2, or Oracle Database Appliance X5-2, go to [“Oracle Database Appliance X3-2/X4-2/X5-2 BIOS Utility” on page 158](#).

This section describes the Oracle Database Appliance (original version) BIOS utility.

All settings are set to the optimal defaults at startup.



Caution - You should not configure system BIOS settings. Oracle Database Appliance patch software will do this for you. The only time you might need to configure BIOS settings would be if requested to do so by Oracle Service.

The following topics are included:

- [“BIOS Booting and Setup” on page 160](#)
- [“Configuring Support for TPM” on page 167](#)
- [“Configuring SP LAN Settings” on page 173](#)
- [“Configuring Option ROM Settings in BIOS” on page 175](#)
- [“BIOS Setup Utility Hot Keys” on page 176](#)
- [“Accessing the BIOS Setup Utility Menus” on page 176](#)
- [“BIOS Setup Utility Screens” on page 179](#)

BIOS Booting and Setup

The following sections describe the tests performed by BIOS during Oracle Database Appliance (original version) bootup:

- [“Default BIOS Power-On Self-Test \(POST\) Events” on page 161](#)
- [“BIOS POST F1 and F2 Errors” on page 162](#)

- [“How BIOS POST Memory Testing Works” on page 164](#)
- [“Clearing Server Node CMOS NVRAM” on page 165](#)

Default BIOS Power-On Self-Test (POST) Events

When an Oracle Database Appliance (original version) server node (also called a system controller) starts, the BIOS performs a power-on self-test that checks the hardware to ensure that all components are present and functioning properly. The following table identifies the events that can occur during BIOS POST, as well as specifies whether these events can prevent the host from powering-on.

Event	Cause	Boot Continues on Host?
User password violation	Attempt to enter password fails three times	No
Setup password violation	Attempt to enter password fails three times	No
Correctable ECC	Memory Correctable ECC (error correction code) error is detected	Does not apply
Uncorrectable ECC	Memory Uncorrectable ECC error is detected	Does not apply
No system memory	No physical memory is detected in the system	No
No usable system memory	All installed memory has experienced an unrecoverable failure	No
Hard disk controller failure	No disk controller is found	Yes
Keyboard failure	Keyboard cannot be initialized	Yes
Boot media failure	No removable boot media is found	Yes
No video device	No video controller is found	No
Firmware (BIOS) ROM corruption	BIOS checksum fails and the boot block is not corrupted	No
System restart	System boot is initiated	Yes
Initiated by hard reset	Boot process is started by hard reset	Yes
Memory initialization	Memory sizing is occurring	Does not apply
Primary processor initialization	System firmware progress	Does not apply
	Primary CPU initialization	
Initiated by warm reset	System firmware progress	Does not apply
	Boot process is started by warm reset	
Embedded controller management	Management controller initialization	Does not apply
Secondary processor(s) initialization	Secondary CPU initialization asserted	Does not apply
	System firmware progress	
Video initialization	When BIOS initializes keyboard	Does not apply
Keyboard controller initialization	When BIOS initializes keyboard	Does not apply

Event	Cause	Boot Continues on Host?
Option ROM initialization	BIOS initializes Option ROMs	Does not apply
Option ROM space exhausted	System firmware progress BIOS cannot install an Option ROM (typically a plug-in card driver) into memory from that device preventing booting	Yes
User initiated system set up	User initiated access to BIOS Setup Utility	Does not apply
User initiated boot to OS	System firmware progress System boot is initiated	Does not apply
No bootable media	System firmware progress No media from which to boot	No
PXE server not found	Boot error - PXE server not found	No. BIOS tries next boot device.
	F12 key was pressed but BIOS fails to boot from PXE server	
ACPI Power state	Soft-off power applied	Does not apply

BIOS POST F1 and F2 Errors

Each Oracle Database Appliance (original version) power-on-self-test (POST) diagnostic is a low-level test designed to detect faults in a specific hardware component. If the POST diagnostic discloses an F1 or F2 error, it typically reports the following information about the error:

- Type of error detected
- When or where the error occurred

The following table lists some of the F1 and F2 error messages that could appear during the POST diagnostics along with instructions for how to possibly resolve the error reported.

BIOS POST Error Message	Error Type	Resolution
Uncorrectable Error Detected on Last Boot:IOH (0) Protocol Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details.
Uncorrectable Error Detected on Last Boot:IOH(0) QPI [x] Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the fault management function and the SP event log in Oracle ILOM for more details. <p>Note - Where QPI [x] equals 0 for QPI Link 0 or 1 for QPI Link 1.</p>
Uncorrectable Error Detected on Last Boot:IOH (0) PCI-E [x] Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the fault management function and the SP event log in Oracle ILOM for more details.

BIOS POST Error Message	Error Type	Resolution
Uncorrectable Error Detected on Last Boot:IOH(0) ESI Error (Please Check SP Log for more Details)	IOH error	<p>Note - Where PCI-E [x] port number can range from 1 to 10 depending on the PCI root port on IOH.</p> <ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the fault management function and the SP event log in Oracle ILOM for more details.
Uncorrectable Error Detected on Last Boot:IOH(0) Thermal Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the fault management function and the SP event log in Oracle ILOM for more details.
Uncorrectable Error Detected on Last Boot:IOH(0) DMA Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details.
Uncorrectable Error Detected on Last Boot:IOH(0) Miscellaneous Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the fault management function and the SP event log in Oracle ILOM for more details.
Uncorrectable Error Detected on Last Boot:IOH(0) VTd Error (Please Check SP Log for more Details)	IOH error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details.
BMC Not Responding	Oracle ILOM error	<ul style="list-style-type: none"> ■ Press F1 to continue. <p>Note - This error message might display if during the SP/BIOS communication an internal error occurs. This error might require you to restart the SP.</p>
<ul style="list-style-type: none"> ■ Primary Slave Hard Disk Error ■ Primary Master Hard Disk Error ■ Secondary Master Hard Disk Error ■ Secondary Slave Hard Disk Error <p>Note - These error messages are not supported on Oracle Database Appliance.</p>	IDE/ATAPI error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details. <p>Note - These type of error messages display when the BIOS is attempting to configure IDE/ATAPI devices in POST.</p>
Timer Error	8254 timer error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details. <p>Note - This type of error typically indicates an error while programming the count register of channel 2 of the 8254 timer. This could indicate a problem with system hardware.</p>
RAM R/W test failed	Memory test failure	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details. <p>Note - This type of error typically indicates that the RAM read/write test failed.</p>
KBC BAT Test failed	Keyboard controller basic assurance test error	<ul style="list-style-type: none"> ■ Press F1 to continue. ■ Check the SP event log in Oracle ILOM for more details.

BIOS POST Error Message	Error Type	Resolution
Display memory test failed	Video display error	<p>Note - Keyboard controller BAT test failed. This error might indicate a problem with keyboard controller initialization.</p> <ul style="list-style-type: none"> Press F1 to continue. Check the SP event log in Oracle ILOM for more details.
CMOS Battery Low	CMOS battery error	<ul style="list-style-type: none"> Press F2 to enter BIOS Setup Utility to load system defaults. Check the SP event log in Oracle ILOM for more details. If necessary, replace CMOS battery.
<ul style="list-style-type: none"> CMOS Checksum Bad CMOS Date/Time Not Set 	CMOS error	<ul style="list-style-type: none"> Press F2 to enter BIOS Setup Utility to load system defaults. Check the SP event log in Oracle ILOM for more details.
Password check failed	Password check error	<ul style="list-style-type: none"> Press F1 to continue. Check the SP event log in Oracle ILOM for more details. <p>Note - This type of error indicates that the password entered does not match the password specified in the BIOS Setup Utility. This condition might occur for both Supervisor and User password verification.</p>
Keyboard/Interface Error	Keyboard controller error	<ul style="list-style-type: none"> Press F1 to continue. Check the SP event log in Oracle ILOM for more details. <p>Note - This type of error indicates that the Keyboard Controller failure. This error might indicate a problem with system hardware.</p>
S.M.A.R.T error on the drive	S.M.A.R.T device error	<ul style="list-style-type: none"> Press F1 to continue. Check the SP event log in Oracle ILOM for more details. <p>Note - Self-Monitoring, Analysis, and Reporting Technology (S.M.A.R.T.) failure messages might indicate the need to replace the storage device.</p>

How BIOS POST Memory Testing Works

The Oracle Database Appliance (original version) BIOS POST memory testing is performed as follows:

1. The first megabyte of DRAM is tested by the BIOS before the BIOS code is copied from ROM to DRAM.
2. After existing out of DRAM, the BIOS performs a simple memory test (where a write/read of every location with the pattern 55aa55aa is performed).

Note - The simple memory test is performed only if Quick Boot is not enabled from the Boot Settings Configuration screen. Enabling Quick Boot causes the BIOS to skip the memory test.

3. The BIOS polls the memory controllers for both correctable and non-correctable memory errors and logs those errors into the SP.

Clearing Server Node CMOS NVRAM

You can clear the CMOS NVRAM by pressing the CLR CMOS button on the Oracle Database Appliance (original version) server node motherboard. This action sets the BIOS to defaults values, which clears the BIOS user and supervisor passwords.

You can also set or reset the BIOS password from the BIOS Setup Utility. See [“BIOS Security Menu Screen” on page 184](#) for more information.



Caution - Data loss. You should not perform this procedure unless instructed to do so by Oracle Service.

▼ Reset BIOS Password and Clear CMOS NVRAM Using CLR CMOS Button


1. **Prepare the server node for service.**
 - a. **Attach an antistatic wrist strap.**

See [“Performing Electrostatic Discharge and Antistatic Prevention Measures” on page 35](#).
 - b. **Remove the server node from the system.**

Power is removed from the server node when you remove it from the system. See [“Removing Server Nodes From the System Chassis” on page 35](#).
 - c. **Remove the server node top cover.**

See [“Removing the Server Node Top Cover” on page 36](#).

2. **Using a stylus, press and release the CLR CMOS button.**



3. **Return the server node to operation.**

- a. **Install the server node top cover.**

See [“Installing the Server Node Top Cover”](#) on page 146.

- b. **Install the server node into the system.**

See [“Installing a Server Node Into the System Chassis”](#) on page 147.

- c. **Power on the server node.**

See [“Powering On Oracle Database Appliance \(Original Version\)”](#) on page 149.

When the server node powers on and boots, it displays a message that indicates that NVRAM has been cleared.

The CMOS NVRAM, including the BIOS password is cleared to its default state.

The default state for the BIOS passwords is that no password is required. To set a BIOS password, see [“BIOS Security Menu Screen”](#) on page 184.

4. **Verify that the Power/OK LED is lit on the server node.**

Ethernet Port Naming and Boot Order

Each Oracle Database Appliance (original version) server node supports two 10/100/1000Base-T Gigabit Ethernet ports on the rear of the chassis. For port locations, see the *Oracle Database Appliance Owner's Guide*.

The device naming for the Ethernet interfaces is reported differently by different interfaces and operating systems. See the following table for the physical (BIOS) and logical (operating system) naming conventions used for each interface.

Interface	NET0	NET1
BIOS	NET0	NET1
Oracle Linux	eth0	eth1

The order in which the BIOS detects the Ethernet ports during boot time, and the corresponding drivers that control those ports, are listed below:

1. NET 0 (INTEL NIC 0)
2. NET 1 (INTEL NIC 1)

Configuring Support for TPM

If you intend to use the Oracle Database Appliance (original version) Trusted Platform Module (TPM) feature set, you must configure the server node to support this feature.


TPM enables you to administer the TPM security hardware in your server node. For additional information about implementing this feature, see the Trusted Platform Module Management documentation.

▼ Configure TPM Support in BIOS

1. **Access the BIOS Setup Utility menus.**

For instructions, see [“Accessing the BIOS Setup Utility Menus” on page 176](#).

When BIOS is started, the main BIOS Setup Utility top-level System Overview screen appears.




2. In the BIOS Setup Utility screen, select the Advanced menu option.

The Advanced Settings screen appears.



3. In the Advanced Settings screen, select Trusted Computing and press Enter.


The Trusted Computing screen appears.



4. **In the Trusted Computing screen, select the TCG/TPM Support.**
A pop-up dialog box appears.
5. **In the pop-up dialog box, set the TCG/TPM Support option to Yes and click OK.**

Note - Even if the TCG/TPM Support was already set to Yes in the dialog shown above, continue on and complete the remaining steps of this procedure to ensure that all TPM configuration requirements are satisfied.


The updated Trusted Computing dialog appears and shows that the TCG/TPM Support setting has changed to Yes.



Note - In the above screen, the Execute TPM Command setting shows the default, Don't Change.


6. **In the Trusted Computing screen, select the Execute TPM Command option setting.**
A pop-up dialog box appears.
7. **In the pop-up dialog box, set the Execute TPM Command option to Enabled and click OK.**

The updated Trusted Computing screen appears and shows that the Execute TPM Command setting has changed to Enabled.



8. **Press F10 to save the changes and exit the BIOS Setup Utility.**
9. **To verify that TPM support is configured, do the following:**
 - a. **Reboot the server node.**
 - b. **To enter the BIOS Setup Utility, press the F2 key while the system is performing the power-on self-test (POST).**
When BIOS is started, the main BIOS Setup Utility top-level screen appears.
 - c. **Select Advanced, then select Trusted Computing and press Enter.**
The updated Trusted Computing screen appears.

Confirm that the TCG/TPM Support setting is set to Yes and the TPM Enabled/Disable Status is set to Enabled.



10. Press F10 to exit the BIOS Setup Utility.

This completes the TPM configuration.

Configuring SP LAN Settings


You can assign an IP address for the Oracle Database Appliance (original version) server node SP from the BIOS Setup Utility on the IPMI LAN configuration menu. Alternatively, you can also specify the LAN settings for the SP using Oracle ILOM. For instructions for setting the IP address in Oracle ILOM, see *Oracle Integrated Lights Out Manager (Oracle ILOM) 3.0 Documentation Collection*.

▼ Configure LAN Settings for SP

1. Access the BIOS Setup Utility menus.

For instructions, see [“Accessing the BIOS Setup Utility Menus”](#) on page 176.

2. In the BIOS Setup Utility menus, use the arrow keys (or Tab key) to navigate to the Advanced menu.
3. In the Advanced menu, select IPMI Configuration.
4. In the IPMI Configuration menu, select LAN Configuration.
The LAN Configuration screen appears.
5. In the LAN Configuration screen, use the arrow keys to select and specify the appropriate LAN configuration settings.



6. After making the necessary changes, select Commit and press Enter to apply the changes.
7. Press F10 to save the changes and exit BIOS.

Configuring Option ROM Settings in BIOS

The Oracle Database Appliance (original version) BIOS Option ROM space is 128 Kbytes. Of these 128 Kbytes, approximately 80 Kbytes are used by the VGA controller, the disk controller, and the network interface card. Approximately 48 Kbytes remain to be shared by the Option ROMs on all bootable PCI-Express plug-in cards.

▼ Enable or Disable Option ROM Settings

1. Access the BIOS Setup Utility menus.

For instructions, see [“Accessing the BIOS Setup Utility Menus”](#) on page 176.

2. In the BIOS Setup Utility menus, use the arrow keys (or Tab key) to navigate to the Boot menu.

The Boot menu appears.



3. In the Boot menu, highlight the Option ROM setting, and then press Enter.

4. Check whether the settings in your screen output match what is shown above. If they do not match, proceed to the next step. If they match, proceed to Step 7 and exit BIOS.

5. To change the settings, in the Boot menu listing the Option ROM settings, highlight the applicable Option ROM setting to modify, then press Enter.

A dialog box appears listing the available settings.

6. In the dialog box, do one of the following:
 - Select `-Enabled` to enable the Option ROM setting.
 - Select `-Disabled` to disable the Option ROM setting.
7. Press F10 to save the changes and exit the BIOS Setup Utility.

BIOS Setup Utility Hot Keys

The following table provides a description of the Oracle Database Appliance (original version) BIOS Setup Utility Oracle ILOM Remote Console keys and the directly attached keyboard keys, and the corresponding serial connection key combinations.

Oracle ILOM Remote Console Keys	Serial Connection Hot Key Combinations	Function
F1	Ctrl+Q (Press and hold the Control key and type Q)	Access the BIOS Setup Utility if there is an error during the boot process.
F2	Ctrl+E	Enter BIOS Setup Utility when the system has completed the power-on self-test (POST).
F7	Ctrl+D	Discard changes, but do not exit.
F8	Ctrl+P	Select the BBS Popup menu, which allows you to select a boot device.
F9	Ctrl+O	Load optimal BIOS defaults.
F10 [†]	Ctrl+S	Save changes and exit.
F12	Ctrl+N	Boot the server node from the network (PXE boot).

[†]F10 is not supported on the Oracle ILOM Remote Console; instead, use the arrow keys to navigate to the Exit menu and press Enter.

Accessing the BIOS Setup Utility Menus

You can access Oracle Database Appliance (original version) BIOS Setup Utility screens from the following interfaces:

- Use a USB keyboard, mouse, and VGA monitor connected directly to the server node.
- Use a terminal (or terminal emulator connected to a computer) through the serial port on the back panel of the server node.

- Connect to the server node using the Oracle ILOM Remote Console.

The following procedure describes the steps for accessing the BIOS Setup Utility menus.

▼ Access BIOS Setup Utility Menus

1. Power-on or power-cycle the server node.
2. The following information appears on the screen:



```

American Megatrends
www.ami.com

Sun
ORACLE

AMIBIOS (C) 2009 American Megatrends, Inc.
BIOS Date: 06/19/09 05:37:42 Ver: 08.00.16
Oracle BIOS Revision: 12.01.03.07
Oracle X4370 M2 Server CPU Power (TDP Limit) = 95 Watts
Product Serial Number:1050CNW001
CPU : Intel(R) Xeon(R) CPU X5675 @ 3.07GHz
Speed : 3.06 GHz Count : 24

Press F2 to run Setup (CTRL+E on Serial Console)
Press F12 if you want to boot from the network (CTRL+N on Serial Console)
Press F8 for BBS POPUP (CTRL+P on Serial Console)
QPI Operational Speed at : 6.4GT/s
BMC Firmware Revision: 3.0.14.13.a r70764
Initializing USB Controllers .. Done.
98296MB OK


(C) American Megatrends, Inc.
66-3047-009999-00101111-061909-TYLSBURG-12010307-V2KC 6B3B

```

3. To enter the BIOS Setup Utility, do the following:
 - a. Wait for the last line of the screen output to change to **Initializing USB Controllers..Done**
This will take several seconds.
 - b. When **Done** appears, press the **F2** key immediately.

Note - If there is an error during the boot process, you can press F1 to access the BIOS Setup Utility.

The BIOS Setup Utility dialog appears.



Note - If the BIOS Setup Utility dialog does not appear, you waited too long to press the F2 key. When Done appears on the screen, you must press the F2 key immediately. Try again.

4. Use the left and right arrow keys to select the different menu options.
5. As you select each menu option, the top-level screen for that menu option appears.
6. To select an option on a top-level screen, use the up and down arrow keys to scroll up and down the options presented.

Only options that can be modified are highlighted when you press the up and down arrow keys.

 - If a field can be modified, as you select the option, user instructions for modifying the option appear in the right column of the screen.
 - If a field is a link to a sub-screen, instructions to press the Enter key to access the sub-screen appear in the right column.
7. Modify the setup field and press the Esc key to save the changes and exit the screen.

Some screens present a confirmation dialog box that enables unwanted changes to be retracted.

8. **On sub-screens that only provide configuration information and cannot be modified, press the Esc key to exit the screen.**
9. **To continue modifying other setup parameters, repeat Step 4 through Step 8. Otherwise, go to Step 10.**
10. **Press and release the right arrow key until the Exit menu screen appears.**
11. **Follow the instructions on the Exit menu screen to save or discard your changes and exit the BIOS Setup Utility.**

BIOS Setup Utility Screens

This section describes the Oracle Database Appliance (original version) BIOS setup utility screens. It includes the following sections:

- [“BIOS Setup Utility Screen Overview” on page 179](#)
- [“BIOS Main Menu Screen” on page 181](#)
- [“BIOS Advanced Menu Screen” on page 182](#)
- [“BIOS PCI Menu Screen” on page 183](#)
- [“BIOS Boot Menu Screen” on page 184](#)
- [“BIOS Security Menu Screen” on page 184](#)
- [“BIOS Chipset Menu Screen” on page 185](#)
- [“BIOS Exit Menu Screen” on page 185](#)

The BIOS utility includes seven top-level screens, many of which include sub-screens. Arrow keys provide navigation, and the options or fields that you can configure appear in color. Online instructions provide additional information.


Note - The screens shown are examples. The version numbers and the screen items and selections shown are subject to change over the life of the product.

BIOS Setup Utility Screen Overview

The following table contains summary descriptions of the Oracle Database Appliance (original version) top-level BIOS setup screens.


Screen	Description	See This Section
Main	General product information, including BIOS type, processor, memory, and time/date.	“BIOS Main Menu Screen” on page 181
Advanced	Configuration information for the CPU, memory, IDE, Super IO, trusted computing, USB, PCI, MPS and other information.	“BIOS Advanced Menu Screen” on page 182
PCI	Configure the system to clear NVRAM during system boot.	“BIOS PCI Menu Screen” on page 183
Boot	Configure the boot device priority (storage drives and boot disk drives).	“BIOS Boot Menu Screen” on page 184
Security	Set or change the user and supervisor passwords.	“BIOS Security Menu Screen” on page 184
Chipset	View the configuration of system chip set.	“BIOS Chipset Menu Screen” on page 185
Exit	Save changes and exit, discard changes and exit, discard changes, or load optimal or fail-safe defaults.	“BIOS Exit Menu Screen” on page 185

The following figures shows a map of the BIOS screens.




BIOS Main Menu Screen

The Oracle Database Appliance (original version) BIOS Main screen provides general product information, including BIOS, processor, system memory, and system time/date.




BIOS Advanced Menu Screen

The Oracle Database Appliance (original version) BIOS Advanced screen provides detailed configuration information for the CPU, memory, IDE, Super IO, trusted computing, USB, PCI, MPS and other system information.



BIOS PCI Menu Screen

The Oracle Database Appliance (original version) BIOS PCI screen enables you to configure the server node to clear NVRAM during system boot.



BIOS Boot Menu Screen

The Oracle Database Appliance (original version) BIOS Boot screen enables you to configure the boot device priority (storage drives and the DVD-ROM drive).



BIOS Security Menu Screen


The Oracle Database Appliance (original version) BIOS Security screen enables you to set or change the supervisor and user passwords. The default state is for the passwords to be unconfigured (not required).

- If you configure a supervisor password, users must enter it to access BIOS setup.
- If you configure a user password, users must enter it before booting an OS.




BIOS Chipset Menu Screen

The Oracle Database Appliance (original version) BIOS Chipset screen enables you to set the chipset parameters.



BIOS Exit Menu Screen

The Oracle Database Appliance (original version) BIOS Exit options enable you to save changes and exit, discard changes and exit, discard changes, or load optimal defaults.



▼ **Exit From the BIOS Setup Utility**

1. **Use the up and down arrow keys to scroll up and down the BIOS Exit options.**
2. **Press Enter to select the option.**

A confirmation dialog box appears that enables you to save the changes and exit the Setup Utility or cancel the exit option.

Note - The confirmation dialog box is only shown below for the Save Changes and Exit option screen. The other exit confirmation screens work in a similar way.



Index

A

- air duct
 - installing
 - Oracle Database Appliance (original version), 101
 - removing
 - Oracle Database Appliance (original version), 100, 100
- antistatic wrist strap
 - described
 - Oracle Database Appliance (original version), 35
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27

B

- battery
 - installing
 - Oracle Database Appliance (original version), 89
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - removing
 - Oracle Database Appliance (original version), 88
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - servicing server node
 - Oracle Database Appliance (original version), 88
- BIOS
 - accessing the setup utility

- Oracle Database Appliance (original version), 176
- Oracle Database Appliance X3-2/X4-2/X5-2, 159
- Oracle Database Appliance X6-2 series, 158
- advanced menu options
 - Oracle Database Appliance (original version), 179
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- boot menu options
 - Oracle Database Appliance (original version), 179
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- chipset menu options
 - Oracle Database Appliance (original version), 179
- common tasks
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- I/O menu options
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- LAN settings
 - Oracle Database Appliance (original version), 173
- legacy and UEFI modes
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- main menu options

- Oracle Database Appliance (original version), 179
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - managing configurations
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - memory testing
 - Oracle Database Appliance (original version), 164
 - Oracle Database Appliance X3-2/X4-2/X5-2, 153
 - Oracle Database Appliance X6-2 series, 153
 - PCI menu options
 - Oracle Database Appliance (original version), 179
 - POST errors
 - Oracle Database Appliance (original version), 162
 - Oracle Database Appliance X3-2/X4-2/X5-2, 153
 - Oracle Database Appliance X6-2 series, 153
 - POST events
 - Oracle Database Appliance (original version), 161
 - resetting password
 - Oracle Database Appliance (original version), 165
 - save and exit options
 - Oracle Database Appliance (original version), 179
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - security menu options
 - Oracle Database Appliance (original version), 179
 - setup screens summary
 - Oracle Database Appliance (original version), 179, 179
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - setup utility hot keys
 - Oracle Database Appliance (original version), 176
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - UEFI driver control options
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - using for resource allocation
 - Oracle Database Appliance (original version), 175
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - BIOS Setup Utility
 - accessing
 - Oracle Database Appliance (original version), 176
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - boot disk backplane cables
 - installing
 - Oracle Database Appliance (original version), 137
 - removing
 - Oracle Database Appliance (original version), 136
 - boot drives
 - slot numbering and supported types
 - Oracle Database Appliance (original version), 53
- ## C
- cables
 - reconnecting power and data cables after servicing
 - Oracle Database Appliance (original version), 149
 - Oracle Database Appliance X3-2/X4-2/X5-2, 144
 - Oracle Database Appliance X6-2 series, 143
 - chassis interlock switch
 - disconnecting

- Oracle Database Appliance (original version), 111
- reconnecting
 - Oracle Database Appliance (original version), 113
- CLR CMOS button
 - location of
 - Oracle Database Appliance (original version), 165
- CMOS NVRAM
 - clearing
 - Oracle Database Appliance (original version), 165
- cold service components
 - CRUs
 - Oracle Database Appliance (original version), 67
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - FRUs
 - Oracle Database Appliance (original version), 99
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- CPUs
 - clearing faults
 - Oracle Database Appliance (original version), 106
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - fault LED locations
 - Oracle Database Appliance (original version), 102
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - fault LEDs
 - Oracle Database Appliance (original version), 24
 - installing
 - Oracle Database Appliance (original version), 106
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - population rules
 - Oracle Database Appliance (original version), 69
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - removing
 - Oracle Database Appliance (original version), 102
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - servicing
 - Oracle Database Appliance (original version), 102
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- CRUs
 - component locations
 - Oracle Database Appliance (original version), 67
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - removal that does not require system power off, 39
 - removal that requires system power off, 65
- D**
 - date and time
 - resetting after battery replacement
 - Oracle Database Appliance (original version), 89
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - server node battery
 - Oracle Database Appliance (original version), 88
 - diagnostic tools
 - summary of, 153
 - DIMMs
 - clearing faults

- Oracle Database Appliance (original version), 73
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - error correction (ECC)
 - Oracle Database Appliance (original version), 76
 - Fault Remind button
 - Oracle Database Appliance (original version), 70
 - installing
 - Oracle Database Appliance (original version), 73
 - population rules
 - Oracle Database Appliance (original version), 69
 - removing
 - Oracle Database Appliance (original version), 70
 - servicing
 - Oracle Database Appliance (original version), 68
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - disk backplane
 - installing boot disk backplane
 - Oracle Database Appliance (original version), 110
 - removing boot disk backplane
 - Oracle Database Appliance (original version), 109
 - servicing boot disk backplane
 - Oracle Database Appliance (original version), 109
 - servicing disk backplane
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - updating TLI information after replacement
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 94
 - disk midplane module
 - installing
 - Oracle Database Appliance (original version), 119
 - removing
 - Oracle Database Appliance (original version), 115
 - servicing
 - Oracle Database Appliance (original version), 115
 - disk midplane module HDD cable
 - installing
 - Oracle Database Appliance (original version), 122
 - removing
 - Oracle Database Appliance (original version), 121
 - servicing
 - Oracle Database Appliance (original version), 121
- E**
- ECC memory
 - correctable and uncorrectable errors
 - Oracle Database Appliance (original version), 76
 - electrostatic discharge (ESD)
 - precautions
 - Oracle Database Appliance (original version), 35
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - emergency shutdown
 - server node
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - Ethernet ports
 - LEDs
 - Oracle Database Appliance (original version), 25
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - naming and boot priority

- Oracle Database Appliance (original version), 167
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- F**
- fan power cable
 - installing
 - Oracle Database Appliance (original version), 129
 - removing
 - Oracle Database Appliance (original version), 128
 - fans
 - detecting faults using LEDs
 - Oracle Database Appliance (original version), 59
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - installing
 - Oracle Database Appliance (original version), 60
 - LEDs
 - Oracle Database Appliance (original version), 20
 - removing
 - Oracle Database Appliance (original version), 59
 - replacing in server node
 - Oracle Database Appliance (original version), 58
 - Oracle Database Appliance X3-2/X4-2/X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
 - fault LED
 - server node fan
 - Oracle Database Appliance (original version), 59
 - server node power supply
 - Oracle Database Appliance (original version), 62
 - Fault Remind button
 - identifying faulty CPU
 - Oracle Database Appliance (original version), 102
 - locating a faulty DIMM
 - Oracle Database Appliance (original version), 70
 - faults
 - clearing CPU faults
 - Oracle Database Appliance (original version), 106
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - clearing DIMM faults
 - Oracle Database Appliance (original version), 73
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - clearing PCIe card faults
 - Oracle Database Appliance (original version), 82
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - clearing PCIe riser faults
 - Oracle Database Appliance (original version), 79
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - clearing the primary HBA card faults
 - Oracle Database Appliance (original version), 86
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - managing
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 93
 - front indicator module (FIM)
 - connectors
 - Oracle Database Appliance (original version), 115
 - front indicator panels
 - installing
 - Oracle Database Appliance (original version), 126
 - removing
 - Oracle Database Appliance (original version), 123
 - servicing

- Oracle Database Appliance (original version), 123
- Oracle Database Appliance X3-2/X4-2/X5-2, 92
- Oracle Database Appliance X6-2 series, 91
- FRUs
 - component locations
 - Oracle Database Appliance (original version), 29
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - removal that requires system power off, 91
- G**
- graceful shutdown
 - server node
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
- H**
- hard disk drives
 - install boot drive
 - Oracle Database Appliance (original version), 57
 - installing
 - Oracle Database Appliance (original version), 55
 - remove boot drive
 - Oracle Database Appliance (original version), 56
 - removing
 - Oracle Database Appliance (original version), 54
 - replacing in server node
 - Oracle Database Appliance (original version), 53
 - Oracle Database Appliance X3-2/X4-2/X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
 - replacing in storage shelf
 - Oracle Database Appliance X3-2/X4-2/X5-2, 44
 - slot numbering and supported types
 - Oracle Database Appliance (original version), 53
 - storage and boot drive status indicators
 - Oracle Database Appliance (original version), 21
- HBA
 - installing
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - installing the primary HBA
 - Oracle Database Appliance (original version), 86
 - primary and secondary cards
 - Oracle Database Appliance (original version), 81
 - removing
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - removing the primary HBA card
 - Oracle Database Appliance (original version), 85
- heatsink
 - cleaning
 - Oracle Database Appliance (original version), 102
- host bus adapter (HBA) cables
 - installing in primary HBA
 - Oracle Database Appliance (original version), 131
 - installing in secondary HBA
 - Oracle Database Appliance (original version), 133
 - removing from primary HBA
 - Oracle Database Appliance (original version), 130
 - removing from secondary HBA
 - Oracle Database Appliance (original version), 132
 - servicing SAS cables
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92

- Oracle Database Appliance X6-2 series, 91
 - hot-plug components
 - Oracle Database Appliance (original version), 29
 - server node
 - Oracle Database Appliance (original version), 52
 - Oracle Database Appliance X3-2/X4-2/X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
 - hot-pluggable components, 39
- I**
- I/O module
 - replacing in Oracle Database Appliance storage shelf
 - Oracle Database Appliance X3-2/X4-2/X5-2, 49
 - ILOM *See* Oracle Integrated Lights Out Manager
- L**
- LEDs
 - AC OK
 - Oracle Database Appliance (original version), 22
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Activity
 - Oracle Database Appliance (original version), 21
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - CPU fault
 - Oracle Database Appliance (original version), 24
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - DC OK
 - Oracle Database Appliance (original version), 22
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Ethernet ports
 - Oracle Database Appliance (original version), 25
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - fans
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - fans status
 - Oracle Database Appliance (original version), 20
 - Fault Remind Power Good
 - Oracle Database Appliance (original version), 24
 - general status
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - internal server node
 - Oracle Database Appliance (original version), 24
 - Locate
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - memory DIMM fault
 - Oracle Database Appliance (original version), 24
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - motherboard
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - OK
 - Oracle Database Appliance (original version), 20
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11

- Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2 series, 11
 - Over Temperature
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - power supplies
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Power/OK
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Ready to Remove
 - Oracle Database Appliance (original version), 18, 21
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - rear component failure
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - server node rear Locate
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - server node rear Locate push to test
 - Oracle Database Appliance (original version), 23
 - server node rear Power/OK
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - server node rear Ready to Remove
 - Oracle Database Appliance (original version), 23
 - server node rear Service Required
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - server node Service Required
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - server node SP OK/Fault
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Service Required
 - Oracle Database Appliance (original version), 18, 20, 21, 22
 - SP OK/Fault
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - storage and boot drives
 - Oracle Database Appliance (original version), 21
 - storage devices
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - storage shelf back panel
 - Oracle Database Appliance X3-2/X4-2, 16
 - Oracle Database Appliance X5-2, 14
 - storage shelf front panel
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 13
- M**
- memory *See* DIMMs
 - motherboard
 - updating TLI information after replacement
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 94
 - motherboard assembly
 - replaceable components on
 - Oracle Database Appliance (original version), 138

-
- Oracle Database Appliance X3-2/X4-2/
X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
 - servicing
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- N**
- network ports
 - naming and boot order
 - Oracle Database Appliance (original
version), 167
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
- O**
- option ROM settings
 - configuring
 - Oracle Database Appliance (original
version), 175
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 159
 - Oracle Database Appliance X6-2 series, 158
 - Oracle Integrated Lights Out Manager (Oracle ILOM)
 - server node power off procedures
 - Oracle Database Appliance (original
version), 32
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - server node power on procedures
 - dual node Oracle Database Appliance with
storage shelf, 145
 - Oracle Database Appliance (original
version), 149
 - Oracle Database Appliance X6-2 series, 143
 - SP reset, 155
 - used as diagnostic tool, 153
- P**
- Pc-Check, 153
- PCIe cards
 - clearing faults
 - Oracle Database Appliance (original
version), 82
 - Oracle Database Appliance X3-2/X4-2/X5-2 and
X6-2 series, 93
 - configurations supported
 - Oracle Database Appliance (original
version), 81
 - installing in PCIe riser
 - Oracle Database Appliance (original
version), 82
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - installing the primary HBA
 - Oracle Database Appliance (original
version), 86
 - primary and secondary HBA
 - Oracle Database Appliance (original
version), 81
 - removing from PCIe riser
 - Oracle Database Appliance (original
version), 81
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - removing the primary HBA card
 - Oracle Database Appliance (original
version), 85
 - servicing
 - Oracle Database Appliance (original
version), 80
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - PCIe riser
 - clearing faults
 - Oracle Database Appliance (original
version), 79
 - Oracle Database Appliance X3-2/X4-2/X5-2 and
X6-2 series, 93
 - installing
 - Oracle Database Appliance (original
version), 79

- Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - removing
 - Oracle Database Appliance (original version), 77
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - servicing
 - Oracle Database Appliance (original version), 77
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - power distribution board
 - installing
 - Oracle Database Appliance (original version), 113
 - removing
 - Oracle Database Appliance (original version), 111
 - servicing
 - Oracle Database Appliance (original version), 111
 - power off
 - system, 34
 - power supplies
 - detecting faults using LEDs
 - Oracle Database Appliance (original version), 62
 - replacing in server node
 - Oracle Database Appliance (original version), 61
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
 - replacing in storage shelf
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 46
 - server node
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
 - status indicators
 - Oracle Database Appliance (original version), 22
 - power-on self-test (POST), 153
 - power-on self-test (POST) events
 - Oracle Database Appliance (original version), 161
 - powering off
 - emergency shutdown
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - graceful shutdown
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - powering on
 - dual node Oracle Database Appliance with storage shelf, 145
 - Oracle Database Appliance (original version), 149
 - Oracle Database Appliance X6-2 series, 143
 - processors *See* CPUs
- ## R
- replaceable components
 - cold service components
 - Oracle Database Appliance (original version), 29
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
 - hot service components
 - Oracle Database Appliance (original version), 29
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
 - replacing
 - hot and cold service components
 - Oracle Database Appliance (original version), 29
 - Oracle Database Appliance X3-2/X4-2/
X5-2, 28

- Oracle Database Appliance X6-2 series, 27
 - required tools
 - servicing components
 - Oracle Database Appliance (original version), 31
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - reset Oracle ILOM SP, 155
- S**
- safety information
 - servicing
 - Oracle Database Appliance (original version), 31
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - SAS expander cable
 - installing
 - Oracle Database Appliance (original version), 135
 - removing
 - Oracle Database Appliance (original version), 134
 - serial number
 - location of
 - Oracle Database Appliance (original version), 31
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 94
 - server node
 - back panel indicators
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - installing into the chassis
 - Oracle Database Appliance (original version), 147
 - internal LEDs
 - Oracle Database Appliance (original version), 24
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - powering off
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - reconnecting power and data cables
 - Oracle Database Appliance (original version), 149
 - Oracle Database Appliance X3-2/X4-2/X5-2, 144
 - Oracle Database Appliance X6-2 series, 143
 - reinstalling in rack
 - Oracle Database Appliance X3-2/X4-2/X5-2, 144
 - Oracle Database Appliance X6-2 series, 143
 - removing from chassis
 - Oracle Database Appliance (original version), 35
 - removing from rack
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - removing middle section, Oracle Database Appliance (original version), 37
 - removing the top cover
 - Oracle Database Appliance (original version), 36
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - slide into rack from maintenance position
 - Oracle Database Appliance X3-2/X4-2/X5-2, 144
 - Oracle Database Appliance X6-2 series, 143
 - slide out from rack to maintenance position
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - service processor reset, 155
 - servicing
 - air duct removal
 - Oracle Database Appliance (original version), 100

- boot disk backplane
 - Oracle Database Appliance (original version), 109
- CPUs
 - Oracle Database Appliance (original version), 102
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- DIMMs
 - Oracle Database Appliance (original version), 68
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
- disk backplane
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- disk midplane module
 - Oracle Database Appliance (original version), 115
- disk midplane module HDD cable
 - Oracle Database Appliance (original version), 121
- front indicator panels
 - Oracle Database Appliance (original version), 123
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- HBA SAS cables
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- hot-plug components, 39
 - Oracle Database Appliance (original version), 52
 - Oracle Database Appliance X3-2/X4-2/X5-2, 43
 - Oracle Database Appliance X6-2 series, 39
- hot-plug components, storage shelf, 43
- motherboard assembly
 - Oracle Database Appliance (original version), 138
 - Oracle Database Appliance X3-2/X4-2/X5-2, 92
 - Oracle Database Appliance X6-2 series, 91
- non-hot-plug CRU components, 65
- non-hot-plug FRU components, 91
- PCIe cards
 - Oracle Database Appliance (original version), 80
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
- PCIe riser
 - Oracle Database Appliance (original version), 77
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
- power distribution board
 - Oracle Database Appliance (original version), 111
- preparing for service
 - Oracle Database Appliance (original version), 29
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
- preparing the system, 27
- removing a server node from chassis
 - Oracle Database Appliance (original version), 35
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
- removing the top cover
 - Oracle Database Appliance (original version), 36
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
- replacing a power supply in storage shelf
 - Oracle Database Appliance X3-2/X4-2/X5-2, 46
- replacing fans in server node
 - Oracle Database Appliance (original version), 58
- replacing hard disk drives in server node

- Oracle Database Appliance (original version), 53
- replacing hard disk drives in storage shelf
 - Oracle Database Appliance X3-2/X4-2/X5-2, 44
- replacing I/O module in storage shelf
 - Oracle Database Appliance X3-2/X4-2/X5-2, 49
- replacing power supplies in server node
 - Oracle Database Appliance (original version), 61
- returning the appliance to operation
 - Oracle Database Appliance (original version), 146
 - Oracle Database Appliance X3-2/X4-2/X5-2, 144
 - Oracle Database Appliance X6-2 series, 143
- returning the system to operation, 143
- server node battery
 - Oracle Database Appliance (original version), 88
 - Oracle Database Appliance X3-2/X4-2/X5-2, 66
 - Oracle Database Appliance X6-2 series, 65
- server node cables
 - Oracle Database Appliance (original version), 128
- updating motherboard or disk backplane TLI information
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 94
- shutdown procedures
 - emergency shutdown
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - graceful shutdown
 - Oracle Database Appliance (original version), 32
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
- shutting down
 - Oracle Database Appliance (original version), 29
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - preparing the system for servicing, 27
- standby power state
 - dual node Oracle Database Appliance with storage shelf, 145
 - Oracle Database Appliance (original version), 149
- status indicators
 - AC OK
 - Oracle Database Appliance (original version), 22
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Activity
 - Oracle Database Appliance (original version), 21
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - CPU fault
 - Oracle Database Appliance (original version), 24
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - DC OK
 - Oracle Database Appliance (original version), 22
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Ethernet ports
 - Oracle Database Appliance (original version), 25
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - fans
 - Oracle Database Appliance (original version), 20
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Fault Remind Power Good

- Oracle Database Appliance (original version), 24
- Oracle Database Appliance X3-2/X4-2, 15
- Oracle Database Appliance X5-2, 12
- Oracle Database Appliance X6-2S/X6-2M, 11
- general status
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- internal server node
 - Oracle Database Appliance (original version), 24
- Locate
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- memory DIMM fault
 - Oracle Database Appliance (original version), 24
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- motherboard
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- OK
 - Oracle Database Appliance (original version), 20
- Oracle Database Appliance X3-2/X4-2, 15
- Oracle Database Appliance X5-2, 12
- Oracle Database Appliance X6-2 series, 11
- Over Temperature
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- power supplies
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- Power/OK
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- Ready to Remove
 - Oracle Database Appliance (original version), 18, 21
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- rear component failure
 - Oracle Database Appliance (original version), 18
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- server node
 - Oracle Database Appliance (original version), 18
- server node rear Locate
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- server node rear Locate push to test
 - Oracle Database Appliance (original version), 23
- server node rear Power/OK
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- server node rear Ready to Remove
 - Oracle Database Appliance (original version), 23
- server node rear Service Required
 - Oracle Database Appliance (original version), 23
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
- server node SP OK/Fault
 - Oracle Database Appliance X3-2/X4-2, 15

- Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - Service Required
 - Oracle Database Appliance (original version), 18, 20, 21, 22
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - SP OK/Fault
 - Oracle Database Appliance (original version), 18
 - storage and boot drives
 - Oracle Database Appliance (original version), 21
 - storage devices
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - Oracle Database Appliance X6-2S/X6-2M, 11
 - status indicators and LEDs
 - storage shelf
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 12
 - storage shelf back panel
 - Oracle Database Appliance X3-2/X4-2, 16
 - Oracle Database Appliance X5-2, 14
 - storage shelf front panel
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 13
 - storage shelf
 - servicing hot-plug components, 43
 - storage shelf indicators
 - back panel
 - Oracle Database Appliance X3-2/X4-2, 16
 - Oracle Database Appliance X5-2, 14
 - front panel
 - Oracle Database Appliance X3-2/X4-2, 15
 - Oracle Database Appliance X5-2, 13
 - System Identifier
 - updating for motherboard, 95
 - system_identifier
 - updating after motherboard replacement
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 94
- T**
- TLI
 - updating after motherboard or disk backplane replacement
 - Oracle Database Appliance X3-2/X4-2/X5-2 and X6-2 series, 94
 - tools
 - required for service
 - Oracle Database Appliance (original version), 31
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - top cover
 - install
 - Oracle Database Appliance X3-2/X4-2/X5-2, 144
 - Oracle Database Appliance X6-2 series, 143
 - install on server node
 - Oracle Database Appliance (original version), 146
 - removing sidewall cover
 - Oracle Database Appliance (original version), 115
 - server node
 - Oracle Database Appliance (original version), 36
 - Oracle Database Appliance X3-2/X4-2/X5-2, 28
 - Oracle Database Appliance X6-2 series, 27
 - system middle section, Oracle Database Appliance (original version), 37
 - Trusted Platform Module (TPM)
 - support for
 - Oracle Database Appliance (original version), 167
 - Oracle Database Appliance X3-2/X4-2/X5-2, 159
 - Oracle Database Appliance X6-2 series, 158

