

IBM TS2280

Setup, Operator, and Service Guide
Machine Type 3580 Model H8S



Note

Before you use this information and the product it supports, read the information in “Notices” on page 97. To ensure that you have the latest publications, visit the web at <http://www.ibm.com/storage/lto>

Released November 2017.

This edition applies to the *IBM TS2280 Tape Drive, SC27-4649-00*, and to the subsequent releases and modifications until otherwise indicated in new editions.

© Copyright IBM Corporation 2017.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

Read this first

This product might not be certified in your country for connection by any means whatsoever to interfaces of public telecommunications networks. Further certification might be required by law before making any such connection. Contact IBM® for information.

Accessing online technical support

It is the customer's responsibility to set up this tape drive or library and to ensure that the drive and library have the latest firmware (unless you have purchased a service contract).

For online technical support:

1. Visit <http://www.ibm.com>.
2. Click **Get Support**.
3. Click **Customer Support** and follow on-screen instructions.

Sending us your comments

Your feedback is important in helping IBM provide accurate and useful information. If you have comments or suggestions for improving this publication, send your comments by:

- Emailing IBM:
 - Internet or IBMLink from US: *starpubs@us.ibm.com*
 - IBMLink from Canada: *STARPUBS at TORIBM*

Include the following information in your email:

- Exact publication title
- Form number (for example, GA32-1234-02) or part number (on the back cover of the publication)
- Page, table, or illustration numbers that you are commenting on
- A detailed description of any information that should be changed

Contents

Note	iii
-----------------------	------------

Read this first	v
Accessing online technical support	v
Sending us your comments	v

Figures	ix
--------------------------	-----------

Tables	xi
-------------------------	-----------

Safety notices	xiii
Completing the safety inspection procedure	xiv
Tape drive ac grounding inspection	xiv
Class I laser product	xv
Rack safety	xvi
Power cords	xvii
End of life (EOL) plan	xviii

Environmental notices	xix
--	------------

Preface	xxi
--------------------------	------------

Introduction	1
Drive features	1
Front panel of the drive	2
Rear panel of the drive	2
Drive performance	3
Cartridge compatibility	3
Speed matching	3
Channel calibration	4
Data cartridge capacity scaling	4
Encryption	4
Inhibiting firmware down-leveling	5
SAS interface	5
Supported servers and operating systems	5
Supported device drivers	5
Ethernet port	5
IBM Spectrum Archive	6
Specifications	6

Installation	7
Avoiding drive damage	7
Unpacking the drive	7
Verifying the shipment	8
Installing the rack mount kit (optional)	8
Inspecting the power cord and outlet	8
Positioning the tape drive	8
Installing the SAS host adapter card (if required)	9
Connecting the SAS interface cable	9
Connecting power	10
Running drive diagnostics	10
Installing device drivers	10
Configuring the tape drive to a server/host	10

Updating firmware	10
Registering for My Support	12

Operations	13
Operating modes	13
Power button	13
Single-character display (SCD)	13
Status lights	14
Unload button	16
Inserting a tape cartridge	17
Removing a tape cartridge	18
Mid-tape recovery	18
Cleaning the drive head	19
Cleaning the tape drive	19
Tape Drive Status web page	19
Diagnostic and maintenance functions	21
Entering Maintenance mode	23
Exiting Maintenance mode	23
Function code 0: Maintenance mode	23
Function code 1: Run drive diagnostics	24
Function code 2: Update drive firmware from FMR tape	24
Function code 3: Create FMR tape	25
Function code 4: Force a drive dump	25
Function code 5: Copy drive dump	26
Function code 6: Run host interface wrap test	27
Function code 7: Run RS-422 wrap test	28
Function code 8: Unmake FMR tape	28
Function code 9: Display error code log	29
Function code A: Clear error code log	29
Function code C: Insert cartridge into tape drive	29
Function code E: Test cartridge & media	29
Function code F: Write performance test	30
Function code H: Test head	31
Function code J: Fast read/write test	32
Function code L: Load/unload test	32
Function code P: Post Error Reporting enabled	33
Function code U: Post Error Reporting disabled	34
Tape drive diagnostic and maintenance web page	34

Ultrium media	37
Data cartridges	37
Cartridge Compatibility	39
Capacity Scaling	39
WORM (Write Once, Read Many) cartridges	39
WORM media	40
Data security on WORM media	40
WORM media errors	40
WORM requirements	40
Cleaning cartridge	40
Cartridge memory chip (LTO-CM)	41
Bar code label	41
Guidelines for bar code labels	43
Write-Protect switch	43
Handling the cartridges	44

Providing training	44
Ensuring proper packaging	44
Proper acclimation and environmental conditions	45
Completing a thorough inspection.	46
Handling the cartridge carefully	46
Examples of cartridge problems	47
Repositioning or reattaching a leader pin	47
Repositioning a leader pin	47
Reattaching a leader pin	49
Environmental and shipping specifications for tape cartridges	52
Disposing of tape cartridges	53
Ordering media supplies	54
Ordering bar code labels	57

Troubleshooting. 59

Procedure 1: Determining firmware level and capturing drive dump	59
Procedure 2: Inspecting a cartridge for damage	60
Procedure 3: Checking SAS host connections	61
Procedure 4: Verifying host interface communications	61
Resolving problems reported by the server	61
Resolving media-related problems.	62
Pre-call checklist.	62
Replacing the tape drive	63

Appendix A. Error codes and messages 65

Appendix B. TapeAlert flags 71

Appendix C. Ordering optional features, replacement parts, and power cords 73

Appendix D. Installing a 19-inch rack mount kit (optional) 79

Rack safety	79
Verify kit contents	80
Tools required	80
Installing the shelf	80
Removing the shelf from the rack	81

Appendix E. Information for trained service personnel 83

Removing the internal drive.	83
Step 1. Removing the cover	83
Step 2. Removing the internal drive	85
Manually removing a tape cartridge	86
Before you begin	87
Recommended tools	87
Beginning procedure	87
Tape spooled off supply reel.	88
Tape pulled from or broken near leader pin	90
Tape broken in mid-tape	91
Tape tangled along tape path	92
No apparent failure or damage to tape	93
Replacing the internal drive	96
Step 1. Replacing the internal drive	96
Step 2. Replacing the cover	96

Notices 97

Trademarks	99
Electronic emission notices	100
Federal Communications Commission Statement	100
Industry Canada Compliance Statement	100
European Union Electromagnetic Compatibility Directive	100
Australia and New Zealand Class A Statement	100
Germany Electromagnetic Compatibility Directive	101
People's Republic of China Class A Statement	101
Taiwan Class A Statement	102
Taiwan Contact Information	102
Japan Voluntary Control Council for Interference Class A Statement	102
Japan Electronics and Information Technology Industries Association Statement	102
Korean Electromagnetic Interference (EMI) Statement	103
Russia Electromagnetic Interference Class A Statement	103

Glossary 105

Index 115

Figures

1. AC grounding diagram (50 Hz and 60 Hz)	xv	22. Attaching the leader pin attach tool to the cartridge	50
2. View of the drive	1	23. Winding the tape out of the cartridge	51
3. Front panel element descriptions	2	24. Removing the C-clip from the leader pin	51
4. Drive rear panel element descriptions - dual SAS ports	2	25. Attaching the leader pin to the tape	52
5. Example of connecting one SAS device to the server	9	26. Flowchart for Analyzing Maintenance Problems	59
6. Example of connecting the SAS device to two servers	9	27. RID tag on rear panel	63
7. Inserting a cartridge into the drive	18	28. Types of receptacles	77
8. Drive Status web page	20	29. Front view of shelf attached to rack rails	81
9. Drive Status web page - topic details	21	30. Rear view of shelf with cables attached to rack rails with tie wraps	81
10. Tape drive diagnostic page	35	31. Removing the screws that secure the cover and internal drive	84
11. The IBM LTO Ultrium data cartridge	37	32. Removing cables from the internal drive	85
12. Ultrium Data and WORM Tape Cartridges	40	33. Releasing the drive from the chassis	86
13. Sample bar code label on the LTO Ultrium 8 Tape Cartridge	43	34. Sliding the drive forward	86
14. Setting the write-protect switch	44	35. Removing the bezel and the cover from the internal drive	88
15. Tape cartridges in a Turtlecase	45	36. Rewinding tape into cartridge	89
16. Double-boxing tape cartridges for shipping	45	37. Drive with cover removed to reveal gear train	90
17. Checking for gaps in the seams of a cartridge	46	38. Leader block assembly (LBA)	91
18. Leader pin in the incorrect and correct positions	48	39. Rewinding tape into cartridge	92
19. Placing the dislodged leader pin into the correct position	48	40. Rewinding tape into cartridge	93
20. Rewinding the tape into the cartridge	49	41. Rewinding tape into cartridge	94
21. Leader pin reattachment kit	50	42. Drive with cover removed to reveal gear train	95
		43. Leader block assembly (LBA)	95

Tables

1. Performance characteristics.	3	12. Cartridges and VOLSERs compatible with the Ultrium Tape Drives	42
2. Performance parameters.	4	13. Location of the write-protect switch	44
3. Specifications	6	14. Environment for operating, storing, and shipping the LTO Ultrium Tape Cartridge	53
4. Meaning of status lights and single-character display (SCD).	14	15. Media supplies	54
5. Functions that the Unload Button completes	16	16. Authorized suppliers of custom bar code labels	57
6. Diagnostic and maintenance functions	22	17. Error codes on the Single-character Display	65
7. Cartridge types and colors	37	18. Optional features.	73
8. Cartridge data capacity and recording formats	38	19. Replacement parts	73
9. Nominal cartridge life: Load/unload cycles	39	20. Power cords	74
10. Ultrium data cartridge compatibility with Ultrium tape drive	39		
11. Bar code label requirements for Ultrium tape drives and libraries	41		

Safety notices

Observe the safety notices when using this product. These safety notices contain danger and caution notices. These notices are sometimes accompanied by symbols that represent the severity of the safety condition.

Most danger or caution notices contain a reference number (Dxxx or Cxxx). Use the reference number to check the translation in the *IBM Systems Safety Notices, G229-9054* manual.

The sections that follow define each type of safety notice and give examples.

Danger notice





A danger notice calls attention to a situation that is potentially lethal or extremely hazardous to people. A lightning bolt symbol always accompanies a danger notice to represent a dangerous electrical condition. A sample danger notice follows:



DANGER: An electrical outlet that is not correctly wired could place hazardous voltage on metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock. (D004)

Caution notice

A caution notice calls attention to a situation that is potentially hazardous to people because of some existing condition, or to a potentially dangerous situation that might develop because of some unsafe practice. A caution notice can be accompanied by one of several symbols:

If the symbol is...	It means...
	A generally hazardous condition not represented by other safety symbols.
	This product contains a Class II laser. Do not stare into the beam. (C029) Laser symbols are always accompanied by the classification of the laser as defined by the U. S. Department of Health and Human Services (for example, Class I, Class II, and so forth).
	A hazardous condition due to mechanical movement in or around the product.
	This part or unit is heavy but has a weight smaller than 18 kg (39.7 lb). Use care when lifting, removing, or installing this part or unit. (C008)

Sample caution notices follow:

Caution

The battery is a lithium ion battery. To avoid possible explosion, do not burn. Exchange only with the IBM-approved part. Recycle or discard the battery as instructed by local regulations. In the United States, IBM has a process for the collection of this battery. For information, call 1-800-426-4333. Have the IBM part number for the battery unit available when you call. (C007)

Caution

The system contains circuit cards, assemblies, or both that contain lead solder. To avoid the release of lead (Pb) into the environment, do not burn. Discard the circuit card as instructed by local regulations. (C014)

Caution

When removing the Modular Refrigeration Unit (MRU), immediately remove any oil residue from the MRU support shelf, floor, and any other area to prevent injuries because of slips or falls. Do not use refrigerant lines or connectors to lift, move, or remove the MRU. Use handholds as instructed by service procedures. (C016)

Caution

Do not connect an IBM control unit directly to a public optical network. The customer must use an additional connectivity device between an IBM control unit optical adapter (that is, fibre, ESCON, FICON[®]) and an external public network . Use a device such as a patch panel, a router, or a switch. You do not need an additional connectivity device for optical fibre connectivity that does not pass through a public network.


Completing the safety inspection procedure

Before you service the unit, complete the safety inspection procedure:

1. Stop all activity on the host bus.
2. Turn off the power to the tape drive.
3. Disconnect the host interface cable.
4. Unplug the tape drive's power cord from the electrical outlet.
5. Check the tape drive's power cord for damage, such as a pinched, cut, or frayed cord.
6. Check the tape drive's host interface cable for damage.
7. Check the cover of the tape drive for sharp edges, damage, or alterations that expose its internal parts.
8. Check the cover of the tape drive for proper fit. It should be in place and secure.
9. Check the product label on the tape drive to make sure that it matches the voltage at your outlet.

Tape drive ac grounding inspection

1. Power off the drive.
2. Disconnect all cables.
3. See Figure 1 on page xv which is provided for reference only. Disconnect the power cord from its source.
4. Inspect the power cable for visible cracks, wear, or damage.



Legend:

- XX External tooth lock washer
Green/yellow ground wire terminated to chassis or ground
- ⊕ Green/yellow ground wire terminated with slip-on spade terminal
- XXX Redundant ground path to frame
- XXX External tooth lock washer

at1400040

Figure 1. AC grounding diagram (50 Hz and 60 Hz)

Class I laser product

Before the library is used, review the following laser safety information.

The product might contain a laser assembly that complies with the performance standards set by the US Food and Drug Administration for a Class I laser product. Class I laser products do not emit hazardous laser radiation. The product has the necessary protective housing and scanning safeguards to ensure that laser radiation is inaccessible during operation or is within Class I limits. External safety agencies reviewed the product and obtained approvals to the latest standards as they apply.

Rack safety

The following general safety information must be used for all rack-mounted devices.

DANGER



- Always lower the leveling pads on the rack cabinet.
- Always install stabilizer brackets on the rack cabinet.
- To avoid hazardous conditions because of uneven mechanical loading, always install the heaviest devices in the bottom of the rack cabinet. Always install servers and optional devices, starting from the bottom of the rack cabinet.
- Rack-mounted devices are not to be used as a shelf or workspace. Do not place any object on top of rack-mounted devices.
- Each rack cabinet might have more than one power cord. Be sure to disconnect all power cords in the rack cabinet before you service any device in the rack cabinet.
- Connect all devices that are installed in a rack cabinet to power devices installed in the same rack cabinet. Do not plug a power cord from a device that is installed in one rack cabinet into a power device that is installed in a different rack cabinet.
- An electrical outlet that is not correctly wired might place hazardous voltage on the metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock.

CAUTION:



- Do not install a unit in a rack where the internal rack ambient temperatures might exceed the manufacturer's recommended ambient temperature for all your rack-mounted devices.
- Do not install a unit in a rack where the air flow is compromised. Ensure that air flow is not blocked or reduced on any side, front, or back of a unit that is used for air flow through the unit.
- Consideration must be given to the connection of the equipment to the supply circuit so that overloading of the circuits does not compromise the supply wiring or overcurrent protection. To provide the correct power connection to a rack, refer to the rating labels on the equipment in the rack to determine the total power requirement of the supply circuit.
- (For sliding drawers) Do not pull out or install any drawer or feature if the rack stabilizer brackets are not attached to the rack. Do not pull out more than one drawer at a time. The rack might become unstable if you pull out more than one drawer at a time.
- (For fixed drawers) This drawer is a fixed drawer and must not be moved for servicing unless specified by the manufacturer. Attempting to move the drawer partially or out of the rack might cause the rack to become unstable or cause the drawer to fall out of the rack.

(R001)

CAUTION:



Removing components from the upper positions in the rack cabinet improves rack stability during relocation. Follow these general guidelines whenever you relocate a populated rack cabinet within a room or building:

- Reduce the weight of the rack cabinet by removing equipment, starting at the top of the rack cabinet. When possible, restore the rack cabinet to the configuration of the rack cabinet as you received it. If this configuration is not known, you must do the following steps.
 - Remove all devices in the 32U position and above.
 - Ensure that the heaviest devices are installed in the bottom of the rack cabinet.
 - Ensure that there are no empty U-levels between devices that are installed in the rack cabinet below the 32U level.
- If the rack cabinet you are relocating is part of a suite of rack cabinets, detach the rack cabinet from the suite.
- Inspect the route that you plan to take to eliminate potential hazards.
- Verify that the route that you choose can support the weight of the loaded rack cabinet. Refer to the documentation that comes with your rack cabinet for the weight of a loaded rack cabinet.
- Verify that all door openings are at least 760 x 2032 mm (30 x 80 in.).
- Ensure that all devices, shelves, drawers, doors, and cables are secure.
- Ensure that the four leveling pads are raised to their highest position.
- Ensure that no stabilizer bracket is installed on the rack cabinet during movement.
- Do not use a ramp that is inclined at more than 10 degrees.
- When the rack cabinet is in the new location:
 - Lower the four leveling pads.
 - Install stabilizer brackets on the rack cabinet.
 - If you removed any devices from the rack cabinet, repopulate the rack cabinet from the lowest position to the highest position.
- If a long-distance relocation is required, restore the rack cabinet to the configuration of the rack cabinet as you received it. Pack the rack cabinet in the original packaging material, or equivalent. Also, lower the leveling pads to raise the casters off the pallet and bolt the rack cabinet to the pallet.

(R002)

Power cords

For your safety, IBM provides a power cord with a grounded attachment plug to use with this IBM product. To avoid electrical shock, always use the power cord and plug with a properly grounded outlet.

IBM power cords used in the United States and Canada are listed by Underwriter's Laboratories (UL) and certified by the Canadian Standards Association (CSA).

For units intended to be operated at 115 volts: Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a parallel blade, grounding-type attachment plug rated 15 amperes, 125 volts.

For units intended to be operated at 230 volts (U.S. use): Use a UL-listed and CSA-certified cord set consisting of a minimum 18 AWG, Type SVT or SJT, three-conductor cord, a maximum of 15 feet in length and a tandem blade, grounding-type attachment plug rated 15 amperes, 250 volts.

For units intended to be operated at 230 volts (outside the U.S.): Use a cord set with a grounding-type attachment plug. The cord set should have the appropriate safety approvals for the country in which the equipment will be installed.

IBM power cords for a specific country or region are usually available only in that country or region.

End of life (EOL) plan

This product is a purchased unit. Therefore, it is the sole responsibility of the purchaser to dispose of it in accordance with local laws and regulations at the time of disposal.

This product contains recyclable materials. The materials should be recycled where facilities are available and according to local regulations. In some areas IBM provides a product take-back program that ensures proper handling of the product. For more information, contact your IBM representative.

Environmental notices

The environmental notices that apply to this product are provided in the *Environmental Notices and User Guide*, Z125-5823-xx manual. A copy of this manual is located on the publications CD.

Preface

Use this guide to install and use the IBM TS2280 tape drive.

“Introduction” on page 1 describes the product, supported servers, operating systems, and device drivers, and lists hardware specifications.

“Installation” on page 7 gives unpacking, set up, and configuration information.

“Operations” on page 13 describes the **Power** button, **Unload** button, and Status lights and explains the function of the Single-character Display. It gives instruction on inserting and removing a tape cartridge, describes methods of updating drive firmware, and explains how to clean the tape drive. It also lists diagnostic and maintenance functions.

“Ultrium media” on page 37 describes the types of tape cartridges to use and defines the conditions for storing and shipping them. It also describes how to handle the cartridges, how to set a cartridge's write-protect switch, and how to order more cartridges.

“Troubleshooting” on page 59 gives tips for solving problems with the drive.

Appendix A, “Error codes and messages,” on page 65 describes the error and informational codes that display on the single-character display.

Appendix B, “TapeAlert flags,” on page 71 describes where to find information about TapeAlert messages that are supported and that can assist with problem determination.

Appendix C, “Ordering optional features, replacement parts, and power cords,” on page 73 lists parts and supplies and provides information about the power cords that are used in different countries or regions.

Appendix D, “Installing a 19-inch rack mount kit (optional),” on page 79 gives the procedure for installing a 19-inch rack mount kit.

Appendix E, “Information for trained service personnel,” on page 83 gives the procedure for removing a tape cartridge that does not eject from the drive and other servicing procedures.

Related publications

- *IBM Ultrium Tape Drive Quick Reference*, GC27-2278 illustrates how to install the drive.
- *IBM LTO Ultrium Tape Drive SCSI Reference*, GA32-0450, gives information about the supported SCSI commands and protocol that govern the behavior of the SCSI interface for LTO drives. The SCSI reference also includes information about the TapeAlert flags that are supported.
- *IBM Tape Device Drivers Installation and User's Guide*, GC27-2130, provides instructions for attaching IBM supported hardware to open-systems operating systems. It indicates what devices and levels of operating systems are supported. It also gives the requirements for adapters, and tells how to configure servers to use the device driver with the Ultrium family of devices. You can obtain this reference at: <https://www-945.ibm.com/support/fixcentral>
- *IBM Tape Device Drivers Programming Reference*, GA32-0566, supplies information to application developers who want to integrate their open-systems applications with IBM supported Ultrium hardware. The reference contains information about the application programming interfaces (APIs) for each of the various supported operating-system environments. You can obtain this reference at the website <https://www-945.ibm.com/support/fixcentral>.
- *IBM Translated Safety Notices*, 96P0851, provides translation of danger and caution notices.

Introduction

The IBM TS2280 Tape Drive is a high-performance, high-capacity data-storage device that is designed to back up and restore open systems applications. It is the eighth generation in the Ultrium series of products. It is available with a Serial Attached SCSI interface (SAS). This model incorporates the Linear Tape-Open (LTO) IBM Ultrium 8 Half Height Tape Drive.




Figure 2. View of the drive

Drive features

The drive offers these features:

- Native storage capacity of 12000 GB per cartridge (30000 GB at 2.5:1 compression) with Ultrium 8 cartridges
- Maximum native data transfer rate of up to 300 MB per second
- Burst data transfer rate of 600 MB per second
- Dual port 6 Gbps Serial Attached Small Computer Systems Interface (SAS)
- Half height form factor
- Support for WORM (Write Once Read Many) on WORM cartridge types
- Read and write compatibility with Ultrium 7 media.
- 1 GB read-and-write cache
- Support for encryption on Ultrium 7, and Ultrium 8 tape cartridges
- Single Character Display (SCD) operator panel
- Ready, Fault, and Encryption status lights
- Maintenance Mode functions
- 1 Gbps Ethernet port for drive status and service
- IBM Spectrum Archive (LTFS) capable

Front panel of the drive




Figure 3. Front panel element descriptions

- | | | | |
|----------|--------------------------|----------|--------------------------------|
| 1 | Cartridge unload button | 4 | Fault light (amber) |
| 2 | Ready light (green) | 5 | Single Character Display (SCD) |
| 3 | Encryption light (white) | 6 | SCD dot |
| | | 7 | Drive power button |

Rear panel of the drive




Figure 4. Drive rear panel element descriptions - dual SAS ports

- | | |
|----------|--|
| 1 | Power receptacle |
| 2 | Fan vent |
| 3 | SAS connectors |
| 4 | Ethernet connector (for drive status and service only) |

Drive performance

If you run applications that are highly dependent on tape-processing speed, take advantage of the significant performance improvements that are provided by this tape drive.

Table 1. Performance characteristics

Performance Characteristics	TS2280 Tape Drive
Native data rate	300 MB/s (with Ultrium 8 media)
Maximum sustained data rate (at maximum compression)	600 MB/s
Burst data rate	600 MB/s
Nominal load-to-ready time	12 seconds
Nominal unload time.	17 seconds
Average rewind time	60 seconds
Note: All sustained data rates depend on the capabilities of the interconnect.	

By using the built-in data-compression capability of the tape drive, greater data rates than the native data transfer rate are achieved. However, the actual throughput is a function of many components, such as the host system processor, disk data rate, block size, data compression ratio, SAS bus capabilities, and system or application software.

Cartridge compatibility

The TS2280 uses the IBM LTO Ultrium 12000 GB data cartridge and is compatible with the cartridges of its predecessor, the IBM Ultrium Tape Drive Generation 7. The drive completes these functions:

- Reads and writes Ultrium 8 cartridges to Ultrium 8 format, including WORM and Data Encryption.
- Reads and writes Ultrium 7 cartridges to Ultrium 7 format, including WORM and Data Encryption.
- Does not read or write Ultrium 6, Ultrium 5, Ultrium 4, Ultrium 3, Ultrium 2, and Ultrium 1 cartridges.

The drive reads tapes that are written by other licensed Ultrium 7, and 8 drives, and writes to tapes that are read by other licensed Ultrium 7 and 8 drives.

In addition to using the IBM LTO Ultrium Data Cartridge with up to 12000 GB capacity, the drive offers read/write capability for certified LTO Ultrium 7 and Ultrium 8 tape cartridges.

Speed matching

To improve system performance, the drive uses a technique that is called *speed matching* to dynamically adjust its native (uncompressed) data rate to the slower data rate of a server. With speed matching, the drive operates at different speeds when it is reading or writing the Ultrium 7 or later cartridge format. Native data rates are shown in the table.

Table 2. Performance parameters

	Ultrium Generation Media	
	Generation 8 media	Generation 7 media
Speed matching data rates (MB/sec)	365.0	306.0
	341.0	287.52
	318.0	268.56
	306.4	250.66
	273.0	231.86
	249.5	213.06
	226.0	194.26
	203.0	175.46
	180.0	157.67
	157.5	138.52
	135.0	120.11
	112.0	101.46

If the server's net (compressed) data rate is between two of the preceding native data rates, the drive calculates the appropriate data rate at which to operate. Speed matching dramatically reduces backhitch, the condition that occurs when a tape stops, reverses, and restarts motion. A backhitch is usually the result of a mismatch between the data rates of the server and the drive.

Channel calibration

System performance is further optimized by a feature that is called *channel calibration*, in which the drive automatically customizes each read/write data channel to compensate for variations in such things as the recording channel's transfer function, the media, and characteristics of the drive head.

Data cartridge capacity scaling

The **SET CAPACITY SCSI** command enables a customer to capacity scale a data cartridge to enable faster random access. As an example, a customer can capacity scale a data cartridge to 20% of its normal length that improves the average access time by almost a factor of 5. However, it also reduces the native capacity of the tape to 1200 GB.

Encryption

The IBM TS2280 Tape Drive supports host Application Managed Encryption (AME), with T10 encryption methods. Data encryption is supported by LTO Ultrium 4 and later data cartridges only.

The encryption-enabled drive contains the necessary hardware and firmware to encrypt and decrypt host tape application data. Encryption policy and encryption keys are provided by the host application. A drive digital certificate is installed at manufacturing time. Each drive receives a unique serial number and certificate. The T10 Application can validate each drive instance by checking the drive's digital certificate.

Application-managed encryption is supported on AIX®, Windows Server, Linux, and Solaris. Encryption requires current device drivers, available on the website <https://www-945.ibm.com/support/fixcentral>.

For details, see the *IBM Tape Device Drivers Encryption Support* documentation, and the *IBM LTO Ultrium Tape Drive SCSI Reference* documentation.

Inhibiting firmware down-leveling

The drive provides the capability to prevent loading and installing drive microcode by way of a Field Microcode Replace (FMR tape) if the firmware level contained in the FMR tape is older than the code level already installed. This option is controlled by the host application. No checking is done if the firmware level is loaded by way of the host interface or the library interface.

SAS interface

The drive has a dual port 6 Gbps SAS (Serial Attached SCSI) host interface.

A drive with a SAS interface can be linked directly to controllers. SAS is a performance improvement over traditional SCSI because SAS enables multiple devices (up to 128) of different sizes and types to be connected simultaneously with thinner and longer cables; its full-duplex signal transmission supports 6.0 Gb/s. In addition, SAS drives can be hot-plugged.

SAS drives auto-negotiate speed. There are no configurable topologies thus no feature switches associated with SAS.

Physical characteristics

The drive contains a dual port, SFF-8088 SAS connector. A list of compatible cables is shown in Appendix C, "Ordering optional features, replacement parts, and power cords," on page 73.

Supported servers and operating systems

To determine the latest supported attachments, visit the web at <http://www.ibm.com/storage/lto> and look for the System Storage interoperability information. For specific instructions about attaching the drive, see "Installation" on page 7.

Supported device drivers

Device drivers enable the drive to interact with various servers. To properly install an IBM device driver (if required), refer to the *IBM Tape Device Drivers Installation and User's Guide*. For applications that use other device drivers, see the application's documentation to determine which drivers to use.

IBM maintains the levels of device drivers and driver documentation for the drive on the Internet. You can access this material at the website <http://www.ibm.com/support/fixcentral>.

Note: If you do not have Internet access and you need information about device drivers, contact your sales representative.

Note: The device driver for System i[®] servers is included in the OS/400[®] operating system.

Ethernet port

The IBM TS2280 tape drive has a single 1 Gbps Ethernet port on the rear panel, with an RJ45 connector. The Default IP address is **169.254.0.3**, but the drive's IP address can be changed as needed. Refer to ITDT to see how to this change is made.

The Ethernet port is used only for monitoring drive status and servicing the drive, not for data transmission.

IBM Spectrum Archive

The IBM Spectrum Archive linear tape file system (previously known as LTFS) is a file system that works with LTO Generation tape technology to access data stored on an IBM tape cartridge.

IBM Spectrum Archive uses the file system's format and resources of the operating system (OS) on which it is running to graphically display the contents of a tape cartridge in the OS's graphical user interface (GUI) format; typically a folder/tree structure. With the host operating system's graphical File Manager, reading data on an LTO tape cartridge is as easy as dragging and dropping. Users can run any application that is designed for disk files against tape data without concern for the fact that the data is physically stored on tape.

Specifications

Specifications for the tape drive. Specifications for tape cartridges are given in "Environmental and shipping specifications for tape cartridges" on page 52.

Table 3. Specifications

Physical Specifications			
Specification	Dimensions		
Width	213 mm (8.4 in.)		
Length	332 mm (13.1 in.)		
Height	58 mm (2.3 in.)		
Weight	4.3 kg (9.4 lbs.)		
Power Specifications			
AC line voltage	100 - 240 Vac		
Line frequency	50 - 60 Hz, auto-ranging		
Line current at 100 Vac	0.48 A		
Line current at 240 Vac	0.20 A		
Other Specifications			
Maximum altitude	3048 m (10,000 ft)		
Maximum altitude for shipping	12192 m (40,000 ft)		
Environmental Specifications			
Environmental Factor	Operating	Storage	Shipping
Temperature	10 - 38°C (50 - 100°F)	-40 to 60°C (-40 to 140°F)	-40 to 60°C (-40 to 140°F)
Relative humidity	20 - 80%	10 - 90%	10 - 90%
Maximum wet bulb temperature	26°C(79°F)	Non-condensing	Non-condensing

Installation

This is a customer setup unit. It is the customer's responsibility to install this product.

Installation involves the following steps:

1. "Avoiding drive damage"
2. "Unpacking the drive"
3. "Verifying the shipment" on page 8
4. "Installing the rack mount kit (optional)" on page 8
5. "Inspecting the power cord and outlet" on page 8
6. "Positioning the tape drive" on page 8
7. "Installing the SAS host adapter card (if required)" on page 9
8. "Connecting the SAS interface cable" on page 9
9. "Connecting power" on page 10
10. "Running drive diagnostics" on page 10
11. "Installing device drivers" on page 10
12. "Configuring the tape drive to a server/host" on page 10
13. "Updating firmware" on page 10
14. "Registering for My Support" on page 12

Avoiding drive damage

To avoid static electricity damage when the drive is handled, use the following precautions:

- Limit your movement. Movement can cause static electricity to build around you.
- Always handle the drive carefully. Never touch exposed circuitry.
- Prevent others from touching the drive.
- Before you unpack and install the drive into an enclosure, touch its static-protective packaging to an unpainted metal surface on the enclosure for at least 2 seconds. This procedure reduces static electricity in the packaging and your body.
- When possible, remove the drive from its static-protective packaging and install it directly into an enclosure without setting it down. When this action is not possible, place the drive 's packaging on a smooth, level surface and place the drive on the packaging.
- Do not place the drive on the cover of the enclosure or on any other metal surface.

Unpacking the drive

Unpack the drive and store the packaging for future moves or shipping.

Attention: If you return the unit for service, ship it in its original or equivalent packing material, or the warranty might be invalidated.

1. Inspect the unit for shipping damage. If there is damage, do not install the unit, and report the damage immediately. Contact your place of purchase.
2. Locate the label on the bottom panel of the unit with the machine type, model number, and serial number of the unit. Make a note of these numbers and store them in an easily accessible place. If you must contact Technical Support, you are asked for these numbers.

Verifying the shipment

Ensure that the following items are included in the shipment:

- Power cord (For the appropriate cord for your country or region, see Appendix C, “Ordering optional features, replacement parts, and power cords,” on page 73)
- IBM LTO Ultrium Cleaning Cartridge
- Single-connector SAS wrap tool
- Optional Rack Mount kit
- The *IBM TS2280 Tape Drive Quick Reference* (GC27-2276-02)
- The *IBM TS2280 Tape Drive Setup, Operator, and Service Guide* SC27-4649-00
- Documentation CD (includes library documentation, translated safety information, and translated warranty information).
- SAS or USB cables are not part of the ship group. They must be ordered separately.

Installing the rack mount kit (optional)

Refer to Appendix D, “Installing a 19-inch rack mount kit (optional),” on page 79. If you did not order the optional kit, proceed to “Inspecting the power cord and outlet.”

If you ordered a 24-inch rack mount kit, refer to the installation instructions included in the kit.

Inspecting the power cord and outlet

1. Inspect the power cord plug to ensure that it matches the power receptacle. If it does not match, see “Power cords” on page 74 to determine the appropriate power cord.
2. Ensure that all associated electrical outlets are properly grounded and that the circuit breaker is turned on.



DANGER

An electrical outlet that is not correctly wired could place hazardous voltage on metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock. (D004)

Positioning the tape drive

Position the unit so it is convenient to the server. The only restrictions are the length of the power cord and the length of the cable to the server. Recommended locations are

- Away from high-traffic areas, especially if the floor is carpeted.
- Out of printer or copy rooms to avoid toner and paper dust. Do not store paper supplies next to any unit.
- Away from moving air, such as doorways, open windows, fans, and air conditioners.
- Off the floor.
- In a horizontal position.
- Where the tape cartridge can be easily inserted.

The unit should not be stacked. Do not place anything on top of the unit.

Installing the SAS host adapter card (if required)

If no other devices are attached to your server, a SAS host adapter might need to be installed in the server. To install an adapter, refer to the instructions that accompany it, also to the section about host adapter installation in your server's documentation. For a list of supported adapters and required interposers, visit the web at <http://www.ibm.com/storage/lto>.

Connecting the SAS interface cable

Each tape drive is required to have a dedicated bus to the initiator, referred to as point-to-point connection. SAS architecture does not support multiple tape drives connected to a single host adapter port. The maximum SAS cable length that can be used to connect the host adapter to the tape drive is 5.5 m.

To connect the cable:

1. Ensure that the tape drive is powered OFF.
2. Since there are several types of SAS connectors, verify that the SAS cable has the correct connectors for the SAS host adapter and for the tape drive.
3. The tape drive has two SAS ports and can be connected to two servers. Refer to the appropriate figure that represents your configuration for cabling information (see Figure 5 or Figure 6). Then, connect the SAS cables to SAS host adapters and to the tape drive as shown.




Figure 5. Example of connecting one SAS device to the server

- | | | | |
|----------|---------------|----------|------------------|
| 1 | Tape drive | 4 | SAS host adapter |
| 2 | SAS connector | 5 | Server |
| 3 | SAS cable | | |




Figure 6. Example of connecting the SAS device to two servers

- | | | | |
|----------|------------|----------|------------------|
| 1 | Tape drive | 4 | SAS host adapter |
|----------|------------|----------|------------------|

- 2** SAS connector
- 3** SAS cables

- 5** Servers

4. Ensure that the host adapter and the server are configured correctly for a SAS bus operation. Refer to the host adapter and server documentation for instructions.
5. If the power cord is already installed, turn power to the tape drive ON.

Connecting power

1. If the power cord is already installed, skip to step 3.
2. Plug the power cord into the rear panel (see Figure 4 on page 2), then plug the other end into a grounded electrical outlet.
3. Power on the unit by pressing **Power**. The POST runs, which check all hardware except the drive head. During the POST, the Single-character Display (SCD) flashes several segmented characters. Each segmented character represents a test that is completed during the POST. When the POST finishes, the SCD momentarily lights all segmented characters and then goes blank.

Running drive diagnostics

Run the Standalone Diagnostic procedure. See “Function code 1: Run drive diagnostics” on page 24 for instructions.

Installing device drivers

A device driver is firmware that enables the tape drive to interact with various servers. Refer to “Supported device drivers” on page 5 for instructions on downloading the latest device drivers.

If you intend to use the tape drive with a commercial software application, refer to that application's installation instructions to install the device driver and configure the tape drive.

If you do not intend to use the tape drive with a commercial software application, refer to the *IBM Ultrium Device Drivers Installation and User's Guide*.

Configuring the tape drive to a server/host

1. Ensure that the tape drive is powered on.
2. To configure the tape drive, refer to the documentation for your server/host and application software.

Updating firmware

Attention: When firmware is updated, do not power off the drive until the update is complete, or the firmware might be lost.

It is the customer's responsibility to ensure that this drive has the current firmware. Periodically check for updated levels of drive firmware by going to the web at <http://www.ibm.com/support/fixcentral>. The drive firmware can be downloaded from this website. Update drive firmware with:

- The host interface
- The ITDT tool
- A field microcode replacement (FMR) tape cartridge
- The Ethernet interface

For instructions on obtaining a new firmware image, go to <http://www.ibm.com/support/fixcentral>. To update the firmware, refer to the following sections.

Updating firmware through the host interface

When drive firmware is updated with the host interface, the procedure varies depending on whether your server uses an IBM tape device driver or a non-IBM tape device driver (such as a driver from Sun, Hewlett-Packard, or Microsoft).

For instructions about updating firmware from a server that uses an IBM tape device driver, refer to the *IBM Ultrium Device Drivers Installation and User 's Guide*.

To update firmware from a server that uses a non-IBM tape device driver, refer to the documentation for that device driver.

ITDT firmware update, dump retrieval and library/drive test tool

ITDT is a tool with multiple functional capabilities and is a quick, convenient, and efficient method for both drive and library firmware updates. As a note, both drive and library memory dump retrievals can be completed by the tool as well.

Some of the capabilities of this tool:

- Firmware update capability to all IBM LTO Tape Drive and Tape Library products.
- The tool does not require any special device drivers.
- The tool is available for most major platforms (Windows, AIX, Solaris, Linux, HP-UX, i5/OS).
- The tool can upload drive and library dump files.
- The tool 's primary function is thoroughly testing a drive. However, if the library is online to the server/host where the tool resides, ITDT communicates with the drive through the library to load and unload a test cartridge, exercising some library functions.
- The tool scans the host bus and finds and displays for selection all IBM LTO devices. The tool does not display and allow for selection any non-IBM device.
- Each function has a "Help" selection that explains the required syntax and a brief explanation of the particular function.
- A readme text file is posted with the .exe for a thorough explanation of initial tool download information from the web and an explanation of tool capabilities. For more information about tool usage, see the ITDT readme text file. For more information about the ITDT site, see <http://www.ibm.com/support/fixcentral>.
- The tool is available in two editions, ITDT-SE (Standard Edition) and ITDT-GE (Graphical Edition). Information about the ITDT editions can be found at <http://www.ibm.com/support/fixcentral>.


Updating the firmware with an FMR tape cartridge

Attention: A SAS drive requires a SAS firmware image. Other types of firmware images do not load on the SAS drive.

To update the drive 's firmware from an FMR tape cartridge:

1. Create an FMR tape (see "Function code 3: Create FMR tape" on page 25). A single FMR tape can be used to update multiple drives if the drives are the same drive type (for example, LTO 8) and host interface (for example, SAS).
2. Update the drive firmware (see "Function code 2: Update drive firmware from FMR tape" on page 24).

After the drive firmware is updated, the FMR tape can be used as a data cartridge by with the "Unmake FMR Tape" function (see "Function code 8: Unmake FMR tape" on page 28).

The SCD presents a series of random characters during the firmware download and update. The SCD briefly displays , then becomes blank (not lit) when the firmware download and update is complete and there are no errors. An error code is displayed if a firmware download or update error is detected. The Ready light and the Fault light flash briefly during the firmware download and update. The Ready light turns on after the firmware download and update are complete.

Updating the firmware with the Ethernet port

Note: The drive uses a limited version of FTP protocol to communicate on the Ethernet interface. It is recommended to use a simple, command-line FTP session, such as the DOS command prompt, to communicate with the drive.

1. Obtain the current drive firmware from the web.
2. Connect an Ethernet patch cable to the drive's Ethernet interface and to a computer. To meet electromagnetic immunity requirements, a shielded Ethernet cable is required.
3. Create an FTP session between the drive and the computer. The drive 's IP address: **169.254.0.3**
4. At the user prompt, type `guest` and press **Enter**.
5. At the password prompt, press **Enter**. No response is needed.
6. Type `bin` to set the communication mode to binary.
7. Type `put <firmware name>` to transfer the firmware to the drive. Replace `<firmware name>` with the actual firmware name. The drive resets automatically when the transfer is complete and the FTP session closes.
8. After the drive resets, the new firmware will be loaded on the drive.
9. Remove the Ethernet patch cable from the drive's Ethernet interface and the computer.

Registering for My Support

My Support registration provides email notification when new firmware levels are updated and available for download and installation. To register for My Support, visit the web at <http://www.ibm.com/support/mySupport>

Operations

Operating the drive involves the front panel items:

- Power button
- Single-character Display (SCD)
- SCD dot
- Ready and Fault status lights
- Unload button
- Encryption status light

Operating modes

The drive functions in these modes:

- Operation mode - functions include reading and writing data, cartridge manipulation, error reporting, and updating firmware with an FMR cartridge. For more information, see “Status lights” on page 14.
- Maintenance mode - functions include drive diagnostic, creation/unmake FMR cartridge, and drive dump manipulation (force to RAM, copy to tape, copy to flash memory, and erase flash). For more information, see “Diagnostic and maintenance functions” on page 21.

The **Unload** button is used to switch between modes. For information, see “Unload button” on page 16.

Power button

The **Power** button is a push button that turns the tape drive on or off. This button is on the front panel (see **7** in “Front panel of the drive” on page 2). When **Power** is in the off position, the primary electrical power within the enclosure is still active. To remove all electrical power to the enclosure, unplug the power cord from the receptacle at the rear of the drive.

When the unit is powered-on but idle, the Ready light (see **2** in “Front panel of the drive” on page 2) is solid green. When it is completing a function, the Ready light is flashing green.

Single-character display (SCD)

The SCD (**5** in “Front panel of the drive” on page 2) presents a single-character code for:

- Error conditions and informational messages
- Diagnostic or maintenance functions (while in maintenance mode only)

Appendix A, “Error codes and messages,” on page 65 lists the codes for error conditions and informational messages. If multiple errors occur, the code with the highest priority (represented by the lowest number) displays first. When the error is corrected, the code with the next highest priority displays, until no errors remain.

“Diagnostic and maintenance functions” on page 21 lists the single-character codes that represent diagnostic or maintenance functions. To initiate a function, the unit must be in maintenance mode.

The SCD is blank during normal operation.

SCD dot

If a drive memory dump is present while the drive is in maintenance mode, a single dot illuminates in the lower right corner of the SCD (see **6** in “Front panel of the drive” on page 2). To copy the memory dump, see “Function code 5: Copy drive dump” on page 26.

The SCD dot is on solid if the memory dump is in RAM memory. The SCD dot flashes if the memory dump is in flash memory.

The SCD dot turns off when you obtain a dump (by using ITDT or a SCSI command) or update the drive firmware.

Note: If the drive memory dump is stored in RAM memory (SCD dot on solid), the memory dump is lost when you turn OFF the power or reset the drive.

Status lights

The status lights (in “Front panel of the drive” on page 2) are light-emitting diodes (LEDs) that provide information about the state of the drive. The Ready status light is green and the Fault status light is amber, and (when lit) solid or flashing. The Encryption status light is white.

Mode	SCD	Ready LED (green)	Fault LED (amber)
Operational	Blank	On	Off
Activity (tape movement) in Operational Mode	Blank	Flashing	Off
Maintenance	Solid character	Flashing	On
Executing Maintenance Selection	Flashing character	Off	On
Error Condition	Solid character	Off	Flashing
Power on / Reset Initialization	Random segments	Off	On

Note: The white Encryption status light is on when the tape drive has a cartridge that is loaded and all data on this cartridge is encrypted (excluding the label). LTO Ultrium 8, and Ultrium 7 cartridges only.

Table 4 lists the conditions of the status lights and Single-character Display (SCD) and provides an explanation of what each condition means.

Table 4. Meaning of status lights and single-character display (SCD)

If the green Ready Status Light is...	And the amber Fault Status Light is...	And the Encryption Status Light is...	And the SCD is...	And the SCD dot is...	Meaning
Off	Off	Off	Off	Off	The drive has no power or is powered off.
On	Off	On/Off	Off	Off	The drive is powered on and in an idle state. Note: If a cartridge is loaded, the white Encryption status light is on when all the data on the cartridge is encrypted (excluding the label). LTO Ultrium 8 and Ultrium 7 cartridges only.

Table 4. Meaning of status lights and single-character display (SCD) (continued)







If the green Ready Status Light is...	And the amber Fault Status Light is...	And the Encryption Status Light is...	And the SCD is...	And the SCD dot is...	Meaning
Flashing (once per second)	Off	On/Off	Off	Off	The drive is reading from the tape, writing to the tape, rewinding the tape, locating data on the tape, loading the tape, or unloading the tape. Note: The white Encryption status light is on when all the data on the cartridge is encrypted (excluding the label). LTO Ultrium 8 and Ultrium 7 cartridges only.
Flashing (once per second)	Off	Off	Off	Off	If the drive contains a cartridge during the power-on cycle, the drive completes POST and slowly rewinds the tape. The process might take up to 13 minutes. The light stops flashing and becomes solid when the drive completes the recovery and is ready for a read or write operation. To eject the cartridge, press Unload .
Off	On	Off	Displaying an error code or Maintenance Mode Function	On/Off	The drive is displaying error codes from the error code log on the SCD. For more information, see "Function code 9: Display error code log" on page 29 and Appendix A, "Error codes and messages," on page 65.
On/Off	On/Off	On/Off	Displaying random segments/ Blank/ displaying random segments/ displaying  /Blank	On/Off	During power-on, or a drive reset, the drive front panel displays drive progress as follows: <ol style="list-style-type: none"> 1. SCD displays random segments (no Lights ON). 2. SCD displays random segments (Ready light ON). 3. SCD displays random segments (Fault light ON). 4. SCD displays [8] (Ready, Fault, Encryption, and SCD dot lights ON). 5. SCD goes blank (Ready light ON) after a successful power-on or reset. <p>If an error is detected during the power-on or reset, the tape drive posts an error code to the SCD. To determine the error, locate the code in Appendix A, "Error codes and messages," on page 65.</p>
Off	On	Off		On/Off	The drive is entering or exiting from Maintenance mode. For more information, see "Function code 0: Maintenance mode" on page 23.
Off	On	Off	Flashing selected function	On/Off	The drive is running the selected function while in Maintenance mode.

Table 4. Meaning of status lights and single-character display (SCD) (continued)

If the green Ready Status Light is...	And the amber Fault Status Light is...	And the Encryption Status Light is...	And the SCD is...	And the SCD dot is...	Meaning
Off	Flashing (once per second)	Off	Displaying error code	Off	An error occurred and the drive or media might require service, or it might require cleaning. Make a note of the code on the SCD, then see Appendix A, "Error codes and messages," on page 65 to determine the action that is required.
Off	Flashing	Off	Displaying 	Off	The drive needs cleaning.
Off	Flashing	Off	Displaying Function Code  or Flashing	Off	The drive is updating firmware. ¹ With an FMR cartridge the SCD displays a  . The SCD is off with the host interface. For more information, see "Updating firmware" on page 10.
Off	Flashing (twice per second)	Off	Off	Off	The drive detected an error and is completing a firmware recovery. It resets automatically.
Off	On	Off	Flashing 	Off	The drive is requesting a cartridge to be loaded.
Off	Flashing (twice per second)	Off	Off	On	There is a drive memory dump in flash memory.

¹ Power must not be removed from the drive until the microcode update is complete. The drive indicates that the update is complete by resetting and completing POST.

Unload button

The **Unload** button (**1** in "Front panel of the drive" on page 2) completes the following functions:

Table 5. Functions that the Unload Button completes



Unload Button Function	How to Initiate the Function
Rewind the tape into the cartridge and eject the cartridge from the drive	Press Unload . The Ready light flashes while the drive is rewinding and unloading. Note: During a rewind and eject operation, the drive does not accept host interface commands.
Place the drive in maintenance mode	Ensure that the drive is unloaded. Then, within 2 seconds, press Unload 3 times. The drive is in maintenance mode when the Ready light is flashing and  displays in the SCD. Note: While in maintenance mode, the drive does not accept host interface commands. Note: If you attempt to enter Maintenance mode with a cartridge in the drive, the drive rewinds and ejects the cartridge. Remove the cartridge and repeat the steps for entering Maintenance mode.
Scroll through the maintenance functions	While in maintenance mode, press Unload once per second to increment the display characters by one. When you reach the character of the diagnostic or maintenance function that you want (see "Diagnostic and maintenance functions" on page 21), press and hold Unload for 3 seconds.

Table 5. Functions that the Unload Button completes (continued)

Unload Button Function	How to Initiate the Function
Exit maintenance mode	<p>Press Unload once per second to increment the display character until  displays. Then, press and hold Unload for 3 seconds. Maintenance mode is exited when the Ready light is On and the SCD becomes blank.</p>
Force a drive memory dump (part of the maintenance mode)	<p>Attention: If the drive detects a permanent error and displays an error code, it automatically forces a drive memory dump (also known as a save of the firmware trace). If you force a drive memory dump, the existing memory dump is overwritten and data is lost. After you force a drive memory dump, do not turn off the power to the drive or you might lose the memory dump data.</p> <p>Choose one of these procedures:</p> <ul style="list-style-type: none"> • If the drive is in maintenance mode (Ready light is flashing and Fault light is On for Maintenance mode), refer to “Function code 4: Force a drive dump” on page 25. • If the drive is in operating mode (Ready light is On or flashing), press and hold Unload for 10 seconds. <p>If captured memory dump data exists, the drive places it into a memory dump area (for information about retrieving the data, see “Procedure 1: Determining firmware level and capturing drive dump” on page 59).</p>
Reset the drive	<p>Press and hold Unload until the drive begins the reset procedure (Fault light turns on when reset starts).</p> <p>Note: If a tape cartridge is loaded in the drive, it unloads the tape. Repeat the "Reset the drive" procedure after the tape is unloaded. The drive saves a memory dump of the current drive state, then reboots to allow communication. Do not cycle power as this action erases the contents of the memory dump.</p>

Inserting a tape cartridge

To insert a tape cartridge:

1. Ensure that the drive is powered-on.
2. Ensure that the write-protect switch on the tape cartridge is properly set (see “Write-Protect switch” on page 43).
3. Grasp the cartridge so that the write-protect switch faces you (see **1** in Figure 7 on page 18).
4. Slide the cartridge into the tape load compartment.

Note:

- a. If the cartridge is already in an ejected position and you want to reinsert it, remove the cartridge, then insert it again.
- b. If the cartridge is already loaded and you cycle the power (turn it off, then on), the tape reloads.
- c. Do not attempt to load a cartridge when the drive is in Maintenance mode until the drive requests it.




Figure 7. Inserting a cartridge into the drive

Removing a tape cartridge

To remove a tape cartridge:

1. Ensure that the drive is powered-on.
2. Press **Unload**. The drive rewinds the tape and partially ejects the cartridge. The Ready light flashes while the tape rewinds, then goes out before the cartridge partially ejects.
3. After the cartridge partially ejects, grasp the cartridge and remove it.

Important: Always remove an ejected cartridge before it is reinserted.

Whenever you unload a tape cartridge, the drive writes any pertinent information to the cartridge memory.


Mid-tape recovery


If reset occurs while a cartridge is loaded, the drive slowly rewinds the tape and ejects the cartridge. If a power cycle occurs while a cartridge is loaded, the drive slowly rewinds the tape. The drive does not automatically eject the cartridge.

The Ready light flashes and the SCD is counting down from 9 to 0, indicating the approximate cartridge rewinding status. Between the counts, the SCD displays random segments while the tape is rewinding into the cartridge. Push **Unload** to eject the cartridge when the Ready light stops flashing.

Cleaning the drive head

Attention: When the drive head is cleaned, use the IBM LTO Ultrium cleaning cartridge (see “Ordering media supplies” on page 54). You might use another LTO cleaning cartridge, but it might not meet the standards of reliability that is established by IBM.

Clean the drive head whenever  displays on the Single-character Display and the Fault light is flashing once per second. It is not recommended that you clean the drive head on a periodic basis; only when the drive requests to be cleaned.

Note: In Maintenance mode, a flashing  with the Fault light On, means to insert a cartridge, not to clean the drive head.

To clean the head, insert the cleaning cartridge into the tape load compartment (see “Front panel of the drive” on page 2). The drive completes the cleaning automatically in less than 3 minutes, then ejects the cartridge. The drive completes a short load/unload test while the cartridge is ejected. Wait for the drive to finish before the cartridge is removed.

Note: The drive automatically ejects an expired cleaning cartridge.

The IBM LTO Ultrium Cleaning Cartridge is valid for 50 uses, and then must be replaced.

Cleaning the tape drive

Clean the exterior surface of the tape drive with a damp towel. If a liquid all-purpose cleaner is used, apply it to the towel. Do not spray the tape drive.

Do not clean the interior of the tape drive; damage might result.

Tape Drive Status web page

The status of the tape drive is accessible from the tape drive’s Ethernet port. The drive status can be viewed only. The status cannot be changed from the Tape Drive Status web page. The tape drive status is available when the drive is operating or idle (the drive must be powered on).

1. Connect the host computer or a laptop to the tape drive’s Ethernet port (RJ45 connector) with an Ethernet patch cable.
2. With a web browser, connect to <http://169.254.0.3> to view the current tape drive status on an HTML web page. (If the drive’s IP address was changed, use that address instead.) The web page is static, so it must be refreshed frequently to show the latest drive status.

ULT3580-HH8 Drive YR1013000128

Text Only version (for cut and paste)

system time: 2012/06/15 09:06:39
drive time : 259 seconds

<input type="checkbox"/> Drive Information	
<input type="checkbox"/> Host Interface	
<input type="checkbox"/> Ethernet Settings	<input type="checkbox"/> VPD Encryption Settings
<input type="checkbox"/> Drive Statistics	<input type="checkbox"/> Tape Statistics
<input type="checkbox"/> Error Code Log	

a67b0032

Figure 8. Drive Status web page

The tape drive model and serial number are shown at the top of the page.

The web page is divided into sections by topic. The topics are

- Drive Information
- Host Interface
- Ethernet Settings
- VPD Encryption Settings
- Drive Statistics
- Tape Statistics (if a cartridge is loaded in the tape drive).
- Engineering Error Log

Click in the box by the title of the section to see the topic details.

ULT3580-HH8 Drive YX1013000128

Text Only version (for cut and paste)

system time: 2015/08/18 09:06:39
drive time : 259 seconds

<input checked="" type="checkbox"/> Drive Information			
Serial Number	YX1013000128	Single Character Display	
Model	ULT3580-HH7	Status Indicators	
Code Level	LTO7 F8E0	Current Time (origin)	259 seconds (Power On)
Status	idle		
<input checked="" type="checkbox"/> Host Interface			
		Port 0	Port 1
Status		unknown	unknown
WWID		50050763124B6B89	50050763128B6B89
SAS Address			
Speed		unknown	unknown
Transport Layer Retries this Power-On		0	0
<input checked="" type="checkbox"/> Ethernet Settings		<input checked="" type="checkbox"/> VPD Encryption Settings	
	Port 0	Encryption Method	None
IP Addresses (Current)	169.254.0.3/24 fe80::221:5eff:fe5:e49d/64	Key Management	Default (by Method)
MAC Address (VPD)	00:21:5E:D5:E4:9D	BOP Encryption	Disabled
Drive IP Address 1 (VPD)	not set		
Drive IP Address 2 (VPD)	not set		
DHCP (VPD)	disabled		
<input checked="" type="checkbox"/> Drive Statistics		<input checked="" type="checkbox"/> Tape Statistics	
Drive Mounts	45	Volume Serial	
Drive MB Written	280830	Tape Mounts	94
Drive MB Read	948131	Tape MB Written	1894168
Power On Hours (current / VPD)	36 / 35	Tape MB Read	1434841
<input type="checkbox"/> Error Code Log			

a67b0033

Figure 9. Drive Status web page - topic details

The web page format is changed to text mode by selecting the “Text Only version” box near the top of the web page. In text mode, the tape drive status information can be copied and pasted easily if it must be sent to support personnel.

Diagnostic and maintenance functions

The drive can:

- Run diagnostics
- Test write and read functions
- Test a suspect tape cartridge
- Update firmware
- Perform other diagnostic and maintenance functions

The drive must be in maintenance mode to perform these functions.

Attention: Maintenance functions cannot be performed concurrently with read or write operations. While in maintenance mode, the tape drive does not accept host interface commands from the server. The tape drive does accept LDI or RS-422 commands.





Table 6 on page 22 describes each diagnostic and maintenance function that the drive can perform, gives the function code which appears on the Single-character Display (SCD), and directs you to the

instructions for performing the function. It is recommended that you use a customer-supplied scratch (blank) data cartridge for diagnostic testing. The diagnostic and maintenance functions are not supported on the WORM and partitioned data tape cartridges.

Table 6. Diagnostic and maintenance functions


Function Code	Diagnostic or Maintenance Function	Instructions Location
0	Exit Maintenance Mode: Causes the drive to become available for reading and writing data.	"Function code 0: Maintenance mode" on page 23
1	Run Drive Diagnostics: Runs tests to determine whether the drive can properly load and unload cartridges, and read and write data.	"Function code 1: Run drive diagnostics" on page 24
2	Update Tape Drive Firmware from FMR Tape: Loads updated firmware from a field microcode replacement (FMR) tape.	"Function code 2: Update drive firmware from FMR tape" on page 24
3	Create FMR Tape: Copies its field microcode replacement (FMR) data to a customer-supplied scratch (blank) data cartridge.	"Function code 3: Create FMR tape" on page 25
4	Force a Drive Dump: Performs a dump of data (also known as saving a microcode trace).	"Function code 4: Force a drive dump" on page 25
5	Copy Drive Dump: Copies data from a drive dump (captured by using Function Code 4) to the beginning of a customer-supplied scratch (blank) data cartridge, copies a drive dump to flash memory, or erases a dump from flash memory.	"Function code 5: Copy drive dump" on page 26
6	Run Host Interface Wrap Test: Performs a check of the circuitry from and to the connector.	"Function code 6: Run host interface wrap test" on page 27
7	Run RS-422 Wrap Test: This test causes the drive to perform a check of the circuitry and connector for the RS-422 interface.	"Function code 7: Run RS-422 wrap test" on page 28
8	Unmake FMR Tape: Erases the FMR data on a customer-supplied scratch (blank) data cartridge and rewrite the cartridge memory on the tape. This turns the cartridge into a valid customer-supplied scratch data cartridge.	"Function code 8: Unmake FMR tape" on page 28
9	Display Error Code Log: Displays the last 10 error codes, one at a time (the codes are ordered; the most recent is presented first and the oldest (tenth) is presented last).	"Function code 9: Display error code log" on page 29
A	Clear Error Code Log: Erases the contents of the error code log.	"Function code A: Clear error code log" on page 29
C	Insert Cartridge into Tape Drive: This function cannot be selected by itself, but is a part of other maintenance functions (such as Run Tape Drive Diagnostics and Create FMR Tape) that require a tape cartridge to be loaded.	"Function code C: Insert cartridge into tape drive" on page 29
E	Test Cartridge & Media: Performs tests to ensure that a suspect cartridge and its magnetic tape are acceptable.	"Function code E: Test cartridge & media" on page 29
F	Write Performance Test: Performs tests to ensure that the drive can read from and write to tape.	"Function code F: Write performance test" on page 30
H	Test Head: Performs tests to ensure that the tape drive's head and tape-carriage mechanics are working correctly.	"Function code H: Test head" on page 31


Table 6. Diagnostic and maintenance functions (continued)

Function Code	Diagnostic or Maintenance Function	Instructions Location
	Fast Read/Write Test: Performs tests to ensure that the drive can read from and write to tape.	“Function code J: Fast read/write test” on page 32
	Load/Unload Test: Tests the drive's ability to load and unload a tape cartridge.	“Function code L: Load/unload test” on page 32
	Enable Post Error Reporting: When selected, deferred-check conditions are reported to the host.	“Function code P: Post Error Reporting enabled” on page 33
	Disable Post Error Reporting: When selected, deferred-check conditions are NOT reported to the host.	“Function code U: Post Error Reporting disabled” on page 34

Entering Maintenance mode

The drive must be in maintenance mode to run drive diagnostic tests or maintenance functions. To place the unit in maintenance mode:

1. Make sure that no cartridge is in the drive.
2. Press **Unload** three times within 2 seconds.  displays in the Single-character Display (SCD), the Ready light is flashing, and the Fault light turns On.


Note: If a cartridge is in the tape drive, it ejects the first time that you press **Unload** and the drive is placed in maintenance mode. To continue placing the drive in maintenance mode, complete the preceding step. While in Maintenance mode, the drive does not accept a cartridge unless the drive requests it. The SCD displays a flashing  to indicate a cartridge must be inserted.

Maintenance functions cannot be completed concurrently with read or write operations. While in maintenance mode, the drive does not receive host interface commands from the server.

Exiting Maintenance mode


The drive must be in Function Code  to exit Maintenance mode.

To exit Maintenance mode:

1. Press and hold **Unload** for 3 or more seconds to take the drive out of maintenance mode. If no error is detected,  temporarily displays in the SCD, then goes blank. The drive then exits maintenance mode and the Ready light turns On.
2. If an error is detected, the SCD shows an error code but still exits maintenance mode. To determine the error, locate the code in Appendix A, “Error codes and messages,” on page 65. To clear the error, turn off the power, then on again.

Note: The drive also exits maintenance mode automatically after it completes a maintenance function or after 10 minutes if no action occurred.

Function code 0: Maintenance mode

Function code  makes the drive available for running drive diagnostic tests or maintenance functions, or exiting from Maintenance mode.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode.”
2. To exit Maintenance mode, see “Exiting Maintenance mode.”

The drive exits Maintenance mode automatically after it completes a maintenance function or after 10 minutes if no action occurred.

Function code 1: Run drive diagnostics

Approximate Run Time = 5 minutes per loop

Total Number of Loops = 1

Function code **1** runs tests that determine whether the drive can properly load and unload cartridges and read and write data.

Record the time that it takes for the test to complete. Compare the recorded time with the "Approximate Run Time". If the test runs successfully but the execution time is longer than the "Approximate Run Time," run "Function code F: Write performance test" on page 30. If the Write Performance Test fails, replace the media and exit maintenance mode.

Attention: For this test, insert only a scratch (blank) data cartridge or a cartridge that might be overwritten. During the test, the drive overwrites the data on the cartridge.

Note: If you inserted an invalid tape cartridge, error code **7** or **7** appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code **F** appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

Steps to Run Drive Diagnostic Tests:




1. Place the drive in Maintenance mode. For instructions, see "Entering Maintenance mode" on page 23.
2. Press **Unload** once per second until **1** displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select function **1**. Wait for the SCD to change to a flashing **1**, requesting a cartridge.
4. Insert a scratch (blank) data cartridge. The SCD changes to a flashing **1** and the test begins. During the test, the drive unloads and loads the cartridge. Do not remove the cartridge during the test.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends, **1** temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code 2: Update drive firmware from FMR tape


Attention: When drive firmware is updated, do not turn the drive off until the update is complete or the firmware might be lost.

Function code **2** loads drive firmware from a field microcode replacement (FMR) tape. The FMR tape must be created from an LTO Ultrium 8 tape drive with the same host interface (SAS or Fibre Channel).




1. Place the drive in Maintenance mode. For instructions, see "Entering Maintenance mode" on page 23.




2. Press **Unload** once per second until  displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing , requesting a cartridge.
4. Insert the FMR tape cartridge. The SCD changes to a flashing . The Fault light is ON solid during tape movement and flashing while code is being loaded. The Ready light is OFF. The tape drive loads the updated firmware from the FMR tape into its erasable programmable read-only memory (EPROM) area.
 - If the update completes successfully, the tape drive rewinds and unloads the FMR tape, resets itself, and is ready to use the new firmware. The drive automatically reboots.
 - If the update fails, the tape drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. The drive then unloads the FMR tape and exits maintenance mode after the cartridge is removed. Contact IBM technical support for problem determination or machine replacement.

Function code 3: Create FMR tape


Function code  copies the drive's field microcode replacement (FMR) data to a scratch data cartridge. The resulting FMR tape is used only to update the firmware on other LTO Ultrium 8 tape drives with the same host interface (SAS or Fibre Channel).

Attention: For this function, insert only a scratch (blank) data cartridge or a cartridge that might be overwritten. During the test, the drive overwrites the data on the cartridge.

Note: If you inserted an invalid tape cartridge, error code  or  appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code  appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until  appears in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing , requesting a cartridge.
4. Insert a scratch (blank) data cartridge that is not write protected (or the tape drive exits maintenance mode). The SCD changes to a flashing . The tape drive copies the FMR data to the scratch data cartridge.
 - If the tape drive creates the FMR tape successfully, it rewinds and unloads the new tape, exits Maintenance mode, and the tape is ready to use.
 - If the tape drive fails to create the FMR tape, it displays an error code. To determine the error, see Table 17 on page 65. The tape drive then unloads the FMR tape, and exits Maintenance mode after the cartridge is removed.

Function code 4: Force a drive dump

Function code  completes a memory dump of data that is collected by the drive (this process is also known as saving a microcode trace).

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until $\boxed{4}$ displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The drive completes the memory dump. The SCD shows $\boxed{0}$, then goes blank, and the drive exits Maintenance mode. To access the contents of the memory dump, see “Function code 5: Copy drive dump.”

Note: You can also force a drive dump when the tape drive is in normal operating mode. Press and hold **Unload** for 10 seconds. This action causes the drive to reboot.

Function code 5: Copy drive dump

Function code $\boxed{5}$ copies data from a drive memory dump (captured in Function Code 4) to the beginning of a scratch (blank) data cartridge.

Attention: For this function, insert only a scratch (blank) data cartridge or a cartridge that might be overwritten. During the test, the drive overwrites the data on the cartridge.

Note: If you inserted an invalid tape cartridge, error code $\boxed{4}$ or $\boxed{7}$ appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code \boxed{P} appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until $\boxed{5}$ displays in the SCD. If you cycle past the wanted code, press **Unload** once per second until the code reappears.
3. Press and hold **Unload** for three or more seconds, then release it to select the function.
4. Press **Unload** once per second to cycle through the following functions:
 - $\boxed{5} - \boxed{0}$: no function
 - $\boxed{5} - \boxed{1}$: copy memory dump to tape; clears RAM memory dump
 - $\boxed{5} - \boxed{2}$: copy memory dump to flash memory; clears RAM memory dump
 - $\boxed{5} - \boxed{3}$: erase flash memory

If you cycle past the wanted code, press **Unload** once per second until the code reappears.

5. Press and hold **Unload** for three or more seconds, then release it to select one of the functions.
6. If you selected $\boxed{5} - \boxed{0}$ the drive exits Maintenance mode. If you selected $\boxed{5} - \boxed{2}$ or $\boxed{5} - \boxed{3}$ the SCD changes to a flashing $\boxed{5}$ while the procedure is completing. After the procedure is completed the drive exits Maintenance mode. If you selected $\boxed{5} - \boxed{1}$ the SCD changes to a flashing \boxed{C} indicating that a data cartridge is to be inserted.
7. Insert a scratch (blank) data cartridge within 60 seconds, or the drive exits Maintenance mode. Ensure that the scratch cartridge is not write protected, or the tape drive exits maintenance mode. The SCD flashes the selection number while the function is completing.

- If the copy operation completes successfully, the tape drive rewinds and unloads the tape, and exits Maintenance mode after the cartridge is removed.
- If the copy operation fails, an error code displays in the SCD. To determine the error, locate the code in Table 17 on page 65. The tape drive unloads the tape cartridge and exits Maintenance mode after the cartridge is removed.

Function code 6: Run host interface wrap test

Approximate Run Time = 10 seconds per loop

Number of Loops = This test runs until stopped by pressing **Unload**.

Function code **6** completes a check of the host interface circuitry and host connector on the drive.

1. Make sure that the host interface wrap plug is connected to the host interface connector at the rear of the drive¹.
 - Connect the wrap plug to the SAS port to be tested.
2. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
3. Press **Unload** once per second until **6** appears in the SCD.
 - To test the SAS interface on the drive,
 - a. Index through the Maintenance mode options until **6** appears in the SCD.
 - b. Press and hold **Unload** for 3 seconds to select Function code **6**.
 - c. After Function code **6** is selected, the SCD displays option **6** - **1**.
 - d. Press **Unload** within 5 seconds to make a different selection. If no other selection is made, the drive completes option **6** - **1**.
4. Continue to press **Unload** once per second to cycle through the following functions:
 - **6** - **1** : test the primary SAS port
 - **6** - **2** : test the secondary SAS port²
 - **6** - **3** : test both primary and secondary SAS ports at the same time (requires a wrap plug in both ports)²
 - **6** - **0** : exit
5. Press and hold **Unload** for three or more seconds, then release it to select one of the functions. The drive automatically starts the test. If you cycle past the wanted code, press **Unload** once per second until the code reappears.
6. The SCD displays a flashing **6** during the test.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends, **0** temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code 7: Run RS-422 wrap test

Note: This function is described here for information only. It is not supported on the IBM TS2260, TS2270, or the TS2280 tape drive.

This test causes the drive to process a check of the circuitry and connector for the RS-422 interface. This connector supports the Library Drive Interface (LDI) and the Automation Drive Interface (ADI).

Before this function is selected, attach an LDI or RS-422 wrap plug to the drive's LDI or RS-422 connector (in place of the LDI or RS-422 cable).

1. Make sure that no cartridge is in the drive, and the appropriate wrap plug is attached to the RS-422 connector.
2. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
3. Press **Unload** once per second until **7** appears in the Single-character Display (SCD). If you cycle past **7**, continue to press **Unload** until the code is displayed again.
4. To select the function, press and hold **Unload** for 3 seconds. After you select the function, **7** flashes and the drive automatically starts the test.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends, **7** temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code 8: Unmake FMR tape

Function code **8** erases the field microcode replacement (FMR) data and rewrites the cartridge memory on the tape. This action converts the cartridge into a valid scratch (blank) data cartridge.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until **8** appears in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select function **8**. The SCD changes to a flashing **8**, requesting a cartridge.
4. Insert the FMR data cartridge (or the tape drive exits Maintenance mode). The SCD changes to a flashing **8**. The tape drive erases the firmware on the tape and rewrites the header in the cartridge memory to change the cartridge to a valid scratch (blank) data cartridge: The drive then ejects the cartridge and exits Maintenance mode.

Note: If you inserted an invalid tape cartridge, error code **U** or **7** appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code **P** appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

- If the tape drive creates the scratch tape successfully, it rewinds and unloads the new tape, exits Maintenance mode, and the tape is ready to use.

- If the tape drive fails to create the scratch tape, it displays an error code. To determine the error, see Table 17 on page 65. The tape drive then unloads the FMR tape, and exits Maintenance mode after the cartridge is removed.

Function code 9: Display error code log

Function code **9** displays the last 10 error codes, one at a time (the codes are ordered; the most recent is presented first and the oldest is presented last). If there are no errors in the log, function code **9** displays in the Single-character Display (SCD) and exits Maintenance Mode.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until **9** appears in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload**, then release it to view the most recent error code.
4. Press and release **Unload** again to view successive error codes. Allow 2 - 3 seconds pass between each depression. The Ready light and Fault light flash On/Off once for each successive error code. The SCD displays **9** when all the error codes are displayed.
5. After all error codes are viewed, exit this function by pressing **Unload** again. The SCD displays **9** and exits Maintenance mode.

Function code A: Clear error code log

Function code **A** erases the contents of the error code log.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until **A** displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. **A** flashes in the SCD, followed by **9**. The tape drive erases all errors from the error code log and exits Maintenance mode.

Function code C: Insert cartridge into tape drive

This function cannot be selected by itself, but is part of other maintenance functions (such as Run tape drive diagnostics and Create FMR tape) that require a tape cartridge to be inserted.

Function code E: Test cartridge & media

Approximate Run Time = 15 minutes per loop

Total Number of Loops = 10

Function code **E** completes tests that determine whether a suspect cartridge and its magnetic tape are acceptable.

Press **Unload** to stop the diagnostic test and exit Maintenance mode. Pressing **Unload** once stops the test at the end of the current test loop. Pressing **Unload** twice stops the test immediately. Wait for the drive to rewind the tape and unload the cartridge.

Attention: When you complete this test, data on the suspect tape is overwritten.

Note: If you inserted an invalid tape cartridge, error code \boxed{U} or $\boxed{7}$ appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code \boxed{P} appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until \boxed{E} displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing \boxed{C} , requesting a cartridge.
4. Ensure that the write-protect switch on the cartridge is off, then insert the cartridge (or the tape drive exits Maintenance mode). The SCD changes to a flashing \boxed{E} . The tape drive runs the tests.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends, \boxed{U} temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code F: Write performance test

Approximate Run Time = 7 minutes per loop

Total Number of Loops = 10


Function code \boxed{F} performs tests to ensure that the drive can read from and write to tape.

Press **Unload** to stop the diagnostic test and exit Maintenance mode. Pressing **Unload** once stops the test at the end of the current test loop. Pressing **Unload** twice stops the test immediately. Wait for the drive to rewind the tape and unload the cartridge.

Attention: For this test, insert only a scratch (blank) data cartridge or a cartridge that can be overwritten. During the test, the drive overwrites the data on the cartridge.

Note: If you inserted an invalid tape cartridge, error code \boxed{U} or $\boxed{7}$ appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code \boxed{P} appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.


1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until \boxed{F} displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing \boxed{C} , requesting a cartridge.
4. Insert a scratch (blank) data cartridge. The SCD changes to a flashing \boxed{F} and the tape drive runs the tests.

- If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends,  temporarily displays in the SCD, and the tape drive exits Maintenance mode.
- If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code H: Test head

Approximate Run Time = 12 minutes per loop




Total Number of Loops = 10





Function code  completes tests to ensure that the tape drive's head and tape-carriage mechanics work correctly.

When you begin this test, the diagnostic test begins the loop sequence. Time the first loop by pressing **Unload** once to stop the diagnostic test after the completion of the first loop, then record the time that it takes for the test to complete. Compare the recorded time with the "Approximate Run Time". If the test runs successfully but the execution time is longer than the "Approximate Run Time", run "Function code F: Write performance test" on page 30. If the Write Performance Test fails, replace the media and exit Maintenance mode.

Press **Unload** to stop the diagnostic test and exit Maintenance mode. Pressing **Unload** once stops the test at the end of the current test loop. Pressing **Unload** twice stops the test immediately. Wait for the drive to rewind the tape and unload the cartridge.

Attention: For this test, insert only a scratch (blank) data cartridge or a cartridge that can be overwritten. During the test, the drive overwrites the data on the cartridge.

Note: If you inserted an invalid tape cartridge, error code  or  appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code  appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

1. Place the drive in Maintenance mode. For instructions, see "Entering Maintenance mode" on page 23.
2. Press **Unload** once per second until  displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing , requesting a cartridge.
4. Insert a scratch (blank) data cartridge. The SCD changes to a flashing . The tape drive runs the tests.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends,  temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code J: Fast read/write test

Approximate Run Time = 7 minutes per loop

Total Number of Loops = 10

Function code **J** completes tests to ensure that the drive can read from and write to tape.

When you begin this test, the diagnostic test begins the loop sequence. Time the first loop by pressing **Unload** once to stop the diagnostic test after the completion of the first loop, then record the time that it takes for the test to complete. Compare the recorded time with the "Approximate Run Time". If the test runs successfully but the execution time is longer than the "Approximate Run Time", run "Function code F: Write performance test" on page 30. If the Write Performance Test fails, replace the media and exit Maintenance mode.

Press **Unload** to stop the diagnostic test and exit Maintenance mode. Pressing **Unload** once stops the test at the end of the current test loop. Pressing **Unload** twice stops the test immediately. Wait for the drive to rewind the tape and unload the cartridge.

Attention: For this test, insert only a scratch (blank) data cartridge or a cartridge that can be overwritten. During the test, the drive overwrites the data on the cartridge.

Note: If you inserted an invalid tape cartridge, error code **J** or **7** appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code **P** appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

1. Place the drive in Maintenance mode. For instructions, see "Entering Maintenance mode" on page 23.
2. Press **Unload** once per second until **J** displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing **L**, requesting a cartridge.
4. Insert a scratch (blank) data cartridge. The SCD changes to a flashing **J** and the tape drive runs the tests.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends, **J** temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code L: Load/unload test

Approximate Run Time = 30 seconds per loop

Total Number of Loops = 10

Function code **L** tests the drive 's ability to load and unload a tape cartridge.

Press **Unload** to stop the diagnostic test and exit Maintenance mode. Pressing **Unload** once stops the test at the end of the current test loop. Pressing **Unload** twice stops the test immediately. Wait for the drive to rewind the tape and unload the cartridge.

Attention: Even though no data is written during this test, it is recommended that you use a blank (scratch) cartridge for this test.

Note: If you inserted an invalid tape cartridge, error code \boxed{U} or $\boxed{7}$ appears in the SCD. If you inserted a write-protected cartridge, or the media has read-only compatibility, error code \boxed{P} appears in the SCD. In either case, the tape drive unloads the cartridge and exits Maintenance mode after the cartridge is removed.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until \boxed{L} displays in the SCD. (If you cycle past the wanted code, press **Unload** once per second until the code reappears.)
3. Press and hold **Unload** for three or more seconds, then release it to select the function. The SCD changes to a flashing \boxed{C} , requesting a cartridge.
4. Insert a scratch (blank) data cartridge. The SCD changes to a flashing \boxed{L} and the tape drive runs the tests.
 - If no error is detected, the diagnostic test loops and begin again. To stop the loop, press **Unload** for 1 second and release. When the loop ends, \boxed{C} temporarily displays in the SCD, and the tape drive exits Maintenance mode.
 - If an error is detected, the Fault light flashes and the drive posts an error code to the SCD. To determine the error, locate the code in Table 17 on page 65. To clear the error either turn the power off and then on again, or reboot the drive by pressing and holding **Unload** for 10 seconds.

Function code P: Post Error Reporting enabled


When Post Error Reporting is enabled, deferred-check conditions are reported to the host and temporary errors are reported in the sense data. Function code \boxed{P} is displayed in Maintenance mode when the drive has Post Error Reporting enabled.







This selection is normally used as a request from support personnel.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until either \boxed{P} or \boxed{U} displays in the SCD. \boxed{P} or \boxed{U} displays in the SCD to indicate the current setting for Post Error Reporting. If you cycle past the desired code, press **Unload** once per second until the code reappears.
3. Exit Maintenance mode if you do not want to change the current setting for Post Error Reporting. For instructions, see “Exiting Maintenance mode” on page 23.
4. To disable Post Error Reporting, press and hold **Unload** for 3 seconds while \boxed{P} displays in the SCD. The SCD changes to \boxed{U} after you release **Unload**.
5. Press **Unload** once per second to select another Maintenance mode function. To exit Maintenance mode, refer to “Exiting Maintenance mode” on page 23.

Function code U: Post Error Reporting disabled

When Post Error Reporting is disabled, deferred-check conditions are not reported to the host and temporary errors are not reported in the sense data. This setting is normal (default) for the drive. When

the drive has Post Error Reporting that is disabled, Function code  is displayed in Maintenance mode. The drive defaults to Post Error Reporting disabled after a reboot or power off/on cycle.

1. Place the drive in Maintenance mode. For instructions, see “Entering Maintenance mode” on page 23.
2. Press **Unload** once per second until either  or  displays in the SCD.  or  displays in the SCD to indicate the current setting for Post Error Reporting. If you cycle past the wanted code, press **Unload** once per second until the code reappears.
3. Exit Maintenance mode if you do not want to change the current setting for Post Error Reporting. For instructions, see “Exiting Maintenance mode” on page 23.
4. To disable Post Error Reporting, press and hold **Unload** for 3 seconds while  displays in the SCD. The SCD changes to  after you release **Unload**.
5. Press **Unload** once per second to select another Maintenance mode function. To exit Maintenance mode, refer to “Exiting Maintenance mode” on page 23.

Tape drive diagnostic and maintenance web page

Several of the tape drive’s maintenance functions are run with the tape drive’s Ethernet port. These functions are the same maintenance functions that are run with **Unload** on the drive’s front panel.

For more information about maintenance functions, see “Diagnostic and maintenance functions” on page 21 section in this User’s Guide.

1. Connect the host computer or a notebook to the tape drive’s Ethernet port (RJ45 connector) with an Ethernet patch cable.
2. With a web browser, connect to <http://169.254.0.3/service.html> to access the tape drive maintenance function menu on an HTML web page. (If the drive’s IP address was changed, use that address instead.)

The tape drive model and serial number are shown at the top of the page. A list of the maintenance functions is shown on the page.

ULT3580-HH8 Drive YX1013000128

Select function:

- 1: Run Drive Diagnostics
- 2: Update Drive Firmware from FMR Tape
- 3: Create FMR Tape
- 4: Force a Drive Dump
- 5.1: Copy Drive Dump - copy dump to tape
- 5.2: Copy Drive Dump - copy dump to flash
- 5.3: Copy Drive Dump - erase flash memory
- 6.1: Run Host Interface Wrap Test - primary port
- 6.2: Run Host Interface Wrap Test - secondary port
- 6.3: Run Host Interface Wrap Test - both ports
- 8: Unmake FMR Tape
- 9: Display Error Code Log
- A: Clear Error Code Log
- E: Test Cartridge & Media
- F: Write Performance Test
- H: Test Head
- J: Fast Read/Write Test
- L: Load/Unload Test

Drive response (press refresh to display current drive status):

Select a test and press run.

a67b0034

Figure 10. Tape drive diagnostic page

Click the button next to the maintenance function, then click **Run** to start the maintenance function.

If the tape drive is installed in a library, some of the maintenance functions cannot be run with the Ethernet procedure.

The status of the maintenance function is shown under the Drive Response. The web page is static so it must be refreshed frequently to show the current maintenance function status.

Press **Cancel now** or **Cancel at end of loop** to stop the maintenance function. It can take several minutes for the maintenance function to end.

Ultrium media

IBM Ultrium media is available in the following types:

- Data cartridge
- WORM (Write Once, Read Many) cartridge
- Cleaning cartridge

To ensure that your IBM Ultrium tape drive conforms to IBM's specifications for reliability, use only IBM LTO Ultrium tape cartridges. You can use other LTO-certified data cartridges, but they might not meet the standards of reliability that are established by IBM. The IBM LTO Ultrium data cartridge cannot be interchanged with the media used in other IBM non-LTO Ultrium tape products.

Figure 11 shows the IBM LTO Ultrium data cartridge and its components.

- | | | | |
|----------|----------------------|----------|----------------------|
| 1 | LTO cartridge memory | 4 | Write-protect Switch |
| 2 | Cartridge door | 5 | Label area |
| 3 | Leader Pin | 6 | Insertion guide |




Figure 11. The IBM LTO Ultrium data cartridge

Data cartridges

The different generations of IBM Ultrium data cartridges are identified by color:

Table 7. Cartridge types and colors

Type	Color
Ultrium 8	Burgundy
Ultrium 8 WORM	Burgundy and Silvery gray
Ultrium 7	Purple
Ultrium 7 WORM	Purple and Silvery gray
Ultrium 6	Black
Ultrium 6 WORM	Black and Silvery gray

Table 7. Cartridge types and colors (continued)

Type	Color
Ultrium 5	Burgundy
Ultrium 5 WORM	Burgundy and Silvery gray
Ultrium 4	Green
Ultrium 4 WORM	Green and Silvery gray
Ultrium 3	Slate Blue
Ultrium 3 WORM	Slate Blue and Silvery gray
Ultrium 2	Purple
Ultrium 1	Black

All generations contain 1/2-inch, dual-coat, magnetic tape.

You can order tape cartridges with the bar code labels included, or you can order custom labels. To obtain tape cartridges and bar code labels, see “Ordering media supplies” on page 54.

When tape is processed in the cartridges, Ultrium Tape Drives use a linear, serpentine recording format. The native data capacity and recording format of Ultrium data cartridges is as follows:

Table 8. Cartridge data capacity and recording formats

Type	Native Data Capacity	Recording Format
Ultrium 8	12000 GB (30000 GB at 2.5:1 compression)	Reads and writes data on 6656 tracks, 32 tracks at a time.
Ultrium 7	6000 GB (15000 GB at 2.5:1 compression)	Reads and writes data on 3584 tracks, 32 tracks at a time.
Ultrium 6	2500 GB (6250 GB at 2.5:1 compression)	Reads and writes data on 2176 tracks, 16 tracks at a time.
Ultrium 5	1500 GB (3000 GB at 2:1 compression)	Reads and writes data on 1280 tracks, 16 tracks at a time.
Ultrium 4	800 GB (1600 GB at 2:1 compression)	Reads and writes data on 896 tracks, 16 tracks at a time.
Ultrium 3	400 GB (800 GB at 2:1 compression)	Reads and writes data on 704 tracks, 16 tracks at a time.
Ultrium 2	200 GB (400 GB at 2:1 compression)	Reads and writes data on 512 tracks, 8 tracks at a time.
Ultrium 1	100 GB (200 GB at 2:1 compression)	Reads and writes data on 384 tracks, 8 tracks at a time.

The first set of tracks is written from near the beginning of the tape almost to the end of the tape. The head then repositions to the next set of tracks for the return pass. This process continues until all tracks are written and the cartridge is full, or until all data is written.

The cartridge door (**2** Figure 11 on page 37) protects the tape from contamination when the cartridge is out of the drive. The tape is attached to a leader pin (**3** in Figure 11 on page 37) behind the door. When the cartridge is inserted into the drive, a threading mechanism pulls the pin (and tape) out of the cartridge, across the drive head, and onto a non-removable take-up reel. The head can then read or write data from or to the tape.

The write-protect switch (**4** in Figure 11 on page 37) prevents data from being written to the tape cartridge. For more information, see “Write-Protect switch” on page 43.

The label area (**5** in Figure 11 on page 37) provides a location to place a label. For more information, see “Bar code label” on page 41.

The insertion guide (**6** in Figure 11 on page 37) is a large, notched area that prevents the cartridge from being inserted incorrectly.

Table 9. Nominal cartridge life: Load/unload cycles

Type	Load/Unload Cycles
Ultrium 8	20,000 (20k)
Ultrium 7	20,000 (20k)
Ultrium 6	20,000 (20k)
Ultrium 5	20,000 (20k)
Ultrium 4	20,000 (20k)
Ultrium 3	20,000 (20k)
Ultrium 2	10,000 (10k)
Ultrium 1	5000 (5k)

Cartridge Compatibility

Table 10. Ultrium data cartridge compatibility with Ultrium tape drive

IBM Ultrium Tape Drive	IBM LTO Ultrium Data Cartridges							
	12000 GB Ultrium 8	6000 GB Ultrium 7	2500 GB Ultrium 6	1500 GB Ultrium 5	800 GB Ultrium 4	400 GB Ultrium 3	200GB Ultrium 2	100GB Ultrium 1
Ultrium 8	Read/Write	Read/Write						
Ultrium 7		Read/Write	Read/Write	Read Only				
Ultrium 6			Read/Write	Read/Write	Read Only			
Ultrium 5				Read/Write	Read/Write	Read only		
Ultrium 4					Read/Write	Read/Write	Read only	
Ultrium 3						Read/Write	Read/Write	Read only
Ultrium 2							Read/Write	Read/Write
Ultrium 1								Read/Write

Capacity Scaling

To control the capacity of the cartridge (for example, to obtain a faster seek time) issue the SCSI command **SET CAPACITY**. For information about this command, refer to the *IBM Ultrium Tape Drive SCSI Reference*.

WORM (Write Once, Read Many) cartridges

Certain records retention and data security applications require a Write Once, Read Many (WORM) method for storing data on tape. The LTO Ultrium 4 and later drives enable WORM support when a WORM tape cartridge is loaded into the drive.

WORM media

Because standard read/write media are incompatible with the WORM feature, a specially formatted WORM tape cartridge (see Figure 12) is required. Each WORM cartridge has a unique, worldwide cartridge identifier (WWCID), which comprises the unique CM chip serial number and the unique tape media serial number. Ultrium 8 WORM cartridges are burgundy and silvery gray. For more information about how to choose and purchase the appropriate WORM tape cartridges for your tape drive, see “Ordering media supplies” on page 54.




Figure 12. Ultrium Data and WORM Tape Cartridges

Data security on WORM media

Certain built-in security measures help ensure that the data that is written on a WORM cartridge does not become compromised. For example:

- The format of an Ultrium WORM Tape Cartridge is not the same as the standard read/write media. This unique format prevents a drive that lacks WORM-capable firmware from writing on a WORM tape cartridge. For LTO 8, native data capacity is 12000 GB and compressed data capacity is 30000 GB.
- When the drive senses a WORM cartridge, the firmware prohibits the changing or altering of user data that is already written on the tape. The firmware notes the last point on the tape that can be appended.

WORM media errors


The following conditions cause WORM media errors to occur:

- Information in the servo manufacturer's word (SMW) on the tape must match information from the cartridge memory (CM) module in the cartridge. If it does not match, a media Error Code 7 posts on the drive's single-character display (SCD).
- Inserting a WORM tape cartridge into a drive that is not compatible with WORM causes the cartridge to be treated as an unsupported medium. The drive reports a media Error Code 7. Upgrading the drive firmware to the correct code level resolves the problem.

WORM requirements

To add WORM capability to your IBM LTO Ultrium 8 drives, you must use either IBM Ultrium 8 12000 GB WORM tape cartridges or IBM Ultrium 7 6000 GB WORM tape cartridges. See “Ordering media supplies” on page 54.

Cleaning cartridge

A specially labeled IBM LTO Ultrium Cleaning Cartridge is used to clean the drive head. The drive itself determines when a head must be cleaned. It alerts you by the SCD flashing a . To clean the head manually, insert a cleaning cartridge into the tape load compartment (see Figure 7 on page 18). The drive completes the cleaning automatically. When the cleaning is finished, the drive ejects the cartridge, and the SCD is blank.

Note: The drive automatically ejects an expired cleaning cartridge without running the cleaning process. Replace the expired cleaning cartridge with a new cleaning cartridge and insert it into the drive.

The IBM cleaning cartridges are valid for 50 uses. The cartridge's LTO-CM chip tracks the number of times that the cartridge is used.

Important: After 50 uses, the cleaning cartridge expires. It is no longer usable, and must be replaced

Cartridge memory chip (LTO-CM)

All generations of the IBM LTO Ultrium Data Cartridges include a Linear Tape-Open Cartridge Memory (LTO-CM) chip (1 in Figure 11 on page 37) that contains information about the cartridge and the tape (such as the name of the manufacturer that created the tape), and also statistical information about how to use the cartridges. The LTO-CM enhances the efficiency of the cartridge. For example, the LTO-CM stores the end-of-data location which, when the next time this cartridge is inserted and the Write command is issued, enables the drive to quickly locate the recording area and begin recording. The LTO-CM also aids in determining the reliability of the cartridge by storing data about its age, how many times it was loaded, and how many errors it accumulated. Whenever you unload a tape cartridge the tape drive writes any pertinent information to the cartridge memory.

The storage capacity of the LTO Generation 6, 7, and 8 LTO-CM is 16320 bytes. The storage capacity of the LTO Generation 4 and 5 LTO-CM is 8160 bytes. LTO Generations 1, 2, and 3 have an LTO-CM capacity of 4096 bytes.

Bar code label

A bar code label contains:

- A volume serial number (VOLSER) that is human-readable.
- A bar code that the library can read.

Note: The LTO Ultrium 8 tape drives do not require bar code labels, but you might choose to use labels for tape cartridge identification purposes.

Table 11. Bar code label requirements for Ultrium tape drives and libraries

Ultrium Tape Drive/Library	Bar Code Label Requirements
3573	Required
3576	Required
3580	Not required
3581	Required with optional Bar Code Reader
3582	Required
3583	Required
3584	Required

When read by a library's bar code reader, the bar code identifies the cartridge's VOLSER to the library. The bar code also tells the library whether the cartridge is a data cartridge or cleaning cartridge. In addition, the bar code includes the two-character media-type identifier Lx, where x equals 1, 2, 3, 4, 5, 6, 7 or 8. L identifies the cartridge as an LTO cartridge and the number represents the generation of cartridge for that cartridge type. Figure 13 on page 43 shows a sample bar code label for the LTO Ultrium Tape Cartridge.

Tape cartridges are ordered with the labels included or with custom labels. To order tape cartridges and bar code labels, see "Ordering media supplies" on page 54. The bar code for usage in IBM tape libraries must meet predefined specifications. They include (but are not limited to):

- Eight uppercase alphanumeric characters, where the last 2 characters must be L8, L7, L6, L5, L4, L3, L2, or L1 (LY, LX, LW, LV, LU, or LT for Ultrium WORM cartridges)
- Label and printing to be non-glossy.
- Nominal narrow line or space width of 0.423 mm (0.017 in.)
- Wide to narrow ratio of 2.75:1.
- Minimum bar length of 11.1 mm (0.44 in.)

Table 12. Cartridges and VOLSERs compatible with the Ultrium Tape Drives

Cartridges	VOLSER
Ultrium 8 Data Cartridge	xxxxxxxL8
Ultrium 8 WORM Cartridge	xxxxxxxLY
Ultrium 7 Data Cartridge	xxxxxxxL7
Ultrium 7 Data Cartridge	xxxxxxxLX
Ultrium 6 Data Cartridge	xxxxxxL6
Ultrium 6 WORM Cartridge	xxxxxxLW
Ultrium 5 Data Cartridge	xxxxxxL5
Ultrium 5 WORM Cartridge	xxxxxxLV
Ultrium 4 Data Cartridge	xxxxxxL4
Ultrium 4 WORM Cartridge	xxxxxxLU
Ultrium 3 Data Cartridge	xxxxxxL3
Ultrium 3 WORM Cartridge	xxxxxxLT
Ultrium 2 Data Cartridge	xxxxxxL2
Ultrium 1 Data Cartridge (READ ONLY)	xxxxxxL1
LTO Ultrium Cleaning Cartridge	CLNxxxLx

*An Ultrium 3 Tape Drive must have a minimum firmware level of 54xx for it to be compatible with the WORM cartridge.

To determine the complete specifications of the bar code and the bar code label, visit the web at <http://www.ibm.com/> and enter "IBM LTO Ultrium Cartridge Label Specification" in the search box. Or contact your IBM sales representative.

When a bar code label is attached to a tape cartridge, place the label only in the recessed label area (see **5** in "Ultrium media" on page 37). A label that extends outside of the recessed area can cause loading problems in the drive.

Attention: Do not place any type of mark on the white space at either end of the bar code. A mark in this area might prevent the library from reading the label.




Figure 13. Sample bar code label on the LTO Ultrium 8 Tape Cartridge. The volume serial number (LTO123) and bar code are printed on the label.


Guidelines for bar code labels

Apply the following guidelines whenever using bar code labels:

- Use only IBM-approved bar code labels on cartridges to be used in an IBM tape library.
- Do not reuse a label or reapply a used label over an existing label.
- Before you apply a new label, remove the old label by slowly pulling it at a right angle to the cartridge case.
- Use peel-clean labels that do not leave a residue after it is removed. If there is glue residue on the cartridge, remove it by gently rubbing it with your finger. Do not use a sharp object, water, or a chemical to clean the label area.
- Examine the label before it is applied to the cartridge. Do not use the label if it has voids or smears in the printed characters or bar code. A library's inventory operation takes much longer if the bar code label is not readable.
- Remove the label from the label sheet carefully. Do not stretch the label or cause the edges to curl.
- Position the label within the recessed label area (see **5** in Figure 11 on page 37).
- With light finger pressure, smooth the label so that no wrinkles or bubbles exist on its surface.
- Verify that the label is smooth and parallel, and has no roll-up or roll-over. The label must be flat to within 0.5 mm (0.02 in.) over the length of the label and have no folds, missing pieces, or smudges.
- Do not place other machine-readable labels on other surfaces of the cartridge. They might interfere with the ability of the drive to load the cartridge.

Write-Protect switch

The position of the write-protect switch on the tape cartridge (see **1**) determines whether you can write to the tape. If the switch is set to:

- The locked position  (solid red), data cannot be written to the tape.
- The unlocked position (black void), data can be written to the tape.

If possible, use your server's application software to write-protect your cartridges (rather than manually setting the write-protect switch). This setting allows the server's software to identify a cartridge that no longer contains current data and is eligible to become a scratch (blank) data cartridge. Do not write-protect scratch (blank) cartridges; the tape drive is not able to write new data to them.

If you must manually set the write-protect switch, slide it left or right to the wanted position.




Figure 14. Setting the write-protect switch

Table 13. Location of the write-protect switch

1	Write-protect switch
----------	----------------------

Handling the cartridges

Attention: Do not insert a damaged tape cartridge into the drive. A damaged cartridge can interfere with the reliability of a drive and might void the warranties of the drive and the cartridge. Before a tape cartridge is inserted, inspect the cartridge case, cartridge door, and write-protect switch for breaks.

Incorrect handling or an incorrect environment can damage cartridges or their magnetic tape. To avoid damage to your tape cartridges and to ensure the continued high reliability of your IBM LTO Ultrium Tape Drives, use the following guidelines:

Providing training

- Post procedures that describe appropriate media handling in places where people gather.
- Ensure that anyone who handles tape is properly trained in handling and shipping procedures. This training includes operators, users, programmers, archival services, and shipping personnel.
- Ensure that any service or contract personnel who complete archiving procedures are properly trained in media-handling procedures.
- Include media-handling procedures as part of any services contract.
- Define and make personnel aware of data recovery procedures.

Ensuring proper packaging

- When a cartridge is shipped, use the original or better packaging.
- Always ship or store a cartridge in a jewel case.
- Use only a recommended shipping container that securely holds the cartridge in its jewel case during transportation. Ultrium Turtlecases (by Perm-A-Store) are tested and found to be satisfactory (see Figure 15 on page 45). They are available at <http://www.turtlecase.com>.



Figure 15. Tape cartridges in a Turtlecase

- Never ship a cartridge in a commercial shipping envelope. Always place it in a box or package.
- If you ship the cartridge in a cardboard box or a box of a sturdy material, ensure that you
 - Place the cartridge in polyethylene plastic wrap or bags to protect it from dust, moisture, and other contaminants.
 - Pack the cartridge snugly; do not allow it to move around.
 - Double-box the cartridge (place it inside a box, then place that box inside the shipping box) and add padding between the two boxes (see Figure 16).



Figure 16. Double-boxing tape cartridges for shipping

Proper acclimation and environmental conditions

- Before you use a tape cartridge, acclimate it to the operating environment for 24 hours or the time necessary to prevent condensation in the drive. The time varies, depending on the environmental extremes to which the cartridge was exposed.
- Ensure that all surfaces of a cartridge are dry before it is inserted.
- Do not expose the cartridge to moisture or direct sunlight.

- Do not expose recorded or blank cartridges to stray magnetic fields of greater than 100 oersteds (for example, terminals, motors, video equipment, X-ray equipment, or fields that exist near high-current cables or power supplies). Such exposure causes the loss of recorded data or makes the blank cartridge unusable.
- Maintain the conditions that are described in “Environmental and shipping specifications for tape cartridges” on page 52.

Completing a thorough inspection

After a cartridge is purchased and before it is used, complete the following steps:

- Inspect the cartridge 's packaging to determine potential rough handling.
- When a cartridge is inspected, open only the cartridge door. Do not open any other part of the cartridge case. The upper and lower parts of the case are held together with screws; separating them destroys the usefulness of the cartridge.
- Inspect the cartridge for damage before it is used or stored.
- Inspect the rear of the cartridge (the part that loads first into the tape load compartment) and ensure that there are no gaps in the seam of the cartridge case (see **1** in Figure 17 and **4** in Figure 19 on page 48). If there are gaps in the seam (see Figure 17), the leader pin might be dislodged. Go to “Repositioning or reattaching a leader pin” on page 47.




Figure 17. Checking for gaps in the seams of a cartridge

- Check that the leader pin is properly seated (see **2** in Figure 18 on page 48).
- If you suspect that the cartridge was mishandled but it appears usable, copy any data onto a good cartridge immediately for possible data recovery. Discard the mishandled cartridge.
- Review handling and shipping procedures.

Handling the cartridge carefully

- Do not drop the cartridge. If the cartridge drops, slide the cartridge door back and ensure that the leader pin is properly seated in the pin-retaining spring clips. See **2** in Figure 18 on page 48. If the leader pin becomes dislodged, go to “Repositioning or reattaching a leader pin” on page 47.

- Do not handle tape that is outside the cartridge. Handling the tape can damage the tape 's surface or edges, which might interfere with read or write reliability. Pulling on tape that is outside the cartridge can damage the tape and the brake mechanism in the cartridge.
- Do not stack more than six cartridges.
- Do not degauss a cartridge that you intend to reuse. Degaussing makes the tape unusable.

Examples of cartridge problems

Split cartridge case. See Figure 17 on page 46.

The cartridge's case is damaged. There is a high possibility of media damage and potential loss.

1. Look for cartridge mishandling.
2. Use the IBM Leader Pin Reattachment Kit (part number 08L9129) to correctly seat the pin (see "Repositioning or reattaching a leader pin"). Then, immediately use data recovery procedures to minimize chances of data loss.
3. Review media-handling procedures.

Improper placement of leader pin. See Figure 18 on page 48.

The leader pin is misaligned.

1. Look for cartridge damage.
2. Use the IBM Leader Pin Reattachment Kit (part number 08L9129) to correctly seat the pin (see "Repositioning or reattaching a leader pin"). Then, immediately use data recovery procedures to minimize chances of data loss.

Repositioning or reattaching a leader pin

Attention: Use a repaired tape cartridge only to recover data and move it to another cartridge. Continued use of a repaired cartridge might void the warranties of the drive and the cartridge.

If the leader pin in your cartridge becomes dislodged from its pin-retaining spring clips or detaches from the tape, you must use the IBM Leader Pin Reattachment Kit (part number 08L9129) to reposition or reattach it. (Do not reattach the pin if you must remove more than 7 meters (23 feet) of leader tape.) The sections that follow describe each procedure.

Repositioning a leader pin

A leader pin that is improperly seated inside a cartridge interferes with the operation of the drive. Figure 18 on page 48 shows a leader pin in the incorrect **1** and correct **2** positions.

To place the leader pin in its proper position, you need the following tools:

- Plastic or blunt-end tweezers
- Cartridge manual rewind tool (from Leader Pin Reattachment Kit, part number 08L9129)




Figure 18. Leader pin in the incorrect and correct positions. The cartridge door is open and the leader pin is visible inside the cartridge.

To reposition the leader pin:

1. Slide open the cartridge door (**1** in Figure 19) and locate the leader pin (**2** (you might need to shake the cartridge gently to roll the pin toward the door).
2. With plastic or blunt-end tweezers, grasp the leader pin and position it in the pin-retaining spring clips (**3**).
3. Press the leader pin gently into the clips until it snaps into place and is firmly seated.
4. Close the cartridge door.




Figure 19. Placing the dislodged leader pin into the correct position. The cartridge door is open to show the leader pin.

5. To rewind the tape, insert the cartridge manual rewind tool (**1** in Figure 20 on page 49) into the cartridge's hub (**2**) and turn it clockwise until the tape becomes taut.




Figure 20. Rewinding the tape into the cartridge

6. Remove the rewind tool by pulling it away from the cartridge.
7. If you suspect that the cartridge was mishandled but it appears usable, copy any data onto a good cartridge immediately for possible data recovery. Discard the mishandled cartridge.

Reattaching a leader pin

The first meter of tape in a cartridge is leader tape. When the leader tape is removed there is a possibility of tape breakage. After the leader pin is reattached, transfer data from the defective tape cartridge. **Do not reuse the defective tape cartridge.**

The Leader Pin Reattachment Kit contains three parts:

- **Leader pin attach tool** (See **1** in Figure 21 on page 50). A plastic brace that holds the cartridge door open.
- **Cartridge manual rewind tool** (See **2** in Figure 21 on page 50). A device that fits into the cartridge's hub and enables you to wind the tape into and out of the cartridge.
- **Pin supplies** (See **3** in Figure 21 on page 50). Leader pins and C-clips.

Attention:

- Use only the IBM Leader Pin Reattachment Kit to reattach the leader pin to the tape. Other methods of reattaching the pin damages the tape, the drive, or both.
- Use this procedure on your tape cartridge only when the leader pin detaches from the magnetic tape and you must copy the cartridge's data onto another cartridge. Destroy the damaged cartridge after you copy the data. This procedure might affect the performance of the leader pin during threading and unloading operations.
- Touch only the end of the tape. Touching the tape in an area other than the end can damage the tape's surface or edges, which might interfere with read or write reliability.




Figure 21. Leader pin reattachment kit

This procedure describes how to reattach a leader pin.

To reattach a leader pin with the IBM leader pin reattachment kit:

1. Attach the leader pin attach tool (**1** in Figure 22) to the cartridge **2** so that the tool 's hook **3** latches into the cartridge 's door **4** . Pull the tool back to hold the door open, then slide the tool onto the cartridge. Open the tool 's pivot arm **5** .




Figure 22. Attaching the leader pin attach tool to the cartridge. To hold the cartridge door open, hook the tool into the door and pull the tool back.

2. To find the end of the tape inside the cartridge, attach the cartridge manual rewind tool (**1** in Figure 23 on page 51) to the cartridge 's hub **2** by fitting the tool 's teeth between the teeth of the hub. Turn the tool clockwise until you see the end of the tape inside the cartridge. Then, slowly turn the rewind tool counterclockwise to bring the tape edge toward the cartridge door **3** .

3. Continue to turn the rewind tool counterclockwise until approximately 13 cm (5 in.) of tape hangs from the cartridge door. If necessary, grasp the tape and pull gently to unwind it from the cartridge.
4. Remove the rewind tool by pulling it away from the cartridge. Set the tool and the cartridge aside.




Figure 23. Winding the tape out of the cartridge. Turn the cartridge manual rewind tool clockwise to see the end of the tape, then turn it counterclockwise to bring the tape to the cartridge door.

5. On the leader pin (**1** in Figure 24), locate the open side of the C-clip **2**. The C-clip is a small black part that secures the tape **3** to the pin.
6. Remove the C-clip from the leader pin by using your fingers to push the clip away from the pin. Set the pin aside and discard the clip.




Figure 24. Removing the C-clip from the leader pin. Use your fingers to push the C-clip from the leader pin.

7. Position the tape in the alignment groove of the leader pin attach tool (see **1** in Figure 25 on page 52).
8. Place a new C-clip into the retention groove **2** (Figure 25 on page 52) on the leader pin attachment tool and make sure that the clip's open side faces up.
9. Place the leader pin (from step 6) into the cavity **3** (Figure 25 on page 52) of the leader pin attach tool.

Attention: To prevent the leader pin from rolling into the cartridge, in the following step use care when the tape is folded over the pin.
10. Fold the tape over the leader pin and hold it with your fingers (see Figure 25 on page 52).

Note: Use care to ensure that the tape is centered over the leader pin. Failure to properly center the tape on the pin causes the repaired cartridge to fail. When the tape is properly centered, a 0.25 mm (0.01-in.) gap exists on both sides of the pin.




Figure 25. Attaching the leader pin to the tape

11. Close the pivot arm **4** of the leader pin attach tool by swinging it over the leader pin so that the C-clip snaps onto the pin and the tape.
12. Swing the pivot arm open and trim the excess tape **5** so that it is flush with the reattached leader pin **6**.
13. Use your fingers to remove the leader pin from the cavity **3** in the leader pin attach tool.
14. Use the cartridge manual rewind tool to wind the tape back into the cartridge (wind the tape clockwise). Ensure that the leader pin is latched by the pin-retaining spring clips on each end of the leader pin.
15. Remove the rewind tool.
16. Remove the leader pin attach tool by lifting its end away from the cartridge.

Environmental and shipping specifications for tape cartridges

Before you use a tape cartridge, acclimate it to the operating environment for 24 hours or the time necessary to prevent condensation in the drive. The time varies, depending on the environmental extremes to which the cartridge was exposed.

The best storage container for the cartridges (until they are opened) is the original shipping container. The plastic wrapping prevents dirt from accumulating on the cartridges and partially protects them from humidity changes.

When you ship a cartridge, place it in its jewel case or in a sealed, moisture-proof bag to protect it from moisture, contaminants, and physical damage. Ship the cartridge in a shipping container that has enough packing material to cushion the cartridge and prevent it from moving within the container.

Table 14 gives the environment for operating, storing, and shipping LTO Ultrium Tape Cartridges.

Table 14. Environment for operating, storing, and shipping the LTO Ultrium Tape Cartridge

Environmental Factor	Environmental Specifications			
	Operating	Operational Storage ¹	Archival Storage ²	Shipping
Temperature	10 - 45°C (50 - 113°F)	16 - 32°C (61 - 90°F)	16 - 25°C (61 - 77°F)	-23 to 49°C (-9 to 120°F)
Relative humidity (non-condensing)	10 - 80%	20 - 80%	20 - 50%	5 - 80%
Maximum wet bulb temperature	26°C (79°F)	26°C (79°F)	26°C (79°F)	26°C (79°F)
Note:				
1. The short term or operational storage environment is for storage durations of up to six months.				
2. The long term or archival storage environment is for durations of six months up to 10 years.				

Disposing of tape cartridges

Under the current rules of the US Environmental Protection Agency (EPA), regulation 40CFR261, the LTO Ultrium Tape Cartridge is classified as non-hazardous waste. As such, it might be disposed of in the same way as normal office trash. These regulations are amended from time to time, and you must review them at the time of disposal.

If your local, state, country (non-US), or regional regulations are more restrictive than EPA 40CFR261, you must review them before you dispose of a cartridge. Contact your account representative for information about the materials that are in the cartridge.

If a tape cartridge must be disposed of in a secure manner, you can erase the data on the cartridge with a high-energy ac degausser (use a minimum of 4000 oersted peak field over the entire space that the cartridge occupies). The tape must make two passes through the field at 90 degree orientation change for each pass to achieve complete erasure. Some commercial degaussers have two magnetic field regions offset 90 degrees from each other to accomplish complete erasure in one pass for higher throughput. Degaussing makes the cartridge unusable.

If you burn the cartridge and tape, ensure that the incineration complies with all applicable regulations.

Ordering media supplies

Table 15 lists the cartridges and media supplies that you can order for the drive.

Table 15. Media supplies

Supply Item	Methods of Ordering Specify the VOLSER characters that you want.
20-PACK IBM LTO Ultrium 8 12000 GB Data Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 552. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 8 12000 GB Data Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 652. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
5-PACK IBM LTO Ultrium 8 12000 GB Data Cartridge (black and white labels unattached)	Order as part number 01PL340 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 8 12000 GB WORM Tape Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 572. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 8 12000 GB WORM Tape Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 672. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 7 6000 GB Data Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 551. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 7 6000 GB Data Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 651. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
5-PACK IBM LTO Ultrium 7 6000 GB Data Cartridge (black and white labels unattached)	Order as part number 38L7189 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 7 6000 GB WORM Tape Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 571. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto

Table 15. Media supplies (continued)

Supply Item	Methods of Ordering Specify the VOLSER characters that you want.
20-PACK IBM Ultrium 7 6000 GB WORM Tape Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 671. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 6 2500 GB Data Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 550. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 6 2500 GB Data Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 650. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
5-PACK IBM LTO Ultrium 6 2500 GB Data Cartridge (black and white labels unattached)	Order as part number 35P1902 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 6 2500 GB WORM Tape Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 570. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 6 2500 GB WORM Tape Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 670. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 5 1500 GB Data Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 014. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 5 1500 GB Data Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 015. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
5-PACK IBM LTO Ultrium 5 1500 GB Data Cartridge (black and white labels unattached)	Order as part number 46C2084 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto

Table 15. Media supplies (continued)

Supply Item	Methods of Ordering Specify the VOLSER characters that you want.
20-PACK IBM Ultrium 5 1500 GB WORM Tape Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 034. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 5 1500 GB WORM Tape Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 035. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 4 800 GB Data Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 010. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM LTO Ultrium 4 800 GB Data Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 011. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
5-PACK IBM LTO Ultrium 4 800 GB Data Cartridge (black and white labels unattached)	Order as part number 95P4278 through an IBM-authorized distributor.
20-PACK IBM Ultrium 4 800 GB WORM Tape Cartridge (with attached labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 032. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
20-PACK IBM Ultrium 4 800 GB WORM Tape Cartridge (without labels)	Order the cartridge from your IBM Sales Representative or any authorized IBM Business Partner by specifying Machine Type 3589 Model 033. You can also order through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
IBM LTO Ultrium 3 400 GB Data Cartridge Order VOLSER labels separately (see "Ordering bar code labels" on page 57).	Order as part number 24R1922 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
IBM LTO Ultrium 3 400 GB WORM Tape Cartridge Order VOLSER labels separately (see "Ordering bar code labels" on page 57).	Order as part number 96P1203 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
IBM LTO Ultrium 2 200 GB Data Cartridge Order VOLSER labels separately (see "Ordering bar code labels" on page 57).	Order as part number 08L9870 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto

Table 15. Media supplies (continued)

Supply Item	Methods of Ordering Specify the VOLSER characters that you want.
IBM LTO Ultrium 1 100 GB Data Cartridge Order VOLSER labels separately (see "Ordering bar code labels").	Order as part number 08L9120 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
IBM LTO Ultrium Cleaning Cartridge (universal cleaning cartridge for use with Ultrium drives) VOLSER labels are included.	Order as part number 35L2086 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
Leader Pin Reattachment Kit	Order as part number 08L9129 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto
Manual Rewind Tool	Order as part number 08L9130 through an IBM-authorized distributor, or online at: http://www-1.ibm.com/storage/tape/lto

To find the closest IBM-authorized distributor, visit the web at <http://www.ibm.com/storage/media>) or call 1-888-IBM-MEDIA.

Ordering bar code labels

The LTO Ultrium Tape Drives do not require cartridge bar code labels. However, if you use your data cartridges or cleaning cartridges in an IBM tape library product, you might need cartridge bar code labels if your tape library product requires them (see Table 11 on page 41). You can order these labels separately from the IBM data cartridges and cleaning cartridges.

You can order bar code labels directly from the authorized label suppliers in Table 16.

Table 16. Authorized suppliers of custom bar code labels

In America	In Europe and Asia
EDP/Colorflex Broomfield, CO U. S. A. Telephone: 800-438-8362 http://www.tri-optic.com	EDP Europe, Ltd. U. K. Telephone: 44 (0) 1245-322380 http://www.edpeurope.com/media-label
Dataware Houston, TX 77274 U. S. A. Telephone: 800-426-4844 http://www.datawarelabels.com/	Dataware Labels Europe Australia Telephone: (029) 496-1111 http://www.datawarelabels.com/
NetC Trumbell, CT U. S. A. Telephone: 203-372-6382 http://www.netc11c.com/	NetC Europe Ltd U. K. Telephone: 44 (0) 1823 49 1439 http://www.netclabels.co.uk
	NetC Asia Pacific Pty Ltd Australia Telephone: 61 (0) 7 5442 6263 http://www.netclabels.com.au

Troubleshooting

If you encounter problems when running the drive, refer to the flowchart in Figure 26. For explanations of codes on the Single-character Display (SCD), see “Single-character display (SCD)” on page 13. Review the “Pre-call checklist” on page 62 before calling IBM Technical Support.




Figure 26. Flowchart for Analyzing Maintenance Problems

Procedure 1: Determining firmware level and capturing drive dump

Customers are responsible for updating Firmware. For optimum performance, the customer must obtain the current level of firmware for the unit by downloading the firmware from <http://www.ibm.com/support/fixcentral>.

The ITDT utility (see “ITDT firmware update, dump retrieval and library/drive test tool” on page 11) is used to update the firmware level and to capture a drive memory dump that might be requested by technical support to aid in problem analysis.

For instructions about updating firmware from a server that uses an IBM tape device driver, refer to the *IBM Tape Device Drivers Installation and User 's Guide*.

To update firmware from a server that uses a non-IBM tape device driver, refer to the documentation for that device driver.

Complete the following steps to determine the current firmware level that is installed on the drive.

1. Use the ITDT utility (available on the web at <http://www.ibm.com/support/fixcentral>) to view the current drive firmware level.
2. Compare this level with the current available firmware level by going to the same website. For information about the ITDT utility, see “Updating firmware” on page 10.

Note: The ITDT utility is used to either update drive firmware to the current level or to capture drive memory dumps from a drive that might be experiencing problems.

Another way to capture a drive memory dump is with the ethernet port. To capture a memory dump on the drive with the Ethernet interface, follow the steps.

Note: The drive uses a limited version of FTP protocol to communicate on the ethernet interface. It is recommended to use a simple, command-line FTP session, such as the DOS command prompt, when communicating with the drive.

1. Connect an ethernet patch cable to the drive 's ethernet interface and to a computer. To meet electromagnetic immunity requirements, a shielded ethernet cable is required.
2. Create an FTP session between the drive and the computer. The drive 's IP address: 169.254.0.3
3. At the user prompt, type `guest` and press **Enter**.
4. At the password prompt, press **Enter**. No response is needed.
5. Type `bin` to set the communication mode to binary.
6. Type `mget *.dmp` to transfer a drive memory dump to the computer. If a memory dump exists, the drive shows you the memory dump name and ask if you want to transfer it to the computer. Type `y` to transfer the existing memory dump or `n` to skip this dump file. Then, the drive asks if you want a forced memory dump. Type `y` to force a memory dump and to transfer the forced memory dump to the computer, or type `n` to skip forcing a memory dump.
7. Type `quit` to end the FTP session.
8. Remove ethernet patch cable from the drive's ethernet interface and the computer.

Procedure 2: Inspecting a cartridge for damage

If the cartridge fails to load or unload properly, complete the following steps:

1. Check that the leader pin is attached and properly seated (see “Repositioning a leader pin” on page 47) by opening the cartridge door and observing the pin's placement.
2. Inspect the cartridge case, the cartridge door, and the write-protect switch for damage.
3. Inspect the rear of the cartridge (the part that you load first into the tape load compartment). Ensure that there are no gaps in the seam of the cartridge case. See **1** in Figure 17 on page 46 and **4** in Figure 19 on page 48. If there are gaps, the leader pin might be dislodged. Go to “Repositioning or reattaching a leader pin” on page 47.
4. Try loading or unloading another tape cartridge.
 - If it fails, contact your service representative for problem determination.
 - If it is successful, discard the cartridge that originally failed.

Note:

1. If a damaged or mishandled cartridge is the problem, see “Handling the cartridges” on page 44 for instructions about handling the media. It is possible that your other cartridges might also be damaged.
2. If your cartridge does not eject properly, contact your service representative. (IBM service personnel must go to Appendix E, “Information for trained service personnel,” on page 83.)

Procedure 3: Checking SAS host connections

Check the host connections for your drive by following the steps.

If your server is not communicating with the SAS drive, the problem might be with the SAS cable, the SAS host adapter, or the SAS host adapter setup.

1. Check whether the tape drive power is on.
2. Verify that the SAS cable is connected properly to the server and to the tape drive.
3. Check whether the parameters for the SAS host adapter installation are correct.
4. Verify that the SAS host adaptor is supported by the tape drive.
5. Ensure that there is a point-to-point connectivity between the server and the tape drive. SAS connectivity does not support multiple drive connections (daisy-chaining of devices).
6. Check the length of the SAS cable. It cannot exceed 5.5 m (18 ft).

Procedure 4: Verifying host interface communications

The Wrap Diagnostic tests the communication function at the device interface. However, to thoroughly verify host-to-device communications, it is highly recommended to exercise activity over the SAS interface bus from the host to the drive and back. A recommended utility to complete this test is the ITDT utility available on the web at <http://www.ibm.com/support/fixcentral>. This utility is especially effective for updating the drive firmware and for completing the Test Device function. For more information about the ITDT utility, see “Updating firmware” on page 10. Complete these steps:

1. If the ITDT utility is not installed on your system, download the appropriate operating system version from the web into a directory or folder of your choice.
2. When installation is complete, run the SCAN (s) option to determine whether your system can detect all of the Ultrium tape drive devices (including any libraries or autoloaders that might be on the bus).
3. Select the drive that is to be tested or to have firmware that is downloaded.
4. For testing, select the Test Device (t) option.

Note: This option completes a series of LOADS, UNLOADS, and WRITE/READ operations. Both tape drive control commands and data are sent to the device over the interface bus.

5. If allowed to complete, the test runs for at least 30 minutes. At any time an ABORT (a) is entered to end the device test early if it is determined that interface communications are satisfactorily achieved.

Resolving problems reported by the server

The procedure for fixing interface bus errors varies, depending on whether the error is consistent or intermittent, and on your configuration. These sections describe how to fix an error.

Fixing SAS bus errors

1. Check whether the tape drive power is on.
2. Verify that the SAS cable is connected properly to the server and to the tape drive.
3. Replace SAS cable if it shows any signs of damage.

Resolving media-related problems

To resolve problems that are related to media, the drive 's firmware includes

- Test Cartridge & Media diagnostic test that verifies whether a suspect cartridge and its magnetic tape are acceptable for use.
- Statistical Analysis and Reporting System (SARS) to help with isolating failures between media and hardware. To determine the cause of failure, SARS uses the cartridge performance history that is saved in the cartridge memory (CM) and the drive performance history that is kept in the drive 's VPD (Vital Product Data) area in NVRAM. Any failures that SARS detects are reported as TapeAlert flags on the server (see *IBM LTO Ultrium Tape Drive SCSI Reference*).

Attention: If you insert the IBM LTO Ultrium Data Cartridge into another manufacturer 's drive, the SARS data in the cartridge memory might become lost or invalid.

If you encounter a media-related problem, refer to “Function code E: Test cartridge & media” on page 29.

Pre-call checklist

If you have questions or problems, go through this checklist before IBM technical support is contacted. Ensure that the total SAS cable length does not exceed 5.5 m (18 ft). Complete these steps before you call IBM technical support. Where instructions refer you to the web, visit <http://www.ibm.com/support/fixcentral>.

1. Perform a general checkup of the hardware and connections:
 - Verify that all cables are connected properly at both ends.
 - Before the SAS cables are attached, ensure that the connector does not contain bent or recessed pins.
 - Ensure that all retention screws for the SAS cable are securely tightened.
2. Verify that the drive's firmware is at the most recent level. To determine the latest release of firmware, visit the web. See “Updating firmware” on page 10 for instructions about downloading the latest firmware.
3. Verify that your device drivers are at the most recent level:
 - For IBM device drivers, visit the web.
 - For the device drivers of independent software vendors (ISVs), visit the appropriate third-party website.
4. Verify whether your hardware and software configuration is supported. To determine the latest supported attachments, visit the web.
5. Review “Frequently Asked Questions and Hints and Tips” on the web.
6. Run one of the diagnostic methods:
 - Local diagnostic tests:
 - a. Run “Function code 1: Run drive diagnostics” on page 24 to determine whether the drive can properly load and unload cartridges, and read and write data. Optionally, you might run one of the following diagnostic procedures:
 - “Function code E: Test cartridge & media” on page 29 to determine whether a suspect cartridge and its magnetic tape are acceptable.
 - “Function code F: Write performance test” on page 30 to ensure that the drive can read from and write to tape.
 - “Function code H: Test head” on page 31 to ensure that the tape drive's head and tape-carriage mechanics work correctly.
 - “Function code J: Fast read/write test” on page 32 to ensure that the drive can read from and write to tape.
 - “Function code L: Load/unload test” on page 32 to test the drive's ability to load and unload a tape cartridge.

- b. Run "Function code 6: Run host interface wrap test" on page 27.
- Remote diagnostic test:
 - With the ITDT utility, run the SCAN as described in "Procedure 4: Verifying host interface communications" on page 61

Replacing the tape drive

To replace your tape drive, complete these steps:

1. Remove the replacement unit from its packaging.
2. Locate the repair identification (RID) tag (included with the replacement unit). See **1** in Figure 27)
3. Write down the serial number of the failed unit on the RID tag.
4. Affix the repair tag to the rear panel of the replacement unit (below the serial number label).
5. Place the failed unit into the packaging of the replacement unit.
6. Follow the instructions (included with the replacement unit) for returning the failed unit.




Figure 27. RID tag on rear panel

Appendix A. Error codes and messages

If the drive detects a permanent error, it displays the error code on the SCD and flashes the Fault light (Ready light is Off).

- Make note of the SCD error code before a cartridge is removed or the SCD error code is cleared.
- If an error occurred with a cartridge in the drive, push **Unload** to eject the cartridge.
- To clear the SCD error code and power cycle the drive, press **Unload** for 10 seconds. A drive memory dump is created.


Attention: If the drive detects a permanent error, and displays an error code other than , it automatically completes a drive memory dump. If you force a drive memory dump, the existing memory dump is overwritten and data is lost. After you force a drive memory dump, do not turn off the power to the drive or you might lose the memory dump data.

Table 17. Error codes on the Single-character Display




Error Code	Cause and Action
	No error occurred and no action is required. This code displays when diagnostic tests are finished running and no error occurred. Note: The Single-character Display is blank during normal operation of the tape drive.
	Temperature problem. The tape drive detected that the recommended operating temperature was exceeded. Complete one or more of these actions: <ul style="list-style-type: none"> • Ensure that the cooling fan is rotating and is quiet. If not, refer to your enclosure documentation. • Remove any blockage that prevents air from flowing freely through the tape drive. • Ensure that the operating temperature and airflow is within the specified range (see “Specifications” on page 6). Clear the error code by power-cycling the tape drive or placing the drive in Maintenance mode. If the operating temperature and airflow are within the specified range, and the problem persists, replace the drive.
	Power problem. The tape drive detected that the externally supplied power is outside the specified voltage limits (the tape drive is not operating). Complete this action: <ol style="list-style-type: none"> 1. Ensure that the power connector is properly seated. 2. Turn power off/on the tape drive to see whether the problem repeats. 3. Replace the tape drive if the problem persists. The error code clears when you place the tape drive in maintenance mode.

Table 17. Error codes on the Single-character Display (continued)

Error Code	Cause and Action
3	<p>Firmware problem. The tape drive determined that a firmware error occurred. Complete this action:</p> <ol style="list-style-type: none"> 1. Collect a drive memory dump. Note: Do not force a new memory dump; the tape drive created one. <ul style="list-style-type: none"> • Server 's host interface with a device driver utility or system tool such as ITDT. For instructions about ITDT, visit the web at http://www.ibm.com/support/fixcentral. • Ultrium tape drive (to copy and read a drive memory dump, use "Function code 5: Copy drive dump" on page 26) 2. Power the tape drive off and on, then retry the operation that produced the error. 3. If the problem persists, download new firmware and retry the operation. 4. If the problem persists, send the drive memory dump that you collected in step 1 to your IBM Support Center. <p>The error code clears when you place the tape drive in Maintenance mode.</p>
4	<p>Firmware or hardware problem. The tape drive determined that a firmware or tape drive hardware failure occurred. Complete this action:</p> <ol style="list-style-type: none"> 1. Collect a drive dump. Note: Do not force a new memory dump; one exists. <ul style="list-style-type: none"> • Server 's host interface with a device driver utility or system tool such as ITDT. For instructions about using ITDT, visit the web at http://www.ibm.com/support/fixcentral. • Ultrium tape drive (to copy and read a drive memory dump, use "Function code 5: Copy drive dump" on page 26) 2. Power the tape drive off and on, then retry the operation that produced the error. The error code clears when you place the tape drive in Maintenance mode. 3. If the problem persists, download new firmware and retry the operation; if new firmware is not available, replace the drive.
5	<p>Tape drive hardware problem. The drive determined that a tape path or read/write error occurred. To prevent damage to the drive or tape, you cannot insert a cartridge if the current cartridge was successfully ejected. The error code might clear when you cycle power to the tape drive or place it in maintenance mode. If the problem persists, replace the drive. Note: Copy the drive memory dump to flash memory before the drive is returned. For instructions, refer to "Function code 5: Copy drive dump" on page 26.</p>
6	<p>Tape drive or media error. The tape drive determined that an error occurred, but it cannot isolate the error to faulty hardware or to the tape cartridge. Ensure that the tape cartridge is the correct media type:</p> <ul style="list-style-type: none"> • Ultrium 1, 2, 3, 4, 5, and 6 cartridges are not supported in the Ultrium 8 tape drive. • Drive does not accept an expired Cleaning Cartridge. • Drive does not accept a WORM cartridge when diagnostic tests are run in Maintenance mode. • Drive does not write over existing data sets on a WORM cartridge. Ensure that you are appending data sets on WORM media rather than attempting to write over existing data sets. <p>If the tape cartridge is the correct media type, complete this action:</p>

Table 17. Error codes on the Single-character Display (continued)

Error Code	Cause and Action
	<p>Problems with Writing Data</p> <p>If the problem occurred while the tape drive was writing data to the tape, retry the operation with a different cartridge:</p> <ul style="list-style-type: none"> • If the operation succeeds, the original cartridge was defective. Copy data from the defective cartridge and discard it. • If the operation fails and another tape drive is available, insert the cartridge into the other unit and retry the operation. <ul style="list-style-type: none"> – If the operation fails, discard the defective cartridge. – If the operation succeeds, insert a scratch data cartridge into the first unit and run “Function code 1: Run drive diagnostics” on page 24. <ul style="list-style-type: none"> - If the diagnostic tests fail, replace the tape drive. - If the diagnostic tests succeed, the error was temporary. • If the operation fails and another tape drive is not available, insert a scratch data cartridge into the unit and run “Function code 1: Run drive diagnostics” on page 24. <ul style="list-style-type: none"> – If the diagnostic tests fail, replace the tape drive. – If the diagnostic tests succeed, discard the cartridge. <p>If the problem occurs with multiple tape cartridges, run “Function code 1: Run drive diagnostics” on page 24:</p> <ul style="list-style-type: none"> • If the diagnostic tests fail, replace the tape drive. • If the diagnostic tests succeed, run “Function code H: Test head” on page 31. <ul style="list-style-type: none"> – If the diagnostic test fails, replace the tape drive. – If the diagnostic test succeeds, replace the cartridges that caused the problem. <p>The error code clears when you remove the tape cartridge or place the tape drive in Maintenance mode.</p> <p>Problems with Reading Data</p> <p>If the problem occurred while the tape drive was reading data from the tape, complete one of these procedures:</p> <ul style="list-style-type: none"> • If another tape drive is available, insert the cartridge into the other unit and retry the operation: <ul style="list-style-type: none"> – If the operation fails, discard the defective cartridge. – If the operation succeeds, insert a scratch data cartridge into the first unit and run “Function code 1: Run drive diagnostics” on page 24: <ul style="list-style-type: none"> - If the diagnostic test fails, replace the tape drive. - If the diagnostic test succeeds, the error was temporary. • If another tape drive is not available, insert a scratch data cartridge into the unit and run “Function code 1: Run drive diagnostics” on page 24: <ul style="list-style-type: none"> – If the diagnostic test fails, replace the tape drive. – If the diagnostic test succeeds, discard the cartridge. <p>If the problem occurs with multiple tape cartridges, run “Function code 1: Run drive diagnostics” on page 24.</p> <ul style="list-style-type: none"> • If the diagnostic test fails, replace the tape drive. • If the diagnostic test succeeds, run “Function code H: Test head” on page 31. <ul style="list-style-type: none"> – If the diagnostic test fails, replace the tape drive. – If the diagnostic test succeeds, replace the cartridges that caused the problem. <p>The error code clears when you remove the tape cartridge or place the tape drive in Maintenance mode.</p>

Table 17. Error codes on the Single-character Display (continued)

Error Code	Cause and Action
<p style="text-align: center;">7</p>	<p>Media error. The tape drive determined an error occurred because of a faulty tape cartridge or an invalid tape cartridge. Ensure that the tape cartridge is the correct media type:</p> <ul style="list-style-type: none"> • Ultrium 1, 2, 3, 4, 5, and 6 cartridges are not supported in the Ultrium 8 tape drive. • Drive does not accept an expired Cleaning Cartridge. • Drive does not accept a WORM cartridge when diagnostic tests are run in Maintenance mode. • Drive does not accept an FMR tape unless the drive is completing "Function code 8: Unmake FMR tape" on page 28. • Drive does not write over existing data sets on a WORM cartridge. Ensure that you are appending data sets on WORM media rather than attempting to write over existing data sets. • Drive does not Create an FMR Tape (Maintenance mode, Function code 3) with a cartridge that is already an FMR tape. Use another cartridge or run Maintenance mode Function code 8: Unmake FMR tape. • Drive does not Unmake FMR tape (Maintenance code 8) with a cartridge that is not an FMR tape. <p>If the tape cartridge is the correct media type, try another tape cartridge. If the problem occurs with multiple tape cartridges, use this procedure:</p> <ol style="list-style-type: none"> 1. If possible, run the tape cartridge in a different tape drive. Replace the media if the operation in the other unit fails, and 6 or 7 displays. If the operation succeeds, run "Function code E: Test cartridge & media" on page 29. <p>Attention: When you run the Test Cartridge & Media diagnostic test, data on the suspect tape is overwritten. Use only a scratch data cartridge to run the test.</p> <ul style="list-style-type: none"> • If the diagnostic test fails, replace the media. • If the diagnostic test succeeds, clean the drive head (see "Cleaning the drive head" on page 19) and run "Function code 1: Run drive diagnostics" on page 24. <ul style="list-style-type: none"> – If the drive diagnostic test fails, replace the drive. – If the drive diagnostic test succeeds, complete the operation that produced the initial media error. <p>The error code clears when you remove the tape cartridge or place the tape drive in Maintenance mode.</p>
<p style="text-align: center;">8</p>	<p>Interface problem. The tape drive determined that a failure occurred in the tape drive 's hardware or in the host bus. See "Troubleshooting" on page 59. If 8 displays while "Function Code 6: Host Interface Test" was running:</p> <ol style="list-style-type: none"> 1. Verify that the correct interface wrap tool was attached in the correct interface port during the test. The test fails if the correct interface wrap tool is not attached. <p>Note: The interface wrap test is not supported on the USB port and displays an invalid error if run.</p> 2. If the correct interface wrap tool was attached during the test, replace the drive. The error code clears when you place the tape drive in Maintenance mode.
<p style="text-align: center;">9</p>	<p>Tape drive or RS-422 error. The tape drive determined that a failure occurred in the tape drive 's hardware or in the RS-422 connection. See "Function code 7: Run RS-422 wrap test" on page 28 or refer to the library procedures to isolate the problem to the drive. The error code clears when you place the tape drive in Maintenance mode.</p>

Table 17. Error codes on the Single-character Display (continued)






Error Code	Cause and Action
	<p>Degraded operation. The tape drive determined that a problem occurred which degraded the operation of the tape drive, but it did not restrict continued use. If the problem persists, determine whether the problem is with the drive or the media.</p> <p>Note: The drive is usable, though the Single-character Display continues to indicate an error and the Fault light flashes. The error code might clear when you cycle power to the tape drive or place it in Maintenance mode.</p> <p>To determine whether the problem is with the drive hardware, or the tape media, complete these procedures:</p> <ol style="list-style-type: none"> 1. If possible, run the tape cartridge in a different drive. Replace the media if the operation in the other drive fails, and  or  displays. If the operation succeeds, run the Test Cartridge & Media diagnostic test (see "Function code E: Test cartridge & media" on page 29). 2. If the Test Cartridge & Media diagnostic test fails, replace the media. If it runs successfully, clean the failing drive and run the drive diagnostic tests (see "Cleaning the drive head" on page 19 and "Function code 1: Run drive diagnostics" on page 24). When you begin this test, the diagnostic test begins the loop sequence. Time the first loop by pressing Unload once to stop the diagnostic test after the completion of the first loop, then record the time that it takes for the test to complete. Compare the recorded time with the "Approximate Run Time". If the test runs successfully but the execution time is longer than the "Approximate Run Time", run "Function code F: Write performance test" on page 30. If the Write Performance Test fails, replace the media and exit Maintenance mode. If the drive diagnostic tests run successfully, complete the operation that produced the initial drive error. 3. If the problem persists, replace the drive. <p>If it is not possible to run the tape cartridge in a different drive, complete these procedures:</p> <ol style="list-style-type: none"> 1. Clean the failing drive and run the drive diagnostic tests (see "Cleaning the drive head" on page 19 and "Function code 1: Run drive diagnostics" on page 24). When you begin this test, the diagnostic test begins the loop sequence. Time the first loop by pressing Unload once to stop the diagnostic test after the completion of the first loop, then record the time that it takes for the test to complete. Compare the recorded time with the "Approximate Run Time". If the test runs successfully but the execution time is longer than the "Approximate Run Time", run "Function code F: Write performance test" on page 30. If the Write Performance Test fails, replace the media and exit Maintenance mode. If the drive diagnostic tests run successfully, run the Test Cartridge & Media diagnostic test (see "Function code E: Test cartridge & media" on page 29). 2. If the Test Cartridge & Media diagnostic test fails, replace the media. If it runs successfully, complete the operation that produced the initial drive error. 3. If the problem persists, replace the drive.
	<p>The tape drive must be cleaned. Clean the tape drive. See "Cleaning the drive head" on page 19.</p> <p>The error code clears when you clean the tape drive or place it in Maintenance mode.</p>
	<p>Fiber AL_PA conflict. Two drives on fiber loop have the same AL_PA. Modify the tape drive AL_PA to eliminate the conflict. NOT SUPPORTED ON THIS DRIVE.</p>

Table 17. Error codes on the Single-character Display (continued)

Error Code	Cause and Action
<p style="text-align: center;">E</p>	<p>Encryption Error. Displayed when the drive detects an error that is associated with an encryption operation. If the problem occurred while the tape drive was writing data to, or reading data from, tape:</p> <ol style="list-style-type: none"> 1. Check the host application to ensure that the host application is providing the correct encryption key. <ul style="list-style-type: none"> • Refer to the <i>IBM LTO Ultrium Tape Drive SCSI Reference</i> documentation for the sense data that is returned for an encryption operation. • Retry the encryption operation after the host application problems are resolved. 2. Check the operation of the tape drive by resetting the drive and running POST. See Table 5 on page 16. <ul style="list-style-type: none"> • Refer to the error code displayed on the SCD if the drive reset and POST fails. • Retry the encryption operation if the drive reset and POST complete without errors. 3. Check the media. <ul style="list-style-type: none"> • Ensure that the correct media is used. Data encryption is supported by LTO Ultrium 4 and later Data Cartridges only. • Retry the encryption operation with the tape cartridge in another encryption enabled drive. Replace the media if the problem repeats with the same tape cartridge in multiple drives. <p>If the problem occurred while the tape drive was running POST or diagnostic tests, replace the drive.</p> <p>The error code clears with the first attempted write/read after the encryption key is changed, or when the drive is placed in Maintenance mode.</p>
<p style="text-align: center;">E</p>	<p>Fiber Port offline. NOT SUPPORTED ON THIS DRIVE.</p>
<p style="text-align: center;">F</p>	<p>Fibre Channel error. NOT SUPPORTED ON THIS DRIVE.</p>
<p style="text-align: center;">J</p>	<p>Incompatible media. The tape drive detected that an unsupported cartridge was loaded or the cartridge that is loaded has an incompatible format.</p>
<p style="text-align: center;">P</p>	<p>Write operation to a write protected cartridge was attempted (includes any attempt to overwrite a WORM protected tape). Ensure that the tape cartridge is the correct media type. If the tape cartridge is the correct media type, check the write-protect switch on the cartridge. The drive does not write to a write-protected cartridge. The error code clears when you remove the tape cartridge or place the tape drive in Maintenance mode.</p>

Appendix B. TapeAlert flags

TapeAlert is a patented technology and standard of the American National Standards Institute (ANSI) that defines conditions and problems that are experienced by tape drives. The technology enables a server to read TapeAlert flags from a tape drive through the host interface. The server reads the flags from Log Sense Page 0x2E. Refer to the *IBM LTO Ultrium Tape Drive SCSI Reference* for the list of TapeAlert flags that are supported by this tape drive.

Appendix C. Ordering optional features, replacement parts, and power cords

For more information on ordering, see “Optional features,” “Replacement parts,” and “Power cords” on page 74.

For more information about ordering media and bar code labels, see “Ordering media supplies” on page 54.

Optional features

Table 18. Optional features

Feature Code	Description
5402	2.0 m SAS/Mini-SAS 1x Cable
5501	1.0 m Mini-SAS/Mini-SAS 1x Cable
5502	2.0 m Mini-SAS/Mini-SAS 1x Cable
5507	4.0 m Mini-SAS HD/Mini-SAS 1x
5509	3.0 m Mini-SAS HD/Mini-SAS 2x Cable

Replacement parts

Table 19. Replacement parts

Part Number	Description
01PL152	TS2280 (3580-H8S) Half Height SAS Bridgebox CRU - dual SAS ports
00VJ140	2 m SAS/Mini-SAS 1x Cable
00VJ139	2 m Mini-SAS/Mini-SAS 1x Cable
95P6566	SAS wrap tool
12X4292	1.0 m Mini-SAS/Mini-SAS 1x Cable
46C2900	4.0 m Mini-SAS HD/Mini-SAS 1x Cable
46C2902	3.0 m Mini-SAS HD/Mini-SAS 2x Cable

Power cords



To avoid electrical shock, a power cord with a grounded attachment plug is provided. Use only properly grounded outlets.

The table lists the power cord part number, feature code, the country, or region where the power cord can be used, and the plug 's standard reference. The last column in the table contains an index number that you can match to a specific receptacle type in Figure 28 on page 77.

All power cords use an appliance coupler that complies with the International Electrotechnical Commission (IEC) Standard 320, Sheet C13.

If the power cord that you receive does not match your receptacle, contact your local dealer.

Power cords that are used in the United States and Canada are listed by Underwriter 's Laboratories (UL), are certified by the Canadian Standards Association (CSA), and comply with the plug standards of the National Electrical Manufacturers Association (NEMA). For other worldwide geographies, plug standards are listed in the table.

Table 20. Power cords

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 28 on page 77
US/Canada <ul style="list-style-type: none"> • 2.8 m, 125 V • FC 9800 • PN 39M5081 • (See Note) 	NEMA 5-15P	Aruba, Bahamas, Barbados, Bermuda, Bolivia, Brazil, Canada, Cayman Islands, Colombia, Costa Rica, Curacao, Dominican Republic, Ecuador, El Salvador, Guatemala, Guyana, Haiti, Honduras, Jamaica, Japan, Liberia, Mexico, Netherlands Antilles, Nicaragua, Panama, Peru, Philippines, Saudi Arabia, South Korea, Suriname, Taiwan, Trinidad Tobago, Venezuela, US	1
Chicago <ul style="list-style-type: none"> • 1.8 m, 125 V • FC 9986 • PN 39M5080 	NEMA 5-15P	Chicago, US	1
US/Canada <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9833 • PN 39M5095 	NEMA 6-15P	Aruba, Bahamas, Barbados, Bermuda, Bolivia, Brazil, Canada, Cayman Islands, Costa Rica, Curacao, Dominican Republic, Ecuador, El Salvador, Guatemala, Guyana, Haiti, Honduras, Jamaica, Japan, Liberia, Netherlands Antilles, Nicaragua, Panama, Peru, Philippines, Suriname, Taiwan, Thailand, Trinidad Tobago, Venezuela, US	2
Australia <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9831 • PN 39M5102 	AS 3112 NZS 198	Argentina, Australia, China, Colombia, New Zealand, Papua New Guinea, Paraguay, Uruguay, Western Samoa	3
France, Germany <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9820 • PN 39M5123 	CEE 7 - VII	Afghanistan, Algeria, Andorra, Angola, Aruba, Austria, Belgium, Benin, Brazil, Bulgaria, Burkina Faso, Burundi, Cameroon, Central African Republic, Chad, Congo-Brazzaville, Curacao, Czech Republic, Democratic Republic of Congo, Denmark, Egypt, Finland, France, French Guiana, Germany, Greece, Guinea, Hungary, Iceland, Indonesia, Iran, Ivory Coast, Jordan, Kenya, Korea, Lebanon, Luxembourg, Macau, Malagasy, Mali, Martinique, Mauritania, Mauritius, Monaco, Morocco, Mozambique, Netherlands, Netherlands Antilles, New Caledonia, Niger, Norway, Poland, Portugal, Romania, Russia, Saudi Arabia, Senegal, Spain, Sweden, Sudan, Syria, Togo, Tunisia, Turkey, Yugoslavia, Zaire, Zimbabwe, Vietnam	4

Table 20. Power cords (continued)

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 28 on page 77
Denmark <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9821 • PN 39M5130 	DK2-5A	Denmark	5
South Africa <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9829 • PN 39M5144 	SABS 164	Bangladesh, Burma, Pakistan, South Africa, Sri Lanka	6
United Kingdom <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9825 • PN 39M5151 	BS 1363	Antigua, Bahrain, Bermuda, Brunei, Channel Islands, China (Hong Kong S.A.R.), Cyprus, Fiji, Ghana, Guyana, India, Iraq, Ireland, Jordan, Kenya, Kuwait, Malaysia, Malawi, Malta, Nepal, Nigeria, Oman, Polynesia, Qatar, Sierra Leone, Singapore, Tanzania, Uganda, UK, United Arab Emirate (Dubai), Yemen, Zambia	7
Switzerland <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9828 • PN 39M5158 	SEV SN 416534	Liechtenstein, Switzerland	8
Italy <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9830 • PN 39M5165 	CEI 23- 16	Chile, Ethiopia, Italy, Libya, Somalia	9
Israel <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9827 • PN 39M5172 	S11-32-1971	Israel	10
Argentina <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9834 • PN 39M5068 	IEC 83-A5	Argentina, Brazil, Colombia, Paraguay, Trinidad Tobago, Uruguay	11
China <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9840 • PN 39M5206 	CCEE	People 's Republic of China	12
Taiwan LV* <ul style="list-style-type: none"> • 2.8 m, 125 V • FC 9835 • PN 39M5247 	CNS 10917-3	Taiwan	13
Taiwan HV** <ul style="list-style-type: none"> • 2.8 m, 250 V • FC 9841 • PN 39M5254 	CNS 10917-3	Taiwan	14
Japan LV* <ul style="list-style-type: none"> • 2.8 m, 125 V • FC 9842 • PN 39M5199 	JIS C8303, C8306	Japan	15

Table 20. Power cords (continued)

Description, Feature Code (FC), and Part Number (PN)	Plug Standard Reference	Country or Region	Index Number in Figure 28 on page 77
Korea HV** • 2.8 m, 250 V • FC 9844 • PN 39M5219	KS C8305, K60884-1	Korea	17
India HV** • 2.8 m, 250 V • FC 9845 • PN 39M5226	IS 6538	India	18
Brazil HV** • 2.8 m, 250 V • FC 9847 • PN 39M5240	InMetro NBR 14136	Brazil	20
* Low Voltage ** Height Voltage			

Types of Receptacles

The figure shows the plugs that are available on the power cords in “Power cords” on page 74. Match the index number that is beside each plug to the index number in Table 20 on page 74.




Figure 28. Types of receptacles

Appendix D. Installing a 19-inch rack mount kit (optional)

Before you begin, read these instructions to familiarize yourself with the installation procedure.

Rack safety

This general safety information must be used for all rack-mounted devices:

DANGER

- Always lower the leveling pads on the rack cabinet.
- Always install stabilizer brackets on the rack cabinet.
- To avoid hazardous conditions because of uneven mechanical loading, always install the heaviest devices in the bottom of the rack cabinet. Always install servers and optional devices starting from the bottom of the rack cabinet.
- Rack-mounted devices are not to be used as a shelf or workspace. Do not place any object on top of rack-mounted devices.
- Each rack cabinet might have more than one power cord. Be sure to disconnect all power cords in the rack cabinet before any device is serviced in the rack cabinet.
- Connect all devices that are installed in a rack cabinet to power devices installed in the same rack cabinet. Do not plug a power cord from a device that is installed in one rack cabinet into a power device that is installed in a different rack cabinet.
- An electrical outlet that is not correctly wired can place hazardous voltage on the metal parts of the system or the devices that attach to the system. It is the responsibility of the customer to ensure that the outlet is correctly wired and grounded to prevent an electrical shock.

CAUTION:

- Do not install a unit in a rack where the internal rack ambient temperatures exceeds the manufacturer 's recommended ambient temperature for all your rack-mounted devices.
- Do not install a unit in a rack where the air flow is compromised. Ensure that air flow is not blocked or reduced on any side, front, or back of a unit that is used for air flow through the unit.
- Consideration must be given to the connection of the equipment to the supply circuit so that overloading of the circuits does not compromise the supply wiring or overcurrent protection. To provide the correct power connection to a rack, refer to the rating labels on the equipment in the rack to determine the total power requirement of the supply circuit.
- (*For sliding drawers.*) Do not pull out or install any drawer or feature if the rack stabilizer brackets are not attached to the rack. Do not pull out more than one drawer at a time. The rack can become unstable if you pull out more than one drawer at a time.
- (*For fixed drawers.*) This drawer is a fixed drawer and must not be moved for servicing unless specified by manufacturer. Attempting to move the drawer partially or completely out of the rack can cause the rack to become unstable or cause the drawer to fall out of the rack.

CAUTION:

Removing components from the upper positions in the rack cabinet improves rack stability during relocation. Follow these general guidelines whenever you relocate a populated rack cabinet within a room or building:

- Reduce the weight of the rack cabinet by removing equipment, starting at the top of the rack cabinet. When possible, restore the rack cabinet to the configuration of the rack cabinet as you received it. If this configuration is not known, you must do these procedures:
 - Remove all devices in the 32U position and above.
 - Ensure that the heaviest devices are installed in the bottom of the rack cabinet.
 - Ensure that there are no empty U-levels between devices that are installed in the rack cabinet below the 32U level.
- If the rack cabinet you are relocating is part of a suite of rack cabinets, detach the rack cabinet from the suite.
- Inspect the route that you plan to take to eliminate potential hazards.
- Verify that the route that you choose can support the weight of the loaded rack cabinet. Refer to the documentation that comes with your rack cabinet for the weight of a loaded rack cabinet.
- Verify that all door openings are at least 760 x 230 mm (30 x 80 in.).
- Ensure that all devices, shelves, drawers, doors, and cables are secure.
- Ensure that the four leveling pads are raised to their highest position.
- Ensure that there is no stabilizer bracket that is installed on the rack cabinet during movement.
- Do not use a ramp that is inclined at more than 10 degrees.
- Once the rack cabinet is in the new location, do these procedures:
 - Lower the four leveling pads.
 - Install stabilizer brackets on the rack cabinet.
 - If you removed any devices from the rack cabinet, repopulate the rack cabinet from the lowest position to the highest position.
- If a long-distance relocation is required, restore the rack cabinet to the configuration of the rack cabinet as you received it. Pack the rack cabinet in the original packaging material, or equivalent. Also, lower the leveling pads to raise the casters off of the pallet and bolt the rack cabinet to the pallet.

(R002)

Verify kit contents

Qty	Description
1	fixed shelf
4	screws
2	tie wraps
	Installation Instructions (Feature 7003)

Tools required

- 7 mm nut driver or 7 mm socket wrench

Installing the shelf

1. Decide at what level you want to install the shelf. The 3580 requires two units (EIAs) of rack space (see **2** in Figure 29 on page 81).

Note: All vertical rack measurements are given in rack units (U). One U is equal to 4.45 cm (1.75 in.). The U levels are marked on labels on one front mounting rail and one rear mounting rail.

2. With the sides and back of the shelf facing up, carefully lift the shelf into the rack between the front and back rack rails with the shelf flanges behind the front rack rails.
3. Align the holes in the shelf flange exactly with the holes in the front rack rails.
4. Holding the shelf **1** level, insert a screw through the top hole **3** in each front flange of the shelf. Loosely thread the screws into the front mounting rails.




Figure 29. Front view of shelf attached to rack rails

5. Check that the shelf is at the same level on the four mounting rails.
6. Insert a screw through the bottom hole **4** in each front flange of the shelf. Loosely thread the screws into the front mounting rails.
7. Tighten all mounting screws with a 7 mm nut driver or a 7 mm socket wrench.
8. Route cables down one of the rear rack rails by threading each tie wrap (see **5** in Figure 30) through a hole in the rail and around the cables. One tie wrap must be located near the rear of the 3580; the other must be located farther down the rack rail. Tighten cable ties securely around the cables so the cables cannot be pulled out. Cut off tie wrap excess.



Figure 30. Rear view of shelf with cables attached to rack rails with tie wraps

The shelf installation is complete. You can now install your equipment on the shelf.

Removing the shelf from the rack

To remove the shelf from the rack, reverse the steps in the installation procedure.

Appendix E. Information for trained service personnel

Attention

- It is strongly recommended that the drive and stuck tape be returned to IBM for removal and recovery.
- If the cartridge in the drive is an INPUT tape containing ACTIVE or 'ONLY COPY' data (i.e., there is no backup), eject commands issued at the host fail to unload the tape, and power-cycling the drive fails to eject the cartridge, make no further attempts to unload this tape. Call Technical Support and open a PMR if one isn't already open, to initiate the process of sending the drive with the loaded cartridge in for recovery.
- These procedures must be performed only by a trained IBM service provider. SSRs should claim their time against service code 33 ECA 013 when performing this procedure.
- Inform the customer the following procedure has high risk of damaging the drive and high risk of not being able to recover the data.

Removing the internal drive

This procedure is to be completed by IBM service personnel only.

Note: One of the four screws that secure the cover to the chassis is a tamperproof screw. A T20 Torx tamperproof screwdriver is required to remove the cover.

Step 1. Removing the cover

1. Unplug all cables from the rear panel of the unit.
2. Move the unit to a clean and sturdy work surface.
3. Turn the unit on its side with the bottom of the unit facing you.
4. Remove the 4 screws (**1** in Figure 31 on page 84) by the feet.




Figure 31. Removing the screws that secure the cover and internal drive

5. Return the unit to its upright position.
6. Gently push the drive 's rear panel to remove the chassis from the cover (see Figure 32 on page 85).

Step 2. Removing the internal drive





Figure 32. Removing cables from the internal drive

1. Unplug the SAS interface cable and the ethernet interface cable (**1** and **2** in Figure 32) from the drive. Disconnecting the internal SAS interface cable disconnects both the SAS interface and electrical power from the drive.

Attention: DO NOT UNPLUG THE INTERNAL POWER CABLE.

2. Press the latch assembly to release the drive.


a80hh045



a80hh046

Figure 33. Releasing the drive from the chassis

3. Slide the internal drive forward towards the front of the chassis to clear the front bezel.



a80hh047

Figure 34. Sliding the drive forward

Manually removing a tape cartridge

This Procedure is to be performed by IBM service personnel only.

The purpose of this section is to assist you in determining the condition of the cartridge or the magnetic tape and to direct you to the procedure you must follow to remove the cartridge.

Attention

- The best solution for recovering data on a damaged cartridge is to send it to IBM for professional data recovery.
- Before this procedure is used, you must exhaust all other means of removing the tape cartridge from the drive. Use this procedure only if you cannot remove the tape cartridge with any other means.
- Determine from the customer if the cartridge contains critical customer data. If the cartridge contains sensitive data that cannot leave the site, inform the customer that certain failure conditions diagnostic tests are done to test the drive for continued use.
- The following removal procedures can destroy customer data! Use extreme care when handling or removing the customer's tape cartridges to minimize tape damage and lost data.

- DO NOT TOUCH the magnetic tape or tape path. Both are sensitive to the oil and salt from your skin. Use clean, lint-free gloves when working around magnetic tape or the tape path components.
- Electrostatic-sensitive components: Consider using an ESD Kit.
- After you remove the tape cartridge, advise the customer to copy the data to another cartridge and to remove this tape cartridge from service.
- Do not use power tools or magnetic tools to complete this procedure.
- To avoid contamination and electrostatic-discharge damage to the drive, never touch the head or electronic components inside the drive.
- If you cannot remove the cartridge from the drive with the following procedures, contact your next level of support.
- The cartridge does not eject automatically at the end of a mid-tape recovery. Instead, the tape is reloaded into the drive and might result in the loss of data.
- INTERNAL COMPONENTS OF THE DRIVE ARE DELICATE AND CAN EASILY BE DAMAGED. EXERCISE EXTREME CAUTION WHEN MANUALLY REMOVING A CARTRIDGE THAT WILL NOT EJECT AFTER PRESSING **UNLOAD**.

Before you begin

1. Attempt to remove the cartridge with the device power ON and with library manager, a host application, or **Unload**. Press and hold **Unload** for 12 seconds. This procedure causes the drive to eject the cartridge when it completed the mid-tape recovery.
2. Attempt to remove the cartridge by power-cycling the drive. Look for the drive to attempt a mid-tape recovery.

Note: It can take up to 15 minutes for the cartridge to rewind and unload.

3. If the cartridge unloads, inform the operator that the cartridge is unloaded. If the cartridge does not unload, repeat steps 2 and 3 again before you continue with this procedure.

Recommended tools

- #1 Phillips screwdriver
- ESD kit
- Flashlight (optional)
- #1 Flathead screwdriver (optional)

Beginning procedure

1. Refer to the enclosure documentation for instructions on removing the drive.
2. Place the drive on a non-slip, sturdy work surface.
3. Ground yourself to the drive with the ESD kit.
4. Remove the cover of the drive:
 - a. To remove the drive bezel, pull the right side of the bezel from the front of the drive, then pull the left side of the bezel out of the frame of the drive.
 - b. Remove the cover of the internal drive:
 - 1) Remove the four cover-mounting screws (**1** in Figure 35 on page 88). Two screws are on each side of the drive.
 - 2) Remove the cover by lifting it up.




Figure 35. Removing the bezel and the cover from the internal drive

5. Inspect the drive to decide which of the following conditions most closely match the symptom on the drive:
 - **Tape spooled off the supply reel** - All the tape appears to be on the takeup reel and no tape is on the supply reel (inside the cartridge). Test the drive after the procedure is completed.
 - **Tape pulled from leader pin (or broken at the front end)** - All the tape appears to be on the supply reel (inside the cartridge) and little or no tape appears to be on the takeup reel. The leader block is positioned in the takeup reel. Return the drive after the procedure is completed.
 - **Tape broken in mid-tape** - Tape appears to be on both the supply reel (inside the cartridge) and takeup reel. Test the drive after the procedure is completed.
 - **Tape tangled along tape path** - Tape appears to be tangled and damaged but intact. Return the drive after the procedure is completed.


-- OR --

 - **No damage to tape (or no apparent failure)** - There appears to be no damage or slack to the tape. Return the drive after the procedure is completed.

Tape spooled off supply reel

Attention: DO NOT TOUCH THE OUTER GUIDE RAIL (**2** in Figure 36 on page 89). THIS RAIL IS VERY DELICATE AND EASILY DAMAGED.

1. From the takeup reel, pull an arm 's length of tape around the rear of the tape path and over the head and rollers on the left side of the drive.
2. Set the drive on its left side with the head and tape path facing up.
3. Make sure that the tape is not twisted. Untwist tape if required.
4. Moisten a cotton swab with water and wet approximately 13 mm (0.5 in.) of the tape end and feed it onto the supply reel (inside the cartridge).
5. Turn the supply reel (**4** in Figure 36 on page 89) clockwise, allowing the moistened tape to adhere to the hub as it winds around the supply reel (inside the cartridge).



a82hd002

Figure 36. Rewinding tape into cartridge

- | | | | |
|---------------------------------|--|---------------------------------|---|
| <p>1</p> <p>2</p> | <p>Loader motor worm gear</p> <p>Outer guide rail</p> <p>WARNING: DO NOT TOUCH</p> | <p>3</p> <p>4</p> | <p>Takeup reel motor</p> <p>Supply reel motor</p> |
|---------------------------------|--|---------------------------------|---|

6. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Turn the supply reel (**4** in Figure 36) 10 more turns. Ensure that you do not stretch the tape.
7. Reassemble the drive, reversing the steps in “Beginning procedure” on page 87.
8. Reassemble the drive chassis, following the steps in “Replacing the internal drive” on page 96.
9. Reinstall the drive canister into the cradle assembly. Ensure that the connector on the drive is seated properly into the connector on the cradle.
10. Allow the drive to complete mid-tape recovery. This action takes several minutes. When this activity completes, push **Unload** to eject the cartridge.
11. Test the drive (see “Function code 1: Run drive diagnostics” on page 24) to determine if it needs to be replaced.

Tape pulled from or broken near leader pin




Figure 37. Drive with cover removed to reveal gear train.

- | | | | | | |
|----------|----------------------------|----------|-------------------------|----------|------------------------|
| 1 | Threader intermediate gear | 2 | Threader mechanism gear | 3 | Loader motor worm gear |
|----------|----------------------------|----------|-------------------------|----------|------------------------|

1. Pull out tape from the takeup reel.

Note: If there is more than approximately 0.6 m (2 ft.) of tape on the takeup reel, go to “Tape broken in mid-tape” on page 91.

2. If there is less than approximately 0.6 m (2 ft.) of tape on the takeup reel, cut off the excess tape as close to the leader pin as possible.
3. Reattach the leader pin to the remaining tape. For instructions, see “Repositioning or reattaching a leader pin” on page 47.
4. Locate the threader intermediate gear (**1** in Figure 37) near the rear of the drive. You can use your finger to rotate the threader intermediate gear (**1** in Figure 37) and slowly rotate the threader mechanism gear (**2** in Figure 37) clockwise.

This draws the tape leader block assembly (LBA) into the cartridge.

5. As the leader pin is secured in the cartridge, you hear the leader pin retention spring clips click into place. If you do not hear the click, continue rolling until the threader intermediate gear (**1** in Figure 37) stops. The LBA is in the correct position.

Note: Be sure to keep tension on the tape as the LBA is drawn into the cartridge.

6. Rotate the loader motor worm gear (**3** in Figure 37) clockwise as viewed from the front of the drive until it stops. This action releases the LBA leader pin.
7. Rotate the threader intermediate gear (**1** in Figure 37) counterclockwise until the leader block is in front of the read/write head. This action moves the LBA out of the cartridge.




Figure 38. Leader block assembly (LBA)

- | | | | |
|----------|------------------------|----------|-----------------------------|
| 1 | Loader motor worm gear | 2 | Leader block assembly (LBA) |
|----------|------------------------|----------|-----------------------------|


8. Rotate the loader motor worm gear (**3** in Figure 37 on page 90) counterclockwise as viewed from the front of the drive until it stops.
9. Remove the cartridge from the cartridge loader tray.
10. Reassemble the drive by reversing the procedure in Step 4 in “Beginning procedure” on page 87.
11. Reassemble the drive chassis.
12. Refer to the appropriate procedure to install the new drive and return the failed drive.

Tape broken in mid-tape

1. With the front of the drive facing you, pull an arm 's length of tape out of the takeup reel. From the takeup reel, thread tape around the rear of the tape path and over the head rollers on the left side of the drive.

Note: If there is less than approximately 5 cm (2 in.) of tape on the takeup reel, go to “Tape pulled from or broken near leader pin” on page 90.

2. From the supply reel inside the cartridge, pull approximately 0.3 m (1 ft.) of tape.
3. Make sure that the tape is not twisted. Untwist tape if required.
4. Moisten a cotton swab with water, and wet approximately 13 mm (0.5 in.) of the tape end. Overlap the tape ends, loosely mending them together.
5. Set the drive on its left side with the head and tape path facing up.
6. Turn the supply reel (**4** in Figure 39 on page 92) clockwise, carefully guiding the mended portion of the tape to wind around the hub of the supply reel that is located inside the cartridge. Continue spooling into the cartridge until the tape is taut. The tape must remain within the flanges of the tape guiding rollers. Turn the supply reel (**4** in Figure 39 on page 92) 10 more turns. Ensure that you do not stretch the tape.



a82hd002

Figure 39. Rewinding tape into cartridge

- | | |
|--|---|
| <p>1 Loader motor worm gear</p> <p>2 Outer guide rail</p> <p>WARNING: DO NOT TOUCH</p> | <p>3 Takeup reel motor</p> <p>4 Supply reel motor</p> |
|--|---|

7. Reassemble the drive by reversing the procedure in Step 4 in “Beginning procedure” on page 87.
8. Reassemble the chassis by following the steps in “Replacing the internal drive” on page 96.
9. Allow the drive to complete mid-tape recovery. This action takes several minutes. When this activity completes, push **Unload** to eject the cartridge.
10. Test the drive (see “Function code 1: Run drive diagnostics” on page 24) to determine whether it needs to be replaced.


Tape tangled along tape path

1. Carefully pull out excess tape and untangle.

Note: If you find the tape to be broken, try one of these procedures:

- “Tape spooled off supply reel” on page 88
- “Tape pulled from or broken near leader pin” on page 90
- “Tape broken in mid-tape” on page 91

2. Set the drive on its left side with the head and tape path facing up.



a82hd002


Figure 40. Rewinding tape into cartridge

- | | |
|--|---|
| <p>1 Loader motor worm gear</p> <p>2 Outer guide rail</p> <p>WARNING: DO NOT TOUCH</p> | <p>3 Takeup reel motor</p> <p>4 Supply reel motor</p> |
|--|---|

3. Turn the supply reel (**4** in Figure 40) clockwise.
4. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Turn the supply reel (**4** in Figure 40) 10 turns. Ensure that you do not stretch the tape.
5. Reassemble the chassis by following the steps in “Replacing the internal drive” on page 96.
6. Allow the drive to complete mid-tape recovery. This action takes several minutes. When this activity completes, push **Unload** to eject the cartridge.
7. Test the drive (see “Function code 1: Run drive diagnostics” on page 24) to determine whether it needs to be replaced.

No apparent failure or damage to tape

1. Set the drive on its left side with the head and tape path facing up.



a82hd002

Figure 41. Rewinding tape into cartridge

- | | | | |
|----------|------------------------|----------|-------------------|
| 1 | Loader motor worm gear | 3 | Takeup reel motor |
| 2 | Outer guide rail | 4 | Supply reel motor |
- WARNING: DO NOT TOUCH

2. Begin spooling the tape back into the cartridge by turning the supply reel motor (**4** in Figure 41) clockwise.
3. Continue spooling into the cartridge until the tape is taut and remains within the flanges of the tape guiding rollers. Ensure that you do not stretch the tape. Continue spooling until all tape is removed from the takeup reel (**3** in Figure 41).
4. Locate the threader intermediate gear (**1** in Figure 42 on page 95) near the rear of the drive. You can use your finger to rotate the threader intermediate gear (**1** in Figure 42 on page 95) and slowly rotate the threader mechanism gear (**2** in Figure 42 on page 95) clockwise. This action draws the tape leader block assembly (LBA) into the cartridge.




Figure 42. Drive with cover removed to reveal gear train.

- | | | | | | |
|----------|-------------------------------|----------|----------------------------|----------|---------------------------|
| 1 | Threader
intermediate gear | 2 | Threader
mechanism gear | 3 | Loader motor worm
gear |
|----------|-------------------------------|----------|----------------------------|----------|---------------------------|

- As the leader pin is secured in the cartridge, you hear the leader pin retention spring clips click into place. If you do not hear the click, continue rolling until the threader intermediate gear (**1** in Figure 42) stops. The LBA is in the correct position.

Note: Be sure to keep tension on the tape as the LBA is drawn into the cartridge.

- Rotate the loader intermediate gear (**1** in Figure 43) clockwise as viewed from the front of the drive until it stops. This action releases the LBA leader pin.
- Rotate the threader motor worm gear (**3** in Figure 43) counterclockwise until the leader block is in front of the read/write head. This action moves the LBA out of the cartridge.




Figure 43. Leader block assembly (LBA)

- | | | | |
|----------|------------------------|----------|-----------------------------|
| 1 | Loader motor worm gear | 2 | Leader block assembly (LBA) |
|----------|------------------------|----------|-----------------------------|

- Rotate the loader motor worm gear (**3** in Figure 43) counterclockwise as viewed from the front of the drive until it stops.
- Remove the cartridge from the cartridge loader tray.
- Reassemble the drive by reversing the procedure in Step 4 in “Beginning procedure” on page 87.
- Reassemble the drive chassis by following the steps in “Replacing the internal drive” on page 96.

12. Refer to the appropriate procedure to install the new drive and return the failed drive.
-

Replacing the internal drive

Step 1. Replacing the internal drive

1. Place the internal drive part way into the chassis.
2. Reconnect the internal interface cable to the drive.
3. Reconnect the internal power cable to the drive.
4. Slide the internal drive completely into the chassis until the latch assembly locks the drive in place.

Step 2. Replacing the cover

1. Gently push the chassis into the cover.
2. Turn the unit on its side with the bottom of the unit facing you.
3. Align the four screw holes in the cover by the feet with the screw holes in the chassis.
4. Replace the 4 screws by the feet.
5. Reconnect all cables to the rear panel of the unit.

Notices

This information was developed for products and services offered in the US. This material might be available from IBM in other languages. However, you may be required to own a copy of the product or product version in that language in order to access it.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

*IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
US*

For license inquiries regarding double-byte character set (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

*Intellectual Property Licensing
Legal and Intellectual Property Law
IBM Japan Ltd.
19-21, Nihonbashi-Hakozakicho, Chuo-ku
Tokyo 103-8510, Japan*

INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM websites are provided for convenience only and do not in any manner serve as an endorsement of those websites. The materials at those websites are not part of the materials for this IBM product and use of those websites is at your own risk.

IBM may use or distribute any of the information you provide in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

*IBM Director of Licensing
IBM Corporation
North Castle Drive, MD-NC119
Armonk, NY 10504-1785
US*

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

The licensed program described in this document and all licensed material available for it are provided by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement or any equivalent agreement between us.

The performance data discussed herein is presented as derived under specific operating conditions. Actual results may vary.

The client examples cited are presented for illustrative purposes only. Actual performance results may vary depending on specific configurations and operating conditions.

The performance data and client examples cited are presented for illustrative purposes only. Actual performance results may vary depending on specific configurations and operating conditions.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

Statements regarding IBM's future direction or intent are subject to change or withdrawal without notice, and represent goals and objectives only.

All IBM prices shown are IBM's suggested retail prices, are current and are subject to change without notice. Dealer prices may vary.

This information is for planning purposes only. The information herein is subject to change before the products described become available.

This information contains examples of data and reports used in daily business operations. To illustrate them as completely as possible, the examples include the names of individuals, companies, brands, and products. All of these names are fictitious and any similarity to actual people or business enterprises is entirely coincidental.

COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs. The sample programs are provided "AS IS", without warranty of any kind. IBM shall not be liable for any damages arising out of your use of the sample programs.

Each copy or any portion of these sample programs or any derivative work must include a copyright notice as follows:

© (your company name) (year).

Portions of this code are derived from IBM Corp. Sample Programs.

© Copyright IBM Corp. _enter the year or years_.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.

Trademarks

The following terms are trademarks of the International Business Machines Corporation in the United States, other countries, or both.

- AIX
- Enterprise Storage Server
- ESCON
- FICON
- i5/OS
- iSeries
- IBM
- pSeries
- S/390
- System Storage
- TotalStorage
- z/OS
- zSeries

IBM, the IBM logo, and [ibm.com](http://www.ibm.com) are trademarks or registered trademarks of International Business Machines Corporation in the United States, other countries, or both. If these and other IBM trademarked terms are marked on their first occurrence in this information with a trademark symbol ((R) or (TM)), these symbols indicate U.S. registered or common law trademarks owned by IBM at the time this information was published. Such trademarks may also be registered or common law trademarks in other countries. A current list of IBM trademarks is available on the Web at "Copyright and trademark information" at <http://www.ibm.com/legal/copytrade.shtml>.

Adobe, the Adobe logo, PostScript, and the PostScript logo are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States, and/or other countries.

Java and all Java-based trademarks are trademarks of Sun Microsystems, Inc. in the United States, other countries, or both.

Microsoft, Windows, and Windows NT are trademarks of Microsoft Corporation in the United States, other countries, or both.

Intel, Intel logo, Intel Inside, Intel Inside logo, Intel Centrino, Intel Centrino logo, Celeron, Intel Xeon, Intel SpeedStep, Itanium, and Pentium are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Linux is a registered trademark of Linus Torvalds in the United States, other countries, or both.

Other company, product, and service names may be trademarks or service marks of others.

Electronic emission notices

This section contains the electronic emission notices or statements for the United States and other countries.

Federal Communications Commission Statement

This explains the Federal Communications Commission's (FCC's) statement.

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, might cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Properly shielded and grounded cables and connectors must be used in order to meet FCC emission limits. IBM is not responsible for any radio or television interference caused by using other than recommended cables and connectors, or by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device might not cause harmful interference, and (2) this device must accept any interference received, including interference that might cause undesired operation.

Industry Canada Compliance Statement

This Class A digital apparatus complies with Canadian ICES-003.

Cet appareil numérique de la classe A est conforme à la norme NMB-003 du Canada.

European Union Electromagnetic Compatibility Directive

This product is in conformity with the protection requirements of European Union (EU) Council Directive 2014/30/EU on the approximation of the laws of the Member States relating to electromagnetic compatibility. IBM cannot accept responsibility for any failure to satisfy the protection requirements resulting from a non-recommended modification of the product, including the fitting of non-IBM option cards.

Attention: This is a Class A product. In a domestic environment this product might cause radio interference in which case the user might be required to take adequate measures.

European community contact:

IBM Deutschland GmbH
Technical Regulations, Department M372
IBM-Allee 1, 71139 Ehningen, Germany
Tele: +49 (0) 800 225 5423 or +49 (0) 180 331 3233
Email: halloibm@de.ibm.com

Australia and New Zealand Class A Statement

Attention: This is a Class A product. In a domestic environment this product might cause radio interference in which case the user might be required to take adequate measures.

Germany Electromagnetic Compatibility Directive
Deutschsprachiger EU Hinweis:
Hinweis für Geräte der Klasse A EU-Richtlinie zur Elektromagnetischen Verträglichkeit

Dieses Produkt entspricht den Schutzanforderungen der EU-Richtlinie 2014/30/EU zur Angleichung der Rechtsvorschriften über die elektromagnetische Verträglichkeit in den EU-Mitgliedsstaaten und hält die Grenzwerte der EN 55022 / EN 55032 Klasse A ein. Um dieses sicherzustellen, sind die Geräte wie in den Handbüchern beschrieben zu installieren und zu betreiben. Des Weiteren dürfen auch nur von der IBM empfohlene Kabel angeschlossen werden. IBM übernimmt keine Verantwortung für die Einhaltung der Schutzanforderungen, wenn das Produkt ohne Zustimmung von IBM verändert bzw. wenn Erweiterungskomponenten von Fremdherstellern ohne Empfehlung von IBM gesteckt/eingebaut werden.

EN 55022 / EN 55032 Klasse A Geräte müssen mit folgendem Warnhinweis versehen werden:
"Warnung: Dieses ist eine Einrichtung der Klasse A. Diese Einrichtung kann im Wohnbereich Funk-Störungen verursachen; in diesem Fall kann vom Betreiber verlangt werden, angemessene Maßnahmen zu ergreifen und dafür aufzukommen."

Deutschland: Einhaltung des Gesetzes über die elektromagnetische Verträglichkeit von Geräten Dieses Produkt entspricht dem "Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG)." Dies ist die Umsetzung der EU-Richtlinie 2014/30/EU in der Bundesrepublik Deutschland.

Zulassungsbescheinigung laut dem Deutschen Gesetz über die elektromagnetische Verträglichkeit von Geräten (EMVG) (bzw. der EMC Richtlinie 2014/30/EU) für Geräte der Klasse A Dieses Gerät ist berechtigt, in Übereinstimmung mit dem Deutschen EMVG das EG-Konformitätszeichen - CE - zu führen.

Verantwortlich für die Einhaltung der EMV-Vorschriften ist der Hersteller:

International Business Machines Corp.
New Orchard Road
Armonk, New York 10504
Tel: 914-499-1900

Der verantwortliche Ansprechpartner des Herstellers in der EU ist:

IBM Deutschland GmbH
Technical Relations Europe, Abteilung M456
IBM-Allee 1, 71139 Ehningen, Germany
Tel: +49 800 225 5426
e-mail: halloibm@de.ibm.com

Generelle Informationen:

Das Gerät erfüllt die Schutzanforderungen nach EN 55024 und EN 55022 / EN 55032 Klasse A.

People's Republic of China Class A Statement

中华人民共和国 "A类" 警告声明

声明

此为A级产品，在生活环境中，该产品可能会造成无线电干扰。在这种情况下，可能需要用户对其干扰采取切实可行的措施。

Taiwan Class A Statement

警告使用者：
這是甲類的資訊產品，在
居住的環境中使用時，可
能會造成射頻干擾，在這
種情況下，使用者會被要
求採取某些適當的對策。

taitem

Taiwan Contact Information

This topic contains the product service contact information for Taiwan.

IBM Taiwan Product Service Contact Information:
IBM Taiwan Corporation
3F, No 7, Song Ren Rd., Taipei Taiwan
Tel: 0800-016-888

台灣IBM 產品服務聯絡方式：
台灣國際商業機器股份有限公司
台北市松仁路7號3樓
電話：0800-016-888

f2c00790

Japan Voluntary Control Council for Interference Class A Statement

This explains the Japan Voluntary Control Council for Interference (VCCI) statement.

この装置は、クラス A 情報技術装置です。この装置を家庭環境で使用する
と電波妨害を引き起こすことがあります。この場合には使用者が適切な対策
を講ずるよう要求されることがあります。

VCCI-A

Japan Electronics and Information Technology Industries Association Statement

This statement explains the Japan JIS C 61000-3-2 product wattage compliance.

(一社) 電子情報技術産業協会 高調波電流抑制対策実施
要領に基づく定格入力電力値： Knowledge Centerの各製品の
仕様ページ参照

This statement explains the Japan Electronics and Information Technology Industries Association (JEITA) statement for products less than or equal to 20 A per phase.

高調波電流規格 JIS C 61000-3-2 適合品

This statement explains the JEITA statement for products greater than 20 A, single phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類：6（単相、PFC回路付）
- 換算係数：0

This statement explains the JEITA statement for products greater than 20 A per phase, three-phase.

高調波電流規格 JIS C 61000-3-2 準用品

本装置は、「高圧又は特別高圧で受電する需要家の高調波抑制対策ガイドライン」対象機器（高調波発生機器）です。

- 回路分類：5（3相、PFC回路付）
- 換算係数：0

Korean Electromagnetic Interference (EMI) Statement

This explains the Korean Electromagnetic Interference (EMI) statement.

이 기기는 업무용 환경에서 사용할 목적으로 적합성평가를 받은 기기로서

가정용 환경에서 사용하는 경우 전파간섭의 우려가 있습니다.

Russia Electromagnetic Interference Class A Statement

This statement explains the Russia Electromagnetic Interference (EMI) statement.

ВНИМАНИЕ! Настоящее изделие относится к классу А.
В жилых помещениях оно может создавать
радиопомехи, для снижения которых необходимы
дополнительные меры

rusemi

Glossary

This glossary defines the special terms, abbreviations, and acronyms that are used in this publication. If you do not find the term that you are looking for, refer to the index or to the *Dictionary of Computing*, 1994.

Numbers

2:1 compression

The relationship between the quantity of data that can be stored with compression as compared to the quantity of data that can be stored without compression. In 2:1 compression, twice as much data can be stored with compression as can be stored without compression.

A

A Ampere.

ac Alternating current.

access method

A technique for moving data between main storage and input or output devices.

adapter card

A circuit board that adds function to a computer.

adj Adjustment.

AIX Advanced Interactive Executive. IBM's implementation of the UNIX operating system. The RS/6000 system, among others, uses AIX as its operating system.

alphanumeric

Pertaining to a character set that contains letters, numerals, and other characters, such as punctuation marks.

alter To change.

ambient temperature

The temperature of air or other media in a designated area, particularly the area that surrounds equipment.

ampere (A)

A unit of measure for electric current that is equivalent to a flow of one coulomb per second, or to the current produced by one volt applied across a resistance of one ohm.

ANSI American National Standards Institute.

archive

To collect and store files in a designated place.

ASCII American National Standard Code for Information Interchange. A 7 bit coded character set (8 bits including parity check) that consists of control characters and graphic characters.

assigning a device

The establishing of the relationship of a device to a running task, process, job, or program.

assignment

The naming of a specific device to complete a function.

asynchronous

Pertaining to two or more processes that do not depend upon the occurrence of specific events such as common timing signals.

attention (notice)

A word for calling attention to the possibility of danger to a program, device, or system, or to data. Contrast with *caution* and *danger*.

ATTN Attention.

B

backup

To make extra copies of documents or software for safekeeping.

bar code

A code that represents characters by sets of parallel bars of varying thickness and separation that are read optically by transverse scanning.

bar code label

Paper bearing a bar code and having an adhesive backing. The bar code label must be affixed to a tape cartridge to enable the library to identify the cartridge and its volume serial number.

bar code reader

A laser device that is specialized for scanning and reading bar codes and

converting them into either the ASCII or EBCDIC digital character code.

bezel Decorative and safety cover.

bicolored

Having two colors.

bit Either of the digits 0 or 1 when used in the binary numbering system.

BM or bill of materials

A list of specific types and amounts of direct materials that are expected to be used to produce a specific job or quantity of output.

browser

A client program that initiates requests to a Web server and displays the information that the server returns.

buffer

A routine or storage that is used to compensate for a difference in rate of flow of data or time of occurrence of events, when data is transferred from one device to another.

bus A facility for transferring data between several devices that are located between two end points, only one device that is able to transmit at a specific moment.

byte A string that consists of bits (usually 8) that are treated as a unit and represent a character. A fundamental data unit.

C

capacity

The amount of data that can be contained on storage media and expressed in bytes of data.

cartridge manual rewind tool

A device that can be fitted into the reel of a cartridge and used to rewind tape into or out of the cartridge.

cartridge storage slot

Individual slot that is located within a magazine that is used to house tape cartridges.

caution (notice)

A word to call attention to possible personal harm to people. Contrast with *attention* and *danger*.

CE Customer engineer; field engineer; service representative.

centimeter (cm)

One one-hundredth of a meter (0.01 m). Approximately 0.39 inch.

channel command

An instruction that directs a data channel, control unit, or device to complete an operation or set of operations.

char Character.

CHK Check.

cleaning cartridge

A tape cartridge that is used to clean the heads of a tape drive. Contrast with *data cartridge*.

command

A control signal that initiates an action or the start of a sequence of actions.

compact disc (CD)

A disc, usually 4.75 inches in diameter, from which data is read optically by using a laser.

compression

The process of eliminating gaps, empty fields, redundancies, and unnecessary data to shorten the length of records or blocks.

concurrent

Refers to diagnostic procedures that can be run on one control unit while the rest of the subsystem remains available for customer applications.

contingent connection

A connection between a channel path and a drive that is caused when a unit check occurs during an I/O operation.

controller

A device that provides the interface between a system and one or more tape drives.

CP Circuit protector.

ctrl Control.

CU Control unit.

D

danger (notice)

A word to call attention to possible lethal harm to people. Contrast with *attention* and *caution*.

data Any representations such as characters or analog quantities to which meaning is or might be assigned.

data buffer
The storage buffer in the control unit. This buffer is used to increase the data transfer rate between the control unit and the channel.

data cartridge
A tape cartridge that is dedicated to storing data. Contrast with *cleaning cartridge*.

data check
A synchronous or asynchronous indication of a condition that is caused by invalid data or incorrect positioning of data.

dc Direct current.

degauss
To make a magnetic tape nonmagnetic by using electrical coils that carry currents that neutralize the magnetism of the tape.

degausser
A device that makes magnetic tape nonmagnetic.

degradation
A decrease in quality of output or throughput or an increase in machine error rate.

degraded
Decreased in quality of output or throughput or increased machine error rate.

deserialize
To change from serial-by-bit to parallel-by-byte.

detented
A part that is held in position with a catch or lever.

device Any hardware component or peripheral device, such as a tape drive or tape library, that can receive and send data.

device driver
A file that contains the code that is needed to use an attached device.

DIAG
Diagnostic section of maintenance information manual.

differential
See *High Voltage Differential (HVD)*.

direct access storage
A storage device in which the access time is independent of the location of the data.

DNS Directory Name System. This system allows the library to recognize text-based addresses instead of numeric IP addresses.

download
To transfer programs or data from a computer to a connected device, typically a personal computer.

To transfer data from a computer to a connected device, such as a workstation or microcomputer.

DRAM
Dynamic random-access memory.

drive, magnetic tape
A mechanism for moving magnetic tape and controlling its movement.

DRV Drive.

DSE Data security erase.

DSP Digital signal processor.

E

EBCDIC
Extended binary-coded decimal interchange code.

EC Edge connector. Engineering change.

ECC Error correction code.

EEPROM
Electrically erasable programmable read-only memory.

EIA Electronics Industries Association.

EIA unit
A unit of measure, which is established by the Electronic Industries Association, equal to 44.45 millimeters (1.75 inches).

eject To remove or force out from within.

electronic mail
Correspondence in the form of messages that are transmitted between user terminals over a computer network.

email See *electronic mail*.

EPO Emergency power off.

EPROM
Erasable programmable read only memory.

EQC Equipment check.

equipment check
An asynchronous indication of a malfunction.

Error log
A data set or file in a product or system where error information is stored for later access.

ESD Electrostatic discharge.

F

fault symptom code (FSC)
A hexadecimal code that is generated by the drive or the control unit microcode in response to a detected subsystem error.

FC Feature code.

FCC Federal communications commission.

FE Field engineer, customer engineer, or service representative.

fiducial
A target that is used for teaching a physical location to a robot.

field replaceable unit (FRU)
An assembly that is replaced in its entirety when any one of its components fails.

file A named set of records that are stored or processed as a unit. Also referred to as a dataset.

file protection
The processes and procedures that are established in an information system that are designed to inhibit unauthorized access to, contamination of, or deletion of a file.

file transfer protocol (FTP)
In the Internet suite of protocols, an application layer protocol that uses TCP and Telnet services to transfer bulk-data files between machines or hosts.

firmware
Proprietary code that is delivered as microcode as part of an operating system. Firmware is more efficient than software loaded from an alterable medium and more adaptable to change than pure

hardware circuitry. An example of firmware is the Basic Input/Output System (BIOS) in read-only memory (ROM) on a PC motherboard.

FLASH EEPROM
An electrically erasable programmable read-only memory (EEPROM) that can be updated.

FMR Field microcode replacement.

format
The arrangement or layout of data on a data medium.

formatter
Part of a magnetic tape subsystem that completes data conversion, speed matching, encoding, first-level error recovery, and interfaces to one or more tape drives.

FP File protect.

frayed Damaged as if by an abrasive substance.

FRU Field replaceable unit.

FSC Fault symptom code.

FSI Fault symptom index.

functional microcode
Microcode that is resident in the machine during normal customer operation.

G

g Gram.

GB gigabyte.

GBIC Gigabit Interface Converter.

Gbi gigabit

Generation 1
The informal name for the IBM Ultrium 1 Tape Drive, which is the first generation of the Ultrium tape drive. The Generation 1 drive has a native storage capacity of up to 100 GB per cartridge and a native sustained data transfer rate of 15 MB per second.

Generation 2
The informal name for the second-generation version of the IBM Ultrium Tape Drive. The Generation 2 drive has a native storage capacity of up to 200 GB per cartridge and a native sustained data transfer rate of 35 MB per second.

Generation 3

The informal name for the third-generation version of the IBM Ultrium Tape Drive. The Generation 3 drive has a native storage capacity of up to 400 GB per cartridge and a native sustained data transfer rate of 135 MB per second.

Generation 4

The informal name for the fourth-generation version of the IBM Ultrium Tape Drive. The Generation 4 drive has a native storage capacity of up to 800 GB per cartridge and a native sustained data transfer rate of 135 MB per second.

Generation 5

The informal name for the fifth-generation version of the IBM Ultrium Tape Drive. The Generation 5 drive has a native storage capacity of up to 1500 GB per cartridge and a native sustained data transfer rate of 140 MB per second.

Generation 6

The informal name for the sixth-generation version of the IBM Ultrium Tape Drive. The Generation 6 drive has a native storage capacity of up to 2500 GB per cartridge and a native sustained data transfer rate of 160 MB per second.

Generation 7

The informal name for the seventh-generation version of the IBM Ultrium Tape Drive. The Generation 7 drive has a native storage capacity of up to 6000 GB per cartridge and a native sustained data transfer rate of 300 MB per second.

gigabit (Gbit)

1 000 000 000 bits.

gigabyte (GB)

1 000 000 000 bytes.

Gigabit Interface Converter (GBIC)

Converts copper interface to optic interface.

gnd Ground.

H**hertz (Hz)**

Unit of frequency. One hertz equals one cycle per second.

hex Hexadecimal.

High Voltage Differential (HVD)

A logic-signaling system that enables data communication between a supported host and the library. HVD signaling uses a paired plus and minus signal level to reduce the effects of noise on the SCSI bus. Any noise that is injected into the signal is present in both a plus and minus state, and is canceled. Synonymous with *differential*.

HVD SCSI Bus High Voltage Differential

Hz Hertz (cycles per second).

I**IBM Spectrum Archive**

Formerly known as Linear Tape File System (LTFS). A file system that works with LTO Generation tape technology to access data stored on an IBM tape cartridge.

IBM Ultrium Tape Drive

Located within the library, a data-storage device that controls the movement of the magnetic tape in an IBM LTO Ultrium Tape Cartridge. The drive houses the mechanism (drive head) that reads and writes data to the tape.

ID Identifier.

identifier (ID)

(1) In programming languages, a lexical unit that names a language object; for example, the names of variables, arrays, records, labels, or procedures. An identifier usually consists of a letter optionally followed by letters, digits, or other characters. (2) One or more characters that are used to identify or name data element and possibly to indicate certain properties of that data element. (3) A sequence of bits or characters that identifies a program, device, or system to another program, device, or system.

IML Initial microprogram load.

initial microprogram load (IML)

The action of loading a microprogram from an external storage to writable control storage.

initiator

The component that runs a command. The initiator can be the host system or the tape control unit.

INST Installation.

interface

A shared boundary. An interface might be a hardware component to link two devices or it might be a portion of storage or registers accessed by two or more computer programs.

interposer

The part that is used to convert a 68-pin connector to a 50-pin D-shell connector.

intervention required

Manual action is needed.

INTRO

Introduction.

I/O Input/output.

IOP Input/output processor.

IPL Initial program load.

ITST Idle-time self-test.

K**kilogram (kg)**

One thousand grams (approximately 2.2 pounds).

km kilometer. 1000 Meters, Approximately 5/8 mile.

L

LAN Local area network. A computer network within a limited area.

LCD See *liquid crystal display*.

LDAP Lightweight Directory Access Protocol. This protocol allows the library to use login and password information that is stored on a server to grant access to the library functionality.

LED Light-emitting diode.

Linear Tape File System (LTFS)

See *IBM Spectrum Archive*.

Linear Tape-Open (LTO)

A type of tape storage technology that is developed by the IBM Corporation, Hewlett-Packard, and Certance. LTO technology is an "open format" technology, which means that its users have multiple sources of product and media. The "open" nature of LTO technology enables compatibility between different vendors' offerings by ensuring that vendors comply with verification standards. The LTO technology is implemented in two formats: the Accellis format focuses on fast access; the Ultrium format focuses on high capacity. The Ultrium format is the preferred format when capacity (rather than fast access) is the key storage consideration. An Ultrium cartridge has a compressed data capacity of up to 800 GB (2:1 compression) and a native data capacity of up to 400 GB.

liquid crystal display (LCD)

A low-power display technology that is used in computers and other I/O devices.

loadable

Having the ability to be loaded.

LTO cartridge memory (LTO-CM)

Within each LTO Ultrium data cartridge, an embedded electronics and interface module that can store and retrieve a cartridge's historical usage and other information.

LVD SCSI Bus Low Voltage Differential

M

m Meter. In the Metric System, the basic unit of length; equal to approximately 39.37 inches.

magnetic tape

A tape with a magnetic surface layer on which data can be stored by magnetic recording.

MAP Maintenance analysis procedure.

mask A pattern of characters that controls the retention or elimination of portions of another pattern of characters. To use a pattern of characters to control the retention or elimination of portions of another pattern of characters.

master file

A file that is used as an authority in a

- specific job and that is relatively permanent, even though its contents might change. Synonymous with main file.
- MB** Mega Byte (expressed as data rate in MB/s or MB/second).
- media capacity**
The amount of data that can be contained on a storage medium, expressed in bytes of data.
- media-type identifier**
Pertaining to the bar code on the bar code label of the IBM Ultrium Tape Cartridge, a 2-character code, L1, that represents information about the cartridge. L identifies the cartridge as one that can be read by devices that incorporate LTO technology; 1 indicates that it is the first generation of its type.
- mega** One million of.
- meter** In the Metric System, the basic unit of length; equal to approximately 39.37 inches.
- micro** One millionth of.
- microcode**
(1) One or more micro instructions. (2) A code, representing the instructions of an instruction set, which is implemented in a part of storage that is not program-addressable. (3) To design, write, and test one or more micro instructions. (4) See also *microprogram*.
- microdiagnostic routine**
A program that runs under the control of a supervisor, usually to identify field replaceable units.
- microdiagnostic utility**
A program that is run by the customer engineer to test the machine.
- microinstruction**
A basic or elementary machine instruction.
- microprogram**
A group of microinstructions that when run completes a planned function.

The term microprogram represents a dynamic arrangement or selection of one or more groups of microinstructions for execution to run a particular function. The term microcode represents
- microinstructions that are used in a product as an alternative to hard-wired circuitry to implement certain functions of a processor or other system component.
- MIM** Media information message.
- mm** Millimeter.
- modifier**
That which changes the meaning.
- mount a device**
To assign an I/O device with a request to the operator.
- MP** Microprocessor.
- ms** Millisecond.
- MSG** Message.
- multipath**
Pertaining to using more than one path.
- N**
- N/A** Not applicable.
- node** In a network, a point at which one or more functional units connect channels or data circuits.
- NTP** Network Time Protocol. This protocol allows the library to set its internal date and time that is based on the date and time of a sever.
- NVS** Nonvolatile storage. A storage device whose contents are not lost when power is cut off.
- O**
- oersted**
The unit of magnetic field strength in the unrationalized centimeter-gram-second (cgs) electromagnetic system. The oersted is the magnetic field strength in the interior of an elongated, uniformly wound solenoid that is excited with a linear current density in its winding of one abampere per 4π centimeters of axial length.
- offline**
Pertaining to the operation of a functional unit without the continual control of a computer. Contrast with *online*.
- online** Pertaining to the operation of a functional unit that is under the continual control of a computer. Contrast with *offline*.

OPER Operation.

ov Over voltage.

overrun

Loss of data because a receiving device is unable to accept data at the rate it is transmitted.

overtightening

To tighten too much.

P

parameter

A variable that is given a constant value for a specified application and that can denote the application.

p bit Parity bit.

PC Parity check.

PCC Power control compartment.

PDF Portable Document Format.

PE Parity error. Product engineer.

pick Pertaining to the library, to remove, by using a robotic device, a tape cartridge from a storage slot or drive.

picker A robotic mechanism that is located inside the library that moves cartridges between the cartridge storage slots and the drive.

PM Preventive maintenance.

POR Power-on reset.

port A physical connection for communication between the 3590 and the host processor. The 3590 has two SCSI ports.

Portable Document Format (PDF)

A standard that is specified by Adobe Systems, Incorporated, for the electronic distribution of documents. PDF files are compact, can be distributed globally (email, the Web, intranets, or CD-ROM), and can be viewed with the Acrobat Reader. The Acrobat Reader is software from Adobe Systems that can be downloaded at no cost from the Adobe Systems home page.

PROM

Programmable read only memory.

PS Power supply.

PWR Power.

R

rack A unit that houses the components of a storage subsystem, such as the library.

rackmount kit

A packaged collection of articles that are used to install the rack-mounted version of the library.

RAM Random access memory.

Random access memory

A storage device into which data is entered and from which data is retrieved in a nonsequential manner.

RAS Reliability, availability, and serviceability.

record A collection of related data or words, which are treated as a unit.

recording density

The number of bits in a single linear track measured per unit of length of the recording medium.

recoverable error

An error condition that allows continued execution of a program.

ref Reference.

reg Register.

reinventor

To inventory again.

retension

The process or function of tightening the tape onto the cartridge, if it is sensed that the tape has a loose wrap on the cartridge.

robot Picker.

robotics

Picker assembly.

RPQ Request for price quotation.

R/W Read/write.

S

s Seconds of time.

SAC Service Action Code. Code that is developed to indicate possible FRU or FRUs to replace to repair the hardware.

SAS Serial attached SCSI interface.

scratch cartridge

A data cartridge that contains no useful data, but can be written to with new data.

SCSI Small computer system interface.

segment

A part.

sel Select.

serialize

To change from parallel-by-byte to serial-by-bit.

serializer

A device that converts a space distribution of simultaneous states that represents data into a corresponding time sequence of states.

servo, servos

An adjective for use in qualifying some part or aspect of a servomechanism.

servomechanism

A feedback control system in which at least one of the system signals represents mechanical motion.

Small Computer Systems Interface (SCSI)

A standard that is used by computer manufacturers for attaching peripheral devices (such as tape drives, hard disks, CD-ROM players, printers, and scanners) to computers (servers). Pronounced "scuzzy". Variations of the SCSI interface provide for faster data transmission rates than standard serial and parallel ports (up to 160 megabytes per second). The variations include

- Fast/Wide SCSI: Uses a 16-bit bus, and supports data rates of up to 20 MBps.
- SCSI-1: Uses an 8-bit bus, and supports data rates of 4 MBps.
- SCSI-2: Same as SCSI-1, but uses a 50-pin connector instead of a 25-pin connector, and supports multiple devices.
- Ultra SCSI: Uses an 8- or 16-bit bus, and supports data rates of 20 or 40 MBps.
- Ultra2 SCSI: Uses an 8- or 16-bit bus and supports data rates of 40 or 80 MBps.
- Ultra3 SCSI: Uses a 16-bit bus and supports data rates of 80 or 160 MBps.
- Ultra160 SCSI: Uses a 16-bit bus and supports data rates of 80 or 160 MBps.

SNS Sense.

special feature

A feature that can be ordered to enhance the capability, storage capacity, or performance of a product, but is not essential for its basic work.

SR Service representative, see also *CE*.

SRAM

Static random access memory.

SS Status store.

ST Store.

standard feature

The significant design elements of a product that are included as part of the fundamental product.

START

Start maintenance.

subsystem

A secondary or subordinate system, capable of operating independently of, or asynchronously with, a controlling system.

SUPP Support.

sync Synchronous, synchronize. Occurring with a regular or predictable time relationship.

T

tachometer, tach

A device that emits pulses that are used to measure/check speed or distance.

tape cartridge

A container-holding magnetic tape that can be processed without separating it from the container.

tape void

An area in the tape in which no signal can be detected.

TCP/IP

Transmission Control Protocol/Internet Protocol.

TCU Tape control unit.

TH Thermal.

thread/load operation

A procedure that places tape along the tape path.

TM Tapemark.

U

UART Universal asynchronous receiver/transmitter.

Universal Serial Bus (USB)

An interface standard that manufacturers use to connect peripheral devices (such as tape drives, hard disk drives, and printers) to computers (host servers). Variations of the USB interface have different data transmission rates. The variations include USB 1.1, USB 2.0, USB 3.0.

unload

Prepare the tape cartridge for removal from the drive.

utilities

Utility programs.

utility programs

A computer program in general support of the processes of a computer; for instance, a diagnostic program.

uv Under voltage.

V

VOLSER

Volume serial number.

volume

A certain portion of data, together with its data carrier, that can be handled conveniently as a unit.

VPD Vital product data. The information that is contained within the tape drive that requires nonvolatile storage that is used by functional areas of the drive, and information that is required for manufacturing, RAS, and engineering.

W

word A character string that is convenient for some purpose to consider as an entity.

Write Write command.

WT world trade.

X

XR External register.

XRA External register address register.

Index

A

- ac grounding diagram xiv
- ac grounding inspection xiv
- adjust data rate 3
- attaching tape drive to server 5

B

- Bar code labels 41
 - guidelines for using 43
 - ordering 57

C

- Cables
 - connecting SAS interface 9
- capacity scaling 4
- cartridge
 - compatibility 3
 - manual removal from drive 86
- Cartridge 37
 - capacity scaling 4, 39
 - cleaning 40
 - compatibility 39
 - data 37
 - data capacity and recording
 - formats 37
 - disposal of 53
 - inserting 17
 - leader pin 47
 - memory chip 41
 - mid-tape recovery 18
 - ordering 54
 - proper handling 44
 - removing 18
 - specifications 52
 - types and colors 37
 - write-protect switch 43
- Cartridge, environment 45
- Cartridges
 - inspecting for damage 60
 - repairing 83
 - testing 29
- channel calibration 4
- cleaning the drive 19
- Cover
 - removing 83
- customize each data channel 4

D

- description of drive 1
- Device drivers
 - installing 10
 - supported 5
- Diagnostic, tape drive 34
- diagnostics 10
- Diagnostics 34
 - clear error code log 29

Diagnostics (continued)

- copying drive dump to tape 26
- disabling post error reporting 34
- display error code log 29
- enabling post error reporting 33
- Fast Read/Write Test 32
- forcing a drive dump 25
- Host Interface Wrap Test 27
- Load/Unload Test 32
- RS-422 Wrap Test 28
- selecting function 21
- tape drive 24
- test cartridge 29
- Test Head 31
- Write Performance Test 30

Display

- SCD dot 13
- single-character 13

drive

- avoiding damage 7
- description 1

Drive

- features 1
- removing 83
- replacing 96
- specifications 6
- drive cleaning 19
- drive diagnostics 10
- Drive dump
 - capturing 59
 - copying to tape 26
 - forcing 25
- Drive head
 - cleaning 19
- drive monitoring 5
- drive servicing 5

E

- Encryption 4
- end of life plan xviii
- Error code log
 - clear 29
 - display 29
- Error codes 65
- Ethernet (RJ45) 34
- Ethernet port 5

F

- Fast Read/Write Test 32
- Features of drive 1
- Feedback
 - Comments
 - sending v
 - sending v
- firmware
 - inhibiting down-leveling 5
- Firmware
 - determining level 59

Firmware (continued)

- updating 10
 - with FMR tape 10
 - with ITDT Tool 10
- FMR tape
 - create 25
 - unmake 28
 - update firmware 24
- front panel features 2

G

- glossary 105
- grounding diagram xiv

H

- host interface
 - physical characteristics 5
- Host Interface Wrap Test 27

I

- IBM Spectrum Archive 6
- Insert Cartridge 29
- installation
 - rack
 - safety xvi
- Installation 7
- Internal drive
 - removing 85
 - replacing 96

L

- Labels
 - bar code 41
 - guidelines for using 43
 - ordering 57
- laser
 - compliance xv
 - safety xv
- Linear Tape File System 6
- Load/Unload Test 32
- Location rules 8
- LTFS 6

M

- Maintenance
 - create FMR tape 25
 - update firmware with FMR tape 24
- Maintenance Function
 - selecting function 21
 - unmaking an FMR tape 28
- Maintenance Mode
 - entering 23
 - exiting 23
- Maintenance, tape drive 34

- media
 - cartridge compatibility 3
- Media 37
 - capacity scaling 4
 - inserting 17
 - mid-tape recovery 18
 - removing 18
 - resolving problems 62
- Message codes 65
- My Support v, 12

O

- operating instructions 13
- operating modes 13
- Operating systems supported 5
- operating systems, supported 5
- ordering
 - bar code labels 73
 - media 73
 - optional features 73
 - power cords 73
 - replacement parts 73
- Ordering Media
 - Ordering WORM cartridges 40

P

- Performance 3
- Post error reporting
 - disabling 34
 - enabling 33
- Power
 - button 13
 - connecting 10
 - cord inspection 8
 - outlet inspection 8
- Problem determination 59
 - checklist 62
- Problems reported by server
 - resolving 61

R

- Rack
 - safety 79
- rack installation
 - safety xvi
- Rack installation 79
- Rack Mount Kit
 - install 79
- Read/Write capability 39
- rear panel features 2
- Remove
 - cover 83
- Removing
 - internal drive 85
- Replacement procedure 63
- Replacing
 - cover 96
 - internal drive 96
- requirements for attaching tape drive to server 5
- RS-422 Wrap Test 28

S

- safety
 - end of life plan xviii
- safety information
 - laser compliance xv
 - laser safety xv
- safety inspection xiv
- SAS Host Adapter Card
 - installation 9
- SAS Host connections
 - checking 61
- SAS interface cables 9
- sending your comments v
- Server connection
 - configuring 10
- Servers supported 5
- servers, supported 5
- Shipment
 - verify 8
 - Verify shipment 8
- Specifications
 - cartridges 52
 - environmental 6
 - physical 6
 - power 6
- speed matching 3
- Status Light 14
- Status, tape drive 19
- support notification v
- supported SAN components 5
- supported servers and operating systems 5

T

- Tape Drive Status 19
- Tape Drive Status, web page 19
- TapeAlert flags 71
- technical support v
- Technical Support
 - accessing online v
 - My Support v
- Test Drive Head 31
- Trademarks 99

U

- Unload Button 16
- Unpacking shipment 7
- Updating firmware 10
 - with FMR tape 10
 - with Host Interface 10
 - with ITDT Tool 10

V

- Verifying Host Interface Communications 61

W

- WORM 40
- WORM (Write Once, Read Many) 39
- Write Once, Read Many (see WORM) 39
- Write Performance Test 30

- Write-Protect switch
 - setting 43

Readers' Comments — We'd Like to Hear from You

IBM TS2280
Setup, Operator, and Service Guide
Machine Type 3580 Model H8S

Publication No. SC27-4649-00

We appreciate your comments about this publication. Please comment on specific errors or omissions, accuracy, organization, subject matter, or completeness of this book. The comments you send should pertain to only the information in this manual or product and the way in which the information is presented.

For technical questions and information about products and prices, please contact your IBM branch office, your IBM business partner, or your authorized remarketer.

When you send comments to IBM, you grant IBM a nonexclusive right to use or distribute your comments in any way it believes appropriate without incurring any obligation to you. IBM or any other organizations will only use the personal information that you supply to contact you about the issues that you state on this form.

Comments:

Thank you for your support.

Send your comments to the address on the reverse side of this form.

If you would like a response from IBM, please fill in the following information:

Name

Address

Company or Organization

Phone No.

Email address



Fold and Tape

Please do not staple

Fold and Tape




NO POSTAGE
NECESSARY
IF MAILED IN THE
UNITED STATES

BUSINESS REPLY MAIL

FIRST-CLASS MAIL PERMIT NO. 40 ARMONK, NEW YORK

POSTAGE WILL BE PAID BY ADDRESSEE

IBM Corporation
Building 9032-2 Department GZW
Information Development
9000 South Rita Road
Tucson, AZ
USA 85744-0002



Fold and Tape

Please do not staple

Fold and Tape



Part Number: 01PL139

Printed in USA

SC27-4649-00



(1P) P/N: 01PL139

