Oracle ASAP™ Cartridge 4.1 for Nortel DMS100

Nortel DMS100 Cartridge Guide

Third Edition
August 2008

ORACLE®

Copyright and Trademark Information

Copyright © 1992, 2008, Oracle and/or its affiliates. All rights reserved.
Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.
The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this software or related documentation is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.
This software is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy and other measures to ensure the safe use of this software. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software in dangerous applications.

This software and documentation may provide access to or information on content, products and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third party content, products and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third party content, products or services.

Contents

1. Cartridge Overview 1

Cartridge content 2
Prerequisites 2
About this guide 2
Services, features, and options 3
Hardware and software requirements 8
Network element (NE) interface 9
ASAP version 9
Connecting to the NE 9
Related documentation 9

2. Installing and Testing the Cartridge 11

Starting ASAP 11
Downloading the cartridge 12
Installing the cartridge 13
Uninstalling the cartridge 13
Testing the cartridge installation 14
Configuring loopback and live mode parameters 14
Modifying dms100_sn06_pots_ne_config.xml 15
Testing the installation 18

3. Atomic Service Description Layer (ASDL) Commands 21

Add Feature Services 22
A_NT-DMS100_SN06_ADD_3WC 27
A_NT-DMS100_SN06_ADD_ACB 28
A_NT-DMS100_SN06_ADD_ACD 29
A_NT-DMS100_SN06_ADD_ACDNR 31
A_NT-DMS100_SN06_ADD_ACRJ 31
A_NT-DMS100_SN06_ADD_AIN 32
A_NT-DMS100_SN06_ADD_AINDN 33
A_NT-DMS100_SN06_ADD_AMSGDENY 35
A_NT-DMS100_SN06_ADD_AR 36
A_NT-DMS100_SN06_ADD_ARDDN 36
A_NT-DMS100_SN06_ADD_ASL 37
A_NT-DMS100_SN06_ADD_AUD 38
A_NT-DMS100_SN06_ADD_AUL 39
A_NT-DMS100_SN06_ADD_AUTODISP 40
A_NT-DMS100_SN06_ADD_CBE 41
A_NT-DMS100_SN06_ADD_CBU 42
A_NT-DMS100_SN06_ADD_CCW 43
A_NT-DMS100_SN06_ADD_CDE 43
A_NT-DMS100_SN06_ADD_CDI 44
A_NT-DMS100_SN06_ADD_CDU 45
A_NT-DMS100_SN06_ADD_CFB 46

A_NT-DMS100_SN06_ADD_CFBL 47
A_NT-DMS100_SN06_ADD_CFD 48
A_NT-DMS100_SN06_ADD_CFDA 50
A_NT-DMS100_SN06_ADD_CFDVT 51
A_NT-DMS100_SN06_ADD_CFF 53
A_NT-DMS100_SN06_ADD_CFGD 53
A_NT-DMS100_SN06_ADD_CFGDA 55
A_NT-DMS100_SN06_ADD_CFI 57
A_NT-DMS100_SN06_ADD_CFMDN 57
A_NT-DMS100_SN06_ADD_CFRA 58
A_NT-DMS100_SN06_ADD_CFS 59
A_NT-DMS100_SN06_ADD_CFU 61
A_NT-DMS100_SN06_ADD_CFW 62
A_NT-DMS100_SN06_ADD_CHD 63
A_NT-DMS100_SN06_ADD_CIF 64
A_NT-DMS100_SN06_ADD_CIR 65
A_NT-DMS100_SN06_ADD_CLF 66
A_NT-DMS100_SN06_ADD_CLI 66
A_NT-DMS100_SN06_ADD_CNAB 67
A_NT-DMS100_SN06_ADD_CNAMD 67
A_NT-DMS100_SN06_ADD_CND 68
A_NT-DMS100_SN06_ADD_CND-NO-BILL 69
A_NT-DMS100_SN06_ADD_CNDB 70
A_NT-DMS100_SN06_ADD_CNF 71
A_NT-DMS100_SN06_ADD_COD 72
A_NT-DMS100_SN06_ADD_COT 72
A_NT-DMS100_SN06_ADD_COT-NO-BILL 73
A_NT-DMS100_SN06_ADD_CPU 74
A_NT-DMS100_SN06_ADD_CSMI 75
A_NT-DMS100_SN06_ADD_CUSD 76
A_NT-DMS100_SN06_ADD_CWD 77
A_NT-DMS100_SN06_ADD_CWI 77
A_NT-DMS100_SN06_ADD_CWO 78
A_NT-DMS100_SN06_ADD_CWT 79
A_NT-DMS100_SN06_ADD_CWX 80
A_NT-DMS100_SN06_ADD_CXR 81
A_NT-DMS100_SN06_ADD_DCF 83
A_NT-DMS100_SN06_ADD_DCPU 84
A_NT-DMS100_SN06_ADD_DDN 84
A_NT-DMS100_SN06_ADD_DENY 85
A_NT-DMS100_SN06_ADD_DENYACB 86
A_NT-DMS100_SN06_ADD_DENYAR 86
A_NT-DMS100_SN06_ADD_DENYCOT 87
A_NT-DMS100_SN06_ADD_DENYCSMI 88
A_NT-DMS100_SN06_ADD_DENYISA 88
A_NT-DMS100_SN06_ADD_DENYU3WC 89
A_NT-DMS100_SN06_ADD_DGT 90
A_NT-DMS100_SN06_ADD_DIN 90

A_NT-DMS100_SN06_ADD_DISP 92
A_NT-DMS100_SN06_ADD_DNH 92
A_NT-DMS100_SN06_ADD_DOR 94
A_NT-DMS100_SN06_ADD_DQS 94
A_NT-DMS100_SN06_ADD_DQT 95
A_NT-DMS100_SN06_ADD_DRCW 96
A_NT-DMS100_SN06_ADD_DRING 98
A_NT-DMS100_SN06_ADD_DSCWID 100
A_NT-DMS100_SN06_ADD_DTM 101
A_NT-DMS100_SN06_ADD_ELN 102
A_NT-DMS100_SN06_ADD_EMW 102
A_NT-DMS100_SN06_ADD_ESL 104
A_NT-DMS100_SN06_ADD_FAA 105
A_NT-DMS100_SN06_ADD_FANI 106
A_NT-DMS100_SN06_ADD_FEATURES 107
A_NT-DMS100_SN06_ADD_FTRGRP 108
A_NT-DMS100_SN06_ADD_GIC 109
A_NT-DMS100_SN06_ADD_GND 110
A_NT-DMS100_SN06_ADD_HOT 111
A_NT-DMS100_SN06_ADD_ICM 111
A_NT-DMS100_SN06_ADD_INSPECT 112
A_NT-DMS100_SN06_ADD_INT 113
A_NT-DMS100_SN06_ADD_INTPIC 114
A_NT-DMS100_SN06_ADD_KSH 114
A_NT-DMS100_SN06_ADD_LCDR 116
A_NT-DMS100_SN06_ADD_LDSA 117
A_NT-DMS100_SN06_ADD_LDSO 118
A_NT-DMS100_SN06_ADD_LNR 118
A_NT-DMS100_SN06_ADD_LNRA 119
A_NT-DMS100_SN06_ADD_LOB 120
A_NT-DMS100_SN06_ADD_LOD 120
A_NT-DMS100_SN06_ADD_LPIC 122
A_NT-DMS100_SN06_ADD_LVM 123
A_NT-DMS100_SN06_ADD_M518 123
A_NT-DMS100_SN06_ADD_M536 124
A_NT-DMS100_SN06_ADD_MDN 125
A_NT-DMS100_SN06_ADD_MSB 126
A_NT-DMS100_SN06_ADD_MSBI 127
A_NT-DMS100_SN06_ADD_MWT 128
A_NT-DMS100_SN06_ADD_NAME 130
A_NT-DMS100_SN06_ADD_NDC 131
A_NT-DMS100_SN06_ADD_NFA 132
A_NT-DMS100_SN06_ADD_NGTSRVCE 133
A_NT-DMS100_SN06_ADD_NLT 134
A_NT-DMS100_SN06_ADD_OBS 135
A_NT-DMS100_SN06_ADD_ONI 136
A_NT-DMS100_SN06_ADD_PIC 137
A_NT-DMS100_SN06_ADD_PORT 138

A_NT-DMS100_SN06_ADD_PRK 139
A_NT-DMS100_SN06_ADD_PRL 140
A_NT-DMS100_SN06_ADD_QTD 140
A_NT-DMS100_SN06_ADD_RAG 141
A_NT-DMS100_SN06_ADD_RCHD 142
A_NT-DMS100_SN06_ADD_RMI 142
A_NT-DMS100_SN06_ADD_RMR 143
A_NT-DMS100_SN06_ADD_RMT 144
A_NT-DMS100_SN06_ADD_RPA 144
A_NT-DMS100_SN06_ADD_RSP 145
A_NT-DMS100_SN06_ADD_RSUS 146
A_NT-DMS100_SN06_ADD_SACB 147
A_NT-DMS100_SN06_ADD_SC1 148
A_NT-DMS100_SN06_ADD_SC2 149
A_NT-DMS100_SN06_ADD_SCA 149
A_NT-DMS100_SN06_ADD_SCF 151
A_NT-DMS100_SN06_ADD_SCL 154
A_NT-DMS100_SN06_ADD_SCRJ 155
A_NT-DMS100_SN06_ADD_SCS 157
A_NT-DMS100_SN06_ADD_SCU 158
A_NT-DMS100_SN06_ADD_SCWID 158
A_NT-DMS100_SN06_ADD_SDN 159
A_NT-DMS100_SN06_ADD_SDSDENY 161
A_NT-DMS100_SN06_ADD_SHU 161
A_NT-DMS100_SN06_ADD_SL 163
A_NT-DMS100_SN06_ADD_SMDR 164
A_NT-DMS100_SN06_ADD_SPB 165
A_NT-DMS100_SN06_ADD_SRA 166
A_NT-DMS100_SN06_ADD_SSAC 166
A_NT-DMS100_SN06_ADD_SUPPRESS 167
A_NT-DMS100_SN06_ADD_SUPR 168
A_NT-DMS100_SN06_ADD_SVCGRP 169
A_NT-DMS100_SN06_ADD_TCW 170
A_NT-DMS100_SN06_ADD_TDN 171
A_NT-DMS100_SN06_ADD_TFO 172
A_NT-DMS100_SN06_ADD_UCD 172
A_NT-DMS100_SN06_ADD_VMEADENY 173
A_NT-DMS100_SN06_ADD_VMEADN 174
A_NT-DMS100_SN06_ADD_WML 175
A_NT-DMS100_SN06_ADD_WUC 177
A_NT-DMS100_SN06_ADD_WUCR 177
A_NT-DMS100_SN06_ADD_DCPK 178
Modify Feature Services 178
A_NT-DMS100_SN06_CHF_FEATURES 180
A_NT-DMS100_SN06_MOD_ACD 181
A_NT-DMS100_SN06_MOD_AIN 183
A_NT-DMS100_SN06_MOD_AINDN 184
A_NT-DMS100_SN06_MOD_ASL 185

A_NT-DMS100_SN06_MOD_AUD 186
A_NT-DMS100_SN06_MOD_AUL 187
A_NT-DMS100_SN06_MOD_AUTODISP 189
A_NT-DMS100_SN06_MOD_CFB 189
A_NT-DMS100_SN06_MOD_CFBL 191
A_NT-DMS100_SN06_MOD_CFD 192
A_NT-DMS100_SN06_MOD_CFDA 194
A_NT-DMS100_SN06_MOD_CFDVT 195
A_NT-DMS100_SN06_MOD_CFF 197
A_NT-DMS100_SN06_MOD_CFS 197
A_NT-DMS100_SN06_MOD_CFU 199
A_NT-DMS100_SN06_MOD_CFW 200
A_NT-DMS100_SN06_MOD_CIF 201
A_NT-DMS100_SN06_MOD_CNAMD 202
A_NT-DMS100_SN06_MOD_CND 203
A_NT-DMS100_SN06_MOD_CNF 204
A_NT-DMS100_SN06_MOD_CPU 205
A_NT-DMS100_SN06_MOD_CSMI 205
A_NT-DMS100_SN06_MOD_CWT 207
A_NT-DMS100_SN06_MOD_CXR 208
A_NT-DMS100_SN06_MOD_DIN 210
A_NT-DMS100_SN06_MOD_DQS 212
A_NT-DMS100_SN06_MOD_DQT 212
A_NT-DMS100_SN06_MOD_DRING 213
A_NT-DMS100_SN06_MOD_EMW 216
A_NT-DMS100_SN06_MOD_ESL 217
A_NT-DMS100_SN06_MOD_FAA 218
A_NT-DMS100_SN06_MOD_FTRGRP 219
A_NT-DMS100_SN06_MOD_GIC 220
A_NT-DMS100_SN06_MOD_ICM 221
A_NT-DMS100_SN06_MOD_KSH 222
A_NT-DMS100_SN06_MOD_LPIC 224
A_NT-DMS100_SN06_MOD_MDN 225
A_NT-DMS100_SN06_MOD_NAME 227
A_NT-DMS100_SN06_MOD_NGTSRVCE 227
A_NT-DMS100_SN06_MOD_OBS 228
A_NT-DMS100_SN06_MOD_PIC 230
A_NT-DMS100_SN06_MOD_RMI 231
A_NT-DMS100_SN06_MOD_SCA 232
A_NT-DMS100_SN06_MOD_SCU 233
A_NT-DMS100_SN06_MOD_SDN 234
A_NT-DMS100_SN06_MOD_SHU 237
A_NT-DMS100_SN06_MOD_SUPR 238
A_NT-DMS100_SN06_MOD_SVCGRP 239
Modify Line Services 240
A_NT-DMS100_SN06_MOD_DN 241
A_NT-DMS100_SN06_MOD_INTERCEPT_NAME 243
A_NT-DMS100_SN06_MOD_LCC 244

A_NT-DMS100_SN06_MOD_LEN 246
A_NT-DMS100_SN06_MOD_LTG 246
A_NT-DMS100_SN06_MOD_MULTILINE-LEN 247
A_NT-DMS100_SN06_MOD_NCOS 248
Delete Feature Services 248
A_NT-DMS100_SN06_DEL_3WC 253
A_NT-DMS100_SN06_DEL_ACB 254
A_NT-DMS100_SN06_DEL_ACD 254
A_NT-DMS100_SN06_DEL_ACDNR 255
A_NT-DMS100_SN06_DEL_ACRJ 256
A_NT-DMS100_SN06_DEL_AIN 256
A_NT-DMS100_SN06_DEL_AINDN 257
A_NT-DMS100_SN06_DEL_AMSGDENY 258
A_NT-DMS100_SN06_DEL_AR 259
A_NT-DMS100_SN06_DEL_ARDDN 259
A_NT-DMS100_SN06_DEL_ASL 260
A_NT-DMS100_SN06_DEL_AUD 261
A_NT-DMS100_SN06_DEL_AUL 261
A_NT-DMS100_SN06_DEL_AUTODISP 262
A_NT-DMS100_SN06_DEL_CBE 263
A_NT-DMS100_SN06_DEL_CBU 264
A_NT-DMS100_SN06_DEL_CCW 265
A_NT-DMS100_SN06_DEL_CDE 265
A_NT-DMS100_SN06_DEL_CDI 266
A_NT-DMS100_SN06_DEL_CDU 267
A_NT-DMS100_SN06_DEL_CFB 268
A_NT-DMS100_SN06_DEL_CFBL 268
A_NT-DMS100_SN06_DEL_CFD 269
A_NT-DMS100_SN06_DEL_CFDA 269
A_NT-DMS100_SN06_DEL_CFDVT 270
A_NT-DMS100_SN06_DEL_CFF 271
A_NT-DMS100_SN06_DEL_CFGD 272
A_NT-DMS100_SN06_DEL_CFGDA 272
A_NT-DMS100_SN06_DEL_CFI 273
A_NT-DMS100_SN06_DEL_CFMDN 274
A_NT-DMS100_SN06_DEL_CFRA 274
A_NT-DMS100_SN06_DEL_CFS 275
A_NT-DMS100_SN06_DEL_CFU 276
A_NT-DMS100_SN06_DEL_CFW 277
A_NT-DMS100_SN06_DEL_CHD 277
A_NT-DMS100_SN06_DEL_CIF 278
A_NT-DMS100_SN06_DEL_CIR 279
A_NT-DMS100_SN06_DEL_CLF 279
A_NT-DMS100_SN06_DEL_CLI 280
A_NT-DMS100_SN06_DEL_CNAB 281
A_NT-DMS100_SN06_DEL_CNAMD 281
A_NT-DMS100_SN06_DEL_CND 282
A_NT-DMS100_SN06_DEL_CND-NO-BILL 282

A_NT-DMS100_SN06_DEL_CNDB 283
A_NT-DMS100_SN06_DEL_CNF 284
A_NT-DMS100_SN06_DEL_COD 285
A_NT-DMS100_SN06_DEL_COT 285
A_NT-DMS100_SN06_DEL_COT-NO-BILL 286
A_NT-DMS100_SN06_DEL_CPU 287
A_NT-DMS100_SN06_DEL_CSMI 287
A_NT-DMS100_SN06_DEL_CUSD 288
A_NT-DMS100_SN06_DEL_CWD 289
A_NT-DMS100_SN06_DEL_CWI 289
A_NT-DMS100_SN06_DEL_CWO 290
A_NT-DMS100_SN06_DEL_CWT 291
A_NT-DMS100_SN06_DEL_CWX 291
A_NT-DMS100_SN06_DEL_CXR 292
A_NT-DMS100_SN06_DEL_DCF 293
A_NT-DMS100_SN06_DEL_DCPU 294
A_NT-DMS100_SN06_DEL_DDN 294
A_NT-DMS100_SN06_DEL_DENY 295
A_NT-DMS100_SN06_DEL_DENYACB 296
A_NT-DMS100_SN06_DEL_DENYAR 296
A_NT-DMS100_SN06_DEL_DENYCOT 297
A_NT-DMS100_SN06_DEL_DENYCSMI 298
A_NT-DMS100_SN06_DEL_DENYISA 298
A_NT-DMS100_SN06_DEL_DENYU3WC 299
A_NT-DMS100_SN06_DEL_DGT 299
A_NT-DMS100_SN06_DEL_DIN 300
A_NT-DMS100_SN06_DEL_DISP 301
A_NT-DMS100_SN06_DEL_DNH 301
A_NT-DMS100_SN06_DEL_DOR 302
A_NT-DMS100_SN06_DEL_DQS 303
A_NT-DMS100_SN06_DEL_DQT 304
A_NT-DMS100_SN06_DEL_DRCW 304
A_NT-DMS100_SN06_DEL_DRING 305
A_NT-DMS100_SN06_DEL_DSCWID 306
A_NT-DMS100_SN06_DEL_DTM 306
A_NT-DMS100_SN06_DEL_ELN 307
A_NT-DMS100_SN06_DEL_EMW 308
A_NT-DMS100_SN06_DEL_ESL 309
A_NT-DMS100_SN06_DEL_FAA 309
A_NT-DMS100_SN06_DEL_FANI 310
A_NT-DMS100_SN06_DEL_FEATURES 311
A_NT-DMS100_SN06_DEL_FTRGRP 312
A_NT-DMS100_SN06_DEL_GIC 312
A_NT-DMS100_SN06_DEL_GND 313
A_NT-DMS100_SN06_DEL_HOT 314
A_NT-DMS100_SN06_DEL_ICM 314
A_NT-DMS100_SN06_DEL_INSPECT 315
A_NT-DMS100_SN06_DEL_INT 316

A_NT-DMS100_SN06_DEL_INTPIC 316
A_NT-DMS100_SN06_DEL_KSH 317
A_NT-DMS100_SN06_DEL_LCDR 318
A_NT-DMS100_SN06_DEL_LDSA 318
A_NT-DMS100_SN06_DEL_LDSO 319
A_NT-DMS100_SN06_DEL_LNR 319
A_NT-DMS100_SN06_DEL_LNRA 320
A_NT-DMS100_SN06_DEL_LOB 321
A_NT-DMS100_SN06_DEL_LOD 322
A_NT-DMS100_SN06_DEL_LPIC 322
A_NT-DMS100_SN06_DEL_LVM 323
A_NT-DMS100_SN06_DEL_M518 324
A_NT-DMS100_SN06_DEL_M536 325
A_NT-DMS100_SN06_DEL_MDN 325
A_NT-DMS100_SN06_DEL_MSB 326
A_NT-DMS100_SN06_DEL_MSBI 327
A_NT-DMS100_SN06_DEL_MWT 328
A_NT-DMS100_SN06_DEL_NAME 328
A_NT-DMS100_SN06_DEL_NDC 329
A_NT-DMS100_SN06_DEL_NFA 330
A_NT-DMS100_SN06_DEL_NGTSRVCE 330
A_NT-DMS100_SN06_DEL_NLT 331
A_NT-DMS100_SN06_DEL_OBS 332
A_NT-DMS100_SN06_DEL_ONI 332
A_NT-DMS100_SN06_DEL_PIC 333
A_NT-DMS100_SN06_DEL_PORT 334
A_NT-DMS100_SN06_DEL_PRK 335
A_NT-DMS100_SN06_DEL_PRL 335
A_NT-DMS100_SN06_DEL_QTD 336
A_NT-DMS100_SN06_DEL_RAG 337
A_NT-DMS100_SN06_DEL_RCHD 337
A_NT-DMS100_SN06_DEL_RMI 338
A_NT-DMS100_SN06_DEL_RMR 339
A_NT-DMS100_SN06_DEL_RMT 339
A_NT-DMS100_SN06_DEL_RPA 340
A_NT-DMS100_SN06_DEL_RSP 341
A_NT-DMS100_SN06_DEL_RSUS 342
A_NT-DMS100_SN06_DEL_SACB 342
A_NT-DMS100_SN06_DEL_SC1 343
A_NT-DMS100_SN06_DEL_SC2 343
A_NT-DMS100_SN06_DEL_SCA 344
A_NT-DMS100_SN06_DEL_SCF 345
A_NT-DMS100_SN06_DEL_SCL 345
A_NT-DMS100_SN06_DEL_SCRJ 346
A_NT-DMS100_SN06_DEL_SCS 347
A_NT-DMS100_SN06_DEL_SCU 348
A_NT-DMS100_SN06_DEL_SCWID 348
A_NT-DMS100_SN06_DEL_SDN 349

A_NT-DMS100_SN06_DEL_SDSDENY 350
A_NT-DMS100_SN06_DEL_SHU 351
A_NT-DMS100_SN06_DEL_SL 352
A_NT-DMS100_SN06_DEL_SMDR 352
A_NT-DMS100_SN06_DEL_SPB 353
A_NT-DMS100_SN06_DEL_SRA 354
A_NT-DMS100_SN06_DEL_SSAC 354
A_NT-DMS100_SN06_DEL_SUPPRESS 355
A_NT-DMS100_SN06_DEL_SUPR 356
A_NT-DMS100_SN06_DEL_SVCGRP 357
A_NT-DMS100_SN06_DEL_TCW 357
A_NT-DMS100_SN06_DEL_TDN 358
A_NT-DMS100_SN06_DEL_TFO 358
A_NT-DMS100_SN06_DEL_UCD 359
A_NT-DMS100_SN06_DEL_VMEADENY 360
A_NT-DMS100_SN06_DEL_VMEADN 361
A_NT-DMS100_SN06_DEL_WML 361
A_NT-DMS100_SN06_DEL_WUC 362
A_NT-DMS100_SN06_DEL_WUCR 363
Hunt group services 363
A_NT-DMS100_SN06_ADD_HUNT-GROUP 363
A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER 368
A_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER 371
A_NT-DMS100_SN06_ESTABLISH_DLH-GROUP 372
POTS Line Services 373
A_NT-DMS100_SN06_ADD_LINE 374
A_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL 376
A_NT-DMS100_SN06_ADD_NEWDN 378
A_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL 383
A_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL 383
A_NT-DMS100_SN06_DEL_LINE 384
A_NT-DMS100_SN06_DEL_NEWDN 385
A_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL 387
A_NT-DMS100_SN06_PLUG-UP_LINE 387
A_NT-DMS100_SN06_QRY_CUSTOMER-INFO 388
A_NT-DMS100_SN06_QRY_DN 389
A_NT-DMS100_SN06_QRY_LEN 390
A_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL 390
A_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL 391
A_NT-DMS100_SN06_RESTORE_LINE 392
A_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES 393
A_NT-DMS100_SN06_SUSPEND_LINE 394
User exit types 395

4. Service Definition 401

Add Feature Services 402
C_NT-DMS100_SN06_ADD_3WC 407
C_NT-DMS100_SN06_ADD_ACB 408

C_NT-DMS100_SN06_ADD_ACD 410
C_NT-DMS100_SN06_ADD_ACDNR 412
C_NT-DMS100_SN06_ADD_ACRJ 413
C_NT-DMS100_SN06_ADD_AIN 414
C_NT-DMS100_SN06_ADD_AINDN 415
C_NT-DMS100_SN06_ADD_AMSGDENY 417
C_NT-DMS100_SN06_ADD_AR 418
C_NT-DMS100_SN06_ADD_ARDDN 419
C_NT-DMS100_SN06_ADD_ASL 420
C_NT-DMS100_SN06_ADD_AUD 421
C_NT-DMS100_SN06_ADD_AUL 423
C_NT-DMS100_SN06_ADD_AUTODISP 424
C_NT-DMS100_SN06_ADD_CBE 425
C_NT-DMS100_SN06_ADD_CBU 426
C_NT-DMS100_SN06_ADD_CCW 427
C_NT-DMS100_SN06_ADD_CDE 428
C_NT-DMS100_SN06_ADD_CDI 429
C_NT-DMS100_SN06_ADD_CDU 430
C_NT-DMS100_SN06_ADD_CFB 431
C_NT-DMS100_SN06_ADD_CFBL 433
C_NT-DMS100_SN06_ADD_CFD 434
C_NT-DMS100_SN06_ADD_CFDA 436
C_NT-DMS100_SN06_ADD_CFDVT 438
C_NT-DMS100_SN06_ADD_CFF 439
C_NT-DMS100_SN06_ADD_CFGD 440
C_NT-DMS100_SN06_ADD_CFGDA 442
C_NT-DMS100_SN06_ADD_CFI 444
C_NT-DMS100_SN06_ADD_CFMDN 445
C_NT-DMS100_SN06_ADD_CFRA 446
C_NT-DMS100_SN06_ADD_CFS 447
C_NT-DMS100_SN06_ADD_CFU 449
C_NT-DMS100_SN06_ADD_CFW 450
C_NT-DMS100_SN06_ADD_CHD 452
C_NT-DMS100_SN06_ADD_CIF 453
C_NT-DMS100_SN06_ADD_CIR 454
C_NT-DMS100_SN06_ADD_CLF 455
C_NT-DMS100_SN06_ADD_CLI 456
C_NT-DMS100_SN06_ADD_CNAB 457
C_NT-DMS100_SN06_ADD_CNAMD 458
C_NT-DMS100_SN06_ADD_CND 459
C_NT-DMS100_SN06_ADD_CND-NO-BILL 460
C_NT-DMS100_SN06_ADD_CNDB 461
C_NT-DMS100_SN06_ADD_CNF 462
C_NT-DMS100_SN06_ADD_COD 463
C_NT-DMS100_SN06_ADD_COT 463
C_NT-DMS100_SN06_ADD_COT-NO-BILL 465
C_NT-DMS100_SN06_ADD_CPU 466
C_NT-DMS100_SN06_ADD_CSMI 467

C_NT-DMS100_SN06_ADD_CUSD 468
C_NT-DMS100_SN06_ADD_CWD 469
C_NT-DMS100_SN06_ADD_CWI 470
C_NT-DMS100_SN06_ADD_CWO 471
C_NT-DMS100_SN06_ADD_CWT 472
C_NT-DMS100_SN06_ADD_CWX 473
C_NT-DMS100_SN06_ADD_CXR 474
C_NT-DMS100_SN06_ADD_DCF 477
C_NT-DMS100_SN06_ADD_DCPU 478
C_NT-DMS100_SN06_ADD_DDN 479
C_NT-DMS100_SN06_ADD_DENY 480
C_NT-DMS100_SN06_ADD_DENYACB 481
C_NT-DMS100_SN06_ADD_DENYAR 481
C_NT-DMS100_SN06_ADD_DENYCOT 482
C_NT-DMS100_SN06_ADD_DENYCSMI 483
C_NT-DMS100_SN06_ADD_DENYISA 484
C_NT-DMS100_SN06_ADD_DENYU3WC 485
C_NT-DMS100_SN06_ADD_DGT 486
C_NT-DMS100_SN06_ADD_DIN 487
C_NT-DMS100_SN06_ADD_DISP 488
C_NT-DMS100_SN06_ADD_DNH 489
C_NT-DMS100_SN06_ADD_DOR 491
C_NT-DMS100_SN06_ADD_DQS 492
C_NT-DMS100_SN06_ADD_DQT 493
C_NT-DMS100_SN06_ADD_DRCW 494
C_NT-DMS100_SN06_ADD_DRING 496
C_NT-DMS100_SN06_ADD_DSCWID 498
C_NT-DMS100_SN06_ADD_DTM 500
C_NT-DMS100_SN06_ADD_ELN 501
C_NT-DMS100_SN06_ADD_EMW 502
C_NT-DMS100_SN06_ADD_ESL 503
C_NT-DMS100_SN06_ADD_FAA 505
C_NT-DMS100_SN06_ADD_FANI 506
C_NT-DMS100_SN06_ADD_FEATURES 507
C_NT-DMS100_SN06_ADD_FTRGRP 508
C_NT-DMS100_SN06_ADD_GIC 509
C_NT-DMS100_SN06_ADD_GND 511
C_NT-DMS100_SN06_ADD_HOT 511
C_NT-DMS100_SN06_ADD_ICM 512
C_NT-DMS100_SN06_ADD_INSPECT 514
C_NT-DMS100_SN06_ADD_INT 515
C_NT-DMS100_SN06_ADD_INTPIC 515
C_NT-DMS100_SN06_ADD_KSH 517
C_NT-DMS100_SN06_ADD_LCDR 518
C_NT-DMS100_SN06_ADD_LDSA 519
C_NT-DMS100_SN06_ADD_LDSO 520
C_NT-DMS100_SN06_ADD_LNR 521
C_NT-DMS100_SN06_ADD_LNRA 522

C_NT-DMS100_SN06_ADD_LOB 523
C_NT-DMS100_SN06_ADD_LOD 524
C_NT-DMS100_SN06_ADD_LPIC 525
C_NT-DMS100_SN06_ADD_LVM 527
C_NT-DMS100_SN06_ADD_M518 528
C_NT-DMS100_SN06_ADD_M536 529
C_NT-DMS100_SN06_ADD_MDN 530
C_NT-DMS100_SN06_ADD_MSB 531
C_NT-DMS100_SN06_ADD_MSBI 532
C_NT-DMS100_SN06_ADD_MWT 533
C_NT-DMS100_SN06_ADD_NAME 535
C_NT-DMS100_SN06_ADD_NDC 536
C_NT-DMS100_SN06_ADD_NFA 537
C_NT-DMS100_SN06_ADD_NGTSRVCE 539
C_NT-DMS100_SN06_ADD_NLT 540
C_NT-DMS100_SN06_ADD_OBS 541
C_NT-DMS100_SN06_ADD_ONI 543
C_NT-DMS100_SN06_ADD_PIC 544
C_NT-DMS100_SN06_ADD_PORT 545
C_NT-DMS100_SN06_ADD_PRK 546
C_NT-DMS100_SN06_ADD_PRL 547
C_NT-DMS100_SN06_ADD_QTD 548
C_NT-DMS100_SN06_ADD_RAG 549
C_NT-DMS100_SN06_ADD_RCHD 550
C_NT-DMS100_SN06_ADD_RMI 551
C_NT-DMS100_SN06_ADD_RMR 552
C_NT-DMS100_SN06_ADD_RMT 553
C_NT-DMS100_SN06_ADD_RPA 553
C_NT-DMS100_SN06_ADD_RSP 554
C_NT-DMS100_SN06_ADD_RSUS 555
C_NT-DMS100_SN06_ADD_SACB 557
C_NT-DMS100_SN06_ADD_SC1 558
C_NT-DMS100_SN06_ADD_SC2 559
C_NT-DMS100_SN06_ADD_SCA 560
C_NT-DMS100_SN06_ADD_SCF 562
C_NT-DMS100_SN06_ADD_SCL 564
C_NT-DMS100_SN06_ADD_SCRJ 566
C_NT-DMS100_SN06_ADD_SCS 568
C_NT-DMS100_SN06_ADD_SCU 569
C_NT-DMS100_SN06_ADD_SCWID 570
C_NT-DMS100_SN06_ADD_SDN 571
C_NT-DMS100_SN06_ADD_SDSDENY 573
C_NT-DMS100_SN06_ADD_SHU 574
C_NT-DMS100_SN06_ADD_SL 575
C_NT-DMS100_SN06_ADD_SMDR 576
C_NT-DMS100_SN06_ADD_SPB 577
C_NT-DMS100_SN06_ADD_SRA 579
C_NT-DMS100_SN06_ADD_SSAC 579

C_NT-DMS100_SN06_ADD_SUPPRESS 581
C_NT-DMS100_SN06_ADD_SUPR 582
C_NT-DMS100_SN06_ADD_SVCGRP 583
C_NT-DMS100_SN06_ADD_TCW 584
C_NT-DMS100_SN06_ADD_TDN 585
C_NT-DMS100_SN06_ADD_TFO 586
C_NT-DMS100_SN06_ADD_UCD 587
C_NT-DMS100_SN06_ADD_VMEADENY 588
C_NT-DMS100_SN06_ADD_VMEADN 589
C_NT-DMS100_SN06_ADD_WML 590
C_NT-DMS100_SN06_ADD_WUC 592
C_NT-DMS100_SN06_ADD_WUCR 593
..... C_NT-DMS100_SN06_ADD_DCPK 593
Modify Feature Services 594
C_NT-DMS100_SN06_CHF_FEATURES 596
C_NT-DMS100_SN06_MOD_ACD 597
C_NT-DMS100_SN06_MOD_AIN 599
C_NT-DMS100_SN06_MOD_AINDN 600
C_NT-DMS100_SN06_MOD_ASL 602
C_NT-DMS100_SN06_MOD_AUD 603
C_NT-DMS100_SN06_MOD_AUL 604
C_NT-DMS100_SN06_MOD_AUTODISP 606
C_NT-DMS100_SN06_MOD_CFB 607
C_NT-DMS100_SN06_MOD_CFBL 608
C_NT-DMS100_SN06_MOD_CFD 610
C_NT-DMS100_SN06_MOD_CFDA 612
C_NT-DMS100_SN06_MOD_CFDVT 614
C_NT-DMS100_SN06_MOD_CFF 615
C_NT-DMS100_SN06_MOD_CFS 616
C_NT-DMS100_SN06_MOD_CFU 618
C_NT-DMS100_SN06_MOD_CFW 619
C_NT-DMS100_SN06_MOD_CIF 620
C_NT-DMS100_SN06_MOD_CNAMD 622
C_NT-DMS100_SN06_MOD_CND 623
C_NT-DMS100_SN06_MOD_CNF 624
C_NT-DMS100_SN06_MOD_CPU 625
C_NT-DMS100_SN06_MOD_CSMI 626
C_NT-DMS100_SN06_MOD_CWT 627
C_NT-DMS100_SN06_MOD_CXR 629
C_NT-DMS100_SN06_MOD_DIN 631
C_NT-DMS100_SN06_MOD_DQS 633
C_NT-DMS100_SN06_MOD_DQT 634
C_NT-DMS100_SN06_MOD_DRING 635
C_NT-DMS100_SN06_MOD_EMW 637
C_NT-DMS100_SN06_MOD_ESL 638
C_NT-DMS100_SN06_MOD_FAA 641
C_NT-DMS100_SN06_MOD_FEATURES 642
C_NT-DMS100_SN06_MOD_FTRGRP 643

C_NT-DMS100_SN06_MOD_GIC 644
C_NT-DMS100_SN06_MOD_ICM 645
C_NT-DMS100_SN06_MOD_KSH 647
C_NT-DMS100_SN06_MOD_LPIC 649
C_NT-DMS100_SN06_MOD_MDN 650
C_NT-DMS100_SN06_MOD_NAME 651
C_NT-DMS100_SN06_MOD_NGTSRVCE 652
C_NT-DMS100_SN06_MOD_OBS 654
C_NT-DMS100_SN06_MOD_PIC 655
C_NT-DMS100_SN06_MOD_RMI 657
C_NT-DMS100_SN06_MOD_SCA 658
C_NT-DMS100_SN06_MOD_SCU 659
C_NT-DMS100_SN06_MOD_SDN 661
C_NT-DMS100_SN06_MOD_SHU 663
C_NT-DMS100_SN06_MOD_SUPR 665
C_NT-DMS100_SN06_MOD_SVCGRP 666
Modify Line Features 667
C_NT-DMS100_SN06_MOD_DN 668
C_NT-DMS100_SN06_MOD_INTERCEPT_NAME 671
C_NT-DMS100_SN06_MOD_LCC 672
C_NT-DMS100_SN06_MOD_LEN 673
C_NT-DMS100_SN06_MOD_LTG 674
C_NT-DMS100_SN06_MOD_MULTILINE-LEN 675
C_NT-DMS100_SN06_MOD_NCOS 676
Delete Feature Services 677
C_NT-DMS100_SN06_DEL_3WC 681
C_NT-DMS100_SN06_DEL_ACB 683
C_NT-DMS100_SN06_DEL_ACD 684
C_NT-DMS100_SN06_DEL_ACDNR 685
C_NT-DMS100_SN06_DEL_ACRJ 686
C_NT-DMS100_SN06_DEL_AIN 687
C_NT-DMS100_SN06_DEL_AINDN 688
C_NT-DMS100_SN06_DEL_AMSGDENY 689
C_NT-DMS100_SN06_DEL_AR 690
C_NT-DMS100_SN06_DEL_ARDDN 691
C_NT-DMS100_SN06_DEL_ASL 692
C_NT-DMS100_SN06_DEL_AUD 693
C_NT-DMS100_SN06_DEL_AUL 694
C_NT-DMS100_SN06_DEL_AUTODISP 695
C_NT-DMS100_SN06_DEL_CBE 696
C_NT-DMS100_SN06_DEL_CBU 697
C_NT-DMS100_SN06_DEL_CCW 698
C_NT-DMS100_SN06_DEL_CDE 699
C_NT-DMS100_SN06_DEL_CDI 700
C_NT-DMS100_SN06_DEL_CDU 701
C_NT-DMS100_SN06_DEL_CFB 702
C_NT-DMS100_SN06_DEL_CFBL 703
C_NT-DMS100_SN06_DEL_CFD 704

C_NT-DMS100_SN06_DEL_CFDA 705
C_NT-DMS100_SN06_DEL_CFDVT 706
C_NT-DMS100_SN06_DEL_CFF 707
C_NT-DMS100_SN06_DEL_CFGD 708
C_NT-DMS100_SN06_DEL_CFGDA 709
C_NT-DMS100_SN06_DEL_CFI 710
C_NT-DMS100_SN06_DEL_CFMDN 711
C_NT-DMS100_SN06_DEL_CFRA 712
C_NT-DMS100_SN06_DEL_CFS 713
C_NT-DMS100_SN06_DEL_CFU 714
C_NT-DMS100_SN06_DEL_CFW 715
C_NT-DMS100_SN06_DEL_CHD 715
C_NT-DMS100_SN06_DEL_CIF 716
C_NT-DMS100_SN06_DEL_CIR 717
C_NT-DMS100_SN06_DEL_CLF 718
C_NT-DMS100_SN06_DEL_CLI 719
C_NT-DMS100_SN06_DEL_CNAB 720
C_NT-DMS100_SN06_DEL_CNAMD 721
C_NT-DMS100_SN06_DEL_CND 722
C_NT-DMS100_SN06_DEL_CND-NO-BILL 723
C_NT-DMS100_SN06_DEL_CNDB 724
C_NT-DMS100_SN06_DEL_CNF 725
C_NT-DMS100_SN06_DEL_COD 726
C_NT-DMS100_SN06_DEL_COT 727
C_NT-DMS100_SN06_DEL_COT-NO-BILL 728
C_NT-DMS100_SN06_DEL_CPU 729
C_NT-DMS100_SN06_DEL_CSMI 730
C_NT-DMS100_SN06_DEL_CUSD 731
C_NT-DMS100_SN06_DEL_CWD 732
C_NT-DMS100_SN06_DEL_CWI 733
C_NT-DMS100_SN06_DEL_CWO 734
C_NT-DMS100_SN06_DEL_CWT 735
C_NT-DMS100_SN06_DEL_CWX 736
C_NT-DMS100_SN06_DEL_CXR 737
C_NT-DMS100_SN06_DEL_DCF 738
C_NT-DMS100_SN06_DEL_DCPU 739
C_NT-DMS100_SN06_DEL_DDN 739
C_NT-DMS100_SN06_DEL_DENY 740
C_NT-DMS100_SN06_DEL_DENYACB 741
C_NT-DMS100_SN06_DEL_DENYAR 742
C_NT-DMS100_SN06_DEL_DENYCOT 743
C_NT-DMS100_SN06_DEL_DENYCSMI 744
C_NT-DMS100_SN06_DEL_DENYISA 745
C_NT-DMS100_SN06_DEL_DENYU3WC 746
C_NT-DMS100_SN06_DEL_DGT 746
C_NT-DMS100_SN06_DEL_DIN 747
C_NT-DMS100_SN06_DEL_DISP 748
C_NT-DMS100_SN06_DEL_DNH 749

C_NT-DMS100_SN06_DEL_DOR 750
C_NT-DMS100_SN06_DEL_DQS 751
C_NT-DMS100_SN06_DEL_DQT 752
C_NT-DMS100_SN06_DEL_DRCW 753
C_NT-DMS100_SN06_DEL_DRING 754
C_NT-DMS100_SN06_DEL_DSCWID 755
C_NT-DMS100_SN06_DEL_DTM 756
C_NT-DMS100_SN06_DEL_ELN 757
C_NT-DMS100_SN06_DEL_EMW 758
C_NT-DMS100_SN06_DEL_ESL 759
C_NT-DMS100_SN06_DEL_FAA 759
C_NT-DMS100_SN06_DEL_FANI 760
C_NT-DMS100_SN06_DEL_FEATURES 761
C_NT-DMS100_SN06_DEL_FTRGRP 763
C_NT-DMS100_SN06_DEL_GIC 764
C_NT-DMS100_SN06_DEL_GND 765
C_NT-DMS100_SN06_DEL_HOT 765
C_NT-DMS100_SN06_DEL_ICM 766
C_NT-DMS100_SN06_DEL_INSPECT 767
C_NT-DMS100_SN06_DEL_INT 768
C_NT-DMS100_SN06_DEL_INTPIC 769
C_NT-DMS100_SN06_DEL_KSH 770
C_NT-DMS100_SN06_DEL_LCDR 771
C_NT-DMS100_SN06_DEL_LDSA 772
C_NT-DMS100_SN06_DEL_LDSO 773
C_NT-DMS100_SN06_DEL_LNR 773
C_NT-DMS100_SN06_DEL_LNRA 774
C_NT-DMS100_SN06_DEL_LOB 775
C_NT-DMS100_SN06_DEL_LOD 777
C_NT-DMS100_SN06_DEL_LPIC 778
C_NT-DMS100_SN06_DEL_LVM 779
C_NT-DMS100_SN06_DEL_M518 780
C_NT-DMS100_SN06_DEL_M536 781
C_NT-DMS100_SN06_DEL_MDN 782
C_NT-DMS100_SN06_DEL_MSB 783
C_NT-DMS100_SN06_DEL_MSBI 784
C_NT-DMS100_SN06_DEL_MWT 785
C_NT-DMS100_SN06_DEL_NAME 786
C_NT-DMS100_SN06_DEL_NDC 787
C_NT-DMS100_SN06_DEL_NFA 788
C_NT-DMS100_SN06_DEL_NGTSRVCE 789
C_NT-DMS100_SN06_DEL_NLT 790
C_NT-DMS100_SN06_DEL_OBS 791
C_NT-DMS100_SN06_DEL_ONI 792
C_NT-DMS100_SN06_DEL_PIC 793
C_NT-DMS100_SN06_DEL_PORT 794
C_NT-DMS100_SN06_DEL_PRK 795
C_NT-DMS100_SN06_DEL_PRL 796

C_NT-DMS100_SN06_DEL_QTD 797
C_NT-DMS100_SN06_DEL_RAG 798
C_NT-DMS100_SN06_DEL_RCHD 799
C_NT-DMS100_SN06_DEL_RMI 800
C_NT-DMS100_SN06_DEL_RMR 801
C_NT-DMS100_SN06_DEL_RMT 801
C_NT-DMS100_SN06_DEL_RPA 802
C_NT-DMS100_SN06_DEL_RSP 803
C_NT-DMS100_SN06_DEL_RSUS 804
C_NT-DMS100_SN06_DEL_SACB 805
C_NT-DMS100_SN06_DEL_SC1 806
C_NT-DMS100_SN06_DEL_SC2 807
C_NT-DMS100_SN06_DEL_SCA 808
C_NT-DMS100_SN06_DEL_SCF 809
C_NT-DMS100_SN06_DEL_SCL 810
C_NT-DMS100_SN06_DEL_SCRJ 811
C_NT-DMS100_SN06_DEL_SCS 812
C_NT-DMS100_SN06_DEL_SCU 813
C_NT-DMS100_SN06_DEL_SCWID 814
C_NT-DMS100_SN06_DEL_SDN 814
C_NT-DMS100_SN06_DEL_SDSDENY 816
C_NT-DMS100_SN06_DEL_SHU 817
C_NT-DMS100_SN06_DEL_SL 818
C_NT-DMS100_SN06_DEL_SMDR 819
C_NT-DMS100_SN06_DEL_SPB 820
C_NT-DMS100_SN06_DEL_SRA 821
C_NT-DMS100_SN06_DEL_SSAC 822
C_NT-DMS100_SN06_DEL_SUPPRESS 823
C_NT-DMS100_SN06_DEL_SUPR 824
C_NT-DMS100_SN06_DEL_SVCGRP 825
C_NT-DMS100_SN06_DEL_TCW 826
C_NT-DMS100_SN06_DEL_TDN 826
C_NT-DMS100_SN06_DEL_TFO 827
C_NT-DMS100_SN06_DEL_UCD 828
C_NT-DMS100_SN06_DEL_VMEADENY 829
C_NT-DMS100_SN06_DEL_VMEADN 830
C_NT-DMS100_SN06_DEL_WML 831
C_NT-DMS100_SN06_DEL_WUC 832
C_NT-DMS100_SN06_DEL_WUCR 833
Hunt Group Services 834
C_NT-DMS100_SN06_ADD_HUNT-GROUP 834
C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER 840
Hunt group services 842
C_NT-DMS100_SN06_ADD_HUNT-GROUP 843
C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER 848
C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER 850
C_NT-DMS100_SN06_ESTABLISH_DLH-GROUP 852
POTS Line Features 853

C_NT-DMS100_SN06_ADD_LINE 854
C_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL 857
C_NT-DMS100_SN06_ADD_NEWDN 859
C_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL 863
C_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL 864
C_NT-DMS100_SN06_DEL_LINE 865
C_NT-DMS100_SN06_DEL_NEWDN 866
C_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL 868
C_NT-DMS100_SN06_PLUG-UP_LINE 869
C_NT-DMS100_SN06_QRY_CUSTOMER-INFO 870
C_NT-DMS100_SN06_QRY_DN 871
C_NT-DMS100_SN06_QRY_LEN 872
C_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL 873
C_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL 874
C_NT-DMS100_SN06_RESTORE_LINE 874
C_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES 876
C_NT-DMS100_SN06_SUSPEND_LINE 877
C_NT-DMS100_SN06_DEL_DCPK 878

5. Configuring ASAP to Support Additional NE Instances 881

Using secure data 884
Extracting source files 886
Loading a new XML file 887

6. MML Commands 889

MML command execution overview 889
MML of DMS100 services 889
Add Features 889
Remove features 914
Change features 915
New POTS line 924
Remove POTS line 925
Change line parameter 925
Assign virtual DN 926
Remove virtual DN 927
Set Up Logical Terminal (ISDN) 927
Set Up DN attributes 928
Add Plug Up-Place 928
Add Suspend 928
Add Restore 928
Add Hunt Group 929
Add Hunt Group Member 930
Remove Hunt Group Member 931
Query by DN 932
Query by DN or LEN 932
Establish Distributed Line Hunt (DLH) Group 933
Query Logical Terminal (ISDN) 933
Query Customer Profile 934

Appendix A: OPT Compound-Parameter Suffixes 935
Example 935
THREE WAY CALLING (3WC) 935
AUTOMATIC CALLBACK (ACB) 936
AUTOMATIC CALL DISTRIBUTION (ACD) 936
AUTOMATIC CALL DISTRIBUTION NOT READY (ACDNR) 938
ADVANCED INTELLIGENT NETWORK (AIN) 938
ADVANCED INTELLIGENT NETWORK DN (AINDN) 939
DENY ACCESS MESSAGING (AMSGDENY) 940
ANONYMOUS CALLER REJECTION (ACRJ) 941
AUTOMATIC RECALL (AR) 941
AR DIALABLE DN (ARDDN) 942
AGENT STATUS LAMP (ASL) 943
AUTOMATIC DIAL (AUD) 943
AUTOMATIC LINE (AUL) 944
AUTOMATIC DISPLAY (AUTODISP) 945
CALL FORWARDING BUSY INTERNAL CALLS ONLY (CBE) 945
CALL FORWARDING BUSY UNRESTRICTED (CBU) 946
CANCEL CALL WAITING (CCW) 946
EXCLUDE EXTERNAL CALLS FROM CALL FORWARDING (CDE) 947
EXCLUDE INTRAGROUP CALLS FROM CALL FORWARDING (CDI) 947
CALL FORWARDING NO ANSWER UNRESTRICTED (CDU) 948
CALL FORWARDING BUSY (CFB) 948
CALL FORWARDING BUSY LINE (CFBL) 950
CALL FORWARDING DO NOT ANSWER (BUSINESS) - CFD 950
CALL FORWARDING DO NOT ANSWER (RESIDENTIAL) - CFDA 952
CALL FORWARDING GROUP DO NOT ANSWER FOR HUNT GROUP (BUSINESS) - CFGD 953
CALL FORWARDING GROUP DO NOT ANSWER (RESIDENTIAL) - CFGDA 954
CALL FORWARDING DO NOT ANSWER VARIABLE TIMER (CFDVT) 955
CALL FORWARD FICXED (CFF) 956
CALL FORWARDING INTRAGROUP (CFI) 957
CALL FORWARDING MADN SECONDARY NUMBER (CFMDN) 957
CALL FORWARDING REMOTE ACCESS (CFRA) 958
CALL FORWARDING SIMULTANEUS/SCREEENING (CFS) 959
CALL FORWARDING UNIVERSAL (CFU) 960
CALL FORWARDING (CFW) 960
CALL HOLD (CHD) 961
CONTROLLED INTERFLOW (CIF) 962
CIRCULAR HUNT (CIR) 962
CALLING LINE IDENTIFICATION WITH FLASH (CLF) 963
CALLING LINE IDENTIFICATION (CLI) 963
CALLING NAME DELIVERY BLOCKING (CNAB) 963
CALL NAME DELIVERY (CNAMD) 964
CALLING NUMBER DELIVERY (CND) 964
CALLING NUMBER DELIVERY BLOCKING (CNDB) 965
STATION CONTROLLED CONFERENCE (CNF) 965

CUTOFF ON DISCONNECT (COD) 966
CUSTOMER ORIGINATED TRACE (COT) 966
CALL PICKUP (CPU) 967
CALL SCREENING, MONITORING & INTERCEPT (CSMI) 967
CALL FORWARDING USAGE SENSITIVE DENIAL (CUSD) 970
DIAL CALL WAITING (CWD) 970
CALL WAITING INTRAGROUP (CWI) 971
CALL WAITING ORIGINATING (CWO) 971
CALL WAITING (CWT) 972
CALL WAITING EXEMPT (CWX) 973
CALL TRANSFER (CXR) 973
DENIED CALL FORWARDING (DCF) 975
DIRECTED CALL PICKUP (DCPU) 976
DIALABLE DIRECTORY NUMBER (DDN) 976
DENY ACCESS TO CLASS FEATURE (DENY) 976
DENY AUTOMATIC RECALL (DENY DENYAR) 977
DENY CALL TRACER (DENY DENYCOT) 978
DENY REPEAT DIAL (DENY DENYACB) 978
DENY THREE WAY CALLING (DENYU3WC) 978
DENY IN-SESSION ACTIVATION (DENYISA) 978
DENY CALL SCREENING, MONITORING & INTERCEPT (DENYCSMI) 979
DIGITONE (DGT) 979
DENIED INCOMING CALL (DIN) 980
DISPLAY (DISP) 981
DIRECTORY NUMBER HUNT (DNH) 981
DENIED ORIGINATOR (DOR) 982
DISPLAY QUEUE STATUS (DQS) 983
DISPLAY QUEUE THRESHOLD (DQT) 983
DISTINCTIVE RING CALL WAITING (DRCW) 984
DISTINCTIVE RING (DRING) 985
CALL WAITING OPTION (DSCWID) 987
DENIED TERMINATION (DTM) 988
ESSENTIAL LINE (ELN) 988
EXECUTIVE MESSAGE WAITING (EMW) 989
EMERGENCY SERVICE LINE (ESL) 990
FORCED AGENT AVAILABILITY (FAA) 992
Flexible Automatic Number ID (FANI) 992
GROUP INTERCOM (GIC) 993
GROUND START (GND) 994
HOTEL/MOTEL (HOT) 994
INTERCOM BUSINESS SET (ICM) 994
INSPECT KEY (INSPECT) 995
INTERCOM (INT) 995
INTERNATIONAL PRIMARY CARRIER (INTPIC) 996
KEY SHORT HUNT (KSH) 996
LOCAL CALL DETAIL REPORTING (LCDR) 998
LONG DISTANCE SIGNAL ACTIVATE (LDSA) 998
LONG DISTANCE SIGNAL OPTION (LDSO) 999

LAST NUMBER REDIAL (LNR) 999
LAST NUMBER REDIAL ASSOCIATED WITH SET (LNRA) 999
LINE OF BUSINESS (LOB) 1000
LINE OVERFLOW TO DN (LOD) 1000
INTRALATA PIC (LPIC) 1001
LEAVE MESSAGE (LVM) 1001
18-BUTTON ADD-ON FOR MERIDIAN M5000 SERIES M518 (M518) 1002
36-BUTTON ADD-ON FOR MERIDIAN M5000 SERIES M536 (M536) 1002
MULTIPLE APPEARANCE DIRECTORY NUMBER (MDN) 1003
MAKE SET BUSY (MSB) 1004
MAKE SET BUSY INTRAGROUP (MSBI) 1004
MESSAGE WAITING (MWT) 1004
NAME DISPLAY (NAME) 1007
NO DOUBLE CONNECT (NDC) 1008
NETWORK FACILITY ACCESS (NFA) 1009
NIGHT SERVICE (NGTSVRCE) 1010
NO LINE INSULATION TEST (NLT) 1010
OBSERVE AGENT (OBS) 1011
OPTERATOR NUMBER IDENTIFICATION(ONI) 1012
INTERLATA PIC (PIC) 1013
PORT (PORT) 1013
CALL PARK (PRK) 1014
PRIVACY RELEASE (PRL) 1014
QUERY TIME AND DATE (QTD) 1015
RING AGAIN (RAG) 1015
RESIDENTIAL CALL HOLD (RCHD) 1015
REMOTE MESSAGE INDICATOR (RMI) 1016
ANSWER SUPERVISION LOCAL (RMT) 1016
ANSWER SUPERVISION TOLL (RMR) 1016
REPEATED ALERT (RPA) 1017
MEASURED RATE COIN LINE (RSP) 1017
Requested Suspension (RSUS) 1018
Subscriber Activated Call Blocking (SACB) 1018
Selective Call Acceptance (SCA) 1020
Selective Call Forwarding (SCF) 1021
Speed Calling Long (SCL) 1024
SPEED CALL SHORT (SCS) 1025
SPEED CALL SHORT LIST 30 (SC1) 1026
SPEED CALL LONG LIST (SC2) 1026
Selective Call Rejection (SCRJ) 1026
SPEED CALLING USER (SCU) 1028
SPONTANEOUS CALL WAITING IDENTIFICATION (SCWID) 1029
Secondary Directory Number (SDN) 1029
STOP HUNT (SHU) 1031
SETUP-DN ATTRIBUTES (SDNA) 1033
DENY BUSY REPEAT DIAL (SDSDENY) 1033
SECONDARY LANGUAGE (SL) 1034
STATION MESSAGE DETAIL RECORDING (SMDR) 1034

ADD LOGICAL TERMINAL (SLT ADD) 1034
ATTACH LOGICAL TERMINAL (SLT ATT) 1036
CHANGE LOGICAL TERMINAL (SLT CHA) 1036
SPECIAL BILLING (SPB) 1038
SUPPRESSED RINGING ACCESS (SRA) 1039
STATION SPECIFIC AUTHORIZATION CODES (SSAC) 1039
SUPERVISOR (SUPR) 1039
ANONYMOUS CALLER (SUPPRESS) 1040
SERVICE GROUP (SVCGRP) 1041
TALKING CALL WAITING (TCW) 1042
DENY TOLL CALL (TDN) 1042
TERMINATION FAULT OPTION (TFO) 1042
UNIFORM CALL DISTRIBUTION (UCD) 1043
DENY VOICE MAIL EASY ACCESS (VMEADENY) 1043
VOICE MAIL EASY ACCESS DN (VMEADN) 1044
WARM LINE (WML) 1044
WAKE UP (WUC) 1046
WAKE UP REMINDER (WUCR) 1046

1

Cartridge Overview

ASAP cartridges are discrete software components that are developed for the ASAP product. An ASAP cartridge offers specific domain behavior on top of the core ASAP software, and provides the configuration that supports a set of services on a network element (NE).

An ASAP cartridge is not a stand-alone component, but operates in conjunction with the ASAP core product. ASAP cartridges offer the following benefits:

- **Reduced Time to Market**—time to market of new services is reduced through simplified development, implementation, and extension of cartridges on customer sites.
- **Extendable**—cartridges can be extended to include additional services and components that deliver business value, without requiring changes to the original cartridge.
- **Simplified Effort**—the effort and technical knowledge that is required to perform customizations is reduced.
- **Ease of Installation**—cartridges can be installed into an ASAP environment without interfering with the existing install base.

An ASAP cartridge can be used to configure ASAP to provision the following:

- NEs from a specific vendor, such as Nortel or Lucent.
- Technologies, such as Asynchronous Transfer Mode (ATM) and Frame Relay switches, or Internet Protocol (IP) routers.
- Services that are supported on the NE, such as ATM, IP Virtual Private Networks (VPN), Wireless, or Optical.

Cartridges are designed for a specific technology, software load, and service.

An ASAP cartridge supports a particular set of services on an NE. These services are independent of customer-specific service definitions. Professional Services or systems integrators can perform extensions to the cartridge to support customer-specific requirements.

For more information on extending a cartridge, refer to the *ASAP Cartridge Development Guide for Service Activation*.

Cartridge content

An ASAP cartridge contains the following:

- An interface to the NE
- A set of scripts, such as State Tables or Java methods
- A set of atomic actions in the form of Atomic Service Description Layer (ASDL) commands
- A set of Common Service Description Layer (CSDL) commands that form meaningful services
- Sample work orders
- Installation scripts

Prerequisites

System integrators such as managers, designers, programmers, and testers who are responsible for the adaptation and integration of ASAP-based solutions should use this manual as a reference. It assumes that readers possess the following skills:

- A knowledge of ASAP programming concepts
- A good working knowledge of the UNIX operating system
- A thorough understanding of service and network provisioning
- Familiarity with telecommunications

About this guide

This guide provides a detailed description of the Nortel DMS100 cartridge. It contains overview and technical information to assist with extending and integrating the cartridge into a customer environment.

The scope of this guide includes ASAP as it pertains to this cartridge. It is not a complete ASAP reference guide.

For additional ASAP information when using this cartridge, refer to the following supporting documentation:

- **ASAP documentation set**—for detailed information on the ASAP core product.
- **ASAP Cartridge Development Guide for Service Activation**—for information on how to extend a cartridge.

The Nortel DMS100 cartridge provides the ASAP service configuration and network element (NE) interface to activate SUB services on DMS100 NEs.

Services, features, and options

Table 1: Services provided in the cartridge

Service	Description
POTS Line with optional adding features	This command establishes service for single-line and multiline telephone sets that are not assigned. This command establishes single-line set DNH pilots and members. Optionally, multiple features can be added when creating line. Add or Delete a basic POTS line.
Change NCOS (To block 700, 900, 976)	This command change the NCOS of the line. Modify the NCOS settings of the line.
ADSI CPE Call waiting on Caller ID	Add or Delete spontaneous call waiting ID option of the line.
ADSI CPE Visual Message Waiting	Add or Delete Message Waiting option on the line.
Anonymous Call Rejection (ACRJ)	The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN). The system routes anonymous calls to an announcement. Add or Delete Anonymous Call Rejection (ACRJ) option for the line.
Automatic Call Back (ACB) ABRE	The ACB option allows a subscriber to place a call to the last station that the subscriber called. If the destination line is busy, ACB monitors the line until the line becomes idle and can accept the call. Add or Delete Automatic Call Back (ACB) feature for the line.
Automatic Recall (AR) AREC	The AR option allows a subscriber to call the last station that calls the subscriber. If the destination line is busy, AR monitors the line until the line becomes idle and can accept the call. Add or Delete Automatic Recall (AR) option for the line.
Automatic Ring Burst - With Voice Messaging	Add or Delete Message waiting option for the line.
Calling Number Delivery Blocking (CNDB)	The CNDB option blocks DN of the calling party. Add or Delete Calling Number Delivery Blocking (CNDB) option for the line.
Calling Name Delivery Blocking (CNAB)BLK CNID	The CNAB option allows the system to block the delivery of the name of the caller. Add or Delete Calling Name Delivery Blocking (CNAB) option for the line.

Table 1: Services provided in the cartridge

Service	Description
Call Forwarding (CFW)(Call Forwarding Variable - all calls)	The CFW option allows the user to forward calls to another location. Add or Delete or modify Call forwarding (CFW) option for the line.
Call Forwarding Busy Line (CFBL)	The CFBL option allows the subscriber to specify a directory number (DN). The DN is a number to which the system forwards calls when the station is busy. Add or Delete option to forward a busy call on a line.
Call Forwarding Do Not Answer - residential (CFDA)	The CFDA option forwards calls not answered to stations in the same customer group. Add or Delete Call forwarding Do not Answer option on a line.
Deluxe Spontaneous Call Waiting Identification (DSCWID)	Deluxe Spontaneous Call Waiting Identification (DSCWID) allows the subscriber to receive calling-party information during call waiting. The subscriber also receives this information with basic SCWID. The DSCWID presents the subscriber with a set of options to treat the incoming call. These options include the following: (1) Answer the new call and put the current call on hold. (2) Disconnect the call. Answer the new call. (3) Forward the new call. (4) Connect the new call to a busy announcement. (5) Connect to a hold announcement. Put the new call on hold. (6) Conference the new call with the current call. Add or Delete Deluxe Spontaneous Call Waiting Identification (DSCWID) option for the line.
Call Waiting (CWT)	The CWT option can alert busy station when one incoming call try to reach DN. Add or Delete Call waiting (CWT) option for the line.
Calling Name Delivery (CNAMD)	The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE). Add or Delete Calling Name Delivery (CNAMD) option for the line.
Calling identification Number (CND)	The CID option allows the operating company to display the calling party identification number. The calling party identification number appears for 800 calls on residential (RES), Integrated business network (IBN), and automatic call distribution (ACD) on centrex lines. Add or Delete Calling Identification Number (CND) option for the line.

Table 1: Services provided in the cartridge

Service	Description
Cancel Call Waiting (CCW)	The Cancel Call Waiting (CCW) option allows Call Waiting (CWT) subscribers to turn off the CWT option. Subscribers can turn off the CWT option during an active telephone call or when the line is idle. If a subscriber activates CCW during a call, CCW cancels all CWT functions for that call. If a subscriber activates CCW during the idle state, CCW cancels all CWT functions for the next incoming or outgoing call. The system restores CW to the line of the subscriber after the call is complete. Add or Delete Cancel Call Waiting (CCW) option for the line.
Call Waiting (CWT)	The CWT option can alert busy station when one incoming call try to reach DN. Add or Delete Call Waiting option to a line.
Customer controlled Ring for call forward no answer	The CFDA option forwards calls not answered to stations in the same customer group. Add or Delete Call forwarding Do not Answer option on a line.
Customer Originated Trace (COT)	The COT option allows the recipient of a harassing call to request an automatic trace of the call. Add or Delete Customer Originated Trace (COT) option for the line.
Do not Disturb (DND)	The DND option allows the attendant to restrict calls to a station or group of stations. While call diversion is active, the attendant overrides the option to complete the call to the affected station(s). Add or Delete Do not Disturb (DND) option for the line.
Call Forwarding (CFW)	The CFW option allows the user to forward calls to another location. Add or Delete or modify Call forwarding (CFW) option for the line.
Event Based billing blocking of Auto Busy Redial	The ACB option allows a subscriber to place a call to the last station that the subscriber called. If the destination line is busy, ACB monitors the line until the line becomes idle and can accept the call. Add or Delete Automatic Call Back (ACB) feature for the line.
Event based billing blocking for Auto Recall	The AR option allows a subscriber to call the last station that calls the subscriber. If the destination line is busy, AR monitors the line until the line becomes idle and can accept the call. Add or Delete Automatic Recall (AR) option for the line.
Event based billing blocking for customer originated Trace	The COT option allows the recipient of a harassing call to request an automatic trace of the call. Add or Delete Customer Originated Trace (COT) option for the line.

Table 1: Services provided in the cartridge

Service	Description
Event based billing for 3 way calling	This option allows the subscriber on the assigned line to place a call on hold. When the call is on hold, the subscriber can set up a request call to another subscriber. The subscriber that initiates the three-way call can switch speech paths between the held party and the talking party. The subscriber can connect all parties into a three-port conference. When the three-way call is in progress, the subscriber can press the 3WC key again to drop the conference. When the subscriber drops the conference, the subscriber connects to a single-party call again. Add or delete Three way calling (3WC) option for the line.
Flexible Automatic Number ID (FANI)	The Flexible Automatic Number ID (FANI) option allows an operating company to assign special-purpose Automatic Number Identification (ANI) information digits to a line. The operating company defines FANI information digits. The FANI information digits identify special types of calls that the general Bellcore-defined ANI information digits have to cover. The FANI information digits apply to outgoing Equal Access (EA), EA path, and Operator Services System (OSS) calls. Add or Delete Flexible Automatic Number Identification (FANI) option for the line.
Group call forwarding/diversion	The CFGDA option allows the system administration to assign call forwarding to a hunt group. Add or Delete CFGDA option for a line.
Incoming call block	The SCRJ option allows to selectively reject calls arriving from a limited set of DNs. Add or Delete Incoming call blocking option for a line.
International subscriber Features Denied (FDN)	The FDN feature can deny a subscriber the use of current features on a temporary condition. This option does not delete the entries from the tables. When the operating company assigns FDN, all other options does not perform for the subscriber. Add or Delete International Subscriber Features Denied (FDN) option for the line.
Intra-LATA WATS (EWALI)	Option EWALI allows the subscriber to choose an Enhanced Wide Area Telecommunication service (EWATS) Intra local area and Transport Area (Intra LATA) carrier network that is subscribed to. Add or Delete Intra-LATA WATS (EWALI) option for the line.

Table 1: Services provided in the cartridge

Service	Description
Last Number Redial (LNR)	The LNR option allows a subscriber to redial the last number dialed. The subscriber uses a single key instead of the full number to redial the last number dialed. Add or Delete Last Number Redial (LNR) option for the line.
Line Hunt Group (GADD)	The user uses the GADD command to add members to a current generic service framework (GSF) , DNH, MLH, or DLH group. Add or Delete Line Hunt Group (GADD) option for the line.
Local Call Detailed Reporting (LCDR) Local Calling plan	The Local call Detailed Reporting (LCDR) option allows billing for local calls to correspond to conversion time. These calls are called local seven-digit extended area service (EAS) calls. The same tape records toll and local calls. Toll calls use the automatic Message accounting (AMA) system. Add or Delete Local Call Detailed Reporting (LCDR) option for the line.
Message Waiting (MWT)	The MWT option allows a message center to inform a user that there is a message. Add or Delete Message Waiting (MWT) option for the line.
Message Waiting Indication - Audio/Visual (MWIDC)	The MSWIDC option allows a message center operator to turn message waiting Indication to ON. The operator performs this action to the telephone set of the user. The ON message indicates that calls forwarded to the message center are ready for retrieval. Add or Delete Message Waiting Indication (MWIDC)- Audio/ Visual option for the line.
Remote Call Forward Service (CFRA)	The Call Forwarding Remote Access (CFRA) option allows a single-line set to use a line other than its own. Add or Delete Remote Call forward Service (CFRA) option for the line.
Screened Call Acceptance (SCA)	The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN). Add or Delete or Modify Screened Call Acceptance (SCA) option for the line.
Distinctive Ringing (DRING)	The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types. Add or Delete or Modify Distinctive Ringing (DRING) option for the line.

Table 1: Services provided in the cartridge

Service	Description
Speed Calling Short List (SC1)	The SC1 option allows a customer to specify a list of up to eight frequently called numbers. These numbers can be called by dialing the digits 2-9. Add or Delete Speed Calling Short List (SC1) option for the line.
Speed Calling Long List L30 (SC2)	The SC2 option allows a customer to specify a list of up to 30 frequently called numbers. These numbers can be called by dialing 20-49. Add or Delete Speed Calling Long list 30 (SC2) option for the line.
Three Way Calling (3WC)	This option allows the subscriber on the assigned line to place a call on hold. When the call is on hold, the subscriber can set up a request call to another subscriber. The subscriber that initiates the three-way call can switch speech paths between the held party and the talking party. The subscriber can connect all parties into a three-port conference. When the three-way call is in progress, the subscriber can press the 3WC key again to drop the conference. When the subscriber drops the conference, the subscriber connects to a single-party call again. Add or delete Three way calling (3WC) option for the line.
Toll Denial (TDN)	The TDN option prevents a line from originating Toll calls. Add or Delete Toll Denial (TDN) option for the line.
Distinctive Ringing/Call Waiting (DRCW)	The Distinctive Ringing/Call Waiting (DRCW) option allows the system to identify terminating calls with a distinct alert pattern. If the line is available, the system issues a distinct ring. If the line is busy, the system issues a distinct call waiting tone. The caller receives standard audible ringback tone. When a call originates from a directory number (DN) on the DRCW list, the system identifies the call by a distinct alert. The system gives standard terminating treatment to call attempts from DNs the system cannot identify or are not on the DRCW screening list. Add or Delete Distinctive Ringing/Call waiting (DRCW) option for the line.

Hardware and software requirements

The following sections contain the high-level software and hardware environment requirements for provisioning SUB services using this cartridge, including:

- Network element (NE) interface
- ASAP version

Network element (NE) interface

This cartridge operates with the following:

- Nortel DMS100 NE with software load SN06.

ASAP version

This cartridge was developed and tested using ASAP 4.7.1.

For more information on the operating environment of this ASAP version, refer to the *ASAP 4.7.1 Release Record*.

Connecting to the NE

The Nortel DMS100 cartridge interfaces with DMS100 NEs using the telnet protocol over TCP/IP.

Related documentation

This cartridge was developed according to the following Network Element Provisioning Specifications:

- North American DMS-100 SERVORD Reference Manual volume 1 & 2

2

Installing and Testing the Cartridge

This chapter describes the following procedures related to installing and testing the cartridge:

- Downloading the cartridge
- Installing the cartridge
- Uninstalling the cartridge
- Testing the cartridge installation

Starting ASAP

Before downloading the cartridge, ensure that ASAP is running.

To start ASAP

1. To start ASAP, execute the following script:

   ```
   start_asap_sys
   ```

2. Ensure the ASAP Daemon (DAM_$ENV_ID) is running by checking the ASAP status using the ASAP script “status”.
3. Check whether the WebLogic instance for this ASAP environment is running. If not, start the WebLogic instance.

The *ASAP System Configuration and Management Guide* contains more information on starting ASAP, the ASAP Daemon, and WebLogic.

Downloading the cartridge

Before you can install the cartridge, you must use the internet to download the cartridge's TAR file from Oracle's Customer Portal.

Use the following instructions to download, then unTAR the TAR file.

To download the TAR file

4. Login to Oracle MetaLink internet home page (http://www.metalink.oracle.com).
5. Download the cartridge patch to your workstation.

To unTAR the TAR file

1. On you workstation, create a repository directory—the naming of which is your choice.

   ```
   mkdir <repository dir>
   ```

2. Untar NortelDMS100_R3_1.tar.

   ```
   tar xvf NortelDMS100_R3_1.tar
   ```

3. Copy the resulting /Nortel_DMS100_SN06 directory and its contents to the repository directory.

   ```
   cp -rf /Nortel_DMS100_SN06 <repository_dir>
   ```

The directory structure in the repository directory should look like the following illustration. (this illustration describes the minimum required structure; you can enhance this directory structure with additional directories based on your requirements and deliverables).

```
<repository_directory>
   Nortel_DMS100_SN06
      /README
      /installCartridge
      /uninstallCartridge
      /NORTEL_DMS100_SN06_POTS_3_1.sar
```

Installing the cartridge

Run the installation script installCartridge to install the cartridge. You will find this script under /Nortel_DMS100_SN06. The script executes the following tasks:

- Configures the Nortel DMS100-specific NE using the SACT.
- Deploys the Nortel DMS100 cartridge service model (only if the Nortel DMS100 service model is not yet deployed) using the Service Activation Deployment Tool (SADT).
- Copies the Nortel DMS100-specific jar files and the cpp library file to the ASAP environment.
- Loads the sample work orders to the SRP database.

For information on the SACT and the SADT, refer to the *ASAP System Configuration and Management Guide*.

To install the cartridge

1. Run the installCartridge script from /Nortel_DMS100_SN06. At the prompt, type:

   ```
   installCartridge NORTEL_DMS100_SN06_POTS_3_1.sar
   ```

2. The script prompts you for the values of the following WebLogic login parameters:

   - WebLogic Hostname
   - WebLogic HTTP Port
   - WebLogic Login User ID
   - WebLogic Login Password

   The script loads the NEP-NE configuration and the CSDL-ASDL configuration to the SARM database, and loads sample work orders to the SRP database. The script also copies the cartridge-specific jar files and cpp library file to the ASAP environment.

3. Restart ASAP to upload the cartridge configuration into ASAP.

Uninstalling the cartridge

Run the uninstallation script uninstallCartridge to uninstall the Nortel DMS100 cartridge. This script is located under Nortel_DMS100_SN06. The script executes the following tasks:

- Unconfigures Nortel DMS100-specific NEs using the SACT.
- Undeploys the Nortel DMS100 cartridge service model (only if the Nortel DMS100 service model is already deployed) using the Service Activation Deployment Tool (SADT).
- Removes the Nortel DMS100-specific jar files and cpp library file from the ASAP environment.

For more information on the SACT and the SADT, refer to the *ASAP System Configuration and Management Guide*.

To uninstall the cartridge

1. Run the uninstallCartridge script from /Nortel_DMS100_SN06. At the prompt, type

   ```
   uninstallCartridge NORTEL_DMS100_SN06_POTS_3_1.<date>.<time>.sar
   ```

2. The script prompts you for the values of the following parameters:
   - WebLogic Hostname
   - WebLogic HTTP Port
   - WebLogic Login User ID
   - WebLogic Login Password

The script unloads the NEP-NE configuration and CSDL-ASDL configuration from SARM database. It also removes the cartridge specific jar files and cpp library file from the ASAP environment.

Testing the cartridge installation

To test this cartridge installation, you need to know about the network element (NE), services, and basic ASAP configuration. You may need to perform adjustments to provision a service for a specific NE, network, or connectivity configuration.

You can test the cartridge installation using one of the following methods:

- **Loopback mode**—does not actually connect to or send commands to the NE.
- **Live mode**—connects to and sends commands to a live NE.

Configuring loopback and live mode parameters

The following sections tell you which variables you must configure in ASAP.cfg to use the loopback and live testing modes.

Loopback mode

The following table details the parameters that you must set to test the cartridge in loopback mode.

Table 2: Loopback Mode Parameter Settings

Configuration Variable	Parameter Settings	Location
LOOPBACK_ON	1 (default setting)	ASAP.cfg

Live mode

The following table details the parameters that you must set in ASAP.cfg to test the cartridge in live mode.

Table 3: Live Mode Parameter Settings

Configuration Variable	Parameter Settings	Location
LOOPBACK_ON	0	ASAP.cfg

Modifying dms100_sn06_pots_ne_config.xml

Use the following procedure to modify cmvt_mms_3_1_x_ne_config.xml.

To modify cmvt_mms_3_1_x_ne_config.xml

1. Create a new source directory under /Nortel_DMS100_SN06. You can give this directory any appropriate, meaningful name you want to.

   ```
   mkdir <new_source_directory>
   ```

2. Copy NORTEL_DMS100_SN06_POTS_3_1.sar to this new source directory.

   ```
   cp NORTEL_DMS100_SN06_POTS_3_1.sar ./<new_source_directory>
   ```

3. Change directory to <new_source_directory>.

   ```
   cd <new_source_directory>
   ```

4. Un-jar NORTEL_DMS100_SN06_POTS_3_1.sar This extracts the contents of the sar file (see Figure 1 on page 17 for an example of the resulting file structure).

   ```
   jar xvf NORTEL_DMS100_SN06_POTS_3_1.sar
   ```

5. Edit <new_source_directory>/Nortel_DMS100_SN06/common/application_config/ cmvt_mms_3_1_x_ne_config.xml in with the appropriate changes.

6. Create a new sar file at the <new_source_directory> level.

   ```
   CreateSar $PWD
   ```

7. Uninstall the cartridge using NORTEL_DMS100_SN06_POTS_3_1.sar in /Nortel_DMS100_SN06 (That is, use the original sar file that you copied in Step 2 above—see "Uninstalling the cartridge" on page 13 for uninstallation instructions).
8. After you uninstall the cartridge, rename the sar file in /Nortel_DMS100_SN06 so you have a backup copy of it.
9. Copy the new sar file from <new_source_directory> to /Nortel_DMS100_SN06.
10. Reinstall the cartridge (see "Installing the cartridge" on page 13 for installation instructions).

```
META-INF/activation-model.xml
Nortel/
   DMS100_SN06/
      POTS/
         sample_wo/
         sarm/
            ne_progs/
            PLSQL/
         control/
            PLSQL/
         nep/
            PLSQL/
         java/
            lib/
         cpp/
            lib/
         service_model/{at least one .xml file}
      common/
         sarm/
            ne_progs/
            PLSQL/
         control/
            PLSQL/
         nep/
            PLSQL/
         java/
            lib/
         cpp/
            lib/
         service_model/
         application_config/
         scripts/
```

Figure 1: File Structure of the Un-Jared .sar File

Testing the installation

The following procedure describes the steps required to test the cartridge installation in loopback mode. We recommend that you perform the initial cartridge installation test in loopback mode.

To test in loopback mode

1. Stop ASAP by typing the following command at the UNIX prompt:

   ```
   stop_asap_sys
   ```

2. Ensure loop back mode is on. See "Loopback mode" on page 14 for a description of how to set the loop back parameter to "On".

3. Start ASAP by typing:

   ```
   start_asap_sys
   ```

4. Send the sample work orders through the SRP Emulator by typing:

   ```
   run_suite $SRP <ctrl_password> <suite name>
   ```

   You can locate the suite names in /Nortel_DMS100_SN06/sample_wo by typing:

   ```
   grep   SUITE * | grep -v END
   ```

   A list of all available suites appears.

   To see the sample work orders, refer to Viewing the sample work orders, below.

   For more information on the SRP Emulator, refer to the *ASAP System Configuration and Management Guide*.

5. Verify the status of the sample work orders by typing:

   ```
   asap_utils l
   ```

   All successful work orders return the 104 state.

   To view the sample work orders provided with this cartridge, refer to the Nortel DMS100 cartridge source.

Viewing the sample work orders

You find the sample work orders under the sample_wo directory in the sar file. The following procedure describes how to view the sample work orders.

To view the sample work orders

1. If necessary, create a repository directory under /Nortel_DMS100_SN06, copy the sar file to the new directory and un-jar the sar file, as described by Step 1 through Step 4 in "Modifying dms100_sn06_pots_ne_config.xml" on page 15.

2. Locate and view the sample work order files under Nortel_DMS100_SN06/Nortel/DMS100_SN06/POTS/sample_wo.

3

Atomic Service Description Layer (ASDL) Commands

ASDL commands represent a set of atomic actions that ASAP can perform on a network element (NE). ASAP can combine ASDLs to create meaningful services (CSDLs) within a cartridge.

This chapter presents detailed information on the ASDL parameters that we provide with this cartridge. The following table lists and describes the type of parameter information that is included.

Table 4: ASDL parameter information

Item	Description
Parameter Name	Identifies the parameter that is configured for the stated service.
Description	Describes the parameter.
Range	Describes or lists the range of values that can be used to satisfy this parameter.
Default Value	Configures a default value for the parameter so that it is not mandatory for the upstream system to provide a value.

Table 4: ASDL parameter information

Item	Description
Type	Indicates one of the following parameter types: ◆ S—Scalar, specifies the parameter label transmitted on the ASDL command. Scalar parameters are conventional name-value pair parameters. ◆ C—Compound, specifies the base name of the compound parameter transmitted on the ASDL command. A compound parameter contains structures or arrays of information that are represented by a particular structure name or compound parameter name. Each compound parameter can contain a large number of elements. If you use compound parameters, you only require a single entry in the ASAP translation tables to call the compound parameter and all its associated parameter elements. ◆ I—Indexed, identifies a parameter that contains a sequential numerical index value to tell the SARM that it should execute the same operation (for example, an ASDL command) for all occurrences of that index. Consequently, if there are several options on a particular CSDL command (OPT1, OPT2, OPT3, etc.), you can specify the OPT parameter as an indexed parameter. When you specify the OPT parameter as an indexed parameter, the SARM generates several occurrences of that same ASDL command and each command has a different value for the option being transmitted to the NEP. For more information on parameter types, refer to the *ASAP Developer Reference*.
Class	Indicates one of the following parameter classifications: ◆ R—Required scalar parameter ◆ O—Optional scalar parameter ◆ C—Required compound parameter ◆ N—Optional compound parameter ◆ M—Mandatory indexed parameter ◆ I—Optional indexed parameter ◆ S—Parameter count

For a detailed description of the Required and Optional parameter classifications, refer to the *ASAP Administration Guide.*

Add Feature Services

This cartridge provides the following ASDL commands:

- A_NT-DMS100_SN06_ADD_3WC
- A_NT-DMS100_SN06_ADD_ACB
- A_NT-DMS100_SN06_ADD_ACD
- A_NT-DMS100_SN06_ADD_ACDNR
- A_NT-DMS100_SN06_ADD_ACRJ
- A_NT-DMS100_SN06_ADD_AIN
- A_NT-DMS100_SN06_ADD_AINDN
- A_NT-DMS100_SN06_ADD_AMSGDENY
- A_NT-DMS100_SN06_ADD_AR
- A_NT-DMS100_SN06_ADD_ARDDN
- A_NT-DMS100_SN06_ADD_ASL
- A_NT-DMS100_SN06_ADD_AUD
- A_NT-DMS100_SN06_ADD_AUL
- A_NT-DMS100_SN06_ADD_AUTODISP
- A_NT-DMS100_SN06_ADD_CBE
- A_NT-DMS100_SN06_ADD_CBU
- A_NT-DMS100_SN06_ADD_CCW
- A_NT-DMS100_SN06_ADD_CDE
- A_NT-DMS100_SN06_ADD_CDI
- A_NT-DMS100_SN06_ADD_CDU
- A_NT-DMS100_SN06_ADD_CFB
- A_NT-DMS100_SN06_ADD_CFBL
- A_NT-DMS100_SN06_ADD_CFD
- A_NT-DMS100_SN06_ADD_CFDA
- A_NT-DMS100_SN06_ADD_CFDVT
- A_NT-DMS100_SN06_ADD_CFF
- A_NT-DMS100_SN06_ADD_CFGD
- A_NT-DMS100_SN06_ADD_CFGDA
- A_NT-DMS100_SN06_ADD_CFI
- A_NT-DMS100_SN06_ADD_CFMDN
- A_NT-DMS100_SN06_ADD_CFRA
- A_NT-DMS100_SN06_ADD_CFS
- A_NT-DMS100_SN06_ADD_CFU
- A_NT-DMS100_SN06_ADD_CFW
- A_NT-DMS100_SN06_ADD_CHD
- A_NT-DMS100_SN06_ADD_CIF

- A_NT-DMS100_SN06_ADD_CIR
- A_NT-DMS100_SN06_ADD_CLF
- A_NT-DMS100_SN06_ADD_CLI
- A_NT-DMS100_SN06_ADD_CNAB
- A_NT-DMS100_SN06_ADD_CNAMD
- A_NT-DMS100_SN06_ADD_CND
- A_NT-DMS100_SN06_ADD_CND-NO-BILL
- A_NT-DMS100_SN06_ADD_CNDB
- A_NT-DMS100_SN06_ADD_CNF
- A_NT-DMS100_SN06_ADD_COD
- A_NT-DMS100_SN06_ADD_COT
- A_NT-DMS100_SN06_ADD_COT-NO-BILL
- A_NT-DMS100_SN06_ADD_CPU
- A_NT-DMS100_SN06_ADD_CSMI
- A_NT-DMS100_SN06_ADD_CUSD
- A_NT-DMS100_SN06_ADD_CWD
- A_NT-DMS100_SN06_ADD_CWI
- A_NT-DMS100_SN06_ADD_CWO
- A_NT-DMS100_SN06_ADD_CWT
- A_NT-DMS100_SN06_ADD_CWX
- A_NT-DMS100_SN06_ADD_CXR
- A_NT-DMS100_SN06_ADD_DCF
- A_NT-DMS100_SN06_ADD_DCPU
- A_NT-DMS100_SN06_ADD_DDN
- A_NT-DMS100_SN06_ADD_DENY
- A_NT-DMS100_SN06_ADD_DENYACB
- A_NT-DMS100_SN06_ADD_DENYAR
- A_NT-DMS100_SN06_ADD_DENYCOT
- A_NT-DMS100_SN06_ADD_DENYCSMI
- A_NT-DMS100_SN06_ADD_DENYISA
- A_NT-DMS100_SN06_ADD_DENYU3WC
- A_NT-DMS100_SN06_ADD_DGT
- A_NT-DMS100_SN06_ADD_DIN
- A_NT-DMS100_SN06_ADD_DISP
- A_NT-DMS100_SN06_ADD_DNH
- A_NT-DMS100_SN06_ADD_DOR

- A_NT-DMS100_SN06_ADD_DQS
- A_NT-DMS100_SN06_ADD_DQT
- A_NT-DMS100_SN06_ADD_DRCW
- A_NT-DMS100_SN06_ADD_DRING
- A_NT-DMS100_SN06_ADD_DSCWID
- A_NT-DMS100_SN06_ADD_DTM
- A_NT-DMS100_SN06_ADD_ELN
- A_NT-DMS100_SN06_ADD_EMW
- A_NT-DMS100_SN06_ADD_ESL
- A_NT-DMS100_SN06_ADD_FAA
- A_NT-DMS100_SN06_ADD_FANI
- A_NT-DMS100_SN06_ADD_FEATURES
- A_NT-DMS100_SN06_ADD_FTRGRP
- A_NT-DMS100_SN06_ADD_GIC
- A_NT-DMS100_SN06_ADD_GND
- A_NT-DMS100_SN06_ADD_HOT
- A_NT-DMS100_SN06_ADD_ICM
- A_NT-DMS100_SN06_ADD_INSPECT
- A_NT-DMS100_SN06_ADD_INT
- A_NT-DMS100_SN06_ADD_INTPIC
- A_NT-DMS100_SN06_ADD_KSH
- A_NT-DMS100_SN06_ADD_LCDR
- A_NT-DMS100_SN06_ADD_LDSA
- A_NT-DMS100_SN06_ADD_LDSO
- A_NT-DMS100_SN06_ADD_LNR
- A_NT-DMS100_SN06_ADD_LNRA
- A_NT-DMS100_SN06_ADD_LOB
- A_NT-DMS100_SN06_ADD_LOD
- A_NT-DMS100_SN06_ADD_LPIC
- A_NT-DMS100_SN06_ADD_LVM
- A_NT-DMS100_SN06_ADD_M518
- A_NT-DMS100_SN06_ADD_M536
- A_NT-DMS100_SN06_ADD_MDN
- A_NT-DMS100_SN06_ADD_MSB
- A_NT-DMS100_SN06_ADD_MSBI
- A_NT-DMS100_SN06_ADD_MWT

- A_NT-DMS100_SN06_ADD_NAME
- A_NT-DMS100_SN06_ADD_NDC
- A_NT-DMS100_SN06_ADD_NFA
- A_NT-DMS100_SN06_ADD_NGTSRVCE
- A_NT-DMS100_SN06_ADD_NLT
- A_NT-DMS100_SN06_ADD_OBS
- A_NT-DMS100_SN06_ADD_ONI
- A_NT-DMS100_SN06_ADD_PIC
- A_NT-DMS100_SN06_ADD_PORT
- A_NT-DMS100_SN06_ADD_PRK
- A_NT-DMS100_SN06_ADD_PRL
- A_NT-DMS100_SN06_ADD_QTD
- A_NT-DMS100_SN06_ADD_RAG
- A_NT-DMS100_SN06_ADD_RCHD
- A_NT-DMS100_SN06_ADD_RMI
- A_NT-DMS100_SN06_ADD_RMR
- A_NT-DMS100_SN06_ADD_RMT
- A_NT-DMS100_SN06_ADD_RPA
- A_NT-DMS100_SN06_ADD_RSP
- A_NT-DMS100_SN06_ADD_RSUS
- A_NT-DMS100_SN06_ADD_SACB
- A_NT-DMS100_SN06_ADD_SC1
- A_NT-DMS100_SN06_ADD_SC2
- A_NT-DMS100_SN06_ADD_SCA
- A_NT-DMS100_SN06_ADD_SCF
- A_NT-DMS100_SN06_ADD_SCL
- A_NT-DMS100_SN06_ADD_SCRJ
- A_NT-DMS100_SN06_ADD_SCS
- A_NT-DMS100_SN06_ADD_SCU
- A_NT-DMS100_SN06_ADD_SCWID
- A_NT-DMS100_SN06_ADD_SDN
- A_NT-DMS100_SN06_ADD_SDSDENY
- A_NT-DMS100_SN06_ADD_SHU
- A_NT-DMS100_SN06_ADD_SL
- A_NT-DMS100_SN06_ADD_SMDR
- A_NT-DMS100_SN06_ADD_SPB

- A_NT-DMS100_SN06_ADD_SRA
- A_NT-DMS100_SN06_ADD_SSAC
- A_NT-DMS100_SN06_ADD_SUPPRESS
- A_NT-DMS100_SN06_ADD_SUPR
- A_NT-DMS100_SN06_ADD_SVCGRP
- A_NT-DMS100_SN06_ADD_TCW
- A_NT-DMS100_SN06_ADD_TDN
- A_NT-DMS100_SN06_ADD_TFO
- A_NT-DMS100_SN06_ADD_UCD
- A_NT-DMS100_SN06_ADD_VMEADENY
- A_NT-DMS100_SN06_ADD_VMEADN
- A_NT-DMS100_SN06_ADD_WML
- A_NT-DMS100_SN06_ADD_WUC
- A_NT-DMS100_SN06_ADD_WUCR
- A_NT-DMS100_SN06_ADD_DCPK

A_NT-DMS100_SN06_ADD_3WC

This option allows the subscriber on the assigned line to place a call on hold. When the call is on hold, the subscriber can set up a request call to another subscriber. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.add3WC.**

Table 5: A_NT-DMS100_SN06_ADD_3WC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 5: A_NT-DMS100_SN06_ADD_3WC

Parameter Name	Description	Range	Default Value	Type	Class
THREE_WAY_CONFERENCE_OPTKEY	The key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_ACB

Adds the ACB option to a line. ACB allows to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addACB.**

Table 6: A_NT-DMS100_SN06_ADD_ACB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_CALL_BACK_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_CALL_BACK_BILLING_OPTION	The specified billing option, when the user assigns the CND or COT option to a RES line.	AMA=recorded, NOAMA=not recorded, or $		S	O

Table 6: A_NT-DMS100_SN06_ADD_ACB

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_BACK_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_ACD

Adds the ACD option to a line. ACD allows the subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addACD.**

Table 7: A_NT-DMS100_SN06_ADD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_CALL_DISTRIBUTION_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 7: A_NT-DMS100_SN06_ADD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_ACDGROUP	A group identifier that is already in table ACDGRP. Indicates the name of the automatic call distribution (ACD) group to which this station belongs.			S	R
AUTOMATIC_CALL_DISTRIBUTION_ACDSGRP	The number of the ACD subgroup to which this station belongs. This number must already appear in table ACDSGRP.			S	R
AUTOMATIC_CALL_DISTRIBUTION_IDNUM	Indicates if an ID number for a Supervisor set is present. This field appears only when a supervisor set uses NEWACD. If Y, the POSID field prompts.			S	R
AUTOMATIC_CALL_DISTRIBUTION_POSID	Enter the ACD agent position ID number. A POSID is for interactions with other ACD options.			S	R
AUTOMATIC_CALL_DISTRIBUTION_IBN_ACD_OPTION	Enter SCAILINK if the ACD agent associates with a set of D-channels for switch-computer communications. Enter ACDNR to deny ACD calls by the ACD agent.			C	R
AUTOMATIC_CALL_DISTRIBUTION_SCAI_LINK	Indicates the PRA D-channel name, or SCAIDEF for the default link set name.			S	O

A_NT-DMS100_SN06_ADD_ACDNR

Adds the ACRJ option to a line. The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addACDNR.**

Table 8: A_NT-DMS100_SN06_ADD_ACDNR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_CALL_DISTRIBUTION_NOT_READY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_ACRJ

Adds the ACRJ option. The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addACRJ.**

Table 9: A_NT-DMS100_SN06_ADD_ACRJ

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 9: A_NT-DMS100_SN06_ADD_ACRJ

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
ANONYMOUS_CALLER_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
ANONYMOUS_CALLER_BLOCKING_STATUS	INACT indicates that the user did not enable the option (not active). ACT indicates that the user enabled the option (active). UNIVI indicates that universal access through customer interface is not active. UNIVA indicates that universal access through customer interface is active.			S	R

A_NT-DMS100_SN06_ADD_AIN

Adds the AIN option to a line. The AIN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to

subscribe to an AINDN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAIN.**

Table 10: A_NT-DMS100_SN06_ADD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_ID_GROUP_AINGRP	The AIN group name used to define a group of trigger behaviors.			S	R
PRIVACY_ID_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
PRIVACY_ID_GROUP_KEYLIST	Specifies DN key numbers to which an option applies. Appears when the user assigns a subset option to BRI multi-line sets. If key number is not provided, assumes that value is $.			C	O

A_NT-DMS100_SN06_ADD_AINDN

Add the AINDN option to a line. The AINDN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item

interface to subscribe to an AINDN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAINDN.**

Table 11: A_NT-DMS100_SN06_ADD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_ID_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
PRIVACY_ID_AINGRP	Enter TIID to datafill the trigger for the following refinements to the item provisioning interface. Up to 16 alphanumeric characters, or TIID.			S	R
PRIVACY_ID_TDP	Datafill the appropriate TDP.	1, 3, 4, 17, 19, 20, 22, 30, 32, and 33		S	O
PRIVACY_ID_TINAME	An alphanumeric vector (1 to 8 characters) to datafill the trigger items defined in table TRIGITM at the specified TDP.			S	O

Table 11: A_NT-DMS100_SN06_ADD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
PRIVACY_ID_TRIGACT	Datafill the value ON to activate the trigger item identified by the TIID. Datafill the value OFF to deactivate the trigger item identified by the TIID.	ON or OFF		S	O

A_NT-DMS100_SN06_ADD_AMSGDENY

Adds the AMSGDENY option to a line. The AMSGDENY option prevents the line from receiving the access to a messaging service. The operating company assigns the AMSGDENY option. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAMSGDENY.**

Table 12: A_NT-DMS100_SN06_ADD_AMSGDENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_AR

Adds the AR option to a line. The AR option allows a subscriber to call the last station that called the subscriber. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAR.**

Table 13: A_NT-DMS100_SN06_ADD_AR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_RECALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_RECALL_BILLING_OPTION	The specified billing option when the user assigns the CND or COT option to a RES line.	AMA=recorded, NOAMA=not recorded, or $		S	O
AUTOMATIC_RECALL_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_ARDDN

Adds the ARDDN option to a line. The ARDDN option allows subscribers to dial a feature code that sets up a call to the directory number (DN) where the subscriber placed the last call.

It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addARDDN.**

Table 14: A_NT-DMS100_SN06_ADD_ARDDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_RECALL_DIALABLE_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_ASL

Adds the ASL option to a line. The ASL option allows a supervisor to monitor the status of an agent position. This process does not interfere with the call. The lamp for the assigned agent status key reflects the status of the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addASL.**

Table 15: A_NT-DMS100_SN06_ADD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 15: A_NT-DMS100_SN06_ADD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AGENT_STATUS_LAMP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AGENT_STATUS_LAMP_AGENT_LEN	The LEN of the agent position.			S	R
AGENT_STATUS_LAMP_MSBOVRD	Make set busy override.			S	R
AGENT_STATUS_LAMP_ASLSDN	Agent status lamp that monitors the SDN of an ACD agent. Key number for the secondary DN the user must monitor.			S	R

A_NT-DMS100_SN06_ADD_AUD

Adds the AUD option to a line. The AUD option allows a business set subscriber to call a number the subscriber dials frequently. The subscriber presses the AUD key to call this number. The subscriber can program and change this number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAUD.**

Table 16: A_NT-DMS100_SN06_ADD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 16: A_NT-DMS100_SN06_ADD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_DIAL_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_DIAL_PGMAUD	Indicates person who programs the AUD key.	Y = yes (operating company programmed); N = no (subscriber programmed)		S	R
AUTOMATIC_DIAL_AUDFEAT	The option or service to be accessed.			S	R

A_NT-DMS100_SN06_ADD_AUL

Adds the AUL option to a line. The automatic line (AUL) option connects to a set location when a directory number (DN) or an assigned AUL option line reports an off-hook status. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAUL.**

Table 17: A_NT-DMS100_SN06_ADD_AUL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 17: A_NT-DMS100_SN06_ADD_AUL

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_LINE_DN	Automatic line DN.			S	O
AUTOMATIC_LINE_NPA	Automatic line NPA.			S	O
AUTOMATIC_LINE_NXX	Automatic line NXX.			S	O
AUTOMATIC_LINE_LINE	Automatic line LINE.			S	O

A_NT-DMS100_SN06_ADD_AUTODISP

Adds the AUTODISP option to a line. The automatic display (AUTODISP) option automatically shows information on incoming calls to a Meridian business set (MBS). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addAUTODISP.**

Table 18: A_NT-DMS100_SN06_ADD_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 18: A_NT-DMS100_SN06_ADD_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_DISPLAY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_DISPLAY_CWT_OPTION	Indicates person who programs the AUD key.	Y = yes (operating company programmed); N = no (subscriber programmed)		S	R
AUTOMATIC_DISPLAY_KEYLIST	The option or service to be accessed.			C	O

A_NT-DMS100_SN06_ADD_CBE

Adds the CBE option to a line. The Call Forwarding Busy Internal Calls Only option allows a subscriber to stop the system when the system forwards external calls. This option allows intragroup calls to forward to a remote station in the customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCBE.**

Table 19: A_NT-DMS100_SN06_ADD_CBE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 19: A_NT-DMS100_SN06_ADD_CBE

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_INTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CBU

Adds the CBU option to a line. The CBU option allows Call Forwarding Busy calls to forward to remote stations outside and inside the customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCBU.**

Table 20: A_NT-DMS100_SN06_ADD_CBU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_CCW

Adds the CCW option to a line. The Cancel Call Waiting (CCW) option allows Call Waiting (CWT) subscribers to turn off the CWT option. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCCW.**

Table 21: A_NT-DMS100_SN06_ADD_CCW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CANCEL_CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CDE

Adds the CDE option to a line. The CDE option prevents the forwarding of calls from outside the customer group. This option can make sure that external calls do not flood the remote station when many of the incoming calls are external. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCDE.**

Table 22: A_NT-DMS100_SN06_ADD_CDE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 22: A_NT-DMS100_SN06_ADD_CDE

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_EXCLUDE_EXTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CDI

Adds the CDI option to a line. The CDI option prevents the forwarding of intragroup calls. The CDI makes sure that intragroup calls do not flood the remote station. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCDI.**

Table 23: A_NT-DMS100_SN06_ADD_CDI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 23: A_NT-DMS100_SN06_ADD_CDI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_EXCLUDE_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CDU

Adds the CDU option to a line. The CDU option allows the system to forward all calls that are not answered to a remote station that is outside or inside customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCDU.**

Table 24: A_NT-DMS100_SN06_ADD_CDU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_CFB

Adds the CFB option to a line. The CFB option allows the system to forward all calls to a busy station to a station determined earlier. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFB.**

Table 25: A_NT-DMS100_SN06_ADD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_BUSY_CNTL	Call forwarding busy control.	F = fixed assignment for CFB, N = normal (default) assignment for CFB, P = programmed assignment for CFB, K = programmed assignment for CFB per key destination		S	O
CALL_FORWARD_BUSY_DN	Call forwarding DN for CFB option.			S	O
CALL_FORWARD_BUSY_NPA	Call forwarding NPA for CFB option.			S	O
CALL_FORWARD_BUSY_NXX	Call forwarding NXX for CFB option.			S	O

Table 25: A_NT-DMS100_SN06_ADD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_LINE	Call forwarding LINE for CFB option.			S	O
CALL_FORWARD_BUSY_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_CFBL

Adds the CFBL option to a line. The CFBL option allows the subscriber to specify a directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFBL.**

Table 26: A_NT-DMS100_SN06_ADD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_LINE_SCRNCL	Screening by class of service.			S	R

Table 26: A_NT-DMS100_SN06_ADD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_LINE_CFBLCNTL	Call forwarding busy line control.	F = fixed assignment for CFBL, N = normal (default) assignment for CFBL, C = programmed assignment for CFBL		S	R
CALL_FORWARD_BUSY_LINE_NUMCALLS	The number of calls the system can forward at the same time. Value 0-1024			S	R
CALL_FORWARD_BUSY_LINE_DN	DN to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NPA	NPA to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NXX	NXX to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_LINE	Line to which the system will forward calls.			S	O

A_NT-DMS100_SN06_ADD_CFD

Adds the CFD option to a line. The CFD option allows the system to forward incoming calls that are not answered within a specified time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFD.**

Table 27: A_NT-DMS100_SN06_ADD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 27: A_NT-DMS100_SN06_ADD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_NO_ANSWER_BUS_CNTL	Call forwarding busy control.	F = fixed assignment for CFD, N = normal (default) assignment for CFD, P = programmed assignment for CFD, K = programmed assignment for CFD per key destination		S	O
CALL_FORWARD_NO_ANSWER_BUS_DN	Call forwarding DN for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NPA	Call forwarding NPA for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NXX	Call forwarding NXX for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_LINE	Call forwarding LINE for CFD option.			S	O

Table 27: A_NT-DMS100_SN06_ADD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_BUS_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_CFDA

Adds the CFDA option to a line. The Call Forwarding Do Not Answer (CFDA) Residential option forwards calls not answered to stations in the same customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFDA.**

Table 28: A_NT-DMS100_SN06_ADD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_RES_CNTL	Call Forwarding Do Not Answer control.	F means fixed, N means normal (default), and C means programmed assignment		S	O
CALL_FORWARD_NO_ANSWER_RES_SCRNCL	Screening identifies screening by class of service.			S	R

Table 28: A_NT-DMS100_SN06_ADD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_RES_NUMCALLS	The number of calls the system can forward at the same time.			S	R
CALL_FORWARD_NO_ANSWER_RES_TIME	Indicates the period of time the base station rings before forwarding.			S	R
CALL_FORWARD_NO_ANSWER_RES_RING_CTRL	Indicates whether the end user or the operating company controls the ringing time-out. PRGRING allows the end user to change the CFDA ringing time-out. FIXRING indicates that only the operating company can change the ringing time-out.			S	R
CALL_FORWARD_NO_ANSWER_RES_DN	Number to which the system forwards calls.			S	O
CALL_FORWARD_NO_ANSWER_RES_NPA	Call forwarding NPA for CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_NXX	Call forwarding NXX for CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_LINE	Call forwarding LINE for CFDA option.			S	O

A_NT-DMS100_SN06_ADD_CFDVT

Adds the CFDVT option to a line.The Call Forwarding Do Not Answer Variable Timer (CFDVT) option allows an end-user to specify how long a call rings before the system

forwards the call to another station. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFDVT.**

Table 29: A_NT-DMS100_SN06_ADD_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_VAR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_NO_ANSWER_VAR_TIME	Call forward do not answer timing. The time, in seconds, that a call rings before the system forwards the call to the next DN.	0-60		S	R
CALL_FORWARD_NO_ANSWER_VAR_RING_CTRL	Ring control. Enter PRGRING to allow end-user to set CVDVT time-out period. Enter FIXRING to indicate to end-user that the CVDVT time-out period is fixed; it can only be changed by the operating company.			S	R

A_NT-DMS100_SN06_ADD_CFF

Adds the CFF option to a line. The CFF option allows the station to forward calls to a location the operating company enters. The user cannot program the number to which the station forwards the calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFF.**

Table 30: A_NT-DMS100_SN06_ADD_CFF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_FIXED_CFFDN	Call forwarding DN for CFF option.			S	O
CALL_FORWARD_FIXED_CFF_OPTION	The value to set the CFFA to active.			S	O

A_NT-DMS100_SN06_ADD_CFGD

Adds the CFGD option to a line. The CFGD option allows a user to assign call forwarding do not answer to separate Hunt groups. With CFGD, calls to idle Hunt group stations ring for a set number of times before the system forwards the calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFGD.**

Table 31: A_NT-DMS100_SN06_ADD_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 31: A_NT-DMS100_SN06_ADD_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_INTERNAL	Indicates whether the system forwards the call to a member of the Hunt group.	Y=YES, N=NO		S	R
CALL_FORWARD_GROUP_NO_ANSWER_BUS_TIMEOUT	Specifies the length of time in seconds before an unanswered call is forwarded.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_DN	Call forwarding DN for CFGD option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_NPA	Call forwarding NPA for CFGD option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_NXX	Call forwarding NXX for CFGD option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_LINE	Call forwarding LINE for CFGD option.			S	O

Table 31: A_NT-DMS100_SN06_ADD_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_BUS_SPECTIME	Special timeout for Call Forward Do Not Answer option.	Y=YES, N=NO		S	R
CALL_FORWARD_GROUP_NO_ANSWER_BUS_TYPE	Call forwarding type.	N = no restrictions, CFGDI = restrict intragroup, CFGDE = restrict extragroup		S	R

A_NT-DMS100_SN06_ADD_CFGDA

Adds the CDGDA option to a line. This option allows the system administrator to assign call forwarding to a Hunt group. Calls to idle Hunt group stations ring for a set period of time before the system forwards the calls to a DN outside the Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFGDA.**

Table 32: A_NT-DMS100_SN06_ADD_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_SCRNCL	Identifies screening by class of service.			S	R

Table 32: A_NT-DMS100_SN06_ADD_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_RES_NUMCALLS	The number of calls the system can forward at the same time.			S	R
CALL_FORWARD_GROUP_NO_ANSWER_RES_TIME	Indicates the period of time the base station rings before forwarding.			S	R
CALL_FORWARD_GROUP_NO_ANSWER_RES_INTERNAL	Indicates whether the system forwards the call to a member of the Hunt group.	Y=YES, N=NO		S	R
CALL_FORWARD_GROUP_NO_ANSWER_RES_DN	Number to which the system forwards calls.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_NPA	Call forwarding NPA for CFGDA option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_NXX	Call forwarding NXX for CFGDA option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_LINE	Call forwarding LINE for CFGDA option.			S	O

A_NT-DMS100_SN06_ADD_CFI

Adds the CFI option to a line. The CFI option allows stations to forward calls only to locations in the customer group that the customer defines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFI.**

Table 33: A_NT-DMS100_SN06_ADD_CFI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_INTRAGROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_INTRAGROUP_KEYLIST	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature.If key number is not provided, assumes that value is $.			C	O

A_NT-DMS100_SN06_ADD_CFMDN

Adds the CFMDN option to a line. The Call Forwarding MADN Secondary Number (CFMDN) option lets secondary units of a multiple appearance directory number (MADN) group, activate call forwarding (CFF, CFU and CFI only) from a station. It is implemented by

the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFMDN.

Table 34: A_NT-DMS100_SN06_ADD_CFMDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_MADN_DN_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CFRA

Adds the CFRA option to a line. The Call Forwarding Remote Access (CFRA) option allows a single-line set to use a line other than its own. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFRA.**

Table 35: A_NT-DMS100_SN06_ADD_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 35: A_NT-DMS100_SN06_ADD_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_REMOTE_ACTIVATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_REMOTE_ACTIVATION_PIN	The first personal identification number (PIN) the operating company assigns to the line.	2-10 digits		S	R
CALL_FORWARD_REMOTE_ACTIVATION_FIRSTUSE	Indicates whether the user must change the PIN before using CFRA for the first time. This prompt applies when option SPP is entered in table CUSTSTN. This field must be set to Y. This action requires the user to change their PIN with SPP before using CFRA for the first time.	Y or N		S	O

A_NT-DMS100_SN06_ADD_CFS

Adds the CFS option to a line. The Call Forwarding Simultaneous/Screening (CFS) option allows the user to call forward more than one call through a station at a time. It is implemented

by the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFS.

Table 36: A_NT-DMS100_SN06_ADD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_SIMULTANEUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_SIMULTANEUS_SIMULT	Indicates Call Forwarding Simultaneous.			S	R
CALL_FORWARD_SIMULTANEUS_NCFUIF	Maximum number of active calls the user can forward through a CFU, CFI, or CFF base station at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_NCFB	Maximum number of active calls the user can forward through a CFB base station at the same time.			S	R

Table 36: A_NT-DMS100_SN06_ADD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_NCFD	The number of calls the user can forward for call forward do not answer at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_SCREEN	Call forwarding screening capability.			S	R
CALL_FORWARD_SIMULTANEUS_CFXNCOS	Call forwarding NCOS.			S	R

A_NT-DMS100_SN06_ADD_CFU

Adds the CFU option to a line. The CFU option allows a station user to reroute incoming calls to another telephone number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFU.**

Table 37: A_NT-DMS100_SN06_ADD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 37: A_NT-DMS100_SN06_ADD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_UNIVERSAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_UNIVERSAL_OVRDACR	Override for account code required.	Y = Yes, N = No		S	R
CALL_FORWARD_UNIVERSAL_KEYLIST	Specifies the key numbers of the DNs to which an option will apply. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_CFW

Adds the CFW option to a line. The CFW option allows the user to forward calls to another location. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCFW.**

Table 38: A_NT-DMS100_SN06_ADD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 38: A_NT-DMS100_SN06_ADD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_TYPE	Type of call forwarding.	C = customer, F = fixed, U = usage sensitive pricing		S	R
CALL_FORWARD_SCRNCL	Screening by class of service.			S	R
CALL_FORWARD_STATE	State of absent subscriber intercept. Default is $.	A = active, I = inactive, W = wait		S	O
CALL_FORWARD_NUMCALLS	The number of calls the user can forward at the same time.	0-1024		S	O
CALL_FORWARD_DN	Number to which calls will be forwarded.	1-30 digits. "$" must not be used		S	O
CALL_FORWARD_NPA	NPA to which calls will be forwarded.			S	O
CALL_FORWARD_NXX	NXX to which calls will be forwarded.			S	O
CALL_FORWARD_LINE	LINE to which calls will be forwarded.			S	O

A_NT-DMS100_SN06_ADD_CHD

Adds the CHD option to a line. The Call Hold (CHD) option allows a subscriber with a 500/2500 set to hold a call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCHD.**

Table 39: A_NT-DMS100_SN06_ADD_CHD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 39: A_NT-DMS100_SN06_ADD_CHD

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_CIF

Adds the CIF option to a line. The Controlled Interflow (CIF) option allows a supervisor to place an automatic call distribution (ACD) group in a controlled interflow mode. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCIF.**

Table 40: A_NT-DMS100_SN06_ADD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CONTROLLED_INTERFLOW_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 40: A_NT-DMS100_SN06_ADD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
CONTROLLED_INTERFLOW_ACDGROUP	The name of the automatic call distribution group name. The name is a group identifier the user must datafill in Table ACDGRP.			S	R

A_NT-DMS100_SN06_ADD_CIR

Adds the CIR option to a line. The Circular Hunt (CIR) option allows hunting to complete a full cycle through a Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCIR.**

Table 41: A_NT-DMS100_SN06_ADD_CIR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CIRCULAR_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CLF

Adds the CLF option to a line. The Calling Line Identification with Flash (CLF) option allows a subscriber to hold an incoming call in the switch. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCLF.**

Table 42: A_NT-DMS100_SN06_ADD_CLF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_CLI

Adds the CLI option to a line. Local and toll calls can stop on the line of the subscriber. If the calls stop, the Calling Line Identification (CLI) option records the following information on the DMS log system. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCLI.**

Table 43: A_NT-DMS100_SN06_ADD_CLI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 43: A_NT-DMS100_SN06_ADD_CLI

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRACE_CLI_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CNAB

Adds the CNAB option to a line. The CNAB option allows the system to block the delivery of the name of the caller. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCNAB.**

Table 44: A_NT-DMS100_SN06_ADD_CNAB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_CNAMD

Adds the CNAMD option to a line. The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE). It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCNAMD.**

Table 45: A_NT-DMS100_SN06_ADD_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALLER_ID_NAME_DELIVERY_BILLING_OPTION	The billing option that the user must specify, when the user assigns the CNAMD.	AMA = AMA record created, NOAMA = AMA record not created		S	O
CALLER_ID_NAME_DELIVERY_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_CND

Adds the CND option to a line. The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is enabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCND.**

Table 46: A_NT-DMS100_SN06_ADD_CND

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 46: A_NT-DMS100_SN06_ADD_CND

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALLING_NUMBER_DELIVERY_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O

A_NT-DMS100_SN06_ADD_CND-NO-BILL

Adds the CND no bill option to a line. The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is disabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCNDNoBill.**

Table 47: A_NT-DMS100_SN06_ADD_CND-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_CNDB

Adds the CNDB option to a line. The Calling Number Delivery Blocking (CNDB) option blocks the delivery of the calling number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCNDB.**

Table 48: A_NT-DMS100_SN06_ADD_CNDB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALLING_NUMBER_DELIVERY_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALLING_NUMBER_DELIVERY_BLOCKING_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O

A_NT-DMS100_SN06_ADD_CNF

Adds the CNF option to a line. The Station Controlled Conference (CNF) option allows a station to have a conference call to a maximum of 30 parties. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCNF.**

Table 49: A_NT-DMS100_SN06_ADD_CNF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_CONTROLLED_CONFERENCE_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
STATION_CONTROLLED_CONFERENCE_CONF_TYPE	The maximum number of stations that can connect to a station controlled conference.			S	R

A_NT-DMS100_SN06_ADD_COD

Adds the COD option to a line. The Cutoff on Disconnect (COD) option applies an open battery signal to the line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCOD.**

Table 50: A_NT-DMS100_SN06_ADD_COD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_COT

Adds the COT option to a line. The COT option allows the recipient of a harassing call to request an automatic trace of the call. The billing option is enabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCOT.**

Table 51: A_NT-DMS100_SN06_ADD_COT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 51: A_NT-DMS100_SN06_ADD_COT

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRACER_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O
CALL_TRACER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_TRACER_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_COT-NO-BILL

Adds the COT option to a line. The COT option allows the recipient of a harassing call to request an automatic trace of the call. The billing option is disabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCOTNoBill.**

Table 52: A_NT-DMS100_SN06_ADD_COT-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 52: A_NT-DMS100_SN06_ADD_COT-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRACER_NO_BILL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CPU

Adds the CPU option to a line. The Call Pickup (CPU) option allows a station to answer incoming calls to another station in the same pickup group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCPU.**

Table 53: A_NT-DMS100_SN06_ADD_CPU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_PICKUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 53: A_NT-DMS100_SN06_ADD_CPU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_PICKUP_CPU _LEN	Indicates the CPU number.			S	R

A_NT-DMS100_SN06_ADD_CSMI

Adds the CSMI option to a line. The CSMI feature allows end users of Network Based Answering Services (NBAS) to monitor and intercept calls that the NBAS handles. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCSMI.**

Table 54: A_NT-DMS100_SN06_ADD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_SCREENING_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_SCREENING_ CSMISTATE	The state of the activation of the CSMI feature.			S	O
CALL_SCREENING_ CSMIPPU	The billing option to use.		N	S	O

Table 54: A_NT-DMS100_SN06_ADD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_SCREENING_CONNEC3W	The call interception (2-way call or 3-way call).		N	S	O
CALL_SCREENING_SCRACTIVE	Indicates whether the SCRDUR parameter is required or not.		N	S	O
CALL_SCREENING_SCRDUR	The length of screening period.		20	S	O
CALL_SCREENING_DENYOPT	The type of call forward for which CSMI is applied.			C	O

A_NT-DMS100_SN06_ADD_CUSD

Adds the CUSD option to a line. The Call Forwarding Usage Sensitive Denial (CUSD) option prevents the use of the POTS Call Forwarding Usage Sensitive Pricing (CFUSP) option. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCUSD.**

Table 55: A_NT-DMS100_SN06_ADD_CUSD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_CWD

Adds the CWD option to a line. The Dial Call Waiting (CWD) option allows a business set user to impose call waiting on a busy station. The busy station can be a 500/2500 set or a business set with a call waiting (CWT) feature key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCWD.**

Table 56: A_NT-DMS100_SN06_ADD_CWD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DIAL_CALL_WAITING_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CWI

Adds the CWI option to a line. The Call Waiting Intragroup (CWI) option allows a subscriber to apply the CWT option to intragroup calls, in addition to those allowed with CWT. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCWI.**

Table 57: A_NT-DMS100_SN06_ADD_CWI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 57: A_NT-DMS100_SN06_ADD_CWI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CWO

Adds the CWO option to a line. The Call Waiting Originating (CWO) option allows an originating line to impose a call waiting tone automatically on a busy called line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCWO.**

Table 58: A_NT-DMS100_SN06_ADD_CWO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 58: A_NT-DMS100_SN06_ADD_CWO

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_ORIGINATING_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CWT

Adds the CWT option to a line. The Call Waiting (CWT) option allows the system to alert a busy station when an incoming call attempts to reach the directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCWT.**

Table 59: A_NT-DMS100_SN06_ADD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_WAITING_CWT_OPTION	Indicates whether the CWT option is active.	Y = Yes, N = No		S	O

Table 59: A_NT-DMS100_SN06_ADD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_RING	Specifies whether a ring from a telephone speaker is required in addition to the LCD diamond CWT key.	Y or N		S	O
CALL_WAITING_PCWT	Precedence call waiting.	Y = Yes, N = No		S	O
CALL_WAITING_KEYLIST	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature.	Key number (1-69), list of key numbers, or $		C	O

A_NT-DMS100_SN06_ADD_CWX

Adds the CWX option to a line. The Call Waiting Exempt (CWX) option does not allow Dial Call Waiting (CWD) and Call Waiting Originating (CWO) to interrupt a business set user. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCWX.**

Table 60: A_NT-DMS100_SN06_ADD_CWX

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 60: A_NT-DMS100_SN06_ADD_CWX

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_EXEMPT_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_CXR

Adds the CXR option to a line. The call transfer (CXR) option allows the assignment of a call transfer type other than the type that the customer group has. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addCXR.**

Table 61: A_NT-DMS100_SN06_ADD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRANSFER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Table 61: A_NT-DMS100_SN06_ADD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_TYPE	Call transfer type.	CTOUT = call transfer outgoing calls, CTINC = call transfer incoming calls, CTINTRA = call transfer intra group, CTALL = call transfer all, NCT = the system routes the call to the attendant if the first leg of the call is INTERGROUP and the controller is terminator of the call, ATTRCLF = the system routes the call to the attendant at all times, CUSTOM = call transfer of types other than above		S	R
CALL_TRANSFER_ORGINTER	For a CUSTOM type call transfer, the first leg of the call is intergroup. The controller is the originator of the call.	AC = second leg of the call is to the attendant, Inter = second leg of the call can be intergroup, Intra = second leg of the call can be intragroup, Trater = second leg of the call can be intragroup or intergroup, Nocxfer = call transfer is not allowed		S	O
CALL_TRANSFER_ORGINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_TRMINTER	First leg of the call is intragroup and the controller is the originator of the call.			S	O

Table 61: A_NT-DMS100_SN06_ADD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_TRMINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_RCL	Call transfer recall.			S	R
CALL_TRANSFER_RCLTIM	Recall timer for transfer recall.			S	O
CALL_TRANSFER_METHOD	The method of call transfer.	Dial (DIAL), Standard (STD), or Release (RLS)		S	R

A_NT-DMS100_SN06_ADD_DCF

Adds the DCF option to a line. The Denied Call Forwarding (DCF) option does not allow a line to receive forwarded calls. This security option helps to protect computer ports. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDCF.**

Table 62: A_NT-DMS100_SN06_ADD_DCF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 62: A_NT-DMS100_SN06_ADD_DCF

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_CALL_FORWARDING_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_DCPU

Adds the DCPU option to a line. The DCPU option allows a station to answer a ringing line in the same customer group before the called party answers the ringing line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDCPU.**

Table 63: A_NT-DMS100_SN06_ADD_DCPU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DDN

Adds the DDN option to a line. The Dialable Directory Number (DDN) option allows the customer premises equipment (CPE) to display incoming calling name, number, and the time

and date of the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDDN.**

Table 64: A_NT-DMS100_SN06_ADD_DDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DIALABLE_DN_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O

A_NT-DMS100_SN06_ADD_DENY

Adds the DENY option to a line. The DENY option prevents individual lines from gaining access to particular Custom Local Area Signaling Services (CLASS) features that are available using Universal Access (UA). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENY.**

Table 65: A_NT-DMS100_SN06_ADD_DENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 65: A_NT-DMS100_SN06_ADD_DENY

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_ACCESS_CLASS_FEATURES_DENYOPT	Specifies the CLASS option to deny on switches.			C	R

A_NT-DMS100_SN06_ADD_DENYACB

Adds the DENYACB option to a line. The DENYACB option prevents the use of the automatic call return feature. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENYACB.**

Table 66: A_NT-DMS100_SN06_ADD_DENYACB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DENYAR

Adds the DENYAR option to a line. The DENYAR option prevents individual lines from gaining access to automatic recall feature that are available using Universal Access (UA). It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENYAR.**

Table 67: A_NT-DMS100_SN06_ADD_DENYAR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DENYCOT

Adds the DENYCOT option to a line. The DENYCOT option prevents the use of the incoming call tracing feature. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENYCOT.**

Table 68: A_NT-DMS100_SN06_ADD_DENYCOT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DENYCSMI

Adds the DENYCSMI option to a line. The DENYCSMI feature prevents users from activating the CSMI option (Call Screening, Monitoring and Intercept) on certain types of call forwarding. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENYCSMI.**

Table 69: A_NT-DMS100_SN06_ADD_DENYCSMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_CALL_SCREENING_DENYOPT	Specifies the type of call forwarding to which CSMI is applied.			C	R

A_NT-DMS100_SN06_ADD_DENYISA

Adds the DENYISA option to a line. The DENYISA feature allows an ISA (In-Session Activation) subscriber to deactivate the ISA feature for each call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENYISA.**

Table 70: A_NT-DMS100_SN06_ADD_DENYISA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 70: A_NT-DMS100_SN06_ADD_DENYISA

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_IN_SESSION_ACTIVATION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_DENYU3WC

Adds the DENYU3WC option to a line. The DENYU3WC option prevents the use of the U3WC feature when U3WC is applied to a RES line or POTS line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDENYU3WC.**

Table 71: A_NT-DMS100_SN06_ADD_DENYU3WC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DGT

Adds the DGT option to a line. The DGT option allows a telephone set to generate an address in the form of dual-tone multi-frequency signals. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDGT.**

Table 72: A_NT-DMS100_SN06_ADD_DGT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DIN

Adds the DIN option to a line. The DIN option prevents selected lines from receiving incoming calls that originate outside the customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDIN.**

Table 73: A_NT-DMS100_SN06_ADD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 73: A_NT-DMS100_SN06_ADD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
DENIED_INCOMING_CALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DENIED_INCOMING_CALL_TRC	Terminating restriction code used with the IBN DIN option. Code indicates the classes of incoming calls allowed on a trunk. The value is in a format of a list in series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DENIED_INCOMING_CALL_ALTTRC	Alternate terminating restriction code. This code applies to IBN extended calls. The value is in a format of a list in a series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DENIED_INCOMING_CALL_DINOPT	Assigns the Transfer Call to Restricted Station (DINE) sub-option to a line.	DINE = Accepts some types of transferred calls, N = Does not accept transferred calls		S	R

A_NT-DMS100_SN06_ADD_DISP

Adds the DISP option to a line. The Display (DISP) option indicates that a business set on a PSET line is a display business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDISP.**

Table 74: A_NT-DMS100_SN06_ADD_DISP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_DNH

Adds the DNH option to a line. The Directory Number Hunt (DNH) option allows directory number hunting. Each line in the Hunt group has a directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDNH.**

Table 75: A_NT-DMS100_SN06_ADD_DNH

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 75: A_NT-DMS100_SN06_ADD_DNH

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DIRECTORY_NUMBER_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DIRECTORY_NUMBER_HUNT_DN	DN of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_NPA	NPA of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_NXX	NXX of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_LINE	LINE of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_GROUPSIZE	Hunt group size. The expected maximum size of the Hunt group.			S	O

A_NT-DMS100_SN06_ADD_DOR

Adds the DOR option to a line. The Denied Origination (DOR) option prevents a line from originating calls. If the user attempts to originate a call from that line, the call receives originating suspended service (ORSS) treatment. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDOR.**

Table 76: A_NT-DMS100_SN06_ADD_DOR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_ORIGINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_DQS

Adds the DQS option to a line. The Display Queue Status (DQS) option allows an ACD supervisor to display the load status information for an ACD group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDQS.**

Table 77: A_NT-DMS100_SN06_ADD_DQS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 77: A_NT-DMS100_SN06_ADD_DQS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_QUEUE_STATUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISPLAY_QUEUE_STATUS_ACDGROUP	A group identifier already in Table ACDGRP.			S	R

A_NT-DMS100_SN06_ADD_DQT

Adds the DQT option to a line. The Display Queue Threshold (DQT) option allows the system to display the status of the incoming call queue. The queue status appears when the ACD agent or supervisor presses the associated key of the set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDQT.**

Table 78: A_NT-DMS100_SN06_ADD_DQT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 78: A_NT-DMS100_SN06_ADD_DQT

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_QUEUE_THRESHOLD_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DISPLAY_QUEUE_THRESHOLD_DIFFGRP	Indicates if the system uses a group other than the ACD INCALLS group to establish the queue threshold status.			S	R

A_NT-DMS100_SN06_ADD_DRCW

Adds the DRCW option to a line. The Distinctive Ringing/Call Waiting (DRCW) option allows the system to identify terminating calls with a distinct alert pattern. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDRCW.**

Table 79: A_NT-DMS100_SN06_ADD_DRCW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 79: A_NT-DMS100_SN06_ADD_DRCW

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_CALL_WAITING_BILLING_OPTION	The specified billing option, when the user assigns the CND or COT option to a RES line.	AMA=recorded, NOAMA=not recorded, or $		S	O
DISTINCTIVE_RING_CALL_WAITING_STATUS	INACT indicates that the user did not enable the option (not active). ACT indicates that the user enabled the option (active). UNIVI indicates that universal access through customer interface is not active. UNIVA indicates that universal access through customer interface is active.			S	R
DISTINCTIVE_RING_CALL_WAITING_DNS	Directory number the user adds to the SCRJ list.			C	O
DISTINCTIVE_RING_CALL_WAITING_VBCOUNT	The number of digits that voice back during SCRJ list review.			C	O
DISTINCTIVE_RING_CALL_WAITING_NPA	The NPA the user adds to the SCRJ list.			C	O
DISTINCTIVE_RING_CALL_WAITING_NXX	The NXX the user adds to the SCRJ list.			C	O
DISTINCTIVE_RING_CALL_WAITING_LINE	The LINE the user adds to the SCRJ list.			C	O

A_NT-DMS100_SN06_ADD_DRING

Adds the DRING option to a line. The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDRING.**

Table 80: A_NT-DMS100_SN06_ADD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISTINCTIVE_RING_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISTINCTIVE_RING_INTRNL	Indicates that intragroup calls have distinctive ringing.			S	R
DISTINCTIVE_RING_EXTRNL	External Calls			S	R
DISTINCTIVE_RING_INTRNL_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_EXTRNL_DRINGTYPE	Ring Type			S	O

Table 80: A_NT-DMS100_SN06_ADD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_GIC_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_RECALL_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_UCD_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_REST_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_ACD_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_MAKECALL_DRINGTYPE	Ring Type			S	O
DISTINCTIVE_RING_TRKS	IBN trunks.	SEL = selected trunks, ALL = all trunks, NO = no trunks		S	R
DISTINCTIVE_RING_GIC	Group Intercom.			S	R
DISTINCTIVE_RING_RECALL	Recall ringing.			S	R
DISTINCTIVE_RING_UCD	Uniform call distribution			S	R
DISTINCTIVE_RING_REST	Call types that remain.			S	R
DISTINCTIVE_RING_ACD	Automatic call distribution.			S	R
DISTINCTIVE_RING_MAKECALL	Indicates distinctive ringing for outbound calls at customer group level.			S	O

A_NT-DMS100_SN06_ADD_DSCWID

Adds the DSCWID option to a line. Deluxe Spontaneous Call Waiting Identification (DSCWID) allows the subscriber to receive calling-party information during call waiting. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDSCWID.**

Table 81: A_NT-DMS100_SN06_ADD_DSCWID

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_OPTIONS_DSUBOPT	The DSCWID suboption to be assigned. The DSWOPT is a vector that is a maximum of three suboptions. If the suboptions are not entered, the default values are used. DTYPE, DAMA, DEFTRMT.			C	O
CALL_WAITING_OPTIONS_DTYPEOPT	The DSCWID type name that indicates which DSCWID type to assign from table DSCWDTYP. Additional values are possible if tuples are datafilled in table DSCWDTYP.			C	O

Table 81: A_NT-DMS100_SN06_ADD_DSCWID

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_OPTIONS_DEFTRMTOPT	The default treatment that is applied when a DSCWID option is not specified.			C	O
CALL_WAITING_OPTIONS_DAMAOPT	The type of AMA recording the system uses with the CONFERENCE option. Enter NONE for no recording or CONF to generate an AMA billing record.			C	O

A_NT-DMS100_SN06_ADD_DTM

Adds the DTM option to a line. The DTM option prevents a line from receiving calls. Calls that attempt to terminate to a line with the DTM option receive denied terminating (DNTR) treatment. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDTM.**

Table 82: A_NT-DMS100_SN06_ADD_DTM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 82: A_NT-DMS100_SN06_ADD_DTM

Parameter Name	Description	Range	Default Value	Type	Class
DENY_TERMINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_ELN

Adds the ELN option to a line. The essential line (ELN) option designates a line as essential. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addELN.**

Table 83: A_NT-DMS100_SN06_ADD_ELN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
ESSENTIAL_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_EMW

Adds the EMW option to a line. The Executive Message Waiting (EMW) option introduces a message waiting class of service (MCOS) to enhance the message waiting option. A user can

only access the MCOS to which the user subscribes. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addEMW.**

Table 84: A_NT-DMS100_SN06_ADD_EMW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
EXECUTIVE_MESSAGE_WAIT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
EXECUTIVE_MESSAGE_WAIT_DNLIST	A DN key that subscribes to an MCOS. Specify one key for each MCOS.	1-69		C	O
EXECUTIVE_MESSAGE_WAIT_NOTICE	Message waiting notification.	STD = stuttered dial tone, MWL = message waiting lamp, CMWI = CLASS message waiting Indicator, PRN = periodic ring notification		S	O
EXECUTIVE_MESSAGE_WAIT_MCOS	The name of the MCOS the MDC line subscribes, or the key set.			C	O

A_NT-DMS100_SN06_ADD_ESL

Adds the ESL option to a line. The Emergency Service Line (ESL) allows a line for emergency service to be designated. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addESL.**

Table 85: A_NT-DMS100_SN06_ADD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
EMERGENCY_SERVICE_LINE_ROH_TONE_TIME	An emergency service office line option parameter; the duration in seconds of the receiver off-hook tone a caller receives when the ESL flashes.			S	R
EMERGENCY_SERVICE_LINE_INTEG_TONE	The integrity tone type.			S	R
EMERGENCY_SERVICE_LINE_INTEG_TONE_TIME	The interval in seconds after which the system generates an alarm and logs a report when an ESL line is off-hook.			S	R
EMERGENCY_SERVICE_LINE_SWITCHHOOK_TONE	The tone the emergency service office line receives when a caller goes on-hook.	LOW=steady low tone, BUSY=60 interruptions per minute (IPM) busy tone		S	R

Table 85: A_NT-DMS100_SN06_ADD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
EMERGENCY_SERVICE_LINE_FASTFLASH	An option for emergency service office lines. Usually N is used. The Y is entered if the emergency service bureau is equipped with an SP-1 console or equivalent that has the ability to generate an 80-ms flash.	Y or N		S	R
EMERGENCY_SERVICE_LINE_RINGBACK	Option used with an emergency service office line to enable the office to ring back a caller who goes on-hook.			S	R
EMERGENCY_SERVICE_LINE_FORCED_DISCONNECT_TIME	Option used with an emergency service office line. The timing in seconds, longer than a 2 s flash, after which the call disconnects and the emergency service line goes on-hook.			S	R

A_NT-DMS100_SN06_ADD_FAA

Adds the FAA option to a line. The Forced Agent Availability (FAA) option allows an ACD (Automatic Call Distribution) supervisor to force an ACD agent from the Not Ready to the Ready state. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addFAA.**

Table 86: A_NT-DMS100_SN06_ADD_FAA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 86: A_NT-DMS100_SN06_ADD_FAA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FORCED_AGENT_AVAILABILITY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
FORCED_AGENT_AVAILABILITY_EXTNDFAA	Extended forced agent availability.Indicates if the feature is valid for ACD agents in any ACD group and subgroup in the same customer group as the supervisor.			S	R
FORCED_AGENT_AVAILABILITY_ACDGROUP	A group identifier already in Table ACDGRP.			S	R

A_NT-DMS100_SN06_ADD_FANI

Adds the FANI option to a line. The Flexible Automatic Number ID (FANI) option allows an operating company to assign special-purpose Automatic Number Identification (ANI)

information digits to a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addFANI.**

Table 87: A_NT-DMS100_SN06_ADD_FANI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FANI_OPTION_FANI_DIGITS	Digits for the FANI option.	Two digits (00-99)		S	R

A_NT-DMS100_SN06_ADD_FEATURES

Adds options to assigned single line and multiline telephone sets, to Hunt group lines, and to proprietary business sets. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLineFeatures.**

Table 88: A_NT-DMS100_SN06_ADD_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 88: A_NT-DMS100_SN06_ADD_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
OPT	Options associated with a service you are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	A flag to indicate MML optimization of the command.	true or false	true	S	O

A_NT-DMS100_SN06_ADD_FTRGRP

Adds the FTRGRP option to a line. The FTRGRP option allows the operating company to define a number of features as a feature group. The feature group can be assigned to customer lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addFTRGRP.**

Table 89: A_NT-DMS100_SN06_ADD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 89: A_NT-DMS100_SN06_ADD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FEATURE_GROUP_ GRPNAME	The name of the feature group with a minimum of one feature.			S	R
FEATURE_GROUP_ OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_GIC

Adds the GIC option to a line. The GIC option allows call termination on a member of a designated intercom group that uses abbreviated dialing. Use abbreviated dialing to access group members. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addGIC.**

Table 90: A_NT-DMS100_SN06_ADD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 90: A_NT-DMS100_SN06_ADD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
GROUP_INTERCOM_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
GROUP_INTERCOM_GICNAME	Designated name of group intercom line			S	R
GROUP_INTERCOM_GICMEMNO	Digits dialed to reach this line.			S	R
GROUP_INTERCOM_GICSMDR	SMDR records required.			S	R
GROUP_INTERCOM_GICNOMSB	Group intercom calls not included in MSB.			S	R

A_NT-DMS100_SN06_ADD_GND

Adds the GND option to a line. The GND option assigns ground signal to the line.and allow consistency to be checked on ground start lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addGND.**

Table 91: A_NT-DMS100_SN06_ADD_GND

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_HOT

Adds the HOT feature to a line. This feature is placed on lines in hotel or motel. It allows the hotel to bill each room for call charges. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addHOT.**

Table 92: A_NT-DMS100_SN06_ADD_HOT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_ICM

Adds the ICM option to a line. The ICM option allows a business set user to directly terminate upon a predesignated business set by pressing the ICM feature key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addICM.**

Table 93: A_NT-DMS100_SN06_ADD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 93: A_NT-DMS100_SN06_ADD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTERCOM_BUSINESS_SET_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
INTERCOM_BUSINESS_SET_LINK_LEN	The LEN of a member of an existing DLH or MLH Hunt group to which additional members are to be linked.			S	R
INTERCOM_BUSINESS_SET_DOR	Denied origination.			S	R
INTERCOM_BUSINESS_SET_SIC_KEY	Straight intercom key.			S	R
INTERCOM_BUSINESS_SET_SMDR	Station message detail recording.			S	R

A_NT-DMS100_SN06_ADD_INSPECT

Adds the INSPECT option to a line. The INSPECT option displays the information on feature/DN keys and incoming calls to a DN. This option also provides information on the Call Waiting key and Intercom key without answering the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addINSPECT.**

Table 94: A_NT-DMS100_SN06_ADD_INSPECT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 94: A_NT-DMS100_SN06_ADD_INSPECT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INSPECT_KEY_OPT KEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_INT

Adds the INT option to a line. The Intercom (INT) option allows the subscriber to dial an access code and ring all the extensions of that DN. The subscriber can speak to the individuals who answer these extensions. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addINT.**

Table 95: C_NT-DMS100_SN06_ADD_INT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	Name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

A_NT-DMS100_SN06_ADD_INTPIC

Adds the INTPIC option to a line. Line option INTPIC allows subscribers of Equal End Offices (EQEO) to designate a carrier for international calls. This option is valid for POTS, COIN, RES, IBN and KSET lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addINTPIC.**

Table 96: A_NT-DMS100_SN06_ADD_INTPIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTL_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
INTL_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTL_PIC_CHOICE	Indicates whether the subscriber is allowed to casually dial Intra-LATA calls.	Y or N		S	R

A_NT-DMS100_SN06_ADD_KSH

Adds the KSH option to a line. The Key Short Hunt (KSH) option allows incoming calls to search for an idle directory number (DN) on which to terminate. The options search for this

DN occurs through a set of DN appearances on a business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addKSH.**

Table 97: A_NT-DMS100_SN06_ADD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
KEY_SHORT_HUNT _OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
KEY_SHORT_HUNT _OVTYPE	Type of overflow required when short Hunt group is busy.	N = no overflow, D = DN to which overflow is to go, R = route		S	R
KEY_SHORT_HUNT _OVDN	The overflow directory number for the KSH option when the OVTYPE is D.			S	O
KEY_SHORT_HUNT _TABID	A table identifier associated with the line overflow to a route (LOR) and KSH options.	OFRT = Office Route Reference Table, IBNRTE = IBN Route Reference Table		S	R

Table 97: A_NT-DMS100_SN06_ADD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
KEY_SHORT_HUNT _KSH_KEY	The line Hunt overflow route index that identifies the overflow route. The index identifies the key on business set or data unit. The index indicates the route reference number when Route (R) is the overflow for the KSH option.			S	O
KEY_SHORT_HUNT _KEYLIST	Appears when an assignment of a subset feature to a multiline set occurs. Specifies key numbers of the DNs to which a feature will apply.			C	O

A_NT-DMS100_SN06_ADD_LCDR

Adds the LCDR option to a line. The Local Call Detail Recording (LCDR) option allows billing for local calls to correspond to conversation time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLCDR.**

Table 98: A_NT-DMS100_SN06_ADD_LCDR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 98: A_NT-DMS100_SN06_ADD_LCDR

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LOCAL_CALL_DETAILED_REPORTING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_LDSA

Adds the LDSA option to a line. The Long Distance Signal Activation (LDSA) allows the subscriber to activate or deactivate long distance alerting. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLDSA.**

Table 99: A_NT-DMS100_SN06_ADD_LDSA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_LDSO

Adds the LDSO option to a line. The Long Distance Signal Option (LDSO) alerts subscribers to long distance calls by means of a different ring and tone. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLDSO.**

Table 100: A_NT-DMS100_SN06_ADD_LDSO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_LNR

Adds the LNR option to a line. The LNR option allows a subscriber to redial the last number dialed. The subscriber uses a single key instead of the full number to redial the last number dialed. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLNR.**

Table 101: A_NT-DMS100_SN06_ADD_LNR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 101: A_NT-DMS100_SN06_ADD_LNR

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LAST_NUMBER_REDIAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_LNRA

Adds the LNRA option to a line. The Last Number Redial Associated with Set (LNRA) option allows a set to access any free Directory Number (DN) on the set. When the user activates the option, the last number the user dialed from the set dials again. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLNRA.**

Table 102: A_NT-DMS100_SN06_ADD_LNRA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LAST_NUMBER_REDIAL_ASSOCIATED_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_LOB

Adds the LOB option to a line. The Line of Business (LOB) option allows an Automatic Call Distribution (ACD) agent to enter a three-digit code for each call. Entering the code pegs a register for that LOB or type of call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLOB.**

Table 103: A_NT-DMS100_SN06_ADD_LOB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LINE_OF_BUSINESS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_LOD

Adds the LOD option to a line. The Line overflow to DN (LOD) option allows subscriber to route to a specific DN when all Hunt group members are busy. The specific DN can be part of the Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLOD.**

Table 104: A_NT-DMS100_SN06_ADD_LOD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 104: A_NT-DMS100_SN06_ADD_LOD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_OVERFLOW_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_BUSY_OVERFLOW_DN	The DN to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_NPA	The NPA to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_NXX	The NXX to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_LINE	The LINE to which calls route when all Hunt group members are busy.			S	O
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 104: A_NT-DMS100_SN06_ADD_LOD

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_LPIC

Adds the LPIC option to a line. Option Intra-LATA PIC (LPIC) allows the user to choose a primary carrier for Intra-LATA service. Field LCHOICE allows subscribers to dial Intra-LATA calls on a casual basis. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLPIC.**

Table 105: A_NT-DMS100_SN06_ADD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTRA_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
INTRA_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R

Table 105: A_NT-DMS100_SN06_ADD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
INTRA_PIC_CHOICE	Indicates whether the subscriber is allowed to casually dial Intra-LATA calls.	Y or N		S	R

A_NT-DMS100_SN06_ADD_LVM

Adds the LVM option to a line. The Leave Message (LVM) option provides key access to message waiting (MWT), call request (CAR), and executive message waiting (EMW). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addLVM.**

Table 106: A_NT-DMS100_SN06_ADD_LVM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LEAVE_MESSAGE_ OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_M518

Adds the M518 option to a line. The 18-Button Add-On for Meridian M5000 Series (M518) option allows the addition of an 18-button add-on unit to a Meridian M5000 series (M5009,

M5112, M5209, or M5312) business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addM518.**

Table 107: A_NT-DMS100_SN06_ADD_M518

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
M518_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
M518_QUANTITY	Indicates the number of M518 add-on units for a M5000 set.			S	O

A_NT-DMS100_SN06_ADD_M536

Adds the M536 option to a line. The 36-Button Add-On for Meridian M5000 Series (M536) option allows the addition of a 36-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addM536.**

Table 108: A_NT-DMS100_SN06_ADD_M536

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 108: A_NT-DMS100_SN06_ADD_M536

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
M536_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_MDN

Adds the MDN option to a line. The MDN option assigns a DN to more than one set. A multiple appearance directory number (MADN) is a directory number (DN) hat appears on more than one Meridian business set (MBS). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addMDN.**

Table 109: A_NT-DMS100_SN06_ADD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 109: A_NT-DMS100_SN06_ADD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
MULTIPLE_APPEARANCE_DN_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
MULTIPLE_APPEARANCE_DN_MDNTYPE	The type of call arrangement.	MCA=multiple call arrangement, SCA=single call arrangement, EXB=extension bridging		S	R
MULTIPLE_APPEARANCE_DN_PRIMARY	Primary member of an MADN group.			S	R
MULTIPLE_APPEARANCE_DN_RING	Whether ringing is required.			S	R
MULTIPLE_APPEARANCE_DN_DIR_NUMBER	The Directory number.			S	R

A_NT-DMS100_SN06_ADD_MSB

Adds the MSB option to a line. The MSB option allows each IBN station to appear busy to incoming calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addMSB.**

Table 110: A_NT-DMS100_SN06_ADD_MSB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 110: A_NT-DMS100_SN06_ADD_MSB

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MAKE_SET_BUSY_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_MSBI

Adds the MSBI option to a line. The Make Set Busy Intragroup (MSBI) option allows each IBN station to appear busy to incoming calls. The system applies a temporary splash of ringing (500 ms) to the line to inform the user of a diverted incoming call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addMSBI.**

Table 111: A_NT-DMS100_SN06_ADD_MSBI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 111: A_NT-DMS100_SN06_ADD_MSBI

Parameter Name	Description	Range	Default Value	Type	Class
MAKE_SET_BUSY_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_MWT

Adds the MWT option to a line. The MWT option allows a message center to inform a user that there is a message. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addMWT.**

Table 112: A_NT-DMS100_SN06_ADD_MWT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.	STD = stuttered dialtone, MWL = message waiting lamp, CMWI = CLASS message waiting indicator, PRN = periodic ring notification		S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MESSAGE_WAITING_INDICATOR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Table 112: A_NT-DMS100_SN06_ADD_MWT

Parameter Name	Description	Range	Default Value	Type	Class
MESSAGE_WAITING_INDICATOR_NOTICE	Message waiting notification. .			S	O
MESSAGE_WAITING_INDICATOR_CMWISTD	When CMWISTD is set to Y, subscribers are allowed to dial an access code to activate or deactivate a stuttered dial tone.	Y = stuttered dial tone is activated. N = No stuttered dial tone		S	O
MESSAGE_WAITING_INDICATOR_CMWIRING	When CMWIRING is set to Y, subscribers can dial an access code. This code allows the subscriber to activate or deactivate ringing that precedes a lamp activation message.			S	O
MESSAGE_WAITING_INDICATOR_IRN	Immediate ring notification; this prompt appears only if PRN or CMWI is selected as the message waiting notification (NOTICE prompt) and input to the CRN prompt is Y.			S	O
MESSAGE_WAITING_INDICATOR_STATUS	When the CMWIRING is set to UDLC, the system does not prompt for the status field.			S	O
MESSAGE_WAITING_INDICATOR_CAR	Call request option.			S	R

Table 112: A_NT-DMS100_SN06_ADD_MWT

Parameter Name	Description	Range	Default Value	Type	Class
MESSAGE_WAITING_INDICATOR_CRRCFW	Call request retrieve call forwarding. Specifies how the system handles forwarding if a subscriber activates the Call Request Retrieve (CRR) feature to return a call to the subscriber that left the message. Note: The CRRCFW is required only if CAR is set to Y.			S	O
MESSAGE_WAITING_INDICATOR_CRX	Call request not required.			S	R

A_NT-DMS100_SN06_ADD_NAME

Adds the NAME feature to a line. The system uses NAME feature to assign a name to DN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addNAME.**

Table 113: A_NT-DMS100_SN06_ADD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 113: A_NT-DMS100_SN06_ADD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
NAME_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NAME_NETNAME	Network name shown as DN attribute.			S	R
NAME_DISPLAYNAME	Name to display on MBS set.			S	R

A_NT-DMS100_SN06_ADD_NDC

Adds the NDC option to a line. The No Double Connect (NDC) option prevents a line from being connected to a verification or test circuit when the line is off-hook. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addNDC.**

Table 114: A_NT-DMS100_SN06_ADD_NDC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NO_DOUBLE_CONNECT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_NFA

Adds the NFA option to a line. The Network Facility Access (NFA) provides a direct access to the services of an Intelligent Processor (IP) through DMS100 switch. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addNFA.**

Table 115: A_NT-DMS100_SN06_ADD_NFA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NETWORK_FACILITY_ACCESS_OPTKEY	A key on a business set or data unit to which the feature is assigned.		1	S	O
NETWORK_FACILITY_ACCESS_USER_ID	The user ID for the line to which the user adds the NFA option.			S	O
NETWORK_FACILITY_ACCESS_IMPLCT_ACC	Specifies whether the line is allowed implicit access.		Y	S	O
NETWORK_FACILITY_ACCESS_EXPLCT_ACC	Specifies whether the line is assigned explicit access.		Y	S	O
NETWORK_FACILITY_ACCESS_AMA_EXPLCT	Controls the AMA billing record generation that follows an explicit connection.		N	S	O

Table 115: A_NT-DMS100_SN06_ADD_NFA

Parameter Name	Description	Range	Default Value	Type	Class
NETWORK_FACILITY_ACCESS_AMA_IPDIAL	Controls the AMA billing record generation that follows an IP dialed connection.		N	S	O
NETWORK_FACILITY_ACCESS_REM_ACC	Specifies whether the line is allowed remote access.		N	S	O
NETWORK_FACILITY_ACCESS_AMA_REM	Controls the AMA billing record generation that follows a remote connection.		N	S	O
NETWORK_FACILITY_ACCESS_NFRA_PIN	The remote access PIN. This is required if REM_ACC is set to Y.			S	O

A_NT-DMS100_SN06_ADD_NGTSRVCE

Adds the NGTSRVCE option to a line. The Night Service option allows the ACD supervisor to place all ACD agent sets in an ACD group in night service mode. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addNGTSRVCE.**

Table 116: A_NT-DMS100_SN06_ADD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 116: A_NT-DMS100_SN06_ADD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
NIGHT_SERVICE_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NIGHT_SERVICE_ACDGROUP	A group identifier that the user already entered in Table ACDGRP. The identifier is the name of the automatic call distribution group to which this station belongs.			S	O

A_NT-DMS100_SN06_ADD_NLT

Adds the NLT option to a line. The No Line Insulation Test (NLT) option allows the automatic line insulation test to skip a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addNLT.**

Table 117: A_NT-DMS100_SN06_ADD_NLT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 117: A_NT-DMS100_SN06_ADD_NLT

Parameter Name	Description	Range	Default Value	Type	Class
NO_LINE_INSULATION_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_OBS

Adds the OBS option to a line. The Observe Agent (OBS) option allows a supervisor to observe conversations between an agent and a caller. This user presses the OBS key to observe conversations between an agent and a caller. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addOBS.**

Table 118: A_NT-DMS100_SN06_ADD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OBSERVE_AGENT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 118: A_NT-DMS100_SN06_ADD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
OBSERVE_AGENT_OBSTYPE	The type of observation a supervisor can apply over incoming ACD calls: basic, extended, or flexible call observing.			S	R
OBSERVE_AGENT_ACDGROUP	A group identifier that Table ACDGRP must already contain. The group identifier is the name of the automatic call distribution group to which this station belongs.			S	O
OBSERVE_AGENT_FOBS_ACDGROUP	Appears if OBSTYPE is set to FOBS.			S	O
OBSERVE_AGENT_FOBSTYPE	Appears if OBSTYPE is set to FOBS. Specifies the type of flexible call observing required.			S	O
OBSERVE_AGENT_FOBS_SUBGROUP	Specifies an ACD subgroup number. Appears if FOBSTYPE = SUBGROUP.			S	O
OBSERVE_AGENT_DN	Specifies an ACD Directory number. Appears if FOBSTYPE = DN.			S	O

A_NT-DMS100_SN06_ADD_ONI

Adds the ONI option to a line. The Operator Number Identification (ONI) directs calls to an operator for the identification of the calling number when the switch cannot find this

information . It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addONI.**

Table 119: A_NT-DMS100_SN06_ADD_ONI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OPERATOR_NUMBER_IDENTIFICATION_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	R

A_NT-DMS100_SN06_ADD_PIC

Adds the PIC option to a line. Option Primary Inter-LATA Carrier (PIC) assigns a PIC to an MDC line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addPIC.**

Table 120: A_NT-DMS100_SN06_ADD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 120: A_NT-DMS100_SN06_ADD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTER_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
INTER_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTER_PIC_CHOICE	Specifies whether the system allows the user to dial 10xxx to access other carriers. Value Y or N.			S	R

A_NT-DMS100_SN06_ADD_PORT

Adds the PORT option to a line. The PORT option allows ten-digit complete LNP triggering for a directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addPORT.**

Table 121: A_NT-DMS100_SN06_ADD_PORT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 121: A_NT-DMS100_SN06_ADD_PORT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LOCAL_NUMBER_PORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_PRK

Adds the PRK option to a line. This option allows a business set user to park a call against the DN of the user. Retrieval of the parked call can occur from any station. When the call is parked, the user can originate and receive calls on that DN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addPRK.**

Table 122: A_NT-DMS100_SN06_ADD_PRK

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_PARK_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_PRL

Adds the PRL option to a line. The PRL option is available to single call announcement (SCA) multiple appearance directory number (MADN) users. The PRL option allows users to establish a conference call between an outside number and max 30 MADN lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addPRL.**

Table 123: A_NT-DMS100_SN06_ADD_PRL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_RELEASE _OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_QTD

Adds the QTD option to a line. This option allows a display business set to display the current time and date. The user presses the QTD key and the current time and date displays for 15 seconds. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addQTD.**

Table 124: A_NT-DMS100_SN06_ADD_QTD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 124: A_NT-DMS100_SN06_ADD_QTD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
QUERY_TIME_DATE _OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_RAG

Adds the RAG option to a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRAG.**

Table 125: A_NT-DMS100_SN06_ADD_RAG

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 125: A_NT-DMS100_SN06_ADD_RAG

Parameter Name	Description	Range	Default Value	Type	Class
RING_AGAIN_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_RCHD

Adds the RCHD option to a line. The RCHD option allows a subscriber to place a call on hold for up to three minutes. The call can be one that the subscriber originated or one that the subscriber received. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRCHD.**

Table 126: A_NT-DMS100_SN06_ADD_RCHD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_RMI

Adds the RMI option to a line. The RMI option allows the subscribers of the message waiting indicator feature to check for the existence of messages in their voice mail box from a remote

location. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRMI.**

Table 127: A_NT-DMS100_SN06_ADD_RMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
REMOTE_MESSAGE_INDICATOR_RMI_STATE	The state of the RMI feature.	active or inactive		S	R
REMOTE_MESSAGE_INDICATOR_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_RMR

Adds the RMR option to a line. This option is assigned to lines which are equipped with a remote hardware message register activated by reverse battery. The RMR option is used on a hotel line to indicate that a charge is due for a local call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRMR.**

Table 128: A_NT-DMS100_SN06_ADD_RMR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 128: A_NT-DMS100_SN06_ADD_RMR

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_RMT

Adds the RMT option to a line. The RMT option is assigned to lines which are equipped with a remote hardware message register activated by reverse battery. The RMT option is used on a hotel lines to indicate that a charge is due for a non-local call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRMT.**

Table 129: A_NT-DMS100_SN06_ADD_RMT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_RPA

Adds the RPA option to a line. The RPA option allows up to seven additional alert tones to a business set when a call terminates on a DN, MADN, GIC, or ACD key and the set is already

active on another key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRPA.**

Table 130: A_NT-DMS100_SN06_ADD_RPA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
REPEATED_ALERT_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_RSP

Adds the RSP option to a line. The RSP option is assigned to lines that have LCCs of ZMD or ZMZPA. This option causes the ANI information digit 7 (coinless pay station identification) plus the calling party's DN to be outpulsed. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRSP.**

Table 131: A_NT-DMS100_SN06_ADD_RSP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 131: A_NT-DMS100_SN06_ADD_RSP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
RESTRICTED_SENT_PAID_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_RSUS

Adds the RSUS option to a line. This option is assigned when a subscriber requests service suspension. When this option is assigned, the treatments to which originations from and terminations to the subscriber line are to be routed must be specified. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addRSUS.**

Table 132: A_NT-DMS100_SN06_ADD_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
REQUESTED_SUSPENSION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Table 132: A_NT-DMS100_SN06_ADD_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
REQUESTED_SUSPENSION_ORIG_SUS	Originating suspension; the treatment to which the subscriber is routed on origination of a call.			S	R
REQUESTED_SUSPENSION_TERM_SUS	Terminating suspension; the treatment to which a call is routed when attempting to terminate to a line with the RSUS option.			S	R

A_NT-DMS100_SN06_ADD_SACB

Adds the SACB option to a line. The SACB option allows a subscriber to control originations from the line by identifying call classes that restrict completion to certain dialed numbers without a personal identification number (PIN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSACB.**

Table 133: A_NT-DMS100_SN06_ADD_SACB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SUB_ACT_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Table 133: A_NT-DMS100_SN06_ADD_SACB

Parameter Name	Description	Range	Default Value	Type	Class
SUB_ACT_CALL_BLOCKING_STATUS	Option prompt when the SCRJ option, SACB option, or PRN option is specified when adding MWT to a line.			S	O
SUB_ACT_CALL_BLOCKING_CC	Indicates the type of call classes to be restricted for SACB.			S	R
SUB_ACT_CALL_BLOCKING_PIN	SACB personal identification number (PIN).			S	R
SUB_ACT_CALL_BLOCKING_SUS	Blocks all calls from an originating line except for those in table SACB against subfield FPBALLOW. STATUS must be specified as ACT.			S	R

A_NT-DMS100_SN06_ADD_SC1

Adds the SC1 option to a line. The SC1 option allows a customer to specify a list of up to eight frequently called numbers. These numbers can be called by dialing the digits 2-9. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSC1.**

Table 134: A_NT-DMS100_SN06_ADD_SC1

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 134: A_NT-DMS100_SN06_ADD_SC1

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_SC2

Adds the SC2 option to a line. The SC2 option allows a customer to specify a list of up to 30 frequently called numbers. These numbers can be called by dialing 20-49. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSC2.**

Table 135: A_NT-DMS100_SN06_ADD_SC2

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_SCA

Adds the SCA option to a line. The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN). It is implemented

by the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCA.

Table 136: A_NT-DMS100_SN06_ADD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SELECTIVE_CALL_ACCEPTANCE_OPT KEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SELECTIVE_CALL_ACCEPTANCE_STAT US	INACT indicates that the option is not enabled (inactive); ACT indicates that the option is enabled (active); UNIVI indicates that universal access via customer interface is inactive, and UNIVA indicates that universal access via customer interface is active.			S	R

Table 136: A_NT-DMS100_SN06_ADD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_ ACCEPTANCE_BILL ING_OPTION	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_ ACCEPTANCE_DNS	Directory number to be added to the SCA list. If a user does not send any value for SELECTIVE_CALL_ BLOCKING_DNS[1], the system will assume that the value is $.			C	O
SELECTIVE_CALL_ ACCEPTANCE_NPA	NPA for the SCA option.			C	O
SELECTIVE_CALL_ ACCEPTANCE_NXX	NXX for the SCA option.			C	O
SELECTIVE_CALL_ ACCEPTANCE_LINE	LINE for the SCA option.			C	O
SELECTIVE_CALL_ ACCEPTANCE_VBC OUNT	Number of digits voiced back during SCA list review.			C	O

A_NT-DMS100_SN06_ADD_SCF

Adds the SCF option to a line. The SCF option allows calls that terminate on the line to be forwarded to a remote destination if the number of the originating station matches one of the

numbers in the SCF list. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCF.**

Table 137: A_NT-DMS100_SN06_ADD_SCF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SELECTIVE_CALL_FORWARDING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SELECTIVE_CALL_FORWARDING_STATUS	INACT indicates that the option is not enabled (inactive), ACT indicates that the option is enabled (active), UNIVI indicates universal access via customer interface is inactive, and UNIVA indicates universal access via customer interface is active.			S	R

Table 137: A_NT-DMS100_SN06_ADD_SCF

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_FORWARDING_BILLING_OPTION	NOAMA indicates that the feature is billed based on a subscription, AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_FORWARDING_DNS	Directory number to be added to the SCF list. If a user does not send any value for SELECTIVE_CALL_FORWARDING_DNS[1], the system will assume that the value is $.			C	O
SELECTIVE_CALL_FORWARDING_NPA	NPA for the SCA option.			C	O
SELECTIVE_CALL_FORWARDING_NXX	NXX for the SCA option.			C	O
SELECTIVE_CALL_FORWARDING_LINE	LINE for the SCA option.			C	O
SELECTIVE_CALL_FORWARDING_VBCOUNT	Number of digits voiced back during SCA list review.			C	O
SELECTIVE_CALL_FORWARDING_FDN	Number to which calls will be forwarded.			S	O
SELECTIVE_CALL_FORWARDING_FDN_NPA	NPA to which calls will be forwarded.			S	O
SELECTIVE_CALL_FORWARDING_FDN_NXX	NXX to which calls will be forwarded.			S	O

Table 137: A_NT-DMS100_SN06_ADD_SCF

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_FORWARDING_FDN_LINE	LINE to which calls will be forwarded.			S	O
SELECTIVE_CALL_FORWARDING_SCRNCL	Screening by class of service.			S	O
SELECTIVE_CALL_FORWARDING_NUMCALLS	LINE to which calls will be forwarded.			S	R
SELECTIVE_CALL_FORWARDING_RINGREM	LINE to which calls will be forwarded.			S	R

A_NT-DMS100_SN06_ADD_SCL

Adds the SCL option to a line. The SCL option allows a customer to specify a list of frequently called numbers that can be called by dialing a two-digit speed calling code instead of the complete number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCL.**

Table 138: A_NT-DMS100_SN06_ADD_SCL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 138: A_NT-DMS100_SN06_ADD_SCL

Parameter Name	Description	Range	Default Value	Type	Class
SPEED_CALLING_LONG_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SPEED_CALLING_LONG_LISTTYPE	The length of the list (L30, L50, L70).			S	R
SPEED_CALLING_LONG_KEYLIST	Applies only to Hunt groups. Appears when the user assigns a subset feature to a multi-line set. Specifies the key numbers of the DNS to which the user applied a feature. If the key number is not provided, you should provide the value $.			C	O

A_NT-DMS100_SN06_ADD_SCRJ

Adds the SCRJ option to a line. The SCRJ option allows a subscriber to selectively reject calls arriving from a limited set of previously identified DNs. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCRJ.**

Table 139: A_NT-DMS100_SN06_ADD_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 139: A_NT-DMS100_SN06_ADD_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
SELECTIVE_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SELECTIVE_CALL_BLOCKING_STATUS	INACT indicates that the option is not enabled (inactive), ACT indicates that the option is enabled (active), UNIVI indicates that universal access via the customer interface is inactive, and UNIVA indicates that universal access via the customer interface is active.			S	R
SELECTIVE_CALL_BLOCKING_BILLING_OPTION	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_BLOCKING_DNS	Directory number to be added to the SCRJ list. If a user does not send any value for SELECTIVE_CALL_BLOCKING_DNS[1], the system will assume that the value is $.			C	O
SELECTIVE_CALL_BLOCKING_NPA	NPA for the SCA option.			C	O

Table 139: A_NT-DMS100_SN06_ADD_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_BLOCKING_NXX	NXX for the SCA option.			C	O
SELECTIVE_CALL_BLOCKING_LINE	LINE for the SCA option.			C	O
SELECTIVE_CALL_BLOCKING_VBCOUNT	Number of digits voiced back during SCA list review.			C	O

A_NT-DMS100_SN06_ADD_SCS

Adds the SCS option to a line. The SCS option allows a customer to specify a list of frequently called numbers that the customer can call by dialing a one-digit speed calling code instead of the complete number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCS.**

Table 140: A_NT-DMS100_SN06_ADD_SCS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPEED_CALLING_SHORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_SCU

Adds the SCU option to a line. This option allows a line to be designated as a speed calling user in a speed calling group. A speed calling user can only originate calls with speed calling and cannot affect the contents of the speed calling list. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCU.**

Table 141: A_NT-DMS100_SN06_ADD_SCU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPEED_CALLING_USER_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SPEED_CALLING_USER_SCUGNUMBER	Specifies a unique group number for the SCU option.			S	R
SPEED_CALLING_USER_SCU_TDN	Specifies whether toll denial is applied to speed called numbers.			S	R

A_NT-DMS100_SN06_ADD_SCWID

Adds the SCWID option to a line. The SCWID option allows subscribers to receive calling party information in conjunction with a call waiting tone. It is implemented by the Java

method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSCWID.

Table 142: A_NT-DMS100_SN06_ADD_SCWID

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_SDN

Adds the SDN option to a line. To add a secondary DN to a Teen Service line, the SDN option can be assigned to POTS, RES, or IBN agents. When no SDNs are assigned to the line, adding the SDN option establishes Teen Service. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSDN.**

Table 143: A_NT-DMS100_SN06_ADD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 143: A_NT-DMS100_SN06_ADD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
SECONDARY_DN_DN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_NPA	Secondary NPA.			S	O
SECONDARY_DN_NXX	Secondary NXX.			S	O
SECONDARY_DN_LINE	Secondary LINE.			S	O
SECONDARY_DN_DNY	NODNY = No deny to call waiting. DNYCWT = Deny call waiting. These options are not applicable to MDC. Enter $ to omit both options.			S	O
SECONDARY_DN_RING	Secondary DN ring type.	0 = normal ringing, 1 = SDN pattern #1, 2 = SDN pattern #2, 3 = SDN pattern #3		S	R

Table 143: A_NT-DMS100_SN06_ADD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
SECONDARY_DN_OPT	Secondary DN type.	P = forward SDN with PDN, N = do not forward SDN, E = enhanced SDN can have own option list		S	R

A_NT-DMS100_SN06_ADD_SDSDENY

Adds the SDSDENY option to a line. The SDSDENY option prevents the offer of Enhanced Busy Call Return (EBCR) service to a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSDSDENY.**

Table 144: A_NT-DMS100_SN06_ADD_SDSDENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_BUSY_REPEAT_DIAL_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_SHU

Adds the SHU option to a line. The SHU option allows hunting at a line to be canceled when activated. SHU can be assigned to one, several, or all lines in a Hunt group. It is implemented

by the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSHU.

Table 145: A_NT-DMS100_SN06_ADD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STOP_HUNT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
STOP_HUNT_SC	Scan point.	tmtype = MTM, RSMtmno = 0-2047tmcktno = 0-29point = 0-6 (SD point number) normal_state = 0 for open or 1 for closed		S	R
STOP_HUNT_TMNO	Enter the number of the trunk module on which the circuit is mounted. Appears after the signal distribution (SD) or SC prompt if data is not entered on one line.			S	R

Table 145: A_NT-DMS100_SN06_ADD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
STOP_HUNT_TMCKTNO	Enter the trunk module circuit number to which the circuit is assigned. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_POINT	SD point number. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_NORMAL_STATE	Normal state of the SD point. Appears after the SD or SC prompt if data is not entered on one line.			S	R

A_NT-DMS100_SN06_ADD_SL

Adds the SL option to a line. The SL option allows a line to receive announcements in a secondary language (a language other than the assigned primary language). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSL.**

Table 146: A_NT-DMS100_SN06_ADD_SL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 146: A_NT-DMS100_SN06_ADD_SL

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
SECONDARY_LANGUAGE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_SMDR

Adds the SMDR option to a line. This option allows the recording of billable and nonbillable calls on a per leg call basis. The SMDR system uses the automatic message accounting (AMA) subsystem to collect call data and record it on a data storage device. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSMDR.**

Table 147: A_NT-DMS100_SN06_ADD_SMDR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_MESSAGE_RECORDING_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_ADD_SPB

Adds the SPB option to a line. The SPB option allow a line number other than the subscriber's line to be used for billing. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSPB.**

Table 148: A_NT-DMS100_SN06_ADD_SPB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPECIAL_BILLING_DN	DN number to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_NPA	NPA of DN to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_NXX	NXX of DN to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_LINE	LINE of DN to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_SRA

Adds the SRA option to a line. The Suppressed Ringing Access (SRA) allows any authorized server to establish a connection to customer's line without applying audible ringing. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSRA.**

Table 149: A_NT-DMS100_SN06_ADD_SRA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_SSAC

Adds the SSAC option to a line. The SSAC option allows a set of numbers, from 2-10 digits, to be dialed from a specific station for purposes of recording billing information and overriding station network class of service (NCOS) restrictions. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSSAC.**

Table 150: A_NT-DMS100_SN06_ADD_SSAC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 150: A_NT-DMS100_SN06_ADD_SSAC

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_SPECIFIC_AUTH_CODES_OPT KEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
STATION_SPECIFIC_AUTH_CODES_AUTHCODE	Authorization code.			C	O

A_NT-DMS100_SN06_ADD_SUPPRESS

Adds the SUPPRESS option to a line. The SUPPRESS option allows a party to prevent the display the directory number (DN) or name at the call destination. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSUPPRESS.**

Table 151: A_NT-DMS100_SN06_ADD_SUPPRESS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 151: A_NT-DMS100_SN06_ADD_SUPPRESS

Parameter Name	Description	Range	Default Value	Type	Class
ANONYMOUS_CALLER_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
ANONYMOUS_CALLER_NETNAME	Network name shown as DN attribute.			C	O
ANONYMOUS_CALLER_SUPPRESS_DN	Suppresses the display of the DN. Enter Y to suppress the display of the DN; enter N if no suppression is required.			C	O
ANONYMOUS_CALLER_SUPPRESS_NAME	Enter Y to suppress the display of the station name; enter N if no suppression is required. Suppresses the display of the station name.			C	O

A_NT-DMS100_SN06_ADD_SUPR

Adds the SUPR option to the line. The SUPR option establishes an automatic call distribution (ACD) supervisor set when assigned to key 1. This option must be assigned before ACD supervisor options can be assigned to the set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSUPR.**

Table 152: A_NT-DMS100_SN06_ADD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 152: A_NT-DMS100_SN06_ADD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
SUPERVISOR_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SUPERVISOR_PRIMARY_ACDGROUP	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.			C	R
SUPERVISOR_PRIMARY_ACDSGRP	The supervisor subgroup identifier that must already be data filled in Table ACDSGRP in order to add the SUPR option to an ACD group.			C	R
SUPERVISOR_IDNUM	Indicates if ID number of agent position is required.	Y = Yes, N = No		C	R

A_NT-DMS100_SN06_ADD_SVCGRP

Adds the SVCCGRP option to the line. The SVCGRP option allows options CLID (Calling Line Identification Display), NAME (Name Display) and REASDSP (Reason Display), packaged in a service group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addSVCGRP.**

Table 153: A_NT-DMS100_SN06_ADD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 153: A_NT-DMS100_SN06_ADD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SERVICE_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SERVICE_GROUP_GRPNAME	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.			S	R

A_NT-DMS100_SN06_ADD_TCW

Adds the TCW option to a line. TCW option - talking call waiting. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addTCW.**

Table 154: A_NT-DMS100_SN06_ADD_TCW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 154: A_NT-DMS100_SN06_ADD_TCW

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_TDN

Adds the TDN option to a line. The TDN option prevents a line from originating toll calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addTDN.**

Table 155: A_NT-DMS100_SN06_ADD_TDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_TFO

Adds the TFO option to a line. The TFO allows an incoming call to attempt to terminate to the first member of the hunt group which appears idle. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addTFO.**

Table 156: A_NT-DMS100_SN06_ADD_TFO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
TERMINATION_FAULT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_UCD

Adds the UCD option to a line. The UCD option permits calls to be distributed evenly among a number of predetermined sets. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addUCD.**

Table 157: A_NT-DMS100_SN06_ADD_UCD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 157: A_NT-DMS100_SN06_ADD_UCD

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
UNIFORM_CALL_DISTRIBUTION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_VMEADENY

Adds the VMEADENY option to a line. The VMEADENY option prevents a subscriber's line from having access to voice messaging system VMS using access code *98. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addVMEADENY.**

Table 158: A_NT-DMS100_SN06_ADD_VMEADENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_VOICE_MAIL_EASY_ACCESS_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_VMEADN

Adds the VMEADN option to a line. The Voice Mail East Access DN (VMEADN) option allows a subscriber's line to access a voice messaging system VMS using access code *98. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addVMEADN.**

Table 159: A_NT-DMS100_SN06_ADD_VMEADN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_DN	Subscriber's voice mail easy access forward DN.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_NPA	Subscriber's VM area code.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_NXX	Subscriber's VM NXX.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_LINE	Subscriber's VM line number.			S	O
VOICE_MAIL_EASY_ACCESS_DN_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_WML

Adds the WML option to a line. The WML option is assigned to lines that route to a predefined DN if no digits are dialed within a modifiable time-out period. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addWML.**

Table 160: A_NT-DMS100_SN06_ADD_WML

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
WARM_LINE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
WARM_LINE_CUSTMOD	Specifies whether a customer can change the DN to which a call is forwarded when the WML time-out expires.			S	R
WARM_LINE_ACTIVE	Specifies whether the option is active.			S	R
WARM_LINE_TIMEOUT	Specifies the length of time in seconds before an unanswered call is automatically forwarded.			S	R

Table 160: A_NT-DMS100_SN06_ADD_WML

Parameter Name	Description	Range	Default Value	Type	Class
WARM_LINE_FTCODE	Enter Y to allow a subscriber to dial octothorpe (#) to access MDC features. Enter N to allow a subscriber to dial # to override the Warm Line feature timer. FTCODE is prompted when the office parameter WML_OCT_IS_LINE_OPT_PARM is set to Y.			S	O
WARM_LINE_DN	The DN to which a call is forwarded when the WML expires.			S	O
WARM_LINE_NPA	The NPA to which a call is forwarded when the WML expires.			S	O
WARM_LINE_NXX	The NXX to which a call is forwarded when the WML expires.			S	O
WARM_LINE_LINE	The LINE to which a call is forwarded when the WML expires.			S	O

A_NT-DMS100_SN06_ADD_WUC

Adds the WUC option to a line. The WUC option allows a subscriber to set a time for the phone to ring. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addWUC.**

Table 161: A_NT-DMS100_SN06_ADD_WUC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
WAKE_UP_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_ADD_WUCR

Adds the WUCR option to a line. The WUCR option allows a subscriber to set a reminder time for the phone to ring. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addWUCR**

Table 162: A_NT-DMS100_SN06_ADD_WUCR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 162: A_NT-DMS100_SN06_ADD_WUCR

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_ADD_DCPK

Adds the DCPK option to a line.The DCPK option allows the system to put calls on hold or to park calls against any valid DN

com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsAddFeatProv.addDCPK.

Table 163:

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory Number			S	O
NPA	3 digits area code			S	O
NXX	First 3 digits of the line number			S	O
LINE	4 digits line extension			S	O
LEN	Line equipment number.			S	O

Modify Feature Services

This cartridge provides the following ASDL commands:

- A_NT-DMS100_SN06_CHF_FEATURES
- A_NT-DMS100_SN06_MOD_ACD
- A_NT-DMS100_SN06_MOD_AIN

- A_NT-DMS100_SN06_MOD_AINDN
- A_NT-DMS100_SN06_MOD_ASL
- A_NT-DMS100_SN06_MOD_AUD
- A_NT-DMS100_SN06_MOD_AUL
- A_NT-DMS100_SN06_MOD_AUTODISP
- A_NT-DMS100_SN06_MOD_CFB
- A_NT-DMS100_SN06_MOD_CFBL
- A_NT-DMS100_SN06_MOD_CFD
- A_NT-DMS100_SN06_MOD_CFDA
- A_NT-DMS100_SN06_MOD_CFDVT
- A_NT-DMS100_SN06_MOD_CFF
- A_NT-DMS100_SN06_MOD_CFS
- A_NT-DMS100_SN06_MOD_CFU
- A_NT-DMS100_SN06_MOD_CFW
- A_NT-DMS100_SN06_MOD_CIF
- A_NT-DMS100_SN06_MOD_CNAMD
- A_NT-DMS100_SN06_MOD_CND
- A_NT-DMS100_SN06_MOD_CNF
- A_NT-DMS100_SN06_MOD_CPU
- A_NT-DMS100_SN06_MOD_CSMI
- A_NT-DMS100_SN06_MOD_CWT
- A_NT-DMS100_SN06_MOD_CXR
- A_NT-DMS100_SN06_MOD_DIN
- A_NT-DMS100_SN06_MOD_DQS
- A_NT-DMS100_SN06_MOD_DQT
- A_NT-DMS100_SN06_MOD_DRING
- A_NT-DMS100_SN06_MOD_EMW
- A_NT-DMS100_SN06_MOD_ESL
- A_NT-DMS100_SN06_MOD_FAA
- A_NT-DMS100_SN06_MOD_FTRGRP
- A_NT-DMS100_SN06_MOD_GIC
- A_NT-DMS100_SN06_MOD_ICM
- A_NT-DMS100_SN06_MOD_KSH
- A_NT-DMS100_SN06_MOD_LPIC
- A_NT-DMS100_SN06_MOD_MDN
- A_NT-DMS100_SN06_MOD_NAME

- A_NT-DMS100_SN06_MOD_NGTSRVCE
- A_NT-DMS100_SN06_MOD_OBS
- A_NT-DMS100_SN06_MOD_PIC
- A_NT-DMS100_SN06_MOD_RMI
- A_NT-DMS100_SN06_MOD_SCA
- A_NT-DMS100_SN06_MOD_SCU
- A_NT-DMS100_SN06_MOD_SDN
- A_NT-DMS100_SN06_MOD_SHU
- A_NT-DMS100_SN06_MOD_SUPR
- A_NT-DMS100_SN06_MOD_SVCGRP

A_NT-DMS100_SN06_CHF_FEATURES

Changes options to assigned single-line and multi-line telephone sets, to Hunt group lines, and to proprietary business sets. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modLineFeatures.**

Table 164: A_NT-DMS100_SN06_CHF_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 164: A_NT-DMS100_SN06_CHF_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
OPT	Options associated with a service you are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	A flag to indicate MML optimization of the command.	true, false	true	S	O

A_NT-DMS100_SN06_MOD_ACD

ACD allows the subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modACD.**

Table 165: A_NT-DMS100_SN06_MOD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 165: A_NT-DMS100_SN06_MOD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
AUTOMATIC_CALL_DISTRIBUTION_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_CALL_DISTRIBUTION_ACDGROUP	A group identifier that is already in table ACDGRP. Indicates the name of the automatic call distribution (ACD) group to which this station belongs.			S	R
AUTOMATIC_CALL_DISTRIBUTION_ACDSGRP	The number of the ACD subgroup to which this station belongs. This number must already appear in table ACDSGRP.			S	R
AUTOMATIC_CALL_DISTRIBUTION_IDNUM	Indicates if an ID number for a supervisor set is present. This field appears only when a supervisor set uses NEWACD. If Y, the POSID field prompts.			S	R
AUTOMATIC_CALL_DISTRIBUTION_POSID	Enter the ACD agent position ID number. A POSID is for interactions with other ACD options.			S	R

Table 165: A_NT-DMS100_SN06_MOD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_IBN_ACD_OPTION	Enter SCAILINK if the ACD agent associates with a set of D-channels for switch-computer communications. Enter ACDNR to deny ACD calls by the ACD agent.			C	R
AUTOMATIC_CALL_DISTRIBUTION_SCAI_LINK	Indicates the PRA D-channel name, or SCAIDEF for the default link set name.			S	O

A_NT-DMS100_SN06_MOD_AIN

The AIN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modAIN.**

Table 166: A_NT-DMS100_SN06_MOD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 166: A_NT-DMS100_SN06_MOD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
PRIVACY_ID_GROUP_AINGRP	The AIN group name used to define a group of trigger behaviors.			S	R
PRIVACY_ID_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
PRIVACY_ID_GROUP_KEYLIST	Specifies DN key numbers to which an option applies. Appears when the user assigns a subset option to BRI multi-line sets. If key number is not provided, the system assumes that the value is $.			C	O

A_NT-DMS100_SN06_MOD_AINDN

The AINDN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modAINDN.**

Table 167: A_NT-DMS100_SN06_MOD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 167: A_NT-DMS100_SN06_MOD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_ID_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
PRIVACY_ID_AINGRP	Enter TIID to datafill the trigger for the following refinements to the item provisioning interface. Up to 16 alphanumeric characters, or TIID.			S	R
PRIVACY_ID_TDP	Datafill the appropriate TDP.	1, 3, 4, 17, 19, 20, 22, 30, 32, and 33		S	O
PRIVACY_ID_TINAME	Alphanumeric vector (1 to 8 characters) to datafill the trigger items defined in table TRIGITM at the specified TDP.			S	O
PRIVACY_ID_TRIGACT	Datafill the value ON to activate the trigger item identified by the TIID. Datafill the value OFF to deactivate the trigger item identified by the TIID.	ON or OFF		S	O

A_NT-DMS100_SN06_MOD_ASL

The ASL option allows a supervisor to monitor the status of an agent position. This process does not interfere with the call. The lamp for the assigned agent status key reflects the status of

the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modASL.**

Table 168: A_NT-DMS100_SN06_MOD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AGENT_STATUS_LAMP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AGENT_STATUS_LAMP_AGENT_LEN	The LEN of the agent position.			S	R
AGENT_STATUS_LAMP_MSBOVRD	Make set busy override.			S	R
AGENT_STATUS_LAMP_ASLSDN	Agent status lamp that monitors the SDN of an ACD agent. Key number for the secondary DN the user must monitor.			S	R

A_NT-DMS100_SN06_MOD_AUD

The AUD option allows a business set subscriber to call a number the subscriber dials frequently. The subscriber presses the AUD key to call this number. The subscriber can

program and change this number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modAUD.**

Table 169: A_NT-DMS100_SN06_MOD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_DIAL_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_DIAL_PGMAUD	Indicates person who programs the AUD key.	Y = yes (operating company programmed), N = no (subscriber programmed)		S	R
AUTOMATIC_DIAL_AUDFEAT	The option or service to be accessed.			S	R

A_NT-DMS100_SN06_MOD_AUL

The automatic line (AUL) option connects to a set location when a directory number (DN) or an assigned AUL option line reports an off-hook status. This ASDL command changes the

option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modAUL.**

Table 170: A_NT-DMS100_SN06_MOD_AUL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_LINE_OPTKEY	Identifies the key on a business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_LINE_DN	Automatic line DN.			S	O
AUTOMATIC_LINE_NPA	Automatic line NPA.			S	O
AUTOMATIC_LINE_NXX	Automatic line NXX.			S	O
AUTOMATIC_LINE_LINE	Automatic line LINE.			S	O

A_NT-DMS100_SN06_MOD_AUTODISP

The automatic display (AUTODISP) option automatically shows information on incoming calls to a Meridian business set (MBS). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modAUTODISP.**

Table 171: A_NT-DMS100_SN06_MOD_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_DISPLAY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_DISPLAY_CWT_OPTION	Indicates person who programs the AUD key.	Y = yes (operating company programmed), N = no (subscriber programmed)		S	R
AUTOMATIC_DISPLAY_KEYLIST	The option or service to be accessed.			C	R

A_NT-DMS100_SN06_MOD_CFB

The CFB option allows the system to forward all calls to a busy station to a station determined earlier. This ASDL command changes the option parameters of the assigned line. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFB.**

Table 172: A_NT-DMS100_SN06_MOD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_BUSY_CNTL	Call forwarding busy control.	F = fixed assignment for CFB, N = normal (default) assignment for CFB, P = programmed assignment for CFB, K = programmed assignment for CFB per key destination		S	O
CALL_FORWARD_BUSY_DN	Call forwarding DN for CFB option.			S	O
CALL_FORWARD_BUSY_NPA	Call forwarding NPA for CFB option.			S	O
CALL_FORWARD_BUSY_NXX	Call forwarding NXX for CFB option.			S	O
CALL_FORWARD_BUSY_LINE	Call forwarding LINE for CFB option.			S	O

Table 172: A_NT-DMS100_SN06_MOD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_MOD_CFBL

The CFBL option allows the subscriber to specify a directory number (DN). This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFBL.**

Table 173: A_NT-DMS100_SN06_MOD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_LINE_CFBLCNTL	Call forwarding busy line control value.	C = programmed assignment for CFBL, F = fixed assignment for CFBL, N = normal (default) assignment for CFBL		S	R
CALL_FORWARD_BUSY_LINE_SCRNCL	Screening by class of service.			S	R

Table 173: A_NT-DMS100_SN06_MOD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_LINE_NUMCALLS	The number of calls the system can forward at the same time.	0-1024		S	R
CALL_FORWARD_BUSY_LINE_DN	DN to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NPA	NPA to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NXX	NXX to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_LINE	Line to which the system will forward calls.			S	O

A_NT-DMS100_SN06_MOD_CFD

The CFD option allows the system to forward incoming calls that are not answered within a specified time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFD.**

Table 174: A_NT-DMS100_SN06_MOD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 174: A_NT-DMS100_SN06_MOD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_BUS_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_NO_ANSWER_BUS_CNTL	Call forwarding busy control.	F = fixed assignment for CFD, N = normal (default) assignment for CFD, P = programmed assignment for CFD, and K = programmed assignment for CFD per key destination		S	O
CALL_FORWARD_NO_ANSWER_BUS_DN	Call forwarding DN for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NPA	Call forwarding NPA for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NXX	Call forwarding NXX for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_LINE	Call forwarding LINE for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

A_NT-DMS100_SN06_MOD_CFDA

The Call Forwarding Do Not Answer (CFDA) Residential option forwards calls not answered to stations in the same customer group. This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFDA.**

Table 175: A_NT-DMS100_SN06_MOD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_RES_CNTL	Call Forwarding Do Not Answer control.	F = fixed, N = normal (default), and C = programmed assignment		S	O
CALL_FORWARD_NO_ANSWER_RES_SCRNCL	Identifies screening by class of service.			S	R
CALL_FORWARD_NO_ANSWER_RES_NUMCALLS	The number of calls the system can forward at the same time.			S	R
CALL_FORWARD_NO_ANSWER_RES_TIME	Indicates the period of time the base station rings before forwarding.			S	R

Table 175: A_NT-DMS100_SN06_MOD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_RES_RING_CTRL	Indicates whether the end user or the operating company controls the ringing time-out. PRGRING allows the end user to change the CFDA ringing time-out. FIXRING indicates that only the operating company can change the ringing time-out.			S	R
CALL_FORWARD_NO_ANSWER_RES_DN	Number to which the system forwards calls.			S	O
CALL_FORWARD_NO_ANSWER_RES_NPA	Call forwarding NPA for the CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_NXX	Call forwarding NXX for the CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_LINE	Call forwarding LINE for the CFDA option.			S	O

A_NT-DMS100_SN06_MOD_CFDVT

The Call Forwarding Do Not Answer Variable Timer (CFDVT) option allows an end-user to specify how long a call rings before the system forwards the call to another station. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFDVT.**

Table 176: A_NT-DMS100_SN06_MOD_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_VAR_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_NO_ANSWER_VAR_TIME	Call forward do not answer timing. The time, in seconds, that a call rings before the system forwards the call to the next DN.	0-60		S	R
CALL_FORWARD_NO_ANSWER_VAR_RING_CTRL	Ring control. Enter PRGRING to allow the end-user to set the CVDVT time-out period. Enter FIXRING to indicate to the end-user that the CVDVT time-out period is fixed; it can only be changed by the operating company.			S	R

A_NT-DMS100_SN06_MOD_CFF

Modify the CFF option to a line. The CFF option allows the station to forward calls to a location the operating company enters. The user cannot program the number to which the station forwards the calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFF.**

Table 177: A_NT-DMS100_SN06_MOD_CFF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_FIXED_CFFDN	Call forwarding DN for CFF option.			S	O
CALL_FORWARD_FIXED_CFF_OPTION	The value to set the CFFA to active.			S	O

A_NT-DMS100_SN06_MOD_CFS

The Call Forwarding Simultaneous/Screening (CFS) option allows the user to call forward more than one call through a station at a time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFS.**

Table 178: A_NT-DMS100_SN06_MOD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 178: A_NT-DMS100_SN06_MOD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_SIMULTANEUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_SIMULTANEUS_SIMULT	Indicates Call Forwarding Simultaneous.			S	R
CALL_FORWARD_SIMULTANEUS_NCFUIF	Maximum number of active calls the user can forward through a CFU, CFI, or CFF base station at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_NCFB	Maximum number of active calls the user can forward through a CFB base station at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_NCFD	The number of calls the user can forward for call forward do not answer at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_SCREEN	Call forwarding screening capability.			S	R

Table 178: A_NT-DMS100_SN06_MOD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_CFXNCOS	Call forwarding NCOS.			S	R

A_NT-DMS100_SN06_MOD_CFU

The CFU option allows a station user to reroute incoming calls to another telephone number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFU.**

Table 179: A_NT-DMS100_SN06_MOD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_UNIVERSAL_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_UNIVERSAL_OVRDACR	Override for account code required.	Y = Yes, N = No		S	R

Table 179: A_NT-DMS100_SN06_MOD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_UNIVERSAL_KEYLIST	Specifies the key numbers of the DNs to which an option will apply. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O

A_NT-DMS100_SN06_MOD_CFW

The CFW option allows the user to forward calls to another location. This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCFW.**

Table 180: A_NT-DMS100_SN06_MOD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_TYPE	Type of call forwarding.	C = customer, F = fixed, U = usage sensitive pricing		S	R
CALL_FORWARD_SCRNCL	Screening by class of service.			S	R
CALL_FORWARD_STATE	State of absent subscriber intercept.	A = active, I = inactive, W = wait		S	O

Table 180: A_NT-DMS100_SN06_MOD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NUMCALLS	The number of calls the user can forward at the same time.	0-1024		S	O
CALL_FORWARD_DN	Number to which calls will be forwarded.	1-30 digits. "$" must not be used		S	O
CALL_FORWARD_NPA	NPA to which calls will be forwarded.			S	O
CALL_FORWARD_NXX	NXX to which calls will be forwarded.			S	O
CALL_FORWARD_LINE	LINE to which calls will be forwarded.			S	O

A_NT-DMS100_SN06_MOD_CIF

The Controlled Interflow (CIF) option allows a supervisor to place an automatic call distribution (ACD) group in a controlled interflow mode. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCIF.**

Table 181: A_NT-DMS100_SN06_MOD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 181: A_NT-DMS100_SN06_MOD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
CONTROLLED_INTERFLOW_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
CONTROLLED_INTERFLOW_ACDGROUP	The name of the automatic call distribution group name. The name is a group identifier the user must datafill in Table ACDGRP.			S	R

A_NT-DMS100_SN06_MOD_CNAMD

The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCNAMD.**

Table 182: A_NT-DMS100_SN06_MOD_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 182: A_NT-DMS100_SN06_MOD_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
CALLER_ID_NAME_DELIVERY_BILLING_OPTION	Indicates the billing option that the user must specify when the user assigns the CNAMD.	AMA = AMA record created, NOAMA = AMA record not created		S	O
CALLER_ID_NAME_DELIVERY_OPTKEY	Identifies a key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_MOD_CND

The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is enabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCND.**

Table 183: A_NT-DMS100_SN06_MOD_CND

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALLING_NUMBER_DELIVERY_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O

A_NT-DMS100_SN06_MOD_CNF

The Station Controlled Conference (CNF) option allows a station to have a conference call to a maximum of 30 parties. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCNF.**

Table 184: A_NT-DMS100_SN06_MOD_CNF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_CONTROLLED_CONFERENCE_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
STATION_CONTROLLED_CONFERENCE_CONF_TYPE	Indicates the maximum number of stations that can connect to a station controlled conference.			S	R

A_NT-DMS100_SN06_MOD_CPU

The Call Pickup (CPU) option allows a station to answer incoming calls to another station in the same pickup group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCPU.**

Table 185: A_NT-DMS100_SN06_MOD_CPU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_PICKUP_OPT KEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
CALL_PICKUP_CPU _LEN	Indicates the CPU number.			S	R

A_NT-DMS100_SN06_MOD_CSMI

The CSMI feature allows end users of Network Based Answering Services (NBAS) to monitor and intercept calls that the NBAS handles. This ASDL command changes the option

parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCSMI.**

Table 186: A_NT-DMS100_SN06_MOD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_SCREENING_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_SCREENING_CSMISTATE	The state of activating CSMI feature.			S	O
CALL_SCREENING_CSMIPPU	Identifies the billing option to use.			S	O
CALL_SCREENING_CONNEC3W	Determines call interception (2-way call or 3-way call).			S	O
CALL_SCREENING_SCRACTIVE	Indicates whether the SCRDUR parameter is required.			S	O
CALL_SCREENING_SCRDUR	Specifies the length of the screening period.			S	O
CALL_SCREENING_DENYOPT	Specifies the type of call forward for which CSMI is applied.			C	R

A_NT-DMS100_SN06_MOD_CWT

The CallWaiting (CWT) option allows the system to alert a busy station when an incoming call attempts to reach the directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCWT.**

Table 187: A_NT-DMS100_SN06_MOD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_WAITING_CWT_OPTION	Indicates if the CWT option is active.	Y = Yes, N = No		S	O
CALL_WAITING_RING	Specifies whether a ring from a telephone speaker is required in addition to the LCD diamond CWT key.	Y or N		S	O
CALL_WAITING_PCWT	Precedence call waiting.	Y = Yes, N = No		S	O

Table 187: A_NT-DMS100_SN06_MOD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_KEYLIST	Specifies key numbers of the DNS to which the user applied a feature. Appears when the user assigns a subset feature to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O

A_NT-DMS100_SN06_MOD_CXR

The call transfer (CXR) option allows the assignment of a call transfer type other than the type that the customer group has. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modCXR.**

Table 188: A_NT-DMS100_SN06_MOD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRANSFER_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O

Table 188: A_NT-DMS100_SN06_MOD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_TYPE	Call transfer type.	CTOUT = call transfer outgoing calls, CTINC = call transfer incoming calls, CTINTRA = call transfer intra group, CTALL = call transfer all, NCT = the system routes the call to the attendant if the first leg of the call is INTERGROUP and the controller is terminator of the call, ATTRCLF = the system routes the call to the attendant at all times, CUSTOM = call transfer of types other than above		S	R
CALL_TRANSFER_ORGINTER	For a CUSTOM type call transfer, the first leg of the call is intergroup. The controller is the originator of the call.	AC = second leg of the call is to the attendant, Inter = second leg of the call can be intergroup, Intra = second leg of the call can be intragroup, Trater = second leg of the call can be intragroup or intergroup, Nocxfer = call transfer is not allowed		S	O
CALL_TRANSFER_ORGINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_TRMINTER	First leg of the call is intragroup and the controller is the originator of the call.			S	O

Table 188: A_NT-DMS100_SN06_MOD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_TRMINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_RCL	Call transfer recall.			S	R
CALL_TRANSFER_RCLTIM	Recall timer for transfer recall.			S	O
CALL_TRANSFER_METHOD	The method of call transfer.	Dial (DIAL), Standard (STD), or Release (RLS)		S	R

A_NT-DMS100_SN06_MOD_DIN

The DIN option prevents selected lines from receiving incoming calls that originate outside the customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modDIN.**

Table 189: A_NT-DMS100_SN06_MOD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 189: A_NT-DMS100_SN06_MOD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_INCOMING_CALL_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
DENIED_INCOMING_CALL_TRC	Terminating restriction code used with the IBN DIN option. Code indicates the classes of incoming calls allowed on a trunk. The value is in a format of a list in series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DENIED_INCOMING_CALL_ALTTRC	Alternate terminating restriction code. This code applies to IBN extended calls. The value is in a format of a list in a series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DENIED_INCOMING_CALL_DINOPT	Assigns the Transfer Call to Restricted Station (DINE) sub-option to a line.	DINE = Accepts some types of transferred calls, N = Does not accept transferred calls		S	R

A_NT-DMS100_SN06_MOD_DQS

The Display Queue Status (DQS) option allows an ACD supervisor to display the load status information for an ACD group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modDQS.**

Table 190: A_NT-DMS100_SN06_MOD_DQS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_QUEUE_STATUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISPLAY_QUEUE_STATUS_ACDGROUP	A group identifier already in Table ACDGRP.			S	R

A_NT-DMS100_SN06_MOD_DQT

The Display Queue Threshold (DQT) option allows the system to display the status of the incoming call queue. The status of the queue appears when the ACD agent or supervisor

presses the associated key of the set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modDQT.**

Table 191: A_NT-DMS100_SN06_MOD_DQT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_QUEUE_THRESHOLD_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISPLAY_QUEUE_THRESHOLD_DIFFGRP	Indicates if the system uses a group other than the ACD INCALLS group to establish the queue threshold status.			S	R

A_NT-DMS100_SN06_MOD_DRING

The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types. It is implemented by

the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modDRING.

Table 192: A_NT-DMS100_SN06_MOD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISTINCTIVE_RING_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISTINCTIVE_RING_INTRNL	Indicates intragroup calls have distinctive ringing.			S	R
DISTINCTIVE_RING_EXTRNL	Indicates external calls have distinctive ringing.			S	R
DISTINCTIVE_RING_INTRNL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_EXTRNL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_GIC_DRINGTYPE	Specifies the ring type.			S	O

Table 192: A_NT-DMS100_SN06_MOD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_RECALL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_UCD_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_REST_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_ACD_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_MAKECALL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_TRKS	IBN trunks.	SEL = selected trunks, ALL = all trunks, NO = no trunks		S	R
DISTINCTIVE_RING_GIC	Group intercom.			S	R
DISTINCTIVE_RING_RECALL	Recall ringing.			S	R
DISTINCTIVE_RING_UCD	Uniform call distribution.			S	R
DISTINCTIVE_RING_REST	Call types that remain.			S	R
DISTINCTIVE_RING_ACD	Automatic call distribution.			S	R
DISTINCTIVE_RING_MAKECALL	Indicates distinctive ringing for outbound calls at customer group level.			S	O

A_NT-DMS100_SN06_MOD_EMW

The Executive MessageWaiting (EMW) option introduces a message waiting class of service (MCOS) to enhance the message waiting option. A user can only access the MCOS to which the user subscribes. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modEMW.**

Table 193: A_NT-DMS100_SN06_MOD_EMW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
EXECUTIVE_MESSAGE_WAIT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
EXECUTIVE_MESSAGE_WAIT_DNLIST	A DN key that subscribes to an MCOS. Specify one key for each MCOS.	1 - 69		C	O
EXECUTIVE_MESSAGE_WAIT_NOTICE	Message waiting notification.	STD = stuttered dial tone, MWL = message waiting lamp, CMWI = CLASS message waiting Indicator, PRN = periodic ring notification		S	O

Table 193: A_NT-DMS100_SN06_MOD_EMW

Parameter Name	Description	Range	Default Value	Type	Class
EXECUTIVE_MESSAGE_WAIT_MCOS	The name of the MCOS the MDC line subscribes, or the key set.			C	O

A_NT-DMS100_SN06_MOD_ESL

The Emergency Service Line (ESL) allows a line for emergency service to be designated. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modESL.**

Table 194: A_NT-DMS100_SN06_MOD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
EMERGENCY_SERVICE_LINE_ROH_TONE_TIME	An emergency service office line option parameter; the duration in seconds of the receiver off-hook tone a caller receives when the ESL flashes.			S	R
EMERGENCY_SERVICE_LINE_INTEG_TONE	The integrity tone type.			S	R

Table 194: A_NT-DMS100_SN06_MOD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
EMERGENCY_SERVICE_LINE_INTEG_TONE_TIME	The interval in seconds after which the system generates an alarm and logs a report when an ESL line is off-hook.			S	R
EMERGENCY_SERVICE_LINE_SWITCHHOOK_TONE	The tone the emergency service office line receives when a caller goes on-hook.	LOW = steady low tone BUSY = 60 interruptions per minute (IPM) busy tone		S	R
EMERGENCY_SERVICE_LINE_FASTFLASH	An option for emergency service office lines. Usually N is used. Y is entered if the emergency service bureau is equipped with an SP-1 console or equivalent that has the ability to generate an 80-ms flash.			S	R
EMERGENCY_SERVICE_LINE_RINGBACK	Option used with an emergency service office line to enable the office to ring back a caller who goes on-hook.			S	R
EMERGENCY_SERVICE_LINE_FORCED_DISCONNECT_TIME	Option used with an emergency service office line. The timing in seconds, longer than a 2 s flash, after which the call disconnects and the emergency service line goes on-hook.			S	R

A_NT-DMS100_SN06_MOD_FAA

The Forced Agent Availability (FAA) option allows an ACD (Automatic Call Distribution) supervisor to force an ACD agent from the Not Ready state to the Ready state. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modFAA.**

Table 195: A_NT-DMS100_SN06_MOD_FAA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FORCED_AGENT_AVAILABILITY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
FORCED_AGENT_AVAILABILITY_EXTNDFAA	Extended forced agent availability. Indicates if the feature is valid for ACD agents in any ACD group and subgroup in the same customer group as the supervisor.			S	R
FORCED_AGENT_AVAILABILITY_ACDGROUP	A group identifier already in Table ACDGRP.			S	R

A_NT-DMS100_SN06_MOD_FTRGRP

The FTRGRP option allows the operating company to define a number of features as a feature group. The feature group can be assigned to customer lines. It is implemented by the Java

method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modFTRGRP.

Table 196: A_NT-DMS100_SN06_MOD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FEATURE_GROUP_ GRPNAME	The name of the feature group with a minimum of one feature.			S	R
FEATURE_GROUP_ OPTKEY	Identifies a key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_MOD_GIC

The GIC option allows call termination on a member of a designated intercom group that uses abbreviated dialing. Use abbreviated dialing to access group members. It is implemented by the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modGIC.

Table 197: A_NT-DMS100_SN06_MOD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 197: A_NT-DMS100_SN06_MOD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
GROUP_INTERCOM_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
GROUP_INTERCOM_GICNAME	Designated name of group intercom line.			S	R
GROUP_INTERCOM_GICMEMNO	Digits dialed to reach this line.			S	R
GROUP_INTERCOM_GICSMDR	SMDR records required.			S	R
GROUP_INTERCOM_GICNOMSB	Group intercom calls not included in MSB.			S	R

A_NT-DMS100_SN06_MOD_ICM

The ICM option allows a business set user to directly terminate upon a predesignated business set by pressing the ICM feature key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modICM.**

Table 198: A_NT-DMS100_SN06_MOD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 198: A_NT-DMS100_SN06_MOD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTERCOM_BUSINESS_SET_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
INTERCOM_BUSINESS_SET_LINK_LEN	The LEN of a member of an existing DLH or MLH Hunt group to which additional members are to be linked.			S	R
INTERCOM_BUSINESS_SET_DOR	Denied origination.			S	R
INTERCOM_BUSINESS_SET_SIC_KEY	Straight intercom key.			S	R
INTERCOM_BUSINESS_SET_SMDR	Station message detail recording.			S	R

A_NT-DMS100_SN06_MOD_KSH

The Key Short Hunt (KSH) option allows incoming calls to search for an idle directory number (DN) on which to terminate. The options search for this DN occurs through a set of

DN appearances on a business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modKSH.**

Table 199: A_NT-DMS100_SN06_MOD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
KEY_SHORT_HUNT _OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
KEY_SHORT_HUNT _OVTYPE	Type of overflow required when short Hunt group is busy.	N = no overflow, D = DN to which overflow is to go, R = route		S	R
KEY_SHORT_HUNT _OVDN	The overflow directory number for the KSH option when the OVTYPE is D.			S	O
KEY_SHORT_HUNT _TABID	A table identifier associated with the line overflow to a route (LOR) and KSH options.	OFRT = Office Route Reference Table, IBNRTE = IBN Route Reference Table		S	R

Table 199: A_NT-DMS100_SN06_MOD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
KEY_SHORT_HUNT _KSH_KEY	The line Hunt overflow route index that identifies the overflow route. The index identifies the key on business set or data unit. The index indicates the route reference number when Route (R) is the overflow for the KSH option.			S	O
KEY_SHORT_HUNT _KEYLIST	Appears when an assignment of a subset feature to a multiline set occurs. Specifies key numbers of the DNs to which a feature will apply.			C	O

A_NT-DMS100_SN06_MOD_LPIC

Option Intra-LATA PIC (LPIC) allows the user to choose a primary carrier for the Intra-LATA service. Field LCHOICE allows subscribers to dial Intra-LATA calls on a casual basis. This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modLPIC.**

Table 200: A_NT-DMS100_SN06_MOD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 200: A_NT-DMS100_SN06_MOD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTRA_PIC_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
INTRA_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTRA_PIC_CHOICE	Indicates whether the subscriber is allowed to casually dial Intra-LATA calls.	Y or N		S	R

A_NT-DMS100_SN06_MOD_MDN

The MDN option assigns a DN to more than one set. A multiple appearance directory number (MADN) is a directory number (DN) that appears on more than one Meridian business set (MBS). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modMDN.**

Table 201: A_NT-DMS100_SN06_MOD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 201: A_NT-DMS100_SN06_MOD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MULTIPLE_APPEARANCE_DN_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
MULTIPLE_APPEARANCE_DN_MDNTYPE	The type of call Arrangement.	MCA = multiple call arrangement, SCA = single call arrangement, EXB = extension bridging		S	R
MULTIPLE_APPEARANCE_DN_PRIMARY	Primary member of a MADN group.			S	R
MULTIPLE_APPEARANCE_DN_RING	Indicates whether ringing is required.			S	R
MULTIPLE_APPEARANCE_DN_DIR_NUMBER	Directory number.			S	R

A_NT-DMS100_SN06_MOD_NAME

The system uses NAME feature to assign a name to DN. This ASDL changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modNAME.**

Table 202: A_NT-DMS100_SN06_MOD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NAME_OPTKEY	Identifies a key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NAME_NETNAME	Network name shown as DN attribute.			S	R
NAME_DISPLAYNAME	Name to display on MBS set.			S	R

A_NT-DMS100_SN06_MOD_NGTSRVCE

The Night Service (NGTSRVCE) option allows the ACD supervisor to place all ACD agent sets in an ACD group in night service mode. The ACD supervisor presses the Night Service key on the supervisor set to place the ACD agent sets in night service modes. It is implemented

by the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modNGTSRVCE.

Table 203: A_NT-DMS100_SN06_MOD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NIGHT_SERVICE_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NIGHT_SERVICE_ACDGROUP	A group identifier that the user already entered in Table ACDGRP. The identifier is the name of the automatic call distribution group to which this station belongs.			S	O

A_NT-DMS100_SN06_MOD_OBS

The Observe Agent (OBS) option allows a supervisor to observe conversations between an agent and a caller. This user presses the OBS key to observe conversations between an agent

and a caller. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modOBS.**

Table 204: A_NT-DMS100_SN06_MOD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OBSERVE_AGENT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
OBSERVE_AGENT_OBSTYPE	The type of observation a supervisor can apply over incoming ACD calls.	basic, extended, or flexible call observing		S	R
OBSERVE_AGENT_ACDGROUP	A group identifier that Table ACDGRP must already contain. The group identifier is the name of the automatic call distribution group to which this station belongs.			S	O
OBSERVE_AGENT_FOBS_ACDGROUP	Appears if OBSTYPE is set to FOBS.			S	O

Table 204: A_NT-DMS100_SN06_MOD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
OBSERVE_AGENT_FOBSTYPE	Appears if OBSTYPE is set to FOBS. Specifies the type of flexible call observing required.			S	O
OBSERVE_AGENT_FOBS_SUBGROUP	Specifies an ACD subgroup number. Appears if FOBSTYPE = SUBGROUP.			S	O
OBSERVE_AGENT_DN	Specifies an ACD Directory number. Appears if FOBSTYPE = DN.			S	O

A_NT-DMS100_SN06_MOD_PIC

Option Primary Inter-LATA Carrier (PIC) assigns a PIC to an MDC line. This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modPIC.**

Table 205: A_NT-DMS100_SN06_MOD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 205: A_NT-DMS100_SN06_MOD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
INTER_PIC_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
INTER_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTER_PIC_CHOICE	Specifies whether the system allows the user to dial 10xxx to access other carriers.	Y or N		S	R

A_NT-DMS100_SN06_MOD_RMI

The RMI Option allows the subscribers of the message waiting indicator feature to check for the existence of messages in their voice mail box from a remote location. This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modRMI.**

Table 206: A_NT-DMS100_SN06_MOD_RMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 206: A_NT-DMS100_SN06_MOD_RMI

Parameter Name	Description	Range	Default Value	Type	Class
REMOTE_MESSAGE_INDICATOR_RMI_STATE	The state of the RMI feature. Valid values are active or inactive.			S	R
REMOTE_MESSAGE_INDICATOR_OPTKEY	Identifies the key on the business set or data units to which an option is assigned.	1-69 for business set; 1, 2, 3, 4, or 7 for data unit		S	O

A_NT-DMS100_SN06_MOD_SCA

The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN). This ASDL command changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modSCA.**

Table 207: A_NT-DMS100_SN06_MOD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SELECTIVE_CALL_ACCEPTANCE_OPTKEY	Identifies the key on the business set or data units to which an option is assigned.	1-69 for business set; 1, 2, 3, 4, or 7 for data unit		S	O

Table 207: A_NT-DMS100_SN06_MOD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_ACCEPTANCE_STATUS	INACT indicates the option is not enabled (inactive), ACT indicates the option is enabled (active), UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.			S	R
SELECTIVE_CALL_ACCEPTANCE_BILLING_OPTION	NOAMA indicates that the feature is billed based on a subscription and AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O

A_NT-DMS100_SN06_MOD_SCU

The SCU option allows a line to be designated as a speed calling user in a speed calling group. A speed calling user can only originate calls with speed calling and cannot affect the contents of the speed calling list. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modSCU.**

Table 208: A_NT-DMS100_SN06_MOD_SCU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 208: A_NT-DMS100_SN06_MOD_SCU

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPEED_CALLING_USER_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SPEED_CALLING_USER_SCUGNUMBER	Specifies a unique group number for the SCU option.			S	R
SPEED_CALLING_USER_SCU_TDN	Specifies whether toll denial is applied to speed call numbers.			S	R

A_NT-DMS100_SN06_MOD_SDN

To add a secondary DN to a Teen Service line. The SDN option can be assigned to POTS, RES, or IBN agents. When no SDNs are assigned to the line, adding the SDN option establishes Teen Service. This ASDL changes the option parameters of the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modSDN.**

Table 209: A_NT-DMS100_SN06_MOD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 209: A_NT-DMS100_SN06_MOD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SECONDARY_DN_DN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_NPA	Secondary NPA.			S	O
SECONDARY_DN_NXX	Secondary NXX.			S	O
SECONDARY_DN_LINE	Secondary LINE.			S	O

Table 209: A_NT-DMS100_SN06_MOD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
SECONDARY_DN_NEW_DN	New Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_NEW_NPA	New Secondary NPA.			S	O
SECONDARY_DN_NEW_NXX	New Secondary NXX.			S	O
SECONDARY_DN_NEW_LINE	New Secondary LINE.			S	O
SECONDARY_DN_DNY	NODNY = No deny to call waiting. DNYCWT = Deny call waiting. These options are not applicable to MDC. Enter $ to omit both options.			S	O
SECONDARY_DN_RING	Secondary DN ring type.	0 = normal ringing, 1 = SDN pattern #1, 2 = SDN pattern #2, 3 = SDN pattern #3		S	R
SECONDARY_DN_OPT	Secondary DN type.	P = forward SDN with PDN, N = do not forward SDN, E = enhanced SDN can have own option list		S	R

A_NT-DMS100_SN06_MOD_SHU

The SHU option allows hunting at a line to be canceled when activated. SHU can be assigned to one, several, or all lines in a Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modSHU.**

Table 210: A_NT-DMS100_SN06_MOD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STOP_HUNT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
STOP_HUNT_SC	Scan point.	tmtype = MTM, RSMtmno = 0-2047, tmcktno = 0-29, point = 0-6 (SD point number), normal_state = 0 for open or 1 for closed		S	R
STOP_HUNT_TMNO	Enter the number of the trunk module on which the circuit is mounted. Appears after the signal distribution (SD) or SC prompt if data is not entered on one line.			S	R

Table 210: A_NT-DMS100_SN06_MOD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
STOP_HUNT_TMCKTNO	Enter the trunk module circuit number to which the circuit is assigned. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_POINT	SD point number. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_NORMAL_STATE	Normal state of the SD point. Appears after the SD or SC prompt if data is not entered on one line.			S	R

A_NT-DMS100_SN06_MOD_SUPR

The SUPR option establishes an automatic call distribution (ACD) supervisor set when assigned to key 1. This option must be assigned before ACD supervisor options can be assigned to the set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modSUPR.**

Table 211: A_NT-DMS100_SN06_MOD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 211: A_NT-DMS100_SN06_MOD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
SUPERVISOR_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SUPERVISOR_PRIMARY_ACDGROUP	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.			C	R
SUPERVISOR_PRIMARY_ACDSGRP	The supervisor subgroup identifier that must already be datafilled in Table ACDSGRP in order to add the SUPR option to an ACD group.			C	R
SUPERVISOR_IDNUM	Indicates if ID number of agent position is required.	Y = Yes, N = No		C	R

A_NT-DMS100_SN06_MOD_SVCGRP

The SVCGRP option allows options CLID (Calling Line Identification Display), NAME (Name Display) and REASDSP (Reason Display), packaged in a service group, to be assigned to a selected line in a customer group or multiple customer groups. It is implemented by the

Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgFeatProv.modSVCGRP.

Table 212: A_NT-DMS100_SN06_MOD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SERVICE_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SERVICE_GROUP_GRPNAME	The group identifier that must already be datafilled in Table ACDGRP when adding the SUPR option to an ACD group.			S	R

Modify Line Services

This cartridge provides the following ASDL commands:

- A_NT-DMS100_SN06_MOD_DN
- A_NT-DMS100_SN06_MOD_INTERCEPT_NAME
- A_NT-DMS100_SN06_MOD_LCC
- A_NT-DMS100_SN06_MOD_LEN
- A_NT-DMS100_SN06_MOD_LTG
- A_NT-DMS100_SN06_MOD_MULTILINE-LEN

- A_NT-DMS100_SN06_MOD_NCOS

A_NT-DMS100_SN06_MOD_DN

The CDN command changes directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modDN.**

Table 213: A_NT-DMS100_SN06_MOD_DN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension of the new DN number.			S	O
NEW_DN	Enter the new DN that replaces the previous DN.			S	O
NEW_NPA	3 digit area code of the new DN number.			S	O
NEW_NXX	First 3 digits of the line number of the new DN number.			S	O
NEW_LINE	4 digit line extension of the new DN number.			S	O

Table 213: A_NT-DMS100_SN06_MOD_DN

Parameter Name	Description	Range	Default Value	Type	Class
INTERCEPT_NAME	The type of intercept you want.	BLDN, AINT, ANCT, CANN, OPRT, and UNDN		S	O
VDNTYPE	Used to provision VDNs.	When BLOCK_OF_DNS is NO, the following inputs are valid: AIN, DISA, CFIB, RCF, RCFEA, RTE, MSR, SIMRING. When BLOCK_OF_DNS is YES, the valid input is RTE		S	O
FWD_DN	The DN (up to 30 digits) to which calls are forwarded in a fixed call forwarding option.			S	O
MAXCALLS	Appears during the assignment of an RCF. Specifies the maximum number of simultaneous calls allowed to the DN.	0-511		S	O
LTG	Line treatment group member, used to calculate the line attribute index then the DN and LCC are insufficient to find an appropriate index. LTG is prompted for in conjunction with LCC.	0-255		S	O
MRSA	MRSA as defined in table MRSANAME. Message rate service area to be used for billing with remote call forwarding.			S	O

Table 213: A_NT-DMS100_SN06_MOD_DN

Parameter Name	Description	Range	Default Value	Type	Class
BLK_TOLL_COM	Appears for the RCF option. Specifies whether incoming toll calls are forwarded to a remote station.	Y or N		S	O
BLK_TOLL_TREATMENT	Appears for the RCF option. Specifies the treatment given to a blocked toll call.			S	O
OM_INDEX	Operations measurements index.	0-127		S	O
SCRNCL	Specifies route or screening class for a forwarded call.	RTE or SCR		S	O
SIGDATA	Specifies whether or not to use RCF signaling enhancements.	Y or N		S	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_MOD_INTERCEPT_NAME

The CICP command changes the intercept name. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modInterceptName.**

Table 214: A_NT-DMS100_SN06_MOD_INTERCEPT_NAME

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 214: A_NT-DMS100_SN06_MOD_INTERCEPT_NAME

Parameter Name	Description	Range	Default Value	Type	Class
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
INTERCEPT_NAME	New intercept name.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_MOD_LCC

The CHG-LCC command changes LCC. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modLCC.**

Table 215: A_NT-DMS100_SN06_MOD_LCC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 215: A_NT-DMS100_SN06_MOD_LCC

Parameter Name	Description	Range	Default Value	Type	Class
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LATA_NAME	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	R
LTG	Line treatment group member used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index.	0-255		S	R
LINE	4 digit line extension.			S	O
LCC	The line class code of the service to be modified.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_MOD_LEN

The CLN command changes line equipment number (LEN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modLEN.**

Table 216: A_NT-DMS100_SN06_MOD_LEN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LEN	Current line equipment number.			S	R
NEW_LEN	New line equipment number.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_MOD_LTG

The CLTG command changes the line treatment group (LTG) number to route a call through a different trunk group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modLTG.**

Table 217: A_NT-DMS100_SN06_MOD_LTG

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O

Table 217: A_NT-DMS100_SN06_MOD_LTG

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LTG	Line treatment group member used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. LTG is prompted for in conjunction with LCC.	0-255		S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_MOD_MULTILINE-LEN

The CKLN command changes the keyset value of the line equipment number (LEN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modCKLEN.**

Table 218: A_NT-DMS100_SN06_MOD_MULTILINE-LEN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LEN	Old line equipment number.			S	R
NEW_LEN	New line equipment number.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_MOD_NCOS

The CHG command changes the NCOS. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsChgLineParam.modNCOS.**

Table 219: A_NT-DMS100_SN06_MOD_NCOS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
NCOS	New network class of service.			S	R
CUSTOM	Customer-specific parameter.			C	O

Delete Feature Services

This cartridge provides the following ASDL commands:

- A_NT-DMS100_SN06_DEL_3WC
- A_NT-DMS100_SN06_DEL_ACB
- A_NT-DMS100_SN06_DEL_ACD
- A_NT-DMS100_SN06_DEL_ACDNR

- A_NT-DMS100_SN06_DEL_ACRJ
- A_NT-DMS100_SN06_DEL_AIN
- A_NT-DMS100_SN06_DEL_AINDN
- A_NT-DMS100_SN06_DEL_AMSGDENY
- A_NT-DMS100_SN06_DEL_AR
- A_NT-DMS100_SN06_DEL_ARDDN
- A_NT-DMS100_SN06_DEL_ASL
- A_NT-DMS100_SN06_DEL_AUD
- A_NT-DMS100_SN06_DEL_AUL
- A_NT-DMS100_SN06_DEL_AUTODISP
- A_NT-DMS100_SN06_DEL_CBE
- A_NT-DMS100_SN06_DEL_CBU
- A_NT-DMS100_SN06_DEL_CCW
- A_NT-DMS100_SN06_DEL_CDE
- A_NT-DMS100_SN06_DEL_CDI
- A_NT-DMS100_SN06_DEL_CDU
- A_NT-DMS100_SN06_DEL_CFB
- A_NT-DMS100_SN06_DEL_CFBL
- A_NT-DMS100_SN06_DEL_CFD
- A_NT-DMS100_SN06_DEL_CFDA
- A_NT-DMS100_SN06_DEL_CFDVT
- A_NT-DMS100_SN06_DEL_CFF
- A_NT-DMS100_SN06_DEL_CFGD
- A_NT-DMS100_SN06_DEL_CFGDA
- A_NT-DMS100_SN06_DEL_CFI
- A_NT-DMS100_SN06_DEL_CFMDN
- A_NT-DMS100_SN06_DEL_CFRA
- A_NT-DMS100_SN06_DEL_CFS
- A_NT-DMS100_SN06_DEL_CFU
- A_NT-DMS100_SN06_DEL_CFW
- A_NT-DMS100_SN06_DEL_CHD
- A_NT-DMS100_SN06_DEL_CIF
- A_NT-DMS100_SN06_DEL_CIR
- A_NT-DMS100_SN06_DEL_CLF
- A_NT-DMS100_SN06_DEL_CLI
- A_NT-DMS100_SN06_DEL_CNAB

- A_NT-DMS100_SN06_DEL_CNAMD
- A_NT-DMS100_SN06_DEL_CND
- A_NT-DMS100_SN06_DEL_CND-NO-BILL
- A_NT-DMS100_SN06_DEL_CNDB
- A_NT-DMS100_SN06_DEL_CNF
- A_NT-DMS100_SN06_DEL_COD
- A_NT-DMS100_SN06_DEL_COT
- A_NT-DMS100_SN06_DEL_COT-NO-BILL
- A_NT-DMS100_SN06_DEL_CPU
- A_NT-DMS100_SN06_DEL_CSMI
- A_NT-DMS100_SN06_DEL_CUSD
- A_NT-DMS100_SN06_DEL_CWD
- A_NT-DMS100_SN06_DEL_CWI
- A_NT-DMS100_SN06_DEL_CWO
- A_NT-DMS100_SN06_DEL_CWT
- A_NT-DMS100_SN06_DEL_CWX
- A_NT-DMS100_SN06_DEL_CXR
- A_NT-DMS100_SN06_DEL_DCF
- A_NT-DMS100_SN06_DEL_DCPU
- A_NT-DMS100_SN06_DEL_DDN
- A_NT-DMS100_SN06_DEL_DENY
- A_NT-DMS100_SN06_DEL_DENYACB
- A_NT-DMS100_SN06_DEL_DENYAR
- A_NT-DMS100_SN06_DEL_DENYCOT
- A_NT-DMS100_SN06_DEL_DENYCSMI
- A_NT-DMS100_SN06_DEL_DENYISA
- A_NT-DMS100_SN06_DEL_DENYU3WC
- A_NT-DMS100_SN06_DEL_DGT
- A_NT-DMS100_SN06_DEL_DIN
- A_NT-DMS100_SN06_DEL_DISP
- A_NT-DMS100_SN06_DEL_DNH
- A_NT-DMS100_SN06_DEL_DOR
- A_NT-DMS100_SN06_DEL_DQS
- A_NT-DMS100_SN06_DEL_DQT
- A_NT-DMS100_SN06_DEL_DRCW
- A_NT-DMS100_SN06_DEL_DRING

- A_NT-DMS100_SN06_DEL_DSCWID
- A_NT-DMS100_SN06_DEL_DTM
- A_NT-DMS100_SN06_DEL_ELN
- A_NT-DMS100_SN06_DEL_EMW
- A_NT-DMS100_SN06_DEL_ESL
- A_NT-DMS100_SN06_DEL_FAA
- A_NT-DMS100_SN06_DEL_FANI
- A_NT-DMS100_SN06_DEL_FEATURES
- A_NT-DMS100_SN06_DEL_FTRGRP
- A_NT-DMS100_SN06_DEL_GIC
- A_NT-DMS100_SN06_DEL_GND
- A_NT-DMS100_SN06_DEL_HOT
- A_NT-DMS100_SN06_DEL_ICM
- A_NT-DMS100_SN06_DEL_INSPECT
- A_NT-DMS100_SN06_DEL_INT
- A_NT-DMS100_SN06_DEL_INTPIC
- A_NT-DMS100_SN06_DEL_KSH
- A_NT-DMS100_SN06_DEL_LCDR
- A_NT-DMS100_SN06_DEL_LDSA
- A_NT-DMS100_SN06_DEL_LDSO
- A_NT-DMS100_SN06_DEL_LNR
- A_NT-DMS100_SN06_DEL_LNRA
- A_NT-DMS100_SN06_DEL_LOB
- A_NT-DMS100_SN06_DEL_LOD
- A_NT-DMS100_SN06_DEL_LPIC
- A_NT-DMS100_SN06_DEL_LVM
- A_NT-DMS100_SN06_DEL_M518
- A_NT-DMS100_SN06_DEL_M536
- A_NT-DMS100_SN06_DEL_MDN
- A_NT-DMS100_SN06_DEL_MSB
- A_NT-DMS100_SN06_DEL_MSBI
- A_NT-DMS100_SN06_DEL_MWT
- A_NT-DMS100_SN06_DEL_NAME
- A_NT-DMS100_SN06_DEL_NDC
- A_NT-DMS100_SN06_DEL_NFA
- A_NT-DMS100_SN06_DEL_NGTSRVCE

- A_NT-DMS100_SN06_DEL_NLT
- A_NT-DMS100_SN06_DEL_OBS
- A_NT-DMS100_SN06_DEL_ONI
- A_NT-DMS100_SN06_DEL_PIC
- A_NT-DMS100_SN06_DEL_PORT
- A_NT-DMS100_SN06_DEL_PRK
- A_NT-DMS100_SN06_DEL_PRL
- A_NT-DMS100_SN06_DEL_QTD
- A_NT-DMS100_SN06_DEL_RAG
- A_NT-DMS100_SN06_DEL_RCHD
- A_NT-DMS100_SN06_DEL_RMI
- A_NT-DMS100_SN06_DEL_RMR
- A_NT-DMS100_SN06_DEL_RMT
- A_NT-DMS100_SN06_DEL_RPA
- A_NT-DMS100_SN06_DEL_RSP
- A_NT-DMS100_SN06_DEL_RSUS
- A_NT-DMS100_SN06_DEL_SACB
- A_NT-DMS100_SN06_DEL_SC1
- A_NT-DMS100_SN06_DEL_SC2
- A_NT-DMS100_SN06_DEL_SCA
- A_NT-DMS100_SN06_DEL_SCF
- A_NT-DMS100_SN06_DEL_SCL
- A_NT-DMS100_SN06_DEL_SCRJ
- A_NT-DMS100_SN06_DEL_SCS
- A_NT-DMS100_SN06_DEL_SCU
- A_NT-DMS100_SN06_DEL_SCWID
- A_NT-DMS100_SN06_DEL_SDN
- A_NT-DMS100_SN06_DEL_SDSDENY
- A_NT-DMS100_SN06_DEL_SHU
- A_NT-DMS100_SN06_DEL_SL
- A_NT-DMS100_SN06_DEL_SMDR
- A_NT-DMS100_SN06_DEL_SPB
- A_NT-DMS100_SN06_DEL_SRA
- A_NT-DMS100_SN06_DEL_SSAC
- A_NT-DMS100_SN06_DEL_SUPPRESS
- A_NT-DMS100_SN06_DEL_SUPR

- A_NT-DMS100_SN06_DEL_SVCGRP
- A_NT-DMS100_SN06_DEL_TCW
- A_NT-DMS100_SN06_DEL_TDN
- A_NT-DMS100_SN06_DEL_TFO
- A_NT-DMS100_SN06_DEL_UCD
- A_NT-DMS100_SN06_DEL_VMEADENY
- A_NT-DMS100_SN06_DEL_VMEADN
- A_NT-DMS100_SN06_DEL_WML
- A_NT-DMS100_SN06_DEL_WUC
- A_NT-DMS100_SN06_DEL_WUCR

A_NT-DMS100_SN06_DEL_3WC

Removes this option from the assigned line. This option allows the subscriber on the assigned line to place a call on hold. When the call is on hold, the subscriber can set up a request call to another subscriber. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.del3WC.**

Table 220: A_NT-DMS100_SN06_DEL_3WC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
THREE_WAY_CONFERENCE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ACB

Removes this option from the assigned line. The ACB option allows a subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delACB.**

Table 221: A_NT-DMS100_SN06_DEL_ACB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_CALL_BACK_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ACD

Removes this option from the assigned line. ACD allows the subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delACD.**

Table 222: A_NT-DMS100_SN06_DEL_ACD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 222: A_NT-DMS100_SN06_DEL_ACD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_CALL_DISTRIBUTION_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ACDNR

Removes this option from the assigned line. The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delACDNR.**

Table 223: A_NT-DMS100_SN06_DEL_ACDNR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 223: A_NT-DMS100_SN06_DEL_ACDNR

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_NOT_READY_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ACRJ

Removes this option from the assigned line. The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delACRJ.**

Table 224: A_NT-DMS100_SN06_DEL_ACRJ

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
ANONYMOUS_CALLER_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_AIN

Removes this option from the assigned line. The AIN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger

Item interface to subscribe to an AINDN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAIN.**

Table 225: A_NT-DMS100_SN06_DEL_AIN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_ID_GROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_AINDN

Removes this option from the assigned line. Use the Trigger Item interface to subscribe to an AINDN. The AINDN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAINDN.**

Table 226: A_NT-DMS100_SN06_DEL_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 226: A_NT-DMS100_SN06_DEL_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_ID_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_AMSGDENY

Removes this option from the assigned line. AMSGDENY prevents the line from receiving access from a messaging service. The operating company assigns the AMSGDENY option. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAMSGDENY.**

Table 227: A_NT-DMS100_SN06_DEL_AMSGDENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_AR

Removes this option from the assigned line. The AR option allows a subscriber to call the last station that called the subscriber. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAR.**

Table 228: A_NT-DMS100_SN06_DEL_AR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_RECALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ARDDN

Removes this option from the assigned line. The ARDDN option allows subscribers to dial a feature code that sets up a call to the directory number (DN) where the subscriber placed the last incoming call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delARDDN.**

Table 229: A_NT-DMS100_SN06_DEL_ARDDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 229: A_NT-DMS100_SN06_DEL_ARDDN

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_RECALL_DIALABLE_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ASL

Removes this option from the assigned line. The ASL option allows a supervisor to monitor the status of an agent position. This process does not interfere with the call. The lamp for the assigned agent status key reflects the status of the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delASL.**

Table 230: A_NT-DMS100_SN06_DEL_ASL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 230: A_NT-DMS100_SN06_DEL_ASL

Parameter Name	Description	Range	Default Value	Type	Class
AGENT_STATUS_LAMP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_AUD

Removes this option from the assigned line. The AUD option allows a business set subscriber to call a number the subscriber dials frequently. The subscriber presses the AUD key to call this number. The subscriber can program and change this number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAUD.**

Table 231: A_NT-DMS100_SN06_DEL_AUD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_DIAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_AUL

Removes this option from the assigned line. The automatic line (AUL) option connects to a set location when a directory number (DN) or an assigned AUL option line reports an off-hook. It

is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAUL.**

Table 232: A_NT-DMS100_SN06_DEL_AUL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_AUTODISP

Removes this option from the assigned line. The automatic display (AUTODISP) option automatically shows information on incoming calls to a Meridian business set (MBS). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delAUTODISP.**

Table 233: A_NT-DMS100_SN06_DEL_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 233: A_NT-DMS100_SN06_DEL_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
AUTOMATIC_DISPLAY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CBE

Removes the CBE option. The Call Forwarding Busy Internal Calls Only (CBE) option allows the subscriber to stop the system when the system forwards external calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCBE.**

Table 234: A_NT-DMS100_SN06_DEL_CBE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 234: A_NT-DMS100_SN06_DEL_CBE

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_INTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CBU

Removes this option from the assigned line. The CBU option allows Call Forwarding Busy calls to forward to remote stations outside and inside the customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCBU.**

Table 235: A_NT-DMS100_SN06_DEL_CBU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_CCW

Removes this option from the assigned line. The Cancel Call Waiting (CCW) option allows Call Waiting (CWT) subscribers to turn off the CWT option. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCCW.**

Table 236: A_NT-DMS100_SN06_DEL_CCW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CANCEL_CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CDE

Removes this option from the assigned line. The CDE option prevents the forwarding of calls from outside the customer group. This option ensures that external calls do not flood the remote station when many of the incoming calls are external. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCDE.**

Table 237: A_NT-DMS100_SN06_DEL_CDE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 237: A_NT-DMS100_SN06_DEL_CDE

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_EXCLUDE_EXTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CDI

Removes this option from the assigned line. The CDI option prevents the forwarding of intragroup calls. The CDI makes sure that intragroup calls do not flood the remote station. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCDI.**

Table 238: A_NT-DMS100_SN06_DEL_CDI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 238: A_NT-DMS100_SN06_DEL_CDI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_EXCLUDE_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CDU

Removes this option from the assigned line. The CDU option allows the system to forward all calls that are not answered to a remote station that is outside or inside customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCDU.**

Table 239: A_NT-DMS100_SN06_DEL_CDU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_CFB

Removes this option from the assigned line. The CFB option allows the system to forward all calls to a busy station to a station determined earlier. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFB.**

Table 240: A_NT-DMS100_SN06_DEL_CFB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFBL

Removes this option from the assigned line. The CFBL option allows the subscriber to specify a directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFBL.**

Table 241: A_NT-DMS100_SN06_DEL_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 241: A_NT-DMS100_SN06_DEL_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CFD

Removes this option from the assigned line. The CFD option allows the system to forward incoming calls that are not answered in a specified time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFD.**

Table 242: A_NT-DMS100_SN06_DEL_CFD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFDA

Removes this option from the assigned line. The Call Forwarding Do Not Answer (CFDA) Residential option forwards calls not answered to stations in the same customer group. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFDA.**

Table 243: A_NT-DMS100_SN06_DEL_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CFDVT

Removes this option from the assigned line. The Call Forwarding Do Not Answer Variable Timer (CFDVT) option allows an end-user to specify how long a call rings before the system forwards the call to another station. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFDVT.**

Table 244: A_NT-DMS100_SN06_DEL_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 244: A_NT-DMS100_SN06_DEL_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
CALL_FORWARD_NO_ANSWER_VAR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFF

Removes this option from the assigned line. The CFF option allows the station to forward calls to a location the operating company enters. The user cannot program the number to which the station forwards the calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFF.**

Table 245: A_NT-DMS100_SN06_DEL_CFF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_FIXED_CFFDN	Call forwarding DN for CFF option.			S	O
CALL_FORWARD_FIXED_OPTION	Enter the value to CFFA to set it to active.			S	O

A_NT-DMS100_SN06_DEL_CFGD

Removes this option from the assigned line. The CFGD option allows the user to assign call forwarding do not answer to separate Hunt groups. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFGD.**

Table 246: A_NT-DMS100_SN06_DEL_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFGDA

Removes this option from the assigned line. The CFGDA option allows the system administrator to assign call forwarding to a Hunt group. The system forwards the calls to a DN outside the Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFGDA.**

Table 247: A_NT-DMS100_SN06_DEL_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 247: A_NT-DMS100_SN06_DEL_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CFI

Removes this option from the assigned line. The CFI option allows stations to forward calls only to locations in the customer group that the customer defines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFI.**

Table 248: A_NT-DMS100_SN06_DEL_CFI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_INTRAGROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFMDN

Removes this option from the assigned line. The Call Forwarding MADN Secondary Number (CFMDN) option lets secondary units of a multiple appearance directory number (MADN) group, activate call forwarding (CFF, CFU and CFI only) from a station. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFMDN.**

Table 249: A_NT-DMS100_SN06_DEL_CFMDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_MADN_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFRA

Removes this option from the assigned line. The Call Forwarding Remote Access (CFRA) option allows a single-line set to use a line other than its own. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFRA.**

Table 250: A_NT-DMS100_SN06_DEL_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 250: A_NT-DMS100_SN06_DEL_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_REMOTE_ACTIVATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFS

Removes this option from the assigned line. The Call Forwarding Simultaneous/Screening (CFS) option allows the user to call forward more than one call through a station at a time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFS.**

Table 251: A_NT-DMS100_SN06_DEL_CFS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 251: A_NT-DMS100_SN06_DEL_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFU

Removes this option from the assigned line. The CFU option allows a station user to reroute incoming calls to another telephone number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFU.**

Table 252: A_NT-DMS100_SN06_DEL_CFU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_UNIVERSAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CFW

Removes this option from the assigned line. The CFW option allows the user to forward calls to another location. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCFW.**

Table 253: A_NT-DMS100_SN06_DEL_CFW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CHD

Removes this option from the assigned line. The Call Hold (CHD) option allows a subscriber with a 500/2500 set to hold a call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCHD.**

Table 254: A_NT-DMS100_SN06_DEL_CHD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 254: A_NT-DMS100_SN06_DEL_CHD

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CIF

Removes this option from the assigned line. The Controlled Interflow (CIF) option allows a supervisor to place an automatic call distribution (ACD) group in a controlled interflow mode. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCIF.**

Table 255: A_NT-DMS100_SN06_DEL_CIF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CONTROLLED_INTERFLOW_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CIR

Removes this option from the assigned line. The Circular Hunt (CIR) option allows hunting to complete a full cycle through a Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCIR.**

Table 256: A_NT-DMS100_SN06_DEL_CIR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CIRCULAR_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CLF

Removes this option from the assigned line. The Calling Line Identification with Flash (CLF) option allows a subscriber to hold an incoming call in the switch. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCLF.**

Table 257: A_NT-DMS100_SN06_DEL_CLF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 257: A_NT-DMS100_SN06_DEL_CLF

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CLI

Removes this option from the assigned line. Local and toll calls can stop on the line of the subscriber. If the calls stop, the Calling Line Identification (CLI) option records the following information on the DMS log system. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCLI.**

Table 258: A_NT-DMS100_SN06_DEL_CLI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRACE_CLI_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CNAB

Removes this option from the assigned line. The CNAB option allows the system to block the delivery of the name of the caller. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCNAB.**

Table 259: A_NT-DMS100_SN06_DEL_CNAB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CNAMD

Removes this option from the assigned line. The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCNAMD.**

Table 260: A_NT-DMS100_SN06_DEL_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 260: A_NT-DMS100_SN06_DEL_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALLER_ID_NAME_DELIVERY_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_CND

Removes this option from the assigned line. The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is enabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCND.**

Table 261: A_NT-DMS100_SN06_DEL_CND

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CND-NO-BILL

Removes this option from the assigned line. The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and

date of the call. The billing option is disabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCNDNoBill.**

Table 262: A_NT-DMS100_SN06_DEL_CND-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CNDB

Removes this option from the assigned line. The Calling Number Delivery Blocking (CNDB) option blocks the delivery of the calling number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCNDB.**

Table 263: A_NT-DMS100_SN06_DEL_CNDB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 263: A_NT-DMS100_SN06_DEL_CNDB

Parameter Name	Description	Range	Default Value	Type	Class
CALLING_NUMBER_DELIVERY_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CNF

Removes this option from the assigned line. The Station Controlled Conference (CNF) option allows a station to have a conference call to a maximum of 30 parties. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCNF.**

Table 264: A_NT-DMS100_SN06_DEL_CNF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_CONTROLLED_CONFERENCE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_COD

Removes this option from the assigned line. The Cutoff on Disconnect (COD) option applies an open battery signal to the line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCOD.**

Table 265: A_NT-DMS100_SN06_DEL_COD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_COT

Removes this option from the assigned line. The COT option allows the recipient of a harassing call to request an automatic trace of the call. The billing option enabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCOT.**

Table 266: A_NT-DMS100_SN06_DEL_COT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 266: A_NT-DMS100_SN06_DEL_COT

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRACER_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_COT-NO-BILL

Removes this option from the assigned line. The COT option allows the recipient of a harassing call to request an automatic trace of the call. The billing option disabled. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCOTNoBill.**

Table 267: A_NT-DMS100_SN06_DEL_COT-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRACER_NO_ BILL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CPU

Removes this option from the assigned line. The Call Pickup (CPU) option allows a station to answer incoming calls to another station in the same pickup group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCPU.**

Table 268: A_NT-DMS100_SN06_DEL_CPU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_PICKUP_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CSMI

Removes this option from the assigned line. The CSMI feature allows end users of Network Based Answering Services (NBAS) to monitor and intercept calls that the NBAS handles. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCSMI.**

Table 269: A_NT-DMS100_SN06_DEL_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 269: A_NT-DMS100_SN06_DEL_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_SCREENING_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	O

A_NT-DMS100_SN06_DEL_CUSD

Removes this option from the assigned line. The Call Forwarding Usage Sensitive Denial (CUSD) option prevents the use of the POTS Call Forwarding Usage Sensitive Pricing (CFUSP) option. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCUSD.**

Table 270: A_NT-DMS100_SN06_DEL_CUSD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_CWD

Removes this option from the assigned line. The Dial CallWaiting (CWD) option allows a business set user to impose call waiting on a busy station. The busy station can be a 500/2500 set or a business set with a call waiting (CWT) feature key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCWD.**

Table 271: A_NT-DMS100_SN06_DEL_CWD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DIAL_CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CWI

Removes this option from the assigned line. The Call Waiting Intragroup (CWI) option allows a subscriber to apply the CWT option to intragroup calls, in addition to those allowed with CWT. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCWI.**

Table 272: A_NT-DMS100_SN06_DEL_CWI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 272: A_NT-DMS100_SN06_DEL_CWI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_INTRAGROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CWO

Removes this option from the assigned line. The Call Waiting Originating (CWO) option allows an originating line to impose a call waiting tone automatically on a busy called line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCWO.**

Table 273: A_NT-DMS100_SN06_DEL_CWO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 273: A_NT-DMS100_SN06_DEL_CWO

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_ORIGINATING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CWT

Removes this option from the assigned line. The Call Waiting (CWT) option allows the system to alert a busy station when an incoming call attempts to reach the directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCWT.**

Table 274: A_NT-DMS100_SN06_DEL_CWT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CWX

Removes this option from the assigned line. The Call Waiting Exempt (CWX) option does not allow Dial Call Waiting (CWD) and Call Waiting Originating (CWO) to interrupt a business

set user. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCWX.**

Table 275: A_NT-DMS100_SN06_DEL_CWX

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_WAITING_EXEMPT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_CXR

Removes this option from the assigned line. The call transfer (CXR) option allows the assignment of a call transfer type other than the type that the customer group has. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delCXR.**

Table 276: A_NT-DMS100_SN06_DEL_CXR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 276: A_NT-DMS100_SN06_DEL_CXR

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_TRANSFER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DCF

Removes this option from the assigned line. The Denied Call Forwarding (DCF) option does not allow a line to receive forwarded calls. This security option helps to protect computer ports. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDCF.**

Table 277: A_NT-DMS100_SN06_DEL_DCF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 277: A_NT-DMS100_SN06_DEL_DCF

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_CALL_FORWARDING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DCPU

Removes this option from the assigned line. The DCPU option allows a station to answer a ringing line in the same customer group before the called party answers the ringing line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDCPU.**

Table 278: A_NT-DMS100_SN06_DEL_DCPU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DDN

Removes this option from the assigned line. The Dialable Directory Number (DDN) option allows the customer premises equipment (CPE) to display incoming calling name, number,

and the time and date of the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDDN.**

Table 279: A_NT-DMS100_SN06_DEL_DDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DENY

Removes this option from the assigned line. The DENY option prevents individual lines from gaining access to particular Custom Local Area Signaling Services (CLASS) features that are available using Universal Access (UA). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENY.**

Table 280: A_NT-DMS100_SN06_DEL_DENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 280: A_NT-DMS100_SN06_DEL_DENY

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
DENY_ACCESS_CLASS_FEATURES_DENYOPT	Specifies the CLASS option to deny on switches.			C	R

A_NT-DMS100_SN06_DEL_DENYACB

Removes this option from the assigned line. The DENYACB option prevents the use of the automatic call return feature. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENYACB.**

Table 281: A_NT-DMS100_SN06_DEL_DENYACB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DENYAR

Removes this option from the assigned line. The DENYAR option prevents individual lines from gaining access to the automatic recall feature that is available using Universal Access

(UA). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENYAR.**

Table 282: A_NT-DMS100_SN06_DEL_DENYAR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DENYCOT

Removes this option from the assigned line. The DENYCOT option prevents the use of the incoming call tracing feature. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENYCOT.**

Table 283: A_NT-DMS100_SN06_DEL_DENYCOT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DENYCSMI

Removes this option from the assigned line. The DENYCSMI feature prevents a user from activating the CSMI option (Call Screening, Monitoring and Intercept) on certain types of call forward. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENYCSMI.**

Table 284: A_NT-DMS100_SN06_DEL_DENYCSMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DENYISA

Removes this option from the assigned line. The DENYISA feature allows an ISA (In-Session Activation) subscriber to deactivate the ISA feature for each call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENYISA.**

Table 285: A_NT-DMS100_SN06_DEL_DENYISA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 285: A_NT-DMS100_SN06_DEL_DENYISA

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_IN_SESSION_ACTIVATION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_DENYU3WC

Removes this option from the assigned line. The DENYU3WC option prevents the use of the U3WC feature when U3WC is applied to a RES line or POTS line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDENYU3WC.**

Table 286: A_NT-DMS100_SN06_DEL_DENYU3WC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DGT

Removes this option from the assigned line. The DGT option allows a telephone set to generate an address in the form of dual-tone multi-frequency signals. It is implemented by the

Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDGT.

Table 287: A_NT-DMS100_SN06_DEL_DGT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DIN

Removes this option from the assigned line. The DIN option prevents selected lines from receiving incoming calls that originate outside the customer group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDIN.**

Table 288: A_NT-DMS100_SN06_DEL_DIN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 288: A_NT-DMS100_SN06_DEL_DIN

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_INCOMING_CALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DISP

Removes this option from the assigned line. The Display (DISP) option indicates that a business set on a PSET line is a display business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDISP.**

Table 289: A_NT-DMS100_SN06_DEL_DISP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DNH

Removes this option from the assigned line. The Directory Number Hunt (DNH) option allows directory number hunting. Each line in the Hunt group has a directory number (DN). It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDNH.**

Table 290: A_NT-DMS100_SN06_DEL_DNH

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DIRECTORY_NUMBER_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DOR

Removes this option from the assigned line. The Denied Origination (DOR) option prevents a line from originating calls. If the user attempts to originate a call from that line, the call receives originating suspended service (ORSS) treatment. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDOR.**

Table 291: A_NT-DMS100_SN06_DEL_DOR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 291: A_NT-DMS100_SN06_DEL_DOR

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_ORIGINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DQS

Removes this option from the assigned line. The Display Queue Status (DQS) option allows an ACD supervisor to display the load status information for an ACD group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDQS.**

Table 292: A_NT-DMS100_SN06_DEL_DQS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 292: A_NT-DMS100_SN06_DEL_DQS

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_STATUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DQT

Removes this option from the assigned line. The Display Queue Threshold (DQT) option allows the system to display the status of the incoming call queue. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDQT.**

Table 293: A_NT-DMS100_SN06_DEL_DQT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DISPLAY_QUEUE_THRESHOLD_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DRCW

Removes this option from the assigned line. The Distinctive Ringing/Call Waiting (DRCW) option allows the system to identify terminating calls with a distinct alert pattern. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDRCW.**

Table 294: A_NT-DMS100_SN06_DEL_DRCW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DRING

Removes this option from the assigned line. The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDRING.**

Table 295: A_NT-DMS100_SN06_DEL_DRING

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 295: A_NT-DMS100_SN06_DEL_DRING

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
DISTINCTIVE_RING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_DSCWID

Removes this option from the assigned line. Deluxe Spontaneous Call Waiting Identification (DSCWID) allows the subscriber to receive calling-party information during call waiting. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDSCWID.**

Table 296: A_NT-DMS100_SN06_DEL_DSCWID

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_DTM

Removes this option from the assigned line. The DTM option prevents a line from receiving calls. Calls that attempt to terminate to a line with the DTM option receive denied terminating

(DNTR) treatment. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delDTM.**

Table 297: A_NT-DMS100_SN06_DEL_DTM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_TERMINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ELN

Removes this option from the assigned line. The essential line (ELN) option designates a line as essential. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delELN.**

Table 298: A_NT-DMS100_SN06_DEL_ELN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 298: A_NT-DMS100_SN06_DEL_ELN

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
ESSENTIAL_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_EMW

Removes this option from the assigned line. The Executive MessageWaiting (EMW) option introduces a message waiting class of service (MCOS) to enhance the message waiting option. A user can only access the MCOS to which the user subscribes. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delEMW.**

Table 299: A_NT-DMS100_SN06_DEL_EMW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
EXECUTIVE_MESSAGE_WAIT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ESL

Removes this option from the assigned line. The Emergency Service Line (ESL) allows a line for emergency service to be designated. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delESL.**

Table 300: A_NT-DMS100_SN06_DEL_ESL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_FAA

Removes this option from the assigned line. The Forced Agent Availability (FAA) option allows an ACD (Automatic Call Distribution) supervisor to force an ACD agent from the Not Ready to the Ready state. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delFAA.**

Table 301: A_NT-DMS100_SN06_DEL_FAA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 301: A_NT-DMS100_SN06_DEL_FAA

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FORCED_AGENT_AVAILABILITY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_FANI

Removes this option from the assigned line. The Flexible Automatic Number ID (FANI) option allows an operating company to assign special-purpose Automatic Number Identification (ANI) information digits to a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delFANI.**

Table 302: A_NT-DMS100_SN06_DEL_FANI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_FEATURES

Deletes options from assigned single line and multi-line telephone sets, from Hunt group lines, and from proprietary business sets. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLineFeatures.**

Table 303: A_NT-DMS100_SN06_DEL_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OPT	Options associated with a service your are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	A flag to indicate MML optimization of the command.	true or false	true	S	O

A_NT-DMS100_SN06_DEL_FTRGRP

Removes this option from the assigned line. The FTRGRP option allows the operating company to define a number of features as a feature group. The feature group can be assigned to customer lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delFTRGRP.**

Table 304: A_NT-DMS100_SN06_DEL_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
FEATURE_GROUP_ OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_GIC

Removes this option from the assigned line. The GIC option allows call termination on a member of a designated intercom group that uses abbreviated dialing. Use abbreviated dialing to access group members. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delGIC.**

Table 305: A_NT-DMS100_SN06_DEL_GIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 305: A_NT-DMS100_SN06_DEL_GIC

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
GROUP_INTERCOM _OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_GND

Removes this option from the assigned line. The GND option assigns ground signal to the line and allow consistency to be checked on ground start lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delGND.**

Table 306: A_NT-DMS100_SN06_DEL_GND

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_HOT

Removes this option from the assigned line. This feature is placed on lines in hotel or motel. It allows the hotel to bill each room for call charges. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delHOT.**

Table 307: A_NT-DMS100_SN06_DEL_HOT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_ICM

Removes this option from the assigned line. The ICM option allows a business set user to directly terminate upon a predesignated business set by pressing the ICM feature key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delICM.**

Table 308: A_NT-DMS100_SN06_DEL_ICM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 308: A_NT-DMS100_SN06_DEL_ICM

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTERCOM_BUSINESS_SET_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_INSPECT

Removes this option from the assigned line. The INSPECT option displays the information on feature/DN keys and incoming calls to a DN. This option also provides information on the Call Waiting key and Intercom key without answering the call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delINSPECT.**

Table 309: A_NT-DMS100_SN06_DEL_INSPECT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INSPECT_KEY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_INT

Removes this option from the assigned line. The Intercom (INT) option allows the subscriber to dial an access code and ring all the extensions of that DN. The subscriber can speak to any individuals who answer these extensions. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delINT.**

Table 310: A_NT-DMS100_SN06_DEL_INT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_INTPIC

Removes this option from the assigned line. Line option INTPIC allows subscribers of Equal End Offices (EQEO) to designate a carrier for international calls. This option is valid for POTS, COIN, RES, IBN and KSET lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delINTPIC.**

Table 311: A_NT-DMS100_SN06_DEL_INTPIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 311: A_NT-DMS100_SN06_DEL_INTPIC

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTL_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_KSH

Removes this option from the assigned line. The Key Short Hunt (KSH) option allows incoming calls to search for an idle directory number (DN) on which to terminate. The options search for this DN occurs through a set of DN appearances on a business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delKSH.**

Table 312: A_NT-DMS100_SN06_DEL_KSH

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
KEY_SHORT_HUNT _OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LCDR

Removes this option from the assigned line. The Local Call Detail Recording (LCDR) option allows billing for local calls to correspond to conversation time. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLCDR.**

Table 313: A_NT-DMS100_SN06_DEL_LCDR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LOCAL_CALL_DETAILED_REPORTING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LDSA

Removes this option from the assigned line. The Long Distance Signal Activation (LDSA) option allows the subscriber to activate or deactivate long distance alerting. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLDSA.**

Table 314: A_NT-DMS100_SN06_DEL_LDSA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 314: A_NT-DMS100_SN06_DEL_LDSA

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_LDSO

Removes this option from the assigned line. The Long Distance Signal Option (LDSO) option allows long distance alerting to subscribers with different ring and tone. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLDSO.**

Table 315: A_NT-DMS100_SN06_DEL_LDSO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_LNR

Removes this option from the assigned line. The LNR option allows a subscriber to redial the last number dialed. The subscriber uses a single key instead of the full number to redial the last

number dialed. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLNR.**

Table 316: A_NT-DMS100_SN06_DEL_LNR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LAST_NUMBER_REDIAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LNRA

Removes this option from the assigned line. The Last Number Redial Associated with Set (LNRA) option allows a set to access any free Directory Number (DN) on the set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLNRA.**

Table 317: A_NT-DMS100_SN06_DEL_LNRA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 317: A_NT-DMS100_SN06_DEL_LNRA

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LAST_NUMBER_REDIAL_ASSOCIATED_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LOB

Removes this option from the assigned line. The Line of Business (LOB) option allows an Automatic Call Distribution (ACD) agent to enter a three-digit code for each call. Entering the code pegs a register for that LOB or type of call. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLOB.**

Table 318: A_NT-DMS100_SN06_DEL_LOB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 318: A_NT-DMS100_SN06_DEL_LOB

Parameter Name	Description	Range	Default Value	Type	Class
LINE_OF_BUSINESS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LOD

Removes this option from the assigned line. The Line Overflow to Directory Number (LOD) option enables a call to be routed to a specified DN. This action occurs when all lines in a Hunt group are busy. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLOD.**

Table 319: A_NT-DMS100_SN06_DEL_LOD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_FORWARD_BUSY_OVERFLOW_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LPIC

Removes this option from the assigned line. The Intra-LATA PIC (LPIC) option allows the user to choose a primary carrier for Intra-LATA services. The LCHOICE field allows

subscribers to dial Intra-LATA calls on a casual basis. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLPIC.**

Table 320: A_NT-DMS100_SN06_DEL_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTRA_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_LVM

Removes this option from the assigned line. The Leave Message (LVM) option provides key access to message waiting (MWT), call request (CAR), and executive message waiting (EMW). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delLVM.**

Table 321: A_NT-DMS100_SN06_DEL_LVM

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 321: A_NT-DMS100_SN06_DEL_LVM

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LEAVE_MESSAGE_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_M518

Removes this option from the assigned line. The 18-Button Add-On for Meridian M5000 Series (M518) option allows the addition of an 18-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delM518.**

Table 322: A_NT-DMS100_SN06_DEL_M518

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 322: A_NT-DMS100_SN06_DEL_M518

Parameter Name	Description	Range	Default Value	Type	Class
M518_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_M536

Removes this option from the assigned line. The 36-Button Add-On for Meridian M5000 Series (M536) option allows the addition of a 36-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delM536.**

Table 323: A_NT-DMS100_SN06_DEL_M536

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
M536_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_MDN

Removes this option from the assigned line. The MDN option assigns a DN to more than one set. A multiple appearance directory number (MADN) is a directory number (DN) hat appears

on more than one Meridian business set (MBS). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delMDN.**

Table 324: A_NT-DMS100_SN06_DEL_MDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MULTIPLE_APPEARANCE_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_MSB

Removes this option from the assigned line. The MSB option allows each IBN station to appear busy to incoming calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delMSB.**

Table 325: A_NT-DMS100_SN06_DEL_MSB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 325: A_NT-DMS100_SN06_DEL_MSB

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MAKE_SET_BUSY_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_MSBI

Removes this option from the assigned line. The Make Set Busy Intragroup (MSBI) option allows each IBN station to appear busy to incoming calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delMSBI.**

Table 326: A_NT-DMS100_SN06_DEL_MSBI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MAKE_SET_BUSY_I NTRAGROUP_OPTK EY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_MWT

Removes this option from the assigned line. The MWT option allows a message center to inform a user that there is a message. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delMWT.**

Table 327: A_NT-DMS100_SN06_DEL_MWT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
MESSAGE_WAITING_INDICATOR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_NAME

Removes this option from the assigned line. The system uses NAME feature to assign a name to DN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delNAME.**

Table 328: A_NT-DMS100_SN06_DEL_NAME

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 328: A_NT-DMS100_SN06_DEL_NAME

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NAME_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_NDC

Removes this option from the assigned line. The No Double Connect (NDC) option prevents a line from being connected to a verification or test circuit when the line is off-hook. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delNDC.**

Table 329: A_NT-DMS100_SN06_DEL_NDC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NO_DOUBLE_CONNECT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_NFA

Removes this option from the assigned line. The Network Facility Access (NFA) option provides a direct access to the services of an Intelligent Processor (IP) through the DMS100 switch. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delNFA.**

Table 330: A_NT-DMS100_SN06_DEL_NFA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NETWORK_FACILITY_ACCESS_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	O

A_NT-DMS100_SN06_DEL_NGTSRVCE

Removes this option from the assigned line. The Night Service (NGTSRVCE) option allows the ACD supervisor to place all ACD agent sets in an ACD group in night service mode. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delNGTSRVCE.**

Table 331: A_NT-DMS100_SN06_DEL_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 331: A_NT-DMS100_SN06_DEL_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
NIGHT_SERVICE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_NLT

Removes this option from the assigned line. The No Line Insulation Test (NLT) option allows the automatic line insulation test to skip a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delNLT.**

Table 332: A_NT-DMS100_SN06_DEL_NLT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 332: A_NT-DMS100_SN06_DEL_NLT

Parameter Name	Description	Range	Default Value	Type	Class
NO_LINE_INSULATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_OBS

Removes this option from the assigned line. The Observe Agent (OBS) option allows a supervisor to observe conversations between an agent and a caller. This user presses the OBS key to observe conversations between an agent and a caller. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delOBS.**

Table 333: A_NT-DMS100_SN06_DEL_OBS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OBSERVE_AGENT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_ONI

Removes this option from the assigned line. The Operator Number Identification (ONI) option directs calls to an operator for the identification of the calling number when the switch cannot

find this information. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delONI.**

Table 334: A_NT-DMS100_SN06_DEL_ONI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OPERATOR_NUMBER_IDENTIFICATION_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	O

A_NT-DMS100_SN06_DEL_PIC

Removes this option from the assigned line. Option Primary Inter-LATA Carrier (PIC) assigns a PIC to a MDC line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delPIC.**

Table 335: A_NT-DMS100_SN06_DEL_PIC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 335: A_NT-DMS100_SN06_DEL_PIC

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
INTER_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_PORT

Removes this option from the assigned line. The PORT option allows ten-digit complete LNP triggering for a directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delPORT.**

Table 336: A_NT-DMS100_SN06_DEL_PORT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LOCAL_NUMBER_PORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_PRK

Removes this option from the assigned line. The PRK option allows a business set user to park a call against the user's DN. Retrieval of the parked call can occur from any station. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delPRK.**

Table 337: A_NT-DMS100_SN06_DEL_PRK

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
CALL_PARK_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_PRL

Removes this option from the assigned line. The PRL option is available to single call announcement (SCA) MADN users. The PRL option allows users to establish a conference call between an outside number and a maximum of 30 MADN lines. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delPRL.**

Table 338: A_NT-DMS100_SN06_DEL_PRL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 338: A_NT-DMS100_SN06_DEL_PRL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
PRIVACY_RELEASE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_QTD

Removes this option from the assigned line. The QTD option allows a display business set to display the current time and date. The user presses the QTD key and the current time and date display for 15 seconds. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delQTD.**

Table 339: A_NT-DMS100_SN06_DEL_QTD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 339: A_NT-DMS100_SN06_DEL_QTD

Parameter Name	Description	Range	Default Value	Type	Class
QUERY_TIME_DATE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_RAG

Removes the RAG option from the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRAG.**

Table 340: A_NT-DMS100_SN06_DEL_RAG

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
RING_AGAIN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_RCHD

Removes this option from the assigned line. The RCHD option allows a subscriber to place a call on hold for up to three minutes. The call can be one that the subscriber originated or one

that the subscriber received. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRCHD.**

Table 341: A_NT-DMS100_SN06_DEL_RCHD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_RMI

Removes this option from the assigned line. The RMI option allows the subscribers of the message waiting indicator feature to check for the existence of messages in their voice mail box from a remote location. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRMI.**

Table 342: A_NT-DMS100_SN06_DEL_RMI

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 342: A_NT-DMS100_SN06_DEL_RMI

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
REMOTE_MESSAGE_INDICATOR_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_RMR

Removes this option from the assigned line. The RMR option is assigned to lines that are equipped with a remote hardware message register activated by reverse battery. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRMR.**

Table 343: A_NT-DMS100_SN06_DEL_RMR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_RMT

Removes this option from the assigned line. The RMT option is assigned to lines that are equipped with a remote hardware message register activated by reverse battery. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRMT.**

Table 344: A_NT-DMS100_SN06_DEL_RMT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_RPA

Removes this option from the assigned line. The RPA option allows up to seven additional alert tones to a business set when a call terminates on a DN, MADN, GIC, or ACD key and the set is already active on another key. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRPA.**

Table 345: A_NT-DMS100_SN06_DEL_RPA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 345: A_NT-DMS100_SN06_DEL_RPA

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
REPEATED_ALERT_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_RSP

Removes this option from the assigned line. The RSP option is assigned to lines that have LCCs of ZMD or ZMZPA. This option causes the ANI information digit 7 (coinless pay station identification) plus the calling party's DN to be outpulsed. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRSP.**

Table 346: A_NT-DMS100_SN06_DEL_RSP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
RESTRICTED_SENT_ PAID_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_RSUS

Removes this option from the assigned line. The RSUS option is assigned when the subscriber requests the suspension of service. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delRSUS.**

Table 347: A_NT-DMS100_SN06_DEL_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
REQUESTED_SUSPENSION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SACB

Removes this option from the assigned line. The SACB option allows a subscriber to control originations from the line by identifying call classes that restrict completion to certain dialed numbers without a personal identification number (PIN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSACB.**

Table 348: A_NT-DMS100_SN06_DEL_SACB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 348: A_NT-DMS100_SN06_DEL_SACB

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SUB_ACT_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SC1

Removes this option from the assigned line. The SC1 option allows a customer to specify a list of up to eight frequently called numbers. These numbers can be called by dialing the digits 2-9. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSC1.**

Table 349: A_NT-DMS100_SN06_DEL_SC1

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_SC2

Removes this option from the assigned line. The SC2 option allows a customer to specify a list of up to 30 frequently called numbers. These numbers can be called by dialing 20-49. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSC2.**

Table 350: A_NT-DMS100_SN06_DEL_SC2

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_SCA

Removes this option from the assigned line. The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCA.**

Table 351: A_NT-DMS100_SN06_DEL_SCA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 351: A_NT-DMS100_SN06_DEL_SCA

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
SELECTIVE_CALL_ACCEPTANCE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SCF

Removes this option from the assigned line. The SCF option allows calls that terminate on the line to be forwarded to a remote destination if the number of the originating station matches one of the numbers in the SCF list. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCF.**

Table 352: A_NT-DMS100_SN06_DEL_SCF

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SELECTIVE_CALL_FORWARDING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SCL

Removes this option from the assigned line. The SCL option allows a customer to specify a list of frequently called numbers that can be called by dialing a two-digit speed calling code

instead of the complete number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCL.**

Table 353: A_NT-DMS100_SN06_DEL_SCL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPEED_CALLING_LONG_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SCRJ

Removes this option from the assigned line. The SCRJ option allows a subscriber to selectively reject calls that arrive from a limited set of previously identified DNs. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCRJ.**

Table 354: A_NT-DMS100_SN06_DEL_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 354: A_NT-DMS100_SN06_DEL_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SELECTIVE_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SCS

Removes this option from the assigned line. The SCS option allows a customer to specify a list of frequently called numbers that the customer can call by dialing a one-digit speed calling code instead of the complete number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCS.**

Table 355: A_NT-DMS100_SN06_DEL_SCS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPEED_CALLING_SHORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SCU

Removes this option from the assigned line. The SCU option allows a line to be designated as a speed calling user in a speed calling group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCU.**

Table 356: A_NT-DMS100_SN06_DEL_SCU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SPEED_CALLING_USER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_SCWID

Removes this option from the assigned line. The SCWID option allows subscribers to receive calling party information in conjunction with a call waiting tone. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSCWID.**

Table 357: A_NT-DMS100_SN06_DEL_SCWID

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 357: A_NT-DMS100_SN06_DEL_SCWID

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_SDN

Removes this option from the assigned line. To add a secondary DN to a Teen Service line, the SDN option can be assigned to POTS, RES, or IBN agents. When no SDNs are assigned to the line, adding the SDN option establishes Teen Service. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSDN.**

Table 358: A_NT-DMS100_SN06_DEL_SDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 358: A_NT-DMS100_SN06_DEL_SDN

Parameter Name	Description	Range	Default Value	Type	Class
SECONDARY_DN_DN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_NPA	Secondary NPA.			S	O
SECONDARY_DN_NXX	Secondary NXX.			S	O
SECONDARY_DN_LINE	Secondary LINE.			S	O

A_NT-DMS100_SN06_DEL_SDSDENY

Removes this option from the assigned line. The SDSDENY option prevents the offer of the Enhanced Busy Call Return (EBCR) service to a line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSDSDENY.**

Table 359: A_NT-DMS100_SN06_DEL_SDSDENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 359: A_NT-DMS100_SN06_DEL_SDSDENY

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_BUSY_REPEAT_DIAL_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SHU

Removes this option from the assigned line. The SHU option allows hunting at a line to be canceled when activated. SHU can be assigned to one, several, or all lines in a Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSHU.**

Table 360: A_NT-DMS100_SN06_DEL_SHU

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STOP_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_SL

Removes this option from the assigned line. The SL option allows a line to receive announcements in a secondary language (a language other than the assigned primary language). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSL.**

Table 361: A_NT-DMS100_SN06_DEL_SL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SECONDARY_LANGUAGE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SMDR

Removes the SMDR option, which allows the recording of both billable and nonbillable calls on a per leg call basis. The SMDR system uses the automatic message accounting (AMA) subsystem to collect the call data and record it on a data storage device. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSMDR.**

Table 362: A_NT-DMS100_SN06_DEL_SMDR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 362: A_NT-DMS100_SN06_DEL_SMDR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_MESSAGE_RECORDING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_SPB

Removes this option from the assigned line. The SPB option allow a line number other than the subscriber's line to be used for billing. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSPB.**

Table 363: A_NT-DMS100_SN06_DEL_SPB

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Table 363: A_NT-DMS100_SN06_DEL_SPB

Parameter Name	Description	Range	Default Value	Type	Class
SPECIAL_BILLING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SRA

Removes this option from the assigned line. The Suppressed Ringing Access (SRA) option allows any authorized server to establish a connection to customer's line without applying audible ringing. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSRA.**

Table 364: A_NT-DMS100_SN06_DEL_SRA

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_SSAC

Removes this option from the assigned line. The SSAC option allows a set of numbers, from 2-10 digits, to be dialed from a specific station to record billing information and overriding

station network class of service (NCOS) restrictions. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSSAC.**

Table 365: A_NT-DMS100_SN06_DEL_SSAC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
STATION_SPECIFIC_AUTH_CODES_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_SUPPRESS

Removes this option from the assigned line. The SUPPRESS option allows a party to prevent the display of the directory number (DN) or name at the call destination. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSUPPRESS.**

Table 366: A_NT-DMS100_SN06_DEL_SUPPRESS

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O

Table 366: A_NT-DMS100_SN06_DEL_SUPPRESS

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
ANONYMOUS_CALLER_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_SUPR

Removes this option from the assigned line. The SUPR option establishes an automatic call distribution (ACD) supervisor set when assigned to key 1. This option must be assigned before ACD supervisor options can be assigned to the set. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSUPR.**

Table 367: A_NT-DMS100_SN06_DEL_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SUPERVISOR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_SVCGRP

Removes the SVCGRP option, which allows options CLID (Calling Line Identification Display), NAME (Name Display) and REASDSP (Reason Display), packaged in a service group, to be assigned to a line in a customer group or multiple customer groups. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delSVCGRP.**

Table 368: A_NT-DMS100_SN06_DEL_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
SERVICE_GROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

A_NT-DMS100_SN06_DEL_TCW

Removes the TCW (Talking Call Waiting) option from the assigned line. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delTCW.**

Table 369: A_NT-DMS100_SN06_DEL_TCW

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 369: A_NT-DMS100_SN06_DEL_TCW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_TDN

Removes this option from the assigned line. The TDN option prevents a line from originating toll calls. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delTDN.**

Table 370: A_NT-DMS100_SN06_DEL_TDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

A_NT-DMS100_SN06_DEL_TFO

Removes this option from the assigned line. The TFO options allows an incoming call to attempt to terminate to the first member of the hunt group which appears idle. It is

implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delTFO.**

Table 371: A_NT-DMS100_SN06_DEL_TFO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
TERMINATION_FAULT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_UCD

Removes this option from the assigned line. The UCD option permits calls to be distributed evenly among a number of predetermined sets. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delUCD.**

Table 372: A_NT-DMS100_SN06_DEL_UCD

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 372: A_NT-DMS100_SN06_DEL_UCD

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
UNIFORM_CALL_DISTRIBUTION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_VMEADENY

Removes this option from the assigned line. The VMEADENY option Prevent subscriber's line to have access to voice messaging system VMS using access code *98. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delVMEADENY.**

Table 373: A_NT-DMS100_SN06_DEL_VMEADENY

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
DENY_VOICE_MAIL_EASY_ACCESS_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_VMEADN

Removes this option from the assigned line. The Voice Mail East Access DN (VMEADN) option allows a subscriber's line to access a voice messaging system VMS using access code *98. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delVMEADN.**

Table 374: A_NT-DMS100_SN06_DEL_VMEADN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
VOICE_MAIL_EASY_ACCESS_DN_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_WML

Removes this option from the assigned line. The WML option is assigned to lines that route to a predefined DN if no digits are dialed within a modifiable time-out period. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delWML.**

Table 375: A_NT-DMS100_SN06_DEL_WML

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O

Table 375: A_NT-DMS100_SN06_DEL_WML

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
WARM_LINE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_WUC

Removes this option from the assigned line. The WUC option allows a subscriber to set a time for the phone to ring. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delWUC.**

Table 376: A_NT-DMS100_SN06_DEL_WUC

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
WAKE_UP_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

A_NT-DMS100_SN06_DEL_WUCR

Removes this option from the assigned line. The WUCR option allows a subscriber to set a reminder time for the phone to ring. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsDelFeatProv.delWUCR.**

Table 377: A_NT-DMS100_SN06_DEL_WUCR

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O

Hunt group services

This cartridge provides the following ASDL commands:

- A_NT-DMS100_SN06_ADD_HUNT-GROUP
- A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER
- A_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER
- A_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

A_NT-DMS100_SN06_ADD_HUNT-GROUP

Creates the following types of groups: Directory Number Hunt (DNH), Distributed Line Hunt (DLH), Multi-Line Hunt (MLH), Bridged Night Number (BNN), Simultaneous Ringing (SimRing). It is implemented by the Java method

com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsHuntGrpProv.addLineHuntGroup.

Table 378: A_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The DN of a DNH/PRH group pilot or the DN associated with a DLH/MLH group.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
LCC	The line class code of the service to be established, modified, or deleted.			S	O
LATA	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	O

Table 378: A_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
LTG	Line treatment group member, used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. The LTG is prompted for in conjunction with the LCC. If office parameters are on, a prompt appears. If office parameters are off, no prompt appears.	0-255		S	O
GROUP	Groups beginning with an alphabetic character. Used with the IBN line class code (LCC); Common Language Location Identifier (CLLI) of an IBN customer group. Identifies the customer group for this ACD group.			S	O
SUBGRP	Groups 0 to 7 subgroup numbers of a customer group to which a station or DN belongs.			S	O
NCOS	The network class of service for IBN lines, trunks, or attendant consoles; defines a set of capabilities or restrictions that allows or denies calls.	0-255		S	O
SNPA	The service numbering plan area (area code).			S	O

Table 378: A_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
KEY	The key on a business or data unit.	1 to 68 for business set. 1,2,5, or 7 for data units		S	O
RINGING	The key on a business set assigned with ringing ability.	Y, N		S	O
PTY	Designation of a party with two-party or multiparty service.	T1 to T5 for tip parties and R1 to R5 for ring parties		S	O
RINGCODE	The ringing code input for two-party or multiparty services and the frequency-selective ringing (FSR) with 1FR.	0-5		S	O
GROUPTYPE	Type of the group to establish, delete, and modify.	DNH, DLH, MLH, BNN, SimRing		S	R
HOST_HUNT_TYPE	The type of Hunt group on which your are to establish a BNN Hunt group.	DLH, DNH, MLH		S	O
HOST_DN	Bridged night number (BNN) pilot DN.			S	O
HOST_LEN	The length of a host MLH/DLH group member that is to be associated with the pilot of a BNN Hunt group.			S	O
MEMBER_DN	Member DN (for DNH).			C	O
MEMBER_NPA	Member 3 digit area code.			C	O

Table 378: A_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
MEMBER_NXX	Member First 3 digits of the line number.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_LEN	The member LEN.			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LINE_CLASS	The LCC of a new member added to a Hunt group if the new number LEN is associated with a Meridian 2000 set.			C	O
BNN	Directory number of BNN member associated with DN_BNN. This is the alternate DN associated to a Hunt DN for night service.			C	O
SIMR_PIN	The PIN assigned to the SimRing group. This prompt appears only with the ado, chf, est, new, and newdn commands. The PIN is used for security reasons, when the user tries to access the interface remotely.			S	O

Table 378: A_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
SIMR_STATE	The state (active or inactive) of the SimRing feature on a line. The default state is INACT. This prompt appears only with the chf, est, and newdn commands.			S	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any deo command.			C	O
GROUPSIZE	Hunt group size; the expected maximum size of the Hunt group.	0-1024		S	O
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	Flag to indicate MML optimization of the command.	true, false	true	S	O

A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Adds a Hunt member to an existing Hunt group using the add command. It is implemented by the Java method

com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsHuntGrpProv.addLineHuntGroupMember.

Table 379: A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The DN of a DNH/PRH group pilot or the DN associated with a DLH/MLH group.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
KEY	The key on a business or data unit.	1 to 68 for business set. 1,2,5, or 7 for data units		S	O
GROUPTYPE	Type of the group to establish, delete, modify.	DNH, DLH, MLH, BNN, SimRing		S	R
HOST_HUNT_TYPE	The type of Hunt group on which a BNN Hunt group is to be established.	DLH, DNH, MLH		S	O
MEMBER_DN	Member DN (for DNH).			C	O
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	First 3 digits of the member line number.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O

Table 379: A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
MEMBER_LEN	The Member LEN.			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LINE_CLASS	The LCC of a new member added to a Hunt group if the new number LEN is associated with a Meridian 2000 set.			C	O
BNN	Directory number of the BNN member associated with the DN_BNN. This is the alternate DN associated to a Hunt DN for night service.			C	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any deo command.			C	O
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	Flag to indicate MML optimization of the command.	true, false	true	S	O
GROUPSIZE	Hunt group size; the expected maximum size of the Hunt group.	0-1024		S	O

A_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

Deletes a Hunt member from an existing Hunt group, using the del command. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsHuntGrpProv.delLineHuntGroupMember.**

Table 380: A_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
GROUPTYPE	Type of the group to establish, delete, modify.	DNH, DLH, MLH, SimRing		S	R
DN	The DN of the SimRing group. When the PDN receives a call, all the members of the SimRing group receive simultaneous notification. A SimRing group can have only one PDN. This prompt appears only with the add, est, and del commands.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number. Either LEN or LTID must exist; if both exist, LTID is ignored.			S	O
MEMBER_DN	Member DN (for DNH).			C	O

Table 380: A_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	Member First 3 digits of the line number.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_LEN	The member LEN.			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
INTERCEPT_NAME	Enter the type of intercept. PODN is an LNP treatment that designates a ported-out DN.			S	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

Establishes a new distributed line Hunt group. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsHuntGrpProv.estDlhGroup.**

Table 381: A_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
PILOT_NPA	3 digits area code of pilot DN.			S	R
PILOT_NXX	First 3 digits of the line number of the pilot DN.			S	R

Table 381: A_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
PILOT_LINE	4 digit line extension of the pilot DN.			S	R
PILOT_LEN	The LEN of Hunt group pilot.			S	R
LCC	The line class code of the pilot DN.			S	R
GROUP_SIZE	Hunt group size.			S	R
MEM_LEN	The LEN of the DLH group member.			C	R
CUSTOM	Customer-specific parameter.			C	O

POTS Line Services

This cartridge provides the following ASDL commands:

- A_NT-DMS100_SN06_ADD_LINE
- A_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL
- A_NT-DMS100_SN06_ADD_NEWDN
- A_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL
- A_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL
- A_NT-DMS100_SN06_DEL_LINE
- A_NT-DMS100_SN06_DEL_NEWDN
- A_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL
- A_NT-DMS100_SN06_PLUG-UP_LINE
- A_NT-DMS100_SN06_QRY_CUSTOMER-INFO
- A_NT-DMS100_SN06_QRY_DN
- A_NT-DMS100_SN06_QRY_LEN
- A_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL
- A_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL
- A_NT-DMS100_SN06_RESTORE_LINE
- A_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

- A_NT-DMS100_SN06_SUSPEND_LINE

A_NT-DMS100_SN06_ADD_LINE

Establishes service for single line and multi-line telephone sets that are not assigned. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineProv.addNewLine.**

Table 382: A_NT-DMS100_SN06_ADD_LINE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	7 or 10 digits entered with no spaces or hyphens.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number. Either LEN or LTID must exist. If both exist, LTID is ignored.			S	O
ZONE	OUTWATS zone identification number.			S	O
LTID	Logical terminal identifier.			S	O
LCC	The line class code of the service to be established, modified, or deleted.	1FR, 1MR, 2FR, 4FR, CDF, IBN, ISDNKSET, INW, OWT, PBM, PBX, ZMZPA		S	R

Table 382: A_NT-DMS100_SN06_ADD_LINE

Parameter Name	Description	Range	Default Value	Type	Class
LATA_NAME	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	R
LTG	Line treatment group member, used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. The LTG is prompted for in conjunction with the LCC.	0-255		S	R
PTY	The designation of a party with two-party or multiparty service.	T1 to T5 for tip parties and R1 to R5 for ring parties		S	O
RINGCODE	The ringing code input for two-party or multiparty services and FSR with 1FR.	0-5		S	O
GROUP	Groups beginning with an alphabetic character. Used with the IBN line class code (LCC); Common Language Location Identifier (CLLI) of an IBN customer group. Identifies the customer group for this ACD group.			S	O
SUBGRP	Groups 0 to 7 subgroup numbers of a customer group to which a station or DN belongs.			S	O

Table 382: A_NT-DMS100_SN06_ADD_LINE

Parameter Name	Description	Range	Default Value	Type	Class
NCOS	The network class of service for IBN lines, trunks, or attendant consoles. Defines a set of capabilities or restrictions that allows or denies calls.	0-255		S	O
SNPA	The service numbering plan area (area code).			S	O
KEY	The key on a business or data unit.	1 to 68 for business sets and 1,2,5, or 7 for data units		S	O
RINGING	The key on a business set assigned with ringing ability.	Y, N		S	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any DEO command.			C	O
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	Flag to indicate MML optimazation of the command.	true, false	true	S	O

A_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

Adds a new logical terminal and defines its service parameters. The SLT ADD command datafills tables LTDEF and KSETINV with the LTID profile information. It is implemented

by the Java method
com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.addLogTerm.

Table 383: A_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LTID	Logical Terminal Identifier.			S	R
LTCLASS	Class of logical terminal based on the type of messaging exchanged between the terminal and the ISDN switch.			S	R
CS	Designated circuit-switched service.			S	O
PS	Packet-switched service.			S	O
MAXKEYS	Maximum number of feature activators(keys) on a logical terminal used for circuit-switched service.			S	O
DEFLTERM	Default logical terminal. Enter Y to provision an integrated and a packet-only NIT with dynamic TEI.			S	O
TEI_TYPE	Terminal endpoint identifier type.			S	O
TEI	Terminal endpoint identifier.			S	O

Table 383: A_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
TSPID	Terminal service profile identifier option is used to initialize BRIFS LTIDs. This option is used with the Free Format SPID feature.			S	O
ABS	Authorized bearer services allows the bearer services to which a circuit-switched call can be subscribed.			C	O
EKTS	Electronic key telephone set.			S	O
OPT	Options installed on the terminal.	AGA, CACH, EKTS, PVC, SLBRI, SPIDSFX, TERML		C	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_ADD_NEWDN

Assigns directory numbers (DN) that are associated with an office route, but not physical line equipment. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineProv.addNewDN.**

Table 384: A_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R

Table 384: A_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
SNPA	Serving numbering plan area station.			S	O
BLOCK_OF_DNS	Used to assign a block of DNs or a single DN. Use YES for a block of DNs or NO for a single DN and RCF.			S	R
VDNTYPE	Used to provision VDNs. When BLOCK_OF_DNS is NO, the following inputs are valid: AIN, DISA, CFIB, RCF, RCFEA, RTE, MSR, SIMRING. When BLOCK_OF_DNS is YES, the valid input is RTE.			S	R

Table 384: A_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
FWD_DN	The DN (up to 30 digits) to which calls are forwarded in a fixed call forwarding option.			S	O
FWD_NPA	3 digit area code of a FWD DN.			S	O
FWD_NXX	First 3 digits of the line number of a FWD DN.			S	O
FWD_LINE	4 digit line extension of a FWD DN.			S	O
MAXCALLS	Appears during the assignment of an RCF. Specifies the maximum number of simultaneous calls allowed to the DN.	0-511		S	O
LTG	Line treatment group member, used to calculate the line attribute index then the DN and LCC are insufficient to find an appropriate index. LTG is prompted for in conjunction with LCC.	0-255		S	O
MRSA	MRSA as defined in table MRSANAME. Message rate service area to be used for billing with remote call forwarding.			S	O
BLK_TOLL_COM	Appears for the RCF option. Specifies whether incoming toll calls are forwarded to a remote station.	Y, N		S	O

Table 384: A_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
BLK_TOLL_TREATMENT	Appears for the RCF option. Specifies the treatment given to a blocked toll call.			S	O
OM_INDEX	Operations measurements index.	0-127		S	O
SCRNCL	Specifies route or screening class for a forwarded call. Values: RTE and SCR.			S	O
OFRTINDX	OFRTINDX value.			S	O
LATANM	LATANM value.			S	O
PRTNM	PRTNM value.			S	O
SIGDATA	Specifies whether or not to use RCF signaling enhancements.	Y, N		S	O
DNTYPE	When VDNTYPE=AIN, value IBN, NONIBN			S	O
LINEATTR	Value of lineattr when VDNTYPE=AIN, DNTYPE=NONIBN			S	O
AIN_VDN_OPT_NCOS	Value of AIN_VDN_OPTION NCOS, when VDNTYPE=AIN.			S	O

Table 384: A_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
AIN_VDN_OPT_SMDR	Option AIN_VDN_OPTION SMDR, where are values are Y, N. Value Y indicates that option will be added, value N no, when VDNTYPE=AIN.			S	O
CUSTGRP	Value of custgrp when VDNTYPE=AIN, DNTYPE=IBN			S	O
SUBGRP	Value of custgrp when VDNTYPE=AIN, DNTYPE=IBN			S	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any DEO command.			C	O
CUSTOM	Customer-specific parameter.			C	O
IS_OPTIMIZED	Flag to indicate MML optimazation of the command.	true, false	true	S	O

A_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL

Attaches a logical terminal to a line equipment number (LEN) and a terminal endpoint identifier (TEI). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.attachLogTerm.**

Table 385: A_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LTID	Logical Terminal Identifier.			S	R
LEN	The LEN for a service to establish, change, or delete.			S	R
OPT	Option(s) associated with a service to add or change on the terminal.	TEI, PHLINK, TO, BCH, PHI, DCHCHNL		C	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL

Changes the following parameters associated with an LTID: AGA, PVC, CACH, SPIDSFX, EKTS, TERML and TSPID. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.changeLogTerm.**

Table 386: A_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LTID	Logical Terminal Identifier.			S	R

Table 386: A_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
OPT	Option(s) associated with a service to add or change on the terminal.	ABS, AGA, CACH, PVC, EKTS, SLBRI, SPIDSFX		C	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_DEL_LINE

Removes services from single-line and multi-line telephone set directory numbers (DN) and line equipment numbers (LEN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineProv.delLine.**

Table 387: A_NT-DMS100_SN06_DEL_LINE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O

Table 387: A_NT-DMS100_SN06_DEL_LINE

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number. Either LEN or LTID must exist. If both exist, LTID is ignored.			S	O
LTID	Logical terminal identifier.			S	O
INTERCEPT_NAME	The type of intercept you want.	BLDN, AINT, ANCT, CANN, OPRT, and UNDN		S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_DEL_NEWDN

Can be used to do the following: delete virtual directory numbers (VDN) that are not associated with physical line equipment, delete remote call forwarding (RCF) from a DN, and delete call forward/interface busy (CFIB) from a DN. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineProv.delNewDN.**

Table 388: A_NT-DMS100_SN06_DEL_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O

Table 388: A_NT-DMS100_SN06_DEL_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
SNPA	Serving numbering plan area station.			S	O
BLOCK_OF_DNS	Used to assign a block of DNs or a single DN. Use YES for a block of DNs or NO for a single DN and RCF.			S	R
POOL_OUT	The Pool out value.	Y, N		S	O
CODEHOLDER	The CodeHolder value.	Y, N		S	O
INTERCEPT_NAME	The type of intercept you want.	BLDN		S	O
TO_DN	Used for block deletion of DN; indicates the last three digits of the last DN in the block. It is in format of 3 digits.			S	O
CUSTOM	Customer-specific parameter.			C	O
VDNTYPE	Used to assign the RCT feature to a block of DNs; selector for the type of DN. RTE = Route, RCF = Remote Call Forwarding, Forwarding LDN = Line DN, RCFEA = Remote Call, Forwarding equal access. A numeric entry of 1 to 30 digits.			S	O

A_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL

Detaches a logical terminal from a LEN and a TEI. This command removes datafill from table LTMAP. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.detachLogTerm.**

Table 389: A_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LTID	Logical Terminal Identifier.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_PLUG-UP_LINE

Allows the user to plug up directory numbers (DNs) on single-line sets. The operating company personnel cannot issue this command on multi-line telephone set DNs. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.plugUpLine.**

Table 390: A_NT-DMS100_SN06_PLUG-UP_LINE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O

Table 390: A_NT-DMS100_SN06_PLUG-UP_LINE

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_QRY_CUSTOMER-INFO

Queries the Customer Profile (QCUST). Retrieves information of the line data associated with one or more customer groups on the switch. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsQryProv.queryQCUST.**

Table 391: A_NT-DMS100_SN06_QRY_CUSTOMER-INFO

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
CUSTGRP	The customer group name for the line.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_QRY_DN

Retrieves information about the system and services associated with wireline or wireless subscriber, based on the directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsQryProv.queryDN.**

Table 392: A_NT-DMS100_SN06_QRY_DN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_QRY_LEN

Generates a printout of line data related to a specified line equipment number (LEN) or directory number (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsQryProv.queryLEN.**

Table 393: A_NT-DMS100_SN06_QRY_LEN

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	O
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL

Generates information about the Logical Terminals, with the logical terminal identifier(LTID). The LTID value is the combination of both logical terminal group name and

number. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsQryProv.queryQLT.**

Table 394: A_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LTID	Logical Terminal Identifier.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL

Removes an LTID from the access information tables. This command removes datafill from table LTDEF. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.removeLogTerm.**

Table 395: A_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
LTID	Logical Terminal Identifier.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_RESTORE_LINE

Restores service to busy or suspended single line and multi-line telephone set directory numbers (DN). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.restoreLine.**

Table 396: A_NT-DMS100_SN06_RESTORE_LINE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	R
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

Adds, changes, or deletes attributes for a specified group of directory numbers (DNs). It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.setUpLine.**

Table 397: A_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
AREACODE	Serving numbering plan area code for the station.			S	R
OFCCODE	Office code for DN, which is the second series of three digits of the DN.			S	R
FROMDIGS	Indicates the starting DN of a DN group to which network attributes are assigned.			S	R
TODIGS	Indicates the last DN of a DN group to which network attributes are assigned.			S	R
NETNAME	Network name that appears as DN attribute.			S	R
FUNCTION	Indicates the function to add, change, or delete the network attributes.			S	R
OPT	Features Used to Set Up Dn Attributes.	NAME, ADDRESS, SUPPRESS, NONUNIQUE		C	O
NAME	Indicates display suppression of the name of the originating subscriber.			S	O

Table 397: A_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O

A_NT-DMS100_SN06_SUSPEND_LINE

Suspends service to Directory Numbers (DNs) on single line and multi-line telephone sets. It is implemented by the Java method **com.metasolv.cartridge.oss.dms100_sn06.DMS100PotsLineSrv.suspendLine.**

Table 398: A_NT-DMS100_SN06_SUSPEND_LINE

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	R
CUSTOM	Customer-specific parameter.			C	O

User exit types

User exit types allow cartridge developers and systems administrators to map ASDL exit codes to one of the predefined base exit types. Base exit types determine the product behavior. Cartridges map return codes and status values from a network element to a user defined exit type.

Regular expressions (regex) are used to perform pattern searches on responses from network elements. The pattern is stored in "tbl_user_err" in the SARM database. The user exit type contains a regex pattern that is applied at runtime.

Regular expressions enable users to associate a series of responses to a specific base type. For example, a regular expression "6." can identify a pattern where any response with the character "6" followed by any number of characters will translate to base type of FAIL. Regular expressions can also allow very specific searches within a response from a network element. Regular expressions are typically compiled before being executed. Compilation produces a binary version of the expression and ensures that the syntax of the regular expression is correct. This compilation occurs using SACT\SADT when user exit types are deployed into ASAP. If the syntax is deemed to be incorrect during compilation, SADT displays an error message and the deployment of the user exit type will fail.

For more information on pattern matching, refer to the *ASAP Developer Reference* and the ASAP Administration Guide.

Several different messages can occur while the user enters service orders. The switch provides error messages when the user enters a service order sequence. The switch also provides error messages when the user confirms a service order.

```
> CHF $ 7224272 1 SCA $ ACT $
This Local DN is not Unique
Please Use the Full National DN
7224272
*** Error ***
>
```

To configure the ASDL exit type for each error message, you can edit the error messages and the corresponding User defined ASDL Exit type mapped in the cartridge service model DMS100_UserDefined_Exit_Type.xml file.

The list of user defined exit types are given below:

Table 399: User exit types

Search pattern	User type	Base type	Description
((?s).)*JOURNAL FILE RECORD NOT CREATED((?s).)*	DMS100_FILE_NOT_CREA	FAIL	Journal File record not created

Table 399: User exit types

Search pattern	User type	Base type	Description
((?s).)*JOURNAL FILE RECORD ID((?s).)*	SUCCEED	SUCCEED	Journal file record active
((?s).)*WARNING((?s).)*	DMS100_WARN	SUCCEED	Warning message
((?s).)*IS NOT AN EXISTING OPTION((?s).)*	DMS100_NOT_EXIST	FAIL	Option not exist
((?s).)*ALREADY EXISTS((?s).)*	DMS100_OPT_EXIST	FAIL	Option already exist
((?s).)*already exists((?s).)*	DMS100_OPT_EXIST	FAIL	Option already exist
((?s).)*OPTION DUPLICATED((?s).)*	DMS100_OPT_EXIST	FAIL	Option already exist
((?s).)*ARE NOT COMPATIBLE((?s).)*	DMS100_INCOMP	FAIL	Incompatible option
((?s).)*improper state((?s).)*	DMS100_IMP_STATE	RETRY	Improper state
((?s).)*IMPROPER LINE STATE((?s).)*	DMS100_IMPROPER_LINE	RETRY	Improper state of line
((?s).)*LEN ((?s).)*	DMS100_LEN_ASSGN	FAIL	LEN not assigned
((?s).)*Invalid or Unassigned DN((?s).)*	DMS100_INV_UNASS_DN	FAIL	Invalid or unassigned DN
((?s).)*Invalid DN((?s).)*	DMS100_INV_DN	FAIL	Invalid DN
((?s).)*INVALID DN((?s).)*	DMS100_INV_DN	FAIL	Invalid DN
((?s).)*IS UNASSIGNED | The Entered DN Does not Map to the Entered Len/Ltid((?s).)*	DMS100_DN_LEN_UNASS	FAIL	LEN or DN unassigned

Table 399: User exit types

Search pattern	User type	Base type	Description
((?s).)*TYPE: UNASSIGNED | The Entered DN Does not Map to the Entered Len/ Ltid((?s).)*	DMS100_DN_LEN_UNASS	FAIL	LEN or DN unassigned
((?s).)*IS ASSIGNED TO LEN | The Entered DN Does not Map to the Entered Len/Ltid((?s).)*	DMS100_LEN_MISMATCH	FAIL	LEN does not match with the DN
((?s).)*DN IS NOT ASSIGNED TO A SUBSCRIBER((?s).)*	DMS100_DN_NOT_ASSGN	FAIL	DN is not assigned to the subscriber
((?s).)*Invalid LEN((?s).)*	DMS100_INV_LEN	FAIL	Invalid LEN
((?s).)*INVALID LEN((?s).)*	DMS100_INV_LEN	FAIL	Invalid LEN
((?s).)*TYPE OF LEN_OR_LTID IS EXT_LEN((?s).)*	DMS100_INV_LEN	FAIL	Invalid LEN
((?s).)*DN IS ASSIGNED((?s).)*	DMS100_DN_ASSGN	FAIL	DN already assigned
((?s).)*TYPE OF GROUPSIZE((?s).)*	DMS100_INV_LINK_DN	FAIL	Invalid link DN
((?s).)*TYPE OF((?s).)*	DMS100_INV_PARM	FAIL	Invalid Parameter
((?s).)*INVALID((?s).)*	DMS100_INV_PARM	FAIL	Invalid Parameter
((?s).)*Out of range: ((?s).)*	DMS100_INV_PARM	FAIL	Invalid Parameter
((?s).)*Wrong type((?s).)*	DMS100_INV_PARM	FAIL	Invalid Parameter
((?s).)*Undefined command((?s).)*	DMS100_UNKNOWN	FAIL	Unknown Error
((?s).)*OUT OF SYNC((?s).)*	DMS100_OUTOFSYNC	MAINTENANCE	Out of Sync

Table 399: User exit types

Search pattern	User type	Base type	Description
((?s).)*ERROR TIMEOUT((?s).)*	DMS100_TIMEOUT	MAINTENANCE	No response from the switch for OPEN_TIMEOUT (tbl_comm_param) seconds
((?s).)*ERROR((?s).)*	DMS100_UNKNOWN	FAIL	Unknown Error
((?s).)*MACHINES ARE OUT OF SYNC((?s).)*	DMS100_OUTOFSYNC	MAINTENANCE	Out of sync
((?s).)*JOURNAL FILE IS INACTIVE((?s).)*	DMS100_FILE_INACTIVE	MAINTENANCE	Journal file is inactive
((?s).)*DISALLOWED DURING DUMP((?s).)*	DMS100_DISALLOW_DUMP	MAINTENANCE	Disallowed during dump
((?s).)*DISALLOWED DURING DATA((?s).)*	DMS100_DISALLOW_DATA	MAINTENANCE	Disallowed during data
((?s).)*IMPROPER LINE STATE((?s).)*	DMS100_IMP_LINE	RETRY	Improper line
((?s).)*PARTY ALREADY ASSIGNED((?s).)*	DMS100_PARTY_ASSGN	FAIL	Party already assigned
((?s).)*NOT ALLOCATED((?s).)*	DMS100_NOT_ALLOC	FAIL	Not allocated
((?s).)*NOT ALLOWED DURING DUMP((?s).)*	DMS100_NOTALLOW_DUMP	MAINTENANCE	Not allowed during dump
((?s).)*NOT IN SYNC((?s).)*	DMS100_NOT_SYNC	MAINTENANCE	Not in sync
((?s).)*OPTION NOT ALLOWED((?s).)*	DMS100_OPT_NOT_ALLOW	FAIL	Option not allowed
((?s).)*SPECIAL TRANSLATION DN((?s).)*	DMS100_SPL_TRANS_DN	FAIL	Special transaction DN
((?s).)*IS ASSOCIATED WITH FEATURE GROUP AND CANNOT BE DELETED((?s).)*	DMS100_GRP_NOT_DEL	FAIL	Associated Feature group cannot be deleted

Table 399: User exit types

Search pattern	User type	Base type	Description
((?s).)*are not compatible((?s).)*	DMS100_NOT_COMPAT	FAIL	Are not compatible
((?s).)*Duplicate appearances of a Shared DN((?s).)*	DMS100_DUP_SHARED_DN	FAIL	Duplicate appearance of shared DN
((?s).)*UNKNOWN_STATE_ERR((?s).)*	DMS100_UNKNOWN_STATE	MAINTENANCE	Unknown state error
((?s).)*Undefined symbol((?s).)*	DMS100_UNDEFINED_SYM	FAIL	The name or displayed name parameter value contains an undefined symbol
((?s).)*already assigned to the key((?s).)*	DMS100_OPT_EXIST	FAIL	Option already exists
((?s).)*QDN((?s).)*	DMS100_SUCCESS	SUCCEED	QDN success
((?s).)*QLEN((?s).)*	DMS100_SUCCESS	SUCCEED	QLEN success
((?s).)*QCUST((?s).)*	DMS100_SUCCESS	SUCCEED	QCUST success
((?s).)*QLT((?s).)*	DMS100_SUCCESS	SUCCEED	QLT success

4

Service Definition

The Nortel DMS100 cartridge contains a set of CSDLs that map to one or more ASDL commands. You can also create additional CSDLs that map to existing and newly-created ASDLs. An upstream system can assemble any of these CSDL commands onto a work order for provisioning.

This chapter presents detailed information on the CSDL parameters that we provide in this cartridge. The following table lists and describes the type of parameter information that is included.

Table 400: ASDL parameter information

Item	Description
Parameter Name	Identifies the parameter that is configured for the stated service.
Description	Describes the parameter.
Range	Describes or lists the range of values that can be used to satisfy this parameter.
Default Value	Configures a default value for the parameter so that it is not mandatory for the upstream system to provide a value.

Table 400: ASDL parameter information

Item	Description
Type	Indicates one of the following parameter types: ◆ S—Scalar, specifies the parameter label transmitted on the ASDL command. Scalar parameters are conventional name-value pair parameters. ◆ C—Compound, specifies the base name of the compound parameter transmitted on the ASDL command. A compound parameter contains structures or arrays of information that are represented by a particular structure name or compound parameter name. Each compound parameter can contain a large number of elements. If you use compound parameters, you only require a single entry in the ASAP translation tables to call the compound parameter and all its associated parameter elements. ◆ I—Indexed, identifies a parameter that contains a sequential numerical index value to tell the SARM that it should execute the same operation (for example, an ASDL command) for all occurrences of that index. Consequently, if there are several options on a particular CSDL command (OPT1, OPT2, OPT3, etc.), you can specify the OPT parameter as an indexed parameter. When you specify the OPT parameter as an indexed parameter, the SARM generates several occurrences of that same ASDL command and each command has a different value for the option being transmitted to the NEP. For more information on parameter types, refer to the *ASAP Developer Reference*.
Class	Indicates one of the following parameter classifications: ◆ R—Required scalar parameter ◆ O—Optional scalar parameter ◆ C—Required compound parameter ◆ N—Optional compound parameter ◆ M—Mandatory indexed parameter ◆ I—Optional indexed parameter ◆ S—Parameter count

For a detailed description of the Required and Optional parameter classifications, refer to the *ASAP Administration Guide.*

Add Feature Services

This cartridge provides the following CSDL commands:

- C_NT-DMS100_SN06_ADD_3WC
- C_NT-DMS100_SN06_ADD_ACB
- C_NT-DMS100_SN06_ADD_ACD
- C_NT-DMS100_SN06_ADD_ACDNR
- C_NT-DMS100_SN06_ADD_ACRJ
- C_NT-DMS100_SN06_ADD_AIN
- C_NT-DMS100_SN06_ADD_AINDN
- C_NT-DMS100_SN06_ADD_AMSGDENY
- C_NT-DMS100_SN06_ADD_AR
- C_NT-DMS100_SN06_ADD_ARDDN
- C_NT-DMS100_SN06_ADD_ASL
- C_NT-DMS100_SN06_ADD_AUD
- C_NT-DMS100_SN06_ADD_AUL
- C_NT-DMS100_SN06_ADD_AUTODISP
- C_NT-DMS100_SN06_ADD_CBE
- C_NT-DMS100_SN06_ADD_CBU
- C_NT-DMS100_SN06_ADD_CCW
- C_NT-DMS100_SN06_ADD_CDE
- C_NT-DMS100_SN06_ADD_CDI
- C_NT-DMS100_SN06_ADD_CDU
- C_NT-DMS100_SN06_ADD_CFB
- C_NT-DMS100_SN06_ADD_CFBL
- C_NT-DMS100_SN06_ADD_CFD
- C_NT-DMS100_SN06_ADD_CFDA
- C_NT-DMS100_SN06_ADD_CFDVT
- C_NT-DMS100_SN06_ADD_CFF
- C_NT-DMS100_SN06_ADD_CFGD
- C_NT-DMS100_SN06_ADD_CFGDA
- C_NT-DMS100_SN06_ADD_CFI
- C_NT-DMS100_SN06_ADD_CFMDN
- C_NT-DMS100_SN06_ADD_CFRA
- C_NT-DMS100_SN06_ADD_CFS
- C_NT-DMS100_SN06_ADD_CFU
- C_NT-DMS100_SN06_ADD_CFW
- C_NT-DMS100_SN06_ADD_CHD
- C_NT-DMS100_SN06_ADD_CIF

- C_NT-DMS100_SN06_ADD_CIR
- C_NT-DMS100_SN06_ADD_CLF
- C_NT-DMS100_SN06_ADD_CLI
- C_NT-DMS100_SN06_ADD_CNAB
- C_NT-DMS100_SN06_ADD_CNAMD
- C_NT-DMS100_SN06_ADD_CND
- C_NT-DMS100_SN06_ADD_CND-NO-BILL
- C_NT-DMS100_SN06_ADD_CNDB
- C_NT-DMS100_SN06_ADD_CNF
- C_NT-DMS100_SN06_ADD_COD
- C_NT-DMS100_SN06_ADD_COT
- C_NT-DMS100_SN06_ADD_COT-NO-BILL
- C_NT-DMS100_SN06_ADD_CPU
- C_NT-DMS100_SN06_ADD_CSMI
- C_NT-DMS100_SN06_ADD_CUSD
- C_NT-DMS100_SN06_ADD_CWD
- C_NT-DMS100_SN06_ADD_CWI
- C_NT-DMS100_SN06_ADD_CWO
- C_NT-DMS100_SN06_ADD_CWT
- C_NT-DMS100_SN06_ADD_CWX
- C_NT-DMS100_SN06_ADD_CXR
- C_NT-DMS100_SN06_ADD_DCF
- C_NT-DMS100_SN06_ADD_DCPU
- C_NT-DMS100_SN06_ADD_DDN
- C_NT-DMS100_SN06_ADD_DENY
- C_NT-DMS100_SN06_ADD_DENYACB
- C_NT-DMS100_SN06_ADD_DENYAR
- C_NT-DMS100_SN06_ADD_DENYCOT
- C_NT-DMS100_SN06_ADD_DENYCSMI
- C_NT-DMS100_SN06_ADD_DENYISA
- C_NT-DMS100_SN06_ADD_DENYU3WC
- C_NT-DMS100_SN06_ADD_DGT
- C_NT-DMS100_SN06_ADD_DIN
- C_NT-DMS100_SN06_ADD_DISP
- C_NT-DMS100_SN06_ADD_DNH
- C_NT-DMS100_SN06_ADD_DOR

- C_NT-DMS100_SN06_ADD_DQS
- C_NT-DMS100_SN06_ADD_DQT
- C_NT-DMS100_SN06_ADD_DRCW
- C_NT-DMS100_SN06_ADD_DRING
- C_NT-DMS100_SN06_ADD_DSCWID
- C_NT-DMS100_SN06_ADD_DTM
- C_NT-DMS100_SN06_ADD_ELN
- C_NT-DMS100_SN06_ADD_EMW
- C_NT-DMS100_SN06_ADD_ESL
- C_NT-DMS100_SN06_ADD_FAA
- C_NT-DMS100_SN06_ADD_FANI
- C_NT-DMS100_SN06_ADD_FEATURES
- C_NT-DMS100_SN06_ADD_FTRGRP
- C_NT-DMS100_SN06_ADD_GIC
- C_NT-DMS100_SN06_ADD_GND
- C_NT-DMS100_SN06_ADD_HOT
- C_NT-DMS100_SN06_ADD_ICM
- C_NT-DMS100_SN06_ADD_INSPECT
- C_NT-DMS100_SN06_ADD_INT
- C_NT-DMS100_SN06_ADD_INTPIC
- C_NT-DMS100_SN06_ADD_KSH
- C_NT-DMS100_SN06_ADD_LCDR
- C_NT-DMS100_SN06_ADD_LDSA
- C_NT-DMS100_SN06_ADD_LDSO
- C_NT-DMS100_SN06_ADD_LNR
- C_NT-DMS100_SN06_ADD_LNRA
- C_NT-DMS100_SN06_ADD_LOB
- C_NT-DMS100_SN06_ADD_LOD
- C_NT-DMS100_SN06_ADD_LPIC
- C_NT-DMS100_SN06_ADD_LVM
- C_NT-DMS100_SN06_ADD_M518
- C_NT-DMS100_SN06_ADD_M536
- C_NT-DMS100_SN06_ADD_MDN
- C_NT-DMS100_SN06_ADD_MSB
- C_NT-DMS100_SN06_ADD_MSBI
- C_NT-DMS100_SN06_ADD_MWT

- C_NT-DMS100_SN06_ADD_NAME
- C_NT-DMS100_SN06_ADD_NDC
- C_NT-DMS100_SN06_ADD_NFA
- C_NT-DMS100_SN06_ADD_NGTSRVCE
- C_NT-DMS100_SN06_ADD_NLT
- C_NT-DMS100_SN06_ADD_OBS
- C_NT-DMS100_SN06_ADD_ONI
- C_NT-DMS100_SN06_ADD_PIC
- C_NT-DMS100_SN06_ADD_PORT
- C_NT-DMS100_SN06_ADD_PRK
- C_NT-DMS100_SN06_ADD_PRL
- C_NT-DMS100_SN06_ADD_QTD
- C_NT-DMS100_SN06_ADD_RAG
- C_NT-DMS100_SN06_ADD_RCHD
- C_NT-DMS100_SN06_ADD_RMI
- C_NT-DMS100_SN06_ADD_RMR
- C_NT-DMS100_SN06_ADD_RMT
- C_NT-DMS100_SN06_ADD_RPA
- C_NT-DMS100_SN06_ADD_RSP
- C_NT-DMS100_SN06_ADD_RSUS
- C_NT-DMS100_SN06_ADD_SACB
- C_NT-DMS100_SN06_ADD_SC1
- C_NT-DMS100_SN06_ADD_SC2
- C_NT-DMS100_SN06_ADD_SCA
- C_NT-DMS100_SN06_ADD_SCF
- C_NT-DMS100_SN06_ADD_SCL
- C_NT-DMS100_SN06_ADD_SCRJ
- C_NT-DMS100_SN06_ADD_SCS
- C_NT-DMS100_SN06_ADD_SCU
- C_NT-DMS100_SN06_ADD_SCWID
- C_NT-DMS100_SN06_ADD_SDN
- C_NT-DMS100_SN06_ADD_SDSDENY
- C_NT-DMS100_SN06_ADD_SHU
- C_NT-DMS100_SN06_ADD_SL
- C_NT-DMS100_SN06_ADD_SMDR
- C_NT-DMS100_SN06_ADD_SPB

- C_NT-DMS100_SN06_ADD_SRA
- C_NT-DMS100_SN06_ADD_SSAC
- C_NT-DMS100_SN06_ADD_SUPPRESS
- C_NT-DMS100_SN06_ADD_SUPR
- C_NT-DMS100_SN06_ADD_SVCGRP
- C_NT-DMS100_SN06_ADD_TCW
- C_NT-DMS100_SN06_ADD_TDN
- C_NT-DMS100_SN06_ADD_TFO
- C_NT-DMS100_SN06_ADD_UCD
- C_NT-DMS100_SN06_ADD_VMEADENY
- C_NT-DMS100_SN06_ADD_VMEADN
- C_NT-DMS100_SN06_ADD_WML
- C_NT-DMS100_SN06_ADD_WUC
- C_NT-DMS100_SN06_ADD_WUCR
- C_NT-DMS100_SN06_ADD_DCPK

C_NT-DMS100_SN06_ADD_3WC

This option allows the subscriber on the assigned line to place a call on hold. When the call is on hold, the subscriber can set up a request call to another subscriber.

Table 401: C_NT-DMS100_SN06_ADD_3WC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 401: C_NT-DMS100_SN06_ADD_3WC

Parameter Name	Description	Range	Default Value	Type	Class
THREE_WAY_CONFERENCE_OPTKEY	The key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 402: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_3WC	A_NT-DMS100_SN06_ADD_3WC

C_NT-DMS100_SN06_ADD_ACB

ACB allows to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call.

Table 403: C_NT-DMS100_SN06_ADD_ACB

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_BACK_BILLING_OPTION	The specified billing option, when the user assigns the CND or COT option to a RES line.	AMA=recorded, NOAMA=not recorded, or $		S	O
AUTOMATIC_CALL_BACK_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), a list of key numbers, or $		C	O

Table 403: C_NT-DMS100_SN06_ADD_ACB

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_BACK_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 404: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ACB	A_NT-DMS100_SN06_ADD_ACB

C_NT-DMS100_SN06_ADD_ACD

ACD allows the subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call.

Table 405: C_NT-DMS100_SN06_ADD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_ACDGROUP	A group identifier that is already in table ACDGRP. Indicates the name of the automatic call distribution (ACD) group to which this station belongs.			S	R
AUTOMATIC_CALL_DISTRIBUTION_ACDSGRP	The number of the ACD subgroup to which this station belongs. This number must already appear in table ACDSGRP.			S	R
AUTOMATIC_CALL_DISTRIBUTION_IBN_ACD_OPTION	Enter SCAILINK if the ACD agent associates with a set of D-channels for switch-computer communications. Enter ACDNR to deny ACD calls by the ACD agent.			C	R
AUTOMATIC_CALL_DISTRIBUTION_IDNUM	Indicates if an ID number for a Supervisor set is present. This field appears only when a supervisor set uses NEWACD. If Y, the POSID field prompts.			S	R
AUTOMATIC_CALL_DISTRIBUTION_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 405: C_NT-DMS100_SN06_ADD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_POSID	Enter the ACD agent position ID number. A POSID is for interactions with other ACD options.			S	R
AUTOMATIC_CALL_DISTRIBUTION_SCAI_LINK	Indicates the PRA D-channel name, or SCAIDEF for the default link set name.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 406: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ACD	A_NT-DMS100_SN06_ADD_ACD

C_NT-DMS100_SN06_ADD_ACDNR

The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN).

Table 407: C_NT-DMS100_SN06_ADD_ACDNR

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_NOT_READY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 408: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ACDNR	A_NT-DMS100_SN06_ADD_ACDNR

C_NT-DMS100_SN06_ADD_ACRJ

The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN).

Table 409: C_NT-DMS100_SN06_ADD_ACRJ

Parameter Name	Description	Range	Default Value	Type	Class
ANONYMOUS_CALLER_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
ANONYMOUS_CALLER_BLOCKING_STATUS	INACT indicates that the user did not enable the option (not active). ACT indicates that the user enabled the option (active). UNIVI indicates that universal access through customer interface is not active. UNIVA indicates that universal access through customer interface is active.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 410: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ACRJ	A_NT-DMS100_SN06_ADD_ACRJ

C_NT-DMS100_SN06_ADD_AIN

The AIN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN.

Table 411: C_NT-DMS100_SN06_ADD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
PRIVACY_ID_GROUP_AINGRP	The AIN group name used to define a group of trigger behaviors.			S	R
PRIVACY_ID_GROUP_KEYLIST	Specifies DN key numbers to which an option applies. Appears when the user assigns a subset option to BRI multi-line sets.If key number is not provided, assumes that value is $.			C	O

Table 411: C_NT-DMS100_SN06_ADD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
PRIVACY_ID_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 412: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AIN	A_NT-DMS100_SN06_ADD_AIN

C_NT-DMS100_SN06_ADD_AINDN

The AINDN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN.

Table 413: C_NT-DMS100_SN06_ADD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 413: C_NT-DMS100_SN06_ADD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
PRIVACY_ID_AINGRP	Enter TIID to datafill the trigger for the following refinements to the item provisioning interface. Up to 16 alphanumeric characters, or TIID.			S	R
PRIVACY_ID_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
PRIVACY_ID_TDP	Datafill the appropriate TDP.	1, 3, 4, 17, 19, 20, 22, 30, 32, and 33		S	O
PRIVACY_ID_TINAME	An alphanumeric vector (1 to 8 characters) to datafill the trigger items defined in table TRIGITM at the specified TDP.			S	O
PRIVACY_ID_TRIGACT	Datafill the value ON to activate the trigger item identified by the TIID. Datafill the value OFF to deactivate the trigger item identified by the TIID.	ON or OFF		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 414: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AINDN	A_NT-DMS100_SN06_ADD_AINDN

C_NT-DMS100_SN06_ADD_AMSGDENY

AMSGDENY prevents the line from receiving access to a messaging service. The operating company assigns the AMSGDENY option.

Table 415: C_NT-DMS100_SN06_ADD_AMSGDENY

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 416: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AMSGDENY	A_NT-DMS100_SN06_ADD_AMSGDENY

C_NT-DMS100_SN06_ADD_AR

The AR option allows a subscriber to call the last station that called the subscriber.

Table 417: C_NT-DMS100_SN06_ADD_AR

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_RECALL_BILLING_OPTION	The specified billing option when the user assigns the CND or COT option to a RES line.	AMA=recorded, NOAMA=not recorded, or $		S	O
AUTOMATIC_RECALL_KEYLIST	Key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	A key number (1-69), list of key numbers, or $		C	O
AUTOMATIC_RECALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 418: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AR	A_NT-DMS100_SN06_ADD_AR

C_NT-DMS100_SN06_ADD_ARDDN

The ARDDN option allows subscribers to dial a feature code that sets up a call to the directory number (DN) where the subscriber placed the last incoming call.

Table 419: C_NT-DMS100_SN06_ADD_ARDDN

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_RECALL_DIALABLE_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 420: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ARDDN	A_NT-DMS100_SN06_ADD_ARDDN

C_NT-DMS100_SN06_ADD_ASL

The ASL option allows a supervisor to monitor the status of an agent position. This process does not interfere with the call. The lamp for the assigned agent status key reflects the status of the call.

Table 421: C_NT-DMS100_SN06_ADD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
AGENT_STATUS_LAMP_AGENT_LEN	The LEN of the agent position.			S	R
AGENT_STATUS_LAMP_ASLSDN	Agent status lamp that monitors the SDN of an ACD agent. Key number for the secondary DN the user must monitor.			S	R
AGENT_STATUS_LAMP_MSBOVRD	Make set busy override.			S	R
AGENT_STATUS_LAMP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 421: C_NT-DMS100_SN06_ADD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 422: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ASL	A_NT-DMS100_SN06_ADD_ASL

C_NT-DMS100_SN06_ADD_AUD

The AUD option allows a business set subscriber to call a number the subscriber dials frequently. The subscriber presses the AUD key to call this number. The subscriber can program and change this number.

Table 423: C_NT-DMS100_SN06_ADD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DIAL_AUDFEAT	The option or service to be accessed.			S	R
AUTOMATIC_DIAL_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 423: C_NT-DMS100_SN06_ADD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DIAL_PGMAUD	Indicates person who programs the AUD key.	Y = yes (operating company programmed); N = no (subscriber programmed)		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 424: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AUD	A_NT-DMS100_SN06_ADD_AUD

C_NT-DMS100_SN06_ADD_AUL

The automatic line (AUL) option connects to a set location when a directory number (DN) or an assigned AUL option line reports an off-hook status.

Table 425: C_NT-DMS100_SN06_ADD_AUL

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_LINE_DN	Automatic line DN.			S	O
AUTOMATIC_LINE_LINE	Automatic line LINE.			S	O
AUTOMATIC_LINE_NPA	Automatic line NPA.			S	O
AUTOMATIC_LINE_NXX	Automatic line NXX.			S	O
AUTOMATIC_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 426: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AUL	A_NT-DMS100_SN06_ADD_AUL

C_NT-DMS100_SN06_ADD_AUTODISP

The automatic display (AUTODISP) option automatically shows information on incoming calls to a Meridian business set (MBS).

Table 427: C_NT-DMS100_SN06_ADD_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DISPLAY_CWT_OPTION	Indicates person who programs the AUD key.	Y = yes (operating company programmed); N = no (subscriber programmed)		S	R
AUTOMATIC_DISPLAY_KEYLIST	The option or service to be accessed.			C	O
AUTOMATIC_DISPLAY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 427: C_NT-DMS100_SN06_ADD_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 428: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_AUTODISP	A_NT-DMS100_SN06_ADD_AUTODISP

C_NT-DMS100_SN06_ADD_CBE

The Call Forwarding Busy Internal Calls Only (CBE) option allows the subscriber to stop the system when the system forwards external calls. The CBE option allows intragroup calls to forward to a remote station in the customer group.

Table 429: C_NT-DMS100_SN06_ADD_CBE

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_INTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 429: C_NT-DMS100_SN06_ADD_CBE

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 430: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CBE	A_NT-DMS100_SN06_ADD_CBE

C_NT-DMS100_SN06_ADD_CBU

The CBU option allows Call Forwarding Busy calls to forward to remote stations outside and inside the customer group.

Table 431: C_NT-DMS100_SN06_ADD_CBU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 432: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CBU	A_NT-DMS100_SN06_ADD_CBU

C_NT-DMS100_SN06_ADD_CCW

The Cancel Call Waiting (CCW) option allows Call Waiting (CWT) subscribers to turn off the CWT option.

Table 433: C_NT-DMS100_SN06_ADD_CCW

Parameter Name	Description	Range	Default Value	Type	Class
CANCEL_CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 434: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CCW	A_NT-DMS100_SN06_ADD_CCW

C_NT-DMS100_SN06_ADD_CDE

The CDE option prevents the forwarding of calls from outside the customer group. This option can make sure that external calls do not flood the remote station when many of the incoming calls are external.

Table 435: C_NT-DMS100_SN06_ADD_CDE

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_EXCLUDE_EXTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 436: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CDE	A_NT-DMS100_SN06_ADD_CDE

C_NT-DMS100_SN06_ADD_CDI

The CDI option prevents the forwarding of intragroup calls. The CDI makes sure that intragroup calls do not flood the remote station.

Table 437: C_NT-DMS100_SN06_ADD_CDI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_EXCLUDE_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 438: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CDI	A_NT-DMS100_SN06_ADD_CDI

C_NT-DMS100_SN06_ADD_CDU

The CDU option allows the system to forward all calls that are not answered to a remote station that is outside or inside customer group.

Table 439: C_NT-DMS100_SN06_ADD_CDU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 440: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CDU	A_NT-DMS100_SN06_ADD_CDU

C_NT-DMS100_SN06_ADD_CFB

The CFB option allows the system to forward all calls to a busy station to a station determined earlier.

Table 441: C_NT-DMS100_SN06_ADD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_CNTL	Call forwarding busy control.	F = fixed assignment for CFB, N = normal (default) assignment for CFB, P = programmed assignment for CFB, K = programmed assignment for CFB per key destination		S	O
CALL_FORWARD_BUSY_DN	Call forwarding DN for CFB option.			S	O
CALL_FORWARD_BUSY_KEYLIST	Specifies key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_FORWARD_BUSY_LINE	Call forwarding LINE for CFB option.			S	O
CALL_FORWARD_BUSY_NPA	Call forwarding NPA for CFB option.			S	O
CALL_FORWARD_BUSY_NXX	Call forwarding NXX for CFB option.			S	O

Table 441: C_NT-DMS100_SN06_ADD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 442: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFB	A_NT-DMS100_SN06_ADD_CFB

C_NT-DMS100_SN06_ADD_CFBL

The CFBL option allows the subscriber to specify a directory number (DN).

Table 443: C_NT-DMS100_SN06_ADD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_LINE_CFBLCNTL	Call forwarding busy line control.	F = fixed assignment for CFBL, N = normal (default) assignment for CFBL, C = programmed assignment for CFBL		S	R
CALL_FORWARD_BUSY_LINE_DN	DN to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_LINE	Line to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NPA	NPA to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NUMCALLS	The number of calls the system can forward at the same time.	0-1024		S	R
CALL_FORWARD_BUSY_LINE_NXX	NXX to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_SCRNCL	Screening by class of service.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 443: C_NT-DMS100_SN06_ADD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 444: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFBL	A_NT-DMS100_SN06_ADD_CFBL

C_NT-DMS100_SN06_ADD_CFD

The CFD option allows the system to forward incoming calls that are not answered in a specified time.

Table 445: C_NT-DMS100_SN06_ADD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_BUS_CNTL	Call forwarding busy control.	F = fixed assignment for CFD, N = normal (default) assignment for CFD, P = programmed assignment for CFD, K = programmed assignment for CFD per key destination		S	O
CALL_FORWARD_NO_ANSWER_BUS_DN	Call forwarding DN for CFD option.			S	O

Table 445: C_NT-DMS100_SN06_ADD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_BUS_KEYLIST	Specifies key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_FORWARD_NO_ANSWER_BUS_LINE	Call forwarding LINE for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NPA	Call forwarding NPA for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NXX	Call forwarding NXX for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 446: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFD	A_NT-DMS100_SN06_ADD_CFD

C_NT-DMS100_SN06_ADD_CFDA

The Call Forwarding Do Not Answer (CFDA) Residential option forwards calls not answered to stations in the same customer group.

Table 447: C_NT-DMS100_SN06_ADD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_RES_CNTL	Call Forwarding Do Not Answer control.	F means fixed, N means normal (default), and C means programmed assignment		S	O
CALL_FORWARD_NO_ANSWER_RES_DN	Number to which the system forwards calls.			S	O
CALL_FORWARD_NO_ANSWER_RES_LINE	Call forwarding LINE for CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_NPA	Call forwarding NPA for CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_NUMCALLS	The number of calls the system can forward at the same time.			S	R
CALL_FORWARD_NO_ANSWER_RES_NXX	Call forwarding NXX for CFDA option.			S	O

Table 447: C_NT-DMS100_SN06_ADD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_RES_RING_CTRL	Indicates whether the end user or the operating company controls the ringing time-out. PRGRING allows the end user to change the CFDA ringing time-out. FIXRING indicates that only the operating company can change the ringing time-out.			S	R
CALL_FORWARD_NO_ANSWER_RES_SCRNCL	Screening identifies screening by class of service.			S	R
CALL_FORWARD_NO_ANSWER_RES_TIME	Indicates the period of time the base station rings before forwarding.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 448: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFDA	A_NT-DMS100_SN06_ADD_CFDA

C_NT-DMS100_SN06_ADD_CFDVT

The Call Forwarding Do Not Answer Variable Timer (CFDVT) option allows an end-user to specify how long a call rings before the system forwards the call to another station.

Table 449: C_NT-DMS100_SN06_ADD_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_VAR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_NO_ANSWER_VAR_RING_CTRL	Ring control. Enter PRGRING to allow end-user to set CVDVT time-out period. Enter FIXRING to indicate to end-user that the CVDVT time-out period is fixed; it can only be changed by the operating company.			S	R
CALL_FORWARD_NO_ANSWER_VAR_TIME	Call forward do not answer timing. The time, in seconds, that a call rings before the system forwards the call to the next DN.	0-60		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 449: C_NT-DMS100_SN06_ADD_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 450: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFDVT	A_NT-DMS100_SN06_ADD_CFDVT

C_NT-DMS100_SN06_ADD_CFF

The CFF option allows the station to forward calls to a location the operating company enters. The user cannot program the number to which the station forwards the calls.

Table 451: C_NT-DMS100_SN06_ADD_CFF

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_FIXED_CFFDN	Call forwarding DN for CFF option.			S	O
CALL_FORWARD_FIXED_CFF_OPTION	The value to set the CFFA to active.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 451: C_NT-DMS100_SN06_ADD_CFF

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 452: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFF	A_NT-DMS100_SN06_ADD_CFF

C_NT-DMS100_SN06_ADD_CFGD

The CFGD option allows the user to assign call forwarding do not answer to separate Hunt groups. With CFGD, calls to idle Hunt group stations ring for a set amount of time before the system forwards the calls.

Table 453: C_NT-DMS100_SN06_ADD_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_BUS_DN	Call forwarding DN for CFGD option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_INTERNAL	Indicates whether the system forwards the call to a member of the Hunt group.	Y=YES, N=NO		S	R
CALL_FORWARD_GROUP_NO_ANSWER_BUS_LINE	Call forwarding LINE for CFGD option.			S	O

Table 453: C_NT-DMS100_SN06_ADD_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_BUS_NPA	Call forwarding NPA for CFGD option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_NXX	Call forwarding NXX for CFGD option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_SPECTIME	Special timeout for Call Forward Do Not Answer option.	Y=YES, N=NO		S	R
CALL_FORWARD_GROUP_NO_ANSWER_BUS_TIMEOUT	Specifies the length of time in seconds before an unanswered call is forwarded.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_BUS_TYPE	Call forwarding type.	N = no restrictions, CFGDI = restrict intragroup, CFGDE = restrict extragroup		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 454: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFGD	A_NT-DMS100_SN06_ADD_CFGD

C_NT-DMS100_SN06_ADD_CFGDA

The CFGDA option allows the system administrator to assign call forwarding to a Hunt group. Calls to idle Hunt group stations ring for a set amount of time before the system forwards the calls. The system forwards the calls to a DN outside the Hunt group.

Table 455: C_NT-DMS100_SN06_ADD_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_RES_DN	Number to which the system forwards calls.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_INTERNAL	Indicates whether the system forwards the call to a member of the Hunt group.	Y=YES, N=NO		S	R
CALL_FORWARD_GROUP_NO_ANSWER_RES_LINE	Call forwarding LINE for CFGDA option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_NPA	Call forwarding NPA for CFGDA option.			S	O
CALL_FORWARD_GROUP_NO_ANSWER_RES_NUMCALLS	The number of calls the system can forward at the same time.			S	R
CALL_FORWARD_GROUP_NO_ANSWER_RES_NXX	Call forwarding NXX for CFGDA option.			S	O

Table 455: C_NT-DMS100_SN06_ADD_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_RES_SCRNCL	Identifies screening by class of service.			S	R
CALL_FORWARD_GROUP_NO_ANSWER_RES_TIME	Indicates the period of time the base station rings before forwarding.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 456: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFGDA	A_NT-DMS100_SN06_ADD_CFGDA

C_NT-DMS100_SN06_ADD_CFI

The CFI option allows stations to forward calls only to locations in the customer group that the customer defines.

Table 457: C_NT-DMS100_SN06_ADD_CFI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_INTRAGROUP_KEYLIST	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If a key number is not provided, assumes that value is $.			C	O
CALL_FORWARD_INTRAGROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 458: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFI	A_NT-DMS100_SN06_ADD_CFI

C_NT-DMS100_SN06_ADD_CFMDN

The Call Forwarding MADN Secondary Number (CFMDN) option lets secondary units of a multiple appearance directory number (MADN) group, activate call forwarding (CFF, CFU and CFI only) from a station.

Table 459: C_NT-DMS100_SN06_ADD_CFMDN

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_MADN_DN_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 460: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFMDN	A_NT-DMS100_SN06_ADD_CFMDN

C_NT-DMS100_SN06_ADD_CFRA

The Call Forwarding Remote Access (CFRA) option allows a single-line set to use a line other than its own.

Table 461: C_NT-DMS100_SN06_ADD_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_REMOTE_ACTIVATION_FIRSTUSE	Indicates whether the user must change the PIN before using CFRA for the first time. This prompt applies when option SPP is entered in table CUSTSTN. This field must be set to Y. This action requires the user to change their PIN with SPP before using CFRA for the first time.	Y or N		S	O
CALL_FORWARD_REMOTE_ACTIVATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_REMOTE_ACTIVATION_PIN	The first personal identification number (PIN) the operating company assigns to the line.	2-10 digits		S	R
DN	Directory number.			S	O

Table 461: C_NT-DMS100_SN06_ADD_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 462: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFRA	A_NT-DMS100_SN06_ADD_CFRA

C_NT-DMS100_SN06_ADD_CFS

The Call Forwarding Simultaneous/Screening (CFS) option allows the user to call forward more than one call through a station at a time.

Table 463: C_NT-DMS100_SN06_ADD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_CFXNCOS	Call forwarding NCOS.			S	R
CALL_FORWARD_SIMULTANEUS_NCFB	Maximum number of active calls the user can forward through a CFB base station at the same time.			S	R

Table 463: C_NT-DMS100_SN06_ADD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_NCFD	The number of calls the user can forward for call forward do not answer at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_NCFUIF	Maximum number of active calls the user can forward through a CFU, CFI, or CFF base station at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_SIMULTANEUS_SCREEN	Call forwarding screening capability.			S	R
CALL_FORWARD_SIMULTANEUS_SIMULT	Indicates Call Forwarding Simultaneous.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 464: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFS	A_NT-DMS100_SN06_ADD_CFS

C_NT-DMS100_SN06_ADD_CFU

The CFU option allows a station user to reroute incoming calls to another telephone number.

Table 465: C_NT-DMS100_SN06_ADD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_UNIVERSAL_KEYLIST	Specifies the key numbers of the DNs to which an option will apply. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_FORWARD_UNIVERSAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_UNIVERSAL_OVRDACR	Override for account code required.	Y = Yes, N = No		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 465: C_NT-DMS100_SN06_ADD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 466: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFU	A_NT-DMS100_SN06_ADD_CFU

C_NT-DMS100_SN06_ADD_CFW

The CFW option allows the user to forward calls to another location.

Table 467: C_NT-DMS100_SN06_ADD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_DN	Number to which calls will be forwarded.	1-30 digits. "$" must not be used		S	O
CALL_FORWARD_LINE	LINE to which calls will be forwarded.			S	O
CALL_FORWARD_NPA	NPA to which calls will be forwarded.			S	O
CALL_FORWARD_NUMCALLS	The number of calls the user can forward at the same time.	0-1024		S	O
CALL_FORWARD_NXX	NXX to which calls will be forwarded.			S	O
CALL_FORWARD_SCRNCL	Screening by class of service.			S	R

Table 467: C_NT-DMS100_SN06_ADD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_STATE	State of absent subscriber intercept. Default is $.	A = active, I = inactive, W = wait		S	O
CALL_FORWARD_TYPE	Type of call forwarding.	C = customer, F = fixed, U = usage sensitive pricing		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 468: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CFW	A_NT-DMS100_SN06_ADD_CFW

C_NT-DMS100_SN06_ADD_CHD

The Call Hold (CHD) option allows a subscriber with a 500/2500 set to hold a call.

Table 469: C_NT-DMS100_SN06_ADD_CHD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 470: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CHD	A_NT-DMS100_SN06_ADD_CHD

C_NT-DMS100_SN06_ADD_CIF

The Controlled Interflow (CIF) option allows a supervisor to place an automatic call distribution (ACD) group in a controlled interflow mode.

Table 471: C_NT-DMS100_SN06_ADD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
CONTROLLED_INTERFLOW_ACDGROUP	The name of the automatic call distribution group name. The name is a group identifier the user must datafill in Table ACDGRP.			S	R
CONTROLLED_INTERFLOW_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 472: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CIF	A_NT-DMS100_SN06_ADD_CIF

C_NT-DMS100_SN06_ADD_CIR

The Circular Hunt (CIR) option allows hunting to complete a full cycle through a Hunt group.

Table 473: C_NT-DMS100_SN06_ADD_CIR

Parameter Name	Description	Range	Default Value	Type	Class
CIRCULAR_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 474: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CIR	A_NT-DMS100_SN06_ADD_CIR

C_NT-DMS100_SN06_ADD_CLF

The Calling Line Identification with Flash (CLF) option allows a subscriber to hold an incoming call in the switch.

Table 475: C_NT-DMS100_SN06_ADD_CLF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 476: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CLF	A_NT-DMS100_SN06_ADD_CLF

C_NT-DMS100_SN06_ADD_CLI

Local and toll calls can stop on the line of the subscriber. If the calls stop, the Calling Line Identification (CLI) option records the following information on the DMS log system.

Table 477: C_NT-DMS100_SN06_ADD_CLI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACE_CLI_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 478: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CLI	A_NT-DMS100_SN06_ADD_CLI

C_NT-DMS100_SN06_ADD_CNAB

The CNAB option allows the system to block the delivery of the name of the caller.

Table 479: C_NT-DMS100_SN06_ADD_CNAB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 480: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CNAB	A_NT-DMS100_SN06_ADD_CNAB

C_NT-DMS100_SN06_ADD_CNAMD

The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE).

Table 481: C_NT-DMS100_SN06_ADD_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
CALLER_ID_NAME_DELIVERY_BILLING_OPTION	The billing option that the user must specify, when the user assigns the CNAMD.	AMA = AMA record created, NOAMA = AMA record not created		S	O
CALLER_ID_NAME_DELIVERY_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 482: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CNAMD	A_NT-DMS100_SN06_ADD_CNAMD

C_NT-DMS100_SN06_ADD_CND

The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is enabled.

Table 483: C_NT-DMS100_SN06_ADD_CND

Parameter Name	Description	Range	Default Value	Type	Class
CALLING_NUMBER_DELIVERY_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 484: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CND	A_NT-DMS100_SN06_ADD_CND

C_NT-DMS100_SN06_ADD_CND-NO-BILL

The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is disabled.

Table 485: C_NT-DMS100_SN06_ADD_CND-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 486: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CND-NO-BILL	A_NT-DMS100_SN06_ADD_CND-NO-BILL

C_NT-DMS100_SN06_ADD_CNDB

The Calling Number Delivery Blocking (CNDB) option blocks the delivery of the calling number.

Table 487: C_NT-DMS100_SN06_ADD_CNDB

Parameter Name	Description	Range	Default Value	Type	Class
CALLING_NUMBER_DELIVERY_BLOCKING_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O
CALLING_NUMBER_DELIVERY_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 488: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CNDB	A_NT-DMS100_SN06_ADD_CNDB

C_NT-DMS100_SN06_ADD_CNF

The Station Controlled Conference (CNF) option allows a station to have a conference call to a maximum of 30 parties.

Table 489: C_NT-DMS100_SN06_ADD_CNF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_CONTROLLED_CONFERENCE_CONF_TYPE	The maximum number of stations that can connect to a station controlled conference.			S	R
STATION_CONTROLLED_CONFERENCE_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 490: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CNF	A_NT-DMS100_SN06_ADD_CNF

C_NT-DMS100_SN06_ADD_COD

The Cutoff on Disconnect (COD) option applies an open battery signal to the line.

Table 491: C_NT-DMS100_SN06_ADD_COD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 492: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_COD	A_NT-DMS100_SN06_ADD_COD

C_NT-DMS100_SN06_ADD_COT

The COT option allows the recipient of a harassing call to request an automatic trace of the call. The billing option is enabled.

Table 493: C_NT-DMS100_SN06_ADD_COT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACER_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O

Table 493: C_NT-DMS100_SN06_ADD_COT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACER_KEYLIST	Specifies key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_TRACER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 494: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_COT	A_NT-DMS100_SN06_ADD_COT

C_NT-DMS100_SN06_ADD_COT-NO-BILL

The COT option allows the recipient of a harassing call to request an automatic trace of the call. The billing option is disabled.

Table 495: C_NT-DMS100_SN06_ADD_COT-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACER_NO_BILL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 496: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_COT-NO-BILL	A_NT-DMS100_SN06_ADD_COT-NO-BILL

C_NT-DMS100_SN06_ADD_CPU

The Call Pickup (CPU) option allows a station to answer incoming calls to another station in the same pickup group.

Table 497: C_NT-DMS100_SN06_ADD_CPU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_PICKUP_CPU_LEN	Indicates the CPU number.			S	R
CALL_PICKUP_OPT KEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 498: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CPU	A_NT-DMS100_SN06_ADD_CPU

C_NT-DMS100_SN06_ADD_CSMI

The CSMI feature allows end users of Network Based Answering Services (NBAS) to monitor and intercept calls that the NBAS handles.

Table 499: C_NT-DMS100_SN06_ADD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_SCREENING_CONNEC3W	The call interception (2-way call or 3-way call).		N	S	O
CALL_SCREENING_CSMIPPU	The billing option to use.		N	S	O
CALL_SCREENING_CSMISTATE	The state of the activation of the CSMI feature.			S	O
CALL_SCREENING_DENYOPT	The type of call forward for which CSMI is applied.			C	O
CALL_SCREENING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_SCREENING_SCRACTIVE	Indicates whether the SCRDUR parameter is required or not.		N	S	O
CALL_SCREENING_SCRDUR	The length of screening period.		20	S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 499: C_NT-DMS100_SN06_ADD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 500: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CSMI	A_NT-DMS100_SN06_ADD_CSMI

C_NT-DMS100_SN06_ADD_CUSD

The Call Forwarding Usage Sensitive Denial (CUSD) option prevents the use of the POTS Call Forwarding Usage Sensitive Pricing (CFUSP) option.

Table 501: C_NT-DMS100_SN06_ADD_CUSD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 502: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CUSD	A_NT-DMS100_SN06_ADD_CUSD

C_NT-DMS100_SN06_ADD_CWD

The Dial Call Waiting (CWD) option allows a business set user to impose call waiting on a busy station. The busy station can be a 500/2500 set or a business set with a call waiting (CWT) feature key.

Table 503: C_NT-DMS100_SN06_ADD_CWD

Parameter Name	Description	Range	Default Value	Type	Class
DIAL_CALL_WAITING_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 504: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CWD	A_NT-DMS100_SN06_ADD_CWD

C_NT-DMS100_SN06_ADD_CWI

The Call Waiting Intragroup (CWI) option allows a subscriber to apply the CWT option to intragroup calls, in addition to those allowed with CWT.

Table 505: C_NT-DMS100_SN06_ADD_CWI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 506: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CWI	A_NT-DMS100_SN06_ADD_CWI

C_NT-DMS100_SN06_ADD_CWO

The Call Waiting Originating (CWO) option allows an originating line to impose a call waiting tone automatically on a busy called line.

Table 507: C_NT-DMS100_SN06_ADD_CWO

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_ORIGINATING_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 508: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CWO	A_NT-DMS100_SN06_ADD_CWO

C_NT-DMS100_SN06_ADD_CWT

The Call Waiting (CWT) option allows the system to alert a busy station when an incoming call attempts to reach the directory number (DN).

Table 509: C_NT-DMS100_SN06_ADD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_CWT_OPTION	Indicates whether the CWT option is active.	Y = Yes, N = No		S	O
CALL_WAITING_KEYLIST	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature.	Key number (1-69), list of key numbers, or $		C	O
CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_WAITING_PCWT	Precedence call waiting.	Y = Yes, N = No		S	O
CALL_WAITING_RING	Specifies whether a ring from a telephone speaker is required in addition to the LCD diamond CWT key.	Y or N		S	O
DN	Directory number.			S	O

Table 509: C_NT-DMS100_SN06_ADD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 510: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CWT	A_NT-DMS100_SN06_ADD_CWT

C_NT-DMS100_SN06_ADD_CWX

The Call Waiting Exempt (CWX) option does not allow Dial Call Waiting (CWD) and Call Waiting Originating (CWO) to interrupt a business set user.

Table 511: C_NT-DMS100_SN06_ADD_CWX

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_EXEMPT_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 511: C_NT-DMS100_SN06_ADD_CWX

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 512: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CWX	A_NT-DMS100_SN06_ADD_CWX

C_NT-DMS100_SN06_ADD_CXR

The call transfer (CXR) option allows the assignment of a call transfer type other than the type that the customer group has.

Table 513: C_NT-DMS100_SN06_ADD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_METHOD	The method of call transfer.	Dial (DIAL), Standard (STD), or Release (RLS)		S	R
CALL_TRANSFER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Table 513: C_NT-DMS100_SN06_ADD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_ORGINTER	For a CUSTOM type call transfer, the first leg of the call is intergroup. The controller is the originator of the call.	AC = second leg of the call is to the attendant, Inter = second leg of the call can be intergroup, Intra = second leg of the call can be intragroup, Trater = second leg of the call can be intragroup or intergroup, Nocxfer = call transfer is not allowed		S	O
CALL_TRANSFER_ORGINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_RCL	Call transfer recall.			S	R
CALL_TRANSFER_RCLTIM	Recall timer for transfer recall.			S	O
CALL_TRANSFER_TRMINTER	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_TRMINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O

Table 513: C_NT-DMS100_SN06_ADD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_TYPE	Call transfer type.	CTOUT = call transfer outgoing calls, CTINC = call transfer incoming calls, CTINTRA = call transfer intra group, CTALL = call transfer all, NCT = the system routes the call to the attendant if the first leg of the call is INTERGROUP and the controller is terminator of the call, ATTRCLF = the system routes the call to the attendant at all times, CUSTOM = call transfer of types other than above		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 514: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_CXR	A_NT-DMS100_SN06_ADD_CXR

C_NT-DMS100_SN06_ADD_DCF

The Denied Call Forwarding (DCF) option does not allow a line to receive forwarded calls. This security option helps to protect computer ports.

Table 515: C_NT-DMS100_SN06_ADD_DCF

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_CALL_FORWARDING_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 516: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DCF	A_NT-DMS100_SN06_ADD_DCF

C_NT-DMS100_SN06_ADD_DCPU

The DCPU option allows a station to answer a ringing line in the same customer group before the called party answers the ringing line.

Table 517: C_NT-DMS100_SN06_ADD_DCPU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 518: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DCPU	A_NT-DMS100_SN06_ADD_DCPU

C_NT-DMS100_SN06_ADD_DDN

The Dialable Directory Number (DDN) option allows the customer premises equipment (CPE) to display the incoming calling name, number, and the time and date of the call.

Table 519: C_NT-DMS100_SN06_ADD_DDN

Parameter Name	Description	Range	Default Value	Type	Class
DIALABLE_DN_BILLING_OPTION	Specifies the billing option.	AMA = AMA record created, NOAMA = AMA record not created		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 520: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DDN	A_NT-DMS100_SN06_ADD_DDN

C_NT-DMS100_SN06_ADD_DENY

The DENY option prevents individual lines from gaining access to particular Custom Local Area Signaling Services (CLASS) features that are available using Universal Access (UA).

Table 521: C_NT-DMS100_SN06_ADD_DENY

Parameter Name	Description	Range	Default Value	Type	Class
DENY_ACCESS_CLASS_FEATURES_DENYOPT	Specifies the CLASS option to deny on switches.			C	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 522: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENY	A_NT-DMS100_SN06_ADD_DENY

C_NT-DMS100_SN06_ADD_DENYACB

The DENYAR option prevents the use of automatic call return feature.

Table 523: C_NT-DMS100_SN06_ADD_DENYACB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 524: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENYACB	A_NT-DMS100_SN06_ADD_DENYACB

C_NT-DMS100_SN06_ADD_DENYAR

The DENYAR option prevents the use of automatic recall feature.

Table 525: C_NT-DMS100_SN06_ADD_DENYAR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 525: C_NT-DMS100_SN06_ADD_DENYAR

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 526: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENYAR	A_NT-DMS100_SN06_ADD_DENYAR

C_NT-DMS100_SN06_ADD_DENYCOT

The DENYAR option prevents the use of call tracing feature.

Table 527: C_NT-DMS100_SN06_ADD_DENYCOT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 528: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENYCOT	A_NT-DMS100_SN06_ADD_DENYCOT

C_NT-DMS100_SN06_ADD_DENYCSMI

The DENYCSMI option prevents the user from activating option CSMI on the some types of Call Forwarding.

Table 529: C_NT-DMS100_SN06_ADD_DENYCSMI

Parameter Name	Description	Range	Default Value	Type	Class
DENY_CALL_SCREENING_DENYOPT	Specifies the type of call forwarding to which CSMI is applied.			C	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 530: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENYCSMI	A_NT-DMS100_SN06_ADD_DENYCSMI

C_NT-DMS100_SN06_ADD_DENYISA

The DENYISA option allows ISA end users to deactivate ISA for each call. Users dial the Cancel ISA (CISA) access code to deactivate ISA.

Table 531: C_NT-DMS100_SN06_ADD_DENYISA

Parameter Name	Description	Range	Default Value	Type	Class
DENY_IN_SESSION_ACTIVATION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 532: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENYISA	A_NT-DMS100_SN06_ADD_DENYISA

C_NT-DMS100_SN06_ADD_DENYU3WC

The DENYU3WC option prevents the use of the U3WC feature when U3WC is applied to a RES line or POTS line.

Table 533: C_NT-DMS100_SN06_ADD_DENYU3WC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 534: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DENYU3WC	A_NT-DMS100_SN06_ADD_DENYU3WC

C_NT-DMS100_SN06_ADD_DGT

The DGT option allows a telephone set to generate an address in the form of dual-tone multi-frequency signals.

Table 535: C_NT-DMS100_SN06_ADD_DGT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 536: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DGT	A_NT-DMS100_SN06_ADD_DGT

C_NT-DMS100_SN06_ADD_DIN

The DIN option prevents selected lines from receiving incoming calls that originate outside the customer group.

Table 537: C_NT-DMS100_SN06_ADD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_INCOMING_CALL_ALTTRC	Alternate terminating restriction code. This code applies to IBN extended calls. The value is in a format of a list in a series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DENIED_INCOMING_CALL_DINOPT	Assigns the Transfer Call to Restricted Station (DINE) sub-option to a line.	DINE = Accepts some types of transferred calls, N = Does not accept transferred calls		S	R
DENIED_INCOMING_CALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DENIED_INCOMING_CALL_TRC	Terminating restriction code used with the IBN DIN option. Code indicates the classes of incoming calls allowed on a trunk. The value is in a format of a list in series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DN	Directory number.			S	O

Table 537: C_NT-DMS100_SN06_ADD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 538: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DIN	A_NT-DMS100_SN06_ADD_DIN

C_NT-DMS100_SN06_ADD_DISP

The Display (DISP) option indicates that a business set on a PSET line is a display business set.

Table 539: C_NT-DMS100_SN06_ADD_DISP

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O

Table 539: C_NT-DMS100_SN06_ADD_DISP

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 540: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DISP	A_NT-DMS100_SN06_ADD_DISP

C_NT-DMS100_SN06_ADD_DNH

The Directory Number Hunt (DNH) option allows directory number hunting. Each line in the Hunt group has a directory number (DN).

Table 541: C_NT-DMS100_SN06_ADD_DNH

Parameter Name	Description	Range	Default Value	Type	Class
DIRECTORY_NUMBER_HUNT_DN	DN of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_GROUPSIZE	Hunt group size. The expected maximum size of the Hunt group.			S	O

Table 541: C_NT-DMS100_SN06_ADD_DNH

Parameter Name	Description	Range	Default Value	Type	Class
DIRECTORY_NUMBER_HUNT_LINE	LINE of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_NPA	NPA of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_NXX	NXX of a new member to be added to a Hunt group. This prompt appears when the ADD command is used.			S	O
DIRECTORY_NUMBER_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 542: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DNH	A_NT-DMS100_SN06_ADD_DNH

C_NT-DMS100_SN06_ADD_DOR

The Denied Origination (DOR) option prevents a line from originating calls. If the user attempts to originate a call from that line, the call receives originating suspended service (ORSS) treatment.

Table 543: C_NT-DMS100_SN06_ADD_DOR

Parameter Name	Description	Range	Default Value	Type	Class
DENY_ORIGINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 544: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DOR	A_NT-DMS100_SN06_ADD_DOR

C_NT-DMS100_SN06_ADD_DQS

The Display Queue Status (DQS) option allows an ACD supervisor to display the load status information for an ACD group.

Table 545: C_NT-DMS100_SN06_ADD_DQS

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_STATUS_ACDGROUP	A group identifier already in Table ACDGRP.			S	R
DISPLAY_QUEUE_STATUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 546: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DQS	A_NT-DMS100_SN06_ADD_DQS

C_NT-DMS100_SN06_ADD_DQT

The Display Queue Threshold (DQT) option allows the system to display the status of the incoming call queue. The status of the queue appears when the ACD agent or supervisor presses the associated key of the set.

Table 547: C_NT-DMS100_SN06_ADD_DQT

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_THRESHOLD_DIFFGRP	Indicates if the system uses a group other than the ACD INCALLS group to establish the queue threshold status.			S	R
DISPLAY_QUEUE_THRESHOLD_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 548: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DQT	A_NT-DMS100_SN06_ADD_DQT

C_NT-DMS100_SN06_ADD_DRCW

The Distinctive Ringing/Call Waiting (DRCW) option allows the system to identify terminating calls with a distinct alert pattern.

Table 549: C_NT-DMS100_SN06_ADD_DRCW

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_CALL_WAITING_BILLING_OPTION	The specified billing option, when the user assigns the CND or COT option to a RES line.	AMA=recorded, NOAMA=not recorded, or $		S	O
DISTINCTIVE_RING_CALL_WAITING_DNS	Directory number the user adds to the SCRJ list.			C	O
DISTINCTIVE_RING_CALL_WAITING_LINE	The LINE the user adds to the SCRJ list.			C	O
DISTINCTIVE_RING_CALL_WAITING_NPA	The NPA the user adds to the SCRJ list.			C	O
DISTINCTIVE_RING_CALL_WAITING_NXX	The NXX the user adds to the SCRJ list.			C	O

Table 549: C_NT-DMS100_SN06_ADD_DRCW

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_CALL_WAITING_STATUS	INACT indicates that the user did not enable the option (not active). ACT indicates that the user enabled the option (active). UNIVI indicates that universal access through customer interface is not active. UNIVA indicates that universal access through customer interface is active.			S	R
DISTINCTIVE_RING_CALL_WAITING_VBCOUNT	The number of digits that voice back during SCRJ list review.			C	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 550: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DRCW	A_NT-DMS100_SN06_ADD_DRCW

C_NT-DMS100_SN06_ADD_DRING

The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types.

Table 551: C_NT-DMS100_SN06_ADD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_ACD	Automatic call distribution.			S	R
DISTINCTIVE_RING_ACD_DRINGTYPE	Ring type.			S	O
DISTINCTIVE_RING_EXTRNL	External calls.			S	R
DISTINCTIVE_RING_EXTRNL_DRINGTYPE	Ring type.			S	O
DISTINCTIVE_RING_GIC	Group intercom.			S	R
DISTINCTIVE_RING_GIC_DRINGTYPE	Ring type.			S	O
DISTINCTIVE_RING_INTRNL	Indicates that intragroup calls have distinctive ringing.			S	R
DISTINCTIVE_RING_INTRNL_DRINGTYPE	Ring type.			S	O
DISTINCTIVE_RING_MAKECALL	Indicates distinctive ringing for outbound calls at customer group level.			S	O
DISTINCTIVE_RING_MAKECALL_DRINGTYPE	Ring type.			S	O

Table 551: C_NT-DMS100_SN06_ADD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISTINCTIVE_RING_RECALL	Recall ringing.			S	R
DISTINCTIVE_RING_RECALL_DRINGTYPE	Ring type.			S	O
DISTINCTIVE_RING_REST	Call types that remain.			S	R
DISTINCTIVE_RING_REST_DRINGTYPE	Ring type.			S	O
DISTINCTIVE_RING_TRKS	IBN trunks.	SEL = selected trunks, ALL = all trunks, NO = no trunks		S	R
DISTINCTIVE_RING_UCD	Uniform call distribution			S	R
DISTINCTIVE_RING_UCD_DRINGTYPE	Ring type.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 552: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DRING	A_NT-DMS100_SN06_ADD_DRING

C_NT-DMS100_SN06_ADD_DSCWID

Deluxe Spontaneous Call Waiting Identification (DSCWID) allows the subscriber to receive calling-party information during call waiting.

Table 553: C_NT-DMS100_SN06_ADD_DSCWID

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_OPTIONS_DAMAOPT	The type of AMA recording the system uses with the CONFERENCE option. Enter NONE for no recording or CONF to generate an AMA billing record.			C	O
CALL_WAITING_OPTIONS_DEFTRMTOPT	The default treatment that is applied when a DSCWID option is not specified.			C	O
CALL_WAITING_OPTIONS_DSUBOPT	The DSCWID suboption to be assigned. The DSWOPT is a vector that is a maximum of three suboptions. If the suboptions are not entered, the default values are used.	DTYPE, DAMA, DEFTRMT		C	O

Table 553: C_NT-DMS100_SN06_ADD_DSCWID

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_OPTIONS_DTYPEOPT	The DSCWID type name that indicates which DSCWID type to assign from table DSCWDTYP. Additional values are possible if tuples are datafilled in table DSCWDTYP.			C	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 554: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DSCWID	A_NT-DMS100_SN06_ADD_DSCWID

C_NT-DMS100_SN06_ADD_DTM

The DTM option prevents a line from receiving calls. Calls that attempt to terminate to a line with the DTM option, receive denied terminating (DNTR) treatment.

Table 555: C_NT-DMS100_SN06_ADD_DTM

Parameter Name	Description	Range	Default Value	Type	Class
DENY_TERMINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 556: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DTM	A_NT-DMS100_SN06_ADD_DTM

C_NT-DMS100_SN06_ADD_ELN

The essential line (ELN) option designates a line as essential.

Table 557: C_NT-DMS100_SN06_ADD_ELN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
ESSENTIAL_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 558: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ELN	A_NT-DMS100_SN06_ADD_ELN

C_NT-DMS100_SN06_ADD_EMW

The Executive Message Waiting (EMW) option introduces a message waiting class of service (MCOS) to enhance the message waiting option. A user can only access the MCOS to which the user subscribes.

Table 559: C_NT-DMS100_SN06_ADD_EMW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
EXECUTIVE_MESSAGE_WAIT_DNLIST	A DN key that subscribes to an MCOS. Specify one key for each MCOS.	1-69		C	O
EXECUTIVE_MESSAGE_WAIT_MCOS	The name of the MCOS the MDC line subscribes, or the key set.			C	O
EXECUTIVE_MESSAGE_WAIT_NOTICE	Message waiting notification.	STD = stuttered dial tone, MWL = message waiting lamp, CMWI = CLASS message waiting Indicator, PRN = periodic ring notification		S	O
EXECUTIVE_MESSAGE_WAIT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 560: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_EMW	A_NT-DMS100_SN06_ADD_EMW

C_NT-DMS100_SN06_ADD_ESL

The Emergency Service Line (ESL) allows a line for emergency service to be designated.

Table 561: C_NT-DMS100_SN06_ADD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
EMERGENCY_SERVICE_LINE_FASTFLASH	An option for emergency service office lines.Usually N is used. The Y is entered if the emergency service bureau is equipped with an SP-1 console or equivalent that has the ability to generate an 80-ms flash.			S	R
EMERGENCY_SERVICE_LINE_FORCED_DISCONNECT_TIME	Option used with an emergency service office line. The timing in seconds, longer than a 2 s flash, after which the call disconnects and the emergency service line goes on-hook.			S	R
EMERGENCY_SERVICE_LINE_INTEG_TONE	The integrity tone type.			S	R

Table 561: C_NT-DMS100_SN06_ADD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
EMERGENCY_SERVICE_LINE_INTEG_TONE_TIME	The interval in seconds after which the system generates an alarm and logs a report when an ESL line is off-hook.			S	R
EMERGENCY_SERVICE_LINE_RINGBACK	Option used with an emergency service office line to enable the office to ring back a caller who goes on-hook.			S	R
EMERGENCY_SERVICE_LINE_ROH_TONE_TIME	An emergency service office line option parameter; the duration in seconds of the receiver off-hook tone a caller receives when the ESL flashes.			S	R
EMERGENCY_SERVICE_LINE_SWITCHHOOK_TONE	The tone the emergency service office line receives when a caller goes on-hook.	LOW=steady low tone, BUSY=60 interruptions per minute (IPM) busy tone		S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 562: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ESL	A_NT-DMS100_SN06_ADD_ESL

C_NT-DMS100_SN06_ADD_FAA

The Forced Agent Availability (FAA) option allows an ACD (Automatic Call Distribution) supervisor to force an ACD agent from the Not Ready to the Ready state.

Table 563: C_NT-DMS100_SN06_ADD_FAA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
FORCED_AGENT_AVAILABILITY_ACDGROUP	A group identifier already in Table ACDGRP.			S	R
FORCED_AGENT_AVAILABILITY_EXTNDFAA	Extended forced agent availability.Indicates if the feature is valid for ACD agents in any ACD group and subgroup in the same customer group as the supervisor.			S	R
FORCED_AGENT_AVAILABILITY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 563: C_NT-DMS100_SN06_ADD_FAA

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 564: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_FAA	A_NT-DMS100_SN06_ADD_FAA

C_NT-DMS100_SN06_ADD_FANI

The Flexible Automatic Number ID (FANI) option allows an operating company to assign special-purpose Automatic Number Identification (ANI) information digits to a line.

Table 565: C_NT-DMS100_SN06_ADD_FANI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
FANI_OPTION_FANI_DIGITS	Digits for the FANI option.	Two digits (00-99)		S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 566: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_FANI	A_NT-DMS100_SN06_ADD_FANI

C_NT-DMS100_SN06_ADD_FEATURES

Adds options to assigned single-line and multiline telephone sets, to Hunt group lines, and to proprietary business sets.

Table 567: C_NT-DMS100_SN06_ADD_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	Directory number.			S	O
IS_OPTIMIZED	A flag to indicate MML optimization of the command.	true or false	true	S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 567: C_NT-DMS100_SN06_ADD_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
OPT	Options associated with a service you are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 568: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_FEATURES	A_NT-DMS100_SN06_ADD_FEATURES

C_NT-DMS100_SN06_ADD_FTRGRP

The FTRGRP option allows the operating company to define a number of features as a feature group. The feature group can be assigned to customer lines.

Table 569: C_NT-DMS100_SN06_ADD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
FEATURE_GROUP_ GRPNAME	The name of the feature group with a minimum of one feature.			S	R
FEATURE_GROUP_ OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Table 569: C_NT-DMS100_SN06_ADD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 570: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_FTRGRP	A_NT-DMS100_SN06_ADD_FTRGRP

C_NT-DMS100_SN06_ADD_GIC

The GIC option allows call termination on a member of a designated intercom group that uses abbreviated dialing. Use abbreviated dialing to access group members.

Table 571: C_NT-DMS100_SN06_ADD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
GROUP_INTERCOM_GICMEMNO	Digits dialed to reach this line.			S	R
GROUP_INTERCOM_GICNAME	Designated name of group intercom line			S	R

Table 571: C_NT-DMS100_SN06_ADD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
GROUP_INTERCOM _GICNOMSB	Group intercom calls not included in MSB.			S	R
GROUP_INTERCOM _GICSMDR	SMDR records required.			S	R
GROUP_INTERCOM _OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 572: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_GIC	A_NT-DMS100_SN06_ADD_GIC

C_NT-DMS100_SN06_ADD_GND

The GND option assigns ground signal to the line and allow consistency to be checked on ground start lines.

Table 573: C_NT-DMS100_SN06_ADD_GND

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 574: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_GND	A_NT-DMS100_SN06_ADD_GND

C_NT-DMS100_SN06_ADD_HOT

This feature is placed on lines in hotel or motel. It allows the hotel to bill each room for call charges.

Table 575: C_NT-DMS100_SN06_ADD_HOT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 575: C_NT-DMS100_SN06_ADD_HOT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 576: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_HOT	A_NT-DMS100_SN06_ADD_HOT

C_NT-DMS100_SN06_ADD_ICM

The ICM option allows a business set user to directly terminate upon a predesignated business set by pressing the ICM feature key.

Table 577: C_NT-DMS100_SN06_ADD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTERCOM_BUSINESS_SET_DOR	Denied origination.			S	R

Table 577: C_NT-DMS100_SN06_ADD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
INTERCOM_BUSINESS_SET_LINK_LEN	The LEN of a member of an existing DLH or MLH Hunt group to which additional members are to be linked.			S	R
INTERCOM_BUSINESS_SET_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
INTERCOM_BUSINESS_SET_SIC_KEY	Straight intercom key.			S	R
INTERCOM_BUSINESS_SET_SMDR	Station message detail recording.			S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 578: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ICM	A_NT-DMS100_SN06_ADD_ICM

C_NT-DMS100_SN06_ADD_INSPECT

The INSPECT option displays the information on feature/DN keys and incoming calls to a DN. This option also provides information on the Call Waiting key and Intercom key without answering the call.

Table 579: C_NT-DMS100_SN06_ADD_INSPECT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INSPECT_KEY_OPT KEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 580: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_INSPECT	A_NT-DMS100_SN06_ADD_INSPECT

C_NT-DMS100_SN06_ADD_INT

The Intercom (INT) option allows the subscriber to dial an access code and ring all the extensions of that DN. The subscriber can speak to the persons who answer these extensions.

Table 581: C_NT-DMS100_SN06_ADD_INT

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	Name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 582: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_INT	A_NT-DMS100_SN06_ADD_INT

C_NT-DMS100_SN06_ADD_INTPIC

Line option INTPIC allows subscribers of Equal End Offices (EQEO) to designate a carrier for international calls. This option is valid for POTS, COIN, RES,IBN and KSET lines.

Table 583: C_NT-DMS100_SN06_ADD_INTPIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 583: C_NT-DMS100_SN06_ADD_INTPIC

Parameter Name	Description	Range	Default Value	Type	Class
INTL_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTL_PIC_CHOICE	Indicates whether the subscriber is allowed to casually dial Intra-LATA calls.	Y or N		S	R
INTL_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 584: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_INTPIC	A_NT-DMS100_SN06_ADD_INTPIC

C_NT-DMS100_SN06_ADD_KSH

The Key Short Hunt (KSH) option allows incoming calls to search for an idle directory number (DN) on which to terminate. The options search for this DN occurs through a set of DN appearances on a business set.

Table 585: C_NT-DMS100_SN06_ADD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
KEY_SHORT_HUNT _KEYLIST	Appears when an assignment of a subset feature to a multiline set occurs. Specifies key numbers of the DNs to which a feature will apply.			C	O
KEY_SHORT_HUNT _KSH_KEY	The line Hunt overflow route index that identifies the overflow route. The index identifies the key on business set or data unit. The index indicates the route reference number when Route (R) is the overflow for the KSH option.			S	O
KEY_SHORT_HUNT _OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
KEY_SHORT_HUNT _OVDN	The overflow directory number for the KSH option when the OVTYPE is D.			S	O
KEY_SHORT_HUNT _OVTYPE	Type of overflow required when short Hunt group is busy.	N = no overflow, D = DN to which overflow is to go, R = route		S	R

Table 585: C_NT-DMS100_SN06_ADD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
KEY_SHORT_HUNT _TABID	A table identifier associated with the line overflow to a route (LOR) and KSH options.	OFRT = Office Route Reference Table, IBNRTE = IBN Route Reference Table		S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 586: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_KSH	A_NT-DMS100_SN06_ADD_KSH

C_NT-DMS100_SN06_ADD_LCDR

The Local Call Detail Recording (LCDR) option allows billing for local calls to correspond to conversation time.

Table 587: C_NT-DMS100_SN06_ADD_LCDR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 587: C_NT-DMS100_SN06_ADD_LCDR

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LOCAL_CALL_DETAILED_REPORTING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 588: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LCDR	A_NT-DMS100_SN06_ADD_LCDR

C_NT-DMS100_SN06_ADD_LDSA

The long distance signal activate (LDSA) line option allows the end user to activate or deactivate Long Distance Alerting (LDA) on a line.

Table 589: C_NT-DMS100_SN06_ADD_LDSA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 589: C_NT-DMS100_SN06_ADD_LDSA

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 590: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LDSA	A_NT-DMS100_SN06_ADD_LDSA

C_NT-DMS100_SN06_ADD_LDSO

The Long Distance Signal Option (LDSO) option provides Long Distance Alerting (LDA) subscribers with a different ring and a different tone.

Table 591: C_NT-DMS100_SN06_ADD_LDSO

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 591: C_NT-DMS100_SN06_ADD_LDSO

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 592: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LDSO	A_NT-DMS100_SN06_ADD_LDSO

C_NT-DMS100_SN06_ADD_LNR

The LNR option allows a subscriber to redial the last number dialed. The subscriber uses a single key instead of the full number to redial the last number dialed.

Table 593: C_NT-DMS100_SN06_ADD_LNR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LAST_NUMBER_REDIAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 594: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LNR	A_NT-DMS100_SN06_ADD_LNR

C_NT-DMS100_SN06_ADD_LNRA

The Last Number Redial Associated with Set (LNRA) option allows a set to access any free Directory Number (DN) on the set. When the user activates the option, the last number the user dialed from the set dials again.

Table 595: C_NT-DMS100_SN06_ADD_LNRA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LAST_NUMBER_REDIAL_ASSOCIATED_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 596: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LNRA	A_NT-DMS100_SN06_ADD_LNRA

C_NT-DMS100_SN06_ADD_LOB

The Line of Business (LOB) option allows an Automatic Call Distribution (ACD) agent to enter a three-digit code for each call. Entering the code pegs a register for that LOB or type of call.

Table 597: C_NT-DMS100_SN06_ADD_LOB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LINE_OF_BUSINESS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 598: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LOB	A_NT-DMS100_SN06_ADD_LOB

C_NT-DMS100_SN06_ADD_LOD

The Line overflow to DN (LOD) option allows subscriber to route to specific DN when all Hunt group members are busy.

Table 599: C_NT-DMS100_SN06_ADD_LOD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_OVERFLOW_DN	The DN to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_LINE	The LINE to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_NPA	The NPA to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_NXX	The NXX to which calls route when all Hunt group members are busy.			S	O
CALL_FORWARD_BUSY_OVERFLOW_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O

Table 599: C_NT-DMS100_SN06_ADD_LOD

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 600: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LOD	A_NT-DMS100_SN06_ADD_LOD

C_NT-DMS100_SN06_ADD_LPIC

Option Intra-LATA PIC (LPIC) allows the user to choose a primary carrier for Intra-LATA service. Field LCHOICE allows subscribers to dial Intra-LATA calls on a casual basis.

Table 601: C_NT-DMS100_SN06_ADD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTRA_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R

Table 601: C_NT-DMS100_SN06_ADD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
INTRA_PIC_CHOICE	Indicates whether the subscriber is allowed to casually dial Intra-LATA calls.	Y or N		S	R
INTRA_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 602: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LPIC	A_NT-DMS100_SN06_ADD_LPIC

C_NT-DMS100_SN06_ADD_LVM

The Leave Message (LVM) option provides key access to message waiting (MWT), call request (CAR), and executive message waiting (EMW).

Table 603: C_NT-DMS100_SN06_ADD_LVM

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEAVE_MESSAGE_ OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 604: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LVM	A_NT-DMS100_SN06_ADD_LVM

C_NT-DMS100_SN06_ADD_M518

The 18-Button Add-On for Meridian M5000 Series (M518) option allows the addition of an 18-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set.

Table 605: C_NT-DMS100_SN06_ADD_M518

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
M518_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
M518_QUANTITY	Indicates the number of M518 add-on units for a M5000 set.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 606: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_M518	A_NT-DMS100_SN06_ADD_M518

C_NT-DMS100_SN06_ADD_M536

The 36-Button Add-On for Meridian M5000 Series (M536) option allows the addition of a 36-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set.

Table 607: C_NT-DMS100_SN06_ADD_M536

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
M536_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 608: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_M536	A_NT-DMS100_SN06_ADD_M536

C_NT-DMS100_SN06_ADD_MDN

The MDN option assigns a DN to more than one set. A multiple appearance directory number (MADN) is a directory number (DN) hat appears on more than one Meridian business set (MBS).

Table 609: C_NT-DMS100_SN06_ADD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MULTIPLE_APPEARANCE_DN_DIR_NUMBER	The directory number.			S	R
MULTIPLE_APPEARANCE_DN_MDNTYPE	The type of call arrangement.	MCA=multiple call arrangement, SCA=single call arrangement, EXB=extension bridging		S	R
MULTIPLE_APPEARANCE_DN_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
MULTIPLE_APPEARANCE_DN_PRIMARY	Primary member of an MADN group.			S	R
MULTIPLE_APPEARANCE_DN_RING	Whether ringing is required.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 610: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_MDN	A_NT-DMS100_SN06_ADD_MDN

C_NT-DMS100_SN06_ADD_MSB

The MSB option allows each IBN station to appear busy to incoming calls.

Table 611: C_NT-DMS100_SN06_ADD_MSB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MAKE_SET_BUSY_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 612: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_MSB	A_NT-DMS100_SN06_ADD_MSB

C_NT-DMS100_SN06_ADD_MSBI

The Make Set Busy Intragroup (MSBI) option allows each IBN station to appear busy to incoming calls. The system applies a temporary splash of ringing (500 ms) to the line to inform the station user of a diverted incoming call.

Table 613: C_NT-DMS100_SN06_ADD_MSBI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MAKE_SET_BUSY_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 614: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_MSBI	A_NT-DMS100_SN06_ADD_MSBI

C_NT-DMS100_SN06_ADD_MWT

The MWT option allows a message center to inform a user that there is a message.

Table 615: C_NT-DMS100_SN06_ADD_MWT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MESSAGE_WAITING_INDICATOR_CAR	Call request option.			S	R
MESSAGE_WAITING_INDICATOR_CMWIRING	When CMWIRING is set to Y, subscribers can dial an access code. This code allows the subscriber to activate or deactivate ringing that precedes a lamp activation message.			S	O
MESSAGE_WAITING_INDICATOR_CMWISTD	When CMWISTD is set to Y, subscribers are allowed to dial an access code to activate or deactivate a stuttered dial tone.	Y = stuttered dial tone is activated. N = No stuttered dial tone		S	O

Table 615: C_NT-DMS100_SN06_ADD_MWT

Parameter Name	Description	Range	Default Value	Type	Class
MESSAGE_WAITING_INDICATOR_CRRCFW	Call request retrieve call forwarding. Specifies how the system handles forwarding if a subscriber activates the Call Request Retrieve (CRR) feature to return a call to the subscriber that left the message. Note: The CRRCFW is required only if CAR is set to Y.			S	O
MESSAGE_WAITING_INDICATOR_CRX	Call request not required.			S	R
MESSAGE_WAITING_INDICATOR_IRN	Immediate ring notification; this prompt appears only if PRN or CMWI is selected as the message waiting notification (NOTICE prompt) and input to the CRN prompt is Y.			S	O
MESSAGE_WAITING_INDICATOR_NOTICE	Message waiting notification.	STD = stuttered dialtone, MWL = message waiting lamp, CMWI = CLASS message waiting indicator, PRN = periodic ring notification		S	O
MESSAGE_WAITING_INDICATOR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Table 615: C_NT-DMS100_SN06_ADD_MWT

Parameter Name	Description	Range	Default Value	Type	Class
MESSAGE_WAITING_INDICATOR_STATUS	When the CMWIRING is set to UDLC, the system does not prompt for the status field.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 616: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_MWT	A_NT-DMS100_SN06_ADD_MWT

C_NT-DMS100_SN06_ADD_NAME

The system uses NAME feature to assign a name to DN.

Table 617: C_NT-DMS100_SN06_ADD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NAME_DISPLAYNAME	Name to display on MBS set.			S	R

Table 617: C_NT-DMS100_SN06_ADD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
NAME_NETNAME	Network name shown as DN attribute.			S	R
NAME_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 618: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_NAME	A_NT-DMS100_SN06_ADD_NAME

C_NT-DMS100_SN06_ADD_NDC

The No Double Connect (NDC) option prevents a line from being connected to a verification or test circuit when the line is off-hook.

Table 619: C_NT-DMS100_SN06_ADD_NDC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 619: C_NT-DMS100_SN06_ADD_NDC

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NO_DOUBLE_CONNECT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 620: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_NDC	A_NT-DMS100_SN06_ADD_NDC

C_NT-DMS100_SN06_ADD_NFA

The Network Facility Access (NFA) provides a direct connection through the DMS-100 switch.

Table 621: C_NT-DMS100_SN06_ADD_NFA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 621: C_NT-DMS100_SN06_ADD_NFA

Parameter Name	Description	Range	Default Value	Type	Class
NETWORK_FACILITY_ACCESS_AMA_EXPLCT	Controls the AMA billing record generation that follows an explicit connection.		N	S	O
NETWORK_FACILITY_ACCESS_AMA_IPDIAL	Controls the AMA billing record generation that follows an IP dialed connection.		N	S	O
NETWORK_FACILITY_ACCESS_AMA_REM	Controls the AMA billing record generation that follows a remote connection.		N	S	O
NETWORK_FACILITY_ACCESS_EXPLCT_ACC	Specifies whether the line is assigned explicit access.		Y	S	O
NETWORK_FACILITY_ACCESS_IMPLCT_ACC	Specifies whether the line is allowed implicit access.		Y	S	O
NETWORK_FACILITY_ACCESS_NFRA_PIN	The remote access PIN. This is required if REM_ACC is set to Y.			S	O
NETWORK_FACILITY_ACCESS_OPTKEY	A key on a business set or data unit to which the feature is assigned.		1	S	O
NETWORK_FACILITY_ACCESS_REM_ACC	Specifies whether the line is allowed remote access.		N	S	O
NETWORK_FACILITY_ACCESS_USER_ID	The user ID for the line to which the user adds the NFA option.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 621: C_NT-DMS100_SN06_ADD_NFA

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 622: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_NFA	A_NT-DMS100_SN06_ADD_NFA

C_NT-DMS100_SN06_ADD_NGTSRVCE

The Night Service (NGTSRVCE) option allows the ACD supervisor to place all ACD agent sets in an ACD group in night service mode. The ACD supervisor presses the Night Service key on the supervisor set to place the ACD agent sets in night service modes.

Table 623: C_NT-DMS100_SN06_ADD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NIGHT_SERVICE_ACDGROUP	A group identifier that the user already entered in Table ACDGRP. The identifier is the name of the automatic call distribution group to which this station belongs.			S	O

Table 623: C_NT-DMS100_SN06_ADD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
NIGHT_SERVICE_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 624: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_NGTSRVCE	A_NT-DMS100_SN06_ADD_NGTSRVCE

C_NT-DMS100_SN06_ADD_NLT

The No Line Insulation Test (NLT) option allows the automatic line insulation test to skip a line.

Table 625: C_NT-DMS100_SN06_ADD_NLT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 625: C_NT-DMS100_SN06_ADD_NLT

Parameter Name	Description	Range	Default Value	Type	Class
NO_LINE_INSULATION_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 626: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_NLT	A_NT-DMS100_SN06_ADD_NLT

C_NT-DMS100_SN06_ADD_OBS

The Observe Agent (OBS) option allows a supervisor to observe conversations between an agent and a caller. This user presses the OBS key to observe conversations between an agent and a caller.

Table 627: C_NT-DMS100_SN06_ADD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 627: C_NT-DMS100_SN06_ADD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OBSERVE_AGENT_ ACDGROUP	A group identifier that Table ACDGRP must already contain. The group identifier is the name of the automatic call distribution group to which this station belongs.			S	O
OBSERVE_AGENT_ DN	Specifies an ACD directory number.Appears if FOBSTYPE = DN.			S	O
OBSERVE_AGENT_F OBSTYPE	Appears if OBSTYPE is set to FOBS. Specifies the type of flexible call observing required.			S	O
OBSERVE_AGENT_F OBS_ACDGROUP	Appears if OBSTYPE is set to FOBS.			S	O
OBSERVE_AGENT_F OBS_SUBGROUP	Specifies an ACD subgroup number. Appears if FOBSTYPE = SUBGROUP.			S	O
OBSERVE_AGENT_ OBSTYPE	The type of observation a supervisor can apply over incoming ACD calls: basic, extended, or flexible call observing.			S	R

Table 627: C_NT-DMS100_SN06_ADD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
OBSERVE_AGENT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 628: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_OBS	A_NT-DMS100_SN06_ADD_OBS

C_NT-DMS100_SN06_ADD_ONI

The Operator Number Identification (ONI) option directs calls to an operator for identification of the calling number when the switch cannot provide this information.

Table 629: C_NT-DMS100_SN06_ADD_ONI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 629: C_NT-DMS100_SN06_ADD_ONI

Parameter Name	Description	Range	Default Value	Type	Class
OPERATOR_NUMBER_IDENTIFICATION_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 630: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_ONI	A_NT-DMS100_SN06_ADD_ONI

C_NT-DMS100_SN06_ADD_PIC

Option Primary Inter-LATA Carrier (PIC) assigns a PIC to an MDC line.

Table 631: C_NT-DMS100_SN06_ADD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTER_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTER_PIC_CHOICE	Specifies whether the system allows the user to dial 10xxx to access other carriers.	Y or N		S	R
INTER_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O

Table 631: C_NT-DMS100_SN06_ADD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 632: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_PIC	A_NT-DMS100_SN06_ADD_PIC

C_NT-DMS100_SN06_ADD_PORT

The PORT option allows ten-digit complete LNP triggering for a directory number (DN).

Table 633: C_NT-DMS100_SN06_ADD_PORT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LOCAL_NUMBER_PORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 633: C_NT-DMS100_SN06_ADD_PORT

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 634: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_PORT	A_NT-DMS100_SN06_ADD_PORT

C_NT-DMS100_SN06_ADD_PRK

The PRK option allows a business set user to park a call against the directory number (DN) of the user. Retrieval of the parked call can occur from any station. When the call is parked, the user can originate and receive calls on that DN.

Table 635: C_NT-DMS100_SN06_ADD_PRK

Parameter Name	Description	Range	Default Value	Type	Class
CALL_PARK_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 635: C_NT-DMS100_SN06_ADD_PRK

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 636: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_PRK	A_NT-DMS100_SN06_ADD_PRK

C_NT-DMS100_SN06_ADD_PRL

The PRL option is available to single call announcement (SCA) multiple appearance directory number (MADN) users.

Table 637: C_NT-DMS100_SN06_ADD_PRL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 637: C_NT-DMS100_SN06_ADD_PRL

Parameter Name	Description	Range	Default Value	Type	Class
PRIVACY_RELEASE_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 638: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_PRL	A_NT-DMS100_SN06_ADD_PRL

C_NT-DMS100_SN06_ADD_QTD

The QTD option allows a display business set to display the current time and date. The user presses the QTD key and the current time and date display for 15 seconds. When another action that uses the display is activated, the time and date display stops.

Table 639: C_NT-DMS100_SN06_ADD_QTD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 639: C_NT-DMS100_SN06_ADD_QTD

Parameter Name	Description	Range	Default Value	Type	Class
QUERY_TIME_DATE_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 640: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_QTD	A_NT-DMS100_SN06_ADD_QTD

C_NT-DMS100_SN06_ADD_RAG

The QTD option allows a display business set to display the current time and date. The user presses the QTD key and the current time and date display for 15 seconds. When another action that uses the display is activated, the time and date display stops.

Table 641: C_NT-DMS100_SN06_ADD_RAG

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 641: C_NT-DMS100_SN06_ADD_RAG

Parameter Name	Description	Range	Default Value	Type	Class
RING_AGAIN_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 642: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RAG	A_NT-DMS100_SN06_ADD_RAG

C_NT-DMS100_SN06_ADD_RCHD

The RCHD option allows a subscriber to place a call on hold for up to three minutes. The call can be one that the subscriber originated or one that the subscriber received.

Table 643: C_NT-DMS100_SN06_ADD_RCHD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 644: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RCHD	A_NT-DMS100_SN06_ADD_RCHD

C_NT-DMS100_SN06_ADD_RMI

The RMI option allows subscribers of the Message Waiting (MWT) feature to check for the existence of messages in their voice mailbox from a remote location.

Table 645: C_NT-DMS100_SN06_ADD_RMI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
REMOTE_MESSAGE_INDICATOR_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
REMOTE_MESSAGE_INDICATOR_RMI_STATE	The state of the RMI feature.	active or inactive		S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 646: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RMI	A_NT-DMS100_SN06_ADD_RMI

C_NT-DMS100_SN06_ADD_RMR

The RMR option is assigned to lines that are equipped with a remote hardware message register activated by reverse battery.

Table 647: C_NT-DMS100_SN06_ADD_RMR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 648: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RMR	A_NT-DMS100_SN06_ADD_RMR

C_NT-DMS100_SN06_ADD_RMT

The RMT option is assigned to lines that are equipped with a remote hardware message register activated by reverse battery. The RMT option is used on a hotel line to indicate that a charge is due for non-local calls.

Table 649: C_NT-DMS100_SN06_ADD_RMT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 650: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RMT	A_NT-DMS100_SN06_ADD_RMT

C_NT-DMS100_SN06_ADD_RPA

The RPA option allows up to seven additional alert tones to a business set when a call terminates on a DN, MADN, GIC, or ACD key and the set is already active on another key.

Table 651: C_NT-DMS100_SN06_ADD_RPA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 651: C_NT-DMS100_SN06_ADD_RPA

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
REPEATED_ALERT_ OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 652: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RPA	A_NT-DMS100_SN06_ADD_RPA

C_NT-DMS100_SN06_ADD_RSP

The RSP option is assigned to lines that have LCCs of ZMD or ZMZPA. This option causes the ANI information digit 7 (coinless pay station identification) plus the calling party's DN to be outpulsed.

Table 653: C_NT-DMS100_SN06_ADD_RSP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 653: C_NT-DMS100_SN06_ADD_RSP

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
RESTRICTED_SENT_PAID_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 654: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RSP	A_NT-DMS100_SN06_ADD_RSP

C_NT-DMS100_SN06_ADD_RSUS

The RSUS option is assigned when the subscriber requests suspension of service. When the RSUS option is assigned, the treatments to which originations from and terminations to the subscriber line are to be routed must be specified.

Table 655: C_NT-DMS100_SN06_ADD_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 655: C_NT-DMS100_SN06_ADD_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
REQUESTED_SUSPENSION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
REQUESTED_SUSPENSION_ORIG_SUS	Originating suspension; the treatment to which the subscriber is routed on origination of a call.			S	R
REQUESTED_SUSPENSION_TERM_SUS	Terminating suspension; the treatment to which a call is routed when attempting to terminate to a line with the RSUS option.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 656: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_RSUS	A_NT-DMS100_SN06_ADD_RSUS

C_NT-DMS100_SN06_ADD_SACB

The SACB option allows a subscriber to control originations from the line by identifying call classes that restrict completion to certain dialed numbers without a personal identification number (PIN).

Table 657: C_NT-DMS100_SN06_ADD_SACB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SUB_ACT_CALL_BLOCKING_CC	Indicates the type of call classes to be restricted for SACB.			S	R
SUB_ACT_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SUB_ACT_CALL_BLOCKING_PIN	SACB personal identification number (PIN).			S	R
SUB_ACT_CALL_BLOCKING_STATUS	Option prompt when the SCRJ option, SACB option, or PRN option is specified when adding MWT to a line.			S	O

Table 657: C_NT-DMS100_SN06_ADD_SACB

Parameter Name	Description	Range	Default Value	Type	Class
SUB_ACT_CALL_BLOCKING_SUS	Blocks all calls from an originating line except for those in table SACB against subfield FPBALLOW. STATUS must be specified as ACT.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 658: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SACB	A_NT-DMS100_SN06_ADD_SACB

C_NT-DMS100_SN06_ADD_SC1

The SC1 option allows a customer to specify a list of up to eight frequently called numbers. These numbers can be called by dialing the digits 2-9.

Table 659: C_NT-DMS100_SN06_ADD_SC1

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 660: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SC1	A_NT-DMS100_SN06_ADD_SC1

C_NT-DMS100_SN06_ADD_SC2

The SC2 option allows a customer to specify a list of up to 30 frequently called numbers. These numbers can be called by dialing 20-49.

Table 661: C_NT-DMS100_SN06_ADD_SC2

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 662: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SC2	A_NT-DMS100_SN06_ADD_SC2

C_NT-DMS100_SN06_ADD_SCA

The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN).

Table 663: C_NT-DMS100_SN06_ADD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_ ACCEPTANCE_BILL ING_OPTION	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_ ACCEPTANCE_DNS	Directory number to be added to the SCA list. If a user does not send any value for SELECTIVE_CALL_ BLOCKING_DNS[1], the system will assume that the value is $.			C	O
SELECTIVE_CALL_ ACCEPTANCE_LINE	LINE for the SCA option.			C	O
SELECTIVE_CALL_ ACCEPTANCE_NPA	NPA for the SCA option.			C	O

Table 663: C_NT-DMS100_SN06_ADD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_ ACCEPTANCE_NXX	NXX for the SCA option.			C	O
SELECTIVE_CALL_ ACCEPTANCE_OPT KEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SELECTIVE_CALL_ ACCEPTANCE_STAT US	INACT indicates that the option is not enabled (inactive); ACT indicates that the option is enabled (active); UNIVI indicates that universal access via customer interface is inactive, and UNIVA indicates that universal access via customer interface is active.			S	R
SELECTIVE_CALL_ ACCEPTANCE_VBC OUNT	Number of digits voiced back during SCA list review.			C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 664: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCA	A_NT-DMS100_SN06_ADD_SCA

C_NT-DMS100_SN06_ADD_SCF

The SCF option allows calls that terminate on the line to be forwarded to a remote destination if the number of the originating station matches one of the numbers in the SCF list.

Table 665: C_NT-DMS100_SN06_ADD_SCF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_FORWARDING_BILLING_OPTION	NOAMA indicates that the feature is billed based on a subscription, AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_FORWARDING_DNS	Directory number to be added to the SCF list. If a user does not send any value for SELECTIVE_CALL_FORWARDING_DNS[1], the system will assume that the value is $.			C	O
SELECTIVE_CALL_FORWARDING_FDN	Number to which calls will be forwarded.			S	O

Table 665: C_NT-DMS100_SN06_ADD_SCF

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_FORWARDING_FDN_LINE	LINE to which calls will be forwarded.			S	O
SELECTIVE_CALL_FORWARDING_FDN_NPA	NPA to which calls will be forwarded.			S	O
SELECTIVE_CALL_FORWARDING_FDN_NXX	NXX to which calls will be forwarded.			S	O
SELECTIVE_CALL_FORWARDING_LINE	LINE for the SCA option.			C	O
SELECTIVE_CALL_FORWARDING_NPA	NPA for the SCA option.			C	O
SELECTIVE_CALL_FORWARDING_NUMCALLS	LINE to which calls will be forwarded.			S	R
SELECTIVE_CALL_FORWARDING_NXX	NXX for the SCA option.			C	O
SELECTIVE_CALL_FORWARDING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SELECTIVE_CALL_FORWARDING_RINGREM	LINE to which calls will be forwarded.			S	R
SELECTIVE_CALL_FORWARDING_SCRNCL	Screening by class of service.			S	O

Table 665: C_NT-DMS100_SN06_ADD_SCF

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_FORWARDING_STATUS	INACT indicates that the option is not enabled (inactive), ACT indicates that the option is enabled (active), UNIVI indicates universal access via customer interface is inactive, and UNIVA indicates universal access via customer interface is active.			S	R
SELECTIVE_CALL_FORWARDING_VBCOUNT	Number of digits voiced back during SCA list review.			C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 666: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCF	A_NT-DMS100_SN06_ADD_SCF

C_NT-DMS100_SN06_ADD_SCL

The SCL option allows a customer to specify a list of frequently called numbers that can be called by dialing a two-digit speed calling code instead of the complete number.

Table 667: C_NT-DMS100_SN06_ADD_SCL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 667: C_NT-DMS100_SN06_ADD_SCL

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_LONG_KEYLIST	Applies only to Hunt groups. Appears when the user assigns a subset feature to a multi-line set. Specifies the key numbers of the DNS to which the user applied a feature. If the key number is not provided, you should provide the value $.			C	O
SPEED_CALLING_LONG_LISTTYPE	The length of the list.	L30, L50, L70		S	R
SPEED_CALLING_LONG_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 668: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCL	A_NT-DMS100_SN06_ADD_SCL

C_NT-DMS100_SN06_ADD_SCRJ

The SCRJ option allows a subscriber to selectively reject calls arriving from a limited set of previously identified DNs.

Table 669: C_NT-DMS100_SN06_ADD_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_BLOCKING_BILLING_OPTION	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_BLOCKING_DNS	Directory number to be added to the SCRJ list. If a user does not send any value for SELECTIVE_CALL_BLOCKING_DNS[1], the system will assume that the value is $.			C	O
SELECTIVE_CALL_BLOCKING_LINE	LINE for the SCA option.			C	O
SELECTIVE_CALL_BLOCKING_NPA	NPA for the SCA option.			C	O

Table 669: C_NT-DMS100_SN06_ADD_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_BLOCKING_NXX	NXX for the SCA option.			C	O
SELECTIVE_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
SELECTIVE_CALL_BLOCKING_STATUS	INACT indicates that the option is not enabled [inactive), ACT indicates that the option is enabled (active), UNIVI indicates that universal access via the customer interface is inactive, and UNIVA indicates that universal access via the customer interface is active.			S	R
SELECTIVE_CALL_BLOCKING_VBCOUNT	Number of digits voiced back during SCA list review.			C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 670: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCRJ	A_NT-DMS100_SN06_ADD_SCRJ

C_NT-DMS100_SN06_ADD_SCS

The SCS option allows a customer to specify a list of frequently called numbers that the customer can call by dialing a one-digit speed calling code instead of the complete number.

Table 671: C_NT-DMS100_SN06_ADD_SCS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_SHORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 672: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCS	A_NT-DMS100_SN06_ADD_SCS

C_NT-DMS100_SN06_ADD_SCU

The SCU option allows a line to be designated as a speed calling user in a speed calling group. A speed calling user can only originate calls with speed calling and cannot affect the contents of the speed calling list.

Table 673: C_NT-DMS100_SN06_ADD_SCU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_USER_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SPEED_CALLING_USER_SCUGNUMBER	Specifies a unique group number for the SCU option.			S	R
SPEED_CALLING_USER_SCU_TDN	Specifies whether toll denial is applied to speed called numbers.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 674: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCU	A_NT-DMS100_SN06_ADD_SCU

C_NT-DMS100_SN06_ADD_SCWID

The SCWID option allows subscribers to receive calling party information in conjunction with a call waiting tone.

Table 675: C_NT-DMS100_SN06_ADD_SCWID

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 676: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SCWID	A_NT-DMS100_SN06_ADD_SCWID

C_NT-DMS100_SN06_ADD_SDN

To add a secondary DN to a Teen Service line, the SDN option can be assigned to POTS, RES, or IBN agents. When no SDNs are assigned to the line, adding the SDN option establishes Teen Service.

Table 677: C_NT-DMS100_SN06_ADD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SECONDARY_DN_DN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O

Table 677: C_NT-DMS100_SN06_ADD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
SECONDARY_DN_DNY	NODNY = No deny to call waiting. DNYCWT = Deny call waiting. These options are not applicable to MDC. Enter $ to omit both options.			S	O
SECONDARY_DN_LINE	Secondary LINE.			S	O
SECONDARY_DN_NPA	Secondary NPA.			S	O
SECONDARY_DN_NXX	Secondary NXX.			S	O
SECONDARY_DN_OPT	Secondary DN type.	P = forward SDN with PDN, N = do not forward SDN, E = enhanced SDN can have own option list		S	R
SECONDARY_DN_RING	Secondary DN ring type.	0 = normal ringing, 1 = SDN pattern #1, 2 = SDN pattern #2, 3 = SDN pattern #3		S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 678: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SDN	A_NT-DMS100_SN06_ADD_SDN

C_NT-DMS100_SN06_ADD_SDSDENY

The SDSDENY option prevents the offer of Enhanced Busy Call Return (EBCR) service to a line.

Table 679: C_NT-DMS100_SN06_ADD_SDSDENY

Parameter Name	Description	Range	Default Value	Type	Class
DENY_BUSY_REPEAT_DIAL_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 680: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SDSDENY	A_NT-DMS100_SN06_ADD_SDSDENY

C_NT-DMS100_SN06_ADD_SHU

The SHU option allows hunting at a line to be canceled when activated. SHU can be assigned to one, several, or all lines in a Hunt group.

Table 681: C_NT-DMS100_SN06_ADD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STOP_HUNT_NORMAL_STATE	Normal state of the SD point. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
STOP_HUNT_POINT	SD point number. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_SC	Scan point.	tmtype = MTM, RSMtmno = 0-2047tmcktno = 0-29point = 0-6 (SD point number) normal_state = 0 for open or 1 for closed		S	R

Table 681: C_NT-DMS100_SN06_ADD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
STOP_HUNT_TMCKTNO	Enter the trunk module circuit number to which the circuit is assigned. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_TMNO	Enter the number of the trunk module on which the circuit is mounted. Appears after the signal distribution (SD) or SC prompt if data is not entered on one line.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 682: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SHU	A_NT-DMS100_SN06_ADD_SHU

C_NT-DMS100_SN06_ADD_SL

The SL option allows a line to receive announcements in a secondary language (a language other than the assigned primary language).

Table 683: C_NT-DMS100_SN06_ADD_SL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 683: C_NT-DMS100_SN06_ADD_SL

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SECONDARY_LANGUAGE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 684: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SL	A_NT-DMS100_SN06_ADD_SL

C_NT-DMS100_SN06_ADD_SMDR

The SMDR option allows the recording of both billable and nonbillable calls on a per leg call basis. The SMDR system uses the automatic message accounting (AMA) subsystem to collect the call data and automatically record it on a data storage device.

Table 685: C_NT-DMS100_SN06_ADD_SMDR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 685: C_NT-DMS100_SN06_ADD_SMDR

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_MESSAGE_RECORDING_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 686: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SMDR	A_NT-DMS100_SN06_ADD_SMDR

C_NT-DMS100_SN06_ADD_SPB

The SPB option allow a line number other than the subscriber's line to be used for billing.

Table 687: C_NT-DMS100_SN06_ADD_SPB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 687: C_NT-DMS100_SN06_ADD_SPB

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
SPECIAL_BILLING_DN	DN number to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_LINE	LINE of DN to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_NPA	NPA of DN to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_NXX	NXX of DN to which calls from a station are to be billed.			S	O
SPECIAL_BILLING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 688: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SPB	A_NT-DMS100_SN06_ADD_SPB

C_NT-DMS100_SN06_ADD_SRA

The SRA option allows any authorized server to establish a connection to that customer's line without applying audible ringing.

Table 689: C_NT-DMS100_SN06_ADD_SRA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 690: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SRA	A_NT-DMS100_SN06_ADD_SRA

C_NT-DMS100_SN06_ADD_SSAC

The SSAC option allows a set of numbers, from 2-10 digits, to be dialed from a specific station for purposes of recording billing information and overriding station network class of service (NCOS) restrictions.

Table 691: C_NT-DMS100_SN06_ADD_SSAC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 691: C_NT-DMS100_SN06_ADD_SSAC

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_SPECIFIC_AUTH_CODES_AUTHCODE	Authorization code.			C	O
STATION_SPECIFIC_AUTH_CODES_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 692: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SSAC	A_NT-DMS100_SN06_ADD_SSAC

C_NT-DMS100_SN06_ADD_SUPPRESS

The SUPPRESS option allows a party prevent the directory number (DN) or name from being displayed at the call destination.

Table 693: C_NT-DMS100_SN06_ADD_SUPPRESS

Parameter Name	Description	Range	Default Value	Type	Class
ANONYMOUS_CALLER_NETNAME	Network name shown as DN attribute.			C	O
ANONYMOUS_CALLER_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
ANONYMOUS_CALLER_SUPPRESS_DN	Suppresses the display of the DN. Enter Y to suppress the display of the DN; enter N if no suppression is required.			C	O
ANONYMOUS_CALLER_SUPPRESS_NAME	Enter Y to suppress the display of the station name; enter N if no suppression is required. Suppresses the display of the station name.			C	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 694: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SUPPRESS	A_NT-DMS100_SN06_ADD_SUPPRESS

C_NT-DMS100_SN06_ADD_SUPR

The SUPR option establishes an automatic call distribution (ACD) supervisor set when assigned to key 1. This option must be assigned before ACD supervisor options can be assigned to the set.

Table 695: C_NT-DMS100_SN06_ADD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SUPERVISOR_IDNUM	Indicates if ID number of agent position is required.	Y = Yes, N = No		C	R
SUPERVISOR_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 695: C_NT-DMS100_SN06_ADD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
SUPERVISOR_PRIMARY_ACDGROUP	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.			C	R
SUPERVISOR_PRIMARY_ACDSGRP	The supervisor subgroup identifier that must already be data filled in Table ACDSGRP in order to add the SUPR option to an ACD group.			C	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 696: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SUPR	A_NT-DMS100_SN06_ADD_SUPR

C_NT-DMS100_SN06_ADD_SVCGRP

The SVCGRP option allows options CLID (Calling Line Identification Display), NAME (Name Display) and REASDSP (Reason Display), packaged in a service group.

Table 697: C_NT-DMS100_SN06_ADD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 697: C_NT-DMS100_SN06_ADD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SERVICE_GROUP_GRPNAME	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.			S	R
SERVICE_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 698: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_SVCGRP	A_NT-DMS100_SN06_ADD_SVCGRP

C_NT-DMS100_SN06_ADD_TCW

TCW option - talking call waiting.

Table 699: C_NT-DMS100_SN06_ADD_TCW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 699: C_NT-DMS100_SN06_ADD_TCW

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 700: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_TCW	A_NT-DMS100_SN06_ADD_TCW

C_NT-DMS100_SN06_ADD_TDN

The TDN option prevents a line from originating toll calls.

Table 701: C_NT-DMS100_SN06_ADD_TDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 701: C_NT-DMS100_SN06_ADD_TDN

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 702: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_TDN	A_NT-DMS100_SN06_ADD_TDN

C_NT-DMS100_SN06_ADD_TFO

The TDN option allows an incoming call to attempt to terminate to the first member of the hunt group which appears idle.

Table 703: C_NT-DMS100_SN06_ADD_TFO

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
TERMINATION_FAULT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 704: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_TFO	A_NT-DMS100_SN06_ADD_TFO

C_NT-DMS100_SN06_ADD_UCD

The UCD option permits calls to be distributed evenly among a number of predetermined sets.

Table 705: C_NT-DMS100_SN06_ADD_UCD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
UNIFORM_CALL_DISTRIBUTION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 706: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_UCD	A_NT-DMS100_SN06_ADD_UCD

C_NT-DMS100_SN06_ADD_VMEADENY

The VMEADENY option Prevent subscriber's line to have access to voice messaging system VMS using access code *98.

Table 707: C_NT-DMS100_SN06_ADD_VMEADENY

Parameter Name	Description	Range	Default Value	Type	Class
DENY_VOICE_MAIL_EASY_ACCESS_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 708: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_VMEADENY	A_NT-DMS100_SN06_ADD_VMEADENY

C_NT-DMS100_SN06_ADD_VMEADN

The VMEADN option is assigned to RES or ISDN lines when access to the subscriber's Voice Messaging System (VMS) is required using access code *98.

Table 709: C_NT-DMS100_SN06_ADD_VMEADN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
VOICE_MAIL_EASY_ACCESS_DN_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_DN	Subscriber's voice mail easy access forward DN.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_LINE	Subscriber's VM line number.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_NPA	Subscriber's VM area code.			S	O
VOICE_MAIL_EASY_ACCESS_DN_VM_NXX	Subscriber's VM NXX.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 710: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_VMEADN	A_NT-DMS100_SN06_ADD_VMEADN

C_NT-DMS100_SN06_ADD_WML

The WML option is assigned to lines that route to a predefined DN if no digits are dialed within a modifiable time-out period.

Table 711: C_NT-DMS100_SN06_ADD_WML

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
WARM_LINE_ACTIVE	Specifies whether the option is active.			S	R
WARM_LINE_CUSTMOD	Specifies whether a customer can change the DN to which a call is forwarded when the WML time-out expires.			S	R
WARM_LINE_DN	The DN to which a call is forwarded when the WML expires.			S	O

Table 711: C_NT-DMS100_SN06_ADD_WML

Parameter Name	Description	Range	Default Value	Type	Class
WARM_LINE_FTCODE	Enter Y to allow a subscriber to dial octothorpe (#) to access MDC features. Enter N to allow a subscriber to dial # to override the Warm Line feature timer. FTCODE is prompted when the office parameter WML_OCT_IS_LINE_OPT_PARM is set to Y.			S	O
WARM_LINE_LINE	The LINE to which a call is forwarded when the WML expires.			S	O
WARM_LINE_NPA	The NPA to which a call is forwarded when the WML expires.			S	O
WARM_LINE_NXX	The NXX to which a call is forwarded when the WML expires.			S	O
WARM_LINE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
WARM_LINE_TIMEOUT	Specifies the length of time in seconds before an unanswered call is automatically forwarded.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 712: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_WML	A_NT-DMS100_SN06_ADD_WML

C_NT-DMS100_SN06_ADD_WUC

The WUC option allows a subscriber to set a time for the phone to ring.

Table 713: C_NT-DMS100_SN06_ADD_WUC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
WAKE_UP_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 714: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_WUC	A_NT-DMS100_SN06_ADD_WUC

C_NT-DMS100_SN06_ADD_WUCR

The WUC option allows a subscriber to set a reminder time for the phone to ring.

Table 715: C_NT-DMS100_SN06_ADD_WUCR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 716: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_WUCR	A_NT-DMS100_SN06_ADD_WUCR

C_NT-DMS100_SN06_ADD_DCPK

The DCPK option option allows the system to put calls on hold or to park calls against any valid DN

Table 717:

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory Number			S	O

Table 717:

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digits line extension			S	O
MCLI	The name of the host NE.			S	R
NPA	3 digits area code			S	O
NXX	First 3 digits of the line number			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service

Table 718:

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DCPK	A_NT-DMS100_SN06_ADD_DCPK

Modify Feature Services

This cartridge provides the following CSDL Commands:

- C_NT-DMS100_SN06_CHF_FEATURES
- C_NT-DMS100_SN06_MOD_ACD
- C_NT-DMS100_SN06_MOD_AIN
- C_NT-DMS100_SN06_MOD_AINDN
- C_NT-DMS100_SN06_MOD_ASL
- C_NT-DMS100_SN06_MOD_AUD
- C_NT-DMS100_SN06_MOD_AUL
- C_NT-DMS100_SN06_MOD_AUTODISP
- C_NT-DMS100_SN06_MOD_CFB
- C_NT-DMS100_SN06_MOD_CFBL
- C_NT-DMS100_SN06_MOD_CFD

- C_NT-DMS100_SN06_MOD_CFDA
- C_NT-DMS100_SN06_MOD_CFDVT
- C_NT-DMS100_SN06_MOD_CFF
- C_NT-DMS100_SN06_MOD_CFS
- C_NT-DMS100_SN06_MOD_CFU
- C_NT-DMS100_SN06_MOD_CFW
- C_NT-DMS100_SN06_MOD_CIF
- C_NT-DMS100_SN06_MOD_CNAMD
- C_NT-DMS100_SN06_MOD_CND
- C_NT-DMS100_SN06_MOD_CNF
- C_NT-DMS100_SN06_MOD_CPU
- C_NT-DMS100_SN06_MOD_CSMI
- C_NT-DMS100_SN06_MOD_CWT
- C_NT-DMS100_SN06_MOD_CXR
- C_NT-DMS100_SN06_MOD_DIN
- C_NT-DMS100_SN06_MOD_DQS
- C_NT-DMS100_SN06_MOD_DQT
- C_NT-DMS100_SN06_MOD_DRING
- C_NT-DMS100_SN06_MOD_EMW
- C_NT-DMS100_SN06_MOD_ESL
- C_NT-DMS100_SN06_MOD_FAA
- C_NT-DMS100_SN06_MOD_FEATURES
- C_NT-DMS100_SN06_MOD_FTRGRP
- C_NT-DMS100_SN06_MOD_GIC
- C_NT-DMS100_SN06_MOD_ICM
- C_NT-DMS100_SN06_MOD_KSH
- C_NT-DMS100_SN06_MOD_LPIC
- C_NT-DMS100_SN06_MOD_MDN
- C_NT-DMS100_SN06_MOD_NAME
- C_NT-DMS100_SN06_MOD_NGTSRVCE
- C_NT-DMS100_SN06_MOD_OBS
- C_NT-DMS100_SN06_MOD_PIC
- C_NT-DMS100_SN06_MOD_RMI
- C_NT-DMS100_SN06_MOD_SCA
- C_NT-DMS100_SN06_MOD_SCU
- C_NT-DMS100_SN06_MOD_SDN

- C_NT-DMS100_SN06_MOD_SHU
- C_NT-DMS100_SN06_MOD_SUPR
- C_NT-DMS100_SN06_MOD_SVCGRP
- C_NT-DMS100_SN06_DEL_DCPK

C_NT-DMS100_SN06_CHF_FEATURES

Modifies the option by first deleting the feature and then adding the feature again.

Table 719: C_NT-DMS100_SN06_CHF_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	Directory number.			S	O
IS_OPTIMIZED	A flag to indicate MML optimization of the command.	true or false	true	S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OPT	Options associated with a service you are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 720: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_CHF_FEATURES	A_NT-DMS100_SN06_CHF_FEATURES

C_NT-DMS100_SN06_MOD_ACD

ACD allows the subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call.

Table 721: C_NT-DMS100_SN06_MOD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_ACDGROUP	A group identifier that is already in table ACDGRP. Indicates the name of the automatic call distribution (ACD) group to which this station belongs.			S	R
AUTOMATIC_CALL_DISTRIBUTION_ACDSGRP	The number of the ACD subgroup to which this station belongs. This number must already appear in table ACDSGRP.			S	R
AUTOMATIC_CALL_DISTRIBUTION_IBN_ACD_OPTION	Enter SCAILINK if the ACD agent associates with a set of D-channels for switch-computer communications. Enter ACDNR to deny ACD calls by the ACD agent.			C	R

Table 721: C_NT-DMS100_SN06_MOD_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_IDNUM	Indicates if an ID number for a supervisor set is present. This field appears only when a supervisor set uses NEWACD. If Y, the POSID field prompts.			S	R
AUTOMATIC_CALL_DISTRIBUTION_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_CALL_DISTRIBUTION_POSID	Enter the ACD agent position ID number. A POSID is for interactions with other ACD options.			S	R
AUTOMATIC_CALL_DISTRIBUTION_SCAI_LINK	Indicates the PRA D-channel name, or SCAIDEF for the default link set name.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 722: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_ACD	A_NT-DMS100_SN06_MOD_ACD

C_NT-DMS100_SN06_MOD_AIN

The AIN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN.

Table 723: C_NT-DMS100_SN06_MOD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
PRIVACY_ID_GROUP_AINGRP	The AIN group name used to define a group of trigger behaviors.			S	R

Table 723: C_NT-DMS100_SN06_MOD_AIN

Parameter Name	Description	Range	Default Value	Type	Class
PRIVACY_ID_GROUP_KEYLIST	Specifies DN key numbers to which an option applies. Appears when the user assigns a subset option to BRI multi-line sets. If key number is not provided, the system assumes that the value is $.			C	O
PRIVACY_ID_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 724: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_AIN	A_NT-DMS100_SN06_MOD_AIN

C_NT-DMS100_SN06_MOD_AINDN

The AINDN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN.

Table 725: C_NT-DMS100_SN06_MOD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 725: C_NT-DMS100_SN06_MOD_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
PRIVACY_ID_AINGRP	Enter TIID to datafill the trigger for the following refinements to the item provisioning interface. Up to 16 alphanumeric characters, or TIID.			S	R
PRIVACY_ID_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
PRIVACY_ID_TDP	Datafill the appropriate TDP.	1, 3, 4, 17, 19, 20, 22, 30, 32, 33		S	O
PRIVACY_ID_TINAME	Alphanumeric vector (1 to 8 characters) to datafill the trigger items defined in table TRIGITM at the specified TDP.			S	O
PRIVACY_ID_TRIGACT	Datafill the value ON to activate the trigger item identified by the TIID. Datafill the value OFF to deactivate the trigger item identified by the TIID.	ON or OFF		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 726: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_AINDN	A_NT-DMS100_SN06_MOD_AINDN

C_NT-DMS100_SN06_MOD_ASL

The ASL option allows a supervisor to monitor the status of an agent position. This process does not interfere with the call. The lamp for the assigned agent status key reflects the status of the call.

Table 727: C_NT-DMS100_SN06_MOD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
AGENT_STATUS_LAMP_AGENT_LEN	The LEN of the agent position.			S	R
AGENT_STATUS_LAMP_ASLSDN	Agent status lamp that monitors the SDN of an ACD agent. Key number for the secondary DN the user must monitor.			S	R
AGENT_STATUS_LAMP_MSBOVRD	Make set busy override.			S	R
AGENT_STATUS_LAMP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 727: C_NT-DMS100_SN06_MOD_ASL

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 728: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_ASL	A_NT-DMS100_SN06_MOD_ASL

C_NT-DMS100_SN06_MOD_AUD

The AUD option allows a business set subscriber to call a number the subscriber dials frequently. The subscriber presses the AUD key to call this number. The subscriber can program and change this number.

Table 729: C_NT-DMS100_SN06_MOD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DIAL_AUDFEAT	The option or service to be accessed.			S	R
AUTOMATIC_DIAL_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
AUTOMATIC_DIAL_PGMAUD	Indicates person who programs the AUD key.	Y = yes (operating company programmed), N = no (subscriber programmed)		S	R

Table 729: C_NT-DMS100_SN06_MOD_AUD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 730: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_AUD	A_NT-DMS100_SN06_MOD_AUD

C_NT-DMS100_SN06_MOD_AUL

The automatic line (AUL) option connects to a set location when a directory number (DN) or an assigned AUL option line reports an off-hook status. This CSDL command changes the option parameters of the assigned line.

Table 731: C_NT-DMS100_SN06_MOD_AUL

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_LINE_DN	Automatic line DN.			S	O
AUTOMATIC_LINE_LINE	Automatic line LINE.			S	O

Table 731: C_NT-DMS100_SN06_MOD_AUL

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_LINE_NPA	Automatic line NPA.			S	O
AUTOMATIC_LINE_NXX	Automatic line NXX.			S	O
AUTOMATIC_LINE_OPTKEY	Identifies the key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 732: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_AUL	A_NT-DMS100_SN06_MOD_AUL

C_NT-DMS100_SN06_MOD_AUTODISP

The automatic display (AUTODISP) option automatically shows information on incoming calls to a Meridian business set (MBS).

Table 733: C_NT-DMS100_SN06_MOD_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DISPLAY_CWT_OPTION	Indicates person who programs the AUD key.	Y = yes (operating company programmed), N = no (subscriber programmed)		S	R
AUTOMATIC_DISPLAY_KEYLIST	The option or service to be accessed.			C	R
AUTOMATIC_DISPLAY_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 734: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_AUTODISP	A_NT-DMS100_SN06_MOD_AUTODISP

C_NT-DMS100_SN06_MOD_CFB

The CFB option allows the system to forward all calls to a busy station to a station determined earlier. This CSDL command changes the option parameters of the assigned line.

Table 735: C_NT-DMS100_SN06_MOD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_CNTL	Call forwarding busy Control.	F = fixed assignment for CFB, N = normal (default) assignment for CFB, P = programmed assignment for CFB, K = programmed assignment for CFB per key destination		S	O
CALL_FORWARD_BUSY_DN	Call forwarding DN for CFB option.			S	O
CALL_FORWARD_BUSY_KEYLIST	Appears when the user assigns a subset option to a multi-line set. Specifies key numbers of the DNs to which an option applies.	Key number (1-69), list of key numbers, or $		C	O
CALL_FORWARD_BUSY_LINE	Call forwarding LINE for CFB option.			S	O
CALL_FORWARD_BUSY_NPA	Call forwarding NPA for CFB option.			S	O
CALL_FORWARD_BUSY_NXX	Call forwarding NXX for CFB option.			S	O
CALL_FORWARD_BUSY_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 735: C_NT-DMS100_SN06_MOD_CFB

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 736: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFB	A_NT-DMS100_SN06_MOD_CFB

C_NT-DMS100_SN06_MOD_CFBL

The CFBL option allows the subscriber to specify a directory number (DN). This CSDL command changes the option parameters of the assigned line.

Table 737: C_NT-DMS100_SN06_MOD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_LINE_CFBLCNTL	Call forwarding busy line control value.	C = programmed assignment for CFBL, F = fixed assignment for CFBL, N = normal (default) assignment for CFBL		S	R
CALL_FORWARD_BUSY_LINE_DN	DN to which the system will forward calls.			S	O

Table 737: C_NT-DMS100_SN06_MOD_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_LINE_LINE	Line to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NPA	NPA to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_NUMCALLS	The number of calls the system can forward at the same time. Value 0-1024.			S	R
CALL_FORWARD_BUSY_LINE_NXX	NXX to which the system will forward calls.			S	O
CALL_FORWARD_BUSY_LINE_SCRNCL	Screening by class of service.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 738: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFBL	A_NT-DMS100_SN06_MOD_CFBL

C_NT-DMS100_SN06_MOD_CFD

The CFD option allows the system to forward incoming calls that are not answered within a specified time.

Table 739: C_NT-DMS100_SN06_MOD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_BUS_CNTL	Call forwarding busy control.	F = fixed assignment for CFD, N = normal (default) assignment for CFD, P = programmed assignment for CFD, and K = programmed assignment for CFD per key destination		S	O
CALL_FORWARD_NO_ANSWER_BUS_DN	Call forwarding DN for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_KEYLIST	Specifies key numbers of the DNs to which an option applies. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_FORWARD_NO_ANSWER_BUS_LINE	Call forwarding LINE for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_NPA	Call forwarding NPA for CFD option.			S	O

Table 739: C_NT-DMS100_SN06_MOD_CFD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_BUS_NXX	Call forwarding NXX for CFD option.			S	O
CALL_FORWARD_NO_ANSWER_BUS_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 740: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFD	A_NT-DMS100_SN06_MOD_CFD

C_NT-DMS100_SN06_MOD_CFDA

The Call Forwarding Do Not Answer (CFDA) Residential option forwards calls not answered to stations in the same customer group. This CSDL command changes the option parameters of the assigned line.

Table 741: C_NT-DMS100_SN06_MOD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_RES_CNTL	Call Forwarding Do Not Answer control.	F = fixed, N = normal (default), and C = programmed assignment		S	O
CALL_FORWARD_NO_ANSWER_RES_DN	Number to which the system forwards calls.			S	O
CALL_FORWARD_NO_ANSWER_RES_LINE	Call forwarding LINE for the CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_NPA	Call forwarding NPA for the CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_NUMCALLS	The number of calls the system can forward at the same time.			S	R
CALL_FORWARD_NO_ANSWER_RES_NXX	Call forwarding NXX for the CFDA option.			S	O
CALL_FORWARD_NO_ANSWER_RES_RING_CTRL	Indicates whether the end user or the operating company controls the ringing time-out. PRGRING allows the end user to change the CFDA ringing time-out. FIXRING indicates that only the operating company can change the ringing time-out.			S	R

Table 741: C_NT-DMS100_SN06_MOD_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_RES_SCRNCL	Identifies screening by class of service.			S	R
CALL_FORWARD_NO_ANSWER_RES_TIME	Indicates the period of time the base station rings before forwarding.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 742: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFDA	A_NT-DMS100_SN06_MOD_CFDA

C_NT-DMS100_SN06_MOD_CFDVT

The Call Forwarding Do Not Answer Variable Timer (CFDVT) option allows an end-user to specify how long a call rings before the system forwards the call to another station.

Table 743: C_NT-DMS100_SN06_MOD_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_VAR_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_NO_ANSWER_VAR_RING_CTRL	Ring control. Enter PRGRING to allow the end-user to set the CVDVT time-out period. Enter FIXRING to indicate to the end-user that the CVDVT time-out period is fixed; it can only be changed by the operating company.			S	R
CALL_FORWARD_NO_ANSWER_VAR_TIME	Call forward do not answer timing. The time, in seconds, that a call rings before the system forwards the call to the next DN.	0-60		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 744: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFDVT	A_NT-DMS100_SN06_MOD_CFDVT

C_NT-DMS100_SN06_MOD_CFF

The CFF option allows the station to forward calls to a location the operating company enters. The user cannot program the number to which the station forwards the calls.

Table 745: C_NT-DMS100_SN06_MOD_CFF

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_FIXED_CFFDN	Call forwarding DN for CFF option.			S	O
CALL_FORWARD_FIXED_CFF_OPTION	The value to set the CFFA to active.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 746: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFF	A_NT-DMS100_SN06_MOD_CFF

C_NT-DMS100_SN06_MOD_CFS

The Call Forwarding Simultaneous/Screening (CFS) option allows the user to call forward more than one call through a station at a time.

Table 747: C_NT-DMS100_SN06_MOD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_CFXNCOS	Call forwarding NCOS.			S	R
CALL_FORWARD_SIMULTANEUS_NCFB	Maximum number of active calls the user can forward through a CFB base station at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_NCFD	The number of calls the user can forward for call forward do not answer at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_NCFUIF	Maximum number of active calls the user can forward through a CFU, CFI, or CFF base station at the same time.			S	R
CALL_FORWARD_SIMULTANEUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 747: C_NT-DMS100_SN06_MOD_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_SCREEN	Call forwarding screening capability.			S	R
CALL_FORWARD_SIMULTANEUS_SIMULT	Indicates Call Forwarding Simultaneous.			S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 748: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFS	A_NT-DMS100_SN06_MOD_CFS

C_NT-DMS100_SN06_MOD_CFU

The CFU option allows a station user to reroute incoming calls to another telephone number.

Table 749: C_NT-DMS100_SN06_MOD_CFU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_UNIVERSAL_KEYLIST	Specifies the key numbers of the DNs to which an option will apply. Appears when the user assigns a subset option to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_FORWARD_UNIVERSAL_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_FORWARD_UNIVERSAL_OVRDACR	Override for account code required.	Y = Yes, N = No		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 750: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFU	A_NT-DMS100_SN06_MOD_CFU

C_NT-DMS100_SN06_MOD_CFW

The CFW option allows the user to forward calls to another location. This CSDL command changes the option parameters of the assigned line.

Table 751: C_NT-DMS100_SN06_MOD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_DN	Number to which calls will be forwarded.	1-30 digits. "$" must not be used		S	O
CALL_FORWARD_LINE	LINE to which calls will be forwarded.			S	O
CALL_FORWARD_NPA	NPA to which calls will be forwarded.			S	O
CALL_FORWARD_NUMCALLS	The number of calls the user can forward at the same time.	0-1024		S	O
CALL_FORWARD_NXX	NXX to which calls will be forwarded.			S	O
CALL_FORWARD_SCRNCL	Screening by class of service.			S	R
CALL_FORWARD_STATE	State of absent subscriber intercept.	A = active, I = inactive, W = wait		S	O
CALL_FORWARD_TYPE	Type of call forwarding.	C = customer, F = fixed, U = usage sensitive pricing		S	R
DN	Directory number.			S	O

Table 751: C_NT-DMS100_SN06_MOD_CFW

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 752: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CFW	A_NT-DMS100_SN06_MOD_CFW

C_NT-DMS100_SN06_MOD_CIF

The Controlled Interflow (CIF) option allows a supervisor to place an automatic call distribution (ACD) group in a controlled interflow mode.

Table 753: C_NT-DMS100_SN06_MOD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
CONTROLLED_INTERFLOW_ACDGROUP	The name of the automatic call distribution group name. The name is a group identifier the user must datafill in Table ACDGRP.			S	R

Table 753: C_NT-DMS100_SN06_MOD_CIF

Parameter Name	Description	Range	Default Value	Type	Class
CONTROLLED_INTERFLOW_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 754: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CIF	A_NT-DMS100_SN06_MOD_CIF

C_NT-DMS100_SN06_MOD_CNAMD

The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE).

Table 755: C_NT-DMS100_SN06_MOD_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
CALLER_ID_NAME_DELIVERY_BILLING_OPTION	Indicates the billing option that the user must specify when the user assigns the CNAMD.	AMA = AMA record created, NOAMA = AMA record not created		S	O
CALLER_ID_NAME_DELIVERY_OPTKEY	Identifies a key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 756: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CNAMD	A_NT-DMS100_SN06_MOD_CNAMD

C_NT-DMS100_SN06_MOD_CND

The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. The billing option is enabled.

Table 757: C_NT-DMS100_SN06_MOD_CND

Parameter Name	Description	Range	Default Value	Type	Class
CALLING_NUMBER_DELIVERY_BILLING_OPTION	Billing option.	AMA=recorded, NOAMA=not recorded, or $		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 758: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CND	A_NT-DMS100_SN06_MOD_CND

C_NT-DMS100_SN06_MOD_CNF

The Station Controlled Conference (CNF) option allows a station to have a conference call to a maximum of 30 parties.

Table 759: C_NT-DMS100_SN06_MOD_CNF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_CONTROLLED_CONFERENCE_CONF_TYPE	Indicates the maximum number of stations that can connect to a station controlled conference.			S	R
STATION_CONTROLLED_CONFERENCE_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 760: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CNF	A_NT-DMS100_SN06_MOD_CNF

C_NT-DMS100_SN06_MOD_CPU

The Call Pickup (CPU) option allows a station to answer incoming calls to another station in the same pickup group.

Table 761: C_NT-DMS100_SN06_MOD_CPU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_PICKUP_CPU_LEN	Indicates the CPU number.			S	R
CALL_PICKUP_OPT KEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 762: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CPU	A_NT-DMS100_SN06_MOD_CPU

C_NT-DMS100_SN06_MOD_CSMI

The CSMI feature allows end users of Network Based Answering Services (NBAS) to monitor and intercept calls that the NBAS handles. This CSDL command changes the option parameters of the assigned line.

Table 763: C_NT-DMS100_SN06_MOD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_SCREENING_CONNEC3W	Determines call interception (2-way call or 3-way call).			S	O
CALL_SCREENING_CSMIPPU	Identifies the billing option to use.			S	O
CALL_SCREENING_CSMISTATE	The state of activating CSMI feature.			S	O
CALL_SCREENING_DENYOPT	Specifies the type of call forward for which CSMI is applied.			C	R
CALL_SCREENING_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_SCREENING_SCRACTIVE	Indicates whether the SCRDUR parameter is required.			S	O
CALL_SCREENING_SCRDUR	Specifies the length of the screening period.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 763: C_NT-DMS100_SN06_MOD_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 764: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CSMI	A_NT-DMS100_SN06_MOD_CSMI

C_NT-DMS100_SN06_MOD_CWT

The Call Waiting (CWT) option allows the system to alert a busy station when an incoming call attempts to reach the directory number (DN).

Table 765: C_NT-DMS100_SN06_MOD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_CWT_OPTION	Indicates if the CWT option is active.	Y = Yes, N = No		S	O
CALL_WAITING_KEYLIST	Specifies key numbers of the DNS to which the user applied a feature. Appears when the user assigns a subset feature to a multi-line set.	Key number (1-69), list of key numbers, or $		C	O
CALL_WAITING_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_WAITING_PCWT	Precedence call waiting.	Y = Yes, N = No		S	O

Table 765: C_NT-DMS100_SN06_MOD_CWT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_RING	Specifies whether a ring from a telephone speaker is required in addition to the LCD diamond CWT key.	Y or N		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 766: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CWT	A_NT-DMS100_SN06_MOD_CWT

C_NT-DMS100_SN06_MOD_CXR

The call transfer (CXR) option allows the assignment of a call transfer type other than the type that the customer group has.

Table 767: C_NT-DMS100_SN06_MOD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_METHOD	The method of call transfer.	Dial (DIAL), Standard (STD), or Release (RLS)		S	R
CALL_TRANSFER_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
CALL_TRANSFER_ORGINTER	For a CUSTOM type call transfer, the first leg of the call is intergroup. The controller is the originator of the call.	AC = second leg of the call is to the attendant, Inter = second leg of the call can be intergroup, Intra = second leg of the call can be intragroup, Trater = second leg of the call can be intragroup or intergroup, Nocxfer = call transfer is not allowed		S	O
CALL_TRANSFER_ORGINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_RCL	Call transfer recall.			S	R
CALL_TRANSFER_RCLTIM	Recall timer for transfer recall.			S	O

Table 767: C_NT-DMS100_SN06_MOD_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_TRMINTER	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_TRMINTRA	First leg of the call is intragroup and the controller is the originator of the call.			S	O
CALL_TRANSFER_TYPE	Call transfer type.	CTOUT = call transfer outgoing calls, CTINC = call transfer incoming calls, CTINTRA = call transfer intra group, CTALL = call transfer all, NCT = the system routes the call to the attendant if the first leg of the call is INTERGROUP and the controller is terminator of the call, ATTRCLF = the system routes the call to the attendant at all times, CUSTOM = call transfer of types other than above		S	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 768: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_CXR	A_NT-DMS100_SN06_MOD_CXR

C_NT-DMS100_SN06_MOD_DIN

The DIN option prevents selected lines from receiving incoming calls that originate outside the customer group.

Table 769: C_NT-DMS100_SN06_MOD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_INCOMING_CALL_ALTTRC	Alternate terminating restriction code. This code applies to IBN extended calls. The value is in a format of a list in a series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DENIED_INCOMING_CALL_DINOPT	Assigns the Transfer Call to Restricted Station (DINE) sub-option to a line.	DINE = Accepts some types of transferred calls, N = Does not accept transferred calls		S	R
DENIED_INCOMING_CALL_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O

Table 769: C_NT-DMS100_SN06_MOD_DIN

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_INCOMING_CALL_TRC	Terminating restriction code used with the IBN DIN option. Code indicates the classes of incoming calls allowed on a trunk. The value is in a format of a list in series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 770: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_DIN	A_NT-DMS100_SN06_MOD_DIN

C_NT-DMS100_SN06_MOD_DQS

The Display Queue Status (DQS) option allows an ACD supervisor to display the load status information for an ACD group.

Table 771: C_NT-DMS100_SN06_MOD_DQS

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_STATUS_ACDGROUP	A group identifier already in Table ACDGRP.			S	R
DISPLAY_QUEUE_STATUS_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 772: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_DQS	A_NT-DMS100_SN06_MOD_DQS

C_NT-DMS100_SN06_MOD_DQT

The Display Queue Threshold (DQT) option allows the system to display the status of the incoming call queue. The status of the queue appears when the ACD agent or supervisor presses the associated key of the set.

Table 773: C_NT-DMS100_SN06_MOD_DQT

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_THRESHOLD_DIFFGRP	Indicates if the system uses a group other than the ACD INCALLS group to establish the queue threshold status.			S	R
DISPLAY_QUEUE_THRESHOLD_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 774: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_DQT	A_NT-DMS100_SN06_MOD_DQT

C_NT-DMS100_SN06_MOD_DRING

The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types.

Table 775: C_NT-DMS100_SN06_MOD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_ACD	Automatic call distribution.			S	R
DISTINCTIVE_RING_ACD_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_EXTRNL	Indicates external calls have distinctive ringing.			S	R
DISTINCTIVE_RING_EXTRNL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_GIC	Group Intercom.			S	R
DISTINCTIVE_RING_GIC_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_INTRNL	Indicates intragroup calls have distinctive ringing.			S	R
DISTINCTIVE_RING_INTRNL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_MAKECALL	Indicates distinctive ringing for outbound calls at customer group level.			S	O
DISTINCTIVE_RING_MAKECALL_DRINGTYPE	Specifies the ring type.			S	O

Table 775: C_NT-DMS100_SN06_MOD_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
DISTINCTIVE_RING_RECALL	Recall ringing.			S	R
DISTINCTIVE_RING_RECALL_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_REST	Call types that remain.			S	R
DISTINCTIVE_RING_REST_DRINGTYPE	Specifies the ring type.			S	O
DISTINCTIVE_RING_TRKS	IBN trunks.	SEL = selected trunks, ALL = all trunks, NO = no trunks		S	R
DISTINCTIVE_RING_UCD	Uniform call distribution.			S	R
DISTINCTIVE_RING_UCD_DRINGTYPE	Specifies the ring type.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 776: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_DRING	A_NT-DMS100_SN06_MOD_DRING

C_NT-DMS100_SN06_MOD_EMW

The Executive MessageWaiting (EMW) option introduces a message waiting class of service (MCOS) to enhance the message waiting option. A user can only access the MCOS to which the user subscribes.

Table 777: C_NT-DMS100_SN06_MOD_EMW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
EXECUTIVE_MESSAGE_WAIT_DNLIST	A DN key that subscribes to an MCOS. Specify one key for each MCOS. The valid entries are 1 to 69.			C	O
EXECUTIVE_MESSAGE_WAIT_MCOS	The name of the MCOS the MDC line subscribes, or the key set.			C	O
EXECUTIVE_MESSAGE_WAIT_NOTICE	Message waiting notification.	STD = stuttered dial tone, MWL = message waiting lamp, CMWI = CLASS message waiting Indicator, PRN = periodic ring notification		S	O

Table 777: C_NT-DMS100_SN06_MOD_EMW

Parameter Name	Description	Range	Default Value	Type	Class
EXECUTIVE_MESSAGE_WAIT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 778: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_EMW	A_NT-DMS100_SN06_MOD_EMW

C_NT-DMS100_SN06_MOD_ESL

The Emergency Service Line (ESL) allows a line for emergency service to be designated.

Table 779: C_NT-DMS100_SN06_MOD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 779: C_NT-DMS100_SN06_MOD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
EMERGENCY_SERVICE_LINE_FASTFLASH	An option for emergency service office lines. Usually N is used. Y is entered if the emergency service bureau is equipped with an SP-1 console or equivalent that has the ability to generate an 80-ms flash.			S	R
EMERGENCY_SERVICE_LINE_FORCED_DISCONNECT_TIME	Option used with an emergency service office line. The timing in seconds, longer than a 2 s flash, after which the call disconnects and the emergency service line goes on-hook.			S	R
EMERGENCY_SERVICE_LINE_INTEG_TONE	The integrity tone type.			S	R
EMERGENCY_SERVICE_LINE_INTEG_TONE_TIME	The interval in seconds after which the system generates an alarm and logs a report when an ESL line is off-hook.			S	R
EMERGENCY_SERVICE_LINE_RINGBACK	Option used with an emergency service office line to enable the office to ring back a caller who goes on-hook.			S	R

Table 779: C_NT-DMS100_SN06_MOD_ESL

Parameter Name	Description	Range	Default Value	Type	Class
EMERGENCY_SERVICE_LINE_ROH_TONE_TIME	An emergency service office line option parameter; the duration in seconds of the receiver off-hook tone a caller receives when the ESL flashes.			S	R
EMERGENCY_SERVICE_LINE_SWITCHHOOK_TONE	The tone the emergency service office line receives when a caller goes on-hook.	LOW = steady low tone BUSY = 60 interruptions per minute (IPM) busy tone		S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 780: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_ESL	A_NT-DMS100_SN06_MOD_ESL

C_NT-DMS100_SN06_MOD_FAA

The Forced Agent Availability (FAA) option allows an ACD (Automatic Call Distribution) supervisor to force an ACD agent from the Not Ready state to the Ready state.

Table 781: C_NT-DMS100_SN06_MOD_FAA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
FORCED_AGENT_AVAILABILITY_ACD GROUP	A group identifier already in Table ACDGRP.			S	R
FORCED_AGENT_AVAILABILITY_EXTN DFAA	Extended forced agent availability. Indicates if the feature is valid for ACD agents in any ACD group and subgroup in the same customer group as the supervisor.			S	R
FORCED_AGENT_AVAILABILITY_OPTK EY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 782: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_FAA	A_NT-DMS100_SN06_MOD_FAA

C_NT-DMS100_SN06_MOD_FEATURES

Modifies the option by first deleting the feature and then adding the feature again.

Table 783: C_NT-DMS100_SN06_MOD_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
DN	Directory number.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
LINE	4 digit line extension.			S	O
LEN	Line equipment number.			S	O
OPT	Options associated with a service you are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R
CUSTOM	Customer-specific parameter.			C	O

Table 783: C_NT-DMS100_SN06_MOD_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
IS_OPTIMIZED	A flag to indicate MML optimization of the command.	true or false	true	S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 784: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_FEATURES	A_NT-DMS100_SN06_DEL_FEATURES
	A_NT-DMS100_SN06_ADD_FEATURES

C_NT-DMS100_SN06_MOD_FTRGRP

The FTRGRP option allows the operating company to define a number of features as a feature group. The feature group can be assigned to customer lines.

Table 785: C_NT-DMS100_SN06_MOD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
FEATURE_GROUP_ GRPNAME	The name of the feature group with a minimum of one feature.			S	R
FEATURE_GROUP_ OPTKEY	Identifies a key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 785: C_NT-DMS100_SN06_MOD_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 786: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_FTRGRP	A_NT-DMS100_SN06_MOD_FTRGRP

C_NT-DMS100_SN06_MOD_GIC

The GIC option allows call termination on a member of a designated intercom group that uses abbreviated dialing. Use abbreviated dialing to access group members.

Table 787: C_NT-DMS100_SN06_MOD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
GROUP_INTERCOM_GICMEMNO	Digits dialed to reach this line.			S	R
GROUP_INTERCOM_GICNAME	Designated name of group intercom line.			S	R
GROUP_INTERCOM_GICNOMSB	Group intercom calls not included in MSB.			S	R
GROUP_INTERCOM_GICSMDR	SMDR records required.			S	R

Table 787: C_NT-DMS100_SN06_MOD_GIC

Parameter Name	Description	Range	Default Value	Type	Class
GROUP_INTERCOM _OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 788: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_GIC	A_NT-DMS100_SN06_MOD_GIC

C_NT-DMS100_SN06_MOD_ICM

The ICM option allows a business set user to directly terminate upon a predesignated business set by pressing the ICM feature key.

Table 789: C_NT-DMS100_SN06_MOD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 789: C_NT-DMS100_SN06_MOD_ICM

Parameter Name	Description	Range	Default Value	Type	Class
INTERCOM_BUSINESS_SET_DOR	Denied origination.			S	R
INTERCOM_BUSINESS_SET_LINK_LEN	The LEN of a member of an existing DLH or MLH Hunt group to which additional members are to be linked.			S	R
INTERCOM_BUSINESS_SET_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
INTERCOM_BUSINESS_SET_SIC_KEY	Straight intercom key.			S	R
INTERCOM_BUSINESS_SET_SMDR	Station message detail recording.			S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 790: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_ICM	A_NT-DMS100_SN06_MOD_ICM

C_NT-DMS100_SN06_MOD_KSH

The Key Short Hunt (KSH) option allows incoming calls to search for an idle directory number (DN) on which to terminate. The options search for this DN occurs through a set of DN appearances on a business set.

Table 791: C_NT-DMS100_SN06_MOD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
KEY_SHORT_HUNT _KEYLIST	Appears when an assignment of a subset feature to a multiline set occurs. Specifies key numbers of the DNs to which a feature will apply.			C	O
KEY_SHORT_HUNT _KSH_KEY	The line Hunt overflow route index that identifies the overflow route. The index identifies the key on business set or data unit. The index indicates the route reference number when Route (R) is the overflow for the KSH option.			S	O

Table 791: C_NT-DMS100_SN06_MOD_KSH

Parameter Name	Description	Range	Default Value	Type	Class
KEY_SHORT_HUNT _OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
KEY_SHORT_HUNT _OVDN	The overflow directory number for the KSH option when the OVTYPE is D.			S	O
KEY_SHORT_HUNT _OVTYPE	Type of overflow required when short Hunt group is busy.	N = no overflow, D = DN to which overflow is to go, R = route		S	R
KEY_SHORT_HUNT _TABID	A table identifier associated with the line overflow to a route (LOR) and KSH options.	OFRT = Office Route Reference Table, IBNRTE = IBN Route Reference Table		S	R
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 792: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_KSH	A_NT-DMS100_SN06_MOD_KSH

C_NT-DMS100_SN06_MOD_LPIC

Option Intra-LATA PIC (LPIC) allows the user to choose a primary carrier for Intra-LATA service. Field LCHOICE allows subscribers to dial Intra-LATA calls on a casual basis. This CSDL command changes the option parameters of the assigned line.

Table 793: C_NT-DMS100_SN06_MOD_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTRA_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTRA_PIC_CHOICE	Indicates whether the subscriber is allowed to casually dial Intra-LATA calls.	Y or N		S	R
INTRA_PIC_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 794: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_LPIC	A_NT-DMS100_SN06_MOD_LPIC

C_NT-DMS100_SN06_MOD_MDN

The MDN option assigns a DN to more than one set. A multiple appearance directory number (MADN) is a directory number (DN) that appears on more than one Meridian business set (MBS).

Table 795: C_NT-DMS100_SN06_MOD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MULTIPLE_APPEARANCE_DN_DIR_NUMBER	The directory number.			S	R
MULTIPLE_APPEARANCE_DN_MDNTYPE	The type of call Arrangement.	MCA = multiple call arrangement, SCA = single call arrangement, EXB = extension bridging		S	R
MULTIPLE_APPEARANCE_DN_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
MULTIPLE_APPEARANCE_DN_PRIMARY	Primary member of a MADN group.			S	R

Table 795: C_NT-DMS100_SN06_MOD_MDN

Parameter Name	Description	Range	Default Value	Type	Class
MULTIPLE_APPEARANCE_DN_RING	Indicates whether ringing is required.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 796: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_MDN	A_NT-DMS100_SN06_MOD_MDN

C_NT-DMS100_SN06_MOD_NAME

The system uses NAME feature to assign a name to DN. This CSDL changes the option parameters of the assigned line.

Table 797: C_NT-DMS100_SN06_MOD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NAME_DISPLAYNAME	Name to display on MBS set.			S	R

Table 797: C_NT-DMS100_SN06_MOD_NAME

Parameter Name	Description	Range	Default Value	Type	Class
NAME_NETNAME	Network name shown as DN attribute.			S	R
NAME_OPTKEY	Identifies a key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 798: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_NAME	A_NT-DMS100_SN06_MOD_NAME

C_NT-DMS100_SN06_MOD_NGTSRVCE

The Night Service (NGTSRVCE) option allows the ACD supervisor to place all ACD agent sets in an ACD group in night service mode. The ACD supervisor presses the Night Service key on the supervisor set to place the ACD agent sets in night service modes.

Table 799: C_NT-DMS100_SN06_MOD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 799: C_NT-DMS100_SN06_MOD_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NIGHT_SERVICE_ACDGROUP	A group identifier that the user already entered in Table ACDGRP. The identifier is the name of the automatic call distribution group to which this station belongs.			S	O
NIGHT_SERVICE_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 800: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_NGTSRVCE	A_NT-DMS100_SN06_MOD_NGTSRVCE

C_NT-DMS100_SN06_MOD_OBS

The Observe Agent (OBS) option allows a supervisor to observe conversations between an agent and a caller. This user presses the OBS key to observe conversations between an agent and a caller.

Table 801: C_NT-DMS100_SN06_MOD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OBSERVE_AGENT_ ACDGROUP	A group identifier that Table ACDGRP must already contain. The group identifier is the name of the automatic call distribution group to which this station belongs.			S	O
OBSERVE_AGENT_ DN	Specifies an ACD directory number. Appears if FOBSTYPE = DN.			S	O
OBSERVE_AGENT_F OBSTYPE	Appears if OBSTYPE is set to FOBS. Specifies the type of flexible call observing required.			S	O
OBSERVE_AGENT_F OBS_ACDGROUP	Appears if OBSTYPE is set to FOBS.			S	O

Table 801: C_NT-DMS100_SN06_MOD_OBS

Parameter Name	Description	Range	Default Value	Type	Class
OBSERVE_AGENT_FOBS_SUBGROUP	Specifies an ACD subgroup number. Appears if FOBSTYPE = SUBGROUP.			S	O
OBSERVE_AGENT_OBSTYPE	The type of observation a supervisor can apply over incoming ACD calls: basic, extended, or flexible call observing.			S	R
OBSERVE_AGENT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 802: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_OBS	A_NT-DMS100_SN06_MOD_OBS

C_NT-DMS100_SN06_MOD_PIC

Option Primary Inter-LATA Carrier (PIC) assigns a PIC to an MDC line. This CSDL command changes the option parameters of the assigned line.

Table 803: C_NT-DMS100_SN06_MOD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 803: C_NT-DMS100_SN06_MOD_PIC

Parameter Name	Description	Range	Default Value	Type	Class
INTER_PIC_CARRIER	See table OCCNAME for list of correct carrier names.			S	R
INTER_PIC_CHOICE	Specifies whether the system allows the user to dial 10xxx to access other carriers. Value Y or N.			S	R
INTER_PIC_OPTKEY	Identifies a key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 804: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_PIC	A_NT-DMS100_SN06_MOD_PIC

C_NT-DMS100_SN06_MOD_RMI

The RMI option allows subscribers of the MessageWaiting (MWT) feature to check for the existence of messages in their voice mailbox from a remote location. This CSDL command changes the option parameters of the assigned line.

Table 805: C_NT-DMS100_SN06_MOD_RMI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
REMOTE_MESSAGE_INDICATOR_OPTKEY	Identifies the key on the business set or data units to which an option is assigned.	1-69 for business set; 1, 2, 3, 4, or 7 for data unit		S	O
REMOTE_MESSAGE_INDICATOR_RMI_STATE	The state of the RMI feature.	active or inactive		S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 806: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_RMI	A_NT-DMS100_SN06_MOD_RMI

C_NT-DMS100_SN06_MOD_SCA

The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN). This CSDL command changes the option parameters of the assigned line.

Table 807: C_NT-DMS100_SN06_MOD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_ACCEPTANCE_BILLING_OPTION	NOAMA indicates that the feature is billed based on a subscription and AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.			S	O
SELECTIVE_CALL_ACCEPTANCE_OPTKEY	Identifies the key on the business set or data units to which an option is assigned.	1-69 for business set; 1, 2, 3, 4, or 7 for data unit		S	O

Table 807: C_NT-DMS100_SN06_MOD_SCA

Parameter Name	Description	Range	Default Value	Type	Class
SELECTIVE_CALL_ACCEPTANCE_STATUS	INACT indicates the option is not enabled (inactive), ACT indicates the option is enabled (active), UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 808: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_SCA	A_NT-DMS100_SN06_MOD_SCA

C_NT-DMS100_SN06_MOD_SCU

The SCU option allows a line to be designated as a speed calling user in a speed calling group. A speed calling user can only originate calls with speed calling and cannot affect the contents of the speed calling list.

Table 809: C_NT-DMS100_SN06_MOD_SCU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 809: C_NT-DMS100_SN06_MOD_SCU

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_USER_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SPEED_CALLING_USER_SCUGNUMBER	Specifies a unique group number for the SCU option.			S	R
SPEED_CALLING_USER_SCU_TDN	Specifies whether toll denial is applied to speed call numbers.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 810: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_SCU	A_NT-DMS100_SN06_MOD_SCU

C_NT-DMS100_SN06_MOD_SDN

To add a secondary DN to a Teen Service line, the SDN option can be assigned to POTS, RES, or IBN agents. When no SDNs are assigned to the line, adding the SDN option establishes Teen Service. This CSDL changes the option parameters of the assigned line.

Table 811: C_NT-DMS100_SN06_MOD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SECONDARY_DN_DN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_DNY	These options are not applicable to MDC. Enter $ to omit both options.	NODNY = No deny to call waiting. DNYCWT = Deny call waiting.		S	O
SECONDARY_DN_LINE	Secondary LINE.			S	O

Table 811: C_NT-DMS100_SN06_MOD_SDN

Parameter Name	Description	Range	Default Value	Type	Class
SECONDARY_DN_NEW_DN	New Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_NEW_LINE	New Secondary LINE.			S	O
SECONDARY_DN_NEW_NPA	New Secondary NPA.			S	O
SECONDARY_DN_NEW_NXX	New Secondary NXX.			S	O
SECONDARY_DN_NPA	Secondary NPA.			S	O
SECONDARY_DN_NXX	Secondary NXX.			S	O
SECONDARY_DN_OPT	Secondary DN type.	P = forward SDN with PDN, N = do not forward SDN, E = enhanced SDN can have own option list		S	R
SECONDARY_DN_RING	Secondary DN ring type.	0 = normal ringing, 1 = SDN pattern #1, 2 = SDN pattern #2, 3 = SDN pattern #3		S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 812: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_SDN	A_NT-DMS100_SN06_MOD_SDN

C_NT-DMS100_SN06_MOD_SHU

The SHU option allows hunting at a line to be canceled when activated. SHU can be assigned to one, several, or all lines in a Hunt group.

Table 813: C_NT-DMS100_SN06_MOD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STOP_HUNT_NORMAL_STATE	Normal state of the SD point. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Table 813: C_NT-DMS100_SN06_MOD_SHU

Parameter Name	Description	Range	Default Value	Type	Class
STOP_HUNT_POINT	SD point number. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_SC	Scan point.	tmtype = MTM, RSMtmno = 0-2047, tmcktno = 0-29, point = 0-6 (SD point number), normal_state = 0 for open or 1 for closed		S	R
STOP_HUNT_TMCKTNO	Enter the trunk module circuit number to which the circuit is assigned. Appears after the SD or SC prompt if data is not entered on one line.			S	R
STOP_HUNT_TMNO	Enter the number of the trunk module on which the circuit is mounted. Appears after the signal distribution (SD) or SC prompt if data is not entered on one line.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 814: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_SHU	A_NT-DMS100_SN06_MOD_SHU

C_NT-DMS100_SN06_MOD_SUPR

The SUPR option establishes an automatic call distribution (ACD) supervisor set when assigned to key 1. This option must be assigned before the ACD supervisor options can be assigned to the set.

Table 815: C_NT-DMS100_SN06_MOD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SUPERVISOR_IDNUM	Indicates if ID number of agent position is required.	Y = Yes, N = No		C	R
SUPERVISOR_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O
SUPERVISOR_PRIMARY_ACDGROUP	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.			C	R

Table 815: C_NT-DMS100_SN06_MOD_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
SUPERVISOR_PRIMARY_ACDSGRP	The supervisor subgroup identifier that must already be datafilled in Table ACDSGRP in order to add the SUPR option to an ACD group.			C	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 816: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_SUPR	A_NT-DMS100_SN06_MOD_SUPR

C_NT-DMS100_SN06_MOD_SVCGRP

The SVCGRP option allows options CLID (Calling Line Identification Display), NAME (Name Display) and REASDSP (Reason Display), packaged in a service group, to be assigned to a selected line in a customer group or multiple customer groups.

Table 817: C_NT-DMS100_SN06_MOD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 817: C_NT-DMS100_SN06_MOD_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
SERVICE_GROUP_GRPNAME	The group identifier that must already be datafilled in Table ACDGRP when adding the SUPR option to an ACD group.			S	R
SERVICE_GROUP_OPTKEY	Identifies key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 818: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_SVCGRP	A_NT-DMS100_SN06_MOD_SVCGRP

Modify Line Features

This cartridge provides the following CSDL Commands:

- C_NT-DMS100_SN06_MOD_DN
- C_NT-DMS100_SN06_MOD_INTERCEPT_NAME
- C_NT-DMS100_SN06_MOD_LCC
- C_NT-DMS100_SN06_MOD_LEN
- C_NT-DMS100_SN06_MOD_LTG
- C_NT-DMS100_SN06_MOD_MULTILINE-LEN
- C_NT-DMS100_SN06_MOD_NCOS

C_NT-DMS100_SN06_MOD_DN

The CDN command changes directory numbers (DN).

Table 819: C_NT-DMS100_SN06_MOD_DN

Parameter Name	Description	Range	Default Value	Type	Class
BLK_TOLL_COM	Appears for the RCF option. Specifies whether incoming toll calls are forwarded to a remote station.	Y or N		S	O
BLK_TOLL_TREATMENT	Appears for the RCF option. Specifies the treatment given to a blocked toll call.			S	O
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
FWD_DN	The DN (up to 30 digits) to which calls are forwarded in a fixed call forwarding option.			S	O
INTERCEPT_NAME	The type of intercept you want.	BLDN, AINT, ANCT, CANN, OPRT, and UNDN		S	O
LINE	4 digit line extension of the new DN number.			S	O

Table 819: C_NT-DMS100_SN06_MOD_DN

Parameter Name	Description	Range	Default Value	Type	Class
LTG	Line treatment group member, used to calculate the line attribute index then the DN and LCC are insufficient to find an appropriate index. LTG is prompted for in conjunction with LCC.	0-255		S	O
MAXCALLS	Appears during the assignment of an RCF. Specifies the maximum number of simultaneous calls allowed to the DN.	0-511		S	O
MRSA	MRSA as defined in table MRSANAME. Message rate service area to be used for billing with remote call forwarding.			S	O
NEW_DN	Enter the new DN that replaces the previous DN.			S	O
NEW_LINE	4 digit line extension of the new DN number.			S	O
NEW_NPA	3 digit area code of the new DN number.			S	O
NEW_NXX	First 3 digits of the line number of the new DN number.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 819: C_NT-DMS100_SN06_MOD_DN

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
OM_INDEX	Operations measurements index.	0-127		S	O
SCRNCL	Specifies route or screening class for a forwarded call.	RTE, SCR		S	O
SIGDATA	Specifies whether or not to use RCF signaling enhancements.	Y or N		S	O
VDNTYPE	Used to provision VDNs.	When BLOCK_OF_DNS is NO, the following inputs are valid: AIN, DISA, CFIB, RCF, RCFEA, RTE, MSR, SIMRING. When BLOCK_OF_DNS is YES, the valid input is RTE		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 820: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_DN	A_NT-DMS100_SN06_MOD_DN

C_NT-DMS100_SN06_MOD_INTERCEPT_NAME

The CICP command changes the intercept name.

Table 821: C_NT-DMS100_SN06_MOD_INTERCEPT_NAME

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
INTERCEPT_NAME	New intercept name.			S	R
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 822: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_INTERCEPT_NAME	A_NT-DMS100_SN06_MOD_INTERCEPT_NAME

C_NT-DMS100_SN06_MOD_LCC

The CHG-LCC command changes the LCC.

Table 823: C_NT-DMS100_SN06_MOD_LCC

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LATA	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	R
LCC	The line class code of the service to be modified.			S	R
LINE	4 digit line extension.			S	O
LTG	Line treatment group member used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index.	0-255		S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 823: C_NT-DMS100_SN06_MOD_LCC

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 824: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_LCC	A_NT-DMS100_SN06_MOD_LCC

C_NT-DMS100_SN06_MOD_LEN

The CLN command changes the line equipment number (LEN).

Table 825: C_NT-DMS100_SN06_MOD_LEN

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LEN	Current line equipment number.			S	R
NEW_LEN	New line equipment number.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 826: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_LEN	A_NT-DMS100_SN06_MOD_LEN

C_NT-DMS100_SN06_MOD_LTG

The CLTG command changes the line treatment group (LTG) number to route a call through a different trunk group.

Table 827: C_NT-DMS100_SN06_MOD_LTG

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LINE	4 digit line extension.			S	O
LTG	Line treatment group member used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. LTG is prompted for in conjunction with LCC.	0-255		S	R

Table 827: C_NT-DMS100_SN06_MOD_LTG

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 828: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_LTG	A_NT-DMS100_SN06_MOD_LTG

C_NT-DMS100_SN06_MOD_MULTILINE-LEN

The CKLN command changes the keyset value of the line equipment number (LEN).

Table 829: C_NT-DMS100_SN06_MOD_MULTILINE-LEN

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LEN	Old line equipment number.			S	R
NEW_LEN	New line equipment number.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 830: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_MULTILINE-LEN	A_NT-DMS100_SN06_MOD_MULTILINE-LEN

C_NT-DMS100_SN06_MOD_NCOS

The CHG command changes the NCOS.

Table 831: C_NT-DMS100_SN06_MOD_NCOS

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LINE	4 digit line extension.			S	O
NCOS	New network class of service.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service

Table 832: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_MOD_NCOS	A_NT-DMS100_SN06_MOD_NCOS

Delete Feature Services

This cartridge provides the following CSDL Commands:

- C_NT-DMS100_SN06_DEL_3WC
- C_NT-DMS100_SN06_DEL_ACB
- C_NT-DMS100_SN06_DEL_ACD
- C_NT-DMS100_SN06_DEL_ACDNR
- C_NT-DMS100_SN06_DEL_ACRJ
- C_NT-DMS100_SN06_DEL_AIN
- C_NT-DMS100_SN06_DEL_AINDN
- C_NT-DMS100_SN06_DEL_AMSGDENY
- C_NT-DMS100_SN06_DEL_AR
- C_NT-DMS100_SN06_DEL_ARDDN
- C_NT-DMS100_SN06_DEL_ASL
- C_NT-DMS100_SN06_DEL_AUD
- C_NT-DMS100_SN06_DEL_AUL
- C_NT-DMS100_SN06_DEL_AUTODISP
- C_NT-DMS100_SN06_DEL_CBE
- C_NT-DMS100_SN06_DEL_CBU
- C_NT-DMS100_SN06_DEL_CCW
- C_NT-DMS100_SN06_DEL_CDE
- C_NT-DMS100_SN06_DEL_CDI
- C_NT-DMS100_SN06_DEL_CDU
- C_NT-DMS100_SN06_DEL_CFB
- C_NT-DMS100_SN06_DEL_CFBL
- C_NT-DMS100_SN06_DEL_CFD
- C_NT-DMS100_SN06_DEL_CFDA
- C_NT-DMS100_SN06_DEL_CFDVT

- C_NT-DMS100_SN06_DEL_CFF
- C_NT-DMS100_SN06_DEL_CFGD
- C_NT-DMS100_SN06_DEL_CFGDA
- C_NT-DMS100_SN06_DEL_CFI
- C_NT-DMS100_SN06_DEL_CFMDN
- C_NT-DMS100_SN06_DEL_CFRA
- C_NT-DMS100_SN06_DEL_CFS
- C_NT-DMS100_SN06_DEL_CFU
- C_NT-DMS100_SN06_DEL_CFW
- C_NT-DMS100_SN06_DEL_CHD
- C_NT-DMS100_SN06_DEL_CIF
- C_NT-DMS100_SN06_DEL_CIR
- C_NT-DMS100_SN06_DEL_CLF
- C_NT-DMS100_SN06_DEL_CLI
- C_NT-DMS100_SN06_DEL_CNAB
- C_NT-DMS100_SN06_DEL_CNAMD
- C_NT-DMS100_SN06_DEL_CND
- C_NT-DMS100_SN06_DEL_CND-NO-BILL
- C_NT-DMS100_SN06_DEL_CNDB
- C_NT-DMS100_SN06_DEL_CNF
- C_NT-DMS100_SN06_DEL_COD
- C_NT-DMS100_SN06_DEL_COT
- C_NT-DMS100_SN06_DEL_COT-NO-BILL
- C_NT-DMS100_SN06_DEL_CPU
- C_NT-DMS100_SN06_DEL_CSMI
- C_NT-DMS100_SN06_DEL_CUSD
- C_NT-DMS100_SN06_DEL_CWD
- C_NT-DMS100_SN06_DEL_CWI
- C_NT-DMS100_SN06_DEL_CWO
- C_NT-DMS100_SN06_DEL_CWT
- C_NT-DMS100_SN06_DEL_CWX
- C_NT-DMS100_SN06_DEL_CXR
- C_NT-DMS100_SN06_DEL_DCF
- C_NT-DMS100_SN06_DEL_DCPU
- C_NT-DMS100_SN06_DEL_DDN
- C_NT-DMS100_SN06_DEL_DENY

- C_NT-DMS100_SN06_DEL_DENYACB
- C_NT-DMS100_SN06_DEL_DENYAR
- C_NT-DMS100_SN06_DEL_DENYCOT
- C_NT-DMS100_SN06_DEL_DENYCSMI
- C_NT-DMS100_SN06_DEL_DENYISA
- C_NT-DMS100_SN06_DEL_DENYU3WC
- C_NT-DMS100_SN06_DEL_DGT
- C_NT-DMS100_SN06_DEL_DIN
- C_NT-DMS100_SN06_DEL_DISP
- C_NT-DMS100_SN06_DEL_DNH
- C_NT-DMS100_SN06_DEL_DOR
- C_NT-DMS100_SN06_DEL_DQS
- C_NT-DMS100_SN06_DEL_DQT
- C_NT-DMS100_SN06_DEL_DRCW
- C_NT-DMS100_SN06_DEL_DRING
- C_NT-DMS100_SN06_DEL_DSCWID
- C_NT-DMS100_SN06_DEL_DTM
- C_NT-DMS100_SN06_DEL_ELN
- C_NT-DMS100_SN06_DEL_EMW
- C_NT-DMS100_SN06_DEL_ESL
- C_NT-DMS100_SN06_DEL_FAA
- C_NT-DMS100_SN06_DEL_FANI
- C_NT-DMS100_SN06_DEL_FEATURES
- C_NT-DMS100_SN06_DEL_FTRGRP
- C_NT-DMS100_SN06_DEL_GIC
- C_NT-DMS100_SN06_DEL_GND
- C_NT-DMS100_SN06_DEL_HOT
- C_NT-DMS100_SN06_DEL_ICM
- C_NT-DMS100_SN06_DEL_INSPECT
- C_NT-DMS100_SN06_DEL_INT
- C_NT-DMS100_SN06_DEL_INTPIC
- C_NT-DMS100_SN06_DEL_KSH
- C_NT-DMS100_SN06_DEL_LCDR
- C_NT-DMS100_SN06_DEL_LDSA
- C_NT-DMS100_SN06_DEL_LDSO
- C_NT-DMS100_SN06_DEL_LNR

- C_NT-DMS100_SN06_DEL_LNRA
- C_NT-DMS100_SN06_DEL_LOB
- C_NT-DMS100_SN06_DEL_LOD
- C_NT-DMS100_SN06_DEL_LPIC
- C_NT-DMS100_SN06_DEL_LVM
- C_NT-DMS100_SN06_DEL_M518
- C_NT-DMS100_SN06_DEL_M536
- C_NT-DMS100_SN06_DEL_MDN
- C_NT-DMS100_SN06_DEL_MSB
- C_NT-DMS100_SN06_DEL_MSBI
- C_NT-DMS100_SN06_DEL_MWT
- C_NT-DMS100_SN06_DEL_NAME
- C_NT-DMS100_SN06_DEL_NDC
- C_NT-DMS100_SN06_DEL_NFA
- C_NT-DMS100_SN06_DEL_NGTSRVCE
- C_NT-DMS100_SN06_DEL_NLT
- C_NT-DMS100_SN06_DEL_OBS
- C_NT-DMS100_SN06_DEL_ONI
- C_NT-DMS100_SN06_DEL_PIC
- C_NT-DMS100_SN06_DEL_PORT
- C_NT-DMS100_SN06_DEL_PRK
- C_NT-DMS100_SN06_DEL_PRL
- C_NT-DMS100_SN06_DEL_QTD
- C_NT-DMS100_SN06_DEL_RAG
- C_NT-DMS100_SN06_DEL_RCHD
- C_NT-DMS100_SN06_DEL_RMI
- C_NT-DMS100_SN06_DEL_RMR
- C_NT-DMS100_SN06_DEL_RMT
- C_NT-DMS100_SN06_DEL_RPA
- C_NT-DMS100_SN06_DEL_RSP
- C_NT-DMS100_SN06_DEL_RSUS
- C_NT-DMS100_SN06_DEL_SACB
- C_NT-DMS100_SN06_DEL_SC1
- C_NT-DMS100_SN06_DEL_SC2
- C_NT-DMS100_SN06_DEL_SCA
- C_NT-DMS100_SN06_DEL_SCF

- C_NT-DMS100_SN06_DEL_SCL
- C_NT-DMS100_SN06_DEL_SCRJ
- C_NT-DMS100_SN06_DEL_SCS
- C_NT-DMS100_SN06_DEL_SCU
- C_NT-DMS100_SN06_DEL_SCWID
- C_NT-DMS100_SN06_DEL_SDN
- C_NT-DMS100_SN06_DEL_SDSDENY
- C_NT-DMS100_SN06_DEL_SHU
- C_NT-DMS100_SN06_DEL_SL
- C_NT-DMS100_SN06_DEL_SMDR
- C_NT-DMS100_SN06_DEL_SPB
- C_NT-DMS100_SN06_DEL_SRA
- C_NT-DMS100_SN06_DEL_SSAC
- C_NT-DMS100_SN06_DEL_SUPPRESS
- C_NT-DMS100_SN06_DEL_SUPR
- C_NT-DMS100_SN06_DEL_SVCGRP
- C_NT-DMS100_SN06_DEL_TCW
- C_NT-DMS100_SN06_DEL_TDN
- C_NT-DMS100_SN06_DEL_TFO
- C_NT-DMS100_SN06_DEL_UCD
- C_NT-DMS100_SN06_DEL_VMEADENY
- C_NT-DMS100_SN06_DEL_VMEADN
- C_NT-DMS100_SN06_DEL_WML
- C_NT-DMS100_SN06_DEL_WUC
- C_NT-DMS100_SN06_DEL_WUCR
- C_NT_DMS100_SN06_DEL_DCPK

C_NT-DMS100_SN06_DEL_3WC

Removes this option from the assigned line. This option allows the subscriber on the assigned line to place a call on hold. When the call is on hold, the subscriber can set up a request call to another subscriber.

Table 833: C_NT-DMS100_SN06_DEL_3WC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 833: C_NT-DMS100_SN06_DEL_3WC

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
THREE_WAY_CONFERENCE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 834: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_3WC	A_NT-DMS100_SN06_DEL_3WC

C_NT-DMS100_SN06_DEL_ACB

Removes this option from the assigned line. The ACB option allows subscribers to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call.

Table 835: C_NT-DMS100_SN06_DEL_ACB

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_BACK_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 836: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ACB	A_NT-DMS100_SN06_DEL_ACB

C_NT-DMS100_SN06_DEL_ACD

ACD allows the subscriber to call the last station the subscriber called. If the line is busy, ACB monitors the line until it becomes idle and accepts the call.

Table 837: C_NT-DMS100_SN06_DEL_ACD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 838: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ACD	A_NT-DMS100_SN06_DEL_ACD

C_NT-DMS100_SN06_DEL_ACDNR

The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN).

Table 839: C_NT-DMS100_SN06_DEL_ACDNR

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_CALL_DISTRIBUTION_NOT_READY_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 840: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ACDNR	A_NT-DMS100_SN06_DEL_ACDNR

C_NT-DMS100_SN06_DEL_ACRJ

Removes this option from the assigned line. The Anonymous Caller Rejection (ACRJ) option allows a subscriber to reject incoming calls from callers who block their names or directory numbers (DN).

Table 841: C_NT-DMS100_SN06_DEL_ACRJ

Parameter Name	Description	Range	Default Value	Type	Class
ANONYMOUS_CALLER_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 842: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ACRJ	A_NT-DMS100_SN06_DEL_ACRJ

C_NT-DMS100_SN06_DEL_AIN

The AIN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN.

Table 843: C_NT-DMS100_SN06_DEL_AIN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
PRIVACY_ID_GROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 844: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AIN	A_NT-DMS100_SN06_DEL_AIN

C_NT-DMS100_SN06_DEL_AINDN

Removes this option from the assigned line. The AINDN option assigns Advanced Intelligent Network (AIN) terminating trigger subscriptions to a directory number (DN). Use the Trigger Item interface to subscribe to an AINDN.

Table 845: C_NT-DMS100_SN06_DEL_AINDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
PRIVACY_ID_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 846: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AINDN	A_NT-DMS100_SN06_DEL_AINDN

C_NT-DMS100_SN06_DEL_AMSGDENY

Removes this option from the assigned line. The AMSGDENY option prevents the line from accessing a messaging service. The operating company assigns the AMSGDENY option.

Table 847: C_NT-DMS100_SN06_DEL_AMSGDENY

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 848: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AMSGDENY	A_NT-DMS100_SN06_DEL_AMSGDENY

C_NT-DMS100_SN06_DEL_AR

Removes this option from the assigned line. The AR option allows a subscriber to call the last station that called the subscriber.

Table 849: C_NT-DMS100_SN06_DEL_AR

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_RECALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 850: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AR	A_NT-DMS100_SN06_DEL_AR

C_NT-DMS100_SN06_DEL_ARDDN

Removes this option from the assigned line. The ARDDN option allows subscribers to dial a feature code that sets up a call to the directory number (DN) where the subscriber placed the last incoming call.

Table 851: C_NT-DMS100_SN06_DEL_ARDDN

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_RECALL_DIALABLE_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 852: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ARDDN	A_NT-DMS100_SN06_DEL_ARDDN

C_NT-DMS100_SN06_DEL_ASL

The ASL option allows a supervisor to monitor the status of an agent position. This process does not interfere with the call. The lamp for the assigned agent status key reflects the status of the call.

Table 853: C_NT-DMS100_SN06_DEL_ASL

Parameter Name	Description	Range	Default Value	Type	Class
AGENT_STATUS_LAMP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 854: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ASL	A_NT-DMS100_SN06_DEL_ASL

C_NT-DMS100_SN06_DEL_AUD

The AUD option allows a business set subscriber to call a number the subscriber dials frequently. The subscriber presses the AUD key to call this number. The subscriber can program and change this number.

Table 855: C_NT-DMS100_SN06_DEL_AUD

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DIAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 856: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AUD	A_NT-DMS100_SN06_DEL_AUD

C_NT-DMS100_SN06_DEL_AUL

Removes this option from the assigned line. The automatic line (AUL) option connects to a set location when a directory number (DN) or an assigned AUL option line reports an off-hook status.

Table 857: C_NT-DMS100_SN06_DEL_AUL

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 858: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AUL	A_NT-DMS100_SN06_DEL_AUL

C_NT-DMS100_SN06_DEL_AUTODISP

The automatic display (AUTODISP) option automatically shows information on incoming calls to a Meridian business set (MBS).

Table 859: C_NT-DMS100_SN06_DEL_AUTODISP

Parameter Name	Description	Range	Default Value	Type	Class
AUTOMATIC_DISPLAY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 860: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_AUTODISP	A_NT-DMS100_SN06_DEL_AUTODISP

C_NT-DMS100_SN06_DEL_CBE

The Call Forwarding Busy Internal Calls Only (CBE) option allows the subscriber to stop the system when the system forwards external calls. The CBE option allows intragroup calls to forward to a remote station in the customer group.

Table 861: C_NT-DMS100_SN06_DEL_CBE

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_INTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 862: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CBE	A_NT-DMS100_SN06_DEL_CBE

C_NT-DMS100_SN06_DEL_CBU

Removes this option from the assigned line. The CBU option allows Call Forwarding Busy calls to forward to remote stations outside and inside the customer group.

Table 863: C_NT-DMS100_SN06_DEL_CBU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 864: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CBU	A_NT-DMS100_SN06_DEL_CBU

C_NT-DMS100_SN06_DEL_CCW

Removes this option from the assigned line. The Cancel Call Waiting (CCW) option allows Call Waiting (CWT) subscribers to turn off the CWT option.

Table 865: C_NT-DMS100_SN06_DEL_CCW

Parameter Name	Description	Range	Default Value	Type	Class
CANCEL_CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 866: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CCW	A_NT-DMS100_SN06_DEL_CCW

C_NT-DMS100_SN06_DEL_CDE

The CDE option prevents the forwarding of calls from outside the customer group. This option can make sure that external calls do not flood the remote station when many of the incoming calls are external.

Table 867: C_NT-DMS100_SN06_DEL_CDE

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_EXCLUDE_EXTERNAL_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 868: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CDE	A_NT-DMS100_SN06_DEL_CDE

C_NT-DMS100_SN06_DEL_CDI

The CDI option prevents the forwarding of intragroup calls. The CDI makes sure that intragroup calls do not flood the remote station.

Table 869: C_NT-DMS100_SN06_DEL_CDI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_EXCLUDE_INTRAGROUP_OPTKEY	A key on business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 870: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CDI	A_NT-DMS100_SN06_DEL_CDI

C_NT-DMS100_SN06_DEL_CDU

Removes this option from the assigned line. The CDU option allows the system to forward all calls that are not answered to a remote station that is outside or inside customer group.

Table 871: C_NT-DMS100_SN06_DEL_CDU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_UNRESTRICTED_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 872: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CDU	A_NT-DMS100_SN06_DEL_CDU

C_NT-DMS100_SN06_DEL_CFB

Removes this option from the assigned line. The CFB option allows the system to forward all calls to a busy station to a station determined earlier.

Table 873: C_NT-DMS100_SN06_DEL_CFB

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 874: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFB	A_NT-DMS100_SN06_DEL_CFB

C_NT-DMS100_SN06_DEL_CFBL

Removes this option from the assigned line. The CFBL option allows the subscriber to specify a directory number (DN).

Table 875: C_NT-DMS100_SN06_DEL_CFBL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 876: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFBL	A_NT-DMS100_SN06_DEL_CFBL

C_NT-DMS100_SN06_DEL_CFD

Removes this option from the assigned line. The CFD option allows the system to forward incoming calls that are not answered in a specified time.

Table 877: C_NT-DMS100_SN06_DEL_CFD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 878: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFD	A_NT-DMS100_SN06_DEL_CFD

C_NT-DMS100_SN06_DEL_CFDA

Removes this option from the assigned line. The Call Forwarding Do Not Answer (CFDA) Residential option forwards calls not answered to stations in the same customer group.

Table 879: C_NT-DMS100_SN06_DEL_CFDA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 880: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFDA	A_NT-DMS100_SN06_DEL_CFDA

C_NT-DMS100_SN06_DEL_CFDVT

Removes this option from the assigned line. The Call Forwarding Do Not Answer Variable Timer (CFDVT) option allows an end-user to specify how long a call rings before the system forwards the call to another station.

Table 881: C_NT-DMS100_SN06_DEL_CFDVT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_NO_ANSWER_VAR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 882: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFDVT	A_NT-DMS100_SN06_DEL_CFDVT

C_NT-DMS100_SN06_DEL_CFF

The CFF option allows the station to forward calls to a location the operating company enters. The user cannot program the number to which the station forwards the calls.

Table 883: C_NT-DMS100_SN06_DEL_CFF

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_FIXED	Call forwarding DN for CFF option.			S	O
CALL_FORWARD_FIXED	Enter the value to CFFA to set it to active.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 884: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFF	A_NT-DMS100_SN06_DEL_CFF

C_NT-DMS100_SN06_DEL_CFGD

Removes this option from the assigned line. The CFGD option allows the user to assign call forwarding do not answer to separate Hunt groups.

Table 885: C_NT-DMS100_SN06_DEL_CFGD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_GROUP_NO_ANSWER_BUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 886: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFGD	A_NT-DMS100_SN06_DEL_CFGD

C_NT-DMS100_SN06_DEL_CFGDA

Removes this option from the assigned line. The CFGDA option allows the system administrator to assign call forwarding to a Hunt group. The system forwards the calls to a DN outside the Hunt group.

Table 887: C_NT-DMS100_SN06_DEL_CFGDA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 888: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFGDA	A_NT-DMS100_SN06_DEL_CFGDA

C_NT-DMS100_SN06_DEL_CFI

The CFI option allows stations to forward calls only to locations in the customer group that the customer defines.

Table 889: C_NT-DMS100_SN06_DEL_CFI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_INTRAGROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 890: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFI	A_NT-DMS100_SN06_DEL_CFI

C_NT-DMS100_SN06_DEL_CFMDN

The Call Forwarding MADN Secondary Number (CFMDN) option lets secondary units of a multiple appearance directory number (MADN) group, activate call forwarding (CFF, CFU and CFI only) from a station.

Table 891: C_NT-DMS100_SN06_DEL_CFMDN

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_MADN_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 892: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFMDN	A_NT-DMS100_SN06_DEL_CFMDN

C_NT-DMS100_SN06_DEL_CFRA

Removes this option from the assigned line. The Call Forwarding Remote Access (CFRA) option allows a single-line set to use a line other than its own.

Table 893: C_NT-DMS100_SN06_DEL_CFRA

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_REMOTE_ACTIVATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 894: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFRA	A_NT-DMS100_SN06_DEL_CFRA

C_NT-DMS100_SN06_DEL_CFS

The Call Forwarding Simultaneous/Screening (CFS) option allows the user to call forward more than one call through a station at a time.

Table 895: C_NT-DMS100_SN06_DEL_CFS

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_SIMULTANEUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 896: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFS	A_NT-DMS100_SN06_DEL_CFS

C_NT-DMS100_SN06_DEL_CFU

Removes this option from the assigned line. The CFU option allows a station user to reroute incoming calls to another telephone number.

Table 897: C_NT-DMS100_SN06_DEL_CFU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_UNIVERSAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 898: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFU	A_NT-DMS100_SN06_DEL_CFU

C_NT-DMS100_SN06_DEL_CFW

Removes this option from the assigned line. The CFW option allows the user to forward calls to another location.

Table 899: C_NT-DMS100_SN06_DEL_CFW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 900: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CFW	A_NT-DMS100_SN06_DEL_CFW

C_NT-DMS100_SN06_DEL_CHD

Removes this option from the assigned line. The Call Hold (CHD) option allows a subscriber with a 500/2500 set to hold a call.

Table 901: C_NT-DMS100_SN06_DEL_CHD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 901: C_NT-DMS100_SN06_DEL_CHD

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 902: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CHD	A_NT-DMS100_SN06_DEL_CHD

C_NT-DMS100_SN06_DEL_CIF

The Controlled Interflow (CIF) option allows a supervisor to place an automatic call distribution (ACD) group in a controlled interflow mode.

Table 903: C_NT-DMS100_SN06_DEL_CIF

Parameter Name	Description	Range	Default Value	Type	Class
CONTROLLED_INTERFLOW_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 903: C_NT-DMS100_SN06_DEL_CIF

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 904: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CIF	A_NT-DMS100_SN06_DEL_CIF

C_NT-DMS100_SN06_DEL_CIR

Removes this option from the assigned line. The Circular Hunt (CIR) option allows hunting to complete a full cycle through a Hunt group.

Table 905: C_NT-DMS100_SN06_DEL_CIR

Parameter Name	Description	Range	Default Value	Type	Class
CIRCULAR_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 905: C_NT-DMS100_SN06_DEL_CIR

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 906: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CIR	A_NT-DMS100_SN06_DEL_CIR

C_NT-DMS100_SN06_DEL_CLF

Removes this option from the assigned line. The Calling Line Identification with Flash (CLF) option allows a subscriber to hold an incoming call in the switch.

Table 907: C_NT-DMS100_SN06_DEL_CLF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 908: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CLF	A_NT-DMS100_SN06_DEL_CLF

C_NT-DMS100_SN06_DEL_CLI

Removes this option from the assigned line. Local and toll calls can stop on the line of the subscriber. If the calls stop, the Calling Line Identification (CLI) option records the following information on the DMS log system.

Table 909: C_NT-DMS100_SN06_DEL_CLI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACE_CLI_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 910: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CLI	A_NT-DMS100_SN06_DEL_CLI

C_NT-DMS100_SN06_DEL_CNAB

Removes this option from the assigned line. The CNAB option allows the system to block the delivery of the name of the caller.

Table 911: C_NT-DMS100_SN06_DEL_CNAB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 912: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CNAB	A_NT-DMS100_SN06_DEL_CNAB

C_NT-DMS100_SN06_DEL_CNAMD

Removes this option from the assigned line. The CNAMD option displays the name of the incoming caller and the time and date of the call on the customer premises equipment (CPE).

Table 913: C_NT-DMS100_SN06_DEL_CNAMD

Parameter Name	Description	Range	Default Value	Type	Class
CALLER_ID_NAME_DELIVERY_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 914: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CNAMD	A_NT-DMS100_SN06_DEL_CNAMD

C_NT-DMS100_SN06_DEL_CND

Removes this option from the assigned line. The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. Billing option enabled.

Table 915: C_NT-DMS100_SN06_DEL_CND

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 916: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CND	A_NT-DMS100_SN06_DEL_CND

C_NT-DMS100_SN06_DEL_CND-NO-BILL

Removes this option from the assigned line. The Calling Number Delivery (CND) option displays the directory number (DN) of the calling party. The CND also displays the time and date of the call. Billing option disabled.

Table 917: C_NT-DMS100_SN06_DEL_CND-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 918: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CND-NO-BILL	A_NT-DMS100_SN06_DEL_CND-NO-BILL

C_NT-DMS100_SN06_DEL_CNDB

Removes this option from the assigned line. The Calling Number Delivery Blocking (CNDB) option blocks the delivery of the calling number.

Table 919: C_NT-DMS100_SN06_DEL_CNDB

Parameter Name	Description	Range	Default Value	Type	Class
CALLING_NUMBER_DELIVERY_BLOCKING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 920: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CNDB	A_NT-DMS100_SN06_DEL_CNDB

C_NT-DMS100_SN06_DEL_CNF

The Station Controlled Conference (CNF) option allows a station to have a conference call to a maximum of 30 parties.

Table 921: C_NT-DMS100_SN06_DEL_CNF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_CONTROLLED_CONFERENCE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 922: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CNF	A_NT-DMS100_SN06_DEL_CNF

C_NT-DMS100_SN06_DEL_COD

Removes this option from the assigned line. The Cutoff on Disconnect (COD) option applies an open battery signal to the line.

Table 923: C_NT-DMS100_SN06_DEL_COD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 924: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_COD	A_NT-DMS100_SN06_DEL_COD

C_NT-DMS100_SN06_DEL_COT

Removes this option from the assigned line. The COT option allows the recipient of a harassing call to request an automatic trace of the call. Billing option enabled.

Table 925: C_NT-DMS100_SN06_DEL_COT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACER_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 926: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_COT	A_NT-DMS100_SN06_DEL_COT

C_NT-DMS100_SN06_DEL_COT-NO-BILL

Removes this option from the assigned line. The COT option allows the recipient of a harassing call to request an automatic trace of the call. Billing option disabled.

Table 927: C_NT-DMS100_SN06_DEL_COT-NO-BILL

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRACER_NO_BILL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 928: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_COT-NO-BILL	A_NT-DMS100_SN06_DEL_COT-NO-BILL

C_NT-DMS100_SN06_DEL_CPU

The Call Pickup (CPU) option allows a station to answer incoming calls to another station in the same pickup group.

Table 929: C_NT-DMS100_SN06_DEL_CPU

Parameter Name	Description	Range	Default Value	Type	Class
CALL_PICKUP_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 930: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CPU	A_NT-DMS100_SN06_DEL_CPU

C_NT-DMS100_SN06_DEL_CSMI

Removes this option from the assigned line. The CSMI feature allows end users of Network Based Answering Services (NBAS) to monitor and intercept calls that the NBAS handles.

Table 931: C_NT-DMS100_SN06_DEL_CSMI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_SCREENING_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 932: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CSMI	A_NT-DMS100_SN06_DEL_CSMI

C_NT-DMS100_SN06_DEL_CUSD

Removes this option from the assigned line. The Call Forwarding Usage Sensitive Denial (CUSD) option prevents the use of the POTS Call Forwarding Usage Sensitive Pricing (CFUSP) option.

Table 933: C_NT-DMS100_SN06_DEL_CUSD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 934: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CUSD	A_NT-DMS100_SN06_DEL_CUSD

C_NT-DMS100_SN06_DEL_CWD

The Dial CallWaiting (CWD) option allows a business set user to impose call waiting on a busy station. The busy station can be a 500/2500 set or a business set with a call waiting (CWT) feature key.

Table 935: C_NT-DMS100_SN06_DEL_CWD

Parameter Name	Description	Range	Default Value	Type	Class
DIAL_CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 936: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CWD	A_NT-DMS100_SN06_DEL_CWD

C_NT-DMS100_SN06_DEL_CWI

The Call Waiting Intragroup (CWI) option allows a subscriber to apply the CWT option to intragroup calls, in addition to those allowed with CWT.

Table 937: C_NT-DMS100_SN06_DEL_CWI

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_INTRAGROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 938: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CWI	A_NT-DMS100_SN06_DEL_CWI

C_NT-DMS100_SN06_DEL_CWO

The Call Waiting Originating (CWO) option allows an originating line to impose a call waiting tone automatically on a busy called line.

Table 939: C_NT-DMS100_SN06_DEL_CWO

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_ORIGINATING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 940: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CWO	A_NT-DMS100_SN06_DEL_CWO

C_NT-DMS100_SN06_DEL_CWT

Removes this option from the assigned line. The CallWaiting (CWT) option allows the system to alert a busy station when an incoming call attempts to reach the directory number (DN).

Table 941: C_NT-DMS100_SN06_DEL_CWT

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 942: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CWT	A_NT-DMS100_SN06_DEL_CWT

C_NT-DMS100_SN06_DEL_CWX

The Call Waiting Exempt (CWX) option does not allow Dial Call Waiting (CWD) and Call Waiting Originating (CWO) to interrupt a business set user.

Table 943: C_NT-DMS100_SN06_DEL_CWX

Parameter Name	Description	Range	Default Value	Type	Class
CALL_WAITING_EXEMPT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 944: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CWX	A_NT-DMS100_SN06_DEL_CWX

C_NT-DMS100_SN06_DEL_CXR

Removes this option from the assigned line. The call transfer (CXR) option allows the assignment of a call transfer type other than the type that the customer group has.

Table 945: C_NT-DMS100_SN06_DEL_CXR

Parameter Name	Description	Range	Default Value	Type	Class
CALL_TRANSFER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 946: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_CXR	A_NT-DMS100_SN06_DEL_CXR

C_NT-DMS100_SN06_DEL_DCF

The Denied Call Forwarding (DCF) option does not allow a line to receive forwarded calls. This security option helps to protect computer ports.

Table 947: C_NT-DMS100_SN06_DEL_DCF

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_CALL_FORWARDING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 948: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DCF	A_NT-DMS100_SN06_DEL_DCF

C_NT-DMS100_SN06_DEL_DCPU

The DCPU option allows a station to answer a ringing line in the same customer group before the called party answers the ringing line.

Table 949: C_NT-DMS100_SN06_DEL_DCPU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 950: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DCPU	A_NT-DMS100_SN06_DEL_DCPU

C_NT-DMS100_SN06_DEL_DDN

Removes this option from the assigned line. The Dialable Directory Number (DDN) option allows the customer premises equipment (CPE) to display incoming calling name, number, and the time and date of the call.

Table 951: C_NT-DMS100_SN06_DEL_DDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 951: C_NT-DMS100_SN06_DEL_DDN

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 952: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DDN	A_NT-DMS100_SN06_DEL_DDN

C_NT-DMS100_SN06_DEL_DENY

Removes this option from the assigned line. The DENY option prevents individual lines from gaining access to particular Custom Local Area Signaling Services (CLASS) features that are available using Universal Access (UA).

Table 953: C_NT-DMS100_SN06_DEL_DENY

Parameter Name	Description	Range	Default Value	Type	Class
DENY_ACCESS_CLASS_FEATURES_DENYOPT	Specifies the CLASS option to deny on switches.			C	R
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 953: C_NT-DMS100_SN06_DEL_DENY

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 954: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENY	A_NT-DMS100_SN06_DEL_DENY

C_NT-DMS100_SN06_DEL_DENYACB

Removes this option from the assigned line. The DENYACB option prevents the use of the automatic call return feature.

Table 955: C_NT-DMS100_SN06_DEL_DENYACB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 955: C_NT-DMS100_SN06_DEL_DENYACB

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 956: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENYACB	A_NT-DMS100_SN06_DEL_DENYACB

C_NT-DMS100_SN06_DEL_DENYAR

Removes this option from the assigned line. The DENYAR option prevents individual lines from gaining access to automatic recall feature that are available using Universal Access (UA).

Table 957: C_NT-DMS100_SN06_DEL_DENYAR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 958: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENYAR	A_NT-DMS100_SN06_DEL_DENYAR

C_NT-DMS100_SN06_DEL_DENYCOT

Removes this option from the assigned line. The DENYCOT option prevents the use of the incoming call tracing feature.

Table 959: C_NT-DMS100_SN06_DEL_DENYCOT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 960: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENYCOT	A_NT-DMS100_SN06_DEL_DENYCOT

C_NT-DMS100_SN06_DEL_DENYCSMI

Removes this option from the assigned line. The DENYCSMI option prevents the user from activating the CSMI option on certain types of Call Forwarding.

Table 961: C_NT-DMS100_SN06_DEL_DENYCSMI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 962: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENYCSMI	A_NT-DMS100_SN06_DEL_DENYCSMI

C_NT-DMS100_SN06_DEL_DENYISA

Removes this option from the assigned line. The DENYISA option allows ISA end users to deactivate ISA for each call. Users dial the Cancel ISA (CISA) access code to deactivate ISA.

Table 963: C_NT-DMS100_SN06_DEL_DENYISA

Parameter Name	Description	Range	Default Value	Type	Class
DENY_IN_SESSION_ACTIVATION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 964: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENYISA	A_NT-DMS100_SN06_DEL_DENYISA

C_NT-DMS100_SN06_DEL_DENYU3WC

Removes this option from the assigned line. The DENYU3WC option prevents the use of the U3WC feature when U3WC is applied to a RES line or POTS line.

Table 965: C_NT-DMS100_SN06_DEL_DENYU3WC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 966: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DENYU3WC	A_NT-DMS100_SN06_DEL_DENYU3WC

C_NT-DMS100_SN06_DEL_DGT

Removes this option from the assigned line. The DGT option allows a telephone set to generate an address in the form of dual-tone multi-frequency signals.

Table 967: C_NT-DMS100_SN06_DEL_DGT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 967: C_NT-DMS100_SN06_DEL_DGT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 968: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DGT	A_NT-DMS100_SN06_DEL_DGT

C_NT-DMS100_SN06_DEL_DIN

Removes this option from the assigned line. The DIN option prevents selected lines from receiving incoming calls that originate outside the customer group.

Table 969: C_NT-DMS100_SN06_DEL_DIN

Parameter Name	Description	Range	Default Value	Type	Class
DENIED_INCOMING_CALL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O

Table 969: C_NT-DMS100_SN06_DEL_DIN

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 970: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DIN	A_NT-DMS100_SN06_DEL_DIN

C_NT-DMS100_SN06_DEL_DISP

The Display (DISP) option indicates that a business set on a PSET line is a display business set.

Table 971: C_NT-DMS100_SN06_DEL_DISP

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 971: C_NT-DMS100_SN06_DEL_DISP

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 972: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DISP	A_NT-DMS100_SN06_DEL_DISP

C_NT-DMS100_SN06_DEL_DNH

Removes this option from the assigned line. The Directory Number Hunt (DNH) option allows directory number hunting. Each line in the Hunt group has a directory number (DN).

Table 973: C_NT-DMS100_SN06_DEL_DNH

Parameter Name	Description	Range	Default Value	Type	Class
DIRECTORY_NUMBER_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 973: C_NT-DMS100_SN06_DEL_DNH

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 974: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DNH	A_NT-DMS100_SN06_DEL_DNH

C_NT-DMS100_SN06_DEL_DOR

Removes this option from the assigned line. The Denied Origination (DOR) option does not allow a line to originate calls. If the user attempts to originate a call from that line, the call receives originating suspended service (ORSS) treatment.

Table 975: C_NT-DMS100_SN06_DEL_DOR

Parameter Name	Description	Range	Default Value	Type	Class
DENY_ORIGINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 975: C_NT-DMS100_SN06_DEL_DOR

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 976: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DOR	A_NT-DMS100_SN06_DEL_DOR

C_NT-DMS100_SN06_DEL_DQS

The Display Queue Status (DQS) option allows an ACD supervisor to display the load status information for an ACD group.

Table 977: C_NT-DMS100_SN06_DEL_DQS

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_STATUS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 978: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DQS	A_NT-DMS100_SN06_DEL_DQS

C_NT-DMS100_SN06_DEL_DQT

The Display Queue Threshold (DQT) option allows the system to display the status of the incoming call queue. The status of the queue appears when the ACD agent or supervisor presses the associated key of the set.

Table 979: C_NT-DMS100_SN06_DEL_DQT

Parameter Name	Description	Range	Default Value	Type	Class
DISPLAY_QUEUE_THRESHOLD_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 980: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DQT	A_NT-DMS100_SN06_DEL_DQT

C_NT-DMS100_SN06_DEL_DRCW

Removes this option from the assigned line. The Distinctive Ringing/Call Waiting (DRCW) option allows the system to identify terminating calls with a distinct alert pattern.

Table 981: C_NT-DMS100_SN06_DEL_DRCW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 982: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DRCW	A_NT-DMS100_SN06_DEL_DRCW

C_NT-DMS100_SN06_DEL_DRING

The Distinctive Ringing (DRING) option assigns a cadence of rings to a business set for each line. The DRING can add different ring patterns for different call types.

Table 983: C_NT-DMS100_SN06_DEL_DRING

Parameter Name	Description	Range	Default Value	Type	Class
DISTINCTIVE_RING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 984: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DRING	A_NT-DMS100_SN06_DEL_DRING

C_NT-DMS100_SN06_DEL_DSCWID

Removes this option from the assigned line. Deluxe Spontaneous Call Waiting Identification (DSCWID) allows the subscriber to receive calling-party information during call waiting.

Table 985: C_NT-DMS100_SN06_DEL_DSCWID

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 986: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DSCWID	A_NT-DMS100_SN06_DEL_DSCWID

C_NT-DMS100_SN06_DEL_DTM

Removes this option from the assigned line. The DTM option prevents a line from receiving calls. Calls that attempt to terminate to a line with the DTM option, receive denied terminating (DNTR) treatment.

Table 987: C_NT-DMS100_SN06_DEL_DTM

Parameter Name	Description	Range	Default Value	Type	Class
DENY_TERMINATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 988: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_DTM	A_NT-DMS100_SN06_DEL_DTM

C_NT-DMS100_SN06_DEL_ELN

Removes this option from the assigned line. The essential line (ELN) option designates a line as essential.

Table 989: C_NT-DMS100_SN06_DEL_ELN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
ESSENTIAL_LINE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 990: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ELN	A_NT-DMS100_SN06_DEL_ELN

C_NT-DMS100_SN06_DEL_EMW

The Executive MessageWaiting (EMW) option introduces a message waiting class of service (MCOS) to enhance the message waiting option. A user can only access the MCOS to which the user subscribes.

Table 991: C_NT-DMS100_SN06_DEL_EMW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
EXECUTIVE_MESSAGE_WAIT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 992: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_EMW	A_NT-DMS100_SN06_DEL_EMW

C_NT-DMS100_SN06_DEL_ESL

The Emergency Service Line (ESL) allows a line for emergency service to be designated.

Table 993: C_NT-DMS100_SN06_DEL_ESL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 994: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ESL	A_NT-DMS100_SN06_DEL_ESL

C_NT-DMS100_SN06_DEL_FAA

The Forced Agent Availability (FAA) option allows an ACD (Automatic Call Distribution) supervisor to force an ACD agent from the Not Ready to the Ready state.

Table 995: C_NT-DMS100_SN06_DEL_FAA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 995: C_NT-DMS100_SN06_DEL_FAA

Parameter Name	Description	Range	Default Value	Type	Class
FORCED_AGENT_AVAILABILITY_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 996: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_FAA	A_NT-DMS100_SN06_DEL_FAA

C_NT-DMS100_SN06_DEL_FANI

Removes this option from the assigned line. The Flexible Automatic Number ID (FANI) option allows an operating company to assign special-purpose Automatic Number Identification (ANI) information digits to a line.

Table 997: C_NT-DMS100_SN06_DEL_FANI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 997: C_NT-DMS100_SN06_DEL_FANI

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 998: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_FANI	A_NT-DMS100_SN06_DEL_FANI

C_NT-DMS100_SN06_DEL_FEATURES

Deletes options from assigned single-line and multiline telephone sets, to Hunt group lines, and to proprietary business sets.

Table 999: C_NT-DMS100_SN06_DEL_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	Directory number.			S	O
IS_OPTIMIZED	A flag to indicate MML optimization of the command. The values are true or false.		true	S	O

Table 999: C_NT-DMS100_SN06_DEL_FEATURES

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OPT	Options associated with a service your are establishing, modifying, or deleting. You can specify a maximum of 20 options in any single command. You can specify a maximum of 128 options in any deo command.			C	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1000: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_FEATURES	A_NT-DMS100_SN06_DEL_FEATURES

C_NT-DMS100_SN06_DEL_FTRGRP

Removes this option from the assigned line. The FTRGRP option allows the operating company to define a number of features as a feature group. The feature group can be assigned to customer lines.

Table 1001: C_NT-DMS100_SN06_DEL_FTRGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
FEATURE_GROUP_ OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1002: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_FTRGRP	A_NT-DMS100_SN06_DEL_FTRGRP

C_NT-DMS100_SN06_DEL_GIC

The GIC option allows call termination on a member of a designated intercom group that uses abbreviated dialing. Use abbreviated dialing to access group members.

Table 1003: C_NT-DMS100_SN06_DEL_GIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
GROUP_INTERCOM_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1004: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_GIC	A_NT-DMS100_SN06_DEL_GIC

C_NT-DMS100_SN06_DEL_GND

Removes this option from the assigned line. The GND option assigns ground signal to the line and allow consistency to be checked on ground start lines.

Table 1005: C_NT-DMS100_SN06_DEL_GND

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1006: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_GND	A_NT-DMS100_SN06_DEL_GND

C_NT-DMS100_SN06_DEL_HOT

Removes this option from the assigned line. This feature is placed on lines in hotel or motel. It allows the hotel to bill each room for call charges.

Table 1007: C_NT-DMS100_SN06_DEL_HOT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1007: C_NT-DMS100_SN06_DEL_HOT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1008: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_HOT	A_NT-DMS100_SN06_DEL_HOT

C_NT-DMS100_SN06_DEL_ICM

The ICM option allows a business set user to directly terminate upon a predesignated business set by pressing the ICM feature key.

Table 1009: C_NT-DMS100_SN06_DEL_ICM

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTERCOM_BUSINESS_SET_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O

Table 1009: C_NT-DMS100_SN06_DEL_ICM

Parameter Name	Description	Range	Default Value	Type	Class
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1010: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ICM	A_NT-DMS100_SN06_DEL_ICM

C_NT-DMS100_SN06_DEL_INSPECT

The INSPECT option displays the information on feature/DN keys and incoming calls to a DN. This option also provides information on the Call Waiting key and Intercom key without answering the call.

Table 1011: C_NT-DMS100_SN06_DEL_INSPECT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INSPECT_KEY_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 1011: C_NT-DMS100_SN06_DEL_INSPECT

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1012: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_INSPECT	A_NT-DMS100_SN06_DEL_INSPECT

C_NT-DMS100_SN06_DEL_INT

Removes this option from the assigned line. The Intercom (INT) option allows the subscriber to dial an access code and ring all the extensions of that DN. The subscriber can speak to the persons who answer these extensions.

Table 1013: C_NT-DMS100_SN06_DEL_INT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 1013: C_NT-DMS100_SN06_DEL_INT

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1014: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_INT	A_NT-DMS100_SN06_DEL_INT

C_NT-DMS100_SN06_DEL_INTPIC

Line option INTPIC allows subscribers of Equal End Offices (EQEO) to designate a carrier for international calls. This option is valid for POTS, COIN, RES,IBN and KSET lines.

Table 1015: C_NT-DMS100_SN06_DEL_INTPIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTL_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1016: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_INTPIC	A_NT-DMS100_SN06_DEL_INTPIC

C_NT-DMS100_SN06_DEL_KSH

The Key Short Hunt (KSH) option allows incoming calls to search for an idle directory number (DN) on which to terminate. The options search for this DN occurs through a set of DN appearances on a business set.

Table 1017: C_NT-DMS100_SN06_DEL_KSH

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
KEY_SHORT_HUNT _OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1018: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_KSH	A_NT-DMS100_SN06_DEL_KSH

C_NT-DMS100_SN06_DEL_LCDR

Removes this option from the assigned line. The Local Call Detail Recording (LCDR) option allows billing for local calls to correspond to conversation time.

Table 1019: C_NT-DMS100_SN06_DEL_LCDR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LOCAL_CALL_DETAILED_REPORTING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1020: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LCDR	A_NT-DMS100_SN06_DEL_LCDR

C_NT-DMS100_SN06_DEL_LDSA

Removes this option from the assigned line. The long distance signal activate (LDSA) line option allows the end user to activate or deactivate Long Distance Alerting (LDA) on a line.

Table 1021: C_NT-DMS100_SN06_DEL_LDSA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1022: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LDSA	A_NT-DMS100_SN06_DEL_LDSA

C_NT-DMS100_SN06_DEL_LDSO

Removes this option from the assigned line. The Long Distance Signal Option (LDSO) option provides Long Distance Alerting (LDA) subscribers with a different ring and a different tone.

Table 1023: C_NT-DMS100_SN06_DEL_LDSO

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1024: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LDSO	A_NT-DMS100_SN06_DEL_LDSO

C_NT-DMS100_SN06_DEL_LNR

Removes this option from the assigned line. The LNR option allows a subscriber to redial the last number dialed. The subscriber uses a single key instead of the full number to redial the last number dialed.

Table 1025: C_NT-DMS100_SN06_DEL_LNR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1025: C_NT-DMS100_SN06_DEL_LNR

Parameter Name	Description	Range	Default Value	Type	Class
LAST_NUMBER_REDIAL_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1026: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LNR	A_NT-DMS100_SN06_DEL_LNR

C_NT-DMS100_SN06_DEL_LNRA

The Last Number Redial Associated with Set (LNRA) option allows a set to access any free Directory Number (DN) on the set. When the user activates the option, the last number the user dialed from the set dials again.

Table 1027: C_NT-DMS100_SN06_DEL_LNRA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1027: C_NT-DMS100_SN06_DEL_LNRA

Parameter Name	Description	Range	Default Value	Type	Class
LAST_NUMBER_REDIAL_ASSOCIATED_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1028: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LNRA	A_NT-DMS100_SN06_DEL_LNRA

C_NT-DMS100_SN06_DEL_LOB

The Line of Business (LOB) option allows an Automatic Call Distribution (ACD) agent to enter a three-digit code for each call. Entering the code pegs a register for that LOB or type of call.

Table 1029: C_NT-DMS100_SN06_DEL_LOB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1029: C_NT-DMS100_SN06_DEL_LOB

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LINE_OF_BUSINESS_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1030: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LOB	A_NT-DMS100_SN06_DEL_LOB

C_NT-DMS100_SN06_DEL_LOD

Removes this option from the assigned line. The Line Overflow to Directory Number (LOD) option enables a call to be routed to a specified DN. This action occurs when all lines in a Hunt group are busy.

Table 1031: C_NT-DMS100_SN06_DEL_LOD

Parameter Name	Description	Range	Default Value	Type	Class
CALL_FORWARD_BUSY_OVERFLOW_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1032: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LOD	A_NT-DMS100_SN06_DEL_LOD

C_NT-DMS100_SN06_DEL_LPIC

Removes this option from the assigned line. The Intra-LATA PIC (LPIC) option allows the user to choose a primary carrier for the Intra-LATA service. The LCHOICE field allows subscribers to dial Intra-LATA calls on a casual basis.

Table 1033: C_NT-DMS100_SN06_DEL_LPIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTRA_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1034: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LPIC	A_NT-DMS100_SN06_DEL_LPIC

C_NT-DMS100_SN06_DEL_LVM

The Leave Message (LVM) option provides key access to message waiting (MWT), call request (CAR), and executive message waiting (EMW).

Table 1035: C_NT-DMS100_SN06_DEL_LVM

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEAVE_MESSAGE_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1036: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LVM	A_NT-DMS100_SN06_DEL_LVM

C_NT-DMS100_SN06_DEL_M518

The 18-Button Add-On for Meridian M5000 Series (M518) option allows the addition of an 18-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set.

Table 1037: C_NT-DMS100_SN06_DEL_M518

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
M518_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1038: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_M518	A_NT-DMS100_SN06_DEL_M518

C_NT-DMS100_SN06_DEL_M536

The 36-Button Add-On for Meridian M5000 Series (M536) option allows the addition of a 36-button add-on unit to a Meridian M5000 series (M5009, M5112, M5209, or M5312) business set.

Table 1039: C_NT-DMS100_SN06_DEL_M536

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
M536_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1040: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_M536	A_NT-DMS100_SN06_DEL_M536

C_NT-DMS100_SN06_DEL_MDN

The MDN option assigns a DN to more than one set. A multiple appearance directory number (MADN) is a directory number (DN) hat appears on more than one Meridian business set (MBS).

Table 1041: C_NT-DMS100_SN06_DEL_MDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MULTIPLE_APPEARANCE_DN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1042: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_MDN	A_NT-DMS100_SN06_DEL_MDN

C_NT-DMS100_SN06_DEL_MSB

Removes this option from the assigned line. The MSB option allows each IBN station to appear busy to incoming calls.

Table 1043: C_NT-DMS100_SN06_DEL_MSB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MAKE_SET_BUSY_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1044: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_MSB	A_NT-DMS100_SN06_DEL_MSB

C_NT-DMS100_SN06_DEL_MSBI

The Make Set Busy Intragroup (MSBI) option allows each IBN station to appear busy to incoming calls. The system applies a temporary splash of ringing (500 ms) to the line to inform the station user of a diverted incoming call.

Table 1045: C_NT-DMS100_SN06_DEL_MSBI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MAKE_SET_BUSY_INTRAGROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1046: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_MSBI	A_NT-DMS100_SN06_DEL_MSBI

C_NT-DMS100_SN06_DEL_MWT

Removes this option from the assigned line. The MWT option allows a message center to inform a user that there is a message.

Table 1047: C_NT-DMS100_SN06_DEL_MWT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MESSAGE_WAITING_INDICATOR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1048: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_MWT	A_NT-DMS100_SN06_DEL_MWT

C_NT-DMS100_SN06_DEL_NAME

Removes this option from the assigned line. The system uses NAME feature to assign a name to DN.

Table 1049: C_NT-DMS100_SN06_DEL_NAME

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NAME_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1050: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_NAME	A_NT-DMS100_SN06_DEL_NAME

C_NT-DMS100_SN06_DEL_NDC

The No Double Connect (NDC) option prevents a line from being connected to a verification or test circuit when the line is off-hook.

Table 1051: C_NT-DMS100_SN06_DEL_NDC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NO_DOUBLE_CONNECT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1052: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_NDC	A_NT-DMS100_SN06_DEL_NDC

C_NT-DMS100_SN06_DEL_NFA

Removes this option from the assigned line. The Network Facility Access (NFA) provides a direct connection through the DMS-100 switch.

Table 1053: C_NT-DMS100_SN06_DEL_NFA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NETWORK_FACILITY_ACCESS_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1054: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_NFA	A_NT-DMS100_SN06_DEL_NFA

C_NT-DMS100_SN06_DEL_NGTSRVCE

The Night Service (NGTSRVCE) option allows the ACD supervisor to place all ACD agent sets in an ACD group in night service mode. The ACD supervisor presses the Night Service key on the supervisor set to place the ACD agent sets in night service modes.

Table 1055: C_NT-DMS100_SN06_DEL_NGTSRVCE

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NIGHT_SERVICE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1056: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_NGTSRVCE	A_NT-DMS100_SN06_DEL_NGTSRVCE

C_NT-DMS100_SN06_DEL_NLT

The No Line Insulation Test (NLT) option allows the automatic line insulation test to skip a line.

Table 1057: C_NT-DMS100_SN06_DEL_NLT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NO_LINE_INSULATION_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1058: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_NLT	A_NT-DMS100_SN06_DEL_NLT

C_NT-DMS100_SN06_DEL_OBS

The Observe Agent (OBS) option allows a supervisor to observe conversations between an agent and a caller. This user presses the OBS key to observe conversations between an agent and a caller.

Table 1059: C_NT-DMS100_SN06_DEL_OBS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OBSERVE_AGENT_ OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1060: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_OBS	A_NT-DMS100_SN06_DEL_OBS

C_NT-DMS100_SN06_DEL_ONI

Removes this option from the assigned line. The Operator Number Identification (ONI) option directs calls to an operator to identify the calling number when the switch cannot provide this information.

Table 1061: C_NT-DMS100_SN06_DEL_ONI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OPERATOR_NUMBER_IDENTIFICATION_OPTKEY	A key on a business set or data unit to which the feature is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1062: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_ONI	A_NT-DMS100_SN06_DEL_ONI

C_NT-DMS100_SN06_DEL_PIC

Removes this option from the assigned line. The Primary Inter-LATA Carrier (PIC) option assigns a PIC to an MDC line.

Table 1063: C_NT-DMS100_SN06_DEL_PIC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
INTER_PIC_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1064: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_PIC	A_NT-DMS100_SN06_DEL_PIC

C_NT-DMS100_SN06_DEL_PORT

Removes this option from the assigned line. The PORT option allows ten-digit complete LNP triggering for a directory number (DN).

Table 1065: C_NT-DMS100_SN06_DEL_PORT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LOCAL_NUMBER_PORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1066: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_PORT	A_NT-DMS100_SN06_DEL_PORT

C_NT-DMS100_SN06_DEL_PRK

The PRK option allows a business set user to park a call against the directory number (DN) of the user. Retrieval of the parked call can occur from any station. When the call is parked, the user can originate and receive calls on that DN.

Table 1067: C_NT-DMS100_SN06_DEL_PRK

Parameter Name	Description	Range	Default Value	Type	Class
CALL_PARK_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1068: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_PRK	A_NT-DMS100_SN06_DEL_PRK

C_NT-DMS100_SN06_DEL_PRL

The PRL option is available to single call announcement (SCA) multiple appearance directory number (MADN) users. The PRL option allows users to establish a conference call between an outside number and a maximum of 30 MADN lines.

Table 1069: C_NT-DMS100_SN06_DEL_PRL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
PRIVACY_RELEASE_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1070: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_PRL	A_NT-DMS100_SN06_DEL_PRL

C_NT-DMS100_SN06_DEL_QTD

The QTD option allows a display business set to display the current time and date. The user presses the QTD key and the current time and date display for 15 seconds. When another action that uses the display is activated, the time and date display stops.

Table 1071: C_NT-DMS100_SN06_DEL_QTD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
QUERY_TIME_DATE _OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1072: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_QTD	A_NT-DMS100_SN06_DEL_QTD

C_NT-DMS100_SN06_DEL_RAG

The QTD option allows a display business set to display the current time and date. The user presses the QTD key and the current time and date display for 15 seconds. When another action that uses the display is activated, the time and date display stops.

Table 1073: C_NT-DMS100_SN06_DEL_RAG

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
RING_AGAIN_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1074: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RAG	A_NT-DMS100_SN06_DEL_RAG

C_NT-DMS100_SN06_DEL_RCHD

Removes this option from the assigned line. The RCHD option allows a subscriber to place a call on hold for up to three minutes. The call can be one that the subscriber originated or one that the subscriber received.

Table 1075: C_NT-DMS100_SN06_DEL_RCHD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1076: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RCHD	A_NT-DMS100_SN06_DEL_RCHD

C_NT-DMS100_SN06_DEL_RMI

Removes this option from the assigned line. The RMI Option allows the subscribers of the message waiting indicator feature to check for the existence of messages in their voice mail box from a remote location.

Table 1077: C_NT-DMS100_SN06_DEL_RMI

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
REMOTE_MESSAGE_INDICATOR_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1078: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RMI	A_NT-DMS100_SN06_DEL_RMI

C_NT-DMS100_SN06_DEL_RMR

Removes this option from the assigned line. The RMR option is assigned to lines that are equipped with a remote hardware message register activated by reverse battery.

Table 1079: C_NT-DMS100_SN06_DEL_RMR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1080: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RMR	A_NT-DMS100_SN06_DEL_RMR

C_NT-DMS100_SN06_DEL_RMT

Removes this option from the assigned line. The RMT option is assigned to lines that are equipped with a remote hardware message register activated by reverse battery.

Table 1081: C_NT-DMS100_SN06_DEL_RMT

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1081: C_NT-DMS100_SN06_DEL_RMT

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1082: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RMT	A_NT-DMS100_SN06_DEL_RMT

C_NT-DMS100_SN06_DEL_RPA

The RPA option allows up to seven additional alert tones to a business set when a call terminates on a DN, MADN, GIC, or ACD key and the set is already active on another key.

Table 1083: C_NT-DMS100_SN06_DEL_RPA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 1083: C_NT-DMS100_SN06_DEL_RPA

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
REPEATED_ALERT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1084: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RPA	A_NT-DMS100_SN06_DEL_RPA

C_NT-DMS100_SN06_DEL_RSP

Removes this option from the assigned line. The RSP option is assigned to lines that have LCCs of ZMD or ZMZPA.

Table 1085: C_NT-DMS100_SN06_DEL_RSP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 1085: C_NT-DMS100_SN06_DEL_RSP

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
RESTRICTED_SENT_PAID_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1086: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RSP	A_NT-DMS100_SN06_DEL_RSP

C_NT-DMS100_SN06_DEL_RSUS

Removes this option from the assigned line. The RSUS option is assigned when the subscriber requests suspension of service.

Table 1087: C_NT-DMS100_SN06_DEL_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 1087: C_NT-DMS100_SN06_DEL_RSUS

Parameter Name	Description	Range	Default Value	Type	Class
REQUESTED_SUSPENSION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1088: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_RSUS	A_NT-DMS100_SN06_DEL_RSUS

C_NT-DMS100_SN06_DEL_SACB

Remove this option from the assigned line. The SACB option allows a subscriber to control originations from the line by identifying call classes that restrict completion to certain dialed numbers without a personal identification number (PIN).

Table 1089: C_NT-DMS100_SN06_DEL_SACB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 1089: C_NT-DMS100_SN06_DEL_SACB

Parameter Name	Description	Range	Default Value	Type	Class
SUB_ACT_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1090: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SACB	A_NT-DMS100_SN06_DEL_SACB

C_NT-DMS100_SN06_DEL_SC1

Removes this option from the assigned line. The SC1 option allows a customer to specify a list of up to eight frequently called numbers. These numbers can be called by dialing the digits 2-9.

Table 1091: C_NT-DMS100_SN06_DEL_SC1

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1092: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SC1	A_NT-DMS100_SN06_DEL_SC1

C_NT-DMS100_SN06_DEL_SC2

Removes this option from the assigned line. The SC2 option allows a customer to specify a list of up to 30 frequently called numbers. These numbers can be called by dialing 20-49.

Table 1093: C_NT-DMS100_SN06_DEL_SC2

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1094: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SC2	A_NT-DMS100_SN06_DEL_SC2

C_NT-DMS100_SN06_DEL_SCA

Removes this option from the assigned line. The SCA option allows a subscriber to selectively accept calls arriving from a limited set of previously identified directory numbers (DN).

Table 1095: C_NT-DMS100_SN06_DEL_SCA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_ ACCEPTANCE_OPT KEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1096: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCA	A_NT-DMS100_SN06_DEL_SCA

C_NT-DMS100_SN06_DEL_SCF

Removes this option from the assigned line. The SCF option allows calls that terminate on the line to be forwarded to a remote destination if the number of the originating station matches one of the numbers in the SCF list.

Table 1097: C_NT-DMS100_SN06_DEL_SCF

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_FORWARDING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1098: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCF	A_NT-DMS100_SN06_DEL_SCF

C_NT-DMS100_SN06_DEL_SCL

Removes this option from the assigned line. The SCL option allows a customer to specify a list of frequently called numbers that can be called by dialing a two-digit speed calling code instead of the complete number.

Table 1099: C_NT-DMS100_SN06_DEL_SCL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_LONG_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1100: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCL	A_NT-DMS100_SN06_DEL_SCL

C_NT-DMS100_SN06_DEL_SCRJ

Removes this option from the assigned line. The SCRJ option allows a subscriber to selectively reject calls arriving from a limited set of previously identified DNs.

Table 1101: C_NT-DMS100_SN06_DEL_SCRJ

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SELECTIVE_CALL_BLOCKING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1102: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCRJ	A_NT-DMS100_SN06_DEL_SCRJ

C_NT-DMS100_SN06_DEL_SCS

Removes this option from the assigned line. The SCS option allows a customer to specify a list of frequently called numbers that the customer can call by dialing a one-digit speed calling code instead of the complete number.

Table 1103: C_NT-DMS100_SN06_DEL_SCS

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_SHORT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1104: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCS	A_NT-DMS100_SN06_DEL_SCS

C_NT-DMS100_SN06_DEL_SCU

The SCU option allows a line to be designated as a speed calling user in a speed calling group. A speed calling user can only originate calls with speed calling and cannot affect the contents of the speed calling list.

Table 1105: C_NT-DMS100_SN06_DEL_SCU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPEED_CALLING_USER_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1106: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCU	A_NT-DMS100_SN06_DEL_SCU

C_NT-DMS100_SN06_DEL_SCWID

Removes this option from the assigned line. The SCWID option allows subscribers to receive calling party information in conjunction with a call waiting tone.

Table 1107: C_NT-DMS100_SN06_DEL_SCWID

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1108: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SCWID	A_NT-DMS100_SN06_DEL_SCWID

C_NT-DMS100_SN06_DEL_SDN

Removes this option from the assigned line. To add a secondary DN to a Teen Service line, the SDN option can be assigned to POTS, RES, or IBN agents. When no SDNs are assigned to the line, adding the SDN option establishes Teen Service.

Table 1109: C_NT-DMS100_SN06_DEL_SDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1109: C_NT-DMS100_SN06_DEL_SDN

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SECONDARY_DN_DN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows that the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows that the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.			S	O
SECONDARY_DN_LINE	Secondary LINE.			S	O
SECONDARY_DN_NPA	Secondary NPA.			S	O
SECONDARY_DN_NXX	Secondary NXX.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1110: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SDN	A_NT-DMS100_SN06_DEL_SDN

C_NT-DMS100_SN06_DEL_SDSDENY

Removes this option from the assigned line. The SDSDENY option prevents the offer of Enhanced Busy Call Return (EBCR) service to a line.

Table 1111: C_NT-DMS100_SN06_DEL_SDSDENY

Parameter Name	Description	Range	Default Value	Type	Class
DENY_BUSY_REPEAT_DIAL_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1112: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SDSDENY	A_NT-DMS100_SN06_DEL_SDSDENY

C_NT-DMS100_SN06_DEL_SHU

The SHU option allows hunting at a line to be canceled when activated. SHU can be assigned to one, several, or all lines in a Hunt group.

Table 1113: C_NT-DMS100_SN06_DEL_SHU

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STOP_HUNT_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1114: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SHU	A_NT-DMS100_SN06_DEL_SHU

C_NT-DMS100_SN06_DEL_SL

Removes this option from the assigned line. The SL option allows a line to receive announcements in a secondary language (a language other than the assigned primary language).

Table 1115: C_NT-DMS100_SN06_DEL_SL

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SECONDARY_LANGUAGE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1116: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SL	A_NT-DMS100_SN06_DEL_SL

C_NT-DMS100_SN06_DEL_SMDR

The SMDR option allows the recording of both billable and nonbillable calls on a per leg call basis. The SMDR system uses the automatic message accounting (AMA) subsystem to collect the call data and automatically record it on a data storage device.

Table 1117: C_NT-DMS100_SN06_DEL_SMDR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_MESSAGE_RECORDING_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1118: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SMDR	A_NT-DMS100_SN06_DEL_SMDR

C_NT-DMS100_SN06_DEL_SPB

Removes this option from the assigned line. The SPB option allow a line number other than the subscriber's line to be used for billing.

Table 1119: C_NT-DMS100_SN06_DEL_SPB

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SPECIAL_BILLING_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1120: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SPB	A_NT-DMS100_SN06_DEL_SPB

C_NT-DMS100_SN06_DEL_SRA

The Suppressed Ringing Access (SRA) allows any authorized server to establish a connection to customer's line without applying audible ringing.

Table 1121: C_NT-DMS100_SN06_DEL_SRA

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1122: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SRA	A_NT-DMS100_SN06_DEL_SRA

C_NT-DMS100_SN06_DEL_SSAC

The SSAC option allows a set of numbers, from 2-10 digits, to be dialed from a specific station for purposes of recording billing information and overriding station network class of service (NCOS) restrictions.

Table 1123: C_NT-DMS100_SN06_DEL_SSAC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
STATION_SPECIFIC_AUTH_CODES_OPT KEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1124: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SSAC	A_NT-DMS100_SN06_DEL_SSAC

C_NT-DMS100_SN06_DEL_SUPPRESS

Removes this option from the assigned line. The SUPPRESS option allows a party to prevent the directory number (DN) or name from being displayed at the call destination.

Table 1125: C_NT-DMS100_SN06_DEL_SUPPRESS

Parameter Name	Description	Range	Default Value	Type	Class
ANONYMOUS_CALLER_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1126: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SUPPRESS	A_NT-DMS100_SN06_DEL_SUPPRESS

C_NT-DMS100_SN06_DEL_SUPR

The SUPR option establishes an automatic call distribution (ACD) supervisor set when assigned to key 1. This option must be assigned before ACD supervisor options can be assigned to the set.

Table 1127: C_NT-DMS100_SN06_DEL_SUPR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SUPERVISOR_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1128: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SUPR	A_NT-DMS100_SN06_DEL_SUPR

C_NT-DMS100_SN06_DEL_SVCGRP

The SVCGRP option allows options CLID (Calling Line Identification Display), NAME (Name Display) and REASDSP (Reason Display), packaged in a service group, to be assigned to a selected line in a customer group or multiple customer groups.

Table 1129: C_NT-DMS100_SN06_DEL_SVCGRP

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
SERVICE_GROUP_OPTKEY	A key on a business set (for M series LCC type) to which an option is assigned.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1130: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_SVCGRP	A_NT-DMS100_SN06_DEL_SVCGRP

C_NT-DMS100_SN06_DEL_TCW

Removes the TCW (talking call waiting) option from the assigned line.

Table 1131: C_NT-DMS100_SN06_DEL_TCW

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1132: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_TCW	A_NT-DMS100_SN06_DEL_TCW

C_NT-DMS100_SN06_DEL_TDN

Removes this option from the assigned line. The TDN option prevents a line from originating toll calls.

Table 1133: C_NT-DMS100_SN06_DEL_TDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O

Table 1133: C_NT-DMS100_SN06_DEL_TDN

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1134: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_TDN	A_NT-DMS100_SN06_DEL_TDN

C_NT-DMS100_SN06_DEL_TFO

Removes this option from the assigned line. The TFO option allows an incoming call to attempt to terminate to the first member of the hunt group which appears idle.

Table 1135: C_NT-DMS100_SN06_DEL_TFO

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Table 1135: C_NT-DMS100_SN06_DEL_TFO

Parameter Name	Description	Range	Default Value	Type	Class
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
TERMINATION_FAULT_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1136: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_TFO	A_NT-DMS100_SN06_DEL_TFO

C_NT-DMS100_SN06_DEL_UCD

The UCD option permits calls to be distributed evenly among a number of predetermined sets. Removes this option from the assigned line.

Table 1137: C_NT-DMS100_SN06_DEL_UCD

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 1137: C_NT-DMS100_SN06_DEL_UCD

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O
UNIFORM_CALL_DISTRIBUTION_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1138: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_UCD	A_NT-DMS100_SN06_DEL_UCD

C_NT-DMS100_SN06_DEL_VMEADENY

Removes this option from the assigned line. The VMEADENY option Prevent subscriber's line to have access to voice messaging system VMS using access code *98.

Table 1139: C_NT-DMS100_SN06_DEL_VMEADENY

Parameter Name	Description	Range	Default Value	Type	Class
DENY_VOICE_MAIL_EASY_ACCESS_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 1139: C_NT-DMS100_SN06_DEL_VMEADENY

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1140: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_VMEADENY	A_NT-DMS100_SN06_DEL_VMEADENY

C_NT-DMS100_SN06_DEL_VMEADN

Removes this option from the assigned line. The Voice Mail East Access DN (VMEADN) option allows subscriber's line to access a voice messaging system (VMS) using access code *98.

Table 1141: C_NT-DMS100_SN06_DEL_VMEADN

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
VOICE_MAIL_EASY_ACCESS_DN_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1142: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_VMEADN	A_NT-DMS100_SN06_DEL_VMEADN

C_NT-DMS100_SN06_DEL_WML

Removes this option from the assigned line. The WML option is assigned to lines that route to a predefined DN if no digits are dialed within a modifiable time-out period.

Table 1143: C_NT-DMS100_SN06_DEL_WML

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
WARM_LINE_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1144: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_WML	A_NT-DMS100_SN06_DEL_WML

C_NT-DMS100_SN06_DEL_WUC

Removes this option from the assigned line. The WUC option allows a subscriber to set a time for the phone to ring.

Table 1145: C_NT-DMS100_SN06_DEL_WUC

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
WAKE_UP_OPTKEY	A key on a business set or data unit to which an option is assigned.	1-69 for business sets; 1, 2, 3, 4, or 7 for data units		S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1146: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_WUC	A_NT-DMS100_SN06_DEL_WUC

C_NT-DMS100_SN06_DEL_WUCR

Removes this option from the assigned line. The WUCR option allows a subscriber to set a reminder time for the phone to ring.

Table 1147: C_NT-DMS100_SN06_DEL_WUCR

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory number.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1148: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_WUCR	A_NT-DMS100_SN06_DEL_WUCR

Hunt Group Services

This cartridge provides the following CSDL Commands:

- C_NT-DMS100_SN06_ADD_HUNT-GROUP
- C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER
- C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER
- C_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

C_NT-DMS100_SN06_ADD_HUNT-GROUP

Creates the following types of groups: Directory Number Hunt (DNH), Distributed Line Hunt (DLH), Multi-Line Hunt (MLH), Bridged Night Number (BNN), and Simultaneous Ringing (SimRing).

Table 1149: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
BNN	Directory number of BNN member associated with DN_BNN. This is the alternate DN associated to a Hunt DN for night service.			C	O
CUSTOM	Customer-specific parameter.			C	O
DN	The DN of a DNH/PRH group pilot or the DN associated with a DLH/MLH group.			S	O

Table 1149: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
GROUP	Groups beginning with an alphabetic character. Used with the IBN line class code (LCC); Common Language Location Identifier (CLLI) of an IBN customer group. Identifies the customer group for this ACD group.			S	O
GROUPSIZE	Hunt group size; the expected maximum size of the Hunt group. Value 0-1024.			S	O
GROUPTYPE	Type of the group to establish, delete, and modify. The values are: DNH, DLH, MLH, BNN, and SimRing.			S	R
HOST_DN	Bridged night number (BNN) pilot DN.			S	O
HOST_HUNT_TYPE	The type of Hunt group on which your are to establish a BNN Hunt group. The values are DLH, DNH, and MLH.			S	O
HOST_LEN	The length of a host MLH/DLH group member that is to be associated with the pilot of a BNN Hunt group.			S	O
IS_OPTIMIZED	Flag to indicate MML optimization of the command. Valid values are true or false.		true	S	O

Table 1149: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
KEY	The key on a business or data unit. 1 to 68 for business set. 1,2,5, or 7 for data units.			S	O
LATA	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	O
LCC	The line class code of the service to be established, modified, or deleted.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
LTG	Line treatment group member, used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. The LTG is prompted for in conjunction with the LCC. If office parameters are on, a prompt appears. If office parameters are off, no prompt appears. Range 0-255.			S	O
MEMBER_DN	Member DN (for DNH).			C	O

Table 1149: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LEN	The member LEN.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_LINE_CLASS	The LCC of a new member added to a Hunt group if the new number LEN is associated with a Meridian 2000 set.			C	O
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	Member First 3 digits of the line number.			C	O
NCOS	The network class of service for IBN lines, trunks, or attendant consoles; defines a set of capabilities or restrictions that allows or denies calls. The range is 0-255.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 1149: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any deo command.			C	O
PTY	Designation of a party with two-party or multiparty service. Valid value is T1 to T5 for tip parties and R1 to R5 for ring parties.			S	O
RINGCODE	The ringing code input for two-party or multiparty services and the frequency-selective ringing (FSR) with 1FR. Value 0-5.			S	O
RINGING	The key on a business set assigned with ringing ability. The values are Y or N.			S	O
SIMR_PIN	The PIN assigned to the SimRing group. This prompt appears only with the ado, chf, est, new, and newdn commands. The PIN is used for security reasons, when the user tries to access the interface remotely.			S	O

Table 1149: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
SIMR_STATE	The state (active or inactive) of the SimRing feature on a line. The default state is INACT. This prompt appears only with the chf, est, and newdn commands.			S	O
SNPA	The service numbering plan area (area code).			S	O
SUBGRP	Groups 0 to 7 subgroup numbers of a customer group to which a station or DN belongs.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1150: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_HUNT-GROUP	A_NT-DMS100_SN06_ADD_HUNT-GROUP

C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Adds a Hunt member to an existing Hunt group, using the add command.

Table 1151: C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
BNN	Directory number of the BNN member associated with the DN_BNN. This is the alternate DN associated to a Hunt DN for night service.			C	O
CUSTOM	Customer-specific parameter.			C	O
DN	The DN of a DNH/PRH group pilot or the DN associated with a DLH/ MLH group.			S	O
GROUPSIZE	Hunt group size; the expected maximum size of the Hunt group. Value 0-1024.			S	O
GROUPTYPE	Type of the group to establish, delete, modify. The values are: DNH, DLH, MLH, BNN, and SimRing.			S	R
HOST_HUNT_TYPE	The type of Hunt group on which a BNN Hunt group is to be established. The values are DLH, DNH, and MLH.			S	O
IS_OPTIMIZED	Flag to indicate MML optimization of the command. Valid values are true or false.		true	S	O

Table 1151: C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
KEY	The key on a business or data unit. 1 to 68 for business set. 1,2,5, or 7 for data units.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O
MEMBER_DN	Member DN (for DNH).			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LEN	The Member LEN.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_LINE_CLASS	The LCC of a new member added to a Hunt group if the new number LEN is associated with a Meridian 2000 set.			C	O
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	Member First 3 digits of the line number.			C	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 1151: C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any deo command.			C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1152: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER	A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Hunt group services

This service pack provides the following CSDL commands:

- C_NT-DMS100_SN06_ADD_HUNT-GROUP
- C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER
- C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER
- C_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

C_NT-DMS100_SN06_ADD_HUNT-GROUP

Creates the following types of groups: Directory Number Hunt (DNH), Distributed Line Hunt (DLH), Multi-Line Hunt (MLH), Bridged Night Number (BNN), and Simultaneous Ringing (SimRing).

Table 1153: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
BNN	Directory number of BNN member associated with DN_BNN. This is the alternate DN associated to a Hunt DN for night service.			C	O
CUSTOM	Customer-specific parameter.			C	O
DN	The DN of a DNH/PRH group pilot or the DN associated with a DLH/ MLH group.			S	O
GROUP	Groups beginning with an alphabetic character. Used with the IBN line class code (LCC); Common Language Location Identifier (CLLI) of an IBN customer group. Identifies the customer group for this ACD group.			S	O
GROUPSIZE	Hunt group size; the expected maximum size of the Hunt group.	0-1024		S	O
GROUPTYPE	Type of the group to establish, delete, and modify.	DNH, DLH, MLH, BNN, SimRing		S	R

Table 1153: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
HOST_DN	Bridged night number (BNN) pilot DN.			S	O
HOST_HUNT_TYPE	The type of Hunt group on which your are to establish a BNN Hunt group.	DLH, DNH, MLH		S	O
HOST_LEN	The length of a host MLH/DLH group member that is to be associated with the pilot of a BNN Hunt group.			S	O
IS_OPTIMIZED	Flag to indicate MML optimization of the command.	true, false	true	S	O
KEY	The key on a business or data unit.	1 to 68 for business set. 1,2,5, or 7 for data units		S	O
LATA	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	O
LCC	The line class code of the service to be established, modified, or deleted.			S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 1153: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
LTG	Line treatment group member, used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. The LTG is prompted for in conjunction with the LCC. If office parameters are on, a prompt appears. If office parameters are off, no prompt appears.	0-255		S	O
MEMBER_DN	Member DN (for DNH).			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LEN	The member LEN.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_LINE_CLASS	The LCC of a new member added to a Hunt group if the new number LEN is associated with a Meridian 2000 set.			C	O
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	First 3 digits of the member line number.			C	O

Table 1153: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
NCOS	The network class of service for IBN lines, trunks, or attendant consoles; defines a set of capabilities or restrictions that allows or denies calls.	0-255		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any deo command.			C	O
PTY	Designation of a party with two-party or multiparty service.	T1 to T5 for tip parties and R1 to R5 for ring parties		S	O
RINGCODE	The ringing code input for two-party or multiparty services and the frequency-selective ringing (FSR) with 1FR.	0-5		S	O
RINGING	The key on a business set assigned with ringing ability.	Y, N		S	O

Table 1153: C_NT-DMS100_SN06_ADD_HUNT-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
SIMR_PIN	The PIN assigned to the SimRing group. This prompt appears only with the ado, chf, est, new, and newdn commands. The PIN is used for security reasons, when the user tries to access the interface remotely.			S	O
SIMR_STATE	The state (active or inactive) of the SimRing feature on a line. The default state is INACT. This prompt appears only with the chf, est, and newdn commands.			S	O
SNPA	The service numbering plan area (area code).			S	O
SUBGRP	Groups 0 to 7 subgroup numbers of a customer group to which a station or DN belongs.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1154: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_HUNT-GROUP	A_NT-DMS100_SN06_ADD_HUNT-GROUP

C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Adds a Hunt member to an existing Hunt group, using the add command.

Table 1155: C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
BNN	Directory number of the BNN member associated with the DN_BNN. This is the alternate DN associated to a Hunt DN for night service.			C	O
CUSTOM	Customer-specific parameter.			C	O
DN	The DN of a DNH/PRH group pilot or the DN associated with a DLH/ MLH group.			S	O
GROUPSIZE	Hunt group size; the expected maximum size of the Hunt group.	0-1024		S	O
GROUPTYPE	Type of the group to establish, delete, modify.	DNH, DLH, MLH, BNN, SimRing		S	R
HOST_HUNT_TYPE	The type of Hunt group on which a BNN Hunt group is to be established.	DLH, DNH, MLH		S	O
IS_OPTIMIZED	Flag to indicate MML optimization of the command.	true, false	true	S	O
KEY	The key on a business or data unit.	1 to 68 for business set. 1,2,5, or 7 for data units		S	O
LEN	Line equipment number.			S	O
LINE	4 digit line extension.			S	O

Table 1155: C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
MEMBER_DN	Member DN (for DNH).			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LEN	The Member LEN.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_LINE_CLASS	The LCC of a new member added to a Hunt group if the new number LEN is associated with a Meridian 2000 set.			C	O
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	Member First 3 digits of the line number.			C	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any deo command.			C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1156: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER	A_NT-DMS100_SN06_ADD_HUNT-GROUP-MEMBER

C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

Deletes a Hunt group member from an existing Hunt group.

Table 1157: C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The DN of the SimRing group. When the PDN receives a call, all the members of the SimRing group receive simultaneous notification. A SimRing group can have only one PDN. This prompt appears only with the add, est, and del commands.			S	O
GROUPTYPE	Type of the group to establish, delete, modify.	DNH, DLH, MLH, SimRing		S	R
INTERCEPT_NAME	Enter the type of intercept. PODN is an LNP treatment that designates a ported-out DN.			S	O

Table 1157: C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number. Either LEN or LTID must exist; if both exist, LTID is ignored.			S	O
LINE	4 digit line extension.			S	O
MEMBER_DN	Member DN (for DNH).			C	O
MEMBER_KEY	The line Hunt overflow route index that identifies the overflow route.			C	O
MEMBER_LEN	The member LEN.			C	O
MEMBER_LINE	Member 4 digit line extension.			C	O
MEMBER_NPA	Member 3 digit area code.			C	O
MEMBER_NXX	Member First 3 digits of the line number.			C	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1158: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER	A_NT-DMS100_SN06_DEL_HUNT-GROUP-MEMBER

C_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

Establishes a new distributed line Hunt group. Only one pilot DN is associated with the Hunt group.

Table 1159: C_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
GROUP_SIZE	Hunt group size.			S	R
LCC	The line class code of the pilot DN.			S	R
MEM_LEN	The LEN of the DLH group member.			C	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
PILOT_LEN	The LEN of Hunt group pilot.			S	R
PILOT_LINE	4 digit line extension of the pilot DN.			S	R
PILOT_NPA	3 digits area code of pilot DN.			S	R
PILOT_NXX	First 3 digits of the line number of the pilot DN.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1160: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ESTABLISH_DLH-GROUP	A_NT-DMS100_SN06_ESTABLISH_DLH-GROUP

POTS Line Features

This cartridge provides the following CSDL commands:

- C_NT-DMS100_SN06_ADD_LINE
- C_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL
- C_NT-DMS100_SN06_ADD_NEWDN
- C_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL
- C_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL
- C_NT-DMS100_SN06_DEL_LINE
- C_NT-DMS100_SN06_DEL_NEWDN
- C_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL
- C_NT-DMS100_SN06_PLUG-UP_LINE
- C_NT-DMS100_SN06_QRY_CUSTOMER-INFO
- C_NT-DMS100_SN06_QRY_DN
- C_NT-DMS100_SN06_QRY_LEN
- C_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL
- C_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL
- C_NT-DMS100_SN06_RESTORE_LINE
- C_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES
- C_NT-DMS100_SN06_SUSPEND_LINE

C_NT-DMS100_SN06_ADD_LINE

Establishes service for single-line and multi-line telephone sets that are not assigned.

Table 1161: C_NT-DMS100_SN06_ADD_LINE

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	7 or 10 digits entered with no spaces or hyphens.			S	O
GROUP	Groups beginning with an alphabetic character. Used with the IBN line class code (LCC); Common Language Location Identifier (CLLI) of an IBN customer group. Identifies the customer group for this ACD group.			S	O
IS_OPTIMIZED	Flag to indicate MML optimazation of the command.	true, false	true	S	O
KEY	The key on a business or data unit.	1 to 68 for business sets and 1,2,5, or 7 for data units		S	O
LATA	The calling Local Access and Transport Area (LATA) name associated with the originator of the call.			S	R
LCC	The line class code of the service to be established, modified, or deleted.	1FR, 1MR, 2FR, 4FR, CDF, IBN, ISDNKSET, INW, OWT, PBM, PBX, ZMZPA		S	R

Table 1161: C_NT-DMS100_SN06_ADD_LINE

Parameter Name	Description	Range	Default Value	Type	Class
LEN	Line equipment number. Either LEN or LTID must exist. If both exist, LTID is ignored.			S	O
LINE	4 digit line extension.			S	O
LTG	Line treatment group member, used to calculate the line attribute index when the DN and LCC are insufficient to find an appropriate index. The LTG is prompted for in conjunction with the LCC.	0-255		S	R
LTID	Logical terminal identifier.			S	O
NCOS	The network class of service for IBN lines, trunks, or attendant consoles. Defines a set of capabilities or restrictions that allows or denies calls.	0-255		S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 1161: C_NT-DMS100_SN06_ADD_LINE

Parameter Name	Description	Range	Default Value	Type	Class
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any DEO command.			C	O
PTY	The designation of a party with two-party or multiparty service.	T1 to T5 for tip parties and R1 to R5 for ring parties		S	O
RINGCODE	The ringing code input for two-party or multiparty services and FSR with 1FR.	0-5		S	O
RINGING	The key on a business set assigned with ringing ability.	Y, N		S	O
SNPA	The service numbering plan area (area code).			S	O
SUBGRP	Groups 0 to 7 subgroup numbers of a customer group to which a station or DN belongs.			S	O
ZONE	OUTWATS zone identification number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1162: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LINE	A_NT-DMS100_SN06_ADD_LINE

C_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

The SLT ADD command adds a new logical terminal and defines its service Parameters. The SLT ADD command datafills tables LTDEF and KSETINV with the logical terminal identifier (LTID) profile information.

Table 1163: C_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
ABS	Authorized bearer services allows the bearer services to which a circuit-switched call can be subscribed.			C	O
CS	Designated circuit-switched service.			S	O
CUSTOM	Customer-specific parameter.			C	O
DEFLTERM	Default logical terminal. Enter Y to provision an integrated and a packet-only NIT with dynamic TEI.			S	O
EKTS	Electronic key telephone set.			S	O

Table 1163: C_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
LTCLASS	Class of logical terminal based on the type of messaging exchanged between the terminal and the ISDN switch.			S	R
LTID	Logical Terminal Identifier.			S	R
MAXKEYS	Maximum number of feature activators(keys) on a logical terminal used for circuit-switched service.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
OPT	Options installed on the terminal.	AGA, CACH, EKTS, PVC, SLBRI, SPIDSFX, TERML		C	O
PS	Packet-switched service.			S	O
TEI	Terminal endpoint identifier.			S	O
TEI_TYPE	Terminal endpoint identifier type.			S	O
TSPID	Terminal service profile identifier option is used to initialize BRIFS LTIDs. This option is used with the Free Format SPID feature.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1164: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL	A_NT-DMS100_SN06_ADD_LOGICAL-TERMINAL

C_NT-DMS100_SN06_ADD_NEWDN

The NEWDN command assigns directory numbers (DN) that are associated with an office route, but not physical line equipment.

Table 1165: C_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
AIN_VDN_OPT_NCOS	Value of AIN_VDN_OPTION NCOS, when VDNTYPE=AIN.			S	O
AIN_VDN_OPT_SMDR	Option AIN_VDN_OPTION SMDR, where are values are Y, N. Value Y indicates that option will be added, value N no, when VDNTYPE=AIN.			S	O
BLK_TOLL_COM	Appears for the RCF option. Specifies whether incoming toll calls are forwarded to a remote station.	Y, N		S	O
BLK_TOLL_TREATMENT	Appears for the RCF option. Specifies the treatment given to a blocked toll call.			S	O

Table 1165: C_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
BLOCK_OF_DNS	Used to assign a block of DNs or a single DN. Use YES for a block of DNs or NO for a single DN and RCF.			S	R
CUSTGRP	Value of custgrp when VDNTYPE=AIN, DNTYPE=IBN			S	O
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
DNTYPE	When VDNTYPE=AIN, value IBN, NONIBN			S	O
FWD_DN	The DN (up to 30 digits) to which calls are forwarded in a fixed call forwarding option.			S	O
FWD_LINE	4 digit line extension of a FWD DN.			S	O
FWD_NPA	3 digit area code of a FWD DN.			S	O
FWD_NXX	First 3 digits of the line number of a FWD DN.			S	O

Table 1165: C_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
IS_OPTIMIZED	Flag to indicate MML optimazation of the command.	true, false	true	S	O
LATANM	LATANM value.			S	O
LINE	4 digit line extension.			S	O
LINEATTR	Value of lineattr when VDNTYPE=AIN, DNTYPE=NONIBN			S	O
LTG	Line treatment group member, used to calculate the line attribute index then the DN and LCC are insufficient to find an appropriate index. LTG is prompted for in conjunction with LCC.	0-255		S	O
MAXCALLS	Appears during the assignment of an RCF. Specifies the maximum number of simultaneous calls allowed to the DN.	0-511		S	O
MRSA	MRSA as defined in table MRSANAME. Message rate service area to be used for billing with remote call forwarding.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Table 1165: C_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
OFRTINDX	OFRTINDX value.			S	O
OM_INDEX	Operations measurements index. Value 0-127.			S	O
OPT	Option(s) associated with a service to be established, modified, or deleted. A maximum of 20 options can be specified in any single command. A maximum of 128 options can be specified in any DEO command.			C	O
PRTNM	PRTNM value.			S	O
SCRNCL	Specifies route or screening class for a forwarded call.	RTE, SCR		S	O
SIGDATA	Specifies whether or not to use RCF signaling enhancements.	Y, N		S	O
SNPA	Serving numbering plan area station.			S	O
SUBGRP	Value of custgrp when VDNTYPE=AIN, DNTYPE=IBN			S	O

Table 1165: C_NT-DMS100_SN06_ADD_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
VDNTYPE	Used to provision VDNs. When BLOCK_OF_DNS is NO, the following inputs are valid: AIN, DISA, CFIB, RCF, RCFEA, RTE, MSR, SIMRING. When BLOCK_OF_DNS is YES, the valid input is RTE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1166: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ADD_NEWDN	A_NT-DMS100_SN06_ADD_NEWDN

C_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL

The SLT ATT command attaches a logical terminal to a line equipment number (LEN) and a terminal endpoint identifier (TEI).

Table 1167: C_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LEN	The LEN for a service to establish, change, or delete.			S	R
LTID	Logical Terminal Identifier.			S	R

Table 1167: C_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
NE_ID_NT-DMS100	The name of the host NE.			S	R
OPT	Option(s) associated with a service to add or change on the terminal.	TEI, PHLINK, TO, BCH, PHI, DCHCHNL		C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1168: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL	A_NT-DMS100_SN06_ATTACH_LOGICAL-TERMINAL

C_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL

The SLT CHA command changes the following parameters associated with an LTID: AGA, PVC, CACH, SPIDSFX, EKTS, TERML and TSPID.

Table 1169: C_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LTID	Logical Terminal Identifier.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
OPT	Option(s) associated with a service to add or change on the terminal.	ABS, AGA, CACH, PVC, EKTS, SLBRI, SPIDSFX		C	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1170: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL	A_NT-DMS100_SN06_CHANGE_LOGICAL-TERMINAL

C_NT-DMS100_SN06_DEL_LINE

Removes service from single line and multi-line telephone set directory numbers (DN) and line equipment numbers (LEN).

Table 1171: C_NT-DMS100_SN06_DEL_LINE

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
INTERCEPT_NAME	The type of intercept you want.	BLDN, AINT, ANCT, CANN, OPRT, UNDN		S	R
LEN	Line equipment number. Either LEN or LTID must exist. If both exist, LTID is ignored.			S	O
LINE	4 digit line extension.			S	O

Table 1171: C_NT-DMS100_SN06_DEL_LINE

Parameter Name	Description	Range	Default Value	Type	Class
LTID	Logical terminal identifier.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1172: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_LINE	A_NT-DMS100_SN06_DEL_LINE

C_NT-DMS100_SN06_DEL_NEWDN

The OUTDN command can be used to do the following: delete virtual directory numbers (VDN) that are not associated with physical line equipment, delete remote call forwarding (RCF) from a DN, or delete call forward/interface busy (CFIB) from a DN.

Table 1173: C_NT-DMS100_SN06_DEL_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
BLOCK_OF_DNS	Used to assign a block of DNs or a single DN. Use YES for a block of DNs or NO for a single DN and RCF.			S	R
CODEHOLDER	The CodeHolder value.	Y, N		S	O
CUSTOM	Customer-specific parameter.			C	O

Table 1173: C_NT-DMS100_SN06_DEL_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
INTERCEPT_NAME	The type of intercept you want. The value is: BLDN.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O
POOL_OUT	The Pool out value. Possible values are: Y or N.			S	O
SNPA	Serving numbering plan area station.			S	O
TO_DN	Used for block deletion of DN; indicates the last three digits of the last DN in the block. It is in format of 3 digits.			S	O

Table 1173: C_NT-DMS100_SN06_DEL_NEWDN

Parameter Name	Description	Range	Default Value	Type	Class
VDNTYPE	Used to assign the RCT feature to a block of DNs; selector for the type of DN. RTE = Route, RCF = Remote Call Forwarding, Forwarding LDN = Line DN, RCFEA = Remote Call, Forwarding equal access. A numeric entry of 1 to 30 digits.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1174: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DEL_NEWDN	A_NT-DMS100_SN06_DEL_NEWDN

C_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL

The SLT DET command detaches a logical terminal from a LEN and a TEI. This command removes datafill from table LTMAP.

Table 1175: C_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LTID	Logical Terminal Identifier.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1176: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL	A_NT-DMS100_SN06_DETACH_LOGICAL-TERMINAL

C_NT-DMS100_SN06_PLUG-UP_LINE

The PLP command allows the user to plug up directory numbers (DNs) on single-line sets. The operating company personnel cannot issue this command on multi-line telephone set DNs.

Table 1177: C_NT-DMS100_SN06_PLUG-UP_LINE

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	R
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O

Table 1177: C_NT-DMS100_SN06_PLUG-UP_LINE

Parameter Name	Description	Range	Default Value	Type	Class
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1178: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_PLUG-UP_LINE	A_NT-DMS100_SN06_PLUG-UP_LINE

C_NT-DMS100_SN06_QRY_CUSTOMER-INFO

Retrieves information about the line data associated with one or more customer groups on the switch.

Table 1179: C_NT-DMS100_SN06_QRY_CUSTOMER-INFO

Parameter Name	Description	Range	Default Value	Type	Class
CUSTGRP	The customer group name for the line.			S	O
CUSTOM	Customer-specific parameter.			C	O
LEN	The LEN for a service to establish, change, or delete.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1180: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_QRY_CUSTOMER-INFO	A_NT-DMS100_SN06_QRY_CUSTOMER-INFO

C_NT-DMS100_SN06_QRY_DN

Retrieves information about the system and services associated with wireline or wireless subscriber, based on the directory number (DN).

Table 1181: C_NT-DMS100_SN06_QRY_DN

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1182: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_QRY_DN	A_NT-DMS100_SN06_QRY_DN

C_NT-DMS100_SN06_QRY_LEN

Command QLEN generates a printout of line data related to a specified line equipment number (LEN) or directory number (DN).

Table 1183: C_NT-DMS100_SN06_QRY_LEN

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	O
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1184: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_QRY_LEN	A_NT-DMS100_SN06_QRY_LEN

C_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL

Retrieves information about the logical terminals, with the logical terminal identifier.

Table 1185: C_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LTID	Logical Terminal Identifier.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1186: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL	A_NT-DMS100_SN06_QRY_LOGICAL-TERMINAL

C_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL

The SLT REM command removes an LTID from the access information tables. This command removes datafill from table LTDEF.

Table 1187: C_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
LTID	Logical Terminal Identifier.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1188: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL	A_NT-DMS100_SN06_REMOVE_LOGICAL-TERMINAL

C_NT-DMS100_SN06_RESTORE_LINE

The RES command restores service to busy or suspended single line and multi-line telephone set directory numbers (DN).

Table 1189: C_NT-DMS100_SN06_RESTORE_LINE

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O

Table 1189: C_NT-DMS100_SN06_RESTORE_LINE

Parameter Name	Description	Range	Default Value	Type	Class
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O
LEN	The LEN for a service to establish, change, or delete.			S	R
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1190: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_RESTORE_LINE	A_NT-DMS100_SN06_RESTORE_LINE

C_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

The SDNA command adds, changes, or deletes attributes for a specified group of directory numbers (DNs).

Table 1191: C_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

Parameter Name	Description	Range	Default Value	Type	Class
AREACODE	Serving numbering plan area code for the station.			S	R
CUSTOM	Customer-specific parameter.			C	O
FROMDIGS	Indicates the starting DN of a DN group to which network attributes are assigned.			S	R
FUNCTION	Indicates the function to add, change, or delete the network attributes.			S	R
NAME	Indicates display suppression of the name of the originating subscriber.			S	O
NETNAME	Network name that appears as DN attribute.			S	R
NE_ID_NT-DMS100	The name of the host NE.			S	R
OFCCODE	Office code for DN, which is the second series of three digits of the DN.			S	R
OPT	Features Used to Set Up Dn Attributes.	NAME, ADDRESS, SUPPRESS, NONUNIQUE		C	O

Table 1191: C_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

Parameter Name	Description	Range	Default Value	Type	Class
TODIGS	Indicates the last DN of a DN group to which network attributes are assigned.			S	R

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1192: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES	A_NT-DMS100_SN06_SETUP_DN-ATTRIBUTES

C_NT-DMS100_SN06_SUSPEND_LINE

The SUS command suspends service to Directory Numbers (DNs) on single line and multi-line telephone sets.

Table 1193: C_NT-DMS100_SN06_SUSPEND_LINE

Parameter Name	Description	Range	Default Value	Type	Class
CUSTOM	Customer-specific parameter.			C	O
DN	The directory number associated with the service that you are establishing, modifying, or deleting. If a 7-digit DN is entered and that DN exists on the switch, you are prompted to enter the full 10-digit DN.			S	O

Table 1193: C_NT-DMS100_SN06_SUSPEND_LINE

Parameter Name	Description	Range	Default Value	Type	Class
LEN	The LEN for a service to establish, change, or delete.			S	R
LINE	4 digit line extension.			S	O
NE_ID_NT-DMS100	The name of the host NE.			S	R
NPA	3 digit area code.			S	O
NXX	First 3 digits of the line number.			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service.

Table 1194: CSDL to ASDL Mapping

CSDL	ASDL
C_NT-DMS100_SN06_SUSPEND_LINE	A_NT-DMS100_SN06_SUSPEND_LINE

C_NT-DMS100_SN06_DEL_DCPK

The DCPK option option allows the system to put calls on hold or to park calls against any valid DN.

Table 1195:

Parameter Name	Description	Range	Default Value	Type	Class
DN	Directory Number			S	R
LEN	Line equipment number.			S	O
LINE	4 digits line extension			S	O

Table 1195:

Parameter Name	Description	Range	Default Value	Type	Class
MCLI	The name of the host NE.			S	R
NPA	3 digits area code			S	O
NXX	First 3 digits of the line number			S	O

Mapping to ASDLs

The following table illustrates the CSDL to ASDL mapping for this service

Table 1196:

CSDL	ASDL
C_NT-DMS100_SN06_ADD_DCPK	**A_NT-DMS100_SN06_ADD_DCPK**

5

Configuring ASAP to Support Additional NE Instances

You can configure ASAP to support the DMS100 - NEP configuration using the Service Activation Configuration Tool (SACT). Refer to the *ASAP Administration Guide* fore more information.

Below is an example of the Activation.Configuration.xml file for the Comverse MMS cartridge.

```
?xml version="1.0" encoding="UTF-8"?>
<activationConfig xmlns="http://www.metasolv.com/ServiceActivation/
  2003/ActivationConfig" xmlns:xsi="http://www.w3.org/2001/XMLSchema-
  instance" xsi:schemaLocation="http://www.metasolv.com/ServiceActi-
  vation/2003/ActivationConfig
C:\data\ASAP\4.7.1\xsd\ActivationConfig.xsd">
   <connectionPool name="DMS100_P">
      <device name="dms100_sn06_dev1">
         <environment>MY_ASAP_SYS</environment>
         <lineType>TELNET_CONNECTION</lineType>
      </device>
      <device name="dms100_sn06_dev2">
         <environment>MY_ASAP_SYS</environment>
         <lineType>TELNET_CONNECTION</lineType>
      </device>
      <device name="dms100_sn06_dev3">
         <environment>MY_ASAP_SYS</environment>
         <lineType>TELNET_CONNECTION</lineType>
      </device>
      <device name="dms100_sn06_dev4">
         <environment>MY_ASAP_SYS</environment>
         <lineType>TELNET_CONNECTION</lineType>
      </device>
      <device name="dms100_sn06_dev5">
         <environment>MY_ASAP_SYS</environment>
         <lineType>TELNET_CONNECTION</lineType>
      </device>
   </connectionPool>
   <element name="DMS100_1">
      <technology>NT-DMS100</technology>
      <softwareLoad>SN06</softwareLoad>
      <nepServerName>$NEP</nepServerName>
      <primaryPool>DMS100_P</primaryPool>
      <maximumConnections>5</maximumConnections>
      <dropTimeout>5</dropTimeout>
      <spawnThreshold>1</spawnThreshold>
```

```
<killThreshold>0</killThreshold>
<routingElement name="DMS100_1">
   <atomicService/>
</routingElement>
<communicationParameter>
   <label>HOST_IPADDR</label>
   <value>
      <value>127.0.0.1</value>
   </value>
   <description>The IP Address of Servord</description>
   <deviceName>COMMON_DEVICE_CFG</deviceName>
   <lineType>TELNET_CONNECTION</lineType>
</communicationParameter>
<communicationParameter>
   <label>PORT</label>
   <value>
      <value>23</value>
   </value>
   <description>Port number Servord</description>
   <deviceName>COMMON_DEVICE_CFG</deviceName>
   <lineType>TELNET_CONNECTION</lineType>
</communicationParameter>
<communicationParameter>
   <label>OPEN_TIMEOUT</label>
   <value>
      <value>15</value>
   </value>
   <description>Connection timeout (seconds)</description>
   <deviceName>COMMON_DEVICE_CFG</deviceName>
   <lineType>TELNET_CONNECTION</lineType>
</communicationParameter>
<communicationParameter>
   <label>READ_TIMEOUT</label>
   <value>
      <value>60</value>
   </value>
   <description>Read timeout (seconds)</description>
   <deviceName>COMMON_DEVICE_CFG</deviceName>
   <lineType>TELNET_CONNECTION</lineType>
</communicationParameter>
<communicationParameter>
   <label>HOST_USERID</label>
   <value>
      <value>asap</value>
   </value>
   <description>Servord User ID</description>
   <deviceName>COMMON_DEVICE_CFG</deviceName>
   <lineType>TELNET_CONNECTION</lineType>
</communicationParameter>
<communicationParameter>
   <label>HOST_PASSWORD</label>
   <value>
      <value>asap</value>
   </value>
   <description>Servord Password</description>
   <deviceName>COMMON_DEVICE_CFG</deviceName>
   <lineType>TELNET_CONNECTION</lineType>
```

```
    </communicationParameter>
    <communicationParameter>
       <label>PROMPT</label>
       <value>
          <value>&gt;</value>
       </value>
       <description>Provisioning prompt</description>
       <deviceName>COMMON_DEVICE_CFG</deviceName>
       <lineType>TELNET_CONNECTION</lineType>
    </communicationParameter>
    <communicationParameter>
       <label>IS_OPTIMIZED</label>
       <value>
          <value>true</value>
       </value>
       <description>A flag to indicate MML optimazation of the com-
mand. The values are false and true.</description>
       <deviceName>COMMON_DEVICE_CFG</deviceName>
       <lineType>TELNET_CONNECTION</lineType>
    </communicationParameter>
    <communicationParameter>
       <label>IS_COMMIT</label>
       <value>
          <value>Y</value>
       </value>
       <description>Servord Save Provisioning Mode</description>
       <deviceName>COMMON_DEVICE_CFG</deviceName>
       <lineType>TELNET_CONNECTION</lineType>
    </communicationParameter>
    <communicationParameter>
       <label>MAX_NUM_CHAR_LINE</label>
       <value>
          <value>75</value>
       </value>
       <description>Max character number per command line</descrip-
tion>
       <deviceName>COMMON_DEVICE_CFG</deviceName>
       <lineType>TELNET_CONNECTION</lineType>
    </communicationParameter>
    <communicationParameter>
       <label>RESPONSELOG</label>
       <value>
          <value>TRUE</value>
       </value>
       <description>Flag to turn on or off response logging</de-
scription>
       <deviceName>COMMON_DEVICE_CFG</deviceName>
       <lineType>TELNET_CONNECTION</lineType>
    </communicationParameter>
    <communicationParameter>
       <label>CONNECTION_PAUSE</label>
       <value>
          <value>2</value>
       </value>
       <description>Sleep time between send and read for connec-
tion.</description>
       <deviceName>COMMON_DEVICE_CFG</deviceName>
```

```
            <lineType>TELNET_CONNECTION</lineType>
         </communicationParameter>
         <communicationParameter>
            <label>PAUSE</label>
            <value>
               <value>1</value>
            </value>
            <description>Pause between sending MML and reading NE re-
   sponse.</description>
            <deviceName>COMMON_DEVICE_CFG</deviceName>
            <lineType>TELNET_CONNECTION</lineType>
         </communicationParameter>
         <communicationParameter>
            <label>VALIDATE_PROMPT</label>
            <value>
               <value>false</value>
            </value>
            <description>Flag indicating if prompt validation is re-
   quired</description>
            <deviceName>COMMON_DEVICE_CFG</deviceName>
            <lineType>TELNET_CONNECTION</lineType>
         </communicationParameter>
         <communicationParameter>
            <label>USE_SECURE_DATA</label>
            <value>
               <value>false</value>
            </value>
            <description>Flag indicating wether Secure Login Username and
   Password Required </description>
            <deviceName>COMMON_DEVICE_CFG</deviceName>
            <lineType>TELNET_CONNECTION</lineType>
         </communicationParameter>
         <communicationParameter>
            <label>DESTINATION</label>
            <value>
               <value>milano</value>
            </value>
            <description>Destination id</description>
            <deviceName>COMMON_DEVICE_CFG</deviceName>
            <lineType>TELNET_CONNECTION</lineType>
         </communicationParameter>
         <communicationParameter>
            <label>ACCESS_GUARD</label>
            <value>
               <value>Y</value>
            </value>
            <description>Access guard Y or N.</description>
            <deviceName>COMMON_DEVICE_CFG</deviceName>
            <lineType>TELNET_CONNECTION</lineType>
         </communicationParameter>
      </element>
   </activationConfig>
```

Using secure data

If you set the "USE_SECURE_DATA" flag in tbl_comm_param to "true", the login will be secure. The login ID and password will not be displayed as a clear text in the NEP.diag file. The labels that support secure data are HOST_CLLI and DEVICE_NAME. For example, HOSTCLLI_1***device_1 or dms100_sn06_dev1:user_sam1***pass_sam1.

```
Diagnostic.diag( Diagnostic.LOW, this, "Getting secure data
Login Username and Password");

Get login information from CTRL DB
    Security sec = ASCAppl.getSecurity();

    String securDataKey = hostClli + "***" + device;
    String secLogin = sec.getSecureData(securDataKey, 1);

    Diagnostic.diag( Diagnostic.LOW, this, "Retrieved secure data  ");
    Diagnostic.diag( Diagnostic.LOW, this, "Parsing login data for user id - password");
```

Secure ASAP data is stored in tbl_classA_secu and tbl_classB_secu. These tables allow entries in a name/value format for class type, security level, caching of data, and so forth.

For more information on these tables, refer to the *ASAP Developer's Reference*.

Secure data can be stored either in "clear" or in "encrypted" format. This depends on the security level of control server, which determines the system security level. During ASAP installation, user IDs and passwords for all the servers are populated from the ASAP_password.dat file.

By default, the data in both tbl_classA_secu and tbl_classB_secu is stored in clear text because the security level for control server/database is set to 0: ctrlS667:ctrlS667:0:**0**:0:0.

If the security level is changed to 1 (ctrlS667:ctrlS667:0:**1**:0:0), then both ASAP and custom data is stored in encrypted format.

Both ASAP and custom secure data can be loaded by using asap_security_tool utility. For more information on the asap_security_tool, refer to ASAP Administration Guide.

To store and retrieve secure NE login information, perform the following steps:

1. If you want to store all the information in encrypted format, ensure that the security level for control database is set to 1 (enable security feature). If security is off, modify the input *.dat file and run once again LoadSecurity script.
2. Load "class B" data, which contains NE access information by following the steps:
    a. Define an input file, which contains data to be stored in tbl_classB_secu.
    b. Load the content of this file into the control database using the asap_security_tool utility:

    ```
    asap_security_tool -u $CTRL_USER -p $CTRL_PASSWORD -r  <secure data
    input file>
    ```

Ensure that ASAP is stopped when running the tool.

Use Security.java class to manipulate secure data. The following example shows how to retrieve an encrypted user ID and password using Java code:

```
Diagnostic.diag( Diagnostic.LOW, this,  diagToken + "Getting access secure
data");
Security sec = ASCAppl.getSecurity();
String secUsername = sec.getSecureData("USER_NOKIA", 1);
Diagnostic.diag( Diagnostic.LOW, this, "Retrieved secure user name" );
String secPassword = sec.getSecureData("PASS_NOKIA", 1);
Diagnostic.diag( Diagnostic.LOW, this, "Retrieved secure password ");
```

Once retrieved, data is automatically decrypted and ready to be sent to the NE. Ensure that this data is not displayed in the cartridge diagnostics. It is recommended that asterisks (***) be displayed instead of real data.

This cartridge supports muliple user IDs and passwords per switch when using secure data. The labels are generated dynamically, based on the name of both the HOSTCLLI and DEVICE, with an underscore as a separator. For example:

```
DMS100_1***dms100_sn06_dev1:user_sam1***pass_sam1:1:0:User name and Password
for DMS100

DMS100_1***dms100_sn06_dev2:user_sam2***pass_sam2:1:0:User name and Password
for DMS100

DMS100_1***dms100_sn06_dev3:user_sam3***pass_sam3:1:0:User name and Password
for DMS100

DMS100_1***dms100_sn06_dev4:user_sam4***pass_sam4:1:0:User name and Password
for DMS100

DMS100_1***dms100_sn06_dev5:user_sam5***pass_sam5:1:0:User name and Password
for DMS100
```

Extracting source files

Before you can access an XML file to modify it, you must extract it from the sar file. Use the following procedure to extract source files from the sar file.

To extract source files

1. If necessary, create a repository directory under //Nortel_DMS100_SN06, copy the .sar file to the new directory and un-jar the sar file, as described in "Loading a new XML file" on page 887.
2. After you un-jar the sar file, you can access the XML files.

Loading a new XML file

When you finish modifying an XML, you must create a new sar file, then restart the cartridge using the new file.

Follow the instructions in "Loading a new XML file" on page 887 for directions on how to load a new XML file.

6

MML Commands

This chapter provides you with a list of the MML commands that this cartridge uses.

MML command execution overview

The following describes how the Java method executes the MML command.

1. The Java method retrieves the ASDL parameters.
2. Using the parameters, the method builds the MML command.
3. If the NE is in live mode, the method sends the MML to the remote host, then waits for the response.
4. The method checks the response from the NE for errors.
   - If the response is error free, the method returns a SUCCEED message to the upstream system.
   - If an error occurs, the method returns an error message to the SARM.

MML of DMS100 services

Add Features

3WC

1FR, 1MR, IBN

```
ado $ dn_or_len 3WC $ Y
```

M5312, ISDNKSET

```
ado $ dn_or_len optkey 3WC $ Y
```

ACB

IBN

```
ado $ dn_or_len ACB billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

M5312, ISDNKSET

```
ado $ dn_or_len optkey ACB billing_option [ keylist ]0..n  $ Y
```

where billing_option = AMA or NOAMA or $, default is $

ACD

IBN

```
ado $ dn_or_len ACD acdgroup acdsgrp  idnum posid  ibn_acd_option0.n
scai_link $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey ACD  acdgroup acdsgrp  idnum posid
ibn_acd_option0.n scai_link $ Y
```

If ibn_acd_option = 'SCAILINK'

scai_link = 'SCAIDEF' or 1-8 alphanumeric

If ibn_acd_option = 'ACDNR'

scai_link = ''

ACDNR

IBN

```
ado $ dn_or_len ACDNR $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey ACDNR $ Y
```

ACRJ

1FR, 1MR, IBN

```
ado $ dn_or_len ACRJ status $ Y
```

M5312, ISDNKSET

```
ado $ dn_or_len optkey ACRJ status $ Y
```

AIN

1FR, 1MR, IBN

```
ado $ dn_or_len AIN aingrp Y
```

M5000

```
ado $ dn_or_len optkey AIN aingrp [ keylist ]0..n  $ Y
```

AINDN

1FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

if aingrp != "TIID"

```
ado $ dn_or_len AINDN aingrp $ Y
```

if aingrp = "TIID"

```
ado $ dn_or_len AINDN aingrp tdp tiname trigger $ Y
```

M5312, ISDNKSET

if aingrp != "TIID"

```
ado $ dn_or_len optkey AINDN aingrp $ Y
```

if aingrp = "TIID"

```
ado $ dn_or_len optkey AINDN aingrp tdp tiname trigger $ Y
```

AMSGDENY

1FR, 1MR, IBN, PBM, PBX

```
ado $ dn_or_len AMSGDENY $ Y
```

AR

IBN

```
ado $ dn_or_len AR billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

M5312, ISDNKSET

```
ado $ dn_or_len optkey AR billing_option [ keylist ]0..n  $ Y
```

where billing_option = AMA or NOAMA or $, default is $

ARDDN

IBN

```
ado $ dn_or_len ARDDN $ Y
```

M5312

```
ado $ dn_or_len optkey ARDDN $ Y
```

ASL

KEYSET LCCs

```
ado $ dn_or_len optkey ASL  agent_len  msbovrd  aslsdn $ Y
```

AUD

KEYSET LCCs

```
ado $ dn_or_len optkey AUD  pgmaud  audfeat $ Y
```

AUL

1FR, 1MR, IBN

```
ado $ dn_or_len AUL aul_dn $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey AUL aul_dn $ Y
```

AUTODISP

KEYSET LCCs

```
ado $ dn_or_len optkey AUTODISP  cwt  [ keylist ]0..n $ Y
```

CBE

IBN

```
ado $ dn_or_len CBE $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CBE $ Y
```

CBU

IBN

```
ADO $ dn_or_len CBU $ Y
```

ISDNKSET, KEYSET LCCs

```
ADO $ dn_or_len optkey CBU $ Y
```

CCW

1FR, 1MR, IBN, ZMZPA

```
ado $ dn_or_len CCW $ Y
```

M5312

```
ado $ dn_or_len optkey CCW $ Y
```

CDE

IBN

```
ADO $ dn_or_len CDE $ Y
```

KEYSET LCCs

```
ADO $ dn_or_len optkey CDE $ Y
```

CDI

IBN

```
ADO $ dn_or_len CDI $ Y
```

KEYSET LCCs

```
ADO $ dn_or_len optkey CDI $ Y
```

CDU

IBN

```
ADO $ dn_or_len CDU $ Y
```

ISDNKSET, KEYSET LCCs

```
ADO $ dn_or_len optkey CDU $ Y
```

CFB

IBN

if cfb_ctrl = F or N

```
ado $ dn_or_len CFB cfb_ctrl fwd_dn $ Y
```

if cfb_ctrl = P

```
ado $ dn_or_len CFB cfb_ctrl  $ Y
```

if cfb_ctrl = K

```
ado $ dn_or_len CFB cfb_ctrl [ keylist ]0..n $ Y
```

ISDNKSET, M5312

if cfb_ctrl = F or N

```
ado $ dn_or_len optkey CFB cfb_ctrl fwd_dn [ keylist ]0..n $ Y
```

if cfb_ctrl = P

```
ado $ dn_or_len optkey CFB cfb_ctrl [ keylist ]0..n $ Y
```

if cfb_ctrl = K

```
ado $ dn_or_len optkey CFB cfb_ctrl [ keylist ]0..n $ Y
```

where default value of cfb_ctrl=N

CFBL

1FR, 1MR, PBX, PBM, ZMZPA

```
ado $ dn_or_len CFBL cfbl_cntl screen_class num_ring  fwd_dn $ Y
```

if cfbl_cntl = C fwd_dn is optional

CFD

IBN

if cfb_ctrl = F or N

```
ado $ dn_or_len CFD cfb_ctrl cfbdn [ keylist ]0..n  $ Y
```

if cfb_ctrl = P or K

```
ado $ dn_or_len CFD cfb_ctrl [ keylist ]0..n  $ Y
```

ISDNKSET, M5312

if cfb_ctrl = F or N

```
ado $ dn_or_len optkey CFD cfb_ctrl cfbdn [ keylist ]0..n $ Y
```

if cfb_ctrl = P or K

```
ado $ dn_or_len optkey CFD cfb_ctrl [ keylist ]0..n $ Y
```

where default value of cfb_ctrl=N

CFDA

1FR, 1MR, PBX, PBM, ZMZPA

if cfdb_ctrl = N, F

```
ado $ dn_or_len CFDA cfdb_ctrl screen_class num_ctrl time ring_ctrl
fwd_dn $ Y
```

where default value of cfdb_ctrl=N

if cfdb_ctrl = C

```
ado $ dn_or_len CFDA cfdb_ctrl screen_class num_ctrl time ring_ctrl $ Y
```

CFGD

IBN

```
ado $ dn_or_len CFGD internal <fwd_dn> spectime <timeout> cfttype $ Y
```

If internal = N, fwd_dn parameter is used.

If spectime = Y, timeout parameter is used.

M5312

```
ado $ dn_or_len optkey CFGD internal <fwd_dn> spectime <timeout>
cfttype $ Y
```

If internal = N, fwd_dn parameter is used.

If spectime = Y, timeout parameter is used.

CFGDA

1FR, 1MR, PBX, ZMZPA

If internal=N

```
ado $ dn_or_len CFGDA screen_class num_ctrl time internal fwd_dn $ Y
```

If internal=Y

```
ado $ dn_or_len CFGDA screen_class num_ctrl time internal $ Y
```

CFDVT

IBN

```
ado $ dn_or_len CFDVT time ring_ctrl $ Y
```

M5312

```
ado $ dn_or_len optkey CFDVT time ring_ctrl $ Y
```

CFRA

IBN

```
ado $ dn_or_len CFRA pin change_prompt_pin $ Y
```

where prompt_pin is optional

M5312

```
ado $ dn_or_len optkey CFRA pin change_prompt_pin $
```

where prompt_pin is optional

CFI

IBN

```
ado $ dn_or_len CFI $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CFI [ keylist ]0..n $ Y
```

CFF

IBN

```
ado $ dn_or_len CFF cffdn option $ Y
```

CFMDN

IBN

```
ado $ dn_or_len CFMDN $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CFMDN  $ Y
```

CFS

IBN

```
ado $ dn_or_len optkey CFS simult ncfuif ncfb ncfd screen cfxncos $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CFS simult ncfuif ncfb ncfd screen cfxncos $ Y
```

CFU

IBN

```
ado $ dn_or_len CFU override_acc $ Y
```

M5312

```
ado $ dn_or_len optkey CFU override_acc [ keylist ]0..n  $ Y
```

CFW

1FR, 1MR, PBX, PBM, ZMZPA

cfw_type=F,C, U (call forward auto, call forward fixed and remote call forward)

```
ado $ dn_or_len CFW cfw_type screen_class (num_ring) (cfw_state cfdn)
$ Y
```

where num_ring is optional

where cfw_state = A or I or $, default is $

If cfw_type=C

```
ado $ dn_or_len CFW cfw_type screen_class num_ring  $ Y
```

If cfw_type=F

```
ado $ dn_or_len CFW cfw_type screen_class num_ring  cfw_state cfdn $ Y
```

If cfw_type=U

```
ado $ dn_or_len CFW cfw_type screen_class $ Y
```

CIF

KEYSET LCCs

```
ado $ dn_or_len optkey CIF acdgroup $ Y
```

CHD

IBN

```
ado $ dn_or_len CHD $ Y
```

CIR

1FR, 1MR, IBN, PBX

```
ado $ dn_or_len CIR $ Y
```

M5312

```
ado $ dn_or_len optkey CIR $ Y
```

CLF

1FR, 1MR, IBN, INW, OWT, ZMZPA

```
ado $ dn_or_len CLF $ Y
```

CLI

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, ZMZPA

```
ado $ dn_or_len CLI $ Y
```

M5312

```
ado $ dn_or_len optkey CLI $ Y
```

CNAB

IBN

```
ado $ dn_or_len CNAB $ Y
```

CNAMD

IBN

```
ado $ dn_or_len CNAMD billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

ISDNKSET

```
ado $ dn_or_len optkey CNAMD billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

CND

IBN

If billing option enabled

```
ado $ dn_or_len CND billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

if billing option disabled

```
ado $ dn_or_len CND $ Y
```

ISDNKSET

If billing option enabled

```
ado $ dn_or_len optkey CND billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

if billing option disabled

```
ado $ dn_or_len optkey CND $ Y
```

CNDB

IBN

```
ado $ dn_or_len CNDB billing_option  $ Y
```

where billing_option = AMA or NOAMA or $, default is $

M5312

```
ado $ dn_or_len optkey CNDB billing_option  $ Y
```

where billing_option = AMA or NOAMA or $, default is $

CNF

IBN

```
ado $ dn_or_len CNF conf_type  $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CNF conf_type $ Y
```

COD

1FR, 1MR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA

```
ado $ dn_or_len COD $ Y
```

COT

IBN

if billing option enabled

```
ado $ dn_or_len COT billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

if billing option disabled

```
ado $ dn_or_len COT $ Y
```

M5312, ISDNKSET

if billing option enabled

```
ado $ dn_or_len optkey COT billing_option [keylist]0..n $ Y
```

if billing option disabled

```
ado $ dn_or_len optkey COT [keylist]0..n $ Y
```

CPU

IBN

```
ado $ dn_or_len CPU cpu_len  $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CPU cpu_len $ Y
```

CSMI

1FR, 1MR, IBN

```
ADO $ <npa><nxx><line> CSMI  <csmistate> <csmippu> <connec3w>
<scractive> <scrdur>  $ Y
```

M5312

```
ADO $ <npa><nxx><line> <optkey> CSMI  <csmistate> <csmippu> <connec3w>
<scractive> <scrdur> [<denyopt>]0..k $ $ Y
```

CUSD

1FR, 1MR, PBM, PBX, ZMZPA

```
ado $ dn_or_len CUSD $ Y
```

CWD

IBN

```
ado $ dn_or_len CWD $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CWD $ Y
```

CWI

IBN

```
ado $ dn_or_len CWI $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CWI $ Y
```

CWO

IBN

```
ado $ dn_or_len CWO $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CWO $ Y
```

CWT

1FR, 1MR, CDF, IBN, ZMZPA

```
ado $ dn_or_len CWT $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey CWT cwt_option ring pcwt [ keylist ]0..n $ $ Y
```

CWX

IBN

```
ado $ dn_or_len CWX $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey CWX $ Y
```

CXR

IBN

```
ado $ dn_or_len CXR cxr_type originter orgintra terminter termintra
cxr_recall recall_time method $ Y
```

where originter, orgintra, terminter, termintra, and recall_time are optional

M5312

```
ado $ dn_or_len optkey CXR cxr_type originter orgintra terminter
termintra cxr_recall recall_time method $ Y
```

DCF

IBN

```
ado $ dn_or_len DCF $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey DCF $ Y
```

DCPU

IBN

```
ado $ dn_or_len DCPU $ Y
```

DDN

IBN

```
ado $ dn_or_len DDN billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

DENY

1FR, 1MR

```
ado $ dn_or_len DENY [denyopt]1..n $ $ Y
```

DENYAR

1FR, 1MR, CDF, ZMZPA

```
ado $ dn_or_len DENY DENYAR $ $ Y
```

DENYCOT

1FR, 1MR, CDF, ZMZPA

```
ado $ dn_or_len DENY DENYCOT $ $ Y
```

DENYACB

1FR, 1MR, CDF, ZMZPA

```
ado $ dn_or_len DENY DENYACB $ $ Y
```

DENYU3WC

1FR, 1MR, CDF, ZMZPA

```
ado $ dn_or_len DENYU3WC $ Y
```

DENYISA

IBN

```
ADO $ dn_or_len DENYISA $ Y
```

ISDNKET

```
ADO $ dn_or_len optkey DENYISA $ Y
```

DENYCSMI

1FR,1MR, IBN

```
ADO $ dn_or_len DENYCSMI [<denyopt>]0..k $ $ Y
```

DGT

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA

```
ado $ dn_or_len DGT $ Y
```

DIN

IBN

```
ado $ dn_or_len DIN trc alttrc dinopt $ Y
```

M5312

```
ado $ dn_or_len optkey DIN trc alttrc dinopt $ Y
```

Note: trc and alttrc parameter value is default $ if they are not provided.

DISP

KEYSET LCCs

```
ado $ dn_or_len optkey DISP $ Y
```

DNH

1FR, 1MR, IBN, INW, OWT, PBX, PBM

```
ado $ dn_or_len DNH link_dn groupsize $ Y
```

M5312, ISDNKSET

```
ado $ dn_or_len optkey DNH link_dn groupsize $ Y
```

DOR

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
ado $ dn_or_len DOR $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey DOR $ Y
```

DQS

KEYSET LCCs

```
ado $ dn_or_len optkey DQS acdgroup $ Y
```

DQT

KEYSET LCCs

```
ado $ dn_or_len optkey DQT diffgrp $ Y
```

DRCW

IBN

```
ado $ dn_or_len DRCW billing_option status [ dns vbcount ]0...n $ $ Y
```

DRING

IBN

```
ado $ dn_or_len DRING intrnl dringtyp extrnl dringtyp trks gic dringtyp
recall dringtyp ucd dringtyp rest dringtyp acd dringtyp makecall
dringtyp $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey DRING intrnl dringtyp extrnl dringtyp trks gic
dringtyp recall dringtyp ucd dringtyp rest dringtyp acd dringtyp
makecall dringtyp $ Y
```

Parameter dringtype is optional but whenever intrnl, extrnl, gic, recall, ucd, rest, acd or makecall is set to 'Y' user should provide value for corresponding dringtype.

DSCWID

1FR, 1MR, IBN

```
ado $ dn_or_len DSCWID [ dsubopt dtypeopt default_value damaopt  ]0..2
$ $ Y
```

OR

```
ado $ dn_or_len DSCWID [ dsubopt dtypeopt default_value damaopt  ]3 $ Y
```

where dtypeopt is, default_value and damaopt are optional, only required if dsubopt is defined

DTM

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
ado $ dn_or_len DTM $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey DTM $
```

ELN

1FR, 1MR, CDF, IBN, OWT, PBX, PBM, ZMZPA

```
ado $ dn_or_len ELN $ Y
```

M5312

```
ado $ dn_or_len optkey ELN $ Y
```

EMW

IBN

```
ado $ dn_or_len EMW notice [mcos]0.n  [dnlist]o.n $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey EMW notice [mcos]0.n  [dnlist]o.n $ Y
```

ESL

1FR

```
ado $ dn_or_len ESL roh_tone_time integ_tone intergrity_tone_time
switchhook_tone fastslash ringback forced_disconnect_time $ Y
```

FAA

KEYSET LCCs

```
ado $ dn_or_len optkey FAA extndfaa acdgroup $ Y
```

FANI

1FR, 1MR, 2FR, 4FR, CDF, INW, OWT, PBX, PBM, ZMZPA

```
ado $ dn_or_len FANI digits $ Y
```

FTRGRP

IBN

```
ADO $ dn_or_len FTRGRP grpname $ Y
```

ISDNKSET, KEYSET LCCs

```
ADO $ dn_or_len optkey FTRGRP grpname $ Y
```

GIC

IBN

```
ado $ dn_or_len GIC gicname gicmemno gicsmdr gicnomsb $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey GIC gicname gicmemno gicsmdr gicnomsb $ Y
```

GND

1FR, 1MR, CDF, IBN , INW, OWT, PBM, PBX, ZMZPA

```
ADO $ dn_or_len GND $ Y
```

HOT

1FR, 1MR, IBN, PBX, PBM, ZMZPA

```
ADO $ dn_or_len HOT $ Y
```

ICM

KEYSET LCCs

```
ado $ dn_or_len optkey ICM link_len sic_key dor smdr $ Y
```

INSPECT

KEYSET LCCs

```
ado $ dn_or_len optkey INSPECT $ Y
```

INT

1FR, 1MR, 4FR, IBN

```
ado $ dn_or_len INT $ Y
```

INTPIC

1FR, 1MR, IBN

```
ado $ dn_or_len INTPIC carrier choice $ Y
```

KEYSET LCCs

```
ado $ dn_or_len  optkey INTPIC carrier choice $ Y
```

KSH

KEYSET LCCs

If OVTYPE=D

```
ado $ dn_or_len optkey KSH ovtype ovdn tabid
```

If OVTYPE=R

```
ado $ dn_or_len optkey KSH ovtype tabid key [keylist] 0...n $ $ Y
```

If OVTYPE=N

```
ado $ dn_or_len optkey KSH ovtype tabid
```

LCDR

1FR, 1MR, 4FR, IBN

```
ado $ dn_or_len LCDR $ Y
```

M5312

```
ado $ dn_or_len optkey LCDR $ Y
```

LDSA

1FR, 1MR, ZMZPA

```
ADO $ dn_or_len LDSA  $ Y
```

LDSO

1FR, 1MR, ZMZPA

```
ADO $ dn_or_len LDSO $ Y
```

LNR

IBN

```
ado $ dn_or_len LNR $ Y
```

M5312

```
ado $ dn_or_len optkey LNR $ Y
```

LNRA

KEYSET LCCs

```
ado $ dn_or_len optkey LNRA $ Y
```

LOB

KEYSET LCCs

```
ado $ dn_or_len optkey LOB $ Y
```

LOD

1FR, 1MR, IBN, INW, PBM, PBX

```
ado $ dn_or_len LOD loddn $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey LOD loddn $ Y
```

LPIC

1FR, 1MR, 4FR, IBN

```
ado $ dn_or_len LPIC carrier choice $ Y
```

M5312

```
ado $ dn_or_len optkey LPIC carrier choice $ Y
```

LVM

KEYSET LCCs

```
ado $ dn_or_len optkey LVM $ Y
```

M518

KEYSET LCCs

```
ado $ dn_or_len optkey M518 quantity $ Y
```

M536

KEYSET LCCs

```
ado $ dn_or_len optkey M536 $ Y
```

MDN

IBN

```
ado $ dn_or_len MDN mdntype primary ring dir_number $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey MDN mdntype primary ring dir_number $ Y
```

MSB

IBN

```
ado $ dn_or_len MSB $ Y
```

M5312

```
ado $ dn_or_len optkey MSB $ Y
```

MSBI

IBN

```
ado $ dn_or_len MSBI $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey MSBI $ Y
```

MWT

IBN

notice=CMWI

```
ado $ dn_or_len MWT notice act_stuttered_dt act_ring_burst status
cr_option cr_call_fwd cr_req $ Y
```

notice=PRN

```
ado $ dn_or_len MWT notice irn status cr_option cr_call_fwd cr_req $ Y
```

notice=STD

```
ado $ dn_or_len MWT notice cr_option cr_call_fwd cr_req $ Y
```

cr_call_fwd is required when cr_option = Y

ISDNKSET, M5312

```
ado $ dn_or_len optkey MWT cr_option cr_call_fwd cr_req $ Y
```

NAME

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
ADO $ dn_or_len NAME <netname> <displayname> $ $ Y
```

ISDNKSET, KEYSET LCCs

```
ADO $ dn_or_len <optkey> NAME <netname> <displayname> $ $ Y
```

NDC

IBN

```
ado $ dn_or_len NDC $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey NDC $ Y
```

NFA

M5312

```
ADO $ dn_or_len <optkey> NFA <user_id> <impct_acc> <explct_acc>
<ama_explct> <ama_ipdial> <rem_acc> <ama_rem> <nfra_pin> $ Y
```

If REM_ACC='Y'

```
ADO $ dn_or_len <optkey> NFA <user_id> <impct_acc> <explct_acc>
<ama_explct><ama_ipdial> <rem_acc> <ama_rem> <nfra_pin> $ Y
```

else

```
ADO $ dn_or_len <optkey> NFA <user_id> <impct_acc> <explct_acc>
<ama_explct><ama_ipdial> <rem_acc> <ama_rem> $ Y
```

Note: impct_acc and explct_acc default value is 'Y', ama_explct, ama_ipdial, rem_acc, ama_rem default value is 'N'.

NGTSRVCE

KEYSET LCCs

```
ado $ dn_or_len optkey NGTSRVCE  acdgroup $ Y
```

NLT

1FR,IBN

```
ado $ dn_or_len NLT $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey NLT $ Y
```

OBS

IBN

If OBSTYPE=BASIC

```
ado $ dn_or_len OBS obstype acdgroup $ Y
```

if OBSTYPE=EXTENDED

```
ado $ dn_or_len OBS obstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=GROUP

```
ado $ dn_or_len OBS obstype fobs_acdgroup fobstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=SUBGROUP

```
ado $ dn_or_len OBS obstype fobs_acdgroup fobstype fobs_subgroup  $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=DN

```
ado $ dn_or_len OBS obstype fobs_acdgroup fobstype dn $ Y
```

KEYSET LCCs

If OBSTYPE=BASIC

```
ado $ dn_or_len optkey OBS obstype acdgroup $ Y
```

if OBSTYPE=EXTENDED

```
ado $ dn_or_len optkey OBS obstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=GROUP

```
ado $ dn_or_len OBS obstype fobs_acdgroup fobstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=SUBGROUP

```
ado $ dn_or_len OBS obstype fobs_acdgroup fobstype fobs_subgroup  $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=DN

```
ado $ dn_or_len OBS obstype fobs_acdgroup fobstype dn $ Y
```

ONI

1FR, 1MR, 2FR, 4FR, CDF, IBN, OWT, PBM, PBX

```
ADO $ dn_or_len  ONI $ Y
```

ISDNKSET

```
ADO $ dn_or_len optkey ONI $ Y
```

PIC

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA

```
ado $ dn_or_len PIC carrier choice $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey PIC carrier choice $ Y
```

PORT

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA

```
ado $ dn_or_len PORT $ Y
```

ISDNKSET

```
ado $ dn_or_len optkey PORT $ Y
```

PRK

IBN

```
ado $ dn_or_len PRK $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey PRK $ Y
```

PRL

KEYSET LCCs

```
ado $ dn_or_len optkey PRL $ Y
```

QTD

KEYSET LCCs

```
ado $ dn_or_len optkey QTD $ Y
```

RAG

IBN

```
ado $ dn_or_len RAG $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey RAG $ Y
```

RCHD

1FR, 1MR

```
ado $ dn_or_len RCHD $ Y
```

RMT

1FR, 1MR,

```
ado $ dn_or_len RMT $ Y
```

RMR

1FR, 1MR

```
ado $ dn_or_len RMR $ Y
```

RPA

KEYSET LCCs

```
ado $ dn_or_len optkey RPA $ Y
```

RSP

1FR, 1MR, CDF, IBN, OWT, PBX, PBM, ZMZPA

```
ado $ dn_or_len RSP $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey RSP $ Y
```

RMI

1FR,1MR

```
ADO $ dn_or_len RMI  <rmi_state> $ Y
```

ISDNKSET

```
ADO $ dn_or_len optkey RMI  <rmi_state> $ Y
```

RSUS

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
ado $ dn_or_len RSUS orig_sus term_sus $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey RSUS orig_sus term_sus $ Y
```

SACB

IBN

```
ado $ dn_or_len SACB status class_type pin suspend $ Y
```

M5312

```
ado $ dn_or_len optkey SACB status class_type pin suspend $ Y
```

SCA

IBN

```
ado $ dn_or_len SCA billing_option status [dns vbcount ]0...n $ $ Y
```

where billing_option = AMA or NOAMA or $, default is $

M5312

```
ado $ dn_or_len optkey SCA billing_option status [dns vbcount ] 0...n $
$ Y
```

where billing_option = AMA or NOAMA or $, default is $

SCF

IBN

```
ado $ dn_or_len SCF billing_option status [dns vbcount ] 0...n $ fwd_dn
scrncl num_call ring_rem $ Y
```

where billing_option = AMA or NOAMA or $, default is $

where scrncl is optional

M5312

```
ado $ dn_or_len optkey SCF billing_option status [dns vbcount ] 0...n $
fwd_dn scrncl num_call ring_rem $ Y
```

where billing_option = AMA or NOAMA or $, default is $

where scrncl is optional

SCL

Non-hunt group:

IBN

```
ado $ dn_or_len SCL list_type $ Y
```

M5312

```
ado $ dn_or_len optkey SCL list_type $ Y
```

Hunt group:

IBN

```
ado $ dn_or_len SCL list_type [ keylist ]0..n $ $ Y
```

M5312

```
ado $ dn_or_len optkey SCL list_type [ keylist ]0..n $ $ Y
```

SCS

IBN

```
ado $ dn_or_len SCS $ Y
```

M5312

```
ado $ dn_or_len optkey SCS $ Y
```

SC1

1FR, 1MR, 2FR, CDF, OWT, ZMZPA

```
ado $ dn_or_len SC1 $ Y
```

SC2

1FR, 1MR, 2FR, CDF, OWT, ZMZPA

```
ado $ dn_or_len SC2 $ Y
```

SCRJ

IBN

```
ado $ dn_or_len SCRJ billing_option status [dns vbcount ] 0...n $ $ Y
```

where billing_option = AMA or NOAMA or $, default is $

ISDNKSET, M5312

```
ado $ dn_or_len optkey SCRJ billing_option status [dns vbcount ] 0...n
$ $ Y
```

where billing_option = AMA or NOAMA or $, default is $

SCU

IBN

```
ado $ dn_or_len SCU scugnumber scu_tdn $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey SCU scugnumber scu_tdn $ Y
```

SCWID

IBN

```
ado $ dn_or_len SCWID $ Y
```

SDN

1FR, 1MR, IBN

```
ado $ dn_or_len SDN sdn ring_type sdn_option sdn_deny $ Y
```

where sdn_deny = NODNY or DNYCWT or $

if sdn_deny is NODNY or DNYCWT then one more $ is added afeter the sdn_deny value.

SDSDENY

IBN

```
ado $ dn_or_len SDSDENY $ Y
```

M5312

```
ado $ dn_or_len optkey SDSDENY $ Y
```

SHU

IBN

```
ado $ dn_or_len SHU sc tmno tmcktno point normal_state $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey SHU sc tmno tmcktno point normal_state $ Y
```

SL

IBN

```
ado $ dn_or_len SL $ Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey SL $ Y
```

SMDR

IBN

```
ado $ dn_or_len SMDR $ Y
```

KEYSET LCCs

```
ado $ dn_or_len optkey SMDR $ Y
```

SPB

1FR, 1MR, 2FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
ADO $ dn_or_len SPB spb_dn $ Y
```

ISDNKSET, KEYSET LCCs

```
ADO $ dn_or_len <optkey> SPB spb_dn $ Y
```

SRA

1FR,1MR, 4FR,CDF, INW, OWT,IBN, ZMZPA

```
ADO $ dn_or_len SRA  $ Y
```

SSAC

IBN

```
ADO $ dn_or_len  SSAC [authcode] 0..n $ Y
```

KEYSET LCCs

```
ADO $ dn_or_len optkey SSAC [authcode] 0..n  $ Y
```

SUPR

IBN

```
ADO $ dn_or_len  SUPR primary_acdgroup primary_acdsgrp idnum $ Y
```

KEYSET LCCs

```
ADO $ dn_or_len optkey SUPR primary_acdgroup primary_acdsgrp idnum $ Y
```

SUPPRESS

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA

```
ado $ dn_or_len SUPPRESS [ netname suppress_dn suppress_name ]0..n $ $
Y
```

ISDNKSET, M5312

```
ado $ dn_or_len optkey SUPPRESS [ netname suppress_dn suppress_name
]0..n $ $ Y
```

SCVGRP

IBN

```
ADO $ dn_or_len  SVCGRP grpname $ Y
```

KEYSET LCCs

```
ADO $ dn_or_len optkey SVCGRP grpname $ Y
```

TCW

1FR, 1MR

```
ado $ dn_or_len TCW $ Y
```

TDN

1FR, 1MR, 2FR

```
ado $ dn_or_len TDN $ Y
```

TFO

1FR, 1MR, 2FR, IBN, M5312, ISDNKSET

```
ado $ dn_or_len optkey TFO $ Y
```

UCD

IBN

```
ado $ dn_or_len UCD $ Y
```

M5312

```
ado $ dn_or_len optkey UCD $ Y
```

VMEADENY

1FR, 2FR

```
ADO $ dn_or_len VMEADENY $ Y
```

ISDNKSET

```
ADO $ dn_or_len optkey VMEADENY $ Y
```

VMEADN

1FR

```
ADO $ dn_or_len VMEADN vmeadn_vm_dn or <vmeadn_vm_npa><vmeadn_vm_nxx>
<vmeadn_vm_line> $ Y
```

ISDNKSET

```
ADO $ dn_or_len optkey VMEADN vmeadn_vm_dn or
<vmeadn_vm_npa><vmeadn_vm_nxx> <vmeadn_vm_line> $ Y
```

WML

1FR, 1MR, IBN

```
ado $ dn_or_len WML cust_mod_dn act_option wml_dn timeout ftcode $ Y
```

where ftcode is optional

M5312

```
ado $ dn_or_len optkey WML cust_mod_dn act_option wml_dn timeout
ftcode $ Y
```

where ftcode is optional

WUC

IBN

```
ado $ dn_or_len WUC $ Y
```

M5312

```
ado $ dn_or_len optkey WUC $ Y
```

WUCR

1FR, 1MR

```
ado $ dn_or_len WUCR $ Y
```

where dn_or_len = dn or len

Remove features

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
deo $ dn_or_len [ option ]1..n $ Y
```

M5312, ISDNKSET, KEYSET LCCs

```
deo $ dn_or_len [ optkey option ]1..n $ Y
```

SDN

1FR, 1MR, IBN

```
deo $ dn_or_len SDN sdn $ Y
```

where dn_or_len = dn or len

DENY

1FR, 1MR, IBN

deo $ dn_or_len DENY [denyopt]1..n $ $ Y

Change features

ACD

IBN

```
chf $ dn_or_len ACD acdgroup acdsgrp  idnum posid  ibn_acd_option0.n
scai_link $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey ACD  acdgroup acdsgrp  idnum posid
ibn_acd_option0.n scai_link $ Y
```

If ibn_acd_option = 'SCAILINK'

```
scai_link = 'SCAIDEF' or 1-8 alphanumeric
```

If ibn_acd_option = 'ACDNR'

```
scai_link = ''
```

AIN

1FR, 1MR, IBN

```
chf $ dn_or_len AIN aingrp Y
```

M5000

```
chf $ dn_or_len optkey AIN aingrp [ keylist ]0..n  $ Y
```

AINDN

1FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

if aingrp != "TIID"

```
chf $ dn_or_len AINDN aingrp $ Y
```

if aingrp = "TIID"

```
chf $ dn_or_len AINDN aingrp tdp tiname trigger $ Y
```

M5312, ISDNKSET

if aingrp != "TIID"

```
chf $ dn_or_len optkey AINDN aingrp $ Y
```

if aingrp = "TIID"

```
chf $ dn_or_len optkey AINDN aingrp tdp tiname trigger $ Y
```

ASL

KEYSET LCCs

```
chf $ dn_or_len optkey ASL  agent_len  msbovrd  aslsdn $ Y
```

AUD

KEYSET LCCs

```
chf $ dn_or_len optkey AUD  pgmaud  audfeat $ Y
```

AUL

1FR, 1MR, IBN

```
chf $ dn_or_len AUL aul_dn $ Y
```

ISDNKSET, M5312

```
chf $ dn_or_len optkey AUL aul_dn $ Y
```

AUTODISP

KEYSET LCCs

```
chf $ dn_or_len optkey AUTODISP  cwt  [ keylist ]0..n $ Y
```

CFB

IBN

if cfb_ctrl = F or N

```
chf $ dn_or_len CFB cfb_ctrl fwd_dn  $ Y
```

if cfb_ctrl = P

```
chf $ dn_or_len CFB cfb_ctrl $ Y
```

if cfb_ctrl = K

```
chf $ dn_or_len CFB cfb_ctrl [ keylist ]0..n $ Y
```

ISDNKSET, M5312

if cfb_ctrl = F or N

```
chf $ dn_or_len optkey CFB cfb_ctrl fwd_dn [ keylist ] 0..n $ Y
```

if cfb_ctrl = P

```
chf $ dn_or_len optkey CFB cfb_ctrl [ keylist ] 0..n $ Y
```

if cfb_ctrl = K

```
chf $ dn_or_len optkey CFB cfb_ctrl [ keylist ]0..n $ Y
```

where default value of cfb_ctrl=N

CFD

IBN

if cfb_ctrl = F or N

```
chf $ dn_or_len CFD cfb_ctrl cfbdn [ keylist ]0..n  $ Y
```

if cfb_ctrl = P or K

```
chf $ dn_or_len CFD cfb_ctrl [ keylist ]0..n  $ Y
```

ISDNKSET, M5312

if cfb_ctrl = F or N

```
chf $ dn_or_len optkey CFD cfb_ctrl cfbdn [ keylist ]0..n $ Y
```

if cfb_ctrl = P or K

```
chf $ dn_or_len optkey CFD cfb_ctrl [ keylist ]0..n $ Y
```

where default value of cfb_ctrl=N

CFBL

1FR, 1MR, PBX, PBM, ZMZPA

```
chf $ dn_or_len CFBL cfbl_cntl screen_class num_ring  fwd_dn $ Y
```

CFDA

1FR, 1MR, PBX, PBM, ZMZPA

```
chf $ dn_or_len CFDA cfdb_ctrl screen_class num_ctrl time ring_ctrl
fwd_dn $ Y
```

where default value of cfdb_ctrl=N

CFDVT

IBN

```
chf $ dn_or_len CFDVT time ring_ctrl $ Y
```

M5312

```
chf $ dn_or_len optkey CFDVT time ring_ctrl $ Y
```

CFF

IBN

```
chf $ dn_or_len CFF cffdn option $ Y
```

CFS

IBN

```
chf $ dn_or_len optkey CFS simult ncfuif ncfb ncfd screen cfxncos $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey CFS simult ncfuif ncfb ncfd screen cfxncos $ Y
```

CFU

IBN

```
chf $ dn_or_len CFU override_acc $ Y
```

M5312

```
chf $ dn_or_len optkey CFU override_acc [ keylist ]0..n  $ Y
```

CFW

1FR, 1MR, PBX, PBM, ZMZPA

cfw_type=F,C, U (call forward auto, call forward fixed and remote call forward)

```
chf $ dn_or_len CFW cfw_type screen_class (num_ring) (cfw_state cfdn)
$ Y
```

where num_ring is optional

where cfw_state = A or I or $, default is $

If cfw_type=C

```
chf $ dn_or_len CFW cfw_type screen_class num_ring cfw_state cfdn $ Y
```

If cfw_type=F

```
chf $ dn_or_len CFW cfw_type screen_class num_ring  cfw_state cfdn $ Y
```

If cfw_type=U

```
chf $ dn_or_len CFW cfw_type screen_class $ Y
```

CIF

KEYSET LCCs

```
chf $ dn_or_len optkey CIF acdgroup $ Y
```

CNAMD

IBN

```
chf $ dn_or_len CNAMD billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

ISDNKSET

```
chf $ dn_or_len optkey CNAMD billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

CND

IBN

If billing option enabled

```
chf $ dn_or_len CND billing_option $ Y
```

where billing_option = AMA or NOAMA or $, default is $

if billing option disabled

```
chf $ dn_or_len CND $ Y
```

CNF

IBN

```
chf $ dn_or_len CNF conf_type  $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey CNF conf_type $ Y
```

CPU

IBN

```
chf $ dn_or_len CPU cpu_len  $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey CPU cpu_len $ Y
```

CSMI

1FR,1MR, IBN

```
CHF $ <npa><nxx><line> CSMI  <csmistate> <csmippu> <connec3w>
<scractive> <scrdur>  $ Y
```

M5312

```
CHF $ <npa><nxx><line> <optkey> CSMI  <csmistate> <csmippu> <connec3w>
<scractive> <scrdur> <denyopt> $ Y
```

CWT

1FR, 1MR, CDF, IBN, ZMZPA

```
chf $ dn_or_len CWT $ Y
```

ISDNKSET, M5312

```
chf $ dn_or_len optkey CWT cwt_option ring pcwt [ keylist ]0..n $ $ Y
```

CXR

IBN

```
chf $ dn_or_len CXR cxr_type originter orgintra terminter termintra
cxr_recall recall_time method $ Y
```

where originter, orgintra, terminter, termintra, and recall_time are optional

M5312

```
chf $ dn_or_len optkey CXR cxr_type originter orgintra terminter
termintra cxr_recall recall_time method $ Y
```

DIN

IBN

```
chf $ dn_or_len DIN trc alttrc dinopt $ Y
```

M5312

```
chf $ dn_or_len optkey DIN trc alttrc dinopt $ Y
```

Note: trc and alttrc parameter value is default $ if they are not provided.

DQS

KEYSET LCCs

```
chf $ dn_or_len optkey DQS acdgroup $ Y
```

DQT

KEYSET LCCs

```
chf $ dn_or_len optkey DQT diffgrp $ Y
```

DRING

IBN

```
chf $ dn_or_len DRING intrnl dringtyp extrnl dringtyp trks gic dringtyp
recall dringtyp ucd dringtyp rest dringtyp acd dringtyp makecall
dringtyp $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey DRING intrnl dringtyp extrnl dringtyp trks gic
dringtyp recall dringtyp ucd dringtyp rest dringtyp acd dringtyp
makecall dringtyp $ Y
```

Parameter dringtype is optional but whenever intrnl, extrnl, gic, recall, ucd, rest, acd or makecall is set to 'Y' user should provide value for corresponding dringtype.

EMW

IBN

```
chf $ dn_or_len EMW notice [mcos]0.n  [dnlist]o.n  $ $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey EMW notice [mcos]0.n  [dnlist]o.n $ $ Y
```

ESL

1FR

```
chf $ dn_or_len ESL roh_tone_time integ_tone intergrity_tone_time
switchhook_tone fastslash ringback forced_disconnect_time $ Y
```

FAA

KEYSET LCCs

```
chf $ dn_or_len optkey FAA extndfaa acdgroup $ Y
```

FTRGRP

IBN

```
CHF $ dn_or_len FTRGRP grpname $ Y
```

ISDNKSET, KEYSET LCCs

```
CHF $ dn_or_len optkey FTRGRP grpname $ Y
```

GIC

IBN

```
chf $ dn_or_len GIC gicname gicmemno gicsmdr gicnomsb $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey GIC gicname gicmemno gicsmdr gicnomsb $ Y
```

ICM

KEYSET LCCs

```
chf $ dn_or_len optkey ICM link_len sic_key dor smdr $ Y
```

INTPIC

1FR, 1MR, IBN

```
chf $ dn_or_len INTPIC carrier choice $ Y
```

KEYSET LCCs

```
chf $ dn_or_len  optkey INTPIC carrier choice $ Y
```

KSH

KEYSET LCCs

If OVTYPE=D

```
chf $ dn_or_len optkey KSH ovtype ovdn tabid
```

If OVTYPE=R

```
chf $ dn_or_len optkey KSH ovtype tabid key [keylist] 0...n $ $ Y
```

If OVTYPE=N

```
chf $ dn_or_len optkey KSH ovtype tabid
```

LPIC

1FR, 1MR, 4FR, IBN

```
chf $ dn_or_len LPIC carrier choice $ Y
```

M5312

```
chf $ dn_or_len optkey LPIC carrier lchoice $ Y
```

OBS

IBN

If OBSTYPE=BASIC

```
chf $ dn_or_len OBS obstype acdgroup $ Y
```

if OBSTYPE=EXTENDED

```
chf $ dn_or_len OBS obstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=GROUP

```
chf $ dn_or_len OBS obstype fobs_acdgroup fobstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=SUBGROUP

```
chf $ dn_or_len OBS obstype fobs_acdgroup fobstype fobs_subgroup  $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=DN

```
chf $ dn_or_len OBS obstype fobs_acdgroup fobstype dn $ Y
```

KEYSET LCCs

If OBSTYPE=BASIC

```
chf $ dn_or_len optkey OBS obstype acdgroup $ Y
```

if OBSTYPE=EXTENDED

```
chf $ dn_or_len optkey OBS obstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=GROUP

```
chf $ dn_or_len OBS obstype fobs_acdgroup fobstype $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=SUBGROUP

```
chf $ dn_or_len OBS obstype fobs_acdgroup fobstype fobs_subgroup  $ Y
```

if OBSTYPE=FOBS and FOBSTYPE=DN

```
chf $ dn_or_len OBS obstype fobs_acdgroup fobstype dn $ Y
```

MDN

IBN

```
chf $ dn_or_len MDN mdntype primary ring dir_number $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey MDN mdntype primary ring dir_number $ Y
```

NAME

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
CHF $ dn_or_len NAME <netname> <displayname> $ $ Y
```

ISDNKSET

```
CHF $ dn_or_len <optkey> NAME <netname> <displayname> $ $ Y
```

PIC

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA

```
chf $ dn_or_len PIC carrier choice $ Y
```

ISDNKSET, M5312

```
chf $ dn_or_len optkey PIC carrier choice $ Y
```

NGTSRVCE

KEYSET LCCs

```
chf $ dn_or_len optkey NGTSRVCE  acdgroup $ Y
```

RMI

1FR,1MR

```
CHF $ dn_or_len RMI  <rmi_state> $ Y
```

ISDNKSET

```
CHF $ dn_or_len optkey RMI  <rmi_state> $ Y
```

SCA

IBN

```
chf $ dn_or_len SCA billing_option status $ Y
```

where billing_option = AMA or NOAMA or $, default is $

M5312

```
chf $ dn_or_len optkey SCA billing_option status $ Y
```

where billing_option = AMA or NOAMA or $, default is $

SDN

1FR, 1MR, IBN

```
chf $ dn_or_len SDN sdn new_sdn ring_type sdn_option sdn_deny $ Y
```

where sdn_deny = NODNY or DNYCWT or $,

if sdn_deny is NODNY or DNYCWT then one more $ is added afeter the sdn_deny value.

where dn_or_len = dn or len

SCRJ

IBN

```
chf $ dn_or_len SCRJ billing_option status [dns vbcount ] 0...n $ $ Y
```

where billing_option = AMA or NOAMA or $, default is $

ISDNKSET, M5312

```
chf $ dn_or_len optkey SCRJ billing_option status [dns vbcount ] 0...n
$ $ Y
```

where billing_option = AMA or NOAMA or $, default is $

SCU

IBN

```
chf $ dn_or_len SCU scugnumber scu_tdn $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey SCU scugnumber scu_tdn $ Y
```

SHU

IBN

```
chf $ dn_or_len SHU sc tmno tmcktno point normal_state $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey SHU sc tmno tmcktno point normal_state $ Y
```

SUPR

IBN

```
chf $ dn_or_len  SUPR primary_acdgroup primary_acdsgrp idnum $ Y
```

KEYSET LCCs

```
chf $ dn_or_len optkey SUPR primary_acdgroup primary_acdsgrp idnum $ Y
```

SCVGRP

IBN

```
CHF $ dn_or_len  SVCGRP grpname $ Y
```

KEYSET LCCs

```
CHF $ dn_or_len optkey SVCGRP grpname $ Y
```

New POTS line

1FR, 1MR, CDF, INW, PBX, PBM, ZMZPA

```
new $ dn lcc lataname ltg len [ option ]0..n $ Y
```

2FR, 4FR

```
new $ dn lcc pty ringcode lataname ltg len [ option ]0..n $ Y
```

OWT

```
new $ dn lcc zone lataname ltg len [ option ]0..n $ Y
```

IBN

```
new $ dn lcc group subgroup ncos <snpa> lataname ltg len [ option ]0..n
$ Y
```

where snpa parameter used when the Length of the DN parameter is 7.

ISDNKSET, M5312, KEYSET LCCs

```
new $ dn lcc group subgroup ncos <snpa> key ringing lataname ltg len [
optkey option ]0..n $ Y
```

where snpa parameter is used when the Length of the DN parameter is 7.

Remove POTS line

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
out $ dn len intercept_name Y
```

Change line parameter

Change DN

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
cdn $ old_dn new_dn intercept_name Y
```

CDN - Virtual DN, vdntype=RCF

```
cdn $ old_dn new_dn intercept_name vdntype fwd_dn max_calls ltg mrsa
blk_toll_com blk_toll_treatment om_index scrncl sigdata Y
```

Change INTERCEPT NAME

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
cicp $ dn intercept_name Y
```

Change Keyset LEN - CKLN

IBN

```
ckln $ len new_len Y
```

Change LCC

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
CHG $ LINE dn_or_len LCC new_lcc lata_name ltg Y
```

Change LEN

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
cln $ len new_len Y
```

Change LTG

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
cltg $ new_ltg dn $ Y
```

Change NCOS

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
CHG $ LINE dn_or_len NCOS new_ncos Y
```

Assign virtual DN

SN06

If vdntype = RCF and block_of_dns = NO

```
newdn $ <snpa> block_of_dns <npa><nxx><line> vdntype fwd_dn max_calls
ltg mrsa blk_toll_com blk_toll_treatment om_index scrncl ofrtindx
latanm prtnm sigdata [ option ]0..n $ Y
```

where snpa, ofrtindx, latanm and prtnm are optional

If vdntype = AIN and block_of_dns= NO and dntype=NONIBN

```
newdn $ <snpa> block_of_dns <npa><nxx><line> vdntype dntype lineattr
NCOS ain_vdn_opt_ncos ain_vdn_opt_smdr $[ option ]0..n $ Y
```

where ain_vdn_opt_ncos ain_vdn_opt_smdr are optional

If vdntype = AIN and block_of_dns= NO and dntype=IBN

```
newdn $ <snpa> block_of_dns <npa><nxx><line> vdntype dntype custgrp
subgrp NCOS ain_vdn_opt_ncos ain_vdn_opt_smdr $[ option ]0..n $ Y
```

where ain_vdn_opt_ncos ain_vdn_opt_smdr are optional

LEC014

```
newdn $ <npa> block_of_dns <nxx><line> vdntype fwd_dn max_calls ltg
mrsa blk_toll_com blk_toll_treatment om_index scrncl ofrtindx latanm
prtnm sigdata [ option ]0..n $ Y
```

where ofrtindx, latanm and prtnm are optional

Remove virtual DN

SN06

if block_of_dns = YES

```
outdn $ snpa YES dn to_dn vdntype pool_out codeholder intercept_name Y
```

where snpa , pool_out and vdntype is optional

Where if pool_out = N then intercept_name

where if pool_out = Y then codeholder

if block_of_dns = NO

```
outdn $ snpa NO dn vdntype pool_out codeholder intercept_name Y
```

where snpa , pool_out, codeholder, intercept_name and vdntype is optional

Where if pool_out = N or not provided then intercept_name

where if pool_out = Y then codeholder

LEC014

if block_of_dns = YES

```
outdn $ <npa> YES <nxx><line> to_dn vdntype intercept_name Y
```

where vdntype is optional

if block_of_dns = NO

```
outdn $ <npa> NO <nxx><line> vdntype intercept_name Y
```

where vdntype is optional

Set Up Logical Terminal (ISDN)

SLT ADD

ISDNKSET

```
SLT $ <ltid> ADD <ltclass> <cs> <ps> <maxkeys> <deflterm> <tei_type>
<tspid> [abs]0..n <ekts> <tei> [FEATURE]0..n $(where $ will appear
only if features added) Y
```

For the above MML, ltid and ltcalss Parameters are Required Parameter type, the other Parameters are Optional Parameter type.

SLT ATT

ISDNKSET

```
SLT $ <ltid> ATT <len> [FEATURE]0..n $ Y
```

SLT CHA

ISDNKSET

```
SLT $ <ltid> CHA [FEATURE]0..n $ Y
```

SLT DET

ISDNKSET

```
SLT $ <ltid> DET Y
```

SLT REM

ISDNKSET

```
SLT $ <ltid> REM Y
```

Set Up DN attributes

1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, ISDNKSET

```
SDNA $ <areacode> <ofccode> <fromdigs> <todigs> <netname> <function>
[FEATURE]0..n <name> $ Y
```

Where name is optional parameter.

Where function = ADD or CHA or DEL

Add Plug Up-Place

```
PLP dn len Y
```

Add Suspend

```
SUS $ dn len Y
```

Add Restore

```
RES $ dn len Y
```

Add Hunt Group

DLH

1FR, 1MR, CDF, PBM, PBX,ZMZPA

```
est $ DLH dn 1FR, 1MR lataname ltg len [ member_len ]0..n $ [ option
]0..n $ groupsize Y
```

2FR,4FR

```
est $ DLH dn 2FR, 4FR pty ringcode lataname ltg len [ member_len ]0..n
$ [ option ]0..n $ groupsize Y
```

ISDNKSET

```
est $ DLH dn ISDNKSET group subgroup ncos  key ringing lataname ltg len
[ member_len member_key ]0..n $ [ option ]0..n $ groupsize Y
```

M5312:

```
est $ DLH dn M5312 group subgroup ncos snpa key ringing lataname ltg
len [ member_len member_line_class member_key ]0..n $ [ option ]0..n $
groupsize Y
```

where member_line_class and member_key are optional

MLH

1FR, 1MR, CDF, PBM, PBX,ZMZPA

```
est $ MLH dn 1FR, 1MR lataname ltg len [ member_len ]0..n $ [ option
]0..n $ groupsize Y
```

2FR, 4FR:

```
est $ MLH dn 2FR, 4FR pty ringcode lataname ltg len [ member_len ]0..n
$ [ option ]0..n $ groupsize Y
```

IBN:

```
est $ MLH dn IBN group subgroup ncos snpa lataname ltg len [ member_len
member_line_class member_key ]0..n $ [ option ]0..n $ groupsize Y
```

ISDNKSET

```
est $ MLH dn ISDNKSET group subgroup ncos key ringing lataname ltg len
[ member_len member_key ]0..n $ [ option ]0..n $ groupsize Y
```

M5312:

```
est $ MLH dn M5312 group subgroup ncos snpa key ringing lataname ltg
len [ member_len member_line_class member_key ]0..n $ [ option ]0..n $
groupsize Y
```

where member_line_class and member_key are optional

DNH

1FR, 1MR, CDF, PBM, PBX,ZMZPA

```
est $ DNH dn 1FR, 1MR lataname ltg len [ member_dn member_len ]0..n $ [
option ]0..n $ groupsize Y
```

2FR, 4FR

```
est $ DNH dn 2FR, 4FR pty ringcode lataname ltg len [ member_dn
member_len ]0..n $ [ option ]0..n $ groupsize Y
```

ISDNKSET

```
est $ DNH dn ISDNKSET group subgroup ncos key ringing lataname ltg len
[member_dn  member_len member_key ]0..n $ [ option ]0..n $ groupsize Y
```

M5312

```
est $ DNH dn M5312 group subgroup ncos snpa key ringing lataname ltg
len [member_dn  member_len member_line_class member_key ]0..n $ [
option ]0..n $ groupsize Y
```

where member_line_class and member_key are optional

BNN

host_hunt_type = DLH or MLH:

```
est $ BNN dn host_hunt_type host_len [ member_len bnn ]1..20 $ [ option
]0..n $ groupsize Y
```

host_hunt_type = DNH:

```
est $ BNN dn host_hunt_type host_dn [ member_dn bnn ]1..n $ [ option
]0..n $ groupsize Y
```

SimRing

```
est $ SIMRING dn_or_len [ member_dn ]1..n $ state pin [ option ]0..n $
Y
```

Note: dn is equivalent to Servord parameter pilot_dn

Add Hunt Group Member

DLH

1FR, 1MR, CDF, PBM, PBX,ZMZPA ,IBN:

```
add $ DLH len [ member_len ]1..n $ [ option ]0..n $ groupsize Y
```

ISDNKSET

```
add $ DLH len key [ member_len member_key]1..n $ [ option ]0..n $
groupsize Y
```

DNH

1FR, 1MR:, CDF, PBM, PBX,ZMZPA

```
add $ DNH dn [ member_dn member_len ]1..n $ [ option ]0..n $ groupsize
Y
```

ISDNKSET

```
add $ DNH dn [ member_dn member_len member_key ]1..n $ [ option ]0..n $
groupsize Y
```

IBN:

```
add $ DNH dn [ member_dn member_len member_key ]1..n $ [ option ]0..n $
groupsize Y
```

where member_key are optional

MLH

1FR, 1MR, 4FR:, 2FR, CDF, PBM, PBX,ZMZPA

```
add $ MLH len [ member_len ]1..n $ [ option ]0..n $ groupsize Y
```

ISDNKSET

```
add $ MLH len key [ member_len member_key]1..n $ [ option ]0..n $
groupsize Y
```

IBN:

```
add $ MLH len [ member_len member_line_class member_key ]1..n $ [
option ]0..n $ groupsize Y
```

where member_line_class and member_key are optional

BNN

1FR, 1MR, CDF, PBM, PBX,ZMZPA

host_hunt_type = DLH or MLH

```
add $ BNN host_hunt_type link_dn [ member_len bnn ]1..n $ groupsize Y
```

host_hunt_type = DNH

```
add $ BNN DNH dn [ member_dn bnn ]1..n $ groupsize Y
```

SIMRING

IBN:

```
add $ SIMRING dn_or_len [ member_dn ]1..n $ Y
```

Note: dn is equivalent to Servord parameter link_dn

Remove Hunt Group Member

DLH

1FR, 1MR, 2FR, 4FR, IBN, M5312, CDF, PBM, PBX,ZMZPA:

```
del $ DLH [ member_len member_key ]1..n $ Y
```

DNH

1FR, 1MR, CDF, PBM, PBX,ZMZPA:

```
del $ DNH [ member_dn ]1..n $  intercept_name Y
```

MLH

1FR, 1MR, 2FR,4FR, IBN, M5312, CDF, PBM, PBX,ZMZPA:

```
del $ MLH [ member_len member_key ]1..n $ Y
```

SIMRING

IBN:

```
del $ SIMRING dn_or_len [ member_dn ]1..n $ Y
```

Query by DN

```
QDN dn

------------------------------------------------------------------------
DN: 7225032
TYPE: SINGLE PARTY LINE
SNPA: 613 SIG: N/A LNATTIDX: N/A
XLAPLAN KEY: N/A RATEAREA KEY: N/A
LINE EQUIPMENT NUMBER: REM4 00 0 00 24
LINE CLASS CODE: M5312 SET
KEY: 1
CUSTGRP: COMKODAK SUBGRP: 0 NCOS: 0 RING: Y
CARDCODE: 6X21AC GND: N PADGRP: PPHON BNV: NL MNO: Y
PM NODE NUMBER : 81
PM TERMINAL NUMBER : 25
OPTIONS:
MCH EBO
AIN LINETRIG1 $
FTRGRP OPTIONS: PFGROUP1
AAB INSPECT MSB $ PRK RAG 3WC CFB P $ I $ CBI CFD P $ I $ CDI CFU N $ I $
PF USER GENERAL LANG ENGLISH SCS
OFFICE OPTIONS:
AIN OFFICETRIG
------------------------------------------------------------------------
```

Query by DN or LEN

```
QLEN dn_or_len

------------------------------------------------------
LEN: HOST 00 0 0 13
TYPE: MULTIPLE PARTY LINE
DIRECTORY NUMBER: 6221227
LINE CLASS CODE: 2FR R1 0
SIGNALLING TYPE: DIGITONE
LNATTIDX: 16
XLAPLAN KEY: COMMXLA RATEAREA KEY: STDRATE
CARDCODE 2X18AD GND N LOSS Y BNV NL MNO N
OPTIONS:
ONI DGT
```

```
ACTIVE UNIVERSAL FEATURES
IDND UNIVA
-------------------------------------------------------
LEN: HOST 00 0 0 13
TYPE: MULTIPLE PARTY LINE
DIRECTORY NUMBER: 6221222
LINE CLASS CODE: 2FR T1 0
SIGNALLING TYPE: DIAL PULSE
LNATTIDX: 16
XLAPLAN KEY: COMMXLA RATEAREA KEY: STDRATE
CARDCODE 2X18AD GND N LOSS Y BNV NL MNO N
OPTIONS:
ONI $
ACTIVE UNIVERSAL FEATURES
IDND UNIVA
LEN: HOST 00 0 0 13
TYPE: MEMBER OF DNH HUNT GROUP
SNPA: 613
HUNT GROUP: 1 HUNT MEMBER: 1
DIRECTORY NUMBER: 7774114
LINE CLASS CODE: IBN
IBN TYPE: STATION
CUSTGRP: CENTESN SUBGRP: 0 NCOS: 0
SIGNALLING TYPE: DIGITONE
CARDCODE 6X17AA GND: N PADGRP: STDLN BNV: NL MNO: N
PM NODE NUMBER: 27
PM TERMINAL NUMBER: 36
OPTIONS: DGT
PILOT DN: 7774113
GROUP OPTIONS: RCVD
ACTIVE UNIVERSAL FEATURES
IDND UNIVA
-------------------------------------------------------
- end -
```

Establish Distributed Line Hunt (DLH) Group

Establish new group:

1FR, 1MR, IBN, INW, ISDNKSET, OWT, PBX, PBM

```
EST $ DLH <pilot_dn> <lcc> <pilot_len> mem_len[k] $ $ <groupsize> Y
```

Where the mem_len parameter will be used as Compound parameter type.

Query Logical Terminal (ISDN)

ISDNKSET

```
QLT <ltid>
```

where:

ltid - Logical Terminal Identifier.

Query Customer Profile

```
QCUST <custgrp> $ ( If CUSTGRP Parameter is defined )
```

Or

```
QCUST LEN <len>  ( If LEN Parameter is defined )
```

Or

```
QCUST ALL     ( If Both CUSTGRP and LEN Parameters is not defined)
```

Appendix A: OPT Compound-Parameter Suffixes

This appendix lists all of the parameter suffixes, organized by service, that go with the OPT compound-parameter.

Example

This example shows how to map these parameters in a work order.

```
OPT[1].FEATURE = THREE_WAY_CONFERENCE
OPT[1].OPTKEY1
OPT[2].FEATURE = CALL_WAITING
OPT[2].OPTKEY2
```

THREE WAY CALLING (3WC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	THREE_WAY_CONFERENCE	R	1FR, 1MR, IBN, ISDNKSET, ZMZPA, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

AUTOMATIC CALLBACK (ACB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_CALL_BACK	R	IBN, ISDNKSET, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].BILLING_OPTION	AMA, NOAMA	O	IBN, M5312, ISDNKSET	Indicate specified billing option.
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	M5312, ISDNKSET	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If key number is not provided, assumes that value is $.

where n = index starting from 1

AUTOMATIC CALL DISTRIBUTION (ACD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_CALL_DISTRIBUTION	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].ACDGROUP	1-16 alphanumeric characters	R	IBN, KEYSET LCCs	A group identifier that is already in table ACDGRP. Indicates the name of the automatic call distribution (ACD) group to which this station belongs.
OPT[n].ACDSGRP	1-255	R	IBN, KEYSET LCCs	The number of the ACD subgroup to which this station belongs. This number must already appear in table ACDSGRP.
OPT[n].IDNUM	Y = Yes, N = No	R	IBN, KEYSET LCCs	Indicates if an ID number for a Supervisor set is present. This field appears only when a supervisor set uses NEWACD. If Y, the POSID field prompts.
OPT[n].POSID	4-digit number (0001-9999)	R	IBN, KEYSET LCCs	Enter the ACD agent position ID number. A POSID is for interactions with other ACD options.
OPT[n].IBN_ACD_OPTION[n]	SCAILINK, ACDNR	R	IBN, KEYSET LCCs	Enter SCAILINK if the ACD agent associates with a set of D-channels for switch-computer communications.Enter ACDNR to deny ACD calls by the ACD agent.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].SCAI_LINK	1-8 alphanumeric or SCAIDEF	O	IBN, KEYSET LCCs	Indicates the PRA D-channel name, or SCAIDEF for the default link set name.

where n = index starting from 1

AUTOMATIC CALL DISTRIBUTION NOT READY (ACDNR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_CALL_DISTRIBUTION_NOT_READY	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

ADVANCED INTELLIGENT NETWORK (AIN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	PRIVACY_ID_GROUP	R	1FR-1MR, IBN, M5000 Series	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5000 Series,	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].AINGRP	Up to 16 alphanumeric characters	R	1FR-1MR, IBN, M5000 Series	The AIN group name used to define a group of trigger behaviors.
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	1FR-1MR, IBN, M5000 Series	Specifies DN key numbers to which an option applies.Appears when the user assigns a subset option to BRI multi-line sets.If key number is not provided, assumes that value is $.

where n = index starting from 1

ADVANCED INTELLIGENT NETWORK DN (AINDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	PRIVACY_ID	R	1FR, CDF, IBN, INW OWT, PBM, PBX, ZMZPA , ISDNKSET, M5312,	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET, M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].AINGRP	Up to 16 alphanumeric characters, or TIID	R	1FR, CDF, IBN, INW OWT, PBM, PBX, ZMZPA , ISDNKSET, M5312	Enter TIID to datafill the trigger item provisioning interface refinements that follow.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].TDP	1, 3, 4, 17, 19, 20, 22, 30, 32, 33	O	1FR, CDF, IBN, INW OWT, PBM, PBX, ZMZPA , ISDNKSET, M5312	Datafill the appropriate TDP.
OPT[n].TINAME	alphanumeric vector (1 to 8 characters)	O	1FR, CDF, IBN, INW OWT, PBM, PBX, ZMZPA , ISDNKSET, M5312	Datafill the trigger items defined in table TRIGITM at the specified TDP.
OPT[n].TRIGACT	ON, OFF	O	1FR, CDF, IBN, INW OWT, PBM, PBX, ZMZPA , ISDNKSET, M5312	Datafill the value ON to activate the trigger item identified by the TIID.Datafill the value OFF to deactivate the trigger item identified by the TIID.

where n = index starting from 1

DENY ACCESS MESSAGING (AMSGDENY)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_ACCESS_ MESSAGING	R	1FR, 1MR, IBN, PBX, PBM	Feature flag

where n = index starting from 1

ANONYMOUS CALLER REJECTION (ACRJ)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	ANONYMOUS_CALLER_BLOCKING	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].STATUS	ACT, INACT, UNIVI, UNIVA	R	IBN, M5312	INACT indicates the option is not turned on (inactive); ACT indicates the option is turned on (active); UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.

where n = index starting from 1

AUTOMATIC RECALL (AR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_RECALL	R	IBN, ISDNKSET, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].BILLING_ OPTION	AMA, NOAMA	O	IBN, M5312, ISDNKSET	Indicate specified billing option.
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	M5312, ISDNKSET	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If key number is not provided, assumes that value is $.

where n = index starting from 1

AR DIALABLE DN (ARDDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_RE CALL_DIALABLE _DN	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

AGENT STATUS LAMP (ASL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AGENT_STATUS_LAMP	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].AGENT_LEN	LEN_OR_LTID valid input	R	KEYSET LCCs	The LEN of the agent position.
OPT[n].MSBOVRD	Y = Yes, N = No	R	KEYSET LCCs	Make set busy override.
OPT[n].ASLSDN	2-8	R	KEYSET LCCs	Agent status lamp that monitors the SDN of an ACD agent. Key number for the secondary DN the user must monitor.

where n = index starting from 1

AUTOMATIC DIAL (AUD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_DIAL	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].PGMAUD	Y = yes (operating company programmed); N = no (subscriber programmed)	R	KEYSET LCCs	Indicates person who programs the AUD key.
OPT[n].AUDFEAT	1-16 alphanumeric characters	R	KEYSET LCCs	The option or service to be accessed.

where n = index starting from 1

AUTOMATIC LINE (AUL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_LINE	R	1FR, 1MR, IBN, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].DN	18 digits maximum	O	1FR, 1MR, IBN, M5312, ISDNKSET	Automatic line DN.
OPT[n].NPA	3 digits	O	1FR, 1MR, IBN, M5312, ISDNKSET	Automatic line NPA
OPT[n].NXX	3 digits	O	1FR, 1MR, IBN, M5312, ISDNKSET	Automatic line NXX
OPT[n].LINE	4 digits	O	1FR, 1MR, IBN, M5312, ISDNKSET	Automatic line LINE

where n = index starting from 1

AUTOMATIC DISPLAY (AUTODISP)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	AUTOMATIC_DISPLAY	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].CWT_OPTION	Y = Yes, N = No	R	KEYSET LCCs	Indicates if the CWT option is active.
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	KEYSET LCCs	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If key number is not provided, assumes that value is $.

where n = index starting from 1

CALL FORWARDING BUSY INTERNAL CALLS ONLY (CBE)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_BUSY_INTERNAL	R	IBN, KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL FORWARDING BUSY UNRESTRICTED (CBU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_BUSY_UNRESTRICTED	R	IBN, ISDNKSET, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET, KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CANCEL CALL WAITING (CCW)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CANCEL_CALL_WAITING	R	1FR, 1MR, IBN, M5312, ZMZPA	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

EXCLUDE EXTERNAL CALLS FROM CALL FORWARDING (CDE)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_EXCLUDE_EXTERNAL	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

The user must assign the CFD option to the line before the user assigns the CDE option to the line.

The user must assign CDE to the same key as CFD. All DNs in the CFD keylist will associate with CDE.

EXCLUDE INTRAGROUP CALLS FROM CALL FORWARDING (CDI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_EXCLUDE_INTRAGROUP	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

The user must assign the CFD or CFB option to the line before the user assigns the CDI option to the line.

The user must assign CDI to the same key as CFD. All DNs in the CFD keylist will associate with CDI.

CALL FORWARDING NO ANSWER UNRESTRICTED (CDU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_NO_ANSWER_UNRESTRICTED	R	IBN, ISDNKSET, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET, KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL FORWARDING BUSY (CFB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE]	CALL_FORWARD_BUSY	R	IBN, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n]. CNTL	F, N, P, K	O	IBN, M5312, ISDNKSET	Call forwarding busy Control. F = fixed assignment for CFB N = normal (default) assignment for CFB P = programmed assignment for CFB K = programmed assignment for CFB per key destination.
OPT[n].DN	30 digits maximum	O	IBN, M5312, ISDNKSET	Call forwarding DN
OPT[n].NPA	3 digits	O	IBN, M5312, ISDNKSET	Call forwarding NPA
OPT[n].NXX	3 digits	O	IBN, M5312, ISDNKSET	Call forwarding NXX
OPT[n].LINE	4 digits	O	IBN, M5312, ISDNKSET	Call forwarding LINE
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	IBN, M5312, ISDNKSET	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If key number is not provided, assumes that value is $.

where n = index starting from 1

CALL FORWARDING BUSY LINE (CFBL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_BUSY_LINE	R	1FR, 1MR, PBM, PBX, ZMZPA	Feature flag
OPT[n].SCRNCL		R	1FR, 1MR, PBM, PBX, ZMZPA	Screening by class of service.
OPT[n].CFBLCNTL	C, F or N	R	1FR, 1MR, PBM, PBX, ZMZPA	Call forward busy line control.
OPT[n].NUMCALLS	0-1024	R	1FR, 1MR, PBM, PBX, ZMZPA	The number of calls the system can forward at the same time.
OPT[n].DN	1-30 digits. "$" must not be used.	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding DN
OPT[n].NPA	3 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding NPA
OPT[n].NXX	3 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding NXX
OPT[n].LINE	4 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding LINE

where n = index starting from 1

CALL FORWARDING DO NOT ANSWER (BUSINESS) - CFD

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_NO_ANSWER_BUS	R	IBN, M5312, ISDNKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n]. CNTL	F, N, P, K	O	IBN, M5312, ISDNKSET	Call forwarding do not answer Control.F = fixed assignment for CFDN = normal (default) P = programmed assignment for CFD.K = programmed assignment for CFD per key destination
OPT[n].DN	1-30 digits. "$" must not be used.	O	IBN, M5312, ISDNKSET	Call forwarding DN
OPT[n].NPA	3 digits	O	IBN, M5312, ISDNKSET	Call forwarding NPA
OPT[n].NXX	3 digits	O	IBN, M5312, ISDNKSET	Call forwarding NXX
OPT[n].LINE	4 digits	O	IBN, M5312, ISDNKSET	Call forwarding LINE
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	IBN, M5312, ISDNKSET	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature.If key number is not provided, assumes that value is $.

where n = index starting from 1

CALL FORWARDING DO NOT ANSWER (RESIDENTIAL) - CFDA

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_NO_ANSWER_RES	R	1FR, 1MR, PBM, PBX, ZMZPA	Feature flag
OPT[n].CNTL	F, N, C	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding do not answer Control.F = fixed assignment for CFDAN = normal (default) P = programmed assignment for CFDA.
OPT[n].DN	1-30 digits. "$" must not be used.	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding DN
OPT[n].NPA	3 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding NPA
OPT[n].NXX	3 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding NXX
OPT[n].LINE	4 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding LINE
OPT[n].SCRNCL		R	1FR, 1MR, PBM, PBX, ZMZPA	Identifies screening by class of service.
OPT[n].NUMCALLS	1-1024	R	1FR, 1MR, PBM, PBX, ZMZPA	The number of calls the system can forward at the same time.
OPT[n].TIME	0-325	R	1FR, 1MR, PBM, PBX, ZMZPA	Indicates the period of time the base station rings before forwarding.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].RING_CTRL	PRGRING or FIXRING	R	1FR, 1MR, PBM, PBX, ZMZPA	Indicates if the end user or the operating company controls the ringing time-out. PRGRING allows the end user to change the CFDA ringing time-out. FIXRING indicates that only the operating company can change the ringing time-out.

where n = index starting from 1

CALL FORWARDING GROUP DO NOT ANSWER FOR HUNT GROUP (BUSINESS) - CFGD

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_GROUP_NO_ANSWER_BUS	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n]. INTERNAL	Y=YES, N=NO.	R	IBN, M5312	Indicates if the system forwards the call to a member of the hunt group.
OPT[n].DN	1-30 digits. "$" must not be used.	O	IBN, M5312	Call forwarding DN
OPT[n].NPA	3 digits	O	IBN, M5312	Call forwarding NPA

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NXX	3 digits	O	IBN, M5312	Call forwarding NXX
OPT[n].LINE	4 digits	O	IBN, M5312	Call forwarding LINE
OPT[n].SPECTIME	Y=YES, N=NO.	R	IBN, M5312	Special timeout for Call Forward Do Not Answer.
OPT[n]. TYPE	N = no restrictions, CFGDI = restrict intragroup, CFGDE = restrict extragroup	R	IBN, M5312	Call forwarding type.
OPT[n]. TIMEOUT		O	IBN, M5312	Specifies the length of time in seconds before an unanswered call is forwarded.

where n = index starting from 1

CALL FORWARDING GROUP DO NOT ANSWER (RESIDENTIAL) - CFGDA

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_GROUP_NO_ANSWER_RES	R	1FR, 1MR, PBX, ZMZPA	Feature flag
OPT[n].DN	1-30 digits. "$" must not be used.	O	1FR, 1MR, PBX, ZMZPA	Call forwarding DN
OPT[n].NPA	3 digits	O	1FR, 1MR, PBX, ZMZPA	Call forwarding NPA
OPT[n].NXX	3 digits	O	1FR, 1MR, PBX, ZMZPA	Call forwarding NXX

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].LINE	4 digits	O	1FR, 1MR, PBX, ZMZPA	Call forwarding LINE
OPT[n].SCRNCL		R	1FR, 1MR, PBX, ZMZPA	Identifies screening by class of service.
OPT[n].NUMCALLS	1-1024	R	1FR, 1MR, PBX, ZMZPA	The number of calls the system can forward at the same time.
OPT[n].TIME	0-325	R	1FR, 1MR, PBX, ZMZPA	Indicates the period of time the base station rings before forwarding.
OPT[n].INTERNAL	Y, N	R	1FR, 1MR, PBX, ZMZPA	Indicates whether the system forwards the call to a member of the hunt group.

where n = index starting from 1

CALL FORWARDING DO NOT ANSWER VARIABLE TIMER (CFDVT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_NO_ANSWER_VAR	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].TIME	0-60	R	IBN, M5312	Call forward do not answer timing. The time, in seconds, that a call rings before the system forwards the call to the next DN.
OPT[n].RING_CTRL	PRGRING or FIXRING	R	IBN, M5312	Ring control. Enter PRGRING to allow end-user to set CVDVT time-out period. Enter FIXRING to indicate to end-user that the CVDVT time-out period is fixed; it can only be changed by the operating company.

where n = index starting from 1

CALL FORWARD FICXED (CFF)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_FIXED	R	IBN,	Feature flag
OPT[n].CFF_OPTION	CFFA	O	IBN	Enter CFFA to change the activation status of CFF to active.
OPT[n].CFFDN	Up to 30 digits.	R	IBN	Call forwarding DN for the CFF

where n = index starting from 1

CALL FORWARDING INTRAGROUP (CFI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_INTRAGROUP	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	KEYSET LCCs	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature.If key number is not provided, assumes that value is $.

where n = index starting from 1

CALL FORWARDING MADN SECONDARY NUMBER (CFMDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_MADN_DN	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL FORWARDING REMOTE ACCESS (CFRA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_REMOTE_ACTIVATION	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].PIN	2-10 digits	R	IBN, M5312	The first personal identification number (PIN) the operating company assigns to the line.
OPT[n].FIRSTUSE	Y or N	O	IBN, M5312	Indicates if the user must change the PIN before using CFRA for the first time. This prompt applies when option SPP is entered in table CUSTSTN. This field must be set to Y. This action requires the user to change their PIN with SPP before using CFRA for the first time.

where n = index starting from 1

CALL FORWARDING SIMULTANEUS/SCREEENING (CFS)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_SIMULTANEUS	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].SIMULT	Y = Yes, N = No	R	IBN, KEYSET LCCs	Indicates Call Forwarding Simultaneous.
OPT[n].NCFUIF	1-1024	R	IBN, KEYSET LCCs	Maximum number of active calls the user can forward through a CFU, CFI, or CFF base station at the same time.
OPT[n].NCFB	1-1024	R	IBN, KEYSET LCCs	Maximum number of active calls the user can forward through a CFB base station at the same time.
OPT[n].NCFD	1-1024	R	IBN, KEYSET LCCs	The number of calls the user can forward for call forward do not answer at the same time.
OPT[n].SCREEN	Y = Yes, N = No	R	IBN, KEYSET LCCs	Call forwarding screening capability.
OPT[n].CFXNCOS	0-255	R	IBN, KEYSET LCCs	Call forwarding NCOS.

where n = index starting from 1

CALL FORWARDING UNIVERSAL (CFU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_UNIVERSAL	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].OVRDACR	Y = Yes, N = No	R	IBN, M5312	Override for account code required.
OPT[n].KEYLIST[n]	Key number (1-69), list of key numbers, or $.	R	IBN, M5312	Appears when the user assigns a subset option to a multi-line set. Specifies the key numbers of the DNs to which an option will apply.

where n = index starting from 1

CALL FORWARDING (CFW)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD	R	1FR, 1MR, PBM, PBX, ZMZPA	Feature flag
OPT[n].TYPE	C, F, U	R	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding type. C = customer, F = fixed, U = usage sensitive pricing
OPT[n].SCRNCL		R	1FR, 1MR, PBM, PBX, ZMZPA	Screening by Class of Service

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NUMCALLS	0-1024	O	1FR, 1MR, PBM, PBX, ZMZPA	The number of calls the user can forward at the same time.
OPT[n].STATE	A, I, W, $	O	1FR, 1MR, PBM, PBX, ZMZPA	State of absent subscriber intercept. Inactive is normally used. Active and wait are read-only conditions. The wait condition occurs when a customer updates call forwarding information.A = active, I = inactive, W = wait. If this parameter is undefined, $ will be send to switch.
OPT[n].DN	1-30 digits. "$" must not be used.	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding DN
OPT[n].NPA	3 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding NPA
OPT[n].NXX	3 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding NXX
OPT[n].LINE	4 digits	O	1FR, 1MR, PBM, PBX, ZMZPA	Call forwarding LINE

where n = index starting from 1

CALL HOLD (CHD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	BUS_CALL_HOLD	R	IBN	Feature flag

where n = index starting from 1

CONTROLLED INTERFLOW (CIF)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CONTROLLED_INTERFLOW	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].ACDGROUP	Alphanumeric	R	KEYSET LCCs	The name of the automatic call distribution group name. The name is a group identifier the user must datafill in Table ACDGRP.

where n = index starting from 1

CIRCULAR HUNT (CIR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CIRCULAR_HUNT	R	1FR, 1MR, IBN, PBX, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALLING LINE IDENTIFICATION WITH FLASH (CLF)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_TRACE_CLF	R	1FR, 1MR, IBN, INW, OWT, ZMZPA	Feature flag

where n = index starting from 1

CALLING LINE IDENTIFICATION (CLI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_TRACE_CLI	R	1FR, 1MR, 2FR, 4FR, IBN, INW, OWT, CDF, PBX, ZMZPA, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALLING NAME DELIVERY BLOCKING (CNAB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALLING_NAME_DELIVERY_BLOCKING	R	IBN	Feature flag

where n = index starting from 1

CALL NAME DELIVERY (CNAMD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALLER_ID_NAME_DELIVERY	R	IBN, ISDNKSET	Feature flag
OPT[n].BILLING_OPTION	AMA, NOAMA	O	IBN, ISDNKSET	AMA record not created Indicates the billing option that the user must specify, when the user assigns the CNAMD.
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALLING NUMBER DELIVERY (CND)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALLING_NUMBER_DELIVERY	R	IBN, ISDNKSET	Feature flag
OPT[n].BILLING_OPTION	AMA, NOAMA, $	O	IBN, ISDNKSET	Indicate specified billing option, when the SUSP entry in Table AMAOPTS is set to "ON," which enables the billing option prompt.

where n = index starting from 1

CALLING NUMBER DELIVERY BLOCKING (CNDB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALLING_NUMBER_DELIVERY_BLOCKING	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].BILLING_OPTION	AMA, NOAMA, $	O	IBN, M5312	Indicate specified billing option, when the SUSP entry in Table AMAOPTS is set to "ON," which enables the billing option prompt.

where n = index starting from 1

STATION CONTROLLED CONFERENCE (CNF)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	STATION_CONTROLLED_CONFERENCE	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].CONF_TYPE	C06, C10, C14, C18, C22, C26, C30	R	IBN, KEYSET LCCs	Indicates the maximum number of Stations that can connect to a station controlled conference.

where n = index starting from 1

CUTOFF ON DISCONNECT (COD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	GUARANTEED_DISCONNECT	R	1FR, 1MR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA	Feature flag

where n = index starting from 1

CUSTOMER ORIGINATED TRACE (COT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_TRACER	R	IBN, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].BILLING_ OPTION	AMA, NOAMA	O	IBN, M5312, ISDNKSET	Indicate specified billing option, when the SUSP entry in Table AMAOPTS is set to "ON," which enables the billing option prompt.

where n = index starting from 1

CALL PICKUP (CPU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_PICKUP	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].CPU_LEN	1-32767	R	IBN, KEYSET LCCs	Indicates the CPU number.

where n = index starting from 1

CALL SCREENING, MONITORING & INTERCEPT (CSMI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_SCREENIN G	R	1FR, 1MR, IBN, M5312	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set. 1,2,3,4,7,8 for data unit	O	M5312	Identifies key on business set or data unit to which an option is assigned.
OPT[n].CSMISTATE	Valid Values (A = Active, I = Inactive)	O	1FR, 1MR, IBN, M5312	The CSMI state holds the activation state of the feature.The user can set the state to active (A) or inactive (I). The default value is A.
OPT[n].CSMIPPU	Y or N. The default value is N.	O	1FR, 1MR, IBN, M5312	Field CSMIPPU determines the billing design to use. When set to N, the system bills CSMI on a monthly flat rate basis. When set to Y, the system bills CSMI on a usage-sensitive basis for RES and POTS lines.
OPT[n].CONNEC3W	Y or N. The Default Value is N	O	1FR, 1MR, IBN, M5312	Field CONNEC3W determines call interception. When the user enters N, the interception establishes a two-way call between the caller and the end user. When the user enters Y, the interception establishes a three-way call between the two parties and the NBAS.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].SCRACTIVE	Y or N. The Default Value is N	O	1FR, 1MR, IBN, M5312	Field SCRACTIVE indicates if field SCRDUR is prompted or not. When the user sets SCRACTIVE to Y, the value in SCRDUR determines the time of the screening period. The user sets SCRACTIVE to N. The office parameter CSMI_SCREENING_TIMER determines the length of the screening period for subscription-based CSMI and Centrex end users.
OPT[n].SCRDUR	0 to 120. Default is 20	O	1FR, 1MR, IBN, M5312	The SCRDUR prompt requires the user to enter the length (in seconds) of the screening period that the user wants.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].DENYOPT[n]	DENYALL, DENYCFDA, DENYCFBL or DENYCFW	R	IBN, M5312	Field DENYOPT does not allow the user to activate option CSMI on calls forwarded by the following Call Forwarding types: o all Call Forwarding types (DENYALL) - Call Forwarding Do Not Answer (DENYCFDA) - Call Forwarding Busy Line (DENYCFBL) - Call Forwarding (DENYCFW)

where n = index starting from 1

CALL FORWARDING USAGE SENSITIVE DENIAL (CUSD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_CALL_FORWARD	R	1FR, 1MR,PBM, PBX, ZMZPA	Feature flag

where n = index starting from 1

DIAL CALL WAITING (CWD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DIAL_CALL_WAITING	R	IBN, KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL WAITING INTRAGROUP (CWI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_WAITING_INTRAGROUP	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL WAITING ORIGINATING (CWO)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_WAITING_ORIGINATING	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL WAITING (CWT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_WAITING	R	1FR, 1MR, CDF, IBN, ZMZPA, ISDNKSET, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].CWT_OPTION	Y,N	O	M5312, ISDNKSET	Indicates if the CWT option is active.
OPT[n].RING	Y,N	O	M5312, ISDNKSET	Specifies whether a ring from a telephone speaker is required in addition to the LCD diamond CWT key. Enter Y or N.
OPT[n].PCWT	Y,N	O	M5312, ISDNKSET	Precedence call waiting.
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $	O	M5312, ISDNKSET	Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If key number is not provided, assumes that value is $.

where n = index starting from 1

CALL WAITING EXEMPT (CWX)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_WAITING_EXEMPT	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL TRANSFER (CXR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_TRANSFER	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].TYPE	CTOUT, CTINC, CTINTRA, CTALL, NCT, INTERGROUP, ATTRCLF, CUSTOM.	R	IBN, M5312	Call transfer type.CTOUT = call transfer outgoing calls, CTINC = call transfer incoming calls, CTINTRA = call transfer intra group, CTALL = call transfer all, NCT = the system routes the call to the attendant if the first leg of the call is INTERGROUP and the controller is terminator of the call, ATTRCLF = the system routes the call to the attendant at all times, CUSTOM = call transfer of types other than above.
OPT[n].ORGINTER	AC, Inter, Intra, Trater, Nocxfer	O	IBN, M5312	For a CUSTOM type call transfer, the first leg of the call is intergroup. The controller is the originator of the call. AC = second leg of the call is to the attendant, Inter = second leg of the call can be intergroup, Intra = second leg of the call can be intragroup, Trater = second leg of the call can be intragroup or intergroup, Nocxfer = call transfer is not allowed.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].ORGINTRA	AC, Inter, Intra, Trater, Nocxfer	O	IBN, M5312	First leg of the call is intragroup and the controller is the originator of the call.
OPT[n].TRMINTER	AC, Inter, Intra, Trater, Nocxfer	O	IBN, M5312	First leg of the call is intragroup and the controller is the originator of the call.
OPT[n].TRMINTRA	AC, Inter, Intra, Trater, Nocxfer	O	IBN, M5312	First leg of the call is intragroup and the controller is the originator of the call.
OPT[n].RCL	Y = Yes, N = No	R	IBN, M5312	Call transfer recall.
OPT[n].RCLTIM	12-120 seconds	O	IBN, M5312	Recall timer for transfer Recall.
OPT[n].METHOD	DIAL (see note), STD, or RLS	R	IBN, M5312	The method of call transfer: Dial (DIAL), Standard (STD), or is Release (RLS).

where n = index starting from 1

Note: Canada only.

DENIED CALL FORWARDING (DCF)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENIED_CALL_FORWARDING	R	IBN,KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

DIRECTED CALL PICKUP (DCPU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DIRECTED_CALL_PICKUP	R	IBN	Feature flag

where n = index starting from 1

DIALABLE DIRECTORY NUMBER (DDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DIALABLE_DN	R	IBN	Feature flag
OPT[n].BILLING_OPTION	AMA, NOAMA	O	IBN	AMA record not created Indicates the billing option that the user must specify, when the user assigns the CNAMD.

where n = index starting from 1

DENY ACCESS TO CLASS FEATURE (DENY)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_ACCESS_CLASS_FEATURES_DENYOPT	R	1FR, 1MR	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].DENYOPT[n]	For non DMS100G =DENYACB, DENYACRJ, DENYAR,DENYCDS, DENYCIDS, DENYCNAB, DENYCNB, DENYCNDB, DENYCNNB,DENYCNND, DENYCOT, DENYDND,DENYDRCW, DENYSCA, DENYSCF,DENYSCRJ, DENY3WCFor DMS100G =DENYAR, DENYDND, DENY3WC	R	1FR, 1MR	Specifies CLASS option to deny.

where n = index starting from 1

DENY AUTOMATIC RECALL (DENY DENYAR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_AUTOMATIC_RECALL	R	1FR, 1MR	Feature flag

where n = index starting from 1

DENY CALL TRACER (DENY DENYCOT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_CALL_TRACER	R	1FR, 1MR	Feature flag

where n = index starting from 1

DENY REPEAT DIAL (DENY DENYACB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_REPEAT_DIAL	R	1FR, 1MR	Feature flag

where n = index starting from 1

DENY THREE WAY CALLING (DENYU3WC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_THREE_WAY_CONFERENCE	R	1FR, 1MR, CDF, ZMZPA	Feature flag

where n = index starting from 1

DENY IN-SESSION ACTIVATION (DENYISA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_IN_SESSION_ACTIVATION	R	IBN, ISDNKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

DENY CALL SCREENING, MONITORING & INTERCEPT (DENYCSMI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_CALL_SCREENING	R	1FR, 1MR, IBN	Feature flag
OPT[n].DENYOPT[n]	valid values (DENYALL, DENYCFW, DENYCFBL, DENYCFDA)	R	1FR, 1MR, IBN	Specify the type of call forward for which CSMI is denied

where n = index starting from 1

DIGITONE (DGT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DIGITONE	R	1FR, 1MR, 2FR, 4FR, IBN, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA	Feature flag

where n = index starting from 1

DENIED INCOMING CALL (DIN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENIED_INCOMING_CALL	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].TRC	A list in series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence, or a $.	O	IBN, KEYSET LCCs	Terminating restriction code used with the IBN DIN option. Code indicates the classes of incoming calls allowed on a trunk.
OPT[n].ALTTRC	A list in series of from one to eight digits, of the numbers 0-7, that a user enters in a continuous numeric sequence, or a $.	O	IBN, KEYSET LCCs	Alternate terminating restriction code.Code applies to IBN extended calls.Refer to TRC for more information.
OPT[n].DINOPT	DINE = Accepts some types of transferred calls (Refer to Notes). N = Does not accept transferred calls.	R	IBN, KEYSET LCCs	Assign Transfer Call to Restricted Station (DINE) sub-option to a line.

where n = index starting from 1

DISPLAY (DISP)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DISPLAY	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

DIRECTORY NUMBER HUNT (DNH)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DIRECTORY_NUMBER_HUNT	R	1FR, 1MR, IBN, INW, OWT, PBM, PBX, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].DN	Up to 15 digits	O	1FR, 1MR, IBN, INW, OWT, PBM, PBX, M5312, ISDNKSET	DN of a new member to be added to a hunt group. This prompt appears when the ADD command is used.
OPT[n].NPA	3 digits	O	1FR, 1MR, IBN, INW, OWT, PBM, PBX, M5312, ISDNKSET	NPA of a new member to be added to a hunt group. This prompt appears when the ADD command is used.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NXX	3 digits	O	1FR, 1MR, IBN, INW, OWT, PBM, PBX, M5312, ISDNKSET	NXX of a new member to be added to a hunt group. This prompt appears when the ADD command is used.
OPT[n].LINE	4 digits	O	1FR, 1MR, IBN, INW, OWT, PBM, PBX, M5312, ISDNKSET	LINE of a new member to be added to a hunt group. This prompt appears when the ADD command is used.
OPT[n].GROUPSIZE	0-1024	O	1FR, 1MR, IBN, INW, OWT, PBM, PBX, M5312, ISDNKSET	Hunt group size. The expected maximum size of the hunt group.

where n = index starting from 1

DENIED ORIGINATOR (DOR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_ORIGINATION	R	1FR, 1MR, 2FR, 4FR, IBN, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

DISPLAY QUEUE STATUS (DQS)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DISPLAY_QUEUE_STATUS	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].ACDGROUP	Alphanumeric	R	KEYSET LCCs	A group identifier already in Table ACDGRP.

where n = index starting from 1

DISPLAY QUEUE THRESHOLD (DQT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DISPLAY_QUEUE_THRESHOLD	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].DIFFGRP	Y = Yes, N = No	R	KEYSET LCCs	Indicates if the system uses a group other than the ACD INCALLS group to establish the queue threshold status.

where n = index starting from 1

DISTINCTIVE RING CALL WAITING (DRCW)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DISTINCTIVE_RING_CALL_WAITING	R	IBN	Feature flag
OPT[n].STATUS	ACT, INACT, UNIVI, UNIVA	R	IBN	INACT indicates the option is not turned on (inactive); ACT indicates the option is turned on (active); UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.
OPT[n].BILLING_OPTION	AMA, NOAMA, $	O	IBN	The specified billing option, when the user assigns the CND or COT option to a RES line. Valid values are AMA=recorded, NOAMA=not recorded, or $.
OPT[n].DNS[n]	10-digit DN	O	IBN	Directory number to be added to the SCA list. If a user does not send any value for OPT[1].DNS[1] system will assume that value is '$'.
OPT[n].NPA[n]	3 digits	O	IBN	NPA to be added to the SCA list.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NXX[n]	3 digits	O	IBN	NXX to be added to the SCA list. If a user does not send any value for OPT[1].NXX[1] system will assume that value is '$'.
OPT[n].LINE[n]	4 digits	O	IBN	LINE to be added to the SCA list. If a user does not send any value for OPT[1].LINE[1] system will assume that value is '$'.
OPT[n].VBCOUNT[n]	1-10 digits	O	IBN	Number of digits voiced back during SCA list review.

where n = index starting from 1

DISTINCTIVE RING (DRING)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DISTINCTIVE_RING	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].INTRNL	Y, N	R	IBN, KEYSET LCCs	Indicates intragroup calls have distinctive ringing.
OPT[n].EXTRNL	Y, N	R	IBN, KEYSET LCCs	External Calls

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].INTRNL_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].EXTRNL_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].GIC_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].RECALL_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].UCD_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].REST_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].ACD_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].MAKECALL_DRINGTYPE	1-8	O	IBN, KEYSET LCCs	Ring Type
OPT[n].TRKS	SEL, ALL, NO	R	IBN, KEYSET LCCs	IBN trunks.SEL = selected trunks, ALL = all trunks, NO = no trunks
OPT[n].GIC	Y, N	R	IBN, KEYSET LCCs	Group Intercom
OPT[n].RECALL	Y, N	R	IBN, KEYSET LCCs	Recall ringing.
OPT[n].UCD	Y, N	R	IBN, KEYSET LCCs	Uniform call distribution.
OPT[n].REST	Y, N	R	IBN, KEYSET LCCs	Call types that remain.
OPT[n].ACD	Y, N	R	IBN, KEYSET LCCs	Automatic call distribution.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].MAKECALL	Y, N	R	IBN, KEYSET LCCs	Indicates distinctive ringing for outbound calls at customer group level.

where n = index starting from 1

CALL WAITING OPTION (DSCWID)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_WAITING_OPTIONS	R	1FR, 1MR, IBN	Feature flag
OPT[n].DSUBOPT[n]	DTYPE, DAMA,DEFTRMT	O	1FR, 1MR, IBN	The DSCWID suboption to be assigned.The DSWOPT is a vector that is a maximum of three suboptions. If the suboptions are not entered, the default values are used.
OPT[n].DTYPEOPT[n]	ADSITIME,ADSICID,NODATA,NOCIDCW,COMPLETE	O	1FR, 1MR, IBN	The DSCWID type name that indicates which DSCWID type to assign from table DSCWDTYP. Additional values are possible if tuples are datafilled in table DSCWDTYP.
OPT[n].DEFTRMTOPT[n]	RING, FWD,ANNC	O	1FR, 1MR, IBN	The default treatment that is applied when a DSCWID option is not specified.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].DAMAOPT[n]	NONE, CONF	O	1FR, 1MR, IBN	The type of AMA recording status the system uses with the CONFERENCE option. Enter NONE for no recording or CONF to generate an AMA billing record.

where n = index starting from 1

DENIED TERMINATION (DTM)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_TERMINATION	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

ESSENTIAL LINE (ELN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	ESSENTIAL_LINE	R	1FR, 1MR, CDF, IBN, OWT, PBX, PBM, ZMZPA M5312	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

EXECUTIVE MESSAGE WAITING (EMW)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	EXECUTIVE_MESSAGE_WAIT	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].DNLIST[n]	1 to 69	O	IBN, KEYSET LCCs	A DN key that subscribes to an MCOS.The valid entries are 1 to 69. Specify one key for each MCOS.
OPT[n].NOTICE	STD, MWL, CMWI, PRN	O	IBN, KEYSET LCCs	Message waiting notification. STD = stuttered dial tone, MWL = message waiting lamp, CMWI = CLASS message waiting Indicator, PRN = periodic ring notification

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].MCOS[n]	CLASSA to CLASSP	O	IBN, KEYSET LCCs	The name of the MCOS the MDC line subscribes, or the key set.

where n = index starting from 1

EMERGENCY SERVICE LINE (ESL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	EMERGENCY_SERVICE_LINE	R	1FR, 1MR	Feature flag
OPT[n].ROH_TONE_TIME	1-10	R	1FR, 1MR	An emergency service office line option parameter; the duration in seconds of the receiver off-hook tone a caller receives when the ESL flashes.
OPT[n].INTEG_TONE	DIAL, REORDER	R	1FR, 1MR	The integrity tone type.
OPT[n].INTEG_TONE_TIME	10-1000	R	1FR, 1MR	The interval in seconds after which the system generates an alarm and logs a report when an ESL line is off-hook.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].SWITCHHOOK_TONE	LOW, BUSY	R	1FR, 1MR	The tone the emergency service office line receives when a caller goes on-hook. LOW=steady low tone, BUSY=60 interruptions per minute (IPM) busy tone
OPT[n].FASTFLASH	Y = Yes, N = No	R	1FR, 1MR	An option for emergency service office lines.Usually N is used. The Y is entered if the emergency service bureau is equipped with an SP-1 console or equivalent that has the ability to generate an 80-ms flash.
OPT[n].RINGBACK	Y = Yes, N = No	R	1FR, 1MR	Option used with an emergency service office line to enable the office to ring back a caller who goes on-hook.
OPT[n].FORCED_DISCONNECT_TIME	0-40	R	1FR, 1MRx	Option used with an emergency service office line. The timing in seconds, longer than a 2 s flash, after which the call disconnects and the emergency service line goes on-hook.

where n = index starting from 1

Note: Which LCC should be compatible. In guide only 1FR LCC.

FORCED AGENT AVAILABILITY (FAA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	FORCED_AGENT_AVAILABILITY	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].EXTNDFAA	Y = Yes, N = No	R	KEYSET LCCs	Extended forced agent availability.Indicates if the feature is valid for ACD agents in any ACD group and subgroup in the same customer group as the supervisor.
OPT[n].ACDGROUP	Alphanumeric	R	KEYSET LCCs	A group identifier already in Table ACDGRP.

Flexible Automatic Number ID (FANI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	FANI_OPTION	R	1FR, 1MR, 2FR, 4FR, CDF, INW, OWT, PBx, ZMZPA	Feature flag
OPT[n].FANI_DIGITS	Two digits (00-99)	R	1FR, 1MR, 2FR, 4FR, CDF, INW, OWT, PBx, ZMZPA	Digits for the FANI option.

where n = index starting from 1

6.82FEATURE GROUP (FTRGRP)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	FEATURE_GROUP	R	IBN, M5312, ISDNKSET	Feature flag
OPT[n].GRPNAME	Any feature group name defined in table FTRGDEFS.	R	IBN, M5312, ISDNKSET	Name of the feature group with a minimum of one feature.
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET, M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

GROUP INTERCOM (GIC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	GROUP_INTERCOM	R	IBN, KEYSET LCCs	Feature flag
OPT[n].GICNAME	Any name, up to eight characters	R	IBN, KEYSET LCCs	Designated name of group intercom line
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].GICMEMNO	Up to four digits	R	IBN, KEYSET LCCs	Digits dialed to reach this line.
OPT[n].GICSMDR	Y = Yes, N = No	R	IBN, KEYSET LCCs	SMDR records required.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].GICNOMSB	Y = Yes, N = No	R	IBN, KEYSET LCCs	Group intercom calls not included in MSB.

where n = index starting from 1

GROUND START (GND)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	GROUND_START	R	1FR, 1MR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA	Feature flag

HOTEL/MOTEL (HOT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	HOTEL	R	1FR, 1MR, IBN, PBX, PBM, ZMZPA	Feature flag

INTERCOM BUSINESS SET (ICM)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	INTERCOM_BUSINESS_SET	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].LINK_LEN		R	KEYSET LCCs	The LEN of a member of an existing DLH or MLH hunt group to which additional members are to be linked.
OPT[n].DOR	Y = Yes, N = No	R	KEYSET LCCs	Denied origination.
OPT[n].SIC_KEY	1-69	R	KEYSET LCCs	Straight intercom key.
OPT[n].SMDR	Y = Yes, N = No	R	KEYSET LCCs	Station message detail recording.

where n = index starting from 1

INSPECT KEY (INSPECT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	INSPECT_KEY	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

INTERCOM (INT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	INTERCOM	R	1FR, 1MR	Feature flag

where n = index starting from 1

INTERNATIONAL PRIMARY CARRIER (INTPIC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	INTL_PIC	R	1FR, 1MR,IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].CARRIER	1 to 16 alphanumeric characters	R	1FR, 1MR, IBN, KEYSET LCCs	See table OCCNAME for list of correct carrier names
OPT[n].CHOICE	Y OR N	R	1FR, 1MR, IBN, KEYSET LCCs	Indicates if the subscriber is allowed to casually dial Intra-LATA calls. Value Y or N.

where n = index starting from 1

KEY SHORT HUNT (KSH)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	KEY_SHORT_HUNT	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OVTYPE	N, D, R	R	KEYSET LCCs	Type of overflow required when short hunt group is busy. N = no overflow, D = DN to which overflow is to go, R = route
OPT[n].OVDN	0-9 up to a maximum of 30 digits	O	KEYSET LCCs	The overflow directory number for the KSH option when the OVTYPE is D.
OPT[n].TABID	OFRT, IBNRTE	R	KEYSET LCCs	A table identifier associated with the line overflow to a route (LOR) and KSH options.OFRT = Office Route Reference Table IBNRTE = IBN Route Reference Table
OPT[n].KSH_KEY	1-10231 to 69 for business set, 1, 2, 3, 4, or 7for data unit	O	KEYSET LCCs	The line hunt overflow route index that identifies the overflow route. The index identifies the key on business set or data unit. The index indicates the route reference number when Route (R) is the overflow for the KSH option.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].KEYLIST[n]	Key number (1-69), list of key numbers, or $	O	KEYSET LCCs	Appears when an assignment of a subset feature to a multiline set occurs. Specifies key numbers of the DNs to which a feature will apply.

where n = index starting from 1

LOCAL CALL DETAIL REPORTING (LCDR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LOCAL_CALL_DETAILED_REPORTING	R	1FR, 1MR, 4FR, IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

LONG DISTANCE SIGNAL ACTIVATE (LDSA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LONG_DISTANCE_SIGNAL_ACTIVATE	R	1FR, 1MR, ZMZPA	Feature flag

where n = index starting from 1

LONG DISTANCE SIGNAL OPTION (LDSO)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LONG_DISTANCE_SIGNAL_OPTION	R	1FR, 1MR, ZMZPA	Feature flag

where n = index starting from 1

LAST NUMBER REDIAL (LNR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LAST_NUMBER_REDIAL	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

LAST NUMBER REDIAL ASSOCIATED WITH SET (LNRA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LAST_NUMBER_REDIAL_ASSOCIATED	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

LINE OF BUSINESS (LOB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LINE_OF_BUSINESS	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

LINE OVERFLOW TO DN (LOD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_FORWARD_BUSY_OVERFLOW	R	1FR, 1MR, IBN, INW, PBX, PBM M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].DN	No alpha characters allowed. Enter up to 30 digits in the range of 0 to 9.	O	1FR, 1MR, IBN, INW, PBX, PBM M5312, ISDNKSET	The DN to which calls route when all hunt group members are busy.
OPT[n].NPA[n]	3 digits	O	1FR, 1MR, IBN, INW, PBX, PBM M5312, ISDNKSET	NPA of routed DN.
OPT[n].NXX[n]	3 digits	O	1FR, 1MR, IBN, INW, PBX, PBM M5312, ISDNKSET	NXX of routed DN

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].LINE[n]	4 digits	O	1FR, 1MR, IBN, INW, PBX, PBM M5312, ISDNKSET	LINE of routed DN

where n = index starting from 1

INTRALATA PIC (LPIC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	INTRA_PIC	R	1FR, 1MR, 4FR, IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].CARRIER	1-16 alphanumeric characters	R	1FR, 1MR, 4FR, IBN, M5312	Carrier name or id
OPT[n].CHOICE	Y or N	R	1FR, 1MR, 4FR, IBN, M5312	Indicates if the subscriber is allowed to casually dial Intra-LATA calls.

where n = index starting from 1

LEAVE MESSAGE (LVM)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LEAVE_MESSAGE	R	KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

18-BUTTON ADD-ON FOR MERIDIAN M5000 SERIES M518 (M518)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	M518	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].QUANTITY	1-3	R	KEYSET LCCs	Indicates the number of M518 add-on units for a M5000 set.

where n = index starting from 1

36-BUTTON ADD-ON FOR MERIDIAN M5000 SERIES M536 (M536)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	M536	R	KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

MULTIPLE APPEARANCE DIRECTORY NUMBER (MDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	MULTIPLE_APPEARANCE_DN	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	R	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].MDNTYPE	MCA, SCA, EXB	R	IBN, KEYSET LCCs	The type of callArrangement.MCA=multiple call arrangement, SCA=single call arrangement, EXB=extension bridging
OPT[n].PRIMARY	Y, N	R	IBN, KEYSET LCCs	Primary member of a MADN group
OPT[n].RING	Y, N	R	IBN, KEYSET LCCs	Whether ringing is required
OPT[n].DIR_NUMBER	Seven digits, with no spaces or hyphens.	R	IBN, KEYSET LCCs	The directory number

where n = index starting from 1

MAKE SET BUSY (MSB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	MAKE_SET_BUSY	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

MAKE SET BUSY INTRAGROUP (MSBI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	MAKE_SET_BUSY_INTRAGROUP	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

MESSAGE WAITING (MWT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	MESSAGE_WAITING_INDICATOR	R	IBN, M5312, ISDNKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].NOTICE	STD, MWL, CMWI, PRN	O	IBN	Message waiting notification. STD = stuttered dialtone, MWL = message waiting lamp, CMWI = CLASS message waiting indicator, PRN = periodic ring notification.
OPT[n].IRN	OFFHOOK, ALWAYS	O	IBN	Immediate ring notification; this prompt appears only if PRN or CMWI is selected as the message waiting notification (NOTICE prompt) and input to the CRN prompt is "Y."
OPT[n].CMWISTD	Y, N	O	IBN	When CMWISTD is set to Y, subscribers are allowed to dial an access code to activate or deactivate stuttered dial tone.Y = stuttered dial tone is activated.N = No stuttered dial tone.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].CMWIRING	Y, N, UDLC	O	IBN	When CMWIRING is set to Y, subscribers can dial an access code. This code allows the subscriber to activate or deactivate ringing that precedes a lamp activation message. Y = Ring burst is activation, N = No ring burst, UDLC = Ring burst functionality is not allowed. If a UDLC line attempts to dial this access code, the result is FNAL treatment. This is a protective measure that does not allow a subscriber to disable the lamp activation.
OPT[n].STATUS	ACT	O	IBN	When the CMWIRING is set to UDLC, the system does not prompt for the status field.
OPT[n].CAR	Y = Yes, N = No	R	IBN, M5312, ISDNKSET	Call request option.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].CRRCFW	NO, ALL, DISPLAY	O	IBN, M5312, ISDNKSET	Call request retrieve call forwarding. Specifies how the system handles forwarding if a subscriber activates Call request retrieve (CRR) to return a call to the subscriber that left the message. Note: The CRRCFW is required only if CAR is set to Y.NO = the CRR call is never forwarded, ALL = the CRR call can be forwarded, DISPLAY = the CRR call is forwarded only if the subscriber that activates CRR has a display set.
OPT[n].CRX	Y = Yes, N = No	R	IBN, M5312, ISDNKSET	Call request not required.

where n = index starting from 1

Note: The CRRCFW prompt will appear only if Y is entered at the CAR prompt.

NAME DISPLAY (NAME)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	NAME	R	1FR,1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA, M5312, ISDNKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].NETNAME	Character String	R	1FR,1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA, M5312, ISDNKSET	Network name shown as DN attribute.
OPT[n].DISPLAYNAME	1-15 characters	R	1FR,1MR, 2FR, 4FR, CDF, IBN, INW, OWT, PBM, PBX, ZMZPA, M5312, ISDNKSET	Name to display on an MBS set.

where n = index starting from 1

NO DOUBLE CONNECT (NDC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	NO_DOUBLE_CONNECT	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	option key number 1	O	KEYSET LCCs	Identifies key on business set or data unit to which the feature is assigned

where n = index starting from 1

NETWORK FACILITY ACCESS (NFA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	NETWORK_FACILITY_ACCESS	R	M5312	Feature flag
OPT[n].OPTKEY	option key number 1	O	M5312	Identifies key on business set or data unit to which the feature is assigned
OPT[n].USER_ID	1-10 digits, The default is the last 7 digits of line, <nxx><line>	O	M5312	The user ID for the line to which the user add NFA option
OPT[n].IMPLCT_ACC	Y or N, the default is Y	O	M5312	Specify if the line is allowed implicit access
OPT[n].EXPLCT_ACC	Y or N, the default is Y	O	M5312	Specify if the line is assigned explicit access
OPT[n].AMA_EXPLCT	Y or N, the default is N	O	M5312	Control the AMA billing record generation that follows an explicit connection
OPT[n].AMA_IPDIAL	Y or N, the default is N	O	M5312	Control the AMA billing record generation that follows IP dialed connection
OPT[n].REM_ACC	Y or N, the default is N	O	M5312	Specify if the line is allowed remote access
OPT[n].AMA_REM	Y or N, the default is N	O	M5312	Control the AMA billing record generation that follows an remote connection

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NFRA_PIN	2-10 numeric digits	O	M5312	The remote access PIN. This is required if REM_ACC is set to Y

where n = index starting from 1

NIGHT SERVICE (NGTSVRCE)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	NIGHT_SERVICE	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1-69 for business set; 1,2, 3, 4, or 7 for data unit	O	KEYSET LCCs	Identifies key on business set or data unit to which the feature is assigned
OPT[n].ACDGROUP	1-16 alphanumeric characters	R	KEYSET LCCs	A group identifier that the user already entered in Table ACDGRP. The identifier is the name of the automatic call distribution group to which this station belongs.

where n = index starting from 1

NO LINE INSULATION TEST (NLT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	NO_LINE_INSULATION	R	IBN, KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1-69 for business set; 1,2, 3, 4, or 7 for data unit	O	KEYSET LCCs	Identifies key on business set or data unit to which the feature is assigned

where n = index starting from 1

OBSERVE AGENT (OBS)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	OBSERVE_AGENT	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1-69 for business set; 1,2, 3, 4, or 7 for data unit	O	KEYSET LCCs	Identifies key on business set or data unit to which the feature is assigned
OPT[n].OBSTYPE	BASIC, EXTENDED, FOBS	R	IBN, KEYSET LCCs	The type of observation a supervisor can apply over incoming ACD calls: basic, extended, or flexible call observing.
OPT[n].ACDGROUP	1-16 alphanumeric characters	O	IBN, KEYSET LCCs	A group identifier that Table ACDGRP must already contain. The group identifier is the name of the automatic call distribution group to which this station belongs.
OPT[n].FOBS_ACDGROUP	Valid ACD group name	O	IBN, KEYSET LCCs	Appears if OBSTYPE is set to FOBS.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FOBSTYPE	GROUP, SUBGROUP, DN	O	IBN, KEYSET LCCs	Appears if OBSTYPE is set to FOBS.Specifies the type of flexible call observing required.
OPT[n].FOBS_SUBGROUP	ACD subgroup number	O	IBN, KEYSET LCCs	Specifies an ACD subgroup number.Appears if FOBSTYPE = SUBGROUP.
OPT[n].DN	ACD DN	O	IBN, KEYSET LCCs	Specifies an ACD directory number.Appears if FOBSTYPE = DN.

where n = index starting from 1

OPTERATOR NUMBER IDENTIFICATION(ONI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	OPTERATOR_NUMBER_IDENTIFICATION	R	1FR, 1MR, 2FR, CDF, IBN, 4FR, OWT, PBM, PBX, M5312 ,ISDNKSET	Feature flag
OPT[n].OPTKEY	1-69 for business set; 1,2, 3, 4, or 7 for data unit	O	M5312, ISDNKSET	Identifies key on business set or data unit to which the feature is assigned

where n = index starting from 1

INTERLATA PIC (PIC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	INTER_PIC	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].CARRIER	1-16 alphanumeric characters	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Carrier name or id
OPT[n].CHOICE	Y or N	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Determines if the system allows the user to dial 10xxx to access other carriers.

where n = index starting from 1

PORT (PORT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	LOCAL_NUMBER_PORT	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

CALL PARK (PRK)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_PARK	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

PRIVACY RELEASE (PRL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	PRIVACY_RELEASE	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

QUERY TIME AND DATE (QTD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	QUERY_TIME_DATE	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

RING AGAIN (RAG)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	RING_AGAIN	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

RESIDENTIAL CALL HOLD (RCHD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_HOLD	R	1FR, 1MR	Feature flag

where n = index starting from 1

REMOTE MESSAGE INDICATOR (RMI)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	REMOTE_MESSAGE_INDICATOR	R	1FR, 1MR, ISDNKSET	Feature flag
OPT[n].RMI_STATE	A= Active, I = Inactive	R	1FR, 1MR, ISDNKSET	The state of RMI feature, active or inactive
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

ANSWER SUPERVISION LOCAL (RMT)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	ANSWER_SUPERVISION_LOCAL	R	1FR, 1MR	Feature flag

where n = index starting from 1

ANSWER SUPERVISION TOLL (RMR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	ANSWER_SUPERVISION_TOLL	R	1FR, 1MR	Feature flag

where n = index starting from 1

REPEATED ALERT (RPA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	REPEATED_ALERT	R	KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

MEASURED RATE COIN LINE (RSP)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	RESTRICTED_SENT_PAID	R	1FR, 1MR, CDF, IBN, OWT, PBM, PBX, ZMZPA ,M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

Requested Suspension (RSUS)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	REQUESTED_SUSPENSION	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].ORIG_SUS	Alphabetic treatment name (up to 4 characters)	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Originating suspension; the treatment to which the subscriber is routed on origination of a call.
OPT[n].TERM_SUS	Alphabetic treatment name (up to 4 characters)	R	1FR, 1MR, 2FR, 4FR, CDF, IBN, INW, OWT PBM, PBX, ZMZPA, M5312, ISDNKSET	Terminating suspension; the treatment to which a call is routed when attempting to terminate to a line with the RSUS option.

where n = index starting from 1

Subscriber Activated Call Blocking (SACB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SUB_ACT_CALL_BLOCKING	R	IBN, M5312	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].STATUS	ACT, INACT	O	IBN, M5312	Option prompt when SCRJ option is specified, when SACB option is specified, or when PRN is specified when adding MWT to a line.
OPT[n].CC	IDDD, I800,I900, I976, LDAS, TDAS, OPRA,SPEC,TOLL, ZROM,ALL,FPB,NONE.	R	IBN, M5312	Indicates the type of call classes to be restricted for SACB.
OPT[n].PIN	2-10 digits.	R	IBN, M5312	SACB personal identification number (PIN).
OPT[n].SUS	Y, N	R	IBN, M5312	Blocks all calls from an originating line except for those in table SACB against subfield FPBALLOW. STATUS must be specified as ACT.

where n = index starting from 1

Selective Call Acceptance (SCA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SELECTIVE_CALL_ACCEPTANCE	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].BILLING_OPTION	AMA, NOAMA	O	IBN, M5312	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.
OPT[n].STATUS	ACT, INACT, UNIVI, UNIVA	R	IBN, M5312	INACT indicates the option is not turned on (inactive); ACT indicates the option is turned on (active); UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.
OPT[n].DNS[n]	10-digit DN	O	IBN, M5312	Directory number to be added to the SCA list. If a user does not send any value for OPT[1].DNS[1] system will assume that value is '$'.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NPA[n]	3 digits	O	IBN, M5312	NPA to be added to the SCA list.
OPT[n].NXX[n]	3 digits	O	IBN, M5312	NXX to be added to the SCA list. If a user does not send any value for OPT[1].NXX[1] system will assume that value is '$'.
OPT[n].LINE[n]	4 digits	O	IBN, M5312	NXX to be added to the SCA list. If a user does not send any value for OPT[1].LINE[1] system will assume that value is '$'.
OPT[n].VBCOUNT[n]	1-10 digits	O	IBN, M5312	Number of digits voiced back during SCA list review.

where n = index starting from 1

Selective Call Forwarding (SCF)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SELECTIVE_CALL_FORWARDING	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].BILLING_ OPTION	AMA, NOAMA	O	IBN, M5312	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.
OPT[n].STATUS	ACT, INACT, UNIVI, UNIVA	R	IBN, M5312	INACT indicates the option is not turned on (inactive); ACT indicates the option is turned on (active); UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.
OPT[n].DNS[n]	10-digit DN	O	IBN, M5312	Directory number to be added to the SCF list. If a user does not send any value for OPT[1].DNS[1] system will assume that value is '$'.
OPT[n].NPA[n]	3 digits	O	IBN, M5312	NPA to be added to the SCF list.
OPT[n].NXX[n]	3 digits	O	IBN, M5312	NXX to be added to the SCF list. If a user does not send any value for OPT[1].NXX[1] system will assume that value is '$'.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].LINE[n]	4 digits	O	IBN, M5312	LINE to be added to the SCF list. If a user does not send any value for OPT[1].LINE[1] system will assume that value is '$'.
OPT[n].VBCOUNT[n]	1-10 digits	O	IBN, M5312	Number of digits voiced back during SCF list review.
OPT[n].FDN	1-30 digits. "$" must not be used.	O	IBN, M5312	Number to which calls will be forwarded. Either FDN or FDN_NPA+FDN_NXX+FDN_LINE must be exist.
OPT[n].FDN_NPA	3 digits	O	IBN, M5312	NPA of FDN to which calls will be forwarded. Either FDN or FDN_NPA+FDN_NXX+FDN_LINE must be exist.
OPT[n].FDN_NXX	3 digits	O	IBN, M5312	NXX of FDN to which calls will be forwarded. Either FDN or FDN_NPA+FDN_NXX+FDN_LINE must be exist.
OPT[n].FDN_LINE	4 digits	O	IBN, M5312	LINE of FDN to which calls will be forwarded. Either FDN or FDN_NPA+FDN_NXX+FDN_LINE must be exist.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].SCRNCL		O	IBN, M5312	Screening by class of service.
OPT[n].NUMCALLS	1-1024	R	IBN, M5312	The number of calls that may be Forwarded simultaneously.
OPT[n].RINGREM	RING, NORING, NA	R	IBN, M5312	Ring reminder option.

where n = index starting from 1

Speed Calling Long (SCL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SPEED_CALLING_LONG	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].LISTTYPE	L30, L50, or L70	R	IBN, M5312	Indicates length of list.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].KEYLIST[n]	Key number (1-69); list of key numbers or $ ($ must be assigned if no KEYLIST is sent from ASAP when adding option for HUNT group)	O	IBN, M5312	This parameter only applied to hunt group. Appears when the user assigns a subset feature to a multi-line set. Specifies key numbers of the DNS to which the user applied a feature. If key number is not provided, you should provide the value is $.

where n = index starting from 1

SPEED CALL SHORT (SCS)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SPEED_CALLING_SHORT	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

SPEED CALL SHORT LIST 30 (SC1)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SPEED_CALLING_SHORT_LIST	R	1FR, 1MR, 2FR, CDF, OWT, ZMZPA	Feature flag

where n = index starting from 1

SPEED CALL LONG LIST (SC2)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SPEED_CALLING_LONG_LIST	R	1FR, 1MR, 2FR, CDF, OWT, ZMZPA	Feature flag

where n = index starting from 1

Selective Call Rejection (SCRJ)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SELECTIVE_CALL_BLOCKING	R	IBN, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].BILLING_ OPTION	AMA, NOAMA	O	IBN, M5312, ISDNKSET	NOAMA indicates that the feature is billed based on a subscription; AMA indicates that the feature is billed based on usage, in which case an AMA billing record is generated for each SLE session.
OPT[n].STATUS	ACT, INACT, UNIVI, UNIVA	R	IBN, M5312, ISDNKSET	INACT indicates the option is not turned on (inactive); ACT indicates the option is turned on (active); UNIVI indicates universal access via customer interface inactive, and UNIVA indicates universal access via customer interface active.
OPT[n].DNS[n]	10-digit DN	O	IBN, M5312, ISDNKSET	Directory number to be added to the SCRJ list. If a user does not send any value for OPT[1].DNS[1] system will assume that value is '$'.
OPT[n].NPA[n]	3 digits	O	IBN, M5312, ISDNKSET	NPA to be added to the SCRJ list.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].NXX[n]	3 digits	O	IBN, M5312, ISDNKSET	NXX to be added to the SCRJ list. If a user does not send any value for OPT[1].NXX[1] system will assume that value is '$'.
OPT[n].LINE[n]	4 digits	O	IBN, M5312, ISDNKSET	NXX to be added to the SCRJ list. If a user does not send any value for OPT[1].LINE[1] system will assume that value is '$'.
OPT[n].VBCOUNT[n]	1-10 digits	O	IBN, M5312, ISDNKSET	Number of digits voiced back during SCRJ list review.

where n = index starting from 1

SPEED CALLING USER (SCU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SPEED_CALLING_USER	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].SCUGNUMBER	1-32767	R	IBN, KEYSET LCCs	Specifies a unique group number for the SCU option.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].SCU_TDN	Y = Yes, N = No	R	IBN, KEYSET LCCs	Specifies whether toll denial is applied to speed called numbers.

where n = index starting from 1

SPONTANEOUS CALL WAITING IDENTIFICATION (SCWID)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	CALL_WAITING_ID	R	IBN	Feature flag

where n = index starting from 1

Secondary Directory Number (SDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SECONDARY_DN	R	1FR, 1MR, IBN	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].DN	Up to 15 digits	O	1FR, 1MR, IBN	Secondary DN. The number entered at this prompt is screened for ambiguity and validity. When a message shows the SDN is ambiguous, re-enter the number with the NPA plus a seven-digit number. When a message shows the SDN is invalid, enter an SDN that is equipped for the office or enter $ to abort the option.
OPT[n].NPA	3 digits	O	1FR, 1MR, IBN	Secondary NPA
OPT[n].NXX	3 digits	O	1FR, 1MR, IBN	Secondary NXX
OPT[n].LINE	4 digits	O	1FR, 1MR, IBN	Secondary LINE
OPT[n].NEW_DN	Up to 15 digits	O	1FR, 1MR, IBN	New secondary DN (used for CHF action). This prompt appears when CHF command is used. Up to six SDNs can be changed with one CHF command. The SDN entry is screened for ambiguity and validity.
OPT[n].NEW_NPA	3 digits	O	1FR, 1MR, IBN	New Secondary NPA (used for CHF action).

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n]. NEW_NXX	3 digits	O	1FR, 1MR, IBN	New Secondary NXX (used for CHF action).
OPT[n]. NEW_LINE	4 digits	O	1FR, 1MR, IBN	New Secondary LINE (used for CHF action).
OPT[n].DNY	NODNY or DNYCWT	O	1FR, 1MR, IBN	NODNY = No deny to call waiting.DNYCWT = Deny call waiting. These options are not applicable to MDC.
OPT[n].RING	0,1,2,3	R	1FR, 1MR, IBN	Secondary DN ring type.0 = normal ringing1 = SDN pattern #12 = SDN pattern #23 = SDN pattern #3
OPT[n].OPT	P,N,E	R	1FR, 1MR, IBN	Secondary DN type.P = forward SDN with PDNN = do not forward SDNE = enhanced SDN can have own option list.

where n = index starting from 1

STOP HUNT (SHU)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	STOP_HUNT	R	IBN, KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].SC	tmtype, tmno, tmcktno, point, normal_state	R	IBN, KEYSET LCCs	Scan point. tmtype = MTM, RSMtmno = 0-2047tmcktno = 0-29point = 0-6 (SD point number) normal_state = 0 for open or 1 for closed
OPT[n].TMNO	0-2047	R	IBN, KEYSET LCCs	Enter the number of the trunk module on which the circuit is mounted. Appears after the signal distribution (SD) or SC prompt if data is not entered on one line.
OPT[n].TMCKTNO	0-29	R	IBN, KEYSET LCCs	Enter the trunk module circuit number to which the circuit is assigned. Appears after the SD or SC prompt if data is not entered on one line.
OPT[n].POINT	0-6	R	IBN, KEYSET LCCs	SD point number. Appears after the SD or SC prompt if data is not entered on one line.
OPT[n].NORMAL_ STATE	0 = open1 = closed	R	IBN, KEYSET LCCs	Normal state of the SD point. Appears after the SD or SC prompt if data is not entered on one line.

where n = index starting from 1

SETUP-DN ATTRIBUTES (SDNA)

Parameter label	Parameter value	Required (R) / Optional (O)	Description
OPT[1..n].FEATURE	NAME	O	Service option that can be added to associate a name of the caller to DN.
OPT[1..n].NAME		O	Name of the caller
OPT[1..n].FEATURE	ADDRESS	O	Service option to provide a replacement DN in place of all or part of calling DN
OPT[1..n].ADDRESS		O	A replacement DN.
OPT[1..n].FEATURE	SUPPRESS	O	Service option to prevent the number of the caller to appear at the call destination
OPT[1..n].FEATURE	NONUNIQUE	O	Service option to indicate the calling DN is not for one line

where n = index starting from 1

DENY BUSY REPEAT DIAL (SDSDENY)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_BUSY_REPEAT_DIAL	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

SECONDARY LANGUAGE (SL)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SECONDARY_LANGUAGE	R	IBN, M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

STATION MESSAGE DETAIL RECORDING (SMDR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	STATION_MESSAGE_RECORDING	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

ADD LOGICAL TERMINAL (SLT ADD)

Parameter label	Parameter value	Required (R) / Optional (O)	Description
OPT[1..n].FEATURE	AGA	O	Associated Group Assignment
OPT[1..n].AG_GROUP	1- 9	O	Associated Group Number

Parameter label	Parameter value	Required (R) / Optional (O)	Description
OPT[1..n].AG_CT	AG_VI, AG_CMD, AG_ALL, AG_UNASSIGNED	O	Associated Group call type
OPT[1..n].FEATURE	CACH	O	Call Appearance Call Heading
OPT[1..n].CACH		O	CACH is valid only for EKTS sets.
OPT[1..n].FEATURE	PVC	O	Protocol Version Control
OPT[1..n].VERSION	FUNCTIONAL, ETSI	O	The version of the protocol used for BRAFS terminal
OPT[1..n].ISSUE	0,1,2	O	The protocol issued to logical terminal
OPT[1..n].FEATURE	SLBRI	O	identifies single line BRI
OPT[1..n].SLBRI	Y or N	O	indicates single line BRI
OPT[1..n].FEATURE	SPIDSFX	O	Service Profile Identifier Suffix
OPT[1..n].SPID_SUFFIX	8 characters alphanumeric suffix	O	
OPT[1..n].FEATURE	TERML	O	The protocol issued to logical terminal
OPT[1..n].LIMIT	1- 8	O	The max. number of NITs allowed on the interface

where n = index starting from 1

ATTACH LOGICAL TERMINAL (SLT ATT)

Parameter label	Parameter value	Required (R) / Optional (O)	Description
OPT[1..n].FEATURE	TEI	O	Terminal endpoint identifier
OPT[1..n].TEI	0 - 63	O	Terminal endpoint number
OPT[1..n].FEATURE	PHLINK	O	Packet Handler Link
OPT[1..n].XSG	0 - 749	O	Used for B-channel packet service only
OPT[1..n].FEATURE	TO	O	
OPT[1..n].TO		O	
OPT[1..n].FEATURE	BCH	O	The B-channel selected for packet data
OPT[1..n].BCH	B1, B2	O	B-channel type
OPT[1..n].FEATURE	PHI	O	Packet Handler Interface
OPT[1..n].PHI	0 - 1023	O	Packet handler interface number
OPT[1..n].FEATURE	DCHCHNL	O	The D-channel handler channel to which the loop is connected
OPT[1..n].DCHCHNL	A number from 0 -31	O	

where n = index starting from 1

CHANGE LOGICAL TERMINAL (SLT CHA)

Parameter label	Parameter value	Required (R) / Optional (O)	Description
OPT[1..n].FEATURE	ABS	O	Indicates authorized bearer services

Parameter label	Parameter value	Required (R) / Optional (O)	Description
OPT[1..n].NEW_ABS	VOICE,VBD, CMD	O	New abs to be applied on the logical terminal
OPT[1..n].FEATURE	AGA	O	Associated Group Assignment
OPT[1..n].AG_GROUP	A number from 1 - 9	O	Associated Group Number
OPT[1..n].AG_CT	AG_VI, AG_CMD, AG_ALL, AG_UNASSIGNED	O	Associated Group call type
OPT[1..n].FEATURE	CACH	O	Call Appearance Call Heading
OPT[1..n].CACH		O	CACH is valid only for EKTS sets.
OPT[1..n].FEATURE	EKTS	O	Electronic key telephone set.
OPT[1..n].EKTS	Y or N	O	indicates electronic key telephone set.
OPT[1..n].FEATURE	PVC	O	Protocol Version Control
OPT[1..n].VERSION	FUNCTIONAL, ETSI	O	The version of the protocol used for BRAFS terminal
OPT[1..n].ISSUE	0,1,2	O	The protocol issued to logical terminal
OPT[1..n].FEATURE	SLBRI	O	identifies single line BRI
OPT[1..n].SLBRI	Y or N	O	indicates single line BRI
OPT[1..n].FEATURE	SPIDSFX	O	Service Profile Identifier Suffix
OPT[1..n].NEW_SPID_SUFFIX	8 characters alphanumeric suffix	O	new service profile identifier suffix

where n = index starting from 1

SPECIAL BILLING (SPB)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SPECIAL_BILLING	R	1FR, 1MR, 2FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA,M5312, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].DN	1-30 digits	O	1FR, 1MR, 2FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA,M5312, ISDNKSET	Special Billing DN number
OPT[n].NPA	3 digits	O	1FR, 1MR, 2FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA,M5312, ISDNKSET	Special Billing number area code
OPT[n].NXX	3 digits	O	1FR, 1MR, 2FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA,M5312, ISDNKSET	Special Billing number nxx
OPT[n].LINE	4 digits	O	1FR, 1MR, 2FR, CDF, IBN, INW, OWT, PBX, PBM, ZMZPA,M5312, ISDNKSET	Special Billing number line number

where n = index starting from 1

SUPPRESSED RINGING ACCESS (SRA)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SUPPRESSED_RINGING_ACCESS	R	1FR, 1MR, RES, IBN, 4FR	Feature flag

where n = index starting from 1

STATION SPECIFIC AUTHORIZATION CODES (SSAC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	STATION_SPECIFIC_AUTH_CODES	R	IBN, KEYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].AUTHCODE[n]	From 2-12 digits or $	R	IBN, KEYSET LCCs	Authorization code.

where n = index starting from 1

SUPERVISOR (SUPR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SUPERVISOR	R	IBN, KEYSET LCCs	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	KEYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].PRIMARY_ ACDGROUP	Alphanumeric	R	IBN, KEYSET LCCs	The group identifier that must already be data filled in Table ACDGRP when adding the SUPR option to an ACD group.
OPT[n].PRIMARY_ ACDSGRP	Numeric	R	IBN, KEYSET LCCs	The supervisor subgroup identifier that must already be data filled in Table ACDSGRP in order to add the SUPR option to an ACD group.
OPT[n].IDNUM	Y, N	R	IBN, KEYSET LCCs	Indicates if ID number of agent position is required.Y = Yes, N = No.

where n = index starting from 1

ANONYMOUS CALLER (SUPPRESS)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	ANONYMOUS_CA LLER	R	1FR, 1MR, 2FR, 4FR , CDF, IBN, INW, OWT, PBM, PBX, ZMZPA,M5312 ,ISDNKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.
OPT[n].NETNAME	Character string	O	1FR, 1MR, 2FR, 4FR , CDF, IBN, INW, OWT, PBM, PBX, ZMZPA,M5312 ,ISDNKSET	Network name shown as DN attribute.
OPT[n].SUPPRESS_DN	Y, N	O	1FR, 1MR, 2FR, 4FR , CDF, IBN, INW, OWT, PBM, PBX, ZMZPA,M5312 ,ISDNKSET	Suppresses the display of the DN.
OPT[n].SUPPRESS_NAME	Y, N	O	1FR, 1MR, 2FR, 4FR , CDF, IBN, INW, OWT, PBM, PBX, ZMZPA,M5312 ,ISDNKSET	Suppresses the display of the station name.

where n = index starting from 1

SERVICE GROUP (SVCGRP)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	SERVICE_GROUP	R	IBN, KESYSET LCCs	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	KESYSET LCCs	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].GRPNAME	Up to 16 alphanumeric characters	R	IBN, KESYSET LCCs	Name of service group defined in table FTRGDEFS (Feature Group Definitions)

where n = index starting from 1

TALKING CALL WAITING (TCW)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	TALKING_CALL_WAITING	R	1FR, 1MR	Feature flag

where n = index starting from 1

DENY TOLL CALL (TDN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_TOLL_CALL	R	1FR, 1MR, 2FR, PBM, PBX, ZMZPA	Feature flag

where n = index starting from 1

TERMINATION FAULT OPTION (TFO)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	TERMINATION_FAULT	R	1FR, 1MR, 2FR, PBM, PBX, IBN, M5312, ISNDKSET	Feature flag

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].OPTKEY	1 to 69 for business set	O	M5312, ISNDKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

UNIFORM CALL DISTRIBUTION (UCD)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	UNIFORM_CALL_DISTRIBUTION	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

DENY VOICE MAIL EASY ACCESS (VMEADENY)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	DENY_VOICE_MAIL_EASY_ACCESS	R	1FR, 2FR, ISDNKSET	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

VOICE MAIL EASY ACCESS DN (VMEADN)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	VOICE_MAIL_EASY_ACCESS_DN	R	1FR, RES, ISDNKSET	Feature flag
OPT[n].VM_DN	1-30 digits	O	1FR, RES, ISDNKSET	subscriber's VM DN number
OPT[n].VM_NPA	3 digits	O	1FR, RES, ISDNKSET	subscriber's VM area code
OPT[n]. VM_NXX	3 digits	O	1FR, RES, ISDNKSET	subscriber's VM nxx
OPT[n]. VM_LINE	4 digits	O	1FR, RES, ISDNKSET	subscriber's VM line number
OPT[n].OPTKEY	1 to 69 for business set	O	ISDNKSET	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

WARM LINE (WML)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	WARM_LINE	R	1FR, 1MR, IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].CUSTMOD	Y = Yes, N = No	R	1FR, 1MR, IBN, M5312	Specifies whether a customer can change the DN to which a call is forwarded when the WML time-out expires.
OPT[n].ACTIVE	Y = Yes, N = No	R	1FR, 1MR, IBN, M5312	Specifies whether the option is active.
OPT[n].DN	1-18 digits, or N or $ for nil DN	O	1FR, 1MR, IBN, M5312	Specifies the DN to which a call is forwarded when the WML expires.
OPT[n].NPA	3 digits	O	1FR, 1MR, IBN, M5312	Specifies the NPA to which a call is forwarded when the WML expires.
OPT[n].NXX	3 digits	O	1FR, 1MR, IBN, M5312	Specifies the NXX to which a call is forwarded when the WML expires.
OPT[n].LINE	4 digits	O	1FR, 1MR, IBN, M5312	Specifies the LINE to which a call is forwarded when the WML expires.
OPT[n].TIMEOUT	1-20	R	1FR, 1MR, IBN, M5312	Specifies the length of time in seconds before an unanswered call is automatically forwarded.

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FTCODE	Y = Yes, N = No	O	1FR, 1MR, IBN, M5312	Enter Y to allow subscriber to dial octothorpe (#) to access MDC features. Enter N to allow subscriber to dial # to override Warm Line feature timer. FTCODE is prompted when office parameter WML_OCT_IS_LINE_OPT_PARM is set to Y.

where n = index starting from 1

WAKE UP (WUC)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	WAKE_UP	R	IBN, M5312	Feature flag
OPT[n].OPTKEY	1 to 69 for business set	O	M5312	Identifies key on business set (for M series LCC type) to which an option is assigned.

where n = index starting from 1

WAKE UP REMINDER (WUCR)

Parameter label	Parameter value	Required (R) / Optional (O)	LCC type	Description
OPT[n].FEATURE	WAKE_UP_REMINDER	R	1FR, 1MR	Feature flag