
These notes are for installing and removing a gigabit interface converter (GBIC) with a bail locking mechanism into an FC-100 Host Adapter, FC-100 Hub, or Sun Enterprise Network Array interface board. Although these illustrations show the GBIC being inserted into an FC-100 Host Adapter, the procedure is the same for all three devices.

For GBICs without a bail, refer to the documentation that was shipped with the device into which you are installing the GBIC.


Installing the GBIC

1. Unwrap the GBIC and pull out the dust covers.
2. With the bail in the unlock position, insert the GBIC into an available port. The unlock position is with the bail near the top of the GBIC.


GBICs are keyed to prevent improper insertion; they can only be installed as shown below.



Caution – Forcing a GBIC into a port can damage the GBIC and/or port. Use minimal pressure when inserting the GBIC.




3. Move the bail down into the lock position.



4. Pull lightly on the bail to ensure that it is properly locked into place.
5. Connect a fiber optic cable to the GBIC.

Fiber optic cables are keyed to prevent improper insertion; they can only be installed as shown below.




Removing the GBIC

1. Disconnect the fiber optic cable connector from the GBIC.



Caution – You must remove the fiber optic cable from the GBIC before removing the GBIC.

2. Move the bail to the unlocked position.



3. Pull on the bail's plastic tab to remove the GBIC.

Ordering Sun Documents

SunDocsSM is a distribution program for technical documentation and is available from SunExpress. You can find a full listing of available documentation on the World Wide Web:

<http://www.sun.com/sunexpress/>

To order or for more information:

Telephone: 1-800-873-7869 (United States and Canada only)

Fax: 1-800-944-0661 (United States and Canada only)

Reader Comments

Your comments and suggestions are important to us. Please let us know what you think about the *GBIC Installation and Removal*, part number 805-3885-10.

You can send detailed comments via email to smcc-docs@sun.com, or

Copyright 1997 Sun Microsystems, Inc. All rights reserved. Use is subject to license terms. Third-party software, including font technology, is copyrighted and licensed from Sun suppliers. Sun, Sun Microsystems, the Sun Logo, SunDocs, and Solaris are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries. **RESTRICTED RIGHTS:** Use, duplication, or disclosure by the U.S. Government is subject to restrictions of FAR 52.227-14(g)(2)(6/87) and FAR 52.227-19(6/87), or DFAR 252.227-7015(b)(6/95) and DFAR 227.7202-3(a).

Copyright 1997 Sun Microsystems, Inc. Tous droits réservés. Distribué par des licences qui en restreignent l'utilisation. Le logiciel détenu par des tiers, et qui comprend la technologie relative aux polices de caractères, est protégé par un copyright et licencié par des fournisseurs de Sun, Sun Microsystems, le logo Sun, SunDocs, et Solaris sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unit et dans d'autres pays.



GBIC Installation and Removal