


# Tekelec T1100 AS DC ELAP Breaker Settings

The following shows the breaker settings for the Tekelec T1100 AS in an DC ELAP configuration:

**Figure 1.** DC ELAP Breaker Settings



## Tekelec T1100 APS DC ELAP Breaker Settings