








Backup Procedure Locator

This card provides the locations of the backup procedures for the various Tekelec[®] products. Each section lists the Tekelec product, followed by the location and title of the backup procedure.

 EAGLE 5 ISS Backup Procedures <i>EAGLE 5 ISS Maintenance Manual</i> - Chapter 2 Backup the Database - Daily	 ELAP Backup Procedures <i>T1100 AS MPS Platform Software and Maintenance Manual</i> - Chapter 3 Backing Up the RTDB
 EPAP Backup Procedures <i>EPAP Administration Manual</i> - Chapter 3 Automatic PDB/RTDB Backup	 LSMS <i>Tekelec LSMS Maintenance Manual</i> - Chapter 4 Using Backup Procedures
 <i>T1000 AS MPS Platform Software and Maintenance Manual</i> - Chapter 3 Backing Up the RTDB (for manual backup) Backing Up the PDB (for manual backup)	