Sun Server X2-8 Animated Service Procedures

ORACLE



1 Choose a procedure

- Components
- Antistatic Precautions
- FEM Removal (CRU)
- FEM Installation (CRU)
- REM Removal (CRU)
- REM Installation (CRU)
- DIMM Removal (CRU)
- DIMM Installation (CRU)
- Battery Replacement (CRU)
- CPU and Heatsink Removal (FRU)
- CPU and Heatsink Installation (FRU)

2 Perform the steps

- CMOD Close-up
- FEM Close-up (CRU)
- REM Close-up (CRU)
- CMOD Battery Close-up (CRU)
- DIMM Close-up (CRU)
- CPU Close-up (FRU)
- Heatsink Close-up (FRU)

Components

CMOD Close-up

On the front of the server chassis and within the ILOM interfaces (web and command-line), the CMODs are designated as BL 0 through BL 3.

Chassis and ILOM Designation
CMOD 3 -BL 3
CMOD 2 -BL 2

- Click a step above to play or replay.
- Click & drag on the model at any time to examine it from any view.
- Right click the model for a menu with 3D view and tool options.

Acrobat Reader 9.0+ Required

Copyright © 2010, 2011, Oracle and/or it's affiliates. All rights reserved. Legal notices link.