

**Oracle® ZFS Storage Appliance Object  
API Guide for Amazon S3 Service  
Support, Release OS8.8.x**

**ORACLE®**

**Part No: F13774-02**  
August 2021



**Part No: F13774-02**

Copyright © 2019, 2021, Oracle and/or its affiliates.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, then the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs (including any operating system, integrated software, any programs embedded, installed or activated on delivered hardware, and modifications of such programs) and Oracle computer documentation or other Oracle data delivered to or accessed by U.S. Government end users are "commercial computer software" or "commercial computer software documentation" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, reproduction, duplication, release, display, disclosure, modification, preparation of derivative works, and/or adaptation of i) Oracle programs (including any operating system, integrated software, any programs embedded, installed or activated on delivered hardware, and modifications of such programs), ii) Oracle computer documentation and/or iii) other Oracle data, is subject to the rights and limitations specified in the license contained in the applicable contract. The terms governing the U.S. Government's use of Oracle cloud services are defined by the applicable contract for such services. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Inside are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Epyc, and the AMD logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information about content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services unless otherwise set forth in an applicable agreement between you and Oracle. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.

**Documentation Accessibility**

For information about Oracle's commitment to accessibility, visit the Oracle Accessibility Program website at <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=docacc>.

**Access to Oracle Support**

Oracle customers that have purchased support have access to electronic support through My Oracle Support. For information, visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> or visit <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> if you are hearing impaired.

**Référence: F13774-02**

Copyright © 2019, 2021, Oracle et/ou ses affiliés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf stipulation expresse de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, accorder de licence, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est livré sous licence au Gouvernement des Etats-Unis, ou à quiconque qui aurait souscrit la licence de ce logiciel pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique :

U.S. GOVERNMENT END USERS: Oracle programs (including any operating system, integrated software, any programs embedded, installed or activated on delivered hardware, and modifications of such programs) and Oracle computer documentation or other Oracle data delivered to or accessed by U.S. Government end users are "commercial computer software" or "commercial computer software documentation" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, reproduction, duplication, release, display, disclosure, modification, preparation of derivative works, and/or adaptation of i) Oracle programs (including any operating system, integrated software, any programs embedded, installed or activated on delivered hardware, and modifications of such programs), ii) Oracle computer documentation and/or iii) other Oracle data, is subject to the rights and limitations specified in the license contained in the applicable contract. The terms governing the U.S. Government's use of Oracle cloud services are defined by the applicable contract for such services. No other rights are granted to the U.S. Government.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer un risque de dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour des applications dangereuses.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

Intel et Intel Inside sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. AMD, Epyc, et le logo AMD sont des marques ou des marques déposées d'Advanced Micro Devices. UNIX est une marque déposée de The Open Group.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers, sauf mention contraire stipulée dans un contrat entre vous et Oracle. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation, sauf mention contraire stipulée dans un contrat entre vous et Oracle.

**Accessibilité de la documentation**

Pour plus d'informations sur l'engagement d'Oracle pour l'accessibilité de la documentation, visitez le site Web Oracle Accessibility Program, à l'adresse : <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=docacc>.

**Accès aux services de support Oracle**

Les clients Oracle qui ont souscrit un contrat de support ont accès au support électronique via My Oracle Support. Pour plus d'informations, visitez le site <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=info> ou le site <http://www.oracle.com/pls/topic/lookup?ctx=acc&id=trs> si vous êtes malentendant.

# Contents

---

<b>Getting Started with the Oracle ZFS Storage Appliance S3 Object API Service</b> .....	9
Preparing S3 API Compatible Clients .....	9
s3cmd .....	10
Boto and Boto3 .....	12
CloudBerry .....	14
Cyberduck .....	14
JetS3t Cockpit .....	16
Protocol Ports Requirements for Amazon S3 .....	18
Interoperability With Other Data Access Protocols .....	18
S3 API Usage Guidelines .....	19
Authentication for S3 API .....	20
Supported Authorization Versions .....	20
Authenticating Requests .....	21
Supported and Unsupported S3 API Operations .....	21
Supported S3 Operations on Buckets .....	21
Supported S3 Operations on Objects .....	22
Unsupported S3 Operations on Buckets .....	23
Unsupported S3 Operations on Objects .....	24
Supported and Unsupported Header Requests .....	24
Supported Common Request Headers .....	25
Unsupported Request Headers .....	26
Supported and Unsupported Response Headers .....	26
Supported Common Response Headers .....	26
Unsupported Common Response Headers .....	28
Unsupported Configuration for ZFS Data Features .....	28
<b>Working with the Oracle ZFS Storage Appliance S3 Object API Service</b> .....	31
Key Concepts and Elements for Accessing Resources .....	31

Making Requests Using the S3 Object API .....	33
Controlling Access to Resources Using S3 ACLs .....	33
Specifying S3 ACL Permissions .....	34
Supported S3 ACL Permissions .....	36
Protecting Your Data with S3 Object Versioning .....	37
<b>S3 Object API Operation Command Reference .....</b>	<b>39</b>
Operations on Services .....	39
GET Service .....	39
Operations on Buckets .....	41
GET Bucket .....	41
GET Bucket ACL .....	43
GET Bucket Object Versioning .....	45
GET Bucket Tagging .....	48
GET Bucket Versioning .....	50
HEAD Bucket .....	52
PUT Bucket .....	53
PUT Bucket ACL .....	55
PUT Bucket Tagging .....	57
PUT Bucket Versioning .....	59
DELETE Bucket .....	61
DELETE Bucket Tagging .....	63
Operations on Objects .....	64
GET Object .....	65
GET Object ACL .....	67
GET Object Tagging .....	70
HEAD Object .....	72
OPTIONS Object .....	74
PUT Object .....	74
PUT Object Copy .....	77
PUT Object ACL .....	80
PUT Object Tagging .....	83
POST Object .....	85
DELETE Object .....	89
DELETE Object Tagging .....	91
 <b>S3 Client Error Handling Reference .....</b>	 <b>95</b>

Error Response Format .....	95
S3 Client Error Codes .....	95





# Getting Started with the Oracle ZFS Storage Appliance S3 Object API Service

---

The Oracle ZFS Storage Appliance S3 Object API Service enables Amazon S3 clients and applications to store content on an Oracle ZFS Storage Appliance filesystem. The following sections provide information to help you get started with using the Oracle ZFS Storage Appliance S3 Object API Service.

- [“Preparing S3 API Compatible Clients” on page 9](#)
- [“Protocol Ports Requirements for Amazon S3” on page 18](#)
- [“Interoperability With Other Data Access Protocols” on page 18](#)
- [“S3 API Usage Guidelines” on page 19](#)
- [“Authentication for S3 API” on page 20](#)
- [“Supported and Unsupported S3 API Operations” on page 21](#)
- [“Supported and Unsupported Header Requests” on page 24](#)
- [“Unsupported Configuration for ZFS Data Features” on page 28](#)

## Related Information

- [Oracle ZFS Storage Appliance RESTful API Guide, Release OS8.8.x](#)
- [Using Oracle Cloud Infrastructure Object Storage Classic](#)

## Preparing S3 API Compatible Clients

The Oracle ZFS Storage Appliance S3 Object API Service supports the following Amazon S3 compatible clients.

---

**Note** - Other S3 compatible clients might work but have not been tested.

---

- [“s3cmd” on page 10](#)

- [“Boto and Boto3” on page 12](#)
- [“CloudBerry” on page 14](#)
- [“Cyberduck” on page 14](#)
- [“JetS3t Cockpit” on page 16](#)

## s3cmd

The following sections provide example information to help you install, configure, and use the s3cmd command-line tool that is an independent development of the official s3cmd tool. For additional information about this tool, refer to the product documentation listed under [“Related Information” on page 12](#).

### Installation Example: s3cmd Client

---

**Note** - The Oracle ZFS Storage Appliance S3 Object API Service does *not* support the official s3cmd command-line client tool.

---

In this example, the GitHub address is used to clone and install the eucaIyptus/s3cmd client.

```
git clone https://github.com/eucaIyptus/s3cmd
cd s3cmd
python setup.py install
```

### Configuration Example: s3cmd Client

Prior to accessing the Oracle ZFS Storage Appliance S3 Object API Service, the eucaIyptus/s3cmd client must be configured. The following example creates a default configuration file manually, which eliminates a need to provide an s3cfg file for each client session.

```
cat s3cfg

[default]
access_key = your_access_key-ID
host_base = hostname.example.com
host_bucket = hostname.example.com
service_path = /s3/v1/export/S3_enabled_share
use_https = False
secret_key = your_secret key
```

Where:

- The access\_key property points to the key required for S3 Authentication. For additional details, see [“Authentication for S3 API” on page 20](#).

- The `host_base` and `host_bucket` properties point to the network address of the Oracle ZFS Storage Appliance system.
- The `service_path` property points to the share object store that was enabled for S3 service.
- The `use_https` property enables you set the HTTPS service. For instance, set the `use_https` property to `False` to disable the HTTPS service or set it to `True` to enable the HTTPS service.
- The `secret_key` property points to the secret key generated for S3 authentication.

### Usage Examples: s3cmd Client

The following examples show interaction with the Oracle ZFS Storage Appliance S3 Object API Service. Additional usage information about the `s3cmd` command-line tool is available at the [S3 Tools web site](#).

List all buckets:

```
s3cmd -c s3cfg ls
```

Create a new bucket named `new_bucket`:

```
s3cmd -c s3cfg mb s3://new_bucket
```

Upload file `abc.txt` to `new_bucket`:

```
s3cmd -c s3cfg put abc.txt s3://new_bucket
```

List all objects in `new_bucket`:

```
s3cmd -c s3cfg ls s3://new_bucket
```

Download object `abc.txt` from `new_bucket` to a new file `abc.2.txt`:

```
s3cmd -c s3cfg get s3://new_bucket/abc.txt abc.2.txt
```

Delete object `abc.txt` from `new_bucket`:

```
s3cmd -c s3cfg del s3://new_bucket/abc.txt
```

Delete bucket `new_bucket`:

```
s3cmd -c s3cfg rb s3://new_bucket
```

Enable debug mode:

```
s3cmd -c s3cfg cmd parameters --debug
```

## Related Information

- See [HowTo use s3cmd with Eucalyptus](#) on the GitHub web site.
- See the [S3 Tools web site](#) for Amazon S3 tools and usage.
- See [Amazon S3 Compatibility API](#) in Oracle Cloud Infrastructure Documentation.

## Boto and Boto3

The following sections provide example information to help you install, configure, and use the Boto and Boto3 command-line tools. For additional information about these tools, refer to the product documentation listed under “[Related Information](#)” on page 13.

---

**Note** - Boto and Boto3 are client functions in Amazon Web Services (AWS) Software Development Kit (SDK) for python. Boto3 is the next generation of Boto and is available for general use.

---

### Installation Example: Boto and Boto3

Install the latest version of Boto or Boto3 using pip, for example:

```
pip install boto
```

```
pip install boto3
```

### Configuration Example: Boto and Boto3

Prior to using Boto (or Boto3), you need to set up authentication credentials. Authentication credentials can be configured in multiple ways. For instance, you can pass authentication credentials as parameter methods, environmental variables, or within a file such as a shared credentials file or an AWS configuration file. The following example defines the authentication credentials in an AWS configuration file.

```
cat ~/.aws/credentials

[default]

aws_access_key_id = YOUR_ID

aws_secret_access_key = YOUR_SECRET
```

### Usage Examples: Boto and Boto3

The following Boto and Boto3 examples show interaction with the Oracle ZFS Storage Appliance S3 Object API Service.

**Boto:**

```
#!/usr/bin/env python

import boto
import boto.s3.connection

access_key = 'coma-04042017'
secret_key = 'd0f8c646dc4303930c547b85ef549ce80aa0709f4720436ab8f24afeaebf80b9'

conn = boto.connect_s3(
    aws_access_key_id = coma-04042017,
    aws_secret_access_key =
d0f8c646dc4303930c547b85ef549ce80aa0709f4720436ab8f24afeaebf80b9,
    host = "x4200-85.us.example.com", # Storage appliance host name.
    port = 443,                       # Set to HTTPS port number for HTTPS connection.
    is_secure=True,                   # Set to True for HTTPS connection.
    debug = 2,
    path = "/s3/v1/export/coma",      # Configured share S3 filesystem.
    calling_format=boto.s3.connection.OrdinaryCallingFormat()
)

bucket = conn.create_bucket('new_bucket')
```

**Boto3:**

```
#!/usr/bin/env python

import boto3

access_key = 'open-sesame'
secret_key = 'ddc37fc17a3837dcb4757612cefa8f4cf0be9508b51b6d6a1087c24e3d7da95f'

b3_session = boto3.Session(aws_access_key_id=access_key,
                           aws_secret_access_key=secret_key,
                           region_name='lalaland')

b3_client = b3_session.client('s3', endpoint_url="https://192.0.2.0/s3/v1/export/
mystore")

bucket = b3_client.create_bucket(Bucket="newbucket")
```

**Related Information**

- See the [GitHub boto web site](#) for the latest versions of Boto or Boto3.
- See the [Boto 3 Documentation](#) for installation, configuration, and use with Amazon S3.

## CloudBerry

The following sections provide example information to help you install, configure, and use CloudBerry backup tools. For additional information about this tool, refer to the [CloudBerry web site](#).

### Installation: CloudBerry

Download and install the appropriate version from the CloudBerry web site.

### Configuration Example: CloudBerry

The following CloudBerry Client configuration is based on Windows 10. To configure an S3 compatible account, perform the following:

1. In the Select Cloud Storage dialog box, choose S3 Compatible.
2. In the S3 Storage Account dialog box, do the following:
  - Enter the access key, secret key, and the service point.  
Note that the service point is provided on the Oracle ZFS Storage Appliance share protocol. For example:

```
https://appliance_hostname.example.com/s3/v1/export/S3_enabled_sharename/
```

Do not omit the trailing /.

- In the Bucket name field, specify a new bucket name or an existing one.
- Click Advanced Settings and clear the SSL check box.

### Usage: CloudBerry

Start backing up files by (1) selecting the S3 compatible account that you just created and (2) following the CloudBerry backup plan and restore plan wizard.

## Cyberduck

The following sections provide example information to help you install, configure, and use the Cyberduck S3 compatible browser. For additional information about this S3 compatible browser, refer to the [Cyberduck web site](#).

### Installation: Cyberduck

Download and install the appropriate version from the Cyberduck web site.

### Configuration Example: Cyberduck

The configuration is based on a Cyberduck client on Windows 10. The default Cyberduck S3 profile does *not* support the Oracle ZFS Storage Appliance S3 API. An Oracle ZFS Storage Appliance cyberduck profile template must be created manually. See the following examples:

#### Oracle ZFS Storage Appliance S3 (HTTPS) Cyberduck Profile:

The Oracle ZFS Storage Appliance S3 (HTTPS) Cyberduck profile uses S3 signature v4 (recommended version).

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE plist PUBLIC "-//Apple//DTD PLIST 1.0//EN" "https://www.apple.com/DTDs/PropertyList-1.0.dtd">
<plist version="1.0">
  <dict>
    <key>Protocol</key>
    <string>s3</string>
    <key>Vendor</key>
    <string>s3-https</string>
    <key>Scheme</key>
    <string>https</string>
    <key>Description</key>
    <string>S3 (HTTPS)</string>
    <key>Default Port</key>
    <string>443</string>
    <key>Hostname Configurable</key>
    <true/>
    <key>Port Configurable</key>
    <true/>
    <key>Context</key>
    <string>/s3/v1/export/SHARE</string>
  </dict>
</plist>
```

#### Oracle ZFS Storage Appliance AWS2 Signature Version (HTTPS) Cyberduck Profile:

The Oracle ZFS Storage Appliance AWS2 Signature Version (HTTPS) Cyberduck profile uses S3 signature v2.

```
<?xml version="1.0" encoding="UTF-8"?>
<!DOCTYPE plist PUBLIC "-//Apple//DTD PLIST 1.0//EN" "https://www.apple.com/DTDs/PropertyList-1.0.dtd">
<plist version="1.0">
  <dict>
    <key>Protocol</key>
    <string>s3</string>
    <key>Vendor</key>
    <string>s3-aws2-https</string>
    <key>Scheme</key>
```

```

    <string>https</string>
    <key>Description</key>
    <string>S3 AWS2 Signature Version (HTTPS)</string>
    <key>Default Port</key>
    <string>443</string>
    <key>Hostname Configurable</key>
    <true/>
    <key>Port Configurable</key>
    <true/>
    <key>Authorization</key>
    <string>AWS2</string>
    <key>Context</key>
    <string>/s3/v1/export/SHARE</string>
  </dict>
</plist>

```

In both templates, you need to change "SHARE" in the "Context" keyword to the share that has s3 service enabled. For example, you can change it to `/s3/v1/export/S3_enabled_share`.

```

<key>Context</key>

<string>/s3/v1/export/S3_enabled_share</string>

```

### Cyberduck GUI-based Configuration:

1. Double-click the profile file you just created. An S3 configuration dialog box appears.
2. In the S3 configuration dialog box, specify the server address that points to the appliance. For example, `appliance_hostname.example.com`
3. In the S3 configuration dialog box, click Close. An S3 bookmark for the Oracle ZFS Storage Appliance system appears.
4. Double-click the bookmark. A Login dialog box appears.
5. In the Login dialog box, specify the required Access Key and Secret Keys, then click Login. You have successfully logged in to your Cyberduck S3 account.

### Usage: Cyberduck

Cyberduck works as a file explorer, enabling you to browse Amazon S3 storage service such as a hard disk.

## JetS3t Cockpit

The following sections provide example information to help you install, configure, and use the JetS3t Cockpit application. For additional information about this application, refer to the product documentation listed under [“Related Information” on page 18](#).



---

**Note** - JetS3t is a free, open-source Java toolkit and application suite for Amazon S3, Amazon CloudFront, and Google Storage for Developers. JetS3t Cockpit is a graphical Java application for viewing and managing AWS S3 content.

---

### Installation: JetS3t Cockpit

Download the zip package from the GitHub [JetS3t site](#). Unzip the package. Download Java JRE and JDK to use appliance and library.

### Configuration Example: JetS3t Cockpit

To configure JetS3t Cockpit on Windows 10, follow these steps:

- Under the jets3t package root, look for "RestS3Service, then edit configs/jets3t properties as follows:
  - In the s3service.s3-endpoint=*property* , specify the network name for the appliance connection.
  - Specify the shared repository that is enabled for S3 by inserting the following line immediately after the line s3service.s3-endpoint=:

```
s3service.s3-endpoint-virtual-path=/s3/v1/export/S3_enabled_share
```

Replace *S3\_enabled\_share* with the name of the S3 enabled share.

- Change the property value for buckets= from false to true.

```
###
```

```
# RestS3Service
```

```
###
```

```
s3service.https-only=true # if required, change from 'true' to 'false'
```

```
s3service.s3-endpoint=hostname.example.com # Storage appliance host name.
```

```
s3service.s3-endpoint-virtual-path=/s3/v1/export/S3_enabled_share # insert this line.
```

```
s3service.s3-endpoint-http-port=80
```

```
s3service.s3-endpoint-https-port=443
```

```
s3service.disable-dns-buckets=true # change from 'false' to 'true'.
```

```
s3service.default-bucket-location=US
```

```
s3service.enable-storage-classes=true
```

```
s3service.default-storage-class=STANDARD
```

- Browse to the bin directory and double-click cockpit.bat. (/cockpit.sh if in Linux)  
The JetS3t Cockpit Login dialog box appears.

3. In the JetS3t Cockpit Login dialog box, click the Direct Login tab, and enter the Access and Secret Keys, then click Login.

You have successfully logged in to the JetS3t Cockpit account.

**Usage: JetS3t Cockpit**

Use the JetS3t Cockpit interface like a file explorer. If you want to use the jets3t library, refer to the JetS3t programmer guide and code samples for more information.

**Related Information**

See the JetS3t site for the [Programmer Guide](#), including code samples.

## Protocol Ports Requirements for Amazon S3

The Oracle ZFS Storage Appliance S3 Object API operates on the following ports:

**TABLE 1** S3 Protocol Ports

Port Number	Protocol
443	HTTPS
80	HTTP

---

**Note** - HTTP(S) requests sent to Oracle ZFS Storage Appliance that start with /s3/ are intended for the Oracle ZFS Storage Appliance S3 API.

---

## Interoperability With Other Data Access Protocols

The following list defines interoperability limitations between the S3 protocol and other data access protocols:

---

**Note** - Other data access protocols include SWIFT API, NFS, SMB, WebDAV, and so on.

---

- **Container and Bucket** – A Swift container will appear as a bucket through S3 and a bucket as a container through Swift.

- **S3 Access** – Any change made by another protocol to the Oracle ZFS Storage Appliance Access Control Lists (ACLs) will have a direct effect on S3 access. The S3 Object API automatically ignores the Oracle ZFS Storage Appliance ACLs that cannot be mapped to S3 ACLs. Access to an object or bucket is dependent on the appliance ACL associations. Do *not* change the appliance ACLs on a filesystem or any of its contents via another protocol.
- **Read and Write Mode** – It is advisable to keep all other protocols in read-only mode when S3 is in read/write mode. If an object is edited by another protocol, users might see unexpected results the next time a request is made to retrieve the object. For instance, an edit from another protocol will be detected and checksums will be recalculated the next time the object is accessed using the S3 API.
- **DLO and Versioning Operations** – Complex operations like Dynamic Large Object (DLO) and versioning are *not* supported for interoperability between SWIFT and S3. These operations, which are very protocol specific, will not work across object protocols. DLO and versioned objects will appear like normal objects from the other protocol. It is advisable to maintain caution when dealing with such objects as accidental deletion or editing could break the functionality for the other protocol.
- **User-Defined Metadata** – User-defined metadata can be stored using either SWIFT or S3. User-defined metadata stored by one of the object protocols can then be retrieved by the other protocol. Note that S3 only allows setting of user-defined metadata for objects, whereas Swift allows it for containers and objects. The user metadata for containers will not be visible from S3.
- **Bucket Access** – Only the object and bucket creator (owner) is permitted access to the object and bucket from the other protocols.

## S3 API Usage Guidelines

The following table describes usage guidelines for naming or mapping S3 API bucket directories and objects.

**TABLE 2** Usage Guidelines: S3 API

No.	Guideline Description
1	The S3 API creates subdirectories in bucket for each / it encounters in the object's name.  For example, when the user uploads an object called <code>accounting/billing.pdf</code> , a directory called <code>accounting</code> is created in the bucket.
2	Objects that are mapped to the Oracle ZFS Storage Appliance directories, such as an object with names that end with /, cannot store content for themselves. However, content can be created in them.  For example: object <code>foo/</code> cannot have any data associated with it but object <code>foo/bar</code> can.
3	Any file name not permitted by the Oracle ZFS Storage Appliance filesystem is also not permitted while creating objects in the S3 API.

No.	Guideline Description
	For example, objects names with any of the following characters are not permitted: //, /, .. Object names containing double // are also not permitted (foo//bar).
4	Object names that are relative paths are not permitted.  For example, ../../../../foo is not permitted.
5	Oracle ZFS Storage Appliance limits file and directory names to 255 characters. The same character limit (255) applies to the virtual directory names and object names for the Oracle ZFS Storage Appliance S3 API.
6	When bucket versioning is either enabled or suspended, take the following naming conventions into consideration: <ul style="list-style-type: none"> <li>■ When versioning is enabled for a bucket, previous versions are saved in the same directory as the current version of the object.</li> <li>■ The current version of an object is renamed when a new object or delete marker takes its place. The new name of the current version follows the pattern: <i>object_name-versionId</i>. For example, <i>billing.pdf-0001</i>.</li> </ul>

## Authentication for S3 API

The following sections identify general aspects of the S3 authentication process as it relates to the Oracle ZFS Storage Appliance S3 Object API Service. For detailed S3 authentication information, refer to the following Amazon S3 documentation:

- [Signing and Authenticating REST Requests](#)
- [“Supported Authorization Versions” on page 20](#)
- [“Authenticating Requests” on page 21](#)

## Supported Authorization Versions

The Oracle ZFS Storage Appliance S3 Object API Service supports both AWS S3 authentication v2 and v4. Both versions require you to create an access key and an associated secret key for proving your identity to the system.

### Signature Version 2 Format:

Authorization: *AWS* *AWSAccessKeyId*:*Signature*

### Signature Version 4 Format (recommended):

*signature=Hex(HMAC-SHA256(SigningKey, StringtoSign))*

## Authenticating Requests

For all S3 bucket operations and object operations, Amazon uses an authorization header in all requests to provide the authentication information. When a request is made, the secret key is used to generate a signature. This signature along with the access key are sent to the server as part of the HTTP/HTTPS request. The server will retrieve the secret key using the access key and generate its own signature. When the generated signature by the system matches the signature in the request, access is granted to the user who issued the keys.

### Related Information:

- [Authenticating Requests \(AWS Signature Version 4\)](#)
- [Authenticating Requests \(AWS Signature Version 2\)](#)

## Supported and Unsupported S3 API Operations

Refer to the following sections for supported and unsupported S3 API operations on buckets and objects:

- [“Supported S3 Operations on Buckets” on page 21](#)
- [“Supported S3 Operations on Objects” on page 22](#)
- [“Unsupported S3 Operations on Buckets” on page 23](#)
- [“Unsupported S3 Operations on Objects” on page 24](#)

## Supported S3 Operations on Buckets

The following table identifies bucket operations that are supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 3** Supported S3 Bucket Operations

Operation	Amazon S3 API Documentation
GET Service	<a href="#">GET Service</a>
GET /	
DELETE Bucket	<a href="#">DELETE Bucket</a>
DELETE /	
DELETE Bucket tagging	<a href="#">DELETE Bucket tagging</a>

Operation	Amazon S3 API Documentation
DELETE /?tagging	
GET Bucket (List Objects) version 2	<a href="#">GET Bucket (List Objects) Version 2</a>
GET /?list-type=2	
GET Bucket (List Objects) version 1	<a href="#">GET Bucket (List Objects) Version 1</a>
GET Bucket acl	<a href="#">GET Bucket acl</a>
GET /?acl	
GET Bucket tagging	<a href="#">GET Bucket tagging</a>
GET /?tagging	
GET Bucket Object versions	<a href="#">GET Bucket Object versions</a>
GET /?versions	
GET Bucket versioning	<a href="#">GET Bucket versioning</a>
GET /?versioning	
HEAD Bucket	<a href="#">HEAD Bucket</a>
HEAD /	
PUT Bucket	<a href="#">PUT Bucket</a>
PUT /	
PUT Bucket acl	<a href="#">PUT Bucket acl</a>
PUT /?acl	
PUT Bucket tagging	<a href="#">PUT Bucket tagging</a>
PUT /?tagging	
PUT Bucket versioning	<a href="#">PUT Bucket versioning</a>
PUT /?versioning	

## Supported S3 Operations on Objects

The following table identifies object operations that are supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 4** Supported S3 Object Operations

Operation	Amazon S3 API Documentation
DELETE Object:	<a href="#">DELETE Object</a>
DELETE /ObjectName	

Operation	Amazon S3 API Documentation
Delete Multiple Objects POST /?delete	<a href="#">Delete Multiple Objects</a>
GET Object GET /ObjectName	<a href="#">GET Object</a>
GET Object ACL GET /ObjectName?acl	<a href="#">GET Object ACL</a>
HEAD Object HEAD /ObjectName	<a href="#">HEAD Object</a>
OPTIONS Object OPTIONS /ObjectName	<a href="#">OPTIONS object</a> If CORS is not enabled on the bucket, Amazon S3 returns a 403 Forbidden response.
POST Object POST /	<a href="#">POST Object</a> POST object is done through HTML forms.
PUT Object PUT /ObjectName	<a href="#">PUT Object</a>
PUT Object ACL PUT /ObjectName?acl	<a href="#">PUT Object acl</a>
PUT Object - Copy PUT /destinationObject	<a href="#">PUT Object - Copy</a>

## Unsupported S3 Operations on Buckets

The following table identifies bucket operations that are not supported by the Oracle ZFS Storage Appliance S3 Object API Service, including cross-origin resource sharing (CORS).

**TABLE 5** Unsupported S3 Bucket Operations

Unsupported Bucket Operation	Unsupported Bucket Operation
GET Bucket location	GET Bucket accelerate PUT Bucket accelerate
GET Bucket cors	GET Bucket website
PUT Bucket cors	PUT Bucket website
PUT Bucket cors	DELETE Bucket website

Unsupported Bucket Operation	Unsupported Bucket Operation
DELETE Bucket cors	
PUT Bucket lifecycle	GET Bucket notification
DELETE Bucket lifecycle	PUT Bucket notification
PUT Bucket policy	GET Bucket requestPayment
DELETE Bucket policy	PUT Bucket requestPayment
GET Bucket replication	GET Bucket logging
PUT Bucket replication	PUT Bucket logging
DELETE Bucket replication	
List Multipart Uploads	

In addition, the PutObjectLockConfiguration feature is not supported.

## Unsupported S3 Operations on Objects

The following table identifies object operations that are not supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 6** Unsupported S3 Object Operations

Unsupported Object Operation	Unsupported Object Operation
GET Object torrent	POST Object restore
Initiate Multipart Upload	
Upload Part	
Complete Multipart Upload	
Abort Multipart Upload	
List Parts	

## Supported and Unsupported Header Requests

The following topics identify header request behavior for the Oracle ZFS Storage Appliance S3 Object API Service.

- [“Supported Common Request Headers” on page 25](#)
- [“Unsupported Request Headers” on page 26](#)



## Supported Common Request Headers

The following table identifies the common request headers supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 7** Common Supported Request Headers

Supported Request Header	Description	Required
Authorization	The Authorization header field identifies the information required for request signature authentication. For more information, see "The Authentication Header" in <a href="#">Amazon Simple Storage Service Developer Guide</a> .	Yes <b>Note</b> - For anonymous requests, this header is not required.
Content-Length	The Content-Length header field represents the length of the message ( <i>without the headers</i> ) according to RFC 2616.	No <b>Note</b> - This header is required for PUTs and load XML operations.
Content-MD5	The Content-MD5 header field represents the base64 encoded 128-bit MD5 digest of the message ( <i>without the headers</i> ) according to RFC 1864.  This header is used as a message integrity check to verify that the data is the same data that was originally sent.	No
Date <i>or</i> x-amz-date	These header fields represents the current date and time according to the requester.  When you specify the Authorization header, you must specify either the x-amz-date or the Date header. If you specify both, the value specified for the x-amz-date header takes precedence	Yes
Expect	The Expect header field is used only when sending a request body with the property values: 100-continue. <b>Note</b> - When your application uses 100-continue as a property value, the request body is not sent until after it receives an acknowledgment. If the message is rejected based on the headers, the body of the message is not sent.	No
Host	The Oracle ZFS Storage Appliance Host FQDNT header field is required for HTTP 1.1 ( <i>most toolkits add this header automatically</i> ); optional for HTTP/1.0 requests.	Yes
x-amz-content-sha256	When using signature version 4 to authenticate a request, the x-amz-content-sha256 header field provides a hash of the request payload. For more information, see the Amazon documentation <a href="#">Signature Calculations for the Authorization Header: Transferring Payload in a Single Chunk (AWS Signature Version 4)</a> .  When uploading an object in chunks, you can set the value to STREAMING-AWS4-HMAC-SHA256-PAYLOAD to indicate that the signature covers only headers and that there is no payload. For more information, see the Amazon documentation <a href="#">Signature</a>	Yes

Supported Request Header	Description	Required
	<a href="#">Calculations for the Authorization Header: Transferring Payload in Multiple Chunks (Chunked Upload) (AWS Signature Version 4).</a>	

## Unsupported Request Headers

The following table lists request headers that are not supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 8** Unsupported Request Headers

Unsupported Request Header	Notes
x-amz-security-token	The Amazon S3 header for generating a temporary security credential is not supported by the Oracle ZFS Storage Appliance S3 API.
x-amz-server-side-encryption-customer-algorithm	These Amazon S3 headers for custom server-side encryption are not supported. Oracle ZFS Storage Appliance provides its own data encryption capability that is managed through its BUI, CLI, and REST interfaces. For more details, see <a href="#">“NFS Authentication and Encryption Options” in Oracle ZFS Storage Appliance Security Guide, Release OS8.8.x.</a>
x-amz-server-side-encryption-customer-key	
x-amz-server-side-encryption-customer-key-MD5	

## Supported and Unsupported Response Headers

The following topics identify response header behavior for the Oracle ZFS Storage Appliance S3 Object API Service.

- [“Supported Common Response Headers” on page 26](#)
- [“Unsupported Common Response Headers” on page 28](#)

## Supported Common Response Headers

The following table identifies the response headers that are common to most Amazon S3 responses.

**TABLE 9** Supported Response Headers

Supported Response Header	Description
Content-Length	The Content-Length header field identifies the response body length in bytes.

Supported Response Header	Description
	Type: String Default: None
Content-Type	The Content-Type header field identifies the MIME type of the content. For example, Content-Type: text/html; charset=utf-8 Type: String Default: None
Date	The Date header field identifies the data and time of the S3 response. For example, Wed, 01 Mar 2018 12:00:00 GMT. Type: String Default: None
ETag	The ETag header field identifies a specific version of a resource (a hash of the object). The ETag reflects changes only to the contents of an object, not its metadata. The ETag is an MD5 digest of the object data. Type: String
Server	The Server header field identifies the name of the server that created the response. Type: String Valid Value: Apache
x-amz-delete-marker	The x-amz-delete-marker identifies whether the object returned was a delete marker (true) or not (false). Type: Boolean Valid Values: true   false Default: false
x-amz-request-id	The x-amz-request-id is a value that is created by Amazon S3 to uniquely identify a request for troubleshooting purposes. Type: String Default: None
x-amz-version-id	When versioning is enabled, the x-amz-version-id identifies the version of the object. When versioning is suspended, the version ID is always null. Type: String Valid Values: null   string Default: null
x-amz-tagging-count	When the count is greater than zero, the x-amz-tagging-count returns the count of the tags associated with the object. Type: String

Supported Response Header	Description
	Default: None

## Unsupported Common Response Headers

The following table lists response headers that are not supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 10** Unsupported Response Headers

Unsupported Response Header	Notes
x-amz-restore	The x-amz-restore header is not supported by the Oracle ZFS Storage Appliance S3 API Service.
x-amz-replication-status	The x-amz-replication-status header is not supported by the S3 API. Oracle ZFS Storage Appliance provides its own remote replication capability, that is managed through its management interfaces (BUI, CLI, REST). For more details, see <a href="#">“Remote Replication” in Oracle ZFS Storage Appliance Administration Guide, Release OS8.8.x.</a>
x-amz-server-side-encryption x-amz-server-side-encryption-aws-kms-key-id x-amz-server-side-encryption-customer-algorithm x-amz-server-side-encryption-customer-key-MD5	These Amazon S3 headers for custom server-side encryption are not supported. Oracle ZFS Storage Appliance provides its own data encryption capability that is managed through its BUI, CLI, and REST interfaces. For more details, see <a href="#">“NFS Authentication and Encryption Options” in Oracle ZFS Storage Appliance Security Guide, Release OS8.8.x.</a>
x-amz-id-2	The x-amz-id-2 token is not supported by the Oracle ZFS Storage Appliance S3 API Service.  Use the x-amz-request-id response header value as an alternative solution.

## Unsupported Configuration for ZFS Data Features

The following table identifies Oracle ZFS Storage Appliance data features that are not supported by the Oracle ZFS Storage Appliance S3 Object API Service.

**TABLE 11** Unsupported Oracle ZFS Storage Appliance S3 Object API Data Features

Unsupported Feature	Notes
Encryption	The configuration of the Oracle ZFS Storage Appliance encryption data feature is not supported by the Oracle ZFS Storage Appliance S3 Object API

Unsupported Feature	Notes
	Service. However, the ZFS encryption data feature is configurable from the BUI, CLI, and REST appliance management interfaces. For details, see <a href="#">“NFS Authentication and Encryption Options” in Oracle ZFS Storage Appliance Security Guide, Release OS8.8.x.</a>
Replication	The configuration of the Oracle ZFS Storage Appliance replication data feature is not supported by the Oracle ZFS Storage Appliance S3 Object API Service. However, the ZFS replication data feature is configurable from the BUI, CLI, and REST appliance management interfaces. For details, see <a href="#">“Remote Replication” in Oracle ZFS Storage Appliance Administration Guide, Release OS8.8.x.</a>
Snapshot	The configuration of the Oracle ZFS Storage Appliance snapshot data feature is not supported by the Oracle ZFS Storage Appliance S3 Object API Service. However, the ZFS snapshot data feature is configurable from the BUI, CLI, and REST appliance management interfaces. For details, see <a href="#">“Snapshot Space Management” in Oracle ZFS Storage Appliance Administration Guide, Release OS8.8.x.</a>



# Working with the Oracle ZFS Storage Appliance S3 Object API Service


---

The following sections describe information about accessing resources, controlling access to resources, as well as supported versioning options to protect your data.

- [“Key Concepts and Elements for Accessing Resources” on page 31](#)
- [“Making Requests Using the S3 Object API” on page 33](#)
- [“Controlling Access to Resources Using S3 ACLs” on page 33](#)
- [“Protecting Your Data with S3 Object Versioning” on page 37](#)

## Key Concepts and Elements for Accessing Resources

The Oracle ZFS Object Storage Model is a share filesystem, where each share is mapped to a project or tenant. Each share is an account. Each account-share holds buckets and each bucket holds data objects. The S3 API uses these key elements to access the appliance resources. An illustration and description of these key elements follow.



- **Share** – A share is a collection of S3 buckets. In the Oracle ZFS Storage Appliance object store implementation, the exported share name represents the account name, for example: /export/account\_name\_share\_mount\_point).

---

**Note** - A share is typically associated with a departmental group-type entity. Access to resources within a share are managed by user roles. For more information about appliance user roles, see [“Configuring Users” in Oracle ZFS Storage Appliance Administration Guide, Release OS8.8.x.](#)

---

- **Bucket** – A bucket is a user-definable element in the object data path. It is a container for storing S3 data objects. In the AWS S3 architecture, buckets and objects are known as resources. For additional information about the use and configuration of buckets, see [Introduction to Amazon S3.](#)
- **Object** – Objects represent the entities stored in a bucket. Each object within a bucket is uniquely identified by a key name and version ID. On Oracle ZFS Storage Appliance, each object consist of a file and a set of metadata that describes the object.



## Making Requests Using the S3 Object API

To send a request message to Oracle ZFS Storage Appliance using the S3 Object API, the request message should include the following entities:

- **Request Type** – The request type states the action to be performed on a resource that is identified in the URI, for example:

```
GET https://appliance:443/s3/v1/export/sharename/bucketname/objectname
```

Where:

- GET is the action to be performed on the resource identified in the URI. For a list of supported actions on buckets and objects, see [“Supported and Unsupported S3 API Operations” on page 21](#).
- The following is the request URI:

```
https://appliance:443/s3/v1/export/sharename/bucketname/objectname
```

The request URI identifies the resources on which to perform actions.

Where:

- *appliance* represents the network address or DNS name of the Oracle ZFS Storage Appliance system.
- *sharename* represents the S3 account name of the share mount point upon which the action is to be performed.
- *bucketname* represents the name of the bucket upon which the action is to be performed.
- *objectname* represents the name of the object upon which the action is to be performed.
- **Request-Header Fields** – The request-header fields act as request modifiers that pass additional information to the S3 appliance. The request headers appear after the request line in the message body. For a list of supported request headers, see [“Supported and Unsupported Header Requests” on page 24](#).

## Controlling Access to Resources Using S3 ACLs

Access to AWS S3 resources are, by default, private. Only the owner of a resource has access. Optionally, resource owners can grant resource permission to other users by specifying resource-based policy options, such as Access Control Lists (ACLs).

---

**Note** - Other AWS S3 resource-based policy options such as Bucket Policies and User Policies are not supported by the Oracle ZFS Storage Appliance S3 API Service. These AWS S3 policies are similar to the appliance roles that are granted to users. For more information about the Oracle ZFS Storage Appliance roles, see [“Configuring Users” in Oracle ZFS Storage Appliance Administration Guide, Release OS8.8.x.](#)

---

**Note** - To support a unified view of the Oracle ZFS Storage Appliance filesystem from other appliance-supported protocols, S3 ACLs are automatically mapped to the equivalent appliance filesystem ACLs. For additional information about Oracle ZFS Storage Appliance ACLs, see [“Access Control Lists for Filesystems” in Oracle ZFS Storage Appliance Administration Guide, Release OS8.8.x.](#)

---

To better understand how to manage appliance resource permissions using AWS S3 ACLs, see the following topics.

- [“Supported and Unsupported Header Requests” on page 24](#)
- [“Setting ACL Policy Permissions in a Request” on page 35](#)
- [“Supported Amazon S3 Predefined User Groups” on page 35](#)
- [“Supported S3 ACL Permissions” on page 36](#)

For further details about managing access permissions with AWS S3 ACLs, see [Who Is a Grantee?](#).

## Specifying S3 ACL Permissions

S3 ACLs enable you to manage access to buckets and objects. Each bucket and object has an ACL attached to it as a subresource. It defines which user or user groups are granted access, as well as the type of access granted. For instance, when a request is received against a resource, the S3 API checks the corresponding ACL to verify that the requester has the necessary access permissions. Each time you create a bucket or object, the S3 API creates a default ACL Policy that grants the resource owner full access control over the newly created resource as shown in the following example.

**Example:** Default ACL Policy for new bucket or object.

```
<?xml version="1.0" encoding="UTF-8"?>
<AccessControlPolicy xmlns="https://s3.amazonaws.com/doc/2018-05-23/">
  <Owner>
    <ID>***Owner-Canonical-User-ID***</ID>
    <DisplayName>Bucket Owner Display Name</DisplayName>
  </Owner>
  <AccessControlList>
```

```

<Grant>
  <Grantee xmlns:xsi="https://www.w3.org/2001/XMLSchema-instance"
    xsi:type="Canonical User">
    <ID>***Canonical-User ID or Group URI***</ID>
    <DisplayName>Appliance Grantee's username</DisplayName>
  </Grantee>
  <Permission>FULL_CONTROL</Permission>
</Grant>
</AccessControlList>
</AccessControlPolicy>

```

Where:

- Owner provides the appliance canonical user ID for the owner that created the bucket.
- Grant provides the name of the grantee and the permission granted.
 

Note that the default ACL Policy includes only one Grant element for the bucket owner. To grant bucket permission to others, you need to add a Grant element for each additional user or predefined group. Each Grant element must always identify the name of the grantee, as well as the permissions granted.
- Grantee provides the name of an individual or predefined group receiving access permission.
 

The grantee can either be an authorized appliance user or an S3 predefined group. When granting access to individual appliance users, you need to specify the canonical user ID associated with the appliance user account. When granting permission to an S3 predefined group, you need to specify the predefined group URI. For a list of supported predefined groups, see [“Supported Amazon S3 Predefined User Groups” on page 35](#).
- Permission provides the type of access permission that is being granted to the grantee. For a list of supported ACL permissions, see [“Supported S3 ACL Permissions” on page 36](#).

## Setting ACL Policy Permissions in a Request

Use one of the following request methods when using S3 APIs (such as PUT/GET/DELETE) to set access policy permissions:

- When creating resources – Set the ACL permissions in the request's HTTP header.
- When editing ACLs associated with existing resources – Set the ACL permissions either in the request's HTTP header or in the request's body.

## Supported Amazon S3 Predefined User Groups

The following table describes the supported Amazon S3 predefined user groups.

**TABLE 12** Amazon S3 Predefined User Groups

Predefined User Group	Description
All Users Group	<p>The All Users Group is represented by the following URI: <code>http://acs.amazonaws.com/groups/global/AllUsers</code></p> <p>Access permission to this group enables anyone to access the resource. The requests can either be signed (authenticated) or unsigned (anonymous).</p> <p><b>Note</b> - Unsigned requests omit the Authentication header in the request. Anonymous users will be mapped to the user <code>nobody</code> in Oracle ZFS Storage Appliance.</p> <p>For security reasons, a resource owner should never grant the All Users Group any of the following permissions: <code>WRITE</code>, <code>WRITE_ACP</code>, or <code>FULL_CONTROL</code>.</p>
Authenticated Users Group	<p>The Authenticated Users Group is represented by the following URI: <code>http://acs.amazonaws.com/groups/global/AuthenticatedUsers</code></p> <p>This group represents all Oracle ZFS Storage Appliance authenticated user accounts. Access permission to this group enables any authenticated user access to the resource. Therefore, when using this group, all requests must be signed (authenticated).</p>

## Supported S3 ACL Permissions

The following tables describe the supported permissions for primary and canned ACLs:

- [Table 13, “Primary ACL: Grantee Supported Permissions,” on page 36](#)
- [Table 14, “Canned ACL: Supported Group Permissions,” on page 37](#)

---

**Note** - You can specify only one canned ACL in a request.

---

**TABLE 13** Primary ACL: Grantee Supported Permissions

Permission	When Granted on Bucket	When Granted on Object
READ	Enables grantee to list the objects in the bucket.	Enables grantee to read the object data and its metadata.
WRITE	Enables grantee to create, overwrite, and delete any object in the bucket.	Not applicable.
READ_ACP	Enables grantee to read the bucket ACL.	Enables grantee to read the object ACL.
WRITE_ACP	Enables grantee to write the ACL for the applicable bucket.	Enables grantee to write the ACL for the applicable object.
FULL_CONTROL	Allows grantee the <code>READ</code> , <code>WRITE</code> , <code>READ_ACP</code> , and <code>WRITE_ACP</code> permissions on the bucket.	Enables grantee the <code>READ</code> , <code>READ_ACP</code> , and <code>WRITE_ACP</code> permissions on the object.

**TABLE 14** Canned ACL: Supported Group Permissions

Canned ACL	Applies To	Permissions Added To ACL
private	Bucket and object	Owner gets FULL_CONTROL. No one else has access rights (default).
public-read	Bucket and object	Owner gets FULL_CONTROL. The All Users Group gets READ access.
public-read-write	Bucket and object	Owner gets FULL_CONTROL. The All Users Group gets READ and WRITE access. For security reasons, granting this canned ACL on a bucket is generally not recommended.
authenticated-read	Bucket and object	Owner gets FULL_CONTROL. The Authenticated Users Group gets READ access.
bucket-owner-read	Object	Object owner gets FULL_CONTROL. Bucket owner gets READ access. If you specify this canned ACL when creating a bucket, the appliance S3 API ignores it.
bucket-owner-full-control	Object	Both the object owner and the bucket owner get FULL_CONTROL over the object. If you specify this canned ACL when creating a bucket, the appliance S3 API ignores it.

## Protecting Your Data with S3 Object Versioning

To preserve, retrieve, and restore every version of every object stored in your Amazon versioning-enabled S3 bucket, the Oracle ZFS Storage Appliance S3 Object API Service supports the use of the following AWS S3 versioning operations.

- **Versioning-Enabled Bucket Object Operations** – The Oracle ZFS Storage Appliance S3 Object API Service supports the following versioning-enabled bucket operations:
  - Adding Objects to Versioning-Enabled Buckets
  - Listing Objects in a Versioning-Enabled Bucket
  - Retrieving Object Versions
  - Deleting Object Versions
- **Versioning-Suspended Bucket Object Operations** – The Oracle ZFS Storage Appliance S3 Object API Service supports the following versioning-suspended bucket operations:
  - Adding Objects to Versioning-Suspended Buckets
  - Retrieving Object Versions from Versioning-Suspended Buckets
  - Deleting Object Versions from Versioning-Suspended Buckets

For further details about AWS S3 versioning features, see [Using Versioning](#).



# S3 Object API Operation Command Reference

---

This reference identifies the operation commands supported by the Oracle ZFS Storage Appliance S3 Object API Service.

- [“Operations on Services” on page 39](#)
- [“Operations on Buckets” on page 41](#)
- [“Operations on Objects” on page 64](#)

## Operations on Services

The Oracle ZFS Storage Appliance S3 Object API supports the [“GET Service” on page 39](#) operation on services.

### GET Service

Returns a list of all buckets owned by the authenticated sender of the request. Anonymous requests cannot list buckets, and you cannot list buckets that you did not create. For more details, see the following:

- [“Syntax Example” on page 39](#)
- [“Request Parameters” on page 40](#)
- [“Request Headers” on page 40](#)
- [“Response Elements” on page 40](#)
- [“Normal Response Code” on page 40](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/
```

## Request Parameters

The GET Service operation does not support the use of request parameters.

## Request Headers

The GET Service operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Response Elements

For a list of supported elements in the XML response for the GET Service operation, see [GET Service](#).

## Normal Response Code

200

## Example

```
<?xml version="1.0" encoding="UTF-8"?>
<ListAllMyBucketsResult>
  <Owner>
    <ID>s3_user</ID>
    <DisplayName>s3_user</DisplayName>
  </Owner>
  <Buckets>
    <Bucket>
      <Name>quotes</Name>
      <CreationDate>2006-02-03T16:45:09.000Z</CreationDate>
    </Bucket>
    <Bucket>
      <Name>samples</Name>
      <CreationDate>2006-02-03T16:41:58.000Z</CreationDate>
    </Bucket>
  </Buckets>
</ListAllMyBucketsResult>
```



## Operations on Buckets

The Oracle ZFS Storage Appliance S3 Object API supports the following operations on buckets:

- [“GET Bucket” on page 41](#)
- [“GET Bucket ACL” on page 43](#)
- [“GET Bucket Object Versioning” on page 45](#)
- [“GET Bucket Tagging” on page 48](#)
- [“GET Bucket Versioning” on page 50](#)
- [“HEAD Bucket” on page 52](#)
- [“PUT Bucket” on page 53](#)
- [“PUT Bucket ACL” on page 55](#)
- [“PUT Bucket Tagging” on page 57](#)
- [“PUT Bucket Versioning” on page 59](#)
- [“DELETE Bucket” on page 61](#)
- [“DELETE Bucket Tagging” on page 63](#)

### GET Bucket

The GET Bucket operation returns some or all (up to 1,000) of the objects in a bucket. You can use the request parameters as selection criteria to return a subset of the objects in a bucket. For more details about this operation, see the following:

- [“Syntax Example” on page 41](#)
- [“Request Parameters” on page 42](#)
- [“Request Headers” on page 42](#)
- [“Request Elements” on page 42](#)
- [“Response Headers” on page 42](#)
- [“Normal Response Code” on page 42](#)
- [“Example Response” on page 42](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucket_name?list-type=2
```

## Request Parameters

For a list of supported request parameters, see [GET Bucket \(List Objects\) Version 2](#).

## Request Headers

The GET Bucket operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The GET Bucket operation does not support the use of request elements.

## Response Headers

The GET Bucket operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

For a list of supported elements in the XML response for the GET Bucket operation, see [GET Bucket \(List Objects\) Version 2](#).

## Normal Response Code

200

## Error Response Code

The GET Bucket operation returns special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example Response

For a list of response examples, see [GET Bucket \(List Objects\) Version 2](#).

## GET Bucket ACL

The GET Bucket ACL operation returns the Access Control List (ACL) of a bucket. To use GET to return the ACL of the bucket, you must have `READ_ACP` access to the bucket. For more details about this operation, see the following:

- [“Syntax Example” on page 43](#)
- [“Request Parameters” on page 43](#)
- [“Request Headers” on page 43](#)
- [“Request Elements” on page 43](#)
- [“Response Headers” on page 43](#)
- [“Response Elements” on page 44](#)
- [“Normal Response Code” on page 44](#)
- [“Error Response Code” on page 44](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucket_name?acl
```

### Request Parameters

The GET Bucket ACL operation does not support the use of request parameters.

### Request Headers

The GET Bucket ACL operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

### Request Elements

The GET Bucket ACL operation does not support the use of request elements.

### Response Headers

The GET Bucket ACL operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

For a list of supported elements in the XML response for the GET Bucket ACL operation, see [GET Bucket acl](#).

## Normal Response Code

200

## Error Response Code

The GET Bucket API return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
GET ?acl
HTTP/1.1 200 OK
x-amz-request-id: tx318BC8BC148832E5
Date: Wed, 28 Oct 2009 22:32:00 GMT
Last-Modified: Sun, 1 Jan 2018 12:00:00 GMT
Content-Length: 124
Content-Type: text/plain
Server: Apache
```

```
<AccessControlPolicy>
  <Owner>
    <ID>john</ID>
    <DisplayName>mary</DisplayName>
  </Owner>
  <AccessControlList>
    <Grant>
      <Grantee xsi:type="CanonicalUser">
        <ID>jane</ID>
        <DisplayName>Bob</DisplayName>
      </Grantee>
      <Permission>FULL_CONTROL</Permission>
    </Grant>
  </AccessControlList>
</AccessControlPolicy>
```

## GET Bucket Object Versioning

The GET Bucket Object Versioning operation lists metadata about all of the object versions in a bucket. Additionally, you can use request parameters as selection criteria to return metadata about a subset of all the object versions. For more details about this operation, see the following:

- “Syntax Example” on page 45
- “Request Parameters” on page 45
- “Request Headers” on page 43
- “Request Elements” on page 45
- “Response Headers” on page 46
- “Response Elements” on page 46
- “Normal Response Code” on page 46
- “Error Response Code” on page 46

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?versions
```

### Request Parameters

For a list of supported request parameters, see [GET Bucket Object versions](#).

### Request Headers

The GET Bucket Object Versioning operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

### Request Elements

The GET Bucket Object Versioning operation does not support the use of request elements.

## Response Headers

The GET Bucket Object Versioning operation uses only response headers that are common to most responses. For more information, [Table 9, “Supported Response Headers,” on page 26.](#)

## Response Elements

For a list of supported response elements, see [GET Bucket Object versions.](#)

## Normal Response Code

200

## Error Response Code

The GET Bucket Object Versioning API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95.](#)

## Example

---

**Note** - For additional request and response examples, see [GET Bucket Object versions.](#)

---

```
GET /?versions
<?xml version="1.0" encoding="UTF-8"?>

<ListVersionsResult>
  <Name>bucket</Name>
  <Prefix>my</Prefix>
  <KeyMarker/>
  <VersionIdMarker/>
  <MaxKeys>5</MaxKeys>
  <IsTruncated>>false</IsTruncated>
  <Version>
    <Key>my-image.jpg</Key>
    <VersionId>003</VersionId>
    <IsLatest>>true</IsLatest>
    <LastModified>2018-10-12T17:50:30.000Z</LastModified>
    <ETag>"fba9dede5f27731c9771645a39863328"</ETag>
    <Size>434234</Size>
    <StorageClass>STANDARD</StorageClass>
```

```

    <Owner>
      <ID>mary</ID>
      <DisplayName>mary</DisplayName>
    </Owner>
  </Version>
  <DeleteMarker>
    <Key>my-second-image.jpg</Key>
    <VersionId>001</VersionId>
    <IsLatest>true</IsLatest>
    <LastModified>2009-11-12T17:50:30.000Z</LastModified>
    <Owner>
      <ID>jill</ID>
      <DisplayName>jill</DisplayName>
    </Owner>
  </DeleteMarker>
  <Version>
    <Key>my-second-image.jpg</Key>
    <VersionId>002</VersionId>
    <IsLatest>>false</IsLatest>
    <LastModified>2009-10-10T17:50:30.000Z</LastModified>
    <ETag>&quot;9b2cf535f27731c974343645a3985328&quot;</ETag>
    <Size>166434</Size>
    <StorageClass>STANDARD</StorageClass>
    <Owner>
      <ID>jill</ID>
      <DisplayName>jill</DisplayName>
    </Owner>
  </Version>
  <DeleteMarker>
    <Key>my-third-image.jpg</Key>
    <VersionId>002</VersionId>
    <IsLatest>true</IsLatest>
    <LastModified>2009-10-15T17:50:30.000Z</LastModified>
    <Owner>
      <ID>moe</ID>
      <DisplayName>moe</DisplayName>
    </Owner>
  </DeleteMarker>
  <Version>
    <Key>my-third-image.jpg</Key>
    <VersionId>001</VersionId>
    <IsLatest>>false</IsLatest>
    <LastModified>2009-10-11T12:50:30.000Z</LastModified>
    <ETag>&quot;772cf535f27731c974343645a3985328&quot;</ETag>
    <Size>64</Size>
    <StorageClass>STANDARD</StorageClass>
    <Owner>
      <ID>moe</ID>

```

```
        <DisplayName>moe</DisplayName>
      </Owner>
    </Version>
  </ListVersionsResult>
```

## GET Bucket Tagging

The GET Bucket Tagging operation returns the tag set associated with the bucket. For more details about this operation, see the following:

- [“Syntax Example” on page 48](#)
- [“Request Parameters” on page 48](#)
- [“Request Headers” on page 48](#)
- [“Request Elements” on page 48](#)
- [“Response Headers” on page 49](#)
- [“Response Elements” on page 49](#)
- [“Normal Response Code” on page 49](#)
- [“Error Response Code” on page 49](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?tagging
```

### Request Parameters

The GET Bucket Tagging operation does not support the use of request parameters.

### Request Headers

The GET Bucket Tagging operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

### Request Elements

The GET Bucket Tagging operation does not support the use of request elements.



## Response Headers

The GET Bucket Tagging operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

For a list of supported response elements, see [GET Bucket tagging](#).

## Normal Response Code

200

## Error Response Code

The GET Bucket Tagging operation does not return errors associated with a bucket. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
GET /?tagging
HTTP/1.1 200 OK
Date: Wed, 25 Nov 2018 12:00:00 GMT
Connection: close
Server: Apache
```

```
<Tagging>
  <TagSet>
    <Tag>
      <Key>Project</Key>
      <Value>Project One</Value>
    </Tag>
    <Tag>
      <Key>User</Key>
      <Value>msmith</Value>
    </Tag>
  </TagSet>
</Tagging>
```

## GET Bucket Versioning

The GET Bucket Versioning operation returns the versioning state of a bucket. To retrieve the versioning state of a bucket, you must be the bucket owner. The following versioning states apply to this operation:

- When versioning is enabled on a bucket, the response is as follows:  

```
<VersioningConfiguration> <Status>Enabled</Status> </VersioningConfiguration>
```
- When versioning is suspended on a bucket, the response is as follows:  

```
<VersioningConfiguration> <Status>Suspended</Status> </VersioningConfiguration>
```
- When versioning is not enabled or suspended on a bucket, the response is as follows:  

```
<VersioningConfiguration/>
```

For further details about the using the GET Bucket Versioning operation, see the following:

- [“Syntax Example” on page 50](#)
- [“Request Parameters” on page 50](#)
- [“Request Headers” on page 51](#)
- [“Request Elements” on page 51](#)
- [“Response Headers” on page 51](#)
- [“Response Elements” on page 51](#)
- [“Normal Response Code” on page 51](#)
- [“Error Response Code” on page 51](#)
- [“Example” on page 51](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?versioning
```

### Request Parameters

The GET Bucket Versioning operation does not support the use of request parameters.

## Request Headers

The GET Bucket Versioning operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The GET Bucket Versioning operation does not support the use of request elements.

## Response Headers

The GET Bucket Versioning operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

The following XML response elements are supported:

- Status
- VersioningConfiguration

For a detailed description of these response elements, see [GET Bucket versioning](#).

## Normal Response Code

200

## Error Response Code

The GET Bucket Versioning operations does not support errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
GET /?versioning
```

```
<VersioningConfiguration xmlns="http://s3.amazonaws.com/doc/2018-03-01/">
  <Status>Enabled</Status>
</VersioningConfiguration>
```

## HEAD Bucket

The HEAD Bucket operation determines whether a bucket exists and if you have permission to access it. To use this operation, you must have permissions to list content in the share target. For more details about this operation, see the following:

- [“Syntax Example” on page 52](#)
- [“Request Parameters” on page 52](#)
- [“Request Headers” on page 52](#)
- [“Request Elements” on page 52](#)
- [“Response Headers” on page 53](#)
- [“Response Elements” on page 53](#)
- [“Normal Response Code” on page 53](#)
- [“Error Response Codes” on page 53](#)
- [“Example” on page 53](#)

## Syntax Example

```
HEAD https://appliance:443/s3/v1/export/share_mount_point_path/bucketname
```

## Request Parameters

The HEAD Bucket operation does not support the use of request parameters.

## Request Headers

The HEAD Bucket operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The HEAD Bucket operation does not support the use of request elements.

## Response Headers

The HEAD Bucket operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

The HEAD Bucket operation does not support the use of response elements.

## Normal Response Code

200 OK

---

**Note** - The HEAD Bucket operation returns the 200 OK response code when both the bucket and access permissions to the bucket exist.

---

## Error Response Codes

- 404 Not Found. This response code is returned when the bucket does not exist.
- 403 Forbidden. This response code is returned when permissions to access the bucket do not exist.

For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
HEAD /  
HTTP/1.1 200 OK  
x-amz-request-id: tx32FE2CEB32F5EE25  
Date: Fri, 10 2018 21:34:56 GMT  
Server: Apache
```

## PUT Bucket

The PUT Bucket operation creates a new bucket. To create a bucket with this operation, you must have an Oracle ZFS Storage Appliance user account and a valid Access Key assigned to

your user account. Anonymous requests are never allowed to create buckets. When you create a bucket, you automatically become the bucket owner. Optionally, a bucket owner can grant permissions to other appliance users or predefined groups. For more details about using the PUT Bucket operation, see the following:

- [“Syntax Example” on page 54](#)
- [“Request Parameters” on page 54](#)
- [“Request Headers” on page 54](#)
- [“Request Elements” on page 54](#)
- [“Response Headers” on page 54](#)
- [“Response Elements” on page 55](#)
- [“Error Response Code” on page 55](#)

## Syntax Example

```
PUT https://appliance:443/s3/v1/export/share_mount_point_path/bucketname
```

## Request Parameters

The PUT Bucket operation does not support the use of request parameters.

## Request Headers

In addition to supporting common request headers, the PUT Bucket operation also supports headers for specifying canned ACLs and specific ACL access permissions for appliance users and predefined groups. For further details about these request headers, see [PUT Bucket](#).

## Request Elements

This implementation of the PUT Bucket operation does not support the use of request elements.

## Response Headers

The PUT Bucket operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the PUT Bucket operation does not return response elements.

## Error Response Code

The PUT Bucket API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

---

**Note** - For additional request and response examples, see [PUT Bucket](#).

---

```
PUT HTTP/1.1
x-amz-date: Sat, 07 Apr 2018 00:54:40 GMT
Authorization: authorization string
x-amz-grant-write: id="scobby", id="shaggy"
```

```
HTTP/1.1 200
```

## PUT Bucket ACL

The PUT Bucket ACL operation sets permissions on an existing bucket using the Access Control List (ACL). For more details about this operation, see the following:

---

**Note** - For further details about managing access permissions using ACLs, see [“Controlling Access to Resources Using S3 ACLs” on page 33](#).

---

- [“Syntax Example” on page 56](#)
- [“Request Parameters” on page 56](#)
- [“Request Headers” on page 56](#)
- [“Request Elements” on page 56](#)
- [“Response Headers” on page 56](#)
- [“Response Elements” on page 56](#)
- [“Error Response Code” on page 56](#)

## Syntax Example

```
PUT https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?acl
```

## Request Parameters

This implementation of the PUT Bucket ACL operation does not support the use of request parameters.

## Request Headers

The PUT Bucket ACL operation supports the following type of request headers. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

- Common request headers. For more details, see [Table 7, “Common Supported Request Headers,” on page 25](#).
- Canned ACL and Grantee Permission request headers. For more details, see [PUT Bucket acl](#).

## Request Elements

The PUT Bucket ACL operation only supports the use of request elements when using a request body to specify an ACL. For a description of supported request elements, see [PUT Bucket acl](#).

## Response Headers

The PUT Bucket ACL operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the PUT Bucket ACL operation does not return response elements.

## Error Response Code

The PUT Bucket ACL operation returns special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).



## Example

```

PUT ?acl HTTP/1.1
Content-Length: 1660
x-amz-date: Thu, 12 Apr 2018 20:04:21 GMT
Authorization: authorization string

<AccessControlPolicy>
  <Owner>
    <ID>bob</ID>
    <DisplayName>bob</DisplayName>
  </Owner>
  <AccessControlList>
    <Grant>
      <Grantee xsi:type="CanonicalUser">
        <ID>bill</ID>
        <DisplayName>bill</DisplayName>
      </Grantee>
      <Permission>FULL_CONTROL</Permission>
    </Grant>
    <Grant>
      <Grantee xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance" xsi:type="Group">
        <URI xmlns="">http://acs.amazonaws.com/groups/global/AllUsers</URI>
      </Grantee>
      <Permission xmlns="">READ</Permission>
    </Grant>
  </AccessControlList>
</AccessControlPolicy>

```

## PUT Bucket Tagging

The PUT Bucket Tagging operation enables you to add a set of tags to an existing bucket. The bucket owner has this permission by default and can grant this permission to others. For more details about this operation, see the following:

- [“Syntax Example” on page 58](#)
- [“Request Parameters” on page 58](#)
- [“Request Headers” on page 58](#)
- [“Request Elements” on page 58](#)
- [“Response Headers” on page 58](#)
- [“Response Elements” on page 58](#)
- [“Expected HTTP Response Code” on page 58](#)
- [“Error Response Code” on page 58](#)

## Syntax Example

PUT `https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?tagging`

## Request Parameters

This implementation of the PUT Bucket Tagging operation does not support the use of request parameters.

## Request Headers

The PUT Bucket Tagging operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The PUT Bucket Tagging operation supports the use of request elements. For description of these request elements, see [PUT Bucket tagging](#).

## Response Headers

The PUT Bucket Tagging operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the PUT Bucket Tagging operation does not return response elements.

## Expected HTTP Response Code

204 No Content

## Error Response Code

This implementation of the PUT Bucket Tagging operation supports the use of the following response errors:

- Special Error. MalformedXMLError where the XML provided does not match the schema.
- Common Errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
PUT ?tagging HTTP/1.1
Content-Length: 1660
x-amz-date: Thu, 12 Apr 2018 20:04:21 GMT
Authorization: authorization string
```

```
<Tagging>
  <TagSet>
    <Tag>
      <Key>Project</Key>
      <Value>Project One</Value>
    </Tag>
    <Tag>
      <Key>User</Key>
      <Value>jsmith</Value>
    </Tag>
  </TagSet>
</Tagging>
HTTP/1.1 204 No Content
```

## PUT Bucket Versioning

The PUT Bucket Versioning operation enables the bucket owner to set the versioning state of an existing bucket. Supported versioning state values are as follows:

- **Enabled.** Enables versioning for the objects in the bucket. All objects added to the bucket receive a unique version ID.
- **Disabled.** Disables versioning for the objects in the bucket. All objects added to the bucket receive the version ID null.

---

**Note** - If the versioning state has never been set on a bucket, it has no versioning state; a GET versioning request does not return a versioning state value.

---

For more details about this operation, see the following:

- [“Syntax Example” on page 60](#)
- [“Request Parameters” on page 60](#)
- [“Request Headers” on page 60](#)

- [“Request Elements” on page 60](#)
- [“Response Headers” on page 58](#)
- [“Response Elements” on page 60](#)
- [“Expected HTTP Response Code” on page 61](#)
- [“Error Response Code” on page 61](#)
- [“Example” on page 61](#)

## Syntax Example

```
PUT https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?versioning
```

## Request Parameters

This implementation of the PUT Bucket Versioning operation does not support the use of request parameters.

## Request Headers

The PUT Bucket Versioning operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The PUT Bucket Versioning operation supports the use of the Status and VersioningConfiguration request elements. For more information about these request elements, see [PUT Bucket versioning](#).

## Response Headers

The PUT Bucket Versioning operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the PUT Bucket Versioning operation does not return response elements.

## Expected HTTP Response Code

200 OK

## Error Response Code

The PUT Bucket Versioning operation does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
PUT /?versioning
<VersioningConfiguration>
  <Status>Enabled</Status>
</VersioningConfiguration>
HTTP/1.1 200 OK
```

## DELETE Bucket

The DELETE Bucket operation deletes the bucket named in the URI. Note that all objects (including all object versions and delete markers) in the bucket must be deleted before the bucket itself can be deleted. For more details about this operation, see the following:

- [“Syntax Example” on page 61](#)
- [“Request Parameters” on page 62](#)
- [“Request Headers” on page 62](#)
- [“Request Elements” on page 62](#)
- [“Response Headers” on page 62](#)
- [“Response Elements” on page 62](#)
- [“Expected HTTP Response Code” on page 62](#)
- [“Error Response Code” on page 62](#)
- [“Example” on page 62](#)

## Syntax Example

```
DELETE https://appliance:443/s3/v1/export/share_mount_point_path/bucketname
```

## Request Parameters

This implementation of the DELETE Bucket operation does not support the use of request parameters.

## Request Headers

The DELETE Bucket operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

This implementation of the DELETE Bucket operation does not support the use of request elements.

## Response Headers

The DELETE Bucket operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the DELETE Bucket does not return response elements.

## Expected HTTP Response Code

204 No Content

## Error Response Code

The DELETE Bucket API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

DELETE /

HTTP/1.1 204 No Content

## DELETE Bucket Tagging

The DELETE Bucket Tagging operation removes a tag set from the specified bucket. For more details, see the following:

- [“Syntax Example” on page 63](#)
- [“Request Parameters” on page 63](#)
- [“Request Headers” on page 63](#)
- [“Request Elements” on page 63](#)
- [“Response Headers” on page 64](#)
- [“Response Elements” on page 64](#)
- [“Expected HTTP Response Code” on page 62](#)
- [“Error Response Code” on page 64](#)

### Syntax Example

```
DELETE https://appliance:443/s3/v1/export/share_mount_point_path/bucketname?tagging
```

### Request Parameters

This implementation of the DELETE Bucket Tagging operation does not support the use of request parameters.

### Request Headers

The DELETE Bucket Tagging operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

### Request Elements

This implementation of the DELETE Bucket Tagging operation does not support the use of request elements.

## Response Headers

The DELETE Bucket Tagging operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the DELETE Bucket Tagging operation does not return response elements.

## Expected HTTP Response Code

204 No Content

## Error Response Code

The DELETE Bucket Tagging API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
DELETE /?tagging
HTTP/1.1 204 No Content
```

# Operations on Objects

The Oracle ZFS Storage Appliance S3 Object API supports the following operations on objects.

- [“GET Object” on page 65](#)
- [“GET Object ACL” on page 67](#)
- [“GET Object Tagging” on page 70](#)
- [“HEAD Object” on page 72](#)
- [“OPTIONS Object” on page 74](#)
- [“PUT Object” on page 74](#)
- [“PUT Object Copy” on page 77](#)
- [“PUT Object ACL” on page 80](#)



- [“PUT Object Tagging” on page 83](#)
- [“POST Object” on page 85](#)
- [“DELETE Object” on page 89](#)
- [“DELETE Object Tagging” on page 91](#)

## GET Object

The GET Object retrieves S3 objects. To use this operation, you must have READ access to the object. If READ access is granted to an anonymous user, the object is returned without an authorization header. Note that the GET Object operation, by default, returns the current version of an object. To return a different version, use the `versionId` subresource. In cases where the current version of the object is a delete marker, S3 behaves as if the object was deleted and includes `x-amz-delete-marker: true` in the response. For more details about this operation, see the following:

- [“Syntax Example” on page 65](#)
- [“Request Parameters” on page 65](#)
- [“Request Headers” on page 65](#)
- [“Request Elements” on page 66](#)
- [“Response Headers” on page 66](#)
- [“Response Elements” on page 66](#)
- [“Expected HTTP Response Code” on page 66](#)
- [“Error Response Code” on page 66](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucketname/objectname
```

### Request Parameters

This implementation of the GET Object operation does not support the use of request parameters.

### Request Headers

The GET Object operation supports the use of the following request headers:

- Request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,”](#) on page 25.
- Request headers for retrieving objects. For a description of these request headers, see [GET Object](#).

## Request Elements

The GET Object operation does not support the use of request elements.

## Response Headers

The GET Object operation supports the use of response headers. For a description of the response headers supported for the GET Object operation, see [GET Object](#).

## Response Elements

This implementation of the GET Object operation does not return response elements.

## Expected HTTP Response Code

200 OK

## Error Response Code

This implementation of the GET Object operation does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference”](#) on page 95.

## Example

```
GET /my-image.jpg
HTTP/1.1 200 OK
x-amz-request-id: tx318BC8BC148832E5
Date: Mon, 3 Oct 2016 22:32:00 GMT
Last-Modified: Wed, 12 Oct 2009 17:50:00 GMT
ETag: "fba9dede5f27731c9771645a39863328"
```

Content-Length: 434234

[434234 bytes of object data]

### Example Response when the Latest Object is a Delete Marker

```
HTTP/1.1 404 Not Found
x-amz-request-id: 318BC8BC148832E5
x-amz-version-id: 003
x-amz-delete-marker: true
Date: Wed, 28 Oct 2018 22:32:00 GMT
Content-Type: text/plain
Connection: close
```

### Example Request Getting a Specified Version of an Object

```
GET /myObject?versionId=002 HTTP/1.1
Date: Wed, 28 Oct 2018 22:32:00 GMT
Authorization: authorization string
HTTP/1.1 200 OK
x-amz-request-id: 318BC8BC148832E5
Date: Wed, 28 Oct 2009 22:32:00 GMT
Last-Modified: Sun, 1 Jan 2018 12:00:00 GMT
x-amz-version-id: 002
ETag: "fba9dede5f27731c9771645a39863328"
Content-Length: 434234
Content-Type: text/plain
Connection: close
[434234 bytes of object data]
```

## GET Object ACL

The GET Object ACL operation returns the Access Control List (ACL) for the specified object. To use this operation, you must have READ\_ACP access to the object. For more details about this operation, see the following:

- [“Syntax Example” on page 68](#)
- [“Request Parameters” on page 68](#)
- [“Request Headers” on page 68](#)
- [“Request Elements” on page 68](#)
- [“Response Headers” on page 68](#)
- [“Response Elements” on page 68](#)
- [“Normal Response Code” on page 68](#)
- [“Error Response Code” on page 68](#)

## Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucketname/objectname?acl
```

## Request Parameters

This implementation of the GET Object ACL does not support the use of request parameters.

## Request Headers

The GET Object ACL operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The GET Object ACL operation does not support the use of request elements.

## Response Headers

The GET Object ACL operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

For a list of supported elements in the XML response for the GET Object ACL operation, see [GET Object ACL](#).

## Normal Response Code

200 OK

## Error Response Code

The GET Object API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

### Sample Response

```
GET /my-image.jpg?acl
HTTP/1.1 200 OK
x-amz-request-id: tx318BC8BC148832E5
x-amz-version-id: 009
Date: Wed, 28 Oct 2018 22:32:00 GMT
Last-Modified: Sun, 1 Jan 2018 12:00:00 GMT
Content-Length: 124
Content-Type: text/plain
Connection: close
```

```
<AccessControlPolicy>
  <Owner>
    <ID>micky</ID>
    <DisplayName>micky</DisplayName>
  </Owner>
  <AccessControlList>
    <Grant>
      <Grantee type="CanonicalUser">
        <ID>minny</ID>
        <DisplayName>minny</DisplayName>
      </Grantee>
      <Permission>FULL_CONTROL</Permission>
    </Grant>
  </AccessControlList>
</AccessControlPolicy>
```

### Sample Request Getting the ACL of the Specific Version of an Object

```
GET /my-image.jpg?versionId=0003
HTTP/1.1 200 OK
x-amz-request-id: 318BC8BC148832E5
Date: Wed, 28 Oct 2018 22:32:00 GMT
Last-Modified: Sun, 1 Jan 2018 12:00:00 GMT
x-amz-version-id: 0004
Content-Length: 124
Content-Type: text/plain
Connection: close
```

```
<AccessControlPolicy>
  <Owner>
    <ID>micky</ID>
    <DisplayName>micky</DisplayName>
  </Owner>
  <AccessControlList>
    <Grant>
```

```
<Grantee xsi:type="CanonicalUser">
  <ID>minny</ID>
  <DisplayName>minny</DisplayName>
</Grantee>
<Permission>FULL_CONTROL</Permission>
</Grant>
</AccessControlList>
</AccessControlPolicy>
```

## GET Object Tagging

The GET Object Tagging operation returns the tags associated with an object by sending the GET request against the tagging subresource associated with the object. To use this operation, you must have READ permissions on the object. For more details about this operation, see the following:

- [“Syntax Example” on page 70](#)
- [“Request Parameters” on page 70](#)
- [“Request Headers” on page 70](#)
- [“Request Elements” on page 71](#)
- [“Response Headers” on page 71](#)
- [“Response Elements” on page 71](#)
- [“Expected HTTP Response Code” on page 71](#)
- [“Error Response Code” on page 71](#)

### Syntax Example

```
GET https://appliance:443/s3/v1/export/share_mount_point_path/bucketname/objectname?tagging
```

### Request Parameters

This implementation of GET Object Tagging API does not support the use of request parameters.

### Request Headers

The GET Object Tagging operation uses only request headers that are common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).

## Request Elements

The GET Object Tagging operation does not support the use of request elements.

## Response Headers

The GET Object Tagging operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

For a list of supported elements in the XML response for the GET Object Tagging operation, see [GET Object tagging](#).

## Expected HTTP Response Code

200 OK

## Error Response Code

The GET Object Tagging operation does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
GET /example-object?tagging
HTTP/1.1 200 OK
Date: Thu, 22 Sep 2018 21:33:08 GMT
Connection: close
Server: Apache
<?xml version="1.0" encoding="UTF-8"?>
<Tagging xmlns="http://s3.amazonaws.com/doc/2006-03-01/">
  <TagSet>
    <Tag>
      <Key>tag1</Key>
      <Value>val1</Value>
    </Tag>
    <Tag>
```

```
<Key>tag2</Key>
  <Value>val2</Value>
</Tag>
</TagSet>
</Tagging>
```

## HEAD Object

The HEAD Object operation retrieves metadata from an object without returning the object itself. This operation is useful if you are interested only in an object's metadata. To use this operation, you must have READ access to the object. A HEAD request has the same options as a GET operation on an object. The response is identical to the GET response except that there is no response body. For more details about the Head Object operation, see the following:

- [“Syntax Example” on page 72](#)
- [“Request Parameters” on page 72](#)
- [“Request Headers” on page 72](#)
- [“Request Elements” on page 73](#)
- [“Response Headers” on page 73](#)
- [“Response Elements” on page 73](#)
- [“Expected HTTP Response Code” on page 73](#)
- [“Error Response Code” on page 73](#)

## Syntax Example

```
HEAD https://appliance:443/s3/v1/export/share_mount_point_path/bucketname/objectname
```

## Request Parameters

This implementation of the HEAD Object operation does not support the use of request parameters.

## Request Headers

The HEAD Object operation supports the use of the following type of request headers:

- Request headers common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#)



- Request headers for Head Object operations. For more information, see [HEAD Object](#).

## Request Elements

The HEAD Object operation does not support the use of request elements.

## Response Headers

This implementation of the HEAD Object operation supports the use of the `x-amz-meta-*` and `x-amz-version-id` response headers. For more details about these response headers, see [HEAD Object](#).

## Response Elements

This implementation of the HEAD Object operation does not return response elements.

## Expected HTTP Response Code

200 OK

## Error Response Code

The HEAD Object API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
HEAD /my-image.jpg
HTTP/1.1 200 OK
x-amz-request-id: 318BC8BC143432E5
x-amz-version-id: 0007
x=custom-made: custom-value
Date: Wed, 28 Oct 2018 22:32:00 GMT
Last-Modified: Sun, 1 Jan 2018 12:00:00 GMT
ETag: "fba9dede5f27731c9771645a39863328"
Content-Length: 434234
Content-Type: text/plain
```

Connection: close  
Server: Apache

## OPTIONS Object

The 403 Forbidden response code is always returned for the OPTIONS Object API operation. The Oracle ZFS Storage Appliance S3 API does not support the use of a cross-origin resource sharing CORS configuration on a bucket.

### Expected HTTP Response Code

403 Forbidden

## PUT Object

The PUT Object operation adds an object to a bucket. To add an object to a bucket, you must have WRITE permissions on the bucket. To ensure data is not corrupted when using the PUT Object operation, you should use the Content-MD5 header. To configure your application to send the Request Headers prior to sending the request body, use the 100-continue HTTP status code. For more details about using this operation, see the following:

- [“Storage Class Options” on page 74](#)
- [“Access Permissions” on page 75](#)
- [“Syntax Example” on page 75](#)
- [“Object Versioning” on page 75](#)
- [“Request Parameters” on page 75](#)
- [“Request Headers” on page 75](#)
- [“Request Elements” on page 76](#)
- [“Response Headers” on page 76](#)
- [“Response Elements” on page 76](#)
- [“Expected HTTP Response Code” on page 76](#)
- [“Error Response Code” on page 76](#)

### Storage Class Options

Oracle ZFS Storage Appliance only supports the STANDARD storage class option.

## Access Permissions

To grant specific permission on an object using a request header, you can either:

- Specify a canned (predefined) ACL using the `x-amz-acl` request header. For more information, see [“Controlling Access to Resources Using S3 ACLs” on page 33](#).
- Specify access permissions explicitly using the `x-amz-grant-read`, `x-amz-grant-read-acp`, and `x-amz-grant-write-acp`, `x-amz-grant-full-control` headers. These headers map to the set of permissions S3 supports in an ACL. For more information, see [“Controlling Access to Resources Using S3 ACLs” on page 33](#).

## Syntax Example

```
PUT https://appliance:443/s3/v1/export/share_mount_point_path/bucketname/objectname
```

## Object Versioning

If you enable versioning for a bucket, S3 automatically generates a unique version ID for the object being stored. S3 returns this ID in the response using the `x-amz-version-id` response header. If versioning is suspended, S3 always uses `null` as the version ID for the object stored. If you enable versioning for a bucket, when S3 receives multiple write requests for the same object simultaneously, it stores all of the objects as separate versions.

## Request Parameters

This implementation of the PUT Object operation does not support the use of request parameters.

## Request Headers

The PUT Object operation supports the use of following request headers:

- Request headers common to all operations. For more information, see [Table 7, “Common Supported Request Headers,” on page 25](#).
- Request headers for PUT Object operations, which include `Content-Disposition`, `Content-Encoding`, `Content-Length`, `Content-MD5`, `Content-Type`, `Expect`, `x-amz-meta-`, `x-amz-tagging`. For a description of these request headers, see [PUT Object](#).

## Request Elements

The PUT Object operation does not support the use of request elements.

## Response Headers

The PUT Object operation supports the use of the following response headers:

- Response headers common to all operations. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).
- The `x-amz-version-id` header. This header describes the object version.

## Response Elements

This implementation of the PUT Object operation does not return response elements.

## Expected HTTP Response Code

200 OK

## Error Response Code

The PUT Object API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
PUT /my-image.jpg
Date: Wed, 12 Oct 2018 17:50:00 GMT
Authorization: authorization string
Content-Type: text/plain
Content-Length: 11434
x-amz-grant-full-control: id="michael"
x-amz-meta-author: Janet
Expect: 100-continue

HTTP/1.1 100 Continue
```

```
HTTP/1.1 200 OK
x-amz-request-id: tx0A49CE4060975EAC
Date: Wed, 12 Oct 2018 17:50:00 GMT
ETag: "1b2cf535f27731c974343645a3985328"
Content-Length: 0
Connection: close
Server: Apache
```

When versioning is enabled on the bucket, the response includes the `x-amz-version-id` header:

```
HTTP/1.1 100 Continue

HTTP/1.1 200 OK
x-amz-request-id: tx0A49CE4060975EAC
x-amz-version-id: 0075
Date: Wed, 12 Oct 2018 17:50:00 GMT
ETag: "fbacf535f27731c9771645a39863328"
Content-Length: 0
Connection: close
```

## PUT Object Copy

The PUT Object Copy operation creates a copy of a stored S3 object. A PUT Object Copy operation is the same as performing a GET and then a PUT. Adding the request header, `x-amz-copy-source`, makes the PUT operation copy the source object into the destination bucket. When copying an object, you can preserve most of the metadata (default) or specify new metadata. However, the ACL is not preserved and is set to private for the user making the request. All copy requests must be authenticated and cannot contain a message body. Additionally, you must have READ access to the source object and WRITE access to the destination bucket. To copy an object only under certain conditions, such as whether the ETag matches or whether the object was modified before or after a specified date, use the request headers `x-amz-copy-source-if-match`, `x-amz-copy-source-if-none-match`, `x-amz-copy-source-if-unmodified-since`, or `x-amz-copy-source-if-modified-since`. For more details about using the PUT Object Copy operation, see the following:

- [“Syntax Example” on page 78](#)
- [“Versioning” on page 78](#)
- [“Access Permissions” on page 78](#)
- [“Request Parameters” on page 78](#)
- [“Request Headers” on page 79](#)
- [“Request Elements” on page 79](#)
- [“Response Headers” on page 79](#)

- [“Response” on page 79](#)
- [“Expected HTTP Response Code” on page 79](#)
- [“Error Response Code” on page 80](#)

## Syntax Example

For a syntax example, see [PUT Object - Copy](#).

## Versioning

By default, `x-amz-copy-source` identifies the current version of an object to copy. However, if the current version is a delete marker, S3 behaves as if the object were deleted.

To copy a different version, use the `versionId` subresource. If you enable versioning on the target bucket, S3 generates a unique version ID for the object being copied. This version ID is different from the version ID of the source object. S3 returns the version ID of the copied object in the `x-amz-version-id` response header in the response. Note that if you do not enable versioning or suspend versioning on the target bucket, the version ID S3 generates a null.

## Access Permissions

To grant specific permission on an object using a request header, you can either:

- Specify a canned (predefined) ACL using the `x-amz-acl` request header. For more information, see [“Controlling Access to Resources Using S3 ACLs” on page 33](#).
- Specify access permissions explicitly using the `x-amz-grant-read`, `x-amz-grant-read-acp`, and `x-amz-grant-write-acp`, `x-amz-grant-full-control` headers. These headers map to the set of permissions S3 supports in an ACL. For more information, see [“Controlling Access to Resources Using S3 ACLs” on page 33](#).

---

**Note** - You can use either a canned ACL or specify access permissions explicitly. You cannot do both.

---

## Request Parameters

This implementation of PUT Object Copy operation does not support the use of request parameters.

## Request Headers

The PUT Object Copy operation supports the use of following request headers:

- Request headers common to all operations. For more information, see [Table 7, “Common Supported Request Headers,”](#) on page 25.
- Request headers for PUT Object operations, which include `x-amz-copy-source`, `x-amz-metadata-directive`, `x-amz-copy-source-if-match`, `x-amz-copy-source-if-none-match`, `x-amz-copy-source-if-unmodified-since`, `x-amz-copy-source-if-modified-since`, `x-amz-tagging-directive`. For a description of these request headers, see [PUT Object - Copy](#).

## Request Elements

The PUT Object Copy operation supports the following requests elements:

- `CopyObjectResult`
- `ETag`
- `LastModified`

For a description of the supported request elements, see [PUT Object - Copy](#).

## Response Headers

The PUT Object Copy operation supports the use of the following response headers:

- Response headers common to all operations. For more information, see [Table 9, “Supported Response Headers,”](#) on page 26.
- Response headers for PUT Object operation, which include `x-amz-version-id` and `x-amz-copy-source-version-id`. For a description of these response headers, see [PUT Object - Copy](#).

## Response

This implementation of the PUT Object Copy operation does not return response elements.

## Expected HTTP Response Code

200 OK

## Error Response Code

The PUT Object Copy API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference”](#) on page 95.

## Example

```
PUT /my-second-image.jpg HTTP/1.1
Host: bucket.s3.amazonaws.com
Date: Wed, 28 Oct 2018 22:32:00 GMT
x-amz-copy-source: /bucket/my-image.jpg
HTTP/1.1 200 OK
x-amz-request-id: tx318BC8BC148832E5
x-amz-copy-source-version-id: 0009
x-amz-version-id: 0099
Date: Wed, 28 Oct 2018 22:32:00 GMT
Connection: close
Server: Apache

<CopyObjectResult>
  <LastModified>2009-10-28T22:32:00</LastModified>
  <ETag>"9b2cf535f27731c974343645a3985328"</ETag>
</CopyObjectResult>
```

Where `x-amz-version-id` returns the version ID of the object in the destination bucket, and `x-amz-copy-source-version-id` returns the version ID of the source object.

## PUT Object ACL

The PUT Object ACL sets the Access Control List (ACL) permissions on an existing bucket object. To set ACL permissions on an existing bucket object, you must have `WRITE_ACP` permissions. You can choose to use request headers to specify the permissions, or specify the ACL in the request body. For more details about using the PUT Object ACL, see the following:

- [“Versioning”](#) on page 81
- [“Syntax Example”](#) on page 81
- [“Request Parameters”](#) on page 81
- [“Request Headers”](#) on page 81
- [“Request Elements”](#) on page 81
- [“Response Headers”](#) on page 82
- [“Response Elements”](#) on page 82



- [“Expected HTTP Response Code” on page 82](#)
- [“Error Response Codes” on page 82](#)

## Versioning

The ACL for an object is set at the object version level. By default, a PUT request sets the ACL for the current version of the object. To set the ACL for a different version, use the `versionId` subresource.

## Syntax Example

For syntax examples, see [PUT Object acl](#).

## Request Parameters

This implementation of the PUT Object ACL operation does not support the use of request parameters.

## Request Headers

The PUT Object ACL operation supports the use of the following access-control headers to set permissions:

- `x-amz-acl` header. Use this header to specify canned ACL permissions.
- `x-amz-grant-permission` header. Use this header to individually specify the permissions for a grantee.

For more information about how to specify ACL permissions, see:

- [“Controlling Access to Resources Using S3 ACLs” on page 33](#)
- [PUT Object acl](#)

## Request Elements

The PUT Object ACL operation supports the use of request elements when not using a request body. Note that if you use a request body, you cannot use the request headers to set an ACL. For a list of supported request elements, see [PUT Object acl](#).

## Response Headers

The PUT Object ACL operation supports the use of the following response headers:

- Response headers common to all operations. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).
- Response headers for a PUT Object operation, which include `x-amz-version-id`. For further details about this response header, see [PUT Object acl](#).

## Response Elements

This implementation of the PUT Object ACL does not support the use of response elements.

## Expected HTTP Response Code

200 OK

## Error Response Codes

The PUT Object ACL operation does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
PUT /my-image.jpg?acl
<AccessControlPolicy>
  <Owner>
    <ID>joe</ID>
    <DisplayName>joe/DisplayName>
  </Owner>
  <AccessControlList>
    <Grant>
      <Grantee type="CanonicalUser">
        <ID>jack</ID>
        <DisplayName>joe</DisplayName>
      </Grantee>
      <Permission>FULL_CONTROL</Permission>
    </Grant>
  </AccessControlList>
```

```
</AccessControlPolicy>

HTTP/1.1 200 OK
x-amz-request-id: tx318BC8BC148832E5
x-amz-version-id: 0055
Date: Wed, 28 Oct 2018 22:32:00 GMT
Last-Modified: Sun, 1 Jan 2018 12:00:00 GMT
Content-Length: 0
Connection: close
Server: Apache
```

Alternatively, a request can also be made to a specific version of an object, for instance:

```
PUT /my-image.jpg?acl&versionId=0099
```

## PUT Object Tagging

The PUT Object Tagging operation adds a set of tags to an existing object. A tag is a key-value pair. You can associate tags with an object by sending a PUT request against the tagging subresource associated with the object. You can retrieve tags by sending a GET request. For more details, see the following:

- [“Syntax Example” on page 83](#)
- [“Request Parameters” on page 83](#)
- [“Request Headers” on page 84](#)
- [“Request Elements” on page 84](#)
- [“Response Headers” on page 84](#)
- [“Response Elements” on page 84](#)
- [“Expected HTTP Response Code” on page 84](#)
- [“Error Response Code” on page 84](#)

### Syntax Example

For syntax examples, see [PUT Object tagging](#).

### Request Parameters

This implementation of the PUT Object Tagging operation does not support the use of request parameters.

## Request Headers

This implementation of the PUT Object Tagging operation does not support the use of request headers.

## Request Elements

For a list of supported request elements, see [PUT Object tagging](#).

## Response Headers

The PUT Object Tagging operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

This implementation of the PUT Object Tagging operation does not return response elements.

## Expected HTTP Response Code

200 OK

## Error Response Code

MalformedXMLError. The XML provided does not match the schema..

## Example

```
PUT object-key?tagging HTTP/1.1
Content-Length: length
Content-MD5: pUNXr/BjKK5G2UKEexample==
x-amz-date: 20180923T001956Z
Authorization: authorization string
<Tagging>
  <TagSet>
    <Tag>
      <Key>tag1</Key>
      <Value>val1</Value>
```

```
</Tag>
<Tag>
  <Key>tag2</Key>
  <Value>val2</Value>
</Tag>
</TagSet>
</Tagging>
HTTP/1.1 200 OK
x-amz-request-id: tx236A8905248E5A01
Date: Fri, 23 Sep 2018 00:20:19 GMT
```

## POST Object

The POST Object operation adds an object to a specified bucket using HTML forms.

---

**Note** - POST is an alternate form of PUT that enables browser-based uploads as a way of putting objects in buckets. Parameters that are passed to PUT in HTTP Headers are instead passed as form fields to POST in the multipart-form-data encoded message body. WRITE access is required to add an object to a bucket. To ensure that data is not corrupted traversing the network, use the Content-MD5 form field. When you use this form field, S3 checks the object against the provided MD5 value. If they do not match, S3 returns an error. Additionally, you can calculate the MD5 value while posting an object to S3 and compare the returned ETag to the calculated MD5 value. The ETag only reflects changes to the contents of an object, not its metadata.

---

For more details about using the POST Object operation, see the following:

- [“Syntax Example” on page 85](#)
- [“Request Parameters” on page 86](#)
- [“Request Headers” on page 86](#)
- [“Request Elements” on page 84](#)
- [“Form Field Names Supported In Request” on page 86](#)
- [“Response Headers” on page 86](#)
- [“Response Elements” on page 87](#)
- [“Expected HTTP Error Response Codes” on page 87](#)
- [“Error Response Code” on page 87](#)

## Syntax Example

For request syntax examples, see [POST Object](#).

## Request Parameters

This implementation of the POST Object operation does not support the use of request parameters.

## Request Headers

This implementation of the POST Object operation does not support the use of request headers.

## Request Elements

The request is made through an HTTP form.

## Form Field Names Supported In Request

The POST Object operation supports the use of following form fields in a request.

---

**Note** - Server side encryption form fields are not supported.

---

Field Name	Field Name
AWSAccessKeyId	policy
acl	success_action_redirect
Cache-Control, Content-Type, Content- Disposition, Content- Encoding, Expires	success_action_status
file	tagging
key	x-amz-storage-class
x-amz-meta-*	

For a description of these supported form fields, see [POST Object](#).

## Response Headers

In addition to the response headers common to all responses, this implementation of the POST Object operation can include the following response headers:

- success\_action\_redirect
- x-amz-version-id

For a more information about these response headers, see [POST Object](#). For a description of common response headers, see [Table 9, “Supported Response Headers,”](#) on page 26.

## Response Elements

For a list of supported elements in the XML response for the POST Object operation, see [POST Object](#).

## Expected HTTP Error Response Codes

200 or 201 or 204

## Error Response Code

The POST Object API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference”](#) on page 95.

## Example

```
POST / HTTP/1.1
User-Agent: browser_data
Accept: file_types
Accept-Language: Regions
Accept-Encoding: encoding
Accept-Charset: character_set
Keep-Alive: 300
Connection: keep-alive
Content-Type: multipart/form-data; boundary=9431149156168
Content-Length: length

--9431149156168
Content-Disposition: form-data; name="key"

acl
--9431149156168
Content-Disposition: form-data; name="tagging"

<Tagging><TagSet><Tag><Key>Tag Name</Key><Value>Tag Value</Value></Tag></TagSet></
Tagging>
```

```
--9431149156168
Content-Disposition: form-data; name="success_action_redirect"

success_redirect
--9431149156168
Content-Disposition: form-data; name="Content-Type"

content_type
--9431149156168
Content-Disposition: form-data; name="x-amz-meta-uuid"

uuid
--9431149156168
Content-Disposition: form-data; name="x-amz-meta-tag"

metadata
--9431149156168
Content-Disposition: form-data; name="AWSAccessKeyId"

access-key-id
--9431149156168
Content-Disposition: form-data; name="Policy"

encoded_policy
--9431149156168
Content-Disposition: form-data; name="Signature"

signature=
--9431149156168
Content-Disposition: form-data; name="file"; filename="MyFilename.jpg"
Content-Type: image/jpeg

file_content
--9431149156168
Content-Disposition: form-data; name="submit"

Upload to S3
--9431149156168--

response:
HTTP/1.1 100 Continue
HTTP/1.1 200 OK
x-amz-request-id: tx0A49CE4060975EAC
x-amz-version-id: null
Date: Wed, 01 Mar 2018 12:00:00 GMT
ETag: "828ef3fdfa96f00ad9f27c383fc9ac7f"
Content-Length: 0
Connection: close
```



Server: Apache

## DELETE Object

If a null version of an object exists, the DELETE operation removes the null version of the object and inserts a delete marker. For more details, see the following:

- [“Syntax Example” on page 89](#)
- [“Versioning” on page 89](#)
- [“Request Parameters” on page 89](#)
- [“Request Parameters” on page 89](#)
- [“Request Elements” on page 90](#)
- [“Response Headers” on page 90](#)
- [“Response Elements” on page 90](#)
- [“Expected HTTP Error Response Code” on page 90](#)
- [“Error Response Code” on page 90](#)

### Syntax Example

For a syntax example, see [DELETE Object](#).

### Versioning

To remove a specific version, you must be the bucket owner and you must use the `versionId` subresource. Using this subresource permanently deletes the version. If the object deleted is a delete marker, S3 sets the response header, `x-amz-delete-marker`, to `true`.

### Request Parameters

This implementation of the DELETE Object operation does not support the use of request parameters.

### Request Headers

This implementation of the DELETE Object operation does not support the use of request headers.

## Request Elements

This implementation of the DELETE Object operation does not support the use of request elements.

## Response Headers

This implementation of the DELETE Object operation supports the use of the `x-amz-version-id` response header. For more details about this response header, see [DELETE Object](#).

## Response Elements

This implementation of the DELETE Object operation does not return response elements.

## Expected HTTP Error Response Code

204 No Content

## Error Response Code

The DELETE Object operation does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

The following request deletes `my-desk-image.jpg`.

```
DELETE /my-desk-image.jpg
HTTP/1.1 204 NoContent
x-amz-request-id: tx0A49CE4060975EAC
Date: Wed, 12 Oct 2018 17:50:00 GMT
Content-Length: 0
Connection: close
Server: Apache
```

The following request deletes the specified version of the object, `my-desk-image.jpg`.

```
DELETE /my-third-image.jpg?versionId=00012
HTTP/1.1 204 NoContent
```

```
x-amz-request-id: tx0A49CE4060975EAC
x-amz-version-id: 00012
Date: Wed, 12 Oct 2018 17:50:00 GMT
Content-Length: 0
Connection: close
Server: Apache
```

If the object deleted is a delete marker, the following response example appears.

```
HTTP/1.1 204 NoContent
x-amz-request-id: tx0A49CE4060975EAC
x-amz-version-id: 0011
x-amz-delete-marker: true
Date: Wed, 12 Oct 2018 17:50:00 GMT
Content-Length: 0
Connection: close
Server: Apache
```

## DELETE Object Tagging

The DELETE Object Tagging operation removes the entire tag set from the specified object. For more details, see the following:

- [“Syntax Example” on page 91](#)
- [“Versioning” on page 91](#)
- [“Request Parameters” on page 92](#)
- [“Request Headers” on page 92](#)
- [“Request Elements” on page 92](#)
- [“Response Headers” on page 92](#)
- [“Response Elements” on page 92](#)
- [“Expected HTTP Response Code” on page 92](#)
- [“Error Response Code” on page 92](#)

### Syntax Example

For a syntax example, see [DELETE Object tagging](#).

### Versioning

To delete tags of a specific object version, add the `versionId` query parameter in the request.

## Request Parameters

The DELETE Object Tagging operation does not support the use of request parameters.

## Request Headers

The DELETE Object Tagging operation does not support the use of request headers.

## Request Elements

The DELETE Object Tagging operation does not support the use of request elements.

## Response Headers

The DELETE Object Tagging operation uses only response headers that are common to most responses. For more information, see [Table 9, “Supported Response Headers,” on page 26](#).

## Response Elements

The DELETE Object Tagging operation does not return response elements.

## Expected HTTP Response Code

204 No Content

## Error Response Code

The DELETE Object API does not return special errors. For general information about S3 errors and a list of error codes, see [“S3 Client Error Handling Reference” on page 95](#).

## Example

```
DELETE exampleobject/?tagging
HTTP/1.1 204 No Content
Date: Wed, 25 Nov 2018 12:00:00 GMT
```

```
Connection: close  
Server: Apache
```



# S3 Client Error Handling Reference

---

This reference identifies errors supported by the Oracle ZFS Storage Appliance S3 Object API.

- [“Error Response Format” on page 95](#)
- [“S3 Client Error Codes” on page 95](#)

## Error Response Format

When an error occurs, the header contains the following information:

- Content-Type: application/xml
- HTTP status code (4xx or 5xx)

Information about an error is also available in the body or response. The following example shows the structure of response elements that are common to all REST error responses.

```
<?xml version="1.0" encoding="UTF-8"?>
<Error>
  <Code>NoSuchKey</Code>
  <Message>The resource you requested does not exist</Message>
  <Resource>/mybucket/myfoto.jpg</Resource>
  <RequestId>4442587FB7D0A2F9</RequestId>
</Error>
```

For further information about REST error response elements, see the Amazon S3 REST API [Error Responses](#) documentation.

## S3 Client Error Codes

For a list of supported error codes, see the Amazon S3 REST API [Error Responses](#) documentation.

