

# StorageTek Enterprise Library Software

---

Syntax Quick Reference

Version 7.1



October 2010  
Revision AA

Submit comments about this document by clicking the Feedback [+] link at: <http://docs.sun.com>

Copyright © 2009, 2010, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle USA, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure the safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle is a registered trademark of Oracle Corporation and/or its affiliates. Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. UNIX is a registered trademark licensed through X/Open Company, Ltd.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

# Contents

---

**Preface** xi

Related Documentation xii

Documentation, Support, and Training xiii

Oracle Welcomes Your Comments xiii

Additional Information xiv

**1. SMC Commands and Control Statements** 1

ALLOCDef 2

ALLOCJob 3

CMDDef 4

COMMtest 5

Display DDrive 6

Display Volume 7

DRIVemap 8

Help 9

HTTP 10

IDAX 11

Llist 12

LOG 13

MONitor 14

MOUNTDef 15

MSGDef 16

MSGJob 17

POLicy 18

READ 19

|                           |    |
|---------------------------|----|
| RESYNChronize             | 19 |
| Route                     | 20 |
| SERVer                    | 21 |
| SIMulate                  | 22 |
| SMSDef                    | 23 |
| STORMNGR                  | 24 |
| TAPEPlex                  | 25 |
| TCPip                     | 26 |
| TRace                     | 27 |
| TREQDef                   | 28 |
| TAPEREQ Control Statement | 29 |
| UEXit                     | 30 |
| UNITAttr                  | 31 |
| USERMsg                   | 32 |

## **2. HSC and VTCS Commands and Control Statements 33**

|                          |    |
|--------------------------|----|
| ACTivities               | 34 |
| ACTMVCGN                 | 34 |
| ARCHive                  | 35 |
| AUDit                    | 36 |
| BACKup                   | 37 |
| CANcel                   | 37 |
| CAPPref                  | 38 |
| CDs                      | 38 |
| CDSData                  | 39 |
| CDSDEF                   | 39 |
| CLean                    | 40 |
| COMMPath                 | 41 |
| CONFIg                   | 42 |
| CONFIg GLOBAL Statement  | 43 |
| CONFIg RECLAIM Statement | 43 |
| CONFIg VTSS Statement    | 44 |
| CONFIg RTD Statement     | 44 |
| CONFIg VTD Statement     | 44 |

|                           |    |
|---------------------------|----|
| CONFIg CLUSTER Statement  | 44 |
| CONFIg CLINK Statement    | 44 |
| CONFIg HOST Statement     | 45 |
| CONFIg TAPEPLEX Statement | 45 |
| CONSolid                  | 46 |
| DEComp                    | 46 |
| DELETSCR                  | 47 |
| DIRBLD                    | 47 |
| DISMount                  | 48 |
| Display Acs               | 48 |
| Display ACTive            | 49 |
| Display ALl               | 49 |
| Display Cap               | 50 |
| Display CDS               | 50 |
| Display CLInk             | 51 |
| Display CLUster           | 51 |
| Display CMD               | 52 |
| Display COMMPath          | 52 |
| Display CONFIG            | 53 |
| Display DRives            | 53 |
| Display DRIVE_INFO        | 54 |
| Display EXceptns          | 55 |
| Display LMUPDEF           | 55 |
| Display LOCKs             | 56 |
| Display Lsm               | 56 |
| Display Message           | 57 |
| Display MGMTDEF           | 57 |
| Display MIGrate           | 58 |
| Display MNTD              | 58 |
| Display MONitor           | 59 |
| Display MVC               | 59 |
| Display MVCPool           | 60 |
| Display OPTion            | 60 |

Display PATH 61  
Display Queue 61  
Display REPlicat 62  
Display Requests 62  
Display RTD 63  
Display SCRatch 63  
Display SEN 64  
Display SERVER 64  
Display SRVlev 65  
Display Status 65  
Display STORCLas 66  
Display STORMNGR 66  
Display TASKs 67  
Display THReshld 67  
Display Volser 68  
Display VOLUME\_INFO 68  
Display VSCRatch 69  
Display VTD 69  
Display VTSS 70  
Display VTV 70  
DRAin 71  
DRTEST CREATE 72  
DRTEST PRIMEprd 73  
DRTEST RESET 74  
DRTEST START 74  
DRTEST STOP 75  
EEXPORT 76  
Eject 77  
ENter 78  
EXECParM 78  
EXPORT 79  
FMTLOG 80  
IMPORT 81

|                               |     |
|-------------------------------|-----|
| INITialize                    | 82  |
| INVENTORY                     | 83  |
| LIBGen                        | 83  |
| LMUPDEF                       | 84  |
| LMUPATH Control Statement     | 84  |
| LOGUTIL                       | 85  |
| LOGUTIL FOR_LOSTMVC Statement | 85  |
| LOGUTIL GENAUDIT Statement    | 86  |
| LOGUTIL LOCATE_VTV            | 86  |
| LOGUTIL UNDELETE Statement    | 86  |
| MERGEcds                      | 87  |
| SLSMERGE Control Statement    | 87  |
| MERGMFST                      | 88  |
| MGMTDEF                       | 88  |
| MGMTclas Control Statement    | 89  |
| MIGRSEL Control Statement     | 90  |
| MIGRVTV Control Statement     | 90  |
| MVCATTR Control Statement     | 90  |
| STORclas Control Statement    | 91  |
| STORLST Control Statement     | 91  |
| STORSEL Control Statement     | 91  |
| VTSSLST Control Statement     | 92  |
| VTSSSEL Control Statement     | 92  |
| MIGrate                       | 93  |
| Format 1                      | 93  |
| Format 2                      | 93  |
| MNTD                          | 94  |
| MODify                        | 95  |
| Mount                         | 96  |
| MOVE                          | 97  |
| MVCDRain                      | 98  |
| MVCMaint                      | 99  |
| MVCPLRPT                      | 100 |

MVCRPt 101  
 OFFload LOGFILE 101  
 OPTION TITLE Control Statement 102  
 OPTion 103  
 RECall 104  
 RECLaim 105  
 RECONcil 106  
 RECOVer 106  
 RELease 107  
 REPLaceall 107  
 RESTore 108  
 RTV Utility 108  
 SCRArch 109  
 SCREdist 109  
 SENter 110  
 SET CLNPRFX 110  
 SET COMPRFX 111  
 SET DRVHOST 111  
 SET EJCTPAS 112  
 SET FREEZE 112  
 SET HOSTID 113  
 SET HSCLEVel 113  
 SET LOGFILE 114  
 SET MAJNAME 114  
 SET MIGOPT 115  
 SET NEWHOST 115  
 SET RMM 116  
 SET SCRLABL 116  
 SET SLIDRIVS 117  
 SET SLISTATN 117  
 SET SMF 118  
 SET TAPEPlex 118  
 SET TCHNIQE 119



|                            |     |
|----------------------------|-----|
| SET VAULT                  | 120 |
| SET VAULTVOL               | 120 |
| SET VOLPARM                | 121 |
| POOLPARM Control Statement | 122 |
| VOLPARM Control Statement  | 122 |
| SRVlev                     | 123 |
| STOPMN                     | 123 |
| SWitch                     | 124 |
| TRace                      | 124 |
| TRACELKP                   | 125 |
| UEXIT                      | 125 |
| UNSCratch                  | 126 |
| UNSElect                   | 126 |
| Vary                       | 127 |
| Vlew                       | 128 |
| VOLPCONV                   | 129 |
| VOLRpt                     | 130 |
| VTVMaint                   | 131 |
| VTVRPt BASIC               | 132 |
| VTVRPt COPIES              | 132 |
| Warn                       | 133 |



# Preface

---

Oracle's StorageTek Enterprise Library Software (ELS) is a solution consisting of the following base software:

- Oracle's StorageTek Storage Management Component (SMC)  
(includes the product formerly known as StorageTek HTTP Server)
- Oracle's StorageTek Host Software Component (HSC)
- Oracle's StorageTek Virtual Tape Control Software (VTCS)
- Oracle's StorageTek Concurrent Disaster Recovery Test (CDRT)

Additionally, the following software is provided with the ELS package:

- Oracle's StorageTek Library Content Manager (LCM). LCM includes an enhanced version of the product formerly known as Offsite Vault Feature.
- Oracle's StorageTek Client System Component for MVS Environments (MVS/CSC)
- Oracle's StorageTek LibraryStation

This publication provides syntax for commands, control statements, and utilities provided by ELS. It is intended for storage administrators, system programmers and operators responsible for configuring and maintaining ELS.

To perform the tasks described in this publication, you should already understand the following:

- z/OS operating system
- JES2 or JES3
- Enterprise Library Software (ELS)

---

## Related Documentation

The following list contains the names of publications that provide additional information about ELS.

The documentation is available online at:

<http://docs.sun.com>

### StorageTek Enterprise Library Software (ELS)

- *Introducing ELS*
- *Installing ELS*
- *ELS Command, Control Statement, and Utility Reference*
- *ELS Messages and Codes*
- *ELS Programming Reference*
- *ELS Legacy Interfaces Reference*
- *Configuring HSC and VTCS*
- *Managing HSC and VTCS*
- *Configuring and Managing SMC*
- *ELS Disaster Recovery and Offsite Data Management Guide*

### StorageTek Library Content Manager (LCM)

- *LCM User's Guide*
- *LCM Messages and Codes*
- *LCM Quick Reference*

### StorageTek Client System Component for MVS Environments (MVS/CSC)

- *MVS/CSC Configuration Guide*
- *MVS/CSC Messages and Codes Guide*
- *MVS/CSC Operator's Guide*
- *MVS/CSC Syntax Quick Reference*
- *MVS/CSC System Programmer's Guide*

### StorageTek LibraryStation

- *LibraryStation Configuration and Administration Guide*
- *LibraryStation Syntax Quick Reference*

---

# Documentation, Support, and Training

| Function      | URL                                                                                                                                               |
|---------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| Oracle Home   | <a href="http://oracle.com">http://oracle.com</a>                                                                                                 |
| Documentation | <a href="http://docs.sun.com">http://docs.sun.com</a>                                                                                             |
| Support       | <a href="http://www.sun.com/support">http://www.sun.com/support</a>                                                                               |
| Training      | <a href="http://www.oracle.com/global/us/education/sun_select_country.html">http://www.oracle.com/global/us/education/sun_select_country.html</a> |

---

## Oracle Welcomes Your Comments

Oracle is interested in improving its documentation and welcomes your comments and suggestions. Submit your comments by clicking the Feedback link at:

<http://docs.sun.com>

---

# Additional Information

## Customer-initiated Maintenance

Customer-initiated maintenance begins with a telephone call from you to Oracle StorageTek Support. You receive immediate attention from qualified Oracle personnel, who record problem information and respond with the appropriate level of support.

To contact Oracle StorageTek Support about a problem:

1. Use the telephone and call:

**☎ 800.872.4786 (1.800.USA.4SUN)** (inside the United States)

**☎ 800.722.4786** (Canada)

For international locations:

<http://www.sun.com/contact/support.jsp>

2. Describe the problem to the call taker. The call taker will ask several questions and will either route your call to or dispatch a support representative.

If you have the following information when you place a service call, the process will be much easier:

|                                 |  |
|---------------------------------|--|
| Account name                    |  |
| Site location number            |  |
| Contact name                    |  |
| Telephone number                |  |
| Equipment model number          |  |
| Device address                  |  |
| Device serial number (if known) |  |
| Urgency of problem              |  |
| Fault Symptom Code (FSC)        |  |
| Problem description             |  |
|                                 |  |
|                                 |  |
|                                 |  |
|                                 |  |

# Conventions for Reader Usability

## Typographic

Some JCL examples in this guide include *italic* type. Italic type is used to indicate a variable. You must substitute an actual value for these variables.


The use of mixed upper and lower case characters for commands, control statements, and parameters indicates that lower case letters may be omitted to form abbreviations. For example, you may simply enter POL when executing the POLicy command.

## Syntax Flow Diagrams

Syntax flow diagramming conventions include the following:


### Flow Lines

Syntax diagrams consist of a horizontal base line, horizontal and vertical branch lines, and the text for a command, control statement, macro, or utility. Diagrams are read left to right, and top to bottom. Arrows indicate flow and direction.




### Single Required Choice

Branch lines (without repeat arrows) indicate that a single choice must be made. If one of the items to choose from is positioned on the baseline of the diagram, one item must be selected.




## Single Optional Choice

If the first item is positioned on the line below the baseline, one item may be optionally selected.




## Defaults

Default values and parameters appear above the baseline.




Some keyword parameters provide a choice of values in a stack. When the stack contains a default value, the keyword and the value choices are placed below the baseline to indicate that they are optional, and the default value appears above the keyword line.



## Repeat Symbol

A repeat symbol indicates that more than one choice can be made or that a single choice can be made more than once. The following example indicates that a comma is required as the repeat delimiter.





## *Keywords*

All command keywords are shown in all upper case or in mixed case. When commands are not case sensitive, mixed case implies that the lowercase letters may be omitted to form an abbreviation.

## *Variables*

Italic type is used to indicate a variable.

## *Alternatives*

A bar ( | ) is used to separate alternative parameter values.

## *Optional*

Brackets [ ] are used to indicate that a command parameter is optional.

## *Delimiters*

If a comma (,), a semicolon (;), or other delimiter is shown with an element of the syntax diagram, it must be entered as part of the statement.

## *Ranges*

An inclusive range is indicated by a pair of elements of the same length and data type, joined by a dash. The first element must be strictly less than the second element.

A hexadecimal range consists of a pair of hexadecimal numbers (for example, 0A2-0AD, or 000-0FC).

A decimal range consists of a pair of decimal numbers (i.e., 1-9, or 010-094). Leading zeros are not required. The decimal portion is referred to as an incremental range. The character positions of the incremental portion of both range elements must match, and the non incremental characters of the first element must be identical to those of the second element.

A numeric VOLSER range (*vol-range*) consists of a pair of VOLSER elements containing a decimal numeric portion of 1 to 6 digits (for example, ABC012-ABC025, or X123CB-X277CB). The decimal portion is referred to as an incremental range. The following additional restrictions apply:

- The character positions of the incremental portion of both range elements must match.
- The non incremental characters of the first element must be identical to those of the second element.
- You cannot increment two portions of a range element. If 111AA△ is the first element, you cannot specify 112AAB for the second element.

- If a VOLSER range contains more than one decimal portion, any portion is valid as the incremental range. For example:

|               |                                                                   |
|---------------|-------------------------------------------------------------------|
| <u>A00B00</u> | the largest range that can be specified is A00B00 through A99B99. |
| <u>A0B0CC</u> | the largest range that can be specified is A0B0CC through A9B9CC. |
| <u>000XXX</u> | the largest range that can be specified is 000XXX through 999XXX. |

An alphabetic VOLSER range (*vol-range*) consists of a pair of VOLSER elements containing an incremental portion of 1 to 6 characters (for example, 000AAA-000ZZZ, or 9AAA55-9ZZZ55). This portion is referred to as an incremental range. The following additional restrictions apply:

- The character positions of the incremental portion of both range elements must match.
- The non incremental characters of the first element must be identical to those of the second element.
- You cannot increment two portions of a range element. If 111AAA is the first element, you cannot specify 112AAB for the second element.
- The alphabetic portion of the VOLSER range is defined as being from character A to Z. To increment multi-character sequences, each character increments to Z. For instance, ACZ is part of the AAA-AMM range. Examples are:

|                                |                                                                        |
|--------------------------------|------------------------------------------------------------------------|
| <u>A00A0</u> - <u>A99A0</u>    | increments VOLSERs A00A0 through A09A0, then A10A0 through A99A0.      |
| 9 <u>AA9A</u> -9 <u>ZZ9A</u>   | increments VOLSERs 9AA9A through 9AZ9A, then 9BA9A through 9ZZ9A.      |
| 111 <u>AAA</u> -111 <u>ZZZ</u> | increments VOLSERs 111AAA through 111AAZ, then 111ABA through 111ZZZ   |
| 999 <u>AM8</u> -999 <u>CM8</u> | increments VOLSERs 999AM8 through 999AZ8, then 999BA8 through 999CM8   |
| A3 <u>BZZ9</u> -A3 <u>CDE9</u> | increments VOLSERs A3BZZ9 through A3CAA9, then A3CAB9 through A3CDE9   |
| <u>AAAAAA</u> - <u>AAACCC</u>  | increments VOLSERs AAAAAA through AAAAAZ, then AAAABA through AAACCC   |
| <u>CCCN</u> NN- <u>DDDN</u> NN | increments VOLSERs CCCNNN through CCCNNZ, then CCCNOA through DDDNNN * |

\* **Caution:** This is a very large range.

The number of volumes in an alphabetic VOLSER range depends on the number of elements in the incrementing portion of the VOLSER range. For an A to Z range in each character position, the number of volumes can be calculated by 26 to the power of the number of positions that are being incremented.

|               |        |             |
|---------------|--------|-------------|
| A-Z           | $26^1$ | 26          |
| AA-ZZ         | $26^2$ | 676         |
| AAA-ZZZ       | $26^3$ | 17,576      |
| AAAA-ZZZZ     | $26^4$ | 456,976     |
| AAAAA-ZZZZZ   | $26^5$ | 11,881,376  |
| AAAAAA-ZZZZZZ | $26^6$ | 308,915,776 |

### *Lists*

A list consists of one or more elements. If more than one element is specified, the elements must be separated by a comma or a blank space, and the entire list must be enclosed in parentheses.

### *Blanks*

Keyword parameters and values may be separated by any number of blanks.

## Control Statements

The standard syntax conventions for control statements are as follows:

- The only valid control statement information area is from column 1 to column 72. Columns 73-80 are ignored.
- Parameters may be separated by one or more blanks or a comma.
- A value is associated with a parameter by an equal (=) sign or by enclosing the value in parentheses, and concatenating it immediately after the parameter.
- Case (upper or lower) is ignored in actual control statements.
- Continuations are supported by including a plus (+) sign at the end of the line to be continued. A control statement is terminated if the statement is not continued.
- /\* and \*/ can be used to enclose comments in the job stream. Comments can be continued over multiple lines, but cannot be nested.

PARMLIB members **must** include a /\*...\*/ comment as the **first** control statement. Otherwise, the old format is assumed. Comments in the old format must begin with an asterisk (\*) in column 1.

For definition data sets (e.g., VOLATTRs, UNITATTRs and TAPEREQs), comments **must** be in the new format (/\*...\*/).

- Asterisk (\*) comments are **not** allowed.
- A /\*...\*/ comment in the first line is **not** required.
- The maximum length for a control statement is 1024 characters.



# SMC Commands and Control Statements

---

This chapter contains syntax for SMC commands and control statements. Interface and subsystem requirement information is included with each command.

Control statements that are loaded by an operator command are described along with that command.

---

**Note** – For detailed information about the commands and control statements included in this publication, and the interfaces used to issue them, refer to the *ELS Command, Control Statement, and Utility Reference*.

---


# ALLOCDDef

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility



# ALLOCJob


## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set

UII: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# CMDDef

**Interfaces:**

Console, utility, or SMCPARMS data set  
 UII: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required





# COMMtest

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UII: Yes (No XML/CSV output)


## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility

---

**Note – Only** HSC TapePlexes or VLEs are eligible for the COMMtest command.

---




# Display DRIve

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
 UII: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility



---

# Display Volume


**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set

UII: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility




# DRIVemap

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility



---


# Help

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
UUI: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility




# HTTP

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required




# IDAX

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility






# List

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
UUI: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility






# LOG

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required




# MONitor

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

- Active SMC required
- Cannot be input to the SMCUSIM utility




# MOUNTDef

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# MSGDef

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# MSGJob

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# POLicy

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# READ

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# RESYNChronize

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility



---


# Route

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
UII: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required





# SERVer


## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set

UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# SIMulate

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# SMSDef

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# STORMNGR

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility



# TAPEPlex


## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set

UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# TCPip

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# TRace

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# TREQDef

**Interfaces:**

Console, utility, or SMCCMDS/SMCPARMS data set  
 UII: Yes (No XML/CSV output)


**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility





## TAPEREQ Control Statement




# UEXit

## Interfaces:

Console, utility, or SMCCMDS/SMCPARMS data set  
 UUI: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility




# UNITAttr

## Interfaces:

Console or SMCCMDS data set  
 UII: Yes (No XML/CSV output)

## Subsystem Requirements:

Active SMC required, or may be input to the SMCUSIM utility



---

# USERMsg


**Interfaces:**

Console or SMCPARMS data set

UII: Yes (No XML/CSV output)

**Subsystem Requirements:**

Active SMC required, or may be input to the SMCUSIM utility



## HSC and VTCS Commands and Control Statements

---

This chapter contains syntax for HSC commands and control statements. Interface and subsystem requirement information is included with each command.

Control statements that are loaded by an operator command are described along with that command.

---

**Note –**

- For detailed information about the commands and control statements included in this publication, and the interfaces used to issue them, refer to the *ELS Command, Control Statement, and Utility Reference*.
  - Certain HSC and VTCS commands are described in the *ELS Legacy Interfaces Guide*. These commands were introduced in a pre-ELS 7.0 software release and their functionality has been replaced.
-


# ACTivities

## Interfaces:

SLUADMIN utility only  
 UUI: No

## Subsystem Requirements:

Active HSC not required




# ACTMVCGN

## Interfaces:

SLUADMIN utility only  
 UUI: Yes

## Subsystem Requirements:

Active HSC required only when specifying the MVCPOOL parameter




# ARCHive

**Interfaces:**

Utility only  
UI: Yes

**Subsystem Requirements:**

Active HSC not required



# AUDit


## Interfaces:

Utility only

UUI: Yes, when MVC or VTSS is specified

## Subsystem Requirements:

- Active HSC/VTCS (AUDit MVC, VTSS, or INVLDMIR)
- Active HSC at FULL service level (all others)





# BACKup

## Interfaces:

SLUADMIN utility only  
 UI: No

## Subsystem Requirements:

Active HSC not required

▶▶BACKup◀◀

# CANcel

## Interfaces:

Console or utility  
 UI: Yes

## Subsystem Requirements:

Active HSC/VTCS

▶▶CANcel◀◀  
 ID(*process-id*)  
 Type(  
 ALL  
 MIGrate  
 RECA11  
 RECLaim  
 )


# CAPPref

## Interfaces:

Console or PARMLIB  
 UII: No

## Subsystem Requirements:

Active HSC at FULL service level




# CDs

## Interfaces:

Console or PARMLIB  
 UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# CDSDAta

## Interfaces:

Utility only  
 UUI: Yes

## Subsystem Requirements:

Active HSC not required




# CDSDEF

## Interfaces:

PARMLIB only  
 UUI: No

## Subsystem Requirements:

None




# CLea

## Interfaces:

Console or PARMLIB  
 UI: No

## Subsystem Requirements:

Active HSC at FULL service level




# COMMPath

## Interfaces:

Console or PARMLIB only  
 UUI: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level



---


# CONFIg

**Interfaces:**


Utility only  
UII: Yes

**Subsystem Requirements:**


Active HSC not required, and must be down on all hosts when running CONFIG RESET.




## CONFIg GLOBAL Statement




## CONFIg RECLAIM Statement




## CONFIg VTSS Statement




## CONFIg RTD Statement




## CONFIg VTD Statement



## CONFIg CLUSTER Statement




## CONFIg CLINK Statement






## CONFIg HOST Statement



## CONFIg TAPEPLEX Statement




# CONSolid

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# DEComp

**Interfaces:**

Utility only  
UII: Yes

**Subsystem Requirements:**

Active HSC not required




# DELETSCR

## Interfaces:

Console or utility  
 UI: Yes

## Subsystem Requirements:

Active HSC/VTCS




# DIRBLD

## Interfaces:

Utility only  
 UI: No

## Subsystem Requirements:

Active HSC not required




# DISMount

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC at FULL service level




# Display Acs

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC at FULL service level



---


## Display ACTive

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


## Display ALl

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at FULL service level




# Display Cap

**Interfaces:**

Console or utility  
UUI: Yes

**Subsystem Requirements:**

Active HSC at FULL service level




# Display CDS

**Interfaces:**

Console or utility  
UUI: Yes

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



---


## Display CLInk

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


## Display CLUster

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# Display CMD

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# Display COMMPath

## Interfaces:

Console or PARMLIB only  
 UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level






# Display CONFIG

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at FULL service level




# Display DRives

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at FULL service level




# Display DRIVE\_INFO

## Interfaces:

Console or utility  
 UUI: Yes

## Subsystem Requirements:

Active HSC/VTCS



---

## Display EXceptns


**Interfaces:**

Console or PARMLIB

UII: No

**Subsystem Requirements:**

Active HSC at FULL service level



---

## Display LMUPDEF


**Interfaces:**

Console or PARMLIB

UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



---


# Display LOCKs

## Interfaces:

Console or utility  
UUI: Yes

## Subsystem Requirements:

Active HSC/VTCS



---


# Display Lsm

## Interfaces:

Console or utility  
UUI: Yes

## Subsystem Requirements:

Active HSC at FULL service level




# Display Message

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at BASE or FULL service level



**Note:** *msg-range* and *msg-list* are only valid when the Display Message command is issued from a utility or programmatic interface.


# Display MGMTDEF

## Interfaces:

Console or PARMLIB  
 UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# Display MIGrate

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# Display MNTD

**Interfaces:**

Console or PARMLIB  
 UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



# Display MONitor


## Interfaces:

Console or PARMLIB

UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level



# Display MVC


## Interfaces:

Console or utility

UII: Yes

## Subsystem Requirements:

Active HSC/VTCS



---


# Display MVCPool

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


# Display OPTion

**Interfaces:**

Console or PARMLIB  
 UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level





# Display PATH


## Interfaces:

Console or PARMLIB

UII: No

## Subsystem Requirements:

Active HSC/VTCS



# Display Queue


## Interfaces:

Console or utility

UII: Yes

## Subsystem Requirements:

Active HSC/VTCS



---


# Display REPlicat

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


# Display Requests

**Interfaces:**

Console or PARMLIB  
 UII: Yes

**Subsystem Requirements:**

Active HSC at BASE or FULL service level




# Display RTD

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC/VTCS




# Display SCRatch

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# Display SEN

**Interfaces:**

Console or PARMLIB  
 UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level




# Display SERVER

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


## Display SRVlev

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC at FULL service level



---


## Display Status

**Interfaces:**

Console or PARMLIB  
UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



---


# Display STORCLas

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


# Display STORMNGR

**Interfaces:**

Console or PARMLIB  
 UII: No

**Subsystem Requirements:**

Active HSC/VTCS




# Display TASKs

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# Display THReshld

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# Display Volser

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC at BASE or FULL service level




# Display VOLUME\_INFO

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS






# Display VSCRatch

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC/VTCS




# Display VTD

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC/VTCS




# Display VTSS

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# Display VTV

**Interfaces:**

Console or utility  
 UII: Yes

**Subsystem Requirements:**

Active HSC/VTCS



---


# DRAIn

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at FULL service level




# DRTEST CREATE

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required



# DRTEST PRIMEprd

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶DRTEST—PRIMEprd—|Options|————▶◀

**Options:**

└─HOSTID(*hostid1,hostid2,...hostidn*)————▶

▶└─DRVTSS(*vtss1,vtss2,...vtssn*)————▶

└─SPARE(*vtss1,vtss2,...vtssn*)——┘

——STORMNGR(*stormngr-list*)——┘

▶─DRACS(*acsid1,acsid2,...acsid16*)————┘

**Note:** PRIMEprd is not valid when DRTEST is issued from the console.

---

## DRTEST RESET

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

►►DRTEST—RESET—►►

**Note:** RESET is not valid when DRTEST is issued from the console.

---

## DRTEST START

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC at FULL service level

►►DRTEST—START—►►

---

# DRTEST STOP

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC at FULL service level

▶▶DRTEST—STOP—▶▶


# EEXPORT

**Interfaces:**

Console or utility  
UII: Yes


**Subsystem Requirements:**

Active HSC not required





## Active HSC at FULL service level




# ENter

**Interfaces:**

Console or utility  
UUI: Yes

**Subsystem Requirements:**

Active HSC at FULL service level




# EXECParM

**Interfaces:**

PARMLIB only  
UUI: No

**Subsystem Requirements:**

None



# EXPORT


## Interfaces:

Utility only

UII: Yes

## Subsystem Requirements:

- Active HSC/VTCS at FULL service level required when specifying the VTV, MGMTCLAS, or STORCLAS parameter.
- Active HSC/VTCS not required when specifying the MVC parameter.



---

# FMTLOG

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶ FMTLOG ◀◀


# IMPORT

## Interfaces:

Utility only  
 UI: Yes

## Subsystem Requirements:

Active HSC/VTCS not required




# INITialize

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC at FULL service level




# INVENTORY

## Interfaces:

Utility only  
 UUI: Yes

## Subsystem Requirements:

Active HSC/VTCS




# LIBGen

## Interfaces:

SLUADMIN utility only  
 UUI: No

## Subsystem Requirements:

Active HSC not required



# LMUPDEF


## Interfaces:

Console or PARMLIB


UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level



## LMUPATH Control Statement






# LOGUTIL

## Interfaces:


SLUADMIN utility only  
 UUI: Yes

## Subsystem Requirements:


Active HSC not required




## LOGUTIL FOR\_LOSTMVC Statement




## LOGUTIL GENAUDIT Statement



## LOGUTIL LOCATE\_VTV



## LOGUTIL UNDELETE Statement



# MERGEcds

## Interfaces:

SLUADMIN utility only  
 UUI: No

## Subsystem Requirements:


Active HSC at BASE service level only




**Note:** If ALL is not specified, MERGEcds reads the parameters specified in the SLSMERGE DD statement.

## SLSMERGE Control Statement


### For REAL volumes:



### If the CDS contains VIRTUAL data:



### If the CDS contains VAULT data:




# MERGMFST

**Interfaces:**

Utility only  
 UI: Yes

**Subsystem Requirements:**

Active HSC not required




# MGMTDEF

**Interfaces:**


Console or PARMLIB only  
 UI: No

**Subsystem Requirements:**


Active HSC at BASE or FULL service level




## MGMTclas Control Statement




## MIGRSEL Control Statement




## MIGRVTV Control Statement




## MVCATTR Control Statement




## STORclas Control Statement




## STORLST Control Statement




## STORSEL Control Statement



## VTSSLST Control Statement



## VTSSSEL Control Statement





# MIGrate


## Interfaces:

Console or utility  
 UUI: Yes


## Subsystem Requirements:

Active HSC/VTCS

## Format 1



## Format 2




# MNTD

## Interfaces:

Console or PARMLIB only  
 UUI: No

## Subsystem Requirements:

Active HSC at FULL service level




# MODify

## Interfaces:

Console or PARMLIB only  
 UUI: No

## Subsystem Requirements:

Active HSC at FULL service level



# Mount

## Interfaces:

Console or utility  
 UUI: Yes

## Subsystem Requirements:

Active HSC at FULL service level

### To mount a specific Nearline volume on a transport:

```

▶▶Mount—volser—devaddr—
      |
      | ,
      | host-id Readonly
  
```

### To mount a scratch volume on a transport:

```

▶▶Mount—
▶
|
| SCRTCH devaddr
| PRIVAT
| host-id SUBpool(subpool-name) MEDia(media-type)
  
```

### To mount a VTV on a VTD and optionally, assign a management class to the VTV:

```

▶▶Mount—volser—devaddr—
      | SCRTCH
      | MGMTclas(mgmt-class-name)
  
```


# MOVE

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC at FULL service level




# MVCDRain

**Interfaces:**

Console or utility  
UUI: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# MVCMAINT

## Interfaces:

Utility only  
 UII: Yes

## Subsystem Requirements:

- Active HSC/VTCS required if RENVTSS is specified
- Can run in batch-only mode when there are no hosts active (on any LPAR) using the CDS that is to be updated



---


# MVCPLRPT

**Interfaces:**

Utility only  
UII: Yes

**Subsystem Requirements:**

Active HSC not required






# MVCRPt

## Interfaces:

Utility only  
 UUI: Yes

## Subsystem Requirements:

Active HSC not required




# OFFload LOGFILE

## Interfaces:

SLUADMIN utility only  
 UUI: No


## Subsystem Requirements:

Active HSC not required





# OPTION TITLE Control Statement



# OPTion


## Interfaces:

Console or PARMLIB only

UUI: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# RECall

**Interfaces:**

Console or utility  
 UUI: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# RECLaim

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC/VTCS




# RECONcil

**Interfaces:**

Utility only  
 UI: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# RECOVer

**Interfaces:**

Console or PARMLIB  
 UI: No

**Subsystem Requirements:**

Active HSC at FULL service level



---

## RELease

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at FULL service level

►►RELease—*cap-id*—————►◄

---

## REPLaceall

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC at BASE or FULL service level

►►REPLaceall—————►◄  
    └─VOLser(—*vol-list*—)─┘


# REStore

**Interfaces:**

SLUADMIN utility only  
UII: No


**Subsystem Requirements:**

HSC must be down (inactive)



# RTV Utility

**Note** – This VTCS utility is a standalone utility executed using the SWSRTV program.






## SCRAtch

### Interfaces:

Console or utility  
 UII: Yes

### Subsystem Requirements:

Active HSC at BASE or FULL service level




## SCREdist

### Interfaces:

SLUADMIN utility only  
 UII: No

### Subsystem Requirements:

Active HSC at FULL service level



---

## SENter

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at FULL service level

►►SENter—*cap-id*—————►◄

---

## SET CLNPRFX

---

**Note** – HSC must be shut down on all systems before changing the cleaning prefix.

---

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

►►SET—CLNPRFX(*prefix*)—————►◄

---

## SET COMPRFX

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶SET—COMPRFX(*cmdhex*)◀◀

---

## SET DRVHOST

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶SET—DRVHOST(

OFF  
host-id

)◀◀

---

## SET EJCTPAS

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

```
►► SET—EJCTPAS( newpswd ) ,OLDPASS(oldpswd) ►►
```

---

## SET FREEZE

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

```
►► SET—FREEZE( ON )—FORLSMID( lsm-id ) ,FORPANEL(panel) ►►
```

---

## SET HOSTID

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶SET—HOSTID(*newhost*),FORHOST(*oldhost*)————▶▶

---

## SET HSCLEVel

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶SET—HSCLEVel(OFF),FORHOST(*host-id*)————▶▶

---


## SET LOGFILE

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required



---

## SET MAJNAME

---

**Note** – HSC must be shut down on all systems before changing the QNAME.


---

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

- Active HSC not required
- HSC must be shut down on all systems before changing the QNAME.




# SET MIGOPT

## Interfaces:

Console or utility  
 UII: Yes

## Subsystem Requirements:

Active HSC/VTCS




# SET NEWHOST

## Interfaces:

SLUADMIN utility only  
 UII: No

## Subsystem Requirements:

Active HSC not required




# SET RMM

**Interfaces:**

Console or utility  
UUI: Yes

**Subsystem Requirements:**

Active HSC/VTCS




# SET SCRLABL

**Interfaces:**

SLUADMIN utility only  
UUI: No

**Subsystem Requirements:**

Active HSC not required





# SET SLIDRIVS


**Caution** – For 9310 and 9740 libraries, Sun recommends you bring the HSC down on all hosts before specifying this parameter, and recycle the HSC after every SET SLIDRIVS operation.

## Interfaces:

SLUADMIN utility only  
 UII: No

## Subsystem Requirements:

Active HSC not required




# SET SLISTATN

## Interfaces:

SLUADMIN utility only  
 UII: No

## Subsystem Requirements:

Active HSC not required



---

## SET SMF

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶SET—SMF(*libtype*)—————▶◀

---

## SET TAPEplex

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required

▶▶SET—TAPEplex(*tapeplex-name*)—————▶◀

---


# SET TCHNIQE

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required




# SET VAULT

**Interfaces:**

SLUADMIN utility only  
 UII: No

**Subsystem Requirements:**

Active HSC not required




# SET VAULTVOL

**Interfaces:**

SLUADMIN utility only  
 UII: No

**Subsystem Requirements:**

Active HSC not required



---


# SET VOLPARM

**Interfaces:**


SLUADMIN utility only  
UII: No

**Subsystem Requirements:**


Active HSC not required



## POOLPARM Control Statement



## VOLPARM Control Statement



---


## SRVlev

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



---


## STOPMN

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



---

# SWitch

**Interfaces:**

Console or PARMLIB only  
UII: No

**Subsystem Requirements:**

Active HSC at FULL service level

The diagram shows the command syntax for the SWitch command. It starts with a double arrow pointing right, followed by the text 'Switch'. A vertical line descends from 'Switch' and connects to a horizontal line that extends to the right. Below this horizontal line, the text 'Acs acs-id' is written. The entire diagram is enclosed in a rectangular box.

**Note:** ACS *acs-id* is optional in a single ACS environment; it is required in a multi-ACS environment.

---

# TRace

**Interfaces:**

Console or utility  
UII: Yes

**Subsystem Requirements:**

Active HSC at BASE or FULL service level

The diagram shows the command syntax for the TRace command. It starts with a double arrow pointing right, followed by the text 'TRace'. A vertical line descends from 'TRace' and connects to a horizontal line that extends to the right. Below this horizontal line, the text 'OFF' is written. To the right of 'OFF', there is a vertical line that connects to a horizontal line. Below this horizontal line, the text 'comp-name' is written. To the right of 'comp-name', there is a vertical line that connects to a horizontal line. Below this horizontal line, the text 'comp-list' is written. The entire diagram is enclosed in a rectangular box.




# TRACELKP

## Interfaces:

Console or PARMLIB only  
 UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level




# UEXIT

## Interfaces:

Console or PARMLIB only  
 UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level



---

## UNSCratch


**Interfaces:**

Console or utility

UII: Yes

**Subsystem Requirements:**

Active HSC at BASE or FULL service level



---

## UNSElect


**Interfaces:**

SLUADMIN utility only

UII: No

**Subsystem Requirements:**

Active HSC not required



# Vary


## Interfaces:

- Console or PARMLIB (Vary ACS)
- Console or utility, UII All (Vary CLINK, RTD, or VTSS)

UII: Yes

## Subsystem Requirements:

- Active HSC at FULL service level (Vary ACS)
- Active HSC/VTCS (Vary CLINK, RTD, or VTSS)




# View

## Interfaces:

Console or PARMLIB only  
 UUI: No

## Subsystem Requirements:

Active HSC at FULL service level



---


# VOLPCONV

**Interfaces:**

SLUADMIN utility only  
UII: No

**Subsystem Requirements:**

Active HSC not required




# VOLRpt

## Interfaces:

Utility only  
 UUI: Yes

## Subsystem Requirements:

Active HSC not required



### Interfaces:

### Subsystem Requirements:

```

sequenceDiagram
    participant User
    participant VTL as VTL API
    User->>VTL: VTVMaint(VTid(volser))
    VTL->>VTL: ULINKMVC(volser)
    VTL->>VTL: MGMTclas(mgmt-clas-name)
    VTL->>VTL: DISMOUNT(VTSSid(name))
    VTL->>VTL: OWNRPlex(name)
    VTL->>VTL: DELEXpot(name)
    VTL->>VTL: ADDEXpot(name)
    VTL->>VTL: RENVTSS(vtss-name)
  
```

The diagram illustrates the sequence of VTL API calls for creating and managing a virtual tape library. The sequence is as follows:

- VTVMaint(VTid(volser))**: Initial call to create the VTL.
- ULINKMVC(volser)**: Call to link the VTL to the ULINKMVC.
- MGMTclas(mgmt-clas-name)**: Call to create the management class.
- DISMOUNT(VTSSid(name))**: Call to dismount the VTL.
- OWNRPlex(name)**: Call to create the ownershipplex.
- DELEXpot(name)**: Call to delete the ownershipplex.
- ADDEXpot(name)**: Call to add the ownershipplex.
- RENVTS(vtss-name)**: Call to create the VTL.


# VTVRPt BASIC

**Interfaces:**

Utility only  
UUI: Yes

**Subsystem Requirements:**

Active HSC not required




# VTVRPt COPIES

**Interfaces:**

Utility only  
UUI: Yes

**Subsystem Requirements:**

Active HSC not required





# Warn

## Interfaces:

Console or PARMLIB only  
 UII: No

## Subsystem Requirements:

Active HSC at BASE or FULL service level

