

Tekelec EAGLE[®] 5
Integrated Signaling System

Release 35.0

Commands Error Recovery Manual

910-3219-001 Revision B

August 2006



TEKELEC

Copyright 2006 Tekelec

**All Rights Reserved
Printed in U.S.A.**

Notice

Information in this documentation is subject to change without notice. Unauthorized use or copying of this documentation can result in civil or criminal penalties.

Any export of Tekelec products is subject to the export controls of the United States and the other countries where Tekelec has operations.

No part of this documentation may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying or recording, for any purpose without the express written permission of an authorized representative of Tekelec.

Other product names used herein are for identification purposes only, and may be trademarks of their respective companies.

RoHS 5/6 - As of July 1, 2006, all products that comprise new installations shipped to European Union member countries will comply with the EU Directive 2002/95/EC "RoHS" (Restriction of Hazardous Substances). The exemption for lead-based solder described in the Annex will be exercised. RoHS 5/6 compliant components will have unique part numbers as reflected in the associated hardware and installation manuals.

WEEE - All products shipped to European Union member countries comply with the EU Directive 2002/96/EC, Waste Electronic and Electrical Equipment. All components that are WEEE compliant will be appropriately marked. For more information regarding Tekelec's WEEE program, contact your sales representative.

Trademarks

The Tekelec logo, EAGLE, G-Flex, G-Port, IP⁷, IP⁷Edge, IP⁷ Secure Gateway, and TALI are registered trademarks of Tekelec, Inc. TekServer is a trademark of Tekelec, Inc. All other trademarks are the property of their respective owners.

Patents

This product is covered by one or more of the following U.S. and foreign patents:

U.S. Patent Numbers:

5,008,929, 5,953,404, 6,167,129, 6,324,183, 6,327,350, 6,456,845, 6,606,379, 6,639,981, 6,647,113, 6,662,017, 6,735,441, 6,745,041, 6,765,990, 6,795,546, 6,819,932, 6,836,477, 6,839,423, 6,885,872, 6,901,262, 6,914,973, 6,940,866, 6,944,184, 6,954,526, 6,954,794, 6,959,076, 6,965,592, 6,967,956, 6,968,048, 6,970,542

Ordering Information

To order additional copies of this document, contact your Tekelec Sales Representative.

Table of Contents

Chapter 1. Introduction	
Overview	1-2
Scope and Audience	1-2
Related Publications	1-3
Customer Care Center	1-8
Documentation Packaging, Delivery, and Updates.....	1-8
Chapter 2. Command Rejected Messages	
Introduction	2-2
Message Listing and Description 2	
Chapter 3. SEAS Error Messages	
Introduction	3-2
Message Listing and Description.....	3-2
Appendix A. Acronyms and Abbreviations	
Index	

Table of Contents

List of Tables

Table 2-1. Valid Frame ID Parameter Values	2-18
Table 2-2. Valid Card Types (type) and Application Types (appl) for the ent-card Command	2-32
Table 2-3. Valid Values for the bps Parameter	2-52
Table 2-4. Invalid Parameter Combinations that Generate an E2155 Error Message	2-56
Table 2-5. Conditions that Generate an E2165 Error Message	2-61
Table 2-6. Conditions that Generate an E2257 Error Message	2-100
Table 2-7. Valid type/period Parameters for the rept-meas Command	2-110
Table 2-8. Valid type/period Parameters for the rept-ftp-meas Command	2-110
Table 2-9. Valid type/entype Parameters for the rept-meas Command	2-111
Table 2-10. Valid type/entype Parameters for the rept-ftp-meas Command	2-112
Table 2-11. Operations Requiring force=yes Parameter	2-147
Table 2-12. Conditions the Generate an E2581 Error Message	2-234
Table 2-13. Valid Port and Application Type Combinations	2-238
Table 2-14. Action if X.25 Route Table is Full	2-270
Table 2-15. Action if X.25 Route Table is Full	2-278
Table 2-16. Routesets Feature with Maximum Values for mtpdpcq and mtpxlq Parameters	2-344
Table 2-17. Routesets Feature with Maximum Values for mtpdpcq and mtpxlq Parameters	2-357
Table 2-18. Conditions that Generate an E2903 Error Message	2-369
Table 2-19. Valid dev/port Parameter Combinations	2-386
Table 2-20. Valid Parameter Combinations for an E3269 Error Message	2-463
Table 2-21. Valid Values for the nsfi Parameter	2-464
Table 2-22. Possible Low-speed and High-speed Link Combinations for 1500 Links	2-478
Table 2-23. Valid Transmission Rates for the bps Parameter	2-482

List of Tables

Table 2-24. Routesets Feature with Maximum Values for the <code>mtpdpcq</code> and <code>mtpxlq</code> Parameters.	2-483
Table 2-25. Routesets Feature with Maximum Values for the <code>mtpdpcq</code> and <code>mtpxlq</code> Parameters.	2-498
Table 2-26. Conditions that Generate an E3500 Error Message	2-517
Table 2-27. Conditions that Generate an E3524 Error Message	2-523
Table 2-28. TSM and TDM Memory Requirements	2-560
Table 2-29. Valid Subnet Mask Values	2-584
Table 2-30. Conditions that Generate an E3779 Error Message	2-601
Table 2-31. Valid Parameter Combinations for Routing Key Types using the <code>chg-appl-rtkey</code> Command	2-619
Table 2-32. Reason that Card Requires a Full Data Download	2-628
Table 2-33. Valid CIC Ranges for SI and MSU Types	2-641
Table 2-34. Conditions that Generate an E3883 Error Message	2-644
Table 2-35. Conditions that Generate an E3932 Error Message	2-663
Table 2-36. Conditions that Generate an E4005 Error Message	2-686
Table 2-37. Valid PVN Subnet Mask Values	2-690
Table 2-38. Routing Keys and Supported PSTN Categories and PSTN IDs for PSTN Category 1	2-696
Table 2-39. Number of Allowed Prefixes	2-800
Table 2-40. Parameter Combinations for the <code>inh-alm</code> Command	2-810
Table 2-41. Valid Frame ID Parameter Values	2-862
Table 2-42. EAGLE 5 ISS Link Cards Not Supported	2-871
Table 2-43. Default Buffer Configuration Sizes	2-878
Table 3-1. SEAS Cross Reference Table	3-3

1

Introduction

Overview	1-2
Scope and Audience	1-2
Related Publications	1-3
Customer Care Center	1-8
Documentation Packaging, Delivery, and Updates	1-8

Overview

The *Commands Error Recovery Manual* provides a description of the error messages used in the EAGLE 5 ISS.

Commands are entered at a terminal to perform system operations such as displaying the system status, administering system security, and maintaining the database. The error messages documented in this book are displayed to provide information about problems encountered when you enter commands.

This document is organized into the following chapters.

Chapter 1, *Introduction* contains general information about the organization of this manual, the audience, references to other Tekelec documentation you might need, information on customer assistance, documentation packaging, delivery, and updates, and a list of acronyms and abbreviations used in the document.

Chapter 2, *Command Rejected Messages* contains the error messages generated by the commands used on the system. These error messages are presented in alphabetical order. The following items are included in the description of each message:

- The error message generated by the system.
- A list of the commands that can generate the error message. Note that where such a list would be extensive, only a representative sample of commands is provided.
- A brief definition of the error message.
- The actions needed to resolve the error condition or to make sure that the error message does not appear when the command is executed again.

Chapter 3, *SEAS Error Messages* contains an index of all of the Signaling Engineering and Administration System (SEAS) error messages generated by the EAGLE 5 ISS.

In addition, an index provides an alphabetical listing of error message text and other entries to assist in finding information.

Scope and Audience

This manual is intended for those who maintain the system and those who do database administration for the system. It is assumed that the user is familiar with the SS7 network and its associated protocols. The manual provides command rejected messages for the system.

Related Documentation

The *Commands Error Recovery Manual* is part of the EAGLE 5 ISS documentation set and may refer to one or more of the following manuals:

- The *Commands Error Recovery Manual* contains the procedures to resolve error message conditions generated by the commands in the *Commands Manual*. These error messages are presented in numerical order.
- The *Commands Manual* contains procedures for logging into or out of the EAGLE 5 ISS, a general description of the terminals, printers, the disk drive used on the system, and a description of all the commands used in the system.
- The *Commands Pocket Guide* is an abridged version of the *Commands Manual*. It contains all commands and parameters, and it shows the command-parameter syntax.
- The *Commands Quick Reference Guide* contains an alphabetical listing of the commands and parameters. The guide is sized to fit a shirt-pocket.
- The *Database Administration Manual – Features* contains procedural information required to configure the EAGLE 5 ISS to implement these features:
 - X.25 Gateway
 - STP LAN
 - Database Transport Access
 - GSM MAP Screening
 - EAGLE 5 Integrated Monitoring Support
- The *Database Administration Manual - Gateway Screening* contains a description of the Gateway Screening (GWS) feature and the procedures necessary to configure the EAGLE 5 ISS to implement this feature.
- The *Database Administration Manual – Global Title Translation* contains procedural information required to configure an EAGLE 5 ISS to implement these features:
 - Global Title Translation
 - Enhanced Global Title Translation
 - Variable Length Global Title Translation
 - Interim Global Title Modification
 - Intermediate GTT Load Sharing
 - ANSI-ITU-China SCCP Conversion
 - Flexible GTT Load Sharing
 - Origin-based SCCP Routing

- The *Database Administration Manual - IP7 Secure Gateway* contains procedural information required to configure the EAGLE 5 ISS to implement the SS7-IP Gateway.
- The *Database Administration Manual - SEAS* contains the EAGLE 5 ISS configuration procedures that can be performed from the Signaling Engineering and Administration Center (SEAC) or a Signaling Network Control Center (SNCC). Each procedure includes a brief description of the procedure, a flowchart showing the steps required, a list of any EAGLE 5 ISS commands that may be required for the procedure but that are not supported by SEAS, and a reference to optional procedure-related information, which can be found in one of these manuals:
 - *Database Administration Manual - Gateway Screening*
 - *Database Administration Manual - Global Title Translation*
 - *Database Administration Manual - SS7*
- The *Database Administration Manual - SS7* contains procedural information required to configure an EAGLE 5 ISS to implement the SS7 protocol.
- The *Database Administration Manual - System Management* contains procedural information required to manage the EAGLE 5 ISS database and GPLs, and to configure basic system requirements such as user names and passwords, system-wide security requirements, and terminal configurations.
- The *Dimensioning Guide for EPAP Advanced DB Features* is used to provide EPAP planning and dimensioning information. This manual is used by Tekelec personnel and EAGLE 5 ISS customers to aid in the sale, planning, implementation, deployment, and upgrade of EAGLE 5 ISS systems equipped with one of the EPAP Advanced Database (EADB) Features.
- The *ELAP Administration Manual* defines the user interface to the EAGLE LNP Application Processor on the MPS/ELAP platform. The manual defines the methods for accessing the user interface, menus, screens available to the user and describes their impact. It provides the syntax and semantics of user input and defines the output the user receives, including information and error messages, alarms, and status.
- The *Feature Manual - ECAP* provides instructions and information on how to install, use, and maintain the Integrated Accounting Feature Application feature on the Eagle Collector Application Processor (ECAP). This feature collects raw MSU data from the EAGLE 5 ISS, categorizes the data into groups, and feeds those groups to another system for accounting activities. Additional features will be added to this manual at a later date.

Introduction

- The *EPAP Administration Manual* describes how to administer the EAGLE Provisioning Application Processor on the MPS/EPAP platform. The manual defines the methods for accessing the user interface, menus, and screens available to the user and describes their impact. It provides the syntax and semantics of user input and defines the output the user receives, including messages, alarms, and status.
- The *Feature Manual - EIR* provides instructions and information on how to install, use, and maintain the EIR feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS. The feature provides network operators with the capability to prevent stolen or disallowed GSM mobile handsets from accessing the network.
- The *Feature Manual - G-Flex C7 Relay* provides an overview of a feature supporting the efficient management of Home Location Registers in various networks. This manual gives the instructions and information on how to install, use, and maintain the G-Flex feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.
- The *Feature Manual - G-Port* provides an overview of a feature providing the capability for mobile subscribers to change the GSM subscription network within a portability cluster while retaining their original MSISDNs. This manual gives the instructions and information on how to install, use, and maintain the G-Port feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.
- The *Feature Manual - INP* provides the user with information and instructions on how to implement, utilize, and maintain the INAP-based Number Portability (INP) feature on the Multi-Purpose Server (MPS) platform of the EAGLE 5 ISS.
- The *FTP-Based Table Retrieve Application (FTRA) User Guide* describes how to set up and use a PC to serve as the offline application for the EAGLE 5 ISS FTP Retrieve and Replace feature.
- The *Hardware Manual - EAGLE 5 ISS* contains hardware descriptions and specifications of Tekelec's signaling products. These include the EAGLE 5 ISS, OEM-based products such as the ASi 4000 Service Control Point (SCP), the Netra-based Multi-Purpose Server (MPS), and the Integrated Sentinel with Extended Services Platform (ESP) subassembly.

The Hardware Manual provides an overview of each system and its subsystems, details of standard and optional hardware components in each system, and basic site engineering. Refer to this manual to obtain a basic understanding of each type of system and its related hardware, to locate detailed information about hardware components used in a particular release, and to help configure a site for use with the system hardware.

- The *Hardware Manual - Tekelec 1000 Application Server* provides general specifications and a description of the Tekelec 1000 Applications Server (T1000 AS). This manual also includes site preparation, environmental and other requirements, procedures to physically install the T1000 AS, and troubleshooting and repair of Field Replaceable Units (FRUs).
- The *Hardware Manual - Tekelec 1100 Application Server* provides general specifications and a description of the Tekelec 1100 Applications Server (T1100 AS). This manual also includes site preparation, environmental and other requirements, procedures to physically install the T1100 AS, and troubleshooting and repair of Field Replaceable Units (FRUs).
- The *Installation Manual - EAGLE 5 ISS* contains cabling requirements, schematics, and procedures for installing the EAGLE 5 ISS along with LEDs, connectors, cables, and power cords to peripherals. Refer to this manual to install components or the complete systems.
- The *Installation Manual - Integrated Applications* provides the installation information for integrated applications such as EPAP 4.0 or earlier (Netra-based Multi-Purpose Server (MPS) platform) and Sentinel. The manual includes information about frame floors and shelves, LEDs, connectors, cables, and power cords to peripherals. Refer to this manual to install components or the complete systems.
- The *LNP Database Synchronization Manual - LSMS with EAGLE 5 ISS* describes how to keep the LNP databases at the LSMS and at the network element (the EAGLE 5 ISS is a network element) synchronized through the use of resynchronization, audits and reconciles, and bulk loads. This manual is contained in both the LSMS documentation set and in the EAGLE 5 ISS documentation set.
- The *LNP Feature Activation Guide* contains procedural information required to configure the EAGLE 5 ISS for the LNP feature and to implement these parts of the LNP feature on the EAGLE 5 ISS:
 - LNP services
 - LNP options
 - LNP subsystem application
 - Automatic call gapping
 - Triggerless LNP feature
 - Increasing the LRN and NPANXX Quantities on the EAGLE 5 ISS
 - Activating and Deactivating the LNP Short Message Service (SMS) feature
- The *Maintenance Manual* contains procedural information required for maintaining the EAGLE 5 ISS and the card removal and replacement procedures. The *Maintenance Manual* provides preventive and corrective maintenance procedures used in maintaining the different systems.

Introduction

- The *Maintenance Pocket Guide* is an abridged version of the Maintenance Manual and contains all the corrective maintenance procedures used in maintaining the EAGLE 5 ISS.
- The *Maintenance Emergency Recovery Pocket Guide* is an abridged version of the Maintenance Manual and contains the corrective maintenance procedures for critical and major alarms generated on the EAGLE 5 ISS.
- The *MPS Platform Software and Maintenance Manual - EAGLE 5 ISS with Tekelec 1000 Application Server* describes the platform software for the Multi-Purpose Server (MPS) based on the Tekelec 1000 Application Server (T1000 AS) and describes how to perform preventive and corrective maintenance for the T1000 AS-based MPS. This manual should be used with the EPAP-based applications (EIR, G-Port, G-Flex, and INP).
- The *MPS Platform Software and Maintenance Manual - EAGLE 5 ISS with Tekelec 1100 Application Server* describes the platform software for the Multi-Purpose Server (MPS) based on the Tekelec 1100 Application Server (T1100 AS) and describes how to perform preventive and corrective maintenance for the T1100 AS-based MPS. This manual should be used with the ELAP-based application (LNP).
- The *Provisioning Database Interface Manual* defines the programming interface that populates the Provisioning Database (PDB) for the EAGLE 5 ISS features supported on the MPS/EPAP platform. The manual defines the provisioning messages, usage rules, and informational and error messages of the interface. The customer uses the PDBI interface information to write his own client application to communicate with the MPS/EPAP platform.
- The *Previously Released Features Manual* summarizes the features of previous EAGLE, EAGLE 5 ISS, and IP⁷ Secure Gateway releases, and it identifies the release number of their introduction.
- The *Release Documentation* contains the following documents for a specific release of the system:
 - *Feature Notice* - Describes the features contained in the specified release. The Feature Notice also provides the hardware baseline for the specified release, describes the customer documentation set, provides information about customer training, and explains how to access the Customer Support website.
 - *Release Notice* - Describes the changes made to the system during the lifecycle of a release. The Release Notice includes Generic Program Loads (GPLs), a list of PRs resolved in a build, and all known PRs.
NOTE: The Release Notice is maintained solely on Tekelec's Customer Support site to provide you with instant access to the most up-to-date release information.
 - *System Overview* - Provides high-level information on SS7, the IP7 Secure Gateway, system architecture, LNP, and EOAP.

- *Master Glossary* - Contains an alphabetical listing of terms, acronyms, and abbreviations relevant to the system.
- *Master Index* - Lists all index entries used throughout the documentation set.
- The *System Manual – EOAP* describes the Embedded Operations Support System Application Processor (EOAP) and provides the user with procedures on how to implement the EOAP, replace EOAP-related hardware, device testing, and basic troubleshooting information.

Customer Care Center

The Customer Care Center offers a point of contact through which customers can receive support for problems that may be encountered during the use of Tekelec's products. The Customer Care Center is staffed with highly trained engineers to provide solutions to your technical questions and issues seven days a week, twenty-four hours a day. A variety of service programs are available through the Customer Care Center to maximize the performance of Tekelec products that meet and exceed customer's needs.

To receive technical assistance, call the Customer Care Center at one of the following locations:

- Tekelec, UK
Phone +44 1784 467 804
Fax +44 1784 477 120
E-mail ecsc@tekelec.com
- Tekelec, USA
Phone (within the continental US) 888-367-8552 (888-FOR-TKLC)
(outside the continental US) +1 919-460-2150
Fax 919-460-0877
E-mail support@tekelec.com

Documentation Packaging, Delivery, and Updates

Customer documentation is provided with each system in accordance with the contract agreements. It is updated whenever significant changes that affect system operation or configuration are made. Updates may be issued as an addendum, or a reissue of the affected documentation.

The document part number appears on the title page along with the current revision of the document, the date of publication, and the software release that the document covers. The bottom of each page contains the document part number and date of publication.

Introduction

Two types of releases are major software releases and maintenance releases. Maintenance releases are issued as addenda with a title page and change bars. On the changed pages, the date and document part number are changed. On any unchanged pages that accompany the changed pages, the date and document part number is unchanged.

When the software release has a minimum effect on documentation, we provide an addendum. The addendum provides an instruction page, a new title page, a change history page, and replacement chapters with the date of publication, the document part number, and change bars.

If a new release has a major impact on documentation, such as a new feature, the entire documentation set is reissued with a new part number and a new release number.

Command Rejected Messages

Introduction	2-2
Message Listing and Description.....	2-2

Introduction

This chapter contains the command rejected error messages generated by the commands used on the EAGLE 5 ISS. The following items make up each description of the error message:

- The error message generated by the EAGLE 5 ISS.
- A list of the commands that can generate the error message. Note that where such a list would be extensive, only a representative sample of commands is provided.
- A brief definition of the error message.
- The actions needed to resolve the error condition or to make sure that the error message does not appear when the command is executed again.

To find error messages listed alphabetically by their text, see the index.

The commands that generate the error messages in this document are described in the *Commands Manual*.

Message Listing and Description

Command rejected messages are listed below in numerical order.

E2001 Cmd Rej: Undefined msg#

Commands Used: `chg-cmd`, `rtrv-cmd`

The `cmd` parameter value must be a valid system command.

Recovery

Re-enter the command specifying a valid system command.

Refer to the *Commands Manual* for additional information regarding valid format, parameters, and syntax for these commands.

E2002 Cmd Rej: Authority Violation

Commands Used: `a11 commands`

You cannot enter a command at a system terminal if you have not logged on to the EAGLE 5 ISS, or if your user ID does not have the authorization to access the command class for the command you tried to enter.

Recovery

1. Log on to the EAGLE 5 ISS. Enter the `logon:uid=<user id>` command and then enter your password.
 2. If after logging on, you are still unable to enter the command, contact your site system administrator to obtain user command access privileges to the EAGLE 5 ISS.
-

E2003 Cmd Rej: Terminal Authority Violation

Commands Used: `a11 commands`

You cannot enter a command at a terminal that is not authorized for that EAGLE 5 ISS command class.

Recovery

Perform one of the following:

- Re-enter the command at another terminal that is authorized for that EAGLE 5 ISS command class.

OR

- Contact the system administrator to discuss EAGLE 5 ISS terminal command access privileges for the terminal you used to enter the command originally.

OR

- If you have system administration authority, change the privileges for the terminal. Enter the `chg-secu-trm` command.

NOTE: You cannot issue this command on the target terminal.

E2004 Cmd Rej: Keyboard is locked. Enter UNLOCK command

Commands Used: `a11 commands`

The keyboard for the terminal was locked using the `lock` command.

Recovery

Unlock the keyboard. Enter the `unlock` command. Anyone attempting to use the keyboard will be prompted to enter the password of the currently logged-on user.

E2005 Cmd Rej: Argument frame overflow

Commands Used: `a11 commands`

You entered a command in which the frame for the argument detected an overflow condition. Re-enter the command specifying the correct format for the command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

Call your Customer Care Center if this error message appears again.

E2006 Cmd Rej: Missing parameter block separator

Commands Used: `All commands that have parameters`

You specified an incorrect block separator. To separate multiple parameter blocks use a colon (:).

Recovery

Re-enter the command specifying a colon (:) between the input values.

Refer to the *Commands Manual* for additional information regarding the command syntax.

E2007 Cmd Rej: Too many errors in this command

Commands Used: `All commands`

You entered a command, in which too many errors have been detected to allow continued processing. Re-enter the command specifying the correct format for the command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

Call your Customer Care Center if this error message appears again.

E2008 Cmd Rej: Missing command identifier

Commands Used: All commands

You entered a command without specifying a keyword. Keywords identify the principal action to be performed by the system and consist of one to three words. In the following example, **dact-slk** is the keyword:

dact-slk:loc=1101:port=a

Recovery

Re-enter the command specifying a keyword.

Refer to the *Commands Manual* for information regarding the correct keyword.

E2009 Cmd Rej: Missing modifier separator

Commands Used: All commands that have parameters

You specified an incorrect modifier separator. Use a hyphen (-) to separate multiple values within a parameter block.

Recovery

Re-enter the command specifying a hyphen (-) between the input values.

Refer to the *Commands Manual* for additional information regarding command syntax.

E2010 Cmd Rej: Unrecognized command

Commands Used: All commands

You entered a command that the EAGLE 5 ISS does not recognize.

Recovery

1. Verify that you have typed the command correctly.

Refer to the *Commands Manual* for additional information regarding the correct keyword.

2. Make any necessary corrections, and then re-enter the command.
-

E2011 Cmd Rej: Missing mandatory parameter - <parm>

Commands Used: all commands

You failed to specify a required parameter value for the entered command.

Recovery

Re-enter the command specifying a valid mandatory command parameter.

Refer to the *Commands Manual* for valid parameter values for this command.

Call your Customer Care Center if this error message appears again.

E2012 Cmd Rej: Cannot specify ALL=YES when command given

Commands Used: all commands

You attempted to run the command specifying the **all=yes** parameter, which is invalid for the command.

Recovery

Re-enter the command that generated this error message specifying and appropriate value for the **all** parameter.

Refer to the *Commands Manual* for detailed information about the use of the command.

Call your Customer Care Center if this error message appears again.

E2013 Cmd Rej: Missing argument assignment operator

Commands Used: all commands

The command you entered requires an argument assignment operator. Use an equal sign (=) to assign arguments.

Recovery

Re-enter the command specifying the assignment parameter (=) properly positioned.

Refer to the *Commands Manual* for additional information regarding the proper use of argument assignment operators for the command.

Call your Customer Care Center if this error message appears again.

E2014 Cmd Rej: Unrecognized parameter identifier

Commands Used: All commands that have parameters

You specified a parameter that the EAGLE 5 ISS does not recognize.

Recovery

1. Verify that you have entered all parameters correctly.

Refer to the *Commands Manual* or information regarding the correct command syntax.

2. Make any necessary corrections and re-enter the command.
-

E2015 Cmd Rej: Missing parameter identifier

Commands Used: All commands that have parameters

You specified a parameter without an identifier that the EAGLE 5 ISS requires.

Recovery

1. Verify that you have entered all parameters correctly.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

2. Make the necessary corrections and re-enter the command.

Call your Customer Care Center if this error message appears again.

E2016 Cmd Rej: <parm_desc> is out of range - <parm>

Commands Used: all commands

You entered a parameter value that is out of range for this command.

Recovery

Re-enter the command specifying a valid value for this command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again.

E2017 Cmd Rej: <parm_desc> is out of range, <min>...<max> - <parm>

Commands Used: all commands

You specified a value that is out of range of the minimum and maximum values allowed for this command parameter.

For the **chg-frm-pwr** and **ent-frm-pwr** commands, if you specify the frame power threshold (**thrshld**) parameter, you must specify a value that is greater than or equal to **30** amps and less than or equal to **65** amps.

For the **rtrv-stp** command, if you specify the optional GPL version (**ver**) parameter (format for **ver** parameter: Major-Minor-Fix), you must specify the values from the following set:

Major: {0 - 255}

Minor: {0 - 255}

Fix: {0 - 255}

For example: **rtrv-stp:gpl=SS7ANSI:ver=027-010-000**

Recovery

Re-enter the command specifying a valid command parameter value.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again.

E2018 Cmd Rej: <parm_desc> is out of range, <min>...<max>, '<char>' - <parm>

Commands Used: all commands

You entered a value outside the range of the allowed minimum and maximum values for the command parameter.

Recovery

Re-enter the command specifying a valid value or character for the command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again.

E2019 Cmd Rej: <parm_desc> is out of range, <min>...<max>, '<char>', '<char>' - <parm>

Commands Used: all commands

You entered a value outside the range of the allowed minimum and maximum values for the command parameter.

Recovery

Re-enter the command specifying a valid value or character for the command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values and characters that are valid for the specified command parameter.

Call your Customer Care Center if this error message appears again.

E2020 Cmd Rej: Table copy command already in process

Commands Used: copy-meas

You attempted to enter a command that had already been entered, and was already running.

Recovery

1. Wait for the command to finish running.
 2. If the command does not finish running within five minutes, call your Customer Care Center. (Under ideal circumstances with minimum system activity, this command requires at least one minute to run).
-

E2021 Cmd Rej: Invalid source table

You attempted to run this command specifying an invalid syntax assigned to the source table parameter.

Recovery

Re-enter the command that generated this error message specifying the correct syntax for the source table.

Call your Customer Care Center if this error message appears again.

E2022 Cmd Rej: Invalid destination table

You attempted to run this command specifying an invalid syntax assigned to the destination table parameter.

Recovery

Re-enter the command that generated this error message specifying the correct syntax for the destination table.

Call your Customer Care Center if this error message appears again.

E2023 Cmd Rej: Invalid OAM drive

You attempted to run this command specifying an invalid syntax assigned to the Operations, Administration and Maintenance (OAM) parameter.

Recovery

Re-enter the command that generated this error message specifying the correct syntax for the OAM drive.

Call your Customer Care Center if this error message appears again.

E2024 Cmd Rej: Invalid system

A system error occurred during the execution of a command.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2025 Cmd Rej: Invalid card location

Commands Used: `act-lbp`, `dact-lbp`, `ent-card`, `tst-slk`

You specified a `loc` parameter for a card that is an invalid type for the command.

- For the `act-lbp` and `dact-lbp` commands, the card type in the specified location must be `limds0`, `limt1`, or `limch` (associated with a `limt1` card).
- For the `ent-card` command, the DSM card must be inserted into an odd-numbered card location. The n+1 slot next to the DSM card must be empty, where n is the odd-numbered location (for example, if the DSM is in location 1101, then the 1102 slot must be empty and unprovisioned).
- For the `tst-slk` command, the card type in the specified location must be a TDM or an MDAL.

Recovery

Re-enter the command that generated this error message specifying the correct `loc` parameter value for a location that contains a valid card type for the command.

Call your Customer Care Center if this error message appears again.

E2026 Cmd Rej: Already logged on

Commands Used: `all commands`

An attempt was made to log on with a user ID that is already logged on to the system.

Recovery

1. Display the user IDs in the database. Enter the `rtrv-user` command.
 2. Display the users logged on the system. Enter the `rept-stat-user` command.
 3. Re-enter the command specifying a user ID that is shown in the output of step 1 and not shown in the output of step 2.
-

E2027 Cmd Rej: IP Address requires 4 octets in the range 1 . . . 254 - <parm>

Commands Used: `all commands`

You have specified an invalid IP address. The specified command parameter has an IP address that does not contain four octets in the required range of 1 through 254.

Recovery

1. Verify the correct IP address containing the allowable range for the four octets.
2. Re-enter the command specifying the correct octet values for the command parameter.

Refer to the *Commands Manual* for the command parameter.

Call your Customer Care Center if this error message appears again.

E2028 Cmd Rej: Octet 1 is out of range, 1 . . . 223 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 1 of the specified command parameter. The value for the octet must be in the range of 1 through 223.

Recovery

Re-enter the command specifying a first octet value from 1 to 223 for this command parameter.

Call your Customer Care Center if this error message appears again.

E2029 Cmd Rej: Octet 2 is out of range, 1 . . . 254 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 2 of the specified command parameter. The value for the octet must be in the range of 1 through 254.

Recovery

Re-enter the command specifying a second octet value from 1 to 254 for this command parameter.

Call your Customer Care Center if this error message appears again.

E2030 Cmd Rej: Octet 3 is out of range, 1 . . . 254 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 3 of the specified command parameter. The value for the octet must be in the range of 1 through 254.

Recovery

Re-enter the command specifying a third octet value from **1** to **254** for this command parameter.

Call your Customer Care Center if this error message appears again.

E2031 Cmd Rej: Octet 4 is out of range, 1 . . . 254 - <parm>

Commands Used: all commands

You have entered an invalid value in octet 4 of the specified command parameter. The value for the octet must be in the range of **1** through **254**.

Recovery

Re-enter the command parameter with a fourth octet value from **1** to **254** for this command parameter.

Call your Customer Care Center if this error message appears again.

E2032 Cmd Rej: Octet 1 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the first octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the missing first octet.

Call your Customer Care Center if this error message appears again.

E2033 Cmd Rej: Octet 2 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the second octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address containing the missing second octet.

Call your Customer Care Center if this error message appears again.

E2034 Cmd Rej: Octet 3 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the third octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the missing third octet.

Call your Customer Care Center if this error message appears again.

E2035 Cmd Rej: Octet 4 missing - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address in which the fourth octet is missing.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the missing fourth octet.

Call your Customer Care Center if this error message appears again.

E2036 Cmd Rej: Too many octets specified, only require 4 - <parm>

Commands Used: all commands

You have entered for the specified command parameter an IP address that contains more than the required four octets.

Recovery

Re-enter the command parameter specifying a valid IP address that contains the required four octets.

Call your Customer Care Center if this error message appears again.

E2037 Cmd Rej: Invalid character in IP address - <parm>

Commands Used: all commands

The specified command parameter contains an invalid character in the IP address.

Recovery

1. Verify the correct IP address contains acceptable values for the four octets.
Refer to the *Commands Manual* for additional information regarding valid IP address characters for the specified command parameter.
2. Re-enter the command parameter specifying a valid IP address that contains valid values.

Call your Customer Care Center if this error message appears again.

E2038 Cmd Rej: <parm_desc> too short, min <min>, max <max>, - <parm>

Commands Used: all commands

You entered a string that is too short and does not contain the minimum number of characters required for this command parameter.

Recovery

Re-enter the command specifying a valid number of characters for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid number of characters for this command parameter.

Call your Customer Care Center if this error message appears again.

E2039 Cmd Rej: <parm_desc> too long, min <min>, max <max>, - <parm>

Commands Used: all commands

You entered a string that is too long and is not limited to the maximum number of characters allowed for this command parameter.

For the **rtrv-stp** command,

- The part number parameter (**partnum**), if specified, may contain no more than **12** characters.
- The GPL type parameter (**gpl**), if specified, may contain no more than **8** characters.

Recovery

Re-enter the command specifying a valid value for this command parameter.

Refer to the *Commands Manual* for detailed information regarding the required number of alphanumeric characters for the command parameter.

Call your Customer Care Center if this error message appears again.

E2040 Cmd Rej: String pattern nonconformance, alphanumeric - <parm>

Commands Used: all commands

The referenced string pattern is invalid because it does not conform to the required alphanumeric content for the command parameter.

Recovery

Re-enter the command specifying a pattern that conforms to the alphanumeric content required for the specified command parameter.

Refer to the *Commands Manual* for detailed information about the use of the command.

Call your Customer Care Center if this error message appears again.

E2041 Cmd Rej: String pattern nonconformance, alphabetic - <parm>

Commands Used: all commands

The referenced string pattern is invalid because it does not conform to the required alphabetic content for the command parameter.

Recovery

Re-enter the command specifying a pattern conforming to the alphabetic content required for the specified command parameter..

Refer to the *Commands Manual* for additional information regarding the detailed information about the use of the command.

Call your Customer Care Center if this error message appears again.

E2042 Cmd Rej: String pattern nonconformance, numeric - <parm>

Commands Used: all commands

You entered an invalid referenced string pattern that does not conform to the required numeric content for the command parameter.

Recovery

Re-enter the command specifying a pattern that conforms to the valid numeric characters required for the specified command parameter.

Call your Customer Care Center if this error message appears again.

E2043 Cmd Rej: System error - revert to mandatory in-pattern specification

Commands Used: all commands

An unanticipated system error has been detected. Make a note of this error and the attendant situation. Contact your Customer Care Center about this error message.

Recovery

Call your Customer Care Center if this error message appears.

E2044 Cmd Rej: <parm_desc> value is undefined - <parm>

Commands Used: all commands

You failed to specify a required parameter value for the entered command.

For the **rtrv-stp** command:

- If you specify the optional display id parameter **display**, you must specify a value equal to **power**.
- If you specify the optional frame id parameter **frm**, you must specify a value from the following set: {**cf00, ef00, ef01, ef02, ef03, ef04**} Refer to Table 2-1 below.
- If you specify the optional shelf id parameter **shelf**, you must specify a value from the following set: {**1100, 1200, 1300, 2100, 2200, 2300, 3100, 3200, 3300, 4100, 4200, 4300, 5100, 5200, 5300, 6100**}
- If you specify the optional card type parameter **type**, you must specify a value from the following set: {**acmenet, dcm, dsm, ipsm, limatm, limch, limds0, lime1, lime1atm, limocu, limt1, limv35, mcpm, stc, tsm**}

For the **chg/dlt/ent/rtrv-frm-pwr** and **rtrv-stp** commands, the mandatory frame id parameter (**frm**) must contain a value that is listed in Table 2-1 below.

Table 2-1. Valid Frame ID Parameter Values

cf00	Control Frame
ef00	First Extension Frame
ef01	Second Extension Frame
ef02	Third Extension Frame
ef03	Fourth Extension Frame
ef04	Fifth Extension Frame

Recovery

Re-enter the command specifying a valid value for each command parameter.

Refer to the *Commands Manual* for additional information regarding valid parameter values for this command.

Call your Customer Care Center if this error message appears again.

E2045 Cmd Rej: <parm_desc> num digits incorrect, min <min> max <max> - <parm>

Commands Used: **a11 commands**

You entered an invalid number of digits for a parameter value. The values represented by <parm>, <min>, and <max> vary according to the specific command entered. The values represented by <min> and <max> specify the valid minimum and maximum number of digits allowed for the command parameter.

Recovery

Re-enter the command specifying the valid number of digits for this command parameter.

E2046 Cmd Rej: Argument definition error, bad argument type

Commands Used: a11 commands

An unanticipated system error has been detected. Make a note of this error and the attendant situation.

Recovery

Call your Customer Care Center if this error message is received.

E2047 Cmd Rej: Missing information unit separator

Commands Used: a11 commands

You failed to specify a required information unit or information unit separator. The correct separator is a hyphen (-) character.

Recovery

Re-enter the command specifying the correct syntax.

Refer to the *Commands Manual* for additional information regarding the valid command syntax that defines the information units and their separators.

Call your Customer Care Center if this error message appears again.

E2048 Cmd Rej: Unneeded information found

Commands Used: a11 commands

You entered a command in which unnecessary information has been found.

Recovery

Re-enter the command specifying the correct syntax, format and parameters.

Refer to the *Commands Manual* for additional information regarding the correct format, parameters, and syntax for the command.

Call your Customer Care Center if this error message appears again.

E2049 Cmd Rej: Lower bound exceeds upper bound of range - %

Commands Used: all commands

You specified an invalid range because the lower bound value is greater than the upper bound for a range in the cited command parameter.

Recovery

Re-enter the command specifying a valid range for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid range of values for the command parameter.

Call your Customer Care Center if this error message appears again.

E2050 Cmd Rej: Incorrect information unit, expecting number or range - <parm>

Commands Used: all commands

You supplied an invalid number or range of numbers for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid number or range of numbers.

Refer to the *Commands Manual* for additional information regarding the numbers, or range of numbers, that are valid for the command parameter.

Call your Customer Care Center if this error message appears again.

E2051 Cmd Rej: Incorrect information unit, expecting number - <parm>

Commands Used: all commands

You supplied an invalid number for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid number.

Refer to the *Commands Manual* for additional information regarding the valid numbers for the command parameter.

Call your Customer Care Center if this error message appears again.

E2052 Cmd Rej: Incorrect information unit, expecting IP address - <parm>

Commands Used: a11 commands

You supplied an invalid IP address for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid IP address.

Refer to the *Commands Manual* for additional information regarding valid IP address values for the command parameter.

Call your Customer Care Center if this error message appears again.

E2053 Cmd Rej: Incorrect information unit, expecting string - <parm>

Commands Used: a11 commands

You supplied an unrecognized string for a parameter value. The value represented by <parm> varies according to the command being entered.

Recovery

Re-enter the command specifying a valid string value.

Refer to the *Commands Manual* for additional information regarding the valid values for the command parameter.

Call your Customer Care Center if this error message appears again.

E2054 Cmd Rej: Incorrect information unit, expecting mnemonic - <parm>

Commands Used: a11 commands

You supplied an invalid mnemonic for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid parameter value.

Refer to the *Commands Manual* for additional information regarding a valid value for the command parameter.

Call your Customer Care Center if this error message appears again.

E2055 Cmd Rej: Incorrect information unit, expecting point code - <parm>

Commands Used: all commands

You entered an unrecognized point code for a parameter value. The value represented by <parm> varies according to the command being entered.

Recovery

Re-enter the command specifying a valid point code value.

Refer to the *Commands Manual* for additional information regarding valid values for the command parameter.

Call your Customer Care Center if this error message appears again.

E2056 Cmd Rej: Incorrect information unit, expecting number or * - <parm>

Commands Used: all commands

You supplied an invalid number or variable for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid number or variable.

Refer to the *Commands Manual* for additional information regarding valid number or variable for the command parameter.

Call your Customer Care Center if this error message appears again.

E2057 Cmd Rej: Incorrect information unit, translation type - <parm>

Commands Used: a11 commands

You supplied an incorrect information unit for the translation type. The translation type from <parm> varies according to the specific command entered.

Recovery

1. Re-enter the command specifying a valid translation type format.
2. Press the **F10** key for Help, and see the valid format for the translation type parameter.

Refer to the *Commands Manual* for additional information regarding the translation type format for the command parameter.

Call your Customer Care Center if this error message appears again.

E2058 Cmd Rej: Incorrect information unit, expecting card location - <parm>

Commands Used: a11 commands

You supplied an invalid card location for a parameter value. The value represented by <parm> varies according to the specific command entered.

Recovery

Re-enter the command specifying a valid card location.

Refer to the *Commands Manual* for additional information regarding the valid card location for the command parameter.

Call your Customer Care Center if this error message appears again.

E2059 Cmd Rej: <parm_desc> is out of range, <min>...<max> - <parm>

Commands Used: a11 commands

You entered a value that is out of range of the minimum and maximum values allowed for this command parameter.

Recovery

Re-enter the command specifying a valid value for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid range of values for the command parameter.

Call your Customer Care Center if this error message appears again.

E2060 Cmd Rej: Lower bound exceeds upper bound of range - <parm>

Commands Used: all commands

You specified an invalid range because the lower bound value is greater than the upper bound for a range in the cited command parameter.

Recovery

Re-enter the command specifying a valid range for this command parameter.

Refer to the *Commands Manual* for additional information regarding the range of values for the command parameter.

Call your Customer Care Center if this error message appears again.

E2061 Cmd Rej: Incorrect input, expecting number, * or range - <parm>

Commands Used: all commands

You specified in the command parameter an input that is invalid, because it does not contain a number, variable, or a range of numbers.

Recovery

Re-enter the command specifying valid input values for this command parameter.

Refer to the *Commands Manual* for additional information regarding the valid inputs required for the command parameter.

Call your Customer Care Center if this error message appears again.

E2062 Cmd Rej: Incorrect information unit, expecting number or none - <parm>

Commands Used: all commands

You specified an information unit that is invalid because it does not contain a number or the string “none” in the command parameter.

Recovery

Re-enter the command specifying information units corrected for this command parameter.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

Call your Customer Care Center if this error message appears again.

E2063 Cmd Rej: Try Double Quoting Parameter with ‘_’

Commands Used: `a11 commands`

You specified an underscore character in an unacceptable format.

Recovery

Re-enter the command specifying the underscore character enclosed in double quotes “_”.

Refer to the *Commands Manual* for additional information regarding the correct format for the parameter.

Call your Customer Care Center if this error message appears again.

E2065 Cmd Rej: CMD parameter is not a valid Eagle command

Commands Used: `chg-cmd, rtrv-cmd`

You entered a `cmd` parameter containing an invalid EAGLE 5 ISS command specified. The `cmd` parameter value must be a valid system command.

Recovery

Re-enter the CMD parameter with the correct EAGLE 5 ISS command parameter.

Call your Customer Care Center if this error message appears again.

E2067 Cmd Rej: Feature Requires at least DSM4GB

Commands Used: `enable-ctrl-feat`

The feature cannot be enabled because the installed DSM card is not configured with at least 4 GB of memory. To enable the feature requires DSM cards with at least 4 GB of memory.

Recovery

1. Upgrade your hardware configuration so that only DSM cards with at least 4 GB of memory are in your system.
 2. Re-enter the **enable-ctrl-feat** command.
-

E2068 Cmd Rej: Feature not compatible with Measurements Platform

Commands Used: **enable-ctrl-feat**

The feature cannot be enabled if the Measurements Platform feature is on.

NOTE: The Measurements Platform feature is controlled by a feature bit. Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

Contact your Customer Care Center.

E2069 Cmd Rej: Feature not compatible with ICNP feature

Commands Used:

You cannot turn on the specified feature with the ICNP feature on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

Contact your Customer Care Center.

E2070 Cmd Rej: IP Address invalid for Address Class

Commands Used: **all commands**

The specified IP Address is invalid.

Recovery

Re-enter the command specifying a valid IP address.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

Call your Customer Care Center if this error message appears again.

E2071 Cmd Rej: Network Number Invalid

Commands Used: `all commands`

The specified Network Number is invalid. Valid Network Numbers cannot contain all 0 bits or all 1 bits.

Recovery

Re-enter the command specifying a valid Network Number.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

Call your Customer Care Center if this error message appears again.

E2072 Cmd Rej: Host Number Invalid

Commands Used: `all commands`

The specified Host Number is invalid. Valid Host Numbers cannot contain all 0 bits or all 1 bits.

Recovery

Re-enter the command specifying a valid Host Number.

Refer to the *Commands Manual* for additional information regarding the correct information units required for the command parameter.

Call your Customer Care Center if this error message appears again.

E2075 Cmd Rej: Incorrect information unit, expecting num,new or dflt - %s

Commands Used: `ent-mrn`

For the `ent-mrn` command, valid values that can be specified for the `mrnset` parameter are: **numerical value [1-3000]**, **new**, or **dflt**.

Recovery

Re-enter the **ent-mrn** command specifying either a **numerical value [1-3000]**, **new**, or **dflt** for the **mrnset** parameter.

Call your Customer Care Center if this error message appears again.

E2076 Cmd Rej: Incorrect information unit, expecting num, none or dflt - %s

Commands Used: **chg-gta**, **ent-gta**

For the **chg/ent-gta** commands, valid values that can be specified for the **mrnset** parameter are: **numerical value [1-3000]**, **none**, or **dflt**.

Recovery

Re-enter the command specifying either a **numerical value [1-3000]**, **none**, or **dflt** for the **mrnset** parameter.

Call your Customer Care Center if this error message appears again.

E2077 Cmd Rej: Incorrect information unit, expecting num or dflt - mrnset

Commands Used: **chg-mrn**, **dlt-mrn**, **rtrv-mrn**

The values specified for the **mrnset** parameter must be either: a **numerical value [1-3000]** or **dflt**.

Recovery

Re-enter the command specifying either a **numerical value [1-3000]** or **dflt** for the **mrnset** parameter.

Call your Customer Care Center if this error message appears again.

E2078 Cmd Rej: Incorrect information unit, expecting new or dflt

Commands Used: **ent-map**

The values specified for the mapset id parameter (**mapset**) must be either **new** or **dflt**.

Recovery

Re-enter the **ent-map** command specifying either **new** or **dflt** for the **mapset** parameter.

Call your Customer Care Center if this error message appears again.

E2083 Cmd Rej: GTTSN parameter mustn't be specified

Commands Used: **chg-gttset1**, **ent-gttset1**, **rtrv-gttset1**

For the **chg/ent/rtrv-gttset1** commands, the **gttsn** parameter must not be specified when the Origin-based SCCP Routing feature is enabled.

For the **rtrv-gttset1** command, the **gttsn** parameter must not be specified when the **gti(x)**, **tt**, **np(v)** and **nai(v)** if **gti(x)=4** parameter combination is specified.

Recovery

Re-enter the command without specifying the **gttsn** parameter.

Call your Customer Care Center if this error message appears again.

E2100 Cmd Rej: Card location already equipped

Commands Used: **ent-card**

You cannot add a card to the database that already exists in the database. The specified card location cannot already be provisioned in the database.

Recovery

1. Display the cards in the database. Enter the **rtrv-card** command.
2. Re-enter the **ent-card** command specifying a card location not shown in step 1.

Refer to the **ent-card** command description in the *Commands Manual*

E2101 Cmd Rej: Card location is unequipped

Commands Used: `act-cdl`, `act-lbp`, `blk-slk`, `chg-appl-sock`, `chg-bip-fld`, `chg-ip-card`, `chg-ip-lnk`, `chg-lbp`, `chg-x25-slk`, `dact-cdl`, `dact-lbp`, `dact-slk`, `dlt-lbp`, `disp-bp`, `disp-bip`, `disp-mem`, `dlt-appl-rtkey`, `dlt-bp`, `dlt-card`, `dlt-dlk`, `dlt-ip-node`, `dlt-ip-rte`, `ent-appl-sock`, `ent-bp`, `ent-dlk`, `ent-ip-node`, `ent-ip-rte`, `ent-slk`, `ent-lbp`, `inh-slk`, `init-card`, `rept-stat-cdl`, `rept-stat-lfs`, `rept-stat-tstslk`, `rtrv-appl-rtkey`, `rtrv-card`, `rtrv-data-insrv`, `rtrv-data-rtdb`, `rtrv-dlk`, `rtrv-ip-card`, `rtrv-ip-lnk`, `rtrv-ip-node`, `rtrv-ip-rte`, `rtrv-lbp`, `rtrv-slk`, `rtrv-x25-slk`, `set-mem`, `tst-bip`, `ublk-slk`, `unhb-slk`

The card in the specified card location, is not defined in the database. To enter the command, a card that is valid for the command must be defined previously in the database for the specified card location.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
 2. Verify that the correct card location was specified.
 3. Verify in the command that a card is defined in the database for the specified card location.
 4. Verify that the card in the specified card location is valid for the command. Refer to the command description in the *Commands Manual*.
 5. Re-enter the command that generated this error message. Specify a valid card location as shown in the output of step 1.
-

E2102 Cmd Rej: Failed reading the IMT table

Commands Used: `chg-e1`, `chg-t1`, `chg-x25-slk`, `dlt-card`, `dlt-e1`, `dlt-ip-node`, `dlt-t1`, `ent-card`, `ent-dlk`, `ent-e1`, `ent-ip-node`, `ent-slk`, `ent-t1`, `ent-x25-rte`, `rtrv-e1`, `rtrv-ip-node`, `rtrv-slk`, `rtrv-stp`, `rtrv-t1`, `rtrv-x25-slk`

The IMT table is corrupt or cannot be found by the system. This table contains the IMT attribute information. The IMT Address table must be accessible.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2103 Cmd Rej: Failed reading the link table

Commands Used: `chg-x25-slk`, `dlt-card`, `dlt-dlk`, `dlt-ip-node`,
`dlt-slk`, `ent-dlk`, `ent-ip-node`, `ent-slk`, `rtrv-dlk`,
`rtrv-ip-node`, `rtrv-slk`, `rtrv-x25-slk`

The Link table is corrupt or cannot be found by the system. The Link table contains the link attribute information and must be accessible.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2104 Cmd Rej: Failed reading shelf table

Commands Used: `chg-x25-slk`, `dlt-card`, `dlt-ip-node`, `ent-card`,
`ent-dlk`, `ent-ip-node`, `ent-slk`, `ent-x25-rte`, `rtrv-ip-node`,
`rtrv-slk`, `rtrv-x25-slk`

The Shelf table is corrupt or cannot be found by the system. The Shelf table contains the shelf attribute information.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2105 Cmd Rej: Invalid card TYPE and APPL load type combination

Commands Used: `act-upgrade`, `ent-card`

For the `act-upgrade` command, this error indicates an unsupported or obsolete card **type** was found in the system.

For the `ent-card` command, the specified card type (**type**) and application (**appl**) combination cannot be used together. Table 2-2 on page 2-32 lists the valid card type and application combinations:

Table 2-2. Valid Card Types (**type**) and Application Types (**appl**) for the **ent-card** Command

Card Type (:type)	Application Type (:appl)	Maximum Cards in the Database
acmenet	stplan	32
dcm	ebdadcm	1
	vxwslan	32
	emdc	2
	iplim, iplimi	41
	ss7ipgw, ipgwi	Total of 64 or combination
stc	eroute	32 (minimum of 17 for 500 links)
dcm	iplim, iplimi	100
	ss7ipgw, ipgwi	Total of 64 or combination
stc	eroute	32 (minimum of 14 for 500 links)
dsm	vsccp	25
ipsm	ips	3
mcpm	mcp	250
lime1, limt1, limch	ss7ansi, ccs7itu	250 for each application
lime1atm	atmitu	115
limds0, limocu, limv35	ss7ansi, ss7gx25, ccs7itu	250 for each application
lime1, limt1	ss7ansi, ccs7itu	125 for each application
limds0, limocu, limv35	ss7ansi, ss7gx25, ccs7itu	250 for each application
limds0, limocu, limv35	ss7ansi, ss7gx25, ccs7itu	250 for each application
limatm	atmansi	115
limds0	ss7ansi, ss7gx25, ccs7itu	250 for each application
limocu, limds0, limv35, lime1, limch	ss7ansi, ccs7itu	250 for each application
limocu	ss7ansi, ss7gx25, ccs7itu	250 for each application
limv35	ss7ansi, ss7gx25, ccs7itu	250 for each application
limds0	ss7ansi	250
tsm	sccp	25
	gls	8
	ebdablm	1

Recovery

1. For the **act-upgrade** command, replace the unsupported or obsolete card type was found with a TSM card or better.

Contact your Customer Care Center if you need assistance.

NOTE: For EAGLE 5 ISS 31.6 and later, replace all ASM cards with TSM cards.

2. For the **ent-card** command, re-enter the **ent-card** command specifying the correct card **type** and **appl** combination.
-

E2106 Cmd Rej: Link is in test mode

Commands Used: **act-slk**, **dlt-slk**

You entered this command while the **tst-slk** command was in progress.

Recovery

1. Wait for the signal link test to complete.
2. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2107 Cmd Rej: Link assigned to card

Commands Used: **dlt-card**

The specified card location has a signaling link or a TCP/IP data link assigned to it. The card cannot be deleted from the database until the signaling link or the TCP/IP data link is deleted from the database. Use the appropriate recovery procedures listed below to delete the signaling link or the TCP/IP data link from the database.

Recovery - SS7 links

1. Display the signaling links in the database. Enter the **rtrv-slk** command.

2. Delete the signaling link from the database. Enter the **dlt-slk** command specifying the card location used in the command that generated this error message along with the port of the signaling link, both shown in the output of step 1, and with the **force=yes** parameter.
 3. Re-enter the **dlt-card** command that generated this error message to delete the card from the database.
-

Recovery - TCP/IP links

1. Display the TCP/IP data links in the database. Enter the **rtrv-dlk** command.
2. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
3. From the outputs from steps 1 and 2, determine if the card location specified in the command that generated this error message has a TCP/IP node and TCP/IP data link assigned to it.
4. Delete the TCP/IP node from the database. Enter the **dlt-ip-node** command specifying the card location used in Step 3.
5. Delete the TCP/IP data link from the database. Enter the **dlt-dlk** command specifying the card location used in Step 3.

NOTE: An IPLNK entry must be provisioned before an IPHOST entry with **type=local** can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

6. Re-enter the **dlt-card** command that generated this error message, to delete the card from the database.
-

E2108 Cmd Rej: Shelf location not equipped

Commands Used: **ent-card**

The shelf location, shown in the card address, could not be found in the database. The specified shelf location must be provisioned and present in the frame.

Recovery

1. Display all shelves in the system. Enter the **rtrv-shlf** command.
 2. Re-enter the **ent-card** command specifying a card address that is in one of the shelf locations displayed in step 1.
-

E2109 Cmd Rej: Database maintenance is required

[or]

Cmd Rej: Database repair is required

Commands Used: chg-dstn, chg-feat, chg-ls, chg-rte, chg-x25-dstn, chg-x25-rte, chg-x25-slk, dlt-card, dlt-dlk, dlt-dstn, dlt-ip-node, dlt-ls, dlt-rte, dlt-slk, dlt-x25-dstn, dlt-x25-rte, ent-card, ent-dlk, ent-dstn, ent-ip-node, ent-ls, ent-rte, ent-slk, ent-x25-dstn, ent-x25-rte, rtrv-ip-node

The command failed because the system detects that:

- The database is incoherent (the command requires that the database be coherent).
- The levels of source databases, during a duplex backup or repair, are not identical on the active and standby OAM fixed disks.
- The database is corrupt. An audit has detected a mismatched checksum in a subset.

Recovery

1. Determine the status of the database. Enter the **rept-stat-db** command.
2. If the status of the database is corrupt, determine which subset is corrupt. Enter the **aud-data:display=all** command.
3. If the database is either incoherent or corrupt, find the conditions shown in the output of step 1 in the following list, and execute the appropriate command.
 - If the current partition of the fixed disk is coherent and the backup partition of the fixed disk is incoherent, enter the **chg-db:action=backup:dest=fixed** command.
 - If the current partition of the fixed disk is coherent and the database on the removable cartridge is incoherent, enter the **chg-db:action=backup:dest=remove** command.
 - If the backup partition of the fixed disk is coherent and the current partition of the fixed disk is incoherent. Call your Customer Care Center.
 - If the database on the removable cartridge is coherent and the current partition of the fixed disk is incoherent. Call your Customer Care Center.
 - If the backup and current partitions on the active fixed disk are coherent and the backup and current partitions on the standby fixed disk are incoherent, use the **chg-db:action=repair** command.
4. If you are performing a duplex backup or restore, verify that the level of the source databases residing on both the active and standby OAM fixed disks are identical.

NOTE: The error message text is altered for this condition and says "Database repair is required." When you have performed the required repair to make both databases identical, continue with step 5.

5. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2110 Cmd Rej: Unable to access DB level

Commands Used: `chg-dstn, chg-feat, chg-ls, chg-rte, chg-x25-dstn, chg-x25-rte, chg-x25-slk, dlt-card, dlt-dlk, dlt-dstn, dlt-ip-node, dlt-ls, dlt-rte, dlt-slk, dlt-x25-dstn, dlt-x25-rte, ent-card, ent-dlk, ent-dstn, ent-ip-node, ent-ls, ent-rte, ent-slk, ent-x25-dstn, ent-x25-rte, rtrv-ip-node`

A severe system fault has occurred and the command was rejected.

Recovery

Call your Customer Care Center if this error message appears.

E2111 Cmd Rej: Database consistency violation - maintenance required

Commands Used: `rtrv-rte`

A database inconsistency has been detected.

Recovery

Call your Customer Care Center if this error message appears.

E2112 Cmd Rej: At least one parameter must be changed

Commands Used: `chg-gta, chg-gtt, chg-gttset, chg-inopts, chg-map, chg-meas, chg-scr-aftpc, chg-scr-blkdp, chg-scr-blkop, chg-scr-cdpa, chg-scr-cgpa, chg-scr-dpc, chg-scr-opc, chg-scrset, chg-scr-sio, chg-scr-tt`

The command was entered without at least one optional parameter specified, or with an invalid optional parameter specified. Some commands require that you specify at least one optional parameter.

Recovery

Re-enter the command specifying at least one valid optional parameter.

Refer to the *Commands Manual* for additional information regarding the command and the required parameters.

E2113 Cmd Rej: CLLI cannot be specified without Point Code

Commands Used: `chg-1s`

You cannot invoke the `clli` feature without specifying the point code value.

Parameters `nfeclli` and `nfepc` are optional, but one may not be specified without the other.

Recovery

Re-enter the `chg-1s` command that generated this error message specifying the correct point code.

Call your Customer Care Center if this error message appears again.

E2114 Cmd Rej: If NDIGITS = 0 then PREFIX parameter is invalid

You do not need to specify the `prefix` parameter if the value specified for the `ndigits` parameter is **0 (ndigits=0)**.

Recovery

Re-enter the command that generated this error message specifying `ndigits=0` and without specifying the `prefix` parameter.

Call your Customer Care Center if this error message appears again.

E2115 Cmd Rej: NDIGITS parameter mandatory with PREFIX parameter

You cannot specify the `prefix` parameter without specifying the `ndigits` parameter.

Recovery

Re-enter the command that generated this error message specifying both the **prefix** and **ndigits** parameters.

Call your Customer Care Center if this error message appears again.

E2116 Cmd Rej: Number of PREFIX digits cannot exceed NDIGITS parameter

You cannot specify a **prefix** parameter that contains more digits than the **ndigits** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct number of digits for the **ndigits** and **prefix** parameters.

Call your Customer Care Center if this error message appears again.

E2117 Cmd Rej: PREFIX parameter mandatory with NDIGITS parameter

You specified the **ndigits** parameter, but failed to include the **prefix** parameter that is required with it.

Recovery

Re-enter the command that generated this error message specifying the **prefix** parameter.

Call your Customer Care Center if this error message appears again.

E2118 Cmd Rej: Invalid link speed combination within linkset

Commands Used: `ent-slk`

You attempted to add a link to a linkset with a transmission rate that was invalid for the linkset.

Recovery - For E1/T1 links:

1. Verify the transmission rate of the links in the linkset. Enter the command `rtrv-ls:lsn=(the linkset the link is being added to)`. The transmission rate of the link is shown in the BPS field of the output.

2. Verify that the links in the linkset are running at **56000** bps or **64000** bps. An E1 link can run at **56000** bps or **64000** bps in a linkset with other links running at **56000** bps and/or **64000** bps. A T1 link can run at **56000** bps in a linkset with other links running at **56000** bps and/or **64000** bps.
3. Re-enter the **ent-s1k** command specifying a valid transmission rate for the link that is being added to the linkset.

Call your Customer Care Center if this error message appears again.

Recovery - For V.35 linksets:

1. Verify the transmission rate of the links in the linkset. Enter the command **rtrv-ls:lsn**=(the linkset the link is being added to). The transmission rate of the link is shown in the BPS field of the output.
2. Re-enter the **ent-s1k** command specifying the transmission rate used by the other V.35 links in the linkset, as shown in the output of step 1.

NOTE: If any of the links in the linkset are DS0 or DSCS links, you cannot set the transmission rate for them, and they default to **56000** bps. Therefore, if any of the V.35 links in this linkset are set to **64000** bps, you must first delete those V.35 links with the **dlt-s1k** command and re-enter them with the **ent-s1k** command specifying a value of **bps=56000**.

E2119 Cmd Rej: BPS must be 56000 or 64000

Commands Used: **ent-s1k**

An attempt was made to enter a signaling link into the database with a card (**loc**) that was assigned to either the **SS7ANSI** or **CCS7ITU GPL** (an SS7 signaling link) and with a value for the bits-per-second (**bps**) parameter other than **56000** or **64000**. For an SS7 signaling link, the only values allowed for the **bps** parameter are **56000** or **64000**.

Recovery

Re-enter the **ent-s1k** command specifying the card location (**loc**) that generated this error message, and a value for the **bps** parameter of either **56000** or **64000**.

If the card type, shown in the TYPE field of the **rtrv-card** output, is either **limds0**, **limocu**, or **limt1**, specify **bps=56000**.

E2120 Cmd Rej: BPS must be 56000 for card type

Commands Used: `ent-s1k`

You specified an invalid bits-per-second (**bps**) rate for the card type. If the card type is either **limds0** (includes the multi-port LIM), **limt1**, or **limocu**, specify a **bps** parameter value of **56000**.

Recovery

Re-enter the `ent-s1k` command that generated this error message specifying the correct **bps** parameter value to reflect the true bits-per-second rate.

Call your Customer Care Center if this error message appears again.

E2121 Cmd Rej: PCRN1 and PCRN2 parameters are invalid if ECM=BASIC

Commands Used: `ent-s1k`

The **pcrn1** and **pcrn2** parameters cannot be specified if the **ecm** parameter is specified as **basic** (**ecm=basic**). The **pcrn1** and **pcrn2** parameters can be specified **ss7ansi** and **ccs7itu** applications only if the **ecm** parameter is specified as **pcr** (**ecm=pcr**).

Recovery

Perform one of the following:

- Re-enter the `ent-s1k` command specifying the **ecm=pcr** parameter, and the **pcrn1** and **pcrn2** parameters.
- OR
- Re-enter the `ent-s1k` command specifying the **ecm=basic** parameter, without specifying the **pcrn1** and the **pcrn2** parameters.
-

E2122 Cmd Rej: Failed reading linkset table

Commands Used: `chg-ls`, `chg-rte`, `chg-rtx`, `dlt-dstn`, `dlt-ls`, `dlt-rte`, `dlt-rtx`, `dlt-slk`, `ent-ls`, `ent-rte`, `ent-rtx`, `ent-slk`, `rtrv-gtwy-acthresh`, `rtrv-ls`, `rtrv-rte`, `rtrv-rtx`, `rtrv-slk`, `set-gtwy-acthresh`

The Linkset table is corrupt or cannot be found by the system. The Linkset table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2124 Cmd Rej: All links of LSN must use same error correction method

Commands Used: `ent-slk`

The command was entered specifying an error correction method (**ecm**) that was different than the method used by other links in the linkset that this link was being added to. All signaling links in a linkset must use the same error correction method.

Recovery

1. Verify the error correction method used by the signaling links in the linkset specified by the **lsn** parameter in the command that generated this error message. Enter the `rtrv-ls:lsn=` command specifying the linkset name specified in the command that generated this error message. The error correction method of the signaling links is shown in the ECM field of the output.
 2. Re-enter the `ent-slk` command that generated this error message specifying a value for the **ecm** parameter that is the same as the error correction method shown in the ECM field of the `rtrv-ls` command output in step 1.
-

E2125 Cmd Rej: Links on specified linkset are in-service

Commands Used: `chg-ls`

You attempted to change a linkset that still has signaling links assigned to it.

Recovery

1. Display the current linkset configuration. Enter the `rtrv-ls` command specifying the linkset name.
2. Deactivate all links in the linkset. Enter the `dact-slk` command.
3. Confirm the link status is Out-of-Service-Maintenance-Disabled (OOS-MT-DSBLD). Enter the `rept-stat-ls` command specifying the linkset name.

4. Delete all links in the associated linkset. Enter the **dlr-slk** command.
 5. Re-enter the **chg-ls** command that generated this error message.
-

E2126 Cmd Rej: Invalid linkset type for card

Commands Used: **ent-slk**

The application for the card specified by the **loc** parameter does not match the domain of the adjacent point code (APC) assigned to the specified linkset name (**lsn**). The specified linkset APC type must be the same as the card application type (ANSI or ITU).

For example, the APC of the linkset name is assigned to the SS7 domain, but the application assigned to the card is **ss7gx25**. Either the linkset APC must be in the X.25 domain, or the card application must be **ss7ansi** or **ccs7itu**.

Recovery

1. Verify the card applications. Enter the **rtrv-card** command.
 2. Verify the linksets and their APCs. Enter the **rtrv-ls** command.
 3. Verify the domains of the APCs shown in step 2. Enter the **rtrv-dstn** command.
 4. Using the outputs of steps 1, 2, and 3 as a guide, re-enter the **ent-slk** command specifying a card location whose application matches the domain of the APC assigned to the linkset that is to contain the signaling link. If the card location has an application of **ss7ansi** or **ccs7itu**, then the APC of the linkset must be in the SS7 domain. If the card location has an application of **ss7gx25**, the APC of the linkset must be in the X.25 domain.
-

E2127 Cmd Rej: l2tset must be 1-10 for ANSI links, 11-20 for ITU

Commands Used: **ent-slk**

The command was entered with a value for the level 2 timer set parameter (**l2tset**) that is not allowed for the type of signaling link being entered to the database. If the signaling link being entered is an ANSI signaling link, the **l2tset** parameter can only be a value from **1** to **10**. If the signaling link being entered is an ITU signaling link, the **l2tset** parameter can only be a value from **11** to **20**. The signaling link type is determined by the APC of the linkset that the signaling link is being added to, and by the application of the card that the signaling link is being assigned to.

Recovery

1. Verify the APC of the linkset specified in the command that generated this error message. Enter the **rtrv-1s** command. The APC of the linkset is shown in the APCA, APCI, or APCN fields in the **rtrv-1s** command output.
 2. Verify the application assigned to the card whose location was specified in the command that generated this error message. Enter the **rtrv-card:loc=** command specifying the card location. The card's application is shown in the APPL field in the **rtrv-card** command output.
 3. Re-enter the command under the following conditions:
 - If the card's application is **ss7ansi**, the linkset's APC must be an ANSI APC and is shown in the APCA field of the **rtrv-1s** command output. The value of the **l2tset** parameter of the **ent-slk** command must be between **1** and **10**.
 - If the card's application is **ccs7itu**, the linkset's APC must be an ITU APC and is shown in the APCI or APCN field of the **rtrv-1s** command output. The value of the **l2tset** parameter of the **ent-slk** command must be between **11** and **20**.
-

E2128 Cmd Rej: Linkset assigned to route must have at least one link

Commands Used: dlt-slk

The specified signaling link is the last link in a linkset that is assigned to a route, and the **force=yes** parameter was not specified. The last link in a linkset that is assigned to a route cannot be deleted, unless the **force=yes** parameter is specified.

Recovery

Re-enter the **dlt-slk** command specifying the **force=yes** parameter.

E2129 Cmd Rej: CDPNPFX must be specified

Commands Used: chg-inpopts

You entered a value for the **ncdpnpx** or **dltpfx** parameter (or both), and did not specify the **cdpnpx** parameter.

Recovery

1. To change a Called Party Number Prefix, re-enter the **chg-inopts** command specifying the existing prefix in the **cdpnprfx** parameter and the new prefix in the **ncdpnprfx** parameter.
 2. To delete a Called Party Number Prefix, re-enter the **chg-inopts** command specifying the existing prefix in the **cdpnprfx** parameter and **ncdpnprfx=none**.
-

E2130 Cmd Rej: Maximum number of links are assigned to this linkset

Commands Used: **ent-slk**

The linkset contains the maximum **16** signaling links and an attempt was made to add another signaling link. To add the new signaling link, first delete a current signaling link, then add the new one.

NOTE: Because there are only **16** signaling link codes (SLCs), you are more likely to see error message E2132.

Recovery

1. Display the signaling links in the linkset. Enter the **rtrv-ls** command specifying the linkset name (**lsn**) that generated this error message.
 2. Delete an existing signaling link. Enter the **dlc-slk** command.
 3. Re-enter the **ent-slk** command that generated this error message.
-

E2131 Cmd Rej: Parameters not valid for card type

Commands Used: **ent-slk**

You specified parameters that cannot be used with the card type specified. The parameters specified for the command must be valid for the type of card in the specified card location.

- The **tset** and **l1mode** parameters can be used only with the **limv35** card types.
- The **l2tset** parameter can be used only with cards whose application is **ss7ansi** or **ccs7itu**.
- The **e1port**, **e1loc**, and **ts** parameters can be used only with the **lime1** and **limch** card types.

- The **t1port**, **t1loc**, and **ts** parameters can be used only with the **limt1** and **limch** card types.
- The **e1atmcr4**, **e1atmsi**, and **e1atmsn** parameters can be used only with the **lime1atm** card type.

Recovery

1. Verify the card type and card application. Enter the **rtrv-card** command specifying the card location that generated this error message. The card type is shown in the TYPE field. The card's application is shown in the APPL field.
 2. Using the output of step 1 and the following guidelines, re-enter the **ent-slk** command:
 - If you want to enter the **tset** or **l1mode** parameters, make sure that the card type is **limv35**.
 - If you want to enter the **l2tset** parameter, make sure that the card application is **ss7ansi** or **ccs7itu**.
 - If you want to enter the **e1loc**, **e1port**, or **ts** parameters, make sure that the card type is **lime1** or **limch**, as appropriate for the combination of parameters.
 - If you want to enter the **t1loc**, **t1port**, or **ts** parameters, make sure that the card type is **limt1** or **limch**, as appropriate for the combination of parameters.
 - If you want to enter the **e1atmcr4**, **e1atmsi**, or **e1atmsn** parameters, make sure that the card type is **lime1atm**.
-

E2132 Cmd Rej: The specified SLC is in use

Commands Used: **ent-slk**

The specified signaling link code (SLC) is already being used by another signaling link in the linkset. The SLC must be unique in the linkset.

Recovery

1. Display the signaling links in the linkset that was specified in the command that generated this error message. Enter the **rtrv-ls** command specifying the name of the specified linkset (**lsn**).
 2. Re-enter the **ent-slk** command specifying a value for the SLC that is not displayed in the output of step 1.
-

E2133 Cmd Rej: There is a link already assigned to this port

Commands Used: `ent-slk`

You cannot assign a signaling link to a card location (**loc**) and **port/link** that already contains a signaling link. A link cannot be assigned to a card location and port that already contain a link. The link that is specified in the **port/link** parameter must not already be assigned.

NOTE: The **link** parameter has been added as a synonym for the **port** parameter. Either **port** or **link** can be used for a few more EAGLE 5 ISS releases; then the **port** parameter will be removed.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
 2. Display the signaling links in the database. Enter the `rtrv-slk` command.
 3. Re-enter the `ent-slk` command specifying a card location and port not shown in the output of step 2, and with a card type shown in the output of step 1 that is either **limatm**, **limocu**, **limds0**, **limv35**, **lime1**, **limt1**, or **limch**. The card types are shown in the TYPE field in the `rtrv-card` output.
-

E2135 Cmd Rej: TSET parameter only valid if MODE = DCE

Commands Used: `ent-slk`

You cannot specify the **tset** parameter without specifying the **l1mode=dce** parameter. The **tset** parameter can be specified only when the **l1mode=dce** parameter is specified. If the **l1mode=dce** parameter is specified and the **tset** parameter is not specified, the **tset** parameter value is set to **off**.

Recovery

Perform one of the following:

- Re-enter the `ent-slk` command specifying the **tset** parameter and the **l1mode=dce** parameter.
- OR
- Re-enter the `ent-slk` command without specifying the **tset** parameter.
-

E2136 Cmd Rej: At least one optional parameter is required

Commands Used: `chg-acg-noc`, `chg-appl-sock`, `chg-assoc`,
`chg-atm-lps`, `chg-attr-seculog`, `chg-cmd`, `chg-cmdclass`,
`chg-dstn`, `chg-ctrl-feat`, `chg-e1`, `chg-eisopts`, `chg-feat`,
`chg-ftp-serv`, `chg-gta`, `chg-gttset`, `chg-gpl`, `chg-gsmap-scrn`,
`chg-gsmopts`, `chg-gws-actset`, `chg-gtt`, `chg-gws-redirect`,
`chg-ip-card`, `chg-ip-lnk`, `chg-l2t`, `chg-l3t`, `chg-lbp`,
`chg-lnpopts`, `chg-ls`, `chg-map`, `chg-m2pa-tset`, `chg-netopts`,
`chg-rte`, `chg-sccpopts`, `chg-scr-aftpc`, `chg-scr-blkdpc`,
`chg-scr-blkopc`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-isup`,
`chg-scr-opc`, `chg-scr-sio`, `chg-secu-dflt`, `chg-secu-trm`,
`chg-sg-opts`, `chg-sid`, `chg-ss7opts`, `chg-stpopts`, `chg-t1`,
`chg-trm`, `chg-user`, `chk-unref-ent`, `dlt-lbp`, `dlt-mrn`, `dlt-rte`,
`dlt-scr-blkdpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-sid`,
`ent-trace`, `rtrv-data-rtdb`, `rtrv-stpopts`, `set-gtwy-acthresh`,
`set-uim-acthresh`

For the above listed commands, at least one optional parameter must be specified.

Recovery

Re-enter the command specifying at least one of the optional parameters.

Refer to the *Commands Manual* for additional information regarding the optional parameters that are available for that command.

E2137 Cmd Rej: Port must be inhibited to change comm. attributes

Commands Used: `chg-trm`

To change any of the communication attributes (**baud**, **fc**, **prty**, **sb**, or **type**), the terminal port must be inhibited. You tried to change one or more of the communication attributes, and the terminal port is not inhibited.

Recovery

1. Remove the terminal port from service. Enter the `inh-trm` command.
 2. Re-enter the `chg-trm` command, specifying the communication parameters to change.
 3. Return the terminal port to service. Enter the `alw-trm` command.
-

E2138 Cmd Rej: Failed reading terminal table

Commands Used: `chg-trm`

The Terminal table is corrupt or cannot be found by the system. The Terminal table contains the terminal attribute information.

Recovery

Re-enter the `chg-trm` command.

Call your Customer Care Center if this error message appears again.

E2139 Cmd Rej: Invalid BAUD value specified

Commands Used: `chg-trm`

The value specified for the `baud` parameter was outside the allowed range.

Recovery

Re-enter the `chg-trm` command specifying one of the following values for the `baud` parameter: **2400**, **4800**, **9600**, or **19200**.

E2140 Cmd Rej: Invalid PRTY value specified

Commands Used: `chg-trm`

The value specified for the `prty` parameter was other than **none**, **even**, or **odd**. These are the only values allowed for the `prty` parameter.

Recovery

Re-enter the `chg-trm` command specifying a value for the `prty` parameter of either **none**, **even**, or **odd**. You cannot specify the **none** value if the `type=vt320` parameter is specified.

E2141 Cmd Rej: Invalid FC value specified

Commands Used: `chg-trm`

You specified an `fc` parameter value that is not allowed. The valid values for the `fc` parameter are: **hw** (hardware), **sw** (software), **both** (both hardware and software), and **none** (no flow control).

Recovery

Re-enter the **chg-trm** command specifying a value for the **fc** parameter that is equal to the flow control value required for the hardware used on the port. The valid values for the **fc** parameter are: **hw** (hardware), **sw** (software), **both** (both hardware and software), and **none** (no flow control).

E2142 Cmd Rej: TYPE = VT320 and PRTY=NONE combination not allowed

Commands Used: **chg-trm**

The command attempted to set the **type=vt320** and the **prty=none**. A VT320 terminal does not support seven-bit data bytes and no parity.

Recovery

Perform one of the following:

- Re-enter the **chg-trm** command specifying the **type=vt320** and the **prty=odd** or **even**.
- OR
- Re-enter the **chg-trm** command specifying the **type=printer** or **ksr** and the **prty= none, even, or odd**.
-

E2143 Cmd Rej: The terminal state request was unanswered

Commands Used: **chg-trm**

There is a problem with the OAM card, the TDM card, or the extended bus interface (EBI) between the two. This problem is preventing the system from determining what state the specified terminal or port is in. The terminal or port attributes cannot be changed until the state of the terminal or port can be determined. This error message follows other error messages or system troubles.

Recovery

1. Remove the terminal from service. Enter the **inh-trm** command.
 2. Re-enter the **chg-trm** command.
 3. If the **chg-trm** command is rejected, call your Customer Care Center.
 4. If the **chg-trm** command is accepted, return the terminal to service. Enter the **alw-trm** command.
-

E2144 Cmd Rej: Location invalid for hardware configuration

Commands Used: `act-slk`, `alw-card`, `blk-slk`, `canc-slk`,
`dact-slk`, `ent-card`, `inh-card`, `inh-slk`, `pass`, `rept-stat-card`,
`rept-stat-db`, `rept-x25-meas`, `rmv-card`, `rtrv-card`, `rst-card`,
`tst-slk`, `ublk-slk`, `unhb-slk`

The specified card location is not defined in the database. The following recovery procedures list the remedial action to take for each command that generates this error message.

You cannot specify the even-numbered card location $n+1$ if a dual slot card occupies the adjacent odd-numbered card location n .

Recovery - `pass`, `rept-stat-card`, `rmv-card`, `rst-card`

1. Display the cards in the database. Enter the `rtrv-card` command.
 2. Re-enter the command specifying a valid card location from step 1.
-

**Recovery - `act-slk`, `blk-slk`, `canc-slk`, `dact-slk`, `inh-slk`,
`tst-slk`, `ublk-slk`, `unhb-slk`**

1. Display the cards in the database, enter the `rtrv-card` command. These commands require either a LIM card or an E1/T1 MIM card. LIM cards are those indicated by the terms `limatm`, `limds0`, `limocu`, or `limv35`; E1/T1 MIM cards are those indicated by the terms `lime1`, `limt1`, or `limch`.
 2. Re-enter the command specifying a valid card location from step 1.
-

Recovery - `rept-x25-meas`

1. Display the cards in the database. Enter the `rtrv-card` command. This command requires a LIM running the `ss7gx25` application. Refer to the terms `limds0`, `limocu`, or `limv35` in the TYPE field and `ss7gx25` in the APPL field of the `rtrv-card` command output.
 2. Re-enter the `rept-x25-meas` command specifying a valid card location.
-

Recovery - `alw-card`, `inh-card`, `rept-stat-db`

1. Enter the **`rtrv-card`** command to display the cards in the database. For these commands, the card type cannot be OAM, TDM, MDAL, or HMUX. The card types are listed in the TYPE field of the **`rtrv-card`** command output.
 2. Re-enter the command specifying a valid card location.
-

Recovery - `ent-card`

1. A DSM card is not allowed in the specified card location. The DSM card must be entered in an odd-numbered card location. The n+1 card location next to the DSM card must be empty, where n is the odd-numbered location (for example, if the DSM is in location 1101, then the 1102 card location must be empty). Enter **`rtrv-card:loc=xxxx`** to determine if a card is provisioned in the n+1 card location.
 2. Re-enter the **`ent-card`** command specifying a valid card location.
-

E2145 Cmd Rej: Failed reading MAS configuration table

Commands Used: `chg-feat`, `chg-gtw-stp`, `chg-ls`, `chg-sid`, `chg-stpopts`, `dlt-dstn`, `ent-card`, `ent-dstn`, `ent-ls`, `init-oap`, `rtrv-feat`, `rtrv-gtw-stp`, `rtrv-sid`, `rtrv-stpopts`

The MAS Configuration table is corrupt or cannot be found by the system.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2146 Cmd Rej: BPS must be 4800,9600,19200,56000,64000,1544000 or 2048000

Commands Used: `ent-slk`

You specified the **`bps`** parameter with a value that is not allowed. The valid values for the **`bps`** parameter are listed in Table 2-3.

Table 2-3. Valid Values for the **bps** Parameter

E1 ATM signaling links	2048000
SE-HSL signaling links (ent-e1 command parameter linkclass=unchan)	1984000
SS7 or CCS7ITU signaling links	56000 or 64000
T1 ATM high-speed links	1544000
X.25 signaling links	4800, 9600, 19200, 56000 or 64000

Recovery

-
1. Verify that the command was entered correctly.
 2. Re-enter the **ent-slk** command.
 3. If the command was entered correctly,
 - Verify the transmission rate of the links in the linkset that you wish to add the link to. Enter the **rtrv-slk** command.
 - Re-enter the **ent-slk** command specifying the **bps** parameter equal to a transmission rate allowed in the linkset that the link is being added to.
-

E2147 Cmd Rej: X-LIST DPC is not allowed

Commands Used: **rept-stat-dstn**, **rept-stat-rte**

You attempted to use a destination point code from the exclusion list.

Recovery

Re-enter the command that generated this error message specifying the correct **dpc** parameter value.

Call your Customer Care Center if this error message appears again.

E2148 Cmd Rej: DPC must be a cluster DPC or cluster member

Commands Used: **rept-stat-cluster**

You attempted to use a destination point code that was not relevant to the cluster setting required by this command.

Recovery

Re-enter the **rept-stat-cluster** command that generated this error message specifying the correct **dpc** parameter value.

Call your Customer Care Center if this error message appears again.

E2149 Cmd Rej: TYPE = SCCS and PRTY=NONE combination not allowed

Commands Used: **chg-trm**

You specified the **type=sccs** parameter and the **prty=none** parameter together. This parameter combination is not allowed by this command.

Recovery

Re-enter the **chg-trm** command specifying a different value for either the **type** or the **prty** parameter.

E2150 Cmd Rej: Frame ID out of range

Commands Used: **rept-stat-db**

The value you assigned to the **Frame ID** parameter was too large.

Recovery

Re-enter the **rept-stat-db** command that generated this error message specifying the correct **Frame ID** parameter value.

Call your Customer Care Center if this error message appears again.

E2152 Cmd Rej: Shelf ID out of range

Commands Used: **dlt-card, dlt-shlf, ent-card, ent-shlf, ent-slk, rept-stat-db, rtrv-shlf, rtrv-slk**

The value specified for the **loc** parameter is not valid physically. The first and second digits in the **loc** parameter do not identify a valid shelf.

The frame and shelf portions of the specified card location (**loc**) can be **11** through **13**; **21** through **23**; **31** through **33**; **41** through **43**; **51** through **53**; and **61**.

The format of the address specified by the **loc** parameter is **XYZZ**, where: **X** = frame (**1, 2, 3, 4, 5, or 6**) **Y** = shelf within the frame (**1, 2, or 3**) **ZZ** = slot within the shelf range for control shelf, **X = 1, Y = 1, ZZ = 1-8, 11-12**
for **disc-imt**, **ZZ = 1-8, 11-13 and 15**
for **init-card**, **ZZ = 1-8, 11-13, and 16**
for **rept-stat-card**, **ZZ = 1-8, 11-13, and 17** range for extension shelves (all other shelves) is **1-8, 11-18**

Recovery

Re-enter the command.

Refer to the *Commands Manual* (**ent-card** command) for additional information regarding valid values for the card location.

E2153 Cmd Rej: Card slot location out of range

Commands Used: **act-dlk, canc-dlk, chg-x25-slk, dlt-card, dlt-dlk, dlt-ip-node, dlt-slk, ent-card, ent-dlk, ent-ip-node, ent-slk, ent-x25-rte, rept-stat-db, rept-stat-dlk, rept-x25-meas, rtrv-card, rtrv-dlk, rtrv-ip-node, rtrv-slk, rtrv-x25-rte, rtrv-x25-slk, tst-dlk**

The value specified for the **loc** parameter is physically invalid. The slot portion of the specified card location (**loc**) can be **1** through **8** and **11** through **18**. Slots **09** and **10** cannot be specified. (The card location is **xyss**, where **x** is the frame, **y** is the shelf, and **ss** is the slot.)

Recovery

Re-enter the command specifying a valid value for the **loc** parameter.

Refer to the *Installation Manual* for additional information regarding the values for the card location, and re-enter the command.

Refer to the *Commands Manual* for additional information regarding the correct format of the address specified by the **loc** parameter.

E2154 Cmd Rej: Card slot reserved by system

Commands Used: `chg-x25-slk`, `dlt-card`, `dlt-dlk`, `dlt-ip-node`,
`dlt-slk`, `ent-card`, `ent-dlk`, `ent-ip-node`, `ent-slk`,
`ent-x25-rte`, `rept-stat-db`, `rtrv-card`, `rtrv-dlk`,
`rtrv-ip-node`, `rtrv-slk`, `rtrv-x25-rte`, `rtrv-x25-slk`

Card locations **1113** through **1118** are reserved for system operation and cannot be specified.

Recovery

Re-enter the command specifying a card location that is not for an OAM, TDM, MDAL, or HMUX card, but make sure the card type is matched to the command as follows:

- `dlt-card`, `ent-card`, `rtrv-card` — all card types except OAM, TDM, MDAL, or HMUX
- `dlt-slk`, `ent-slk`, `rtrv-slk` —
- `limds0`, `limocu`, `limv35`, `lime1`, `limt1`, or `limch` card types running the `ss7ansi` or `ccs7itu` application
- `limatm` card type running the `atmansi` application
- `chg-x25-rte`, `chg-x25-slk`, `ent-x25-rte`, `rtrv-x25-rte`,
`rtrv-x25-slk` — `limds0`, `limocu`, or `limv35` card types running the `ss7gx25` application
- `dlt-dlk`, `dlt-ip-node`, `ent-dlk`, `ent-ip-node`, `rtrv-dlk`,
`rtrv-ip-node` — `acmenet` card type

E2155 Cmd Rej: Invalid parameter combination specified

Commands Used: `act-flash`, `chg-ctrl-feat`, `chg-db`, `chg-gta`,
`chg-gtt`, `chg-gtcnv`, `chg-isupvar-attrib`, `dlt-gta`, `ent-gta`,
`init-flash`, `rept-stat-cluster`, `rept-stat-db`, `rept-stat-gpl`,
`rept-stat-ls`, `rept-stat-slk`, `rtrv-dstn`, `rtrv-gta`, `rtrv-ls`,
`rtrv-rte`, `rtrv-rtx`, `rtrv-sid`, `rtrv-stp`, `rtrv-isupvar-attrib`,
`tst-slk`

You specified an invalid parameter combination. Table 2-4 lists by command the invalid parameter combinations that generate this error message.

Table 2-4. Invalid Parameter Combinations that Generate an E2155 Error Message

Command	Invalid Parameter Combination Entered
act-flash, init-flash	<p>You cannot specify the following parameter combinations:</p> <ul style="list-style-type: none"> - loc and sloc / eloc parameters cannot be specified together - Either loc or sloc / eloc must be specified - appl is required if sloc / eloc are specified - sloc and eloc must be specified together - sloc cannot be greater than eloc when specified - If the target is HMUX or HIPR, both sloc and eloc must be HMUX or both must be HIPR and on the same IMT bus. Note: For HMUX or HIPR, the bus is implicitly based on the specified location. Both the starting and ending locations must be on the same bus. sloc / eloc XX09 specifies MUX/SWITCH A bus, sloc / eloc XX10 specifies MUX/SWITCH B bus. For example, sloc=1109:eloc=6109 specifies all MUX/SWITCH cards on the A bus only, and sloc=1110:eloc=6110 specifies all MUX/SWITCH cards on the B bus only. MUX/SWITCH cards from both the A and B bus cannot be activated simultaneously. <p>If the target is HC Blade, then gpl is required if loc is specified.</p>
chg-ctrl-feat	<p>You cannot specify both the status and alarm parameters in the command. Only one of these parameters can be specified in this command.</p>
chg-db	<p>You cannot specify the force parameter in conjunction with a parameter other than action=canceledl. The force parameter can only be used with action=canceledl.</p>
chg-gta	<p>The nnp, nna, npdd, nsdd, nsds, ngti, and npds parameters are not valid with the rgmtt parameter.</p> <p>If the value specified for the translate indicator (xlat) parameter is udts or disc, the only other optional parameters allowed are gta/egta, cgpc, opc or cgssn/ecgssn.</p> <p>You cannot specify the gta parameter if the ecgssn parameter is specified.</p> <p>You cannot specify the cgpc parameter if either the egta or ecgssn parameter is specified.</p> <p>You cannot specify the opc parameter if either the egta or ecgssn parameter is specified.</p> <p>You cannot specify the cgssn parameter if the egta parameter is specified.</p>

Table 2-4. Invalid Parameter Combinations that Generate an E2155 Error Message (Continued)

Command	Invalid Parameter Combination Entered
chg-gtcnv	You intermixed digit manipulation parameters nsdd and nsds (new suffix digits), npdd and npds (new prefix digits), or RDMOD (reset digit modifiers). Digit manipulation parameters nsdd and nsds are mutually exclusive of the npdd and npds parameters. The four values can be added or changed (but not at the same time). However, to specify or delete existing values or to change between suffix and prefix manipulations, RDMOD must be used to reset the current values. RDMOD cannot be specified in a command containing a new suffix or new prefix parameter.
chg-gtt	The nnp , nna , npdd , nsdd , nsds , ngti , and npds parameters are not valid with the rgmtt parameter.
chg-isupvar-attr	Refer to the chg-isupvar-attr command description in the <i>Commands Manual</i> for the valid parameter combinations in this command.
disp-disk-dir	The loc and src parameters are mutually exclusive.
dlt/ent-gta	If the value specified for the translate indicator (xlat) parameter is udts or disc , the only other optional parameters allowed are gta/egta , cgpc , opc or cgssn/ecgssn .
	You cannot specify the gta parameter if the ecgssn parameter is specified.
	You cannot specify the cgpc parameter if either the egta or ecgssn parameter is specified.
	You cannot specify the opc parameter if either the egta or ecgssn parameter is specified.
You cannot specify the cgssn parameter if the egta parameter is specified.	
format-disk	The low=no parameter must be specified if using the prtngprp= parameter.
rept-stat-card	The stat parameter cannot be specified if loc or port is specified.
rept-stat-cluster	You specified the stat parameter and the dpc or dpca parameter in the same command. The stat parameter cannot be specified with the dpc or dpca parameter in this command.
rept-stat-db	You cannot specify both the display and loc parameters, or both the db and loc parameters in this command.
rept-stat-gpl	You cannot specify a combination of the display=all , gpl= , or loc= parameters in this command.

Table 2-4. Invalid Parameter Combinations that Generate an E2155 Error Message (Continued)

Command	Invalid Parameter Combination Entered
rept-stat-ls	You cannot specify both the stat and lsn parameters in the same command. You can only specify one of these parameters, but not both, in this command.
rept-stat-slk	You cannot specify the stat parameter and either the loc or port parameter in this command.
rtrv-dstn	You cannot specify the msar=only parameter along with one or more other parameters for this command. The msar=only parameter cannot be specified along with any other parameters in this command. OR You cannot specify more than one of the following parameters: alias , cli , dpc for this command. You can only specify one of these parameters in this command. OR You cannot specify the pctype or pcst parameters along with any of the following parameters: aliasa/aliasi/alisan/alisa24 , dpc/dpca/dpci/dpcn/dpcn24 , cli , ncai , spc/spca/spci/spcn/spcn24 in this command.
rtrv-gta	You cannot specify cgpc , cgssn , or opc parameters if gttsn parameter set type is cdgta . You cannot specify cgpc , cgssn , or opc parameters if gttsn parameter set type is cggta . You cannot specify cgpc , cgssn , cdgta or cggta parameters if gttsn parameter set type is opc . You cannot specify cgssn , opc , cdgta or cggta parameters if gttsn parameter set type is cgpc . You cannot specify cgpc , opc , cdgta or cggta parameters if gttsn parameter set type is cgssn .
rtrv-isupvar-attrib	You cannot specify either the msgcode and parmcode parameters or the parmcode and display parameters in the same command. These two combinations are not valid in this command.
rtrv-ls	You cannot specify the lsn parameter along with one or more optional parameters. Optional parameters are ignored when the lsn parameter is entered. OR You specified more than one optional parameter and did not specify the lsn parameter. If the lsn parameter is not specified, only one optional parameter can be entered, except for the combination of the slsobit and slsrsb parameters.

Table 2-4. Invalid Parameter Combinations that Generate an E2155 Error Message (Continued)

Command	Invalid Parameter Combination Entered
rtrv-rte	You cannot specify the pctype or pcst parameters along with one of the following parameters: cli , dpc/dpca/dpci/dpcn/dpcn24 , lsn , ncai in this command.
rtrv-rtx	Only one of the following parameters may be specified: cic , ilns , opc or si .
rtrv-sid	You cannot specify the spc parameter along with either the cpc or cpctype parameter in this command.
rtrv-stp	No two optional parameters can be specified together except the following parameter sets {DISPLAY, FRM} and {GPL, VER}.
tst-slk	You cannot specify the force , loopback , or time parameters when action=stop in this command.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated the error message.

E2156 Cmd Rej: Cannot allow terminal configured as type=none

You cannot specify a value of **none** for the **type** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct **type** parameter value.

Call your Customer Care Center if this error message appears again.

E2158 Cmd Rej: Card location specified must be the standby

You attempted to assign the location of the active card to the **loc** parameter when you ran this command.

Recovery

Re-enter the command that generated this error message specifying the correct **loc** parameter value.

Call your Customer Care Center if this error message appears again.

E2160 Cmd Rej: Measurements not inhibited

Commands Used: `act-upgrade`, `copy-disk`, `format-disk`

This error message indicates that OAM measurements are not inhibited. These commands require that measurements be inhibited while the disk contents are being copied or the disk is being formatted.

Recovery

1. Turn OAM measurements off. Enter the `chg-meas:collect=off` command.
 2. Re-enter the command.
 3. Upon command completion, turn OAM measurements on. Enter the `chg-meas:collect=on` command.
-

E2161 Cmd Rej: Removable cartridge contains Eagle data (use FORCE=YES)

Commands Used: `format-disk`

The removable cartridge to be formatted contains EAGLE 5 ISS data. To format a cartridge already containing EAGLE 5 ISS data, **force=yes** must be specified.

Recovery

1. Make sure that the removable cartridge is in the correct location and the command has been specified correctly.
2. Re-enter the `format-disk` command specifying the **force=yes** parameter.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure completes.

E2163 Cmd Rej: CLLI used by STP

Commands Used: `chg-dstn`, `ent-dstn`

The specified CLLI is the same as the CLLI that is assigned to the EAGLE 5 ISS.

Recovery

1. Enter the `rtrv-sid` command to verify the CLLI for the EAGLE 5 ISS.
 2. Using the output from step 1 as a guide, re-enter the command specifying a CLLI that is not the same as the CLLI for the EAGLE 5 ISS.
-

E2164 Cmd Rej: Fixed disk contains Eagle data (use FORCE=YES)

Commands Used: `copy-disk`

The media to be formatted contains EAGLE 5 ISS data.

Recovery

1. Ensure that you really want to copy over the EAGLE 5 ISS data on the target disk, and that you have entered the `copy-disk` command correctly.
 2. Re-enter the `copy-disk` command specifying the `force=yes` parameter.
-

E2165 Cmd Rej: Removable cartridge not inserted

Commands Used: `act-upgrade`, `disp-tbl`, `format-disk`, `set-tbl`, `tst-disk`

Table 2-5 lists by command the conditions that generate this error message. The table is followed by a procedure to use to recover from the error.

Table 2-5. Conditions that Generate an E2165 Error Message

Command	Condition
<code>act-upgrade</code>	The system did not find a removable cartridge in the removable cartridge drive. The <code>act-upgrade</code> command requires that a removable cartridge containing the upgrade software be inserted in the removable cartridge drive.
<code>disp-tbl</code> , <code>set-tbl</code>	The command was entered with the card location of the MDAL card (1117). To specify the MDAL card with these commands, a removable cartridge must be in the removable cartridge drive.

Table 2-5. Conditions that Generate an E2165 Error Message (Continued)

Command	Condition
format-disk	You specified type=meas or type=system for this command. This requires that a removable cartridge be inserted in the removable cartridge drive.
tst-disk	You specified loc=1117 for the command. Specifying card location 1117 requires that a removable cartridge must be present in the removable cartridge drive.

Recovery

1. Go to the removable cartridge drive on the MDAL card, and visually verify whether there is a removable cartridge is in the removable cartridge drive.
2. If a removable cartridge is in the removable cartridge drive, eject and then insert the removable cartridge.
3. If no removable cartridge is in the removable cartridge drive, insert a removable cartridge in the removable cartridge drive. For the **act-upgrade** command, make sure the removable cartridge contains the required software for the upgrade.
4. Reseat the MDAL.
5. Re-enter the command.

Call your Customer Care Center if this error message appears again.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period of time can cause damage. Remove the cartridge after the command or procedure completes.

E2166 Cmd Rej: Partial point codes are not allowed

Commands Used: **chg-appl-rtkey, chg-sid, ent-appl-rtkey, chg-x25-dstn, ent-x25-dstn, rtrv-x25-dstn, ent-rmt-appl, dlt-rmt-appl**

You entered a partial point code, and the system detected that the cluster routing and management diversity (CRMD) feature is turned on. The partial point code is used for CRMD routing. If the CRMD feature is turned on, these commands require that full point codes be entered for the point code parameters. The following Recovery procedures list by command, the remedial action to take for this error message.

Recovery - chg-sid

1. Enter the **rtrv-sid** command to verify the site point code and capability point code.
 2. Enter **rtrv-dstn** to display the destination point codes in the database.
 3. Enter **rtrv-ls** to display the adjacent point codes in the database.
 4. Re-enter the command. Specify a full point code for the point code parameters. Use the outputs from steps 1 through 3 to make sure the specified point code does not match any values not being changed by the **chg-sid** command, and does not match any destination point codes or adjacent point codes.
-

Recovery - chg-x25-dstn ent-x25-dstn rtrv-x25-dstn

1. Enter the **rtrv-dstn** command to display the destination point codes in the database.
 2. Re-enter the command, with point code parameters that specify a full point code that is shown in the output of step 1.
-

Recovery - chg-appl-rtkey ent-appl-rtkey

1. Enter the **rtrv-dstn** command to display the destination point codes in the database.
 2. Re-enter the command, with point code parameters that specify a full point code shown in the output of step 1.
-

Recovery - ent-rmt-appl, dlt-rmt-appl

1. Enter the **rtrv-rmt-appl** command to verify the format of the point codes in the table.
 2. Re-enter the command specifying a full point code in the correct format.
-

E2167 Cmd Rej: Point code matches a STP capability point code

Commands Used: `chg-gsmopts`, `chg-ls`, `ent-dstn`, `ent-ls`

The point code specified (destination point code or an alias point code), is the same as the capability point code of the EAGLE 5 ISS destination point codes. The specified Adjacent Point Code cannot match any of the EAGLE 5 ISS's capability codes as specified in its self-identity.

Alias point codes entered with the `ent-dstn`, `ent-ls`, or `chg-ls` command cannot match the capability point codes of the EAGLE 5 ISS, the site point codes of the EAGLE 5 ISS, or any existing destination point codes and alias point codes.

The ITU-I or ITU point code entered with the `chg-gsmopts` command for an IN platform used by the Prepaid Short Message Service Intercept feature cannot be the same as the capability point code of the EAGLE 5 ISS.

Recovery - `chg-ls`, `ent-dstn`, `ent-ls`

1. Display the capability point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command. The capability point codes are shown in the CPCA, CPCI, CPCN, and CPCN 24 fields of the `rtrv-sid` command output. The site point codes of the EAGLE 5 ISS are shown in the PCA, PCI, PCN, and PCN24 fields of the `rtrv-sid` command output.
 2. Display the destination point codes and alias point codes in the database. Enter the `rtrv-dstn` command. Destination point codes are shown in the DPCA, DPCI, DPCN, and DPCN24 fields of the `rtrv-dstn` command output. Alias point codes are shown in the ALIASA, ALIASI, ALIASN, and ALIASN24 fields of the `rtrv-dstn` command output.
 3. Re-enter the command specifying a point code that is not shown in the outputs of steps 1 and 2.
-

Recovery - `chg-gsmopts`

1. Display the capability point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command. The capability point codes are shown in the CPCA, CPCI, CPCN, and CPCN24 fields of the `rtrv-sid` command output.
 2. Re-enter the command specifying a point code that is not shown in the output of step 1.
-

E2168 Cmd Rej: Point code matches a STP point code

Commands Used: `chg-gsmopts`, `chg-ls`, `ent-dstn`, `ent-ls`

The point code specified (destination point code or an alias point code), is the same as the site point code of the EAGLE 5 ISS destination point code. The specified Adjacent Point Code cannot match the destination point code of the EAGLE 5 ISS as specified in its self-identity.

Alias point codes entered with the `ent-dstn`, `ent-ls`, or `chg-ls` command cannot match the site point codes of the EAGLE 5 ISS, the capability point codes of the EAGLE 5 ISS, or any existing destination point codes and alias point codes.

The ITU-I or ITU point code entered with the `chg-gsmopts` command for an IN platform used by the Prepaid Short Message Service Intercept feature cannot be the same as the site point code of the EAGLE 5 ISS.

Recovery - `chg-ls`, `ent-dstn`, `ent-ls`

1. Display site point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command. The site point codes are in the PCA, PCI, PCN, and PCN24 fields of the `rtrv-sid` command output. The capability point codes of the EAGLE 5 ISS are shown in the CPCA, CPCI, CPCN, and CPCN24 fields of the `rtrv-sid` command output.
 2. Display the destination point codes and alias point codes in the database. Enter the `rtrv-dstn` command. Destination point codes are shown in the DPCA, DPCI, DPCN, and DPCN24 fields of the `rtrv-dstn` command output. Alias point codes are shown in the ALIASA, ALIASI, and ALIASN fields of the `rtrv-dstn` command output.
 3. Re-enter the command specifying a point code that is not shown in the outputs of steps 1 and 2.
-

Recovery - `chg-gsmopts`

1. Display the site point codes in the EAGLE 5 ISS. Enter the `rtrv-sid` command. The site point codes are shown in the PCA, PCI, PCN, and PCN24 fields of the `rtrv-sid` command output. The capability point codes of the EAGLE 5 ISS are shown in the CPCA, CPCI, CPCN, and CPCN24 fields of the `rtrv-sid` command output.
 2. Re-enter the `chg-gsmopts` command specifying a point code that is not shown in the output from step 1.
-

E2169 Cmd Rej: Point code out of range

Commands Used: `chg-gta`, `chg-gtt`, `chg-ls`, `chg-map`, `chg-sid`,
`dlt-gta`, `dlt-map`, `ent-dstn`, `ent-gta`, `ent-gtt`, `ent-ls`,
`ent-map`, `ent-rtx`, `ent-sid`, `ent-spc`, `rtrv-gta`, `rtrv-gtt`

The specified point code is out of the allowable range.

For the `chg-ls` and `ent-ls` commands, if the system is configured for ANSI formatted point code, the network indicator value of the far end pc parameter (**ni**) must be **6** or greater when the cluster value is **0** (**nc**).

Recovery

Re-enter the command specifying a valid point code value.

Refer to the specific commands and "Point Code Formats and Conversion," in the *Commands Manual* for information on the correct point code values.

E2171 Cmd Rej: Failed reading level 2 timer set table

Commands Used: `chg-l2t`, `rtrv-l2t`

The Level 2 Timer Set table is corrupt or cannot be found by the system. The Level 2 Timer Set table contains the level 2 timer set information.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2172 Cmd Rej: Command action is out of phase with expected procedure

Commands Used: `act-flash`, `act-upgrade`, `init-flash`

The `act-upgrade` command was not entered at the proper time during the upgrade process.

OR

You entered an `act-flash` command to activate a flash GPL, and the GPL running on the card is not inactive.

OR

You entered an `init-flash` command to load an inactive flash GPL onto a card, and the card is currently running an inactive flash GPL.

Recovery - act-upgrade

1. Enter the **act-upgrade:action=dbstatus** command to verify the phase that the upgrade process is in. The phase of the upgrade process is shown in the header of the command output.
 2. If the upgrade process is at Upgrade Phase 0, then enter the **act-upgrade:action=converttoam** command.
 3. If the upgrade process is at Upgrade Phase 2, then enter the **act-upgrade:action=oamcomplete** command.
-

Recovery - act-flash

1. Enter the **rept-stat-gpl** command to display the GPLs running on the cards installed in the system.
 2. Verify that the GPL you want to activate is inactive on the card. A plus sign (+) in the column between the RUNNING and APPROVED columns indicates an inactive GPL.
 3. If the GPL is inactive, re-enter the **act-flash** command.
Call your Customer Care Center if this error message appears again.
-

Recovery - init-flash

1. Display the GPLs running on the cards installed in the system. Enter the **rept-stat-gpl** command.
 2. Verify that the card is not already running an inactive flash GPL. A plus sign (+) in the column between the RUNNING and APPROVED columns indicates an inactive GPL.
 3. If the card is not running an inactive GPL, re-enter the **init-flash** command.
Call your Customer Care Center if this error message appears again.
-

E2173 Cmd Rej: Failed reading level 3 timer set table

Commands Used: **chg-13t**

The Level 3 Timer Set table is corrupt or cannot be found by the system. The Level 3 Timer Set table contains the level 3 timer set information.

Recovery

Re-enter the **chg-13t** command.

Call your Customer Care Center if this error message appears again.

E2174 Cmd Rej: May not modify both T20 and IT22 timers

Commands Used: chg-13t

The command was entered specifying both the **t20** and **it22** timers. These two parameters define the same timer, but the **t20** timer is used with ANSI linksets only, and the **it22** timer is used with ITU linksets. Because these two parameters define the same timer, both parameters cannot be specified in the same command.

Recovery

Re-enter the **chg-13t** command specifying either the **t20** parameter for ANSI linksets only, or the **it22** parameter for ITU linksets, but not both in the same command.

E2175 Cmd Rej: May not modify both T21 and IT23 timers

Commands Used: chg-13t

The command was entered specifying both the **t21** and **it23** timers. These two parameters define the same timer, but the **t21** timer is used with ANSI linksets only, and the **it23** timer is used with ITU linksets. Because these two parameters define the same timer, both parameters cannot be specified in the same command.

Recovery

Re-enter the **chg-13t** command specifying either the **t21** or **it23** parameters, but not both in the same command.

E2177 Cmd Rej: Destination parameter not supported

Commands Used: chg-db

The command was entered specifying the destination (**dest**) parameter, and the **action=backup** parameter was not specified. If you specify the **dest** parameter, the **action=backup** parameter must also be specified.

Recovery

Re-enter the **chg-db** command specifying both the **dest** and the **action=backup** parameters.

E2178 Cmd Rej: Source parameter not supported

Commands Used: chg-db

The command was entered specifying the source (**src**) parameter, and the **action=restore** parameter was not specified. If you specify the **src** parameter, the **action=restore** parameter must be specified.

Recovery

Re-enter the **chg-db** command specifying both the **src** and the **action=restore** parameters.

E2179 Cmd Rej: Current actv OAM db is not supported for this upgrade

Commands Used: act-upgrade

The database on the active TDM is not at the proper level for this command.

Recovery

Enter the **act-upgrade:action=dbstatus** command to verify the version of the database on the active TDM. The version of the database is shown in the VERSION STATUS field.

Call your Customer Care Center if this error message appears again.

E2180 Cmd Rej: Current stbby OAM db is not supported for this upgrade

Commands Used: act-upgrade

The database on the standby TDM is not at the proper level for this command.

Recovery

Enter the **act-upgrade:action=dbstatus** command to verify the version of the database on the standby TDM. The version of the database is shown in the VERSION STATUS field.

Call your Customer Care Center if this error message appears again.

E2181 Cmd Rej: ANSI PC is identical to ANSI CPC

Commands Used: `chg-sid`

The specified ANSI point code (**pca**) matches the ANSI capability point code (**cpca**).

Recovery

1. Verify the ANSI capability point code in the system. Enter the `rtrv-sid` command. The ANSI capability point code is shown in the CPCA field of the output.
 2. Display the destination point codes in the database. Enter the `rtrv-dstn` command. The ANSI destination point codes are shown in the DPCA field of the output.
 3. Display the adjacent point codes in the database. Enter the `rtrv-ls` command. The ANSI adjacent point codes are shown in the APCA field of the output.
 4. Re-enter the `chg-sid` command specifying a point code that does not match the capability point code, and does not match any point codes in the destination point codes or adjacent point codes.
-

E2182 Cmd Rej: Only one of NCPC/A, NCPCI, or NCPCN/N24 may be specified

Commands Used: `chg-sid`

You tried to enter the command specifying more than one of the **ncpc**, **ncpca**, **ncpci**, **ncpcn**, or **ncpcn24** parameters. You can enter only one of these parameters per command.

Recovery

Re-enter the `chg-sid` command specifying a value for only one of the following parameters: **ncpc**, **ncpca**, **ncpci**, **ncpcn**, or **ncpcn24**.

E2183 Cmd Rej: Capability point code is already being used

Commands Used: `chg-sid`

You specified a capability point code (`cpca`, `cpci`, `cpcn`, `cpcn24`) that is already being used to define an STP.

Recovery

1. Verify the site point codes and capability point codes in the system. Enter the `rtrv-sid` command. The site point codes are shown in the PCA, PCI, and PCN fields of the output. The capability point codes are shown in the CPCA, CPCI, CPCN, CPCN24 fields of the output.
 2. Display the destination point codes in the database. Enter the `rtrv-dstn` command. The ANSI destination point codes are shown in the DPCA, DPCI, DPCN, and DPCN24 fields of the output.
 3. Re-enter the `chg-sid` command specifying a point code that does not match the site point code or capability point code, and does not match any point codes in the destination point codes.
-

E2184 Cmd Rej: CLLI is already being used by a route

Commands Used: `chg-dstn`, `ent-dstn`

You specified a CLLI that already exists in the Route table. The CLLI must be unique to the Route table.

Recovery

1. Display the self-identification parameters. Enter the `rtrv-sid` command.
 2. Display all entries in the Route table or SID. Enter the `rtrv-dstn` command.
 3. Re-enter the command that generated this error message specifying a CLLI that is not in the Route table.
-

E2185 Cmd Rej: Capability point code matches STP's own point code

Commands Used: `chg-sid`

The capability point code (CPC) you entered matches either the STP's current point code or a point code previously specified for this STP.

Recovery

1. Enter the **rtrv-sid** command to display the CPC currently specified for the STP. The capability point code is displayed in either the CPCA, CPCI, CPCN, CPCN24, PC, PCI, PCN, or PCN24 field.
 2. Re-enter the command specifying a CPC that is different from the one displayed in step 1.
-

E2186 Cmd Rej: Capability point code already defined as a route DPC**Commands Used: chg-sid**

You entered the command and specified a value for the **cpc** parameter that matches a value already in the database as a route DPC. The capability point code (**cpc**) parameter cannot be already assigned as a route destination point code.

Recovery

1. Enter the **rtrv-dstn** command to display the route DPCs for this EAGLE 5 ISS.
 2. Re-enter the **chg-sid** command, specifying a value for the **cpc** parameter that differs from all of the DPCs displayed in step 1.
-

E2187 Cmd Rej: International PC is identical to international CPC**Commands Used: chg-sid**

The specified international (ITU-I) point code (**pci**) matches the international capability point code (**cpci**).

Recovery

1. Enter the **rtrv-sid** command to verify the ITU-I capability point code in the system. The ITU-I capability point code is shown in the CPCI field of the output.
 2. Enter the **rtrv-dstn** command to display the destination point codes in the database. The ITU-I destination point codes are shown in the DPCI field of the output.
 3. Re-enter the command specifying a point code that does not match the capability point code, and does not match any point codes in the destination point codes.
-

E2188 Cmd Rej: National PC is identical to national CPC

Commands Used: `chg-sid`

The specified national (ITU-N) point code (**pcn**) matches the national capability point code (**cpcn**).

Recovery

1. Verify the ITU-N capability point code in the system. Enter the `rtrv-sid` command. The ITU-N capability point code is shown in the CPCN field of the output.
 2. Display the destination point codes in the database. Enter the `rtrv-dstn` command. The ITU-N destination point codes are shown in the DPCN field of the output.
 3. Re-enter the command specifying a point code that does not match the capability point code, and does not match any point codes in the destination point codes.
-

E2189 Cmd Rej: Site point code is already being used

Commands Used: `chg-sid`, `ent-sid`

The `chg-sid` command was entered with a site point code (**pca**, **pci**, **pcn**, or **pcn24**) that was defined as a route destination point code. The site point code cannot be used as a route destination point code.

The `chg-sid` or `ent-sid` command was entered with an STP destination point code that was previously defined as a capability point code, or defined as the same type of STP destination point code if one already exists.

Recovery

1. verify the site point codes and capability point codes in the system. Enter the `rtrv-sid` command. The site point codes are shown in the PCA, PCI, PCN, and PCN24 fields of the output. The capability point codes are shown in the CPCA, CPCI, CPCN, and CPCN24 fields of the output.
 2. Display the destination point codes in the database. Enter the `rtrv-dstn` command. The ANSI destination point codes are shown in the DPCA, DPCI, DPCN, and DPCN24 fields of the output.
 3. Re-enter the command specifying a point code that does not match the site point code or capability point code, and does not match any point codes in the destination point codes.
-

E2190 Cmd Rej: Cannot delete STP self ID if a DPC of same type is defined**Commands Used: chg-sid**

You specified a point code parameter (**pc**, **pca**, **pci**, **pcn**, or **pcn24**) value of **none**. This action deletes the associated self ID point code from the database; however, the database contains point codes in the Destination Point Code table that are of the same point code type as the self ID point code being deleted. The EAGLE 5 ISS does not allow this action.

The EAGLE 5 ISS requires that, if destination point codes of a particular point code type are to be used, the EAGLE 5 ISS's self ID must be defined with a point code of the same point code type.

Recovery

1. Display the self ID of the EAGLE 5 ISS. Enter the **rtrv-sid** command.
2. Display the DPCs in the database. Enter the **rtrv-dstn** command.
3. Re-enter the **chg-sid** command that generated the error message specifying a point code parameter whose point code type is not being used by the Destination Point Code table as shown in the output from step 2. For example, if the **rtrv-dstn** output contains no DPCN or Aliasn field, use the **pcn=none** parameter for the self ID point code that you want to delete.

If the output from step 2 contains fields for all point code types (DPCA, DPCI, DPCN, and DPCN24), and you **must** delete the self ID point code, call your Customer Care Center for assistance.

E2191 Cmd Rej: Failed reading SLTM table**Commands Used: chg-slt**

The Signaling Link Test Message (SLTM) table is corrupt or cannot be found by the system. The SLTM table contains the signaling link test message information.

Recovery

Re-enter the **chg-slt** command.

Call your Customer Care Center if this error message appears again.

E2192 Cmd Rej: Pattern contains invalid characters**Commands Used: chg-slt**

The specified pattern contains characters that are not allowed. The pattern can contain only the characters **0 – 9** and **A – F**. The first two characters of the pattern must be the characters **A – F**.

Recovery

Re-enter the **chg-slt** command specifying a pattern that contains only the characters **0 – 9** and **A – F**, with the first two characters from the range **A – F**.

E2193 Cmd Rej: Pattern has odd number of characters**Commands Used: chg-slt**

The specified pattern contains an odd number of characters. It must have an even number of characters.

Recovery

Re-enter the **chg-slt** command specifying a pattern that contains an even number of characters, but no more than **30** characters.

E2194 Cmd Rej: SLTSET and ENABLED cannot be specified together**Commands Used: rtrv-slt**

The command was entered with both the **sltset** and **enabled** parameters. This parameter combination is not allowed by this command.

Recovery

Re-enter the **rtrv-slt** command specifying either the **sltset** or **enabled** parameters, but not both.

E2195 Cmd Rej: NCDPNPFX already exists in INPOPTS Table**Commands Used: chg-inpopts**

You entered a command to change a New Called Party Number Prefix to the prefix specified in the **ncdpnpfx** parameter, and the new Prefix already exists in the INPOPTS table.

Recovery

1. Enter the **rtrv-inpopts** command. The CDPNPFX field in the output shows a list of prefixes that are already entered in the INPOPTS table.
2. If the new prefix you entered does not appear in the output, re-enter the **chg-inpopts** command.

Call your Customer Care Center if this error message appears again.

E2196 Cmd Rej: Failed reading the user identification table

Commands Used: **chg-pid**, **chg-user**, **dlt-user**, **ent-user**

The user identification table is corrupt or cannot be found by the system. This table contains the user identification information.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2197 Cmd Rej: The specified user identification is already defined

Commands Used: **chg-user**, **ent-user**

The command entered specified a user identification (**nuid** for the **chg-user** command, **uid** for the **ent-user** command) that already exists in the database. The values specified for the **uid** parameter (**ent-user** command) or **nuid** (**chg-user** command) cannot be in the database.

Recovery

1. Display the user IDs in the database. Enter the **rtrv-user** command.
 2. Re-enter the command that generated this error message with a value for the **uid** parameter (**ent-user** command) or **nuid** (**chg-user** command) that is not shown in the output of step 1.
-

E2198 Cmd Rej: The maximum number of users is already defined**Commands Used: ent-user**

The database can contain a maximum of **100** user IDs. An attempt was made to add a user ID to the database, and the database already contains the maximum **100** user IDs. No more users can be added until a current user ID is deleted from the database or a current user ID is changed.

Recovery

1. Display the user IDs in the database. Enter the **rtrv-user** command.
 - If you wish to change a current user ID, enter the **chg-user** command specifying a user ID (**uid**) shown in the output of step 1. For the **nuid** parameter, specify the user ID used in the command that generated this error message.
 - If you wish to delete a user ID from the database, enter the **dlt-user** command specifying a user ID shown in the output of step 1. Enter the **rept-stat-user** command to verify if the user ID to be deleted is currently logged on to the system. If that user is logged on to the system, advise that user to log off the system. If the user is logged on to the system, and you execute the **dlt-user** command, that user will be logged off the system.
 2. Re-enter the **ent-user** command that generated this error message.
-

E2199 Cmd Rej: The specified user identification is not defined**Commands Used: chg-pid, chg-user, dlt-user, rtrv-secu-user**

The command was entered with a user identification (**uid**) that is not in the database. The value specified for the **uid** parameter must be in the database.

Recovery

1. Display the user IDs in the database. Enter the **rtrv-user** command.
 2. Re-enter the command that generated this error message with a value for the **uid** parameter that is shown in the output of step 1.
-

E2200 Cmd Rej: Database maint. in progress - retry later

Commands Used: `chg-dstn`, `chg-feat`, `chg-ls`, `chg-rte`,
`chg-x25-dstn`, `chg-x25-rte`, `chg-x25-slk`, `dlt-card`, `dlt-dlk`,
`dlt-dstn`, `dlt-ip-node`, `dlt-ls`, `dlt-rte`, `dlt-slk`,
`dlt-x25-dstn`, `dlt-x25-rte`, `ent-card`, `ent-dlk`, `ent-dstn`,
`ent-ip-node`, `ent-ls`, `ent-rte`, `ent-slk`, `ent-x25-dstn`,
`ent-x25-rte`, `rtrv-card`, `rtrv-dstn`, `rtrv-feat`, `rtrv-ip-node`,
`rtrv-ls`, `rtrv-rte`, `rtrv-slk`, `rtrv-x25-dstn`, `rtrv-x25-rte`,
`rtrv-x25-slk`

You entered the command while a database maintenance operation was being executed and was not completed. This command cannot be executed while a database maintenance operation is in progress.

Recovery

Wait for the database maintenance operation to finish, then re-enter the command.

E2201 Cmd Rej: Shelf location 1100 is reserved for the control shelf

Commands Used: `dlt-shlf`, `ent-shlf`

The command was entered with the value **1100** for the **loc** parameter. Shelf **1100** is the control shelf and cannot be deleted from the database.

Recovery

1. Display the shelves in the database. Enter the `rtrv-shlf` command.
 2. Re-enter the command specifying values shown in the SHELF FRAME and DISPLAY SHELF fields of the `rtrv-shlf` output to determine the value of the **loc** parameter. For example, if the value **3** is shown in the SHELF FRAME field and the value **2** is shown in the DISPLAY SHELF field, that shelf would be entered in the `dlt-shlf:loc=` command as **3200**.
-

E2202 Cmd Rej: Shelf location already equipped

Commands Used: `ent-shlf`

The shelf specified by the **loc** parameter already exists in the database. The shelf specified by the **loc** parameter cannot be in the database.

Recovery

1. Display the shelves in the database. Enter the **rtrv-shlf** command.
 2. Re-enter the **ent-shlf** command specifying a shelf location that is not shown in the output of step 1.
-

E2203 Cmd Rej: All cards on shelf must be unequipped**Commands Used: dlt-shlf**

An attempt was made to remove a shelf from the database, and that shelf has cards assigned to it. The specified shelf cannot contain any cards.

Recovery

To remove the cards from the shelf, go to the “Removing a Shelf” procedure in the *Database Administration Manual - System Management*.

E2204 Cmd Rej: Waiting for duplex mode in provisioning subsystem**Commands Used: Any command used to update a database**

An attempt was made to update a database immediately following a dual OAM boot, a switchover, or a database repair, and before the detection of an active standby. An active OAM waits for up to five minutes for an available standby before allowing database updates.

Recovery

1. Wait for the message:
INFO: Provisioning subsystem is in duplex mode.
OR
Wait five minutes.
 2. Re-enter the command.
-

E2205 Cmd Rej: Invalid destination application ID**Commands Used: send-msg**

You specified an invalid **da** parameter value.

Recovery

Re-enter the **send-msg** command that generated this error message specifying the correct **da** parameter value.

Call your Customer Care Center if this error message appears again.

E2206 Cmd Rej: Invalid originating application ID

Commands Used: **send-msg**

You specified an invalid **oa** parameter value.

Recovery

Re-enter the **send-msg** command that generated this error message specifying the correct **oa** parameter value.

Call your Customer Care Center if this error message appears again.

E2207 Cmd Rej: Location type cannot receive messages

Commands Used: **send-msg**

The destination location is not equipped to receive messages. You may have specified the wrong card location (**loc** parameter).

Recovery

Re-enter the **send-msg** command that generated this error message specifying the correct **loc** parameter value.

Call your Customer Care Center if this error message appears again.

E2208 Cmd Rej: ALL only qualifier allowed with given card type

Commands Used: **disp-bp, disp-mem, dlt-bp, ent-bp, ent-trace, set-mem**

You attempted to run this command specifying the card type qualifier (subsystem) set to a value that is not allowed for the card.

Recovery

Re-enter the command that generated this error message specifying the **all** value for the subsystem qualifier.

Call your Customer Care Center if this error message appears again.

E2209 Cmd Rej: Both DR and DA parameters cannot be entered

Commands Used: **ent-bp**

You attempted to run this command and specified values for both the data register and memory dump address parameters.

Recovery

Perform one of the following:

- Re-enter the **ent-bp** command that generated this error message specifying only the **dr** parameter.

OR

- Re-enter the **ent-bp** command that generated this error message specifying only the **da** parameter.

Call your Customer Care Center if this error message appears again.

E2210 Cmd Rej: BYTE, WORD or DWORD must be entered

Commands Used: **set-mem**

You tried to run this command without specifying one of the following parameters: **byte**, **word**, or **dword**.

Recovery

Re-enter the **set-mem** command that generated this error message specifying the correct **byte**, **word**, or **dword** parameter value.

Call your Customer Care Center if this error message appears again.

E2211 Cmd Rej: Maximum number of CDPNPFXs already provisioned

Commands Used: `chg-inpopts`

You entered the command to provision a Called Party Number Prefix (CDPNPFX), but the database already contains the maximum of five prefixes.

Recovery

Verify the number of prefixes in the database. Enter the `rtrv-inpopts` command. View the CDPNPFX column of the output.

- If the number of prefixes is less than five, re-enter `chg-inpopts` command that generated this error message.
- If the number of prefixes is five, change one of the existing prefixes. Enter the `chg-inpopts` command.

Call your Customer Care Center if this error message appears again.

E2212 Cmd Rej: Invalid card type for this command

Commands Used: `act-flash, chg-appl-sock, chg-bip-fld, chg-bip-rec, chg-e1, chg-ip-card, chg-ip-lnk, chg-t1, disp-bip, disp-bp, disp-mem, dlt-appl-rtkey, dlt-bp, dlt-e1, dlt-ip-rte, dlt-t1, ent-appl-sock, ent-bp, ent-card, ent-e1, dlt-ip-rte, ent-slk, ent-t1, ent-trace, init-flash, init-imt-gpl, rept-x25-meas, rtrv-appl-rtkey, rtrv-bip, rtrv-e1, rtrv-ip-card, rtrv-ip-lnk, rtrv-ip-rte, rtrv-t1, set-mem, tst-slk, tst-t1`

The card specified in the `loc` parameter is not valid.

Recovery `ent-appl-sock, chg-appl-sock`

The card type cannot be an IPGWI with TALI sockets provisioned.

1. Display the card's configuration. Enter the `rtrv-card` command specifying the card location that generated this error message. The card's **type** is shown in the TYPE field of the output.
2. Re-enter the command. Specify the correct location for the card's type.

Call your Customer Care Center if this error message appears again.

Recovery - chg-e1, dlt-e1, ent-e1, rtrv-e1

The card type allowed for these commands must be a **lime1**.

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location that generated this error message. The card's type is shown in the TYPE field of the output.
 2. If the card at the specified location is of type **lime1**, re-enter the command.
Call your Customer Care Center if this error message appears again.
-

Recovery - chg-t1, dlt-t1, ent-t1, rtrv-t1, tst-t1

The specified card location (**loc**) parameter must be an HC-MIM card with card type **limt1**.

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location that generated this error message. The card's type is shown in the TYPE field of the output.
 2. If the card at the specified location is a **limt1**, re-enter the command.
Call your Customer Care Center if this error message appears again.
-

Recovery - ent-card

For the **ent-card** command, the valid card types (**type**) parameter are: **acmenet, dcm, dsm, ipsm, limatm, limch, limds0, lime1, lime1atm, limocu, limt1, limv35, mcpm, stc, tsm**.

Re-enter the **ent-card** command specifying a valid card type (**type**) parameter.
Call your Customer Care Center if this error message appears again.

Recovery - ent-slk

Display the card's configuration. Enter the **rtrv-card** command specifying the card location that generated this error message. The card's type is shown in the TYPE field of the output.

- If the card in the specified location is a **lime1**, re-enter the **ent-slk** command specifying the **e1loc** parameter.
- If the card in the specified location is a **limt1**, re-enter the **ent-slk** command specifying the **t1loc** parameter.

Call your Customer Care Center if this error message appears again.

Recovery - **tst-slk**

The card types **lime1**, **limt1**, and **limch** are supported for this command only for **loopback** type **sltc**.

1. Display the card's configuration, using the **rtrv-card** command specifying the card location used in the command that generated this error message. The card's type is shown in the TYPE field of the output.
 2. If the card in the specified location is a **lime1**, **limt1**, or **limch** card, re-enter the **tst-slk** command specifying the **loopback=sltc** parameter.
-

Recovery - **act-flash, init-flash**

This command requires an allowed high-speed ATM signalling link card (**limatm**), or data communications module card of type **dcm**, **dsm**, **lime1**, **limt1**, or **limch** (including DSM, MPL, MPL-T, GPSM-II, and E1/T1 MIM cards).

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location used in the command that generated this error message. The card's type is shown in the TYPE field of the output.
 2. Re-enter the command specifying the correct location for the card's type.
-

Recovery - **chg-ip-card, rtrv-ip-card**

This command requires an allowed DSM or IPSM card.

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location used in the command that generated this error message. The card's type is shown in the TYPE field of the output.
 2. If the card in the specified location is a DSM or IPSM, re-enter the command.
 3. Call your Customer Care Center if this error message appears again.
-

Recovery - chg-ip-lnk, rtrv-ip-lnk

This command requires an allowed DCM, SSEDCCM, DSM, or IPSM (card type DCM) card. If the Ethernet interface B is used, the card must be an SSEDCCM.

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location used in the command that generated this error message. The card's type is shown in the TYPE field of the output.
2. If the card in the specified location is a DCM, SSEDCCM, DSM, or IPSM, re-enter the command.

Call your Customer Care Center if this error message appears again.

Recovery - ent-trace

For the **ent-trace** command, the following values are allowed: **atmansi, atmitu, ccs7, ituipgwi, iplim, iplimi, sccp, ss7ansi, ss7ipgw, or vsccp**.

Re-enter the command specifying a valid value for the **ent-trace** parameter.

Recovery - init-imt-gpl

For the **init-imt-gpl** command, you cannot specify a high-speed ATM signaling link card type (**type=limatm**).

1. Display the card's configuration. Enter the **rtrv-slk** command specifying the card location used in the command that generated this error message. The card's type is shown in the TYPE field of the output.
 2. Re-enter the command specifying the correct location for the card's type.
-

Recovery - rept-x25-meas

The card type can be X.25 signaling links that are equipped in the database.

1. Verify the specified card applications. Enter the **rtrv-card** command. Cards that can contain an X.25 signaling link are assigned the **ss7gx25** application. This is shown in the APPL field in the output.

2. Verify the signaling links in the database. Enter the **rtrv-slk** command.
3. Using the outputs of steps 1 and 2 as a guide, re-enter the command specifying a card location that is both assigned the **ss7gx25** application, and equipped as a signaling link.

Recovery - chg-bip-rec, chg-bip-fld, disp-bip, rtrv-bip

Either there is no BIP at this location (TDM at locations **1114** or **1116**, HMUX or HIPR at locations **9** and **10** on each extension shelf), or the **type** is not supported (e.g. **type=dbd** was specified for an OAM, ATM, TSM, or E1 card).

Re-enter the command specifying the correct values for **loc** and **type**.

**Recovery - disp-bp, disp-mem, dlt-bp, disp-mem, set-mem,
dlt-appl-rtkey, rtrv-appl-rtkey**

Re-enter the command specifying the correct value for **loc**.

Recovery - dlt-ip-rte, ent-ip-rte, rtrv-ip-rte

The card type in the location specified in the **loc** parameter must be an IP card (a DCM or SSEDCCM card running the **ss7ipgw**, **ipgwi**, **iplim** or **iplimi** application).

1. Enter the **rtrv-card** command to display the card types installed in the system.
2. Re-enter the command specifying a card location in the **loc** parameter for the correct IP card.

E2213 Cmd Rej: Missing parameter - BC

Commands Used: disp-mem, ent-bp

You ran this command without specifying the **bc** parameter (number of data bytes to display).

Recovery

Re-enter the command that generated this error message specifying the correct **bc** parameter value.

Call your Customer Care Center if this error message appears again.

E2214 Cmd Rej: Missing parameter - CARD, LOC or IMT

Commands Used: `disp-bp`, `disp-mem`, `dlt-bp`, `ent-bp`, `set-mem`

You attempted to run this command without specifying one of these parameters: `card`, `loc`, or `imt`.

Recovery

Re-enter the command that generated this error message specifying the correct value for one (and only one) of the following parameters: `card`, `loc`, or `imt`.

Call your Customer Care Center if this error message appears again.

E2215 Cmd Rej: Missing parameter - DA or DR

Commands Used: `ent-bp`

You attempted to run this command without specifying either the data register (`dr`) or the memory dump address (`da`) parameters.

Recovery

Perform one of the following:

- Re-enter the `ent-bp` command that generated this error message specifying the correct `dr` parameter value.

OR

- Re-enter the `ent-bp` command that generated this error message specifying the correct `da` parameter value.

Call your Customer Care Center if this error message appears again.

E2216 Cmd Rej: CDPNPFX must not be NONE

Commands Used: `chg-inpopts`

The `cdnpfx` parameter cannot have a specified value of `none`.

Recovery

1. View the values for **cdpnpfx**. Enter the **rtrv-inpopts** command.
 2. To delete an existing prefix (that appears in the output of step 1), re-enter the **chg-inpopts** command specifying the desired prefix in the **cdpnpfx** parameter and **ncdnpfx=none**.
-

E2217 Cmd Rej: More than one of CARD, LOC and IMT specified

Commands Used: **disp-bp, disp-mem, dlt-bp, ent-bp, set-mem**

You attempted to run this command while specifying more than one of these parameters: **card, loc, or imt**.

Recovery

Re-enter the command that generated this error message specifying the correct value for one (and only one) of the following parameters: **card, loc, or imt**.

Call your Customer Care Center if this error message appears again.

E2218 Cmd Rej: Only one of BYTE, WORD or DWORD may be entered

Commands Used: **set-mem**

You tried to run this command while entering more than one of the following parameters: **byte, word, or dword**.

Recovery

Re-enter the **set-mem** command that generated this error message specifying the correct **byte, word, or dword** parameter value.

Call your Customer Care Center if this error message appears again.

E2219 Cmd Rej: Specified BC exceeds max allowed (96)

Commands Used: **ent-bp**

You cannot specify a value greater than **96** for the **bc** parameter (number of data bytes to display).

Recovery

Re-enter the **ent-bp** command that generated this error message specifying a **bc** parameter value ≤ 96 .

Call your Customer Care Center if this error message appears again.

E2220 Cmd Rej: DLTPFX must not be specified, when NCDPNPFX is NONE

Commands Used: **chg-inopts**

You specified **ncdnpfx=none** and specified the **dlfpfx** parameter. You cannot specify the **dlfpfx** parameter when you specify the value **none** for the **ncdnpfx** parameter.

Recovery

To delete a prefix, re-enter the **chg-inopts** command specifying the value in the **cdnpfx** parameter for the prefix to be deleted and **ncdnpfx=none**.

E2221 Cmd Rej: File transfer in progress

Commands Used: **act-file-trns, copy-fta, copy-seculog, disp-fta-dir, dlt-fta**

You entered the command while another command is already in progress. The EAGLE 5 ISS does not allow this action. Only one file transfer may be active at one time.

Recovery

Wait until the file transfer is complete, then re-enter the command.

E2222 Cmd Rej: CDPNPFx doesn't exist in INPOPTS Table

Commands Used: **chg-inopts**

You entered a command to change or delete a value for the **cdnpfx** parameter that is not in the INPOPTS table.

Recovery

Enter the **rtrv-inopts** command. The CDPNPFX field in the output shows a list of valid names.

- If the value you entered appears in the output, re-enter the **chg-inopts** command.
- If the value you entered does not appear in the output, you cannot change or delete the specified **cdnpfx** value.

Call your Customer Care Center if this error message appears again.

E2223 Cmd Rej: Invalid drive specified

Commands Used: **copy-fta**, **disp-tbl**, **set-lbp**, **set-tbl**

You attempted to run this command while specifying an invalid hard drive.

Recovery

Re-enter the command that generated this error message specifying the correct drive identifier.

Call your Customer Care Center if this error message appears again.

E2224 Cmd Rej: Only one Source and Destination may be specified

Commands Used: **chg-db**, **copy-fta**

You cannot specify multiple instances of the **src** or **dest** parameters.

Recovery

Re-enter the command that generated this error message specifying the correct **src** and **dest** parameter values.

Call your Customer Care Center if this error message appears again.

E2225 Cmd Rej: SRC and DEST must be specified

Commands Used: **chg-db**, **copy-fta**

You failed to specify both the source and the destination parameters for this operation.

Recovery

Re-enter the command that generated this error message specifying correct **src** and **dest** parameter values.

Call your Customer Care Center if this error message appears again.

E2226 Cmd Rej: CDPNNAI doesn't exist in INPOPTS Table

Commands Used: **chg-inopts**

You specified **snai=none** to delete a **cdpnnai** from the database, and the **cdpnnai** value that you entered does not exist in the database.

Recovery

1. Enter the **rtrv-inopts** command. The CDPNNAI field in the output shows a list of valid values.
 2. If the **cdpnnai** value you entered appears in the output, re-enter the command. Call your Customer Care Center if this error message appears again.
 3. If the value you entered does not appear in the output, you cannot specify **snai=none** to delete it.
-

E2227 Cmd Rej: Maximum Number of CDPNNAIs already provisioned

Commands Used: **chg-inopts**

You entered the command to create or change a Called Party Number Nature of Address Indicator, but the database already contains the maximum of 5 values.

Recovery

Verify the number of **cdpnnai** values in the INPOPTS table. Enter the **rtrv-inpopts** command.

- If the number of CDPNNAs listed in the CDPNNAI column of the output is less than 5, re-enter the **chg-inpopts** command that generated this error message.
- If the number of CDPNNAs is 5 or greater, you must delete or change one of the existing CDPNNAs. Enter the **chg-inpopts** command to change the value of an existing **cdpnnai** entry.

Call your Customer Care Center if this error message appears again.

E2229 Cmd Rej: Use DFILE when specifying STBL

Commands Used: **copy-fta**

You cannot copy information out of a Source table into a destination file without specifying both the **(dfile)** and **(stbl)** parameters. A destination file must be specified when a Source table is specified.

Recovery

Re-enter the **copy-fta** command that generated this error message specifying both the **(dfile)** and **(stbl)** parameters. A Source table must be specified when a destination file is specified.

Call your Customer Care Center if this error message appears again.

E2230 Cmd Rej: Use DTBL when specifying SFILE

Commands Used: **copy-fta**

You cannot copy information out of a source file into a Destination table without specifying both the **(dtbl)** and **(sfile)** parameters. A Destination table must be specified when a source file is specified.

Recovery

Re-enter the **copy-fta** command that generated this error message specifying both the **(dtbl)** and **(sfile)** parameters.

Call your Customer Care Center if this error message appears again.

E2231 Cmd Rej: Use SFILE when specifying DTBL**Commands Used: copy-fta**

You cannot copy information out of source file into a Destination table without specifying both the **(dtbl)** and **(sfile)** parameters. A source file must be specified when a Destination table is specified.

Recovery

Re-enter the **copy-fta** command that generated this error message specifying both the **(dtbl)** and **(sfile)** parameters.

Call your Customer Care Center if this error message appears again.

E2232 Cmd Rej: Use STBL when specifying DFILE**Commands Used: copy-fta**

You cannot copy information out of a Source table into a destination file without specifying both the **(dfile)** and **(stbl)** parameters. A Source table must be specified when a destination file is specified.

Recovery

Re-enter the **copy-fta** command that generated this error message specifying both the **(dfile)** and **(stbl)** parameters.

Call your Customer Care Center if this error message appears again.

E2233 Cmd Rej: May not specify Filename when ALL=YES**Commands Used: dlt-fta**

You cannot specify the **filename** parameter, if the **all** parameter equals **yes (all=yes)**.

Recovery

Perform one of the following:

- Re-enter the **dlt-fta** command specifying the **all=yes** parameter.
- OR
- Re-enter the **dlt-fta** command specifying the **filename** parameter.

Call your Customer Care Center if this error message appears again.

E2234 Cmd Rej: Must specify ALL=YES to delete all files

Commands Used: `dl1t-fta`

You attempted to run this command specifying the **all** parameter not specified or specified as **no**, and with the filename not specified as well.

Recovery

Perform one of the following actions:

- Re-enter the `dl1t-fta` command that generated this error message specifying the **all=yes** parameter.

OR

- Re-enter the `dl1t-fta` command that generated this error message specifying the filename.

Call your Customer Care Center if this error message appears again.

E2235 Cmd Rej: Card location must be 1113 or 1115, or APPL=E(OAM)

Commands Used: `init-card`

You specified the `initclk` parameter that is invalid because it does not meet these criteria:

- If `initclk` and `appl` parameters are used, the specified `loc` must be **1113** or **1115**.

OR

- If `initclk` and `appl` parameters are used, the specified `appl` must be **oam**.

Recovery

Re-enter the `init-card` command specifying one of the following:

- Specify **1115** when `initclk` and `loc` are specified, or

OR

- Specify **appl=eam** when **initclk** and **appl** are specified, or
OR
 - Specify **appl=eoam** when **initclk** and **appl** are specified.
-

E2236 Cmd Rej: Must specify GPL name and version

Commands Used: **chg-gpl**, **rtrv-stp**

For the **chg-gpl** command, if either of the **appl** or **ver** parameters are specified, then both of these parameters must be specified. The one exception to this rule is that the **ver** parameter is not required if **appl=emap** or **appl=oap**.

For the **rtrv-stp** command, the **gpl** parameter is mandatory when the **ver** parameter is specified.

Recovery chg-gpl

Re-enter the **chg-gpl** command specifying both the **appl** and **ver** parameters.

Recovery rtrv-stp

Re-enter the **rtrv-stp** command specifying both the **gpl** and **ver** parameters.

E2237 Cmd Rej: Card location must be 1114 or 1116

You specified an invalid value for the **loc** parameter.

Recovery

Re-enter the command that generated this error message specifying the correct value for the **loc** parameter.

Call your Customer Care Center if this error message appears again.

E2239 Cmd Rej: Data audit already in progress

Commands Used: **aud-data**

An attempt was made to execute the **aud-data** command while a previously entered **aud-data** command was still executing.

Recovery

If you want to execute the **aud-data** command again, wait for the previously entered **aud-data** command to finish executing. Otherwise, no action is necessary.

E2240 Cmd Rej: Card location must be 1114, 1116, or 1117

Commands Used: **copy-fta, disp-fta-dir, disp-tbl, set-lba, set-tbl**

The command was entered with a card location other than the TDMs (1114, 1116), or MDAL (1117).

Recovery

Re-enter the command specifying one of these card locations: 1114, 1116, or 1117. If card location 1117 is specified, make sure a removable cartridge is in the removable cartridge drive.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure completes.

E2241 Cmd Rej: No File Transfer Area on removable cartridge

Commands Used: **copy-fta, dlt-fta**

The command was entered with the card location of the source (**sloc**) or the card location of the destination (**dloc**) equal to the removable cartridge disk location, and using a default value for the FTA to be copied (**sfile**) or for the name of the file to be copied into the FTA (**dfile**).

Recovery

Re-enter the **copy-fta** command specifying a value for **sfile** or **dfile**.

Call your Customer Care Center if this error message appears again.

E2242 Cmd Rej: Destination card invalid

Commands Used: `chg-bip-flt`, `chg-bip-rec`, `disp-bip`, `rtrv-bip`, `tst-bip`

The command was entered with a card location (**loc**) that is either an HMUX or MDAL card. These card locations are not valid with these commands.

Recovery

Re-enter the command specifying a card location that is not an HMUX or MDAL card.

NOTE: The MDAL card is in location 1117. The HMUX cards are in locations 9 and 10 on each shelf.

E2244 Cmd Rej: INIT=YES only valid with BID record

Commands Used: `chg-bip-rec`

You attempted to initialize a Board Identification PROM, but did not include the necessary identification information when you entered this command.

Recovery

Re-enter the `chg-bip-rec` command that generated this error message specifying the correct **data** parameter value.

Call your Customer Care Center if this error message appears again.

E2245 Cmd Rej: CDPNNAI and SNAI must be specified together

Commands Used: `chg-inopts`

You specified the `cdpnnai` parameter or the `snai` parameter but not both. When you specify one of these parameters (`cdpnnai` and `snai`) in this command, the other parameter must also be specified.

Recovery

Re-enter the `chg-inopts` command specifying both the `cdpnnai` and `snai` parameters.

E2246 Cmd Rej: Command Class Management feature must be enabled

Commands Used: `chg-cmd`, `chg-cmdclass`, `chg-secu-trm`, `chg-user`,
`ent-user`, `rtrv-cmd`, `rtrv-cmdclass`

These commands or a configurable command class name are not allowed until the Command Class Management feature has been enabled. You must enable the Command Class Management feature before these commands are supported.

Recovery

1. Display the controlled features that are turned on in the system. Enter the `rtrv-ctrl-feat` command. Verify that the Command Class Management feature is turned on.
2. If the Command Class Management feature is turned on, you can re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2252 Cmd Rej: Day out of range

Commands Used: `rtrv-log`, `rtrv-secu-log`, `set-date`

You specified the day part of the date not within the allowed range of values. The day component must accurately reflect the number of days in the month and year indicated. For example, you entered **960231**, and February never has more than 29 days.

Recovery

Re-enter the command specifying a system date within the allowed range of values.

E2253 Cmd Rej: Echo is not set for this terminal

Commands Used: `canc-echo`, `dact-echo`

This command stops the echoing of output from a terminal to one or more terminals. An attempt was made to stop the echoing of the terminal's output when the terminal was not able to echo its output.

Recovery

No action required. If you want to activate the echoing of the terminal's output, enter the **act-echo** command.

E2254 Cmd Rej: Minutes out of range

Commands Used: **act-lbp, rtrv-log, rtrv-secuolog, set-time**

The following Recovery procedures lists by command the remedial action to take if you encounter this error message.

Recovery - **act-lbp**

1. You specified a value for the **time=hhmmss** that is out of range. Specify **time** in the **hhmmss** format. The range for **mm** is **00-59**. The hh part of time is handled by the parser.
2. Re-enter the command specifying value for the minutes from **00** to **59**.

Recovery - **rtrv-log, rtrv-secuolog**

1. You specified a value for the minutes component of the **stime** and **etime** parameter combination that is not valid. Using the 24-hour clock, specify the time in the form of HHMMSS, where HH is the hour, MM is the minutes, and SS is the seconds. The valid values for the minutes is **00** to **59**.
 2. Re-enter the command specifying the value for the minutes from **00** to **59**.
-

Recovery - **set-time**

1. You specified an invalid value for the minutes displayed in the system time. The system time, along with the system date, is reflected on all reports and output messages. The system time is entered in the form of HHMM, where HH is the hour, MM is the minutes. The hour is based on a 24-hour clock. The valid values for the minutes is **00** to **59**.
 2. Re-enter the command specifying the value for the minutes from **00** to **59**.
-

E2255 Cmd Rej: Month out of range

Commands Used: `rtrv-log`, `rtrv-secu-log`, `set-date`

You specified a value for month not in the valid range. Enter the date in the form of YYMMDD, where YY is the year, MM is the month, and DD is the day of the month. The valid values for the month is **01** to **12**.

Recovery

Re-enter the command specifying a value for the month from **01** to **12**.

E2256 Cmd Rej: Terminal is currently inhibited

Commands Used: `act-echo`

The terminal that the output would be sent to is inhibited. Terminal output cannot be echoed to a terminal that is inhibited.

Recovery

1. Enter the `rept-stat-trm` command to display the status of all the terminals and printers on the system.
 2. Enter the `rst-trm` or the `alw-trm` command specifying the terminal numbers that are inhibited to activate these terminals.
 3. Re-enter the command.
-

E2257 Cmd Rej: Terminal is currently out of service

Commands Used: `act-echo`, `inh-trm`, `rmv-trm`

Table 2-6 lists by command the conditions that may have generated the error message.

Table 2-6. Conditions that Generate an E2257 Error Message

Command	Condition
<code>act-echo</code>	The terminal that the output would be sent to is currently out of service. Terminal output cannot be echoed to a terminal that is out of service.
<code>inh-trm</code> <code>rmv-trm</code>	An attempt was made to place a terminal out of service and that terminal was already out of service. Only terminals that are in service can be placed out of service.

Recovery

1. Verify the status of the terminals. Enter the **rept-stat-trm** command. The terminals that are in service are shown by the entry IS-NR in the PST field in the **rept-stat-trm** output.
 2. Re-enter the command specifying a terminal, from the output of step 1, that is in service.
-

E2258 Cmd Rej: NMULTCC and MULTCC parameters must be entered together

Commands Used: **chg-gsmopts**

If you specify the **nmultcc** parameter, you must also specify the **multcc** parameter.

Recovery

Whenever the **nmultcc** parameter is specified to change an existing value, the **multcc** parameter must also be specified. For example, specify both parameters in the command **chg-gsmopts:multcc=xxx:nmultcc=yyy** to change the value **xxx** to the value **yyy** in the GSM Options MULTCC list.

E2259 Cmd Rej: Terminal already echoing to specified terminal

Commands Used: **act-echo**

An attempt was made to echo the terminal's output to a terminal that is already being used for this purpose.

Recovery

No action is necessary since the terminal's output is being echoed to the specified terminal.

E2260 Cmd Rej: Disk access error - fixed disk

Commands Used: **act-user, dact-user, login, logout**

The command was entered and both TDMs could not be found.

Recovery

1. Visually verify that both TDM cards are present in card locations **1114** and **1116**. If they are not, place each TDM card in locations **1114** and **1116** making sure that each TDM is fully seated in the control shelf.
2. Enter the **rept-stat-db** command to verify the status of the TDM cards. Both the active and the standby TDM cards should be in the IS-NR (in-service normal) state.

Call your Customer Care Center if this error message appears again.

E2261 Cmd Rej: Illegal attempt to delete yourself

Commands Used: **dlt-user**

The command was entered with the user ID of the user logged on the terminal that this command was issued from. This is not allowed by this command.

Recovery

1. Display the user IDs in the database. Enter the **rtrv-user** command.
 2. If you are not the user logged on to the terminal that issued the command that generated this error message, enter the **rept-stat-user** command to verify the user ID that is logged on to this terminal. The terminal ID is shown in the system ID region of the terminal display.
 3. Re-enter the command that generated this error message with a value for the **uid** parameter that is shown in the output of step 1, but not the one that is logged on to this terminal, as shown in the output of step 2.
-

E2262 Cmd Rej: Password too long, 12 maximum

Commands Used: **act-user, chg-pid, chg-user, ent-user, login**

The command was entered with a password that contained more than twelve alphanumeric characters. The password must contain the minimum required in **rtrv-secu-dflt**, and no more than twelve alphanumeric characters. The password is not case sensitive. For security reasons, the password is never displayed on the terminal.

Recovery

1. Enter the **rtrv-secu-dflt** command to see the default settings for passwords on this system.

minlen = minimum number of characters required.

alpha = minimum number of alpha characters required.

num = minimum number of number characters required.

punc = minimum number of punctuation characters required.

2. Re-enter the command specifying a password that contains from five to twelve alphanumeric characters.
-

E2263 Cmd Rej: Password does not contain enough characters

Commands Used: *act-user*, *chg-pid*, *chg-user*, *ent-user*, *login*

The command was entered with a password that contained less than five alphanumeric characters. The password must contain the minimum required in **rtrv-secu-dflt**, and no more than twelve alphanumeric characters. The password is not case sensitive. For security reasons, the password is never displayed on the terminal.

Recovery

1. Enter the **rtrv-secu-dflt** command to see the default settings for passwords on this system.

minlen = minimum number of characters required.

alpha = minimum number of alpha characters required

num = minimum number of number characters required

punc = minimum number of punctuation characters required.

2. Re-enter the command specifying a password that contains from five-to-twelve alphanumeric characters.
-

E2264 Cmd Rej: Password verification failed

Commands Used: *act-user*, *chg-pid*, *chg-user*, *ent-user*, *login*

The user ID and password combination that was entered could not be found in the database.

Recovery

1. Verify that the user ID and password combination are correct.
 2. Re-enter the command specifying the correct user ID and password combination.
- Call your Customer Care Center if this error message appears again.
-

E2265 Cmd Rej: User currently logged on**Commands Used: chg-user**

An attempt was made to change the attributes of a user ID, and that user was logged on the system. No changes can be made to a user ID while that user is logged on the system.

Recovery

1. Display the user IDs in the database. Enter the **rtrv-user** command.
 2. Display the users logged on the system. Enter the **rept-stat-user** command.
 3. Re-enter the command specifying a user ID that is shown in the output from step 1 and not shown in the output from step 2.
-

E2266 Cmd Rej: Class name is not an existing configurable command class**Commands Used: chg-cmd, chg-secu-trm, chg-user, ent-user**

The arguments specified by the Configurable Command Class names (parameters **CC1** to **CC8**) must be set to **default** or provisioned to configurable command class names.

Recovery

Enter the **rtrv-cmdclass** command to find the list of valid configurable command class names; then re-enter the command specifying corrected names.

Call your Customer Care Center if this error message appears again.

E2267 Cmd Rej: Init-sys already in progress at another terminal**Commands Used: `init-sys`**

You entered the `init-sys` command at your terminal, and someone else has entered the `init-sys` command already at another terminal, and it has started processing. When the `init-sys` command is entered, another `init-sys` command cannot be in progress on another port.

Recovery

Wait until the system is done re-initializing, then re-enter the `init-sys` command that generated this error message.

E2269 Cmd Rej: Unable to communicate with card at location**Commands Used: `disp-tbl`, `init-imt-gpl`, `set-lba`, `set-tbl`**

The command you keyed in failed to have its desired effect on the card. The reason may be a keyboarding error or a hardware error.

Recovery

1. Re-enter the command that generated this error message specifying the correct `loc` parameter.
2. If this error message appears again, perform the following:
 - Press the **F-11** function key on the terminal, to toggle it to its alternate mode, and re-enter the command.
 - Investigate hardware factors including the LAN, the card, and the terminal.

Call your Customer Care Center if this error message appears again.

E2270 Cmd Rej: Card does not exist or is not an LPE**Commands Used: `init-card`**

The card specified by the `loc` parameter cannot be found in the database or is not allowed by this command. All cards except HMUX, TDM, and the MDAL can be initialized by this command.

Recovery

1. Display the cards in the database. Enter the **rtrv-card** command.
 2. Re-enter the **init-card** command specifying a card location that is not an HMUX, TDM, or MDAL card.
-

E2271 Cmd Rej: Either LOC or APPL (not both) must be specified**Commands Used: init-card**

You cannot specify both the **loc** and **appl** parameters. Both of these parameters are optional, but either the **loc** or **appl** parameter, but not both parameters, must be specified in the command.

Recovery

Re-enter the **init-card** command specifying either the **loc** or the **appl** parameters, but not both.

E2272 Cmd Rej: Invalid GPL type for this command**Commands Used: alw-card, init-card, init-imt-gpl, rst-card**

You specified an invalid **code** parameter or an invalid **appl** parameter. If the **serial** parameter is specified, the value specified for the **appl** parameter must be one of the following: **atmansi**, **ccs7itu**, **gls**, **sccp**, **ss7ansi**, **ss7gx25**, **stplan**, **emdc**, or **all**.

Recovery - alw-card, init-imt-gpl, rst-card

Re-enter the command that generated this error message specifying the correct **code** parameter.

Call your Customer Care Center if this error message appears again.

Recovery - init-card

Re-enter the command that generated this error message specifying the correct **appl** parameter.

Call your Customer Care Center if this error message appears again.

E2273 Cmd Rej: Seconds out of range

Commands Used: `act-lbp`, `rtrv-log`, `rtrv-seculog`

You specified an invalid **time** parameter specification.

Recovery `act-lbp`

You specified an out of range value for the seconds component (**ss**) of the **time** parameter. Specify **time** in the **hhmmss** format. The range for (**ss**) is **00-59**. The hour (**hh**) component of time is handled by the parser.

Re-enter the command specifying the value for the seconds from **00-59**.

Recovery - `rtrv-log`, `rtrv-seculog`

You specified an out of range value for the seconds component (**ss**) of the **stime** and **etime** parameter combination that is not valid. Using the 24-hour clock, you specify the time in the form of **hhmmss**, where (**hh**) is the hour, (**mm**) is the minutes, and (**ss**) is the seconds. The range of valid values for the seconds component is **00-59**.

Re-enter the command specifying the value for the seconds from **00-59**.

E2274 Cmd Rej: TT must be specified when enttype=tt

Commands Used: `rept-meas`

You specified the **enttype=tt** parameter without specifying the **tt** parameter, as required. The value for the **tt** parameter, which specifies the specific translation type to be reported, must be a numeric value from **0** to **255**.

Recovery

Re-enter the command specifying the **tt** parameter.

E2275 Cmd Rej: Day-to-hour measurement data not yet collected

Commands Used: `rept-ftp-meas`, `rept-meas`

The time that the command was entered to specify a measurement report for day-to-hour measurements (`type=avldth` or `type=mtcdth`) was between midnight (00:00) and 59 minutes past midnight (00:59). Day-to-hour measurement collection starts at midnight and are updated on an hourly basis. A day-to-hour measurement report cannot be generated before the first hour of measurements have been collected.

Recovery

Wait until after 1:00 AM (01:00) and re-enter the command that generated this error message.

E2276 Cmd Rej: Day-to-hour measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered during routine collection with either the (`type=avldth` or `type=mtcdth`) parameter.

Recovery

Re-enter the command after collection is complete. (The prior period is no longer accessible).

E2277 Cmd Rej: Daily measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered with either the (`type=avld` or `type=mtcd`) parameter during routine collection.

Recovery

Re-enter the command specifying either the (`type=avld` or `type=mtcd`) parameter after routine collection is complete.

E2278 Cmd Rej: 30-minute measurement collection in progress

Commands Used: `chg-ctrl-feat`, `chg-measopts`, `rept-ftp-meas`,
`rept-meas`

You entered the `chg-ctrl-feat` command to turn on the 15 Minute Measurements feature while a 30-minute measurement collection was already in progress.

OR

The `rept-meas` command was entered with either the `type=systot`, `type=comp`, or `type=avl` parameter during routine collection.

OR

The `rept-ftp-meas` command was entered with either the `type=systot`, `type=comp`, `type=gtwy`, or `type=avl` parameter during routine collection.

Recovery

To get a report before routine collection started, do one of the following actions:

- Enter the command specifying the `period=last` parameter.

OR

- Enter the command without specifying the `period` parameter.

OR

- Re-enter the command after the 30-minute measurement collection is complete. (The prior period is no longer accessible).
-

E2279 Cmd Rej: 5-minute measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered specifying the `type=nm` parameter during routine collection.

Recovery

Re-enter the command after the 15-minute measurement collection is complete. (The prior period is no longer accessible).

E2280 Cmd Rej: Invalid PERIOD for this TYPE or ENTTYPE

Commands Used: `rept-ftp-meas`, `rept-meas`

This error message is output when the **period** parameter is specified with a report type (**type**) parameter that is not allowed. The permissible combinations for **rept-meas** are listed in Table 2-7. An X in a cell indicates that the parameter is valid for the report type shown.

Table 2-7. Valid **type/period** Parameters for the **rept-meas** Command

Period Value	Report Type (type=) parameter											
	avl	avld	avldth	comp	gtwy	mtcd	mtcdth	mtch	mtcs	nm	rbase	systot
last	X	X	X	X	X	X	X	X		X		X
specific	X		X	X	X			X				X
active	X			X	X				X	X		
all	X		X									

The permissible combinations for **rept-ftp-meas** are listed in Table 2-8. An X in a cell indicates that the parameter is valid for the report type shown.

Table 2-8. Valid **type/period** Parameters for the **rept-ftp-meas** Command

Period Value	Report Type (type=) parameter											
	avl	avld	avldth	comp	gtwy	mtcd	mtcdth	mtch	mtcs	nm	rbase	systot
last	X	X	X	X	X	X	X	X		X		X
specific	X			X	X	X		X				X
active									X		X	

Recovery

Re-enter the command, specifying the compatible **type** and **period** parameters.

E2281 Cmd Rej: Invalid ENTTYPE for this TYPE

Commands Used: `rept-ftp-meas`, `rept-meas`

You specified an invalid combination of the **type** (report type) and **enttype** (entity type) parameters. For the `rept-meas` command, valid **type** (report type) and **enttype** (entity type) combinations are listed in Table 2-9. For the `rept-ftp-meas` command, see Table 2-10. An X in a table cell indicates that the parameter is valid for the report type shown.

Recovery

Re-enter the command, specifying the compatible **type** and **enttype** parameters.

Table 2-9. Valid **type/enttype** Parameters for the `rept-meas` Command

Entity Type (enttype) Value	Report Types (type=) parameter											
	systot	comp	mtcd	mtcdth	mtch	mtcs	nm	avl	avld	avldth	gtwy	rbase
stp	X		X	X			X				X	X
link		X	X	X		X	X	X	X	X		X
lnkset		X	X	X		X	X				X	X
lnp			X		X							
tt	X											
stplan	X		X	X				X				
origni											X	
origninc											X	
lsdestni											X	
lsonigni											X	
lsonismt											X	
np			X		X							
mapscrn			X		X							

Table 2-10. Valid **type/enttype** Parameters for the **rept-ftp-meas** Command

Entity Type (enttype) Value	Report Types (type=) parameter											
	systot	comp	mtcd	mtcdth	mtch	mtcs	nm	avl	avld	avldth	gtwy	rbase
stp	X		X	X			X				X	X
link		X	X	X		X	X	X	X	X		X
lnkset		X	X	X		X	X				X	X
lnp			X		X							
tt	X											
stplan	X		X	X				X				
origni											X	
origninc											X	
lsdestni											X	
lsorigni											X	
lsonismt											X	
np			X		X							
mapscrn			X		X							
eir			X		X							

E2283 Cmd Rej: QH, HH, or DAY cannot be specified when PERIOD=LAST

Commands Used: **rept-ftp-meas**, **rept-meas**

You specified the **hh**, **qh**, or the **day** parameter with the **period=last** parameter.

Recovery

Perform one of the following:

- Re-enter the command specifying the **period** parameter with values **last**, **active**, or **all**, without specifying the **hh**, **qh**, or the **day** parameter.

OR

- Re-enter the command specifying the **period=specific** and the **hh**, **qh**, or the **day** parameter.
-

E2284 Cmd Rej: QH, HH, or DAY cannot be specified when PERIOD=ACTIVE

Commands Used: `rept-ftp-meas`, `rept-meas`

You specified the **hh**, **qh**, or the **day** parameter with the **period=active** parameter.

Recovery

Perform one of the following:

- Re-enter the command specifying the **period** parameter with values **last**, **active**, or **all**, without specifying the **hh**, **qh**, or the **day** parameter.

OR

- Re-enter the command specifying the **period=specific** and the **hh**, **qh**, or the **day** parameters.
-

E2285 Cmd Rej: QH, HH, or DAY cannot be specified when PERIOD=ALL

Commands Used: `rept-meas`

You specified the **hh**, **qh**, or the **day** parameter with the **period=all** parameter.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **period** parameter with values **last**, **active**, or **all** without specifying the **hh**, **qh**, or the **day** parameter.
- OR
- Re-enter the **rept-meas** command specifying the **period=specific** and the **hh**, **qh**, or the **day** parameters.
-

E2286 Cmd Rej: QH or HH must be specified when PERIOD=SPECIFIC

Commands Used: **rept-ftp-meas**, **rept-meas**

You specified the **period=specific** parameter, and the **hh** or **qh** parameter was not specified.

Recovery

Re-enter the command specifying the **period=specific** parameter, and the **hh** or **qh** parameters.

E2287 Cmd Rej: ACTIVE not available for type-enttype combination

Commands Used: **rept-meas**

You specified the **period=active** parameter with an incompatible parameter combination. The **period=active** parameter cannot be used with the **enttype=stp** and **enttype=tt** parameters. The **period=active** parameter cannot be used with the **type=gtwy** parameter if the value for the **enttype** parameter is **lsorigni**, **lsdestni**, **origni**, or **origininc**.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **period=active** parameter with an acceptable parameter combination.
- OR
- Re-enter the **rept-meas** command specifying either **last** or **specific** for the **period** parameter.
-

E2288 Cmd Rej: Either LSN or LOC and LINK must be specified

Commands Used: rept-meas

You specified the link entity **type**, and the **lsn** parameter or the **loc** and **port/link** parameters were not specified.

Recovery

Re-enter the **rept-meas** command specifying the **lsn** parameter or the **loc** and **port/link** parameters.

E2289 Cmd Rej: LOC and LINK must be specified when PERIOD=ALL

Commands Used: rept-meas

You specified the **period=all** parameter with the report type **avl**, and either the **loc**, **port/link**, or **both** parameters were not specified.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **period=all** parameter and the **loc** and **port/link** parameters.
- OR
- Re-enter the **rept-meas** command specifying the values **last**, **active**, or **specific** for the **period** parameter, with the **loc** and **port/link** parameters optional.
-

E2290 Cmd Rej: Hourly measurement collection in progress

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered with either the `type=avldth`, `type=ntcdth`, or `type=mtch` parameter during routine collection.

Recovery

Re-enter the command after collection is complete. (The prior period is no longer accessible).

E2291 Cmd Rej: PERIOD must be 1 hour boundary for report type

Commands Used: `rept-ftp-meas`, `rept-meas`

You set the `period` parameter to **specific**, and either the `hh` parameter with final two digits of **30** or the `qh` parameter with final two digits of **15**, **30**, or **45**. The type of report you selected, however, requires that you set the final two digits of the `hh` or `qh` parameter to **00**. Day-to-hour measurement collection starts at midnight and is updated on an hourly basis.

Recovery

Re-enter the command, with the `hh` parameter properly set. Acceptable values range from **0** to **2400**, in increments of **1** hour.

Call your Customer Care Center if this error message appears again.

E2292 Cmd Rej: Card does not exist or is not a LIM (LOC)

Commands Used: `act-slk`, `alw-slk`, `blk-slk`, `dact-slk`, `ent-slk`, `inh-slk`, `rept-meas`, `rtrv-slk`, `ublk-slk`, `unhb-slk`

The card specified by the `loc` parameter cannot be found in the database, or is not a LIM card.

Recovery

1. Enter the `rtrv-card` command to display the cards in the database.
 2. Re-enter the command specifying a card location shown in step 1 for which the TYPE field in the `rtrv-card` command output is **limatm**, **limds0**, **limocu**, **limv35**, **lime1**, **limt1**, or **limch**.
-

E2293 Cmd Rej: TRM parameter not valid for type-enttype combo

Commands Used: `rept-meas`

You selected a terminal ID (printer location) that was not compatible with the information being sought, as defined by the **type** and **enttype** parameters.

Recovery

Perform one of the following:

- Re-enter the `rept-meas` command that generated this error message, and change either the **enttype** or **type** parameters.

OR

- Re-enter the `rept-meas` command that generated this error message, and omit the **trm** parameter.

Call your Customer Care Center if this error message appears again.

E2294 Cmd Rej: LSN and LOC cannot be specified together

Commands Used: `rept-meas`

You specified both the **lsn** and **loc** parameters in the command.

Recovery

Re-enter the `rept-meas` command specifying either the **lsn** parameter or the **loc** and **port** parameters specified, but not both.

E2295 Cmd Rej: LSN and LINK parms cannot be specified together

Commands Used: `rept-meas`

You specified both the **lsn** and **port/link** parameters in the command.

Recovery

Re-enter the `rept-meas` command specifying either the **lsn** parameter or the **loc** and **port/link** parameters specified, but not both.

E2296 Cmd Rej: Both LOC and LINK must be specified

Commands Used: `rept-meas`, `rtrv-slk`

You entered one of the following commands:

For the `rept-meas` command, you cannot specify the `enttype=link` parameter without specifying either the `loc` or `port/link` (or both) parameters.

For the `rtrv-slk` command, you must specify either the `loc` or `port/link`, or both parameters.

Recovery

Re-enter the command specifying the `loc` or `port/link` (or both) parameters.

E2297 Cmd Rej: TT parameter valid only when ENTTYPE=TT

Commands Used: `rept-meas`

You attempted to specify the `tt` parameter with a parameter other than `enttype=tt`. The `rept-meas:type=systot:enttype=tt` command is the only valid parameter combination for the `tt` parameter.

Recovery

Re-enter the `rept-meas` command as follows:

`rept-meas:type=systot:enttype=tt:tt=<0-255>` where `<0-255>` is the specific translation type to be reported.

E2298 Cmd Rej: LOC parameter not valid for this ENTTYPE

Commands Used: `rept-meas`

You specified the `loc` parameter, but the `enttype` specified was not valid.

Recovery

1. Review the specified parameters for this ENTTYPE in the *Commands Manual*.
2. Perform one of the following:
 - Re-enter the `rept-meas` command specifying the `enttype` from the previous attempt without specifying the `loc` parameter.

OR

- Re-enter the **rept-meas** command specifying **enttype=link** and include the **loc** and **port** parameters.

OR

- Re-enter the **rept-meas** command specifying **enttype=stplan** and include the **loc** parameter.
-

E2299 Cmd Rej: LINK parameter valid only when ENTTYPE=LINK

Commands Used: **rept-meas**

If the **port/link** parameter is specified, the **enttype** must be equal to **link**.

Recovery

Perform one of the following:

- Re-enter the **rept-meas** command specifying the **port/link** parameter and the **enttype=link**.

OR

- Re-enter the **rept-meas** command without specifying the **port/link** parameters.
-

E2300 Cmd Rej: LSN must be specified

Commands Used: **dlt-rtx**, **rept-meas**

You specified an entity type (**enttype=lnkset**, **lsdestni**, **lsorigni**, or **lsonismt**), but did not specify the **lsn** parameter.

For the **dlt-rtx** command, you must specify an **lsn** if **all** is not specified.

Recovery

Re-enter the command specifying the **lsn** parameter.

E2301 Cmd Rej: LSN parameter not valid for type-enttype combination

Commands Used: `rept-meas`

You specified the **lsn** parameter with an invalid **type/enttype** parameter combination. You cannot specify the **lsn** parameter with the following parameters:

enttype=stp/tt/stplan/origni/origninc/lnp/np/mapscrn or
type=systot.

Recovery

Perform one of the following:

- Re-enter the command specifying the **type=systot** parameter, without specifying the **lsn** parameter.
- OR
- Re-enter the command specifying any other valid combination of **type** and **enttype** parameters with the **lsn** parameter.
-

E2302 Cmd Rej: PERIOD must be 1/2 hour boundary

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered with the **period=specific** and **hh** parameters, and values for the minutes portion the **hh** parameter were not **00** or **30**. The value of the **hh** parameter is in the form of **HHMM**, where **HH** is the hour, **MM** is the minutes. The hour is based on a 24-hour clock (**00-24**). The valid values for the minutes are **00** and **30**. The values **00** or **30** are the only values allowed for the minutes portion of the **hh** parameter.

Recovery

Re-enter the command specifying the **period=specific** and **hh** parameters, and make sure that the values for the minutes portion of the **hh** parameter are either **00** or **30**.

E2303 Cmd Rej: Unknown LSN

Commands Used: `rept-meas`, `rept-stat-iptps`

The linkset name (**lsn**) could not be found.

Recovery

1. Display the linksets in the database. Enter the **rtrv-ls** command.
 2. Re-enter the command specifying one of the linkset names from step 1.
-

E2304 Cmd Rej: Invalid TYPE

Commands Used: **rept-meas**, **rept-stat-lnp**

The following Recovery procedures list the appropriate remedial action to take for each command that generates this error message.

Recovery - rept-meas

You entered an invalid combination of the **type** (report type) and **enttype** (entity type) parameters.

Refer to the command in the *Commands Manual* for information on the correct combinations of values and re-enter the **rept-meas** command.

Recovery - rept-stat-lnp

You specified a value other than **sccp-all** for the **card** parameter. For the **rept-stat-lnp** command, if you specify the **card** parameter, you must also specify **sccp-all**.

Re-enter the command **rept-stat-lnp:card=sccp-all**.

E2305 Cmd Rej: On demand report currently being printed

Commands Used: **rept-ftp-meas**, **rept-meas**

The system is currently printing the on-demand report specified in the command that generated this error message. An on-demand report cannot be specified in the **rept-meas** or **rept-ftp-meas** command while the system is printing that same on-demand report.

Recovery

Perform one of the following:

- Re-enter the command specifying another type of on-demand measurements report.
- OR
- Wait until the on-demand measurements report specified in the command that generated this error message has finished printing, then re-enter the command that generated this error message.
- OR
- Wait until the on-demand measurements report specified in the command that generated this error message has finished printing, then re-enter the command that generated this error message.
-

E2306 Cmd Rej: NZO is not valid for this TYPE

Commands Used: `rept-meas`

The **nzo** parameter was specified with report type **systot**, **comp**, **mtcd**, **mtcdth**, **mtch**, **mtcs**, **nm**, **gtwy**, or **rbase**. The **nzo** parameter can be specified only with report types **avl**, **avld**, and **avldth**.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the report types **avl**, **avld**, or **avldth** and the **nzo** parameter.
- OR
- Re-enter the command specifying any of the following the report types: **systot**, **comp**, **mtcd**, **mtcdth**, **mtch**, **mtcs**, **nm**, **gtwy**, or **rbase**, without specifying the **nzo** parameter.
-

E2307 Cmd Rej: QH or HH is not valid for this TYPE

Commands Used: `rept-ftp-meas`, `rept-meas`

The **hh** or **qh** parameter was specified for the report types **mtcd** and **nm**.

The **hh** parameter must specify a half-hourly boundary (the end of the requested half-hour for the report) for valid report types (**mtcd** and **nm** are excluded).

The **qh** parameter must specify a quarter-hourly boundary (the end of the requested quarter-hour for the report) for valid report types (**avld**, **mtcd**, **nm**, **rbase**, and **mtcs** are excluded).

Recovery

Re-enter the command without specifying the **hh** or **qh** parameter.

E2309 Cmd Rej: NI required

Commands Used: **rept-meas**

You omitted the required **ni** parameter.

Recovery

Re-enter the **rept-meas** command that generated this error message specifying the correct **ni** parameter value.

Call your Customer Care Center if this error message appears again.

E2310 Cmd Rej: File already exists

You attempted to load a file with a name that matches a file that is already in the database.

Recovery

Re-enter the command that generated this error message specifying the correct file name.

Call your Customer Care Center if this error message appears again.

E2312 Cmd Rej: Invalid SCSI device syntax

Commands Used: **disp-disk**

You either entered the wrong SCSI syntax, or had a hardware failure.

Recovery

Re-enter the **disp-disk** command that generated this error message specifying the correct SCSI syntax.

Call your Customer Care Center if this error message appears again.

E2314 Cmd Rej: Invalid filename entered

Commands Used: **chg-tbl**, **copy-fta**

You entered this command specifying an invalid filename.

Recovery

Re-enter the command that generated this error message specifying the correct filename.

Call your Customer Care Center if this error message appears again.

E2316 Cmd Rej: Class name is not an existing command class name

Commands Used: **chg-cmdclass**, **rtrv-cmd**, **rtrv-cmdclass**

The argument specified by the CLASS parameter must be a valid configurable or non-configurable command class name.

Recovery

1. Display a list of valid command class names. Enter the **rtrv-cmdclass** command.
2. Re-enter the command specifying a valid configurable or non-configurable command class name.

Call your Customer Care Center if this error message appears again.

E2317 Cmd Rej: Invalid table Id

Commands Used: **chg-tbl**

You entered an invalid value for the **id** parameter.

Recovery

Re-enter the **chg-tb1** command that generated this error message specifying the correct **id** parameter value.

Call your Customer Care Center if this error message appears again.

E2318 Cmd Rej: Invalid file length

Commands Used: chg-tb1

You entered an invalid value for the **filelength** parameter.

Recovery

Re-enter the **chg-tb1** command that generated this error message specifying the correct **filelength** parameter value.

Call your Customer Care Center if this error message appears again.

E2319 Cmd Rej: New class name cannot be the same as an existing class name

Commands Used: chg-cmdclass

The new command class name cannot be the duplicate of an existing configurable or non-configurable command class name. You entered this command specifying the same name as an existing command class name. These names cannot be the same.

Recovery

1. Display a list of valid command class names. Enter the **rtrv-cmdclass** command.
2. Re-enter the **chg-cmdclass** command specifying a valid command class name that is **not** on the list.

Call your Customer Care Center if this error message appears again.

E2320 Cmd Rej: Telnet terminal TYPE can only be set to TELNET or NONE

Commands Used: chg-trm

You must specify **type=telnet**, **emsalm**, or **none** for terminal numbers in the range from **17** to **40**. When a terminal number is in the range from **17** to **40**, the communication parameters are rejected.

You may also specify **type=emsalm** for terminal numbers from **1** to **16**.

Recovery

Re-enter the **chg-trm** command specifying the correct the **type** parameter.

E2321 Cmd Rej: Communication Settings are not allowed on TELNET terminals

Commands Used: **chg-trm**

Communications parameters are invalid for non-serial terminals, which are any terminal number **17** or above. Communications settings are not applicable when **type=telnet**.

Recovery

Re-enter the **chg-trm** command for the appropriate parameter combination:

- If the terminal type is **telnet**, the terminal number must be **17** or above, and you cannot specify communication settings.

OR

- If you intend to use communications settings, you must specify a terminal number in the range from **1** to **16**, and cannot specify **type=telnet**.
-

E2322 Cmd Rej: Alias defined as a destination point code

Commands Used: **chg-dstn**, **ent-dstn**, **rtrv-dstn**

The value specified for the alias parameter already exists as a destination point code. These commands do not allow an alias point code to be the same as a destination point code.

Recovery

1. Display all the destination point codes and alias point codes in the database. Enter the **rtrv-dstn** command specifying no parameters. The destination point codes are shown in the DPCA, DPCI, and DPCN fields of the output. The alias point codes are shown in the ALIASA, ALIASI, and ALIASN fields of the output.

2. For the **ent-dstn** and **chg-dstn** commands, enter the **rtrv-sid** command to verify the site point codes and capability point codes in the system. The site point codes are shown in the PCA, PCI, and PCN fields of the output. The capability point codes are shown in the CPCA, CPCI, CPCN fields of the output.
 3. Re-enter the command specifying a point code that does not match the site point code or capability point code, and that does not match any destination point codes or alias point codes.
-

E2323 Cmd Rej: Terminals 1-16 cannot be set to TYPE=TELNET

Commands Used: **chg-trm**

You cannot specify terminals **1** to **16** as **type=telnet**. Only terminals IDs **17** and above can be TELNET terminals.

Recovery

Re-enter the **chg-trm** command for the appropriate parameter combination. If the terminal type must be **telnet**, you must specify a terminal ID number **17** or above. If you are using terminal IDs **1** to **16**, the type cannot be **telnet**.

E2324 Cmd Rej: Alias not defined

Commands Used: **dlt-tt**, **rtrv-tt**

The specified alias cannot be found. The following Recovery procedures list by command the remedial action to take.

Recovery dlt-tt

1. Display the aliases and translation types. Enter the **rtrv-tt** command.
2. Re-enter the **dlt-tt** command specifying one of the aliases from step 1.

NOTE: To delete an alias, both the alias and the translation type must be specified, and both must already exist in the database for the specified network type.

Recovery - rtrv-tt

Perform one of the following actions:

- Verify that the **alias** has been entered correctly and re-enter the command.
OR
 - Enter the **rtrv-tt** command without specifying any parameters.
-

E2325 Cmd Rej: Alias type matches DPC type

Commands Used: chg-dstn, ent-dstn

The command was entered with a destination point code of one type and an alias point code of the same type. For example, if the **dpca** parameter was specified, then to generate this error message, the **aliasa** parameter was specified with this command. Alias point codes must be of a different point code type than the destination point code.

Recovery

Re-enter the command specifying the following destination point code and alias point code parameter combinations.

dpc/dpca aliasi, aliasn
dpci aliasa, aliasn
dpcn aliasa, aliasi

E2326 Cmd Rej: APC not defined as destination point code

Commands Used: chg-ls, ent-ls

The specified adjacent point code could not be found in the Destination Point Code table. For an adjacent point code to be assigned to a linkset, it must be defined in the Destination Point Code table.

Recovery

1. Display all the destination point codes in the Destination Point Code table.
Enter the **rtrv-dstn** command.
2. Re-enter the command specifying a point code from the output in step 1.

OR

1. Add the specified point code to the Destination Point Code table. Enter the **ent-dstn** command.
 2. Re-enter the command specifying the point code that generated this error message.
-

E2328 Cmd Rej: CLLI not defined in route table

Commands Used: **rtrv-dstn**, **rtrv-rte**

The command was entered with the **cli** parameter specified, and the value for the **cli** parameter was not found in the database. If the **cli** parameter is specified with these commands, the value for the **cli** parameter must be in the database.

Recovery

Re-enter the command specifying no parameters to display all routes (**rtrv-rte**) or all destination point codes (**rtrv-dstn**) and all the CLLI values for these routes and destination point codes in the database.

E2329 Cmd Rej: IPSM card not equipped

Commands Used: **chg-trm**

You specified a command that cannot be executed because the IPSM card is not equipped. Before the command you issued can be executed, the supporting IPSM card must be equipped.

Recovery

1. Display all the terminals. Enter the **rtrv-trm** command.
 2. With the output from step 1 as a guide, re-enter the **chg-trm** command for an IPSM card when you are certain it is equipped.
-

E2330 Cmd Rej: LSN must be provided with ALL=NO

Commands Used: **dlt-rte**

You specified the **all=no** parameter or you did not specify **all**, and the **lsn** parameter was not entered. If you use the **all=no** parameter, you must enter the **lsn** parameter.

Recovery

Re-enter the **dlt-rte** command specifying the **lsn** parameter.

E2331 Cmd Rej: Cannot specify LSN parameter with ALL=YES**Commands Used: dlt-rte**

You specified both the **lsn** and **all=yes** parameters. To delete all routes for a given route entry, the **all=yes** parameter must be used without an **lsn** value. To delete a route, you must use the **lsn** parameter.

Recovery

1. To delete all routes for a given route entry, re-enter the **dlt-rte** command specifying the **all=yes** parameter. Do not use the **lsn** parameter.
 2. To delete a route, re-enter the **dlt-rte** command specifying the **lsn** parameter. Do not use the **all=yes** parameter.
-

E2332 Cmd Rej: Point code defined as an alias**Commands Used: chg-ls, ent-dstn, ent-ls**

The value specified for the destination point code parameter already exists as an alias point code. This command does not allow a destination point code to be the same as an alias point code.

Recovery

1. Enter the **rtrv-dstn** command specifying no parameters to display all the destination point codes and alias point codes in the database. The destination point codes are shown in the DPCA, DPCI, DPCN, and DPCN24 fields of the output. The alias point codes are shown in the ALIASA, ALIASI, and ALIASN fields of the output.
 2. Enter the **rtrv-sid** command to verify the site point codes and capability point codes in the system. The site point codes are shown in the PCA, PCI, PCN, and PCN24 fields of the output. The capability point codes are shown in the CPCA, CPCI, CPCN, and CPCN24 fields of the output.
 3. Re-enter the command specifying a point code that does not match the site point code or capability point code, and does not match any destination point codes or alias point codes.
-

E2333 Cmd Rej: DPC is already being used

Commands Used: `ent-dstn`

The specified destination point code already exists in the database.

Recovery

1. Display all destination point codes in the database. Enter the `rtrv-dstn` command.
 2. Display the point code of this EAGLE 5 ISS and its capability point code. Enter the `rtrv-sid` command.
 3. Re-enter the `ent-dstn` command specifying a point code that is not shown in the outputs of steps 1 and 2.
-

E2334 Cmd Rej: DPC defined as linkset APC

Commands Used: `dlt-dstn`

The specified destination point code is defined as a linkset adjacent point code in the database. The destination point code to be deleted cannot be defined as a linkset adjacent point code.

Recovery

1. Enter the `rtrv-ls` to display all linkset adjacent point codes in the database and to verify the specified point code is a linkset adjacent point code.
 2. Enter the `dlt-ls` command specifying the point code specified in the command that generated this error message.
 3. Re-enter the `dlt-dstn` command that generated this error message.
-

E2335 Cmd Rej: CLI is not identical to that of matching Destination

Commands Used: `chg-ls`, `ent-ls`, `rtrv-dstn`

You assigned an invalid value to the `cli` parameter. The `cli` or the destination being entered must match the `cli` of the current site.

Recovery

Re-enter the command that generated this error message specifying the correct `cli` parameter value.

Call your Customer Care Center if this error message appears again.

E2336 Cmd Rej: GWSA, GWSM, GWSD are invalid without SCRSET specified

Commands Used: `chg-ls`, `ent-ls`

There is currently no gateway screening screen set assigned to this linkset.

Recovery

Re-enter the command specifying the `scrn` parameter to apply a screen set and make the parameters `gwsa`, `gwsn`, or `gwsd` valid.

E2337 Cmd Rej: If GWSA=OFF then GWSD must also be OFF

Commands Used: `chg-ls`, `ent-ls`

You attempted to enter or change a linkset that has gateway screening turned off (`gwsa=off`), and you specified the `gwsd=on` parameter. Gateway screening MSU discard must be turned off (`gwsd=off`) for a linkset if gateway screening is turned off (`gwsa=off`) for that linkset.

Recovery

Re-enter the command specifying the `gwsa=off` and `gwsd=off` parameters.

E2338 Cmd Rej: Invalid CLLI

Commands Used: `ent-dstn`, `rtrv-dstn`

You assigned an invalid value to the `cli` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `cli` parameter value.

Call your Customer Care Center if this error message appears again.

E2339 Cmd Rej: PC/CLLI does not match current PC/CLLI of the STP

Commands Used: `rtrv-dstn`, `ent-dstn`

You assigned an invalid value to the `clli` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `clli` parameter value.

Call your Customer Care Center if this error message appears again.

E2340 Cmd Rej: Invalid point code

Commands Used: `chg-dstn`, `chg-rte`, `chg-sid`, `chg-x25-dstn`,
`dlt-dstn`, `dlt-rte`, `ent-dstn`, `ent-rte`, `ent-x25-dstn`,
`rtrv-dstn`, `rtrv-rte`, `rtrv-sid`

The specified point code either could not be found in the database or was not in the format required by this command. The point code **0-0-0** is not allowed. The following Recovery procedures list by command the remedial action to take for this error message.

**Recovery - `chg-dstn`, `chg-rte`, `chg-x25-dstn`, `dlt-rte`, `ent-rte`, `ent-x25-dstn`,
`rtrv-dstn`, `rtrv-rte`**

1. Display the Destination Point Code table. Enter the `rtrv-dstn` command specifying no parameters.
 2. Re-enter the command specifying a point code shown in the output of step 1.
-

Recovery - `chg-sid`

1. Display the Capability Point Code table. Enter the `rtrv-sid` command specifying no parameters.
 2. Re-enter the `chg-sid` command specifying a valid point code that is in the Capability Point Code table and, does not match the EAGLE 5 ISS point code and destination point code.
-

Recovery - **dlt-dstn**

1. Display the point codes in the Destination Point Code table. Enter the **rtrv-dstn** command specifying no parameters.
 2. Display the linksets in the database. Enter the **rtrv-ls** command.
 3. Re-enter the **dlt-dstn** command specifying a point code that is in the Destination Point Code table (output of step 1) and that is not shown in the output of step 2.
-

Recovery - **ent-dstn**

1. Display the destination point codes in the database. Enter the **rtrv-dstn** command specifying no parameters.
 2. Display the point code and the capability point code of the EAGLE 5 ISS. Enter the **rtrv-sid** command.
 3. Re-enter the **ent-dstn** command specifying a point code that is not in the Destination Point Code table (output of step 1), that is not shown in the output of step 2, and that follows the guidelines for point codes for the **ent-dstn** command description in the *Commands Manual*.
-

E2341 Cmd Rej: May not change adjacent point code type

Commands Used: **chg-ls**

The command was entered with an adjacent point code (**apca**, **apci**, or **apcn**) whose point code type was different from the point code type of the adjacent point code currently specified for that linkset. The new adjacent point code must be of the same point code type as the current adjacent point code of the linkset.

Recovery

1. Display the linkset used in the command that generated this error message. Enter the **rtrv-ls** command specifying the linkset name (**lsn**) specified in the command that generated this error message.
 - If the adjacent point code is an ANSI point code, the adjacent point code of the linkset is shown in the APCA field of the **rtrv-ls** output.
 - If the adjacent point code is an ITU-I point code, the adjacent point code of the linkset is shown in the APCI field of the **rtrv-ls** output.
 - If the adjacent point code is an ITU-N point code, the adjacent point code of the linkset is shown in the APCN field of the **rtrv-ls** output.

2. Display the point codes in the Destination Point Code table with the **rtrv-dstn** command. The ANSI destination point codes are shown in the DPCA field; the ITU-I destination point codes are shown in the DPCI field; the ITU-N destination point codes are shown in the DPCN field, and the 24-bit ITU-N destination point codes are shown in the DPCN24 field of the **rtrv-dstn** output.
 3. Re-enter the **chg-ls** command specifying a destination point code, from step 2, whose point code type matches the point code type of the adjacent point code shown in step 1.
-

E2342 Cmd Rej: Links assigned to linkset

Commands Used: dlt-ls

An attempt was made to delete a linkset that still has assigned signaling links.

Recovery

1. Display the current linkset configuration using the **rtrv-ls** command, specifying the linkset name.
 2. Deactivate all links in the linkset using the **dact-slk** command.
 3. Confirm the link status is Out-of-Service - Maintenance Disabled (OOS-MT-DSBLD) using the **rept-stat-ls** command, specifying the linkset name.
 4. Delete all links in the associated linkset, using the **dlt-slk** command.
 5. Re-enter the **dlt-ls** command that generated this error message.
-

E2343 Cmd Rej: Linkset APC/SAPC is already being used

Commands Used: chg-ls, ent-ls

The specified adjacent point code (**apc**) or secondary adjacent point code (**sapc**) is already assigned to another linkset. Only one linkset can be assigned to an **apc** or **sapc**.

Recovery

1. Display the linksets in the database. Enter the **rtrv-ls** command.
 2. Re-enter the command specifying a value for the **apc** or **sapc** that is not shown in the output of step 1.
-

E2345 Cmd Rej: Linkset already defined

Commands Used: `chg-ls`, `ent-ls`

You cannot add a linkset that is already in the database. The specified linkset is already in the database.

Recovery

1. Display the linksets in the database. Enter the `rtrv-ls` command.
 2. Re-enter the command specifying a linkset name that is not shown in step 1.
-

E2346 Cmd Rej: Linkset not defined

Commands Used: `chg-ls`, `chg-rte`, `chg-rtx`, `dlt-ls`, `dlt-rtx`, `ent-rte`, `ent-rtx`, `ent-slk`, `rtrv-gtwy-acthresh`, `rtrv-ls`, `rtrv-rte`, `rtrv-rtx`, `set-gtwy-acthresh`

The specified linkset cannot be found in the STP active database.

For the `rtrv-rte` command, all link sets must be defined in the route set.

For the `chg-rte` command, if an incoming link set name (`ilsn`) or new link set name (`nl sn`) is specified in the command, that target link set name specified must exist in the STP active LINK SET database.

For the `chg/dlt/ent/rtrv-rtx` commands, the specified `lsn/ilsn` must exist in the Route table.

Recovery

1. Display the linksets in the database. Enter the `rtrv-ls` command specifying no parameters.
 2. Re-enter the command specifying a linkset name from the output in step 1.
-

E2347 Cmd Rej: Linkset table full

Commands Used: `ent-ls`, `chg-ls`

The Linkset table contains the maximum **1024** linksets and an attempt was made to add another linkset. To add the new linkset, you can either change an existing linkset, or delete an existing linkset and add the new one.

Recovery

1. Display the linksets in the database. Enter the **rtrv-ls** command.
2. To change an existing linkset, enter the **chg-ls** command specifying the new linkset information.

OR

1. Delete an existing route. Enter the **dlt-ls** command.
 2. Re-enter the command that generated this error message.
-

E2348 Cmd Rej: Linkset referenced by route

Commands Used: dlt-ls

You tried to delete a linkset that is referenced by a routeset.

Recovery

1. Delete the routeset reference. Enter the **dlt-rte** command specifying the linkset name from the command that generated this error message.
 2. Re-enter the **dlt-ls** command that generated this error message.
-

E2349 Cmd Rej: Linkset Type used for cluster route cannot be A or E

Commands Used: ent-rte

When the destination address is a network cluster address, the linkset can only be a B, C, or D linkset.

Recovery

Re-enter the **ent-rte** command specifying a B, C, or D linkset.

E2350 Cmd Rej: At most two linksets can be assigned same cost

Commands Used: chg-rte, ent-rte

You tried to assign a cost value (**rc**) parameter to a linkset, when two other linksets already have that value assigned to them. A maximum of two linksets can have the same cost value.

Recovery

1. Display the routes and their cost values. Enter the **rtrv-rte** command.
 2. Re-enter the command specifying a value for the **rc** parameter that is not being used or is used by one linkset or less.
-

E2351 Cmd Rej: Linkset not assigned in route table

Commands Used: **chg-rte, dlt-rte, rtrv-rte**

The linkset referenced by the **lsn** parameter could not be found in the database. If the **lsn** parameter is specified, the linkset referenced by the **lsn** parameter must be defined as a route.

Recovery - chg-rte, dlt-rte

1. Display the routes in the Route table. Enter the **rtrv-rte** command without specifying the **lsn** parameter.
 2. Re-enter the command specifying an **lsn** value shown in the output of step 1.
-

Recovery - rtrv-rte

Re-enter the **rtrv-rte** command without specifying the **lsn** parameter.

E2352 Cmd Rej: Cannot perform change while telnet port in use

Commands Used: **chg-trm**

The specified terminal is already in use. The Telnet port cannot be removed from service (**rmv-trm**) when the **type, baud, prty, sb,** and **fc** parameters are being changed.

Recovery

Re-enter **chg-trm** command specifying a different Telnet port.

E2353 Cmd Rej: Routeset is full

Commands Used: `ent-dstn`, `ent-rte`

The specified routeset already has **six** routes in it. A routeset can contain up to **six** routes.

Recovery

Re-enter the command specifying a different routeset to add the route to.

OR

1. Delete a route from the routeset. Enter the `dlr-rte` command.
 2. Re-enter the command that generated this error message.
-

E2354 Cmd Rej: Routeset must be empty

Commands Used: `dlr-dstn`

You tried to delete the destination point code (DPC) from the database while there were routes in the database assigned to the DPC. A DPC cannot be deleted if there are any routes assigned to it.

Recovery

1. Display the routes assigned to the DPC. Enter the `rtrv-rte` command specifying the DPC that was used in the command that generated this error message.
 2. Delete these routes from the database. Enter the `dlr-rte` command.
 3. Re-enter the `dlr-dstn` command that generated this error message.
-

E2355 Cmd Rej: Linkset already assigned to route

Commands Used: `ent-rte`

The specified linkset is already in the specified route.

Recovery

1. Display the linksets in the route. Enter the `rtrv-rte` command specifying the specified route.

2. Display the linksets in the database. Enter the **rtrv-ls** command.
 3. Using the outputs of steps 1 and 2, re-enter the **ent-rte** command specifying a linkset that is in the database but is not assigned to the specified route.
-

E2356 Cmd Rej: Last route to DPC in use by GTT

Commands Used: **dlt-rte**

You cannot delete the last route to a destination point code because it is referenced by a global translation title (GTT).

Recovery

1. Perform one of the following:
 - Delete the GTT referencing the route's destination.
OR
 - Change the route used by the GTT to a route using a different destination.
OR
 - Add another route using the same destination.
 2. Re-enter the **dlt-rte** command that generated this error message.
-

E2357 Cmd Rej: Linkset is unequipped

Commands Used: **chg-rte, dlt-rte, ent-rte, rtrv-rte**

The specified linkset could not be found in the database.

Recovery

1. Display the linksets in the database. Enter the **rtrv-ls** command.
 2. Re-enter the command specifying a linkset from the output of step 1.
-

E2358 Cmd Rej: Routeset is empty

Commands Used: **dlt-rte**

The command was entered with the **all=yes** parameter, and the routeset contains no routes. If the **all=yes** parameter is specified, the routeset must have routes in it.

Recovery

1. Display the routes in the database. Enter the **rtrv-dstn** command.
 2. Re-enter the **dlt-rte** command specifying a destination point code (DPCA, DPCI, DPCN, or DPCN24 fields) shown in the output of step 1 that has routes assigned to it, along with the **all=yes** parameter.
-

E2359 Cmd Rej: Route table is full

Commands Used: **ent-dstn**, **chg-dstn**

The Destination Point Code table is full. You must delete a destination point code before another point code can be added to the Destination Point Code table.

Recovery

1. Display the Route table. Enter the **rtrv-dstn** command.
 2. Delete a destination point codes from the Route table. Enter the **dlt-dstn** command.
 3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2361 Cmd Rej: Screen set name not defined

Commands Used: **chg-ls**, **ent-ls**

The specified screen set name could not be found in the database.

Recovery

1. Verify that the screen set name was entered correctly and re-enter the command.
 2. If the screen set name was entered correctly and this error message appears again, display the screen sets in the database. Enter the **rtrv-scrset** command specifying no parameters.
 3. Re-enter the command specifying a screen set name from the output in step 2.
-

E2363 Cmd Rej: ITU point codes are not supported when DOMAIN=X25

Commands Used: **chg-dstn**, **ent-dstn**

You attempted to assign an ITU destination point code, but this is valid only in the SS7 domain. You had set the **domain** parameter to **x25**. The following Recovery procedures list by command the remedial action to take.

Recovery - ent-dstn

Perform one of the following:

- Re-enter the **ent-dstn** command, but set the **domain** parameter to **ss7**.
- OR
- Re-enter the **ent-dstn** command, but omit the **domain** parameter.
-

Recovery - chg-dstn

1. You cannot use the **chg-dstn** command to change the **domain** parameter. Therefore, delete this destination, using the **dlc-dstn** command.
2. Re-enter the destination using the **ent-dstn** command specifying the **domain** parameter equal to **ss7**.

OR

Re-enter the destination using the **ent-dstn** command without specifying the **domain** parameter.

E2364 Cmd Rej: TELNET cannot be specified unless the IPSM card is equipped

Commands Used: **rtrv-trm**

You specified a command that cannot be executed because the IPSM card is not equipped. Before the command you issued can be executed, the supporting IPSM card must be equipped.

Recovery

1. Display the cards that are defined in the database. Enter the **rtrv-card** command. Verify that the card you specified in the **loc** parameter is the correct IPSM card.
2. If you specified the correct card in the **loc** parameter, go to step 4.

3. If the desired card is not equipped, equip an IPSM card for use with the **ent-card:appl=ips** command.

Refer to the *Commands Manual* for details.

4. Re-enter the original **rtrv-trm** command.

Contact your Customer Care Center if this error message appears again.

E2365 Cmd Rej: TELNET Feature must be activated first

Commands Used: **alw-trm, inh-trm, rmv-trm, rst-trm**

You entered a terminal command for a terminal with **type=telnet**. However, the IP User Interface (Telnet) feature must be enabled and turned on before you can use this terminal command.

Recovery

1. Display the terminals and their types to confirm the terminal you want to address. Enter the **rtrv-trm** command.
2. Display the features that are controlled with feature access keys in the system. Enter the **rtrv-ctrl-feat** command.
3. Using step 2, verify the IP User Interface (Telnet) feature has been purchased and installed in your system. Contact your Customer Care Center for assistance.
4. If the Telnet feature has been purchased and installed in your system, use the output from step 2 to verify its status.

Refer to the *Database Administration Manual - System Management* for instructions on enabling and turning on the IP User Interface (Telnet) feature and any prerequisite features that must be turned on.

5. When the Telnet feature is turned on in the system, re-enter the command specifying the parameter that requires the Telnet feature to be on.

Call your Customer Care Center if this error recurs.

E2366 Cmd Rej: LOC must be specified

Commands Used: **inh-alm, rept-stat-card, unhb-alm**

The following Recovery procedures list by command the condition that generated the error message and the remedial action to take.

For the **rept-stat-card** command, if the **mode** parameter is specified, the **loc** parameter must also be specified.

Recovery - inh-alm, unhb-alm

You specified the **dev=card** or **dev=dlk** parameter, which both require that you also specify the **loc** parameter.

Perform one of the following:

- Re-enter the command that generated this error message specifying the **loc** parameter.
- OR
- Re-enter the command without specifying the **dev=card** or **dev=dlk** parameter.
-

Recovery - rept-stat-card

Perform one of the following:

- Re-enter the **rept-stat-card** command specifying both the **mode** and **loc** parameters.
- OR
- Re-enter the **rept-stat-card** command without specifying the **mode** parameter.
-

E2367 Cmd Rej: May not specify both LOC and STAT

Commands Used: **rept-stat-card**

The command was entered with a card location (**loc**) and the primary state filter (**stat**) parameters. This command does not allow this parameter combination. Either of these parameters can be entered with this command, but both of these parameters cannot be specified at the same time.

Recovery

Re-enter the **rept-stat-card** command specifying either the **loc** or **stat** parameters, but not both.

E2368 Cmd Rej: System busy - try again later

Commands Used: `act-flash`, `alw-card`, `alw-map-ss`, `alw-trm`, `blk-slk`, `canc-cmd` `clr-imt-stats`, `dact-slk`, `init-flash`, `inh-alm`, `inh-card`, `inh-map-ss`, `init-imt-gp1`, `init-mux`, `rept-imt-info`, `rept-imt-lvl1`, `rept-imt-lvl2`, `rept-stat-alm`, `rept-stat-card`, `rept-stat-clk`, `rept-stat-eroute`, `rept-stat-imt`, `rept-stat-lfs`, `rept-stat-meas`, `rept-stat-mps`, `rept-stat-ndc`, `rept-stat-sccp`, `rept-stat-slan`, `rept-stat-sys`, `rept-stat-trbl`, `rept-x25-meas`, `rmv-card`, `rmv-trm`, `rst-card`, `rst-trm`, `tst-imt`, `ublk-slk`, `unhb-alm`, `unhb-slk`

The following Recovery procedures list the remedial action to take for each command that generates this error message.

Recovery - `canc-cmd`

You issued the `canc-cmd:trm=` command on the same terminal that is running the command you want to cancel.

1. Verify the user and terminal number that has the command to be canceled.
Enter the `rept-stat-user` command.
 2. Perform one of the following:
 - Go to another terminal to issue `canc-cmd:trm=` command, or
 - OR
 - Enter the `canc-cmd` command without specifying the `trm` parameter.
-

Recovery - `rept-stat-trbl`

No other `rept-stat-xxxx` command may be in progress when this command is issued.

Wait for all `rept-stat-xxxx` commands to complete, then re-enter `rept-stat-trbl` command.

Recovery - All other commands that use this error

The following conditions may have generated this error:

Heavy disk activity (for example, database maintenance or measurement collection) prevented access to the system.

If the command you entered is an action command, the command cannot execute because another action command is in progress. An action command is a command used to effect changes to the state of entities within the system.

For more information on action commands, see the *Commands Manual*.

1. Wait for some of the disk activity to subside or for the action command to complete.
 2. Re-enter the command that generated this error message.
-

E2369 Cmd Rej: Partition specified invalid for target disk

Commands Used: `tst-disk`

You entered a command to test a disk partition that does not exist on the target disk. For example, partitions 3 and 4 do not exist on a 4 GB disk; it has only partitions 1 and 2.

OR

You entered a command and specified `partition=1, 2, 3, 4, or all` to test a disk which has been formatted (`format-disk` command) but does not yet contain a DOS directory structure (created with `copy-disk` command).

NOTE: The `partition=disk` parameter is accepted in this situation, as this tests the entire disk and does not care about individual partitions. The `partition=disk` parameter is used only by Tekelec for debug purposes.

Recovery

Re-enter the `tst-disk` command specifying a valid `partition` parameter value for the disk being tested.

OR

Re-enter the `tst-disk` command to test the disk.

Enter the `copy-disk` command to create the DOS directory structure of the target disk.

Refer to the *Database Administration Manual - System Management* for information about formatting and copying a TDM disk.

E2370 Cmd Rej: Terminal Id not entered

Commands Used: `rst-trm`

You cannot enter the reset terminal command without specifying the terminal id (`trm`) parameter. You must enter the `trm` parameter for this command to execute.

Recovery

Re-enter the **rst-trm** command specifying the **trm** parameter.

E2371 Cmd Rej: Force parameter required

Commands Used: **chg-db**, **inh-alm**, **inh-card**, **inh-trm**,
init-network, **rmv-card**, **set-uim-acthresh**

This error code occurs when inhibiting a card would result in the loss of service or the service is not presently active; you must specify the **force=yes** parameter to perform the command. The **force=yes** parameter serves as a safeguard to ensure your intent in issuing some commands. You must use the **force=yes** parameter to perform the operations described in Table 2-11.

Table 2-11. Operations Requiring **force=yes** Parameter

Command	You must specify the force=yes parameter if you are...
chg-db	Specifying the action=canceled parameter.
inh-alm	Trying to inhibit critical alarms.
inh-card	Trying to inhibit the only remaining MCPM or LIM card.
inh-trm	Trying to inhibit the last OAP port.
init-network	Trying to reset all network cards and override the required four card SS7ANSI or CCS7ITU configuration.
set-uim-acthresh	Trying to set the limit=0 parameter for a given interval. Specifying limit=0 turns off all occurrences of the specified UIM. Use this method of creating thresholds only if you are certain the correct UIM is specified.

Recovery

Refer to Table 2-11 for the operation that you want to perform, and enter the appropriate command specifying the **force=yes** parameter.

E2372 Cmd Rej: Terminal is not equipped

Commands Used: **rmv-trm**, **rst-trm**

The specified **trm** number has no terminal assigned to it.

Recovery

1. Enter the **rtrv-trm** command to display all the terminals.
 2. With the output from step 1 as a guide, re-enter the command specifying a **trm** number that has a terminal assigned to it.
-

E2373 Cmd Rej: Link is unequipped in the database

Commands Used: **act-cdl, act-lbp, act-slk, alw-slk, blk-slk, canc-slk, dact-cdl, dact-lbp, dlt-slk, inh-alm, inh-slk, rept-meas, rept-stat-cdl, rept-stat-lfs, rept-stat-slk, rept-stat-tstslk, tst-slk, unhb-alm, ublk-slk, unhb-slk**

You cannot specify a signaling link (**slk**) or data link (**dlk**) that is not provisioned in the database.

Recovery

1. Display the signaling links in the database. Enter the **rtrv-slk** command.
 2. Re-enter the command specifying a card location and port of a properly provisioned signaling link shown in the output of step 1.
-

E2374 Cmd Rej: SCCP not Configured

Commands Used: **alw-map-ss, inh-map-ss, rept-stat-mps, rept-stat-sccp, rept-stat-lnp**

No SCCP/VSCCP cards were found in the system. This command requires that the system have at least one SCCP/VSCCP card.

Recovery

1. Display the cards in the system. Enter the **rtrv-card** command.
SCCP cards are shown by the entries TSM in the TYPE field and SCCP in the APPL field.
VSCCP cards are shown by the entries DSM in the TYPE field and VSCCP in the APPL field.
2. If there are no SCCP or VSCCP cards in the system, no action is necessary.
3. If there are SCCP or VSCCP cards in the system, re-enter the command.

Call your Customer Care Center if this error message appears again.

E2375 Cmd Rej: Unknown command

Commands Used: **All commands**

The entered command is invalid.

Recovery

Re-enter the command.

If this error message appears again, refer to the specified command in the *Commands Manual*.

E2376 Cmd Rej: Specified LOC is invalid

Commands Used: **act-cdl, act-dlk, act-flash, act-lbp, act-lpo, act-slk, alw-card, alw-slk, blk-slk, canc-dlk, cancel-lpo, cancel-slk, chg-lbp, dact-cdl, dact-lbp, dact-slk, dlt-lbp, ent-lbp, inh-slk, init-flash, init-imt-gpl, pass, rept-stat-cdl, rept-stat-dlk, rept-stat-lfs, rept-stat-slk, rept-stat-tstslk, rept-x25-meas, rst-card, rtrv-lbp, rtrv-obit, rtrv-trbl, tst-dlk, tst-slk, ublk-slk, unhb-slk**

You assigned an invalid card location value to the **loc** parameter.

Recovery

1. Display the cards in the database. Enter the **rtrv-card** command.
2. Re-enter the command that generated this error message specifying the correct **loc** parameter value.

Call your Customer Care Center if this error message appears again.

E2377 Cmd Rej: No test link message is sent

Commands Used: **tst-slk**

You either entered this command while another action command was in progress, or you specified a card that is not a LIM card.

Recovery

1. Allow time for the other action command to complete and then re-enter the **tst-slk** command.
OR
 2. Verify the card in the specified location is a LIM card. Display the cards in the database. Enter the **rtrv-card** command. LIM cards are identified by the terms **limatm**, **limds0**, **limocu**, or **limv35** in the TYPE field.
 3. Re-enter the **tst-slk** command specifying a valid LIM card location.
-

E2378 Cmd Rej: The specified card cannot be inhibited

Commands Used: **inh-card**, **rmv-card**

The command specified a card that cannot be inhibited because it is a TDM or MDAL that cannot be inhibited. The only cards that can be inhibited with this command are as follows: TSM (not in location 1114 or 1116), DCM, DSM, ACM, or LIM (including E1/T1 MIM) cards). The card location specified in this command was either an OAM, TDM, MDAL, or HMUX card.

Recovery

1. Display the cards in the database. Enter the **rtrv-card** command. The card types are shown in the TYPE field in the output.
 2. Re-enter the command specifying a card location (**loc**) shown in the output of step 1, and that is not one of the following card types:
 - OAM - card locations **1113** and **1115** (GPSM-II card performs OAM f unction)
 - TDM - card location **1114** and **1116**
 - MDAL - card location **1117**
 - HMUX - card locations **9** and **10** in each shelf
-

E2379 Cmd Rej: Missing parameter

Commands Used: **chg-gta**, **chg-isupvar-attrib**, **ent-gta**, **ent-slk**, **rept-stat-slk**, **rtrv-isupvar-attrib**

For the **chg-gta** command:

- If the value of the **xlat** parameter is changed from **udts/disc** to **dpc**, **dpcngt**, or **dpcssn**, then **gta/egta** or **cgpc** or **opc** or **cgssn/ecgssn**, **pc/pca/pci/pcn/pcn24**, and **ri** must be specified.
- If the value of the **xlat** parameter is **udts/disc**, changing the **pc** or other fields requires the **xlat** parameter to be values other than **udts/disc**.

For the **ent-gta** command, the routing indicator (**ri**) and **pc/pca/pci/pcn/pcn24** parameters must be specified, if the value specified for the **xlat** parameter is **dpc**, **dpcngt**, **dpcssn**.

The **rept-stat-slk** command can be entered with either the **stat** parameter, or the **loc** and **port/link** parameters. The command that generated this error message was entered with either the **loc** or **port/link** parameters by themselves. If the **stat** parameter is specified, it must be specified by itself. If either the **loc** or **port/link** parameters is specified, the other parameter must be specified.

For the **ent-slk** command;

- If the **loc** parameter specifies an E1 card (**lime1**) or Channel card (**limch**), the timeslot (**ts**) parameter must also be specified.
- If the **loc** parameter specifies a Channel card (**limch**), the **e1loc** parameter must specify the E1 card location for the E1 interface that will service the Channel card timeslot.
- If the **loc** parameter specifies a Channel card (**limch**), the **t1loc** parameter must specify the E1/T1 MIM card location of the T1 interface that will service the Channel card timeslot.
- If the **loc** parameter specifies an E1/T1 MIM card used as a T1 card (**limt1**) or Channel card (**limch**), the timeslot (**ts**) parameter must also be specified.

Recovery

Re-enter the **rept-stat-slk** command specifying either the **stat** parameter, or the **loc** and **port** parameters.

OR

Re-enter the **ent-slk** command specifying the timeslot (**ts**) parameter for card type **lime1** or **limch**. If the **loc** parameter specifies a Channel card (**limch**), specify the **e1loc** parameter for the E1 card that has the E1 interface that will service the Channel card timeslot.

OR

Re-enter the **ent-slk** command specifying the timeslot (**ts**) parameter for card type **limt1** or **limch**. If the **loc** parameter specifies a Channel card (**limch**), specify the **t1loc** parameter for the E1/T1 MIM card that has the T1 interface that will service the Channel card timeslot.

OR

Re-enter the **ent-gta** command specifying the correct **xlat** parameter value and, if required, specifying **ri=gt** or **ri=ssn**.

NOTE: If the **xlat=dpcngt** parameter is specified, the **ri=gt** parameter must be specified. If **xlat=dpcssn** is specified, then the **ssn** parameter must be specified. If **xlat=dpcngt** is specified, the **ntt** parameter must be specified. Asterisks cannot be specified for the **ssn** and **ri** parameters. If **xlat=udts** or **disc**, the only other optional parameters allowed are **gta/egta**, **cgpc**, **opc** or **cgssn/ecgssn**.

E2381 Cmd Rej: Combined total baud rate for all ports cannot exceed 168K

Commands Used: **chg-trm**

The combined total line speed (baud rate as bits-per-second) for all active terminal ports cannot exceed **168,000** bps. When you entered the **chg-trm** command, the value of the combined total line speed for all ports exceeded **168,000** bps.

Recovery

1. Display the status of each port a terminal is attached to. Enter the **rept-stat-trm** command. The PST field displays the primary state of the terminal for each port.
 2. Use the information displayed in step 1 to determine which ports are not being used. For example, the PST field might display OOS-MT-DSBLD for a port not in use.
 3. Enter the **chg-trm** command specifying the **type=none** parameter for the terminals on the ports not being used (from step 2). Specifying (**type=none**) conveys to the terminal processor that a particular port is not connected or is no longer in use, thereby freeing up system resources.
 4. Re-enter the **rept-stat-trm** command and verify that the combined total line speed for all ports no longer exceeds **168,000** bps.
 5. Re-enter the **chg-trm** command.
-

E2382 Cmd Rej: Only 4 ports with sys maint. output group ON are allowed

Commands Used: **chg-trm**

You can configure only four terminals to receive system maintenance-related unsolicited messages. You entered the **chg-trm** command specifying the **sys=yes** parameter, and four terminals are already configured to receive system maintenance-related unsolicited messages.

Recovery

1. Verify the number of terminals configured to receive system maintenance-related unsolicited messages. Enter the **rtrv-trm** command. The SYS field should display **yes** for each of the four terminals so configured.
2. Re-enter the original **chg-trm** command without specifying the **sys=no** parameter.
If you must specify a particular port to receive system maintenance-related unsolicited messages, do the following:
 3. Using the information displayed in step 1, select one of the ports already configured, and re-enter the **chg-trm** command specifying that port and the **sys=no** parameter.
 4. Verify that only three ports now have **yes** displayed in the SYS field. Enter the **rtrv-trm** command.
 5. Re-enter the **chg-trm** command specifying the particular port you need configured to receive system maintenance-related unsolicited messages, specifying the **sys=yes** parameter for that port.

Call your Customer Care Center if this error message appears again.

E2383 Cmd Rej: MCP card must be IS-ANR Restrict to enable measplatform

Commands Used: **chg-measopts**

You entered the **chg-measopts** command specifying the **platformenable** parameter to enable the Measurements Platform collection function. At least one MCPM card must be in the IS-ANR Restrict state before you can enable the Measurements Platform collection function. The cards usually reach IS-ANR Restrict state within 2 minutes after the feature is turned on.

Recovery

1. Display the state of each MCPM card in the system. Enter the **rept-stat-card** or **rept-stat-meas** command. The Primary State of each card is shown in the PST column of the command output.
 2. If no MCPM cards are in the IS-ANR Restrict state, wait a couple of minutes and enter one of the **rept-stat-** commands again.
 3. When at least one MCPM card is in the IS-ANR Restrict state, re-enter the command the Measurements Platform collection function.
-

E2384 Cmd Rej: Link set is not equipped

Commands Used: `dact-rstst`, `inh-alm`, `rept-stat-ls`, `unhb-alm`

You specified a linkset, specified by the **lsn** parameter, that is not in the database.

Recovery

1. Display all the linksets configured in the database. Enter the command specifying no parameters. The valid linksets are displayed in the LSN field of the output.
 2. Select a valid linkset from the LSN field and re-enter the command specifying a valid linkset value for the **lsn** parameter.
-

dact-rstst

The linkset you specified in the **lsn** parameter must be in the Linkset table and in the DPC's routeset. In this case, it failed to meet either or both conditions.

OR

Recovery

1. Acquire the identifying information for the provisioned clusters. Enter the command `rept-stat-cluster` command without parameters.
 2. Re-enter the command that generated this error message specifying one of the valid linksets displayed in step 1 as the **lsn** parameter.
-

E2385 Cmd Rej: May not specify both LSN and PST

Commands Used: `rept-stat-ls`

The command was entered with both the **lsn** and **stat** parameters. The **lsn** parameter identifies the name of the linkset. The **stat** parameter identifies the primary state (PST) of the linksets to report on. The command can be entered with either of these parameters, but not both.

Recovery

Re-enter the `rept-stat-ls` command specifying either the **lsn** parameter, the **stat** parameter, or no parameters.

E2386 Cmd Rej: DPC parameter needed with MODE=FULL

Commands Used: `rept-stat-cluster`, `rept-stat-dstn`

The following Recovery procedures list the remedial action to take for each command that generates this error message.

Recovery - `rept-stat-cluster`

When you specify the `mode=full` parameter, you must also specify the `dpc` parameter. When you enter the command specifying no parameters, summary information for all of the defined cluster DPCs is shown. When you enter the command specifying a provisioned cluster member DPC, the report shows status information for the specified DPC plus route information. The destination point code must be in the database.

1. Enter the `rtrv-dstn` command to display all the destination point codes in the database.
2. Re-enter the command specifying the `mode=full` parameter, and the `dpc` parameter with a point code from the output of step 1, for a report with the additional information.

OR

Re-enter the command specifying no parameters for a summary report.

Recovery - `rept-stat-dstn`

You entered the `mode=full` parameter and the destination point code parameter (`dpc`, `dpca`, `dpcn`, `dpcn24`, `dpci`) was not specified, as required. The destination point code must be in the database.

1. Display all the destination point codes in the database. Enter the `rtrv-dstn` command.
 2. Re-enter the `rept-stat-dstn` command specifying a destination point code that is in the output of step 1 and the `mode=full` parameter.
-

E2387 Cmd Rej: Card is not in service

Commands Used: `act-cd1`, `act-lbp`, `dact-cd1`, `dact-lbp`,
`dlt-appl-rtkey`, `pass`, `rept-x25-meas`, `rtrv-appl-rtkey`,
`tst-slk`

The command was entered with a card location whose card was out of service. The cards specified in these commands must be in service.

Recovery

1. Display the status of the cards in the system using the **rept-stat-card** command. If the card is in service, the entry IS-NR appears in the PST field of the output.
 2. Re-enter the command specifying a card location that is in service.
-

E2388 Cmd Rej: Point code not equipped

Commands Used: **rept-stat-dstn**

You assigned an invalid point code parameter.

Recovery

Re-enter the **rept-stat-dstn** command that generated this error message specifying the correct (**pc**) parameter value.

Call your Customer Care Center if this error message appears again.

E2389 Cmd Rej: No troubles to Display

Commands Used: **rtrv-trbl**

The command was entered to display an entry from the trouble log, and no troubles were found.

Recovery

No action is necessary since there are no troubles to display.

E2390 Cmd Rej: No obits to display

Commands Used: **rtrv-obit**

The command was entered to display an entry from the obituary log, and none were found.

Recovery

No action is necessary since there are no obituaries to display.

E2391 Cmd Rej: Echo not allowed for telnet terminals

Commands Used: `act-echo`

You specified an Telnet port for the `trm` parameter, which is not allowed. You cannot echo FROM or TO a telnet port.

Recovery

1. Enter the `rtrv-trm` command for a list of valid terminal choices. If the entry in the TYPE column is TELNET, the terminal is not a valid choice.
 2. Re-enter the `act-echo` command specifying a valid (that is, a non-telnet) value in the `trm` parameter.
-

E2392 Cmd Rej: Received wrong display mode

Commands Used: `rept-imt-info`, `rept-stat-gpl`,

You assigned an invalid value to the display mode parameter.

Recovery - `rept-imt-info`

Re-enter the command that generated this error message specifying the correct **mode** parameter value. This parameter is optional if the **report** parameter equals **err**; otherwise, it is not allowed.

Call your Customer Care Center if this error message appears again.

Recovery - `rept-stat-gpl`

Re-enter the `rept-stat-gpl` command that generated this error message specifying the correct **display** parameter value.

NOTE: You cannot specify the **display=all** parameter and the **appl** parameter in the same command.

Call your Customer Care Center if this error message appears again.

E2393 Cmd Rej: Terminal is not equipped

Commands Used: `rtrv-trm`

You issued a command that cannot be executed because the specified terminal is not equipped.

Recovery

1. Display all terminals. Enter the **rtrv-trm** command.
 2. With the output from step 1 as a guide, re-enter the **rtrv-trm** command for an equipped terminal, or equip the terminal for use.
-

E2394 Cmd Rej: Number out of range

Commands Used: **chg-appl-sock**, **chg-assoc**, **ent-appl-sock**, **ent-assoc**, **rtrv-obit**, **rtrv-trbl**

You assigned a value to a parameter that was either too great or too small.

Recovery

Re-enter the command that generated this error message specifying the correct parameter value.

Call your Customer Care Center if this error message appears again.

E2398 Cmd Rej: Standby MASP is isolated

Commands Used: **format-disk**, **rtrv-obit**, **rtrv-trbl**

The card location specified in this command was the standby OAM, and the standby OAM could not be found. There is a communication problem with the standby OAM card.

Recovery

1. Reseat the standby OAM card.
2. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2399 Cmd Rej: Standby MASP has not finished initializing

Commands Used: **copy-disk**, **format-disk**

A **copy-disk** or **format-disk** command was entered before the standby MASP finished initializing.

Recovery

Wait until the standby MASP has finished its initialization process. Then re-enter the command.

E2401 Cmd Rej: GTA range overlaps a current range

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`, `ent-gta`, `ent-gtt`

The new **gta**/**egta** range cannot include the **gta** or the **egta** of an existing range. It is, however, permissible for the new global title address range to completely fall within an existing global title address range.

An example follows that shows what happens when the user attempts to enter a point code range (such as 8005550000 to 8005559999) that overlaps an existing range. The overlapping links must match. If they do not, error message E2401 is generated displaying the list of overlapped point codes:

```
The following GTA ranges overlap the input GTA range
START GTA          END GTA
8005550000         8005551999
8005552000         8005553999
8005554000         8005555999
ENT-GTT: MASP A - Command Aborted
```

Recovery

1. Re-enter the command specifying different values for the **gta** and **egta** parameters.
 2. To verify the global title address ranges, enter the **rtrv-gtt** or **rtrv-gta** command.
-

E2402 Cmd Rej: GTA range does not exist

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`

The specified GTA range must exist.

The Global Title Address range, as expressed by the **gta** and **egta** parameters, must already exist in the global title translation.

The following Recovery procedures list by command the remedial action for this error message.

Recovery - chg-gta, dlt-gta

The specified GTA range must exist for the specified GTT set in the STP active database. Note that an exact match is not required. (See example below).

1. Display the global title addresses in the Global Title Translation table. Enter the **rtrv-gta** command.
 2. Re-enter the command specifying one of the global title address values displayed from the output in step 1.
-

Recovery - chg-gtt, dlt-gtt

The global title address must be in the Global Title Translation table.

1. Display the global title addresses in the Global Title Translation table. Enter the **rtrv-gtt** command.
2. Re-enter the command, with one of the global title address values displayed from the output of the **rtrv-gtt** command.

An example follows that shows what happens when the user attempts to enter a point code range (such as **8005550000** to **8005559999**) that overlaps an existing range. The overlapping links must match. If they do not, error message E2401 is generated displaying the list of overlapped point codes:

The following GTA ranges overlap the input GTA range

```
START GTA      END GTA
8005550000    8005551999
8005552000    8005553999
8005554000    8005555999
CHG-GTT: MASP A - Command Aborted
```

E2403 Cmd Rej: Length of EGTA must be equal to length of GTA

Commands Used: chg-gta, chg-gtt, dlt-gta, dlt-gtt, ent-gta, ent-gtt, rtrv-gta, rtrv-gtt

The **egta** parameter does not contain the same number of digits as the **gta** parameter. The **egta** and the **gta** parameters must have the same lengths or contain the same number of digits.

Recovery

Re-enter the command specifying the same number of digits for both the **egta** and the **gta** parameters.

E2404 Cmd Rej: GTA does not match translation type's number of digits

Commands Used: `chg-gtt`, `dlt-gtt`, `ent-gtt`, `rtrv-gtt`

The global title address specified for the translation type must contain the same number of digits specified in the `ent-tt` command for that translation type.

If the VGTT (variable length GTT) feature is turned on, you can provision up to 10 GTA lengths per translation type. When you enter the `ent-gtt` command to create entries, the software keeps track of the lengths and allows only 10 different lengths. Only global title entries that match the defined GTA lengths are allowed.

Recovery

1. Display the translation type information in the Route table. Enter the `rtrv-tt` command. The number of GTA digits allowed is listed in the NDGT column of the output.
 2. Re-enter the command specifying the global title address containing one of the GTA lengths listed in the output of step 1.
-

E2405 Cmd Rej: GTA does not exist in any range

Commands Used: `rtrv-gta`, `rtrv-gtt`

The command cannot find the global title address specified by the `gta` parameter.

Recovery

Perform one of the following:

- Verify that the translation type or GTT set name has been entered correctly and re-enter the command.

OR

- Enter the `rtrv-gtt` command without specifying any parameters, or enter the `rtrv-gta` command specifying only the mandatory `gttsn` parameter.
-

E2406 Cmd Rej: ADJ required if MPC/MSSN is given or MULT=DOM or SHR

Commands Used: `chg-map`, `ent-map`

You entered the command without specifying the **adj** parameter and with the mated point code (**mpc**, **mpca**, **mpci**, **mpcn**) and **mssn** parameters, or with the **mult=dom** or **mult=shr** parameters. If any of these parameters are specified in the command, the **adj** parameter must be entered.

Recovery

Re-enter the command specifying the **adj** parameter.

E2407 Cmd Rej: GTA range is already assigned

Commands Used: `ent-gtt`

The range of global title addresses specified is already assigned to this translation type.

Recovery

1. Re-enter the `ent-gtt` command specifying different values for the **gta** and **egta** parameters.
 2. To verify which global title addresses have been assigned to translation types, enter the `rtrv-gtt` command.
-

E2408 Cmd Rej: CSPC broadcast group already exists

Commands Used: `ent-cspc`

You tried to enter a Concerned Signaling Point Code broadcast group name that has already been entered. Entering a CSPC broadcast group with no point code implies that a new CSPC broadcast group is to be created, but the name specified in this command is already in use. The CSPC broadcast group names must be unique.

Recovery

1. Display the CSPC broadcast group names. Enter the `rtrv-cspc` command.
 2. Re-enter the `ent-cspc` command specifying another name for the CSPC broadcast group that is not shown in step 1.
-

E2409 Cmd Rej: EGTA cannot be specified without GTA

Commands Used: `chg-gtt`, `ent-gtt`, `rtrv-gtt`, `rtrv-gta`

You cannot specify the `egta` parameter and not specify the `gta` parameter.

Recovery

Re-enter the command that generated this error message specifying both the `egta` and `gta` parameters.

Call your Customer Care Center if this error message appears again.

E2410 Cmd Rej: CSPC broadcast group table is full

Commands Used: `ent-cspc`

The system can contain a maximum of 2550 CSPC broadcast groups. The CSPC broadcast group cannot be entered until another CSPC broadcast group is deleted. This threshold has been reached and this command attempted to enter more than 2550 CSPC broadcast groups.

Recovery

1. Display the CSPC broadcast group information. Enter the `rtrv-cspc` command specifying no parameters.
2. From the output of the `rtrv-cspc` command entered in step 1, select a CSPC broadcast group to delete.
3. Delete the CSPC broadcast group selected in step 2. Enter the `dlt-cspc` command.
4. Re-enter the `ent-cspc` command specifying the parameters that generated this error message to add the desired CSPC broadcast group.

Call your Customer Care Center if this error message appears again.

E2411 Cmd Rej: CSPC group does not exist

Commands Used: `chg-map`, `dlt-cspc`, `ent-cspc`, `ent-map`,
`rtrv-cspc`

The following command-specific Recovery procedures list the remedial actions required for this error message.

Recovery - chg-map, dlt-cspc, ent-cspc, rtrv-cspc

The new concerned signaling point code group could not be found. To change the name of a CSPC group, that CSPC group name must exist in the CSPC Group Name table.

1. Display the CSPC group names in the CSPC Group Name table. Enter the **rtrv-cspc** command specifying no parameters.
 2. Re-enter the command that generated this error message specifying a CSPC group name displayed in the CSPC Group Name table from step 1.
-

Recovery - ent-cspc

You tried to enter a Concerned Signaling Point Code to a CSPC group that is not in the CSPC Group Name table. To enter a CSPC to a CSPC group, that CSPC group must exist in the CSPC Group Name table.

1. If the CSPC group name was entered correctly and this error message appears, re-enter the **ent-cspc** command specifying the group parameter only.
 2. Re-enter the **ent-cspc** command, this time including the point codes.
-

E2412 Cmd Rej: Command already in progress

Commands Used: act-gpl, chg-gpl, copy-gpl, rtrv-gpl, rept-stat-gpl

The command was entered while the system was still executing one of these previously entered commands: **act-gpl, chg-gpl, copy-gpl, rept-stat-gpl, or rtrv-gpl**. No other activate, change, copy, or retrieve GPL command can be in progress when these commands are entered.

Recovery

Wait until the system has completed executing the command in progress. Then re-enter the appropriate gpl command that generated this error message.

E2413 Cmd Rej: PC already exists in CSPC group

Commands Used: `ent-cspc`

The specified point code already exists in the concerned signaling point code group. The point code must exist in the Routing Table and cannot already exist in the specified group.

Recovery

1. Verify that the point code was entered correctly and re-enter the `ent-cspc` command.
 2. If the point code was entered correctly and this error message appears again, the point code already exists in the concerned signaling point code group.
-

E2414 Cmd Rej: PC does not exist in CSPC group

Commands Used: `chg-map`, `dlt-cspc`, `ent-map`

The specified point code does not exist in the specified concerned signaling point code group.

Recovery

1. Display the point codes currently assigned to the group. Enter the `rtrv-cspc` command specifying the desired CSPC group name.
 2. Re-enter the `dlt-cspc` command specifying one of the displayed point codes in step 1.
-

E2415 Cmd Rej: Concerned node table for this group is full

Commands Used: `ent-cspc`

You cannot enter more than **96** point codes to a CSPC group.

Recovery

NOTE: The point code cannot be entered until another point code is removed.

1. Display the CSPC group information. Enter the `rtrv-cspc` command specifying no parameters.
2. From the output of the `rtrv-cspc` command entered in step 1, select a point code to be deleted.

3. Delete the point code selected in step 2. Enter the **dlt-cspc** command.
 4. Re-enter the **ent-cspc** command specifying the parameters that generated this error message to enter the desired point code.
-

E2416 Cmd Rej: Unable to access database. Severe database failure

Commands Used: **chg-gta, chg-gtt, chg-feat, chg-lnpopts, chg-mrn, chg-sccp-serv, chg-scr-aftpc, chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-dpc, chg-scr-isup, chg-scr-opc, chg-scrset, chg-scr-sio, chg-scr-tt, dlt-mrn, dlt-sccp-serv, dlt-scr-aftpc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-cdpa, dlt-scr-cgpa, dlt-scr-dpc, ent-scr-isup, dlt-scr-opc, dlt-scrset, dlt-scr-sio, dlt-scr-tt, ent-gta, ent-gtt, ent-map, ent-mrn, ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-dpc, ent-scr-isup, ent-scr-opc, ent-scrset, ent-scr-sio, ent-scr-tt, rtrv-sccp-serv, rtrv-feat, rtrv-lnpopts, rtrv-mrn, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-dpc, ent-scr-isup, rtrv-scr-opc, rtrv-scrset, rtrv-scr-sio, rtrv-scr-tt**

A severe system fault has occurred and the command was rejected.

Recovery

Call your Customer Care Center.

E2417 Cmd Rej: Point code does not exist in the routing table

Commands Used: **chg-gsmopts, chg-gsmmap-scrn, chg-gsms-opcode, chg-gta, chg-rtx, dact-rstst, ent-cspc, ent-gsmmap-scrn, ent-gsms-opcode, ent-gta, ent-rtx, inh-alm, rept-stat-cluster, rst-dstn, unhb-alm**

If a point code is specified, the point code (**pc/pca/pci/pcn/pcn24** or **npc/npca/npci/npcn/npcn24**) parameter must exist as a destination in the ordered route entity set or must reside in a cluster (ANSI only) that exists as a destination in the ordered route entity set (for global title routing).

For the **chg-rtx** and **ent-rtx** commands, the specified Destination Point Code (**dpc**) must already exist in Route table.

Recovery

1. Add the destination point code into the Destination Point Code table. Enter the **ent-dstn:dpc=xxx** command.
 2. Add the route to the Route table. Enter the **ent-rte:dpc=xxx:lsn=yyy** command specifying the linkset name (**lsn**) associated with this route.
 3. Verify your point code now exists as a destination in the Route table. Enter the **rtrv-rte:pc=xxx** command to display the point codes in the Route table.
 4. Re-enter the command specifying one of the point codes displayed in the output from step 3.
-

E2418 Cmd Rej: Mate PC/SSN cannot be given when MULT=SOL

Commands Used: **ent-map**, **chg-map**

The **mult=sol**, **mpc**, and **mssn** parameters were specified in the same command. The **mult=sol** parameter cannot be specified with the **mpc** and **mssn** parameters.

Recovery

Perform one of the following:

- Enter the command specifying the **mpc** and **mssn** parameters, and without the **mult=sol** parameter.
- OR
- Enter the command specifying the **mult=sol** parameter, and without the **mpc** and **mssn** parameters.
-

E2419 Cmd Rej: Point code does not exist in the remote point code table

Commands Used: **chg-gta**, **chg-gtt**, **ent-gta**, **ent-gtt**

The specified point code could not be found in the Remote Point Code/Mated Application (MAP) table.

- For the **chg-gta** command, this error is generated only if the optional point code (**pc/pca/pci/pcn/pcn24**) parameter is not specified.
- For the **chg-gta**, **ent-gta**, and **ent-gtt** commands, you can override this rule by specifying the **force=yes** parameter.

NOTE: If a final GTT is specified with the (ri=ssn) and (xlat=dpc) parameters, the specified point code (pc/pca/pci/pcn/pcn24) must exist in the MAP table.

For the **chg-gta**, **ent-gta**, and **ent-gtt** commands, if the specified point code is not in the MAP table; the **force=yes** parameter must be specified to execute the command and instead of error message E2419, the following caution messages are displayed in the scroll area of the terminal:

```
DPC DOES NOT EXIST IN MATED APPLICATION TABLE
DPC-SSN DOES NOT EXIST IN MATED APPLICATION TABLE
```

Recovery

1. Display the MAP table. Enter the **rtrv-map** command specifying no parameters.
 2. Perform one of the following:
Re-enter the command specifying a point code (**pc/pca/pci/pcn/pcn24**) parameter that exists in the MAP table.
OR
For the **chg-gta**, **ent-gta**, and **ent-gtt** commands, if the specified point code is not in the MAP table, re-enter the command specifying the **force=yes** parameter.
-

E2420 Cmd Rej: EGTA must be greater than or equal to GTA

Commands Used: **chg-gta**, **chg-gtt**, **dlt-gta**, **dlt-gtt**, **ent-gta**, **ent-gtt**, **rtrv-gta**, **rtrv-gtt**

A range of global title addresses cannot be established if the **egta** parameter value is less the **gta** parameter value. You cannot specify a value for the **egta** parameter that is less than the value of the **gta** parameter.

Recovery

Re-enter the command specifying a value for the **egta** parameter that is greater than or equal to the **gta** value.

E2421 Cmd Rej: ALL=YES must be specified to delete the entire group**Commands Used: dlt-cspc**

Neither the **pc** nor the **all** parameter was specified; therefore, the command was interpreted as an attempt to delete an entire concerned signaling point code group. To delete an entire concerned signaling point code group, specify the **all=yes** parameter.

Recovery

To delete an entire concerned signaling point code group, re-enter the **dlt-cspc** command specifying the **all=yes** parameter.

E2422 Cmd Rej: ALL=YES must be specified to delete all SSNs for a PC**Commands Used: dlt-map**

Neither the **ssn** nor the **all** parameter was specified; therefore, the command was interpreted as an attempt to delete all subsystem numbers for a given point code. To delete all subsystem numbers for a given point code, specify the **all=yes** parameter.

Recovery

To delete all subsystem numbers for a given point code, re-enter the **dlt-map** command specifying the **all=yes** parameter. Do not use the **ssn** parameter.

E2423 Cmd Rej: FORCE=YES must be specified for NUM greater than 1000**Commands Used: rtrv-gta, rtrv-gtt**

You cannot display more than **1000** entries (indicated by the **num** parameter) without specifying the **force** parameter.

Recovery

Perform one of the following:

- To display more than 1000 entries, re-enter the command specifying **force=yes** and a value greater than 1000 for the **num** parameter.

NOTE: The range of values for the **num** parameter is from 1 to 65535.

OR

- To display 1000 or less entries, re-enter the command specifying **force=no** and a value less than or equal to 1000 for the **num** parameter.
-

E2424 Cmd Rej: SRM=YES cannot be entered with ITU point code types

Commands Used: **chg-map**, **ent-map**

You cannot specify the Control of Subsystem Routing Messages (**srm=yes**) parameter and an ITU point code (**pci**, **pcn**, or **pcn24**). The **srm=yes** parameter can be specified only with an ANSI point code (**pc** or **pca**).

Recovery

Perform one of the following:

- Re-enter the command specifying an ANSI point code and the **srm=yes** parameter, or do not specify the **srm** parameter. The default value for the **srm** parameter for an ANSI point code is **yes**.

OR

- Re-enter the command specifying either an ITU point code and the **srm=no** parameter, or do not specify the **srm** parameter. The default value for the **srm** parameter for an ITU point code is **no**.
-

E2425 Cmd Rej: Mate PC/SSN cannot be same as PC/SSN

Commands Used: **chg-map**, **ent-map**

You cannot specify the same values for the mate point code (**mpc**) and mate subsystem number (**mssn**) pair and the primary point code (**pc**) and subsystem number (**ssn**) pair.

The mate point code can be equal to the primary point code if the mate subsystem number is not equal to the primary subsystem number. If the primary point code is not equal to the mate point code, the subsystem number can be the same as the mate subsystem number.

Recovery

Re-enter the command, specifying values for the primary point code/subsystem pair that are not the same as those for the mate point code/subsystem pair.

E2426 Cmd Rej: Mnemonic argument is undefined

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

You cannot specify a value other than `gt` or `ssn` for the `ri` parameter. You cannot specify `ri=dpc`.

Recovery

Re-enter the command specifying a value of `ri=gt` or `ri=ssn`.

E2427 Cmd Rej: MPC does not exist in routing Table

Commands Used: `chg-map`, `chg-mrn`, `chg-sccp-serv`, `ent-map`,
`ent-mrn`

The mate remote point code specified in the command is not in the Route table. To enter a mate remote point code, the mate remote point code to be entered must be in the Route table.

Recovery

1. Verify that the mate remote point code was entered correctly and re-enter the command.
 2. If the mate remote point code was entered correctly and this error message appears again, enter the `rtrv-rte` command to display the route table.
 3. Re-enter the command specifying one of the point code values displayed in the `rtrv-rte` command.
-

E2428 Cmd Rej: MPC entered, MSSN must also be given

Commands Used: `chg-map`, `ent-map`

You cannot specify a mate point code (`mpc`) and not specify a mate subsystem number (`mssn`). If you specify an `mpc`, you must also specify a `mssn`.

Recovery

Re-enter the command specifying values for both the `mpc` and the `mssn` parameters.

E2429 Cmd Rej: MPC network type does not match PC network type

Commands Used: `chg-map`, `ent-map`

The values specified for the point code type (**pc**) and the optional mated point code type (**mpc**) must be for the same types of networks. If a mated point code is specified, the network type of the specified point code must match the network type of the specified mated point code.

- If the point code value is entered as **pc** or **pca**, the **mpc**, if specified, must be **mpc** or **mpca**.
- If the point code value is entered as **pci**, **pcn**, or **pcn24**, the **mpc**, if specified, must be **mpci**, **mpcn**, or **mpcn24**, respectively.

NOTE: To mix group and PC Network types, the "ANSI/ITU/24 Bit ITU-N Conversion" feature must be on.

Recovery

Re-enter the command making sure that the point code and mated point code types match.

- If the specified point code is for an ANSI point code (**pc** or **pca**), the mated point code must also be for an ANSI point code (**mpc** or **mpca**).
 - If the specified point code is for an ITU-I point code (**pci**), the mated point code must also be for an ITU-I point code (**mpci**).
 - If the specified point code is for an ITU-N point code (**pcn**), the mated point code must also be for an ITU-N point code (**mpcn**).
 - If the specified point code is for an ITU-N 24-bit point code (**pcn24**), the mated point code must also be for an ITU-N point code (**mpcn24**).
-

E2430 Cmd Rej: Subsystem table for MPC is full

Commands Used: `chg-map`, `ent-map`

You tried to enter more than 10 subsystem numbers. Each mate remote point code can contain only 10 subsystem numbers, and this threshold has been reached.

Recovery

NOTE: You cannot enter the subsystem number for the given mate remote point code until another subsystem number is removed.

1. Display the data for this mate remote point code. Enter the `rtrv-map` command specifying the **pc** parameters.

2. From the output of the **rtrv-map** command entered in step 1, select a subsystem number to be deleted.
 3. Delete the subsystem number selected in step 2. Enter the **dlt-map** command.
 4. Re-enter the command specifying the parameters that generated this error message, to enter the desired subsystem number.
-

E2431 Cmd Rej: MPC/MSSN pair already exists

Commands Used: **chg-map**, **ent-map**

The values specified for the mate point code (**mpc**) and mate subsystem number (**mssn**) are already in the database. The mate point code and mate subsystem number pairs must be unique.

Recovery

1. Display the mate point codes and mate subsystem number pairs. Enter the **rtrv-map** command.
 2. Re-enter the command, with values for the mate point code and the mate subsystem number that are not shown in the output of step 1.
-

E2432 Cmd Rej: MSSN or MATERC entered, MPC must also be given

Commands Used: **ent-map**

You entered the mate subsystem number or relative cost, but you did not enter a mate point code. If you enter a mate subsystem number or relative cost, you must enter a mate point code.

Recovery

Re-enter the command specifying a mate point code in addition to the mate subsystem number or relative cost.

E2435 Cmd Rej: New/existing PC does not exist in the remote PC table

Commands Used: chg-gsmopts, chg-gta, chg-gtt

You entered the **chg-gta** or **chg-gtt** command specifying the **xlat=dpc** and **ri=ssn** parameters and specified the **pc/pca/pci/pcn/pcn24** parameter. The point code, however, could not be found in the MAP table. For the **chg-gta** command, you can override this rule by issuing the **force=yes** parameter.

OR

You entered the **chg-gsmopts** command specifying **ssn** as the existing **ppsmsri1** or **ppsmsri2** parameter value, and the **ppsmspci1**, **ppsmspci2**, **ppsmspcn1** or **ppsmspcn2** parameter value has not been defined in the Mated Application (MAP) table.

Recovery chg-gsmopts, chg-gtt

1. Enter the **rtrv-map** command specifying no parameters to display the mate applications information.
 2. Re-enter the command specifying a point code displayed in step 1.
-

Recovery chg-gta

Re-enter the **chg-gta** command that generated the error message specifying the **force=yes** override.

E2437 Cmd Rej: New/existing RI must be GT for new/existing XLAT=DPCNGT

Commands Used: chg-gta, chg-gtt

The translate indicator (**xlat**) was entered with the value of **dpcngt**, and the routing indicator (**ri**) was equal to **ssn**.

Recovery

Perform one of the following:

- Re-enter the command specifying the **xlat=dpcngt** and **ri=gt** parameters.
- OR
- Enter the command specifying the **xlat** parameter equal to **dpc** or **dpcssn**.
-

E2438 Cmd Rej: MPC and MSSN must be defined for new MULT val**Commands Used: chg-map**

The command was entered with the **mult=dom** or **mult=shr** parameters, to change the multiplicity from solitary to either dominant or load sharing, and without the mated point code (**mpc, mpca, mpci, mpcn, mpcn24**) and **mssn** parameters. If the **mult=dom** or **mult=shr** parameter is specified, the mated point code (**mpc, mpca, mpci, mpcn, mpcn24**) and **mssn** parameters must also be specified.

Recovery

Re-enter the **chg-map** command specifying the mated point code (**mpc, mpca, mpci, mpcn, mpcn24**), **mssn**, and the **mult=dom** or **mult=shr** parameter.

E2439 Cmd Rej: New PC does not exist in the routing table**Commands Used: chg-gtt**

To change the point code to the new point code specified in the command, the new point code must be in the routing table.

Recovery

1. Enter the **rtrv-rte** command to display the point codes in the routing table.
 2. Re-enter the **chg-gtt** command, with one of the point code values displayed from the output of the **rtrv-rte** command.
-

E2440 Cmd Rej: Primary PC/SSN pair already exists**Commands Used: ent-map**

The command attempted to enter a primary point code and a primary subsystem number that has already been entered. The primary point code and primary subsystem number pairs must be unique.

Recovery

Re-enter the **ent-map** command specifying different values for the primary point code and the primary subsystem number.

E2441 Cmd Rej: NGT must be specified for new values of XLAT/RI

Commands Used: `chg-gtt`

You specified the `xlat=dpcngt` and `ri=gt` parameters, and without the `ngt` parameter. The `ngt` parameter must be specified if the `xlat=dpcngt` and `ri=gt` parameters are specified.

Recovery

Re-enter the command specifying the `xlat=dpcngt`, `ri=gt`, and the `ngt` parameters.

E2442 Cmd Rej: SSN must be specified for new values of XLAT/RI

Commands Used: `chg-gta`, `chg-gtt`

You specified the `xlat=dpcssn` parameter and without the `ssn` parameter. You must enter the `ssn` parameter with the `xlat=dpcssn` parameter.

Recovery

Re-enter the command specifying the `xlat=dpcssn` and `ssn` parameters.

E2443 Cmd Rej: NGT can only be specified when XLAT=DPCNGT

Commands Used: `chg-gtt`, `ent-gtt`

You entered the new global title translation type (`ngt`), and you entered the translate indicator (`xlat`) with the value of `dpc` or `dpcssn`.

Recovery

NOTE: If the ANSI-ITU-China SCCP Conversion feature is enabled, this error code will not be generated.

Perform one of the following:

- Enter the command specifying the `xlat=dpcngt` and `ngt` parameters.
 - OR
 - Enter the command specifying the `xlat` parameter equal to `dpc` or `dpcssn`, and without specifying the `ngt` parameter.
-

E2444 Cmd Rej: Allow rejected: terminal is not equipped

Commands Used: `alw-trm`, `rst-trm`

If you attempt to allow a terminal number that has not been equipped, the result is a semantic error message.

Recovery

1. Display all the terminals. Enter the `rtrv-trm` command.
 2. Based on the output from step 1, re-enter the command for an equipped terminal or equip the terminal for use.
-

E2446 Cmd Rej: SCCPMT must be specified as 9, 10, 17, 18, or *

Commands Used: `chg-scr-cgpa`, `dlt-scr-cgpa`, `ent-scr-cgpa`,
`rtrv-scr-cgpa`

You assigned an invalid value to the `sccpmt` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `sccpmt` parameter value.

Call your Customer Care Center if this error message appears again.

E2447 Cmd Rej: NUM exceeds maximum table size

Commands Used: `rtrv-gtt`

You assigned an invalid value to the `num` parameter.

Recovery

Re-enter `rtrv-gtt` the command that generated this error message specifying the correct `num` parameter value.

Call your Customer Care Center if this error message appears again.

E2448 Cmd Rej: ALL=YES cannot be specified with a point code**Commands Used: dlt-cspc**

You specified both the **pc** and **all** parameters. To delete an entire concerned signaling point code group, the **all=yes** parameter must be used without specifying a point code. To delete a point code in a concerned signaling point code group, the **pc** parameter must be used.

Recovery

1. To delete an entire concerned signaling point code group, re-enter the **dlt-cspc** command specifying the **all=yes** parameter. Do not use the **pc** parameter.
 2. To delete a point code in a concerned signaling point code group, re-enter the **dlt-cspc** command specifying the **pc** parameter. Do not use the **all** parameter.
-

E2449 Cmd Rej: CSPC group network type does not match PC network type**Commands Used: chg-map, dlt-cspc, ent-cspc, ent-map**

The command was entered with a concerned signaling point code (CSPC) group name (**grp**) containing point codes whose network type does not match the network type of the specified point code (**pc**, **pca**, **pci**, **pcn**, or **pcn24**). The network type of the point codes in the specified CSPC group name must be the same as the network type of the specified point code.

NOTE: Mixing group and point code network types is supported in the ent-map, chg-map, and ent-cspc commands only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

1. Display the CSPC groups. Enter the **rtrv-cspc** command. The network type of the point codes in each CSPC group is shown in the NETWORK field of the output.
 2. Re-enter the command specifying the CSPC group name (**grp**) whose network type matches the network type of the specified point code.
 - If the point code is an ANSI point code (**pc** or **pca**), then enter a CSPC group name that contains ANSI point codes, shown by the entry ANSI in the NETWORK field of the **rtrv-cspc** command output in step 1.
 - If the point code is an ITU-I point code (**pci**), then enter a CSPC group name that contains ITU-I point codes, shown by the entry ITU-I in the NETWORK field of the **rtrv-cspc** command output in step 1.
 - If the point code is an ITU-N point code (**pcn**), then enter a CSPC group name that contains ITU-N point codes, shown by the entry ITU-N in the NETWORK field of the **rtrv-cspc** command output in step 1.
 - If the point code is a 24-Bit ITU-N point code (**pcn24**), then enter a CSPC group name that contains 24-Bit ITU-N point codes, shown by the entry ITU-N24 in the NETWORK field of the **rtrv-cspc** command output in step 1.
-

E2450 Cmd Rej: PC/SSN does not exist as a mated application

Commands Used: **chg-gsmmap-scrn**, **chg-gsms-opcode**,
ent-gsmmap-scrn, **ent-gsms-opcode**

When you attempt to specify point code parameters (**pc/pca/pci/pcn/pcn24** or **npc/npca/npci/npcn/npcn24**) or subsystem number (**ssn** or **nssn**) parameters, you must either specify **force=yes** or ensure the new point code and subsystem number are previously populated in the SCCP application entity set (Remote Point Code / Mated Application Table).

Recovery

Re-enter the command specifying the **force=yes** parameter or ensuring the SCCP application first contains the new point code or subsystem number.

Call your Customer Care Center if this error message appears again.

E2451 Cmd Rej: Primary remote PC does not exist in routing table

Commands Used: `ent-map`

The primary remote point code specified in the command is not in the routing table. The primary remote point code to be entered must be in the routing table.

Recovery

1. Verify that the primary remote point code was entered correctly and re-enter the command.
 2. If the primary remote point code was entered correctly and this error message appears again, enter the `rtrv-rte` command to display the route table.
 3. Re-enter the `ent-map` command specifying one of the point code values displayed in the `rtrv-rte` command.
-

E2452 Cmd Rej: Remote point code does not exist in MAP table

Commands Used: `chg-map`, `dlt-map`, `rtrv-map`

The specified remote point code is not in the MAP table. These commands require that the specified remote point code be defined previously in the MAP table by the `ent-map` command.

Recovery

1. Display the remote point codes in the MAP table. Enter the `rtrv-map` command specifying no parameters. This is all that is necessary if the `rtrv-map` command generated this error message.
2. Enter a desired remote point code that is not in the output of step 1 with the `ent-map` command.

OR

Re-enter the command specifying a remote point code that is already defined in the output of step 1.

E2453 Cmd Rej: Subsystem table for primary remote point code is full

Commands Used: `ent-gtt`, `ent-map`, `chg-gtt`, `chg-map`

You cannot enter more than **10** subsystem numbers. Each primary remote point code can contain only **10** subsystem numbers, and this threshold has been reached.

Recovery

1. The subsystem number for the given primary remote point code cannot be entered until another subsystem number is deleted.
 2. Enter the **rtrv-map** command specifying the **pc** parameters to display the data for this primary remote point code.
 3. From the output of the **rtrv-map** command entered in step 2, select a subsystem number to be deleted.
 4. Enter the **dlt-map** command to delete the subsystem number selected in step 3.
 5. Re-enter the command specifying the parameters that generated this error message to enter the desired subsystem number.
-

E2454 Cmd Rej: Remote point code table is full

Commands Used: **chg-gtt**, **chg-map**, **ent-gtt**, **ent-map**

You cannot enter more than **1024** remote point codes. The system can contain only **1024** remote point codes, and this threshold has been reached.

A new remote point code cannot be entered until an existing remote point code is deleted.

Recovery

1. Display the MAP table. Enter the **rtrv-map** command specifying no parameters.
 2. Select a remote point code to be deleted from the output of step 1
 3. Delete the remote point code. Enter the **dlt-map** command.
 4. Enter the desired remote point code. Re-enter the **ent-map** command specifying the parameters that generated this error message.
- Call your Customer Care Center if this error message appears again.
-

E2455 Cmd Rej: ALL cannot be specified with a subsystem

Commands Used: **dlt-map**

You cannot specify the **all** and the **ssn** parameters together. This parameter combination is not allowed.

Recovery

Re-enter the **dlt-map** command specifying either the **all** parameter or the **ssn** parameter, but not both.

E2456 Cmd Rej: SSN does not exist for given remote point code

Commands Used: **chg-map**, **dlt-map**, **rtrv-map**

The subsystem number specified in the command does not exist.

Recovery

1. Verify that the subsystem number was entered correctly.
 2. Re-enter the command.
 3. If the subsystem number was entered correctly and this error message appears again, enter the **rtrv-map** command specifying no parameters to display the mate applications information.
 4. Re-enter the command specifying one of the subsystem number values displayed in the **rtrv-map** command.
-

E2457 Cmd Rej: SSN can only be specified when XLAT=DPCSSN

Commands Used: **chg-gta**, **chg-gtt**, **ent-gta**, **ent-gtt**

You entered the subsystem number (**ssn**), and the translate indicator (**xlat**) was entered with the value **dpc** or **dpcngt**.

Recovery

Perform one of the following:

- Re-enter the command specifying the **xlat=dpcssn** and the **ssn** parameters.
- OR
- Re-enter the command without specifying the **ssn** parameter.
-

E2458 Cmd Rej: SSN cannot be specified without a point code**Commands Used: rtrv-map**

You entered a subsystem number, but you did not enter a point code. If you enter a subsystem number, you also must enter a point code.

Recovery

Re-enter the **rtrv-map** command, with the point code in addition to the subsystem number.

E2459 Cmd Rej: Alias already in use**Commands Used: chg-dstn, ent-dstn, ent-tt**

The specified alias value is already being used by an alias for another translation type.

Recovery

1. Enter the **rtrv-dstn** or **rtrv-tt** command to display the translation types and the aliases.
 2. Re-enter the command specifying an alias not shown in the output of step 1.
-

E2460 Cmd Rej: Alias defined as translation type**Commands Used: dlt-tt, ent-tt, rtrv-tt**

The specified alias is defined as a translation type. The alias cannot be specified if it is defined as a translation type.

Recovery

1. Display the translation types and aliases for these translations types. Enter the **rtrv-tt** command specifying no parameters.
 2. Re-enter the command specifying an alias that is not a translation type.
-

E2461 Cmd Rej: Alias not assigned to translation name

Commands Used: `rtrv-tt`

The association of the specified alias and specified translation name could not be found.

Recovery

Perform one of the following:

- Verify that the translation name and alias have been entered correctly and re-enter the command.

OR

- Enter the `rtrv-tt` command specifying only the translation name.
-

E2462 Cmd Rej: GTT table is full

Commands Used: `chg-gta`, `chg-gtt`, `dlt-gta`, `dlt-gtt`, `ent-gta`, `ent-gtt`

You cannot add an entry to the GTT table because the GTT table is full. The GTT table can support up to **269,999** entries.

If the XGTT feature is enabled, the GTT table can support up to either **400,000** or **1,000,000** entries, depending on the controlled feature part number that is enabled.

Recovery

1. The GTT table and Translation Type table contains an extremely large amount of information that could take many hours to display. However, you can use one of the following commands to display a portion of the table or a specific record to determine if there are entries you can delete:

- the `rtrv-gtt` command for GTT
- the `rtrv-gta` command for EGTT

(You can use the `canc-cmd` command to abort the `rtrv-gtt` and `rtrv-gta` commands).

2. If you determine that there is an entry you want to delete, delete the entire range (**gta** to **egta**) for the entry.
 3. Due to the size of the table (**269,999**, **400,000**, or **1,000,000** possible entries), if you receive this error message, you may want to reexamine your database structure.
-

E2463 Cmd Rej: Alias not assigned to translation type

Commands Used: `dlt-tt`, `rtrv-tt`

The association of the specified alias and specified translation type could not be found.

Recovery

1. Display the Translation Type table. Enter the `rtrv-tt` command.
 2. Re-enter the command specifying a translation type and alias combination shown in the output of step 1.
-

E2464 Cmd Rej: Translation TYPE already exists

Commands Used: `ent-tt`

The translation type specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

1. Display the Translation Type table. Enter the `rtrv-tt` command.
 2. Re-enter the `ent-tt` command specifying a different value for the translation type.
-

E2465 Cmd Rej: Translation TYPE defined as an alias

Commands Used: `chg-gtt`, `chg-lnp-ttmap`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `ent-tt`, `rtrv-gtt`, `rtrv-lnp-ttmap`, `rtrv-tt`

The specified translation type was defined as an alias for another translation type. The translation type cannot be specified if it is defined as an alias for another translation type.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command.
 2. Re-enter the command specifying a translation type that is not defined as an alias.
-

E2466 Cmd Rej: Translation TYPE specified does not exist

Commands Used: **chg-gtt, dlt-gtt, dlt-tt, ent-gta, ent-gtt, ent-tt, rtrv-gtt, rtrv-tt**

The translation type specified must be in the Translation Type table.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command specifying no parameters.
 2. Re-enter the command specifying a translation type that exists in the Translation Type table.
-

E2467 Cmd Rej: TTN already in use

Commands Used: **ent-tt**

The translation name specified is used by another translation type. Translation names must be unique.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command.
 2. Re-enter the **ent-tt** command specifying a different translation name.
-

E2468 Cmd Rej: TTN specified does not exist

Commands Used: **chg-gtt, dlt-gtt, dlt-tt, ent-gtt, rtrv-gtt, rtrv-tt**

The translation type name specified must be in the Translation Type table.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command.
 2. Re-enter the command specifying one of the translation type names values displayed from the output of the **rtrv-tt** command.
-

E2469 Cmd Rej: NDGT parameter not permitted with ALIAS

Commands Used: **ent-tt**

You cannot specify the **alias** parameter and the **ndgt** parameter.

Recovery

Re-enter the **ent-tt** command specifying the **alias** parameter or the **ndgt** parameter, but not both.

E2470 Cmd Rej: Point Code network type does not match TT network type

Commands Used: **chg-gta, chg-gtt, ent-gta, ent-gtt, rtrv-gtt**

The command was entered with a point code whose network type does not match the network type of the translation type. The network type of the translation type and the translated point code must match. You cannot have mixed networks.

Recovery

NOTE: If the ANSI-ITU-China SCCP Conversion feature is enabled, this error code will not be generated.

Re-enter the command specifying a point code whose network type matches the specified translation type.

- If the translation type is an ANSI translation type (**type** or **typea**), the point code must be an ANSI point code (**pc** or **pca**).
 - If the translation type is an ITU-I translation type (**typei**), the point code type must be an ITU-I point code (**pci**).
 - If the translation type is an ITU-N translation type (**typen** or **typen24**), the point code type an ITU-N point code (**pcn** or **pcn24**).
-

E2471 Cmd Rej: Translation TYPE has an alias**Commands Used: dlt-tt**

The specified translation type has an alias assigned to it. The translation type cannot be deleted until the alias assigned to it has been deleted.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command.
 2. Delete the alias assigned to the translation type. Enter the **dlt-tt** command.
 3. Delete the translation type. Re-enter the **dlt-tt** command.
-

E2472 Cmd Rej: Translation TYPE is referenced by GTT entry**Commands Used: dlt-tt**

A translation type cannot be deleted if it is referenced by a current global title translation entry.

Recovery

1. Display the GTT table. Enter the **rtrv-gtt** command.
 2. Delete the global title translation entry associated with the translation type to be deleted. Enter the **dlt-gtt** command.
 3. Delete the translation type. Enter the **dlt-tt:type=** command.
-

E2473 Cmd Rej: TTN and TYPE do not correspond to each other**Commands Used: chg-gtt, dlt-gtt, dlt-tt, ent-gtt, rtrv-gtt, rtrv-tt**

This error message appears if both the translation type and translation name parameters are specified. For this command to be successful, the specified translation type and translation name must be in the translation table.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** (or **rtrv-ttn** or **rtrv-type**) command.
 2. Re-enter the command, with the translation type and/or translation name values displayed from the output of the **rtrv-tt** command.
-

E2474 Cmd Rej: Translation TYPE must be specified

Commands Used: **dlt-tt**, **ent-tt**

The command specified an alias without a translation type. The translation type must be specified if an alias is specified.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command.
 2. Re-enter the command specifying a translation type as well as the alias.
-

E2475 Cmd Rej: Either TYPE or TTN must be specified

Commands Used: **chg-gtt**, **dlt-gtt**, **dlt-tt**, **ent-gtt**, **rtrv-gtt**

The command was entered without either the **type** or **ttn** parameters specified. This command requires either the translation type (**type**) or the translation name (**ttn**) parameters to be specified.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** command.
 2. Re-enter the command specifying either the **type** or **ttn** parameters, using one of the values displayed by the **rtrv-tt** command.
-

E2477 Cmd Rej: This function is not yet supported

You attempted to enter a command that has not yet been developed and enabled. You may have made a clerical error.

Recovery

Re-enter the command that generated this error message.

If this error message appears again, refer to the *Commands Manual* for valid syntax usage.

E2478 Cmd Rej: Wild card entries are not allowed in this command

Commands Used: `chg-gta`, `chg-gtt`, `chg-map`, `dlt-gta`, `dlt-gtt`,
`dlt-map`, `dlt-tt`, `ent-gta`, `ent-gtt`, `ent-map`, `ent-tt`,
`rtrv-gta`, `rtrv-gtt`, `rtrv-map`, `rtrv-tt`

A wild card (*) was specified as a value for one or more of the parameters for this command. You cannot specify a wild card as a value for any of the parameters for these commands.

NOTE: When a 'wild card' is used to specify a parameter value '*' it indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '*'".

Recovery

Re-enter the command without specifying a wild card for any of the parameter values.

E2479 Cmd Rej: NGT must be specified when XLAT=DPCNGT

Commands Used: `ent-gtt`

You entered the translate indicator (`xlat`) specifying the value `dpcngt`, and the `ngt` parameter was not entered.

Recovery

Re-enter the `ent-gtt` command specifying both the `xlat=dpcngt` and the `ngt` parameters.

E2480 Cmd Rej: RI=GT must be specified when XLAT=DPCNGT

Commands Used: `ent-gta`, `ent-gtt`

You entered the translate indicator (`xlat`) parameter specifying the value `dpcngt`, and the routing indicator (`ri`) was entered specifying the value `ssn`.

Recovery

Re-enter the command specifying both the `xlat=dpcngt` and `ri=gt` parameters.

E2481 Cmd Rej: SSN must be specified when XLAT=DPCSSN

Commands Used: `ent-gta`, `ent-gtt`

You entered the translate indicator (`xlat`) specifying the value `dpcssn` and the subsystem number (`ssn`) was not entered.

Recovery

Re-enter the command specifying both the `xlat=dpcssn` and the `ssn` parameters.

E2484 Cmd Rej: SSN must be 1 if NSFI=AFTPC

Commands Used: `ent-scr-cdpa`

You entered the `nsfi=aftpc` parameter, and the `ssn` parameter is not equal to `1`. If the `nsfi=aftpc` parameter is entered, the `ssn` parameter must be equal to `1`.

Recovery

Perform one of the following:

- Re-enter the `ent-scr-cdpa` command specifying the `nsfi=aftpc` and the `ssn=1` parameters.
- OR
- Re-enter the `ent-scr-cdpa` command specifying the `nsfi=stop` parameter and the `ssn=1-255`.
-

E2485 Cmd Rej: All entered point code elements must be C if any are C

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`,
`dlt-scr-blkdpc`, `dlt-scr-blkopc`, `ent-scr-blkdpc`,
`ent-scr-blkopc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`

The command was entered with the one of the point code parameters (**ni**, **nc**, **ncm**, **zone**, **area**, **id**, **msa**, **ssa**, **sp**) equal to **c** (for “Continue”) and the other parameters not equal to **c**. If any of the point code parameters are equal to **c**, then all the point code parameters must be equal to **c**.

Whenever **c** for “continue” is entered for the first parameter, the other parameters will default to **c** in the database.

Recovery

Re-enter the command, specifying the value **c** for the point code parameters, and make sure that the specified point code parameters are of the same network type. Point code parameters **ni**, **nc**, and **ncm** are for ANSI point codes. Point code parameters **zone**, **area**, and **id** are for ITU-I point codes. Point code parameter **npc** is for ITU-N point codes. Point code parameters **msa**, **ssa**, and **sp** are for 24-bit ITU-N point codes.

E2486 Cmd Rej: NSFI must be STOP if COPY or REDIRECT are specified

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`,
`chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-dpc`, `chg-scr-opc`,
`chg-scrset`, `chg-scr-sio`, `chg-scr-tt`, `ent-scr-aftpc`,
`ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`,
`ent-scr-dpc`, `ent-scr-opc`, `ent-scrset`, `ent-scr-sio`,
`ent-scr-tt`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-dpc`,
`rtrv-scr-opc`, `rtrv-scrset`, `rtrv-scr-sio`, `rtrv-scr-tt`

You specified the **copy=yes**, the **redirect=yes**, or both parameters, and the value for the **nsfi** parameter was not **stop**. If the **copy=-yes**, the **redirect=yes**, or both parameters are specified, then the **nsfi=stop** parameter must also be specified.

Recovery

Perform one of the following:

- Re-enter the command specifying **nsfi=stop** and either or both of the **copy=yes** and **redirect=yes** parameters.

OR

- Re-enter the command specifying a value for the **nsfi** parameter not equal to **stop** and without the **copy=yes** or the **redirect=yes** parameter.
-

E2487 Cmd Rej: EPRI cannot be less than PRI

Commands Used: **chg-scr-sio, ent-scr-sio**

The specified **epri** value must be greater than or equal to the **pri** parameter.

Recovery

1. Display the **pri**. Enter the **rtrv-scr-sio** command. The allowed SIO information for the specified screening reference is displayed.
 2. Re-enter the command specifying a new value for the **epri** parameter, using the information displayed in step 1 to make the value of the **epri** greater than or equal to the **pri** value.
-

E2488 Cmd Rej: H0 and H1 must be specified for given SI

Commands Used: **chg-scr-sio, dlt-scr-sio, ent-scr-sio**

The service indicator (**si**) is less than or equal to **2**, and the heading code values **h0** and **h1** were not specified.

Recovery

Re-enter the command specifying the **si** equal to **2** or less and the heading code values **h0** and **h1**.

E2489 Cmd Rej: H0/H1 matches existing H0/H1 in given SR

Commands Used: **ent-scr-sio**

The specified heading code pair **h0/h1** cannot be in the range of any existing wild-carded **h0/h1** pair in the **sr, nic, and si** parameters combination.

NOTE: A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '*'".

Recovery

1. Enter the **rtrv-scr-sio** command to display the data for this screening reference.
 2. Re-enter the command specifying a value for the heading code **h0** and **h1** parameters that does not appear in the data displayed during step 1, or within a range of data displayed during step 1.
-

E2490 Cmd Rej: H0 and H1 cannot be specified for SI greater than 2

Commands Used: **chg-scr-sio**, **dlt-scr-sio**, **ent-scr-sio**,
rtrv-scr-sio

You cannot specify the **h0** and **h1** parameters if the value of the service indicator (**si**) is greater than 2.

Recovery

1. For service indicator values greater than 2, re-enter the command without specifying the **h0** and **h1** parameters.
 2. For service indicator values less than or equal to 2, re-enter the command specifying the **h0** and **h1** parameters.
-

E2491 Cmd Rej: NH0 and NH1 cannot be specified for NSI greater than 2

Commands Used: **chg-scr-sio**

You cannot specify the **nh0** and **nh1** parameters if the value of the new service indicator (**nsi**) is greater than 2.

Recovery

1. For new service indicator values greater than 2, re-enter the **chg-scr-sio** command without specifying the **nh0** and **nh1** parameters.
 2. For new service indicator values less than or equal to 2, re-enter the **chg-scr-sio** command specifying the **nh0** and **nh1** parameters.
-

E2492 Cmd Rej: The NSFI / RI combination is invalid

Commands Used: `chg-scr-cgpa`, `ent-scr-cgpa`

You specified a combination of values for the **ri** parameter and the **nsfi** parameter that is not allowed.

- If you specify **ri=gt**, you can only specify **nsfi=tt**
- If you specify **ri=dpc**, you can only specify only the **nsfi=cdpa**
- If you specify the **ri=***, you can specify either **nsfi=tt** or **nsfi=cdpa**

Recovery

Perform one of the following:

- Re-enter the command specifying **ri=gt** and **nsfi=tt**
OR
 - Re-enter the command specifying **ri=dpc** and **nsfi=cdpa**
OR
 - Re-enter the command specifying **ri=*** and either **nsfi=tt** or **nsfi=cdpa**
-

E2493 Cmd Rej: H1 must be wild card if H0 is wild card

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`,
`rtrv-scr-sio`

You cannot specify a wild-card (*) value for the **h0** parameter and not for the **h1** parameter.

NOTE: A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '***', which SEAS uses for "all and every entry in the database including the value '*1'".

Recovery

Perform one of the following:

- Re-enter the command without specifying the **h0** and **h1** parameters.
OR

- Re-enter the command specifying wild-card (asterisk) values for both the **h0** and **h1** parameters.

OR

- Re-enter the command specifying values for both the **h0** and **h1** parameters.

Call your Customer Care Center if this error message appears again

E2494 Cmd Rej: The NSFI is invalid for this screen type

Commands Used: `chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-dpc, chg-scr-opc, chg-scrset, chg-scr-sio, chg-scr-tt, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-dpc, ent-scr-opc, ent-scrset, ent-scr-sio, ent-scr-tt`

You specified a value for the **nsfi** parameter that is not allowed for this command.

Recovery

Re-enter the command specifying the correct value for the **nsfi** parameter. Refer to the *Commands Manual* for the correct parameter values.

E2495 Cmd Rej: Point codes contain invalid wild card combinations

Commands Used: `chg-scr-aftpc, chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, dlt-scr-aftpc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-cdpa, dlt-scr-cgpa, dlt-scr-destfld, dlt-scr-dpc, dlt-scr-opc, ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-opc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc`

This error message occurs under one of the following conditions:

NOTE: A 'wild card' is a term used to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for all and every entry in the database including the value '*'.

- If the **ni=*** and the **nc** or **ncm** are not.
- If the **nc=*** and the **ncm** is not.
- If the **nni=*** and the **nnc** or **nncm** are not.

- If the **nnc**=* and the **nncm** is not.
- If the **nni**=*, **nnc** and **nncm** are not given, and **nc** or **nncm** are not wild cards.
- If the **nnc**=*, **nncm** is not given, and the **nncm** is not wild.
- If the **zone**=* and the **area** and **id** are not.
- If the **area**=* and the **id** is not.
- If the **msa**=* and the **ssa** and **sp** are not.
- If the **ssa** is specified as an asterisk and the **sp** is not.

Recovery

1. If the **ni** is a wild card, re-enter the command specifying the **ni**, **nc**, and **nncm** as wild cards.
 2. If the **nc** is a wild card, re-enter the command specifying the **nc** and **nncm** as wild cards.
 3. If the **nnc** is a wild card, re-enter the command specifying the **nnc**, **nncm**, and **nncm** as wild cards.
 4. If the **nnc** is a wild card, re-enter the command specifying the **nnc** and **nncm** as wild cards.
 5. If **zone** is specified as an asterisk, re-enter the command specifying the **area** and **id** with an asterisk.
 6. If **area** is specified as an asterisk, re-enter the command specifying **id** with an asterisk.
 7. If **msa** is specified as an asterisk, re-enter the command specifying the **ssa** and **sp** with an asterisk.
 8. If **ssa** is specified as an asterisk, re-enter the command specifying **sp** with an asterisk.
-

E2496 Cmd Rej: NI, ZONE, MSA or NPC cannot be C - more than one exists

Commands Used: **dlt-scr-blkdpc**, **dlt-scr-blkopc**

An attempt was made to delete the point code **c-c-c**, or **npc=c**, from the screening reference, and the screening reference contains more than one entry. The point code **c-c-c**, or **npc=c**, cannot be deleted until all other entries in the screening reference have been deleted.

Recovery

Re-enter the command specifying different values for the **ni**, **nc**, **ncm** parameters for an ANSI point code, **zone**, **area**, **id** parameters for an ITU-I point code, **msa**, **ssa**, **sp** for a 24-bit ITU-N point code, or the **npc** parameter for an ITU-N point code.

E2497 Cmd Rej: NI, ZONE, MSA or NPC cannot be C for existing blocked SR

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`

The point code **c-c-c**, or **npc=c**, was specified for a SR (screening reference) that already exists. The point code **c-c-c**, or **npc=c**, can be specified only for a screening reference that does not exist. If a blocked screen reference exists, then **ni**, **zone**, **msa**, or **npc** cannot equal **c**. Point code **c-c-c** already exists for this blocked SR.

Recovery

Re-enter the command specifying values other than **c** for the point code.

E2498 Cmd Rej: Last entry in given SR is ref'ed by another screen

Commands Used: `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-dpc`, `dlt-scr-isup`, `dlt-scr-opc`, `dlt-scr-sio`, `dlt-scr-tt`

The specified screening reference contains only one entry. If this screening reference is referenced by another screen, it cannot be deleted.

Recovery

1. Find which screen is referencing the specified screening reference; enter one of the following commands with their parameter to display the screen set data:
 - `rtrv-scr-aftpc`, for the `dlt-scr-aftpc` command
 - `rtrv-scr-blkdpc`, for the `dlt-scr-blkdpc` command
 - `rtrv-scr-blkopc`, for the `dlt-scr-blkopc` command
 - `rtrv-scr-cdpa`, for the `dlt-scr-cdpa` command
 - `rtrv-scr-cgpa`, for the `dlt-scr-cgpa` command
 - `rtrv-scr-dpc`, for the `dlt-scr-dpc` command

- `rtrv-scr-opc`, for the `dlt-scr-opc` command
 - `rtrv-scrset`, for the `dlt-scrset` command
 - `rtrv-scr-sio`, for the `dlt-scr-sio` command
 - `rtrv-scr-tt`, for the `dlt-scr-tt` command
2. When the screen is found, change the `nsr` parameter to a value other than the specified screening reference in the command that generated this error message. Enter one of the following commands:
 - `chg-scr-aftpc`, for the `dlt-scr-aftpc` command
 - `chg-scr-blkdpc`, for the `dlt-scr-blkdpc` command
 - `chg-scr-blkopc`, for the `dlt-scr-blkopc` command
 - `chg-scr-cdpa`, for the `dlt-scr-cdpa` command
 - `chg-scr-cgpa`, for the `dlt-scr-cgpa` command
 - `chg-scr-dpc`, for the `dlt-scr-dpc` command
 - `chg-scr-opc`, for the `dlt-scr-opc` command
 - `chg-scrset`, for the `dlt-scrset` command
 - `chg-scr-sio`, for the `dlt-scr-sio` command
 - `chg-scr-tt`, for the `dlt-scr-tt` command
 3. Repeat steps 1 and 2 for any other screens found referencing the screening reference specified in the command that generated this error message.
 4. Re-enter the command that generated this error message.
-

E2499 Cmd Rej: Maximum number of rules exceeded in screen set

Commands Used: `chg-scr-aftpc`, `ent-scr-aftpc`, `chg-scr-blkdpc`, `ent-scr-blkdpc`, `chg-scr-blkopc`, `ent-scr-blkopc`, `chg-scr-cdpa`, `ent-scr-cdpa`, `chg-scr-cgpa`, `ent-scr-cgpa`, `chg-scr-dpc`, `ent-scr-dpc`, `chg-scr-opc`, `ent-scr-opc`, `chg-scrset`, `ent-scrset`, `chg-scr-sio`, `ent-scr-sio`, `chg-scr-tt`, `ent-scr-tt`

You exceeded the available capacity for the screen set. If the screen set reaches 100% capacity (indicated by the "100% full" message), the EAGLE 5 ISS will allow subsequent entries. An error will occur, however, when downloading the screen set to the card. Screen sets should not exceed 100% capacity.

Recovery

Delete screen set entries until the capacity is below 100%, using the appropriate version of the **dlt-scr-** command.

Call your Customer Care Center if this error message appears again.

E2500 Cmd Rej: Maximum number of screen sets exceeded

Commands Used: **ent-scrset**

The system can contain up to **63** user-definable screen sets. The attempt to add a screen set exceeds this limit. To add another screen set, one has to be deleted.

Recovery

1. Display the screen sets. Enter the **rtrv-scrset** command. Select a screen set to be deleted.
 2. Display the linksets. Enter the **rtrv-ls** command.
 3. From the linksets that reference a screen set (field SCRSET), record the data from the linkset(s) that reference the screen set to be deleted.
 4. Change the screen set reference of the linkset(s), from the screen set to be deleted to another screen set. Enter the **chg-ls** command.
 5. Delete the screen set. Enter the **dlt-scrset** command.
 6. Add the new screen set. Enter the command that generated this error message.
-

E2501 Cmd Rej: Mixed point code types are not allowed

Commands Used: **chg-appl-rtkey, ent-appl-rtkey, ent-scr-blkdpc, chg-scr-blkdpc, dlt-scr-blkdpc, rtrv-scr-blkdpc, ent-scr-blkopc, chg-scr-blkopc, dlt-scr-blkopc, rtrv-scr-blkopc, ent-scr-dpc, chg-scr-dpc, dlt-scr-dpc, rtrv-scr-dpc, ent-scr-opc, chg-scr-opc, dlt-scr-opc, rtrv-scr-opc, ent-scr-aftpc, chg-scr-aftpc, dlt-scr-aftpc, rtrv-scr-aftpc, ent-scr-cdpa, chg-scr-cdpa, dlt-scr-cdpa, rtrv-scr-cdpa, ent-scr-cgpa, chg-scr-cgpa, dlt-scr-cgpa, rtrv-scr-cgpa, ent-scr-destfld, chg-scr-destfld, rtrv-scr-destfld**

The command was entered with a point code that contains different network types. Point codes are specified by the following parameters:

ANSI point code – **ni, nc, ncm** and for the enter and change commands — **nni, nnc, nncm**

ITU-I point code – **zone, area, id** and for the enter and change commands — **nzone, narea, nid**

ITU-N point code – **npc** and for the enter and change commands — **nnpc**

24-bit ITU-N point code - **msa, ssa, sp** and for the enter and change commands — **nmsa, nssa, nsp**

An example of a point code containing different network types (i.e., mixed types of point codes) is **ni-area-npc**. This is not allowed. If any of the enter and change commands are entered, an existing point code of one network type can be changed to another network type—as long as all the proper parameters are used.

Recovery

Re-enter the command specifying the proper values for point codes.

ANSI point code – **ni, nc, ncm** and for the enter and change commands — **nni, nnc, nncm**

ITU-I point code – **zone, area, id** and for the enter and change commands — **nzone, narea, nid**

ITU-N point code – **npc** and for the enter and change commands — **nnpc**

24-bit ITU-N point code - **msa, ssa, sp** and for the enter and change commands — **nmsa, nssa, nsp**

E2502 Cmd Rej: NSR cannot be specified if COPY or REDIRECT are specified

Commands Used: chg-scr-blkdpc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-dpc, rtrv-scr-opc, rtrv-scrset, rtrv-scr-sio, rtrv-scr-tt

You cannot specify the **nsr** parameter if the **copy=yes** and / or the **redirect=yes** parameters are specified.

Recovery

Perform one of the following:

- Re-enter the command specifying the **copy=yes** and / or the **redirect=yes** parameters, without specifying the **nsr** parameter.

OR

- Re-enter the command specifying the **nsr** parameter, without specifying the **copy=yes** and / or the **redirect=yes** parameters.
-

E2503 Cmd Rej: NC cannot be zero when NI is less than 6

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-cdpa`,
`chg-scr-cgpa`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`,
`dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`,
`dlt-scr-dpc`, `dlt-scr-opc`, `ent-scr-blkdpc`, `ent-scr-blkopc`,
`ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`, `ent-scr-opc`,
`rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-dpc`, `rtrv-scr-opc`

The network cluster number must be 1-255, because the network identifier entered is less than or equal to 5.

Recovery

Re-enter the command specifying the proper network cluster number or the proper network identifier.

Refer to the *Commands Manual* to find correct values.

E2504 Cmd Rej: New/existing NSFI=AFTPC requires new/existing SSN=1

Commands Used: `chg-scr-cdpa`

You entered the **nsfi=aftpc** parameter and the **ssn** parameter is not equal to 1. If you enter the **nsfi=aftpc** parameter, then **ssn** must be equal to 1.

Recovery

Perform one of the following:

- Re-enter the **chg-scr-cdpa** command specifying the **nsfi=aftpc** and the **ssn=1** parameters.

OR

- Re-enter the **chg-scr-cdpa** command specifying the **nsfi=stop** parameter and the **ssn** parameter equal to **1-255**.
-

E2505 Cmd Rej: NH0 and NH1 must be specified for given NSI

Commands Used: chg-scr-sio

The new service indicator (**nsi**) specified is less than or equal to **2** and the **nh0** and **nh1** parameters have not been specified. If the new service indicator is less than or equal to **2**, and the old **si** was greater than **2**, the **nh0** and **nh1** parameters must be specified.

Recovery

1. For service indicator values greater than **2**, re-enter the command without specifying the **nh0** and **nh1** parameters.
 2. For service indicator values less than or equal to **2**, re-enter the command specifying the **nh0** and **nh1** parameters.
-

E2506 Cmd Rej: New H0/H1 matches existing wild carded H0/H1 in given SR

Commands Used: chg-scr-sio

Either the **h0** or **h1**, or both, have been specified where they had previously been set (by default) to be wild-carded.

NOTE: A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '**', which SEAS uses for "all and every entry in the database including the value '*'".

Recovery

Change the **h0** and/or **h1** settings. Enter the **chg-scr-sio** command.

E2507 Cmd Rej: NH0 and NH1 cannot be specified for SI greater than 2

Commands Used: `chg-scr-sio`

You cannot specify a value for the service indicator that is greater than 2, and the **nh0** and **nh1** parameters.

Recovery

Perform one of the following:

- Re-enter the `chg-scr-sio` command specifying a value for the **si** parameter greater than 2, without specifying the **nh0** and **nh1** parameters.
- OR
- Re-enter the `chg-scr-sio` command specifying a value for the **si** parameter less than 2 and the **nh0** and **nh1** parameters.
-

E2508 Cmd Rej: SCMGFID is invalid

Commands Used: `chg-scr-cdpa`, `dlt-scr-cdpa`, `ent-scr-cdpa`,
`rtrv-scr-cdpa`

You probably did one of the following:

- Specified the **ssn=1** parameter and failed to specify the **scmgfid** parameter
- OR
- Specified the **ssn** parameter with a value other than 1 and specified the **scmgfid** parameter

These combinations are not allowed. You **must** specify the **scmgfid** parameter if you specify the **ssn=1** parameter. You **must not** specify the **scmgfid** parameter if you specify a value other than 1 for the **ssn** value.

Recovery

Perform one of the following:

- Re-enter the command specifying both the **ssn=1** parameter and the **scmgfid** parameter.
- OR
- Re-enter the command specifying the **ssn** parameter with a value other than 1, and without specifying the **scmgfid** parameter.
-

E2509 Cmd Rej: NH1 must be wild card if NH0 is wild card

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`,
`rtrv-scr-sio`

You specified a wild-card value for the **nh0** parameter but not the **nh1** parameter.

NOTE: A 'wild card' is a term to describe the parameter value '*' that indicates the full range of values. Do not confuse this usage with the parameter value '***', which SEAS uses for "all and every entry in the database including the value '*!'".

Recovery

Perform one of the following:

- Re-enter the command without specifying the **nh0** and **nh1** parameters.
OR
- Re-enter the command specifying the **nh0** and **nh1** parameters both assigned to wild-card (indicated by an asterisk) values.
OR
- Re-enter the command specifying both the **nh0** and **nh1** parameters assigned to specific values.

Call your Customer Care Center if this error message appears again.

E2510 Cmd Rej: NI is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`,
`chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`,
`chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`,
`dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`, `dlt-scr-dpc`,
`dlt-scr-opc`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`,
`ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`,
`ent-scr-opc`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

You entered a combination of the parameters **ni**, **nc**, and/or **ncm** that is not allowed. Use the following guidelines in determining what combinations of these parameters you need to enter:

- If **ni**, **nc**, or **ncm** is specified, a screening reference must be specified.
- If you specify the **ni** parameter as an asterisk (`ni=*`) or as a range, you must specify the **nc** and **ncm** parameters as an asterisk or as the full range **000-255**.

- If you specify a single value for the **nc** parameter, you also must specify a single value for the **ni** parameter.
- If you specify a range for the **nc** parameter, you must specify a single value for the **ni** parameter, and you must specify the **ncm** parameter as an asterisk (**ncm=***) or the full range of **000-255**.
- If you specify a single value, or a range other than the full range of **000-255**, for the **ncm** parameter, you must specify the **ni** and the **nc** parameters with a single value.

Recovery

Re-enter the command specifying the appropriate combinations of parameters as outlined in the preceding list.

E2511 Cmd Rej: NC is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`, `rept-meas`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

For the gateway screening commands:

You entered a combination of the parameters **ni**, **nc**, and/or **ncm** that is not allowed. Use the following guidelines in determining what combinations of these parameters you need to enter:

- If **ni**, **nc**, or **ncm** is specified, a screening reference must be specified.
- If you specify the **ni** parameter as an asterisk (**ni=***) or as a range, you must specify the **nc** and **ncm** parameters as an asterisk or as the full range **000-255**.
- If you specify a single value for the **nc** parameter, you also must specify a single value for the **ni** parameter.
- If you specify a range for the **nc** parameter, you must specify a single value for the **ni** parameter, and you must specify the **ncm** parameter as an asterisk (**ncm=***) or the full range of **000-255**.

- If you specify a single value, or a range other than the full range of **000-255**, for the **ncm** parameter, you must specify the **ni** and the **nc** parameters with a single value.
- If you specify the **nc** parameter as an asterisk (**nc=***), you must specify the **ncm** parameter as an asterisk or as the full range **000-255**.

For the **rept-meas** command:

You specified the **origininc** parameter and the **ni** and **nc** parameters, and the measurements data is not available.

Recovery

Re-enter the gateway screening command specifying the appropriate combinations of parameters as outlined in the preceding list.

E2512 Cmd Rej: NCM is invalid

Commands Used: **chg-scr-aftpc, chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, dlt-scr-aftpc, dlt-scr-blkdpc, dlt-scr-blkopc, dlt-scr-cdpa, dlt-scr-cgpa, dlt-scr-destfld, dlt-scr-dpc, dlt-scr-opc, ent-scr-aftpc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-cdpa, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-opc, rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc**

You entered a combination of the parameters **ni**, **nc**, and/or **ncm** that is not allowed. Use the following guidelines in determining what combinations of these parameters you need to enter:

- If you specify the **ni** parameter as an asterisk (**ni=***) or as a range, you must specify the **nc** and **ncm** parameters as an asterisk or as the full range **000-255**.
- If you specify a range for the **nc** parameter, you must specify a single value for the **ni** parameter, and you must specify the **ncm** parameter as an asterisk (**ncm=***) or the full range of **000-255**.
- If you specify a single value, or a range other than the full range of **000-255**, for the **ncm** parameter, you must specify the **ni** and the **nc** parameters with a single value.
- If you specify the **nc** parameter as an asterisk (**nc=***), you must specify the **ncm** parameter as an asterisk or as the full range **000-255**.

Recovery

Re-enter the command specifying the appropriate combinations of parameters as outlined in the preceding list.

E2514 Cmd Rej: PC/SSN/RI/SCCPMT already exists in given SR

Commands Used: `chg-scr-cgpa`, `ent-scr-cgpa`

While holding the value of the screening reference parameter `sr` constant, you attempted to change the value of one of the other parameters. But, the other parameters already have the value you assigned to them.

Recovery

1. Enter the `rtrv-scr-cgpa` command to acquire the current state of the parameters with the given `sr` parameter.
 2. Re-enter the command that generated this error message, using appropriate parameter values acquired in step 1.
-

E2515 Cmd Rej: PC/SSN/RI/SCCPMT does not exist in given SR

Commands Used: `chg-scr-cdpa`, `dlt-scr-cdpa`, `rtrv-scr-cdpa`,
`dlt-scr-cdpa`, `dlt-scr-cgpa`,

You entered this command specifying the `pc`, `ssn`, `ri`, or `sccpmt` parameter set to a value that does not exist in the screening reference. You cannot change, retrieve, or delete an entry that does not exist.

Recovery

1. Enter the `rtrv-scr-cgpa` command without specifying the `pc`, `ssn`, `ri`, or `sccpmt` parameter, to acquire the current state of the parameters.
 2. Re-enter the command that generated this error message, using appropriate `pc`, `ssn`, or `scmgfid` parameter values acquired in step 1.
-

E2516 Cmd Rej: PC/SSN/SCMG already exists in given SR

Commands Used: `chg-scr-cdpa`, `ent-scr-cdpa`

While holding the value of the screening reference parameter **sr** constant, you attempted to change the value of one of the other parameters. But, the new parameters already exist in the database.

You cannot add a CDPA entry that matches any specific or range or asterisk entry that already exists in the specified screening table.

Recovery

1. Enter the `rtrv-scr-cgpa` command to acquire the current state of the parameters.
 2. Re-enter the command that generated this error message, using appropriate parameter values acquired in step 1.
-

E2517 Cmd Rej: PC/SSN/SCMGFID does not exist in given SR

Commands Used: `chg-scr-cdpa`, `dlt-scr-cdpa`, `ent-scr-cdpa`,
`rtrv-scr-cdpa`, `dlt-scr-cdpa`, `dlt-scr-cgpa`,

You entered this command specifying the **pc**, **ssn**, or **scmgfid** parameter set to a value that does not exist in the screening reference.

Recovery

1. Enter the `rtrv-scr-cgpa` command without specifying the **pc**, **ssn**, or **scmgfid** parameter, to acquire the current state of the parameters.
 2. Re-enter the command that generated this error message, specifying the appropriate **pc**, **ssn**, or **scmgfid** parameter values acquired in step 1.
-

E2518 Cmd Rej: NNIC, NSI, and NH0/NH1 entry already exists in given SR

Commands Used: `chg-scr-sio`

For the **nnic**, **nsi**, **nh0**, and **nh1** parameters to be changed, the values cannot exist in the specified screening reference.

Recovery

1. Verify that the values for the **nnic**, **nsi**, **nh0**, and **nh1** parameters have been entered correctly and re-enter the `chg-scr-sio` command.

2. If the values for these parameters are entered correctly and this error message appears again, enter the **rtrv-scr-sio:sr=** command to display the allowed SIO information for the specified screening reference.
 3. Re-enter the **chg-scr-sio** command specifying different values for the **nnic**, **nsi**, **nh0**, and **nh1** parameters that do not match those displayed in step 2.
-

E2519 Cmd Rej: ISUPMT/TUPMT already exists in given SRI

Commands Used: **chg-scr-isup**, **ent-scr-isup**

You attempted to specify an allowed ISUP screening reference in a given **sr** with an existing ISUPMT (ISUP message type) or an allowed ISUP screening reference in a given SR with an existing TUPMT (TUP message type). Duplicate ISUPMTs and TUPMTs are not permitted.

Recovery

1. Verify the values for the **sr** and **isupmt** parameters and the **sr** and **tupmt** parameters have been entered correctly, and re-enter the command.
 2. If the value for these parameters have been entered correctly and this error message appears again, enter the **rtrv-scr-isup:sr=** command to display the allowed ISUP information for the specified screening reference.
 3. Re-enter the command specifying a different values for the parameters, making certain that the values do not duplicate those displayed in step 2.
-

E2520 Cmd Rej: ISUPMT/TUPMT does not exist in given SR

Commands Used: **chg-scr-isup**, **dlt-scr-isup**

You specified an allowed ISUP or TUP screening reference in a given **sr** for an ISUPMT (ISUP message type) or for an TUPMT (TUP message type) that does not exist in the database. A valid **isupmt** or **tupmt** parameter is required for this command.

Recovery

Verify the **isupmt** or **tupmt** parameter, and re-enter the command specifying an existing **isupmt** or **tupmt** parameter.

E2521 Cmd Rej: NIC must be specified for given SI**Commands Used: rtrv-scr-sio**

The command was entered with a service indicator value (**si**), and the network indicator code value (**nic**) was not specified. The **si** parameter cannot be specified if the **nic** parameter is not specified.

Recovery

1. Display all the network indicator codes and service indicators in the database. Enter the **rtrv-scr-sio** command specifying no parameters.
 2. If you wish to display a particular service indicator entry, enter the **rtrv-scr-sio** command specifying the values for both the **nic** and **si** parameters shown in output of step 1.
-

E2522 Cmd Rej: NIC does not exist for given SR**Commands Used: chg-scr-sio, dlt-scr-sio, rtrv-scr-sio**

The command was entered, and the combination of the screening reference (**sr**) and network indicator code (**nic**) could not be found in the database.

Recovery - rtrv-scr-sio

Re-enter the **rtrv-scr-sio** command specifying no parameters.

Recovery - chg-scr-sio, dlt-scr-sio

1. Display the allowed SIO information in the database. Enter the **rtrv-scr-sio** command.
 2. Re-enter the command specifying a screening reference (**sr**) and network indicator code (**nic**) combination found in the output of step 1.
-

E2525 Cmd Rej: NI, ZONE, MSA or NPC must be C when creating new blocked SR**Commands Used: ent-scr-blkdpc, ent-scr-blkopc**

To create a new blocked DPC or OPC screening reference, you must specify **ni**, **zone**, **msa** with the point code **c-c-c** or **npc** with **c**. The first entry in a new screen reference for a blocked DPC or OPC must be the point code **c-c-c**, or **npc=c**.

Recovery

Re-enter the command specifying the point code **c-c-c** for an ANSI, ITU-I, or 24-bit ITU-N point code, or **npc=c** for an ITU-N point code.

E2526 Cmd Rej: All new PC parms must be null if NI, ZONE, MSA or NPC = C

Commands Used: **chg-scr-blkdpc, chg-scr-blkopc**

If the **ni, zone, msa, or npc** point codes are set to **c**, all new point code parameters must be null. The point code **c-c-c** cannot be changed to a numbered point code.

Recovery

Re-enter the command specifying new point code parameters as null values if the **ni, zone, msa, or npc** point codes are set to **c**.

E2527 Cmd Rej: C value not allowed

Commands Used: **chg-scr-aftpc, chg-scr-blkdpc, chg-scr-blkopc, chg-scr-cdpa, chg-scr-cgpa, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, dlt-scr-aftpc, dlt-scr-destfld, dlt-scr-dpc, dlt-scr-opc, ent-scr-aftpc, ent-scr-cgpa, ent-scr-destfld, ent-scr-dpc, ent-scr-opc, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc**

You specified a new point code that contained the value **c**. A point code with the value **c** is not allowed when changing a screening entry whose **nsfi** is equal to **fail** for these parameters: **nni-nnc-nncm, nzone-narea-nid, nmsa-nssa-nsp, or nnpc**.

Recovery

Re-enter the command specifying values other than **c** for the new point code.

E2528 Cmd Rej: No match on AREA or SSA parameter during retrieve

Commands Used: **rtrv-scr-sio, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc, rtrv-scr-aftpc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-dpc, rtrv-scr-opc**

No match was found for either the **area** or **ssa** parameter.

Recovery

Re-enter the command specifying the screening reference to show all area values, as well as other values for the screening reference (**sr**).

E2529 Cmd Rej: No match on EPRI parameter during retrieve

Commands Used: rtrv-scr-sio

The ending priority (**epri**) was not found.

Recovery

Re-enter the **rtrv-scr-sio** command specifying the screening reference to show all ending priorities, as well as other values for the screening reference.

E2530 Cmd Rej: No match on H0 parameter during retrieve

Commands Used: rtrv-scr-sio

The h0 heading code (**h0**) was not found.

Recovery

Re-enter the **rtrv-scr-sio** command specifying the screening reference to show all **h0** heading codes, as well as other values for the screening reference.

E2531 Cmd Rej: No match on H1 parameter during retrieve

Commands Used: rtrv-scr-sio

The h1 heading code (**h1**) was not found.

Recovery

Re-enter the **rtrv-scr-sio** command specifying the screening reference to show all h1 heading codes, as well as other values for the screening reference.

E2532 Cmd Rej: No match on ID or SP parameter during retrieve

Commands Used: `rtrv-scr-sio`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scr-aftpc`,
`rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-destfld`,
`rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the **id** or **sp** parameter.

Recovery

Re-enter the `rtrv-scr-sio` command specifying the screening reference to show all ID values, as well as other values for the screening reference.

E2533 Cmd Rej: No match on NC parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match for the network cluster (**nc**) parameter was found.

Recovery

Re-enter the command specifying the screening reference to show all network clusters, as well as other values for the screening reference.

E2534 Cmd Rej: No match on NCM parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the network cluster member (**ncm**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all network cluster members, as well as other values for the screening reference.

E2535 Cmd Rej: No match on NI parameter during retrieve

Commands Used: `rept-meas`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

For the gateway screening commands, no match was found for the network identifier (**ni**) parameter.

For the `rept-meas` command, you specified the **origini** parameter and the **ni** parameter, and the measurements data is not available.

Recovery - Gateway Screening commands

Re-enter the command specifying the screening reference, to show all network identifiers as well as other values for the screening reference.

Recovery - `rept-meas`

1. Verify that you entered the correct **origini** and **ni** parameter values in the command.
2. Re-enter the `rept-meas` command.

Contact your Customer Care Center if this error message appears again.

E2536 Cmd Rej: No match on NIC parameter during retrieve

Commands Used: `rtrv-scr-sio`

The specified network indicator code (**nic**) parameter was not found.

Recovery

Enter the `rtrv-scr-sio:all=yes` command to show all **nic** values as well as other values for the screening reference.

E2537 Cmd Rej: No match on NPC parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the national point code (**npc**) parameter.

Recovery

Re-enter the **rtrv-scr-sio** command specifying the screening reference to show all national point codes, as well as other values for the screening reference.

E2538 Cmd Rej: No match on NSFI parameter during retrieve

Commands Used: **rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc, rtrv-scrset, rtrv-scr-sio, rtrv-scr-tt**

No match was found for the next screening function identifier (**nsfi**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all next screening function identifiers, as well as other values for the screening reference.

E2539 Cmd Rej: No match on NSR parameter during retrieve

Commands Used: **rtrv-scr-aftpc, rtrv-scr-blkdpc, rtrv-scr-blkopc, rtrv-scr-cdpa, rtrv-scr-cgpa, rtrv-scr-destfld, rtrv-scr-dpc, rtrv-scr-opc, rtrv-scrset, rtrv-scr-sio, rtrv-scr-tt**

No match was found for the next screen reference (**nsr**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all next screening function identifiers, as well as other values for the screening reference.

E2540 Cmd Rej: No match on PRI parameter during retrieve

Commands Used: **rtrv-scr-sio**

The message priority (**pri**) was not found.

Recovery

Re-enter the **rtrv-scr-sio** command specifying the screening reference to show all message priorities, as well as other values for the screening reference.

E2541 Cmd Rej: No match on RI parameter during retrieve

Commands Used: **rtrv-scr-cgpa**

No match was found for the routing indicator (**ri**) parameter.

Recovery

Re-enter the **rtrv-scr-cgpa** command specifying the screening reference to show all routing indicators, as well as other values for the screening reference.

E2542 Cmd Rej: No match on SI parameter during retrieve

Commands Used: **rtrv-scr-sio**

The service indicator (**si**) was not found.

Recovery

Re-enter the **rtrv-scr-sio** command specifying the screening reference to show all service indicators, as well as other values for the screening reference.

E2543 Cmd Rej: No match on SSN parameter during retrieve

Commands Used: **rtrv-scr-aftpc**, **rtrv-scr-cdpa**, **rtrv-scr-cgpa**

No match was found for the subsystem number (**ssn**) parameter.

Recovery

Re-enter the command specifying the screening reference to show all subsystem numbers, as well as other values for the screening reference.

E2544 Cmd Rej: No match on TYPE parameter during retrieve

Commands Used: `rtrv-scr-tt`

No match was found for the translation type (**type**) parameter.

Recovery

Re-enter the `rtrv-scr-tt` command specifying the screening reference to show all translation types, as well as other values for the screening reference.

E2545 Cmd Rej: No match on ZONE or MSA parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scr-sio`

No match was found for the **zone** or **msa** parameter.

Recovery

Re-enter the command specifying the screening reference to show all **zone** values, as well as other values for the screening reference.

E2546 Cmd Rej: NSFI must be specified

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`

You specified the point code equal to **c-c-c** and the **nsfi** parameter was not specified. You must specify the **nsfi** parameter if the point code is **c-c-c**.

Recovery

Re-enter the command along with the **nsfi** parameter.

E2547 Cmd Rej: NSFI must not be FAIL

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`,
`ent-scr-blkdpc`, `ent-scr-blkopc`

You specified the point code equal to `c-c-c` and the `nsfi` parameter equal to `fail`. The `nsfi` parameter cannot be `fail` if the point code is `c-c-c`. If the SR (screen reference) does not exist, you must correct the command parameters; a new BLKPOPC screening table will be created.

Recovery

Re-enter the command specifying:

- The `ni`, `zone`, `msa`, or `npc` parameter equal to `c`
- The `nsfi` parameter equal to any value other than `fail`.

For more information about the command, refer to the *Commands Manual*.

E2548 Cmd Rej: NSFI must be STOP

Commands Used: `chg-scr-aftpc`, `chg-scr-isup`, `ent-scr-aftpc`,
`ent-scr-isup`

You specified the `nsfi` parameter specifying a value that is not allowed for this command.

Recovery

Re-enter the command specifying the `nsfi=stop` parameter. The value `stop` is the only value that can be specified for the `nsfi` parameter.

E2549 Cmd Rej: NSFI must be FAIL

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`

You specified the point code not equal to `c-c-c` and the `nsfi` parameter not equal to `fail`. If the point code is not `c-c-c`, the `nsfi` must be `fail`.

Recovery

Re-enter the command specifying the `nsfi` parameter equal to `fail`.

E2550 Cmd Rej: NSFI / NSR cannot be specified

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`,
`rtrv-scr-aftpc`, `rtrv-scr-cgpa`, `rtrv-scr-opc`, `rtrv-scrset`

You specified the **nsfi** equal to **stop** or **fail**, and the **nsr** parameter was specified. If the **nsfi** is **stop** or **fail**, the **nsr** cannot be specified.

Recovery

Re-enter the command specifying the **nsfi** equal to **stop** or **fail**, without specifying the **nsr** parameter.

E2551 Cmd Rej: NSI must be specified for given NNIC

Commands Used: `chg-scr-sio`

The command was entered with a new network indicator code (**nnic**), and a new service indicator (**nsi**) has not been specified. If a new service indicator is specified, a new network indicator code must be specified.

Recovery

Re-enter the `chg-scr-sio` command specifying either both the **nnic** and **nsi** parameters, or neither the **nnic** and **nsi** parameters.

E2552 Cmd Rej: NSFI and NSR do not reference an existing screen

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`,
`chg-scr-cgpa`, `chg-scr-dpc`, `chg-scr-opc`, `chg-scrset`,
`chg-scr-sio`, `chg-scr-tt`, `ent-scr-blkdpc`, `ent-scr-blkopc`,
`ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`, `ent-scr-opc`,
`ent-scrset`, `ent-scr-sio`, `ent-scr-tt`

The values specified for the **nsfi** and **nsr** parameters do not reference an existing screen.

Recovery

1. Verify that the **nsfi** and **nsr** parameters were entered correctly, and re-enter the command.

2. If the **nsfi** and **nsr** were entered correctly and this error message appears again, display the screen set data. Enter one of the following commands with these parameters:
 - **rtrv-scr-blkdpc**, for the **chg-scr-blkdpc** command and **nsfi=blkdpc** parameter
 - **rtrv-scr-blkopc**, for the **chg-scr-blkopc** command and **nsfi=blkopc** parameter
 - **rtrv-scr-cdpa**, for the **chg-scr-cdpa** command and **nsfi=cdpa** parameter
 - **rtrv-scr-cgpa**, for the **chg-scr-cgpa** command and **nsfi=cgpa** parameter
 - **rtrv-scr-dpc**, for the **chg-scr-dpc** command and **nsfi=dpc** parameter
 - **rtrv-scr-opc**, for the **chg-scr-opc** command and **nsfi=opc** parameter
 - **rtrv-scrset**, for the **chg-scrset** and **ent-scrset** commands
 - **rtrv-scr-sio**, for the **chg-scr-sio** command and **nsfi=sio** parameter
 - **rtrv-scr-tt**, for the **chg-scr-tt** command and **nsfi=tt** parameter
 3. Re-enter the command specifying the correct **nsfi** and **nsr** parameters displayed in step 2.
-

E2553 Cmd Rej: NSR must be specified for given NSFI

Commands Used: **chg-scr-blkdpc**, **chg-scr-blkopc**, **chg-scr-cdpa**, **chg-scr-cgpa**, **chg-scr-dpc**, **chg-scr-opc**, **chg-scrset**, **chg-scr-sio**, **chg-scr-tt**, **ent-scr-blkdpc**, **ent-scr-blkopc**, **ent-scr-cdpa**, **ent-scr-cgpa**, **ent-scr-dpc**, **ent-scr-opc**, **ent-scrset**, **ent-scr-sio**, **ent-scr-tt**

You specified the **nsfi** parameter equal to a value other than **stop** and the **nsr** parameter was not specified or, for the **chg-scr-blkdpc**, **chg-scr-blkopc**, **ent-scr-blkdpc**, and **ent-scr-blkopc** commands, You specified the **nsfi** parameter equal to a value other than **fail**, and the **nsr** parameter was not specified. The **nsr** parameter must be specified if the value of the **nsfi** parameter is anything other than **stop** or **fail**.

Recovery

Re-enter the command specifying the **nsr** parameter.

E2554 Cmd Rej: NSR cannot be specified when NSFI is STOP or FAIL

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-isup`, `chg-scr-opc`, `chg-scrset`, `chg-scr-sio`, `chg-scr-tt`, `dlt-scr-cgpa`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-isup`, `ent-scr-opc`, `ent-scrset`, `ent-scr-sio`, `ent-scr-tt`, `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-isup`, `rtrv-scr-opc`, `rtrv-scr-tt`

The `nsr` parameter cannot be specified if `nsfi=stop` or `nsfi=fail`.

Recovery

Re-enter the command specifying the `nsfi=stop` or `nsfi=fail`, and without specifying the `nsr` parameter.

E2555 Cmd Rej: Point code does not exist in given SR

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`

The point code defined by the `ni`, `nc`, and `ncm` parameters is not defined in the specified screening reference (NPC, the ITU-N standard, or zone area ID, the ITU-I standard). The point code must be in the given screening reference.

Refer to the command in the *Commands Manual* for information on the correct values.

Recovery

1. Verify the point codes for the given screening reference. Enter one of the following commands with the given screening reference:
 - `rtrv-scr-blkdpc`, for the `chg-scr-blkdpc` and `dlt-scr-blkdpc` commands
 - `rtrv-scr-blkopc`, for the `chg-scr-blkopc` and `dlt-scr-blkopc` commands

- `rtrv-scr-dpc`, for the `chg-scr-dpc` and `dlt-scr-dpc` commands
 - `rtrv-scr-opc`, for the `chg-scr-opc` and `dlt-scr-opc` commands
2. Re-enter the command specifying one of the point codes shown in step 1.
-

E2556 Cmd Rej: A complete point code must be entered

Commands Used: `ent-scr-aftpc`, `chg-scr-aftpc`, `dlt-scr-aftpc`,
`ent-scr-blkdpc`, `chg-scr-blkdpc`, `dlt-scr-blkdpc`,
`ent-scr-blkopc`, `chg-scr-blkopc`, `dlt-scr-blkopc`,
`ent-scr-cdpa`, `chg-scr-cdpa`, `dlt-scr-cdpa`, `ent-scr-cgpa`,
`chg-scr-cgpa`, `dlt-scr-cgpa`, `ent-scr-dpc`, `chg-scr-dpc`,
`dlt-scr-dpc`, `ent-scr-opc`, `chg-scr-opc`, `dlt-scr-opc`,
`ent-scr-destfld`, `chg-scr-destfld`, `dlt-scr-destfld`

The command was entered without all the necessary parameters needed to define a point code. These commands require that a point code be entered, and that the point code must be defined by all the necessary parameters for a point code of a particular network type.

A complete point code must be entered using one and only one of the four point code forms represented as **ni-nc-ncm**, **zone-area-id**, **msa-ssa-sp**, or **npc**. The only exception is the special case of entering **c** for "Continue" in the commands that allow it.

Recovery

Re-enter the command specifying a point code containing the following parameters:

ANSI point codes – **ni**, **nc**, **ncm**

ITU-I point codes – **zone**, **area**, **id**

ITU-N point codes – **npc**

24-bit ITU-N point codes – **msa**, **ssa**, **sp**

E2557 Cmd Rej: GWS/GTT shared table is full

Commands Used: `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-dpc`,
`ent-scr-opc`, `ent-scr-aftpc`, `ent-scr-cdpa`, `ent-scr-cgpa`,
`ent-scr-destfld`, `ent-scrset`, `ent-tt`

When you attempted to add a gateway screening screen set, a gateway screening reference name, or a global title translation type to the database, the system determined that the table shared by the gateway screening and global title translation features is full and the database could not be updated.

Either a gateway screening screen set and all of its rules, or a global title translation type (and all global title translation data referencing that translation type) must be deleted from the database.

Recovery - For a Gateway Screening Screen Set

1. Display the gateway screening screen sets in the database. Enter the **rtrv-scrset** command. Select a screen set to delete from the database.
2. Enter these commands to verify the gateway screening entities that reference the gateway screening screen set selected in step 1.
 - **rtrv-scr-aftpc**
 - **rtrv-scr-blkdpc**
 - **rtrv-scr-blkopc**
 - **rtrv-scr-cdpa**
 - **rtrv-scr-cgpa**
 - **rtrv-scr-dpc**
 - **rtrv-scr-destfld**
 - **rtrv-scr-opc**
 - **rtrv-scr-tt**
 - **rtrv-scr-sio**
3. Delete any entries in the gateway screening entities displayed in step 2 that reference the screen set name selected in step 1. This includes the screen set itself.

For additional information, refer to the procedures in the *Database Administration Manual - Gateway Screening*.
4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

Recovery - For a Global Title Translation Type

1. Display the global title translation types in the database. Enter the **rtrv-tt** command. Select a translation type to delete from the database.
2. Enter the **rtrv-gtt:type=** command, specifying the translation type selected in step 1, to verify the global title translation data referencing the translation type selected in step 1.

3. Delete the global title translation data displayed in step 2. Enter the **dlt-gtt** command.
 4. If the selected translation type has any alias translation types assigned to it, delete them. Enter the **dlt-tt:type= :alias=** command.
 5. Delete the translation type. Enter the **dlt-tt:type=** command.
 6. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2558 Cmd Rej: Point code already exists in given SR

Commands Used: chg-scr-blkdpc, chg-scr-blkopc, chg-scr-destfld, chg-scr-dpc, chg-scr-opc, ent-scr-blkdpc, ent-scr-blkopc, ent-scr-destfld, ent-scr-dpc, ent-scr-opc

The point code specified in the command already exists in the SR (screening reference). You cannot add a point code to an SR if it is already there. If asterisks or ranges are specified for the point code, nothing that matches the specified range or point codes can already exist in the screening table for the screening reference.

If the SR already exists, the blocked OPC cannot be defined as specified or exist within an existing range of OPCs. The blocked OPC that was intended to be added to the BLKOPC screening table for the blocked OPC SR was specified by one of these parameter sets: **ni-nc-ncm, zone-area-id, msa-ssa-sp, or npc**.

Recovery

1. Enter one of the following commands to verify the point codes in the screening reference:
 - **rtrv-scr-blkdpc**, for the **ent-scr-blkdpc** command
 - **rtrv-scr-blkopc**, for the **ent-scr-blkopc** command
 - **rtrv-scr-dpc**, for the **ent-scr-dpc** command
 - **rtrv-scr-opc**, for the **ent-scr-opc** command
 2. Re-enter the command specifying a different point code for the screening reference.
-

E2559 Cmd Rej: PC/SSN does not exist in given SR

Commands Used: `chg-scr-aftpc`, `chg-scr-cdpa`, `chg-scr-cgpa`,
`dlt-scr-aftpc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`

The point code/subsystem number combination (**ni**, **nc**, **ncm**, **ssn**) to be changed does not exist in the screening reference (SR) specified in the command. The point code/subsystem number combination must be in the given screening reference.

OR

The AFTPC or AFTPC range defined by the one of the four point code types represented (**ni-nc-ncm**, **zone-area-id**, **msa-ssa-sp**, or **npc**) must already exist in the screening reference before you can perform this command.

Recovery

1. Verify the point code/subsystem number combinations for the given screening reference. Enter one of the following commands with the given screening reference:
 - `rtrv-scr-aftpc`, for the `chg-scr-aftpc` and `dlt-scr-aftpc` commands
 - `rtrv-scr-cdpa`, for the `chg-scr-cdpa` and `dlt-scr-cdpa` commands
 - `rtrv-scr-cgpa`, for the `chg-scr-cgpa` and `dlt-scr-cgpa` commands
 2. Re-enter the command specifying the appropriate values for the new point code/subsystem number combination shown in step 1.
-

E2560 Cmd Rej: Inhibit rejected, target terminal is not equipped

Commands Used: `alw-trm`, `inh-trm`, `rmv-trm`, `rst-trm`

You have attempted to inhibit a terminal number in the allowable range of numbers, but it has not been equipped. This command cannot be completed.

Recovery

1. Display all the terminals. Enter the `rtrv-trm` command.
 2. With the output from step 1 as a guide, re-enter the command for an equipped terminal, or equip the terminal for use.
-

E2561 Cmd Rej: PC/SSN already exists in given SR

Commands Used: `chg-scr-aftpc`, `chg-scr-cgpa`, `ent-scr-cdpa`,
`ent-scr-cgpa`, `ent-scr-aftpc`

The specified point code or subsystem (**ni**, **nc**, **ncm**, **msa**, **ssa**, **sp**, **ssn**) is already in the given screening reference. The point code and subsystem number cannot be added if it is already in the screening reference.

Recovery

1. Verify the point code/subsystem number combinations. Enter the appropriate retrieve command, such as `rtrv-scr-cdpa` command.
 2. Re-enter the command specifying the appropriate values for the point code / subsystem number combination, making sure that the values are not in the given screening reference.
-

E2564 Cmd Rej: Point code out of range

Commands Used: `chg-scr-aftpc`, `chg-scr-cdpa`, `chg-scr-cgpa`,
`chg-sid`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-destfld`,
`chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-aftpc`, `dlt-scr-blkdpc`,
`dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-destfld`,
`dlt-scr-dpc`, `dlt-scr-opc`, `ent-dstn`, `ent-ls`, `ent-scr-aftpc`,
`ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`,
`ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-opc`, `rtrv-scr-aftpc`,
`rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`,
`rtrv-scr-cgpa`, `rtrv-scr-destfld`, `rtrv-scr-dpc`, `rtrv-scr-opc`

The specified point code was not entered with the correct values. The following point codes are **not** allowed:

- ANSI point code value **000-000-000**
- ITU-International point code value **0-000-0**

Refer to the command in the *Commands Manual* for additional information about correct point code values.

Recovery

Re-enter the command specifying the correct point code value.

E2565 Cmd Rej: Gateway screening rules table is full

Commands Used: `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-destfld`, `ent-scr-dpc`, `ent-scr-isup`, `ent-scr-opc`, `ent-scr-sio`

The attempt was made to add a gateway screening entry, but the gateway screening rules table is full. The gateway screening rules table can contain only 362,700 rules. To add another gateway screening entry, an existing gateway screening entry has to be deleted or changed.

Recovery

1. Display the entries in the gateway screening table. Enter one of the following commands: `rtrv-scr-aftpc`, `rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`, `rtrv-scr-dpc`, `rtrv-scr-opc`, `rtrv-scr-isup`, `rtrv-scr-sio`, or `rtrv-scr-destfld`.
2. If you wish to delete a current entry in the specified screening entity, enter one of the following commands: `dlt-scr-aftpc`, `dlt-scr-blkdpc`, `dlt-scr-blkopc`, `dlt-scr-cdpa`, `dlt-scr-cgpa`, `dlt-scr-dpc`, `dlt-scr-isup`, `dlt-scr-opc`, `dlt-scr-sio`, or `dlt-scr-destfld`.
3. Re-enter the command that generated this error message.
4. If you want to change a current entry in the specified screening entity, enter one of the following commands, with the screening information that you attempted to add within the command that generated this error message.
 - `chg-scr-aftpc`, for the `ent-scr-aftpc` command
 - `chg-scr-blkdpc`, for the `ent-scr-blkdpc` commands
 - `chg-scr-blkopc`, for the `ent-scr-blkopc` command
 - `chg-scr-cdpa`, for the `ent-scr-cdpa` command
 - `chg-scr-cgpa`, for the `ent-scr-cgpa` command
 - `chg-scr-dpc`, for the `ent-scr-dpc` command
 - `chg-scr-isup`, for the `ent-scr-isup` command
 - `chg-scr-opc`, for the `ent-scr-opc` command
 - `chg-scr-destfld`, for the `ent-scr-destfld` command
 - `chg-scr-sio`, for the `ent-scr-sio` command

Call your Customer Care Center if this error message appears again.

E2567 Cmd Rej: Screen set name already exists**Commands Used: ent-scrset**

The screen set was not entered because the specified screen set name already exists. The specified screen set name must be unique.

Recovery

1. Display the screen set data. Enter the **rtrv-scrset** command specifying no parameters.
 2. Re-enter the **ent-scrset** command specifying a screen set name that does not match any of the screen set names displayed in step 1.
-

E2568 Cmd Rej: Screen set name is referenced by a link set**Commands Used: dlt-scrset**

A screen set that is assigned to a linkset and cannot be deleted.

Recovery

1. Delete the screen set association from the linkset. Enter the **chg-ls** command.
 2. Delete the screen set. Re-enter the **dlt-scrset** command.
-

E2569 Cmd Rej: SIO does not exist in given SR**Commands Used: chg-scr-sio, dlt-scr-sio**

The entry specified by the **nic**, **si**, **h0**, and **h1** parameters could not be found.

Recovery

1. Display the allowed SIO information for the specified screening reference. Enter the **rtrv-scr-sio** command.
 2. Re-enter the command specifying the appropriate **nic**, **si**, **h0**, and **h1** parameter information from step 1.
-

E2570 Cmd Rej: NIC, SI, and H0/H1 entry already exists in given SR

Commands Used: `ent-scr-sio`

The `nic`, `si`, `h0`, and `h1` parameters specified already exist in the screening reference.

Recovery

1. Display the allowed SIO information for the specified screening reference. Enter the `rtrv-scr-sio` command.
 2. Re-enter the `ent-scr-sio` command specifying values for the `nic`, `si`, `h0`, and `h1` parameters that do not match those displayed in step 1.
-

E2571 Cmd Rej: SI does not exist for given SR

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `rtrv-scr-sio`

The specified service indicator (`si`) and screening reference (`sr`) combination could not be found in the database. These commands require that the specified screening reference and service indicator combination must be in the database.

Recovery

1. Display the allowed SIO screening references and the associated service indicators in the database. Enter the `rtrv-scr-sio` command. The screening references are shown in the SR field of the `rtrv-scr-sio` command output. The service indicators are shown in the SI field of the `rtrv-scr-sio` command output.
 2. Re-enter the command specifying a screening reference and service indicator combination shown in the `rtrv-scr-sio` command output in step 1.
-

E2572 Cmd Rej: NIC and SI must be specified for given H0 and H1

Commands Used: `rtrv-scr-sio`

The command was entered with the heading codes (`h0` and `h1`) parameters specified, but the service indicator (`si`) and network indicator code (`nic`) parameters were not specified. The `h0` and `h1` parameters cannot be specified if the `nic` and `si` parameters are not specified.

Recovery

1. Display all the network indicator codes (**nic**), service indicators (**si**), and heading codes (**ho** and **h1**) parameters in the database. Enter the **rtrv-scr-sio** command specifying no parameters.
 2. If you wish to view a particular heading code entry, enter the **rtrv-scr-sio** command specifying the values for the **nic**, **si**, **h0**, and **h1** parameters shown in the output of step 1.
-

E2573 Cmd Rej: SR or NSR does not reference an existing SR

Commands Used: **chg-scr-aftpc**, **chg-scr-destfld**, **chg-scr-blkdpc**, **chg-scr-blkopc**, **chg-scr-cdpa**, **chg-scr-cgpa**, **chg-scr-destfld**, **chg-scr-dpc**, **chg-scr-opc**, **chg-scr-sio**, **chg-scr-tt**, **dlt-scr-cdpa**, **dlt-scr-cgpa**, **dlt-scr-isup**, **dlt-scr-sio**, **dlt-scr-tt**, **rtrv-scr-aftpc**, **rtrv-scr-blkdpc**, **rtrv-scr-blkopc**, **rtrv-scr-cdpa**, **rtrv-scr-cgpa**, **rtrv-scr-destfld**, **rtrv-scr-dpc**, **rtrv-scr-isup**, **rtrv-scr-opc**, **rtrv-scr-sio**

The screening reference specified by the **sr** or **nsr** parameter does not exist.

Recovery

1. Verify the screening references in the entity set. Enter one of the following commands:
 - **rtrv-scr-aftpc**, for the **chg-scr-aftpc** command
 - **rtrv-scr-blkdpc**, for the **chg-scr-blkdpc** command
 - **rtrv-scr-blkopc**, for the **chg-scr-blkopc** command
 - **rtrv-scr-cdpa**, for the **chg-scr-cdpa** and **dlt-scr-cdpa** commands
 - **rtrv-scr-cgpa**, for the **chg-scr-cgpa** and **dlt-scr-cgpa** commands
 - **rtrv-scr-destfld**, for the **chg-scr-destfld** command
 - **rtrv-scr-dpc**, for the **chg-scr-dpc** command
 - **rtrv-scr-isup**, for the **chg-scr-isup** and **dlt-scr-isup** commands
 - **rtrv-scr-opc**, for the **chg-scr-opc** command

- `rtrv-scr-sio`, for the `chg-scr-sio` and `dlt-scr-sio` commands
 - `rtrv-scr-tt`, for the `chg-scr-tt` and `dlt-scr-tt` commands
2. Re-enter the command specifying the screening reference from the output in step 1.
-

E2574 Cmd Rej: TYPE does not exist in given SR

Commands Used: `chg-scr-tt`, `dlt-scr-tt`

The specified translation type could not be found.

Recovery

1. View the translation types in the screening reference. Enter the `rtrv-scr-tt` command.
 2. Re-enter the command specifying one of the translation types from the output of step 1.
-

E2575 Cmd Rej: TYPE matches existing TYPE in given SR

Commands Used: `chg-scr-tt`

The new type matches a type already in the screening reference.

Recovery

1. Display the data for this screening reference. Enter the `rtrv-scr-tt` command.
 2. Re-enter the `chg-scr-tt` command specifying a new value for the new translation type, that did not appear in the `rtrv` command executed in step 1.
-

E2577 Cmd Rej: A specific SSN must be specified in the range (1-255,*)

Commands Used: `chg-scr-aftpc`, `dlt-scr-aftpc`, `dlt-scr-cgpa`

You either failed to include the `ssn` parameter on the command line, or assigned a value to it that was out of range.

Recovery

Re-enter the command that generated this error message specifying the correct **ssn** parameter value.

Call your Customer Care Center if this error message appears again.

E2579 Cmd Rej: GWS must be ON if LAN is ON**Commands Used: chg-feat**

You specified the **lan=on** parameter to turn the STP LAN feature on, and the Gateway Screening feature is off. To use the STP LAN feature, the Gateway Screening feature must be turned on.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

Re-enter the **chg-feat** command specifying the **lan=on** and **gws=on** parameters.

E2580 Cmd Rej: A specific NIC must be specified in the range (0-3)**Commands Used: dlt-scr-sio**

You either failed to include the **nic** parameter on the command line, or assigned a value to it that was out of range.

Recovery

Re-enter the **dlt-scr-sio** command that generated this error message specifying the correct **nic** parameter value.

Call your Customer Care Center if this error message appears again.

E2581 Cmd Rej: CRMD feature must be ON**Commands Used: chg-dstn, ent-dstn, chg-feat**

The parameters specified require the Cluster Routing and Management Diversity feature turned on. Refer to Table 2-12 for a list of conditions that generate an E2581 error message.

Table 2-12. Conditions the Generate an E2581 Error Message

Command(s)	Condition
chg-dstn ent-dstn	You tried to enter or change a cluster destination point code, and the system detected that the cluster routing and management diversity (CRMD) feature is off. To enter a cluster destination point code, the CRMD feature must be turned on.
chg-feat	You entered chg-feat:ncr=on to turn on the nested cluster routing (NCR) feature, but the system detected that the cluster routing and management diversity (CRMD) feature is off. The crmd feature must be turned on (crmd=on) prior to enabling the ncr parameter (ncr=on).

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the CRMD feature is turned on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the CRMD feature is turned off (from the output of step 1), turn it on. Enter the **chg-feat:crmd=on** command.
 4. Re-enter the command that generated this error message.
-

E2582 Cmd Rej: Feature corresponding to APPL not ON

Commands Used: **ent-card**, **ent-dstn**

You cannot add to the database a LIM card that uses the **ss7gx25** application, if the X.25/SS7 gateway feature is turned off. To add a LIM card that uses the **ss7gx25** application to the database (**appl=ss7gx25**), the X.25/SS7 gateway feature must be turned on.

OR

You tried to define a destination address in the X.25 destination entity domain (**domain=x25**), and the system detected that the X.25/SS7 gateway feature was not turned on.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the X.25/SS7 gateway feature is turned on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the X.25/SS7 gateway feature is turned off (from the output of step 1), turn it on. Enter the **chg-feat:x25g=on** command.
 4. Re-enter the command that generated this error message.
-

E2583 Cmd Rej: LAN feature must be ON

Commands Used: **ent-card**

You specified the **appl=stplan** or **appl=vxwslan** parameter, and the system detected that the LAN feature was turned off. To specify the **appl=stplan/vxwslan** parameters, the LAN feature must be turned on.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the LAN feature is turned on (from the output of step 1), re-enter **ent-card** the command.
Call your Customer Care Center if this error message appears again.
 3. If the LAN feature is turned off (from the output of step 1), turn it on. Enter the **chg-feat:lan=on** command.
 4. Re-enter the **ent-card** command that generated this error message.
-

E2584 Cmd Rej: GTT feature must be ON

Commands Used: `chg-ctrl-feat`, `chg-feat`, `enable-ctrl-feat`, `ent-card`

You entered the `chg-ctrl-feat` command to turn on the Intermediate Global Title Translation Load Sharing (IGTTLS) feature, and the Global Title Translation (GTT) feature is turned off. Before you can turn on the IGTTLS feature, the GTT feature must be turned on and the IGTTLS feature must be enabled.

OR

You entered the `chg-feat` command to turn on the G-Flex feature and the GTT feature is turned off. Before you can turn on the G-Flex feature, the GTT feature must be turned on and the G-Flex feature must be enabled.

NOTE: EGTT can be on when G-Flex is on. GTT is required for EGTT.

OR

You entered the `enable-ctrl-feat` command to enable the EIR (Equipment Identity Register) feature or the GMS (GSM Map Screening) feature, and the GTT feature is turned off. Before you can enable the EIR feature or the GMS feature, the GTT feature must be turned on.

OR

You entered the `ent-card` command to add an SCCP or VSCCP card to the database, and the GTT feature is turned off. Before you can add an SCCP or VSCCP card to the database (`appl=sccp/vsccp`), the GTT feature must be turned on.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the status of features that are controlled by feature bits in the database. Enter the `rtrv-ctrl-feat` command.
2. Verify that the GTT feature has been purchased and installed in the system. Contact your Customer Care Center for assistance. Verify that the GTT feature is turned on in the system.
3. If the GTT feature is turned off (from the output of step 1), turn it on. Enter the `chg-ctrl-feat:gtt=on` command. Verify that the GTT feature is turned on in the system. Enter the `rtrv-ctrl-feat` command.
 - If you are trying to turn on the IGTTLS feature, display the status of features that are controlled with access keys in the system. Verify that the

IGTTLS feature is enabled in the system. Enter the **rtrv-ctrl-feat** command.

When the GTT feature is turned on in the system (see step 3), re-enter the **chg-ctrl-feat** command to turn on the IGTTLS feature.

- If you are trying to enable the EIR feature and the GTT feature is turned off (from the output of steps 1 and 2),

Verify that the EIR feature has been purchased and installed in the system. (Contact your Customer Care Center for assistance if needed).

When the GTT feature is turned on in the system (see step 3), re-enter the **enable-ctrl-feat** command to enable the EIR feature.

- If you are trying to enable the GMS feature and the GTT feature is turned off (from the output of steps 1 and 2),

Verify that the GMS feature has been purchased and installed in the system. (Contact your Customer Care Center for assistance if needed).

When the GTT feature is turned on in the system (see step 3), re-enter the **enable-ctrl-feat** command to enable the GMS feature.

Call your Customer Care Center if this error message appears again.

E2585 Cmd Rej: GWS feature must be ON

Commands Used: **enable-ctrl-feat**, **ent-card**

The GWS feature must be turned on prior to issuing this command. Specifically:

- **enable-ctrl-feat** - You must first turn on the GWS feature before you can turn on the ISUP NP with EPAP feature.
- **ent-card** - You tried to add a GLS card to the database, and the system detected that the gateway screening (GWS) feature was not turned **on**. To add a GLS card to the database (**appl=gl**s), the GWS feature must be turned **on**.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
2. If the GWS feature is turned on (from the output of step 1), re-enter the command.

Call your Customer Care Center if this error message appears again.

3. If the GWS feature is turned off (from the output of step 1), turn it on. Enter the **chg-feat:gws=on** command.
 4. Re-enter the command that generated this error message.
-

E2586 Cmd Rej: Invalid LINK for APPL

Commands Used: **dlt-slk**, **ent-slk**, **rept-meas**, **rtrv-slk**

You specified a **link** parameter that is invalid for the card's application type. If the card application is **ss7gx25**, only **link=a** can be specified.

Recovery

1. Display the card's configuration using the **rtrv-card** command specifying the card location used in the command that generated this error message. The card's application is shown in the APPL field of the output.
 2. Re-enter the command specifying a **link** parameter that is valid for the card's application type (see Table 2-13).
-

Table 2-13. Valid Port and Application Type Combinations

Card	Port	Supported Application
Two-port LIM	A	All supported applications. The two-port LIM supports the DS0, OCU, V35, ATM, or E1 interface.
Two-port LIM	B	All supported applications except ss7gx25 (X.25 signaling link), atmansi , (ATM HSL signaling link), or ss7ipgw/ipgwi (IP signaling link)
Multi-port LIM	A, B, A1, B1, A2, B2, A3, B3	The ss7ml GPL with DS0 interface at 56Kbps running the ss7ansi application only.

E2587 Cmd Rej: Card GPL of link does not match domain of linkset APC**Commands Used: ent-slk**

You specified a card location whose application (GPL) is not the same as the domain of the adjacent point code of the linkset that contains the signaling link. For example, the specified card is a LIM using the **ss7gx25** application, and the domain of the linkset adjacent point code is in the SS7 domain. For this example to be successful, the card would have to be a LIM using the **ss7ansi** or **ccs7itu** application, or the linkset adjacent point code must be in the X.25 domain.

Recovery

1. Verify the card applications (**ss7ansi** or **ss7gx25**) of the cards in the system. Enter the **rtrv-card** command.
 2. Display the destination point codes and to verify the domain (SS7 or X.25) of each destination point code. Enter the **rtrv-dstn** command. The adjacent point code of the linkset must be in the Destination Point Code table.
 3. Using the outputs of steps 1 and 2 as a guide, re-enter the **ent-slk** command, making sure the card application of the specified signaling link matches the domain of the adjacent point code of the linkset containing the signaling link.
-

E2588 Cmd Rej: Link must be removed from X.25 route(s)**Commands Used: dlt-slk**

The specified signaling link has an X.25 route assigned to it, and the **force=yes** parameter was not entered. To delete the signaling link, all associated X.25 routes must be deleted, or the **force=yes** parameter must be entered.

Recovery

1. Display the X.25 routes in the database. Enter the **rtrv-x25-rte** command.
 2. Delete all X.25 routes associated with the signaling link (**loc** and **port**) specified in the command that generated this error message with the **dlt-x25-rte** command.
 3. Re-enter the **dlt-slk** command that generated this error message.
OR
 4. Re-enter the **dlt-slk** command specifying the **force=yes** parameter.
-

E2589 Cmd Rej: L2TSET cannot be specified if card application is SS7GX25**Commands Used: ent-slk**

You cannot specify the **l2tset** parameter for a card that is running the **ss7gx25** application. If the card application is **ss7gx25**, the **l2tset** parameter cannot be specified. However, you can specify the **l2tset** parameter for a card that is running the **ss7ansi** or the **ccs7itu** application.

Recovery

1. Display the cards in the database. Enter the **rtrv-card** command.
 2. If the signaling link you want to enter is an SS7 signaling link, enter the **ent-slk** command specifying a card location running the **ss7ansi** or **ccs7itu** application, as shown in the output of step 1 (in the APPL field of the output), and with the **l2tset** parameter.
 3. If the signaling link you want to enter is an X.25 signaling link, enter the **ent-slk** command specifying a card location running the **ss7gx25** application, as shown in the output of step 1 (in the APPL field of the output), and without the **l2tset** parameter.
-

E2591 Cmd Rej: BEI must be YES if APC domain is X.25**Commands Used: chg-ls, ent-ls**

You specified the **bei=no** parameter, and the domain of the adjacent point code (APC) of the linkset is in the X.25 domain. If the domain of the APC is in the X.25 domain, the **bei** parameter must be set to **yes**.

Recovery

1. Display the point codes in the destination point code table. Enter the **rtrv-dstn** command. The domain of the point codes is shown in the DOMAIN field of the output.
2. Display the linksets in the database, using the **rtrv-ls** command.
3. If you are adding a new linkset (**ent-ls** command), and the selected point code is in the SS7 domain, enter either the **bei=yes** or **bei=no** parameter, or do not enter the **bei** parameter. The default value for the **bei** parameter is **no**. If the selected point code is in the X.25 domain, enter the **bei=yes** parameter (default is **yes** in the X.25 domain).
4. If you are changing an existing linkset (**chg-ls** command), find the point code of the linkset to be changed in the output of step 1 to determine the domain of the point code. If the domain of the point code is **x25**, and the **bei=**

no (shown in the BEI field in the output of step 2), enter the **bei=yes** parameter. If the domain of the point code is **SS7**, enter either the **bei=yes** or **bei=no** parameter, or do not enter the **bei** parameter. If the **bei** parameter is not specified, the **bei** value does not change.

E2592 Cmd Rej: Warm Restart capable Feature must be enabled

Commands Used: **alw-card**, **init-card**, **init-sys**

You specified the **data=persist** parameter. Before you can use this parameter, a feature must be turned on in the system that can warm restart without reloading the card database. The features that are capable of warm restart are LNP, LNP ELAP Configuration, G-Flex, G-Port, and INP.

Recovery

1. Display the features that are turned on. Enter the **rtrv-feat** command. Verify that one of the warm restart capable features is turned on.
 2. If a warm restart capable feature is turned on, re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2593 Cmd Rej: APC cannot be of a different domain than previous

Commands Used: **chg-1s**

The specified APC was not in the same domain as the previous APC assigned to the linkset. For example, the previous APC was an SS7 APC and the new APC was an X.25 APC. The **chg-1s** command does not allow this.

Recovery

1. Verify all point codes and the domains that they are assigned to. Enter the **rtrv-dstn** command. The domain of each point code is shown in the DOMAIN field in the output.
 2. Re-enter the **chg-1s** command, with a point code whose domain matches the domain of the previous APC. If the domain of the previous APC is **ss7**, select a point code whose domain is **ss7**. If the domain of the previous APC is **x25**, select a point code whose domain is **x25**.
-

E2594 Cmd Rej: X.25 Destination assigned to non-X.25 linkset**Commands Used: ent-rte**

The specified DPC is assigned to the X.25 domain (an X.25 DPC), and the specified linkset (**lsn**) is assigned to an adjacent point code (APC) that is assigned to the SS7 domain (an SS7 linkset). An X.25 DPC must be assigned to an X.25 linkset, and an SS7 DPC must be assigned to an SS7 linkset.

Recovery

1. Display the destination point codes in the database. Enter the **rtrv-dstn** command.
 2. Display the linksets in the database. Enter the **rtrv-ls** command.
 3. Using the outputs from steps 1 and 2 as a guide, re-enter the **ent-rte** command specifying an X.25 DPC and an X.25 linkset.
-

E2595 Cmd Rej: SS7 Destination assigned to non-SS7 linkset**Commands Used: ent-rte**

The specified DPC is assigned to the SS7 domain (an SS7 DPC), and the specified linkset (**lsn**) is assigned to an adjacent point code (APC) that is assigned to the X.25 domain (an X.25 linkset). An SS7 DPC must be assigned to an SS7 linkset, and an X.25 DPC must be assigned to an X.25 linkset.

Recovery

1. Display the destination point codes in the database. Enter the **rtrv-dstn** command.
 2. Display the linksets in the database. Enter the **rtrv-ls** command.
 3. Using the outputs from steps 1 and 2 as a guide, re-enter the **ent-rte** command specifying an SS7 DPC and an SS7 linkset.
-

E2596 Cmd Rej: DPC must be removed from X.25 route tbl**Commands Used: dlt-dstn**

The specified destination point code (DPC) is referenced by an X.25 destination. A DPC cannot be deleted from the database if it is referenced by an X.25 destination.

Recovery

1. Display the X.25 destinations in the database using the **rtrv-x25-dstn** command, specifying the DPC used in the command that generated this error message.
 2. Display any X.25 routes associated with the X.25 destination shown in step 1, using the **rtrv-x25-rte** command, specifying the X.25 address shown in the X25 ADDR field in step 1.
 3. If the output of step 2 shows any X.25 routes associated with the X.25 address shown in step 1, delete those X.25 routes from the database using the **dlt-x25-rte** command, specifying the X.25 addresses shown in the X25 ADDR and SS7 ADDR fields in the output of step 2.
 4. Delete the X.25 destinations associated with the DPC from the database, shown in the X25 ADDR field in the output of step 1, using the **dlt-x25-dstn** command.
 5. Re-enter the **dlt-dstn** command that generated this error message.
-

E2597 Cmd Rej: Cccmmd table must be accessible

Commands Used: **chg-cmd**, **rtrv-cmd**

The cccmmd table was not accessible to the command you entered.

Recovery

Re-enter carefully the command that generated this error message specifying correct parameter values.

Call your Customer Care Center if this error message appears again.

E2598 Cmd Rej: Cccnames table must be accessible

Commands Used: **chg-cmd**, **chg-cmdclass**, **chg-secu-trm**, **chg-user**, **ent-user**, **rtrv-cmd**, **rtrv-cmdclass**, **rtrv-secu-trm**, **rtrv-secu-user**, **rtrv-user**

The Cccnames table was not accessible to the command you entered.

Recovery

Re-enter carefully the command that generated this error message specifying correct parameter values.

Call your Customer Care Center if this error message appears again.

E2599 Cmd Rej: Failed reading the extended link table

Commands Used: `chg-appl-sock`, `chg-x25-slk`, `dlt-ip-node`,
`ent-dlk`, `ent-ip-node`, `ent-slk`, `rtrv-dlk`, `rtrv-x25-slk`

The Extended Link table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2600 Cmd Rej: Linkset SAPC referenced by route

Commands Used: `chg-ls`

You have been prevented from deleting an **sapc** (Secondary Adjacent Point Code) linkset because it is currently referenced by a route. The command cannot delete an **sapc** when a route exists for a linkset in the SAPC's domain or group code.

Recovery

1. If you did not intend to delete this route, enter the correct linkset name.
 2. If you did intend to delete this route:
 - Delete the route reference with the `dlt-rte` command specifying the linkset name from the command that generated this error message.
 - Re-enter the `chg-ls` command that generated this error message.
-

E2601 Cmd Rej: Command aborted due to system error

Commands Used: `chg-ss-appl`, `dlt-dlk`, `dlt-ip-node`,
`dlt-ss-appl`, `ent-dlk`, `ent-ss-appl`, `rtrv-ss-appl`,
`rtrv-data-rtdb`, `rtrv-data-insrv`

The command could not be executed because of a system error. The state of the card must be determined.

Recovery

1. Re-enter the command that generated this error message.
 2. If this error message appears again, reinitialize the active MASP. Enter the **init-card** command, specifying the location of the OAM.
 3. Re-enter the command that generated this error message.
 4. If this error message appears again, determine the status of the database. Enter the **rept-stat-db** command.
 5. If the database is incoherent, find the conditions shown in the output of step 4 in the following list, and execute the appropriate command.
 - If the current partition of the fixed disk is coherent and the backup partition of the fixed disk is incoherent, enter the **chg-db:action=backup:dest=fixed** command.
 - If the current partition of the fixed disk is coherent and the database on the removable cartridge is incoherent, use the **chg-db:action=backup:dest=remove** command.
 - If the backup partition of the fixed disk is coherent and the current partition of the fixed disk is incoherent, use the **chg-db:action=restore:src=fixed** command.
 - If the database on the removable cartridge is coherent and the current partition of the fixed disk is incoherent, enter the **chg-db:action=restore:src=remove** command.
 - If the backup and current partitions on the active TDM are coherent and the backup and current partitions on the standby TDM are not coherent, use the **chg-db:action=repair** command.
 6. Log into the EAGLE 5 ISS. Enter the **login** or **act-user** command.
 7. Verify that the database is coherent. Re-enter the **rept-stat-db** command.
 8. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2602 Cmd Rej: Card is not a ACMENET card

Commands Used: **ent-dlk**, **rtrv-dlk**, **rtrv-ip-node**

The card in the location specified in this command is not an Application Communications Module Ethernet (ACMENET). The ACM Ethernet card is the only card type that can be entered with this command. The card software application must be STP LAN.

Recovery

1. Verify the card types in the database. Enter the **rtrv-card** command. The ACM cards are indicated by the term ACMENET in the TYPE field of the **rtrv-card** command output.
 2. Re-enter the command specifying a card type that is an ACMENET.
-

E2603 Cmd Rej: Card must be inhibited before executing this command

Commands Used: **chg-bip-fld**, **chg-ip-card**, **chg-ip-lnk**, **dlt-dlk**, **dlt-ip-node**, **ent-dlk**, **ent-ip-node**, **init-flash**, **tst-bip**

The specified card was not OOS-MT-DSBLD (out of service - maintenance disabled). These commands require that the card be in the OOS-MT-DSBLD state before any TCP/IP data links or IP nodes can be added or deleted.

NOTE: This error message does not apply to HMUX cards for the **init-flash** command.

Recovery

1. Display the status of the card, specified in the command that generated this error message, using the **rept-stat-card** command, specifying the card location. The primary state of the card is shown in the PST field.
2. If the primary state of the card displayed in step 1 is not OOS-MT-DSBLD, enter the **rmv-card** command to make the primary state of the card OOS-MT-DSBLD.
3. Re-enter the command that generated this error message.
4. If the primary state of the card displayed in step 1 is OOS-MT-DSBLD, re-enter the command.

Call your Customer Care Center if this error message appears again.

E2604 Cmd Rej: Card location not assigned a TCP/IP link

Commands Used: **dlt-dlk**, **dlt-ip-node**, **ent-ip-node**, **rtrv-dlk**, **rtrv-ip-node**

The specified card does not contain a TCP/IP data link.

Recovery

1. Display the TCP/IP data links in the database. Enter the **rt rv-dlk** command specifying no parameters.
 2. Re-enter the command specifying a card location (**loc**) shown in step 1 that contains a TCP/IP data link.
-

E2605 Cmd Rej: First octet of IPADDR cannot be 127

Commands Used: ent-dlk

You cannot specify an IP address whose first number is **127**, which is a loopback address. You cannot specify a loopback address with this command.

Recovery

Re-enter the **ent-dlk** command without specifying **127** as the first number of the IP address.

E2606 Cmd Rej: Point code must exist within the group

Commands Used: chg-mrn

You entered the command to change the relative costs specified for more than one point code. At least one of the point codes that you specified does not exist in the group in the Mated Relay Node (MRN) table that is indicated by the point code specified in the **pc** parameter. When you enter the relative costs to change them, all point codes specified must exist in the group indicated by the **pc** parameter point code value.

Recovery

1. Display the point codes in each group in the MRN table. Enter the **rt rv-mrn** command. Verify that you specified the correct point codes in one group in the table.
 2. Re-enter the **chg-mrn** command to change the relative costs, with all specified point codes in the same group in the MRN table
 3. If you need to change relative costs for point codes in another group, enter another command for the point codes in that group.
-

E2607 Cmd Rej: IPADDR assigned to a TCP/IP node

Commands Used: `ent-dlk`

The specified IP address (`ipaddr`) was already assigned to a TCP/IP node.

Recovery

1. Verify the TCP/IP nodes in the database. Enter the `rtrv-ip-node` command.
 2. Re-enter the `ent-dlk` command specifying a value for the `ipaddr` parameter that is not shown in the output of step 1.
-

E2608 Cmd Rej: IPADDR not assigned to a TCP/IP link

Commands Used: `dlt-ip-node`, `ent-ip-node`

The specified IP address (`ipaddr`) is the IP address for a TCP/IP data link, not a TCP/IP node. The specified IP address must be the IP address of a TCP/IP node instead of a TCP/IP data link.

Recovery

1. Display the TCP/IP nodes in the database. Enter the `rtrv-ip-node` command.
 2. Re-enter the command specifying an IP address shown in the output of step 1.
-

E2609 Cmd Rej: Only one optional parameter may be specified

Commands Used: `rept-stat-eroute`, `rept-stat-lnp`,
`rept-stat-sccp`, `rtrv-dlk`, `rtrv-ip-node`, `rtrv-ip-rte`

You can enter these commands with only one optional parameter, with the exception of the `ipaddr` and `ipport` parameter combination for the `rtrv-ip-node` command. The following Recovery procedures list by command the remedial action for this error message.

Recovery - rept-stat-lnp

Enter the `rept-stat-lnp` command specifying either: no parameters, the `loc` parameter, or the `card` parameter.

Recovery - rept-stat-eroute, rept-stat-sccp

Enter the command specifying either no parameters, only the **perf** parameter, or only the **loc** parameter.

Recovery - rtrv-dlk

Enter the **rtrv-dlk** command specifying either: no parameters, the **loc** parameter, or the **ipaddr** parameter.

Recovery - rtrv-ip-node

Enter the **rtrv-ip-node** command specifying either: no parameters, the **ipaddr** parameter, the **ipaddr** and **ipport** parameters, the **ipappl** parameter, or the **loc** parameter.

Recovery - rtrv-ip-rte

Enter the command specifying either no parameters, only the **loc** parameter, only the **dest** parameter, or only the **gtwy** parameter.

E2610 Cmd Rej: IPADDR assigned to a TCP/IP link

Commands Used: ent-dlk, ent-ip-node

You assigned an invalid value to the **ipaddr** parameter. The IP address cannot be in the TCP/IP link table and cannot be a TCP/IP node. The specified TCP/IP data link cannot be in the database.

Recovery

1. Display the current IP addresses. Enter the **rtrv-dlk** command.
2. Re-enter the command that generated this error message specifying the correct **ipaddr** parameter value.

Call your Customer Care Center if this error message appears again.

E2611 Cmd Rej: Total Ethernet Capacity is greater than 100% for IP Node**Commands Used: ent-ip-node**

The value you assigned to the **cap** parameter, when added to the values that were assigned when IP addresses were defined, totaled more than **100**.

Recovery

1. Enter the **rtrv-ip-node** command to acquire the present status of the IP node.
 2. Re-enter the **ent-ip-node** command that generated this error message, but set the **cap** parameter to not push the total capacity beyond 100%, when added to the existing capacity as seen in step 1.
-

E2612 Cmd Rej: IPPORT already assigned**Commands Used: ent-ip-node**

You tried to assign a different IP application to an IP port (**ippport**) that, in combination with the IP address used in the command that generated this error message, is already in the database. Once a particular IP address and IP port combination is assigned to an IP application, that IP address and IP port combination must always use that IP application.

Recovery

1. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
 2. Re-enter the **ent-ip-node** command specifying an IP port (**ippport**), IP address (**ipaddr**), and IP application (**ipappl**) combination that is not shown in the output of step 1.
-

E2613 Cmd Rej: IPPORT can only be specified if IPADDR is specified**Commands Used: rtrv-ip-node**

You cannot specify the **ippport** parameter without specifying the **ipaddr** parameter. If you specify the **ippport** parameter, you must also specify the **ipaddr** parameter.

Recovery

Re-enter the **rtrv-ip-node** command specifying both the **ipaddr** and the **ipport** parameters.

E2614 Cmd Rej: IPADDR w/o IPRTE must match first octet of TCP/IP link**Commands Used: ent-ip-node**

You specified an IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. No **iprte** parameter (IP address of a TCP/IP router) was assigned. The network portion of the IP address assigned to the TCP/IP data link and the IP address of the IP node must be the same. The IP address is a Class A IP address. This is determined by the first field of the IP address. The first field value of a Class A IP address is **1** to **126**. The values **0** and **127** are not allowed for IP addresses. For a Class A IP address, the first field is the network portion of the IP address.

Recovery

1. Display the IP addresses of the TCP/IP data links. Enter the **rtrv-dlk** command.
 2. Display the IP addresses of the TCP/IP nodes. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a Class A IP address not shown in the output of step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of step 1).
-

E2615 Cmd Rej: IPADDR w/o IPRTE must match first 2 octets of TCP/IP link**Commands Used: ent-ip-node**

You specified an IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. No **iprte** parameter (IP address of a TCP/IP router) was assigned. The network portion of the IP address assigned to the TCP/IP data link and the IP address of the IP node must be the same. The IP address is a Class B IP address. This is determined by the first field of the IP address. The first field value of a Class B IP address is **128** to **191**. For a Class B IP address, the first two fields are the network portion of the IP address.

Recovery

1. Enter **rtrv-dlk** to display the IP addresses of the TCP/IP data links.
 2. Display the IP addresses of the TCP/IP nodes. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a Class B IP address not shown in the output of step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of step 1).
-

E2616 Cmd Rej: IPADDR w/o IPRTE must match first 3 octets of TCP/IP link

Commands Used: **ent-ip-node**

You specified an IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. No **iprte** parameter (IP address of a TCP/IP router) was assigned. The network portion of the IP address assigned to the TCP/IP data link and the IP address of the IP node must be the same. The IP address is a Class C IP address. This is determined by the first field of the IP address. The first field value of a Class C IP address is from **192** to **223**. For a Class C IP address, the first three fields are the network portion of the IP address.

Recovery

1. Display the IP addresses of the TCP/IP data links. Enter the **rtrv-dlk** command.
 2. Display the IP addresses of the TCP/IP nodes. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a Class C IP address not shown in the output of step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of step 1).
-

E2617 Cmd Rej: IPAPPL already assigned to specified LOC

Commands Used: **ent-ip-node**

The specified IP application (**ipappl**) was already assigned to the TCP/IP data link specified by the **loc** parameter. Only one IP node (**ipaddr**, **ipappl**, and **loc** parameter combination) can be assigned to a TCP/IP data link.

Recovery

1. Verify the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
 2. Verify the TCP/IP data links in the database. Enter the **rtrv-dlk** command.
 3. Re-enter the **ent-ip-node** command specifying values for the IP node (**ipaddr**, **ipappl**, and **loc** parameter combination) that is not shown in the output of step 1, but with a value for the **loc** parameter shown in the output of step 2.
-

E2619 Cmd Rej: Only one of IPAPPL or IPPORT may be specified**Commands Used: dlt-ip-node**

You specified both the **ipappl** and **ippport** parameters. This combination is not allowed by this command.

Recovery

Re-enter the **dlt-ip-node** command specifying either the **ipappl** or **ippport** parameters, but not both.

E2620 Cmd Rej: No optional parameters may be specified if FORCE=YES**Commands Used: dlt-ip-node**

You specified either the **ipappl**, **ippport**, or **loc** parameters, and with the **force=yes** parameter. If you specify the **force=yes** parameter, none of the other optional parameters, **ipappl**, **ippport**, or **loc**, can be specified.

Recovery

Re-enter the **dlt-ip-node** command specifying either the **force=yes** parameter or the **ipappl**, **ippport**, or **loc** parameters.

E2621 Cmd Rej: FORCE=YES must be specified to delete entire node**Commands Used: dlt-ip-node**

The command was entered with only the **ipaddr** parameter. The system interprets this as an attempt to delete all connections from the specified IP node. To delete all connections from an IP node, the **force=yes** parameter must be specified.

Recovery

Re-enter the **dlt-ip-node** command specifying the **force=yes** parameter, or with either the **ipappl**, **ippport**, or **loc** parameters to delete a specific application or port from the IP node.

E2622 Cmd Rej: IPADDR not assigned to specified LOC

Commands Used: **dlt-ip-node**, **rtrv-ip-node**

The command was entered with the **ipaddr** and **loc** parameters, and the node specified by the **ipaddr** parameter could not be found to be connected to the TCP/IP data link specified by the **loc** parameter. For this command to be successful, the **ipaddr** and **loc** parameter combination must be in the database.

Recovery

1. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
2. Re-enter the command specifying an IP address (**ipaddr**) and its associated card location (**loc**) shown in the output of step 1.

OR

Re-enter the command specifying no parameters.

E2623 Cmd Rej: IPPORT on node not assigned to specified LOC

Commands Used: **dlt-ip-node**

You specified the **ippport** and the **loc** parameters, and the **ipaddr/ippport** combination could not be found for the specified location. If you enter the command specifying the **ippport** and the **loc** parameters, the **ipaddr/ippport** combination must be assigned to the TCP/IP data link specified by the **loc** parameter.

Recovery

1. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command specifying no parameters.
 2. Re-enter the **dlt-ip-node** command specifying an **ipaddr/ipport** combination and the corresponding card location shown in the output from the **rtrv-ip-node** command.
-

E2624 Cmd Rej: IPAPPL on node not assigned to specified LOC**Commands Used: dlt-ip-node**

You specified the **ipappl** and the **loc** parameters, and the **ipaddr/ipappl** combination could not be found for the specified location. If you enter the command specifying the **ipappl** and the **loc** parameters, the **ipaddr/ipappl** combination must be assigned to the TCP/IP data link specified by the **loc** parameter.

Recovery

1. Enter **rtrv-ip-node** with no parameters to display the TCP/IP nodes in the database.
 2. Re-enter the **dlt-ip-node** command specifying an **ipaddr/ipappl** combination and the corresponding card location shown in the output of step 1.
-

E2625 Cmd Rej: IPADDR not assigned to any TCP/IP link**Commands Used: dlt-ip-node**

The node specified by the **ipaddr** parameter could not be found to be connected to any TCP/IP data link. At least one connection to the specified TCP/IP node must exist for this command to be successful.

Recovery

1. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
 2. Re-enter the **dlt-ip-node** command specifying an IP address shown in the output of step 1.
-

E2626 Cmd Rej: IPPORT on Node not connected to any TCP/IP link**Commands Used: dlt-ip-node**

The specified IP port (**ipappl**) could not be found in the database. To specify an IP port with this command, it must be assigned to a TCP/IP node, and that node must be connected to a TCP/IP data link.

Recovery

1. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
 2. Re-enter the **dlt-ip-node** command specifying an IP port (**ipport**) that is shown in the output of step 1.
-

E2627 Cmd Rej: IPAPPL on node not connected to any TCP/IP link**Commands Used: dlt-ip-node**

The specified IP application (**ipappl**) could not be found in the database. To specify an IP application with this command, it must be assigned to a TCP/IP node, and that node must be connected to a TCP/IP data link.

Recovery

1. Display the TCP/IP nodes in the database. Enter the **rtrv-ip-node** command.
 2. Re-enter the **dlt-ip-node** command specifying an IP application (**ipappl**) that is shown in the output of step 1.
-

E2628 Cmd Rej: Only one of IPADDR, IPAPPL, IPRTE, or LOC can be specified**Commands Used: rtrv-ip-node**

You specified a combination of the **ipaddr**, **ipappl**, **iprte**, or **loc** parameters. You can specify only one of these parameters with this command.

Recovery

Re-enter the **rtrv-ip-node** command specifying either the **ipaddr**, **ipappl**, **iprte**, or the **loc** parameters, but not a combination of these parameters.

E2629 Cmd Rej: Card has IP LNK with IP address assigned**Commands Used: dlt-card**

The specified card location has an IP link assigned to it. The card cannot be deleted from the database until the IP link is deleted from the database.

Recovery

1. Display the IP links in the database. Enter the **rtrv-ip-lnk** command.
2. Display the IP hosts in the database. Enter the **rtrv-ip-host** command.
3. From the outputs of steps 1 and 2, determine if the card location specified in the command that generated this error message has an IP link assigned to it.
4. Delete the IPHOST from the database. Enter the **dlt-ip-host** command specifying the card location used in step 3.

NOTE: An IPLNK entry must be provisioned before an IPHOST entry with type=local can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

5. Delete the IP link from the database. Enter the **chg-ip-lnk** command specifying the card location used in step 3.
 6. Delete the card from the database. Re-enter the **dlt-card** command that generated this error message.
-

E2630 Cmd Rej: IPADDR and IP RTE cannot be the same address**Commands Used: ent-ip-node**

You entered this command specifying the same address for **ipaddr** (the node's IP address) and **iprte** (the default router's IP address). These addresses cannot be the same.

Recovery

1. Verify the values for **ipaddr** and **iprte**. Enter the **rtrv-ip-node** command.
 2. Re-enter the **ent-ip-node** command specifying different addresses for the **ipaddr** and **iprte** parameters.
-

E2631 Cmd Rej: Link must be cancelled before executing this command

Commands Used: dlt-dlk, inh-card

The following Recovery procedures list by command the remedial action to take for this error message.

Recovery - dlt-dlk

The specified TCP/IP data link was not OOS-MT-DSBLD (out of service - maintenance disabled). To delete a TCP/IP data link from the database, that link must be in an OOS-MT-DSBLD state.

1. To display the status of the TCP/IP data link, use the **rept-stat-dlk** command, specifying the card location. The primary state (PST) field shows the link state.
2. If the primary state displayed in step 1 is not OOS-MT-DSBLD, enter the **canc-dlk** command to make the primary state of the link OOS-MT-DSBLD.
3. Re-enter the command that generated this error message.
4. If the primary state of the TCP/IP data link displayed in step 1 is OOS-MT-DSBLD, re-enter the **dlt-dlk** command.

Call your Customer Care Center if this error message appears again.

Recovery - inh-card

You tried to inhibit a card that has signaling or data links that are in service. Before you can inhibit the card, you must put the links in the OOS-MT-DSBLD (out of service - maintenance disabled) state.

1. To display the status of the signaling link, enter the **rept-stat-slk** command, specifying the card location. For a data link, use the **rept-stat-dlk** command. The primary state of the link is shown in the *PST* field.
2. If the primary state of the link displayed in step 1 is not OOS-MT-DSBLD, enter the **inh-slk** command to make the primary state of the link OOS-MT-DSBLD.

Inhibit all signaling links that provide timeslots serviced by E1 interfaces on an E1 card (card type **lime1**) or by T1 interfaces on an E1/T1 MIM used as a T1 card (card type **limt1**).

For a data link, use the **canc-dlk** command.

Re-enter the **inh-card** command that generated this error message.

3. If the primary state of the link displayed in step 1 is OOS-MT-DSBLD, re-enter the command.

Call your Customer Care Center if this error message appears again.

E2632 Cmd Rej: IPRTE address assigned to TCP/IP Link

Commands Used: **ent-ip-node**

The specified router IP address (**iprte**) was already assigned to a TCP/IP link.

Recovery

1. Verify the TCP/IP data links in the database. Enter the **rtrv-dlk** command.
 2. Verify the TCP/IP router addresses in the database. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a router IP address that is different from the address assigned to the TCP/IP link.
-

E2633 Cmd Rej: IPRTE address must use first octet of Class A TCP/IP Link

Commands Used: **ent-ip-node**

You specified a router IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. The IP address assigned to the TCP/IP router is a Class A IP address. For a Class A IP address, the first field is the network portion of the IP address. The first field value of a Class A IP address is from **1** to **126**. The values **0** and **127** are not allowed for IP addresses.

Recovery

1. Display the IP addresses of the TCP/IP data links. Enter the **rtrv-dlk** command.
 2. Display the IP addresses of the TCP/IP routers. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a Class A router IP address not shown in the output of step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of step 1).
-

E2634 Cmd Rej: IPRTE address must use first 2 octets of Class B TCP/IP Link**Commands Used: ent-ip-node**

You specified a router IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. The IP address assigned to the TCP/IP router is a Class B IP address. For a Class B IP address, the first two fields are the network portion of the IP address. The first field value of a Class B IP address is from **128** to **191**.

Recovery

1. Display the IP addresses of the TCP/IP data links. Enter the **rtrv-dlk** command.
 2. Display the IP addresses of the TCP/IP routers. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a Class B router IP address not shown in the output of step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of step 1).
-

E2635 Cmd Rej: IPRTE address must use first 3 octets of Class C TCP/IP Link**Commands Used: ent-ip-node**

You specified a router IP address whose network portion does not match the network portion of the IP address assigned to the TCP/IP data link. The IP address assigned to the TCP/IP router is a Class C IP address. For a Class C IP address, the first three fields are the network portion of the IP address. The first field value of a Class B IP address is **192** to **223**.

Recovery

1. Display the IP addresses of the TCP/IP data links. Enter the **rtrv-dlk** command.
 2. Display the IP addresses of the TCP/IP routers. Enter the **rtrv-ip-node** command.
 3. Re-enter the **ent-ip-node** command specifying a Class C router IP address not shown in the output of step 2, and whose network portion of the address matches the network portion of the IP address assigned to the TCP/IP data link location specified in this command (shown in the output of step 1).
-

E2636 Cmd Rej: IPADDR assigned to a TCP/IP router

Commands Used: `ent-dlk`

The specified IP address (`ipaddr`) was already assigned to a TCP/IP router. The IP Address must not already be assigned to an existing TCP/IP Default Router.

Recovery

1. Verify the TCP/IP router addresses in the database. Enter the `rtrv-ip-node` command.
 2. Re-enter the `ent-dlk` command, with a value for the `ipaddr` parameter that is not shown in the output of step 1.
-

E2638 Cmd Rej: IPADDR already assigned to another TCP/IP link

Commands Used: `ent-dlk`

The specified IP address (`ipaddr`) is already assigned to a TCP/IP data link. The IP Address must not already be assigned to an existing TCP/IP data link.

Recovery

1. Verify the TCP/IP data links in the database. Enter the `rtrv-dlk` command.
 2. Re-enter the `ent-dlk` command, with a value for the `ipaddr` parameter that is not shown in the output of step 1.
-

E2639 Cmd Rej: Failed reading redirect table

Commands Used: `chg-gws-redirect`, `chg-sid`, `dlt-rte`,
`dlt-gws-redirect`, `ent-gws-redirect`

The Gateway Screening Redirect Function table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2640 Cmd Rej: Redirect function data has already been entered**Commands Used: ent-gws-redirect**

The command was entered, but the gateway screening redirect function data has already been entered. Once specific gateway screening redirect function data is entered, the same **ent-gws-redirect** command cannot be entered again.

Recovery

If you wish to change the data for the gateway screening redirect function, either

- Enter the **chg-gws-redirect** command specifying the new information.
OR
 - Delete the current gateway screening redirect function information with the **dlt-gws-redirect** command, and re-enter the **ent-gws-redirect** command that generated this error message
OR
 - No action is necessary.
-

E2641 Cmd Rej: Redirect function data has not been entered**Commands Used: chg-gws-redirect, dlt-gws-redirect**

The command was entered, but no gateway screening redirect function data has been changed or deleted. These commands can be entered only if the gateway screening redirect function data has been previously entered with the **ent-gws-redirect** command.

Recovery

No action is necessary.

E2642 Cmd Rej: DPC must have at least one route defined**Commands Used: chg-gws-redirect, ent-gws-redirect**

The command was entered with a value for the destination point code (DPC) parameter that has no route assigned to it. These commands require that the DPC have at least one route assigned to it.

Recovery

1. Display the routes in the database. Enter the **rtrv-rte** command. The point codes that have routes assigned to them are shown in the DPCA field. Only ANSI point codes can be used with the gateway screening redirect function.
 2. Re-enter the command that generated this error message, with a point code shown in the DPCA field in the output of step 1.
-

E2643 Cmd Rej: Cannot delete last route to DPC ref. in MAP table

Commands Used: **dlt-rte**

You cannot delete the last route to the specified DPC for a mated application. If this route is deleted and any of these references exist, those references will not be valid.

Recovery

1. Display information about this route and the DPC it points to. Enter the **rept-stat-rte** command.
 2. Delete the other references that point to this DPC.
 3. Re-enter the **dlt-rte** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2644 Cmd Rej: Cannot delete last route to DPC ref. by an X.25 route

Commands Used: **dlt-rte**

The route that you attempted to delete was the last route to the DPC, and that DPC was referenced by an X.25 route. You must first delete the X.25 routes to that DPC.

Recovery

1. Display the X.25 destination associated with the DPC used in the command that generated this error message. Enter the **rtrv-x25-dstn** command.
 2. Display the X.25 routes associated with the X.25 address shown in step 1. Enter the **rtrv-x25-rte** command.
 3. Delete the X.25 routes shown in step 2. Enter the **dlt-x25-rte** command.
 4. Re-enter the **dlt-rte** command that generated this error message.
-

E2645 Cmd Rej: Cannot delete last route to DPC ref. by redirect func**Commands Used: dlt-rte**

You cannot delete the last route to the DPC that is referenced by the gateway screening redirect function. You must change the DPC used by the gateway screening redirect function, or you must disable the gateway screening redirect function, before you can delete the last route to the DPC.

Recovery

1. Display the gateway screening function DPC. Enter the **rtrv-gws-redirect** command.
 - To change the gateway screening function DPC, refer to the *Database Administration Manual - Features*.
 - To disable the gateway screening redirect function, refer to the *Database Administration Manual - Features*.
 2. Re-enter the **dlt-rte** command that generated this error message.
-

E2646 Cmd Rej: APC cannot be ref. by an X.25 route with LC2NM=YES**Commands Used: chg-ls, ent-ls**

You entered either **chg-ls** or **ent-ls**, or another similar command, with an APC whose associated X.25 address is being used in an X.25 route that has the logical channel to network management mapping function turned on (**lc2nm=yes**). This combination is not allowed.

Recovery

1. View X.25 routes. Enter the **rtrv-x25-rte** command.
 2. View the X.25 addresses for their associated point codes. Enter the **rtrv-x25-dstn** command.
 3. View the DPC table. Enter the **rtrv-dstn** command.
 4. View the linksets. Enter the **rtrv-ls** command.
 5. Re-enter the command specifying a point code shown in step 3 that is not shown in step 4 as an adjacent point code. Also, ensure that the point code has an X.25 address (from step 2) that does not have an X.25 route with the logical channel to network management mapping function on ("no" is displayed in the LC2NM field in step 1).
-

E2647 Cmd Rej: Only one of PCN or PCN24 may be specified

Commands Used: `chg-sid`, `ent-sid`

You cannot specify both the `pcn` and `pcn24` parameters in the same command.

Recovery

Re-enter the command specifying either the `pcn` or `pcn24` parameter, but not both.

E2648 Cmd Rej: Failed reading the route table

Commands Used: `chg-dstn`, `chg-gsmmap-scrn`, `chg-gsmopts`,
`chg-gsms-opcode`, `chg-gta`, `chg-gtt`, `chg-gws-redirect`, `chg-ls`,
`chg-map`, `chg-mrn`, `chg-rte`, `chg-rtx`, `chg-sccp-serv`, `chg-sid`,
`chg-x25-dstn`, `dlt-dstn`, `dlt-ls`, `dlt-rte`, `dlt-rtx`, `dlt-slk`,
`dlt-spc`, `ent-dstn`, `ent-gsmmap-scrn`, `ent-gsms-opcode`,
`ent-gta`, `ent-gtt`, `ent-gws-redirect`, `ent-ls`, `ent-map`,
`ent-mrn`, `ent-rmt-appl`, `ent-rte`, `ent-rtx`, `ent-spc`,
`ent-x25-dstn`, `ent-x25-rte`, `rtrv-dstn`, `rtrv-rte`, `rtrv-rtx`

The Route table is corrupt or cannot be found by the system. The Route table must be accessible.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2649 Cmd Rej: Failed reading the X.25 destination table

Commands Used: `chg-x25-dstn`, `dlt-x25-dstn`, `ent-x25-rte`,
`rtrv-x25-dstn`

The X.25 Destination table is corrupt or cannot be found by the system. The X.25 Destination table contains the shelf attribute information.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2650 Cmd Rej: Failed reading the X.25 route table

Commands Used: `chg-x25-dstn`, `chg-x25-rte`, `dlt-x25-dstn`,
`dlt-x25-rte`, `ent-x25-rte`

The X.25 Route table is corrupt or cannot be found by the system. The X.25 Route table contains the shelf attribute information.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2654 Cmd Rej: Max Packet Size must be 128 when N1 is equal to 1080

Commands Used: `chg-x25-s1k`

You cannot specify `n1=1080` if the `mps=256`. If you specify `n1=1080`, the value of the `mps` parameter must be `128`.

Recovery

Perform one of the following:

- Re-enter the `chg-x25-s1k` command specifying `n1=1080` and `mps=128`.
- OR
- Re-enter the `chg-x25-s1k` command, and omit both parameters, to accept the system defaults of a `256` byte maximum packet size, and `2104` maximum number of bits in a frame.
-

E2655 Cmd Rej: X.25 Address must contain at least four digits

Commands Used: `chg-x25-dstn`, `chg-x25-rte`, `dlt-x25-dstn`,
`dlt-x25-rte`, `ent-x25-dstn`, `ent-x25-rte`, `rtrv-x25-dstn`,
`rtrv-x25-rte`

The specified X.25 address (`xaddr`) contained less than four digits. These commands require that the `xaddr` parameter have a minimum of four digits.

Recovery

Re-enter the command specifying an X.25 address parameter (**xaddr**) parameter at least four digits in length.

E2656 Cmd Rej: GTT must be ON before MGTT can be ON

Commands Used: **chg-feat**

You must turn on the Global Title Translation (GTT) feature before you can turn on the Global Title Translation Modifications (MGTT) feature.

Recovery

1. Verify that the GTT feature is turned off. Enter the **rtrv-feat** command.
 2. Turn on the GTT feature. Enter the **chg-feat:gtt=on** command.
 3. Turn on the MGTT feature. Enter the **chg-feat:mgtt=on** command.
-

E2657 Cmd Rej: Point code not defined

Commands Used: chg-dstn, chg-gws-redirect, chg-ls, chg-rte, chg-x25-dstn, dlt-dstn, dlt-rmt-appl, dlt-rte, ent-gws-redirect, ent-ls, ent-rmt-appl, ent-rte, ent-x25-dstn, rtrv-dstn, rtrv-rte, rtrv-x25-dstn

The specified destination point code (DPC) could not be found in the database. To execute the command, the destination point code must be in the Destination Point Code table.

OR

The specified end node internal point code could not be found in the database. To execute the command the internal point code must be in the Destination Point Code table

The following Recovery procedures list the remedial action for commands that generates this error message.

Recovery - **rtrv-dstn**

Re-enter the **rtrv-dstn** command specifying no parameters, to display all the destination point codes in the database.

Recovery - rtrv-rte

Re-enter the **rtrv-rte** command specifying no parameters, to display all routes in the database.

Recovery - rtrv-x25-dstn

Re-enter the **rtrv-x25-dstn** command specifying no parameters, to display all X.25 destinations in the database.

Recovery - chg-dstn, chg-ls, chg-x25-dstn, dlt-dstn, ent-ls, ent-rte, ent-x25-dstn

Verify that the command was entered correctly, and re-enter the command.

OR

1. Display the destination point codes in the database. Enter the **rtrv-dstn** command.
 2. Re-enter the command specifying a destination point code shown in the output of step 1.
-

Recovery - chg-gws-redirect, ent-gws-redirect

1. Display the destination point codes in the database. Enter the **rtrv-dstn** or **rtrv-sid** command, as you require.
 2. Re-enter the command specifying a destination point code shown in the output of step 1.
-

Recovery - dlt/ent-rmt-appl

1. Display the existing internal point codes in the Destination table. Enter the **rtrv-dstn** command.
 2. Re-enter the command specifying an existing internal point code displayed in step 1.
-

Recovery - chg-rte, dlt-rte

Verify that the command was entered correctly and re-enter the command.

OR

1. Display the Route table. Enter the **rtrv-rte** command specifying no parameters to display all the routes in the database.
 2. Re-enter the command specifying a point code displayed in step 1.
-

E2658 Cmd Rej: X.25 address already exists in X.25 destination table

Commands Used: ent-x25-dstn

The specified X.25 address (**xaddr**) is already in the database. The X.25 address must be unique in the database.

Recovery

1. Display the X.25 destinations in the database. Enter the **rtrv-x25-dstn** command.
 2. Re-enter the command specifying an X.25 address that is not shown in the output of step 1.
-

E2659 Cmd Rej: X.25 address cannot be referenced by route

Commands Used: chg-x25-dstn, dlt-x25-dstn

The specified X.25 address (**xaddr**) is referenced by the X.25 routing table. To execute these commands, the X.25 address cannot be referenced by any X.25 routes.

Recovery

1. Display the X.25 routes in the database. Enter the **rtrv-x25-rte** command.
 2. Delete the X.25 routes that reference the specified X.25 address. Enter the **dlt-x25-rte** command.
 3. Re-enter the command that generated this error message.
-

E2660 Cmd Rej: X.25 address does not exist in X.25 destination table

Commands Used: `chg-x25-dstn`, `dlt-x25-dstn`, `ent-x25-rte`,
`rtrv-x25-dstn`

The specified X.25 address (**xaddr**) cannot be found in the database. These commands require that the X.25 address be in the database.

Recovery

1. Display the X.25 destinations in the database. Enter the `rtrv-x25-dstn` command.
2. Re-enter the command specifying an X.25 address that is shown in the output of step 1.

E2661 Cmd Rej: X.25 destination table is full

Commands Used: `ent-x25-dstn`, `chg-x25-dstn`, `chg-stpopts`
`chg-x25-dstn`, `ent-x25-dstn`

The X.25 Destination table already contains the maximum of destinations, and you attempted to add another X.25 destination. The maximum number allowed depends on the features you have turned on. If you have the X.25 feature turned on, the maximum number is **1024**. If you have both the X.25 and the x252000 features turned on, the maximum number is **2000**.

You can enter the `rtrv-feat` command to check which features are turned on for your system. If the X.25 feature is on, the output shows `x25g=on`. If the x252000 feature is on, the output shows both `x25g=on` and `x252000=on`.

To add a new X.25 destination if you have reached the maximum, perform one of the procedures in Table 2-14.

Table 2-14. Action if X.25 Route Table is Full

To Perform this Action	Follow this Procedure
Change an existing destination.	Display the X.25 destinations in the database. Enter the <code>rtrv-x25-dstn</code> command. Enter the <code>chg-x25-dstn</code> command specifying the new X.25 destination information.
Delete an existing X.25 destination and add the new one.	Enter the <code>dlt-x25-dstn</code> command. Re-enter the command that generated this error message.

Table 2-14. Action if X.25 Route Table is Full (Continued)

To Perform this Action	Follow this Procedure
Increase the maximum number of destinations allowed if x252000 feature is not yet on.	Enter chg-feat:x252000=on . Re-enter the command that generated this error message.

For the **chg-stpopts** command, you cannot increase the number of DPCs configured, using the **mtpdpcq** parameter, if space allocated for maintaining x-list entries (**mtpxlq** parameter) becomes full. The values of the **mtpxlq** and **mtpdpcq** parameters are interdependent; that is, if you want to increase the number of DPCs that can be configured, you must decrease the number of x-list entries that the STP is to maintain. Conversely, if you increase the number of x-list entries that the STP maintains, you must decrease the number of DPCs that can be provisioned.

Call your Customer Care Center if this error message appears again.

Recovery

1. Verify that the x-list storage is full, or nearly full. Enter the **rept-stat-xlist** command. This command displays a snapshot of the statistics related to the storage of x-list entries. The percentage of space in the x-list reserved area currently in use is displayed in the Current X-LIST occupancy field. When the x-list storage is full, the percentage of space displayed in this field is 100%.
 2. If the percentage of space displayed in step 1 is less than 100%, re-enter the command.
-

E2662 Cmd Rej: Maximum SVCAs already defined for link

Commands Used: **chg-x25-rte**, **ent-x25-rte**

You tried to assign an automatic switched virtual circuit (SVCA) to a signaling link (**loc** and **port**) that contains the maximum number of switched virtual circuits (SVC). The maximum number of SVCs for a signaling link is defined by the **chg-x25-slk** command.

Recovery

1. Display the maximum number of SVCs allowed for the signaling link. Enter the **rtrv-x25-slk** command specifying the card location and port of the signaling link. The maximum number of SVCs defined for the X.25 signaling link is shown in the SVC field of the output.

2. Display the X.25 routes in the database. Enter the **rtrv-x25-rte** command specifying the **type=svca** parameter. The number of SVCs assigned to the specified signaling link should be equal to the number in the **SVC** field in the output of step 1.
 3. If the total of PVCs and SVCs defined for this X.25 signaling link is less than **255**, shown in the **PVC** and **SVC** fields of the output of step 1, change the number of SVCs. Enter the **chg-x25-slk** command and a higher value for the **svc** parameter.
 4. Re-enter the command that generated this error message.
 5. If the total of PVCs and SVCs defined for this X.25 signaling link is **255**, delete an X.25 route with a connection type of SVCA (**type=svca**) assigned to the specified signaling link. Enter the **dlt-x25-rte** command.
 6. Re-enter the command that generated this error message.
-

E2663 Cmd Rej: Combination of X.25 addresses not in X.25 route table

Commands Used: **chg-x25-rte**, **dlt-x25-rte**

The combinations of X.25 addresses entered in the command line cannot be found in the X.25 routing table. These X.25 addresses combinations cannot be changed or deleted if they are not in the X.25 routing table.

Recovery

1. Display the entries in the X.25 routing table. Enter the **rtrv-x25-rte** command.
 2. Re-enter the command specifying X.25 addresses that are shown in the output of step 1.
-

E2664 Cmd Rej: LC must be specified when TYPE=PVC

Commands Used: **ent-x25-rte**

You specified the **type=pvc** parameter and without the **lc** parameter. The **lc** parameter is required when the **type=pvc** parameter is specified.

Recovery

Re-enter the **ent-x25-rte** command specifying both the **type=pvc** and the **lc** parameters.

E2665 Cmd Rej: LC can only be specified when TYPE=PVC

Commands Used: `ent-x25-rte`, `rtrv-x25-rte`

You cannot specify the `lc` parameter and the `type=svca` or `type=svcr` parameters. The connection types SVCA (`type=svca`) or SVCR (`type=svcr`) cannot be specified with the `lc` parameter. Only the connection type PVC (`type=pvc`) can be specified with the `lc` parameter.

Recovery

Perform one of the following:

- Re-enter the command specifying the `lc` and `type=pvc` parameters, or
OR
 - Re-enter the command specifying either the `type=svca` or `type=svcr` parameters, and without the `lc` parameter.
-

E2666 Cmd Rej: LOC must be specified when TYPE=PVC or SVCA

Commands Used: `chg-x25-rte`, `ent-x25-rte`

You cannot specify the `type=pvc` or `type=svca` parameters without specifying the `loc` parameter. If the `type=pvc` or `type=svca` parameters are specified, the `loc` parameter must be specified.

Recovery

1. Display the cards in the database. Enter the `rtrv-card` command.
 2. Re-enter the command specifying either the `type=pvc` or `type=svca` parameters and a card location (`loc` parameter) shown in the output of step 1. This card location must be either a `limsd0`, `limocu`, or `limv35` card type and must be assigned the `ss7gx25` application. The card types are shown in the TYPE field, and the applications are shown in the APPL field, of the `rtrv-card` output.
-

E2667 Cmd Rej: LOC must not be specified when TYPE=SVCR

Commands Used: `rtrv-x25-rte`

You cannot specify the `type=svcr` and the `loc` parameters. If the `type=svcr` parameter is specified, the `loc` parameter cannot be specified.

Recovery

Re-enter the **rtrv-x25-rte** command specifying the **type=svcr** parameter without specifying the **loc** parameter.

E2668 Cmd Rej: PORT must not be specified when TYPE=SVCR

Commands Used: **chg-x25-rte**, **ent-x25-rte**

You cannot specify the **port** parameter if **type=svcr**. You can specify the **port** parameter only with the **loc** parameter. The **loc** parameter cannot be specified with the **type=svcr** parameter.

The **port** parameter can be specified only with the **loc** parameter. Neither the **loc** nor the **port** parameters cannot be specified with the **type=svcr** parameter.

Recovery

Re-enter the command specifying the **type=svcr** parameter without specifying the **port** parameter.

E2669 Cmd Rej: SS7 address does not exist in X.25 destination table

Commands Used: **ent-x25-rte**

The specified SS7 address (**saddr**, the dummy X.25 address assigned to the SS7 destination point code) could not be found in the X.25 destination table. This command requires that the SS7 address be in the X.25 destination table.

Recovery

1. Display the X.25 destinations (**xaddr**) in the database. Enter the **rtrv-x25-dstn** command.
 2. Display the DPCs in the database. Enter the **rtrv-dstn** command.
 3. Using the output from steps 1 and 2 as a guide, re-enter the **ent-x25-rte** command that generated this error message, with an SS7 address (**saddr**) that is assigned to the SS7 domain and is in the X.25 destination table.
-

E2670 Cmd Rej: DPC assigned to X25 address does not exist in X25 domain

Commands Used: `ent-x25-rte`

You specified a value for the **xaddr** (X.25 address) parameter whose destination point code is not in the X.25 domain.

Recovery

1. Display the destination point codes in the database. Enter the `rtrv-dstn` command.
 2. Display the X.25 addresses in the X.25 destination table. Enter the `rtrv-x25-dstn` command.
 3. Using the output from steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying a destination point code that is in the X.25 domain.
-

E2671 Cmd Rej: DPC assigned to SS7 address does not exist in SS7 domain

Commands Used: `ent-x25-rte`

You specified a value for the SS7 X.25 address (**saddr**) parameter whose destination point code is not in the SS7 domain.

Recovery

1. Display the destination point codes in the database. Enter the `rtrv-dstn` command.
 2. Display the X.25 addresses in the X.25 destination table. Enter the `rtrv-x25-dstn` command.
 3. Using the output from steps 1 and 2 as a guide, re-enter the `ent-x25-rte` command specifying a destination point code that is in the SS7 domain.
-

E2672 Cmd Rej: DPC assigned to X.25 address has no SS7 routes

Commands Used: `ent-x25-rte`

The destination point code (DPC) associated with the X.25 address (**xaddr**) does not have any routes assigned to it. For the execution of this command to be successful, the DPC must have at least one route assigned to it.

Recovery

1. Display the X.25 destinations in the database. Enter the **rtrv-x25-dstn** command.
 2. Display the routes in the database. Enter the **rtrv-rte** command.
 3. Perform one of the following:
 - Using the output from steps 1 and 2 as a guide, re-enter the **ent-x25-rte** command, with an X.25 address whose DPC has at least one route assigned to it.OR
 - Using the output from steps 1 and 2 as a guide, re-enter the **ent-x25-rte** command specifying the **dstn** but not the route.
 4. Re-enter the original command.
-

E2673 Cmd Rej: DPC assigned to SS7 address has no SS7 routes

Commands Used: **ent-x25-rte**

The destination point code (DPC) associated with the SS7 address (**saddr**) does not have any routes assigned to it. For the execution of this command to be successful, the DPC must have at least one route assigned to it.

Recovery

1. Display the X.25 destinations in the database. Enter the **rtrv-x25-dstn** command.
 2. Display the routes in the database. Enter the **rtrv-rte** command.
 3. Perform one of the following:
 - Using the output from steps 1 and 2 as a guide, re-enter the **ent-x25-rte** command specifying an SS7 address whose DPC has at least one route assigned to it.OR
 - Using the output from steps 1 and 2 as a guide, re-enter the **ent-x25-rte** command specifying the **dstn** but not the route.
 4. Re-enter the original command.
-

E2674 Cmd Rej: Combination of X.25 addresses exists in X.25 route table**Commands Used: ent-x25-rte**

The X.25 addresses entered in the command line are already in the X.25 routing table. These X.25 addresses cannot be entered if they are already in the X.25 routing table.

Recovery

1. Display the entries in the X.25 routing table. Enter the **rtrv-x25-rte** command.
 2. Display the entries in the X.25 destination table. Enter the **rtrv-x25-dstn** command.
 3. Re-enter the **ent-x25-rte** command, with X.25 addresses that are shown in the output of step 2 and that are not in the output of step 1.
 4. If the X.25 addresses you wish to enter are not shown in the output of step 2, add the X.25 addresses to the X.25 destination table using the **ent-x25-dstn** command, then re-enter the **ent-x25-rte** command specifying those X.25 addresses.
-

E2675 Cmd Rej: Combination of SS7 PC/SSNs exists in X.25 route table**Commands Used: ent-x25-rte**

The SS7 point codes and subsystem combinations associated with the X.25 addresses entered in the command line are already in the X.25 routing table. These point code and subsystem combinations cannot be entered if they are already in the X.25 routing table.

Recovery

1. Display the entries in the X.25 routing table. Enter the **rtrv-x25-rte** command.
 2. Display the entries in the X.25 destination table. Enter the **rtrv-x25-dstn** command.
 3. Re-enter the **ent-x25-rte** command, with X.25 addresses that are shown in the output of step 2 and that are not in the output of step 1.
 4. If the X.25 addresses you wish to enter are not shown in the output of step 2, add the X.25 addresses to the X.25 destination table using the **ent-x25-dstn** command, then re-enter the **ent-x25-rte** command specifying those X.25 addresses.
-

E2676 Cmd Rej: X.25 route table is full

Commands Used: `ent-x25-rte`, `chg-x25-rte`

The X.25 route table already contains the maximum of routes, and you attempted to add another X.25 route. The maximum number allowed depends on the features you have turned on. If you have the X.25 feature turned on, the maximum number is 1024. If you have both the X.25 and the x252000 features turned on, the maximum number is 2000.

You can enter the `rtrv-feat` command to check which features are turned on for your system. If the X.25 feature is on, the output shows `x25g=on`. If the x252000 feature is on, the output shows both `x25g=on` and `x252000=on`.

Recovery

To add a new X.25 route if you have reached the maximum, perform one of the procedures in Table 2-15.

Table 2-15. Action if X.25 Route Table is Full

To Perform this Action	Follow This Procedure
Change an existing route.	Display the X.25 routes in the database. Enter the <code>rtrv-x25-rte</code> command. To change an existing X.25 route, enter the <code>chg-x25-rte</code> command specifying the new X.25 route information.
Delete an existing X.25 route and add the new one.	Delete an existing X.25 route. Enter the <code>dlt-x25-rte</code> command. Re-enter the command that generated this error message.
Increase the maximum number of routes allowed if the x252000 feature is not yet on.	Enter <code>chg-feat:x252000=on</code> . Re-enter the command that generated this error message.

E2677 Cmd Rej: Link not equipped

Commands Used: `ent-x25-rte`

The specified signaling link (**loc** and **port**) could not be found in the database. This command requires that an X.25 signaling link be in the database.

Recovery

1. Display the signaling links in the database. Enter the **rtrv-slk** command. The X.25 signaling links are shown in the output by dashes in the L2TSET field.
 2. Re-enter the **ent-x25-rte** command specifying an X.25 signaling link shown in the output of step 1.
-

E2678 Cmd Rej: Link not assigned to SS7-X.25 card

Commands Used: **rept-x25-meas**

The card containing the signaling link, specified in this command by the **loc** and **port** parameters, is not a LIM using the **ss7gx25** application. Only signaling links assigned to LIMs using the **ss7gx25** application can be specified with this commands.

Recovery

1. Verify the applications assigned to the cards. Enter the **rtrv-card** command.
 2. Verify that the cards running the **ss7gx25** application, shown in the APPL field in the output of step 1, have signaling links assigned to them. Enter the **rtrv-slk** command.
 3. Using the output from steps 1 and 2 as a guide, re-enter the **rept-x25-meas** command specifying a card location (**loc**) that is running the **ss7gx25** application that has a signaling link assigned to it, and the corresponding port on that card.
-

E2679 Cmd Rej: LC greater than maximum PVCs for link

Commands Used: **ent-x25-rte**

The logical channel number specified with this command is greater than the maximum number of PVCs allowed for the signaling link. The **ent-x25-rte** command does not allow this.

Recovery

1. View the x25 signal link information. Enter the **rtrv-x25-slk** command.
 2. Re-enter the **ent-x25-rte** command specifying a logical channel number that is less than the number PVCs determined in step 1.
-

E2680 Cmd Rej: LC already in use

Commands Used: `ent-x25-rte`

The specified logical channel of the signaling link is assigned to another X.25 route. The logical channel specified in this command cannot be assigned to another X.25 route.

Recovery

1. Display all X.25 routes in the database. Enter the `rtrv-x25-rte` command.
 2. Re-enter the `ent-x25-rte` command specifying the `type=pvc` parameter, and a logical channel for the X.25 route that is not assigned to another X.25 route at this logical channel.
-

E2681 Cmd Rej: Cannot change if existing connection type is PVC

Commands Used: `chg-x25-rte`

The specified X.25 route has a connection type of PVC (permanent virtual circuit). An X.25 route that has a connection type of PVC cannot be changed with this command. To use this command, the connection type must be SVCA (automatic virtual circuit) or SVCR (remote virtual circuit).

Recovery

1. Display the X.25 routes in the database. Enter the `rtrv-x25-rte` command. The connection type is shown in the TYPE field of the output.
 2. Re-enter the `chg-x25-rte` command specifying an X.25 route that has a connection type of either SVCA or SVCR.
-

E2682 Cmd Rej: New connection type must be different from existing

Commands Used: `chg-x25-rte`

The connection type of the specified X.25 signaling link was not changed by this command. For example, the connection type of the X.25 signaling link is SVCA (automatic switched virtual circuit), and the command was entered with the `type=svca` parameter. When this command is entered, the connection type must be changed.

Recovery

1. Display the X.25 routes in the database. Enter the **rtrv-x25-rte** command. The connection type of the X.25 signaling links is shown in the *TYPE* field of the output.
 2. If the connection type of the specified X.25 signaling link is SVCA, re-enter the command specifying the **type=svcr** parameter.
 3. If the connection type of the specified X.25 signaling link is SVCR, re-enter the command specifying the **type=svca** parameter.
-

E2683 Cmd Rej: Cannot specify LC without LOC**Commands Used: rtrv-x25-rte**

You cannot specify the **lc** parameter without specifying the **loc** parameter. If the **lc** parameter is specified, the **loc** parameter must be specified.

Recovery

Re-enter the **rtrv-x25-rte** command specifying both the **lc** and **loc** parameters.

E2684 Cmd Rej: N1 must be either 1080 or 2104**Commands Used: chg-x25-slk**

You specified a value for the **n1** parameter that was not **1080** or **2104**. The only values allowed for this parameter is **1080** or **2104**.

Recovery

Re-enter the command specifying either **1080** or **2104** for the value for the **n1** parameter.

E2685 Cmd Rej: MPS must be either 128 or 256**Commands Used: chg-x25-slk**

You assigned an invalid value to the maximum packet size (**mps**) parameter. The only valid values are **128** and **256**.

Recovery

Re-enter the **chg-x25-s1k** command that generated this error message specifying a value of either **128** or **256** for the **mpps** parameter.

Call your Customer Care Center if this error message appears again.

E2686 Cmd Rej: PVC plus SVC must be at least 1

Commands Used: chg-x25-s1k

You specified the sum of the values for the **pvc** and **svc** parameters being **0** (for example, **pvc=0** and **svc=0**). The sum of the values for the **pvc** and **svc** parameters must be greater than **0**.

Recovery

Re-enter the **chg-x25-s1k** command specifying a value greater than **0** for either the **pvc** and/or **svc** parameter.

E2687 Cmd Rej: PVC plus SVC cannot be greater than 255

Commands Used: chg-x25-s1k

You specified the sum of the values for the **pvc** and **svc** parameters being greater than **255** (for example, **pvc=125** and **svc=150**). The sum of the values for the **pvc** and **svc** parameters cannot exceed **255**.

Recovery

Re-enter the **chg-x25-s1k** command and make sure that the sum of the values for the **pvc** and **svc** parameters does not exceed **255**.

E2688 Cmd Rej: Cannot decrease PVC below a logical channel in use

Commands Used: chg-x25-s1k

You specified a value for the **pvc** parameter that was less than the number of logical channels assigned to the X.25 signaling link. The number of PVCs cannot be less than the number of logical channels for a particular X.25 signaling link.

Recovery

1. Display the number of PVCs assigned to the X.25 signaling link. Enter the **rtrv-x25-slk** command, with the card location and port used in the command that generated this error message. The number of PVCs is shown in the PVC field of the output.
 2. Display the logical channels for the X.25 routes assigned to the X.25 signaling link displayed in step 1. Enter the **rtrv-x25-rte** command. The number of logical channels is shown in the LC field of the output.
 3. Perform one of the following:
 - Re-enter the command specifying a value for the **pvc** parameter that is equal to or greater than the number of logical channels displayed in step 2.OR
 - Use the **dlt-x25-rte** command to delete a logical channel.
 4. Re-enter the **chg-x25-slk** command.
-

E2689 Cmd Rej: Cannot decrease SVC below number of SVCs already in use

Commands Used: **chg-x25-slk**

The new quantity of SVCs assigned to the specified signaling link is less than the amount used by the X.25 route associated with the X.25 signaling link. The amount of SVCs assigned to an X.25 signaling link must be equal to or greater than the amount used by the X.25 route associated with the signaling link.

Recovery

1. Display the X.25 routes associated with the specified X.25 signaling link. Enter the **rtrv-x25-rte** command specifying the card location of the specified X.25 signaling link. The connection type is shown in the TYPE field of the output.
2. Count the number of SVCAs in the output of step 1.

3. Perform one of the following actions:
 - Re-enter the **chg-x25-s1k** command specifying a value for the **svc** parameter that is equal to greater than the number of SVCAs determined in step 2.OR
 - Use the **dlt-x25-rte** command to delete an SVC.
 4. Re-enter the **chg-x25-s1k** command.
-

E2690 Cmd Rej: LOC not assigned a X.25 signaling link

Commands Used: chg-x25-s1k

The specified card location was not an X.25 signaling link.

Recovery

1. Display the signaling links in the database. Enter the **rtrv-x25-s1k** command.
 2. Re-enter the **chg-x25-s1k** command specifying a card location that is an X.25 signaling link as shown in step 1.
-

E2691 Cmd Rej: Card is not a SS7GX25 card

Commands Used: chg-x25-s1k

You specified a card that is not assigned the **ss7gx25** application.

Recovery

1. Display the cards in the database. Enter the **rtrv-x25-s1k** command.
 2. Re-enter the **chg-x25-s1k** command specifying a **ss7gx25** card location shown in step 1.
-

E2692 Cmd Rej: FWORD can only be used with PADDR

Commands Used: set-mem

You specified an invalid parameter. You can enter only one of the following parameters, **byte**, **word**, or **dword**.

Recovery

Re-enter the **set-mem** command that generated this error message specifying the correct **byte**, **word**, or **dword** parameter value.

Call your Customer Care Center if this error message appears again.

E2693 Cmd Rej: FWORD is not supported at this time

Commands Used: **disp-bp**, **disp-mem**, **ent-bp**, **set-mem**

You specified an invalid parameter. You can enter only one of the following parameters, **byte**, **word**, or **dword**; however, you must enter one of them.

Recovery

Re-enter the command that generated this error message specifying the correct **byte**, **word**, or **dword** parameter value.

Call your Customer Care Center if this error message appears again.

E2694 Cmd Rej: Invalid combination of ADDR and PADDR specified

Commands Used: **disp-mem**, **dlt-bp**, **ent-bp**, **set-mem**

You can enter only one of the parameters **addr** or **paddr**.

Recovery

Re-enter the command that generated this error message specifying either the **addr** or **paddr** parameter, but not both.

Call your Customer Care Center if this error message appears again.

E2695 Cmd Rej: DPADDR cannot be entered with DR/DA

Commands Used: **ent-bp**

The **dpaddr** parameter cannot be entered with the **da** or **dr** parameters.

Recovery

Re-enter the **ent-bp** command that generated this error message specifying the correct **dpaddr**, **da**, or **dr** parameter value.

Call your Customer Care Center if this error message appears again.

E2696 Cmd Rej: REP cannot be specified when DUR=PERM

Commands Used: **ent -bp**

You attempted to define a breakpoint that was both permanent, and repeating. You cannot enter the **dur=perm** and the **rep** parameters at the same time.

Recovery

Re-enter the **ent -bp** command that generated this error message specifying the correct **dur** or **rep** parameter value.

Call your Customer Care Center if this error message appears again.

E2697 Cmd Rej: IND cannot be greater than 3

Commands Used: **ent -bp**

You cannot enter the **ent -bp** command specifying a value greater than **3** for the **ind** parameter.

Recovery

Re-enter the **ent -bp** command specifying a value less than **3** for the **ind** parameter.

Call your Customer Care Center if this error message appears again.

E2698 Cmd Rej: DUR=PERM can only be specified with a 486 processor

Commands Used: **ent -bp**

You cannot enter the **ent -bp** command specifying the **dur=perm** parameter if the processor is not a 80486 CPU.

Recovery

Perform one of the following:

- Re-enter the **ent-bp** command that generated this error message and omit the **dur** parameter,
- OR
- Re-enter the **ent-bp** command that generated this error message and set the **dur** parameter to **temp**.

Call your Customer Care Center if this error message appears again.

E2699 Cmd Rej: DATA can only be specified with P486

Commands Used: **ent-bp**

The value **data** for the breakpoint-type portion of the **type** parameter can only be specified with the value **p486** for the processor-type portion of the **type** parameter.

Recovery

Re-enter the **ent-bp** command that generated this error message specifying the correct value **p486** for the processor-type portion of the **type** parameter.

Call your Customer Care Center if this error message appears again.

E2700 Cmd Rej: ACCESS can only be specified with TYPE=P486-DATA

Commands Used: **ent-bp**

You can specify the **access** parameter only when the value of the processor-type portion of the **type** parameter is **p486**.

Recovery

Re-enter the **ent-bp** command that generated this error message specifying the correct value (**p486**) of the processor type portion of the **type** parameter.

Call your Customer Care Center if this error message appears again.

E2701 Cmd Rej: Meas Platform feature must be ON

Commands Used: `chg-measopts`, `ent-card`, `rept-ftp-meas`,
`rept-stat-meas`, `rtrv-measopts`

The Measurements Platform feature must be turned on before you can use these commands.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Verify that the Measurements Platform feature is turned on. Enter the `rtrv-feat` command. If the Measurements Platform feature is off, you must turn it on before you can re-enter the command that generated the error message.
 2. To turn on the Measurements Platform feature. Enter the `chg-feat:measplat=on` command.
 3. When the Measurements Platform feature is turned on, re-enter the command that generated the error message.
-

E2702 Cmd Rej: At least one MCPM card must be configured in system

Commands Used: `rept-stat-meas`

At least one MCPM card must be configured in the EAGLE 5 ISS for the Measurements Platform feature, before you can enter the `rept-stat-meas` command.

Recovery

1. Enter the `rept-stat-card` command and verify that there is at least one MCPM card configured in the EAGLE 5 ISS for the Measurements Platform.
2. If there are no MCPM cards configured in the system, you cannot use this command.
3. If there is at least one MCPM card configured in the system, re-enter the command that generated the error message.

Call your Customer Care Center if this error message appears again.

E2703 Cmd Rej: Missing parameter - DPADDR or DR

Commands Used: `ent-bp`

You attempted to set a break point, but omitted the necessary `dpaddr` or `dr` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `dpaddr` or `dr` parameter value.

Call your Customer Care Center if this error message appears again.

E2704 Cmd Rej: Invalid IPADDR

Commands Used: `chg-ftp-serv`, `chg-ip-card`, `chg-ip-lnk`,
`dlt-ftp-serv`, `ent-ftp-serv`, `ent-ip-host`, `rtrv-ftp-serv`,
`rtrv-ip-host`, `tst-dlk`

You entered the command for an IP address (`ipaddr` parameter) that does not exist in the database, or you specified an `ipaddr` parameter value that does not conform to the value's specified naming conventions. An IP address consists of the system's network number and the machine's unique host number (four numbers separated by dots, with each number in the range of 0-255). An IP address example is **192.9.200.44**, where **192.9.200** is the network number and **44** is the machine's host number.

The following Recovery procedures apply to the specific command that generated this error message.

Recovery - tst-dlk

1. Display the IP addresses configured in the database. Enter the `rtrv-dlk` command.
2. Re-enter the `tst-dlk` command specifying an IP address that exists in the database.

OR

1. Add the IP address to the database. Enter the `ent-dlk` command.
 2. Re-enter the `tst-dlk` command.
-

**Recovery - chg-ftp-serv, chg-ip-card, chg-ip-lnk, dlt-ftp-serv,
ent-ip-host, ent-ftp-serv, rtrv-ftp-serv,
rtrv-ip-host**

Re-enter the command specifying a value for the IP address that conforms to the specified naming conventions.

Call your Customer Care Center if this error message appears again.

E2705 Cmd Rej: IP Node Address never entered or Card DB corrupt

Commands Used: dlt-ip-node, ent-ip-node

If you specify the **loc** and **ipaddr** parameters, the specified IP address must match the IP address of the card location's remote IP node.

Recovery

Re-enter the command that generated this error message specifying the correct **ipaddr** parameter value.

Call your Customer Care Center if this error message appears again.

E2706 Cmd Rej: APPL is invalid for report or entity

Commands Used: rept-meas

You specified the **appl** parameter with an **enttype** parameter value that is not **stplan** and a **type** that is not **avl**. The **appl** parameter is valid only with **enttype=stplan** and **type=avl**.

Recovery

Re-enter the command specifying the correct combination of parameters.

Refer to the **rept-meas** command description in the *Commands Manual* for valid parameter combinations.

Call your Customer Care Center if this error message appears again.

E2707 Cmd Rej: LOC is invalid for specified report TYPE

Commands Used: `rept-meas`

You specified the `loc` parameter with the `type=systot` parameter. This combination is not allowed.

Recovery

Re-enter the `rept-meas` command specifying the `type=systot` parameter, and without the `loc` parameter.

E2708 Cmd Rej: APPL or LOC must be specified

Commands Used: `rept-meas`

The command was entered with both the `appl` and `loc` parameters. Either of these parameters may be entered, but not both.

Recovery

Re-enter the `rept-meas` command specifying either the `appl`, or the `loc` and `port` parameters.

E2709 Cmd Rej: APPL is invalid for specified PERIOD

Commands Used: `rept-meas`

You specified the `appl` parameter, and either the `period=active` or `period=all` parameters. The `appl` parameter can be used only with the `period=last` or the `period=specific` parameters.

Recovery

Re-enter the `rept-meas` command specifying the `appl` parameter, and either the `period=last` or the `period=specific` parameters.

E2710 Cmd Rej: Cannot assign ITU and ANSI LHOST to the same AS

Commands Used: `chg-assoc`, `ent-as`

You entered a `chg-assoc` command to change the `lhost` for a specified association. The current `lhost` and the specified new `lhost` are running different types of applications (ITU or ANSI). This is not allowed.

OR

You entered an **ent-as** command to assign an M3UA/SUA association (adapter type) to an application server (AS). The associations assigned to the specified M3UA/SUA association (adapter type) are assigned to a different type of **lhost** than the **lhost** type for the associations for the M3UA/SUA associations (adapter type) already assigned to the AS (ITU or ANSI). This is not allowed.

Recovery - **chg-assoc**

1. Display the IP address for the current and new association local hosts (**lhost**). Enter the **rtrv-ip-host** command
 2. Display the card location for each **lhost** IP address from step 1. Enter the **rtrv-ip-lnk** command.
 3. Display the application that is running on each **lhost** card. Enter the **rtrv-card** command. The **ss7ipgw** and **iplim** applications are ANSI, and the **ipgwi** and **iplimi** applications are ITU.
 4. Re-enter the **chg-assoc** command that generated this error message specifying parameters that change the **lhost** for the association to a new **lhost** of the same type.
-

Recovery - **ent-as**

1. Display the associations with the specified AS. Enter the **rtrv-as** command.
 2. Display the **lhost** assigned to each association for the specified M3UA/SUA association (adapter type). Enter the **rtrv-assoc** command.
 3. Display the **lhost** IP addresses. Enter the **rtrv-ip-host** command.
 4. Display the card location for one **lhost** IP address from step 3. Enter the **rtrv-ip-lnk** command.
 5. Display the application that is running on that **lhost** card. Enter the **rtrv-card** command. The **ss7ipgw** and **iplim** applications are ANSI, and the **ipgwi** and **iplimi** applications are ITU.
 6. Re-enter the **ent-as** command specifying the correct parameters to assign the M3UA/SUA association (adapter type) to an AS, so that all associations assigned to M3UA/SUA association (adapter type) on the AS have the same type of **lhost**.
-

E2711 Cmd Rej: Invalid parameter

Commands Used: `chg-gtt`, `chg-tbl`, `ent-gtt`

You specified a parameter that the software did not recognize. You may have made a clerical error, or the system may need maintenance.

For the `chg-gtt` and `chg-egtt` commands, you cannot specify the routing indicator (`ri`) and point code (`pc`) parameters, if the value for the translate indicator `xlat=udts` or `discard` is changed and the `xlat` parameter is not specified.

Recovery

Re-enter the command that generated this error message specifying the correct parameter value.

Call your Customer Care Center if this error message appears again.

E2712 Cmd Rej: RESETCHAR not valid with ACTION=CREATE

Commands Used: `chg-tbl`

If `action=create` is requested, the following parameters must be entered: `name`, `ext`, `filelength`. All other parameters are ignored or defaulted. You attempted to enter the `resetchar` parameter.

Recovery

Re-enter the command that generated this error using only the valid parameters.

Call your Customer Care Center if this error message appears again.

E2713 Cmd Rej: FILELENGTH not valid with ACTION=RESET

Commands Used: `chg-tbl`

If `action=reset` is requested, the `id` parameter must be entered. All other parameters (including `filelength`) are ignored or defaulted.

Recovery

1. Re-enter the command that generated this error message specifying only the valid parameters.
 2. Call your Customer Care Center if this error message appears again.
-

E2714 Cmd Rej: NAME not valid with ACTION=RESET

Commands Used: **chg-tbl**

If **action=reset** is requested, the **id** parameter must be entered. All other parameters (including **name**) are ignored or defaulted.

Recovery

1. Re-enter the command that generated this error message specifying only the valid parameters.
 2. Call your Customer Care Center if this error message appears again.
-

E2715 Cmd Rej: EXT not valid with ACTION=RESET

Commands Used: **chg-tbl**

If **action=reset** is requested, the **id** parameter must be entered. All other parameters (including **ext**) are ignored or defaulted.

Recovery

1. Re-enter the command that generated this error message specifying only the valid parameters.
 2. Call your Customer Care Center if this error message appears again.
-

E2716 Cmd Rej: RESETCHAR not valid with ACTION=RENAME

Commands Used: **chg-tbl**

If **action=rename** is requested, the following parameters must be entered: **id**, **name**, **ext**. All other parameters (including **resetchar**) are ignored or defaulted.

Recovery

Re-enter the **chg-tbl** command that generated this error message specifying only the valid parameters.

Call your Customer Care Center if this error message appears again.

E2717 Cmd Rej: filelength not valid with ACTION=RENAME

Commands Used: `chg-tbl`

If **action=rename** is requested, the following parameters must be entered: **id**, **name**, **ext**. All other parameters (including **filelength**) are ignored or defaulted.

Recovery

Re-enter the `chg-tbl` command that generated this error message specifying only the valid parameters.

Call your Customer Care Center if this error message appears again.

E2718 Cmd Rej: No match on REDIRECT parameter during retrieve

Commands Used: `rtrv-scr-sio`, `rtrv-scr-blkdpc`,
`rtrv-scr-blkopc`, `rtrv-scr-dpc`, `rtrv-scr-opc`

The **redirect** parameter was not found. If this is what was being verified, no further action is needed.

Recovery

Re-enter the command without specifying a **redirect** parameter.

E2719 Cmd Rej: REDIRECT can only be specified with ANSI point codes

Commands Used: `chg-gws-redirect`, `ent-gws-redirect`

You specified a value for the destination point code (**dpc**) parameter that was not an ANSI point code (either an ITU-I or ITU-N point code). These commands require that the DPC be an ANSI point code and have at least one route assigned to it.

Recovery

1. Display the routes in the database. Enter the `rtrv-rte` command. The ANSI point codes that have routes assigned to them are shown in the DPCA field.
 2. Re-enter the command that generated this error message, with a point code shown in the DPCA field in the output of step 1.
-

E2720 Cmd Rej: 386/486 register cannot be specified

Commands Used: `ent-bp`

For 80286 processors, you cannot specify **80386** or **80486** registers.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying the correct `ca` parameter value.

Call your Customer Care Center if this error message appears again.

E2721 Cmd Rej: Integer value must be less than 65535

Commands Used: `ent-bp`

For 80286 processors, integer values for registers and conditions must be less than **65535**.

Recovery

Re-enter the `ent-bp` command that generated this error message specifying a `ca` parameter value less than **65535**.

Call your Customer Care Center if this error message appears again.

E2722 Cmd Rej: BC should be less than 2000

Commands Used: `disp-mem`

You cannot specify a value for the `bc` parameter that is greater than **2000**.

Recovery

Re-enter the `disp-mem` command that generated this error message specifying a value for the `bc` parameter of **2000** or less.

Call your Customer Care Center if this error message appears again.

E2723 Cmd Rej: Password operations not allowed on a non-secure terminal

Commands Used: `chg-user`, `ent-user`, `login`

You attempted to create or modify a password from a TELNET terminal (terminal IDs 17 to 40) without the OA&M IP Security Enhancements feature turned on. This command will not execute on a TELNET terminal until this feature is turned on.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off with the `chg-ctrl-feat` command. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for more information about enabling features with access keys.

Recovery

NOTE: Password operations (such as login with expired password) are not supported on a TELNET terminal until the OA&M IP Security Enhancement feature is enabled and turned on, thus securing the TELNET terminal.

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Verify that the OA&M IP Security Enhancements feature has been purchased and installed in your system.

Contact your Customer Care Center for assistance.

3. If you have purchased and installed the OA&M IP Security Enhancements feature, you must use the `enable-ctrl-feat` and `chg-ctrl-feat` commands first to enable and then to turn on the feature.

Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information.

4. When the feature is turned on, you can re-enter the command specifying the parameters that generated this error message.
-

E2725 Cmd Rej: ANSI site id not defined

Commands Used: `act-oap-config`, `chg-dstn`, `ent-dstn`

You entered a command that requires that the ANSI site ID be provisioned in the database.

Recovery

1. Display all site identification STP point codes and capability point codes.
Enter the **rtrv-sid** command.
 2. Re-enter the command that generated this error message, and assign a valid value, acquired in step 1, to the **pc** or **pca** parameter.
Call your Customer Care Center if this error message appears again..
-

E2726 Cmd Rej: ITU-INTL site id not defined

Commands Used: **chg-sid**, **ent-dstn**

You entered this command specifying the **pci** parameter, but the international ITU site ID had not already been provisioned.

Recovery

1. Display all site identification STP point codes and capability point codes.
Enter the **rtrv-sid** command.
 2. Re-enter the **chg-sid** command that generated this error message and assign a valid value, acquired in step 1, to the **pci** parameter.
Call your Customer Care Center if this error message appears again..
-

E2727 Cmd Rej: ITU-NATL site id not defined

Commands Used: **chg-sid**, **ent-dstn**

You entered this command specifying the **pcn** parameter, but the national ITU site ID had not already been provisioned.

Recovery

1. Display all site identification STP point codes and capability point codes.
Enter the **rtrv-sid** command.
 2. Re-enter the **chg-sid** command that generated this error message, and assign a valid value, acquired in step 1, to the **pcn** parameter.
Call your Customer Care Center if this error message appears again..
-

E2728 Cmd Rej: MGTT cannot be ON if any SCCP card less than 586 processor**Commands Used: chg-feat**

You entered a command to turn on the Modified Global Title Translation (MGTT) feature, but one or more SCCP cards in the system have less than a 586 processor. All SCCP cards in the system must have at least 586 processors before you can turn on the MGTT feature.

Recovery

1. Verify that all SCCP cards in the system have at least 586 processors.
 2. When all SCCP cards have at least 586 processors, re-enter the **chg-feat:mgtt=on** command to turn on the MGTT feature.
-

E2729 Cmd Rej: TDM does not support Global Timing Interface**Commands Used: chg-stpopts**

Unless both TDM cards can support Global Timing Interface, which requires both TDM cards to have part number 870-0774-15 or later, (or 870-0774-18), the **chg-stpopts** command cannot be used to perform either:

- Setting parameter **hsclksrc=t1framed, t1unframed, e1framed, or e1unframed**, or
- Changing parameter **hsckll**.

Recovery

1. Verify the required hardware baseline is installed.
 2. Ensure that both TDM cards installed in card locations **1114** and **1116**, are part number 870-0774-15, or later, (or 870-0774-18). If your TDM cards are the incorrect part number, contact your Customer Care Center.
 3. Verify both TDM cards are IS-NR. Enter the **rtrv-card** command.
 4. Re-enter the **chg-stpopts** command.
- Call your Customer Care Center if this error message appears again.
-

E2730 Cmd Rej: SEAS Subsystem has not been provisioned**Commands Used: rept-stat-seas**

The SEAS subsystem has not been provisioned and is not part of the EAGLE 5 ISS maintenance system.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Turn on the SEAS feature using the `chg-feat:seas=on` command.
 2. Ensure that at least one OAP terminal is configured. Enter the `chg-trm:type=oap` command.
 3. Re-enter the `rept-stat-seas` command.
-

E2731 Cmd Rej: FORCE=YES must be given to inhibit last OAP terminal

Commands Used: `inh-trm`

Only one terminal is in the in-service normal (IS-NR) state. If you disable this port, you lose OAP service.

Recovery

1. Verify the status of the OAP subsystem. Enter the `rept-stat-seas` command.
 2. When you know the last OAP terminal is disabled, re-enter `inh-trm` command specifying the `force=yes` parameter.
-

E2732 Cmd Rej: Invalid TRM value for SEAS TDM port

Commands Used: `rmv-trm`

You either entered an invalid value for the `trm` parameter, or tried to inhibit the terminal that you entered this command from.

Recovery

Re-enter the `rmv-trm` command that generated this error message specifying the correct `trm` parameter value.

Call your Customer Care Center if this error message appears again.

E2733 Cmd Rej: The T1PORT at the specified location is already equipped

Commands Used: `ent-t1`

You attempted to add a T1 interface in the database using a port on the E1/T1 MIM card (`t1port = 1` or `2`) that already has a T1 interface on the card at the specified location (`t1loc`).

Recovery

1. Enter the `rtrv-t1` command to display the port and card location information for each T1 interface defined in the database. Verify that there is not a T1 interface defined for the port you specified in the `ent-t1` command.
 2. Do one of the following:
 - If a port is available without a T1 interface at the specified card location, re-enter the `ent-t1` command specifying the available port.OR
 - If no port is available without a T1 interface at the specified card location, re-enter the `ent-t1` command specifying an available E1/T1 MIM card location and port number.
-

E2734 Cmd Rej: The Channel card must be on the same shelf as its T1 card.

Commands Used: `ent-slk`

You entered a command to assign a signaling link with a timeslot for a Channel card to a T1 interface. The T1 interface that you specified to service the timeslot is not on a T1 card (`t1loc, t1port`) parameters on the same shelf with the Channel card (`loc`) parameter.

Recovery

Re-enter the `ent-slk` command specifying a T1 interface on an E1/T1 MIM card used as a T1 card that is on the same shelf with the Channel card.

E2736 Cmd Rej: All signaling links serviced by the T1 must be deactivated

Commands Used: `chg-t1, inh-card`

You entered a command that requires all signaling links that are serviced by one or both T1 interfaces on the specified E1/T1 MIM card to be deactivated before the command can execute.

You cannot change the value of one or more of the following parameters before you deactivate all of the signaling links serviced by the specified T1 interface: **framing**, **encode**, **ll**, or **t1tsel**.

You cannot inhibit the E1/T1 MIM card until you deactivate all signaling links that provide timeslots serviced by each T1 interface assigned to that card.

Recovery

1. Deactivate all signaling links with timeslots that are serviced by the specified T1 interface (for the **chg-t1** command), or by each defined T1 interface (for the **inh-card** command). Enter the **dact-slk** command.

Refer to the *Commands Manual* for more information.

2. Re-enter the command to change the specified T1 interface parameter value or inhibit the card.
-

E2737 Cmd Rej: The T1PORT at the specified location is not equipped

Commands Used: **chg-t1**, **dlt-t1**, **rtrv-t1**

You entered a command to change, delete, or retrieve information for, a T1 interface that has not been defined for the port that you specified in the **t1port** parameter, on the E1/T1 MIM card at the specified location.

Recovery

1. Display all T1 interface port and card location information. Enter the **rtrv-t1** command specifying no parameters.
2. Verify that you specified the correct port in the **t1port** parameter and the correct E1/T1 MIM card in the **loc** parameter for the T1 interface
 - If the specified port or card location was incorrect, re-enter the command specifying the correct port and card location.
 - If the specified port and card location were correct, re-enter the command.

Call your Customer Care Center if this error message appears again.

E2738 Cmd Rej: Cannot inhibit IMT bus - alternate bus is in abnormal state

Commands Used: **inh-imt**

The alternate IMT bus must be in-service normal (IS-NR) in order for the specified bus to be inhibited.

Recovery

Call your Customer Care Center if this error message appears again. This is a command that should only be entered when specifically directed to do so by your Customer Care Center.

E2739 Cmd Rej: T1 card location is unequipped

Commands Used: `chg-t1`, `dlt-t1`, `ent-t1`, `rtrv-t1`

You entered a command to add, delete, change, or retrieve information for a T1 interface on the E1/T1 MIM card specified in the `loc` parameter; and the card is not defined as type `limt1` in the database.

Recovery

1. Display the cards that are defined in the database. Enter the `rtrv-card` command. Verify that the card you specified in the `loc` parameter is the correct E1/T1 MIM card.
 2. If you specified the correct card in the `loc` parameter, re-enter the command.
 3. If the `loc` parameter value that you specified was incorrect for the card, re-enter the command specifying the correct `loc` parameter value.
 4. Call your Customer Care Center if this error message appears again.
-

E2740 Cmd Rej: The specified LOC only supports SLTC loopbacks

Commands Used: `tst-slk`

You entered a command for a loopback test that was not an SLTC loopback test. The E1/T1 MIM card supports only SLTC loopbacks.

Recovery

1. Re-enter the command specifying the SLTC loopback test type (`loopback=sltc`) for the E1/T1 card specified in the `loc` parameter.
 2. Call your Customer Care Center if this error message appears again.
-

E2742 Cmd Rej: T1 is assigned to card**Commands Used: dlt-card**

You cannot delete an E1/T1 MIM card used as a T1 card (card type **limt1**) that has at least one T1 interface associated with it. You must delete all T1 interfaces associated with the card before the card can be deleted.

Recovery

1. Display the list of signaling links assigned to the T1 card. Enter the **rtrv-slk** command.
 2. Deactivate all the signaling links assigned to the T1 card. Enter the **dact-slk** command for each link.
 3. Delete all signaling links assigned to the T1 card. Enter the **dlt-slk** command for each link.
 4. Display the T1 interfaces associated with the card. Enter the **rtrv-t1** command.
 5. Delete the T1 interfaces associated with the card. Enter the **dlt-t1** command. (Refer to the *Commands Manual*).
 6. Delete the card. Re-enter the **dlt-card** command.
-

E2743 Cmd Rej: Card type of LIMCH does not support T1PORT = 2**Commands Used: ent-slk**

You entered a command to assign a timeslot for a Channel card. You entered the **t1port=2** parameter for the T1 interface on port 2 of the E1/T1 MIM card used as the T1 card that will service the timeslot. Only T1 interfaces on T1 card port 1 can service timeslots for Channel cards.

Recovery

Re-enter the **ent-slk** command specifying **t1port=1** for the T1 card with the appropriate T1 interface to service the timeslot for the Channel card.

E2744 Cmd Rej: T1PORT specified by T1LOC is not equipped**Commands Used: ent-slk**

You entered a command to assign a signaling link to a T1 interface on an E1/T1 card used as a T1 card. The T1 interface has not been defined for the port specified in the **t1port** parameter on the T1 card specified in the **t1loc** parameter.

Recovery

1. Enter the **rtrv-t1** command to display the port and card location information for T1 interfaces already defined.
 2. Verify that the T1 interface is defined for the port on the T1 card to which you want to assign the signaling link.
 3. If the T1 interface is defined for the specified port on the T1 card at the specified location, re-enter the command specifying the correct T1 card location (**t1loc** parameter) and port (**t1port** parameter). Call your Customer Care Center if this error message appears again.
 4. If the T1 interface needs to be defined for the specified port on the T1 card at the specified location, perform the following actions:
 - Define the T1 interface attributes for the specified port on the T1 card in the location specified by the **t1loc** parameter. Enter the **ent-t1** command.
 - Re-enter the **ent-slk** command specifying the port for the defined T1 interface on the card specified in the **t1loc** parameter. (A signaling link for a Channel card can be assigned only to the T1 interface on T1 card port 1; a link for the T1 card itself can be assigned to the T1 interface on port 1 or port 2).
-

E2746 Cmd Rej: TS value on the T1 already in use by a signaling link

Commands Used: **ent-slk**

You entered a command to assign a timeslot and signaling link to a T1 interface on an E1/T1 MIM card used as a T1 card. The timeslot that you specified in the command **ts** parameter is already assigned to a signaling link serviced by the T1 interface on the T1 card specified in the **t1loc** and **t1port** parameters.

Recovery

1. Display the T1 interface port, card location, and timeslot information. Enter the **rtrv-t1** command.
 2. Re-enter the **ent-slk** command specifying an available timeslot for the T1 interface on the T1 card specified in the **t1port** and **t1loc** parameters.
-

E2747 Cmd Rej: FORCE=YES is required when card is allowed

Commands Used: **dlt-ip-rte**

You entered a command to delete a static IP route entry from the Static IP Route table, and the card that has the entry assigned is **allowed**.

Recovery

1. Inhibit the card. Enter the **inh-card** command.
2. Delete the static IP route entry for the card. Re-enter the **dlt-ip-rte** command.

OR

Re-enter the command to delete the entry and specifying the **force=yes** parameter to delete the entry while the card is allowed.

E2748 Cmd Rej: T1 TS value must be specified in the range (1-24)

Commands Used: ent-slk

You entered a command to assign a signaling link to a T1 interface on an E1/T1 MIM card that is used as a T1 card and specified a timeslot (**ts**) parameter value that is larger than **24** or less than **1** for the signaling link. The timeslot parameter value assigned to a signaling link for a T1 interface cannot be greater than **24** and cannot be **0**.

Recovery

Re-enter the **ent-slk** command to assign the signaling link and timeslot to the T1 interface on the T1 card, specifying a value greater than **0** and less than or equal to **24** for the **ts** parameter.

E2749 Cmd Rej: Could not block link for testing

Commands Used: act-cdl, act-lbp, tst-slk

The command you entered was unsuccessful. This error message may indicate a serious failure and require technical assistance.

Recovery

Wait for a brief period, and re-enter the same command.

Call your Customer Care Center if this error message appears again.

E2750 Cmd Rej: UserID already logged on (or is logging on) another terminal

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because your user ID is already logged in, or is being logged in, to the EAGLE 5 ISS at another terminal.

Recovery

1. Look at the scroll area of the terminal screen you are using for login. The following message is displayed:

Info: UID is currently logged on (or is logging on) to terminal yy

(where yy is in the range 1 - 16).

2. Find the terminal at yy and log off your user ID at that work station.
 3. Return to your work station and resume login procedures.
-

E2751 Cmd Rej: UserID has been revoked

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because the systems administrator has revoked your user ID.

Recovery

1. Contact your systems administrator to determine why your user ID has been revoked.
 2. If the systems administrator agrees to reinstate your user ID, re-enter the `login` command.
-

E2752 Cmd Rej: UserID has become obsolete and cannot be used

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because the number of days that have elapsed since you last successfully logged on to the EAGLE 5 ISS with this user ID exceeds the number established for your site.

Recovery

1. Contact your systems administrator to have the last successful login date associated with your user ID reset to today's date.
 2. Re-enter the `login` command.
-

E2753 Cmd Rej: Password does not contain enough alphabetic characters

If you are the systems administrator:

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

The requirements for the password are given in the scroll area of the logon screen. If you fail to adhere to these requirements, this error message will appear after you entered the command and received the password prompt, but entered a password that did not contain the required minimum number of alphabetic characters.

Recovery

1. Review the site password complexity requirements.
 2. Display the system wide, security-related defaults. Enter the `rtrv-secu-dflt` command. The minimum number of alphabetic characters allowed is displayed in the ALPHA field.
 3. Re-enter the command, and at the password prompt, type a new password containing the correct minimum number of alphabetic characters and that meets the other password complexity requirements for your site.
-

If you are not the systems administrator:

Commands Used: `act-user`, `chg-pid`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of alphabetic characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site's password complexity requirements.
 2. Re-enter the command, and at the password prompt, type a new password that meets all the password complexity requirements for your site.
-

E2754 Cmd Rej: Password does not contain enough numeric characters

If you are the systems administrator:

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of numeric characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site password complexity requirements.
 2. Display the system wide, security-related defaults. Enter the `rtrv-secu-dflt` command. The minimum number of numeric characters allowed is displayed in the NUM field.
 3. Re-enter the command, and at the password prompt, type a new password containing the correct minimum number of numeric characters and that meets the other password complexity requirements for your site.
-

If you are not the systems administrator:

Commands Used: `act-user`, `chg-pid`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of numeric characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site's password complexity requirements.
 2. Re-enter the command, and at the password prompt, type a new password that meets all the password complexity requirements for your site.
-

E2755 Cmd Rej: Password does not contain enough punctuation characters

If you are the system administrator:

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of punctuation characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site password complexity requirements.
 2. Display the system wide, security-related defaults. Enter the `rtrv-secu-dflt` command. The minimum number of punctuation characters allowed is displayed in the PUNC field.
 3. Re-enter the command, and at the password prompt, type a new password containing the correct minimum number of punctuation characters and that meets the other password complexity requirements for your site.
-

If you are not the system administrator:

Commands Used: `act-user`, `chg-pid`, `login`

After you entered the command and received the password prompt, you entered a password that does not contain the required minimum number of punctuation characters.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site's password complexity requirements.
 2. Re-enter the command, and at the password prompt, type a new password that meets all the password complexity requirements for your site.
-

E2756 Cmd Rej: Failed reading the password table

Commands Used: `chg-pid`, `chg-user`, `ent-user`, `login`

The EAGLE 5 ISS was unable to access the Password table.

Recovery

This error message indicates a potentially serious error accessing the disk. call your Customer Care Center.

E2757 Cmd Rej: Invalid userID/password combination

Commands Used: `act-user`, `login`

Your attempt to login to the EAGLE 5 ISS has been denied because of one of the following: you either entered a user ID or a password not in the EAGLE 5 ISS database, or you entered a user ID-password combination not in the database. In other words, even though both the user ID and password may be in the database, to pass login verification they must be authorized for use together.

Recovery

1. Contact your systems administrator to verify your correct user ID-password combination.
 2. Re-enter the `login` command specifying the user ID and password combination that the systems administrator has assigned to you.
-

E2758 Cmd Rej: ALPHA+NUM+PUNC must not be greater than 12

Commands Used: `act-user`, `chg-pid`, `chg-user`, `ent-user`, `login`

After you entered the command and received the password prompt, you entered a password whose total of alphabetic, numeric, and punctuation characters exceeds the system allowed maximum of **12**.

NOTE: Commands `ent-user` and `chg-user` are only available to the system administrator.

Recovery

1. Read the requirements for the password in the scroll area of the logon screen. Make sure that you understand all of your site password complexity requirements.
 2. Re-enter the command, and at the password prompt, type a new password whose total of alphabetic, numeric, and punctuation characters does not exceed the system allowed maximum of **12**.
-

E2759 Cmd Rej: Revocation of security admin userID not allowed

Commands Used: `chg-user`, `ent-user`

The user ID you have attempted to revoke is authorized for the *security administration* category (for example, systems administrator), and the EAGLE 5 ISS does not allow revocation of a user ID in that category. This safeguard ensures that at least one person always has access to the EAGLE 5 ISS.

Recovery

Perform one of the following:

- Re-enter the command specifying another user ID.
- OR
- Re-enter the command specifying the `revoke=no` parameter.
-

E2760 Cmd Rej: Failed reading the security defaults table

Commands Used: `chg-pid`, `chg-secu-dflt`, `chg-user`, `ent-user`, `login`, `rtrv-secu-dflt`

The EAGLE 5 ISS cannot access the Security Defaults table.

Recovery

This error message indicates a potentially serious error accessing the disk. Call your Customer Care Center.

E2761 Cmd Rej: Password cannot contain userID

Commands Used: `chg-pid`, `chg-user`, `ent-user`, `login`

You specified a password that contains the user ID that must be used in conjunction with the password. The password cannot contain the string of characters that makes up the user ID to be used in conjunction with it.

Recovery

Re-enter the command specifying a different password.

E2762 Cmd Rej: Terminal temporarily disabled. Excessive LOGIN failures

Commands Used: `act-user`, `login`

You tried to login to the EAGLE 5 ISS at a terminal that is disabled because the login failure threshold level was exceeded. For security reasons, the site administrator has configured the EAGLE 5 ISS to disable terminals for a specified amount of time, when login failures exceeds a specified number.

Recovery

1. Contact the system administrator and request that the port be reset.
 2. When the port has been reset, re-enter the `login` command.
-

E2764 Cmd Rej: Both OAM cards must be of type GPSM-II to enable TSCSYNC

Commands Used: `chg-feat`

You entered a command to turn on the Time Slot Counter synchronization (TSC) feature. The feature requires that both OAM cards must be card type GPSM-II.

Recovery

1. Verify the card type of each OAM card. Enter the `rtrv-card` command.

2. If the OAM cards are both type GPSM-II, re-enter the command.
 3. If one or both OAM cards are not type GPSM-II, you must replace one or both OAM cards with GPSM-II cards before you can turn on the TSC feature.
 4. Call your Customer Care Center if this error message appears again.
-

E2765 Cmd Rej: Invalid password. Keyboard is locked. Enter UNLOCK command

Commands Used: `lock`, `unlock`

Your keyboard is locked and when you attempt to unlock it using the `unlock` command, you enter the wrong password. You must enter the password of the logged in user to unlock the keyboard.

Recovery

1. Re-enter the `unlock` command.
2. The following message will appear:

Enter LOGIN Password to unlock keyboard:

Enter the correct password.

If you enter an incorrect password again, the following message appears:

E2765 Cmd Rej: Invalid password. Keyboard is locked.

3. Enter the `unlock` command and return to step 1.
4. If you continue to enter the wrong password until the number of `unlock` commands entered at your keyboard exceeds the site specified maximum, the following message appears:

E2770 Cmd Rej: Terminal temporarily disabled due to excessive UNLOCK failures

The keyboard remains locked. See the system administrator to have the port reset.

5. If you enter the correct password, the following message appears in the scroll area:

Info: Keyboard unlocked. xxxxx UNLOCK commands were attempted.

The keyboard is unlocked and xxxxx indicates the number of `unlock` commands entered at your keyboard while it was locked.

E2766 Cmd Rej: Command cannot be executed on an OAP terminal**Commands Used: lock**

You cannot lock an OAP or SEAS terminal. The specified terminal cannot be an OAP or SEAS terminal.

Recovery

Enter another command.

E2767 Cmd Rej: Keyboard is not locked**Commands Used: unlock**

You entered the **unlock** command at a terminal the keyboard is not locked, or you entered the **unlock** command at an OAP terminal. OAP terminals cannot be locked. The **unlock** command is valid only if the keyboard is locked.

Recovery

Enter another command.

E2768 Cmd Rej: DURAL must be specified within 0..995959 or 999999**Commands Used: chg-trm**

You specified an unacceptable **dural** parameter value. The value for dural must be specified as either **all** digits or **999999**.

Recovery

Perform one of the following:

- Re-enter the **chg-trm** command specifying digits in the range of **0-59** for seconds, **0-59** for minutes, or **0-99** for hours.

OR

- Re-enter the **chg-trm** command specifying the value of **999999**.
-

E2769 Cmd Rej: Entry already exists for this application at this IP Address

Commands Used: `ent-ftp-serv`

You entered a command for an FTP server with an application/IP address combination that already exists in the FTP Server table.

Recovery

1. Enter the `rtrv-ftp-serv` command to display the information for the FTP servers that are defined in the FTP Server table.
 2. Re-enter the `ent-ftp-serv` command for the FTP server with an application/IP address combination that does not appear in the output from step 1.
-

E2770 Cmd Rej: Terminal temporarily disabled. Excessive UNLOCK failures

Commands Used: `unlock`

Your terminal keyboard is locked and temporarily disabled because the number of failed unlock attempts exceeds the site-specified maximum. The port must not be in an unlock disabled state because of excessive successive unlock failures.

Recovery

1. Contact your system administrator to get the terminal reset.

NOTE: Locked terminals can also be unlocked by issuing the `inh-trm` command, followed by the `alw-trm` command.

2. Re-enter the `unlock` command.
-

E2771 Cmd Rej: Both WRNLN and WRNTX must be specified

Commands Used: `chg-secu-dflt`

When you enter the `chg-secu-dflt` command, you must specify both the warning message line number (`wrnln`) and the warning message text (`wrntx`) parameters.

Recovery

1. Re-enter the **chg-secu-dflt** command specifying both the **wrnln** and the **wrntx** values.
 2. Call your Customer Care Center if this error message appears again.
-

E2772 Cmd Rej: Entry already exists for this application at this priority**Commands Used: chg-ftp-serv, ent-ftp-serv**

You entered a command to enter or change an FTP server application and priority parameter combination, and the specified application with the specified priority already exists in the FTP Server table.

Recovery

1. Enter the **rtrv-ftp-serv** command to display the information for the FTP servers that are defined in the FTP Server table.
 2. Re-enter the command for the FTP server, with an application and priority combination that does not appear in the output from step 1.
-

E2773 Cmd Rej: FTP Server table must be accessible**Commands Used: act-ftp-trns, chg-ftp-serv, dlt-ftp-serv, ent-ftp-serv, rtrv-ftp-serv**

The FTP Server table was not accessible to the command you entered.

Recovery

Re-enter the command that generated this error message specifying correct parameter values.

Call your Customer Care Center if this error message appears again.

E2774 Cmd Rej: FTP Server table entry not found for this APP/IPADDR**Commands Used: chg-ftp-serv, dlt-ftp-serv**

You entered a command to change or delete the entry for an FTP server in the FTP Server table, and the entry to be changed or deleted does not exist in the table.

Recovery

1. Enter the **rtrv-ftp-serv** command to display the current entries in the FTP Server table. Verify the information for the FTP server entry that you want to change or delete.
 2. Re-enter the command that generated this error message specifying correct parameter values.
 3. Call your Customer Care Center if this error message appears again.
-

E2775 Cmd Rej: Cannot change terminal authority while user is logged on

Commands Used: **chg-secu-trm**

You tried to change the terminal access rights for a terminal while a user is logged on to that terminal. The EAGLE 5 ISS does not allow this action.

Recovery

Re-enter the command when that user ID is logged off.

E2776 Cmd Rej: At least two ports must have security admin authority

Commands Used: **chg-secu-trm**

You entered the command for a security administration terminal, and tried to change the access rights in such a way that only one terminal would remain configured for security administration. The EAGLE 5 ISS requires that at least two terminals be configured as security administration terminals in case one of them has a hardware failure.

Recovery

1. Enter the **rtrv-secu-trm** command to display the access rights for the terminal in question.
2. Perform one of the following:
 - Re-enter the command specifying either the **all=yes** or the **sa=yes** parameter.
 - OR
 - Re-enter the command specifying a different port (**port**) parameter for making the original change in security access rights. This action ensures

that the two ports originally configured for security administration remain that way.

E2777 Cmd Rej: Cannot change TYPE as system requires 2 SA enabled terminals

Commands Used: chg-trm

You entered the command for a security administration terminal, and tried to change the **type** parameter to a non-terminal value of **printer** or **none**. The EAGLE 5 ISS requires that at least two terminals be configured as security administration terminals in case one of them has a hardware failure.

Recovery

1. Enter the **rtrv-secu-trm** command to display the access rights for the terminal in question.
 2. Perform one of the following:
 - Re-enter the **chg-trm** command specifying a value other than **printer** or **none** for the **type** parameter, orOR
 - Re-enter the **chg-trm** command for a different terminal by specifying a different value for the **terminal** parameter; subsequently configuring another terminal to the non-terminal value of **printer** or **none**.
-

E2778 Cmd Rej: Max number of entries exist in FTP Server table

Commands Used: ent-ftp-serv

The maximum number of FTP servers that can be entered in the FTP Server table is **10**. You entered a command that would have created the 11th entry in the table. You must delete an existing FTP server before you can add a new one.

Recovery

1. Enter the **rtrv-ftp-serv** command to display the FTP servers currently in the FTP Server table.
 2. Delete one of the existing FTP servers. Enter the **dlt-ftp-serv** command specifying the appropriate parameters.
 3. Re-enter the **ent-ftp-serv** command to add the new FTP server into the FTP Server table.
-

E2779 Cmd Rej: Max number of FTPSERV table entries exist for this APP**Commands Used: ent-ftp-serv**

You entered a command to enter an FTP sever into the FTP Server table for an application. The maximum number of FTP servers already exist that can be entered for that application. You must delete an existing FTP server for that application before you can add a new one.

Recovery

1. Display the FTP servers currently entered in the FTP Server table. Enter the **rtrv-ftp-serv** command.
 2. Delete an existing FTP server for the application. Enter the **dlt-ftp-serv** command specifying the appropriate parameters.
 3. Re-enter the **ent-ftp-serv** command to add the new FTP server to the FTP Server table.
-

E2780 Cmd Rej: DFLTACT must be specified as FORWARD, DUPLICATE, or DUPDISC**Commands Used: ent-gsms-opcode**

You entered a command to provision a GSM Map opcode and its default action. This command lets you provision the opcodes for which the EAGLE 5 ISS attempts to perform GSM screening. You can specify the point code and subsystem number parameters only if you also specify **dftact=forward**, **dftact=duplicate**, or **dftact=dupdisc**. These parameters define the node to which the input messages are routed.

Recovery

Re-enter the **ent-gsms-opcode** command containing the parameter **dftact=forward**, **dftact=duplicate**, or **dftact=dupdisc**, specifying the **pc/pca/pci/pcn/pcn24** parameters and/or subsystem number point code (**ssn**) parameter.

Refer to the Commands Manual for detailed information about the use of this command.

E2781 Cmd Rej: NDFLTACT parameter must be FORWARD, DUPLICATE, or DUPDISC**Commands Used: chg-gsms-opcode**

You entered a command to specify new attributes for a defined GSM Map opcode. You can modify the default action screening and the user-defined name of an existing opcode. If you specify the new point code and/or new subsystem number parameters, you must also specify the new default action screening parameters as **ndfltact=forward**, **ndfltact=duplicate**, or **ndfltact=dupdisc**.

Recovery

Re-enter the **chg-gsms-opcode** command specifying one of the required default action screening parameters.

E2782 Cmd Rej: When REXMIT=BSD is specified, an RTT cannot be assigned**Commands Used: chg-app1-sock**

You entered a command to change the **rtt** parameter value, and either you specified the **rexmit=bsd** parameter value or the **rexmit** parameter value is already set to the default of **bsd**. When the parameter value **rexmit=bsd** is set or specified, you cannot specify an **rtt** parameter value in the command.

Recovery

1. Display the current setting of the **rexmit** parameter. Enter the **rtrv-app1-sock** command.
2. If in the output from step 1, the **rexmit** value is **bsd**, you cannot specify an **rtt** parameter value in the command.

Perform one of the following:

- Re-enter the **chg-app1-sock** command specifying an **rtt** parameter value, and a **rexmit** parameter value of **fixed** or **mod** if it is appropriate in your system.

OR

- Re-enter the **chg-app1-sock** command without specifying the **rtt** parameter.
-

E2783 Cmd Rej: When REXMIT=FIXED or MOD is specified, an RTT must be assigned

Commands Used: `chg-appl-sock`

You entered a command that specified a **rexmit** parameter value of either **fixed** or **mod**, and you did not specify an **rtt** parameter value in the command. When the parameter value **rexmit=fixed** or **rexmit=mod** is specified, you must specify an **rtt** parameter value in the command.

Recovery

Re-enter the `chg-appl-sock` command specifying a **rexmit** parameter value of **fixed** or **mod** and an **rtt** parameter value.

E2784 Cmd Rej: Current ITU-N site id must be disabled for this assignment

Commands Used: `chg-sid`

You entered the command to define a 24-bit ITU-N site ID point code. The EAGLE 5 ISS site ID is currently a 14-bit ITU-N point code. You must use the `chg-sid` command to delete the existing 14-bit ITU-N site ID before you can enter a 24-bit ITU-N point code site ID.

Recovery

1. Display the current STP site ID. Enter the `rtrv-sid` command.
Refer to the *Database Administration - SS7 Manual* and the `chg-sid` command in the *Commands Manual* for the procedure for replacing an existing site ID with a 24-bit ITU-N site ID.
 2. Enter the `chg-sid:pcn=none` command.
 3. Enter the `chg-sid` command specifying the 24-bit site ID as the **pcn24** parameter value.
-

E2785 Cmd Rej: ITU-N 24bit site id not defined

Commands Used: `chg-dstn`, `ent-dstn`

You entered the command to define a 24-bit ITU-N point code destination. The EAGLE 5 ISS site ID is not a 24-bit ITU-N point code. Use the `chg-sid` command to replace the existing site ID with a 24-bit ITU-N point code site ID before you can enter the 24-bit ITU-N point code destination.

Recovery

Display the current STP site ID. Enter the **rtrv-sid** command.

Refer to the *Database Administration - SS7 Manual* and the **chg-sid** command in the *Commands Manual* for the procedure for replacing the existing ITU-N site ID with a 24-bit ITU-N site ID.

When the existing site ID has been replaced, re-enter the command to define a 24-bit ITU-N point code destination.

E2787 Cmd Rej: PC network type does not match existing PC network type

Commands Used: **chg-mrn**, **ent-mrn**, **chg-sccp-serv**

You specified a point code that has a parameter value format for a network of a different type than the existing point codes in the network.

Recovery

Re-enter the command specifying a format for the point code parameter value that is correct for the existing network type. Refer to the *Commands Manual* for valid point code formats.

E2788 Cmd Rej: Invalid Loopback selection for LIME1ATM

Commands Used: **tst-slk**

The E1 ATM card does not support **payload** loopback or **line** loopback tests.

Recovery

Perform one of the following actions:

- Re-enter the **tst-slk** command specifying a valid **loopback** parameter value for the E1 ATM card.

OR

- Enter the **tst-slk** command for the **payload** or **line** loopback test for a card that is not an E1 ATM card.
-

E2789 Cmd Rej: NNP,NNAI,NPDD/S,NSDD/S,NGTI,RMGTT invalid if MGTT is OFF

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

You specified one or more of the parameters `nnp`, `nnai`, `npdd`, `npds`, `nsdd`, `nsds`, `ngti`, and `rmgtt`. These parameters are not valid in the command if the MGTT feature is off in your system.

Recovery

1. Verify that the MGTT feature is turned on in your system. Enter the `rtrv-feat` command.
 2. If the MGTT feature is on, re-enter the command that generated this error message.
 3. If the MGTT feature is off and you want to use the `rmgtt`, `nnp`, `nnai`, `npdd`, `nsdd`, `nsds`, `ngti`, or `npds` parameter in a command, you must turn the MGTT feature on in the system. Enter the `chg-feat:mgtt=on` command.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2790 Cmd Rej: Table is full, no more entries allowed

Commands Used: `ent-pstn-pres`

The PSTN/ISUP Variant table is full.

Recovery `ent-pstn-pres`

1. View the entries in the PSTN table. Enter the `rtrv-pstn-pres` command.
 2. To add an entry to the PSTN table, you must either change or delete an existing entry.
 - To change an existing entry in the PSTN table, enter the `chg-pstn-pres` command.
OR
 - To delete an existing entry in the PSTN table, enter the `dlt-pstn-pres` command.
 3. Re-enter the `ent-pstn-pres` command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2791 Cmd Rej: Quantity control feature capacity exceeded

Commands Used: `ent-pstn-pres`

You attempted to enter more PSTNs than were purchased or configured. Enter the `rtrv-ctrl-feat` command to see provisioned features.

Recovery

Either delete a PSTN entry before another can be entered, or purchase additional quantity and configure with `enable-ctrl-feat`.

Call your Customer Care Center if this error message appears again.

E2792 Cmd Rej: PSTN is not defined

Commands Used: `chg-isupvar-attrib`, `copy-isupvar-attrib`,
`dlt-pstn-pres`, `rtrv-isupvar-attrib`

The specified `pstnid` is not in the PSTN table.

Recovery

1. View the PSTN IDs currently configured in the PSTN table. Enter the `rtrv-pstn-pres` command.
 2. Re-enter command specifying correct value for `pstnid`.
-

E2793 Cmd Rej: Only parmCODE=0 (EOP) can have MINLEN=0

Commands Used: `chg-isupvar-attrib`, `chg-pstn-pres`

You entered a non-zero `parmcode` with `minlen=0`.

Recovery

Re-enter with non-zero `minlen` or use a different `parmCODE`.

Call your Customer Care Center if this error message appears again.

E2794 Cmd Rej: MSGCODE and parmCODE must both be DEFINED

Commands Used: `chg-isupvar-attrib`

You entered a command that resulted in either the **msgcode** or the **parmcode** having **attrib=defined** and, the other **parmcode** or **msgcode** with an **attrib** value other than **defined**. Both the **msgcode** and the **parmcode** must have **attrib=defined**.

Recovery

Re-enter the `chg-isupvar-attrib` command so that **msgcode** and **parmcode** will both have **attrib=defined**.

Refer to the *Commands Manual* for information about using the parameters.

E2795 Cmd Rej: MF or MV parms must be kept in an ordered list starting at 1

Commands Used: `chg-isupvar-attrib`

A parameter cannot be changed to **notsupp** if it is a mandatory fixed (**mf**) or a mandatory variable (**mv**) parameter. Removing it will cause the list of parameters to be non-sequential.

Recovery

Parameters must be deleted from the end of the list and entered at the end of the list only. In other words, if you have parameters (**0, 1, 2, 3, 4**) and you want to delete parameter **2**, you must first delete parameter **4** and then parameter **3**.

E2796 Cmd Rej: Max number of DEFINED MSGCODEs per variant is exceeded

Commands Used: `chg-isupvar-attrib`

You entered a command that caused the maximum number of **msgcode** entries per variant with **attrib=defined** to be exceeded.

Recovery

Enter a command that will not exceed the maximum.

Refer to the *Commands Manual* and the *Database Administration Manual - IP7 Secure Gateway* for information on entering **msgcode** entries.

E2797 Cmd Rej: Max number of DEFINED parmCODEs per variant is exceeded

Commands Used: `chg-isupvar-attrib`

You entered a command that caused the maximum number of **parmcode** entries per variant with **attrib=defined** to be exceeded.

Recovery

Enter a command that will not exceed the maximum.

Refer to the *Commands Manual* and the *Database Administration Manual - IP7 Secure Gateway* for information on entering **parmcode** entries.

E2798 Cmd Rej:parmCODE is supported in a message, cannot be NOTDEFINED

Commands Used: `chg-isupvar-attrib`

You entered a command to change a **parmcode** to **attrib=notdefined**, and the **parmcode** is still supported in a message. This is not allowed.

Recovery

1. Enter a command to change the **parmcode** to **attrib=notsupp**.
 2. Re-enter the `chg-isupvar-attrib` command to change the **parmcode** to **attrib=notdefined**.
-

E2810 Cmd Rej: Two OAP terminals are already configured

Commands Used: `chg-trm`

The EAGLE 5 ISS you are configuring has two terminals configured for OAP using the **type=oap** parameter, and you attempted to configure a third OAP terminal. You can configure only two OAP terminals on an EAGLE 5 ISS.

Recovery

1. Display the values of all terminals using the `rtrv-trm` command. In the output, under the TYPE column, OAP is displayed for each terminal configured for OAP.
2. If you must change either one (or both) of the terminals currently configured for OAP, inhibit the terminal you want to change using the `rmv-trm` command specifying the terminal that you want to inhibit. For example, you might specify `rmv-trm:trm=4` to inhibit the terminal at trm 4.

3. Enter the **rept-stat-trm** command to verify that the terminal you are inhibiting is out of service (OOS-MT-DSBLD).
 4. Change the terminal characteristics for the terminal you are reconfiguring using the **chg-trm** command. For example, you might specify **chg-trm:trm=4:type=oap:all=yes**.
 5. Verify the changes made. Enter the **rtrv-trm** command specifying the trm number of the terminal you reconfigured. For example, you might specify **rtrv-trm:trm=4**.
 6. When you have completed the changes to your configuration, activate the terminal that you inhibited in step 2. Enter the **rst-trm** command.
-

E2811 Cmd Rej: Comm. attributes cannot be entered for OAP terminal

Commands Used: **chg-trm**

You entered the command for an OAP terminal (**type=oap**) parameter and specified one or more of the communications attributes parameters: **baud**, **prty**, **sb**, and **fc**. For OAP ports, these parameters must be allowed to default to **baud=19200**, **prty=even**, **sb=1**, and **fc=sw**.

Recovery

Perform one of the following:

- Re-enter the **chg-trm** command but specify none of the communications attributes. For example, you might specify **chg-trm:trm=4:type=oap:all=yes**.
- OR
- Re-enter the **chg-trm** command as you originally entered it, but with a value other than **oap** for the **type** parameter.
-

E2812 Cmd Rej: SEAS feature or LNP feature is not configured

Commands Used: **chg-oap-config**, **chg-trm**

You entered the command without specifying the required SEAS feature or LNP feature turned on. The following Recovery procedures list by command the remedial action to take if you encounter this error message.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery - chg-oap-config

1. Verify that the SEAS feature is turned on. Enter the **rtrv-feat** command. Verify that the LNP feature is turned on. Enter the **rtrv-ctrl-feat** command.

Refer to the *Commands Manual* for valid SEAS and LNP OAP parameter combinations.

2. To turn on either:
 - The SEAS feature. Enter the **chg-feat:seas=on**, or
 - The LNP feature. Enter the **enable-ctrl-feat** command.

Refer to the “Activating the LNP Feature” procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting this procedure.

3. Re-enter the **chg-oap-config** command that generated this error message. Call your Customer Care Center if this error message appears again.
-

Recovery - chg-trm

1. Verify the SEAS feature is turned on. Enter the **rtrv-feat** command. Verify the LNP feature is turned on. Enter the **rtrv-ctrl-feat** command. Both features must be on.

2. To turn on:
 - The SEAS feature, enter the **chg-feat:seas=on** command.
 - The LNP feature, enter the **enable-ctrl-feat** command.

Refer to the “Activating the LNP Feature” procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting this procedure.

3. Re-enter the **chg-trm** command. Call your Customer Care Center if this error message appears again.
-

E2813 Cmd Rej: FORCE=YES must be specified to initialize the last OAP**Commands Used: init-oap**

You must specify the **force=yes** parameter to reset the last OSS/Application Processor (OAP).

Recovery

Re-enter the **init-oap** command that generated this error message specifying the **force=yes** parameter.

Call your Customer Care Center if this error message appears again.

E2815 Cmd Rej: PC and RC must be entered as a pair

Commands Used: **chg-mrn, ent-mrn, chg-sccp-serv**

You entered a command that specified a point code, but did not specify a relative cost for the point code. Both the point code parameter and relative code parameter must be specified together in the command.

Recovery

Re-enter the command that generated this error message specifying parameter values for both the point code and its relative cost.

E2816 Cmd Rej: PC already exists in the MRN entity set

Commands Used: **chg-mrn, ent-mrn**

The specified point code already exists in the MRN table.

Recovery

1. Display the MRN table. Enter the **rtv-mrn** command.
 2. Re-enter the command that generated this error message specifying a point code parameter that does not appear in the output from step 1.
-

E2817 Cmd Rej: MRN table is full

Commands Used: **chg-mrn, ent-mrn**

You entered a command to add a point code to the Mated Relay Node (MRN) table, and the MRN table already contains the maximum number of point code entries allowed in the MRN table.

Recovery

1. Display the MRN table. Enter the **rtrv-mrn** command.
 2. Delete an existing point code from the MRN table. Enter the **dlt-mrn** command.
 3. Re-enter the command to add a point code to the MRN table.
-

E2818 Cmd Rej: A maximum of 8 PCs are allowed in a group

Commands Used: **ent-mrn**, **chg-mrn**

You entered a command to add one or more point codes to a group in the Mated Relay Node (MRN) table, and the point code group already contains 8 point codes.

Recovery

1. Display the MRN table. Enter the **rtrv-mrn** command.
 2. Delete one or more existing point codes from the group. Enter the **dlt-mrn** command.
 3. Re-enter the command to add one or more point codes to the group in the MRN table.
-

E2819 Cmd Rej: Destination disk is unformatted

Commands Used: **copy-disk**, **copy-gpl**

You entered the command, but the destination disk has not been formatted.

Recovery

1. Enter the **copy-disk** command specifying the **format=yes** parameter to format the destination disk.
 2. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2820 Cmd Rej: Source location must specify the active fixed disk

Commands Used: **copy-fta**

You assigned the wrong value to the **sloc** parameter.

Recovery

1. View the active fixed disk. Enter the **rept-stat-db** command.
 2. Re-enter the **copy-fta** command specifying the correct **sloc** parameter value.
Call your Customer Care Center if this error message appears again.
-

E2821 Cmd Rej: Could not access removable disk

Commands Used: **act-upgrade**, **copy-disk**

During an upgrade procedure or a **copy-disk** command action, there was an unsuccessful attempt to read a removable disk. A formatted removable cartridge containing the next release is required for the upgrade. Alternatively, you may have a hardware problem with the cartridge or the removable disk.

Recovery

1. Verify the removable cartridge contains the next release.
2. Verify that the removable cartridge is inserted in the MDAL.
3. Verify that the MDAL is seated properly.
4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure is completed.

E2822 Cmd Rej: Destination location must specify the standby fixed disk

Commands Used: **copy-fta**

You specified the wrong value for the **dloc** parameter.

Recovery

1. Show the standby fixed disk. Enter the **rept-stat-db** command.
2. Re-enter the **copy-fta** command specifying the correct **dloc** parameter value.

Call your Customer Care Center if this error message appears again.

E2823 Cmd Rej: Destination location must specify the standby removable disk

Commands Used: `copy-fta`

You specified the wrong value to the **dloc** parameter.

Recovery

Re-enter the `copy-fta` command specifying the correct **dloc** parameter value.

Call your Customer Care Center if this error message appears again.

E2824 Cmd Rej: Could not access standby fixed disk

Commands Used: `copy-fta`, `copy-gpl`, `format-disk`

You may have a hardware problem.

Recovery

1. Verify the status of the standby TDM. Enter the `rept-stat-db` command.
2. If the status of the standby TDM shows **noaccs**, call your Customer Care Center.
3. If the status of the standby TDM shows **stdby**, re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2825 Cmd Rej: Could not access removable disk

Commands Used: `copy-fta`

You may have a hardware problem. The removable drive is not available.

Recovery

Re-enter the `copy-fta` command.

Call your Customer Care Center if this error message appears again.

E2826 Cmd Rej: Could not access active fixed disk

Commands Used: `copy-fta`, `copy-gpl`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2828 Cmd Rej: Source and destination disks not compatible

Commands Used: `copy-fta`, `format-disk`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2829 Cmd Rej: Destination disk capacity equals 0

Commands Used: `copy-disk`, `copy-gpl`, `format-disk`

The system cannot determine the capacity of the disk being formatted.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2830 Cmd Rej: Source drive not coherent

Commands Used: `copy-disk`, `copy-gpl`, `format-disk`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2831 Cmd Rej: Current database not coherent

Commands Used: `chg-db`, `format-disk`

Resolving this issue is beyond the scope of this manual.

Recovery

Refer to the *Database Administration Manual - System Management* for detailed instructions.

Call your Customer Care Center if this error message appears again.

E2832 Cmd Rej: MTPRSI is only valid if MTPRS or ITUMTPRS feature is ON

Commands Used: `chg-stpopts`

You specified the `mtparsi` parameter, but the ANSI MTP restart (MTPRS) or the ITU MTP restart (ITUMTPRS) feature is off. One or both of these features must be turned on before you can issue the `mtparsi` parameter.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Verify that the MTPRS or the ITUMTPRS features are off (`mtpars=off` or `itumtpars=off`). Enter the `rtrv-feat` command.
2. Perform one or both of the following:
 - Turn on the MTPRS feature. Enter the `chg-feat:mtpars=on` command.
 - OR
 - Turn on the ITUMTPRS feature. Enter the `chg-feat:itumtpars=on` command.
3. Re-enter the `chg-stpopts` command.

OR

4. Re-enter the **chg-stpopts** command without specifying the **mtprs** parameter.
-

E2833 Cmd Rej: MTPRSIT parameter is only valid if MTPRS feature is ON

Commands Used: **chg-stpopts**

You specified the **mtprsit** parameter, but the MTP Restart (MTPRS) feature is off.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Verify that the MTPRS feature is turned on. Enter the **rtrv-feat** command. If the MTPRS feature is off, you must turn it on.
2. Turn the MTPRS feature on. Enter the **chg-feat:mtprs=on** command.
3. Re-enter the **chg-stpopts** command.

OR

4. Re-enter the **chg-stpopts** command without specifying the **mtprsit** parameter.
-

E2834 Cmd Rej: MTPRSE parameter is only valid if MTPRS feature is ON

Commands Used: **chg-ls**, **chg-stpopts**, **ent-ls**

You specified the **mtpmse** parameter, but the ANSI MTP Restart (MTPRS) feature is off.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Verify that the MTPRS feature is turned on. Enter the **rtrv-feat** command. If the MTPRS feature is off, you must turn it on.
2. Turn on the MTPRS feature. Enter the **chg-feat:mtpms=on** command.
3. Re-enter the command that generated this error message.

OR

Re-enter the command that generated this error without specifying the **mtprse** parameter.

E2836 Cmd Rej: Too many nested cluster dstn entered

Commands Used: `ent-dstn`

You specified the **ncai** parameter, but you have already provisioned **500** nested clusters. The maximum number allowed is **500**.

Recovery

1. Display a list of provisioned nested clusters. Enter the `rtrv-dstn:ncai=yes` command.
2. Display the provisioned nested clusters routing information. Enter the `rtrv-rte` command. Here is an example of system output:

DPCN	ALIASA	ALIASI	CLLI	LSN	RC	APC
40-1-*	-----	-----	-----	1s8	10	45-1-0
40-1-*	-----	-----	-----	1s7	10	45-2-0
40-1-30	-----	-----	-----	1s3	10	45-1-30
40-1-10	-----	-----	-----	1s8	10	45-1-0
40-1-10	-----	-----	-----	1s7	10	45-2-0

The nested member (in this example, **dpc=40-1-30**) has a different routeset than its cluster (**dpc=40-1-***).

3. Delete a cluster member route. Enter the `dlt-rte` command specifying the DPC of a cluster member whose route you want to delete. The deletion results in the provisioned member assuming the attributes of its cluster.
 4. Change a nested cluster point code to a non-nested cluster point code. Enter the `chg-dstn` command specifying the **ncai=no** parameter.
 5. Re-enter the command that generated this error message.
-

E2837 Cmd Rej: NCR must be enabled to enter NCAI param

Commands Used: `chg-dstn`, `ent-dstn`

You specified the **ncai** parameter, but the Nested Cluster Routing (NCR) feature is turned off, as required.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the NCR feature is turned off, as seen in the output of step 1 (NCR=off), turn it on. Enter the **chg-feat:ncr=on** command.
Re-enter the command that generated this error message.
 3. If the NCR feature is turned on, as seen in the output of step 1 (NCR=on), re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E2838 Cmd Rej: Unable to change Network/Cluster dstn NCAI param

Commands Used: **chg-dstn**

You specified the **ncai=no** parameter to change a provisioned nested cluster point code to a non-nested cluster point code. The EAGLE 5 ISS does not allow this action since the previously provisioned members of the cluster have a different route set.

Recovery

1. Enter the **rtrv-rte** command to view routing information for the cluster.
Here is an example of system output:

DPCN	ALIASA	ALIASI	CLLI	LSN	RC	APC
40-1-*	-----	-----	-----	1s8	10	45-1-0
40-1-*	-----	-----	-----	1s7	10	45-2-0
40-1-30	-----	-----	-----	1s3	10	45-1-30
40-1-10	-----	-----	-----	1s8	10	45-1-0
40-1-10	-----	-----	-----	1s7	10	45-2-0

The nested member (in this example, **dpc=40-1-30**) has a different routeset than its cluster (**dpc=40-1-***).

2. Enter the **dlr-rte** command specifying the DPC of a cluster member whose route you want to delete. The deletion results in the provisioned member assuming the attributes of its cluster.
 3. Enter the **chg-dstn** command specifying the **ncai=no** parameter, to change the nested cluster point code to a non-nested cluster point code.
-

E2839 Cmd Rej: Invalid parameter for ITU-N 24bit point code

Commands Used: `chg-appl-rtkey`, `chg-dstn`, `ent-dstn`, `ent-ls`

You specified a 24-bit ITU-N point code and a 14-bit ITU-N alias or ANSI alias point code. Or you specified a 14-bit ITU-N point code and a 24-bit ITU-N alias or ANSI alias point code. You cannot mix 14- and 24-bit point codes. Specifying mixed point codes and alias point codes in a command is not supported.

OR

You entered the **norm** parameter in the `chg-appl-rtkey` for a 24-bit point code. The **norm** parameter is not valid for 24-bit point codes.

Refer to the *Commands Manual* for valid parameter combinations.

Recovery

Re-enter the command that generated this error message specifying one or more valid optional parameters for a 24-bit point code.

Call your Customer Care Center if this error message appears again.

E2840 Cmd Rej: Failed reading tt map table

Commands Used: `chg-ttmap`, `dlt-ttmap`, `ent-ttmap`, `rtrv-ttmap`

The TT MAP table was not accessible to the command you entered. The Translation Type Mapping table must be accessible.

Recovery

Re-enter the command that generated this error message specifying correct **ett** and **mtt** parameter values.

Call your Customer Care Center if this error message appears again.

E2841 Cmd Rej: tt map table full for LSN specified

Commands Used: `ent-ttmap`

The translation type MAP table was full for the linkset specified on the **lsn** parameter.

Recovery

1. Display a list of the current linksets and their status. Enter the **rtrv-ttmap** command.
2. Re-enter the command that generated this error message and set the **lsn** parameter to indicate a linkset that has room to spare.

OR

1. Delete a surplus translation type map from the desired linkset. Enter the **dlt-ttmap** command.
 2. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2842 Cmd Rej: tt map table is full**Commands Used: ent-ttmap**

The translation type MAP table was full for the linkset specified on the **lsn** parameter.

Recovery

1. Display a list of the current linksets and their status. Enter the **rtrv-ttmap** command.
2. Re-enter the command that generated this error message and set the **lsn** parameter to indicate a linkset with room to spare.

OR

1. Delete a surplus translation type map from the desired linkset. Enter the **dlt-ttmap** command.
 2. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2843 Cmd Rej: TT Mapping is not provisioned for this link set**Commands Used: chg-ttmap, dlt-ttmap**

The **lsn** parameter you entered referenced a linkset that was not defined with an accessible Linkset table.

Recovery

Re-enter the command that generated this error message specifying a different **lsn** parameter value.

Call your Customer Care Center if this error message appears again.

E2844 Cmd Rej: ETT not defined for LSN and IO specified

Commands Used: `chg-ttmap`, `dlt-ttmap`, `ent-ttmap`, `rtrv-ttmap`

You failed to specify the existing translation type parameter **ett** when entering this command.

Recovery

Re-enter the command that generated this error message specifying the correct **ett** parameter value.

Call your Customer Care Center if this error message appears again.

E2845 Cmd Rej: ETT already mapped for LSN and IO specified

Commands Used: `ent-ttmap`

The command you entered duplicates a previous mapping of an existing translation type.

Recovery

1. Display a list of existing translation type maps. Enter the `rtrv-ttmap` command.
2. Modify the settings that apply to the existing translation type (**ett**) parameter you are working on. Enter the `chg-ttmap` command.

Call your Customer Care Center if this error message appears again.

E2846 Cmd Rej: ETT cannot be mapped to MTT with same value

Commands Used: `ent-ttmap`

You attempted to re-map a translation point back to its existing value.

Recovery

Re-enter the **ent-ttmap** command that generated this error message specifying a different **mtt** parameter value.

Call your Customer Care Center if this error message appears again.

E2847 Cmd Rej: IF IO or ETT specified, BOTH opt. parms must be specified**Commands Used: dlt-ttmap**

If you specify one of these two parameters, you need to specify the other one as well.

Recovery

Perform one of the following:

- Re-enter the command that generated this error message specifying the correct **io** and **ett** parameter values.

OR

- Re-enter the command that generated this error message without specifying both the **io** and the **ett** parameters.

Call your Customer Care Center if this error message appears again.

E2848 Cmd Rej: ASL8 is only valid for ANSI link sets**Commands Used: chg-ls, ent-ls**

You specified the **asl8=yes** parameter with a linkset containing an adjacent point code in the X.25 domain. This parameter can only be assigned to an SS7 ANSI linkset.

Recovery

Re-enter the command specifying **asl8=no**.

Call your Customer Care Center if this error message appears again.

E2849 Cmd Rej: PC must already exist in the MRN table

Commands Used: `chg-mrn`, `dlt-mrn`, `rtrv-mrn`

You specified a point code parameter value that does not already exist in the Mated Relay Node (MRN) table. The point code must exist in the MRN table before you can change, delete, or retrieve the table information for the point code.

Recovery

1. Display the MRN table. Enter the `rtrv-mrn` command.
 2. Re-enter the command specifying a point code that appears in the output from step 1.
-

E2850 Cmd Rej: MTPXLxx parameters are only valid if CRMD feature is ON

Commands Used: `chg-stpopts`

You specified the `mtpxlq`, `mtpxlet`, and `mtpxlot` parameters, but the Cluster Routing and Management Diversity (CRMD) feature is off.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Verify whether the CRMD feature is turned on. Enter the `rtrv-feat` command. If the CRMD feature is off, you must turn it on.
2. Turn on the CRMD feature. Enter the `chg-feat:crmd=on` command.
3. Re-enter the `chg-stpopts` command.

OR

Re-enter the `chg-stpopts` command without specifying any of these suspect parameters.

E2851 Cmd Rej: MTPXLQ cannot exceed available space in the dstn table

Commands Used: `chg-stpopts`

You entered a value for `mtpxlq` that exceeds the allowable sum of destinations provisioned as determined by adding the values of the `mtpdpcq` and `mtpxlq` parameters ($mtpdpcq + mtpxlq \leq \text{sum}$).

Table 2-16 shows the maximum values of **mtpdpcq**, **mtpxlq**, and their sums with a particular Routesets Feature turned on.

Table 2-16. Routesets Feature with Maximum Values for **mtpdpcq** and **mtpxlq** Parameters

Routesets Feature	Maximum values		
	mtpdpcq	mtpxlq	sum
None	2000	2000	2500
5000	5000	5000	5500
6000	6000	6000	6500
7000	7000	6000	7500
8000	8000	6000	8500

Recovery

1. Verify the number of **mtpdpcq** and **mtpxlq** entries currently allocated. Enter the **rtrv-stpopts** command.
 2. Display the DPCs. Enter the **rtrv-dstn** command.
 3. Calculate the maximum value for the **mtpxlq** parameter, using the information from Table 2-16 and Steps 1 and 2.
 4. Re-enter the command specifying a value for the **mtpxlq** parameter that does not exceed the command requirements as calculated in Step 3.
-

E2852 Cmd Rej: Failed reading STP options table

Commands Used: **chg-gsmopts**, **chg-sccpopts**, **chg-ss7opts**, **chg-stpopts**, **inh-alm**, **rtrv-sccpopts**, **rtrv-stpopts**, **unhb-alm**

The STP options table is corrupt or cannot be found by the system.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E2853 Cmd Rej: ELEI is only valid for cluster destinations

Commands Used: `chg-dstn`, `ent-dstn`

You specified the `elei` parameter, and you specified a DPC that is not a cluster destination. If you specify the `elei` parameter, you must also specify a cluster destination for the `dpc/dpca/dpci/dpcn/dpcn24` parameter.

Recovery

1. Display the cluster DPCs. Enter the `rept-stat-cluster` command.
 2. Perform one of the following:
 - Re-enter the `chg-dstn` command you originally entered, specifying the `elei` parameter, and a cluster destination point code from the output of Step 1.
OR
 - Re-enter the `ent-dstn` command you originally entered, but do not use one of the cluster DPCs from Step 1. Use the format `x-x-*` to take advantage of the wildcard (a variable value indicated by an asterisk) feature.
OR
 - Re-enter the command you originally entered without specifying the `elei` parameter.
-

E2854 Cmd Rej: Alias PCs are not valid for cluster destinations

Commands Used: `chg-dstn`, `ent-dstn`

You cannot specify an alias point code (`aliasa/aliasi/aliasn/aliasn24`) parameter when you specify a cluster destination or a network destination for the (`dpc/dpca/dpci/dpcn/dpcn24`) parameter.

Recovery

1. Perform one of the following:
 - Display the cluster DPCs. Enter the `rept-stat-cluster` command.
OR
 - Display network destinations. Enter the `rtrv-dstn` command.

2. Re-enter the command you originally entered specifying the **aliasa/aliasi/aliasn/ aliasn24** parameter, and a value for the **dpc/dpca/dpci/dpcn/dpcn24** parameter that is not listed as a cluster or network destination in the output from Step 1.

OR

Re-enter the command you originally entered, without specifying the **aliasa/aliasi/aliasn/aliasn24** parameter.

E2855 Cmd Rej: Cluster DPCs are only valid if the CRMD feature is ON

Commands Used: **chg-dstn, dlt-dstn, ent-dstn, rtrv-dstn**

You specified a cluster DPC (**ni-nc-***), but the Cluster Routing and Management Diversity (CRMD) feature is off.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the CRMD feature is on (CRMD=on from the output of Step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the CRMD feature is off (CRMD=off from the output of Step 1), turn it on using the **chg-feat** command.
 4. Re-enter the command that generated the error message.
-

E2856 Cmd Rej: ELEI is only valid if the CRMD feature is ON

Commands Used: **chg-dstn, ent-dstn**

You attempted to change the exception-list exclusion indicator (**elei**) parameter, even though you did not have the cluster routing and management diversity (CRMD) feature turned on.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rt rv-feat** command.
 2. If the CRMD feature is on (CRMD=on from the output of Step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the CRMD feature is off (CRMD=off from the output of Step 1), turn it on.
Enter the **chg-feat : crmd=on** command.
 4. Re-enter the command that generated the error message.
-

E2857 Cmd Rej: DPC is referenced by SCCP's MAP table

Commands Used: **dlt-dstn**

You attempted to delete a destination point code which was referenced in the mated application table.

Recovery

Perform one of the following:

- Re-enter the **dlt-dstn** command that generated this error message specifying a value for the **dpc** parameter that is not in the MAP table.
- OR
- Delete the point code from the MAP table and then re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2858 Cmd Rej: SLSCI is only valid for ANSI link sets

Commands Used: **chg-ls, ent-ls**

You specified the **slsci=yes** parameter, but the linkset does not have an ANSI APC.

Recovery

Perform one of the following:

- Re-enter the command specifying the **slsci=no** parameter.
OR
 - To use the **chg-1s** command specifying the **slsci=yes** parameter setting, first enter the **rtrv-1s** command to obtain the ACPA.
OR
 - To use the **ent-1s** command specifying the **slsci=yes** parameter setting, first enter the **rtrv-dstn** command to obtain the DCPA.
-

E2859 Cmd Rej: Destination address must be a full point code

Commands Used: **chg-dstn, chg-gta, chg-gtt, chg-1s, chg-x25-dstn, dlt-cspc, ent-cspc, ent-dstn, ent-gta, ent-gtt, ent-1s, ent-x25-dstn, rtrv-gta, rtrv-gtt, rtrv-x25-dstn**

You entered the command and specified a destination point code that is not a full point code. A full point code is specified using numerical values for all three segments of the point code.

Recovery

Re-enter the command specifying a point code using the appropriate numerical values for all three segments of the point code.

E2860 Cmd Rej: TFATCABMLQ value exceeds number of links in link set

Commands Used: **chg-1s, ent-1s**

You entered the command and specified a value for the TFA/TCA broadcast minimum link quality (**tfatcabmlq**) parameter, that is more than the total number of links assigned to the linkset. This value cannot exceed the total number of links assigned to the linkset.

Recovery

1. Display the linkset information. Enter the **rtrv-ls** command. The LNKS column lists the total number of links assigned to the linkset.
 2. Re-enter the command specifying a value for the **tfatcabmlq** parameter that is less than the number of links found in step 1, and that is in the parameter's range (**0, 1-16**).
-

E2861 Cmd Rej: Site PC, CPCs and NCPCs must be full point codes

Commands Used: **chg-sid**, **ent-sid**, **rtrv-sid**

You entered the command and specified a point code that is not a full point code. A full point code is one that you specify with numerical values for all three segments of the point code.

Recovery

Re-enter the command specifying a numerical value for all three segments of the point code.

E2862 Cmd Rej: Network/Cluster DSTNs are not supported in the X.25 domain

Commands Used: **ent-dstn**

You entered the command and specified a cluster destination point code that is in the X.25 domain. This command does not support cluster destination point codes in the X.25 domain.

Recovery

1. Display the DPCs. Enter the **rtrv-dstn** command.
2. Re-enter the **ent-dstn** command specifying the cluster **dpc** and the **domain=ss7** parameter.

OR

Re-enter the command specifying the full **dpc** and the **domain=x25** parameter.

E2863 Cmd Rej: Destination's alias PCs must be full PCs

Commands Used: `chg-dstn`, `ent-dstn`, `rtrv-dstn`

You entered this command specifying an asterisk designated as the network indicator (**ni**), network cluster (**nc**), or network cluster member (**ncm**).

Recovery

Re-enter the command that generated this error message specifying the correct point code format.

Call your Customer Care Center if this error message appears again.

E2864 Cmd Rej: Address (PCx) of primary subsystem must be a full PC

Commands Used: `chg-map`, `dlt-map`, `ent-map`, `rtrv-map`

You entered the command but did not specify numerical values for all three segments of the destination point code. The destination point code of the primary subsystem must be a full point code; in other words, you must specify numerical values for all three segments of the point code (**ni-nc-ncm**).

Recovery

Re-enter the command specifying numerical values for all three segments of the destination point code.

E2865 Cmd Rej: Address (MPCx) of mate subsystem must be a full PC

Commands Used: `chg-map`, `ent-map`

The command was entered with a value for the mate point code (**mpc**, **mpca**, **mpci**, **mpcn**, **mpcn24**) that was a cluster point code (**001-011-***). The value for these parameters must be a full point code (**001-011-001**), and the point code must be in the routing table.

Recovery

1. Display the mated applications. Enter the `rtrv-map` command.

2. Display the routes in the database. Enter the **rtrv-rte** command.
 3. Re-enter the command specifying a value for the **mpc (mpca, mpci, mpcn, mpcn24)** parameter that is displayed in the **rtrv-rte** command output (as displayed in one of the following fields: DPCA, DPCI, DPCN, or DPCN24) and is not a cluster point code.
-

E2866 Cmd Rej: TFATCABMLQ is invalid for C-link sets**Commands Used: chg-1s**

The optional TFA/TCA broadcast minimum link quality (**tfatcabmlq**) parameter cannot be changed for C linksets, because C linksets are the primary route for mated STPs.

Recovery

Re-enter the **chg-1s** command that generated this error message without specifying the **tfatcabmlq** parameter.

Call your Customer Care Center if this error message appears again.

E2867 Cmd Rej: Routes of equal cost cannot exist for X.25 destinations**Commands Used: chg-rte, ent-rte**

Combined linksets are not allowed for X.25 destinations. Routes of equal cost destined for X.25 domains are not allowed.

Recovery

Re-enter the **chg-rte** command that generated this error message specifying the correct rc parameter value.

Call your Customer Care Center if this error message appears again.

E2868 Cmd Rej: Invalid NCAI parameter has been entered**Commands Used: chg-dstn, ent-dstn**

You specified the **ncai** parameter for a destination address that is not a cluster destination. The EAGLE 5 ISS does not allow this action.

Recovery

Re-enter the command without specifying the **ncai** parameter.

OR

1. View the cluster DPCs and the routeset information for all configured clusters. Enter the **rept-stat-cluster** command. The cluster DPCs are displayed in the DPCA field (for example, 7-7-* is a cluster destination).
 2. Re-enter the command specifying a destination address that is a cluster destination.
-

E2869 Cmd Rej: NCAI param is only valid if both feat CRMD and NCR are ON

Commands Used: **ent-dstn**

You specified the **ncai** parameter, but the Cluster Routing and Management Diversity (CRMD) and Nested Cluster Routing (NCR) features are turned off, as required.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If both the CRMD and NCR features are turned on (from the output of Step 1 - CRMD=on and NCR=on), re-enter the **ent-dstn** command.
Call your Customer Care Center if this error message appears again.
 3. If either the CRMD or the NCR feature is turned off, turn it on. Enter the **chg-feat:crmd=on** or **chg-feat:ncr=on** commands.
 4. Re-enter the **ent-dstn** command that generated this error message.
-

E2870 Cmd Rej: LFS feature must be ON

Commands Used: **act-lbp, chg-lbp, dlt-lbp, ent-lbp, rept-stat-lfs, rtrv-lbp**

The Link Fault Sectionalization (LFS) feature must be turned on to use these commands.

NOTE: Once a feature that is controlled using a feature bit is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Verify whether the LFS feature is turned on. Enter the `rttrv-feat` command. If the LFS feature is off, you must turn it on.
 2. Turn on the LFS feature. Enter the `chg-feat:lfs=on` command.
 3. Re-enter the command that generated the error message.
-

E2871 Cmd Rej: NCPCx and CPCx type must match

Commands Used: `chg-sid`

You specified an STP capability point code type that does not match the new STP capability point code type; for example:

```
chg-sid:cpcn=01234:ncpci=2-003-4
```

In this example, the STP capability point code is ITU national, and the new STP capability point code is ITU international.

Recovery

Re-enter the `chg-sid` command specifying the same capability point code type for both the `cpc/cpca/cpci/cpcn/cpcn24` parameter and the `ncpc/ncpca/ncpci/ncpcn/ncpcn24` parameter.

E2872 Cmd Rej: CPCx has not been provisioned

Commands Used: `chg-sid`

You specified the new STP capability point code (`ncpc/ncpca/ncpci/ncpcn/ncpcn24` parameter), but the specified STP capability point code (`cpc/cpca/cpci/cpcn/cpcn24` parameter) does not exist in the database.

This command requires that, if you specify the `ncpc/ncpca/ncpci/ncpcn/ncpcn24` parameter, you must already have entered the `cpc/cpca/cpci/cpcn/cpcn24`.

Recovery

1. Enter the `rttrv-sid` command specifying the `cpcx` parameter to verify the capability point code's existence.

2. Re-enter the **chg-sid** command without specifying the **ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameter.

OR

Re-enter the **chg-sid** command specifying both the **ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameter and the **cpc/cpca/cpci/cpcn/cpcn24** parameter, ensuring that you use the same point code type for both.

Call your Customer Care Center if this error message appears again.

E2873 Cmd Rej: NCPCx cannot be specified without CPCx

Commands Used: chg-sid

You specified the new STP capability point code (**ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameter), but you did not specify the STP capability point code (**cpc/cpca/cpci/cpcn/cpcn24** parameter). This command requires that if you specify the **ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameter, you must specify the **cpc/cpca/cpci/cpcn/cpcn24** parameter.

Recovery

Re-enter the **chg-sid** command specifying both the **ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameter and the **cpc/cpca/cpci/cpcn/cpcn24** parameter, ensuring that you use the same point code type for both.

E2874 Cmd Rej: Failed reading site identification table

Commands Used: chg-dstn, chg-gta, chg-gsmopts, chg-gtt, chg-gws-redirect, chg-ls, chg-map, chg-mrn, chg-sccp-serv, chg-sid, dlt-map, ent-gta, ent-gtt, ent-gws-redirect, ent-ls, ent-map, ent-mrn, ent-spc, rtrv-dstn, rtrv-map, rtrv-sid

The site identification table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2875 Cmd Rej: Network/Cluster cannot have alias DPC members**Commands Used: ent-dstn**

Alias ANSI point codes cannot have the same network identifier (**ni**) and network cluster (**nc**) subfields as a cluster point code that is already defined.

Recovery

Re-enter the **ent-dstn** command that generated this error message specifying the correct **ni** and **nc** subfields.

Call your Customer Care Center if this error message appears again.

E2876 Cmd Rej: Alias DPCs cannot be a member of a Network or Cluster**Commands Used: ent-dstn**

Alias ANSI point codes cannot have the same network identifier (**ni**) and network cluster (**nc**) subfields as a cluster point code that is already defined.

Recovery

Re-enter the **ent-dstn** command that generated this error message specifying the correct **ni** and **nc** subfields.

Call your Customer Care Center if this error message appears again.

E2877 Cmd Rej: NCAI required if cluster members have different route set**Commands Used: ent-dstn**

You entered a command to provision a cluster point code and did not include **ncai=yes** in the command. When the collection of signaling points sharing the network identifier (**ni**) and network cluster (**nc**) code have different route sets, you must specify **ncai=yes** in the command.

Recovery

Re-enter the **ent-dstn** command that generated this error message and include the **ncai=yes** parameter.

Call your Customer Care Center if this error message appears again.

E2878 Cmd Rej: Ordered routes cannot be assigned to cluster members**Commands Used: ent-rte**

A route is already provisioned for *ni-nc-xxx* (where *xxx* is * or *pc*). You cannot enter a route on a linkset different than the one already provisioned, unless the specified destination addresses's NCAI (nested cluster allowed indicator) is set to **yes**.

Recovery

1. Change the NCAI to **yes**. Enter the **chg-dstn:dpc=ni-nc-*:ncai=yes** command.
2. Re-enter the **ent-rte** command that generated this error message.

OR

1. Verify that the DPC you specified is a member of a cluster. Enter the **rept-stat-cluster** command. This command displays routeset information for all configured clusters. The cluster DPCs are displayed in the DPCA field. (For example, if *7-7-** exists, then *7-7-3* cannot be assigned to a route because it is a cluster member).
2. Re-enter the **ent-rte** command that generated this error message specifying a DPC that is not a member of a provisioned cluster.

Call your Customer Care Center if this error message appears again.

E2879 Cmd Rej: Ordered routes cannot be deleted from cluster members**Commands Used: dlt-rte**

The ordered route you attempted to delete has a full point code address (*ni-nc-ncm*) as the destination address and is a member of a provisioned cluster (*ni-nc-**). You can delete the ordered route only if the specified destination's NCAI (nested cluster allowed indicator) is set to **yes**. Deletion of a provisioned member's ordered routes results in the provisioned member assuming the attributes of its cluster.

Recovery

1. Change the NCAI to **yes**. Enter the **chg-dstn:dpc=ni-nc-*:ncai=yes** command.
2. Re-enter the **dlt-rte** command that generated this error message.

OR

1. Verify that the DPC you specified is a member of a cluster. Enter the **rept-stat-cluster** command. This command displays routeset information for all configured clusters. The cluster DPCs are displayed in the DPCA field.
 2. Re-enter the **dlt-rte** command that generated this error message specifying a destination point code that is not a member of a provisioned cluster.
Call your Customer Care Center if this error message appears again.
-

E2880 Cmd Rej: MTPDPCQ cannot exceed available space in the dstn table

Commands Used: **chg-stpopts**

You entered a value for **mtpdpcq** that exceeds the allowable sum of destinations provisioned as determined by adding the values of the **mtpdpcq** and **mtpxlq** parameters (**mtpdpcq + mtpxlq <= sum**).

Table 2-17 shows the maximum values of **mtpdpcq**, **mtpxlq**, and their sums with a particular Routesets Feature turned on.

Table 2-17. Routesets Feature with Maximum Values for **mtpdpcq** and **mtpxlq** Parameters

Routesets Feature	Maximum values		
	mtpdpcq	mtpxlq	sum
None	2000	2000	2500
5000	5000	5000	5500
6000	6000	6000	6500
7000	7000	6000	7500
8000	8000	6000	8500

Recovery

1. Verify the number of **mtpdpcq** and **mtpxlq** entries currently allocated. Enter the **rtrv-stpopts** command.
2. Display the DPCs. Enter the **rtrv-dstn** command.

3. Calculate the maximum value for the **mtpdpcq** parameter, using the information from Table 2-17 and Steps 1 and 2.
 4. Re-enter the **chg-stpopts** command specifying a value for the **mtpdpcq** parameter that does not exceed the command requirements as calculated in Step 3.
-

E2881 Cmd Rej: MTPDPCQ cannot be increased while x-list storage is full**Commands Used: chg-stpopts**

You cannot increase the number of DPCs provisioned (**mtpdpcq**) if space allocated for maintaining x-list entries becomes full.

Recovery

Re-enter the **chg-stpopts** command that generated this error message to eliminate the possibility that this error message was generated by a data input error.

Call your Customer Care Center if this error message appears again.

E2882 Cmd Rej: MSAR=ONLY must be specified exclusively**Commands Used: rtrv-dstn**

You entered the command and specified the **msar=only** parameter along with other parameters. When you specify the **msar=only** parameter, it must be the only parameter you specify.

Recovery

Perform one of the following:

- Re-enter the **rtrv-dstn** command specifying the **msar=only** parameter by itself.
- OR
- Re-enter the **rtrv-dstn** command specifying a value other than **only** for the **msar** parameter.
-

E2883 Cmd Rej: Maximum number of CPCs defined (96)**Commands Used: chg-sid**

The maximum number of capability point codes you can specify is **96**. You specified a capability point code (**cpc**) that would have been the 97th entry in the database. You must first delete an existing CPC before you can add a new one.

Recovery

1. Display the CPCs currently configured in the EAGLE 5 ISS database. Enter the **rtrv-sid** command.
 2. Delete one of the existing CPCs. Enter the **chg-sid:cpc=xxx-xxx-xxx:ncpc=none** command, where **xxx-xxx-xxx** is a point code you select from the output in step 1.
-

E2884 Cmd Rej: PCx, NPCx, CPCx or NCPCx must not be equal**Commands Used: chg-sid**

The values specified for the **pc/pca/pci/pcn/pcn24**, **cpc/cpca/cpci/cpcn/cpcn24**, and **ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameters must all be different.

Recovery

Re-enter the **chg-sid** command specifying a different value for each of the **pc/pca/pci/pcn/pcn24**, **npci/npcn**, **cpc/cpca/cpci/cpcn/cpcn24**, and **ncpc/ncpca/ncpci/ncpcn/ncpcn24** parameters.

E2885 Cmd Rej: Ordered routes cannot be changed for cluster members**Commands Used: chg-rte**

You specified a destination address that is a full point code address (**ni-nc-ncm**) and is a member of a provisioned cluster (**ni-nc-***), but the specified destination address's Nested Cluster Allowed Indicator (NCAI) is set to **no**.

Whether the attributes of the ordered routes assigned to the cluster can be changed is determined by the destination address's NCAI. The NCAI (**ncai=yes/no**) is set with the **ncai** parameter of the **ent/chg-dstn** commands.

If the **ncai=no**, the attributes of the ordered routes assigned to the cluster cannot be changed.

If the **ncai=yes**, then the specified destination address is a member of a provisioned nested cluster where the attributes of the ordered routes assigned to the cluster can be changed.

Perform one of the procedures in the following Recovery procedures.

Recovery - Change ordered route attributes for the cluster.

1. Verify that the DPC you specified is a member of a cluster. Enter the **rept-stat-cluster** command. This command displays routeset information for all configured clusters and the cluster DPCs are displayed in the DPCA field.
 2. Re-enter the **chg-rte** command specifying the cluster DPC (displayed in the DPCA field) of the cluster member point code you entered originally.
-

Recovery - Change ordered route attributes for a different DPC.

Re-enter the **chg-rte** command specifying a DPC that is not a member of a cluster displayed in the DPCA field.

Recovery - Change ordered route attributes for a DPC assigned to the cluster.

Change the **ncai** setting. Enter the **chg-dstn:dpc=ni-nc-*:ncai=yes** command. Re-enter the **chg-rte** command that generated this error message.

E2886 Cmd Rej: DSTN address must be a full, network or cluster PC

Commands Used: **chg-dstn**, **chg-rte**, **dact-rstst**, **dlt-dstn**, **dlt-rte**, **ent-dstn**, **ent-rte**, **rept-stat-cluster**, **rept-stat-dstn**, **rst-dstn**, **rtrv-rte**

The following Recovery procedures describe the conditions that causes the error and list the remedial actions to take for each command that generates this error message.

Recovery - rept-stat-dstn

You specified a point code in the format **ni-nc-**** or **ni-nc-***** and the **mode=full** parameter. The **mode=full** parameter requests detailed status information for a single point code, and specifying point codes in the format **ni-nc-**** or **ni-nc-***** requests summary status for a range of point codes; therefore, the two are not compatible, and you cannot specify them in the same command.

Perform one of the following:

- Re-enter the **rept-stat-dstn** command without specifying the **mode=full** parameter. Use a point code in the format **ni-nc-**** or **ni-nc-*****. Here is an example: **rept-stat-dstn:dpc=1-1-****

OR

- Re-enter the **rept-stat-dstn** command specifying the **mode=full** parameter and a destination point code. Here is an example: **rept-stat-dstn:dpc=1-1-1:mode=full**

Recovery - chg-dstn, chg-rte, dact-rstst, dlt-dstn, dlt-rte, ent-dstn, ent-rte

You specified a point code in the format **ni-nc-**** or **ni-nc-*****. You can enter these formats only on the **rtrv** or **rept-stat** command to simplify retrieving and reporting ranges of destination point codes.

Re-enter the command specifying a single destination point code. Here is an example: **chg-dstn:dpc=111-222-111:c11i=r1ghncxa01a)**

Recovery - rept-stat- cluster, rst-dstn, rtrv-rte

You specified a destination address (**dpc** or **dpca**) that was not a full point code, a cluster point code, a network address, or a permissible asterisk combination.

Re-enter the command specifying a valid destination point code.

Refer to the *Commands Manual* for information regarding valid destination point code formats.

E2887 Cmd Rej: Failed accessing maintenance data

Commands Used: `chg-stpopts`, `dlt-appl-rtkey`, `rept-stat-rtkey`,
`rtrv-appl-rtkey`

The cluster exception-list (x-list) maintenance data is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2888 Cmd Rej: MTPDPCQ cannot be less than no. of destinations provisioned

Commands Used: `chg-stpopts`, `ent-stpopts`

You have specified a value for the `mtpdpcq` parameter that is **less** than the number of DPCs configured in the EAGLE 5 ISS database. This parameter is used to specify the **maximum** number of DPCs that you can configure in the database.

Recovery

1. Display the number of DPCs configured in the EAGLE 5 ISS database. Enter the `rtrv-dstn` command. If you have the Cluster Routing and Management Diversity (CRMD) feature turned on, the total number of DPCs is displayed in the TOTAL DPC(s) field. If you do not have the CRMD feature turned **on**, the number is the first number (in bold for this example) in parentheses as displayed in the following example of output:
Destination table is (678 of 2000) 34% full
 2. Re-enter the command specifying a value for the `mtpdpcq` parameter that is greater than or equal to, the number of DPCs displayed in the output of step 1.
-

E2889 Cmd Rej: No user associated with OAP terminal

Commands Used: `canc-user`, `chg-pid`, `logout`, `rtrv-user`

You specified OAP flow-through, but because OAP requires no login, there is no user to cancel, no password to change, no user privileges to retrieve, no logout necessary. The `logout` command cannot be issued from a SEAS terminal.

Recovery

These commands cannot be entered from a OAP terminal. You must be logged in to an EAGLE 5 ISS terminal to use these commands.

E2890 Cmd Rej: DPC must be specified as wildcard when used with STAT

Commands Used: `rept-stat-dstn`

You specified both the **dpc** and the **stat** parameters, but you did not specify the point code in wild card format (***ni-nc-**** or ***ni-nc-******).

NOTE: A 'wildcard value' is an expression meaning the value is a variable indicated by an asterisk. Refer to Appendix A of the *Commands Manual* for an explanation of the use of asterisks in commands.

Recovery

Perform one of the following:

- Re-enter the `rept-stat-dstn` command specifying either the **dpc** parameter or the **stat** parameter, but not both.
- OR
- Re-enter the `rept-stat-dstn` command specifying both the **dpc** and the **stat** parameters, and the point code in wild card format (***ni-nc-**** or ***ni-nc-******).
-

E2891 Cmd Rej: Failed reading Link Fault Sectionalization table

Commands Used: `act-lbp`, `chg-lbp`, `dlt-lbp`, `ent-lbp`, `rtrv-lbp`

The link fault sectionalization table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2892 Cmd Rej: LOC is not LFS capable

Commands Used: `act-lbp`, `chg-lbp`, `dact-lbp`, `dlt-lbp`, `ent-lbp`,
`rept-stat-lfs`, `rtrv-lbp`

You entered the command and identified a card location that does not meet the command criteria. The card location (**loc**) must identify a provisioned **limds0**, **limt1**, or **limch** (which is associated with a **limt1**) card configured with either an **ss7ansi** or a **ccs7itu** application.

Recovery

1. Display information about the card in the location you have identified. Enter the **rtrv-card** command. The output of this command shows the card location, the card type, the application the card is running, the linkset name, and the signaling link code for the LIM cards.
 2. Use the output from step 1 to select a card location that is provisioned as a **limds0**, **limt1**, or **limch** card configured with either an **ss7ansi** or a **ccs7itu** application.
 3. Re-enter the command specifying the card location selected in step 2 as the **loc** parameter value.
-

E2893 Cmd Rej: REP must be greater than prev. and less than subsequent REP

Commands Used: `chg-lbp`, `ent-lbp`

You entered the command and specified a **rep** parameter value for this remote link element (RLE) that does not meet the command criteria. The **rep** parameter value you specify for an RLE must be **greater** than the **rep** parameter value of any previously defined RLE of the same type and **less** than the **rep** parameter value of any subsequently defined RLE of that type.

Recovery

1. Display all the loopback points on the signaling links for this STP. Enter the **rtrv-lbp** command. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. The RLEs for each LBP are listed in the RLE field, and the repetition counts for the LBPs are listed in the REP field of the output. Refer to the output examples for the **rtrv-lbp** command in the *Commands Manual*.

2. Use the output from step 1 to determine a value for the **rep** parameter that meets the command criteria.
 3. Re-enter the command specifying the **rep** parameter with the value you selected in step 2.
-

E2894 Cmd Rej: LBP has already been provisioned

Commands Used: `ent-1bp`

You attempted to configure a loopback point ID that has been used in a previous configuration. This command does not allow that action.

Recovery

1. Display all the loopback points on the signaling links for this STP. Enter the `rtrv-1bp` command. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. Refer to the output examples for the `rtrv-1bp` command in the *Commands Manual*.
 2. Re-enter the command specifying for the **lbp** parameter a loopback point ID value that does not appear in the output from step 1.
-

E2895 Cmd Rej: REP must be zero if link element to be tested is NEI

Commands Used: `act-1bp`, `chg-1bp`, `ent-1bp`

You entered the command and specified the **rle=nei** parameter, but you did not specify the **rep=0** parameter. If the remote link element (**rle**) parameter to be tested is a network element interface (**nei**) value, you must specify the repetition count (**rep**) parameter as **0**.

Recovery

Perform one of the following:

- Re-enter the command as you entered it originally specifying the **rep=0** parameter.
- OR
- Re-enter the command specifying the **rep** parameter with a value other than **0**, and the **rle** parameter with a range value other than **nei**.
-

E2896 Cmd Rej: DS0 and NEI link elements do not support non-latching tests

Commands Used: `act-1bp`, `chg-1bp`, `ent-1bp`

You entered the command and specified either the `rle=ds0` or the `rle=nei` parameter, and you specified the `lfst=nlt` parameter instead of the `lfst=llt` parameter. The DS0 and NEI link elements cannot be used for non-latching loopback (NLT) tests.

Recovery

Perform one of the following actions:

- Re-enter the command specifying either the `rle=ds0` or the `rle=nei` parameter and the `lfst=llt` parameter.
- OR
- Re-enter the command specifying either `ocu`, `csu`, and `dsu` for the `rle` parameter, and the `lfst=nlt` parameter.
-

E2897 Cmd Rej: REP is only valid if LFST is defined as LLT

Commands Used: `act-1bp`, `chg-1bp`, `ent-1bp`

You entered the command and specified the `rep` parameter, but you did not specify the `lfst=llt` parameter. You can specify the number of link elements to be tested only if you choose the latching loopback test.

Recovery

Perform one of the following:

- Re-enter the command specifying the `rep` parameter and the `lfst=llt` parameter.
- OR
- Re-enter the command without specifying the `rep` parameter.
-

E2898 Cmd Rej: LBP cannot exceed previously defined NEI LBP value**Commands Used: ent-lbp**

You cannot specify a value for the **lbp** parameter that exceeds the **lbp** parameter value previously defined for a loopback point with **rle=nei** specified. The network element interface (NEI), specified by the **rle=nei** parameter, identifies the last remote link element on the signaling link; therefore, you cannot define an element whose relative position is beyond that of the NEI.

Recovery

1. Enter the **rtrv-lbp** command to display all the loopback points on the signaling links for this STP. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. The NEI LBPs are listed last and are identified by NEI in the RLE field of the output. Refer to the output examples for the **rtrv-lbp** command in the *Commands Manual*.
 2. Locate the LBP ID value for the NEI LBP on the signaling link being configured.
 3. Re-enter the **ent-lbp** command specifying a value for the **lbp** parameter that is less than than the LBP ID value found in step 2.
-

E2899 Cmd Rej: NEI LBP has already been defined for the CCS7 link**Commands Used: chg-lbp, ent-lbp**

You entered the command to configure a Network Element Interface (NEI) Remote Link Element (RLE) on a signaling link that already has an NEI LBP configured.

Recovery

1. Verify that the link has an NEI LBP configured. Enter the **rtrv-lbp** command. This command displays all the loopback points on the signaling links for this STP. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. The NEI LBPs are listed last and are identified by NEI in the RLE field of the output. Refer to the output examples for the **rtrv-lbp** command in the *Commands Manual*.
 2. Re-enter the command you entered originally specifying a value other than **nei** for the **rle** parameter.
-

E2900 Cmd Rej: NEI LBP must be defined as the last link element

Commands Used: `chg-lbp`, `ent-lbp`

You entered the command and tried to configure a network element interface (NEI) remote link element (RLE), whose loopback point (LBP) ID does not define the last element on the link. For example, you might have entered `ent-lbp:loc=1101:port=a:lbp=2:rle=nei:lft=11t`. If the NEI loopback point 2, at card location **1101 port a**, is not the **last** element on that signaling link, you receive error message E2900.

Recovery

1. Display all the loopback points on the signaling links for this STP. Enter the `rtrv-lbp` command. The loopback point IDs for each signaling link are displayed in numerical order in the LBP field. Refer to the output examples for the `rtrv-lbp` command in the *Commands Manual*.
2. Using the output from step 1, determine the loopback point ID of the last element on the signaling link in question.
3. Re-enter the command you entered originally specifying a value for the `lbp` parameter that is greater than the last loopback point ID in the output from step 1.

OR

Re-enter the command you entered originally specifying a value other than `nei` for the `rle` parameter.

E2901 Cmd Rej: LBP must have been previously defined in database

Commands Used: `act-lbp`, `chg-lbp`, `dlt-lbp`

You cannot change or delete a loopback point that does not already exist in the database.

Recovery

1. Display the attributes for all the loopback points for SS7 links assigned to the STP. Enter the `rtrv-lbp` command. The loopback points are listed in the LBP field of the output.
 2. Using the output from step 1, select the loopback point you want to change, delete, or activate.
 3. Re-enter the command specifying the loopback point you selected in step 2.
-

E2902 Cmd Rej: LBP or ALL parameter must be specified exclusively**Commands Used: dlt-lbp**

You entered the **dlt-lbp** command and specified both the **lbp** and the **all** parameters. This combination is not allowed. The **all** parameter deletes all loopback points for the specified signaling link, whereas the **lbp** parameter deletes a specific loopback point.

Recovery

Re-enter the **dlt-lbp** command specifying either the **lbp** parameter (with a specific loopback point) or the **all** parameter, but not both.

E2903 Cmd Rej: LOC and PORT parameter combination must be specified

Commands Used: inh-alm, rept-stat-cdl, rept-stat-lfs, rept-stat-tstslk, rtrv-e1, rtrv-lbp, rtrv-t1, unhb-alm

Table 2-18 on page 2-369 lists by command the conditions that may have generated this error message.

Table 2-18. Conditions that Generate an E2903 Error Message

Command	Condition
inh-alm, unhb-alm	You specified the dev=slk parameter, which requires that both the loc and the port/link parameters be specified.
rept-stat-cdl, rept-stat-lfs, rept-stat-tstslk	You entered a port parameter without also specifying the card location. Re-enter the command either with both loc and port parameters or without the port parameter.
rtrv-lbp	You entered the command and specified the lbp parameter, but you did not enter a loc and port parameter combination. In order to display the attributes for a specific loopback point (lbp parameter) that lies along an SS7 signaling link, you must specify the card location (loc parameter) and port (port parameter).
rtrv-e1	You entered the command but did not specify both the loc and e1port parameters. This command requires that both of these parameters.
rtrv-t1	You entered the command but did not specify both the loc and t1port parameters. This command requires that both of these parameters.

Recovery

Re-enter the command that generated this error message specifying the **loc** and **port** parameters.

E2904 Cmd Rej: TFATFRPR must be in increments of 100 msec**Commands Used: chg-stpopts**

You specified a value for the **tfatfrpr** parameter that is not in increments of **100** ms (milliseconds). For example, you might have entered **chg-stpopts:tfatfrpr=225**.

Recovery

1. Display the current values of the EAGLE 5 ISS's node-level processing option indicators, maintained in the STP's options table. Enter the **rtrv-stpopts** command. The TRATFRPR field displays the value you entered for the **tfatfrpr** parameter for the **chg-stpopts** command. The value must be an increment of **100** ms.
 2. Re-enter the **chg-stpopts** command specifying a value that is an increment of **100** ms.
-

E2905 Cmd Rej: LFS command in progress**Commands Used: act-lbp, dact-lbp, tst-slk**

You cannot issue another **act-lbp** or **dact-lbp** or **tst-slk** command until any previously issued **act-lbp** or **dact-lbp** or **tst-slk** command is accepted.

Recovery

1. Display the status of the currently active LFS tests. Enter the **rept-stat-lfs** command.
 2. Re-enter the command that generated this error after the previously issued **act-lbp** or **dact-lbp** or **tst-slk** command is accepted.
Call your Customer Care Center if this error message appears again.
-

E2906 Cmd Rej: LFS test is completing, cannot be canceled**Commands Used: `dact-1bp`**

A previously issued `act-1bp` command is about to complete. A new `dact-1bp` command cannot be accepted until the `act-1bp` command completes.

Recovery

1. Display the status of the currently active LFS tests. Enter the `rept-stat-lfs` command.
2. Re-enter the `dact-1bp` command after permitting the currently running test enough time to complete.

Call your Customer Care Center if this error message appears again.

E2907 Cmd Rej: No active LFS Test on the specified link**Commands Used: `dact-1bp`**

There is no active LFS Test on the specified link. A `dact-1bp` command has been issued on a link other than the one for which the test is active.

Recovery

1. Display the status of the currently active LFS tests. Enter the `rept-stat-lfs` command.
2. Re-enter the `dact-1bp` command, specifying a link with an active LFS test.

Call your Customer Care Center if this error message appears again.

E2909 Cmd Rej: LFS data is only valid for OCTET and ALTERNATE patterns**Commands Used: `act-1bp`**

You can specify the `data` parameter only if you specify the `pattern=octet` parameter or `pattern=alternate` parameter.

Recovery

Re-enter the `act-1bp` command that generated this error message specifying the correct `pattern` parameter value.

Call your Customer Care Center if this error message appears again.

E2910 Cmd Rej: RLE and LFST must be specified when database is not used**Commands Used: act-1bp**

If you specify any one of the **rle**, **rep**, **lfst**, or **orcli** parameters, the database is not used to look up their values; therefore, you must specify the **lfst** and **rle** parameters.

Recovery

Re-enter the **act-1bp** command specifying the correct **rle** and **lfst** parameter values.

Call your Customer Care Center if this error message appears again.

E2911 Cmd Rej: OCTET and ALTERNATE are not valid for non-latching test**Commands Used: act-1bp**

You can specify the **pattern=octet** or **pattern=alternate** parameter only for latching tests.

Recovery

Re-enter the **act-1bp** command that generated this error message without specifying the **pattern** parameter.

Call your Customer Care Center if this error message appears again.

E2912 Cmd Rej: LOC must be LIMDS0 or LIMOCU with SS7ANSI or CCS7ITU**Commands Used: act-1bp**

The card location (**loc**) parameter must identify a provisioned **limds0** card configured with either an **ss7ansi** or **ccs7itu** application.

Recovery

Re-enter the **act-1bp** command that generated this error message specifying the correct **loc** parameter value.

Call your Customer Care Center if this error message appears again.

E2913 Cmd Rej: Link must not be active for dact-lbp command

Commands Used: `dact-lbp`

The specified signaling link must not be active. The `dact-lbp` command can be entered on a link only if there is an active LFS test active on that link.

Recovery

1. Wait until the active LFS testing of the link is complete.
 2. Deactivate the link. Re-enter the `dact-lbp` command.
-

E2914 Cmd Rej: REP parameter must be specified

Commands Used: `chg-lbp`, `ent-lbp`

You did not specify the `rep` parameter, accepting instead the default value, and that value is incongruous with `rep` parameter values of previously defined loopback points.

For example, suppose the previously defined values for the `rep` parameter were **1** and **2**. The EAGLE 5 ISS defaults to **2** because no integer exists between **1** and **2**. The sequence of `rep` parameter values would now be **1, 2, 2** but the two same values cause the EAGLE 5 ISS to generate error message E2914.

Recovery

1. Enter the `rtrv-lbp` command and look at the REP field values for the `rep` parameter.
 2. Select a new `rep` parameter value based on these previously entered values.
 3. Re-enter the original command (`chg-lbp` or `ent-lbp`), specifying the new value for the `rep` parameter.
-

E2915 Cmd Rej: MTPT10ALT cannot be less than level-3 timer T10

Commands Used: `chg-stpopts`

You entered this command specifying the `mtp10alt` parameter set to a value that gave it a priority that was too high, since this timer by definition schedules tests on low-priority routes.

Recovery

1. Acquire the current descriptive parameters. Enter the **rtrv-stpopts** command.
 2. Re-enter the **chg-stpopts** command that generated this error message, and assign a valid value, acquired in step 1, to the **mtp10alt** parameter.
-

E2916 Cmd Rej: Link must not be active to execute command

Commands Used: **act-cdl, act-lbp, dact-cdl, dact-lbp, tst-slk**

The link that you use for testing cannot be active.

Recovery

1. Deactivate the signaling link with the **dact-slk** command.
 2. Re-enter the original command.
Call your Customer Care Center if this error message appears again.
-

E2917 Cmd Rej: Link must be SS7 to execute command

Commands Used: **rept-stat-tstslk, tst-slk**

The signaling link must be an SS7 signaling link to execute this command.

Recovery

Re-enter the command that generated this error message to rule out the possibility that it was the result of a keying error.

Call your Customer Care Center if this error message appears again.

E2918 Cmd Rej: Link must be SS7 to display Level 2 stats

Commands Used: **rept-stat-slk**

The signaling link must be an SS7 signaling link to display level 2 statistics.

Recovery

Re-enter the **rept-stat-slk** command that generated this error message without specifying the **l2stats** parameter.

Call your Customer Care Center if this error message appears again.

E2919 Cmd Rej: LOC and PORT must be specified to display Level2 stats

Commands Used: **rept-stat-slk**

You cannot display Level2 stats without specifying values for both the **loc** and **port** parameters.

Recovery

Re-enter the **rept-stat-slk** command specifying values for both the **loc** and **port** parameters.

E2920 Cmd Rej: Loopback in progress

Commands Used: **act-lbp**

You entered this command while another **act-lbp** command was in progress. Only one loopback test can be performed at a time.

Recovery

1. Wait for the active loopback test to complete.
 2. Re-enter the additional **act-lbp** command.
-

E2921 Cmd Rej: LFS must not be running on requested link

Commands Used: **act-cdl, tst-slk**

You entered this command while the Link Fault Sectionalization test was running on the requested link.

Recovery

Perform one of the following:

- Re-enter the command that generated this error message after giving the link time to complete any activities in progress.

OR

- Re-enter the command that generated this error message but specify a different link.

Call your Customer Care Center if this error message appears again.

E2922: Cmd Rej: Link must be SAAL to execute command

Commands Used: `act-cdl`, `tst-slk`

You specified a **loopback** parameter valid only for ATM high-speed signaling links.

Recovery

1. Display the card's configuration, using the `rtrv-card` command specifying the card location used in the command that generated this error message. The card's type is shown in the TYPE field of the output.
 2. If the card's type is not `limatm` or `lime1atm`, re-enter the command, using a parameter valid for low-speed signaling links.
-

E2923 Cmd Rej: Maximum number of link tests already in progress

Commands Used: `act-lbp`, `dact-cdl`, `dact-lbp`, `tst-slk`

The maximum number of allowed LFS or signaling link tests is already in progress.

`act-lbp`, `tst-slk`

At least one active test must complete before re-issuing another `act-lbp` command.

`dact-cdl`

A command-driven loopback is not found, assumed to be a remote loopback. The maximum number of tests is running; therefore, the `dact-cdl` command is not allowed for the remote loopback. At least one active test must complete before supporting the `dact-cdl` command.

dact-1bp

A locally initiated loopback is not found, and is assumed to be a remote loopback. The maximum number of tests is currently running; therefore, the **dact-1bp** command is not allowed for the remote loopback. At least one active test must complete before you re-enter the **dact-1bp** command.

Recovery

1. Enter the **rept-stat-lfs** or **rept-stat-tstslk** command to display the status of the currently active tests.
2. Re-enter the command that generated this error message after either permitting one of the currently running tests sufficient time to complete, or stopping an active test with the **dact-1bp** or **tst-slk:action=stop** command.

Call your Customer Care Center if this error message appears again.

E2924 Cmd Rej: LOC has maximum number of LFS Tests already in progress**Commands Used: act-1bp**

The maximum number of allowed tests is already in progress on this LOC. At least one active LFS test on this LOC must be completed before another **act-1bp** command can be performed for this card location.

Recovery

1. Enter the **rept-stat-lfs** command to monitor the amount of time until test completion for the LOC.
2. Re-enter the **act-1bp** command that generated this error after permitting the test on the LOC to complete.

Call your Customer Care Center if this error message appears again.

E2925 Cmd Rej: The Gateway Linkset table is full**Commands Used: ent-1s**

You exceeded the maximum number of linksets (255) when you entered this command.

Recovery

1. Enter the **rtrv-ls** command to acquire the linkset information.
 2. Delete an unneeded linkset.
 3. Re-enter the **ent-ls** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2926 Cmd Rej: A problem occurred while trying to access the GWS database

Commands Used: chk-unref-ent, ent-ls, chg-ls

You may have an intermittent system problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2927 Cmd Rej: The linkset is provisioned locally

Commands Used: ent-slk

OAP attempted to provision GWS on a linkset that has GWS on it already through an EAGLE 5 ISS terminal.

Recovery

Re-enter the **ent-slk** command that generated this error message specifying the correct **slc** parameter value.

Call your Customer Care Center if this error message appears again.

E2928 Cmd Rej: The linkset specified is not a Gateway Linkset

Commands Used: ent-ls, chg-ls, rtrv-gtwy-acthresh, set-gtwy-acthresh

You specified the **gwsa**, **gwsn**, or **gwsd** parameters as active, but the linkset does not support these features.

Another possibility is that you used OAP **gtwy-ls** commands on a non-gateway linkset.

Recovery

Perform one of the following:

- Re-enter the command that generated this error message specifying **off** for the **gwsa**, **gwsm**, or **gwsd** parameters.

OR

- Re-enter the command that generated this error message without specifying the **gwsa**, **gwsm**, and **gwsd** parameters.

Call your Customer Care Center if this error message appears again.

E2929 Cmd Rej: The linkset specified does not exist in the linkset table

Commands Used: chg-ls, dlt-ls, rtrv-ls

You entered this command specifying an invalid **lsn** parameter value.

Recovery

1. Display a list of valid linkset names. Enter the **rtrv-ls** command.
2. Re-enter the command that generated this error message specifying the correct **lsn** parameter value.

Call your Customer Care Center if this error message appears again.

E2930 Cmd Rej: The Gateway Linkset specified already exists

Commands Used: ent-ls

The linkset name (**lsn**) parameter value must be unique.

Recovery

1. Display the linkset information. Enter the **rtrv-ls** command.
2. Re-enter the **ent-ls** command that generated this error message specifying the correct (unique) **lsn** parameter value.

Call your Customer Care Center if this error message appears again.

E2931 Cmd Rej: SEAS Gateway Screen Set Names cannot be changed locally**Commands Used: chg-1s**

You entered the command at an EAGLE 5 ISS terminal and tried to change a SEAS gateway linkset. Gateway linksets can be configured only from a OAP terminal and not from an EAGLE 5 ISS terminal.

Recovery

1. Display the linkset information. Enter the **rtrv-1s** command. The entries displayed as "SEAS" in the SCRN field were created at an OAP terminal and cannot be changed at an EAGLE 5 ISS terminal.
 2. Perform one of the following:
 - Re-enter the **chg-1s** command for a linkset with a name other than "SEAS" in the SCRN field of the output from step 1.OR
 - If a linkset for a SEAS screen set name must be changed, do so at an OAP terminal.
-

E2932 Cmd Rej: SEAS Gateway Linksets cannot be deleted locally**Commands Used: dlt-1s**

You entered the command at an EAGLE 5 ISS terminal and tried to delete a SEAS gateway linkset. Gateway linksets can be deleted only from an OAP terminal and not from an EAGLE 5 ISS terminal.

Recovery

1. Display the linkset information. Enter the **rtrv-1s** command. The entries displayed as "SEAS" in the SCRN field were created at an OAP terminal and cannot be deleted from an EAGLE 5 ISS terminal.
 2. Perform one of the following:
 - Re-enter the **dlt-1s** command for a linkset with a name other than "SEAS" in the SCRN field of the output from step 1.OR
 - If a linkset for a SEAS screen set name must be deleted, do so at an OAP terminal.
-

E2933 Cmd Rej: A specific SI must be specified in the range (0-15)

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`

You either failed to include the service identifier (**si**) parameter on the command line, or assigned a value to it that was out of range.

Recovery

Re-enter the command that generated this error message specifying the **si** parameter and correct range value.

Call your Customer Care Center if this error message appears again.

E2935 Cmd Rej: If SDATE=EDATE, then ETIME after or same as STIME

Commands Used: `rtrv-log`

You specified the start date (**sdate**) and end date (**edate**) for the same day (that is, **sdate=edate**), but you specified an end time (**etime**) that is before the start time (**stime**). If you specify the same start and end date, you must specify an end time that is the same as or later than the start time.

Recovery

Perform one of the following:

- Re-enter the command specifying a value for the **etime** parameter that is later than or the same as the value for the **stime** parameter. For example, you might enter

```
rtrv-log:sdate=961021:edate=961021:stime=130000:etime=140000
```

OR

- If you meant to enter different dates, re-enter the command specifying the correct values for the **edate** and **sdate** parameters.
-

E2936 Cmd Rej: SDATE+STIME must be before current date-time

Commands Used: `rtrv-log`

You specified a combination of start date (**sdate**) and start time (**stime**) that is later than the current date-time combination. The EAGLE 5 ISS does not allow you to specify a time in the future to retrieve logs.

Recovery

Re-enter the command specifying values for the **sdate** and **stime** parameters that are before the current date and time. For example, if today's date and time are 11:00 a.m., October 22, 1996, you must enter the **rtrv-log** command specifying a start date and start time combination that is before **sdate=961022** and **stime=110000**.

E2938 Cmd Rej: RTRV-LOG command already in progress**Commands Used: rtrv-log**

You tried to enter a retrieve log command while another retrieve log command was already in progress. The EAGLE 5 ISS does not allow two retrieve log commands to be in progress at the same time.

Recovery

Wait until the active retrieve log command finishes processing, and re-enter the command.

E2939 Cmd Rej: Unable to read the selected log**Commands Used: rtrv-log**

The EAGLE 5 ISS was unable to access the selected log.

Recovery

This error message indicates a potentially serious disk error.
Call your Customer Care Center.

E2940 Cmd Rej: Standby MASP is not available**Commands Used: rtrv-log**

You attempted to download the log of alarms from the standby maintenance and administration subsystem processor, by setting the **slog** parameter to **stb**.

Recovery

1. You are operating without a standby/backup system. Find out immediately why the standby MASP is not in operation.
 2. Bring the standby MASP back into service.
 3. If unable to bring the standby MASP back into service, call your Customer Care Center.
-

E2941 Cmd Rej: Invalid combination - EDATE with STIME**Commands Used:** `rtrv-log`

You specified the **stime** parameter and the **edate** parameter. The EAGLE 5 ISS does not allow this combination.

Recovery

Re-enter the `rtrv-log` command specifying another valid combination of the time (**stime/etime**) and date (**sdate/edate**) parameters.

Refer to the *Commands Manual* for valid combinations.

E2942 Cmd Rej: Failed reading/writing Extended Linkset Table**Commands Used:** `rtrv-gtwy-acthresh`, `set-gtwy-acthresh`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2943 Cmd Rej: Failed reading/writing Extended STP Options Table**Commands Used:** `rtrv-gtwy-prmtrs`, `set-scrrej-prmtrs`

You may have a hardware problem.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2944 Cmd Rej: Invalid INTRVL value specified

Commands Used: `set-gtwy-acthresh`, `set-scrrej-prmtrs`,
`set-uim-acthresh`

You assigned an invalid value to the `intrvl` parameter. Valid values are **5, 10, 15, 20, 25, 30**.

Recovery

Re-enter the command that generated this error message specifying a valid `intrvl` parameter value.

Call your Customer Care Center if this error message appears again.

E2945 Cmd Rej: Source database version is not compatible

Commands Used: `act-upgrade`

The removable cartridge did not contain source-release system data (GPLs and database).

Recovery

1. Enter the `act-upgrade:action=dbstatus` command to verify the version of the removable cartridge (MDAL). The version of the removable cartridge is shown in the VERSION STATUS field.
2. If the removable cartridge contains the source-release system data, re-enter the `act-upgrade` command.
Call your Customer Care Center if this error message appears again.
3. If the removable cartridge does not contain the source-release system data, remove the removable cartridge from the removable cartridge drive, and insert the removable cartridge that contains the source-release system data.
4. Re-enter the `act-upgrade` command.

Call your Customer Care Center if this error message appears again.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure completes.

E2946 Cmd Rej: No match on DESTFLD parameter during retrieve

Commands Used: `rtrv-scr-sio`

You set the `nsfi` parameter to the `destfld` value, but no match was found.

Recovery

Re-enter the `rtrv-scr-sio` command that generated this error message specifying a different `destfld` parameter value.

Call your Customer Care Center if this error message appears again.

E2947 Cmd Rej: No match on SCCPMT parameter during retrieve

Commands Used: `rtrv-scr-cgpa`

You set the SCCP Message Type parameter `sccpmt` to a value that did not match any of the screening references in the allowed calling party address (CGPA) entity set.

Recovery

Perform one of the following:

- Re-enter the `rtrv-scr-cgpa` command that generated this error message specifying another `sccpmt` parameter value.

OR

- Re-enter the `rtrv-scr-cgpa` command that generated this error message and omit the `sccpmt` parameter.

Call your Customer Care Center if this error message appears again.

E2948 Cmd Rej: No match on SCMGFID parameter during retrieve

Commands Used: `rtrv-scr-cdpa`

You entered this command specifying the SCCP management (SCMG) format ID parameter set to a value that does not exist in the screening reference.

Recovery

1. Enter the **rtrv-scr-cgpa** command without specifying the **scmgid** parameter, to acquire the current state of the parameter.
 2. Re-enter the **rtrv-scr-cgpa** command that generated this error message, using the appropriate **scmgid** parameter value acquired in step 1.
- Call your Customer Care Center if this error message appears again.
-

E2949 Cmd Rej: SNAME must be specified

Commands Used: **inh-alm**, **unhb-alm**

You attempted to inhibit an alarm on an application socket device, but you did not specify the required **sname** parameter value.

Recovery

Re-enter the command specifying the **sname** parameter value.

E2950 Cmd Rej: PORT parameter invalid for DEV selected

Commands Used: **inh-alm**, **unhb-alm**

The **port/link** parameter value you entered was not valid for the device you configured with the **dev** parameter. Valid choices are shown in Table 2-19:

Table 2-19. Valid **dev/port** Parameter Combinations

dev=	port=
dlk	a, b
lsmsq3	a1, a2, b1, b2
ndclk	a1, a2, b1, b2
seasx25	a1, a2, b1, b2
slk	a, b

Recovery

Re-enter the command that generated this error message specifying the correct **port** parameter value.

Call your Customer Care Center if this error message appears again.

E2951 Cmd Rej: LSN must be specified

Commands Used: `inh-a.lm`, `unhb-a.lm`

You failed to enter the required linkset name (**lsn**) parameter when you specified the **dev** parameter with a value of **ls**.

Recovery

Re-enter the command that generated this error message specifying the correct **lsn** parameter value.

Call your Customer Care Center if this error message appears again.

E2952 Cmd Rej: PORT must be specified

Commands Used: `inh-a.lm`, `unhb-a.lm`

You failed to include the **port** parameter when you specified the **dev** parameter with a value of **seasx25**, **ndclk**, or **lsmconn**. The valid range of values for the **port** parameter is as follows:

- a1** – EMDC A to EMAP A link
- a2** – EMAP A to NDC OS link
- b1** – EMDC B to EMAP B link
- b2** – EMAP B to NDC OS link

Recovery

Re-enter the command that generated this error message specifying the correct **port** parameter value.

Call your Customer Care Center if this error message appears again.

E2953 Cmd Rej: ID must be specified

Commands Used: `inh-a.lm`, `unhb-a.lm`

You failed to include the required **id** parameter when you specified the **dev** parameter with a value of **cdt**.

Recovery

Re-enter the command that generated this error message specifying the correct **id** parameter value.

Call your Customer Care Center if this error message appears again.

E2954 Cmd Rej: DEV state does not allow alarms to be inhibited

Commands Used: `inh-alm`

The device you selected was servicing an action command when you entered this command.

Recovery

Wait for the device to finish its action, then re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E2955 Cmd Rej: Network Routing is only valid if the NRT feature is ON

Commands Used: `chg-dstn`, `chg-rte`, `dlt-dstn`, `dlt-rte`,
`ent-dstn`, `ent-rte`, `rtrv-dstn`, `rtrv-rte`

You attempted to enter a network destination, but the NRT (network routing) feature has not been turned on.

NOTE: Once a feature is turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information. When using the Network Routing feature, limited network management is provided for point codes not covered by full point code routing, cluster routing, or nested cluster routing.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
2. If the NRT feature is turned on (NRT=on from the output of step 1), re-enter the command.

Call your Customer Care Center if this error message appears again.

3. If the NRT feature is off (NRT=off from the output of step 1), enter **chg-feat:nrt=on** to turn on NRT.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E2956 Cmd Rej: NCM must be * when using Network Routing

Commands Used: **chg-dstn, chg-rte, dlt-dstn, dlt-rte, ent-dstn, ent-rte, rtrv-dstn, rtrv-rte**

You entered a destination point code that has an invalid format for network routing. The destination point code for network routing must have a format of **dpc=ni-*-***. In other words, if you enter an asterisk (*) in the *nc* field, you must also enter an asterisk (*) in the *ncm* field (for example, **dpc=21-*-***).

Recovery

Re-enter the command, specifying a valid destination point code for network routing.

E2960 Cmd Rej: CHG-PID not allowed while in upgrade mode

Commands Used: **chg-pid**

You attempted to enter the **chg-pid** command while the system is in upgrade mode. This action is not allowed.

Recovery

1. Wait until the upgrade has completed.
 2. Re-enter **chg-pid** the command.
-

E2961 Cmd Rej: T<#> (domain) must be between <min> and <max>

Commands Used: **all commands**

You specified a timer number that is outside the range of acceptable timer numbers.

Recovery

Re-enter the command specifying a valid timer number that is within the minimum-maximum range of permissible timer values.

Refer to the *Commands Manual* for the correct format of the parameter.

Call your Customer Care Center if this error message appears again.

E2962 Cmd Rej: <device> is <condition>

Commands Used: `chg-db`, `copy-disk`, `copy-meas`, `copy-gpl`,
`format-disk`

The command cannot complete because it cannot write to the specified device (either a removable cartridge or fixed disk) for the reason described in the condition.

The following Recovery procedures list the variations of this error message and the appropriate corrective action to take.

Contact your Customer Care Center if this error message appears again.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge from the MDAL after the command or procedure completes

Recovery - Removable cartridge is not inserted

Insert a system disk for the current system release.

Recovery - Removable cartridge is not initialized

1. Enter the command:
`format-disk:type=system:force=yes`

Note: Specify `force=yes` to format a system removable cartridge that already contains data.

2. Re-issue `copy-gpl` or `chg-db`, as appropriate.
-

Recovery - Removable cartridge is not a system disk

Insert a system disk for the current system release.

Recovery - Removable cartridge is not a MEAS disk

1. Remove the system disk from the MDAL.
 2. Insert a MEAS disk for the current system release.
-

Recovery - Removable cartridge is inaccessible (internal problem)

Remove and re-install the MDAL and cartridge or a spare.

Recovery - Fixed disk is not inserted

Insert a fixed disk for the current system release.

Recovery - Fixed disk is not initialized

1. Enter the command:
`format-disk:type=fixed:loc=1114`
 2. Re-issue the `copy-disk` command.
-

Recovery - Fixed disk is inaccessible (internal problem)

Remove and re-install the MDAL and cartridge or a spare.

E2963 Cmd Rej: Cannot read DB Stat Table (<database>, <disk>, <MASP status>)

OR

Cmd Rej: Incorrect DB version (<database>, <disk>, <MASP status>)

OR

Cmd Rej: DB status is UPG 1 (<database>, <disk>, <MASP status>)

OR

Cmd Rej: DB is incoherent (<database>, <disk>, <MASP status>)

Commands Used: All database commands

A problem has been detected with the designated database:

- DB Stat table cannot be read
- DB version is incorrect
- DB status is UPG 1
- DB is incoherent
(‘Incoherent’ means that a previous database update was unsuccessful, leaving the coherency indicator unchanged; for more information on database coherency, see the *Database Administration Manual - System Management*).

The designation of the problem database is identified as:

- <database> **Curr DB** or **Bkup DB**
- <disk> **Fxd Disk** or **Rmv Disk**
- <MASP status> **Active MASP** or **Stby MASP**

Recovery

1. Determine the status of your database. Enter the command:
rept-stat-db:display=all
2. Re-enter the command that generated the error message.
Call your Customer Care Center if this error message appears again.

E2964 Cmd Rej: PVN conflicts with IP route dest or IP card local network**Commands Used: act-upgrade**

One of the following two conditions exists:

- The specified EAGLE 5 ISS PVN network address matches the destination network address of an IP static route on the IPLIMx and IPGWx cards.
OR
- The specified EAGLE 5 ISS PVN network address matches the network address of an ethernet interface of the IPGWx and IPLIMx cards in the source data base.

Recovery

1. Use the **chg-netopts** command to specify an EAGLE 5 ISS PVN network address in the source database,
 - that is not the same as the destination address of a IP static route,OR
 - that is not the same as the IP network address of the ethernet interface of an IPLIMx and IPGWx Card.
 2. Re-enter the **act-upgrade** command.
-

E2965 Cmd Rej: Too many parameters entered

Commands Used: inh-alm, rept-stat-alm, unhb-alm

Too many parameters were specified for the command.

Refer to the command description in the *Commands Manual* for valid parameters for the command.

OR

For the **rept-stat-alm** command, you specified the **dev** parameter, but did not specify the required **display** parameter.

Recovery **inh-alm, unhb-alm**

Re-enter the command that generated this error message specifying fewer parameters.

Refer to the **inh-alm** and **unhb-alm** commands in the *Commands Manual* for the valid parameter combinations.

Call your Customer Care Center if this error message appears again.

Recovery - **rept-stat-alm**

Re-enter the **rept-stat-alm** command specifying both the **dev** and **display** parameters.

E2966 Cmd Rej: TRM must be specified

Commands Used: `chg-secu-trm`, `chg-trm`, `rmv-trm`, `inh-alm`,
`inh-trm`, `rst-trm`, `unhb-alm`

You entered the command without specifying the mandatory **trm** parameter. For **inh-alm** and **unhb-alm** specifically, it is the **dev=trm** parameter that requires that you also specify the **trm** parameter.

Recovery

Re-enter the command that generated this error message, and include the **trm** parameter.

Call your Customer Care Center if this error message appears again.

E2967 Cmd Rej: Active OAM database is incoherent

Commands Used: `all commands`

The database was found to be incoherent, which means that a previous database update was unsuccessful, leaving the coherency indicator unchanged. During the subsequent attempted execution of an upgrade procedure, an error was detected when either of the following was issued: `act-upgrade:action=converttoam` or `act-upgrade:action=convertstp`

Recovery

1. Consult the *Upgrade Procedures* document for the target upgrade.
Refer to the relevant Recovery Procedure section in that document for instructions.
 2. Follow the instructions for recovering from the upgrade procedure error.
Those instructions will direct you to back out of the upgrade mode.
After returning to full-function mode in the source release, follow instructions in the *Database Administration Manual – System Management* to fix the problem with database incoherence.
Call your Customer Care Center if this error message appears again.
-

E2968 Cmd Rej: FORCE=YES is required to isolate card from IMT**Commands Used: `disc-imt`**

The command was entered, but was unsuccessful in isolating the card from the specified IMT bus. In a situation where a card is already disconnected from one IMT bus and the command is asking to remove the card from the other bus, the **force** parameter is required.

Recovery

Re-enter the **disc-imt** command specifying the **force=yes** parameter to disconnect a specific card from the IMT bus.

Call your Customer Care Center if this error message appears again.

E2969 Cmd Rej: Unable to determine current connect status of card <card>**Commands Used: `all commands`**

In response to a query, the connect status of the specified card cannot be determined.

Recovery

1. Verify that you typed the command correctly.
 2. Make any necessary corrections, and then re-enter the command.
Refer to the *Commands Manual* for information regarding the correct command usage.
Call your Customer Care Center if this error message appears again.
-

E2970 Cmd Rej: Action requires ICNP feature to be configured**Commands Used: `rept-meas`**

You attempted an action that requires the IntraCarrier Number Portability and IN Triggers feature to be configured.

Recovery

1. Display the features in the system. Enter the **rtrv-ctrl-feat** command.
2. If the feature has been purchased and installed in your system verify its status.

Refer to the *Database Administration Manual - System Management* for instructions on enabling and turning on, and configuring the IntraCarrier Number Portability and IN Triggers feature and any prerequisite features that must be turned on.

3. When the feature is turned on in the system, re-enter the **rept-meas** command specifying the parameter that requires the ICNP feature to be on. Call your Customer Care Center if this error message appears again.
-

E2971 Cmd Rej: System busy - Repeat later

Commands Used: all OAP commands

A system-busy error can result from either:

- Heavy disk activity (resulting from database maintenance or measurement collection) is preventing access to the system.
- OR
- A conflict between two action commands has occurred. If you enter an action command while another action command is in progress, your command cannot execute.

An action command is a command that changes the state of entities within the EAGLE 5 ISS. For more information, refer to the *Commands Manual*.

Recovery

1. Wait until the disk activity subsides or the action command completes.
 2. Re-enter the command that generated this error message.
- Call your Customer Care Center if this error message appears again.
-

E2972 Cmd Rej: Specified Port is not valid for Card and Appl Type

Commands Used: **act-lpo, act-slk, alw-slk, blk-slk, canc-lpo, canc-slk, dact-slk, ent-slk, inh-slk, rept-stat-slk, rtrv-slk, ublk-slk**

You specified a signaling port that is not supported on the card type in the location that you specified. If you specify port **a1, b1, a2, b2, a3, or b3**, the card must be one of the following types:

- A multi-port LIM with card type **limds0** and application **ss7ansi**.
- An E1/T1 MIM card with card type **lime1, limt1, or limch** and application **ss7ansi** or **ccs7itu**.

- A DCM card with card type DCM and application IPLIM or IPLIMI.
- A SSEDCCM card, with application **iplim** or **iplimi**, and **ipliml2=saaltali**, **m2pa**, or **m3ua**. (Note: message E2972 appears with 'E2976 Card does support more than 2 Links').

Links **a4-a31** and **b4-b31** can be specified only when the card type is **lime1** or **limt1** for an HC-MIM card and the **appl** type is **ss7ansi** or **ccs7itu**.

Recovery

Re-enter the command specifying a valid port for the card type and application.

E2973 Cmd Rej: If specified, BPS must be 56000 for Multi Port LIM

Commands Used: **ent-s1k**

You entered a **bps** value that is not valid for a multi-port LIM or an E1/T1 MIM used as a T1 card. Multi-port LIMs and T1 cards support **bps=56000** links only.

Recovery

Re-enter the **ent-s1k** command for the multi-port LIM specifying **bps=56000**.

E2974 Cmd Rej: BPS must be 56000 for all ports on Multi Port LIM

Commands Used: **ent-s1k**

You entered a **bps** value that is not valid for a port on a multi-port LIM. All ports on multi-port LIMs support **bps=56000** links only.

Recovery

Re-enter the **dlt-mrn** command for the multi-port LIM specifying **bps=56000**.

E2976 Cmd Rej: Card does not support more than 2 Links

Commands Used: `alw-slk`, `act-lpo`, `act-slk`, `blk-slk`, `canc-lpo`, `canc-slk`, `dact-slk`, `dlt-slk`, `ent-slk`, `inh-alm`, `inh-slk`, `rept-stat-slk`, `rtrv-slk`, `ublk-slk`, `unhb-alm`, `unhb-slk`

You specified a signaling link that is not supported on the card that is running. If you specify port **a1**, **b1**, **a2**, **b2**, **a3** or **b3**, the card that is running must be one of the following cards:

- A multi-port LIM (card type **limds0** and application **ss7ansi**). or
- An E1/T1 MIM (card type **lime1**, **limt1**, or **limch** and application **ss7ansi** or **ccs7itu**), or
- A DCM card with card type **dcm** and application **iplim** or **iplimi**, or
- A SSEDCCM card, with application **iplim** or **iplimi**, and **ipliml2=saaltali**, **m2pa**, or **m3ua**. (Note: message E2976 is displayed whenever 'E2972 Specified Port is not valid for Card and Appl Type' appears).

Only port **a** or port **b** can be specified for 2-port cards running **ss7ansi** and **ccs7itu** applications.

Links **a4-a31** and **b4-b31** can be specified only when the card type is **lime1** or **limt1** for an HC-MIM card and the **appl** type is **ss7ansi** or **ccs7itu**.

Recovery

Re-enter the command specifying a port that is valid for the card that is running.

E2977 Cmd Rej: Cannot leave a solitary PC in group

Commands Used: `dlt-mrn`

You entered a command that would delete all but one point code in a group. If deleting one or more point codes from the group would leave only one point code in the group, you must delete the entire group.

Recovery

1. Display the group of point codes that contains the point codes to be deleted. Enter the `rtrv-mrn` command. Verify that the command would leave only one point code in the group.
 2. Re-enter the command specifying the **all=yes** parameter with the point code parameter value for one of the point codes in the group. This will delete the entire group.
-

E2978 Cmd Rej: RC is required if no other optional parameters are provided**Commands Used: chg-mrn**

You specified only the point code (**pc**) parameter. The relative cost (**rc**) parameter must also be entered if you enter no other optional parameters in the command.

Recovery

Re-enter the **chg-mrn** command specifying the **pc** parameter and its relative cost (**rc**) parameter or other optional parameters.

E2979 Cmd Rej: Cannot enter the same PC more than once**Commands Used: chg-mrn, ent-mrn**

The specified point code parameter value already exists in the table.

Recovery

1. Display the point codes currently in the MRN table. Enter the **rtrv-mrn** command.
 2. Re-enter the command specifying a point code parameter value that does not appear in the output from step 1.
-

E2980 Cmd Rej: Must be in upgrade phase 3 or full function mode**Commands Used: init-network**

You entered the command and the EAGLE 5 ISS was not in *Upgrade Phase 3* mode or *Full Function* mode. *Upgrade Phase 3* mode means that the MASPs are running GPLs that match the major revision defined for the approved GPLs, but the other network processors are only *prepared* to be upgraded. *Full Function* mode means that all MASPs are running GPLs that match the major revision defined for the approved GPLs. *Full Function* mode is the normal operating mode for the MASP.

Recovery

1. Contact your Customer Care Center for assistance in using this command.
 2. When instructed to do so by the Customer Care Center, re-enter the **init-network** command.
-

E2981 Cmd Rej: Already in nodal isolation**Commands Used: `init-network`**

You entered the command, and the EAGLE 5 ISS detected that there were no in-service active links. The `init-network` command requires that at least one `ss7ansi` or `ccs7itu` card must exist with an in-service active link.

Recovery

1. Return the inhibited signaling link(s) to service. Enter the `alw-slk` command.
 2. Restore the card to IS-NR (in-service normal). Enter the `rst-card` (or `alw-card`) command.
 3. Verify that the card(s) are in service. Enter the `rept-stat-card` command.
 4. Re-enter the `init-network` command.
-

E2982 Cmd Rej: Database is incoherent**Commands Used: `init-network`**

The database is incoherent, which means that a previous database update was unsuccessful, thereby leaving the coherency indicator unchanged.

For more information on database coherency, see the *Database Administration Manual – System Management*.

Recovery

Verify the operational status of the EAGLE 5 ISS database. Enter the `rept-stat-db` command.

- If the current partition of the fixed disk is coherent and the back up partition of the fixed disk is incoherent, create a backup copy of the database on the fixed disk. Enter the following command:
`chg-db:action=backup:dest=fixed`
- If the current partition of the fixed disk is coherent and the database on the removable cartridge is incoherent, create a backup copy of the database to the removable cartridge. Enter the following command:
`chg-db:action=backup:dest=remove`
- If the backup partition of the fixed disk is coherent and the current partition of the fixed disk is incoherent, restore the database from the backup partition of the fixed disk. Enter the following command:
`chg-db:action=restore:src=fixed`

- If the database on the removable cartridge is coherent and the current partition of the fixed disk is incoherent, restore the database from the removable cartridge. Enter the following command:
chg-db:action=restore:src=remove
 - If the backup and current partitions on the active TDM are coherent and the backup and current partitions on the standby TDM are incoherent, repair the database. Enter the following command:
chg-db:action=repair
-

E2984 Cmd Rej: SRM or MRC cannot be entered for a solitary entry

Commands Used: **ent-map**

You cannot specify a solitary application and the Control of Subsystem Routing Messages (**srm**) parameter or the Control of Message Routing Under Congestion (**mrc**) parameter. This combination is not allowed. The **srm** or **mrc** parameters cannot be specified for a solitary **pc/ssn** pair entry.

Recovery

Perform one of the following:

- If a solitary application is desired, re-enter the **ent-map** command without specifying the **srm** or **mrc** parameters.

OR
 - If a solitary application is not desired, re-enter the **ent-map** command specifying the **srm** and **mrc** parameters.
-

E2985 Cmd Rej: Mate Relative Cost (MateRC) required if MPC/MSSN is entered

Commands Used: **ent-map**

If a mate subsystem number (**mssn**) parameter or mate point code (**mpc**) parameter is specified, the relative cost (**materc**) parameter must be specified.

Recovery

Re-enter the **ent-map** command specifying the **mpc**, **mssn**, and **materc** parameters.

E2986 Cmd Rej: Relative Cost (RC) is required for PC/SSN and MPC/MSSN

Commands Used: `ent-map`

If the `pc/ssn` and `mpc/mssn` parameter pairs are specified, the `rc` parameter must be specified.

Recovery

Re-enter the `ent-map` command specifying the `pc/ssn` and `mpc/mssn` parameter pairs and the relative cost (`rc`) parameter.

E2987 Cmd Rej: Subsystem Relative Cost (RC) must be less than its mate

Commands Used: `ent-map`, `chg-map`

You specified a value for the relative cost (`rc`) parameter for a true point code that is greater than at least one mated subsystem of the group.

Recovery

Re-enter the command specifying a relative cost (`rc`) parameter value for the true point code that is less than at least one mated subsystems in the group.

E2988 Cmd Rej: Maximum number of Mated Applications (MAP) exceeded

Commands Used: `chg-map`

You entered a command that would result in more than the eight mated applications that are allowed.

Recovery

Delete an existing mated application and re-enter the `chg-map` command for the new mated application.

OR

Enter the mated application as a new primary point code.

E2989 Cmd Rej: For Mate Point Code (MPC), MSSN, Materc, RC must be provided**Commands Used: ent-map**

You cannot specify the **mpc** parameter without specifying the **mssn**, **materc**, and **rc** parameters. If the **mpc** parameter is specified, the **mssn**, **materc**, and **rc** parameters must also be specified.

Recovery

Re-enter the **ent-map** command specifying the **mpc**, **mssn**, **materc** and **rc** parameters.

E2990 Cmd Rej: Relative Cost (RC) of true PC must be less than RC of mate**Commands Used: chg-map, ent-map**

You specified the relative cost (**rc**) parameter value for a true point code that is greater than the relative cost for its mate. If the **pc** parameter value is an EAGLE 5 ISS true point code, the subsystem must have a lower relative cost than all other mated subsystems in the group.

Recovery

Re-enter the command specifying a value for the **rc** parameter for the true point code that is less than the relative cost for its mate.

E2991 Cmd Rej: Relative Cost (RC) of true MPC must be less than RC of mate**Commands Used: ent-map**

You specified the **materc** parameter value for a true mated point code greater than the relative cost of its mate.

Recovery

Re-enter the **ent-map** command specifying the **mpc** and **materc** parameter values so that the relative cost of the mated point code is less than the relative cost of its mate.

E2992 Cmd Rej: Mate parameters: MPC, MSSN, MaterC are required together**Commands Used: chg-map**

The **mpc**, **mssn**, and **materc** parameters must be specified together in the command.

Recovery

Re-enter the **chg-map** command specifying values for the **mpc**, **mssn**, and **materc** parameters.

E2993 Cmd Rej: Map entry must be solitary**Commands Used: ent-map**

You specified parameters that would create more than one MAP entry. The MAP entry must be solitary.

Recovery

Re-enter the **ent-map** command without specifying the **mpc**, **mssn**, and **materc** parameters, to create a solitary MAP entry.

E2994 Cmd Rej: True Point Code may not be routed to self**Commands Used: chg-map**

You specified parameters that would route the true point code to itself. A true point code cannot be routed to itself.

Recovery

Re-enter the **chg-map** command specifying different values for the **pc** and **mpc** parameters.

E2995 Cmd Rej: True Point Code can only have one mate**Commands Used: chg-map**

You entered the command that would result in more than one mate for a true point code. A true point code can have only one mate.

Recovery

If you want to change the mate of the true point code, delete the current mate and re-enter the **chg-map** command to enter the new mate.

E2996 Cmd Rej: Intermed GTT Load sharing feature must be on

Commands Used: **chg-mrn**, **ent-mrn**

You entered the command to add, change, or delete an entry in the Mated Relay Node (MRN) table. The Intermediate Global Title Translation Load Sharing (IGTTLS) feature must be turned on before you can use this command.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.
2. Verify that the IGTTLS feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the IGTTLS feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

NOTE: Before the IGTTLS feature can be turned on, the GTT feature must be turned on (see the **chg-feat** command) and every SCCP card in the system must have at least a 586 processor.

4. Turn on the IGTTLS feature. Enter the **chg-ctrl-feat:igttls=on** command.

Refer to the *Commands Manual* and the *Database Administration Manual - Global Title Translation* for more information about turning on the IGTTLS feature.

5. When the IGTTLS feature is turned on, re-enter the command that generated this error message.
-

E2997 Cmd Rej: PC must match NPCFMTI set in CHG-STPOPTS

Commands Used: **chg-mrn**, **dlt-mrn**, **ent-mrn**

You entered the command to add, change, or delete the entry for a point code or alternate point code in the Mated Relay Node (MRN) table. The format of the point code in the parameter value does not match the format defined for the system using the **chg-stpopts** command **npcfnti** parameter.

Refer to the **chg-stpopts** command description in *Commands Manual* for **npcfnti** parameter values.

Recovery

1. Display the current settings of the STP options in your system. Enter the **rtrv-stpopts** command. Verify the value for **npcfmti** in the output.
 2. Re-enter the command specifying the point code or alternate point code parameter value in the format indicated by the **npcfmti** setting in the output from step 1.
-

E2998 Cmd Rej: PC cannot match the SID

Commands Used: **chg-mrn, chg-sccp-serv, ent-mrn**

You entered a command to add or change a point code entry in the Mated Relay Node table, and the specified point code is the same as the EAGLE 5 ISS site identifier (SID). This is not allowed.

Recovery

1. Display the current SID. Enter the **rtrv-sid** command.
 2. Re-enter the command specifying parameters for a point code that is not the same as the SID.
-

E2999 Cmd Rej: Failed reading the MRN table

Commands Used: **chg-gta, chg-gtt, chg-mrn, dlt-mrn, ent-gta, ent-gtt, ent-mrn, rtrv-mrn, chg-sccp-serv, dlt-sccp-serv, rtrv-sccp-serv**

The Mated Relay Node (MRN) table is corrupt or cannot be found by the system. The MRN table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3000 Cmd Rej: DPC is referenced by SCCP in MRN table or SCCP Serv table**Commands Used: `dlt-dstn`**

You cannot delete a Destination Point Code (DPC) that is referenced by an SCCP as a point code in the Mated Relay Node (MRN) table. You cannot delete a DPC that is present in either the MRN table or the SCCP SEV table.

Recovery

1. Display the point codes in the MRN table. Enter the `rtrv-mrn` command.
 2. Before you can delete the DPC from the destination entity, you must delete the point code from the MRN table or the SCCP SEV table. Enter the `dlt-mrn` command.
 3. Verify that the DPC to be deleted is in the MRN table or the SCCP SEV table. Enter the `rtrv-mrn` command.
 4. Delete the DPC from the Destination table. Re-enter the `dlt-dstn` command.
-

E3001 Cmd Rej: SDATE must be earlier or equal to EDATE**Commands Used: `rtrv-log`, `rtrv-secu log`**

If you specify both the `sdate` and `edate` parameters, the date you specify for the start date (`sdate`) parameter must be earlier than or equal to the date specified for the end date (`edate`) parameter.

Recovery

Re-enter the command specifying a new date for the `sdate` parameter (in the form `yyymmdd`, where `yy` is year, `mm` is month, and `dd` is day) that is earlier than the date specified for the `edate` parameter.

E3002 Cmd Rej: STIME must be earlier or equal to ETIME**Commands Used: `rtrv-secu log`**

If you specify both the start time (`stime`) and end time (`etime`) parameters, the time you specify for the `stime` parameter must be earlier than or equal to the time specified for the `etime` parameter.

Recovery

Re-enter the **rtrv-secu** command specifying a new time for the start time (**stime**) parameter (in the form **hhmmss**—**hh**=hours (00-23), **mm**=minutes (00-59), **ss**=seconds (00-59)) that is earlier than the time specified for the end time (**etime**) parameter.

E3003 Cmd Rej: Modification of security log not allowed

Commands Used: **copy-fta**, **copy-tbl**

You cannot specify the values (170, 500 or 502) for the source table (**stbl**) parameter, the destination table (**dtbl**) parameter, or both.

Recovery

Re-enter the command specifying values other than (170, 500 or 502) for the **stbl** and/or **dtbl** parameters.

E3004 Cmd Rej: Un-uploaded security log entries exist on standby fixed disk

Commands Used: **copy-disk**, **format-disk**

You entered the command to copy the contents of the active fixed disk to the standby fixed disk, and the system determined that the standby fixed disk security log contains un-uploaded entries. The standby fixed disk cannot be initialized while un-uploaded security log entries exist on the standby fixed disk.

Recovery

1. Display pertinent information about the security log on the active and standby fixed disks. Enter the **rept-stat-secu** command. The **ENTRIES** field shows the number of un-uploaded commands currently recorded in the log.
 2. Copy the log from the standby fixed disk to the active fixed disk's file transfer area (FTA) and reset the **ENTRIES** field to 0 (zero). Enter the **copy-seculog:slog=stb** command.
 3. Re-enter the **copy-disk** command.
-

E3005 Cmd Rej: Security log command already in progress

Commands Used: `copy-secu``log`, `rept-stat-secu``log`, `rtrv-secu``log`

You cannot enter a security log command while another security log command is already in progress. The system does not allow two security log commands to be in progress at the same time.

Recovery

Wait until the active security log command finishes processing and re-enter the command.

E3007 Cmd Rej: Specified UID is reserved for system use

Commands Used: `ent-user`

You cannot specify a user ID that is reserved for system use. The user IDs “**seas**” and “**none**” are both reserved for system use.

Recovery

Re-enter the `ent-user` command specifying a valid user ID other than “**seas**” or “**none.**”

E3008 Cmd Rej: Failed reading the security log attributes table

Commands Used: `chg-attr-secu``log`

The Security Log Attributes table is corrupt or cannot be found by the system.

Recovery

Re-enter the `chg-attr-secu``log` command that generated this error message.
Call your Customer Care Center if this error message appears again.

E3009 Cmd Rej: LNP feature must be ON

Commands Used: `chg-acg-noc`, `chg-db`, `chg-feat`, `chg-lnp-serv`, `chg-cmd`, `chg-lnpopts`, `chg-map`, `chg-measopts`, `chg-oap-config`, `chg-secu-trm`, `chg-sid`, `chg-ss-appl`, `chg-user`, `dlt-lnp-serv`, `dlt-ss-appl`, `enable-ctrl-feat`, `ent-card`, `ent-lnp-serv`, `ent-map`, `ent-ss-appl`, `ent-user`, `rept-ftp-meas`, `rept-meas`, `rept-stat-lnp`, `rept-stat-lsms`, `rst-card`, `rtrv-cmd`, `rtrv-cmdclass`, `rtrv-lnp-serv`, `rtrv-lnpopts`, `rtrv-sid`, `rtrv-ss-appl`

The LNP feature (refer to the `enable-ctrl-feat` command) must be turned on for you to perform the following actions:

- Alter the LNP database
- Enter `ent-card:appl=ebdablm` or `ent-card:appl=ebdadcm`
- Enter `chg-feat:wnp=on` or `chg-feat:plnp=on`
- Retrieve or report on LNP information or measurements

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command and `rtrv-ctrl-feat` command.
2. If the LNP feature is turned on (from the output of step 1 - LNP ported TNs = on), re-enter the command.
Call your Customer Care Center if this error message appears again.
3. If the LNP feature is turned off (from the output of step 1 - the LNP ported TNs entry does not appear in the `rtrv-ctrl-feat` output), turn it on. Enter the `enable-chg-feat` command.
Refer to the "Activating the LNP Feature" procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting this process.
4. If required, reset the terminal, terminal command class, and user ID privileges.

Refer to the *Database Administration Manual - System Management* for these procedures.

5. Re-enter the command that generated this error message.
-

E3012 Cmd Rej: LNP subsystem is offline in database

Commands Used: `alw-map-ss`

You cannot run this command while the LNP subsystem is offline in the database.

Recovery

1. Activate the LNP subsystem. Enter the `chg-ss-appl:appl=lnp:nstat=online` command.
 2. Re-enter the `alw-map-ss` command that generated this error message.
-

E3014 Cmd Rej: Card location specified must be an SCCP card

Commands Used: `rept-stat-mps`, `rept-stat-lnp`, `rept-stat-sccp`

The specified `loc` parameter is invalid for the card location.

- For the `rept-stat-sccp` command, the TSM card must be an SCCP card or the DSM card must be a VSCCP card.
- For the `rept-stat-mps` command, the DSM card must be a VSCCP card.

Recovery

1. Display the cards and their identifying information. Enter the `rtrv-card` command. SCCP cards are shown by the entries TSM in the TYPE field and SCCP in the APPL field in the `rtrv-card` command output. VCCP cards are shown by the entries DSM in the TYPE field and VSCCP in the APPL field.
 2. Perform one of the following actions:
 - Re-enter the command specifying a valid card location obtained in step 1.
 - OR
 - Re-enter the command without specifying the `loc` parameter.
-

E3015 Cmd Rej: Cannot delete the last route to a DPC referenced in either the MRN table or the SCCP SERV table

Commands Used: `dlt-rte`, `dlt-dstn`

You entered a command that specified a route to a destination point code (DPC) that is the last route to that point code, and the point code still exists in the Mated Relay Node (MRN) table. You cannot delete the last route to a point code that is present in either the MRN table or the SCCP SERV table.

Recovery

1. To delete the specified route, you must first delete the point code from the MRN table or the SCCP SEV table. Enter the `dlt-mrn` command.
 2. When point code has been deleted from the MRN table or the SCCP SEV table, re-enter the command to delete the specified route.
-

E3017 Cmd Rej: SCCP card must have at least 586 processor

Commands Used: `chg-ctrl-feat`

Before you can turn on the Intermediate Global Title Translation Load Sharing (IGTTLS) feature, all SCCP cards in the system must have at least a 586 processor. If one or more SCCP cards in the system has less than a 586 processor, you cannot turn on the IGTTLS feature.

Recovery

1. Verify the processor on each SCCP card. Enter the `rtrv-card` command.
 2. If any SCCP cards have processors less than 586, you must replace those SCCP cards before you can turn on the IGTTLS feature.
 3. When all SCCP cards have at least 586 processors, re-enter the `chg-ctrl-feat:partnum=893xxxxxx:status=on` command specifying the correct 9-digit part number for the IGTTLS feature.
-

E3018 Cmd Rej: SSNE should be greater than SSN

Commands Used: `ent-rmt-appl`, `dlt-rmt-appl`

The value specified for the `ssne` parameter is less than or equal to the value of the `ssn` parameter.

Recovery

Re-enter the command specifying a value for the **ssn** parameter that is less than the value of the **ssne** parameter. Omit the **ssne** parameter if only one value is desired.

Call your Customer Care Center if this error message appears again.

E3019 Cmd Rej: Conflicts with existing entry

Commands Used: `dlt - /ent - rmt - appl`

Several conditions cause this error:

- You entered a point code of the same network type (ANSI/ITUI/ITUN) that does not match the point code already in the Remote Application table for that type.
- The point codes match, but the **si** value is already present (except when **si=3**).
- The point code matches, **si=3**, and one or more subsystem numbers **s** already entered overlap the range specified by the **ssn** and **ssne** parameter values.

Recovery

1. View which entries in the Remote Application table conflict with the failed command. Enter the `rtrv - rmt - appl` command.
2. Re-enter the `ent - rmt - appl` command specifying parameter values that do not conflict with existing the entry.

Call your Customer Care Center if this error message appears again.

E3020 Cmd Rej: Remote Application not found

Commands Used: `dlt - rmt - appl`

To delete a remote application entry, the **ipc**, **si**, and **ssn...ssne** parameter values must all match a values that are in the Destination table.

The command will fail if any of these conditions are not true.

Recovery

Re-enter the **dlt-rmt-app1** command making sure the values specified for the **ipc**, **si**, and **ssn...ssne** parameters all match a value in the Destination table.

Call your Customer Care Center if this error message appears again.

E3031 Cmd Rej: MULTCC entry cannot be NONE

Commands Used: **chg-gsmopts**

You cannot specify a value of **none** for the **multcc** parameter (**multcc=none**).

Recovery

Perform one of the following:

- Re-enter the **chg-gsmopts** command specifying a value other than **none** for the **multcc** parameter.

OR

- Reset the value specified for the **multcc** parameter. Enter the following command: **chg-gsmopts:multcc=xxx:nmultcc=none**
-

E3040 Cmd Rej: <reserved word> cannot be used in this command <reserved name> = reserved word

Commands Used: **Any command that has a reserved word**

You cannot specify a value for a parameter that is a reserved word for another parameter for the entered command. Reserved words (for example, "none") cannot be used to name a group.

Recovery

Re-enter the command specifying a value that is not a reserved word.

Refer to the *Commands Manual* for information about reserved words for the entered command.

Call your Customer Care Center if this error message appears again.

E3041 Cmd Rej: Timeout

Commands Used: `all commands`

A timeout occurred before or during the processing of a command.

Recovery

Re-enter the command specifying appropriate corrections.

If necessary, consult the *Commands Manual* for the correct command format.

Call your Customer Care Center if this error message appears again.

E3042 Cmd Rej: Command Response Timeout, freeing up scroll area

Commands Used: `Any command`

While in keyboard send/receive (KSR) mode, you entered a command but received no response from the OAM card.

Recovery

Re-enter the command that generated this error message.

Verify that your terminal settings for peripheral devices such as printers and display terminals match the system terminal settings, as described under "Dependencies" for the `chg-trm` command in the *Commands Manual*.

Call your Customer Care Center if this error message appears again.

E3043 Cmd Rej: IMT fault test in progress

Commands Used: `alw-imt, conn-imt, disc-imt, inh-imt, init-mux, rmv-imt, rst-imt`

The command was entered while an IMT fault isolation test was in progress, which is not allowed.

Recovery

Perform one of the following actions:

- Wait until the IMT fault isolation test is complete, then re-enter the command.
- OR
- If the **disc-imt** command was entered, re-enter the **disc-imt** command specifying the **force=yes** parameter. The **force=yes** parameter allows a card to be disconnected from the IMT bus being tested.
-

E3044 Cmd Rej: Invalid parameter specified for report type

Commands Used: **rept-imt-info**

You cannot specify the **report=util** parameter and either the **mode**, **erronly**, **sbucket**, and **ebucket** parameters. This parameter combination is not allowed. The **mode**, **erronly**, **sbucket**, and **ebucket** parameters can be specified only when the **report=err** parameter is specified.

Recovery

Perform one of the following actions:

- Re-enter the **rept-imt-info** command specifying the **report=err** parameter and either the **mode**, **erronly**, **sbucket**, and **ebucket** parameters.
- OR
- Re-enter the **rept-imt-info** command specifying the **report=util** parameter without specifying the **mode**, **erronly**, **sbucket**, and **ebucket** parameters.
-

E3045 Cmd Rej: Alternate bus must be IS-NR

Commands Used: **tst-imt**

Before you can test the IMT bus using the **tst-imt** command, the state of the alternate IMT bus must be IS-NR state.

Recovery

1. Verify the state of the IMT buses. Enter the **rept-stat-imt** command.
 2. Re-enter the **tst-imt** command specifying the IMT bus that is OOS-MT-DSBLD (out-of-service maintenance-disabled). This is shown in the PST field of the output of step 1.
-

E3046 Cmd Rej: Target bus must be inhibited

Commands Used: **tst-imt**

The state of the IMT bus being tested is not OOS-MT-DSBLD (out of service maintenance disabled).

Recovery

1. Verify the state of the IMT buses with the **rept-stat-imt** command. The state of the IMT bus is shown in the PST field of the **rept-stat-imt** command output.
 2. If the state of one of the IMT buses is OOS-MT-DSBLD, re-enter the **tst-imt** command specifying the IMT bus that is OOS-MT-DSBLD.
 3. If the state of both IMT buses is not OOS-MT-DSBLD, place the IMT bus you wish to test out of service with the **rmv-imt** command.
 4. Re-enter the **tst-imt** command specifying the IMT bus placed out of service in step 3.
-

E3047 Cmd Rej: Parameter combination invalid

Commands Used: **ent-e1**, **chg-e1**, **clr-imt-stats**, **rept-imt-lvl1**, **rept-imt-lvl2**, **rtrv-gttset**

The command was entered with an invalid combination of parameters.

For the **rtrv-gttset** command, if the GTT Set name (**gttsn**) parameter is specified, the **settype** or **netdom** parameters cannot be specified.

Recovery **clr-imt-stats**, **rept-imt-lvl1**, **rept-imt-lvl2**

Re-enter the command specifying either the **s** and **e** parameters or **sloc** and **eloc** parameters.

Recovery chg-e1, ent-e1

If the **linkclass=unchan** parameter is specified:

- **chanbrdg=on** or **cas=on** are not valid parameters.
 - the **minsurate** parameter is only valid when **linkclass=unchan**.
-

Recovery rtrv-gttset

Re-enter the **rtrv-gttset** command specifying the **gttsn** parameter without specifying the **settype** and **netdom** parameters.

E3048 Cmd Rej: Starting address/location must be specified

Commands Used: **clr-imt-stats**, **rept-imt-1v11**

The command was entered without the starting IMT address(es) or starting card location (**sloc**) parameters.

Recovery

Re-enter the command specifying either the **s** or **sloc** parameters.

E3049 Cmd Rej: Ending bucket cannot be less than starting bucket

Commands Used: **rept-imt-info**

The value of the ending bucket (**ebucket**) parameter was less than the value of the starting bucket (**sbucket**) parameter.

Recovery

Re-enter the **rept-imt-info** command specifying a value for the **ebucket** parameter that is greater than the value of the **sbucket** parameter.

E3050 Cmd Rej: L parameter cannot be used in combination with LOC

Commands Used: **rept-imt-1v12**

The command was entered with both the **l** and **loc** parameters. This combination is not allowed.

Recovery

Re-enter the **rept-imt-1v12** command specifying either the **l** or **loc** parameter, but not both.

E3051 Cmd Rej: Source address/location must be specified

Commands Used: **rept-imt-1v12**

The command was entered without specifying the source IMT address (**l**) parameter or the source card location (**loc**) parameter.

Recovery

Re-enter the **rept-imt-1v12** command specifying either the **l** or **loc** parameter.

E3052 Cmd Rej: IMT statistics collection in progress - Repeat later

Commands Used: **clr-imt-stats, init-flash, init-imt-gpl, init-mux, rept-imt-info, rept-imt-1v11, rept-imt-1v12, tst-imt**

The command was entered when the system was collecting the Interprocessor Message Transport (IMT) statistics for the hourly performance monitoring report.

Recovery

Wait for the system to finish collecting the IMT statistics, then re-enter the command.

- If IMT errors are found during the collection process, the hourly performance monitoring report is generated and the collection process has finished. When the hourly performance monitoring report is generated, re-enter the command.
 - If no IMT errors are found during the collection process, the hourly performance monitoring report is not generated. In this case, wait five minutes, then re-enter the command.
-

E3053 Cmd Rej: Failed reading ACG NOC table

Commands Used: `chg-acg-noc`, `dlt-acg-noc`, `ent-acg-noc`,
`rtrv-acg-noc`

The Automatic Call Gapping (ACG) Node Overload Control (NOC) table is corrupt or cannot be found by the system. The ACG NOC table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3054 Cmd Rej: The specified overload level is not defined

Commands Used: `chg-acg-noc`, `dlt-acg-noc`

You attempted to adjust or change an overload level other than those that are currently defined. The specified overload level must be defined.

Recovery

1. Display a list of all currently defined overload levels. Enter the `rtrv-acg-noc` command.
 2. Repeat the command specifying one of the overload levels from step 1.
-

E3055 Cmd Rej: Failed reading ACG MIC table

Commands Used: `ent-acg-mic`

The Automatic Call Gapping (ACG) Manually Initiated Control (MIC) table is corrupt or cannot be found by the system.

Recovery

Re-enter the `ent-acg-mic` command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3056 Cmd Rej: Parameters ND, INTVL, and AINTVL are required

Commands Used: `ent-acg-mic`

For the `ent-acg-mic` command, if you specify the `type=all` parameter, you must also specify all of the following optional parameters: `aintvl`, `intvl`, and `nd`.

Recovery

Perform one of the following actions:

- Re-enter the `ent-acg-mic` command specifying the `type=all` parameter and the `aintvl`, `intvl`, and `nd`.
- OR
- Re-enter the `ent-acg-mic` command without specifying the `type` parameter (the default is `type=sd`).
-

E3057 Cmd Rej: Parameters SERV and DGTS are not allowed for TYPE=ALL

Commands Used: `chg-acg-mic`, `dlt-acg-mic`, `ent-acg-mic`,
`rtrv-acg-mic`

If you enter one of the above commands specifying the `type=all` parameter, you cannot specify the optional parameters `serv` and `dgts`.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the `type=all` parameter and do not specify the optional parameters `serv` and `dgts`.
- OR
- Re-enter the command and omit the `type` parameter (the default is `type=sd`).
-

E3058 Cmd Rej: Parameters SERV and DGTS are required

Commands Used: `chg-acg-mic`, `dlt-acg-mic`, `ent-acg-mic`

If you enter the one of the above commands specifying the `type=sd` parameter, you must also specify the optional parameters `serv` and `dgts`.

Recovery

Re-enter the command specifying the **type=sd** parameter, and the optional parameters **serv** and **dgts**.

E3059 Cmd Rej: Parameter ND is not allowed

Commands Used: **chg-acg-mic**, **ent-acg-mic**

The **type=sd** parameter instructs the command to process information that is defined by the service and digits, the **serv** and **dgts** parameters. This approach is not compatible with using the optional parameter **nd**, to reset the number of digits. You cannot select using a criteria that is itself being changed.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message, and omit the **nd** parameter.
- OR
- Re-enter the command that generated this error message, and set the **type=all**.
-

E3060 Cmd Rej: Parameter AINTVL is required

Commands Used: **ent-acg-mic**

If you enter this command specifying the **serv=ain** parameter, you must also specify the optional parameter **aintvl**.

Recovery

Perform one of the following actions:

- Re-enter the **ent-acg-mic** command specifying the **serv=ain** parameter and the **aintvl** parameter.
- OR
- Re-enter the **ent-acg-mic** command specifying the **serv=in** parameter.
-

E3061 Cmd Rej: Parameter INTVL is not allowed

Commands Used: `chg-acg-mic`, `ent-acg-mic`

If you enter this command specifying the `serv=ain` parameter, you cannot specify the `intvl` parameter.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the `serv=ain` parameter, and do not specify the `intvl` parameter.

OR

- Re-enter the command specifying the `serv=in` parameter.
-

E3062 Cmd Rej: Parameter INTVL is required

Commands Used: `ent-acg-mic`

For the `ent-acg-mic` command, if you specify the `serv=in` parameter, you must also specify the optional parameter `intvl`.

Recovery

Perform one of the following actions:

- Re-enter the `ent-acg-mic` command specifying the `serv=in` parameter and the `intvl` parameter.

OR

- Re-enter the `ent-acg-mic` command specifying the `serv=ain` parameter.
-

E3063 Cmd Rej: Parameter AINTVL is not allowed

Commands Used: `chg-acg-mic`, `ent-acg-mic`

If you enter this command specifying the `serv=in` parameter, you must not specify the `aintvl` parameter.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **serv=in** parameter, and do not specify the **aintvl** parameter.

OR

- Re-enter the command specifying the **serv=ain** parameter.
-

E3064 Cmd Rej: DGTS parameter must be 3 or 6-10 digits

Commands Used: **chg-acg-mic**, **dlt-acg-mic**, **ent-acg-mic**,
rtrv-acg-mic

You entered the command and specified a value for the **dgts** parameter that the system does not accept. The system accepts the following values for the **dgts** parameter: **3** or **6** through **10** digits.

Recovery

Re-enter the command specifying a new value for the **dgts** parameter, either **3** or a number from **6** through **10**.

E3065 Cmd Rej: ND parameter must be 3 or 6-10

Commands Used: **chg-acg-mic**, **ent-acg-mic**

You entered the command and specified a value for the **nd** parameter that the system does not accept. The system accepts the following values for the **nd** parameter: **3** or **6** through **10** digits.

Recovery

Re-enter the command specifying a new value for the **nd** parameter, either **3** or a number from **6** through **10**.

E3066 Cmd Rej: An MIC of TYPE=ALL already exists

Commands Used: `ent-acg-mic`

You entered a second command specifying an Manually Initiated Control (MIC) whose **type** parameter is set to all. Only one of these can exist at a time in the LNP data base.

Recovery

1. Display the values of the current ACG control parameters **nd**, **intvl**, and **aintvl**. Enter the `rtrv-acg-mic` command.
 2. Re-enter the `ent-acg-mic` command that generated this error message with an MIC that is not shown in the output generated in step 1.
-

E3067 Cmd Rej: An MIC with the same service and digits already exists

Commands Used: `ent-acg-mic`

You specified a Manually Initiated Control (MIC) whose service (**serv**) parameter and digits (**dgts**) parameter duplicate an MIC that already exists in the LNP database. Each MIC called by this command must be unique.

Recovery

1. Display the values of ACG controls assigned to certain queries. Enter the `rtrv-acg-mic` command.
 2. Re-enter the `ent-acg-mic` command that generated this error message with an MIC that is not shown in the output generated in step 1.
-

E3068 Cmd Rej: Table full - a maximum of 256 TYPE=SD MICs are allowed

Commands Used: `ent-acg-mic`, `chg-acg-mic`

You entered the command when the LNP database had already reached its maximum capacity of **256** Manually Initiated Controls.

Recovery

1. Display the values of all ACG controls. Enter the `rtrv-acg-mic` command specifying no parameters.
2. Review ACG controls, to select one or more that is no longer needed.

3. Delete ACG controls that are not needed. Enter the **dlt-acg-mic** command.
 4. Re-enter the command that generated this error message.
-

E3069 Cmd Rej: Parameter ND, DRTN, INTVL, or AINTVL is required

Commands Used: **chg-acg-mic**

If you enter this command specifying the **type=all** parameter. You must also specify at least one of these optional parameters: **nd**, **drtn**, **intvl**, or **aintvl**.

Recovery

Perform one of the following actions:

- Re-enter the **chg-acg-mic** command specifying the **type=all** parameter, specifying one of the optional parameters.

OR

- Re-enter the **chg-acg-mic** command and omit the **type** parameter (the default is **type=sd**).
-

E3070 Cmd Rej: Parameter DRTN or AINTVL is required

Commands Used: **chg-acg-mic**

When you enter this command specifying the **serv=ain** parameter, you must specify at least one of these optional parameters: **drtn** or **aintvl**.

Recovery

Perform one of the following actions:

- Re-enter the **chg-acg-mic** command specifying the **serv=ain** parameter, specifying one of the optional parameters.

OR

- Re-enter the **chg-acg-mic** command without specifying the **serv=ain** parameter.
-

E3071 Cmd Rej: Parameter DRTN or INTVL is required

Commands Used: `chg-acg-mic`

When you enter this command specifying the `serv=in` parameter, you must specify at least one of these optional parameters: `drtn` or `intvl`.

Recovery

Perform one of the following actions:

- Re-enter the `chg-acg-mic` command specifying the `serv=in` parameter, specifying one of the optional parameters.

OR

- Re-enter the `chg-acg-mic` command without specifying the `serv=in` parameter.
-

E3072 Cmd Rej: No MIC of TYPE=ALL exists

Commands Used: `chg-acg-mic`, `dlt-acg-mic`

You specified a Manually Initiated Control (MIC) with the `type` parameter either set to `all`, or completely omitted. Each MIC that already exists in the LNP database has values assigned to the `serv` and `dgts` parameters.

Recovery

1. Enter the `rtrv-acg-mic` command to display the values of ACG controls assigned to certain queries.
 2. Re-enter the command that generated this error message specifying an MIC that has its `serv` and `dgts` parameters set to match an MIC shown in the output generated in step 1.
-

E3073 Cmd Rej: No MIC with the same service and digits exists

Commands Used: `chg-acg-mic`, `dlt-acg-mic`

You specified a MIC whose service (`serv`) parameter and digits (`dgts`) parameter do not exist in the LNP database.

Recovery

1. Display the values of ACG controls assigned to certain queries. Enter the **rtrv-acg-mic** command.
 2. Re-enter the command that generated this error message specifying a MIC that is shown in the output generated in step 1.
-

E3074 Cmd Rej: AND parameter must be 6 or 10

Commands Used: **chg-acg-noc**, **ent-acg-noc**

You specified a value other than **6** or **10** for the AIN number of digits (**and**) parameter. The system does not support this action.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a value of **6** or **10** for the **and** parameter.

OR

- Re-enter the command that generated this error message without specifying the **and** parameter.
-

E3075 Cmd Rej: IND parameter must be 6 or 10

Commands Used: **chg-acg-noc**, **ent-acg-noc**

You cannot specify a value other than **6** or **10** for the IN number of digits (**ind**) parameter. The system does not allow this action. The value specified for the **ind** parameter must be either **6** or **10**.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message, and set the **ind** parameter to either **6** or **10**.

OR

- Re-enter the command that generated this error message, and omit the **ind** parameter.
-

E3076 Cmd Rej: The specified overload level has already been defined**Commands Used: ent-acg-noc**

The LNP process can be programmed to take remedial action at ten different levels of overload severity. The controlling variable is the threshold LNP query rates for node overload levels. The response is to adjust the duration of, and intervals between, the automatic call gapping (ACG) function calls as each level is reached.

A command that attempts to re-define one of the levels that has already been defined will trigger this error message.

Recovery

1. Obtain a list of all currently defined overload levels. Enter the **rtrv-acg-noc** command without specifying parameters.
2. Re-enter the **ent-acg-noc** command specifying an overload level other than those from step 1.

OR

Change one of the existing overload levels. Enter the **chg-acg-noc** command.

E3077 Cmd Rej: TT must be specified if PC is specified**Commands Used: rtrv-lnp-ttmap**

The translation type (**tt**) parameter must be specified if the point code (ANSI) is specified.

Recovery

Perform one of the following actions:

- Re-enter the **rtrv-lnp-ttmap** command specifying both the **tt** and **pc** parameters.

OR

- Re-enter the **rtrv-lnp-ttmap** command specifying only the **tt** parameter.
-

E3078 Cmd Rej: DPC cannot be defined as a remote application IPC**Commands Used: dlt-dstn**

You entered a command to delete a **dpc** and specified a remote application Internal Point Code (IPC) for the **dpc** parameter value. This is not allowed.

Recovery

1. Display the list of existing destination point codes. Enter the **rtrv-dstn** command.
 2. Re-enter the **dlt-dstn** command that generated this error message specifying a valid destination point code to be deleted.
Call your Customer Care Center if this error message appears again.
-

E3079 Cmd Rej: Command cannot be executed on an MGMT terminal**Commands Used: lock**

You cannot lock the keyboard of a terminal that is defined as type **mgmt** for use with Network Surveillance. The **lock** command is not valid for a **mgmt** terminal used for Network Surveillance.

Recovery

Verify that the terminal is type **mgmt**. Enter the **rtrv-trm** command.

No other action is required.

E3080 Cmd Rej: ACTION must be specified as FORWARD, DUPLICATE, or DUPDISC**Commands Used: ent-gsmmap-scrn**

You entered a command to provision a GSM MAP Screening entry that filters or allows TCAP messages for specific Map opcodes based on CgPA and CdPA addresses and forbidden parameters. You can specify the point code (**pc**, **pca**, **pci**, **pcn**, or **pcn24**) and subsystem number (**ssn**) parameters only if you also specify **action=forward**, **action=duplicate**, or **action=dupdisc**. The **action** parameters let you define the node to which the input messages are routed.

Recovery

Re-enter the **ent-gsmmap-scrn** command specifying one of the required default screening action parameters.

E3081 Cmd Rej: NACTION parameter must be FORWARD, DUPLICATE, or DUPDISC**Commands Used: chg-gsmmap-scrn**

You entered a command to change attributes for a defined GSM MAP Screening entry. The attributes (nforbid and naction) filter or allow SCCP messages containing Map opcodes, CgPA and CdPA addresses, **np**, **nai**, and forbidden parameters. If you change the point code (**npc**, **npca**, **npci**, **npcn**, or **npcn24**) and/or subsystem number point code (**nssn**), you must also specify one of the new screening actions for the forbidden parameters **naction=forward**, **naction=duplicate**, or **naction=dupdisc**.

Recovery

Re-enter the **chg-gsmmap-scrn** command specifying one of the new screening actions for the forbidden parameters **naction=forward**, **naction=duplicate**, or **naction=dupdisc**.

E3082 Cmd Rej: NDFLTACT must be specified (FORWARD, DUPLICATE, or DUPDISC)**Commands Used: chg-gsms-opcode**

You entered a command to change attributes of a GSM MAP opcode. These attributes (**ndfltact** and **nopname**) can be the new default screening action and new user-defined name for an opcode. If you change the point code (**npc/npca/npci/npcn/npcn24**) and/or subsystem number (**nssn**), you must also specify **ndfltact=forward**, **ndfltact=duplicate**, or **ndfltact=dupdisc**.

Recovery

Re-enter the **chg-gsms-opcode** command specifying one of the required default screening action (**ndfltact**) parameters.

E3083 Cmd Rej: NACTION must be specified (FORWARD, DUPLICATE, or DUPDISC)

Commands Used: `chg-gsmmap-scrn`

You entered a command to change the attributes for a defined GSM MAP Screening entry. The attributes (**nforbid** and **naction**) filter or allow SCCP messages containing MAP opcodes, CgPA and CdPA addresses, **np**, **nai**, and forbidden parameters. If you change the point code (**npc**, **npca**, **npci**, **npcn**, or **npcn24**) and/or subsystem number (**nssn**), you must also specify **naction=forward**, **naction=duplicate**, or **naction=duplicate**.

Recovery

Re-enter the `chg-gsmmap-scrn` command specifying one of the required new action screening if forbidden parameters: **naction=forward**, **naction=duplicate**, or **naction=duplicate**.

E3084 Cmd Rej: Both OAM cards must be of the same type to update database

Commands Used: Any command used to update a database

You entered a command to update the system database. The database cannot be updated because the OAM is running on two different types of cards (GSM-II and MCAP). The two cards that run the OAM must be the same type before you can update the database.

Refer to the *Installation Manual* for information about upgrading the MASP cards.

Recovery

1. Replace one of the two OAM cards, so that both cards are the same type.
 2. Re-enter the command to update the database.
-

E3085 Cmd Rej: Cannot change the RC parameter with the ENT command

Commands Used: `ent-mrn`

The `ent-mrn` command cannot be used to change the relative cost (**rc**) assigned to a point code; you must use the `chg-mrn` command.

Recovery

1. Display the point code and its existing relative cost parameter values. Enter the **rtrv-mrn** command.
 2. Change the relative cost for the point code. Enter the **chg-mrn** command specifying the point code and the new relative cost parameters.
-

E3086 Cmd Rej: New PC and RC must be entered as a pair**Commands Used: ent-mrn**

You entered a command to add a new point code to the Mated Relay Node (MRN) table, and you did not specify both the new point code (**pc**) parameter value and the new relative cost (**rc**) parameter value for the point code. Both the point code and the relative cost parameters are required for a new point code.

Recovery

Re-enter the **ent-mrn** command specifying both the new point code (**pc**) parameter value and the relative cost (**rc**) parameter value for the new point code.

E3087 Cmd Rej: Must enter at least one PC/RC pair**Commands Used: ent-mrn**

You must specify at least one point code (**pc**) and the relative cost (**rc**) parameter value pair.

Recovery

Re-enter the **ent-mrn** command specifying at least one point code and relative cost parameter pair.

E3088 Cmd Rej: MEAS Platform must be enabled**Commands Used: chg-ctrl-feat, chg-measopts, enable-ctrl-feat, rept-ftp-meas**

You entered the **chg-ctrl-feat** command to turn on the 15 Minute Measurements feature but the Measurements Platform collection function is not enabled. You must enable the collection function before you can use this command.

OR

You entered the **chg-measopts** command to turn on the Filename with CLI feature but the Measurements Platform collection function is not enabled. You must enable the Measurements Platform collection function before you can use this command.

OR

You entered the **enable-ctrl-feat** command to turn on the MTP MAP Screening feature but the Measurements Platform collection function is not enabled. Enable the Measurements Platform collection function before using this command.

OR

You entered the **rept-ftp-meas** command to manually initiate generation and FTP transfer of a measurements report from the Measurements Platform to the customer's FTP server. The Measurements Platform collection function is not enabled. You must enable the collection function before you can use this command.

NOTE: Once the Measurements Platform collection function has been enabled using the **chg-measopts** command, it cannot be disabled using the **chg-measopts** command. Though it is not recommended, collection can be stopped and started by inhibiting and allowing all MCPM cards. All previous measurements data can be lost when you inhibit all MCPM cards, if the cards are removed. Refer to the **chg-measopts**, **alw-card**, and **inh-card** commands in the *Commands Manual*, and call your Customer Care Center. for further information.

Recovery

1. Enter the **rtrv-measopts** command and verify that the Measurements Platform function is disabled (**platformenable=off**).
 2. To enable the Measurements Platform collection function, enter the **chg-measopts:platformenable=on** command.
 3. When the Measurements Platform collection function is enabled, you can re-enter the original command.
-

E3089 Cmd Rej: FTP Server password must be 1 - 15 characters in length

Commands Used: **chg-ftp-serv**, **ent-ftp-serv**

You entered a command to enter or change information for a Measurements Platform FTP server. A prompt appeared asking you for the FTP server password. You either pressed the Return key after the prompt without entering the FTP server password, or you entered a password that was more than 15 characters long.

Recovery

1. Re-enter the command to enter or change the FTP server information. The password prompt appears again.
 2. After the prompt, enter the password for the FTP server, and press the Return key. The password must be at least 1 character and not more than 15 characters long.
-

E3090 Cmd Rej: Full Point Code must be specified

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`, `dlt-gta`, `ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gta`, `rtrv-gta`

If a point code was specified, the point code (`pc/pca/pci/pcn/pcn24` or `np/npc/npci/npcn/npcn24`) must be a full point code. A full point code contains numerical values for all segments of the point code.

Recovery

Re-enter the command specifying a full point code.

Call your Customer Care Center if this error message appears again.

E3091 Cmd Rej: PC/SSN must be given with Action FORWARD, DUPLICATE, DUPDISC

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `ent-gsmmap-scrn`, `ent-gsms-opcode`

When you issue a command specifying the parameter `dfltact`, `ndfltact`, `action`, or `naction` set to the value `forward`, `duplicate`, or `dupdisc`, along with the point code and subsystem number parameters.

Recovery -gsmmap-scrn commands

1. If you specified `ent-gsmmap-scrn:action=forward`, `duplicate`, or `dupdisc`, you must include the `pc/pca/pci/pcn/pcn24` and `ssn` parameters.
 2. If you specified `chg-gsmmap-scrn:naction=forward`, `duplicate`, or `dupdisc`, you must include the `npc/npc/npci/npcn/npcn24` and `nssn` parameters.
-

Recovery -gsms-opcode commands

1. If you specified **ent-gsms-opcode:dfltact=forward**, **duplicate**, or **dupdisc**, you must include the **pc/pca/pci/pcn/pcn24** and **ssn** parameters.
 2. If you specified **chg-gsms-opcode:ndfltact=forward**, **duplicate**, or **dupdisc**, you must include the **npc/npca/npci/npcn/npcn24** and **ssn** parameters.
-

E3092 Cmd Rej: PC/SSN must be specified if FORCE is specified

Commands Used: **chg-gsmmap-scrn**, **chg-gsms-opcode**,
ent-gsmmap-scrn, **ent-gsms-opcode**

If you specify the **force** parameter, you must also specify the point code and subsystem number parameters.

Recovery

1. Re-enter the command containing the parameter **force**, specifying either **pc/pca/pci/pcn/pcn24** or **npc/npca/npci/npcn/npcn24** parameters and/or subsystem number point code (**ssn** or **nssn**) parameter.
 2. If you used the **chg-gsmmap-scrn** command, specify the **force** parameter with the **npc/npca/npci/npcn/npcn24** and **nssn** parameters
Refer to the *Commands Manual* for the additional information.
-

E3093 Cmd Rej: EROUTE not configured

Commands Used: **rept-stat-eroute**

You entered a command to retrieve card and subsystem information for an STC card running the **eroute** application. The STC card is not configured in the system.

Recovery

1. Display the card information. Enter the **rept-stat-card** command.
 2. Verify that at least one STC card is configured in the system.
If an STC card is not installed in the system, you cannot use this command until STC cards are installed and provisioned, and the EAGLE 5 Integrated Monitoring Support feature is installed and operating.
 3. If an STC card is in the system, re-enter **rept-stat-eroute** command.
-

E3094 Cmd Rej: Both OAM cards must be of same type to perform upgrade

Commands Used: `act-upgrade`

A prerequisite of the upgrade is that both OAM cards installed in the system must be of the same type.

Recovery

Prior to performing the upgrade, perform the following actions:

1. Verify the hardware baseline configuration requirements are met.
2. Install the same type of OAM cards (both) in the system.

Call your Customer Care Center if this error message appears again.

E3095 Cmd Rej: LHOST/ALHOST location not found

Commands Used: `chg-appl-sock`, `chg-assoc`, `ent-appl-sock`,
`ent-assoc`

A card location associated with the IP address for the host name that you entered in the **lhost** parameter for the command was not found in the IP Link table.

OR

The signaling link associated with the local host that you entered in the **lhost** parameter has not been activated.

Recovery

1. Enter the `rtrv-ip-host` command to display the IP addresses for the host names in the IP Host table. Verify the IP address for the specified local host name.
2. Enter the `rtrv-ip-lnk` command to verify the card location for the local host name IP address.
3. If the card location for the local host IP address is not shown for the local host IP address in the output from step 2, enter the `chg-ip-lnk` command to define the card location.
4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

OR

1. Enter the **rtrv-ip-host** command to display the IP addresses for the host names in the IP Host table. Verify the IP address for the specified local host name.
 2. Enter the **rtrv-ip-lnk** command to display the card location for the local host name IP address.
 3. Enter the **rtrv-slk** command for the local host card location to display the signaling links and ports assigned to the card.
 4. Enter the **rept-stat-slk** command to verify the status of the signaling link assigned to the local host card.
 5. If the link is not In Service, enter the **act-slk** command to activate the signaling link.
 6. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3096 Cmd Rej: Invalid socket/association ratio for card type

Commands Used: **chg-appl-sock**, **chg-assoc**, **ent-appl-sock**,
ent-assoc

You entered a command that would create an invalid socket/association ratio for this type of card.

Recovery

Re-enter the command specifying parameter values that do not create an invalid socket/association ratio for the card.

Refer to the *Commands Manual* for information about socket/association ratios.

E3097 Cmd Rej: GPSM-II required to support more than 700 links

Commands Used: **enable-ctrl-feat**, **ent-slk**

If you entered the **enable-ctrl-feat** command to enable the 6000 Routesets Controlled Feature. To enable the 6000 Routesets feature, both OAM cards in locations (1113 and 1115) must be running GPSM-II cards.

OR

If you entered the **ent-slk** command to assign a signaling link that will result in raising the number of links in the system to greater than **700**. To assign more than **700** links in the system, both OAM cards in locations (**1113** and **1115**) must be running GPSM-II cards.

Recovery - enable-ctrl-feat

1. Enter the **rept-stat-card:loc=1113** command and the **rept-stat-card:loc=1115** command. Verify that both of the cards are GPSM-II cards and one of them is running the active OAM application.
 2. If neither card is a GPSM-II card running the active OAM, you cannot enable the 6000 Routesets controlled feature. To enable this feature, you must replace both MCAP cards in your system with GPSM-II cards.
 3. If one of the two GPSM-II cards is running the active OAM application, re-enter the command to enable the 6000 Routesets controlled feature.
Contact your Customer Care Center if this error message appears again.
-

Recovery - ent-slk

1. Verify that both of the cards are GPSM-II cards and one of them is running the active OAM application. Enter the **rept-stat-card:loc=1113** command and the **rept-stat-card:loc=1115** command.
 2. If one of the two GPSM-II cards is running the active OAM application, re-enter the **ent-slk** command to assign the signaling link.
 3. If neither card is a GPSM-II card running the active OAM, you cannot assign more than **700** links in the system.
To add another link, you must first delete an existing link (refer to the **dl1-slk** command in the *Commands Manual*); or replace both MCAP cards in your system with GPSM-II cards.
Contact your Customer Care Center if this error message appears again.
-

E3098 Cmd Rej: PPSMSGTA must not be NONE

Commands Used: chg-gsmopts

You cannot specify a value of **none** for the **ppsmgta** parameter.

Recovery

Re-enter the **chg-gsmopts** command specifying a valid value for the **ppsmgta** parameter.

E3099 Cmd Rej: PPSMSGTA must be specified when NPPSMSGTA is specified

Commands Used: chg-gsmopts

You cannot specify the **nppsmgta** parameter without specifying the **ppsmgta** parameter. The **nppsmgta** parameter cannot be specified by itself.

Recovery

Re-enter the **chg-gsmopts** command specifying both the **ppsmgta** parameter and the **nppsmgta** parameter.

E3100 Cmd Rej: PPSMSGTA doesn't exist in GSMOPTS Table

Commands Used: chg-gsmopts

You entered a command to change a **ppsmgta** parameter value to a new **nppsmgta** parameter value. The **ppsmgta** parameter value that you enter must already exist in the GSMOPTS table.

Recovery

1. Display the **ppsmgta** parameter values currently in the GSMOPTS table. Enter the **rtrv-gsmopts** command.
 2. Re-enter the **chg-gsmopts** command specifying a value for the **ppsmgta** parameter that appears in the output from step 1.
-

E3101 Cmd Rej: Maximum number of PPSMSGTAs already provisioned

Commands Used: chg-gsmopts

You cannot add a **ppsmgta** value to the GSMOPTS table because the maximum of three **ppsmgta** values are already provisioned.

Recovery

1. Display the **ppsmgta** parameter values currently in the GSMOPTS table. Enter the **rtrv-gsmopts** command.
 2. You can enter the new **ppsmgta** value to the table by changing an existing **ppsmgta** value to the new value. Enter the command specifying the existing **ppsmgta** value (one that appears in the output from step 1) in the **ppsmgta** parameter and the new **ppsmgta** value in the **nppsmgta** parameter.
-

E3102 Cmd Rej: NPPSMSGTA already exists in GSMOPTS Table

Commands Used: **chg-gsmopts**

You entered a command to change an existing **ppsmgta** parameter value to a new **nppsmgta** parameter value. The new value that you enter in the **nppsmgta** parameter cannot already exist in the GSMOPTS table.

Recovery

1. Display the **ppsmgta** parameter values currently in the GSMOPTS table. Enter the **rtrv-gsmopts** command.
 2. Re-enter the **chg-gsmopts** command specifying a value for the **nppsmgta** parameter that does not appear as a **ppsmgta** value in the output from step 1.
-

E3103 Cmd Rej: GTT must be ON before XGTT can be enabled

Commands Used: **enable-ctrl-feat**

The GTT feature must be turned on before you can enable the Expanded Global Title Translation (XGTT) Table Expansion feature.

NOTE: Once the XGTT feature access key has been turned on, it cannot be turned off. Refer to the **chg-ctrl-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.

- From the output from step 1, verify the XGTT Table Expansion feature has been purchased and installed in your system. Call your Customer Care Center for assistance.
- From the output from step 1 determine the status of the GTT feature.

- If the GTT feature is on, enable the XGTT feature.

Re-enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

- If the GTT feature is off, turn it on:

Enter **chg-feat:gtt=on** command.

Verify the GTT feature is on. Enter the **rtrv-ctrl-feat** command.

NOTE: Before the XGTT can be enabled:

- Both cards that run the OAM must be of type GPSM-II.
- XGTT from **269,999** to **400,000** entries requires all SCCP GPLs running on TSM cards or a combination of TSM and DSM cards.
- XGTT with **1,000,000** entries requires all SCCP GPLs running on DSM cards.

Enable the XGTT Table Expansion feature. Re-enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E3104 Cmd Rej: XGTT requires at least a 586 processor for SCCP GPLs

Commands Used: enable-ctrl-feat

You entered a command to enable the Expanded Global Title Translation (XGTT) Table Expansion feature, but one or more SCCP cards in the system have less than a 586 processor. All SCCP cards in the system must have at least 586 processors before you can turn on XGTT.

Recovery

- Verify that all SCCP cards in the system have at least 586 processors:
 - Enter the **rtrv-card** command to locate all SCCP cards in your system.
 - Visually inspect all SCCP cards. Any SCCP card that is a DSM or TSM card contains 586 processors. Any SCCP card that is a TSM card contains only

486 processors and must be replaced. Call your Customer Care Center. for assistance if necessary.

2. When all SCCP cards have at least 586 processors, re-enter the **enable-ctrl-feat** command to enable the XGTT feature.
-

E3105 Cmd Rej: XGTT requires both OAMs running on GPSMII cards

Commands Used: **enable-ctrl-feat**

You cannot enable the Expanded Global Title Translation (XGTT) Table Expansion feature if both OAM cards are not type GPSM-II. Before the XGTT feature can be enabled, both OAM cards must be of type GPSM-II.

Recovery

1. Verify each OAM card type. Enter the **rtrv-card** command.
 2. If both OAM cards are type GPSM-II, re-enter **enable-ctrl-feat** the command.
 3. If both OAM cards are not type GPSM-II, replace the non-GPSM-II OAM cards with GPSM-II cards.
 4. Re-enter the **enable-ctrl-feat** command to enable the XGTT feature.
Call your Customer Care Center if this error message appears again.
-

E3106 Cmd Rej: XGTT with 1 million entries requires DSM cards for SCCP GPLs

Commands Used: **enable-ctrl-feat**

You cannot enable the Expanded Global Title Translation (XGTT) Table Expansion feature with 1,000,000 entries if SCCP GPLs are running on both TSM and DSM cards. To enable the XGTT feature with 1,000,000 entries, all SCCP GPLs must be running on DSM cards.

Recovery

1. Upgrade your hardware to ensure that you have only DSM cards (no TSMs) on your system.
 2. Re-enter the **enable-ctrl-feat** command to enable the XGTT feature.
Call your Customer Care Center if this error message appears again.
-

E3107 Cmd Rej: XMAP requires at least a 586 processor for SCCP GPLs**Commands Used: enable-ctrl-feat**

You entered a command to enable the Expanded MAP Table (XMAP) feature, but one or more SCCP cards in the system have less than a 586 processor. Before you can turn on the XMAP feature, all SCCP cards in the system must have at least 586 processors.

Recovery

1. Verify that all SCCP cards in the system have at least 586 processors:
 - Enter the **rtrv-card** command to locate all SCCP cards in your system.
 - Visually inspect all SCCP cards. Any SCCP card that is a DSM or TSM card contains 586 processors. Any SCCP card that is a TSM card contains only 486 processors and must be replaced. Contact your Customer Care Center for assistance if necessary.
 2. When all SCCP cards have at least 586 processors, re-enter the **enable-ctrl-feat** command to enable the XMAP feature.
-

E3108 Cmd Rej: XMAP requires both OAMs running on GPSMII cards**Commands Used: enable-ctrl-feat**

You cannot enable the Expanded MAP Table (XMAP) feature if both OAM cards are not type GPSM-II. Before the XMAP feature can be enabled, both OAM cards must be of type GPSM-II.

Recovery

1. Verify the type of OAM cards. Enter the **rtrv-card** command.
 2. If both OAM cards are type GPSM-II, re-enter the **enable-ctrl-feat** command.
Call your Customer Care Center if this error message appears again.
 3. If both OAM cards are not type GPSM-II, replace the non-GPSM-II cards with GPSM-II cards.
 4. Re-enter the **enable-ctrl-feat** command to enable the XMAP feature.
-

E3109 Cmd Rej: Temporary feature key is not allowed for the feature

Commands Used: `enable-ctrl-feat`

You entered a command to enable a Controlled Feature, but a temporary feature access key is not allowed for this feature.

Controlled feature access keys may be temporary or permanent. A temporary feature access key enables a specific controlled feature for a limited period of time, after which the controlled feature is automatically disabled by the STP/SG system. A permanent feature access key enables a controlled feature indefinitely. An enabled controlled feature remains enabled even through an in-service upgrade. An enabled controlled feature cannot be disabled via administrative commands.

Recovery

1. Display the controlled features that are currently enabled. Enter the `rtrv-ctrl-feat` command.
 2. Examine the features that have been purchased and enabled to date.
 3. If you find a discrepancy between the controlled features displayed and those your system should have enabled, call your Customer Care Center.
-

E3110 Cmd Rej: Loading Mode unstable due to maint. baseline not established

Commands Used: `all ent/dlt/chg commands and init-card`

The command was entered while the MASP was re-initializing.

Recovery

Wait until the MASP has re-initialized, then re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3111 Cmd Rej: Loading mode unstable. System's LIM service is unavailable

Commands Used: `all ent/dlt/chg commands and init-card`

The command was entered, and the system detected that less than 80% of the system's LIMs and the minimum number of VSCCP or SCCP cards required to support 80% of the LIMs are not in service or are inhibited (OOS-MT-DSBLD).

Recovery

1. Display the state of the signaling links in the database. Enter the **rept-stat-slk** command. The state of the signaling links should be either in-service normal (IS-NR) or out-of-service maintenance-disabled (OOS-MT-DSBLD). (As shown in the PST field of the **rept-stat-slk** command output).
 2. Enter the **inh-slk** command to put every SLK whose state is not IS-NR or OOS-MT-DSBLD into an out-of-service disabled state.
 3. Enter the **rept-stat-card** command to display the state of the VSCCP, SCCP, and LIM cards in the database. The state of all these cards should be IS-NR or OOS-MT-DSBLD. (This is shown in the PST field of the **rept-stat-card** output).
 4. Enter the **inh-card:loc=xxxx** command to put all the cards whose state is not IS-NR or OOS-MT-DSBLD in an out-of-service disabled state.
 5. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3112 Cmd Rej: Loading Mode unstable due to SCCP service is deficient

Commands Used: all ent/dlt/chg commands, **init-card**, and **rtrv-data-rtdb**, **rtrv-data-insrv**

The command was entered, and the system detected that LIMs are being denied SCCP service or the state of any DSM/TSM is neither in-service normal (IS-NR) or out-of-service maintenance disabled (OOS-MT-DSBLD).

Recovery

1. Display the status of the signaling links in the database with the **rept-stat-slk** command. The state of the signaling links should be IS-NR or OOS-MT-DSBLD. This is shown in the PST field of the **rept-stat-slk** command output.
2. Display the status of the DSM/TSMs in the database with the **rept-stat-sccp** command. The state of the DSM/TSMs should be in-service normal (IS-NR) or out-of-service maintenance-disabled (OOS-MT-DSBLD). This is shown in the PST field of the **rept-stat-sccp** command output.
3. Place the cards shown in steps 1 and 2 whose state is not IS-NR or OOS-MT-DSBLD out of service, with the **rmv-card** command.
4. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3117 Cmd Rej: No available primary MCP

Commands Used: `rept-ftp-meas`, `rept-meas`

When you entered the command, the Measurements Platform feature was turned on but there was no primary MCP (Measurement Collection Processor) available in the system.

Recovery

1. Verify the status of MCPM cards in the system. Enter the `rtrv-card` and `rept-stat-card` commands.
2. Verify that the Measurements Platform feature is turned on. Enter the `rtrv-measopts` command.
3. Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3119 Cmd Rej: Failed Reading GTT TRANS table

Commands Used: `chg-gta`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `rtrv-gta`

The GTT Trans table is corrupt or cannot be found by the system. The GTA Trans table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3120 Cmd Rej: Failed reading GTT DBMM table

Commands Used: `chg-gta`, `chg-gttset`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `ent-gttset`, `rtrv-gta`, `rtrv-gttset`

The GTT DataBase Memory Manager (DBMM) table is corrupt or cannot be found by the system. The GTT DBMM table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3121 Cmd Rej: Domain indicated by GTIx must match that of existing TT

Commands Used: `ent-gttse1`

The domain you specified with the `gti/gtia/gtii/gtin/gtin24=4` parameter does not match the domain of the translation type (tt). The domain is defined as `gti` and `gtia=ansi`, `gtii=ITU international`, `gtin=ITU national`, and `gtin24=24-Bit ITU national`.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttse1` command.
 2. Re-enter the `ent-gttse1` command specifying a value for the GTI domain that matches the translation type's domain.
-

E3122 Cmd Rej: SERV has not been assigned a true TT

Commands Used: `ent-lnp-serv`

You attempted to enter this command specifying an invalid parameter.

Recovery

Re-enter the `ent-lnp-serv` command that generated this error message specifying the correct parameter.

Call your Customer Care Center if this error message appears again.

E3123 Cmd Rej: Failed Reading LNP TT SERV table

Commands Used: `chg-lnp-serv`, `dlt-lnp-serv`, `ent-lnp-serv`,
`rtrv-lnp-serv`

The LNP TT SERV table is corrupt or cannot be found by the system. The LNP database and the LNP TT SERV table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3124 Cmd Rej: Failed Reading LNP SS Appl table

Commands Used: `chg-map`, `chg-ss-appl`, `dlt-ss-appl`, `ent-map`,
`ent-ss-appl`, `rtrv-ss-appl`

The LNP TT SS Appl table is corrupt or cannot be found by the system. The LNP SS Appl table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3132 Cmd Rej: LNP SS Appl table is full

Commands Used: `ent-ss-appl`, `chg-ss-appl`

You attempted to reserve an identifying number for an application's subsystem, but the LNP SS Appl table that contains this information had already reached capacity.

Recovery

1. Display the LNP SS Appl table. Enter the `rtrv-ss-appl` command.
2. Delete one of the existing service types listed. Enter the `dlt-ss-appl` command.
3. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3139 Cmd Rej: Translation Type is already in LNP database

Commands Used: `ent-lnp-serv`, `chg-lnp-serv`

You attempted to enter a translation type that duplicated one that was already on record.

Recovery

1. Enter the **rtrv-lnp-serv** command to retrieve a list of all LNP services and translation types.
 2. Perform one of the following actions:
 - Use the **chg-lnp-serv** command to change the syntax of the service type that is currently assigned to the translation type, to that of the desired service type.OR
 - Use the **dlt-lnp-serv** command to delete the service type, listed in step 1, that currently is matched to the translation type.
 3. Re-enter the command that generated this error message.
-

E3140 Cmd Rej: Service Type is already in LNP database

Commands Used: ent-lnp-serv

You attempted to enter a service type that is already on record.

Recovery

1. Enter the **rtrv-lnp-serv** command to retrieve a list of all LNP services and translation types.
 2. Perform one of the following actions:
 - Use the **chg-lnp-serv** command to change the syntax of the service type that is currently assigned to the translation type, to that of the desired service type.OR
 - Use the **dlt-lnp-serv** command to delete the service type, listed in step 1, that currently is matched to the translation type.
 3. Re-enter the command that generated this error message.
-

E3143 Cmd Rej: New Translation Type already in LNP database

Commands Used: chg-lnp-serv, ent-lnp-serv

The specified new translation type (**ntt**) was not added to the LNP database because it already exists in the LNP database. The new translation type (**ntt**) parameter must not already exist in the LNP database.

A maximum of eight unique LNP services can each be assigned one translation type apiece.

Recovery

1. Display a list of all LNP services. Enter the **rtrv-lnp-serv** command.
 2. Re-enter the **chg-lnp-serv** command specifying an **ntt** that is not listed in the output from step 1.
-

E3145 Cmd Rej: New Translation Type Name already in LNP database

Commands Used: **chg-lnp-serv**

The specified new translation type name (**nttn**) was not added to the LNP database because it already exists in the LNP database. The new translation type name (**nttn**) parameter must not already exist in the LNP database.

Up to **eight** unique LNP services can each be assigned one translation type apiece.

Recovery

1. Display a list of all LNP services. Enter the **rtrv-lnp-serv** command.
 2. Re-enter the **chg-lnp-serv** command specifying a **nttn** that is not listed in the output from step 1.
-

E3146 Cmd Rej: Service type is not in LNP database

Commands Used: **chg-lnp-serv**, **dlt-lnp-serv**

You cannot change or delete a service type that is not in the LNP database.

Recovery

1. Display a list of all LNP services. Enter the **rtrv-lnp-serv** command.
 2. Perform one of the following actions:
 - Use the **chg-lnp-serv** command to change the syntax of one of the existing service types to that of the desired service type.OR
 - Use the **dlt-lnp-serv** command to delete one of the existing service types listed in step 1.
-

E3147 Cmd Rej: Translation Type referenced in LNP database

Commands Used: `dlt-lnp-serv`

A translation type cannot be deleted if it is referenced by a current LNP database entry.

Recovery

1. Display the GTT table. Enter the `rtrv-gtt` command.
 2. Delete the global title translation entry associated with the translation type to be deleted. Enter the `dlt-gtt` command.
 3. Delete the translation type. Enter `dlt-tt:type=`
OR
 1. Change the `tt-service` combination. Enter the `chg-lnp-serv` command.
 2. Re-enter the `dlt-lnp-serv` command that generated this error message.
 3. If you need to rebuild your database, call your Customer Care Center.
-

E3148 Cmd Rej: Translation Type Name is not in the LNP database

Commands Used: `ent-lnp-serv`, `chg-lnp-serv`

The specified LNP service was not entered or changed because the specified translation type name (`ttn`) does not exist in the LNP database.

Recovery

1. Display a list of valid translation types. Enter the `rtrv-lnp-serv` command.
 2. Re-enter the command that generated this error message specifying a valid translation type name (`ttn`) from the output from step 1.
-

E3149 Cmd Rej: Maximum number of applications already assigned

Commands Used: `ent-ss-appl`

You attempted to add one more subsystem application than the system was designed to process.

NOTE: This error is currently handled by error message E3266. Should you see this error, though, follow the instructions below.

Recovery

1. Enter the **rtrv-ss-appl** command to retrieve a list of all subsystem applications.
 2. Use the **dlt-ss-appl** command to delete one of the existing subsystem applications listed in step 1.
 3. Re-enter the **ent-ss-appl** command that generated this error message.
-

E3150 Cmd Rej: Application already assigned

Commands Used: **ent-ss-appl**

You attempted to add a duplicate subsystem application.

Recovery

1. Display a list of all subsystem applications. Enter the **rtrv-ss-appl** command.
 2. Delete one of the existing subsystem applications listed in step 1. Enter the **dlt-ss-appl** command.
 3. Re-enter the **ent-ss-appl** command that generated this error message.
-

E3152 Cmd Rej: Application type not in LNP database

Commands Used: **chg-ss-appl, dlt-ss-appl**

You attempted to change or delete a subsystem application with a type that is not listed in the database.

Recovery

1. Display a list of all subsystem applications. Enter the **rtrv-ss-appl** command.
 2. Delete one of the existing subsystem applications listed in step 1. Enter the **dlt-ss-appl** command.
 3. Re-enter the **ent-ss-appl** command that generated this error message.
-

E3153 Cmd Rej: Subsystem must be inhibited before it can be OFFLINE

Commands Used: `chg-ss-appl`

This command changes the status of the LNP subsystem application between offline and online. You must inhibit the LNP subsystem before taking it offline.

Recovery

1. Determine the subsystem number (**ssn**) for the LNP subsystem. Enter the `rtrv-ss-appl` command.
 2. Inhibit the LNP subsystem. Enter the `inh-map-ss` command specifying the **ssn** for the LNP subsystem.
 3. Change the status of the LNP subsystem to offline. Enter the `chg-ss-appl:appl=lnp:nstat=offline` command.
-

E3154 Cmd Rej: Subsystem must be in opposite state of change

Commands Used: `chg-ss-appl`

The state of the subsystem is already online (or offline).

Recovery

No action required.

E3155 Cmd Rej: Subsystem must be inhibited before it can be deleted

Commands Used: `dlt-ss-appl`

You must inhibit the subsystem before you can delete it.

Recovery

1. Determine the subsystem number (**ssn**) for the LNP subsystem. Enter the `rtrv-ss-appl` command.
 2. Inhibit the LNP subsystem. Enter the `inh-map-ss` command specifying the **ssn** parameter value for the LNP subsystem.
 3. Delete the LNP subsystem. Enter the `dlt-ss-appl:appl=lnp` command.
-

E3172 Cmd Rej: Alias is not assigned to SERV**Commands Used: dlt-lnp-serv**

The alias you entered must be associated with the LNP service you are trying to delete.

Recovery

1. Display a list of the LNP services and their associated aliases. Enter the **rtrv-lnp-serv** command.
2. Re-enter the **dlt-lnp-serv** command that generated this error message specifying the correct alias parameter.

Call your Customer Care Center if this error message appears again.

E3177 Cmd Rej: FORCE=YES must be specified if NUM is greater than 50**Commands Used: rtrv-home-smsc, rtrv-srvsel**

You specified a value greater than **50** for the **num** parameter, but you did not specify the **force=yes** parameter. If the **num** parameter is set to a value greater than **50**, the **force=yes** parameter must be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **force=yes** parameter.
OR
 - Re-enter the command specifying a value less than **50** for the **num** parameter.
OR
 - Re-enter the command without specifying a **num** parameter value.
-

E3198 Cmd Rej: Failed reading LNP Options table**Commands Used: chg-lnpopts, rtrv-lnpopts**

The LNP Options table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3199 Cmd Rej: To change or delete SERV, it must have no LNP aliases

Commands Used: `dlt-lnp-serv`, `chg-lnp-serv`

You must delete all aliases associated with the LNP service before you can change or delete the service.

Recovery

1. Display a list of the LNP services, and their associated aliases. Enter the `rtrv-lnp-serv` command.
2. Delete the aliases associated with the LNP service you are trying to change or delete.
3. Delete or change the desired LNP service. Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3209 Cmd Rej: CPCTYPE cannot be specified without CPC

Commands Used: `chg-sid`

You specified the `cpctype` parameter, but did not specify a `cpc` parameter.

Recovery

Re-enter the `chg-sid` command specifying both the `cpc` parameter and the `cpctype` parameter.

E3210 Cmd Rej: CPCTYPE cannot be specified with NCPC

Commands Used: `chg-sid`

The `cpctype` and `ncpc` parameters cannot be specified together.

Recovery

Re-enter the **chg-sid** command specifying either the **cpctype** or the **ncpc** parameter, but not both.

Call your Customer Care Center if this error message appears again.

E3217 Cmd Rej: DUAL OAP configuration is needed for LNP feature**Commands Used: act-oap-config**

You cannot specify a value of single for the OAP configuration parameter (**cfg=sngl**). The LNP feature requires that a dual OAP configuration (**cfg=dual**) be specified.

Recovery

1. Determine the OAP configuration. Enter the **rtrv-oap-config** command.
 2. If the OAP configuration indicates single (**cfg=sngl**), change it to dual. Enter **chg-oap-config:cfg=dual** command.
 3. Verify the OAP configuration changed to dual. Re-enter the **rtrv-oap-config** command.
 4. Re-enter the **act-oap-config** command.
-

E3220 Cmd Rej: CPCx must be ANSI if CPCTYPE equals LNP**Commands Used: chg-sid**

You used the wrong capability point code parameter and value. It is necessary to assign a value to the **cpc** or **cpcx** parameter, when the **cpctype=lnp**.

Recovery

1. Display the necessary information about the current self-identification. Enter the **rtrv-sid** command.
 2. Perform one of the following actions:
 - If the output of step 1 indicates that the **cpctype=stp**, re-enter the **chg-sid** command that generated this error message specifying the correct **cpctype** parameter value.OR
 - If the output of step 1 indicates that the **cpctype=lnp**, the appropriate capability point code parameter will be either **cpci** or **cpcn**. Re-enter the **chg-sid** command that generated this error message specifying the correct **cpcx** parameter value.
-

E3225 Cmd Rej: NONE is a reserved name and cannot be used for a TTN

Commands Used: ent-lnp-serv

When you entered this command to reserve an LNP translation type for a unique LNP service, you attempted to assign the only forbidden name (**none**) to the translation type. You can define the translation type by any alphabetic string from **1** to **8** characters long, except for **ttn=none**.

Recovery

Re-enter the **ent-lnp-serv** command specifying the **ttn** parameter as an alphabetic string from **1** to **8** characters long, excluding **ttn=none**.

E3226 Cmd Rej: New digits valid (DV) must not match old DV indication

Commands Used: chg-lnp-serv

The value specified for the new digits valid (**ndv**) parameter cannot be the same as the value specified for the old (or current) digits valid indication (**dv**) parameter.

Recovery

Perform one of the following actions:

- Re-enter the **chg-lnp-serv** command without specifying the **ndv** parameter.
- OR
- Re-enter the **chg-lnp-serv** command specifying a different value for the **ndv** parameter.
-

E3233 Cmd Rej: System serial number has not been locked

Commands Used: enable-ctrl-feat

The feature that you attempted to enable does not have the system serial number locked in the database.

Contact your Customer Care Center and refer to the **ent-serial-num** command in the Commands Manual before you use the command to lock the Serial Number table. If you inadvertently enter and lock an incorrect serial number in the database, a manual procedure and a system disk are required from Tekelek.

Recovery

Re-enter the **enable-ctrl-feat** command.

Call your Customer Care Center if this error message appears again.

E3239 Cmd Rej: Point Code must be the STP True point code

Commands Used: ent-map

You specified the wrong value for the **pc/pca/pci/pcn** parameter. When specifying a MAP entry for LNP subsystems, only the STP's true point code can be entered.

Recovery

1. Display the correct site identification number for this STP. Enter the **rtrv-sid** command.
 2. Re-enter the command that generated this error message specifying the point code value for this STP.
-

E3243 Cmd Rej: Unknown hardware configuration

Commands Used: `chg-feat`, `enable-crt1-feat`

Ensure that the system is configured at the proper hardware baseline.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3244 Cmd Rej: UIM number does not exist in UIM Threshold table

Commands Used: `dlt-uim-acthresh`

You specified an invalid UIM number. The UIM number must exist in the UIM Threshold Table.

Recovery

1. Verify that you have typed the UIM number correctly. If necessary, enter the `rtrv-uim-acthresh` command to retrieve a list of valid UIM numbers.
 2. Re-enter the `dlt-uim-acthresh` command specifying a valid UIM number.
-

E3245 Cmd Rej: PLNP feature must be ON

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

You entered a value of `pcs` for the `serv` or `nserv` parameter, which requires that the PLNP (PCS 1900 LNP) Feature be on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

Perform one of the following actions:

Re-enter the command specifying a value other than `pcs` for the `serv` parameter.

OR

- a. Verify that the PLNP feature is on. Enter the **rtrv-feat** command. If the PLNP feature is not on, you must turn it on.
- b. Turn on the PLNP feature. Enter the **chg-feat:plnp=on** command.
- c. Re-enter the **ent-lnp-serv** command specifying **serv=pcs**.

OR

Re-enter the **chg-lnp-serv** command specifying **nserv=pcs**.

Call your Customer Care Center if this error message appears again.

E3250 Cmd Rej: DV must be SCCP when SERV is a user defined type

Commands Used: chg-lnp-serv, ent-lnp-serv

You entered the command and specified one of the user-defined type values (**udf1-udf6**) for the **serv** parameter, but you did not specify a value of **sccp** for the digits valid (**dv** or **ndv**) parameter. If you specify a user-defined type value for the **serv** parameter, you must specify the **dv/ndv=sccp** parameter.

Recovery

Re-enter the command as you entered it originally with a user defined type value for the **serv** parameter and specifying the **dv/ndv=sccp** parameter.

E3251 Cmd Rej: DV must be TCAP when SERV is WNP, AIN, PCS, IN or LNPQS

Commands Used: chg-lnp-serv, ent-lnp-serv

You entered the command and specified either the **wnp**, **ain**, **pcs**, or **in** value for the **serv** parameter, but you did not specify a value of **tcap** for the digits valid (**dv** or **ndv**) parameter. If you specify a value of **lnpqs**, **wnp**, **ain**, **pcs**, or **in** for the **serv** parameter, you must specify the **dv/ndv=tcap** parameter.

Recovery

Re-enter the command as you entered it originally with either **lnpqs**, **wnp**, **ain**, **pcs**, or **in** as the value for the **serv** parameter, specifying the **dv=tcap** or **ndv= tcap** parameter.

E3252 Cmd Rej: A TTN-reserved service type name only if it matches SERV

Commands Used: `chg-lnp-serv`, `ent-lnp-serv`

You specified the **ttn** parameter set to a reserved service type name that did not match the one assigned to the **serv** parameter.

Recovery

Perform one of the following actions:

- Re-enter the command setting the **ttn** parameter to a non-reserved service type name.
 - Re-enter the command setting the **ttn** parameter to match the one assigned to the **serv** parameter.
-

E3266 Cmd Rej: Only 6 message relay services can be assigned

Commands Used: `ent-lnp-serv`

You entered this command to reserve an LNP translation type for a unique LNP service. The available services include up to four query services (**ain**, **in**, **pcs**, and **wnp**), as well as any combination of six message relay or user-defined services. The six message relay services have already been assigned.

Recovery

View a list of defined service types, and verify that six message relay or user-defined services have already been assigned. Enter the `rtrv-lnp-serv` command.

E3269 Cmd Rej: Invalid H0/H1 or NH0/NH1 specified

Commands Used: `chg-scr-sio`, `dlt-scr-sio`, `ent-scr-sio`

You specified a valid combination of the **h0** and **h1** parameters and/or the **nh0** and **nh1** parameters. Table 2-20 lists the valid combinations of the **h0/h1** and **nh0/nh1** parameters:

Table 2-20. Valid Parameter Combinations for an E3269 Error Message

If you specify the h0 (nh0) parameter as:	You can specify the h1 (nh1) parameter as:
A single value	A single value
A single value	A range
A single value	An asterisk (*) entry
A range	An asterisk (*) entry
An asterisk (*) entry	An asterisk (*) entry

Note that, when you enter the **chg-scr-sio** command specifying the **nh0** or **nh1** parameters, the values you specify must be valid with the **h0** or **h1** values currently in the database.

Recovery

Re-enter the command specifying a valid combination of parameters from the preceding table.

E3271 Cmd Rej: NSFI is invalid

Commands Used: `chg-scr-aftpc`, `chg-scr-blkdpc`, `chg-scr-blkopc`, `chg-scr-cdpa`, `chg-scr-cgpa`, `chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-isup`, `chg-scr-opc`, `chg-scr-sio`, `ent-scr-aftpc`, `ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-cdpa`, `ent-scr-cgpa`, `ent-scr-dpc`, `ent-scr-destfld`, `ent-scr-isup`, `ent-scr-opc`, `ent-scr-sio`, `ent-scr-tt`, `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-destfld`, `rtrv-scr-isup`, `rtrv-scr-sio`, `rtrv-scr-tt`

You specified an invalid value for the **nsfi** parameter. Table 2-21 lists by command the valid values for the **nsfi** parameter.

Table 2-21. Valid Values for the **nsfi** Parameter

Commands	Valid Values
chg-scr-aftpc, ent-scr-aftpc, rtrv-scr-aftpc	stop
chg-scr-blkdpc, ent-scr-blkdpc	cgpa, stop, fail, or destfld
chg-scr-blkopc, ent-scr-blkopc	stop, fail, dpc, blkdpc, sio, or cgpa
chg-scr-cdpa, ent-scr-cdpa, rtrv-scr-cdpa	stop or aftpc
chg-scr-cgpa, ent-scr-cgpa	stop, cdpa, or tt
chg-scr-destfld, ent-scr-destfld, rtrv-scr-destfld	stop
chg-scr-dpc, ent-scr-dpc	stop, blkdpc, cgpa, or destfld
chg-scr-opc, ent-scr-opc	stop, sio, dpc, blkopc, blkdpc, or cgpa
chg-scr-sio, ent-scr-sio, rtrv-scr-sio	stop, cdpa, dpc, blkdpc, cgpa, or destfld Specify nsfi=destfld only if si=00 . Specify nsfi=cdpa or nsfi=cgpa only if si=03 . Specify nsfi=isup only if si=05 .
ent-scr-tt, rtrv-scr-tt	stop or cdpa

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a valid **nsfi** parameter.

OR

- Re-enter the command that generated this error message without specifying the **nsfi** parameter.
-

E3272 Cmd Rej: PC does not match existing entry in given SR

Commands Used: `chg-scr-blkdpc`, `chg-scr-blkopc`,
`chg-scr-destfld`, `chg-scr-dpc`, `chg-scr-opc`, `dlt-scr-blkdpc`,
`dlt-scr-blkopc`, `dlt-scr-destfld`, `dlt-scr-dpc`, `dlt-scr-opc`,
`ent-scr-blkdpc`, `ent-scr-blkopc`, `ent-scr-dpc`

The values specified for the area, **id**, **msa**, **narea**, **nc**, **ncm**, **ni**, **nid**, **nnpc**, **npc**, **nsp**, **nssa**, **nzone**, **sp**, **ssa**, or **zone** point code parameters do not match the existing entry specified by the screening reference (**sr**) parameter. The blocked OPC or DPC defined must already exist in the screening reference.

Recovery

1. Determine the valid settings for the point code and screening reference parameters. Enter the `rtrv-scr-blkdpc` command.
 2. Re-enter the command specifying the correct point code parameter value.
 3. Re-enter the command specifying the correct **sr** parameter value.
-

E3273 Cmd Rej: NIC, SI, H0/H1, & PRI entry already exist in given SR

Commands Used: `chg-scr-sio`, `ent-scr-sio`

You entered this command specifying the **h0/h1**, **nic**, **orpri**, **si** parameter set to a value that matches an existing entry specified by the screening reference (**sr**) parameter.

Recovery

1. Determine the valid settings for the screening reference parameter. Enter the `rtrv-scr-sio` command.
2. Re-enter the command specifying the correct screening reference (**sr**) parameter value.

Call your Customer Care Center if this error message appears again.

E3276 Cmd Rej: Command not allowed while in upgrade mode

Commands Used: `act-cdl`, `act-lbp`, `chg-db`, `chg-measopts`,
`dact-cdl`, `dact-lbp`, `inh-alm`, `rept-stat-cdl`, `rept-stat-lfs`,
`rept-stat-tstslk`, `rtrv-measopts`, `tst-slk`, `unhb-alm`

You entered the command while the system was in upgrade mode. The command is not supported in upgrade mode.

Recovery

Wait until the system has completed the upgrade that is in progress; then re-enter the command.

E3278 Cmd Rej: RMIN must be less than or equal to RMAX**Commands Used: chg-assoc**

In the command that you entered, the specified **rmin** parameter value was greater than the specified **rmax** value. The **rmin** parameter value must be less than or equal to the **rmax** parameter value.

Recovery

Re-enter the **chg-assoc** command specifying the **rmin** value less than or equal to the **rmax** value.

E3279 Cmd Rej: CWMIN must be less than or equal 16384 for IPGW associations**Commands Used: chg-assoc**

You entered a command for an IPGWx association, and specified a **cwmin** parameter value greater than **16384**. The **cwmin** parameter value must be less than or equal to **16384** for IPGWx associations

Recovery

Re-enter the **chg-assoc** command specifying the **cwmin** value less than or equal to **16384**.

E3280 Cmd Rej: SLK IPLIML2 requires linkset MTPRSE setting to be no**Commands Used: chg-1s, ent-slk**

You entered a **chg-1s** command to change the **mtpmse** parameter value for a linkset from **no** to **yes**, and the linkset contains IPLIMx M3UA signaling links. The **mtpmse** parameter value must be **no** (**mtpmse=no**) for linksets that contain IPLIMx M3UA signaling links. (Refer to **chg-1s** Recovery procedure).

OR

You entered an **ent-slk** command to add an IPLIMx M3UA signaling link to a linkset, and the linkset has the **mtprse** parameter value set to **yes**. IPLIMx M3UA links must be in a linkset with **mtprse=no**; they do not support MTP Restart procedures. (Refer to **ent-slk** Recovery procedure).

Recovery - **chg-ls**

1. Verify that the linkset contains IPLIMx M3UA links (the IPLIML2 column says M3UA for the link. Enter the **rtrv-slk** command specifying the **lsn** parameter for the linkset for which you want to change the **mtprse** value.
2. If the linkset contains IPLIMx M3UA links, you cannot change the **mtprse** parameter value to **yes** for the linkset.

Refer to the *Database Administration Manual - SS7* for procedures to define linksets and signaling links.

3. If the linkset does not contain IPLIMx M3UA links, re-enter the **chg-ls** command that generated this error.

Call your Customer Care Center if this error message appears again.

Recovery - **ent-slk**

1. Verify that you entered the correct linkset name (**lsn**) in the command.
 2. Enter the **rtrv-ls** command specifying the **lsn** parameter for the linkset to which you want to add the link. Verify the **mtprse** value for the linkset.
 3. If the **mtprse** value for the linkset is **yes**, you must either add the link to another linkset that has **mtprse=no**, or change the **mtprse** value to **no** for this linkset. Refer to the *Database Administration Manual - SS7* for procedures to define linksets and signaling links.
 4. Re-enter the **ent-slk** command that generated this error, to add the link to a linkset that has **mtprse=no**.
-

E3281 Cmd Rej: IPLIML2 is only valid for IPLIMx SLK

Commands Used: **ent-slk**

You specified the **ipliml2** parameter for a signaling link that is not an IPLIMx signaling link. The **ipliml2** parameter is valid only for IPLIMx links.

Recovery

1. If the signaling link is not an IPLIMx signaling link, re-enter the **ent-s1k** command without specifying the **ipliml2** parameter.
 2. If the signaling link is an IPLIMx signaling link, re-enter the **ent-s1k** command specifying the **ipliml2** parameter.
-

E3282 Cmd Rej: All links in linkset must have same IPLIML2 setting

Commands Used: **ent-s1k**

To add an IPLIMx M3UA signaling link to a linkset, you must specify **ipliml2=m3ua**. The **ipliml2** value must be specified as **m3ua** for all links in a linkset that contains M3UA links.

Recovery

1. Enter the **rtrv-s1k** command specifying the card location (**loc**) for the linkset with the new link to be added. Verify the **ipliml2** value for the links in the linkset.
 2. Re-enter the **ent-s1k** command specifying the **ipliml2=m3ua** parameter value for the link.
-

E3285 Cmd Rej: Cannot change existing STP True PC if in MAP table

Commands Used: **chg-sid**

The system's true point code cannot be changed if it is referenced in the mated application (MAP) table.

Recovery

1. Display the system's true point code. Enter the **rtrv-sid** command. The system's true point code is shown in the *PCA* field.
2. Display the mated applications. Enter the **rtrv-map** command. The point codes are shown in the *PCA* field.
3. Delete the system's true point code from the mated applications table. Enter the **dlt-map** command.

4. Re-enter the **chg-sid** command.
 5. Assign the new true point code of the system to the mated applications (MAP) table. Enter the **ent-map** command.
-

E3286 Cmd Rej: STP True PC does not exist in MAP table

Commands Used: **ent-ss-appl**

You attempted to reserve an LNP subsystem number (**ssn**) for an application, but no STP true point code exists in the mated applications (MAP) table.

Recovery

1. View a list of (**pc/pca/pci/pcn**) point codes assigned to the EAGLE 5 ISS. Enter the **rtrv-sid** command.
 2. Assign mated application values to the true point code (**pc/pca/pci/pcn**) and subsystem number (**ssn**). Enter the **ent-map** command.
 3. Re-enter the **ent-ss-appl** command specifying the assigned values for the **pc/pca/pci/pcn** and **ssn**.
-

E3287 Cmd Rej: Map with STP True PC has LNP/INP/EIR SS-APPL assigned

Commands Used: **dlt-map**

You cannot delete a mate application pair (MAP) that has an LNP, INP or EIR subsystem application number assigned.

Recovery

1. Display the applications in the database. Enter the **rtrv-ss-appl** command.
2. Using the output of step 1, perform the following command(s):
 - If an LNP subsystem exists, inhibit the LNPQS subsystem. Enter the **inh-map-ss** command specifying the **ssn** parameter value. Then delete

the application from the LNP database. Enter the **dlt-ss-appl:appl=lnp** command.

- If an INP subsystem exists, delete the application from the INP database. Enter the **dlt-ss-appl:appl=inp** command.
 - If an EIR subsystem exists, delete the application from the EIR database. Enter the **dlt-ss-appl:appl=eir** command.
3. Delete the appropriate MAP. Re-enter the **dlt-map** command specifying values for the **pc/pca** and **ssn** parameters.
-

E3288 Cmd Rej: STP True PC and LNP SSN do not exist in MAP table

Commands Used: **ent-ss-appl**

To reserve an LNP subsystem number (**ssn**) for an application requires an STP true point code/subsystem number combination to be defined in the Mated Applications (MAP) table.

Recovery

1. View the point codes (**pca**) assigned to the EAGLE 5 ISS. Enter the **rtrv-sid** command.
 2. Assign mated application values for the true point code (**pc/pca**) and subsystem number (**ssn**). Enter the **ent-map** command.
 3. Re-enter the **ent-ss-appl** command specifying the newly assigned values for **pc/pca** and **ssn** parameters.
-

E3289 Cmd Rej: Must specify NC when NI is specified for ORIGININC

Commands Used: **rept-meas**

The network cluster (**nc**) parameter must be specified whenever the network indicator (**ni**) parameter is specified.

Recovery

Perform one of the following actions:

- Re-enter the **rept-meas** command specifying the other optional parameter.
- OR
- Re-enter the **rept-meas** command but do not specify the **ni** parameter.

Call your Customer Care Center if this error message appears again.

E3290 Cmd Rej: True PC already exists in MAP table

Commands Used: `ent-map`

You attempted to enter this command specifying an invalid parameter.

Recovery

Re-enter the `ent-map` command that generated this error message specifying the correct parameter.

Call your Customer Care Center if this error message appears again.

E3291 Cmd Rej: Card location specified must be an OAM card

Commands Used: `clr-disk-stats`, `disp-disk-stats`, `init-flash`

You attempted to enter this command specifying an invalid `loc` parameter.

Recovery

Re-enter the command that generated this error message specifying the correct `loc` parameter.

Call your Customer Care Center if this error message appears again.

E3292 Cmd Rej: Must specify either: ENTRY or ROW with COLUMN

Commands Used: `disp-tbl`, `set-tbl`

The command was entered specifying an invalid combination of the `entry`, `row`, and `column` parameters. The `row` parameter must be specified with the `column` parameter. The `entry` parameter cannot be specified with the either the `row` or `column` parameters.

Recovery

Re-enter the command specifying either the `entry` parameter, or the `column` and `row` parameters.

E3293 Cmd Rej: Invalid offset

Commands Used: `disp-tbl`, `set-lba`, `set-tbl`

The value specified for the **offset** parameter was not valid.

Recovery

Re-enter the command specifying the correct **offset** parameter value.

Call your Customer Care Center if this error message appears again.

E3294 Cmd Rej: Security tables may not be altered

Commands Used: `disp-tbl`, `set-lba`, `set-tbl`

The table specified by the **tblid** parameter is either the Security Log, User ID, or Password table. These tables cannot be altered.

Recovery

Re-enter the command specifying the correct **tblid** parameter value.

Call your Customer Care Center if this error message appears again.

E3295 Cmd Rej: DEBUG must be on

Commands Used: `disp-tbl`, `set-lba`, `set-tbl`

The specified command could not be executed because the debug function is turned off.

Recovery

Call your Customer Care Center.

E3296 Cmd Rej: A timeout occurred while processing SCSI Debug Command

Commands Used: `disp-disk-dir`, `disp-lba`, `disp-tbl`, `set-lba`, `set-tbl`, `tst-disk`

A timeout occurred on the SCSI device before or during the processing of this command.

Recovery

Call your Customer Care Center.

E3297 Cmd Rej: Failed reading trouble text table

Commands Used: `set-uim-acthresh`

The system Trouble Text Table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the `set-uim-acthresh` command.

Call your Customer Care Center if this error message appears again.

E3298 Cmd Rej: If specified, BPS must be 2048000 for LIME1ATM Card

Commands Used: `ent-s1k`

You specified parameters for a high-speed link on an E1 ATM card (card type `lime1atm`) and but did not specify **2048000** for the `bps` parameter (`bps=2048000`). For an E1 ATM link, the `bps` parameter value must be **2048000**.

Recovery

Re-enter the `ent-s1k` command specifying `bps=2048000`.

Call your Customer Care Center if this error message appears again.

E3299 Cmd Rej: Network Security Enhancements feature must be ON

Commands Used: `chg-stpopts`

The Network Security Enhancements feature must be enabled and turned on before you can specify the `secmtpmate`, `secmtpsid`, `secmtpsnm`, or `secscpcscmg` parameters.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.

2. Verify that the Network Security Enhancements feature has been purchased and installed in your system. Contact your Customer Care Center for assistance.
3. Enable the Network Security Enhancements feature. Enter the **enable-ctrl-feat** command.
4. Turn on the Network Security Enhancements feature. Enter the **chg-ctrl-feat** command.

Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information.

5. Verify the Network Security Enhancements feature is turned on. Enter the **rtrv-ctrl-feat** command.
 6. Re-enter the command specifying the parameters that generated this error message.
-

E3331 Cmd Rej: ECGSSN cannot be specified without CGSSN

Commands Used: rtrv-gta

You cannot specify the **ecgssn** parameter without specifying the **cgssn** parameter.

Recovery

Perform either one of the following actions:

Re-enter the **rtrv-gta** command specifying the **ecgssn** parameter without specifying the **cgssn** parameter.

OR

Re-enter the **rtrv-gta** command without specifying the **ecgssn** parameter.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again.

E3332 Cmd Rej: GTA, CGPC, OPC and CGSSN are mutually exclusive

Commands Used: chg-gta, dlt-gta, ent-gta, rtrv-gta

The **cgpc**, **cgssn**, **gta** and **opc** parameters are mutually exclusive. Each of these parameters must be specified individually in separate commands.

Recovery

Re-enter the command specifying a value for each of the **cgpc**, **cgssn**, **gta** and **opc** parameters individually in separate commands.

Refer to the *Commands Manual* for the correct values and format for this command parameter.

Call your Customer Care Center if this error message appears again.

E3333 Cmd Rej: Alarm Inhibition Level cannot be changed

Commands Used:

Recovery

Call your Customer Care Center if this error message appears again.

E3404 Cmd Rej: VCI values 0...4 and 6...31 are reserved

Commands Used: **ent-slk**

You cannot specify the values **0...4** and **6... 31** for the Virtual Channel Identifier (**vci**) parameter; these values are reserved system values.

Recovery

Re-enter the command specifying a **vci** parameter value of **5** (the default) or a value from **32...65535**.

E3405 Cmd Rej: LINK must be A if card type is LIMATM or LIME1ATM

Commands Used: **ent-slk**, **rtrv-slk**

You specified the **port/link=b** parameter, and the card's application is **atmansi** (card type **limatm**) or **atmitu** (E1 ATM card type **lime1atm**). If the card's application is **atmansi** or **atmitu**, only the **port/link=a** parameter can be specified.

Recovery

1. Display the card's configuration, using the **rtrv-card** command specifying the card location (**loc**). The card's application is shown in the APPL field of the output.
 2. If the card's application is **atmansi** or **atmitu**, re-enter the command specifying the **port/link=a** parameter.
-

E3406 Cmd Rej: BPS must be 1544000 for LIMATM cards

Commands Used: **ent-slk**

The **bps** parameter value for a **limatm** card must equal **1544000**. If the specified card is a **limatm** card, only the **bps=1544000** parameter can be specified. The value of the **bps** parameter must be **1544000** if the card application is **atmansi**.

Recovery

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location (**loc**). The card's type is shown in the TYPE field of the output.
 2. If the specified card is a **limatm**, re-enter the **ent-slk** command specifying the **bps=1544000** parameter.
-

E3407 Cmd Rej: LSL parameters not valid for card type

Commands Used: **ent-slk**

The parameter values specified for the signaling link (**ecm**, **l1mode**, **l2set**, **pcrn1**, **pcrn2**, and **tset**), are valid only for low-speed signaling links.

Recovery

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location (**loc**). The card's type is shown in the TYPE field of the output.

2. If the card in the specified location is a low-speed card, not a **atmitu** or **limatm** card, re-enter the **ent-slk** command specifying the parameters for low-speed signaling links: **ecm**, **l1mode**, **l2set**, **pcrn1**, **pcrn2**, and **tset**
 3. If the card in the specified location is high-speed card (**atmitu** or **limatm**), re-enter the **ent-slk** command specifying the correct parameters.
 - For ATM high-speed signaling links: **atmtsel**, **ll**, **lpset**, **vci**, and **vpi**
 - For E1 ATM high-speed signaling links: **atmtsel**, **lpset**, **vci**, **vpi**, **e1atmcr4**, **e1atmsi**, and **e1atmsn**
-

E3408 Cmd Rej: ATM parameters not valid for card type

Commands Used: **ent-slk**

The parameter values specified for the signaling link are valid only for high-speed links.

Recovery

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location (**loc**). The card's type is shown in the TYPE field of the output.
 2. If the card in the specified location is a low-speed card, not a **limatm** or **lime1atm** card, re-enter the **ent-slk** command specifying the parameters for low-speed signaling links: **ecm**, **l1mode**, **l2set**, **pcrn1**, **pcrn2**, and **tset**.
 3. If the card in the specified location is a high-speed card (**atmitu** or **limatm**), re-enter the **ent-slk** command specifying the correct parameters.
 - For ATM high-speed signaling links: **atmtsel**, **ll**, **lpset**, **vci**, and **vpi**
 - For E1 ATM high-speed signaling links: **atmtsel**, **lpset**, **vci**, **vpi**, **e1atmcr4**, **e1atmsi**, and **e1atmsn**
-

E3409 Cmd Rej: Max number combined LSLs and ATM HSLs already entered

Commands Used: **ent-slk**

This message appears when you try to enter a low-speed signaling link or an ATM or E1 ATM high-speed signaling link and the system already contains the maximum number of links it can support.

A maximum of **1200**, or **1500** links is allowed, depending on the hardware that is installed. A mixture of ATM and E1 ATM high-speed and low-speed signaling links is supported.

If the addition of either a low-speed signaling link or an ATM or E1 ATM high-speed signaling link exceeds the total number of low-speed and high-speed signaling links allowed in the system, the **ent-slk** command is rejected.

The addition of an ATM or E1 ATM high-speed signaling link decreases the number of low-speed signaling links that can be supported by the system.

For a maximum of **1500** links, Table 2-22 on page 2-478 shows possible low-speed and high-speed link combinations. LIMATM, E1 ATM, and IPLIM cards are equivalent up to the point where slot space constraints prevent equivalency.

Table 2-22. Possible Low-speed and High-speed Link Combinations for 1500 Links

# of ATM or E1 ATM cards	# of 56/64 Kbps links	# of IPLIM cards	# of 56/64 Kbps links
0	1500	0	1500
0	1200	0	1200
1	1199	1	1199
5	1195	5	1195
15	1185	15	1185
20	1180	20	1180
30	1165	30	1165
40	1150	40	1040
60	1110	60	880
80	1025	80	720
90	950	90	560
100	875	100	400
115	800		
100% Traffic(1.0 erlang) per link		100% Traffic(1.0 erlang) per link	

Recovery

For a maximum of **41** ATM and/or E1 ATM high-speed links, perform the following actions:

1. Enter the **rtrv-slk** command to determine the number of low-speed signaling links and ATM and/or E1 ATM high-speed signaling links the system already contains.

ATM high-speed signaling links are of card type **limatm**. E1 ATM high-speed links are of card type **lime1atm**. All other types constitute low-speed links.

2. Use Table 2-22 on page 2-478 to determine the number of low-speed links that the system allows, based on the number of ATM and/or E1 ATM high-speed links the system contains.
3. If you need to add a link to the system and the system already contains the maximum number of allowed links, you must first delete an existing link (use the **dlr-slk** command) and then add the new link to the system.

For a maximum of 115 ATM and/or E1 ATM high-speed links total, perform the following actions:

1. Enter the **rtrv-slk** command to determine the number of low-speed signaling links and ATM and E1 ATM high-speed signaling links the system already contains.

ATM high-speed links are of card type **limatm**. E1 ATM high-speed links are of card type **lime1atm**. IP high-speed links are of card types **iplim** and **iplim1**. All other types constitute low-speed links. Refer to Table 2-22 on page 2-478.

2. If you need to add a link to the system and the system already contains the maximum number of allowed links, you must delete one or more existing links (use the **dlr-slk** command) to allow you to add the new link.
-

E3410 Cmd Rej: Failed reading the ATM link parameter set table

Commands Used: chg-atm-lps

The ATM Parameter Set table is corrupt or cannot be found by the system.

Recovery

Re-enter the **chg-atm-lps** command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3411 Cmd Rej: Specified LPSET contains default values and not configurable

Commands Used: chg-atm-lps

LPSETs 20 and 30 contain system default parameters which can be copied but not changed.

Recovery

To change the parameter value of a **lpset**, re-enter the **chg-atm-lps** command specifying the new value.

E3412 Cmd Rej: SRCLPSET and LPSET cannot be equal

Commands Used: `chg-atm-lps`

You entered this command specifying the same parameter value for both `srclpset`, and `lpset` for an `action=copy`. The `srclpset` parameter provides the value of the source parameter set to be copied. The `lpset` parameter provides the value of the new parameter set.

Recovery

Re-enter the `chg-atm-lps` command specifying a value from 1 to 20 for `srclpset` and a different value from 1 to 19 for `lpset`.

E3413 Cmd Rej: ACTION and SRCLPSET must be specified together

Commands Used: `chg-atm-lps`

The `action` and `srclpset` parameters must both be specified. The `action=copy` parameter indicates that the values for one link parameter set are to be copied to another. The `srclpset` parameter provides the value of the source parameter set to be copied.

Recovery

Re-enter the `chg-atm-lps` command specifying both the `action` and the `srclpset` parameters.

E3414 Cmd Rej: Invalid parameters for ACTION=COPY

Commands Used: `chg-atm-lps`

If the `action=copy` parameter is specified, only the `lpset` and `srclpset` parameters can be specified.

Recovery

Re-enter the `chg-atm-lps` command specifying values for the `lpset` and `srclpset` parameters.

E3415 Cmd Rej: LOC and CLASS cannot be specified together**Commands Used: rtrv-slk**

The **loc** and **class** parameters cannot be specified together in the same command. The **loc** parameter provides information about a single card at a certain location. The **class** parameter provides information about the class of either low-speed or ATM high-speed signaling links, as specified.

Recovery

Re-enter the **rtrv-slk** command specifying either the **loc** or the **class** parameter, but not both.

E3416 Cmd Rej: NI is invalid for type-enttype combo**Commands Used: rept-meas**

You entered this command specifying a value for the network indicator (**ni**) parameter, but **ni** is not a valid entry for this **type-enttype** combination.

Recovery

Re-enter the **rept-meas** command specifying **type=gtwy**, and **enttype=origni** or **enttype=originc**.

E3417 Cmd Rej: NC is invalid for type-enttype combo**Commands Used: rept-meas**

You entered this command specifying a value for the network cluster (**nc**) parameter, but **nc** is not a valid entry for this **type-enttype** combination.

Recovery

Re-enter the **rept-meas** command specifying **type=gtwy** and **enttype=originc**.

E3418 Cmd Rej: Specified BPS is invalid**Commands Used: ent-slk**

The value specified for the bits-per-second (**bps**) parameter is invalid.

Recovery

1. Display the card's configuration. Enter the **rtrv-card** command specifying the card location (**loc**). The card's type is shown in the TYPE field of the output.
2. If the card in the specified location is a low-speed card, not an **limatm** or **lime1atm** card, re-enter the **ent-slk** command specifying a **bps** rate of either **4800, 9600, 19200, 56000, 64000**.
3. If the card in the specified location is a high-speed card (**limatm** or **lime1atm**), re-enter the **ent-slk** command specifying a **bps** rate of either
 - For a **limatm** card, **bps=1544000**
 - For a **lime1atm** card, **bps=2048000**

Table 2-23 provides a list of valid transmission rates for the **bps** parameter.

Table 2-23. Valid Transmission Rates for the **bps** Parameter

Card Application	bps Transmission Rate	Domain
ss7ansi	56000 or 64000	SS7
ss7gx25	4800, 9600, 19200, 56000, or 64000	X.25
ccs7itu	56000 or 64000	SS7
atmansi	1544000	SS7
ss7ansi, ccs7itu (SE-HSL cards)	1984000	SS7
atmitu	2048000	SS7

E3419 Cmd Rej: Day is invalid for type-enttype combination

Commands Used: **rept-ftp-meas**, **rept-meas**

This message appears when the **day** parameter is specified with a **type** and/or **enttype** parameter that is not allowed. The **day** parameter is valid for **type=mtcd** and **enttype=lnp/mapscrn/np/eir** only.

Recovery

Re-enter the command specifying the day parameter with **type=mtcd** and **enttype=lnp/mapscrn/np/eir**.

E3421 Cmd Rej: DSTN5000 feature must be enabled

Commands Used: `chg-stpopts`, `enable-ctrl-feat`

You attempted to turn on a Routesets Feature without the 5000 Routesets Feature first being turned on. The 5000 Routesets Feature must be turned on before you can turn on the 6000, 7000 or 8000 Routesets Feature.

You entered a value for `mtpdpcq` or `mtpxlq` that exceeds the allowable sum of destinations provisioned as determined by adding the values of the `mtpdpcq` and `mtpxlq` parameters ($mtpdpcq + mtpxlq \leq \text{sum}$). Table 2-24 shows the maximum values of `mtpdpcq`, `mtpxlq`, and their sums with a particular Routesets feature turned on.

Table 2-24. Routesets Feature with Maximum Values for the `mtpdpcq` and `mtpxlq` Parameters.

Routesets Feature	Maximum values		
	<code>mtpdpcq</code>	<code>mtpxlq</code>	sum
None	2000	2000	2500
5000	5000	5000	5500
6000	6000	6000	6500
7000	7000	6000	7500
8000	8000	6000	8500

NOTE: once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Perform one of the following Recovery procedures:

Recovery - Turn Routesets Feature On

1. Display the features in the database. Enter the `rt rv-feat` command.
 2. If the DSTN5000 feature is turned on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the DSTN5000 feature is turned off (from the output of step 1), turn it on.
Enter `chg-feat:dstn5000=on` command.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

Recovery - Enter `mtpdpcq` or `mtpxlq` parameter

1. Verify the number of `mtpdpcq` and `mtpxlq` entries currently allocated. Enter the `rtrv-stpopts` command.
 2. Re-enter the command specifying a value for the `mtpdpcq` and `mtpxlq` parameters that does not exceed the command requirements.
-

E3422 Cmd Rej: Echo capability not applicable on originating terminal**Commands Used:** `act-echo`, `canc-echo`

You entered your own terminal ID number for the `trm` parameter value. You cannot echo to the terminal from which the command is issued.

Recovery

Re-enter the command specifying a different value for the `trm` parameter.

E3423 Cmd Rej: Day must be specified when PERIOD=SPECIFIC**Commands Used:** `rept-ftp-meas`, `rept-meas`

This message appears when the `day` parameter is not specified when using `period=specific`. The `day` parameter must be specified when `period=specific`.

Recovery

Re-enter the command specifying the `day` parameter along with `period=specific`.

E3424 Cmd Rej: Invalid parameter for SCCP**Commands Used:** `ent-trace`

You entered a parameter that is invalid for an SCCP card: `entityid`, `dn`, `imei`, `imsi`, `opc`, `dpc`, `tlnpisuptype`, `sspi` and `ssp`. An MSU for an SCCP card can be filtered using one or more of the following parameters: `gt`, `lrn`, `tn`, `ssp`, and `sspa`.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3425 Cmd Rej: Invalid parameter for SS7ANSI, ATMANSI, IPLIM, or SS7IPGW

Commands Used: `ent-trace`

You entered a parameter that is invalid for an ANSI SS7 card running the `ss7ansi`, `atmansi`, `iplim`, or `ss7ipgw` GPL. The invalid parameters are `gt`, `entityid`, `dn`, `imei`, `imsi`, `lrn` and `tn`.

For an ANSI SS7 card, MSUs can be filtered using the following parameters: `ssp/sspa`, `opc/opca`, `dpc/dpca`, and `tlnpisuptype`.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3426 Cmd Rej: ANSI PC parameters are invalid for ITU cards

Commands Used: `ent-trace`

You entered one of the following invalid parameters (ANSI point code parameters) for an ITU SS7 card: `opc`, `opca`, `dpc`, `dpca`, `ssp`, and `sspa`. Valid point code entries would be `opci`, `opcn`, `opcn24`, `dpci`, `dpcn`, `dpcn24`, `sspi`, `sspn`, and `sspn24`.

Recovery

Re-enter the `ent-trace` command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

E3427 Cmd Rej: ITU PC parameters are invalid for ANSI cards

Commands Used: `ent-trace`

You entered one of the following invalid parameters (ITU point code parameters) for an ANSI SS7 card: `opci`, `opcn`, `opcn24`, `dpci`, `dpcn`, `dpcn24`, `sspi`, `sspn`, and `sspn24`. Valid point code entries would be `opc`, `opca`, `dpc`, `dpca`, `ssp`, and `sspa`.

Recovery

Re-enter the **ent-trace** command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3428 Cmd Rej: Invalid parameter for CCS7ITU or IPLIMI**Commands Used: ent-trace**

The following parameters are invalid for ITU SS7 cards running the **ccs7itu** or **iplimi** GPLs: **gt**, **entityid**, **dn**, **imei**, **imsi**, **lrn**, **tn**, and **tlnpisuptye**. For ITU SS7 cards, MSUs can be filtered using one or more of the following parameters: **sspi/sspn**, **opci/opcn**, and **dpci/dpcn**.

Recovery

Re-enter the **ent-trace** command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3429 Cmd Rej: Invalid parameter for VSCCP**Commands Used: ent-trace**

You specified a parameter (**dpc**, **opc**, or **tlnpisuptye**) that is invalid for a VSCCP card. For VSCCP cards, MSUs can be filtered using one or more of the following parameters: **dn**, **entityid**, **gt**, **imsi**, **lrn**, **ssp/sspa/sspi**, and **tn**.

Recovery

Re-enter the **ent-trace** command specifying the correct format and parameters.

Refer to the *Commands Manual* for additional information regarding the command format, parameters, and syntax.

E3431 Cmd Rej: SCCPCNV must be ON before TCAPCNV can be ON**Commands Used: chg-feat**

You cannot enable and turn on the **tcapcnv** feature before the **sccpcnv** feature is enabled and turned on.

Recovery

1. Turn on the SCCPCNV feature. Enter the **chg-feat:sccpcnv=on** command.
 2. Turn on the TCAPCNV feature. Enter the **chg-feat:tcapcnv=on** command
Call your Customer Care Center if this error appears again.
-

E3433 Cmd Rej: DPC parameter must be specified

Commands Used: **inh-alm, unhb-alm**

You must specify the **dpc** parameter value if the **dev=route** parameter is specified.

Recovery

Re-enter the command specifying the **dev=route** parameter and a value for the **dpc** parameter.

Call your Customer Care Center if this error appears again.

E3434 Cmd Rej: The alarms are already inhibited for this device

Commands Used: **inh-alm**

You tried to inhibit the alarm for a device that already has disabled alarms.

Recovery

1. Identify any alarms that have been inhibited. Enter the **rept-stat-trbl** command. The letter *I* after the message reference number (MRN) indicates that the alarm has been inhibited.
 2. Re-enter the **inh-alm** command specifying a device that is not already inhibited.
-

E3435 Cmd Rej: To disable CRITALMINH, critical alarms cannot be inhibited

Commands Used: **chg-stpopts**

You cannot specify the **critalminh=no** parameter if you have critical alarms that are currently inhibited on your system.

Recovery

1. Enter the **rept-stat-trbl** command to identify the critical alarms that have been inhibited. The letter *I* after the message reference number (MRN) indicates that the alarm has been inhibited. Critical alarms are identified by *C. Here is an example:

```
5054.0013I*C CARD 1202 SS7ANSI      Card is isolated from the system
```

2. Enter the **unhb-alm:dev=xxxx** command where **xxxx** is the device type that is inhibited.

Refer to the *Commands Manual* for valid parameter combinations that may be specified with the **dev** parameter.

3. Re-enter the **chg-stpopts** command.

Call your Customer Care Center if this error appears again.

E3436 Cmd Rej: CRITALMINH not set trying to inhibit critical alarms

Commands Used: **inh-alm**

You tried to inhibit critical alarms, but the STP option CRITALMINH has not been enabled. You must first enable this option.

Recovery

1. Enter the **rtrv-stpopts** command. The output shows the current setting (**yes** or **no**) for the CRITALMINH option.
 2. If the output from Step 1 shows that the option is enabled, re-enter the **inh-alm** command that generated this error message.
Call your Customer Care Center if this error message appears again.
 3. If the output from Step 1 shows that the option is disabled, enter the **chg-stpopts:criticalminh=yes** command.
 4. Re-enter the **inh-alm** command that generated this error message.
-

E3437 Cmd Rej: Device alarm inhibit table not accessible

Commands Used: **inh-alm**, **unhb-alm**

The Device Alarm Inhibit table is not accessible and may be corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error appears again.

E3438 Cmd Rej: Lvl 1 Removable detected during upgrade**Commands Used: act-upgrade**

The removable cartridge required for the upgrade has upgrade phase indicators. The upgrade command expects the disks to be in certain phases before executing a specific action. This message occurs if you swap out the removable cartridge at some point during the upgrade, so that the disk is no longer in the expected phase.

Recovery

If you have swapped out the removable cartridge, re-insert the removable cartridge that you were using for the upgrade.

OR

1. Determine the status of the removable cartridge. Enter the **act-upgrade:action=dbstatus** command.
 2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.
-

E3439 Cmd Rej: Standby TDM in unknown upgrade mode**Commands Used: act-upgrade**

The TDMs have upgrade phase indicators. The upgrade command expects the disks to be in certain phases before executing a specific action. This message appeared because the standby TDM is not in the correct phase.

Recovery

1. Display the current database status. Enter the **act-upgrade:action=dbstatus** command.
 2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.
-

E3440 Cmd Rej: Active TDM in unknown upgrade mode**Commands Used: act-upgrade**

The TDMs have upgrade phase indicators. The upgrade command expects the disks to be in certain phases before executing a specific action. This message appeared because the active TDM is not in the correct phase.

Recovery

1. Display the current database status. Enter the **act-upgrade:action=dbstatus** command.
 2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.
-

E3441 Cmd Rej: Removable in unknown upgrade mode**Commands Used: act-upgrade**

The removable cartridge has upgrade phase indicators. The upgrade command expects the disk to be in certain phases before executing a specific action. This message appeared because the disk is not in the correct phase.

Recovery

1. Display the current database status. Enter the **act-upgrade:action=dbstatus** command.
 2. Follow the recovery procedure in the upgrade procedure documentation, or contact your Customer Care Center.
-

E3442 Cmd Rej: Removable is from previously aborted upgrade**Commands Used: act-upgrade**

The upgrade command specifying the **convertstp** action runs from upgrade phase 0 to upgrade phase 3 unless an anomaly occurs that causes the command to terminate.

Recovery

1. Take whatever action is necessary to correct the anomaly.
 2. Re-enter the **act-upgrade:action=convertstp** command.
-

E3443 Cmd Rej: THRES parameter valid only with CONVERTNET/CONVERTSTP

Commands Used: `act-upgrade`

You cannot specify the **thres** parameter without specifying the **convertnet** or **convertstp** parameters.

Recovery

Perform one of the following actions:

- Re-enter the **act-upgrade** command without specifying the **thres** parameter.
OR
- Re-enter the **act-upgrade** command specifying the **thres** parameter and the **convertnet** parameter.
OR
- Re-enter the **act-upgrade** command specifying the **thres** parameter and the **convertstp** parameter.

Call your Customer Care Center if this error appears again.

E3444 Cmd Rej: MTP Restart Indicator must be off to execute this command

Commands Used: `act-upgrade`

You entered an **act-upgrade** command when the MTP Restart Indicator STP option is set to on. Upgrades are not allowed when the MTP Restart Indicator STP option is set to on.

NOTE: You can enter the **act-upgrade:action=dbstatus** command when the MTP Restart Indicator STP option is on, but no other **act-upgrade** command actions are allowed.

Recovery

1. Turn off the MTP Restart Indicator STP option. Enter the **chg-stpopts:mtprsi=no** command.
 2. Re-enter the **act-upgrade** command.
-

E3445 Cmd Rej: Connection not compatible with SLK IPLIML2 setting

Commands Used: `chg-appl-sock`, `ent-appl-sock`, `chg-assoc`, `ent-assoc`

You specified the **lhost** parameter for a local host on an IPLIMx card. The local host connection is not valid for the setting of the **ipliml2** parameter for the signaling link assigned to the specified local host connection.

For the `ent-appl-sock` or `chg-appl-sock` command, the signaling link for the local host connection on an IPLIMx card must have the **ipliml2** parameter set to **saaltali**, **m2pa**, or **m3ua**.

For the `ent-assoc` or `chg-assoc` command, the signaling link for the local host connection must have the **ipliml2** parameter set to **m2pa** or **m3ua**.

Recovery

1. Enter the `rtrv-ip-host` command to display the IP address for the local host.
2. Enter the `rtrv-ip-lnk` command to display the card location for the local host IP address.
3. Enter the `rtrv-slk` command for the card location, to display the **ipliml2** settings for the links assigned to the signaling link ports on the card.

Refer to the *Database Administration Manual - IP⁷ Secure Gateway* for information on signaling link and socket or association assignments.

- If **saaltali** is shown in the IPLIML2 column from step 3 for the link assigned to the local host signaling link port, you must enter a command that defines a socket connection for the local host.
 - If **m2pa** or **m3ua** is shown in the IPLIML2 column from step 3 for the link assigned to the local host signaling link port, you must enter a command that defines an association connection for the local host.
-

E3446 Cmd Rej: SLK not provisioned for assigned Lhost

Commands Used: `chg-appl-sock`, `chg-assoc`

You entered a command to change the local host IP address, and the new local host has no signaling link assigned to its associated signaling link port.

Recovery

1. Enter the `rtrv-ip-host` command to display the IP address for the new local host.

2. Enter the **rtrv-ip-lnk** command to display the card location for the new local host IP address.
 3. Enter the **rtrv-slk** command for the card location to display the linksets containing links assigned to the signaling link ports for the card.
 4. If there is no linkset shown for the local hosts signaling link port, assign a link to the signaling link port for the new local host.

Refer to the procedures in the Database Administration Manual - IP⁷ *Secure Gateway* for assigning links and linksets.
 5. Re-enter the command to change the local host IP address.
-

E3447 Cmd Rej: IPLIMx connections cannot be resident in AS

Commands Used: **chg-assoc**

You entered a **chg-assoc** command to move an association having an M3UA/SUA association assigned to an application server (AS). The command is to move the association from a card running the **ss7ipgw** or **ipgwi** application to a card running the **iplim** or **iplimi** application. IPLIMx M3UA/SUA associations cannot be assigned to an AS.

Recovery - **chg-assoc**

1. Display the current local host name. Enter the **rtrv-assoc** command.
2. Verify that the association is bound to an M3UA/SUA association that is assigned to an AS. Enter the **rtrv-as** command.
3. Display the card location for the association's current local host and new local host. Enter the **rtrv-ip-lnk** command.
4. Verify the application that is running on each local host card. Enter the **rtrv-card** command.

If the current host application is **ss7ipgw** or **ipgwi** and the new local host card application is **iplim** or **iplimi**, you cannot move the association to that new local host.

Refer to the *Database Administration Manual - IP⁷ Secure Gateway* for the procedures to define and change associations.

E3448 Cmd Rej: LHOST has open socket or association

Commands Used: `chg-ip-lnk`, `dlt-slk`

You entered a command to change the local host IP address. The local IP address cannot be changed if the current or new local host has open sockets or associations (the **open** parameter set to **yes** using the **ent-assoc** or **chg-assoc** command).

OR

You entered a command to delete an IPLIMx or IPGWx signaling link assigned to a local host that has a socket or association with connection status **open=yes**. The socket or association connection status must be **open=no** before you can delete the link.

Recovery - `chg-ip-lnk`

1. Display the host name for the current and new local host. Enter the `rtrv-ip-host` command.
 2. Display connection status (**open**) for the sockets. Enter the `rtrv-appl-sock` command for the current and new host names.
 3. Change the connection status of each open socket to **no** for the current and new local hosts. Enter the `chg-appl-sock` command.
 4. Re-enter the `chg-ip-lnk` command to change the local host IP address.
-

Recovery - `dlt-slk`

1. Display the host name for the local host. Enter the command `rtrv-ip-host`.
 2. Enter the `rtrv-assoc` command for the local host name to display connection status (**open**) for the associations.
 3. Enter the `chg-assoc` command to change the connection status of each open association to **no** for the local host.
 4. Re-enter the command to delete the signaling link.
-

E3449 Cmd Rej: Command not supported with current IPLIML2 setting

Commands Used: `alw-slk`, `inh-slk`, `tst-slk`, `unhb-slk`

You entered a command to test (**loopback-sltc**) inhibit, or allow/uninhibit an IPLIMx signaling link that has an **ipliml2** parameter setting of **m3ua**. These commands are not allowed for an IPLIMx M3UA signaling link.

Recovery

1. Display the IPLIML2 setting for the signaling link. Enter the **rtrv-slk** command.
 2. If the IPLIML2 setting is **m3ua** for the link, you cannot use the commands to test, inhibit, or allow/uninhibit the link.
-

E3450 Cmd Rej: Invalid Part Number

Commands Used: **chg-ctrl-feat**, **enable-ctrl-feat**

The system does not recognize the **partnum** parameter value that you entered.

The **partnum** parameter value must be nine digits, without any dashes. The first three digits are **893**. The next six values are numeric (**0...9**).

Recovery

Re-enter the command specifying the correct part number for the feature.

Call your Customer Care Center if this error appears again.

E3451 Cmd Rej: Controlled Feature is not enabled

Commands Used: **chg-ctrl-feat**, **chg-trm**, **ent-pstn-pres**,
chg-pstn-pres, **dlt-pstn-pres**, **rtrv-pstn-pres**,
copy-isupvar-attrib, **chg-isupvar-attrib**, **rtrv-isupvar-attrib**

You entered the **chg-ctrl-feat** command to turn a feature on or off. However, the specified feature has not been enabled in the system.

OR

You entered the **chg-trm** command specifying the **trm** parameter with a value greater than **16** and the IPSM card is equipped. The IP User Interface (Telnet) feature must be enabled using the **enable-ctrl-feat** command and turned on using the **chg-ctrl-feat** command before you can specify a Telnet terminal, that is, a terminal (**trm**) set to value greater than **16**.

OR

The command you entered requires the ISUP Normalization feature to be enabled and possibly a feature for a Tekelec-defined or user-defined ISUP Normalization Variant to be enabled.

Recovery - chg-ctrl-feat

Display the status of the features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.

- If the feature is enabled, re-enter **chg-ctrl-feat** command specifying the appropriate part number to change the on/off status.
 - If the feature is disabled, enable the desired feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information before attempting to turn it on.
-

Recovery - chg-trm

Either change the **trm=1** value to **16**, for a non-Telnet terminal and re-enter the **chg-trm** command.

OR

1. Enable the IP User Interface (Telnet) feature to support Telnet terminals (**trm=value** or greater).
2. To enable the Telnet feature, enter the command **rtrv-trm** to display the terminals and their types.
3. Display the features that are controlled using feature access keys in the system. Enter the **rtrv-ctrl-feat** command.
4. Using the output from step 3, verify the IP User Interface (Telnet) feature has been purchased and installed in your system. Contact your Customer Care Center for assistance.
5. If the Telnet feature has been purchased and installed in your system, use the output from step 3 to verify its status.

Refer to the *Database Administration Manual - System Management* for instructions on how to enable and turn on the IP User Interface (Telnet) feature and any prerequisite features (if any) that must be turned on.

6. When the Telnet feature is turned on in the system, re-enter the **chg-trm** command specifying the parameter that requires the Telnet feature to be on. Call your Customer Care Center if this error appears again.
-

Recovery pstn-pres and isupvar-attrib

1. Display the status of features in your system, and check for the ISUP Normalization feature. Enter the **rtrv-ctrl-feat** command.

Refer to the ISUP Variant procedures in the *Database Administration Manual - IP⁷ Secure Gateway* Manual and the *Commands Manual* to enable each required feature.

2. When the feature is enabled, re-enter the command.
-

E3452 Cmd Rej: Invalid Feature Access Key

Commands Used: `enable-ctrl-feat`

The `fak` parameter value that you entered has one of the following conditions:

- Does not meet one of the following naming conventions:
 - Must be a 13-character alphanumeric (A...Z, a...z, or 0...9) symbol.
 - First character must be an alphabet letter.
 - String can not include any special characters, including space.
 - Format: [A...Z] | [a...z] | [0...9]. Capital letters are always mapped to lower case.
- Does not correspond to the **partnum** parameter you entered.
- Does not correspond to the serial number in the database.

Recovery

Re-enter the command ensuring you follow the naming conventions.

Call your Customer Care Center if this error appears again.

E3453 Cmd Rej: Invalid system serial number in database

Commands Used: `enable-ctrl-feat`

The serial number entered is not in the system database, or does not meet one of the following naming conventions:

- Must be a 15-character alphanumeric (A...Z, a...z, or 0...9) symbol.
- First two characters must be alphabet letters.
- Remaining characters must be numeric.
- String can not include any special characters, including space.
- Format: [A...Z] | [a...z] | [0...9].

Recovery

1. Display the system serial number that is in the database. Enter the `rtrv-serial-num` command.
2. Re-enter the `enable-ctrl-feat` command specifying the correct serial number. Follow the naming conventions listed above.

Call your Customer Care Center if this error appears again.

E3454 Cmd Rej: Routesets Feature Quantity must be increased

Commands Used: `chg-stpopts`

The number of routes being set beyond **5000** is more than the Feature Quantity Key will allow. Before you can change the value of the MTP destination point code quantity (`mtpdpcq`) or the MTP x-list quantity (`mtpxlq`) parameters, you must first turn on the correct Routesets Feature.

The allowable sum of destinations provisioned is determined by adding the values of the `mtpdpcq` and `mtpxlq` parameters ($mtpdpcq + mtpxlq \leq \text{sum}$). Table 2-25 shows the maximum values of `mtpdpcq`, `mtpxlq`, and their sums with a particular Routesets Feature turned on.

NOTE: The values of the `mtpdpcq` and `mtpxlq` parameters are interdependent; that is, if you want to increase the number of DPCs that can be provisioned, you must decrease the number of x-list entries that the STP is to maintain. Conversely, if you increase the number of x-list entries that the STP maintains, you must decrease the number of DPCs that can be provisioned.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off with the `chg-ctrl-feat` command. Refer to the appropriate Database Administration Manual and the Commands Manual for more information about enabling features with access keys.

Table 2-25. Routesets Feature with Maximum Values for the `mtpdpcq` and `mtpxlq` Parameters.

Routesets Feature	Maximum values		
	<code>mtpdpcq</code>	<code>mtpxlq</code>	sum
5000	5000	5000	5500
6000	6000	6000	6500
7000	7000	6000	7500
8000	8000	6000	8500

Recovery

1. Display the status of features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.
2. Verify that the correct Routesets feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the Routesets feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual - SS7* for more information about enabling this feature.

4. Re-enter the **chg-stpopts** command that generated this error message.
-

E3455 Cmd Rej: SCTP Association or SLK provisioned: Card supports 2 links

Commands Used: **ent-slk**

You cannot specify more than two signaling links on an IPLIMx card running on a DCM.

The IPLIM/IPLIMI application supports up to eight SAALTAI signaling links on SSEDCM cards only.

Recovery

Re-enter the **ent-slk** command and limit the number of signaling links to two for DCMs configured as IPLIM or IPLIMI.

E3456 Cmd Rej: LNP ELAP Configuration feature must be ON

Commands Used: **enable-ctrl-feat**

You must enable the LNP ELAP Configuration feature before enabling these features:

- LNP ported TN feature access key for 24 Million TNs or greater
- LNP ported NPANXX 300K quantity key enabling
- LNP ported LRN 150K quantity key enabling

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.
2. If the LNP ELAP Configuration feature is turned on, re-enter the **enable-ctrl-feat** command that generated this error message.
3. If the LNP ELAP Configuration feature is turned off:

- Verify that you have purchased and installed the correct features for your system. Contact your Customer Care Center if you need assistance.
- Enable the LNP ELAP Configuration feature. Enter the **chg-ctrl-feat** command and the appropriate part number and access key information. Turn on the feature. Enter the **chg-ctrl-feat** command.

Refer to the *Commands Manual and LNP Feature Activation Guide for the details*

- To enable any of these features.
 - LNP ported TN feature access key for 24 Million TNs or greater
 - LNP ported NPANXX 300K quantity key enabling
 - LNP ported LRN 150K quantity key enablingRe-enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E3457 Cmd Rej: Perm feature key cannot be turned off for the feature

Commands Used: **chg-ctrl-feat**

You cannot turn off a permanently on feature. Once a permanent feature access key is turned on, it cannot be turned off.

Refer to the Commands Manual (**enable-ctrl-feat**) for a list of permanently on controlled features.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the status of the enabled controlled features. Enter the **rtrv-ctrl-feat** command.
 2. Verify the status of the feature that you tried to turn off.
 3. If the feature is turned on, you cannot turn it off with the **chg-ctrl-feat** command. Call your Customer Care Center if you need assistance with turning features on and off.
-

E3458 Cmd Rej: LNP ported TNs 4million Qty Feat Require at least TSM512MB**Commands Used: enable-ctrl-feat**

You cannot enable the LNP Ported TNs 4 Million Quantity Key feature. Not all TSM cards have at least **512** MB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient memory quantity.
 2. Re-enter the **enable-ctrl-feat** command.
Call your Customer Care Center if this error message appears again.
-

E3459 Cmd Rej: LNP ported TNs 6million Qty Feat Require at least TSM768MB**Commands Used: enable-ctrl-feat**

You cannot enable the LNP Ported TNs 6 Million Quantity Key Feature. Not all TSM cards have at least **768** MB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient memory quantity.
 2. Re-enter the **enable-ctrl-feat** command.
Call your Customer Care Center if this error message appears again.
-

E3460 Cmd Rej: LNP ported TNs 8million Qty Feat Require at least TSM1GB**Commands Used: enable-ctrl-feat**

You cannot enable the LNP Ported TNs 8 Million Quantity Key Feature. Not all TSM cards have at least **1** GB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient memory quantity.
2. Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3461 Cmd Rej: LNP ported TNs 12million Qty Feat Req at least TSM/DSM1GB

Commands Used: enable-ctrl-feat

You cannot enable the LNP Ported TNs 12 Million Quantity Key Feature. Not all TSM cards or DSM cards have at least 1 GB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient (at least 1 GB) memory quantity.
2. Re-enter the **enable-ctrl-feat** command.

Call your Customer Care Center if this error message appears again.

E3462 Cmd Rej: LNP ported TNs 24million Qty Feat Require at least DSM2GB

Commands Used: enable-ctrl-feat

You cannot enable the LNP Ported TNs 24 Million Quantity Key Feature. Not all DSM cards have at least 2 GB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient memory quantity.
2. Re-enter the **enable-ctrl-feat** command.

Call your Customer Care Center if this error message appears again.

E3463 Cmd Rej: LNP ported TNs 36million Qty Feat Require at least DSM3GB

Commands Used: enable-ctrl-feat

You cannot enable the LNP Ported TNs 36 Million Quantity Key Feature. Not all DSM cards have at least 2 GB of memory. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient memory quantity.
 2. Re-enter the **enable-ctrl-feat** command.
Call your Customer Care Center if this error message appears again.
-

E3464 Cmd Rej: LNP ported TNs 48 to 192 M Qty Feat Req at least DSM4GB**Commands Used: enable-ctrl-feat**

You cannot enable an LNP Ported TNs feature for a quantity greater than 48 million TNs. Not all DSM cards have at least 4 GB. You need to upgrade your hardware.

Recovery

1. Upgrade your hardware with a sufficient memory quantity.
 2. Re-enter the **enable-ctrl-feat** command.
Call your Customer Care Center if this error message appears again.
-

E3465 Cmd Rej: STPOPTS HMUXTVG must be turned on for this feature**Commands Used: chg-ctrl-feat**

You entered the command to enable the 6000 Routesets controlled feature. However, this command cannot be executed due to a possible error in the STP Options table. Call your Customer Care Center for assistance.

Recovery

1. If you have purchased and installed the 6000 Routesets controlled feature, re-enter the **enable-ctrl-feat** and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual - SS7* for more information about turning on this feature.
 2. Turn on the feature. Enter the **chg-ctrl-feat** command.

Call your Customer Care Center if this error message appears again. Report this error code and that the STP Options table appears to be in error.
-

E3466 Cmd Rej: SSO parameter is not compatible with True PC

Commands Used: `chg-map`, `ent-map`

You attempted to specify an SSO parameter that is incompatible with the True point code.

Recovery

Perform one of the following actions:

- Re-enter the command changing the subsystem status option parameter.
- OR
- Re-enter the command altering the primary and/or mate remote point code.
-

E3467 Cmd Rej: FTP SERV table must contain one entry with application USER

Commands Used: `act-ftp-trns`

You entered a command to activate an FTP transfer on the EAGLE 5 ISS, but the FTP Server table does not have an entry specifying the application USER.

Recovery

1. Enter the `rtrv-ftp-serv` command to display the information for the FTP Servers that are defined in the FTP Server table.
 2. Re-enter the `act-ftp-trans` command for the FTP Server, ensuring at least one entry specifies the application USER.
-

E3468 Cmd Rej: FTP transfer already in progress

Commands Used: `act-ftp-trns`

You entered a command to activate an FTP transfer on the EAGLE 5 ISS, but an FTP Server transfer is currently in progress.

Recovery

The FTP transfer is currently in progress. Re-enter the `act-ftp-trns` command later when the current transfer has completed.

E3469 Cmd Rej: M2PATSET requires M2PA adapter type

Commands Used: `chg-assoc`, `ent-assoc`

You entered a command that requires the M2PA adapter to be specified. When you specify the `m2patset` parameter, you must also specify `adapter=m2pa`.

For more information, refer to the *Commands Manual*.

Recovery

Re-enter the command that generated this error message specifying `adapter=m2pa`.

Call your Customer Care Center if this error message appears again.

E3470 Cmd Rej: SRCTSET and TSET cannot be equal

Commands Used: `chg-m2pa-tset`

You cannot specify the same parameter value for both `srctset` and `tset`. The `srctset` parameter indicates which timer set is to be copied into the timer set specified by the `tset` parameter. The `tset` parameter provides the value of the new parameter set. The timer set specified by `srctset` cannot be the timer specified by `tset`.

Recovery

Re-enter the `chg-m2pa-tset` command specifying a value for `srctset` from 1 to 20 and a different value for `tset` also in the range from 1 to 20.

E3473 Cmd Rej: The last active serial port cannot be inhibited

Commands Used: `inh-trm`

The `inh-trm` command does not permit the user to inhibit all serial ports from a Telnet user. One serial port must remain active and available for login and must be of the terminal type capable of entering commands, such as the VT100, KSR, MGMT, or SCCS.

Recovery

1. Display all the terminals. Enter the `rtrv-trm` command.
 2. With the output from step 1 as a guide, re-enter the `inh-trm` command for only appropriate terminals.
-

E3474 Cmd Rej: MO SMS feature must be activated

Commands Used: `chg-srvsel`, `ent-home-smsc`, `ent-srvsel`

If using the `ent-home-smsc` command, you entered a command involving Home SMSC specific addresses, which identify Short Message Center Service Centers. Before you can perform this function, you must first turn on the MO SMS (Portability Check for Mobile Originated SMS) feature.

If using the `ent-srvsel` or `chg-srvsel` command, you specified `serv=mnpsms` or `nserv=mnpsms` without having already enabled and turned on the MO SMS (Portability Check for Mobile Oriented SMS) feature.

Recovery

1. Enter the `rtrv-ctrl-feat` command to display the status of features in your system that have feature access keys.
2. Verify that the MO SMS (Portability Check for Mobile Originated SMS) feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. If you have purchased and installed the MO SMS Feature in your system, you must use the `enable-ctrl-feat` and `chg-ctrl-feat` commands to enable and turn on the MO SMS feature.

NOTE: To fully utilize the MO SMS feature in your system, you must use both the `enable-ctrl-feat` and `chg-ctrl-feat` commands first to enable and then to turn on the feature. Refer to the *Commands Manual* for more information about activating (that is, enabling and turning on) this feature.

4. With the feature turned on, re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3475 Cmd Rej: Failed reading HOME SMSC ADDRESS table

Commands Used: `dlt-home-smsc`, `ent-home-smsc`, `rtrv-home-smsc`

The Home SMSC Address table is corrupt or cannot be found by the system. This table contains the HOME SMSC specific addresses.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3476 Cmd Rej: SMSC ADDR to be deleted does not exist in database**Commands Used: dlt-home-smsc**

The command cannot find the SMSC address specified by the **smsc** parameter.

Recovery

Perform one of the following actions:

- Verify that the SMSC address was entered correctly, and re-enter the **dlt-home-smsc** command.

OR

- Verify the SMSC address is not present. Enter the **rtrv-home-smsc** command specifying the **smsc** parameter.
-

E3477 Cmd Rej: SMSC Address already exists**Commands Used: ent-home-smsc**

The specified SMSC Address entry already exists in the database.

Recovery

Perform one of the following actions:

- Verify that the SMSC address was entered correctly, and re-enter the **ent-home-smsc** command.

OR

- Verify the SMSC address is already present. Enter the **rtrv-home-smsc** command specifying the same **smsc** parameter value.
-

E3478 Cmd Rej: Home SMSC Table is full**Commands Used: ent-home-smsc**

The specified address cannot be entered into the Home SMSC Address table because the Home SMSC table is full.

Recovery

1. Display the Home SMSC Address table. Enter the **rtrv-home-smsc** command.
 2. Delete an existing entry from the table. Enter the **dlt-home-smsc** command.
 3. Re-enter the **ent-home-smsc** command to add the address entry into the table.
-

E3479 Cmd Rej: MO SMS feature must be enabled

Commands Used: **dlt-home-smsc**, **rtrv-home-smsc**

You entered a command involving Home SMSC specific addresses, which identify Short Message Center Service Centers. Before you can perform this function, you must first enable the MO SMS (Portability Check for Mobile Originated SMS) feature.

Recovery

1. Enter the **rtrv-ctrl-feat** command to display the status of features in your system that have feature access keys.
2. Verify that the MO SMS (Portability Check for Mobile Originated SMS) feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. If you have purchased and installed the MO SMS Feature in your system, you must use the **enable-ctrl-feat** command to enable the feature.

NOTE: Before you can fully utilize the MO SMS feature in your system, you must use the **enable-ctrl-feat** and **chg-ctrl-feat** commands first to enable and then to turn on the feature. Refer to the *Commands Manual* for more information about activating (that is, enabling and turning on) this feature.

4. With the feature enabled, re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3481 Cmd Rej: S/ESLOT cannot be set to 9 or 10

Commands Used: **rept-imt-info**

The Start or End slot locations for HIPR or SIFB statistics for cards on the HIPR or SIFB shelf cannot be set to **9** or **10**. Valid range for S/ESLOT is **1-8** and **11-18**.

Recovery

Re-enter the `rept-imt-info` command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command.

E3482 Cmd Rej: Link capacity exceeds limit allowed by SE-HSL feature key

Commands Used: `ent-slk`

The signaling link capacity is full. You cannot provision additional signaling links until the capacity is increased. The HC-MIM SLK Capacity feature access key allows additional links to be provisioned per HC-MIM card as listed below.

- default quantity is **16** per card, allowing link **A** to **A7**, **B** to **B7**
- **24** quantity feature access key allows **A** to **A11** and **B** to **B11**
- **32** quantity feature access key allows **A** to **A15** and **B** to **B15**
- **40** quantity feature access key allows **A** to **A19** and **B** to **B19**
- **48** quantity feature access key allows **A** to **A23** and **B** to **B23**
- **56** quantity feature access key allows **A** to **A27** and **B** to **B27**
- **64** quantity feature access key allows **A** to **A31** and **B** to **B31**

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display a list of features controlled by a feature access key in the system. Enter the `rtrv-ctrl-feat` command.
 2. Verify the HC-MIM SLK quantity feature access key is installed.
 3. To provision signaling links beyond the quantity feature installed, contact your Tekelec Sales Representative for assistance in purchasing another HC-MIM SLK quantity feature.
-

E3483 Cmd Rej: CAS=ON is not supported on this card

Commands Used: `ent-e1`, `chg-e1`

You cannot specify the `cas=on` parameter for the HC-MIM card. **You cannot specify the `cas=on` parameter when `chanbrdg=on` has been specified.** You cannot specify the `cas=on` parameter for port value 3 to 8.

Recovery

Re-enter the command without specifying the `cas=on` parameter.

Refer to the *Commands Manual* for valid combination of parameters for the specific command.

E3484 Cmd Rej: Interface to a channel card is not supported

Commands Used: `ent-s1k`

The card location specified is not supported. . The `elloc/tlloc` parameters are not valid for the E5-E1/T1 card or the HC-MIM card. The new E5-E1T1 also does not support the Channel card interface. HC-MIM cards cannot be used as or with Channel cards.

Recovery

Re-enter the `ent-s1k` command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the `ent-s1k` command.

E3485 CMD Rej: CHANBRDG is not supported on this card

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

The location specified is not an HC-MIM card. The `chanbrdg` parameter can be specified for HC-MIM and E5-E1/T1 cards. The `chanbrdg=on` parameter is not valid if a low capacity MIM card is present

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3486 Cmd Ref: CHANBRDG parameter is invalid for even numbered port

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

An odd-numbered port must be specified. The `chanbrdg=on` parameter indicates whether an odd-numbered port is to pair with its even-numbered port for non-signaling data pass through. The `chanbrdg=on` parameter cannot be specified for an HC-MIM card for even-numbered T1 ports.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3487 Cmd Rej: Timing Source must be specified if CHANBRDG=ON is specified

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

The timing source parameter `e1tsel` or `t1tsel` must be specified if `chanbrdg=on` is specified. The timing source is **master** (internal), **slave** (line), or **recovered** from its paired port. The **recovered** option is only valid for a port that is in channel bridging (`chanbrdg=on`) mode.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3488 CMD Rej: RECOVERED is allowed only in channel bridging mode

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

The **recovered** option is only valid for a port that is in channel bridging (`chanbrdg=on`) mode. The `e1tsel=recovered` parameter cannot be specified if the specified HC-MIM E1 port is not in channel bridging (`chanbrdg=on`) mode.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3489 Cmd Rej: Adjacent even numbered port has signaling link assigned

Commands Used:

All signaling links assigned to its adjacent even-numbered port must be deleted before provisioning the port into channel bridging mode.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3490 Cmd Rej: HIPR must be equipped on the shelf for this card

Commands Used: `chg-t1`, `ent-slk`, `ent-e1`, `ent-t1`

HIPR cards must be in card locations **xy09** and **xy10** (*x* is the frame, *y* is the shelf)

- On any shelf that contains one or more HC-MIM cards. When **link** parameter values **a4-a31** and **b4-b31** are specified, the system verifies that HIPR cards are in card locations **xy09** and **xy10** on the same shelf with the specified HC-MIM card.
- On each shelf that contains one or more HC-MIM cards that are used as SE-HSL (**linkclass=unchan**) cards.
- On each shelf that contains one or more HC-MIM cards that are used as E1 cards. The system checks for HIPR cards when HC-MIM E1 ports **3** through **8** are specified.
- On each shelf that contains one or more HC-MIM cards that are used as T1 cards. The system checks for HIPR cards when HC-MIM T1 ports **3** through **8** are specified.

A HIPR card must be equipped in the same shelf where the HC-MIM card resides (**loc**) when provisioning:

- **ent-e1**: ports **3** through **8**
- **ent-t1**: ports **3** through **8**
- **ent-slk**: link **A4, B4,...A31, B31**
- SE-HSL (**linkclass=unchan**)

Recovery

1. Display the cards on the shelf. Enter the **rtrv-card** command. The card type appears in the TYPE column for each card in the system. The card location appears in the CARD column; the first two digits of the location are the frame and shelf number where the card is installed
 2. Verify the HIPR card is equipped in the same shelf as the HC-MIM card for the port/link to be provisioned.
 3. Re-enter the command specifying the correct **loc** parameter.
-

E3491 Cmd Rej: Port is channel bridged with its master port

Commands Used: **chg-e1, dlt-e1, chg-t1, dlt-t1, ent-slk**

Provisioning of a bridged slave E1/T1 port is not allowed while channel bridging is activated.

Recovery

Re-enter the command specifying a channel bridged master E1/T1 port instead.

E3492 Cmd Rej: ADD/DROP mode provisioned FORCE=YES required

Commands Used: **inh-card**

If channel bridging (Add/Drop mode) is active then **FORCE=YES** is required to inhibit the card. Force removal of the card. This parameter is required if the card is the last card supporting a linkset, SCCP subsystem, Measurement Platform Subsystem, EPAP-to-DSM connection, E1, or GLS. Also if the TDM contains a security log with un-uploaded entries or any other TDM process in progress.

Recovery

Re-enter the **inh-card** command.

E3493 Cmd Rej: MULTCC entry already exists in the GSM Options CC list

Commands Used: `chg-gsmopts`, `chg-stpopts`

You attempted to specify an entry in the GSM Options MULTCC List, but the command failed because the country code already exists there. The attempted entry was either the defcc (`chg-stpopts` command) or the multcc (`chg-gsmopts` command).

Recovery

1. If the specified value already entered is acceptable, no change is required since that value already exists.
2. If the defcc or multcc value already entered is not acceptable, change the value by performing one of the following commands:

To change a defcc value, enter `chg-gsmopts:multcc=xxx:nmultcc=none`, which deletes the value xxx. Next enter `chg-stpopts:defcc=xxx` to assign a Default Country Code to the GSM Options MULTCC list.

To change a multcc value, enter `chg-gsmopts:multcc=xxx:nmultcc=yyy`, which replaces the value xxx with value yyy in the GSM Options MULTCC list.

For more information about the Default Country Codes and Multiple Country Codes, refer to the Commands Manual.

E3494 Cmd Rej: Link is invalid for card location

Commands Used: `dlt-slk`, `ent-slk`, `rtrv-slk`

You cannot provision a links **a4, b4, ..., a31, b31** and specify an even-numbered card location. Provisioning for links of **a4, b4, ..., a31, b31** and E1/T1 interfaces **3** through **8** is only allowed if HIPR is equipped, the FAN feature is on, LIME1/T1 card or HC-MIM card is in odd-numbered card location, and the card is not provisioned as an E1/T1 channel card.

The **link** parameter values **a4-a31** and **b4-b31** can be specified only for HC-MIM cards that are used as E1 cards or T1 cards.

Links **a4-a31** and **b4-b31** cannot be specified for Channel cards.

Links A16, B16, ..., A31, B31 cannot be specified for even-numbered card location.

Recovery

Re-enter the command specifying a valid odd-numbered n card location.

E3495 Cmd Rej: CHANBRDG is invalid for even numbered card location

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

The `chanbrdg=on` parameter cannot be specified for an HC-MIM card in an even-numbered (n+1) card location. An odd-numbered (n) port must be specified. The `chanbrdg=on` parameter indicates whether an odd-numbered port is to pair with its even-numbered port for non-signaling data pass through.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3496 Cmd Rej: E1/T1 Port greater than 2 unavailable

Commands Used: `ent-e1`, `ent-t1`

You must specify an odd-numbered card location (`loc=n`). The `e1port` parameter values **3** through **8** cannot be specified for an even-numbered HC-MIM card location.

Recovery

Re-enter the command specifying a valid combination of parameters.

Refer to the *Commands Manual* for valid combination of parameters for the specific command that generated this error message.

E3497 Cmd Rej: Either ALIASN or ALIASN24, not both, for destination

Commands Used: `chg-dstn`, `ent-dstn`

You cannot enter values for both the `aliasn` and the `aliasn24` parameters in the same command. For ANSI or ITU-I destinations, these parameters are mutually exclusive and must be entered individually in separate commands.

Recovery

Re-enter the command specifying a value for either the `aliasn` or the `aliasn24` parameter, but not both.

E3498 Cmd Rej: CdPA GTT Selector already exists in GTIN24-TT-NP(V)-NAI(V)

Commands Used: `ent-gttsel`

You cannot specify a CdPA selector that already matches an existing `gtin24`, `tt`, and `np/nai` or `npv/naiv` parameter combination.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttsel` command.
 2. Re-enter the `ent-gttsel` command specifying values for the above parameters that are not in the database.
-

E3499 Cmd Rej: GTT Selector does not exist in GTIN24-TT-NP(V)-NAI(V)

Commands Used: `chg-gttsel`, `dlt-gttsel`

You specified an entry that does not match an existing `gtin24`, `tt`, `np/nai`, and `npv/naiv` parameter combination as required.

For example, if you want to change the selectors linked with GTTSN `itun241` so that they are linked to GTTSN `itun242`, and the current selectors for `itun241` are (`gtin24=2`, `tt=5`, `npv=1`, `naiv=2`), you would enter the following combination:

`chg-gttsel:gtin24=2:tt=5:npv=1:naiv=2:gttsn=itun242`

This example assumes that `gttsn=itun242` is an existing GTT set in the database.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttsel` command..
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3500 Cmd Rej: GFLEX feature must be on

Commands Used: `chg-srvsel`, `chg-stpopts`, `ent-srvsel`,
`rtrv-srvsel`

Table 2-26 lists by command the conditions that cause this error. The table is followed by a procedure to resolve the error.

Table 2-26. Conditions that Generate an E3500 Error Message

Command	Condition
chg-srvsel, ent-srvsel, rtrv-srvsel	The G-Flex feature must be turned on before you can specify the nserv/serv=gflex parameter.
chg-stpopts	The G-Flex feature must be turned on before you can specify the ansigflex=yes parameter.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the G-Flex feature is turned on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again
 3. If the G-Flex feature is off (from the output of step 1), turn it on. Enter the **chg-feat:gflex=on** command.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again
-

E3501 Cmd Rej: CCNC cannot be NONE

Commands Used: **chg-gsmopts**

You cannot specify a value of **none** for the country code and network code (**ccnc**) parameter.

Recovery

Re-enter the command specifying a valid value (2-8 digits [**0-9, a-f, A-F**]) for the **ccnc** parameter.

E3502 Cmd Rej: The NONE value is not allowed in this case

Commands Used: `chg-prefix`, `dlt-homern`, `dlt-subnetid`,
`dlt-vendid`, `ent-homern`, `ent-subnetid`, `ent-trace`, `ent-vendid`

You cannot specify a value of **none** for one of the following command parameters:

- One of the following **ent-trace** command parameters: **dn**, **entityid**, **gt**, **imei**, or **imsi**.
- The **rn** parameter of an **ent-homern** or **dlt-homern** command.
- The **none** value is not allowed for GSM MAP SRI Redirect feature prefix values.

The EAGLE 5 ISS does not allow this action.

Recovery

Re-enter the command specifying a valid parameter value.

E3505 Cmd Rej: Prepaid SMS Intercept Ph1 feature must be ON

Commands Used: `chg-gsmopts`, `chg-srvsel`, `ent-srvsel`

You must enable and turn on the Prepaid Short Message Service Intercept (PPSMS) Phase 1 feature before using the specified command and parameters.

You entered the **chg-gsmopts** command specifying one or more of the following parameters: **ppsmsgta**, **nppsmsgta**, **ppsmspci1**, **ppsmspci2**, **ppsmspcn1**, **ppsmspcn2**, **ppsmsri1**, **ppsmsri2**.

You entered the **ent-srvsel** or **chg-srvsel** command specifying **serv=smsmr** or **nserv=smsmr**.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Verify that you have purchased and installed the PPSMS Phase 1 feature on your system. Contact your Customer Care Center if you need assistance.

2. If the PPSMS Phase 1 feature is purchased and installed on your system, the feature must be enabled and turned on before you can re-enter the command that generated this error.
 3. When the PPSMS Phase 1 feature is enabled and turned on in your system, re-enter the command.
-

E3507 Cmd Rej: Translation TYPEN24 already exists

Commands Used: `ent-tt`

The translation type (`typen24`) specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

1. Determine if the translation type that you want to use already exists in the translation type table. Enter the `rtrv-tt` command.
 2. Re-enter the `ent-tt` command specifying a different translation type.
-

E3511 Cmd Rej: CCNC and MCCMNC parameters must be entered together

Commands Used: `chg-gsmopts`

If you specify one of the following parameters, you must specify the other as well: `ccnc` and `mccmnc`.

Recovery

Re-enter the command specifying both the `ccnc` and `mccmnc` parameters.

E3514 Cmd Rej: Maximum of 10 unique CCNCs allowed

Commands Used: `chg-gsmopts`

You specified the `ccnc/mccmnc` parameter combination. You are allowed to have up to ten sets of `ccnc/mccmnc` parameter combinations. The command would have exceeded the ten allowed sets.

Recovery

1. To delete an existing **ccnc/mccmnc** parameter combination, enter the **chg-gsmopts:ccnc=xx:mccmnc=none** command where *xx* (the value of the **ccnc** parameter) specifies the **ccnc/mccmnc** parameter combination to delete.
 2. Re-enter the **chg-gsmopts** command that generated this error message.
-

E3515 Cmd Rej: CCNC already exists

Commands Used: **chg-gsmopts**

You specified either **ccnc=xx:mccmnc=yy** and the **ccnc** already exists, or **ccnc=xx:mccmnc=none** and the **ccnc** does not exist. The **ccnc** must not exist unless **mccmnc=none** is specified.

To add a new **ccnc/mccmnc** parameter combination, enter the **chg-gsmopts:ccnc=xx:mccmnc=yy** command where *xx* (the value of the **ccnc** parameter) and *yy* (the value of the **mccmnc** parameter) specify the **ccnc/mccmnc** parameter combination to add.

To delete an existing **ccnc/mccmnc** parameter combination, enter the **chg-gsmopts:ccnc=xx:mccmnc=none** command where *xx* (the value of the **ccnc** parameter) specifies the **ccnc/mccmnc** parameter combination to delete.

Recovery

Re-enter the **chg-gsmopts** command that generated this error message.

E3516 Cmd Rej: SCCP appl provisioned with ASM card type

Commands Used: **chg-feat, enable-ctrl-feat**

The EGMS, INP, G-Port, G-Flex, and Origin Based SCCP Routing features cannot be enabled and turned on. To enable and turn these features on, you must first be upgrade your hardware. These features require at least a DSM card running the VSCCP application.

Recovery

1. Upgrade your hardware *to at least a DSM card(s) and the VSCCP application*.
 2. Re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E3517 Cmd Rej: VSCCP cards have insufficient extended memory**Commands Used: chg-feat**

You attempted to turn on the INP feature, but your VSCCP cards do not have sufficient memory. At least one daughterboard on the DSM card is required. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Re-enter the **chg-feat** command.

Call your Customer Care Center if this error message appears again.

E3518 Cmd Rej: Active OAM must be equipped with E586 hardware

You attempted to bring INP online, but your active Operations, Administration, and Maintenance (OAM) module is not equal to the task. You need to upgrade the hardware.

Recovery

1. Upgrade your OAM hardware.
2. Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3519 Cmd Rej: Standby OAM must be equipped with E586 hardware**Commands Used: chg-feat**

You attempted to bring INP online, but your standby Operations, Administration, and Maintenance (OAM) module is not equal to the task. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Re-enter the **chg-feat** command.

Call your Customer Care Center if this error message appears again.

E3522 Cmd Rej: Service Selector Table is full

Commands Used: `ent-srvsel`

You cannot add an entry to the Service Selector table because the Service Selector table is full.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

Perform one of the following actions:

- Delete an entry from the Service Selector table. Enter the `dlt-srvsel` command.
- OR
- Change an entry in the Service Selector table. Enter the `chg-srvsel` command.
-

E3523 Cmd Rej: At least one parameter must be changed(NSNP, NSNAI, NSERV)

Commands Used: `chg-srvsel`

You must specifying at least one of the following parameters: `nsnp`, `nsnai`, or `nserv`.

Recovery

Re-enter the `chg-srvsel` command specifying at least one of the following parameters: `nsnp`, `nsnai`, or `nserv`.

E3524 Cmd Rej: INP feature must be ON

Commands Used: `chg-inpopts`, `chg-sid`, `chg-srvsel`, `chg-ss-appl`, `dlt-homern`, `dlt-ss-appl`, `ent-homern`, `ent-srvsel`, `ent-ss-appl`, `rtrv-homern`, `rtrv-inpopts`, `rtrv-sid`, `rtrv-srvsel`, `enable-ctrl-feat`

Table 2-27 lists by command the conditions that cause this error. The table is followed by a procedure that provides a response for the error.

Table 2-27. Conditions that Generate an E3524 Error Message

Commands	Condition
chg-inpopts, dlt-homern, ent-homern, rtrv-homern, rtrv-inpopts	To specify these commands, the INP feature must be turned on.
chg-sid, rtrv-sid	To specify the cpctype=inp parameter, the INP feature must be turned on.
chg-srvsel, ent-srvsel, rtrv-srvsel	If you specify the serv=inpnr or serv=inpq parameter, the INP feature must be turned on.
chg-ss-appl, dlt-ss-appl, ent-ss-appl	To specify the appl=inp parameter, the INP feature must be turned on.
enable-ctrl-feat	You attempted to enable a feature but the INP feature must first be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 - If the INP feature is on (from the output of step 1), re-enter the command.
 - If the INP feature is off (from the output of step 1), turn it on. Enter the **chg-feat** command.
 2. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3525 Cmd Rej: Command will cause system clock outage – Use FORCE=YES

Commands Used: **init-card, init-flash**

You are prevented from specifying the **initclk** parameter if the resulting TDM bitfile reload would cause a system clock outage. To override this restriction and allow the TDM bitfile to reload (resulting in a system clock outage), you must specify the **force=yes** parameter.



CAUTION: Creating a system clock outage will probably result in the loss of traffic on all links.

The following scenarios will result in system clock outages.

Trying to initialize both MASPs at one time by specifying param **appl=oam**.

Performing a simplex MASP configuration (that is, a system with a one TDM).

Having a bad clock status on the remaining TDM card.

Recovery

Perform one of the following:

- Re-enter the command without specifying the **initclk** parameter
- OR
- Re-enter the command specifying **force=yes**, which will create a system clock outage and possibly stop the traffic on some or all links.
-

E3526 Cmd Rej: Invalid TDM configuration for INITCLK

Commands Used: **init-card**, **init-flash**

You can specify the **initclk** parameter for only TDM cards that support bitfile reloading, that is, TDMs with part number 870-0774-15 or later, (or 870-0774-18).

Recovery

Perform one of the following:

- Ensure that TDM cards with part number 870-0774-15 or later, (or 870-0774-18), are installed in card locations 1114 and 1116. If your TDMs are not the correct part number and level, contact your Customer Care Center.
- OR
- Re-enter the command without specifying the **initclk** parameter.
-

E3527 Cmd Rej: NMULTCC entry already exists in the GSM Options MULTCC list**Commands Used: chg-gsmopts**

You specified an nmultcc parameter value for the GSM Options MULTCC List, but that value already exists there. Duplicate multcc entries are not supported.

Recovery

1. Display the multcc parameter values currently in the MULTCC list. Enter the **rtrv-gsmopts** command.
 2. Re-enter the **chg-gsmopts** command specifying a value for the nmultcc parameter that does not appear as a multcc value in the output from step 1.
-

E3534 Cmd Rej: E1 Port test command in progress**Commands Used: tst-e1**

A port test is in progress on this e1port. Only one port test can be performed at a time. Subsequent test requests are rejected until the e1port test is complete.

Recovery

Wait for all tests to complete, then re-enter the **tst-e1** command.

E3535 Cmd Rej: E1 Port test command not in progress**Commands Used: tst-e1**

There is no active test in progress on this e1port. The parameter **action=stop** cannot be performed if there is no active port test.

Recovery

Re-enter the **tst-e1** command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

E3537 Cmd Rej: Card's A/B interface IP Networks must be unique**Commands Used: chg-ip-lnk**

The IP network addresses assigned to the A and B interface ports are not unique.

Recovery

1. Display the existing IP addresses for the card. Enter the **rtrv-ip-card** command.
 2. Define a correct IP address for the card. Enter the **chg-ip-card** command.
 3. Verify that the **port** and **ipaddr** parameters in the **chg-ip-lnk** command specify unique addresses for ports A and B.
 4. Re-enter the **chg-ip-lnk** command specifying the correct parameters.
Call your Customer Care Center if this error message appears again.
-

E3538 Cmd Rej: Linkset SLK requires ITUN APC/SAPC to be 14bit or 24bit only

Commands Used: **chg-ls**, **ent-slk**

The specified linkset requires the ITU-N APC/SAPC to be either 14-bit or 24-bit.

- SAPC cannot be ITU-N 24-bit if linkset contains IPLIM SAALTALI or E1 ATM links. These links do not support 24-bit ITU-N traffic
- The linkset cannot have both 14-bit ITU-N and 24-bit ITU-N APC/SAPC unless it contains only IPGWI or IPLIM M3UA links. These links support 14-bit ITU-N and 24-bit ITU-N traffic simultaneously.

The linkset with **ipgwapc=no** cannot have both 14-bit ITU-N and 24-bit ITU-N APC/SAPC if no links are provisioned

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

E3541 Cmd Rej: Failed reading GSM Options Table

Commands Used: **chg-gsmopts**, **chg-stpopts**, **rtrv-gsmopts**

The GSM Options table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3542 Cmd Rej: Failed reading GSM SSN Table

Commands Used: `dlt-gsm-ssn`, `ent-gsm-ssn`, `rtrv-gsm-sasn`

The GSM SSN table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3543 Cmd Rej: Failed reading GTT Selector Table

Commands Used: `chg-gttset`, `dlt-gttset`, `dlt-gttset`,
`ent-gttset`, `rtrv-gttset`

The GTT Selector table is corrupt or cannot be found by the system. The GTT Selector table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3544 Cmd Rej: Failed reading GTT Set Table

Commands Used: `chg-gttset`, `chg-gta`, `chg-gttset`, `chg-sccpopts`,
`dlt-gta`, `dlt-gttset`, `ent-gta`, `ent-gttset`, `ent-gttset`,
`rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`, `rtrv-sccpopts`

The GTT Set table is corrupt or cannot be found by the system. The GTT Set table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3545 Cmd Rej: Failed reading SERV Selector Table

Commands Used: `chg-srvsel`, `dlt-srvsel`, `ent-srvsel`,
`rtrv-srvsel`

The Service Selector table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3547 Cmd Rej: System serial number entered is invalid

Commands Used: `ent-serial-num`

The system serial number with the `ent-serial-num` command is unacceptable for one of the following reasons:

- The system serial number entered with the `lock=yes` parameter does not match the contents of the Serial Number table in the database.
- OR
- The system serial number entered does not meet all these rules:
 1. The string must be alphanumeric and cannot exceed 15 characters
 2. The first two characters must be alphabetic (referred to as the prefix)
 3. All remaining characters must be numeric
 4. The string cannot contain any special characters (including space)
 5. The format for acceptable characters is: [A..Z] | [a..z] | [0..9]

Recovery

Re-enter the `ent-serial-num` command specifying a valid system serial number.

E3548 Cmd Rej: System serial number is already locked in database

Commands Used: `ent-serial-num`

The serial number entered has already been locked in the Serial Number table. Once the table is locked, you cannot enter the serial number again.

Recovery

Contact your Customer Care Center if you need to change the serial number.

E3550 Cmd Rej: GTT must be on before EGTT can be on

Commands Used: **chg-feat**

You cannot turn on the Enhanced Global Title Translation (EGTT) feature because the Global Title Translation (GTT) feature is turned off. GTT must be turned on before you can turn on EGTT.

NOTE: When the EGTT feature is turned on, three new command sets, the GTT Selector (**ent/chg/dlt/rtrv-gttset**), GTT Set (**ent/dlt/rtrv-gttset**), and GTA (**ent/chg/dlt/rtrv-gta**) commands, replace the following Translation Type and Global Title Translation commands: **ent/dlt/rtrv-tt**, and **ent/chg/dlt/rtrv-gtt**. All data previously provisioned with these commands is maintained.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

2. If the GTT feature is on (GTT=on from the output from step 1), re-enter the **chg-feat:egtt=on** command.

Call your Customer Care Center if this error message appears again.

3. If the GTT feature is off (GTT=off from the output from step 1), enter **chg-feat:gtt=on** to turn on GTT.

4. Re-enter the **chg-feat:egtt=on** command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3551 Cmd Rej: NP and NPV must not be specified together

Commands Used: **chg-gttset**, **chg-srvsel**, **dlt-gttset**, **dlt-srvsel**, **ent-gttset**, **ent-srvsel**, **rtrv-gttset**, **rtrv-srvsel**

You cannot specify both the **np** and **npv** parameters together.

Recovery

Re-enter the command specifying either the **np** or the **npv** parameter, but not both.

E3552 Cmd Rej: NAI and NAIV must not be specified together

Commands Used: `chg-gtttsel`, `chg-srvsel`, `dlt-gtttsel`,
`dlt-srvsel`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`, `rtrv-srvsel`

You cannot specify both the **nai** and **naiv** parameters together.

Recovery

Re-enter the command specifying either the **nai** or the **naiv** parameter, but not both.

E3553 Cmd Rej: GTI (A)=4, and GTI (X)=1 and 3 are not supported

Commands Used: `chg-gtttsel`, `chg-srvsel`, `dlt-gtttsel`,
`dlt-srvsel`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`, `rtrv-srvsel`

You specified an invalid value for the GTI (global title indicator).

- For an ANSI domain, the only valid value for the **gti** or **gtia** parameters is **2** (**gti=2** or **gtia=2**).
- For an ITU-I or ITU-N domain, the valid values for the **gtii/gtin/gtin24** parameters are either **2** or **4** (**gtii/gtin/gtin24=2** or **gtii/gtin/gtin24=4**).

Recovery

Re-enter the command specifying a valid value for the global title indicator.

E3554 Cmd Rej: NP(V) and NAI(V) must not be specified for given GTI value

Commands Used: `chg-gtttsel`, `chg-srvsel`, `dlt-gtttsel`,
`dlt-srvsel`, `ent-gta`, `ent-gtttsel`, `ent-srvsel`, `rtrv-gtttsel`,
`rtrv-srvsel`

You cannot specify **gtii/gtin/gtin24=2** and the **np/nai** or the **npv/naiv** parameter combinations. If you specify **gtii/gtin/gtin24=2**, the **np/nai** or the **npv/naiv** parameter combinations are invalid.

Recovery

Perform one of the following actions:

- Re-enter the command specifying **gtii/gtin/gtin24=4** and specify either the **np/naï** or the **npv/naiv** parameter combinations.
- OR
- Re-enter the command specifying **gtii/gtin/gtin24=2** without specifying the **np/naï** or the **npv/naiv** parameter combinations.
-

E3555 Cmd Rej: NP(V) and NAI(V) must be specified for given GTI value

Commands Used: `chg-gtt sel`, `chg-srv sel`, `dlt-gtt sel`,
`dlt-srv sel`, `ent-gtt sel`, `ent-srv sel`

You cannot specify either **gtii/gtin/gtin24=4**, without specifying either the **np/naï** or the **npv/naiv** parameter combinations. If you specify **gtii/gtin/gtin24=4**, you must also specify either the **np/naï** or the **npv/naiv** parameter combinations.

Recovery

Perform one of the following actions:

- Re-enter the command specifying a value other than **4** for the global title indicator.
- OR
- Re-enter the command specifying a GTI value of **4**, and either the **np/naï** or the **npv/naiv** parameter combination.
-

E3556 Cmd Rej: This command is not valid when EGTT is ON

Commands Used: `chg-gtt`, `dlt-gtt`, `dlt-tt`, `ent-gtt`, `ent-tt`,
`rtrv-gtt`, `rtrv-tt`

You cannot enter a GTT (Global Title Translation) or TT (Translation Type) command if the EGTT (Enhanced Global Title Translation) feature is turned on your system. Once the EGTT feature is turned on:

- A new set of EGTT commands replaces the old GTT or TT commands and,
- The system will no longer accept the old GTT or TT commands.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the EGTT feature is off (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the EGTT feature is on (from the output of step 1), the new EGTT command sets replace the old GTT and TT commands:
 - GTT Set commands: **ent/dlt/rtrv-gttset**
 - GTA commands: **ent/chg/dlt/rtrv-gta**
 - GTT Selector commands: **ent/chg/dlt/rtrv-gttset**
-

E3557 Cmd Rej: EGTT must be ON before this command can be entered

Commands Used: **chg-gta, chg-gttset, chg-gttset, dlt-gta, dlt-gttset, dlt-gttset, chg-feat, ent-gta, ent-gttset, ent-gttset, rtrv-gta, rtrv-gttset, rtrv-gttset**

The command you entered requires that the EGTT (Enhanced Global Title Translation) feature to be turned on (**chg-feat:egtt=on**).

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the EGTT feature is on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
- NOTE:** The Global Title Translation (GTT) feature must be turned on (**chg-feat:gtt=on**) before the Enhanced Global Title Translation (EGTT) feature can be turned on.
3. If the EGTT feature is off (from the output of step 1), turn it on. Enter the **chg-feat:egtt=on** command.
 4. Re-enter the command that generated this error message.
-

E3558 Cmd Rej: CdPA GTT Selector already exists in GTI-TT-NP(V)-NAI(V)**Commands Used: ent-gttse1**

The specified CdPA GTT selector was not entered because an entry that matches the values specified for the **gti**, **tt**, and **np/naï** or **npv/naïv** parameter combination, already exists in the GTT Selector table.

Recovery

1. Display the GTT Selector table. Enter the **rtrv-gttse1** command.
 2. Re-enter the **ent-gttse1** command specifying values that do not already exist in the database for the **gti**, **tt**, and **np/naï** or **npv/naïv** parameters.
-

E3559 Cmd Rej: GTT Selector specified by GTI-TT-NP(V)-NAI(V) does not exist**Commands Used: chg-gttse1, dlt-gttse1**

You specified an entry that does not match an existing **gti**, **tt**, **np/naï**, and **npv/naïv** parameter combination as required.

For example, if you want to change the change the selectors linked with **gttsn=ansi1** so that they are linked to **gttsn=ansi2**, and the current selectors for **ansi1** are (**gti=2**, **tt=5**, **npv=1**, **naïv=2**), you would enter the following combination:

```
chg-gttse1:gti=2:tt=5:npv=1:naïv=2:gttsn=ansi2
```

This example assumes that **gttsn=ansi2** is an existing GTT set in the database.

Recovery

1. Display the GTT Selector table. Enter the **rtrv-gttse1** command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3560 Cmd Rej: GTT Set specified by GTTSN already exists**Commands Used: ent-gttset**

The value specified for the **gttsn** parameter already exists in the database. This action is not allowed.

Recovery

1. Display the existing GTT set entries. Enter the **rtrv-gttset** command. In the output, the existing GTT sets are listed in the GTTSN column.
 2. Re-enter the **ent-gttset** command specifying a value for the **gttsn** parameter that does not already exist.
-

E3561 Cmd Rej: GTT Set specified by GTTSN does not exist

Commands Used: **chg-gta, chg-gttset, dlt-gta, dlt-gttset, ent-gta, rtrv-gta, rtrv-gttset**

The value specified for the GTT Set Name (**gttsn**) parameter does not match the name of an existing GTT Set entry. The GTT Set Name must match the name of an existing GTT Set.

Recovery

1. Display the existing GTT set entries. Enter the **rtrv-gttset** command. In the output, the existing GTT sets are listed in the GTTSN column.
 2. Re-enter the command specifying a valid value for the **gttsn** parameter.
-

E3562 Cmd Rej: Network domains of GTI and CDGTASN/GTTSN must match

Commands Used: **chg-gttset1, ent-gttset1**

The network domain of the new or existing selector must match the network domain of the existing GTT Set specified by the **cdgtasn/gttsn** parameter, unless the network domain of the existing GTT Set is **cross**.

Recovery

1. Display the domain of the existing GTTSN. Enter the **rtrv-gttset** command. The domain is listed in the NETDOM column of the output.
 2. Perform one of the following actions:
 - Re-enter the command specifying a GTI that matches the network domain of the existing GTT set.
 - OR
 - Re-enter the command specifying an existing GTT set that matches the network domain of the GTI.
-

E3563 Cmd Rej: NAI entries per TT-NP combination has reached allowed max

Commands Used: `chg-gttset`, `ent-gttset`

The specified Nature of Address Indicator (NAI) could not be entered into the GTT Selector table because no more than 5 NAI entries per Translation Type-Numbering Plan (TT-NP) combination are allowed. For each unique TT-NP combination, you can specify up to 5 specific NAI entries.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttset` command.
 2. Delete an entry from the table. Enter the `dlt-gttset` command.
 3. Re-enter the `ent-gttset` command that generated this error message.
-

E3564 Cmd Rej: GTT Set table is full

Commands Used: `ent-gttset`

The specified GTT set could not be entered into the GTT Set table because the GTT Set table is full. The GTT Set table cannot contain more than 2000 entries.

Recovery

1. Display the GTT Set table. Enter the `rtrv-gttset` command. The GTT sets are listed in the GTTSN column.
 2. Delete one of the existing entries. Enter the `dlt-gttset` command. Note that you may first have to delete any GTT selectors (`dlt-gttset`) or GTAs assigned (`dlt-gta`) to the GTT set.
 3. Re-enter the `ent-gttset` command.
Call your Customer Care Center if this error message appears again.
-

E3565 Cmd Rej: GTT Set must not be specified as NONE

Commands Used: `chg-gta`, `chg-gttset`, `dlt-gta`, `dlt-gttset`, `ent-gta`, `ent-gttset`, `ent-gttset`, `rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`

You entered the command specifying a value of **none** for at least one of the GTT Sets, which is not allowed. You must specify an existing GTT Set in place of none.

Recovery

Re-enter the command specifying a valid value for the GTT Set.

E3566 Cmd Rej: GTT Set specified by GTTSN has GTT Selectors assigned to it**Commands Used: dlt-gttset**

You cannot delete a GTT set that has GTT selectors assigned to it. The value specified for the GTT set name (**gttsn**) parameter is being used by one or more GTT selectors.

Recovery

1. Display a list of the GTT selectors assigned to the GTT set. Enter the **rtrv-gttset:gttsn=** command.
 2. Delete the GTT selectors assigned to the GTT set. Enter the **dlt-gttset** command.
 3. Re-enter the **dlt-gttset** command that generated this error message.
-

E3567 Cmd Rej: GTT Set must not be used by or assigned to any Translation**Commands Used: chg-gttset, dlt-gttset**

For the **chg-gttset** command, the number of digits (**ndgt**) parameter is invalid if GTAs are assigned to the GTT Set.

For the **dlt-gttset** command: You cannot delete a GTT set that has the **gta/cgpc/cgssn/opc** parameters assigned to it. You cannot delete a GTT set that is used by or assigned to any translation.

Recovery

1. Display the GTAs assigned to the GTT set. Enter the **rtrv-gta:gttsn=** command.
 2. Delete the assigned GTAs from the GTT set. Enter the **dlt-gta** command.
 3. Re-enter the **dlt-gttset** command.
-

E3568 Cmd Rej: NTT can only be specified when XLAT=DPCNGT

Commands Used: `chg-gta`, `ent-gta`

You cannot specify the `ntt` parameter without specifying the translate indicator `xlat=dpcngt` parameter. If the `ntt` parameter is specified, the `xlat=dpcngt` parameter must be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the `ntt` parameter and `xlat=dpcngt`.
- OR
- Re-enter the command without specifying the `ntt` parameter.
-

E3569 Cmd Rej: NTT must be specified when XLAT=DPCNGT

Commands Used: `chg-gta`, `ent-gta`, `rtrv-gta`

You cannot specify `xlat=dpcngt` without specifying the `ntt` parameter. If the `xlat=dpcngt` parameter is specified, the `ntt` parameter must also be specified.

Recovery

Perform one of the following actions:

- Re-enter the command specifying both the `ntt` and `xlat=dpcngt` parameters.
- OR
- Re-enter the command without specifying the `xlat=dpcngt` parameter.
-

E3570 Cmd Rej: Point Code type does not match GTT Set network domain

Commands Used: `chg-gta`, `dlt-gta`, `ent-gta`, `rtrv-gta`

The point code specified for the network type does not match the network domain of the GTT set name (`gttsn`) parameter. The network type of the specified point code must be the same as the network domain of the GTT set.

- If the specified GTT Set is an ANSI set, the point code must be a valid ANSI point code (`cgpc/cgpca`, `opc/opca`).
- If the specified GTT Set is an ITU set, the point code must be a valid ITU point code (`cgpci/cgpcn/cgpcn24`, `opci/opcn/opcn24`).

NOTE: If the ANSI-ITU-China SCCP Conversion feature is enabled, this error code will not be generated.

Recovery

1. Determine the network domain of the GTT set. Enter the **rtrv-gttset** command. The network domain is listed in the **NETDOM** column of the output.
 2. Re-enter the command specifying a point code whose network type matches the specified **gttsn** parameter.
 - If the specified GTT set is an ANSI set, the point code must be a valid ANSI point code (**pc** or **pca**).
 - If the specified GTT set is an ITU set, the point code type must be a valid ITU point code (**pci** or **pcn** or **pcn24**).
-

E3571 Cmd Rej: GTA Length does not match GTT Set number of digits

Commands Used: chg-gta, dlt-gta, ent-gta, rtrv-gta

The global title address specified must contain the same number of digits that have been assigned with the **ndgt** parameter of the **ent-gttset** command for the GTT set.

If the VGTT (variable length GTT) feature is turned on, the **ndgt** parameter is invalid. You can provision up to 10 GTA lengths per GTT set. When you enter the **ent-gta** command to create entries, the software keeps track of the lengths and allows only ten different lengths. Only global title entries matching the defined GTA lengths are allowed.

Recovery

1. Display the number of digits allocated for the GTT set. Enter the **rtrv-gttset** command. The number of digits is listed in the **NDGT** column of the output.
 2. Re-enter the command specifying a GTA that contains one of the GTA lengths listed in the output of step 1.
-

E3572 Cmd Rej: RI must be SSN when CCGT is YES

Commands Used: `chg-gta`, `ent-gta`

You specified the `ccgt=yes` parameter, but you did not specify `ri=ssn` parameter as required. For the `chg-gta` command, this applies to new or existing values for these parameters.

Recovery

Perform one of the following actions:

- Re-enter the command specifying `ri=ssn`.
 - OR
 - Re-enter the command without specifying the `ccgt=yes` parameter.
-

E3573 Cmd Rej: CCGT must be NO when PC is the STP's PC or CPC

Commands Used: `chg-gta`, `ent-gta`

You specified a value for the `pc/pca/pci/pcn/pcn24` parameter that is one of the STP's point codes or capability point codes. In such cases, you must specify the `ccgt=no` parameter. For the `chg-gta` command, this applies to new or existing values for the `pc/pca/pci/pcn/pcn24` parameter.

Recovery

Re-enter the command specifying the `ccgt=no` parameter.

E3574 Cmd Rej: NTT must be specified for new values of XLAT/RI

Commands Used: `chg-gta`

You specified the `xlat=dpcngt` and `ri=gt` parameters, and without the `ntt` parameter. The `ntt` parameter must be specified if you specify the `xlat=dpcngt` and `ri=gt` parameters.

Recovery

Re-enter the `chg-gta` command specifying the `xlat=dpcngt`, `ri=gt`, and the `ntt` parameters.

E3575 Cmd Rej: The sum of the values for NPCFMTI must be equal to 14**Commands Used: chg-stpopts**

The sum of all the values specified by the **npcfmti** parameter (**m1+m2+m3+m4**) must equal **14**. If the ITU national point code format has less than four numbers, the parts of the point code format not being used must be specified as **0**. All four parts of the point code format must be specified, no matter how many numbers the point code format will contain. Some examples follow: **npcfmti=7-7-0-0**, **npcfmti=0-6-8-0**, **npcfmti=0-0-4-10**, **npcfmti=3-8-3-0**, and **npcfmti=14-0-0-0**.

Recovery

Re-enter the **chg-stpopts** command specifying a valid value for the **npcfmti** parameter.

E3576 Cmd Rej: EGTT cannot be ON if any SCCP card has a 486 processor**Commands Used: chg-feat**

You attempted to turn on the EGTT feature. The command failed because you have an SCCP card running on a 486 processor, which is an invalid hardware configuration for this feature. When the system detects this configuration, it automatically puts the SCCP (with the 486 processor) in the OOS-MT_DSBLD/MEA state, so that you can remove the card.

Recovery

1. Upgrade all 486 SCCP cards with 586 SCCP cards.
2. Re-enter the **chg-feat** command.

Call your Customer Care Center if this error message appears again.

E3577 Cmd Rej: CCGT must be NO when RI is set to GT**Commands Used: chg-gta, ent-gta**

If **ri=gt** is specified, you must specify **ccgt=no** (the default value). If **ccgt=yes** is specified, you must specify **ri=ssn**.

Recovery

Perform one of the following actions:

- Re-enter the command specifying **ri=gt** or **ri=ssn**, and **ccgt=no**.
- OR
- Re-enter the command specifying **ri=ssn** and **ccgt=yes**.
-

E3578 Cmd Rej: NP and NAI must be specified as DFLT together

Commands Used: **chg-gttset**, **dlt-gttset**, **rtrv-gttset**

The **np** and **nai** parameters must both be specified as **dflt** and both must be specified together (**np=dflt:nai=dflt**).

Recovery

Re-enter the command specifying both the **np=dflt** and the **nai=dflt** parameters.

E3579 Cmd Rej: NI parameter may not be specified for ITU linksets

Commands Used: **rept-meas**

You specified either the **enttype=lsdestni** or **enttype=lsorigni** parameters with the **ni** parameter for an ITU gateway linkset. You cannot specify the **ni** parameter for ITU linksets for the LSDESTNI or LSORIGNI reports. The **ni** parameter can be specified only for ANSI linksets.

Recovery

Perform one of the following actions:

- Re-enter the **rept-meas** command but do not specify the **ni** parameter.
- OR
- Re-enter the **rept-meas** command specifying an ANSI linkset for the **lsn** parameter.
-

E3581 Cmd Rej: SSN value must be LNP SSN or INP SSN

Commands Used: `alw-map-ss`, `inh-map-ss`

You specified a subsystem (`ssn`) parameter that did not represent the LNPQS or INPQS subsystem.

Recovery

1. Enter the `rtrv-ss-appl` command to obtain the number that correctly identifies the LPNQS or INPQS subsystem. The output identifies the subsystem/SSN combination as shown in the following example:
APPL SSN STAT
LNP 15 online
 2. Re-enter the command that generated this error message specifying the correct value for the `ssn` parameter.
-

E3582 Cmd Rej: INP subsystem is offline in database

Commands Used: `alw-map-ss`

You attempted to run this command while the INP subsystem was offline in the database.

Recovery

Enter the command `chg-ss-appl:appl=inp:nstat=online` to activate the INP subsystem.

E3583 Cmd Rej: Initial Command Response Timeout

Commands Used: `all commands`

A response from the entered command has not been received on the OAM/EOAM, within the two-second command response interval.

Recovery

1. Wait for five minutes until the OAM/EOAM return to an operational state.
 2. Reconnect to the server and re-enter the original command.
-

E3584 Cmd Rej: Feature configuration requires DSM card with VSCCP appl**Commands Used: ent-card**The following features require a DSM card(s) running the **vsccp** application:

- Enhanced GSM MAP Screening (EGMS) = E3899
- Equipment Identity Register (EIR)
- Flexible GTT Load Sharing (FGTTLS)
- G-Flex
- G-Port
- INP
- LNP ELAP Configuration
- Origin-based SCCP Routing

Recovery

1. Verify that your hardware is adequate.
 2. Re-enter the command specifying **ent-card:loc=xxxx:type=dsm:appl=vsccp** (where **xxxx** is the card location of the DSM).
-

E3585 Cmd Rej: Dest IP Address is invalid**Commands Used: dlt-ip-rte, ent-ip-rte, rtrv-ip-rte**You specified an invalid destination IP address in the **dest** parameter of the command.

To be valid, the specified destination IP address must:

- consist of four numbers separated by dots, with each number in the range of **0-255**
- not be the default route (**0.0.0.0**)
- not correspond to any loopback address (i.e. **127.X.X.X**)
- be unique per card
- not correspond to an IP address that is local to this card's A or B network

Recovery

Re-enter the command specifying a valid destination IP address as per the conditions listed above.

E3586 Cmd Rej: Dest IP Address already exists for this card**Commands Used: ent-ip-rte**

The specified destination IP address (**dest**) parameter already exists for the card in the location specified by the **loc** parameter.

Recovery

1. Display the existing destination IP addresses for the card. Enter the **rtrv-ip-rte** command.
 2. Re-enter the **ent-ip-rte** command specifying a destination IP address that is unique and does not already exist for the specified card.
-

E3587 Cmd Rej: Dest IP Address cannot be local to this cards A, B network**Commands Used: ent-ip-rte**

You cannot define a destination IP address that is local to the A or B network for the card in the location specified by the **loc** parameter. For this command the destination IP address cannot be local to the A or B network for the card.

Recovery

1. Display the existing destination IP addresses for the card. Enter the **rtrv-ip-rte** command.
 2. Re-enter the **ent-ip-rte** command specifying a destination IP address that is not local to the A or B network for the specified card.
-

E3588 Cmd Rej: Dest IP Address does not exist for this card**Commands Used: dlt-ip-rte**

You entered a command to delete a static IP route from the IP route table. The specified destination IP address (**dest**) parameter does not exist in the IP Route table for the specified card.

Recovery

To delete a static IP route entry for the specified card,

1. Display the existing destination IP addresses for the card. Enter the **rtrv-ip-rte** command specifying the **loc** parameter.
2. Re-enter the **dlt-ip-rte** command specifying a valid destination IP address for the entry you want to delete for the specified card.

OR

To delete the entry for the specified destination IP address,

1. Verify that there is a card with an entry containing the specified destination IP address. Enter the **rtrv-ip-rte** command specifying the **dest** parameter.
 2. Re-enter the **dlt-ip-rte** command specifying the correct card location in the **loc** parameter for the card that has the specified destination IP address.
-

E3589 Cmd Rej: Specified cards A, B interface IP Address must be assigned

Commands Used: **ent-ip-rte**

The A or B interface IP address has not been assigned for the card in the location that you specified in the **loc** parameter for the command.

Recovery

1. Display the existing IP addresses for the card. Enter the **rtrv-ip-card** command.
2. Define the missing IP addresses for the card. Enter the **chg-ip-card** command.
3. Re-enter the **ent-ip-rte** command.

Call your Customer Care Center if this error message appears again.

E3590 Cmd Rej: Temporary key is un-available

Commands Used: **enable-ctrl-feat**

The temporary access key has expired for the feature that you tried to enable.

Recovery

1. To continue to use the feature, you must purchase the feature from Tekelec. Contact your Customer Care Center.
 2. When you have purchased the feature and obtained a permanent feature access key, re-enter the **enable-ctrl-feat** command to enable the feature.
-

E3591 Cmd Rej: Invalid System serial number

Commands Used: **ent-serial-num**

The serial number that you entered in the command does not meet one of the following naming conventions:

- Up to 15 alphanumeric characters (**A...Z**, **a...z**, or **0...9**). Mixed case is allowed.
- The first two characters (the prefix) must be letters.
- The remaining characters must be numeric.
- No special characters or spaces.
- Format: [**A...Z**] | [**a...z**] | [**0...9**].

Call your Customer Care Center before using the **ent-serial-num** command. Entering a serial number with **lock=yes** is permanent. Correcting an incorrect serial number requires a manual procedure and system disk (MO) from Tekelec.

Recovery

Re-enter the **ent-serial-num** command specifying the correct system serial number.

Call your Customer Care Center if this error message appears again.

E3592 Cmd Rej: System serial number is already locked in database

Commands Used: **ent-serial-num**

You entered a command to enter the system serial number, and the serial number that you entered has already been locked in the serial number table. Once the table is locked, you cannot enter the serial number again.

Recovery

If you need to change the serial number, contact your Customer Care Center.

E3593 Cmd Rej: Part Number does not belong to an On/Off Feature**Commands Used: chg-ctrl-feat**

You entered a part number associated with a quantity feature entry. The On/Off status of a feature associated with quantity cannot be changed by this command.

Recovery

Re-enter the **chg-ctrl-feat** command specifying the correct part number.

Call your Customer Care Center if this error message appears again.

E3595 Cmd Rej: Def Router IP Addr must be local to this cards A, B network**Commands Used: chg-ip-card**

You specified an IP address in the **defrouter** parameter that is not local to the A or B network for this card. The **defrouter** IP address must be local to this card's A or B network.

Recovery

1. Display the local A and B network IP addresses and the current **defrouter** IP address for this card. Enter the **rtrv-ip-card** command specifying the **loc** parameter for this card.
 2. Re-enter the **chg-ip-card** command specifying a defrouter IP address that is local to the A or B network for this card.
-

E3596 Cmd Rej: IP Address still referenced by the Def Router**Commands Used: chg-ip-lnk**

You entered a command to change the **ipaddr** and **subnet** values to addresses that represent a different network. You cannot change to an address on a different network if the **defrouter** address is assigned to this network interface.

Recovery

1. Display the current **defrouter** IP addresses. Enter the **rtrv-ip-card** command.
 2. Display the current **ipaddr** and **submask** addresses. Enter the **rtrv-ip-lnk** command.
 3. Re-enter the **chg-ip-lnk** command specifying **ipaddr** and **submask** values that are on this network.
-

E3597 Cmd Rej: IP Address still referenced by static IP Routes

Commands Used: **chg-ip-lnk**

You entered a command to change the **ipaddr** and **submask** values to addresses that represent a different network. You cannot change to an address on a different network if the address is referenced by any static IP routes using this network interface.

Recovery

1. Display the current static IP route addresses. Enter the **rtrv-ip-rte** command.
 2. Display the current **ipaddr** and **submask** addresses. Enter the **rtrv-ip-lnk** command.
 3. Re-enter the **chg-ip-lnk** command specifying **ipaddr** and **submask** values that are on this network.
-

E3598 Cmd Rej: LNP ELAP Configuration and WNP features must be ON

Commands Used: **enable-ctrl-feat**

You entered a command to enable the LNP SMS feature. The LNP ELAP Configuration and WNP features must be turned on before you can enable the LNP SMS feature.

Recovery

1. Verify that the GTT, LNP, LNP ELAP Configuration, and WNP features have been purchased and turned on in the system.
 - Enter the **rtrv-feat** command to list the features controlled by feature bits and their status in the system.
 - Enter the **rtrv-ctrl-feat** command to list those features in the system controlled by a feature access key.

Contact your Customer Care Center for assistance in determining the status of system features.

2. When the required features are purchased, installed, and turned on, re-enter the command to enable the LNP SMS feature.

Call your Customer Care Center if this error message appears again.

E3599 Cmd Rej: WSMSC feature must be Activated

Commands Used: chg-lnp-serv, chg-lnpopts, ent-lnp-serv

For the **chg-lnpopts** command, the LNP Short Message Service (LNP SMS) feature must be turned on before you can specify the **wsmc10dig** parameter.

OR

For the **ent-lnp-serv** or **chg-lnp-serv** commands, the LNP Short Message Service (LNP SMS) feature must be turned on before you can specify the **serv=wsmc** parameter.

Recovery

1. Display those features in the system that are controlled with feature access keys. Enter the **rtrv-ctrl-feat** command.
2. Verify that the LNP SMS feature has been purchased and installed in your system. Contact your Customer Care Center for assistance.
3. If the LNP SMS feature has been purchased and installed in your system, use the output from step 1 to verify the status of the LNP SMS feature.

Refer to the *LNP Feature Activation Guide* for instructions on enabling and turning on the LNP SMS feature and the features that must be turned on before the LNP SMS feature can be turned on

4. When the LNP SMS feature is turned on in the system, re-enter the command specifying the parameter that requires the LNP SMS feature to be on.

Call your Customer Care Center if this error message appears again.

E3612 Cmd Rej: SSN must be in SS-APPL table when PC is true point code

Commands Used: `chg-gta`, `ent-gta`

If you specify the `ssn` parameter and the value of the `pc/pca/pci/pcn/pcn24` is the STP's true point code, then the new or existing value of the `ssn` parameter must exist in the SS-APPL table.

Recovery

Re-enter the command without specifying the `ssn` parameter.

OR

1. Display a list of SSNs that exist in the SS-APPL table. Enter the `rtrv-appl-ss` command.
 2. Re-enter the command that generated this error message specifying a value for the `ssn` parameter.
-

E3615 Cmd Rej: T1 Port test command in progress

Commands Used: `tst-t1`

A T1 Port test is in progress. Only one port test is performed at a time. Subsequent test requests are rejected and this error is displayed.

Recovery

Wait for all tests to complete, then re-enter the `tst-t1` command.

E3616 Cmd Rej: APC/SAPC type and group code must match DPC

Commands Used: `chg-rte`, `ent-rte`, `chg-rtx`, `ent-rtx`

The route destination type and group codes that you specified do not match the route's linkset Adjacent / Secondary Adjacent Point Code type and group codes. Secondary Adjacent Point Codes allow an ITU linkset to support the routing and network management for multiple point code types and/or multiple group codes.

APC/SAPC type and group code must match the DPC. The STP ensures that the route destination type and group code match the route Link Set Adjacent PC /Secondary Adjacent PC type and group code.

The linkset APC/SAPC type and group code specified by the linkset name (`lsn`) parameter must match the DPC or its alias.

Recovery

1. Verify the Adjacent Point Code / Secondary Adjacent Point Code(s) of the linkset specified in the command that generated this error. Enter the **rtrv-ls** command.
 2. Perform one of the following:
 - Re-enter the command specifying a destination (**dpc**, **dpca**, **dpci**, **dpcn**, or **dpcn24**) that matches the point code type and group code of the Adjacent Point Code (**apc**, **apca**, **apci**, **apcn**, or **apcn24**) or one of the Secondary Adjacent Point Codes (**spcn** or **spci**) of the linkset specified by the **lsn** parameter.OR
 - Provision a Secondary Adjacent Point Code (**sapci**, **sapcn**, or **sapcn24**) that matches the point code type and group code of the destination point code (**dpci**, **dpcn**, or **dpcn24**) specified by the command. Enter the **chg-ls** command.
 3. When you have provisioned the Secondary Adjacent Point Code, re-enter the command causing this error message.
-

E3618 Cmd Rej: LHOST and ALHOST must refer to different IP addresses

Commands Used: chg-assoc, ent-assoc

In the command that you entered, the **lhost** and **alhost** names refer to the same IP address. The **lhost** and **alhost** names must refer to different IP addresses.

Recovery

Re-enter the command specifying **lhost** and **alhost** names that do not refer to the same IP address.

E3619 Cmd Rej: LHOST and ALHOST must refer to IP address on the same card

Commands Used: chg-assoc, ent-assoc

In the command that you entered, the **lhost** and **alhost** names reference IP addresses on different IP cards. The **lhost** and **alhost** names must reference IP addresses on the same IP card.

Recovery

Re-enter the command specifying **lhost** and **alhost** names that reference IP addresses on the same IP card.

E3629 Cmd Rej: Turn off EISCOPY before changing PVN and PVNMask**Commands Used: chg-netopts**

You entered a command to change the Private Virtual Network (PVN) IP address and the PVN subnet mask in the system. The EAGLE 5 Integrated Monitoring Support featurecopy function must be turned off before you can change the PVN and PVN submask addresses in the system. You can turn the copy function back on after the addresses are changed.

Recovery

1. Turn off the EIS copy function. Enter the **chg-eisopts:eiscopy=off** command.
 2. Re-enter the **chg-netopts** command to change the PVN and PVN submask.
 3. Turn the copy function on. Enter the **chg-eisopts:eiscopy=on** command.
-

E3630 Cmd Rej: Entry is already defined as the STP Options DefCC**Commands Used: chg-gsmopts**

You entered a value for the **multcc** or **nmultcc** parameter that already defined as the STP Options Default Country Code (**defcc**). The EAGLE 5 ISS does not support duplicate use of these entries.

Recovery

1. Enter the **rtrv-stpopts** and **rtrv-gsmopts** commands and examine the **defcc** and **multcc** definitions.
 2. Re-enter the **chg-gsmopts** command specifying a value for the **multcc** or **nmultcc** parameter that differs from all the **defcc** and **multcc** values shown in output from step 1.
-

E3632 Cmd Rej: MULTCC list is full

Commands Used: `chg-gsmopts`

You entered a value for the **multcc**, but the GSM Options MULTCC list has already reached its limit of ten entries. No additional **multcc** entries are allowed.

Recovery

Since the **multcc** entries are limit and filled, you must either accept the current entries, or delete one to make room for a new entry. In the latter case, use the command `chg-gsmopts:multcc=xxx:nmultcc=yyy` to replace value **xxx** with value **yyy** in the GSM Options MULTCC list.

E3633 Cmd Rej: MULTCC entry does not exist

Commands Used: `chg-gsmopts`

You specified a value for **multcc**, but that **multcc** does not exist.

Recovery

1. Enter the `rtrv-gsmopts` commands and examine the **multcc** definitions.
 2. Re-enter the `chg-gsmopts` command specifying a valid **multcc** entry.
-

E3634 Cmd Rej: Cannot set DefCC to none if a GSM Options MULTCC is defined

Commands Used: `chg-stpopts`

You cannot specify a Default Country Code of none (**defcc=none**) if a GSM Options MULTCC entry is already defined.

Recovery

If a GSM Options MULTCC is already defined, specifying **defcc=none** is invalid. You can either:

- Re-enter the command without specifying the **defcc=none** parameter.
- OR
- Delete all GSM Options MULTCC definitions, and then re-enter the `chg-stpopts` command.

For more information about this command refer to the Commands Manual.

E3635 Cmd Rej: UIM number does not exist in STP Trouble Text Table

Commands Used: `set-uim-acthresh`

You specified an invalid UIM number. The UIM number must exist in the system Trouble Text table.

Recovery

1. Verify that you have entered the UIM number correctly.
Refer to the Maintenance Manual for a complete list of UIM numbers.
 2. Re-enter the `set-uim-acthresh` command specifying a valid UIM number.
-

E3638 Cmd Rej: Failed Reading SS Appl table

Commands Used: `chg-gta`, `ent-gta`

The SS Appl table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3640 Cmd Rej: Failed reading OAP configuration table

Commands Used: `chg-oap-config`, `act-oap-config`

The OAP configuration table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3641 Cmd Rej: Specified OAP not available

Commands Used: `act-oap-config`

For the `act-oap-config` command to execute, the link from the EAGLE 5 ISS to the specified OAP(s) must be in service.

Recovery

1. Enter the **rtrv-oap-config** command to check whether the entry for **config** is **sngl** or **dual**.
2. Enter the **rtrv-trm** command to see which terminals are OAP terminals.
3. Enter the **rept-stat-trm** command to check whether the entry for the specified OAP(s) is IS-NR.
4. Correct any problems, and re-enter the **act-oap-config** command as you entered it previously.

Call your Customer Care Center if this error message appears again.

E3642 Cmd Rej: The current LSMS and the associated NSAP, PSEL and SSEL required

Commands Used: act-oap-config

Before this command can be executed, the database must be configured for Network Service Access Point (NSAP), Presentation Selector (PSEL), and Session Selector (SSEL) for the specified LSMS (main or shadow) for the LNP feature.

Recovery

1. View information about your OAP configuration. Enter the **rtrv-oap-config** command.
2. If there is an entry in the LSMS NSAP, LSMS SSEL, and LSMS PSEL fields for the specified Active LSMS (main or shadow) for the OAP(s) that you are configuring, re-enter the **act-oap-config** command.

Call your Customer Care Center if this error message appears again.

3. If entries are missing from the fields identified in step 2, enter the appropriate parameter values, using the **chg-oap-config** command.
 4. Re-enter the **act-oap-config** command that generated this error message.
-

E3643 Cmd Rej: If OAP parameter not specified as ALL, FORCE=YES required

Commands Used: act-oap-config

The **force=yes** parameter must be specified with the **act-oap-config** command, if you enter the **oap=a**, **oap=b**, or **oap=none** parameter.

Recovery

Re-enter the **act-oap-config** command specifying **force=yes**.

E3644 Cmd Rej: Specified OAP does not exist

Commands Used: **act-oap-config**

You specified the **oap=a**, **oap=b**, or **oap=all** parameter with the **act-oap-config** command. For the command to execute, the specified OAP(s) must be configured, and the link from the EAGLE 5 ISS to the OAP(s) must be in service.

Recovery

1. Verify the primary state (PST) of the OAP(s). Enter the **rept-stat-seas** command.
2. If the entry IS-NR does not appear in the *PST* field for the specified OAP(s), the link is not in service.
3. If the entry IS-NR does appear in the *PST* field for the specified OAP(s), re-enter the **act-oap-config** command.

Call your Customer Care Center if this error message appears again.

E3646 Cmd Rej: GWS must be ON before CNCF can be ON

Commands Used: **chg-feat**

The Gateway Screening (GWS) feature must be turned on before you can turn on the CNCF feature.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
2. If the GWS feature is on (from the output of step 1), re-enter the **chg-feat:cncf=on** command.

Call your Customer Care Center if this error message appears again.

3. If the GWS feature is off (from the output of step 1), turn it on. Enter the **chg-feat:gws=on** command.
 4. Turn on the CNCF feature. Enter the **chg-feat:cncf=on** command.
-

E3647 Cmd Rej: WNP feature must be ON

Commands Used: **chg-1np-serv**, **ent-1np-serv**

You specified **serv=wnp** or **nserv=wnp**, but the Wireless Number Portability (WNP) feature is turned off.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the WNP feature is turned on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the WNP feature is turned off (from the output of step 1), turn it on. Enter the **chg-feat** command.
 4. Re-enter the **ent-1np-serv** command specifying **serv=wnp**.
OR
 5. Re-enter the **chg-1np-serv** command specifying **nserv=wnp**.
-

E3648 Cmd Rej: XLAT must be DPCSSN and RI must be SSN if PC is the True PC

Commands Used: **chg-gta**, **ent-gta**

If the value of the **pc/pca/pci/pcn/pcn24** parameter is the STP's true point code, you must specify **dpcssn** for the new or existing **xlat** parameter and **ssn** for the new or existing **ri** parameter.

Recovery

Perform one of the following actions:

- Re-enter the command specifying **xlat=dpcssn** and **ri=ssn**.
- OR
- Re-enter the command specifying a point code that is not a true point code.
-

E3655 Cmd Rej: Failed reading the GWS Stop Action Set table

Commands Used: all gateway screening and gateway screening stop action set commands

The GWS Stop Action table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3656 Cmd Rej: ACTNAME specified must exist in the GWS Stop Action Set table

Commands Used: all gateway screening commands

You entered a value for the **actname** parameter that is not in the GWS Stop Action Set table.

Recovery

1. Enter the **rtrv-gws-actset** command. The *ACT NAME* field in the output shows a list of valid action names.
 2. If the value you entered appears in the output, call your Customer Care Center.
 3. If the value you entered does not appear in the output, it can be added to the database via the **chg-gws-actset** command.
-

E3657 Cmd Rej: NSR cannot be specified if ACTNAME is specified

Commands Used: all gateway screening commands, except gateway screening enter commands

You cannot specify both the **nsr** and the **actname** parameters with this command.

Recovery

Re-enter the command specifying a value for either the **actname** or the **nsr** parameter, but not both.

E3658 Cmd Rej: NSFI must be STOP if ACTNAME is specified

Commands Used: all gateway screening commands, except **ent-scr-aftpc** and **ent-scr-destfld**

To specify the **actname** parameter, specify the value for the Next Screen Function Identifier (**nsfi**) equal to **stop** (**nsfi=stop**).

Recovery

Re-enter the command specifying the **actname** parameter and **nsfi=stop**.

E3661 Cmd Rej: Target drive capacity must be sufficient to perform request

Commands Used: **chg-db**

The target drive does not have sufficient capacity to hold the required amount of data. Refer to the *Commands Manual* for the disk drive capacity requirements.

Recovery

Call your Customer Care Center if this error message appears again.

E3663 Cmd Rej: Failed accessing the memory equipage table

Commands Used: **chg-db**

The Memory Equipage table is corrupt or cannot be found by the system.

Recovery

Re-enter the **chg-db** command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3664 Cmd Rej: Capacity of TDM(s) / TSM(s) insufficient to support request

Commands Used: chg-db

Both capacity and memory must be sufficient to support the number of ported telephone numbers allowed by the number of LNP 4DIGIT objects configured in the database (current setting plus the value of the **num** parameter). Table 2-28 shows the TSM and TDM requirements.

Table 2-28. TSM and TDM Memory Requirements

Number of LNP 4DIGIT Objects	Number of Ported Numbers Supported	TSM Memory Requirements	Fixed Disk Drive Capacity Requirements
1	2 Million	256 Mbytes	4 Gigabytes
2	4 Million	512 Mbytes	4 Gigabytes
3	6 Million	768 Mbytes	4 Gigabytes
4	8 Million	1024 Mbytes	4 Gigabytes
5	10 Million	1024 Mbytes	4 Gigabytes
6	12 Million	1024 Mbytes	4 Gigabytes

Recovery

Call your Customer Care Center.

E3668 Cmd Rej: No other optional parameters may be specified with "ALL"

Commands Used: chg-gws-actset

You entered this command specifying **all=none** specified and with values for other optional parameters. If **all=none** is specified, you cannot specify other optional parameters.

Recovery

Re-enter the command specifying **all=none** and no other optional parameters.

E3669 Cmd Rej: The CNCF feature must be on if CNCF is specified

Commands Used: **chg-gws-actset**

You cannot specify a value of **cncf** for a parameter from **act1** through **act10** if the Calling Name Conversion Feature (CNCF) is turned off.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the CNCF and GWS features are on, re-enter the **chg-gws-actset** command.
Call your Customer Care Center if this error message appears again.
 3. If the CNCF feature is turned off (from the output of step 1) and GWS is on, turn the CNCF feature on. Enter the **chg-feat:cncf=on** command.
 4. Re-enter the **chg-gws-actset** command.
-

E3671 Cmd Rej: Duplicate ACTs in different slots are not allowed

Commands Used: **chg-gws-actset**

You cannot enter the same gateway screening stop action value (**cncf**, **copy**, **none**, or **rdct**) for more than one parameter (**act1** through **act10**) in a stop action set.

Recovery

Re-enter the **chg-gws-actset** command without specifying identical values for more than one stop action within a stop action set.

Call your Customer Care Center if this error message appears again.

E3672 Cmd Rej: ACTNAME already exists in GWS Action Set Table

Commands Used: `chg-gws-actset`

The value you entered for the **actname** parameter is already defined in the database.

Recovery

1. Verify that the value you entered is already in the database. Enter the `rtrv-gws-actset` command.
 2. Re-enter the `chg-gws-actset` command specifying a different value for the **actname** parameter.
-

E3673 Cmd Rej: COPY must be in ACT1

Commands Used: `chg-gws-actset`

You entered the parameter value of **copy** for an action set other than **act1**. The **copy** value can be used only with the **act1** parameter.

Recovery

Re-enter the command specifying **act1=copy**.

E3674 Cmd Rej: RDCT must be in lowest priority action slot

Commands Used: `chg-gws-actset`

You entered the parameter value of **rdct** (redirect) for a step action other than the last step action specified for the command. The **rdct** parameter value can only be specified for the last step action in an action set.

Recovery

Re-enter the command specifying **rdct** for the last step action in the action set.

E3675 Cmd Rej: An ACTNAME must be specified

Commands Used: chg-gws-actset

You entered a new gateway screening stop action set in the database, but you did not specify a value for the **actname** parameter. A value for the **actname** parameter is required when an action set is first entered in the database. Afterward, the **actname** parameter is optional.

Recovery

Re-enter the **chg-gws-actset** command specifying a unique value for the **actname** parameter.

E3678 Cmd Rej: ACTNAME and ACTID cannot both be specified

Commands Used: rtrv-gws-actset

You cannot enter the **rtrv-gws-actset** command specifying both the **actname** and the **actid** parameters. Specify either the **actname** or the **actid** parameter.

Recovery

Re-enter the **rtrv-gws-actset** command specifying a value for either the **actname** or the **actid**, but not both.

E3679 Cmd Rej: FORCE=YES must be specified to change existing stop action

Commands Used: chg-gws-actset

You cannot change an existing stop action within a stop action set without specifying the **force=yes** parameter.

Recovery

Re-enter the **chg-gws-actset** command specifying **force=yes**.

E3680 Cmd Rej: No match on ACTNAME parameter during retrieve

Commands Used: all gateway screening retrieve commands

The entered GWS stop action set name (**actname**) was not found.

Recovery

Enter the command specifying the screening reference to show all action set name identifiers, as well as other values for the screening reference.

E3681 Cmd Rej: Source and destination combination is not allowed

Commands Used: `copy-gp1`

GPLs can be copied only as follows:

- From the fixed disk on the active TDM to the removable cartridge
- From the removable cartridge to the fixed disk on the standby TDM
- From the active TDM to the standby TDM
- From the standby TDM to the removable cartridge

The active TDM cannot be the destination.

Recovery

Re-enter the `copy-gp1` command specifying the correct values for the `sloc` and `dloc` parameters.

Refer to the *Commands Manual* for information about the `copy-gp1` command.

Call your Customer Care Center if this error message appears again.

E3682 Cmd Rej: GWS and LNP must be ON before TLNP can be ON

Commands Used: `chg-feat`

You cannot turn on the Triggerless LNP feature before both the Gateway Screening and the Local Number Portability features are turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** and the **rtrv-ctrl-feat** command.
2. If both the GWS and LNP features are on (from the output of step 1), re-enter the **chg-feat** command.

Call your Customer Care Center if this error message appears again.

3. If GWS and/or LNP are off (from the output of step 1):
 - Turn on the GWS feature. Enter the **chg-feat:gws=on** command.
 - Turn on the LNP feature. Enter the **chg-feat:lnp=on** command.

Refer to the “Activating the LNP Feature” procedure in the *LNP Feature Activation Guide*, and call your Customer Care Center before starting the process

4. Re-enter the **chg-feat:tlnp=on** command to turn on the TLNP feature.
-

E3683 Cmd Rej: TLNP feature must be ON

Commands Used: **chg-gws-actset**, **chg-lnpopts**

You entered the **chg-gws-actset** command and the Triggerless LNP Feature (TLNP) is off.

OR

You entered the **chg-lnpopts** and specified the **jipprv** or **jipdigits** parameter, and the Triggerless LNP Feature (TLNP) is off.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the TLNP feature is turned on (from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the TLNP feature is turned off (from the output of step 1), turn it on. Enter the **chg-feat:tlnp=on** command.
 4. Re-enter the command that generated this error message.
-

E3684 Cmd Rej: TLNP and RDCT cannot be in the same action set

Commands Used: `chg-gws-actset`

You cannot specify both the **tlnp** and **rdct** stop actions within the same action set. The Triggerless LNP (**tlnp**) gateway screening stop action cannot be specified in the same action set with the Redirect (**rdct**) gateway screening stop action.

Recovery

Re-enter the command specifying either **tlnp** or **rdct** for the action set.

E3685 Cmd Rej: TLNP and CNCF cannot be in the same action set

Commands Used: `chg-gws-actset`

You cannot specify both the **tlnp** and **cncf** stop actions within the same action set. The Triggerless LNP (**tlnp**) gateway screening stop action cannot be specified in the same action set with the Calling Name Conversion Facility (**cncf**) gateway screening stop action.

Recovery

Re-enter the command specifying either **tlnp** or **cncf** for the action set.

E3686 Cmd Rej: GTT DBMM table is full

Commands Used: `ent-gttset`, `ent-tt`

The GTT DBMM table is an internal table that should never reach full capacity.

Recovery

If this error appears call your Customer Care Center.

E3687 Cmd Rej: Cannot enter MULTCC if STP Options DefCC is NONE

Commands Used: `chg-stpopts`

You cannot specify a GSM Options MULTCC entry when the STP Options Default Country Code is defined as none (**defcc=none**).

Recovery

1. Because the STP Options Default Country Code is **none**, you must specify a value for the default country code (**defcc**) first, as in **chg-stpopts: defcc=xxx**.
 2. Re-enter the **chg-stpopts** command specifying the Multiple Country Code (**multcc**) parameter.
-

E3688 Cmd Rej: 15-minute measurement collection in progress

Commands Used: **chg-measopts**, **rept-ftp-meas**, **rept-meas**, **rept-stat-meas**

The **chg-measopts: collect15min=off** command (to turn off the 15 Minute Measurements feature) was entered at a time when the quarter-hour collection was in progress.

OR

The **rept-meas** command was entered with either the **type=systot**, **type=comp**, or **type=avl** parameter during routine collection.

OR

The **rept-ftp-meas** command was entered with either the **type=systot**, **type=comp**, **type=gtwy**, or **type=avl** parameter during routine collection.

Recovery

To get a report before routine collection has started, do one of the following actions:

- Enter the command specifying the **period=last** parameter.
- Enter the command without specifying the **period** parameter.

OR

Re-enter the command after collection has completed. (The prior period is no longer accessible).

E3689 Cmd Rej: Period must be 1/4 hour boundary

Commands Used: `rept-ftp-meas`, `rept-meas`

The command was entered with the **period=specific** and **qh** parameters, and values for the minutes portion of the **qh** parameter were not **00**, **15**, **30**, and **45**. The value of the **qh** parameter is in the form of HHMM, where HH is the hour, MM is the minutes. The hour is based on a 24-hour clock (**00-24**). Valid values for the minutes are **00**, **15**, **30**, and **45**. These values are the only values allowed for the minutes portion of the **qh** parameter.

Recovery

Re-enter the command specifying the **period=specific** and quarter hour (**qh**) parameters, and the values **00**, **15**, **30**, and **45** for the minutes portion of the **qh** parameter.

E3690 Cmd Rej: QH cannot be specified unless 15 min meas is turned on

Commands Used: `rept-ftp-meas`, `rept-meas`

The 15 Minute Measurements feature must be enabled and turned on before you can specify the quarter hour (**qh**) parameter.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Verify that the 15 Minute Measurements feature has been purchased, installed, and turned on. Contact your Customer Care Center if you need assistance.
3. If you have purchased and installed the 15 Minute Measurements feature, you must:
 - Enable the feature. Enter the `enable-ctrl-feat` command.
 - Turn on the feature. Enter the `chg-ctrl-feat` command.

Refer to the *Commands Manual* and the *Database Administration Manual -- System Management* for more information about turning on the 15 Minute Measurements feature.

4. When the 15 Minute Measurements feature is turned on, re-enter the command that generated this error message.
-

E3692 Cmd Rej: Cannot turn on feature with EMDC provisioned

Commands Used: `chg-ctrl-feat`

The command to turn on the 15 Minute Measurements collection feature is not supported with an EMDC card provisioned. These features are mutually exclusive.

Recovery

You cannot turn on the 15 Minute Measurements feature while an EMDC card is provisioned. You must either remove any provisioned EMDC card or stop issuing the command to enable the 15 Minute Measurements feature.

E3693 Cmd Rej: collect=on cannot be specified with 15 min coll operational

Commands Used: `chg-meas`

The **collect=on** parameter cannot be specified when the 15 Minute Measurements collection is operational. The 15 Minute Measurements collection option provides for only scheduled FTP reports; the 15 Minute Measurements feature does not support any scheduled UI reports. The **collect=on** parameter controls overall measurement collection and scheduled reporting. This message indicates the 15 Minute Measurements collection is already operational and only the supported 15 minute scheduled FTP reports will be available.

Recovery

Since the 15 Minute Measurements collection option (**collect15min=on**) is already on, you cannot issue the **collect=on** parameter. No scheduled UI reports are available for the 15 Minute Measurements feature.

E3694 Cmd Rej: QH and HH cannot be specified together

Commands Used: `rept-ftp-meas`, `rept-meas`

You cannot specify the quarter hour (**qh**) and half hour (**hh**) parameters together.

Recovery

Re-enter the command specifying either the **qh** or **hh** parameters, but not both.

E3695 Cmd Rej: Command not supported for non-IPGWx linksets**Commands Used: rept-stat-iptps**

You entered a command to report the current and peak IPGWx TPS utilization, but the linkset specified is not an IPGWx linkset. The EAGLE 5 ISS does not support this command for non-IPGWx linksets.

Recovery

1. Display the linksets in the database. Enter the **rtrv-ls** command.
 2. Re-enter the **rept-stat-iptps** command specifying one of the linkset names from step 1.
-

E3696 Cmd Rej: Cannot provision EMDC card with 15 min coll feature on**Commands Used: ent-card**

You cannot provision an EMDC card when the 15 Minute Measurements feature is turned on.

Recovery

Re-enter the **ent-card** command without specifying the **appl=emdc** parameter.

E3697 Cmd Rej: 15-minute measurement feature must be on**Commands Used: chg-measopts**

The prerequisite for the command you entered is the 15 Minute Measurements feature. Before you specify the **collect15min=on** parameter, you must first enable and turn on the 15 Minute Measurements feature.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.
2. Verify that the 15 Minute Measurements feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the 15 Minute Measurements feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

4. Turn the feature on. Enter the **chg-ctrl-feat** command.
Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information about turning on this feature
 5. When the feature is turned on, re-enter the **chg-measopts** command.
-

E3698 Cmd Rej: At least one MCP card must be IS-NR**Commands Used: chg-ctrl-feat**

When you entered the command, no Measurements Collection Processor card was IS-NR (in service-normal).

Recovery

1. Enter the **rtrv-card** and **rept-stat-card** commands to verify the status of MCPM cards in the system.
2. Enter the **rtrv-measopts** command to verify that the Measurements Platform feature is enabled.
3. When the Measurements Platform feature is enabled and at least one MCP card is IS-NR, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3699 Cmd Rej: EIR feature must be ON

Commands Used: chg-gsmopts, chg-measopts, chg-sid, chg-srvsel, chg-ss-appl, ent-map, ent-srvsel, ent-ss-appl, ent-trace, rept-fpt-meas, rtrv-data-rtdb

The prerequisite for the command and/or parameters as entered is the Equipment Identity Register (EIR) feature. Before you can enter the following combinations of commands and parameters, you must first turn on the EIR feature.

- For the **chg-gsmopts** command, you entered the **eirimsichk=on** or **eirgrsp=on** or **eirrsptype=on** parameter.
- For the **chg-measopts** command, you entered the **mtcdeir=on** or **mtcheir=on** parameter.
- For the **chg-sid** command, you entered the **cpctype=eir** parameter.
- For the **chg-srvsel** or **ent-srvsel** command, you entered the **serv=eir** or **nserv=eir** parameter.
- For the **chg-ss-appl** or **ent-ss-appl** command, you entered the **appl=eir** parameter.

- For the **ent-map** command, you entered a true point code for the **pci** parameter.
- For the **ent-trace** or **rtrv-data-rtddb** command, you entered the **imei=** parameter.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.
2. Verify that the EIR feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the EIR feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information. Turn on the EIR feature. Enter the **chg-ctrl-feat:eir=on** command.

Refer to the *Commands Manual* and the *Feature Manual - EIR* for more information about turning on this feature

4. When the EIR feature is turned on, re-enter the command causing this message.
-

E3700 Cmd Rej: SEAC CLI parameter requires SEAS feature

Commands Used: **chg-oap-config**

The SEAS feature must be turned on before the **seaccli** parameter can be specified.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the SEAS feature is on (from the output of step 1), re-enter the **chg-oap-config** command.
Call your Customer Care Center if this error message appears again.
 3. If the SEAS feature is off (from the output of step 1), turn it on. Enter the **chg-feat** command.
 4. When the SEAS feature is turned on, re-enter the **chg-oap-config** command that generated this error message.
-

E3701 Cmd Rej: X.25 packet size parameter requires SEAS feature

Commands Used: `chg-oap-config`

The SEAS feature must be turned on before the `x25ps` parameter can be specified.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
 2. If the SEAS feature is on (from the output of step 1), re-enter the `chg-oap-config` command.
Call your Customer Care Center if this error message appears again.
 3. If the SEAS feature is off (from the output of step 1), turn it on. Enter the `chg-feat` command.
 4. When the SEAS feature is turned on, re-enter the `chg-oap-config` command that generated this error message.
-

E3702 Cmd Rej: X.25 mode parameter requires SEAS feature

Commands Used: `chg-oap-config`

The SEAS feature must be turned on before the `x25mode` parameter can be specified.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
 2. If the SEAS feature is on (from the output of step 1), re-enter the `chg-oap-config` command.
Call your Customer Care Center if this error message appears again.
 3. If the SEAS feature is off (from the output of step 1), turn it on. Enter the `chg-feat` command.
 4. When the SEAS feature is turned on, re-enter the `chg-oap-config` command that generated this error message.
-

E3703 Cmd Rej: NSAP parameter requires LNP feature

Commands Used: `chg-oap-config`

The LNP feature must be turned on before the **mnsap** and **snsap** parameters can be specified.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-ctrl-feat` command.
2. If the LNP feature is on (from the output of step 1 - the LNP ported TNs entry appears in the output with a quantity less than or equal to **12,000,000**), re-enter the `chg-oap-config` command.

Call your Customer Care Center if this error message appears again.

3. If the LNP feature is off (from the output of step 1- the LNP ported TNs entry does not appear in the output), turn it on. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Refer to the "Activating the LNP Feature" procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center. before starting the process.

4. Re-enter the `chg-oap-config` command that generated this error message.
-

E3704 Cmd Rej: SSEL parameter requires LNP feature

Commands Used: `chg-oap-config`

The **spse1** and **ssse1** parameters require that the LNP feature be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.
2. If the LNP feature is on (from the output of step 1 - the LNP ported TNs entry appears in the output with a quantity less than or equal to **12,000,000**), re-enter the command.

Call your Customer Care Center if this error message appears again.

3. If the LNP feature is off (from the output of step 1- the LNP ported TNs entry does not appear in the output), turn it on. Enter the **enable-ctrl-feat** command. (Refer to the “Activating the LNP Feature” procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting the process).
 4. Re-enter the command that generated this error message.
-

E3705 Cmd Rej: PSEL parameter requires LNP feature

Commands Used: **chg-oap-config**

The **mpsel** and **spsel** parameters require that the LNP feature be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - LNP* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.
2. If the LNP feature is **on** (from the output of step 1 - the LNP ported TNs entry appears in the output with a quantity less than or equal to 12,000,000), re-enter the command.

Call your Customer Care Center if this error message appears again.

3. If the LNP feature is off (from the output of step 1- the LNP ported TNs entry does not appear in the output), turn it on. Enter the **enable-ctrl-feat** command.

Refer to the “Activating the LNP Feature” procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting the process.

4. Re-enter the **chg-oap-config** command that generated this error message.
-

E3706 Cmd Rej: LSMS parameter requires LNP feature

Commands Used: `chg-oap-config`

The `lsms` parameter requires that the LNP feature be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - LNP* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-ctrl-feat` command.
2. If the LNP feature is on (from the output of step 1 - the LNP ported TNs entry appears in the output with a quantity less than or equal to **12,000,000**), re-enter the `chg-oap-config` command.

Call your Customer Care Center if this error message appears again.

3. If the LNP feature is off (the LNP ported TNs entry does not appear in the output from step 1), turn it on. Enter the `chg-ctrl-feat` command.

Refer to the "Activating the LNP Feature" procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting the process.

4. Re-enter the `chg-oap-config` command that generated this error message.
-

E3707 Cmd Rej: OAP Hostname required before OAP update

Commands Used: `act-oap-config`

The database must be configured with the Hostname for either the SEAS or LNP feature before this command can be executed.

Recovery

1. View information about your OAP configuration. Enter the `rtrv-oap-config` command.
2. If there is an entry in the HOSTNAME field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.

Call your Customer Care Center if this error message appears again.

3. If there is not an entry in the HOSTNAME field of the output, enter names for **aname** (OAP A) and/or **bname** (OAP B). Enter the **chg-oap-config** command.
 4. Re-enter the **act-oap-config** command that generated this error message.
-

E3708 Cmd Rej: OAP CFG required before OAP update

Commands Used: **act-oap-config**

The database must be configured for single or dual OAP(s) for either the SEAS or LNP feature before the **act-oap-config** command can be executed.

Recovery

1. View information about your OAP configuration. Enter the **rtrv-oap-config** command.
 2. If an entry exists in the CONFIG field of the output for the OAP(s) you are configuring, re-enter the **act-oap-config** command.
Call your Customer Care Center if this error message appears again.
 3. If there is no entry in the CONFIG field of the output, specify a **cfg** value, using the **chg-oap-config** command.
 4. Re-enter the **act-oap-config** command that generated this error message.
-

E3710 Cmd Rej: APPL not valid for command

Commands Used: **ent-card**

This **appl** parameter identifies the type of software that will run on the card. The values specified for the **appl** parameter cannot be found or it has not been defined. The following applications are valid for the **appl** parameter: **atmansi**, **atmitu**, **ccs7itu**, **ebdablm**, **ebdadcm**, **emdc**, **eoam**, **eroute**, **gls**, **ipgwi**, **iplim**, **iplimi**, **ips**, **mcp**, **sccp**, **ss7ansi**, **ss7gx25**, **ss7ipgw**, **stplan**, **vscpp**, **vxwslan**.

Recovery

Re-enter the **ent-card** command specifying a valid value for the **appl** parameter.

Refer to the *Commands Manual* for a list of valid values.

E3713 Cmd Rej: OAP IP Address required before OAP update**Commands Used: act-oap-config**

The database must be configured for Common Language Location Identifier for the LNP feature before this command can be executed.

Recovery

1. View information about your OAP configuration. Enter the **rtrv-oap-config** command.
 2. If there is an entry in the IP ADDRESS field of the output for the OAP(s) you are configuring, re-enter the **act-oap-config** command.
Call your Customer Care Center if this error message appears again.
 3. If there is not an entry in the IP ADDRESS field of the output, enter names for **aipaddr** (OAP A) and/or **bipaddr** (OAP B). Enter the **chg-oap-config** command.
 4. Re-enter the **act-oap-config** command that generated this error message.
-

E3715 Cmd Rej: Insufficient #SCCP cards to support LIM - use FORCE=YES**Commands Used: ent-card**

You tried to add an SS7 card (LIM card or DCM card containing IP links) to the database; however, the installation of the additional card might push the system's transactions-per-second (TPS) capacity beyond the level that the EAGLE 5 ISS can handle. The EAGLE 5 ISS calculates the current system TPS capacity based on the number and type of provisioned SCCP cards available in the system. An SCCP card can be either a TSM card running the **sccp** application, or a DSM card running the **vsccp** application. Each SCCP card can handle the following number of transactions-per-second: 850 for a TSM card and 1700 for a DSM card. The system must contain enough SCCP cards to handle the number of SCCP transactions-per-second that the SS7 cards send to the SCCP cards.

When you issue the **ent-card** command to add a card that requests service from either an SCCP card or VS CCP card, the EAGLE 5 ISS adds the current TPS level to the estimated TPS level for the new card. The EAGLE 5 ISS uses the following values to derive the TPS estimate: 53 for LSL (cards provisioned as SS7ANSI, CCS7ITU or SS7GX25 cards), 480 for ATM cards, and 1000 for IPLIM cards. The EAGLE 5 ISS then compares the sum to a user-configured threshold set via the **chg-th-alm** command. The purpose of the threshold is to generate an alarm (UAM 0330) if the threshold is exceeded. The SCCP TPS threshold also triggers this error message if you issue the **ent-card** command and the resulting TPS level (the current TPS plus the estimated TPS for the new card) would be greater than the threshold configured.

Recovery

Perform one of the following actions:

1. Enter the **chg-th-alm** command to increase the TPS threshold.
2. Re-enter the command that generated this error message.

OR

1. Re-enter the command that generated this error message specifying the **force=yes** parameter.
2. Add the required number of SCCP cards to the database after you add the SS7 card.

OR

1. Add the required number of SCCP cards to the database.
 2. Add the SS7 card to the database.
-

E3716 Cmd Rej: APPL parameter must be specified with CONVERTNET action

Commands Used: **act-upgrade**

If you specify the **action=convertnet** parameter, you must also specify the **appl** parameter.

Recovery

Re-enter the **act-upgrade** command specifying the **action=convertnet** parameter and the **appl** parameter.

E3717 Cmd Rej: Both LIMIT and INTRVL must be specified for UIM threshold.

Commands Used: **set-uim-acthresh**

Both the **limit** and **intrvl** parameters must be specified to create a new UIM threshold.

Recovery

Re-enter the **set-uim-acthresh** command specifying both the **limit** and **intrvl** parameters.

E3718 Cmd Rej: SEAC CLLI required before OAP update

Commands Used: `act-oap-config`

The database must be configured for the SEAC Common Language Location Identifier for the SEAS feature before this command can be executed.

Recovery

1. View information about your OAP configuration. Enter the `rtrv-oap-config` command.
 2. If there is an entry in the SEAC CLLI field of the output for the OAP(s) you are configuring, re-enter the `act-oap-config` command.
Call your Customer Care Center if this error message appears again.
 3. If there is no entry in the SEAC CLLI field of the output, specify a `seaccli` value. Enter the `chg-oap-config` command.
 4. Re-enter the command that generated this error message.
-

E3719 Cmd Rej: SEAS X.25 packet size required before OAP update

Commands Used: `act-oap-config`

The database must be configured for X.25 Packet Size for the SEAS feature before this command can be executed.

Recovery

1. View information about your OAP configuration. Enter the `rtrv-oap-config` command.
 2. If there is an entry of 7 or 8 in the X.25 PACKET SIZE field of the output for the OAP(s) you are configuring, re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If there is no entry in the X.25 PACKET SIZE field of the output, specify an `x25ps` value, using the `chg-oap-config` command.
 4. Re-enter the command that generated this error message.
-

E3720 Cmd Rej: SEAS X.25 mode required before OAP update

Commands Used: `act-oap-config`

The database must be configured for X.25 mode for the SEAS feature before this command can be executed.

Recovery

1. Enter the **rtrv-oap-config** command to view information about your OAP configuration.
 2. If there is an entry of DTE or DCE in the X.25 MODE field of the output for the OAP(s) you are configuring, re-enter the **act-oap-config** command.
Call your Customer Care Center if this error message appears again.
 3. If there is not an entry in the X.25 MODE field of the output, specify an **x25mode** value. Enter the **chg-oap-config** command.
 4. Re-enter the command that generated this error message.
-

E3725 Cmd Rej: Removable cartridge database level is not compatible

Commands Used: **act-upgrade**

You entered the command **act-upgrade:action=converttoam** to convert the active OAM database, but the database on the removable cartridge (MDAL) is not at level 1. Level 1 is the required level for upgrade.

Recovery

1. Enter the command **act-upgrade:action=dbstatus** to verify the level of the removable cartridge (MDAL). The information is displayed in the LEVEL field for the MDAL entry.
2. If the MDAL is at level 1, re-enter the **act-upgrade** command.
Call your Customer Care Center if this error message appears again or if the MDAL is at a level other than 1.

NOTE: Leaving a removable cartridge in the MDAL for a prolonged period can cause damage. Remove the cartridge after the command or procedure completes.

E3726 Cmd Rej: Active device state does not permit database change

Commands Used: **dlt-card**, **dlt-slk**

You attempted to delete a card or a signaling link that is in a state other than Out-of-Service - Maintenance-Disabled (OOS-MT-DSBLD).

Recovery - dlt-card

1. Enter the **inh-card** command to change the state of the card to OOS-MT-DSBLD.

NOTE: If the card contains signaling links, all links must be OOS-MT-DSBLD before you can inhibit the card. Refer to the **canc-slk** (**dact-slk**) command in the *Commands Manual*.

2. Re-enter the **dlt-card** command that generated this error message.
-

Recovery - dlt-slk

1. Enter the **canc-slk** or **dact-slk** command to disconnect (deactivate) the signaling link. The link is placed in the OOS-MT-DSBLD state.

2. Perform one of the following actions:

If the link to be deleted is the last or only link in a link set that is still used by an ordered route, enter the **dlt-slk** command specifying the **force** parameter. The command deletes the link you specify in the **loc** and **port** parameters.

If the link set has more than one link, enter the **dlt-slk** command without specifying the **force** parameter to delete the link that you specify in the **loc** and **port** parameters.

3. If you want to delete the link set after all of its links have been deleted, use the **dlt-ls** command. Refer to the *Commands Manual*.
-

E3727 Cmd Rej: Max number of cards of application type already exist**Commands Used: ent-card**

You cannot exceed the maximum number of cards allowed for that application type in the database. Refer to the **ent-card** command in the *Commands Manual* for a list of card types, their associated part numbers and application types, and the maximum number cards allowed in the database.

Recovery

1. Display the cards and assigned application types in the database. Enter the **rtrv-card** command.
2. If the number of cards per application type is less than the maximum number allowed, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3728 Cmd Rej: Card(s) not in-service normal - FORCE parameter required

Commands Used: `act-upgrade`, `init-card`

You attempted the command without all cards of the specified GPL type being in the in-service normal (IS-NR) state. In such cases, the **force** parameter is required.

Recovery

Re-enter the command specifying the **force** parameter.

E3729 Cmd Rej: APPL parameter valid only with CONVERTNET action

Commands Used: `act-upgrade`

You specified the **appl** parameter with a parameter other than **action=convertnet**. The **appl** parameter is valid only when the **action=convertnet** parameter is also specified.

Recovery

Perform one of the following actions:

- Re-enter the **act-upgrade** command without specifying the **appl** parameter.
- OR
- Re-enter the **act-upgrade** command specifying the **appl** and **action=convertnet** parameters.
-

E3731 Cmd Rej: Invalid Hostname

Commands Used: `chg-appl-sock`, `chg-assoc`, `dlt-ip-host`,
`ent-appl-sock`, `ent-assoc`, `ent-ip-host`, `rtrv-appl-sock`,
`rtrv-assoc`, `rtrv-ip-host`

The value specified for the hostname is invalid. The naming conventions for the **host**, **lhost**, and **rhost** parameters specify that they must be comprised of (a-z, A-Z, 0-9, -, .), beginning with a letter and up to 60 characters in length.

Recovery

Re-enter the command specifying a value for the hostname that conforms to the specified naming conventions.

Call your Customer Care Center if this error message appears again.

E3732 Cmd Rej: Invalid Subnet Mask

Commands Used: `chg-ip-lnk`, `ent-ip-rte`

The value specified for the **submask** parameter is invalid. If the **ipaddr** parameter is specified, the **submask** parameter must be specified and must be valid for the class of the entered IP address, as shown in Table 2-29:

Table 2-29. Valid Subnet Mask Values

Class A Networks	Class A or B Networks	Class A, B, or C Networks
255.0.0.0	255.255.0.0	255.255.255.0
255.192.0.0	255.255.192.0	255.255.255.192
255.224.0.0	255.255.224.0	255.255.255.224
255.240.0.0	255.255.240.0	255.255.255.240
255.248.0.0	255.255.248.0	255.255.255.248
255.252.0.0	255.255.252.0	255.255.255.252
255.254.0.0	255.255.254.0	
255.255.128.0	255.255.255.128	

Recovery

Re-enter the command specifying a value for the **submask** parameter derived from Table 2-29 on page 2-584.

Call your Customer Care Center if this error message appears again.

E3733 Cmd Rej: Socket name not found

Commands Used: `chg-appl-sock`, `dlt-appl-rtkey`, `dlt-appl-sock`

The specified socket name was not found in the associated table. The following Recovery procedures list by command the remedial action to take for this error.

Recovery - dlt-appl-rtkey

1. Enter the **rtrv-appl-rtkey** command to determine if the entered socket name is present in the **SNAME** field of the output.
 2. If the entered name is present, re-enter the command.
Call your Customer Care Center if this error message appears again.
-

Recovery - chg-appl-sock, dlt-appl-sock

1. Enter the **rtrv-appl-sock** command to determine if the entered socket name is present in the SNAME field of the output.
 2. If the entered name is present, re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E3735 Cmd Rej: Hostname must be unique**Commands Used: ent-ip-host**

You tried to enter a hostname (**host**) that is already in the IP host table. The host name to be added must be unique.

Recovery

1. Enter the **rtrv-ip-host** command specifying no parameters, to show the host names currently in the IP host table. This information is shown in the HOST field of the output.
 2. Re-enter the command specifying a host name that does not match any of the names displayed in the HOST field in the output of step 1.
-

E3736 Cmd Rej: Socket name already exists**Commands Used: ent-appl-rtkey, ent-appl-sock**

You entered a socket name (**sname**) using the **ent-appl-sock** command that is already in the Socket table. The socket name to be added must be unique in the Socket table.

OR

You entered a socket name into the Routing Key table with filter parameters (**dpc/dpca, si, ssn, opc, cics, cice**), using the **ent-appl-rtkey** command, but an identical socket name with identical filter parameters is already present.

The following Recovery procedures list by command the remedial action to take for this error.

Recovery - ent-appl-rtkey

1. Enter the **rtrv-appl-rtkey** command and verify that the socket name and filter parameters you entered already exist in the Routing Key table.
2. If the socket name and filter parameters are not present in the output of step 1, re-enter the **ent-appl-rtkey** command.

Call your Customer Care Center if this error message appears again.

Recovery ent-appl-sock

1. Display the socket data. This information is shown in the SNAME field of the output. Enter the **rtrv-appl-sock** command specifying no parameters.
 2. Re-enter the **ent-appl-sock** command specifying a socket name that does not match any of the socket names displayed in the SNAME field in the output of step 1.
-

E3737 Cmd Rej: Socket connection parameters must be unique

Commands Used: **chg-appl-sock**, **ent-appl-sock**

You entered parameter values to fully specify a socket (**lhost**, **rhost**, **lport**, **rport**, **port**) but these values are identical to another fully specified socket that already exists in the Socket table under another name (**sname**). Socket connection parameters must be unique for each socket name.

Recovery

1. Verify that an entry exists with the parameter values you specified, but with a different socket name. Enter the **rtrv-appl-sock** command.
2. If no such entry exists,
 - re-enter the command that generated this error message.
 - OR
 - re-enter the command specifying different socket connection parameters.

Call your Customer Care Center if this error message appears again.

E3738 Cmd Rej: Host table is full

Commands Used: `ent-ip-host`

The IP Host table is full. You must delete an existing entry before adding another one to the IP Host table.

Recovery

1. Display the entries in the IP Host table. Enter the `rtrv-ip-host` command.
2. Delete an existing entry from the IP host table. Enter the `dlt-ip-host` command specifying the `host` parameter for the entry you want to delete.
3. Add the desired IP host entry to the IP Host table. Re-enter the `ent-ip-host` command specifying the `host` parameter entry you want to add.

Call your Customer Care Center if this error message appears again.

E3739 Cmd Rej: No Entry found

Commands Used: `dlt-ip-host`

The value specified for the `host` parameter was not found in the IP host table.

Recovery

1. Verify that the host name you entered is not in the IP Host table. Enter the `rtrv-ip-host` command. Host names are shown in the HOST field of the output.
2. If the host name you entered is shown in the HOST field of the output, re-enter the `dlt-ip-host` command.

Call your Customer Care Center if this error message appears again.

E3740 Cmd Rej: If AUTO=yes, then DUPLEX and SPEED are not allowed

Commands Used: `chg-ip-lnk`

If you enter the `chg-ip-lnk` command specifying `auto=yes`, you cannot specify the `duplex` and/or `speed` parameters.

Recovery

Perform one of the following actions:

Re-enter the **chg-ip-lnk** command specifying **auto=yes** without specifying the **duplex** and/or **speed** parameters.

OR

Re-enter the **chg-ip-lnk** command specifying **auto=no** and the **duplex** and/or **speed** parameters.

E3741 Cmd Rej: If TIMER is specified, TVALUE must be specified

Commands Used: **chg-dcmps**

If you enter the **chg-dcmps** command specifying the **timer** parameter, you must also specify the **tvalue** parameter.

Recovery

Re-enter the **chg-dcmps** command specifying both the **timer** and the **tvalue** parameters.

E3742 Cmd Rej: If PARM is specified, PVALUE must be specified

Commands Used: **chg-dcmps**

If you enter the **chg-dcmps** command specifying the **parm** parameter, you must also specify the **pvalue** parameter.

Recovery

Re-enter the **chg-dcmps** command specifying both the **parm** and the **pvalue** parameters.

E3743 Cmd Rej: SSN required if SI is 3

Commands Used: **chg-appl-rtkey**, **dlt-appl-rtkey**, **dlt-rmt-appl**, **ent-appl-rtkey**, **ent-rmt-appl**

You entered a value of **si=3** (or the string equivalent **si=sccp**) for this command, but you did not specify a value for the **ssn** parameter. If you enter **si=3**, you must also enter a value for the **ssn** parameter.

Recovery

Re-enter the command specifying **si=3** and a value for the **ssn** parameter .

E3745 Cmd Rej: Invalid Domain name

Commands Used: chg-ip-card

You entered a domain name that does not conform to the naming convention for this parameter. The naming conventions for the **domain** parameter specify that it must be comprised of (**a-z, A-Z, 0-9, -, .**), and up to 120 characters in length.

Recovery

Re-enter the **chg-ip-card** command specifying a value for the **domain** name that conforms to the specified naming conventions.

Call your Customer Care Center if this error message appears again.

E3746 Cmd Rej: No other optional parms can be entered with SRCSET

Commands Used: chg-dcmps

You entered this command specifying the **srcset** parameter and at least one other optional parameter. If the **srcset** parameter is specified, no additional optional parameters can be specified.

Recovery

Re-enter the **chg-dcmps** command specifying **srcset** as the only optional parameter.

E3747 Cmd Rej: Too many IP connections per card

Commands Used: chg-appl-sock, ent-appl-sock

The maximum number of IP connections allowed per card was exceeded with the entry of the **ent-appl-sock** command. IP connections are composed of sockets and associations. The allowed maximum is **50** IP connections per card for the SS7IPGW or IPGWI application. The allowed maximum is **one** IP connection per card for the IPLIMx applications. IPLIMx refers to a DCM card or SSEDCCM card running the **iplim** application or the **iplimi** application to support **two** point-to-point links.

Recovery

Call your Customer Care Center.

E3748 Cmd Rej: Socket Table full

Commands Used: `ent-appl-sock`

The maximum number of sockets allowed per system was exceeded with the entry of this command. The allowed maximum is **250** sockets per system.

Recovery

Call your Customer Care Center.

E3749 Cmd Rej: If IPADDR is specified SUBMASK is required

Commands Used: `chg-ip-lnk`

When entering the `chg-ip-lnk` command, you specified a value for the `ipaddr` parameter but did not specify a value for the `submask` parameter. If the `ipaddr` parameter is specified, the `submask` parameter is required.

Recovery

Re-enter the `chg-ip-lnk` command specifying a valid value for the `submask` parameter.

Call your Customer Care Center if this error message appears again.

E3751 Cmd Rej: Max sockets per routing key exceeded

Commands Used: `ent-appl-rtkey`

The routing key you entered is already associated with the maximum number of socket names allowed (**16**). To add the new routing key, first delete a current routing key association, then add the new one.

Recovery

1. Display the routing key assignments for the entered destination point code.
Enter the `rtrv-appl-rtkey:dpc=<destination point code>` command.

2. Delete an existing association. Enter the **dlt-appl-rtkey** command specifying the **dpc**, **si**, **ssn**, and **sname** parameters for the association you want to delete.
 3. Re-enter the **ent-appl-rtkey** command.
Call your Customer Care Center if this error message appears again.
-

E3752 Cmd Rej: Max IP connections exceeded

Commands Used: **ent-appl-sock**

Your attempt to enter an IP connection that exceeds the maximum allowed per system.

Recovery

Call your Customer Care Center.

E3753 Cmd Rej: Command is not supported for IPLIM and SS7IPGW links

Commands Used: **blk-slk**, **tst-slk**, **ublk-slk**

The command you entered is not valid on TCP/IP links (DCM cards equipped with SS7IPGW or certain IPLIM links).

NOTE: The command is allowable, however, for IPLIM M2PA link types. IPLIM/IPLIMI does support Ports A, B, A1, B1, A2, B2, A3 or B3 for M2PA/SCTP associations on SSED CM cards.

Recovery

1. Verify that the card at the specified location is a DCM card running the SS7IPGW or IPLIM application. Enter the **rtrv-card** command. This information is shown in the TYPE and APPL fields of the output.
2. If the card type is other than DCM and the application type is other than SS7IPGW or IPLIM, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3754 Cmd Rej: Command is not supported for SS7IPGW links

Commands Used: **inh-slk**, **unhb-slk**

The command you entered is not valid on TCP/IP point-to-multipoint links (DCM cards equipped with SS7IPGW links).

Recovery

1. Verify that the card at the specified location is a DCM card running the SS7IPGW application. Enter the **rtrv-card** command. This information is shown in the TYPE and APPL fields of the output.
2. If the card type is other than DCM and the application type is other than SS7IPGW, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3756 Cmd Rej: OPEN must be NO to change or delete socket

Commands Used: **chg-appl-sock**, **dlt-appl-sock**

For the **chg-appl-sock** command, the **open** parameter must be set to no for this command, before entering the **server**, **lhost**, **lport**, **rhost**, and **rport** parameters.

For the **dlt-appl-sock** command, the **sname** parameter must be in an **open=no** state before socket table entries can be deleted.

The following Recovery procedures are command-specific for this error message.

Recovery chg-appl-sock

Re-enter the **chg-appl-sock** command specifying **open=no**.

Recovery dlt-appl-sock

1. Change the status of the **sname** parameter to **open=no**. Enter the **chg-appl-sock:open=no** command.
 2. Re-enter the **dlt-appl-sock** command.
-

E3757 Cmd Rej: SSN is not allowed unless SI is 3

Commands Used: **chg-appl-rtkey**, **dlt-appl-rtkey**, **dlt-rmt-appl**, **ent-appl-rtkey**, **ent-rmt-appl**, **rtrv-appl-rtkey**

You specified the **ssn** parameter, but the **si** parameter value is not 3. If the **ssn** parameter is specified, the **si** parameter value must be 3 **si=3** (or the string equivalent **si=sccp**).

Recovery

1. Determine the service indicator value as shown in the SI column of the output. Enter the **rtrv-*appl-rtkey*** or **rtrv-*rmt-appl*** command.
 2. Re-enter the command specifying the **ssn** parameter and **si=3**.
Call your Customer Care Center if this error message appears again.
-

E3758 Cmd Rej: If Domain name is specified, RSTDMAIN is not valid**Commands Used: *chg-ip-card***

You cannot specify the **rstdomain** parameter if the **domain** parameter is specified.

Recovery

Re-enter the **chg-*ip-card*** command specifying the **domain** parameter but not the **rstdomain** parameter.

E3760 Cmd Rej: IP address must be unique**Commands Used: *chg-ip-lnk*, *ent-ip-host***

You tried to enter an IP address (**ipaddr**) that is already in the IP Link table. The IP address to be added must be unique.

OR

You tried to enter a host name and IP address into the IP Host table, and the IP address is already in the IP Host table. The IP address to be added must be unique.

Recovery - *chg-ip-lnk*

1. Display the host names and IP addresses currently in the IP Link table. Enter the **rtrv-*ip-lnk*** command specifying no parameters. This information is shown in the IPADDR field of the output.
 2. Re-enter the **chg-*ip-lnk*** command specifying an IP address that is not displayed in the IPADDR field in the output from step 1.
-

Recovery - ent-ip-host

1. Display the host names and IP addresses currently in the IP Host table. Enter the **rtrv-ip-host** command specifying no parameters.
 2. Re-enter the **ent-ip-host** command specifying the host name and an IP address that does not match any of the entries currently in the IP Host table.
-

E3761 Cmd Rej: At least one of TIMER, PARM, SRCSET must be entered**Commands Used: chg-dcmps**

The **chg-dcmps** command requires at least one of the following optional parameters to be specified: **parm**, **srcset** or **timer**.

Recovery

Re-enter the **chg-dcmps** command specifying at least one of the required optional parameters: **parm**, **srcset** or **timer**.

E3762 Cmd Rej: Host table must contain IP Link addresses**Commands Used: chg-ip-lnk, dlt-ip-host**

You tried to enter an IP address (**ipaddr**) into the IP Link table, but the address is not in the IP Host table. An IP address must be in the IP Host table before it can be added to the IP Link table.

OR

You tried to delete an IP host name (**host**) from the IP Host table, and the host name has an IP address in the IP Link table. You must first delete the IP address from the IP Link table before you can delete the IP host name.

Recovery - chg-ip-lnk

1. Display the IP Host table. Enter the **rtrv-ip-host** command specifying no parameters. Verify that the address you entered is not in the table. This information is shown in the IPADDR field of the output.
2. If the IP address you entered is in the IP Host table, re-enter the **chg-ip-lnk** command.
3. If the IP address you entered is not in the IP Host table, enter the IP address. Enter the **ent-ip-host** command.
4. Re-enter the **chg-ip-lnk** command that generated this error message.

Call your Customer Care Center if this error message appears again.

Recovery - `dlt-ip-host`

1. Display the host names and IP addresses currently in the IP Host table. Enter the `rtrv-ip-host` command specifying no parameters.
 2. Display the IP addresses currently in the IP Link table. Enter the `rtrv-ip-lnk` command specifying no parameters. Verify that the IP address for the host to be deleted is still in the IP Link table.
 3. Delete the IP address from the IP Link table. Enter the `chg-ip-lnk` command specifying the parameter `ipaddr=0.0.0.0` and the `loc` and `port` parameters that correspond to the host's IP address.
 4. Delete the host name from the IP Host table. Re-enter the `dlt-ip-host` command.
-

E3763 Cmd Rej: Routing Key table full

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`

The Routing Key table is full (1000 entries per system). You must delete an existing routing key before adding another one to the table.

Recovery

1. Enter the `rtrv-appl-rtkey` command to display the entries in the Routing Key table.
 2. Enter the `dlt-appl-rtkey` command specifying the `dpc`, `si`, `ssn`, and `sname` parameters for the entry you want to delete.
 3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3764 Cmd Rej: Routing key not found

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`

The specified entry was not found in the Routing Key table.

Recovery

1. Enter the **rtrv-appl-rtkey** command to determine if the routing key you specified is in the Routing Key table.
2. If the routing key you specified is shown in the output from step 1, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3765 Cmd Rej: Fully specified connection required to change OPEN

Commands Used: **chg-appl-sock**, **chg-assoc**

You tried to change the setting of the **open** parameter, to **yes** but you did not specify values for all parameters required to fully specify the connection:

- For **chg-appl-sock**: **server**, **lhost**, **rhost**, **lport**, and **rport**
- For **chg-assoc**: **lhost**, **rhost**, **lport**, and **rport**

Recovery

1. Enter the command specifying the connection fully specified and without the **open** parameter.
2. Re-enter the command specifying the connection fully and with the **open=yes** parameter.

Call your Customer Care Center if this error message appears again.

E3767 Cmd Rej: Socket Name not defined

Commands Used: **rept-stat-applsock**

You entered a socket name (**sname**) that is not in the database.

Recovery

1. View the list of defined sockets. Enter the **rtrv-appl-sock** command specifying no parameters.
2. If the socket name you entered appears in the SNAME field of the output, re-enter the **rept-stat-applsock** command.

Call your Customer Care Center if this error message appears again.

3. If the socket does not appear in the output of step 1, you can define the socket. Enter the **ent-appl-sock** command specifying the **sname** parameter.
-

E3768 Cmd Rej: Link B not supported for device

Commands Used: **ent-slk**, **rept-stat-slk**

The command you entered requires that you specify **port/link=a** for cards running the **ss7ipgw** or **ipgwi** applications.

Recovery

Re-enter the command that generated this error message specifying the **port/link=a** parameter.

E3769 Cmd Rej: Too many sockets per SLK

Commands Used: **chg-appl-sock**, **ent-appl-sock**

The maximum number of sockets allowed per signaling link was exceeded with the entry of this command. The allowed maximum is one socket per signaling link for the IPLIMx applications. **IPLIMx** refers to a dual-slot DCM card or SSEDCM card running the **iplim** application or the **iplimi** application to support two point-to-point links.

Recovery

Call your Customer Care Center.

E3770 Cmd Rej: SS7 parameters cannot be specified for IP7 link

Commands Used: **ent-slk**

The specified SS7 parameters are not allowed when entering an IP⁷ link (card application **iplim**, **iplimi**, **ipgwi**, or **ss7ipgw**).

If an IP7 link is assigned to a card, the following SS7 parameters cannot be specified: **atmtsel**, **e1atmcrc4**, **e1atmsi**, **e1atmsn**, **ecm**, **lpset**, **l1mode**, **l2tset**, **ll**, **pcrn1**, **pcrn2**, **tset**, **vci** and **vpi**.

Recovery

Re-enter the **ent-slk** command specifying valid IP7 link parameters.

Call your Customer Care Center if this error message appears again.

E3772 Cmd Rej: Only one SS7IPGW or IPGWI link allowed in mated linkset**Commands Used: ent-slk**

The mated IPGWx linkset specified already has an assigned signaling link. A mated linkset can have only one signaling link. If the specified linkset has a mate linkset, only 1 SS7IPGW or IPGWI signaling link can be assigned to the specified linkset. The assigned link must be an SS7IPGW or IPGWI link.

Recovery

1. Verify that the card in the specified location is running an IPGWx application. Enter the **rtrv-card** command.
2. Verify that the correct linkset was specified. If the correct linkset was specified, perform either of the following:
 - Delete the pre-existing signaling link from the linkset. Enter the **dlt-slk** command.
 - Add the new signaling link. Enter the **ent-slk** commandOR
 - Delete the **matelsn** from the linkset. Enter the **chg-ls:action=delete** command.
 - Add the new signaling link to the linkset. Enter the **chg-ls:action=add** command.

Call your Customer Care Center if this error message appears again.

E3774 Cmd Rej: Failed reading the UIM Threshold Table**Commands Used: set-uim-acthresh**

The UIM Threshold Table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the **set-uim-acthresh** command.

Call your Customer Care Center if this error message appears again.

E3775 Cmd Rej: SERIAL param valid only with APPL param

Commands Used: **init-card**

The **serial** parameter can be used only with the **appl** parameter.

Recovery

Re-enter the **init-card** command specifying both the **appl** and **serial** parameters.

E3776 Cmd Rej: Invalid APPL selection for SERIAL init card command

Commands Used: **init-card**

You specified an invalid value for the **appl** parameter. Valid values for the **appl** parameter are: **all**, **atmansi**, **ccs7itu**, **emdc**, **gls**, **sccp**, **ss7ansi**, **ss7gx25**, and **stplan**.

Recovery

Re-enter the **init-card** command specifying one of the following values: **all**, **atmansi**, **ccs7itu**, **emdc**, **gls**, **sccp**, **ss7ansi**, **ss7gx25**, or **stplan**, for the **appl** parameter.

E3777 Cmd Rej: APPL=ALL can only be selected when SERIAL=YES is specified

Commands Used: **init-card**

If you enter the **init-card:appl=all** command, you must specify the **serial=yes** parameter.

Recovery

Re-enter the **init-card:appl=all:serial=yes** command.

E3778 Cmd Rej: Active/Stby GPL versions are not compatible

Commands Used: `copy-disk`, `format-disk`

The OAM GPL version that is running on the active OAM card location is not the same OAM GPL version that is running on the standby OAM card. If the two version numbers are not identical, the command aborts. Note that it is the running GPL versions that must be identical, not the approved or trial GPLs (as shown in the output of the `rept-stat-gpl` command).

You may have encountered this error during an upgrade, when one OAM may be booted from a removable cartridge and the other from the fixed disk. This action could cause different GPLs to be running in the active and standby OAM cards.

Recovery

Use the following commands, or command combinations, to boot both OAM cards with the same GPL version from the removable cartridge:

- Determine the GPL versions. Enter the `rtrv-gpl` command.
- If the GPL version on the standby OAM card is different from the GPL version on the active OAM card, insert a removable cartridge with the correct GPL version.
- Boot the standby OAM card. Enter the `init-card:loc=<xxxx>` command, where `xxxx` is the location of the standby OAM card.

Call your Customer Care Center if this error message appears again.

E3779 Cmd Rej: FORCE=YES must be specified

Commands Used: `chg-db`, `inh-card`

Table 2-30 lists by command the conditions that generate this error message. The table is followed by a Recovery procedure to resolve the error.

Table 2-30. Conditions that Generate an E3779 Error Message

Command	Condition
chg-db	You specified the action=canceledl parameter, but you did not specify the force=yes parameter. You must specify force=yes , whenever you specify the action=canceledl operation.
inh-card	You specified the only in-service EMDCA-DCM or EPAP/ELAP-DSM, which requires that you specify the force=yes parameter. OR If inhibiting the VSCCP card would cause less than 80% of the in-service normal (IS-NR) LIM cards to have VSCCP service (i.e., cause the system to enter an unstable loading mode), you must specify the force=yes parameter.

Recovery

Re-enter the command specifying **force=yes**.

E3780 Cmd Rej: Syntax Error Found

Commands Used: **Pass-through commands**

The command you entered does not conform to the required syntax.

Recovery

Re-enter the command as the rules require.

Refer to the *Commands Manual* for the syntax rules for the command.

Call your Customer Care Center if this error message appears again.

E3781 Cmd Rej: MTP restart option not valid for IPGWAPC linksets

Commands Used: **chg-ls, ent-ls**

You specified the **mtpmse=yes** parameter to enter or change an IPGWAPC linkset. The MTP Restart option (the MTPRS feature for ANSI, or the ITUMTPRS feature for ITU) is not valid for IPGWx Adjacent Point Code linksets.

Recovery - ent-1s

Re-enter the **ent-1s** command specifying **ipgwapc=yes** parameter, and either

- do not specify the **mtprse** parameter
 - OR
 - specify the **mtprse=no** parameter
-

Recovery - chg-1s

1. Display attributes of the linkset you want to change. Enter the **rtrv-1s** command. (You must specify the linkset name **lsn** parameter). Verify that **mtprse=no** in the output.
 2. Re-enter the **chg-1s** command and either
 - do not specify the **mtprse** parameter
 - OR
 - specify the **mtprse=no** parameter
-

E3782 Cmd Rej: Command Not Found

Commands Used: Pass-through commands

The pass-through command you entered was not found.

Recovery

Re-enter the command specifying the correct information.

Refer to the *Commands Manual* for information about the command.

Call your Customer Care Center if this error message appears again.

E3783 Cmd Rej: CICS must be less than or equal to CICE

**Commands Used: chg-appl-rtkey, dlt-appl-rtkey,
ent-appl-rtkey, rtrv-appl-rtkey**

You specified a value for the starting circuit identification code (**cics**) that was greater than the value specified for the ending circuit identification code (**cice**). The value entered for the starting circuit identification code must be less than or equal to the value entered for the ending circuit identification code.

Recovery

Re-enter the command specifying a value for the **cics** parameter that is less than or equal to the value for the **cice** parameter.

E3785 Cmd Rej: IPISUP Feature must be on

Commands Used: **ent-appl-rtkey**

You entered this command for a DPC/SI/CIC routing key to route ISUP messages, but the ISUP routing over IP feature is turned off.

Recovery

1. Turn on the ISUP routing over IP feature. Enter the **chg-feat:ipisup=on** command.
 2. Re-enter the **ent-appl-rtkey** command.
Call your Customer Care Center if this error message appears again.
-

E3786 Cmd Rej: CIC Range overlaps an existing routing key

Commands Used: **dlt-appl-rtkey**, **ent-appl-rtkey**

You entered a circuit identification code range (**cics** to **cice**) that overlaps an existing routing key.

Recovery

1. View the conflicting circuit identification code range for the existing routing key. Enter the **rtrv-appl-rtkey** command specifying the CIC range. This information is shown in the CICS and CICE fields of the output.
 2. Re-enter the command specifying a circuit identification code range (**cics** to **cice**) that does not overlap the range of an existing routing key.
Call your Customer Care Center if this error message appears again.
-

E3787 Cmd Rej: SSN not allowed with OPC, CICS, and CICE

Commands Used: `rtrv-appl-rtkey`

You specified the `ssn` parameter along with the `opc`, `cics`, and `cice` parameters. The `opc`, `cics`, and `cice` parameters are used to route ISUP messages and require that `si=5` (or the string equivalent `si=isup`). The `ssn` parameter is not allowed unless `si=3` (or the string equivalent `si=sccp`).

Recovery

Re-enter the `rtrv-appl-rtkey` command without specifying a value for the `ssn` parameter.

E3788 Cmd Rej: OPC, CICS, CICE are required if SI is 4, 5, or 13

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`, `ent-appl-rtkey`

You entered the command without specifying the `opc`, `cics`, and `cice` parameters specified. The `opc`, `cics`, and `cice` parameters are used to route ISUP messages and must be specified if `si=4`, `5`, or `13` (or the string equivalent `si=tup`, `isup` or `qbicc`) is specified and the routing key `type=full` is specified or defaulted.

Recovery

Re-enter the command specifying values for the `opc`, `cics`, and `cice` parameters for `si=4`, `5`, or `13` and routing key `type=full`.

E3789 Cmd Rej: OPC, CICS, CICE are not allowed with SI unless SI is 4, 5, or 13

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`,
`ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified the `opc`, `cics`, and `cice` parameters specified, but the `si` parameter value is not `4`, `5`, or `13`. The `opc`, `cics`, and `cice` parameters are used to route ISUP messages and can be specified only if `si=4`, `5`, or `13` (or the string equivalent `si=tup`, `isup` or `qbicc`) is specified.

Recovery

1. Enter the `rtrv-appl-rtkey` command to determine the service indicator value, as shown in the **SI** column of the output.

2. If **si** is 4, 5, or 13 (or TUP, ISUP, or QBICC) from the output of step 1, re-enter the command.
 3. Call your Customer Care Center if this error message appears again.
-

E3791 Cmd Rej: Gtwy IP Address is invalid

Commands Used: `ent-ip-rte`, `rtrv-ip-rte`

You specified an invalid gateway IP address in the **gtwy** parameter of the command. The gateway IP address:

- Must be four numbers separated by dots, with each number in the range of **0-255**
- Must not be the default route (**0.0.0.0**)
- Must not correspond to any loopback address (i.e. **127.X.X.X**)
- Must be unique per card
- Must not correspond to an IP address that is local to this card's A or B network

Recovery

Re-enter the command specifying a valid gateway IP address.

E3792 Cmd Rej: Gtwy IP Address must be local to this cards A, B network

Commands Used: `ent-ip-rte`

For the card in the location specified in the **loc** parameter, you specified a gateway IP address in the **gtwy** parameter of the command that is not local to the A or B network of the card. The gateway IP address must correspond to an IP address that is local to this card's A or B network.

Recovery

Re-enter the `ent-ip-rte` command specifying a gateway IP address that is local to the A or B network for the specified card.

E3793 Cmd Rej: Max IP Route entries already exist for this card**Commands Used: ent-ip-rte**

You entered a command to define a static IP route for the card in the location specified in the **loc** parameter. The maximum number of **64** static IP routes for this card already exist in the Static IP Route table.

Recovery

1. Display the existing route entries for the card. Enter the **rtrv-ip-rte** command.
 2. To add a route entry for the card, delete an existing route entry. Enter the **dlt-ip-rte** command.
 3. Re-enter the **ent-ip-rte** command to add the new route entry for the card.
-

E3794 Cmd Rej: IP Route table full**Commands Used: ent-ip-rte**

You entered a command to define a static IP route for the card in the location specified in the **loc** parameter. The maximum number of **1024** static IP routes already exist in the Static IP Route table.

Recovery

1. Display the existing route entries for the card. Enter the **rtrv-ip-rte** command.
 2. To add another route entry for the card, delete an existing route entry from the table. Enter the **dlt-ip-rte** command.
 3. Re-enter the **ent-ip-rte** command to add the new route entry for the card.
-

E3795 Cmd Rej: LNP ported NPANXXs 300K Qty Feat Requires at least DSM2GB**Commands Used: enable-ctrl1-feat**

You attempted to enable the LNP ported NPANXX 300K Quantity Keys, but not all DSMs have the required memory, at least a 2 GB DSM card. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Re-enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E3796 Cmd Rej: LNP ported LRNs 150K Qty Feat Requires at least DSM2GB

Commands Used: enable-ctrl-feat

You attempted to enable the LNP ported LRNs 150K Quantity Keys feature, but not all DSMs have the required memory, at least a 2 GB DSM card. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Re-enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E3797 Cmd Rej: LNP ported TNs 2million Qty Feat Requires at least TSM256MB

Commands Used: enable-ctrl-feat

You attempted to enable the LNP ported TNs 2 million Quantity feature, but not all DSMs have the required memory, at least a TSM card with 256 MB of memory. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware.
2. Re-enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E3798 Cmd Rej: Measurement Preparation in progress, Retry later

Commands Used: `chg-db`

Since there is measurement preparation in progress, the upload to the OAM (**finished1**) cannot be started.

Recovery

Wait for the measurement preparation operation to finish, and then re-enter the command.

E3799 Cmd Rej: Force=YES must be specified

Commands Used: `act-lbp`, `chg-db`, `chg-stpopts`, `chg-t1`, `ent-t1`, `inh-card`, `tst-slk`

You entered the command without specifying the **force=yes** parameter, as required.

You cannot specify `chg-stpopts:hsclksrc=xxx` when the high speed clocks are reporting valid status unless you include the **force=yes** parameter.

For the `act-lbp` or `tst-slk` commands, you must specify the **force=yes** parameter to activate more than 256 link tests.

Recovery

Re-enter the command specifying **force=yes**.

E3800 Cmd Rej: BLM/DCM card must be provisioned and IS-NR for bulk download

Commands Used: `chg-db`

You specified the `chg-db:action=begined1` command, but the BLM and DCM cards do not meet the requirements for a bulk download. The BLM and DCM cards must be provisioned, and their primary state (PST) must be in-service normal (IS-NR).

Recovery

1. Refer to your *LNP Database Synchronization Manual* for instructions on provisioning cards.

2. Display the status of the BLM and DCM cards. Enter the **rept-stat-card** command.
 - If the primary state of one of the BLM or DCM cards displayed in step 2 is in service, the entry IS-NR appears in the *PST* field of the output. Re-enter the **chg-db** command that generated this error message.
 - If the primary state of one of the BLM or DCM cards displayed in step 2 is out-of-service maintenance disabled (OOS-MT-DSBLD), change the primary state of the card to IS-NR. Enter the **alw-card** command. Re-enter the **chg-db** command that generated this error message.
 - If the primary state of one of the cards displayed in step 2 is out of service - maintenance (OOS-MT) or in service - abnormal (IS-ANR), refer to Appendix A of the *Maintenance Manual* to take the appropriate action to place the card in service.
 3. Re-enter the **chg-db** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3801 Cmd Rej: BLM/DCM LNP database must be coherent to do a bulk download

Commands Used: chg-db

You specified the **chg-db:action=begined1** command. This execute command, the LNP database on the BLM or DCM card must be both coherent, and at the same level as the current LNP database on the active OAM card.

Recovery

1. Determine the status of the database. Enter the **rept-stat-db:display=all** command.
 2. If the BLM or DCM database is not coherent, enter the following command:
init-card:loc=xxxx
where xxxx is the location of the BLM or DCM card.
 3. Re-enter the **chg-db:action=begined1** command.
Call your Customer Care Center if this error message appears again.
-

E3802 Cmd Rej: BLM must be provisioned and IS-NR for an upload

Commands Used: chg-db

You specified the **chg-db:action=finished1** command. This action requires that the BLM card be provisioned and its primary state (PST) must be IS-NR.

Recovery

1. Refer to the *LNP Database Synchronization Manual* for instructions on provisioning cards.
 2. To display the status of the cards, enter the **rept-stat-card** command. If the card is in service, the entry IS-NR appears in the *PST* field of the output.
 3. Re-enter the **chg-db** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3803 Cmd Rej: Bulk download from LSMS to the BLM card must have completed

Commands Used: **chg-db**

You specified the **chg-db:action=finished1** command before the download from the LSMS to the BLM card completed.

Recovery

1. Wait until the following message appears:

```
5061.1497      SYSTEM      INFO      LSMS Bulk Download complete
```

2. Re-enter the **chg-db:action=finished1** command.
-

E3804 Cmd Rej: Database in the BLM card must be coherent for an upload

Commands Used: **chg-db**

You specified the **chg-db:action=finished1** command. However, the LNP database currently resident in the BLM card is not coherent.

Recovery

1. Determine the status of the database. Enter the **rept-stat-db:display=all** command.
 2. If the BLM database is not coherent, enter the following command:
init-card:loc=xxxx
where *xxxx* is the location of the BLM card.
 3. From the LSMS, restart the bulk download, and then re-enter the **chg-db** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3805 Cmd Rej: Enhanced Bulk Download not in progress**Commands Used: chg-db**

You specified either the **chg-db:action=finished1** or the **chg-db:action=canceled1** command. Before either of these commands can execute, you must first issue the **chg-db:action=begined1** command.

Recovery

1. Enter the **chg-db:action=begined1** command.
2. Wait until the following message appears:

```
5061.1497      SYSTEM          INFO      LSMS Bulk Download complete
```

E3806 Cmd Rej: Enhanced Bulk Download already in progress**Commands Used: chg-db**

You specified the **chg-db:action=begined1** command, while a previously issued **chg-db:action=begined1** command is in effect.

Recovery

Perform one of the following actions:

- Wait for the download to complete. At completion, the following message appears:

```
1497 LSMS Bulk Download complete
```

OR

- Wait for LSMS to cancel the download, in which case the following message appears:

```
5061.1498      SYSTEM          INFO      LSMS Bulk Download cancelled at LSMS
```

OR

- Cancel the download. Enter the **chg-db:action=canceled1** command.
-

E3807 Cmd Rej: Failed reading Secondary Point Code (SPC) table**Commands Used: chg-sid, dlt-spc, ent-spc, rtrv-spc**

The Secondary Point Code table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3808 Cmd Rej: SPC and NSPC may not be equal

Commands Used: `chg-sid`

When you specify the `spc` and `nspc` parameters, their values must be different.

Recovery

Re-enter the `chg-sid` command and make sure that the values for the `spc` and `nspc` parameters are different.

E3809 Cmd Rej: SPC may not exist in the STP's route table

Commands Used: `ent-spc`

You specified a secondary point code that exists as a destination or an alias in the STP database's Destination table. The system does not allow this action.

Recovery

1. Display the DPCs in the Destination table. Enter the `rtrv-dstn` command.
 2. Re-enter the `ent-spc` command that generated the error message specifying an SPC that does not exist as a destination or an alias in the Destination table, as shown in the output from step 1.
-

E3810 Cmd Rej: SPC may not exist as a TPC or CPC in the SID table

Commands Used: `chg-sid`, `ent-spc`

You specified a value for the `spc` parameter that matches one of the following entries in the SID table:

- An existing or new true point code
- An existing or new capability point code

The system does not allow this action.

Recovery

1. Display the point codes currently configured in the system database. Enter the **rtrv-spc** command.
 2. Enter the **rtrv-sid** command to display the point codes currently in the SID table. The EAGLE 5 ISS's true point code is shown in the PCA field. Capability point codes are shown in the CPCA, CPCI, CPCN, and CPCN24 fields.
 3. Re-enter the command that generated the error message, but use an SPC that is not referenced in the SID table, as shown in the output from step 1.
-

E3811 Cmd Rej: SPC may not exist as a TPC, CPC, or DPC in the route table**Commands Used: chg-sid**

You specified a true point code (TPC) that matches an existing/new secondary point code (SPC). The system does not allow this action.

Recovery

1. Display the system's true point code with the **rtrv-sid** command. The system's true point code is shown in the PCA field.
 2. Re-enter the **chg-sid** command that generated this error message specifying a value for the **pc/pca** parameter that does not exist as an SPC, as shown in the output from step 1.
-

E3812 Cmd Rej: The SPC already exists**Commands Used: ent-spc**

The specified Secondary Point Code (SPC) entry already exists in the Secondary Point Code table.

Recovery

1. Display the SPCs currently configured in the Secondary Point Code table. Enter the **rtrv-spc** command.
 2. Re-enter the **ent-spc** command that generated the error message specifying a value for the **spc** parameter that does not exist in the Secondary Point Code table.
-

E3814 Cmd Rej: SPC does not exist

Commands Used: `ent-dstn`, `chg-dstn`

You specified the `spc` parameter, but the `spc` is not defined as a Secondary Point Code (SPC) in the database. The exception to this rule is if you specify `spc=none`.

Recovery

1. Display the SPCs currently configured. Enter the `rtrv-spc` command.
 2. Re-enter the command that generated the error message specifying an SPC that is defined in the database, as shown in the output from step 1.
-

E3815 Cmd Rej: The maximum number of SPCs has already been defined

Commands Used: `ent-spc`

The maximum number of Secondary Point Codes (SPCs) you can enter into the database is **40**. When you entered the command, you specified a SPC that would have been the 41st entry in the database. You must first delete an existing SPC entry from the database before you can add a new one.

Recovery

1. Display the SPCs currently configured in the system database. Enter the `rtrv-spc` command.
 2. Delete one of the existing SPCs. Enter the `dlt-spc=xxx-xxx-xxx` command, where `xxx-xxx-xxx` is a point code you select from the output of step 1.
 3. Re-enter the `ent-spc` command.
-

E3819 Cmd Rej: SPC may not be referenced in the STP's route table

Commands Used: `dlt-spc`

You specified a secondary point code (`spc`) parameter value that is referenced in the Destination Point Code table. The system does not allow this action.

Recovery

1. Display the DPCs in the database. Enter the **rtrv-dstn** command.
 2. Re-enter the **dlt-spc** command specifying a **spc** that is not referenced in the destination point code table, as shown in the output from step 1.
-

E3820 Cmd Rej: Site SPC must be a full point code**Commands Used: ent-spc**

Specify the **spc** parameter as a full point code. A full point code contains numerical values for all three segments of the point code. The exception to this rule is when you specify a value of **none**.

Recovery

Re-enter the **ent-spc** command specifying a full point code.

Call your Customer Care Center if this error message appears again.

E3821 Cmd Rej: SPC & DPC must be the same network type**Commands Used: chg-dstn, ent-dstn**

You specified the **spc** parameter, but its network type (ANSI, ITU-N, or ITU-I) does not match the network type for the destination point code (DPC). For instance, if you specify the **spci** parameter, you must specify the **dpci** parameter so that both network types are ITU-I. Likewise, **dpca** must be specified with **spca** (ANSI), **dpcn** with **spcn** (ITU-N), and **dpcn24** with **spcn24** (24-bit ITU-N).

Recovery

Re-enter the command specifying **spc** and **dpc** parameters that are the same network type.

E3822 Cmd Rej: SPC must be a full point code**Commands Used: chg-dstn, ent-dstn, rtrv-dstn**

You specified the **spc** parameter, but did not specify a full point code, as required. A full point code contains numerical values for all three segments of the point code. The exception to this rule is if you specify **spc=none**.

Recovery

1. Display the secondary point codes in the database. Enter the **rtrv-spc** command.
 2. Re-enter the command specifying a full point code, as shown in the output of step 1.
-

E3823 Cmd Rej: Domain must be SS7 if SPC is specified

Commands Used: **chg-dstn, ent-dstn**

If you specify the **spc** parameter, you must specify **domain=ss7**.

Recovery

Re-enter the command that generated this error message specifying **domain=ss7**.

E3825 Cmd Rej: New CIC range overlaps an existing routing key

Commands Used: **chg-appl-rtkey**

You entered a new circuit identification code range (**ncics-to-ncice**) that overlaps an existing routing key.

Recovery

1. Enter the **rtrv-appl-rtkey** command specifying the new CIC range to see the conflicting circuit identification code range for the existing routing key. This information is shown in the CICS and CICE fields of the output.
 2. Re-enter the **chg-appl-rtkey** command specifying a new circuit identification code range (**ncics-to-ncice**) that does not overlap the range of an existing routing key.

Call your Customer Care Center if this error message appears again.
-

E3826 Cmd Rej: NCICS must be less than or equal to NCICE

Commands Used: **chg-appl-rtkey**

You specified a value for the new starting circuit identification code (**ncics**) that is greater than the value specified for the new ending circuit identification code (**ncice**). The value entered for the starting circuit identification code must be less than or equal to the value entered for the ending circuit identification code.

Recovery

Re-enter the **chg-appl-rtkey** command specifying a value for the **ncics** parameter that is less than or equal to the value for the **ncice** parameter.

E3827 Cmd Rej: No change requested

Commands Used: **chg-appl-rtkey**, **chg-ctrl-feat**,
enable-ctrl-feat, **ent-pstn-pres**

The parameters specified for this command are identical to the parameters of an existing routing key or controlled On/Off feature.

Recovery

1. Enter one of the following commands to verify that a routing key or controlled feature already exists with the parameters that you entered:
 - the **rtrv-appl-rtkey** command
 - the **rtrv-ctrl-feat** command
 2. If there is no routing key or controlled feature in the output identical to the parameters you entered, re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If there is a routing key or controlled feature in the output identical to the parameters you entered, re-enter the command specifying different parameters.
Call your Customer Care Center if this error message appears again.
-

E3828 Cmd Rej: Card GPL type SS7IPGW requires IPGWAPC=YES

Commands Used: **ent-slk**

When specifying an IP link (**type=ss7ipgw**) with the **ent-slk** command, the **lsn** parameter must reference a linkset that specifies an IP gateway adjacent point code (**ent-ls:ipgwapc=yes**).

Recovery

1. Determine if the **type=ss7ipgw** and **ipgwapc=yes**. Enter the **rtrv-ls** command specifying the linkset name (**lsn**).
2. If the criteria identified in step 1 is met, re-enter the **ent-slk** command.

Call your Customer Care Center if this error message appears again.

3. If **type=ss7ipgw** but **ipgwapc=no**, enter the **ent-1s** command specifying **ipgwapc=yes**.
 4. Re-enter the **ent-s1k** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3829 Cmd Rej: Link set with IPGWAPC=YES requires SS7IPGW/IPGWI GPL

Commands Used: ent-s1k

When entering an IP link with the **lsn** parameter referencing a linkset that specifies an IP gateway adjacent point code (**ent-1s:ipgwapc=yes**), the card GPL type must be **type=ss7ipgw** or **type=ipgwi**.

Recovery

1. Determine if the **type=ss7ipgw** or **type=ipgwi** and **ipgwapc=yes**. Enter the **rtrv-1s** command specifying the linkset name (**lsn**).
 2. If the criteria identified in step 1 are met, re-enter the **ent-s1k** command.
Call your Customer Care Center if this error message appears again.
-

E3830 Cmd Rej: DPC must not specify a cluster route for IPGWAPC link set

Commands Used: chg-rte, ent-rte

You specified a cluster route for a destination point code (**dpc**) for a link set that has **ipgwapc=yes** specified. A destination point code cannot specify a cluster route for a link set that has an IP gateway adjacent point code (**ipgwapc**) specified.

Recovery

1. Verify that the link set name (**lsn**) references a destination point code that is a cluster route. Enter the **rtrv-rte** command for the link set. Cluster routes use a wild card (*) as part of the address.
 2. If the referenced destination point code is not a cluster route, re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3831 Cmd Rej: Invalid parameter combination for SI

Commands Used: chg-appl-rtkey

The combination of parameters you entered is not valid for the specified service indicator (**si**) value.

Use only one of the following parameter combinations to specify new values for the routing key:

- Specify **ncics**, **ncice**, or **ncics** and **ncice** to re-size the CIC range for the routing key
- Specify **nsname** to override the socket associations for the routing key
- Specify **split** to split the routing key into 2 entries with adjacent CIC ranges

Refer to Table 2-31 for valid parameter combinations for specific actions and service indicator values.

Table 2-31. Valid Parameter Combinations for Routing Key Types using the **chg-appl-rtkey** Command

Action	DPC*	SI*	SSN	OPC	CICS	CICE	NCICS	NCICE	SPLIT	NS NAME
Split CIC Range	X	X		X	X	X			X	
Re-size CIC Range	X	X		X	X	X	X	X		
Socket Name Override (SI=ISUP)	X	X		X	X	X				X
Socket Name Override (SI = SCCP)	X	X	X							X
Socket Name Override (SI = not SCCP or ISUP)	X	X								X
* Indicates mandatory parameter										

Recovery

Re-enter the **chg-appl-rtkey** command specifying valid parameters for the specified service indicator value.

Call your Customer Care Center if this error message appears again.

E3832 Cmd Rej: SPLIT must be greater than CICS

Commands Used: **chg-appl-rtkey**

The value specified for the circuit identification code split range (**split**) must be greater than the value entered for the starting circuit identification code (**cics**).

Recovery

Re-enter the command specifying a value for **split** that is greater than the value specified for **cics**.

Call your Customer Care Center if this error message appears again.

E3833 Cmd Rej: SPLIT must be less than or equal to CICE

Commands Used: **chg-appl-rtkey**

The value entered for the circuit identification code split range (**split**) must be less than or equal to the value entered for the ending circuit identification code (**cice**).

Recovery

Re-enter the command specifying a value for **split** that is less than or equal to the value specified for **cice**.

Call your Customer Care Center if this error message appears again.

E3834 Cmd Rej: NCICE unspecified, NCICS must be less than or equal to CICE

Commands Used: **chg-appl-rtkey**

The value entered for the new starting circuit identification code (**ncics**) must be less than or equal to the value entered for the ending circuit identification code (**cice**) when the new ending circuit identification code (**ncice**) is not specified.

Recovery

Re-enter the command specifying a value for **ncics** that is less than or equal to the value specified for **cice**.

Call your Customer Care Center if this error message appears again.

E3835 Cmd Rej: L2STATS not valid for SS7IPGW

Commands Used: **rept-stat-slk**

The command as entered, is not valid. Level 2 status (l2stats) output is not available for TCP/IP point-to-multipoint links (DCM cards equipped as SS7IPGW links).

Recovery

1. Enter the **rtrv-card** command to verify that the card at the specified location is a DCM card running the SS7IPGW application. This information is shown in the TYPE and APPL fields of the output.
2. If the card type is other than DCM or the application type is other than SS7IPGW, re-enter the **rept-stat-slk** command.

Call your Customer Care Center if this error message appears again.

E3836 Cmd Rej: Command not valid for IPLIM

Commands Used: **blk-slk**, **ublk-slk**

The command you entered is not valid on TCP/IP point-to-point links (DCM cards equipped as IPLIM links).

Recovery

1. Enter the **rtrv-card** command to verify that the card at the specified location is a DCM card running the IPLIM application. This information is shown in the TYPE and APPL fields of the output.
2. If the card type specified is not a DCM card, or the application type specified is not IPLIM, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3837 Cmd Rej: Command not valid for SS7IPGW

Commands Used: `alw-slk`, `blk-slk`, `inh-slk`, `rept-stat-tstslk`,
`tst-slk`, `unhb-slk`

The command you entered is not valid on TCP/IP point-to-multipoint links (DCM cards equipped as SS7IPGW links).

Recovery

1. Verify that the card at the specified location is a DCM card running the SS7IPGW application. Enter the `rtrv-card` command. This information is shown in the TYPE and APPL fields of the output.
2. If the card type specified is not a DCM card, or the application type specified is not SS7IPGW, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3838 Cmd Rej: SPLIT, NCICS, NCICE are not allowed with SI unless SI is 4, 5, or 13

Commands Used: `chg-appl-rtkey`

You entered a value for a circuit identification code split range (`split`), a new starting circuit identification code (`ncics`), or a new ending circuit identification code (`ncice`), along with a value for the service indicator (`si`) that is other than 4, 5, or 13 (or `tup`, `isup`, or `qbicc`).

Recovery

Re-enter the command specifying an `si` value of 4, 5, or 13 (or `tup`, `isup`, or `qbicc`).

Call your Customer Care Center if this error message appears again.

E3839 Cmd Rej: SPLIT, RC, NCICS, NCICE or attributes required

Commands Used: `chg-appl-rtkey`

You entered the command to change a routing key but did not specify a value for the `split`, `rc`, `ncics`, or `ncice` parameter. At least one of these values must be specified to change a routing key.

Recovery

Re-enter the command specifying the value(s) for **split**, **rc**, **ncics**, or **ncice** appropriate to the change action you want to make. (Refer to Table 2-31 on page 2-619).

Call your Customer Care Center if this error message appears again.

E3840 Cmd Rej: Attributes required

Commands Used: **chg-appl-rtkey**

You entered the command to change a routing key, but you did not supply attributes required in the command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for information on the command format, parameters, and syntax.

Call your Customer Care Center if this error message appears again.

E3841 Cmd Rej: Dynamic rtkeys + SRKQ exceed max allowed rtkey limit

Commands Used: **chg-sg-opts**

The sum of the values specified for the **srkq** parameter and dynamic routing key entries on any SS7IPGW or IPGWI card cannot exceed the maximum allowed routing key limit.

Recovery

1. Enter the **rept-stat-rtkey** command and verify the sum of: the value specified for the static routing key quantity (**srkq**) and the highest number of dynamic routing keys at a location.
2. Perform one of the following actions:
 - Enter the **chg-sg-opts** command specifying a value for the **srkq** parameter such that the sum of the value you specify and the highest

number of dynamic routing keys at a location does not exceed the maximum allowed routing key limit.

NOTE: The routing key limit is 1000 if any DCM cards configured as SS7IPGW or IPGWI are installed and is 2500 if no DCM cards configured as SS7IPGW or IPGWI are installed

- Delete dynamic routing key entries at the specified location (**loc**) until the sum of the specified static routing key quantity (**SRKQ** from the output of step 1) and the highest number of dynamic routing keys at a specific location does not exceed the maximum allowed routing key limit. Enter the **dlt-appl-rtkey** command.

NOTE: The routing key limit is 1000 if any DCM cards configured as SS7IPGW or IPGWI are installed and is 2500 if no DCM cards configured as SS7IPGW or IPGWI are installed

E3842 Cmd Rej: Entries in static route key table cannot exceed SRKQ

Commands Used: chg-appl-rtkeys, chg-sg-opts, ent-appl-rtkey

You attempted to reduce the maximum number allowed for static routing keys (**srkq**) to a number less than the current number of actual static routing keys. The number of entries in the static Routing Key table cannot exceed the **SRKQ** number.

Recovery

1. Enter the **rept-stat-rtkey** command and verify the values specified for the static routing key quantity (**srkq**) and the total number of static entries in the Routing Key table.
 2. Perform one of the following actions:
 - Enter the **chg-sg-opts** command specifying a value for the **srkq** parameter that is equal to or higher than the total number of static entries in the Routing Key table.

OR

 - Delete static routing key entries until the desired value for **srkq** (from the output of step 1) is greater than the total number of static entries in the Routing Key table. Enter the **dlt-appl-rtkey** command.
-

E3843 Cmd Rej: SRKQ + DRKQ exceed max allowed rtkey limit**Commands Used: chg-sg-opts**

The sum of the values you entered for the **srkq** (static entries in the Routing Key table) and **drkq** (dynamic entries in the Routing Key table) parameters exceeds the maximum number of routing keys allowed. (The routing key limit is 1000 if any DCM cards configured as SS7IPGW or IPGWI are installed and is 2500 if no DCM cards configured as SS7IPGW or IPGWI are installed).

Recovery

Re-enter the **chg-sg-opts** command specifying values for **srkq** and **drkq** such that their sum does not exceed the maximum allowed routing key limit.

E3844 Cmd Rej: LOC not allowed with MODE=STATIC**Commands Used: rtrv-appl-rtkey**

You entered a value for the **loc** parameter, but **mode=static** is also specified. Specifying a card location (**loc**) refers to socket associations for dynamic entries in the Routing Key table (**mode=dynamic**) of the SS7IPGW/IPGWx card at the specified card location.

Recovery

Re-enter the **rtrv-appl-rtkey** command without specifying the **loc** parameter

OR

Re-enter the **rtrv-appl-rtkey** command specifying **mode=dynamic** and the **loc** parameter

Call your Customer Care Center if this error message appears again.

E3845 Cmd Rej: DYNRTK feature must be enabled to perform this operation**Commands Used: chg-sg-opts**

You attempted to change an option relating to Dynamic Routing keys, but the Dynamic Routing Key feature has not been turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the Dynamic Routing Key feature is turned on (from the output of step 1 - **dynrtk=on**), re-enter the command.
 3. Call your Customer Care Center if this error message appears again.
 4. If the Dynamic Routing Key feature is turned off (from the output of step 1 - **dynrtk=off**), turn the feature on. Enter the **chg-feat:dynrtk=on** command.
 5. Re-enter the command that generated this error message.
-

E3846 Cmd Rej: X25G Feature must be ON before X252000 can be ON

Commands Used: **chg-feat**

You cannot turn on the X252000 (2000 X.25 routes and destinations) feature because the X25G (X.25/SS7 gateway) feature is turned off. You must turn on the X25G feature (**chg-feat:x25g=on**) before you can turn on the **x252000** feature.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the X25G feature is turned on (**X25G=on**), re-enter the **chg-feat** command.
Call your Customer Care Center if this error message appears again.
 3. If the X25G feature is off (**X25G=off**), turn it on. Enter the **chg-feat:x25g=on** command.
 4. Re-enter the **chg-feat** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3847 Cmd Rej: FORCE valid only with APPL, DATA or INITCLK parameters

Commands Used: **init-card**

You specified the **force** parameter with a parameter other than the **appl**, **data**, or **initclk** parameters. This action is not allowed.

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the **force** parameter.
- OR
- Re-enter the command specifying either the **appl**, **data**, or **initclk** parameter.
-

E3848 Cmd Rej: FORCE parameter valid only with DATA parameter

Commands Used: **init-sys**

You cannot specify the **force** parameter without specifying the **data** parameter.

Recovery

Perform one of the following actions:

- Re-enter the **init-sys** command without specifying the **force** parameter.
- OR
- Re-enter the **init-sys** command specifying both the **data** and **force** parameters.
-

E3849 Cmd Rej: Card(s) cannot warm restart - FORCE parameter required

Commands Used: **init-card**, **init-sys**

You specified the **data=persist** parameter without the **force** parameter. The command was rejected because an SCCP or EBDABLM card present in the system cannot maintain a persistent LNP database over the reset. Table 2-32 on page 2-628 lists the possible reasons a card may require a full data download:

```
Verifying card(s) persistent LNP database - please wait
The following cards require a full data download:
Card      Reason
----      -
zzzz     xxxxxxxxx
```

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **force** parameter.
 - OR
 - Re-enter the command without specifying the **data=persist** parameter.
-

Table 2-32. Reason that Card Requires a Full Data Download

xxxxxxx value	Description
POWER ON	Power on reset
XILINX VERSION	M256 Xilinx version has changed
DB VERSION	LNP Database version has changed
DB LEVEL	Database level is not supported or difference exceeds incremental loading capability
DB STATUS	Database status is incoherent
HW ERR	Hardware error bit checks on the card fail
AUDIT FAILED	Checksum comparisons of the LNP database fail
AUDIT TIMEOUT	LNP initialization audit timed out
NO AUDIT	Unable to perform LNP DB audit. LNP audit not on or excessive number of unknown checksums
USER REQUEST	User initiated init-card or init-sys command reload type cold
UNKNOWN	Unknown
OTHER	Other

E3850 Cmd Rej: Parameters inconsistent on re-entering of command

Commands Used: **init-sys**

Since this command causes a complete system reload, you are required to enter the command twice. This serves as a mechanism to confirm that you really want to execute the command. When you entered the **init-sys** command the second time, the parameters did not match the parameters you entered the first time. The parameters must be the same both times.

Recovery

Re-enter the **init-sys** command specifying the same parameters both times.

E3851 Cmd Rej: MTPRSE parameter is only valid if ITUMTPRS feature is ON

Commands Used: **chg-ls**, **ent-ls**

You specified the **mtpkse** parameter, but the ITU MTP Restart (ITUMTPRS) feature is off.

Recovery

1. Verify that the ITUMTPRS feature is turned on. Enter the **rtrv-feat** command. If the MTPRS feature is off, you must turn it on.
 2. Turn on the MTPRS feature. Enter the **chg-feat:itumtprs=on** command.
 3. Perform one of the following actions:
 - Re-enter the command that generated this error message.OR
 - Re-enter the command that generated this error message without specifying the **mtpkse** parameter.
-

E3852 Cmd Rej: Specified APPL or LOC not supported with DATA parameter

Commands Used: **alw-card**, **init-card**, **rst-card**

You specified the **data** parameter with an invalid value for the **appl** or **loc** parameter. The **data** parameter is valid only for SCCP and EBDABLM card locations or GPLs.

Recovery

Perform one of the following actions:

- Re-enter the command specifying a valid value for the **appl** or **loc** parameter.
- OR
- Re-enter the command without specifying the **data** parameter.
-

E3853 Cmd Rej: SS7IPGW/IPGWI cards must be inhibited to change SYNC**Commands Used: chg-sg-opts**

You attempted to perform an action on a card that is not allowed if the card is in a state other than Out-of-Service - Maintenance-Disabled (OOS-MT-DSBLD).

Recovery

1. Enter the **inh-card** command to change the state of the card at the specified location to OOS-MT-DSBLD.

NOTE: If the card contains signaling links, all links must be OOS-MT-DSBLD before you can inhibit the card.

2. Re-enter the **chg-sg-opts** command that generated this error message.
-

E3854 Cmd Rej: NCICS unspecified, NCICE must be greater than or equal to CICS**Commands Used: chg-appl-rtkey**

The value entered for the new ending circuit identification code (**ncice**) must be greater than or equal to the value entered for the starting circuit identification code (**cics**), when the new starting circuit identification code (**ncics**) is not specified.

Recovery

Re-enter the **chg-appl-rtkey** command specifying a value for **ncice** that is greater than or equal to the value specified for **cics**.

Call your Customer Care Center if this error message appears again.

E3855 Cmd Rej: Command not valid for IPLIMI**Commands Used: blk-slk, tst-slk, ublk-slk**

The command you entered is not valid on TCP/IP links (DCM cards equipped with certain IPLIMI links).

NOTE: The command is allowable, however, for IPLIM M2PA link types. IPLIM/IPLIMI does support Ports A, B, A1, B1, A2, B2, A3 or B3 for M2PA/SCTP associations on SSEDCCM cards.

Recovery

1. Enter the **rtrv-card** command to verify that the card at the specified location is a DCM card running the IPLIMI application. This information is shown in the TYPE and APPL fields of the output.
2. If the card type is other than DCM and the application type is other than IPLIMI, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3856 Cmd Rej: Processor timeout error

Commands Used: chg-sg-opts

There was a processor timeout error during the period when this command was entered.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3857 Cmd Rej: Unexpected response message error

Commands Used: chg-sg-opts

This command generated an unexpected response message.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3858 Cmd Rej: Host Name Still Referenced in IP Link Table

Commands Used: dlt-ip-host

You entered the command to delete an entry from the IP Host table which defines local host names for IP addresses, but the entry has not been deleted from the IP Link table.

Recovery

1. Determine the associated IP address for the local host name. Enter the **rtrv-ip-host** command.
 2. Determine the parameter values for **loc** and **port** associated with the IP address from the output of step 1. Enter the **rtrv-ip-lnk** command.
 3. Change the IP address for the location and port from the output of step 2 to **0.0.0.0** (**ipaddr=0.0.0.0**). Enter the **chg-ip-lnk** command. This will delete the IP address for this entry from the IP Link table.
 4. Re-enter the **dlt-ip-host** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3859 Cmd Rej: Cannot assign LHOST to the B interface

Commands Used: **chg-appl-sock**, **ent-appl-sock**

You cannot provision a socket LHOST with a host name that is associated with the B interface.

Recovery

1. Determine the associated IP address for the host name. Enter the **rtrv-ip-host** command.
 2. Determine the parameter values for **loc** and **port** associated with the IP address from the output of step 1. Enter the **rtrv-ip-lnk** command.
 3. Re-enter the command that generated this error message, using the host name associated with the A interface.
Call your Customer Care Center if this error message appears again.
-

E3860 Cmd Rej: Port not valid for card or application type

Commands Used: **chg-appl-sock**, **chg-assoc**, **ent-appl-sock**,
ent-assoc

Only the **port/link=a** parameter can be specified on cards running the **ss7ipgw** or **ipgwi** applications.

Only **port/link=a** or **port/link=b** can be specified for the link parameter value if the card is a dual-slot DCM card running the **iplim** or **iplimi** application.

The port/link parameter values **a**, **b**, **a1**, **b1**, **a2**, **b2**, **a3**, and **b3** can be specified only if the card is an SSEDCCM card running the **iplim** or **iplimi** application.

Recovery

Display the card's configuration. Enter the **rtrv-card** command specifying the card location (**loc**) used in the command that generated this error message. The card's application is shown in the *APPL* field of the output.

- If the specified card is running the **ss7ipgw** or **ipgwi** application, re-enter the command specifying the **port/link=a** parameter.
- If the specified card is running the **iplim** or **iplimi** application, re-enter the command specifying the **port/link=a** or **port/link=b** parameter.
- If the specified card is a SSEDCCM card running the **iplim** or **iplimi** application, re-enter the command specifying only port/link parameter values **a, b, a1, b1, a2, b2, a3, and b3**.

Call your Customer Care Center if this error message appears again.

E3861 Cmd Rej: Cannot echo to OAP terminal

Commands Used: act-echo

You specified an OAP port for the **trm** parameter, which is not allowed.

Recovery

1. Determine the valid terminals in the system. Enter the **rtrv-trm** command. If the entry in the TYPE column is OAP, the terminal is not a valid choice.
 2. Re-enter the **act-echo** command specifying a valid value for the **trm** parameter.
-

E3862 Cmd Rej: SLSOCBIT parameter is only valid for ITU link sets

Commands Used: chg-ls, ent-ls

You attempted to specify the **slsocbit** parameter for a link set other than an ITU link set, which is not allowed. The **slsocbit** parameter is only valid for ITU link sets.

Recovery

Perform one of the following actions:

- Re-enter the command specifying an ITU link set.
- OR
- Re-enter the command without specifying the **slsobit** parameter.
-

E3863 Cmd Rej: SLSOCBIT parameter not permitted if SLSOCB feature is off

Commands Used: `chg-ls`, `ent-ls`

You cannot specify the **slsobit** parameter if the SLSOCB feature is turned off.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
 2. If the SLSOCB feature is turned on, re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the SLSOCB feature is turned off, turn the feature on: Enter the `chg-feat:slsob=on` command.
 4. Re-enter the command that generated this error message specifying the **slsobit** parameter
-

E3864 Cmd Rej: SLSRSB parameter is only valid for ITU Link Sets

Commands Used: `chg-ls`, `ent-ls`

You cannot specify the **slsrsb** parameter for a non-ITU link set. The **slsrsb** parameter is only valid for ITU link sets.

Recovery

Perform one of the following actions:

- Re-enter the command specifying the **s1srsb** parameter for an ITU link set.
OR
 - Re-enter the command without specifying the **s1srsb** parameter.
-

E3865 Cmd Rej: Cannot enter MTPRSE with SLSOCBIT, SLSRSB parameters

Commands Used: **rtrv-1s**

You cannot specify the MTP Restart Equipped (**mtprese**) parameter and the Other CIC Bit (**s1socbit**) or Rotated SKS Bit (**s1srsb**) parameter.

Recovery

Re-enter the **rtrv-1s** command specifying a valid parameter combination.

If necessary, consult your *Commands Manual*.

E3866 Cmd Rej: Fan feature must be enabled

Commands Used: **chg-t1, ent-card, ent-slk, ent-e1, ent-t1**

The fan feature bit must be on before you can

- add a DCM card,
- specify links **a4...a31**,
- specify links **b4...b31**,
- specify **linkclass=unchan** for an E1 port,
- provision ports **3...8**
- use HC-MIM cards in an EAGLE 5 ISS shelf (see the **chg-feat** command). The system checks the fan feature bit when E1 or T1 ports **3** through **8** are specified.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the fan feature is on, re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. To enable the fan feature bit, enter the **enable-ctrl-feat** command and the appropriate part number and access key information.
 4. To turn on the fan feature bit, enter the **chg-feat:fan=on** command.
 5. Verify the fan feature bit is turned on. Enter the **rtrv-feat** command.
 6. Re-enter the command that generated this error message.
-

E3867 Cmd Rej: MPC feature must be enabled

Commands Used: **ent-spc**, **rtrv-spc**

Before you can add a secondary point code (SPC), you must first turn on the Multiple Point Code (MPC) feature.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the MPC feature is turned on, re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the MPC feature is turned off, turn it on. Enter the **chg-feat:mpc=on** command.
 4. Re-enter the command that generated this error message.
-

E3868 Cmd Rej: Open sockets cannot have same lhost/lport

Commands Used: **chg-appl-sock**

You entered the command **chg-appl-sock:open=yes**, but the socket shares the same local host (**lhost**) and local port (**lport**). Multiple server sockets can share the same local host and local port, but no client socket can share the same local host and local port with another socket, either server or client.

Recovery

1. Contact your network administrator concerning the availability of a local port.
2. Re-enter the **chg-appl-sock** command specifying the new local port name (**lport**).

Call your Customer Care Center if this error message appears again.

E3870 Cmd Rej: GTT must be ON before VGTT can be ON

Commands Used: **chg-feat**

You cannot turn on the Variable length GTT (VGTT) feature because the Global Title Translation (GTT) feature is turned off. GTT must be turned on before you can turn on VGTT.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the GTT feature is turned on (GTT = on), re-enter the **chg-feat** command.
Call your Customer Care Center if this error message appears again.
 3. If the GTT feature is off, turn it on. Enter **chg-feat:gtt=on** command.
 4. Turn on the VGTT feature. Enter the **chg-feat:vgtt=on** command.
Call your Customer Care Center if this error message appears again.
-

E3871 Cmd Rej: ITUTFR parameter is only valid for ITU link sets

Commands Used: **chg-ls, ent-ls, rtrv-ls**

You attempted to specify the **itutfr** parameter for a non-ITU national linkset. The **itutfr** parameter is valid only for ITU national (ITU-N) linksets. Consequently, if you specify the **itutfr** parameter, the value specified for the **lsn** parameter must also be an ITU-N linkset.

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the **itutfr** parameter.
- OR
- Re-enter the command specifying the **itutfr** parameter with an ITU national linkset.
-

E3872 Cmd Rej: IPGWI link must be in a single link linkset

Commands Used: ent-slk

The card in the specified location is running the IPGWI application and it already has a link assigned to it. Only one IPGWI link is allowed in a linkset.

Recovery

1. Verify that the card at the specified location is running the IPGWI application. Enter the **rtrv-card** command.
 2. If the card is not running the IPGWI application, re-enter the **ent-slk** command.
Call your Customer Care Center if this error message appears again.
-

E3873 Cmd Rej: Card GPL type IPGWI requires a link set with IPGWAPC=YES

Commands Used: ent-slk

When entering an IP link (**type=ipgwi**) with the **ent-slk** command, the linkset name (**lsn**) parameter must reference a linkset that specifies an IP gateway adjacent point code (**ipgwapc=yes**).

Recovery

1. Determine if the IP link is **type=ipgwi** and references **ipgwapc=yes**. Enter the **rtrv-ls** command specifying the linkset name (**lsn**).
 2. If the criteria identified in step 1 are met, re-enter the **ent-slk** command.
Call your Customer Care Center if this error message appears again.
- OR

3. If the IP link is **type=ipgwi** but **ipgwapc** is not yes, enter the command **ent-ls:ipgwapc=yes**
 4. Re-enter the **ent-slk** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3874 Cmd Rej: TUP must use DPC/SI route key if DPC is ANSI

Commands Used: **chg-appl-rtkey, dlt-appl-rtkey, ent-appl-rtkey, rtrv-appl-rtkey**

You specified **si=4** (for a routing key in an ITU network using TUP) and an ANSI Destination Point Code (**dpc**). When you specify **si=4** and an ANSI DPC:

- You must specify only the **dpc** and **si** parameters to identify the routing key to be entered, deleted, retrieved, or changed.
- The **opc/opca/opci/opcn, cics, cice, ncics, ncice, split, pstncat, pstnid,** and **norm** parameters are not valid in this case.
- You can enter just the **sname** and **asname** for a new routing key.
- You can change only the **sname** (with the **nsname** parameter) and the **asname** (with the **nasname** parameter) of an existing routing key.

Recovery

Re-enter the command specifying only the **dpc** and **si** parameters to identify the routing key. Specify the **sname** or **asname** parameter to enter a new routing key or delete an existing routing key. Specify the **nsname** or **nasname** parameter to change an existing routing key.

E3875 Cmd Rej: Command not valid for IPGWI

Commands Used: **alw-slk, blk-slk, inh-slk, rept-stat-tstslk, tst-slk, unhb-slk**

The command you entered is not valid on TCP/IP point-to-multipoint links, that is, DCM cards equipped as IPGWI links.

Recovery

1. Verify that the card at the specified location is a DCM card running the IPGWI application. Enter the **rtrv-card** command. This information is shown in the TYPE and APPL fields of the output.
2. If the card type is other than DCM or the application type is other than IPGWI, re-enter the command.

Call your Customer Care Center if this error message appears again.

E3876 Cmd Rej: L2STATS not valid for IPGWI

Commands Used: **rept-stat-slk**

The command that you entered is not valid. **Level 2 status (l2stats)** output is not available for TCP/IP point-to-multipoint links (DCM cards equipped as IPGWI links).

Recovery

1. Enter the **rtrv-card** command to verify that the card at the specified location is a DCM card running the IPGWI application. This information is shown in the TYPE and APPL fields of the output.
2. If the card type is other than DCM card or the application type is other than IPGWI, re-enter the **rept-stat-slk** command.

Call your Customer Care Center if this error message appears again.

E3877 Cmd Rej: ANSI/ITU point code type mismatch

Commands Used: **chg-rtx, ent-rte, ent-rtx**

You entered a command to create a route with an ANSI DPC to go over an ITU APC or an ITU DPC to go over an ANSI APC. All routes with ANSI DPCs must use ANSI linkset APCs. A route with an ITU-I DPC can go over an ITU-N APC and an ITU-N DPC can go over an ITU-I APC.

The network domain of the APC in the Linkset specified by the linkset name (**lsn**) parameter must be the same network domain of specified the DPC or its alias.

Recovery

1. Display the linksets in the database. Enter the **rtrv-ls** command. The APCs of the linksets are shown in the APCA, APCI, and APCN fields of the output.

2. Enter the **rtrv-dstn** command to display the DPCs in the database. The DPCs are shown in the DPCA, DPCI, and DPCN fields of the output.
 3. Re-enter the command specifying a DPC type that is valid with the linkset APC type.
 - ANSI point codes are shown in the DPCA and APCA fields of the **rtrv-dstn** and **rtrv-ls** command outputs.
 - ITU-I point codes are shown in the DPCI and APCI fields of the **rtrv-dstn** and **rtrv-ls** command outputs.
 - ITU-N point codes are shown in the DPCN and APCN fields of the **rtrv-dstn** and **rtrv-ls** command outputs.
 - 24-bit ITU-N point codes are shown in the DPCN24 and APCN24 fields of the **rtrv-dstn** and **rtrv-ls** command outputs.
-

E3878 Cmd Rej: CIC outside of valid range for SI

Commands Used: **chg-appl-rtkey**, **dlt-appl-rtkey**,
ent-appl-rtkey, **rtrv-appl-rtkey**

You specified a starting Circuit Identification Code (**cics**) or ending Circuit Identification Code (**cice**) that is out of range for the routing key SI. The **cics** and **cice** parameters are valid only if **si=4, 5, or 13**.

Refer to the **chg-appl-rtkey** description in the *Commands Manual* for valid CIC and SI parameter values for MSU types.

- For the **chg-appl-rtkey** command, you specified a value for the **cics** or **cice** parameter, or both, that is outside the CIC range that was defined for the routing key that you want to change.
- For the **dlt-appl-rtkey** or **rtrv-appl-rtkey** command, you specified a value for the **cics** or **cice** parameter, or both, that is outside the CIC range that was defined for the routing key to be deleted or retrieved.
- For the **ent-appl-rtkey** command, you can specify the **cics** and **cice** parameters only if you specify **si=5**. You specified a value for the **cics** or **cics** parameter, or both, that is outside the valid range for **si** type 5 and the DPC type.

Table 2-33. Valid CIC Ranges for SI and MSU Types

SI	MSU for ANSI DPC	MSU for ITU DPC	Comments
4 (TUP)	N/A	CIC is 12 bits. Range is 0-4095	The TUP protocol is used only in ITU networks.

Table 2-33. Valid CIC Ranges for SI and MSU Types (Continued)

SI	MSU for ANSI DPC	MSU for ITU DPC	Comments
5 (ISUP)	CIC is 14 bits. Range is 0-16383	CIC is 12 bits. Range is 0-4095	
13 (QBICC)	CIC is 32 bits. Range is 0-4294967295		

Recovery

1. If you entered a **chg-appl-rtkey** or **dlt-appl-rtkey** command, you can enter the **rtrv-appl-rtkey** command to verify the SI and the CIC or CIC range for the routing key to be deleted or changed (see the SI, CICS, and CICE columns in the output).
 2. Re-enter the command that generated this error message, with a valid value for the **cics** or **cice** parameter, or both, for the routing key SI.
-

E3879 Cmd Rej: The MPC feature must be ON before ITUDUPPC can be ON**Commands Used: chg-feat**

You tried to turn on the ITUDUPPC (ITU National duplicate point code) feature, but the MPC (Multiple Point Code) feature is not on. MPC must be turned on before you can turn on ITUDUPPC.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the MPC feature is turned on (MPC = on from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the MPC feature is off (MPC = off from the output of step 1), enter **chg-feat :mpc=on** to turn on MPC.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3880 Cmd Rej: Grp Code of dstn & True PC must match if no Secondary PC

Commands Used: `chg-dstn`, `ent-dstn`

You specified an ITU-N destination that does not use a secondary point code (**spc**). In such cases, the group code of the ITU-N destination must match the group code of the true point code (**tpc**).

Recovery

1. Enter the `rtrv-sid` command to display the group code of true point code. The group code (**aa-zz**) is a two-letter code appended to the last subfield of an ITU-N point code. It appears in the PCN column of the `rtrv-sid` output. Here is an example: `128-15-1-1-si` (**si** is the group code).
 2. Re-enter the command that generated this error message specifying an ITU-N destination whose group code matches the group code of the true point code.
-

E3881 Cmd Rej: Group Code of destination and Secondary PC must match

Commands Used: `chg-dstn`, `ent-dstn`

You specified an ITU-N destination that uses an secondary point code (**spc**). The group code of the ITU-N destination must match the group code of the SPC. The group code (**aa-zz**) is the two-letter code appended to the last subfield of an ITU-N point code (for example, **si** is the group code in SPC: `128-15-1-1-si`).

Recovery

1. Display the SPCs in the SPC table. Enter the `rtrv-spc` command.
 2. Re-enter the command that generated this error message specifying an ITU-N destination whose group code matches the group code of the secondary point code.
-

E3883 Cmd Rej: GSM Map Screening feature must be ON

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`,
`chg-measopts`, `chg-stpopts`, `enable-ctrl-feat`,
`ent-gsms-opcode`, `ent-gsmssn-scrn`, `ent-gsmmap-scrn`,
`rept-ftp-meas`, `rept-meas`

Table 2-34 lists by command the conditions that cause this error. Use the procedure following the table for the error response.

Table 2-34. Conditions that Generate an E3883 Error Message

Commands	Condition
chg-stpopts	The GSM MAP Screening feature must be turned on before you can specify the gsmdflt or gsmdecerr parameters.
chg-gsmmap-scrn , ent-gsmmap-scrn , chg-gsms-opcode , ent-gsms-opcode , ent-gsmssn-scrn	The command you entered requires the GSM MAP Screening feature turned on.
chg-measopts , rept-ftp-meas , rept-meas	The GSM MAP Screening feature must be turned on before you can specify enttype=mapscrn parameter.
enable-ctrl-feat	The GSM MAP Screening feature must be turned on before enabling the EGMS feature.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled.

Refer to the *Database Administration Manual - Features* and the *Commands Manual* about enabling features with access keys.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.
 2. Verify the GSM MAP Screening feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
 3. Enable the GSM MAP Screening feature in your system. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual - Features* for more information about enabling this feature.
 4. Turn on the feature. Enter the **chg-ctrl-feat** command.
 5. Re-enter the command that generated this error message.
-

E3884 Cmd Rej: SSN/TYPE combination already exists

Commands Used: `ent-gsmssn-scrn`

You attempted to enter an **ssn/type** parameter combination that already exists in the GSM SSN Screening table. The subsystem number and type pairs must be unique.

Recovery

Re-enter the `ent-gsmssn-scrn` command specifying different values for the `ssn/type` parameter combination.

E3885 Cmd Rej: Failure reading the GSM SSN Screening Table

Commands Used: `ent-gsmssn-scrn`, `dlt-gsms-opcode`,
`dlt-gsmssn-scrn`, `rtrv-gsmssn-scrn`

The GSM SSN Screening table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3886 Cmd Rej: SSN/TYPE combination does not exist

Commands Used: `ent-gsmssn-scrn`, `dlt-gsmssn-scrn`

You specified an **ssn/type** parameter combination that does not already exist in the GSM SSN Screening table as required.

Recovery

1. Display the GSM SSN Screening table. Enter the `rtrv-gsmssn-scrn` command.
 2. Re-enter the command specifying an **ssn/type** parameter combination that exists in the GSM SSN Screening table.
-

E3887 Cmd Rej: OPCODE already exists

Commands Used: `ent-gsms-opcode`

You specified a value for the **opcode** parameter that already exists in the GSM MAP Op-Code table. You must specify a unique value.

Recovery

1. Display the GSM MAP Op-Code table. Enter the `rtrv-gsms-opcode` command.
 2. Re-enter the `ent-gsms-opcode` command specifying a value for the **opcode** parameter that does not already exist in the database.
-

E3888 Cmd Rej: OPNAME already used

Commands Used: `ent-gsms-opcode`

You specified a value for the **opname** parameter that already exists in the GSM MAP Op-Code table. You must specify a unique value.

Recovery

1. Display the GSM MAP Op-Code table. Enter the `rtrv-gsms-opcode` command.
 2. Re-enter the `ent-gsms-opcode` command specifying a value for the **opname** parameter that does not already exist in the database.
-

E3889 Cmd Rej: Failure reading the GSM OPCODE Table

Commands Used: `chg-gsms-opcode`, `chg-gsmmap-scrn`,
`dlt-gsms-opcode`, `dlt-gsmmap-scrn`, `ent-gsms-opcode`,
`ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`

The GSM MAP Op-Code table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3890 Cmd Rej: Failure reading the GSM MAP SCRN Table

Commands Used: `chg-gsmmap-scrn`, `dlt-gsmmap-scrn`,
`ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

The GSM MAP screening table must be accessible for the command to execute. A failure occurred in reading the table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3892 Cmd Rej: OPNAME does not exist in the database

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`,
`dlt-gsmmap-scrn`, `dlt-gsms-opcode`, `ent-gsmmap-scrn`,
`rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`

You specified a value for the opname parameter that does not exist in the GSM MAP Op-Code table. You must specify an existing value.

Recovery

1. Enter the `rtrv-gsms-opcode` command to display the existing entries.
 2. Re-enter the original command specifying a value for the opname parameter that already exists in the database.
-

E3893 Cmd Rej: Entry being deleted is referenced by a GSM MAP Screen entry

Commands Used: `dlt-gsms-opcode`

You attempted to delete an entry that is referenced in the GSM MAP screening table. This action is not allowed.

Recovery

1. Delete the entry from the GSM MAP screening table. Enter the `dlt-gsms-scrn` command.
 2. Delete the desired entry. Re-enter the `dlt-gsms-opcode` command.
-

E3894 Cmd Rej: SADDR and EADDR must have the same number of digits

Commands Used: `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

The **saddr** parameter does not contain the same number of digits as the **eaddr** parameter. The **saddr** and the **eaddr** parameter must contain the same number of digits.

Recovery

Re-enter the command specifying the same number of digits for the **saddr** and the **eaddr** parameter values.

E3895 Cmd Rej: EADDR must be greater than SADDR

Commands Used: `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

The value specified for the **eaddr** parameter is less than the value specified for the **saddr** parameter.

Recovery

Re-enter the command specifying a value for the **eaddr** parameter that is greater than or equal to the value for the **saddr** parameter.

E3897 Cmd Rej: GSM MAP SCRN entry already exists or overlaps another entry

Commands Used: `ent-gsmmap-scrn`

You specified either a single entry for the CgPA or CdPA (that is, the **eaddr** parameter was not specified) or a range entry for the CgPA or CdPA (that is, the **eaddr** parameter was specified).

- If a single entry is specified for the CgPA or CdPA (that is, **eaddr** is not specified), the combination of **saddr**, **npv**, **naiv** for the specified **opname** must not already exist in the GSM MAP Screening Table.
- If a range entry is specified for the CgPA or CdPA (that is, **eaddr** is specified), the combination of **saddr**, **eaddr**, **npv**, **naiv** for the specified **opname** must not already exist or overlap with another range entry in the GSM MAP Screening Table.

Recovery

1. Display a list of existing entries. Enter the **rtrv-gsmmap-scrn** command.
 2. Re-enter the **ent-gsmmap-scrn** command specifying a single or range entry that does not already exist or that does not overlap any other range entry in the database.
-

E3898 Cmd Rej: EADDR can not be specified without SADDR

Commands Used: **ent-gsmmap-scrn**, **rtrv-gsmmap-scrn**

If you specify the **eaddr** parameter, you must also specify the **saddr** parameter. The **eaddr** parameter alone is not supported.

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the **eaddr** parameter.
- OR
- Re-enter the command specifying both the **eaddr** and **saddr** parameters.
-

E3899 Cmd Rej: EGMS feature requires DSM card with VSCCP APPL or better

Commands Used: **ent-card**

You cannot provision a TSM card with the SCCP application when the Enhanced GSM MAP Screening (EGMS) feature is enabled. The Enhanced GSM MAP Screening (EGMS) feature requires a DSM card with the VSCCP application or better.

Recovery

Re-enter the **ent-card** command specifying the correct card type and application combination.

E3900 Cmd Rej: GSM Map Screening feature must be enabled

Commands Used: `dlt-gsms-opcode`, `dlt-gsmmap-scrn`,
`dlt-gsmssn-scrn`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`,
`rtrv-gsmssn-scrn`

The command failed because the GSM MAP Screening feature is not enabled.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* about enabling features with access keys.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
 2. Verify the GSM MAP Screening feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
 3. If you have purchased and installed the GSM MAP Screening feature in your system, use the `enable-ctrl-feat` command first to enable the feature.
Refer to the *Commands Manual* and the *Database Administration Manual - Features* for more information about enabling this feature.
 4. When the GSM MAP Screening feature is enabled, you can re-enter the command that generated this error message.
-

E3901 Cmd Rej: CGPA entry is referred by CDPA entries

Commands Used: `dlt-gsmmap-scrn`

The CgPA entry cannot be deleted because it is referred to by other CdPA entries.

Recovery

1. Display the existing CdPA entries for the CgPA you want to delete. Enter the `rtrv-gsmmap-scrn` command.
 2. Delete all the CdPA entries located in step 1 for the CgPA you want to delete.
 3. Re-enter the `dlt-gsmmap-scrn` command.
-

E3902 Cmd Rej: FORBID can not be STATE or LOCATION for the given OPNAME

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`,
`rtrv-gsmmap-scrn`

To specify the **nforbid/forbid=state/location** parameter, the operation code referenced by the specified **opname** must have a value of 71. The **nforbid/forbid=state/location** option is only valid for ATI MAP operation codes; **opcode=71** signifies an ATI MAP operation code.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a different value for the **opname** parameter

OR

- Re-enter the command that generated this error message without specifying **nforbid/forbid=state/location**.
-

E3903 Cmd Rej: Screening action can not be ATIERR for the given OPNAME

Commands Used: `chg-gsmmap-scrn`, `ent-gsmmap-scrn`,
`rtrv-gsmmap-scrn`

To specify the **action=atierr**, or **naction=atierr** parameter, the operation code referenced by the specified **opname** must have a value of 71. The **atierr** option is only valid for ATI MAP operation codes; **opcode=71** signifies an ATI MAP operation code.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying **action/naction=pass/discard**, but do not specify a value of **atierr**.

OR

- Re-enter the command that generated this error message specifying a different value for the **opname** parameter (that is, **opcode=71**).
-

E3904 Cmd Rej: DFLTACT cannot be ATIERR unless OPCODE=71

Commands Used: `chg-gsms-opcode`, `ent-gsms-opcode`

You specified the `dfltact/ndfltact=atierr` parameter with a value other than 71 for the `opcode` parameter. If you specify the `dfltact/ndfltact=atierr` parameter, you must specify `opcode=71`. The `atierr` option is only valid for ATI MAP operation codes; `opcode=71` signifies an ATI MAP operation code.

Recovery

Re-enter the command specifying the `dfltact=atierr` or `ndfltact=atierr` and `opcode=71` parameter combination.

E3905 Cmd Rej: CGSR doesn't exist for specified OPNAME

Commands Used: `chg-gsmmap-scrn`, `dlt-gsmmap-scrn`,
`ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

You issued a command that requires a `cgscr` that does not currently exist in the database. The following lists by command remedial actions to perform for this error.

For additional details, refer to the *Commands Manual*.

Recovery `chg-gsmmap-scrn`, `dlt-gsmmap-scrn`

You issued a command that requires an existing `cgscr` (CgPA Screening Reference). This error reports that the specified `opname` does not have a `cgscr`.

1. Enter the `rtrv-gsmmap-scrn` command specifying the `opname` specifying the same as the original message.
 2. Re-enter the command specifying the appropriate `opname`, `cgscr`, and optionally the `cdsr` parameter(s).
-

Recovery `ent-gsmmap-scrn`, `rtrv-gsmmap-scrn`

You issued a command that requires an existing `cgscr` (CgPA Screening Reference). This error reports that the specified `opname` does not have a `cgscr`.

1. To create a CgPA entry, enter the `ent-gsmmap-scrn` command specifying the `cgscr` and `opname` parameters.

2. To create a CdPA entry, enter the `ent-gsmmap-scrn` command specifying the `opname`, `cgsr`, and `cdsr` parameters.
 3. To display any portion of the EGMS MAP Screen Table, specify the `rtrv-gsmmap-scrn` command and the appropriate `opname`, `cgsr`, and optionally the `cdsr` parameter(s)
-

E3906 Cmd Rej: The GSM MAP Screening table is full

Commands Used: `ent-gsmmap-scrn`

The GSM MAP Screening table is full. You must delete an entry before another one can be added.

Recovery

1. Display the GSM MAP Screening table. Enter the `rtrv-gsmmap-scrn` command.
 2. Enter the `dlt-gsmmap-scrn` command specifying an entry shown in the output in step 1.
 3. Re-enter the `ent-gsmmap-scrn` command that generated this error message. Call your Customer Care Center if this error message appears again.
-

E3908 Cmd Rej: Invalid OAM HW config or an HMUX card is out of service

Commands Used: `act-upgrade`

When the command was entered, the system detected a problem with the hardware baseline required for release 30.0 or above, namely one of the following was missing or not operating.

- An invalid OAM configuration: either a correct TDM card (-10 or later) is missing or the HMUX options are not turned on
- An HMUX card is out of service.

Verify the required hardware baseline is installed and operating by performing these actions.

Recovery

1. Ensure that TDM cards with part number 870-0774-10 or later, (or 870-0774-18), are installed.

2. Verify that all HMUX cards are in service with the **rept-stat-card** command.
 3. Re-enter the **act-upgrade** command.
Call your Customer Care Center if this error message appears again.
-

E3910 Cmd Rej: Translation TYPEN24 specified does not exist

Commands Used: **dlt-tt**, **rtrv-tt**

The translation type specified (**typen24**) must be in the Translation Type table.

Recovery

1. Re-enter the **rtrv-tt** or **rtrv-gtt** command specifying no parameters to display the Translation Type table.
 2. Re-enter the command specifying one of the translation type (**tt**) values displayed from the output of step 1.
-

E3911 Cmd Rej: Either PLNP or WNP Features must be ON

Commands Used: **chg-1npopts**

You specified the **wqredrct** parameter, which requires that either the PCS (Personal Communication Service) 1900 Number Portability feature or the WNP (Wireless LNP) feature be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command.
 2. If the PCS or WNP feature is turned on (**wnp=on** or **plnp=off**), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If both features are turned off (**wnp=off** or **plnp=off**), enter the **chg-feat** command to turn one or both of the features on.
 4. Re-enter the command that generated this error message.
-

E3912 Cmd Rej: Translation TYPEN already exists

Commands Used: `ent-tt`

The translation type (**typen**) specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

1. Determine if the translation type you want to use already exists in the translation type table. Enter the `rtrv-tt` command.
 2. Re-enter the `ent-tt` command specifying a different translation type.
To see if the translation type you want to use already exists in the translation type table, enter the `rtrv-tt` command.
-

E3913 Cmd Rej: Translation TYPEI already exists

Commands Used: `ent-tt`

The translation type (**typei**) specified already exists in the translation type table. You cannot add a translation type that already exists.

Recovery

Re-enter the `ent-tt` command specifying a different translation type.
To see if the translation type you want to use already exists in the translation type table, enter the `rtrv-tt` command.

E3914 Cmd Rej: CdPA GTT Selector already exists in GTIN-TT-NP(V)-NAI(V)

Commands Used: `ent-gttse1`

The specified CdPA Selector was not entered because an entry that matches the values specified **gtin**, **tt**, and **np/ nai** or **npv/ naiv** parameter combination already exists in the GTT Selector table.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttse1` command.
 2. Re-enter the `ent-gttse1` command specifying values for the above parameters that do not already exist in the database.
-

E3915 Cmd Rej: CdPA GTT Selector already exists in GTII-TT-NP(V)-NAI(V)

Commands Used: `ent-gttsel`

The specified CdPA selector was not entered because an entry that matches the values specified for the `gtii`, `tt`, and `np/naï` or `npv/naïv` parameter combination, already exists in the GTT Selector table.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttsel` command.
 2. Re-enter the `ent-gttsel` command specifying values for the above parameters that do not already exist in the database.
-

E3916 Cmd Rej: GTT Selector does not exist in GTIN-TT-NP(V)-NAI(V)

Commands Used: `chg-gttsel`, `dlt-gttsel`

You specified an entry that does not match an existing `gtin`, `tt`, `np/naï`, and `npv/naïv` parameter combination as required.

For example, if you want to change the change the selectors linked with GTTSN `ansi1` so that they are linked to GTTSN `ansi2`, and the current selectors for `ansi1` are (`gtin=2`, `tt=5`, `npv=1`, `naïv=2`), you would enter the following combination:

```
chg-gttsel:gtin=2:tt=5:npv=1:naïv=2:gttsn=ansi2
```

This example assumes that `gttsn=ansi2` is an existing GTT set in the database.

Recovery

1. Display the GTT Selector table. Enter the `rtrv-gttsel` command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3917 Cmd Rej: GTT Selector does not exist in GTII-TT-NP(V)-NAI(V)

Commands Used: `chg-gttsel`, `dlt-gttsel`

You specified an entry that does not match an existing `gtii`, `tt`, `np/naï`, and `npv/naïv` parameter combination as required. For example, if you want to change the change the selectors linked with GTTSN `ansi1` so that they are linked to GTTSN `ansi2`, and the current selectors for `ansi1` are (`gtii=2`, `tt=5`, `npv=1`, `naïv=2`), you would enter the following combination:

```
chg-gttsel:gtii=2:tt=5:npv=1:naïv=2:gttsn=ansi2
```

This example assumes that **gttsn=ansi2** is an existing GTT set in the database.

Recovery

1. Display the GTT Selector table. Enter the **rtrv-gttsel** command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3918 Cmd Rej: Translation TYPEN specified does not exist

Commands Used: chg-gtt, dlt-gtt, dlt-tt, ent-gtt, rtrv-gtt, rtrv-tt

The translation type specified (**typen**) must be in the Translation Type table.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** or **rtrv-gtt** command specifying no parameters.
 2. Re-enter the command specifying one of the translation type values displayed.
-

E3919 Cmd Rej: Translation TYPEI specified does not exist

Commands Used: chg-gtt, dlt-gtt, dlt-tt, ent-gtt, rtrv-gtt, rtrv-tt

The translation type specified (**tt=typei**) is not in the Translation Type table.

Recovery

1. Display the Translation Type table. Enter the **rtrv-tt** or **rtrv-gtt** command specifying no parameters.
 2. Re-enter the command specifying a Translation Type values that exists in the Translation Type table.
-

E3920 Cmd Rej: VGTT cannot be On if any SCCP card has a 486 processor**Commands Used: chg-feat**

You attempted to bring VGTT online, but your hardware is inadequate and requires upgrading. To turn on both the VGTT and LNP features requires that you have all DSM cards on your system. To turn on both the VGTT and EGTT features requires that you have TSM cards. You cannot turn on the VGTT feature if you have ASM cards on your system.

Recovery

1. Upgrade your hardware.
2. Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3921 Cmd Rej: ITU National Point Code must be full point code**Commands Used: all commands that use ITU national point codes except retrieve commands**

You entered the command and specified an ITU national point code that is not a full point code. A full point code is one that you specify with a numerical value for the *nnnn* segment of the point code. If the ITUDUPPC (ITU national duplicate point code) feature is on, the ITU national point code will also contain a group code. The group code is a two-character field from **aa** to **zz** that is entered as the last subfield of an ITU-N point code, *nnnn-gc* (for example, 2112-aa). You can also assign a flexible point code format with the **chg-stpopts:npfmt** parameter.

Refer to the **chg-stpopts** command in the *Commands Manual* for information on flexible point code formats.

None of the above formatting options allows you to use an asterisk (*) for entering or changing ITU national point codes. The asterisk is allowed only for retrieving ITU national point codes.

Recovery

Re-enter the command specifying a valid value for the ITU national point code.

E3922 Cmd Rej: GTT must be ON before INP can be ON**Commands Used: chg-feat**

You cannot turn on the INAP Number Portability (INP) feature, if the Global Title Translation (GTT) feature is turned off. The GTT feature must be turned on before you can turn on INP feature.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
 2. If the GTT feature is turned on (GTT = on from the output from step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the GTT feature is off (GTT = off from the output from step 1), turn it on. Enter the `chg-feat:gtt=on` command.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3923 Cmd Rej: INP and LNP are mutually exclusive**Commands Used: chg-feat, enable-ctrl-feat**

You tried to turn on either the INP or the LNP feature, but the other of the features is already turned on. These two features are mutually exclusive, so you can have either feature on, but not both.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** command to verify the status of the INP feature and the **rtrv-ctrl-feat** command to verify the status the LNP feature.
 2. If both features are turned off (where INP=off and the LNP ported TNs entry does not appear in the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E3925 Cmd Rej: HOMERN Table is full**Commands Used: ent-homern**

The HOMERN table is full. You must delete a routing number before another one can be added.

Recovery

1. Display the routing numbers in the HOMERN table. Enter the **rtrv-homern** command.
 2. Enter the **dlt-homern** command specifying a routing number shown in the output from step 1.
 3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3926 Cmd Rej: Failed reading HOMERN Table**Commands Used: dlt-homern, ent-homern, rtrv-homern**

The HOMERN table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3927 Cmd Rej: Failed reading INPOPTS Table**Commands Used: chg-inpopts, rtrv-inpopts**

The INPOPTS table is corrupt or cannot be found by the system.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3928 Cmd Rej: STP True PC and INP SSN do not exist in MAP table

Commands Used: `ent-ss-appl`

You attempted to reserve an INP subsystem number (**ssn**) for an application, but the STP true point code/subsystem number combination has not been defined in the mated applications (MAP) table.

Recovery

1. View the point codes assigned to the system. Enter the `rtrv-sid` command
 2. Assign mated application values for the true point code (`pc/pca/pci/pcn`) and the INP subsystem number (**ssn**). Enter the `ent-map` command.
 3. Re-enter the `ent-ss-appl` command specifying the newly assigned values for (`pc/pca/pci/pcn`) and the INP **ssn**.
-

E3929 Cmd Rej: LNP or INP feature must be ON

Commands Used: `alw-map-ss`, `inh-map-ss`

The INP (INAP number portability) feature or LNP (Local Number Portability) feature must be turned on prior to issuing this command.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` and the `rtrv-ctrl-feat` commands.
2. If the INP or LNP feature is turned on (`inp=on` or the LNP ported TNs entry appears in the output of step 1), re-enter the command.

Call your Customer Care Center if this error message appears again.

3. If the INP and LNP features are off (**inp=off** or the LNP ported TNs entry does not appear in the output of step 1), you can:
 - Turn on the INP features. Enter the **chg-feat:inp=on** command.
OR
 - Turn on the LNP feature. Enter the **enable-ctrl-feat** command.Refer to the "Activating the LNP Feature" procedure in the *LNP Feature Activation Guide* or *Database Administration Manual - LNP*, and call your Customer Care Center before starting the process)
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3930 Cmd Rej: RN already exists in HOMERN Table

Commands Used: **ent-homern**

You specified a routing number (**rn**) that already exists in the HOMERN table. The **rn** must be unique to the HOMERN table.

Recovery

1. Display the routing numbers in the HOMERN table. Enter the **rtrv-homern** command.
 2. Re-enter the **ent-homern** command that generated this error message specifying a value for **rn** that is not in the output in step 1.
-

E3931 Cmd Rej: RN does not exist in HOMERN Table

Commands Used: **dlt-homern**

The routing number (RN) must exist in the HOMERN table.

Recovery

1. Display the routing numbers in the HOMERN table. Enter the **rtrv-homern** command.
 2. Re-enter the **dlt-homern** command specifying one of the RN values displayed in the output of step 1.
-

E3932 Cmd Rej: GFLEX, INP, or GPORT feature must be ON

Commands Used: `chg-stpopts`, `ent-trace`

Table 2-35 lists by command the conditions that may detect this error. The table is followed by a procedure that provides a remedy to the error.

Table 2-35. Conditions that Generate an E3932 Error Message

Commands	Condition
<code>chg-stpopts</code>	The INP (INAP number portability) feature, G-Flex (GSM flexible numbering), or G-Port (GSM mobile number portability) feature must be turned on prior to specifying the <code>defcc</code> , <code>defndc</code> , and <code>dsmaud</code> parameters.
<code>ent-trace</code>	The INP, G-Flex, or G-Port feature must be turned on prior to specifying the <code>dn</code> and <code>entityid</code> parameters.

NOTE: Once a feature has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.
 2. If the INP, G-Flex, or G-Port feature is turned on (`inp/gflex/gport = on` from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the INP, G-Flex, G-Port feature is off (`inp/gflex/gport = off` from the output of step 1), enter `chg-feat` command to turn on the required feature.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3934 Cmd Rej: CPCx must not be ANSI if CPCTYPE is INP or EIR

Commands Used: `chg-sid`

You specified the `cpctype=inp` or `cpctype=eir` parameter with an ANSI point code. This action is not allowed.

Recovery

Re-enter the **chg-sid** command that generated this error message, but this time do one of the following actions:

- Specify a value other than **inp** or **eir** for the **cpctype** parameter.
 - Specify **cpcn/ncpcn/ncpcn24** or **cpci/ncpci** for the point code.
-

E3935 Cmd Rej: DRANP and DRANPV must not be specified together

Commands Used: **chg-inopts**, **rtrv-inopts**

You cannot specify both the **dranp** and **dranpv** parameters.

Recovery

Re-enter the command specifying either the **dranp** or the **dranpv** parameter, but not both.

E3936 Cmd Rej: DRANAI and DRANAIV must not be specified together

Commands Used: **chg-inopts**, **rtrv-inopts**

You cannot specify the **dranai** and **dranaiv** parameters together in the same command.

Recovery

Re-enter the command specifying either the **dranai** or **dranaiv** parameter, but not both.

E3937 Cmd Rej: Entry already exists with specified GTI-TT-NP(V)-NAI(V)-SSN

Commands Used: **ent-srvsel**

You cannot specify a value that matches an existing **gti**, **tt**, **nai(v)**, **np(v)**, and **ssn** parameter combination.

Recovery

1. Display the existing values for the above parameters. Enter the **rtrv-srvsel** command.
 2. Re-enter the **ent-srvsel** command specifying values that do not already exist in the database for the above parameters.
-

E3938 Cmd Rej: Entry does not exist with specified GTI-TT-NP(V)-NAI(V)-SSN

Commands Used: **chg-srvsel, dlt-srvsel**

You specified an entry that does not match an existing **gti, tt, np/nai** and **npv/naiv**, and **ssn** parameter combination as required.

Recovery

1. Display the service selectors. Enter the **rtrv-srvsel** command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3939 Cmd Rej: (N)SNP must be E164 when NSERV=INPMR

Commands Used: **chg-srvsel, ent-srvsel, rtrv-srvsel**

If you specify the **nserv=inpmr** parameter, you must also specify either the **nsnp=e164** or **snp=e164** parameter.

Recovery

Re-enter the command specifying the **nserv=inpmr** parameter and either the **nsnp=e164** or **snp=e164** parameter.

E3940 Cmd Rej: (N)SERV value is invalid for the specified (N)SNAI

Commands Used: **chg-srvsel, ent-srvsel, rtrv-srvsel**

You specified one of the following values for the **nsnai/snai** parameter: **rnidn, rnrndn, rnsdn**, and you specified a value other than **inpmr, gport, smsmr**, or **mnpmsms** for the **nserv/serv** parameter. This parameter combination is not allowed.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying a valid value for the **nserv/serv** parameter. (Note that the **nsnai/snai** parameter may not be specified if you specify **serv=inpq**).

OR

- Re-enter the command that generated this error message specifying some other value for the **nsnai/snai** parameter.
-

E3941 Cmd Rej: GTII must not be specified when (N)SERV = INPQ

Commands Used: **chg-srvsel, ent-srvsel, rtrv-srvsel**

The **gtii** parameter cannot be specified if the **nserv/serv=inpq** parameter is specified.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message specifying either the **gti, gtia, or gtin** parameter and the **nserv/serv=inpq** parameter.

OR

- Re-enter the command that generated this error message without specifying the value **inpq** for the **nserv/serv** parameter.
-

E3942 Cmd Rej: GTI/GTIA is invalid for specified (N)SERV

Commands Used: **chg-srvsel, ent-srvsel**

The **gti** or **gtia** parameter cannot be specified if the **nserv/serv=inpqr, inpq, gport, smsmr, mnpsms, or eir** parameter is specified.

Recovery

Re-enter the command that generated this error message performing one of the following actions:

- Re-enter the command that generated this error message specifying **nserv/serv = gflex, inpq, inpmr, gport, smsmr, mnpsms, or eir.**
OR
 - Re-enter the command that generated this error message specifying the **gtin** parameter and **nserv/serv=inpq, inpmr, gport, smsmr, mnpsms, or eir.**
OR
 - Re-enter the command that generated this error message specifying the **gtin** or **gtii** parameter and **nserv/serv=inpmr**
-

E3943 Cmd Rej: (N)SNP/(N)SNAI must not be specified when (N)SERV=INPQ/EIR

Commands Used: chg-srvsel, ent-srvsel, rtrv-srvsel

The parameters **nsnp, snp, nsnai, or snai** cannot be specified if **nserv/serv=inpq** or **eir**.

Recovery

Perform one of the following actions:

- Re-enter the command that generated this error message without specifying the **nsnp, snp, nsnai, or snai** parameter.
OR
 - Re-enter the command that generated this error message without specifying **nserv/serv=inpq** or **eir**.
-

E3944 Cmd Rej: SNAI & SNP must be specified when SERV is not INPQ/EIR

Commands Used: ent-srvsel

The **snai** and **snp** parameters must be specified when **serv=gflex, gport, inpmr, smsmr, or mnpsms**.

Recovery

Perform one of the following corrections:

- Re-enter the **ent-srvsel** command specifying the **snp** and **snai** parameters.
- OR
- Re-enter the **ent-srvsel** command specifying a valid value for the **serv** parameter.
-

E3945 Cmd Rej: SERV must not be GFLEX when SNAI = RNIDN/RNNDN/RNSDN

Commands Used: rtrv-srvsel

You specified the **serv=gflex** parameter with one of the following values for the **snai** parameter: **rnidn**, **rnndn**, or **rnsdn**. This parameter combination is not allowed.

Recovery

Perform one of the following actions:

- Re-enter the **rtrv-srvsel** command specifying a value other than **gflex** for the **serv** parameter.
- OR
- Re-enter the **rtrv-srvsel** command specifying a value other than **rnidn**, **rnndn**, or **rnsdn** for the **snai** parameter.
-

E3946 Cmd Rej: Entry already exists with specified GTII-TT-NP(V)-NAI(V)-SSN

Commands Used: ent-srvsel

You specified an entry that matches an existing **gtii**, **tt**, **np(v)**, **npv/naiv** and **ssn** parameter combination, which is not allowed.

Recovery

1. Display the existing values for the above parameters. Enter the **rtrv-srvsel** command.
 2. Re-enter the **ent-srvsel** command specifying values that do not already exist in the database for the above parameters.
-

E3947 Cmd Rej: Entry already exists with specified GTIN-TT-NP(V)-NAI(V)-SSN**Commands Used: ent-srvsel**

You cannot specify a value for a parameter that matches the value of an existing **gtin**, **tt**, **np(v)**, **nai(v)**, and **ssn** parameter combination.

Recovery

1. Display the service selectors. Enter the **rtrv-srvsel** command.
 2. Re-enter the **ent-srvsel** command specifying values that do not already exist in the database for the above parameters.
-

E3948 Cmd Rej: Entry does not exist with specified GTII-TT-NP(V)-NAI(V)-SSN**Commands Used: chg-srvsel, dlt-srvsel**

You specified an entry that does not match an existing **gtii**, **tt**, **np(v)** and **nai(v)**, and **ssn** parameter combination as required.

Recovery

1. Display the service selectors. Enter the **rtrv-srvsel** command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3949 Cmd Rej: Specified card cannot be the Active MASP**Commands Used: act-flash, init-flash, alw-card, rst-card, inh-card, rmv-card**

You specified the card address for the Active MASP card in the **loc** parameter for the command. The card address in the command cannot be for the Active MASP

Recovery

Re-enter the command specifying a card address in the **loc** parameter that is not the Active MASP.

E3950 Cmd Rej: Standby MASP is inhibited

Commands Used: Any command used to update a database

You entered a command to update the system database. The database cannot be updated because the standby MASP is inhibited.

Recovery

1. Enter the **alw-card** command to allow the MASP, and wait for the MASP to come to the in-service state.
 2. Re-enter the command to update the database.
-

E3951 Cmd Rej: Entry does not exist with specified GTIN-TT-NP(V)-NAI(V)-SSN

Commands Used: **chg-srvsel**, **dlt-srvsel**

You specified an entry that does not match an existing **gtin**, **tt**, **np(v)** and **nai(v)**, and **ssn** parameter combination as required.

Recovery

1. Display the service selectors. Enter the **rtrv-srvsel** command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E3954 Cmd Rej: NSNAI must be specified when NSERV = INPMR

Commands Used: **chg-srvsel**

You cannot specify the **nserv=inpmr** parameter without specifying the **nsnai** parameter.

Recovery

Perform one of the following actions:

- Re-enter the **chg-srvsel** command that generated this error message specifying the **nsnai** parameter.
- OR
- Re-enter the **chg-srvsel** command that generated this error message specifying another value for the **nserv** parameter.
-

E3955 Cmd Rej: Invalid combination of parameters for a partial routing key

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`,
`ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified parameters that do not define a full routing key, and the specified parameter combination is invalid for a partial routing key.

The following types of partial routing keys are supported:

- DPC-SI-OPC (ignore CIC) can be used as a partial match key for CIC-based traffic.
- DPC-SI (ignore all other fields) can be used as a partial match key for CIC-based traffic or SCCP traffic.
- DPC only (ignore all other fields) can be used as a partial match for any type of traffic.
- SI only (ignore all other fields) can be used as a partial match for any type of traffic.

Recovery

Re-enter the command specifying a valid combination of parameters for a partial routing key, or with parameters for a full routing key.

E3956 Cmd Rej: GFLEX and LNP are mutually exclusive

Commands Used: `chg-feat`, `enable-ctrl-feat`

You tried to turn on either the G-Flex or the LNP feature, but the other of the features is already turned on. These two features are mutually exclusive, so you can have either feature on, but not both.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the command **rtrv-feat** to determine the status of the G-Flex feature. Enter the command **rtrv-ctrl-feat** to determine the status the LNP feature.
 2. If both features are turned off (**gflex=off** and the LNP ported TNs entry does not appear in the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E3957 Cmd Rej: When type=partial or default, specify attributes

Commands Used: **chg-appl-rtkey**

You specified the routing key **type** specified as **partial** or **default**, and you did not enter the attributes parameters **rcontext**, **pstncat**, **pstnid**, or **norm**.

Recovery

Re-enter the command specifying the routing key **type** of **partial** or **default**, and include the attributes parameters **rcontext**, **pstncat**, **pstnid**, or **norm**.

E3958 Cmd Rej: When type=partial or default, SPLIT/RESIZE are not supported

Commands Used: **chg-appl-rtkey**

You specified the routing key **type** specified as **partial** or **default**, and you specified the **split** parameter in the command. The **split** parameter cannot be specified when **type=partial** or **type=default**.

Recovery

Re-enter the command without specifying the **split** parameter, or re-enter the command without specifying the **type** parameter (the default value is **type=full**) and with parameters for a full routing key.

E3959 Cmd Rej: Invalid combination of parameters for a default routing key

Commands Used: **chg-appl-rtkey**, **rtrv-appl-rtkey**

You specified the routing key **type** parameter as **default**, and you entered an invalid combination of parameters for a default routing key.

When **type=default** is specified:

- Only the **sname** parameter can be specified for the **rtrv-appl-rtkey** command.
- Only the **nsname** parameter or the attributes parameters **pstnid**, **pstncat**, and **norm** can be specified for the **chg-appl-rtkey** command.

Recovery

Re-enter the appropriate command specifying **type=default** and a valid combination of parameters for a default routing key.

E3960 Cmd Rej: When type=DEFAULT, other allowed parameters are SNAME/LOC

Commands Used: dlt-appl-rtkey

You specified the routing key type specified as default, and one or more parameters that were not **sname** or **loc**. When you specify **type=default**, the only other valid parameters are **sname** and **loc**.

Recovery

Re-enter the **dlt-appl-rtkey** command specifying **type=default** and the **sname** and the **loc** parameters to delete socket associations in the dynamic Routing Key table of a particular SS7IPGW or IPGWI card.

E3961 Cmd Rej: PVN and PVNMASK must be specified together

Commands Used: chg-netopts

You entered a command without specifying both the **pvn** parameter and the **pvnmask** parameter. Both parameters must be specified together in the command.

Recovery

Re-enter the **chg-netopts** command specifying IP addresses in both the **pvn** and **pvnmask** parameters.

E3962 Cmd Rej: PVN and PVNMASK must not be the same**Commands Used: chg-netopts**

You entered a command that specified or would result in the same IP address for the Private Virtual Network IP address and the Private Virtual Network submask IP address. The two addresses must not be the same in the system.

Recovery

1. Enter the **rtrv-netopts** command to display the PVN and PVNMASK IP addresses in the system. Verify the PVN and PVNMASK addresses that you specified in the command.
 2. Re-enter the **chg-netopts** command specifying two different addresses in the **pvn** and **pvnmask** parameters.
-

E3963 Cmd Rej: HMUXTVG must be ON before E5IS can be ON**Commands Used: chg-feat, chg-meas**

You entered a command to turn on the EAGLE 5 Integrated Monitoring Support feature (**chg-feat:e5is=on**). However, this command cannot be executed due to a possible error in the STP Options table.

Recovery

If you receive this message, call your Customer Care Center and report this error code and that the STP Options table appears to be in error.

E3964 Cmd Rej: TSCSYNC must be ON before E5IS can be ON**Commands Used: chg-feat**

You tried to turn on the EAGLE 5 Integrated Monitoring Support feature before the Time Slot Counter Synchronization (TSC) feature has been turned on. The TSC feature must be turned on before the E5IS feature can be turned on (or at the same time the E5IS feature is turned on, in the same command—**(chg-feat:e5is=on:tscsync=on)**).

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the **chg-feat** command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the command **rtrv-feat**.
 2. If the TSC feature is not **on**, turn it on. Enter the **chg-feat:tscsync=on** command.
 3. Re-enter the command **chg-feat:e5is=on** to turn on the E5IS feature.
-

E3965 Cmd Rej: Invalid PVN

Commands Used: **chg-netopts**

You entered a command that specified an invalid Private Virtual Network IP address in the **pvn** parameter.

Recovery

Re-enter the **chg-netopts** command specifying a valid Class B IP address for the **pvn** parameter.

Refer to the **chg-netopts** command description in the *Commands Manual*.

Contact your Customer Care Center if this error message appears again.

E3966 Cmd Rej: Max number of STC cards per shelf is entered

Commands Used: **ent-card**

You tried to add an STC card to a shelf for the EAGLE 5 Integrated Monitoring Support feature. The shelf already contains the maximum three STC cards.

Recovery

1. Display the cards on the shelf. Enter the **rtrv-card** command. The card type STC appears in the TYPE column for each STC card in the system. The card location appears in the CARD column; the first two digits of the location are the frame and shelf number where the card is installed.
2. If there are already three STC cards on the shelf, you cannot add another one to that shelf unless you remove one of the existing STC cards from the shelf.
3. If there are fewer than three STC cards on the shelf, re-enter the command to add the STC card to the shelf.

Contact your Customer Care Center if this error message appears again.

E3967 Cmd Rej: E5IS must be on

Commands Used: `chg-eisopts`, `chg-netopts`, `rtrv-eisopts`,
`rtrv-netopts`

You cannot enable, disable, or retrieve the current setting for the EAGLE 5 Integrated Monitoring Support copy function, if the E5IS feature has not been turned on in the system.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the command `rtrv-feat`.
 2. If the E5IS feature is off (`E5IS= off`), turn it on. Enter the `chg-feat:e5is=on` command. Refer to the *Commands Manual*.
 3. When the E5IS feature is turned on, re-enter the command to enable, disable, or retrieve the current setting for the E5IS copy function.
-

E3968 Cmd Rej: Invalid hardware for E5IS COPY to be on

Commands Used: `chg-eisopts`

You entered a command to enable the copy function for the EAGLE 5 Integrated Monitoring Support feature. The required hardware is not in the system for the command. The E5IS feature requires at least two STC cards in IS-NR state to be installed on at least one shelf in the system.

Recovery

1. Display the cards currently installed in the system. Enter the command `rtrv-card`. Locate any STC cards in the output.
 2. Enter the `rept-stat-card` command specifying the `loc` parameter for each STC card located in step 1. Verify that at least two STC cards are running the `eroute` application and are in the IS-NR state.
 3. If the required hardware is installed, re-enter the `chg-eisopts` command.
Call your Customer Care Center if this error message appears again.
-

E3979 Cmd Rej: Read NETOPTS table failed

Commands Used: `chg-eisopts`, `chg-netopts`, `rtrv-eisopts`,
`rtrv-netopts`

The NETOPTS table for the EAGLE 5 Integrated Monitoring Support feature must be accessible for the command to execute. A failure occurred while reading the NETOPTS table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E3986 Cmd Rej: LNP and GPORT features are mutually exclusive

Commands Used: `chg-feat`

You tried to turn on either the GSM mobile number portability (G-Port) feature or or the LNP ported TNs Quantity feature access key, but one of the two features is already turned on. These two features are mutually exclusive and, consequently, both cannot be turned on at the same time.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the command `rtrv-feat` to determine the status of the G-Port feature. Enter the command `rtrv-ctrl-feat` to determine the status the LNP feature.
 - If the G-Port feature is on (`gport=on`), you cannot turn on the LNP feature.
 - If the LNP ported TNs entry appears in the output of step 1, you cannot turn on the G-Port feature.
2. If neither of these two features are on, you can re-enter the `chg-feat` command to turn one of them on, but not both.

Contact your Customer Care Center if this error message appears again.

E3987 Cmd Rej: GTT must be ON before GPORT can be ON**Commands Used: chg-feat**

You tried to turn on the GSM Mobile Number Portability (G-Port) feature, but the Global Title Translation (GTT) feature is off. The GTT feature bit must be turned on before you can turn the G-Port feature bit on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the command `rtrv-feat` command.
 2. If the GTT feature is on (`gtt=on` from the output of step 1), turn the G-Port feature bit on. Enter the `chg-feat:gport=on` command.
Call your Customer Care Center if this error message appears again.
 3. If the GTT feature is off (`gtt=off` from the output of step 1), turn the GTT feature bit on. Enter the `chg-feat:gtt=on` command.
 4. Turn the G-Port feature bit on. Enter the `chg-feat:gport=on` command.
Call your Customer Care Center if this error message appears again.
-

E3988 Cmd Rej: GPORT feature requires DSM Cards**Commands Used: chg-feat**

You attempted to turn on the G-Port feature, but your hardware is inadequate and requires upgrading. The G-Port feature requires a DSM card running the VSCCP application.

Recovery

Re-enter the `chg-feat` command.

Call your Customer Care Center if this error message appears again.

E3989 Cmd Rej: GPORT feature must be on when (N)SERV=GPORT**Commands Used: chg-srvsel, ent-srvsel, rtrv-srvsel**

The G-Port feature bit must be turned on before you can specify `nserv=gport`.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the command `rtrv-feat`.
 2. If the G-Port feature bit is turned on (`gport=on`) from the output of step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
 3. If the G-Port feature bit is off (`gport=off`) from the output of step 1), enter the command `chg-feat:gport=on` to turn the G-Port feature bit on.
 4. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E3990 Cmd Rej: (N)SNP must be E164 when (N)SERV=GPORT/PPSMS/MNPSMS

Commands Used: `chg-srvsel`, `ent-srvsel`

You specified a value other than `nsnp/snp=e164` with the `nserv=gport`, `ppsms`, or `mnpsms` parameter. If you specify `nserv=gport`, `ppsms`, or `mnpsms`, you must specify a value of `e164` for the `nsnp/snp` parameter.

Recovery

Re-enter the command specifying `nsnp/snp=164`.

E3991 Cmd Rej: GPORT feature must be on

Commands Used: `chg-feat`, `chg-gsmopts`, `chg-prefix`,
`enable-ctrl-feat`

The G-Port feature bit must be turned on prior to issuing this command.
Specifically:

- **chg-gsmopts** - the G-Port feature bit must be turned on before specifying the `defmapvr`, `is412gsm`, `mrsndig`, `mrsnnai`, `mrsnnp`, `srfaddr`, `srfnai`, `srfnp`, `sridn`, or `srverpfx` parameters. The G-Port feature bit and the Prepaid Short Message Service (PPSMS) Phase 1 feature bit must be turned on before you can specify the `ppsmsgta`, `nppsmsgta`, `ppmspci1`, `ppmspci2`, `ppmspcn1`, `ppmspcn2`, `ppmsri1`, and `ppmsri2` parameters.
- **chg-feat** - the G-Port feature bit must be turned on before entering the command to turn on the PPSMS Phase 1 feature bit or the G-Port MNP Circular Route Prevention (MNPCR) feature bit or the Portability Check for Mobile Originated SMS or the GSM MAP SRI Redirect feature or the ISUP NP with EPAP feature.
- **chg-prefix** - the G-Port feature bit must be turned on before provisioning a prefix for the GSM MAP SRI Redirect feature.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled feature access keys that are designated as On/Off features can be turned on and off using the `chg-ctrl-feat` command. Refer to the appropriate *Feature Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with feature access keys.

Recovery

1. Display the features in the database. Enter the commands `rtrv-feat` and `rtrv-ctrl-feat`.
2. If the G-Port feature is turned on, re-enter the command that generated this error message.
3. If the G-Port feature is turned off, perform the following actions:
 - Verify that you have purchased and installed the correct features for your system. Contact your Customer Care Center if you need assistance.
 - If the feature(s) were purchased and are installed on your system, enter the command `chg-feat:gport=on` to turn the G-Port feature on.
 - Use the `enable-ctrl-feat` command to enable the PPSMS Phase 1 feature, G-Port MNP Circular Route Prevention feature, or Portability Check for Mobile Originated SMS or the GSM MAP SRI Redirect feature

or the ISUP NP with EPAP feature. Refer to the *Commands Manual* and *Feature Manual -- G-Port Manual* for additional details.

- Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3992 Cmd Rej: SRFADDR, SRFNAI & SRFNP parameters must be entered together

Commands Used: `chg-gsmopts`

You entered one or two of the following parameters: `srfaddr`, `srfnai`, or `srfnp`. You must specify all three parameters.

Recovery

Re-enter the command specifying all three parameters: `srfaddr`, `srfnaiand` `srfnp`.

E3993 Cmd Rej: GTIA/GTI must not be specified when (N)SERV= GPORT

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

You cannot specify the `gtia` parameter or `gti` parameter when `nserv=gport`.

Recovery

Re-enter the command specifying the `gtii` or `gtin` parameter and the `nserv=gport` parameter.

E3994 Cmd Rej: (N)SERV must be GPORT/SMSMR/MNPSMS when (N)SNAI=CCRNDN

Commands Used: `chg-srvsel`, `ent-srvsel`, `rtrv-srvsel`

You specified a value other than `ccrndn` for the `nsnai/snai` parameter, and you specified the `nserv/serv=gport`, `ppsms`, `mnpsms`, or `eir` parameter. When you specify the `nserv/serv=gport`, `ppsms`, `mnpsms`, or `eir` parameter, you must specify the `nsnai/snai=ccrndn` parameter.

Recovery

Re-enter the command that generated this error, specifying **gport**, **ppsms**, **mnpms**, or **eir** for the **nserv/serv** parameter and **crndn** for the **nsnai/snai** parameter.

E3995 Cmd Rej: MSRNNAI and MSRNNP parameters must be entered together

Commands Used: **chg-gsmopts**

You entered one of the following parameters: **msrnnai** or **msrnnp**. If you specify one of the above parameters, you must specify both.

Recovery

Re-enter the command specifying both the **msrnnai** and **msrnnp** parameters.

E3997 Cmd Rej: GFLEX or GPORT feature must be on or EIR feature must be enabled

Commands Used: **rtrv-gsmopts**

The command you entered is invalid unless one of the following conditions is true:

- the G-Flex feature is on, or
- the G-Port feature is on, or
- the EIR feature is enabled.

Specifically, for the **rtrv-gsmopts** command;

- The G-Flex feature must be turned on before specifying the **ccnc**, **defmcc**, **defmnc**, or **mccmnc** parameters.
- The G-Port feature must be turned on before specifying the **defmapvr**, **mrsndig**, **mrsnnai**, **mrsnnp**, **srfaddr**, **srfnai**, or **srfnp** parameters.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** and the **rtrv-ctrl-feat** commands.
2. If the G-Flex or G-Port feature is turned **on** (**gflex=on** or **gport=on**) or the EIR feature is enabled, re-enter the **rtrv-gsmopts** command.

Call your Customer Care Center if this error message appears again.

3. If the G-Flex or G-Port feature is **off** (**gflex=off** or **gport=off**) and the EIR feature is not enabled, you can either:
 - Turn on the G-Port or G-Flex features. Enter the **chg-feat:gflex=on** or **chg-feat:gport=on** command.

OR

- Enable the EIR feature with the **enable-ctrl-feat** command.

Refer to the EIR Feature activation in the *Feature Manual - EIR* and the *Commands Manual* call your Customer Care Center before starting the process.

THEN

- Re-enter the **rtrv-gsmopts** command that generated this error message.

Call your Customer Care Center if this error message appears again.

E3998 Cmd Rej: NSNAI = NONE only allowed when NSERV = INPQ

Commands Used: **chg-srvsel**

If you specify the **nsnai=none** parameter, you must specify the **nserv=inpq** parameter.

Recovery

Re-enter the **chg-srvsel** command specifying both the **nsnai=none** and **nserv=inpq** parameters.

E3999 Cmd Rej: When type=full, DPC and SI must be specified

Commands Used: **chg-appl-rtkey**, **dlt-appl-rtkey**, **ent-appl-rtkey**

If you specify a value of **full** for the routing key **type** parameter (**type=full**), you must also specify either the destination point code (**dpc**) parameter and/or the system indicator (**si**) parameter.

Recovery

Re-enter the command specifying either the **dpc** and/or the **si** parameters.

E4001 Cmd Rej: Group Code of DPCN and OPCN must match

Commands Used: `ent-app1-rtkey`

The group codes for the `dpcn` and `opcn` parameter values must match when you specify both parameters in the command.

A two-letter group code is required for ITU-N point codes and spare point codes (DPCN/OPCN) when the ITU Duplicate Point Code feature (ITUDUPPC) is turned on, and not allowed when the feature is off.

Recovery

Re-enter the `ent-app1-rtkey` command specifying the same group codes for the `dpcn` and `opcn` parameter values.

E4002 Cmd Rej: PSTNCAT=0 requires PSTNID=0

Commands Used: `chg-app1-rtkey`

You cannot specify a value of `0` for the Public Switched Telephone Network (PSTN) Category (`pstncat=0`) and a value other than `0` for the `pstnid` parameter. The parameter value `pstncat=0` requires the parameter value `pstnid=0`.

Recovery

Re-enter the `chg-app1-rtkey` command specifying both the `pstncat=0` and the `pstnid=0` parameters.

E4003 Cmd Rej: MULTGC=YES requires IPGWI or IPLIMI links

Commands Used: `chg-ls`, `ent-slk`

If you specify that multiple group codes are allowed to be carried across IPGWI and IPLIMI linksets (`multgc=yes`), you must also specify a IPGWI or IPLIMI links.

If the linkset name (`lsn`) parameter is specified and multiple group codes are allowed (`multgc=yes`), all links assigned to the linkset must be of the same type (IPGWI or IPLIMI).

Recovery

Re-enter the command specifying `multgc=yes` and a IPGWI or IPLIMI links.

E4004 Cmd Rej: PSTNCAT=1 requires ITU-I or ITU-N point code

Commands Used: `chg-appl-rtkey`

If you specify a value of **1** for the Public Switched Telephone Network (PSTN) Category parameter (`pstncat=1`), you must specify an ITU-I or ITU-N point code.

The parameter value `pstncat=1` can be used only with routing keys that specify ITU-N or ITU-I point codes. The `pstnid` parameter values used with `pstncat=1` must meet specific SI value criteria.

Refer to the `chg-appl-rtkey` description in the *Commands Manual* for valid parameter values when `pstncat=1` is specified in the command.

Recovery

Re-enter the `chg-appl-rtkey` command specifying the `pstncat=1` parameter and an ITU-I or ITU-N point code.

E4005 Cmd Rej: Either INP or GPORT feature must be ON

Commands Used: `chg-measopts`, `dlt-homern`, `ent-homern`,
`rept-ftp-meas`, `rept-meas`, `rtrv-homern`

Table 2-36 lists by command the conditions that generate an E4005 error message.

Table 2-36. Conditions that Generate an E4005 Error Message

Commands	Condition
<code>dlt-homern</code> <code>ent-homern</code> <code>rtrv-homern</code>	You entered the command, but the INP or G-Port feature is turned off as required.
<code>chg-measopts</code> <code>rept-ftp-meas</code> <code>rept-meas</code>	You specified the <code>enttype=np:type=mtch</code> parameters. To specify this parameter combination, the INP or G-Port feature must be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command.

2. If the INP or G-Port feature is on (from the output of step 1),
 - Re-enter the command that generated this message.
Call your Customer Care Center if this error message appears again.
 3. If the INP or G-Port feature is off (from the output of step 1),
 - Verify that the INP or G-Port feature is purchased and installed in the system. Contact your Customer Care Center for assistance.
NOTE: Refer to the INP or G-Port feature activation procedure in the *Feature Manual - G-Port* or *Feature Manual - INP* and the *Commands Manual* for additional information before proceeding.
 - Enable the INP or G-Port feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information. Turn on the INP or G-Port feature, enter the **chg-ctrl-feat** command.
 - Re-enter the command that generated this message.
Call your Customer Care Center if this error message appears again.
-

E4006 Cmd Rej: DSM's are required when LNP and VGTT are ON

Commands Used: `chg-feat`, `enable-ctrl-feat`

You tried to turn on the variable length GTT (VGTT) feature or the LNP Feature, and one of these features is already turned on your system. To use both of these features requires DSM cards running the VSCCP application.

Recovery

1. Upgrade your hardware to ensure that you have only DSM cards (no TSMs) on your system.
 2. Re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E4007 Cmd Rej: Ten GTA Lengths are supported per TT

Commands Used: `ent-gtt`

You cannot provision more than **10** GTA lengths per translation type. If the variable length GTT (VGTT) feature is turned on, you can provision up to a maximum of **10** GTA lengths per translation type.

Recovery

1. Display all GTAs for the specified translation type. Enter the **rtrv-gtt** command.
 2. Delete all of the GTAs of a particular length. Enter the **dlt-gtt** command. When the last address of a particular length is deleted, that length no longer counts toward the **10** lengths supported per translation type.
 3. Re-enter the **ent-gtt** command that generated this error message.
-

E4008 Cmd Rej: Ten GTA Lengths are supported per GTTSET

Commands Used: **ent-gta**

If the variable length GTT (VGTT) feature is turned on, you cannot provision more than **10** GTA lengths per GTT set. When the **ent-gta** command is entered to create entries, the software keeps track of the lengths and allows only **10** different lengths. You attempted to add an entry that would have exceeded this maximum.

Recovery

1. Display all GTAs for the specified GTT set. Enter the **rtrv-gta** command.
 2. Delete all of the GTAs of a particular length. Enter the **dlt-gtt** command. When the last address of a particular length is deleted, that length no longer counts toward the **10** lengths supported per GTT set.
 3. Re-enter the **ent-gta** command.
-

E4009 Cmd Rej: GTA length is not defined for TT

Commands Used: **chg-gtt, dlt-gtt, rtrv-gtt**

You attempted to change, delete, or retrieve a GTA length that has not been defined for the specified translation type.

Recovery

1. Display all of the GTA lengths for the translation type. Enter the **rtrv-tt** command.
 2. Re-enter the command that generated this error message specifying an existing GTA length.
-

E4010 Cmd Rej: GTA length is not defined for GTTSET

Commands Used: `chg-gta`, `dlt-gta`, `rtrv-gta`

You cannot change, delete, or retrieve a GTA length that has not been defined for the specified GTT set.

Recovery

1. Display all of the GTA lengths for the translation type. Enter the `rtrv-gta` command.
 2. Re-enter the command that generated this error message specifying an existing GTA length.
-

E4011 Cmd Rej: NDGT parameter is invalid for VGTT

Commands Used: `chg-gttset`, `ent-gttset`, `ent-tt`

You cannot specify the number of digits (`ndgt`) parameter if the Variable length GTT (VGTT) feature is turned on.

Recovery

Perform one of the following actions:

- Re-enter the command without specifying the `ndgt` parameter.
- OR
- Enter the `ent-gta` or `ent-gtt` command to provision up to **10** different GTA lengths per GTT set.
-

E4012 Cmd Rej: Invalid PVNMASK

Commands Used: `chg-netopts`

The IP address specified by the Private Virtual Network subnet mask (`pvnmask`) parameter is invalid. The value must be valid for a Class B network IP address as shown in Table 2-37.

Table 2-37. Valid PVN Subnet Mask Values

Valid for Class B Networks	
255.255.0.0	255.255.248.0
255.255.192.0	255.255.252.0
255.255.224.0	255.255.254.0
255.255.240.0	255.255.255.128

Recovery

Re-enter the **chg-netopts** command specifying a valid **pvnmask** parameter value.

E4013 Cmd Rej: T1 Port test command not in progress**Commands Used: tst-t1**

There is no active test in progress on this t1port. The parameter **action=stop** cannot be performed if there is no active port test.

Recovery

Re-enter the **tst-t1** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **tst-t1** command.

E4014 Cmd Rej: CGSR must be specified when CDSR is specified**Commands Used: rtrv-gsmmap-scrn**

For the **rtrv-gsmmap-scrn** command, if you specify the **cdsr** parameter, you must also specify the **cgsr** parameter.

Recovery

Re-enter the **rtrv-gsmmap-scrn** command specifying both the **cdsr** and the **cgsr** parameters.

E4015 Cmd Rej: CGSR or CDSR shouldn't be specified when SADDR is specified

Commands Used: `rtrv-gsmmap-scrn`

For the `rtrv-gsmmap-scrn` command, if you specify the `saddr` parameter, the `cgsr` or `cdsr` parameters cannot be specified.

Recovery

Re-enter the `rtrv-gsmmap-scrn` command specifying the `saddr` parameter, without specifying the `cgsr` or `cdsr` parameters.

E4016 Cmd Rej: SADDR, NPV and NAIV must be specified together

Commands Used: `rtrv-gsmmap-scrn`

For the `rtrv-gsmmap-scrn` command, the `saddr`, `npv`, and `naiv` parameters must be specified together.

Recovery

Re-enter the `rtrv-gsmmap-scrn` command specifying the `saddr`, `npv`, and `naiv` parameters together.

E4017 Cmd Rej: ACTION or FORBID parameter shouldn't be specified

Commands Used: `rtrv-gsmmap-scrn`

When any of the `saddr`/`eaddr`/`npv`/`naiv` and `cdsr` parameters are specified, the `forbid` and `action` parameters cannot be specified.

You cannot specify the `action` or `forbid` parameters whenever any of the following are specified:

- The combination of `saddr` (with or without `eaddr`), `npv`, and `naiv` parameters.
- OR
- The `cdsr` parameter.

Recovery

Perform one of the following actions:

- Re-enter the **rtrv-gsmmap-scrn** command without specifying the **action** or **forbid** parameters
- OR
- Re-enter the **rtrv-gsmmap-scrn** command specifying the **action** or **forbid** parameters, but do not include either the **cdsr** parameter or the combination of **saddr** (with or without **eaddr**), **npv**, and **naiv** parameters.
-

E4019 Cmd Rej: OPCODE and OPNAME shouldn't be specified together

Commands Used: **rtrv-gsms-opcode**

You cannot specify the MAP Op-code Number (**opcode**) and User-defined Name for Op-code (**opname**) together in this same command. These two parameters are mutually exclusive.

Recovery

Re-enter the **rtrv-gsms-opcode** command specifying either the **opcode** or the **opname** parameter, but not both.

E4024 Cmd Rej: SRCSET and SET cannot be equal

Commands Used: **chg-uaps**

Your attempt to change the UAPS parameter set was unsuccessful because the specified set number and source set parameters were identical. The **set** parameter and the **srcset** parameter cannot be the same value.

Recovery

Review the **set** and **srcset** parameters, and change the specification of the appropriate one. Re-enter the **chg-uaps** command specifying the correct parameter values.

E4026 Cmd Rej: STP options HMUXABUS or HMUXBBUS must be set=yes

Commands Used: `clr-imt-stats`, `rept-imt-info`, `init-mux`

The command you entered cannot be executed due to a possible error in the STP Options table.

Recovery

Call your Customer Care Center and report you received error message E4026, and that the STP Options table appears to be in error.

E4027 Cmd Rej: S/ESHELF can only be entered, when report = hmutexerr is set

Commands Used: `rept-int-info`

You cannot specify the `sshelf`, `eshelf`, or both parameters for a command used for HMUX cards without specifying `report=hmutexerr`.

Recovery

Re-enter the `rept-int-info` command specifying the `sshelf` and/or `eshelf` parameters and `report=hmutexerr`.

E4032 Cmd Rej: Either BUS or Location (not both) must be specified

Commands Used: `init-mux`

The `bus` or `loc` parameter must also be specified.

Recovery

Re-enter the `init-mux` command specifying either the `bus` or `loc` parameter, but not both.

E4033 Cmd Rej: If GTIXLAT is 22, NAI and NP cannot be specified

Commands Used: `ent-gtcnv`

If you specify a value of **22** for the ANSI Global Title Indicator (`gtixlat=22`), the Nature of Address Indicator (`nai`) and Numbering Plan (`np`) parameters cannot be specified.

Recovery

Perform one of the following actions:

- Re-enter the **ent-gtcnv** command specifying the (**nai**) and (**np**) parameters, and a value other than 22 for the (**gtixlat**) parameter.
- OR
- Re-enter the **ent-gtcnv** command specifying **gtixlat=22** without specifying the **nai** and **np** parameters.
-

E4034 Cmd Rej: If GTIXLAT is 24, NAI and NP must be specified

Commands Used: **ent-gtcnv**

If you specify a value of **24** for the ITU Global Title Indicator (**gtixlat=24**), the Nature of Address Indicator (**nai**) and Numbering Plan (**np**) parameters must also be specified.

Recovery

Perform one of the following actions:

- Re-enter the **ent-gtcnv** command specifying **gtixlat=24** and the **nai** and **np** parameters.
- OR
- Re-enter the **ent-gtcnv** command specifying a value other than **24** for the (**gtixlat**) parameter.
-

E4035 Cmd Rej: TTA must be specified for a direction of ATOI

Commands Used: **chg-gtcnv**, **dlt-gtcnv**

If you specify that the direction of conversion is ANSI-to-ITU (**dir=atoi**), the ANSI translation type (**tta**) parameter must be specified.

Recovery

Re-enter the command specifying **dir=atoi** and the **tta** parameter. i.e.,
chg-gtcnv:dir=atoi:tta=xxx

E4036 Cmd Rej: At least TTA, TTI must be specified for a direction of BOTH

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

If you specify that the direction of conversion is BOTH (**dir=both**), the ANSI translation type (**tta**) and the ITU translation type (**tti**) parameters must also be specified.

Recovery

Re-enter the command specifying **dir=both** and the **tta** and **tti** parameters. i.e.,
chg-gtcnv:dir=both:tta=xxx:tti=yyy

E4037 Cmd Rej: Error in FEATCTRL.TBL date, maintenance required

Commands Used: `enable-ctrl-feat`

The contents of the FEATCTRL.TBL is in violation of its stable condition rules. The table content requires maintenance.

Recovery

Perform maintenance on the FEATCTRL database table. We recommend that a database backup be performed after every successful `enable-ctrl-feat` command.

E4038 Cmd Rej: NORM=YES not supported for specified PSTNCAT/PSTNID values

Commands Used: `chg-appl-rtkey`

If you specify **yes** for the **norm** parameter (**norm=yes**), you must specify a value of **1** for the **pstncat** parameter value. The **pstnid** parameter value can be either **1**, **2**, **3**, or **4**. The parameter value **norm=yes** can be entered if **pstncat=1** and the **pstnid** parameter value is indicated by "*" in Table 2-38. The parameter value **pstncat=1** may be used only with keys that specify ITU-N or ITU-I point codes.

Refer to the `chg-appl-rtkey` command description in the *Commands Manual* for more information about the key attributes parameters.

Table 2-38. Routing Keys and Supported PSTN Categories and PSTN IDs for PSTN Category 1

Routing Key Entry Type	SI	PC Type	norm=yes is valid	pstnid for pstncat = 1			
				1=ITU Q.767	2=ETSI V3	3=UK PNO-ISC7	4=GERMAN ISUP
Full-CIC and Partial DPC/OPC/SI	5	ANSI					
		ITU-I/N	*	*	*	*	*
	4 or 13	ALL					
Full-SCCP	3		ALL				
Full-DPC/SI	ALL	ALL					
Partial DPC/SI	5	ANSI					
		ITU-I/N	*	*	*	*	*
	Other than 5						
Partial DPC	N/A	ALL					
Partial SI	ALL	N/A					
Default	N/A	N/A					

Recovery

Perform one of the following actions:

- Re-enter the **chg-appl-rtkey** command specifying **norm=yes**, **pstncat=1**, and a valid **pstnid** parameter value (1, 2, 3, or 4).
- OR
- Re-enter the **chg-appl-rtkey** command specifying the correct **pstncat** and **pstnid** parameter values and **norm=no**.
-

E4039 Cmd Rej: MULTGC=YES not allowed if ITUDUPPC feature is OFF

Commands Used: `chg-ls`, `ent-ls`

You cannot specify a value of yes for the Multiple Group Codes Allowed (**multgc=yes**) parameter if the International National Duplicate Point Code (ITUDUPPC) feature is turned off. Multiple group codes are not supported if the ITUDUPPC feature is turned off.

Recovery

1. Verify that the ITUDUPPC feature is turned off. Enter the **rtrv-feat** command.
 2. Re-enter the command without specifying a value of yes for the multiple group code (**multgc**) parameter.
-

E4040 Cmd Rej: Invalid combination of PSTNCAT and PSTNID values

Commands Used: `chg-appl-rtkey`, `chg-isupvar-attrib`,
`copy-isupvar-attrib`, `rtrv-isupvar-attrib`

You specified an invalid combination of **pstncat** and **pstnid** parameter values.

Refer to the command description in the *Commands Manual* for information about valid **pstncat** and **pstnid** parameter combinations.

Recovery

Re-enter the command specifying a valid combination of **pstncat** and **pstnid** parameter values.

E4041 Cmd Rej: Cannot change routing key and attribute values

Commands Used: `chg-appl-rtkey`

You entered a command that specified values for both routing key parameters and routing key attribute parameters.

The key attribute parameters (**pstncat**, **pstnid**, and **norm**) are not valid with routing key parameters **ncics**, **ncice**, **split**, **nsname**, or **nasname**.

Recovery

Re-enter the command and specify only valid routing key parameters or only valid key attribute parameters.

E4042 Cmd Rej: ISUP Normalization feature must be enabled to set NORM=YES

Commands Used: `chg-app1-rtkey`

This feature requires the ISUP Normalization ON/OFF controlled feature as well as a separate ON/OFF controlled feature for each ISUP variant that can be normalized.

Recovery

You must first purchase the ISUP Normalization feature, then enable using the `enable-ctrl-feat` command.

E4044 Cmd Rej: Only two E1 ports allowed for Linkclass equals unchan

Commands Used: `ent-e1`, `chg-e1`

A maximum of two E1 ports (any two) of the 8 ports on the SE-HSL card can be used to define E1 interfaces. You attempted to define a third E1 interface. The E1 port is specified using the `e1port` parameter.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4045 Cmd Rej: Linkset with MULTGC=YES requires IPGWI/IPLIMI GPL

Commands Used: `ent-slk`

The card application must be IPGWI or IPLIMI if the LSN references a link set that specifies `multgc=yes`.

When the linkset name (`lsn`) parameter is specified and multiple group codes are allowed (`multgc=yes`), the card in the specified card location must be running either the `ipgwi` or the `iplimi` card application.

Recovery

Re-enter the **ent-slk** command and reference a link set with a card application of **ipgwi** or **iplimi**.

E4046 Cmd Rej: E1 is assigned to card**Commands Used: dlt-card**

Before you can delete a 2-port E1 card or an E1/T1 MIM card that is being used as an E1 card (card type **lime1** that has an E1 interface associated with it), you must first delete all E1 interfaces associated with the card.

Recovery

1. Display a list of signaling links assigned to the E1 card. Enter the **rtrv-slk** command.
 2. Deactivate all signaling links assigned to the E1 card. Enter the **dact-slk** command for each link.
 3. Delete all signaling links assigned to the E1 card. Enter the **dlt-slk** command for each link.
 4. Display the E1 interfaces associated with the E1 cards. Enter the **rtrv-e1** command.
 5. Delete all E1 interfaces associated with the E1 card. Enter the **dlt-e1** command.
 6. Delete the E1 card. Re-enter the **dlt-card** command.
-

E4047 Cmd Rej: Signaling link is not provisioned for the card**Commands Used: alw-card**

You cannot allow a 2-port E1 card or Channel card or an E1/T1 MIM card used as an E1 card, T1 card, or Channel card (card type **lime1**, **limt1**, or **limch**) that has no signaling links associated with it. At least one signaling link must be associated with the card before the card can be allowed.

Recovery

1. Associate at least one signaling link with the card. Enter the **ent-slk** command.

Refer to the *Commands Manual* for detailed information about the use of the **ent-slk** command.

2. Allow the card. Re-enter the **alw-card** command.
-

E4048 Cmd Rej: All signaling links serviced by the E1 must be deactivated

Commands Used: **chg-e1**, **inh-card**

You entered a command that requires all signaling links assigned to the specified E1 card to be deactivated before the command can execute.

You cannot change the value of one or more of the following parameters before you deactivate all of the signaling links serviced by the specified E1 card: **crc4**, **cas**, **encode**, or **e1tsel**.

You cannot inhibit an E1 card or an E1/T1 MIM card used as an E1 card until you deactivate all signaling links that provide timeslots serviced by the E1 interfaces assigned to that card.

Recovery

1. Deactivate all signaling links with timeslots that are serviced by the specified E1 card. Enter the **dact-slk** command.
 2. Re-enter the command to change the specified parameter value or inhibit the card.
-

E4049 Cmd Rej: Card type of LIMCH does not support E1PORT = 2

Commands Used: **ent-slk**

You cannot assign a timeslot for a Channel card and assigned e1port 2 as the E1 interface on the E1 card or E1/T1 MIM card used as an E1 card to service the timeslot. E1 interfaces that service timeslots for Channel cards can only be assigned to the e1port 1 of the E1 card.

Recovery

Re-enter the **ent-slk** command and specify **e1port=1** for the E1 card with the appropriate E1 interface to service the timeslot for the Channel card.

E4050 Cmd Rej: E1PORT specified by E1LOC is not equipped**Commands Used: ent-slk**

The E1 interface for the e1port specified by the **e1port** parameter on an E1 card or, E1/T1 MIM card being used as an E1 card specified by the **e1loc** parameter, is not defined in the database.

Recovery

1. Display the E1 port and card location information. Enter the **rtrv-e1** command. Verify that the **e1loc** parameter specifies the correct card location.
2. Verify that the e1loc parameter specifies the correct card location.
 - If the E1 interface is defined for the specified e1port on the E1 card at the specified location, re-enter the **ent-slk** command specifying the correct card location (e1loc) and e1port (e1port).
 - If the E1 interface has not been defined for the specified port on the E1 card at the specified location, perform the following actions:
 - Define the E1 attributes for the specified e1port on the E1 card in the location specified by the e1loc parameter. Enter the ent-e1 command.
 - Re-enter the ent-slk command and specify the defined e1port.

Contact your Customer Care Center if this error message appears again.

E4051 Cmd Rej: TS value on the E1 already in use by a signaling link**Commands Used: ent-slk**

The timeslot that you specified in the command is already assigned to a signaling link on the E1 card or E1/T1 MIM card being used as an E1 card and E1 interface specified in the **e1loc** and **e1port** parameters.

Recovery

1. Display the E1 port, card location, and timeslot information. Enter the **rtrv-e1** command.
 2. Re-enter the **ent-slk** command specifying an available timeslot for the E1 card and interface specified in the **e1port** and **e1loc** parameters.
-

E4052 Cmd Rej: E1 specified by E1LOC/E1PORT is using CAS, TS=16 not allowed**Commands Used: ent-s1k**

You specified a timeslot value of **16** for an E1 interface that has Channel Associated Signaling (CAS) enabled. When CAS is enabled for an E1 interface, you cannot assign timeslot **16** to that E1 interface.

Recovery

1. Display the E1 port, card location, and timeslot information. Enter the **rtrv-e1** command.
 2. Re-enter the **ent-s1k** command specifying an available timeslot other than **16** for the E1 interface and card specified by the **e1port** and **e1loc** parameters.
-

E4054 Cmd Rej: The E1PORT at the specified location is already equipped**Commands Used: ent-e1**

You cannot add an E1 interface to the database if the e1port on the E1 card (**e1port** = **1** or **2**) already has an E1 interface defined on that E1 card in the specified location.

Recovery

1. Display the E1 port and card location information. Enter the **rtrv-e1** command.
 2. Perform one of the following actions:
 - If an e1port is available at the specified location, re-enter the **ent-e1** command specifying the available e1port.
 - OR
 - If no e1port is available at the specified card location, re-enter the **ent-e1** command specifying an available E1 card location and port number.
-

E4055 Cmd Rej: The E1PORT at the specified location is not equipped**Commands Used: chg-e1, dlt-e1, rtrv-e1, ent-s1k**

You cannot change, delete, or retrieve information for an E1 interface on an E1 card that has not been defined by the **e1port** and **loc** parameters.

Recovery chg-e1, dlt-e1, rtrv-e1

1. Display all **e1port** and **loc** parameter information. Enter the **rtrv-e1** command specifying no parameters. Verify that you specified the correct **e1port** and **loc** parameters.
 2. If the specified **e1port** or **loc** are incorrect, re-enter the command specifying the correct **e1port** and **loc** parameters.
 3. If the specified **e1port** or **loc** was correct, re-enter the command.
Call your Customer Care Center if this error message appears again.
-

Recovery ent-slk

1. Display all E1 port and E1 card location information. Enter the **rtrv-e1** command specifying no parameters. Verify that you specified the correct **e1port** parameter and the correct E1 card location (**loc**) parameter for the command.
 2. If the specified E1 card location (**loc**) is correct but not listed, you must equip the specified card location with an appropriate card.
 3. Re-enter the **ent-slk** command.
Call your Customer Care Center if this error message appears again.
-

E4056 Cmd Rej: Timeslot 16 on the E1 is in use, CAS = ON not allowed**Commands Used: chg-e1**

You cannot change from Common Channel Signaling (CCS) to Channel Associated Signaling (CAS) multi-framing for the E1 interface on the specified E1 port and card. CAS cannot be enabled because timeslot **16** is being used by the E1 interface.

Recovery

1. Display the E1 port, card location, and timeslot information. Enter the **rtrv-e1** command.

2. If you need to correct any part of the command information, re-enter the **chg-e1** command specifying the correct information.
 3. If you need to change the **cas** parameter value, you must first delete timeslot **16** from the E1 interface before you enter the command again.
 - Display the signaling link information for the E1 card, including the timeslot used by each link. Enter the **rtrv-slk** command.
 - Delete the signaling link that has timeslot **16** assigned. Enter the **dlt-slk** command.
 - Add a new signaling link for the E1 interface with a timeslot other than **16**. Enter the **ent-slk** command.
 - Re-enter the **chg-e1** command specifying **cas=on**.
-

E4057 Cmd Rej: All signaling links serviced by this E1/T1 must be deleted

Commands Used: **dlt-e1**, **dlt-t1**

You entered a command to delete an E1 interface or a T1 interface before you deleted all signaling links that are serviced by that E1 interface or T1 interface.

Recovery

1. Display the signaling links assigned to the E1 or T1 interface. Enter the **rtrv-slk** command.
 2. If the links have not already been deactivated, deactivate all of the signaling links assigned to the E1 or T1 interface. Enter the **dact-slk** command.
 3. Delete all of the signaling links assigned to the E1 or T1 interface. Enter the **dlt-slk** command.
 4. Delete the E1 or T1 interface. Re-enter the **dlt-e1** or **dlt-t1** command.
-

E4058 Cmd Rej: The Channel card must be on the same shelf as its E1 card.

Commands Used: **ent-slk**

You entered a command to assign a signaling link with a timeslot to a Channel card. The E1 interface that would service the timeslot is not on an E1 card (**e1loc**, **e1port** parameters) on the same shelf with the Channel card (**loc**) parameter.

Recovery

Re-enter the **ent-slk** command specifying an E1 interface on an E1 card that is on the same shelf with the Channel card.

E4059 Cmd Rej: Failed reading the E1/T1 table

Commands Used: **chg-e1, chg-t1, dlt-card, dlt-e1, dlt-t1, ent-e1, ent-slk, ent-t1, rtrv-e1, rtrv-t1**

The E1/T1 table must be accessible for the command to execute. A failure occurred while reading the E1/T1 table.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E4060 Cmd Rej: MULTGC=YES requires ITU-N or ITU-I point code

Commands Used: **chg-ls, ent-ls**

You must specify an ITU-N or ITU-I point code if **multgc=yes** is specified.

Recovery

Re-enter the command specifying **multgc=yes** and either a ITU-N or ITU-I point code.

E4061 Cmd Rej: Group Code of DPC(s) and APC/SAPC must match when MULTGC=NO

Commands Used: **chg-ls**

The group codes for the DPC(s) and APC/SAPC must match when entering this command specifying **multgc=no**. MULTGC can only be changed to NO if there are no routes with group codes different than the ADJPC's group code. If the ADJPC's group code is changed, MULTGC must be YES or there must be no routes using the linkset.

Recovery

Enter the **chg-1s** command to update **apc/sapc** group code.

E4062 Cmd Rej: Inhibit IPSM card(s) before changing feature status

Commands Used: chg-ctrl-feat

Before you can use this command to change the feature status of the EAGLE 5 ISS OA&M IP Security feature (either turning on or turning off), you must first inhibit all IPSM cards in the system.

Recovery

1. Determine which Telnet terminals are on the IPSM card(s). Enter the **rtrv-trm** command.
 2. Inhibit all Telnet terminals if the Telnet feature is on. Enter the **inh-trm** command.
 3. Inhibit all IPSM cards in the system. Enter the **inh-card** command.
 4. Turn the Eagle OA&M IP Security feature on or off. Re-enter the **chg-ctrl-feat** command.
 5. Allow all IPSM cards in the system. Enter the **alw-card** command.
 6. Allow all Telnet terminals. Enter the **alw-trm** command.
- Call your Customer Care Center if this error message appears again.
-

E4063 Cmd Rej: GTI/GTIA/GTII/GTIN not within specified range of 1 to 4

Commands Used: chg-gttset, chg-srvset, dlt-gttset, dlt-srvset, ent-gttset, ent-srvset, rtrv-gttset, rtrv-srvset

You cannot specify a value for the **gti**, **gtia**, **gtii**, or **gtin** parameter that is outside the range of 1 to 4. Supported values for ANSI are **gti=2** and **gtia=2**. Supported values for ITU are **gtii=2, 4** and **gtin=2, 4**.

Recovery

Re-enter the command specifying a valid value for the **gti**, **gtia**, **gtii**, or **gtin** parameter.

E4064 Cmd Rej: Host Name Referenced by Application Socket or Association**Commands Used: dlt-ip-host**

You cannot delete a host name from the IP Host table if the host name is still referenced by one or more application sockets or associations. Before a host name can be deleted from the IP Host table, you must first delete all application socket or association references to the host name.

Recovery

Enter the **rtrv-appl-sock** command specifying the host name that you want to delete. Verify the application sockets that reference the host name.

OR

1. Enter the **rtrv-assoc** command specifying the host name that you want to delete. Verify the associations that reference the host name.
 2. Delete each referenced socket or association. Enter the **dlt-appl-sock** command or **dlt-assoc** command.
 3. Delete the host name. Re-enter the **dlt-ip-host** command.
-

E4065 Cmd Rej: Application Sockets on Port B Not Allowed**Commands Used: chg-ip-lnk**

You cannot assign application socket to DCM card with IP connections on the B interface. The B interface is not supported on DCMs; however, it is supported on SSEDCMs.

Recovery

1. Determine the associated IP address for the host name. Enter the **rtrv-ip-host** command.
2. Determine the parameter values for **loc** and **port** associated with the IP address from the output of step 1. Enter the **rtrv-ip-lnk** command.
3. Re-enter the command that generated this message, using the host name associated with the A interface.

Call your Customer Care Center if this error message appears again.

E4066 Cmd Rej: Matching routing key already entered for AS

Commands Used: `ent-appl-rtkey`

The specified AS name (**asname**) parameter and routing key could not be added to the Routing Key table because an entry that matches the specified AS name and routing key already exists in the Routing Key table.

Recovery

1. Display the AS names and routing keys in the Routing Key table. Enter the `rtrv-appl-rtkey` command. Verify that the AS name and routing key for your command are correct and unique.
 2. Re-enter the `ent-appl-rtkey` command specifying the correct AS name and routing key.
-

E4067 Cmd Rej: Only SNAME, ASNAME or RCONTEXT allowed for default rtkey

Commands Used: `ent-appl-rtkey`

You specified **type=default** for a default routing key, and one or more parameters other than **sname** or **asname** or **rcontext**.

Recovery

Re-enter the command specifying only the **type=default** parameter and either the **sname** or **asname** or **rcontext** parameter specified.

E4068 Cmd Rej: Must specify either SNAME or ASNAME

Commands Used: `ent-appl-rtkey`, `inh-alm`, `unhb-alm`

You must specify either the **sname** parameter or the **asname** parameter. One of the two parameters is required in the command.

For the `inh-alm` and `unhb-alm` commands:

- When the **dev=applsock** parameter is specified, the **sname** parameter must be specified.
- When the **dev=as** parameter is specified, the **asname** parameter must be specified.

Recovery

Re-enter the command specifying either the **sname** or the **asname** parameter.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4069 Cmd Rej: Entry already exists with specified GTIN24-TT-NP(V)-NAI(V)-SSN

Commands Used: ent-srvsel

You specified an entry that matches an existing **gtin24**, **tt**, **np/naï** or **npv/naïv**, and **ssn** parameter combination, which is not allowed.

Recovery

1. Display the existing values for the above parameters. Enter the **rtrv-srvsel** command.
 2. Re-enter the command specifying values that do not already exist in the database for the above parameters.
-

E4073 Cmd Rej: AS/socket cannot be deleted while assigned to a routing key

Commands Used: dlt-appl-sock, dlt-assoc, dlt-as

You entered a command to delete an AS from the AS table, and the AS is still associated with a routing key. You must first delete the AS association with the routing key before you can delete the AS.

Recovery

1. Display the current AS and routing key associations. Enter the **rtrv-appl-rtkey** command.
 2. Delete the AS association with the routing key. Enter the **dlt-appl-rtkey** command.
 3. Re-enter the command to delete the AS.
-

E4075 Cmd Rej: Invalid name for adapter type

Commands Used: `chg-appl-sock`, `chg-assoc`, `dlt-assoc`

The command specified a name that is invalid for the IP connection type. The command was rejected to prevent the erroneous change or deletion of a provisioned IP connection.

Recovery

1. Display the names of the IP connection. Enter the `rtrv-assoc` and `rtrv-appl-sock` commands.
 2. Check whether the name you are specifying is an association or an application socket.
 3. Re-enter the correct command for the IP connection you are specifying; that is, specify `aname` for a `chg-assoc` or `dlt-assoc` command, or specify `sname` for a `chg-appl-sock` or `dlt-appl-sock` command.
-

E4076 Cmd Rej: E1 card location is unequipped

Commands Used: `chg-e1`, `dlt-e1`, `ent-e1`, `rtrv-e1`

You entered a command to add, change, delete, or retrieve information for an E1 interface for an E1 card or an E1/T1 card used as an E1 card. The card in the location specified by the `loc` parameter must be equipped (defined in the database) as type `lime1`.

Recovery

1. Perform one of the following actions:
 - Enter the `rtrv-card` command specifying the location in the `loc` parameter of the E1 card to which you want to add the E1 interface. Verify that the card in that location is of type `lime1`.
 - OR
 - Enter the `rtrv-e1` command specifying no parameters to display the card location information for `lime1` cards defined in the database. Verify the card location for the card with the E1 interface that you want to change, delete, or retrieve.
 2. Re-enter the command specifying the correct card location in the `loc` parameter for the card on which you want to add, change, delete, or retrieve the E1 interface.
-

E4077 Cmd Rej: Parameters incompatible with adapter type

Commands Used: `dlt-appl-rtkey`

You cannot specify the `rcontext` and `loc` parameters together in the same command line. The `loc` parameter is only used with dynamic (TALI-only) routing keys and dynamic routing keys do not support routing context.

Recovery

Re-enter the `dlt-appl-rtkey` command specifying the `rcontext` and `loc` parameters using separate command lines.

Example:

The following command would generate an E4077 error message:

```
dlt-appl-rtkey:loc=xxxx:rcontext=y
```

E4078 Cmd Rej: Conflicting parameters specified

Commands Used: `chg-appl-rtkey`, `dlt-appl-rtkey`,
`ent-appl-rtkey`, `rtrv-appl-rtkey`

You specified parameters that cannot be entered in the same command.

Recovery

Re-enter the command specifying a valid combination of parameters.

E4079 Cmd Rej: Specified AS name not found

Commands Used: `chg-as`, `dlt-appl-rtkey`, `dlt-as`, `rept-stat-as`

You entered a command to delete a routing key, delete an application server (AS), or display the status of an AS. The value specified for the AS name parameter (`asname`) does not exist in the AS table.

Recovery

1. Display the AS names that are currently in the AS table. Enter the `rtrv-as` command. Verify the AS name that you specified is in the AS table.
 2. Re-enter the command specifying the correct AS name.
-

E4081 Cmd Rej: Maximum number of connections already provisioned for AS**Commands Used: ent-as**

You entered a command to add an M3UA/SUA association to an existing application server (AS). The AS already has the maximum of **16** associations (M3UA/SUA/M2PA IP connections).

Recovery

1. Display the associations with ASs in the AS table. Enter the **rtrv-as** command.
 2. To create another association with the AS, you must first delete an existing association from the AS.

Refer to the *Commands Manual* for detailed information about the use of the **dlr-as** command.
 3. If you have deleted an existing association for the AS, re-enter the **ent-as** command to create an association with the AS.
-

E4083 Cmd Rej: Connection adapter type does not match AS adapter type**Commands Used: ent-as**

You entered a command to add an M3UA/SUA association to an application server (AS), and the adapter type is not the same as the adapter type of one or more associations that have already been assigned to the AS.

Recovery

1. Enter the **rtrv-as** command to display the associations for the AS.
 2. Enter the **rtrv-assoc** command to display the adapter type of the existing associations.
 3. Re-enter the **ent-as** command to add an association with the same adapter type as one or more associations already assigned to the AS.
-

E4087 Cmd Rej: Both NPV and NAIV must be either * or numbers**Commands Used: ent-gsmmap-scrn**

You specified inconsistent values for the **np** and **naiv** parameters. The values you specify for both of these parameters must be either * (wildcard notation) or numbers.

Recovery

Re-enter the **ent-gsmmap-scrn** command that generated this error message specifying either * or numbers for the **np** and **naiv** parameters.

E4089 Cmd Rej: Unable to change adapter when assigned to an AS

Commands Used: **chg-assoc**

You entered a command to change the adapter value (M3UA, SUA, or M2PA) for an association. The specified association is bound to an AS. You cannot change the adapter value when the association is bound to an AS.

Recovery

1. Display each AS and its current association. Enter the **rtrv-as** command.
 2. If you want to change the adapter value for the association, first delete the association name for the adapter you want to change. Enter the **dlt-as** command specifying the association name parameter (**aname=**) of the association to delete.
 3. Re-enter the **chg-assoc** command to change the adapter value for the desired association.
-

E4091 Cmd Rej: Association connection parameters must be unique

Commands Used: **chg-assoc**, **ent-assoc**

You entered a command to change one or more connection parameters for an association or to add an association to the IPAPSOCK table. The new association has exactly the same local host, local port, remote host, and remote port as an existing association in the table. No two associations can have exactly the same **lhost/lport/rhost/rport** parameter combination.

Recovery

1. Display the existing associations and their connection parameters. Enter the **rtrv-assoc** command.
 2. Re-enter the command specifying a connection parameter combination that is not exactly the same as for any existing association.
-

E4092 Cmd Rej: Too many associations per SLK**Commands Used: chg-assoc**

You entered a command that would result in more than one association per signalling link. On IPLIM/IPLIMI cards only one association is allowed per signalling link. When you enter the association, the **port** parameter value (**a** or **b**) indicates which link on the card is to use the association.

Recovery

1. Display the IP address of the IPLIM or IPLIMI card. Enter the **rtrv-ip-lnk** command.
 2. Display the host name for the card. Enter the **rtrv-ip-host** command and specify the IP address (**ipaddr** parameter) from step 1 for the card.
 3. Display the associations on the card. Enter the **rtrv-assoc** command and specify the host name (**lhost** parameter) from step 2 for the card.
 4. Re-enter the **chg-assoc** command specifying an available port to assign an association.
-

E4093 Cmd Rej: Too many associations per card**Commands Used: chg-assoc, ent-assoc**

You entered a command to create a new association in the IPAPSOCK table. The entry would result in too many associations for the card. The following associations are allowed:

- Only **2** associations per IPLIM card (one per link)
- Only **4** association allowed on an IPGWx card using DCM hardware
- SSED CM hardware allows **50** associations on an IPGWx card

Recovery

1. Display the associations in the IPAPSOCK table. Enter the **rtrv-assoc** command.
 2. Re-enter the command if the card allows another association.
Call your Customer Care Center if this error message appears again.
-

E4096 Cmd Rej: Association name already exists

Commands Used: `ent-assoc`

You entered a command to add an association to the IPAPSOCK table. The table already contains an association with the name that you specified in the command.

Recovery

1. Display the existing association names in the IPAPSOCK table. Enter the `rtrv-assoc` command.
 2. Re-enter the `ent-assoc` command specifying an association name that is not already in the IPAPSOCK table.
-

E4097 Cmd Rej: Cannot assign LHOST/ALHOST to the B interface

Commands Used: `ent-assoc`, `chg-assoc`, `chg-appl-sock`,
`ent-appl-sock`

You tried to provision socket LHOST or association LHOST/ALHOST with a host name that is associated with the B interface. The B interface is not supported on DCMs; however, it is supported on SSED CMs.

Recovery

1. Determine the associated IP address for the host name. Enter the `rtrv-ip-host` command.
2. Determine the parameter values for `loc` and `port` associated with the IP address from the output of step 1. Enter the `rtrv-ip-lnk` command.
3. Re-enter the command that generated this message, specifying the host name associated with the A interface.

Call your Customer Care Center if this error message appears again.

E4098 Cmd Rej: OPEN must be NO to change an Association or its AS/Rtkey

Commands Used: `chg-as`, `chg-assoc`, `dlt-appl-rtkey`, `dlt-as`,
`dlt-assoc`, `ent-as`

The connection state of an association must be `open=no` before you can change the characteristics (`lhost`, `lport`, `rhost`, `rport`, `adapter`, `ver`, `istrms`, `ostrms`, `rmode`, `rmin`, `rmax`, `rtime`s, and `cwmin`) of an association, or delete the association.

OR

The connection state of the associations bound to the M3UA/SUA associations for the AS must be **open=no** before you can enter, change, or delete the AS.

Recovery - chg-assoc, dlt-assoc

1. Display the associations and their connection states. Enter the **rtrv-assoc** command. Verify the connection state of the specified association.
 2. If the connection state for the specified association is **open=no**, re-enter the **chg-assoc** or **dlt-assoc** command.
Contact your Customer Care Center if this error message appears again.
 3. If the connection state for the specified association is **open=yes**, change the connection status to **open=no**. Perform the following actions:
 - Enter the **chg-assoc** command specifying the association name (**aname**) and the **open=no** parameter.
 - Re-enter the command to change the association characteristics or to delete the association
-

Recovery - chg-as, dlt-as, ent-as

1. Display the **mode** for the AS you want to change or delete. Enter the **rtrv-as** command.
 2. Display the connection status of the associations bound to each AS. Enter the **rtrv-assoc** command.
 3. For each association that needs to be changed from a connection state of **open=yes** to a connection state of **open=no**, enter the **chg-assoc** command specifying the **open=no** parameter.
 4. When all required association connection states are **open=no**, re-enter the command to enter, change, or delete the AS.
-

E4099 Cmd Rej: Association name not found

Commands Used: chg-assoc, dlt-assoc, rept-stat-assoc

You entered a command that specified an association name; the name that you specified is not defined in the IPAPSOCK table.

Recovery

1. Display the association names that currently exist in the IPAPSOCK table. Enter the **rtrv-assoc** command. Verify that you specified an existing association name.
 2. Re-enter the command specifying an existing association name, as shown in the output from step 1.
-

E4100 Cmd Rej: LNP feature must be on before LNP ELAP Config can be on

Commands Used: **chg-ctrl-feat**

The LNP feature must be turned on before the LNP ELAP Configuration feature can be turned on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.
2. If the LNP feature is on (from the output of step 1 - the LNP ported TNs entry quantity is less than or equal to **12,000,000**), re-enter the command.
Call your Customer Care Center if this error message appears again.
3. If the LNP feature is off (from the output of step 1- the LNP ported TNs entry does not appear in the output), turn it on. Enter the **chg-ctrl-feat** command.

Refer to the “*Activating the LNP Feature*” procedure in the *Database Administration Manual - LNP*, and call your Customer Care Center before starting the process.

4. Turn on the LNP ELAP Configuration feature. Re-enter the **chg-ctrl-feat** command.
-

E4101 Cmd Rej: LNP ELAP CFG feat incompatible with SCCP/EBDADCM/EBDABLM appl

Commands Used: `chg-ctrl-feat`, `ent-card`

You cannot specify the `appl=sccp/ebdadcm/ebdablm` parameter if the LNP ELAP Configuration feature is turned on in your system. Turning on the LNP ELAP Configuration feature requires DSM cards running the `vsccp` application.

The EDBADCM GPL is used by the DCM card to transmit the LSMS LNP database to the EAGLE 5 ISS for enhanced bulk download. The EDBABLM GPL is used by the TSM card for enhanced bulk download. If LNP ELAP Configuration is turned on, the Eagle LNP Application Processor (ELAP) provides the functionality for accomplishing bulk loading.

Recovery

1. Re-enter the command that generated this error message without specifying `appl=sccp/ebdadcm/ebdablm`.
 2. To remove any card that is mentioned, enter the `dlt-card` command.
-

E4102 Cmd Rej: GFLEX/INP/GPORT/EIR/LNP ELAP Config feature must be ON

Commands Used: `rept-stat-db`, `rept-stat-mps`, `rtrv-data-rtdb`, `rtrv-data-insrv`

The GSM Flexible Numbering (G-Flex) feature, INAP Number Portability (INP) feature, or GSM Mobile Number Portability (G-Port) feature must be turned on before issuing the command to display EPAP MPS database or VSCCP card status.

The LNP ELAP Configuration or Equipment Identity Register (EIR) feature must be enabled and turned on before you can issue the command to display ELAP MPS database or VSCCP card status.

Recovery

Display the features in the database. Enter the `rtrv-feat` command to verify the status of the G-Flex, INP, and G-Port features and the `rtrv-ctrl-feat` command to verify the status of the EIR and LNP features.

- If none of the features listed in this message description are turned on, you cannot use the `rept-stat-mps` command.

You can enter a different `rept-stat-xxx` command (such as `rept-stat-sccp` or `rept-stat-card`) depending on the type of status information you are trying to retrieve.

The *Commands Manual* lists the System Maintenance commands (**rept-stat-xxx** commands). Refer to the list if you need help in determining the correct command.

- If none of the features listed in this message description are turned on, you cannot use the **db=mps** parameter in the **rept-stat-db** command.

You can enter the **rept-stat-db** command specifying other parameter values for database and card status information.

E4106 Cmd Rej: Use REPT-STAT-MPS when LNP ELAP Configuration is ON

Commands Used: **rept-stat-lsms**

The LNP ELAP Configuration feature is turned on in your system; consequently, the **rept-stat-lsms** command is no longer available. Use the **rept-stat-mps** command to obtain status information for the Eagle LNP Application Processor (ELAP) subsystem.

Recovery

Re-enter the command using the **rept-stat-mps** command instead of the **rept-stat-lsms** command.

E4107 Cmd Rej: AS table is full

Commands Used: **ent-as**

You entered a command to add an application server process to the AS table. The table already contains the maximum of **250** AS entries. Before you can add another AS to the table, you must delete an existing AS from the table.

Recovery

1. Display the ASs that are in the AS table. Enter the **rtrv-as** command.
 2. To delete an existing AS from the AS table, refer to the **dlt-as** command description in the *Commands Manual* for restrictions using this command.
 3. When you have deleted an existing AS from the AS table, re-enter the **ent-as** command to add another AS to the AS table.
-

E4108 Cmd Rej: Host assignment to IPLIM/IPLIMI card not supported

Commands Used: `chg-assoc`, `ent-assoc`

You entered a command to add an association to the IPAPSOCK table or change the characteristics of an association in the table. You specified a port that is on an IPLIM or IPLIMI card. You cannot assign a local or remote host to an IPLIM or IPLIMI card.

Recovery

1. Display the card TYPE and APPL (application). Enter the `rtrv-card` command for the card with the specified port. Verify that the card is not an IPLIM or IPLIMI card.
 2. If the card is not an IPLIM or IPLIMI card, re-enter the command.
Contact your Customer Care Center if this error message appears again.
 3. If the card is an IPLIM or IPLIMI card, re-enter the command specifying a port on the correct card.
-

E4109 Cmd Rej: Association is still assigned to AS

Commands Used: `dlt-assoc`

You cannot delete an association from the IPAPSOCK table that is assigned to an AS.

NOTE: The connection state must be `open=no` to delete the association from the IPAPSOCK table.

Recovery

1. Display all ASs with that association. Enter the `rtrv-as:aname=<association_name>` command.
 2. Delete the association for each AS. Enter the `dlt-as` command.
Refer to the *Commands Manual* for detailed information about the use of the `dlt-as` command.
-

E4113 Cmd Rej: Measurement collection in progress, Retry later

Commands Used: `copy-disk`, `format-disk`

You entered a command that is not allowed at this time because the OAM measurements collection is in progress. Measurement requirements for disk access are not compatible with the `copy-disk` and `format-disk` commands.

Recovery

Wait a time for the measurement collection operation to complete, and then re-enter the command.

NOTE: Because no user output specifically indicates that measurement collection has begun or ended, re-enter the command until it is accepted. If this error message does not clear up within an hour, call your Customer Care Center for assistance.

E4114 Cmd Rej: TTA cannot be specified for a direction of ITOA

Commands Used: `dlt-gtcnv`

If you specify the direction of conversion is ITU-to-ANSI (**dir=itoa**), you cannot specify the ANSI translation type (**tta**) parameter.

Recovery

Re-enter the `dlt-gtcnv` command specifying **dir=itoa**, without specifying the **tta** parameter.

E4115 Cmd Rej: TTI must be specified for a direction of ITOA

Commands Used: `chg-gtcnv`, `dlt-gtcnv`

If you specify the direction of conversion is ITU-to-ANSI (**dir=itoa**), the ITU translation type (**tti**) parameter must be specified.

Recovery

Re-enter the command specifying **dir=itoa** and the **tti** parameter.

E4116 Cmd Rej: Wildcard/Asterisk invalid for direction of BOTH

Commands Used: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`

The use of wildcards is not allowed if the direction of conversion is **both** (**dir=both**). (A wildcard is an entry specified with the use of asterisks).

Refer to the *Commands Manual* for details about the use of wildcards with these commands.

Recovery

Re-enter the command without specifying wildcards or asterisks if the direction of conversion is BOTH (**dir=both**) parameter is specified.

E4117 Cmd Rej: Wildcard/Asterisk combination invalid for direction

Commands Used: `ent-gtcnv`

The specified command is invalid because the combination of wildcards used is not correct for the specified (**dir**) parameter. The direction of conversion parameter restricts which combination of parameters can use asterisks. (A wildcard is an entry specified with the use of asterisks).

Refer to the *Commands Manual* for detailed information about the use of the `ent-gtcnv` command.

Recovery

Re-enter the `ent-gtcnv` command specifying parameters that do not use wildcards or asterisks.

E4118 Cmd Rej: Wildcard/Asterisk required for TTI, NP, NAI if DIR is ITOA

Commands Used: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`

The command is invalid because wildcards are required for the **tti**, **np**, and **nai** parameters when specifying an ITU-to-ANSI direction of conversion (**dir=itoa**). (A wildcard is an entry specified with the use of asterisks).

Refer to the *Commands Manual* for details about the valid use of wildcards with these command.

Recovery

Re-enter the command specifying the **tti=***, **np=***, and **nai=*** parameters when specifying **dir=itoa**.

E4119 Cmd Rej: Key values: DIR, TTA, TTI, NP, NAI already exist

Commands Used: **ent-gtcnv**

The command is invalid because the key **dir**, **tta**, **tti**, **np**, or **nai** value(s) have already been specified for this Global Title Conversion table entry.

Recovery

Re-enter the **ent-gtcnv** command without the previously specified **dir**, **tta**, **tti**, **np**, or **nai** parameter.

E4120 Cmd Rej: Key values: DIR, TTA, TTI, NP, NAI does not exist

Commands Used: **chg-gtcnv**, **dlt-gtcnv**

The command is invalid because not all key values **dir**, **tta**, **tti**, **np**, and **nai** have been specified.

Recovery

1. Enter the **ent-gtcnv** command specifying all the key values **dir**, **tta**, **tti**, **np**, and **nai**.
 2. Once all key values are defined, re-enter the original command.
-

E4121 Cmd Rej: ENCODE = AMI not currently supported

Commands Used: **chg-e1**, **ent-e1**, **ent-t1**

You cannot specify a value of **ami** for the **encode** parameter (**encode=ami**) for a 2-port E1 card. The 2-port E1 card does not support Alternate Mark Inversion (AMI) encoding. Alternate Mark Inversion (AMI) encoding is only supported on the E1/T1 MIM card, or the HC-MIM card used as an E1 or T1 card.

Recovery

Re-enter the command specifying **encode=hdb3** for the 2-port E1 card.

E4122 Cmd Rej: Both NP and NAI must be specified if either is present

Commands Used: **chg-gtcnv, dlt-gtcnv**

If you specify either the **np** or **nai** parameter, you must specify both of these parameters.

Recovery

Re-enter the command specifying both the **np** and **nai** parameters.

E4123 Cmd Rej: SAPC entry not found for the linkset

Commands Used: **chg-1s**

The value specified for the **sapc** parameter does not exist for the linkset.

Recovery

1. Display all the destination point codes in the Destination Point Code table.
Enter the **rtrv-1s:1sn** command for the given linkset.
 2. Re-enter the **chg-1s** command specifying a point code from the output in Step 1.
-

E4124 Cmd Rej: APC/SAPC with specified group code already exists for linkset

Commands Used: **chg-ip-1nk, chg-1s**

Only one secondary adjacent point code (**sapc**) or **apc** per domain per linkset is allowed when the specified group code is **multgc=no** for the linkset. Additionally, when the specified group code is **multgc=yes**, only one **sapcn** per group code per link set is allowed.

Recovery

1. Display all **apc/sapc** entries for the specified linkset. Enter the **rtrv-ls:lsn** command.
 2. Delete the **apc/sapc** entry. Enter the **chg-ls** command specifying **action=delete**, if necessary.
-

E4125 Cmd Rej: Maximum SAPC entries exceeded**Commands Used: chg-ls**No additional secondary adjacent point code (**sapc**) entry can be added.**Recovery**

1. Delete an **sapc** entry that is not being used. Enter the **chg-ls** command specifying **action=delete**, if necessary.
 2. Re-enter the **chg-ls** command to add the **sapc** entry.
-

E4126 Cmd Rej: Only one ITU-N APC/SAPC allowed with MULTGC=NO**Commands Used: chg-ls**Only one secondary adjacent point code (**sapc**) or **apc** per ITU-N domain per linkset is allowed when **multgc=no** for the linkset.**Recovery**

Display all the destination point codes in the Destination Point Code table. Enter the **rtrv-ls:lsn** command for the given linkset.

E4127 Cmd Rej: Only one ITU-I or 24-bit ITU-N APC/SAPC allowed per linkset**Commands Used: chg-ls**Only one secondary adjacent point code (**sapc**) or **apc** is allowed per linkset in an ITU-I or 24-bit ITU-N domain.

Recovery

1. Display all the destination point codes in the Destination Point Code table. Enter the **rtrv-ls:lsn** command for the given linkset.
 2. Re-enter the **chg-ls** command specifying a point code from the output in Step 1.
-

E4128 Cmd Rej: SAPC entry present for the linkset

Commands Used: **chg-ls**

A secondary adjacent point code (**sapc**) is provisioned for the linkset.

Recovery

Delete a **sapc** entry. Enter the **chg-ls** command specifying **action=delete**.

E4129 Cmd Rej: SAPC allowed for ITU-I or ITU-N linkset only

Commands Used: **chg-ls**

The secondary adjacent point code (**sapc**) value specified is not allowed for this ANSI linkset.

Recovery

Change linkset *apc* type, if needed.

E4132 Cmd Rej: Group code not allowed with specified network type

Commands Used: **dlt-na, ent-na**

The group code (**gc**) parameter can not be specified for ANSI, ITUI, and ITUN24 type network appearances.

Recovery

1. For the **dlt-na** command, enter the **rtrv-na** command to display the existing network appearances. Verify the network appearance that you want to delete.
 2. Re-enter the command that generated this message without specifying the **gc** parameter for the network appearance.
-

E4133 Cmd Rej: Group code required for ITUN when ITUDUPPC feat is ON**Commands Used: ent-na**

The group code (**gc**) parameter must be specified for ITUN network appearances when the ITUDUPPC feature is turned on.

Recovery

1. Verify that the ITUDUPPC feature is turned on. Enter the **rtrv-feat** command.
 2. Re-enter the **ent-na** command specifying the group code (**gc**) parameter for the ITUN network appearance.
-

E4134 Cmd Rej: Group code not allowed when ITUDUPPC feat is OFF**Commands Used: ent-na**

The group code (**gc**) parameter cannot be specified for network appearances if the ITUDUPPC feature is turned off.

Recovery

1. Verify that the ITUDUPPC feature is turned off. Enter the **rtrv-feat** command.
 2. Re-enter the **ent-na** command without specifying the group code (**gc**) parameter for the network appearance.
-

E4135 Cmd Rej: Group code must be in SID or SPC table**Commands Used: ent-na**

You specified a group code for a network appearance, and the group code was not found in the SID or SPC table.

Recovery

1. Enter the **rtrv-sid** and **rtrv-spc** commands to verify the group code.
 2. Re-enter the **ent-na** command specifying the correct group code (**gc**) parameter for the network appearance.
-

E4136 Cmd Rej: NA entry already equipped**Commands Used: ent-na**

You entered a command to define a network appearance that already exists in the Network Appearance table.

Recovery

1. Display the existing network appearances in the Network Appearance table. Enter the **rtrv-na** command.
 2. Re-enter the **ent-na** command to define a network appearance that does not already exist in the Network Appearance table.
-

E4138 Cmd Rej: NA entry not found**Commands Used: dlt-na**

You entered a command to delete a network appearance. The specified network appearance was not found in the Network Appearance table.

Recovery

1. Display the existing network appearances in the Network Appearance table. Enter the **rtrv-na** command. Verify the network appearance that you want to delete is in the Network Appearance table.
 2. Delete the network appearance. Re-enter the **dlt-na** command specifying the network appearance that you want to delete.
-

E4139 Cmd Rej: RC Already Equipped

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`

You attempted to add or change the routing context value of a routing key without satisfying the following criteria:

- The routing context value in a routing key must be unique (multiple routing keys can not have identical routing context values).
- The routing context value in a routing key may only be changed if all of the ASPs associated with the routing key are **open=no**. For SPLIT AS routing key changes, the old AS and the new AS must both meet this criteria.
- The routing context value in a routing key may not be changed during the same command as a RESIZE or SPLIT routing key change.
- A routing key containing a routing context may only be deleted if all of the ASPs associated with the routing key are **open=no**.

Recovery

1. Display the routing keys and routing context values. Enter the `rtrv-appl-rtkey:display=all` command.
 2. Following the above criteria, re-enter the command to add or change the routing context value for a routing key.
-

E4141 Cmd Rej: IPSM card(s) must be inhibited to enable telnet feature

Commands Used: `chg-ctrl-feat`

Before you can change the status of the Telnet feature (either turning on or turning off), you must first inhibit all Internet Protocol Services Module (IPSM) cards. Inhibit all IPSM cards before changing the status of the Telnet feature.

Recovery

1. Inhibit all IPSM cards. Enter the `inh-card` command.
 2. Turn on the Telnet feature for the cards you inhibited in step 1. Re-enter the `chg-ctrl-feat` command.
Call your Customer Care Center if this error message appears again.
 3. Allow all IPSM cards. Enter the `alw-card` command for each card inhibited in Step 1.
-

E4146 Cmd Rej: CTX parameter is invalid for this card**Commands Used: ent -bp**

You cannot specify the bit-mapped microengine context mask (**ctx**) parameter for a card that is not an IXP-based card with processor **type=IXP**.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4147 Cmd Rej: Invalid combination of TYPE, UENG, and CTX parameters**Commands Used: ent -bp**

If you specify **type=ixp**, then you must also specify both the microengine number (**ueng**) and the bit-mapped microengine context mask (**ctx**) parameters.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4148 Cmd Rej: DATA parameter is invalid for this card**Commands Used: ent -bp**

The **data** parameter is only valid on an IXP-based card.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4149 Cmd Rej: ARM register must be specified

Commands Used: **ent -bp**

The **ca**, **cb**, and **drarm** register values must be specified for an IXP-based card with processor **type=arm**.

Recovery

Re-enter the **ent -bp** command specifying a valid combination of parameters. Valid **ca**, **cb**, and **drarm** register values for an IXP-based card ARM processor are **sp**, **lr**, **pc**, and **r0..r15**.

E4150 Cmd Rej: UENG register must be specified

Commands Used: **ent -bp**

The microengine number (**ueng**) parameter must be specified for a card with processor **type=ixp**. The **ca** and **cb** parameters are not valid with processor **type=ixp**.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of this **ent -bp** command.

E4151 Cmd Rej: UENG parameter is invalid for this card

Commands Used: **disp-bp**, **dlt-bp**, **ent-bp**

The microengine number (**ueng**) parameter is only valid on an IXP-based card with processor **type=ixp**.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4152 Cmd Rej: Invalid combination of TYPE and DATA parameters

Commands Used: **ent -bp**

The **data** parameter is only valid with breakpoint **type=data**.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4153 Cmd Rej: CA or CB register value is invalid for this card

Commands Used: **ent -bp**

The **ca**, **cb**, and **drarm** register values must be specified for an IXP-based card with processor **type=arm**.

Recovery

Re-enter the **ent -bp** command specifying a valid combination of parameters. Valid **ca**, **cb**, and **drarm** register values for an IXP-based card ARM processor are **sp**, **lr**, **pc**, and **r0..r15**.

E4154 Cmd Rej: DRARM parameter is invalid for this processor

Commands Used: **ent -bp**

The ARM register indirect memory dump (**drarm**) parameter can only be specified with processor **type=arm**.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4155 Cmd Rej: DR parameter is invalid for this card**Commands Used: ent -bp**

The register indirect memory dump (**dr**) parameter is not valid on an IXP-based card.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4156 Cmd Rej: DRARM parameter is invalid for this card**Commands Used: ent -bp**

The ARM register indirect memory dump (**drarm**) parameter is only valid on an IXP-based card.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4157 Cmd Rej: DA parameter is invalid for this card**Commands Used: ent -bp**

The dump address (**da**) parameter is not valid on an IXP-based card.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4158 Cmd Rej: ADDR parameter is invalid for this card**Commands Used: ent -bp**

The **addr** parameter is valid only for cards with PROM-based COM processors (such as TSMs); that is, when **proc=com** is specified for DS0 cards. ~~A HPR or IMTPCI card was specified and the ADDR parameter used. The parameter is not valid for use with the HPR and IMTPCI cards.~~

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4159 Cmd Rej: TYPE parameter value is invalid for this card**Commands Used: ent -bp**

Processor types ARM and IXP are only valid on an IXP-based card.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4160 Cmd Rej: ACCESS parameter value is invalid for this card**Commands Used: ent -bp**

When using the **access** parameter, **format=any** is only valid on an IXP-based card. The **format** parameter must be set to **any** on IXP-based cards.

Recovery

Re-enter the **ent -bp** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent -bp** command.

E4161 Cmd Rej: Routing Context parameter is required for SUA

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`, `ent-as`

Routing context is mandatory for routing keys associated with an AS containing SUA ASPs.

Recovery - `chg-appl-rtkey`, `ent-appl-rtkey`

You attempted to add or change a routing key without specifying a routing context value.

Re-enter the command specifying a valid routing context value.

Recovery - `ent-as`

You attempted to create an AS whose routing key does not have a routing context value.

- Display the routing keys and routing context value. Enter the `rtrv-appl-rtkey:display=all` command.
 - Assign a routing context value to the appropriate routing key. Enter the `chg-appl-rtkey` command.
 - Create the AS. Re-enter the `ent-as` command.
-

E4165 Cmd Rej: Point Code Subtype Prefix not supported

Commands Used: `rtrv-dstn`, `rtrv`, `rte`

Spare Point Code subtype `s` or `ps` is not supported with `pctype=ansi` or `pctype=itun24`.

Recovery

1. Re-enter the command without specifying the `pcst` parameter.
 2. Re-enter the command specifying `pcst=p` or `pcst=none`.
-

E4166 Cmd Rej: Enhanced GSM Map Screening must be ON**Commands Used: enable-ctrl-feat**

The command to enable the MTP MAP Screening feature was not allowed because the Enhanced GSM MAP (EGMS) feature must be enabled first.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* about enabling features with access keys.

Recovery

1. Enter the **rtrv-ctrl-feat** command to display the status of features in your system that have feature access keys.
2. Verify the Enhanced GSM MAP Screening (EGMS) feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the Enhanced GSM MAP Screening feature in your system. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information. Turn on the feature. Enter the **chg-ctrl-feat** command.

Refer to the *Commands Manual* and the *Database Administration Manual - Features* for more information about enabling this feature.

4. Enable the MTP MAP Screening feature. Re-enter the **enable-ctrl-feat** command and the appropriate part number and access key information.
-

E4167 Cmd Rej: Cannot add NP and NAI to an entry where GTIXLAT is 22**Commands Used: chg-ctcnv**

You cannot specify the new numbering plan (**np**) and the new nature of address indicator (**nai**) parameters, if the value for the **gtixlat** parameter is **22** (**gtixlatt=22**).

Recovery

Re-enter the **chg-ctcnv** command specifying **gtixlatt=22** and without specifying the **np** and **nai** parameters.

E4168 Cmd Rej: At least one Non-Key parm that is to be changed is required

Commands Used: `chg-gtcnv`

The command is invalid because it does not specify at least one non-key parameter to be changed.

Recovery

Re-enter the `chg-gtcnv` command specifying at least one of these non-key parameters: `npdd`, `npds`, `nsdd`, `nsds`, or `rdmod`.

E4169 Cmd Rej: GT Conversion table is full

Commands Used: `ent-gtcnv`

The Default Global Title Conversion table is full. You must delete a translation type entry before another translation type entry can be added to the conversion table.

Recovery

1. Display the translation type entries in the Default Global Title Conversion table. Enter the `rtrv-gtcnv` command.
 2. Delete an existing entry from the Default Global Title Conversion table . Enter the `dlt-gtcnv` command specifying one of the translation type entries shown in the output in step 1.
 3. Re-enter the `ent-gtcnv` command.
Call your Customer Care Center if this error message appears again.
-

E4170 Cmd Rej: Prefix & Suffix digit modification parameters can't be mixed

Commands Used: `chg-gta`, `chg-gtcnv`, `chg-gtt`, `ent-gta`, `ent-gtcnv`, `ent-gtt`

Specifying both prefix digit manipulation and suffix digit manipulation parameters is not supported. You cannot mix these parameters in a single command because they are mutually exclusive.

Recovery

Re-enter the command specifying either prefix digit manipulation or suffix digit manipulation parameters, but not both.

E4171 Cmd Rej: SCCP Conversion feature must be enabled

Commands Used: `chg-gta`, `chg-gtcnv`, `chg-gtt`, `chg-gttset`, `chg-stpopts`, `dlt-gtcnv`, `ent-gta`, `ent-gtcnv`, `ent-gtt`, `ent-gttset`, `rtrv-gta`, `rtrv-gtcnv`, `rtrv-gttset`

The ANSI/ITU/24 Bit SCCP Conversion feature must be enabled before you can specify the `netdom=cross` parameter.

The ANSI-ITU-China SCCP Conversion feature must be enabled and turned on before the `ngti` parameter can be specified.

The ANSI-ITU-China SCCP Conversion feature must be enabled before entering any of the following:

- Specifying the new GTI code (`ngti`) parameter with either the global title translation commands (`ent-gtt`, `chg-gtt`, `rtrv-gtt`), or with the global title address commands (`ent-gta`, `chg-gta`, `rtrv-gta`).
- Any global translation conversion command, `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`, or `rtrv-gtcnv`
- Command parameters `cnvcgda`, `cnvcgdi`, `cnvcgdn`, `cnvcgdn24`, or `gtcnvdflt`.

Recovery

1. Display the status of features in your system that have feature access keys
Enter the `rtrv-ctrl-feat` command.
2. Verify the ANSI-ITU-China SCCP Conversion feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the ANSI-ITU-China SCCP Conversion feature. Enter the `enable-ctrl-feat` command specifying the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual – Global Title Translation* for more information about enabling this feature.

4. Re-enter the command that generated this error message.
-

E4172 Cmd Rej: Can't switch existing Pfx/Sfx, use RDMOD to reset**Commands Used: chg-gtcnv**

You cannot switch the prefix and suffix digit modifier parameters in a single command because they are mutually exclusive. To change the values from prefix to suffix or the reverse, first use the **rdmod** parameter to reset the current digit modifier values.

Recovery

1. Reset the digit modifiers. Enter the **chg-gtcnv:tta=xxx:tti=yyy:rdmod=yes** command.
 2. Re-enter the **chg-gtcnv** command specifying either the prefix or suffix digit modifiers.
-

E4173 Cmd Rej: Not compatible with SCCP Conversion feature**Commands Used: chg-feat**

You cannot specify either the SCCP Conversion (SCCPCNV feature bit) or TCAP Conversion (TCAPCNV feature bit) features because the ANSI-ITU-China SCCP Conversion feature is already enabled. The ANSI-ITU-China SCCP Conversion feature is mutually exclusive with both of those feature bits.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

Display the features in the database. Enter the **rtrv-feat** command to verify the status of the SCCPCNV and TCAPCNV features and the **rtrv-ctrl-feat** command to verify the status the ANSI-ITU-China SCCP Conversion feature.

Call your Customer Care Center if this error message appears again.

E4174 Cmd Rej: NGTI only valid when PC and GTTSN are different domains

Commands Used: `chg-gta`, `ent-gta`

The New GTI Code (**ngti**) parameter is valid only when the translated point code (**pc**) and GTT set name (**gttsn**) are different domains. The **ngti** parameter can be specified only when the translated point code and the translation type are in different domains, or are both in the ITU domain.

Recovery

1. Verify all point codes and the domains that they are assigned to. Enter the `rtrv-dstn` command. The domain of each point code is shown in the DOMAIN field in the output.
 2. Re-enter the original command specifying an **ngti** parameter with a PC (translation point code) whose domain is different from the domain of the GTTSN (GTT set name).
-

E4175 Cmd Rej: If NGTI is 4, NNP and NNAI must be specified

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

If you specify the New GTI Code is **4** (**ngti=4**), you must specify both the new numbering plan (**nnp**) and the new nature of address indicator (**nnai**) parameters.

Recovery

Re-enter the command specifying both the **nnp** and **nnai** parameters.

E4176 Cmd Rej: If NGTI is 2, NNP and NNAI cannot be specified

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

If you specify the New GTI Code parameter is **2** (**ngti=2**), you cannot specify the new numbering plan (**nnp**) or new nature of address indicator (**nnai**) parameters.

Recovery

Re-enter the command without specifying the **nnp** and **nnai** parameters.

E4177 Cmd Rej: EIR and INP are mutually exclusive

Commands Used: `chg-feat`, `enable-ctrl-feat`

You cannot enable and turn on the EIR feature if the INP feature is turned on. Conversely, you cannot enable and turn on the INP feature, while the EIR feature is turned on. The EIR and INP features are mutually exclusive.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Feature Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` command to verify the status of the INP feature and the `rtrv-ctrl-feat` command to verify the status the EIR feature.
 2. If the INP feature is turned off and the EIR feature does not appear in the output from step 1), re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E4178 Cmd Rej: EIR and LNP are mutually exclusive

Commands Used: `enable-ctrl-feat`

You tried to enable either the EIR feature or the LNP feature, but the other of the features is already enabled or turned on. These two features are mutually exclusive, so you can have either feature, but not both.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-ctrl-feat` command to verify the status the LNP and EIR features.
 2. If both features are not listed in the step 1 output, re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E4179 Cmd Rej: EIR feature cannot be enabled if ASM/TSM is present**Commands Used: enable-ctrl-feat**

The Equipment Identity Register (EIR) feature cannot be enabled if the EAGLE 5 ISS contains TSM cards (i.e., the test verifies that no SCCP GPLs are present). The EIR feature requires DSM cards, not TSM cards.

Recovery

1. Display the cards and loads in the system. Enter the **rtrv-card** command.
2. If a TSM card is present in the system, it will show the APPL as SCCP, which is incompatible with the EIR feature. To support the EIR feature, the system must have only DSM cards and VSCCP loads.
3. Verify that the system contains only DSM cards and VSCCP APPLs and that the EIR feature has been purchased and installed in your system.

Contact your Customer Care Center if you need assistance.

E4180 Cmd Rej: Wildcard SSN already exists**Commands Used: ent-srvsel**

You specified a command specifying a **gti/gtia/gtii/gtin, tt, np(v), nai(v)**, and a specific **ssn** that already has a matching wildcard **ssn** entry. (A wildcard **ssn** entry is specified with the use of asterisks). This duplication of entry is not allowed.

Recovery

1. Display the existing values for the above parameters. Enter the **rtrv-srvsel** command.
 2. Re-enter the **ent-srvsel** command specifying values that do not already exist in the database for the above parameters.
-

E4181 Cmd Rej: Specific SSN already exists**Commands Used: ent-srvsel**

You specified a command specifying a **gti/gtia/gtii/gtin, tt, np(v), nai(v)**, and a wildcard **ssn** that already has a matching specific **ssn** entry. (A wildcard **ssn** entry is specified with the use of asterisks). This duplication of entry is not allowed.

Recovery

1. Display the existing values for the above parameters. Enter the **rtrv-srvsel** command.
 2. Re-enter the **ent-srvsel** command specifying values that do not already exist in the database for the above parameters.
-

E4182 Cmd Rej: STP True PC and EIR Subsystem do not exist in MAP table

Commands Used: **ent-ss-appl**

To reserve an EIR subsystem number (**ssn**) for an application, the STP true point code/EIR subsystem number combination must be previously defined in the Mated Applications (MAP) table.

Recovery

1. Enter the **rtrv-sid** command to see the point codes (**pca/pci/pcn**) assigned to the system.
 2. Enter the **ent-map** command and assign mated application values for the true point code (**pc/pca/pci/pcn**) and the EIR subsystem number (**ssn**).
 3. Re-enter the **ent-ss-appl** command specifying the newly assigned values for **pc/pca/pci/pcn** and the EIR **ssn**.
-

E4183 Cmd Rej: INP or EIR feature must be ON

Commands Used: **ent-map**

Either the INAP Number Portability (INP) or the Equipment Identity Register (EIR) feature must be turned on before issuing this command when the PCN is a True Point Code.

NOTE: The INP and EIR features are mutually exclusive and controlled by separate methods. The INP feature is controlled using a feature bit. The EIR feature is controlled by enabling the controlled feature.

Recovery

1. Display the status of the INP and the EIR features. Enter the **rtrv-feat** command and the EIR feature **rtrv-ctrl-feat** commands.
2. If the INP or the EIR feature is turned on, re-enter the **ent-map** command.
Call your Customer Care Center if this error message appears again.

3. If both the INP and EIR features are off, perform either of the following:

- Turn on the INP features. Enter the **chg-feat:inp=on** command.

OR

- Turn on the EIR feature. Enter the **chg-ctrl-feat:eir=on** command.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature key is permanently enabled, it cannot be disabled. Refer to the appropriate *Feature Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

4. Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4184 Cmd Rej: EIR subsystem is offline in database

Commands Used: **alw-map-ss**

To run this command, the EIR subsystem must be online (activated) in the database.

Recovery

Activate the EIR subsystem. Enter the **chg-ss-appl:appl=eir:nstat=online** command.

E4185 Cmd Rej: EIR feature must be enabled

Commands Used: **dlt-ss-appl, rtrv-sid**

The Equipment Identity Register (EIR) feature is not enabled. You must enable the EIR feature before entering either the **rtrv-sid** command specifying the **cpctype=eir** parameter, or the **dlt-ss-appl** command specifying the **appl=eir** parameter.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the **rtrv-ctrl-feat** command.
2. Verify that the EIR feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.

3. Enable the EIR feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the “*Activating the EIR Feature*” procedure in the *Feature Manual - EIR*, and call your Customer Care Center before starting the process.

4. When the feature has been enabled, re-enter the command that generated this message.
-

E4186 Cmd Rej: GFLEX/GPORT/INP must be ON or EIR must be enabled

Commands Used: dlt-srvsel, rtrv-srvsel

The command you entered requires either the G-Flex, G-Port, or INP feature turned on, or the EIR feature must be enabled.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Feature Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** and the **rtrv-ctrl-feat** commands.
2. If the G-Flex, G-Port, or INP features are turned on, or the EIR feature is enabled re-enter the command.
Call your Customer Care Center if this error message appears again.
3. If the G-Flex, G-Port, and INP features are turned off and if the EIR feature is not enabled, you can either:

- Turn on any of the G-Flex, G-Port, or INP features. Enter the **chg-feat: gflex=on** or **chg-feat: gport=on** or **chg-feat: inp=on** commands.

OR

- Enable the EIR feature. Enter the **enable-ctrl-feat** command.

Refer to the “*Activating the EIR Feature*” procedure in the *Feature Manual - EIR*, and call your Customer Care Center before starting the process.

THEN

- Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4188 Cmd Rej: LNP or EIR must be enabled or INP must be ON**Commands Used: `rtrv-ss-appl`**

This command is not valid unless one of the following conditions is true: the Local Number Portability (LNP) feature is enabled or the Equipment Identity Register (EIR) feature is enabled or the INAP Number Portability (INP) feature is on.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Feature Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the `rtrv-feat` and the `rtrv-ctrl-feat` commands.
2. If the INP feature is turned on (`inp=on`), or the LNP ported TNs entry appears in the output of step 1, or the EIR feature is enabled, re-enter the `rtrv-ss-appl` command.

Call your Customer Care Center if this error message appears again.

3. If the INP feature is turned off (`inp=off`) and the LNP ported TNs entry does not appear in the output of step 1, and the EIR feature is not enabled, either:

- Turn on the INP feature. Enter the `chg-feat:inp=on` command.

OR

- Enable the LNP feature or EIR feature. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Refer to the Activating the Feature procedures in the *Database Administration Manual - LNP* or the *Feature Manual - EIR*. Call your Customer Care Center before starting the process.

THEN

- Re-enter the `rtrv-ss-appl` command that generated this message.

Call your Customer Care Center if this error message appears again.

E4189 Cmd Rej: SSN for ITU-I and ITU-N True Point Codes must be the same**Commands Used: `chg-map`, `ent-map`**

If you specify ITU-I, ITU-N, ITU-I Spare, and ITU-N Spare true point codes, you must specify the same subsystem number (`ssn`).

Recovery

Re-enter the command that generated this error message specifying the same **ssn** value for ITU-I, ITU-N, ITU-I Spare, and ITU-N Spare point codes.

E4191 Cmd Rej: GFLEX/GPORT/EIR feature must be on

Commands Used: **chg-gsmopts**

This command requires one of the following features turned on: G-Flex, G-Port, or EIR.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-feat** and the **rtrv-ctrl-feat** commands.
2. If the G-Flex or G-Port feature or EIR feature is on, re-enter the **chg-gsmopts** command.

Call your Customer Care Center if this error message appears again.

3. If the G-Flex, G-Port, and EIR features are off, either:
 - Turn on the G-Port or G-Flex features. Enter the **chg-feat:gflex=on** or **gport=on** command; call your Customer Care Center before starting the process.

OR

- Enable EIR feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.
- Turn on the EIR feature. Enter the **chg-ctrl-feat** command.

Refer to the *Activating the EIR Feature* procedure in the *Feature Manual - EIR*. Call your Customer Care Center before starting the process.

THEN

- Re-enter the **chg-gsmopts** command that generated this message.

Call your Customer Care Center if this error message appears again.

E4192 Cmd Rej: GFLEX or EIR feature must be on

Commands Used: `ent-trace`, `rtrv-data-rtddb`

The G-Flex or Equipment Identity Register (EIR) feature must be turned on before you can specify the **imsi** parameter.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Feature Manual* and to the *Commands Manual* for details about turning on features with bits and turning on features with feature keys.

Recovery

1. If the **imsi** parameter is not required to be specified, re-enter the command without specifying the **imsi** parameter.
2. If the **imsi** parameter is required to be specified, perform the following actions:
 - Display the features in the database. Enter the `rtrv-feat` and the `rtrv-ctrl-feat` commands.
 - Determine whether the G-Flex feature is turned on or the EIR feature is enabled.
 - If the G-Flex feature is turned on (`gflex=on`) or the EIR feature is enabled, re-enter the command.

Call your Customer Care Center if this error message appears again.

3. If the G-Flex feature is turned off (`gflex=off`) or the EIR feature is not enabled and turned on, either:
 - Turn on the G-Flex feature. Enter the `chg-feat:gflex=on` command.OR

NOTE: The GTT feature must be turned on before the EIR feature can be enabled.

 - If the GTT feature is on, enable the EIR feature. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Refer to the *Activating the EIR Feature* procedure in the *Feature Manual - EIR*, and call your Customer Care Center before starting the process.

 - Turn on the EIR feature using the `chg-ctrl-feat` command.
4. Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4193 Cmd Rej: Spare Point Code Feature must be enabled

Commands Used: `ent/chg-dstn`, `ent/dlt-cspc`, `ent/chg-map`,
`ent-na`, `ent/dlt/rtrv-spc`, `ent/chg/vfy-sid`,
`ent/chg/dlt/rtrv-scr-aftpc`, `ent/chg/dlt/rtrv-scr-cdpa`,
`ent/chg/dlt/rtrv-scr-cgpa`, `ent/chg/dlt/rtrv-scr-blkdpc`,
`ent/chg/dlt/rtrv-scr-blkopc`, `ent/chg/dlt/rtrv-scr-destfld`,
`ent/chg/dlt/rtrv-scr-dpc`, `ent/chg/dlt/rtrv-scr-opc`

The Spare Point Code feature must be enabled before the above commands can support Spare Point Code parameters.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* about enabling features with access keys.

Recovery

1. Display the status of features in your system that have feature access keys. Enter the `rtrv-ctrl-feat` command.
2. Verify the Spare Point Code feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the Spare Point Code feature. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual - Features* for more information about enabling this feature.

NOTE: The Spare Point Code feature cannot be enabled if TALI sockets have been provisioned for an IPGWI card.

4. Verify the Spare Point Code feature is enabled. Enter the `rtrv-ctrl-feat` command.
 5. Re-enter the command that generated this error message.
-

E4195 Cmd Rej: Spare Point Codes not supported with adapter type

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`

Spare Point Codes are not valid for TALI sockets.

Recovery

Re-enter the command without specifying Spare Point Codes.

E4196 Cmd Rej: Spare Point Code Feature not compatible with TALI socket

Commands Used: `chg-appl-sock`, `enable-ctrl-feat`, `ent-appl-sock`

The Spare Point Code feature cannot be enabled if TALI sockets have been provisioned for an IPGWI card.

Recovery

Contact your Customer Care Center if you need assistance.

E4197 Cmd Rej: CCGT and NGTI are mutually exclusive

Commands Used: `chg-gta`, `ent-gta`

You cannot specify both the Cancel Called Global Title Indicator (`ccgt`) and New GTI Code (`ngti`) parameters together in the same command.

Recovery

Re-enter the command specifying either the `ccgt` or `ngti` parameter but not both.

E4198 Cmd Rej: Can't switch existing Pfx/Sfx, use RMGTT to reset

Commands Used: `chg-gtt`

You cannot switch the existing prefix or suffix digit manipulation parameters. Neither can you specify both prefix digit manipulation and suffix digit manipulation parameters because they are mutually exclusive. To change the values from prefix to suffix or the reverse, first use the `rmgtt` parameter to reset the Modified Global Title Translation feature (MGTT) fields.

Recovery

1. Reset the MGTT fields. Enter the `chg-gtt:rmgtt=yes` command.
 2. Re-enter the `chg-gtt` command specifying either the prefix digit manipulation or suffix digit manipulation parameters.
-

E4199 Cmd Rej: NGTI only valid when PC and TYPE are different domains

Commands Used: `chg-gtt`, `ent-gtt`

The New GTI Code (**ngti**) parameter is valid only when the translated point code (**pc**) and translation type (**type**) are different domains.

Recovery

1. Verify all point codes and the domains that they are assigned to. Enter the `rtrv-dstn` command. The domain of each point code is shown in the DOMAIN field in the output.
 2. Re-enter the original command specifying the **ngti** parameter with a translation point code (**pc**) whose domain does not match the domain of the translation type (**type**).
-

E4200 Cmd Rej: Cannot use NEXT if preceding RTRV-LOG command used TYPE=ALL

Commands Used: `rtrv-log`

You specified the **next** parameter that followed a `rtrv-log` command specifying the **type=all** parameter. You cannot use the **next** parameter with the **type=all** parameter. This sequence of commands is not supported.

Recovery

Re-enter the `rtrv-log` command without specifying the **next** parameter.

Refer to the *Commands Manual* for detailed information about the use of this command.

E4201 Cmd Rej: SCCPCNV, TCAPCNV must be disabled

Commands Used: `enable-ctrl-feat`

The attempt to enable the ANSI-ITU-China SCCP Conversion feature was unsuccessful. It is mutually exclusive with the SCCPCNV (SCCP Conversion) feature bit and TCAPCNV (TCAP Conversion) feature bit.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

Display the features in the database. Enter the **rtrv-feat** command to verify the status of the SCCPCNV and TCAPCNV features and the **rtrv-ctrl-feat** command to verify the status the ANSI-ITU-China SCCP Conversion feature.

Call your Customer Care Center if this error message appears again.

E4202 Cmd Rej: SCCP Conversion feature requires at least TSM Hardware

Commands Used: **enable-ctrl-feat**

You cannot enable the ANSI-ITU-China SCCP Conversion feature because a required TSM card is missing. You need to upgrade the hardware.

Recovery

1. Upgrade your hardware to at least the TSM hardware required for the SCCP Conversion feature.
2. Re-enter the **enable-ctrl-feat** command.

Call your Customer Care Center if this error message appears again.

E4203 Cmd Rej: ENUM requires an SNUM as its mate parameter

Commands Used: **rtrv-log**, **rtrv-trbltx**

You specified the **enum** parameter but not with its mate parameter, **snum**. When **enum** is specified, the **snum** parameter is required too.

Recovery

Re-enter the command specifying values for the mate parameters **enum** and **snum**.

E4204 Cmd Rej: ENUM must be greater or equal to mate parameter SNUM

Commands Used: **rtrv-log**, **rtrv-trbltx**

The **enum** value must be equal to or greater than the **snum** value.

Recovery

Re-enter the command specifying the **enum** value equal to or greater than the **snum** value.

E4205 Cmd Rej: ENUM range does not match SNUM: 1-999 or 1000-1499

Commands Used: `rtrv-log`, `rtrv-trbltx`

You specified the **enum** value not in the same range as its mate parameter, **snum**. Both parameters must be in the same range, either **1-999** (for UAMs) or **1000-1499** (For UIMs).

Recovery

Re-enter the command specifying the **enum** value in the same range as its mate parameter, **snum**.

E4206 Cmd Rej: NEXT requires this term issued last valid RTRV-LOG command

Commands Used: `rtrv-log`

Because the **next** parameter extends a previous command, the system requires that the `rtrv-log:next=n` command be entered from the same terminal without any intervening `rtrv-log` commands from this or any other terminal. This **next** option command was either the first `rtrv-log` command from the issuing terminal or another `rtrv-log` command was received from another terminal in the interval between the first and second command from this terminal.

Recovery

Re-enter the `rtrv-log` command without specifying the **next** parameter. To extend the display of UAM or UIM log entries, re-enter the `rtrv-log` command specifying the **next** parameter, while making certain that no other terminal enters an intervening `rtrv-log` command.

E4208 Cmd Rej: No other parameters are permitted with the NEXT parameter

Commands Used: `rtrv-log`

The command entered is invalid because the **next** parameter was specified along with another parameter. When the **next** parameter is specified, no other parameters can be specified.

Recovery

Re-enter the **rtrv-log** command specifying only the **next** parameter.

E4209 Cmd Rej: OUTGRP and SNUM/ENUM combination invalid**Commands Used: rtrv-trbltx**

You cannot specify both the **outgrp** and **snum/enum** parameters. When the **outgrp** parameter is specified, the **snum** and **enum** parameters cannot be specified.

Refer to the *Commands Manual* for detailed information about the use of the **rtrv-trbltx** command.

Recovery

Re-enter the **rtrv-trbltx** command specifying either the **outgrp** parameter or the **snum/enum** parameters.

E4210 Cmd Rej: TYPE and SNUM/ENUM combination invalid**Commands Used: rtrv-log, rtrv-trbltx**

You specified an invalid combination of values for the **type** and **snum/enum** parameters. The values specified for **type** did not agree with the **snum/enum** parameter values.

Recovery

Re-enter the command specifying corresponding values for the **type** and **snum/enum** parameters.

E4211 Cmd Rej: If DIR=BKWD, SDATE/STIME must be > EDATE/ETIME**Commands Used: rtrv-log**

The command entered is invalid because it specified incorrect **date/time** parameters when **dir=bkwd** (direction is a backward search). For a backward search direction, the specified **sdate/stime** must be greater than the **edate/etime**.

Recovery

Re-enter the **rtrv-log** command specifying **sdate/stime** values greater than the **edate/etime**.

E4212 Cmd Rej: Cannot execute command until table initialization complete**Commands Used: rtrv-log**

You entered a command that cannot be executed until the table initialization of the ELOG and UIM logs has completed. Please wait until the table has been initialized (that is, the maintenance baseline is established).

Recovery

When the table initialization of the ELOG and UIM logs has completed, you can re-enter the **rtrv-log** command.

E4213 Cmd Rej: Current set of next elog entries have been overwritten**Commands Used: rtrv-log**

Since the previous entry of a **rtrv-log** command, a number of UAMs and/or UIMs have been logged. Consequently, the pointer to the next log to display has been overwritten by those alarms occurring since the original **rtrv-log** command was entered. Because the pointer was overwritten by system activity, you cannot use the **next** parameter until you enter a new **rtrv-log** command without a **next** parameter.

Recovery

Re-enter the **rtrv-log** command without specifying the **next** parameter.

Refer to the *Commands Manual* for detailed information about the use of the **rtrv-log** command.

E4214 Cmd Rej: LOC and E1PORT parameter combination must be specified**Commands Used: inh-alm, unhb-alm**

You specified the **dev=e1port** parameter, which requires that both the **loc** and the **e1port** parameters be specified.

Recovery

Re-enter the command specifying **dev=e1port** and the **loc** and **e1port** parameters.

Refer to the *Commands Manual* for detailed information about the use of this command.

E4215 Cmd Rej: LOC and T1PORT parameter combination must be specified

Commands Used: **inh-alm**, **unhb-alm**

You specified the **dev=t1port** parameter, which requires that both the **loc** and the **t1port** parameters be specified.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4216 Cmd Rej: Linkset cannot be the mate of another linkset

Commands Used: **chg-ls**, **dlt-ls**

The specified linkset is already the mate of another linkset. A linkset can have only one mate.

Recovery

1. Display the mates of specified linksets with the **rtrv-ls** command. The output displays mates of other linksets under the **MATELSN** heading.
 2. Using the output from step 1, verify that the correct **matelsn** was specified.
If the **matelsn** was correct, then delete that linkset as a mate from the other linkset that specifies it as a **matelsn**.
 3. Re-enter the command that generated this error message specifying a linkset (**lsn=**) that is not the mate of another linkset.
-

E4217 Cmd Rej: Linkset cannot reference self as mate**Commands Used: chg-ls**

You cannot specify the linkset itself as the mate. A mate to a linkset must be another unique linkset.

Recovery

Re-enter the **chg-ls** command that generated this error message specifying a linkset (**lsn=**) that is not itself.

E4218 Cmd Rej: A mated linkset cannot have more than one link assigned**Commands Used: chg-ls**

The command is invalid because the linkset specified as a mate has more than one signaling link assigned to it. A mated linkset can have only one signaling link.

Recovery

1. Display the mates of specified linksets with the **rtrv-ls** command. The output displays mates of other linksets under the **MATELSN** heading.
 2. Based on the output from step 1, verify that the correct **matelsn** was specified. If the correct **matelsn** was specified, then the number of signaling links assigned to that linkset must be reduced to one in order to allow the linkset to be referenced as a **matelsn**.
-

E4219 Cmd Rej: Mated linksets must contain only SS7IPGW or IPGWI links**Commands Used: chg-ls**

The command is invalid because the **lsn** or **matelsn** parameter refers to a linkset that contains a non-IPGWx signaling link.

Recovery

Re-enter the **chg-ls** command that generated this error message specifying the **matelsn** parameter a mate linkset that is an IPGWx linkset.

E4220 Cmd Rej: Mated linksets must have APCs of same network type**Commands Used: chg-1s**

The command is invalid because the parameter and the adjacent point code parameter (**apc, apca, apci, apcn, apcn24**) are different network linkset types. Mated linksets must have APCs that share a common network type.

Recovery

Verify that the specified linksets and APC are correct. If they are correct, change the APC of either linkset so that the network types are the same.

E4221 Cmd Rej: Card having link in linkset must first be inhibited**Commands Used: chg-1s**

The specified card was not OOS-MT-DSBLD (out of service - maintenance disabled). The command is invalid because the card hosting the signaling link in the specified linkset is not inhibited.

Recovery

1. Display the status of the card, specified in the command that generated this message, with the **rept-stat-card** command, specifying the card location. The primary state of the card is shown in the PST field.
 - If the primary state of the card displayed in step 1 is not OOS-MT-DSBLD, make the primary state of the card OOS-MT-DSBLD. Enter the **rmv-card** command. Go to step 2.
 - If the primary state of the card displayed in step 1 is OOS-MT-DSBLD, go to step 2.
 2. Re-enter the **chg-1s** command that generated this message.
Call your Customer Care Center if this error message appears again.
-

E4222 Cmd Rej: Card having link in mate linkset must first be inhibited**Commands Used: chg-1s**

The specified card was not OOS-MT-DSBLD (out of service - maintenance disabled). The command is invalid because the card hosting the signaling link in the specified mate linkset is not inhibited.

Recovery

1. Display the status of the card, specified in the command that generated this message, with the **rept-stat-card** command, specifying the card location. The primary state of the card is shown in the PST field.
 - If the primary state of the card displayed in step 1 is not OOS-MT-DSBLD, make the primary state of the card OOS-MT-DSBLD. Enter the **rmv-card** command and go to step 2.
 - If the primary state of the card displayed in step 1 is OOS-MT-DSBLD, go to step 2.
 2. Re-enter the **chg-1s** command that generated this message.
Call your Customer Care Center if this message appears again.
-

E4223 Cmd Rej: Action requires either SAPC or MATELSN, not both

Commands Used: chg-1s

If you specify **action=delete**, you must also specify either the **sapc** or **matelsn** parameters, but not both.

Recovery

Re-enter the **chg-1s** command that generated this error message specifying the **action=delete** parameter to delete a link that is either a **sapc** or **matelsn**.

E4224 Cmd Rej: Up to 8 SS7IPGW or IPGWI links allowed in un-mated linkset

Commands Used: ent-slk

You cannot assign more than eight SS7IPGW or IPGWx signaling links to an unmated linkset. For an unmated linkset, a maximum of eight SS7IPGW or IPGWx signaling links are allowed per linkset.

Recovery

1. Verify that the card in the specified location is running an unmated SS7IPGW or IPGWx application. Enter the **rtrv-card** command.

2. If the card is not running an unmated SS7IPGW or IPGWx application, re-enter the **ent-slk** command specifying the correct card location.
 3. If the unmated linkset already has eight links assigned, you cannot assign another link to it. You may choose to change current assignments (**chg-slk**) or use a different linkset to make the assignment.
-

E4225 Cmd Rej: Mate already exists for linkset

Commands Used: **chg-ls**

You cannot assign a mate linkset (**matelsn**) to a linkset that already has an assigned mate linkset. Only one mate linkset per linkset is supported.

Recovery

1. Display the mates of specified linksets. Enter the **rtrv-ls** command. The MATELSN heading displays linkset mates.
 2. Using the output of step 1, verify that the correct **lsn** was specified and that it already has a **matelsn** assigned.
 3. You can either:
 - Accept the current mate linkset assignment,
OR
 - Change the assigned mate linkset by first issuing the **chg-ls:action=delete** command to delete the currently assigned **matelsn** from the linkset. Then enter **chg-ls:action=add** to assign another **matelsn** to the linkset.
-

E4234 Cmd Rej: RI must be GT when specifying NGT

Commands Used: **chg-gtt**, **ent-gtt**

You specified the **ngt** parameter without also specifying the **ri=gt** parameter.

NOTE: This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error message specifying both the **ngt** parameter and the **ri=gt** parameter.

E4235 Cmd Rej: NGT can only be specified when XLAT=DPC or DPCNGT

Commands Used: `chg-gtt`, `ent-gtt`

You specified the **ngt** parameter without also specifying the **xlat=dpc** or **xlat=dpcngt** parameter. The **ngt** parameter can only be specified when **xlat=dpc** or **xlat=dpcngt**.

NOTE: This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error messages specifying both the **ngt** parameter and either the **xlat=dpc** or **xlat=dpcngt** parameter.

E4236 Cmd Rej: RI must be GT when specifying NTT

Commands Used: `chg-gta`, `ent-gta`

You specified the **ntt** parameter without also specifying the **ri=gt** parameter. When the ANSI-ITU-China SCCP Conversion feature is on and the **ntt** parameter is specified, the **ri=gt** parameter must be specified.

NOTE: This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error message specifying both the **ntt** parameter and the **ri=gt** parameter.

E4237 Cmd Rej: NTT can only be specified when XLAT=DPC or DPCNGT

Commands Used: `chg-gta`, `ent-gta`

You specified the **ntt** parameter without also specifying the **xlat=dpc** or **xlat=dpcngt** parameter. When the ANSI-ITU-China SCCP Conversion feature is on, the **ntt** parameter can be specified only when the **xlat** parameter value is **dpc** or **dpcngt**.

NOTE: This error message is generated only when the ANSI-ITU-China SCCP Conversion feature is enabled.

Recovery

Re-enter the command that generated this error message specifying both the **ntt** parameter and either the **xlat=dpc** or **xlat=dpcngt** parameter.

E4238 Cmd Rej: Point code matches a STP secondary point code.

Commands Used: **ent-dstn**

The Signal Transfer Point (STP) validates the command to ensure that the specified destination address does not correspond to the STP's secondary point code.

Recovery

1. Display the site destination secondary point codes (SPCs) in the system. Enter the **rtrv-spc** command. The SPCs are shown in the SPC, SPCA, SPCI or SPCN24 outputs.
 2. Re-enter the **ent-dstn** command specifying a secondary point code (**spc**) that is not shown in the outputs of step 1.
-

E4239 Cmd Rej: At least one other optional parameter is required

Commands Used: **chg-gsmmap-scrn**, **rtrv-data-rtdb**

The command that you entered requires at least one additional parameter to be specified.

Recovery

Perform one of the following actions:

- If you used the **chg-gsmmap-scrn** command, re-enter the command and do not specify the **cdsr** parameter and do specify at least one of these other required parameters: **naction**, **ncdsr**, **ncgsr**, **nforbid**, **npc/npca/npci/npcn/npcn24**, or **nssn**.
- OR
- For the **rtrv-data-rtdb** command, re-enter the command specifying the **loc** parameter and at least one of the following parameters: **imsi**, **dn**, **entity**, or **imei**.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4240 Cmd Rej: GFLEX or GPORT feature must be ON

Commands Used: `rtrv-data-rtdb`

For the `rtrv-data-rtdb` command, the G-Flex or G-Port feature must be on before you can specify the `dn` and/or `entity` parameters.

Recovery

Display the features in the database. Enter the `rtrv-feat` command.

- If the G-Flex or G-Port feature is on (shown in the output of step 1), re-enter the `rtrv-data-rtdb` command that generated this error message specifying the `dn` and/or `entity` parameters.
- If the G-Flex or G-Port feature is off (shown in the output of step 1), verify that the G-Flex or G-Port feature is purchased and installed in the system. Contact your Customer Care Center for assistance.
 - If the feature is purchased and installed, refer to the procedure in the *Feature Manual - G-Flex* or *Feature Manual - G-Port* and the *Commands Manual* to enable and turn the feature on.
 - Re-enter the `rtrv-data-rtdb` command specifying the `dn` and/or `entity` parameters.

Call your Customer Care Center if this error message appears again.

E4241 Cmd Rej: Link test must not be running on requested link

Commands Used: `act-cdl`, `act-lbp`, `dact-lbp`

You entered this command while a `tst-slk` command was running. These tests cannot be performed simultaneously.

Recovery

Perform one of the following actions:

- Wait for the current test to complete. Determine the status of the signaling links currently under test. Enter the `rept-stat-tstslk` command.

OR

- Stop the current test with the **tst-slk:action=stop** command for the appropriate card and link. Then re-enter the original command that prompted this error.

OR

- Re-enter the original command that prompted this error specifying a different card and link.

Call your Customer Care Center if this error message appears again.

E4242 Cmd Rej: Requested link must not be in command driven loopback

Commands Used: **act-lbp**, **dact-lbp**, **tst-slk**

You entered this command while the specified signaling link was already performing a command-driven loopback. These tests cannot be performed simultaneously.

Recovery

Perform one of the following actions:

- Stop the command-driven loopback with the **dact-cdl** command for the appropriate card and link. Then you can re-enter the command that generated this error message.

OR

- Re-enter the command that generated this error message specifying a different card and link.

Call your Customer Care Center if this error message appears again.

E4243 Cmd Rej: Link test command in progress

Commands Used: **tst-slk**

You entered this command for a specified signaling link that is already performing a link test. All link test commands are rejected until the current test is completed.

Recovery

Perform one of the following actions:

- Wait for the current test to complete. Determine the status of the signaling links currently under test. Enter the **rept-stat-tstslk** command.

OR

- Stop a link test with the **tst-slk:action=stop** command for the appropriate card and link. Then re-enter the **tst-slk** command that generated this error message.

OR

- Re-enter the **tst-slk** command that generated this error message specifying a different card and link.

Call your Customer Care Center if this error message appears again.

E4244 Cmd Rej: Link test command not in progress

Commands Used: **tst-slk**

You attempted to stop a link test, but the specified link test is not currently in progress. The **action=stop** parameter is invalid if a link test is not active.

Recovery

1. Verify that the card location and link are specified correctly.
 2. Use the **rept-stat-tstslk** command report to confirm the status of the signaling links currently under test.
 3. If you are certain the specified card location and link have a link command in progress and this command continues to fail, call your Customer Care Center for assistance.
-

E4245 Cmd Rej: Card does not support command driven loopback

Commands Used: **act-cdl**, **rept-stat-cdl**

The card in the specified card location (**loc**) does not support command-driven loopback.

Recovery

1. Enter the **rtrv-card** command to verify the card type and application at the specified location is one of the following:
 - An AINF LIM (card type **limds0**, **limocu**, **limv32** and either application **ss7ansi** or **ccs7itu**), or
 - A multi-port LIM (card type **limds0** and application **ss7ansi**), or
 - An E1/T1 MIM (card type **lime1**, **limt1**, or **limch** and either application **ss7ansi** or **ccs7itu**), or **limatm**, or **lime1atm**
 2. Re-enter the command and specify an **loc** that supports command-driven loopback.
-

E4246 Cmd Rej: Command driven loopback in progress

Commands Used: **act-cd1**

You entered this command for a specified signaling link that is already performing a command-driven loopback test. All command-driven loopback test commands are rejected until the current test is stopped.

Recovery

Perform one of the following actions:

- Stop the command-driven loopback test. Enter the **dact-cd1** command specifying the appropriate card and link. Re-enter the **act-cd1** command that generated this error message.
- OR
- Re-enter the **act-cd1** command that generated this error message specifying a different card and link.

Call your Customer Care Center if this error message appears again.

E4247 Cmd Rej: Command driven loopback not in progress

Commands Used: **dact-cd1**

You attempted to deactivate a command-driven loopback on a signaling link that is not currently in command-driven loopback but is running a link test.

Recovery

1. Determine the status of the signaling links currently in a command-driven loopback. Enter the **rept-stat-cdl** command.
 2. If you are certain the specified card location and link are in the process of a command-driven loopback and this command continues to fail, call your Customer Care Center for assistance.
-

E4248 Cmd Rej: Card GPL state conflict

Commands Used: **init-flash**

Dependent GPL must be activated. The card cannot support a valid version of BLBIOS and BLCPLD at the same time

Recovery

You must either remove the resident version before activating a new one, or you must activate the resident version before activating a new version.

E4249 Cmd Rej: Mate linkset not defined

Commands Used: **chg-ls**

You specified a mate linkset (**matelsn**) that is not defined. The mate linkset that is successfully assigned to a linkset must be one that is already equipped in the linkset database.

Recovery

1. Display the existing linksets. Enter the **rtrv-ls** command linksets.
 2. Perform one of the following:
 - Re-enter the **chg-ls** command and specify another mate linkset from those listed in the output of step 1 that is suitably equipped as a mate linkset.OR
 - Create a new linkset that is intended to be assigned as the original linkset's mate linkset. Enter the **ent-ls** command.
-

E4250 Cmd Rej: Linkset does not reference MATELSN

Commands Used: `dact-cd1`

The command is invalid because **action=delete** was specified and the linkset is not mated to the linkset specified by the **matelsn** parameter.

Recovery

Re-enter the `dact-cd1` command specifying both the **lsn** and **matelsn** parameters.

E4251 Cmd Rej: IPTPS required for IPGWx linksets

Commands Used: `chg-ls`, `ent-ls`

The **iptps** parameter must be specified for IPGWx linksets.

Recovery

Re-enter the command that generated this error message specifying the **iptps** parameter.

Call your Customer Care Center if this error message appears again.

E4252 Cmd Rej: IPTPS not allowed for non-IPGWx linksets

Commands Used: `ent-ls`

You cannot specify the **iptps** parameter for non-IPGWx linksets.

Recovery

Re-enter the `ent-ls` command that generated this error message without specifying the **iptps** parameter.

Call your Customer Care Center if this error message appears again.

E4253 Cmd Rej: LSUSEALM not allowed for non-IPGWx linksets

Commands Used: `chg-ls`, `ent-ls`

You cannot specify the **lsusealm** parameter for non-IPGWx linksets.

Recovery

Re-enter the command that generated this error message without specifying the **lsusealm** parameter.

Call your Customer Care Center if this error message appears again.

E4254 Cmd Rej: SLKUSEALM not allowed for non-IPGWx linksets

Commands Used: **chg-ls**, **ent-ls**

You cannot specify the **slkusealm** parameter for non-IPGWx linksets.

Recovery

Re-enter the command that generated this error message without specifying the **slkusealm** parameter.

Call your Customer Care Center if this error message appears again.

E4255 Cmd Rej: Total IPTPS for all linksets can't exceed system TPS limit

Commands Used: **chg-ls**, **ent-ls**

The specified command attempted to define more IPTPS values than the existing current IPGWx System IP TPS increments can support. This error indicates the sum of all TPS values, including the one being entered, exceeds the system limit that is set with the IPGWx System IP TPS feature key.

Recovery

1. Display the System TPS in the database with the **rtrv-ctrl-feat** command. Then display the IPTPS values for the existing linksets with the **rtrv-ls** command. (The error occurs when the sum of the provisioned System TPS plus the new TPS being defined is greater than the system TPS limit).
2. Perform one of the following solutions:
 - Reduce the TPS for other linksets with the **chg-ls** command, orOR

- Reduce the TPS for the linkset that was being entered or changed, or
OR
- Obtain the key for more System TPS.

NOTE: For information about expanding your System TPS limit, contact your Customer Care Center for assistance.

E4256 Cmd Rej: IPTPS must be divisible by 10

Commands Used: `chg-ls`, `ent-ls`

The value specified for the `iptps` parameter must be divisible by 10.

Recovery

Re-enter the command specifying a value for the `iptps` parameter that is divisible by 10.

E4257 Cmd Rej: Entity must be specified when Entity type is specified

Commands Used: `rtrv-data-rtdb`

For the `rtrv-data-rtdb` command, the `entity` parameter must be specified if the `entitytype` parameter is specified.

Recovery

Re-enter the `rtrv-data-rtdb` command specifying both the `entitytype` and `entity` parameters.

E4258 Cmd Rej: Target card is not a DSM card with VSCCP appl

Commands Used: `rtrv-data-insrv`, `rtrv-data-rtdb`

The card specified by the `loc` parameter is not a DSM card running the VSCCP application.

Recovery

1. Display the cards in the system. Enter the **rtrv-card** command. DSM VSCCP cards are identified by the entries DSM in the TYPE field and VSCCP in the APPL field in the **rtrv-card** command output.
 2. Re-enter the command specifying the **loc** parameter of a DSM card with the VSSCP application.
-

E4259 Cmd Rej: Target card is not in Active state

Commands Used: **rtrv-data-rtdb**, **rtrv-data-insrv**

The card specified by the **loc** parameter is not in an active state. The specified target card must be in an active state.

Recovery

1. Display the cards in the system. Enter the **rept-stat-card** command. The command output shows ACTIVE status cards in the Secondary State (SST) entries, DSM cards in the TYPE field, and VSCCP applications in the APPL field.
 2. Re-enter the command specifying a card location (**loc**) for a active DSM VSCCP card.
-

E4260 Cmd Rej: Cluster DPCs can't inherit A or E linkset types

Commands Used: **ent-dstn**

Cluster destination point codes (DPCs) cannot inherit cluster members that have routes with A or E linkset types.

Recovery

Re-enter the **ent-dstn** command specifying a B, C, or D linkset type.

E4262 Cmd Rej: A specified SI value must be 3 for SUA

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`, `ent-as`

If specified, the service indicator (**si**) parameter must be (**si=3**) for routing keys that are associated with SUA Application Servers.

For SCCP MSU traffic, the routing key service indicator (**si**) value associated with an AS containing SUA ASPs must be **3** (SCCP) for the following key types:

- DPC-SI-SSN key
- DPC-SI key
- SI-only key

Recovery - `chg-appl-rtkey`, `ent-appl-rtkey`

Re-enter the command specifying **si=3**

Recovery - `ent-as`

1. Display the routing keys and **si** values. Enter the `rtrv-appl-rtkey` command.
 2. Assign a valid **si** value to the appropriate routing key. Enter the `chg-appl-rtkey` command.
 3. Re-enter the `ent-as` command to create the AS.
-

E4264 Cmd Rej: Parameter PCST / NPCST is not allowed with C for blocked SR

Commands Used: `chg/dlt/ent/rtrv-scr-aftpc`,
`chg/dlt/ent/rtrv-scr-cdpa`, `chg/dlt/ent/rtrv-scr-cgpa`,
`chg/dlt/ent/rtrv-scr-blkdpc`, `chg/dlt/ent/rtrv-scr-blkopc`,
`chg/dlt/ent/rtrv-scr-destfld`, `chg/dlt/ent/rtrv-scr-dpc`,
`chg/dlt/ent/rtrv-scr-opc`

A command and parameter combination is not allowed:

- The command **ent-scr-blkopc** or **ent-scr-blkdpc** with combination of parameter **pcst** and subparameter **c** is not allowed for a blocked screening reference (SR).
- The command **chg-scr-blkopc** or **chg-scr-blkdpc** with combination of parameter **pcst** or **npcst** and subparameter **c** is not allowed for a blocked screening reference (SR).
- The parameter **pcst** can not be used with an ANSI point code parameter (**ni**, **nc**, **ncm**) or with an ITU-N24 point code parameter (**sa**, **ssa**, **sp**).

Recovery

Re-enter the command specifying the correct parameter combination.

E4265 Cmd Rej: Network Appearance table full

Commands Used: `ent-na`

The Network Appearance table can contain a maximum of **45** entries.

Recovery

Call your Customer Care Center.

E4266 Cmd Rej: Channel bridged slave port is invalid for link provisioning

Commands Used: `ent-slk`

Provisioning of signaling links on a bridged slave E1/T1 port is not allowed while channel bridging is activated.

Recovery

Re-enter the `ent-slk` command specifying a channel bridged master E1/T1 port.

E4267 Cmd Rej: Invalid timing source for channel bridging

Commands Used: `ent-e1`, `chg-e1`, `ent-t1`, `chg-t1`

To use the `chanbrdg` parameter, you must also specify a timing source (`e1tsel`). The timing source valid entries are master (internal), slave (line), or recovered from its paired port.

NOTE: The `e1tsel=line` parameter cannot be specified if the specified HC-MIM E1 port is in channel bridging mode (`chanbrdg=on`).

The argument value for e1 timing selector is "external" for EAGLE® release 28.1. For older releases the argument is "internal".

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands

E4268 Cmd Rej: Cannot delete last route to DPC ref. in CSPC table

Commands Used: `dlt-rte`

You cannot delete the last route to the specified destination point code (DPC) that is referenced by a Concerned Secondary Point Code (CSPC) group. If this route were to be deleted while these references existed, the CSPC groups would contain point codes with no routes to the nodes identified by those point codes.

Recovery

1. Display information about this route and the DPC it points to. Enter the `rept-stat-rte` command.
 2. Delete the DPC references from the assigned CSPC group(s).
 3. Re-enter the `dlt-rte` command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E4269 Cmd Rej: No match on PCST parameter during retrieve

Commands Used: `rtrv-scr-aftpc`, `rtrv-scr-cdpa`, `rtrv-scr-cgpa`,
`rtrv-scr-blkdpc`, `rtrv-scr-blkopc`, `rtrv-scr-destfld`,
`rtrv-scr-dpc`, `rtrv-scr-opc`

No match was found for the point code subtype (`pcst`) parameter.

Recovery

Enter the command specifying the screening reference to show all next screening function identifiers, as well as other values for the screening reference.

E4270 Cmd Rej: Failed reading Application Socket table

Commands Used: `enable-ctrl-feat`

The Application Socket table could not be read.

Recovery

Verify that an Application Socket table entry exists with the parameter values you specified. Enter the `rtrv-appl-sock` command.

- If an entry does exist, re-enter the `enable-ctrl-feat` command that generated this error message.
OR
- Re-enter the `enable-ctrl-feat` command specifying different socket connection parameters.
OR
- If an entry does not exist, create an Application Socket table entry specifying the desired parameter values. Enter the `ent-appl-sock` command.
 - Re-enter the `enable-ctrl-feat` command that caused this message.

Call your Customer Care Center if this error message appears again.

E4272 Cmd Rej: Maximum RContexts per AS exceeded

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`, `ent-as`

The AS is already associated with 4 different routing contexts (or 4 different routing keys with routing context).

Recovery

1. Display the routing keys and routing context values. Enter the `rtrv-appl-rtkey:display=all` command.

2. Create an AS with new routing keys and routing context.
OR
 3. Change the routing key routing context.
 - The routing context value in a routing key may only be changed if all of the ASPs associated with the routing key are **open=no**. For SPLIT AS routing key changes, the old AS and the new AS must both meet this criteria.
 - The routing context value in a routing key may not be changed during the same command as a RESIZE or SPLIT routing key change.
 - A routing key containing a routing context may only be deleted if all of the ASPs associated with the routing key are **open=no**.
-

E4273 Cmd Rej: Private PC not allowed for non-IPGW linkset

Commands Used: **chg-ls**, **ent-ls**

The private (**p-**) and private and spare (**ps-**) point codes can only be assigned to IPGW linksets (**ipgwapc=yes** is specified).

Recovery

Determine the type of route. Enter the **rtrv-rte** command.

- If the route is a non-IPGW route, re-enter the command that generated this error message without specifying the private (**p-**) and private and spare (**ps-**) point codes.
OR
 - If the route is an IPGW route. Re-enter the command specifying the correct private (**p-**) and private and spare (**ps-**) point codes.
-

E4274 Cmd Rej: Cannot mix Unchannelized and Channelized modes on E1 card

Commands Used: **ent-e1**, **chg-e1**

Channelized and un-channelized E1PORT mixed mode is not allowed on a single card.

Recovery

1. Verify the E1PORT setting for the card location in question. Enter the **rtrv-e1** command.
 2. Re-enter the command specifying the correct format and parameters.
Refer to the *Commands Manual* for detailed information about the use of these commands.
-

E4275 Cmd Rej: TS not allowed when SEHSL feature has set Linkclass = Unchan

Commands Used: ent-slk

An E1PORT which has been provisioned for SE-HSL (**linkclass-unchan**) does not allow use of the timeslot parameter (**ts**) for this command.

Recovery

1. Verify the E1PORT setting for the card location in question. Enter the **rtrv-e1** command and verify the E1PORT setting for the card location in question.
 2. Re-enter the **ent-slk** command specifying the correct format and parameters.
Refer to the *Commands Manual* for detailed information about the use of the **ent-slk** command.
-

E4276 Cmd Rej: If specified BPS must be 1984000 when Linkclass = Unchan

Commands Used: ent-slk

The value specified for the **bps** parameter is not allowed. If the link class is specified as unchannelized (**linkclass=unchan**) by the **ent-e1** command, then the specified bits-per-second rate must be **1984000 (bps=1984000)** for SE-HSL signaling links. If **bps** is not specified, it will default to **1984000**.

Recovery

Re-enter the **ent-slk** command specifying the correct format and parameters.
Refer to the *Commands Manual* for detailed information about the use of the **ent-slk** command.

E4277 Cmd Rej: LINKCLASS=UCH is not valid for even numbered card loc

Commands Used: `ent-e1`

You cannot specify the `linkclass=unchan` parameter for even-numbered card locations.

Recovery

Re-enter the `ent-e1` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `ent-e1` command.

E4278 Cmd Rej: APCNTYPE parameter is only valid for ITUN/ITUN24 link sets

Commands Used: `ent-ls`, `chg-ls`

You specified an adjacent point code value that is ANSI or ITUI, and specified the `apctype` parameter. The `apctype` parameter can be specified only for linksets that have an ITUN or ITUN24 adjacent point code defined for them in the same `ent/chg-ls` command.

The point code parameter must be `apcn` or `apcn24` (not `apc`, `apca`, or `apci`) when the `apctype` parameter is specified in the same command.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4279 Cmd Rej: Only IPGW routes are allowed for private PCs

Commands Used: `ent-rte`, `chg-rte`

You cannot specify a private point code as the destination point code (`dpca/dpci/dpcn`) for a non-IPGW route. A destination point code cannot be a private point code for a link set that is not an IP gateway route.

Recovery

Re-enter the command that generated this error message without specifying a **Private point code prefix**.

OR

Verify the route is an IPGW route. Enter the **rtrv-rte** command.

Re-enter the command specifying the Private point code prefix.

E4280 Cmd Rej: Alias PCs exceed Max allowed for Feature Quantity

Commands Used: enable-ctrl-feat

You cannot enable the 7000 Routesets feature and the 8000 Routesets feature because **8000** alias point codes are already assigned in the system.

Recovery

1. Display the number of provisioned aliases. Enter the **rtrv-dstn** command.
 2. If **8000** aliases are provisioned, use either **dlt-dstn** to delete destination point code entries or use **chg-dstn** to delete aliases (**chg-dstn=none**) for destination point codes until the number of provisioned aliases is less than **8000**.
 3. Verify less than **8000** aliases are provisioned. Enter the **rtrv-dstn** command.
 4. Enable the 7000/8000 Routesets feature. Enter the **enable-ctrl-feat** command.
-

E4281 Cmd Rej: Specified link not supported for SE-HSL

Commands Used: ent-slk

You specified the **link** parameter with a value that is not allowed. An HC-MIM card that is used for SE-HSL un-channelized links, can only have **link=a** or **link=b** specified. If the card is an E5-E1T1 used for SE-HSL links, only the **link=a** parameter can be specified.

Recovery HC-MIM card

1. Verify the E1 port setting for the card location in question. Enter the **rtrv-e1** command.
2. Re-enter the **ent-slk** command specifying **link=a** or **link=b** for SE-HSL un-channelized links.

Refer to the *Commands Manual* for detailed information about the use of the **ent-slk** command.

Recovery E5-E1T1 card

1. Verify the E1 port setting for the card location in question. Enter the **rtrv-e1** command.
2. Re-enter the **ent-s1k** command specifying **link=a** for SE-HSL un-channelized links.

Refer to the *Commands Manual* for detailed information about the use of this command.

E4282 Cmd Rej: A SEHSL feature key must be enabled to provision SEHSL

Commands Used: **ent-e1**

The SE-HSL feature must be enabled before you can provision unchannelized E1 links. An SE-HSL feature quantity must be enabled before the **linkclass=unchan** parameter can be specified for an SE-HSL card.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as on/off features can be turned on and off using the **chg-ctrl-feat** command. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for more information about enabling features with access keys.

Recovery

1. Display the SE-SHL feature status in the database. Enter the **rtrv-feat** and the **rtrv-ctrl-feat** commands.
2. Enable the SE-HSL feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information. .

Refer to the *Commands Manual* and the *Database Administration Manual - System Management* for more information

3. Turn the SE-HSL feature bit on. Enter the **chg-ctrl-feat** command.
 4. When the SE-SHL feature is enabled and turned on, re-enter the **ent-e1** command to provision the unchannelized E1 links.
-

E4283 Cmd Rej: Command cannot be executed on a Telnet terminal

Commands Used: `act-file-trns`, `act-upgrade`, `lock`

The specified command can not be issued from a Telnet terminal (terminal IDs 17 to 40). You cannot initiate an upgrade conversion from a Telnet terminal. You cannot initiate a transfer of files in the File Transfer Area from a Telnet terminal.

Recovery

1. The `lock` command is invalid and cannot be performed from a Telnet terminal.
2. For the `act-upgrade` command:
 - Display a list of valid terminal choices. Enter the `rtrv-trm` command. If the entry in the TYPE column is TELNET, the terminal is not a valid choice.
 - Re-enter the `act-upgrade` command specifying a valid (non-Telnet) value for the `trm` parameter.

Refer to the *Commands Manual* for detailed information about the use of the `act-upgrade` command.

E4284 Cmd Rej: CGPA entry can't be provisioned

Commands Used: `ent-gsmmap-scrn`

Your command to provision a CgPA entry was unsuccessful because the CgPA entry cannot be provisioned in the GSMSCRN table when only one entry space is available. Two spaces are required because a default wildcard CdPA entry is also automatically created for each CgPA entry you create.

Recovery

1. Delete at least two entries from the GSMSCRN table. Enter the `dlt-gsmmap-scrn` command.
 2. Re-enter the `ent-gsmmap-scrn` command to add the desired CgPA entry to the GSMSCRN table.
-

E4285 Cmd Rej: Enhanced GSM Map Screening feature must be ON

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-ls`,
`ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-ls`

The Enhanced GSM MAP Screening (EGMS) feature must be on when certain parameters are specified. Refer to the Recovery procedures below for the commands and remedial actions required.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* about enabling features with access keys.

To correct conditions identified by the following Recovery list, perform the Recovery procedure 'Verifying the EGMS Feature' below.

Recovery - `chg-gsmmap-scrn`

EGMS feature must be turned on when:

- `npc` or `npca` is specified
 - `cdsr` or `ncdsr` is specified
-

Recovery - `chg-gsms-opcode`

EGMS feature must be turned on when: - `npc` or `npca` is specified

Recovery - `ent-gsmmap-scrn`

EGMS feature must be turned on when:

- `saddr=*`
 - `saddr` or `eaddr` contains hex digits
 - `cdsr` is specified
 - `pc` or `pca` is specified
-

Recovery - ent-gsms-opcode

EGMS feature must be turned on when:

- **opcode=***
 - **pc** or **pca** is specified
-

Recovery - ent-ls

EGMS feature must be turned on when - **gsmscrn=on** for ANSI linkset

Recovery - Verifying the EGMS Feature

Review the command and verify the need for the EGMS parameters:

1. If the EGMS parameters are not required, re-enter the **ent-ls** command.
2. If the EGMS feature is required, verify the EGMS feature is enabled and turned on. Display the installed features in the database. Enter the **rtrv-ctrl-feat** command.

- If the EGMS feature is enabled and turned on, re-enter the **ent-ls** command.

Call your Customer Care Center if this error message appears again.

- If the EGMS feature is not enabled, enable the feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.
- Turn on the EGMS feature. Enter the **chg-ctrl-feat:egms=on** command.

Refer to the *Database Administration Manual - Features*. Call your Customer Care Center before starting this process.

3. When the EGMS feature is on, re-enter the original command.
-

E4286 Cmd Rej: EADDR shouldn't be specified when SADDR = *

Commands Used: **ent-gsmmap-scrn**, **rtrv-gsmmap-scrn**

You specified the **saddr=*** parameter, so the **eaddr** parameter is not needed and not allowed.

Recovery

Re-enter the command without specifying the **eaddr** parameter.

E4287 Cmd Rej: CDSR does not exist in the database

Commands Used: **chg-gsmmap-scrn**, **dlt-gsmmap-scrn**,
rtrv-gsmmap-scrn

You entered a command containing an OPNAME and CGSR for which a CdPA Screening Reference (**cdsr**) does not exist.

Recovery

1. Enter the **rtrv-gsmmap-scrn** command to display the existing GSM MAP Screening CDSR entries.
 2. Re-enter the command, and specify parameters identifying a **cdsr** appearing in the output of step 1.
-

E4288 Cmd Rej: NCGSR shouldn't be specified when CDSR is specified

Commands Used: **chg-gsmmap-scrn**

If you specify the **cdsr** parameter, you cannot also specify the **ncgsr** parameter.

Recovery

Re-enter the **chg-gsmmap-scrn** command specifying either the **ncgsr** or the **cdsr** parameter, but not both.

E4289 Cmd Rej: (N)CGSR already exists for specified OPNAME

Commands Used: **chg-gsmmap-scrn**, **ent-gsmmap-scrn**

You specified a CgPA Screening Reference (**cgsr**) or New CgPA Screening Reference (**ncgsr**) that already exists for the opname (user-defined name for Op-Code). The **cgsr** or **ncgsr** parameters cannot be created because the specified opname is already defined.

Recovery

1. Display the existing GSM MAP Screening CgPA entries. Enter the **rtrv-gsmmap-scrn** command.
 2. Re-enter the command specifying a value for the **cgsr** or **ncgsr** parameters that is not in the output from step 1.
-

E4290 Cmd Rej: CDSR must be specified when NCDSR is specified

Commands Used: **chg-gsmmap-scrn**

You cannot specify the **ncdsr** parameter without specifying the **cdsr** parameter.

Recovery

Re-enter the **chg-gsmmap-scrn** command and specify both the **cdsr** and **ncdsr** parameters.

E4291 Cmd Rej: Enhanced GSM Map Screening feature must be enabled

Commands Used: **dlt-gsmmap-scrn**, **rtrv-gsmmap-scrn**,
rtrv-gsms-opcode

The command you entered requires the Enhanced GSM MAP Screening (EGMS) feature to be enabled.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the *Database Administration Manual - Features* and to the *Commands Manual* for details about enabling features with access keys.

Recovery

1. Review the command and verify the need for the EGMS parameters. If the EGMS parameters are not required, re-enter the command without them.
2. If the EGMS feature is required, display the status of the installed features with feature access keys. Enter the **rtrv-ctrl-feat** command.
3. If the EGMS feature is enabled, re-enter the command.
4. If the EGMS feature is not enabled, verify the EGMS feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.

5. Enable the EGMS feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling this feature.

6. Re-enter the command that generated this error message..

Call your Customer Care Center if this error message appears again.

E4292 Cmd Rej: SADDR must be specified when EGMS feature is OFF

Commands Used: ent-gsmmap-scrn

You must specify the Starting Origination Address (**saddr**) parameter for the **ent-gsmmap-scrn** command when the Enhanced GSM MAP Screening (EGMS) feature is off.

Recovery

Perform one of the following actions:

- Re-enter the **ent-gsmmap-scrn** command and specify the **saddr** parameter.
- OR
- Turn on the EGMS feature. Enter the **chg-ctrl-feat** command specifying the appropriate part number.

Refer to the *Commands Manual* for detailed information about the use of this command.

E4293 Cmd Rej: (N)CDSR already exists for specified CGSR

Commands Used: chg-gsmmap-scrn, ent-gsmmap-scrn

You specified a CdPA Screening Reference (**cdsr**) or a new CdPA Screening Reference (**ncdsr**) that already exists for the CgPA Screening Reference (**cgSR**). The CdPA entry cannot be created because the specified **cdsr** or **ncdsr** already exists.

Recovery

1. Display the existing GSM MAP Screening CdPA entries. Enter the `rtrv-gsmmap-scrn` command.
 2. Re-enter the command specifying a value for the `cdsr` or the `ncdsr` parameter that is not in the output from step 1.
-

E4294 Cmd Rej: Meas for Enh GSM MAP Screening not supported on EOAM

Commands Used: `rept-meas`

You cannot generate a Measurements Report on an Enhanced Operations, Administration, and Maintenance (EOAM) card. The `rept-meas` command cannot be used to generate Enhanced GSM MAP Screening measurements.

Recovery

Enter the `rept-ftp-meas` command.

Refer to the *Commands Manual* for detailed information about the use of this command.

Call your Customer Care Center if this error message appears again.

E4295 Cmd Rej: The FEATURE/ANSIGFLEX option combination is invalid

Commands Used: `chg-feat`, `chg-stpopts`

You cannot specify `ansigflex=yes` when any of these features are turned on: G-Port, INP, or EIR. The ANSI G-Flex at 1700 TPS feature (that is, the `ansigflex` system option) is mutually exclusive with the G-Port, INP, or EIR features. To enable the ANSIGFLEX option, the GPORT, INP and EIR features must be off.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for the details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the feature status in the database. Enter the `rtrv-feat` and the `rtrv-ctrl-feat` commands.

2. If the G-Port and INP features are off (see the **rtrv-feat** output) and the EIR feature is off (shown by the **rtrv-ctrl-feat** output), you must first disable the ANSI G-Flex at 1700 TPS system option (**chg-stpopts:ansigflex=no**) to turn on the other feature(s).
 3. If the G-Port, INP, or EIR feature are on (shown in the output of step 1), you cannot issue the **chg-stpopts:ansigflex=yes** command specifying **ansigflex=yes**. For assistance, contact your Customer Care Center.
-

E4296 Cmd Rej: SRVSEL of ITU found, but not allowed with ANSIGFLEX

Commands Used: chg-stpopts

You cannot enter the **chg-stpopts:ansigflex=yes** command when a DSM service selector (SRVSEL) contains an ITU entry. The ANSI G-Flex at 1700 TPS feature supports only ANSI systems.

Recovery

If the service selector specifies an ITU entry, perform one of the following actions:

- Re-enter the **chg-stpopts** command without specifying the **ansigflex=yes** parameter
- OR
- Delete ITU service selectors from the SRVSEL for the DSM, and then re-enter the **chg-stpopts:ansigflex=yes** command.
-

E4297 Cmd Rej: ITU entries not allowed when ANSIGFLEX is on

Commands Used: chg-srvsel, ent-srvsel

You cannot specify any ITU service selector entries if **ansigflex=yes**. The ANSI G-Flex at 1700 TPS feature is mutually exclusive with any ITU entries.

Recovery

You cannot specify an ITU entry if the **ansigflex=yes** parameter has been specified for the system.

1. Disable the **ansigflex** system option. Enter the **chg-stpopts:ansigflex=no** command.
 2. Re-enter the command specifying ITU service selector.
-

E4298 Cmd Rej: Alias PC table is full

Commands Used: `chg-dstn`, `ent-dstn`

You cannot provision more than **8000** entries in the Alias PC table. If the 8000 Routesets feature key is enabled, a maximum of **8000** alias PCs entries can be provisioned.

Recovery

1. Display the number of provisioned aliases in the Alias PC table. Enter the `rtrv-dstn` command.
 2. If 8000 entries are provisioned, perform one of the following actions:
 - Delete destination point code entries until the number of provisioned aliases is less than **8000**. Enter the `dlt-dstn` command.OR
 - Delete aliases for destination point codes until the number of provisioned aliases is less than **8000**. Enter the `chg-dstn=none` command.
 3. Re-enter the command that generated this error message.
-

E4299 Cmd Rej: Cannot enter a wildcard with XLAT=2, Use XLAT=4 for wildcard

Commands Used: `chg-gtcnv`, `dlt-gtcnv`, `ent-gtcnv`

If you specify `gtixlat=22` and `dir=itoe`, you cannot also use a wildcard entry. You can, however, use a wildcard entry and `dir=itoe` if you specify `gtixlat=24`.

Recovery

Re-enter the command specifying a wildcard entry and `dir=itoe`, if you specify `gtixlat=24`.

E4300 Cmd Rej: Conns cannot exist in rtkeys with and without rcontext

Commands Used: `chg-appl-rtkey`, `ent-appl-rtkey`,

An attempt was made to enter or change the routing context value of a routing key value already associated with an AS that is not allowed. An AS can not be simultaneously assigned to routing keys with routing contexts and to routing keys without routing contexts. All the routing key(s) associated with an AS must either have routing contexts or all the routing key(s) associated with an AS must not have routing contexts.

-
-

Recovery **chg-appl-rtkey, ent-appl-rtkey**

1. Enter the **rtrv-appl-rtkey:display=all** command to display the routing keys and routing context values.
 2. Determine if the routing key you wish to create or change is assigned to an AS.
 3. If the routing key is already assigned to an AS, re-enter the command specifying an appropriate routing context value for the routing key.
 4. If you wish to assign the routing key to an AS, re-enter the command ensuring that either (1) all the routing key(s) associated with an AS have routing contexts, or (2) all the routing key(s) associated with an AS have no routing contexts.
 5. If the routing key is already assigned to an AS and you wish to delete the routing context, you must first delete all routing keys associated with the AS and then re-enter routing keys without routing context values for the AS. The last RTKEY assigned to an AS cannot be deleted unless all associations in the AS provisioned for the RTKEY are OPEN=NO.
-

E4301 Cmd Rej: PCx specified does not exist as a True Point Code

Commands Used: **chg-sid**

The specified point code does not exist as a True Point Code (STP destination point code). The PCI /PCN value specified must already exist as an STP destination point code.

Recovery **chg-sid**

1. Determine the STP self-identity destination point code, CLLI, and capability point codes associated with the STP in its active database. Enter the **rtrv-sid** command.
2. Verify the PCx value exists. The PCx value must exist to use the **chg-sid** command.

Refer to the specific command and “*Point Code Formats and Conversion*,” in the *Commands Manual* for information on the correct values.

3. Re-enter the **chg-sid** command specifying a valid PCx value.
-

E4302 Cmd Rej: NPCx cannot be specified without PCx

Commands Used: chg-sid

For the **chg-sid** command:

- If you specify the **npci** parameter, you must also specify the **pci** parameter.
- If you specify the **npcn** parameter, you must also specify the **pcn** parameter.

Recovery

Re-enter the **chg-sid** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **chg-sid** command.

E4317 Cmd Rej: Failed reading VENDID table

Commands Used: ent-vendid, dlt-vendid, rtrv-vendid

The Vendor ID table is corrupt or it cannot be found by the system. The Vendor ID table contains the vendor identification information.

Recovery

Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4318 Cmd Rej: VENDID already exists in VENDID table

Commands Used: ent-vendid

The specified ID entry is already present in the Vendor ID table. To change vendor information, you must first delete the vendor ID and create a new one.

Recovery

Re-enter the **ent-vendid** command specifying a different ID.

OR

1. Display the entries in the Vendor ID table. Enter the **rtrv-vendid** command.
 2. Delete an entry before creating a new entry. Enter the **dlt-vendid** command.
 3. Create a new entry. Enter the **ent-vendid** command.
-

E4319 Cmd Rej: VENDID does not exist in VENDID table

Commands Used: dlt-vendid

The specified vendor ID entry does not exist in the Vendor ID table.

Recovery

1. Display the entries in the Vendor ID table. Enter the **rtrv-vendid** command.
 2. Re-enter the **dlt-vendid** command specifying the appropriate vendor ID.
-

E4320 Cmd Rej: SRI Redirect Feature must be enabled

Commands Used: ent-vendid, rtrv-vendid, chg-prefix

The GSM MAP SRI Redirect feature must be enabled before provisioning is allowed.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off with the **chg-ctrl-feat** command. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for more information about enabling features with access keys.

Recovery

1. Display features in the database. Enter the **rtrv-feat** and **rtrv-ctrl-feat** commands.

2. If the correct feature or features are turned on (see the output of step 1), re-enter the command that generated this message.
3. If the correct feature or features are turned off (see the output of step 1):
 - Verify that you have purchased and installed the correct features for your system. Contact your Customer Care Center if you need assistance.
 - Enable the G-Port feature. Enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information. Turn the G-Port feature on. Enter the **chg-ctrl-feat** command. Enable the PPSMS Phase 1 feature, G-Port MNP Circular Route Prevention feature, Portability Check for Mobile Originated SMS, or GSM MAP SRI Redirect to Serving HLR. Enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.
 - Re-enter the command that generated this message.

Refer to the *Commands Manual* and *Feature Manual - G-Port Manual* for additional details.

Call your Customer Care Center if this error message appears again.

E4321 Cmd Rej: All VENDID table entries must be of length VENDIDLEN

Commands Used: ent-vendid

All vendor ID entries must be of the specified length value for VENDIDLEN. VENDIDLEN determines the allowed length for all Vendor ID values and must be entered before any VEND=Vendor ID value is allowed.

As long as there are no entries in the VendID list, VENDIDLEN may be changed.

Recovery

1. Use **rtrv-vendid** to display the VENDIDLEN in the vendor ID table.
 2. Re-enter the **ent-vendid** command specifying the appropriate VENDIDLEN for the vendor ID.
-

E4322 Cmd Rej: VENDIDLEN may only be changed if VENDID table is empty

Commands Used: ent-vendid

The VENDIDLEN value may only be changed if the Vendor ID list is empty. VENDIDLEN determines the allowed length for all Vendor ID values and must be entered before any VEND=Vendor ID value is allowed.

Recovery

Re-enter the command specifying the appropriate VENDIDLEN.

OR

1. Display the Vendor ID table. Enter the **rtrv-vendid** command.
 2. Delete all Vendor ID table entries. Enter the **dlt-vendid** command.
 3. Create a new VENDIDLEN value, then create a new Vendor ID table entries. Enter the **ent-vendid** command.
-

E4323 Cmd Rej: Invalid condition value comparison for CA or CB register.

Commands Used: **ent-bp**

The condition value specified for comparison of the CA or CB registers is invalid.

Recovery

Re-enter the **ent-bp** command specifying a valid set of condition values.

Refer to the *Commands Manual* for detailed information about the use of the **ent-bp** command.

E4325 Cmd Rej: ELAP architecture does not support LNP quantity requested

Commands Used: **enable-ctrl1-feat**

You cannot enable 192 Million LNP feature because the ELAP version installed does not support the quantity requested by the feature. To enable the 192 Million LNP feature, the installed ELAP version must be 5.0 or higher.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Enter the **rept-stat-mps** command to determine the ELAP version installed.

2. If the installed ELAP version is not 5.0 or higher, you must upgrade the software level. Contact your Customer Care Center for assistance.
3. If the installed ELAP version is 5.0 or higher (or after the software has been upgraded), enter the appropriate ELAP commands to convert the 120 Million database structure to the data compaction structure for 192 Million numbers.
4. Re-enter the **enable-ctrl-feat** command to enable the 192 Million LNP feature.

Call your Customer Care Center if this error message appears again.

E4326 Cmd Rej: ELAP must be available to verify LNP quantity support

Commands Used: **enable-ctrl-feat**

You cannot enable an LNP feature greater than 96 Million because no ELAP is currently available. To enable LNP quantities above 96 Million, an ELAP must be available to validate its software version.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Determine if ELAP is installed. Enter the **rtrv-ctrl-feat** command.
2. If ELAP is not installed, contact your Customer Care Center for assistance.
3. After ELAP is installed and configured, re-enter the command to enable the LNP feature.

Call your Customer Care Center if this error message appears again.

E4327 Cmd Rej: For VENDNUM specified the prefix is not provisioned

Commands Used: **ent-vendid**

For the vendor number specified, the prefix for feature GSM MAP SRI Redirect is not provisioned.

Recovery

1. Use **chg-prefix** to provision a prefix for the GSM MAP SRI Redirect feature.
 2. Re-enter the **ent-vendid** command that generated this message.
-

E4328 Cmd Rej: IS412GSM must be provisioned before SERVERPFX**Commands Used: chg-gsmopts**

The IS-41-to-GSM Migration parameter, **chg-gsmopts:is412gsm=x**, must be provisioned before specifying the **serverpfx** parameter.

Recovery

1. Use **chg-gsmopts** to provision **is412gsm**.
 2. Re-enter the **chg-gsmopts** command to specifying the **serverpfx** parameter.
-

E4329 Cmd Rej: Set SERVERPFX to NONE before disabling IS412GSM**Commands Used: chg-gsmopts**

The **serverpfx** parameter must be set to **none** before you can disable IS-41-to-GSM Migration feature

Recovery

1. Enter the **chg-gsmopts** command to set **serverpfx=none**.
 2. Re-enter the **chg-gsmopts** command to disable **is412gsm**.
-

E4330 Cmd Rej: Network Address conflicts with IP Route Table**Commands Used: chg-netopts**

The destination IP network address specified by the **pvn** and **pvnmask** parameters is the same as a route defined in the IP Route Table. This creates a conflict and is not allowed.

Recovery

1. Display the IP Route Table. Enter the **rtrv-ip-rte** command.

2. Delete the conflicting IP route. Enter the **dlt-ip-rte** command.
 3. Re-enter the **chg-netopts** command.
-

E4331 Cmd Rej: Specified network addr assigned to a IP card Ethernet Port

Commands Used: **chg-netopts**

The IP network address specified by the **pvn** and **pvnmask** parameters is the same IP network address assigned to Ethernet A or B of one of the IPLIMx or IPGWx cards.

Recovery

Re-enter the **chg-netopts** command specifying a different network address.

E4332 Cmd Rej: The specified network address is already assigned to the PVN

Commands Used: **chg-ip-lnk**, **chg-netopts**

The IP network address specified by the **ipaddr** and **submask** parameters is the same as the network address for the **pvn** and **pvnmask** parameters contained in the NETOPTS table.

Recovery

Re-enter the **chg-ip-lnk** or **chg-netopts** command specifying IP network addresses that are not the same for the PVN and the card's ethernet interface.

E4333 Cmd Rej: Cannot specify IP routes to the PVN

Commands Used: **ent-ip-rte**

You cannot specify a destination IP network address using the **dest** and the **submask** parameters that is the same as the network address specified by the **pvn** and **pvnmask** parameters defined in the NETOPTS table.

Recovery

Re-enter the **ent-ip-rte** command specifying a different network address. Use the **dlt-ip-rte** or **chg-netopts** command to resolve the conflicting network address.

E4334 Cmd Rej: Requires C-linksets parameter tfatcabmlq to be set to 0**Commands Used: chg-ss7opts**

The TFA/TCA Broadcast Minimum Link Quantity (**tfatcabmlq**) parameter for one or more C-linksets is not set to **0**. The linkset restrict (**lsrestrict**) parameter cannot be set to **off** until the **tfatcabmlq** parameter for all C-linksets is set to **0**.

You can change the default value of **tfatcabmlq** in C-linksets after the **lsrestrict** is turned **on**. The value of **tfatcabmlq** in any C-linkset it must be set to **0** before the **lsrestrict** option can be turned **off**. You cannot set the **lsrestrict** option to **off** until you set all C linkset **tfatcabmlq** values back to **0**.

When the **lsrestrict** option is **on**, the **tfatcabmlq** parameter value for C linksets can be changed to a non-zero value (see the **chg-ls** command). If the **tfatcabmlq** parameter in any C linkset has been changed to a non-zero value, the **tfatcabmlq** value must be set back to **0** for all C linksets before the **lsrestrict** option can be turned **off**.

Recovery

1. Display all linksets. Enter the **rtrv-ls** command. C-linksets are identified with a **C** in the LST field.
 2. For all C-linksets, set **tfatcabmlq=0**. Enter the **chg-ls** command.
 3. Re-enter the **chg-ss7opts** command to turn off **lsrestrict**.
-

E4335 Cmd Rej: Multiple CGSSN/SELID entries exist for specified selector**Commands Used: dlt-gttse1**

If multiple **cgssn/selid** entries exist for the specified global title selector, the selector cannot be deleted; However, if there is only one **cgssn/selid** entry, the selector can be deleted.

Recovery

Determine if multiple **cgssn/selid** entries exist for the specified global title selector. Enter the **rtrv-gttse1** command specifying the **gti** and **tt** parameters.

- If only one **cgssn/selid** entry exists for the specified global title selector, the selector can be deleted. Re-enter the **dlt-gttse1** command.
 - If multiple **cgssn/selid** entries exist for the specified global title selector, the selector cannot be deleted.
-

E4339 Cmd Rej: Common screening list feature invalid

Commands Used: `chg-cs1`, `dlt-cs1`, `ent-cs1`, `rtrv-cs1`

The common screening list feature specified is not valid. The part number (**pn**) parameter or feature name (**feature**) parameter identify the particular enabled screening feature for which the screening data will be associated. The specified feature name must be for a feature that uses a Common Screening List.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4340 Cmd Rej: Common screening list key invalid

Commands Used: `chg-cs1`, `ent-cs1`

The common screening list key specified is invalid. The specified feature and list type require a valid **ds** parameter.

Recovery

1. If you are attempting to change a common screening list, display a list of screening numbers for the specified feature and screening list name or a specific **ds** value for a particular feature and screening list name. Enter the `rtrv-cs1` command.

Refer to the *Commands Manual* for detailed information about the use of these commands.

2. Re-enter the command specifying the correct parameters.
-

E4342 Cmd Rej: Feature Prefix too short

Commands Used: `chg-prefix`

The feature prefix specified has a length that is less than the minimum prefix-length requirements for that feature-type. The length of the specified feature prefix is too short.

Recovery

Re-enter the **chg-prefix** command specifying a feature prefix of the correct length.

E4343 Cmd Rej: Feature Prefix too long**Commands Used: chg-prefix**

The specified feature prefix length is greater than the maximum prefix-length requirements for that feature-type. The length of the specified feature prefix is too long.

Recovery

Re-enter the **chg-prefix** command specifying the correct prefix length.

E4344 Cmd Rej: Maximum allowed Prefix values already entered for feature**Commands Used: chg-prefix**

The specified feature already has the maximum number of prefixes defined and no more are allowed. To add or change a prefix, you must first delete a prefix. Table 2-39 lists the number of allowed prefixes based on the feature name.

Table 2-39. Number of Allowed Prefixes

Feature Name	Number of Allowed Prefixes
GSM MAP SRI Redirect	3
ISUP NP with EPAP	7

Recovery

1. Display the provisioned prefix information for all features. Enter the **rtrv-prefix** command.
 2. Delete an entry based on the name of the feature, its Prefix, and PrefixNum value. Enter the **dlt-prefix** command.
 3. Re-enter the **chg-prefix** command to enter a different feature prefix.
-

E4345 Cmd Rej: Feature Prefix already exists**Commands Used: chg-prefix**

The specified feature prefix already exists. To add or change a prefix, you must first delete a prefix.

Recovery

Re-enter the **chg-prefix** command specifying a different feature prefix.

OR

1. Display the provisioned prefix information for all features. Enter the **rtrv-prefix** command to display the provisioned prefix information for all features.
 2. Delete an entry based on the name of the feature, its Prefix, and PrefixNum value. Enter the **dlt-prefix** command.
 3. Re-enter the **chg-prefix** command to enter a different feature prefix.
-

E4346 Cmd Rej: FEATPFX table full**Commands Used: chg-prefix**

The feature Prefix table is full. A maximum of **256** entries is allowed. To add or change a prefix, you must first delete a prefix.

Recovery

1. Display the provisioned prefix information for all features. Enter the **rtrv-prefix** command.
 2. Delete an entry from the Prefix table based on the name of the feature, its Prefix, and PrefixNum value. Enter the **dlt-prefix** command.
 3. Re-enter the **chg-prefix** command to enter a different feature prefix.
-

E4347 Cmd Rej: Feature Name is not valid**Commands Used: chg-prefix, dlt-prefix, rtrv-prefix**

The feature name specified is not valid. Either the name is not in the feature control list, or the feature does not support the use of prefix values.

The feature name must match an existing control feature.

Recovery

Re-enter the command specifying a valid feature name.

E4348 Cmd Rej: Feature Prefix Number invalid

Commands Used: **chg-prefix**

The value specified for the **prefixnum** parameter is not valid.

Recovery

Re-enter the **chg-prefix** command specifying a valid **prefixnum** parameter value.

E4349 Cmd Rej: Feature Prefix still in use

Commands Used: **dlt-prefix**

The prefix is being used by another feature. The prefix value or prefix number is associated with a feature with a different name.

Recovery

Re-enter the **dlt-prefix** command specifying a valid **feature** name.

E4350 Cmd Rej: Feature Prefix not found

Commands Used: **dlt-prefix**

The feature prefix specified is not in the FEATURE_PREFIX table.

Recovery

Re-enter the **dlt-prefix** command specifying a valid feature prefix.

E4352 Cmd Rej: SUBNETID table is full

Commands Used: `ent-subnetid`

The Subnet ID table maximum allowed number of entries is 50. To add a new entry, you must first delete an existing entry.

Recovery

1. Display the Subnet ID table information. Enter the `rtrv-subnetid` command.
 2. Delete a Subnet ID table entry. Enter the `dlt-subnetid` command.
 3. Re-enter the `ent-subnetid` command to enter a different subnet ID.
-

E4353 Cmd Rej: Failed reading SUBNETID table

Commands Used: `ent-subnetid`, `dlt-subnetid`, `rtrv-subnetid`

The subnet ID table is corrupt or it cannot be found by the system. The subnet ID refers to the network entity address of the HLR within an operator's network.

Recovery

Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4354 Cmd Rej: SUBNETID already exists in SUBNETID table

Commands Used: `ent-subnetid`

The specified Subnet ID entry already exists in the Subnet ID table. To add a new entry you must first delete (or change) an existing Subnet ID table entry.

NOTE: Up to 50 Subnet ID entries can be entered into the Subnet ID table.

Recovery

Re-enter the `ent-subnetid` command specifying a different `subnetid` value.

OR

1. Display the Subnet ID table. Enter the `rtrv-subnetid` command.
2. Change an existing Subnet ID entry. Enter the `chg-subnetid` command.

OR

1. Display the Subnet ID table. Enter the **rtrv-subnetid** command.
 2. Delete an existing Subnet ID entry. Enter the **dlt-subnetid** command.
 3. Add the new Subnet ID entry. Enter the **ent-subnetid** command.
-

E4355 Cmd Rej: SUBNETID does not exist in SUBNETID table

Commands Used: dlt-subnetid

The specified Subnet ID entry is not in the Subnet ID table.

Recovery

1. Display the Subnet ID table. Enter the **rtrv-subnetid** command.
 2. Re-enter the **dlt-subnetid** command specifying a valid Subnet ID entry.
-

E4356 Cmd Rej: ISUP NP with EPAP feature must be enabled

Commands Used: ent-subnetid, rtrv-subnetid, chg-prefix

The ISUP NP with EPAP feature must be enabled before provisioning is allowed.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off with the **chg-ctrl-feat** command. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for more information about enabling features with access keys.

Recovery

1. Display features in the database. Enter the **rtrv-feat** and **rtrv-ctrl-feat** commands.

NOTE: The G-Port feature and the GWS (Gateway Screening) feature must be turned on before the ISUP NP with EPAP feature can be enabled (see the **chg-feat** command).

- If the G-Port and GWS (Gateway Screening) features are enabled and turned on, enable the ISUP NP with EPAP feature.
 - Enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.
 - Re-enter the command that generated this message.
- If the G-Port and GWS (Gateway Screening) features are enabled and turned off perform the following actions:
 - Enter the **chg-ctrl-feat:gport=on** and **chg-ctrl-feat:gws=on** commands.

Refer to the *Commands Manual* and *Feature Manual - G-Port* for additional details.

- Enable the ISUP NP with EPAP feature, enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.
- Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4357 Cmd Rej: All SUBNETID table entries must be of length SUBNETIDLEN

Commands Used: ent-subnetid

All subnet ID entries must be of the length (number of digits) specified by **subnetidlen** parameter. The **subnetidlen** parameter defines the allowed length for all **subnetid** parameter values, and must be entered first, before the command is entered the second time to enter the Subnet ID and Subnet Number.

If there are no entries in the Subnet ID table, the value of the **subnetidlen** parameter may be changed.

Recovery

1. Determine the value of the **subnetidlen** parameter. Enter the **rtrv-subnetid** command.
2. Re-enter the **ent-subnetid:subnetidlen=xx** command specifying a value for **xx** from the output of step 1.
3. Add the Subnet ID and Subnet Number entries to the Subnet ID table. Re-enter the **ent-subnetid** command specifying the appropriate number of digits for all **subnetid** parameter values, as specified by the **subnetidlen** parameter.

Example:

```
ent-subnetid:subnetidlen=6  
ent-subnetid:subnetid=886933:subnetnum=1
```

E4358 Cmd Rej: SUBNETIDLEN may only be changed if SUBNETID table is empty**Commands Used:** ent-subnetid

The **subnetidlen** value may only be changed if the Subnet ID table is empty. The **subnetidlen** parameter determines the allowed length (number of digits) for all subnet ID values and must be entered before any subnet ID value can be entered.

Recovery

If the Subnetid table is empty, re-enter the command specifying the appropriate **subnetidlen**.

OR

1. Display the entries in the Subnet ID table. Enter the **rtrv-subnetid** command.
2. Delete all entries in the Subnet ID table. Enter the **dlt-subnetid** command.
3. Specify a new **subnetidlen** value. Enter the **ent-subnet:subnetidlen=xx** command where **xx** is any value from 1-15.
4. Add the Subnet ID and Subnet Number entries to the Subnet ID table. Re-enter the **ent-subnetid** command specifying the appropriate number of digits for all **subnetid** parameter values, as specified by the **subnetidlen** parameter.

Example:

```
ent-subnetid:subnetidlen=9  
ent-subnetid:subnetid=886445933:subnetnum=1
```

E4359 Cmd Rej: For SUBNETNUM specified the prefix is not provisioned**Commands Used:** ent-subnetid

The specified subnet number is not provisioned for the ISUP NP with EPAP feature prefix number.

For the ISUP NP with EPAP featureThe **subnetnum** parameter value corresponds to a previously defined entry in the Prefix table that matches the **prefixnum** parameter value and provides a reference to the **prefixnum**.

Recovery

1. Provision a prefix for the ISUP NP with EPAP feature. Enter the **chg-prefix** command.
 2. Re-enter the **ent-subnetid** command that generated this message.
-

E4360 Cmd Rej: VENDIDLEN must be set before Vendor ID may be entered**Commands Used: ent-vendid**

The **vendidlen** value must be specified before any Vendor ID may be entered. The **vendidlen** parameter determines the allowed length (number of digits) for all Vendor ID values and must be entered before any **vendorid** entries.

Recovery

1. Specify a value for the **vendoridlen** parameter. Enter the **ent-vendid:vendoridlen=x** command where **x** is a value from 1-15 digits.
 2. Re-enter the **ent-vendid** command to enter vendor ID values.
-

E4361 Cmd Rej: Enter param VENIDLEN, or params VENDID, VENDNUM and VENTYPE**Commands Used: ent-vendid**

The **ent-vendid** command is used to enter elements into the Vendor ID table, for the GSM MAP SRI Redirect to Serving HLR (aka GSM MAP SRI Redirect) feature.

The **vendidlen** parameter cannot be specified in the same command with the **vendid**, **vendidlen**, and **vendtype** parameters. Either the **vendidlen** parameter, or the **vendid**, **vendidlen**, and **vendtype** parameters can be specified in one command.

Recovery

Perform one of the following actions:

- Re-enter the **ent-vendid** command specifying the **vendidlen** parameter.
- OR
- Re-enter the **ent-vendid** command specifying the **vendid**, **vendidlen**, and **vendtype** parameters.
-

E4362 Cmd Rej: SUBNETDLEN must be set before Subnet ID may be entered

Commands Used: `ent-subnetid`

The **subnetidlen** value must be specified before any subnet ID may be entered. The **subnetidlen** determines the allowed length (number of digits) for all subnet ID values and must be specified before any **subnetid** value can be specified.

Recovery

1. Specify a value for the **subnetidlen** parameter. Enter the `ent-subnet:subnetidlen=xx` command where **xx** is any value from 1-15.
 2. Re-enter the `ent-subnetid` command to enter subnet ID values.
-

E4363 Cmd Rej: Enter params SUBNETIDLEN or paramrs SUBNETID and SUBNETNUM

Commands Used: `ent-subnetid`

The **subnetidlen** parameter cannot be specified in the same command with the **subnetid** and **subnetnum** parameters. Either the **subnetidlen** parameter, or the **subnetid** and the **subnetnum** parameters can be specified in one command.

Recovery

Perform one of the following actions:

- Re-enter the `ent-subnetid` command specifying the **subnetidlen** parameter.
- OR
- Re-enter the `ent-subnetid` command specifying the **subnetid** and the **subnetnum** parameters.
-

E4364 Cmd Rej: Failed reading FEATPFX

Commands Used: `chg-prefix`, `dlt-prefix`, `rtrv-prefix`

The feature prefix table is corrupt or it cannot be found by the system. The feature prefix table contains the feature and its relation to a prefix, and is used to reference the prefix from another table.

Recovery

Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4365 Cmd Rej: Either TLNP or ISUP NP with EPAP must be enabled

Commands Used: `chg-gws-actset`

To provision a GWS TLNP Stop Action, either the Triggerless LNP (TLNP) feature must be turned on, or the ISUP NP with EPAP feature must be enabled.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off with the `chg-ctrl-feat` command. Refer to the appropriate *Database Administration Manual* and the *Commands Manual* for more information about enabling features with access keys.

Recovery

1. Display features in the database. Enter the `rtrv-feat` and `rtrv-ctrl-feat` commands.
2. If the TLNP feature is turned on, or the ISUP NP with EPAP feature is enabled, re-enter the `chg-gws-actset` command that generated this message.
3. If the TLNP feature is turned off (see the output of step 1):
 - Turn on the TLNP feature. Enter the `chg-ctrl-feat:tlnp=on` command.

Refer to the *Commands Manual* for detailed information about the use of the `chg-ctrl-feat` command.

- Re-enter the `chg-gws-actset` command that generated this message.

Call your Customer Care Center if this error message appears again.

E4367 Cmd Rej: Cannot change network domain to anything other than CROSS

Commands Used: `chg-gttset`

You cannot specify any other values for the network domain (`netdom`) parameter other than `cross`.

Recovery

Re-enter the `chg-gttset` command specifying `netdom=cross`.

E4366 Cmd Rej: DEV type is not supported by specified location

Commands Used: `inh-alm`, `unhb-alm`

You specified a card location that does not support the device type specified. The `loc` parameter must be specified if the device `dev=card`, `slk`, `dlk`, `e1port`, or `t1port` parameter is specified.

Table 2-40 shows the valid parameter combinations for the `inh-alm` command. The `dur` and `lvl` parameters are valid with all `dev` parameter values.

Table 2-40. Parameter Combinations for the `inh-alm` Command

Value (:dev)	a p p l s o c k	a s c a r d	c a r d	c l o c	d l k	e 1 p o r t	l s	s c o n n	n d c l k	n d c q 3	r o u t e	s e a s x 2 5	s l k	t 1 p o r t	t r m
Device Parameter															
No Parameters				X						X					
:asname	X														
:dpc/dpca/dpci/dpcn/dpcn24											X				
:e1port=1-8						X									
:id			X												
:link/port=a, b					X								X		
:link/port=a, b, a1, a2, b1, b2, a3, b3													X		
:link/port=a1, a2, b1, b2								X	X			X			
:loc			X		X	X							X	X	
:lsn							X								
:sname	X														
:t1port=1-8														X	
:trm															X

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4368 Cmd Rej: The specified CMD cannot be assigned a configurable class

Commands Used: `chg-cmd`

The specified command cannot be assigned to a configurable class.

The **login** command is rejected as a parameter. The **login** command is available to all users, and can not be assigned to a configurable class.

Recovery

Re-enter the **chg-cmd** command.

Refer to the *Commands Manual* for detailed information about the use of the **chg-cmd** command.

Call your Customer Care Center if this error message appears again.

E4369 Cmd Rej: Cannot assign APC with exception routes to linkset

Commands Used: **ent-rtx**

You cannot provision exception routes for adjacent point codes. Adjacent point codes cannot have exception routes.

Recovery

Re-enter the **ent-rtx** command specifying a point code value that is not an adjacent point code.

E4370 Cmd Rej: Level 1 Alarm Threshold level must be less than Level 2

Commands Used: **chg-th-alm**

You specified an incorrect value for either the Level 1 or Level 2 Threshold Alarms. The setting for the Level 1 alarm threshold must be less than the setting for the corresponding Level 2 alarm threshold.

Recovery

Re-enter the **chg-th-alm** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **chg-th-alm** command.

E4374 Cmd Rej: Association in maximum allowed application servers**Commands Used: ent-as**

The maximum number of adapter states (M3U/SUA associations) for a single SS7IPW or IPGWI card is **50**. You must either select a different AS or delete or change the association assigned to the desired AS.

Recovery

Re-enter the **ent-as** command specifying a different AS.

Refer to the *Commands Manual* for detailed information about the use of the **ent-as** command.

OR

1. Display the AS and its associations. Enter **rtrv-as** command.
 2. Delete or change the association for the AS. Enter either the **dlt-assoc** or **chg-assoc** commands.
-

E4375 Cmd Rej: Route Exception already exists for input parameters**Commands Used: chg-rtx, ent-rtx**

A Route table entry already exists for the specified parameters.

Recovery

1. Display the Route table entries. Enter the **rtrv-rte** command.
 2. Re-enter the command specifying a different set parameters.
-

E4376 Cmd Rej: Maximum matching Route Exceptions already exist for DPC

Commands Used: `chg-rtx`, `ent-rtx`

Only one pair of identical Route Exception conditions, that differ only in their LSN assignment, may exist for a given DPC.

- For the **opc**, Incoming Link Set Name (**ilsn**), CIC range (**cic** and **ecic** values are not identical), and **si** criteria, only one pair of identical Route Exception conditions, that differ only in their LSN assignment, may exist for a given DPC.

ent-rtx:dpc=1-1-1:opca=6-*-*:ilsn=lset4:si=5:cic=0:ecic=16383

- For single CIC criteria, only one exception route per CIC value per **dpc** per route cost (**rc**).

Recovery

Perform one of the following actions:

- Re-enter the command specifying a different set of Route Exception parameters.

OR

- Delete one of the existing Exception Routes. Enter the `dlt-rtx` command.
 - Re-enter the command that generated this error message.
-

E4377 Cmd Rej: Maximum Route Exceptions already exist per DPC and Criteria

Commands Used: `ent-rtx`

A maximum of six Route Exceptions may be associated with the specified DPC and criteria.

Recovery

1. Display the Route table entries. Enter `rtrv-rte` command.
 2. Delete one of the route exception entries from the table that match the **dpc** and criteria. Enter the `dlt-rtx` command.
 3. Re-enter the `ent-rtx` command specifying the **dpc** and criteria to add the route exception.
-

E4378 Cmd Rej: Maximum Route Exceptions already exist for this STP

Commands Used: `ent-rtx`

The overall number of Route Exceptions and normal routes that may be defined for the EAGLE 5 ISS cannot be over **8000**.

Recovery

1. Display the Route table. Enter the `rtrv-rte` command.
 2. Delete a route exception from the Route table. Enter the `dlt-rtx` command.
 3. Add the route exception to the Route table. Enter the `ent-rtx` command.
-

E4379 Cmd Rej: Failed to access Route Exception Table

Commands Used: `chg-rtx`, `dlt-ls`, `dlt-rte`, `dlt-rtx`, `ent-rtx`, `rtrv-rtx`

The Route table is inaccessible. The Route table must be accessible.

Recovery

Re-enter the command that generated this error message.

Call your Customer Care Center if this error message appears again.

E4380 Cmd Rej: Route Exception does not exist

Commands Used: `chg-rtx`, `dlt-rtx`

The combination of Route Exception parameter conditions specified does not exist.

Recovery

1. Display the Route table. Enter the `rtrv-rtx` command.
 2. Re-enter the command specifying a valid combination of Route Exception parameters.
-

E4381 Cmd Rej: CIC Range overlaps an existing range

Commands Used: `ent-rtx`

You cannot specify a CIC range that overlaps an existing CIC range.

For example, the following command entry is not allowed because the specified starting and ending CIC ranges are the same:

```
ent-rtx:dpc=ansi pc:cic={0-16383}:ecic={0-16383}
```

Recovery

1. View the Route table. Enter the `rtrv-rtx` command.
 2. Re-enter the `ent-rtx` command specifying a CIC range that does not overlap an existing CIC range.
-

E4382 Cmd Rej: LSN and NLSN cannot be identical

Commands Used: `chg-rtx`

You cannot specify the same values for the linkset name (`lsn`) parameter and the new linkset name (`nlsn`) parameter.

Recovery

Re-enter the `chg-rtx` command specifying different values for the `lsn` and `nlsn` parameters.

E4383 Cmd Rej: Either NLSN or RC must be specified

Commands Used: `chg-rtx`

For the `chg-rtx` command, either the new linkset name (`nlsn`) parameter or the routing cost (`rc`) parameter must be specified.

Recovery

Re-enter the `chg-rtx` command specifying either the new linkset name (`nlsn`) parameter or the routing cost (`rc`) parameter.

E4384 Cmd Rej: Use type=remote or enter ipaddr in IPLNK table

Commands Used: `ent-ip-host`

The system detected the host as **type=local** but the IP address does not exist in the IP-LNK table. For local hosts, the IP address must exist in the IP-LNK table.

A remote host is one that resides in a different network or subnetwork. A local host resides within the EAGLE.

Recovery

If you are attempting to enter an IP host that does not reside in the EAGLE, then re-enter the `ent-ip-host` command specifying **type=remote**.

OR

Re-enter the `ent-ip-host` command specifying an IP address of an existing local host.

OR

1. Create a local host entry to configure an IPLNK entry. Enter the `chg-ip-lnk` command.

NOTE: An IPLNK entry must be provisioned before an IPHOST entry can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

2. Re-enter the `ent-ip-host` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `ent-ip-host` command.

E4385 Cmd Rej: Use type=local or remove ipaddr from IPLNK table

Commands Used: `ent-ip-host`

The system detected the host as **type=remote** but the IP address is assigned in the IP-LNK table. For remote hosts, the IP address must not exist in the IP-LNK table.

A remote host is one that resides in a different network or subnetwork. A local host resides within the EAGLE.

Recovery

If you are attempting to enter an IP host that resides in the EAGLE, then re-enter the command specifying **type=local**.

OR

1. Delete the IPHOST from the database. Enter the **dlt-ip-host** command specifying the correct IP address.

NOTE: An IPLNK entry must be provisioned before an IPHOST entry can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

2. Delete the IPLNK entry. Enter the **chg-ip-lnk:ipaddr=0.0.0.0** command.
3. Re-enter the **ent-ip-host** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **ent-ip-host** command.

E4386 Cmd Rej: IP Address found in host table

Commands Used: **chg-ip-lnk**

You attempted to change an IP address to a remote host but a corresponding IPHOST entry to that IP address is assigned.

NOTE: An IPLNK entry must be provisioned before an IPHOST entry can be provisioned with a corresponding IP Address. Similarly, the IPHOST entry must be deleted before the IPLNK entry with a corresponding IP Address can be set to 0.0.0.0.

Recovery

1. Display the IP links in the database. Enter the **rtrv-ip-lnk** command.
2. Display the IP hosts in the database. Enter the **rtrv-ip-host** command.
3. Using the outputs of steps 1 and 2, determine the IPHOST assigned to the IP address that generated the error message.
4. Delete the IPHOST from the database. Enter the **dlt-ip-host** command specifying the information found in step 3.
5. Re-enter the **chg-ip-lnk** command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the **chg-ip-lnk** command.

E4387 Cmd Rej: OPC must not be identical to DPC

Commands Used: `chg-rtx`, `ent-rtx`

For the `ent-rtx` command, if `dpc=pointcode1:opc=pointcode2`. The values specified for `pointcode1` and `pointcode2` cannot not be the same.

Recovery

Re-enter the command specifying different values for the `pointcode1` and `pointcode2` parameters.

E4388 Cmd Rej: Exception route cannot be assigned to adjacent point code

Commands Used: `ent-rtx`

For the `ent-rtx` command, you cannot specify a Destination Point Code that is also an Adjacent Point Code.

Recovery

Re-enter the `ent-rtx` command specifying a value for the `dpc` parameter that is not an Adjacent Point Code.

E4389 Cmd Rej: BOOT=NO not supported for specified gpl

Commands Used: `init-flash`

The boot parameter can not be set to NO if the gpl being downloaded is BLCPLD. The HCMIM card must be booted after the BLCPLD is downloaded.

Recovery

Re-enter the `init-flash` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `init-flash` command.

E4391 Cmd Rej: Exception route cannot be assigned to cluster members

Commands Used: `ent-rtx`

An exception route cannot be assigned to cluster members if only the Nested Cluster Routing feature is turned on. However, if the Nested Cluster Routing is also turned on, it is allowed.

This error can occur if Cluster Routing is provisioned and a point code with an asterisk network cluster member sub-field (e.g.: 1-1-*) is in the Route table and there is an attempt to add an exception route and a full point code specified (e.g.: `dpc=1-1-9`).

Recovery

1. Turn on the Nested Cluster Routing feature. Enter the `chg-feat:ncr=on` command.
 2. Re-enter the `ent-rtx` command.
-

E4392 Cmd Rej: Assigned SLKs must be deleted before apcntype can be changed

Commands Used: `ent-ls`, `chg-ls`

You cannot change the value of the `apcntype` parameter for a linkset that still has links assigned to it. The assigned links must first be deleted.

Recovery

1. Display the current linkset configuration. Enter the `rtrv-ls` command specifying the linkset name (`lsn`) parameter.
 2. Delete all links in the linkset. Enter the `dlt-slk` command.
 3. Re-enter the command to change the `apcntype` parameter value for the linkset.
 4. When the `apcntype` has been changed, assign links of the correct type (ITUN or ITUN24) to the linkset.
-

E4393 Cmd Rej: Origin Based SCCP Routing feature must be enabled

Commands Used: `chg-gta`, `chg-gttset`, `chg-ls`, `chg-sccpopts`, `dlt-gta`, `ent-gta`, `ent-gttset`, `ent-gttset`, `ent-ls`, `rtrv-gta`, `rtrv-gttset`, `rtrv-gttset`

For the **chg-gta** or **ent-gta** commands, the Origin Based SCCP Routing feature must be enabled whenever the **cggtasn**, **cgpcsn**, **cgssnsn**, **opcsn**, **cgpc/cgpc/cgpci/cgpcn/cgpcn24**, **opc/opca/opci/opcn/opcn24**, **(e)cgssn**, or **selid** parameters are specified.

For the **chg-gta** or **ent-gta** commands, the Origin Based SCCP Routing feature must be enabled if **xlat=disc** or **xlat=udts** is specified.

For the **dlt-gta** or **rtrv-gta** commands, the Origin Based SCCP Routing feature must be enabled whenever the **cgpc/cgpc/cgpci/cgpcn/cgpcn24**, **opc/opca/opci/opcn/opcn24**, or **(e)cgssn** parameters are specified.

For the **chg/ent/rtrv-gttset1** commands, the Origin Based SCCP Routing feature must be enabled whenever the **cggtasn** or **cgpcsn** or **cgssn** or **selid** parameters are specified.

For the **ent/rtrv-gttset** commands, the Origin Based SCCP Routing feature must be enabled whenever the value specified for the **settype** parameter is either **cgta** or **cgssn** or **opc** or **cgpc**.

For the **chg/ent-ls** commands, the Origin Based SCCP Routing feature must be enabled whenever the value specified for the **gttmode** parameter is **acdcd**, **cgacdcd**, **acdcdcg**, **cgcd**, **cdcg**, or **cg**.

For the **chg-sccpopts** command, the Origin Based SCCP Routing feature must be enabled whenever the specified value for the **dfltgttmode** is **acdcd**, **cgacdcd**, **acdcdcg**, **acdcdcg**, **cgcd**, **cdcg**, or **cg**, or when the **dfltcgpcasn** or **dfltcgpcisn** parameters are specified.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off with the **chg-ctrl-feat** command. Refer to the *Commands Manual* for more information about enabling features with access keys.

Recovery

1. Verify that the Origin Based SCCP Routing feature is enabled. Enter the **rtrv-ctrl-feat** command.
2. If the Origin Based SCCP Routing feature is enabled, re-enter the command that generated this error message.
3. If the Origin Based SCCP Routing feature is not enabled (see the output of step 1), enable the feature.
 - Enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.

NOTE: Before you can enable the Origin Based SCCP Routing feature the EGTT feature must be turned on and at least a DSM card running the VSCCP application must be provisioned in the system.

Refer to the *Commands Manual* for detailed information about the use of the **enable-ctrl-feat** command.

- Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4396 Cmd Rej: CgPA GTT Selector already exists in GTIN-TT-NP(V)-NAI(V)

Commands Used: **ent-gttset**

You cannot add the specified CgPA GTT selector to the GTT Selector table because an entry that exactly matches the specified CgPA selector already exists in the GTT Selector table.

Recovery

1. Display the GTT Selector table. Enter the **rtrv-gttset** command specifying the **gtin**, **tt**, and **(np(v))**, and **nai(v)** if **gtin=4** or **gtin24=4** parameter combination.
2. Re-enter the **ent-gttset** command specifying a different range values for the **gtin**, **tt**, and **(np(v))**, and **nai(v)** if **gtin=4** or **gtin24=4** parameter combination from those that already exist in the GTT Selector table.

Call your Customer Care Center if this error message appears again.

E4397 Cmd Rej: At least one GTT Set Name must be specified

Commands Used: **chg-gttset**, **ent-gttset**

At least one GTT Set Name (**cdgtasn**, or **cggtasn**, or **cgpcsn**) must be specified.

Recovery

Re-enter the command specifying at least one GTT Set Name.

E4398 Cmd Rej: CGGTASN/CGPCSN/SELID are mutually exclusive

Commands Used: **chg-gta**, **ent-gta**

You cannot specify the **cggtasn**, **cgpcsn**, and **selid** parameters together in the same command line. These parameters are mutually exclusive and must be specified using separate command lines.

Recovery

Re-enter the command specifying each of the **cggtasn**, **cgpcsn**, and **selid** parameters separately.

E4399 Cmd Rej: Set type of GTT Set Name doesn't match

Commands Used: **chg-gta**, **ent-gta**

The value specified for the GTT set name (**gttsn**) parameter does not match the corresponding set type entry in the GTTSET table. The following GTT set names and matching GTT set types may be specified:

- GTT Set name specified with **cgssnsn** parameter, set type must be **cgssn**
- GTT Set name specified with **cggtasn** parameter, set type must be **cggta**
- GTT Set name specified with **cgpcsn** parameter, set type must be **cgpc**
- GTT Set name specified with **opcsn** parameter, set type must be **opc**

Recovery

1. Determine the GTT Set Name for the GTT set type that is specified in the GTTSET table. Enter the **rtrv-gttset** command.
 2. Re-enter the command specifying the correct value for the **gttsn** parameter.
-

E4400 Cmd Rej: GTA/CGPC/OPC/CGSSN must be specified

Commands Used: **chg-gta**, **dlt-gta**, **ent-gta**

The **gta**, or the **cgpc/cgpca/cgpci/cgpcn/cgpcn24**, or the **opc/opca/opci/opcn/opcn24**, or **cgssn** parameters are mutually exclusive and must be specified.

Recovery

Re-enter the command specifying the **gta**, or the **cgpc/cgpca/cgpci/cgpcn/cgpcn24**, or the **opc/opca/opci/opcn/opcn24**, or the **cgssn** parameters separately.

E4401 Cmd Rej: CGSSNSN cannot be specified with CGGTASN/OPCSN/CGPCSN/SELID

Commands Used: `chg-gta`, `ent-gta`

You cannot specify the `cggtasn`, `opcsn`, `cgpcsn`, and `selid` parameters if the `cgssnsn` parameter is specified.

Recovery

Perform one of the following:

Re-enter the command specifying the `cgssnsn` parameter without specifying the `cggtasn`, `opcsn`, `cgpcsn`, and `selid` parameters.

OR

Re-enter the command specifying the `cggtasn`, `opcsn`, `cgpcsn`, and `selid` parameters without specifying the `cgssnsn` parameter.

E4402 Cmd Rej: SETTYPE must be CDGTA when NETDOM=CROSS

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

For the `ent-gttset` command, the value specified for the GTT set type (`settype`) parameter must be `cdgta`, when the value specified for the network domain (`netdom`) parameter is `cross`.

For the `chg-gttset` command, the existing GTT set type (`settype`) must be `cdgta`, when the value specified for the network domain (`netdom`) parameter is `cross`.

NOTE: For the `chg-gttset` command, `cross` is the only value that can be specified for the `netdom` parameter.

Recovery

Re-enter the command specifying `settype=cdgta` and `netdom=cross`.

E4403 Cmd Rej: CGSSN can't be specified together with optional GTT Set Name

Commands Used: `chg-gta`, `ent-gta`

If the `cgssn` parameter is specified, the `cggtasn`, `cgpcsn`, `cgssnsn`, `opcsn`, and `selid` parameters must not be specified.

Recovery

Re-enter the command specifying the **cgssn** parameter, without specifying the **cggtasn**, **cgpcsn**, **cgssnsn**, **opcsn**, and **selid** parameters.

E4404 Cmd Rej: End value must be greater than or equal to a starting value

Commands Used: **chg-gta**, **chg-rtx**, **dlt-gta**, **dlt-rtx**, **ent-gta**, **ent-rtx**, **rtrv-gta**, **rtrv-rtx**

For the **ent/chg/dlt/rtrv-gta** commands, the value specified for the **ecgssn** must be greater than or equal to the value specified for the **cgssn**.

For the **ent/chg/dlt/rtrv-rtx** commands, the value specified for the **ecic** value must be greater than or equal to the value specified for the **cic**.

Recovery

Re-enter the command specifying an end value that is greater than the starting value.

Call your Customer Care Center if this error message appears again.

E4405 Cmd Rej: Optional GTT Set is not compatible with GTTSN set type

Commands Used: **chg-gta**, **ent-gta**

The **cgssnsn** parameter cannot be specified if the value specified for the GTTSN set type is **cdgta** or **cgssn**.

The **cggtasn** or **cgpcsn** or **opcsn** parameters must be specified if the value specified for the GTTSN set type is **cdgta**.

Recovery

Re-enter the command specifying either the **cggtasn** or **cgpcsn** or **opcsn** parameters, if the GTTSN set type is **cdgta**.

E4406 Cmd Rej: GTA parm must be specified if GTTSN is type of CDGTA/CGGTA

Commands Used: **ent-gta**, **chg-gta**, **dlt-gta**

The **gta** parameter must be specified if the value specified for the GTTSN set type is **cdgta** or **cggta**.

Recovery

Re-enter the command specifying the **gta** parameter, and a value for the GTTSN set type of either **cdgta** or **cggta**.

E4407 Cmd Rej: CGPCx parm must be specified if GTTSN is type of CGPC

Commands Used: **ent-gta, chg-gta, dlt-gta**

The **cgpc/cgpca/cgpci/cgpcn/cgpcn24** parameter must be specified if the value specified for the GTTSN set type is **cgpc**.

Recovery

Re-enter the command specifying the **cgpc/cgpca/cgpci/cgpcn/cgpcn24** parameter, and a value for the GTTSN set type of **cgpc**.

E4408 Cmd Rej: OPCx parm must be specified if GTTSN is type of OPC

Commands Used: **ent-gta, chg-gta, dlt-gta**

The **opc/opca/opci/opcn/opcn24** parameter must be specified if the value specified for the GTTSN set type is **opc**. The **opc/opca/opci/opcn/opcn24** parameters can only be specified for an OPC GTTSN set type.

Recovery

Re-enter the command specifying the **opc/opca/opci/opcn/opcn24** parameter and a value for the GTTSN set type of **opc**.

E4409 Cmd Rej: CGSSN parm must be specified if GTTSN is type of CGSSN

Commands Used: **chg-gta, dlt-gta, ent-gta**

The **cgssn** parameter must be specified if the value specified for the GTTSN set type is **cgssn**. The **cgssn** parameter can only be specified for a CGSSN GTTSN set type.

Recovery

Re-enter the command specifying the **cgssn** parameter for the CGSSN GTTSN set type.

E4410 Cmd Rej: CgPA GTT Selector already exists in GTIN24-TT-NP(V)-NAI(V)

Commands Used: **ent-gttsel**

The CgPA GTT Selector could not be added to the GTT Selector table because an entry that matches the specified **gtin24**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameter combination already exists. An entry must not already exist that exactly matches the specified **gtin24**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameter combination for the specified CgPA selector.

Recovery

Re-enter the **ent-gttsel** command specifying a different set of values for the **gtin24**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameters.

E4411 Cmd Rej: CgPA GTT Selector already exists in GTII-TT-NP(V)-NAI(V)

Commands Used: **ent-gttsel**

The CgPA GTT Selector could not be added to the GTT Selector table because an entry that matches the specified **gtii**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameter combination already exists. An entry must not already exist that exactly matches the specified international **gtii**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameter combination for the specified CgPA selector.

Recovery

Re-enter the **ent-gttsel** command specifying a different set of values for the **gtii**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameters.

E4412 Cmd Rej: CGSSN range cannot overlap a currently existing range

Commands Used: **chg-gta**, **dlt-gta**, **ent-gta**

The specified CGSSN range cannot overlap a range that currently exists for the specified GTT Set.

Recovery

Re-enter the command specifying a CGSSN range that does not overlap the existing **cgssn** range for the specified GTT Set.

E4413 Cmd Rej: CgPA GTT Selector already exists in GTI-TT-NP(V)-NAI(V)

Commands Used: **ent-gttse1**

The CgPA GTT Selector could not be added to the GTT Selector table because an entry that matches the specified **gti**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameter combination already exists. An entry must not already exist that exactly matches the specified **gti**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameter combination for the specified CgPA selector.

Recovery

Re-enter the **ent-gttse1** command specifying a different set of values for the **gti**, **tt**, **np(v)**, **nai(v)**, **cgssn** and/or **selid** parameters.

E4414 Cmd Rej: SSNSELID Table is full

Commands Used: **ent-gttse1**

The specified value could be entered into the SSNSELID table because the table is full. (Maximum number of entries is **10,000**).

Recovery

1. Display the SSNSELID table. Enter the **rtrv-gttse1** command.
 2. Change or delete an existing SSNSELID table entry. Enter the **chg-gttse1** or **dlt-gttse1** command.
 3. Re-enter the **ent-gttse1** command to add the entry to the SSNSELID table.
-

E4415 Cmd Rej: CGSSN range does not exist

Commands Used: **chg-gta**, **dlt-gta**, **rtrv-gta**

The range specified for the **cgssn** parameter does not exist. The specified CGSSN range must exist for the specified GTT Set (note that an exact match is not required.)

Recovery

Re-enter the command specifying a valid range for the **cgssn** parameter.

E4416 Cmd Rej: Cannot delete to DSTN that has exception routes**Commands Used: dlt-rtx**

You cannot delete the last route to a destination that is referenced by the Route table. A Route table entry exists that is referenced by the destination point code.

Recovery

1. Display the Route table. Enter the **rtrv-rte** command.
 2. Delete the DPC references from the Route table. Enter the **dlt-rte** command.
 3. Delete the desired route. Re-enter the **dlt-rte** command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E4418 Cmd Rej: Specified GTT set does not exist**Commands Used: chg-sccpopts**

The specified GTT set for the Default Calling Party ANSI Point Code Set Name (**dfltcgpcasn**), or the Default Calling Party ITU Point Code Set Name (**dfltcgpcisn**), must exist in the GTTSET table.

- The **dfltcgpcasn** parameter determines the system default of the GTT Calling Party Point Code Set for ANSI when **gti=0**
- The **dfltcgpcisn** parameter determines the system default of the GTT Calling Party Point Code Set for ITU when **gti=0**.

Recovery

1. Display the STP Options table. Enter the **rtrv-sccpopts** command.
 2. Re-enter the **chg-sccpopts** command specifying **gti=0** and a default set name (**dfltcgpcasn** or **dfltcgpcisn**) parameter that exists in the GTTSET table.
-

E4419 Cmd Rej: FGTTLS feature requires minimum DSM card with VSCCP APPL

Commands Used: `ent-card`

The current hardware configuration does not support the Flexible GTT Load-Sharing (FGTTLS) feature. This feature requires DSM cards running the `vsccp` application.

Recovery

1. Verify that the system contains only DSM cards and VSCCP APPLs with the Flexible GTT Load-Sharing feature turned on. Enter the `rtrv-card` command. If necessary, install DSM cards provisioned with the VSCCP application.
 2. Re-enter the `ent-card` command.
Call your Customer Care Center if this error message appears again.
-

E4435 Cmd Rej: OPC/ILSN/CIC/SI is mandatory and mutually exclusive

Commands Used: `chg-rtx`, `dlt-rtx`, `ent-rtx`

Only one of the following optional parameters may be specified for a Route Exception entry: `cic`, `ilns`, `opc`, or `si`.

Recovery

Re-enter the command specifying only one of the following optional parameters: `cic`, `ilns`, `opc`, or `si`.

Call your Customer Care Center if this error message appears again.

E4441 Cmd Rej: CGGTA and CGPC are mutually exclusive

Commands Used: `rtrv-data-gtt`

You cannot specify the `cggta` and `cgpc` parameters together in the same command.

Recovery

Re-enter the `rtrv-data-gtt` command specifying the `cggta` and the `cgpc` parameters separately.

E4442 Cmd Rej: CDGTA must be specified

Commands Used: `rtrv-data-gtt`

The `cdgta` parameter must be specified if the `opc` parameter is specified.

Recovery

Re-enter the `rtrv-data-gtt` command specifying both the `opc` parameter and the `cdgta` parameter.

E4443 Cmd Rej: CGGTA or CGPC or OPC must be specified

Commands Used: `rtrv-data-gtt`

If the `cgssn` parameter is specified, then either `cggta` or `cgpc` or `opc` parameter must be specified.

Recovery

Re-enter the `rtrv-data-gtt` command specifying the `cgssn` parameter and either the `cggta`, or `cgpc`, or `opc` parameters.

E4444 Cmd Rej: CGGTA or CGPC must be specified

Commands Used: `rtrv-data-gtt`

You must specify either the `cggta` or `cgpc` parameters.

Recovery

Re-enter the `rtrv-data-gtt` command specifying either the `cggta` or `cgpc` parameter.

E4445 Cmd Rej: Target card is not a TSM/DSM with SCCP/VSCCP appl

Commands Used: `rtrv-data-gtt`

The target network card specified by the `loc` parameter must either be a TSM card running the SCCP application or a DSM card running the VSCCP application.

Recovery

Re-enter the **rtrv-data-gtt** command specifying the **loc** parameter for either a TSM card running the SCCP application, or a DSM card running the VSCCP application.

E4448 Cmd Rej: Too many IP connection states per card

Commands Used: **chg-appl-sock, chg-assoc, ent-appl-sock, ent-as**

There are per card and per system limits on the maximum number of sockets supported: the maximum number of sockets per Local Host on SS7IPGW/IPGWI cards is **50**, the maximum number of sockets per signaling link on IPLIM/IPLIMI cards is **1**, and the maximum number of IP connections per system is **4000**.

Each time an M3UA/SUA association is assigned to an AS, the SS7IPGW or IPGWI card that hosts the association must maintain a state (ASP-Down, ASP-Inactive, ASP-Active) for the association/AS combination. Each TALI socket on an SS7IPGW or IPGWI card requires the card to maintain a TALI state (NEx-FEx) as well. These states are referred to as adapter states. A single M3UA/SUA association may have multiple adapter states, one for each AS it resides in. There is a single adapter state for each TALI socket. The maximum number of adapter states for a single SS7IPW or IPGWI card is **50**.

Recovery **chg-appl-sock, ent-appl-sock,**

The maximum number of IP connections allowed per card was exceeded. IP connections are composed of sockets and associations. For the SS7IPGW or IPGWI applications, the maximum number of IP connections per card is **50**.

Call your Customer Care Center if this error message appears again.

Recovery **chg-assoc, ent-as**

1. Display the connection types in the AS table. Enter the **rtrv-assoc** or **rtrv-as** command.
2. If you want to associate another connection type with the AS, you must first delete an existing connection type association from the AS.

Refer to the *Commands Manual* for detailed information about the use of these commands.

3. If you have deleted an existing connection type association for the AS, re-enter the command to associate the new connection type with the AS.
-

E4454 Cmd Rej: Specified GTT Set must be type of CGPC

Commands Used: `chg-sccpopts`

For the `chg-sccpopts` command, the specified GTT Set for the `dfltcgpcasn`, `dfltcgpcisn` parameters must be a set type of `cgpc` defined in the GTTSET table.

Recovery

Re-enter the `chg-sccpopts` command specifying a value of `cgpc` for the the GTT set type.

E4455 Cmd Rej: CGGTASN/CGPCSN must be specified if CGSSN/SELID is specified

Commands Used: `chg-gttset`, `ent-gttset`

The `cggtasn` or the `cgpcsn` parameter must be specified if the `cgssn` and/or `selid` parameters are specified.

Recovery

Re-enter the command specifying the `cgssn` and/or `selid` parameters and either the `cggtasn` or the `cgpcsn` parameters.

E4456 Cmd Rej: GTT set name must match the network domain

Commands Used: `chg-sccpopts`

The specified GTT Set domain must match the network domain for the specified GTT Set Name.

- For the default CGPCA Set Name (`dfltcgpcasn`), the specified network domain must be an ANSI network domain.
- For the default CGPCI Set Name (`dfltcgpcisn`), the specified network domain must be an ITU (including ITU-I, ITU-N, ITU-N24) network domain.

Recovery

Re-enter the **chg-sccpopts** command specifying the correct network domain for the specified GTT Set Name.

E4457 Cmd Rej: SELID is valid only if specified GTTSN's set type is CDGTA

Commands Used: **chg-gta, ent-gta**

You can only specify the **selid** parameter if the value specified for the GTTSN set type is **cdgta**.

Recovery

Re-enter the command specifying a value for the **selid** parameter and GTTSN whose **settype=cdgta**.

E4458 Cmd Rej: Common screening list feature is required

Commands Used: **chg-cs1, dlt-cs1, ent-cs1**

An enabled feature that uses a common screening list must be specified using either a valid part number (**pn**) or feature name.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4459 Cmd Rej: Common screening list type is required

Commands Used: **chg-cs1, dlt-cs1, ent-cs1**

The value specified for the **list** parameter is invalid.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4460 Cmd Rej: Common screening list type is invalid

Commands Used: `chg-cs1`, `dlt-cs1`, `ent-cs1`, `rtrv-cs1`

The specified screening list name (**list**) is invalid for the specified screening feature.

NOTE: The list parameter is required if the specified feature supports more than one screening list, otherwise it is optional.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4461 Cmd Rej: Common screening list entry already exists

Commands Used: `ent-cs1`

The specified digit string (**ds**) entry already exists for the specified feature and screening list. Duplicate digit string entries are not allowed for any feature and screening list combination.

Recovery

1. Display a list of screening numbers for the specified feature and screening list name. Enter the `rtrv-cs1` command.
 2. Re-enter the `ent-cs1` command specifying a valid **ds** entry.
-

E4462 Cmd Rej: Common screening list entry not present

Commands Used: `chg-cs1`, `dlt-cs1`

The specified entry does not exist for the specified feature part number or feature name and list type.

Recovery

Re-enter the command specifying a valid **ds** entry for the specified feature part number or feature name and list type.

E4464 Cmd Rej: Common screening list invalid parameter combination

Commands Used: **chg-cs1, dlt-cs1, ent-cs1, rtrv-cs1**

The specified parameter combination is invalid.

Recovery

Re-enter the command specifying a valid parameter combination.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4466 Cmd Rej: Common screening list is full

Comands Used: **ent-cs1**

The common screening list for the specified feature is full.

Recovery

1. Display a list of screening numbers for the specified feature and screening list name. Enter the **rtrv-cs1** command.
2. Delete the screening numbers for the specified feature and screening list name. Enter the **dlt-cs1** command.
3. Re-enter the **ent-cs1** command.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4467 Cmd Rej: Common screening list read fail

Comands Used: **chg-cs1, dlt-cs1, ent-cs1, rtrv-cs1**

The specified screening list cannot be read.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E4468 Cmd Rej: Common screening list requested feature must be enabled

Commands Used: `chg-csl`, `dlt-csl`, `ent-csl`

The feature for the specified common screening list is not enabled.

Recovery

1. Display the status of features in your system. Enter the `rtrv-ctrl-feat` command.
2. Verify the feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. If you have purchased and installed the feature in your system, enable the feature. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling the feature.

4. When the feature is enabled, then re-enter the command.

Call your Customer Care Center if this error message appears again.

E4469 Cmd Rej: Failed reading SSNSELID table

Commands Used: `chg-gttset`, `dlt-gttset`, `ent-gttset`,
`rtrv-gttset`

The SSNSELID table is inaccessible. The SSNSELID table must be accessible.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E4470 Cmd Rej: SSNSELID entry already exists

Commands Used: `chg-gttsel`, `ent-gttsel`

The value specified for the `cgssn` and/or `selid` parameter already exists in the SSNSELID table. The specified `cgssn` and/or `selid` is already being used by other selector.

Recovery

Re-enter the command specifying a different value for the `cgssn` and/or `selid` parameter.

E4471 Cmd Rej: SSNSELID entry does not exist

Commands Used: `chg-gttsel`

The value specified for the `cgssn` and/or `selid` parameter does not exist in the SSNSELID table. If the specified `cgssn` and/or `selid` does not exist in SSNSELID table, it cannot be changed.

Recovery

1. Display the SSNSELID table. Enter the `rtrv-gttsel` command.
 2. Re-enter the command specifying a valid value for the `selid` parameter.
-

E4475 Cmd Rej: MRNSET must be specified (only) if RI parameter is GT

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

With the Flexible GTT Loadsharing feature enabled, the `mrnset` parameter must be specified if `ri=gt` is specified. If `ri=ssn` is specified, then the `mrnset` parameter cannot be specified

Recovery

Re-enter the command specifying both the `mrnset` and `ri=gt` parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

Call your Customer Care Center if this error message appears again.

E4476 Cmd Rej: Specified PC must exist in MRNSET

Commands Used: `chg-gta`, `chg-gtt`

The specified PC value does not exist in the MRN Set.

Recovery

1. Add the PC to the MRN set. Enter the `ent-mrn` or `chg-mrn` command.
Refer to the *Commands Manual* for detailed information about the use of these commands.
 2. Re-enter the command and specified `pc` parameter.
Call your Customer Care Center if this error message appears again.
-

E4479 Cmd Rej: MRNSET must be specified (only) if FGTTLS feature is enabled

Commands Used: `chg-gta`, `chg-gtt`, `chg-mrn`, `dlt-mrn`, `ent-gta`,
`ent-gtt`, `ent-mrn`, `rtrv-mrn`

The Flexible GTT Loadsharing (FGTTLS) feature must be enabled before the `mrnset` parameter can be specified. The `mrnset` parameter can only be specified if the FGTTLS feature is enabled.

Recovery

1. Display the status of features in your system. Enter the `rtrv-ctrl-feat` command.
2. Verify the FGTTLS feature was purchased and installed in your system.
Contact your Customer Care Center if you need assistance.
3. If you have purchased and installed the feature in your system, use the `enable-ctrl-feat` command to enable the feature.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling this feature.

NOTE: The Flexible GTT Load Sharing feature requires a DSM card running the vsccp application.

4. When the FGTTLS feature is enabled, then re-enter the command specifying the `mrnset` parameter.
Call your Customer Care Center if this error message appears again.
-

E4480 Cmd Rej: Specified MRNSET does not exist

Commands Used: `chg-gta`, `chg-gtt`, `chg-mrn`, `dlt-mrn`, `ent-gta`,
`ent-gtt`, `ent-mrn`, `rtrv-mrn`

The specified MRNSET does not exist in the MRN table. The specified MRNSET must already exist in the MRN table.

Recovery

1. Add the MRNSET to the MRN table. Enter the `ent-mrn` command.
Refer to the *Commands Manual* for detailed information about the use of these commands.
 2. Re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E4482 Cmd Rej: Multiple groups are allowed only in default MRNSET

Commands Used: `ent-mrn`

You cannot add a group to an existing MRNSET that is not the default MRNSET. The default MRNSET can have any number of load sharing groups in order to maintain compatibility with existing functionality.

Recovery

Re-enter the `ent-mrn` command.
Call your Customer Care Center if this error message appears again.
Refer to the *Commands Manual* for detailed information about the use of the `ent-mrn` command.

E4483 Cmd Rej: PC does not exist in specified MRNSET

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`, `ent-mrn`,
`chg-mrn`, `dlt-mrn`, `rtrv-mrn`

The specified PC does not exist in the MRN set. The specified point code must already exist in the specified MRN set.

Recovery

1. Display the MRN table. Enter the `rtrv-mrn` command.

2. If the specified PC is not in the MRNSET, add the PC to the MRNSET. Enter the **ent-mrn** or **chg-mrn** command.
Refer to the *Commands Manual* for detailed information about the use of these commands.
 3. Re-enter the command.
Call your Customer Care Center if this error message appears again.
-

E4484 Cmd Rej: PC reference exists in GTT translation

Commands Used: **dlt-mrn**

You cannot delete a PC from the MRN table that is still referenced by a GTT/GTA entry.

Recovery

1. Display the GT Translations. Enter the **rtrv-gtt** or **rtrv-gta** commands.
 2. Delete the specified **pc** from the GTT table. Enter the **dlt-gtt** or **dlt-gta** commands.
 3. Delete the specified **pc** from the MRN table. Re-enter the **dlt-mrn** command.
Call your Customer Care Center if this error message appears again.
-

E4485 Cmd Rej: PC & MRNSET must be specified together

Commands Used: **rtrv-mrn**

You must specify both the **pc** and the **mrnset** parameters when the Flexible GTT Loadsharing feature is enabled.

Recovery

Re-enter the **rtrv-mrn** command specifying both **pc** and the **mrnset** parameters.
Refer to the *Commands Manual* for detailed information about the use of the **rtrv-mrn** command.

E4486 Cmd Rej: GTT Set specified by CGGTASN/CGPCSN does not exist

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The GTTSET specified by the CgPA GTA GTT Set Name (`cggtasn`) parameter or the CgPA PC GTT Set Name (`cgpcsn`) parameter, does not exist in the database. The GTTSET parameter value must exist in the database before it can be assigned to a GTT selector.

Recovery

1. Display the GTT Set table. Enter the `rtrv-gttset` command.

Refer to the *Commands Manual* for detailed information about the use of these commands.

NOTE: The GTT Set table cannot have more than 2000 entries.

2. Add the GTT set to the GTT Set table. Enter the `ent-gttset` command specifying either the `settype=cggtasn` parameter, or the `settype=cgpcsn` parameter.
 3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E4487 Cmd Rej: GTI domain doesn't match CGGTASN/CGPCSN domain

Commands Used: `chg-gttset`, `ent-gttset`

The CgPA GTA GTT Set Name or CgPA PC GTT Set Name network domain does not match the network domain specified by the Global Title Indicator (`gti/gtia/gtii/gtin/gtin24`) parameter.

For all GTT Selector commands, the network domain (ANSI, ITU-I, or ITU-N) is specified with the Global Title Indicator parameter where `gti` and `gtia` = `ansi`; `gtii` = `itu-i`; `gtin` = `itu-n`, and `gtin24` = `itu-n 24 bit`.

Recovery

Re-enter the command specifying a network domain for the `cggtasn` or `cgpcsn` parameter that matches the network domain specified by the GTI parameter.

E4488 Cmd Rej: CGGTASN/CGPCSN set type doesn't match

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The value specified for the `cggtasn` or `cgpcsn` set type does not match the set type of the corresponding entry specified in the GTTSET table.

- For the `cggtasn` parameter, the specified set type should be `cggta`.
- For the `cgpcsn` parameter, the specified set type should be `cgpc`.

Recovery

Re-enter the command specifying the correct set type parameter value.

E4489 Cmd Rej: Common screening list starting digits of key must be unique

Commands Used: `chg-cs1`, `ent-cs1`

The leading digit pattern in the specified digit string must be unique within the specified feature screening list.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4490 Cmd Rej: Card type must be VXWSLAN for a 100Mbit link

Commands Used: `ent-dlk`

You specified a value of **100** for the `speed` parameter, but the specified card location is not provisioned for the SLAN Enhancement. For a **100** Mbps data link, a DCM card running the `vxwslan` appl must be provisioned in the specified card location.

Recovery

1. List the card types in the database. Enter the `rtrv-card` command. The Verify that the card location you entered is a DCM card provisioned for VXWSLAN in the APPL field of the `rtrv-card` command output.
 2. Re-enter the `ent-dlk` command specifying a valid card type.
-

E4491 Cmd Rej: Invalid IP database configuration

Commands Used: `act-upgrade`

Unresolved IP references were found in the IP database during the upgrade or health check procedure. This means that the database contains references to IP signaling entities (Application Server, IP Connection, IP Host, etc) that do not exist or configuration parameters that are no longer supported.

Recovery

Call your Customer Care Center to speak with Upgrade Support.

E4492 Cmd Rej: Common screening list invalid DS parameter value

Commands Used: `chg-cs1`, `ent-cs1`

The specified digit string (**ds**) parameter contains invalid value(s) for the specified feature screening list.

Recovery

Re-enter the command specifying a valid **ds** parameter value for the specified feature and list type.

E4493 Cmd Rej: Common screening list DS length invalid

Commands Used: `chg-cs1`, `ent-cs1`

The specified digit string length is invalid for the screening feature and list type. The length of the digit string that is specified for the **ds** parameter must be valid for the screening feature and list type.

Recovery

Re-enter the command specifying a valid digit string length for the screening feature and list type.

E4495 Cmd Rej: Specify a single output method

Commands Used: `rtrv-data-insrv`

You specified multiple methods of output. Only one primary method of output, either trigger type, index, or range, can be specified where a range uses **begin** and/or **end** parameters.

Recovery

Re-enter the `rtrv-data-insrv` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-data-insrv` command.

E4496 Cmd Rej: Range endpoints are reversed

Commands Used: `rtrv-data-insrv`

The **begin** and **end** values for specifying a range are reversed.

Recovery

Re-enter the `rtrv-data-insrv` command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of the `rtrv-data-insrv` command.

E4497 Cmd Rej: ICNP feature must be activated

Commands Used: `rtrv-data-insrv`

The IntraCarrier Number Portability and IN Triggers (ICNP) feature must be enabled and turned on for the IN Service table to exist for data retrieval.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Refer to the appropriate *Database Administration Manual* and to the *Commands Manual* for details about turning on features with bits and enabling features with access keys.

Recovery

1. Display the features in the system. Enter the **rtrv-ctrl-feat** command.
2. If the IntraCarrier Number Portability and IN Triggers (ICNP) feature has been purchased and installed in your system verify its status. Enter the **rtrv-ctrl-feat** command.

Refer to the *Database Administration Manual - System Management* for any prerequisite features that must be turned on before enabling, turning on, and configuring the ICNP feature.

NOTE: The ICNP feature requires a 4 GB DSM card to enable the feature. The INP feature must be turned on before the ICNP feature can be enabled.

3. Enable the INCP feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.
4. Turn on the INCP feature. Enter the **chg-ctrl-feat** command.
5. Verify the INCP feature is enabled and turned on. Enter the **rtrv-ctrl-feat** command.
6. When the INCP feature is enabled and turned on in the system, re-enter the **rtrv-data-insrv** command.

Call your Customer Care Center if this error message appears again.

E4498 Cmd Rej: The Prepaid IDP Query Relay Feature Must be Enabled

Commands Used: chg-prefix

The IDPR feature must be enabled before a prefix can be changed or provisioned for the Prepaid IDP Query Relay (IDPR) feature.

Recovery

1. Display the status of features in your system. Enter the **rtrv-ctrl-feat** command.
2. Verify the IDPR feature was purchased and installed in your system.

Contact your Customer Care Center if you need assistance.

NOTE: The GTT feature must be on before the IDPR feature can be enabled. The IDPR feature requires DSM cards running the VSCCP application and ELAP. The IDP RELAY feature and the LNP cannot be enable at the same time in the system.

3. Enable the IDPR feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling this feature.

4. Re-enter the **chg-prefix** command.

Call your Customer Care Center if this error message appears again.

E4499 Cmd Rej: Common screening list invalid parameter value

Commands Used: **chg-cs1**, **ent-cs1**

The specified common screening list parameter value must be valid for the specified screening list feature.

Recovery

Re-enter the command specifying the correct format and parameters.

Refer to the *Commands Manual* for detailed information about the use of these commands.

E4500 Cmd Rej: Prepaid IDP Query Relay feature must be ON when (N)SERV=IDPR

Commands Used: **ent-srvsel**, **rtrv-srvsel**

The Prepaid IDP Query Relay (IDPR) feature must be turned on before the **idpr** parameter value can be specified.

Recovery

1. Enter the **rtrv-ctrl-feat** command to display the status of features in your system.
2. Verify the IDPR feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.

NOTE: The GTT feature must be on before the IDPR feature can be enabled. The IDPR feature requires DSM cards running the VSCCP application and ELAP. The IDP RELAY feature and the LNP cannot be enable at the same time in the system.

3. Enable the IDPR feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.
4. Turn on the IDPR feature. Enter the **chg-ctrl-feat** command.
5. Re-enter the **ent-srvsel** command.

Call your Customer Care Center if this error message appears again.

E4501 Cmd Rej: Enabling of IDPR requires VSCCP DSM cards and ELAP

Commands Used: `enable-ctrl-feat`

You tried to turn on the IDPR feature but the hardware is not compatible. This feature requires DSM cards running the VSCCP application and ELAP.

Recovery

1. Display the cards and loads for each. Enter the `rtrv-card` command.
 2. Verify that the system contains only DSM cards and VSCCP APPLs and that the ELAP Feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
-

E4502 Cmd Rej: GTT must be on before IDPR can be enabled

Commands Used: `chg-feat`

You cannot turn on the IDPR feature with the Global Title Translation (GTT) feature turned off. The GTT feature must be enabled and turned on (`gtt=on`) before the IDPR feature can be enabled and turned on (`idpr=on`).

Recovery

1. Display the status of features in your system. Enter the `rtrv-ctrl-feat` command.
2. Verify the GTT feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the GTT feature. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.
*Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling the GTT feature.*
4. Turn on the GTT feature. Enter the `chg-feat:gtt=on` command.
5. Re-enter the `enable-ctrl-feat` command.

Call your Customer Care Center if this error message appears again.

E4503 Cmd Rej: IDPR and LNP are mutually exclusive**Commands Used: chg-feat**

You cannot turn on the IDPR feature if the LNP feature is turned on. If the LNP feature is turned on, the IDPR feature cannot be turned on. If the IDPR feature is turned on, the LNP feature cannot be turned on.

Recovery

1. Turn off LNP.
2. Display the status of the features in your system. Enter the **rtrv-ctrl-feat** command.
3. Verify the GTT feature was purchased and installed in your system. Contact your Customer Care Center if you need assistance.
4. Enable the GTT feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling this feature.

5. Turn on the GTT feature. Enter the **chg-feat:gtt=on** command.
6. Re-enter the **enable-ctrl-feat** command.

Call your Customer Care Center if this error message appears again.

E4504 Cmd Rej: IDPR cannot be enabled if ASM/TSM is present**Commands Used: enable-ctrl-feat**

The IDPR feature cannot be enabled if ASM/TSM cards are present in the system. To enable the IDPR feature, DSM cards running the VSCCP application and ELAP are required.

Recovery

1. Remove any ASM/TSM cards.
2. Verify that the system contains only DSM cards running the VSCCP application and that the ELAP Feature has been purchased and installed in your system. Contact your Customer Care Center if you need assistance.
3. Enable the ELAP feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling this feature.

4. Turn on the ELAP feature. Enter the **chg-feat** command.
5. Enable the IDPR feature. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E4505 Cmd Rej: Requested service parameters not supported when (N)SERV=IDPR

Commands Used: **chg-srvsel, ent-srvsel, rtrv-srvsel**

One or more service parameters were selected that are not supported for the IDP Relay feature. Valid mandatory service parameters are **gtia, gtii, gtin, serv, ssn, tt**, and optional parameters are **nai** and **np**.

Recovery

Re-enter the command specifying valid service parameter values for the IDP Relay feature.

E4506 Cmd Rej: Must specify trigger type with an offset

Commands Used: **rtrv-data-insrv**

You specified an **offset** without specifying a trigger type (**tt**). A trigger type must be specified with an offset to determine the IN Service entry to output.

Recovery

Re-enter the **rtrv-data-insrv** command specifying both the **tt** and **offset** parameters.

Refer to the *Commands Manual* for detailed information about the use of the **rtrv-data-insrv** command.

E4507 Cmd Rej: IDPR feature requires DEFCC to be provisioned

Commands Used: **chg-ctrl-feat**

Before you can turn on the IDP RELAY feature, the default country code (**defcc**) parameter must first be provisioned via the **chg-stpopts** command.

Recovery

Re-enter the **chg-ctrl-feat** command specifying a valid entry.

E4508 Cmd Rej: SEAS can only update translations with Default MRNSET

Commands Used: **cht-gta**, **chg-gtt**

You can only use a SEAS command specifying **mrnset=dflt**. SEAS command will not operate on any other MRNSET except the default MRNSET.

Recovery

Re-enter the command.

Refer to the *Commands Manual* for detailed information about the use of these commands.

Call your Customer Care Center if this error message appears again.

E4509 Cmd Rej: Translation entry already exists

Commands Used: **ent-gta**

The specified **cgpc** or **opc** translation entry already exists.

Recovery

Re-enter the **ent-gta** command specifying a different value for the **cgpc** or **opc** parameters.

E4510 Cmd Rej: Translation entry does not exist

Commands Used: **chg-gta**, **dlt-gta**

The translation entry for the specified CgPA PC or OPC does not exist.

Recovery

Re-enter the command specifying a different value for the CgPA PC or OPC.

E4511 Cmd Rej: CDGTASN/GTTSN is not provisioned

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

For the `chg-gttset` command, the specified CDGTA GTTSET or GTT Set Name is not provisioned for the specified GTT Selector. You cannot change the value of a GTT Set Name or CDGTA Set Name (`cdgtasn`) if it is not provisioned in the GTTSEL table.

For the `ent-gttset` and `rtrv-gttset` commands, either the specified CDGTA GTTSET or GTT Set Name is not provisioned in the GTT Set table or `cdgtasn=none` is specified, but `cdgtasn` is not provisioned for that selector table.

Recovery `chg-gttset`

1. Display the GTTSEL table. Enter the `rtrv-gttset` command.
 2. Re-enter the command specifying a valid value for the `cdgtasn` or `gttsn` parameter that is provisioned in the database.
-

Recovery `ent-gttset` and `rtrv-gttset`

1. Display the GTTSEL table. Enter the `rtrv-gttset` command.
 2. Re-enter the `ent-gttset` or `rtrv-gttset` commands specifying a valid value for the `cdgtasn` or `gttsn` parameter that is provisioned in the database.
-

E4512 Cmd Rej: CgPA GTT Selector doesn't exist in GTI-TT-NP(V)-NAI(V)

Commands Used: `chg-gttset`

The specified `cggtta gttset/cgpc gttset` parameter is not provisioned in the database.

Recovery

1. Retrieve the GTTSEL table. Enter the `rtrv-gttset` command.
 2. Re-enter the `chg-gttset` command specifying a valid value for the `cggtasn` or `cgpcsn` parameters.
-

E4513 Cmd Rej: CDGTASN/GTTSN can not be specified as NONE

Commands Used: **chg-gttse1**

You cannot specify a value of **none** for the **cdgtasn** or **gttsn** parameters. If the **chg-gttse1** command specifies the only GTTSET associated with that selector, then **cdgtasn=none** cannot be specified.

Recovery

Re-enter the **chg-gttse1** command specifying a value other than **none** for the **cdgtasn** or **gttsn** parameters.

E4514 Cmd Rej: CDGTASN and CGGTASN/CGPCSN can not be specified as NONE

Commands Used: **chg-gttse1**

You cannot specify a value of **none** for the **cdgtasn** and the **cggtasn** or the **cgpcsn** parameters.

For the **chg-gttse1** command, if a GTT selector contains two GTT sets, you cannot delete or specify a value of **none** to both GTT sets. A GTT selector must point to at least one GTT set.

Recovery - if a GTT selector contains two GTT sets

To delete one of the GTT sets. Perform one of the following actions:

- Re-enter the **chg-gttse1** command without specifying **none** for both the **cdgtasn** and the **cggtasn** parameters.
- OR
- Re-enter the **chg-gttse1** command without specifying **none** for both the **cdgtasn** and the **cgpcsn** parameters.
-

E4515 Cmd Rej: CGGTASN/CGPCSN can not be specified as NONE

Commands Used: **chg-gttse1, rtrv-gttse1**

For the **chg-gttse1** command, you cannot specify a value of **none** for the **cggtasn** or **cgpcsn** parameter if the GTT Selector contains only one GTT set. A GTT selector must point to at least one GTT set

For the **rtrv-gttse1** command, a value of **none** can not be specified for any GTT set parameter.

Recovery

Re-enter the command without specifying a value of **none** for the **cggtasn** and/or **cgpcsn** parameters.

E4516 Cmd Rej: CGGTASN/CGPCSN mustn't be specified

Commands Used: **rtrv-gttse1**

You cannot specify the **cggtasn** or **cgpcsn** parameters if the **cgssn** and/or **selid** parameters are specified.

Recovery

Re-enter the command specifying the **cgssn** and/or **selid** parameters without specifying the **cggtasn** or **cgpcsn** parameters.

OR

Re-enter the command specifying the **cggtasn** or **cgpcsn** parameters without specifying the **cgssn** and/or **selid** parameters.

E4517 Cmd Rej: CDGTASN must not be specified

Commands Used: **rtrv-gttse1**

You cannot specify the **cdgtasn** parameter in the **rtrv-gttse1** command, given the following two scenarios:

When **gti=2** and the **tt** parameter is specified.

— OR —

When **gti=4** and the **tt**, **np/naiv**, **nai/naiv** parameters are specified.

Recovery

Re-enter the **rtrv-gttse1** command specifying the **cdgtasn** parameter if **neither** of the following conditions exist:

gti=2 and the **tt** parameter is specified.

— OR —

gti=4 and the **tt**, **np/naiv**, **nai/naiv** parameters are specified

E4519 Cmd Rej: CDGTASN/GTTSN set type doesn't match

Commands Used: `chg-gttset`, `ent-gttset`, `rtrv-gttset`

The value specified for the `cdgtasn` or `gttsn` set type does not match the set type of the corresponding entry specified in the GTTSET table.

If the CdPA GTA GTT Set Name (`cdgtasn`) parameter is specified, the value specified for the GTTSET type must be `cdgta`.

Recovery

Re-enter the command specifying the `cdgtasn` or `gttsn` parameter whose set type is `cdgta`.

E4520 Cmd Rej: Specified Fahrenheit values convert to same Celsius value

Commands Used: `chg-th-alm`

Due to the Fahrenheit to Celsius temperature conversion method used, there are multiple values in Fahrenheit which convert to the same Celsius value which is not allowed. (For example: Fahrenheit values of **140** and **141** convert to Celsius values of **60.0** and **60.56** which are the same as the conversion method uses only whole temperature values in Celsius).

Recovery

Re-enter the `chg-th-alm` command specifying Fahrenheit values with a difference of at least two degrees.

E4521 Cmd Rej: CGPCSN set domain must be the same as GTTSN set domain

Commands Used: `chg-gta`, `ent-gta`

The CGPCSN set domain must be the same as the GTTSN set domain. i.e. if the GTTSN set domain is ANSI, then the CGPCSN set domain must also be ANSI; and if GTTSN set domain is ITU, then the CGPCSN set domain must also be ITU.

Recovery

Re-enter the command specifying the same domain (either ansi or itu) for both the `cgpcsn` and `gttsn` parameters.

E4522 Cmd Rej: OPCSN set domain must be the same as GTTSN set domain

Commands Used: `chg-gta`, `ent-gta`

The OPCSN set domain must be the same as the GTTSN set domain, i.e. if the GTTSN set domain is ANSI, then the OPCSN set domain must also be ANSI; and if the GTTSN set domain is ITU, then the OPCSN set domain must also be ITU.

Recovery

Re-enter the command specifying the same domain (either ansi or itu) for both the `opcsn` and `gttsn` parameters.

E4523 Cmd Rej: MAPSET must be specified (only) if FGTTLS feature is enabled

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`, `chg-gtt`, `chg-map`, `dlt-map`, `ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gta`, `ent-gtt`, `ent-map`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`, `rtrv-gta`, `rtrv-gtt`, `rtrv-map`

The mapset id parameter (**mapset**) must be specified if the Flexible GTT Load-Sharing (FGTTLS) feature is enabled. The **mapset** parameter can only be specified if the FGTTLS feature is enabled.

Recovery

Determine the status of the FGTTLS feature. Enter the `rtrv-ctrl-feat` command.

- If the FGTTLS feature is enabled, re-enter the command specifying the **mapset** parameter.

Refer to the *Commands Manual* and the *Database Administration Manual – Features* for more information about enabling this feature

- If the FGTTLS feature is not enabled, enable it. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

NOTE: The Flexible GTT Load Sharing feature requires a DSM card running the vsccp application.

- Re-enter the command specifying the **mapset** parameter.

Call your Customer Care Center if this error message appears again.

E4524 Cmd Rej: Failed Reading MAP table

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`,
`chg-gtt`, `chg-map`, `dlt-gsmmap-scrn`, `dlt-gsms-opcode`, `dlt-gta`,
`dlt-gtt`, `dlt-map`, `ent-gsmmap-scrn`, `ent-gsms-opcode`, `ent-gta`,
`ent-gtt`, `ent-map`, `rtrv-map`

The MAP table is not accessible. The MAP table must be accessible.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E4526 Cmd Rej: MAP table is full

Commands Used: `ent-map`

The MAP table is full. You must delete an entry before another entry can be added to the MAP table.

Recovery

1. Display the contents of the MAP table. Enter the `rtrv-map` command.
2. To make room for the new entry delete an existing MAP table entry. Enter the `dlt-map` command.
3. Add the new entry to the MAP table. Re-enter the `ent-map` command.

Refer to the *Commands Manual* for detailed information about the use of these commands.

Call your Customer Care Center if this error message appears again.

E4527 Cmd Rej: Specified MAPSET does not exist

Commands Used: `chg-gsmmap-scrn`, `chg-gsms-opcode`, `chg-gta`,
`chg-gtt`, `chg-map`, `dlt-map`, `ent-gsmmap-scrn`, `ent-gsms-opcode`,
`ent-gta`, `ent-gtt`, `rtrv-gsmmap-scrn`, `rtrv-gsms-opcode`,
`rtrv-gta`, `rtrv-gtt`, `rtrv-map`

The specified MAPSET must exist in the database.

Recovery

1. Display the MAP table. Enter the **rtrv-map** command.
 2. Add the MAPSET to the MAP table. Enter the **ent-map** command.
Refer to the *Commands Manual* for detailed information about the use of these commands.
 3. Re-enter the command that generated this error message.
Call your Customer Care Center if this error message appears again.
-

E4528 Cmd Rej: PC/SSN doesn't exist in MAPSET

Commands Used: **chg-gsmmap-scrn**, **chg-gsms-opcode**, **chg-gta**, **chg-map**, **chg-gtt**, **chg-map**, **dlt-map**, **ent-gsmmap-scrn**, **ent-gsms-opcode**, **ent-gta**, **ent-gtt**, **rtrv-map**

For the **chg/dlt/rtrv-map** commands, if the **pc**, **ssn** and **mapset** parameters are specified, then that **pc/ssn/mapset** combination must already be provisioned in the MAP table.

The specified **pc/ssn** must exist in the MAPSET

- if the **mapset** parameter is not specified as **dflt**.
- OR
- if the **mapset** parameter is specified as **dflt (mapset=dflt)** and the **force** parameter is specified as **no (force=no)**.

Recovery **chg/dlt/rtrv-map** commands

1. Determine the **pc/ssn/mapset** entries in the MAP table. Enter the **rtrv-map** command.
 2. Re-enter the appropriate **chg/dlt/rtrv-map** command specifying a valid **pc/ssn/mapset** parameter combination that exists in the MAP table.
-

Recovery **chg-gsms-opcode**

1. Determine the **pc/ssn** entries in the MAP table. Enter the **rtrv-map** command.
 2. Re-enter the **chg-gsms-opcode** command specifying a valid **pc/ssn** that exists in the MAP table.
-

Recovery ent-gsms-opcode

1. Determine the **pc/ssn** entries in the MAP table. Enter the **rtrv-map** command.
 2. Re-enter the **ent-gsms-opcode** command specifying a valid **pc/ssn** that exists in the MAP table.
-

E4529 Cmd Rej: MAP entry is being referred by other entries**Commands Used: dlt-map**

You cannot delete a MAP table entry that is still referenced by a translation or other GSM Map Screening entry or entries. If the value of the **mapset** parameter is specified as any value other than **dflt**, then the **pc/ssn/mapset** parameters must not be referenced from a GTT, GSM-MAP Opcode or GSM MAP Screening table entry.

Recovery

1. Display the MAP table. Enter the **rtrv-map** command.
 2. From the output of step 1, determine if the **pc/ssn/mapset** parameters reference a GTT, GSM-MAP Opcode or GSM MAP Screening table entry.
 3. To delete a MAP, enter the **chg-map** command specifying **mapset=dflt**.
-

E4530 Cmd Rej: MAPSET must be specified if action is FORWARD/DUP/DUPDISC**Commands Used: chg-gsms-opcode, ent-gsms-opcode**

The **mapset** parameter must be specified if the screening **action** parameter is specified as either **forward**, **duplicate**, or **dupdisc**.

Recovery

Re-enter the command specifying the **action** parameter as either **forward**, **duplicate**, or **dupdisc** and the **mapset** parameter.

E4531 Cmd Rej: NMAPSET must be specified if FORCE is specified**Commands Used: chg-gsms-opcode, chg-gsmmap-scrn**

The **force** parameter may be specified only if the new mapset id (**nmapset**) parameter is specified.

Recovery

Re-enter the command specifying both the **force=yes** and the **nmapset** parameters.

E4532 Cmd Rej: MAPSET must be specified (only) if RI parameter is SSN

Commands Used: **chg-gtt**, **ent-gtt**

The **mapset** parameter can only be specified, if the Flexible GTT Load-Sharing (FGTTLS) feature is enabled and the **ri=ssn**. The **mapset** parameter must be specified when the Flexible GTT Load-Sharing (FGTTLS) feature is enabled and **ri=ssn**. The **mapset** parameter must not be specified if **ri=gt**.

Recovery

Re-enter the command specifying both the **ri=ssn** and the **mapset** parameters

E4534 Cmd Rej: CSPC entry is being referred by other entities

Commands Used: **dlt-cspc**

You cannot delete a Concerned Signaling Point Code group cannot that is still referenced by one or more Mate Application entities. The specified CSPC group cannot be deleted because it is being referenced by other RPC3/MAP table entries.

NOTE: Error message E4534 can only be received if the Flexible GTT Load-Sharing feature is enabled. If the Flexible GTT Load-Sharing feature is not enabled, the following caution note will be displayed:

CSPC GROUP MAY BE IN USE BY A MATE APPLICATION

Recovery

1. Display the RPC3/MAP table. Enter the **rtrv-cspc** command.
2. Reassign the specified **cspc** references in the RPC3/MAP table. Enter the **chg-cspc** command.
3. Delete the specified **cspc** from the RPC3/MAP table. Enter the **dlt-cspc** command.

Call your Customer Care Center if this error message appears again.

E4535 Cmd Rej: NDGT parameter is invalid for CGSSN, CGPC and OPC sets

Commands Used: `chg-gttset`, `ent-gttset`

You cannot specify the number of digits (**ndgt**) parameter if the value for the GTT set type (**settype**) parameter is **cgssn**, **opc** or **cgpc**.

Recovery

Perform one of the following

- Re-enter the command specifying the **ndgt** parameter and a value for the **settype** of either **cdgta** or **cggta**.

OR

- Re-enter the command without specifying the **ndgt** parameter and a value for the **settype** of either **cgssn**, **opc** or **cgpc**.
-

E4536 Cmd Rej: settype parameter must be specified

Commands Used: `ent-gttset`

The GTT set type (**settype**) parameter must be specified if the Origin based SCCP Routing feature is enabled.

Recovery

Determine if the Origin based SCCP Routing feature is enabled. Enter the `rtrv-ctrl-feat` command.

- If the Origin based SCCP Routing feature is enabled, re-enter the `ent-gttset` command specifying the **settype** parameter.
- If the Origin based SCCP Routing feature is not enabled, enable the feature. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Re-enter the `ent-gttset` command specifying the **settype** parameter.

E4537 Cmd Rej: Power Threshold entry already exists in FPT table

Commands Used: `ent-frp-pwr`

The value specified for the **thrshld** parameter is already be provisioned in the Frame Power Threshold table.

Recovery

Enter the **chg-frm-pwr** command specifying a different value (valid range is 30 - 65 amps) for the **thrshld** parameter.

Call your Customer Care Center if this error message appears again.

E4538 Cmd Rej: Power Threshold entry does not exist in FPT table

Commands Used: **chg-frm-pwr**, **dlt-frm-pwr**

A value for the frame power threshold (**thrshld**) parameter does not exist in the Frame Power Threshold table.

Recovery

Enter the **ent-frm-pwr** command to add the **thrshld** parameter value to the Frame Power Threshold table.

Call your Customer Care Center if this error message appears again.

E4539 Cmd Rej: Failed reading FPT table

Commands Used: **chg-frm-pwr**, **dlt-frm-pwr**, **dlt-shlf**,
ent-frm-pwr, **rtrv-frm-pwr**

The Frame Power Threshold table is inaccessible. The Frame Power Threshold table must be accessible.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E4540 Cmd Rej: Failed reading Assembly Power table

Commands Used: **rtrv-stp**

The Assembly Power table is inaccessible. The Assembly Power table must be accessible.

Recovery

Re-enter the **rtrv-stp** command.

Call your Customer Care Center if this error message appears again.

E4541 Cmd Rej: Entered Frame must be a provisioned frame

Commands Used: **ent-frm-pwr**, **rtrv-frm-pwr**, **rtrv-stp**

The frame specified by the frame id parameter (**frm**) is not a provisioned frame (i.e. no shelf is provisioned in that frame). Refer to Table 2-41 on page 2-862 for a list of valid Frame ID parameter values.

Table 2-41. Valid Frame ID Parameter Values

CF00	Control Frame
EF00	First Extension Frame
EF01	Second Extension Frame
EF02	Third Extension Frame
EF03	Fourth Extension Frame
EF04	Fifth Extension Frame

Recovery

1. Determine which shelves are provisioned. Enter the **rtrv-shlf** command.
 2. Re-enter the command specifying a value for the frame id parameter for a provisioned frame (shelf is provisioned in that frame).
-

E4542 Cmd Rej: Failed deleting shelf as FPT entry is provisioned

Commands Used: **dlt-shlf**

If the equipped shelf is the only provisioned shelf in the frame, the Frame Power Threshold (FPT) entry cannot be configured for the corresponding frame in the Frame Power Threshold table.

Recovery

1. Delete the frame power value for the specified frame. Enter the **dlt-frm-pwr** command.
 2. Delete the shelf. Enter the **dlt-shlf** command.
-

E4543 Cmd Rej: PC/MAPSET does not exist in MAP table

Commands Used: **dlt-map**, **rtrv-map**

No matching entry for the specified **pc** and **mapset** exists in the MAP Table.

- For the **dlt-map** command, if the **pc** and **mapset** parameters are specified and **all=yes** is specified, then at least one entry for that **pc/mapset** must exist in MAP table.
- For the **rtrv-map** command, if the **pc** and **mapset** parameters are specified and the **ssn** parameter is **not** specified, then at least one entry for that **pc/mapset** must exist in MAP table.

Recovery

Re-enter the command specifying valid **pc** and **mapset** parameter values.

E4544 Cmd Rej: The IDPS for Prepaid Feature Must be Enabled

Commands Used: **enable-ctrl-feat**

The IDP Screening for Prepaid feature must be enabled before provisioning is allowed.

NOTE: Once a feature that is controlled using a feature access key is permanently enabled, it cannot be disabled. Features with enabled keys that are designated as On/Off features can be turned on and off using the **chg-ctrl-feat** command. Refer to the *Commands Manual* for more information about enabling features using access keys.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.
2. If the IDP Screening for Prepaid feature is enabled (see the output of step 1), re-enter the command that generated this message.
3. If the IDP Screening for Prepaid feature is not enabled, enable it. Enter the **enable-ctrl-feat** command.

Refer to the *Commands Manual* for detailed information about the use of the **enable-ctrl-feat** command.

4. Verify that the IDP Screening for Prepaid feature is enabled. Enter the **rtrv-ctrl-feat** command. Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4545 Cmd Rej: IDP Screening for Prepaid feature must be ON when SERV=IDPS

Commands Used: chg-ctrl-feat

The IDP Screening for Prepaid feature must be on before you can specify the **serv=idps** parameter.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.
2. If the IDP Screening for Prepaid feature is turned on (see the output from step 1), re-enter the **chg-ctrl-feat** command that generated this error message.

Call your Customer Care Center if this error message appears again.

3. If the IDP Screening for Prepaid feature is turned off (see the output from step 1), turn it on. Enter the **chg-ctrl-feat:idps=on** command.

Refer to the *Commands Manual* for detailed information about the use of the **chg-ctrl-feat** command.

4. Verify that the IDP Screening for Prepaid feature is turned on. Enter the **rtrv-ctrl-feat** command. Re-enter the **chg-ctrl-feat** command that generated this error message.

Call your Customer Care Center if this error message appears again.

E4546 Cmd Rej: GTT must be on before IDPS can be enabled

Commands Used: chg-feat, enable-ctrl-feat

The GTT feature must be on before you can enable the IDP Screening for Prepaid feature. You cannot enable the IDPS feature unless the GTT feature is on.

Recovery

1. Display the features in the database. Enter the **rtrv-ctrl-feat** command.

2. If the GTT feature is turned on (see the output of step 1), re-enter **enable-ctrl-feat** the command and the appropriate part number and access key information.
 3. If the GTT feature is turned off (see the output of step 1), turn it on. Enter the **chg-feat:gtt=on** command.
 4. Verify that the GTT feature is turned on. Enter the **rtrv-ctrl-feat** command. Re-enter the command that generated this message.
Call your Customer Care Center if this error message appears again.
-

E4547 Cmd Rej: IDPS cannot be enabled if ASM/TSM is present

Commands Used: **enable-ctrl-feat**

You cannot enable the IDP Screening for Prepaid feature with ASM and TSM cards in the system. If at least one ASM/TSM card is present the IDPS feature cannot be enabled. To enable the IDP Screening for Prepaid feature requires a DSM card running the VSCCP application.

Recovery

1. Display the cards in the system. Enter the **rtrv-card** command.
 2. In the output of step 1, if an ASM or TSM card is present in the system, the APPL will be listed as SCCP, which is incompatible with the IDP Screening for Prepaid feature. To support the IDP Screening for Prepaid feature, the system requires a DSM card running the VSCCP application.
 3. Verify that the system contains a DSM card running the VSCCP application. Contact your Customer Care Center if you need assistance.
-

E4548 Cmd Rej: Requested service parameters not supported when SERV=IDPS

Commands Used: **chg-srvsel**, **ent-srvsel**

The service parameters specified are not supported when **serv=idps**. If the **serv=idps** parameter is specified, the following mandatory service selector parameters must also be specified: **tt**, **serv**, **ssn** and the global title indicator parameters **gti** and **gtii**. The optional service selector parameters supported are: **np** and **nai**.

Recovery

Re-enter the command specifying the correct service selector parameters.

Call your Customer Care Center if this error message appears again.

E4549 Cmd Rej: EDATE/ETIME must be greater than current system date/time

Commands Used: `inh-alm`

For the `inh-alm` command, the `edate` and `etime` specified must be greater than the current system date and time.

Recovery

Re-enter the `inh-alm` command specifying values for the `edate` and `etime` parameters that are greater than the values for the current system date and time.

E4550 Cmd Rej: Both EDATE and ETIME parameters are required

Commands Used: `inh-alm`

For the `inh-alm` command, both `edate` and `etime` parameters must be specified if the value of the `dur` parameter is specified as `timed` (`dur=timed`).

Recovery

Re-enter the `inh-alm` command specifying `dur=timed` and both the `edate` and the `etime` parameters.

E4551 Cmd Rej: DISPLAY parameter is mandatory with DUR parameter

Commands Used: `rept-stat-alm`

The `display` parameter (`disp`) must be specified if the `dur` parameter is specified.

Recovery

Re-enter the `rept-stat-alm` command specifying both the `dur` parameter and the `disp` parameter.

E4552 Cmd Rej: DUR parameter is mandatory with EDATE parameter

Commands Used: `rept-stat-alm`

For the `rept-stat-alm` command, if you specify the `edate` parameter, you must also specify the `dur` parameter.

Recovery

Re-enter the `rept-stat-alm` command specifying both the `edate` parameter and the `dur` parameter.

E4553 Cmd Rej: EDATE parameter requires DUR = timed

Commands Used: `rept-stat-alm`

For the `rept-stat-alm` command, if the `edate` parameter is specified, the value specified for the `dur` parameter must be `timed`.

Recovery

Perform one of the following actions:

Re-enter the `rept-stat-alm` command specifying the `edate` parameter and `timed` for the `dur` parameter `dur=timed`.

OR

Re-enter the `rept-stat-alm` command without specifying `edate` parameter.

E4554 Cmd Rej: DEV must be either slk, ls, or route if CLI is specified

Commands Used: `rept-stat-alm`

The `device` parameter must be specified as either `slk`, `ls`, or `route`, if the `cli` parameter is specified.

Recovery

Perform one of the following actions:

Re-enter the `rept-stat-alm` command specifying either `slk`, `ls` or `route` for the `device` parameter if the `cli` parameter is specified.

OR

Re-enter the **rept-stat-alm** command without specifying **cli** parameter.

E4555 Cmd Rej: Version parameter not supported for SUA or M3UA

Commands Used: **chg-assoc**

The adapter type specified (SUA or M3UA) is not supported by the **ver** parameter. The **ver** parameter only supports M2PA adapters (**ver=d6**) or (**ver=rfc**).

Recovery

Re-enter the **chg-assoc** command specifying the **ver** parameter only when the adapter is an M2PA Draft 6 (**ver=d6**) or M2PA RFC (**ver=rfc**).

Call your Customer Care Center if this error message appears again.

E4556 Cmd Rej: Timer not supported for M2PA Draft 6

Commands Used: **chg-m2pa-tset**

The T2 timer is not supported by M2PA Draft 6. The T2 timer was specified with the **ver=d6** parameter specified. The T2 timer can only be specified when **ver=rfc**.

Recovery

Re-enter the **chg-m2pa-tset** command specifying **ver=rfc** for the T2 timer.

Call your Customer Care Center if this error message appears again.

E4557 Cmd Rej: Timer value or SRCTSET required

Commands Used: **chg-m2pa-tset**

A timer value or M2PA timer set value (**srctset**) must be specified. If the **srctset** parameter is specified, no other timer values can be specified. Also, the timer set specified here cannot be the timer set specified by the timer set name (**tset**) parameter.

NOTE: The **srctset** parameter and the **tset** parameter cannot specify the same timer set name.

Recovery

Re-enter the **chg-m2pa-tset** command specifying an M2PA timer parameter or the **srcset** parameter.

Refer to the *Commands Manual* for detailed information about the use of the **chg-m2pa-tset** command.

Call your Customer Care Center if this error message appears again.

E4559 Cmd Rej: ASM/TSM Cards Cannot be Provisioned when IDPS is Enabled

Commands Used: **ent-card**

ASM cards and TSM cards do not support the IDP Screening for Prepaid feature. The IDP Screening for Prepaid feature requires a DSM card running the VSCCP application.

Recovery

1. Display the cards in the system. Enter the **rtrv-card** command.
 2. In the output from step 1, if an ASM or TSM card is present in the system, it will show the APPL as SCCP, which is incompatible with the IDP Screening for Prepaid feature. To support the IDP Screening for Prepaid feature, the system requires a DSM card running the VSCCP application.
 3. Verify that the system contains a DSM card running the VSCCP application. Contact your Customer Care Center if you need assistance.
-

E4560 Cmd Rej: CGSSNSN set domain must be the same as GTTSN set domain

Commands Used: **chg-gta**, **ent-gta**

The name specified for the GTT set name (**gttsn**) set domain, and the CGSSN Set Name (**cgssnsn**) set domain, must be the same (either **ansi** or **itu**).

Recovery

Re-enter the command specifying the same name (either **ansi** or **itu**) for both the **cgssnsn** and **gttsn** parameters.

E4564 Cmd Rej: CGGTASN set domain must be the same as GTTSN set domain

Commands Used: `chg-gta`, `ent-gta`

The name specified (either **ansi** or **itu**) for the GTT Set Name (**gttsn**) set domain, and the CGGTA Set Name (**cggtsn**) set domain, must be the same.

Recovery

Re-enter the command specifying the same name (either **ansi** or **itu**) for both the **gttsn** and **cggtsn** parameters.

E4579 Cmd Rej:MTPLPRST option must be enabled

Commands Used: `chg-stpopts`, `rtrv-stpopts`

The MTP Low Priority Route Set Test option must be enabled.

The MTP Low Priority Route Set Test option controls route-set-test messaging for routes other than the DPC-only least cost routes. If higher cost routes are used for exception routing, this feature maintains accurate non-adjacent status to ensure that routing occurs properly.

Recovery

Enable the MTP Low Priority Route Set Test option. Enter the **chg-stpopts:mtplprst=yes** command.

Call your Customer Care Center if this error message appears again.

E4580 Cmd Rej: CIC must be specified if ECIC is specified

Commands Used: `chg-rtx`, `dlt-rtx`, `ent-rtx`, `rtrv-rtx`

The start circuit identification code (**cic**) parameter must be specified if the end circuit identification code (**ecic**) parameter is specified.

Recovery

Re-enter the command specifying both the **cic** and the **ecic** parameters.

Call your Customer Care Center if this error message appears again.

E4581 Cmd Rej: Unsupported Hardware is equipped in the system

Commands Used: enable-ctrl-feat

The Origin-Based MTP Routing feature key cannot be enabled if there is any unsupported hardware equipped in the system. Once the Origin-Based MTP Routing feature is turned on, any unsupported hardware (link cards) defined in Table 2-42 will auto-inhibit.

Table 2-42. EAGLE 5 ISS Link Cards Not Supported

LIM Card Name	LIMDS0	LIMV35	LIMOCU	ILA/EILA	LIM-E1	ASM	Dual-Slot DCM
Part Number	870-1009	870-1010	870-1012	870-1014-xx	870-1379-01	obsolete	870-1984-xx 870-2197-xx

Recovery

1. Upgrade your hardware to ensure that you have no unsupported cards on your system.
2. Enable the Origin-Based MTP Routing feature. Re-enter the **enable-ctrl-feat** command specifying the appropriate part number and access key information.

Call your Customer Care Center if this error message appears again.

E4582 Cmd Rej: Single rte to APC or SAPC for IPGW LS allowed

Commands Used: chg-ls, chg-rte, ent-ls, ent-rte

You cannot specify more than one route to an APC or SAPC for an IPGWx linkset.

- For the **chg-rte** and **ent-rte** commands, you cannot assign more than one route to an APC or SAPC for an IPGWx linkset.
- For the **chg-ls** command, you cannot assign an SAPC to an IPGWx linkset that is already assigned to a route involving another linkset
- For the **ent-ls** command, you cannot assign an APC or SAPC to an IPGWx linkset that is already assigned to a route involving another linkset.

Recovery

Re-enter the **ent/chg-rte** command specifying a different DPC since the selected point code (APC or SAPC of an IPGWx linkset) is already assigned a single route.

E4583 Cmd Rej: DISPLAY parameter is mandatory with FRM parameter

Commands Used: **rtrv-stp**

The display id (**display**) parameter must be specified if the frame id (**frm**) parameter is specified.

Recovery

Re-enter the **rtrv-stp** command specifying both the **display** and **frm** parameters.

E4584 Cmd Rej: MTP Origin Based Routing Feature must be ON

Commands Used: **chg-rtx, dlt-rtx, ent-rtx, rtrv-rtx**

The MTP Origin Based Routing feature must be enabled and turned on before you can access a UI option that is unique to the feature.

Recovery

1. Determine the status of the MTP Origin Based Routing feature. Enter the **rtrv-ctrl-feat** command.
2. Verify that the MTP Origin Based Routing feature has been purchased and installed in the system. Contact your Customer Care Center for assistance.
3. If the MTP Origin Based Routing feature is enabled, go to step 5.
4. If the MTP Origin Based Routing feature is not enabled, enable it. Enter the **enable-ctrl-feat** command and the appropriate part number and access key information. Verify that the MTP Origin Based Routing feature is enabled. Enter the **rtrv-ctrl-feat** command.

Refer to the *Commands Manual* for detailed information about the use of the **enable-ctrl-feat** command.
5. Turn on the MTP Origin Based Routing feature. Enter the **chg-ctrl-feat** command.

Call your Customer Care Center if this error message appears again.

E4585 Cmd Rej: Failed Reading SCCP Service Table

Commands Used: `chg-sccp-serv`, `dlt-sccp-serv`, `rtrv-mrn`,
`rtrv-sccp-serv`

The SCCP Service Table is corrupt or cannot be found by the system.

Recovery

Re-enter the command.

Call your Customer Care Center if this error message appears again.

E4586 Cmd Rej: Invalid combination of new and existing point codes

Commands Used: `chg-mrn`, `dlt-mrn`, `ent-mrn`, `rtrv-mrn`

The combination of point codes entered are invalid.

Recovery

Re-enter the command specifying a valid combination of point codes.

E4587 Cmd Rej: At least one point code must be specified

Commands Used: `dlt-sccp-serv`

You entered this command without specifying at least one point code.

Recovery

Re-enter the `dlt-sccp-serv` command specifying both the point code parameter (`pc`) and its associated relative cost (`rc`) together as a pair.

E4589 Cmd Rej: SCCP-SERV allocation within MRN table is full

Commands Used: `chg-sccp-serv`

The allocation of SCCP-SERV point codes within the MRN table is full. For each supported service (Gport and Gflex), up to seven point codes may be specified for each network type (ANSI, ITU-I, S-ITU-I, ITU-N, S-ITU-N, and ITU-N24).

Recovery

1. Display the SCCP Service table. Enter the **rtrv-sccp-serv** command.
 2. Change one of the existing point codes in the SCCP service group. Enter the **chg-sccp-serv:pc=xxx-xxx-xxx:rc=xxx** command where **xxx-xxx-xxx** is a point code in the SCCP service group from the output in step 1.
-

E4590 Cmd Rej: Maximum point codes have been allocated to SCCP-SERV set

Commands Used: chg-sccp-serv

The specified SCCP service group is full. You cannot provision more than seven point codes in a SCCP service group. Before you can add a new point code to the group, you must delete an existing point code from the group.

Recovery

1. Display the SCCP Service table. Enter the **rtrv-sccp-serv** command.
 2. Change one of the existing point codes in the SCCP service group. Enter the **chg-sccp-serv:pc=xxx-xxx-xxx:rc=xxx** command where **xxx-xxx-xxx** is a point code in the SCCP service group from the output in step 1.
-

E4591 Cmd Rej: PC must already exist in the SCCP-SERV set

Commands Used: dlt-sccp-serv

The specified point code does not exist in the specified SCCP service group.

Recovery

1. Display the SCCP Service table. Enter the **rtrv-sccp-serv** command.
2. Re-enter the **dlt-sccp-serv** command specifying a point code that exists in the specified SCCP service group.

Call your Customer Care Center if this error message appears again

E4594 Cmd Rej: Feature associated with SERV must be ON or enabled

Commands Used: `chg-sccp-serv`, `rtrv-mrn`, `rtrv-sccp-serv`

The G-Flex feature must be enabled before the `serv=gflex` parameter can be specified. The G-Port feature must be enabled before the `serv=gport` parameter can be specified.

NOTE: Once a feature that is controlled using a feature bit has been turned on, it cannot be turned off. Refer to the `chg-feat` command in the *Commands Manual* for further information.

Recovery

Display the features in the database. Enter the `rtrv-ctrl-feat` command.

If the G-Flex or G-Port feature is enabled (from the output of step 1), re-enter the command.

Call your Customer Care Center if this error message appears again.

1. If the G-Flex or G-Port feature is not enabled (from the output of step 1), enable it. Enter the `enable-ctrl-feat` command and the appropriate part number and access key information.

Refer to the *Commands Manual* for detailed information about the use of the `enable-ctrl-feat` command.

2. Verify that the G-Flex or G-Port feature is enabled. Enter the `rtrv-ctrl-feat` command. Re-enter the command that generated this message.

Call your Customer Care Center if this error message appears again.

E4595 Cmd Rej: Only one E1 port allowed for Linkclass equal unchan

Commands Used: `ent-e1`

You cannot specify more than one e1 port per E5-E1/T1 card as `linkclass=unchan`.

Recovery

Re-enter the `ent-e1` command specifying only one e1 port on an E5-E1/T1 card as `linkclass=unchan`.

E4597 Cmd Rej: DPC cannot be IPGWx APC or SAPC

Commands Used: `ent-appl-rtkey`

You cannot specify a DPC for a routing key that is the adjacent node (APC) or Secondary Adjacent Point Code (SAPC) for an IPGW linkset.

Recovery

1. Display a list of point codes in the linkset. Enter the `rtrv-ls` command.
2. Re-enter the `ent-appl-rtkey` command specifying a DPC that is not an APC or SAPC for an IPGW linkset.

Call your Customer Care Center if this error message appears again.

E4598 Cmd Rej: Routing Context not configured

Commands Used: `chg-appl-rtkey`

The value of the `nrcontext` parameter cannot be changed for a routing key if the `rcontext` parameter has not been configured for that routing key.

Recovery

1. Provision the `rcontext` parameter for the routing key. Enter the command `chg-appl-rtkey:rcontext=`
2. Re-enter the `chg-appl-rtkey` command specifying both the `rcontext` parameter and the new value for the `nrcontext` parameter for the routing key.

Example: `chg-appl-rtkey:rcontext=1:nrcontext=2`

E4599 Cmd Rej: GTT Set specified by GTTSN is being referred in SCCPOPTS

Commands Used: `dlt-gttset`

You cannot delete a GTT set that is still referenced by the SCCP Options table.

Recovery

1. Display the SCCP Options table. Enter the `rtrv-sccpopts` command.
2. Delete the specified GTT Set name. Enter the `chg-sccpopts` command specifying `gttsn=none`.

Call your Customer Care Center if this error message appears again.

E4600 Cmd Rej: Must specify either SNAME or ASNAME or RC

Commands Used: `ent-appl-rtkey`

Either the `sname` or `asname` or `rc` parameters must be specified.

Recovery

Re-enter the `ent-appl-rtkey` command specifying either the `sname` or the `asname` or the `rc` parameters.

Refer to the *Commands Manual* for detailed information about the use of the `ent-appl-rtkey` command.

E4601 Cmd Rej: CGGTASN and CGPCSN are mutually exclusive

Commands Used: `chg-gttse1`, `ent-gttse1`

You cannot specify the `cggtsn` and `cgpcsn` parameters together in the same command.

Recovery

Re-enter the command specifying either the `cggtsn` or the `cgpcsn` parameters separately.

E4602 Cmd Rej: Requested Assoc Buffer Space Exceeds Available Buffer Space

Commands Used: `chg-assoc`, `ent-assoc`

The requested associate buffer size exceeds available buffer space for the card type. The supported card and allowable buffer configuration sizes are shown in Table 2-43 on page 2-878.

Table 2-43. Default Buffer Configuration Sizes

Card	Default Buffer Size (KB)	Minimum Buffer Size (KB)	Maximum Buffer Size (KB)
DCM/IPGW	16	8	400
EDCM/IPLIM	200	8	400
EDCM/IPGW	16	8	400
E5-ENET/IPLIM	200	8	400
E5-ENET/IPGW	16	8	400

Recovery

1. Determine the used and total sctp buffer space on the card and the card location. Enter the **rtrv-assoc** command.
2. Re-enter the command specifying a buffer size that is between **8** and **400** KB.

Example:

```
chg-assoc:aname=xxxxx:open=no
```

```
chg-assoc:aname=xxxxx:bufsize=345
```

Call your Customer Care Center if this error message appears again

E4603 Cmd Rej: CGTT/CGNPV/CGNAIV mustn't be specified when CGGTIx=0

Commands Used: **rtrv-data-gtt**

You cannot specify the **cgtt**, **cgnpv**, or **cgnaiv** parameters when the value specified for the **cggti(x)** parameter is 0 (**cggti(x)=0**).

Recovery

Re-enter the command specifying **cggti(x)=0** without specifying the **cgtt**, **cgnpv**, or **cgnaiv** parameters.

E4604 Cmd Rej: CGPC must be specified

Commands Used: **rtrv-data-gtt**

For the **rtrv-data-gtt** command, you must specify a value for the **cgpc** parameter when gttmode contains both cgpa mode and **cggti(x)=0**.

Recovery

Re-enter the **rtrv-data-gtt** command specifying the **cgpc** parameter.

E4607 Cmd Rej: Linkset referenced by exception route**Commands Used: dlt-ls**

The specified linkset is referenced by an exception route. You cannot delete a linkset that is being used by an exception route.

Recovery

Perform one of the following actions:

Re-enter the **dlt-ls** command specifying a linkset that is not referenced by an exception route.

OR

1. Display the Route table. Enter the **rtrv-rtx** command.
 2. Delete the exception route references to the specified linkset. Enter the **dlt-rtx** command.
 3. Delete the specified linkset. Enter the **dlt-ls** command.
-

E4608 Cmd Rej: True Point Code can exist only in Default MAPSET**Commands Used: chg-map, ent-map**

A true PC/SSN can only exist in the default MAP Set.

Recovery

1. Display the site point codes in the system. Enter the **rtrv-sid** command. The site point codes are shown in the PCA, PCI, PCN, and PCN24 fields of the **rtrv-sid** command output.
 2. Re-enter the command specifying a **pc/ssn** that is not listed in the PCA, PCI, PCN, and PCN24 fields of the output from step 2.
-

E4900 Cmd Rej: Entry does not exist with specified GTIN24-TT-NP(V)-NAI(V)

Commands Used: `chg-srvsel`, `dlt-srvsel`

You specified an entry that does not match an existing `gtin24`, `tt`, `np(v)`, `nai(v)`, and `ssn` parameter combination as required.

Recovery

1. Display the service selectors. Enter the `rtrv-srvsel` command.
 2. Re-enter the command specifying a parameter combination that exists in the database.
-

E4901 Cmd Rej: TTI, NP, NAI cannot be specified for a direction of ATOI

Commands Used: `dlt-gtcnv`

The following parameter(s) cannot be specified when the direction of conversion is ANSI-to-ITU (`dir=atoi`): ITU translation type (`tii`), numbering plan (`np`), and nature of address indicator (`nai`).

Recovery

Re-enter the `dlt-gtcnv` command specifying `dir=atoi`, but without specifying parameters `tii`, `np`, and `nai`.

E4902 Cmd Rej: CSPC group cannot contain both PCN and PCN24 point codes

Commands Used: `ent-cspc`

The specified concerned signaling point code types are mutually exclusive. A concerned signaling point code group cannot include both `pcn` and `pcn24` point codes (ITUN and ITUN24).

Recovery

1. Determine which type of point code is desired (ITUN or ITUN24).
2. Re-enter the `ent-cspc` command specifying either `pcn` or `pcn24` point codes, but not both.

Call your Customer Care Center if this error message appears again.

E4903 Cmd Rej: If NGTI is 4, PC cannot be ANSI

Commands Used: `chg-gta`, `chg-gtt`, `ent-gta`, `ent-gtt`

You cannot specify an ANSI point code if the new GTI code (**ngti**) parameter is 4. If **ngti=4**, you cannot specify an ANSI point code; if you need an ANSI point code, specify **ngti=2**.

Recovery

Re-enter the command, specifying either:

- **ngti=4** with no ANSI point code specified
- OR
- **ngti=2** for ANSI point codes
-

E4904 Cmd Rej: ADDTBLCNV and DELTBLCNV cannot be specified together

Commands Used: `chg-upgrade-config`

The specified parameters (**addtblcnv** and **delttblcnv**) are mutually exclusive.

Recovery

Re-enter the **chg-upgrade-config** command specifying either the **addtblcnv** or the **delttblcnv** parameter, but not both.

Call your Customer Care Center if this error message appears again.

E4999 Cmd Rej: Undefined

Commands Used: `all commands`

Undefined error.

Recovery

Call your Customer Care Center.

SEAS Error Messages

Introduction	3-2
Message Listing and Description.....	3-2

Introduction

This chapter contains an index of all of the Signaling Engineering and Administration System (SEAS) error messages generated by the system. Descriptions include the SEAS commands that trigger the error messages, the equivalent system error messages and commands, and the explanatory text.

SEAS error messages are generic pointers to system problems. This chapter is used to find system-specific solutions.

Failure to consult this index when necessary can result in service-affecting issues, including delays in problem resolution.

When a SEAS command fails, use the system `rtrv-secu log` command to secure a list of the operations in progress at the time of the failure. When you find the command that failed, look it up in the first column of the table below. Then, look up the corresponding SEAS error message in the second column. Note the system error code, then look it up in Chapter 2, “Command Rejected Messages” of this manual. Follow the troubleshooting directions found there.

Some resolutions to the error messages require the assistance of your Customer Care Center specialist. To receive technical assistance refer to “Customer Care Center” on page 1-8.

Message Listing and Description

The messages are listed in Table 3-1, “SEAS Cross Reference Table,” on page 3-3 in alphabetical order by SEAS command.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-DSTN	DIFC		ENT-DSTN	When a PC destination address is added, the STP shall determine whether the corresponding destination is an adjacent signaling point, as evidenced by a match against a far-end point code (FE PC) in its LINK SET entity-set. If so, the STP shall ensure that the destination identifier is identical to that link set's FE CLLI.
ADD-DSTN	SEHW	E2145	ENT-DSTN	MAS configuration table not accessible.
ADD-DSTN	DISI	E2163	ENT-DSTN	The STP shall validate the command to ensure that the destination identifier is not equal to the STP's own self-identity CLLI.
ADD-DSTN	DASI	E2168	ENT-DSTN	The STP shall validate the command to ensure that the specified destination address does not correspond to the STP's own DPC or any of its capability codes as specified in its SELF IDENTITY entity set.
ADD-DSTN	DIAS	E2184	ENT-DSTN	When a PC destination address is added, the STP shall determine whether the corresponding destination is an adjacent signaling point, as evidenced by a match against a far-end point code (FE PC) in its LINK SET entity-set. If so, the STP shall ensure that the destination identifier is assigned to no other destination address.
ADD-DSTN	IDNS	E2332	ENT-DSTN	The destination address cannot already be defined as an alias address.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-DSTN	DAAS	E2333	ENT-DSTN	The STP shall validate the command to ensure that the specified destination address does not already exist in the DESTINATION entity set.
ADD-DSTN	IDRE	E2340	ENT-DSTN	If the system is configured for ANSI formatted point code, the network indicator value of the DPC parameter must be 6 or greater when the cluster value is 0.
ADD-DSTN	INCE	E2359	ENT-DSTN	Space must be available in the Destination table.
ADD-DSTN	SEHW	E2648	ENT-DSTN	Route table not accessible.
ADD-DSTN	INCE	E2836	ENT-DSTN	If NCAI is specified as YES, the maximum number of provisioned nested clusters must be no greater than 500.
ADD-DSTN	IDNC	E2853	ENT-DSTN	The STP shall ensure that no argument for elei is entered if the destination address is not a cluster destination.
ADD-DSTN	IDNS	E2855	ENT-DSTN	Cluster destinations are not permitted if the CRMD feature is OFF.
ADD-DSTN	IDNC	E2856	ENT-DSTN	ELEI is only valid if the CRMD feature is ON.
ADD-DSTN	IDNS	E2868	ENT-DSTN	The STP shall ensure that no argument for NCAI is entered if the destination address is not a cluster destination.
ADD-DSTN	IDNV	E2869	ENT-DSTN	NCAI is only valid if the CRMD and Nested Cluster Feature is ON.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-DSTN	IDNS	E2875	ENT-DSTN	If provisioning a cluster destination, it cannot have the same network identifier (NI) and network cluster (NC) codes of any previously defined alias ANSI point codes.
ADD-DSTN	IDNS	E2877	ENT-DSTN	If provisioning a cluster point code, the collection of signaling points sharing the same network identifier (NI) and network cluster (NC) code must have the same route set.
ADD-DSTN	IDRE	E2886	ENT-DSTN	Destination address must be a full or a cluster point code.
ADD-DSTN	IDNV	E2955	ENT-DSTN	Network Routing is only valid if the NRT feature is ON.
ADD-DSTN	IPNS	N/A	ENT-DSTN	Supplier-specific signaling link parameter(s) (z) cannot be specified.
ADD-GTT	IDNS	E2169	ENT-GTT	If the system is defined as an ANSI system, the Translated Point Code must be a valid ANSI point code. If the ANSI/ITU/24 Bit SCCP Conversion feature is enabled, this MTT error code will not be generated.
ADD-GTT	IDRE	E2169	ENT-GTA	PC/PCA/PCI/PCN/PCN24 must not be out of range.
ADD-GTT	SAAS	E2401	ENT-GTA	The GTA range cannot overlap a currently existing range for the specified GTT Set in the STP active data base.
ADD-GTT	SAAS	E2401	ENT-GTT	The GTA range cannot overlap a current range.
ADD-GTT	IDNS	E2403	ENT-GTA	If EGTA is specified, GTA and EGTA must be the same length.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-GTT	IDNS	E2403	ENT-GTT	If a range of GTAs is specified, the endpoint values must be of the same length.
ADD-GTT	IDNS	E2404	ENT-GTT	The length of the specified GTA must match the number of digits provisioned for the specified Translation Type or the Translation Type referenced by the specified Translation Type Name, unless the PVGTT or VGTT feature is on. In the case the PVGTT feature is on the length of the specified GTA and EGTA can be less than or equal to the number of digits provisioned for the corresponding TT. In the case the VGTT feature is on, up to 10 different lengths can be provisioned per TT.
ADD-GTT	INCE	E2416	ENT-GTT	Unable to access database. Severe database failure.
ADD-GTT	SEHW	E2416	ENT-GTA	Failed accessing database.
ADD-GTT	SDNE	E2417	ENT-GTA	PC/PCA/PCI/PCN/PCN24 must exist as a Destination in the Route table or reside in a cluster that exists as a Destination in the Route table (for global title routing), unless the point code is the STP's True PC.
ADD-GTT	SDNE	E2417	ENT-GTT	The DPC must exist as a destination in the ORDERED ROUTE entity set or reside in a cluster that exists as a destination in the ORDERED ROUTE entity set (for global title routing). The following clause applies only to the DBS software base. The PC specified does not have to exist in the ORDERED ROUTE entity set if the PC is the EAGLE's True PC.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-GTT	SNEX	E2419	ENT-GTA	If a final GTT is specified (RI=SSN) with XLAT=DPC, and FORCE is not specified as "YES", PC must exist in the Remote Point Code/Mated Application table.
ADD-GTT	SNEX	E2419	ENT-GTT	If a final GTT is specified, the routing indication is DPC and the FORCE parameter is not specified as YES, the point code must exist in the SCCP Application entity set (Remote Point Code/Mated Application Table).
ADD-GTT	IDNC	E2420	ENT-GTA	If EGTA is specified, EGTA must be greater than GTA.
ADD-GTT	IDNC	E2420	ENT-GTT	If a range of GTAs is specified, the end of range value must be greater than the start of range value.
ADD-GTT	SANE	E2450	ENT-GTA	If a final GTT is specified (RI=SSN) with XLAT=DPCSSN, and FORCE is not specified as "YES", the PC-SSN must be populated in the Remote Point Code/Mated Application table.
ADD-GTT	SANE	E2450	ENT-GTT	If a final GTT is specified, the routing indicator is SSN, XLAT=DPCSSN, and the FORCE parameter is not specified as "YES", the DPC-SSN must be populated in the SCCP Application entity set (Remote Point Code/Mated Application Table).
ADD-GTT	SANE	E2450	ENT-GTT	If a final GTT is specified, the routing indicator is DPCSSN and the FORCE parameter is not specified as YES, the DPC-SSN must be populated in the SCCP Application entity set (Remote Point Code/Mated Application Table).

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-GTT	INCE	E2453	ENT-GTT	Subsystem table for primary remote point code is full.
ADD-GTT	INCE	E2454	ENT-GTT	Remote point code table is full.
ADD-GTT	RINC	E2457	ENT-GTA	If SSN is specified, XLAT must be DPCSSN.
ADD-GTT	RINC	E2457	ENT-GTT	If a Subsystem Number is specified, the Translate Indicator must be DPCSSN.
ADD-GTT	RINC	E2457	ENT-GTT	If a Subsystem Number is specified, the Translate Indicator must be DPCSSN.
ADD-GTT	INCE	E2462	ENT-GTA	If the XGTT feature is enabled, the GTT table may have up to either 400,000 or 1,000,000 entries. Refer to . If XGTT is not enabled, the GTT table contains up to 269,999 user entries. If the user attempts to enter more that the allowed number of GTT entries, an error message appears.
ADD-GTT	INCE	E2462	ENT-GTT	If the XGTT feature is enabled, the GTT table may have up to either 400,000 or 1,000,000 entries. Refer to . If XGTT is not enabled, the GTT table contains up to 269,999 user entries. If the user attempts to enter more that the allowed number of GTT entries, an error message appears.
ADD-GTT	INCE	E2462	ENT-GTA	The GTT table can not be FULL.
ADD-GTT	INCE	E2462	ENT-GTT	The GTT table can not be FULL.
ADD-GTT	IDNS	E2465	ENT-GTT	The specified Translation Type or the Translation Type referenced by the specified Translation Type Name must not be defined as an alias.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-GTT	SNEX	E2466	ENT-GTA	The Translation Type must match that of an existing ANSI GTT Selector which is assigned to a GTT Set.
ADD-GTT	SNEX	E2466	ENT-GTT	If a Translation Type is specified, the Translation Type must exist in the STP's active database.
ADD-GTT	IDNS	E2470	ENT-GTT	The network type of the Translation Type and Translated Point Code must match. You can not have mixed networks.
ADD-GTT	SEHW	E2648	ENT-GTA	Route table not accessible.
ADD-GTT	SEHW	E2648	ENT-GTT	Route table not accessible.
ADD-GTT	IDNV	E2859	ENT-GTA	PC/PCA/PCI/PCN/PCN24 must be a full point code.
ADD-GTT	IDNV	E2859	ENT-GTT	Translated Point Code must be a full point code.
ADD-GTT	SEHW	E2874	ENT-GTA	Site ID table not accessible.
ADD-GTT	SEHW	E2874	ENT-GTT	Site ID table not accessible.
ADD-GTT	SEHW	E3119	ENT-GTA	GTA table not accessible.
ADD-GTT	SEHW	E3120	ENT-GTA	GTT DBMM table not accessible.
ADD-GTT	SEHW	E3543	ENT-GTA	GTT Selector table not accessible
ADD-GTT	SEHW	E3544	ENT-GTA	GTT Set table not accessible.
ADD-GTT	IDNS	E3570	ENT-GTA	If the specified GTT Set is an ANSI set, PC/PCA must be a valid ANSI point code. If the ANSI/ITU/24 Bit SCCP Conversion feature is enabled, this MTT error code will not be generated.
ADD-GTT	IDNS	E3571	ENT-GTA	The length of the specified GTA must match the number of digits provisioned for the specified GTT Set referenced by GTTSN.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-GTT	IDNV	N/A	ENT-GTA	Alpha characters may not be specified for GTA.
ADD-GTT	SAAS	N/A	ENT-GTT	The DPC-SSN-GTA entity must not already exist in the ORDERED GLOBAL TITLE TRANSLATION entity set for that translation type in the STP active data base.
ADD-GTWYLS	IDNS	2337	ADD-GTWYLS	If GWSD is specified as ON, GWSA must also be ON.
ADD-GTWYLS	GNFI	E2494	ADD-GTWYLS	The NSFI must be in the range (STOP, OPC, DPC, BLKDPC, BLKOPC, SIO).
ADD-GTWYLS	GNRF	E2552	ADD-GTWYLS	The NSFI/NSR combo must exist in the GWS entity set.
ADD-GTWYLS	GNSR	E2553	ADD-GTWYLS	NSR must be specified if NSFI is not STOP.
ADD-GTWYLS	GNSR	E2554	ADD-GTWYLS	NSR can not be specified if NSFI is STOP.
ADD-GTWYLS	INCE	E2925	ADD-GTWYLS	There must be enough EAGLE screenset resources for the Gateway Linkset to be entered.
ADD-GTWYLS	GAEX	E2927	ADD-GTWYLS	The Gateway Linkset can not be provisioned locally, i.e. the SCRN parameter of the linkset entry must be 'none' before a Gateway Linkset can be provisioned.
ADD-GTWYLS	SNAS	E2929	ADD-GTWYLS	The generic linkset must exist.
ADD-GTWYLS	GAEX	E2930	ADD-GTWYLS	The GTWYLS must not already exist.
ADD-GTWYLS	SEHW	E3655	ADD-GTWYLS	The GWS Stop Action Set table not accessible.
ADD-GTWYLS	IDNS	E3656	ADD-GTWYLS	The ACTNAME name, if specified other than 'NONE', must exist in the GWS Stop Action Set Table.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-GTWYLS	IDNS	E3658	ADD-GTWYLS	Specifying ACTNAME via the supplier specific parameter block can only occur when NSFI is specified and equal to STOP.
ADD-GTWYLS	IPMS	N/A	ADD-GTWYLS	A linkset name must be specified.
ADD-GTWYLS	IPMS	N/A	ADD-GTWYLS	NSFI must be specified.
ADD-GTWYLS	IPNS	N/A	ADD-GTWYLS	LSGI(ln) Parameter is not supported.
ADD-LS	SEHW	E2122	ENT-LS	Linkset table not accessible.
ADD-LS	SEHW	E2145	ENT-LS	MAS configuration table not accessible.
ADD-LS	IDNS	E2167	ENT-LS	The specified Adjacent Point Code must not match any of the STP's capability codes as specified in its self-identity. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
ADD-LS	IDNS	E2168	ENT-LS	The specified Adjacent Point Code must not match the STP's own DPC as specified in its self-identity. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
ADD-LS	IDRE	E2169	ENT-LS	If the system is configured for ANSI formatted point code, the network indicator value of the FE PC parameter must be 6 or greater when the cluster value is 0.
ADD-LS	IDNS	E2169	ENT-LS	PC or MPC point code out of range. If the system is configured for ANSI formatted point code, the network indicator value of the FE PC parameter must be 6 or greater when the cluster value is 0.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-LS	IDNS	E2332	ENT-LS	Adjacent Point Code must not be defined as an alias. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
ADD-LS	FCDI	E2335	ENT-LS	If a PC destination address matching the entered FE PC is found, the STP shall compare the FE CLI for the given link set to the Destination Identifier (DI) of that matching destination. If they are not identical, the STP shall reject the ADD-LS command.
ADD-LS	FPAS	E2343	ENT-LS	The STP must ensure that the FE PC value specified is not assigned to any other linkset (Linkset Name).
ADD-LS	SAAS	E2345	ENT-LS	The STP must ensure that the linkset specified does not already exist in the STP's active database.
ADD-LS	INCE	E2347	ENT-LS	Linkset table must not be full.
ADD-LS	IDNS	E2591	ENT-LS	BEI must be omitted or YES if APC is in the X.25 domain.
ADD-LS	IDNS	E2646	ENT-LS	Adjacent Point Code cannot be referenced by an X.25 route with LC2NM=YES. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
ADD-LS	SEHW	E2648	ENT-LS	Route table not accessible.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-LS	IDNS	E2657	ENT-LS	The STP shall search its DESTINATION entity set for a PC destination address matching the entered FE PC. SEAS's view of the database requires that Destination entities be validated against linkset entities. This difference in rules represents a fundamental difference in the data base views of system and SEAS. If this condition is detected, the IDNS code must be returned to the SEAC.
ADD-LS	IDNS	E2834	ENT-LS	MTPRSE parameter not permitted if MTPRS feature is OFF(ANSI).
ADD-LS	IDNS	E2848	ENT-LS	ASL8 parameter is only valid for ANSI link sets.
ADD-LS	IDNS	E2858	ENT-LS	SLSCI parameter is only valid for ANSI link sets.
ADD-LS	IDNV	E2859	ENT-LS	Adjacent destination address must be a full point code. The SEAS ADD-LS command does not have any provisions for accepting partial point codes. However, if fewer than 9 numerals are received for the Point Code parameter, the commands will be rejected with the Input Data Not Valid error code.
ADD-LS	SEHW	E2874	ENT-LS	STP site ID table not accessible.
ADD-LS	IDNS	E3851	ENT-LS	MTPRSE parameter not permitted if ITUMTPRS feature is OFF(ITU).
ADD-SCRAFTPC	IDNS		ENT-SCR-AFTP C	Ranges are not supported for SSN.
ADD-SCRAFTPC	IDNV		ENT-SCR-AFTP C	The screen reference must begin with an alpha character.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRAFTPC	IDNS	E2495	ENT-SCR-AFTP C	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
ADD-SCRAFTPC	GCLI	E2511	ENT-SCR-AFTP C	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRAFTPC	GCMi	E2512	ENT-SCR-AFTP C	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRAFTPC	GNSR	E2554	ENT-SCR-AFTP C	NSR may not be specified.
ADD-SCRAFTPC	IDNS	E2556	ENT-SCR-AFTP C	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.
ADD-SCRAFTPC	GAEX	E2561	ENT-SCR-AFTP C	The new affected point code and subsystem number to be added or changed cannot already exist in the AFTP entity set.
ADD-SCRAFTPC	IDRE	E2564	ENT-SCR-AFTP C	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
ADD-SCRAFTPC	INCE	E2565	ENT-SCR-AFTP C	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRAFTPC	GNFI	E3271	ENT-SCR-AFTP C	The NSFI must be STOP.
ADD-SCRAFTPC	IPNS	N/A	ENT-SCR-AFTP C	The supplier specific parameter is not supported.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRBLKDPC	IDNV		ENT-SCR-BLKD PC	The screen reference must begin with an alpha character.
ADD-SCRBLKDPC	IDNS	E2136	ENT-SCR-BLKD PC	At least one optional parameter must be specified.
ADD-SCRBLKDPC	IDNS	E2495	ENT-SCR-BLKD PC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
ADD-SCRBLKDPC	GAEX	E2497	ENT-SCR-BLKD PC	If blocked screen reference exists, then NI, ZONE, MSA or NPC must not equal C. Point code C-C-C already exists for this blocked SR.
ADD-SCRBLKDPC	GCLI	E2511	ENT-SCR-BLKD PC	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRBLKDPC	GCMJ	E2512	ENT-SCR-BLKD PC	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRBLKDPC	GAEX	E2525	ENT-SCR-BLKD PC	When creating a new blocked screen reference NI, ZONE, MSA or NPC must be equal to C. Point code C-C-C must be the first point code entered for a new blocked screen reference.
ADD-SCRBLKDPC	GNFI	E2547	ENT-SCR-BLKD PC	If the SR does not currently exist, (1) NI, ZONE, MSA, or NPC must equal C, (2) NSFI must not be FAIL and (3) a new BLKDPC screening table is created.
ADD-SCRBLKDPC	GNFI	E2549	ENT-SCR-BLKD PC	NSFI must be FAIL when entering any point code that is not a continue entry.
ADD-SCRBLKDPC	GNRF	E2552	ENT-SCR-BLKD PC	The screen referenced by NSFI and NSR must already exist.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRBLKDPC	GNSR	E2553	ENT-SCR-BLKD PC	If NSFI is not equal to STOP or FAIL, NSR must be specified.
ADD-SCRBLKDPC	IDNS	E2556	ENT-SCR-BLKD PC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
ADD-SCRBLKDPC	GAEX	E2558	ENT-SCR-BLKD PC	If SR exists, the blocked DPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be added to the BLKDPC screening table for the blocked DPC screening reference must not already exist as defined or within an existing range of DPCs.
ADD-SCRBLKDPC	IDNS	E2564	ENT-SCR-BLKD PC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
ADD-SCRBLKDPC	INCE	E2565	ENT-SCR-BLKD PC	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRBLKDPC	GNFI	E3271	ENT-SCR-BLKD PC	The NSFI must be valid for BLKDPC screens.
ADD-SCRBLKDPC	IPNS	N/A	ENT-SCR-BLKD PC	The Supplier Specific Parameter is not supported.
ADD-SCRBLKOPC	IDNV		ENT-SCR-BLKO PC	The screen reference must begin with an alpha character.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRBLKOPC	IDNS	E2136	ENT-SCR-BLKO PC	At least one optional parameter must be specified.
ADD-SCRBLKOPC	IDNS	E2495	ENT-SCR-BLKO PC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
ADD-SCRBLKOPC	GAEX	E2497	ENT-SCR-BLKO PC	If a blocked screen reference exists, then NI, ZONE, MSA or NPC must not equal C. Point code C-C-C already exists for this blocked SR.
ADD-SCRBLKOPC	GCLI	E2511	ENT-SCR-BLKO PC	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRBLKOPC	GCMJ	E2512	ENT-SCR-BLKO PC	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRBLKOPC	GAEX	E2525	ENT-SCR-BLKO PC	When creating a new blocked screen reference NI, ZONE, MSA or NPC must be equal to C. Point code C-C-C must be the first point code entered for a new blocked screen reference.
ADD-SCRBLKOPC	GNFI	E2547	ENT-SCR-BLKO PC	If the SR does not currently exist, (1) NI, ZONE, MSA, or NPC must equal C, (2) NSFI must not be FAIL and (3) a new BLKOPC screening table is created.
ADD-SCRBLKOPC	GNFI	E2549	ENT-SCR-BLKO PC	NSFI must be FAIL when entering any point code that is not a continue entry (C-C-C).
ADD-SCRBLKOPC	GNSR	E2552	ENT-SCR-BLKO PC	The screen referenced by NSFI and NSR must already exist.
ADD-SCRBLKOPC	GNSR	E2553	ENT-SCR-BLKO PC	If NSFI is not equal to STOP or FAIL, NSR must be specified.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRBLKOPC	IDNS	E2556	ENT-SCR-BLKO PC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
ADD-SCRBLKOPC	GAEX	E2558	ENT-SCR-BLKO PC	If asterisk or ranges are specified for the blocked OPC, nothing that matches the specified range of OPCs may already exist in the BLKOPC screening table for the screening reference.
ADD-SCRBLKOPC	GAEX	E2558	ENT-SCR-BLKO PC	If the SR exists, the blocked OPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be added to the BLKOPC screening table for the blocked OPC screening reference must not already exist as defined or within an existing range of OPCs.
ADD-SCRBLKOPC	IDNS	E2564	ENT-SCR-BLKO PC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0, are not allowed.
ADD-SCRBLKOPC	INCE	E2565	ENT-SCR-BLKO PC	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRBLKOPC	GNFI	E3271	ENT-SCR-BLKO PC	The NSFI specified must be valid for the BLKOPC entity type.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRBLKOPC	IPNS	N/A	ENT-SCR-BLKO PC	The Supplier Specific Parameter is not supported.
ADD-SCRCDDPA	IDNS		ENT-SCR-CDPA	Ranges are not supported for SSN.
ADD-SCRCDDPA	IDNV		ENT-SCR-CDPA	The screen reference must begin with an alpha character.
ADD-SCRCDDPA	IDNS	E2136	ENT-SCR-CDPA	At least one optional parameter must be specified.
ADD-SCRCDDPA	IDNS	E2484	ENT-SCR-CDPA	If NSFI=AFTPC then SSN must equal 1.
ADD-SCRCDDPA	GFII	E2508	ENT-SCR-CDPA	If SSN is not equal to 1, the SCMG format identifier must be NULL.
ADD-SCRCDDPA	GFII	E2508	ENT-SCR-CDPA	The SCMGID parameter must be specified for SSN=1.
ADD-SCRCDDPA	GCLI	E2511	ENT-SCR-CDPA	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRCDDPA	GCMII	E2512	ENT-SCR-CDPA	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRCDDPA	GAEX	E2516	ENT-SCR-CDPA	The new CDPA entry to be added cannot match any specific, range, or asterisk- entry already existing in the specified screening table.
ADD-SCRCDDPA	GNRF	E2552	ENT-SCR-CDPA	The screen referenced by NSFI and NSR must already exist.
ADD-SCRCDDPA	GNSR	E2553	ENT-SCR-CDPA	NSR must be specified if NSFI is not STOP.
ADD-SCRCDDPA	GNSR	E2554	ENT-SCR-CDPA	NSR must be NULL if the NSFI specified is STOP.
ADD-SCRCDDPA	GNII	E2564	ENT-SCR-CDPA	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRCDDPA	INCE	E2565	ENT-SCR-CDPA	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRCDDPA	GNFI	E3271	ENT-SCR-CDPA	The NSFI must be valid for CDPA screens.
ADD-SCRCDDPA	IPNS	N/A	ENT-SCR-CDPA	The supplier specific parameter is not supported.
ADD-SCRCGPA	IDNS		ENT-SCR-CGPA	Ranges are not supported for SSN.
ADD-SCRCGPA	IDNV		ENT-SCR-CGPA	The screen reference must begin with an alpha character.
ADD-SCRCGPA	GNFI	E2492	ENT-SCR-CGPA	NSFI may only be specified as TT if RI is GT or *.
ADD-SCRCGPA	GNFI	E2492	ENT-SCR-CGPA	NSFI may only be specified as CDPA if RI is DPC or *.
ADD-SCRCGPA	IDNS	E2495	ENT-SCR-CGPA	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
ADD-SCRCGPA	GCLI	E2511	ENT-SCR-CGPA	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRCGPA	GCM I	E2512	ENT-SCR-CGPA	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRCGPA	GAEX	E2514	ENT-SCR-CGPA	The new CGPA PC, RI, SCCPMT and subsystem number to be added can not already exist in the CGPA entity set.
ADD-SCRCGPA	GNRF	E2552	ENT-SCR-CGPA	The screen referenced by NSFI and NSR must already exist.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRCGPA	GNSR	E2553	ENT-SCR-CGPA	NSR must be specified if NSFI is not STOP.
ADD-SCRCGPA	GNSR	E2554	ENT-SCR-CGPA	NSR must be NULL if the NSFI specified is STOP.
ADD-SCRCGPA	IDNS	E2556	ENT-SCR-CGPA	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.
ADD-SCRCGPA	IDRE	E2564	ENT-SCR-CGPA	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
ADD-SCRCGPA	INCE	E2565	ENT-SCR-CGPA	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRCGPA	GNFI	E3271	ENT-SCR-CGPA	The NSFI must be valid for CGPA screens.
ADD-SCRCGPA	IPNS	N/A	ENT-SCR-CGPA	The linkset group identifier parameter is not supported.
ADD-SCRCGPA	IPNS	N/A	ENT-SCR-CGPA	The supplier specific parameter is not supported.
ADD-SCRDESTFLD	IDNV		ENT-SCR-DESTFLD	The screen reference must begin with an alpha character.
ADD-SCRDESTFLD	IDNS	E2495	ENT-SCR-DESTFLD	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRDESTFLD	GCLII	E2511	ENT-SCR-DESTFLD	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRDESTFLD	GCFMI	E2512	ENT-SCR-DESTFLD	Point codes specified by NI-NC-NCM must be valid.
ADD-SCRDESTFLD	IDNV	E2527	ENT-SCR-DESTFLD	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
ADD-SCRDESTFLD	GNSR	E2554	ENT-SCR-DESTFLD	NSR can not be specified.
ADD-SCRDESTFLD	GAEX	E2558	ENT-SCR-DESTFLD	The destination point code, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must not already exist as specified or within an existing range of DPCs.
ADD-SCRDESTFLD	GNII	E2564	ENT-SCR-DESTFLD	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
ADD-SCRDESTFLD	INCE	E2565	ENT-SCR-DESTFLD	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRDESTFLD	GNFI	E3271	ENT-SCR-DESTFLD	NSFI must be specified as STOP.
ADD-SCRDESTFLD	IPNS	N/A	ENT-SCR-DESTFLD	The Supplier Specific Parameter is not supported.
ADD-SCRDPC	IDNV		ENT-SCR-DPC	The screen reference must begin with an alpha character.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRDPC	IDNS	E2495	ENT-SCR-DPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
ADD-SCRDPC	GCLI	E2511	ENT-SCR-DPC	Pointcodes specified by NI-NC-NCM must be valid.
ADD-SCRDPC	GCM I	E2512	ENT-SCR-DPC	Pointcodes specified by NI-NC-NCM must be valid.
ADD-SCRDPC	IDNV	E2527	ENT-SCR-DPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
ADD-SCRDPC	G NRF	E2552	ENT-SCR-DPC	The screen referenced by NSFI and NSR must already exist.
ADD-SCRDPC	G NRF	E2552	ENT-SCR-DPC	The screen referenced by NSFI and NSR must already exist.
ADD-SCRDPC	GNSR	E2553	ENT-SCR-DPC	If NSFI is not equal to STOP, NSR must be specified.
ADD-SCRDPC	GAEX	E2558	ENT-SCR-DPC	The DPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must not already exist as specified or within an existing range of DPCs.
ADD-SCRDPC	GNII	E2564	ENT-SCR-DPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
ADD-SCRDPC	INCE	E2565	ENT-SCR-DPC	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRDPC	GNFI	E3271	ENT-SCR-DPC	The NSFI must be valid for DPC screens.
ADD-SCRDPC	IPNS	N/A	ENT-SCR-DPC	The Supplier Specific Parameter is not supported.
ADD-SCROPC	IDNV		ENT-SCR-OPC	The screen reference must begin with an alpha character.
ADD-SCROPC	IDNS	E2495	ENT-SCR-OPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
ADD-SCROPC	GCLI	E2511	ENT-SCR-OPC	Point codes specified by NI-NC-NCM must be valid.
ADD-SCROPC	GCM1	E2512	ENT-SCR-OPC	Point codes specified by NI-NC-NCM must be valid.
ADD-SCROPC	IDNV	E2527	ENT-SCR-OPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
ADD-SCROPC	G NRF	E2552	ENT-SCR-OPC	The screen referenced by NSFI and NSR must already exist.
ADD-SCROPC	GNSR	E2553	ENT-SCR-OPC	If NSFI is not equal to STOP, NSR must be specified.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCROPC	IDNS	E2556	ENT-SCR-OPC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
ADD-SCROPC	GAEX	E2558	ENT-SCR-OPC	The OPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must not already exist as specified or within an existing range of OPCs.
ADD-SCROPC	GNII	E2564	ENT-SCR-OPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
ADD-SCROPC	INCE	E2565	ENT-SCR-OPC	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCROPC	GNFI	E3271	ENT-SCR-OPC	The NSFI must be valid for OPC screens.
ADD-SCROPC	IPNS	N/A	ENT-SCR-OPC	The Supplier Specific Parameter is not supported.
ADD-SCRSIO	IDNV		ENT-SCR-SIO	The screen reference must begin with an alpha character.
ADD-SCRSIO	IDRE		ENT-SCR-SIO	Heading codes must be in the range (*,0..15).
ADD-SCRSIO	IDRE		ENT-SCR-SIO	Message Priority must be in the range (*,0..3) or n1&&n2 where n1 and n2 are in the range 0-3 and n1 < n2.
ADD-SCRSIO	IDRE		ENT-SCR-SIO	The Network Indicator Code must be in the range (*,0..3).

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCRSIO	GHCI	E2393	ENT-SCR-SIO	If H0 is asterisk, H1 must be asterisk or not specified.
ADD-SCRSIO	GHCI	E2488	ENT-SCR-SIO	H0 and H1 must be specified is SI is less than or equal 2.
ADD-SCRSIO	GHCI	E2490	ENT-SCR-SIO	For screening entries containing SI>2, H0 and H1, must not be specified.
ADD-SCRSIO	G NRF	E2552	ENT-SCR-SIO	The screen referenced by NSF I and NSR must already exist.
ADD-SCRSIO	G NSR	E2553	ENT-SCR-SIO	NSR must be specified if NSF I is not STOP.
ADD-SCRSIO	G NSR	E2554	ENT-SCR-SIO	NSR must be NULL if the NSF I specified is STOP.
ADD-SCRSIO	INCE	E2565	ENT-SCR-SIO	The command will be rejected if the Gateway Screening rules table already contains the max number of rules.
ADD-SCRSIO	GHCI	E3269	ENT-SCR-SIO	H1 must not be NULL if H0 is not NULL.
ADD-SCRSIO	GNFI	E3271	ENT-SCR-SIO	NSFI may be CDPA only if SI is 03.
ADD-SCRSIO	GNFI	E3271	ENT-SCR-SIO	NSFI may be CGPA only if SI is 03.
ADD-SCRSIO	GNFI	E3271	ENT-SCR-SIO	NSFI may be DESTFLD only if SI is 00.
ADD-SCRSIO	GNFI	E3271	ENT-SCR-SIO	NSFI may be ISUP only if SI is 05.
ADD-SCRSIO	GNFI	E3271	ENT-SCR-SIO	The NSF I must be valid for SIO screens.
ADD-SCRSIO	GAEX	E3273	ENT-SCR-SIO	The network indicator code, service indicator, priority, and heading codes to be added to the allowed SIO entity set can not already exist. If a range is specified, nothing within the entire combination of the specified range may already exist.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ADD-SCR TT	IDNV		ENT-SCR-TT	The screen reference must begin with an alpha character.
ADD-SCR TT	G NRF	E2552	ENT-SCR-TT	The screen referenced by NSFI and NSR must already exist.
ADD-SCR TT	G NSR	E2553	ENT-SCR-TT	NSR must be specified if the NSFI is not STOP.
ADD-SCR TT	G NSR	E2554	ENT-SCR-TT	NSR can not be specified if the NSFI is STOP.
ADD-SCR TT	INCE	E2565	ENT-SCR-TT	The command will be rejected if the Gateway Screening rules table already contains the maximum number of rules.
ADD-SCR TT	GAEX	E2575	ENT-SCR-TT	If the screening reference exists, the single value or range specified for allowed TYPE to be added to the TT screen for the allowed TT screening reference must not already exist in that TT screen.
ADD-SCR TT	GNFI	E3271	ENT-SCR-TT	The NSFI must be valid for TT screens.
ADD-SCR TT	IPNS	N/A	ENT-SCR-TT	The supplier specific parameter is not supported.
ANSI PC	GCLI	E2511	ANSI PC	If a range is specified for NC, a single NI must be specified, and NCM must be asterisk or the full range (000-255).
ANSI PC	GCLI	E2511	ANSI PC	If a single value is specified for NC, a single NI must also be specified.
ANSI PC	GCLI	E2511	ANSI PC	If a single value or range other than (000-255) is specified for NCM, then NI must be specified as a single value.
ANSI PC	GCLI	E2511	ANSI PC	If NI is specified as asterisk or a range, NC and NCM must be asterisk or the full range (000-255).
ANSI PC	G CMI	E2512	ANSI PC	If a range is specified for NC, NCM must be asterisk or the full range (000-255).

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ANSI PC	GCFI	E2512	ANSI PC	If a single value or range other than (000-255) is specified for NCM, then NC must be specified as a single value.
ANSI PC	GCFI	E2512	ANSI PC	If NC is specified as asterisk, NCM must be asterisk or the full range (000-255).
ASGN-MAP	IDNS	E2425	ENT-MAP	Mate PC/SSN cannot be same as PC/SSN.
ASGN-MAP	SDNE	E2427	ENT-MAP	Mate remote point code must already exist as destination in the ORDERED ROUTE entity set or reside in a cluster destination for which ordered routes are specified.
ASGN-MAP	INCE	E2430	ENT-MAP	Subsystem table for MPC is full.
ASGN-MAP	SAAS	E2431	ENT-MAP	Mate remote DPC-SSN entity must not already exist in the MATED APPLICATIONS entity set.
ASGN-MAP	SAAS	E2440	ENT-MAP	Primary remote DPC-SSN entity must not already exist in the MATED APPLICATIONS entity set.
ASGN-MAP	SDNE	E2451	ENT-MAP	Primary remote point code must already exist as destination in the ORDERED ROUTE entity set or reside in a cluster destination for which ordered routes are specified.
ASGN-MAP	INCE	E2454	ENT-MAP	Remote point code table is full.
ASGN-MAP	IEC=29 1	E2648	ENT-MAP	Failed reading route table.
ASGN-MAP	IEC=29 1	E2874	ENT-MAP	Failed reading site identification table.
ASGN-MAP	CCUN	E3009	ENT-MAP	LNP feature must be on when administering a true point code.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-MAP	IEC=291	E3124	ENT-MAP	Failed reading SS APPL table.
ASGN-MAP	SAAS	E3290	ENT-MAP	True point code cannot already exist in the MATED APPLICATIONS entity set.
ASGN-MAP	SANE	N/A	ENT-MAP	Both DPC-SSN applications must be provisioned in the SCCP APPLICATION entity set.
ASGN-RTE	SEHW	E2122	ENT-RTE	Linkset table not accessible.
ASGN-RTE	SNLM	E2128	ENT-RTE	The STP shall ensure that the target link set specified in the command has at least one member assigned (unless FORCE = YES for EAGLE only).
ASGN-RTE	DASI	E2167	ENT-RTE	The STP shall ensure that the specified destination address does not correspond to any of the STP's capability codes as specified in its self-identity.
ASGN-RTE	DASI	E2168	ENT-RTE	The STP shall ensure that the specified destination address does not correspond to the STP's own DPC as specified in its self-identity.
ASGN-RTE	IDNS	E2327	ENT-RTE	Adjacent point code type must match destination point code type.
ASGN-RTE	SLSM	E2346	ENT-RTE	The STP shall ensure that the target link set specified in the command exists in the active data base.
ASGN-RTE	LSTI	E2349	ENT-RTE	The STP must ensure that, if a specified destination address is a network cluster address (NI-NC), the linkset Type of the linkset used in the ordered route is not inconsistent with cluster routing, i.e., that the linkset specified is not an A-Linkset or an E-Linkset, but instead has linkset Type B, C, or D.
ASGN-RTE	INCE	E2350	ENT-RTE	At most two linksets can be assigned the same cost within a routeset.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-RTE	INCE	E2353	ENT-RTE	At most six routes can be defined per routeset.
ASGN-RTE	SAAS	E2355	ENT-RTE	The STP must ensure that the ORDERED ROUTE entity set of the active database does not already contain a destination and linkset combination equal to that specified.
ASGN-RTE	IDNS	E2357	ENT-RTE	All linksets currently assigned to a routeset must still be equipped.
ASGN-RTE	IDNS	E2594	ENT-RTE	If the route is to be assigned a destination that is marked for the X.25 domain, then the route must be assigned to a linkset with an adjacent point code in the X.25 domain, unless that linkset is of type C.
ASGN-RTE	IDNS	E2595	ENT-RTE	If the route to be is assigned a destination that is marked for the SS7 domain, then the route must be assigned to a link set with an adjacent point code in the SS7 domain, unless that link set is of type C.
ASGN-RTE	SEHW	E2648	ENT-RTE	Route table not accessible.
ASGN-RTE	SDAM	E2657	ENT-RTE	The STP shall ensure that the destination address specified is defined in the STP's active DESTINATION entity set.
ASGN-RTE	IDNS	E2867	ENT-RTE	Routes of equal cost (combined linksets) cannot exist for X.25 destinations.
ASGN-RTE	SEHW	E2874	ENT-RTE	STP site ID table not accessible.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-RTE	IDNS	E2878	ENT-RTE	Ordered routes cannot be assigned to a destination that is a member of a provisioned cluster (NI-NC-*); destinations comprising a cluster inherit their ordered routes from its cluster if NCAI is specified as NO. If NCAI is specified as YES then destination is a member of a provisioned nested cluster where ordered routes can be assigned to a provisioned member.
ASGN-RTE	IDNV	E2886	ENT-RTE	Destination address (DPC/da) must be a full or a cluster point code.
ASGN-RTE	IDNV	E2955	ENT-RTE	Network Routing is only valid if the NRT feature is ON.
ASGN-RTE	IDNS	E3830	ENT-RTE	If LSN references a link set with IPGWAPC=YES, DPC must not specify a cluster route.
ASGN-RTE	IDNS	E3877	ENT-RTE	ANSI/ITU point code type mismatch.
ASGN-RTE	IDNS	N/A	ENT-RTE	A range of destination addresses (da) cannot be specified.
ASGN-RTE	IPNS	N/A	ENT-RTE	Supplier-specific parameters (z) cannot be specified.
ASGN-SID	SEHW	E2145	CHG-SID	MAS configuration table not accessible.
ASGN-SID	IDRE	E2169	CHG-SID	If the system is configured for ANSI formatted point code, the network indicator value of the PC, CPC, and/or NCPC parameter(s) must be 6 or greater when the cluster value is 0.
ASGN-SID	SAAS	E2183	CHG-SID	STP capability point code must not have been previously defined as an STP capability point code.
ASGN-SID	IDNS	E2184	CHG-SID	CLLI must not be assigned to a route.
ASGN-SID	CPCE	E2185	CHG-SID	STP capability point code must not have been previously defined as the STP destination point code.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SID	IDNS	E2186	CHG-SID	STP capability point code must not have been previously defined as a route destination point code.
ASGN-SID	IDNS	E2189	CHG-SID	STP destination point code must not have been previously defined as an STP capability point code.
ASGN-SID	IDNS	E2189	CHG-SID	STP destination point code must not have been previously defined as a route destination point code.
ASGN-SID	IDRE	E2340	CHG-SID	STP capability point code must be a valid point code (i.e. 0-0-0).
ASGN-SID	SESW	E2362	CHG-SID	Could not add/change the (new) capability point code to the list due to software error. This case will generate an ATH with more information.
ASGN-SID	SEHW	E2639	CHG-SID	Redirect table not accessible.
ASGN-SID	SEHW	E2648	CHG-SID	Route table not accessible.
ASGN-SID	IDNV	E2861	CHG-SID	STP destination and capability point codes can only be provisioned as full point codes, or "none".
ASGN-SID	SNEX	E2872	CHG-SID	If NCPCx is specified, CPCx must have been previously defined.
ASGN-SID	SEHW	E2874	CHG-SID	STP site ID table not accessible.
ASGN-SID	INCE	E2883	CHG-SID	The maximum number of CPCs that can be provisioned is 96.
ASGN-SID	IDNC	E2884	CHG-SID	If specified, PCx, NPCx, CPCx or NCPCx must not be equal. - No value for parameters PCI, NPCI, CPCI, or NCPCI may be the same point code. - No value for parameters PCN, NPCN, CPCN, or NCPCN may be the same point code.
ASGN-SID	SEHW	E3807	CHG-SID	SPC table not accessible.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SID	IDNS	N/A	CHG-SID	A range of Capability Codes cannot be specified.
ASGN-SID	INPE	N/A	CHG-SID	“none” cannot be used with CLLI.
ASGN-SLK	IDNS	E3768	ENT-SLK	LINK B not supported for device (IPLIM, SS7IPGW, IPLIMI, IPGWI). Starting with IP7 SG Release 2.1, this error code will not be used for ent-slk commands related to IPLIM and IPLIMI cards. As of release 2.1, those 2 applications are capable of supporting both a and b links.
ASGN-SLK	IDNS	E2101	ENT-SLK	The command is rejected if the E1LOC parameter is specified and the card location specified by E1LOC is not equipped.
ASGN-SLK	IDNS	E2101	ENT-SLK	The command is rejected if the T1LOC parameter is specified and the card location specified by T1LOC is not equipped.
ASGN-SLK	ENEQ	E2101	ENT-SLK	The port (card location) must be equipped.
ASGN-SLK	SEHW	E2102	ENT-SLK	Card (IMT) table not accessible.
ASGN-SLK	SEHW	E2103	ENT-SLK	Link table not accessible.
ASGN-SLK	IDNS	E2104	ENT-SLK	If the E1LOC/E1PORT parameters are specified, the ATMTSEL parameter is not recognized as valid.
ASGN-SLK	IDNS	E2118	ENT-SLK	All links in a link set must specify the same BPS, or must specify a BPS of 56000 or 64000.
ASGN-SLK	IDNS	E2119	ENT-SLK	BPS must be 56000 or 64000 if card application is SS7ANSI or CCS7ITU.
ASGN-SLK	IDNS	E2120	ENT-SLK	BPS must be 56000 if card type is LIMDS0 or LIMOCU.
ASGN-SLK	IDNS	E2121	ENT-SLK	PCRN1 and PCRN2 parameter may be specified only if the ECM parameter is specified and its value is PCR.
ASGN-SLK	SEHW	E2122	ENT-SLK	Linkset table not accessible.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SLK	IDNS	E2126	ENT-SLK	Linkset APC type (ITU/ANSI) must match application type of card.
ASGN-SLK	IDNS	E2131	ENT-SLK	If application is ATMITU, then ATMANSI specific parameters, LSL and IP Link parameters shouldn't be specified.
ASGN-SLK	IDNS	E2131	ENT-SLK	The parameters are not valid for the card type.
ASGN-SLK	SAAS	E2132	ENT-SLK	The member number (Signaling Link Code) must not already exist for that linkset in the STP active database.
ASGN-SLK	EAAS	E2133	ENT-SLK	The port (link) must not already be assigned to a link (equipped).
ASGN-SLK	IDNS	E2135	ENT-SLK	The TSET parameter is only valid when L1MODE = DCE. When L1MODE = DCE is entered and TSET is not entered then TSET will be set to OFF.
ASGN-SLK	IDNV	E2146	ENT-SLK	The link speed (BPS/lkspd) parameter must be 4800, 9600, 19200, 56000, 64000, 1544000, 1984000, or 2048000. For SEAS the allowed values of the link speed are 9.6, 19.2, 56, 64, 1536 and 1984. Values outside the list given are rejected with IDNV.
ASGN-SLK	IDRE	E2152	ENT-SLK	Shelf location must be 11xx, 12xx, 13xx, 21xx, 22xx, 23xx, 31xx, 32xx, 33xx, 41xx, 42xx, 43xx, 51xx, 52xx, 53xx, or 61xx.
ASGN-SLK	IDRE	E2153	ENT-SLK	Card location must be between 1..18 and not 9 or 10.
ASGN-SLK	IDRE	E2154	ENT-SLK	Card location must not be 1113..1118.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SLK	IDNS	E2212	ENT-SLK	The command is rejected if the E1LOC parameter is specified and the type of card specified by E1LOC is not LIME1.
ASGN-SLK	IDNS	E2212	ENT-SLK	The command is rejected if the T1LOC parameter is specified and the type of card specified by T1LOC is not LIMT1.
ASGN-SLK	ENEQ	E2292	ENT-SLK	Card is not a LIM or does not exist. The card must be a LIM.
ASGN-SLK	SNEX	E2346	ENT-SLK	The specified linkset name must already exist in the STP active database.
ASGN-SLK	IDNS	E2379	ENT-SLK	The command is rejected if the type of card specified by LOC is LIME1, LIMT1, or LIMCH and the TS parameter is not specified or if the card type is LIMCH and one of either the E1LOC or T1LOC parameter is not specified.
ASGN-SLK	IDNS	E2586	ENT-SLK	If card application is SS7GX25, PORT must be A.
ASGN-SLK	IDNS	E2589	ENT-SLK	If card application is SS7GX25, L2TSET cannot be specified.
ASGN-SLK	SEHW	E2599	ENT-SLK	Extended link table not accessible.
ASGN-SLK	IDNS	E2734	ENT-SLK	The cards specified by T1LOC and LOC must be on the same shelf if T1LOC is specified.
ASGN-SLK	IDNS	E2743	ENT-SLK	The command is rejected if the type of card specified by LOC is LIMCH and T1PORT is not provisioned as port 1.
ASGN-SLK	IDNS	E2744	ENT-SLK	The command is rejected if the T1PORT at the card location specified by T1LOC is not equipped.
ASGN-SLK	IDNS	E2746	ENT-SLK	The command is rejected if the TS value on the T1 specified by T1LOC/T1PORT is already being used by a signaling link.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SLK	IDNS	E2748	ENT-SLK	The command will be rejected if TS is not specified in the range of 1-24.
ASGN-SLK	IDNS	E2972	ENT-SLK	Links A1, B1, A2, B2, A3 and B3 can ONLY be specified when: - card type is LIMDS0 and APPL type is SS7ANSI - card type is LIME1, or LIMT1, or LIMCH and the APPL type is SS7ANSI or CCS7ITU, - card type is SSEDCEM and APPL type is IPLIM/IPLIMI. NOTE: This error will always be reported with E2976 for IPLIM/IPLIMI - Links a4-a31 and b4-b31 can be specified only when the card type is LIME1 or LIMT1 for an HC-MIM card and the APPL type is SS7ANSI or CCS7ITU.
ASGN-SLK	IDNS	E2973	ENT-SLK	Multi Port LIM supports 56000 BPS links ONLY.
ASGN-SLK	IDNS	E2976	ENT-SLK	If specified link is A1, B1, A2, B2, A3 or B3, card running must be: - a Multi Port LIM, an E1/T1 MIM, or HC-MIM - a SSEDCEM, with APPL type IPLIM/IPLIMI and IPLIML2 is SAAL/TALI or M2PA.
ASGN-SLK	IDNS	E3097	ENT-SLK	The active OAM must be running on a GPMS-II card in order to support more than 700 links.
ASGN-SLK	IDNS	E3280	ENT-SLK	SLK IPLIML2 requires LS MTPRSE setting to be NO.
ASGN-SLK	IDNS	E3281	ENT-SLK	IPLIML2 is only valid for IPLIM SLK.
ASGN-SLK	IDNS	E3282	ENT-SLK	All Links in LS must have same IPLIML2 setting.
ASGN-SLK	IDNS	E3298	ENT-SLK	LIME1ATM Card supports 2048000 BPS Links ONLY.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SLK	IDNS	E3404	ENT-SLK	VCI values 0..4 and 6..31 are reserved and cannot be specified.
ASGN-SLK	SESW	E3404	ENT-SLK	VCI values 0..4 and 6..31 are reserved and cannot be specified.
ASGN-SLK	IDNS	E3405	ENT-SLK	If card application is ATMANSI or ATMITU, LINK must be A.
ASGN-SLK	IDNS	E3406	ENT-SLK	If card application is ATMANSI, BPS must be 1544000.
ASGN-SLK	IDNS	E3407	ENT-SLK	If card application is ATMANSI, then ECM, L1MODE, L2TSET, PCRN1, PCRN2, and TSET parameters cannot be specified.
ASGN-SLK	IDNS	E3408	ENT-SLK	If card application is neither ATMANSI nor ATMITU, then LPSET, VCI, VPI, LL, E1ATMSI, E1ATMSN, E1ATMCRC4 and ATMTSEL parameters cannot be specified.
ASGN-SLK	IDNS	E3409	ENT-SLK	Addition of a LSL or ATM HSL cannot exceed the total number of ATM HSL and LSL links allowed by the system.
ASGN-SLK	IDNS	E3418	ENT-SLK	If card application is not ATMANSI, BPS cannot be 1544000.
ASGN-SLK	IDNS	E3418	ENT-SLK	If card application is not ATMITU, BPS cannot be 2048000.
ASGN-SLK	DNS	E3455	ENT-SLK	When any SCTP associations are provisioned for LHOSTs on IPLIMx running on a DCM, a maximum of two links are supported.
ASGN-SLK	IDNS	E3482	ENT-SLK	Link capacity exceeds limit allow by feature access key.
ASGN-SLK	IDNS	E3484	ENT-SLK	HC-MIM does not support interface to a channel card (E1LOC/T1LOC cannot be HCMIM card).
ASGN-SLK	IDNS	E3490	ENT-SLK	HIPR must be equipped in the same shelf where the HC-MIM card resides when link a4 to a31 or b4 to b31 is provisioned.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SLK	IDNS	E3491	ENT-SLK	The specified port is channel bridged with the parent port.
ASGN-SLK	IDNS	E3494	ENT-SLK	If specified link is A4, B4, ..., A31, B31, card running must be HC-MIM - Link a4, b4, ..., a31, b31 is invalid parameter for channel card. Card running must be an HC-MIM if specified link is a4-a31 or b4-b31.
ASGN-SLK	IDNS	E3494	ENT-SLK	link a4, b4, ..., a31, b31 cannot be specified for even-numbered card location.
ASGN-SLK	IDNS	E3770	ENT-SLK	If card application is IPLIM, IPLIMI, IPGWI or SS7IPGW, the following parameters cannot be specified: LPSET, VCI, VPI, LL, ATMTSEL, E1ATMCRC4, E1ATMSI, E1ATMSN, ECM, L1MODE, L2TSET, PCRN1, PCRN2, and TSET.
ASGN-SLK	IDNS	E3772	ENT-SLK	Only one SS7IPGW or IPGWI link allowed in mated linkset.
ASGN-SLK	IDNS	E3828	ENT-SLK	If card application is SS7IPGW, LSN must specify IPGWAPC=YES.
ASGN-SLK	IDNS	E3829	ENT-SLK	If LSN references a link set which specifies IPGWAPC=YES, card application must be SS7IPGW or IPGWI.
ASGN-SLK	IDNS	E3866	ENT-SLK	Fan feature bit must be turned on if link a4 to a31 or b4 to b31 is specified.
ASGN-SLK	IDNS	E3872	ENT-SLK	If card application is IPGWI, linkset must be empty (only 1 IPGWI link allowed per linkset).
ASGN-SLK	IDNS	E3873	ENT-SLK	If card application is IPGWI, LSN must specify IPGWAPC=YES.
ASGN-SLK	IDNS	E4003	ENT-SLK	MULTGC=YES requires links of same type IPGWI/IPLIMI.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
ASGN-SLK	IDNS	E4045	ENT-SLK	If LSN references a link set which specifies MULTGC=YES, card application must be IPGWI or IPLIMI.
ASGN-SLK	IDNS	E4049	ENT-SLK	The command is rejected if the type of card specified by LOC is LIMCH and E1PORT is not provisioned as port 1.
ASGN-SLK	IDNS	E4050	ENT-SLK	The command is rejected if the E1PORT at the card location specified by E1LOC is not equipped.
ASGN-SLK	IDNS	E4051	ENT-SLK	The command is rejected if the TS value on the E1 specified by E1LOC/E1PORT is already being used by a signaling link.
ASGN-SLK	IDNS	E4052	ENT-SLK	The command is rejected if the E1 specified by E1LOC/E1PORT is using CAS and TS=16.
ASGN-SLK	IDNS	E4058	ENT-SLK	The cards specified by E1LOC and LOC must be on the same shelf if E1LOC is specified.
ASGN-SLK	SEHW	E4059	ENT-SLK	E1/T1 table not accessible.
ASGN-SLK	IDNS	E4266	ENT-SLK	Channel bridged slave port is invalid for link provisioning.
ASGN-SLK	IDNS	E4281	ENT-SLK	Specified link not supported for SE-HSL
ASGN-SLK	IDNS	N/A	ENT-SLK	Encryption option (encr) can be specified only as N or null.
ASGN-SLK	IDNS	N/A	ENT-SLK	The value 1536 cannot be specified for the link speed (lkspd) parameter.
ASGN-SLK	IPNS	N/A	ENT-SLK	Equipment options (eqopts) cannot be specified.
ASGN-SLK	IPNS	N/A	ENT-SLK	Supplier-specific signaling link parameter(s) (z) cannot be specified.
CHG-DSTN	CNNA	E2136	CHG-DSTN	One or more optional parameters must be specified.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-DSTN	DISI	E2163	CHG-DSTN	The STP shall validate the command instructions and ensure that, if a new destination identifier is specified, it is not equal to the STP's own self-identity CLLI.
CHG-DSTN	DIAS	E2184	CHG-DSTN	The STP shall determine whether the destination is an adjacent signaling point, as evidenced by a match against a far-end point code (FE PC) in its LINK SET entity-set. If so, the STP shall ensure that the new destination identifier is assigned to no other destination address.
CHG-DSTN	SEHW	E2648	CHG-DSTN	Route table not accessible.
CHG-DSTN	SNEX	E2657	CHG-DSTN	The STP shall validate the command instructions and ensure that the target destination already exists in the DESTINATION entity set.
CHG-DSTN	INCE	E2836	CHG-DSTN	If changing a provisioned non-nested cluster point code to a nested cluster point code (NCAI parameter set to YES), the maximum number of provisioned nested clusters must be no greater than 500.
CHG-DSTN	IDNS	E2838	CHG-DSTN	If changing a provisioned nested cluster point code to a non-nested cluster point code (NCAI parameter set to NO), previously provisioned members of the cluster must have the same route set.
CHG-DSTN	IDNC	E2853	CHG-DSTN	The STP shall ensure that no argument for elei is entered if the destination address is not a cluster destination.
CHG-DSTN	IDNS	E2855	CHG-DSTN	Cluster destinations are not permitted if the CRMD feature is OFF .

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-DSTN	IDNS	E2868	CHG-DSTN	The STP shall ensure that no argument for NCAI is entered if the destination address is not a cluster destination.
CHG-DSTN	SEHW	E2874	CHG-DSTN	STP self-identity table not accessible.
CHG-DSTN	IDRE	E2886	CHG-DSTN	Destination address must be a full or a cluster point code.
CHG-DSTN	IDNV	E2955	CHG-DSTN	Network Routing is only valid if the NRT feature is ON.
CHG-DSTN	DIFC	N/A	CHG-DSTN	The STP shall determine whether the destination is an adjacent signaling point, as evidenced by a match against a far-end point code (FE PC) in its LINK SET entity-set. If so, the STP shall ensure that the new destination identifier is identical to that link set's FE CLLI.
CHG-DSTN	IDNC	N/A	CHG-DSTN	The STP shall ensure that no argument for bei is entered if the destination address is not a cluster destination.
CHG-DSTN	IPNS	N/A	CHG-DSTN	New supplier-specific signaling link parameter(s) (nz) cannot be specified.
CHG-GTT	CNNA	E2112	CHG-GTA	At least one optional parameter is required to be changed.
CHG-GTT	CNNA	E2136	CHG-GTT	At least one optional parameter is required.
CHG-GTT	CNNA	E2136	CHG-GTT	At least one optional parameter is required.
CHG-GTT	IDRE	E2169	CHG-GTA	PC/PCA/PCI/PCN/PCN24 must not be out of range.
CHG-GTT	IDRE	E2169	CHG-GTT	The specified Point code must not be out of range.
CHG-GTT	SNEX	E2401	CHG-GTA	The GTA range cannot overlap a currently existing range for the specified GTT Set in the STP active data base.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-GTT	SNEX	E2402	CHG-GTA	The specified GTA range must exist for the specified GTT Set in the STP active data base (note that an exact match is not required).
CHG-GTT	SNEX	E2402	CHG-GTT	The specified GTA range must exist.
CHG-GTT	IDNS	E2403	CHG-GTA	If EGTA is specified, GTA and EGTA must be the same length.
CHG-GTT	IDNS	E2403	CHG-GTT	If a Global Title Address range is specified, the length of the starting and ending address must be the same.
CHG-GTT	IDNS	E2404	CHG-GTT	The length of the specified GTA must match the number of digits provisioned for the specified Translation Type or the Translation Type referenced by the specified Translation Type Name, unless the PVGTT or VGTT feature is on. In the case the PVGTT feature is on the length of the specified GTA and EGTA can be less than or equal to the number of digits provisioned for the corresponding TT. In the case the VGTT feature is on, up to 10 different lengths can be provisioned per TT.
CHG-GTT	INCE	E2416	CHG-GTT	Unable to access database. Severe database failure.
CHG-GTT	SEHW	E2416	CHG-GTA	Failed accessing database.
CHG-GTT	SDNE	E2417	CHG-GTA	If specified, PC/PCA/PCI/PCN/PCN24 must exist as a Destination in the Route table or reside in a cluster that exists as a Destination in the Route table (for global title routing), unless the point code is the STP's True PC.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-GTT	SDNE	E2417	CHG-GTT	The specified Point Code must exist in routing table. NOTE: The following clause applies only to the DBS software base. The PC specified does not have to exist in the ORDERED ROUTE entity set if the PC is the EAGLE's True PC.
CHG-GTT	SNEX	E2419	CHG-GTA	If the new or existing RI=SSN and the new or existing XLAT=DPC, and PC/PCA/PCI/PCN is not specified, the existing PC must exist in the Remote Point Code/Mated Application table, unless FORCE is specified as YES.
CHG-GTT	SNEX	E2419	CHG-GTT	If the new or existing RI=SSN and the new or existing XLAT=DPC, and PC/PCA/PCI/PCN is not specified, a PC must exist in the Remote Point Code/Mated Application table.
CHG-GTT	IDNC	E2420	CHG-GTA	If EGTA is specified, EGTA must be greater than GTA.
CHG-GTT	IDNC	E2420	CHG-GTT	If a Global Title Address range is specified, the starting address must be greater than or equal to the ending address.
CHG-GTT	SNEX	E2435	CHG-GTA	If the new or existing RI=SSN and the new or existing XLAT=DPC, and PC/PCA/PCI/PCN/PCN24 is specified, the new PC must exist in the Remote Point Code/Mated Application table, unless FORCE is specified as YES.
CHG-GTT	SNEX	E2435	CHG-GTT	If the new or existing RI=SSN and the new or existing XLAT=DPC, and PC/PCA/PCI/PCN is specified, the new PC must exist in the Remote Point Code/Mated Application table.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-GTT	SNEX	E2436	CHG-GTA	If the new or existing RI=SSN and the new or existing XLAT=DPCSSN, then the new or existing PC-SSN must be populated in the Remote Point Code/Mated Application table, unless FORCE is specified as YES.
CHG-GTT	SNEX	E2436	CHG-GTT	The New or existing Point Code/Subsystem Number combination must exist as a mated application.
CHG-GTT	SANE	E2436	CHG-GTT	The new or existing Point Code/Subsystem Number combination must exist as a mated application.
CHG-GTT	INCE	E2453	CHG-GTT	Subsystem table for primary remote point code is full.
CHG-GTT	INCE	E2454	CHG-GTT	Remote point code table is full.
CHG-GTT	RINC	E2457	CHG-GTA	If SSN is specified, the new or existing XLAT must be DPCSSN.
CHG-GTT	RINC	E2457	CHG-GTT	A Translated Subsystem Number can only be specified when DPCSSN is specified for the Translate Indicator parameter.
CHG-GTT	INCE	E2462	CHG-GTT	The GTT table can not be FULL.
CHG-GTT	INCE	E2462	CHG-GTA	The GTT table can not be FULL.
CHG-GTT	IDNS	E2465	CHG-GTA	The Translation Type must not be defined as an alias.
CHG-GTT	IDNS	E2465	CHG-GTT	The specified Translation Type must not be defined as an alias.
CHG-GTT	SNEX	E2466	CHG-GTA	The Translation Type must match that of an existing ANSI GTT Selector which is assigned to a GTT Set.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-GTT	SNEX	E2466	CHG-GTT	The specified Translation Type must exist.
CHG-GTT	SEHW	E2648	CHG-GTA	Route table not accessible.
CHG-GTT	SEHW	E2648	CHG-GTT	Route table not accessible.
CHG-GTT	IDNV	E2859	CHG-GTA	PC/PCA/PCI/PCN/PCN24 must be a full point code.
CHG-GTT	SEHW	E2874	CHG-GTA	Site ID table not accessible.
CHG-GTT	SEHW	E2874	CHG-GTT	Site ID table not accessible.
CHG-GTT	SEHW	E3119	CHG-GTA	GTA table not accessible.
CHG-GTT	SEHW	E3120	CHG-GTA	GTT DBMM table not accessible.
CHG-GTT	SEHW	E3543	CHG-GTA	GTT Selector table not accessible.
CHG-GTT	SEHW	E3544	CHG-GTA	GTT Set table not accessible.
CHG-GTT	IDNS	E3570	CHG-GTA	If the specified GTT Set is an ANSI set, PC/PCA must be a valid ANSI point code. If the ANSI/ITU/24 Bit SCCP Conversion feature is enabled, this MTT error code will not be generated.
CHG-GTT	IDNS	E3571	CHG-GTA	The length of the specified GTA must match the number of digits provisioned for the specified GTT Set referenced by GTTSN.
CHG-GTT	IDNV	N/A	CHG-GTA	*** cannot be specified for GTA.
CHG-GTT	IDNV	N/A	CHG-GTA	Alpha characters may not be specified for GTA.
CHG-GTT	RINC	N/A	CHG-GTT	The resulting (new or retained) routing indicator (RI) and SSN must ensure that SSN=000 if and only if RI=G (0), denoting a subsequent GTT at an STP indicated by the DPC. SEAS enforces this rule, but EAGLE does not.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-GTT	RINC	N/A	CHG-GTT	The resulting (new or retained) routing indicator (RI) and SSN must ensure that SSN is from the range 002-255 if and only if RI=D (1), denoting a specific SCCP subsystem at a signaling end-point. SEAS enforces this rule, but EAGLE does not.
CHG-GTT	SAAS	N/A	CHG-GTT	The newly defined DPC-SSN-RC-RI combination must not already be defined for any of the specified GTA(s) in the entity set.
CHG-GTT	SANE	N/A	CHG-GTT	The new DPC-SSN must be populated in the SCCP Application entity set (Remote Point Code/Mated Application Table).
CHG-GTT	SDNE	N/A	CHG-GTT	The new DPC must exist in the ORDERED ROUTE entity set or be part of a network cluster for which an ordered route is provisioned there. NOTE: The following clause applies only to the DBS software base. The PC specified does not have to exist in the ORDERED ROUTE entity set if the PC is the EAGLE's True PC.
CHG-GTT	SNEX	N/A	CHG-GTT	The specified target Destination Point Code/Subsystem Number combination must already exist in the STP active database for the Global Title Address(es) specified.
CHG-GTWYLS	IDNS	E2337	CHG-GTWYLS	If GWSD is specified as ON, GWSA must also be ON.
CHG-GTWYLS	CCNA	E2136	CHG-GTWYLS	At least one optional parameter must be specified.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-GTWYLS	GNFI	E2494	CHG-GTWYLS	The NSFI must be in the range (STOP, OPC, DPC, BLKDPC, BLKOPC, SIO).
CHG-GTWYLS	G NRF	E2552	CHG-GTWYLS	The NSFI/NSR combo must exist.
CHG-GTWYLS	GNSR	E2553	CHG-GTWYLS	NSR must be specified if NSFI is not STOP.
CHG-GTWYLS	GNSR	E2554	CHG-GTWYLS	NSR can not be specified if NSFI is STOP.
CHG-GTWYLS	INCE	E2925	CHG-GTWYLS	There must be enough screenset resources for the Gateway Linkset.
CHG-GTWYLS	GNEX	E2928	CHG-GTWYLS	The GTWYLS must already exist.
CHG-GTWYLS	SEHW	E3655	CHG-GTWYLS	The GWS Stop Action Set table not accessible.
CHG-GTWYLS	IDNS	E3657	CHG-GTWYLS	NSR can not be specified if ACTNAME is specified.
CHG-GTWYLS	IDNS	E3658	CHG-GTWYLS	Specifying ACTNAME via the supplier specific parameter block can only occur when NSFI is specified and equal to STOP or not changed an already equal to STOP.
CHG-GTWYLS	IPMS	N/A	CHG-GTWYLS	A linkset name must be specified.
CHG-GTWYLS	IPNS	N/A	CHG-GTWYLS	LSGI(ln) Parameter is not supported.
CHG-GTWYLS	IPNS	N/A	CHG-GTWYLS	The Supplier Specific Parameter is not supported.
CHG-LS	IDNV	E2113	CHG-LS	Parameters nfecli and nfepc are optional, but one may not be specified without the other.
CHG-LS	SEHW	E2122	CHG-LS	Linkset table not accessible.
CHG-LS	SLRA	E2125	CHG-LS	The STP must validate the change command to ensure that no links in the linkset are enabled to carry traffic (i.e., that all are in the UAV [unavailable] service state at the time the change is activated).
CHG-LS	CNNA	E2136	CHG-LS	One or more optional parameters must be specified.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-LS	IDNS	E2167	CHG-LS	The specified Adjacent Point Code must not match any of the STP's capability codes as specified in its self-identity. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
CHG-LS	IDNS	E2168	CHG-LS	The specified Adjacent Point Code must not match the STP's own DPC as specified in its self-identity. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
CHG-LS	IDRE	E2169	CHG-LS	If the system is configured for ANSI formatted point code, the network indicator value of the FE PC parameter must be 6 or greater when the cluster value is 0.
CHG-LS	IDNS	E2332	CHG-LS	Adjacent Point Code must be defined as true point code (aliases not permitted). This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
CHG-LS	IDNS	E2335	CHG-LS	If a PC destination address matching the entered new FE PC is found, the STP shall compare the FE CLLI for the given link set to the Destination Identifier (DI) of that matching destination. If they are not identical, the STP shall reject the CHG-LS command. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-LS	IDNS	E2341	CHG-LS	The point code types of the old APC and the new APC must match. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
CHG-LS	FPAS	E2343	CHG-LS	The STP must validate the change command to ensure that the new FE PC value is not already assigned to any other linkset (Linkset Name).
CHG-LS	SAAS	E2345	CHG-LS	The STP shall ensure that the link set specified does not already exist in the STP's active data base.
CHG-LS	SNEX	E2346	CHG-LS	The STP must validate the change command to ensure that the specified linkset exists in the STP's active database.
CHG-LS	IDNS	E2591	CHG-LS	BEI must be omitted or YES if APC is in the X.25 domain.
CHG-LS	IDNS	E2593	CHG-LS	Cannot change linkset APC domain. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
CHG-LS	IDNS	E2646	CHG-LS	APC cannot be referenced by an X.25 route with LC2NM=YES. This rule is a system-specific rule that SEAS does not enforce. If this condition is detected, the IDNS code must be returned to the SEAC.
CHG-LS	SEHW	E2648	CHG-LS	Route table not accessible.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-LS	IDNS	E2657	CHG-LS	APC must have been previously defined. This rule is a system specific rule that SEAS does not enforce. SEAS's view of the database requires that Destination entities be validated against Link Set entities. This is backwards from what EAGLE requires, according to this rule. The difference in rules represents a fundamental difference in the data base views of EAGLE and SEAS. If this condition is detected, the IDNS" code must be returned to the SEAC.
CHG-LS	IDNS	E2834	CHG-LS	MTPRSE parameter not permitted if MTPRS feature is OFF(ANSI).
CHG-LS	IDNS	E2848	CHG-LS	ASL8 parameter is only valid for ANSI link sets.
CHG-LS	IDNS	E2858	CHG-LS	SLSCI parameter is only valid for ANSI link sets.
CHG-LS	IDNV	E2859	CHG-LS	Adjacent destination address must be a full point code. The SEAS CHG-LS command does not have any provisions for accepting partial point codes. However, if less than 9 numerals are received for the Point Code parameter the commands will be rejected with the Input Data Not Valid error code.
CHG-LS	IDNS	E2860	CHG-LS	TFATCABMLQ value cannot exceed the total number of assigned links in the link set.
CHG-LS	IDNS	E2866	CHG-LS	If LST=C is specified, TFATCABMLQ is invalid unless ss7opts lsrestrict is on.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-LS	IDNS	E2866	CHG-LS	TFATCABMLQ is invalid for C-link sets unless ss7opts lsrestrict is on. For C-link sets it is never a primary route (except to reach STP's mate).
CHG-LS	SEHW	E2874	CHG-LS	STP site ID table not accessible.
CHG-LS	IDNS	E3851	CHG-LS	MTPRSE parameter not permitted if ITUMTPRS feature is OFF(ITU).
CHG-MAP	GR-310		CHG-MAP	Either or both of the values of parameters c-d must be different from the current values for the mate application.
CHG-MAP	GR-310		CHG-MAP	Either or both of the values of parameters c-d must also be different from the retained application identify specified in a-b (i.e. the retained application's new mate cannot be itself).
CHG-MAP	SDNE		CHG-MAP	The new mate DPC shall exist as a destination in the ORDERED ROUTE entity set or reside in a cluster destination for which ordered routes are specified there.
CHG-MAP	SNEX		CHG-MAP	The DPC and SSN being retained and the current mate specified must already exist in the MATED APPLICATIONS entity set.
CHG-MAP	<itu>	E2424	CHG-MAP	SRM=YES cannot be entered with ITU point code types.
CHG-MAP	IDNS	E2425	CHG-MAP	Mate PC/SSN cannot be the same as PC/SSN.
CHG-MAP	SDNE	E2427	CHG-MAP	MPC does not exist in routing table.
CHG-MAP	<itu>	E2429	CHG-MAP	MPC network type does not match PC network type.
CHG-MAP	INCE	E2430	CHG-MAP	Subsystem table for MPC is full.
CHG-MAP	SAAS	E2431	CHG-MAP	MPC/MSSN pair already exists. The new mate must not already be assigned in the MATED APPLICATIONS entity set.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-MAP	SNEX	E2445	CHG-MAP	PC and SSN are not primary applications.
CHG-MAP	SNEX	E2452	CHG-MAP	Remote point code does not exist in MAP table.
CHG-MAP	INCE	E2454	CHG-MAP	Remote point code table is full.
CHG-MAP	SNEX	E2456	CHG-MAP	SSN does not exist for given remote point code.
CHG-MAP	IEC=29 1	E2648	CHG-MAP	Failed reading route table.
CHG-MAP	IEC=29 1	E2874	CHG-MAP	Failed reading site identification table.
CHG-MAP	CCUN	E3009	CHG-MAP	LNP feature must be on when administering a true point code.
CHG-MAP	IEC=29 1	E3124	CHG-MAP	Failed reading SS APPL table.
CHG-MAP	SANE	N/A	CHG-MAP	The new mate must be provisioned in the SCCP APPLICATION entity set.
CHG-RTE	SEHW	E2122	CHG-RTE	Linkset table not accessible.
CHG-RTE	SNLM	E2128	CHG-RTE	If a new link set (nlsn) is specified in the command, that at least one member (i.e. link) must be assigned to it.
CHG-RTE	CNNA	E2136	CHG-RTE	Non-null values must be specified for at least one of the nlsn, or nrc parameters for the change command to be considered valid.
CHG-RTE	SLSM	E2346	CHG-RTE	If a new link set (nlsn) is specified in the command, that link set name must exist in the active LINK SET entity.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-RTE	LSTI	E2349	CHG-RTE	The STP must ensure that, if a specified destination address is a network cluster address (NI-NC), the linkset Type of the linkset used in the ordered route is not inconsistent with cluster routing, i.e., that the linkset specified is not an A-Linkset or an E-Linkset, but instead has linkset Type B, C, or D.
CHG-RTE	INCE	E2350	CHG-RTE	At most two linksets can be assigned the same cost.
CHG-RTE	SNEX	E2351	CHG-RTE	Linkset not assigned to route.
CHG-RTE	SAAS	E2355	CHG-RTE	If the Identity of one route is being changed because of a change in the linkset name attribute, the active ORDERED ROUTE entity should not already contain the new ORDERED ROUTE entity corresponding to the resulting linkset name and destination address.
CHG-RTE	IDNS	E2357	CHG-RTE	All linksets currently assigned to a routeset must be equipped.
CHG-RTE	SEHW	E2648	CHG-RTE	Route table not accessible.
CHG-RTE	SNEX	E2657	CHG-RTE	The target ordered-route must already exist in the ORDERED ROUTE entity set.
CHG-RTE	IDNS	E2867	CHG-RTE	Routes of equal cost (combined linksets) cannot exist for X.25 destinations.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-RTE	IDNS	E2885	CHG-RTE	If the specified destination address is a full point code address (NI-NC-NCM) and is a member of a provisioned cluster (NI-NC-*), attributes of the ordered routes assigned to it cannot be changed if the NCAI is specified as NO. If NCAI is specified as YES then the specified destination address is a provisioned member of a provisioned nested cluster where the attributes of the ordered routes assigned to it can be changed.
CHG-RTE	IDNV	E2886	CHG-RTE	Current destination address (cda) must be a full or a cluster point code.
CHG-RTE	IDNV	E2955	CHG-RTE	Network Routing is only valid if the NRT feature is ON.
CHG-RTE	IDNS	E3830	CHG-RTE	If LSN references a link set with IPGWAPC=YES, DPC must not specify a cluster route.
CHG-RTE	IDNS	N/A	CHG-RTE	** and *** cannot be specified for the ncm field of current destination address (cda).
CHG-RTE	IDNS	N/A	CHG-RTE	** cannot be specified for the nc field of current destination address (cda).
CHG-RTE	IDNS	N/A	CHG-RTE	** cannot be specified for the ni field of current destination address (cda).
CHG-RTE	IDNS	N/A	CHG-RTE	A range of current destination addresses (cda) cannot be specified.
CHG-RTE	IPNS	N/A	CHG-RTE	New destination address (nda) cannot be specified.
CHG-RTE	IPNS	N/A	CHG-RTE	New supplier-specific parameters (nz) cannot be specified.
CHG-SCRAFTPC	IDNS		CHG-SCR-AFTP C	Ranges are not supported for SSN.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRAFTPC	IDNV		CHG-SCR-AFTP C	The screen reference must begin with an alpha character.
CHG-SCRAFTPC	IDNS	E2495	CHG-SCR-AFTP C	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
CHG-SCRAFTPC	GCLI	E2511	CHG-SCR-AFTP C	Point codes specified by NI-NC-NCM must be valid.
CHG-SCRAFTPC	GCM I	E2512	CHG-SCR-AFTP C	Point codes specified by NI-NC-NCM must be valid.
CHG-SCRAFTPC	IDNS	E2556	CHG-SCR-AFTP C	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.
CHG-SCRAFTPC	GNEX	E2559	CHG-SCR-AFTP C	The affected point code(s) and subsystem number to be changed must exist in the AFTP entity set.
CHG-SCRAFTPC	GAEX	E2561	CHG-SCR-AFTP C	The new affected point code(s) and subsystem number to be changed can not already exist in the AFTP entity set.
CHG-SCRAFTPC	IDRE	E2564	CHG-SCR-AFTP C	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRAFTPC	GNEX	E2573	CHG-SCR-AFTP C	The SR must already exist.
CHG-SCRAFTPC	GNFI	E3271	CHG-SCR-AFTP C	NSFI must be STOP if specified.
CHG-SCRAFTPC	IDNS	N/A	CHG-SCR-AFTP C	A specific SSN must be specified in the range (*,1-255).
CHG-SCRAFTPC	IPNS	N/A	CHG-SCR-AFTP C	The supplier specific parameter is not supported.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRBLKDPC	IDNV		CHG-SCR-BLKD PC	The screen reference must begin with an alpha character.
CHG-SCRBLKDPC	IDNS	E2136	CHG-SCR-BLKD PC	At least one optional parameter must be specified.
CHG-SCRBLKDPC	IDNS	E2485	CHG-SCR-BLKD PC	If NI = C, NC and NCM must either be C or not entered. If ZONE = C, AREA and ID must either be C or not entered. If MSA = C, SSA and SP must either be C or not entered. In all cases if C for "continue" is entered for the first parameter the other parameters will default to C in the database.
CHG-SCRBLKDPC	IDNS	E2495	CHG-SCR-BLKD PC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
CHG-SCRBLKDPC	GCLI	E2511	CHG-SCR-BLKD PC	Point codes specified by NI-NC-NCM or NNI-NNC-NNCM must be valid.
CHG-SCRBLKDPC	GCMII	E2512	CHG-SCR-BLKD PC	Point codes specified by NI-NC-NCM or NNI-NNC-NNCM must be valid.
CHG-SCRBLKDPC	GNII	E2526	CHG-SCR-BLKD PC	All new point code parameters must be null if NI, ZONE, MSA, or NPC are equal to C. Point Code C-C-C cannot be changed to a numbered point code.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRBLKDPC	IDNV	E2527	CHG-SCR-BLKD PC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA, NSSA, NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
CHG-SCRBLKDPC	GNFI	E2547	CHG-SCR-BLKD PC	NSFI can not be FAIL when changing a continue(c-c-c) entry.
CHG-SCRBLKDPC	GNFI	E2549	CHG-SCR-BLKD PC	NSFI must be FAIL when entering any point code that is not a continue entry (C-C-C).
CHG-SCRBLKDPC	GNFI	E2550	CHG-SCR-BLKD PC	NSFI and NSR can not be specified when changing a screening entry which is not the continue entry (c-c-c).
CHG-SCRBLKDPC	G NRF	E2552	CHG-SCR-BLKD PC	The screen referenced by NSFI and NSR must already exist.
CHG-SCRBLKDPC	GNSR	E2553	CHG-SCR-BLKD PC	If NSFI is not equal to STOP or FAIL, NSR must be specified.
CHG-SCRBLKDPC	IDNS	E2556	CHG-SCR-BLKD PC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
CHG-SCRBLKDPC	GAEX	E2558	CHG-SCR-BLKD PC	If asterisk is specified for the new blocked DPCs, nothing that matches the specified range of DPCs may already exist in the BLKDPC screening table for the screening reference.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRBLKDPC	GAEX	E2558	CHG-SCR-BLKD PC	The new blocked DPC given by NNI-NNC-NNC, NZONE-NAREA-NID, NMSA-NSSA-NSP, or NNPC must not already exist as specified or within an existing range of DPCs.
CHG-SCRBLKDPC	IDNS	E2564	CHG-SCR-BLKD PC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRBLKDPC	GNEX	E2573	CHG-SCR-BLKD PC	The SR must already exist.
CHG-SCRBLKDPC	GNFI	E3271	CHG-SCR-BLKD PC	The NSFI must be valid for BLKDPC screens.
CHG-SCRBLKDPC	GNEX	E3272	CHG-SCR-BLKD PC	The blocked DPC defined by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must already exist in the screening reference.
CHG-SCRBLKDPC	IPNS	N/A	CHG-SCR-BLKD PC	The Supplier Specific Parameter is not supported.
CHG-SCRBLKOPC	IDNV		CHG-SCR-BLKO PC	The screen reference must begin with an alpha character.
CHG-SCRBLKOPC	IDNS	E2136	CHG-SCR-BLKO PC	At least one optional parameter must be specified.
CHG-SCRBLKOPC	IDNS	E2495	CHG-SCR-BLKO PC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
CHG-SCRBLKOPC	GCLII	E2511	CHG-SCR-BLKO PC	Point codes specified by NI-NC-NCM or NNI-NNC-NNCM must be valid.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRBLKOPC	GCFI	E2512	CHG-SCR-BLKO PC	Point codes specified by NI-NC-NCM or NNI-NNC-NNCM must be valid.
CHG-SCRBLKOPC	GNFI	E2547	CHG-SCR-BLKO PC	NSFI can not be FAIL when changing a continue entry.
CHG-SCRBLKOPC	GNFI	E2549	CHG-SCR-BLKO PC	NSFI must be FAIL when entering any pointcode that is not a continue entry (C-C-C).
CHG-SCRBLKOPC	GNFI	E2550	CHG-SCR-BLKO PC	NSFI and NSR can not be specified when changing a screening entry who's entry is not continue (c-c-c).
CHG-SCRBLKOPC	GNSR	E2552	CHG-SCR-BLKO PC	The screen referenced by NSFI and NSR must already exist.
CHG-SCRBLKOPC	GNSR	E2553	CHG-SCR-BLKO PC	If NSFI is not equal to STOP or FAIL, NSR must be specified.
CHG-SCRBLKOPC	IDNS	E2556	CHG-SCR-BLKO PC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
CHG-SCRBLKOPC	GAEX	E2558	CHG-SCR-BLKO PC	The new blocked OPC or range of OPC's, given by NNI-NNC-NNC, NZONE-NAREA-NID, NMSA-NSSA-NSP, or NNPC must not already exist as specified or within an existing range of blocked OPCs.
CHG-SCRBLKOPC	IDNS	E2564	CHG-SCR-BLKO PC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRBLKOPC	GNEX	E2573	CHG-SCR-BLKO PC	The SR must already exist.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRBLKOPC	GNFI	E3271	CHG-SCR-BLKO PC	The NSFI must be valid for BLKOPC screens.
CHG-SCRBLKOPC	GNEX	E3272	CHG-SCR-BLKO PC	The blocked OPC defined by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must already exist in the screening reference.
CHG-SCRBLKOPC	IPNS	N/A	CHG-SCR-BLKO PC	The Supplier Specific Parameter is not supported.
CHG-SCRCDPA	IDNV		CHG-SCR-CDPA	The screen reference must begin with an alpha character.
CHG-SCRCDPA	IDNS	E2136	CHG-SCR-CDPA	At least one optional parameter must be specified.
CHG-SCRCDPA	IDNS	E2484	CHG-SCR-CDPA	If NSFI=AFTPC then SSN must equal 1.
CHG-SCRCDPA	GFII	E2508	CHG-SCR-CDPA	If SSN is not equal to 1, the SCMG format identifier must be NULL.
CHG-SCRCDPA	GFII	E2508	CHG-SCR-CDPA	The SCMG I D parameter must be specified for SSN=1.
CHG-SCRCDPA	GCLI	E2511	CHG-SCR-CDPA	Point codes specified by NI-NC-NCM must be valid.
CHG-SCRCDPA	GCM I	E2512	CHG-SCR-CDPA	Point codes specified by NI-NC-NCM must be valid.
CHG-SCRCDPA	GAEX	E2516	CHG-SCR-CDPA	The new CDPA PC/SCMGFID and subsystem number to be changed can not already exist in the CDPA entity set.
CHG-SCRCDPA	GNEX	E2517	CHG-SCR-CDPA	The CDPA PC/SCMGFID and subsystem number to be changed must exist in the CDPA entity set.
CHG-SCRCDPA	GNRF	E2552	CHG-SCR-CDPA	The screen referenced by NSFI and NSR must already exist.
CHG-SCRCDPA	GNSR	E2553	CHG-SCR-CDPA	NSR must be specified if NSFI is not STOP.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRCDDPA	GNSR	E2554	CHG-SCR-CDPA	NSR must be NULL if the NSFI specified is STOP.
CHG-SCRCDDPA	GNII	E2564	CHG-SCR-CDPA	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRCDDPA	GNEX	E2573	CHG-SCR-CDPA	The SR must already exist.
CHG-SCRCDDPA	GNFI	E3271	CHG-SCR-CDPA	The NSFI must be valid for CDPA screens if specified.
CHG-SCRCDDPA	IDNS	N/A	CHG-SCR-CDPA	'**' is not supported for the SCMGFID parameter.
CHG-SCRCDDPA	IDNS	N/A	CHG-SCR-CDPA	Ranges are not supported for SSN.
CHG-SCRCGPA	IDNV		CHG-SCR-CGPA	The screen reference must begin with an alpha character.
CHG-SCRCGPA	IDNS	E2136	CHG-SCR-CGPA	At least one optional parameter must be specified.
CHG-SCRCGPA	GNFI	E2492	CHG-SCR-CGPA	The NSFI may only be CDPA if RI is DPC or asterisk.
CHG-SCRCGPA	GNFI	E2492	CHG-SCR-CGPA	The NSFI may only be TT if RI is GT or asterisk.
CHG-SCRCGPA	GCLI	E2511	CHG-SCR-CGPA	Point codes specified by NI-NC-NCM must be valid.
CHG-SCRCGPA	GCFI	E2512	CHG-SCR-CGPA	Point codes specified by NI-NC-NCM must be valid.
CHG-SCRCGPA	GAEX	E2514	CHG-SCR-CGPA	The new CGPA PC, RI, SCCPMT and subsystem number to be added can not already exist in the CGPA entity set.
CHG-SCRCGPA	GNRF	E2552	CHG-SCR-CGPA	The screen referenced by NSFI and NSR must already exist.
CHG-SCRCGPA	GNSR	E2553	CHG-SCR-CGPA	NSR must be specified if NSFI is not STOP.
CHG-SCRCGPA	GNSR	E2554	CHG-SCR-CGPA	NSR must be NULL if the NSFI specified is STOP.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRCGPA	IDNS	E2556	CHG-SCR-CGPA	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.
CHG-SCRCGPA	GNEX	E2559	CHG-SCR-CGPA	The CGPA PC or range of PCs, RI, SCCPMT, and subsystem number(s) to be changed must exist in the CGPA entity set.
CHG-SCRCGPA	GAEX	E2561	CHG-SCR-CGPA	The new CGPA PC and subsystem number to be changed can not already exist in the CGPA entity set.
CHG-SCRCGPA	IDRE	E2564	CHG-SCR-CGPA	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRCGPA	GNEX	E2573	CHG-SCR-CGPA	The SR must already exist.
CHG-SCRCGPA	GNFI	E3271	CHG-SCR-CGPA	The NSFI must be valid for CGPA screens.
CHG-SCRCGPA	IDNS	N/A	CHG-SCR-CGPA	A specific RI must be specified in the range (*, GT, DPC).
CHG-SCRCGPA	IDNS	N/A	CHG-SCR-CGPA	Ranges are not supported for SSN.
CHG-SCRCGPA	IDNS	N/A	CHG-SCR-CGPA	The current SSN must be specified in the range (*, 1-255).
CHG-SCRCGPA	IPNS	N/A	CHG-SCR-CGPA	The linkset group identifier parameter is not supported.
CHG-SCRDESTFLD	IDNV		CHG-SCR-DESTFLD	The screen reference must begin with an alpha character.
CHG-SCRDESTFLD	IDNS	E2136	CHG-SCR-DESTFLD	At least one optional parameter must be specified.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRDESTFLD	IDNS	E2495	CHG-SCR-DESTFLD	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
CHG-SCRDESTFLD	GCLI	E2511	CHG-SCR-DESTFLD	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
CHG-SCRDESTFLD	GCM I	E2512	CHG-SCR-DESTFLD	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
CHG-SCRDESTFLD	IDNV	E2527	CHG-SCR-DESTFLD	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
CHG-SCRDESTFLD	GNSR	E2554	CHG-SCR-DESTFLD	NSR can not be specified.
CHG-SCRDESTFLD	IDNS	E2556	CHG-SCR-DESTFLD	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
CHG-SCRDESTFLD	GAEX	E2558	CHG-SCR-DESTFLD	The new DESTFLD, given by NNI-NNC-NNC, NZONE-NAREA-NID, NMSA-NSSA-NSP, or NNPC must not already exist as specified or within an existing range of DPCs.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRDESTFLD	GNII	E2564	CHG-SCR-DESTFLD	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRDESTFLD	GNEX	E2573	CHG-SCR-DESTFLD	The screen reference must exist for the DESTFLD screen name.
CHG-SCRDESTFLD	GNFI	E3271	CHG-SCR-DESTFLD	NSFI must be STOP if specified.
CHG-SCRDESTFLD	GNEX	E3272	CHG-SCR-DESTFLD	The DESTFLD entry defined by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must already exist in the screening reference.
CHG-SCRDESTFLD	IPNS	N/A	CHG-SCR-DESTFLD	The Supplier Specific Parameter is not supported.
CHG-SCRDPC	GNFI		CHG-SCR-DPC	The NSFI must be valid for DPC screens.
CHG-SCRDPC	IDNV		CHG-SCR-DPC	The screen reference must begin with an alpha character.
CHG-SCRDPC	IDNS	E2136	CHG-SCR-DPC	At least one optional parameter must be specified.
CHG-SCRDPC	IDNS	E2495	CHG-SCR-DPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
CHG-SCRDPC	GCLI	E2511	CHG-SCR-DPC	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
CHG-SCRDPC	GCM I	E2512	CHG-SCR-DPC	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRDPC	IDNV	E2527	CHG-SCR-DPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
CHG-SCRDPC	GNERF	E2552	CHG-SCR-DPC	The screen referenced by NSFI and NSR must already exist.
CHG-SCRDPC	GNSR	E2553	CHG-SCR-DPC	If NSFI is not equal to STOP, NSR must be specified.
CHG-SCRDPC	IDNS	E2556	CHG-SCR-DPC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
CHG-SCRDPC	GAEX	E2558	CHG-SCR-DPC	The new DPC, given by NNI-NNC-NNC, NZONE-NAREA-NID, NMSA-NSSA-NSP, or NNPC must not already exist as specified or within an existing range of DPCs.
CHG-SCRDPC	GNII	E2564	CHG-SCR-DPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCRDPC	GNEX	E2573	CHG-SCR-DPC	The SR must already exist.
CHG-SCRDPC	GNEX	E3272	CHG-SCR-DPC	The DPC entry defined by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must already exist in the screening reference.
CHG-SCRDPC	IDNS	N/A	CHG-SCR-DPC	The Supplier Specific Parameter is not supported.
CHG-SCR-ISUP	IDNV	E2041	CHG-SCR-ISUP	The screen reference must begin with an alpha character.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCR-ISUP	IDRE	E2060	CHG-SCR-ISUP	Low bound exceeds upper bound of range – ISUPMT/TUPMT. SEAS is not applicable for TUP.
CHG-SCR-ISUP	IDMS	E2396	CHG-SCR-ISUP	Parameter NSFI must be specified if parameter NISUPMT is specified (SEAS only).
CHG-SCR-ISUP	IDNV	E2397	CHG-SCR-ISUP	Parameter NSFI must be not specified if parameters ISUPMT and NISUPMT are not specified (SEAS only).
CHG-SCR-ISUP	GAEX	E2519	CHG-SCR-ISUP	New ISUPMT/TUPMT already exists in given SR. SEAS is not applicable for TUP.
CHG-SCR-ISUP	GNEX	E2520	CHG-SCR-ISUP	ISUPMT/TUPMT does not exist in given SR. SEAS is not applicable for TUP.
CHG-SCR-ISUP	GNFI	E2548	CHG-SCR-ISUP	NSFI must equal STOP, if specified.
CHG-SCR-ISUP	GNSR	E2554	CHG-SCR-ISUP	NSR can not be specified if the NSFI is STOP.
CHG-SCR-ISUP	GNEX	E2573	CHG-SCR-ISUP	The SR must exist.
CHG-SCR-ISUP	GNFI	E3271	CHG-SCR-ISUP	NSFI is invalid.
CHG-SCR-ISUP	IDNV	E3303	CHG-SCR-ISUP	SEAS only: VALUE 'x' FOR <> PARAMETER IS NOT VALID.
CHG-SCR-ISUP	IDRE	E3306	CHG-SCR-ISUP	SEAS only: VALUE 'x' OUT OF RANGE FOR <> PARAMETER.
CHG-SCR-ISUP	IPMS	E3322	CHG-SCR-ISUP	SEAS only: INPUT PARAMETER <> MISSING.
CHG-SCR-ISUP	IPNS	E3324	CHG-SCR-ISUP	SEAS only: INPUT PARAMETER - USE OF PARAMETER NOT SUPPORTED BY THIS IMPLEMENTATION(The supplier specific parameter 'nz' is not supported).

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCR-ISUP	IDNV	E3506	CHG-SCR-ISUP	ISUP Message Type must be valid (SEAS only).
CHG-SCROPC	GNFI		CHG-SCR-OPC	The NSFI must be valid for OPC screens.
CHG-SCROPC	IDNV		CHG-SCR-OPC	The screen reference must begin with an alpha character.
CHG-SCROPC	IDNS	E2136	CHG-SCR-OPC	At least one optional parameter must be specified.
CHG-SCROPC	IDNS	E2495	CHG-SCR-OPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
CHG-SCROPC	GCLI	E2511	CHG-SCR-OPC	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
CHG-SCROPC	GCM I	E2512	CHG-SCR-OPC	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
CHG-SCROPC	G N R F	E2552	CHG-SCR-OPC	The screen referenced by NSFI and NSR must already exist.
CHG-SCROPC	G N S R	E2553	CHG-SCR-OPC	If NSFI is not equal to STOP, NSR must be specified.
CHG-SCROPC	IDNS	E2556	CHG-SCR-OPC	A complete point code must be entered, i.e. ‘***’ may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: ‘***’ in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for “continue” in commands that allow it.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCROPC	GAEX	E2558	CHG-SCR-OPC	The new OPC, given by NNI-NNC-NNC, NZONE-NAREA-NID, NMSA-NSSA-NSP, or NNPC must not already exist as specified or within an existing range of OPCs.
CHG-SCROPC	GNII	E2564	CHG-SCR-OPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
CHG-SCROPC	GNEX	E2573	CHG-SCR-OPC	The screen reference must exist for the OPC screen name.
CHG-SCROPC	GNEX	E3272	CHG-SCR-OPC	The current OPC entry or range of entries defined by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must already exist in the screening reference.
CHG-SCROPC	IDNS	N/A	CHG-SCR-OPC	** is not supported for NC or NCM parameters. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax.
CHG-SCROPC	IDNS	N/A	CHG-SCR-OPC	The Supplier Specific Parameter is not supported.
CHG-SCRSIO	IDNV		CHG-SCR-SIO	The screen reference must begin with an alpha character.
CHG-SCRSIO	IDRE		CHG-SCR-SIO	Heading codes must be in the range (*,0..15).
CHG-SCRSIO	IDRE		CHG-SCR-SIO	Message Priority must be in the range (*,0..3).
CHG-SCRSIO	IDRE		CHG-SCR-SIO	The Network Indicator Code must be in the range (*,0..3).
CHG-SCRSIO	IDNS	E2136	CHG-SCR-SIO	At least one optional parameter must be specified.
CHG-SCRSIO	GHCI	E2488	CHG-SCR-SIO	H0 and H1 must be specified if SI is less than or equal 2.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRSIO	GHCI	E2490	CHG-SCR-SIO	For screening entries containing SI>2, H0 and H1, must not be specified.
CHG-SCRSIO	GHCI	E2490	CHG-SCR-SIO	For screening entries containing SI>2 or NSI>2, H0, H1, NH0, and NH1 must not be specified.
CHG-SCRSIO	GAEX	E2518	CHG-SCR-SIO	The network indicator code, service indicator, priority(s), and heading codes to be added or changed to the allowed SIO entity set can not already exist. If a range is specified, nothing within the entire combination of the specified range may already exist.
CHG-SCRSIO	G NRF	E2552	CHG-SCR-SIO	The screen referenced by NSFI and NSR must already exist.
CHG-SCRSIO	GNSR	E2553	CHG-SCR-SIO	NSR must be specified when NSFI is not STOP.
CHG-SCRSIO	GNSR	E2554	CHG-SCR-SIO	NSR can not be specified when NSFI=STOP.
CHG-SCRSIO	GNEX	E2569	CHG-SCR-SIO	The current network indicator code, service indicator, priority(s), and heading codes to be deleted/changed type must exist.
CHG-SCRSIO	GNEX	E2573	CHG-SCR-SIO	The SR must already exist.
CHG-SCRSIO	GHCI	E3269	CHG-SCR-SIO	H1 must not be NULL if H0 is not NULL.
CHG-SCRSIO	GHCI	E3269	CHG-SCR-SIO	If H0 is asterisk, H1 must be asterisk.
CHG-SCRSIO	GHCI	E3269	CHG-SCR-SIO	If NH0 is asterisk or a range, NH1 must also be asterisk.
CHG-SCRSIO	GNFI	E3271	CHG-SCR-SIO	NSFI may be CDPA only if SI is 03.
CHG-SCRSIO	GNFI	E3271	CHG-SCR-SIO	NSFI may be CGPA only if SI is 03.
CHG-SCRSIO	GNFI	E3271	CHG-SCR-SIO	NSFI may be DESTFLD only if SI is 00.
CHG-SCRSIO	GNFI	E3271	CHG-SCR-SIO	NSFI may be ISUP only if SI is 05.
CHG-SCRSIO	GNFI	E3271	CHG-SCR-SIO	The NSFI must be valid for SIO screens.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SCRSIO	IDNS	N/A	CHG-SCR-SIO	The current NIC can not be specified as "***".
CHG-SCRSIO	IDNS	N/A	CHG-SCR-SIO	The current PRI can not be specified as "***".
CHG-SCR TT	IDNV		CHG-SCR-TT	The screen reference must begin with an alpha character.
CHG-SCR TT	IDNS	E2136	CHG-SCR-TT	At least one optional parameter must be specified.
CHG-SCR TT	GNRF	E2552	CHG-SCR-TT	The screen referenced by NSFI and NSR must already exist.
CHG-SCR TT	GNSR	E2553	CHG-SCR-TT	NSR must be specified if the NSFI is not STOP.
CHG-SCR TT	GNSR	E2554	CHG-SCR-TT	NSR can not be specified if the NSFI is STOP.
CHG-SCR TT	GNEX	E2573	CHG-SCR-TT	The SR must already exist.
CHG-SCR TT	GNEX	E2574	CHG-SCR-TT	The current translation type value or range must exist.
CHG-SCR TT	GAEX	E2575	CHG-SCR-TT	The new Translation type value or range can not already exist in the database.
CHG-SCR TT	N/A	E3657	CHG-SCR-TT	NSR can not be specified if ACTNAME is specified.
CHG-SCR TT	IDNS	N/A	CHG-SCR-TT	The current translation type must be specified and can not be NULL or **.
CHG-SCR TT	IPNS	N/A	CHG-SCR-TT	The supplier specific parameter is not supported.
CHG-SLK	CNNA	N/A	CHG-SLK	Non-null values must be specified for at least one of the (nsvcst, nlkspd, nencr, neqopts, or nz) parameters for the change command to be considered valid.
CHG-SLK	IDNS	N/A	CHG-SLK	A range of member numbers (mn) cannot be specified.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHG-SLK	IPNS	N/A	CHG-SLK	New encryption option (nencr) cannot be specified.
CHG-SLK	IPNS	N/A	CHG-SLK	New equipment options (neqopts) cannot be specified
CHG-SLK	IPNS	N/A	CHG-SLK	New link speed parameter (nlkspd) cannot be specified.
CHG-SLK	IPNS	N/A	CHG-SLK	New supplier-specific signaling link parameter(s) (nz) cannot be specified.
CHG-SLK	SAIS	N/A	CHG-SLK	The member (i.e., link) shall not currently be in the ACT service state if the specified new service state is ACT.
CHG-SLK	SAOS	N/A	CHG-SLK	The member (i.e., link) shall not currently be in the OOS service state if the specified new service state is OOS.
CHG-SLK	SAUA	N/A	CHG-SLK	The member (i.e., link) shall not currently be in the UAV service state if the specified new service state is UAV.
CHG-SLK	SCDP	N/A	CHG-SLK	The member (i.e., link) shall not currently be undergoing loop back testing if the specified new service state is ACT.
CHG-SLK	SESW	N/A	CHG-SLK	Internal software errors must not occur.
CHG-SLK	SLSM	N/A	CHG-SLK	The link set must exist in the STP active data base.
CHG-SLK	SNEX	N/A	CHG-SLK	The Link Set signaling link member must exist in the STP active data base.
CHK-UNREF-ENT	IPMS	E2136	CHK-UNREF-ENT	At least one Entity Set Name must be specified.
CHK-UNREF-ENT	SEHW	E2926	CHK-UNREF-ENT	GWS database not accessible.
CHK-UNREF-ENT	IDNV	N/A	CHK-UNREF-ENT	No other Entity Types may be entered with **.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
CHK-UNREF-ENT	IPEX	N/A	CHK-UNREF-ENT	No more than 10 Entity Set Names may be specified.
DISC-SLK	IDNS		DLT-SLK	If specified link is A4, B4, ..., A31, B31, card running must be HC-MIM - Link a4, b4, ..., a31, b31 is invalid parameter for channel card. Card running must be an HC-MIM if specified link is a4-a31 or b4-b31.
DISC-SLK	SEHW	E2103	DLT-SLK	Link table not accessible.
DISC-SLK	IDNS	E2106	DLT-SLK	The signaling link may not have an active LFS test in progress.
DISC-SLK	SEHW	E2122	DLT-SLK	Linkset table not accessible.
DISC-SLK	SNLM	E2128	DLT-SLK	If an ordered route exists that uses this linkset, other members must be connected (assigned) in the linkset unless FORCE = YES is specified.
DISC-SLK	SNEX	E2373	DLT-SLK	The signaling link must already exist in the STP active database.
DISC-SLK	IDNS	E2586	DLT-SLK	If card application is SS7GX25, LINK must be A.
DISC-SLK	SEHW	E2648	DLT-SLK	Route table not accessible.
DISC-SLK	IDNS	E2976	DLT-SLK	If specified link is A1, B1, A2, B2, A3 or B3, card running must be: - a Multi Port LIM, a MIM, or a HC-MIM - a SSEDCEM and with APPL type IPLIM/IPLIMI .
DISC-SLK	IDNS	E3494	DLT-SLK	link a4, b4, ..., a31, b31 cannot be specified for even-numbered card location.
DISC-SLK	SLRA	E3726	DLT-SLK	The link must not be enabled to carry traffic (i.e., it must be in the unavailable [UAV] maintenance state) before the action is applied.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DISC-SLK	IDNS	E3771	DLT-SLK	PORT B not supported for device (IPLIM, IPLIMI, SS7IPGW, IPGWI, ATMANSI). Starting with IP7 SG Release 2.1, this error code will not be used for dlt-slk commands related to IPLIM and IPLIMI cards. As of release 2.1, those 2 applications are capable of supporting both a and b ports.
DISC-SLK	IDNS	N/A	DLT-SLK	** cannot be specified for the member number parameter (mn).
DISC-SLK	IDNS	N/A	DLT-SLK	A range of member numbers (mn) cannot be specified.
DLT-DSTN	N/A	E2055	DLT-DSTN	The DPCN specified must match the format dictated by the npcfnti parameter via the CHG-STPOPTS command.
DLT-DSTN	SEHW	E2122	DLT-DSTN	Link set table not accessible.
DLT-DSTN	SEHW	E2145	DLT-DSTN	MAS configuration table not accessible.
DLT-DSTN	IDNS	E2334	DLT-DSTN	DPC cannot be defined as a link set APC or SAPC.
DLT-DSTN	SRTE	E2354	DLT-DSTN	The STP shall validate the command to ensure that no ordered routes exist in the ORDERED ROUTE entity set for the specified destination address.
DLT-DSTN	IDNS	E2596	DLT-DSTN	If X.25 Gateway feature is ON, ensure that X.25 Destination is not referenced by the deleted Destination.
DLT-DSTN	SEHW	E2648	DLT-DSTN	Route table not accessible.
DLT-DSTN	SEHW	E2649	DLT-DSTN	X.25 destination table not accessible.
DLT-DSTN	SNEX	E2657	DLT-DSTN	The STP shall validate the command to ensure that the corresponding DESTINATION entity already exists in the STP's active data base.
DLT-DSTN	IDNS	E2857	DLT-DSTN	DPC cannot be referenced by SCCP as a destination point code in the mate applications table.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-DSTN	IDRE	E2886	DLT-DSTN	Destination address must be a full or a cluster point code.
DLT-DSTN	IDNV	E2955	DLT-DSTN	Network Routing is only valid if the NRT feature is ON.
DLT-GTT	SNEX	E2401	DLT-GTA	The GTA range cannot overlap a currently existing range for the specified GTT Set in the STP active data base.
DLT-GTT	SNEX	E2402	DLT-GTA	The specified GTA range must exist for the specified GTT Set in the STP active data base (note that an exact match is not required) .
DLT-GTT	SNEX	E2402	DLT-GTT	The specified GTA range must exist.
DLT-GTT	IDNS	E2403	DLT-GTA	If EGTA is specified, GTA and EGTA must be the same length.
DLT-GTT	IDNS	E2403	DLT-GTT	If a Global Title Address range is specified, the length of the starting and ending address must be the same.
DLT-GTT	IDNS	E2404	DLT-GTT	The length of the specified GTA must match the number of digits provisioned for the specified Translation Type or the Translation Type referenced by the specified Translation Type Name, unless the PVGTT or VGTT feature is on. In the case the PVGTT feature is on the length of the specified GTA and EGTA can be less than or equal to the number of digits provisioned for the corresponding TT. In the case the VGTT feature is on, up to 10 different lengths can be provisioned per TT.
DLT-GTT	IDNC	E2420	DLT-GTA	If EGTA is specified, EGTA must be greater than GTA.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-GTT	IDNC	E2420	DLT-GTT	If a range of GTAs is specified, the end of range value must be greater than the start of range value.
DLT-GTT	INCE	E2462	DLT-GTT	The GTT table can not be FULL. In the case a delete command causes a split requiring more entries to be added.
DLT-GTT	INCE	E2462	DLT-GTA	The GTT table can not be FULL in case a delete command causes a split requiring more entries to be added.
DLT-GTT	IDNS	E2465	DLT-GTA	The Translation Type must not be defined as an alias.
DLT-GTT	IDNS	E2465	DLT-GTT	The specified Translation Type must not be defined as an alias.
DLT-GTT	SNEX	E2466	DLT-GTA	The Translation Type must match that of an existing ANSI GTT Selector.
DLT-GTT	SNEX	E2466	DLT-GTT	The specified Translation Type must exist.
DLT-GTT	SEHW	E3119	DLT-GTA	GTA table not accessible.
DLT-GTT	SEHW	E3120	DLT-GTA	GTT DBMM table not accessible.
DLT-GTT	SEHW	E3543	DLT-GTA	GTT Selector table not accessible.
DLT-GTT	SEHW	E3544	DLT-GTA	GTT Set table not accessible.
DLT-GTT	IDNS	E3571	DLT-GTA	The length of the specified GTA must match the number of digits provisioned for the specified GTT Set referenced by GTTSN.
DLT-GTT	IDNV	N/A	DLT-GTA	*** cannot be specified for GTA.
DLT-GTT	IDNV	N/A	DLT-GTA	Alpha characters may not be specified for GTA.
DLT-GTT	IDNV	N/A	DLT-GTA	DPC must be a full point code.
DLT-GTT	IDRE	N/A	DLT-GTA	DPC must not be out of range.
DLT-GTWYLS	GNEX	E2928	DLT-GTWYLS	The GTWYLS must exist.
DLT-GTWYLS	IPMS	N/A	DLT-GTWYLS	A linkset name must be specified.
DLT-LS	SEHW	E2122	DLT-LS	Linkset table not accessible.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-LS	SMEX	E2342	DLT-LS	The specified link set must have no assigned members.
DLT-LS	SNEX	E2346	DLT-LS	The linkset to be deleted must already exist in the STP active database.
DLT-LS	SRTE	E2348	DLT-LS	An ordered route must not exist that uses this linkset.
DLT-LS	SEHW	E2648	DLT-LS	Route table not accessible.
DLT-LS	IDNS	E2932	DLT-LS	Linksets that are SEAS GTWYLS cannot be deleted locally. This error is generated because SEAS Gateway linksets do not exist on system, but are screen sets in use by linksets.
DLT-LS	SEHW	E4379	DLT-LS	Route Exception table not accessible.
DLT-MAP	SNEX	E2445*	DLT-MAP	PC and SSN are not primary applications.
DLT-MAP	SNEX	E2452	DLT-MAP	Primary remote point code (PC) must already exist in the MATE APPLICATIONS entity set.
DLT-MAP	SNEX	E2456	DLT-MAP	Primary subsystem number (SSN) must already exist in the MATE APPLICATIONS entity set associated with given Primary remote point code.
DLT-MAP	IEC=29 1	E2874	DLT-MAP	Failed reading site identification table.
DLT-MAP	SESW	E3287	DLT-MAP	Cannot delete STP True point code assigned to lnp, INP, or EIR subsystem (non-DBS 1.0 only).
DLT-RTE	SEHW	E2122	DLT-RTE	Linkset table not accessible.
DLT-RTE	SNEX	E2351	DLT-RTE	The STP must ensure that the ORDERED ROUTE entity set of the STP active database already contains an entity with the destination and linkset specified.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-RTE	SGRD	E2356	DLT-RTE	The STP must ensure that, for Point Code and Capability Code destinations, if an Ordered GTT object exists with this destination, at least one other entity must exist in the Ordered Route entity set for that destination or for a network cluster destination including that DPC.
DLT-RTE	IDNS	E2357	DLT-RTE	All linksets currently assigned to a routeset must be equipped.
DLT-RTE	IDNS	E2358	DLT-RTE	If all routes are to be deleted in a routeset, the routeset must not be empty.
DLT-RTE	SEHW	E2639	DLT-RTE	Redirect table not accessible.
DLT-RTE	IDNS	E2644	DLT-RTE	Cannot delete last route to a destination referenced by an X.25 route.
DLT-RTE	IDNS	E2645	DLT-RTE	Cannot delete last route to a destination referenced by the redirect function's destination parameter.
DLT-RTE	SEHW	E2648	DLT-RTE	Route table not accessible.
DLT-RTE	SNEX	E2657	DLT-RTE	The STP shall ensure that the ORDERED ROUTE entity set of the STP active data base already contains an entity with the destination.
DLT-RTE	IDNS	E2879	DLT-RTE	If the specified destination address is a full point code address (NI-NC-NCM) and is a member of a provisioned cluster (NI-NC-*), ordered routes assigned to it cannot be deleted if NCAI is specified as NO. If NCAI is specified as YES then the specified destination is a member of a provisioned nested cluster where the provisioned member ordered routes can be deleted. Deletion of provisioned member ordered routes will result in the provisioned member assuming the attributes of its cluster.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-RTE	IDNV	E2886	DLT-RTE	Destination address (DPC/da) must be a full or a cluster point code.
DLT-RTE	IDNV	E2955	DLT-RTE	Network Routing is only valid if the NRT feature is ON.
DLT-RTE	SEHW	E4379	DLT-RTE	Route Exception table not accessible.
DLT-RTE	IDNS	N/A	DLT-RTE	** and *** cannot be specified for the ncm field of destination address (da).
DLT-RTE	IDNS	N/A	DLT-RTE	** cannot be specified for the nc field of destination address (da).
DLT-RTE	IDNS	N/A	DLT-RTE	** cannot be specified for the ni field of destination address (da).
DLT-RTE	IDNS	N/A	DLT-RTE	A range of destination addresses (da) cannot be specified.
DLT-SCRAFTPC	IDNS		DLT-SCR-AFTPC	Ranges are not supported for SSN.
DLT-SCRAFTPC	IDNV		DLT-SCR-AFTPC	The screen reference must begin with an alpha character.
DLT-SCRAFTPC	IDNS	E2495	DLT-SCR-AFTPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
DLT-SCRAFTPC	GRES	E2498	DLT-SCR-AFTPC	No AFTPC screening reference can be deleted which is referenced by an entity in another screening set.
DLT-SCRAFTPC	GCLI	E2511	DLT-SCR-AFTPC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRAFTPC	GCMII	E2512	DLT-SCR-AFTPC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRAFTPC	IDNS	E2556	DLT-SCR-AFTPC	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRAFTPC	GNEX	E2559	DLT-SCR-AFTPC	The AFTPC or AFTPC range defined by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC must already exist in the screening reference.
DLT-SCRAFTPC	IDRE	E2564	DLT-SCR-AFTPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRAFTPC	IDNS	N/A	DLT-SCR-AFTPC	A specific SSN must be specified in the range (1-255, *).
DLT-SCRBLKDPC	IDNV		DLT-SCR-BLKD PC	The screen reference must begin with an alpha character.
DLT-SCRBLKDPC	IDNS	E2136	DLT-SCR-BLKD PC	At least one optional parameter must be specified.
DLT-SCRBLKDPC	IDNS	E2485	DLT-SCR-BLKD PC	If NI = C, NC and NCM must either be C or not entered. If ZONE = C, AREA and ID must either be C or not entered. If MSA = C, SSA and SP must either be C or not entered. In all cases if C for "continue" is entered for the first parameter the other parameters will default to C in the database.
DLT-SCRBLKDPC	GREF	E2496	DLT-SCR-BLKD PC	Point code to delete cannot be C-C-C because there is another point code in this blocked screen reference. The last screen reference to be deleted, must have either NI, ZONE, MSA, or NPC equal to 'C'.
DLT-SCRBLKDPC	GREF	E2498	DLT-SCR-BLKD PC	The last entry deleted may not be referenced by another screening entry.
DLT-SCRBLKDPC	GCLI	E2511	DLT-SCR-BLKD PC	Point codes specified by NI-NC-NCM or NNI-NNC-NNCM must be valid.
DLT-SCRBLKDPC	GCFI	E2512	DLT-SCR-BLKD PC	Point codes specified by NI-NC-NCM or NNI-NNC-NNCM must be valid.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRBLKDPC	IDNS	E2556	DLT-SCR-BLKD PC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
DLT-SCRBLKDPC	IDNS	E2564	DLT-SCR-BLKD PC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRBLKDPC	GNEX	E3272	DLT-SCR-BLKD PC	The blocked DPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be deleted from the BLKDPC screen for the blocked DPC screening reference must already exist in that BLKDPC screen.
DLT-SCRBLKDPC	IPNS	N/A	DLT-SCR-BLKD PC	The Supplier Specific Parameter is not supported.
DLT-SCRBLKOPC	IDNV		DLT-SCR-BLKO PC	The screen reference must begin with an alpha character.
DLT-SCRBLKOPC	IDNS	E2485	DLT-SCR-BLKO PC	If NI = C, NC and NCM must either be C or not entered. If ZONE = C, AREA and ID must either be C or not entered. If MSA = C, SSA and SP must either be C or not entered. In all cases if C for "continue" is entered for the first parameter the other parameters will default to C in the database.
DLT-SCRBLKOPC	GRES	E2496	DLT-SCR-BLKO PC	The last screen reference to be deleted, must have either NI, ZONE, MSA, or NPC equal to 'C'. Point code to delete cannot be C-C-C because there is another point code in this blocked screen reference.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRBLKOPC	GRES	E2498	DLT-SCR-BLKO PC	The last entry deleted may not be referenced by another screening entry.
DLT-SCRBLKOPC	GCLI	E2511	DLT-SCR-BLKO PC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRBLKOPC	GCMJ	E2512	DLT-SCR-BLKO PC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRBLKOPC	IDNS	E2556	DLT-SCR-BLKO PC	A complete point code must be entered, i.e. ‘**’ may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: ‘**’ in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for “continue” in commands that allow it.
DLT-SCRBLKOPC	IDNS	E2564	DLT-SCR-BLKO PC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRBLKOPC	GNEX	E3272	DLT-SCR-BLKO PC	The blocked OPC or range of OPC’s, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be deleted from the BLKOPC screen for the blocked OPC screening reference must already exist in that BLKOPC screen.
DLT-SCRBLKOPC	IPNS	N/A	DLT-SCR-BLKO PC	The Supplier Specific Parameter is not supported.
DLT-SCRCDDPA	IDNS		DLT-SCR-CDPA	Ranges are not supported for SSN.
DLT-SCRCDDPA	IDNV		DLT-SCR-CDPA	The screen reference must begin with an alpha character.
DLT-SCRCDDPA	GRES	E2498	DLT-SCR-CDPA	No CDPA screening reference can be deleted which is referenced by an entity in another screening set.
DLT-SCRCDDPA	GFII	E2508	DLT-SCR-CDPA	If SSN is not equal to 1, the SCMG format identifier must be NULL.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRCDDPA	GFII	E2508	DLT-SCR-CDPA	The SCMGID parameter must be specified for SSN=1.
DLT-SCRCDDPA	GCLI	E2511	DLT-SCR-CDPA	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRCDDPA	GCMII	E2512	DLT-SCR-CDPA	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRCDDPA	GNEX	E2517	DLT-SCR-CDPA	The CDPA PC, SCMGFID and subsystem number(s) to be changed or deleted must exist in the CDPA entity set.
DLT-SCRCDDPA	IDNS	E2556	DLT-SCR-CDPA	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.
DLT-SCRCDDPA	GNII	E2564	DLT-SCR-CDPA	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRCDDPA	GNEX	E2573	DLT-SCR-CDPA	The SR must already exist.
DLT-SCRCDDPA	IDNS	N/A	DLT-SCR-CDPA	*** is not supported for the SCMGFID parameter.
DLT-SCRCGPA	IDNS		DLT-SCR-CGPA	Ranges are not supported for SSN.
DLT-SCRCGPA	IDNV		DLT-SCR-CGPA	The screen reference must begin with an alpha character.
DLT-SCRCGPA	GREF	E2498	DLT-SCR-CGPA	No CGPA screening reference can be deleted which is referenced by an entity in another screening set.
DLT-SCRCGPA	GCLI	E2511	DLT-SCR-CGPA	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRCGPA	GCMII	E2512	DLT-SCR-CGPA	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRCGPA	GNEX	E2515	DLT-SCR-CGPA	The CGPA PC, RI, SCCPMT and subsystem number to be deleted must exist in the CGPA entity set.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRCGPA	IDNS	E2556	DLT-SCR-CGPA	A complete point code must be entered using one and only one of the four point code types represented by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC.
DLT-SCRCGPA	IDRE	E2564	DLT-SCR-CGPA	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRCGPA	GNEX	E2573	DLT-SCR-CGPA	The SR must already exist.
DLT-SCRCGPA	IDNS	N/A	DLT-SCR-CGPA	A specific RI must be specified in the range (*, GT, DPC).
DLT-SCRCGPA	IDNS	N/A	DLT-SCR-CGPA	A specific SSN must be specified in the range (*,1-255).
DLT-SCRCGPA	IPNS	N/A	DLT-SCR-CGPA	The linkset group identifier parameter is not supported.
DLT-SCRDESTFLD	IDNV		DLT-SCR-DESTFLD	The screen reference must begin with an alpha character.
DLT-SCRDESTFLD	IDNS	E2495	DLT-SCR-DESTFLD	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
DLT-SCRDESTFLD	REF	E2498	DLT-SCR-DESTFLD	If only one entry exists, the SR must not be referenced by another screening table, otherwise, the entire screening table is deleted.
DLT-SCRDESTFLD	GCLI	E2511	DLT-SCR-DESTFLD	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
DLT-SCRDESTFLD	GCM I	E2512	DLT-SCR-DESTFLD	Point codes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRDESTFLD	IDNV	E2527	DLT-SCR-DESTFLD	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
DLT-SCRDESTFLD	IDNS	E2556	DLT-SCR-DESTFLD	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
DLT-SCRDESTFLD	GNII	E2564	DLT-SCR-DESTFLD	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRDESTFLD	GNEX	E3272	DLT-SCR-DESTFLD	The DESTFLD, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be deleted from the DESTFLD entity set for the DESTFLD screening reference must already exist in that DESTFLD screen.
DLT-SCRDESTFLD	IPNS	N/A	DLT-SCR-DESTFLD	The Supplier Specific Parameter is not supported.
DLT-SCRDPC	IDNV		DLT-SCR-DPC	The screen reference must begin with an alpha character.
DLT-SCRDPC	GRAF	E2498	DLT-SCR-DPC	If only one entry exists, the SR must not be referenced by another screening table, otherwise, the entire screening table is deleted.
DLT-SCRDPC	GCLI	E2511	DLT-SCR-DPC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCRDPC	GCMII	E2512	DLT-SCR-DPC	Point codes specified by NI-NC-NCM must be valid.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCRDPC	IDNV	E2527	DLT-SCR-DPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
DLT-SCRDPC	IDNS	E2556	DLT-SCR-DPC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
DLT-SCRDPC	GNII	E2564	DLT-SCR-DPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
DLT-SCRDPC	GNEX	E3272	DLT-SCR-DPC	The DPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be deleted from the DPC entity set for the DPC screening reference must already exist in that DPC screen.
DLT-SCRDPC	IPNS	N/A	DLT-SCR-DPC	The Supplier Specific Parameter is not supported.
DLT-SCR-ISUP	IDNV	E2041	DLT-SCR-ISUP	The screen reference must begin with an alpha character.
DLT-SCR-ISUP	IDRE	E2060	DLT-SCR-ISUP	Low bound exceeds upper bound of range – ISUPMT/TUPMT. SEAS is not applicable for TUP.
DLT-SCR-ISUP	GREF	E2498	DLT-SCR-ISUP	Last entry in given SR is referenced by another screen.
DLT-SCR-ISUP	GNEX*	E2520	DLT-SCR-ISUP	ISUPMT/TUPMT does not exist in given SR.
DLT-SCR-ISUP	GNEX	E2573	DLT-SCR-ISUP	The SR must exist.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCR-ISUP	IDNV	E3303	DLT-SCR-ISUP	SEAS only: VALUE 'x' FOR <> PARAMETER IS NOT VALID.
DLT-SCR-ISUP	IDRE	E3306	DLT-SCR-ISUP	SEAS only: VALUE 'x' OUT OF RANGE FOR <> PARAMETER.
DLT-SCR-ISUP	IPMS	E3322	DLT-SCR-ISUP	SEAS only: INPUT PARAMETER <> MISSING.
DLT-SCR-ISUP	IDNV	E3506	DLT-SCR-ISUP	ISUP Message Type must be valid (SEAS only).
DLT-SCROPC	IDNV		DLT-SCR-OPC	The screen reference must begin with an alpha character.
DLT-SCROPC	GRES	E2498	DLT-SCR-OPC	If only one entry exists, the SR must not be referenced by another screening table, otherwise, the entire screening table is deleted.
DLT-SCROPC	GCLI	E2511	DLT-SCR-OPC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCROPC	GCMII	E2512	DLT-SCR-OPC	Point codes specified by NI-NC-NCM must be valid.
DLT-SCROPC	IDNV	E2527	DLT-SCR-OPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
DLT-SCROPC	IDNS	E2556	DLT-SCR-OPC	A complete point code must be entered, i.e. '**' may not be used for any of the parameters NI, NC or NCM in the case of SEAS commands. NOTE: '**' in SEAS is the same as not specifying the parameter in the EAGLE syntax. For EAGLE commands, a complete point code must be entered in the form NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC except in the special case of entering C for "continue" in commands that allow it.
DLT-SCROPC	GNII	E2564	DLT-SCR-OPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCROPC	GNEX	E3272	DLT-SCR-OPC	The OPC, given by NI-NC-NCM, ZONE-AREA-ID, MSA-SSA-SP, or NPC to be deleted from the OPC screen for the OPC screening reference must already exist in that OPC screen.
DLT-SCROPC	IPNS	N/A	DLT-SCR-OPC	The Supplier Specific Parameter is not supported.
DLT-SCRSIO	IDNV		DLT-SCR-SIO	The screen reference must begin with an alpha character.
DLT-SCRSIO	IDRE		DLT-SCR-SIO	Heading codes must be in the range (*, *,0..15).
DLT-SCRSIO	IDRE		DLT-SCR-SIO	Message Priority must be in the range (*,0..3) or n1&&n2 where n1 and n2 are in the range 0-3 and n1 < n2.
DLT-SCRSIO	IDRE		DLT-SCR-SIO	The Network Indicator Code must be in the range (*, 0..3).
DLT-SCRSIO	GHCI	E2393	DLT-SCR-SIO	If H0 is asterisk, H1 must be asterisk or not specified.
DLT-SCRSIO	GHCI	E2488	DLT-SCR-SIO	H0 and H1 must be specified if SI is less than or equal 2.
DLT-SCRSIO	GHCI	E2490	DLT-SCR-SIO	For screening entries containing SI>2, H0 and H1, must not be specified.
DLT-SCRSIO	GREF	E2498	DLT-SCR-SIO	The SIO entry to be deleted can not be referenced by another screening reference.
DLT-SCRSIO	GNEX	E2569	DLT-SCR-SIO	The current network indicator code, service indicator, priority(s), and heading codes to be changed must exist.
DLT-SCRSIO	GNEX	E2573	DLT-SCR-SIO	The SR must already exist.
DLT-SCRSIO	GHCI	E3269	DLT-SCR-SIO	H1 must not be NULL if H0 is not NULL.
DLT-SCRSIO	IDNS	N/A	DLT-SCR-SIO	A specific PRI or range of PRIs must be specified.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
DLT-SCR TT	IDNV		DLT-SCR-TT	The screen reference must begin with an alpha character.
DLT-SCR TT	GRAF	E2498	DLT-SCR-TT	The Translation type to be deleted can not be referenced by another screening reference.
DLT-SCR TT	GNEX	E2573	DLT-SCR-TT	The SR must already exist.
DLT-SCR TT	GNEX	E2574	DLT-SCR-TT	The current translation type value or range must exist.
DLT-SCR TT	IDNS	N/A	DLT-SCR-TT	The current translation type must be specified and can not be NULL or **.
ENT-SCR-ISUP	IDNV	E2041	ENT-SCR-ISUP	The screen reference must begin with an alpha character.
ENT-SCR-ISUP	IDRE	E2060	ENT-SCR-ISUP	Low bound exceeds upper bound of range - ISUPMT/TUPMT. SEAS is not applicable for TUP.
ENT-SCR-ISUP	GAEX*	E2519	ENT-SCR-ISUP	ISUPMT/TUPMT already exists in given SR.
ENT-SCR-ISUP	GNFI	E2548	ENT-SCR-ISUP	NSFI must be equal to STOP, if specified.
ENT-SCR-ISUP	GNSR	E2554	ENT-SCR-ISUP	NSR can not be specified if the NSFI is STOP.
ENT-SCR-ISUP	GNFI	E3271	ENT-SCR-ISUP	NSFI is invalid.
ENT-SCR-ISUP	IDNV	E3303	ENT-SCR-ISUP	SEAS only: VALUE 'x' FOR <> PARAMETER IS NOT VALID.
ENT-SCR-ISUP	IDRE	E3306	ENT-SCR-ISUP	SEAS only: VALUE 'x' OUT OF RANGE FOR <> PARAMETER.
ENT-SCR-ISUP	IPMS	E3322	ENT-SCR-ISUP	SEAS only: INPUT PARAMETER <> MISSING.
ENT-SCR-ISUP	IPNS	E3324	ENT-SCR-ISUP	SEAS only: INPUT PARAMETER - USE OF PARAMETER NOT SUPPORTED BY THIS IMPLEMENTATION(The supplier specific parameter 'z' is not supported).
RTRV-GTWY-ACT HRESH	SEHW	E2122	RTRV-GTWY-A CTHRESH	Link set table not accessible.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
RTRV-GTWY-ACTHRESH	LSNX	E2346	RTRV-GTWY-ACTHRESH	The STP must validate that the linkset specified already exists in the STP active database.
RTRV-GTWY-ACTHRESH	LSNL	E2928	RTRV-GTWY-ACTHRESH	The STP must validate that the linkset is in the Gateway linkset entity set of the requesting system.
RTRV-GTWY-ACTHRESH	SEHW	E2942	RTRV-GTWY-ACTHRESH	Extended-Link set table not accessible.
RTRV-GTWY-PRMTRS	SEHW	E2943	RTRV-GTWY-PRMTRS	Extended-STP Options table not accessible.
RTRV-LNP-DBTS	RL	E2109	RTRV-LNP-DBTS	If in duplex mode, the active and standby current database levels must be equivalent.
RTRV-LNP-DBTS	RL	E2109	RTRV-LNP-DBTS	The active and standby (if available) current databases must be coherent.
RTRV-LNP-DBTS	RL	E2109	RTRV-LNP-DBTS	The active OAM must have established itself as being in duplex or simplex mode.
RTRV-LNP-DBTS	CCUN	E3009	RTRV-LNP-DBTS	The LNP feature must be enabled prior to using this command.
RTRV-SCR-ISUP	IDNV	E2041	RTRV-SCR-ISUP	The screen reference must begin with an alpha character.
RTRV-SCR-ISUP	IDRE	E2060	RTRV-SCR-ISUP	Low bound exceeds upper bound of range - ISUPMT/TUPMT. SEAS is not applicable for TUP.
RTRV-SCR-ISUP	GNSR	E2554	RTRV-SCR-ISUP	NSR can not be specified if NSFI is specified as STOP.
RTRV-SCR-ISUP	GNEX	E2573	RTRV-SCR-ISUP	If the SR is specified it must exist.
RTRV-SCR-ISUP	GNFI	E3271	RTRV-SCR-ISUP	NSFI must be valid.
RTRV-SCR-ISUP	IDNV	E3303	RTRV-SCR-ISUP	SEAS only: VALUE 'x' FOR <> PARAMETER IS NOT VALID.
RTRV-SCR-ISUP	IDRE	E3306	RTRV-SCR-ISUP	SEAS only: VALUE 'x' OUT OF RANGE FOR <> PARAMETER.
RTRV-SCR-ISUP	IPMS	E3322	RTRV-SCR-ISUP	SEAS only: INPUT PARAMETER <> MISSING.
SET-GTWY-ACTHRESH	GENV		SET-GTWY-ACTHRESH	INTRVL argument - not valid (eg. not numeric).

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
SET-GTWY-ACTH RESH	GMNV		SET-GTWY-ACT HRESH	RECV argument - not valid (eg. not numeric).
SET-GTWY-ACTH RESH	GRNV		SET-GTWY-ACT HRESH	REJ argument - not valid (eg. not numeric).
SET-GTWY-ACTH RESH	LSNV		SET-GTWY-ACT HRESH	LSN argument - not valid (eg. Wrong # of characters in string).
SET-GTWY-ACTH RESH	SEHW	E2122	SET-GTWY-ACT HRESH	Linkset table not accessible.
SET-GTWY-ACTH RESH	GRMS	E2136	SET-GTWY-ACT HRESH	At least one optional parameter is required.
SET-GTWY-ACTH RESH	LSNX	E2346	SET-GTWY-ACT HRESH	The STP must validate that the linkset specified already exists in the STP active database.
SET-GTWY-ACTH RESH	LSNL	E2928	SET-GTWY-ACT HRESH	The STP must validate that the linkset is in the Gateway linkset entity set of the requesting system.
SET-GTWY-ACTH RESH	SEHW	E2942	SET-GTWY-ACT HRESH	Extended linkset table not accessible.
SET-GTWY-ACTH RESH	GENV	E2944	SET-GTWY-ACT HRESH	INTRVL argument - valid type, but invalid possible value.
SET-SCRREJ-PRMT RS	GNNV		SET-SCRREJ-PR MTRS	LIMIT argument - not valid (ie. not numeric).
SET-SCRREJ-PRMT RS	GTNV		SET-SCRREJ-PR MTRS	INTRVL argument - not valid (ie. not numeric).
SET-SCRREJ-PRMT RS	SEHW	E2943	SET-SCRREJ-PR MTRS	Extended-STP Options table not accessible.
SET-SCRREJ-PRMT RS	IDRE	E2944	SET-SCRREJ-PR MTRS	INTRVL argument - valid type, but invalid possible value.
VFY-DSTN	SEHW	E2648	RTRV-DSTN	Route table not accessible.
VFY-DSTN	SNEX	E2657	RTRV-DSTN	The STP shall ensure that the destination address specified is defined in the STP's active DESTINATION entity set.
VFY-DSTN	IDNS	E2855	RTRV-DSTN	CRMD feature must be on so that Cluster destination point codes are valid.
VFY-DSTN	SEHW	E2874	RTRV-DSTN	The Site ID table not accessible.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-DSTN	IDNS	E2882	RTRV-DSTN	The MSAR=ONLY must be specified exclusively.
VFY-DSTN	IDNV	E2955	RTRV-DSTN	Network Routing is only valid if the NRT feature is ON.
VFY-GTT	IDNS	E2169	RTRV-GTT	If the system is defined as an ANSI system, the Translated Point Code must be a valid ANSI point code.
VFY-GTT	IDRE	E2169	RTRV-GTA	Point Code must not be out of range.
VFY-GTT	IDNS	E2403	RTRV-GTA	If EGTA is specified, GTA and EGTA must be the same length.
VFY-GTT	IDNS	E2403	RTRV-GTT	If a range of GTAs is specified, the endpoint values must be of the same length.
VFY-GTT	<NF>	E2405	RTRV-GTA	The specified GTA range must exist for the specified GTT Set in the STP active data base (note that an exact match is not required, however, overlap with another range is not allowed).
VFY-GTT	<NF>	E2405	RTRV-GTT	The specified GTA must exist in an existing range.
VFY-GTT	IDNV	E2409	RTRV-GTA	If EGTA is specified, GTA must be specified.
VFY-GTT	IDNV	E2409	RTRV-GTT	The GTA parameter must be specified when the EGTA parameter is specified.
VFY-GTT	IDNC	E2420	RTRV-GTA	If EGTA is specified, EGTA must be greater than GTA.
VFY-GTT	IDNC	E2420	RTRV-GTT	If a range of GTAs is specified, the end of range value must be greater than the start of range value.
VFY-GTT	IDNS	E2465	RTRV-GTA	The Translation Type must not be defined as an alias.
VFY-GTT	IDNS	E2465	RTRV-GTT	The specified Translation Type must not be defined as an alias.
VFY-GTT	<NF>	E2466	RTRV-GTA	The Translation Type must match that of an existing ANSI GTT Selector.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-GTT	<NF>	E2466	RTRV-GTT	The specified Translation Type must exist.
VFY-GTT	IDNS	E2470	RTRV-GTT	The Translation Type network type and the Translated Point Code network type must match.
VFY-GTT	IPMS	E2475	RTRV-GTT	Either TYPE or TTN must be specified.
VFY-GTT	IDNV	E2859	RTRV-GTA	PC/PCA/PCI/PCN/PCN24 must be a full point code.
VFY-GTT	IDNV	E2859	RTRV-GTT	Translated Point Code must be a full point code.
VFY-GTT	SEHW	E3119	RTRV-GTA	GTA table not accessible.
VFY-GTT	SEHW	E3120	RTRV-GTA	GTT DBMM table not accessible.
VFY-GTT	SEHW	E3543	RTRV-GTA	GTT Selector table not accessible.
VFY-GTT	SEHW	E3544	RTRV-GTA	GTT Set table not accessible.
VFY-GTT	IDNS	E3570	RTRV-GTA	If the specified GTT Set is an ANSI set, PC/PCA must be a valid ANSI point code.
VFY-GTT	IDNS	E3571	RTRV-GTA	The length of the specified GTA must match the number of digits provisioned for the specified GTT Set referenced by SNAME.
VFY-GTT	IDNV	N/A	RTRV-GTA	Alpha characters may not be specified for GTA.
VFY-GTWYLS	IPMS	N/A	VFY-GTWYLS	A linkset name or "***" must be specified for parameter ls.
VFY-GTWYLS	NF	N/A	VFY-GTWYLS	If a linkset name is specified then the linkset must exist and be configured as a SEAS Gateway Linkset.
VFY-GTWYLS	NF	N/A	VFY-GTWYLS	If all Gateway Linksets are requested by specifying the "***" value for the linkset name, then one or more Gateway Linksets must exist.
VFY-LS	SEHW	E2122	RTRV-LS	Linkset table not accessible.
VFY-LS	NF Case	E2346	RTRV-LS	The specified linkset must exist in the STP active database.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-MAP	<NF>	E2452	RTRV-MAP	Remote point code does not exist in MAP table.
VFY-MAP	<NF>	E2456	RTRV-MAP	SSN does not exist for given remote point code.
VFY-MAP	SEHW	E2874	RTRV-MAP	STP site ID table not accessible.
VFY-RTE	SEHW	E2111	RTRV-RTE	The database must be consistent.
VFY-RTE	SEHW	E2122	RTRV-RTE	Link set table not accessible.
VFY-RTE	SNEX	E2346	RTRV-RTE	All link sets must be defined in the route set.
VFY-RTE	IDNS	E2357	RTRV-RTE	All link sets currently assigned to a route set must still be equipped.
VFY-RTE	SEHW	E2648	RTRV-RTE	Route table not accessible.
VFY-RTE	SNEX	E2657	RTRV-RTE	The STP shall validate the command instructions and ensure that the target destination already exists in the DESTINATION entity set.
VFY-RTE	SEHW	E2874	RTRV-RTE	The Site ID table not accessible.
VFY-RTE	IDNV	E2886	RTRV-RTE	Destination address (DPC/da) must be a full or a cluster point code.
VFY-RTE	IDNV	E2955	RTRV-RTE	Network Routing is only valid if the NRT feature is ON.
VFY-SCRAFTPC	IDNS		RTRV-SCR-AFTP C	Ranges are not supported for SSN.
VFY-SCRAFTPC	IDNV		RTRV-SCR-AFTP C	The screen reference must begin with an alpha character.
VFY-SCRAFTPC	IDNS	E2495	RTRV-SCR-AFTP C	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCRAFTPC	GCLI	E2511	RTRV-SCR-AFTP C	Point codes specified by NI-NC-NCM must be valid.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SCRAFTPC	GCM I	E2512	RTRV-SCR-AFTP C	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRAFTPC	IDNV	E2527	RTRV-SCR-AFTP C	NI, NC, NCM, ZONE, AREA, ID, MSA, SSA, SP, or NPC can not have the Value C.
VFY-SCRAFTPC	IDNS	E2564	RTRV-SCR-AFTP C	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
VFY-SCRAFTPC	NF case	E2573	RTRV-SCR-AFTP C	If the SR is specified then it must exist in the AFTP entity set.
VFY-SCRBLKDPC	IDNV		RTRV-SCR-BLK DPC	The screen reference must begin with an alpha character.
VFY-SCRBLKDPC	IDNS	E2485	RTRV-SCR-BLK DPC	If NI = C, NC and NCM must either be C or not entered. If ZONE = C, AREA and ID must either be C or not entered. If MSA = C, SSA and SP must either be C or not entered. In all cases if C for "continue" is entered for the first parameter the other parameters will default to C in the database.
VFY-SCRBLKDPC	IDNS	E2495	RTRV-SCR-BLK DPC	If NI is specified as asterisk, NC and NCM must also be asterisk. If NC is specified or re-specified as asterisk, NCM must also be asterisk. If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCRBLKDPC	GCLI	E2511	RTRV-SCR-BLK DPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRBLKDPC	GCM I	E2512	RTRV-SCR-BLK DPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRBLKDPC	IDNS	E2564	RTRV-SCR-BLK DPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SCRBLKDPC	NF case	E2573	RTRV-SCR-BLK DPC	If the SR is specified then it must exist.
VFY-SCRBLKOPC	IDNV		RTRV-SCR-BLK OPC	The screen reference must begin with an alpha character if specified.
VFY-SCRBLKOPC	IDNS	E2485	RTRV-SCR-BLK OPC	If NI = C, NC and NCM must either be C or not entered. If ZONE = C, AREA and ID must either be C or not entered. If MSA = C, SSA and SP must either be C or not entered. In all cases if C for "continue" is entered for the first parameter the other parameters will default to C in the database.
VFY-SCRBLKOPC	IDNS	E2495	RTRV-SCR-BLK OPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCRBLKOPC	GCLI	E2511	RTRV-SCR-BLK OPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRBLKOPC	GCM I	E2512	RTRV-SCR-BLK OPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRBLKOPC	IDNS	E2564	RTRV-SCR-BLK OPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0, are not allowed.
VFY-SCRBLKOPC	NF case	E2573	RTRV-SCR-BLK OPC	If the SR is specified then it must exist.
VFY-SCR-CDPA	IDNS		RTRV-SCR-CDP A	Ranges are not supported for SSN.
VFY-SCR-CDPA	IDNV		RTRV-SCR-CDP A	The screen reference must begin with an alpha character.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SCR-CDPA	IDNS	E2495	RTRV-SCR-CDP A	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCR-CDPA	GCLI	E2511	RTRV-SCR-CDP A	Point codes specified by NI-NC-NCM must be valid.
VFY-SCR-CDPA	GCM I	E2512	RTRV-SCR-CDP A	Point codes specified by NI-NC-NCM must be valid.
VFY-SCR-CDPA	IDNS	E2564	RTRV-SCR-CDP A	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
VFY-SCR-CDPA	NF case	E2573	RTRV-SCR-CDP A	If the SR is specified then it must exist in the AFTPC entity set.
VFY-SCR-CDPA	GNFI	E3271	RTRV-SCR-CDP A	The NSFI must be valid for CDPA screens.
VFY-SCRCGPA	IDNS		RTRV-SCR-CGP A	Ranges are not supported for the SSN parameter.
VFY-SCRCGPA	IDNV		RTRV-SCR-CGP A	The screen reference must begin with an alpha character.
VFY-SCRCGPA	IDNS	E2495	RTRV-SCR-CGP A	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCRCGPA	GCLI	E2511	RTRV-SCR-CGP A	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRCGPA	GCM I	E2512	RTRV-SCR-CGP A	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRCGPA	IDNS	E2564	RTRV-SCR-CGP A	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SCRCGPA	NF case	E2573	RTRV-SCR-CGP A	If the SR is specified then it must exist.
VFY-SCRCGPA	IPNS	N/A	RTRV-SCR-CGP A	Linkset Group Identifier is not supported.
VFY-SCRDESTFLD	IDNV		RTRV-SCR-DEST FLD	The screen reference must begin with an alpha character.
VFY-SCRDESTFLD	IDNS	E2495	RTRV-SCR-DEST FLD	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCRDESTFLD	GCLI	E2511	RTRV-SCR-DEST FLD	Pointcodes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
VFY-SCRDESTFLD	GCM I	E2512	RTRV-SCR-DEST FLD	Pointcodes specified by NI-NC-NCM and NNI-NNC-NNCM must be valid.
VFY-SCRDESTFLD	IDNV	E2527	RTRV-SCR-DEST FLD	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
VFY-SCRDESTFLD	GNSR	E2554	RTRV-SCR-DEST FLD	NSR can not be specified.
VFY-SCRDESTFLD	IDNS	E2564	RTRV-SCR-DEST FLD	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
VFY-SCRDESTFLD	NF case	E2573	RTRV-SCR-DEST FLD	If the SR is specified then it must exist.
VFY-SCRDESTFLD	GNFI	E3271	RTRV-SCR-DEST FLD	NSFI must be STOP if specified.
VFY-SCRDESTFLD	N/A	E3657	RTRV-SCR-DEST FLD	NSR can not be specified if ACTNAME is specified.
VFY-SCRDPC	IDNV		RTRV-SCR-DPC	The screen reference must begin with an alpha character.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SCRDPC	IDNS	E2495	RTRV-SCR-DPC	If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCRDPC	GCLI	E2511	RTRV-SCR-DPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRDPC	GCM I	E2512	RTRV-SCR-DPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCRDPC	IDNV	E2527	RTRV-SCR-DPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
VFY-SCRDPC	IDNS	E2564	RTRV-SCR-DPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
VFY-SCRDPC	NF case	E2573	RTRV-SCR-DPC	If the SR is specified then it must exist.
VFY-SCROPC	IDNV		RTRV-SCR-OPC	The screen reference must begin with an alpha character.
VFY-SCROPC	IDNS	E2495	RTRV-SCR-OPC	If NI is specified as asterisk, NC and NCM must also be asterisk. If NC is specified or re-specified as asterisk, NCM must also be asterisk. If ZONE is specified or re-specified as asterisk, AREA and ID must also be asterisk. If AREA is specified or re-specified as asterisk, ID must also be asterisk. If MSA is specified or re-specified as asterisk, SSA and SP must also be asterisk. If SSA is specified or re-specified as asterisk, SP must also be asterisk.
VFY-SCROPC	GCLI	E2511	RTRV-SCR-OPC	Point codes specified by NI-NC-NCM must be valid.

SEAS Error Messages

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SCROPC	GCFI	E2512	RTRV-SCR-OPC	Point codes specified by NI-NC-NCM must be valid.
VFY-SCROPC	IDNV	E2527	RTRV-SCR-OPC	NNI, NNC, NNCM, NAREA, NZONE, NID, NMSA-NSSA-NSP, and NPC must not equal C, when changing a screening entry who's NSFI is equal to FAIL.
VFY-SCROPC	IDNS	E2564	RTRV-SCR-OPC	ANSI point code value 000-000-000, and ITU-International point code value 0-000-0 are not allowed.
VFY-SCROPC	NF case	E2573	RTRV-SCR-OPC	If the SR is specified then it must exist.
VFY-SCRSIO	IDNV		RTRV-SCR-SIO	The screen reference must begin with an alpha character.
VFY-SCRSIO	NF case	E2573	RTRV-SCR-SIO	If the SR is specified then it must exist in the SIO entity set.
VFY-SCRSIO	GNFI	E3271	RTRV-SCR-SIO	The NSFI must be valid for SIO screens.
VFY-SCRSIO	IDNS	N/A	RTRV-SCR-SIO	Ranges are not supported for the SI, or NIC parameters.
VFY-SCR TT	IDNV		RTRV-SCR-TT	The screen reference must begin with an alpha character.
VFY-SCR TT	GNSR	E2554	RTRV-SCR-TT	NSR can not be specified if NSFI is specified as STOP.
VFY-SCR TT	GNFI	E3271	RTRV-SCR-TT	If NSFI is specified, it must be valid for TT screens.
VFY-SID	SEHW	E2145	RTRV-SID	STP MAS Configuration table not accessible.
VFY-SID	IDRE	E2340	RTRV-SID	STP capability point code must be a valid point code (i.e. 0-0-0).
VFY-SID	IDNV	E2861	RTRV-SID	STP destination and capability point codes can only be retrieved as full point codes.
VFY-SID	SEHW	E2874	RTRV-SID	STP site id table not accessible.
VFY-SLK	ENEQ	E2101	RTRV-SLK	If specified, card location must be equipped.
VFY-SLK	SEHW	E2102	RTRV-SLK	Card (IMT) table not accessible.

Table 3-1. SEAS Cross Reference Table (Continued)

SEAS Command	SEAS Error Code	System Error Code	System Command	Explanatory Text
VFY-SLK	SEHW	E2103	RTRV-SLK	Link table not accessible.
VFY-SLK	SEHW	E2122	RTRV-SLK	Linkset table not accessible.
VFY-SLK	IDRE	E2152	RTRV-SLK	If card location is specified, shelf location must be 11xx, 12xx, 13xx, 21xx, 22xx, 23xx, 31xx, 32xx, 33xx, 41xx, 42xx, 43xx, 51xx, 52xx, 53xx, or 61xx.
VFY-SLK	IDRE	E2153	RTRV-SLK	If specified, card location must be between 1..18 and not 9 or 10 .
VFY-SLK	IDRE	E2154	RTRV-SLK	If specified, card location must not be 1113..1118 .
VFY-SLK	ENEQ	E2292	RTRV-SLK	Card must be a lim .
VFY-SLK	IDNS	E2296	RTRV-SLK	Cannot specify a link without specifying a card location.
VFY-SLK	IDNS	E2586	RTRV-SLK	If card application is ss7gx25 , LINK must be A .
VFY-SLK	IDNS	E2976	RTRV-SLK	If specified link is A1, B1, A2, B2, A3 or B3 , card running must be - a Multi Port LIM, a MIM, or HC-MIM - a SSEDCM and APPL type iplim/iplimi .
VFY-SLK	IDNS	E3405	RTRV-SLK	If card application is atmansi or atmitu , link must be A .
VFY-SLK	IDNS	E3415	RTRV-SLK	loc and class cannot be specified together.
VFY-SLK	IDNS	E3494	RTRV-SLK	If specified link is A4, B4, ..., A31, B31 , card running must be HC-MIM - Links a4, b4, ..., a31, b31 is invalid parameter for channel card - Card running must be an HC-MIM if specified link is a4-a31 or b4-b31 .
VFY-SLK	IDNS	E3494	RTRV-SLK	Links a4, b4, ..., a31, b31 cannot be specified for even-numbered card location.
VFY-SLK	SESW	N/A	RTRV-SLK	Internal software errors must not occur.

A

Acronyms and Abbreviations

AAL	ATM Adaptation Layer
AAL5	ATM Adaptation Layer 5
AAL5CP	ATM Adaptation Layer 5 Common Port
AATM	ATM Applique
ACG	Automatic Call Gapping
ACM	Application Communications Module
ADJ DPC	Adjacent Destination Point Code
AI	Address Indicator
AIN	Advanced Intelligent Network
AINF	Application Interface Applique
AMI	Alternate Mark Inversion encoding
AP	Application Processor
APC	Adjacent Point Code
ARP	Address Resolution Protocol
AS	Application Server; a logical entity serving a specific Routing Key
ASP	Application Server Process
ATI	Any Time Interrogation
ATM	Asynchronous Transfer Mode
ATMANSI	Application software for the ATM (high-speed) SS7 signaling links

Acronyms and Abbreviations

ATM HSL	Asynchronous Transfer Mode High Speed Link
ATMM	ATM Layer Management
AVL	Availability Measurements report
AVLD	Daily Availability measurements report
AVLDTH	Day-to-Hour Availability measurements report
B8ZS	Bipolar with 8-Zero Substitution encoding
BIP	Board Identification PROM
BITS	Building Integrated Timing System
BLM	Bulk Load Module
BPHCAP	Application software used by the application processor and the IMT processor of the LIMATM
BPDCM	Application software for flash memory management on the DCM card.
BSN	Backward Sequence Number
CAS	Channel Associated Signaling
CCS	Common Channel Signaling
CCS7	Common Channel Signaling System #7
CCS7ITU	Application software for the ITU SS7 signaling links
CDPA	Called Party Address
CDSR	CDPA Screening Reference
CGPA	Calling Party Address
CGSR	CGPA Screening Reference
CF	Control Frame
CIC	Circuit Identification Code
CLLI	Common Language Location Identifier
CLU	Network Cluster
CM	Cluster Management
CNCF	Calling Name Conversion Facility
CP	Communication Processor

Acronyms and Abbreviations

CPC	Capability Point Code
CPU	Central Processing Unit
CRC	Cyclic Redundancy Check
CRMD	Cluster Routing and Management Diversity
CRP	Circular Route Prevention
CSPC	Concerned Signaling Point Code Group
CSU	Channel Service Unit
DB	Database
DCM	Database Communications Module
DEFCC	Default Country Code
DIP	Dual In-Line Package
DIX	Digital/Intel/Xerox de facto standard for Ethernet Media Access Control Type
DN	Dialed or Directory Number
DPC	Destination Point Code
DRAM	Dynamic Random Access Memory
DS0	Digital Signal Level - 0
DSM	Database Services Module
DSU	Data Service Unit
E5IS	Eagle 5 Integrated Sentinel
EBDA	Enhanced Bulk Download and Audit
EDR	Efficient Data Representation
EF	Extension Frame
EGMS	Enhanced GSM Map Screening
EGTT	Enhanced Global Title Translation
EIA	Electronic Industries Association
EILA	Enhanced Integrated LIM Applique
EIR	Equipment Identity Register
ELAP	Eagle LNP Application Processor

Acronyms and Abbreviations

EMDC	Element Measurement & Data Collection Application
EMAP	Eagle Measurements Application Processor
ENET	Ethernet
EOAM	Enhanced Operations, Administration, and Maintenance
EOAP	Enhanced OSS Application Process
EPAP	Eagle Provisioning Application Processor
EPROM	Erasable PROM
ESP	Extended Service Platform
FAP	Fuse and Alarm Panel
FAS	Frame Alignment Signal
FFGTLS	Flexible Final GTT Load-Sharing
FGTTLs	Flexible GTT Load-Sharing
FIGTTLs	Flexible Intermediate GTT Load-Sharing
FPCR	Full Point Code Routing
FSN	Forward Sequence Number
FTA	File Transfer Area
FTP	File Transfer Protocol
GDB	GSM Real-Time Database
G-Flex	GSM Flexible Numbering
G-Port	GSM Mobile Number Portability
GMS	GSM Map Screening
GMSC	Gateway MSC
GPL	Generic Program Load
GPSM	General Purpose Service Module
GSL	Generic Software Load
GSM	Global System for Mobile Communications
GTA	Global Title Address
GTI	Global Title Indicator

Acronyms and Abbreviations

GTT	Global Title Translation
GTWY	Gateway Administration measurements report
GWS	Gateway Screening
GWSA	Gateway Screening Application
GWSM	Gateway Screening Messages
HDB3	High Density Bipolar 3 encoding
HLR	Home Location Register
HMUX	High-Speed Multiplexer
HOMERN	Home Network Routing Number Prefix
HRN	Home Routing Number
HSL	High-Speed Link
IAM	Initial Address Message
IC	Integrated Circuit
ICMP	Internet Control Message Protocol
ID	Identity
IGTTLS	Intermediate GTT Load-Sharing
IL	Incremental loading
ILA	Integrated LIM Applique
IMEI	International Mobile Equipment Identity
IMSI	International Mobile Station Identifier
IMT	Interprocessor Message Transport
IN	Intelligent Network
INAP	Intelligent Network Application Part
INP	INAP-based Number Portability
INET	Internet
INH	Inhibit
IP	Internet Protocol
IPC	Internal Point Code

Acronyms and Abbreviations

IPS	Internet Protocol Services
IPSM	IP Services Module
IP7SG	IP ⁷ Secure Gateway
IPGWI	An ITU version of SS7IPGW
IPGWx	Point to multi-point IP Transport GPL, referring to SS7IPGW (ANSI) and IPGWI (ITU)
IPLIM	Application software used by the DCM card for TCP/IP point-to-point connectivity for ANSI point codes
IPLIMI	Application software used by the DCM card for TCP/IP point-to-point connectivity for ITU point codes
IPLIMx	Point-to-point IP Transport GPL, referring to IPLIM (ANSI) and IPLIMI (ITU)
IPMX	IMT Power and Multiplexer
IS-41	International Standard 41 (same as and interchangeable with ANSI-41)
IS-ANR	In Service - Abnormal
ISDN	Integrated Services Digital Network
IS-NR	In Service - Normal
ISUP	ISDN User Part
ITU	International Telecommunications Union
ITUDUPPC	ITU National Duplicate Point Code
JIP	Jurisdiction Indicator Parameter
LAN	Local Area Network
LB	Load Balancing
LBP	Loop Back Point
LC	Logical channel
LED	Light Emitting Diode
LFS	Link Fault Sectionalization
LIM	Link Interface Module
LIM-AINF	Link Interface Module with the AINF interface
LIM-ATM	LIM with ATM interface

Acronyms and Abbreviations

LIM-DS0	LIM with DS0 Applique
LIM-E1	LIM with E1 Applique
LIM-OCU	LIM with Office Channel Unit Applique
LIM-V35	LIM with V35 Interface
LNP	Local Number Portability
LNP MR	LNP Message Relay
LNP QS	LNP Query Service
LNP SMS	LNP Short Message Service
LPE	Logical Processing Element
LRN	Location Routing Number
LS	Link Set
LSB	Least Significant Bit (bit 1)
LSL	Low-Speed Link, used when referring to a 64 Kbps or 56 Kbps signaling link
LSMS	Local Service Management System
LSN	Link Set Name
LSSU	Link Status Signal Unit
MAAL	Management ATM Adaptation Layer
MAP	Mobile Application Part
MAPSCRN	GSM MAP Screening measurements report
MASP	Maintenance and Administration Subsystem Processor
MCAP	MAS Communication Application Processor Card
MCC	Mobile Country Code
MCM	Maintenance Communication Module
MCP	Measurement Collection Processor
MCPM	Measurement Collection and Polling Module
MDAL	Maintenance Disk and Alarm (card)
MDN	Mobile Dialed Number
MGT	Mobile Global Title
MGTT	Modified Global Title Translation

MF	Miscellaneous Frame
MIC	
MIM	Multi-Channel Interface Module
MIN	Mobile Identification Number
MNP	Mobile Number Portability
MNP-SRF	Signaling Relay Function for support of Mobile Number Portability
MO SMS	Portability Check for Mobile Originated SMS
MOBR	MTP Origin Based Routing
MPC	Multiple Point Code feature
MPL	Multi-port LIM
MPS	Multi-Purpose Server
MRN	(1) Message Reference Number, or (2) Mated Relay Node
MR	Message Relay
MSB	Most Significant Bit
MSC	Mobile Switching Center
MSAR	Memory Space Accounting Reporting
MSISDN	(1) Mobile Station ISDN Number, or (2) Mobile Switching ISDN Number
MSRN	Mobile Station Roaming Number
MSU	Message Signal Unit
MTC	Maintenance Daily measurements report
MTC	Maintenance Day-to-Hour measurements report
MTCH	Maintenance Hourly (marginal) measurements report
MTCS	Maintenance Status (link/link set) measurements report
MTP	Message Transfer Part
MTP2	Message Transfer Part, Level 2
NAI	Nature of Address Indicator
NCAI	Nested Cluster Allowed Indicator
NCR	Nested Cluster Routing

Acronyms and Abbreviations

NDC	Network Data Collection
NFAS	Non-Frame Alignment Signal
NGT	New Global Title Translation Type
NI	Network Indicator
NIC	Network Information Center
NID	Network Identification
NM	Network Management
NOC	
NP	Number Plan
NPA	Numbering Plan Area
NPAC	Number Portability Administration Center
NRT	Network Routing
NSAP	Network Service Access Point
NSFI	Next Screening Function Indicator
NSP	Network Services Part
NSPC	New Secondary Point Code
OAM	Operations, Administration, and Maintenance
OAP	Operation System Support Application Processor
OAMP	Operations, Administration and Maintenance Part
OCU	Office Channel Unit
OOS-MA	Out of Service - Memory Administration
OOS-MT	Out of Service - Maintenance
OOS-MT-DSBLD	Out of Service - Maintenance Disabled
OPC	Origination Point Code
OSI	Open Systems Interconnection
OSS	Operations Systems Support
PC	Point Code
PCR	Preventive Cyclic Retransmission

Acronyms and Abbreviations

PCS	Personal Communications Service (North American GSM)
PCST	Point Code Subtype
PDBA	Provisioning Database Application
PDN	Packet Data Network
PLNP	PCS 1900 LNP
PLNPQS	LNPQS support provided for PLNP
PPSMS	Prepaid Short Message Service Intercept
PROM	Programmable Read-Only Memory
PSEL	Presentation Selector
PST	Primary State for Maintenance
PSTN	Public Switched Telephone Network
PVC	Permanent Virtual Circuit
PVN	Private Virtual Network
Q3	Q.3 Protocol
RAM	Random Access Memory
RBASE	Record Base measurements report
RI	Routing Indicator
RFC	Request for Comments
RMC	Remote Maintenance Center
RMTP	Reliable Multicast Transport Protocol
RN	Routing Number
RTDB	DSM Real-time database
RTX	Exception Route
SAAL	Signaling ATM Adaptation Layer
SAPC	Secondary Adjacent Point Code
SBR	Subsystem Backup Routing (an SCCP management message)
SCCP	Signaling Connection Control Part

Acronyms and Abbreviations

SCMG	SCCP Management
SCP	Service Control Point
SCRSET	Screen Set
SCSI	Small Computer System Interface
SCTP	Stream Control Transmission Protocol
SE-SHL	Synchronous E1 High Speed Link
SEAS	Signaling Engineering and Administration System
SI	Service Indicator
SIB	Status Indication “Busy”
SIE	Status Indication “Emergency” Alignment
SIN	Status Indication “Normal Alignment”
SIO	Service Information Octet
SIO	Status Indication “Out of Alignment”
SIOS	Status Indication “Out of Service”
SLK	Signaling Link
SLS	Signaling Link Selection
SLSCI	Signaling Link Conversion Indicator
SLTM	Signaling Link Test Message
SMS	Short Message Service
SMSC	Short Message Service Center
SMSMR	SMS Message Relay
SNAI	Service Nature of Address Indicator
SNM	Signaling Network Management
SNR	(1) Service Numbering Plan, or (2) Subsystem Normal Routing (an SCCP management message)
SOG	Subsystem Out of Service Grant (an SCCP management message)
SOR	(1) Support for Optimal Routing, or (2) Subsystem Out of Service Request (an SCCP management message)
SP	Signaling Point
SPC	(1) Secondary Point Code, or (2) Signaling Point Code

SRF	Signaling Relay Function
SRI	Send Routing Information
SS7	Signaling System #7
SS7ANSI	Application software for the ANSI SS7 signaling links
SS7GX25	Application software for the X.25/SS7 gateway feature
SS7IPGW	Application software used by the DCM card for TCP/IP point-to-multipoint capability
SSA	Subsystem Allowed (An SCCP management message)
SSEL	Session Selector
SSN	SS7 Subsystem Number
SSP	Service Switching Point
SSU	Status Signal Unit
ST	Stop Digit—BCD value 15 (0xF), used to indicate the end of dialing for certain applications
STC	Sentinel Transport Transfer Card
STP	Signal Transfer Point
STP LAN	Application software for the STP LAN feature
SVC	Switched Virtual Circuit
SYSTOT	System Total measurements report
TCP	Transmission Control Protocol
TCAP	Transaction Capabilities Application Part
TDM	Terminal Disk Module
TF	Toll Free
TFC	Transfer Congestion
TFP	Transfer Prohibited
TFR	Transfer Restricted
TLNP	Triggerless LNP
TPC	True Point Code
TPS	Transactions Per Second
TRA	Traffic Restarting Allowed

Acronyms and Abbreviations

TRBL	Trouble
TRW	Traffic Restarting Waiting
TSC	Time Slot Counter Synchronization
TSM	Translation Services Module
TT	Translation Type
TUP	Telephone User Part (predecessor to ISUP protocol)
TV	Ticket Voucher
TVG	Group Ticket Voucher
UART	Universal Asynchronous Receiver - Transmit
UDP	User Datagram Protocol
UDTS	Unit Data Transfer Service
UI	User Interface
UID	User ID
UIM	Unsolicited Informational Message
UPD	Update
VGTT	Variable Length GTT
VLR	Visitor Location Register
VMSC	Voice Mail Service Center, or Visited Mobile Switching Center
VSCCP	VxWorks Signaling Connection Control Part
WNP	Wireless Number Portability
XUDT	Extended User Data
X.25 DE	X.25 Destination Entity

Acronyms and Abbreviations

Index

Symbols

- (N)CDSR already exists for specified CGSR, 2-786
- (N)CGSR already exists for specified OPNAME, 2-784
- (N)SERV must be GPORT/PPSMS/MNPSMS/EIR when (N)SNAI=CCRNDN, 2-681
- (N)SERV value is invalid for the specified (N)SNAI, 2-665
- (N)SNP must be E164 when (N)SERV=GPORT/PPSMS/MNPSMS, 2-679
- (N)SNP must be E164 when NSERV=INPMR, 2-665
- (N)SNP/(N)SNAI must not be specified when (N)SERV=INPQ/EIR, 2-667
- <device> is <condition>, 2-390
- <parm_desc> is out of range - <parm>, 2-7
- <parm_desc> is out of range, <min>...<max> - <parm>, 2-8
- <parm_desc> is out of range, <min>...<max>, '<char>' - <parm>, 2-8
- <parm_desc> is out of range, <min>...<max>, '<char>', '<char>' - <parm>, 2-9
- <parm_desc> num digits incorrect, min <min> max <max> - <parm>, 2-18
- <parm_desc> too long, min <min>, max <max>, - <parm>, 2-16
- <parm_desc> too short, min <min>, max <max>, - <parm>, 2-15
- <parm_desc> value is undefined - <parm>, 2-17
- <parm_desc> is out of range, <min>...<max> - <parm>, 2-23
- <reserved word> cannot be used in this command <reserved name> = reserved word, 2-414

Numerics

- 15-minute measurement collection in progress, 2-567
- 15-minute measurement feature must be on, 2-570
- 30-minute measurement collection in progress, 2-109
- 386/486 register cannot be specified, 2-296

- 5-minute measurement collection in progress, 2-109

A

- A complete point code must be entered, 2-223
- A GTT Set Name must be specified, 2-821
- A mated linkset cannot have more than one link assigned, 2-757
- A maximum of 8 PCs are allowed in a group, 2-331
- A problem occurred while trying to access the GWS database, 2-378
- A SEHSL feature key must be enabled to provision SEHSL, 2-780
- A specific NIC must be specified in the range (0-3), 2-233
- A specific SI must be specified in the range (0-15), 2-381
- A specific SSN must be specified in the range (1-255,*), 2-232
- A specified SI value must be 3 for SUA, 2-772
- A timeout occurred while processing SCSI Debug Command, 2-472
- A TTN-reserved service type name only if it matches SERV, 2-462
- ACCESS can only be specified with TYPE=P486-DATA, 2-287
- ACCESS parameter value is invalid for this card, 2-734
- ACTION and SRCLPSET must be specified together, 2-480
- ACTION must be specified as FORWARD, DUPLICATE, or DUPDISC, 2-430
- ACTION or FORBID parameter shouldn't be specified, 2-691
- Action requires either SAPC or MATELSN, not both, 2-759
- Action requires ICNP feature to be configured, 2-395
- Active device state does not permit database change, 2-581
- ACTIVE not available for type-enttype combination, 2-114
- Active OAM database is incoherent, 2-394
- Active OAM must be equipped with E586 hardware, 2-521
- Active TDM in unknown upgrade mode, 2-490

- Active/Stby GPL versions are not compatible, 2-600
- ACTNAME already exists in GWS Action Set Table, 2-562
- ACTNAME and ACTID cannot both be specified, 2-563
- ACTNAME specified must exist in the GWS Stop Action Set table, 2-558
- ADD/DROP mode provisioned FORCE=YES required, 2-513
- ADDR parameter is invalid for this card, 2-734
- Address (MPCx) of mate subsystem must be a full PC, 2-350
- Address (PCx) of primary subsystem must be a full PC, 2-350
- ADDTBLCNV and DELTBLCNV cannot be specified together, 2-881
- ADJ required if MPC/MSSN is given or MULT=DOM or SHR, 2-162
- Adjacent even numbered port has signaling link assigned, 2-512
- Alias already in use, 2-183
- Alias defined as a destination point code, 2-126
- Alias defined as translation type, 2-183
- Alias DPCs cannot be a member of a Network or Cluster, 2-355
- Alias is not assigned to SERV, 2-455
- Alias not assigned to translation name, 2-184
- Alias not assigned to translation type, 2-185
- Alias not defined, 2-127
- Alias PC table is full, 2-789
- Alias PCs are not valid for cluster destinations, 2-345
- Alias PCs exceed Max allowed for Feature Quantity, 2-779
- Alias type matches DPC type, 2-128
- ALL cannot be specified with a subsystem, 2-181
- All cards on shelf must be unequipped, 2-79
- All entered point code elements must be C if any are C, 2-192
- All links in linkset must have same IPLIML2 setting, 2-468
- All links of LSN must use same error correction method, 2-41
- All new PC parms must be null if NI, ZONE, MSA or NPC = C, 2-212
- ALL only qualifier allowed with given card type, 2-80
- All signaling links serviced by the E1 must be deactivated, 2-700
- All signaling links serviced by the T1 must be deactivated, 2-301
- All signaling links serviced by this E1/T1 must be deleted, 2-704
- All SUBNETID table entries must be of length SUBNETIDLEN, 2-805
- All VENDID table entries must be of length VENDIDLEN, 2-793
- ALL=YES cannot be specified with a point code, 2-178
- ALL=YES must be specified to delete all SSNs for a PC, 2-169
- ALL=YES must be specified to delete the entire group, 2-169
- Allow rejected terminal is not equipped, 2-177
- ALPHA+NUM+PUNC must not be greater than 12, 2-312
- Already in nodal isolation, 2-400
- Already logged on, 2-11
- Alternate bus must be IS-NR, 2-416
- An ACTNAME must be specified, 2-563
- An MIC of TYPE=ALL already exists, 2-425
- An MIC with the same service and digits already exists, 2-425
- AND parameter must be 6 or 10, 2-428
- ANSI PC is identical to ANSI CPC, 2-70
- ANSI PC parameters are invalid for ITU cards, 2-485
- ANSI site id not defined, 2-297
- ANSI/ITU point code type mismatch, 2-640
- APC cannot be of a different domain than previous, 2-241
- APC cannot be ref. by an X.25 route with LC2NM=YES, 2-264
- APC not defined as destination point code, 2-128
- APC/SAPC type and group code must match DPC, 2-550
- APC/SAPC with specified group code already exists for linkset, 2-724
- APCNTYPE parameter is only valid for ITUN/ITUN24 link sets, 2-778
- APPL is invalid for report or entity, 2-290
- APPL is invalid for specified PERIOD, 2-291
- APPL not valid for command, 2-577
- APPL or LOC parameter must be specified, 2-291
- APPL parameter must be specified with CONVERTNET action, 2-579
- APPL parameter valid only with CONVERTNET action, 2-583

Index

APPL=ALL can only be selected when
SERIAL=YES is specified, 2-599
Application already assigned, 2-453
Application Sockets on Port B Not
Allowed, 2-707
Application type not in LNP database, 2-453
Argument definition error, bad argument
type, 2-19
Argument frame overflow, 2-4
ARM register must be specified, 2-731
AS table is full, 2-719
AS/socket cannot be deleted while assigned to a
routing key, 2-709
ASL8 is only valid for ANSI link sets, 2-342
ASM/TSM Cards Cannot be Provisioned when
IDPS is Enabled, 2-869
Assigned SLKs must be deleted before apctype
can be changed, 2-819
Association connection parameters must be
unique, 2-713
Association in maximum allowed application
servers, 2-812
Association is still assigned to AS, 2-720
Association name already exists, 2-715
Association name not found, 2-716
At least one MCP card must be IS-NR, 2-571
At least one MCPM card must be configured in
system, 2-288
At least one Non-Key parm that is to be changed
is required, 2-737
At least one of TIMER, PARM, SRCSET must be
entered, 2-594
At least one optional parameter is
required, 2-47
At least one other optional parameter is
required, 2-762
At least one parameter must be changed, 2-36
At least one parameter must be changed(NSNP,
NSNAI, NSERV), 2-522
At least one point code must be specified, 2-873
At least TTA, TTI must be specified for a direction
of BOTH, 2-695
At least two ports must have security admin
authority, 2-318
At most two linksets can be assigned same
cost, 2-137
Attributes required, 2-623
Authority Violation, 2-2

B

BC should be less than 2000, 2-296

BEI must be YES if APC domain is X.25, 2-240
BLM must be provisioned and IS-NR for an
upload, 2-609
BLM/DCM card must be provisioned and IS-NR
for bulk download, 2-608
BLM/DCMLNP database must be coherent to do
a bulk download, 2-609
BOOT=NO not supported for specified
gpl, 2-818
Both DR and DA parameters cannot be
entered, 2-81
Both EDATE and ETIME parameters are
required, 2-866
Both LIMIT and INTRVL must be specified for
UIM threshold., 2-579
Both LOC and LINK must be specified, 2-118
Both NP and NAI must be specified if either is
present, 2-724
Both NPV and NAIV must be either * or
numbers, 2-712
Both OAM cards must be of same type to perform
upgrade, 2-437
Both OAM cards must be of the same type to
update database, 2-432
Both OAM cards must be of type GPSM-II to
enable TSCSYNC, 2-313
Both WRNLN and WRNTX must be
specified, 2-316
BPS must be 1544000 for LIMATM cards, 2-476
BPS must be
4800,9600,19200,56000,64000,1544000 or
2048000, 2-51
BPS must be 56000 for all ports on Multi Port
LIM, 2-397
BPS must be 56000 or 64000, 2-39, 2-40
Bulk download from LSMS to the BLM card must
have completed, 2-610
BYTE, WORD or DWORD must be
entered, 2-81

C

C value not allowed, 2-212
CA or CB register value is invalid for this
card, 2-732
Can't switch existing Pfx/Sfx, use RDMOD to
reset, 2-739
Can't switch existing Pfx/Sfx, use RMGTT to
reset, 2-750
Cannot, 2-138
Cannot add NP and NAI to an entry where
GTIXLAT is 22, 2-736

- Cannot allow terminal configured as type=none, 2-59
- Cannot assign APC with exception routes to linkset, 2-811
- Cannot assign ITU and ANSI LHOST to the same AS, 2-291
- Cannot assign LHOST to the B interface, 2-632
- Cannot assign LHOST/ALHOST to the B interface, 2-715
- Cannot change existing STP True PC if in MAP table, 2-468
- Cannot change if existing connection type is PVC, 2-280
- Cannot change network domain to anything other than CROSS, 2-809
- Cannot change routing key and attribute values, 2-697
- Cannot change terminal authority while user is logged on, 2-318
- Cannot change the RC parameter with the ENT command, 2-432
- Cannot change TYPE as system requires 2 SA enabled terminals, 2-319
- Cannot change TYPE as system requires two SA enabled terminals, 2-322
- Cannot decrease PVC below a logical channel in use, 2-282
- Cannot decrease SVC below number of SVCs already in use, 2-283
- Cannot delete last route to DPC ref. by an X.25 route, 2-263
- Cannot delete last route to DPC ref. by redirect func, 2-264
- Cannot delete last route to DPC ref. In MAP table, 2-263, 2-774
- Cannot delete last route to DSTN that has exception routes, 2-828
- Cannot delete STP self ID if a DPC of same type is defined, 2-74
- Cannot delete the last route to a DPC referenced in the MRN table, 2-412
- Cannot echo to OAP terminal, 2-633
- Cannot enter a wildcard with XLAT=2, Use XLAT=4 for wildcard, 2-789
- Cannot enter MTPRSE with SLSOCBIT, SLSRSB parameters, 2-635
- Cannot enter MULTCC if STP Options DefCC is NONE, 2-566
- Cannot enter the same PC more than once, 2-399
- Cannot execute command until table initialization complete, 2-755
- Cannot inhibit IMT bus - alternate bus is in abnormal stat, 2-302
- Cannot leave a solitary PC in group, 2-398
- Cannot mix Unchannelized and Channelized modes on E1 card, 2-776
- Cannot provision EMDC card with 15 min coll feature on, 2-570
- Cannot read DB Stat Table (<database>, <disk>, <MASP status>), 2-391
- Cannot set DefCC to none if a GSM Options MULTCC is defined, 2-553
- Cannot specify ALL=YES when command given, 2-6
- Cannot specify LC without LOC, 2-281
- Cannot specify LSN parameter with ALL=YES, 2-130
- Cannot turn on feature with EMDC provisioned, 2-569
- Cannot use NEXT if preceding RTRV-LOG command used TYPE=ALL, 2-751
- Capability point code already defined as a route DPC, 2-72
- Capability point code is already being used, 2-71
- Capability point code matches STP's own point code, 2-71
- Capacity of TDM(s) / TSM(s) insufficient to support request, 2-560
- Card does not exist or is not a LIM (LOC), 2-116
- Card does not exist or is not an LPE, 2-105
- Card does not support command driven loopback, 2-765
- Card does not support more than 2 Links, 2-398
- Card GPL of link does not match domain of linkset APC, 2-239
- Card GPL state conflict, 2-767
- Card GPL type IPGWI requires a link set with IPGWAPC=YES, 2-638
- Card GPL type SS7IPGW requires IPGWAPC=YES, 2-617
- Card has IP LNK with IP address assigned, 2-257
- Card having link in linkset must first be inhibited, 2-758
- Card having link in mate linkset must first be inhibited, 2-758
- Card is not a SS7GX25 card, 2-284
- Card is not an ACMENET card, 2-245
- Card is not in service, 2-155
- Card location already equipped, 2-29
- Card location is unequipped, 2-30

Index

- Card location must be 1113 or 1115, or APPL=E(OAM), 2-94
- Card location must be 1114 or 1116, 2-95
- Card location must be 1114, 1116, or 1117, 2-96
- Card location not assigned a TCP/IP link, 2-246
- Card location specified must be an OAM card, 2-471
- Card location specified must be an SCCP card, 2-411
- Card location specified must be the standby, 2-59
- Card must be inhibited before executing this command, 2-246
- Card slot location out of range, 2-54
- Card slot reserved by system, 2-55
- Card type must be VXWSLAN for a 100Mbit link, 2-842
- Card type of LIMCH does not support E1PORT = 2, 2-700
- Card type of LIMCH does not support T1PORT = 2, 2-304
- Card(s) cannot warm restart - FORCE parameter required, 2-627
- Card(s) not in-service normal - FORCE parameter required, 2-583
- Card's A/B interface IP Networks must be unique, 2-525
- CAS=ON is invalid for HC-MIM, 2-510
- Cccmmd table must be accessible, 2-243
- Cccnames table must be accessible, 2-243
- CCGT and NGTI are mutually exclusive, 2-750
- CCGT must be NO when PC is the STP's PC or CPC, 2-539
- CCGT must be NO when RI is set to GT, 2-540
- CCNC already exists, 2-520
- CCNC and MCCMNC parameters must be entered together, 2-519
- CCNC cannot be NONE, 2-517
- CDGTA GTTSET is not provisioned for specified GTT Selector, 2-851
- CDGTA must be specified, 2-830
- CDGTA or CGGTA or CGPC must be specified, 2-830
- CDGTASN and CGGTASN/CGPCSN can not be specified as NONE, 2-852
- CDGTASN can not be specified as NONE, 2-852
- CDGTASN must not be specified, 2-853
- CDGTASN set type doesn't match, 2-854
- CDPNNAI and SNAI must be specified together, 2-97
- CDPNNAI doesn't exist in INPOPTS Table, 2-91
- CDPNPFX doesn't exist in INPOPTS Table, 2-89
- CDPNPFX must be specified, 2-43
- CDPNPFX must not be NONE, 2-87
- CDSR does not exist in the database, 2-784
- CDSR must be specified when NCDSR is specified, 2-785
- CGGTA and CGPC are mutually exclusive, 2-829
- CGGTA or CGPC or OPC must be specified, 2-830
- CGGTASN and CGPCSN are mutually exclusive, 2-877
- CGGTASN set domain must be the same as GTTSN set domain, 2-870
- CGGTASN set type doesn't match, 2-842
- CGGTASN/CGPCSN can not be specified as NONE, 2-852
- CGGTASN/CGPCSN mustn't be specified if CGSSN/SELID specified, 2-853
- CGGTASN/CGPCSN/SELID are mutually exclusive, 2-821
- CGPA entry can't be provisioned, 2-781
- CGPA entry is referred by CDPA entries, 2-650
- CgPA GTT Selector already exists in GTII-TT-NP(V)-NAI(V), 2-826
- CgPA GTT Selector already exists in GTIN24-TT-NP(V)-NAI(V), 2-826
- CgPA GTT Selector already exists in GTIN-TT-NP(V)-NAI(V), 2-821
- CgPA GTT Selector already exists in GTI-TT-NP(V)-NAI(V), 2-827
- CgPA GTT Selector doesn't exist in GTI-TT-NP(V)-NAI(V), 2-851
- CGPC must be specified, 2-878
- CGPCSN set domain must be the same as GTTSN set domain, 2-854
- CGPCx is only valid if GTTSN is type of CGPC, 2-825
- CGSR doesn't exist for specified OPNAME, 2-652
- CGSR must be specified when CDSR is specified, 2-690
- CGSR or CDSR shouldn't be specified when SADDR is specified, 2-691
- CGSSN cannot be specified together with optional GTT Set Name, 2-823
- CGSSN is only valid if GTTSN is type of CGSSN, 2-825

- CGSSN range cannot overlap a currently existing range, 2-826
- CGSSN range does not exist, 2-827
- CGSSN/SELID is invalid if
 - CGGTASN/CGPCSN is not specified, 2-832
- CGSSNSN cannot be specified with
 - CGGTASN/OPCSN/CGPCSN/SELID, 2-823
- CGSSNSN set domain must be the same as GTTSN set domain, 2-869
- CGTT/CGNPV/CGNAIV mustn't be specified when CGGTIx=0, 2-878
- CHANBRDG is invalid for even numbered card location, 2-515
- CHANBRDG is only valid for HC-MIM, 2-510
- CHANBRDG parameter is invalid for even numbered port, 2-511
- Channel bridged slave port is invalid for link provisioning, 2-773
- CHG-PID not allowed while in upgrade mode, 2-389
- CIC must be specified if ECIC is specified, 2-870
- CIC outside of valid range for SI, 2-641
- CIC Range overlaps an existing range, 2-815
- CIC Range overlaps an existing routing key, 2-603
- CICS must be less than or equal to CICE, 2-602
- Class name is not an existing command class name, 2-124
- Class name is not an existing configurable command class, 2-104
- CLLI cannot be specified without Point Code, 2-37
- CLLI is already being used by a route, 2-71
- CLLI is not identical to that of matching Destination, 2-131
- CLLI not defined in route table, 2-129
- CLLI used by STP, 2-61
- Cluster DPCs are only valid if the CRMD feature is ON, 2-346
- Cluster DPCs can't inherit A or E linkset types, 2-771
- CMD parameter is not a valid Eagle command, 2-25
- collect=on cannot be specified with 15 min coll operational, 2-569
- Combination of SS7 PC/SSNs exists in X.25 route table, 2-277
- Combination of X.25 addresses exists in X.25 route table, 2-277
- Combination of X.25 addresses not in X.25 route table, 2-272
- Combined total baud rate for all ports cannot exceed 168K, 2-152
- Comm. attributes cannot be entered for OAP terminal, 2-328
- Command aborted
 - due to system error, 2-244
- Command action is out of phase with expected procedure, 2-66
- Command already in progress, 2-164
- Command cannot be executed on a Telnet terminal, 2-781
- Command cannot be executed on an MGMT terminal, 2-430
- Command cannot be executed on an OAP terminal, 2-315
- Command Class Management feature must be enabled, 2-98
- Command driven loopback in progress, 2-766
- Command driven loopback not in progress, 2-766
- Command is not supported for IPLIM and SS7IPGW links, 2-591
- Command is not supported for SS7IPGW links, 2-591
- Command not allowed while in upgrade mode, 2-465
- Command Not Found, 2-602
- Command not supported for non-IPGWx linksets, 2-570
- Command not supported with current IPLIML2 setting, 2-494
- Command not valid for IPGWI, 2-639
- Command not valid for IPLIM, 2-621
- Command not valid for IPLIMI, 2-630
- Command not valid for SS7IPGW, 2-622
- Command Rejected Messages
 - description, 2-2, 3-2
- Command Response Timeout, freeing up scroll area, 2-415
- Command will cause system clock outage – Use FORCE=YES, 2-523
- Common screening list DS length invalid, 2-843
- Common screening list entry already exists, 2-834
- Common screening list entry not present, 2-834
- Common screening list feature invalid, 2-799
- Common screening list feature is required, 2-833
- Common screening list invalid DS parameter value, 2-843

Index

- Common screening list invalid parameter combination, 2-835
 - Common screening list invalid parameter value, 2-846
 - Common screening list is full, 2-835
 - Common screening list key invalid, 2-799
 - Common screening list read fail, 2-835
 - Common screening list requested feature must be enabled, 2-836
 - Common screening list starting digits of key must be unique, 2-842
 - Common screening list type is invalid, 2-834
 - Common screening list type is required, 2-833
 - Communication Settings are not allowed on TELNET terminals, 2-126
 - Concerned node table for this group is full, 2-165
 - Conflicting parameters specified, 2-711
 - conflicts with existing entry, 2-413
 - Connection adapter type does not match AS adapter type, 2-712
 - Connection not compatible with SLK IPLIML2 setting, 2-492
 - Controlled Feature is not enabled, 2-495
 - COPY must be in ACT1, 2-562
 - Could not access active fixed disk, 2-334
 - Could not access removable disk, 2-332, 2-333
 - Could not access standby fixed disk, 2-333
 - Could not block link for testing, 2-306
 - CPCTYPE cannot be specified with NCPC, 2-456
 - CPCTYPE cannot be specified without CPC, 2-456
 - CPCx has not been provisioned, 2-353
 - CPCx must be ANSI if CPCTYPE equals LNP, 2-457
 - CPCx must not be ANSI if CPCTYPE is INP or EIR, 2-663
 - CRITALMINH not set trying to inhibit critical alarms, 2-488
 - CRMD feature must be ON, 2-233
 - CSPC broadcast group already exists, 2-162
 - CSPC broadcast group table is full, 2-163
 - CSPC entry is being referred by other entities, 2-859
 - CSPC group cannot contain both PCN and PCN24 point codes, 2-880
 - CSPC group does not exist, 2-163
 - CSPC group network type does not match PC network type, 2-178
 - CTX parameter is invalid for this card, 2-730
 - Current actv OAM db is not supported for this upgrade, 2-69
 - Current database not coherent, 2-335
 - Current ITU-N site id must be disabled for this assignment, 2-322
 - Current set of next elog entries have been overwritten, 2-755
 - Current stdby OAM db is not supported for this upgrade, 2-69
 - Customer Care Center, 1-8
 - CWMIN must be less than or equal 16384 for IPGW associations, 2-466
- ## D
- DA parameter is invalid for this card, 2-733
 - Daily measurement collection in progress, 2-108
 - Data audit already in progress, 2-95
 - DATA can only be specified with P486, 2-287
 - DATA parameter is invalid for this card, 2-730
 - Database consistency violation - maintenance required, 2-36
 - Database in the BLM card must be coherent for an upload, 2-610
 - Database is incoherent, 2-400
 - Database maint. in progress - retry later, 2-78
 - Database maintenance is required, 2-35
 - Database repair is required, 2-35
 - Day is invalid for type-enttype combination, 2-482
 - Day must be specified when PERIOD=SPECIFIC, 2-484
 - Day out of range, 2-98
 - Day-to-hour measurement collection in progress, 2-108
 - Day-to-hour measurement data not yet collected, 2-108
 - DB is incoherent (<database>, <disk>, <MASP status>), 2-391
 - DB status is UPG 1 (<database>, <disk>, <MASP status>), 2-391
 - DEBUG must be on, 2-472
 - Def Router IP Addr must be local to this cards A, B network, 2-547
 - Dest IP Address already exists for this card, 2-544
 - Dest IP Address cannot be local to this cards A, B network, 2-544
 - Dest IP Address does not exist for this card, 2-544
 - Dest IP Address is invalid, 2-543

- Destination address must be a full point code, 2-348
- Destination card invalid, 2-97
- Destination disk capacity equals 0, 2-334
- Destination disk is unformatted, 2-331
- Destination location must specify the standby fixed disk, 2-332
- Destination location must specify the standby removable disk, 2-333
- Destination parameter not supported, 2-68
- Destination's alias PCs must be full PCs, 2-350
- DEV must be either slk, ls, or route if CLLI is specified, 2-867
- DEV state does not allow alarms to be inhibited, 2-388
- DEV type is not supported by specified location, 2-810
- Device alarm inhibit table not accessible, 2-488
- DFLTACT can not be ATIERR unless OPCODE=71, 2-652
- DFLTACT must be specified as FORWARD, DUPLICATE, or DUPDISC, 2-320
- DGTS parameter must be 3 or 6-10 digits, 2-424
- Disk access error - fixed disk, 2-101
- DISPLAY parameter is mandatory with DUR parameter, 2-866
- DISPLAY parameter is mandatory with FRM parameter, 2-872
- DLTPFX must not be specified, when NCDPNPFX is NONE, 2-89
- Documentation Packaging, Delivery, and Updates, 1-8
- Domain indicated by GTIx must match that of existing TT, 2-448
- Domain must be SS7 if SPC is specified, 2-616
- DPADDR cannot be entered with DR/DA, 2-285
- DPC assigned to SS7 address does not exist in SS7 domain, 2-275
- DPC assigned to SS7 address has no SS7 routes, 2-276
- DPC assigned to X.25 address has no SS7 routes, 2-275
- DPC assigned to X25 address does not exist in X25 domain, 2-275
- DPC cannot be defined as a remote application IPC, 2-430
- DPC cannot be IPGWx APC or SAPC, 2-876
- DPC defined as linkset APC, 2-131
- DPC is already being used, 2-131
- DPC is referenced by SCCP in the MRN table, 2-407
- DPC is referenced by SCCP's MAP table, 2-347
- DPC must be a cluster DPC or cluster member, 2-52
- DPC must be removed from X.25 route tbl, 2-242
- DPC must be specified as wildcard when used with STAT, 2-363
- DPC must have at least one route defined, 2-262
- DPC must not specify a cluster route for IPGWAPC link set, 2-618
- DPC parameter must be specified, 2-487
- DPC parameter needed with MODE=FULL, 2-155
- DR parameter is invalid for this card, 2-733
- DRANAI and DRANAIV must not be specified together, 2-664
- DRANP and DRANPV must not be specified together, 2-664
- DRARM parameter is invalid for this card, 2-733
- DRARM parameter is invalid for this processor, 2-732
- DS0 and NEI link elements do not support non-latching tests, 2-366
- DSM's are required when LNP and VGTT are ON, 2-687
- DSTN address must be a full, network or cluster PC, 2-360
- DSTN5000 feature must be enabled, 2-483
- DUAL OAP configuration is needed for LNP feature, 2-457
- Duplicate ACTs in different slots are not allowed, 2-561
- DUR parameter is mandatory with EDATE parameter, 2-867
- DUR=PERM can only be specified with a 486 processor, 2-286
- DURAL must be specified within 0.995959 or 999999, 2-315
- DV must be SCCP when SERV is a user defined type, 2-461
- DV must be TCAP when SERV is WNP, AIN, PCS, IN or LNPQS, 2-461
- Dynamic rkeys + SRKQ exceed max allowed rkey limit, 2-623
- DYNRTK feature must be enabled to perform this operation, 2-625

E

- E1 card location is unequipped, 2-710, 2-711
- E1 is assigned to card, 2-699

Index

- E1 Port test command in progress, 2-525
- E1 Port test command not in progress, 2-525
- E1 specified by E1LOC/E1PORT is using CAS, TS=16 not allowed, 2-702
- E1/T1 Port greater than 2 unavailable, 2-515
- E1PORT specified by E1LOC is not equipped, 2-701
- E5IS must be on, 2-676
- EADDR cannot be specified without SADDR, 2-649
- EADDR must be greater than SADDR, 2-648
- EADDR shouldn't be specified when SADDR = *, 2-783
- Eagle can only accept messages of 450 or fewer bytes (C<col>), 2-474, 2-475
- Echo capability not applicable on originating terminal, 2-484
- Echo is not set for this port, 2-98
- Echo not allowed for telnet terminals, 2-157
- EDATE parameter requires DUR = timed, 2-867
- EDATE/ETIME must be greater than current system date/time, 2-866
- EGMS feature requires DSM card with VSCCP APPL or better, 2-649
- EGTA cannot be specified without GTA, 2-163
- EGTA must be greater than or equal to GTA, 2-168
- EGTT cannot be ON if any SCCP card has a 486 processor, 2-540
- EGTT must be ON before this command can be entered, 2-532
- EIR and INP are mutually exclusive, 2-737, 2-741
- EIR and LNP are mutually exclusive, 2-741
- EIR feature cannot be enabled if ASM/TSM is present, 2-742
- EIR feature must be enabled, 2-744
- EIR feature must be ON, 2-571
- EIR subsystem is offline in database, 2-744
- Either ALIASN or ALIASN24, not both, for destination, 2-515
- Either BUS or Location (not both) must be specified, 2-693
- Either INP or GPORT feature must be ON, 2-686
- Either LOC or APPL (not both) must be specified, 2-106
- Either LSN or LOC and LINK must be specified, 2-115
- Either NLSN or RC must be specified, 2-815
- Either PLNP or WNP Features must be ON, 2-654
- Either TLNP or ISUP NP with EPAP must be enabled, 2-809
- Either TYPE or TTN must be specified, 2-189
- ELAP architecture does not support LNP quantity requested, 2-794
- ELAP must be available to verify LNP quantity support, 2-795
- ELEI is only valid for cluster destinations, 2-345
- ELEI is only valid if the CRMD feature is ON, 2-346
- Enabling of IDPR requires VSCCP DSM cards and ELAP, 2-847
- ENCODE = AMI not currently supported, 2-723
- End value must be greater than or equal to a starting value, 2-824
- Ending bucket cannot be less than starting bucket, 2-418
- Enhanced Bulk Download already in progress, 2-611
- Enhanced Bulk Download not in progress, 2-611
- Enhanced GSM Map Screening feature must be enabled, 2-785
- Enhanced GSM Map Screening feature must be ON, 2-782
- Enhanced GSM Map Screening must be ON, 2-736
- Enter param VENIDLLEN, or params VENDID, VENDNUM and VENDTYPE, 2-807
- Enter params SUBNETIDLLEN or paramrs SUBNETID and SUBNETNUM, 2-808
- Entered DPC exists in APPFLT table, 2-861
- Entered Frame must be a provisioned frame, 2-862
- Entered NOPC does not exist in the routing table, 2-860
- Entered OPC does not exist in the routing table, 2-860
- Entity must be specified when Entity type is specified, 2-770
- Entries in static route key table cannot exceed SRKQ, 2-624
- Entry already exists for this application at this IP Address, 2-316
- Entry already exists for this application at this priority, 2-317
- Entry already exists with specified GTII-TT-NP(V)-NAI(V)-SSN, 2-668
- Entry already exists with specified GTIN24-TT-NP(V)-NAI(V)-SSN, 2-709

- Entry already exists with specified GTIN-TT-NP(V)-NAI(V)-SSN, 2-669
 - Entry already exists with specified GTI-TT-NP(V)-NAI(V)-SSN, 2-664
 - Entry being deleted is referenced by a GSM Map Screen entry, 2-647
 - Entry does not exist with specified GTII-TT-NP(V)-NAI(V)-SSN, 2-669
 - Entry does not exist with specified GTIN24-TT-NP(V)-NAI(V)-SSN, 2-880
 - Entry does not exist with specified GTIN-TT-NP(V)-NAI(V)-SSN, 2-670
 - Entry does not exist with specified GTI-TT-NP(V)-NAI(V)-SSN, 2-665
 - Entry is already defined as the STP Options DefCC, 2-552
 - ENUM must be greater or equal to mate parameter SNUM, 2-752
 - ENUM range does not match SNUM 1-999 or 1000-1499, 2-753
 - ENUM requires an SNUM as its mate parameter, 2-752
 - EPRI cannot be less than PRI, 2-193
 - EROUTE not configured, 2-436
 - Error in FEATCTRL.TBL date, maintenance required, 2-695
 - ETT already mapped for LSN and IO specified, 2-341
 - ETT cannot be mapped to MTT with same value, 2-341
 - ETT not defined for LSN and IO specified, 2-341
 - Exception route cannot be assigned to adjacent point code, 2-818
 - Exception route cannot be assigned to cluster members, 2-819
 - EXT not valid with ACTION=RESET, 2-294
- F**
- Failed accessing maintenance data, 2-362
 - Failed accessing the memory equippage table, 2-559
 - Failed deleting shelf as FPT entry is provisioned, 2-862, 2-863
 - Failed reading ACG MIC table, 2-420
 - Failed reading ACG NOC table, 2-420
 - Failed reading Application Socket table, 2-775
 - Failed reading Assembly Power table, 2-861
 - Failed reading FEATPFX, 2-808
 - Failed reading FPT table, 2-861
 - Failed reading GSM Options Table, 2-526
 - Failed reading GSM SSN Table, 2-527
 - Failed reading GTT DBMM table, 2-447
 - Failed reading GTT Selector Table, 2-527
 - Failed reading GTT Set Table, 2-527
 - Failed Reading GTT TRANS table, 2-447
 - Failed reading HOME SMSC ADDRESS table, 2-506
 - Failed reading HOMERN Table, 2-660
 - Failed reading INPOPTS Table, 2-660
 - Failed reading level 2 timer set table, 2-66
 - Failed reading level 3 timer set table, 2-67, 2-68
 - Failed reading Link Fault Sectionalization table, 2-363
 - Failed reading linkset table, 2-40
 - Failed reading LNP Options table, 2-455
 - Failed Reading LNP SS Appl table, 2-449
 - Failed Reading LNP TT SERV table, 2-448
 - Failed Reading MAP table, 2-856
 - Failed reading MAS configuration table, 2-51
 - Failed reading OAP configuration table, 2-554
 - Failed reading redirect table, 2-261
 - Failed Reading SCCP Service Table, 2-873
 - Failed reading Secondary Point Code (SPC) table, 2-611
 - Failed reading SERV Selector Table, 2-528
 - Failed reading shelf table, 2-31
 - Failed reading site identification table, 2-354
 - Failed reading SLTM table, 2-74
 - Failed Reading SS Appl table, 2-554
 - Failed reading STP options table, 2-344
 - Failed reading SUBNETID table, 2-803
 - Failed reading terminal table, 2-48
 - Failed reading the ATM link parameter set table, 2-479
 - Failed reading the E1/T1 table, 2-705
 - Failed reading the extended link table, 2-244
 - Failed reading the GWS Stop Action Set table, 2-558
 - Failed reading the IMT table, 2-30
 - Failed reading the link table, 2-31
 - Failed reading the MRN table, 2-406
 - Failed reading the password table, 2-311, 2-312
 - Failed reading the route table, 2-265
 - Failed reading the security log attributes table, 2-409
 - Failed reading the UIM Threshold Table, 2-598
 - Failed reading the user identification table, 2-76
 - Failed reading the X.25 destination table, 2-265
 - Failed reading the X.25 route table, 2-266
 - Failed reading trouble text table, 2-473
 - Failed reading tt map table, 2-339
 - Failed reading VENDID table, 2-791

Index

- Failed reading/writing Extended Linkset Table, 2-383
- Failed reading/writing Extended STP Options Table, 2-383
- Failed to access Route Exception Table, 2-814
- Failure reading the GSM Map SCRN Table, 2-647
- Failure reading the GSM OPCODE Table, 2-646
- Failure reading the GSM SSN Screening Table, 2-645
- Fan feature must be enabled, 2-635
- FEATPFX table full, 2-801
- Feature associated with SERV must be ON or enabled, 2-875
- Feature bit configuration requires DSM card with VSCCP appl, 2-543
- Feature corresponding to APPL not ON, 2-234
- Feature Name is not valid, 2-801
- Feature not compatible with ICNP feature, 2-26
- Feature not compatible with Measurements Platform, 2-26
- Feature Prefix already exists, 2-801
- Feature Prefix not found, 2-802
- Feature Prefix Number invalid, 2-802
- Feature Prefix still in use, 2-802
- Feature Prefix too long, 2-800
- Feature Prefix too short, 2-799
- Feature Requires at least DSM4GB, 2-25
- FGTTLS feature requires minimum DSM card with VSCCP APPL, 2-829
- File already exists, 2-123
- File transfer in progress, 2-89
- filelength not valid with ACTION=RENAME, 2-295
- FILELENGTH not valid with ACTION=RESET, 2-293
- First octet of IPADDR cannot be 127, 2-247
- Fixed disk contains Eagle data (use FORCE=YES), 2-61
- Fixed disk is inaccessible (internal problem), 2-391
- Fixed disk is not initialized, 2-391
- Fixed disk is not inserted, 2-391
- For Mate Point Code (MPC), MSSN, MateRC, RC must be provided, 2-403
- For SUBNETNUM specified the prefix is not provisioned, 2-806
- For VENDNUM specified the prefix is not provisioned, 2-795
- FORBID can not be STATE or LOCATION for the given OPNAME, 2-651
- FORCE parameter required, 2-147
- FORCE parameter valid only with DATA parameter, 2-627
- FORCE valid only with APPL, DATA or INITCLK parameters, 2-626
- FORCE=YES is required to isolate card from IMT, 2-395
- FORCE=YES is required when card is allowed, 2-305
- FORCE=YES must be given to inhibit last OAP terminal, 2-300
- FORCE=YES must be specified, 2-600
- Force=YES must be specified, 2-608
- FORCE=YES must be specified for NUM greater than 1000, 2-169
- FORCE=YES must be specified if NUM is greater than 50, 2-455
- FORCE=YES must be specified to change existing stop action, 2-563
- FORCE=YES must be specified to delete entire node, 2-253
- FORCE=YES must be specified to initialize the last OAP, 2-329
- Frame ID out of range, 2-53
- FTP SERV table must contain one entry with application USER, 2-504
- FTP Server password must be 1 - 15 characters in length, 2-434
- FTP Server table entry not found for this APP/IPADDR, 2-317
- FTP Server table must be accessible, 2-317
- FTP transfer already in progress, 2-504
- Full Point Code must be specified, 2-435
- Fully specified connection required to change OPEN, 2-596
- FWORD can only be used with PADDR, 2-284
- FWORD is not supported at this time, 2-285

G

- Gateway screening rules table is full, 2-228
- GFLEX and LNP are mutually exclusive, 2-671
- GFLEX feature must be on, 2-516
- GFLEX or EIR feature must be on, 2-748
- GFLEX or GPORT feature must be ON, 2-763
- GFLEX or GPORT feature must be on, 2-682
- GFLEX, INP, or GPORT feature must be ON, 2-663
- GFLEX/GPORT/EIR feature must be on, 2-747
- GFLEX/GPORT/INP must be ON or EIR must be enabled, 2-745
- GFLEX/INP/GPORT/EIR/LNP ELAP Config feature must be ON, 2-718

- GPORT feature must be on, 2-680
- GPORT feature must be on when (N)SERV=GPORT, 2-678
- GPORT feature requires DSM Cards, 2-678
- GPSM-II required to support more than 700 links, 2-438
- Group code must be in SID or SPC table, 2-727
- Group code not allowed when ITUDUPPC feat is OFF, 2-727
- Group code not allowed with specified network type, 2-726
- Group Code of destination and Secondary PC must match, 2-643
- Group Code of DPCN and OPCN must match, 2-685
- Group code required for ITUN when ITUDUPPC feat is ON, 2-727
- groupcode of DPC(s) and APC/SAPC must match when MULTGC=NO, 2-705
- Grp Code of dstn & True PC must match if no Secondary PC, 2-643
- GSM Map Screening feature must be enabled, 2-650
- GSM Map Screening feature must be ON, 2-643
- GSM Map SCRN entry already exists or overlaps another entry, 2-648
- GT Conversion table is full, 2-737
- GTA does not exist in any range, 2-161
- GTA does not match translation type's number of digits, 2-161
- GTA is only valid if GTTSN is type of CDGTA/CGGTA, 2-824
- GTA Length does not match GTT Set number of digits, 2-538
- GTA length is not defined for GTTSET, 2-689
- GTA length is not defined for TT, 2-688
- GTA range does not exist, 2-159
- GTA range is already assigned, 2-162
- GTA range overlaps a current range, 2-159
- GTA/CGPC/OPC/CGSSN is mandatory and mutually exclusive, 2-822
- GTI (A)=4, and GTI (X)=1 and 3 are not supported, 2-530
- GTI network domain does not match CGGTASN network domain, 2-841
- GTI network domain does not match GTT set, 2-534
- GTI/GTIA is invalid for specified (N)SERV, 2-666
- GTI/GTIA/GTII/GTIN not within specified range of 1 to 4, 2-706
- GTIA/GTI must not be specified when (N)SERV= GPORT, 2-681
- GTII must not be specified when (N)SERV = INPQ, 2-666
- GTT DBMM table is full, 2-566
- GTT feature must be ON, 2-236
- GTT must be on before EGTT can be on, 2-529
- GTT must be ON before GPORT can be ON, 2-678
- GTT must be on before IDPR can be enabled, 2-847
- GTT must be on before IDPS can be enabled, 2-864
- GTT must be ON before INP can be ON, 2-659
- GTT must be ON before MGTT can be ON, 2-267
- GTT must be ON before VGTT can be ON, 2-637
- GTT must be ON before XGTT can be enabled, 2-441
- GTT Selector already exists in GTII-TT-NP(V)-NAI(V), 2-656
- GTT Selector already exists in GTIN24-TT-NP(V)-NAI(V), 2-516
- GTT Selector already exists in GTIN-TT-NP(V)-NAI(V), 2-655
- GTT Selector does not exist in GTII-TT-NP(V)-NAI(V), 2-656
- GTT Selector does not exist in GTIN24-TT-NP(V)-NAI(V), 2-516
- GTT Selector does not exist in GTIN-TT-NP(V)-NAI(V), 2-656
- GTT Selector specified by GTI-TT-NP(V)-NAI(V) already exists, 2-533
- GTT Selector specified by GTI-TT-NP(V)-NAI(V) does not exist, 2-533
- GTT Set Name must match its set type, 2-822
- GTT set name must match the network domain, 2-832
- GTT Set specified by CGGTASN does not exist, 2-841
- GTT Set specified by GTTSN already exists, 2-533
- GTT Set specified by GTTSN does not exist, 2-534
- GTT Set specified by GTTSN has GTAs assigned to it, 2-536
- GTT Set specified by GTTSN has GTT Selectors assigned to it, 2-536
- GTT Set specified by GTTSN is being referred in SCCPOPTS, 2-876
- GTT Set table is full, 2-535

Index

- GTT table is full, 2-184
GTTSN must not be specified as NONE, 2-535
Gtwy IP Address is invalid, 2-605
Gtwy IP Address must be local to this cards A, B network, 2-605, 2-606
GWS and LNP must be ON before TLNP can be ON, 2-564
GWS feature must be ON, 2-237
GWS must be ON before CNCF can be ON, 2-556
GWS must be ON if LAN is ON, 2-233
GWS/GTT shared table is full, 2-223
GWSA, GWSM, GWSM are invalid without SCRSET specified, 2-132
- ### H
- H0 and H1 cannot be specified for SI greater than 2, 2-194
H0 and H1 must be specified for given SI, 2-193
H0/H1 matches existing H0/H1 in given SR, 2-193
H1 must be wild card if H0 is wild card, 2-195
HC-MIM does not support interface to a channel card, 2-510
HH must be specified when PERIOD=SPECIFIC, 2-114
HIPR must be equipped on the shelf where HC-MIM card reside, 2-512
HMUXTVG must be ON before E5IS can be ON, 2-674
Home SMSC Table is full, 2-507
HOMERN Table is full, 2-660
Host assignment to IPLIM/IPLIMI card not supported, 2-720
Host Name Referenced by Application Socket or Association, 2-707
Host Name Still Referenced in IP Link Table, 2-631
Host Number Invalid, 2-27
Host table is full, 2-587
Host table must contain IP link addresses, 2-594
Hostname must be unique, 2-585
Hourly measurement collection in progress, 2-116
- ### I
- ICNP feature must be activated, 2-844
ID must be specified, 2-387
IDP Screening for Prepaid feature must be ON when SERV=IDPS, 2-864
IDPR and LNP are mutually exclusive, 2-848
IDPR cannot be enabled if ASM/TSM is present, 2-848
IDPR feature requires DEFCC to be provisioned, 2-849
IDPS cannot be enabled if ASM/TSM is present, 2-865
If AUTO=yes, then DUPLEX and SPEED are not allowed, 2-587
If DIR=BKWD, SDATE/STIME must be > EDATE/ETIME, 2-754
If Domain name is specified, RSTDOMAIN is not valid, 2-593
If GTIXLAT is 22, NAI and NP cannot be specified, 2-693
If GTIXLAT is 24, NAI and NP must be specific, 2-694
If GWSA=OFF then GWSM must also be OFF, 2-132
If IO or ETT specified, BOTH opt. Parms must be specified, 2-342
If IPADDR is specified SUBMASK is required, 2-590
If NDIGITS = 0 then PREFIX parameter is invalid, 2-37
If NGTI is 2, NNP and NNAI cannot be specified, 2-740
If NGTI is 4, NNP and NNAI must be specified, 2-740
If NGTI is 4, PC cannot be ANSI, 2-881
If OAP parameter not specified as ALL, FORCE=YES required, 2-555
If PARM is specified, PVALUE must be specified, 2-588
If SDATE=EDATE, then ETIME after or same as STIME, 2-381
If specified BPS must be 1984000 when Linkclass = Unchan, 2-777
If specified, BPS must be 2048000 for LIME1ATM Card, 2-473
If specified, BPS must be 56000 for Multi Port LIM, 2-397
If TIMER is specified, TVALUE must be specified, 2-588
Illegal attempt to delete yourself, 2-102
IMT fault test in progress, 2-415
IMT statistics collection in progress - Repeat later, 2-419
Incorrect DB version (<database>, <disk>, <MASP status>), 2-391
Incorrect information unit, expecting card location - <parm>, 2-23

- Incorrect information unit, expecting IP address - <parm>, 2-21
- Incorrect information unit, expecting mnemonic - <parm>, 2-21
- Incorrect information unit, expecting new or dflt, 2-28, 2-29
- Incorrect information unit, expecting num or dflt - mnrnset, 2-28
- Incorrect information unit, expecting num,new or dflt - mnrnset, 2-27
- Incorrect information unit, expecting num,none or dflt - mnrnset, 2-28
- Incorrect information unit, expecting number - <parm>, 2-20
- Incorrect information unit, expecting number or * - <parm>, 2-22
- Incorrect information unit, expecting number or none - <parm>, 2-24
- Incorrect information unit, expecting number or range - <parm>, 2-20
- Incorrect information unit, expecting point code - <parm>, 2-22
- Incorrect information unit, expecting string - <parm>, 2-21
- Incorrect information unit, translation type - <parm>, 2-23
- Incorrect input, expecting number, * or range - <parm>, 2-24
- IND cannot be greater than 3, 2-286
- IND parameter must be 6 or 10, 2-428
- Inhibit rejected, target terminal is not equipped, 2-226
- INIT=YES only valid with BID record, 2-97
- Initial Command Response Timeout, 2-542
- Init-sys already in progress at another terminal, 2-105
- INP and LNP are mutually exclusive, 2-659
- INP feature must be ON, 2-522
- INP or EIR feature must be ON, 2-743
- INP subsystem is offline in database, 2-542
- Insufficient #SCCP cards to support LIM - use FORCE=YES, 2-578
- Integer value must be less than 65535, 2-296
- Intermed GTT Load sharing feature must be on, 2-405
- International PC is identical to international CPC, 2-72
- Invalid APPL selection for SERIAL init card command, 2-599
- Invalid BAUD value specified, 2-48
- Invalid card location, 2-11
- Invalid card TYPE and APPL load type combination, 2-31
- Invalid card type for this command, 2-82
- Invalid character in IP address - <parm>, 2-15
- Invalid CLLI, 2-132
- Invalid combination - EDATE with STIME, 2-383
- Invalid combination of ADDR and PADDR specified, 2-285
- Invalid combination of new and existing point codes, 2-873
- Invalid combination of parameters for a default routing key, 2-672
- Invalid combination of parameters for a partial routing key, 2-671
- Invalid combination of PSTNCAT and PSTNID values, 2-697
- Invalid combination of TYPE and DATA parameters, 2-732
- Invalid combination of TYPE, UENG, and CTX parameters, 2-730
- Invalid condition value comparison for CA or CB register., 2-794
- Invalid destination application ID, 2-79
- Invalid destination table, 2-10
- Invalid Domain name, 2-589
- Invalid drive specified, 2-90
- Invalid ENTTYPE for this TYPE, 2-111
- Invalid FC value specified, 2-48
- Invalid Feature Access Key, 2-497
- Invalid file length, 2-125
- Invalid filename entered, 2-124
- Invalid GPL type for this command, 2-106
- Invalid H0/H1 or NH0/NH1 specified, 2-462
- Invalid hardware for EISCOPY to be on, 2-676
- Invalid Hostname, 2-583
- Invalid INTRVL value specified, 2-384
- Invalid IP database configuration, 2-843
- Invalid IPADDR, 2-289
- Invalid LINK for APPL, 2-238
- Invalid link speed combination within linkset, 2-38
- Invalid linkset type for card, 2-42
- Invalid Loopback selection for LIME1ATM, 2-323
- Invalid name for adapter type, 2-710
- Invalid NCAI parameter has been entered, 2-351
- Invalid OAM drive, 2-10
- Invalid OAM HW config or an HMUX card is out of service, 2-653
- Invalid offset, 2-472

Index

- Invalid originating application ID, 2-80
- Invalid parameter, 2-293
- Invalid parameter combination for SI, 2-619
- Invalid parameter combination specified, 2-55
- Invalid parameter for CCS7ITU or IPLIMI, 2-486
- Invalid parameter for ITU-N 24bit point code, 2-339
- Invalid parameter for SCCP, 2-484
- Invalid parameter for SS7ANSI, ATMANSI, IPLIM, or SS7IPGW, 2-485
- Invalid parameter for VSCCP, 2-486
- Invalid parameter specified for report type, 2-416
- Invalid parameters for ACTION=COPY, 2-480
- Invalid Part Number, 2-495
- Invalid password. Keyboard is locked. Enter UNLOCK command, 2-314
- Invalid PERIOD for this TYPE or ENTTYPE, 2-110
- Invalid point code, 2-133
- Invalid PRTY value specified, 2-48
- Invalid PVN, 2-675
- Invalid PVNMASK, 2-689
- Invalid SCSI device syntax, 2-123
- Invalid socket/association ratio for card type, 2-438
- Invalid source table, 2-9
- Invalid Subnet Mask, 2-584
- Invalid system, 2-10
- Invalid System serial number, 2-546
- Invalid system serial number in database, 2-497
- Invalid table Id, 2-124
- Invalid timing source for channel bridging, 2-774
- Invalid TRM value for SEAS TDM port, 2-300
- Invalid TYPE, 2-121
- Invalid userID/password combination, 2-311
- IP Address found in host table, 2-817
- IP Address invalid for Address Class, 2-26
- IP address must be unique, 2-593
- IP Address requires 4 octets in the range 1 . . . 254 - <parm>, 2-11
- IP Address still referenced by the Def Router, 2-547
- IP Node Address never entered or Card DB corrupt, 2-290
- IP Route table full, 2-606
- IPADDR already assigned to another TCP/IP link, 2-261
- IPADDR and IPRTE cannot be the same address, 2-257
- IPADDR assigned to a TCP/IP link, 2-249
- IPADDR assigned to a TCP/IP node, 2-248
- IPADDR assigned to a TCP/IP router, 2-261
- IPADDR not assigned to a TCP/IP link, 2-248
- IPADDR not assigned to any TCP/IP link, 2-255
- IPADDR not assigned to specified LOC, 2-254
- IPADDR w/o IPRTE must match first 2 octets of TCP/IP link, 2-251
- IPADDR w/o IPRTE must match first 3 octets of TCP/IP link, 2-252
- IPADDR w/o IPRTE must match first octet of TCP/IP link, 2-251
- IPAPPL already assigned to specified LOC, 2-252
- IPAPPL on Node not assigned to specified LOC, 2-255
- IPAPPL on node not connected to any TCP/IP link, 2-256
- IPGWI link must be in a single link linkset, 2-638
- IPISUP Feature must be on, 2-603
- IPLIML2 is only valid for IPLIMx SLK, 2-467
- IPLIMx connections cannot be resident in AS, 2-493
- IPPORT already assigned, 2-250
- IPPORT can only be specified if IPADDR is specified, 2-250
- IPPORT on node not assigned to specified LOC, 2-254
- IPPORT on Node not connected to any TCP/IP link, 2-256
- IPRTE address assigned to TCP/IP link, 2-259
- IPRTE address must use first 2 octets of Class B TCP/IP Link, 2-260
- IPRTE address must use first 3 octets of Class C TCP/IP Link, 2-260
- IPRTE address must use first octet of Class A TCP/IP Link, 2-259
- IPSM card not equipped, 2-129
- IPSM card(s) must be inhibited to enable telnet feature, 2-729
- IPTPS must be divisible by 10, 2-770
- IPTPS not allowed for non-IPGWx linksets, 2-768
- IPTPS required for IPGWx linksets, 2-768
- IS412GSM must be provisioned before SERVERPFX, 2-796
- ISUP normalization feature must be enabled to set NORM=YES, 2-698
- ISUP NP with EPAP feature must be enabled, 2-804

ISUPMT/TUPMT already exists in given SR, 2-210
 ISUPMT/TUPMT does not exist in given SR, 2-210
 ITU entries not allowed when ANSIGFLEX is on, 2-788
 ITU National Point Code must be full point code, 2-658
 ITU PC parameters are invalid for ANSI cards, 2-485
 ITU point codes are not supported when DOMAIN=X25, 2-142
 ITU-INTL site id not defined, 2-298
 ITU-NATL site id not defined, 2-298
 ITUTFR parameter is only valid for ITU link sets, 2-637

K

Key values
 DIR, TTA, TTI, NP, NAI already exist, 2-723
 DIR, TTA, TTI, NP, NAI does not exist, 2-723
 Keyboard is locked. Enter UNLOCK command, 2-3
 Keyboard is not locked, 2-315

L

L parameter cannot be used in combination with LOC, 2-418
 L2STATS not valid for IPGWI, 2-640
 L2STATS not valid for SS7IPGW, 2-621
 L2TSET cannot be specified if card application is SS7GX25, 2-240
 l2tset must be 1-10 for ANSI links, 11-20 for ITU, 2-42
 LAN feature must be ON, 2-235
 Last entry in given SR is ref'ed by another screen, 2-198
 Last route to DPC in use by GTT, 2-140
 LBP cannot exceed previously defined NEI LBP value, 2-367
 LBP has already been provisioned, 2-365
 LBP must have been previously defined in database, 2-368
 LBP or ALL parameter must be specified exclusively, 2-369
 LC already in use, 2-280
 LC can only be specified when TYPE=PVC, 2-273
 LC greater than maximum PVCs for link, 2-279

LC must be specified when TYPE=PVC, 2-272
 Length of EGTA must be equal to length of GTA, 2-160
 Level 1 Alarm Threshold level must be less than Level 2, 2-811
 LFS command in progress, 2-370
 LFS data is only valid for OCTET and ALTERNATE patterns, 2-371
 LFS feature must be ON, 2-352
 LFS must not be running on requested link, 2-375
 LFS test is completing, cannot be canceled, 2-371
 LHOST and ALHOST must refer to different IP addresses, 2-551
 LHOST and ALHOST must refer to IP address on the same card, 2-551
 LHOST has open socket or association, 2-492, 2-494
 LHOST/ALHOST location not found, 2-437
 Link assigned to card, 2-33
 link capacity exceeds limit allow by feature key, 2-509
 Link is in test mode, 2-33
 Link is invalid for card location, 2-514
 Link is unequipped in the database, 2-148
 LINK must be A if card type is LIMATM or LIME1ATM, 2-475
 Link must be cancelled before executing this command, 2-258
 Link must be removed from X.25 route(s), 2-239
 Link must be SAAL to execute command, 2-376
 Link must be SS7 to display Level 2 stats, 2-374
 Link must be SS7 to execute command, 2-374
 Link must not be active for dact-lbp command, 2-373
 Link must not be active to execute command, 2-374
 Link not assigned to SS7-X.25 card, 2-279
 Link not equipped, 2-278
 Link Parameter may only be a or b for SE-HSL, 2-779
 LINK parameter valid only when ENTTYPE=LINK, 2-119
 Link set is not equipped, 2-154
 Link set with IPGWAPC=YES requires SS7IPGW/IPGWI GPL, 2-618
 Link test command in progress, 2-764
 Link test command not in progress, 2-765
 Link test must not be running on requested link, 2-763

Index

- LINKCLASS=UCH is not valid for even numbered card loc, 2-778
- Links assigned to linkset, 2-135
- Links on specified linkset are in-service, 2-41
- Linkset already assigned to route, 2-139
- Linkset already defined, 2-136
- Linkset APC/SAPC is already being used, 2-135
- Linkset assigned to route must have at least one link, 2-43
- Linkset cannot be the mate of another linkset, 2-756
- Linkset cannot reference self as mate, 2-757
- Linkset does not reference MATELSN, 2-768
- Linkset is unequipped, 2-140
- Linkset not assigned in route table, 2-138
- Linkset not defined, 2-136
- Linkset referenced by exception route, 2-879
- Linkset referenced by route, 2-137
- Linkset SAPC referenced by route, 2-244
- Linkset SLK requires ITUN APC/SAPC to be 14bit or 24bit only, 2-526
- Linkset table full, 2-136
- Linkset Type used for cluster route cannot be A or E, 2-137
- linkset with MULTGC=YES requires IPGWI/IPLIMI GPL, 2-698
- LNP and GPORT features are mutually exclusive, 2-677
- LNP ELAP CFG feat incompatible with SCCP/EBDADCM/EBDABLM appl, 2-718
- LNP ELAP Configuration and WNP features must be ON, 2-548
- LNP ELAP Configuration feature must be ON, 2-499
- LNP feature must be ON, 2-410
- LNP feature must be on before LNP ELAP Config can be on, 2-717
- LNP or EIR must be enabled or INP must be ON, 2-746
- LNP or INP feature must be ON, 2-661
- LNP ported LRNs 150K Qty Feat Requires at least DSM2GB, 2-607
- LNP ported NPANXXs 300K Qty Feat Requires at least DSM2GB, 2-606
- LNP ported TNs 12million Qty Feat Req at least TSM/DSM1GB, 2-502
- LNP ported TNs 24million Qty Feat Require at least DSM2GB, 2-502
- LNP ported TNs 36million Qty Feat Require at least DSM3GB, 2-502
- LNP ported TNs 48 to 228 M Qty Feat Req at least DSM4GB, 2-503
- LNP ported TNs 4million Qty Feat Require at least TSM512MB, 2-501
- LNP ported TNs 6million Qty Feat Require at least TSM768MB, 2-501
- LNP ported TNs 8million Qty Feat Require at least TSM1GB, 2-501
- LNP SS Appl table is full, 2-449
- LNP subsystem is offline in database, 2-411
- Loading Mode unstable due to maint. baseline not established, 2-445
- Loading Mode unstable due to SCCP service is deficient, 2-446
- Loading mode unstable. System's LIM service is unavailable, 2-445
- LOC and CLASS cannot be specified together, 2-481
- LOC and E1PORT parameter combination must be specified, 2-755
- LOC and LINK must be specified when PERIOD=ALL, 2-115
- LOC and PORT must be specified to display Level2 stats, 2-375
- LOC and PORT parameter combination must be specified, 2-369
- LOC and T1PORT parameter combination must be specified, 2-756
- LOC has maximum number of LFS Tests already in progress, 2-377
- LOC is invalid for specified report TYPE, 2-291
- LOC is not LFS capable, 2-364
- LOC must be LIMDS0 or LIMOCU with SS7ANSI or CCS7ITU, 2-372
- LOC must be specified, 2-143
- LOC must be specified when TYPE=PVC or SVCA, 2-273
- LOC must not be specified when TYPE=SVCR, 2-273
- LOC not allowed with MODE=STATIC, 2-625
- LOC not assigned an X.25 signaling link, 2-284
- LOC parameter not valid for this ENTTYPE, 2-118
- Location invalid for hardware configuration, 2-50
- Location type cannot receive messages, 2-80
- Loopback in progress, 2-375
- Lower bound exceeds upper bound of range - %, 2-20
- Lower bound exceeds upper bound of range - <parm>, 2-24

LSL parameters not valid for card type, 2-476, 2-477
 LSMS parameter requires LNP feature, 2-576
 LSN and LINK parms cannot be specified together, 2-117
 LSN and LOC cannot be specified together, 2-117
 LSN and NLSN cannot be identical, 2-815
 LSN must be provided with ALL=NO, 2-129
 LSN must be specified, 2-119, 2-387
 LSN parameter not valid for type-enttype combination, 2-120
 LSUSEALM not allowed for non-IPGWx linksets, 2-768, 2-769
 Lvl 1 Removable detected during upgrade, 2-489

M

M2PATSET requires M2PA adapter type, 2-505 manual
 related publications, 1-3
 MAP entry is being referred by other entries, 2-858
 Map entry must be solitary, 2-404
 MAP table is full, 2-856
 Map with STP True PC has LNP/INP/EIR SS-APPL assigned, 2-469
 MAPSET must be specified (only) if FGTTLS feature is enabled, 2-855
 MAPSET must be specified (only) if RI parameter is SSN, 2-859
 MAPSET must be specified if action is FORWARD/DUP/DUPDISC, 2-858
 MAPSET must be specified if FORCE is specified, 2-858
 Matching routing key already entered for AS, 2-708
 Mate already exists for linkset, 2-760
 Mate linkset not defined, 2-767
 Mate parameters
 MPC, MSSN, MateRC are required together, 2-404
 Mate PC/SSN cannot be given when MULT=SOL, 2-167
 Mate PC/SSN cannot be same as PC/SSN, 2-170
 Mate Relative Cost (MateRC) required if MPC/MSSN is entered, 2-401
 Mated linksets must contain only SS7IPGW or IPGWI links, 2-757
 Mated linksets must have APCs of same network type, 2-758
 Max IP connections exceeded, 2-591
 Max number combined LSLs and ATM HSLs already entered, 2-477
 Max number of cards of application type already exist, 2-582
 Max number of DEFINED MSGCODEs per variant is exceeded, 2-326
 Max number of DEFINED PARMCODEs per variant is exceeded, 2-327
 Max number of entries exist in FTP Server table, 2-319
 Max number of FTPSERV table entries exist for this APP, 2-320
 Max number of STC cards per shelf is entered, 2-675
 Max Packet Size must be 128 when N1 is equal to 1080, 2-266
 Max sockets per routing key exceeded, 2-590
 Maximum allowed Prefix values already entered for feature, 2-800
 Maximum matching Route Exceptions already exist for DPC, 2-813
 Maximum number of applications already assigned, 2-452
 Maximum Number of CDPNNAIs already provisioned, 2-91
 Maximum number of CDPNPFxs already provisioned, 2-82
 Maximum number of connections already provisioned for AS, 2-712
 Maximum number of CPCs defined (96), 2-359
 Maximum number of link tests already in progress, 2-376
 Maximum number of links are assigned to this linkset, 2-44
 Maximum number of Mated Applications (MAP) exceeded, 2-402
 Maximum number of PPSMSGTAs already provisioned, 2-440
 Maximum number of rules exceeded in screen set, 2-199
 Maximum number of screen sets exceeded, 2-200
 Maximum of 10 unique CCNCs allowed, 2-519
 Maximum point codes have been allocated to SCCP-SERV set, 2-874
 Maximum RContexts per AS exceeded, 2-775
 Maximum Route Exceptions already exist for this STP, 2-814

Index

- Maximum Route Exceptions already exist per DPC and Criteria, 2-813
- maximum SAPC entries exceeded, 2-725
- Maximum SVCAs already defined for link, 2-271
- May not change adjacent point code type, 2-134
- May not modify both T21 and IT23 timers, 2-68
- May not specify both LOC and STAT, 2-144
- May not specify both LSN and PST, 2-154
- May not specify Filename when ALL=YES, 2-93
- MCP card must be IS-ANR Restrict to enable measplatform, 2-153
- Meas for Enh GSM MAP Screening not supported on EOAM, 2-787
- Meas Platform feature must be ON, 2-288
- MEAS Platform must be enabled, 2-433
- Measurement collection in progress, Retry later, 2-721
- Measurement Preparation in progress, Retry later, 2-608
- Measurements not inhibited, 2-60
- MF or MV parms must be kept in an ordered list starting at 1, 2-326
- MGTT cannot be ON if any SCCP card less than 586 processor, 2-299
- Minutes out of range, 2-99
- Missing argument assignment operator, 2-6
- Missing command identifier, 2-5
- Missing information unit separator, 2-19
- Missing mandatory parameter - <parm>, 2-6
- Missing modifier separator, 2-5
- Missing parameter, 2-150
- Missing parameter - BC, 2-86
- Missing parameter - CARD, LOC or IMT, 2-87
- Missing parameter - DA or DR, 2-87
- Missing parameter - DPADDR or DR, 2-289
- Missing parameter block separator, 2-4
- Missing parameter identifier, 2-7
- Mixed point code types are not allowed, 2-200
- Mnemonic argument is undefined, 2-171
- MO SMS feature must be activated, 2-506, 2-508
- Modification of security log not allowed, 2-408
- Month out of range, 2-100
- More than one of CARD, LOC and IMT specified, 2-88
- MPC and MSSN must be defined for new MULT val, 2-175
- MPC does not exist in routing table, 2-171
- MPC entered, MSSN must also be given, 2-171
- MPC feature must be enabled, 2-636
- MPC network type does not match PC network type, 2-172
- MPC/MSSN pair already exists, 2-173
- MPS must be either 128 or 256, 2-281
- MRN table is full, 2-330
- MRNSET must be specified (only) if FGTTLS feature is enabled, 2-838
- MRNSET must be specified (only) if RI parameter is GT, 2-837
- MSAR=ONLY must be specified exclusively, 2-358
- MSGCODE and PARMCODE must both be DEFINED, 2-326
- MSRNNAI and MSRNNP parameters must be entered together, 2-682
- MSSN or MATERC entered, MPC must also be given, 2-173
- MTP Origin Based Routing Feature must be ON, 2-872
- MTP Restart Indicator must be off to execute this command, 2-491
- MTP restart option not valid for IPGWAPC linksets, 2-601
- MTPDPCQ cannot be increased while x-list storage is full, 2-358
- MTPDPCQ cannot be less than no. of destinations provisioned, 2-362
- MTPDPCQ cannot exceed available space in the dstn table, 2-357
- MTPLPRST option must be enabled, 2-870
- MTPRSE parameter is only valid if ITUMTPRS feature is ON, 2-629
- MTPRSE parameter is only valid if MTPRS feature is ON, 2-336
- MTPRSI is only valid if MTPRS or ITUMTPRS feature is ON, 2-335
- MTPRSIT parameter is only valid if MTPRS feature is ON, 2-336
- MTPT10ALT cannot be less than level-3 timer T10, 2-373
- MTPXLQ cannot exceed available space in the dstn table, 2-343
- MTPXLxx parameters are only valid if CRMD feature is ON, 2-343
- MULTCC entry already exists in the GSM Options CC list, 2-514
- MULTCC entry cannot be NONE, 2-414
- MULTCC entry does not exist, 2-553
- MULTCC list is full, 2-553
- MULTGC=YES not allowed if ITUDUPPC feature is OFF, 2-697
- MULTGC=YES requires IPGWI or IPLIMI links, 2-685

MULTGC=YES requires ITU-N or ITU-I point code, 2-705
 Multiple CGSSN/SELID entries exist for specified selector, 2-798
 Multiple groups are allowed only in default MRNSET, 2-839
 Must be in upgrade phase 3 or full function mode, 2-399
 Must enter at least one PC/RC pair, 2-433
 Must specify ALL=YES to delete all files, 2-94
 Must specify application and version, 2-95
 Must specify either
 ENTRY or ROW with COLUMN, 2-471
 Must specify either SNAME or ASNAME, 2-708
 Must specify either SNAME or ASNAME or RC, 2-877
 Must specify NC when NI is specified for ORIGININC, 2-470
 Must specify trigger type with an offset, 2-849

N

N1 must be either 1080 or 2104, 2-281
 NA entry already equipped, 2-728
 NA entry not found, 2-728
 NACTION must be specified (FORWARD, DUPLICATE, or DUPDISC), 2-432
 NACTION parameter must be FORWARD, DUPLICATE, or DUPDISC, 2-431
 NAI and NAIV must not be specified together, 2-530
 NAI entries per TT-NP combination has reached allowed max, 2-535
 NAME not valid with ACTION=RESET, 2-294
 National PC is identical to national CPC, 2-73
 NC cannot be zero when NI is less than 6, 2-202
 NC is invalid, 2-206
 NC is invalid for type-enttype combo, 2-481
 NCAI param is only valid if both feat CRMD and NCR are ON, 2-352
 NCAI required if cluster members have different route set, 2-355
 NCDPNPFX already exists in INPOPTS Table, 2-75
 NCGSR shouldn't be specified when CDSR is specified, 2-784
 NCICE unspecified, NCICS must be less than or equal to CICE, 2-620
 NCICS must be less than or equal to NCICE, 2-616
 NCICS unspecified, NCICE must be greater than or equal to CICS, 2-630

NCM is invalid, 2-207
 NCM must be * when using Network Routing, 2-389
 NCPCx and CPCx type must match, 2-353
 NCPCx cannot be specified without CPCx, 2-354
 NCR must be enabled to enter NCAI param, 2-337
 ND parameter must be 3 or 6-10, 2-424
 NDFLTACTION must be specified (FORWARD, DUPLICATE, or DUPDISC), 2-431
 NDFLTACTION parameter must be FORWARD, DUPLICATE, or DUPDISC, 2-321
 NDGT parameter is invalid for CGSSN, CGPC and OPC sets, 2-860
 NDGT parameter is invalid for VGTT, 2-689
 NDGT parameter not permitted with ALIAS, 2-187
 NDIGITS parameter mandatory with PREFIX parameter, 2-37
 NEI LBP has already been defined for the CCS7 link, 2-367
 NEI LBP must be defined as the last link element, 2-368
 Network Address conflicts with IP Route Table, 2-796, 2-797
 Network Appearance table full, 2-773
 Network Number Invalid, 2-27
 Network Routing is only valid if the NRT feature is ON, 2-388
 Network Security Enhancements feature must be ON, 2-473
 Network/Cluster cannot have alias DPC members, 2-355
 Network/Cluster DSTNs are not supported in the X.25 domain, 2-349
 New CIC range overlaps an existing routing key, 2-616
 New class name cannot be the same as an existing class name, 2-125
 New connection type must be different from existing, 2-280
 New digits valid (DV) must not match old DV indication, 2-458
 New H0/H1 matches existing wild carded H0/H1 in given SR, 2-203
 New PC and RC must be entered as a pair, 2-433
 New PC does not exist in the routing table, 2-175
 New Translation Type already in LNP database, 2-450

Index

- New Translation Type Name already in LNP database, 2-451
- New/existing NSFI=AFTPC requires new/existing SSN=1, 2-202
- New/existing PC does not exist in the remote PC table, 2-174
- New/existing RI must be GT for new/existing XLAT=DPCNGT, 2-174
- NEXT requires this term issued last valid RTRV-LOG command, 2-753
- NGT can only be specified when XLAT=DPC or DPCNGT, 2-761
- NGT can only be specified when XLAT=DPCNGT, 2-176
- NGT must be specified for new values of XLAT/RI, 2-176
- NGT must be specified when XLAT=DPCNGT, 2-190
- NGTI only valid when PC and GTTSN are different domains, 2-740
- NGTI only valid when PC and TYPE are different domains, 2-751
- NH0 and NH1 cannot be specified for NSI greater than 2, 2-194
- NH0 and NH1 cannot be specified for SI greater than 2, 2-204
- NH0 and NH1 must be specified for given NSI, 2-203
- NH1 must be wild card if NH0 is wild card, 2-205
- NI is invalid, 2-205
- NI is invalid for type-enttype combo, 2-481
- NI parameter may not be specified for ITU linksets, 2-541
- NI required, 2-123
- NI, ZONE, MSA or NPC cannot be C - more than one exists, 2-197
- NI, ZONE, MSA or NPC cannot be C for existing blocked SR, 2-198
- NI, ZONE, MSA or NPC must be C when creating new blocked SR, 2-211
- NIC and SI must be specified for given H0 and H1, 2-230
- NIC does not exist for given SR, 2-211
- NIC must be specified for given SI, 2-211
- NIC, SI, and H0/H1 entry already exists in given SR, 2-230
- NIC, SI, H0/H1, & PRI entry already exist in given SR, 2-465
- NMULTCC and MULTCC parameters must be entered together, 2-101
- NMULTCC entry already exists in the GSM Options MULTCC list, 2-525
- NNIC, NSI, and NH0/NH1 entry already exists in given SR, 2-209
- NNP,NNAI,NPDD/S,NSDD/S,NGTI,RMGTT invalid if MGTT is OFF, 2-324
- No active LFS Test on the specified link, 2-371
- No available primary MCP, 2-447
- No change requested, 2-617
- No Entry found, 2-587
- No File Transfer Area on removable cartridge, 2-96
- No match on ACTNAME parameter during retrieve, 2-563
- No match on AREA or SSA parameter during retrieve, 2-212
- No match on DESTFLD parameter during retrieve, 2-385
- No match on EPRI parameter during retrieve, 2-213
- No match on H0 parameter during retrieve, 2-213
- No match on H1 parameter during retrieve, 2-213
- No match on ID or SP parameter during retrieve, 2-214
- No match on NC parameter during retrieve, 2-214
- No match on NCM parameter during retrieve, 2-214
- No match on NI parameter during retrieve, 2-215
- No match on NIC parameter during retrieve, 2-215
- No match on NPC parameter during retrieve, 2-215
- No match on NSFI parameter during retrieve, 2-216
- No match on NSR parameter during retrieve, 2-216
- No match on PCST parameter during retrieve, 2-774
- No match on PRI parameter during retrieve, 2-216
- No match on REDIRECT parameter during retrieve, 2-295
- No match on RI parameter during retrieve, 2-217
- No match on SCCPMT parameter during retrieve, 2-385
- No match on SCMGFID parameter during retrieve, 2-385

- No match on SI parameter during retrieve, 2-217
 - No match on SSN parameter during retrieve, 2-217
 - No match on TYPE parameter during retrieve, 2-218
 - No match on ZONE or MSA parameter during retrieve, 2-218
 - No MIC of TYPE=ALL exists, 2-427
 - No MIC with the same service and digits exists, 2-427
 - No obits to display, 2-156
 - No optional parameters may be specified if FORCE=YES, 2-253
 - No other optional parameters may be specified with "ALL", 2-560
 - No other optional parms can be entered with SRCSET, 2-589
 - No other parameters are permitted with the NEXT parameter, 2-753
 - No test link message is sent, 2-149
 - No troubles to display, 2-156
 - No user associated with OAP terminal, 2-362
 - NONE is a reserved name and cannot be used for a TTN, 2-458
 - NORM=YES not supported for specified PSTNCAT/PSTNID values, 2-695
 - Not compatible with SCCP Conversion feature, 2-739
 - NP and NAI must be specified as DFLT together, 2-541
 - NP and NPV must not be specified together, 2-529
 - NP ported TNs 2million Qty Feat Requires at least TSM256MB, 2-607
 - NP(V) and NAI(V) must be specified for given GTI value, 2-531
 - NP(V) and NAI(V) must not be specified for given GTI value, 2-530
 - NPCx cannot be specified without PCx, 2-791
 - NPPSMSGTA already exists in GSMOPTS Table, 2-441
 - NSAP parameter requires LNP feature, 2-574
 - NSFI / NSR cannot be specified, 2-220
 - NSFI and NSR do not reference an existing screen, 2-220
 - NSFI is invalid, 2-463
 - NSFI must be FAIL, 2-219
 - NSFI must be specified, 2-218
 - NSFI must be STOP, 2-219
 - NSFI must be STOP if ACTNAME is specified, 2-559
 - NSFI must be STOP if COPY or REDIRECT are specified, 2-192
 - NSFI must not be FAIL, 2-219
 - NSI must be specified for given NNIC, 2-220
 - NSNAI = NONE only allowed when NSERV = INPQ, 2-683
 - NSNAI must be specified when NSERV = INPMR, 2-670
 - NSR cannot be specified if ACTNAME is specified, 2-559
 - NSR cannot be specified if COPY or REDIRECT are specified, 2-201
 - NSR cannot be specified when NSFI is STOP or FAIL, 2-222
 - NSR must be specified for given NSFI, 2-221
 - NTT can only be specified when XLAT=DPC or DPCNGT, 2-761
 - NTT can only be specified when XLAT=DPCNGT, 2-537
 - NTT must be specified for new values of XLAT/RI, 2-539
 - NTT must be specified when XLAT=DPCNGT, 2-537
 - NUM exceeds maximum table size, 2-177
 - Number of PREFIX digits cannot exceed NDIGITS parameter, 2-38
 - Number out of range, 2-158
 - NZO is not valid for this TYPE, 2-122
- O**
- OAP CFG required before OAP update, 2-577
 - OAP Hostname required before OAP update, 2-576
 - OAP IP Address required before OAP update, 2-578
 - Octet 1 is out of range, 1 . . . 223 - <parm>, 2-12
 - Octet 1 missing - <parm>, 2-13
 - Octet 2 is out of range, 1 . . . 254 - <parm>, 2-12
 - Octet 2 missing - <parm>, 2-13
 - Octet 3 is out of range, 1 . . . 254 - <parm>, 2-12
 - Octet 3 missing - <parm>, 2-14
 - Octet 4 is out of range, 1 . . . 254 - <parm>, 2-13
 - Octet 4 missing - <parm>, 2-14
 - OCTET and ALTERNATE are not valid for non-latching test, 2-372
 - On-demand report currently being printed, 2-121
 - Only 4 ports with sys maint. output group ON are allowed, 2-152
 - Only 6 message relay services can be assigned, 2-462

Index

- Only IPGW routes are allowed for private PCs, 2-778
 - Only one E1 port allowed for Linkclass equal unchan, 2-875
 - only one ITU-I APC/SAPC allowed per linkset, 2-725
 - Only one of BYTE, WORD or DWORD may be entered, 2-88
 - Only one of IPADDR, IPAPPL, IPRTE, or LOC can be specified, 2-256
 - Only one of IPAPPL or IPPORT may be specified, 2-253
 - Only one of NCPC/A, NCPCI, or NCPCN/N24 may be specified, 2-70
 - Only one of PPCN or PCN24 may be specified, 2-265
 - Only one optional parameter may be specified, 2-248
 - Only one Source and Destination may be specified, 2-90
 - Only one SS7IPGW or IPGWI link allowed in mated linkset, 2-598
 - Only PARMCODE=0 (EOP) can have MINLEN=0, 2-325
 - Only SNAME, ASNAME or RCONTEXT allowed for default rtkey, 2-708
 - Only two E1 ports allowed for Linkclass equals unchan, 2-698
 - OPC must not be identical to DPC, 2-818
 - OPC, CICS, CICE are not allowed with SI unless SI is 4, 5, or 13, 2-604
 - OPC, CICS, CICE are required if SI is 4, 5, or 13, 2-604
 - OPC/ILSN/CIC/SI is mandatory and mutually exclusive, 2-829
 - OPCODE already exists, 2-646
 - OPCODE and OPNAME shouldn't be specified together, 2-692
 - OPCSN set domain must be the same as GTTSN set domain, 2-855
 - OPCx is only valid if GTTSN is type of OPC, 2-825
 - OPEN must be NO to change an Association or its AS/Rtkey, 2-715
 - OPEN must be NO to change or delete socket, 2-592
 - Open sockets cannot have same lhost/lport, 2-636
 - OPNAME already used, 2-646
 - OPNAME does not exist in the database, 2-647
 - Optional GTT Set is not compatible with GTTSN set type, 2-824
 - Ordered routes cannot be assigned to cluster members, 2-356
 - Ordered routes cannot be changed for cluster members, 2-359
 - Ordered routes cannot be deleted from cluster members, 2-356
 - Origin Based SCCP Routing feature must be enabled, 2-819
 - OUTGRP and SNUM/ENUM combination invalid, 2-754
- ## P
- P Address still referenced by static IP Routes, 2-548
 - Parameter AINTVL is not allowed, 2-423
 - Parameter AINTVL is required, 2-422
 - Parameter combination invalid, 2-417
 - Parameter DRTN or AINTVL is required, 2-426
 - Parameter DRTN or INTVL is required, 2-427
 - Parameter INTVL is not allowed, 2-423
 - Parameter INTVL is required, 2-423
 - Parameter ND is not allowed, 2-422
 - Parameter ND, DRTN, INTVL, or AINTVL is required, 2-426
 - Parameter PCST / NPCST is not allowed with C for blocked SR, 2-773
 - Parameters inconsistent on re-entering of command, 2-628
 - Parameters ND, INTVL, and AINTVL are required, 2-421
 - Parameters not valid for card type, 2-44
 - Parameters SERV and DGTS are not allowed for TYPE=ALL, 2-421
 - Parameters SERV and DGTS are required, 2-421
 - PARMCODE is supported in a message, cannot be NOTDEFINED, 2-327
 - Part Number does not belong to an On/Off Feature, 2-547
 - Partial point codes are not allowed, 2-62
 - Partition specified invalid for target disk, 2-146
 - Password cannot contain userID, 2-313
 - Password does not contain enough alphabetic characters, 2-308
 - Password does not contain enough characters, 2-103
 - Password does not contain enough numeric characters, 2-309
 - Password does not contain enough punctuation characters, 2-310
 - Password operations not allowed on a non-secure terminal, 2-297

- Password too long, 12 maximum, 2-102
- Password verification failed, 2-103
- Pattern contains invalid characters, 2-75
- Pattern has odd number of characters, 2-75
- PC & MRNSET must be specified together, 2-840
- PC already exists in CSPC group, 2-165
- PC already exists in the MRN entity set, 2-330
- PC and RC must be entered as a pair, 2-330
- PC cannot match the SID, 2-406
- PC does not exist in CSPC group, 2-165
- PC does not exist in specified MRNSET, 2-839
- PC does not match existing entry in given SR, 2-465
- PC must already exist in the MRN table, 2-343
- PC must already exist in the SCCP-SERV set, 2-874
- PC must match NPCFMTI set in CHG-STPOPTS, 2-405
- PC network type does not match existing PC network type, 2-323
- PC reference exists in GTT translation, 2-840
- PC/CLLI does not match current PC/CLLI of the STP, 2-133
- PC/SSN already exists in given SR, 2-227
- PC/SSN does not exist as a mated application, 2-179
- PC/SSN does not exist in given SR, 2-226
- PC/SSN does not exist in MAPSET, 2-857
- PC/SSN must be given with Action FORWARD, DUPLICATE, DUPDISC, 2-435
- PC/SSN must be specified if FORCE is specified, 2-436
- PC/SSN/RI/SCCPMT already exists in given SR, 2-208
- PC/SSN/RI/SCCPMT does not exist in given SR, 2-208
- PC/SSN/SCMG already exists in given SR, 2-209
- PC/SSN/SCMGFID does not exist in given SR, 2-209
- PCRN1 and PCRN2 parameters are invalid if ECM=BASIC, 2-40
- PCx specified does not exist as a True Point Code, 2-790
- PCx, NPCx, CPCx or NCPCx must not be equal, 2-359
- PERIOD must be 1 hour boundary for report type, 2-116
- PERIOD must be 1/2 hour boundary, 2-120
- Period must be 1/4 hour boundary, 2-568
- Perm feature key cannot be turned off for the feature, 2-500
- PLNP feature must be ON, 2-460
- Point code already exists in given SR, 2-225
- Point code defined as an alias, 2-130
- Point code does not exist in given SR, 2-222
- Point code does not exist in the remote point code table, 2-167
- Point code does not exist in the routing table, 2-166
- Point code matches a STP capability point code, 2-64
- Point code matches a STP point code, 2-65
- Point code matches a STP secondary point code., 2-762
- Point Code must be the STP True point code, 2-459
- Point code must exist within the group, 2-247
- Point code network type does not match TT network type, 2-187
- Point code not defined, 2-267
- Point code not equipped, 2-156
- Point code out of range, 2-66, 2-227
- Point Code Subtype Prefix not supported, 2-735
- Point Code type does not match GTT Set network domain, 2-537
- Point codes contain invalid wild card combinations, 2-196
- Port B not supported for device, 2-597
- Port is channel bridged with its master port, 2-513
- Port must be inhibited to change comm. attributes, 2-47
- PORT must be specified, 2-387
- PORT must not be specified when TYPE=SVCR, 2-274
- Port not valid for card or application type, 2-632
- PORT parameter invalid for DEV selected, 2-386
- PPSMSGTA doesn't exist in GSMOPTS Table, 2-440
- PPSMSGTA must be specified when NPPSMSGTA is specified, 2-440
- PPSMSGTA must not be NONE, 2-439
- PREFIX parameter mandatory with NDIGITS parameter, 2-38
- Prepaid IDP Query Relay feature must be ON when (N)SERV=IDPR, 2-846
- Prepaid SMS Intercept Ph1 feature must be ON, 2-518
- Primary PC/SSN pair already exists, 2-175

Index

Primary remote PC does not exist in routing table, 2-180
Private PC not allowed for non-IPGW linkset, 2-776
Processor timeout error, 2-631
PSEL parameter requires LNP feature, 2-575
PSTN is not defined, 2-325
PSTNCAT=0 requires PSTNID=0, 2-685
PSTNCAT=1 requires ITU-I or ITU-N point code, 2-686
PVC plus SVC cannot be greater than 255, 2-282
PVC plus SVC must be at least 1, 2-282
PVN and PVMASK must be specified together, 2-673
PVN and PVMASK must not be the same, 2-674
PVN conflicts with IP route dest or IP card local network, 2-392

Q

QH and HH cannot be specified together, 2-569
QH cannot be specified unless 15 min meas is turned on, 2-568
QH or HH is not valid for this TYPE, 2-122
QH or HH must be specified when PERIOD=SPECIFIC, 2-114
QH, HH, or DAY cannot be specified when PERIOD=ACTIVE, 2-113
QH, HH, or DAY cannot be specified when PERIOD=ALL, 2-113
QH, HH, or DAY cannot be specified when PERIOD=LAST, 2-112
Quantity control feature capacity exceeded, 2-325

R

Range endpoints are reversed, 2-844
RC Already Equipped, 2-729
RC is required if no other optional parameters are provided, 2-399
RDCT must be in lowest priority action slot, 2-562
Read NETOPTS table failed, 2-677
Received wrong display mode, 2-157
RECOVERED is allowed only in channel bridging mode, 2-511
REDIRECT can only be specified with ANSI point codes, 2-295
Redirect function data has already been entered, 2-262

Redirect function data has not been entered, 2-262
Relative Cost (RC) is required for PC/SSN and MPC/MSSN, 2-402
Relative Cost (RC) of true MPC must be less than RC of mate, 2-403
Relative Cost (RC) of true PC must be less than RC of mate, 2-403
remote application not found, 2-413
Remote point code does not exist in MAP table, 2-180
Remote point code table is full, 2-181
Removable cartridge contains Eagle data (use FORCE=YES), 2-60
Removable cartridge database level is not compatible, 2-581
Removable cartridge is inaccessible (internal problem), 2-391
Removable cartridge is not a MEAS disk, 2-391
Removable cartridge is not a system disk, 2-390
Removable cartridge is not inserted, 2-390
Removable cartridge not inserted, 2-61
Removable in unknown upgrade mode, 2-490
Removable is from previously aborted upgrade, 2-490
REP cannot be specified when DUR=PERM, 2-286
REP is only valid if LFST is defined as LLT, 2-366
REP must be greater than prev. and less than subsequent REP, 2-364
REP must be zero if link element to be tested is NEI, 2-365
REP parameter must be specified, 2-373
Requested Assoc Buffer Space Exceeds Available Buffer Space., 2-877
Requested link must not be in command driven loopback, 2-764
Requested service parameters not supported when (N)SERV=IDPR, 2-849
Requested service parameters not supported when SERV=IDPS, 2-865
Requires C-linksets parameter tfatcabmlq to be set to 0, 2-798
RESETCHAR not valid with ACTION=CREATE, 2-293
RESETCHAR not valid with ACTION=RENAME, 2-294
Revocation of security admin userID not allowed, 2-312
RI must be GT when specifying NGT, 2-760
RI must be GT when specifying NTT, 2-761

RI must be SSN when CCGT is YES, 2-539
 RI=GT must be specified when
 XLAT=DPCNGT, 2-191
 RLE and LFST must be specified when database
 is not used, 2-372
 RMIN must be less than or equal to
 RMAX, 2-466
 RN already exists in HOMERN Table, 2-662
 RN does not exist in HOMERN Table, 2-662
 Route Exception already exists for input
 parameters, 2-812
 Route Exception does not exist, 2-814
 Route table is full, 2-141
 Routes of equal cost cannot exist for X.25
 destinations, 2-351
 Routeset is empty, 2-140
 Routeset is full, 2-139
 Routeset must be empty, 2-139
 Routesets Feature Quantity must be
 increased, 2-498
 Routing Context parameter is required for
 SUA, 2-735
 Routing key not found, 2-595
 Routing Key table full, 2-595
 RTRV-LOG command already in
 progress, 2-382

S

S/ESHELF can only be entered, when report =
 hmutex is set, 2-693
 S/ESLOT cannot be set to 9 or 10, 2-508
 SADDR and EADDR must have the same
 number of digits, 2-648
 SADDR must be specified when EGMS feature is
 OFF, 2-786
 SADDR, NPV and NAIV must be specified
 together, 2-691
 SAPC allowed for ITU-I or ITU-N linkset
 only, 2-726
 SAPC entry not found for the linkset, 2-724
 SAPC entry preset for the linkset, 2-726
 SCCP appl provisioned with ASM card
 type, 2-520
 SCCP card must have at least 586
 processor, 2-412
 SCCP Conversion feature must be
 enabled, 2-738
 SCCP Conversion feature requires at least TSM
 Hardware, 2-752
 SCCP not configured, 2-148

SCCPCNV must be ON before TCAPCNV can be
 ON, 2-486
 SCCPCNV, TCAPCNV must be disabled, 2-751
 SCCPMT must be specified as 9, 10, 17, 18, or
 *, 2-177
 SCCP-SERV allocation within MRN table is
 full, 2-873
 SCMGFID is invalid, 2-204
 Screen set name already exists, 2-229
 Screen set name is referenced by a link set, 2-229
 Screen set name not defined, 2-141
 Screening action can not be ATIERR for the given
 OPNAME, 2-651
 SCTP Association or SLK provisioned
 Card supports 2 links, 2-499
 SDATE must be earlier or equal to
 EDATE, 2-407
 SDATE+STIME must be before current
 date-time, 2-381
 SEAC CLLI parameter requires SEAS
 feature, 2-572
 SEAC CLLI required before OAP update, 2-580
 SEAS can only update translations with Default
 MRNSET, 2-850
 SEAS Error Messages Index, 3-1
 SEAS feature or LNP feature is not
 configured, 2-328
 SEAS Gateway Linksets cannot be deleted
 locally, 2-380
 SEAS Gateway Screen Set Names cannot be
 changed locally, 2-380
 SEAS Subsystem has not been
 provisioned, 2-299
 SEAS X.25 mode required before OAP
 update, 2-580
 SEAS X.25 packet size required before OAP
 update, 2-580
 Seconds out of range, 2-107
 Security log command already in
 progress, 2-409
 Security tables may not be altered, 2-472
 SELID is valid only if specified GTTSN is set type
 of CDGTA, 2-833
 SERIAL param valid only with APPL
 param, 2-599
 SERV has not been assigned a true TT, 2-448
 SERV must not be GFLEX when SNAI =
 RNIDN/RNNDN/RNSDN, 2-668
 Service Selector Table is full, 2-522
 Service Type is already in LNP database, 2-450
 Service type is not in LNP database, 2-451

Index

- Set SERVERPFX to NONE before disabling IS412GSM, 2-796
- SETTYPE must be CDGTA when NETDOM=CROSS, 2-823
- Shelf ID out of range, 2-53
- Shelf location 1100 is reserved for the control shelf, 2-78
- Shelf location already equipped, 2-78
- Shelf location not equipped, 2-34
- SI does not exist for given SR, 2-230
- Signaling link is not provisioned for the card, 2-699
- Single rte to APC or SAPC for IPGW LS allowed, 2-871
- SIO does not exist in given SR, 2-229
- Site PC, CPCs and NCPCs must be full point codes, 2-349
- Site point code is already being used, 2-73
- Site SPC must be a full point code, 2-615
- SLK IPLIML2 requires linkset MTPRSE setting to be no, 2-466
- SLKUSEALM not allowed for non-IPGWx linksets, 2-769
- SLSCI is only valid for ANSI link sets, 2-347
- SLSOCBIT parameter is only valid for ITU link sets, 2-633
- SLSOCBIT parameter not permitted if SLSOCB feature is off, 2-634
- SLRSRB parameter is only valid for ITU Link Sets, 2-634
- SLTSET and ENABLED cannot be specified together, 2-75
- SMSC ADDR to be deleted does not exist in database, 2-507
- SMSC Address already exists, 2-507
- SNAI & SNP must be specified when SERV is not INPQ/EIR, 2-667
- SNAME must be specified, 2-386
- Socket connection parameters must be unique, 2-586
- Socket name already exists, 2-585
- Socket Name not defined, 2-596
- Socket name not found, 2-584
- Socket Table full, 2-590
- Source address/location must be specified, 2-419
- Source and destination combination is not allowed, 2-564
- Source and destination disks not compatible, 2-334
- Source database version is not compatible, 2-384
- Source drive not coherent, 2-334
- Source location must specify the active fixed disk, 2-331
- Source parameter not supported, 2-69
- Spare Point Code Feature must be enabled, 2-749
- Spare Point Code Feature not compatible with TALI socket, 2-750
- Spare Point Codes not supported with adapter type, 2-749
- SPC & DPC must be the same network type, 2-615
- SPC and NSPC may not be equal, 2-612
- SPC does not exist, 2-614
- SPC may not be referenced in the STP's route table, 2-614
- SPC may not exist as a TPC or CPC in the SID table, 2-612
- SPC may not exist as a TPC, CPC, or DPC in the route table, 2-613
- SPC may not exist in the STP's route table, 2-612
- SPC must be a full point code, 2-615
- Specified GTT Set must be type of CGPC, 2-832
- Specific SSN already exists, 2-742
- Specified APPL or LOC not supported with DATA parameter, 2-629
- Specified AS name not found, 2-711
- Specified BC exceeds max allowed (96), 2-88
- Specified BPS is invalid, 2-481
- Specified card cannot be the Active MASP, 2-669
- Specified cards A, B interface IP Address must be assigned, 2-545
- Specified Fahrenheit values convert to same Celsius value, 2-854
- Specified GTT set does not exist, 2-828
- Specified LOC is invalid, 2-149
- Specified LPSET contains default values and not configurable, 2-479
- Specified MAPSET does not exist, 2-856
- Specified MRNSET does not exist, 2-839
- Specified OAP does not exist, 2-556
- Specified OAP not available, 2-554
- Specified PC must exist in MRNSET, 2-838
- Specified Port is not valid for Card and APPL Type, 2-396
- Specified UID is reserved for system use, 2-409
- Specify a single output method, 2-844
- SPLIT must be greater than CICS, 2-620
- SPLIT must be less than or equal to CICE, 2-620
- SPLIT, NCICS, NCICE are not allowed with SI unless SI is 4, 5, or 13, 2-622

- SPLIT, RC, NCICS, NCICE or attributes required, 2-622
- SR or NSR does not reference an existing SR, 2-231
- SRC and DEST must be specified, 2-90
- SRCLPSET and LPSET cannot be equal, 2-480
- SRCSET and SET cannot be equal, 2-692
- SRCTSET and TSET cannot be equal, 2-505
- SRFADDR, SRFNAI & SRFNP parameters must be entered together, 2-681
- SRI Redirect Feature must be enabled, 2-792
- SRKQ + DRKQ exceed max allowed rtkey limit, 2-625
- SRM or MRC cannot be entered for a solitary entry, 2-401
- SRM=YES cannot be entered with ITU point code types, 2-170
- SRVSEL of ITU found, but not allowed with ANSIGFLEX, 2-788
- SS7 address does not exist in X.25 destination table, 2-274
- SS7 Destination assigned to non-SS7 linkset, 2-242
- SS7 parameters cannot be specified for IP7 link, 2-597
- SS7IPGW/IPGWI cards must be inhibited to change SYNC, 2-630
- SSEL parameter requires LNP feature, 2-574
- SSN can only be specified when XLAT=DPCSSN, 2-182
- SSN cannot be specified without a point code, 2-183
- SSN does not exist for given remote point code, 2-182
- SSN for ITU-I and ITU-N True Point Codes must be the same, 2-746
- SSN is not allowed unless SI is 3, 2-592
- SSN must be 1 if NSFI=AFTPC, 2-191
- SSN must be in SS-APPL table when PC is true point code, 2-550
- SSN must be specified for new values of XLAT/RI, 2-176
- SSN must be specified when XLAT=DPCSSN, 2-191
- SSN not allowed with OPC, CICS, and CICE, 2-604
- SSN required if SI is 3, 2-588
- SSN value must be LNP SSN or INP SSN, 2-542
- SSN/TYPE combination already exists, 2-645
- SSN/TYPE combination does not exist, 2-645
- SSNE should be greater than SSN, 2-412
- SSNSELID entry already exists, 2-837
- SSNSELID entry does not exist, 2-837
- SSNSELID Table is full, 2-827
- SSNSELID table must be accessible, 2-836
- SSO parameter is not compatible with True PC, 2-504
- Standby MASP has not finished initializing, 2-158
- Standby MASP is inhibited, 2-670
- Standby MASP is isolated, 2-158
- Standby MASP is not available, 2-382
- Standby OAM must be equipped with E586 hardware, 2-521
- Standby TDM in unknown upgrade mode, 2-489
- Starting address/location must be specified, 2-418
- STIME must be earlier or equal to ETIME, 2-407
- STP options HMUXABUS or HMUXBBUS must be set=yes, 2-693
- STP True PC and EIR subsystem do not exist in MAP table, 2-743
- STP True PC and INP SSN do not exist in MAP table, 2-661
- STP True PC and LNP SSN do not exist in MAP table, 2-470
- STP True PC does not exist in MAP table, 2-469
- STPOPTS HMUXTVG must be turned on for this feature, 2-503
- String pattern nonconformance, alphabetic - <parm>, 2-16
- String pattern nonconformance, alphanumeric - <parm>, 2-16
- String pattern nonconformance, numeric - <parm>, 2-17
- SUBNETDLEN must be set before Subnet ID may be entered, 2-808
- SUBNETID already exists in SUBNETID table, 2-803
- SUBNETID does not exist in SUBNETID table, 2-804
- SUBNETID table is full, 2-803
- SUBNETIDLEN may only be changed if SUBNETID table is empty, 2-806
- Subsystem must be in opposite state of change, 2-454
- Subsystem must be inhibited before it can be deleted, 2-454
- Subsystem must be inhibited before it can be OFFLINE, 2-454
- Subsystem Relative Cost (RC) must be less than its mate, 2-402
- Subsystem table for MPC is full, 2-172

Index

- Subsystem table for primary remote point code is full, 2-180
 - Syntax Error Found, 2-601
 - System busy - Repeat later, 2-396
 - System busy - try again later, 2-145
 - System error - revert to mandatory in-pattern specification, 2-17
 - System serial number entered is invalid, 2-528
 - system serial number has not be locked, 2-459
 - System serial number is already locked in database, 2-528, 2-546
- T**
- T<#> (domain) must be between <min> and <max>, 2-389
 - T1 card location is unequipped, 2-303
 - T1 is assigned to card, 2-304
 - T1 Port test command in progress, 2-550
 - T1 Port test command not in progress, 2-690
 - T1 TS value must be specified in the range (0-23), 2-306
 - T1PORT specified by T1LOC is not equipped, 2-304
 - Table copy command already in process, 2-9
 - Table full - a maximum of 256 TYPE=SD MICs are allowed, 2-425
 - Table is full, no more entries allowed, 2-324
 - Target bus must be inhibited, 2-417
 - Target card is not a DSM card with VSCCP appl, 2-770
 - Target card is not a TSM/DSM with SCCP/VSCCP appl, 2-830
 - Target card is not in Active state, 2-771
 - Target drive capacity must be sufficient to perform request, 2-559
 - TDM does not support Global Timing Interface, 2-299
 - TELNET cannot be specified unless the IPSM card is equipped, 2-142
 - TELNET Feature must be activated first, 2-143
 - Telnet terminal TYPE can only be set to TELNET or NONE, 2-125
 - Temporary feature key is not allowed for the feature, 2-445
 - temporary key is un-available, 2-545
 - Ten GTA Lengths are supported per GTTSET, 2-688
 - Ten GTA Lengths are supported per TT, 2-687
 - Terminal already echoing to specified terminal, 2-101
 - Terminal Authority Violation, 2-3
 - Terminal Id not entered, 2-146
 - Terminal is currently inhibited, 2-100
 - Terminal is currently out of service, 2-100
 - Terminal is not equipped, 2-147, 2-157
 - Terminal temporarily disabled. Excessive LOGIN failures, 2-313
 - Terminal temporarily disabled. Excessive UNLOCK failures, 2-316
 - Terminals 1-16 cannot be set to TYPE=TELNET, 2-127
 - TFATCABMLQ is invalid for C-link sets, 2-351
 - TFATCABMLQ value exceeds number of links in link set, 2-348
 - TFATFRPR must be in increments of 100 msec, 2-370
 - The alarms are already inhibited for this device, 2-487
 - The Channel card must be on the same shelf as its E1 card., 2-704
 - The Channel card must be on the same shelf as its T1 card., 2-301
 - The CNCF feature must be on if CNCF is specified, 2-561
 - The current LSMS and the associated NSAP, PSEL and SSEL required, 2-555
 - The E1PORT at the specified location is already equipped, 2-702
 - The E1PORT at the specified location is not equipped, 2-702
 - The FEATURE/ANSIGFLEX option combination is invalid, 2-787
 - The Gateway Linkset specified already exists, 2-379
 - The Gateway Linkset table is full, 2-377
 - The GSM MAP Screening table is full, 2-653
 - The IDPS for Prepaid Feature Must be Enabled, 2-863
 - The last active serial port cannot be inhibited, 2-505
 - The linkset is provisioned locally, 2-378
 - The linkset specified does not exist in the linkset table, 2-379
 - The linkset specified is not a Gateway Linkset, 2-378
 - The maximum number of SPCs has already been defined, 2-614
 - The maximum number of users is already defined, 2-77
 - The MPC feature must be ON before ITUDUPPC can be ON, 2-642
 - The NONE value is not allowed in this case, 2-518

- The NSFI / RI combination is invalid, 2-195
- The NSFI is invalid for this screen type, 2-196
- The Prepaid IDP Query Relay Feature Must be Enabled, 2-845
- The SPC already exists, 2-613
- The specified card cannot be inhibited, 2-150
- The specified CMD cannot be assigned a configurable class, 2-810
- The specified LOC only supports SLTC loopbacks, 2-303
- The specified overload level has already been defined, 2-429
- The specified overload level is not defined, 2-420
- The specified SLC is in use, 2-45
- The specified user identification is already defined, 2-76
- The specified user identification is not defined, 2-77
- The sum of the values for NPCFMTI must be equal to 14, 2-540
- The T1PORT at the specified location is already equipped, 2-301
- The T1PORT at the specified location is not equipped, 2-302
- The terminal state request was unanswered, 2-49
- There is a link already assigned to this port, 2-46
- This command is not valid when EGTT is ON, 2-531
- This function is not yet supported, 2-189
- THRES parameter valid only with CONVERTNET/CONVERTSTP, 2-491
- Timeout, 2-415
- Timer not supported for M2PA Draft 6, 2-868
- Timer value or SRCTSET required, 2-868
- Timeslot 16 on the E1 is in use, CAS = ON not allowed, 2-703
- Timing Source must be specified if CHANBRDG=ON is specified, 2-511
- TLNP and CNCF cannot be in the same action set, 2-566
- TLNP and RDCT cannot be in the same action set, 2-566
- TLNP feature must be ON, 2-565
- To change or delete SERV, it must have no LNP aliases, 2-456
- To disable CRITALMINH, critical alarms cannot be inhibited, 2-487
- Too many associations per card, 2-714
- Too many associations per SLK, 2-714
- Too many errors in this command, 2-4
- Too many IP connection states per card, 2-831
- Too many IP connections per card, 2-589
- Too many nested cluster dstn entered, 2-337
- Too many octets specified, only require 4 - <parm>, 2-14
- too many parameters entered, 2-393
- Too many sockets per SLK, 2-597
- Total Ethernet Capacity is greater than 100% for IP Node, 2-250
- Total IPTPS for all linksets can't exceed system TPS limit, 2-769
- Translation entry already exists, 2-850
- Translation entry does not exist, 2-850
- Translation TYPE already exists, 2-185
- Translation TYPE defined as an alias, 2-185
- Translation TYPE has an alias, 2-188
- Translation Type is already in LNP database, 2-449
- Translation TYPE is referenced by GTT entry, 2-188
- Translation TYPE must be specified, 2-189
- Translation Type Name is not in the LNP database, 2-452
- Translation Type referenced in LNP database, 2-452
- Translation TYPE specified does not exist, 2-186
- Translation TYPEI already exists, 2-655
- Translation TYPEI specified does not exist, 2-657
- Translation TYPEN already exists, 2-655
- Translation TYPEN specified does not exist, 2-657
- Translation TYPEN24 already exists, 2-519
- Translation TYPEN24 specified does not exist, 2-654
- TRM must be specified, 2-394
- TRM parameter not valid for type-enttype combo, 2-117
- True PC already exists in MAP table, 2-471
- True Point Code can exist only in Default MAPSET, 2-879
- True Point Code can only have one mate, 2-404
- True Point Code may not be routed to self, 2-404
- Try Double Quoting Parameter with '_', 2-25
- TS not allowed when SEHSL feature has set Linkclass = Unchan, 2-777
- TS value on the E1 already in use by a signaling link, 2-701
- TS value on the T1 already in use by a signaling link, 2-305

Index

- TSCSYNC must be ON before E5IS can be ON, 2-674
- TSET parameter only valid if MODE = DCE, 2-46
- tt map table full for LSN specified, 2-339
- tt map table is full, 2-340
- TT Mapping is not provisioned for this link set, 2-340
- TT must be specified if PC is specified, 2-429
- TT must be specified when enttype=tt, 2-107
- TT parameter valid only when ENTTYPE=TT, 2-118
- TTA cannot be specified for a direction of ITOA, 2-721
- TTA must be specified for a direction of ATOI, 2-694
- TTI must be specified for a direction of ITOA, 2-721
- TTI, NP, NAI cannot be specified for a direction of ATOI, 2-880
- TTN already in use, 2-186
- TTN and TYPE do not correspond to each other, 2-188
- TTN specified does not exist, 2-186
- TUP must use DPC/SI route key if DPC is ANSI, 2-639
- Turn off EISCOPY before changing PVN and PVNMask, 2-552, 2-706
- Two OAP terminals are already configured, 2-327
- TYPE = SCCS and PRTY=NONE combination not allowed, 2-53
- TYPE = VT320 and PRTY=NONE combination not allowed, 2-49
- TYPE and SNUM/ENUM combination invalid, 2-754
- TYPE does not exist in given SR, 2-232
- TYPE matches existing TYPE in given SR, 2-232
- TYPE parameter value is invalid for this card, 2-734
- Unable to change adapter when assigned to an AS, 2-713
- Unable to change Network/Cluster dstn NCAI param, 2-338
- Unable to communicate with card at location, 2-105
- Unable to determine current connect status of card <card>, 2-395
- Unable to read the selected log, 2-382
- Undefined, 2-881
- Undefined msg#, 2-2
- Unexpected response message error, 2-631
- Unknown command, 2-149
- Unknown hardware configuration, 2-460
- Unknown LSN, 2-120
- Unneeded information found, 2-19
- Unrecognized command, 2-5
- Unrecognized parameter identifier, 2-7
- Unsupported Hardware is equipped in the system, 2-871
- Un-uploaded security log entries exist on standby fixed disk, 2-408
- Up to 8 SS7IPGW or IPGWI links allowed in un-mated linkset, 2-759
- Use DFILE when specifying STBL, 2-92
- Use DTBL when specifying SFILE, 2-92
- Use REPT-STAT-MPS when LNP ELAP Configuration is ON, 2-719
- Use SFILE when specifying DTBL, 2-93
- Use STBL when specifying DFILE, 2-93
- Use type=local or remove ipaddr from IPLNK table, 2-816
- Use type=remote or enter ipaddr in IPLNK table, 2-816
- User currently logged on, 2-104
- UserID already logged on (or is logging on) another terminal, 2-307
- UserID has become obsolete and cannot be used, 2-307
- UserID has been revoked, 2-307

U

- UENG parameter is invalid for this card, 2-731
- UENG register must be specified, 2-731
- UIM number does not exist in STP Trouble Text Table, 2-554
- UIM number does not exist in UIM Threshold table, 2-460
- Unable to access database. Severe database failure, 2-166
- Unable to access DB level, 2-36

V

- VCI values 0...4 and 6...31 are reserved, 2-475
- VENDID already exists in VENDID table, 2-791
- VENDID does not exist in VENDID table, 2-792
- VENDIDLEN may only be changed if VENDID table is empty, 2-793
- VENDIDLEN must be set before Vendor ID may be entered, 2-807
- Version parameter not supported for SUA or M3UA, 2-868

VGTT cannot be On if any SCCP card has a 486 processor, 2-658
 VSCCP cards have insufficient extended memory, 2-521

W

Waiting for duplex mode in provisioning subsystem, 2-79
 Warm Restart capable Feature must be enabled, 2-241
 When REXMIT=BSD is specified, an RTT cannot be assigned, 2-321
 When REXMIT=FIXED or MOD is specified, an RTT must be assigned, 2-322
 When type=DEFAULT, other allowed parameters are SNAME/LOC, 2-673
 When type=full, DPC and SI must be specified, 2-683
 When type=partial or default, specify attributes, 2-672
 When type=partial or default, SPLIT/ RESIZE are not supported, 2-672
 Wild card entries are not allowed in this command, 2-190
 Wildcard SSN already exists, 2-742
 Wildcard/Asterisk combination invalid for direction, 2-722
 Wildcard/Asterisk invalid for direction of BOTH, 2-722
 Wildcard/Asterisk required for TTI, NP, NAI if DIR is ITOA, 2-722
 WNP feature must be ON, 2-557
 WSMSC feature must be Activated, 2-549

X

X.25 address already exists in X.25 destination table, 2-269
 X.25 address cannot be referenced by route, 2-269
 X.25 address does not exist in X.25 destination table, 2-270
 X.25 Address must contain at least four digits, 2-266
 X.25 Destination assigned to non-X.25 linkset, 2-242
 X.25 destination table is full, 2-270
 X.25 mode parameter requires SEAS feature, 2-573
 X.25 packet size parameter requires SEAS feature, 2-573

X.25 route table is full, 2-278
 X25G Feature must be ON before X252000 can be ON, 2-626
 XGTT requires at least a 586 processor for SCCP GPLs, 2-442
 XGTT requires both OAMs running on GPSPMII cards, 2-443
 XGTT with 1 million entries requires DSM cards for SCCP GPLs, 2-443
 XLAT must be DPCSSN and RI must be SSN if PC is the True PC, 2-557
 X-LIST DPC is not allowed, 2-52
 XMAP requires at least a 586 processor for SCCP GPLs, 2-444
 XMAP requires both OAMs running on GPSPMII cards, 2-444