



# Sun StorEdge™ 6920 System Site Preparation Guide

---

Sun Microsystems, Inc.  
www.sun.com

Part No. 819-0118-10  
May 2005  
Revision A

Submit comments about this document at: <http://www.sun.com/hwdocs/feedback>

Copyright © 2005 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, U.S.A. All rights reserved.

THIS PRODUCT CONTAINS CONFIDENTIAL INFORMATION AND TRADE SECRETS OF SUN MICROSYSTEMS, INC. USE, DISCLOSURE OR REPRODUCTION IS PROHIBITED WITHOUT THE PRIOR EXPRESS WRITTEN PERMISSION OF SUN MICROSYSTEMS, INC.

Use is subject to license terms.

This distribution may include materials developed by third parties.

Sun, Sun Microsystems, the Sun logo, Java, Jiro, Netra, Solaris, and Sun StorEdge are trademarks or registered trademarks of Sun Microsystems, Inc. in the U.S. and other countries.

Legato and the Legato logo are registered trademarks, and Legato NetWorker are trademarks or registered trademarks of Legato Systems, Inc.

Products covered by and information contained in this service manual are controlled by U.S. Export Control laws and may be subject to the export or import laws in other countries. Nuclear, missile, chemical biological weapons or nuclear maritime end uses or end users, whether direct or indirect, are strictly prohibited. Export or reexport to countries subject to U.S. embargo or to entities identified on U.S. export exclusion lists, including, but not limited to, the denied persons and specially designated nationals lists is strictly prohibited.

Use of any spare or replacement CPUs is limited to repair or one-for-one replacement of CPUs in products exported in compliance with U.S. export laws. Use of CPUs as product upgrades unless authorized by the U.S. Government is strictly prohibited.

DOCUMENTATION IS PROVIDED "AS IS" AND ALL EXPRESS OR IMPLIED CONDITIONS, REPRESENTATIONS AND WARRANTIES, INCLUDING ANY IMPLIED WARRANTY OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT, ARE DISCLAIMED, EXCEPT TO THE EXTENT THAT SUCH DISCLAIMERS ARE HELD TO BE LEGALLY INVALID.

---

Copyright © 2005 Sun Microsystems, Inc., 4150 Network Circle, Santa Clara, California 95054, Etats-Unis. Tous droits réservés.

CE PRODUIT CONTIENT DES INFORMATIONS CONFIDENTIELLES ET DES SECRETS COMMERCIAUX DE SUN MICROSYSTEMS, INC. SON UTILISATION, SA DIVULGATION ET SA REPRODUCTION SONT INTERDITES SANS L'AUTORISATION EXPRESSE, ECRITE ET PREALABLE DE SUN MICROSYSTEMS, INC.

L'utilisation est soumise aux termes de la Licence.

Cette distribution peut comprendre des composants développés par des tierces parties.

Sun, Sun Microsystems, le logo Sun, Java, Jiro, Netra, Solaris, et Sun StorEdge sont des marques de fabrique ou des marques déposées de Sun Microsystems, Inc. aux Etats-Unis et dans d'autres pays.

Ce produit est soumis à la législation américaine en matière de contrôle des exportations et peut être soumis à la réglementation en vigueur dans d'autres pays dans le domaine des exportations et importations. Les utilisations, ou utilisateurs finaux, pour des armes nucléaires, des missiles, des armes biologiques et chimiques ou du nucléaire maritime, directement ou indirectement, sont strictement interdites. Les exportations ou reexportations vers les pays sous embargo américain, ou vers des entités figurant sur les listes d'exclusion d'exportation américaines, y compris, mais de manière non exhaustive, la liste de personnes qui font objet d'un ordre de ne pas participer, d'une façon directe ou indirecte, aux exportations des produits ou des services qui sont régis par la législation américaine en matière de contrôle des exportations et la liste de ressortissants spécifiquement désignés, sont rigoureusement interdites.

L'utilisation de pièces détachées ou d'unités centrales de remplacement est limitée aux réparations ou à l'échange standard d'unités centrales pour les produits exportés, conformément à la législation américaine en matière d'exportation. Sauf autorisation par les autorités des Etats-Unis, l'utilisation d'unités centrales pour procéder à des mises à jour de produits est rigoureusement interdite.

LA DOCUMENTATION EST FOURNIE "EN L'ETAT" ET TOUTES AUTRES CONDITIONS, DECLARATIONS ET GARANTIES EXPRESSES OU TACITES SONT FORMELLEMENT EXCLUES, DANS LA MESURE AUTORISEE PAR LA LOI APPLICABLE, Y COMPRIS NOTAMMENT TOUTE GARANTIE IMPLICITE RELATIVE A LA QUALITE MARCHANDE, A L'APTITUDE A UNE UTILISATION PARTICULIERE OU A L'ABSENCE DE CONTREFACON.



Please  
Recycle



Adobe PostScript

# Contents

---

**Preface** vii

**Site Preparation and Planning** 1

Customer Obligations 1

Safety Information 2

    Handling Precautions 2

    Secure Installation Requirements 3

    Placement of a Sun Product 3

Facility Requirements 3

    Environmental Requirements 4

    Recommended Operating Environment 4

    Electrical and Power Specifications 5

    Physical Specifications 5

        Physical Dimensions 6

        Clearance and Service Access 6

Cabling Requirements 6

Collecting System Information 7

Planning Your Storage Configuration 9



# Tables

---

TABLE 1	Facility Environmental Specifications	4
TABLE 2	Facility Optimal Environmental Specifications	4
TABLE 3	Power Specifications for Each Cabinet	5
TABLE 4	System Physical Specifications	6
TABLE 5	Clearance and Service Access for the Base Cabinet	6
TABLE 6	Cable Specifications	7
TABLE 7	Default Storage Configuration and Configuration Options	9



# Preface

---

The *Sun StorEdge™ 6920 System Site Preparation Guide* describes facility physical, electrical, and environmental requirements for installing a Sun StorEdge™ 6920 system. Follow the guidelines as outlined in this document when planning your installation.

---

## Sun StorEdge 6920 System Documentation

The following is a list of documents related to the Sun StorEdge 6920 system. For any document number with *nn* as a suffix, use the most current document.

<b>Subject</b>	<b>Title</b>	<b>Part Number</b>
Unpacking instructions attached to the shipping container	<i>Unpacking Guide</i>	816-8365- <i>nn</i>
System regulatory and safety information	<i>Sun StorEdge 6920 System Regulatory and Safety Compliance Manual</i>	819-0119- <i>nn</i>
System installation and initial configuration information	<i>Sun StorEdge 6920 System Getting Started Guide</i>	819-0117- <i>nn</i>
Late-breaking information not included in the information set	<i>Sun StorEdge 6920 System Release Notes</i>	819-0120- <i>nn</i>

System overview information, as well as information on system configuration, maintenance, and basic troubleshooting, is covered in the online help included with the software. In addition, the `sscs(1M)` man page provides information about the commands used to manage storage using the command-line interface (CLI).

---

## Related Documentation

The following documents provide detailed information, if needed, about system components.

<b>Product</b>	<b>Title</b>	<b>Part Number</b>
Best practices	<i>Best Practices for Sun StorEdge 6920 System (Version 3.0.0)</i>	819-0122- <i>nn</i>
Sun StorEdge network Fibre Channel switch-8 and switch-16	<i>Sun StorEdge Network 2Gb FC Switch-8 and Switch-16 FRU Installation</i>	817-0064- <i>nn</i>
	<i>Sun StorEdge Network 2 Gb FC Switch-8 and Switch-16 Release Notes</i>	817-0770- <i>nn</i>
	<i>Sun StorEdge Network 2 Gb FC Switch-64 Release Notes</i>	817-0977- <i>nn</i>
Sun StorEdge Brocade switch documentation	<i>Sun StorEdge Network 2 Gb Brocade SilkWorm 3200, 3800, and 12000 Switch 3.1/4.1 Firmware Guide to Documentation</i>	817-0062- <i>nn</i>
Sun StorEdge McData switch documentation	<i>Sun StorEdge Network 2 Gb McDATA Intrepid 6064 Director Guide to Documentation, Including Firmware 5.01.00</i>	817-0063- <i>nn</i>
Expansion cabinet	<i>Sun StorEdge Expansion Cabinet Installation and Service Manual</i>	805-3067- <i>nn</i>
Storage Service Processor	<i>Sun Fire V210 and V240 Server Administration Guide</i>	816-4826- <i>nn</i>
Solaris Operating System	<i>Solaris Handbook for Sun Peripherals</i>	816-4468- <i>nn</i>

---

## Accessing Sun Documentation

You can view, print, or purchase a broad selection of Sun documentation, including localized versions, at:

<http://www.sun.com/documentation>

For Sun StorEdge 6920 system documentation, go to:

[http://www.sun.com/products-n-solutions/hardware/docs/Network\\_Storage\\_Solutions/Midrange/6920/index.html](http://www.sun.com/products-n-solutions/hardware/docs/Network_Storage_Solutions/Midrange/6920/index.html)

---

## Related Third-Party Documentation

For installation instructions and other information about Brocade and McData Fibre Channel switches, refer to the product documentation provided by the vendor.

---

## Third-Party Web Sites

Sun is not responsible for the availability of third-party web sites mentioned in this document. Sun does not endorse and is not responsible or liable for any content, advertising, products, or other materials that are available on or through such sites or resources. Sun will not be responsible or liable for any actual or alleged damage or loss caused by or in connection with the use of or reliance on any such content, goods, or services that are available on or through such sites or resources.

---

## Contacting Sun Technical Support

If you have technical questions about this product that are not answered in this guide, go to:

<http://www.sun.com/service/contacting>

---

## Sun Welcomes Your Comments

Sun is interested in improving its documentation and welcomes your comments and suggestions. You can submit your comments by going to:

<http://www.sun.com/hwdocs/feedback>

Please include the title and part number of this document with your feedback:

*Sun StorEdge 6920 System Site Preparation Guide*, part number 819-0118-10

# Site Preparation and Planning

---

This document provides the information you need to prepare your site before installing the Sun StorEdge™ 6920 system. Follow the guidelines as outlined in this document when planning your installation.

To determine the complete list of components and storage systems your shipment will include, consult your local Sun sales representative.

For a product overview and installation instructions, refer to the *Sun StorEdge 6920 System Getting Started Guide*.

This document contains the following sections:

- [“Customer Obligations” on page 1](#)
- [“Safety Information” on page 2](#)
- [“Facility Requirements” on page 3](#)
- [“Cabling Requirements” on page 6](#)
- [“Collecting System Information” on page 7](#)
- [“Planning Your Storage Configuration” on page 9](#)

---

## Customer Obligations

The customer is obliged to inform Sun Microsystems, Inc. of any and all ordinances and regulations that might affect the installation. The customer is responsible for meeting all government codes and regulations concerning facilities. The customer is also required to do the following:

- Comply with all local, national, and international codes covered in this specification. The subjects covered include fire and safety, building, and electrical codes.

- Document and inform Sun Microsystems, Inc. of any deviations from this specification.

---

## Safety Information

Install the Sun StorEdge 6920 system in accordance with the local safety codes and regulations at the facility site. Make sure that you read the safety precautions in the *Sun StorEdge 6920 System Regulatory and Safety Compliance Manual*. The following sections contain additional safety information for the local facility:

- [“Handling Precautions” on page 2](#)
- [“Secure Installation Requirements” on page 3](#)
- [“Placement of a Sun Product” on page 3](#)

---

**Note** – Do not make mechanical or electrical modifications to the equipment. Sun Microsystems, Inc. is not responsible for regulatory compliance of a modified Sun product.

---

## Handling Precautions



---

**Caution** – A fully configured Sun StorEdge 6920 system cabinet can weigh in excess of 1400 pounds (627 kg). Ensure that all surfaces this system will move over can withstand this load.

---

The cabinet is equipped with wheels so that you can move it. Use enough personnel when moving the cabinet, especially on sloped loading docks and ramps, to gain access to a raised computer room floor. Move the cabinet slowly and deliberately, and make sure that the floor is free from foreign objects and cables that the cabinet could roll over.



---

**Caution** – To avoid injury, wear protective footwear when moving a system.

---

# Secure Installation Requirements

To minimize personnel injury in the event of a seismic occurrence, you must securely fasten the cabinet to a rigid structure extending from the floor to the ceiling, or from the walls, of the room in which the cabinet is located.

Install the cabinet on a level surface. At each corner, on the base of the cabinet, are adjustable nonskid pads. Extend these pads when the cabinet is installed to prevent the cabinet from rolling. Do not use these pads to level the cabinet.

## Placement of a Sun Product

If you have ordered a Sun StorEdge 6920 system without an expansion cabinet, make sure you allow enough room to install a second or third cabinet in the event that you want to expand your system.



---

**Caution** – Do not block or cover the openings of your Sun product. Never place a Sun product near a radiator or heat register. Failure to follow these guidelines can cause overheating and affect the reliability of your Sun product.

---

Air cools the Sun StorEdge 6920 system cabinets from front to back. Air enters at the front, circulates, and is expelled at the back of the cabinet. The front and back door clearances provide sufficient space for cooling. See [TABLE 5](#) for specific clearance specifications.

---

## Facility Requirements

This section contains the following information about the facility requirements for the Sun StorEdge 6920 system:

- [“Environmental Requirements” on page 4](#)
- [“Recommended Operating Environment” on page 4](#)
- [“Electrical and Power Specifications” on page 5](#)
- [“Physical Specifications” on page 5](#)

# Environmental Requirements

The environmental requirements in [TABLE 1](#) are the limits to which the systems are tested to ensure that they meet all functional requirements.

**TABLE 1** Facility Environmental Specifications

Specifications	Operating	Nonoperating
Temperature	41°F to 95°F (5°C to 35°C) noncondensing	-40°F to -76°F (-40°C to -60°C) noncondensing
Relative humidity	10% to 90% noncondensing maximum gradient 10% per hour	93% noncondensing maximum gradient 10% per hour
Altitude	9,840 feet (3,000 meters)	39,370 feet (12,000 meters)

Avoid temperature extremes and keep the work area clean. Maintain the operating conditions described in [TABLE 2](#). The storage system typically resides in a computer room environment that provides control over environmental factors such as temperature, humidity, and airborne dust. A computer room installation can also help protect equipment from fire, flood, or other danger originating in the building.

## Recommended Operating Environment

The operating environmental limits in [TABLE 1](#) reflect what the systems have been tested to, in order to meet all functional requirements. The optimum operating condition in [TABLE 2](#) is the recommended operating environment. Operating computer equipment for extended periods of time at or near the temperature or humidity extremes is known to significantly increase the failure rate of hardware components. To minimize any chance of down time due to component failure, plan to use the optimal temperature and humidity ranges.

**TABLE 2** Facility Optimal Environmental Specifications

Environmental Factor	Ambient Temperature Range	Ambient Relative Humidity
Operating	70°F to 73.5°F (21°C to 23°C)	45% to 50%

# Electrical and Power Specifications

All Sun StorEdge 6920 systems require two independent power sources. Each storage system cabinet has two power conditioners for redundancy mounted in the base of the cabinet. To maintain the power redundancy, each conditioner must be connected to an independent power source. [TABLE 3](#) lists the power required for each conditioner.

**TABLE 3** Power Specifications for Each Cabinet

Specification	Rating
AC voltage rating	200 to 240 VAC
AC voltage range	180 to 264 VAC
Frequency range	50 to 60 Hz single phase
Current at 240 VAC	32A
Power consumption, maximum:	
• Sun StorEdge 6920 system, base cabinet	4.2 kW
• Sun StorEdge 6920 system with one expansion cabinet	8.4 kW
• Sun StorEdge 6920 system with two expansion cabinets	12.6 kW

The following is recommended for all installations:

- All AC mains and supply conductors to power distribution boxes for the system cabinet must be enclosed in a metal conduit or raceway, when specified by local, national, and/or other applicable government codes and regulations. The supply conductors and power distribution boxes (or equivalent metal enclosures) must be grounded at both ends.
- The supplied storage systems require voltages within minimum fluctuation. The facilities voltage at the customer facility must not vary by more than (+/-) 5%.
- The customer facilities must provide suitable surge protection.

## Physical Specifications

This section contains the physical requirements for the Sun StorEdge 6920 system.

## Physical Dimensions

The values given in [TABLE 4](#) are for the maximum hardware configuration.

**TABLE 4** System Physical Specifications

System	Height	Width	Depth	Weight
Sun StorEdge 6920 system, base cabinet	75 in. 190.5 cm	23.9 in. 60.7 cm	37 in. 94 cm	1465 lb. 665 kg
Sun StorEdge 6920 system with one expansion cabinet	75 in. 190.5 cm	47.8 in. 121.4 cm	37 in. 94 cm	3000 lb. 1364 kg
Sun StorEdge 6920 system with two expansion cabinets	75 in. 190.5 cm	71.7 in. 182.1 cm	37 in. 94 cm	4550 lb. 2068 kg

## Clearance and Service Access

[TABLE 5](#) provides front and back physical clearance requirements for servicing the components in the base cabinet. The diagnostic and monitoring software has service procedures provided by the Service Advisor that you can access when you are logged in to the system. For information about how to access the Service Advisor, see the *Sun StorEdge 6920 System Getting Started Guide* and online help system.

**TABLE 5** Clearance and Service Access for the Base Cabinet

Access Location	Clearance Needed
Front	48 in. 122 cm
Back	36 in. 92 cm

---

## Cabling Requirements

When cabling the system, follow these guidelines:

- Keep the power and interface cables clear of walkways. Route cables inside walls, under the floor, through the ceiling, or in protective channels or raceways. Route interface cables (excluding fiber-optic cables) away from motors and other sources of magnetic or radio frequency interference.

- Do not exceed cable length limitations. [TABLE 6](#) shows the cable specifications and lengths.

**TABLE 6** Cable Specifications

Cable Type	Connector	Maximum Length
Shielded Ethernet, 10/100BASE-T, category 5	RJ-45	328.084 ft. (100 m)
Serial (Available only to qualified field service representatives)	RJ-45	82.021 ft. (25 m)
Power (220V)	Standard	Not applicable

The power cables are the standard cables shipped with the Sun StorEdge 6920 system. The cables that connect two cabinets together are standard Fibre Channel (FC) cables.

---

## Collecting System Information

Before beginning the installation, prepare the site and gather the information that you will need to perform the installation. To do this, refer to the worksheet on page 8.



---

**Caution** – The Sun StorEdge 6920 system uses the private network addresses 10.0.0.x and 192.168.0.x. Therefore, do not use these addresses when connecting directly to the Sun StorEdge 6920 system. If your network uses these addresses, ensure that they are behind a firewall, as dictated by the network RFCs.

---

Use this worksheet to collect the information you will need during the system installation.

<b>Sun StorEdge 6920 System Configuration Worksheet</b>	
	<b>Sun StorEdge 6920 system ID:</b> (0–7) _____
	<b>Sun StorEdge 6920 system IP address:</b> _____
	<b>Gateway IP address:</b> _____
	<b>Sun StorEdge 6920 system network mask:</b> _____
	<b>IP Address of the domain name service (DNS):</b> _____
	<b>Name server domain name:</b> _____
	<b>Email notification address:</b> _____
	<b>Telephone number (analog phone line for remote monitoring):</b> _____
	<b>Site address:</b> _____
	<b>Host IP address (another host on your network):</b> _____
	<b>Host bus adapter (HBA) WWNs:</b> _____

---

# Planning Your Storage Configuration

After you collect the information you will need and before you actually configure the system, you must determine how to configure your Sun StorEdge 6920 system according to your site requirements.

Use [TABLE 7](#) as a guide for planning your site storage configuration.

For more information about specific features and configuration options, see the *Sun StorEdge 6920 System Getting Started Guide* and the online help system.

**TABLE 7** Default Storage Configuration and Configuration Options

Storage Component	Default Configuration	Configuration Options
Storage domains	All storage elements are initially located in one storage domain (DEFAULT), which can be accessed by all hosts (initiators). This storage domain contains the Default storage pool with its associated disks and virtual disks.	You can choose either of the following options: <ul style="list-style-type: none"><li>• Use the existing default configuration (as is).</li><li>• Create a custom storage domain.</li></ul>
Storage profiles	The default storage domain uses the Default profile to specify its storage parameters. The default storage profile is: RAID level: RAID-5 Segment size: 64 Kbyte Read-ahead mode: On Number of drives: Variable Array type: Best Available Match: Bandwidth Number of disks: Variable Dedicated hot spare: No Virtualization strategy: Stripe Stripe size: 1 Mbyte  Note: You cannot delete any of the predefined profiles, including the Default profile. Additionally, you cannot delete or modify a profile that is in use and already associated with a storage pool.	You can choose any of the following options: <ul style="list-style-type: none"><li>• Use the existing default configuration (as is).</li><li>• Select one of the predefined storage profiles shipped with the system to create a new storage pool.</li><li>• Create a custom storage profile.</li></ul>

**TABLE 7** Default Storage Configuration and Configuration Options (*Continued*)

<b>Storage Component</b>	<b>Default Configuration</b>	<b>Configuration Options</b>
Storage pools	All virtual disks are initially in one storage pool (Default).	You can choose either of the following options: <ul style="list-style-type: none"><li>• Use the existing default configuration (as is).</li><li>• Create a new storage pool and reassign some of the virtual disks to the new storage pool.</li></ul>
Virtual disks	Virtual disks are preconfigured based on the number of drives ordered for your system. The virtual disks are configured as RAID-5. If an array has 7 drives per tray, all 7 drives are configured as a single RAID-5 virtual disk. If an array has 14 drives, the tray is configured as two RAID-5 virtual disks.	You can choose any of the following options: <ul style="list-style-type: none"><li>• Use the existing default configuration (as is).</li><li>• Move an existing, unused virtual disk to a different storage pool that has similar attributes.</li><li>• Delete an existing RAID-5 virtual disk and reconfigure the disks into a new virtual disk in another storage pool with a different storage profile.</li></ul>
Volumes	The default configuration does not include predefined volumes.	You must configure volumes.