

Sun Server X3-2 (formerly Sun Fire X4170 M3)

Site Planning Guide



Part No.: E22358-06
December 2012

Copyright © 2012, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related software documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications which may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Copyright © 2012, Oracle et/ou ses affiliés. Tous droits réservés.

Ce logiciel et la documentation qui l'accompagne sont protégés par les lois sur la propriété intellectuelle. Ils sont concédés sous licence et soumis à des restrictions d'utilisation et de divulgation. Sauf disposition de votre contrat de licence ou de la loi, vous ne pouvez pas copier, reproduire, traduire, diffuser, modifier, breveter, transmettre, distribuer, exposer, exécuter, publier ou afficher le logiciel, même partiellement, sous quelque forme et par quelque procédé que ce soit. Par ailleurs, il est interdit de procéder à toute ingénierie inverse du logiciel, de le désassembler ou de le décompiler, excepté à des fins d'interopérabilité avec des logiciels tiers ou tel que prescrit par la loi.

Les informations fournies dans ce document sont susceptibles de modification sans préavis. Par ailleurs, Oracle Corporation ne garantit pas qu'elles soient exemptes d'erreurs et vous invite, le cas échéant, à lui en faire part par écrit.

Si ce logiciel, ou la documentation qui l'accompagne, est concédé sous licence au Gouvernement des Etats-Unis, ou à toute entité qui délivre la licence de ce logiciel ou l'utilise pour le compte du Gouvernement des Etats-Unis, la notice suivante s'applique:

U.S. GOVERNMENT END USERS. Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

Ce logiciel ou matériel a été développé pour un usage général dans le cadre d'applications de gestion des informations. Ce logiciel ou matériel n'est pas conçu ni n'est destiné à être utilisé dans des applications à risque, notamment dans des applications pouvant causer des dommages corporels. Si vous utilisez ce logiciel ou matériel dans le cadre d'applications dangereuses, il est de votre responsabilité de prendre toutes les mesures de secours, de sauvegarde, de redondance et autres mesures nécessaires à son utilisation dans des conditions optimales de sécurité. Oracle Corporation et ses affiliés déclinent toute responsabilité quant aux dommages causés par l'utilisation de ce logiciel ou matériel pour ce type d'applications.

Oracle et Java sont des marques déposées d'Oracle Corporation et/ou de ses affiliés. Tout autre nom mentionné peut correspondre à des marques appartenant à d'autres propriétaires qu'Oracle.

Intel et Intel Xeon sont des marques ou des marques déposées d'Intel Corporation. Toutes les marques SPARC sont utilisées sous licence et sont des marques ou des marques déposées de SPARC International, Inc. AMD, Opteron, le logo AMD et le logo AMD Opteron sont des marques ou des marques déposées d'Advanced Micro Devices. UNIX est une marque déposée d'The Open Group.

Ce logiciel ou matériel et la documentation qui l'accompagne peuvent fournir des informations ou des liens donnant accès à des contenus, des produits et des services émanant de tiers. Oracle Corporation et ses affiliés déclinent toute responsabilité ou garantie expresse quant aux contenus, produits ou services émanant de tiers. En aucun cas, Oracle Corporation et ses affiliés ne sauraient être tenus pour responsables des pertes subies, des coûts occasionnés ou des dommages causés par l'accès à des contenus, produits ou services tiers, ou à leur utilisation.



Adobe PostScript

Contents

Using This Documentation v

Preparing the Site for Installation 1

Server Specifications 1

Physical Specifications 2

Environmental Specifications 3

Minimum Clearance for Service Access 3

Power Source Requirements 4

Agency Compliance Specifications 4

Preparing the Facility 5

Operating Environment Requirements 6

Electrical Power 6

Optimal Ambient Temperature 7

Optimal Ambient Relative Humidity 7

Airflow Considerations 7

Heat Dissipation Calculation 8

Using This Documentation

This document provides specifications and site requirements for planning the installation of the Sun Server X3-2.

Note – The Sun Server X3-2 was formerly named the Sun Fire X4170 M3 server. This former name might still appear in the software. The new product name does not indicate any change in system features or functionality.

It is intended for system administrators, network administrators, and service technicians who have an understanding of server systems.

This section describes how to get the latest software and firmware, documentation and feedback, and support and accessibility information.

- [“About this Documentation” on page v](#)
- [“Related Documentation” on page vi](#)
- [“Feedback” on page vi](#)
- [“Support and Accessibility” on page vi](#)

About this Documentation

This documentation set is available in both PDF and HTML formats. The information is presented in topic-based organization (similar to online help) and therefore does not include chapters, appendices, or section numbering.

A PDF version that includes all information on a particular subject (such as hardware installation or product notes) can be generated by clicking the PDF button in the upper left corner of the HTML page.

Related Documentation

Documentation	Link
All Oracle documentation	http://www.oracle.com/documentation
Sun Server X3-2	http://www.oracle.com/pls/topic/lookup?ctx=SunServerX3-2
Oracle Integrated Lights Out Manager (ILOM) 3.1	http://www.oracle.com/pls/topic/lookup?ctx=ilom31

Feedback

You can provide feedback on this documentation at:

<http://www.oracle.com/goto/docfeedback>

Support and Accessibility

Description	Links
Access electronic support through My Oracle Support	http://support.oracle.com For hearing impaired: http://www.oracle.com/accessibility/support.html
Learn about Oracle's commitment to accessibility	http://www.oracle.com/us/corporate/accessibility/index.html

Preparing the Site for Installation

Note – The Sun Server X3-2 was formerly named the Sun Fire X4170 M3 server. This former name might still appear in the software. The new product name does not indicate any change in system features or functionality.

These sections provide the specifications and site requirements for planning the installation of the Sun Server X3-2.

Note – For safety and compliance information, refer to the online *Sun Server X3-2 Safety and Compliance Guide*, and to the *Important Safety Information for Sun Hardware Systems* that came with your server.

Description	Links
Review the server’s specifications.	“Server Specifications” on page 1
Prepare the facility for server installation.	“Preparing the Facility” on page 5

Related Information

- [Sun Server X3-2 Installation Guide, “About the Installation Procedure” on page 1](#)

Server Specifications

Review the following server specifications before preparing the facility for installation.

- [“Physical Specifications” on page 2](#)
- [“Environmental Specifications” on page 3](#)
- [“Minimum Clearance for Service Access” on page 3](#)

- [“Power Source Requirements”](#) on page 4
- [“Agency Compliance Specifications”](#) on page 4

Physical Specifications

Dimension	Server Specification	Measurements
Width	With bezel	18.9 inches (482.4 mm)
	Server chassis	17.19 inches (436.5 mm)
Depth	Maximum overall	29 inches (737 mm)
Height	1-rack unit (1U) nominal	1.68 inches (42.6 mm)
Weight	Fully populated server	36.1 lbs (16.4 kg)

Related Information

- [“Minimum Clearance for Service Access”](#) on page 3
- [Sun Server X3-2 Installation Guide, “Rack Requirements”](#) on page 20

Environmental Specifications

Specification	Operating	Nonoperating
Ambient temperature (Does not apply to removable media)	<ul style="list-style-type: none"> Maximum range: 41°F to 95°F (5°C to 35°C) up to 2,953 feet (900 meters) Optimal: 69.8°F to 73.4°F (21°C to 23°C) <p>Note - Maximum ambient operating temperature is derated by 1 degree C per 300 meters of elevation beyond 900 meters, up to a maximum altitude of 3,000 meters.</p>	-40°F to 158°F (-40°C to 70°C)
Relative humidity	<ul style="list-style-type: none"> 10% to 90% noncondensing, short term 25°F to 113°F (-5°C to 55°C) 5% to 90% noncondensing, but not to exceed 0.024 kg of water per kg of dry air (0.053 lbs water/2.205 lbs dry air) 	Up to 93% noncondensing 100.4° (37.7°C) maximum wet bulb
Altitude	<p>Up to 9,840 feet (3,000 meters) maximum ambient temperature is derated by 1°C per 300 meters above 900 meters.</p> <p>Note - In China markets, regulations may limit installations to a maximum altitude of 6,562 feet (2,000 meters).</p>	Maximum 39,370 feet (12,000 meters)
Acoustic Noise	<ul style="list-style-type: none"> Maximum condition: 7.91 Bels A weighted Idle condition: 5.28 Bels A weighted 	Not applicable

Related Information

- [“Operating Environment Requirements” on page 6](#)
- [“Airflow Considerations” on page 7](#)
- [Sun Server X3-2 Installation Guide, “About the Installation Procedure” on page 1](#)

Minimum Clearance for Service Access

Description	Specification
Clearance, front of server	48.5 inches (123.2 cm)
Clearance, rear of server	36 inches (91 cm)

Related Information

- “Physical Specifications” on page 2
- *Sun Server X3-2 Installation Guide*, “Rack Requirements” on page 20

Power Source Requirements

The server uses AC power. The values in the following table are the power supply specifications.

Note – The power dissipation numbers listed in the following table are the maximum rated power numbers for the power supply used in the system. The numbers are not a rating of the actual power consumption of the system. For up-to-date information about the power consumption, go to the Oracle web site and navigate to the product page: <http://www.oracle.com>

Parameter	AC Requirement
Voltage (nominal)	100 to 127/200 to 240 VAC (90 to 132/180 to 264 VAC ranges)
Input current (maximum)	7.2 A @ 100-127 VAC; 3.4 A @ 200-240 VAC (720 VA)
Frequency (nominal)	50/60 Hz (47 to 63 Hz range)

Related Information

- “Electrical Power” on page 6
- *Sun Server X3-2 Installation Guide*, “Server Components” on page 6

Agency Compliance Specifications

The server complies with the following specifications.

Category	Relevant Standards
Safety	UL/CSA-60950-1, 2nd Edition, 2007-03-27 EN60950-1:2006 +A11:2009 +A1:2010 +A12:2011 IEC60950-1:2005 +A1:2009 CB Scheme with all country deviations CNS14336-1 GB4943
Ergonomics	EK1-ITB-2000
EMI	EN55022:2006 +A1:2007/CISPR22:2008 Class A 47 CFR 15B Class A ICES-003 Class A VCCI Class A AS/NZ 3548 Class A CNS 13438 Class A GB9254 Class A EN61000-3-2 GB17625.1 EN61000-3-3
Immunity	EN55024:2010 IEC 61000-4-2 Electrostatic discharge IEC 61000-4-3 RF E-field immunity IEC 61000-4-4 Electrical Fast Transient/Burst IEC 61000-4-5 Surge IEC 61000-4-6 RF-Conducted immunity IEC 61000-4-8 Power frequency magnetic field immunity IEC 61000-4-11 Voltage dips, short interruptions
Regulatory markings	CE, FCC, ICES-003, C-tick, VCCI, GOST-R, BSMI, KCC, UL/cUL, UL/S-mark, CCC

Related Information

- *Sun Server X3-2 Safety and Compliance Manual*

Preparing the Facility

Follow these requirements and considerations when preparing the facility for the server.

- [“Operating Environment Requirements” on page 6](#)
- [“Electrical Power” on page 6](#)
- [“Optimal Ambient Temperature” on page 7](#)
- [“Optimal Ambient Relative Humidity” on page 7](#)
- [“Airflow Considerations” on page 7](#)
- [“Heat Dissipation Calculation” on page 8](#)

Related Information

- [“Server Specifications” on page 1](#)
- [Sun Server X3-2 Installation Guide, “About the Installation Procedure” on page 1](#)

Operating Environment Requirements

Your environmental control system must provide intake air for the server that complies with the limits specified in [“Environmental Specifications” on page 3](#).

To avoid overheating, *do not* direct warmed air toward these areas of the server:

- The front air intake of the server
- The server access panels

Note – When you receive your server, place it in the environment in which you will install it. Leave the server in its shipping crate at its final destination for 24 hours. This resting period prevents thermal shock and condensation.

Operating computer equipment in extremes of temperature or humidity increases the failure rate of hardware components. To minimize the chance of component failure, use the server within the optimal temperature and humidity ranges.

Electrical Power

Connect each power supply to a separate circuit if possible. This redundancy enables the server to remain operational if one of the circuits fails. Consult your local electrical codes for any additional requirements.

Related Information

- [“Power Source Requirements” on page 4](#)

Optimal Ambient Temperature

An ambient temperature range of 69.8°F (21°C) to 73.4°F (23°C) is optimal for server reliability. At 71.6°F (22°C) it is easy to maintain safe relative humidity levels. Operating in this temperature range provides a buffer if the environmental support systems fail.

Related Information

- [“Operating Environment Requirements” on page 6](#)

Optimal Ambient Relative Humidity

Ambient relative humidity levels between 45 percent and 50 percent are the most suitable for server operation in order to:

- Prevent corrosion
- Provide an operating time buffer in the event of environmental control system failure
- Help avoid failures caused by the intermittent interference from static discharges that occur when relative humidity is too low

Electrostatic discharge (ESD) is easily generated and less easily dissipated in areas where the relative humidity level is below 35 percent. ESD risk becomes critical when levels drop below 30 percent.

Related Information

- [“Operating Environment Requirements” on page 6](#)

Airflow Considerations

Optimize airflow and cooling by reviewing the following list of considerations.

- Ensure unobstructed airflow through the chassis. The server uses internal blowers that can achieve a total airflow of 100 CFM in normal operating conditions.
- Ensure that inlet air enters at the front of the server and exits from the back.
- Ensure that ventilation openings such as cabinet doors, for both the inlet and exhaust of the server, provide a minimum open area of 17.75 inches² (45.1 cm²) each. This size is equivalent to a 60 percent open area perforation pattern across

the front and rear area of the server that measures 17.4 inches x 1.75 inches (442 mm x 43 mm). You must evaluate the impact of other open area characteristics that are more restrictive.

- Ensure that front and rear clearance of the server allow a minimum of 0.2 in. (5 mm) at the front of the server and 3.15 in. (80 mm) at the rear of the server when mounted. These clearance values are based on the inlet and exhaust impedance (available open area) stated above and assume a uniform distribution of the open area across the inlet and exhaust areas. These values also improve cooling performance.

Note – The combination of inlet and exhaust restrictions such as cabinet doors and the spacing of the server from the doors can affect the cooling performance of the server. You must evaluate these restrictions. Server placement is particularly important for high-temperature environments.

- Take care to prevent recirculation of exhaust air within a rack or cabinet.
- Manage cables to minimize interference with the server exhaust vent.
- Ensure that air temperature rise through the server is no greater than 68°F (20°C).

Related Information

- [“Operating Environment Requirements” on page 6](#)
- [“Optimal Ambient Temperature” on page 7](#)
- [“Optimal Ambient Relative Humidity” on page 7](#)

Heat Dissipation Calculation

To calculate the heat generated by a server so that you can estimate the heat your cooling system must dissipate, convert the figure for the server’s power requirement from watts to BTU/hr. A general formula for doing this is to multiply the average operating power requirement figure in watts by 3.412.

Related Information

- [“Operating Environment Requirements” on page 6](#)
- [“Optimal Ambient Temperature” on page 7](#)
- [“Optimal Ambient Relative Humidity” on page 7](#)
- [“Airflow Considerations” on page 7](#)