

**Oracle® Communications  
Diameter Signaling Router (DSR)**

**SDS Disaster Recovery Guide**

Release 5.0

**909-2308-001, Revision D**

January 2015

**ORACLE®**

Oracle Communications Diameter Signaling Router SDS Disaster Recovery Guide, Release 5.0

Copyright ©2011, 2015 Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.



**CAUTION: Use only the Upgrade procedure included in the Upgrade Kit. Before upgrading any system, please access My Oracle Support (MOS) (<https://support.oracle.com>) and review any Technical Service Bulletins (TSBs) that relate to this upgrade.**

My Oracle Support (MOS) (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support (CAS) can assist you with MOS registration.

Call the CAS main number at 1-800-223-1711 (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>.

See more information on MOS in the Appendix section.

**TABLE OF CONTENTS**

**1.0 INTRODUCTION .....5**

1.1 Purpose and Scope.....5

1.2 References.....5

1.3 Acronyms .....5

1.4 Assumptions .....6

1.5 How to use this Document .....6

**2.0 DISASTER RECOVERY SCENARIOS.....7**

2.1 Complete connectivity loss of Primary SDS servers .....7

2.1.1 Pre Condition .....7

2.1.2 Recovery Steps.....7

2.1.3 Post Condition.....9

2.2 Replacement of A DP server .....10

2.2.1 Pre Condition .....10

2.2.2 Recovery Steps.....10

2.2.3 Post Condition.....10

2.3 Replacement of a DP SOAM.....11

2.3.1 Pre Condition .....11

2.3.2 Recovery Steps.....11

2.3.3 Post Condition.....11

2.4 Replacement of a Query server.....12

2.4.1 Pre Condition .....12

2.4.2 Recovery Steps.....12

2.4.3 Post Condition.....12

2.5 Replacement of a SDS server .....13

2.5.1 Pre Condition .....13

2.5.2 Recovery Steps.....13

2.5.3 Post Condition.....14

2.6 Replacement of Primary SDS server pair .....15

2.6.1 Pre Condition .....15

2.6.2 Recovery Steps.....15

2.6.3 Post Condition.....16

2.7 Replacement of DP SOAM server pair .....17

2.7.1 Pre Condition .....17

2.7.2 Recovery Steps.....17

2.7.3 Post Condition.....17

2.8 Replacement of DR SDS server pair .....18

2.8.1 Pre Condition .....18

2.8.2 Recovery Steps.....18

2.8.3 Post Condition.....18

2.9 Replacement of SDS frame.....19

2.9.1 Pre Condition .....19

2.9.2 Recovery Steps.....19

2.9.3 Post Condition.....19

2.10 Replacement of DP SOAM frame.....20

2.10.1 Pre Condition .....20

2.10.2 Recovery Steps.....20

2.10.3 Post Condition.....20

**APPENDIX A. MY ORACLE SUPPORT (MOS) .....21**

## List of Tables

**Table 1 - Acronyms** .....6

## 1.0 INTRODUCTION

### 1.1 PURPOSE AND SCOPE

This document describes procedures to use during SDS 3.x product related disaster scenarios.

The disaster scenarios covered in document are

- 1) Connectivity loss to primary SDS servers and DR SDS activation.
- 2) A defective DP server
- 3) A defective Query Server
- 4) A defective DP SOAM server
- 5) A defective SDS server
- 6) A defective SDS server pair
- 7) A defective DP SOAM server pair
- 8) A defective CISCO switch
- 9) Total loss of SDS frame.
- 10) Total loss of SOAM frame.

This document is intended for execution by Oracle’s Tekelec Customer Service team on fielded SDS systems. It also could be used at Tekelec by PV and development team.

### 1.2 REFERENCES

**External (Customer Facing):**

- [1] *SDS Initial Installation and Configuration Guide*, UG006385
- [2] *TPD Initial Product Manufacture User’s Guide*, 909-2130-001
- [3] *Platform 6.x Configuration Procedure Reference*, 909-2209-001, v. C or greater, 2012
- [4] *DSR 4.0 Disaster Recovery Guide*, UG006190
- [5] *Cabinet Assembly Instructions*, 910-6083-001

**Internal (Internal documents are available to Tekelec personnel only):**

- [6] *ALEXA 5.0 HP c-Class & Rack-mount Server Site Installation and Configuration*, TR007011
- [7] *Platform 5.0 Generic HP c-Class Networking Interconnect*, TR006851
- [8] *DSR Network Planning for AT&T Mobility – LTE*, MS006641
- [9] *BL460cc Hardware Upgrade AT&T PAS Lab*, WI006803
- [10] *SDS 4.0 Software Upgrade Procedure*, UG006386

### 1.3 ACRONYMS

Acronym	Meaning
CSV	Comma Separated Values
DP	Database Processor
IMI	Internal Management Interface
ISL	Inter-Switch-Link
MP	Message Processor
NE	Network Element
NOAM	Network Operations, Administration & Maintenance
OAM	Operations, Administration & Maintenance
SDS	Network Operations, Administration & Maintenance
RMM	Remote Management Module
SOAM	Systems Operations, Administration & Maintenance

TPD	Tekelec Platform Distribution (Linux OS)
VIP	Virtual IP
XMI	External Management Interface

**Table 1 - Acronyms**

**1.4 ASSUMPTIONS**

This procedure assumes the following;

- The user conceptually understands SDS topology and network configuration.
- The user has at least an intermediate skill set with command prompt activities on an open systems computing environment such as Linux or TPD.

**1.5 HOW TO USE THIS DOCUMENT**

When executing this document, understanding the following helps to ensure that the user understands the manual’s intent:

- 1) Before beginning a procedure, completely read the instructional text (it appears immediately after the Section heading for each procedure) and all associated procedural WARNINGS or NOTES.
- 2) Before execution of a STEP within a procedure, completely read the left and right columns including any STEP specific WARNINGS or NOTES.

If a procedural STEP fails to execute successfully, STOP and contact My Oracle Support (Appendix A).

## 2.0 DISASTER RECOVERY SCENARIOS

### 2.1 COMPLETE CONNECTIVITY LOSS OF PRIMARY SDS SERVERS

#### 2.1.1 PRE CONDITION

- User cannot access GUI of the primary SDS
- User still can access GUI of the DR SDS
- Provisioning clients are disconnected from the primary SDS
- Provisioning has stopped

#### 2.1.2 RECOVERY STEPS

In order to quickly make SDS GUI accessible and provisioning to continue, DR SDS servers are activated and made to serve as primary SDS via following steps.

<b>1</b> <input type="checkbox"/>	Disable the application on DR SDS servers.	<p>This step ensures that when the DR SDS assumes Primary SDS status in a controlled fashion. Disabling the application inhibits provisioning and can be started after successful validation.</p> <ol style="list-style-type: none"> <li>1. Login to DR SDS GUI as one of the admin users.</li> <li>2. Select [Main Menu: Status &amp; Manage → Server] screen.</li> <li>3. Select the row that has active DR SDS server. It highlights ‘Stop’ button at the bottom.</li> <li>4. Click the ‘Stop’ button and then click the ‘OK’ button. At this time, HA switch over causes an automatic logout.</li> <li>5. Login to DR SDS GUI as one of the admin user.</li> <li>6. Repeat step 3 to 4 for new active DR SDS server.</li> <li>7. Verify that ‘PROC’ column on both DR SDS servers show ‘Man’ indicating that application is manually stopped.</li> </ol>
<b>2</b> <input type="checkbox"/>	SSH to VIP address of the DR SDS as root and make it primary SDS	<ol style="list-style-type: none"> <li>1. Login via SSH to VIP of DR SDS server as root user.</li> <li>2. Execute the command <b>top.setPrimary</b></li> </ol> <p>This step makes the DR SDS take over as the Primary SDS.</p> <ol style="list-style-type: none"> <li>3. System generates several replication and collection alarms as replication/collection links to/from former Primary SDS servers becomes inactive.</li> </ol>
<b>3</b> <input type="checkbox"/>	Clear any persistent alarms	<p>Wait at least 5 minutes for replication to rsync (“inetmerge” or “inetrep” alarms may remain present).</p> <p>If inetmerge or inetrep alarms persist beyond 5 minutes, then on the new primary SDS, restart the corresponding process(es):</p> <pre># pm.kill &lt;inetmerge or inetrep&gt;</pre> <p>View alarms until all clear.</p>
<b>4</b> <input type="checkbox"/>	Verify replication	<ol style="list-style-type: none"> <li>1. Monitor [Main Menu: Status &amp; Manage → Server] screen at new-Primary SDS.</li> <li>2. It may take several minutes for replication, afterward the DB and Reporting Status columns should show ‘Normal.’</li> </ol>

<p>5 □</p>	<p>Re-enable the application on the now-Primary SDS using the Active new-Primary SDS GUI.</p>	<ol style="list-style-type: none"> <li>1. Login to new-Primary SDS GUI as one of the admin user.</li> <li>2. Select [Main Menu: Status &amp; Manage → Server] screen.</li> <li>3. Select the row that has the active new-Primary SDS server. This action highlights the ‘Restart’ button at the bottom.</li> <li>4. Click the ‘Restart’ button and then click the ‘OK’ button.</li> <li>5. Verify that ‘PROC’ column now shows ‘Norm’.</li> <li>6. Repeat step 3 to 5 for standby new-Primary SDS server.</li> </ol> <p>Provisioning connections can now resume to the VIP of the new-Primary SDS.</p>
<p>6 □</p>	<p>Decrease the durability admin status and then reconfigure and reconnect the customer’s provisioning clients.</p>	<ol style="list-style-type: none"> <li>1. Lower the durability admin status to (NO pair) to exclude former-Primary SDS servers from the provisioning database durability. A value greater than 2 must be adjusted downward.             <ol style="list-style-type: none"> <li>a. Login to new SDS GUI as admin user</li> <li>b. Select [Main Menu: Administration → General Options]</li> <li>c. Set <i>durableAdminState</i> to 2 (NO pair)</li> <li>d. Click the ‘OK’ button</li> </ol> </li> <li>2. Have customer reconfigure provisioning clients to connect to XMI VIP of the newly activated SDS servers.</li> <li>3. Verify that provisioning from clients have started.             <ol style="list-style-type: none"> <li>a. Select [Main Menu: SDS → Maintenance → Command Log]</li> <li>b. Check that new commands have been executed</li> </ol> </li> </ol>
<p>At this point, SDS provisioning is fully functioning. The remaining steps bring the old Primary SDS servers back into service as the new DR SDS site.</p>		
<p>7 □</p>	<p>Bring former-Primary SDS back to service.</p>	<ol style="list-style-type: none"> <li>1. Determine what has happened to former-Primary SDS site.              SDS frame defective _____              SDS servers defective _____              Networking outage _____              Switch defective _____</li> <li>2. Based on the above disaster recovery scenario, execute procedure from this document to return the former-Primary SDS servers and site back to service.</li> </ol>
<p>8 □</p>	<p>Convert former Primary SDS servers to new DR SDS</p>	<ol style="list-style-type: none"> <li>1. SSH to active former-Primary SDS server as root.</li> <li>2. Execute the command <b>top.setSecondary</b> This step allows the formerly Primary SDS to become the DR SDS.</li> <li>3. Monitor [Main Menu: Status &amp; Manage → Server] screen at new DR SDS GUI.</li> <li>4. It may take several minutes for replication, afterward the DB and Reporting Status columns should show ‘Normal.’</li> </ol>

<p>9</p> <p>□</p>	<p>Stop Non-Service processes on DR</p>	<ol style="list-style-type: none"> <li>1. Select [Main Menu: Status &amp; Manage → Server] for now Active DR SDS on GUI.</li> <li>2. Press the ‘Stop’ button for new DR SDS (stops <i>all</i> processes).</li> <li>3. Press the ‘OK’ button to confirm.</li> <li>4. Again select [Main Menu: Status &amp; Manage → Server] for new DR SDS on GUI.</li> <li>5. Press the ‘Restart’ button for new DR SDS (starts <i>only</i> Service processes).</li> <li>6. Press the ‘OK’ button to confirm.</li> <li>7. Monitor [Main Menu: Status &amp; Manage → Server] screen for new DR SDS on GUI.</li> <li>8. It may take a few seconds, but afterward the Application State should be ‘Enabled,’ and the Alarm and Process Status columns should show ‘Normal.’</li> </ol>
<p>10</p> <p>□</p>	<p>Set durability admin status to include DR SDS</p>	<ol style="list-style-type: none"> <li>1. If you reduced the durability status in step 5, raise durability admin status to its former value (NO + DRNO) .             <ol style="list-style-type: none"> <li>a. Login to new primary SDS GUI as admin user</li> <li>b. Select [Main Menu: Administration → General Options]</li> <li>c. Set <i>durableAdminState</i> to 3(NO DRNO)</li> <li>d. Click the ‘OK’ button</li> </ol> </li> <li>2. Now new DR SDS servers are part of provisioning database durability.</li> </ol>

**2.1.3 POST CONDITION**

- GUI on the new primary SDS is accessible
- Provisioning clients are connected to the new primary SDS
- Database provisioning resumes
- New DR SDS GUI is accessible
- Replication and collection alarms have cleared
- Note: To swap new primary SDS and new DR SDS back to their original roles, run this procedure again.

## 2.2 REPLACEMENT OF A DP SERVER

### 2.2.1 PRE CONDITION

- DP blade server has stopped processing traffic
- It has been determined the DP blade server is defective and needs replacement
- New DP server is available

### 2.2.2 RECOVERY STEPS

1	<p><b>Note:</b> This step is optional and only executable if DP is powered on and functional. Stop software on DP server.</p>	<ol style="list-style-type: none"> <li>1. Login to DP SOAM GUI for the site where DP is located.</li> <li>2. Select [Main Menu: Status &amp; Manage → Server] and select DP by Hostname.</li> <li>3. Click the ‘Stop’ button followed by the ‘Ok’ button on confirmation screen.</li> </ol>
2	<p><b>Note:</b> This step is optional and only executable if DP is powered on and functional. Verify that no signaling traffic is processed at the DP.</p>	<ol style="list-style-type: none"> <li>1. Login to DP SOAM GUI for the site where DP is located.</li> <li>2. Select [Main Menu: Status &amp; Manage → KPIs] and select ‘DP’ tab.</li> <li>3. Verify that ‘Total Queries/Sec’ KPI is now showing ‘0’ for the DP’s hostname.</li> </ol>
3	Replace Server	<ol style="list-style-type: none"> <li>1. Power down DP.</li> <li>2. Label all connected cables.</li> <li>3. Disconnect all necessary cables so the server can be physically removed from the enclosure for replacement.</li> <li>4. Follow reference [9], BL460cc Hardware Upgrade, to remove and replace the DP blade.</li> <li>5. Wire in the new DP blade server according to the cables you labeled and removed from the old blade.</li> </ol>
4	Install the new DP server and wait for it to complete replication sync.	<ol style="list-style-type: none"> <li>1. Execute procedure 10 (DP Installation) from reference [1].</li> <li>2. Execute procedure 10.2 (Applying the Database Processor Configuration File) from reference [1].</li> <li>3. Execute procedure 10.5 (Restarting Database Processor Application) from reference [1].</li> </ol>
5	Verify status and traffic.	<ol style="list-style-type: none"> <li>1. Login to DP SOAM GUI for the site where DP is located.</li> <li>2. Select [Main Menu: Status &amp; Manage → KPIs] and select ‘DP’ tab.</li> <li>3. Verify that ‘Total Queries/Sec’ KPI is now showing a non-zero value for the DP’s hostname.</li> </ol>

### 2.2.3 POST CONDITION

- DP server is processing traffic

**2.3 REPLACEMENT OF A DP SOAM**

**2.3.1 PRE CONDITION**

- DP SOAM has stopped functioning
- It has been determined to replace the blade hosting DP SOAM
- New blade replacement is available
- SDS GUI is accessible

**2.3.2 RECOVERY STEPS**

<b>1</b> <input type="checkbox"/>	Prepare for server replacement.	Identify the DP SOAM that needs replacement DP SOAM hostname = _____
<b>2</b> <input type="checkbox"/>	Make DP SOAM server's Max Allowed HA Role "Standby" so it does not become active.	<ol style="list-style-type: none"> <li>1. Go to the SDS GUI.</li> <li>2. Select [Main Menu: Status &amp; Manage → HA].</li> <li>3. Select the DP SOAM that needs replacement.</li> <li>4. Change its "Max Allowed HA Role" to "Standby".</li> <li>5. Click the "OK" button.</li> </ol>
<b>3</b> <input type="checkbox"/>	Remove DP SOAM from the server group.	<ol style="list-style-type: none"> <li>1. Go to the SDS GUI.</li> <li>2. Select [Main Menu: Configuration → Server Groups].</li> <li>3. Select DP SOAM's server group.</li> <li>4. Click the "Edit" button.</li> <li>5. Move DP SOAM out of the server group.</li> <li>6. Click the "OK" button.</li> </ol>
<b>4</b> <input type="checkbox"/>	Remediate hardware and Recover DSR services	Execute Recovery Scenario 2, of reference [4] , DSR Disaster Recovery Guide, to remediate hardware and restore DSR blade services.
<b>5</b> <input type="checkbox"/>	Prepare the new DP SOAM server	<ol style="list-style-type: none"> <li>1. Execute Procedure 8 (OAM Installation for DP SOAM Sites) from reference [1].</li> <li>2. Execute procedure 8.3 (Applying the DP SOAM Server Configuration File) from reference [1].</li> </ol>
<b>6</b> <input type="checkbox"/>	Add DP SOAM server to the server group and validate pairing	From reference [1] execute following procedures in sequence on new DP SOAM server. <ol style="list-style-type: none"> <li>a. Procedure 9.2 (Adding a Server to an DP SOAM Server Group)</li> <li>b. Procedure 9.3 (Restarting OAM Server Application)</li> </ol>

**2.3.3 POST CONDITION**

- DP SOAM is back in service

## 2.4 REPLACEMENT OF A QUERY SERVER

### 2.4.1 PRE CONDITION

- Query server has stopped functioning
- It has been determined to replace the Query server
- New Query server replacement is available

### 2.4.2 RECOVERY STEPS

1 <input type="checkbox"/>	Prepare for server replacement.	Identify the Query server that needs replacement Query server hostname = _____
2 <input type="checkbox"/>	Make Query Server's Max Allowed HA Role "Standby" so it does not become active.	<ol style="list-style-type: none"> <li>1. Go to the SDS GUI.</li> <li>2. Select [Main Menu: Status &amp; Manage → HA].</li> <li>3. Select the Query Server that needs replacement.</li> <li>4. Change its "Max Allowed HA Role" to "Standby".</li> <li>5. Click the "OK" button.</li> </ol>
3 <input type="checkbox"/>	Remove Query Server from the server group.	<ol style="list-style-type: none"> <li>1. Go to the SDS GUI.</li> <li>2. Select [Main Menu: Configuration → Server Groups].</li> <li>3. Select the Query Server's server group.</li> <li>4. Click the "Edit" button.</li> <li>5. Move Query Server out of the server group.</li> <li>6. Click the "OK" button.</li> </ol>
4 <input type="checkbox"/>	Power down Query Server	<ol style="list-style-type: none"> <li>1. Power down the Query Server.</li> <li>2. Label all cables connected to Query Server.</li> <li>3. Replace Query server by instructions in reference [5].</li> <li>4. Wire in the new Query server according to the cables you labeled and removed from the old server.</li> </ol>
5 <input type="checkbox"/>	Replace Query Server	<ol style="list-style-type: none"> <li>1. Replace Query server by instructions in reference [5].</li> <li>2. Wire in the new Query server according to the cables you labeled and removed from the old server.</li> </ol>
6 <input type="checkbox"/>	Prepare the new Query server	<ol style="list-style-type: none"> <li>1. Execute Procedure 1 (Installing the SDS Application) from reference [1].</li> <li>2. Execute procedure 4.2 (Applying the Query Server Configuration File) from reference [1].</li> <li>3. Execute procedure 4.3 (Adding the Query Server to the SDS Server Group) from reference [1].</li> </ol>
7 <input type="checkbox"/>	Start Query Server	Execute procedure 4.4 (Restarting Query Server Application) from reference [1].

### 2.4.3 POST CONDITION

- Query server is back in service

## 2.5 REPLACEMENT OF A SDS SERVER

### 2.5.1 PRE CONDITION

- SDS server has stopped functioning
- It has been determined to RMA the SDS server
- New SDS server replacement is available

### 2.5.2 RECOVERY STEPS

1 □	Prepare for server replacement.	Identify the SDS server that needs replacement Hostname = _____
2 □	Make SDS server's Max Allowed HA Role "Standby" so it does not become active.	<ol style="list-style-type: none"> <li>1. Go to the SDS GUI.</li> <li>2. Select [Main Menu: Status &amp; Manage → HA].</li> <li>3. Select the SDS that needs replacement.</li> <li>4. Change its "Max Allowed HA Role" to "Standby".</li> <li>5. Click the "OK" button.</li> </ol>
3 □	Remove SDS from the server group.	<ol style="list-style-type: none"> <li>1. Go to the SDS GUI.</li> <li>2. Select [Main Menu: Configuration → Server Groups].</li> <li>3. Select Primary SDS's server group.</li> <li>4. Click the "Edit" button.</li> <li>5. Move SDS out of the server group.</li> <li>6. Click the "OK" button.</li> </ol>
4 □	Power down and replace SDS Server	<ol style="list-style-type: none"> <li>1. Power down SDS server.</li> <li>2. Label all cables connected to SDS server.</li> <li>3. Replace SDS server by instructions in reference [5].</li> <li>4. Wire in the new SDS server according to the cables you labeled and removed from the old server.</li> </ol>
5 □	Prepare the new SDS server	<ol style="list-style-type: none"> <li>1. Execute Procedure 1 (Installing the SDS Application) from reference [1].</li> <li>2. Execute procedure 2.4 (Applying The SDS Server Configuration File) from reference [1].</li> </ol>
6 □	Add SDS server to the server group	<p>From reference [1] execute following procedures in sequence on new Primary SDS server.</p> <ol style="list-style-type: none"> <li>a) Procedure 3.2 (Adding a Server to an OAM Server Group)</li> <li>b) Procedure 3.3 (Verifying the SDS Server Alarm status)</li> </ol>
7 □	Install Netbackup Client Software	<p>Execute Section 3.11.5 <i>Application NetBackup Client Procedures</i> of reference [3] to complete this step.</p> <p><b>NOTE:</b> Location of the <code>bpstart_notify</code> and <code>bpend_notify</code> scripts is required for the execution of this step. These scripts are located as follows:</p> <p style="text-align: center;"> <code>/usr/TKLC/appworks/sbin/bpstart_notify</code>  <code>/usr/TKLC/appworks/sbin/bpend_notify</code> </p>

8	□	<p>Link notify scripts to well-known path stated in the above step</p> <pre># ln -s &lt;path&gt;/bpstart_notify /usr/opensv/netbackup/bin/bpstart_notify # ln -s &lt;path&gt;/bpend_notify /usr/opensv/netbackup/bin/bpend_notify</pre>
---	---	---

**2.5.3 POST CONDITION**

- SDS server is back in service

## 2.6 REPLACEMENT OF PRIMARY SDS SERVER PAIR

### 2.6.1 PRE CONDITION

- Active and Standby SDS server have stopped functioning
- DR SDS servers are not available or not installed
- It has been determined to replace both SDS servers
- New SDS servers for replacement are available
- Recent backup archives of SDS configuration and provisioning databases are available

### 2.6.2 RECOVERY STEPS

1	Determine SDS backup archive	<p><b>Note:</b> If DR SDS servers are available, follow recovery steps from section 2.1 of this document instead.</p> <p>Make sure that you have access to SDS backup archive that contains provisioning data as well as configuration data. This backup archive should be in uncompressed format.</p>
2	Power down and remove old SDS servers. Replace with new SDS servers.	<ol style="list-style-type: none"> <li>1. Power down SDS servers.</li> <li>2. Label all cables connected to SDS servers.</li> <li>3. Physically remove both SDS servers from the frame.</li> <li>4. Follow reference [5] for the physical installation of SDS server.</li> <li>5. Wire in the new SDS servers according to the cables you labeled and removed from the old servers.</li> </ol>
3	Install first SDS server in the frame	Execute procedure 1(Installing the SDS Application) from reference [1] on the first SDS server.
4	Configure first SDS server in the frame	Execute procedure 2 (Configuring SDS Server A) ( <b>omit step 51 to configure SDS B</b> ) ( <b>omit step between 51 and 52 to configure switches unless this is a complete frame replacement</b> ), from reference [1] on the first SDS server.
5	Copy SDS backup archive to new SDS server.	<ol style="list-style-type: none"> <li>1. Login via SSH to the console of new SDS server.</li> <li>2. Copy /etc/hosts file from another SDS server to this server.</li> <li>3. Copy the uncompressed backup archive identified in step 1 to /var/TKLC/db/filemgmt area on newly installed first SDS server.</li> <li>4. Execute “<b>prod.dbup</b>” to stop running applications. Leave database running.</li> <li>5. Restore the configuration DB by executing <code>idb.restore -n -t /var/TKLC/db/filemgmt -v &lt;configuration archive file name&gt;</code></li> <li>6. Restore the provisioning DB by executing <code>idb.restore -n -t /var/TKLC/db/filemgmt -v &lt;provisioning archive file name&gt;</code></li> <li>7. SDS database is now restored. Start application by executing “<b>prod.start</b>”.</li> </ol>
6	Install the new second SDS server in the frame.	Follow recovery steps from section 2.5 of this document to restore second SDS server.

**2.6.3 POST CONDITION**

- Both SDS servers are back in service
- Provisioning clients are connected to SDS VIP address
- Provisioning continues

**2.7 REPLACEMENT OF DP SOAM SERVER PAIR**

**2.7.1 PRE CONDITION**

- Active and Standby DP SOAM servers have stopped functioning
- It has been determined to replace both blades that host DP SOAM
- New blades for replacement are available
- Access to Primary SDS GUI is available
- DPs are not receiving provisioning database updates.

**2.7.2 RECOVERY STEPS**

<b>1</b> <input type="checkbox"/>	Prepare for server replacement.	Identify the DP SOAM servers that needs replacement DP SOAM 1 = _____ DP SOAM 2 = _____
<b>2</b> <input type="checkbox"/>	Remediate hardware and Recover DSR services	If DSR recovery has not already been performed, execute Recovery Scenario 2, of reference [4], DSR Disaster Recovery Guide.
<b>3</b> <input type="checkbox"/>	Install SDS on DP SOAM servers	Execute procedure 8 (OAM Installation for DP SOAM sites) from reference [1].
<b>4</b> <input type="checkbox"/>	Configure software on DP SOAM servers	Execute procedure 8.3 (Applying the DP SOAM Server Configuration File) from reference [1].
<b>5</b> <input type="checkbox"/>	Start DP SOAM	Execute procedure 9.3 (Restarting OAM Server Application) from reference [1].
<b>6</b> <input type="checkbox"/>	Verify that DP SOAM servers received SDS provisioning	<ol style="list-style-type: none"> <li>1. Login to active DP SOAM GUI using VIP address.</li> <li>2. Select [Main Menu: Status &amp; Manage → Servers] screen.</li> <li>3. Make sure that new DP SOAM servers show ‘Norm’ for DB, Reporting Status and Appl State.</li> </ol>

**2.7.3 POST CONDITION**

- Both DP SOAM servers are back in service
- DP SOAM configuration changes can be made from DP SOAM GUI
- DPs are now receiving provisioning updates

## 2.8 REPLACEMENT OF DR SDS SERVER PAIR

### 2.8.1 PRE CONDITION

- Active and Standby DR SDS servers have stopped functioning
- It has been determined to RMA the both DR SDS servers
- New DR SDS servers for replacement are available
- Access to Primary SDS GUI is functional

### 2.8.2 RECOVERY STEPS

1 <input type="checkbox"/>	Prepare for server replacement.	Identify the DR SDS servers that needs replacement DR SDS 1 = _____ DR SDS 2 = _____
2 <input type="checkbox"/>	Power down and remove old DR SDS servers.	<ol style="list-style-type: none"> <li>1. Power down DR SDS Servers.</li> <li>2. Label all cables connected to DR SDS servers.</li> <li>3. Physically remove both DR SDS servers from the frame.</li> </ol>
3 <input type="checkbox"/>	Replace with new DR SDS servers	<ol style="list-style-type: none"> <li>1. Install new DR SDS servers by instructions in reference [5].</li> <li>2. Wire in the new DR SDS servers according to the cables you labeled and removed from the old servers.</li> </ol>
4 <input type="checkbox"/>	Install software on DR SDS servers in the frame.	Execute procedure 1 (Installing the SDS Application) from reference [1].
5 <input type="checkbox"/>	Pair DR SDS servers and bring them online	<ol style="list-style-type: none"> <li>1. Execute procedure 5.3 (Applying the OAM Server Configuration File) from reference [1] (<b>omit the step to configure switches unless this is a complete frame replacement</b>).</li> <li>2. Execute procedure 6.2 (Adding a Server to OAM Server Group) from reference [1].</li> <li>3. Execute procedure 6.3 (Restarting OAM Server Application) from reference [1].</li> </ol>
6 <input type="checkbox"/>	Install Netbackup Client Software	<p>Execute Section 3.11.5 <i>Application NetBackup Client Procedures</i> of reference [3] to complete this step.</p> <p><b>NOTE:</b> Location of the bpstart_notify and bpend_notify scripts is required for the execution of this step. These scripts are located as follows:</p> <p style="text-align: center;">/usr/TKLC/appworks/sbin/bpstart_notify /usr/TKLC/appworks/sbin/bpend_notify</p> <p><b>NOTE:</b> Netbackup client software must be installed on each DR server of the pair.</p>
7 <input type="checkbox"/>	Link notify scripts to well-known path stated in the above step	<pre># ln -s &lt;path&gt;/bpstart_notify /usr/opensv/netbackup/bin/bpstart_notify # ln -s &lt;path&gt;/bpend_notify /usr/opensv/netbackup/bin/bpend_notify</pre>

### 2.8.3 POST CONDITION

- Both DR SDS servers are back in service

**2.9 REPLACEMENT OF SDS FRAME**

**2.9.1 PRE CONDITION**

- SDS frame is destroyed
- A replacement SDS frame with 2 SDS servers and a Query Server is available
- DR SDS servers and GUI are available

**2.9.2 RECOVERY STEPS**

1 <input type="checkbox"/>	Determine SDS site and status of provisioning	If SDS frame is the Primary SDS frame, execute procedure from section 2.1 to activate DR SDS site. This allows provisioning to continue and makes the defective frame a defective DR SDS frame.
2 <input type="checkbox"/>	Install new replacement frame	Follow reference [5] to install new DR SDS frame.
3 <input type="checkbox"/>	Install DR SDS servers and connect	<ol style="list-style-type: none"> <li>1. Install new DR SDS servers by instructions in reference [5].</li> <li>2. Wire in the new DR SDS servers according to reference [7].</li> </ol>
4 <input type="checkbox"/>	Install switches	Follow reference [5] to install new switches into the DR SDS frame.
5 <input type="checkbox"/>	Recover DR SDS server pair	Follow recovery steps from section 2.8 of this document.
6 <input type="checkbox"/>	Recover Query server	Follow recovery steps from section 2.4 of this document.

**2.9.3 POST CONDITION**

- DR SDS frame is back in service

**2.10 REPLACEMENT OF DP SOAM FRAME**

**2.10.1 PRE CONDITION**

- DP SOAM frame is destroyed
- A replacement DP SOAM frame with 2 DP SOAM servers and DP servers is available

**2.10.2 RECOVERY STEPS**

1	Install new DP SOAM frame	Follow procedure in reference [4] to install new DP SOAM frame.
2	Install DP SOAM Cabinet	Presently DSR recovery documentation lacks material to replace the blade cabinet. Follow reference [5] chapter 7 for installation of HP BladeSystem enclosure.
3	Install DSR	Execute Recovery Scenario 1, of reference [4] , DSR Disaster Recovery Guide, to restore DSR services.
4	Recover DP SOAM server pair	Follow recovery steps from section 2.7 of this document.
5	Recover DP servers	For each DP server, follow recovery steps from section 2.2 of this document.

**2.10.3 POST CONDITION**

- DP SOAM frame is back in service

## APPENDIX A. MY ORACLE SUPPORT (MOS)

MOS (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support (CAS) can assist you with MOS registration.

Call the CAS main number at **1-800-223-1711** (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>.

When calling, there are multiple layers of menu selections. Make the selections in the sequence shown below on the Support telephone menu:

1. For the first set of menu options, select: 2, "New Service Request".  
You will hear another set of menu options.
2. In this set of menu options, select: 3, "Hardware, Networking and Solaris Operating System Support".  
A third set of menu options begins.
3. In the third set of options, select: 2, "Non-technical issue".

Then you will be connected to a live agent who can assist you with MOS registration and provide Support Identifiers. Simply mention you are a Tekelec Customer new to MOS.