Oracle[®] Communications Policy Management

Roadmap to Hardware Documentation Release 11.1 E53448 Revision 01

May 2014



Oracle[®] Communications Roadmap to Hardware Documentation, Release 11.1

Copyright [©] 2014, Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT RIGHTS Programs, software, databases, and related documentation and technical data delivered to U.S. Government customers are "commercial computer software" or "commercial technical data" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, the use, duplication, disclosure, modification, and adaptation shall be subject to the restrictions and license terms set forth in the applicable Government contract, and, to the extent applicable by the terms of the Government contract, the additional rights set forth in FAR 52.227-19, Commercial Computer Software License (December 2007). Oracle America, Inc., 500 Oracle Parkway, Redwood City, CA 94065.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Table of Contents

Chapter 1: Roadmap	5
Introduction	
General Descriptions and Hardware Features	6
User Operations - LEDs	7
Policy Management (Policy) Platform Configuration	8

List of Figures

Figure 1: Example of an AC cabinet with Cisco 4948-4948E	9
Figure 2: Example of an AC Co-Mingled cabinet with Cisco 4948E-F	10
Figure 3: Example of a DC cabinet with Cisco 4948-4948E	11
Figure 4: Example of a DC Co-Mingled cabinet with Cisco 4948E-F	12
Figure 5: AC Cabinet with Cisco 4948E-F, (3) Enclosures, (1 DL380/ 2 DL360)	14
Figure 6: AC Cabinet with Cisco 4948E-F, (2) Enclosures, (6 DL380/ 12 DL360)	15
Figure 7: AC Cabinet with Cisco 4948E-F, (1) Enclosures, (11 DL380/ 12 DL360)	16
Figure 8: DC Cabinet; (2) Enclosures; (2) Switches; RMS	17
Figure 9: DC Cabinet; (1) Enclosure; (2) Switches; RMS	18

Chapter 1

Roadmap

Topics:

- Introduction.....6
- *General Descriptions and Hardware Features.....6*
- User Operations LEDs.....7
- Policy Management (Policy) Platform Configuration.....8

Introduction

Note: Viewing the user online documentation requires Internet access. For the most current user documentation, always reference the latest manufacturer online documentation.

Not all components, features, or documents referenced in this aid may be installed or used. For any questions related to available components or hardware features, contact your Sales representative. For assistance with the content of the referenced user documentation or help with procedures, contact the Tekelec Customer Care Center.

General Descriptions and Hardware Features

This category directs you to the manufacturer online documentation that provides general descriptions of equipment including hardware features available.

Note: Not all features presented in the manufacturer documentation may be supported by this configuration. Contact the Customer Care Center for additional information.

- *HP BladeSystem c-Class architecture technology brief* provides a general explanation of c-Class architecture and describes how the components within BladeSystem c-Class work together.
- Important Safety Information For Server, Storage, Power, Networking, and Rack Products contains important safety information concerning Server, Storage, Power, Networking, and Rack Products.
- The *HP Intelligent Rack Family User Guide* provides additional installation information for the HP642 series cabinet.
- *HP ProLiant Intel-based 300-series G6 and G7 servers* describes the key technologies implemented in Intel-based HP ProLiant 300-series G6 and G7 servers.
- Technologies in the HP BladeSystem c7000 Enclosure describes the HP BladeSystem c7000 Enclosure.
- *HP ProLiant BL460c G6 Server Blade User Guide* describes the ProLiant BL460c blade server.
- HP ProLiant BL460c Gen8 Server Blade User Guide describes the ProLiant BL460c Gen8 blade server.
- *HP ProLiant BL620c G7 Server Blade User Guide* describes the ProLiant BL620c blade server.
- *HP ProLiant DL360 G6 Server User Guide* describes the HP ProLiant DL360 G6 Server system features and components.
- *HP ProLiant DL360p Gen8 Server User Guide* describes the HP ProLiant DL360p Gen8 Server system features and components.
- *HP ProLiant DL380 G6 Server User Guide* describes the HP ProLiant DL380 G6 Server system features and components.
- *HP ProLiant DL380p Gen8 Server User Guide* describes the HP ProLiant DL380p Gen8 Server system features and components.
- *Cisco Catalyst Blade Switch 3020 for HP Hardware Installation Guide* describes the Catalyst 3020 switch, as well as system features and components.
- *ProCurve Series 6120 Blade Switches Installation and Getting Started Guide* describes the HP ProCurve 6120XG switch, as well as system features and components.
- *Catalyst 4900 Series Switch Installation Guide* describes the Cisco Catalyst 4900 series switches, as well as system features and components.
- *Catalyst 4948E and Catalyst 4948E-F Switch Installation Guide* describes the Cisco Catalyst 4849E and 4948E-F switches, as well as system features and components.

- *1Gb Ethernet Pass-Thru Module* describes the 1Gb Ethernet Pass-Thru Module.
- *Telect 125A 8-Position Demarcation panel* ±24*V*/-48*V* describes the Telect 125A 8-Position Demarcation panel, ±24V/-48V
- Telect 150A Dual-feed 4/4 TPA/GMT, -48V describes the Telect 150A Dual-feed 4/4 TPA/GMT, -48V.
- *HP 252663 Modular Power Distribution Unit with Extension Bars* describes the AC Power Distribution Unit.

User Operations - LEDs

This category directs you to specific sections of the manufacturer online doumentation on LED indicators for the specified equipment.



Warning: Customers do not perform installation procedures; these procedures are performed by authorized personnel. Contact the Customer Care Center for assistance with any procedure.



Warning: Performing any procedure not authorized or approved by Oracle may void any or all Oracle warranties. Contact the Customer Care Center for assistance with any procedure.

- WARNING
- Information describing LED functions of the 3020 switch can be found in this document: *Cisco Catalyst Blade Switch 3020 for HP Hardware Installation Guide*.
- The LED functions of the Cisco Catalyst 4900 Series Switch can be found in this document: *Catalyst 4900 Series Switch Installation Guide*.
- The LED functions of the Cisco Catalyst 4948E-F Switch can be found in this document: *Catalyst 4948E and Catalyst 4948E-F Switch Installation Guide*.
- The LED functions of the HP ProCurve 6120XG switch can be found in this document: *ProCurve Series* 6120 *Blade Switches Installation and Getting Started Guide*.
- *HP ProLiant DL360 G6 Server User Guide* provides information describing LED functions of the DL 360 G6 server.
- *HP ProLiant DL360p Gen8 Server User Guide* provides information describing LED functions of the DL 360p Gen8 server.
- *HP ProLiant DL380 G6 Server User Guide* provides information describing LED functions of the DL 380 G6 server.
- *Hp ProLiant DL380 Gen8 Server User Guide* provides information describing LED functions of the DL 380p Gen8 server.
- See the *HP ProLiant BL460c G6 Server Blade User Guide* for information describing LED functions of the BL460c G6 server.
- See the *HP ProLiant BL460c Gen8 Server Blade User Guide* for information describing LED functions of the BL460c Gen8 server.
- See *Telect 100A 4-Position Demarcation Circuit Breaker panel* for information describing the Telect 100A 4-Position Demarcation DC Power Distribution Panel LEDs.
- See *Telect 100A Dual-feed 4/4 TPA/GMT, -48V* for information describing the Telect 100A Dual-feed DC Power Distribution Panel LEDs.

Policy Management (Policy) Platform Configuration

Cabinet configurations are specific to customer requirements. All hardware components listed in *General Descriptions and Hardware Features* may not be shown in the example configurations presented. You must refer to your customer order for exact configuration and rack line-up.

Refer to *General Descriptions and Hardware Features* for the components that may be installed in an Policy Management (Policy) c-Class cabinet.

Examples of possible cabinet configuration and component placement are presented here.

- Figure 1: Example of an AC cabinet with Cisco 4948-4948E
- Figure 2: Example of an AC Co-Mingled cabinet with Cisco 4948E-F
- Figure 3: Example of a DC cabinet with Cisco 4948-4948E
- Figure 4: Example of a DC Co-Mingled cabinet with Cisco 4948E-F

Add enclosure 1 (UFU-U16), enclosure 2 (U17-U26) and enclosure 3 (U27-U38). Max 3




Figure 1: Example of an AC cabinet with Cisco 4948-4948E




Figure 2: Example of an AC Co-Mingled cabinet with Cisco 4948E-F

U	E	Eagle	XG c-C	Class C	abinet	(Max	config)	
44		TEL	ECT 4/	4 PAN	EL (805	5-0197-	R01)		PDP A
43		TEL	ECT 4/	4 PAN	EL (805	5-0197-	R01)		PDP B
42			OPE	N - FIL	LER P/	ANEL		_	Bracket (U42)
41	TELE	ЕСТ НО	DEMA	RCATIC	ON PAN	EL (805	5-0198-	R01)	PDP C
40	TELE	ЕСТ НО	DEMA	RCATIC	ON PAN	EL (805	5-0198-	R01)	PDP D
39			OPE	N - FIL	LER P/	ANEL			
38	TELE	ЕСТ НО	DEMA	RCATIC	on pan	EL (805	5-0198-	R01)	PDP E
37	TELE	ЕСТ НО	DEMA	RCATIC	on pan	EL (805	5-0198-	R01)	PDP F
36			OPE	N - FIL	LER P/	ANEL			
35	Cisco 4	4948/4	948E A	\ggrega	<mark>ition S</mark> v	vitch B			Switch B (rear mounted)*
34	Cisco 4	4948/4	948E A	\ggrega	<mark>ition S</mark> v	vitch A			Switch A (rear mounted)*
33			OPE	N - FIL	LER P/	ANEL			Bracket (U33)
32			OPE	N - FIL	LER P/	ANEL			
31				0 - MG					Management Server 1
30			805-05	537-G06	6/805-0	609-01			
29			SERV	ER D 8	305-054	15-Gxx			
28			SERV	ER C 8	305-054	15-Gxx			> Optional Rack Mount Servers
27				ER B 8					
26			_	/ER A 8	_	_	_)
25		SE	ISMIC	BRACE	E (805-	0188-G	601)		
24		_8_							
23									
22									
21	-				_		_		
20	1	2	3	4	5	6	7	8	2nd Extension c7000 enclosure (CXEN2) (805-0541-G01)
19									
18 17									
16							▏▀▋▀		
15	9	10	11	12	13	14	15	16	
14				BRACE				10	
13									
12									
11									
10							▏▀▇▀		
9	1	2	3	4	5	6	7	8	c7000 enclosure
8		-	_	_	_	_	_	_	(CXEN1) (805-0541-G01)
7									
6									
5									
4	9	10	11	12	13	14	15	16	J
3				OP	ΈN				-
2				N - FIL					DC Cable Management Area
1			OPE	N - FIL	LER P/	ANEL			3

Figure 3: Example of a DC cabinet with Cisco 4948-4948E




Figure 4: Example of a DC Co-Mingled cabinet with Cisco 4948E-F

• Figure 5: AC Cabinet with Cisco 4948E-F, (3) Enclosures, (1 DL380/2 DL360)

- Figure 6: AC Cabinet with Cisco 4948E-F, (2) Enclosures, (6 DL380/12 DL360)
- Figure 7: AC Cabinet with Cisco 4948E-F, (1) Enclosures, (11 DL380/12 DL360)
- Figure 8: DC Cabinet; (2) Enclosures; (2) Switches; RMS
- Figure 9: DC Cabinet; (1) Enclosure; (2) Switches; RMS

	1	U		_	Cabi	inet (M	ax Co	nfia)		_	È.	
		42	1 388			BURNE AT	an co			888 I I I		
		41	1.	SWITC	HB		-					
		40		CHATC			<u>0</u>					
		39		SWITC	A H.							
		38					SERV	ERA (8	05-059	9-XX)		
		37	SERV	ERA-	805-060	19-XX	SERV	ER B (8	05-059	9-XX)		
		36	1)	2)	3)	(\$	(\$	(\$	9	(6)		
		35	-bay	-bay	-bay	-bay	-bay	-bay	·bay	-bay		
		34	(cxen3-bay1)	(cxen3-bay2)	(cxen3-bay3)	(cxen3-bay4)	(cxen3-bay 4)	(cxen3-bay 4)	(cxen3-bay 7)	(cxen3-bay8)		
		33										
		32	1	2	3	4	5	6	7	8		
		31	(6)	y10	111	412	y13	414	y15	y16		
		30	3-ba	3-ba	3-ba	3-ba	3-ba	3-ba	3-ba	3-ba		
1		29	(cxen3-bay9)	(cxen3-bay10)	(cxen3-bay11)	(cxen3-bay12)	(exen3-bay13) un	(cxen3-bay14) on	(cxen3-bay15)	(cxen3-bay16)		1
	A1-4 EXT. BAR	28									B1-4 EXT. BAR	l
	B	27	9	10	11	12	13	14	15	16	m	l
	×	26 25	ay1)	ay2)	ay3)	ay4)	ay5)	ay6)	ay7)	ay8)	×	l
	4	24	12-b	12-b	12-b	12-b	12-b	2-b	2-b	12-b	4	l
	A1-	23	(cxen2-bay1)	(cxen2-bay2)	(cxen2-bay3)	(cxen2-bay4)	(cxen2-bay5)	(cxen2-bay6)	(cxen2-bay7)	(cxen2-bay8)	m	l
	_	22	1			4						l
	A3-4 EXT. BAR	21		(cxen2-bay10)	(cxen2-bay11)	2)	(cxen2-bay13)	(cxen2-bay14) o	(cxen2-bay15)	(cxen2-bay16) co	B3-4 EXT. BAR	l
	- H	20	(cxen2-bay9)	bay	bay	(cxen2-bay12)	bay	bay	bay	bay	E.	l
	X	19	en2-	en2-	en2-	an2-	an2-	an2-	an2-	an2-	Ш	l
	Z	18			(cxe	(cx e	(cx o	(cx o	(cx o	(cx c	Z	l
	A3	17	9	10	11	12	13	14	15	16	B	
		16	3	5	3	(4)	6	6	E	6		
		15	-ba	(eq-	(eq-	-ba	-ba	-ba	-ba	-ba		
		14	(cxen1-bay1)	(cxen1-bay2)	(cxen1-bay3)	(cxen1-bay4)	(cxen1-bay5)	(cxen1-bay6)	(cxen1-bay7)	(cxen1-bay8)		
		13										
		12	1	ent-bay 10) ĸ	3	4	5	6	7	8		
	2	11	en1-bay9)	ay10	en1-bay11)	en1-bay12)	en1-bay13)	en1-bay14)	en1-bay15)	en1-bay16)		
		10 9	1-be	11-be	11-be	1-b	1-b	1-be	1-b	11-be		
		8	(cxer	(cxer	(схег	(cxer	(cxer	(cxer	(схел	(схел		
		7	9	10	11	12	13	14	15	16		
	1	6	,	10	11	PDU		14	1.5	10		
		5				PDU						
		4				PDU						
		3				PDU						
		2				PDU						
		1				PDU						

Figure 5: AC Cabinet with Cisco 4948E-F, (3) Enclosures, (1 DL380/ 2 DL360)

			U		Cabinet (Max Config)									
		2	42				Manager .	L. Manager						
		3	41		SWITC	HB								
			40	-			C.	1						
		2	39		SWITC	HA								
			38					SERV	ERA (8	05-059	9-XX)			
		3	37	SERV	ERA-8	305-060	09-XX	-		05-059				
			36							05-059				
			35	SERV	ER B - 8	305-060	09-XX			05-059				
			34							05-059				
			33	SERV	ERC-8	305-060	09-XX	SERV	ERF(8	05-059	9-XX)			
		- 1	32					SERV	ER G (8	05-059	9-XX)			
		1	31	SERV	ERD-1	305-06	09-XX	SERV	ER H (8	05-059	9-XX)			
			30	CED14	-	005 050	0 VV	SERV	ER I (8	05-059	9-XX)			
			29	SERV	EKE-0	305-060	J9-XX	SERV	ER J (8	05-059	9-XX)			
	1	Ω.	28	SEDI	EP E - G	305-060	19.99	SERV	ER K (8	05-059	9-XX)	CC.		
		BAR	27	SERV	ER F - C	505-000	J3-77	SERV	ER L (8	05-059	9-XX)	B1-4 EXT. BAR		
		E	26	÷.	3	(6	(4)	9	(9)	5	(8)	E		
		EXT.	25	(cxen2-bay1	(cxen2-bay2)	(cxen2-bay3)	(cxen2-bay4)	(cx en2-bay5)	(cxen2-bay6)	(cxen2-bay7)	(cxen2-bay8)	ŵ		
		A1-4	24	en2	en2	en2	en2	en2	en2	en2	en2	4		
		A	23				ğ		-	-		'n		
l	Ľ	Ľ	22	1	2	3	4	5	6	7	8	Ľ	Ľ	
l	8	BAR	21	(6 Åi	(cxen2-bay10)	(cxen2-bay11)	(cxen2-bay12)	(cxen2-bay13)	(cxen2-bay14)	(cxen2-bay15)	(cxen2-bay16)	B	'n	
l	F	EXT.	20	2-ba	2-ba	2-ba	2-ba	2-ba	2-ba	2-ba	2-ba	F.	F	
l	Û	Û	19	(cxen2-bay9)	xen	xen;	xen	xen	xen	xen;	xen	Û	Ц,	
l	A3-3 EXT. BAR	A3-4	18				_					B3-4 EXT. BAR	B3-3 EXI. BAR	
L	A	A	17	9	10	11	12	13	14	15	16	ш	ш	
		3	16	av1)	ay 2)	ay 3)	ay 4)	ay 5)	ay 6)	(1/10	ay 8)			
			15 14	1-b	1-b	1-b	1-b	1-b	1-b	1-b	1-b			
		1	14	(cxen1-bay1)	(cxen1-bay2)	(cxen1-bay3)	(cxen1-bay4)	(cxen1-bay5)	(cxen1-bay6)	(cxen1-bay7)	(cxen1-bay8)			
			12	1	2	3	4	5	6	7	8			
		5	11											
			10	ays	Day1	Day1	Day1	Day1	Day1	Day1	ay1			
			9	en1-bay9)	en1-bay10)	en1-bay11)	en1-bay12)	en1-bay13)	en1-bay14)	en1-bay15)	en1-bay16)			
			8	(cxe	(cxe	(cxe	(cxe	(cxe	(cxe	(cxe	(cxe			
		8	7	9	10	11	12	13	14	15	16			
			6				PDU							
			5				PDU	A3						
			4				PDU	B2						
		1	3				PDU	A2						
		6	2				PDU	B1						
			1				PDU	A1						

Figure 6: AC Cabinet with Cisco 4948E-F, (2) Enclosures, (6 DL380/ 12 DL360)

		U			Cab	inet (M	ax Co	nfia)					
		42		_		BROOM I	Lan Co		0000000000	0000	ň –		
		41	12	SWITC	HB								
		40					1						
		39	1.	SWITC	HA								
		38					SERV	ERA (8	05-059	9-XX1	2		
		37	SERV	ERA-8	805-060	09-XX		ER B (8					
		36						ER C (8					
		35	SERV	ER B - 8	305-060	9-XX		ER D (8					
		34						ERE (8					
		33	SERV	ERC-8	805-060	19-XX		ER F (8					
		32					SERV	ERG (8	05-059	9-XX)			
		31	SERV	ERD-8	805-060	J9-XX	SERV	ER H (8	05-059	9-XX)			
		30					SERV	ER I (80	5-059	9-XX)	8		
		29	SERV	ERE-8	305-060	19-XX	SERV	ER J (80	05-059	9-XX)			
	œ	28	CEDV	-	805-060		SERV	ER K (S	05-059	9-XX)	CC.		
	BAR	27	SERV	ER F - C	505-060	19-AA	SERV	ER L (80	05-059	9-XX)	B1-4 EXT. BAR		
	E	26	SERV	ER C.	305-060	10.VV		FILLER	PANEL		E		
	EXT.	25	SERV	EN G + G	505-000	13· 14		FILLER	PANEL		Ш		
	A1-4	24	SERV	ER H .	305-060	19.77		FILLER	PANEL		4		
	A	23	JENV	LIXIT-C	505-000	13- AA		FILLER	PANEL		à		
Ľ	CL.	22	SERV	FRI-8	05-060	9.XX		FILLER	PANEL		C.	CC.	
BA	BAR	21	DENT	Litt o	00 000			FILLER	PANEL		BAR	BA	
t		20	SERV	ERJ-8	05-060	9-XX		FILLER	PANEL			E	
ŵ	EXT	19						FILLER	PANEL		ŵ	ŵ	
A3-3 EXT. BAR	A3-4	18	SERV	ERK-8	05-060	19-XX		FILLER	PANEL		B3-4 EXT	B3-3 EXT. BAR	
A	A	17						FILLER	PANEL	_	00	00	
		16	9/1)	9/2)	9(3)	N4)	(9)	(9 k)	(1/4	(B)			
		15	1-ba	I-ba	1-ba	1-ba	-ba	1-ba	1-ba	I-ba			
		14	(cxen1-bay1)	(cxen1-bay2)	(cxen1-bay3)	(cxen1-bay4)	(cxen1-bay5)	(cxen1-bay6)	(cxen1-bay7)	(cxen1-bay8)			
		13					-						
		12	1	2	3	4	5	6	7	8			
		11	ay9)	(cxen1-bay10)	ent-bay11)	en1-bay12)	ant-bay13)	en1-bay14)	en1-bay15)	en1-bay16)			
		10	en1-bay9)	1-b	11-b	11-b	1-b	1-b	1-b	1-b			
		8	(cxen	cx en	(cxen	(cxer	(cxen	(cxer	(cxen	(cxer			
		7	9	10	11	12	13	14	15	16			
		6	9	10	11	PDU		14	15	10			
		5				PDU							
		4				PDU							
		3				PDU							
		2				PDU							
		1				PDU							

Figure 7: AC Cabinet with Cisco 4948E-F, (1) Enclosures, (11 DL380/ 12 DL360)

U		_	Cab	inet (N	lax co	nfia)							
44	P	DP A -			PANEL		197-R0	1)					
43					PANEL								
42	-	OPEN - FILLER PANEL											
41	PDP	PDP C - TELECT HC DEMARCPANEL (805-0198-R01)											
40	PDP D - TELECT HC DEMARCPANEL (805-0198-R01)												
39	OPEN - FILLER PANEL												
38	PDP E - TELECT HC DEMARCPANEL (805-0198-R01)												
37	PDP F - TELECT HC DEMARCPANEL (805-0198-R01)												
36	OPEN - FILLER PANEL												
35													
34	SWITCHB												
33	30000												
32	5	WITCH	A		1112								
31	DL	380 - S	ERVER	RA.	DL360 -	SERVER	A (915-	0607369					
30			509-XX()		DL360	SERVER	B (895-0	0007-000					
29	DL	380 - S	ERVER	RB	DL360-	SERVER	C (005-0	0607-90Q					
28			509-XX()		DL360 -	SERVER	D (815-0	617-203					
27	DL	380 - S	ERVER	RC	DL350 -	SERVER	E (105-0	687.009					
26		(805-06	609-XX()		DL360-	SERVER	F (105-0	887-509					
25		SE	ISMIC	BRACI	E (805-	0188-G	01)						
24			~										
23	6-600	6-G10	6-G10	(mm2-boyd) 205-0596-033	(materia) 805-0596-000	(read-leafe) 805-0596-0313	(1102-0536-021) 805-0536-0212	(mad ling) 805.0595.0233					
22	[croi2-boal] 005-0036-031	(cros2-boy2) 805-0556-0213	(crost-bryd) 005-0556-021)	5-059	5-059	5.059	5.059 5.059	5 059					
21	- 2	- 2	- 2	- 2	- 2	- 2	- 8	- 5					
20	1	2	3	4	5	6	7	8					
19								4 2 4					
18	(Sint)	(0)44-010) 00-009-000	the second	1110	(conditive) 805-0595-000	(multitude) 805-0595-020	(1044-0444) 805-0595-0202	5.8					
17	(con2-bog9) 00-000-000	(0)44(0) 05-055-000	(cond-brigh) 805-0555-000	(0)/v1(0)/00) 005-0056-000	69-69	68.089	5 059	(01444444)					
16	- 2	-2	~8	28	28		-8	1000					
15	9	10	11	12	13	14	15	16					
14		SE	ISMIC	BRACE	E (805-	0188-G	01)						
13													
12	(matha)	(contray2) 01-0556-GO	(contray)) 01-0556-GO	[contbat] 0.0356-00	[conttay]) 0.0816-00	[mathy]	[mathy]) 6.0556-20	(mutby)					
11	(cont-byl) 501-0516-GO	(contray2) 501-0536-GOO	(centray) 801-0556-GO	(matheyt) 801-0556-GOX	(contray) 881-0816-000	(mathy) 00-066-200	(mathsyl) 805-866-020	(mu11mg2) 201-0516-020X					
10	8	*	*	*	*		80	60					
9	1	2	3	4	5	6	7	8					
8				~~		~		# <u>1</u>					
7	(controys) 01-0156-600	[craf-bay]]] 01-0156-GO	(cont-boy1) 01-0156-GO	6-60	6-00	[multhyft]]	[enul bay5] 01-0156-0200	SILIE					
6	(controy) 801-0136-GOC	[crat-byf0] 891-0156-GOC	(cent-bag1) 801-0186-GCC	[craftbyf2] 895-0156-GCC	[enuldayt3] 895-0586-000	[multibritk] 805-0156-02CC	(evid bey 5) 801-0156-020X	Generation XI					
5	8	- 35	- 38	- 38	-30	- 30	- 30	Creek C					
4	9	10	11	12	13	14	15	16					
3				OPE			-						
2			OPE	N - FIL	LER P	ANEL NEL							
1			VEC		LEN P/	THE		-					

Figure 8: DC Cabinet; (2) Enclosures; (2) Switches; RMS

U	_		Cab	inet (N	lax co	nfig)								
44	P	DP A -	TELEC	CT 4/4 F	ANEL	(805-0	197-R0	1)						
43	P	DP B -	TELEC	T 4/4 F	ANEL	(805-0	197-R0	1)						
42	-		OPE	N - FILI	LER PA	ANEL		-						
41	PDP	C - TEL	ECT H	DEMA	RCPAN	IEL (80	5-0198-	-R01)						
40	PDP	PDP D - TELECT HC DEMARCPANEL (805-0198-R01)												
39	OPEN - FILLER PANEL													
38	PDP E - TELECT 4/4 PANEL (805-0197-R01)													
37	OPEN - FILLER PANEL													
36	OPEN - FILLER PANEL													
35														
34	SWITCH B													
33														
32	SWITCHA													
31	DL:	380 - S	ERVER	RA	DL360 -	SERVER	A (805-0	0607-XX)						
30		(805-06	509-XX)		DL360 -	SERVER	B (805-0	0607-XX)						
29	DL:	380 - S	ERVER	RB	DL380 -	SERVER	C (805-0	0607-XX)						
28		(805-06	509-XX)		DL360 -	SERVER	D (805-0	0607-XX)						
27	DL	380 - S	ERVER	RC	DL380 -	SERVER	E (805-0	607-XXJ						
26		(805-06	509-XX)		DL360 -	SERVER	F (805-0	607-XX)						
25	DL	380 - S	ERVER	RD	DL360 -	SERVER	G (805-0	0607-XX)						
24	(805-0609-XX) DL380 - SERVER H (806-0607-XX)													
23	DL	380 - S	ERVER	RE	DL360	SERVER	1 (805-0	607-HX)						
22		(805-00	609-XX)		DL360 -	SERVER	J (805-0	(607-XX)						
21	DL	380 - S	ERVE	RF	DL360 -	SERVER	К (805-0	607-XX)						
20		(805-06	509-XX)		DL360 -	SERVER	L (805-0	607-XXJ						
19	DL	380 - S	ERVER	RG	OPE	N-FILL	ER PA	NEL						
18		(805-06	509-XX)		OPE	N-FILL	ER PA	NEL						
17	DL:	380 - S	ERVER	RH	OPE	N-FILL	ER PA	NEL						
16	4	(805-06	509-XX)		OPE	N-FILL	ER PA	NEL						
15			OPE	N - FILI	LER PA	ANEL								
14		SE	ISMIC	BRACE	E (805-	0188-G	01)							
13	-×	-8	-8	-8	-8	- 8	-8	-8						
12	(cont-beyl) 005-0506-GXX	[cm+bay2] 805-0596-0XX	[count-bay3] 005-0556-GXX	[cm1+bay4] 805-0596-GXX	(court-bay5) 005-00506-QXX	[cont-bayb] 805-0556-GXX	[cum1-boy7] 805-0536-GXX	[cont-bay8] 805-0556-GX						
11	(cxu)	[COM 805-05	[cma 005-05	[Com 805-05	[com 005-05	1000 805-05	[com 005-05	[con 805-05						
10														
9	1	2	3	4	5	6	7	8						
8	-×	εð	-8	εð	æŏ	τŏ	æŏ	985- 619-00						
7	(creat-buy9) 05-0536-GXC	(com1-bay10) 05-0536-QXX	(csent-beyft) 05-0536-GX)	(cont-bayl2) 05-0536-GX	(count-bey13) 05-0536-QX)	(coent-bay14) 05-0536-GX0	(csent-beyf5) 05-0536-QX)	K 405-0						
6	(cccn1-buy9) 805-0536-GXX	(crent-bay10) 805-0586-020	(cont-beyf) 005-0536-QXX	[cont-bay12] 805-0536-033	(count-bay13) 805-0536-QXX	(cont-bayt4) 805-0536-GXX	(csent-broyf5) 805-0536-QXX	(countrbuy %) 01 8546-622.05.205-6615						
5					100		2.6							
4	9	10	11	12	13	14	15	16						
3			OPE	OPE		ANEL								
1			OPE			ANEL								

Figure 9: DC Cabinet; (1) Enclosure; (2) Switches; RMS