

**Oracle® Communications
EAGLE**

ATINP User's Guide

E54350-01 Revision A

July 2014

Oracle® Communications ATINP User's Guide

Copyright © 1993, 2014,

Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services.

Table of Contents

Chapter 1: Introduction.....	6
Introduction.....	7
Scope and Audience.....	7
Manual Organization.....	8
Documentation Admonishments.....	8
My Oracle Support (MOS).....	9
Emergency Response.....	9
Related Publications.....	10
Documentation Availability, Packaging, and Updates.....	10
Locate Product Documentation on the Oracle Technology Network Site.....	10
Chapter 2: Feature Description.....	12
ATINP Feature Overview.....	13
The ATINPQ Local Subsystem.....	14
ATINP Configuration Options.....	16
ATINP Protocol Handling of MSUs.....	31
ATINP Return Result Message.....	32
ATINP Error Response MSU Encoding.....	36
Hardware Requirements.....	37
MPS/EPAP Platform.....	37
Chapter 3: EAGLE ATINP Commands.....	38
EAGLE 5 Commands.....	39
Chapter 4: ATINP Configuration.....	41
Introduction.....	42
EPAP Entity Provisioning.....	42
System Prerequisites.....	42
ATINP Feature Prerequisites.....	43
ATINP Configuration Procedure.....	44
Enabling ATINP, Setting STP Options, and Turning On ATINP.....	45
Enabling the Service Portability Feature.....	47

Provisioning True Point Codes and Capability Point Codes.....	48
Provisioning the ATINPQ Local Subsystem.....	49
Adding the ATINPQ Local Subsystem Application.....	49
Removing a Local Subsystem Application.....	51
Provisioning the ATINP Service Selector.....	52
Adding an ATINP Service Selector.....	52
Removing a Service Selector.....	53
Changing an Existing Service Selector to an ATINP Service Selector.....	54
Provisioning the ATINP Options.....	57
Activating the ATINPQ Local Subsystem.....	58
Turning On the Service Portability Feature.....	59
Turning Off the Service Portability Feature.....	60
Changing the State of a Subsystem Application.....	61
Taking the Subsystem Application Offline.....	62
Taking the Subsystem Application Online.....	63
Chapter 5: ATINP Measurements.....	65
ATINP Measurements.....	66
Chapter 6: Maintenance.....	68
ATINPQ Subsystem Alarms (UAMs).....	69
ATINPQ Subsystem UIMs.....	69
Maintenance Commands.....	71
rept-stat-sccp.....	72
EAGLE 5 ISS Debug Commands.....	72
Status Reporting and Problem Identification.....	73
EPAP Status and Alarm Reporting.....	74
Glossary.....	77

List of Tables

Table 1: Admonishments.....	8
Table 2: Handling of Multiple Requests in RequestedInfo.....	14
Table 3: ATINP Options.....	16
Table 4: RTDB Lookup Success Determination.....	32
Table 5: Encoded Number Portability Status value.....	35
Table 6: Commands used for ATINP.....	39
Table 7: System Prerequisites.....	42
Table 8: ATINP Feature Prerequisite.....	43
Table 9: ATINPQ Local Subsystem Prerequisites.....	49
Table 10: Subsystem Allow/Inhibit.....	58
Table 11: Pegs for Per System and Per SSP.....	66
Table 12: ATINPQ UAMs.....	69
Table 13: ATINPQ UIMs.....	70
Table 14: Maintenance Commands.....	71
Table 15: Status Reporting for EPAP-Related Features.....	73

Chapter 1

Introduction

Topics:

- *Introduction.....7*
- *Scope and Audience.....7*
- *Manual Organization.....8*
- *Documentation Admonishments.....8*
- *My Oracle Support (MOS).....9*
- *Emergency Response.....9*
- *Related Publications.....10*
- *Documentation Availability, Packaging, and Updates.....10*
- *Locate Product Documentation on the Oracle Technology Network Site.....10*

This chapter contains a brief description of the ATINP feature. The contents include sections about the manual scope, audience, and organization; how to find related publications; and how to contact Oracle for assistance.

Introduction

Before number portability, SCPs and other querying nodes could easily determine which network the subscriber belonged to based on the digits dialed by the caller. With number portability, subscriber digits cannot be relied upon to determine the subscriber's network.

Anytime Interrogation Number Portability Query (ATINP) is an Oracle Communications EAGLE feature that provides a method for querying entities to obtain number portability, routing information, or location information for subscribers directly from an EAGLE.

ATINP provides number portability functions for decoding the information in the incoming ATI query message, number conditioning before the Real Time Database (RTDB) lookup, determining the success or failure of the RTDB lookup, and formatting the Return Result or Error Response based on the result of the lookup. ATINP is fully compliant with the ATI standards for Global Number Portability in 3GPP TS 23.066 V7.0.0 (2007-06), *Support of Mobile Number Portability*.

ATINP supports the use of Additional Subscriber Data (ASD) in formatting response messages.

ATINP supports Service Portability functions that allow a subscriber to keep the same phone number when switching from one type of network or service technology to another within the same operator's network. With Service Portability, the subscriber remains with the same operator, but receives service from a different network technology supported by that operator or moves from one physical network to another, with both networks operated by the same service provider. The Service Portability (S-Port) feature allows RTDB GRN Entity digits to be used as Service Portability prefixes for own-network GSM and IS41 subscribers in response digit formats.

ATINP supports functions to cluster CNLs into groups referred to as ROPs, which can be used to simplify routing and simple billing analysis in cases where the number of supported CNLs is very large. The Generic Routing Number field is used to store ROP information.

The ATINPQ local subsystem in the EAGLE processes ITU-TCAP ATI messages with the requested information parameter *MNP Requested Info* or *Location Information*. The EAGLE responds with an ATI ACK message that contains either number portability and routing information or location information, or responds with an ATI NACK message if the requested information cannot be provided. The original ATI query is discarded.

ATINP is an EPAP-based feature that requires Oracle Communications EAGLE Application Processor Provisioning (EPAP) provisioning data from the Real Time Database (RTDB). Subscriber data is transferred from customer databases to the EPAP. The EPAP formats the RTDB and loads it to each Service Module card on the EAGLE. The RTDB data is used in obtaining number portability information and in determining how to correctly format the ATI ACK response message.

Scope and Audience

This manual is intended for anyone responsible for installing, maintaining, and using the ATINP feature in the Oracle Communications EAGLE. Users of this manual and the others in the EAGLE family of documents must have a working knowledge of telecommunications and network installations.

Manual Organization




This document is organized into the following chapters:


- *Introduction* contains general information about the ATINP documentation, the organization of this manual, and how to get technical assistance.
- *Feature Description* provides a functional description of the ATINP feature, including network perspectives, assumptions and limitations, a database overview, Service Module provisioning and reloading, ATINP user interface, and an audit overview.
- *EAGLE ATINP Commands* describes the commands that can be used for ATINP feature configuration functions.
- *ATINP Configuration* provides procedures for configuring the ATINP feature for use in the Oracle Communications EAGLE.
- *ATINP Measurements* describes ATINP-related measurements, measurements reports, and methods of collection.
- *Maintenance* describes ATINP-related UAMs and UIMs, commands that can be used for maintenance functions; and status and alarm reporting for the EAGLE, Oracle Communications EAGLE Application Processor Provisioning (EPAP), Service Module cards, services, and the local subsystem.

Documentation Admonishments

Admonishments are icons and text throughout this manual that alert the reader to assure personal safety, to minimize possible service interruptions, and to warn of the potential for equipment damage.

Table 1: Admonishments

Icon	Description
 DANGER	Danger: (This icon and text indicate the possibility of <i>personal injury</i> .)
 WARNING	Warning: (This icon and text indicate the possibility of <i>equipment damage</i> .)
 CAUTION	Caution: (This icon and text indicate the possibility of <i>service interruption</i> .)

Icon	Description
	Topple: (This icon and text indicate the possibility of <i>personal injury and equipment damage.</i>)

My Oracle Support (MOS)

MOS (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support (CAS) can assist you with MOS registration.

Call the CAS main number at **1-800-223-1711** (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>. When calling, make the selections in the sequence shown below on the Support telephone menu:

1. Select **2** for New Service Request
2. Select **3** for Hardware, Networking and Solaris Operating System Support
3. Select **2** for Non-technical issue

You will be connected to a live agent who can assist you with MOS registration and provide Support Identifiers. Simply mention you are a Tekelec Customer new to MOS.

MOS is available 24 hours a day, 7 days a week, 365 days a year.

Emergency Response

In the event of a critical service situation, emergency response is offered by the Customer Access Support (CAS) main number at **1-800-223-1711** (toll-free in the US), or by calling the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>. The emergency response provides immediate coverage, automatic escalation, and other features to ensure that the critical situation is resolved as rapidly as possible.

A critical situation is defined as a problem with the installed equipment that severely affects service, traffic, or maintenance capabilities, and requires immediate corrective action. Critical situations affect service and/or system operation resulting in one or several of these situations:

- A total system failure that results in loss of all transaction processing capability
- Significant reduction in system capacity or traffic handling capability
- Loss of the system's ability to perform automatic system reconfiguration
- Inability to restart a processor or the system
- Corruption of system databases that requires service affecting corrective actions
- Loss of access for maintenance or recovery operations
- Loss of the system ability to provide any required critical or major trouble notification

Any other problem severely affecting service, capacity/traffic, billing, and maintenance capabilities may be defined as critical by prior discussion and agreement with Oracle.

Related Publications

For information about additional publications that are related to this document, refer to the *Related Publications Reference* document, which is published as a separate document on the Oracle Technology Network (OTN) site. See [Locate Product Documentation on the Oracle Technology Network Site](#) for more information.

Documentation Availability, Packaging, and Updates

Tekelec provides documentation with each system and in accordance with contractual agreements. For General Availability (GA) releases, Tekelec publishes a complete EAGLE 5 ISS documentation set. For Limited Availability (LA) releases, Tekelec may publish a documentation subset tailored to specific feature content or hardware requirements. Documentation Bulletins announce a new or updated release.

The Tekelec EAGLE 5 ISS documentation set is released on an optical disc. This format allows for easy searches through all parts of the documentation set.

The electronic file of each manual is also available from the [Tekelec Customer Support](#) site. This site allows for 24-hour access to the most up-to-date documentation, including the latest versions of Feature Notices.

Printed documentation is available for GA releases on request only and with a lead time of six weeks. The printed documentation set includes pocket guides for commands and alarms. Pocket guides may also be ordered separately. Exceptions to printed documentation are:

- Hardware or Installation manuals are printed without the linked attachments found in the electronic version of the manuals.
- The Release Notice is available only on the Customer Support site.

Note: Customers may print a reasonable number of each manual for their own use.

Documentation is updated when significant changes are made that affect system operation. Updates resulting from Severity 1 and 2 Problem Reports (PRs) are made to existing manuals. Other changes are included in the documentation for the next scheduled release. Updates are made by re-issuing an electronic file to the customer support site. Customers with printed documentation should contact their Sales Representative for an addendum. Occasionally, changes are communicated first with a Documentation Bulletin to provide customers with an advanced notice of the issue until officially released in the documentation. Documentation Bulletins are posted on the Customer Support site and can be viewed per product and release.

Locate Product Documentation on the Oracle Technology Network Site

Oracle customer documentation is available on the web at the Oracle Technology Network (OTN) site, <http://docs.oracle.com>. You do not have to register to access these documents. Viewing these files requires Adobe Acrobat Reader, which can be downloaded at www.adobe.com.

1. Log into the Oracle Technology Network site at <http://docs.oracle.com>.
2. Under **Applications**, click the link for **Communications**.
The **Oracle Communications Documentation** window opens with Tekelec shown near the top.
3. Click **Oracle Communications Documentation for Tekelec Products**.
4. Navigate to your Product and then the Release Number, and click the **View** link (the **Download** link will retrieve the entire documentation set).
5. To download a file to your location, right-click the PDF link and select **Save Target As**.

Feature Description

Topics:

- [ATINP Feature Overview.....13](#)
- [The ATINPQ Local Subsystem.....14](#)
- [ATINP Configuration Options.....16](#)
- [ATINP Protocol Handling of MSUs.....31](#)
- [ATINP Return Result Message.....32](#)
- [ATINP Error Response MSU Encoding.....36](#)
- [Hardware Requirements.....37](#)
- [MPS/EPAP Platform.....37](#)

This chapter describes the functions provided by the ATINP feature, including MSU protocol handling, ATI message decoding, and response message formatting.

The chapter includes an overview of the EAGLE Provisioning Application Processor (EPAP). EPAP provides the Realtime Database (RTDB) that is used in the database lookup functions.

ATINP Feature Overview

ATINP Functions

The ATINP feature provides number portability functions and Service Portability functions for decoding the incoming ATI message, conditioning the MSISDN to International format if needed, performing the RTDB lookup, and determining the result of the lookup.

ATINP configuration options affect the following functions and values:

- Number conditioning of the incoming MSISDN digits before RTDB lookup is performed
- Determination of a successful RTDB lookup
- Controlling whether the IMSI, MSISDN, Routing Number, and Location parameters will be included or not included in the ATI ACK response message
- Controlling the length of formatted digits for Location Information queries
- Formatting of the IMSI, MSISDN, Routing Number, and Location parameters in the ATI ACK response message, and the maximum number of digits to be used from the SRFISMSI or entity ID in the encoding format
- Default routing number and outbound message digits delimiter to be used in outbound message formats
- Use of GRN digits as Routing Number digits in the ATI ACK response message for own-network subscribers (example: using GRN digits for ROP information)

Response message handling functions determine whether a success or failure response is needed (or no response), format the information in the response message, send the response, and issue any required UIMs and network management messages.

ATINP Considerations

The GTT feature must be on before the ATINP feature can be enabled.

The ATINP feature must be enabled before configuration options can be provisioned in the ATINPQOPTS table for ATINP. The Service Portability feature must be also enabled before the ATINPQOPTS SPORTTYPE configuration option can be provisioned to use Service Portability with ATINP.

The ATINP feature and the Service Portability feature must be turned on before Service Portability processing will occur for ATI Query messages.

Note: The Service Portability feature, the IDP A-party Blacklist feature, support for ROP data, and ATINP support for Location Information use GRN data for different purposes. The IDP A-party Blacklist feature is mutually exclusive with the Service Portability feature, and this restriction is enforced in feature provisioning. Feature provisioning does not enforce the restriction that the Service Portability feature is mutually exclusive with ROP data support and ATINP support for Location Information.

The ATINPQ Local Subsystem

Local subsystems in the EAGLE 5 are maintainable entities for query and response that are used when the STP acts as an SCP. Specific point codes can be defined for routing to local subsystems independently of the STP in the network. A local subsystem can be taken online and offline as needed in the system.

The ATINPQ local subsystem in the EAGLE 5 processes ITU-TCAP ATI messages with the requested information parameter *MNP Requested Info* or *Location Information*. The EAGLE 5 responds with an ATI ACK message that contains number portability and routing information or location information, or responds with an ATI NACK message if the requested information cannot be provided. The original ATI query is discarded.

If RequestedInfo contains *MNP Requested Info* and *Location Information* or other requests (for example: *subscriberState*), then RequestedInfo is considered to contain only *MNP Requested Info*. The other requests will be ignored. Refer to [Table 2: Handling of Multiple Requests in RequestedInfo](#) for handling of multiple requests in RequestedInfo. A *Location Information* query is processed only if ATINP is enabled and turned on and the ATISUPPLOCINFO option is set to ON.

Table 2: Handling of Multiple Requests in RequestedInfo

MNP Requested Info	Location Information	any other request	Request handled by ATINPQ Subsystem
No	No	Yes	UIM 1402: ATINPQ: Invalid Requested Info will be generated and an error response will be sent
Yes	No	No	MNP Requested Info
Yes	Yes	No	MNP Requested Info
Yes	Yes	Yes	MNP Requested Info
No	Yes	No	Location Information
No	Yes	Yes	Location Information

ATINP supports ANSI MTP/SCCP and ITU-TCAP ATI query or ITU MTP/SCCP and ITU-TCAP ATI query.

For ATINP, EAGLE 5 supports ANSI, ITU-I, ITU-N, ITU-I Spare, and ITU-N Spare capability point code types. ITU-N24 point codes are not supported. Capability point codes for the ATINPQ local subsystem can be configured only after the ATINP feature is enabled.

The ATINPQ local subsystem can have a mate subsystem and a concerned point code group assigned to it. The ATINPQ local subsystem cannot be set to Load Shared mode (as end nodes do not perform load sharing), but can be set only to Dominant or Solitary mode. The ATINPQ local subsystem can be entered in MAP table if the ATINP feature is enabled.

The ATINPQ local subsystem can be taken online and offline using the procedures in [Changing the State of a Subsystem Application](#).

Messages for the ATINPQ Local Subsystem

Messages for the ATINPQ local subsystem can arrive Rt-on-SSN or Rt-on-GT. All MSUs must contain either the EAGLE 5 true or secondary point code (TSPC), or the ATINPQ capability point code (CPC) in the DPC field of the message. Traditionally, messages for local subsystems were allowed to have the DPC as the EAGLE 5 STP CPC. However, it is strongly recommended to use the ATINPQ CPC for ATI queries, and not the CPC of the STP for network management issues that can arise.

Rt-on-SSN Handling

If the message arrives Rt-on-SSN, it must contain the EAGLE 5 ATINPQ subsystem number in the Called Party Subsystem field of the message.

If the ATINPQ local subsystem is online, the DPC field can contain either the EAGLE 5 true or secondary point code or the ATINPQ capability point code. Any response message will use the true or secondary point code assigned to the EAGLE 5 as the OPC. Because the EAGLE 5 cannot generate an SSP when a message arrives Rt-on-SSN for the EAGLE 5 CPC, nodes sending Rt-on-SSN traffic should use the true or secondary point code.

If the ATINPQ local subsystem is offline and the mated subsystem is available, the EAGLE 5 will generate a network management message to force the network to transition traffic to the mate.

Rt-on-GT Handling

Rt-on-GT MSUs can arrive either with SCCP CdPA information that matches an EAGLE 5 service selector, or with a GTA address that has been provisioned to translate to the ATINPQ local subsystem.

If the ATINPQ subsystem is online, the DPC field can contain either the EAGLE 5 true or secondary point code or the ATINPQ capability point code. The query is directed to the local subsystem and processed. Any response message will use the true or secondary point code assigned to the EAGLE 5 as the OPC.

If the ATINPQ local subsystem is offline and the mated subsystem is available, the EAGLE 5 will act as both STP and SCP, and reroute the message to the mated subsystem. If a Rt-on-GT message arrives for the EAGLE 5 true or secondary point code, the EAGLE 5 cannot generate a TFP. The EAGLE 5 handles and reroutes these messages, instead of forcing the adjacent node to route to the mate. Therefore, nodes that send Rt-on-GT traffic to an EAGLE 5 should use an ATINPQ CPC, not the EAGLE 5 TSPC.

Network Management Responses

The EAGLE 5 must reply to network management queries about the current state of the local subsystem. When the local subsystem changes state, network management messages are sent to the CSPC group.

Multiple Local Subsystems

The EAGLE 5 supports provisioning Capability Point Codes for two or more local subsystems, allowing local subsystems for two or more EPAP-based features to operate at the same time in the system. For example, local subsystems for the ATINP feature and the EIR feature can coexist in the system.

Though queries meant for any local system will still be processed if they are sent with DPC = STP CPC, it is strongly recommended not to use the STP CPC for such queries. Instead, the CPC for the appropriate subsystem should be used as the DPC of the message. For instance, for LNP queries use the LNP CPC, not the STP CPC. For ATI queries, use the ATINPQ CPC, and so on.

ATINP Configuration Options

The ATINP configuration options described in [Table 3: ATINP Options](#) are used for the following functions:

- Specify the format of the IMSI, MSISDN, Routing Number, or Location parameters in the ATI ACK response message, and the maximum number of digits to be used from the SRFIMSI or Entity ID in the encoding format.
- Determine whether the IMSI, MSISDN, Routing Number, or Location parameter is included or not included in the ATI ACK response message.
- Specify the default routing number and outbound message digits delimiter to be used in outbound message formats.
- Specify the number conditioning to be performed on the MSISDN digits in the incoming ATI query message before RTDB lookup is performed, and indicate the determination of a successful RTDB lookup.
- Specify Service Portability processing that can be performed for ATI messages.

Table 3: ATINP Options

Option	Value	Action in the STP
ATIACKIMSI - used for IMSI parameter encoding in the ATI ACK message	NONE	This is the default value. The IMSI parameter is not included in the ATI ACK response message.
	SRFIMSI	If an Entity was found during lookup and <ul style="list-style-type: none"> • If SRFIMSI is provisioned in the Entity, then encode the outgoing IMSI digits as the SRFIMSI. • If SRFIMSI is not provisioned in the Entity, then do not include the IMSI parameter in the ATI ACK response.
	ASD	The IMSI digits in the ATI ACK response are encoded as the ASD (Additional Subscriber Data) if ASD is found during RTDB lookup and ASD was provisioned in the EPAP. If ASD is not available, the IMSI parameter is not included in the response message.
	GRN	The IMSI digits in the ATI ACK response are encoded as the GRN if GRN is supported and found during RTDB lookup and GRN was provisioned in the EPAP. If GRN is not supported or not provisioned, the IMSI parameter is not included in the response message.

Option	Value	Action in the STP
ATIACKMSISDN - specifies the inclusion and formatting of the MSISDN in the ATI ACK response	NONE	MSISDN parameter is not included in the ATI ACK response.
	MSISDN	This is the default value. MSISDN digits in the ATI ACK response are encoded as the MSISDN from the incoming ATI query. If the RTDB lookup matched on odd number of digits, then the MSISDN is encoded with the match in the RTDB without the trailing 0.
	ASD	The MSISDN in the ATI ACK response is encoded as the ASD (Additional Subscriber Data) if the MSISDN was found during RTDB lookup and ASD was provisioned in EPAP. If ASD is not available, the MSISDN parameter is not included in the ATI ACK response.
	ASDDLMMMSISDN	The MSISDN digits in the ATI ACK response message are encoded as ASD (if available) + ATIDLM (if not NONE) + MSISDN from the incoming message. If the RTDB lookup matched on odd number of digits, then the MSISDN is encoded with the match in the RTDB without the trailing 0.
	GRN	The MSISDN digits in the ATI ACK response message are encoded as GRN if supported and found during RTDB lookup, and provisioned in the EPAP. If GRN is not supported or not provisioned, the MSISDN parameter is not encoded in the ATI ACK response.
	GRNDLMMMSISDN	The MSISDN digits in the ATI ACK response are encoded as GRN (if supported and available) + ATIDLM (if not NONE) + MSISDN from the incoming message. When GRN field is supported, it is returned in the entity lookup data if GRN entity was found. If GRN field is not supported or not available by EPAP, it is not included in any formats specifying GRN. If the RTDB lookup matched on odd number of digits, then the MSISDN is encoded with the match in the RTDB without the trailing 0.

Option	Value	Action in the STP
ATIACKRN - specifies the formatting of the Routing Number digits in the ATI ACK response	NONE	The Routing Number parameter is not included in the response.
	RN	<p>This option value is expected to be used when Service Portability is used with ATINP.</p> <p>If Entity type RN was found in RTDB lookup, the subscriber is generally considered to be a foreign subscriber.</p> <p>The exception is the case when Entity data is RN with PT=0, and either the IGM feature is on or the Service Portability feature is enabled; the subscriber is considered to be an own-network IS41 subscriber in this case. The Entity type is considered to be SP.</p> <p>Foreign Subscribers</p> <p>Encode Routing Number digits as the found Entity ID. (Not affected by Service Portability processing.)</p> <p>Own Subscriber</p> <p>If the Service Portability feature is ON, the Entity type is SP (GSM subscriber), the SPORTTYPE option value is GSM or ALL, and GRN is available, encode the Routing Number as GRN. If GRN is not available, a UIM is generated and the Routing Number is not included in the response.</p> <p>If the Service Portability feature is ON, the Entity type is SP (GSM subscriber), the SPORTTYPE option value is IS41 or NONE, the behavior is the same as when the Service Portability feature is OFF.</p> <p>If the Service Portability feature is ON, the Entity type is RN and PT = 0 (IS41 subscriber), the SPORTTYPE option value is IS41 or ALL, and GRN is available, encode the Routing Number as GRN. If GRN is not available, a UIM is generated and the Routing Number is not included in the response.</p> <p>If the Service Portability feature is ON, the Entity type is RN and PT = 0 (IS41 subscriber), the SPORTTYPE option value is GSM or NONE, the behavior is the same as when the Service Portability feature is OFF.</p> <p>If the Service Portability feature is ON, and a DN is not found in the RTDB, the DN is found</p>

Option	Value	Action in the STP
		<p>but no Entity is found, or the DN is found and the Entity type is not SP or RN with PT = 0, the behavior is the same as when the Service Portability feature is OFF</p> <p>When the Service Portability feature is OFF, the Routing Number digits are encoded as the ATIDFLTRN option value instead of the Entity ID, if the ATIDFLTRN value is not NONE and one of the following conditions is true:</p> <ul style="list-style-type: none"> • MSISDN was found but No Entity found in RTDB. • MSISDN was not found in RTDB (only in the case of ATINPTYPE=ALWAYS; for ATINPTYPE=ANY, this results in a lookup failure). • Entity was found with type SP or considered to be type SP. <p>In all other cases, the Routing Number parameter is not included in the ATI ACK response.</p> <p>This is the default value.</p>
	RNSP	<p>If an Entity was found in RTDB lookup and Entity type was either SP or RN, encode Routing Number digits as the found Entity ID.</p> <p>The Routing Number digits are encoded as the ATIDFLTRN option value if the ATIDFLTRN value is not NONE and one of the following conditions is true:</p> <ul style="list-style-type: none"> • MSISDN found but Entity was not found. • MSISDN was not found in RTDB (Only in case of ATINPTYPE=ALWAYS. For ATINPTYPE=ANY, this results in a lookup failure). • Entity of type other than SP or RN was found. <p>In all other cases, the Routing Number parameter is not included in the response.</p>
	ASDDLMRNSP	<p>Encode the Routing Number as ASD (if available from lookup Entity) + ATIDLM (if not NONE) + RNSP.</p> <p>RNSP is encoded as described for the ATIACKRN=RNSP value.</p>

Option	Value	Action in the STP
		<p>If formatting results in 0 digits or only DLM digits, the Routing Number parameter is not included in the response message.</p> <p>If ATIDL M is not NONE, and ASD digits are available, DLM is included even if RN/SP does not have any digits (resulting in ASD+DLM).</p> <p>The ASD field is returned in the Entity lookup data, if Entity was found. If the ASD field is not provisioned in EPAP, it is not included in any formats specifying ASD.</p>
	RNSPDLMASD	<p>Encode Routing Number digits as RN/SP + ATIDL M (if not NONE) + ASD (if available from lookup Entity).</p> <p>RN/SP is encoded as described for the ATIA CKRN=RNSP option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number is not included in the response message.</p> <p>If ATIDL M is not NONE and ASD digits are available, DLM is included even if RN/SP does not have any digits, resulting in DLM+ASD.</p>
	SRFIMSI	<p>Encode Routing Number digits as SRFIMSI configured in the entity data.</p> <p>If SRFIMSI was not found (MSISDN not found in RTDB, MSISDN found but no Entity found, or Entity found but SRFIMSI not configured), then the Routing Number is not included in the response message.</p>
	SRFIMSIDLMASD	<p>Encode Routing Number digits as SRFIMSI + ATIDL M (if not NONE) + ASD (if available from lookup Entity).</p> <p>SRFIMSI is encoded as described for the ATIA CKRN=SRFIMSI option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number is not included in the response message.</p> <p>If ATIDL M is not NONE and ASD digits are available, DLM is included even if SRFIMSI does not have any digits, resulting in DLM+ASD.</p>

Option	Value	Action in the STP
	ASDDLMSRFIMSI	<p>Encode Routing Number as ASD (if available from lookup Entity) + ATIDLM (if not NONE) + SRFIMSI.</p> <p>SRFIMSI is encoded as described for the ATIACKRN=SRFIMSI option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number parameter is not included in the response message.</p> <p>If ATIDLM is not NONE and ASD digits are available, DLM is included even if SRFIMSI does not have any digits (resulting in ASD+DLM).</p> <p>The ASD field is returned in the Entity lookup data (if Entity was found). If the ASD field is not provisioned in EPAP, it is not included in any formats specifying ASD.</p>
	GRNDLMRNSP	<p>Encode Routing Number as GRN (if supported and available from lookup Entity) + ATIDLM (if not NONE) + RNSP.</p> <p>RNSP is encoded as described for the ATIACKRN = RNSP option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number parameter is not included in the response message.</p> <p>If ATIDLM is not NONE and GRN digits are available, DLM is included even if RN/SP does not have any digits, resulting in GRN+DLM.</p> <p>The GRN field is returned in the Entity lookup data, if GRN Entity was found. If the GRN field is not provisioned in EPAP, it is not included in any formats specifying GRN.</p>
	RNSPDLMGRN	<p>Encode Routing Number as RN/SP + ATIDLM (if not NONE) + GRN (if supported and available from lookup entity).</p> <p>RN/SP is encoded as described for the ATIACKRN = RNSP option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number parameter is not included in the response message.</p> <p>If ATIDLM is not NONE and GRN digits are available, DLM is included even if RN/SP does not have any digits, resulting in DLM+GRN.</p>

Option	Value	Action in the STP
		<p>The GRN field is returned in the Entity lookup data, if GRN Entity was found. If the GRN field is not provisioned in EPAP, it is not included in any formats specifying GRN.</p>
	SRFIMSIDLMGRN	<p>Encode Routing Number as SRFIMSI + ATIDL M (if not NONE) + GRN (if supported and available from lookup entity).</p> <p>Note: SRFIMSI digits configured with RN or SP entity data are used only to encode the Routing Number.</p> <p>SRFIMSI is encoded as described for the ATIACKRN = SRFIMSI option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number parameter is not included in the response message.</p> <p>If ATIDL M is not NONE and GRN digits are available, DLM is included even if SRFIMSI does not have any digits, resulting in DLM+GRN.</p> <p>The GRN field is returned in the Entity lookup data, if GRN Entity was found. If the GRN field is not provisioned in EPAP, it is not included in any formats specifying GRN.</p>
	GRNDLMSRFIMSI	<p>Encode Routing Number as GRN (if supported and available from lookup entity) + ATIDL M (if not NONE) + SRFIMSI.</p> <p>SRFIMSI digits configured with RN or SP entity data are used only to encode the Routing Number.</p> <p>SRFIMSI is encoded as described for the ATIACKRN = SRFIMSI option.</p> <p>If formatting results in 0 digits or only DLM digits, the Routing Number parameter is not included in the response message.</p> <p>If ATIDL M is not NONE and GRN digits are available, DLM is included even if SRFIMSI does not have any digits, resulting in GRN+DLM.</p> <p>The GRN field is returned in the Entity lookup data, if GRN Entity was found. If the GRN field is not provisioned in EPAP, it is not included in any formats specifying GRN.</p>

Option	Value	Action in the STP
<p>ATIACKVLRNUM - specifies the formatting of the vlr-number within Location Information in the ATI ACK response; affects protocol processing only if ATINP feature is turned on</p> <p>Note: If vlr-number does not have any digits to encode due to Entity not found or ATIDFLTRN not provisioned, then the incoming MSISDN is encoded as vlr-number.</p>	ASD	<p>The vlr-number is encoded as ASD configured in the Entity data.</p> <p>If ASD was not found (for example: MSISDN is not found in RTDB or MSISDN is found but no ASD is found), then the vlr-number is encoded as incoming MSISDN.</p>
	ASDDLNRNSP	<p>The vlr-number is encoded as ASD, if available from RTDB lookup + ATINPQOPTS:ATIDL (if not NONE) + RNSP. The RNSP part is encoded as described in the option ATIACKVLRNUM = RNSP, except for the MSISDN encoding if RN/SP is not found.</p> <p>If ATIDL is not NONE and ASD digits are available, DLM is included even if RN/SP does not have any digits (resulting in ASD+DLM).</p> <p>If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	ASDDLMSRFIMSI	<p>The routing number is encoded as ASD (if available from RTDB lookup) + ATINPQOPTS:ATIDL (if not NONE) + SRFIMSI. The SRFIMSI part is encoded as described in the option ATIACKVLRNUM = SRFIMSI.</p> <p>If ATIDL is not NONE and ASD digits are available, DLM is included even if SRFIMSI does not have any digits (resulting in DLM+ASD).</p> <p>If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	ASDMSISDN	<p>The vlr-number in the ATI ACK response is encoded as ASD (if found during RTDB lookup) + incoming MSISDN.</p> <p>If ASD was not found (for example: MSISDN is not found in RTDB or MSISDN is found but no ASD is found), then the vlr-number is encoded as incoming MSISDN.</p>
	GRNDLMSRFIMSI	<p>The vlr-number is encoded as GRN (if available from RTDB lookup) + ATINPQOPTS:ATIDL (if not NONE) + SRFIMSI. The SRFIMSI part is encoded as described in the option ATIACKVLRNUM= SRFIMSI.</p>

Option	Value	Action in the STP
		<p>If ATIDLm is not NONE and GRN digits are available, DLM is included even if SRFIMSI does not have any digits (resulting in GRN+DLM).</p> <p>If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	GRNDLMRNSP	<p>The vlr-number is encoded as GRN (if available from RTDB lookup) + ATINPQOPTS:ATIDLm (if not NONE) + RNSP. The RNSP part is encoded as described in the option ATIAckVLRNUM = RNSP, except for the MSISDN encoding if RN/SP is not found.</p> <p>If ATIDLm is not NONE and GRN digits are available, DLM is included even if RN/SP does not have any digits (resulting in GRN+DLM).</p> <p>If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	MSISDN	<p>The vlr-number in the ATIAck response is encoded as the incoming MSISDN.</p>
	RN	<p>If Entity = RN was found in RTDB lookup, the subscriber is considered to be a foreign subscriber, except in the special case when Entity = RN/PT=0 and either the IGM feature is turned on or the S-Port feature was enabled. If the S-Port feature was enabled, the subscriber is considered IS41 Own Subscriber and is not considered to be a foreign subscriber.</p> <p><i>For Foreign Subscriber</i></p> <p>Encode vlr-number digits as found in Entity (RN). This specifies that the vlr-number in the ATIAck response is encoded as RN, if found during RTDB lookup. This is not affected by Service Portability (S-Port).</p> <p><i>For Own Subscriber</i></p> <p>When the Service Portability feature (S-Port) is ON:</p> <p>IF Entity type SP is found (considered GSM subscribers)</p> <p>IF SPORTTYPE = GSM or ALL,</p> <p>IF EPAP GRN is available,</p>

Option	Value	Action in the STP
		<p>THEN Encode vlr-number as EPAP GRN.</p> <p>ELSE</p> <ul style="list-style-type: none"> • UIM: 1426 S-Port: Missing GRN for srvc prtd subs • Standard ATIA CK response is encoded with MSISDN as vlr-number. <p>ELSE (SPORTTYPE = IS41 or NONE)</p> <p>Same behavior as when Service Portability is off</p> <p>ELSE IF Entity is found with data RN/PT=0 (IS-41 subscribers):</p> <p>IF SPORTTYPE = IS41 or ALL,</p> <p>IF EPAP GRN is available,</p> <p>THEN Encode vlr-number as EPAP GRN.</p> <p>ELSE</p> <ul style="list-style-type: none"> • UIM: 1426: S-Port: Missing GRN for srvc prtd subs • Standard ATI response is encoded with MSISDN as vlr-number. <p>ELSE (SPORTTYPE = GSM or NONE)</p> <p>Same behavior as when Service Portability is off</p> <p>ELSE</p> <p>(implies S-Port is ON and either:</p> <ul style="list-style-type: none"> • DN not found in RTDB, or • DN found and no entity, or • DN found and Entity neither SP nor RN/0) <p>Same behavior as when Service Portability is off</p> <p>When the Service Portability feature (S-Port) is OFF:</p> <p>IF ATINPQOPTS:ATIDFLTRN is not NONE and any of the following is true:</p> <ul style="list-style-type: none"> • MSISDN was found but no Entity was found in RTDB. • MSISDN was not found in RTDB. (This applies only when ATINPTYPE=ALWAYS. For ATINPTYPE=ANY, this results in an RTDB lookup failure.)

Option	Value	Action in the STP
		<ul style="list-style-type: none"> Entity was found with type SP. (If IGM is ON or S-Port is enabled, and Entity is RN/PT=0, then this is considered to be Entity type SP, not RN.) <p>THEN ATIDFLTRN is used in place of the Entity. The vlr-number digits are encoded as ATIDFLTRN.</p> <p>ELSE The vlr-number parameter is encoded as incoming MSISDN in the response.</p>
	RNMSISDN	<p>The vlr-number in the ATI ACK response is encoded as RN, if found during RTDB lookup, + incoming MSISDN.</p> <p>IF ATINPQOPTS:ATIDFLTRN is not NONE and any of the following is true:</p> <ul style="list-style-type: none"> MSISDN was found but no Entity found in RTDB MSISDN was not found in RTDB (This applies only when ATINPTYPE=ALWAYS. For ATINPTYPE=ANY, this results in an RTDB lookup failure.) Entity was found with type SP (If IGM is ON or S-Port is enabled, and entity data is RN/PT=0, it is considered to be of type SP, not RN.) <p>THEN ATIDFLTRN is used in place of Entity. The vlr-number is encoded as ATIDFLTRN + incoming MSISDN.</p> <p>IF ATINPQOPTS:ATIDFLTRN is NONE,</p> <p>THEN the vlr-number is encoded as incoming MSISDN in the response.</p>
	RNSP	<p>If Entity was found during NPDB lookup and Entity type was either SP or RN, encode vlr-number as the found entity ID.</p> <p>Otherwise, if ATINPQOPTS:ATIDFLTRN is not NONE and any of the following conditions are met, the vlr-number is encoded as ATIDFLTRN:</p> <ul style="list-style-type: none"> MSISDN was found, but Entity was not found in RTDB. MSISDN was not found in RTDB. This applies only when ATINPTYPE=ALWAYS. For ATINPTYPE=ANY, this results in a lookup failure.

Option	Value	Action in the STP
		<ul style="list-style-type: none"> Entity of type other than SP or RN was found. <p>In all other cases, vlr-number is encoded as the incoming MSISDN in the ATI ACK response.</p>
	RNSPDLMASD	<p>The vlr-number is encoded as RN/SP + ATIDL M (if not NONE) + ASD (if available from RTDB lookup). RN/SP is encoded as described in the option ATIACKRN = RNSP, except for the MSISDN encoding if RN/SP not found.</p> <p>If ATIDL M is not NONE and ASD digits are available, DLM is included even if RN/SP does not have any digits (resulting in DLM+ASD).</p> <p>If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	RNSPDLMGRN	<p>The vlr-number is encoded as RN/SP + ATIDL M (if not NONE) + GRN (if available from RTDB lookup). RN/SP is encoded as described in the option ATIACKRN = RNSP, except for the MSISDN encoding if RN/SP is not found.</p> <p>If ATIDL M is not NONE and GRN digits are available, DLM is included even if RN/SP does not have any digits (resulting in DLM+GRN).</p> <p>If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	RNSPMSISDN	<p>This is the default value.</p> <p>If Entity was found during RTDB lookup and Entity type was SP or RN, encode vlr-number as the found Entity type + incoming MSISDN.</p> <p>ELSE IF ATINPQOPTS:ATIDFLTRN is not NONE and any of the following is true:</p> <ul style="list-style-type: none"> MSISDN was found, but Entity was not found in RTDB. MSISDN was not found in RTDB. This applies only when ATINPTYPE=ALWAYS. For ATINPTYPE=ANY, this results in a lookup failure. Entity of type other than SP or RN was found.

Option	Value	Action in the STP
		<p>THEN vlr-number is encoded as ATIDFLTRN. IF ATINPQOPTS:ATIDFLTRN is NONE, THEN vlr-number is encoded as incoming MSISDN in the response.</p>
	SRFIMSI	<p>The vlr-number is encoded as SRFIMSI is configured in the Entity data. If SRFIMSI was not found (for example: MSISDN not found in RTDB, MSISDN found but no Entity found, or SP/RN Entity found but SRFIMSI not configured), then the vlr-number is encoded as the incoming MSISDN. SRFIMSI digits configured with only Entity type RN or SP are used to encode vlr-number.</p>
	SRFIMSIDLMAASD	<p>The vlr-number is encoded as SRFIMSI + ATIDLMA (if not NONE) + ASD (if supported and available from RTDB lookup). SRFIMSI is encoded as described in the option ATIACKVLRNUM = SRFIMSI. If ATIDLMA is not NONE and ASD digits are available, DLM is included even if SRFIMSI does not have any digits (resulting in DLM+ASD). If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
	SRFIMSIDLMAGRN	<p>The vlr-number is encoded as SRFIMSI + ATIDLMA (if not NONE) + GRN (if available from RTDB lookup). SRFIMSI is encoded as described in the option ATIACKVLRNUM= SRFIMSI. If ATIDLMA is not NONE and GRN digits are available, DLM is included even if SRFIMSI does not have any digits (resulting in DLM+GRN). If the formatting results in no digits or only DLM digits, the vlr-number is encoded with only MSISDN in the response.</p>
ATIDFLTRN - Default Routing Number used in encoding outgoing formats in the ATI ACK response in cases where an	NONE	This option can be set to NONE at any time. The default value is NONE.
	HEX (1-15 digits)	The specific encoding is described further in other option value descriptions.

Option	Value	Action in the STP
RN is not returned from an RTDB lookup		
ATIDLDM - specifies whether delimiter digits or no delimiter is to be used in encoding outbound digits in ATI ACK response	NONE	This option can be set to NONE at any time by the user. The default value is NONE.
	HEX (1-15 digits)	
ATINPTYPE - specifies when an RTDB lookup is successful	ANY	MSISDN lookup is considered successful when any match is found (RN, SP, and match with no entity, GRN with PT=0xFF). See ATINP Protocol Handling of MSUs for a description of determination of success. This specifically excludes the case when MSISDN is not found in RTDB.
	ALWAYS	The lookup is always considered to be successful whether or not MSISDN is found in RTDB match.
ENTITYLEN - maximum number of digits to be used from RTDB lookup data (SRFIMSI or Entity ID) to encode Routing Number digits in the encoding format specified by the ATIACKRN option If Entity ID or SRFIMSI is not being used by the specified ATIACKRN format, this option does not apply.	NONE	This is the default value. The SRFIMSI or Entity ID is used without modification in the ATIACKRN format specified.
	Decimal (1-15)	Example: If the SRFIMSIDLMASD format is specified, ENTITYLEN = 5, SRFIMSI from Entity = 1234567890 (10 digits), ASD = 123, and DLM = 55, then a maximum of 5 digits is used from SRFIMSI to encode the format as 12345 + 55 + 123. If ENTITYLEN = NONE, then all ten digits from SRFIMSI would be used. The same applies to formats that encode an Entity ID.
OFF - Disables or turns off a comma-separated list of feature options	ATISUPP LOCINFO	This value specifies that Location Information request is not processed by the ATINP subsystem if the ATINP feature is turned on. This is the default value for ATISUPPLOCINFO.
ON - Enables or turns on a comma-separated list of feature options	ATISUPP LOCINFO	This value specifies that Location Information request is processed by the ATINP subsystem if the ATINP feature is turned on.
SNAI - specifies either that the NAI of the incoming MSISDN	INTL	The NAI of the incoming MSISDN digits is considered to be International. No conditioning

Option	Value	Action in the STP
digits is considered to be International or International regardless of the NAI value in the incoming MSISDN, or that the NAI value determines whether number conditioning to International format is needed before RTDB lookup		is performed on the MSISDN before RTDB lookup.
	NAT	The NAI of the incoming MSISDN digits is considered to be National. The MSISDN is conditioned to international format before RTDB lookup by pre-pending the provisioned STPOPTS default country code (DEFCC) parameter value. The STPOPTS DEFCC parameter must be provisioned to a value other than NONE before the ATINP feature can be turned on. The DEFCC value cannot be set to NONE after the ATINP feature is turned on.
	NAI	This is the default value. The NAI field of the MSISDN parameter determines whether number conditioning is required before RTDB lookup. If NAI is INTL (0x01) or Network Specific Number (0x3), then the number is considered to be International and no conditioning is performed before RTDB lookup. If NAI is not considered INTL, it is considered to be National. The STPOPTS default country code (DEFCC) value is pre-pended to the MSISDN to condition it to international format before RTDB lookup.
SPORTTYPE - indicates the Service Portability processing that is requested for ATI queries for own-network subscribers; can be provisioned when the Service Portability feature is enabled but not turned on; impacts protocol processing only if the Service Portability feature is turned on.	NONE	This is the default value. No Service Portability processing is requested.
	GSM	Service Portability is requested for ATI queries for own-network GSM subscribers (Entity = SP).
	IS41	Service Portability is requested for ATI queries for own-network IS41 subscribers (Entity = RN, PT = 0).
	ALL	GSM and IS41 Service Portability is requested for own-network subscribers (Entity = SP or Entity = RN, PT = 0).
VLRNUMLEN - indicates the maximum number of digits that can be encoded as vlr-number in ATI ACK, as defined by ATIACKVLRNUM	Decimal (1-40)	The default value is 40. Example: If ATIACKVLRNUM = RNSPMSISDN format is specified, VLRNUMLEN = 12, MSISDN is 1234567890, entity RN from RTDB

Option	Value	Action in the STP
		lookup was 13579, then the vlr-number digits would be 135791234567890. With VLRNUMLEN = 12, the vlr- number digits in the Location Information field of response message are encoded as 135791234567.

Note:

If the Service Portability feature is enabled or the IGM feature is turned on, and RTDB lookup results in Entity = RN and PT=0, then the Entity is considered to be SP.

If the RTDB lookup matched on odd number of digits, then the MSISDN is encoded with the match in the RTDB without the trailing 0.

ATINP Protocol Handling of MSUs

ATINP supports SCCP UDT and non-segmented XUDT Class 0 and Class 1 messages.

The high-level ATINP message processing flow, after the MSU reaches the active local subsystem is:

1. Decode and verify the incoming ATI message.

The requestedInfo parameter must be MNP Requested Info or Location Information. If message contains both requests (MNP Requested Info and Location Information), then MNP Requested Info is processed.

The incoming MSISDN must have at least one digit.

The information in each MSU is decoded and verified on the LIM card. SCCP messages to the EAGLE 5 (Service Indicator = 3) are forwarded to Service Module cards for processing.

Response messages and UIMs (see [ATINPQ Subsystem UIMs](#)) can be generated for various common decode errors and for some ATINP-specific decode errors. Some malformed messages do not generate any response.

2. Condition the incoming MSISDN to international format if it is not considered to be international already.

An MSISDN of 15 digits or less will be conditioned to International format if needed.

The MSISDN is considered to be in International format if either of the following conditions is true:

- The ATINP option SNAI=INTL is provisioned. See [ATINP Configuration Options](#).
- The ATINP option SNAI=NAI is provisioned and the Nature of Address field in the MSISDN is INTL (0x1) or Network Specific Number (0x3).

An MSISDN of more than 15 digits is not conditioned for lookup. If the provisioned value of the ATINPTYPE option is ALWAYS, a response is sent for "MSISDN NOT Found in NPDB".

A trailing Stop Digit (0xF) in the MSISDN is treated as filler and will not be considered as part of the MSISDN during lookup.

3. Search the RTDB to locate the conditioned MSISDN.

If the conditioned MSISDN is not found in the individual entries, the range entries are searched (odd/even number lookups are supported).

4. Determine whether the lookup is considered successful, based on provisioned ATINP options.
The provisioned ATINP TYPE option value determines whether the lookup is considered to be successful. See [Table 4: RTDB Lookup Success Determination](#).
5. If the lookup is successful, use the lookup information and ATINP options to encode the ATI ACK response message, and route the response to the originator of the ATI query. See [ATINP Configuration Options](#).
Note: In a successful DN lookup, if ASD is part of one of the entities, Additional Subscriber Data will be considered in formatting of the outgoing response message.
6. If the lookup is not successful, send an ATI NACK response message with the appropriate error code.
7. Discard the original ATI message.

See [ATINP Configuration Options](#) for option descriptions and response formats.

Table 4: RTDB Lookup Success Determination

ATINP TYPE Option	DN found in RTDB	Entity Found	Entity Type	Portability Type	Lookup Success
ALWAYS	N/A	N/A	N/A	N/A	Success
ANY	No	N/A	N/A	N/A	Failure
	Yes	No	N/A	N/A	Success
		Yes	SP	N/A	Success
			RN	N/A	Success
			GRN	0xFF	Success
			VMS	0xFF	Success
			All other cases are considered lookup failure.		

ATINP Return Result Message

A Return Result message ("ATI ACK" message) is used to return the result of the ATINP Query when the RTDB lookup is considered to be successful.

The Return Result message includes Number Portability Status. Routing Number digits, MSISDN digits, and IMSI digits can be included, and ASD and GRN data can be used, depending on RTDB lookup results and ATINP configuration option values. [ATINP Configuration Options](#) describes the options and the encoding results for each option value.

Routing Number

If the ATIACKRN option value is not **none**, routing number information is included in the response message. The ATIACKRN option values determine the data from the RTDB lookup that is used in the outgoing RN. (See [ATINP Configuration Options](#).)

A default routing number can be provisioned using the ATIDFLTRN option, to be used in the outgoing message formats when an RN is not returned from the RTDB lookup.

Additional Subscriber Data is included in some of the formats of the return result information if it is available in the found Entity. The following formats consider Additional Subscriber Data (ASD) digits for encoding the outgoing RN parameter:

- ASD+DLM+RNSP
- RNSP+DLM+ASD
- SRFIMSI+DLM+ASD
- ASD+DLM+SRFIMSI

Generic Routing Number (GRN) digits included in an Entity can be used in formatting the outgoing RN. The Generic Routing Number can be used in identifying GSM or IS41 own-network subscribers for Service Portability, or for identifying members of ROPs (CNL clusters). The following formats consider Generic Routing Number (GRN) digits for encoding the outgoing RN parameter:

- GRN+DLM+RNSP
- RNSP+DLM+GRN
- SRFIMSI+DLM+GRN
- GRN+DLM+SRFIMSI

Note: If the RTDB Entity type is RN with PT=0 and either the IGM feature is On or the Service Portability feature is enabled, the subscriber is considered to be an own-network IS41 subscriber, and the Entity type is treated as SP. See the ATIACKRN=RN configuration option description in [ATINP Configuration Options](#).

A maximum of 40 digits will be encoded in the routeingNumber field. Though the specified length of routeingNumber is 1-5 bytes, ATINP allows encoding of up to 40 digits, based on the ATIACKRN ATINP option value. If the format results in more than 40 digits, the digits will be truncated to satisfy the 40-digit limit. If truncation of digits occurs, UIM 1403 "LSS: Dgts truncated in encd parms" will be generated.

An outbound message digits delimiter and a maximum number of digits to be used from Entity data can be provisioned for use in the encoding formats.

If an odd number of digits is encoded, a filler of 0xF is used as the last digit.

IMSI Digits

If the ATIACKIMSI option value is not **none**, IMSI digits are included in the response, as indicated by the following ATIACKIMSI values:

- SRFIMSI - If an Entity was found during lookup and SRFIMSI was provisioned in the Entity, then the IMSI digits are encoded as the SRFIMSI value.
- ASD - If an Entity was found during RTDB lookup and ASD (Additional Subscriber Data) was provisioned in the EPAP Entity, then IMSI digits are encoded as the ASD. If ASD is not available, the IMSI parameter will not be encoded in the response message.

- GRN - If an Entity was found during RTDB lookup and GRN (Generic Routing Number) was provisioned in the EPAP Entity, then IMSI digits are encoded as the GRN. If GRN is not available, the IMSI parameter will not be encoded in the response message.

The ASD format considers ASD digits for encoding the outgoing IMSI parameter.

The Generic Routing Number can be used in identifying GSM or IS41 own-network subscribers for Service Portability, or for identifying members of ROPs (CNL clusters). The GRN format considers GRN digits for encoding the outgoing IMSI parameter.

If an odd number of digits is encoded, a filler of 0xF is used as the last digit.

MSISDN

If the ATIACKMSISDN option value is not **none**, MSISDN digits are included in the response. The digits can be either the MSISDN from the incoming message, Additional Subscriber Data found in the EPAP Entity, Generic Routing Number found in the EPAP Entity, or a combination of MSISDN, ASD or GRN, and digits delimiter.

The following formats consider ASD digits for encoding the outgoing MSISDN parameter:

- ASD
- ASD+DLM+MSISDN

Generic Routing Number (GRN) digits included in an Entity can be used in formatting the outgoing MSISDN. The Generic Routing Number can be used in identifying GSM or IS41 own-network subscribers for Service Portability, or for identifying members of ROPs (CNL clusters). The following formats consider GRN digits for encoding the outgoing MSISDN parameter:

- GRN
- GRN+DLM+MSISDN

A maximum of 40 digits will be encoded in the MSISDN digits field. Though the specified length of MSISDN is 1-9 bytes – 1 byte for nature of address/numbering plan, eight bytes for digits, ATINP will allow encoding of up to 40 digits for this field, based on the ATIACKMSISDN ATINP option value. If the format results in more than 40 digits, the digits will be truncated to satisfy the 40 digit limit. UIM 1403: "LSS: Dgts truncated in encd parms" will be generated.

If an odd number of digits was encoded, a filler of 0xF is used as the last digit. The Nature of Address field will be copied from the incoming MSISDN.

Number Portability Status

The portability type of the MSISDN can represent the following types of numbers:

- An own number ported out
- An own number not ported out
- A foreign number ported in
- A foreign number ported to foreign network
- Foreign number not known to be ported

Because the existing EPAP portability does not support options for "Own number not ported out" and "Foreign number ported in", this feature cannot distinguish between these two types of numbers that belong to own network. Using configured data, a best fit match will be made for returning number portability status (encoded value is in parentheses), as follows:

Table 5: Encoded Number Portability Status value

Encoded Number Portability Status value	Criterion
Not Known To Be Ported (0)	<ul style="list-style-type: none"> • MSISDN not found in the NPDB • MSISDN found with no entity and EPAP portability type (PT) provisioned as one of the following values: <ul style="list-style-type: none"> • 0 (NOT KNOWN TO BE PORTED) • 1 (OWN NUMBER PORTED OUT) • 2 (FOREIGN NUMBER PORTED TO FOREIGN NETWORK) • 36 (NOT IDENTIFIED TO BE PORTED) • 0xFF (none - NO STATUS) • MSISDN and Entity found in RTDB with Entity type = RN, PT = 0, S-Port is not enabled, and IGM feature is OFF. • MSISDN and Entity found in RTDB with Entity type = RN, and PT=0xFF (none - NO STATUS) or PT=36 (Not identified to be ported). <p>Note: This says that if a routing number was not found in RTDB (no Entity) then the MNP SRF cannot provide any useful information to the querying node about the network that owns this MSISDN. The querying node uses its available digits to route the call. PT=5 implies migrated customer (own network) and PT=3, 4, and 6-35 are prepaid servers that are also own subscribers.</p>
Own Number Ported Out (1)	MSISDN and Entity found in RTDB with Entity type=RN and PT=1 (OWN NUMBER PORTED OUT)
Foreign Number Ported To Foreign Network (2)	MSISDN and Entity found in RTDB with Entity type=RN and PT=2 (FOREIGN NUMBER PORTED TO FOREIGN NETWORK)
Own Number Not Ported Out (4)	<ul style="list-style-type: none"> • MSISDN and Entity found in RTDB with Entity type other than RN. (Non-RN Entity type in general implies own subscriber). <p>Note: The combinations of 1 RN and 1 VMS ID, and 1 RN and 1 GRN, are valid combinations for network entities. In this case, the Entity type is considered to be RN (presumably, our own network is providing voice mail support for a foreign number).</p> <ul style="list-style-type: none"> • MSISDN found in RTDB with no Entity and PT=Migrated (5)

Encoded Number Portability Status value	Criterion
	<ul style="list-style-type: none"> • MSISDN found in RTDB with no Entity but PT=Prepaid (3, 4, 6-35). • MSISDN and Entity found in RTDB with Entity type=RN, PT=0, and S-Port is enabled or IGM feature is turned ON (migrated subscriber is considered own subscriber). • MSISDN and Entity found in RTDB with Entity type=RN, and PT=5 (migrated) or PT=Prepaid (3,4,6-35).
Foreign Number Ported In (5)	Not Supported. (Imported) Numbers that meet criteria for "Own Number Not Ported Out" have portability status value of 4.

ATINP Error Response MSU Encoding

The EAGLE 5 ISS can return any of the following error messages after processing an ATI message:

- Return Error

A response message with a Return Error component is referred to as an ATI NACK message or Return Error message. A Return Error component is used for the receipt of an ATI message when the ATINP feature is turned off (ATINP must be enabled – if ATINP is disabled, the message will not reach the subsystem), for ATI lookup problems, and for some decoding issues.

Refer to 3GPP TS 29.002 version 6.15.0, ETSI TS 129 002 V6.15.0 (2005-12), *Digital Cellular Telecommunications System (Phase2+); Mobile Application Part (MAP) Specification*.

- Reject

Reject messages are used for decoding errors in the Component portion of the original MSU.

- U-Abort

U-Abort messages are used for decode errors in the Dialog or Component portion of the original MSU.

- P-Abort

P-Abort messages are used for certain errors detected during decode of the Transaction portion of the original MSU.

Reject, P-Abort, and U-Abort error codes are described in ITU-T Recommendation Q.773, *Transaction Capabilities Formats and Encoding*.

Hardware Requirements

EPAP-related features that perform an RTDB lookup require Service Module cards (DSM cards, E5-SM4G cards, or E5-SM8G-B cards) running the VSCCP application. The EAGLE 5 ISS can be equipped with up to 32 (31+1) Service Module cards.

Features that do not perform an RTDB lookup require Service Module cards only for GTT processing that might be performed for the feature. These features can coexist in systems with EPAP, but do not require an EPAP connection.

MPS/EPAP Platform

Oracle provides the Multi-Purpose Server (MPS) platform as a subsystem of the Oracle Communications EAGLE. The MPS provides support for EPAP-related features that perform Real Time Database (RTDB) lookups.

The MPS is composed of hardware and software components that interact to create a secure and reliable platform. For details about the MPS hardware, refer to *Application B Card Hardware and Installation Guide*. The MPS provides the means of connecting the customer provisioning application with the EAGLE and accepts the customer number portability data, while accommodating numbers of varying lengths.

The Oracle Communications EAGLE Application Processor Provisioning (EPAP) is software that runs on the MPS hardware platform. EPAP collects and organizes customer provisioning data, and forwards the data to the EAGLE Service Module cards. For detailed information about EPAP, refer to *Administration Guide* for EPAP.

In this manual, Service Module card refers to a DSM card, an E5-SM4G card, or an E5-SM8G-B card unless a specific card is required. For more information about the supported cards, refer to *Hardware Reference*. DSM cards are not supported with Oracle Communications EAGLE Application B Card (E5-APP-B) based EPAP systems.

Chapter 3

EAGLE ATINP Commands

Topics:

- [EAGLE 5 Commands.....39](#)

This chapter contains brief descriptions of the EAGLE commands that are used for the configuration of the ATI Number Portability Query (ATINP) feature.

EAGLE 5 Commands

This chapter describes EAGLE 5 commands that can be used for the configuration of the ATI Number Portability Query (ATINP) feature.

Refer to *Commands Manual* for complete descriptions of the following commands, including parameter names, valid values, and output examples for the commands.

Table 6: Commands used for ATINP

Type	Commands
System Serial Number	ent/rtrv-serial-num
Card	ent/dlt/rtrv/alw/inh/init/rept-stat-card
Feature Control	enable/chg/rtrv-ctrl-feat
STP Options	chg/rtrv-stpopts
EAGLE 5 STP Self Identification	chg/rtrv-sid
Mated Application (MAP)	chg/dlt/ent/rtrv-map
Subsystem Application	chg/dlt/ent/rtrv-ss-appl
Service Selector	chg/dlt/ent/rtrv-srvsel
ATINP Options, and options for Service Portability	chg/rtrv-atinpqopts
Local Subsystem Activation	alw/inh-map-ss

enable-ctrl-feat / chg-ctrl-feat / rtrv-ctrl-feat

These commands are used to enable, turn on, and display the on/off status of the ATINP feature and the Service Portability feature.

chg-stpopts / rtrv-stpopts

The STP Options commands are used to provision system options for the EAGLE 5. The options are used to control system-level processing. Features can check the option values to determine what processing to apply.

The Default Country Code (defcc) and DSM checksum audit (dsmaud) parameters are supported for ATINP.

chg/dlt/rtrv-ss-appl

The Local Subsystem Application commands are used to reserve a subsystem number for a local subsystem application, to delete the local subsystem application, to change the online/offline status of the subsystem application, and to display the local subsystem application status in the database.

The local subsystem application for the ATINP feature is ATINPQ.

ent-srvsel / dlt-srvsel / chg-srvsel / rtrv-srvsel

The service selector commands are used to provision and display service selector information for the atinp service.

chg-atinpqopts / rtrv-atinpqopts

The ATINP Options commands are used to provision the configuration options for the ATINP feature. The options control number portability and Service Portability processing for ATI messages and response message formatting.

The ATINP Options commands define and display ATINP options that are provisioned in the ATINPQOPTS table. The ATINP options are used for the following functions:

- Specify the format of the IMSI, MSISDN, and Routing Number parameters in the ATI ACK response message, and the maximum number of digits to be used from the SRFIMSI or Entity ID in the encoding format
- Determine whether the IMSI, MSISDN, or Routing Number parameter is included or not included in the ATI ACK response message
- Specify the inclusion and formatting of the Location Information field in the ATI ACK response message
- Specify the default routing number and outbound message digits delimiter to be used in outbound message formats
- Specify the number conditioning to be performed on the MSISDN digits in the incoming ATI query message before RTDB lookup is performed, and indicate the determination of a successful RTDB lookup
- Specify Service Portability processing that can be performed for ATI messages

alw/inh / inh-map-ss

The alw/inh-map-ss commands allow and inhibit (or shut down) the operation of a mated application subsystem. The subsystem number for the local subsystem application must be specified in the command.

Allowing causes the subsystem to become operational in the system.

Inhibiting stops the operation of (shuts down) a mated application subsystem. The specified subsystem attempts a coordinated shutdown. If the coordinated shutdown fails, a UIM is issued indicating the shutdown failed. If the force parameter is specified in the command, the subsystem is forced to shut down, and a coordinated shutdown is not performed.

ATINP Configuration

Topics:

- *Introduction.....42*
- *ATINP Configuration Procedure.....44*
- *Enabling ATINP, Setting STP Options, and Turning On ATINP.....45*
- *Enabling the Service Portability Feature.....47*
- *Provisioning True Point Codes and Capability Point Codes.....48*
- *Provisioning the ATINPQ Local Subsystem.....49*
- *Provisioning the ATINP Service Selector.....52*
- *Provisioning the ATINP Options.....57*
- *Activating the ATINPQ Local Subsystem.....58*
- *Turning On the Service Portability Feature.....59*
- *Turning Off the Service Portability Feature.....60*
- *Changing the State of a Subsystem Application.....61*

This chapter provides procedures for configuring the ATINP feature for use in the EAGLE 5 ISS.

Introduction

The ATINP feature is configured on the EAGLE 5 ISS and on the EPAP. This chapter describes prerequisites and procedures for the EAGLE 5 ISS configuration only. The EPAP configuration is covered in the *EPAP Administration Manual*. This chapter also includes procedures for configuration of the Service Portability feature for use with ATINP, and for provisioning options to allow the use of the GRN for ROP information.

[ATINP Configuration Procedure](#) lists the steps for enabling and turning on the ATINP feature and the Service Portability feature, and for the provisioning required for the features. Each step contains a link or reference to information and procedures to use to complete the step. Feature provisioning can be performed after the features are enabled and before the features are turned on.

The ATINP feature and other related features are optional and must be purchased from Tekelec before they can be used in your system. If you are not sure whether you have purchased a specific feature, contact your Tekelec Sales or Account Representative.

Note: For an in-service environment, contact the [My Oracle Support \(MOS\)](#) before continuing to configure the ATINP feature. For an environment that is not yet in-service, continue with the configuration.

EPAP Entity Provisioning

It is recommended that EPAP entity (SP or RN) administration not be done until after the point code and/or subsystem number has been entered into the EAGLE 5 ISS MAP table.

- EPAP-administered entity data can possibly become out-of-sync with the EAGLE 5 ISS MAP table when the creation of point codes and/or subsystem numbers in the MAP table is performed after EPAP database administration.
- If this mismatch is discovered in real-time operations, a UIM (such as SCCP did not route - DPC not in MAP tbl or SCCP did not route - SS not in MAP tbl) is sent to the EAGLE 5 ISS maintenance terminal.

System Prerequisites

Before any feature that is described in this manual can be enabled, the prerequisites listed in [Table 7: System Prerequisites](#) are required in the system.

Table 7: System Prerequisites

Prerequisite	Verification and Provisioning
The system serial number must be correct and locked.	Note: The serial number cannot be changed after it is entered and locked in the system.
For new installations, the system is shipped with an unlocked serial number. The serial number can be changed if necessary and must be locked after the system is on-site.	Locate the serial number for the system on a label affixed to the control shelf (1100). Enter the <code>rtrv-serial-num</code> command to display the serial number and its locked status.

Prerequisite	Verification and Provisioning
For systems that are being upgraded, the serial number is usually already verified and locked.	<p>Verify that the displayed serial number is correct for the system.</p> <p>If no serial number is displayed, enter the <code>ent-serial-num</code> command (without the lock parameter) to provision the serial number that appears on the control shelf label. Enter the <code>rtrv-serial-num</code> command and verify that the serial number was entered correctly.</p> <p>Enter the <code>ent-serial-num</code> command with the <code>lock=yes</code> parameter to lock the serial number in the system.</p>
<p>A sufficient number of Service Module cards must be equipped.</p> <p>Some features require only E5-SM4G cards and cannot use DSM cards. See specific feature prerequisites, if any, in this section.</p> <p>Refer to the <i>Dimensioning Guide for EPAP Advanced DB Features</i> for information on the dimensioning rules and the database capacity requirements for EPAP-related features.</p>	<p>Enter the <code>rept-stat-card:appl=vscpc</code> command to list the Service Module cards in the system.</p> <p>If more cards or cards of a different type are needed, refer to the procedures in the <i>Database Administration Manual - GTT</i> to add Service Module cards or remove DSM cards.</p>
<p>The GTT feature must be on in the system.</p> <p>Some features require an additional GTT-related feature such as EGTT. See the specific feature prerequisites in this section.</p>	<p>Enter the <code>rtrv-feat</code> command to display the GTT feature status.</p> <p>If the GTT feature is on, the <code>gtt=on</code> entry appears in the output.</p> <p>If the <code>gtt=off</code> entry appears in the output, use the procedures in the <i>Database Administration Manual - GTT</i> to turn on and provision the GTT feature and any other GTT-related features and functions that will be used in the system.</p>

ATINP Feature Prerequisites

Before the ATINP feature can be enabled, the following prerequisites are required in the system:

Table 8: ATINP Feature Prerequisite

Prerequisite	Verification and Provisioning
The ANSIGFLEX system option cannot be set to Yes.	<p>Enter the <code>rtrv-stpopts</code> command.</p> <p>Verify that the ANSIGFLEX entry does not appear in the command output or that the ANSIGFLEX entry shows a value of No.</p>
The LNP feature cannot be on in the system.	Enter the <code>rtrv-ctrl-feat</code> command.

Prerequisite	Verification and Provisioning
	If the LNP feature is on, shown with a quantity greater than zero for the LNP ported TNs entry in the command output, the feature described in this manual cannot be enabled.

ATINP Configuration Procedure

The EAGLE 5 ISS configuration of the ATINP feature consists of the following steps. The steps contain links and references to detailed procedures and information needed to complete each step.

1. Verify, and provision if needed, the system prerequisites. See [System Prerequisites](#).
2. Verify, and provision if needed, the feature prerequisites. See [ATINP Feature Prerequisites](#).
3. Enable the ATINP feature, set system STP options, and turn on the ATINP feature. See [Enabling ATINP, Setting STP Options, and Turning On ATINP](#).
4. Enable the Service Portability feature, if it will be used with ATINP. See [Enabling the Service Portability Feature](#).
5. Change the self identification of the EAGLE 5 ISS node to include true point codes and ATINP capability point codes. See [Provisioning True Point Codes and Capability Point Codes](#) and refer to the procedures in the *Database Administration Manual - SS7*.
6. Refer to the procedures in the *Database Administration Manual - Global Title Translation* to provision the following items:
 - Translation types and mappings
 - Mated Application table entries for the ATINP feature that contain the EAGLE 5 ISS true point codes, the ATINP capability point codes, and the ATINPQ subsystem number. Only solitary and dominant loadsharing are supported.

The ATINPQ subsystem can have a mate subsystem and a concerned point code group assigned to it in the MAP table.

If multiple point code types for ATINPQ are provisioned in the MAP table, then the point code type for the Subsystem Out-of-Service Request message (SOR) is determined using the following order:

1. ANSI
2. ITU-N
3. ITU-N Spare
4. ITU-I
5. ITU-I Spare
7. Provision state and subsystem number for the ATINPQ local subsystem application. See [Adding the ATINPQ Local Subsystem Application](#).
8. Provision the service selector mechanism to route MSUs to the ATINPQ subsystem. See [Adding an ATINP Service Selector](#).

The ATINP service is atinp.

The Translation Type and Subsystem Number are the values assigned for the ATINP local subsystem when the MAP table entries were defined. See Step 4 in this procedure.

ATINP supports ANSI, ITU-I, and ITU-N Global Title Indicators; ITU-N24 is not supported.

The Nature of Address Indicator and Numbering Plan are required when the GTI value is 4, and not allowed when the GTI value is 2.

ATINP does not support the Service Nature of Address or the Service Numbering Plan.

9. Provision ATINP options, including options for Service Portability and GRN data processing if required. See [Provisioning the ATINP Options](#).
10. Activate the ATINP local subsystem. See [Activating the ATINPQ Local Subsystem](#).
11. Turn on the Service Portability feature, if it will be used with ATINP. See [Turning On the Service Portability Feature](#).
12. Configure the Measurements Platform feature or the E5-OAM Integrated Measurements feature if measurements are to be collected for ATINPQ.

Refer to the procedures in the *Database Administration Manual - System Management* for configuring the Measurements Platform feature, the E5-OAM Integrated Measurements feature, and the EAGLE OA&M IP Security feature in the EAGLE 5 ISS. (OAM-based measurements reports are not available for ATINPQ).

Enabling ATINP, Setting STP Options, and Turning On ATINP

This procedure is used to enable the ATINP feature, set the system STP options, and turn on the ATINP feature in the EAGLE 5 ISS.

- The ATINP feature must be enabled using the ATINP feature part number 893022101 and a feature access key.

Note: Controlled features must be purchased before you can receive the feature access key to use to enable the feature. If you are not sure if you have purchased a feature and received the feature access key, contact your Sales Representative or Account Representative.

When the ATINP feature is enabled, it is permanently enabled. The ATINP feature cannot be temporarily enabled.

Note: Provisioning of ATINP options and other information can be done after the feature is enabled and before the feature is turned on.

- After the ATINP feature has been enabled, the STP option for the default country code must be changed from NONE to an appropriate value for ATINP.

The `chg-stpopts` and `rtrv-stpopts` commands support the `defcc` and `dsmaud` parameters for the ATINP feature.

In the `rtrv-stpopts` command output, the `defcc` parameter is displayed with value NONE when the ATINP feature is enabled.

- After the ATINP feature has been enabled, the STP options are set, and database provisioning is complete, the ATINP feature status must be set to on (the feature must be “turned on”).

After the ATINP feature is enabled and turned on, the ATINP feature can be turned off again.

When the feature is turned on:

- The `defcc` parameter value cannot be set to NONE.

- The DSM audit running state (dsmaud) parameter of the `chg-stpopts` command can be provisioned for ATINP.
 - The `dsmaud` parameter is displayed with value `off` when the ATINP feature is turned on.
1. Enable the ATINP feature, by entering the `enable-ctrl-feat` command.
`enable-ctrl-feat:partnum=893022101:fak=<feature access key>`

Note: The feature access key (the `fak` parameter) is provided by Tekelec. If you do not have the controlled feature part number or the feature access key for the feature, contact your Tekelec Sales Representative or Account Representative.

When the feature is enabled, the ATINP entry appears in the output of the `rtrv-ctrl-feat` command.

```
rlghncxa03w 08-08-29 16:40:40 EST EAGLE5 39.2.0
The following features have been permanently enabled:
Feature Name          Partnum    Status  Quantity
HC-MIM SLK Capacity   893012707 on       64
ATINP                 893022101 off      ----
;
```

2. Verify that the `defcc STP` option parameter value is not `NONE`. Enter the `rtrv-stpopts` command.
 - If the value is not `NONE`, continue with [Step 3](#).
 - If the `defcc` parameter value is `NONE`, use the `chg-stpopts` command to provision a new value. Then continue with [Step 3](#).

Note: Database provisioning of ATINP options can be done here, before the ATINP feature is turned on in the system.

3. Turn on the ATINP feature. Enter the `chg-ctrl-feat` command.
`chg-ctrl-feat:partnum=893022101:status=on`

When the feature is turned on, the status changes to `on` in the `rtrv-ctrl-feat` command output.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum    Status  Quantity
HC-MIM SLK Capacity   893012707 on       64
ATINP                 893022101 on       ----
;
```

4. Back up the database changes, by entering the following command.
`chg-db:action=backup:dest=fixed`

The following messages appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Enabling the Service Portability Feature

If Service Portability can be applied to the messages processed by a feature described in this manual, use this procedure to enable the Service Portability feature in the EAGLE 5 ISS.

The Service Portability feature must be enabled using the feature part number 893034301 and a feature access key.

Note: Controlled features must be purchased before you can receive the feature access key to use to enable the feature. If you are not sure if you have purchased a feature and received the feature access key, contact your Sales Representative or Account Representative.

When the S-Port feature is enabled, it is permanently enabled. The S-Port feature cannot be temporarily enabled. After the S-Port feature is enabled and turned on, the S-Port feature can be turned off again.

Provisioning of S-Port options can be done after the feature is enabled and before the feature is turned on.

After the S-Port feature has been enabled and database provisioning is complete, the S-Port feature status must be set to on (the feature must be “turned on”) before S-Port processing will occur.

1. Display the status of the features that are controlled with feature access keys. Enter the `rtrv-ctrl-feat` command. The output lists the enabled features in the system and shows the on/off status for each feature.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name           Partnum   Status   Quantity
HC-MIM SLK Capacity    893012707 on        64
;
```

If the Service Portability entry appears in the `rtrv-ctrl-feat` output, performing this procedure is not necessary.

2. Enable the S-Port feature, by entering the `enable-ctrl-feat` command.


```
enable-ctrl-feat:partnum=893034301:fak=<feature access key>
```

When the feature is enabled, the Service Portability entry appears in the output of the `rtrv-ctrl-feat` command.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name           Partnum   Status   Quantity
HC-MIM SLK Capacity    893012707 on        64
Service Portability    893034301 off        ----
;
```

3. Back up the database changes, by entering the following command.


```
chg-db:action=backup:dest=fixed
```

The following messages appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
```

```
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Provisioning True Point Codes and Capability Point Codes

This procedure explains briefly how to provision EAGLE 5 ISS true point codes, and capability point codes for EPAP-based features. Refer to the detailed procedures in the *Database Administration Manual - SS7* for provisioning true and capability point codes, and the CLI if needed.

For the ATINPQ subsystem, the EAGLE 5 ISS supports ANSI, ITU-I, ITU-N, ITU-I Spare, and ITU-N Spare capability point code types. including group codes. ITU-N24 capability point codes are not supported.

This procedure explains how to provision EAGLE 5 ISS true point codes and ATINP capability point codes.

1. Display the true and capability point codes in the system. Enter the `rtrv-sid` command.

```
tekelecstp 08-07-22 15:07:48 EST EAGLE 39.2.0

PCA          PCI          PCN          CLLI          PCTYPE
-----          -          -          tekelecstp    ANSI
;

```

2. Verify that the desired EPAP-based feature is enabled and turned on, by entering the `rtrv-ctrl-feat` command.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum  Status  Quantity
HC-MIM SLK Capacity  893012701 on       64
ATINP                 893022101 on       ----
;

```

- If the feature entry appears in the command output, and the feature status is on, continue with [Step 3](#).
 - If the feature entry does not appear in the command output or if the feature status in the entry is off, go to the procedure in this manual to enable and turn on the EPAP-based feature. Continue with [Step 3](#).
3. Change the true point codes and capability point codes as needed, using the `chg-sid` command. Refer to the procedures in the *Database Administration Manual - SS7* for changing the Self-Identification of the EAGLE 5 ISS. The system might need to be initialized for the point code changes to take effect. This must be done carefully to minimize traffic loss.
 4. Verify the changes with the `rtrv-sid` command.

```
tekelecstp 08-08-22 15:07:48 EST EAGLE 39.2.0

PCA          PCI          PCN          CLLI          PCTYPE
001-001-001  2-002-2     01234       tekelecstp    ANSI

CPCA (ATINP)
```



```

004-004-004

CPCI (ATINP)
5-012-0

CPCN (ATINP)
12345

;
```

5. Back up the changes using the `chg-db:action=backup:dest=fixed` command.

The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```

Provisioning the ATINPQ Local Subsystem

The following procedures in this section are used to add or remove a local subsystem application:

- [Adding the ATINPQ Local Subsystem Application](#)
- [Removing a Local Subsystem Application](#)

See the procedures in [Changing the State of a Subsystem Application](#) to take the subsystem application online or offline.

Note: The EAGLE 5 ISS supports the operation of two or more local subsystems for EPAP-related features in the system at one time. For example, the local subsystems for INP and EIR can coexist in the system.

Adding the ATINPQ Local Subsystem Application

This procedure is used to define the ATINPQ subsystem application. The subsystem application can be taken online when it is defined or later in the configuration process (see [Changing the State of a Subsystem Application](#)).

Before the ATINPQ subsystem application can be added to the database, the following conditions must exist in the system:

Table 9: ATINPQ Local Subsystem Prerequisites

Prerequisite	Verification
The ATINP feature must be enabled and turned on	Enter the <code>rtrv-ctrl-feat</code> command. If the ATINP entry with Status of on does not appear in the output, see the Enabling ATINP ,

Prerequisite	Verification
	Setting STP Options, and Turning On ATINP procedure.
The application specified by the appl parameter (atinpq) cannot already be in the database.	Enter the <code>rtrv-ss-appl</code> command. If the ATINPQ entry appears in the output, this procedure cannot be performed.
EAGLE 5 ISS true point codes and ATINP capability point codes must be defined, and entered in the Mated Application table with a subsystem number to be used for the ATINPQ subsystem application.	Only one subsystem number for the application can be defined, and must be used for all point code types assigned to the local subsystem. Enter the <code>rtrv-sid</code> command, and verify that the true and capability point codes needed for the feature are correct. If changes are required, see Provisioning True Point Codes and Capability Point Codes Enter the <code>rtrv-map</code> command, and verify that the MAP table entries are correct for the ATINPQ local subsystem. If changes are required, refer to the procedures in the <i>Database Administration Manual – Global Title Translation</i> for provisioning solitary and dominant mated applications.

The examples in this procedure reserve the subsystem number 100 for the ATINPQ subsystem application and set the ATINPQ subsystem application status to online.

1. Add the ATINPQ application and subsystem number, using the `ent-ss-appl` command.

If the `stat` parameter is not specified, the status defaults to offline.

```
ent-ss-appl:appl=atinpq:ssn=100:stat=online
```

2. Verify the changes, by entering the `rtrv-ss-appl` command.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT
ATINPQ 100  online

SS-APPL TABLE IS 25% FULL (1 OF 4)
;
```

3. Back up the changes using the `chg-db:action=backup:dest=fixed` command. The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```

Removing a Local Subsystem Application

This procedure is used to remove a subsystem application from the database. The subsystem application to be removed must be in the database and the subsystem must be out of service.

1. Display the subsystem application number for the local subsystem application in the database, by entering the `rtrv-ss-appl` command.
2. Display the operating status of the local subsystem, by entering the `rept-stat-sccp` command. If the subsystem is out of service, shown by an entry containing OOS-MT-DSBLD for the subsystem in the `rept-stat-sccp` output, go to [Step 5](#).
3. Place the local subsystem application out of service. Enter the `inh-map-ss` command and specify the subsystem number displayed in [Step 1](#).

```
inh-map-ss:ssn=11
```

```
rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 39.2.0
Inhibit map subsystem command sent to all SCCP cards.
Command Completed.
```

When this command has successfully completed, the following message appears. If the `force=yes` parameter is not specified, wait for a message that indicates the subsystem is inhibited.

```
rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 39.2.0
Inhibit map subsystem command sent to all SCCP cards.
Command Completed.
```

4. Verify that the local subsystem is out of service (OOS-MT-DSBLD), by entering the `rept-stat-sccp` command. If the local subsystem is not out of service, return to [Step 3](#) and enter the `inh-map-ss` command with the `force=yes` parameter specified.
5. Remove the local subsystem application from the database, by entering the `dlt-ss-appl` command. `dlt-ss-appl:appl=<subsystem>`
6. Verify the changes by entering the `rtrv-ss-appl` command. The deleted entry should not appear in the output.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT

SS-APPL TABLE IS 0% FULL (0 OF 4)
;
```

7. Back up the changes using the `chg-db:action=backup:dest=fixed` command. The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```

Provisioning the ATINP Service Selector

The procedures in this section describe how to add, change, and remove a service selector. The information is indicated that is specific to ATINP.

Refer to the *Commands Manual* for complete descriptions of the commands used in these procedures, including parameter names, valid values, and output examples for the commands.

Adding an ATINP Service Selector

This procedure is used to add a service selector for the ATINP feature.

The ATINP feature must be enabled and turned on before an ATINP service selector can be added.

1. Verify that the ATINP feature is enabled and turned on, by entering the `rtrv-ctrl-feat` command.

If the ATINP feature is enabled and turned on, the status of the ATINP entry is on.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum  Status  Quantity
HC-MIM SLK Capacity   893012707 on      64
ATINP                 893024401 on      ----
;
```

- If the ATINP feature is enabled and turned on, continue with [Step 2](#).
 - If the ATINP feature is not enabled or turned on, go to [Enabling ATINP, Setting STP Options, and Turning On ATINP](#) to enable and turn on the ATINP feature. Then continue with [Step 2](#).
2. Display any existing ATINP service selectors in the database, by entering the `rtrv-srvsel:serv=atinp` command.

```
rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 41.1.0

GTII  TT  NP      NAI  SSN  SNP  SNAI  SERV
4     1    e164   intl 3    ---  ---   atinp
4     2    e164   intl *    ---  ---   atinp

GTIN  TT  NP      NAI  SSN  SNP  SNAI  SERV
4     4    e164   natl 4    ---  ---   atinp

SRV SELECTOR table is (3 of 20992) 1 % full
;
```

3. Add new ATINP service selectors, using the `ent-srvsel` command. For example, enter commands like these:

```
ent-srvsel:serv=atinp:tt=35:ssn=100:gtin=4:np=e214:nai=natl
ent-srvsel:serv=atinp:tt=57:ssn=75:gtin=2
```

- Verify the changes by entering the `rtrv-srvsel` command with the parameters and values used in [Step 3](#).

```

rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 41.1.0

GTII  TT  NP      NAI  SSN  SNP  SNAI  SERV
4      1  e164  intl  3    ---  ---   atinp
4      2  e164  intl  *    ---  ---   atinp

GTIN  TT  NP      NAI  SSN  SNP  SNAI  SERV
4      4  e164  natl  4    ---  ---   atinp
4     35  e214  natl 100  ---  ---   atinp
2     57  ---   ---  75   ---  ---   atinp

SRV SELECTOR table is (5 of 20992) 1 % full
;

```

- Back up the changes using the `chg-db:action=backup:dest=fixed` command. The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.

```

Removing a Service Selector

This procedure is used to remove a service selector from the database.

The GTI, GTII, GTIN, tt, and ssn parameter values can be used to limit the amount of information displayed with the `rtrv-srvsel` command.

- Display the service selectors in the database, by entering the `rtrv-srvsel` command.

```

rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 39.2.0
GTII  TT  NP      NAI  SSN  SNP  SNAI  SERV
4      1  e214  intl  4    e164  intl  gport
4      1  e214  intl  5    e164  intl  smsmr
4      2  e214  intl  5    e164  intl  mnpsms
4      2  e164  intl  ---  ---  ---   vflex

GTIN  TT  NP      NAI  SSN  SNP  SNAI  SERV
4      4  e214  natl  75   e164  intl  gflex
4      9  e214  natl 100   e164  intl  gflex

```

```

  4      35  e214    natl  100  ---  ---  atinp
  2      57  e214    natl   75  ---  ---  vflex

SRV SELECTOR table is (8 of 20992)  1 % full
;

```

- Remove the service selector from the database, using the `dlt-srvsel` command. For example, enter commands like these.

```

dlt-srvsel:serv=atinp:tt=35:ssn=100:gtin=4:np=e214:nai=natl
dlt-srvsel:serv=atinp:tt=57:ssn=75:gtin=2

```

To remove a service selector, the GTI, GTII, GTIN, tt, and ssn parameter values must be entered as shown in the `rtrv-srvsel` command output.

- Verify the changes by entering the `rtrv-srvsel` command with the parameters and values used in [Step 2](#).

```

rtrv-srvsel:serv=atinp:tt=35:ssn=100:gtin=4:np=e214:nai=natl

```

```

rlghncxa03w 08-06-28 14:42:38 GMT  EAGLE 39.2.0

GTIN  TT  NP      NAI  SSN  SNP  SNAI  SERV
No SRV Selector found in range
;

```

```

rtrv-srvsel:serv=atinp:tt=57:ssn=75:gtin=2

```

```

tekelecstp 08-08-28 16:35:22 EST  EAGLE 39.2.0
GTII  TT  NP      NAI  NPV  NAIV  SSN  SNP  SNAI  SERV
No SRV Selector found in range
;

```

- Back up the changes using the `chg-db:action=backup:dest=fixed` command. The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.

```

Changing an Existing Service Selector to an ATINP Service Selector

This procedure is used to change an existing non-ATINP service selector to a ATINP service selector.

The only parameters that can be changed using this procedure are:

:nserv

New DSM service type, ATINP

:nsnp

An ATINP service selector cannot contain an SNP value; if the service selector being changed contains an SNP value, this value must be changed to **none** with this parameter.

:nsnai

An ATINP service selector cannot contain an SNAI value; if the service selector being changed contains an SNAI value, this value must be changed to **none** with this parameter.

The `chg-srvsel` command requires that the following parameters be specified with the values shown in the `rtrv-srvsel` output for the service selector that is being changed. If any of these parameter values need to be changed for a ATINP service selector, use the procedure in [Removing a Service Selector](#) to remove the existing service selector. Then use the procedure in [Adding an ATINP Service Selector](#) to add the new ATINP service selector with the new parameter information.

:gtii/gtin/gtin24

Global title indicator for ITU international (gtii), ITU national using 14-bit point codes (gtin), and ITU national using 24-bit point codes (gtin24).

:tt

Translation type

:ssn

Subsystem number

:nai

Nature of address indicator

:naiv

Nature of address indicator value

:np

Numbering plan

:npv

Numbering plan value

1. Display the service selectors in the database, using the `rtrv-srvsel` command.

```
rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 39.2.0

GTII  TT  NP      NAI  SSN  SNP  SNAI  SERV
4      1    e214   intl  4    e164  intl  gport
4      1    e214   intl  5    e164  intl  smsmr
4      2    e214   intl  5    e164  intl  mnpsms
4      2    e164   intl  *    ---   ---   vflex
```

```

GTIN  TT  NP      NAI  SSN  SNP  SNAI  SERV
4     4    e214   natl  34   e164  intl  gflex
4     9    e214   natl  ---  e164  intl  gflex

SRV SELECTOR table is (6 of 20992)  1 % full

;

```

2. Verify that the ATINP feature is enabled and turned on, by entering the `rtrv-ctrl-feat` command. If the ATINP feature is enabled and turned on, the status of the ATINP entry is on.

```

rlghncxa03w 09-06-29 16:40:40 EST  EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum  Status  Quantity
HC-MIM SLK Capacity   893012707  on      64
ATINP                 893024401  on      ----

;

```

- If the ATINP feature is enabled and turned on, continue with [Step 3](#).
 - If the ATINP feature is not enabled or turned on, go to [Enabling ATINP, Setting STP Options, and Turning On ATINP](#) to enable and turn on the ATINP feature. Then continue with [Step 3](#).
3. Change the service selector, using a `chg-srvsel` command similar to the following example.
`chg-srvsel:gtin=4:tt=4:np=e214:nai=natl:ssn=34:nsnp=none:nsnai=none:nserv=atinp`

Note: If the SNP or SNAI parameter values are shown as dashes in the `rtrv-srvsel` output, these parameters cannot be specified with the `chg-srvsel` command. If the `gtii/gtin/gtin24` parameter value is 2, the `np`, `nai`, `npv`, and `naiv` parameters cannot be specified with the `chg-srvsel` command.

If the `gtii/gtin/gtin24` parameter value is 4, either the `np` and `nai`, or the `npv` and `naiv` parameters must be specified with the `chg-srvsel` command. The `np` and `nai` parameters can be specified in place of the `npv` and `naiv` parameters, and the `npv` and `naiv` parameters can be specified in place of the `np` and `naiv` parameters as long as parameter values be specified correspond to the values shown in the `rtrv-srvsel` output. Refer to the `chg-srvsel` command description in the *Commands Manual*.

4. Verify the changes by entering the `rtrv-srvsel` command with the `serv=atinp` parameter and the values for the other parameter that were used in [Step 3](#).

```
rtrv-srvsel:gtin=4:tt=4:np=e214:nai=natl:ssn=34:serv=atinp
```

```

rlghncxa03w 08-06-28 14:42:38 GMT  EAGLE 39.2.0

GTIN  TT  NP      NAI  SSN  SNP  SNAI  SERV
4     4    e214   natl  34   ---  ---  atinp

```



```
SRV SELECTOR table is (6 of 20992) 1 % full
;
```

5. Back up the changes using the `chg-db:action=backup:dest=fixed` command.

The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```

Provisioning the ATINP Options

Refer to [ATINP Configuration Options](#) in this manual and to the `chg-atinpqopts` command description in the *Commands Manual* for valid parameter values, input examples, and rules for entering the command correctly.

1. Verify that the ATINP feature is enabled, by entering the `rtrv-ctrl-feat` command.

If the ATINP feature has not been turned on, the status in the ATINP entry is off.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum  Status  Quantity
HC-MIM SLK Capacity   893012707 on      64
ATINP                  893022101 off     ----
;
```

- If the ATINP feature is not enabled (the ATINP entry does not appear in the output), go to [Enabling ATINP, Setting STP Options, and Turning On ATINP](#) to enable the ATINP feature. Then continue with [Step 3](#).
 - If the ATINP feature is enabled, continue with [Step 3](#).
2. If the Service Portability feature will be used with ATINP, verify that the Service Portability entry appears in the output in [Step 1](#).
 - If the Service Portability entry appears in the output, continue with [Step 3](#).
 - If the Service Portability entry does not appear in the output, go to [Enabling the Service Portability Feature](#) to enable the feature. Then continue with [Step 3](#).
 3. Display the current settings of the ATINP options, using the `rtrv-atinpqopts` command.
 4. Change the ATINP options to the required settings, by entering the `chg-atinpqopts` command with at least one of the ATINP option parameters specified. If Service Portability will be used with ATINP, change the ATINP options that apply to Service Portability to the required settings.

Refer to [ATINP Configuration Options](#) in this manual and to the `chg-atinpopts` command description in the *Commands Manual* for valid parameter values, input examples, and rules for entering the command correctly.

```
chg-atinpopts:atinptype=<type>:snai=<snai>:atidlm=<delimiter>
```

5. Verify the changes, by entering the `rtrv-atinpopts` command.
6. If the ATINP feature was not turned on (status is off in the output in [Step 1](#)), go to [Enabling ATINP, Setting STP Options, and Turning On ATINP](#) to turn on the feature.
7. Back up the changes, using the `chg-db:action=backup:dest=fixed` command.

These messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Activating the ATINPQ Local Subsystem

The procedure in this section explains how to activate the ATINPQ local subsystem.

When all feature configuration is complete, the ATINPQ subsystem application must be taken online and the local subsystem must be activated to allow it to begin operation.

When the local subsystem operating state is Inhibited, the `chg-ss-appl` command can be used to change the online or offline database state of the subsystem. The `rtrv-ss-appl` command displays the online or offline provisioned value.

When the first Service Module card is loaded, this state tells whether the subsystem should be considered allowed (online) or inhibited (offline). This is a database state. If the command is accepted, then the change is made to the tables and can be read after an `init-sys` command is entered to initialize the system.

When the Service Module cards are in-service and the subsystem application is online, the `alw/inh-map-ss` commands can be used to change the dynamic operating state of the local subsystem to allowed or inhibited. The `inh-map-ss` command does not necessarily force a state change, because it can fail if the mate does not send an SOG. The `force=yes` parameter must be specified to bypass the SOR/SOG exchange and inhibit immediately. (There is no `rtrv-map-ss` command.)

The procedures in [Changing the State of a Subsystem Application](#) explain how to take a local subsystem online and offline.

Table 10: Subsystem Allow/Inhibit

Command \ Subsystem State	Offline	Online
<code>alw-map-ss</code>	Command is rejected because the subsystem must be online to be in the Allowed state.	Attempts to make the local subsystem active.

Command \ Subsystem State	Offline	Online
inh-map-ss	Command accepted, but no action because offline implies inhibited.	Attempts to inhibit the local subsystem. Use of the force=yes parameter bypasses the SOR/SOG exchange and inhibits immediately.
chg-ss-appl:appl=atinpq:nstat=online	Changes local subsystem status to online.	No change to local subsystem status in the database.
chg-ss-appl:appl=atinpq:nstat=offline	Command is rejected because the subsystem must be inhibited to go offline.	Changes local subsystem database status to offline.

1. Display the online/offline status of the ATINPQ subsystem application, by entering the `rtrv-ss-appl` command.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT
ATINPQ 11  offline

SS-APPL TABLE IS 25% FULL (1 OF 4)
;
```

2. Change the ATINPQ subsystem status to online.
`chg-ss-appl:appl=atinpq:nstat=online`
3. Enter the command to allow the ATINPQ subsystem to begin operation.
`alw-map-ss:ssn=<ATINPQ ssn>`

```
integrat40 08-05-24 10:37:22 EST EAGLE5 39.2.0
Allow map subsystem command sent to all SCCP cards.
Command Completed.
;
```

4. Display the operating status of the ATINPQ subsystem, by entering the `rept-stat-sccp` command.

Turning On the Service Portability Feature

This procedure is used to turn on the Service Portability feature in the EAGLE 5 ISS, using the feature part number 893034301.

Before the Service Portability (S-Port) feature can be turned on, the feature must be enabled in the EAGLE 5 ISS.

Provisioning of S-Port options can be done after the feature is enabled and before the feature is turned on.

After the S-Port feature has been enabled and database provisioning is complete, the Service Portability feature status must be set to on (the feature must be "turned on"). MSUs will not be processed by the Service Portability feature until the feature is turned on.

After the Service Portability feature is enabled and turned on, it can be turned off again. Service Portability processing can occur only when the Service Portability feature is on and a feature that uses S-Port is on.

1. Display the status of the features that are controlled with feature access keys. Enter the `rtrv-ctrl-feat` command. The output lists the enabled features in the system and shows the on/off status for each feature.
 - If the entry for the Service Portability feature appears in the `rtrv-ctrl-feat` output with status on, performing this procedure is not necessary.
 - If the status of the Service Portability feature in the output is off, continue with [Step 2](#).

2. Turn on the S-Port feature, by entering the `chg-ctrl-feat` command.

```
chg-ctrl-feat:partnum=893034301:status=on
```

When the feature is turned on, the feature status changes to on in the `rtrv-ctrl-feat` command output.

```
rlghncxa03w 09-08-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum  Status  Quantity
HC-MIM SLK Capacity  893012707 on       64
ATINP                 893022101 on       ----
Service Portability  893034301 on       ----
;
```

3. Back up the database changes, by entering the following command.

```
chg-db:action=backup:dest=fixed
```

The following messages appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.
```

Turning Off the Service Portability Feature

Before the Service Portability (S-Port) feature can be turned on and off, the feature must be enabled in the EAGLE 5 ISS.

This procedure is used to turn off the Service Portability feature, using its feature part number 8930343001.

Note: MSUs will not be processed by a feature when the feature is turned off in the system.

1. Display the status of the features that are controlled with feature access keys. Enter the `rtrv-ctrl-feat` command. The output lists the enabled features in the system and shows the on/off status for each feature.

```
rlghncxa03w 09-06-29 16:40:40 EST EAGLE5 41.1.0
The following features have been permanently enabled:
```

```

Feature Name          Partnum   Status   Quantity
HC-MIM SLK Capacity  893012707 on        64
TIF Number Portability 893018901 on        ----
Service Portability   893034301 on        ----
;

```

If the entry for the Service Portability feature appears in the `rtrv-ctrl-feat` output with status off, performing this procedure is not necessary.

If the status of the Service Portability feature in the output is on, continue with [Step 2](#).

- Turn off the S-Port feature, by entering the `chg-ctrl-feat` command.

```
chg-ctrl-feat:partnum=<893034301>:status=off
```

When the feature is turned off, the feature status changes to off in the `rtrv-ctrl-feat` command output.

```

rlghncxa03w 09-05-29 16:40:40 EST  EAGLE5 41.1.0
The following features have been permanently enabled:
Feature Name          Partnum   Status   Quantity
HC-MIM SLK Capacity  893012707 on        64
TIF Number Portability 893018901 on        ----
Service Portability   893034301 off       ----
;

```

- Back up the database changes, by entering the following command.

```
chg-db:action=backup:dest=fixed
```

The following messages appear; the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```

BACKUP (FIXED) : MASP A - Backup starts on active MASP.
BACKUP (FIXED) : MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED) : MASP A - Backup starts on standby MASP.
BACKUP (FIXED) : MASP A - Backup on standby MASP to fixed disk complete.

```

Changing the State of a Subsystem Application

The procedures in this section are used to set the state of an existing subsystem application to either online or offline.

The online or offline status of the subsystem application is shown in the STAT field of the `rtrv-ss-appl` command output.

The `rept-stat-sccp` command displays the operating state (in or out of service) of the subsystem.

If the subsystem application is to be taken online, the subsystem application must be offline.

When the subsystem is taken online (regardless of how the subsystem was taken offline), the EAGLE 5 ISS sends SNR/SSA. A UAM is generated, indicating that the subsystem is ALLOWED.

If the subsystem application is to be taken offline, the subsystem application must be online. The subsystem must be taken out of service (OOS-MT-DSBLD) with the `inh-map-ss` command before it can be taken offline.

A subsystem application can be taken offline using coordinated state change, or forced offline without using coordinated state change.

When the `inh-map-ss` command is entered for the subsystem, a coordinated shutdown is attempted. If the coordinated shutdown fails, a UIM is generated, indicating that the shutdown failed. If the force parameter is specified, the subsystem is forced to shut down; a coordinated shutdown is not performed.

For coordinated state change, SCMG sends an SOR message to the mated subsystem and will start a T_{coord} timer (30 seconds). If SCMG receives an SOG message from the mated subsystem before the T_{coord} timer expires, SCMG will broadcast SSPs to the concerned point code group, send SBR/SSP, and take the subsystem offline. A UAM is generated, indicating that the subsystem is PROHIBITED. If the SOG is not received before T_{coord} expires, then the inhibit request is denied and a UIM is generated.

When the subsystem is taken offline without coordinated state change, the EAGLE 5 ISS sends SBR/SSPs. A UAM is generated, indicating that the subsystem is PROHIBITED.

When the EAGLE 5 ISS receives an SOR message from its mated subsystem, it will reply with an SOG message if both of the following conditions are met:

- The local subsystem is available
- The total load on the DSM subsystem is less than 45% of its capacity

If either of these conditions is not met, the EAGLE 5 ISS will not reply to the SOR message.

Taking the Subsystem Application Offline

Use the procedure in this section to take a subsystem application offline.

1. Verify the state of the subsystem application - online or offline, by entering the `rtrv-ss-appl` command.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT
ATINPQ 11  online

SS-APPL TABLE IS 25% FULL (1 OF 4)
;
```

If the ATINPQ subsystem application is offline, this procedure does not need to be performed.

2. Display the operating status of the subsystem by entering the `rept-stat-sccp` command.
3. Place the subsystem out of service. Specify the subsystem number displayed in the output in [Step 1](#).

```
inh-map-ss:ssn=100
```

```
rlghncxa03w 08-06-28 14:42:38 GMT EAGLE 39.2.0
Inhibit map subsystem command sent to all SCCP cards.
Command Completed.
;
```

4. Verify that the subsystem is out of service, by entering the `rept-stat-sccp` command.
5. Take the subsystem offline. Enter the `chg-ss-appl` command with the `nstat=offline` parameter.

```
chg-ss-appl:appl=atinpq:nstat=offline
```

6. Verify the changes by entering the `rtrv-ss-appl` command.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT
ATINPQ 11  offline

SS-APPL TABLE IS 25% FULL (1 OF 4)
;
```

7. Back up the new changes using the `chg-db:action=backup:dest=fixed` command. The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
BACKUP (FIXED): MASP A - Backup starts on standby MASP.
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```

Taking the Subsystem Application Online

Use the procedure in this section to take the subsystem application online.

1. Verify the state of the subsystem application - online or offline, by entering the `rtrv-ss-appl` command.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT
ATINPQ 11  offline

SS-APPL TABLE IS 25% FULL (1 OF 4)
;
```

If the ATINPQ subsystem is online, this procedure does not need to be performed.

2. Display the operating status of the subsystem by entering the `rept-stat-sccp` command.
3. Take the subsystem application online. Enter the `chg-ss-appl` command with the `nstat=online` parameter.
`chg-ss-appl:appl=atinpq:nstat=online`
4. Verify the changes by entering the `rtrv-ss-appl` command.

```
tekelecstp 08-07-25 08:02:22 EST EAGLE 39.2.0
APPL  SSN  STAT
ATINPQ 11  online

SS-APPL TABLE IS 25% FULL (1 OF 4)
;
```

5. Back up the new changes using the `chg-db:action=backup:dest=fixed` command. The following messages appear, the active Maintenance and Administration Subsystem Processor (MASP) appears first.

```
BACKUP (FIXED): MASP A - Backup starts on active MASP.
BACKUP (FIXED): MASP A - Backup on active MASP to fixed disk complete.
```

```
BACKUP (FIXED): MASP A - Backup starts on standby MASP.  
BACKUP (FIXED): MASP A - Backup on standby MASP to fixed disk complete.
```


Chapter 5

ATINP Measurements

Topics:

- [ATINP Measurements.....66](#)

This chapter describes the measurements that can be collected and generated for the ATINP feature.

ATINP Measurements

The EAGLE 5 ISS Measurements subsystem supports the collection and retrieval of measurements related to the ATINP feature and the ATINPQ local subsystem. The ATINP measurements can be collected with either of the following collection methods:

- The Measurements Platform feature enabled and the Measurements Platform collection option on
- The E5-OAM Integrated Measurements feature enabled and on and the E5-OAM Integrated Measurements collection option on

OAM-based (UI) measurements are not available for ATINP.

Refer to the *Measurements* manual for descriptions of collection methods, measurements, and measurements reports.

Refer to the *Commands Manual* for descriptions of the commands used to enable and turn on features, turn on measurements collection options, and schedule and generate measurements reports.

Refer to the procedures in the *Database Administration Manual - System Management* for configuring the Measurements Platform feature or the EAGLE 5 Integrated Measurements feature and the EAGLE OA&M IP Security feature in the EAGLE 5 ISS.

The Per System totals and Per SSP totals shown in [Table 11: Pegs for Per System and Per SSP](#) are collected for ATINP. The totals are reported in the Hourly Maintenance Measurements (MTCHATINP) report and Daily Maintenance Measurements (MTCDATINP) report.

Note: If an MSU is received with CdPA Rt-on-GT, EAGLE 5 ISS replaces the OPC with its PC as a part of the GTT process. If the CgPA is Rt-on-GT and no CgPA PC is present, it is not possible to determine the originating SSP until GTT has been performed on the CgPA during the encode function. If a decode problem with the query is encountered, then processing will be aborted and Per-SSP measurements will not be updated. GTT of the CgPA will not be attempted on a suspect message. Normal UIM generation will occur (see [ATINPQ Subsystem UIMs](#)).

Table 11: Pegs for Per System and Per SSP

Peg	Description
ATINPQRCV	Total number of queries received for the ATINPQ service, when the incoming message opcode is ATI. Note: MSUs resulting in U-Abort and P-Abort messages typically are not successfully decoded to identify them as ATI messages. ATINPQRCV will not be incremented for these MSUs.
ATIPNQACK	Total number of ATI ACK messages sent by the ATINPQ service
ATIPNQERR	Total number of incoming ATI messages that did not result in either ATI ACK or ATI NACK with Error Code of either Unknown Subscriber or ATI Not Allowed. (The ATI NACK is considered to

Peg	Description
	be a TC_END TCAP message with a Return Error component.) Note: MSUs resulting in U-Abort and P-Abort messages typically are not successfully decoded to identify them as ATI messages. ATINPQERR will not be incremented for these MSUs.

Chapter 6

Maintenance

Topics:

- *ATINPQ Subsystem Alarms (UAMs).....69*
- *ATINPQ Subsystem UIMs.....69*
- *Maintenance Commands.....71*
- *EAGLE 5 ISS Debug Commands.....72*
- *Status Reporting and Problem Identification.....73*

This chapter describes commands and reports that can be used for ATINP maintenance, including status reporting and problem identification.

ATINPQ Subsystem Alarms (UAMs)

This section contains a list of EAGLE 5 ISS UAMs that support the ATINPQ local subsystem. All ATINPQ-related UAMs are generated to the APSS Output Group.

Refer to the *Unsolicited Alarm and Information Messages* manual for descriptions and corrective procedures for EAGLE 5 ISS-related alarms.

Refer to the *T1200 Integrated Application Platform Maintenance Manual* or *EPAP Alarms on T1200 Platform Manual* for descriptions and corrective procedures for MPS-related alarms.

Table 12: ATINPQ UAMs

UAM	Severity	Message Text	Alarm Condition
0565	Critical	ATINPQ Subsystem is not available	No SCCP cards have an ATINPQ status of Active (all are OOS or loading)
0566	Critical	ATINPQ Subsystem is disabled	All IS-NR SCCP cards have ATINPQ status of offline (with at least 1 card IS-NR). An inh-map-ss command has been executed.
0567	Minor	ATINPQ Subsystem normal, cards(s) abnormal	1 SCCP card has ATINPQ status of Active and there are 1 or more cards with ATINPQ status other than Active (offline or loading)
0568	None	ATINPQ Subsystem is available	All SCCP cards are IS-NR and have an ATINPQ status of Active
0569	None	ATINPQ Subsystem is removed	Last SCCP card deleted

ATINPQ Subsystem UIMs

This section contains a list of EAGLE 5 UIMs that support the ATINPQ local subsystem.

Refer to *Unsolicited Alarm and Information Messages* for a complete description of all UIM text and formats.

Note: If both a decode and an encode error occur during ATINP processing, precedence is given to the decode error and only one UIM will be generated.

Table 13: ATINPQ UIMs

UIM	Text	Description	Action
1395	Inh ATINPQ SS request alrdy outstanding	A second attempt to inhibit the ATINPQ subsystem has been made while the first is still being processed.	None - the second attempt will be ignored
1396	Failure Inhibiting ATINPQ SS	The attempted inhibit of the ATINPQ subsystem failed. A response SOG was not received from the mate.	No action necessary.
1397	LSS: Missing Mandatory Parameter	A required parameter was missing in the ATINP query.	Verify that the incoming ATINP query has Subscriber Identity and Requested Info parameters.
1398	ATINPQ: Badly formatted Subs Id	The Subscriber Identity parameter in the ATINP query was found to be mistyped.	Verify that the Subscriber Identity parameter length is at least 2 bytes (1 byte length field of MSISDN). If greater than 2 bytes, the Subscriber Identity length must be equal to 2 + the length of the MSISDN.
1399	ATINPQ: Subscriber Identity not MSISDN	The Choice for Subscriber Identity in the ATINP query is not the MSISDN.	
1400	LSS: Invalid MSISDN digits length	The MSISDN length in Subscriber Information was 0, or the MSISDN had only one 0xF (filler) digit.	
1402	ATINPQ: Invalid Requested Info	The Requested Info parameter in the incoming ATINP query was invalid. Either the length of the Requested Info parameter does not contain MNP Requested Info or Location Information, or the parameter is badly formatted.	
1403	LSS: Dgts truncated in encd parms	One or more encoded digits parameter in the ATINP ACK response had to be truncated to fit maximum allowed encoded digits.	Verify the expected number of digits in routeingNumber and MSISDN fields. These depend on the combination of requested formatting for routeingNumber, MSISDN, and vlr-number fields (ATINPQOPTS: ATIACKRN, ATIACKMSISDN, ATIACKVLRNUM options), digits in incoming ATINP query, and the result of RTDB lookup.

UIM	Text	Description	Action
1426	S-Port: Missing GRN for srvc prtd subs	Service Portability required use of RTDB GRN for encoding response; however GRN was not provisioned.	Verify EPAP provisioning for the subscriber.

Maintenance Commands

The following commands can be used for maintenance when an EPAP-related feature is on.

Refer to *Commands Manual* for complete descriptions of the commands, including parameters, valid parameter values, rules for using the commands, and output examples.

Table 14: Maintenance Commands

Command	Description
rept-stat-sys	Reports the status of system entities, including cards. The output includes the number of Service Module cards that are in service (IS-NR) and how many are in another state (IS-ANR, OOS-MT, OOS-MT-DSBLD).
rept-stat-sccp	Reports operating status of services and subsystems, CPU usage, and Service Module card status. When the loc parameter is specified, the command displays detailed card traffic statistics, including cards that are denied SCCP service. See the section in this manual that describes the use of the <code>rept-stat-sccp</code> command.
rept-stat-mps	Displays the overall status of the EPAP application running on the MPS (multi-purpose server). Command output for the various reports of this command include overall MPS alarm status and card status, and status for a specific Service Module card when a feature is on.
rept-stat-trbl	Includes a summary of any trouble notifications (UAMs) for local subsystems, cards, and linksets. The severity of each alarm is indicated in the output report.
rept-stat-alm	Displays the alarm counts and totals for local subsystems and Service Module card/EPAP IP links.
rept-stat-db	Displays the status information for the EAGLE 5 ISS databases. This includes the level information for each Service Module card, and for the active and standby EPAP RTDB. The command reports database exception status such as corrupted, incoherent, or inconsistent, as well as providing the birth dates and levels. It shows the status of each PDB and RTDB when an EPAP-related feature is enabled.
rtrv-tbl capacity	Retrieves table use capacity summary information. For each table listed, the number of table entry elements in use and the total allowed number of table elements is presented, along with a percent (%) full value. Information is shown for some tables only if the feature that uses the table is enabled.

Command	Description
inh-card/alw-card	<p>The <code>inh-card</code> command is used to change the operating state of the card from In-Service Normal (IS-NR) to Out-of-Service Maintenance-Disabled (OOS-MT-DSBLD). A craftsperson then can test the card or physically remove it from the shelf.</p> <p>The <code>alw-card</code> command is used to change the card from OOS-MT-DSBLD (Out-of-Service Maintenance-Disabled) to IS-NR (In-Service Normal) if card loading is successful.</p>
inh-alm/unhb-alm	Used to allow and inhibit reporting of alarms for a given device, including the Service Module card ports. The commands allow both Port A and Port B to be specified. Inhibited alarms will not generate UAMs or cause alarm indicators to be turned on. All <code>rept-stat-xxx</code> commands continue to display the alarms with an indication that the device has its alarms inhibited.
rtrv-data-rtdb	<p>Retrieves Entity data, DN data, IMEI data, IMSI data, TN data, NPANXX data, and LRN data from the RTDB on an active Service Module card.</p> <p>If the <code>loc</code> parameter is specified and the target card is an active Service Module card, the RTDB data is retrieved from that card.</p> <p>If the <code>loc</code> parameter is not specified, the RTDB data is retrieved on the active Service Module card that has the lowest IMT address.</p> <p>The RTDB status on the active Service Module card can be coherent or incoherent.</p>

rept-stat-sccp

This command reports local subsystem operating status, CPU usage related to the subsystem, and Service Module card status. When the `loc` parameter is specified, the command displays detailed card traffic statistics.

EAGLE 5 ISS Debug Commands

The *Commands Manual* contains descriptions of debug commands that can be used in assessing and modifying system status and operation. Most of the debug commands are used only under the direction of Tekelec support personnel.

The `ent-trace` command can be used to trace MSUs sent to Service Module cards that are running the VSCCP application. The EAGLE 5 ISS traps MSUs that meet the specified tracing criteria, which are the DN and ENTITYID parameters when the ATINP feature is enabled.

Status Reporting and Problem Identification

EAGLE 5 commands can be used to obtain status and statistics for the EAGLE 5 system, the EPAP systems, system devices including Service Module cards, EPAP-related features, local subsystems, and SCCP services.

Refer to *Commands Manual* for complete descriptions of the commands, including parameters and valid values, rules for using the commands correctly, and output examples.

Refer to *Unsolicited Alarm and Information Messages* for descriptions and recovery procedures for UAMs and UIMs.

Refer to *EPAP Administration Manual* for descriptions of EPAP functions and operation.

Refer to *EPAP Alarms on the T1200 Platform* or *EPAP Alarms and Maintenance on the E5-APP-B Platform* for descriptions and recovery procedures for EPAP alarms.

Refer to the appropriate Feature Manual for information about the functions and operation of EPAP-related features.

Table 15: Status Reporting for EPAP-Related Features

Reports, Status, and Statistics	Command
EAGLE 5 ISS	
Maintenance Status Report - indicates whether Maintenance, Routing, and SCCP Baselines have been established.	rept-stat-sys
Alarms and operating state for system devices, including Service Module ("SCCP") cards.	rept-stat-sys
Unsolicited Alarm Messages (UAMs) and Unsolicited Information Messages (UIMs)	rept-stat-alm rept-stat-trbl
EPAP/MPS (from the EAGLE 5 ISS)	
EPAP code version and operating state for each EPAP.	rept-stat-mps
MPS hexadecimal alarm strings for the active and standby EPAPs.	rept-stat-mps
Operating state and alarm status of equipped Service Module cards and their DSM ports and IP connections.	rept-stat-mps rept-stat-mps:loc=<Service Module card location>
Amount of memory used by the RTDB on the specified card, as a percent of available Service Module card memory.	rept-stat-mps:loc=<Service Module card location>

Reports, Status, and Statistics	Command
EPAP Provisioning Database (PDB), EPAP Real Time Database (RTDB), and Service Module card RTDB status information - Coherent, birthdate (date and time of creation), and exception (condition when a problem was detected).	rept-stat-db rept-stat-db:db=mps
Service Module Cards, EPAP-Related Features, Services, Local Subsystems	
Status of the Service Module cards, and the services executing on the cards for EPAP-related features that are turned on. Includes Service Report, Subsystem Report, and Alarm Status; Total Service Statistics.	rept-stat-sccp
Operating state and alarm status of equipped Service Module cards and their DSM ports and IP connections; EPAP-related feature status per card.	rept-stat-mps:loc=<Service Module card location>
Alarms and operating state for Service Module ("SCCP") cards.	rept-stat-sys rept-stat-mps
Any cards that are denied SCCP service.	rept-stat-sccp
Detailed view of the status of SCCP services provided by the specified Service Module card. Includes Card Alarm Status, Card Service Statistics	rept-stat-sccp:loc=<Service Module card location>
General SCCP traffic performance for Service Module cards. Message rates for TVG performance.	rept-stat-sccp:mode=perf
Statistics for EPAP-related feature local subsystems - Subsystem Report	rept-stat-sccp
Statistics for EPAP-related features	rept-stat-sccp

EPAP Status and Alarm Reporting

Because EPAP has no direct means of accepting user input or displaying output messages on EAGLE 5 ISS terminals, EPAP maintenance, measurements, and status information are routed through a Service Module card. EPAP sends two types of messages to the Service Module card: *EPAP Maintenance Blocks* and *DSM Status Requests and DSM Status Messages*. Each message type is discussed in the following sections.

EPAP Maintenance Blocks

The EPAP forwards all status and error messages to the Service Module cards in maintenance blocks. Maintenance blocks are asynchronously sent whenever the EPAP has something to report. The status

information that is displayed when a `rept-stat-mps` command is issued includes information that came from the maintenance blocks.

The active EPAP generates and sends maintenance blocks to the primary Service Module card. One maintenance block is sent as soon as the IP link is established between the active EPAP and the primary Service Module card. Additional maintenance blocks are sent whenever the EPAP needs to report any change in status or error conditions. The information returned in maintenance blocks is included in the output of the `rept-stat-mps` and `rept-stat-sccp` commands.

The EPAP sends maintenance blocks that contain at least the following information:

- Status of EPAP 'A' - actual states are active, standby, and down (inoperative). Maintenance blocks include a field for this information so that it can be available for the output of the `rept-stat-mps` command.
- Status of EPAP 'B' - actual states are active, standby, and down (inoperative). Maintenance blocks include a field for this information so that it can be available for the output of the `rept-stat-mps` command.
- Identification of Active EPAP - a field to identify the active EPAP.
- Congestion Indicator - an indicator showing provisioning link congestion. The link between the EPAPs and the external source of provisioning data can become congested in high-provisioning traffic situations. When this occurs and subsequently as the congestion clears, the EPAP sends maintenance blocks to the Service Module card.
- Alarm Conditions - an error code field. If the EPAP needs to report an alarm condition, it puts an appropriate UAM identifier in this field.
- Current MPS Database Size - a field indicating the current RTDB size. The Service Module card uses this information to calculate the percentage of memory used by the RTDB.

DSM Status Requests and DSM Status Messages

When the EPAP needs to know the status of a Service Module card, it sends a DSM Status Request to all Service Module cards, and each Service Module card returns its status to the EPAP.

Service Module cards send a DSM Status Message to the EPAP when any the following events occur in the Service Module card:

- The Service Module card is booted.
- The Service Module card receives a DSM Status Request message from the EPAP
- The Service Module card determines that it needs to download the entire RTDB; for example, the Service Module card determines that the RTDB needs to be downloaded because it is totally corrupted, or a craftsperson requests that the RTDB be reloaded. The Service Module card sends a Full Download Request message to the EPAP
- The Service Module card starts receiving RTDB downloads or updates. When a Service Module card starts downloading the RTDB or accepting updates, it sends a DSM Status Message informing the EPAP of the first record received. This helps the EPAP keep track of downloads in progress.

The DSM Status Message provides the following information to the EPAP:

- **DSM Memory Size.** When the Service Module card is initialized, it determines the amount of memory present. The EPAP uses the value to determine if the Service Module card has enough memory to hold the RTDB.

Refer to the *Dimensioning Guide for EPAP Advanced DB Features* for important information on the dimensioning rules and the Service Module card database capacity requirements.

- **Load Mode Status.** This indicator indicates whether or not a sufficient number of the IS-NR (In-Service Normal) LIMs have access to SCCP services.

A

ACK	Data Acknowledgement
ASD	Additional Subscriber Data Additional data that is associated with a subscriber (DN) or a range of subscribers.
ATI	Any Time Interrogation An ATI message allows an external server to interrogate an HLR and obtain information about the location and/or state of a GSM subscriber. Incoming application-terminated
ATINP	ATI Number Portability Query feature
ATINPQ	ATI Number Portability Query (Name of the local subsystem)

C

CNL	Small Geographic Area
CSPC	Concerned Signaling Point Code The point code that receives subsystem allowed and subsystem prohibited status messages about a particular global title translation node. These messages are broadcast from SCCP management.

E

E

EPAP

EAGLE Provisioning Application Processor

EPAP-related features

Features that require EPAP connection and use the Real Time Database (RTDB) for lookup of subscriber information.

- ANSI Number Portability Query (AINPQ)
- ANSI-41 Analyzed Information Query – no EPAP/ELAP (ANSI41 AIQ)
- Anytime Interrogation Number Portability (ATI Number Portability, ATINP)
- AINPQ, INP, G-Port SRI Query for Prepaid, GSM MAP SRI Redirect, IGM, and ATINP Support for ROP
- A-Port Circular Route Prevention (A-Port CRP)
- Equipment Identity Register (EIR)
- G-Flex C7 Relay (G-Flex)
- G-Flex MAP Layer Routing (G-Flex MLR)
- G-Port SRI Query for Prepaid
- GSM MAP SRI Redirect to Serving HLR (GSM MAP SRI Redirect)
- GSM Number Portability (G-Port)
- IDP A-Party Blacklist
- IDP A-Party Routing
- IDP Relay Additional Subscriber Data (IDPR ASD)
- IDP Relay Generic Routing Number (IDPR GRN)
- IDP Service Key Routing (IDP SK Routing)
- IDP Screening for Prepaid
- INAP-based Number Portability (INP)

E

- Info Analyzed Relay Additional Subscriber Data (IAR ASD)
- Info Analyzed Relay Base (IAR Base)
- Info Analyzed Relay Generic Routing Number (IAR GRN)
- Info Analyzed Relay Number Portability (IAR NP)
- INP Circular Route Prevention (INP CRP)
- IS41 Mobile Number Portability (A-Port)
- IS41 GSM Migration (IGM)
- MNP Circular Route Prevention (MNPCR)
- MO-based GSM SMS NP
- MO-based IS41 SMS NP
- MO SMS Generic Routing Number (MO SMS GRN)
- MO- SMS B-Party Routing
- MO SMS IS41-to-GSM Migration
- MT-based GSM SMS NP
- MT-based GSM MMS NP
- MT-based IS41 SMS NP
- MTP Routed Messages for SCCP Applications (MTP Msgs for SCCP Apps)
- MTP Routed Gateway Screening Stop Action (MTPRTD GWS Stop Action)
- Portability Check for MO SMS
- Prepaid IDP Query Relay (IDP Relay, IDPR)
- Prepaid SMS Intercept Phase 1 (PPSMS)
- Service Portability (S-Port)
- S-Port Subscriber Differentiation
- Triggerless ISUP Framework Additional Subscriber Data (TIF ASD)
- Triggerless ISUP Framework Generic Routing Number (TIF GRN)

M**MPS****Multi-Purpose Server**

The Multi-Purpose Server provides database/reload functionality and a variety of high capacity/high speed offboard database functions for applications. The MPS resides in the General Purpose Frame.

Messages Per Second

A measure of a message processor's performance capacity. A message is any Diameter message (Request or Answer) which is received and processed by a message processor.

MSISDN**Mobile Station International
Subscriber Directory Number**

The MSISDN is the network specific subscriber number of a mobile communications subscriber. This is normally the phone number that is used to reach the subscriber.

**Mobile Subscriber Integrated
Services Digital Network [Number]**

Mobile Station International Subscriber Directory Number. The unique, network-specific subscriber number of a mobile communications subscriber. MSISDN follows the E.164 numbering plan; that is, normally the MSISDN is the phone number that is used to reach the subscriber.

N**NAI****Nature of Address Indicator**

Standard method of identifying users who request access to a network.

Network Access Identifier

The user identity submitted by the client during network authentication.

R

RN	<p>Routing Number</p> <p>The number provided by the Freephone Service Provider (FSP) to the Access Service Provider (ASP) to enable a pre-determined routing of traffic to a specific network/carrier/customer.</p>
ROP	<p>Large Geographic Area (Groups of CNLs)</p>
RTDB	<p>Real Time Database</p>

S

SCP	<p>Service Control Point</p> <p>Service Control Points (SCP) are network intelligence centers where databases or call processing information is stored. The primary function of SCPs is to respond to queries from other SPs by retrieving the requested information from the appropriate database, and sending it back to the originator of the request.</p> <p>Secure Copy</p>
Service Portability	<p>See S-Port.</p>
SNAI	<p>Service Nature of Address Indicator</p> <p>An internal G-Port parameter that allows a user to specify how to interpret the signaling connection control part (SCCP) called party address (CdPA) GTA of a LOCREQ/SMSREQ message.</p>
SOG	<p>Subsystem Out-of-Service Grant</p>

S

	Service Order Gateway
SOR	Support of Optimal Routing System Out of Service Request
SP	Service Provider Signaling Point A set of signaling equipment represented by a unique point code within an SS7 domain.
SSN	SS7 Subsystem Number The subsystem number of a given point code. The subsystem number identifies the SCP application that should receive the message, or the subsystem number of the destination point code to be assigned to the LNP subsystem of the EAGLE. Subsystem Number A value of the routing indicator portion of the global title translation data commands indicating that no further global title translation is required for the specified entry. Subsystem Number Used to update the CdPA.
STP	Signal Transfer Point The STP is a special high-speed switch for signaling messages in SS7 networks. The STP routes core INAP communication between the Service Switching Point (SSP) and the Service Control Point (SCP) over the network. Spanning Tree Protocol

T

TFP	TransFer Prohibited (Msg) A procedure included in the signaling route management (functionality) used to inform a signaling point of the unavailability of a signaling route.
TSPC	True or Secondary Point Code

U

UAM	Unsolicited Alarm Message A message sent to a user interface whenever there is a fault that is service-affecting or when a previous problem is corrected. Each message has a trouble code and text associated with the trouble condition.
UIM	Unsolicited Information Message A message sent to a user interface whenever there is a fault that is not service-affecting or when a previous problem is corrected. Each message has a trouble code and text associated with the trouble condition.