

Oracle® Communications
Diameter Signaling Router
Rack Mount Server Disaster Recovery Guide
Release 7.1.x/7.2/7.3
E56227 Revision 03

July 2016

ORACLE®

**Oracle Communications Diameter Signaling Router Rack Mount Server Disaster Recovery Procedure,
Release 7.1.x/7.2/7.3**

Copyright © 2016 Oracle and/or its affiliates. All rights reserved.

This software and related documentation are provided under a license agreement containing restrictions on use and disclosure and are protected by intellectual property laws. Except as expressly permitted in your license agreement or allowed by law, you may not use, copy, reproduce, translate, broadcast, modify, license, transmit, distribute, exhibit, perform, publish, or display any part, in any form, or by any means. Reverse engineering, disassembly, or decompilation of this software, unless required by law for interoperability, is prohibited.

The information contained herein is subject to change without notice and is not warranted to be error-free. If you find any errors, please report them to us in writing.

If this is software or related documentation that is delivered to the U.S. Government or anyone licensing it on behalf of the U.S. Government, the following notice is applicable:

U.S. GOVERNMENT END USERS: Oracle programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, delivered to U.S. Government end users are "commercial computer software" pursuant to the applicable Federal Acquisition Regulation and agency-specific supplemental regulations. As such, use, duplication, disclosure, modification, and adaptation of the programs, including any operating system, integrated software, any programs installed on the hardware, and/or documentation, shall be subject to license terms and license restrictions applicable to the programs. No other rights are granted to the U.S. Government.

This software or hardware is developed for general use in a variety of information management applications. It is not developed or intended for use in any inherently dangerous applications, including applications that may create a risk of personal injury. If you use this software or hardware in dangerous applications, then you shall be responsible to take all appropriate fail-safe, backup, redundancy, and other measures to ensure its safe use. Oracle Corporation and its affiliates disclaim any liability for any damages caused by use of this software or hardware in dangerous applications.

Oracle and Java are registered trademarks of Oracle and/or its affiliates. Other names may be trademarks of their respective owners.

Intel and Intel Xeon are trademarks or registered trademarks of Intel Corporation. All SPARC trademarks are used under license and are trademarks or registered trademarks of SPARC International, Inc. AMD, Opteron, the AMD logo, and the AMD Opteron logo are trademarks or registered trademarks of Advanced Micro Devices. UNIX is a registered trademark of The Open Group.

This software or hardware and documentation may provide access to or information on content, products, and services from third parties. Oracle Corporation and its affiliates are not responsible for and expressly disclaim all warranties of any kind with respect to third-party content, products, and services. Oracle Corporation and its affiliates will not be responsible for any loss, costs, or damages incurred due to your access to or use of third-party content, products, or services, except as set forth in an applicable agreement between you and Oracle.



CAUTION:

MOS (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support (CAS) can assist you with MOS registration.

Call the CAS main number at **1-800-223-1711** (toll-free in the US), or call the Oracle Support hotline for your local country from the list at
<http://www.oracle.com/us/support/contact/index.html>.

Table of Contents

Table of Contents	3
List of Procedures	5
List of Tables	5
List of Figures	6
1.0 Introduction	7
1.1 Purpose and Scope	7
1.2 References	7
1.3 Acronyms	8
1.4 Terminology	9
1.5 Optional Features	10
2.0 General Description	11
2.1 Complete Server Outage (All Servers)	12
2.2 Partial server outage with one NOAM server intact and all SOAMs failed	12
2.3 Partial server outage with both NOAM servers failed and one SOAM server intact	12
2.4 Partial server outage with NOAM and one SOAM server intact	12
2.5 Partial server outage with Both NOAMs failed and DR-NOAM available	12
For a partial outage with both NOAM servers failed but a DR NOAM available, the DR NOAM is switched from secondary to primary then recovers the failed NOAM servers.	12
2.6 Partial Service outage with corrupt database	12
3.0 Procedure Overview	13
3.1 Required Materials	13
3.2 Disaster Recovery Strategy	14
4.0 Procedure Preparation	16
5.0 Disaster Recovery Procedure	17
5.1 Recovering and Restoring System Configuration	19
5.1.1 Recovery Scenario 1 (Complete Server Outage)	19
5.1.2 Recovery Scenario 2 (Partial Server Outage with at least one NOAM server intact and all SOAMs failed)	62
5.1.3 Recovery Scenario 3 (Partial Server Outage with all NOAM servers failed and one SOAM server intact)	93
5.1.4 Recovery Scenario 4 (Partial Server Outage with one NOAM server and one SOAM server intact)	115
5.1.5 Recovery Scenario 5 (Both NOAM servers failed with DR-NOAM available)	137

5.1.6 Recovery Scenario 6 (Database Recovery)	143
6.0 Resolving User Credential Issues after Database Restore	153
6.1 Restoring a Deleted User	153
6.2 Keeping a Restored user.....	154
6.3 Removing a Restored User	156
6.4 Restoring a Modified User.....	158
6.5 Restoring an Archive that does not contain a Current User.....	159
7.0 IDIH Disaster Recovery.....	162
Appendix A. DSR Database Backup.....	169
Appendix B. Recovering/Replacing Failed Cisco 4948 Aggregation Switches (HP DL380 Gen 8 Only) .	174
Appendix C. Switching DR NOAM Site to Primary	175
Appendix D. Returning a Recovered Site to Primary.....	179
Appendix E. Inhibit A and B Level Replication on C-Level Servers.....	186
Appendix F. Un-Inhibit A and B Level Replication on C-Level Servers	188
Appendix G. Restore TVOE Configuration from Backup Media	190
Appendix H. Restore PMAC from Backup	197
Appendix I. Workarounds for Issues not fixed in this Release.....	206
Appendix J. My Oracle Support (MOS).....	207

List of Procedures

Procedure 1: Recovery Scenario 1	20
Procedure 2: Recovery Scenario 2	63
Procedure 3: Recovery Scenario 3	94
Procedure 4: Recovery Scenario 4	117
Procedure 5: Recovery Scenario 5	138
Procedure 6: Recovery Scenario 6 (Case 1)	143
Procedure 7: Recovery Scenario 6 (Case 2)	148
Procedure 8: Keep Restored User	154
Procedure 9: Remove the Restored User	156
Procedure 10: Restoring an Archive that does not Contain a Current User	159
Procedure 11: IDIH Disaster Recovery Preparation	163
Procedure 12: IDIH Disaster Recovery (Re-Install Mediation and Application Servers)	165
Procedure 13: DSR Database Backup	169
Procedure 14: Recovering a Failed Aggregation Switch (Cisco 4948E/4948E-F)- HP DL380 Only	174
Procedure 19: Switching a DR NOAM Site to Primary	175
Procedure 20: Returning a Recovered Site to Primary	179
Procedure 21: Inhibit A and B Level Replication on C-Level Servers	186
Procedure 22: Un-Inhibit A and B Level Replication on C-Level Servers	188
Procedure 23: Restore TVOE Configuration from Backup Media	190
Procedure 24: Restore PMAC from Backup Media	197
Procedure 25: Restore PMAC from Backup Server	200

List of Tables

Table 1 Acronyms	8
Table 2 Terminology	9
Table 3 Optional Features	10
Table 4. Recovery Scenarios	16

List of Figures

Figure 1. Determining Recovery Scenario 15

1.0 Introduction

1.1 Purpose and Scope

This document is a guide to describe procedures used to execute disaster recovery for DSR 7.1.x/7.2/7.3 Rack Mount Server deployment. This includes recovery of partial or complete loss RMS servers. The audience for this document includes GPS groups such as Software Engineering, Product Verification, Documentation, and Customer Service including Software Operations and First Office Application. This document can also be executed by Oracle customers, as long as Oracle Customer Service personnel are involved and/or consulted. This document provides step-by-step instructions to execute disaster recovery for DSR 7.1.x/7.2/7.3. Executing this procedure also involves referring to and executing procedures in existing support documents.

Note that components dependent on DSR might need to be recovered as well, for example IDIH, PMAC, and SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only).

Note that this document only covers the disaster recovery scenarios of DSR 7.1.x/7.2/7.3 Rack Mount Server deployments.

1.2 References

- [1] TPD Initial Product Manufacture, E54521-01
- [2] Platform 7.0.x Configuration Procedure Reference, E54386
- [3] DSR FABR Feature Activation Procedure, E58664
- [4] DSR RBAR Feature Activation Procedure, E58665
- [5] DSR MAP-Diameter Feature Activation Procedure, E58666
- [6] PM&C 5.7/6.0 Disaster Recovery Guide, E54388
- [7] DSR 7.1/7.2/7.3 PCA Configuration, E63560
- [8] DSR 7.1.x/7.2/7.3 Rack Mount Server Installation Guide, E64707
- [9] TVOE 3.0 Disaster Recovery Procedure, E53019
- [10] DSR 7.1 Hardware and Software Installation Procedure 1/2, E53488

1.3 Acronyms

Table 1 Acronyms

Acronym	Definition
BIOS	Basic Input Output System
CD	Compact Disk
DVD	Digital Versatile Disc
EBIPA	Enclosure Bay IP Addressing
FRU	Field Replaceable Unit
iLO	Integrated Lights Out manager
IPM	Initial Product Manufacture – the process of installing TPD on a hardware platform
MSA	Modular Smart Array
NB	NetBackup
OA	HP Onboard Administrator
OS	Operating System (e.g. TPD)
RMS	Rack Mounted Server
PMAC	Platform Management & Configuration
SAN	Storage Area Network
SFTP	Secure File Transfer Protocol
SNMP	Simple Network Management Protocol
TPD	Tekelec Platform Distribution
TVOE	Tekelec Virtual Operating Environment
VM	Virtual Machine
VSP	Virtual Serial Port
IPFE	IP Front End
PCA	Policy and Charging Application
IDIH	Integrated Diameter Intelligence Hub
SDS	Subscriber Database Server

1.4 Terminology

Table 2 Terminology

Base hardware	Base hardware includes all hardware components (bare metal) and electrical wiring to allow a server to power on.
Base software	Base software includes installing the server's operating system: Oracle Platform Distribution (TPD).
Failed server	A failed server in disaster recovery context refers to a server that has suffered partial or complete software and/or hardware failure to the extent that it cannot restart or be returned to normal operation and requires intrusive activities to re-install the software and/or hardware.
Software Centric	The business practice of delivering an Oracle software product, while relying upon the customer to procure the requisite hardware components. Oracle provides the hardware specifications, but does not provide the hardware or hardware firmware, and is not responsible for hardware installation, configuration, or maintenance.
Enablement	The business practice of providing support services (hardware, software, documentation, etc) that enable a 3rd party entity to install, configuration, and maintain Oracle products for Oracle customers.

1.5 Optional Features

Further configuration and/or installation steps will need to be taken for optional features that may be present in this deployment. Please refer to these documents for disaster recovery steps needed for their components

Table 3 Optional Features

Feature	Document
Range Based Address Resolution (RBAR)	DSR RBAR Feature Activation Procedure, E58665
Map-Diameter Interworking (MAP-IWF)	DSR MAP-Diameter Feature Activation Procedure, E58666
Policy and Charging Application (PCA) – (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only)	DSR 7.1/7.2/7.3 PCA Configuration, E63560
Full Address Based Resolution (FABR) – (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only)	DSR FABR Feature Activation Procedure, E58664

2.0 General Description

The DSR disaster recovery procedure falls into five basic categories. It is primarily dependent on the state of the NOAM servers and SOAM servers:

Recovery of the entire network from a total outage	<ul style="list-style-type: none">• All NOAM servers failed• All SOAM servers failed
Recovery of one or more servers with at least one NOAM server intact	<ul style="list-style-type: none">• 1 or more NOAM servers intact• 1 or more SOAM or MP servers failed
Recovery of the NOAM pair with one or more SOAM servers intact	<ul style="list-style-type: none">• All NOAM servers failed• 1 or more SOAM servers intact
Recovery of one or more server with at least one NOAM and one SOAM server intact.	<ul style="list-style-type: none">• 1 or more NOAM servers intact• 1 or more SOAM servers intact• 1 SOAM or 1 or more MP servers failed
Recovery of one or more server with corrupt databases that cannot be restored via replication from the active parent node.	

Note: For Failed Aggregation switches (HP DL380 Gen 8 Only) refer to **Appendix B.**
Recovering/Replacing Failed Cisco 4948 Aggregation Switches.

2.1 Complete Server Outage (All Servers)

This is the worst case scenario where all the servers in the network have suffered complete software and/or hardware failure. The servers are recovered using base recovery of hardware and software and then restoring database backups to the active NOAM and SOAM servers.

Database backups will be taken from customer offsite backup storage locations (assuming these were performed and stored offsite prior to the outage). If no backup files are available, the only option is to rebuild the entire network from scratch. The network data must be reconstructed from whatever sources are available, including entering all data manually.

2.2 Partial server outage with one NOAM server intact and all SOAMs failed

This case assumes that at least one NOAM servers intact. All SOAM servers have failed (including SOAM spares-If equipped) and are recovered using base recovery of hardware and software. Database is restored on the SOAM server and replication will recover the database of the remaining servers.

2.3 Partial server outage with both NOAM servers failed and one SOAM server intact

If both NOAM servers have suffered complete software and/or hardware failure (where DR-NOAMs are not present), but at least one SOAM server is available. Database is restored on the NOAM and replication will recover the database of the remaining servers.

2.4 Partial server outage with NOAM and one SOAM server intact

The simplest case of disaster recovery is with at least one NOAM and at least one SOAM servers intact. All servers are recovered using base recovery of hardware and software. Database replication from the active NOAM and SOAM servers will recover the database to all servers. (**Note:** this includes failures of any disaster recovery NOAM servers)

2.5 Partial server outage with Both NOAMs failed and DR-NOAM available

For a partial outage with both NOAM servers failed but a DR NOAM available, the DR NOAM is switched from secondary to primary then recovers the failed NOAM servers.

2.6 Partial Service outage with corrupt database

Case 1: Database is corrupted, replication channel is inhibited (either manually or because of comcol upgrade barrier) and database backup is available

Case 2: Database is corrupted but replication channel is active

3.0 Procedure Overview

This section lists the materials required to perform disaster recovery procedures and a general overview (disaster recovery strategy) of the procedure executed.

3.1 Required Materials

The following items are needed for disaster recovery:

1. A hardcopy of this document (E66227) and hardcopies of all documents in the reference list
2. Hardcopy of all NAPD performed at the initial installation and network configuration of this customer's site. If the NAPD cannot be found, escalate this issue within My Oracle Support (MOS) until the NAPD documents can be located.
3. DSR recent backup files: Electronic backup file (preferred) or hardcopy of all DSR configuration and provisioning data.
4. Latest Network Element report: Electronic file or hardcopy of Network Element report.
5. The xml configuration files used to configure the Cisco 4948 aggregation switches, available on the PMAC Server (or PMAC backup)
6. The switch backup files taken after the switch is configured, available on the PMAC Server (or PMAC backup)
7. The network element XML file used for the initial configuration.
8. Firmware files as provided by hardware vendor
9. NetBackup Files if they exist. This may require the assistance of the customer's NetBackup administrator.
10. PMAC and TVOE backups (*If available*)
11. One (1) target release DSR Media, or a target-release ISO
12. One (1) target release SDS Media, or a target-release ISO (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only)
13. Three (3) target release iDIH Media, or target-release ISOs
14. VM Placement and Socket Pinning workbook (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only)
15. Latest RADIUS shared secret encryption key file backup (DpiKf.bin.encr)
16. List of activated and enabled features


Note: For all Disaster Recovery scenarios, we assume that the NOAM Database backup and the SOAM database backup were performed around the same time, and that no synchronization issues exist among them.

3.2 Disaster Recovery Strategy

Disaster recovery procedure execution is performed as part of a disaster recovery strategy with the basic steps listed below:

1. Evaluate failure conditions in the network and determine that normal operations cannot continue without disaster recovery procedures. This means the failure conditions in the network match one of the failure scenarios described in **section 2.0**.
2. Read and review the content in this document.
3. Gather required materials in **section 3.1 Required Materials**
4. From the failure conditions, determine the Recovery Scenario and procedure to follow (using **Figure 1. Determining Recovery Scenario** and **Table 4. Recovery Scenarios**).
5. Execute appropriate recovery procedures (listed in **Table 4. Recovery Scenarios**).

Figure 1. Determining Recovery Scenario



4.0 Procedure Preparation

Disaster recovery procedure execution is dependent on the failure conditions in the network. The severity of the failure determines the recovery scenario for the network. Use **Table 4. Recovery Scenarios** below to evaluate the correct recovery scenario and follow the procedure(s) listed to restore operations.

Note: A failed server in disaster recovery context refers to a server that has suffered partial or complete software and/or hardware failure to the extent that it cannot restart or be returned to normal operation and requires intrusive activities to re-install the software and/or hardware.

Table 4. Recovery Scenarios

Recovery Scenario	Failure Condition	Section
1	<ul style="list-style-type: none">• All NOAM servers failed.• All SOAM servers failed.• MP servers may or may not be failed.	Section 5.1.1 Recovery Scenario 1 (Complete Server Outage)
2	<ul style="list-style-type: none">• At least 1 NOAM server is intact and available.• All SOAM servers failed.• MP servers may or may not be failed.	Section 5.1.2 Recovery Scenario 2 (Partial Server Outage with at least one NOAM server intact and all SOAMs failed)
3	<ul style="list-style-type: none">• All NOAM servers failed.• At least 1 SOAM server out of Active, StandBy, Spare is intact and available.• MP servers may or may not be failed.	Section 5.1.3 Recovery Scenario 3 (Partial Server Outage with all NOAM servers failed and one SOAM server intact)

4	<ul style="list-style-type: none"> • At least 1 NOAM server is intact and available. • At least 1 SOAM server out of Active, StandBy, Spare is intact and available. • 1 or more MP servers have failed. 	Section 5.1.4 Recovery Scenario 4 (Partial Server Outage with one NOAM server and one SOAM server intact)
5	<ul style="list-style-type: none"> • Both NOAM servers failed. • DR NOAM is Available • SOAM servers may or may not be failed. • MP servers may or may not be failed. 	Section 5.1.5 Recovery Scenario 5 (Both NOAM servers failed with DR-NOAM available)
6: Case 1	<ul style="list-style-type: none"> • Server is intact • Database gets corrupted on the server • Replication channel from parent is inhibited because of upgrade activity 	Section 5.1.6.1 Recovery Scenario 6: Case 1
6: Case 2	<ul style="list-style-type: none"> • Server is intact • Database gets corrupted on the server • Latest Database backup of the corrupt server is NOT present • Server having a corrupted database • Replication channel is not inhibited • Server has the same release as that of its Active parent 	Section 5.1.6.2 Recovery Scenario 6: Case 2

5.0 Disaster Recovery Procedure

Call [Appendix J, My Oracle Support \(MOS\)](#) prior to executing this procedure to ensure that the proper recovery planning is performed.

Before disaster recovery, users must properly evaluate the outage scenario. This check ensures that the correct procedures are executed for the recovery.

**** **WARNING** ****

**** **WARNING** ****

Note: Disaster recovery is an exercise that requires collaboration of multiple groups and is expected to be

coordinated by the TAC prime. Based on TAC's assessment of Disaster, it may be necessary to deviate from the documented process.

Recovering Base Hardware:

1. Hardware Recovery will be executed by the appropriate HW vender.
2. Base Hardware Replacement must be controlled by engineer familiar with DSR Application

5.1 Recovering and Restoring System Configuration

Disaster recovery requires configuring the system as it was before the disaster and restoration of operational information. There are eight distinct procedures to choose from depending on the type of recovery needed. Only one of these should be followed (not all).

5.1.1 Recovery Scenario 1 (Complete Server Outage)

For a complete server outage, TVOE is recovered on all RMS Servers. The VMs are re-created and configured. The database restored on one of the NOAM and SOAM servers. Database replication from the active NOAM server will recover the database on these servers. The major activities are summarized in the list below. Use this list to understand the recovery procedure summary. Do not use this list to execute the procedure. The actual procedures' detailed steps are in Procedure 1. The major activities are summarized as follows:

Recover Base Hardware and Software for all RMSs:

- Recover the base hardware
- Recover the Virtual Machines
- Recover the software

Recover PMAC

Recover Active NOAM Guest.

- Recover the NOAM database.
- Reconfigure the application

Recover Standby NOAM Guest.

- Reconfigure the Application

Recover Query Server (SDS Only) Guest

- Reconfigure the Application

Recover all SOAM and MP/DP Guest.

- Recover the SOAM database.
- Reconfigure the Application

Recover IDIH if necessary

Restart processes and re-enable provisioning and replication.

Procedure 1: Recovery Scenario 1

S T E P #	<p>This procedure performs recovery if both NOAM servers are failed and all SOAM servers are failed. This procedure also caters the C-Level Sever failure</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact Appendix J. My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Workarounds	Refer to Appendix I . Workarounds for Issues not fixed in this Release to understand any workarounds required during this procedure.
2 <input type="checkbox"/>	Gather Required Materials	Gather the documents and required materials listed in Section 3.1 Required Materials
3 <input type="checkbox"/>	Replace Failed Equipment	HW vendor to replace the failed equipment
4 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Configure BIOS Settings and Update Firmware	<ol style="list-style-type: none"> Configure and verify the BIOS/NEB settings by executing procedure “<i>Configure Oracle X5-2/Netra X5-2 Server</i>” from reference [8] Verify and/or upgrade server firmware by executing procedure “<i>Upgrade Rack Mount Server Firmware</i>” from reference [8]
5 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Backup Available	<p>This step assumes that TVOE and PMAC backups are available, if backups are NOT available, skip this step.</p> <ol style="list-style-type: none"> Restore the TVOE backup by executing Appendix G. Restore TVOE Configuration from Backup Media on ALL failed rack mount servers Restore the PMAC backup by executing Appendix H. Restore PMAC from Backup <p style="text-align: center;">Proceed to Step 7</p>
6 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Backup Not Available	<p>This step assumes that TVOE and PMAC backups Are NOT available, if the TVOE and PMAC have already been restored, skip this step</p> <ol style="list-style-type: none"> Execute procedure “<i>Install and Configure TVOE on First RMS (PMAC Host)</i>” from reference [8] Execute section “<i>Install PMAC</i>” from reference [8] <p style="text-align: center;">Proceed to Next Step</p>

Procedure 1: Recovery Scenario 1

7 <input type="checkbox"/>	Recovery Failed Cisco 4948 Aggregation Switches (HP DL380 Only)	<p>Recover failed Cisco 4948 aggregation switches, if needed:</p> <p>Backup configuration files available: Refer to Appendix B. Recovering/Replacing Failed Cisco 4948 Aggregation Switches to recover failed Cisco 4948 aggregation switches</p> <p>Backup configuration files NOT available: Execute section “Configure Cisco 4948E-F Aggregation Switches (HP DL 380 Gen 8 Only)” from reference [8]</p>
8 <input type="checkbox"/>	Configure PMAC (No Backup)	<p>If PMAC backup was NOT restored in step 5, execute this step. Otherwise Skip this Step.</p> <p>Execute sections “Configure PMAC Server” and “Add Cabinet to PMAC” from reference [8]</p>
9 <input type="checkbox"/>	Install/Configure Additional Rack Mount Servers	<p>If TVOE backups were NOT performed on any additional rack mount servers or are not available, execute this step. Otherwise Skip this Step</p> <ol style="list-style-type: none"> Oracle X5-2/Netra X5-2/ HP DL380 GEN 8: Execute procedure “Install TVOE on Additional Rack Mount Servers” from reference [8] HP DL380 GEN 9: Execute procedure “Install and Configure TVOE on First RMS” from reference [8] Execute “Configure TVOE on Additional Rack Mount Servers” from reference [8] Configure and verify the BIOS/NEB settings by executing procedure “Configure Oracle X5-2/Netra X5-2 Server” from reference [8]
10 <input type="checkbox"/>	Determine VM Placement and Socket Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only)	<p>Oracle X5-2/Netra X5-2/HP DL380 GEN 9 ONLY, HP DL380 GEN 8 SKIP THIS STEP</p> <p>Determine the VM placement and Pinning for proper VM placement and pinning.</p>
11 <input type="checkbox"/>	Deploy Redundant PMAC	<p>Refer to procedure “Deploy Redundant PMAC (Optional)” to re-deploy and configure any redundant PMACs previously configured.</p>
12 <input type="checkbox"/>	Create Virtual Machines For Applications	<p>Execute section “Create Virtual Machines for Applications” from reference [8]</p>
13 <input type="checkbox"/>	Perform CPU Pinning	<p>Configure VM CPU socket pinning on each TVOE host to optimize performance by executing procedure “CPU Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only)” from reference [8]</p>
14 <input type="checkbox"/>	Install Software on Virtual Machines	<p>Execute section “Install Software on Virtual Machines” from reference [8]</p>



Procedure 1: Recovery Scenario 1

15 <input type="checkbox"/>	Obtain Latest Database Backup and Network Configuration Data.	<ol style="list-style-type: none"> 1. Obtain the most recent database backup file from external backup sources (ex. file servers) or tape backup sources. 2. Obtain most recent “RADIUS shared secret encryption key” file DpiKf.bin.encr from external backup sources (Only when the RADIUS Key Revocation MOP has been executed on the system) <p>From required materials list in Section 3.1 Required Materials; use site survey documents and Network Element report (if available), to determine network configuration data.</p>
16 <input type="checkbox"/>	Execute DSR Installation Procedure for the First NOAM	<p>Verify the networking data for Network Elements</p> <p>Note: Use the backup copy of network configuration data and site surveys (Step 2)</p> <p>Note: SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only) disaster recovery actions can and should be worked simultaneously, doing so would allow faster recovery of the complete solution (i.e. stale DB on DP servers will not receive updates until SDS-SOAM servers are recovered. The following steps will be written to accommodate both DSR and SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only) disaster recovery steps.</p> <p>IMPORTANT: While creating the first NOAMs in this step, it is important that the server hostname is the same as one of the NOAM hostnames used prior to the disaster.</p> <p>DSR:</p> <ol style="list-style-type: none"> 1. Configure the first NOAM server by executing procedure “<i>Configure First NOAM NE and Server</i>” from reference [8] 2. Configure the NOAM server group by executing procedure “<i>Configure the NOAM Server Group</i>” from reference [8] <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only):</p> <ol style="list-style-type: none"> 1. Configure the first SDS NOAM server by executing procedure “<i>Configure First SDS NOAM NE and Server</i>” from reference [8] 2. Configure the SDS NOAM server group by executing procedure “<i>Configure the SDS NOAM Server Group</i>” from reference [8]


Procedure 1: Recovery Scenario 1

17 <input type="checkbox"/>	<p>NOAM GUI: Login</p> <p>DSR Only, if SDS, Skip to Step 23</p> <p>Login to the NOAM GUI as the guiadmin user:</p> 
--------------------------------	--

Procedure 1: Recovery Scenario 1

<p>18 <input type="checkbox"/> NOAM GUI: Upload the Backed up Database File</p>	<p>DSR Only, if SDS, Skip to Step 23</p> <p>Browse to Main Menu->Status & Manage->Files</p>  <p>Select the Active NOAM server. The following screen will appear:</p>  <p>Click on Upload as shown below and select the file “<i>NO Provisioning and Configuration:</i>” file backed up after initial installation and provisioning.</p> <p>Upload</p> <p>1 GB used (3.00%) of 34 GB available System utilization: 1.8 GB (5.24%) of 34 GB available.</p> <ol style="list-style-type: none"> 1. Click on Browse and locate the backup file 2. Check This is a backup file Box 3. Click on Open as shown below.  <p>Click on the Upload button. The file will take a few seconds to upload depending on the size of the backup data. The file will be visible on the list of entries after the upload is complete.</p>
--	---

Procedure 1: Recovery Scenario 1

19	<p>NOAM GUI: Disable Provisioning</p>	<p>DSR Only, if SDS, Skip to Step 23</p> <p>Click on Main Menu->Status & Manage->Database</p>  <p>Disable Provisioning by clicking on Disable Provisioning button at the bottom of the screen as shown below.</p>  <p>A confirmation window will appear, press OK to disable Provisioning.</p>  <p>The message "<i>Warning Code 002</i>" will appear.</p>
----	--	--

Procedure 1: Recovery Scenario 1

<p>20</p> <p><input type="checkbox"/> NOAM GUI: Verify the Archive Contents and Database Compatibility</p>	<p>DSR Only, if SDS, Skip to Step 23</p> <p>Select the Active NOAM server and click on the Compare.</p> <p>Database Compare</p> <p>Select archive to compare on server: Shelby.NO-A</p> <p>Archive</p> <p><input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160405_021501.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160406_021502.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160407_021501.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160408_021501.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration_.72.18.0.MAN.tar.b2z</p> <p>Ok Cancel</p> <p>Verify that the output window matches the screen below.</p> <p>Note: You will get a database mismatch regarding the NodeIDs. That is expected. If that is the only mismatch, proceed, otherwise stop and contact Appendix J. My Oracle Support (MOS) and ask for assistance.</p> <p>Note: Archive Contents and Database Compatibilities must be the following:</p> <p>Archive Contents: Configuration data</p> <p>Database Compatibility: The databases are compatible.</p> <p>Note: The following is expected Output for Topology Compatibility Check since we are restoring from existing backed up data base to database with just one NOAM:</p> <p>Topology Compatibility THE TOPOLOGY SHOULD BE COMPATIBLE MINUS THE NODEID.</p> <p>Note: We are trying to restore a backed up database onto an empty NOAM database. This is an expected text in Topology Compatibility.</p> <p>If the verification is successful, Click BACK button and continue to next step in this procedure.</p>
---	---

Procedure 1: Recovery Scenario 1

21	ACTIVE NOAM: <input type="checkbox"/> Restore the Database	<p>DSR Only, if SDS, Skip to Step 23</p> <p>Click on Main Menu->Status & Manage->Database</p> <p>Select the Active NOAM server, and click on Restore as shown below.</p> <p>The following screen will be displayed. Select the proper back up provisioning and configuration file.</p> <p>Database Restore</p> <p>Select archive to Restore on server: Shelby-NO-A</p> <p>Archive</p> <ul style="list-style-type: none"> <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160405_021501.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160406_021502.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160407_021501.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration.NETWORK_OAMP.20160408_021501.AUTO.tar <input type="radio"/> backup/Backup.dsr.Shelby-NO-A.Configuration._72.18.0.MAN.tar.bz2 * <p>Ok Cancel</p> <p>Click OK Button. The following confirmation screen will be displayed.</p> <p>If you get an error that the NodeIDs do not match. That is expected. If no other errors beside the NodeIDs are displayed, select the Force checkbox as shown above and Click OK to proceed with the DB restore.</p> <p>Database Restore Confirm</p> <p>Incompatible database selected</p> <p>Discrepancies:</p> <ul style="list-style-type: none"> - IMI Server Address A3118.120 has different node IDs in current topology and the selected backup file. Current node ID: A3118.120, Selected backup file node ID: B2073.087 - IMI Server Address C1157.241 has different node IDs in current topology and the selected backup file. Current node ID: C1157.241, Selected backup file node ID: B2073.087 - IMI Server Address B1787.161 has different node IDs in current topology and the selected backup file. Current node ID: B1787.161 Selected backup file node ID: B2073.087 <p>Confirm archive "3bladeNPQR.blade07.Configuration.NETWORK_OAMP.20110119_184253.MAN.tar" to Restore on server: blade07</p> <p>Force Restore? <input checked="" type="checkbox"/> Force Force restore on blade07, despite compare errors.</p> <p>Ok Cancel</p> <p>Note: After the restore has started, the user will be logged out of XMI NO GUI since the restored Topology is old data.</p>
----	--	---


Procedure 1: Recovery Scenario 1

22	SDS NOAM: Transfer SDS Configuration and Provisioning backup Database Files	SDS Only, if DSR, Skip this step
		<p>Using the IP of the recovered SDS NOAM, transfer the uncompressed backup database files to the <code>/var/TKLC/db/filemgmt</code> directory</p> <p>Linux:</p> <ol style="list-style-type: none"> From the command line of a Linux machine use the following command to copy the configuration backup file to the SDS NOAM guest: <div data-bbox="589 620 1277 680" style="border: 1px solid black; padding: 5px;"> <pre># scp <path_to_configuration_db_file> admusr@<SDS_NOAM_IP>:/var/TKLC/db/filemgmt</pre> </div> <ol style="list-style-type: none"> From the command line of a Linux machine use the following command to copy the provisioning backup file to the SDS NOAM guest: <div data-bbox="589 844 1277 903" style="border: 1px solid black; padding: 5px;"> <pre># scp <path_to_provisioning_db_file> admusr@<SDS_NOAM_IP>:/var/TKLC/db/filemgmt</pre> </div> <p>Note: where <code><path_to_db_file></code> is the path to the backup database file on the local system and <code><SDS_NOAM_IP></code> is the recovered SDS NOAM IP address.</p> <p>Windows:</p> <p>Use WinSCP to copy the backup database files into the <code>/var/TKLC/db/filemgmt</code> directory. Please refer to [10] procedure <i>Using WinSCP</i> to copy the backup image to the customer system.</p>
23	SDS NOAM: Login	SDS Only, if DSR, Skip this step
	SDS NOAM: Stop running applications	SDS Only, if DSR, Skip this step
		<p>Issue the following command to stop running applications. Leave database running:</p> <div data-bbox="507 1564 985 1596" style="border: 1px solid black; padding: 5px;"> <pre>\$ sudo prod.stop --ignore-cap</pre> </div> <p>Note: This step may take several minutes to complete.</p>


Procedure 1: Recovery Scenario 1

25 <input type="checkbox"/>	SDS NOAM: Stop running applications	SDS Only, if DSR, Skip this step Restore the configuration DB by executing the following command: <pre>\$ sudo idb.restore -n -t /var/TKLC/db/filemgmt -v <full path to configuration archive file name></pre>
26 <input type="checkbox"/>	SDS NOAM: Stop running applications	SDS Only, if DSR, Skip this step Restore the configuration DB by executing the following command: <pre>\$ sudo idb.restore -n -t /var/TKLC/db/filemgmt -v <full path to provisioning archive file name></pre>
27 <input type="checkbox"/>	SDS NOAM: Stop running applications	SDS Only, if DSR, Skip this step Start the SDS application by executing the following command: <pre>\$ sudo prod.start</pre>
28 <input type="checkbox"/>	NOAM VIP GUI: Login	Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of: <pre>http://<Primary_NOAM_VIP_IP_Address></pre> Login as the guiadmin user: 


Procedure 1: Recovery Scenario 1

29	NOAM VIP GUI: <input type="checkbox"/> Monitor and Confirm database restoral	<p>Wait for 5-10 minutes for the System to stabilize with the new topology:</p> <p>Monitor the Info tab for "Success". This will indicate that the restore is complete and the system is stabilized.</p> <p>The following alarms must be ignored for NOAM and MP Servers until all the Servers are configured:</p> <p>Alarms with Type Column as "REPL" , "COLL", "HA" (with mate NOAM), "DB" (about Provisioning Manually Disabled)</p> <p>Note: Do not pay attention to these alarms until all the servers in the system are completely restored.</p> <p>Note: The Configuration and Maintenance information will be in the same state it was backed up during initial backup.</p>
30	Active NOAM: <input type="checkbox"/> Set Failed Servers to Standby	<p>Navigate to Main Menu -> Status & Manage -> HA</p>  <p>Select Edit</p> <p>Set the Max Allowed HA Role drop down box to Standby for the failed servers.</p> <p>Select Ok</p> 
31	ACTIVE NOAM: <input type="checkbox"/> Login	<p>Login to the recovered Active NOAM via SSH terminal as admusr.</p>




Procedure 1: Recovery Scenario 1

32 <input type="checkbox"/>	<p>NOAM VIP GUI: Recover Standby NOAM</p>	<p>Install the second NOAM server:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the Second NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8].</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only):</p> <p>Execute procedure “<i>Configure the Second SDS NOAM Server</i>”, steps 1, 4-7, 9-10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8]</p>
33 <input type="checkbox"/>	<p>Install NetBackup Client (Optional)</p>	<p>If NetBackup is used execute procedure “<i>Install NetBackup Client (Optional)</i>” from reference [8]</p>
34 <input type="checkbox"/>	<p>Active NOAM: Correct the RecognizedAuthority table</p>	<p>Establish an SSH session to the active NOAM, login as admusr.</p> <p>Execute the following command:</p> <pre>\$ sudo top.setPrimary - Using my cluster: A1789 - New Primary Timestamp: 11/09/15 20:21:43.418 - Updating A1789.022: <DSR_NOAM_B_hostname> - Updating A1789.144: <DSR_NOAM_A_hostname></pre>
35 <input type="checkbox"/>	<p>NOAM VIP GUI: Restart DSR application</p>	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered standby NOAM server and click on Restart.</p> 



Procedure 1: Recovery Scenario 1

36	<p>NOAM VIP GUI: Set HA on Standby NOAM</p>	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>Select the standby NOAM server, set it to Active</p> <p>Press OK</p>
----	--	--

Procedure 1: Recovery Scenario 1


37	<p>NOAM VIP GUI: Perform Keyexchange with Remote Import Server</p>	<p>SDS Only, DSR Skip This Step</p> <p>1) Navigate to Main Menu -> SDS -> Configuration -> Options</p>  <p>2) Uncheck the Remote Import Enabled Box:</p>  <p>3) Click Apply</p>  <p>Note: Re-navigate to Main Menu -> SDS -> Configuration -> Options to clear Success banner.</p> <p>4) Re-Enter the Remote Import Password:</p>  <p>5) Click Apply</p>  <p>Note: Re-navigate to Main Menu -> SDS -> Configuration -> Options to clear Success banner.</p> <p>6) Check the Remote Import Enabled Box:</p> 
----	---	---

Procedure 1: Recovery Scenario 1


		SDS Only, DSR Skip This Step
38	NOAM VIP GUI: Repeat for <input type="checkbox"/> Remote Export Server	Repeat Step 36 for the remote Export Server
39	NOAM VIP GUI: Perform Keyexchange with Export Server	<p>Navigate to Main Menu -> Administration -> Remote Servers -> Data Export</p>  <p>Click on SSH Key Exchange at the bottom of the screen</p> <p>Enter the Password and press OK</p> 
40	NOAM VIP GUI: Recover Query Servers	SDS Only, DSR Skip This Step <p>Execute procedure “Configuring SDS Query Servers”, steps 1, 4-9 from reference [8]</p>
41	SDS NOAM VIP GUI: Restart SDS application	SDS Only, DSR Skip This Step <p>Navigate to Main Menu->Status & Manage->Server</p>  <p>Select the recovered Query server and click on Restart.</p> 

Procedure 1: Recovery Scenario 1


Procedure 1: Recovery Scenario 1

44	NOAM VIP GUI: <input type="checkbox"/> Recover Active SOAM Server	<p>Install the SOAM servers</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the SOAM Servers</i>”, steps 1-3, and 5-8, 10. from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p> <p>Note: If you are using NetBackup, also execute step 12.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only):</p> <p>Execute procedure “<i>Configure the SDS SOAM Servers</i>”, steps 1-3, and 5-8, 10. from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p>
45	NOAM VIP GUI: <input type="checkbox"/> Set HA on SOAM Server	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>Select the SOAM server, set it to Active</p> <p>Press OK</p>

Procedure 1: Recovery Scenario 1

46	<p>NOAM VIP GUI: Restart DSR application</p>	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered SOAM server and click on Restart.</p> 
----	---	---

Procedure 1: Recovery Scenario 1

<p>DSR Only, if SDS, Skip This Step</p>	
<p>47 <input type="checkbox"/> NOAM VIP GUI: Upload the backed up SOAM Database file (DSR Only)</p>	<p>DSR Only, if SDS, Skip This Step</p> <p>Navigate to Main Menu->Status & Manage->Files</p> <p>Select the Active SOAM server. The following screen will appear. Click on Upload as shown below and select the file “<i>SO Provisioning and Configuration:</i>” file backed up after initial installation and provisioning.</p> <p style="text-align: center;"> <input type="button" value="Delete"/> <input type="button" value="View"/> <input type="button" value="Upload"/> <input type="button" value="Download"/> <input type="button" value="Deploy ISO"/> <input type="button" value="Validate ISO"/> </p> <p>1 GB used (3.00%) of 34 GB available System utilization: 1.8 GB (5.24%) of 34 GB available.</p> <p>1. Click on Browse and locate the backup file 2. Check This is a backup file Box 3. Click on Open as shown below.</p>   <p>Click on the Upload button. The file will take a few seconds to upload depending on the size of the backup data. The file will be visible on the list of entries after the upload is complete.</p>



Procedure 1: Recovery Scenario 1

DSR Only, if SDS, Skip This Step	
48	<p>Recovered SOAM GUI: Login (DSR Only)</p> <p>Establish a GUI session on the recovered SOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;">http://<Recovered_SOAM_IP_Address></div> <p>Login as the guiadmin user:</p> 

Procedure 1: Recovery Scenario 1

<p>49</p> <p><input type="checkbox"/> Recovered SOAM GUI: Verify the Archive Contents and Database Compatibility (DSR Only)</p>	<p>DSR Only, if SDS, Skip This Step</p> <p>Click on Main Menu->Status & Manage->Database</p> <p>Select the Active SOAM server and click on the Compare.</p>  <p>The following screen is displayed; click the button for the restored database file that was uploaded as a part of Step 13 of this procedure.</p> <p>Database Compare</p> <p>Select archive to compare on server: Corvette-SO-B</p> <p>Archive</p> <p>• The selected database came from blade07 on 01/19/2011 at 13:43:47 EDT and contains the following comment: • • Archive Contents • provisioningConfig, configuration data • Database Compatibility • The databases are compatible. • • Node Type Compatibility • The node types are compatible. • • Topology Compatibility • THE TOPOLOGY IS NOT COMPATIBLE. CONTACT TEXELC CUSTOMER SERVICES BEFORE RESTORING THIS DATABASE.</p> <p>• Description - IMI Server Address A3118 120 has different node ID in current topology and the selected backup file. Current node ID: A3118 120. Selected backup file node ID: E2073 087 - IMI Server Address C1157 241 has different node ID in current topology and the selected backup file. Current node ID: C1157 241. Selected backup file node ID: E2073 087 - IMI Server Address B1787 161 has different node ID in current topology and the selected backup file. Current node ID: B1787 161. Selected backup file node ID: E2073 087</p> <p>• User Compatibility • The user and authentication data are compatible. • Contracts • provisioningMdsConfiguration • Fabric Instance Counts • Current AdminKeys count: 0 Selected: 0 • Current AdminServers count: 0 Selected: 0 • Current ApowersCapacityConstraints count: 2 Selected: 2 • Current AssociationCountSet count: 0 Selected: 0 • Current AssociationConfigSet count: 1 Selected: 1 • Current AuthMKeys count: 2 Selected: 6 • Current AuthorizedIp count: 1 Selected: 1</p> <p>Note: Archive Contents and Database Compatibilities must be the following: Archive Contents: Configuration data Database Compatibility: The databases are compatible.</p> <p>Note: The following is expected Output for Topology Compatibility Check since we are restoring from existing backed up data base to database with just one SOAM:</p> <p>Topology Compatibility THE TOPOLOGY SHOULD BE COMPATIBLE MINUS THE NODEID.</p> <p>Note: We are trying to restore a backed up database onto an empty SOAM database. This is an expected text in Topology Compatibility.</p> <p>If the verification is successful, Click BACK button and continue to next step in this procedure.</p>
--	---


Procedure 1: Recovery Scenario 1

50	<p>Recovered SOAM GUI: <input type="checkbox"/> Restore the Database (DSR Only)</p>	<p>DSR Only, if SDS, Skip This Step</p> <p>Select the Active SOAM server, and click on Restore as shown below.</p> <p>The following screen will be displayed. Select the proper back up provisioning and configuration file.</p> <p>Main Menu: Status & Manage -> Database [Restore]</p>  <p>Click OK Button. The following confirmation screen will be displayed.</p> <p>If you get an error that the NodeIDs do not match. That is expected. If no other errors beside the NodeIDs are displayed, select the Force checkbox as shown above and Click OK to proceed with the DB restore.</p>  <p>Note: After the restore has started, the user will be logged out of XMI SOAM GUI since the restored Topology is old data.</p>
51	<p>Recovered SOAM GUI: <input type="checkbox"/> Monitor and Confirm database restoral (DSR Only)</p>	<p>DSR Only, if SDS, Skip This Step</p> <p>Wait for 5-10 minutes for the System to stabilize with the new topology:</p> <p>Monitor the Info tab for “Success”. This will indicate that the restore is complete and the system is stabilized.</p> <p>Note: Do not pay attention to alarms until all the servers in the system are completely restored.</p> <p>Note: The Configuration and Maintenance information will be in the same state it was backed up during initial backup.</p>



Procedure 1: Recovery Scenario 1

52	NOAM VIP GUI: <input type="checkbox"/> Login	<p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"><a href="http://<Primary_NOAM_VIP_IP_Address>">http://<Primary_NOAM_VIP_IP_Address></div> <p>Login as the guiadmin user:</p>
53	NOAM VIP GUI: <input type="checkbox"/> Recover the Remaining SOAM Servers	<p>Recover the remaining SOAM servers (Standby, Spare-Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only) by DSR:</p> <p>Execute procedure “<i>Configure the SOAM Servers</i>”, steps 1-3, and 5-8, 10 from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p> <p>Note: If you are using NetBackup, also execute step 12.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen9 Only):</p> <p>Execute procedure “<i>Configure the SDS SOAM Servers</i>”, steps 1-3, and 5-8, 10 from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p>



Procedure 1: Recovery Scenario 1

54	NOAM VIP GUI: <input type="checkbox"/> Restart DSR application	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered standby SOAM server and click on Restart.</p> <p>Stop Restart Reboot NTP Sync Report</p>
55	NOAM VIP GUI: <input type="checkbox"/> Start Replication on Working C-Level Servers (DSR Only)	<p>DSR Only, if SDS, Skip This Step</p> <p>Un-Inhibit (<i>Start</i>) Replication to the working C-Level Servers which belongs to the same site as of the failed SOAM servers.</p> <p>Execute Appendix F. Un-Inhibit A and B Level Replication on C-Level Servers</p> <p>If the “<i>Rep/ Status</i>” is set to “Inhibited”, click on the Allow Replication button as shown below using the following order, otherwise if none of the servers are inhibited, skip this step and continue with the next step:</p> <ul style="list-style-type: none"> • Active NOAM Server • Standby NOAM Server • Active SOAM Server • Standby SOAM Server • Spare SOAM Server (<i>if applicable</i>) –Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only • Active DR NOAM Server • Standby DR NOAM Server • MP/IPFE Servers • SBRs (<i>if SBR servers are configured, start with the active SBR, then standby, then spare</i>) –Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only <p>Verify that the replication on all the working servers is allowed. This can be done by clicking on each server and checking that the button below shows “Inhibit Replication”, and NOT “Allow Replication”.</p> 


Procedure 1: Recovery Scenario 1

56	NOAM VIP GUI: Set HA on Standby SOAM	Navigate to Status & Manage -> HA  Click on Edit at the bottom of the screen Select the standby SOAM server, set it to Active Press OK
57	SOAM VIP GUI: Perform Keyexchange with Export Server	Navigate to Main Menu -> Administration -> Remote Servers -> Data Export  Click on SSH Key Exchange at the bottom of the screen Enter the Password and press OK 
58	(PCA Only) Activate PCA Feature	If you are installing PCA, execute the applicable procedures (Added SOAM site activation or complete system activation) within Appendix A of [7] to activate PCA. Note: If not all SOAM sites are ready at this point, then you should repeat activation for each *new* SOAM site that comes online.


Procedure 1: Recovery Scenario 1

59	<p>NOAM VIP GUI: Recover the C-Level Server (DA-MPs, SBRs, IPFE, SS7-MP, and SDS DPs)</p>	<p>Recovery C-Level Servers:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the MP Servers</i>”, Steps 1, 9-12, 14 from reference [8]</p> <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 13</p> <p>Note: Execute steps 15-17 if you plan to configure a default route on your MP that uses a signaling (XSI) network instead of the XMI network.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the SDS DP Servers</i>”, Steps 1, 6-7, 9 from reference [8]</p> <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 8</p> <p>Repeat this step for any remaining failed MP servers.</p>
60	<p>NOAM VIP GUI: Restart DSR Application on recovered C-Level Servers.</p>	<p>Navigate to Main Menu->Status & Manage->Server</p>  <p>Select the recovered C-Level servers and click on Restart.</p> 



Procedure 1: Recovery Scenario 1

<p>61</p> <p><input type="checkbox"/> NOAM VIP GUI: Start replication on all C-Level Servers (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Un-Inhibit (<i>Start</i>) Replication to the ALL C-Level Servers</p> <p>Navigate to Status & Manage -> Database</p>  <p>If the “<i>Rep/ Status</i>” is set to “Inhibited”, click on the Allow Replication button as shown below using the following order:</p> <ul style="list-style-type: none"> • Active NOAM Server • Standby NOAM Server • Active SOAM Server • Standby SOAM Server • Spare SOAM Server (<i>if applicable</i>)-Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only • Active DR NOAM Server • Standby DR NOAM Server • MP/IPFE Servers • SBRs (<i>if SBR servers are configured, start with the active SBR, then standby, then spare</i>) –Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only <p>Verify that the replication on all servers is allowed. This can be done by clicking on each server and checking that the button below shows “Inhibit Replication”, and NOT “Allow Replication”.</p> 
---	--

Procedure 1: Recovery Scenario 1

62	NOAM VIP GUI: Set HA on all C-Level Servers	Navigate to Status & Manage -> HA  Click on Edit at the bottom of the screen For each server whose Max Allowed HA Role is set to Standby, set it to Active Press OK
63	ACTIVE NOAM: Perform key exchange between the active-NOAM and recovered servers.	Establish an SSH session to the Active NOAM, login as admusr . Execute the following command to perform a keyexchange from the active NOAM to each recovered server: <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <code>\$ keyexchange admusr@<Recovered Server Hostname></code> </div>
64	ACTIVE NOAM: Activate Optional Features	Establish an SSH session to the active NOAM, login as admusr . Refer to Section 1.5 Optional Features to activate any features that were previously activated.


Procedure 1: Recovery Scenario 1

65	<p><input type="checkbox"/> NOAM VIP GUI: Fetch and Store the database Report for the Newly Restored Data and Save it</p>	<p>Navigate to Main Menu -> Status & Manage -> Database</p>  <p>Select the active NOAM server and click on the Report button at the bottom of the page. The following screen is displayed:</p> <p>Main Menu: Status & Manage -> Database [Report]</p>  <p>Click on Save and save the report to your local machine.</p>
----	--	--



Procedure 1: Recovery Scenario 1

<p>66</p> <p><input type="checkbox"/> ACTIVE NOAM: Verify Replication Between Servers.</p>	<p>Login to the Active NOAM via SSH terminal as admusr.</p> <p>Execute the following command:</p> <pre>\$ sudo irepstat -m</pre> <p>Output like below shall be generated:</p> <pre>-- Policy 0 ActStb [DbReplication] ----- ----- Oahu-DAMP-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.15%cpu 25B/s A=me CC To Oahu-DAMP-2 Active 0 0.10 0.14%cpu 25B/s A=me Oahu-DAMP-2 -- Stby BC From Oahu-SOAM-2 Active 0 0.50 ^0.11%cpu 31B/s A=C3642.212 CC From Oahu-DAMP-1 Active 0 0.10 ^0.14 1.16%cpu 31B/s A=C3642.212 Oahu-IPFE-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 24B/s A=C3642.212 Oahu-IPFE-2 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 28B/s A=C3642.212 Oahu-NOAM-1 -- Stby AA From Oahu-NOAM-2 Active 0 0.25 ^0.03%cpu 23B/s Oahu-NOAM-2 -- Active AA To Oahu-NOAM-1 Active 0 0.25 1%R 0.04%cpu 61B/s AB To Oahu-SOAM-2 Active 0 0.50 1%R 0.05%cpu 75B/s Oahu-SOAM-1 -- Stby BB From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 27B/s Oahu-SOAM-2 -- Active AB From Oahu-NOAM-2 Active 0 0.50 ^0.03%cpu 24B/s BB To Oahu-SOAM-1 Active 0 0.50 1%R 0.04%cpu 32B/s BC To Oahu-IPFE-1 Active 0 0.50 1%R 0.04%cpu 21B/s BC To Oahu-SS7MP-2 Active 0 0.50 1%R 0.04%cpu 21B/s irepstat (40 lines) (h)elp (m)erged</pre>
---	---

Procedure 1: Recovery Scenario 1

67	NOAM VIP GUI: <input type="checkbox"/> Verify the Database states	<p>Click on Main Menu->Status and Manager->Database</p>  <p>Verify that the “OAM Max HA Role” is either “Active” or “Standby” for NOAM and SOAM and “Application Max HA Role” for MPs is “Active”, and that the status is “Normal” as shown below:</p> <table border="1" data-bbox="502 720 1351 910"> <thead> <tr> <th>Network Element</th><th>Server</th><th>Role</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Status</th><th>DB Level</th><th>OAM Repl Status</th><th>SIG Repl Status</th><th>Repl Status</th><th>Repl Audit Status</th></tr> </thead> <tbody> <tr> <td>NO_10303</td><td>NO2</td><td>Network OAM&P</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>PSBR</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>MP2</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO1</td><td>System OAM</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>NO_10303</td><td>NO1</td><td>Network OAM&P</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>IPFE</td><td>MP</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO2</td><td>System OAM</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> </tbody> </table>	Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status	NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg
Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status																																																																																
NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																

Procedure 1: Recovery Scenario 1

68	<p>NOAM VIP GUI: <input type="checkbox"/> Upload the backed up RADIUS Key file (RADIUS Only)</p> <p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Navigate to Main Menu->Status & Manage->Files</p> <p>Select the Active NOAM server. The following screen will appear. Click on Upload as shown below and select the file “<i>RADIUS shared secret encryption key:</i>” file backed up after initial installation and provisioning or after key revocation execution.</p>  <p>Click on Browse and Locate the DpiKf.bin.encr file and click on Open as shown below.</p>  <p>Click on the Upload button. The file will take a few seconds to upload depending on the size of the file. The file will be visible on the list of entries after the upload is complete.</p> <p>Note: This file should be deleted from the operator's local servers as soon as key file is uploaded to Active NOAM server.</p>
----	--



Procedure 1: Recovery Scenario 1

69 <input type="checkbox"/>	<p>NOAM VIP: Copy and distribute RADIUS Key file on Active NOAM (RADIUS Only)- Part 1</p> <p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Login to the Active NOAM VIP via SSH terminal as admusr user.</p> <p>Execute the following commands to copy the key file:</p> <div data-bbox="502 566 1354 756" style="border: 1px solid black; padding: 10px;"><pre>\$ cd /usr/TKLC/dpi/bin \$./sharedKrevo -decr \$ sudo rm /var/TKLC/db/filemgmt/<backed up key file name></pre></div> <p>Execute following command to check if all the servers in topology are accessible:</p> <div data-bbox="502 994 1354 1410" style="border: 1px solid black; padding: 10px;"><pre>\$./sharedKrevo -checkAccess [admusr@NOAM-2 bin]\$./sharedKrevo -checkAccess FIPS integrity verification test failed. 1450723084: [INFO] 'NOAM-1' is accessible. FIPS integrity verification test failed. 1450723084: [INFO] 'SOAM-1' is accessible. FIPS integrity verification test failed. 1450723085: [INFO] 'SOAM-2' is accessible. FIPS integrity verification test failed. 1450723085: [INFO] 'IPFE' is accessible. FIPS integrity verification test failed. 1450723085: [INFO] 'MP-2' is accessible.</pre></div> <p>Note: If all the servers are not accessible, contact My Oracle Support (MOS)</p>
--------------------------------	---




Procedure 1: Recovery Scenario 1

70	<p><input type="checkbox"/> NOAM VIP: Copy and distribute RADIUS Key file on Active NOAM (RADIUS Only)- Part 2</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Execute following command to distribute key file to all the servers in the topology :</p> <div data-bbox="502 496 1411 1298" style="border: 1px solid black; padding: 10px;"><pre>\$./sharedKrevo -synchronize \$./sharedKrevo -updateData Example output: 1450723210: [INFO] Key file on Active NOAM and IPFE are same. 1450723210: [INFO] NO NEED to sync key file to IPFE. FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723210: [INFO] Key file on Active NOAM and MP-2 are same. 1450723210: [INFO] NO NEED to sync key file to MP-2. FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723211: [INFO] Key file on Active NOAM and MP-1 are same. 1450723211: [INFO] NO NEED to sync key file to MP-1. [admusr@NOAM-2 bin]\$./sharedKrevo -updateData 1450723226: [INFO] Updating data on server 'NOAM-2' 1450723227: [INFO] Data updated to 'NOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723228: [INFO] Updating data on server 'SOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723230: [INFO] 1 rows updated on 'SOAM-2'... 1450723230: [INFO] Data updated to 'SOAM-2' [admusr@NOAM-2 bin]\$</pre></div> <p>Note: For any errors contact My Oracle Support (MOS)</p>
----	---	---


Procedure 1: Recovery Scenario 1

71	NOAM VIP GUI: <input type="checkbox"/> Verify the HA Status	<p>Click on Main Menu->Status and Manage->HA</p>  <p>Select the row for all of the servers Verify that the “HA Role” is either “Active” or “Standby”.</p> <table border="1" data-bbox="502 720 1372 882"> <thead> <tr> <th>Hostname</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Max Allowed HA Role</th><th>Mate Hostname List</th><th>Network Element</th><th>Server Role</th><th>Active VIPs</th></tr> </thead> <tbody> <tr> <td>NO2</td><td>Active</td><td>OOS</td><td>Active</td><td>NO1</td><td>NO_10303</td><td>Network OAM&P</td><td>10.240.70.132</td></tr> <tr> <td>SO1</td><td>Standby</td><td>OOS</td><td>Active</td><td>SO2</td><td>SO_10303</td><td>System OAM</td><td></td></tr> <tr> <td>SO2</td><td>Active</td><td>OOS</td><td>Active</td><td>SO1</td><td>SO_10303</td><td>System OAM</td><td>10.240.70.133</td></tr> <tr> <td>MP1</td><td>Standby</td><td>Active</td><td>Active</td><td>MP2</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>MP2</td><td>Active</td><td>Active</td><td>Active</td><td>MP1</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>IPFE</td><td>Active</td><td>OOS</td><td>Active</td><td></td><td>SO_10303</td><td>MP</td><td></td></tr> </tbody> </table>	Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs	NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132	SO1	Standby	OOS	Active	SO2	SO_10303	System OAM		SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133	MP1	Standby	Active	Active	MP2	SO_10303	MP		MP2	Active	Active	Active	MP1	SO_10303	MP		IPFE	Active	OOS	Active		SO_10303	MP	
Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs																																																			
NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132																																																			
SO1	Standby	OOS	Active	SO2	SO_10303	System OAM																																																				
SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133																																																			
MP1	Standby	Active	Active	MP2	SO_10303	MP																																																				
MP2	Active	Active	Active	MP1	SO_10303	MP																																																				
IPFE	Active	OOS	Active		SO_10303	MP																																																				
72	NOAM GUI: <input type="checkbox"/> Enable Provisioning	<p>Click on Main Menu->Status & Manage->Database</p>  <p>Enable Provisioning by clicking on Enable Provisioning button at the bottom of the screen as shown below.</p> <p><input type="button" value="Enable Provisioning"/> <input type="button" value="Report"/> <input type="button" value="Inhibit/Allow Replication"/> <input type="button" value="Backup..."/> <input type="button" value="Compare..."/> <input type="button" value="Restore..."/> <input type="button" value="Man Audit"/> <input type="button" value="Suspend Auto Audit"/></p> <p>A confirmation window will appear, press OK to enable Provisioning.</p> <p>Enable provisioning. Are you sure?</p> <p><input type="button" value="OK"/> <input type="button" value="Cancel"/></p>																																																								


Procedure 1: Recovery Scenario 1

73	SOAM GUI: Enable Provisioning	<p>Click on Main Menu->Status & Manage->Database</p>  <p>Enable Provisioning by clicking on Enable Provisioning button at the bottom of the screen as shown below.</p>  <p>A confirmation window will appear, press OK to enable Provisioning.</p> 
74	SOAM VIP GUI: Verify the Local Node Info (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Local Node</p>  <p>Verify that all the local nodes are shown.</p>



Procedure 1: Recovery Scenario 1

75	<p>SOAM VIP GUI: Verify the Peer Node Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Peer Node</p>  <p>Verify that all the peer nodes are shown.</p>
----	--	--




Procedure 1: Recovery Scenario 1

76	<p>SOAM VIP GUI: <input type="checkbox"/> Verify the Connections Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Connections</p>  <p>Verify that all the connections are shown.</p>
77	<p>MP Servers: <input type="checkbox"/> Disable SCTP Auth Flag (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>For SCTP connections without DTLS enabled, refer to Enable/Disable DTLS Appendix from reference [8]</p> <p>Execute this procedure on all Failed MP Servers.</p>



Procedure 1: Recovery Scenario 1

78	<p>SOAM VIP GUI: Enable Connections if needed (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Maintenance->Connections</p>  <p>Select each connection and click on the Enable button. Alternatively you can enable all the connections by selecting the EnableAll button.</p> <p>Enable Disable EnableAll DisableAll Diagnose Start Diagnose End SCTP STATISTICS <input type="checkbox"/> Pause updates</p> <p>Verify that the Operational State is Available.</p> <p>Note: If a Disaster Recovery was performed on an IPFE server, it may be necessary to disable and re-enable the connections to ensure proper link distribution</p>
79	<p>SOAM VIP GUI: Enable Optional Features (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu -> Diameter -> Maintenance -> Applications</p>  <p>Select the optional feature application configured in step 65.</p> <p>Click the Enable button.</p> <p>Enable Disable <input type="checkbox"/> Pause updates</p>

Procedure 1: Recovery Scenario 1

80	SOAM VIP GUI: <input type="checkbox"/> Re-enable Transports if Needed (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Transport Manager -> Maintenance -> Transport</p>  <p>Select each transport and click on the Enable button</p>  <p>Verify that the Operational Status for each transport is Up.</p>
81	SOAM VIP GUI: <input type="checkbox"/> Re-enable MAPIWF application if needed(DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Local SCCP Users</p>  <p>Click on the Enable button corresponding to MAPIWF Application Name.</p>  <p>Verify that the SSN Status is Enabled.</p>

Procedure 1: Recovery Scenario 1

<p>82</p> <input type="checkbox"/>	<p>SOAM VIP GUI: Re-enable links if needed (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Links</p> 
<p>83</p> <input type="checkbox"/>	<p>SOAM VIP GUI: Examine All Alarms</p>	<p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>
<p>84</p> <input type="checkbox"/>	<p>NOAM VIP GUI: Examine All Alarms</p>	<p>Login to the NOAM VIP if not already logged in.</p> <p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>
<p>85</p> <input type="checkbox"/>	<p>Restore GUI Usernames and Passwords</p>	<p>If applicable, Execute steps in Section 6.0 to recover the user and group information restored.</p>

Procedure 1: Recovery Scenario 1

86	<input type="checkbox"/> Backup and Archive All the Databases from the Recovered System	Execute Appendix A to back up the Configuration databases:
87	<input type="checkbox"/> Recover IDIH (If Configured)	If any components of IDIH were affected, refer to Section 7.0 to perform the disaster recovery on IDIH.

5.1.2 Recovery Scenario 2 (Partial Server Outage with at least one NOAM server intact and all SOAMs failed)

For a partial server outage with an NOAM server intact and available; SOAM servers are recovered using recovery procedures of base hardware and software and then executing a database restore to the active SOAM server using a database backup file obtained from the SOAM servers. All other servers are recovered using recovery procedures of base hardware and software. Database replication from the active NOAM server will recover the database on these servers. The major activities are summarized in the list below. Use this list to understand the recovery procedure summary. Do not use this list to execute the procedure. The actual procedures' detailed steps are in **Procedure 2**. The major activities are summarized as follows:

Recover **Standby NOAM** server (*if needed*) by recovering base hardware, software and the database.

- Recover the base hardware.
- Recover the software.

Recover **Active SOAM** server by recovering base hardware and software.


- Recover the base hardware.
- Recover the software.
- Recover the Database.

Recover any failed **SOAM and MP/DP** servers by recovering base hardware and software.


- Recover the base hardware.
- Recover the software.
- The database has already been restored at the active SOAM server and does not require restoration at the SO and MP/DP servers.

Recover IDIH if necessary

Procedure 2: Recovery Scenario 2

S T E P #	<p>This procedure performs recovery if at least 1 NOAM server is available but all SOAM servers in a site have failed. This includes any SOAM server that is in another location.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Workarounds	Refer to Appendix I to understand any workarounds required during this procedure.
2 <input type="checkbox"/>	Gather Required Materials	Gather the documents and required materials listed in Section 3.1 .
3 <input type="checkbox"/>	NOAM VIP GUI: Login	<p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> http://<Primary_NOAM_VIP_IP_Address> </div> <p>Login as the guiadmin user:</p>  <p>Fri Mar 20 12:29:52 2015 EDT</p> <p>Log In Enter your username and password to log in</p> <p>Username: <input type="text" value="guiadmin"/> Password: <input type="password" value="*****"/> <input type="checkbox"/> Change password <input type="button" value="Log In"/></p> <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</p>

Procedure 2: Recovery Scenario 2

4 <input type="checkbox"/>	Active NOAM: Set Failed Servers to Standby	Navigate to Main Menu -> Status & Manage -> HA  Select Edit Set the Max Allowed HA Role drop down box to Standby for the failed servers. Select Ok 
5 <input type="checkbox"/>	Replace Failed Equipment	HW vendor to replace the failed equipment
6 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Configure BIOS Settings and Update Firmware	1. Configure and verify the BIOS settings by executing procedure <i>“Configure the HP/Oracle RMS BIOS settings”</i> from reference [8] 2. Verify and/or upgrade server firmware by executing procedure <i>“Upgrade Rack Mount Server Firmware”</i> from reference [8]
7 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Backup Available	<p>If the PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 10.</p> <p>This step assumes that TVOE and PMAC backups are available, if backups are NOT available, skip this step.</p> <ol style="list-style-type: none"> 1. Restore the TVOE backup by executing Appendix G on ALL failed rack mount servers 2. Restore the PMAC backup by executing Appendix H <p style="text-align: center;">Proceed to Step 10</p>

Procedure 2: Recovery Scenario 2

8	Recover PMAC and PMAC <input type="checkbox"/> TVOE Host: Backup Not Available	If the PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 10.
		This step assumes that TVOE and PMAC backups are NOT available, if the TVOE and PMAC have already been restored, skip this step
		<ol style="list-style-type: none"> 1. Execute procedure <i>"Install and Configure TVOE on First RMS (PMAC Host)"</i> from reference [8] 2. Execute section <i>"Install PMAC"</i> from reference [8]
		Proceed to Next Step
9	<input type="checkbox"/> Configure PMAC (No Backup)	If PMAC backup was NOT restored in step 5, execute this step. Otherwise Skip this Step .
		Execute sections <i>"Configure PMAC Server"</i> and <i>"Add Cabinet to PMAC"</i> from reference [8]
10	<input type="checkbox"/> Install/Configure Additional Rack Mount Servers	If TVOE backups were NOT performed on any additional rack mount servers or are not available, execute this step. Otherwise Skip this Step
		<ol style="list-style-type: none"> 5. Oracle X5-2/Netra X5-2/ HP DL380 GEN 8: Execute procedure <i>"Install TVOE on Additional Rack Mount Servers"</i> from reference [8] 6. HP DL380 GEN 9: Execute procedure <i>"Install and Configure TVOE on First RMS"</i> from reference [8] 7. Execute <i>"Configure TVOE on Additional Rack Mount Servers"</i> from reference [8] 8. Configure and verify the BIOS/NEB settings by executing procedure <i>"Configure Oracle X5-2/Netra X5-2 Server"</i> from reference [8]
11	<input type="checkbox"/> Determine VM Placement and Socket Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)	FOR Oracle X5-2/Netra X5-2/HP DL380 GEN 9 ONLY, HP DL380 GEN 8 SKIP THIS STEP
		Refer to the DSR VM placement and Pinning workbook to determine proper VM placement and pinning.
12	<input type="checkbox"/> Deploy Redundant PMAC	If the redundant PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 13.
		Refer to procedure <i>"Deploy Redundant PMAC (Optional)"</i> to re-deploy and configure any redundant PMACs previously configured.
13	<input type="checkbox"/> Create Virtual Machines For Applications	Execute section <i>"Create Virtual Machines for Applications"</i> from reference [8]
14	<input type="checkbox"/> Perform CPU Pinning	Configure VM CPU socket pinning on each TVOE host to optimize performance by executing procedure <i>"CPU Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)"</i> from reference [8]



Procedure 2: Recovery Scenario 2

15 <input type="checkbox"/>	Install Software on Virtual Machines	Execute section “ <i>Install Software on Virtual Machines</i> ” from reference [8]
16 <input type="checkbox"/>	NOAM VIP GUI: Login	<p>If the failed server(s) are NOT OAM type, skip to step 37</p> <p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; display: inline-block;"><code>http://<Primary_NOAM_VIP_IP_Address></code></div> <p>Login as the guiadmin user:</p>  <p>Oracle System Login</p> <p>Fri Mar 20 12:29:52 2015 EDT</p> <p>Log In Enter your username and password to log in</p> <p>Username: <input type="text" value="guiadmin"/> Password: <input type="password" value="*****"/></p> <p><input type="checkbox"/> Change password</p> <p>Log In</p> <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>

Procedure 2: Recovery Scenario 2



17 <input type="checkbox"/>	<p>NOAM VIP GUI: Recover Standby NOAM</p>	<p>Install the second NOAM server:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the Second NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8].</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the Second SDS NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8]</p>
18 <input type="checkbox"/>	<p>Active NOAM: Correct the RecognizedAuthority table</p>	<p>Establish an SSH session to the active NOAM, login as admusr.</p> <p>Execute the following command:</p> <div style="border: 1px solid black; padding: 5px;"> <pre>\$ sudo top.setPrimary - Using my cluster: A1789 - New Primary Timestamp: 11/09/15 20:21:43.418 - Updating A1789.022: <DSR_NOAM_B_hostname> - Updating A1789.144: <DSR_NOAM_A_hostname></pre> </div>

Procedure 2: Recovery Scenario 2



19	NOAM VIP GUI: Restart DSR application	Navigate to Main Menu->Status & Manage->Server ,  Select the recovered standby NOAM server and click on Restart . 
20	NOAM VIP GUI: Set HA on Standby NOAM	Navigate to Status & Manage -> HA  Click on Edit at the bottom of the screen Select the standby NOAM server, set it to Active Press OK

Procedure 2: Recovery Scenario 2

Procedure 2: Recovery Scenario 2

23	NOAM VIP GUI: Set HA on SOAM Server	Navigate to Status & Manage -> HA  Click on Edit at the bottom of the screen Select the SOAM server, set it to Active Press OK
24	NOAM VIP GUI: Restart DSR application	Navigate to Main Menu->Status & Manage->Server ,  Select the recovered SOAM server and click on Restart . 

Procedure 2: Recovery Scenario 2

25	<p>NOAM VIP GUI: Upload the backed up SOAM Database file (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Browse to Main Menu->Status & Manage->Files</p>  <p>Select the Active SOAM server. The following screen will appear:</p>  <p>Click on Upload as shown below and select the file “<i>NO Provisioning and Configuration:</i>” file backed up after initial installation and provisioning.</p>  <p>1. Click on Browse and locate the backup file 2. Check This is a backup file Box 3. Click on Open as shown below.</p>  <p>Click on the Upload button. The file will take a few seconds to upload depending on the size of the backup data. The file will be visible on the list of entries after the upload is complete.</p>
----	--	---



Procedure 2: Recovery Scenario 2

26	<p>Recovered SOAM GUI: <input type="checkbox"/> Login (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Establish a GUI session on the recovered SOAM server. Open the web browser and enter a URL of:</p> <p>http://<Recovered_SOAM_IP_Address></p> <p>Login as the guiadmin user:</p>
----	---	--

Procedure 2: Recovery Scenario 2

27	<p>Recovered SOAM GUI: <input type="checkbox"/> Verify the Archive Contents and Database Compatibility (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Click on Main Menu->Status & Manage->Database</p> <p>Select the Active SOAM server and click on the Compare.</p> <p style="text-align: center;"> <input type="button" value="Enable Provisioning"/> <input type="button" value="Report"/> <input type="button" value="Inhibit Replication"/> <input type="button" value="Backup..."/> <input type="button" value="Compare..."/> <input type="button" value="Restore..."/> <input type="button" value="Man Audit"/> <input type="button" value="Suspend Auto Audit"/> </p> <p>The following screen is displayed; click the button for the restored database file that was uploaded as a part of Step 24 of this procedure.</p> <p>Main Menu: Status & Manage -> Database [Compare]</p> <p>Database Compare</p> <p>Select archive to compare on server: Corvette-SO-B</p> <p> <input type="checkbox"/> backup/Backup.dsr.Corvette-SO-B Configuration SYSTEM_OAM.20190409_021502.AUTO.tar <input type="checkbox"/> backup/Backup.dsr.Corvette-SO-B Configuration SYSTEM_OAM.20190410_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsr.Corvette-SO-B Configuration SYSTEM_OAM.20190411_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsr.Corvette-SO-B Configuration SYSTEM_OAM.20190412_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsr.Corvette-SO-B Configuration SYSTEM_OAM.20190413_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsr.Corvette-SO-B Configuration SYSTEM_OAM.20190414_021501.AUTO.tar </p> <p style="text-align: right;"> <input type="button" value="OK"/> <input type="button" value="Cancel"/> </p> <p>Verify that the output window matches the screen below.</p> <p>Note: You will get a database mismatch regarding the NodeID. That is expected. If that is the only mismatch, proceed, otherwise stop and contact My Oracle Support (MOS)</p> <p>Output Window:</p> <pre> • The selected database came from blade07 on 01/19/2011 at 13:43:47 EDT and contains the following comment . . . • Archive Contents • ProvisioningAndConfiguration data • Database Compatibility • The databases are compatible • Node Type Compatibility • The node types are compatible • Topology Compatibility • THE TOPOLOGY IS NOT COMPATIBLE. CONTACT TELELEC CUSTOMER SERVICES BEFORE RESTORING THIS DATABASE. Description: - IMI Server Address A3118.120 has different <code>Node ID</code> in current topology and the selected backup file. Current node ID: A3118.120 Selected backup file node ID: B2073.087 - IMI Server Address C1157.241 has different <code>Node ID</code> in current topology and the selected backup file. Current node ID: C1157.241 Selected backup file node ID: B1787.161 - IMI Server Address B1787.161 has different <code>Node ID</code> in current topology and the selected backup file. Current node ID: B1787.161 Selected backup file node ID: B2073.087 . • User Compatibility • The user and authentication data are compatible. • Contexts • ProvisioningAndConfiguration • Table Instance Count • Current ASGroup count: 0 Selected: 0 • Current AdaccesServers count: 0 Selected: 0 • Current Association count: 0 Selected: 0 • Current AssociationCountSet count: 1 Selected: 1 • Current Adapters count: 2 Selected: 6 • Current Admorthads count: 1 Selected: 1 </pre> <p>Note: Archive Contents and Database Compatibilities must be the following:</p> <p>Archive Contents: Configuration data</p> <p>Database Compatibility: The databases are compatible.</p> <p>Note: The following is expected Output for Topology Compatibility Check since we are restoring from existing backed up data base to database with just one SOAM:</p> <p>Topology Compatibility</p> <p>THE TOPOLOGY SHOULD BE COMPATIBLE MINUS THE NODEID.</p> <p>Note: We are trying to restore a backed up database onto an empty SOAM database. This is an expected text in Topology Compatibility.</p> <p>If the verification is successful, Click BACK button and continue to next step in this procedure.</p>
Page	73	E56227-03



Procedure 2: Recovery Scenario 2

28	Recovered SOAM GUI: <input type="checkbox"/> Restore the Database (DSR Only)	DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step
		<p>Select the Active SOAM server, and click on Restore as shown below.</p> <p>The following screen will be displayed. Select the proper back up provisioning and configuration file.</p> <p>Main Menu: Status & Manage -> Database [Restore]</p>  <p>Click OK Button. The following confirmation screen will be displayed.</p> <p>If you get an error that the NodeIDs do not match. That is expected. If no other errors beside the NodeIDs are displayed, select the Force checkbox as shown above and Click OK to proceed with the DB restore.</p>  <p>Note: After the restore has started, the user will be logged out of XMI SOAM GUI since the restored Topology is old data.</p>
29	Recovered SOAM GUI: <input type="checkbox"/> Monitor and Confirm database restoral (DSR Only)	DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step
		<p>Wait for 5-10 minutes for the System to stabilize with the new topology:</p> <p>Monitor the Info tab for “Success”. This will indicate that the restore is complete and the system is stabilized.</p> <p>Note: Do not pay attention to alarms until all the servers in the system are completely restored.</p> <p>Note: The Configuration and Maintenance information will be in the same state it was backed up during initial backup.</p>


Procedure 2: Recovery Scenario 2

30	NOAM VIP GUI: <input type="checkbox"/> Login	<p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">http://<Primary_NOAM_VIP_IP_Address></div> <p>Login as the guiadmin user:</p>
31	NOAM VIP GUI: <input type="checkbox"/> Recover the Remaining SOAM Servers	<p>Recover the remaining SOAM servers (Standby, Spare-Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only) by DSR:</p> <p>Execute procedure “<i>Configure the SOAM Servers</i>”, steps 1-3, and 5-8, 10 from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p> <p>Note: If you are using NetBackup, also execute step 12.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the SDS SOAM Servers</i>”, steps 1-3, and 5-8, 9-10 from reference [8]</p>


Procedure 2: Recovery Scenario 2

32	NOAM VIP GUI: Restart DSR application	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered standby SOAM server and click on Restart.</p> 
33	NOAM VIP GUI: Start Replication on Working C-Level Servers (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Un-Inhibit (<i>Start</i>) Replication to the working C-Level Servers which belongs to the same site as of the failed SOAM servers.</p> <p>Execute Appendix F</p> <p>If the “<i>Rep/ Status</i>” is set to “Inhibited”, click on the Allow Replication button as shown below using the following order, otherwise if none of the servers are inhibited, skip this step and continue with the next step:</p> <ul style="list-style-type: none"> • Active NOAM Server • Standby NOAM Server • Active SOAM Server • Standby SOAM Server • Spare SOAM Server (<i>if applicable</i>) –Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only • Active DR NOAM Server • Standby DR NOAM Server • MP/IPFE Servers • SBRs (<i>if SBR servers are configured, start with the active SBR, then standby, then spare</i>) –Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only <p>Verify that the replication on all the working servers is allowed. This can be done by clicking on each server and checking that the button below shows “Inhibit Replication”, and NOT “Allow Replication”.</p> 


Procedure 2: Recovery Scenario 2

34	NOAM VIP GUI: Set HA on Standby SOAM	Navigate to Status & Manage -> HA  <p>Click on Edit at the bottom of the screen Select the standby SOAM server, set it to Active Press OK</p>
35	(PCA Only) Activate PCA Feature	If you are installing PCA, execute the applicable procedures (Added SOAM site activation or complete system activation) within Appendix A of [7] to activate PCA. <p>Note: If not all SOAM sites are ready at this point, then you should repeat activation for each *new* SOAM site that comes online.</p>
36	NOAM VIP GUI: Recover the C-Level Server (DA-MPs, SBRs, IPFE, SS7-MP, and SDS DPs)	Recover C-Level Servers: <p>DSR:</p> Execute procedure <i>“Configure the MP Servers”</i> , Steps 1, 9-12, 14 from reference [8] <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 13</p> <p>Note: Execute steps 15-17 if you plan to configure a default route on your MP that uses a signaling (XSI) network instead of the XMI network.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> Execute procedure <i>“Configure the SDS DP Servers”</i> , Steps 1, 6-7, 9 from reference [8] <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 8</p> <p>Repeat this step for any remaining failed MP/DP servers.</p>


Procedure 2: Recovery Scenario 2

37	NOAM VIP GUI:	Navigate to Main Menu->Status & Manage->Server
	<input type="checkbox"/> Restart DSR <input type="checkbox"/> Application on recovered C-Level Servers.	 <p>Select the recovered C-Level servers and click on Restart.</p> <p>Stop Restart Reboot NTP Sync Report</p>



Procedure 2: Recovery Scenario 2

38	NOAM VIP GUI: <input type="checkbox"/> Start replication on all C-Level Servers (DSR Only)	DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step
		<p>Un-Inhibit (<i>Start</i>) Replication to the ALL C-Level Servers</p> <p>Navigate to Status & Manage -> Database</p>  <p>If the “<i>Rep/ Status</i>” is set to “Inhibited”, click on the Allow Replication button as shown below using the following order:</p> <ul style="list-style-type: none"> • Active NOAM Server • Standby NOAM Server • Active SOAM Server • Standby SOAM Server • Spare SOAM Server (<i>if applicable</i>) - Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only • Active DR NOAM Server • Standby DR NOAM Server • MP/IPFE Servers • SBRs (<i>if SBR servers are configured, start with the active SBR, then standby, then spare</i>) - Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only <p>Verify that the replication on all servers is allowed. This can be done by clicking on each server and checking that the button below shows “Inhibit Replication”, and NOT “Allow Replication”.</p> 

Procedure 2: Recovery Scenario 2

39	NOAM VIP GUI: Set HA on all C-Level Servers	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>For each server whose Max Allowed HA Role is set to Standby, set it to Active</p> <p>Press OK</p>
40	ACTIVE NOAM: Perform key exchange between the active-NOAM and recovered servers.	<p>Establish an SSH session to the Active NOAM, login as admusr.</p> <p>Execute the following command to perform a keyexchange from the active NOAM to each recovered server:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ keyexchange admusr@<Recovered Server Hostname></pre> </div> <p>Note: If an export server is configured, perform this step.</p>
41	ACTIVE NOAM: Activate Optional Features	<p>Establish an SSH session to the active NOAM, login as admusr.</p> <p>Refer to Section 1.5 Optional Features to activate any features that were previously activated.</p> <p>Note: While running the activation script, the following error message (and corresponding messages) output may be seen, this can safely be ignored:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>iload#31000{S/W Fault}</pre> </div>



Procedure 2: Recovery Scenario 2

42	<p><input type="checkbox"/> NOAM VIP GUI: Fetch and Store the database Report for the Newly Restored Data and Save it</p>	<p>Navigate to Main Menu -> Status & Manage -> Database</p>  <p>Select the active NOAM server and click on the Report button at the bottom of the page. The following screen is displayed:</p> <p>Main Menu: Status & Manage -> Database [Report]</p>  <p>Click on Save and save the report to your local machine.</p>
----	--	--



Procedure 2: Recovery Scenario 2

<p>43</p> <input type="checkbox"/>	<p>ACTIVE NOAM: Verify Replication Between Servers.</p>	<p>Login to the Active NOAM via SSH terminal as admusr.</p> <p>Execute the following command:</p> <pre>\$ sudo irepstat -m</pre> <p>Output like below shall be generated:</p> <pre>-- Policy 0 ActStb [DbReplication] ----- ----- Oahu-DAMP-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.15%cpu 25B/s A=me CC To Oahu-DAMP-2 Active 0 0.10 0.14%cpu 25B/s A=me Oahu-DAMP-2 -- Stby BC From Oahu-SOAM-2 Active 0 0.50 ^0.11%cpu 31B/s A=C3642.212 CC From Oahu-DAMP-1 Active 0 0.10 ^0.14 1.16%cpu 31B/s A=C3642.212 Oahu-IPFE-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 24B/s A=C3642.212 Oahu-IPFE-2 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 28B/s A=C3642.212 Oahu-NOAM-1 -- Stby AA From Oahu-NOAM-2 Active 0 0.25 ^0.03%cpu 23B/s Oahu-NOAM-2 -- Active AA To Oahu-NOAM-1 Active 0 0.25 1%R 0.04%cpu 61B/s AB To Oahu-SOAM-2 Active 0 0.50 1%R 0.05%cpu 75B/s Oahu-SOAM-1 -- Stby BB From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 27B/s Oahu-SOAM-2 -- Active AB From Oahu-NOAM-2 Active 0 0.50 ^0.03%cpu 24B/s BB To Oahu-SOAM-1 Active 0 0.50 1%R 0.04%cpu 32B/s BC To Oahu-IPFE-1 Active 0 0.50 1%R 0.04%cpu 21B/s BC To Oahu-SS7MP-2 Active 0 0.50 1%R 0.04%cpu 21B/s irepstat (40 lines) (h)elp (m)erged</pre>
------------------------------------	--	---


Procedure 2: Recovery Scenario 2

44	NOAM VIP GUI: <input type="checkbox"/> Verify the Database states	<p>Click on Main Menu->Status and Manager->Database</p>  <p>Verify that the “OAM Max HA Role” is either “Active” or “Standby” for NOAM and SOAM and “Application Max HA Role” for MPs is “Active”, and that the status is “Normal” as shown below:</p> <table border="1"> <thead> <tr> <th>Network Element</th><th>Server</th><th>Role</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Status</th><th>DB Level</th><th>OAM Repl Status</th><th>SIG Repl Status</th><th>Repl Status</th><th>Repl Audit Status</th></tr> </thead> <tbody> <tr> <td>NO_10303</td><td>NO2</td><td>Network OAM&P</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>PSBR</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>MP2</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO1</td><td>System OAM</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>NO_10303</td><td>NO1</td><td>Network OAM&P</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>IPFE</td><td>MP</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO2</td><td>System OAM</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> </tbody> </table>	Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status	NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg
Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status																																																																																
NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
45	NOAM VIP GUI: <input type="checkbox"/> Verify the HA Status	<p>Click on Main Menu->Status and Manager->HA</p>  <p>Select the row for all of the servers Verify that the “HA Role” is either “Active” or “Standby”.</p> <table border="1"> <thead> <tr> <th>Hostname</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Max Allowed HA Role</th><th>Mate Hostname List</th><th>Network Element</th><th>Server Role</th><th>Active VIPs</th></tr> </thead> <tbody> <tr> <td>NO2</td><td>Active</td><td>OOS</td><td>Active</td><td>NO1</td><td>NO_10303</td><td>Network OAM&P</td><td>10.240.70.132</td></tr> <tr> <td>SO1</td><td>Standby</td><td>OOS</td><td>Active</td><td>SO2</td><td>SO_10303</td><td>System OAM</td><td></td></tr> <tr> <td>SO2</td><td>Active</td><td>OOS</td><td>Active</td><td>SO1</td><td>SO_10303</td><td>System OAM</td><td>10.240.70.133</td></tr> <tr> <td>MP1</td><td>Standby</td><td>Active</td><td>Active</td><td>MP2</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>MP2</td><td>Active</td><td>Active</td><td>Active</td><td>MP1</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>IPFE</td><td>Active</td><td>OOS</td><td>Active</td><td></td><td>SO_10303</td><td>MP</td><td></td></tr> </tbody> </table>	Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs	NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132	SO1	Standby	OOS	Active	SO2	SO_10303	System OAM		SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133	MP1	Standby	Active	Active	MP2	SO_10303	MP		MP2	Active	Active	Active	MP1	SO_10303	MP		IPFE	Active	OOS	Active		SO_10303	MP																																	
Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs																																																																																			
NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132																																																																																			
SO1	Standby	OOS	Active	SO2	SO_10303	System OAM																																																																																				
SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133																																																																																			
MP1	Standby	Active	Active	MP2	SO_10303	MP																																																																																				
MP2	Active	Active	Active	MP1	SO_10303	MP																																																																																				
IPFE	Active	OOS	Active		SO_10303	MP																																																																																				


Procedure 2: Recovery Scenario 2

46	SOAM GUI: Enable Provisioning	<p>Click on Main Menu->Status & Manage->Database</p>  <p>Enable Provisioning by clicking on Enable Provisioning button at the bottom of the screen as shown below.</p>  <p>A confirmation window will appear, press OK to enable Provisioning.</p> 
47	SOAM VIP GUI: Verify the Local Node Info (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Local Node</p>  <p>Verify that all the local nodes are shown.</p>



Procedure 2: Recovery Scenario 2

48	<p>SOAM VIP GUI: Verify the Peer Node Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Peer Node</p>  <p>Verify that all the peer nodes are shown.</p>
----	--	--



Procedure 2: Recovery Scenario 2

49	<p>SOAM VIP GUI: <input type="checkbox"/> Verify the Connections Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Connections</p>  <p>Verify that all the connections are shown.</p>
50	<p>MP Servers: <input type="checkbox"/> Disable SCTP Auth Flag (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>For SCTP connections without DTLS enabled, refer to Enable/Disable DTLS Appendix from reference [8]</p> <p>Execute this procedure on all Failed MP Servers.</p>




Procedure 2: Recovery Scenario 2

51	SOAM VIP GUI: Enable <input type="checkbox"/> Connections if needed (DSR Only)	DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step
		<p>Navigate to Main Menu->Diameter->Maintenance->Connections</p>  <p>Select each connection and click on the Enable button. Alternatively you can enable all the connections by selecting the EnableAll button.</p> <p>Enable Disable EnableAll DisableAll Diagnose Start Diagnose End SCTP STATISTICS <input type="checkbox"/> Pause updates</p> <p>Verify that the Operational State is Available.</p> <p>Note: If a Disaster Recovery was performed on an IPFE server, it may be necessary to disable and re-enable the connections to ensure proper link distribution</p>
52	SOAM VIP GUI: Enable Optional Features (DSR Only)	DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step
		<p>Navigate to Main Menu -> Diameter -> Maintenance -> Applications</p>  <p>Select the optional feature application configured in step 42.</p> <p>Click the Enable button.</p> <p>Enable Disable <input type="checkbox"/> Pause updates</p>

Procedure 2: Recovery Scenario 2

53	SOAM VIP GUI: <input type="checkbox"/> Re-enable Transports if Needed (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Transport Manager -> Maintenance -> Transport</p>  <p>Select each transport and click on the Enable button</p>  <p>Verify that the Operational Status for each transport is Up.</p>
54	SOAM VIP GUI: <input type="checkbox"/> Re-enable MAPIWF application if needed(DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Local SCCP Users</p>  <p>Click on the Enable button corresponding to MAPIWF Application Name.</p>  <p>Verify that the SSN Status is Enabled.</p>

Procedure 2: Recovery Scenario 2

<p>55 <input type="checkbox"/></p>	<p>SOAM VIP GUI: Re-enable links if needed (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Links</p>  <p>Click on Enable button for each link.</p> <p>Enable Disable</p> <p>Verify that the Operational Status for each link is Up.</p>
<p>56 <input type="checkbox"/></p>	<p>SOAM VIP GUI: Examine All Alarms</p>	<p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>
<p>57 <input type="checkbox"/></p>	<p>NOAM VIP GUI: Examine All Alarms</p>	<p>Login to the NOAM VIP if not already logged in.</p> <p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>

Procedure 2: Recovery Scenario 2

58 <input type="checkbox"/>	NOAM VIP: Verify all servers in Topology are accessible (RADIUS Only)	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to the NOAM VIP. Login as admusr.</p> <p>Execute following commands to check if all the servers in the Topology are accessible :</p> <div data-bbox="502 530 971 587" style="border: 1px solid black; padding: 5px;"><pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -checkAccess</pre></div> <p>Example Output:</p> <div data-bbox="512 692 1046 977" style="border: 1px solid black; padding: 5px;"><pre>[admusr@NOAM-2 bin]\$./sharedKrevo -checkAccess FIPS integrity verification test failed. 1450723403: [INFO] 'NOAM-1' is accessible. FIPS integrity verification test failed. 1450723403: [INFO] 'SOAM-1' is accessible. FIPS integrity verification test failed. 1450723403: [INFO] 'SOAM-2' is accessible. FIPS integrity verification test failed. 1450723404: [INFO] 'IPFE' is accessible. FIPS integrity verification test failed. 1450723404: [INFO] 'MP-2' is accessible. FIPS integrity verification test failed. 1450723404: [INFO] 'MP-1' is accessible. [admusr@NOAM-2 bin]\$</pre></div>
--------------------------------	---	---

Procedure 2: Recovery Scenario 2

<p>59 <input type="checkbox"/> NOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Execute following commands to check if existing Key file on Active NOAM (The NOAM which is intact and was not recovered) server is valid :</p> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -validate</pre> <div style="background-color: black; color: white; padding: 10px; margin-top: 10px;"> <pre>[admsusr@NOAM-2 bin]\$./sharedKrevo -validate FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723458: [INFO] Key file for 'NOAM-1' is valid 1450723458: [INFO] Key file for 'NOAM-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723459: [INFO] Key file for 'SOAM-1' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723460: [INFO] Key file for 'SOAM-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723461: [INFO] Key file for 'IPFE' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723461: [INFO] Key file for 'MP-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723462: [INFO] Key file for 'MP-1' is valid [admsusr@NOAM-2 bin]\$</pre> </div> <p>If output of above command shows that the existing key file is not valid, contact My Oracle Support (MOS)</p> <p>Execute following command to copy the key file to all the servers in the Topology:</p> <pre>\$./sharedKrevo -synchronize</pre> <div style="background-color: black; color: white; padding: 10px; margin-top: 10px;"> <pre>FIPS integrity verification test failed. FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722753: [INFO] Synced key to IPFE FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722754: NOAM-2 and MP-2 key files differ. Sync NOAM-2 key file to MP-2. FIPS integrity verification test failed. 1450722755: [INFO] Synced key to MP-2 FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722756: NOAM-2 and MP-1 key files differ. Sync NOAM-2 key file to MP-1. FIPS integrity verification test failed. 1450722758: [INFO] Synced key to MP-1 [admsusr@NOAM-2 bin]\$</pre> </div> <pre>\$./sharedKrevo -updateData</pre> <div style="background-color: black; color: white; padding: 10px; margin-top: 10px;"> <pre>[admsusr@NOAM-1 bin]\$./sharedKrevo -updateData 1450203518: [INFO] Updating data on server 'NOAM-1' 1450203519: [INFO] Data updated to 'NOAM-1' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203520: [INFO] Updating data on server 'SOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203522: [INFO] 1 rows updated on 'SOAM-2'... 1450203522: [INFO] Data updated to 'SOAM-2' [admsusr@NOAM-1 bin]\$</pre> </div> <p>Note: If any errors are present, stop and contact My Oracle Support (MOS)</p>
--	---

Procedure 2: Recovery Scenario 2

60 <input type="checkbox"/>	Backup and Archive All the Databases from the Recovered System	Execute Appendix A to back up the Configuration databases:
61 <input type="checkbox"/>	Recover IDIH (If Configured)	If any components of IDIH were affected, refer to Section 7.0 to perform the disaster recovery on IDIH.

5.1.3 Recovery Scenario 3 (Partial Server Outage with all NOAM servers failed and one SOAM server intact)

For a partial server outage with an SOAM server intact and available; NOAM servers are recovered using recovery procedures of base hardware and software and then executing a database restore to the active NOAM server using a NOAM database backup file obtained from external backup sources such as customer servers or NetBackup. All other servers are recovered using recovery procedures of base hardware and software. Database replication from the active NOAM/active SOAM server will recover the database on these servers. The major activities are summarized in the list below. Use this list to understand the recovery procedure summary. Do not use this list to execute the procedure. The actual procedures' detailed steps are in **Procedure 3**. The major activities are summarized as follows:

Recover **Active NOAM** server by recovering base hardware, software and the database.

- Recover the base hardware.
- Recover the software.
- Recover the database

Recover **NOAM servers** by recovering base hardware and software.

- Recover the base hardware.
- Recover the software.

Recover any failed **SOAM and MP/DP servers** by recovering base hardware and software.

- Recover the base hardware.
- Recover the software.
- Database is already intact at one SOAM server and does not require restoration at the other SOAM and MP/DP servers.

Recover IDIH if necessary

Procedure 3: Recovery Scenario 3

S T E P #	<p>This procedure performs recovery if ALL NOAM servers are failed but 1 or more SOAM servers are intact. This includes any SOAM server that is in another location (spare SOAM server).</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Workarounds	Refer to Appendix I. to understand any workarounds required during this procedure.
2 <input type="checkbox"/>	Gather Required Materials	Gather the documents and required materials listed in Section 3.1.
3 <input type="checkbox"/>	Replace Failed Equipment	HW vendor to replace the failed equipment
4 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Configure BIOS Settings and Update Firmware	<ol style="list-style-type: none"> Configure and verify the BIOS settings by executing procedure "<i>Configure the HP/Oracle RMS BIOS settings</i>" from reference [8] Verify and/or upgrade server firmware by executing procedure "<i>Upgrade Rack Mount Server Firmware</i>" from reference [8]
5 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Backup Available	<p>If the PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 8.</p> <p>This step assumes that TVOE and PMAC backups are available, if backups are NOT available, skip this step.</p> <ol style="list-style-type: none"> Restore the TVOE backup by executing Appendix G on ALL failed rack mount servers Restore the PMAC backup by executing Appendix H <p style="text-align: center;">Proceed to Step 7</p>
6 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Backup Not Available	<p>If the PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 8.</p> <p>This step assumes that TVOE and PMAC backups Are NOT available, if the TVOE and PMAC have already been restored, skip this step</p> <ol style="list-style-type: none"> Execute procedure "<i>Install and Configure TVOE on First RMS (PMAC Host)</i>" from reference [8] Execute section "<i>Install PMAC</i>" from reference [8] <p style="text-align: center;">Proceed to Next Step</p>



Procedure 3: Recovery Scenario 3

7 <input type="checkbox"/>	Configure PMAC (No Backup)	If PMAC backup was NOT restored in step 5, execute this step. Otherwise Skip this Step . Execute sections “Configure PMAC Server” and “Add Cabinet to PMAC” from reference [8]
8 <input type="checkbox"/>	Install/Configure Additional Rack Mount Servers	If TVOE backups were NOT performed on any additional rack mount servers or are not available, execute this step. Otherwise Skip this Step <ol style="list-style-type: none"> 9. Oracle X5-2/Netra X5-2/ HP DL380 GEN 8: Execute procedure “<i>Install TVOE on Additional Rack Mount Servers</i>” from reference [8] 10. HP DL380 GEN 9: Execute procedure “<i>Install and Configure TVOE on First RMS</i>” from reference [8] 11. Execute “<i>Configure TVOE on Additional Rack Mount Servers</i>” from reference [8] 12. Configure and verify the BIOS/NEB settings by executing procedure “<i>Configure Oracle X5-2/Netra X5-2 Server</i>” from reference [8]
9 <input type="checkbox"/>	Determine VM Placement and Socket Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)	FOR ORACLE X5-2/NETRA X5-2/HP DL380 GEN 9 ONLY, HP DL380 GEN 8 SKIP THIS STEP Refer to the DSR VM placement and Pinning workbook to determine proper VM placement and pinning.
10 <input type="checkbox"/>	Deploy Redundant PMAC	If the redundant PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 13. Refer to procedure “ <i>Deploy Redundant PMAC (Optional)</i> ” to re-deploy and configure any redundant PMACs previously configured.
11 <input type="checkbox"/>	Create Virtual Machines For Applications	Execute section “Create Virtual Machines for Applications” from reference [8]
12 <input type="checkbox"/>	Perform CPU Pinning	Configure VM CPU socket pinning on each TVOE host to optimize performance by executing procedure “ <i>CPU Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)</i> ” from reference [8]
13 <input type="checkbox"/>	Install Software on Virtual Machines	Execute section “ <i>Install Software on Virtual Machines</i> ” from reference [8]


Procedure 3: Recovery Scenario 3

14 <input type="checkbox"/>	Execute DSR Installation Procedure for the First NOAM	<p>Verify the networking data for Network Elements</p> <p>Note: Use the backup copy of network configuration data and site surveys (Step 2)</p> <p>Note: SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only) disaster recovery actions can and should be worked simultaneously, doing so would allow faster recovery of the complete solution (i.e. stale DB on DP servers will not receive updates until SDS-SOAM servers are recovered. The following steps will be written to accommodate both DSR and SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only) disaster recovery steps.</p> <p>DSR:</p> <ol style="list-style-type: none"> 1. Configure the first NOAM server by executing procedure “<i>Configure First NOAM NE and Server</i>” from reference [8] 2. Configure the NOAM server group by executing procedure “<i>Configure the NOAM Server Group</i>” from reference [8] <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <ol style="list-style-type: none"> 1. Configure the first SDS NOAM server by executing procedure “<i>Configure First SDS NOAM NE and Server</i>” from reference [8] <p>Configure the SDS NOAM server group by executing procedure “<i>Configure the SDS NOAM Server Group</i>” from reference [8]</p>
15 <input type="checkbox"/>	NOAM GUI: Login	<p>If the failed server(s) are NOT OAM type, skip to step 30</p> <p>Login to the NOAM GUI as the guiadmin user:</p>  <p>The screenshot shows the Oracle System Login page. The title is "Oracle System Login" and the date is "Fri Mar 20 12:29:52 2015 EDT". A "Log In" box contains fields for "Username" (set to "guiadmin") and "Password" (set to "*****"). There is a "Change password" checkbox and a "Log In" button. Below the box, a welcome message says "Welcome to the Oracle System Login." and a note says "Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies." At the bottom, there is a trademark notice: "Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners."</p>



Procedure 3: Recovery Scenario 3

<p>16</p> <input type="checkbox"/>	<p>NOAM GUI: Upload the Backed up Database File</p>	<p>Browse to Main Menu->Status & Manage->Files</p>  <p>Select the Active NOAM server. The following screen will appear:</p>  <p>Click on Upload as shown below and select the file “<i>NO Provisioning and Configuration:</i>” file backed up after initial installation and provisioning.</p>  <p>Click on Browse and locate the backup file and click on Open as shown below.</p>  <p>Click on the Upload button. The file will take a few seconds to upload depending on the size of the backup data. The file will be visible on the list of entries after the upload is complete.</p>
------------------------------------	--	---

Procedure 3: Recovery Scenario 3

17	<p>NOAM GUI: Verify the Archive Contents and Database Compatibility</p>	<p>Select the Active NOAM server and click on the Compare.</p> <p>The following screen is displayed; click the button for the restored database file that was uploaded as a part of Step 18 of this procedure.</p> <p>Database Compare</p> <p>Select archive to compare on server: Shelby.NO.A</p> <p>Archive</p> <p><input type="checkbox"/> backup/Backup.dsrShelby-NO-A.Configuration.NETWORK_OAMP20160405_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsrShelby-NO-A.Configuration.NETWORK_OAMP20160406_021502.AUTO.tar <input type="checkbox"/> backup/Backup.dsrShelby-NO-A.Configuration.NETWORK_OAMP20160407_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsrShelby-NO-A.Configuration.NETWORK_OAMP20160408_021501.AUTO.tar <input type="checkbox"/> backup/Backup.dsrShelby-NO-A.Configuration_72_18.0.MAN.tar.bz2</p> <p>Ok Cancel</p>
		<p>Verify that the output window matches the screen below.</p> <p>Note: You will get a database mismatch regarding the NodeID. That is expected. If that is the only mismatch, proceed, otherwise stop and contact My Oracle Support (MOS) and ask for assistance.</p> <p></p> <p>Note: Archive Contents and Database Compatibilities must be the following:</p> <p>Archive Contents: Configuration data</p> <p>Database Compatibility: The databases are compatible.</p> <p>Note: The following is expected Output for Topology Compatibility Check since we are restoring from existing backed up data base to database with just one NOAM:</p> <p>Topology Compatibility THE TOPOLOGY SHOULD BE COMPATIBLE MINUS THE NODEID.</p> <p>Note: We are trying to restore a backed up database onto an empty NOAM database. This is an expected text in Topology Compatibility.</p> <p>If the verification is successful, Click BACK button and continue to next step in this procedure.</p>

Procedure 3: Recovery Scenario 3

18	ACTIVE NOAM: <input type="checkbox"/> Restore the Database	<p>Click on Main Menu->Status & Manage->Database</p> <p>Select the Active NOAM server, and click on Restore as shown below.</p> <p>The following screen will be displayed. Select the proper back up provisioning and configuration file.</p> <p>Main Menu: Status & Manage -> Database [Restore]</p>  <p>Click OK Button. The following confirmation screen will be displayed.</p> <p>If you get an error that the NodeIDs do not match. That is expected. If no other errors beside the NodeIDs are displayed, select the Force checkbox as shown above and Click OK to proceed with the DB restore.</p> <p>Database Restore Confirm</p> <p>Incompatible database selected</p>  <p>Note: After the restore has started, the user will be logged out of XMI NO GUI since the restored Topology is old data.</p>
----	--	---



Procedure 3: Recovery Scenario 3

19	NOAM VIP GUI: Login	<p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"> http://<Primary_NOAM_VIP_IP_Address> </div> <p>Login as the guiadmin user:</p>  <p>Fri Mar 20 12:29:52 2015 EDT</p> <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>
20	NOAM VIP GUI: Monitor and Confirm database restoral	<p>Wait for 5-10 minutes for the System to stabilize with the new topology:</p> <p>Monitor the Info tab for “Success”. This will indicate that the restore is complete and the system is stabilized.</p> <p>Following alarms must be ignored for NOAM and MP/DP Servers until all the Servers are configured:</p> <p>Alarms with Type Column as “REPL” , “COLL” , “HA” (with mate NOAM), “DB” (about Provisioning Manually Disabled)</p> <p>Note: Do not pay attention to alarms until all the servers in the system are completely restored.</p> <p>Note: The Configuration and Maintenance information will be in the same state it was backed up during initial backup.</p>
21	ACTIVE NOAM: Login	<p>Login to the recovered Active NOAM via SSH terminal as admusr.</p>


Procedure 3: Recovery Scenario 3

22 <input type="checkbox"/>	NOAM VIP GUI: Recover Standby NOAM	<p>Install the second NOAM server:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the Second NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8].</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the Second SDS NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8]</p>
23 <input type="checkbox"/>	Install NetBackup Client (Optional)	<p>If NetBackup is used execute procedure “<i>Install NetBackup Client (Optional)</i>” from reference [8]</p>
24 <input type="checkbox"/>	Active NOAM: Correct the RecognizedAutho- rity table	<p>Establish an SSH session to the active NOAM, login as admusr.</p> <p>Execute the following command:</p> <div style="border: 1px solid black; padding: 5px; background-color: #f0f0f0;"> <pre>\$ sudo top.setPrimary - Using my cluster: A1789 - New Primary Timestamp: 11/09/15 20:21:43.418 - Updating A1789.022: <DSR_NOAM_B_hostname> - Updating A1789.144: <DSR_NOAM_A_hostname></pre> </div>


Procedure 3: Recovery Scenario 3

25	NOAM VIP GUI: Restart DSR application	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered standby NOAM server and click on Restart.</p> <p>Stop Restart Reboot NTP Sync Report</p>
26	NOAM VIP GUI: Recover the Remaining SOAM Servers	<p>Recover the remaining SOAM servers (Standby, Spare-Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only) by DSR:</p> <p>Execute procedure “Configure the SOAM Servers”, steps 1-3, and 5-8, 10 from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p> <p>Note: If you are using NetBackup, also execute step 12.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “Configure the SDS SOAM Servers”, steps 1-3, and 5-8, 10 from reference [8]</p> <p>Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9</p>
27	NOAM VIP GUI: Restart DSR application	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered standby SOAM server and click on Restart.</p> <p>Stop Restart Reboot NTP Sync Report</p>


Procedure 3: Recovery Scenario 3

28 <input type="checkbox"/>	(PCA Only) Activate PCA Feature	<p>If you are installing PCA, execute the applicable procedures (Added SOAM site activation or complete system activation) within Appendix A of [7] to activate PCA.</p> <p>Note: If not all SOAM sites are ready at this point, then you should repeat activation for each *new* SOAM site that comes online.</p>
29 <input type="checkbox"/>	NOAM VIP GUI: Recover the C-Level Server (DA-MPs, SBRs, IPFE, SS7-MP, and SDS DPs)	<p>Recover C-Level Servers:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the MP Servers</i>”, Steps 1, 9-12, 14 from reference [8]</p> <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 13</p> <p>Note: Execute steps 15-17 if you plan to configure a default route on your MP that uses a signaling (XSI) network instead of the XMI network.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the SDS DP Servers</i>”, Steps 1, 6-7, 9 from reference [8]</p> <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 8</p> <p>Repeat this step for any remaining failed MP/DP servers.</p>
30 <input type="checkbox"/>	NOAM VIP GUI: Set HA on all C-Level Servers	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>For each server whose Max Allowed HA Role is set to Standby, set it to Active</p> <p>Press OK</p>

Procedure 3: Recovery Scenario 3

31	NOAM VIP GUI: Restart DSR	Navigate to Main Menu->Status & Manage->Server
	<input type="checkbox"/> Application on recovered C-Level Servers.	 <p>Select the recovered C-Level servers and click on Restart.</p> <p>Buttons: Stop, Restart, Reboot, NTP Sync, Report</p>
32	ACTIVE NOAM: Perform key exchange between the active-NOAM and recovered servers.	Establish an SSH session to the Active NOAM, login as admusr . Execute the following command to perform a keyexchange from the active NOAM to each recovered server: <div style="border: 1px solid black; padding: 2px; display: inline-block;"> \$ keyexchange admusr@<Recovered Server Hostname> </div> <p>Note: If an export server is configured, perform this step.</p>
33	ACTIVE NOAM: Activate Optional Features	Establish an SSH session to the active NOAM, login as admusr . Refer to Section 1.5 Optional Features to activate any features that were previously activated. <p>Note: While running the activation script, the following error message (and corresponding messages) output may be seen, this can safely be ignored:</p> <pre>iload#31000{S/W Fault}</pre>



Procedure 3: Recovery Scenario 3

<p>34</p> <p><input type="checkbox"/> NOAM VIP GUI: Fetch and Store the database Report for the Newly Restored Data and Save it</p>	<p>Navigate to Main Menu -> Status & Manage -> Database</p>  <p>Select the active NOAM server and click on the Report button at the bottom of the page. The following screen is displayed:</p> <p>Main Menu: Status & Manage -> Database [Report]</p> <pre> ===== d s r D a t a b a s e S t a t u s R e p o r t ===== Report Generated: Thu Nov 05 11:23:30 2015 EST From: Network OAM&P on host LDM2NO1 Report Version: 7.1.1.0.0-71.28.0 User: guiaadmin ----- General ----- Hostname : LDM2NO1 Database Birthday : 2015-10-26 10:44:09 EDT Appworks Database Version : 6.0 Application Database Version : Capacities and Utilization ----- Disk Utilization 2.6%: 233M used of 9.1G total, 8.4G available Memory Utilization 26.8%: 1413M used of 5266M total, 3853M available Alarms </pre> <p>Print Save Back</p> <p>Click on Save and save the report to your local machine.</p>
--	---



Procedure 3: Recovery Scenario 3

<p>35 <input type="checkbox"/> ACTIVE NOAM: Verify Replication Between Servers.</p>	<p>Login to the Active NOAM via SSH terminal as admusr.</p> <p>Execute the following command:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ sudo irepstat -m</pre> </div> <p>Output like below shall be generated:</p> <pre>-- Policy 0 ActStb [DbReplication] ----- ----- Oahu-DAMP-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.15%cpu 25B/s A=me CC To Oahu-DAMP-2 Active 0 0.10 0.14%cpu 25B/s A=me Oahu-DAMP-2 -- Stby BC From Oahu-SOAM-2 Active 0 0.50 ^0.11%cpu 31B/s A=C3642.212 CC From Oahu-DAMP-1 Active 0 0.10 ^0.14 1.16%cpu 31B/s A=C3642.212 Oahu-IPFE-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 24B/s A=C3642.212 Oahu-IPFE-2 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 28B/s A=C3642.212 Oahu-NOAM-1 -- Stby AA From Oahu-NOAM-2 Active 0 0.25 ^0.03%cpu 23B/s Oahu-NOAM-2 -- Active AA To Oahu-NOAM-1 Active 0 0.25 1%R 0.04%cpu 61B/s AB To Oahu-SOAM-2 Active 0 0.50 1%R 0.05%cpu 75B/s Oahu-SOAM-1 -- Stby BB From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 27B/s Oahu-SOAM-2 -- Active AB From Oahu-NOAM-2 Active 0 0.50 ^0.03%cpu 24B/s BB To Oahu-SOAM-1 Active 0 0.50 1%R 0.04%cpu 32B/s BC To Oahu-IPFE-1 Active 0 0.50 1%R 0.04%cpu 21B/s BC To Oahu-SS7MP-2 Active 0 0.50 1%R 0.04%cpu 21B/s irepstat (40 lines) (h)elp (m)erged</pre>
--	---


Procedure 3: Recovery Scenario 3

36	NOAM VIP GUI: <input type="checkbox"/> Verify the Database states	<p>Click on Main Menu->Status and Manager->Database</p>  <p>Verify that the “OAM Max HA Role” is either “Active” or “Standby” for NOAM and SOAM and “Application Max HA Role” for MPs is “Active”, and that the status is “Normal” as shown below:</p> <table border="1" data-bbox="502 720 1351 910"> <thead> <tr> <th>Network Element</th><th>Server</th><th>Role</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Status</th><th>DB Level</th><th>OAM Repl Status</th><th>SIG Repl Status</th><th>Repl Status</th><th>Repl Audit Status</th></tr> </thead> <tbody> <tr> <td>NO_10303</td><td>NO2</td><td>Network OAM&P</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>PSBR</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>MP2</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO1</td><td>System OAM</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>NO_10303</td><td>NO1</td><td>Network OAM&P</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>IPFE</td><td>MP</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO2</td><td>System OAM</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> </tbody> </table>	Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status	NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg
Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status																																																																																
NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
37	NOAM VIP GUI: <input type="checkbox"/> Verify the HA Status	<p>Click on Main Menu->Status and Manager->HA</p>  <p>Select the row for all of the servers Verify that the “HA Role” is either “Active” or “Standby”.</p> <table border="1" data-bbox="502 1431 1367 1600"> <thead> <tr> <th>Hostname</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Max Allowed HA Role</th><th>Mate Hostname List</th><th>Network Element</th><th>Server Role</th><th>Active VIPs</th></tr> </thead> <tbody> <tr> <td>NO2</td><td>Active</td><td>OOS</td><td>Active</td><td>NO1</td><td>NO_10303</td><td>Network OAM&P</td><td>10.240.70.132</td></tr> <tr> <td>SO1</td><td>Standby</td><td>OOS</td><td>Active</td><td>SO2</td><td>SO_10303</td><td>System OAM</td><td></td></tr> <tr> <td>SO2</td><td>Active</td><td>OOS</td><td>Active</td><td>SO1</td><td>SO_10303</td><td>System OAM</td><td>10.240.70.133</td></tr> <tr> <td>MP1</td><td>Standby</td><td>Active</td><td>Active</td><td>MP2</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>MP2</td><td>Active</td><td>Active</td><td>Active</td><td>MP1</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>IPFE</td><td>Active</td><td>OOS</td><td>Active</td><td></td><td>SO_10303</td><td>MP</td><td></td></tr> </tbody> </table>	Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs	NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132	SO1	Standby	OOS	Active	SO2	SO_10303	System OAM		SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133	MP1	Standby	Active	Active	MP2	SO_10303	MP		MP2	Active	Active	Active	MP1	SO_10303	MP		IPFE	Active	OOS	Active		SO_10303	MP																																	
Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs																																																																																			
NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132																																																																																			
SO1	Standby	OOS	Active	SO2	SO_10303	System OAM																																																																																				
SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133																																																																																			
MP1	Standby	Active	Active	MP2	SO_10303	MP																																																																																				
MP2	Active	Active	Active	MP1	SO_10303	MP																																																																																				
IPFE	Active	OOS	Active		SO_10303	MP																																																																																				



Procedure 3: Recovery Scenario 3

38	<p>SOAM VIP GUI: Verify the Local Node Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Local Node</p>  <p>Verify that all the local nodes are shown.</p>
39	<p>SOAM VIP GUI: Verify the Peer Node Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Peer Node</p>  <p>Verify that all the peer nodes are shown.</p>




Procedure 3: Recovery Scenario 3

40	<p>SOAM VIP GUI: <input type="checkbox"/> Verify the Connections Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Connections</p>  <p>Verify that all the connections are shown.</p>
41	<p>MP Servers: <input type="checkbox"/> Disable SCTP Auth Flag (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>For SCTP connections without DTLS enabled, refer to Enable/Disable DTLS Appendix from reference [8]</p> <p>Execute this procedure on all Failed MP Servers.</p>


Procedure 3: Recovery Scenario 3

42	<p>SOAM VIP GUI: <input type="checkbox"/> Enable Connections if needed (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Maintenance->Connections</p>  <p>Select each connection and click on the Enable button. Alternatively you can enable all the connections by selecting the EnableAll button.</p> <p style="text-align: right;"> <input type="button" value="Enable"/> <input type="button" value="Disable"/> <input type="button" value="EnableAll"/> <input type="button" value="DisableAll"/> <input type="button" value="Diagnose Start"/> <input type="button" value="Diagnose End"/> <input type="button" value="SCTP STATISTICS"/> <input type="checkbox"/> Pause updates </p> <p>Verify that the Operational State is Available.</p> <p>Note: If a Disaster Recovery was performed on an IPFE server, it may be necessary to disable and re-enable the connections to ensure proper link distribution</p>
43	<p>SOAM VIP GUI: <input type="checkbox"/> Enable Optional Features (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu -> Diameter -> Maintenance -> Applications</p>  <p>Select the optional feature application configured in step 33.</p> <p>Click the Enable button.</p> <p style="text-align: center;"> <input type="button" value="Enable"/> <input type="button" value="Disable"/> <input type="checkbox"/> Pause updates </p>

Procedure 3: Recovery Scenario 3

44	<p>SOAM VIP GUI: Re-enable Transports if Needed (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Transport Manager -> Maintenance -> Transport</p>  <p>Select each transport and click on the Enable button</p>  <p>Verify that the Operational Status for each transport is Up.</p>
45	<p>SOAM VIP GUI: Re-enable MAPIWF application if needed(DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Local SCCP Users</p>  <p>Click on the Enable button corresponding to MAPIWF Application Name.</p>  <p>Verify that the SSN Status is Enabled.</p>


Procedure 3: Recovery Scenario 3

46	SOAM VIP GUI: Re-enable links if needed (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Links</p>  <p>Click on Enable button for each link.</p> <p>Enable Disable</p> <p>Verify that the Operational Status for each link is Up.</p>
47	NOAM VIP: Verify all servers in Topology are accessible (RADIUS Only)	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to the NOAM VIP. Login as admusr.</p> <p>Execute following commands to check if all the servers in the Topology are accessible :</p> <pre>\$./usr/TKLC/dpi/bin/sharedKrevo -checkAccess</pre> <p>Output Example:</p> <pre>1450112012: [INFO] 'SOAM-2' is accessible. FIPS integrity verification test failed. The authenticity of host 'ipfe (10.240.146.16)' can't be established. RSA key fingerprint is ea:7f:0d:eb:56:4d:de:b1:5b:04:a3:fe:72:4e:c3:52. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added 'ipfe,10.240.146.16' (RSA) to the list of known hosts . 1450112015: [INFO] 'IPFE' is accessible. FIPS integrity verification test failed. The authenticity of host 'mp-2 (10.240.146.24)' can't be established. RSA key fingerprint is 73:ec:ac:d7:af:d2:78:dd:8e:bf:8e:79:a8:26:a7:b6. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added 'mp-2,10.240.146.24' (RSA) to the list of known hosts . 1450112017: [INFO] 'MP-2' is accessible. FIPS integrity verification test failed. The authenticity of host 'mp-1 (10.240.146.14)' can't be established. RSA key fingerprint is c5:66:85:6c:1d:c8:9f:78:92:2c:ca:8b:83:9b:ef:99. Are you sure you want to continue connecting (yes/no)? yes Warning: Permanently added 'mp-1,10.240.146.14' (RSA) to the list of known hosts . 1450112020: [INFO] 'MP-1' is accessible.</pre> <p>Note: If any of the servers are not accessible, stop and contact My Oracle Support (MOS)</p>


Procedure 3: Recovery Scenario 3

48 □	<p>SOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to any of the Active SOAM which remained intact and operational (Need to Login to Active SOAM server which was not recovered or did not need recovery). Login as admusr.</p> <p>Execute following commands to check if existing Key file on Active SOAM server is valid :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -validate</pre> </div> <p>Expected Output:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>/usr/TKLC/dpi/</pre> </div> <p>Note: If output of above command shows that existing key file is not valid, contact My Oracle Support (MOS)</p> <p>Establish an SSH session to the active SOAM, login as admusr.</p> <p>Execute following command to copy the key file to Active NOAM :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -copyKey -destServer <Active NOAM server name></pre> </div>
---------	--	--

Procedure 3: Recovery Scenario 3

49	<p>NOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to any of the Active NOAM. Login as admusr.</p> <p>Execute following command to copy the key file to all the servers in the Topology :</p> <pre>\$./sharedKrevo -synchronize</pre> <pre>[admusr@NOAM-1 bin]\$./sharedKrevo -synchronize FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203505: [INFO] Key file on Active NOAM and NOAM-2 are same. 1450203505: [INFO] NO NEED to sync key file to NOAM-2. FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203506: [INFO] Key file on Active NOAM and SOAM-1 are same. 1450203506: [INFO] NO NEED to sync key file to SOAM-1. FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203506: [INFO] Key file on Active NOAM and SOAM-2 are same. 1450203506: [INFO] NO NEED to sync key file to SOAM-2. FIPS integrity verification test failed.</pre> <pre>\$./sharedKrevo -updateData</pre> <pre>[admusr@NOAM-1 bin]\$./sharedKrevo -updateData 1450203518: [INFO] Updating data on server 'NOAM-1' 1450203519: [INFO] Data updated to 'NOAM-1' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203520: [INFO] Updating data on server 'SOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203522: [INFO] 1 rows updated on 'SOAM-2'... 1450203522: [INFO] Data updated to 'SOAM-2'</pre>
50	<p>SOAM VIP GUI: Examine All Alarms</p>	<p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>

Procedure 3: Recovery Scenario 3

51 <input type="checkbox"/>	NOAM VIP GUI: Examine All Alarms	<p>Login to the NOAM VIP if not already logged in.</p> <p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>
52 <input type="checkbox"/>	Backup and Archive All the Databases from the Recovered System	Execute Appendix A to back up the Configuration databases:
53 <input type="checkbox"/>	Recover IDIH (If Configured)	If any components of IDIH were affected, refer to Section 7.0 to perform the disaster recovery on IDIH.

5.1.4 Recovery Scenario 4 (Partial Server Outage with one NOAM server and one SOAM server intact)

For a partial outage with an NOAM server and an SOAM server intact and available, only base recovery of hardware and software is needed. The intact NO and SOAM servers are capable of restoring the database via replication to all servers. The major activities are summarized in the list below. Use this list to understand the recovery procedure summary. Do not use this list to execute the procedure. The actual procedures' detailed steps are in Procedure 4. The major activities are summarized as follows:

Recover Standby NOAM server by recovering base hardware and software.

- Recover the base hardware.
- Recover the software.

The database is intact at the active NOAM server and does not require restoration at the standby NOAM server.

- Recover any failed SO and MP/DP servers by recovering base hardware and software.
- Recover the base hardware.
- Recover the software.

The database is intact at the active NOAM server and does not require restoration at the SO and MP/DP servers.


- Re-apply signaling networks configuration if the failed rack mount server contains an MP/DP.

Recover IDIH if necessary

Procedure 4: Recovery Scenario 4

S T E P #	<p>This procedure performs recovery if at least 1 NOAM server is intact and available and 1 SOAM server is intact and available.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1 <input type="checkbox"/>	Workarounds Refer to Appendix I to understand any workarounds required during this procedure.
2 <input type="checkbox"/>	Gather Required Materials Gather the documents and required materials listed in Section 3.1
3 <input type="checkbox"/>	<p>NOAM VIP GUI: Login</p> <p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> http://<Primary_NOAM_VIP_IP_Address> </div> <p>Login as the guiadmin user:</p>  <p>The screenshot shows the Oracle System Login page. At the top, the word "ORACLE" is written in red. Below it, the text "Oracle System Login" is displayed. A timestamp "Fri Mar 20 12:29:52 2015 EDT" is shown. The main area is a "Log In" form with the following fields: - Username: guiadmin - Password: (redacted) - Change password (checkbox) - Log In (button) Below the form, a message reads: "Welcome to the Oracle System Login. Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies." At the bottom, there is a note: "Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners."</p>

Procedure 4: Recovery Scenario 4

4	DSR/SDS Active NOAM: Set Failed Servers to Standby	Navigate to Main Menu -> Status & Manage -> HA  <p>Select Edit</p> <p>Set the Max Allowed HA Role drop down box to Standby for the failed servers.</p> <p>Select Ok</p> <p>Ok Cancel</p>
5	Replace Failed Equipment	HW vendor to replace the failed equipment
6	Recover PMAC and PMAC TVOE Host: Configure BIOS Settings and Update Firmware	<ol style="list-style-type: none"> 1. Configure and verify the BIOS settings by executing procedure <i>“Configure the HP/Oracle RMS BIOS settings”</i> from reference [8] 2. Verify and/or upgrade server firmware by executing procedure <i>“Upgrade Rack Mount Server Firmware”</i> from reference [8]
7	Recover PMAC and PMAC TVOE Host: Backup Available	<p>If the PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 10.</p> <p>This step assumes that TVOE and PMAC backups are available, if backups are NOT available, skip this step.</p> <ol style="list-style-type: none"> 1. Restore the TVOE backup by executing Appendix G on ALL failed rack mount servers 2. Restore the PMAC backup by executing Appendix H <p>Proceed to Step 10</p>

Procedure 4: Recovery Scenario 4

8 <input type="checkbox"/>	Recover PMAC and PMAC TVOE Host: Backup Not Available	<p>If the PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 10.</p> <p>This step assumes that TVOE and PMAC backups Are NOT available, if the TVOE and PMAC have already been restored, skip this step</p> <ol style="list-style-type: none"> 1. Execute section “<i>Install and Configure TVOE on First RMS (PMAC Host)</i>” from reference [8] 2. Execute section “<i>Install PMAC</i>” from reference [8] 3. Execute section “<i>Initialize the PMAC Application</i>” from reference [8] <p style="text-align: center;">Proceed to Next Step</p>
9 <input type="checkbox"/>	Configure PMAC (No Backup)	<p>If PMAC backup was NOT restored in step 5, execute this step. Otherwise Skip this Step.</p> <p>Execute sections “<i>Configure PMAC Server</i>” and “<i>Add Cabinet to PMAC</i>” from reference [8]</p>
10 <input type="checkbox"/>	Install/Configure Additional Rack Mount Servers	<p>If TVOE backups were NOT performed on any additional rack mount servers or are not available, execute this step. Otherwise Skip this Step</p> <ol style="list-style-type: none"> 13. Oracle X5-2/Netra X5-2/ HP DL380 GEN 8: Execute procedure “<i>Install TVOE on Additional Rack Mount Servers</i>” from reference [8] 14. HP DL380 GEN 9: Execute procedure “<i>Install and Configure TVOE on First RMS</i>” from reference [8] 15. Execute “<i>Configure TVOE on Additional Rack Mount Servers</i>” from reference [8] 16. Configure and verify the BIOS/NEB settings by executing procedure “<i>Configure Oracle X5-2/Netra X5-2 Server</i>” from reference [8]
11 <input type="checkbox"/>	Determine VM Placement and Socket Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)	<p>FOR ORACLE X5-2/NETRA X5-2/HP DL380 GEN 9 ONLY, HP DL380 GEN 8 SKIP THIS STEP</p> <p>Refer to the DSR VM placement and Pinning workbook to determine proper VM placement and pinning.</p>
12 <input type="checkbox"/>	Deploy Redundant PMAC	<p>If the redundant PMAC is located on the failed rack mount server(s), execute this step. Otherwise skip to step 13.</p> <p>Refer to procedure “<i>Deploy Redundant PMAC (Optional)</i>” to re-deploy and configure any redundant PMACs previously configured.</p>
13 <input type="checkbox"/>	Create Virtual Machines For Applications	<p>Execute section “<i>Create Virtual Machines for Applications</i>” from reference [8]</p>
14 <input type="checkbox"/>	Perform CPU Pinning	<p>Configure VM CPU socket pinning on each TVOE host to optimize performance by executing procedure “<i>CPU Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)</i>” from reference [8]</p>



Procedure 4: Recovery Scenario 4

15 <input type="checkbox"/>	Install Software on Virtual Machines	Execute section “ <i>Install Software on Virtual Machines</i> ” from reference [8]
16 <input type="checkbox"/>	NOAM VIP GUI: Login	<p>If the failed server(s) are NOT OAM type, skip to step 25</p> <p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"><a href="http://<Primary_NOAM_VIP_IP_Address>">http://<Primary_NOAM_VIP_IP_Address></div> <p>Login as the guiadmin user:</p>  <p>Fri Mar 20 12:29:52 2015 EDT</p> <p>Log In Enter your username and password to log in</p> <p>Username: <input type="text" value="guiadmin"/> Password: <input type="password" value="*****"/> <input type="checkbox"/> Change password <input type="button" value="Log In"/></p> <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>



Procedure 4: Recovery Scenario 4

17 <input type="checkbox"/>	NOAM VIP GUI: Recover Standby NOAM	<p>Install the 1st failed NOAM server:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the Second NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8].</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the Second SDS NOAM Server</i>”, steps 1, 4-7,10 from reference [8]</p> <p>Note: Execute step 8 if NetBackup is used.</p> <p>Note: Execute step 9 if Oracle X5-2/Netra X5-2/HP DL380 Gen 9</p> <p>If NetBackup is used, execute procedure “<i>Install NetBackup Client</i>” from reference [8]</p>
18 <input type="checkbox"/>	Active NOAM: Correct the RecognizedAutho- rity table	<p>Establish an SSH session to the active NOAM, login as admusr.</p> <p>Execute the following command:</p> <div style="border: 1px solid black; padding: 5px; background-color: #f0f0f0;"> <pre>\$ sudo top.setPrimary - Using my cluster: A1789 - New Primary Timestamp: 11/09/15 20:21:43.418 - Updating A1789.022: <DSR_NOAM_B_hostname> - Updating A1789.144: <DSR_NOAM_A_hostname></pre> </div>


Procedure 4: Recovery Scenario 4

19	NOAM VIP GUI: Restart DSR application	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select the recovered standby NOAM server and click on Restart.</p> <p>Stop Restart Reboot NTP Sync Report</p>
20	NOAM VIP GUI: Set HA on Standby NOAM	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>Select the standby NOAM server, set it to Active</p> <p>Press OK</p>



Procedure 4: Recovery Scenario 4

21	NOAM VIP GUI: Recover SOAM Servers	Recover the SOAM servers (Standby, Spare-Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only) DSR: Execute procedure “ <i>Configure the SOAM Servers</i> ”, steps 1-3, and 5-8, 10 from reference [8] Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9 Note: If you are using NetBackup, also execute step 12. SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only): Execute procedure “ <i>Configure the SDS SOAM Servers</i> ”, steps 1-3, and 5-8, 10 from reference [8] Note: If Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 9
22	NOAM VIP GUI: Restart DSR application	Navigate to Main Menu->Status & Manage->Server ,  Select the recovered standby SOAM server and click on Restart . 

Procedure 4: Recovery Scenario 4

<p>23 <input type="checkbox"/></p>	<p>NOAM VIP GUI: Set HA on Standby SOAM</p>	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen Select the standby SOAM server, set it to Active Press OK</p>
<p>24 <input type="checkbox"/></p>	<p>(PCA Only) Activate PCA Feature</p>	<p>If you are installing PCA, execute the applicable procedures (Added SOAM site activation or complete system activation) within Appendix A of [7] to activate PCA.</p> <p>Note: If not all SOAM sites are ready at this point, then you should repeat activation for each *new* SOAM site that comes online.</p>
<p>25 <input type="checkbox"/></p>	<p>NOAM VIP GUI: Recover the C- Level Server (DA-MPs, SBRs, IPFE, SS7-MP, and SDS DPs</p>	<p>Recover C-Level Servers:</p> <p>DSR:</p> <p>Execute procedure “<i>Configure the MP Servers</i>”, Steps 1, 9-12, 14 from reference [8]</p> <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 13</p> <p>Note: Execute steps 15-17 if you plan to configure a default route on your MP that uses a signaling (XSI) network instead of the XMI network.</p> <p>SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only):</p> <p>Execute procedure “<i>Configure the SDS DP Servers</i>”, Steps 1, 6-7, 9 from reference [8]</p> <p>Note: For Oracle X5-2/Netra X5-2/HP DL380 Gen 9, also execute step 8</p> <p>Repeat this step for any remaining failed MP/DP servers.</p>


Procedure 4: Recovery Scenario 4

26	NOAM VIP GUI: Set HA on all C-Level Servers	Navigate to Status & Manage -> HA  Click on Edit at the bottom of the screen For each server whose Max Allowed HA Role is set to Standby, set it to Active Press OK
27	NOAM VIP GUI: Restart DSR Application on recovered C-Level Servers.	Navigate to Main Menu->Status & Manage->Server  Select the recovered C-Level servers and click on Restart . 
28	ACTIVE NOAM: Perform key exchange between the active-NOAM and recovered servers.	Establish an SSH session to the Active NOAM, login as admusr . Execute the following command to perform a keyexchange from the active NOAM to each recovered server: <div style="border: 1px solid black; padding: 2px; display: inline-block;"> \$ keyexchange admusr@<Recovered Server Hostname> </div> Note: If an export server is configured, perform this step.

Procedure 4: Recovery Scenario 4

29 <input type="checkbox"/>	ACTIVE NOAM: Activate Optional Features	Establish an SSH session to the active NOAM, login as admusr . Refer to Section 1.5 Optional Features to activate any features that were previously activated. Note: While running the activation script, the following error message (and corresponding messages) output may be seen, this can safely be ignored: <i>iload#31000 {S/W Fault}</i>
30 <input type="checkbox"/>	MP Servers: Disable SCTP Auth Flag (DSR Only)	DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step For SCTP connections without DTLS enabled, refer to Enable/Disable DTLS Appendix from reference [8] Execute this procedure on all Failed MP Servers.



Procedure 4: Recovery Scenario 4

31	<p>NOAM VIP GUI: Fetch and Store the database Report for the Newly Restored Data and Save it</p> <p>Navigate to Main Menu -> Status & Manage -> Database</p>  <p>Select the active NOAM server and click on the Report button at the bottom of the page. The following screen is displayed:</p> <p>Main Menu: Status & Manage -> Database [Report]</p> <pre>===== d s r D a t a b a s e S t a t u s R e p o r t ===== Report Generated: Thu Nov 05 11:23:30 2015 EST From: Network OAM&P on host LDM2NO1 Report Version: 7.1.1.0.0-71.28.0 User: guiaadmin ----- General ----- Hostname : LDM2NO1 Database Birthday : 2015-10-26 10:44:09 EDT Appworks Database Version : 6.0 Application Database Version : Capacities and Utilization ----- Disk Utilization 2.6%: 233M used of 9.1G total, 8.4G available Memory Utilization 26.8%: 1413M used of 5266M total, 3853M available ----- Print Save Back</pre> <p>Click on Save and save the report to your local machine.</p>
----	--


Procedure 4: Recovery Scenario 4

<p>32 <input type="checkbox"/> ACTIVE NOAM: Verify Replication Between Servers.</p>	<p>Login to the Active NOAM via SSH terminal as admusr.</p> <p>Execute the following command:</p> <pre>\$ sudo irepstat -m</pre> <p>Output like below shall be generated:</p> <pre>-- Policy 0 ActStb [DbReplication] ----- ----- Oahu-DAMP-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.15%cpu 25B/s A=me CC To Oahu-DAMP-2 Active 0 0.10 0.14%cpu 25B/s A=me Oahu-DAMP-2 -- Stby BC From Oahu-SOAM-2 Active 0 0.50 ^0.11%cpu 31B/s A=C3642.212 CC From Oahu-DAMP-1 Active 0 0.10 ^0.14 1.16%cpu 31B/s A=C3642.212 Oahu-IPFE-1 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 24B/s A=C3642.212 Oahu-IPFE-2 -- Active BC From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 28B/s A=C3642.212 Oahu-NOAM-1 -- Stby AA From Oahu-NOAM-2 Active 0 0.25 ^0.03%cpu 23B/s Oahu-NOAM-2 -- Active AA To Oahu-NOAM-1 Active 0 0.25 1%R 0.04%cpu 61B/s AB To Oahu-SOAM-2 Active 0 0.50 1%R 0.05%cpu 75B/s Oahu-SOAM-1 -- Stby BB From Oahu-SOAM-2 Active 0 0.50 ^0.03%cpu 27B/s Oahu-SOAM-2 -- Active AB From Oahu-NOAM-2 Active 0 0.50 ^0.03%cpu 24B/s BB To Oahu-SOAM-1 Active 0 0.50 1%R 0.04%cpu 32B/s BC To Oahu-IPFE-1 Active 0 0.50 1%R 0.04%cpu 21B/s BC To Oahu-SS7MP-2 Active 0 0.50 1%R 0.04%cpu 21B/s irepstat (40 lines) (h)elp (m)erged</pre>
--	---



Procedure 4: Recovery Scenario 4

33	NOAM VIP GUI: <input type="checkbox"/> Verify the Database states	<p>Click on Main Menu->Status and Manager->Database</p>  <p>Verify that the “OAM Max HA Role” is either “Active” or “Standby” for NOAM and SOAM and “Application Max HA Role” for MPs is “Active”, and that the status is “Normal” as shown below:</p> <table border="1"> <thead> <tr> <th>Network Element</th><th>Server</th><th>Role</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Status</th><th>DB Level</th><th>OAM Repl Status</th><th>SIG Repl Status</th><th>Repl Status</th><th>Repl Audit Status</th></tr> </thead> <tbody> <tr> <td>NO_10303</td><td>NO2</td><td>Network OAM&P</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>PSBR</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>MP2</td><td>MP</td><td>Active</td><td>Active</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO1</td><td>System OAM</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>NO_10303</td><td>NO1</td><td>Network OAM&P</td><td>Standby</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>IPFE</td><td>MP</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>Normal</td><td>Allowed</td><td>AutoInProg</td></tr> <tr> <td>SO_10303</td><td>SO2</td><td>System OAM</td><td>Active</td><td>OOS</td><td>Normal</td><td>0</td><td>Normal</td><td>NotApplicable</td><td>Allowed</td><td>AutoInProg</td></tr> </tbody> </table>	Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status	NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg	SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg	SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg
Network Element	Server	Role	OAM Max HA Role	Application Max HA Role	Status	DB Level	OAM Repl Status	SIG Repl Status	Repl Status	Repl Audit Status																																																																																
NO_10303	NO2	Network OAM&P	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	PSBR	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	MP2	MP	Active	Active	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO1	System OAM	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
NO_10303	NO1	Network OAM&P	Standby	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
SO_10303	IPFE	MP	Active	OOS	Normal	0	Normal	Normal	Allowed	AutoInProg																																																																																
SO_10303	SO2	System OAM	Active	OOS	Normal	0	Normal	NotApplicable	Allowed	AutoInProg																																																																																
34	NOAM VIP GUI: <input type="checkbox"/> Verify the HA Status	<p>Click on Main Menu->Status and Manager->HA</p>  <p>Select the row for all of the servers Verify that the “HA Role” is either “Active” or “Standby”.</p> <table border="1"> <thead> <tr> <th>Hostname</th><th>OAM Max HA Role</th><th>Application Max HA Role</th><th>Max Allowed HA Role</th><th>Mate Hostname List</th><th>Network Element</th><th>Server Role</th><th>Active VIPs</th></tr> </thead> <tbody> <tr> <td>NO2</td><td>Active</td><td>OOS</td><td>Active</td><td>NO1</td><td>NO_10303</td><td>Network OAM&P</td><td>10.240.70.132</td></tr> <tr> <td>SO1</td><td>Standby</td><td>OOS</td><td>Active</td><td>SO2</td><td>SO_10303</td><td>System OAM</td><td></td></tr> <tr> <td>SO2</td><td>Active</td><td>OOS</td><td>Active</td><td>SO1</td><td>SO_10303</td><td>System OAM</td><td>10.240.70.133</td></tr> <tr> <td>MP1</td><td>Standby</td><td>Active</td><td>Active</td><td>MP2</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>MP2</td><td>Active</td><td>Active</td><td>Active</td><td>MP1</td><td>SO_10303</td><td>MP</td><td></td></tr> <tr> <td>IPFE</td><td>Active</td><td>OOS</td><td>Active</td><td></td><td>SO_10303</td><td>MP</td><td></td></tr> </tbody> </table>	Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs	NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132	SO1	Standby	OOS	Active	SO2	SO_10303	System OAM		SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133	MP1	Standby	Active	Active	MP2	SO_10303	MP		MP2	Active	Active	Active	MP1	SO_10303	MP		IPFE	Active	OOS	Active		SO_10303	MP																																	
Hostname	OAM Max HA Role	Application Max HA Role	Max Allowed HA Role	Mate Hostname List	Network Element	Server Role	Active VIPs																																																																																			
NO2	Active	OOS	Active	NO1	NO_10303	Network OAM&P	10.240.70.132																																																																																			
SO1	Standby	OOS	Active	SO2	SO_10303	System OAM																																																																																				
SO2	Active	OOS	Active	SO1	SO_10303	System OAM	10.240.70.133																																																																																			
MP1	Standby	Active	Active	MP2	SO_10303	MP																																																																																				
MP2	Active	Active	Active	MP1	SO_10303	MP																																																																																				
IPFE	Active	OOS	Active		SO_10303	MP																																																																																				



Procedure 4: Recovery Scenario 4

35	SOAM VIP GUI: <input type="checkbox"/> Enable Connections if needed (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Maintenance->Connections</p>  <p>Select each connection and click on the Enable button. Alternatively you can enable all the connections by selecting the EnableAll button.</p> <p style="text-align: center;"> <input type="button" value="Enable"/> <input type="button" value="Disable"/> <input type="button" value="EnableAll"/> <input type="button" value="DisableAll"/> <input type="button" value="Diagnose Start"/> <input type="button" value="Diagnose End"/> <input type="button" value="SCTP STATISTICS"/> <input type="checkbox"/> Pause updates </p> <p>Verify that the Operational State is Available.</p> <p>Note: If a Disaster Recovery was performed on a DA-MP server where IPFEs are present, it may be necessary to disable and re-enable the connections to ensure proper link distribution.</p> <p>Note: The links will need to remain in the disabled state for longer than the “Delete Age” timer as configured in Main Menu -> IPFE -> Configuration -> Target Sets as indicated below:</p> <p>Main Menu: IPFE -> Configuration -> Target Sets [Forminsert]</p> 
----	--	---


Procedure 4: Recovery Scenario 4

36	<p>SOAM VIP GUI: Verify the Local Node Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Local Node</p>  <p>Verify that all the local nodes are shown.</p>
37	<p>SOAM VIP GUI: Verify the Peer Node Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Peer Node</p>  <p>Verify that all the peer nodes are shown.</p>

Procedure 4: Recovery Scenario 4

38	<p>SOAM VIP GUI: Verify the Connections Info (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Diameter->Configuration->Connections</p>  <p>Verify that all the connections are shown.</p>
39	<p>SOAM VIP GUI: Re-enable Transports if Needed (DSR Only)</p>	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->Transport Manager -> Maintenance -> Transport</p>  <p>Select each transport and click on the Enable button</p> <p>Enable Disable Block</p> <p>Verify that the Operational Status for each transport is Up.</p>

Procedure 4: Recovery Scenario 4

40	SOAM VIP GUI: <input type="checkbox"/> Re-enable MAPIWF application if needed(DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Local SCCP Users</p>  <p>Click on the Enable button corresponding to MAPIWF Application Name.</p> <p>Enable Disable</p> <p>Verify that the SSN Status is Enabled.</p>
41	SOAM VIP GUI: <input type="checkbox"/> Re-enable links if needed (DSR Only)	<p>DSR Only, if SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), Skip This Step</p> <p>Navigate to Main Menu->SS7/Sigtran->Maintenance->Links</p>  <p>Click on Enable button for each link.</p> <p>Enable Disable</p> <p>Verify that the Operational Status for each link is Up.</p>



Procedure 4: Recovery Scenario 4

42 <input type="checkbox"/>	NOAM VIP: Verify all servers in Topology are accessible (RADIUS Only)	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to the NOAM VIP. Login as admusr.</p> <p>Execute following commands to check if all the servers in the Topology are accessible :</p> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -checkAccess</pre> <p>Example Output:</p> <pre>[admusr@NOAM-2 bin]\$./sharedKrevo -checkAccess FIPS integrity verification test failed. 1450723084: [INFO] 'NOAM-1' is accessible. FIPS integrity verification test failed. 1450723084: [INFO] 'SOAM-1' is accessible. FIPS integrity verification test failed. 1450723085: [INFO] 'SOAM-2' is accessible. FIPS integrity verification test failed. 1450723085: [INFO] 'IPFE' is accessible. FIPS integrity verification test failed. 1450723085: [INFO] 'MP-2' is accessible. FIPS integrity verification test failed. 1450723086: [INFO] 'MP-1' is accessible. [admusr@NOAM-2 bin]\$</pre> <p>Note: If any of the servers are not accessible, stop and contact My Oracle Support (MOS)</p>
--------------------------------	---	---

Procedure 4: Recovery Scenario 4

<p>43</p> <p><input type="checkbox"/> NOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Execute following commands to check if existing Key file on Active NOAM server is valid :</p> <pre>\$./sharedKrevo -validate [admusr@NOAM-2 bin]\$./sharedKrevo -validate FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887507: [INFO] Key file for 'NOAM-1' is valid 1450887507: [INFO] Key file for 'NOAM-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887507: [INFO] Key file for 'SOAM-1' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887508: [INFO] Key file for 'SOAM-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887509: [INFO] Key file for 'IPFE' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887510: [INFO] Key file for 'MP-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887510: [INFO] Key file for 'MP-1' is valid [admusr@NOAM-2 bin]\$</pre> <p>If output of above command shows that existing key file is not valid then contact My Oracle Support (MOS)</p> <p>Execute following command to copy the key file to all the servers in the Topology :</p> <pre>\$./sharedKrevo -synchronize [admusr@NOAM-2 bin]\$./sharedKrevo -synchronize FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887549: NOAM-2 and NOAM-1 key files differ. Sync NOAM-2 key file to NOAM-1. FIPS integrity verification test failed. 1450887551: [INFO] Synced key to NOAM-1 FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887552: NOAM-2 and SOAM-1 key files differ. Sync NOAM-2 key file to SOAM-1. FIPS integrity verification test failed. 1450887554: [INFO] Synced key to SOAM-1 FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887554: [INFO] Key file on Active NOAM and SOAM-2 are same. 1450887554: [INFO] NO NEED to sync key file to SOAM-2.</pre> <pre>\$./sharedKrevo -updateData [admusr@NOAM-2 bin]\$./sharedKrevo -updateData 1450887607: [INFO] Updating data on server 'NOAM-2' 1450887608: [INFO] Data updated to 'NOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887609: [INFO] Updating data on server 'SOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450887611: [INFO] 1 rows updated on 'SOAM-2'... 1450887611: [INFO] Data updated to 'SOAM-2'</pre>
<p>Page 135</p>	<p>E56227-03</p>

Procedure 4: Recovery Scenario 4

44 <input type="checkbox"/>	SOAM VIP GUI: Examine All Alarms	<p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>
45 <input type="checkbox"/>	NOAM VIP GUI: Examine All Alarms	<p>Login to the NOAM VIP if not already logged in.</p> <p>Navigate to Main Menu->Alarms & Events->View Active</p>  <p>Examine all active alarms and refer to the on-line help on how to address them.</p> <p>If needed contact My Oracle Support (MOS).</p>
46 <input type="checkbox"/>	Restart oampAgent if Needed	<p>Note: If alarm “10012: The responder for a monitored table failed to respond to a table change” is raised, the oampAgent needs to be restarted.</p> <p>Establish an SSH session to each server that has the alarm. Login admusr</p> <p>Execute the following commands:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ sudo pm.set off oampAgent \$ sudo pm.set on oampAgent</pre> </div>
47 <input type="checkbox"/>	Backup and Archive All the Databases from the Recovered System	<p>Execute Appendix A to back up the Configuration databases:</p>
48 <input type="checkbox"/>	Recover IDIH (If Configured)	<p>If any components of IDIH were affected, refer to Section 7.0 to perform the disaster recovery on IDIH.</p>

5.1.5 Recovery Scenario 5 (Both NOAM servers failed with DR-NOAM available)

For a partial outage with both NOAM servers failed but a DR NOAM available, the DR NOAM is switched from secondary to primary then recovers the failed NOAM servers. The major activities are summarized in the list below. Use this list to understand the recovery procedure summary. Do not use this list to execute the procedure. The actual procedures' detailed steps are in **Procedure 5**. The major activities are summarized as follows:

Switch DR NOAM from secondary to primary

Recover the failed NOAM servers by recovering base hardware and software.

- Recover the base hardware.
- Recover the software.
- The database is intact at the newly active NOAM server and does not require restoration.

If applicable, recover any failed SOAM and MP/DP servers by recovering base hardware and software.

- Recover the base hardware.
- Recover the software.
- The database is intact at the active NOAM server and does not require restoration at the SOAM and MP/DP servers.

Recover IDIH if necessary

Procedure 5: Recovery Scenario 5

S T E P #	<p>This procedure performs recovery if both NOAM servers have failed but a DR NOAM is available</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Workarounds	Refer to Appendix I to understand any workarounds required during this procedure.
2 <input type="checkbox"/>	Gather Required Materials	Gather the documents and required materials listed in Section 3.1 .
3 <input type="checkbox"/>	Switch DR NOAM to Primary	Execute Appendix C to have the DR NOAM become active.

Procedure 5: Recovery Scenario 5

<p>4</p> <p><input type="checkbox"/> Recover System</p>	<p>If ALL SOAM servers have failed, execute Procedure 2</p> <p>If ALL NOAM servers have failed, execute the following steps:</p> <ol style="list-style-type: none"> 1) Procedure 4: <i>Steps 4-15</i> 2) Perform a keyexchange between the newly active NOAM and the recovered NOAM PMAC: <p>From a terminal window connection on the active NOAM as the admusr user, exchange SSH keys for admusr between the active NOAM and the recovered NOAM's PMAC server using the keyexchange utility, using the management IP address for the PMAC server.</p> <p>When prompted for the password, enter the password for the admusr user of the PMAC server.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ keyexchange admusr@<Recovered_Servers_PMAC_IP_Address></pre> </div> <p>Note: if keyexchange fails, edit /home/admusr/.ssh/known_hosts and remove blank lines, and retry the keyexchange commands.</p> <ol style="list-style-type: none"> 3) Use the PMAC GUI to determine the control network IP address of the recovered VMs. From the PMAC GUI, navigate to Main Menu -> Software -> Software Inventory <p>Perform a keyexchange between the recovered PMAC and the recovered guests:</p> <p>From a terminal window connection on the recovered PMAC as the admusr user, exchange SSH keys for admusr between the PMAC and the recovered VM guests using the keyexchange utility, using the control network IP addresses for the VM guests</p> <p>When prompted for the password, enter the password for the admusr user of the VM guest.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ keyexchange admusr@<Recovered_VM_control_IP_Address></pre> </div> <p>Note: if keyexchange fails, edit /home/admusr/.ssh/known_hosts and remove blank lines, and retry the keyexchange commands.</p> <ol style="list-style-type: none"> 4) Procedure 4: <i>16-20 (To be performed for each NOAM)</i>
--	--


Procedure 5: Recovery Scenario 5

5 <input type="checkbox"/>	Perform Key exchange between Active NOAM and Recovered NOAMs	<p>Perform a keyexchange between the newly active NOAM and the recovered NOAM servers:</p> <p>From a terminal window connection on the active NOAM as the admusr user, exchange SSH keys for admusr between the active NOAM and the recovered NOAM servers using the keyexchange utility, using the host names of the recovered NOAMs.</p> <p>When prompted for the password, enter the password for the admusr user of the recovered NOAM servers.</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ keyexchange admusr@<Recovered_NOAM_Hostname></pre> </div>
6 <input type="checkbox"/>	NOAM VIP GUI: Recover Standby/Spare SOAM and C-Level Servers	<p>If necessary, refer to Procedure 3 to recover any standby or Spare SOAMs as well as any C-Level servers.</p>
7 <input type="checkbox"/>	Recovered Active NOAM: Activate Optional Features	<p>Map-Diameter Interworking (MAP-IWF) and/or Policy and Charging Application (PCA) Only</p> <p>Establish an SSH session to the recovered active NOAM, login as admusr.</p> <ul style="list-style-type: none"> Refer to [5] to activate Map-Diameter Interworking (MAP-IWF) Refer to [7] to activate Policy and Charging Application (PCA) -(Oracle X5-2/Netra X5-2/HP DL380 Gen 9 ONLY) <p>Note: While running the activation script, the following error message (and corresponding messages) output may be seen, this can safely be ignored:</p> <pre>iLoad#31000{S/W Fault}</pre>

Procedure 5: Recovery Scenario 5

8	DR-NOAM VIP: <input type="checkbox"/> Copy key file to recovered NOAM servers in Topology (RADIUS Only)	<p>If the RADIUS key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to any of the Active DR NOAM which is intact and operational. Login as admusr.</p> <p>Execute following commands to check if existing Key file on Active DR NOAM server is valid :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -validate</pre> </div> <p>Note: If errors are present, stop and contact My Oracle Support (MOS)</p> <p>If key file is valid, Execute following commands to copy Key file from Active DR NOAM server to recovered NOAMs :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$./sharedKrevo -copyKey -destServer <First NOAM> \$./sharedKrevo -copyKey -destServer <Second NOAM></pre> </div>						
9	Primary NOAM: <input type="checkbox"/> Modify DSR OAM process	<p>Establish an SSH session to the primary NOAM, login as admusr.</p> <p>Execute the following commands:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>Retrieve the cluster ID of the recovered NOAM:</p> <pre>\$ sudo iqt -fClusterID TopologyMapping where "NodeID='<DR_NOAM_Host_Name>'"</pre> <table style="margin-left: 40px; border-collapse: collapse;"> <tr> <td style="padding-right: 20px;">Server_ID</td> <td style="padding-right: 20px;">NodeID</td> <td style="padding-right: 20px;">ClusterID</td> </tr> <tr> <td>1</td> <td>Oahu-DSR-NOAM-2</td> <td style="background-color: yellow;">A1055</td> </tr> </table> <p>Execute the following command to start the DSR OAM process on the recovered NOAM:</p> <pre>\$ echo "<clusterID> DSROAM_Proc Yes" iload -ha -xun -fcluster -fresource -foptional HaClusterResourceCfg</pre> </div>	Server_ID	NodeID	ClusterID	1	Oahu-DSR-NOAM-2	A1055
Server_ID	NodeID	ClusterID						
1	Oahu-DSR-NOAM-2	A1055						
10	<input type="checkbox"/> Switch DR NOAM Back to Secondary	<p>Once the system has been recovered:</p> <p>Execute Appendix D to have the recovered NOAM become primary again.</p>						

Procedure 5: Recovery Scenario 5

11 <input type="checkbox"/>	<p>NOAM VIP: Verify all servers in Topology are accessible (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p>
		<p>Establish an SSH session to the NOAM VIP. Login as admusr. Execute following commands to check if all the servers in the Topology are accessible :</p>
		<pre>\$ cd /usr/TKLC/dsr/bin/ \$./sharedKrevo -checkAccess</pre>
		<p>Note: If any of the servers are not accessible, stop and contact My Oracle Support (MOS)</p>
12 <input type="checkbox"/>	<p>NOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>Establish an SSH session to the Active NOAM, login as admusr. Execute following command to copy the key file to all the servers in the Topology :</p>
		<pre>\$./sharedKrevo -synchronize \$./sharedKrevo -updateData</pre>
		<p>Note: If errors are present, stop and contact My Oracle Support (MOS)</p>
13 <input type="checkbox"/>	<p>Recovered Servers: Verify Alarms</p>	<p>Navigate to Main Menu -> Alarms & Events -> View Active</p> 
		<p>Verify the recovered servers are not contributing to any active alarms (Replication, Topology misconfiguration, database impairments, NTP, etc.)</p>
14 <input type="checkbox"/>	<p>Recover IDIH (If Configured)</p>	<p>If any components of IDIH were affected, refer to Section 7.0 to perform the disaster recovery on IDIH.</p>

5.1.6 Recovery Scenario 6 (Database Recovery)

5.1.6.1 Recovery Scenario 6: Case 1


For a partial outage with

- Server having a corrupted database
- Replication channel from parent is inhibited because of upgrade activity or
- Server is in a different release then that of its Active parent because of upgrade activity.
- Verify that the Server Runtime backup files, performed at the start of the upgrade, are present in /var/TKLC/db/filemgmt area in the following format
 - Backup.DSR.HPC02-NO2.FullDBParts.NETWORK_OAMP.20140524_223507.UPG.tar.bz2
 - Backup.DSR.HPC02-NO2.FullRunEnv.NETWORK_OAMP.20140524_223507.UPG.tar.bz2

Note: During recovery, the corrupted Database will get replaced by the sever Runtime backup. Any configuration done after taking the backup will not be visible post recovery.

Note: Corrupt databases on the SOAM will replicate to all SOAMs in its Network Element (Active, Standby, and Spare). It may be necessary to perform this recovery procedure on ALL SOAMs.


Procedure 6: Recovery Scenario 6 (Case 1)

S T E P #	<p>This procedure performs recovery if database is corrupted in the system</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Workarounds	Refer to Appendix I to understand any workarounds required during this procedure.
2 <input type="checkbox"/>	NOAM VIP GUI: Set Failed Servers to Standby	<p>Navigate to Main Menu -> Status & Manage -> HA</p>  <p>Select Edit</p> <p>Set the Max Allowed HA Role drop down box to Standby for the failed servers.</p> <p>Select Ok</p> 

Procedure 6: Recovery Scenario 6 (Case 1)

3 <input type="checkbox"/>	Server Being Recovered: Login	Establish an SSH session to the server in question. Login as admusr
4 <input type="checkbox"/>	Server Being Recovered: Change runlevel to 3	Execute the following command to bring the system to runlevel 3. <code>\$ sudo init 3</code>
5 <input type="checkbox"/>	Server Being Recovered: Recover System	Execute the following command and follow the instructions appearing the console prompt <code>\$ sudo /usr/TKLC/appworks/sbin/backout_restore</code>
6 <input type="checkbox"/>	Server Being Recovered: Change runlevel to 4	Execute the following command to bring the system back to runlevel 4. <code>\$ sudo init 6</code>
7 <input type="checkbox"/>	Server Being Recovered: Verify the server	Execute the following command to verify if the processes are up and running <code>\$ sudo pm.getprocs</code> Example Output: <pre>A 5139 cmha Up 12/21 13:16:25 1 cmha A 5140 cmplatalarm Up 12/21 13:16:25 1 cmplatalarm A 5143 cmsnmpsa Up 12/21 13:16:25 1 cmsnmpsa -R 1.3.6.1.4.1.3 23.5.3.28.1 A 5145 cmsoapa Up 12/21 13:16:25 1 cmsoapa A 9969 eclipseHelp Up 12/21 13:16:39 1 eclipseHelp A 5149 idbsvc Up 12/21 13:16:25 1 idbsvc -M10 -ME204 -D40 - DE820 -W1 -S2 A 6149 idbunlock Up 12/21 13:16:36 1 idbunlock -f A 5151 inetmerge Up 12/21 13:16:25 1 inetmerge A 5155 inetrep Up 12/21 13:16:25 1 inetrep A 5160 oampAgent Up 12/21 13:16:25 1 oampAgent A 5164 pm.watchdog Up 12/21 13:16:25 1 pm.watchdog A 5167 raclerk Up 12/21 13:16:25 1 raclerk -r 6000 A 5171 re.portmap Up 12/21 13:16:25 1 re.portmap -c100 A 5174 statclerk Up 12/21 13:16:25 1 statclerk -s -0 A 5177 vipmgr Up 12/21 13:16:25 1 vipmgr A -1 AstateInit Done 12/21 13:16:36 1 AstateInit A -1 auditPTask Done 12/21 13:16:36 1 auditPeriodicTask A -1 auditTasks Done 12/21 13:16:36 1 auditDefunctTasks A -1 guiReqMapLoad Done 12/21 13:16:25 1 guiReqMapLoad A -1 mkdbhooks Done 12/21 13:16:25 1 mkdbhooks [root@MP-1 admusr]#</pre>

Procedure 6: Recovery Scenario 6 (Case 1)

8	NOAM VIP GUI: <input type="checkbox"/> Set Failed Servers to Active	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>For each failed server whose Max Allowed HA Role is set to Standby, set it to Active</p> <p>Press OK</p>
9	NOAM VIP: <input type="checkbox"/> Verify all servers in Topology are accessible (RADIUS Only)	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to the NOAM VIP. Login as admusr.</p> <p>Execute following commands to check if all the servers in the Topology are accessible :</p> <div data-bbox="491 1121 1396 1649" style="border: 1px solid black; padding: 10px;"> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -checkAccess [admusr@NOAM-2 bin]\$./sharedKrevo -checkAccess FIPS integrity verification test failed. 1450723797: [INFO] 'NOAM-1' is accessible. FIPS integrity verification test failed. 1450723797: [INFO] 'SOAM-1' is accessible. FIPS integrity verification test failed. 1450723797: [INFO] 'SOAM-2' is accessible. FIPS integrity verification test failed. 1450723798: [INFO] 'IPFE' is accessible. FIPS integrity verification test failed. 1450723798: [INFO] 'MP-2' is accessible. FIPS integrity verification test failed. 1450723798: [INFO] 'MP-1' is accessible. [admusr@NOAM-2 bin]\$</pre> </div>

Procedure 6: Recovery Scenario 6 (Case 1)

<p>10 <input type="checkbox"/> NOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Execute following commands to check if existing Key file on Active NOAM (The NOAM which is intact and was not recovered) server is valid :</p> <pre>\$./sharedKrevo -validate</pre> <div style="background-color: black; color: white; padding: 10px;"> [admusr@NOAM-2 bin]\$./sharedKrevo -validate FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723843: [INFO] Key file for 'NOAM-1' is valid 1450723843: [INFO] Key file for 'NOAM-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723844: [INFO] Key file for 'SOAM-1' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723845: [INFO] Key file for 'SOAM-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723845: [INFO] Key file for 'IPFE' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723846: [INFO] Key file for 'MP-2' is valid FIPS integrity verification test failed. FIPS integrity verification test failed. 1450723847: [INFO] Key file for 'MP-1' is valid [admusr@NOAM-2 bin]\$</div> <p>If output of above command shows that the existing key file is not valid, contact My Oracle Support (MOS)</p> <p>Execute following command to copy the key file to all the servers in the Topology :</p> <pre>\$./sharedKrevo -synchronize</pre> <div style="background-color: black; color: white; padding: 10px;"> FIPS integrity verification test failed. 1450722733: [INFO] Synced key to IPFE FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722734: NOAM-2 and MP-2 key files differ. Sync NOAM-2 key file to MP-2. FIPS integrity verification test failed. 1450722735: [INFO] Synced key to MP-2 FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722736: NOAM-2 and MP-1 key files differ. Sync NOAM-2 key file to MP-1. FIPS integrity verification test failed. 1450722738: [INFO] Synced key to MP-1 [admusr@NOAM-2 bin]\$</div> <pre>\$./sharedKrevo -updateData</pre> <div style="background-color: black; color: white; padding: 10px;"> [admusr@NOAM-1 bin]\$./sharedKrevo -updateData 1450203518: [INFO] Updating data on server 'NOAM-1' 1450203519: [INFO] Data updated to 'NOAM-1' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203520: [INFO] Updating data on server 'SOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203522: [INFO] 1 rows updated on 'SOAM-2'... 1450203522: [INFO] Data updated to 'SOAM-2'</div> <p>Note: If any errors are present, stop and contact My Oracle Support (MOS) E56227-03</p>
Page 146	

Procedure 6: Recovery Scenario 6 (Case 1)


11	<input type="checkbox"/> Backup and Archive All the Databases from the Recovered System	Execute Appendix A to back up the Configuration databases:
----	--	---

5.1.6.2 Recovery Scenario 6: Case 2



For a partial outage with

- Server having a corrupted database
- Replication channel is not inhibited or
- Server has the same release as that of its Active parent

Procedure 7: Recovery Scenario 6 (Case 2)

S T E P #	<p>This procedure performs recovery if database got corrupted in the system and system is in the state to get replicated</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1 <input type="checkbox"/>	<p>Workarounds</p> <p>Refer to Appendix I to understand any workarounds required during this procedure.</p>
2 <input type="checkbox"/>	<p>NOAM VIP GUI:</p> <p>Set Failed Servers to Standby</p> <p>Navigate to Main Menu -> Status & Manage -> HA</p>  <p>Select Edit</p> <p>Set the Max Allowed HA Role drop down box to Standby for the failed servers.</p> <p>Select Ok</p> <p>Ok Cancel</p>
3 <input type="checkbox"/>	<p>Server in Question: Login</p> <p>Establish an SSH session to the server in question. Login as admusr</p>
4 <input type="checkbox"/>	<p>Server in Question: Take Server out of Service</p> <p>Execute the following command to take the server out of service.</p> <pre>\$ sudo bash -l \$ sudo prod.clobber</pre>
5 <input type="checkbox"/>	<p>Server in Question: Take Server to DbUp State and Start the Application</p> <p>Execute the following commands to take the server to Dbup and start the DSR application:</p> <pre>\$ sudo bash -l \$ sudo prod.start</pre>

Procedure 7: Recovery Scenario 6 (Case 2)

6	<p>Server in Question: <input type="checkbox"/> Verify the Server State</p>	<p>Execute the following commands to verify the processes are up and running:</p> <pre>\$ sudo pm.getprocs</pre> <p>Execute the following command to verify if replication channels are up and running:</p> <pre>\$ sudo irepstat</pre> <p>Execute the following command to verify if merging channels are up and running:</p> <pre>\$ sudo inetmstat</pre>
7	<p>NOAM VIP GUI: <input type="checkbox"/> Restart DSR application</p>	<p>Navigate to Main Menu->Status & Manage->Server,</p>  <p>Select each recovered server and click on Restart.</p> <p>Stop Restart Reboot NTP Sync Report</p>
8	<p>NOAM VIP GUI: <input type="checkbox"/> Set Failed Servers to Active</p>	<p>Navigate to Status & Manage -> HA</p>  <p>Click on Edit at the bottom of the screen</p> <p>For each failed server whose Max Allowed HA Role is set to Standby, set it to Active</p> <p>Press OK</p>

Procedure 7: Recovery Scenario 6 (Case 2)

9 <input type="checkbox"/>	NOAM VIP: Verify all servers in Topology are accessible (RADIUS Only)	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Establish an SSH session to the NOAM VIP. Login as admusr.</p> <p>Execute following commands to check if all the servers in the Topology are accessible :</p> <div data-bbox="491 530 1062 593" style="border: 1px solid black; padding: 5px;"><pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -checkAccess</pre></div>
-------------------------------	---	---

Procedure 7: Recovery Scenario 6 (Case 2)

<p>10 <input type="checkbox"/> NOAM VIP: Copy key file to all the servers in Topology (RADIUS Only)</p>	<p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Execute following commands to check if existing Key file on Active NOAM (The NOAM which is intact and was not recovered) server is valid :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ cd /usr/TKLC/dpi/bin/ \$./sharedKrevo -validate</pre> </div> <p>If output of above command shows that the existing key file is not valid, contact My Oracle Support (MOS)</p> <p>Execute following command to copy the key file to all the servers in the Topology :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$./sharedKrevo -synchronize</pre> <div style="background-color: black; color: white; padding: 10px; margin-top: 10px;"> <pre>FIPS integrity verification test failed. FIPS integrity verification test failed. FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722733: [INFO] Synced key to IPFE FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722734: NOAM-2 and MP-2 key files differ. Sync NOAM-2 key file to MP-2. FIPS integrity verification test failed. 1450722735: [INFO] Synced key to MP-2 FIPS integrity verification test failed. FIPS integrity verification test failed. 1450722736: NOAM-2 and MP-1 key files differ. Sync NOAM-2 key file to MP-1. FIPS integrity verification test failed. 1450722738: [INFO] Synced key to MP-1 [admusr@NOAM-2 bin]\$</pre> </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$./sharedKrevo -updateData</pre> <div style="background-color: black; color: white; padding: 10px; margin-top: 10px;"> <pre>[admusr@NOAM-1 bin]\$./sharedKrevo -updateData 1450203518: [INFO] Updating data on server 'NOAM-1' 1450203519: [INFO] Data updated to 'NOAM-1' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203520: [INFO] Updating data on server 'SOAM-2' FIPS integrity verification test failed. FIPS integrity verification test failed. 1450203522: [INFO] 1 rows updated on 'SOAM-2'... 1450203522: [INFO] Data updated to 'SOAM-2'</pre> </div> </div>
<p>Note: If any errors are present, stop and contact My Oracle Support (MOS)</p>	

Procedure 7: Recovery Scenario 6 (Case 2)

11	<input type="checkbox"/> Backup and Archive All the Databases from the Recovered System	Execute Appendix A to back up the Configuration databases:
----	--	---

6.0 Resolving User Credential Issues after Database Restore

User incompatibilities may introduce security holes or prevent access to the network by administrators. User incompatibilities are not dangerous to the database, however. Review each user difference carefully to ensure that the restoration will not impact security or accessibility.

6.1 Restoring a Deleted User

```
- User 'testuser' exists in the selected backup file but not in the current database.
```


These users were removed prior to creation of the backup and archive file. They will be reintroduced by system restoration of that file.

6.2 Keeping a Restored user

Procedure 8: Keep Restored User

S T E P #	Perform this procedure to keep users that will be restored by system restoration. Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number. If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.
1 <input type="checkbox"/>	Before Restoration: Notify Affected Users Before Restoration Contact each user that is affected before the restoration and notify them that you will reset their password during this maintenance operation.
2 <input type="checkbox"/>	After Restoration: Login to the NOAM VIP Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of: http://<Primary_NOAM_VIP_IP_Address> Login as the guiadmin user:  The page shows the Oracle System Login interface. At the top is the red "ORACLE" logo. Below it is the text "Oracle System Login" and the date "Fri Mar 20 12:29:52 2015 EDT". A central box is titled "Log In" with the sub-instruction "Enter your username and password to log in". It contains fields for "Username" (set to "guiadmin") and "Password" (set to "*****"). There is a "Change password" link and a "Log In" button. Below the login form is a welcome message: "Welcome to the Oracle System Login." A note below states: "Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies." At the bottom is a copyright notice: "Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners."

Procedure 8: Keep Restored User



3 <input type="checkbox"/> After Restoration: Reset User Passwords	<p>Navigate to Administration -> Access Control -> Users</p>  <p>Select the user</p> <p>Click the Change Password button</p> <p>Enter a new password</p> <p>Enter the new password for guiadmin two times.</p> <p>New Password: <input type="text"/></p> <p>Retype New Password: <input type="text"/></p> <p><input checked="" type="checkbox"/> Force password change on next login</p> <p>Continue</p> <p>Click the Continue button</p>
--	---

6.3 Removing a Restored User

Procedure 9: Remove the Restored User

S T E P #	<p>Perform this procedure to remove users that will be restored by system restoration</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1 <input type="checkbox"/> After Restoration: Login to the NOAM VIP	<p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <p><code>http://<Primary_NOAM_VIP_IP_Address></code></p> <p>Login as the guiadmin user:</p>  <p>The screenshot shows the Oracle System Login page. At the top, it says "Fri Mar 20 12:29:52 2015 EDT". Below that is a "Log In" box with the instruction "Enter your username and password to log in". It has fields for "Username: guiadmin" and "Password: [REDACTED]". There is a "Change password" link and a "Log In" button. Below the box, it says "Welcome to the Oracle System Login." and "Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies." At the bottom, there is a note: "Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners."</p>

Procedure 9: Remove the Restored User

2	<p>After Restoration: <input type="checkbox"/> Delete User</p>	<p>Navigate to Administration -> Access Control -> Users</p>  <p>Select the user</p> <p>Click the Delete button</p>  <p>Delete selected users?</p>  <p>Click the OK button to confirm.</p>
---	---	---

6.4 Restoring a Modified User

These users have had a password change prior to creation of the backup and archive file. The will be reverted by system restoration of that file.

- The password for user 'testuser' differs between the selected backup file and the current database.

Before Restoration:

Verify that you have access to a user with administrator permissions that is not affected.

Contact each user that is affected and notify them that you will reset their password during this maintenance operation.

After Restoration:

Log in and reset the passwords for all users in this category. See the steps in **Procedure 8** for resetting passwords for a user.

6.5 Restoring an Archive that does not contain a Current User

These users have been created after the creation of the backup and archive file. The will be deleted by system restoration of that file.



```
- User 'testuser' exists in current database but not in the selected backup file.
```

If the user is no longer desired, do not perform any additional steps. The user is permanently removed.



Procedure 10: Restoring an Archive that does not Contain a Current User

S T E P #	Perform this procedure to remove users that will be restored by system restoration	
	Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.	
	If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.	
1 <input type="checkbox"/> Before Restoration: Notify Affected Users Before Restoration	Contact each user that is affected before the restoration and notify them that you will reset their password during this maintenance operation.	
2 <input type="checkbox"/> Before Restoration: Login to the NOAM VIP	Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of: <a href="http://<Primary_NOAM_VIP_IP_Address>">http://<Primary_NOAM_VIP_IP_Address> Login as the guiadmin user:  Oracle System Login Fri Mar 20 12:29:52 2015 EDT <div style="border: 1px solid #ccc; padding: 10px; width: 300px; margin: 20px auto;"><p style="text-align: center;">Log In Enter your username and password to log in</p><p style="text-align: center;">Username: <input type="text" value="guiadmin"/></p><p style="text-align: center;">Password: <input type="password" value="*****"/></p><p style="text-align: center;"><input type="checkbox"/> Change password</p><p style="text-align: center;">Log In</p></div> <p style="text-align: center;">Welcome to the Oracle System Login.</p> <p style="text-align: center;">Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p style="text-align: center;"><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>	

Procedure 10: Restoring an Archive that does not Contain a Current User

3	<p>Before Restoration:</p> <p><input type="checkbox"/> Record user settings</p>	<p>Navigate to Administration -> Access Control -> Users</p>  <p>Under each affected user, record the following:</p> <ul style="list-style-type: none"> • Username, • Account status • Remote Auth • Local Auth • Concurrent Logins Allowed • Inactivity Limit • Comment • Groups
4	<p>After Restoration:</p> <p><input type="checkbox"/> Login</p>	<p>Establish a GUI session on the NOAM server by using the VIP IP address of the NOAM server. Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <a href="http://<Primary_NOAM_VIP_IP_Address>">http://<Primary_NOAM_VIP_IP_Address> </div> <p>Login as the guiadmin user:</p>  <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</p>

Procedure 10: Restoring an Archive that does not Contain a Current User

<p>5</p> <p><input type="checkbox"/> After Restoration: Recreate affected user</p>	<p>Navigate to Administration -> Access Control -> Users</p>  <p>Click Insert</p> <p>Recreate the user using the data collected in Step 3.</p>  <p>Click Ok</p>
<p>6</p> <p><input type="checkbox"/> After Restoration: Repeat for Additional Users</p>	<p>Repeat Step 5 to recreate additional users.</p>
<p>7</p> <p><input type="checkbox"/> After Restoration: Reset the Passwords</p>	<p>See Procedure 8 for resetting passwords for a user.</p>

7.0 IDIH Disaster Recovery

The fdconfig xml file you use for disaster recovery is different from the one used for fresh installation. The one for disaster recovery has **hostname-upgrade_xx-xx-xx.xml** file format. It took out the oracle server installation part since for disaster recovery it is not needed. If the disaster recovery procedure is being executed on the rack mount server containing the Oracle database, the fdconfig installation xml file used

Note: the fdconfig xml file for disaster recovery is exactly the same as the one for upgrade and this file should have been created during the latest upgrade or fresh installation. In case the file is not found, make a copy of the fdconfig.xml file for fresh installation with “-upgrade” between the hostname and the version number. Edit the newly created **hostname-upgrade_xx-xx-xx.xml** file and take out the following section within the dotted line:

```
</infrastructure>
</infrastructures>
<servers>
.....
<tvoeguest id="ORA">
  <infrastructure>localPMAC</infrastructure>
  </postdeploy>
  </scripts>
</tvoeguest>
.....
<tvoeguest id="MED">
  <infrastructure>localPMAC</infrastructure>
  <!--Specify which Rack Mount Server TVOE Host the Mediation server will be placed -->
  <tvoehost>mgmtsvrtvoe2</tvoehost>
  <name>MED</name>
```


Disaster Recovery Scenarios:

Disaster Recovery Scenario	fdconfig file to use
Server containing Oracle database server	Install fdconfig xml
Server containing Application Server	Upgrade/Disaster Recovery xml
Server containing Mediation Server	Upgrade/Disaster Recovery xml


Procedure 11: IDIH Disaster Recovery Preparation

S T E P #	<p>This procedure performs disaster recovery preparation steps for the IDIH.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	PMAC GUI: Login	<p>Open web browser and enter:</p> <p><a href="http://<PMAC_Mgmt_Network_IP>">http://<PMAC_Mgmt_Network_IP></p> <p>Login as pmacadmin user:</p>
2 <input type="checkbox"/>	PMAC GUI: Verify necessary IDIH images are available	<p>Navigate to Main Menu -> Software -> Manage Software Images</p> <p>Verify the current IDIH TVOE, TPD, Oracle, Application and Mediation images are listed.</p> <p>Verify these values match the name in the <code><software> </software></code> section in the <code>hostname-upgrade_xx-xx-xx.xml</code> file.</p> <p>Note: If the necessary software images are not available please follow the instructions from reference [8].</p>
3 <input type="checkbox"/>	Oracle Guest: Login	Establish an SSH session to the Oracle guest, login as admusr .


Procedure 11: IDIH Disaster Recovery Preparation

4	<p>Oracle Guest: Perform Database Health check</p>	<p>Execute the following command to perform a database health check:</p> <pre>\$ sudo /usr/TKLC/xIH/plat/bin/analyze_server.sh -i</pre> <p>Output:</p>  <pre>[admusr@thunderbolt-ora ~]\$ sudo /usr/TKLC/xIH/plat/bin/analyze_server.sh -i 10:10:52: STARTING HEALTHCHECK PROCEDURE 10:10:52: date: 05-12-15, hostname: thunderbolt-ora 10:10:52: TPD VERSION: 7.0.1.0.0-86.20.0 10:10:52: ----- 10:10:52: Checking disk free space 10:10:52: No disk space issues found 10:10:52: Checking syscheck - this can take a while 10:10:58: No errors in syscheck modules 10:10:58: Checking Alarm Manager alarmStatus 10:11:00: No alarms found 10:11:00: Checking statefiles 10:11:00: Statefiles do not exist 10:11:00: Checking runlevel 10:11:00: Runlevel is OK (N 4) 10:11:00: Checking upgrade log 10:11:00: Install logs are free of errors 10:11:00: Analyzing date 10:11:00: NTP deamon is running 10:11:00: Server is synchronized with ntp server 10:11:00: Checking NTP status 10:11:00: tvoe-host is integrated 10:11:00: Ntp settings is OK 10:11:00: Checking server entries in host file. 10:11:00: oracle is present in /etc/hosts 10:11:00: mediation is present in /etc/hosts 10:11:00: appserver is present in /etc/hosts 10:11:00: Ping server entries in host file. 10:11:00: Ping server oracle 10:11:00: Ping server mediation 10:11:00: Ping server appserver 10:11:00: Check oracle Server 10:11:01: Oracle server and resources online 10:11:01: All tests passed! 10:11:01: ENDING HEALTHCHECK PROCEDURE WITH CODE 0 [admusr@thunderbolt-ora ~]\$</pre>
---	---	--



Procedure 12: IDIH Disaster Recovery (Re-Install Mediation and Application Servers)

S T E P #	<p>This procedure performs disaster recovery for the IDIH by re-installing the mediation and application servers.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1 <input type="checkbox"/>	<p>PMAC GUI: Login</p> <p>Open web browser and enter:</p> <p><a href="http://<PMAC_Mgmt_Network_IP>">http://<PMAC_Mgmt_Network_IP></p> <p>Login as pmacadmin user:</p>  <p>ORACLE®</p> <p>Oracle System Login</p> <p>Tue Mar 17 13:49:25 2015 UTC</p> <p>Log In</p> <p>Enter your username and password to log in</p> <p>Username: pmacadmin</p> <p>Password: *****</p> <p><input type="checkbox"/> Change password</p> <p>Log In</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</p> <p>Copyright © 2010, 2015, Oracle and/or its affiliates. All rights reserved.</p>
2 <input type="checkbox"/>	<p>Remove existing Application Server</p> <p>Navigate to Main Menu -> VM Management</p>  <p>Select the application guest,</p> <p>Click on the Delete button.</p> 

Procedure 12: IDIH Disaster Recovery (Re-Install Mediation and Application Servers)

3 <input type="checkbox"/>	Remove existing Mediation Server	<p>Navigate to Main Menu -> VM Management</p>  <p>Select the Mediation guest, Click on the Delete button.</p> 
4 <input type="checkbox"/>	PMAC: Establish SSH session and Login	Establish an SSH session to the PMAC, login as admusr .
5 <input type="checkbox"/>	PMAC: Re-install the Mediation and Application Servers	<p>Execute the following command (Enter your upgrade file) :</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ cd /var/TKLC/smac/guest-dropin \$ sudo fdconfig config --file=<hostname-upgrade_xx-xx-xx>.xml</pre> </div> <div style="text-align: center; margin-top: 20px;">  <p>Warning: If you run the fdconfig without “upgrade” in the XML filename, the database will be destroyed and you will lose all of the existing data.</p> </div>

Procedure 12: IDIH Disaster Recovery (Re-Install Mediation and Application Servers)

<input type="checkbox"/> 6	PMAC GUI: Monitor the Configuration	<p>If not already done so, establish a GUI session on the PMAC server.</p> <p>Navigate to Main Menu -> Task Monitoring</p>  <p>Monitor the IDIH configuration to completion.</p> <p>Alternatively, you can monitor the fdconfig status through the command line after executing the fdconfig command:</p> <p>Example:</p>  <pre>[admsr@bertie:~]\$ sudo fdconfig config --file=d-ray_04-21-15.xml run Config Request to start a new configuration Running d-ray_04-21-15.xml configuration Configuration file processing complete Created a deployment database file: deploy_d-ray_20150511T093944_630c.fdcdb Preparing to run the configuration steps PMAC has no in progress tasks Cabinet is already provisioned, skipping: 1 RMS is already provisioned, skipping: 10.250.36.27 Server discovery complete: [RMS ip: 10.250.36.27] Hostname for [RMS ip: 10.250.36.27] already set to d-ray skipping</pre>
----------------------------	---	--

Procedure 12: IDIH Disaster Recovery (Re-Install Mediation and Application Servers)


7 <input type="checkbox"/>	Perform CPU Pinning	<p>Configure VM CPU socket pinning on each TVOE host to optimize performance by executing procedure “<i>CPU Pinning (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only)</i>” steps 1-3 from reference [8]</p> <p>Establish an SSH session to the TVOE host of the recovered VM, login as admusr.</p> <p>Perform the following command to list the current VMs configured:</p> <div data-bbox="491 544 1421 882" style="border: 1px solid black; padding: 5px;"><pre>\$ sudo virsh list [admusr@Oahu-TVOE-1 ~]\$ sudo virsh list Id Name State -- -- -- 1 Oahu-PMAC running 14 MED running 15 ORA running 16 APP running 27 Oahu-NOAM-2 running 31 Oahu-SOAM-2 running [admusr@Oahu-TVOE-1 ~]\$</pre></div> <p>Reboot the recovered VM by executing the following command:</p> <div data-bbox="491 994 1258 1184" style="border: 1px solid black; padding: 5px;"><pre>\$ sudo virsh reboot <virsh ID> [admusr@Oahu-TVOE-1 ~]\$ sudo virsh reboot 14 Domain 14 is being rebooted [admusr@Oahu-TVOE-1 ~]\$</pre></div> <p>Repeat for each recovered VM</p>
-------------------------------	----------------------------	---

Appendix A. DSR Database Backup


Procedure 13: DSR Database Backup

S	The intent of this procedure is to back up the provision and configuration information from an NOAM or SOAM server after the disaster recovery is complete
T	Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.
E	If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.
P	
#	
1	NOAM/SOAM VIP: Login <input type="checkbox"/> Establish a GUI session on the NOAM or SOAM server by using the VIP IP address of the NOAM or SOAM server. Open the web browser and enter a URL of: http://<Primary_NOAM/SOAM_VIP_IP_Address> Login as the guiadmin user:  <p>The image shows the Oracle System Login page. At the top, the Oracle logo is displayed. Below it, the title "Oracle System Login" is shown, along with the date and time "Fri Mar 20 12:29:52 2015 EDT". A "Log In" button is visible at the bottom of the form. The page also includes a welcome message and a note about browser requirements.</p> <p>Welcome to the Oracle System Login. Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>


Procedure 13: DSR Database Backup

<p>2</p> <p><input type="checkbox"/> NOAM/SOAM VIP: Backup Configuration Data for the System</p>	<p>Navigate to Main Menu -> Status & Manage -> Database</p>  <p>Select the Active NOAM Server and Click on Backup button</p> <p>Disable Provisioning Report Inhibit Replication Backup... Compare... Restore... Man Audit Suspend Auto Audit</p> <p>Make sure that the checkboxes next to “Configuration” is checked.</p> <p>Database Backup</p> <table border="1"> <thead> <tr> <th>Field</th><th>Value</th></tr> </thead> <tbody> <tr> <td>Server: Jetta-NO-1</td><td></td></tr> <tr> <td>Select data for backup</td><td><input type="checkbox"/> Provisioning <input checked="" type="checkbox"/> Configuration</td></tr> <tr> <td>Compression</td><td><input type="radio"/> gzip <input checked="" type="radio"/> bzip2 <input type="radio"/> none*</td></tr> <tr> <td>Archive Name</td><td>Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150428_09311.*</td></tr> <tr> <td>Comment</td><td><input type="text"/></td></tr> </tbody> </table> <p>Enter a filename for the backup and press OK</p>	Field	Value	Server: Jetta-NO-1		Select data for backup	<input type="checkbox"/> Provisioning <input checked="" type="checkbox"/> Configuration	Compression	<input type="radio"/> gzip <input checked="" type="radio"/> bzip2 <input type="radio"/> none*	Archive Name	Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150428_09311.*	Comment	<input type="text"/>
Field	Value												
Server: Jetta-NO-1													
Select data for backup	<input type="checkbox"/> Provisioning <input checked="" type="checkbox"/> Configuration												
Compression	<input type="radio"/> gzip <input checked="" type="radio"/> bzip2 <input type="radio"/> none*												
Archive Name	Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150428_09311.*												
Comment	<input type="text"/>												

Procedure 13: DSR Database Backup

<p>3</p> <input type="checkbox"/>	<p>NOAM/SOAM VIP: Verify the backup file existence.</p>	<p>Navigate to Main Menu -> Status & Manage -> Files</p>  <p>Main Menu: Status & Manage -> Files</p> <p>Filter Tasks</p> <table border="1"> <thead> <tr> <th>File Name</th> </tr> </thead> <tbody> <tr><td>Backup.DSR.Jetta-NO-1.FullDBParts.NETWORK_OAMP.20150421_143846.UPC.tar.bz2</td></tr> <tr><td>Backup.DSR.Jetta-NO-1.FullRunEnv.NETWORK_OAMP.20150421_143846.UPG.tar.bz2</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150414_021511.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150415_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150416_021511.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150417_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150418_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150419_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150420_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150421_021511.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150422_021511.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150423_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150424_021511.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150425_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150426_021510.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150427_021511.AUTO.tar</td></tr> <tr><td>backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150428_021511.AUTO.tar</td></tr> </tbody> </table> <p>Select the Active NOAM or SOAM tab.</p> <p>The files on this server will be displayed. Verify the existence of the backup file.</p>	File Name	Backup.DSR.Jetta-NO-1.FullDBParts.NETWORK_OAMP.20150421_143846.UPC.tar.bz2	Backup.DSR.Jetta-NO-1.FullRunEnv.NETWORK_OAMP.20150421_143846.UPG.tar.bz2	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150414_021511.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150415_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150416_021511.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150417_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150418_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150419_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150420_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150421_021511.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150422_021511.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150423_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150424_021511.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150425_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150426_021510.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150427_021511.AUTO.tar	backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150428_021511.AUTO.tar
File Name																				
Backup.DSR.Jetta-NO-1.FullDBParts.NETWORK_OAMP.20150421_143846.UPC.tar.bz2																				
Backup.DSR.Jetta-NO-1.FullRunEnv.NETWORK_OAMP.20150421_143846.UPG.tar.bz2																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150414_021511.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150415_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150416_021511.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150417_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150418_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150419_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150420_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150421_021511.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150422_021511.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150423_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150424_021511.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150425_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150426_021510.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150427_021511.AUTO.tar																				
backup/Backup.dsr.Jetta-NO-1.Configuration.NETWORK_OAMP.20150428_021511.AUTO.tar																				

Procedure 13: DSR Database Backup

<p>4</p> <input type="checkbox"/>	<p>NOAM/SOAM VIP: Download the file to a local machine.</p>	<p>From the previous step, choose the backup file.</p> <p>Select the Download button</p> <div style="text-align: center;"> <input type="button" value="Delete"/> <input type="button" value="View"/> <input type="button" value="Upload"/> <input type="button" value="Download"/> <input type="button" value="Deploy ISO"/> <input type="button" value="Validate ISO"/> </div> <p>1.1 GB used (5.93%) of 18.4 GB available System utilization: 1.1 GB (5.99%) of 18.4 GB available.</p> <p>Select OK to confirm the download.</p> 
<p>5</p> <input type="checkbox"/>	<p>Upload the Image to Secure Location</p>	<p>Transfer the backed up image saved in the previous step to a secure location where the Server Backup files are fetched in case of system disaster recovery.</p>
<p>6</p> <input type="checkbox"/>	<p>Backup Active SOAM</p>	<p>Repeat Steps 2 through 5 to back up the Active SOAM</p>

Procedure 13: DSR Database Backup

7 <input type="checkbox"/>	<p>Take Secured backup of key file (RADIUS Only)</p> <p>If the RADIUS (DSR 7.2 Only) key has never been revoked, skip this step (If RADIUS was never configured on any site in the network, the RADIUS key would have most likely never been revoked. Check with your system administrator)</p> <p>Login to ssh shell of Active NOAM server using user admusr</p> <p>Take secure backup of updated key file “RADIUS shared secret encryption key” for disaster scenarios.</p> <p>Execute following command to encrypt the key file before being backed up to secure customer setup :</p> <div data-bbox="496 608 887 642" style="border: 1px solid black; padding: 2px;"><pre>\$./sharedKrevo -encr</pre></div> <p>Execute following command to copy the encrypted key file to secure customer setup :</p> <div data-bbox="496 777 1348 857" style="border: 1px solid black; padding: 2px;"><pre>\$ sudo scp /var/TKLC/db/filemgmt/DpiKf.bin.encr user@<customer IP>:<path of customer setup></pre></div> <p>Note: Access to backed up key file must be strictly controlled by the operator. If the operator wishes to further encrypt this key file using operator specified encryption techniques, the operator is recommended to do so, however the operator shall be responsible to decrypt this file using operator specific decryption techniques and copy the resulting DpiKf.bin.encr file securely to the file management folder if the key file needs to be restored for disaster recovery. Once the key file is backed up to the operator provided server and path, it is the responsibility of the operator to ensure access to the backed up key file is extremely selective and restricted</p>
-------------------------------	---

Appendix B. Recovering/Replacing Failed Cisco 4948 Aggregation Switches (HP DL380 Gen 8 Only)

The following procedures provide steps to recover 3rd party devices (i.e. switches). Follow the appropriate procedure as needed for your disaster recovery.

Procedure 14: Recovering a Failed Aggregation Switch (Cisco 4948E/4948E-F)- HP DL380 Only

S T E P #	<p>The intent of this procedure is to recover a failed Aggregation (4948E / 4948E-F) Switch.</p> <p>Prerequisites for this procedure are:</p> <ul style="list-style-type: none">• A copy of the networking xml configuration files• A copy of HP Misc Firmware DVD or ISO• IP address and hostname of the failed switch• Rack Mount position of the failed switch <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1 <input type="checkbox"/>	<p>Recover failed Aggregation Switches: Cisco 4948E/4948E-F</p> <p>Login to the PMAC via SSH as admusr</p> <p>Remove the old SSH key of the switch from the PMAC by executing the following command from a PMAC command shell:</p> <div style="border: 1px solid black; padding: 5px; text-align: center;"><code>sudo ssh-keygen -R <4948_switch_ip></code></div> <p>Refer to procedure “Replace a failed 4948/4948E/4948E-F switch (PM&C Installed) (netConfig)” to replace a failed Aggregation switch. - Refer [2] for the applicable platform configuration reference.</p> <p>Note: You will need a copy of the HP Misc Firmware DVD or ISO (<i>or firmware file obtained from the appropriate hardware vendor</i>) and of the original networking xml files custom for this installation. These will either be stored on the PMAC in a designation location, or the information used to populate them can be obtained from the NAPD.</p>

Appendix C. Switching DR NOAM Site to Primary

Upon the loss of a Primary DSR NOAM Site, the DR NOAM Site should become primary. The following steps are used to enable such switchover.



Preconditions:

- User cannot access the primary DSR
- User still can access the DR DSR
- Provisioning clients are disconnected from the primary DSR
- Provisioning has stopped


Procedure 19: Switching a DR NOAM Site to Primary

S T E P #	<p>The intent of this procedure is to switch a DR site to Primary.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1 <input type="checkbox"/>	<p>DR-NOAM VIP: Login</p> <p>Establish a GUI session on the DR-NOAM server by using the VIP IP address of the DR-NOAM.</p> <p>Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"><a href="http://<Primary_DR_NOAM_VIP_IP_Address>">http://<Primary_DR_NOAM_VIP_IP_Address></div> <p>Login as the guiadmin user:</p>




Procedure 19: Switching a DR NOAM Site to Primary

2	<p>DR-NOAM VIP: <input type="checkbox"/> Disable DSR Application on DR-NOAM Servers</p>	<p>Navigate to Main Menu -> Status & Manage -> Server</p>  <p>Select the row that has the Active DR-NOAM server.</p> <p>Select the Stop button.</p>  <p>Note: At this time, HA switch over causes an automatic logout.</p>
3	<p>DR-NOAM VIP: <input type="checkbox"/> Login</p>	<p>Establish a GUI session on the DR-NOAM server by using the VIP IP address of the DR-NOAM.</p> <p>Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <a href="http://<Primary_DR_NOAM_VIP_IP_Address>">http://<Primary_DR_NOAM_VIP_IP_Address> </div> <p>Login as the guiadmin user:</p>  <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>

Procedure 19: Switching a DR NOAM Site to Primary

4	DR-NOAM VIP: Repeat	Repeat step 2 to disable the DSR application on the now active DR NOAM. Note: The DSR application should now be stopped on all DR-NOAMs.								
5	DR-NOAM VIP: Verify DSR application is stopped.	Verify that “ PROC ” column on both DR DSR servers show “ Man ” indicating that application is manually stopped								
6	Primary DR-NOAM: Establish an SSH session	Login via SSH to the physical IP of the chosen primary DR-NOAM server as admusr								
7	Primary DR-NOAM: Change Role to Primary	Execute the command <div style="border: 1px solid black; padding: 2px;">\$ sudo top.setPrimary</div> Note: This step makes the DR DSR take over as the Primary. Execute the following command to verify the role was changed to primary: <div style="border: 1px solid black; padding: 2px;">\$ sudo top.myrole</div> System generates several replication and collection alarms as replication/collection links to/from former Primary NOAM servers becomes inactive.								
8	Primary DR-NOAM: Verify Replication	Navigate to Main Menu -> Status & Manage -> Server  It may take several minutes for replication; afterward the “ DB ” and “ Reporting Status ” columns should show “ Normal ”. <table border="1" data-bbox="489 1552 938 1700"> <thead> <tr> <th>DB</th> <th>Reporting Status</th> </tr> </thead> <tbody> <tr> <td>Norm</td> <td>Norm</td> </tr> <tr> <td>Norm</td> <td>Norm</td> </tr> <tr> <td>Norm</td> <td>Norm</td> </tr> </tbody> </table>	DB	Reporting Status	Norm	Norm	Norm	Norm	Norm	Norm
DB	Reporting Status									
Norm	Norm									
Norm	Norm									
Norm	Norm									

Procedure 19: Switching a DR NOAM Site to Primary

9	<p>New Primary NOAM: Re-enable the application.</p>	<p>Navigate to Main Menu -> Status & Manage -> Server</p>  <p>Select the row that has the active New-Primary NOAM server.</p> <p>Click the Restart button and then click the OK button.</p> <p>Stop Restart Reboot NTP Sync Report</p> <p>Verify that “PROC” column now shows “Norm”.</p>  <p>Provisioning can now resume to the VIP of the new-Primary DSR.</p>
10	<p>New Primary NOAM: Decrease the Durability Admin status</p>	<p>SDS ONLY, DSR SKIP THIS STEP</p> <p>Lower the durability admin status to (NOAM pair) to exclude former-Primary NOAM servers from the provisioning database durability.</p> <p>If a value other than 1 has been configured for “cm.idb.durableAdminState” , record this value for future reference upon restoring the failed NOAMs</p> <p>Navigate to Main Menu -> Administration -> General Options</p>  <p>Set “cm.idb.durableAdminState” to 1</p>  <p>Click the OK button</p>

Procedure 19: Switching a DR NOAM Site to Primary



11	New Primary NOAM: Repeat for standby of new-primary NOAM Server	Repeat steps 8-9 for standby of the new-Primary NOAM server.
----	--	---

Appendix D. Returning a Recovered Site to Primary


Procedure 20: Returning a Recovered Site to Primary

S T E P #	<p>The intent of this procedure is to return a recovered site to primary.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>
1	<p>Primary NOAM VIP: Login</p> <p>Establish a GUI session on the primary NOAM server by using the VIP IP address of the primary NOAM.</p> <p>Open the web browser and enter a URL of:</p> <p><code>http://<Primary_NOAM_VIP_IP_Address></code></p> <p>Login as the guiadmin user:</p> <p>ORACLE®</p> <p>Oracle System Login</p> <p>Fri Mar 20 12:29:52 2015 EDT</p> <p>Log In</p> <p>Enter your username and password to log in</p> <p>Username: <input type="text" value="guiadmin"/></p> <p>Password: <input type="password" value="*****"/></p> <p><input type="checkbox"/> Change password</p> <p>Log In</p> <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</p>

Procedure 20: Returning a Recovered Site to Primary

2	<p>Primary NOAM VIP: Disable DSR Application on DR-NOAM Servers</p>	<p>Navigate to Main Menu -> Status & Manage -> Server</p>  <p>Select the row that has the Active DR-NOAM server.</p> <p>Select the Stop button.</p>  <p>Note: At this time, HA switch over causes an automatic logout.</p>
3	<p>Primary NOAM VIP: Login</p>	<p>Establish a GUI session on the primary NOAM server by using the VIP IP address of the NOAM.</p> <p>Open the web browser and enter a URL of:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <a href="http://<Primary_NOAM_VIP_IP_Address>">http://<Primary_NOAM_VIP_IP_Address> </div> <p>Login as the guiadmin user:</p>  <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>

Procedure 20: Returning a Recovered Site to Primary

4 <input type="checkbox"/>	Primary NOAM VIP: Repeat	Repeat step 2 to disable the DSR application on the now active DR NOAM. Note: The DSR application should now be stopped on all DR-NOAMs.								
5 <input type="checkbox"/>	Primary NOAM VIP: Verify DSR application is stopped.	Verify that “ PROC ” column on both DR DSR servers show “ Man ” indicating that application is manually stopped								
6 <input type="checkbox"/>	Primary NOAM VIP: Establish an SSH session	Login via SSH to the physical IP of the chosen primary DR-NOAM server as admusr								
7 <input type="checkbox"/>	Primary NOAM VIP: Change Role to Secondary	Execute the command <div style="border: 1px solid black; padding: 5px;"><pre>\$ sudo top.setSecondary</pre></div> Note: This step makes the primary NOAM to revert to DR-NOAM Execute the following command to verify the role was changed to secondary: <div style="border: 1px solid black; padding: 5px;"><pre>\$ sudo top.myrole myNodeId=A1250.249 myMasterCapable=true myMateNodeId=A1250.248 myParentCluster=00000 myClusterRole=Secondary myClusterTimestamp=02/26/16 10:00:20.047</pre></div>								
8 <input type="checkbox"/>	New DR-NOAM VIP: Verify Replication	Navigate to Main Menu -> Status & Manage -> Server  It may take several minutes for replication; afterward the “ DB ” and “ Reporting Status ” columns should show “ Normal ”. <div style="border: 1px solid black; padding: 5px;"><table border="1"><thead><tr><th>DB</th><th>Reporting Status</th></tr></thead><tbody><tr><td>Norm</td><td>Norm</td></tr><tr><td>Norm</td><td>Norm</td></tr><tr><td>Norm</td><td>Norm</td></tr></tbody></table></div>	DB	Reporting Status	Norm	Norm	Norm	Norm	Norm	Norm
DB	Reporting Status									
Norm	Norm									
Norm	Norm									
Norm	Norm									



Procedure 20: Returning a Recovered Site to Primary

9	To-Be-Primary NOAM VIP: <input type="checkbox"/> Establish an SSH session	Login via SSH to the physical IP of the chosen primary DR-NOAM server as <i>admusr</i>
10	To-Be-Primary DSR NOAM VIP: Set To-be-Primary DSR NOAM to Primary	Execute the following command: <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <code>\$ sudo top.setPrimary</code> </div> <p>Note: This step makes the DSR take over as the Primary.</p> <p>Execute the command to verify the server role was changed to Primary:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <code>\$ sudo top.myrole</code> myNodeId=A1055.206 myMasterCapable=true myMateNodeId=A1055.214 myParentCluster=00000 myClusterRole=Primary myClusterTimestamp=02/26/16 10:01:52.162 </div> <p>System generates several replication and collection alarms as replication/collection links to/from former Primary NOAM servers becomes inactive.</p>


Procedure 20: Returning a Recovered Site to Primary

11 <input type="checkbox"/>	<p>Primary Active NOAM: Login</p> <p>Establish a GUI session on the primary NOAM server by using the VIP IP address of the primary NOAM.</p> <p>Open the web browser and enter a URL of:</p> <p><code>http://<Primary_NOAM_VIP_IP_Address></code></p> <p>Login as the guiadmin user:</p> <p>ORACLE®</p> <p>Oracle System Login</p> <p>Fri Mar 20 12:29:52 2015 EDT</p> <p>Log In</p> <p>Enter your username and password to log in</p> <p>Username: <input type="text" value="guiadmin"/></p> <p>Password: <input type="password" value="*****"/></p> <p><input type="checkbox"/> Change password</p> <p>Log In</p> <p>Welcome to the Oracle System Login.</p> <p>Unauthorized access is prohibited. This Oracle system requires the use of Microsoft Internet Explorer 8.0, 9.0, or 10.0 with support for JavaScript and cookies.</p> <p><small>Oracle and Java are registered trademarks of Oracle Corporation and/or its affiliates. Other names may be trademarks of their respective owners.</small></p>
--------------------------------	--

Procedure 20: Returning a Recovered Site to Primary


12	<p>New Primary NOAM VIP: Re-enable the application.</p>	<p>Navigate to Main Menu -> Status & Manage -> Server</p>  <p>Select the row that has the active new primary NOAM server.</p> <p>Click the Restart button and then click the OK button.</p> <p>Stop Restart Reboot NTP Sync Report</p> <p>Verify that “PROC” column now shows “Norm”.</p> 
13	<p>New Primary NOAM VIP:</p> <p><input type="checkbox"/> Repeat on Standby Recovered NOAM</p>	<p>Repeat Step 12 on the standby recovered primary NOAM.</p> <p>Provisioning can now resume on the VIP of the new-Primary DSR.</p>
14	<p>New Primary DSR NOAM VIP: Repeat on DR-NOAMs</p>	<p>Repeat Step 12 on the active and standby DR-NOAMs</p>
15	<p>New Primary DSR NOAM VIP: Verify Replication</p>	<p>Monitor Main Menu -> Status & Manage -> Server screen at new-Primary DSR.</p> <p>It may take several minutes for replication; afterward the “DB” and “Reporting Status” columns should show “Normal”</p> <p>Note: the inetmerge process might have to be restarted if replication is taking excessive time. To restart it, ssh to the active site NOAM and run the following command to restart the replication process:</p> <div style="border: 1px solid black; padding: 5px; text-align: center;">\$ sudo pm.kill inetmerge</div>

Procedure 20: Returning a Recovered Site to Primary

16	<p>New Primary NOAM VIP: Set Durability admin status to include DR-NOAM (Optional)</p> <p>SDS ONLY, DSR SKIP THIS STEP</p> <p>If you reduced the durability status in procedure 19, raise durability admin status to its former value</p> <p>Navigate to Main Menu -> Administration -> General Options</p>  <p>Set "durableAdminState" to its former value</p>  <p>Click the OK button</p> <p>Now new DRNOAM DSR servers are part of provisioning database durability.</p>
----	---

Appendix E. Inhibit A and B Level Replication on C-Level Servers

Procedure 21: Inhibit A and B Level Replication on C-Level Servers

S T E P #	<p>The intent of this procedure is to inhibit A and B level replication on all C Level servers of this site</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>																																																																
1 <input type="checkbox"/>	<p>Active NOAM: Login</p> <p>Login to the Active NOAM server via SSH as admusr.</p>																																																																
2 <input type="checkbox"/>	<p>Active NOAM: Inhibit replication on all C level Servers</p> <p>Execute the following command:</p> <pre>\$ for i in \$(iqgt -p -z -h -fhostName NodeInfo where "nodeId like 'C*' and siteId='<SOAM Site_NE name of the site>'"); do iset -finhibitRepPlans='A B' NodeInfo where "nodeName='\$i"'; done</pre> <p>Note: SOAM Site_NE name of the site can be found out by logging into the Active NOAM GUI and going to Configuration->Server Groups screen.</p> <p>Please see the screenshot below for more details. E.g. if ServerSO1 belongs to the site which is being recovered then sitelid will be SO_HPC03.</p> <p>Main Menu: Configuration -> Server Groups</p>  <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Server Group Name</th> <th>Level</th> <th>Parent</th> <th>Function</th> <th colspan="4">Servers</th> </tr> <tr> <th></th> <th></th> <th></th> <th></th> <th>NE</th> <th>Server</th> <th>HA Role Pref</th> <th>VPs</th> </tr> </thead> <tbody> <tr> <td>MPSG</td> <td>C</td> <td>SOSG</td> <td>DSR (multi-active cluster)</td> <td>SO_HPC03</td> <td>ServerMP1</td> <td></td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>SO_HPC03</td> <td>ServerMP2</td> <td></td> <td></td> </tr> <tr> <td>NOSG</td> <td>A</td> <td>NONE</td> <td>DSR (active/standby pair)</td> <td>SO_HPC03</td> <td>ServerN01</td> <td>10.240.10.166</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>SO_HPC03</td> <td>ServerN02</td> <td>10.240.10.166</td> <td></td> </tr> <tr> <td>SOSG</td> <td>B</td> <td>NOSG</td> <td>DSR (active/standby pair)</td> <td>SO_HPC03</td> <td>ServerS01</td> <td>10.240.10.166</td> <td></td> </tr> <tr> <td></td> <td></td> <td></td> <td></td> <td>SO_HPC03</td> <td>ServerS02</td> <td>10.240.10.166</td> <td></td> </tr> </tbody> </table>	Server Group Name	Level	Parent	Function	Servers								NE	Server	HA Role Pref	VPs	MPSG	C	SOSG	DSR (multi-active cluster)	SO_HPC03	ServerMP1							SO_HPC03	ServerMP2			NOSG	A	NONE	DSR (active/standby pair)	SO_HPC03	ServerN01	10.240.10.166						SO_HPC03	ServerN02	10.240.10.166		SOSG	B	NOSG	DSR (active/standby pair)	SO_HPC03	ServerS01	10.240.10.166						SO_HPC03	ServerS02	10.240.10.166	
Server Group Name	Level	Parent	Function	Servers																																																													
				NE	Server	HA Role Pref	VPs																																																										
MPSG	C	SOSG	DSR (multi-active cluster)	SO_HPC03	ServerMP1																																																												
				SO_HPC03	ServerMP2																																																												
NOSG	A	NONE	DSR (active/standby pair)	SO_HPC03	ServerN01	10.240.10.166																																																											
				SO_HPC03	ServerN02	10.240.10.166																																																											
SOSG	B	NOSG	DSR (active/standby pair)	SO_HPC03	ServerS01	10.240.10.166																																																											
				SO_HPC03	ServerS02	10.240.10.166																																																											

Procedure 21: Inhibit A and B Level Replication on C-Level Servers

3 <input type="checkbox"/> Active NOAM: Verify Replication has been Inhibited.	<p>After executing above steps to inhibit replication on MP(s), no alarms on GUI would be raised informing that replication on MP/DP is disabled.</p> <p>Verification of replication inhibition on MP/DPs can be done by analyzing NodeInfo output. InhibitRepPlans field for all the MP/DP servers for the selected site e.g. Site SO_HPC03 shall be set as 'A B':</p> <p>Perform the following command:</p> <div data-bbox="489 528 734 559" style="border: 1px solid black; padding: 5px;"><pre>\$ iqt NodeInfo</pre></div> <p>Expected output:</p> <table border="1" data-bbox="489 633 1338 770"><thead><tr><th>nodeId</th><th>nodeName</th><th>hostName</th><th>nodeCapability</th><th>inhibitRepPlans</th><th>sitId</th></tr></thead><tbody><tr><td>A1386.099</td><td>NO1</td><td>NO1</td><td>Active</td><td></td><td>NO_HPC03</td></tr><tr><td>B1754.109</td><td>SO1</td><td>SO1</td><td>Active</td><td></td><td>SO_HPC03</td></tr><tr><td>C2254.131</td><td>MP2</td><td>MP2</td><td>Active</td><td>A B</td><td>SO_HPC03</td></tr><tr><td>C2254.233</td><td>MP1</td><td>MP1</td><td>Active</td><td>A B</td><td>SO_HPC03</td></tr></tbody></table>	nodeId	nodeName	hostName	nodeCapability	inhibitRepPlans	sitId	A1386.099	NO1	NO1	Active		NO_HPC03	B1754.109	SO1	SO1	Active		SO_HPC03	C2254.131	MP2	MP2	Active	A B	SO_HPC03	C2254.233	MP1	MP1	Active	A B	SO_HPC03
nodeId	nodeName	hostName	nodeCapability	inhibitRepPlans	sitId																										
A1386.099	NO1	NO1	Active		NO_HPC03																										
B1754.109	SO1	SO1	Active		SO_HPC03																										
C2254.131	MP2	MP2	Active	A B	SO_HPC03																										
C2254.233	MP1	MP1	Active	A B	SO_HPC03																										

Appendix F. Un-Inhibit A and B Level Replication on C-Level Servers

Procedure 22: Un-Inhibit A and B Level Replication on C-Level Servers

S T E P #	<p>The intent of this procedure is to Un-inhibit A and B level replication on all C Level servers of this site</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>																																
1 <input type="checkbox"/>	<p>Active NOAM: Login</p> <p>Login to the Active NOAM server via SSH as admusr user.</p>																																
2 <input type="checkbox"/>	<p>Active NOAM: Un-Inhibit replication on all C level Servers</p> <p>Execute the following command:</p> <pre>\$ for i in \$(iqt -p -z -h -fhostName NodeInfo where "nodeId like 'C*' and siteId='<SOAM_Site_NE_namee>'"); do iset -finhibitRepPlans=''' NodeInfo where "nodeName='\$i'"; done</pre> <p>Note: SOAM Site NE name of the site can be found out by logging into the Active NOAM GUI and going to Configuration->Server Groups screen.</p> <p>Please see the screenshot below for more details. E.g. if ServerSO1 belongs to the site which is being recovered then sitelid will be SO_HPC03.</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>Server Group Name</th> <th>Level</th> <th>Parent</th> <th>Function</th> <th>NE</th> <th>Server</th> <th>HA Role Pref</th> <th>VIPs</th> </tr> </thead> <tbody> <tr> <td>S0SG</td> <td>C</td> <td>S0SG</td> <td>DSR (multi-active cluster)</td> <td>SO_HPC03 SO_HPC03</td> <td>ServerIP1 ServerIP2</td> <td></td> <td></td> </tr> <tr> <td>N0SG</td> <td>A</td> <td>NONE</td> <td>DSR (active/standby pair)</td> <td>NO_HPC03 NO_HPC03</td> <td>ServerN01 ServerN02</td> <td></td> <td>10.240.10.166 10.240.10.166</td> </tr> <tr> <td>S0SG</td> <td>B</td> <td>N0SG</td> <td>DSR (active/standby pair)</td> <td>SO_HPC03 SO_HPC03</td> <td>ServerS01 ServerS02</td> <td></td> <td>10.240.10.166 10.240.10.166</td> </tr> </tbody> </table>	Server Group Name	Level	Parent	Function	NE	Server	HA Role Pref	VIPs	S0SG	C	S0SG	DSR (multi-active cluster)	SO_HPC03 SO_HPC03	ServerIP1 ServerIP2			N0SG	A	NONE	DSR (active/standby pair)	NO_HPC03 NO_HPC03	ServerN01 ServerN02		10.240.10.166 10.240.10.166	S0SG	B	N0SG	DSR (active/standby pair)	SO_HPC03 SO_HPC03	ServerS01 ServerS02		10.240.10.166 10.240.10.166
Server Group Name	Level	Parent	Function	NE	Server	HA Role Pref	VIPs																										
S0SG	C	S0SG	DSR (multi-active cluster)	SO_HPC03 SO_HPC03	ServerIP1 ServerIP2																												
N0SG	A	NONE	DSR (active/standby pair)	NO_HPC03 NO_HPC03	ServerN01 ServerN02		10.240.10.166 10.240.10.166																										
S0SG	B	N0SG	DSR (active/standby pair)	SO_HPC03 SO_HPC03	ServerS01 ServerS02		10.240.10.166 10.240.10.166																										

Procedure 22: Un-Inhibit A and B Level Replication on C-Level Servers

<p>3</p> <p><input type="checkbox"/> Active NOAM: Verify Replication has been un- Inhibited.</p>	<p>After executing above steps to un-inhibit replication on MP/DP(s), no alarms on GUI would be raised informing that replication on MP/DP is disabled.</p> <p>Verification of replication un-inhibition on MP/DPs can be done by analyzing NodeInfo output. InhibitRepPlans field for all the MP/DP servers for the selected site e.g. Site SO_HPC03 shall be set as 'A B':</p> <p>Perform the following command:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ sudo iqt NodeInfo</pre> <p>Expected output:</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <thead> <tr> <th>nodeId</th> <th>nodeName</th> <th>hostName</th> <th>nodeCapability</th> <th>inhibitRepPlans</th> <th>sitId</th> <th>excludeTables</th> </tr> </thead> <tbody> <tr> <td>A1386.099</td> <td>NO1</td> <td>NO1</td> <td>Active</td> <td></td> <td>SO_HPC03</td> <td></td> </tr> <tr> <td>B1754.109</td> <td>SO1</td> <td>SO1</td> <td>Active</td> <td></td> <td>SO_HPC03</td> <td></td> </tr> <tr> <td>C2254.131</td> <td>MP2</td> <td>MP2</td> <td>Active</td> <td></td> <td>SO_HPC03</td> <td></td> </tr> <tr> <td>C2254.233</td> <td>MP1</td> <td>MP1</td> <td>Active</td> <td></td> <td>SO_HPC03</td> <td></td> </tr> </tbody> </table> </div>	nodeId	nodeName	hostName	nodeCapability	inhibitRepPlans	sitId	excludeTables	A1386.099	NO1	NO1	Active		SO_HPC03		B1754.109	SO1	SO1	Active		SO_HPC03		C2254.131	MP2	MP2	Active		SO_HPC03		C2254.233	MP1	MP1	Active		SO_HPC03	
nodeId	nodeName	hostName	nodeCapability	inhibitRepPlans	sitId	excludeTables																														
A1386.099	NO1	NO1	Active		SO_HPC03																															
B1754.109	SO1	SO1	Active		SO_HPC03																															
C2254.131	MP2	MP2	Active		SO_HPC03																															
C2254.233	MP1	MP1	Active		SO_HPC03																															

Appendix G. Restore TVOE Configuration from Backup Media





Procedure 23: Restore TVOE Configuration from Backup Media

S T E P #	<p>This procedure provides steps to restore the TVOE application configuration from backup media.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Install TVOE Application	<ul style="list-style-type: none">• If the PMAC is NOT hosted on the failed rack mount server, follow procedure “<i>Install TVOE on Additional Rack Mount Servers</i>” from reference [8]• If the PMAC is hosted on the failed rack mount server, follow procedure “<i>Install and Configure TVOE on First RMS (PMAC Host)</i>” from reference [8]
2 <input type="checkbox"/>	Establish network connectivity	<ul style="list-style-type: none">• If the PMAC is NOT hosted on the failed rack mount server, skip this step• If the PMAC is hosted on the failed rack mount server, execute procedures “<i>Gather and Prepare Configuration files</i>” and “<i>First RMS Configuration</i>” <p>Note: The IP address that is configured on the TVOE must be one that will be accessible via the network of the machine that currently holds the TVOE Backup ISO image. This could be a NetBackup Master Server, a Customer PC, etc.</p>
3 <input type="checkbox"/>	Restore TVOE Backup ISO image to the TVOE host (NetBackup)	<p>If using NetBackup to restore the TVOE backup ISO image execute this step, otherwise skip this step</p> <ol style="list-style-type: none">1. Execute Appendix “Application NetBackup Client Installation Procedures” from reference [8]2. Interface with the NetBackup Master Server and initiate a restore of the TVOE backup ISO image. <p>Note: Once restored, the ISO image will be in <code>/var/TKLC/bkp/</code> on the TVOE server.</p>


Procedure 23: Restore TVOE Configuration from Backup Media

<p>3</p> <input type="checkbox"/>	<p>Transfer TVOE Backup ISO image to the TVOE host (NetBackup)</p>	<p>Restoring TVOE backup ISO using SCP</p> <p>Using the IP of the TVOE host, transfer the backup ISO image to the TVOE.</p> <p>Linux:</p> <p>From the command line of a Linux machine use the following command to copy the backup ISO image to the TVOE host:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre># scp <path_to_image> tvoexfer@<TVOE_IP>:backup/</pre> </div> <p>Note: where <code><path_to_image></code> is the path to the backup ISO image on the local system and <code><TVOE_IP></code> is the TVOE IP address.</p> <p>Note: If the IP is an IPv4 address then <code><TVOE_IP></code> will be a normal dot-decimal notation (e.g. “10.240.6.170”).</p> <p>Note: If the IP is an IPv6 link local address then <code><TVOE_IP></code> will be need to be scoped such as “[fe80::21e:bfःfe76:5e1c%control]” where <code>control</code> is the name of the interface on the machine that is initiating the transfer and it must be on the same link as the interface on the TVOE host.</p> <p>IPv4 Example:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre># scp /path/to/image.iso tvoexfer@10.240.6.170:backup/</pre> </div> <p>IPv6 Example:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre># scp /path/to/image.iso tvoexfer@[fe80::21e:bfःfe76:5e1c%control]:backup/</pre> </div> <p>Windows:</p> <p>Use WinSCP to copy the Backup ISO image into the backup directory within the <code>tvoexfer</code> user’s home directory. Please refer to [10] procedure <i>Using WinSCP</i> to copy the backup image to the customer system.</p>
<p>4</p> <input type="checkbox"/>	<p>TVOE Server: Login</p>	<p>Establish an SSH session to the TVOE server, login as admusr.</p>

Procedure 23: Restore TVOE Configuration from Backup Media

5	Restore TVOE Backup ISO image	Restore the TVOE backup ISO by executing the following: <pre>\$ sudo su - platcfg</pre> Navigate to Maintenance -> Backup and Restore -> Restore Platform -> Select Backup Media
		
		Select the desired archive:
		
		Select OK
		Select Restore Backup Archive
		
		Confirm restore:
		

Procedure 23: Restore TVOE Configuration from Backup Media

6	<input type="checkbox"/> Monitor TVOE Backup process	<p>Wait for the restore to complete.</p>  <p>Note: This will typically take less than 5 minutes</p> <p>Restore complete:</p> 
---	---	---

Procedure 23: Restore TVOE Configuration from Backup Media

Procedure 23: Restore TVOE Configuration from Backup Media

Appendix H. Restore PMAC from Backup


Procedure 24: Restore PMAC from Backup Media

S T E P #	<p>This procedure provides steps to restore the PMAC application configuration from backup media.</p> <p>Prerequisite: TVOE management server has been restored.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance.</p>	
1 <input type="checkbox"/>	Deploy the PMAC Guest	Execute section “ <i>Install PMAC</i> ” from reference [8]
2 <input type="checkbox"/>	PMAC: Login	Establish an SSH session to the PMAC server, login as admusr .
3 <input type="checkbox"/>	Restore PMAC Backup image to the TVOE host	<p>From the remote backup location, copy the backup file to the deployed PMAC. There are too many possible backup scenarios to cover them all here.</p> <p>The example below is a simple scp from a redundant PM&C backup location. If using IPv6 addresses, command requires shell escapes, e.g. admusr@[<ipV6addr>]:<file></p> <div style="border: 1px solid black; padding: 5px;"><pre>\$ sudo /usr/bin/scp -p \ admusr@<remoteserver>:/var/TKLC/smac/backup/*.pef \ /var/TKLC/smac/backup/</pre></div> <p>Note: It is important to copy the correct backup file to use in the restore. The latest backup may not be the backup which contains the system data of interest. This could be the case if the automatic backup, which is scheduled in the morning, is performed on the newly installed PMAC prior to the restoration of the data.</p>
4 <input type="checkbox"/>	PMAC: Verify no Alarms are present	Verify no alarms are present by executing the following command: <div style="border: 1px solid black; padding: 5px;"><pre>\$ sudo /usr/TKLC/plat/bin/alarmMgr --alarmStatus</pre></div>

Procedure 24: Restore PMAC from Backup Media

5	Restore the PMAC Data from Backup	<p>Restore the PMAC data from backup by executing the following command:</p> <pre>\$ sudo /usr/TKLC/smac/bin/pmacadm restore</pre> <p>PM&C Restore been successfully initiated as task ID 1</p> <p>To check the status of the background task, issue the following command:</p> <pre>\$ sudo /usr/TKLC/smac/bin/pmaccli getBgTasks</pre> <p>Note: The result will eventually display <i>PMAC Restore successful</i>.</p>
6	PMAC GUI: Login	<p>Open web browser and navigate to the PMAC GUI, Login as PMACadmin user:</p> <pre>https://<pmac_network_ip></pre> 
7	PMAC GUI: Verify Restore Task completed	<p>Navigate to Task Monitoring</p> <p>Verify the restore background task completed successfully.</p> <p>Note: After the restore is complete, you may see some tasks mentioning ISO images being deleted. This is normal behavior, ISO images will be added in the next step.</p>

Procedure 24: Restore PMAC from Backup Media

8	PMAC GUI: <input type="checkbox"/> Verify System Inventory	<p>Navigate to Main Menu -> System Inventory</p>  <p>Verify previously provisioned cabinets are present</p>
9	PMAC: Verify PMAC <input type="checkbox"/>	<p>Perform a system health check on the PMAC</p> <div style="background-color: #f0f0f0; padding: 5px;"><pre>\$ sudo /usr/TKLC/plat/bin/alarmMgr --alarmStatus</pre></div> <p>This command should return no output on a healthy system.</p> <div style="background-color: #f0f0f0; padding: 5px;"><pre>\$ sudo /usr/TKLC/smac/bin/sentry status</pre></div> <p>All Processes should be running, displaying output similar to the following:</p> <pre>PM&C Sentry Status ----- sentryd started: Mon Jul 23 17:50:49 2012 Current activity mode: ACTIVE Process PID Status StartTS NumR ----- ----- smacTalk 9039 running Tue Jul 24 12:50:29 2012 2 smacMon 9094 running Tue Jul 24 12:50:29 2012 2 hpiPortAudit 9137 running Tue Jul 24 12:50:29 2012 2 snmpEventHandler 9176 running Tue Jul 24 12:50:29 2012 2 Fri Aug 3 13:16:35 2012 Command Complete.</pre>
10	PMAC: Add ISO images to the PMAC <input type="checkbox"/>	<p>Re-add any needed ISO images to the PMAC by executing procedure <i>“Load DSR, SDS (Oracle X5-2/Netra X5-2/HP DL380 Gen 9 Only), and TPD ISOs to the PMAC Server”</i> from reference [8] for ALL ISO images as required.</p>


Procedure 25: Restore PMAC from Backup Server

S T E P #	<p>This procedure provides steps to restore the PMAC application configuration from backup server.</p> <p>Prerequisite: TVOE management server has been restored.</p> <p>Check off (✓) each step as it is completed. Boxes have been provided for this purpose under each step number.</p> <p>If this procedure fails, contact My Oracle Support (MOS) and ask for assistance</p>	
1 <input type="checkbox"/>	Deploy the PMAC Guest	<p>Execute section “<i>Install PM&C</i>” from reference [10]</p> <p>Note: This procedure is for restoring from a NetBackup server, so specify the appropriate options when deploying PM&C for use with NetBackup.</p>
2 <input type="checkbox"/>	PMAC TVOE Host: Login	<p>Establish an SSH session to the PMAC TVOE Host, login as admusr.</p>
3 <input type="checkbox"/>	PMAC TVOE Host: Login to PMAC Guest Console	<p>On the TVOE host, execute the following command:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> \$sudo virsh list </div> <p>This will produce a listing of currently running virtual machines.</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <pre>[admusr@Oahu-TVOE-1 ~]\$ sudo virsh list Id Name State -- -- 1 Oahu-PMAC running</pre> </div> <p>Find the VM name for your PMAC and note its ID number in the first column.</p>
4 <input type="checkbox"/>	<p>Connect to console of the VM using the VM number obtained in Step 3.</p>	<p>On the TVOE host, execute:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> \$sudo virsh console <PMAC-VMID> </div> <p>Where PMAC-VMID is the VM ID you obtained in Step 3:</p> <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <pre>[admusr@Oahu-TVOE-1 ~]\$ sudo virsh console 1 Connected to domain Oahu-PMAC Escape character is ^] Oracle Linux Server release 6.7 Kernel 2.6.32-573.3.1.el6prerel7.0.3.0.0_86.37.0.x86_64 on an x86_64 Oahu-PMAC login: [REDACTED]</pre> </div> <p>You are now connected to the PMAC guest console.</p> <p>If you wish to return to the TVOE host, you can exit the session by pressing CTRL +]</p>

Procedure 25: Restore PMAC from Backup Server

5 <input type="checkbox"/>	<p>PMAC: Prepare PMAC guest to transfer the appropriate backup from Backup Server. Disable iptables, and enable the TPD platcfg backup configuration menus.</p> <p>Run the following commands on the PMAC:</p> <pre>\$ sudo /sbin/service iptables stop iptables: Flushing firewall rules: [OK] iptables: Setting chains to policy ACCEPT: filter [OK] \$ sudo /usr/TKLC/smac/etc/services/netbackup start Modified menu NBConfig -- show Set the following menus: NBConfig to visible=1 Modified menu NBInit -- show Set the following menus: NBInit to visible=1 Modified menu NBDeInit -- show Set the following menus: NBDeInit to visible=1 Modified menu NBInstall -- show Set the following menus: NBInstall to visible=1 Modified menu NBVerifyEnv -- show Set the following menus: NBVerifyEnv to visible=1 Modified menu NBVerify -- show Set the following menus: NBVerify to visible=1=</pre>
-------------------------------	--


Procedure 25: Restore PMAC from Backup Server

<p>6 <input type="checkbox"/> PMAC: Verify the TPD platcfg backup menus are visible, then exit the TPD platcfg Utility</p>	<p>Issue the following command to verify the TPD platcfg backup menus are visible:</p> <pre>\$ sudo /bin/su - platcfg</pre>  <p>Note: In the example image above of the TPD platcfg utility Main Menu the backup menu is identified as "NetBackup Configuration".</p>
<p>7 <input type="checkbox"/> PMAC: Verify the iptables rules are disabled on the PMAC guest</p>	<p>Verify the iptables rules are disabled on the PMAC guest by executing the following command:</p> <pre>\$ sudo /sbin/iptables -nL</pre> <pre>INPUT (policy ACCEPT) target prot opt source destination Chain FORWARD (policy ACCEPT) target prot opt source destination Chain OUTPUT (policy ACCEPT) target prot opt source destination</pre>
<p>8 <input type="checkbox"/> PMAC: Install backup utility client software on the PMAC Guest</p>	<p>Execute section "<i>PM&C NetBackup Client Installation and Configuration</i>" from [10] - Start at step 4.</p> <p>Note: The "<i>Initialize PM&C Application</i>" and "<i>Configure PM&C application</i>" prerequisites can be ignored.</p>

Procedure 25: Restore PMAC from Backup Server

9	Backup Server: <input type="checkbox"/> Verify appropriate PMAC backup exists.	<p>This step will likely be executed by customer IT personnel.</p> <p>Log in to the Backup Server as the appropriate user, using the user password.</p> <p>Execute the appropriate commands to verify the PMAC backup exists for the desired date.</p> <p>Note: The actions and commands required to verify that the PM&C backups exist and the commands required to perform backup and restore on the Backup Server are the responsibility of the site customer.</p> <p>Note: It is important to choose the correct backup file to use in the restore. The latest backup may not be the backup which contains the system data of interest. This could be the case if the automatic backup, which is scheduled in the morning, is performed on the newly installed PM&C prior to the restoration of the data.</p>
10	Backup Server: <input type="checkbox"/> Verify appropriate PMAC backup exists.	<p>This step will likely be executed by customer IT personnel.</p> <p>Log in to the Backup Server as the appropriate user, using the user password.</p> <p>Execute the appropriate commands to verify the PMAC backup exists for the desired date.</p> <p>Execute the appropriate commands to restore the PM&C Management Server backup for the desired date.</p> <p>Note: The actions, and commands, required to verify the PM&C backups exist, and the commands required to perform backup and restore on the Backup Server are the responsibility of the site customer.</p>
11	PMAC: Verify no Alarms are present <input type="checkbox"/>	<p>Verify no alarms are present by executing the following command:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ sudo /usr/TKLC/plat/bin/alarmMgr --alarmStatus</pre> </div>
12	Restore the PMAC Data from Backup <input type="checkbox"/>	<p>Restore the PMAC data from backup by executing the following command:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ sudo /usr/TKLC/smac/bin/pmacadm restore</pre> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <p>PM&C Restore been successfully initiated as task ID 1</p> </div> <p>To check the status of the background task, issue the following command:</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> <pre>\$ sudo /usr/TKLC/smac/bin/pmaccli getBgTasks</pre> </div> <p>Note: The result will eventually display <i>PMAC Restore successful</i>.</p>

Procedure 25: Restore PMAC from Backup Server

13	PMAC GUI: Login	Open web browser and navigate to the PMAC GUI, Login as PMACadmin user: <div style="border: 1px solid black; padding: 2px; display: inline-block;"> <a href="https://<pmac_network_ip>">https://<pmac_network_ip> </div> 
14	PMAC GUI: Verify Restore Task completed	Navigate to Task Monitoring Verify the restore background task completed successfully. Note: After the restore is complete, you should see "Add Enclosure" tasks start for all previously provisioning servers. These should be allowed to complete before continuing. Note: After the restore is complete, you may see some tasks mentioning ISO images being deleted. This is normal behavior, ISO images will be added in the next step.
15	PMAC GUI: Verify System Inventory	Navigate to Main Menu -> System Inventory  Verify previously provisioned enclosures are present

Procedure 25: Restore PMAC from Backup Server

16 <input type="checkbox"/>	PMAC: Verify PMAC	<p>Perform a system health check on the PMAC</p> <pre>\$ sudo /usr/TKLC/plat/bin/alarmMgr --alarmStatus</pre> <p>This command should return no output on a healthy system.</p> <pre>\$ sudo /usr/TKLC/smac/bin/sentry status</pre> <p>All Processes should be running, displaying output similar to the following:</p> <pre>PM&C Sentry Status ----- sentryd started: Mon Jul 23 17:50:49 2012 Current activity mode: ACTIVE Process PID Status StartTS NumR ----- ----- smacTalk 9039 running Tue Jul 24 12:50:29 2012 2 smacMon 9094 running Tue Jul 24 12:50:29 2012 2 hpiPortAudit 9137 running Tue Jul 24 12:50:29 2012 2 snmpEventHandler 9176 running Tue Jul 24 12:50:29 2012 2 Fri Aug 3 13:16:35 2012 Command Complete.</pre>
17 <input type="checkbox"/>	PMAC: Add ISO images to the PMAC	<p>Re-add any needed ISO images to the PMAC by executing procedure “<i>Load Application and TPD ISO onto PMAC Server</i>” from reference [8]</p>

Appendix I. Workarounds for Issues not fixed in this Release

Issue	Associated PR	Workaround
Inetsync alarms after performing disaster recovery	222828	<p>Restart the Inetsync service on all affected servers using the following commands:</p> <div style="border: 1px solid black; padding: 5px; width: fit-content;"><pre>\$ pm.set off inetsync \$ pm.set on inetsync</pre></div>

Appendix J. My Oracle Support (MOS)

MOS (<https://support.oracle.com>) is your initial point of contact for all product support and training needs. A representative at Customer Access Support (CAS) can assist you with MOS registration.

Call the CAS main number at **1-800-223-1711** (toll-free in the US), or call the Oracle Support hotline for your local country from the list at <http://www.oracle.com/us/support/contact/index.html>.

When calling, there are multiple layers of menus selections. Make the selections in the sequence shown below on the Support telephone menu:

1. For the first set of menu options, select 2, "New Service Request". You will hear another set of menu options.
2. In this set of menu options, select 3, "Hardware, Networking and Solaris Operating System Support". A third set of menu options begins.
3. In the third set of options, select 2, "Non-technical issue". Then you will be connected to a live agent who can assist you with MOS registration and provide Support Identifiers. Simply mention you are a Tekelec Customer new to MOS.